# User manual

## Refrigeration Dryer



DATE: 2012.06.20 - Rev.2 CODE: 272889



## Index

- 1. Safety
- 2. Introduction
- 3. Installation
- 4. Commissioning
- 5. Control
- 6. Maintenance
- 7. Troubleshooting

#### 8. Appendix

- There are symbols whose meaning is given in the paragraph 8.1.
  - 8.1 Legend
  - 8.2 Installation diagram
  - 8.3 Technical data
  - 8.4 Spare parts list
  - 8.5 Exploded drawings
  - 8.6 Dimensional drawings
  - 8.7 Refrigerant circuits
  - 8.8 Wiring diagram

## 1 Safety

#### 1.1 Importance of the manual

- Keep it for the entire life of the machine.
- Read it before any operation.
- It is subject to changes: for updated information see the version on the unit.

#### 1.2 Warning signals

	Instruction for avoiding danger to persons.
F	Instruction for avoiding damage to the equipment.
	The presence of a skilled or authorized technician is required
	There are symbols whose meaning is given in the para.8.

#### 1.3 Safety instructions

Always disconnect the dryer from the main power supply before starting maintenance work.

The manual is intended for the end-user, only for operations performable with closed panels: operations requiring opening with tools must be carried out by skilled and qualified personnel.

Do not exceed the design limits given on the dataplate.

It is the user's responsibility to avoid loads different from the internal static pressure. The unit must be appropriately protected whenever risks of seismic phenomena exist.

The safety devices on the compressed air circuit must be provided for by the user.

Only use the unit for professional work and for its intended purpose.

The user is responsible for analysing the application aspects for product installation, and following all the applicable industrial and safety standards and regulations contained in the product instruction manual or other documentation supplied with the unit.

Tampering or replacement of any parts by unauthorised personnel and/or improper machine use exonerate the manufacturer from all responsibility and invalidate the warranty.

The manufacturer declines and present or future liability for damage to persons, things and the machine, due to negligence of the operators, non-compliance with all the instructions given in this manual, and non-application of current regulations regarding safety of the system.

The manufacturer declines any liability for damage due to alterations and/or changes to the packing.

It is the responsibility of the user to ensure that the specifications provided for the selection of the unit or components and/or options are fully comprehensive for the correct or foreseeable use of the machine itself or its components.

**IMPORTANT:** The manufacturer reserves the right to modify this manual at any time.

For the most comprehensive and updated information, the user is advised to consult the manual supplied with the unit.

#### 1.4 Residual risks:

The installation, start up, stopping and maintenance of the ma-

chine must be performed in accordance with the information and instructions given in the technical documentation supplied and always in such a way to avoid the creation of a hazardous situation. The risks that it has not been possible to eliminate in the design stage are listed in the following table.

part affected	residual risk	manner of exposure	precautions
heat exchanger coil	small cuts	contact	avoid contact, wear protective gloves
fan grille and fan	lesions	insertion of poin- ted objects through the grille while the fan is in operation	do not poke objects of any type through the fan grille or place any objects on the grille
<i>inside the unit:</i> compressor and discharge pipe	burns	contact	avoid contact, wear protective gloves
<i>inside the unit:</i> metal parts and electrical wires	ide the unit: tal parts and ctrical wires intoxication, electrical shock, serious str burns intoxication, elat shock, serious str tri		adequate electrical protection of the power supply line; ensure metal parts are properly con- nected to earth
outside the unit: area surroun- ding the unit	intoxication, serious burns	fire due to short circuit or overhea- ting of the supply line upstream of the unit's electrical panel	ensure conductor cross-sectional areas and the sup- ply line protection system conform to applicable regula- tions

## 2 Introduction

This manual refers to refrigeration dryers designed to guarantee high quality in the treatment of compressed air.

#### 2.1 Transport

The packed unit must:

- a) remain upright;
- b) be protected against atmospheric agents;
- c) be protected against impacts.

#### 2.2 Handling

Use a fork – lift truck suitable for the weight to be lifted, avoiding any type of impact.

#### 2.3 Inspection

- a) All units are assembled, wired, filled with coolant and oil, and tested under standard operating conditions in the factory;
- b) on receiving the machine check its condition: immediately notify the transport company in case of any damage;
- c) unpack the unit as close as possible to the place of installation.

#### 2.4 Storage

If several units have to stacked, follow the notes given on the packing. Keep the unit packed in a clean place protected from damp and bad weather.

## **3** Installation

#### 3.1 Procedures

Install the dryer inside, in a clean area protected from direct atmospheric agents (including sunlight).

**Comply with the instructions given in par.** 8.2 and 8.3. All dryers must be fitted with adequate pre-filtration near the dryer air inlet. Seller is excluded any obbligation of compensation or refund for any direct or indirect damage caused by its absence.

**I** Pre-filter element (for 3 micron filtration or better) must be replaced at least once a year, or sooner as per manufacturer recommendations.

 $\square T$  Do not invert the compressed air inlet and outlet connections and observe the maximum tightening torque (N x m) as specified in par. 8.3.

#### **3.2 Operating space**

E Leave a space of 60 inches (1.5 m) around the unit.

#### 3.3 Tips

To prevent damage to the internal parts of the dryer and air compressor, avoid installations where the surrounding air contains solid and/or gaseous pollutants (e.g. sulphur, ammonia, chlorine and installations in marine environments).

The ducting of extracted air is not recommended for versions with axial fans.

#### **3.4** Electrical connection

Use approved cable in conformity with the local laws and regulations (for minimum cable section, see par. 8.3). Install a differential thermal magnetic circuit breaker with contact opening distance  $\geq 0.12$  inches (3 mm) ahead of the system (IDn = 0.3A) (see the relevant current local regulations). The nominal current In of the magnetic circuit breaker must be equal to the FLA with an intervention curve type D.

#### 3.5 Condensate drain connection

The dryer is supplied either with a float drain, a timed drain or an electronic level sensing drain.

If a timed or electronic unloader is installed, use terminals CN (R1-S1) (see par. 8.8).

For timed and electronic drains: refer to separate manual supplied with the dryer for specific details concerning the condensate drain.

 $\square \mathcal{F}$  Make the connection to the draining system, avoiding connection in a closed circuit shared by other pressurized discharge lines. Check the correct flow of condensate discharges. Dispose of all the condensate in conformity with current local environmental regulations.

## 4 Commissioning

#### 4.1 Preliminary checks

Before commissioning the dryer, make sure:

- a) installation was carried out according that given in the section 3;
- b) the air inlet valves are closed and that there is no air flow through the dryer;
- c) the power supply is correct;

#### 4.2 Starting

a) Start the dryer before the air compressor by means of the main power switch (14); the power lamp will illuminate

(green);

b) after at least 5 minutes slowly open the air inlet valve and subsequently open the air outlet valve: the dryer is now performing its air drying function.

#### 4.3 Operation

- a) Leave the dryer on during the entire period the air compressor is working;
- b) the dryer operates in automatic mode, therefore field settings are not required;

c) in the event of unforeseen excess air flows, by – pass to avoid overloading the dryer;

#### 4.4 Stop

- a) Stop the dryer 2 minutes after the air compressor stops or in any case after interruption of the air flow;
- b) do not allow compressed air to flow through the dryer when the latter is not running;
- c) switch off at the main power switch <sup>(14)</sup>. The power light goes out and the compressor stops.

## 5 Control



## **6** Maintenance

- a) The machine is designed and built to guarantee continuous operation; however, the life of its components depends on the maintenance performed;
- b) when requesting assistance or spare parts, identify the machine (model and serial number) by reading the dataplate located on the unit.

#### 6.1 General instructions

Before any maintenance, make sure:

- the pneumatic circuit is no longer pressurized;
- the dryer is disconnected from the main power supply.

 $\square \mathcal{F}$  Always use the Manufacturer's original spare parts: otherwise the Manufacturer is relieved of all liability regarding machine malfunctioning.

 $\square \overline{F}$  In case of refrigerant leakage, contact qualified and authorized personnel.

 $\square$  The Schrader valve must only be used in case of machine malfunction: otherwise any damage caused by incorrect refrigerant charging will not be covered by the warranty.

#### 6.2 Refrigerant 🕐

Charging: any damage caused by incorrect refrigerant replacement carried out by unauthorized personnel will not be covered by the warranty.

 $\square \overrightarrow{F}$  At normal temperature and pressure, the R134a refrigerant is a colourless gas classified in SAFETY GROUP A1 – EN378 (group 2 fluid according to Directive PED 97/23/EC); GWP (Global Warming Potential) = 1300.

 $\triangle$  In case of refrigerant leakage, ventilate the room.

#### 6.3 **Preventive Maintenance Programme**

To guarantee lasting maximum dryer efficiency and reliability:

Maintenance Activity Description	Maintenance Interval (standard operating conditions)					
Activity	Daily	Weekly	4 Months	12 Months		
Check POWER ON indicator is lit.	$\checkmark$					
Check control panel indicators.	$\swarrow$					
Check condensate drain.		$\sim$				
Clean condenser fins.			1			
Check electrical absorption.			$\sim$			
Depressurize the dryer. Complete drain maintenance.				1		
Depressurize the dryer. Repalce pre – and post – filter ele- ments.				1		
4	chec	k	se	ervice		

The following are available (see par. 8.4):

- a) compressor kits;
- b) fan kits;
- c) automatic expansion valve kits;
- d) individual spare parts.

#### 6.4 Dismantling

The refrigerant and the lubricating oil contained in the circuit must be recovered in conformity with current local environmental regulations.

A S	Recycling Disposal
structural work	steel/epoxy-polyester resins
exchanger	aluminium
pipes	aluminium/copper
drain	polyamide
exchanger insulation	EPS (sintered polystyrene)
pipe insulation	synthetic rubber
compressor	steel/copper/aluminium/oil
condenser	steel/copper/aluminium
refrigerant	R134a
valves	brass
electrical cables	copper/PVC

## 7 Troubleshooting



## 8 Appendix

#### 8.1 Legend

	Meaning		Meaning
① MC	Compressor	(12) PV	Fan pressure switch
2	Refrigerant condenser	( <b>13</b> ) HT	High temperature safety thermostat
③ EV	Fan motor	( <b>1</b> 4) QS	Main power switch
4	Evaporator	(15)	Cover
5	Separator	CN	Electronic condensate drain power supply
6	Power cable	SK	Overload protector
7 AEV	Expansion automatic valve	KA	Starting relay
8	Refrigerant filter	С	Compressor starting capacitor
(10)	Airair exchanger	QF	Residualcurrent automatic circuit breaker
1	Dewpoint indicator		

#### 8.2 Installation diagram



1	Air compressor
2	Dryer
3	Bypass unit
4	Filter (3 micron filtration or better) near dryer air inlet
5	Tank in position A or in B
6	Outlet filter
7	OilWater separator
8	Condensate drain

⚠	ſ	Safety valves for not exceeding dryer design pressure
	I	Hoses for air connections if the system undergoes vibrations
⚠	I	Suitable dampers if the system undergoes pulsations

## 8.3 Technical data

	Weight Refrigerant		Weight		Refrig	gerant	MINM Ambient tem	AX. perature	Compressed	Air-side			Minimum section	Compressed air inlet/outlet	Connections (Tightening torque)	0.1
					- Am	b	air inlet	max. working	<b>F.L.A</b> . [A]		validated cable	<u>a</u>	<i>E U</i>	Sound pressure level		
			a (Kg)	During transport and stockage	After installation	temperature pressure				for eletrical connection	Ğ	×				
	(lb)	(kg)	(oz)	(kg)	1		la In	Max 🌐	115V±10% 1ph/60Hz	230V±10% 1ph/60Hz	Ø	NPT	[N x m]	<b>◀</b> <sup>€</sup> [dB(A)]		
										-						
PRD10	41.8	19	5.99	0.17					3.74	-		NPT		50		
PRD15										-		(compatible)				
PRD25	51.9	22.5	0.52	0.27	32–122°F	41–122°F	149°F	232 PSIg	1 79	-	2C16AWG	1/2"	50			
PRD35	51.0	23.5	9.52	0.27	0-50°C	5-50°C	65°C	16 bar	4.78	-	JUIDAWU		50			
PRD50	58.4	26.5	8.81	0.25	1				8.31	-	1	NPT	1	55		
PRD75	68.3	31	9.52	0.27					10.23	-	1	(with adaptor)				
PRD100	77.2	35	12.34	0.35					12.44	6.22	]	3/4"				

Calibration values	Expansion automatic valve	Fan pressure switch			
<u>K</u>	AEV	(12) PV			
PRD10PRD15	35 PSIg (+1.5, -0) 2.4 bar (+0.1, -0)	ON: 160 PSIg OFF: 116 PSIg			
PRD25PRD100	32 PSIg (+1.5, -0) 2.2 bar (+0.1, -0)	ON: 11 bar OFF: 8 bar			

## 8.4 🛄 Spare parts list

			(8.5)	PRD10	PRD15	PRD25	PRD35	PRD50	PRD75	PRD100
-)	Commence lit	(115V/1Ph/60Hz)		SP-147439		SP-147405		SP-147100	SP-147339	SP-147341
a)	Compressor kit	(230V/1Ph/60Hz)	(1) (8)							
•	F 1'	(115V/1Ph/60Hz)		SP-38	SP-381679 SP-381793					SP-381616
D)	Fan Kit	(230V/1Ph/60Hz)	3			SP-381794				
c)	Automatic expansion	n valve kit	78		SP-473108					SP-473109
	Refrigerant condenser		2	SP-11	SP-114800 SP-114801		SP-114802	SP-114803	SP-114754	
	Evaporator/Separetor/Air-air heat-exchanger		4 5 10	SP-47	SP-472157 SP-472158 SP-472159				SP-472159	
	Power cable		6	SP-256347						
	Refrigerant filter		8	SP-206214						
d)	Dewpoint indicator		11)	SP-354317						
	Fan pressure switch		12	SP-354376						
	High temperature safety thermostat		13	SP-473399						
	Main power switch		14		SP-255132					
	Cover		15	SP-13	SP-137926 SP-137928 SP-137931					

## 8.5 Exploded drawing



## 8.6 Dimensional drawing PRD10--PRD15



## Dimensional drawing PRD25--PRD35



## Dimensional drawing PRD50--PRD100



## 8.7 Refrigerant circuit



Wiring diagram PRD10--PRD15



#### Wiring diagram PRD25--PRD100





© 2012 Parker Hannifin Corporation. Product names are trademarks or registered trademarks of their respective companies



Parker Hannifin Corporation Finite Airtek Filtration Division 4087 Walden Avenue Lancaster, NY 14086 phone 716 686 6400 www.parker.com/faf