



**Panasonic**

**Operating Instructions  
IC Recorder**

Model No. **RR-US360**

**Dear customer**

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully. Before connecting, operating or adjusting this product, please read these instructions completely. Please keep this manual for future reference.



P1 En

Panasonic Consumer Electronics Company,  
Division of Matsushita Electric Corporation of America  
One Panasonic Way Secaucus, New Jersey 07094  
<http://www.panasonic.com>

Panasonic Sales Company, Division of Matsushita Electric of Puerto Rico, Inc. ("PSC")  
Ave. 65 de Infantería, Km. 9.5 San Gabriel Industrial Park, Carolina, Puerto Rico 00985  
© 2004 Matsushita Electric Industrial Co., Ltd.  
Printed in Japan

RQT7944-P  
F1004TJ0

**Before use**

**Hint 1** Release hold before operation

**Hint 2** Recorded contents are stored in folders

**Hint 3** Use HQ to record with high sound quality and SP for long recordings

**Hint 4** Change the microphone sensitivity according to the distance

There is no power button.

The unit returns to standby if there is no operation after 10 seconds have elapsed.

Press [ ] to stop the operation midway/cancel the setting.

A maximum of 99 files can be stored in each folder.

Recording mode and recording time total of all folders

Recording Mode	SP (Standard play)	FQ (Fine quality)	HQ (High quality)
RR-QR380	8 hours 30 minutes	9 hours 40 minutes	4 hours 30 minutes
RR-QR360	4 hours 30 minutes	5 hours 00 minutes	2 hours 30 minutes

High quality sound

When recording close to the source: LO

When recording the source from a distance: HI

**Menu display**

File lock, Preventing unnecessary recording, Play speed, Continuous play

Use [ ] to change the menu and [ ] to enter

Press and hold (More than 2 seconds)

E.g.: Microphone sensitivity

Setting the time, Timer play, Timer recording, Operation beep

\*1 Not displayed during dictation recording.  
\*2 Displayed only when there is a recorded file.  
\*3 Displayed only when the time is set.

This product may receive radio interference caused by mobile telephones or other products during operation. If such interference is apparent, please increase separation between the product and the mobile telephone or other product.

**CAUTION:**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
• Reorient or relocate the receiving antenna.  
• Increase the separation between the equipment and receiver.  
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
• Consult the dealer or an experienced radio/TV technician for help.  
Any unauthorized changes or modifications to this equipment would void the user's authority to operate this device.  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Recording**

1 Select meeting or dictation recording 2 Select the folder 3 Select the recording mode 4 Select the microphone sensitivity 5 Recording (Monaural recording)

Meeting recording: Press and hold [FOLDER/MENU] to enter MEETING mode. Select folder (A-D), then recording mode (SP, FQ, HQ), and microphone sensitivity (HI, LO).

Dictation recording: Press and hold [FOLDER/MENU] to enter DICTATION mode. Select folder (A-D). When dictation recording, the following settings are automatically set: Dictation folder, HQ mode, and Dictation recording mode.

Recording information is displayed: (Recording date), (Recording start time), (Recording time), (Total number of files).

**Other recording methods**

Recording automatically pauses when there is no sound.

**Preventing unnecessary recording:** Enter menu mode, select "OFF", select "On".

**Checking the remaining recording time available:** Press and hold [FOLDER/MENU] to display remaining recording time.

**Recording through an external microphone (not included):** Plug type: 3.5 mm (1/8 in.) monaural. Use a plug-in power compatible microphone monaural.

**Preparation 1 Inserting batteries**

**Supplied accessories:** USB cable (K1HA09BD0001), CD-ROM (Voice Editing).

**To order accessories, refer to "Accessory Purchases" on page 8.**

AAA, LR03, AM-4 battery (not included)

The battery indicator (displayed during operation)

Replace the batteries within 30 seconds to preserve the settings. Recordings remain intact.

**Playing/Erasing**

1 Select the folder 2 Select file or folder 3 Play/Erase

**Playing:** Select folder (A-D), then file number. Press and hold [ ] to play.

**Erasing:** Select folder (A-D), then file number. Press and hold [ERASE] to erase.

**Basic operations during play:** Backward, Forward, Stop play, Listen to the first 5 seconds of each file (Intro scan).

**Other play methods**

**Changing the play speed (5 levels):** Enter menu mode, select "SPEED", select speed.

**Continuous play:** Enter menu mode, select "On", select "On".

**Displaying the remaining play time:** Press and hold [FOLDER/MENU] to display remaining play time.

**Listening with the earphones (not included):** Plug type: 3.5 mm (1/8 in.) monaural.

**Preparation 2 Setting the time**

Flashes until the time is set.

When the year is flashing (e.g. 2004), begin from step 3.

1 Enter the menu mode. Press and hold [FOLDER/MENU].

2 Select "YEAR". Use [ ] to select.

3 Set the time: Year, Month/day, Time display (12/24H), Time.

The clock has a monthly accuracy of +/- 60 seconds at room temperature. When replacing the batteries, the clock stops and restarts when you reinsert them and close the battery cover.

**Organizing**

1 Play a file 2 Enter the move mode 3 Select the destination folder 4 Move

**Move:** Play file, Press and hold [FOLDER/MENU], select destination folder.

**File lock:** Select folder, enter menu mode, select "Lock", select file, lock.

**Saving (dubbing)**

Select the file to dub and play [ ]

**Recording to a cassette tape recorder:** Audio cable, Monaural mini plug, Stereo mini plug, Monaural MIC.

**Recording from a cassette tape recorder:** Audio cable, Monaural mini plug, Stereo mini plug, Headphone jack.

