Register your product and get support at www.philips.com/welcome

HTS3276

HTS3371

HTS3378



- ZH-TW 使用手册
- MS-MY Manual pengguna

PHILIPS

Contents

1	Important Safety and important notice	4 4
	Trademark notice	5
2	Your Home Theater System	6
	Feature highlights	6
	Product overview	7
3	Connect	10
	Place the Home Theater System	10
	Connect video cables	11
	Connect speaker cables to speakers	12
	Connect speaker to speaker stand	12
	Connect speakers and subwoofer	13
	Connect radio antenna	13
	Connect audio cables/other devices	14
	Connect power cord	16
4	Get started	17
	Insert the remote control batteries	17
	Find the correct viewing channel	18
	Select menu display language	18
	Turn on Progressive Scan	19
	Change speaker settings	20
	Use Philips EasyLink	21
	Select a play source	23
5	Play	24
-	Play a disc	24
	Play video	24
	Play music	28
	Play photo	29
	Play from USB device	30
	Play from portable media player	31
	Play from radio	31

6	Advanced features Create MP3 audio files	33 33
7	Adjust sound Control the volume Select surround sound Select a preset sound Adjusting microphone volume level Karaoke settings Turning vocals off (voice cancel)	34 34 34 35 35 35
8	Adjust settings General setup Audio setup Video setup Preferences	36 36 38 40 42
9	Additional Information Update software Care	44 44 44
10	Specifications	45
11	Troubleshooting	47
12	Glossary	49

English

Contents

ΕN 3

1 Important

Safety and important notice

Warning

- Risk of overheating! Never install the Home Theater System in a confined space. Always leave a space of at least 4 inches around the Home Theater System for ventilation. Ensure curtains or other objects never cover the ventilation slots on the Home Theater System.
- Never place the Home Theater System, remote control or batteries near naked flames or other heat sources, including direct sunlight.
- Only use this Home Theater System indoors. Keep this Home Theater System away from water, moisture and liquid-filled objects.
- Never place this Home Theater System on other electrical equipment.
- Keep away from this Home Theater System during lightning storms.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Visible and invisible laser radiation when open. Avoid exposure to beam.

Recycling notice



This electronic equipment contains a large number of materials that can be recycled or reused if disassembled by a specialised company. If you are disposing of an old machine, please take it to a recycling centre. Please observe the local regulations regarding disposal of packaging materials, exhausted batteries and old equipment.

Copyright notice

Be responsible Respect copyrights

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protected technology must be authorised by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorised by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

About Progressive Scan

Consumers should note that not all high definition television sets are fully compatible with this product and may cause artefacts to be displayed on the picture. In case of 525 or 625 progressive scan picture problems, it is recommended that the user switch the connection to the 'standard definition' output. If there are questions regarding our TV set compatibility with this model 525p and 625p DVD player, please contact our customer service centre.

Trademark notice

DIGITAL

Manufactured under license from Dolby Laboratories. Dolby, Pro Logic and the double-D symbol are trademarks of Dolby Laboratories.



DivX, DivX Ultra Certified, and associated logos are trademarks of DivX, Inc. and are used under license.

Official DivX® Ultra Certified product. Plays all versions of DivX® video (including DivX® 6) with enhanced playback of DivX® media files and the DivX® Media Format. Plays DivX® video with menus, subtitles and audio tracks.



Manufactured under license under U.S. Patent #'s: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535 & other U.S. and worldwide patents issued & pending. DTS and DTS Digital Surround are registered trademarks and the DTS logos and Symbol are trademarks of DTS, Inc. © 1996-2007 DTS, Inc. All Rights Reserved.



ENERGY STAR and the ENERGY STAR mark are registered U.S. trademarks.



Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

HDMI, and HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC.



The USB-IF Logos are trademarks of Universal Serial Bus Implementers Forum, inc.



2 Your Home Theater System

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Feature highlights

Video upscaling to 1080p

Enjoy watching discs in the highest picture quality available for your HDTV. This Home Theater System offers full high-definition video playback up to 1080p resolution that provides a highly detailled picture and increased sharpness that delivers a more true-to-life picture for an amazing viewing experience.

Philips EasyLink

Your Home Theater System supports Philips EasyLink, which uses the HDMI CEC (Consumer Electronics Control) protocol. EasyLink-compliant devices that are connected through HDMI connectors can be controlled by a single remote control.



• Philips does not guarantee 100% interoperability with all HDMI CEC devices.

Listen to rich uncompressed multi-channel surround sound

This Home Theater System supports 5.1 channels of uncompressed audio that delivers a real-to-life sound experience as if you are listening to it live.

High speed USB 2.0 Link and MP3 link

Simply plug your USB device into the USB jack to play your MP3/WMA/JPEG/DivX files; or plug your portable media player to the MP3 LINK jack to enjoy the music play in superb sound quality.

Sync the audio output with the video play

Synchronise audio and video by delaying the audio output if the video signal sent to the TV is slower than the audio streams.

Create MP3 files

Convert your favourite audio tracks from an audio CD into MP3 format. The created MP3 files are saved in your USB device.

Screen Fit

View the movie in full screen display on any TV.

Karaoke scoring function

Karaoke scoring gives a score and a comment for each performance. Have your singing performance scored for even more karaoke fun at home!

Region codes

You can play discs with the following region codes.

DVD region code Countries



Asia Pacific, Taiwan, Korea




Australia, New Zealand

Your Home Theater System

English

Product overview

Main unit



(1 (Standby-On)

- Turns on the Home Theater System or switches to standby mode.
- 2 Disc compartment

③ ▲ (Open/Close)

Opens or closes the disc compartment.

(4) ►II (Play/Pause)

- Starts, pauses or resumes disc play.
- In radio mode, automatically tunes radio stations during first-time setup.

(5) ■ (Stop)

- Stops disc play.
- In radio mode, erases the current preset radio station.

6 SOURCE

• Selects a media to play or listen to audio from the connected device.

7 Display panel

 Displays the current status or disc information.

8 IR sensor

• Detects signals from the remote control. Point the remote control at the IR sensor.

9 VOL

• Increases or decreases volume.

10 MP3 LINK

• Connects a portable audio player


MIC

• Connects a microphone.

(12) + ↔ (USB)

• Connects a USB supported device.

Remote Control



1 (Standby-On)

- Turns on the Home Theater System or switches to standby mode.
- Press and hold to turn off the Home Theater System and all HDMI CEC compliant devices.

② ▲ (Open/Close)

 Opens or closes the disc compartment.

3 PROGRAM / REPEAT

- In radio mode, resets the list of preset stations: press to manually reset; press and hold to automatically reset.
- Selects or turns off repeat or shuffle mode.

(4) 🗉 SETUP

• Accesses or exits the setup menu.

(S) ▲▼◀► (Navigation buttons)

- Navigates through the menus.
- Press left and right for fast backward or forward search.
- In radio mode, press up and down to tune the radio frequency.
- In radio mode, press left or right to start auto search.

6 🗉 INFO

- For discs, displays information about the current status or the disc.
- For slideshows, displays a thumbnail view of photo files.

⑦ ►II (Play/Pause)

- Starts, pauses or resumes disc play.
- In radio mode, automatically tunes radio stations during first-time setup.

⑧ ■(Stop)

- Stops disc play.
- In radio mode, erases the current preset radio station.

9 SURR (Surround Sound)

• Switches to supported surround sound or stereo sound.

10 AUDIO SYNC

- Selects an audio language or channel.
- Press and hold to access the setting for audio sync, then press VOL +/- to set the audio delay time.

(1) Numeric buttons

Selects an item to play.

12 SUBTITLE

- Select DVD or DivX subtitle languages.
- (13) VOCAL
 - Changes the audio channel of a karaoke disc.
- (14) MIC (VOL +/-)
 - Increases or decreases microphone volume.
- (15) Source buttons
 - AUDIO SOURCE: Selects an audio input source.
 - **RADIO**: Switches to FM band.
 - **USB**: Switches to the USB source.
 - **DISC**: Switches to the disc source.
- (16) OK
 - Confirms an entry or selection.
- (17) ➡ BACK
 - Returns to a previous screen.
 - For DVD, goes to the title menu.
 - For VCD version 2.0 or SVCD with PBC turned on, returns to the menu during playback.

(18) ► / ► (Previous/Next)

- Skips to the previous or next title, chapter or track.
- (19) ♥ (Mute)
 - Mutes or restores audio output.
- 20 VOL +/-
 - Increases or decreases volume.
- 21 SOUND
 - Selects a predefined sound effect.

2 ZOOM / CREATE MP3

- Zooms in or out of the picture.
- Accesses the menu to create MP3.
- 23 KARAOKE
 - Accesses or exits the karaoke menu.

3 Connect

Make the following connections to use your Home Theater System.

Basic connections:

- Video
- Speakers and subwoofer
- Power

Optional connections:


- Radio antenna
- Audio
 - Audio from TV
 - Audio from digibox/recorder/game console
- Other devices
 - Portable media player
 - USB device

- Note

- Refer to the type plate at the back or bottom of the product for identification and supply ratings.
- Before you make or change any connections, ensure that all the devices are disconnected from the power outlet.

Place the Home Theater System

- Place the Home Theater System where it cannot be pushed, pulled over or knocked down. Do not place it in an enclosed cabinet.
- Make sure that you have full access to the power cord for easy disconnection of the Home Theater System from the power supply.



Different set of speakers for HTS3371 and HTS3378 (see 'Specifications' > 'Speakers').

- 1 Place this Home Theater System near the TV.
- 2 Place the speakers system at normal listening ear-level and directly parallel to the listening area.
- **3** Place the subwoofer in the corner of the room or at least 3 feet away from the TV.

⊁ Тір

• To avoid magnetic interference or unwanted noise, never place this Home Theater System too close to any radiation devices.

Connect video cables


Connect this Home Theater System to TV to view disc play. Select the best video connection that the TV can support.

- Option 1: Connect to the HDMI jack (for a HDMI, DVI or HDCP-compliant TV).
- Option 2: Connect to the component video jacks (for a standard TV or progressive scan TV).
- Option 3: Connect to the video (CVBS) jack (for a standard TV).

Note

• You must connect this Home Theater System directly to a TV.

Option 1: Connect to the HDMI jack



1 Connect an HDMI cable (not supplied) to the HDMI OUT jack on this Home Theater System and the HDMI input jack on the TV.




• If your device supports HDMI CEC, you can control compliant devices with a single remote control. (see 'Get started' > 'Use Philips EasyLink').

🔆 Tij

- If the TV has a DVI connection only, connect via a HDMI/DVI adaptor. Connect an audio cable for sound output.
- You can optimise the video output. (see 'Adjust settings' > 'Video setup' > [HDMI Setup]).
- This type of connection provides the best picture quality.

Option 2: Connect to the component video jack




- 1 Connect the component video cable (not supplied) to the **Y Pb Pr** jacks on this Home Theater System and the COMPONENT VIDEO input jacks on the TV.
 - If a progressive scan TV is used, you may turn on the progressive scan mode. (see 'Get started' > 'Turn on progressive scan').

Note

- The component video input jack on the TV might be labelled as Y Pb/Cb Pr/Cr or YUV.
- This type of connection provides good picture quality.

Option 3: Connect to the Video (CVBS) jack



 Connect a composite video cable to the VIDEO jack on this Home Theater System and the VIDEO input jack on the TV.

Note

- The video input jack on the TV might be labelled as A/V IN, VIDEO IN, COMPOSITE or BASEBAND.
- This type of connection provides standard picture quality.

Connect speaker cables to speakers


For models with tallboy speakers (HTS3276, HTS3378).



1 Connect the speaker cables to the matching colour jacks on the speakers (or speaker stands).

Connect speaker to speaker stand

For models with tallboy speakers (HTS3276, HTS3378).




1 Attach the speakers to the speaker stands and secure the position with screws.

Connect speakers and subwoofer

For HTS3276

(HTS3371 and HTS3378 have a different set of speakers)




1 Connect the speakers and subwoofer to the matching jacks on the Home Theater System.



• Ensure that the colours of the plugs and jacks are matched.

Connect radio antenna



- Connect the FM antenna to the FM75Ω jack on this Home Theater System (for some models, this cable is already connected).
- 2 Extend the FM antenna and fix its ends to the wall.



• For better FM stereo reception, connect to an external FM antenna.


Connect

Connect audio cables/other devices

Route the audio from other devices to this Home Theater System to enjoy audio play with multi-channel surround capabilities.

Connect audio to TV

(also used for EasyLink control)



1 Connect the audio cables (not supplied) to the AUDIO IN-AUX1 jacks on the Home Theater System and the AUDIO output jacks on the TV.


- Note

 To listen to the audio output from this connection, press AUDIO SOURCE repeatedly until 'AUX1' is displayed on the display panel.

Connect audio from cable box/ recorder/game console

You can choose to connect to analogue or digital jacks depending on the device capabilities.

Connect to analogue jacks



 Connect the audio cables (not supplied) to the AUDIO IN-AUX2 jacks on the Home Theater System and the AUDIO output jacks on the device.

Note

 To listen to the audio output from this connection, press AUDIO SOURCE repeatedly until 'AUX2' is displayed on the display panel.

Connect to coaxial jack


000 COAXIAL DIGITAL IN COAXIAL Ð DIGITAL OUT

1 Connect a coaxial cable (not supplied) to the COAXIAL DIGITAL-IN jack on the Home Theater System and the COAXIAL/DIGITAL output jack on the device.

Note

• To listen to the audio output from this connection, press AUDIO SOURCE repeatedly until 'COAX IN' is displayed on the display panel.

Connect to optical jack




1 Connect an optical cable (not supplied) to the OPTICAL DIGITAL-IN jack on the Home Theater System and the OPTICAL/SPDIF output jack on the device.



Note

· To listen to the audio output from this connection, press AUDIO SOURCE repeatedly until 'OPTI IN' is displayed on the display panel.

Connect portable media player




1 Connect a 3.5mm stereo audio cable (not supplied) to the MP3 LINK jack on this Home Theater System and the phone jack on the portable media player (such as MP3 player).



 To listen to the audio output from this connection, press AUDIO SOURCE repeatedly until 'MP3 LINK' is displayed on the display panel.

Connect USB device



1 Connect the USB device to ← USB jack on this Home Theater System.



- This Home Theater System can only play/view MP3, WMA, DivX (Ultra) or JPEG files that are stored on such devices.
- Press USB to access the content and play the files.


Connect power cord

Warning

- Risk of product damage! Ensure that the power supply voltage corresponds to the voltage printed on the back or the underside of the Home Theater System.
- Before connecting to a socket, set the voltage selector (at the rear or bottom of this Home Theater System) to the local power line voltage. (For HTS3371, HTS3378 only)
- Connect the power cord to the socket when all the required connections are made.
 - → The Home Theater System is ready to be set up for use.

4 Get started

Insert the remote control batteries



- 1 On the back of the remote control, slide the battery cover to remove it.
- 2 Insert the 2 supplied batteries (AAA). Be sure the + and - ends of the batteries line up with the markings inside the case.
- **3** Slide the cover back into position.


Note

- Do not mix batteries (old and new or carbon and alkaline, etc.).
- Remove batteries if they are exhausted or if the remote control is not to be used for a long time.
- Batteries contain chemical substances, they should be disposed of properly.

Control a play source

- 1 Press RADIO, USB or DISC button to select the source you wish to control.
- 2 Select the desired function (for example $[\triangleleft, \triangleright]$).

Navigate through the menu



- Point the remote control directly at the remote sensor on the Home Theater System and select the desired function.
- 2 Press the following buttons on the remote control to navigate through the on-screen menus.

Button	Action
AV	Move up or down
•	Move left or right
ОК	Confirm a selection
1 2 3 4 5 6 7 8 9 0 0	Enter numbers

English

Find the correct viewing channel

- 1 Press () to turn on the Home Theater System.
- 2 Press **DISC** to switch to disc mode.
- **3** Turn on the TV and switch to the correct video-in channel in one of the following ways:
 - Go to the lowest channel on your TV, then press the Channel Down button until you see the Philips screen.
 - Press the -D SOURCE button repeatedly on the remote control of your TV.

🔆 Tip

• The video-in channel is between the lowest and highest channels and may be called FRONT, A/V IN, VIDEO, HDMI etc. See the TV user manual on how to select the correct input on the TV.

Select menu display language

- Note

 Skip this setting if this Home Theater System is connected to a HDMI CEC compliant TV. It switches automatically to the same OSD menu language as per your TV setting.

General Setup	
EasyLink Setup	 Auto
Disc Lock	O English
Display Dim	● 中文 (简体)
OSD Language	● 中文 (繁體)
Screen Saver	O Melayu
Sleep Timer	О Русский
DivX(R) VOD Code	0 ไทย

1 Press DISC.

- 2 Press 🗈 SETUP.
 - → [General Setup] menu is displayed.

3 Press ►.

4

Press ▲▼ to select **[OSD Language]** in the menu, then press ►.

- The language options are different depending on your country or region. It may not correspond to the illustration shown here.
- 5 Press ▲▼ to select a language, then press OK.

🔆 Тір

 You can set the default language for DVD disc menu (see 'Adjust settings' > 'Preferences' > [Disc Menu]).

Turn on Progressive Scan

If the TV supports progressive scan output, you can connect this Home Theater System and the TV using component video connection. (see 'Connect video cables' > 'Option 2: Connect to the component video jack').

Video Setup	
TV System	O On
TV Display	Off Off
Screen Fit	
Picture Setting	
HDMI Setup	
Closed Caption	
Progressive	

- Turn on the TV and ensure that the TV progressive scan mode is deactivated (see the TV user manual).
- 2 Switch the TV to the correct viewing channel for this Home Theater System.
- 3 Press DISC.
- 4 Press SETUP.
- 5 Press ▼ to select [Video Setup] in the menu, then press ►.
- 6 Select [Progressive] > [On], then press OK.
 - → A warning message is displayed.
- 7 To proceed, select [Ok] and press OK.
 → The progressive setup is complete.
 - Note
 - If a blank/distorted screen is displayed, wait for 15 seconds for the auto recover.
 - If no picture is displayed, turn off the progressive scan mode as follows: 1) Press ▲ to open the disc compartment. 2) Press ◄. 3) Press AUDIO SYNC.

- 8 Press 🗈 SETUP to exit the menu.
- **9** You can now turn on the progressive scan mode on the TV.

Note

 During play, when progressive scan mode is on for both this Home Theater System and the TV, distorted picture may be displayed. Turn off the progressive scan feature on both this Home Theater System and the TV.

Change speaker settings

Ideally, the distance between listening position and all the speakers should be the same. If not, change the speaker settings based on their distance from the listening position to obtain the best possible surround sound.

Audio Setup	
Speakers Volume	
Speakers Delay	
HDMI Audio	
CD Upsampling	
Audio Sync	

- 1 Press DISC.
- 2 Press 🗈 SETUP.
- 3 Press ▼ to select [Audio Setup] in the menu, then press ►.
 - If the speaker setup option is not accessible, press twice before you try the above steps again.

To set the speakers level

1 Select [Speakers Volume] in the menu, then press ►.

Speakers Volume Setup		
Front Left	OdB	
Front Right	0dB	
Center	0dB	
Subwoofer	0dB	
Rear Left	0dB	
Rear Right	0dB	

- 2 Press ↔ to change the volume level, then press OK.
 - → The test tone is emitted from the speaker.
 - Repeat the above setting for other speakers until all the speakers' output level sounds equally balance.
 - To exit the menu, press SETUP.

To set the output delay time (centre and rear speakers only)

1 Select [Speakers Delay] in the menu, then press ►.

Speakers Distance Setup

Center	0MS
Rear Left	0MS
Rear Right	0MS

- 2 Press ◆ to set the delay time, then press OK.
 - Repeat the above setting for other speakers until the sound output from different speakers reach the listening position at the same time.
 - To exit the menu, press 🗈 SETUP.

🗧 Тір

- Set a longer delay time if the centre speaker or rear speaker is closer to the listening position than the front speaker.
- Allow 1ms setting for every 1 foot distance between the speaker and the listening position.

Use Philips EasyLink

Your Home Theater System supports Philips EasyLink, which uses the HDMI CEC (Consumer Electronics Control) protocol. EasyLink-compliant devices that are connected through HDMI connectors can be controlled by a single remote control.

- Note

- Philips does not guarantee 100% interoperability with all HDMI CEC devices.
- 1 Turn on the HDMI CEC operations on the TV and other connected devices. See TVs/devices manual for details.
- 2 You can now enjoy the following Philips EasyLink controls.

EasyLink

You can turn off or turn on all EasyLink features.

One-touch play

When you connect your Home Theater System to devices that support one-touch play, you can control your Home Theater System and the devices with one remote control. For example, when you press Play on your Home Theater System remote control, your TV automatically switches to the correct channel to show the DVD content. To enable One-touch play, a video disc must be placed in the disc compartment before operation.

One-touch standby

When you connect your Home Theater System to devices that support standby, you can use your Home Theater System remote control to put your Home Theater System and all connected HDMI devices in standby mode. You can perform one-touch standby using the remote control from any of the connected HDMI devices.

System Audio Control

When you connect your Home Theater System to HDMI CEC compliant devices, your Home Theater System can switch automatically to play audio from the connected device.

To use one-touch audio, you must map the audio input from the connected device to your Home Theater System.

Audio Input Mapping

When you map the audio input correctly, this Home Theater System switches to the audio from the played device automatically.

Map the audio inputs to the connected devices



Note

· Before you start, ensure that the audio output of the HDMI TV and other HDMI devices have been connected to the audio input jacks on this Home Theater System.

General Setup	
EasyLink Setup	O EasyLink
Disc Lock	One Touch Play
Display Dim	One Touch Standby
OSD Language	O System Audio Control
Screen Saver	O Audio Input Mapping
Sleep Timer	
DivX(R) VOD Code	

- 1 Press **DISC**
- 2 Press 🗈 SETUP.
 - → [General Setup] menu is displayed.
- 3 Press .
- 4 Select [EasyLink Setup], then press ▶.
 - [One Touch Play] and [One Touch ٠ Standby] functions are turned on by default in the factory.

- 5 Select [System Audio Control] > [On], then press **OK** to start scanning devices.
 - → Once complete, audio input mapping menu is displayed.


Audio Input Mapp	bing
Aux 1	O [TV]
Aux 2	O [DVD 3400]
Coaxial In	• other (Non-HDMI)
Optical In	

For example, if the TV audio is connected to the AUX1 jack on this Home Theater System, select [Aux1] and map with the TV (brand name) at the right panel.

- 6 Select the audio input of this Home Theater System that is used to connect to other HDMI devices (e.g. AUX1, AUX2), then press ▶.
- 7 Select the correct connected device, then press OK.
 - → Repeat steps 5–7 to map other connected devices.
- 8 Press SETUP to exit the menu.


Select a play source

On the main unit



 Press SOURCE button repeatedly to select: DISC > USB > FM > AUX 1 > AUX 2 > COAX IN > OPTI IN > MP3 LINK > DISC ...

On the remote control



 Press AUDIO SOURCE repeatedly to switch to the connected audio source:

Display	Device connected to
AUX 1	AUDIO IN-AUX1 jacks
AUX 2	AUDIO IN-AUX2 jacks
COAX IN	COAXIAL DIGITAL IN
	socket
OPTI IN	OPTICAL DIGITAL IN
	socket
MP3 LINK	MP3 LINK socket

- Press **RADIO** to switch to FM band.
- Press **USB** to switch to USB mode.
- Press **DISC** to switch to disc mode.

Get started

5 Play

Play a disc

Caution

- Never place any objects other than discs into the disc compartment.
- Never touch the disc optical lens inside the disc compartment.

1 Press ≜ to open the disc compartment.

2 Insert a disc with its label facing up.

- For double-sided discs, load the side to play face up.
- **3** Press **▲** to close the disc compartment and start disc play.
 - To view disc play, turn on the TV to the correct viewing channel for this Home Theater System.
 - To stop disc play, press ■.

Note

- Check the types of discs supported. (see 'Specifications' > 'Playback media').
- If the password entry menu is displayed, enter the password before you can play the locked or restricted disc.
- If you pause or stop a disc for about 5 minutes, the screen saver activates. To deactivate the screen saver, press DISC.
- After you pause or stop a disc and no buttons are pressed within 15 minutes, this Home Theater System automatically switches to standby mode.

Play video

- Note

 For video disc, playback always resumes from the point where it was last stopped. To start play from the beginning, press I while the message is displayed.

Control video play

- 1 Play a title.
- Use the remote control to control the title.

Button	Action
►II	Starts, pauses or resumes disc
	play.
	Stops disc play.
	Skips to the next title or chapter.
M	Skips to the beginning of the current title or chapter. Press twice to jump to the previous title or chapter.
◀◀ / ▶▶	Searches fast-forward (right) or fast-backward (left). Press repeatedly to change the search speed. In pause mode, slow motion backward or forward play.
▲ / ▼	Searches slow-forward (down) or slow-backward (up). Press repeatedly to change the search speed. For VCD, only slow-forward play is possible.

Change video play


- **1** Play a title.
- 2 Use the remote control to change the video play.

Button	Action
AUDIO	Selects an audio language or
SYNC	channel on a disc.
SUBTITLE	Selects the subtitle language on
	a disc.
REPEAT	Selects or turns off repeat or
	shuffle mode.
	Repeat options vary depending
	on the disc type.
	For VCDs, repeat play is only
	possible if the PBC mode is
	turned off.
ZOOM	Zooms in or out of the picture.
	To pan through the zoomed
	image, press the Navigation
	buttons.
INFO	Displays the current status or
	disc information.
	You can change the video
	play options here without
	interrupting disc play.

Note

• Some operations may not work with some discs. See the information accompanying the disc for details.

Access DVD menu



1 Press **DISC** to access disc main menu.

2 Select a play option, then press OK.

- In some menus, press the **Numeric buttons** to input your selection.
- To return to the title menu during play, press → BACK.

Play

Access VCD menu or preview menu

The PBC (Playback Control) for VCD is activated by default in the factory. When you load a VCD, the contents menu is displayed.

- 1 Press ▲▼ to select a play option, then press OK to start play.
 - If PBC is off, it skips the menu and starts play from the first title.
 - To return to the menu during play, press → BACK (only possible if the PBC mode is on).
- 2 Press **DISC** to preview the contents of the disc.
 - To exit the menu, press **DISC**.

Select Digest Type:

Track Digest

Disc Interval

Track Interval

3 Select a preview play option, then press OK

[Track Digest]

Plays the first few seconds of each track in a disc.

[Disc Interval]

Divides the total disc time by six and play the first few seconds of these intervals.

[Track Interval]

Divides the current track by six and play the first few seconds of these intervals. This option is not available in stop mode.


This option is not available in stop



• You can change the PBC setting (see 'Adjust settings' > 'Preferences' > **[PBC]**).

Sync audio output with video play

If the video play is slower than the audio output (sound does not match with the pictures), you can delay the audio output to match the video.




- 1 Press and hold AUDIO SYNC until 'AUDIO SYNC' is displayed.
- 2 Within five seconds, press VOL +/- to set the delay time for audio output.



Note

• If the volume control is not used within five seconds, it resumes normal volume control function.

Quick skip play to a specific time



1 During play, press 🗊 INFO.

ightarrow The disc status menu is displayed.

- 2 Press \checkmark to view information, then press OK.
 - [TT Time] (title time)
 - [Ch Time] (chapter time)
 - [Disc Time] (disc time)
 - [Track Time] (track time)
- **3** Press the Numeric buttons to enter the time where you want to skip to, then press OK.

Note

• The options are different depending on the disc type.

English

Repeat play a specific section

- During playback, press ⊡ INFO.
 → The disc status menu is displayed.
- 2 Select [Repeat] in the menu, then press ►.
- 3 Move to [A-B] in the menu, then press OK to set the starting point.
- 4 Press OK again to set the ending point.→ Repeat play starts.
- 5 To cancel repeat play, select [Off] and press OK.

• The marked section for repeat play is only possible within a track/title.

View video play from different camera angles

- During play, press ⊡ INFO.
 → The disc status menu is displayed.
- 2 Select [Angle], then press ▶.
- **3** Press the Numeric buttons to select an angle, then press OK.
 - \mapsto Play changes to the selected angle.

Note

• Applicable only to discs containing multi-angle scenes.

Play DivX® video

DivX video is a digital media format that retains high quality despite a high rate of compression. You can enjoy DivX video on this DivX® Certified Home Theater System.

- 1 Insert a disc or USB device that contains the DivX videos.
- 2 Press DISC or USB.
 - → A contents menu is displayed.
- 3 Select a title to play, then press ► II.
- 4 Use the remote control to control the title.

Button	Action
AUDIO	Selects an audio language or
SYNC	channel.
SUBTITLE	Select DVD or DivX subtitle
	languages.
	Stops play.
	For DivX Ultra video, press
	this button again to display the
	contents menu.
INFO	Displays DivX Ultra video
	information.

Note

- You can only play DivX videos that were rented or purchased with the DivX registration code of this Home Theater System (see 'Adjust settings' > 'General setup' > [DivX(R) VOD Code]).
- You can play DivX video files of up to 4GB.
- If the subtitle does not appear correctly, change the character set (see 'Adjust settings' > 'Preferences' > [DivX Subtitle]).
- This Home Theater System can display up to 45 characters in the subtitle.

Note

Play music

Control audio track play

- 1 Play a track.
- 2 Use the remote control to control the track.

Button	Action
▶11	Starts, pauses or resumes disc play.
	Stops disc play.
	Skips to the next track.
1 2 3 4 5 6 7 8 9 0 0	Skips to the beginning of the current track. Press twice to jump to the previous track. Selects an item to play.
◀◀ / ▶▶	Searches fast-forward (right) or fast-backward (left). Press repeatedly to change the search speed.
REPEAT	Selects or turns off repeat or shuffle mode.

Play MP3/WMA music

MP3/WMA is a type of highly compressed audio file (files with .mp3 or .wma extensions).

- 1 Insert a disc or USB that contains the MP3/WMA music.
- 2 Press DISC or USB.

→ A contents menu is displayed.

- **3** Select a folder, then press **OK**.
- 4 Select a track to play, then press ► II.
 - To return to the main menu, press
 ⇒ BACK or press ▲ until 'Previous' folder is selected, then press OK.

- Note

- For disc recorded in multiple sessions, only the first session is played.
- This Home Theater System does not support MP3PRO audio format.
- If any special characters are present in the MP3 track name (ID3) or album name, it might not be displayed correctly on the screen because these characters are not supported.
- Some WMA files are protected by Digital Rights Management and cannot be played on this Home Theater System.
- Folders/files that exceed the supported limit of this Home Theater System will not be displayed or played.

🔆 Tip

 You can select the display of data contents, view folders or files (see 'Adjust settings' > 'Preferences' > [MP3/JPEG Display]).

Play photo

Play photo as slideshow

This Home Theater System can play JPEG photos (files with .jpeg or .jpg extensions).

- 1 Insert a disc or USB that contains the JPEG photos.
- 2 Press DISC or USB.
 - ➡ Slideshow begins (for Kodak disc) or a contents menu (for JPEG disc) is displayed.
- **3** Select the folder/album you want to play.
 - To preview the photos in the folder/ album, press 🖸 INFO.



- To go to previous or next screen display, press I / ►I.
- To select a photo, press the **Navigation buttons**.
- To display the selected photo only, press **OK**.
- Press ►II to start slideshow play.
 - To return to the menu, press → BACK.



- You may require longer time to display the disc content on the TV due to the large number of songs/ photos compiled onto one disc.
- If the JPEG photo is not recorded with an 'exif' type file, the actual thumbnail picture is not shown on the display. It is replaced by a 'blue mountain' thumbnail picture.
- This Home Theater System can only display digital camera pictures according to the JPEG-EXIF format, typically used by almost all digital cameras. It cannot display Motion JPEG and pictures in formats other than JPEG, or sound clips associated with pictures.
- Folders/files that exceed the supported limit of this Home Theater System are not displayed or played.

Control photo play

- 1 Play photo slideshow.
- 2 Use the remote control to control the photo.

Skips to the previous photo.	
Skips to the next photo.	
Rotates the photo clockwise.	
Rotates the photo anti-	
clockwise.	
Zooms in or out of the	
picture.	
Play pause in zoom mode.	
Stops play.	

Play musical slideshow


Play MP3/WMA music files and JPEG photo files simultaneously to create musical slideshow. The MP3/WMA and JPEG files must be stored on the same disc or USB device.

- 1 Play MP3/WMA music.
- 2 Navigate to the photo folder/album and press OK to start slideshow play.
 - → Slideshow begins and continues till the end of the photo folder or album.
 - → Audio continues to play till the end of the disc.
 - To stop slideshow play, press ■.
 - To stop music play, press 🔳 again.

Play from USB device

This Home Theater System plays/views MP3, WMA, DivX (Ultra) or JPEG files on the following USB devices:

- digital camera that complies with the PTP standard
- flash drive
- memory card reader
- HDD (external power source needed)




- Connect a USB device to the ↔ (USB) jack.
- 2 Press USB.
 - \mapsto A contents menu is displayed.
- 3 Select a file to play, then press ►II.
 → Play starts.
 - To stop play, press or remove the USB device.

Note

- If the device does not fit into the USB jack, connect it through a USB extension cable.
- If you connect a multiple USB card/device reader, only one card/device can be accessed.

Play from portable media player

Simply connect your portable media player (e.g. MP3 player) to this Home Theater System to enjoy superb sound quality from your music collections.




- 1 Connect a 3.5 mm stereo audio cable (not supplied) from the MP3 LINK jack on this Home Theater System to the 'headphone' jack on the portable media player.
- 2 Press AUDIO SOURCE repeatedly until 'MP3 LINK' is displayed.
- **3** Start play on your portable media player.
 - To stop play, press **STOP** on the portable media player.

- Control playback is only possible on the portable media player.
- Stop play on the portable media player before you switch to other play media/source.

Play from radio

Check if the FM antenna has been connected to this Home Theater System. If not, connect the supplied FM antenna to the FM75 Ω jack and fix its ends to the wall.



🔆 Tip

- For better FM stereo reception, connect an external FM antenna (not supplied).
- Position the antenna as far away as possible from your TV, VCR or other radiation source to prevent interference.

First time tuning

When you access radio mode for the first time, follow the instructions to install the radio stations.

- 1 Press RADIO.
 - ↔ 'AUTO INSTALL ... PRESS PLAY' is displayed.
- 2 Press ►II.
 - → All detected radio stations are stored.
 - → Once complete, it tunes to the first preset radio station.
 - To stop auto tuning, press ■.

Note

- This Home Theater System can store up to a maximum of 40 radio stations.
- If auto installation is not activated or less than 5 radio stations are stored, you will be prompted to install the radio stations again.

Note

Listen to radio

- 1 Press RADIO.
- 2 Use the remote control to control the radio.

Button	Action
 ∢▶	Selects a preset radio station.
AV	Tunes the radio frequency up or
	down.
	Press and hold this button to
	erase the current radio station
	from the preset list.
	The preset number for other
	radio stations remain unchanged.

Reinstall all the radio stations

- 1 Press RADIO.
- 2 Press and hold **PROGRAM** for more than 5 seconds.
 - → All previously stored radio stations are replaced.

- Note

• Check the radio antenna connection if no stereo signal is detected or less than 5 stations are detected during radio installation.

Search and store radio stations individually

- 1 Press RADIO.
- 2 Press ◀◀ / ▶▶.
 - → It starts searching until a radio station is detected.
- **3** Repeat step 2 until you tune to the radio station you wish to store.
 - To finetune the radio frequency, press ▲ / ▼.

4 Press **PROGRAM**.

- → The preset station number blinks.
- ➡ If no action is carried out within 20 seconds after the above step, it exits the preset mode.
- 5 Press I / ► (or the Numeric buttons) to select a preset number to store.
- 6 Press **PROGRAM** to confirm.

Change the tuning grid

In some countries, the frequency step between adjacent channels in FM band is 50 kHz or 100 kHz.

- Note

- This feature is only applicable for certain regions.
- Changing the tuning grid erases all preset radio stations.

1 Press RADIO.

- 2 Press ■.
- 3 Press and hold ►II until 'GRID 9' or 'GRID 10' is displayed.
 - → 'GRID 9' for 50 kHz and 'GRID 10' for 100 kHz.

English

6 Advanced features

Create MP3 audio files

You can convert audio CDs into MP3 audio files with this Home Theater System. The created MP3 audio files are saved in your USB device.

Option	Description	
[Speed]	Selects the write-to-file speed.	
	If [Normal] speed is selected,	
	music play can be heard while	
	creating the MP3 file.	
[Bitrate]	Selects the quality level. Higher	
	bitrate for better sound quality	
	and bigger file size.	
	Default setting is [128kbps] .	

CREATE MP3			
OPTIONS		TRA	CK
Speed	Normal	O Track01	04:14
Bitrate	128kbps	O Track02	04:17
Lonato	12010000	O Track03	03:58
		O Track04	04:51
		O Track05	03:53
SUMMARY		O Track06	04:09
Select Track	0	O Track07	04:38
Time	00:00	.	•
Start	Exit	Select All	Deselect All

- 1 Insert an audio CD. (CDDA/HDCD)
- 2 Connect the USB flash drive to ⊷↔ (USB) jack on this Home Theater System.
- **3** During disc play, press **CREATE MP3**.
- 4 Select the conversion options in the [OPTIONS] panel, then press OK.
- 5 Press ► to access the [TRACK] panel.

- 6 Select the audio track, then press OK.
 - To select another track, repeat step 6.
 - To select all tracks, select [Select All] in the menu and press OK.
 - To deselect all tracks, select [Deselect all] in the menu and press OK.
- 7 Select [Start] in the menu to convert, then press OK.
 - → Once complete, a new folder is created automatically in the USB device to store all the new MP3 files.
 - To exit the menu, select [Exit] and press OK.

Note


- While you convert, do not press any buttons.
- DTS CDs and copy-protected CDs cannot be converted.
- Write-protected or password-protected USB devices cannot be used to store MP3 files.

7 Adjust sound

Control the volume

- 1 Press VOL +/- to increase or decrease the volume.
 - To mute, press 🕷.
 - To restore the volume, press w again or press VOL +.


Select surround sound



1 Press SURR repeatedly to select the best surround output that's available on the disc.

Option	Description
5 CH	Enhances the stereo channel
STEREO	output by duplicating the
	sound output to the centre
	and rear speakers. Ideal for
	party music.
MULTI-	Multi-channel surround
CHANNEL/	output: DTS (Digital Theatre
DPLII	Systems), Dolby Digital, and
	Dolby Pro Logic II.
STEREO	Stereo sound from two front
	speakers.


Select a preset sound



1 Press SOUND repeatedly to select the sound effect that most suitable for the video or music you play.

Video/Music	Description
ACTION /	Enhance low and
ROCK	high range for
	great sounding
	movie effects and
	atmosphere. Great
	for action movies and
	rock/pop music.
CONCERT/	Flat and pure sound
CLASSIC	mode. Ideal for
	listening to classical
	music and watching
	live concert disc.
DRAMA /	Clear mid and high
JAZZ	range. Recreates the
	atmosphere of a live
	club with the artist
	just in front of you.
	Good for jazz music
	and watching dramas.
SPORTS	Moderate mid range
	and surround effects
	for clear vocals and
	the atmosphere of a
	live sports venue. It
	is also ideal for video
	gaming.
NIGHT	Dynamically
	controlled sound
	mode suitable
	for watching
	movies at night or
	for nonintrusive
	background music.

Adjusting microphone volume level



- 1 Connect a microphone (not supplied) to the **MIC** socket on this Home Theater System.
- 2 Turn on the microphone output. (see 'Karaoke settings'.)
- **3** Press MIC (VOL +/-) to adjust the microphone volume.
 - → 'MIC XX' is displayed.
 - Sing or speak into the microphone to find the desired volume level.

Karaoke settings



- 1 Turn on the TV to the correct viewing channel for this Home Theater System.
- 2 Press KARAOKE.
 - → [Karaoke Setup Page] menu is displayed.
- **3** Select an option and change the setting, then press **OK**.
 - To exit the menu, press KARAOKE.

[Mic]

Turns microphone output on and off.

- [On] Turns microphone on.
- [Off] Turns microphone off.

[Echo Level]

Press ▲▼ to set the echo level.

[Key]

Press $\blacktriangle \forall$ to set the pitch level that matches your voice.

[Score]

Selects a karaoke rating score level.

- [Off] No score rating display.
- [Basic] Basic rating.
- [Intermediate] Intermediate rating.
- [Advance] Advance rating.

Turning vocals off (voice cancel)

1 Press VOCAL repeatedly until 'VOICE CANCEL' is displayed.

Note

• You cannot cancel the voice output from MP3 or WMA audio.

8 Adjust settings

You can customise various kinds of settings as you prefer. Refer to the following instructions to navigate through the setup menus.

Symbol	Options	
\$	[General Setup]	
•([Audio Setup]	
0	[Video Setup]	
	[Preferences]	
 Note If the setup option is greyed out, it means the setting cannot be changed in the current state. 		

General setup

General Setup	
EasyLink Setup	
Disc Lock	
Display Dim	
OSD Language	
Screen Saver	
Sleep Timer	
DivX(R) VOD Code	

1 Press SETUP.

→ [General Setup] menu is displayed.

2 Press ►.

3

Select an option, then press OK.

- 4 Select a setting, then press OK.
 - To return to the previous menu, press → BACK.
 - To exit the menu, press 🗈 SETUP.

- Note

• See the explanations of the above options in the following pages.

Adjust settings

[EasyLink Setup]

If this Home Theater System is connected to HDMI CEC compliant TV/devices, all connected devices can respond to the following commands simultaneously:

Option	Description
[EasyLink]	Turns off or on all EasyLink
	features.
	To disable this feature, select
	[Off].
[One	When you press PLAY , the
Touch	TV and Home Theater System
Play]	are turned on. Disc play starts
	if there is a disc in the Home
	Theater System.
	To disable this feature, select
	[Off].
[One	When you press and hold
Touch	STANDBY, connected HDMI
Standby]	CEC devices simultaneously
	switch to standby.
	To disable this feature, select
	[Off].
[System	When you play audio that is
Audio	routed from the connected
Control]	devices, this Home Theater
	System switches to the
	corresponding audio source
	automatically. To enable this feature, select
	[On]. Then proceed to [Audio
	Input Mapping] to scan and map
	all the connected devices.
[Audio	When you map the audio
Input	input correctly, this Home
Mapping]	Theater System switches to the
	audio from the played device
	automatically.
	/-

⁻ Note

- You must turn on the HDMI CEC operations on the TV/devices before you can enjoy the EasyLink controls. See the TV/devices manual for details.
- Philips does not guarantee 100% interoperability with all HDMI CEC compliant devices.

[Disc Lock]

Sets play restriction for specific discs. Before you start, place the disc in the disc compartment (maximum 40 discs can be locked).

- [Lock] Restricts access to the current disc. Once activated, a password is needed to unlock and play the disc.
- [Unlock] Plays all discs.

🔆 Тір

• You can set or change the password (see 'Adjust settings' > 'Preferences' > [Password]).

[Display Dim]

Changes the brightness level of the display panel on this Home Theater System.

- [100%] Normal brightness.
- [70%] Medium brightness.
- [40%] Dimmest display.

[OSD Language]

Selects the default on-screen menu language.

[Screen Saver]

Turns off or on the screen saver mode. Helps to protect the TV screen from being damaged due to over exposure to a static image for too long.

- **[On]** Sets the screen saver to appear after 5 minutes of inactivity (for example, in pause or stop mode).
- [Off] Disable screen saver mode.

[Sleep Timer]

Switches to standby automatically after the preset time.

- [15 mins], [30 mins], [45 mins], [60 mins] – Selects the count down time before the Home Theater System switches to standby.
- [Off] Disables sleep timer mode.

[DivX(R) VOD Code]

Displays the DivX® registration code.



 Enter this Home Theater System DivX registration code when you rent or purchase a video from www. divx.com/vod. The DivX videos rented or purchased through the DivX® VOD (Video On Demand) service can be played only on the device to which it is registered.

Audio setup

Audio Setup

_		
	Speakers Volume	
	Speakers Delay	
	HDMI Audio	
	CD Upsampling	
	Audio Sync	

1 Press SETUP.

→ [General Setup] menu is displayed.

- 2 Press ▼ to select [Audio Setup], then press ►.
- **3** Select an option, then press **OK**.
- 4 Select a setting, then press OK.
 - To return to the previous menu, press → BACK.
 - To exit the menu, press 🗈 SETUP.

- Note

• See the explanations of the above options in the following pages.

English

[Speakers Volume]

Sets the volume level of each speaker to get the ideal audio balance.

1) To start, press OK.

2) Select a speaker in the menu, then press

◆ to adjust the volume level.

3) Press OK to confirm and exit.

Note

• The test tone is emitted from the speaker which you adjust.

[Speakers Delay]

Sets the delay time for the centre and rear speakers if they are placed closer to the listening position, so that the sound output from all speakers reaches the listening position at the same time.

1) To start, press OK.

2) Select a speaker in the menu, then press

◆ to set the delay time.

3) Press OK to confirm and exit.

- Note

• Allow 1ms setting for every 1 foot distance between the speaker and the listening position.

[HDMI Audio]

Selects the HDMI audio setting when you connect this Home Theater System and the TV with a HDMI cable.

- [On] Allows audio output through the TV and the speaker system. If the audio format on the disc is not supported, it will be downmixed to two-channel sound (linear-PCM).
- **[Off]** Disables audio output from the TV. The sound is only output through the speaker system.

[CD Upsampling]

Converts the music CD to a higher sampling rate using sophisticated digital signal processing for better sound quality.

- [Off] Disables CD-upsampling.
- [88.2kHz (X2)] Converts the sampling rate of the CDs twice as high as the original rate.

- Note

• CD upsampling is only available in stereo mode.

[Audio Sync]

Sets the default delay time for audio output when you play a video disc.

1) To start, press OK.

2) Select a speaker delay in the menu, then

- press \blacktriangleleft to set the delay time.
- 3) Press OK to confirm and exit.

Video setup

Video Setup	
TV System	
TV Display	
Screen Fit	
Picture Setting	
HDMI Setup	
Closed Caption	
Progressive	

1 Press E SETUP.

- → [General Setup] menu is displayed.
- 2 Press ▼ to select [Video Setup], then press .
- 3 Select an option, then press OK
- Select a setting, then press OK.
 - To return to the previous menu, press **D BACK**.
 - To exit the menu, press E SETUP.

Note

See the explanations of the above options in the following pages.


[TV System]

Change this setting if the video does not appear correctly. By default, this setting matches the most common setting for TVs in your country.

- [PAL] For PAL-system TV.
- [NTSC] For NTSC-system TV.
- [Multi] For TV that is compatible with both PAL and NTSC

[TV Display]

Selects one of the following display formats:







16:9 (Wide Screen)

- [4:3 Pan Scan] For 4:3 screen TV: fullheight display with the trimmed sides.
- [4:3 Letter Box] For 4:3 screen TV: wide-screen display with black bars on the top and bottom of the screen.
- [16:9 Wide Screen] For wide-screen TV: display ratio 16:9.

[Screen Fit]

Fits the picture format to the TV screen to enjoy watching disc play in full screen mode.

- [Select] Displays various types of full screen format, press OK to select a suitable picture format that best fits to the TV screen.
- [Off] Returns to normal screen display.

[Picture Setting]

Selects a predefined set of picture colour settings or customises the personal setting.

- [Standard] Original colour setting.
- [Bright] Vibrant colour setting.
- [Soft] Warm colour setting.
- [Personal] Customises the colour setting. Set the level of brightness, contrast, sharpness/tint and colour saturation, then press OK.

[HDMI Setup]

Selects the HDMI video setting when you connect this Home Theater System and the TV with a HDMI cable.

• [Wide Screen Format] – Defines the wide screen format for disc play.

Option	Description
[Superwide]	Centre position of the
	screen is stretched less
	than the side. Applicable
	only to 720p and above
	video resolution setting.
[4:3 Pillar Box]	No stretching of the
	picture. Black bars are
	displayed on both sides
	of the screen.
[Off]	Picture is displayed
	according to the format
	of the disc.

Note

• This setting is only available if you have set the [TV Display] setting to [16:9 Wide Screen].

 [HDMI Video] – Selects the HDMI video output resolution that is compatible with your TV display capability.

Option	Description
[Auto]	Detects and selects the best supported video resolution automatically.
[480i], [576i], [480p], [576p], [720p], [1080i], [1080p]	Selects a video resolution that is best supported by the TV. See the TV manual for details.

Note

If the setting is not compatible with your TV, a blank screen appears. Wait for 15 seconds for auto recover or switch to its default mode as follows: 1) Press ▲.
 2) Press ◄. 3) Press ZOOM.

Turns off or on display captions.

- [On] Shows the sound effects in subtitles. Applicable only to discs with Closed Caption information included and the TV supports this feature.
- [Off] Disables closed caption.

[Progressive]

If the TV supports progressive scan output, you can turn on the progressive scan mode to enhance the picture quality. Video connection through component video is required.

- [On] Turns on progressive scan mode.
- [Off] Disables progressive scan mode.

🔆 Tip

• There is a more detailed description available (see 'Get started' > 'Turn on Progressive Scan').

English

Preferences

Note

Stop disc play before you can access [Preferences].

Preferences		
Audio		
Subtitle		
Disc Menu		
Parental		
PBC		
MP3/JPEG Display		
Password		
DivX Subtitle	V	

1 Press E SETUP.

→ [General Setup] menu is displayed.

- 2 Press ▼ to select [Preferences], then press .
- 3 Select an option, then press OK.
- Select a setting, then press OK.
 - To return to the previous menu, press **D BACK**,
 - To exit the menu, press I SETUP.

Note

See the explanations of the above options in the following pages.

[Audio]

Selects the default audio language for disc play.

[Subtitle]

Selects the default subtitle language for disc play.

[Disc Menu]

Selects the language for disc menu.



• If the language you have set is not available on the disc, the disc uses its own default language.

- · For some discs, the subtitle/audio language can only be changed from the disc menu.
- To select the languages that are not listed in the menu, select [Others]. Then check the Language Code list at the back of this user manual and enter the respective 4-digit language code.

[Parental]

Restricts access to discs that are unsuitable for children. These types of discs must be recorded with ratings.

1) Press OK.

2) Select a rating level, then press OK.

3) Press the Numeric buttons to enter the password.



- · Rated discs above the level you set in [Parental] require a password to be played.
- · The ratings are country-dependent. To allow all discs to play, select '8'.
- · Some discs have ratings printed on them but are not recorded with ratings. This function has no effect on such discs.



 You can set or change the password (see 'Preferences' > [Password]).

Adjust settings

English

[PBC]

Turns off or on the content menu of VCDs/ SVCDs with PBC (playback control) feature.

- **[On]** Displays index menu when you load a disc for play.
- **[Off]** Skips the menu and starts play from the first title.

[MP3/JPEG Display]

Selects to display the folders or display all the files.

- [View Folders] Displays the folders of MP3/WMA files.
- [View Files] Displays all the files.

[Password]

Sets or changes the password for locked discs and play restricted DVDs.

Change Password	
Old Password	
New Password	
Confirm Password	
	ОК

1) Press the Numeric buttons to enter

'136900' or the last set password at **[Old Password]** field.

2) Enter the new password at **[New Password]** field.

3) Enter the new password again at **[Confirm Password]** field.

4) Press **OK** to exit the menu.

- Note

• If you forget the password, enter '136900' before you set a new password.

[DivX Subtitle]

Selects a character set that supports the $\ensuremath{\text{Div}X}$ subtitle.

[Standard]	English, Irish, Danish,
	Estonian, Finnish,
	French, German,
	Italian, Portuguese,
	Luxembourgish, Norwegian
	(Bokmål and Nynorsk),
	Spanish, Swedish, Turkish
[Central	Polish, Czech, Slovak,
Europe]	Albanian, Hungarian,
	Slovene, Croatian, Serbian
	(Latin script), Romanian
[Cyrillic]	Belarusian, Bulgarian,
	Ukrainian, Macedonian,
	Russian, Serbian
[Greek]	Greek
[Hebrew]	Hebrew
[Chinese(Simp)]	Simplified Chinese
[Korean]	Korean



• Ensure that the subtitle file has the exact same file name as the movie file. If for example the file name of the movie is 'Movie.avi', then you will need to name the text file 'Movie.sub' or 'Movie.srt'.

[Version Info.]

Displays the software version of this Home Theater System.

⊁ Тір

 This information is required when you want to find out if a newer software version is available at the Philips website that you may download and install on this Home Theater System.

[Default]

Resets all the settings of this Home Theater System to factory default, except for **[Disc Lock]**, **[Password]** and **[Parental]** settings.

9 Additional Information

Update software

To check for new updates, compare the current software version of your Home Theater System with the latest software version (if available) at the Philips website.

Preferences	
Disc Menu	
Parental	
PBC	
MP3/JPEG Display	
Password	
DivX Subtitle	
Version Info.	
Default	

- 1 Press I SETUP.
- 2 Select [Preferences] > [Version Info.], then press OK.
- **3** Write down the version number, then press I SETUP to exit the menu.
- 4 Go to www.philips.com/support to check the latest software version available for this Home Theater System.
- 5 If the latest software version is higher than the software version of this Home Theater System, download it and store onto a CD-R or USB flash drive.
- 6 Insert the CD-R or USB flash drive to this Home Theater System.
- 7 Press DISC or USB, then follow the instruction on the TV to confirm update operation.
 - → Once software update is complete, this Home Theater System turns off to standby automatically.



- Do not remove the CD-R or USB when software updating is in progress.
- 8 Disconnect the power cord for a few seconds and connect again to reboot the system.

Care

Caution

• Never use solvents such as benzene, thinner, cleaners available commercially or anti-static sprays intended for discs.

Clean discs

Wipe the disc with a micro fibre cleaning cloth from the centre to the edge in a straight line movement.

Clean main unit screen

Wipe the screen surface with a micro fibre cleaning cloth.

10 Specifications

- Note

• Specification and design are subject to change without notice

Playback media

 DVD-Video, DVD+R/+RW, DVD-R/-RW, DVD+R DL, CD-R/CD-RW, Audio CD, Video CD/SVCD, Picture CD, MP3-CD, WMA-CD, DivX-CD, USB flash drive

Amplifier

- Total output power:
 - Home Theatre mode: - For HTS3276: 420 W RMS (2 X 100 + 4 X 55)
 - For HTS3371, HTS3378: 1000 W RMS (6 X 167)
- Frequency response: 40 Hz ~ 20 kHz
- Signal-to-noise ratio:
 - > 60 dB (A-weighted)
- Input sensitivity:
 - AUX1: 400 mV
 - AUX2: 400 mV
 - MP3 LINK: 250 mV

Disc

- Laser Type: Semiconductor
- Disc diameter: 12 cm / 8 cm
- Video decording: MPEG1/ MPEG2 / DivX / DivX Ultra
- Video DAC: 12 bits, 108 MHz
- Signal system: PAL / NTSC
- Video S/N: 56 dB
- Audio DAC: 24 bits / 96 kHz
- Frequency response:
 - 4 Hz–20 kHz (44.1 kHz)
 - 4 Hz–22 kHz (48 kHz)
 - 4 Hz–44 kHz (96 kHz)
- PCM: IEC 60958
- Dolby Digital: IEC 60958, IEC 61937
- DTS: IEC 60958, IEC 61937

Radio

- Tuning range: FM 87.5-108 MHz (50/100 kHz)
- 26 dB quieting sensitivity: FM 22 dBf
- IF rejection ratio: FM 60 dB
- Signal-to-noise ratio: FM 50 dB
- Harmonic distortion: FM 3%
- Frequency response: FM 180 Hz~10 kHz / ±6dB
- Stereo separation: FM 26 dB (1 kHz)
- Stereo Threshold: FM 29 dB

USB

- Compatibility: High Speed USB (2.0)
- Class support: UMS (USB Mass Storage Class)
- File system: FAT12, FAT16, FAT32

Main Unit

- Power supply:
 - For HTS3276: 110-240 V; ~50-60 Hz
 - For HTS3371/3378: 110-127 V/220-240 V; ~50-60 Hz switchable
- Power consumption:
 - For HTS3276: 80 W
 - For HTS3371, HTS3378: 180 W
- Standby power consumption: < 1 W
- Dimensions (WxHxD): 360 x 57 x 331 (mm)
- Weight:
 - For HTS3276: 2.87 kg
 - For HTS3371, HTS3378: 3.01 kg

Specifications

Speakers

- System: full range satellite
- Speaker impedance:
 - For HTS3276: 4 ohm (centre), 8 ohm (Front/Rear)
 - For HTS3371, HTS3378: 4 ohm (centre), 4 ohm (Front/Rear)
- Speaker drivers:
 - Centre/Front/Rear: 3'' full range
- Frequency response: 150 Hz ~ 20 kHz
- Dimensions (WxHxD):
 - For HTS3276
 - Centre: 244 × 103 × 74 (mm)
 - Front: 262 × 1199 × 264 (mm)
 - Rear: 103 × 203 × 71 (mm)
 - For HTS3371:
 - Centre/Front/Rear:
 - 100 × 100 × 75 (mm)
 - For HTS3378:
 - Centre: 244 × 103 × 74 (mm)
 - Front: 262 × 1199 × 264 (mm)
 - Rear: 262 × 1199 × 264 (mm)
- Weight:
 - For HTS3276:
 - Centre: 0.85 kg
 - Front: 3.6 kg
 - Rear: 0.55 kg
 - For HTS3371:
 - Centre: 0.67 kg
 - Front: 0.48 kg
 - Rear: 0.45 kg
 - For HTS3378:
 - Centre: 0.85 kg
 - Front: 3.6 kg
 - Rear: 3.55 kg

Subwoofer

- Impedance: 4 ohm
- Speaker drivers: 165 mm (6.5") woofer
- Frequency response: 40 Hz \sim 150 Hz
- Dimensions (WxHxD):
 - For HTS3276, HTS3371: 163 × 363 × 369 (mm)
 - For HTS3378: 242 x 352 x 360 (mm)
- Weight:
 - For HTS3276, HTS3371: 4.7 kg
 - For HTS3378: 5.6 kg

Laser specification

- Type: Semiconductor laser GaAIAs (CD)
- Wave length: 645–665 nm (DVD), 770–800 nm (CD)
- Output power: 6 mW (DVD),
 7 mW (VCD/CD)
- Beam divergence: 60 degrees.

English

11 Troubleshooting

Warning

• Risk of electric shock. Never remove the casing of the Home Theater System.

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using the Home Theater System, check the following points before requesting service. If the problem remains unsolved, register your Home Theater System and get support at www.philips.com/ welcome.

If you contact Philips, you will be asked for the model and serial number of your Home Theater System. The model number and serial number are on the back or underside of your Home Theater System. Write the numbers here:

Model No.

Serial No.

Main unit

The buttons on this Home Theater System do not work.

• Disconnect this Home Theater System from the power outlet for a few minutes, then connect again.

Picture

No picture.

- See TV manual for correct video input channel selection. Change the TV channel until you see the DVD screen.
- Press DISC.
- If you have changed the [TV Display] setting, switch back to default mode:
 1) Press
 to open the disc compartment.
 - 2) Press ◀.
 - 3) Press SUBTITLE.
- If this happens when you turn on the progressive scan setting, you have to switch to its default mode:
 - 1) Press 🛓
 - 2) Press 4.
 - 3) Press AUDIO SYNC.

No picture on HDMI connection.

- Check if the HDMI cable is faulty. Replace a new HDMI cable.
- If this happens when you change the HDMI video resolution, you have to switch to its default mode:
 - 1) Press 🛦.
 - 2) Press **4**.
 - 3) Press ZOOM.

Sound

No sound.

 Ensure that the audio cables are connected and press the correct input source (for example, AUDIO SOURCE, USB) to select the device you want to play.

No sound on HDMI connection.

- Sound cannot transmit through HDMI connection if the connected device is non-HDCP compliant or only DVIcompatible. Make an analogue or digital audio connection.
- Ensure that the **[HDMI Audio]** setting is turned on.

No sound from TV programme.

 Connect an audio cable from the AUDIO input on this Home Theater System to the AUDIO output on your TV. Then press AUDIO SOURCE repeatedly to select the corresponding audio input source.

No surround sound effect from the speakers.

- Press **SURR** to select a correct surround sound setting.
- Ensure that the source you are playing is recorded or broadcast in surround sound (Dolby Digital, etc).Sound cannot transmit through HDMI connection if the connected device is non-HDCP compliant or only DVI-compatible. Make an analogue or digital audio connection.

Play

DivX video files cannot be played.

- Ensure that the DivX file is encoded according to the 'Home Theatre Profile' with the DivX encoder.
- Ensure that the DivX video file is complete.

The aspect ratio of the screen is not aligned with the TV display setting.

• The aspect ratio is fixed on the disc.

DivX subtitle does not display correctly.

- Ensure that the subtitle file name is the same as the movie file name.
- Select the correct character set:
 - 1) Press 🗈 SETUP.
 - 2) Select [Preferences], then press ►.

Select [DivX Subtitle], then press OK.
 Select the character set that supports the subtitle.

The contents of the USB flash drive cannot be read.

- The USB flash drive format is not compatible with this Home Theater System.
- Drive is formatted with different file system which is not supported by this unit (e.g. NTFS).
- Maximum size of memory supported is 160 GB.

12 Glossary

A

Aspect ratio

Aspect ratio refers to the length to height ratio of TV screens. The ratio of a standard TV is 4:3, while the ratio of a high-definition or wide TV is 16:9. The letter box allows you to enjoy a picture with a wider perspective on a standard 4:3 screen.

D

DivX®

The DivX® codec is a patent-pending, MPEG-4 based video compression technology developed by DivX®, Inc. It can shrink the file size of digital video and still maintain high visual quality.

Dolby Digital

A surround sound system developed by Dolby Laboratories that contains up to six channels of digital audio (front left and right, surround left and right, centre and subwoofer.)

Η

HDCP

High-bandwidth Digital Content Protection. This is a specification that provides a secure transmission of digital contents between different devices (to prevent unauthorised copyright.)

HDMI

High-Definition Multimedia Interface (HDMI) is a high-speed digital interface that can transmit uncompressed high definition video and digital multichannel audio. It delivers high quality picture and sound quality, completely free from noise. HDMI is fully backwardcompatible with DVI.

As required by the HDMI standard, connecting to HDMI or DVI products without HDCP (High-bandwidth Digital Content Protection) will result in no Video or Audio output.

j IPEG

A very common digital still picture format. A still-picture data compression system proposed by the Joint Photographic Expert Group, which causes only a small decrease in image quality in spite of its high compression ratio. Files are recognised by their file extension '.jpg' or '.jpeg'.

Μ

MP3

A file format with a sound data compression system. MP3 is the abbreviation of Motion Picture Experts Group 1 (or MPEG-1) Audio Layer 3. With the MP3 format, one CD-R or CD-RW can contain about 10 times more data than a regular CD.

MPEG

Motion Picture Experts Group. A collection of compression systems for digital audio and video.

Ρ

PBC

Playback Control. A system where you navigate through a Video CD/Super VCD with on-screen menus that are recorded onto the disc. You can enjoy interactive playback and search.

PCM

Pulse Code Modulation. A digital audio encoding system.

Progressive scan

The progressive scan displays twice as many frames per second as an ordinary TV system. It offers higher picture resolution and quality.

W

WMA

Windows Media[™] Audio. Refers to an audio compression technology developed by Microsoft Corporation. WMA data can be encoded with Windows Media player version 9 or Windows Media player for Windows XP. Files are recognised by their file extension '.wma.'

WMV

Windows Media Video. Refers to a video compression technology developed by Microsoft Corporation. WMV content can be encoded by using Windows Media® Encoder 9 series. Files are recognised by their file extension '.wmv'. Thank-you for purchasing this quality Philips product.

Philips New Zealand Ltd guarantees this product against defective components and faulty workmanship for a period of 12 months. Any defect in materials or workmanship occurring within 12 months from the date of purchase subject to the following conditions will be rectified free of charge by the retailer from whom this product was purchased.

Conditions

- The product must have been purchased in New Zealand. As proof of purchase, retain the original sales docket indicating the date of purchase.
- 2. The guarantee applies only to faults caused by defective components, or faulty workmanship on the part of the manufacturer.
- 3. The guarantee does not cover failures caused by misuse, neglect, normal wear and tear, accidental breakage, use on the incorrect voltage, use contrary to operating instructions, or unauthorised modification to the product or repair by an unauthorised technician.
- Reasonable evidence (in the form of a sales docket) must be supplied to indicate that the product was purchased no more than 12 months prior to the date of your claim.
- In the event of a failure, Philips shall be under no liability for any injury, or any loss or damage caused to property or products other than the product under guarantee.

This guarantee does not prejudice your rights under common law and statute, and is in addition to the normal responsibilities of the retailer and Philips.

How to claim

Should your Philips product fail within the guarantee period, please return it to the retailer from whom it was purchased. In most cases the retailer will be able to satisfactorily repair or replace the product.

However, should the retailer not be able to conclude the matter satisfactorily, or if you have other difficulties claiming under this guarantee, please contact

The Guarantee Controller Philips New Zealand Ltd. P.O. Box 41.021 Auckland (09) 84 94 160 fax (09) 84 97 858



PHILIPS CONSUMER ELECTRONICS WARRANTY POLICY FOR AUSTRALIA

Effective 1st October 2007

Philips provides the following Consumer Electronics products with a 1 Year Manufacturers Warranty:-

Colour Televisions, Projection TV, Plasma & LCD TV, DVD Players, DVD Recorders, DVD Recorders with Hard Disk, Personal Video Recorders, Audio Systems, Wireless Audio Systems, Home Theatre systems, Digital Set Top Box, Digital Photo Display, MP3 players & Portable Audio products.

Additionally, all Philips LCD televisions with a built-in digital tuner sold after 1st October 2007, are supported by a 3 Year Manufacturers Warranty.

The benefits given to the purchaser by this warranty are in addition to all other rights and remedies, which the purchaser has in respect of the product under the Trade Practices Act or other Commonwealth or State Law.

The conditions contained in this warranty replace and override the provision of the Philips World-Wide Guarantee for products purchased in Australia and used in Australia.

Please record the following information for your records and keep in a safe place. It is essential that you retain your original purchase receipt to make a warranty claim.

Model number	:
Serial number	:
Date of purchase	:
Retailer	:

If you require assistance with the operation of the product, its features or specifications, you may call the **Philips Technology Care Centre** on **1300 363 391** where support is provided by our trained call centre staff.

If the product fails within the warranty period then the following will apply.

Free Repair Service – at an Authorised Service Centre

For the products listed below, please contact one of our Authorised Service Centres on 1300 361 392. Colour Television, Plasma or LCD Television, LCD Television, Projection Television, DVDR/VCR Combo, DVD Recorder with Hard Drive, Personal Video Recorder, LCD Projector, Wireless Audio System, Audio System, Home Theatre System, Digital Set-Top-Box or a Portable DVD player with an LCD screen for which you paid more than \$250.

Version 1.2: 1st October 2007



Free Replacement – at your Retailer

For Digital Photo Frames or any product with a purchase price of less than \$250, please return the faulty product to the place of purchase. The retailer will arrange a replacement product for you.

If your Philips product develops a fault outside of the warranty period, please contact a Philips **Authorised Service Centre** on **1300 361 392** to discuss your repair options.

Conditions of Repair Warranty

- a. All claims for warranty service should be made to your nearest Philips Authorised Service Centre or the Philips Technology Care Centre. Proof of the original date of purchase must be provided.
- b. This warranty extends only to defects in material or workmanship occurring under normal use of the product when operated in accordance with the instructions.
- c. Philips may, at its discretion choose to replace rather than repair any product covered by this Warranty.
- d. If a replacement product is supplied under the repair policy, it is warranted for the remainder of the warranty period, from the original date of purchase.
- e. Home service is provided only within the normal service area of the nearest Philips Authorised Service Centre. Home Service will be provided for television only with a screen size of 29 inch or above (product includes CRT, LCD TV, Projection TV, and Plasma TV). For televisions with screen sizes of less than 29 inch and all other products with a repair warranty, please take these products to the nearest Authorised Service Centre.
- f. This Manufacturers Warranty is limited to 3 months for products used in commercial applications.
- g. Product accessories are covered by the same warranty period. If an accessory is faulty, please contact the Philips Technology Care Centre for a replacement.
- h. This Manufacturers Warranty is neither transferable nor valid in countries other than Australia.
- i. The warranty period is valid from the original date of purchase of the product.

This Warranty does not cover:-

- a. Mileage or travel is not covered outside the Philips Authorised Service Centres' normal service area.
- b. Service costs arising from failure to correctly adjust the controls of the product or to observe the instructions, or inspections that reveal that the product is in normal working order.
- c. Product failures caused by misuse, neglect, accidental breakage, transit damage, amateur repairs or modification by un-authorised persons, external fires, lightning strikes, floods, vermin infestation or liquid spillage.
- d. Cleaning of video or audio heads.
- e. Reception problems.
- f. Replacement of worn or used batteries or other consumables.
- g. Second hand products.
- h. Refurbished products which are covered by a 6 month manufacturers warranty.

Language Code

Abkhazian	6566
Afar	6565
Afrikaans	6570
Amharic	6577
Arabic	6582
Armenian	7289
Assamese	6583 6569
Avestan	6589
Aymara Azerhaijani	6590
Bahasa Melayu	7783
Bashkir	6665
Belarusian	6669
Bengali	6678
Bihari	6672
Bislama	6673
Bokmål, Norwegian	7866
Bosanski	6683
Brezhoneg	6682
Bulgarian	6671
Burmese	7789
Castellano, Español	6983
Catalán	6765
Chamorro	6772
Chechen	6769
Chewa; Chichewa; Nyanj	
中文	9072
Chuang; Zhuang	9065
Church Slavic; Slavonic	6785
Chuvash	6786
Corsican	6779 6783
Česky Dansk	6865
Deutsch	6869
Dzongkha	6890
English	6978
Esperanto	6979
Estonian	6984
Euskara	6985
Ελληνικά	6976
Faroese	7079
Français	7082
Frysk	7089
Fijian	7074
Gaelic; Scottish Gaelic	7168
Gallegan	7176
Georgian	7565
Gikuyu; Kikuyu	7573
Guarani	7178
Gujarati	7185
Hausa	7265
Herero Hindi	7290
Hindi Hiri Motu	7273 7279
Hrwatski	6779
Ido	7379
Interlingua (Internationa	
Interlingue	7365
Inuktitut	7385

Inupiaq	7375
Irish	7165
Íslenska	7383
Italiano	7384
lvrit	7269
Japanese	7465
Javanese	7486
Kalaallisut	7576
Kannada	7578
Kashmiri	7583
Kazakh	7575
Kernewek	7587
Khmer	7577
Kinyarwanda	8287
Kirghiz	7589
Komi	7586
Korean	7579
Kuanyama; Kwanyama	7574
Kurdish	7585
Lao	7679
Latina	7665 7686
Latvian	7666
Letzeburgesch;	7673
Limburgan; Limburger Lingala	7678
Lithuanian	7684
Luxembourgish;	7666
Macedonian	7775
Malagasy	7771
Magyar	7285
Malayalam	7776
Maltese	7784
Manx	7186
Maori	7773
Marathi	7782
Marshallese	7772
Moldavian	7779
Mongolian	7778
Nauru	7865
Navaho; Navajo Ndebele, North	7886 7868
Ndebele, South	7882
Ndonga	7871
Nederlands	7876
Nepali	7869
Norsk	7879
Northern Sami	8369
North Ndebele	7868
Norwegian Nynorsk;	7878
Occitan; Provencal	7967
Old Bulgarian; Old Slavonic	6785
Oriya	7982
Oromo	7977
Ossetian; Ossetic	7983
Pali	8073
Panjabi	8065
Persian	7065
Polski	8076
Português	8084

Pushto	8083
Russian	8285
Quechua	8185
Raeto-Romance	8277
Romanian	8279
Rundi	8278
Samoan	8377
Sango	8371
Sanskrit	8365
Sardinian	8367
Serbian	8382
Shona	8378
Shqip	8381
Sindhi	8368
Sinhalese	8373
Slovensky	8373
Slovenian	8376
Somali	8379
Sotho; Southern	8384
South Ndebele	7882
Sundanese	8385
Suomi	7073
Swahili	8387
Swati	8383
Svenska	8386
Tagalog	8476
Tahitian	8489
Tajik	8471
Tamil -	8465
Tatar	8484
Telugu	8469
Thai	8472
Tibetan	6679
Tigrinya Tana (Tana Islanda)	8473
Tonga (Tonga Islands)	8479
Tsonga	8483
Tswana	8478
Türkçe Turkuzan	8482 8475
Turkmen Twi	8487
Uighur	8571
Ukrainian	8575
Urdu	8582
Uzbek	8590
Vietnamese	8673
Volapuk	8679
Walloon	8765
Welsh	6789
Wolof	8779
Xhosa	8872
Yiddish	8973
Yoruba	8979
Zulu	9085



© 2009 Koninklijke Philips Electronics N.V. All rights reserved. sgpjy_0903/98_4

