# FUJIFILM

# DIGITAL CAMERA FINEPIX S8600 Series

# **Owner's Manual**



For information on related products, visit our website at http://www.fujifilm.com/products/digital\_cameras/index.html

Before You Begir	1
First Step	s
Basic Photography and Playbac	 K
More on Photograph	y
More on Playbac	k.
Movie	 s
Connection	 s
Menu	s
Technical Note	s
Troubleshooting	g
Appendi	 x

BL04301-102 EN





Be sure to read this notes before using	WARNING
Safety Notes Make sure that you use your camera correctly. Read these Safety Notes and your <i>Owner's Manual</i> carefully before use. After reading these Safety Notes, store them in a safe place.	Do not allow water or foreign objects to enter the camera. If water or foreign objects get inside the camera, turn the came off, remove the battery and disconnect and unplug the AC pow adapter. Continued use of the camera can cause a fire or electric shock. • Contact your FUJIFILM dealer.
About the lcons he icons shown below are used in this document to indicate the severity of he injury or damage that can result if the information indicated by the icon	Do not use the camera in the bathroom or shower. This can cause a fire or electric shock.
s ignored and the product is used incorrectly as a result.  This icon indicates that death or serious injury can result if the information is ignored.	orshower. Do not disas- semble Failure to observe this precaution can cause fire or electric shock.
This icon indicates that personal injury or material damage can result if the information is ignored. The icons shown below are used to indicate the nature of the information which is to be observed.	Should the case break open as the result of a fall or other accident, do not touch the exposed parts. Ponot touch intendi parts parts and the damaged parts. Remove the battery in mediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.
Triangular icons tell you that this information requires attention ("important").         O       Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").         Image: The second s	Do not change, heat or unduly twist or pull the connection cord and do n place heavy objects on the connection cord.           These actions could damage the cord and cause a fire or electr shock.           . If the cord is damaged, contact your FUJIFILM dealer.           Donot place the camera on an unstable surface.           This can cause the camera to fall or tip over and cause injury.
WARNING If a problem arises, turn the camera off, remove the battery, disconnect and unplug the AC power adapter. Continued use of the camera when it is emitting smoke, is emitting	Never attempt to take pictures while in motion. Do not use the camera while in motion. Do not use the camera while you are walking or driving a vehicle. The can result in you falling down or being involved in a traffic accident Do not touch any metal parts of the camera during a thunderstorm. This can cause an electric shock due to induced current from th
Unplug frampover socket.       any unusual odor, or is in any other abnormal state can cause a fire or electric shock.         • Contact your FUJIFILM dealer.	Do not use the battery except as specified.           Load the battery as aligned with the indicator.

	MARNING	CAUTION	
$\bigcirc$	Do not heat, change or take apart the battery. Do not drop or subject the bat- tery to impacts. Do not store the battery with metallic products. Do not use chargers other than the specified model to charge the battery.	$\bigcirc$	Do not leave this camera in places subject to extremely high temperatures. Do not leave the camera in locations such as a sealed vehicle or in direct sunlight. This can cause a fire.
	Any of these actions can cause the battery to burst or leak and cause fire or injury as a result.	$\bigcirc$	Keep out of the reach of small children. This product could cause injury in the hands of a child.
$\mathcal{O}$	Use only the battery or AC power adapters specified for use with this camera. Do not use voltages other than the power supply voltage shown. The use of other power sources can cause a fire.	$\bigcirc$	<b>Do not place heavy objects on the camera.</b> This can cause the heavy object to tip over or fall and cause injury.
$\overline{\mathcal{O}}$	If the battery leaks and fluid gets in contact with your eyes, skin or clothing. Flush the affected area with clean water and seek medical attention or call an emergency number right away.	$\bigcirc$	Do not move the camera while the AC power adapter is still connected. Do not pull on the connection cord to disconnect the AC power adapter. This can damage the power cord or cables and cause a fire or electric shoce
0	Do not use the charger to charge batteries other than those specified here. The supplied battery charger is for use only with the type of battery supplied with the camera. Using the charger to charge conventional	$\bigcirc$	Do not use the AC power adapter when the plug is damaged or the plug sock connection is loose. This could cause a fire or electric shock.
y	batteries or other types of rechargeable batteries can cause the bat- tery to leak fluid, overheat or burst.	$\bigcirc$	Do not cover or wrap the camera or the AC power adapter in a cloth or blanker. This can cause heat to build up and distort the casing or cause a fire
0	Danger of explosion if battery is incorrectly replaced. Replace only with the same.	0	When you are cleaning the camera or you do not plan to use the camera for an extended period, remove the battery and disconnect and unplug the power adapter.
	Do not use in the presence of flammable objects, explosive gases, or dust.		Failure to do so can cause a fire or electric shock.
<u> </u>	When carrying the battery, install it in a digital camera or keep it in the hard case. When storing the battery, keep it in the hard case. When discarding,	<b>E</b>	When charging ends, unplug the charger from the power socket. Leaving the charger plugged into the power socket can cause a fire.
0	cover the battery terminals with insulation tape. Contact with other metallic objects or battery could cause the bat- tery to ignite or burst.	$\bigcirc$	Using a flash too close to a person's eyes may temporarily affect the eyesight Take particular care when photographing infants and young chi dren.
0	Keep Memory Cards out of the reach of small children. Because Memory Cards are small, they can be swallowed by children. Be sure to store Memory Cards out of the reach of small children. If	0	When a memory card is removed, the card could come out of the slot too quid Iy. Use your finger to hold it and gently release the card. Injury could result to those struck by the ejected card.
	a child swallows a Memory Card, seek medical attention or call an emergency number.		Request regular internal testing and cleaning for your camera. Build-up of dust in your camera can cause a fire or electric shock. • Contact your FUIFILM dealer to request internal cleaning every 2 year
	CAUTION Do not use this camera in locations affected by oil fumes, steam, humidity or	$\bigcirc$	Please note this is not a free of charge service.     Remove your fingers from the flash window before the flash fires.     Failure to observe this precaution could result in burns.
$\mathcal{S}$	dust. This can cause a fire or electric shock.		Keep the flash window clean and do not use the flash if the window is o

structed.

This can cause a fire or electric shock.

Failure to observe these precautions could cause smoke or discoloration.

#### **Power Supply and Battery**

\* Confirm your battery type before reading the following descriptions

The following explains proper use of batteries and how to prolong their life. Incorrect use of batteries can cause shorter battery life, as well as leakage, excessive heat, fire or explosion.

#### 1 Camera uses the Rechargeable Lithium-ion Battery

- \* When shipped, the battery is not fully charged. Always charge the battery before using it.
- \* When carrying the battery, install it in a digital camera or keep it in the soft case

#### Battery Features

- · The battery gradually loses its charge even when not used. Use a battery that has been charged recently (in the last day or two) to take pictures.
- To maximize the life of the battery. turn the camera off as guickly as possible when it is not being used.
- The number of available frames will be lower in cold locations or at low temperatures. Take along a spare fully charged battery. You can also increase the amount of power produced by putting the battery in your pocket or another warm place to heat it and then loading it into the camera just before you take a picture.

If you are using a heating pad, take **Notes on storage** care not to place the battery directly against the pad. The camera may not operate if you use a depleted battery in cold conditions.

#### Charging the Battery

- · Charging times will increase at ambient temperatures below +10°C (+50°F) or above +35°C (+95°F). Do not attempt to charge the battery at temperatures above 40°C (+104°F); at temperatures below 0°C (+32°F), the battery will not charge.
- The Rechargeable Lithium-ion Batterv does not need to be fully discharged or exhausted flat before being charged.
- The battery may feel warm after it **Handling the Battery** has been charged or immediately normal.
- · Do not recharge a fully charged battery.

#### Battery Life

At normal temperatures, the batterv can be used at least 300 times. If the time for which the battery provides power shortens markedly, this indicates that the battery has reached the end of its effective life and should be replaced.

- If a battery is stored for long periods while charged, the performance of the battery can be impaired. If the battery will not be used for some time, run the battery out before storing it.
- · If you do not intend to use the camera for a long period of time, remove the battery from the camera.
- · Store the battery in a cool place.
- The battery should be stored in a dry location with an ambient temperature between +15°C and +25°C (+59°F and +77°F).
- Do not leave the battery in hot or extremely cold places.

## **Cautions for Your Safety:**

- after being used. This is perfectly . Do not carry or store battery with metal objects such as necklaces or hairpins.
  - Do not heat the battery or throw it into a fire.
  - · Do not attempt to take apart or change the battery.
  - Do not recharge the battery with chargers other those specified.
  - Dispose of used battery promptly.
  - · Do not drop the battery or otherwise subject it to strong impacts.
  - · Do not expose the battery to water.
  - Always keep the battery terminals clean

· Do not store batteries in hot places. Also, if you use the battery for a long period, the camera body and the battery itself will become warm. This is normal. Use the AC power adapter if you are taking pictures or viewing images for a long period of time.

#### 2 Camera uses AA Alkaline, **Rechargeable Ni-MH (nickel-metal** hydride) or AA lithium batteries

\* For details on the batteries that vou can use, refer to the Owner's Manual of your camera.

#### Cautions for Using Battery

- Do not heat the batteries or throw them into a fire
- · Do not carry or store batteries with metal objects such as necklaces or hairpins.
- · Do not expose the batteries to water, and keep batteries from getting wet or stored in moist locations.
- · Do not attempt to take apart or change the batteries, including battery casings.
- · Do not subject the batteries to strong impacts.
- · Do not use batteries that are leakina, deformed, discolored.
- Do not store batteries in warm or humid places.
- · Keep the batteries out of reach of babies and small children.
- Make sure that the battery polarity  $(\oplus \text{ and } \ominus)$  is correct.

- Do not use new with used batteries. Do not use charged and discharged batteries together.
- · Do not use different types or brands of batteries at the same time.
- · If you do not intend to use the camera for a long period of time, remove the batteries from the camera. Note if the camera is left with the batteries removed, the time and date settings are cleared.
- The batteries feel warm right after being used. Before removing the • Ni-MH batteries left unused in batteries, turn the camera off and wait for the batteries to cool down.
- Since batteries do not work well in cold weather or locations, warm the batteries by placing them inside your garments before use. Batteries do not work well when cold. They will work again when the temperature returns to normal.
- · Soil (such as fingerprints) on the battery terminals makes the batteries charge less reducing the number of images. Carefully wipe the battery terminals with a soft dry cloth before loading.

If any liquid at all leaks from the batteries, wipe the battery compartment thoroughly and then load new batteries



If any battery fluid comes into contact with your hands or clothing, flush the area thoroughly with water. Note that battery fluid can cause loss of eyesight if it gets into your eves. If this occurs, do not rub your eyes. Flush the fluid out with clean water and contact your physician for treatment.

#### Using the AA-size Ni-MH batteries correctly

come "deactivated". Also, repeatedly charging Ni-MH batteries that are only partially discharged can cause them to suffer from the "memory effect". Ni-MH batteries that are "deactivated" or affected by "memory" suffer from the problem of only providing power for a short time after being charged. To prevent this problem, discharge and recharge them several times using the camera's "Discharging rechargeable batteries" function. Deactivation and memory are specific to Ni-MH batteries and are not in fact battery faults.

See Owner's Manual for the procedure for "Discharging rechargeable batteries".

#### 

Do not use the "Discharging rechargeable batteries" function when alkaline batteries being used.

- To charge Ni-MH batteries, use the guick battery charger (sold separately). Refer to the instructions supplied with the charger to make sure that the charger is used correctly.
- · Do not use the battery charger to charge other batteries.
- Note that the batteries feel warm after being charged.
- storage for long periods can be- Due to the way the camera is constructed, a small amount of current is used even when the camera is turned off. Note in particular that leaving Ni-MH batteries in the camera for a long period will overdischarge the batteries and may render them unusable even after recharging.
  - Ni-MH batteries will self-discharge even when not used, and the time for which they can be used may be shortened as a result.
  - Ni-MH batteries will deteriorate rapidly if over-discharged (e.g. by discharging the batteries in a flashlight). Use the "Discharging rechargeable batteries" function provided in the camera to discharge the batteries.

 Ni-MH batteries have a limited service life. If a battery can only be used for a short time even after repeated discharge-charge cycles, it may have reached the end of its service life.

#### Disposing of Batteries

CAUTION: When disposing of batteries, do so in accordance with your local waste disposal regulations.

#### 3 Notes on both models (1, 2)

#### AC Power Adapter

Always use the AC Power Adapter with the camera. The use of an AC Power adapter other than FUJIEII M AC Power Adapter can be damaged to your digital camera.

For details on the AC power adapter, refer to the Owner's Manual of your camera.

- Use the AC power adapter for indoor use only.
- · Plug the connection cord plug securely into the DC input terminal.
- · Turn off the FUJIFILM Digital camera before disconnecting the cord from the DC input terminal. To disconnect, pull out the plug gently. Do not pull on the cord.
- · Do not use the AC power adapter with any device other than your camera.
- During use, the AC power adapter will become hot to the touch. This is normal.

- · Do not take apart the AC power unless intended only for personal gerous.
- Do not use the AC power adapter performances, entertainments and in a hot and humid place.
- adapter to strong shocks.
- humming. This is normal.
- If used near a radio, the AC power adapter may cause static. If this happens, move the camera away from the radio.

#### **Before Using the Camera**

Do not aim the camera at extremely bright light sources, such as the sun in a cloudless sky. Failure to observe this precaution could damage the camera image sensor.

#### Test Shots Prior to Photography

For important photographs (such as weddings and overseas trips), always take a test shot and view the image to make sure that the camera is working normally.

· FUJIFILM Corporation cannot accept liability for any incidental losses (such as the costs of photography or the loss of income from photography) incurred as a result of faults with this product.

#### Notes on Copyright

Images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner.

adapter. Doing so could be dan- use. Note that some restrictions apply to the photographing of stage exhibits, even when intended purely • Do not subject the AC power for personal use. Users are also asked to note that the transfer of Memory The AC power adapter may emit a Card containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

#### Handling Your Digital Camera

To ensure that images are recorded correctly, do not subject the camera to impact or shock while an image is being recorded.

#### Liquid Crystal

If the LCD monitor is damaged, take particular care with the liquid crystal in the monitor. If any of the following situations arise, take the urgent action indicated.

· If liquid crystal comes in contact with your skin:

Wipe the area with a cloth and then wash thoroughly with soap and running water.

- · If liquid crystal gets into your eye: Flush the affected eye with clean water for at least 15 minutes and then seek medical assistance.
- If liquid crystal is swallowed: Flush your mouth thoroughly with water. Drink large guantities of water and induce vomiting. Then seek medical assistance.

Although the LCD panel is produced **Notes on Electrical Interference** with highly sophisticated technologies, there may be black spots or permanently lit spots. This is not a this camera may cause interference malfunction, and does not affect recorded images.

#### Trademark Information

xD-Picture Card and *P*, are trademarks of FUJIFII M Corporation. The typefaces included herein are solely developed by DynaComware Taiwan Inc. Macintosh, QuickTime, and Mac OS are trademarks of Apple Inc. in the U.S.A. and other countries. Windows 8. Windows 7. Windows Vista, and the Windows logo are trademarks of the Microsoft group of companies. Adobe and Adobe Reader are either trademarks or registered trademarks of Adobe Systems Incorporated in the U.S.A. and/ or other countries. The SDHC and SDXC logos are trademarks of SD-3C. LLC. The HDMI logo is a trademark. YouTube is a trademark of Google Inc. Facebook is a trademark of Facebook, Inc. All other trade names mentioned in this manual are the trademarks or registered trademarks of their respective owners.

If the camera is to be used in hospitals or aircrafts, please note that to other equipment in the hospital or aircraft. For details, please check with the applicable regulations.

#### Exif Print (Exif ver. 2.3)

Exif Print Format is a newly revised digital camera file format that contains a variety of shooting information for optimal printing.

#### IMPORTANT NOTICE: Read Before Using the Software

Direct or indirect export, in whole or in part, of licensed software without the permission of the applicable governing bodies is prohibited.

## **About This Manual**

Before using the camera, read this manual and the warnings on pages ii–vi. For information on specific topics, consult the sources below.

✓ Table of Contents 💷 viii	✓ Troubleshooting ♀ 99
The "Table of Contents" gives an overview of the entire manual. The principal camera operations are listed here.	Having a specific problem with the camera? Find the answer here.
✔ Warning Messages and Displays 🕮 107	
Find out what's behind that flashing icon or error	
message in the display.	

#### Memory Cards

Pictures can be stored in an optional SD, SDHC, and SDXC memory cards (🕮 9), referred to in this manual as "memory cards".

## **Table of Contents**

For Your Safety	ii
Safety Notes	
About This Manual	

#### **Before You Begin**

. 1
. 1
. 1
. 2
.4
. 5
•

#### **First Steps**

The Strap and Lens Cap	6
Inserting the Batteries	7
Inserting a Memory Card	9
Turning the Camera On and Off	
Shooting Mode	
Playback Mode	
Basic Setup	

Basic Photography and Playback	
Taking Pictures in SRAUTO (Scene Recognition) Mo	<b>de</b> 14
Viewing Pictures	19
More on Photography	
Shooting Mode	20
SRAUTO SCENE RECOGNITION	20
<b>AUTO</b>	
💁 CONTINUOUS SHOOTING	20
Adv. ADVANCED	21
SP SCENE POSITION	24
PANORAMA MOTION PANORAMA	25
P: PROGRAM AE	27
S: SHUTTER PRIORITY AE	28
<b>M</b> : MANUAL	
Intelligent Face Detection	
Focus Lock	
S Macro and Super Macro Modes (Close-ups)	34
4 Using the Flash (Intelligent Flash)	35
ి Using the Self-Timer	
Exposure Compensation	42
- · ·	

#### **More on Playback**

Playback Options	44
Playback Zoom	4
★ Favorites: Rating Pictures	4
Viewing Photo Information	46
Multi-Frame Playback	47
Viewing Panoramas	48
PhotoBook Assist	49
Creating a PhotoBook	49
Viewing PhotoBooks	50
Editing and Deleting PhotoBooks	50
Image Search	5 <sup>-</sup>
Deleting Pictures	52
-	

#### Movies

Recording Movies	53
Movie Frame Size	
Viewing Movies	55

#### Connections

Viewing Pictures on TV	56
Connecting the Camera to High Definition (HD) TVs	s56
Printing Pictures via USB	57
Connecting the Camera	57
Printing Selected Pictures	57
Printing the DPOF Print Order	58
Creating a DPOF Print Order	60
Viewing Pictures on a Computer	63
Copying Pictures to a Computer	63
Windows: Downloading and Installing MyFinePix S	tudio
to a Computer	63

Windows: Installing MyFinePix Studio	64
Windows: Uninstalling MyFinePix Studio	66
Connecting the Camera	66
Menus	
Using the Menus: Shooting Mode	
Using the Shooting Menu	
Shooting Menu Options	
ISO	71
IMAGE SIZE	
IMAGE QUALITY	72
FINEPIX COLOR	73
WB WHITE BALANCE	73
PHOTOMETRY	74
AF MODE	
MOVIE AF MODE	
🔄 AE BKT EV STEPS	76
🔁 FLASH	76
Using the Menus: Playback Mode	77
Using the Playback Menu	
Playback Menu Options	77
MARK FOR UPLOAD TO	78
SLIDE SHOW	80
RED EYE REMOVAL	81
• PROTECT	82
CROP	83
🖀 RESIZE	84
IMAGE ROTATE	
DISP. ASPECT	86

The Setup Menu	87
Using the Setup Menu	87
Setup Menu Options	88
1 TIME DIFFERENCE	90
🕼 FORMAT	91
🔄 IMAGE DISP	91
🖾 FRAME NO	92
PLAYBACK VOLUME	92
🐼 LCD BRIGHTNESS	92
🔀 LCD POWER SAVE	92
🗃 AUTO POWER OFF	93
INTELLIGENT DIGITAL ZOOM	93
🚍 DISCHARGE (Ni-MH Batteries Only)	94
DATE STAMP	95

#### **Technical Notes**

Optional Accessories	96
Accessories from FUJIFILM	97
Caring for the Camera	98

#### Troubleshooting

Troubleshooting	
Warning Messages and Displays	107

#### Appendix

Memory Card Capacity	111
Specifications	112

## Symbols and Conventions

The following symbols are used in this manual:

**()** Caution: This information should be read before use to ensure correct operation.

**The Note:** Points to note when using the camera.

**Tip**: Additional information that may be helpful when using the camera.

E: Other pages in this manual on which related information may be found.

Menus and other text in the camera monitor are shown in bold. In the illustrations in this manual, the monitor display may be simplified for explanatory purposes.

## **Supplied Accessories**

The following items are included with the camera:



• Basic Manual

\* A USB cable is not included. Use a Mini USB cable (available from third-party suppliers) that is no longer than 60 cm (1.9 ft.).






Strap


## Parts of the Camera

For more information, refer to the page listed to the right of each item.



\* Illustrations in this manual may be simplified for explanatory purposes.


#### Introduction




#### **Camera Displays**

The following indicators may appear during shooting and playback. The indicators displayed vary with camera settings.

#### Shooting



**Before You Begin** 




shutter button is pressed (🕮 20).

niques made easy (🕮 21).

#### Attaching the Strap

Attach the strap to the two strap eyelets as shown below.

1





#### **\** Caution


To avoid dropping the camera, be sure the strap is correctly secured.

### The Lens Cap

Attach the lens cap as shown.



To avoid losing the lens cap, pass the supplied string through the eyelet () and secure the lens cap to the strap ().





## **Inserting the Batteries**

The camera takes three AA alkaline, lithium, or rechargeable Ni-MH batteries. A set of three alkaline batteries is supplied with the camera. Insert the batteries in the camera as described below.

## 1 Open the battery-chamber cover.

Slide the batterychamber latch in the direction shown and open the batterychamber cover.

#### 👉 Note

Be sure the camera is off before opening the battery-chamber cover.

#### **\** Cautions

- Do not open the battery-chamber cover when the camera is on. Failure to observe this precaution could result in damage to image files or memory cards.
- Do not use excessive force when handling the battery-chamber cover.

## **2** Insert the batteries.

Insert the batteries in the orientation shown by the "+" and "-" marks inside the battery chamber.

#### **\** Cautions

- Insert the batteries in the correct orientation.
- Never use batteries with peeling or damaged casing or mix old and new batteries, batteries with different charge levels, or batteries of different types.
   Seilerent types

Failure to observe these precautions could result in the batteries leaking or overheating.

- Never use manganese or Ni-Cd batteries.
- The capacity of alkaline batteries varies with the manufacturer and drops at temperatures below 10°C/50°F; Ni-MH batteries are recommended.
- Fingerprints and other soil on the battery terminals can shorten battery life.





#### **3** Close the battery-chamber cover.

Close the battery-chamber cover and slide it in until the latch clicks into place.



#### **\** Caution

Do not use force. If the battery-chamber cover does not close, check that the batteries are in the correct orientation and try again.

#### 🗟 Tip: Using an AC Power Adapter

The camera can be powered by an optional AC power adapter and DC coupler (sold separately).

#### Choosing the Battery Type

After replacing the batteries with batteries of a different type, select the battery type using the **BATTERY TYPE** option in the setup menu (**B** 89) to ensure that the battery level is



displayed correctly and the camera does not turn off unexpectedly.

The camera can store pictures on SD, SDHC, and SDXC memory cards (sold separately).

### Compatible Memory Cards

FUJIFILM and SanDisk SD, SDHC, and SDXC memory cards have been approved for use in the camera. A complete list of approved memory cards is available at

*http://www.fujifilm.com/products/digital\_cameras/index.html.* Operation is not guaranteed with other cards. The camera can not be used with *xD-Picture Cards* or MultiMediaCard (MMC) devices.

### **\** Caution

Memory cards can be locked, making it impossible to format the card or to record or delete images. Before inserting a memory card, slide the write-protect switch to the unlocked position.

Write-protect

## ■ Inserting a Memory Card

Open the battery-chamber cover.

#### 👉 Note

Be sure the camera is off before opening the battery-chamber cover.



## 2 Insert the memory card.

Holding the memory card in the orientation shown below, slide it in until it clicks into place at the back of the slot.







Be sure card is in correct orientation; do not insert at an angle or use force. 3 Close the battery-chamber cover.

Close the batterychamber cover and slide it in until the latch clicks into place.



#### Removing Memory Cards

After confirming that the camera is off, press the card in and then release it slowly. The card can now be removed by hand.



#### **\** Cautions


- The memory card may spring out if you remove your finger immediately after pushing the card in.
- Memory cards may be warm to the touch after being removed from the camera. This is normal and does not indicate a malfunction.

#### **\** Cautions

- <u>Do not turn the camera off or remove the memory card while the memory card is being formatted or data are being recorded to or</u> <u>deleted from the card</u>. Failure to observe this precaution could damage the card.
- Format SD/SDHC/SDXC memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device. For more information on formatting memory cards, see page 91.
- Memory cards are small and can be swallowed; keep out of reach of children. If a child swallows a memory card, seek medical assistance immediately.
- miniSD or microSD adapters that are larger or smaller than the standard dimensions of an SD/SDHC/SDXC card may not eject normally; if the card does not eject, take the camera to an authorized service representative. Do not forcibly remove the card.
- Do not affix labels to memory cards. Peeling labels can cause camera malfunction.
- Movie recording may be interrupted with some types of SD/SDHC/SDXC memory card. Use a **CLASS** card or better when shooting HD movies.
- Formatting a memory card in the camera creates a folder in which pictures are stored. Do not rename or delete this folder or use a computer or other device to edit, delete, or rename image files. Always use the camera to delete pictures from memory cards; before editing or renaming files, copy them to a computer and edit or rename the copies, not the originals.

## Shooting Mode

Press the **ON/OFF** button to turn the camera on. The lens will extend automatically.



Press **ON/OFF** again to turn the camera off.

#### 民 Tip: Switching to Playback Mode

Press the ▶ button to start playback. Press the shutter button halfway to return to shooting mode.

#### **\** Cautions

- Be sure that the lens cap is removed before turning the camera on.
- Forcibly preventing the lens from extending could cause damage or product malfunction.
- Pictures can be affected by fingerprints and other marks on the lens. Keep the lens clean.
- The **ON/OFF** button does not completely disconnect the camera from its power supply.

## <u>Playback Mode</u>

To turn the camera on and begin playback, press the  $\blacktriangleright$  button for about a second.



Press the **b** button again or press the **ON/OFF** button to turn the camera off.

#### 🔊 Tip: Switching to Shooting Mode

To exit to shooting mode, press the shutter button halfway. Press the 🕨 button to return to playback.

#### 🔊 Tip: Auto Power Off

The camera will turn off automatically if no operations are performed for the length of time selected in the The camera will turn off automatically if no operations are performed for the length of time selected in the **AUTO POWER OFF** menu (see page 93).

## **Basic Setup**

START MENU 图言語/LANG ENGLISH FRANCAIS

> DEUTSCH ESPAÑOL PORTUGUÉS

SET BACK NO

A language-selection dialog is displayed the first time the camera is turned on. Set up the camera as described below (for information on resetting the clock or changing languages, see page 88).

## Choose a language.

**1.1** Press the selector up or down to highlight a language.

1.2 Press MENU/OK.

## **2** Set the date and time.

- ODDATE / TIME NOT SET
   2.1 Product

   2015
   2015

   2013
   AM

   2012
   AM

   COX SET
   EMO(N)
- 2.1 Press the selector left or right to highlight the year, month, day, hour, or minute and press up or down to change. To change the order in which the year, month, and day are displayed, highlight the date format and press the selector up or down.
  - 2.2 Press MENU/OK. A battery type message will be displayed; if the type differs from the type inserted in the camera, use the setup menu BATTERY TYPE option ( 89) to specify the correct type.

### Tip: The Camera Clock

If the batteries are removed for an extended period, the camera clock and battery type will be reset and the language-selection dialog will be displayed when the camera is turned on. If the batteries are left in the camera for about 10 hours, the battery can be removed for about 24 hours without resetting the clock, language, or battery type.








First Steps

## Taking Pictures in SRAUTO (Scene Recognition) Mode


This section describes how to take pictures in **SRAUTO** mode.

### Turn the camera on.

Press the **ON/OFF** button to turn the camera on.



### 2 Select SRAUTO mode. Rotate the mode dial to SRAUTO.



#### SRAUTO


In this mode, the camera automatically analyzes the composition and selects a scene according to shooting conditions and the type of subject:



- O (PORTRAIT): Human portrait Selected scene subject.
- 🗅 (LANDSCAPE): Man-made or natural landscape.
- 🕲 (NIGHT): Poorly-lit landscape.
- ❷ (MACRO): Subject close to camera.
- 🚱 (NIGHT PORTRAIT): Poorly-lit portrait subject.
- 🕲 (BACKLIT PORTRAIT): Back-lit portrait subject.
- (AUTO) is selected if none of the above are detected.

## **3** Check the battery level.

Check the battery level in the display.




Indicator	Description
NO ICON	Batteries are partially discharged.
1	Batteries are low. Replace as soon
(red)	as possible.
	Batteries are exhausted. Turn cam-
(blinks red)	era off and replace batteries.

#### 👉 Note

A battery warning may not be displayed before the camera turns off, particularly if batteries are reused after having once been exhausted. Power consumption varies greatly from mode to mode; the low battery warning (() may not be displayed or may be displayed only briefly before the camera turns off in some modes or when switching from shooting to playback mode.

## **4** Frame the picture.

Use the zoom control to frame the picture in the display.



#### Tip: Focus Lock

Use focus lock ( $\boxplus$  32) to focus on subjects that are not in the focus frame.

#### Holding the Camera

Hold the camera steady with both hands and brace your elbows against your sides. Shaking or unsteady hands can blur your shots.



To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the lens and flash.



#### Shooting Information

To choose the shooting information and guides displayed, press the **DISP/BACK** button.

Indicators displayed/indicators hidden/best framing/ HD framing/histogram

To use best framing, position the main subject at the intersection of two lines or align one of the horizontal lines with the horizon. When HD framing is used, 16:9 aspect ratio guide lines are displayed to make it easy to frame HD shots. Use focus lock (🖽 32) to focus on subjects that will not be in the center of the frame in the final photograph.

#### Avoiding Blurred Pictures

If the subject is poorly lit, blurring caused by camera shake can be reduced using the **MODE** option in the setup menu (**B** 89). Note that blurring may still occur depending on the scene.

### 👉 Note

Choose **OFF** to turn image stabilization off when using a tripod.

## **5** Focus.

Press the shutter button halfway to focus.



### 👉 Note

The lens may make a noise when the camera focuses; this is normal. In **SRAUTO** mode, the camera continuously adjusts focus, increasing the drain on the batteries.

If the camera is able to focus, it will beep twice and the indicator lamp will glow green.

If the camera is unable to focus, the focus frame will turn red, **!AF** will be displayed, and the indicator lamp will blink green. Change the composition or use focus lock (III) 32).


## 6 Shoot.

Smoothly press the shutter button the rest of the way down to take the picture.




#### 🗟 Tip: The Shutter Button

The shutter button has two positions. Pressing the shutter button halfway (1) sets focus and exposure; to shoot, press the shutter button the rest of the way down (2).



#### 👉 Note

If the subject is poorly lit, the AF-assist illuminator may light to assist focus (🗐 33). For information on using the flash when lighting is poor, see page 35.



The indicator lamp shows camera status as follows:

Indicator lamp	Camera status
Glows green	Focus locked.
Blinks green	Blur, focus, or exposure warning. Pic-
	ture can be taken.
Blinks green	Recording pictures. Additional pic-
and orange	tures can be taken.
Glows	Recording pictures. No additional pic-
orange	tures can be taken at this time.
Blinks orange	Flash charging; flash will not fire when
	picture is taken.
	Lens or memory error (memory card
Blinks red	full or not formatted, format error, or
	other memory error).
Tip: Warnings Detailed warnings appear in the display. See pages	

Detailed warnings appear in the display. See pages 107–110 for more information.

## **Viewing Pictures**

Pictures can be viewed in the monitor. When taking important photographs, take a test shot and check the results.

## 1 Press the ▶ button.



The most recent picture will be displayed in the monitor.



## **2** View additional pictures.

Press the selector right to view pictures in the order recorded, left to view pictures in reverse order.



Press the shutter button to exit to shooting mode.

### Deleting Pictures

To delete the picture currently displayed in the monitor, press the selector up (面). The following dialog will be displayed.





• To delete the picture, press **MENU/OK**.

T ERASE	OK?
•	•
OK VES	GACCOCANCEL
	CHARLE OF MOLL

To exit without deleting the picture, press **DISP/BACK**.

#### 🗟 Tip: The Playback Menu

Pictures can also be deleted from the playback menu (
 77).

Choose a shooting mode according to the scene or type of subject. To choose a shooting mode, rotate the mode dial to the desired setting (🕮 5). The following modes are available:

## SRAUTO SCENE RECOGNITION


The camera automatically analyzes the composition and selects the appropriate scene mode according to the subject and shooting conditions (E= 14).

## AUTO

Choose for crisp, clear snapshots. This mode is recommended in most situations.

## **<u>©</u> CONTINUOUS SHOOTING**

Capture motion in a series of pictures. Use the **CONTINUOUS** option in the shooting menu to choose a continuous mode.



#### **\** Cautions

- Focus and exposure are determined by the first frame in each series. The flash turns off automatically; the previously-selected flash mode is restored when the shooting mode is changed.
- Frame rate varies with shutter speed, shooting conditions, and the number of pictures in each burst.
- The number of pictures that can be taken in a single burst varies with the scene and camera settings. The number of pictures that can be recorded depends on the memory available.
- If the self-timer is used when 🚡 and 🖳 are selected, only one picture will be taken when the shutter button is pressed.
- At a setting of A, white lines may appear in bright areas of the image; these can be avoided by choosing A mode.

### 🔳 🖻 AE BKT

Each time the shutter button is pressed, the camera takes three shots: one using the metered value for exposure, the second overexposed by the amount selected for **AEBKTEV STEPS** in the shooting menu (**1**76), and the third underexposed by the same amount (the camera may not be able to use the selected bracketing increment if the amount of over- or under- exposure exceeds the limits of the exposure metering system).

#### LONG PERIOD

The camera takes pictures while the shutter button is pressed. Shooting ends when the shutter button is released or memory is full.

#### 🔳 🛅 FINAL

The camera takes up to 40 pictures while the shutter button is pressed, but only the last 5 frames are recorded.

#### ■ 👜 CONTINUOUS/👜 CONTINUOUS/👜 CONTINUOUS

The camera takes photographs while the shutter button is pressed.

## Adv. ADVANCED

This mode combines "point-and-shoot" simplicity with sophisticated photographic techniques. The **Adv. MODE** option in the shooting menu can be used to choose from the following advanced modes:

### ADVANCED FILTER

Take photos with filter effects. Select a filter effect and press **MENU/OK**.

#### 👉 Note

Depending on the subject and camera settings, images may in some cases be grainy or vary in brightness and hue.

Filter	Description
🖓 TOY CAMERA	Choose for a retro toy camera effect.
A MINIATURE	The tops and bottoms of pictures are blurred for a diorama effect.
🙉 POP COLOR	Create high-contrast images with saturated colors.
Miker HIGH-KEY	Create bright, low-contrast images.
ENER LOW-KEY	Create uniformly dark tones with few areas of emphasized highlights.
📾 DYNAMIC TONE	Dynamic tone expression is used for a fantasy effect.
🕼 FISH-EYE	Create a distorting effect of a fisheye lens.
A SOFT FOCUS	Create a look that is evenly soft throughout the whole image.
🙉 CROSS SCREEN	Create a star pattern where lines radiate out from bright objects.
🕰 PARTIAL COLOR (RED)	
PARTIAL COLOR (ORANGE)	
🕰 PARTIAL COLOR (YELLOW)	Areas of the image that are the selected color are recorded in that color. All others areas of the
A PARTIAL COLOR (GREEN)	image are recorded in black-and-white.
🕰 PARTIAL COLOR (BLUE)	
Section (Antion Color (Antion	]

\* To check the effect, play the picture after shooting.

### Q4 Natural & 4

This mode helps ensure good results with backlit subjects and in other situations with difficult lighting. Before shooting, raise the flash; pictures can only be taken when the flash is raised. Each time the shutter button is pressed, the camera takes two shots: one shot without the flash to preserve natural lighting, followed immediately by a second shot with the flash. Do not move the camera until shooting is complete.

#### Notes

- Do not use where flash photography is prohibited.
- Only available if memory remains for two pictures.

### Zoom Bracketing

Each time the shutter button is pressed, the camera takes three pictures: one at the current zoom ratio with an image size of **I**, a second zoomed in  $1.4 \times$  and cropped to **M**, and a third zoomed in  $2 \times$  and cropped to **S** (pictures will only be taken if there is enough memory for three images). Two frames are displayed to show the areas that will be included in the second and third pictures; the outer frame shows the area that will be recorded at  $1.4 \times \text{zoom}$ , the inner frame the area that will be recorded at  $2 \times \text{zoom}$ .




#### 🖌 Note

Digital zoom can not be used. If digital zoom is active maximum optical zoom position.

## SP SCENE POSITION

The camera offers a choice of "scenes," each adapted to particular shooting conditions or a specific type of subject. Use the **SCENE POSITION** option in the shooting menu to choose the scene assigned to the **SP1/SP2** position on the mode dial.



Scene	Description
PORTRAIT	Choose this mode for soft-toned portraits with natural skin tones.
😫 BABY MODE	Choose for natural skin tones when taking portraits of infants. The flash turns off automatically.
LANDSCAPE	Choose this mode for crisp, clear daylight shots of buildings and landscapes.
🦗 SPORT	Choose this mode when photographing moving subjects. Priority is given to faster shutter speeds.
C NIGHT	Choose this mode for poorly lit twilight or night scenes. Sensitivity is automatically raised to reduce blur caused by camera shake.
🖈 NIGHT (TRIPOD)	Choose this mode for slow shutter speeds when shooting at night. Use a tripod to prevent blur.
# FIREWORKS	Slow shutter speeds are used to capture the expanding burst of light from a firework. Press the selector up (12) to display a shutter-speed selection dialog and press the selector up and down to choose a shutter speed.
酱 SUNSET	Choose this mode to record the vivid colors in sunrises and sunsets.
≺ <b>®</b> ∗ SNOW	Choose for crisp, clear shots that capture the brightness of scenes dominated by shining white snow.
▲? EEACH	Choose for crisp, clear shots that capture the brightness of sunlit beaches.
▼ PARTY	Capture indoor background lighting under low-light conditions.
✤ FLOWER	Choose for vivid close-ups of flowers. The camera focuses in the macro range.
TEXT TEXT	Take clear pictures of text or drawings in print. The camera focuses in the macro range.


## PANORAMA MOTION PANORAMA

In this mode, you can take up to three pictures and join them together to form a panorama. Use of a tripod is recommended to assist in composing overlapping shots.

#### ✓ Note

Operations are described in the factory settings (MAUTO).

Rotate the mode dial to PANORAMA





**7** Press the selector up to select a frame. Press the selector left or right to highlight a pan direction and press MENU/OK.




**2** Take a photograph. Exposure and white balance for the panorama are set with the first shot.




### 🗲 Note

The camera zooms all the way out and zoom remains fixed at the widest angle until shooting is complete.

Frame the next shot to overlap with the previous picture by superimposing  $\oplus$  on + so that they form a solid circle  $(\bullet)$ . The camera will release the shutter automatically. Pan direction





Display after 1st shot

- Shutter released
- **5** Take the last shot as described in Step 4.

### 🖌 Note

To end shooting and create a panorama after the first or second shot, press the multi selector up after completing Step 3 or Step 4 and proceed to Step 6.

# **6** Press **MENU/OK** to save the picture.

### **\** Cautions

- Panoramas are created from multiple frames. The camera may in some cases be unable to stitch the frames together perfectly.
- The desired results may not be achieved with moving subjects, subjects close to the camera, unvarying subjects such as the sky or a field of grass, subjects that are in constant motion, such as waves and waterfalls, or subjects that undergo marked changes in brightness. Panoramas may be blurred if the subject is poorly lit.

### For Best Results

For best results, be careful not to tilt the camera backward or forward or to either side and try not to move the camera while **①** and **+** are aligned to form a solid circle.

### Framing Panoramas Manually

Follow the steps below if the desired results are not achieved with **M AUTO** selected for **ANORA-MA MODE**:

- 1 Select M MANUAL for PANORAMA MODE in the shooting menu.
- 2 Select a frame and take the first shot.
- 3 Press MENU/OK to display a guide showing an edge of the picture you have just taken. Take the next shot, framing it to overlap with the previous picture.

Guide






Display after 1st shot

Frame next shot

- **4** Repeat Step 3 to take the third shot and then press **MENU/OK** to display the completed panorama.
- 5 Press MENU/OK to save the picture.

## P: PROGRAM AE

In this mode, the camera sets exposure automatically. If desired, you can choose different combinations of shutter speed and aperture that will produce the same exposure (program shift).



#### **\** Caution

If the subject is outside the metering range of the camera, the shutter speed and aperture displays will show "---". Press the shutter button halfway to measure exposure again.

#### Program Shift

Press the selector up (🔁) to choose the desired combination of shutter speed and aperture. Values that differ from those automatically selected by the camera are shown in yellow. The default values can be restored by raising the flash or turning the camera off. Program shift is not available when the flash is raised.




Shutter speed

## S: SHUTTER PRIORITY AE

In this mode, you choose the shutter speed while the camera adjusts aperture for optimal exposure.

Rotate the mode dial to **S**.



2 Press the selector up (☑). Shutter speed and aperture will be displayed.





**3** Press the selector up or down to choose the shutter speed.



**4** Press the **MENU/OK** button to exit to shooting mode.



**5** Take pictures. If the correct exposure can not be achieved at the selected shutter speed, aperture will be displayed in red when the shutter button is pressed halfway. Adjust shutter speed until the correct exposure can be achieved.


#### **\** Caution

If the subject is outside the metering range of the camera, the aperture display will show "---". Press the shutter button halfway to measure exposure again.

## M: MANUAL


In this mode, you choose both shutter speed and aperture. If desired, exposure can be altered from the value suggested by the camera.

Rotate the mode dial to **M**.



2 Press the selector up (☑). Shutter speed and aperture will be displayed.





**3** Press the selector up or down to choose the shutter speed.



**4** Press the selector left or right to choose the aperture.




**5** Press the **MENU/OK** button to exit to shooting mode.



**6** Take pictures.

#### The Exposure Indicator

The amount the picture will be under- or over-exposed at current settings is shown by the exposure indicator. Pictures taken with the indicator to the left of center ("-") will be underexposed, pictures taken with the indicator is to the right of center ("+"), over-exposed.



# **Intelligent Face Detection**

Intelligent Face Detection allows the camera to automatically detect human faces and set focus and exposure for a face anywhere in the frame for shots that emphasize portrait subjects. Choose for group portraits (in horizontal or vertical orientations) to prevent the camera from focusing on the background.

#### Turn Intelligent Face Detection on. To use Intelligent Face Detection, press MENU/ OK to display the shooting menu and select ON for I FACE DETECTION (I 69).



Green border

- If a face is detected, it will be indicated by a green border.
- If there is more than one face in the frame, the camera will select the face closest to the center; other faces are indicated by white borders.

#### **\** Cautions

- If no face is detected when the shutter button is pressed halfway (💷 101), the camera will focus on the subject at the center of the display and red-eye will not be removed.
- If the subject moves as the shutter button is pressed, their face may not be in the area indicated by the green border when the picture is taken. If the number of faces is large, additional time may be required for processing.

#### Intelligent Face Detection

Intelligent Face Detection is recommended when using the self-timer for group- or self-portraits (🖽 37).



When a picture taken with Intelligent Face Detection is displayed, the camera can automatically select faces for red-eye removal (🕮 81), playback zoom (🕮 45), slide shows (🕮 80), image search (🕮 51), image disp. (🕮 91), printing (🗐 60), and cropping (🕮 83).

# **Focus Lock**

To compose photographs with off-center subjects:

## **1** Position the subject in the focus frame.



## 2 Focus.

Press the shutter button halfway to set focus and exposure. Focus and exposure will remain locked while the shutter button is pressed halfway (AF/AE lock).





Repeat steps 1 and 2 as desired to refocus before taking the picture.

## **3** Recompose the picture.

Keeping the shutter button pressed halfway, recompose the picture.



## **4** Shoot.

Press the shutter-release button the rest of the way down to take the picture.



Press the rest of the way down

#### Autofocus

Although the camera boasts a high-precision autofocus system, it may be unable to focus on the subjects listed below. If the camera is unable to focus using autofocus, use focus lock (🗐 32) to focus on another subject at the same distance and then recompose the photograph.

• Very shiny subjects such • Fast-moving subjects. as mirrors or car bodies.





- Subjects photographed through a window or other reflective object.
- Dark subjects and subjects that absorb rather than reflect light, such as hair or fur.
- Insubstantial subjects, such as smoke or flame.
- Subjects that show little contrast with the background (for example, subjects in clothing that is the same color as the background).
- Subjects positioned in front of or behind a highcontrast object that is also in the focus frame (for example, a subject photographed against a backdrop of highly contrasting elements).

#### The AF-Assist Illuminator


If the subject is poorly lit, the AF-assist illuminator will light to assist the focus operation when the shutter button is pressed halfway.

#### 👉 Notes

- Avoid shining the AF-assist illuminator directly into your subject's eyes.
- The camera may be unable to focus using the AFassist illuminator in some cases. If the camera is unable to focus in macro mode (🗐 34), try increasing the distance to the subject.

# Macro and Super Macro Modes (Close-ups)

For close-ups, press the selector left (💭) to choose from the macro options shown below.



When macro mode is in effect, the camera focuses on subjects near the center of the frame. Use the zoom control to compose pictures. In super macro mode, optical zoom can not be adjusted and the flash can not be used.

#### 👉 Notes

- Use of a tripod is recommended to prevent blur caused by camera shake.
- Flash compensation may be required when using the flash (🕮 76).
- Using the flash at close range may cast a lens shadow. Zoom a little or have more distance from the subject.

When the flash is used, the camera's *Intelligent Flash* system instantly analyzes the scene based on such factors as the brightness of the subject, its position in the frame, and its distance from the camera. Flash output and sensitivity are adjusted to ensure that the main subject is correctly exposed while preserving the effects of ambient background lighting, even in dimly-lit indoor scenes. Use the flash when lighting is poor, for example when shooting at night or indoors under low light.

#### 1 Raise the flash.

Press the flash pop-up button to raise the flash.

#### Turning the Flash Off

Lower the flash where flash photography is prohibited or to capture natural lighting under dim light. At slow shutter speeds, or will be displayed to warn that pictures may be blurred; use of a tripod is recommended.


#### Choose a flash mode.

Press the selector right (**\$**). The flash mode changes each time the selector is pressed.

Description
The flash fires when required. Recommended in most situations.
The flash fires whenever a picture is taken. Use for backlit subjects or for natural
coloration when shooting in bright light.

**\$**\$/**\$** Capture both the main subject and the background under low light (note that brightly lit scenes may be overexposed).





## Focus.

Press the shutter button halfway to focus. If the flash will fire, 🗲 will be displayed when the shutter button is pressed halfway. At slow shutter speeds, 🕼 will appear in the display to warn that pictures may be blurred; use of a tripod is recommended.

## Shoot.

Press the shutter button the rest of the way down to shoot.

#### **N** Caution

The flash may fire several times with each shot. Do not move the camera until shooting is complete.

#### ✓ Note

The peripheral part of an image may be dark when using the flash.

#### Red-Eye Removal

When Intelligent Face Detection is active (🕮 30), and **ON** is selected for 🐼 **RED EYE REMOVAL** in the setup menu (🕮 81), red-eye removal is available in 🏩, 👁‡, and 🏩. Red-eye removal minimizes "red-eye" caused when light from the flash is reflected from the subject's retinas as shown in the illustration at right.









# 🔆 Using the Self-Timer

The camera offers a ten-second timer that allows photographers to appear in their own photographs, and a two-second timer that can be used to avoid blur caused by the camera moving when the shutter button is pressed.

### 1 Set the timer.

Press the selector down (🙂), and then press the selector left or right to highlight an option and press **MENU/OK**.





Choose from **OFF** (self-timer off),  $\mathfrak{G}$  (10 s delay), or  $\mathfrak{G}$  (2 s delay)

#### 2 Focus.

Press the shutter button halfway to focus.

#### **\** Caution

Stand behind the camera when using the shutter button. Standing in front of the lens can interfere with focus and exposure.

## **3** Start the timer.

Press the shutter button the rest of the way down to start the timer. The display shows the number of seconds remaining until the shutter is released. To stop the timer before the picture is taken, press **DISP/BACK**.






The self-timer lamp on the front of the camera will blink immediately before the picture is taken. If the two-second timer is selected, the self-timer lamp will blink as the timer counts down.



Because it ensures that the faces of portrait subjects will be in focus, Intelligent Face Detection (= 30) is recommended when using the self-timer for group portraits or self-portraits. To use the self-timer with Intelligent Face Detection, select 🖏 **10 SEC** or 🆏 **2 SEC** in the self-timer menu and then press the shutter button all the way down to start the timer. The camera will detect faces while the timer is counting down and adjust focus and exposure immediately before the shutter is released. Be careful not to move until the picture has been recorded.

#### 👉 Note

The self-timer turns off automatically when the picture is taken, a different shooting mode is selected, playback mode is selected, or the camera is turned off.



# 📾 INSTANT ZOOM

In instant zoom, the area surrounding the frame is visible in the display. Use to frame erratically moving subjects such as children, pets, and athletes at sporting events.

**1** Position the subject in the focus frame. Use the zoom control to frame the subject in the center of the display.



2 Select INSTANT ZOOM in the shooting menu (19 69).

An Instant Zoom setting screen is displayed.




3 Select a framed area to enlarge by pressing ▲ or ▼, and then press the MENU/OK button.

The frame is displayed as shown at right.



## **4** Focus and shoot.

The framed area will be enlarged to create a full-sized picture.



#### INTELLIGENT DIGITAL ZOOM

1 Enable digital zoom. Select ON for the INTELLIGENT DIGITAL ZOOM option in the setup menu ( 93).

## 2 Choose a subject.

Frame the subject in the center of the display using intelligent digital zoom.




3 Select INSTANT ZOOM in the shooting menu (I 69). An Instant Zoom setting screen is displayed. 4 Select a framed area to enlarge by pressing ▲ or ▼, and then press the MENU/OK button.

The camera will zoom to the maximum optical zoom position with the area that will be recorded using intelligent digital zoom indicated by a frame at the center of the display.




## **5** Frame the picture.

Use the zoom control to choose the area that will be included in the final photograph.



## **6** Focus and shoot.

The framed area will be enlarged to create a full-sized picture.



#### 🗟 Tip: Intelligent Face Detection

Intelligent Face Detection will not detect faces outside the selected frame.


#### **\** Cautions


- Pictures taken using the instant zoom are lower quality than pictures taken using normal zoom.
- Only horizontal (landscape-orientation) framing is available in continuous shooting mode.

Use exposure compensation when photographing very bright, very dark, or high-contrast subjects.

## Press the selector up (🛃).

The exposure indicator will be displayed.





## 2 Choose a value.

Press the selector left or right. The effect is visible in the display.







Choose negative values to reduce exposure ("–" sign turns yellow)



Choose positive values to increase exposure ("+" sign turns yellow)

**3** Return to shooting mode.

Press the **MENU/OK** button to return to shooting mode.

# **4** Take pictures.

## 🗲 Note

A  $\bowtie$  icon and exposure indicator are displayed at settings other than  $\pm 0$ . Exposure compensation is not reset when the camera is turned off; to restore normal exposure control, choose a value of  $\pm 0$ .


<ul> <li>Choosing an Exposure Compensation Value</li> <li>Backlit subjects: choose values from +2/3 EV to +12/3 EV</li> </ul>
<ul> <li>Highly reflective subjects or very bright scenes (e.g., snowfields): +1 EV</li> </ul>
<ul> <li>Scenes that are mostly sky: +1 EV</li> <li>Spotlit subjects (particularly if photographed against dark backgrounds): -2/3 EV</li> </ul>

- Subjects with low reflectivity (pine trees or dark-colored foliage):  $-\frac{2}{3}$  EV



# **Playback Options**

To view the most recent picture in the monitor, press the  $\blacktriangleright$  button.





Press the selector right to view pictures in the order recorded, left to view pictures in reverse order. Keep the selector pressed to scroll rapidly to the desired frame. Choosing a Display Format Press the DISP/BACK button to cycle through playback display formats as shown below.





Information on



Information off



#### 👉 Note

Pictures taken using other cameras are indicated by a 🛱 ("gift image") icon during playback.

## Playback Zoom

Select **T** to zoom in on pictures displayed in single-frame playback; select **W** to zoom out. When the picture is zoomed in, the selector can be used to view areas of the image not currently visible in the display.



- Zoom indicator

Navigation window shows portion of image currently displayed in monitor

Press **DISP/BACK** to exit zoom.

#### 🗲 Note

The maximum zoom ratio varies with image size. Playback zoom is not available with copies resized or cropped to a size of  $\mathfrak{M}$  or smaller.

#### Intelligent Face Detection

Pictures taken with Intelligent Face Detection (□ 30) are indicated by a ♀ icon. Press the ▼ button to zoom in on the subject selected with Intelligent Face Detection. You



can then use the zoom control to zoom in and out.

# ★ Favorites: Rating Pictures

To rate the picture currently displayed in full-frame playback, press **DISP/BACK** and press the selector up and down to select from zero to five stars.

#### Tip: Favorites

Ratings can be used for image search (🕮 51).

## Viewing Photo Information

To view or hide the photo information listed below in single-frame playback, press **DISP/BACK** a few times.






Image quality and size, <sup>(2)</sup> Sensitivity,
 Shutter speed/aperture, <sup>(4)</sup> FinePix color,
 Flash mode, <sup>(6)</sup> White balance,
 Exposure compensation, <sup>(8)</sup> Frame number,
 Picture (overexposed areas blink on and off),
 Histogram


#### Histograms

Histograms show the distribution of tones in the image. Brightness is shown by the horizontal axis, the number of pixels by the vertical axis.

**Optimal exposure**: Pixels are distributed in an even curve throughout the tone range. **Overexposed**: Pixels are clustered

at the right side of the graph.

**Underexposed**: Pixels are clustered at the left side of the graph.



## Multi-Frame Playback

To change the number of images displayed during playback, select  $\pmb{W}.$ 





Select **W** to increase the number of pictures displayed to two, nine, or one hundred.





Select **T** to reduce the number of images displayed.

Use the selector to highlight images and press **MENU/OK** to view the highlighted image full frame. In the nine- and hundred-frame displays, press the selector up or down to view more pictures.

#### 🗟 Tip: Two-Frame Display

Two-frame display can be used to compare pictures taken in �**‡** mode.



# **Viewing Panoramas**

To view a panorama, display in single-frame view and press the selector down.



The following operations can be performed during playback:

Operation	Button	Description	
Start/pause playback		<b>Press the selector down</b> to start playback. Press again to pause.	
End playback		Press the selector up to end playback.	

Create books from your favorite photos.

# <u>Creating a PhotoBook</u>

- Select **PHOTOBOOK ASSIST** in the playback menu.
- 2 Highlight NEW BOOK.



**3** Press **MENU/OK** to display the new book dialog.



- **4** Choose pictures for the new book.
  - **SELECT FROM ALL**: Choose from all the pictures available.

## 🗲 Note

Neither photographs வ or smaller nor movies can be selected for photobooks.

5 Scroll through the images and press the selector up to select or deselect the current image for inclusion in the book. To display the current image on the cover, press the selector down.

## 🗲 Note

The first picture selected automatically becomes the cover image. Press the selector down to select a different picture for the cover.

6 Press **MENU/OK** to exit when the book is complete.



Highlight COMPLETE PHOTOBOOK.



## 👉 Note

Choose **SELECT ALL** to select all photos, or all photos matching the specified search conditions, for the book.

# 8 Press MENU/OK. The new book will be added to the list in the photobook assist menu.



#### **\** Cautions

- Photobooks can contain up to 300 pictures.
- Books that contain no photos are automatically deleted.

#### PhotoBooks

Photobooks can be copied to a computer using the MyFinePix Studio software (🕮 63).

# Viewing PhotoBooks

Highlight a book in the photobook assist menu and press **MENU/OK** to display the book, then press the selector left and right to scroll through the pictures. Press **DISP/BACK** to return to the photobook assist menu.

# Editing and Deleting PhotoBooks

Display the photobook and press **MENU/OK** to view book edit options.



- **2** Choose from the following options:
  - **EDIT**: Edit the book as described in "Creating a PhotoBook" on page 49.
  - **ERASE**: Delete the current photobook.
- Follow the on-screen instructions.

# Image Search

Search for pictures by date, subject, scene, file type, and rating.

- menu.
- **)** Highlight one of the following options and press MENU/OK:

Option	Description
BY DATE	Find all pictures taken on a selected date.
BY FACE	Find all pictures containing faces.
BY ★ FAVORITES	Find all pictures with a specified rating (IIII 45).
BY SCENE	Find all pictures that match a selected scene.
BY TYPE OF DATA	Find all still pictures or all movies.
BY UPLOAD MARK	Find all pictures selected for upload to a specified destination (🕮 78).

Select 🐼 IMAGE SEARCH in the playback | 3 Select a search condition. Only pictures that match the search condition will be displayed. To delete or protect selected pictures or to view the selected pictures in a slide show, press **MENU/OK** and choose from the following options:

Option	See page
i ERASE	52
on PROTECT	82
SLIDE SHOW	80

**4** To end the search, select **EXIT SEARCH**.

To delete individual pictures, multiple selected pictures, or all pictures, press the selector up ( $\mathbf{m}$ ), and choose from the options below. *Note that deleted pictures can not be recovered. Copy important pictures to a computer or other storage device before proceeding.* 




Option	Description	
FRAME	Press the selector left or right to scroll through pictures and press <b>MENU/OK</b> to delete the current picture (a confirmation dialog is not displayed).	
SELECTED FRAMES	Highlight pictures and press <b>MENU/OK</b> to select or deselect (pictures that are protected or in a print order are shown by <b>II</b> ). When the operation is complete, press <b>DISP/BACK</b> to display a confirmation dialog, then highlight <b>OK</b> and press <b>MENU/OK</b> to delete the selected pictures.	
ALL FRAMES	A confirmation dialog will be displayed; highlight <b>OK</b> and press <b>MENU/OK</b> to delete all unprotected pictures. Pressing <b>DISP/BACK</b> cancels deletion; note that any pictures deleted before the button was pressed can not be recovered.	

#### 👉 Notes

- Protected pictures can not be deleted. Remove protection from any pictures you wish to delete (🕮 82).
- Pictures can also be deleted by 🛅 **ERASE** from playback menu.
- If a message appears stating that the selected images are part of a DPOF print order, press **MENU/OK** to delete the pictures.

# Recording Movies

Press ● to shoot a movie. During recording, the following indicators will be displayed and sound will be recorded via the built-in microphone (be careful not to cover the microphone during recording).



To end recording, press the  $\bullet$  button again. Recording ends automatically when the movie reaches maximum length or memory is full.

#### 👉 Notes

- Exposure and white balance are adjusted automatically throughout recording. The color and brightness of the image may vary from that displayed before recording begins.
- Sounds made by the camera may be recorded.

#### **\** Cautions

- The indicator lamp lights while movies are being recorded. Do not open the battery chamber during shooting or while the indicator lamp is lit. Failure to observe this precaution could prevent the movie from being played back.
- Vertical or horizontal streaks may appear in movies containing very bright subjects. This is normal and does not indicate a malfunction.
- The temperature of the camera may rise if it is used to record movies for an extended period or if the ambient temperature is high. This is normal and does not indicate a malfunction.
- Optical zoom can not be adjusted when shooting movies in super macro mode (🗐 34).

#### Zooming While Recording a Movie

The zoom can be used while recording a movie. In the setup menu, select **DT DIGITAL** or **OT OPTICAL** (E 89).

**DI DIGITAL**: Image quality may deteriorate when the zoom is used.

**OPTICAL**: The sound of the camera zooming may be heard when playing movie.

## Movie Frame Size

Before recording, select a frame size using the **MOVIE MODE** option in the shooting menu.

Option	Description	
1280×720	High Definition.	
<u>540</u> 640×480	Standard definition.	
<u>520</u> 320×240	Longer movie.	


# **•** Viewing Movies

During playback (E 44), movies are displayed in the monitor as shown at right. The following operations can be performed while a movie is displayed:



Operation	Description	
Start/pause	Press the selector down to start playback.	
playback	Press again to pause.	
End	Press the selector up to end playback. If	
playback/	playback is not in progress, pressing the	
delete	selector up will delete the current movie.	
	Press the selector right to advance, left to	
Advance/	rewind. If playback is paused, the movie	
rewind	will advance or rewind one frame each	
	time the selector is pressed.	
	Press MENU/OK to pause playback and dis-	
Adjust	play volume controls. Press the selector	
volume	up or down to adjust the volume; press	
	MENU/OK again to set the volume.	

Progress is shown in the monitor during playback.



#### 🚯 Tip: Viewing Movies on a Computer

Copy movies to the computer before viewing.

#### **\** Caution

Do not cover the speaker during playback.

# Connecting the Camera to High Definition (HD) TVs

When an HDMI cable (available from third-party suppliers) is connected, pictures and sound are played back on the TV.

Turn the camera off and connect an HDMI cable available from third party suppliers.



#### 👉 Notes

- The USB cable can not be used while an HDMI cable is connected.
- Use an HDMI cable no more than 1.5 m (4.9 ft.) long.
- When an HDMI cable is connected, pictures and sound are played back on the TV.
- **2** Tune the television to the HDMI input channel. See the documentation supplied with the television for details.
- 3 Press the ▶ button for about a second to turn the camera on. The camera monitor turns off and pictures and movies are played back on the TV. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.

#### **\** Caution

When connecting the cable, be sure the connectors are fully inserted.

# **Printing Pictures via USB**


If the printer supports PictBridge, the camera can be connected directly to the printer and pictures can be printed without first being copied to a computer. Note that depending on the printer, not all the functions described below may be supported.

## **Connecting the Camera**

1 Connect a USB cable (available from third-party suppliers) as shown and turn the printer on.



2 Press the ▶ button for about a second to turn the camera on. USB will be displayed in the monitor, followed by the PictBridge display shown below at right.



# **Printing Selected Pictures**

**1** Press the selector left or right to display a picture you wish to print.



PictBridge

- **2** Press the selector up or down to choose the number of copies (up to 99).
- **3** Repeat steps 1–2 to select additional pictures. Press **MENU/OK** to display a confirmation dialog when settings are complete.



**4** Press **MENU/OK** to start printing.



#### ${\ensuremath{\overline{\rm N}}}$ Tip: Printing the Date of Recording

To print the date of recording on pictures, press **DISP**/ **BACK** in steps 1–2 to display the PictBridge menu (see "Printing the DPOF Print Order," below). Press the selector up or down to highlight **PRINT WITH DATE** and press **MENU/OK** to return to the PictBridge display (to print pictures without the date of recording, select **PRINT WITHOUT DATE**).

#### 👉 Note

If no pictures are selected when the **MENU/OK** button is pressed, the camera will print one copy of the current picture.

# Printing the DPOF Print Order

To print the print order created with **PRINT ORDER (DPOF)** in the playback menu (**B** 60).

In the PictBridge display, press **DISP/ BACK** to open the PictBridge menu.





**2** Press the selector up or down to highlight **A PRINT DPOF**.



**3** Press **MENU/OK** to display a confirmation dialog.

🐔 🖴 PRINT DPOF OK?
Co TOTAL: 9 SHEETS
OK YES BACK CANCEL

# **4** Press **MENU/OK** to start printing.



#### During Printing

The message shown at right is displayed during printing. Press **DISP/BACK** to cancel before all pictures are printed (depending on the printer, printing may end before the current picture has printed).



If printing is interrupted, press **D** to turn the camera off and then on again.

#### Disconnecting the Camera

Confirm that "PRINTING" is not displayed in the monitor and turn the camera off. Disconnect the USB cable.

#### 👉 Notes

- Print pictures from a memory card that has been formatted in the camera.
- If the printer does not support date printing, the **PRINT WITH DATE** c option will not be available in the PictBridge menu and the date will not be printed on the pictures in the DPOF print order.
- When pictures are printed via direct USB connection, page size, print quality, and border selections are made using the printer.

# Creating a DPOF Print Order

The **PRINT ORDER (DPOF)** option in the playback menu can be used to create a digital "print order" for PictBridge-compatible printers (EE 96) or devices that support DPOF.

#### DPOF

**DPOF** (Digital Print Order Format) is standard that allows pictures to be printed from "print orders" stored on a memory card. The information in the order includes the pictures to be printed, date imprint, and the number of copies of each picture.

## WITH DATE 💽/ WITHOUT DATE

**1** Select playback mode and press **MENU/OK** to display the playback menu.



2 Highlight PRINT ORDER (DPOF) and press MENU/OK.







WITH DATE C: Print the date of recording on pictures.


**WITHOUT DATE**: Do not print the date of recording on pictures.

4 Press the selector left or right to display a picture you wish to include in or remove from the print order.



5 Press the selector up or down to choose the number of copies (up to 99). To remove a picture from the order, press the selector down until the num-

ber of copies is 0.



#### 🗟 Tip: Intelligent Face Detection

If the current picture was created with Intelligent Face Detection, pressing  $\blacksquare$  sets the number of copies to the number of faces detected.

#### 👉 Note

When pictures are printed via direct USB connection, page size, print quality, and border selections are made using the printer.

- 6 Repeat steps 4–5 to complete the print order. Press **MENU/OK** to save the print order when settings are complete, or **DISP/BACK** to exit without changing the print order.
- 7 The total number of prints is displayed in the monitor. Press **MENU**/ **OK** to exit.
- The pictures in the current print order are indicated by a icon during playback.





#### 👉 Notes

- Print orders can contain a maximum of 999 pictures.
- If a memory card is inserted containing a print order created by another camera, the message shown at right will be displayed. Pressing MENU/

RESET DPOF OK?
OK YES BACK NO

**OK** cancels the print order; a

new print order must be created as described above.

## RESET ALL

To cancel the current print order, select **RESET ALL** in the **PRINT ORDER** (**DPOF**) menu. The confirmation shown at right will

RESET DPOF OK?	
OK YES BACK CANCEL	

be displayed; press **MENU/OK** to remove all pictures from the order.

# **Copying Pictures to a Computer**

Windows users can use **MyFinePix Studio** to copy pictures to a computer, where they can be stored, viewed, organized, and printed.

Mac (Macintosh) users can use a standard application in Mac OS such as Image Capture to import pictures or movies to Mac. Proceed to "Connecting the Camera" (🖽 66).

# Windows: Downloading and Installing MyFinePix Studio to a Computer

If CD-ROM is not included in the Supplied Accessories (🕮 1), download **MyFinePix Studio** from the following website:

## http://fujifilm-dsc.com/mfs/.

Double-click the downloaded file "**MFPS\_Setup.EXE**" to start the installer, and follow the on-screen instructions to install MyFinePix Studio.

When installation is complete, proceed to "Connecting the Camera" (🖽 66).

# Windows: Installing MyFinePix Studio

If CD-ROM is included in the Supplied Accessories, install MyFinePix Studio from the supplied CD-ROM.

1 Confirm that the computer meets the following system requirements:

	Windows 8/Windows 7 (SP 1)/ Windows Vista (SP 2) <sup>1</sup>	Windows XP (SP 3) <sup>1</sup>	
CPU	3 GHz Pentium 4 or better (2.4 GHz Core 2 Duo or better) <sup>2</sup>	2 GHz Pentium 4 or better (2.4 GHz Core 2 Duo or better) <sup>2</sup>	
RAM	1 GB or more	512 MB or more (1 GB or more) <sup>2</sup>	
Free disk space	2 GB or more		
GPU	Supports DirectX 9 or later (recommended)	Supports DirectX 7 or later (required; performance not guaranteed with other GPUs)	
Video	1,024×768 pixels or more with 24-bit color or better		
Other	<ul> <li>• Built-in USB port recommended. Operation is not guaranteed with other USB ports.</li> <li>• .NET Framework 3.5 Service Pack 1 required when uploading images or using Map Viewer.</li> <li>• Internet connection (broadband recommended) required to install .NET Framework (if necessary), to us auto update feature, and when performing such tasks as sharing pictures on-line or via e-mail.</li> </ul>		

1 Other versions of Windows are not supported. Only pre-installed operating systems are supported; operation is not guaranteed on home-built computers or computers that have been upgraded from earlier versions of Windows.

2 Recommended when displaying HD movies.

**2** Start the computer. Log in to an account with administrator privileges before proceeding.

**3** Exit any applications that may be running and insert the installer CD in a CD-ROM drive.

#### Windows 8/Windows 7/Windows Vista

If an AutoPlay dialog is displayed, click **SETUP. EXE**. A "User Account Control" dialog will then be displayed; click **Yes** (Windows 8/Windows 7) or **Allow** (Windows Vista).

The installer will start automatically; click **Install MyFinePix Studio** and follow the onscreen instructions to install MyFinePix Studio.

#### If the Installer Does Not Start Automatically (Windows 7/Windows Vista/Windows XP)

If the installer does not start automatically, select **Computer** or **My Computer** from the Start menu, then double-click the **FINEPIX** CD icon to open the FINEPIX CD window and double-click **setup** or **SETUP.EXE**.

#### If the Installer Does Not Start Automatically (Windows 8)

- 1 Select **Desktop** on the Start screen.
- 2 Select File Explorer on the taskbar.
- 3 Select Computer in the navigation pane.
- **4** Double-click the drive icon inserting the **FINEPIX** CD and follow the on-screen instructions to install.
- **4** If prompted to install Windows Media Player, DirectX, or .NET Framework, follow the onscreen instructions to complete installation.
- **5** Remove the installer CD from the CD-ROM drive when installation is complete. Store the installer CD in a dry location out of direct sunlight in case you need to re-install the software. The version number is printed at the top of the CD label for reference when updating the software or contacting customer support.

Installation is now complete. Proceed to "Connecting the Camera" on page 66.

# Windows: Uninstalling MyFinePix Studio

Only uninstall the software when it is no longer required or before beginning reinstallation.

- **1** After quitting the software and disconnecting the camera, open the control panel and use "Programs and Features" (Windows 8/ Windows 7/Windows Vista) or "Add or Remove Programs" (Windows XP) to uninstall MyFinePix Studio.
- 2 Under Windows, one or more confirmation dialogs may be displayed; read the contents carefully before clicking **OK**.

# **Connecting the Camera**


#### 👉 Note

Windows users may require the Windows CD when starting the software for the first time.

#### **\** Caution

Loss of power during transfer could result in loss of data or damage to the memory card. Insert fresh or fully-charged batteries before connecting the camera.

2 Turn the camera off and connect a USB cable (available from third-party suppliers) as shown, making sure the connectors are fully inserted. Connect the camera directly to the computer; do not use a USB hub or keyboard.



3 Press the ► button for about a second to turn the camera on and follow the on-screen instructions to copy pictures to the computer. To exit without copying pictures, click Cancel.

Importing pictures or movies to Mac (Macintosh) Use a standard application in Mac OS such as Image Capture to import pictures or movies to Mac. For more information on using the software, start the application and select the appropriate option from the **Help** menu.

#### **\** Cautions

- If a memory card containing a large number of images is inserted, there may be a delay before the software starts and you may be unable to import or save images. Use a memory card reader to transfer pictures.
- Make sure that the computer does not display a message stating that copying is in progress and that the indicator lamp is out before turning the camera off or disconnecting the USB cable (if the number of images copied is very large, the indicator lamp may remain lit after the message has cleared from the computer display). Failure to observe this precaution could result in loss of data or damage to the memory card.
- Disconnect the camera before inserting or removing memory cards.
- In some cases, it may not be possible to access pictures saved to a network server using the software in the same way as on a standalone computer.
- The user bears all applicable fees charged by the phone company or Internet service provider when using services that require an Internet connection.

# <u>Using the Shooting Menu</u>

- **1** Press **MENU/OK** to display the shooting menu.
- **2** Press the selector up or down to highlight the desired menu item.
- **3** Press the selector right to display options for the highlighted item.



- **4** Press the selector up or down to highlight the desired option.
- **5** Press **MENU/OK** to select the high-lighted option.
- **6** Press **DISP/BACK** to exit from the menu.





# **Shooting Menu Options**

Menu item	Description	Options	Default
SCENE POSITION	Choose a scene for <b>SP1/SP2</b> mode (🕮 24).	\$/ <b>\/</b> / <b>%</b> /⊄/ <sub>*</sub> ⊄/%/	SP1: 🗣
		<b>≚</b> /*&/∡1/▼/*/™	SP2: 📥
Adv. MODE	Choose an advanced shooting mode (💷 21).	AAV/@\$/	AGA
	Adjust ISO sensitivity. Choose higher values when the	AUTO (1600) / AUTO (800) /	
ISO ISO	subject is poorly lit ( 71).	AUTO (400) / 6400 S / 3200 S /	AUTO (800)
		1600/800/400/200/100	
		<b>4</b> :3/ <b>1</b> :1/ <b>1</b> :1/	
IMAGE SIZE	Choose image size and aspect ratio (💷 71).	M 4:3/ M 3:2/ M 16:9/ M 1:1/	L 4:3
		S 4:3/ S 3:2/ S 16:9/ S 1:1	
🔛 IMAGE QUALITY	Choose image quality (🕮 72).	FINE/NORMAL	NORMAL
FINEPIX COLOR	Shoot pictures in standard or saturated color or in black- and white (🗐 73).	sor/or/or	STD
I WHITE BALANCE	Adjust color for different light sources (🕮 73).	AUTO/只/涞/≿/ 牂/洸/洸/み	AUTO
INSTANT ZOOM	Use to frame erratically moving subjects such as children, pets, and athletes at sporting events (🖽 39).	0FF/0/0/0/0	OFF
CONTINUOUS	Choose a continuous shooting mode option (🗐 20).	5/1/5/A/A/Q	<u>p</u>
	Choose whether the camera automatically detects and		
ACE DETECTION	sets focus and exposure for human portrait subjects (🗐 30).	ON/OFF	OFF
D PHOTOMETRY	Choose how the camera meters exposure (🕮 74).	0/[•]/[]	Ø

Menus

Menu item	Description	Options	Default	
AF MODE	Choose how the camera selects a focus area (💷 75).	era selects a focus area (♀ 75).		
PANORAMA MODE	Choose how panoramas are framed (💷 25).	ow panoramas are framed (🕮 25). 🗖 🗖 / 🗖		
MOVIE AF MODE	This option controls how the camera selects the focus area for movies (買 76).			
HI MOVIE MODE	Choose a frame size for movies (🕮 54).	ID 1280×720/ IO 640×480/ ID 1280×240 ID 1280×		
🗃 AE BKT EV STEPS	■ AE BKT EV STEPS Choose the size of the bracketing increment when 🖷 is selected in continuous shooting mode (🕮 76).		±1/3 <b>EV</b>	
🚰 FLASH	Adjust flash brightness (🗐 76).	-²⁄3 EV - +²⁄3 EV in steps of 1⁄3 EV	0	

## SO ISO

Control the camera's sensitivity to light. Higher values can be used to reduce blur when lighting is poor; note, however, that mottling may appear in pictures taken at high sensitivities. If **AUTO, AUTO (800)**, or **AUTO (400)** is selected, the camera will adjust sensitivity automatically in response to shooting conditions. The maximum values that will be selected by the camera at settings of **AUTO (800)** and **AUTO (400)** are 800 and 400 respectively. Settings other than **AUTO** are shown by an icon in the display.

#### 👉 Note

Sensitivity is not reset when the camera is turned off or another shooting mode is selected.

# IMAGE SIZE

Choose the size and aspect ratio at which still pictures are recorded. Large pictures can be printed at large sizes with no drop in quality; small pictures require less memory, allowing more pictures to be recorded.

The number of pictures that can be taken at the selected setting is shown in the display (🖽 4).

#### Size Versus Aspect Ratio Size

Option Prints at sizes up to	
	34×25 cm (13.5×10 in.)
	24×18 cm (9.5×7 in.)
S	17 × 13 cm (7 × 5 in.)

#### Aspect ratio

**4:3**: Pictures have the same proportions as the camera display.

**3:2**: Pictures have the same proportions as a frame of 35 mm film.

**16:9**: Suited for display on High Definition (HD) devices.

1:1: Pictures are square.

## 🗲 Note

Image size is not reset when the camera is turned off or another shooting mode is selected.

# 🔛 IMAGE QUALITY

Choose how much image files are compressed. Select **FINE** (low compression) for higher image quality, **NORMAL** (high compression) to increase the number of pictures that can be stored.

# **FINEPIX COLOR**

Enhance contrast and color saturation or take pictures in black and white.

Option	Description	
STANDARD	Standard contrast and saturation.	
STANDARD	Recommended in most situations.	
	Vivid contrast and color. Choose	
CHROME	Vivid contrast and color. Choose for vivid shots of flowers or en-	
	hanced greens and blues in land-	
	scapes.	
B&W	Take pictures in black and white.	

Settings other than **STANDARD** are shown by an icon in the display.

#### 👉 Notes

- **FINEPIX COLOR** is not reset when the camera is turned off or another shooting mode is selected.
- The effects of **CHROME** vary from scene to scene and may be difficult to discern with some subjects. Depending on the subject, the effects of **CHROME** may not be visible in the display.

# **WB WHITE BALANCE**

For natural colors, choose a setting that matches the light source.

Option	Description	
AUTO	White balance adjusted automatically.	
D	Measure a value for white balance.	
*	For subjects in direct sunlight.	
*	For subjects in the shade.	
₩í	Use under "daylight" fluorescent lights.	
) デ 2	Use under "warm white" fluorescent lights.	
兴	Use under "cool white" fluorescent lights.	
-Å-	Use under incandescent lighting.	

If **AUTO** does not produce the desired results (for example, when taking close-ups), select  $\square$  and measure a value for white balance or choose the option that matches the light source.

### 👉 Notes

- At settings other than 📮, auto white balance is used with the flash. Lower the flash (🗐 35) to take pictures at other settings.
- Results vary with shooting conditions. Play pictures back after shooting to check colors in the monitor.

## 🔳 📮: Custom White Balance

Choose 🖵 to adjust white balance for unusual lighting conditions. White balance measurement options will be displayed; frame a white object so that it fills the monitor and press the shutter button all the way down to measure white balance.

If "COMPLETED!" is displayed, press MENU/OK to set white balance to the measured value. This value can be reselected by pressing MENU/OK when custom white balance options are displayed.

**If "UNDER" is displayed**, raise exposure compensation (🗐 42) and try again.

If "OVER" is displayed, lower exposure compensation and try again.

#### ы Тір

To give a deliberate color cast to your photographs, measure a value for custom white balance using a colored instead of a white object.

# PHOTOMETRY

Choose how the camera meters exposure when Intelligent Face Detection is off.

- [I] MULTI: Automatic scene recognition is used to adjust exposure for a wide range of shooting conditions.
- [•] SPOT: The camera meters lighting conditions at the center of the frame. Recommended when the background is much brighter or darker than the main subject. Can be used with focus lock (💷 32) to meter off-center subjects.
- [] AVERAGE: Exposure is set to the average for the entire frame. Provides consistent exposure across multiple shots with the same lighting, and is particularly effective for landscapes and portraits of subjects dressed in black or white.

# AF MODE

This option controls how the camera selects the focus area when Intelligent Face Detection is off (🗐 30). Regardless of the option selected, the camera will focus on the subject in the center of the monitor when macro mode is on (🗐 34).

- CENTER: The camera focuses on the subject in the center of the frame. This option can be used with focus lock (
  S2).
- MULTI: When the shutter button is pressed halfway, the camera detects high-contrast subjects near the center of the frame and selects the focus area automatically (if the focus frame is not displayed, select 
   CENTER and use focus lock; 32).








Focus frame

• AREA: The focus position can be chosen manually by pressing the selector up, down, left, or right and pressing **MENU/OK** when the focus



brackets are in the desired position. Choose for precise focus when the camera is mounted on a tripod. Note that exposure is set for the subject in the center of the frame; to meter an off-center subject, use AF/AE lock (🗐 32).

- **CONTINUOUS**: The camera continually adjusts focus to reflect changes in the distance to the subject even when the shutter button is not pressed (note that this increases the drain on the battery).
- E. TRACKING: Position the subject in the center focus area and press the selector left to select tracking. Focus will track the subject as it moves through the frame.



## MOVIE AF MODE

This option controls how the camera selects the focus area for movies.

Option	Description	
<b>CENTER</b>	The camera focuses on the subject	
	in the center of the frame.	
	The camera continuously adjusts focus to reflect changes in the dis-	
	focus to reflect changes in the dis-	
	tance to subjects near the center of	
	the frame.	

#### 👉 Note

Note that in 🔲 mode, the camera focuses continuously, increasing the drain on the battery, and that the sound of the camera focusing may be audible.

# 🖪 AE BKT EV STEPS

Choose the size of the exposure bracketing increment used when **T** (AE bracketing) is selected in continuous shooting mode ( $\blacksquare$  21). Choose from increments of  $\pm \frac{1}{3}$  EV,  $\pm \frac{2}{3}$  EV, and  $\pm 1$  EV.

# 🚰 FLASH

Adjust flash brightness. Choose from values between +2/3 EV and -2/3 EV. The default setting is  $\pm 0$ . Note that the desired results may not be achieved depending on shooting conditions and the distance to the subject.

# <u>Using the Playback Menu</u>

- **1** Press the **b** button to enter playback mode.
- **2** Press **MENU/OK** to display the playback menu.



►

**3** Press the selector up or down to highlight the desired menu item.



tions for the highlighted item.5 Press the selector up or down to

highlight the desired option.

A Press the selector right to display op-

6 Press **MENU/OK** to select the highlighted option.



# Playback Menu Options

The following options are available:

Option	Description
IMAGE SEARCH	Search for pictures by date, subject, scene, file type, or rating (💷 51).
i ERASE	Delete all or selected pictures (💷 52).
MARK FOR UPLOAD	Select pictures for upload to YouTube, Facebook or MyFinePix.com using My- FinePix Studio (Windows only) (🕮 78).
SLIDE SHOW	View pictures in a slide show (🕮 80).
RED EYE REMOVAL	Create copies with reduced red eye (🖽 81).
■ PROTECT	Protect pictures from accidental dele- tion (🖽 82).
CROP	Create cropped copies of pictures (🖽 83).
RESIZE	Create small copies of pictures (🗐 84).
IMAGE ROTATE	Rotate pictures (💷 85).
🗳 PHOTOBOOK ASSIST	Create books from your favorite photos (🗐 49).
PRINT ORDER (DPOF)	Select pictures for printing on DPOF- and PictBridge-compatible devices (🕮 60).
🔲 DISP. ASPECT	Choose how High Definition (HD) de- vices display pictures (🗐 86).

# MARK FOR UPLOAD TO

You can select images and movies to be queued for upload to YouTube, Facebook and MyFinePix.com. Select 🚳 MARK FOR UPLOAD TO in the playback menu.

# Add/Remove Items in the Upload Queue

Select an upload destination.

# 2 Press MENU/OK.

- **3** Select items to be added to, or removed from, the upload queue.
- 4 Press MENU/OK to confirm.
  - Items not in the upload queue will be added to the queue when you select them and press **MENU/OK**.
  - Items in the upload queue will be removed from the queue when you select them and press **MENU/OK**.

5 Repeat steps 3 and 4 as necessary and add or remove items.When finished, press DISP/BACK to save the settings.

#### DISP BACK

#### 🔊 Tips

- YouTube, Facebook or MyFinePix.com is displayed to indicate items queued for upload.
- Only movies can be selected for upload to YouTube.
- Only photos can be selected for upload to MyFinePix. com.
- During playback, selected pictures are indicated by
   YouTube, Facebook or MyFinePix.com icons.



# Removing All Items From the Upload Queue

You can remove all items from the upload queue.

# Select **RESET ALL**.

The screen for removing all items from the upload queue is displayed.





2 Select OK.



# 3 Press MENU/OK.


All items are removed from the up-load queue.

## 👉 Note

If there are many items in the upload queue when you select to remove all items from the queue, it may take some time to remove them. To cancel, press **DISP/BACK**.

# Upload Items

Items added to the upload queue using the camera can be easily uploaded from a computer by using the MyFinePix Studio. Install MyFinePix Studio (E 63).



## 👉 Note

This feature is available only when using a computer running Windows.

## SLIDE SHOW

View pictures in an automated slide show. Choose the type of show and press **MENU/OK** to start. Press **DISP/BACK** at any time during the show to view on-screen help. When a movie is displayed, movie play-back will begin automatically, and the slide show will continue when the movie ends. The show can be ended at any time by pressing **MENU/OK**.

Option	Displayed in
NORMAL	Press selector left or right to go back or skip ahead one frame. Select FADE-IN for fade transitions between
FADE-IN	frames.
NORMAL 😫	As above, except that camera automatically zooms in on faces selected with Intelligent Face detection.
FADE-IN 😫	ירא מסטיב, באנבףו נוזמו כמוזיבים מענטוזומווכמוץ בטטוזא זוז טודומנפא צפופנופט שונו דוונפוווקפוונ דמנפ טפנפננוטדו.

#### 👉 Note

The camera will not turn off automatically while a slide show is in progress.

## RED EYE REMOVAL

If the current picture is marked with a 😰 icon to indicate that it was taken with Intelligent Face Detection, this option can be used to remove red-eye. The camera will analyze the image; if red-eye is detected, the image will be processed to create a copy with reduced red-eye.



#### 👉 Notes

- Red eye may not be removed if the camera is unable to detect a face or the face is in profile. Results may differ depending on the scene. Red eye can not be removed from pictures that have already been processed using red-eye removal or pictures created with other devices.
- The amount of time needed to process the image varies with the number of faces detected.
- Copies created with RED EYE REMOVAL are indicated by a right icon during playback.

# ■ PROTECT

Protect pictures from accidental deletion. The following options are available.

#### FRAME

Protect selected pictures.

**1** Press the selector left or right to display the desired picture.



Sen PROTECT OK?			PROT
•	۲		
			VEC
OKYES BACK CANCEL		ОК	

Picture not protected

Protected picture

CT OK?

2 Press **MENU/OK** to protect the picture. If the picture is already protected, pressing **MENU/OK** will remove protection from the image.



# **3** Repeat steps 1–2 to protect additional images. Press **DISP/BACK** to exit when the operation is complete.



# SET ALL

Press **MENU/OK** to protect all pictures, or press **DISP/BACK** to exit without changing picture status.

HILE			
	PACK	BACKOCANCEL	710 <sup>7</sup> 8 c a Nori

## RESET ALL

Press **MENU/OK** to remove protection from all pictures, or press **DISP/BACK** to exit without changing picture status.

পদ RESET ALL OK?
IT MAY TAKE A WHILE
OK YES BACK CANCEL

If the number of pictures affected is very large, a message will be displayed while the operation is in progress. Press **DISP/BACK** to exit before the operation is complete.

## **\** Caution

Protected pictures will be deleted when the memory card is formatted (  $\textcircled{\sc l}$  91).

# CROP

To create a cropped copy of a picture, play the picture back and select 🖾 **CROP** in the playback menu (🗐 77).

1 Use the zoom control to zoom in and out and use the selector to scroll the picture until the desired portion is displayed (to exit to singleframe playback without creating a cropped copy, press **DISP/BACK**).

Zoom indicator



Navigation window shows portion of image currently displayed in monitor

If the size of the final copy will be **MO**, **YES** will be displayed in yellow.

#### 🗟 Tip: Intelligent Face Detection

If the picture was shot with Intelligent Face Detection (■ 30), ull be displayed in the monitor. Press the button to zoom in on the selected face. **2** Press **MENU/OK** to view the copy size. Larger crops produce larger copies.



**3** Press **MENU/OK** to save the cropped copy to a separate file.

#### 👉 Note

Pictures taken with other cameras can not be cropped.

## RESIZE

To create a small copy of a picture, play the picture back and select **E RESIZE** in the playback menu (1) 77).

**1** Highlight a size and press **MENU/OK** to display a confirmation dialog.



**2** Press **MENU/OK** to copy the picture at the selected size.



# IMAGE ROTATE

By default, pictures taken in tall orientation are displayed in wide orientation. Use this option to display pictures in the correct orientation in the monitor. It has no effect on pictures displayed on a computer or other device.

#### 👉 Notes

- Protected pictures can not be rotated. Remove protection before rotating pictures (🗐 82).
- The camera may not be able to rotate pictures created with other devices.

To rotate a picture, play the picture back and select **2 IMAGE ROTATE** in the playback menu (1) 77).

Press the selector down to rotate the picture 90° clockwise, up to rotate the picture 90° counterclockwise.






2 Press **MENU/OK** to confirm the operation (to exit without rotating the picture, press **DISP/BACK**).

The next time the picture is played back, it will automatically be rotated.

## DISP. ASPECT

Choose how High Definition (HD) devices display pictures with an aspect ratio of 4 : 3 (this option is available only when an HDMI cable is connected). Select **16:9** to display the image so that it fills the screen with its top and bottom cropped out, **4:3** to display the entire image with black bands at either side.



#### 👉 Note

Photographs with an aspect ratio of 16 : 9 are displayed full screen, those with an aspect ratio of 3 : 2 in a black frame.

# <u>Using the Setup Menu</u>

Display the setup menu.1.1 Press MENU/OK to display the menu for the current mode.



**1.2** Press the selector left to high-light a left tab.



 1.3 Press the selector up or down to select set. The setup menu appears.

SET-UP	1/5
C DATE/TIME C DATE/TIME C DATE/TIME C TIME DIFFERENCE C TIME DIFFERENCE C TIME DIFFERENCE C TIME SILENT MODE C TIME SILENT MODE C TIME FORMAT	② ENGLISH OFF
BACK EXIT	

# **2** Adjust settings.

**2.1** Press the selector right to activate the setup menu.



**2.2**Press the selector up or down to highlight a menu item.



**2.3** Press the selector right to display options for the highlighted item.



**2.4**Press the selector up or down to highlight an option.



**2.5** Press **MENU/OK** to select the highlighted option.



DISP BACK

2.6 Press **DISP/BACK** to exit from the menu.



# **Setup Menu Options**

Menu item	Description	Options	Default
DATE/TIME	Set the camera clock (🕮 13).	—	_
TIME DIFFERENCE	IME DIFFERENCE Set the clock to local time (🕮 90).		企
®ฎ 言語/LANG.	LANG. Choose a language (🕮 13).		—
SILENT MODE	Disables the AF-assist illuminator (except for the <b>4</b> shooting mode), operation sounds, shutter sound, and movie playback sound.	ON/OFF	OFF
C RESET	Reset all settings except C DATE/TIME, TIME DIFFERENCE, BACKGROUND COLOR, and D BATTERY TYPE to default values. A confirmation dialog will be displayed, press the selector up or down to highlight OK and press MENU/OK.	_	
ER FORMAT	Format memory cards (🕮 91).	_	
📧 IMAGE DISP.	GE DISP.         Choose how long pictures are displayed after shooting (🗐 91).         1.5 SEC/0.5 ZOOM/0		0.5 SEC
🖾 FRAME NO.	Choose how files are named (🕮 92).	CONT. / RENEW	CONT.
OPERATION VOL.	Adjust the volume of camera controls. Adjust the volume of the shutter sound.	• <b>4</b> •1) (high) / • <b>4</b> •1 (mid) / • <b>4</b> • (low) / • <b>40FF</b> (mute)	
SHUTTER SOUND	Choose the sound made by the shutter.	♪1/♪2 ♪1	

Menu item	Description	Options	Default
PLAYBACK VOLUME	Adjust the volume for movie playback (💷 92).	—	7
🔯 LCD BRIGHTNESS	Control the brightness of the display (💷 92).	<b>-5</b> -+5	0
LCD POWER SAVE	<b>LCD POWER SAVE</b> Choose whether to save power to increase battery life (🕮 92).		SAVE OFF
AUTO POWER OFF	Choose the auto power off delay (💷 93).	2 MIN / 5 MIN / OFF 2 MIN	
IS MODE	Enable image stabilization during shooting ((@), CONTINUOUS) or only when the shutter button is pressed halfway ((@) <sub>2</sub> SHOOTING ONLY) (E 16).	( <b>a</b> ) <sub>1</sub> / ( <b>a</b> ) <sub>2</sub> / OFF	(4)1
RED EYE REMOVAL	Remove "red-eye" effects caused by the flash.	ON/OFF	ON
INTELLIGENT DIGITAL ZOOM	Enable or disable intelligent digital zoom (🕮 93).	ON/OFF	OFF
🖏 MOVIE ZOOM TYPE	Choose the zoom type when recording movies (🕮 54).	Di / Opt	Opt
AF ILLUMINATOR	Turn the AF-assist illuminator on or off (🕮 33).	ON/OFF	ON
💿 SAVE ORG IMAGE	Choose whether to save unprocessed copies of pictures taken using red-eye removal.	ON/OFF	OFF
AUTOROTATE PB	Choose <b>ON</b> to automatically rotate "tall" (portrait-orientation) pictures during playback.	ON/OFF	ON
BACKGROUND COLOR	Choose a color scheme.	_	
🖾 BATTERY TYPE	Specify the type of battery used in the camera (🕮 8).	da/dn/dl	(A)
DISCHARGE	Discharge rechargeable Ni-MH batteries (🕮 94).		
DATE DATE STAMP	Choose whether to add shooting date and time to the pic- tures.	31 + @ / 31 / OFF	OFF

# TIME DIFFERENCE

When travelling, use this option to switch the camera clock instantly from your home time zone to the local time at your destination.

# **1** Specify the difference between local time and your home time zone.

1.1 Press the selector up or down to highlight + LOCAL.

**1.2** Press the selector right to display the time difference.



- **1.3** Press the selector left or right to highlight **+**, **-**, hours, or minutes; press up or down to edit.
- **1.4** Press **MENU/OK** when settings are complete.



# **2** Switch between local time and your home time zone.

- **LOCAL**: Switch to local time. If this option is selected, and the time and date will be displayed in yellow for three seconds each time the camera is turned on.



After changing time zones, check that the date and time are correct.

## FORMAT

Format a memory card. Highlight **OK** and press **MENU/OK** to begin formatting.

#### **\** Cautions

- All data—including protected pictures—will be deleted. Be sure important files have been copied to a computer or other storage device.
- Do not open the battery cover during formatting.

# IMAGE DISP.

Choose an option other than **OFF** to display pictures in the monitor after shooting. Pictures can be displayed for 1.5 s (**1.5 SEC**), 0.5 s (**0.5 SEC**), or until the **MENU/OK** button is pressed (**ZOOM (CONTINUOUS)**). If **ZOOM (CONTINUOUS)** is selected, photos can be zoomed in to check focus and other fine details (see page 45). Colors may differ slightly from those in the final image.

When the picture is zoomed in, the selector can be used to view areas of the image not currently visible in the display.


When the picture was taken with P FACE DE-TECTION turned on, detected face is zoomed. When more than one face was detected, you can move to the next face by pressing  $\blacktriangledown$ .

**ZOOM (CONTINUOUS)** is disabled in the following case:

• 💁 / 🐠 / 📟 is selected in the shooting mode.

## 🖾 FRAME NO.

New pictures are stored in image files named using a four-digit file number assigned by adding one to the last file number used. The file number is displayed dur-



ing playback as shown at right. **PRAME NO.** controls whether file numbering is reset to 0001 when a new memory card is inserted or the current memory card is formatted.

- **CONTINUOUS**: Numbering continues from the last file number used or the first available file number, whichever is higher. Choose this option to reduce the number of pictures with duplicate file names.
- **RENEW**: Numbering is reset to 0001 after formatting or when a new memory card is inserted.

#### 👉 Notes

- If the frame number reaches 999-9999, the shutter release will be disabled (🕮 108).
- Selecting  **RESET** (**■** 88) resets **■ FRAME NO.** to **CONTINUOUS** but does not reset frame numbering.
- Frame numbers for pictures taken with other cameras may differ.

# PLAYBACK VOLUME

Press the selector up or down to choose volume for movie playback and press **MENU/OK** to select.

## LCD BRIGHTNESS

Press the selector up or down to choose display brightness and press **MENU/OK** to select.

## LCD POWER SAVE

Choose whether to save power to increase battery life. This option does not take effect during playback or recording movies.

Option	Description
	The display dims to save power if no operations are performed for a
	no operations are performed for a
🖾 POWER SAVE ON	few seconds. Normal brightness
	can be restored by pressing the
	few seconds. Normal brightness can be restored by pressing the shutter button halfway.
Mage of the second seco	Automatic dimming off.

## AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually. Note that regardless of the option selected, the camera will not turn off automatically when connected to a printer (🗐 57) or computer (🗐 66) or when a slide show is in progress (🗐 80).

#### 🔄 Tip: Reactivating the Camera


To reactivate the camera after it has turned off automatically, use the **ON/OFF** button or press the  $\blacktriangleright$  button for about a second ( $\blacksquare$  12).

# INTELLIGENT DIGITAL ZOOM

If ON is selected, selecting T at the maximum optical zoom position triggers intelligent digital zoom, further magnifying the image while processing it for sharp, high-resolution results.

#### 🗲 Notes

- Intelligent digital zoom may end when another mode is selected.
- Intelligent digital zoom may sometimes produce lower quality images than optical zoom.
- The time needed to record images increases.
- Intelligent digital zoom is not available in continuous mode or during movie recording.



# DISCHARGE (Ni-MH Batteries Only)

The capacity of rechargeable Ni-MH batteries may be temporarily reduced when new, after long periods of disuse, or if they are repeatedly recharged before being fully discharged. Capacity can be increased by repeatedly discharging the batteries using the **DISCHARGE** option and recharging them in a battery charger (sold separately). Do not use **DISCHARGE** with non-rechargeable batteries, and note that the batteries will not discharge if the camera is powered by an optional AC power adapter and DC coupler.

 Selecting DISCHARGE displays a confirmation dialog. Press MENU/ OK.

**7** Select **OK**.



**3** Press **MENU/OK** to begin discharging the batteries. When the batteries are fully discharged, the battery level indicator will blink red and the camera will turn off. To cancel the process before the batteries are fully discharged, press **DISP/BACK**.



## DATE DATE STAMP


To add shooting date and time, choose  $\overline{\mathfrak{I}} + \mathcal{O}$ . To add only shooting date, choose  $\overline{\mathfrak{I}}$ . When **OFF** is selected, no information will be added to the pictures.

#### 👉 Notes

- Added shooting date and time can not be deleted from the pictures. To take pictures without date and time, select **OFF** for **ME DATE STAMP**.
- When the camera clock is not set, setting dialog will be displayed. Set the date and time (💷 13).
- When using **DATE STAMP**, selecting **WITHOUT DATE** for **PRINT ORDER (DPOF)** is recommended (**E** 60).
- Date and time can not be added to the movies and the panoramas.

# **Optional Accessories**

The camera supports a wide range of accessories from FUJIFILM and other manufacturers.



\*1 Available separately.

**Technical Notes** 

# **Accessories from FUJIFILM**

The following optional accessories are available from FUJIFILM. For the latest information on the accessories available in your region, check with your local FUJIFILM representative or visit *http://www.fujifilm.com/products/digital\_cameras/index.html*.

AC power adapter		Use for extended playback or when copying pictures to a computer (shape of adapter and plug vary with region of sale).	
DC coupler	CP-04	Connect the AC-5VX AC power adapter to the camera.	

# **Caring for the Camera**

To ensure continued enjoyment of the product, observe the following precautions.

#### Storage and Use

If the camera will not be used for an extended period, remove the battery and memory card. Do not store or use the camera in locations that are:

- exposed to rain, steam, or smoke
- very humid or extremely dusty
- exposed to direct sunlight or very high temperatures, such as in a closed vehicle on a sunny day
- extremely cold
- subject to strong vibration
- exposed to strong magnetic fields, such as near a broadcasting antenna, power line, radar emitter, motor, transformer, or magnet
- in contact with volatile chemicals such as pesticides
- next to rubber or vinyl products

#### Water and Sand

Exposure to water and sand can also damage the camera and its internal circuitry and mechanisms. When using the camera at the beach or seaside, avoid exposing the camera to water or sand. Do not place the camera on a wet surface.

#### Condensation

Sudden increases in temperature, such as occur when entering a heated building on a cold day, can cause condensation inside the camera. If this occurs, turn the camera off and wait an hour before turning it on again. If condensation forms on the memory card, remove the card and wait for the condensation to dissipate.

#### Cleaning

Use a blower to remove dust from the lens and monitor, then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of FUJIFILM lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied. Care should be taken to avoid scratching the lens or monitor. The camera body can be cleaned with a soft, dry cloth. Do not use alcohol, thinner, or other volatile chemicals.

## Traveling

Keep the camera in your carry-on baggage. Checked baggage may suffer violent shocks that could damage the camera.

# Troubleshooting

#### **Power and Battery**

	Problem	Possible cause	Solution	Page
		The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	7
		The batteries are not in the correct orienta-	Re-insert the batteries in the correct orienta-	7
		tion.	tion.	/
	The camera does	The battery-chamber cover is not latched.	Latch the battery-chamber cover.	8
	not turn on.	The AC power adapter and DC coupler are	Make sure that the AC power adapter and DC	
		not connected properly.	coupler are properly connected.	
			After inserting the batteries or connecting the	
			AC power adapter/DC coupler, wait a few mo-	-
		AC power adapter/DC coupler unplugged.	ments before turning the camera on.	
			Warm the batteries by placing them in a pocket	
		The batteries are cold.	or other warm place and re-insert them in the	iv
Power			camera immediately before taking a picture.	
supply		There is dirt on the battery terminals.	Clean the terminals with a soft, dry cloth.	—
		The camera is in <b>SRAUTO</b> mode.	Select another shooting mode.	20
	The batteries run		Discharge Ni-MH batteries using the 📼 DIS-	
	down quickly.	· · · · · · · · · · · · · · · · · · ·	CHARGE option and recharge them in a bat-	
		for an extended period, or have been re-	tery charger (sold separately). If the batteries	94
		charged without first being fully discharged	do not hold a charge after repeated discharg-	
		(rechargeable Ni-MH batteries only).	ing and recharging, they have reached the end	
			of their service life and must be replaced.	
		CONTINUOUS is selected for TAF MODE.	Select a different focusing option.	75
	The camera turns	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	7
	off suddenly.	The AC power adapter or DC coupler has	Make sure that the AC power adapter and DC	
	lon succerny.	been disconnected.	coupler are properly connected.	

#### **Menus and Displays**

Problem	Possible cause	Solution	Page
Menus and displays are	English is not selected for the 💿 言語/LANG.		13, 88
not in English.	option in the setup menu.	Select LINGLISH.	15,00

#### Shooting

	Problem	Possible cause	Solution	Page
	N	Memory is full.	Insert a new memory card or delete pictures.	9, 52
	No picture is taken when	Memory is not formatted.	Format the memory card.	91
	the shutter	There is dirt on the memory card contacts.	Clean the contacts with a soft, dry cloth.	—
Taking	button is	The memory card is damaged.	Insert a new memory card.	9
pictures	pressed.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	7
pictures		The camera has turned off automatically.	Turn the camera on.	12
	The monitor goes dark after shooting.	The flash has fired.	The monitor may darken while the flash charges. Wait for the flash to charge.	35
	The camera	The subject is close to the camera.	Select macro mode.	34
Focus	does not	The subject is far away from the camera.	Cancel macro mode.	54
	focus.	The subject is not suited to autofocus.	Use focus lock.	32

	Problem	Possible cause	Solution	Page
	mot available.	Intelligent Face Detection is not available in the current shooting mode.		20
	No face is detected.	The subject's face is obscured by sunglasses, a hat, long hair, or other objects.	Remove the obstructions.	30
Intelligent Face		The subject's face occupies only a small area of the frame.	Change the composition so that the subject's face occupies a larger area of the frame.	
Detection		The subject's head is tilted or horizontal.	Ask the subject to hold their head straight.	]
		The camera is tilted.	Hold the camera straight.	16
		The subject's face is poorly lit.	Shoot in bright light.	
	selected.	The selected subject is closer to the center of the frame than the main subject.	off and frame the picture using focus lock.	30, 32
Close-ups	Macro mode is not available.	Macro mode is not available in the current shooting mode.	Choose a different shooting mode.	20, 34

	Problem	Possible cause	Solution	Page
		The flash is lowered.	Raise the flash.	35
		The flash is charging.	Wait for the flash to charge.	35
	The flash does	The flash is not available in the current shoot- ing mode.	Choose a different shooting mode.	20
	not me.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	7
Flash		The camera is in super macro or continuous shooting mode.	Turn super macro off and use a shooting mode other than continuous shooting mode.	34, 20
		The desired flash mode is not available in the current shooting mode.	Choose a different shooting mode.	20
	The flash does	The subject is not in range of the flash.	Position the subject in range of the flash.	114
		The flash window is obstructed.	Hold the camera correctly.	16
	the subject.	Fast shutter speed selected.	Choose a slower shutter speed.	28, 29

	Problem	Possible cause	Solution	Page
		The lens is dirty.	Clean the lens.	98
	Pictures are	The lens is blocked.	Keep objects away from the lens.	16
	blurred.	<b>!AF</b> is displayed during shooting and the fo- cus frame is displayed in red.	Check focus before shooting.	107
		🕼 is displayed during shooting.	Use the flash or a tripod.	35
	Pictures are mottled.	The ambient temperature is high and the sub- ject is poorly lit.	This is normal and does not indicate a mal- function.	_
Problem images	Vertical lines appear in pictures.	The camera has been used continuously at high temperatures.	Turn the camera off and wait for it to cool down.	_
	1	The sun or another bright object was in the frame.	White or purple vertical lines may appear when a very bright object is framed in the display. This is normal and does not indicate a malfunction. Smear is not recorded in photo- graphs but may appear in movies. If possible, avoid shooting movies with bright objects in or close to the frame.	_
Recording	Pictures are not recorded.	Power was interrupted during shooting.	Turn the camera off before connecting the AC power adapter/DC coupler. Leaving the camera on can result in corrupted files or damage to the memory card.	
Continuous shooting mode	Only one pic- ture is taken.	The self timer is on and an option 🚡 and ஆ are selected in continuous shooting mode.	Turn the self-timer off.	37

# Troubleshooting

#### Playback

	Problem	Possible cause	Solution	Page
	Pictures are grainy.	The pictures were taken with a different make or model of camera.	—	—
FICTURES	Playback zoom unavailable.	The picture has been resized or cropped to 640 or is from another make or model of camera.	—	45
	No sound in	The camera is in silent mode.	Turn silent mode off.	88
Audio	movie play- back.	Playback volume is too low.	Adjust playback volume.	92
Auulo		The microphone was obstructed.	Hold the camera correctly during recording.	53
		The speaker is obstructed.	Hold the camera correctly during playback.	55
	Inictures not	Some of the pictures selected for deletion are protected.	Remove protection using the device with which it was originally applied.	82
	File number- ing is unex- pectedly reset.	The battery-chamber cover was opened while the camera was on.	Turn the camera off before opening the bat- tery-chamber cover.	12

#### Connections

	Problem	Possible cause	Solution	Page
	Monitor is off.	The camera is connected to a TV.	View pictures on the TV.	56
TV	No picture or	The camera is not properly connected.	Connect the camera correctly.	56
ΙV	sound.	Input on the television is set to "TV".	Set the TV input correctly.	—
	sound.	The volume on the television is too low.	Adjust the volume.	
Computer	The com- puter does not recognize the camera.	The camera is not properly connected.	Connect the camera correctly.	66
	Pictures can	The camera is not properly connected.	Connect the camera correctly.	57
	not be printed.	The printer is off.	Turn the printer on.	
PictBridge	Only one copy is printed. The date is not printed.	The printer is not PictBridge-compatible.	_	_

#### Miscellaneous

Problem	Possible cause	Solution	Page
Nothing happens when the shutter but-	Temporary camera malfunction.	Remove and reinsert the batteries or discon- nect and reconnect the AC power adapter/ DC coupler.	7
ton is pressed.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	7
The camera does not function as expected.	Temporary camera malfunction.	Remove and reinsert the batteries or discon- nect and reconnect the AC power adapter/ DC coupler. If the problem persists, contact your FUJIFILM dealer.	7
l want to use an AC power adapter and DC coupler overseas.	Check the label on the AC power adapter.	The AC power adapter can be used with volt- ages of 100–240V and power frequency of 50/60Hz. However, power outlets differ de- pending on the regions. Consult your travel agent for information on plug adapters.	_
Date and time added by <b>DATE STAMP</b> are not correct.	The camera clock is not correctly set.	Reset the date and time.	13
Date and time are added to the pictures.	ন্ত্রা + 🕑 or হ্রা is selected for 🏧 DATE STAMP option.	Added shooting date and time can not be deleted from the pictures. To take pic- tures without date and time, select <b>OFF</b> for <b>DATE STAMP</b> .	95

The following warnings are displayed in the monitor:

Warning	Description	Solution
∎∎ (red)	Batteries are low.	Insert fresh or fully-charged spare batteries.
🗖 (blinks red)	Batteries are exhausted.	Insert nesh of fully-charged spare batteries.
ļo	Slow shutter speed. Picture may be blurred.	Use the flash or mount the camera on a tripod.
<b>!AF</b> (displayed in red with red focus frame)	The camera can not focus.	<ul> <li>Use focus lock to focus on another subject at the same distance, then recompose the picture (= 32).</li> <li>Use macro mode to focus when taking close-ups.</li> </ul>
Aperture or shutter speed shown in red	The subject is too bright or too dark. The pic- ture will be over- or under-exposed.	If the subject is dark, use the flash.
FOCUS ERROR LENS CONTROL ERROR	Camera malfunction.	Turn the camera off and then on again, taking care
	TURN THE CAMERA OFF, REMOVE LENS CAP OR OBSTRUCTION AND TURN THE CAMERA ON	to touch the lens. If the message persists, contact a FUJIFILM dealer.
	The memory card is not formatted or the memory card was formatted in a computer or other device.	Format the memory card using the 🖼 FORMAT op- tion in the camera setup menu (🕮 91).
CARD NOT INITIALIZED	The memory card contacts require cleaning.	Clean the contacts with a soft, dry cloth. If the mes- sage is repeated, format the memory card (E 91). If the message persists, replace the memory card.
	Camera malfunction.	Contact a FUJIFILM dealer.
PROTECTED CARD	The memory card is locked.	Unlock the memory card (🕮 9).

Warning	Description	Solution
BUSY	The memory card is incorrectly formatted.	Use the camera to format the memory card (🕮 91).
	The memory card is not formatted for use in the camera.	Format the memory card (💷 91).
CARD ERROR	The memory card contacts require cleaning or the memory card is damaged.	Clean the contacts with a soft, dry cloth. If the mes- sage is repeated, format the memory card (🕮 91). If the message persists, replace the memory card.
	Incompatible memory card.	Use a compatible memory card.
	Camera malfunction.	Contact a FUJIFILM dealer.
D MEMORY FULL	The memory card is full; pictures can not be recorded.	Delete pictures or insert a memory card with more free space.
WRITE ERROR	Memory card error or connection error.	Re-insert the memory card or turn the camera off and then on again. If the message persists, contact a FUJIFILM dealer.
WKITE EKKUK	Not enough memory remaining to record ad- ditional pictures.	Delete pictures or insert a memory card with more free space.
	The memory card is not formatted.	Format the memory card (🕮 91).
	The file is corrupt or was not created with the camera.	The file can not be played back.
READ ERROR	The memory card contacts require cleaning.	Clean the contacts with a soft, dry cloth. If the mes- sage is repeated, format the memory card (🗐 91). If the message persists, replace the memory card.
	Camera malfunction.	Contact a FUJIFILM dealer.
FRAME NO. FULL	The camera has run out of frame numbers (cur- rent frame number is 999-9999).	Format the memory card and select <b>RENEW</b> for the <b>Important Problem</b> FRAME NO. option in the <b>Set-UP</b> menu. Take a picture to reset frame numbering to 100-0001, then return to the <b>Important FRAME NO.</b> menu and select <b>CON-</b> <b>TINUOUS</b> .

Warning	Description	Solution
TOO MANY FRAMES	An attempt was made to search more than 5,000 images.	The maximum number of images on which searches can be performed is 5,000.
PROTECTED FRAME	An attempt was made to delete or rotate a pro- tected picture.	Remove protection and try again (💷 82).
GAO CAN NOT CROP	An attempt was made to crop a 🜆 picture.	
CAN NOT CROP	The picture selected for cropping is damaged or was not created with the camera.	These pictures can not be cropped.
M CANNOT EXECUTE	An attempt was made to resize a 🔳 picture.	An attempt was made to create a resized copy at a size
S CANNOT EXECUTE	An attempt was made to resize a 🛐 picture.	equal to or larger than the original. Choose a smaller
640 CANNOT EXECUTE	An attempt was made to resize a 👪 picture.	size.
DPOF FILE ERROR	The DPOF print order on the current memory card contains more than 999 images.	The maximum number of images to which DPOF print order can be tagged is 999 per memory card.
CAN NOT SET DPOF	The picture can not be printed using DPOF.	_
😫 CAN NOT SET DPOF	Movies can not be printed using DPOF.	_
CAN NOT ROTATE	The picture is protected.	Remove protection before rotating pictures.
😭 CAN NOT ROTATE	Movies can not be rotated.	—
🛱 CANNOT EXECUTE	Resize or red-eye removal can not be applied to the selected picture.	_
😫 CANNOT EXECUTE	Red-eye removal can not be applied to movies.	—
DEACTIVATE SILENT MODE	An attempt was made to adjust the volume with the camera in silent mode.	Exit silent mode before adjusting the volume.

Warning	Description	Solution
COMMUNICATION ERROR	lwore being printed or conied to a computer or	I ontirm that the device is turned on and that the LISK
PRINTER ERROR		Check printer (see printer manual for details). To resume printing, turn the printer off and then turn it back on.
PRINTER ERROR RESUME?		Check printer (see printer manual for details). If printing does not resume automatically, press <b>MENU/OK</b> to resume.
CAN NOT BE PRINTED	An attempt was made to print a movie, a pic- ture not created with the camera, or a picture in a format not supported by the printer.	Movies and some pictures created with other devices can not be printed. If the picture was created with the camera, check the printer manual to confirm that the printer supports the JFIF-JPEG or Exif-JPEG format. If it does not, the pictures can not be printed.

## **Memory Card Capacity**

The following table shows the recording time or number of pictures available at different image sizes. All figures are approximate; file size varies with the scene recorded, producing wide variations in the number of files that can be stored. The number of exposures or length remaining may not diminish at an even rate.

#### Photographs

							0	A		S							
		4:3	3:2	16:9	1:1	4:3	3:2	16:9	1:1	4:3	3:2	16:9	1:1				
4 GB	FINE	480	540	640	640	950	1,000	1,260	1,200	1,870	2,100	3,400	2,400				
400	NORMAL	960	1,070	1,270	1,270	1,860	2,050	2,430	2,400	3,530	3,900	6,160	4,550				
8 GB	FINE	980	1,100	1,300	1,300	1,920	2,100	2,530	2,500	3,750	4,100	6,840	4,900				
0 UD	NORMAL	1,930	2,160	2,550	2,550	3,740	4,100	4,880	4,900	7,090	7,800	12,370	9,100				

#### Movie

	ID 1280×720	540 640×480	<u>820</u> 320 × 240
	(30 fps) 1	(30 fps) <sup>2</sup>	(30 fps) <sup>3</sup>
4 GB	18 min.	54 min.	114 min.
8 GB	35 min.	107 min.	226 min.

1 Use a CLASS Card or better. Individual movies can not exceed 9 minutes in length.

2 Use a CLASS card or better. Individual movies can not exceed 29 minutes in length.

3 Use a CLASS card or better. Individual movies can not exceed 61 minutes in length.

# Specifications

System	
Model	Digital Camera FinePix S8600 Series
Effective pixels	16 million
CCD	½3-in., square-pixel CCD with primary color filter
Storage media	SD/SDHC/SDXC memory cards
File system	Compliant with Design Rule for Camera File System (DCF), Exif 2.3, and Digital Print Order Format (DPOF)
File format	Still pictures: Exif 2.3 JPEG (compressed)
	Movies: AVI • Audio: WAV/monaural sound
Image size (pixels, file size)	• • • • • • • • • • • • • • • • • • •
	• M 4:3 (3,264×2,448) • M 3:2 (3,264×2,176) • M 16:9 (3,264×1,840) • M 1:1 (2,432×2,432)
	• 🔄 4:3 (2,304×1,728) • 🔄 3:2 (2,304×1,536) • 🔄 16:9 (1,920×1,080) • 🔄 1:1 (1,728×1,728)
Lens	Fujinon 36×optical zoom lens, F/2.9 (wide angle)—6.9 (telephoto)
Focal length	f=4.5 mm-162.0 mm (35-mm format equivalent: 25 mm-900 mm)
Digital zoom	<ul> <li>Intelligent digital zoom: approx. 2.0 × (up to 72 × with optical zoom)</li> </ul>
	Movies: approx. 2 ×
Aperture	F2.9/F6.5* (wide angle), F6.9/F15.4* (telephoto), *uses Neutral Density (ND) filter
Focus range (distance from	Approx. 40 cm (1.3 ft.)–infinity (wide angle); approx. 2.5 m (8.2 ft.)–infinity (telephoto)
front of lens)	• Macro: approx. 5 cm-3.0 m/1.9 in9.8 ft. (wide angle); approx. 2.5 m-3.0 m/8.2 ft9.8 ft. (telephoto)
	• Super macro: approx. 1 cm-100 cm/0.3 in3.2 ft. (wide angle)
Sensitivity	Standard output sensitivity equivalent to ISO 100, 200, 400, 800, 1600, 3200, 6400 (3200 and 6400 available
	only at image sizes 🛐); AUTO (400), AUTO (800), AUTO (1600)

Annual fuence in	4 a (fm a)*1	Continuous frames (Image size)*2									
• 🕸: 8 s – ½ s	<ul> <li>Other modes: <sup>1</sup>/<sub>4</sub> s - <sup>1</sup>/<sub>2</sub></li> </ul>	2,000 S									
• <b>P</b> , <b>S</b> , <b>M</b> : 8 s - ½,000 s	• C+: 1/8 S - 1/2,000 S	• <b>x</b> <sup>(*</sup> : 3 s − <sup>1</sup> / <sub>2,000</sub> s									
Optical stabilization, le	ens shift										
Available (camera auto	Available (camera automatically selects 🔾, 🗳, 🗳, 🧐, 🧐, or 🕲)										
-2 EV - +2 EV in increm	nents of 1⁄3 EV ( <b>P</b> , <b>S</b> )										
		nual exposure									
256-segment <b>t</b> hrough	n- <b>t</b> he-lens (TTL) meterir	ng; MULTI, SPOT, AVERAGE									
	Programmed AE, shut -2 EV - +2 EV in increm Available (camera auto Optical stabilization, le • <b>P</b> , <b>S</b> , <b>M</b> : 8 s - ½000 s • ☆: 8 s - ½ s	Optical stabilization, lens shift           • P, S, M: 8 s - ½,000 s         • C: ½ s - ½,000 s									

	Approx. frame rate (fps)*1	Continuous frames (Image size)*2							
ъ	1.2	3 frames (selected exposure, overexposure, underexposure)							
۵.	0.4	maximum number of frames varies with image size and available memory							
<b>1</b> .2		5							
Q	1.2	5							
M <sup>2</sup>	3.3	20 M S							
Ð	8.0	40 S							

	<b>e e e e e e e e e e</b>	
Bracketing	±1/3 EV, ±2/3 EV, ±1 EV	
Focus	<ul> <li>Mode: CENTER/MULTI/AREA/CONTINUOUS/TRACKING</li> </ul>	
	<ul> <li>Autofocus system: Contrast-detect TTL AF</li> </ul>	

System	
White balance	Automatic scene detection; six manual preset modes for direct sunlight, shade, daylight fluorescent, warm white fluorescent, cool white fluorescent, and incandescent lighting; custom white balance
Self-timer	Off, 2 sec, 10 sec
Flash	Manual pop-up flash with CCD-metered auto flash control (using monitor pre-flashes); effective range when sensitivity is set to <b>ISO AUTO</b> is approx. 40 cm–6.7 m/1.3 ft.–21.9 ft. (wide angle) or 2.5 m–3.5 m/8.2 ft.–11.4 ft. (telephoto); effective range in macro mode is approx. 40 cm–3.0 m/1.3 ft.–9.8 ft. (wide angle) or 2.0 m–3.0 m/6.5 ft.–9.8 ft. (telephoto)
Flash modes	Auto, forced flash, off, slow synchro (red-eye removal off); auto with red-eye removal, forced flash with red-eye removal, off, slow sync with red-eye removal (red-eye removal on)
Monitor Frame coverage	3.0-in. (7.6 cm), 460k-dot color LCD monitor Approx. 97% (shooting), 100% (playback)
Movie frame rate	1280×720 (720p)/ 1280 440×480 (VGA)/ 1280 320×240 (QVGA); frame rate 30 fps
Input/output terminals	
HDMI output	HDMI Mini Connector
Digital input/output	USB 2.0 High Speed

Power supply/other											
Power sources	<ul> <li>AA alkaline batteries (×3)</li> <li>AA lithium batteries (×3; available from third-part AA rechargeable nickel-metal hydride (Ni-MH) b</li> <li>AC-5VX AC power adapter and CP-04 DC couple</li> </ul>	atteries (×3; available from third-party suppliers)									
Battery life (approximate	Battery type	Approximate number of frames									
number of frames that can	Alkaline (type supplied with camera)	250									
be taken with fresh or fully	Lithium	590									
charged batteries)	Ni-MH	410									
	CIPA standard, measured in 🗖 (auto) mode using batteries supplied with camera (alkaline batteries only) and SD memory card.										
	<b>Note</b> : Number of shots that can be taken with battery varies with battery charge level and will decline at low temperatures.										
Camera dimensions	121.3 mm × 80.8 mm × 64.6 mm/4.7 in. × 3.1 in. × 2.5	in. (W×H×D), excluding projections									
Shooting weight	Approx. 450 g/15.8 oz., including batteries and me	mory card									
Camera weight	Approx. 380 g/13.4 oz., excluding batteries, access	ories, and memory cards									
Operating conditions	• <b>Temperature</b> : 0 °C - +40 °C/+32 °F - +104 °F	Humidity: 10%-80% (no condensation)									

#### Notices

- Specifications subject to change without notice. FUJIFILM shall not be held liable for damages resulting from errors in this manual.
- Although the monitor is manufactured using advanced high-precision technology, small bright points and anomalous colors (particularly in the vicinity of text) may appear. This is normal for this type of monitor and does not indicate a malfunction; images recorded with the camera are unaffected.
- Digital cameras may malfunction when exposed to strong radio interference (e.g., electric fields, static electricity, or line noise).
- Due to the type of lens used, some distortion may occur at the periphery of images. This is normal.

## Memo

## FUJIFILM

#### **FUJIFILM Corporation**

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN

http://www.fujifilm.com/products/digital\_cameras/index.html

Please contact your local distributor for repairs and technical support. (see Worldwide Network list)

### **Shooting Mode and Camera Settings**

The options available in each shooting mode are listed below.

												S	hoot	ing n	node										
							Adv.	,						SI	P1/S	P2									
	Option		SRAUTO	Ô	Ô	Adv	@\$	ZOOM	9	69		*	Ċ	* <sup>(*</sup>	-16- 16-	*	•	<b>≜ĩ</b>	Y	*	TEXT	PANORAMA	Ρ	S	Μ
		Ð		V	~	~	~	~												<b>1</b>	$\checkmark^1$		~	~	~
	۲	Ŷ		V	~	~		~															~	~	~
		OFF		V	~	~	~	V	✓1	✓1	$\mathbf{V}^{1}$	$\mathbf{V}^{1}$	$\mathbf{V}^1$	$\checkmark^1$	$\mathbf{V}^{1}$	$\mathbf{V}^{1}$	$\mathbf{V}^1$	$\checkmark^1$	$\mathbf{V}^1$			$\mathbf{V}^{1}$	~	~	~
		AUTO	~	V		~		V	V			V					V	~	$\mathbf{V}^1$				V		
	© OFF	4	~	V		~	$\mathbf{V}^1$	V	V			V				$\mathbf{V}^{1}$	V	~			$\mathbf{V}^{1}$		V	$\checkmark^1$	$\checkmark^1$
	Urr	S <b>‡</b>				~			V				$\checkmark^1$	$\mathbf{V}^1$									V		
<b>4</b> <sup>2</sup>		۶ ک			$\mathbf{V}^{1}$					$\mathbf{V}^{1}$	$\mathbf{V}^{1}$				$\mathbf{V}^{1}$					1		$\checkmark^1$			
<b>*</b> -		AUTO	~	V				V	V								V	~	<b>1</b>				V		
	© ON	@\$	~	V			$\mathbf{V}^{1}$	V	V							$\mathbf{V}^{1}$	V	V					~	$\checkmark^1$	
	(WON	O SLOW							V				$\mathbf{V}^1$	$\checkmark^1$									~		
		۲ 🕃 ک			$\mathbf{V}^{1}$																				
	Ŀ	<b>Z</b> <sup>4</sup>																					~	~	
	D	OFF		V		~	~	~	V	V	$\checkmark^1$	$\mathbf{V}^{1}$	~	~	$\mathbf{V}^{1}$	~	~	~	~	<b>1</b>	$\checkmark^1$	$\checkmark^1$	~	~	~
	8	ON	<b>V</b> <sup>1</sup>	V		~	~	V	V	V			~	~		V	V	V	~				V	~	~
		0	~	V	✓ <sup>5</sup>	✓ <sup>5</sup>	V	V	V	V	✓ <sup>5</sup>	✓ <sup>5</sup>	~	~	✓ 5	V	V	V	V	V <sup>5</sup>	✓ <sup>5</sup>	✔5	V	~	~
	1	6 6	~	V	V	V	~	V	V	V	~	V	V	V	V	V	V	V	V	V	~		~	V	~
	(	Ů	~	V		~	V	V	V	V	V	V	V	V	V	V	V	V	V	V	~		V	V	~

											9	shoot	ing n	node										
						Adv.	,						SI	P1/S	P2									
0p	otion	SRAUTO	Ó	Ō,	Adv	@\$	2000	9	۲		*	C	*C*	*	*	-6-	<b>≜ĩ</b>	Y	*	TEXT	PANORAMA	Р	S	Μ
	AUTO (1600)																					V	~	
	AUTO (800)																					V	~	
	AUTO (400)																					V	~	
	6400 <sup>7</sup>																					V		~
ISO	3200 <sup>7</sup>																					~		~
150	1600																					V		V
	800																					V		V
	400																					V		~
	200																					V		~
	100																					V		V
	0	~	~	V	~	~	V	V	V	~	~	~	~	~	~	~	~	~	~	~		V	V	~
ŧ	M	~	V	V	~	~		V	V	~	~	~	~	~	~	~	V	~	~	~		V	~	~
	S	~	V	V	~	~		V	V	~	~	~	~	~	~	~	V	~	~	~	<b>√</b> <sup>9</sup>	V	V	~
	1280 × 720	V	V	V	~	~	V	V	V	~	~	~	~	~	~	~	V	~	~	~	V	V	V	~
,##	510 640 × 480	~	V	V	~	~	V	V	V	~	~	~	~	~	~	~	V	~	~	~	~	V	V	~
	520 320 × 240	~	V	V	~	~	V	V	V	~	~	~	~	~	~	~	V	~	~	~	~	V	V	~
	FINE	~	V	V	~	~	V	V	V	~	~	~	~	~	~	V	V	~	~	~	~	V	V	~
<b>.</b>	NORMAL	~	V	V	~	~	V	V	V	~	~	~	~	~	~	~	V	~	~	~	~	V	~	~
	STD	~	V	V		~	V	V	~	~	~	~	~	V	~	V	V	~	~	~	V	V	V	~
	Ö <b>r</b>		V	V		~	V														V	V	V	~
	₿ <b>r</b>	~	V	V		~	V	V	V	~	~	~	~	V	V	V	V	~	~	~	~	V	V	V
[	ق <sup>8</sup>																					V	~	~
	WB																				~	~	~	V
																						V	V	V
	(,📽 )	~	V	V	~	~	V	V	V	~	~	~	~	V	~	~	V	~	~	~	~	V	~	~
	<u>4±</u>																					V	V	~

	Shooting mode																							
					Adv.			SP1/SP2																
Option		SRAUTO	Ô	Ô,	Adv	@\$	E.COM	9	6		*	C	*C*	*	*	-5-	<b>∆</b> ĩ	Y	*	TEXT	PANORAMA	Р	S	Μ
																						V	~	~
	( <b>@</b> ) <sub>1</sub>	~	V	~	~	~	V	V	V	V	V	~	~	~	V	~	~	~	V	~	~	V	~	~
	( <b>@</b> ) <sub>2</sub>	~	V	~	~	~	~	V	V	V	V	~	~	~	V	~	~	~	V	~	~	V	~	~
	OFF	~	V	V	~	~	~	V	V	V	~	~	~	~	~	~	~	~	~	~	~	V	~	~
AF	ON	~	~	V	~	~	~	~	V			~	V			V	~			~		~	~	~
	OFF	~	V	V	~	~	~	V	V	$\mathbf{V}^{1}$	<b>1</b>	V	~	$\checkmark^1$	1	V	V	$\checkmark^1$	1	~	$\checkmark^1$	V	~	~
<b>1</b> 2	ON		V			V		V	V	V	~	V	~	~	V	~	V	~	V	V		V	V	~
	OFF		V		$\checkmark^1$	V	$\mathbf{V}^{1}$	V	V	V	~	V	~	V	V	~	V	V	V	~	$\checkmark^1$	V	V	~

1 Automatically optimized for selected shooting mode.

2 Flash turns off automatically in super macro mode (**2**).

3 Lower flash to select 🕄 in modes other than 🕚.

4 Disabled if flash fires when set to AUTO or 💭 or if flash is set to 🕏 or 👁 and subject is poorly lit.

5 **ON** selected automatically.

6 Only horizontal (landscape-orientation) framing is available in continuous shooting mode.

7 Image sizes over S are set to S.

8 Fixed at 💽 when Intelligent Face Detection is on.

9 Aspect ratio fixed at 4:3.