

Bright Cluster Manager 8.0

# Administrator Manual

Revision: 4aa1881

Date: Wed Sep 27 2023



©2017 Bright Computing, Inc. All Rights Reserved. This manual or parts thereof may not be reproduced in any form unless permitted by contract or by written permission of Bright Computing, Inc.

## **Trademarks**

Linux is a registered trademark of Linus Torvalds. PathScale is a registered trademark of Cray, Inc. Red Hat and all Red Hat-based trademarks are trademarks or registered trademarks of Red Hat, Inc. SUSE is a registered trademark of Novell, Inc. PGI is a registered trademark of NVIDIA Corporation. FLEXlm is a registered trademark of Flexera Software, Inc. All other trademarks are the property of their respective owners.

## **Rights and Restrictions**

All statements, specifications, recommendations, and technical information contained herein are current or planned as of the date of publication of this document. They are reliable as of the time of this writing and are presented without warranty of any kind, expressed or implied. Bright Computing, Inc. shall not be liable for technical or editorial errors or omissions which may occur in this document. Bright Computing, Inc. shall not be liable for any damages resulting from the use of this document.

## **Limitation of Liability and Damages Pertaining to Bright Computing, Inc.**

The Bright Cluster Manager product principally consists of free software that is licensed by the Linux authors free of charge. Bright Computing, Inc. shall have no liability nor will Bright Computing, Inc. provide any warranty for the Bright Cluster Manager to the extent that is permitted by law. Unless confirmed in writing, the Linux authors and/or third parties provide the program as is without any warranty, either expressed or implied, including, but not limited to, marketability or suitability for a specific purpose. The user of the Bright Cluster Manager product shall accept the full risk for the quality or performance of the product. Should the product malfunction, the costs for repair, service, or correction will be borne by the user of the Bright Cluster Manager product. No copyright owner or third party who has modified or distributed the program as permitted in this license shall be held liable for damages, including general or specific damages, damages caused by side effects or consequential damages, resulting from the use of the program or the un-usability of the program (including, but not limited to, loss of data, incorrect processing of data, losses that must be borne by you or others, or the inability of the program to work together with any other program), even if a copyright owner or third party had been advised about the possibility of such damages unless such copyright owner or third party has signed a writing to the contrary.

# Table of Contents

Table of Contents . . . . .	i
0.1 Quickstart . . . . .	xv
0.2 About This Manual . . . . .	xv
0.3 About The Manuals In General . . . . .	xv
0.4 Getting Administrator-Level Support . . . . .	xvi
0.5 Getting Professional Services . . . . .	xvi
<b>1 Introduction . . . . .</b>	<b>1</b>
1.1 Bright Cluster Manager Functions And Aims . . . . .	1
1.2 The Scope Of The Administrator Manual (This Manual) . . . . .	1
1.2.1 Installation . . . . .	1
1.2.2 Configuration, Management, And Monitoring Via Bright Cluster Manager Tools And Applications . . . . .	2
1.3 Outside The Direct Scope Of The Administrator Manual . . . . .	2
<b>2 Cluster Management With Bright Cluster Manager . . . . .</b>	<b>5</b>
2.1 Concepts . . . . .	5
2.1.1 Devices . . . . .	5
2.1.2 Software Images . . . . .	6
2.1.3 Node Categories . . . . .	7
2.1.4 Node Groups . . . . .	7
2.1.5 Roles . . . . .	8
2.2 Modules Environment . . . . .	8
2.2.1 Adding And Removing Modules . . . . .	8
2.2.2 Using Local And Shared Modules . . . . .	9
2.2.3 Setting Up A Default Environment For All Users . . . . .	9
2.2.4 Creating A Modules Environment Module . . . . .	10
2.2.5 Lua Modules Environment (LMod) . . . . .	10
2.3 Authentication . . . . .	11
2.3.1 Changing Administrative Passwords On The Cluster . . . . .	11
2.3.2 Logins Using <code>ssh</code> . . . . .	13
2.3.3 Certificates . . . . .	13
2.3.4 Profiles . . . . .	14
2.4 Bright View GUI . . . . .	14
2.4.1 Installing The Cluster Management GUI Service . . . . .	14
2.4.2 Navigating The Cluster With Bright View . . . . .	15
2.5 Cluster Management Shell . . . . .	17
2.5.1 Invoking <code>cmsh</code> . . . . .	18
2.5.2 Levels, Modes, Help, And Commands Syntax In <code>cmsh</code> . . . . .	19
2.5.3 Working With Objects . . . . .	23
2.5.4 Accessing Cluster Settings . . . . .	31

2.5.5	Advanced <code>cmsh</code> Features . . . . .	32
2.6	Cluster Management Daemon . . . . .	39
2.6.1	Controlling The Cluster Management Daemon . . . . .	39
2.6.2	Configuring The Cluster Management Daemon . . . . .	41
2.6.3	Configuring The Cluster Management Daemon Logging Facilities . . . . .	41
2.6.4	Configuration File Modification, And The <code>FrozenFile</code> Directive . . . . .	42
2.6.5	Configuration File Conflicts Between The Standard Distribution And Bright Cluster Manager For Generated And Non-Generated Files . . . . .	42
<b>3</b>	<b>Configuring The Cluster</b> . . . . .	<b>45</b>
3.1	Main Cluster Configuration Settings . . . . .	46
3.1.1	Cluster Configuration: Various Name-Related Settings . . . . .	46
3.1.2	Cluster Configuration: Some Network-Related Settings . . . . .	47
3.1.3	Miscellaneous Settings . . . . .	48
3.1.4	Limiting The Maximum Number Of Open Files . . . . .	50
3.2	Network Settings . . . . .	51
3.2.1	Configuring Networks . . . . .	52
3.2.2	Adding Networks . . . . .	55
3.2.3	Changing Network Parameters . . . . .	55
3.3	Configuring Bridge Interfaces . . . . .	66
3.4	Configuring VLAN interfaces . . . . .	68
3.4.1	Configuring A VLAN Interface Using <code>cmsh</code> . . . . .	68
3.4.2	Configuring A VLAN Interface Using Bright View . . . . .	68
3.5	Configuring Bonded Interfaces . . . . .	69
3.5.1	Adding A Bonded Interface . . . . .	69
3.5.2	Single Bonded Interface On A Regular Node . . . . .	70
3.5.3	Multiple Bonded Interface On A Regular Node . . . . .	70
3.5.4	Bonded Interfaces On Head Nodes And HA Head Nodes . . . . .	70
3.5.5	Tagged VLAN On Top Of a Bonded Interface . . . . .	71
3.5.6	Further Notes On Bonding . . . . .	71
3.6	Configuring InfiniBand And Omni-Path Interfaces . . . . .	71
3.6.1	Installing Software Packages . . . . .	72
3.6.2	Subnet Managers . . . . .	72
3.6.3	InfiniBand Network Settings . . . . .	73
3.6.4	Verifying Connectivity . . . . .	74
3.7	Configuring BMC (IPMI/iLO) Interfaces . . . . .	75
3.7.1	BMC Network Settings . . . . .	75
3.7.2	BMC Authentication . . . . .	76
3.7.3	Interfaces Settings . . . . .	77
3.8	Configuring Switches And PDUs . . . . .	78
3.8.1	Configuring With The Manufacturer's Configuration Interface . . . . .	78
3.8.2	Configuring SNMP . . . . .	78
3.8.3	Uplink Ports . . . . .	78
3.8.4	The <code>showport</code> MAC Address to Port Matching Tool . . . . .	79
3.8.5	Disabling Port Detection . . . . .	80
3.8.6	The <code>switchoverview</code> Command . . . . .	80
3.9	Disk Layouts: Disked, Semi-Diskless, And Diskless Node Configuration . . . . .	81

3.9.1	Disk Layouts . . . . .	81
3.9.2	Disk Layout Assertions . . . . .	81
3.9.3	Changing Disk Layouts . . . . .	82
3.9.4	Changing A Disk Layout From Disked To Diskless . . . . .	82
3.10	Configuring NFS Volume Exports And Mounts . . . . .	83
3.10.1	Exporting A Filesystem Using Bright View And <code>cmsh</code> . . . . .	84
3.10.2	Mounting A Filesystem Using Bright View And <code>cmsh</code> . . . . .	86
3.10.3	Mounting A Filesystem Subtree For A Diskless Node Over NFS . . . . .	89
3.10.4	Mounting The Root Filesystem For A Diskless Node Over NFS . . . . .	91
3.10.5	Configuring NFS Volume Exports And Mounts Over RDMA With OFED Drivers . . . . .	93
3.11	Managing And Configuring Services . . . . .	94
3.11.1	Why Use The Cluster Manager For Services? . . . . .	94
3.11.2	Managing And Configuring Services—Examples . . . . .	95
3.12	Managing And Configuring A Rack . . . . .	98
3.12.1	Racks . . . . .	98
3.12.2	Assigning Devices To A Rack . . . . .	100
3.12.3	Assigning Devices To A Chassis . . . . .	101
3.13	Configuring A GPU Unit, And Configuring GPU Settings . . . . .	104
3.13.1	GPUs And GPU Units . . . . .	104
3.13.2	GPU Unit Configuration Example: The Dell PowerEdge C410x . . . . .	104
3.13.3	Configuring GPU Settings . . . . .	106
3.14	Configuring Custom Scripts . . . . .	108
3.14.1	<code>custompowerscript</code> . . . . .	109
3.14.2	<code>custompingscript</code> . . . . .	109
3.14.3	<code>customremoteconsolescript</code> . . . . .	110
3.15	Cluster Configuration Without Execution By CMDaemon . . . . .	110
3.15.1	Cluster Configuration: The Bigger Picture . . . . .	110
3.15.2	Making Nodes Function Differently By Image . . . . .	111
3.15.3	Making All Nodes Function Differently From Normal Cluster Behavior With FrozenFile . . . . .	112
3.15.4	Adding Functionality To Nodes Via An <code>initialize</code> Or <code>finalize</code> Script . . . . .	112
3.15.5	Examples Of Configuring Nodes With Or Without CMDaemon . . . . .	113
<b>4</b>	<b>Power Management</b> . . . . .	<b>115</b>
4.1	Configuring Power Parameters . . . . .	115
4.1.1	PDU-Based Power Control . . . . .	116
4.1.2	IPMI-Based Power Control . . . . .	117
4.1.3	Combining PDU- and IPMI-Based Power Control . . . . .	118
4.1.4	Custom Power Control . . . . .	118
4.1.5	Hewlett Packard iLO-Based Power Control . . . . .	119
4.1.6	Dell <code>racadm</code> -based Power Control . . . . .	120
4.2	Power Operations . . . . .	120
4.2.1	Power Operations With Bright View . . . . .	120
4.2.2	Power Operations Through <code>cmsh</code> . . . . .	121
4.3	Monitoring Power . . . . .	122
4.4	CPU Scaling Governors . . . . .	123
4.4.1	The Linux Kernel And CPU Scaling Governors . . . . .	123

4.4.2	The Governor List According To <code>sysinfo</code> . . . . .	123
4.4.3	Setting The Governor . . . . .	124
<b>5</b>	<b>Node Provisioning</b> . . . . .	<b>127</b>
5.1	Before The Kernel Loads . . . . .	127
5.1.1	PXE Booting . . . . .	127
5.1.2	iPXE Booting From A Disk Drive . . . . .	131
5.1.3	iPXE Booting Using InfiniBand . . . . .	131
5.1.4	Bootng From The Drive . . . . .	131
5.1.5	The Boot Role . . . . .	132
5.2	Provisioning Nodes . . . . .	132
5.2.1	Provisioning Nodes: Configuration Settings . . . . .	132
5.2.2	Provisioning Nodes: Role Setup With <code>cmsh</code> . . . . .	133
5.2.3	Provisioning Nodes: Role Setup With Bright View . . . . .	134
5.2.4	Provisioning Nodes: Housekeeping . . . . .	136
5.3	The Kernel Image, Ramdisk And Kernel Modules . . . . .	139
5.3.1	Bootng To A “Good State” Software Image . . . . .	139
5.3.2	Selecting Kernel Driver Modules To Load Onto Nodes . . . . .	139
5.3.3	InfiniBand Provisioning . . . . .	140
5.4	Node-Installer . . . . .	142
5.4.1	Requesting A Node Certificate . . . . .	143
5.4.2	Deciding Or Selecting Node Configuration . . . . .	145
5.4.3	Starting Up All Network Interfaces . . . . .	154
5.4.4	Determining Install-mode Type And Execution Mode . . . . .	156
5.4.5	Running Initialize Scripts . . . . .	161
5.4.6	Checking Partitions, RAID Configuration, Mounting Filesystems . . . . .	161
5.4.7	Synchronizing The Local Drive With The Software Image . . . . .	162
5.4.8	Writing Network Configuration Files . . . . .	165
5.4.9	Creating A Local <code>/etc/fstab</code> File . . . . .	166
5.4.10	Installing GRUB Bootloader . . . . .	166
5.4.11	Running Finalize Scripts . . . . .	168
5.4.12	Unloading Specific Drivers . . . . .	168
5.4.13	Switching To The Local <code>init</code> Process . . . . .	168
5.5	Node States . . . . .	169
5.5.1	Node States Icons In Bright View . . . . .	169
5.5.2	Node States Shown In <code>cmsh</code> . . . . .	169
5.5.3	Node States Indicating Regular Start Up . . . . .	169
5.5.4	Node States That May Indicate Problems . . . . .	170
5.6	Updating Running Nodes . . . . .	172
5.6.1	Updating Running Nodes: Configuration With <code>excludelistupdate</code> . . . . .	172
5.6.2	Updating Running Nodes: With <code>cmsh</code> Using <code>imageupdate</code> . . . . .	178
5.6.3	Updating Running Nodes: With Bright View Using the <code>Update</code> node Option . . . . .	178
5.6.4	Updating Running Nodes: Considerations . . . . .	178
5.7	Adding New Nodes . . . . .	179
5.7.1	Adding New Nodes With <code>cmsh</code> And Bright View Add Functions . . . . .	179
5.8	Troubleshooting The Node Boot Process . . . . .	179
5.8.1	Node Fails To PXE Boot . . . . .	179

5.8.2	Node-installer Logging . . . . .	182
5.8.3	Provisioning Logging . . . . .	183
5.8.4	Ramdisk Fails During Loading Or Sometime Later . . . . .	183
5.8.5	Ramdisk Cannot Start Network . . . . .	183
5.8.6	Node-Installer Cannot Create Disk Layout . . . . .	184
5.8.7	Node-Installer Cannot Start BMC (IPMI/iLO) Interface . . . . .	186
<b>6</b>	<b>User Management</b>	<b>191</b>
6.1	Managing Users And Groups With Bright View . . . . .	191
6.2	Managing Users And Groups With <code>cmsh</code> . . . . .	193
6.2.1	Adding A User . . . . .	193
6.2.2	Saving The Modified State . . . . .	194
6.2.3	Editing Properties Of Users And Groups . . . . .	195
6.2.4	Reverting To The Unmodified State . . . . .	197
6.2.5	Removing A User . . . . .	198
6.3	Using An External LDAP Server . . . . .	198
6.3.1	External LDAP Server Replication . . . . .	200
6.3.2	High Availability . . . . .	202
6.4	Tokens And Profiles . . . . .	203
6.4.1	Modifying Profiles . . . . .	204
6.4.2	Creation Of Custom Certificates With Profiles, For Users Managed By Bright Cluster Manager's Internal LDAP . . . . .	205
6.4.3	Creation Of Custom Certificates With Profiles, For Users Managed By An External LDAP . . . . .	208
6.4.4	Logging The Actions Of CMDaemon Users . . . . .	209
<b>7</b>	<b>Workload Management</b>	<b>211</b>
7.1	Workload Managers Choices . . . . .	211
7.2	Forcing Jobs To Run In A Workload Management System . . . . .	212
7.2.1	Disallowing User Logins To Regular Nodes Via <code>cmsh</code> . . . . .	212
7.2.2	Disallowing User Logins To Regular Nodes Via Bright View . . . . .	213
7.2.3	Disallowing Other User Processes Outside Of Workload Manager User Processes . . . . .	213
7.3	Installation Of Workload Managers . . . . .	213
7.3.1	Setting Up, Enabling, And Disabling The Workload Manager With <code>wlm-setup</code> . . . . .	213
7.3.2	Other Options With <code>wlm-setup</code> . . . . .	215
7.3.3	Prolog And Epilog Scripts . . . . .	217
7.4	Enabling, Disabling, And Monitoring Workload Managers . . . . .	219
7.4.1	Enabling And Disabling A Workload Manager With Bright View . . . . .	220
7.4.2	Enabling And Disabling A Workload Manager With <code>cmsh</code> . . . . .	222
7.4.3	Monitoring The Workload Manager Services . . . . .	224
7.5	Configuring And Running Individual Workload Managers . . . . .	225
7.5.1	Configuring And Running Slurm . . . . .	225
7.5.2	Configuring And Running SGE . . . . .	229
7.5.3	Installing, Configuring, And Running UGE . . . . .	230
7.5.4	Configuring And Running Torque . . . . .	235
7.5.5	Configuring And Running PBS Pro . . . . .	238
7.5.6	Installing, Configuring And Running OpenLava . . . . .	240

7.5.7	Installing, Configuring, And Running LSF . . . . .	241
7.6	Using Bright View With Workload Management . . . . .	246
7.6.1	Jobs Display And Handling In Bright View . . . . .	246
7.6.2	Queues Display And Handling In Bright View . . . . .	247
7.7	Using cmsh With Workload Management . . . . .	247
7.7.1	Jobs Display And Handling In cmsh: jobs Mode . . . . .	247
7.7.2	Job Queues Display And Handling In cmsh: jobqueue Mode . . . . .	251
7.7.3	Nodes Drainage Status And Handling In cmsh . . . . .	254
7.7.4	Launching Jobs With cm-launcher . . . . .	255
7.8	Examples Of Workload Management Assignment . . . . .	256
7.8.1	Setting Up A New Category And A New Queue For It . . . . .	256
7.8.2	Setting Up A Prejob Check . . . . .	259
7.9	Power Saving Features . . . . .	260
7.9.1	Slurm . . . . .	260
7.9.2	The cm-scale Service . . . . .	261
7.10	Cgroups . . . . .	289
7.10.1	Cgroups Settings For Workload Managers . . . . .	289
7.10.2	Managed Cgroups . . . . .	295
<b>8</b>	<b>Containerization</b> . . . . .	<b>301</b>
8.1	Docker Engine . . . . .	301
8.1.1	Docker Setup . . . . .	302
8.1.2	Integration With Workload Managers . . . . .	303
8.1.3	DockerHost Role . . . . .	304
8.1.4	Iptables . . . . .	305
8.1.5	Storage Backends . . . . .	305
8.1.6	The Container Daemon Service And RunC Runtime . . . . .	308
8.1.7	Docker Monitoring . . . . .	310
8.2	Docker Registry . . . . .	310
8.2.1	Docker Registry Setup . . . . .	310
8.2.2	DockerRegistry Role . . . . .	310
8.3	Kubernetes . . . . .	311
8.3.1	Kubernetes Setup . . . . .	311
8.3.2	Disabling Kubernetes . . . . .	314
8.3.3	Kubernetes Cluster . . . . .	315
8.3.4	Kubernetes Roles . . . . .	316
8.3.5	Security Model . . . . .	328
8.3.6	Networking Model . . . . .	330
8.3.7	Kubernetes Monitoring . . . . .	332
8.3.8	Setup Of A Storage Class For Ceph . . . . .	332
8.4	Singularity . . . . .	334
8.4.1	Use Cases . . . . .	334
8.4.2	Package cm-singularity . . . . .	334
8.4.3	MPI Integration . . . . .	335



<b>9</b>	<b>Mesos</b>	<b>337</b>
9.1	Mesos Introduction . . . . .	337
9.1.1	Concepts . . . . .	337
9.1.2	Installation Notes . . . . .	337
9.1.3	Installation Options . . . . .	338
9.1.4	Mesos Installation Packages . . . . .	338
9.2	Using The <code>cm-mesos-setup</code> Utility To Deploy, Uninstall, And Scale Mesos . . . . .	338
9.2.1	Deployment Of Mesos . . . . .	339
9.2.2	Uninstallation Of Mesos . . . . .	346
9.2.3	Masters Scaling . . . . .	347
9.3	Using Bright View To Install And Manage Mesos . . . . .	347
9.3.1	Mesos Installation Wizard Using Bright View . . . . .	347
9.3.2	Mesos Settings Management With Bright View . . . . .	348
9.4	Network Configuration . . . . .	350
9.5	Mesos Objects . . . . .	350
9.5.1	Mesos Cluster . . . . .	350
9.5.2	MesosMaster Role . . . . .	351
9.5.3	MesosSlave Role . . . . .	352
9.5.4	Marathon Role . . . . .	354
9.5.5	MesosDNS Role . . . . .	354
9.5.6	MesosProxy Role . . . . .	355
9.6	Using Mesos . . . . .	355
9.6.1	Accessing The Non-Bright Mesos And Marathon Web Interfaces . . . . .	356
9.6.2	Spawning And Checking On A Test Application . . . . .	356
9.7	Scaling . . . . .	359
<b>10</b>	<b>BeeGFS</b>	<b>361</b>
10.1	BeeGFS Introduction . . . . .	361
10.1.1	BeeGFS Concepts . . . . .	361
10.1.2	BeeGFS Installation Notes And Options . . . . .	361
10.2	Deployment And Uninstallation Of BeeGFS With <code>cm-beegfs-setup</code> . . . . .	362
10.2.1	Deployment Of BeeGFS . . . . .	362
10.2.2	Uninstalling BeeGFS . . . . .	369
10.3	Managing The Deployed BeeGFS Instance . . . . .	369
10.3.1	Setup . . . . .	369
10.3.2	BeeGFS Objects . . . . .	370
10.3.3	Usage . . . . .	382
10.3.4	Admon Interface . . . . .	382
<b>11</b>	<b>Post-Installation Software Management</b>	<b>385</b>
11.1	Bright Cluster Manager Packages And Their Naming Convention . . . . .	385
11.2	Managing Packages On The Head Node . . . . .	387
11.2.1	Managing RPM Or .deb Packages On The Head Node . . . . .	387
11.2.2	Installation Of Packages On The Head Node That Are Not .deb And Not .rpm Packages . . . . .	390
11.3	Kernel Management On A Head Node Or Image . . . . .	391
11.3.1	Installing A Standard Distribution Kernel Into An Image . . . . .	391

11.3.2	Excluding Kernels And Other Packages From Updates . . . . .	392
11.3.3	Updating A Kernel In A Software Image . . . . .	393
11.3.4	Setting Kernel Options For Software Images . . . . .	394
11.3.5	Kernel Driver Modules . . . . .	394
11.4	Managing A Package In A Software Image And Running It On Nodes . . . . .	396
11.4.1	Installing From Head Into The Image: Changing The Root Directory Into Which The Packages Are Deployed . . . . .	396
11.4.2	Installing From Head Into The Image: Updating The Node . . . . .	398
11.4.3	Installing From Head Into The Image: Possible Issues When Using <code>rpm --root,</code> <code>yum --installroot</code> Or <code>chroot</code> . . . . .	398
11.5	Managing Non-RPM Software In A Software Image And Running It On Nodes . . . . .	399
11.5.1	Managing The Software Directly On An Image . . . . .	400
11.5.2	Managing The Software Directly On A Node, Then Syncing Node-To-Image . . . .	400
11.6	Creating A Custom Software Image . . . . .	403
11.6.1	Creating A Base Distribution Archive From A Base Host . . . . .	403
11.6.2	Creating The Software Image With <code>cm-create-image</code> . . . . .	405
11.6.3	Configuring Local Repositories For Linux Distributions, And For The Bright Clus- ter Manager Package Repository, For A Software Image . . . . .	411
11.6.4	Creating A Custom Image From The Local Repository . . . . .	413
<b>12</b>	<b>Cluster Monitoring</b> . . . . .	<b>415</b>
12.1	A Basic Monitoring Example And Action . . . . .	415
12.1.1	Synopsis Of Basic Monitoring Example . . . . .	415
12.1.2	Before Using The Basic Monitoring Example—Setting Up The Pieces . . . . .	416
12.1.3	Using The Monitoring Basic Example . . . . .	417
12.2	Monitoring Concepts And Definitions . . . . .	420
12.2.1	Measurables . . . . .	420
12.2.2	Enummetrics . . . . .	422
12.2.3	Metrics . . . . .	423
12.2.4	Health Check . . . . .	424
12.2.5	Trigger . . . . .	426
12.2.6	Action . . . . .	426
12.2.7	Severity . . . . .	427
12.2.8	AlertLevel . . . . .	427
12.2.9	Flapping . . . . .	427
12.2.10	Data Producer . . . . .	427
12.2.11	Conceptual Overview: The Main Monitoring Interfaces Of Bright View . . . . .	429
12.3	Monitoring Visualization With Bright View . . . . .	430
12.3.1	The Monitoring Window . . . . .	430
12.4	Monitoring Configuration With Bright View . . . . .	432
12.4.1	Monitoring Configuration: Data Producers . . . . .	433
12.4.2	Monitoring Configuration: Measurables . . . . .	435
12.4.3	Monitoring Configuration: Consolidators . . . . .	437
12.4.4	Monitoring Configuration: Actions . . . . .	439
12.4.5	Monitoring Configuration: Triggers . . . . .	441
12.4.6	Monitoring Configuration: Health status . . . . .	443
12.4.7	Monitoring Configuration: All Health Checks . . . . .	444

12.4.8	Monitoring Configuration: Standalone Monitored Entities . . . . .	445
12.5	The monitoring Mode Of <code>cmsh</code> . . . . .	445
12.5.1	The <code>action</code> Submode . . . . .	446
12.5.2	The <code>consolidator</code> Submode . . . . .	448
12.5.3	The <code>measurable</code> Submode . . . . .	450
12.5.4	The <code>setup</code> Submode . . . . .	454
12.5.5	The <code>standalone</code> Submode . . . . .	458
12.5.6	The <code>trigger</code> Submode . . . . .	458
12.6	Obtaining Monitoring Data Values . . . . .	461
12.6.1	Getting The List Of Measurables For An Entity: The <code>measurables</code> , <code>metrics</code> , <code>healthchecks</code> And <code>enummetrics</code> Commands . . . . .	461
12.6.2	On-Demand Metric Sampling And Health Checks . . . . .	462
12.6.3	The Latest Data And Counter Values—The <code>latest*data</code> And <code>latestmetriccounters</code> Commands . . . . .	464
12.6.4	Data Values Over A Period—The <code>dumpmonitoringdata</code> Command . . . . .	466
12.6.5	Monitoring Data Health Overview—The <code>monitoringhealthoverview</code> Command . . . . .	471
12.6.6	Monitoring Data About The Monitoring System—The <code>monitoringinfo</code> Com- mand . . . . .	471
12.7	The User Portal . . . . .	472
12.7.1	Accessing The User Portal . . . . .	472
12.7.2	Setting A Common Username/Password For The User Portal . . . . .	473
12.7.3	User Portal Home Page . . . . .	474
12.8	Job Monitoring . . . . .	475
12.8.1	Job Metrics . . . . .	476
12.8.2	Job Information Retention . . . . .	481
12.8.3	Job Metrics Sampling Configuration . . . . .	481
12.8.4	Job Monitoring In <code>cmsh</code> . . . . .	482
12.9	Event Viewer . . . . .	483
12.9.1	Viewing Events In Bright View . . . . .	484
12.9.2	Viewing Events In <code>cmsh</code> . . . . .	484
12.9.3	Using The Event Bucket From The Shell For Events And For Tagging Device States . . . . .	486
12.9.4	<code>InfoMessages</code> . . . . .	486
<b>13</b>	<b>Day-to-day Administration</b> . . . . .	<b>489</b>
13.1	Parallel Shells: <code>pdsh</code> And <code>pexec</code> . . . . .	489
13.1.1	<code>pdsh</code> In The OS Shell . . . . .	489
13.1.2	<code>pexec</code> In <code>cmsh</code> . . . . .	493
13.1.3	<code>pexec</code> In Bright View . . . . .	493
13.1.4	Using The <code>-j -join</code> Option Of <code>pexec</code> In <code>cmsh</code> . . . . .	494
13.1.5	Other Parallel Commands . . . . .	494
13.2	Getting Support With Cluster Manager Issues . . . . .	495
13.2.1	Support Via E-mail . . . . .	495
13.2.2	Reporting Cluster Manager Diagnostics With <code>cm-diagnose</code> . . . . .	495
13.2.3	Requesting Remote Support With <code>request-remote-assistance</code> . . . . .	496
13.2.4	Requesting Remote Support With A Shared Screen Utility . . . . .	497
13.3	Backups . . . . .	498
13.3.1	Cluster Installation Backup . . . . .	498

13.3.2	Local Database And Data Backups And Restoration . . . . .	498
13.4	Revision Control For Images . . . . .	500
13.4.1	Btrfs: The Concept And Why It Works Well In Revision Control For Images . . . . .	500
13.4.2	Btrfs Availability And Distribution Support . . . . .	501
13.4.3	Installing Btrfs To Work With Revision Control Of Images In Bright Cluster Manager	501
13.4.4	Using <code>cmsh</code> For Revision Control Of Images . . . . .	503
13.5	BIOS Configuration And Updates . . . . .	506
13.5.1	BIOS Configuration . . . . .	506
13.5.2	Updating BIOS . . . . .	507
13.5.3	Booting DOS Image . . . . .	507
13.6	Hardware Match Check With The <code>hardware-profile</code> Data Producer . . . . .	508
13.7	Serial Over LAN Console Access . . . . .	509
13.7.1	Background Notes On Serial Console And SOL . . . . .	509
13.7.2	SOL Console Configuration With Bright View . . . . .	511
13.7.3	SOL Console Configuration And Access With <code>cmsh</code> . . . . .	511
13.7.4	The <code>conman</code> Serial Console Logger And Viewer . . . . .	511
13.8	Managing Raw Monitoring Data . . . . .	515
13.8.1	Monitoring Subsystem Disk Usage With The <code>monitoringinfo --storage Op-</code> <code>tion</code> . . . . .	515
13.8.2	Estimating The Required Size Of The Storage Device . . . . .	515
13.8.3	Moving Monitoring Data Elsewhere . . . . .	516
13.8.4	Deleting All Monitoring Data . . . . .	516
<b>14</b>	<b>MIC Configuration</b>	<b>519</b>
14.1	Introduction . . . . .	519
14.2	MIC Software Installation . . . . .	519
14.2.1	MIC Software Packages . . . . .	520
14.2.2	MIC Environment MIC Commands . . . . .	522
14.2.3	Bright Computing MIC Tools . . . . .	522
14.2.4	MIC OFED Installation . . . . .	522
14.3	MIC Configuration . . . . .	524
14.3.1	Using <code>cm-mic-setup</code> To Configure MICs . . . . .	524
14.3.2	Using <code>cmsh</code> To Configure Some MIC Properties . . . . .	525
14.3.3	Using MIC Overlays To Place Software On The MIC . . . . .	527
14.4	MIC Card Flash Updates . . . . .	529
14.5	Other MIC Administrative Tasks . . . . .	531
14.5.1	How <code>CMDaemon</code> Manages MIC Cards . . . . .	531
14.5.2	Using Workload Managers With MIC . . . . .	532
14.5.3	Mounting The Root Filesystem For A MIC Over NFS . . . . .	533
14.5.4	MIC Metrics . . . . .	533
14.5.5	User Management On The MIC . . . . .	534
<b>15</b>	<b>High Availability</b>	<b>535</b>
15.0	Introduction . . . . .	535
15.0.1	Why Have High Availability? . . . . .	535
15.0.2	High Availability Is Possible On Head Nodes, And Also On Regular Nodes . . . . .	535
15.0.3	High Availability Usually Uses Shared Storage . . . . .	535

15.0.4	Organization Of This Chapter . . . . .	535
15.1	HA Concepts . . . . .	536
15.1.1	Primary, Secondary, Active, Passive . . . . .	536
15.1.2	Monitoring The Active Head Node, Initiating Failover . . . . .	536
15.1.3	Services In Bright Cluster Manager HA Setups . . . . .	536
15.1.4	Failover Network Topology . . . . .	537
15.1.5	Shared Storage . . . . .	539
15.1.6	Guaranteeing One Active Head At All Times . . . . .	540
15.1.7	Automatic Vs Manual Failover . . . . .	541
15.1.8	HA And Cloud Nodes . . . . .	542
15.2	HA Setup Procedure Using <code>cmha-setup</code> . . . . .	542
15.2.1	Preparation . . . . .	543
15.2.2	Failover Cloning . . . . .	544
15.2.3	Shared Storage Setup . . . . .	547
15.2.4	Automated Failover And Relevant Testing . . . . .	549
15.3	Running <code>cmha-setup</code> Without <code>Ncurses</code> , Using An XML Specification . . . . .	550
15.3.1	Why Run It Without <code>Ncurses</code> ? . . . . .	550
15.3.2	The Syntax Of <code>cmha-setup</code> Without <code>Ncurses</code> . . . . .	550
15.3.3	Example <code>cmha-setup</code> Run Without <code>Ncurses</code> . . . . .	551
15.4	Managing HA . . . . .	552
15.4.1	Changing An Existing Failover Configuration . . . . .	552
15.4.2	<code>cmha</code> Utility . . . . .	552
15.4.3	States . . . . .	555
15.4.4	Failover Action Decisions . . . . .	556
15.4.5	Keeping Head Nodes In Sync . . . . .	557
15.4.6	High Availability Parameters . . . . .	559
15.4.7	Viewing Failover Via Bright View . . . . .	560
15.4.8	Re-cloning A Head Node . . . . .	560
15.5	HA For Regular Nodes . . . . .	562
15.5.1	Why Have HA On Regular Nodes? . . . . .	562
15.5.2	Comparing Head And Regular Node HA . . . . .	562
15.5.3	Setting Up A Regular Node HA Service . . . . .	563
15.5.4	The Sequence Of Events When Making Another HA Regular Node Active . . . . .	566
15.6	HA And Workload Manager Jobs . . . . .	567
<b>16</b>	<b>Dell BIOS Management</b> . . . . .	<b>569</b>
16.1	Introduction . . . . .	569
16.2	Prerequisites For BIOS Management . . . . .	569
16.3	BIOS settings . . . . .	570
16.3.1	Initializing The BIOS Settings Via <code>cmsh</code> . . . . .	570
16.3.2	Managing The BIOS Settings Via Bright View . . . . .	570
16.3.3	Applying Dell Settings And Firmware Updates Via Bright View . . . . .	573
16.3.4	Managing The BIOS Settings Via <code>cmsh</code> . . . . .	573
16.4	Frequently Asked Questions . . . . .	576

<b>A</b>	<b>Generated Files</b>	<b>579</b>
A.1	Files Generated Automatically On Head Nodes . . . . .	579
A.2	Files Generated Automatically In Software Images: . . . . .	582
A.3	Files Generated Automatically On Regular Nodes . . . . .	583
A.4	Files Not Generated, But Installed. . . . .	583
<b>B</b>	<b>Bright Computing Public Key</b>	<b>587</b>
<b>C</b>	<b>CMDaemon Configuration File Directives</b>	<b>589</b>
<b>D</b>	<b>Disk Partitioning And RAID Configuration</b>	<b>613</b>
D.1	Structure Of Partitioning Definition—The Global Partitioning XML Schema File . . . . .	613
D.2	Structure Of Hardware RAID Definition—The Hardware RAID XML Schema File . . . . .	619
D.3	Example: Default Node Partitioning . . . . .	622
D.4	Example: Hardware RAID Configuration . . . . .	624
D.4.1	RAID level 0 And RAID 10 Example . . . . .	624
D.5	Example: Software RAID . . . . .	625
D.6	Example: Software RAID With Swap . . . . .	626
D.7	Example: Logical Volume Manager . . . . .	627
D.8	Example: Logical Volume Manager With RAID 1 . . . . .	628
D.9	Example: Diskless . . . . .	630
D.10	Example: Semi-diskless . . . . .	631
D.11	Example: Preventing Accidental Data Loss . . . . .	631
D.12	Example: Using Custom Assertions . . . . .	632
<b>E</b>	<b>Example initialize And finalize Scripts</b>	<b>635</b>
E.1	When Are They Used? . . . . .	635
E.2	Accessing From Bright View And cmsb . . . . .	635
E.3	Environment Variables Available To initialize And finalize Scripts . . . . .	636
E.4	Using Environment Variables Stored In Multiple Variables . . . . .	639
E.5	Storing A Configuration To A Filesystem . . . . .	640
E.5.1	Storing With Initialize Scripts . . . . .	640
E.5.2	Ways Of Writing A Finalize Script To Configure The Destination Nodes . . . . .	640
E.5.3	Restricting The Script To Nodes Or Node Categories . . . . .	642
<b>F</b>	<b>Workload Managers Quick Reference</b>	<b>643</b>
F.1	Slurm . . . . .	643
F.2	Sun Grid Engine . . . . .	644
F.3	Torque . . . . .	646
F.4	PBS Pro . . . . .	646
F.5	OpenLava . . . . .	647
<b>G</b>	<b>Metrics, Health Checks, Enummetrics, And Actions</b>	<b>649</b>
G.1	Metrics And Their Parameters . . . . .	649
G.1.1	Regular Metrics . . . . .	649
G.1.2	NFS Metrics . . . . .	654
G.1.3	Monitoring System Metrics . . . . .	656
G.1.4	Parameters For Metrics . . . . .	658

G.2	Health Checks And Their Parameters . . . . .	660
G.2.1	Health Checks . . . . .	660
G.2.2	Parameters For Health Checks . . . . .	666
G.3	Actions And Their Parameters . . . . .	667
G.3.1	Actions . . . . .	667
G.3.2	Parameters For A Monitoring Action . . . . .	667
<b>H</b>	<b>Workload Manager Configuration Files Updated By CMDaemon</b>	<b>669</b>
H.1	Slurm . . . . .	669
H.2	Grid Engine (SGE/UGE) . . . . .	669
H.3	Torque . . . . .	669
H.4	PBS Pro . . . . .	669
H.5	LSF . . . . .	670
H.6	OpenLava . . . . .	670
<b>I</b>	<b>Changing The LDAP Password</b>	<b>671</b>
I.1	Setting A New Password For The LDAP Server . . . . .	671
I.2	Setting The New Password In <code>cmd.conf</code> . . . . .	671
I.3	Checking LDAP Access . . . . .	672
<b>J</b>	<b>Tokens</b>	<b>673</b>
<b>K</b>	<b>Understanding Consolidation</b>	<b>683</b>
K.1	Introduction . . . . .	683
K.2	What Is Consolidation? . . . . .	683
K.3	Raw Data And Consolidation . . . . .	683
K.4	A Demonstration Of The Output . . . . .	684





# Preface

Welcome to the *Administrator Manual* for the Bright Cluster Manager 8.0 cluster environment.

## 0.1 Quickstart

For readers who want to get a cluster up and running as quickly as possible with Bright Cluster Manager, there is a quickstart installation guide in Chapter 1 of the *Installation Manual*.

## 0.2 About This Manual

The rest of this manual is aimed at helping system administrators configure, understand, and manage a cluster running Bright Cluster Manager so as to get the best out of it.

The *Administrator Manual* covers administration topics which are specific to the Bright Cluster Manager environment. Readers should already be familiar with basic Linux system administration, which the manual does not generally cover. Aspects of system administration that require a more advanced understanding of Linux concepts for clusters are explained appropriately.

This manual is not intended for users interested only in interacting with the cluster to run compute jobs. The *User Manual* is intended to get such users up to speed with the user environment and workload management system.

## 0.3 About The Manuals In General

Regularly updated versions of the Bright Cluster Manager 8.0 manuals are available on updated clusters by default at `/cm/shared/docs/cm`. The latest updates are always online at <http://support.brightcomputing.com/manuals>.

- The *Installation Manual* describes installation procedures.
- The *User Manual* describes the user environment and how to submit jobs for the end user.
- The *Cloudbursting Manual* describes how to deploy the cloud capabilities of the cluster.
- The *Developer Manual* has useful information for developers who would like to program with Bright Cluster Manager.
- The *OpenStack Deployment Manual* describes how to deploy OpenStack with Bright Cluster Manager.
- The *Big Data Deployment Manual* describes how to deploy Big Data with Bright Cluster Manager.
- The *UCS Deployment Manual* describes how to deploy the Cisco UCS server with Bright Cluster Manager.
- The *Machine Learning Manual* describes how to install and configure machine learning capabilities with Bright Cluster Manager.

If the manuals are downloaded and kept in one local directory, then in most pdf viewers, clicking on a cross-reference in one manual that refers to a section in another manual opens and displays that section in the second manual. Navigating back and forth between documents is usually possible with keystrokes or mouse clicks.

For example: <Alt>-<Backarrow> in Acrobat Reader, or clicking on the bottom leftmost navigation button of xpdf, both navigate back to the previous document.

The manuals constantly evolve to keep up with the development of the Bright Cluster Manager environment and the addition of new hardware and/or applications. The manuals also regularly incorporate customer feedback. Administrator and user input is greatly valued at Bright Computing. So any comments, suggestions or corrections will be very gratefully accepted at [manuals@brightcomputing.com](mailto:manuals@brightcomputing.com).

## **0.4 Getting Administrator-Level Support**

If the reseller from whom Bright Cluster Manager was bought offers direct support, then the reseller should be contacted.

Otherwise the primary means of support is via the website <https://support.brightcomputing.com>. This allows the administrator to submit a support request via a web form, and opens up a trouble ticket. It is a good idea to try to use a clear subject header, since that is used as part of a reference tag as the ticket progresses. Also helpful is a good description of the issue. The followup communication for this ticket typically goes via standard e-mail. Section 13.2 has more details on working with support.

## **0.5 Getting Professional Services**

Bright Computing normally differentiates between professional services (customer asks Bright Computing to do something or asks Bright Computing to provide some service) and support (customer has a specific question or problem that requires an answer or resolution). Professional services can be provided after consulting with the reseller, or the Bright account manager.

# 1

## Introduction

### 1.1 Bright Cluster Manager Functions And Aims

Bright Cluster Manager contains tools and applications to facilitate the installation, administration, and monitoring of a cluster. In addition, Bright Cluster Manager aims to provide users with an optimal environment for developing and running applications that require extensive computational resources.

### 1.2 The Scope Of The Administrator Manual (This Manual)

The *Administrator Manual* covers installation, configuration, management, and monitoring of Bright Cluster Manager, along with relevant background information to help understand the topics covered.

#### 1.2.1 Installation

Installation can generally be divided into parts as follows, with some parts covered by the *Administrator Manual*, some by the *Installation Manual*, and some by other manuals:

- **Initial installation of Bright Cluster Manager:** This is covered in the *Installation Manual*, which gives a short introduction to the concept of a cluster along with details on installing Bright Cluster Manager onto the head node. The *Installation Manual* is therefore the first manual an administrator should usually turn to when getting to work with Bright Cluster Manager for the first time. The *Administrator Manual* can be referred to as the main reference resource once the head node has had Bright Cluster Manager installed on it.
- **Provisioning installation:** This is covered in the *Administrator Manual*. After the head node has had Bright Cluster Manager installed on it, the other, regular, nodes can (PXE) boot off it and provision themselves from it with a default image, without requiring a Linux distribution DVD themselves. The PXE boot and provisioning process for the regular nodes is described in detail in Chapter 5.  
  
In brief, provisioning installs an operating system and files on a node. This kind of installation to a regular node differs from a normal Linux installation in several ways. An important difference is that content that is put on the filesystem of the regular node is normally overwritten by provisioning when the regular node reboots.
- **Post-installation software installation:** The installation of software to a cluster that is already configured and running Bright Cluster Manager is described in detail in Chapter 11 of this manual.
- **Third-party software installation:** The installation of software that is not developed by Bright Computing, but is supported as a part of Bright Cluster Manager. This is described in detail in the *Installation Manual*.
- **Cloudbursting, Big Data, OpenStack, and Machine Learning:** these are integrated by Bright Computing in various ways. These have their own deployment procedures and have separate manuals.

### 1.2.2 Configuration, Management, And Monitoring Via Bright Cluster Manager Tools And Applications

The administrator normally deals with the cluster software configuration via a front end to the Bright Cluster Manager. This can be GUI-based (Bright View, section 2.4), or shell-based (`cmsh`, section 2.5). Other tasks can be handled via special tools provided with Bright Cluster Manager, or the usual Linux tools. The use of Bright Cluster Manager tools is usually recommended over standard Linux tools because cluster administration often has special issues, including that of scale.

The following topics are among those covered in this manual:

Chapter, Title	Description
2 Cluster Management With Bright Cluster Manager	Introduction to main concepts and tools of Bright Cluster Manager. Lays down groundwork for the remaining chapters
3 Configuring The Cluster	Further configuration and set up of the cluster after software installation of Bright Cluster Manager on the head node.
4 Power Management	How power management within the cluster works
5 Node Provisioning	Node provisioning in detail
6 User Management	Account management for users and groups
7 Workload Management	Workload management implementation and use
8 Containerization	Using Docker and Kubernetes with Bright Cluster Manager
9 Mesos	Deploying and using Mesos with Bright Cluster Manager
11 Post-Installation Software Management	Managing, updating, modifying Bright Cluster Manager software and images
12 Cluster Monitoring	Cluster monitoring, conditional triggering of actions, user portal and job monitoring
13 Day-To-Day Administration	Miscellaneous administration
14 MIC Configuration	Intel MIC architecture integration with Bright Cluster Manager
15 High Availability	Background details and setup instructions to build a cluster with redundant head nodes

The appendices to this manual generally give supplementary details to the main text.

The following topics are also logically a part of Bright Cluster Manager administration, but they have their own separate manuals. This is because they have, or are eventually expected to have, many features:

- Cloudbursting (*Cloudbursting Manual*)
- OpenStack deployment (*OpenStack Deployment Manual*)
- Big Data deployment (*Big Data Deployment Manual*)
- Developer topics (*Developer Manual*)

### 1.3 Outside The Direct Scope Of The Administrator Manual

The following supplementary resources can deal with issues related to this manual, but are outside its direct scope:

- **Use by the end user:** This is covered very peripherally in this manual. The user normally interacts with the cluster by logging into a custom Linux user environment to run jobs. Details on running jobs from the perspective of the user are given in the *User Manual*.

- **The knowledge base** at <http://kb.brightcomputing.com> often supplements the *Administrator Manual* with discussion of the following:
  - Obscure, or complicated, configuration cases
  - Procedures that are not really within the scope of Bright Cluster Manager itself, but that may come up as part of related general Linux configuration.
- **Further support options.** If the issue is not described adequately in this manual, then section 13.2 describes how to get further support.



# 2

## Cluster Management With Bright Cluster Manager

This chapter introduces cluster management with Bright Cluster Manager. A cluster running Bright Cluster Manager exports a cluster management interface to the outside world, which can be used by any application designed to communicate with the cluster.

Section 2.1 introduces a number of concepts which are key to cluster management using Bright Cluster Manager.

Section 2.2 gives a short introduction on how the modules environment can be used by administrators. The modules environment provides facilities to control aspects of a users' interactive sessions and also the environment used by compute jobs.

Section 2.3 introduces how authentication to the cluster management infrastructure works and how it is used. Section 2.4 and section 2.5 introduce the cluster management GUI (Bright View) and cluster management shell (`cmsh`) respectively. These are the primary applications that interact with the cluster management daemon.

Section 2.6 describes the basics of the cluster management daemon, `CMDaemon`, running on all nodes of the cluster.

### 2.1 Concepts

In this section some concepts central to cluster management with Bright Cluster Manager are introduced.

#### 2.1.1 Devices

A *device* in the Bright Cluster Manager cluster management infrastructure represents components of a cluster. A device can be any of the following types:

- Head Node
- Physical Node
- Virtual Node
- Cloud Node
- Virtual SMP Node
- GPU Unit
- MIC
- Chassis

- Ethernet Switch
- InfiniBand Switch
- Myrinet Switch
- Power Distribution Unit
- Rack Sensor Kit
- Generic Device

A device can have a number of properties (e.g. rack position, hostname, switch port) which can be set in order to configure the device. Using Bright Cluster Manager, operations (e.g. power on) may be performed on a device. The property changes and operations that can be performed on a device depend on the type of device. For example, it is possible to mount a new filesystem to a node, but not to an Ethernet switch.

Every device that is managed by Bright Cluster Manager has a device state associated with it. The table below describes the most important states for devices:

state	device is	monitored by Bright?	state tracking?
UP	UP	monitored	tracked
DOWN	DOWN	monitored	tracked
UP/CLOSED	UP	mostly ignored	tracked
DOWN/CLOSED	DOWN	mostly ignored	tracked

These, and other other states are described in more detail in section 5.5.

DOWN and DOWN/CLOSED states have an important difference. In the case of DOWN, the device is down, but is typically intended to be available, and thus typically indicates a failure. In the case of DOWN/CLOSED, the device is down, but is intended to be unavailable, and thus typically indicates that the administrator would like the device to be ignored.

### 2.1.2 Software Images

A *software image* is a blueprint for the contents of the local filesystems on a regular node. In practice, a software image is a directory on the head node containing a full Linux filesystem.

The software image in a standard Bright Cluster Manager installation is based on the same parent distribution that the head node uses. A different distribution can also be chosen after installation, from the distributions listed in section 2.1 of the *Installation Manual* for the software image. That is, the head node and the regular nodes can run different parent distributions. However, such a “mixed” cluster can be harder to manage and it is easier for problems to arise in such mixtures. Such mixtures, while supported, are therefore not recommended, and should only be administered by system administrators that understand the differences between Linux distributions.

RHEL6/CentOS6/SL6 mixtures are completely compatible with each other on the head and regular nodes. On the other hand, SLES may need some effort to work in a mixture with RHEL/CentOS/SL.

When a regular node boots, the node provisioning system (Chapter 5) sets up the node with a copy of the software image, which by default is called `default-image`.

Once the node is fully booted, it is possible to instruct the node to re-synchronize its local filesystems with the software image. This procedure can be used to distribute changes to the software image without rebooting nodes (section 5.6.2).

It is also possible to “lock” a software image so that no node is able to pick up the image until the software image is unlocked. (section 5.4.7).



Software images can be changed using regular Linux tools and commands (such as `rpm` and `chroot`). More details on making changes to software images and doing image package management can be found in Chapter 11.

### 2.1.3 Node Categories

The collection of settings in Bright Cluster Manager that can apply to a node is called the configuration of the node. The administrator usually configures nodes using the Bright View (section 2.4) or `cmsh` (section 2.5) front end tools, and the configurations are managed internally with a database.

A *node category* is a group of regular nodes that share the same configuration. Node categories allow efficiency, allowing an administrator to:

- configure a large group of nodes at once. For example, to set up a group of nodes with a particular disk layout.
- operate on a large group of nodes at once. For example, to carry out a reboot on an entire category.

A node is in exactly one category at all times, which is default by default. The default category can be changed by accessing the `base` object of `partition` mode (page 59), and setting the value of `defaultcategory` to another, existing, category.

Nodes are typically divided into node categories based on the hardware specifications of a node or based on the task that a node is to perform. Whether or not a number of nodes should be placed in a separate category depends mainly on whether the configuration—for example: monitoring setup, disk layout, role assignment—for these nodes differs from the rest of the nodes.

A node inherits values from the category it is in. Each value is treated as the default property value for a node, and is overruled by specifying the node property value for the node.

One configuration property value of a node category is its software image (section 2.1.2). However, there is no requirement for a one-to-one correspondence between node categories and software images. Therefore multiple node categories may use the same software image, and conversely, one variable image—it is variable because it can be changed by the node setting—may be used in the same node category.

Software images can have their parameters overruled by the category settings. By default, however, the category settings that can overrule the software image parameters are unset.

By default, all nodes are placed in the `default` category. Alternative categories can be created and used at will, such as:

#### Example

Node Category	Description
<code>nodes-ib</code>	nodes with InfiniBand capabilities
<code>nodes-highmem</code>	nodes with extra memory
<code>login</code>	login nodes
<code>storage</code>	storage nodes

### 2.1.4 Node Groups

A *node group* consists of nodes that have been grouped together for convenience. The group can consist of any mix of all kinds of nodes, irrespective of whether they are head nodes or regular nodes, and irrespective of what (if any) category they are in. A node may be in 0 or more node groups at one time. I.e.: a node may belong to many node groups.

Node groups are used mainly for carrying out operations on an entire group of nodes at a time. Since the nodes inside a node group do not necessarily share the same configuration, configuration changes cannot be carried out using node groups.

#### Example

Node Group	Members
brokenhardware	node087,node783,node917
headnodes	mycluster-m1,mycluster-m2
rack5	node212..node254
top	node084,node126,node168,node210

One important use for node groups is in the `nodegroups` property of the provisioning role configuration (section 5.2.1), where a list of node groups that provisioning nodes provision is specified.

### 2.1.5 Roles

A *role* is a task that can be performed by a node. By assigning a certain role to a node, an administrator activates the functionality that the role represents on this node. For example, a node can be turned into provisioning node, or a storage node by assigning the corresponding roles to the node.

Roles can be assigned to individual nodes or to node categories. When a role has been assigned to a node category, it is implicitly assigned to all nodes inside of the category.

A *configuration overlay* is a feature introduced in Bright Cluster Manager 7.1. A configuration overlay is a group of roles that can be assigned to designated groups of nodes within a cluster. In the case of Big Data, the overlays are called Hadoop, Cassandra, or Spark configuration groups (section 3.1.7 of the *Big Data Deployment Manual*), and are applied to nodes within a Hadoop, Cassandra, or Spark instance.

Some roles allow parameters to be set that influence the behavior of the role. For example, the `Slurm Client Role` (which turns a node into a Slurm client) uses parameters to control how the node is configured within Slurm in terms of queues and the number of GPUs.

When a role has been assigned to a node category with a certain set of parameters, it is possible to override the parameters for a node inside the category. This can be done by assigning the role again to the individual node with a different set of parameters. Roles that have been assigned to nodes override roles that have been assigned to a node category.

Examples of role assignment are given in sections 5.2.2 and 5.2.3.

## 2.2 Modules Environment

The *modules environment* is a third-party software (section 7.1 of the *Installation Manual*) that allows users to modify their shell environment using pre-defined *modules*. A module may, for example, configure the user's shell to run a certain version of an application.

Details of the modules environment from a user perspective are discussed in section 2.3 of the *User Manual*. However some aspects of it are relevant for administrators and are therefore discussed here.

### 2.2.1 Adding And Removing Modules

Modules may be loaded and unloaded, and also be combined for greater flexibility.

Modules currently installed are listed with:

```
module list
```

The modules available for loading are listed with:

```
module avail
```

Loading and removing specific modules is done with `module load` and `module remove`, using this format:

```
module load <MODULENAME1> [<MODULENAME2> ...]
```

For example, loading the `shared` module (section 2.2.2), the `gcc` compiler, the `openmpi` parallel library, and the `openblas` library, allows an MPI application to be compiled with OpenBLAS optimizations:

### Example

```
module add shared
module add gcc/6.1.0
module add openmpi/gcc/64/1.10.1
module add openblas/dynamic/0.2.18
mpicc -o myapp myapp.c
```

Specifying version numbers explicitly is typically only necessary when multiple versions of an application are installed and available. When there is no ambiguity, module names without a further path specification may be used.

#### 2.2.2 Using Local And Shared Modules

Applications and their associated modules are divided into *local* and *shared* groups. Local applications are installed on the local filesystem, whereas shared applications reside on a shared (i.e. imported) filesystem.

It is recommended that the `shared` module be loaded by default for ordinary users. Loading it gives access to the modules belonging to shared applications, and allows the `module avail` command to show these extra modules.

Loading the `shared` module automatically for `root` is not recommended on a cluster where shared storage is not on the head node itself. This is because `root` logins could be obstructed if this storage is not available, and if the `root` user relies on files in the shared storage.

On clusters without external shared storage, `root` can safely load the `shared` module automatically at login. This can be done by running the following command as `root`:

```
module initadd shared
```

Other modules can also be set to load automatically by the user at login by using “`module initadd`” with the full path specification. With the `initadd` option, individual users can customize their own default modules environment.

Modules can be combined in *meta-modules*. By default, the `default-environment` meta-module exists, which allows the loading of several modules at once by a user. Cluster administrators are encouraged to customize the `default-environment` meta-module to set up a recommended environment for their users. The `default-environment` meta-module is empty by default.

The administrator and users have the flexibility of deciding the modules that should be loaded in undecided cases via module *dependencies*. Dependencies can be defined using the `prereq` and `conflict` commands. The man page for `modulefile` gives details on configuring the loading of modules with these commands.

#### 2.2.3 Setting Up A Default Environment For All Users

How users can set up particular modules to load automatically for their own use with the `module initadd` command is discussed in section 2.2.2.

How the administrator can set up particular modules to load automatically for all users by default is discussed in this section (section 2.2.3). In this example it is assumed that all users have just the following modules:

### Example

```
[fred@bright80 ~]$ module list
Currently Loaded Modulefiles:
1) gcc/6.1.0          2) slurm/16.05.2
```

The Torque and Maui modules can then be set up by the administrator as a default for all users in the following 2 ways:

1. Defining part of a `.profile` to be executed for login shells. For example:

```
[root@bright80 ~]# cat /etc/profile.d/userdefaultmodules.sh
module load shared
module load torque
module load maui
```

Whenever users now carry out a bash login, these modules are loaded.

2. Instead of placing the modules directly in a script under `profile.d` like in the preceding item, a slightly more sophisticated way is to set the modules in the meta-module `/cm/shared/modulefiles/default-environment`. For example:

```
[root@bright80 ~]# cat /cm/shared/modulefiles/default-environment
##Module1.0#####
## default modulefile
##
proc ModulesHelp { } {
    puts stderr "\tLoads default environment modules for this cluster"
}
module-whatis "adds default environment modules"

# Add any modules here that should be added by when a user loads the 'default-enviro\
nment' module
module add shared torque maui
```

The script `userdefaultmodules.sh` script under `profile.d` then only needs to have the `default-environment` module loaded in it:

```
[root@bright80 ~]# cat /etc/profile.d/userdefaultmodules.sh
module load default-environment
```

Now, whenever the administrator changes the `default-environment` module, users get these changes too during login.

The lexicographical order of the scripts in the `/etc/profile` directory is important. For example, naming the file `defaultusermodules.sh` instead of `userdefaultmodules.sh` means that the `modules.sh` script is run after the file is run, instead of before, which would cause an error.

## 2.2.4 Creating A Modules Environment Module

All module files are located in the `/cm/local/modulefiles` and `/cm/shared/modulefiles` trees. A module file is a Tcl or Lua script in which special commands are used to define functionality. The `modulefile(1)` man page has more on this.

Cluster administrators can use the existing modules files as a guide to creating and installing their own modules for module environments, and can copy and modify a file for their own software if there is no environment provided for it already by Bright Cluster Manager.

## 2.2.5 Lua Modules Environment (LMod)

By default, Bright Cluster Manager uses traditional Tcl scripts for its module files, or *TMod*. Lua modules, or *LMod*, provide an alternative modules environment, where the files are typically written in Lua. LMod can be used as a replacement for TMod.

Conceptually LMod works in the same way as TMod, but provides some extra features and commands.

For LMod, the module files are typically written in Lua, but LMod is also capable of reading Tcl module files. It is therefore not necessary to convert all existing Tcl modules manually to the Lua language.

On a Bright cluster, both LMod and TMod are installed by default. However only one of them is active, depending on which one is enabled. Switching between LMod and TMod for a node can be done by setting an environment variable, `$ENABLE_LMOD` in the `cm-lmod-init.sh` shell script.

### Switching For The Head Node

For example, for the head node:

#### Example

```
[root@bright80 ~]# cat /etc/sysconfig/modules/lmod/cm-lmod-init.sh
export ENABLE_LMOD=1
```

In the preceding example, LMod is enabled, and TMod is disabled if `$ENABLE_LMOD` is set to 1.

#### Example

```
[root@bright80 ~]# cat /etc/sysconfig/modules/lmod/cm-lmod-init.sh
export ENABLE_LMOD=0
```

In the preceding example, LMod is disabled, and TMod is enabled if `$ENABLE_LMOD` is set to 0.

A change in the file on the node is effective after having logged out, then logged into the shell again.

### Switching For The Regular Nodes

A *node image* is a directory and contents of that directory. It is used as the template for a regular node when the node is provisioned (Chapter 5). For a node image with the name *<image name>*, the `cm-lmod-init.sh` file is located at `/cm/images/<image name>/etc/sysconfig/modules/lmod/cm-lmod-init.sh`. For switching between LMod and TMod on a regular node, the file is changed on the image, and the file on the image is then updated to the node. The update from the image to the node is typically carried out with the `imageupdate` command in `cmsh` (section 5.6.2) or the `Update node` command in Bright View (section 5.6.3).

## 2.3 Authentication

### 2.3.1 Changing Administrative Passwords On The Cluster

How to set up or change regular user passwords is not discussed here, but in Chapter 6 on user management.

Amongst the administrative passwords associated with the cluster are:

1. **The root password of the head node:** This allows a root login to the head node.
2. **The root passwords of the software images:** These allow a root login to a regular node running with that image, and is stored in the image file.
3. **The root password of the node-installer:** This allows a root login to the node when the node-installer, a stripped-down operating system, is running. The node-installer stage prepares the node for the final operating system when the node is booting up. Section 5.4 discusses the node-installer in more detail.
4. **The root password of MySQL:** This allows a root login to the MySQL server.

To avoid having to remember the disparate ways in which to change these 4 kinds of passwords, the `cm-change-passwd` command runs a dialog prompting the administrator on which of them, if any, should be changed, as in the following example:

```
[root@bright80 ~]# cm-change-passwd
With this utility you can easily change the following passwords:
* root password of head node
* root password of slave images
* root password of node-installer
* root password of mysql
```

Note: if this cluster has a high-availability setup with 2 head nodes, be sure to run this script on both head nodes.

```
Change password for root on head node? [y/N]: y
Changing password for root on head node.
Changing password for user root.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.
```

```
Change password for root in default-image [y/N]: y
Changing password for root in default-image.
Changing password for user root.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.
```

```
Change password for root in node-installer? [y/N]: y
Changing password for root in node-installer.
Changing password for user root.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.
```

```
Change password for MYSQL root user? [y/N]: y
Changing password for MYSQL root user.
Old password:
New password:
Re-enter new password:
```

For a high-availability—also called a failover—configuration, the passwords are copied over automatically to the other head node when a change is made in the software image root password (case 2 on page 11).

For the remaining password cases (head root password, MySQL root password, and node-installer root password), the passwords are best “copied” over to the other head node by simply rerunning the script on the other head node.

Also, in the case of the password for software images used by the regular nodes: the new password that is set for a regular node only works on the node after the image on the node itself has been updated, with, for example, the `imageupdate` command (section 5.6.2). Alternatively, the new password can be made to work on the node by simply rebooting the node to pick up the new image.

The LDAP root password is a random string set during installation. Changing this is not done using `cm-change-password`. It can be changed as explained in Appendix I.

If the administrator has stored the password to the cluster in the Bright View front-end, then the password should be modified there too (figure 2.1).

### 2.3.2 Logins Using `ssh`

The standard system login root password of the head node, the software image, and the node-installer, can be set using the `cm-change-passwd` command (section 2.3.1).

In contrast, `ssh` logins are set by default to be passwordless:

- For non-root users, an `ssh` passwordless login works if the `/home` directory that contains the authorized keys for these users is mounted. The `/home` directory is mounted by default.
- For the root user, an `ssh` passwordless login should always work since the authorized keys are stored in `/root`.

Users can be restricted from `ssh` logins

- on regular nodes using the `usernodelogin` (section 7.2.1) or “User node login” (section 7.2.2) settings.
- on the head node by modifying the `sshd` configuration on the head node. For example, to allow only root logins, the value of `AllowUsers` can be set in `/etc/ssh/sshd_config` to `root`. The man page for `sshd_config` has details on this.

### 2.3.3 Certificates

#### PEM Certificates And CMDaemon Front-end Authentication

While nodes in a Bright Cluster Manager cluster accept ordinary `ssh` based logins, the cluster manager accepts public key authentication using `X509v3` certificates. Public key authentication using `X509v3` certificates means in practice that the person authenticating to the cluster manager must present their public certificate, and in addition must have access to the private key that corresponds to the certificate.

Bright Cluster Manager uses the PEM format for certificates. In this format, the certificate and private key are stored as plain text in two separate PEM-encoded files, ending in `.pem` and `.key`.

**Using `cmsh` and authenticating to the Bright Cluster Manager:** By default, one administrator certificate is created for root for the `cmsh` front end to interact with the cluster manager. The certificate and corresponding private key are thus found on a newly-installed Bright Cluster Manager cluster on the head node at:

```
/root/.cm/admin.pem  
/root/.cm/admin.key
```

The `cmsh` front end, when accessing the certificate and key pair as user `root`, uses this pair by default, so that prompting for authentication is then not a security requirement. The logic that is followed to access the certificate and key by default is explained in detail in item 2 on page 207.

**Using Bright View and authenticating to the Bright Cluster Manager:** When an administrator uses the Bright View front end, a login to the cluster is carried out with username password authentication (figure 2.1), unless the authentication has already been stored in the browser.

If the administrator certificate and key are replaced, then any other certificates signed by the original administrator certificate must be generated again using the replacement, because otherwise they will no longer function.

Certificate generation in general, including the generation and use of non-administrator certificates, is described in greater detail section 6.4.

#### Replacing A Temporary Or Evaluation License

In the preceding section, if a license is replaced, then regular user certificates need to be generated again. Similarly, if a temporary or evaluation license is replaced, regular user certificates need to be generated again. This is because the old user certificates are signed by a key that is no longer valid. The generation of non-administrator certificates and how they function is described in section 6.4.

### 2.3.4 Profiles

Certificates that authenticate to CMDaemon contain a *profile*.

A profile determines which cluster management operations the certificate holder may perform. The administrator certificate is created with the `admin` profile, which is a built-in profile that allows all cluster management operations to be performed. In this sense it is similar to the `root` account on unix systems. Other certificates may be created with different profiles giving certificate owners access to a pre-defined subset of the cluster management functionality (section 6.4).

## 2.4 Bright View GUI

This section introduces the basics of the cluster management GUI (Bright View). Bright View is the web application front end to cluster management in Bright Cluster Manager. It should run without problems on recent (mid-2016 and later) browsers.

### 2.4.1 Installing The Cluster Management GUI Service

The GUI interface is provided by default as a web service on port 8081 from the head node to the browser. The URL takes the form:

```
https://< host name or IP address>:8081/bright-view
```

The Bright Cluster Manager package that provides the service is `bright-view`, and is installed by default with Bright Cluster Manager. The service can be disabled by removing the package.

#### Bright Cluster Manager Bright View Login Window

Figure 2.1 shows the login dialog window for Bright View




Figure 2.1: Editing The Cluster Connection Parameters

#### Bright Cluster Manager Bright View Default Display On Connection

Clicking on the `Login` button logs the administrator into the Bright View service on the cluster. By default an overview window is displayed, corresponding to the path `Cluster→Partition` base (figure 2.2).






Figure 2.2: Cluster Overview

### 2.4.2 Navigating The Cluster With Bright View

Aspects of the cluster can be managed by administrators using Bright View (figure 2.2).

The resource tree, displayed on the left side of the window, consists of cluster usage concepts such as HPC, Big Data, and OpenStack. It also has a cluster-centric approach to miscellaneous system concepts such as hardware devices *Devices*, non-hardware resources such as *Users & Groups*, and *Networking*.

Selecting a resource opens a window that allows parameters related to the resource to be viewed and managed.

As an example, the *Cluster* resource can be selected. This opens up the so-called *Partition base* window, which is essentially a representation of the cluster instance.<sup>1</sup>

The options within the *Partition base* window are mapped out in figure 2.3 and summarily described next.

<sup>1</sup>The name *Partition base* is literally a footnote in Bright Cluster Manager history. It derives from the time that Bright clusters were planned to run in separate partitions within the cluster hardware. The primary cluster was then to be the *base* cluster, running in the *base* partition. The advent of Bright Cluster Manager cloud computing options in the form of the *Cluster-On-Demand* option (Chapter 2 of the *Cloudbursting Manual*), and the *Cluster Extension* option (Chapter 3 of the *Cloudbursting Manual*) means developing cluster partitions is no longer a priority.




Figure 2.3: Cluster Overview Navigation

### Overview

The Overview window has three scrollable overview panes that show current data for the cluster as a whole:

- The top pane, OVERVIEW, shows some system resource information, such as uptime, memory, swap memory.
- The middle pane, WORKLOAD, shows workloads that the cluster is managing.
- The bottom pane, DISKS, shows disk mount points and their use.

### Settings

The Settings window has a number of global cluster properties and property groups. These are loosely grouped as follows:

- Cluster name, Administrator e-mail, Time zone
- Node basename, Node digits

- Name servers, Time servers
- Search domains, Relay Host
- Externally visible IP, Provisioning Node Auto Update Timeout
- BMC Settings
- Default category, Default MIC category, Default software image, Default burn configuration
- External network, Management network
- Sign installer certificates
- Failover: Opens up a window to manage failover properties.
- Failover groups: Opens up a window to manage the failover groups properties.
- Burn configs: Opens up a window to manage burn configuration settings.
- revision

### License info

The `License info` window shows information to do with cluster licensing. A slightly obscure property within this window is `version`, which refers to the version type of the license. The license for Bright Cluster Manager versions 7.0 and above is of a type that is compatible with versions all the way up to 8.0. Bright Cluster Manager license versions from before 7.0 are not compatible. In practice it means that an upgrade from before 7.0, to 7.0 or beyond, requires a license upgrade. Bright Computing must be contacted to arrange the license upgrade.

### Version info

The `Version info` window shows further useful version information for important cluster software.

### Run command

The `Run command` option allows a specified command to be run on a selected node of the cluster. The command can run at periodic intervals using the `Update interval` setting. If `Update interval` is set to 0, then the command is run only once.

## 2.5 Cluster Management Shell

This section introduces the basics of the cluster management shell, `cmsh`. This is the command-line interface to cluster management in Bright Cluster Manager. Since `cmsh` and Bright View give access to the same cluster management functionality, an administrator need not become familiar with both interfaces. Administrators intending to manage a cluster with only Bright View may therefore safely skip this section.

The `cmsh` front end allows commands to be run with it, and can be used in batch mode. Although `cmsh` commands often use constructs familiar to programmers, it is designed mainly for managing the cluster efficiently rather than for trying to be a good or complete programming language. For programming cluster management, the use of Python bindings (Chapter 1 of the *Developer Manual*) is generally recommended instead of using `cmsh` in batch mode.

Usually `cmsh` is invoked from an interactive session (e.g. through `ssh`) on the head node, but it can also be used to manage the cluster from outside.

### 2.5.1 Invoking `cmsh`

From the head node, `cmsh` can be invoked as follows:

#### Example

```
[root@mycluster ~]# cmsh
[mycluster]%
```

By default it connects to the IP address of the local management network interface, using the default Bright Cluster Manager port. If it fails to connect as in the preceding example, but a connection takes place using `cmsh localhost`, then the management interface is most probably not up, and bringing the management interface up then allows `cmsh` to connect to CMDaemon.

Running `cmsh` without arguments starts an interactive cluster management session. To go back to the unix shell, a user enters `quit`:

```
[mycluster]% quit
[root@mycluster ~]#
```

#### Batch Mode And Piping In `cmsh`

The `-c` flag allows `cmsh` to be used in batch mode. Commands may be separated using semi-colons:

```
[root@mycluster ~]# cmsh -c "main showprofile; device status apc01"
admin
apc01 ..... [   UP   ]
[root@mycluster ~]#
```

Alternatively, commands can be piped to `cmsh`:

```
[root@mycluster ~]# echo device status | cmsh
apc01 ..... [   UP   ]
mycluster ..... [   UP   ]
node001 ..... [   UP   ]
node002 ..... [   UP   ]
switch01 ..... [   UP   ]
[root@mycluster ~]#
```

#### Dotfiles And `/etc/cmshrc` File For `cmsh`

In a similar way to unix shells, `cmsh` sources dotfiles, if they exist, upon start-up in both batch and interactive mode. In the following list of dotfiles, a setting in the file that is in the shorter path will override a setting in the file with the longer path (i.e.: “shortest path overrides”):

- `~/.cm/cmsh/.cmshrc`
- `~/.cm/.cmshrc`
- `~/.cmshrc`

If there is no dotfile for the user, then, if it exists, the file `/etc/cmshrc`, which is accessible to all users, is sourced, and its settings used.

Sourcing settings is convenient when defining command aliases. Command aliases can be used to abbreviate longer commands. For example, putting the following in `.cmshrc` would allow `lv` to be used as an alias for `device list virtualnode`:

#### Example

```
alias lv device list virtualnode
```

**Built-in Aliases In `cmsh`**

The following aliases are built-ins, and are not defined in any `.cmshrc` or `cmshrc` files:

```
[bright80]% alias
alias - goto -
alias .. exit
alias / home
alias ? help
alias ds device status
```

**Options Usage For `cmsh`**

The options usage information for `cmsh` is obtainable with `cmsh -h` (figure 2.4).

```
Usage:
  cmsh [options] ..... Connect to localhost using default port
  cmsh [options] <--certificate|-i certfile> <--key|-k keyfile> <host[:port]>
      Connect to a cluster using certificate and key in PEM format
  cmsh [options] <--certificate|-i certfile> [--password|-p password] <uri[:port]>
      Connect to a cluster using certificate in PFX format

Valid options:
--help|-h ..... Display this help
--noconnect|-u ..... Start unconnected
--controlflag|-z ..... ETX in non-interactive mode
--nocolor|-o ..... Do not use misc. colors in the text output
--noredirect|-r ..... Do not follow redirects
--norc|-n ..... Do not load cmshrc file on start-up
--noquitconfirmation|-Q ..... Do not ask for quit confirmation
--command|-c <"c1; c2; ..."> .. Execute commands and exit
--file|-f <filename> ..... Execute commands in file and exit
--echo|-x ..... Echo all commands
--quit|-q ..... Exit immediately after error
--disablemultiline|-m ..... Disable multiline support
```

Figure 2.4: Usage information for `cmsh`

**Man Page For `cmsh`**

There is also a man page for `cmsh(8)`, which is a bit more extensive than the help text. It does not however cover the modes and interactive behavior.

**2.5.2 Levels, Modes, Help, And Commands Syntax In `cmsh`**

The *top-level* of `cmsh` is the level that `cmsh` is in when entered without any options.

To avoid overloading a user with commands, cluster management functionality has been grouped and placed in separate `cmsh modes`. Modes and their levels are a hierarchy available below the top-level, and therefore to perform cluster management functions, a user switches and descends into the appropriate mode.

Figure 2.5 shows the top-level commands available in `cmsh`. These commands are displayed when `help` is typed in at the top-level of `cmsh`:

```

alias ..... Set aliases
bigdata ..... Enter bigdata mode
category ..... Enter category mode
ceph ..... Enter ceph mode
cert ..... Enter cert mode
cloud ..... Enter cloud mode
cmsub ..... Enter cmsub mode
color ..... Manage console text color settings
configurationoverlay ..... Enter configurationoverlay mode
delimiter ..... Display/set delimiter
device ..... Enter device mode
etcd ..... Enter etcd mode
events ..... Manage events
exit ..... Exit from current object or mode
export ..... Display list of aliases current list formats
filesynconfig ..... Enter filesynconfig mode
group ..... Enter group mode
groupingsyntax ..... Manage the default grouping syntax
hadoop ..... Enter hadoop mode
help ..... Display this help
history ..... Display command history
jobqueue ..... Enter jobqueue mode
jobs ..... Enter jobs mode
keyvaluestore ..... Enter keyvaluestore mode
kubernetes..... Enter kubernetes mode
list ..... List state for all modes
main ..... Enter main mode
modified ..... List modified objects
monitoring ..... Enter monitoring mode
network ..... Enter network mode
nodegroup ..... Enter nodegroup mode
openstack ..... Enter openstack mode
partition ..... Enter partition mode
process ..... Enter process mode
profile ..... Enter profile mode
puppet ..... Enter puppet mode
quit ..... Quit shell
quitconfirmation ..... Manage the status of quit confirmation
rack ..... Enter rack mode
refresh ..... Refresh all modes
run ..... Execute cmsh commands from specified file
session ..... Enter session mode
softwareimage ..... Enter softwareimage mode
task ..... Enter task mode
time ..... Measure time of executing command
unalias ..... Unset aliases
user ..... Enter user mode
watch ..... Execute a command periodically, showing output
zookeeper ..... Enter zookeeper mode

```

Figure 2.5: Top level commands in cmsh

All levels inside cmsh provide these top-level commands.  
 Passing a command as an argument to help gets details for it:

### Example

```
[myheadnode]% help run
Name:
    run - Execute all commands in the given file(s)

Usage:
    run [OPTIONS] <filename> [<filename2> ...]

Options:
    -x, --echo
        Echo all commands

    -q, --quit
        Exit immediately after error

[myheadnode]%
```

In the general case, invoking `help` at any level, without an argument, provides two lists:

- Firstly, under the title of `Top`: a list of top-level commands.
- Secondly, under the title of the level it was invoked at: a list of commands that may be used at that level.

For example, entering the `session` level and entering `help` gives firstly, output with a title of `Top`, and secondly, output with a title of `session` (some output ellipsized):

### Example

```
[myheadnode]% session
[myheadnode->session]% help
===== Top =====
...
===== session =====
id ..... Display current session id
killsession ..... Kill a session
list ..... Provide overview of active sessions
[myheadnode->session]%
```

### Navigation Through Modes And Levels In `cmsh`

- To enter a mode, a user enters the mode name at the `cmsh` prompt. The prompt changes to indicate that `cmsh` is in the requested mode, and commands for that mode can then be run.
- To get to an object level within a mode, the `use` command is used with the object name. The prompt then changes to indicate that an object within that mode is now being used, and that commands are applied for that particular object.
- To leave a mode, and go back up a level, the `exit` command is used. At the top level, `exit` has the same effect as the `quit` command, that is, the user leaves `cmsh` and returns to the unix shell. The string `..` is an alias for `exit`.
- The `path` command at any mode depth displays a path to the current mode depth, in a form that is convenient for copying and pasting.
- The `home` command, which is aliased to `/`, takes the user from any mode depth to the top level.

### Example

```
[bright80]% device
[bright80->device]% list
Type                Hostname (key)    MAC                Category
-----
EthernetSwitch      switch01          00:00:00:00:00:00
HeadNode             bright80          00:0C:29:5D:55:46
PhysicalNode         node001           00:0C:29:7A:41:78  default
PhysicalNode         node002           00:0C:29:CC:4F:79  default
[bright80->device]% exit
[bright80]% device
[bright80->device]% use node001
[bright80->device[node001]]% path
home;device;use node001;
[bright80->device[node001]]% home
[bright80]% home;device;use node001    #copy-pasted from path output
[bright80->device[node001]]%
```

A command can also be executed in a mode without staying within that mode. This is done by specifying the mode before the command that is to be executed within that node. Most commands also accept arguments after the command. Multiple commands can be executed in one line by separating commands with semi-colons.

A cmsh input line has the following syntax:

```
<mode> <cmd> <arg> ... <arg>; ...; <mode> <cmd> <arg> ... <arg>
```

where *<mode>* and *<arg>* are optional. <sup>2</sup>

### Example

```
[bright80->network]% device status bright80; list
bright80 ..... [   UP   ]
Name (key)  Type      Netmask bits  Base address  Domain name
-----
externalnet External 16          192.168.1.0   brightcomputing.com
globalnet   Global  0           0.0.0.0       cm.cluster
internalnet Internal 16          10.141.0.0    eth.cluster
[bright80->network]%
```

In the preceding example, while in network mode, the status command is executed in device mode on the host name of the head node, making it display the status of the head node. The list command on the same line after the semi-colon still runs in network mode, as expected, and not in device mode, and so displays a list of networks.

Inserting a semi-colon makes a difference, in that mode is entered, so that the list displays a list of nodes (some output truncated here for convenience):

### Example

```
[bright80->network]% device; status bright80; list
bright80 ..... [   UP   ]
Type                Hostname (key)    MAC                Category
-----
HeadNode             bright80          FA:16:3E:C8:06:D1
PhysicalNode         node001           FA:16:3E:A2:9C:87  default
[bright80->device]%
```

<sup>2</sup> A more precise synopsis is:

```
[<mode>] <cmd> [<arg> ... ] [; ... ; [<mode>] <cmd> [<arg> ... ]]
```



### 2.5.3 Working With Objects

Modes in `cmsh` work with associated groupings of data called *objects*. For instance, `device` mode works with `device` objects, and `network` mode works with `network` objects. The commands used to deal with objects have similar behavior in all modes. Not all of the commands exist in every mode, and not all of the commands function with an explicit object:

Command	Description
<code>use</code>	Use the specified object. I.e.: Make the specified object the <i>current object</i>
<code>add</code>	Create the object and use it
<code>assign</code>	Assign a new object
<code>unassign</code>	Unassign an object
<code>clear</code>	Clear the values of the object
<code>clone</code>	Clone the object and use it
<code>remove</code>	Remove the object
<code>commit</code>	Commit local changes, done to an object, to <code>CMDaemon</code>
<code>refresh</code>	Undo local changes done to the object
<code>list</code>	List all objects at current level
<code>sort</code>	Sort the order of display for the <code>list</code> command
<code>format</code>	Set formatting preferences for <code>list</code> output
<code>foreach</code>	Execute a set of commands on several objects
<code>show</code>	Display all properties of the object
<code>swap</code>	Swap (exchange) the names of two objects
<code>get</code>	Display specified property of the object
<code>set</code>	Set a specified property of the object
<code>clear</code>	Set default value for a specified property of the object.
<code>append</code>	Append a value to a property of the object, for a multi-valued property
<code>removefrom</code>	Remove a value from a specific property of the object, for a multi-valued property
<code>modified</code>	List objects with uncommitted local changes
<code>usedby</code>	List objects that depend on the object
<code>validate</code>	Do a validation check on the properties of the object
<code>exit</code>	Exit from the current object or mode level

Working with objects with these commands is demonstrated with several examples in this section.

**Working With Objects:** `use`, `exit`

#### Example

```
[mycluster->device]% use node001
[mycluster->device[node001]]% status
node001 ..... [  UP  ]
[mycluster->device[node001]]% exit
[mycluster->device]%
```

In the preceding example, `use node001` issued from within `device` mode makes `node001` the *current object*. The prompt changes accordingly. The `status` command, without an argument, then returns status information just for `node001`, because making an object the current object makes subsequent commands within that mode level apply only to that object. Finally, the `exit` command exits the current object level.

**Working With Objects:** add, commit, remove

The commands introduced in this section have many implicit concepts associated with them. So an illustrative session is first presented as an example. What happens in the session is then explained in order to familiarize the reader with the commands and associated concepts.

**Example**

```
[mycluster->device]% add physicalnode node100 10.141.0.100
[mycluster->device*[node100*]]% commit
[mycluster->device[node100]]% category add test-category
[mycluster->category*[test-category*]]% commit
[mycluster->category[test-category]]% remove test-category
[mycluster->category*]% commit
Successfully removed 1 Categories
Successfully committed 0 Categories
[mycluster->category]% device remove node100
[mycluster->category]% device
[mycluster->device*]% commit
Successfully removed 1 Devices
Successfully committed 0 Devices
[mycluster->device]%
```

**add:** The `add` command creates an object within its associated mode, and in `cmsh` the prompt drops into the object level just created. Thus, at the start in the preceding example, within `device` mode, a new object, named `node100`, is added. For this particular object properties can also be set, such as the type (`physicalnode`), and IP address (`10.141.0.100`). The node object level (`[node100*]`) is automatically dropped into from `device` mode when the `add` command is executed. After execution, the state achieved is that the object has been created with some properties. However, it is still in a temporary, modified state, and not yet persistent.

*Asterisk tags* in the prompt are a useful reminder of a modified state, with each asterisk indicating a tagged object that has an unsaved, modified property. In this case, the unsaved properties are the IP address setting, the node name, and the node type.

**commit:** The `commit` command is a further step that actually saves any changes made after executing a command. In this case, in the second line, it saves the `node100` object with its properties. The asterisk tag disappears for the prompt if settings for that mode level or below have been saved.

Conveniently, the top level modes, such as the `category` mode, can be accessed directly from within this level if the mode is stated before the command. So, stating the mode `category` before running the `add` command allows the specified category `test-category` to be added. Again, the `test-category` object level within `category` mode is automatically dropped into when the `add` command is executed.

**remove:** The `remove` command removes a specified object within its associated mode. On successful execution, if the prompt is at the object level, then the prompt moves one level up. The removal is not actually carried out fully yet; it is only a proposed removal. This is indicated by the asterisk tag, which remains visible, until the `commit` command is executed, and the `test-category` removal is saved. The `remove` command can also remove a object in a non-local mode, if the non-local mode is associated with the command. This is illustrated in the example where, from within `category` mode, the `device` mode is declared before running the `remove` command for `node100`. The proposed removal is configured without being made permanent, but in this case no asterisk tag shows up in the `category` mode, because the change is in `device` mode.. To drop into `device` mode, the mode command “`device`” is executed. An asterisk tag then does appear, to remind the administrator that there is still an uncommitted change (the node that is to be removed) for the mode. The `commit` command would remove the

object whichever mode it is in—the non-existence of the asterisk tag does not change the effectiveness of `commit`.

**The `-w|--wait` option to `remove`:** The `commit` command by default does not wait for the state change to complete. This means that the prompt becomes available right away. This means that it is not obvious that the change has taken place, which could be awkward if scripting with `cmsh` for cloning (discussed shortly) a software image (section 2.1.2). The `-w|--wait` option to the `commit` command works around this issue by waiting for the cloning of the software image to be completed before making the prompt available.

**The `add` command—syntax notes:** In most modes the `add` command takes only one argument, namely the name of the object that is to be created. However, in `device` mode an extra object-type, in this case `physicalnode`, is also required as argument, and an optional extra IP argument may also be specified. The response to “`help add`” while in `device` mode gives details:

```
[myheadnode->device]% help add
Name:
  add - Create a new device of the given type with specified hostname

Usage:
  add <type> <hostname>
  add <type> <hostname> <ip>

Arguments:
  type
    cloudnode, physicalnode, virtualnode, virtualsmpnode, headnode, mic,
    ethernetswitch, ibswitch, myrinetswitch, powerdistributionunit,
    genericdevice, racksensor, chassis, gpuunit
```

**Working With Objects:** `clone`, `modified`, `swap`

Continuing on with the node object `node100` that was created in the previous example, it can be cloned to `node101` as follows:

### Example

```
[mycluster->device]% clone node100 node101
Warning: The Ethernet switch settings were not cloned, and have to be set manually
[mycluster->device*[node101*]]% exit
[mycluster->device*]% modified
State  Type                                     Name
-----
+      Device                                 node101
[mycluster->device*]% commit
[mycluster->device]%
[mycluster->device]% remove node100
[mycluster->device*]% commit
[mycluster->device]%
```

The `modified` command is used to check what objects have uncommitted changes, and the new object `node101` that is seen to be modified, is saved with a `commit`. The device `node100` is then removed by using the `remove` command. A `commit` executes the removal.

The “+” entry in the `State` column in the output of the `modified` command in the preceding example indicates the object is a newly added one, but not yet committed. Similarly, a “-” entry indicates an object that is to be removed on committing, while a blank entry indicates that the object has been modified without an addition or removal involved.

Cloning an object is a convenient method of duplicating a fully configured object. When duplicating a device object, `cmsh` will attempt to automatically assign a new IP address using a number of heuristics. In the preceding example, `node101` is assigned IP address `10.141.0.101`.

Sometimes an object may have been misnamed, or physically swapped. For example, `node001` exchanged physically with `node002` in the rack, or the hardware device `eth0` is misnamed by the kernel and should be `eth1`. In that case it can be convenient to simply swap their names via the cluster manager front end rather than change the physical device or adjust kernel configurations. This is equivalent to exchanging all the attributes from one name to the other.

For example, if the two interfaces on the head node need to have their names exchanged, it can be done as follows:

```
[mycluster->device]% use mycluster
[mycluster->device[mycluster]]% interfaces
[mycluster->device[mycluster]->interfaces]% list
Type          Network device name  IP          Network
-----
physical      eth0 [dhcp]          10.150.4.46  externalnet
physical      eth1 [prov]          10.141.255.254 internalnet
[bright80->device[mycluster]->interfaces]% swap eth0 eth1; commit
[bright80->device[mycluster]->interfaces]% list
Type          Network device name  IP          Network
-----
physical      eth0 [prov]          10.141.255.254 internalnet
physical      eth1 [dhcp]          10.150.4.46  externalnet
[mycluster->device[mycluster]->interfaces]% exit; exit
```

#### Working With Objects: get, set, refresh

The `get` command is used to retrieve a specified property from an object, and `set` is used to set it:

#### Example

```
[mycluster->device]% use node101
[mycluster->device[node101]]% get category
test-category
[mycluster->device[node101]]% set category default
[mycluster->device*[node101*]]% get category
default
[mycluster->device*[node101*]]% modified
State Type          Name
-----
Device          node101
[mycluster->device*[node101*]]% refresh
[mycluster->device[node101]]% modified
No modified objects of type device
[mycluster->device[node101]]% get category
test-category
[mycluster->device[node101]]%
```

Here, the `category` property of the `node101` object is retrieved by using the `get` command. The property is then changed using the `set` command. Using `get` confirms that the value of the property has changed, and the `modified` command reconfirms that `node101` has local uncommitted changes. The `refresh` command undoes the changes made, and the `modified` command confirms that no local changes exist. Finally the `get` command reconfirms that no local changes exist.

A string can be set as a revision label for any object:

#### Example

```
[mycluster->device[node101]]% set revision "changed on 10th May"
[mycluster->device*[node101*]]% get revision
[mycluster->device*[node101*]]% changed on 10th May 2011
```

This can be useful when using shell scripts with an input text to label and track revisions when sending commands to `cmsh`. How to send commands from the shell to `cmsh` is introduced in section 2.5.1.

Some properties are Booleans. For these, the values “yes”, “1”, “on” and “true” are equivalent to each other, as are their opposites “no”, “0”, “off” and “false”. These values are case-insensitive.

#### Working With Objects: `clear`

##### Example

```
[mycluster->device]% set node101 mac 00:11:22:33:44:55
[mycluster->device*]% get node101 mac
00:11:22:33:44:55
[mycluster->device*]% clear node101 mac
[mycluster->device*]% get node101 mac
00:00:00:00:00:00
[mycluster->device*]%
```

The `get` and `set` commands are used to view and set the MAC address of `node101` without running the `use` command to make `node101` the *current object*. The `clear` command then unsets the value of the property. The result of `clear` depends on the type of the property it acts on. In the case of string properties, the empty string is assigned, whereas for MAC addresses the special value `00:00:00:00:00:00` is assigned.

#### Working With Objects: `list`, `format`, `sort`

The `list` command is used to list all `device` objects. The `-f` flag takes a format string as argument. The string specifies what properties are printed for each object, and how many characters are used to display each property in the output line. In following example a list of objects is requested, displaying the `hostname`, `ethernet switch` and `ip` properties for each object.

##### Example

```
[bright80->device]% list -f hostname:14,ethernet switch:15,ip
hostname (key) ethernet switch ip
-----
apc01                                10.142.254.1
bright80      switch01:46          10.142.255.254
node001        switch01:47          10.142.0.1
node002        switch01:45          10.142.0.2
switch01                                10.142.253.1
[bright80->device]%
```

Running the `list` command with no argument uses the current format string for the mode.

Running the `format` command without arguments displays the current format string, and also displays all available properties including a description of each property. For example (output truncated):

##### Example

```
[bright80->device]% format
Current list printing format:
-----
hostname:[10-14]

Valid fields:
```

```

-----
Revision          : Entity revision
Type              : The type of the device
activation         : Date on which node was defined
additionalhostnames : Additional hostnames that should resolve to the interfaces IP address
banks             : Number of banks
...

```

To change the current format string, a new format string can be passed as an argument to `format`.

The print specification of the `format` command uses the delimiter ":" to separate the parameter and the value for the width of the parameter column. For example, a width of 10 can be set with:

### Example

```

[bright80->device]% format hostname:10
[bright80->device]% list
hostname (
-----
apc01
bright80
node001
node002
switch01

```

A range of widths can be set, from a minimum to a maximum, using square brackets. A single minimum width possible is chosen from the range that fits all the characters of the column. If the number of characters in the column exceeds the maximum, then the maximum value is chosen. For example:

### Example

```

[bright80->device]% format hostname:[10-14]
[bright80->device]% list
hostname (key)
-----
apc01
bright80
node001
node002
switch01

```

The parameters to be viewed can be chosen from a list of valid fields by running the `format` command without any options, as shown earlier.

Multiple parameters can be specified as a comma-separated list (with a colon-delimited width specification for each parameter). For example:

### Example

```

[bright80->device]% format hostname:[10-14],ethernet switch:14,ip:20
[bright80->device]% list
hostname (key) ethernet switch  ip
-----
apc01                                10.142.254.1
bright80      switch01:46    10.142.255.254
node001        switch01:47    10.142.0.1
node002        switch01:45    10.142.0.2
switch01                                10.142.253.1

```

The default parameter settings can be restored with the `-r|--reset` option:

### Example

```
[bright80->device]% format -r
[bright80->device]% format | head -3
Current list printing format:
-----
type:22, hostname:[16-32], mac:18, category:[16-32], ip:15, network:[14-32], status:[16-32]
[bright80->device]%
```

The `sort` command sets the alphabetical sort order for the output of the `list` according precedence of the parameters specified.

### Example

```
[bright80->device]% sort type mac
[bright80->device]% list -f type:15,hostname:15,mac
type           hostname (key)  mac
-----
HeadNode       bright80      08:0A:27:BA:B9:43
PhysicalNode    node002         00:00:00:00:00:00
PhysicalNode    log001          52:54:00:DE:E3:6B
[bright80->device]% sort type hostname
[bright80->device]% list -f type:15,hostname:15,mac
type           hostname (key)  mac
-----
HeadNode       bright80      08:0A:27:BA:B9:43
PhysicalNode    log001          52:54:00:DE:E3:6B
PhysicalNode    node002         00:00:00:00:00:00

[bright80->device]% sort mac hostname
[bright80->device]% list -f type:15,hostname:15,mac
type           hostname (key)  mac
-----
PhysicalNode    node002         00:00:00:00:00:00
HeadNode       bright80      08:0A:27:BA:B9:43
PhysicalNode    log001          52:54:00:DE:E3:6B
```

The preceding `sort` commands can alternatively be specified with the `-s|--sort` option to the `list` command:

```
[bright80->device]% list -f type:15,hostname:15,mac --sort type,mac
[bright80->device]% list -f type:15,hostname:15,mac --sort type,hostname
[bright80->device]% list -f type:15,hostname:15,mac --sort mac,hostname
```

### Working With Objects: `append`, `removefrom`

When dealing with a property of an object that can take more than one value at a time—a list of values—the `append` and `removefrom` commands can be used to respectively append to and remove elements from the list. If more than one element is appended, they should be space-separated. The `set` command may also be used to assign a new list at once, overwriting the existing list. In the following example values are appended and removed from the `powerdistributionunits` properties of device `node001`. The `powerdistributionunits` properties represent the list of ports on power distribution units that a particular device is connected to. This information is relevant when power operations are performed on a node. Chapter 4 has more information on power settings and operations.

### Example

```
[mycluster->device]% use node001
[mycluster->device[node001]]% get powerdistributionunits
apc01:1
[...device[node001]]% append powerdistributionunits apc01:5
[...device*[node001*]]% get powerdistributionunits
apc01:1 apc01:5
[...device*[node001*]]% append powerdistributionunits apc01:6
[...device*[node001*]]% get powerdistributionunits
apc01:1 apc01:5 apc01:6
[...device*[node001*]]% removefrom powerdistributionunits apc01:5
[...device*[node001*]]% get powerdistributionunits
apc01:1 apc01:6
[...device*[node001*]]% set powerdistributionunits apc01:1 apc01:02
[...device*[node001*]]% get powerdistributionunits
apc01:1 apc01:2
```

#### Working With Objects: `usedby`

Removing a specific object is only possible if other objects do not have references to it. To help the administrator discover a list of objects that depend on (“use”) the specified object, the `usedby` command may be used. In the following example, objects depending on device `apc01` are requested. The `usedby` property of `powerdistributionunits` indicates that device objects `node001` and `node002` contain references to (“use”) the object `apc01`. In addition, the `apc01` device is itself displayed as being in the up state, indicating a dependency of `apc01` on itself. If the device is to be removed, then the 2 references to it first need to be removed, and the device also first has to be brought to the `CLOSED` state (page 170) by using the `close` command.

#### Example

```
[mycluster->device]% usedby apc01
Device used by the following:
Type           Name           Parameter
-----
Device         apc01           Device is up
Device         node001          powerDistributionUnits
Device         node002          powerDistributionUnits
[mycluster->device]%
```

#### Working With Objects: `validate`

Whenever committing changes to an object, the cluster management infrastructure checks the object to be committed for consistency. If one or more consistency requirements are not met, then `cmsh` reports the violations that must be resolved before the changes are committed. The `validate` command allows an object to be checked for consistency without committing local changes.

#### Example

```
[mycluster->device]% use node001
[mycluster->device[node001]]% clear category
[mycluster->device*[node001*]]% commit
Code  Field           Message
-----
1     category        The category should be set
[mycluster->device*[node001*]]% set category default
[mycluster->device*[node001*]]% validate
All good
[mycluster->device*[node001*]]% commit
[mycluster->device[node001]]%
```



**Working With Objects:** `show`

The `show` command is used to show the parameters and values of a specific object. For example for the object `node001`, the attributes displayed are (some output ellipsized):

```
[mycluster->device[node001]]% show
Parameter                                         Value
-----
Activation                                       Thu, 03 Aug 2017 15:57:42 CEST
BMC Settings                                    <submode>
Block devices cleared on next boot
Burn config                                     <0 bytes>
Burning                                         no
...
Data node                                       no
Default gateway                               10.141.255.254 (network: internalnet)
...
Software image                                 default-image
Start new burn                                 no
Static routes                                 <0 in submode>
...
```

**Working With Objects:** `assign`, `unassign`

The `assign` and `unassign` commands are analogous to `add` and `remove`. The difference between `assign` and `add` from the system administrator point of view is that `assign` sets an object with settable properties from a choice of existing names, whereas `add` sets an object with settable properties that include the name that is to be given. This makes `assign` suited for cases where multiple versions of a specific object choice cannot be used.

For example,

- If a node is to be configured to be run with particular Slurm settings, then the node can be assigned an `slurmclient` role (section 2.1.5) with the `assign` command. The node cannot be assigned another `slurmclient` role with other Slurm settings at the same time. Only the settings within the assigned Slurm client role can be changed.
- If a node is to be configured to run with added interfaces `eth3` and `eth4`, then the node can have both physical interfaces added to it with the `add` command.

The only place where the `assign` command is currently used within `cmsh` is within the `roles` submode, available under the main `category` mode or the main `device` mode. Within `roles`, `assign` is used for assigning tasklike `roles` objects.

**2.5.4 Accessing Cluster Settings**

The management infrastructure of Bright Cluster Manager is designed to allow cluster partitioning in the future. A cluster partition can be viewed as a virtual cluster inside a real cluster. The cluster partition behaves as a separate cluster while making use of the resources of the real cluster in which it is contained. Although cluster partitioning is not yet possible in the current version of Bright Cluster Manager, its design implications do decide how some global cluster properties are accessed through `cmsh`.

In `cmsh` there is a `partition` mode which will, in a future version, allow an administrator to create and configure cluster partitions. Currently, there is only one fixed partition, called `base`. The `base` partition represents the physical cluster as a whole and cannot be removed. A number of properties global to the cluster exist inside the `base` partition. These properties are referenced and explained in remaining parts of this manual.

**Example**

```
[root@myheadnode ~]# cmsh
[myheadnode]% partition use base
[myheadnode->partition[base]]% show
```

Parameter	Value
Administrator e-mail	
BMC Settings	<submode>
Burn configs	<2 in submode>
Cluster name	my-cluster
Default MIC category	
Default burn configuration	default-destructive
Default category	default
Default software image	default-image
External network	externalnet
Externally visible IP	
Failover	not defined
Failover groups	<0 in submode>
Headnode	my-headnode
Lustre settings	<submode>
Management network	internalnet
Name	base
Name servers	192.168.101.1
Name servers from dhcp	4.2.2.4
No zero conf	no
Node basename	node
Node digits	3
Notes	<0 bytes>
Provisioning Node Auto Update Timeout	300
Relay Host	
Revision	
Search domains	example.com
Sign installer certificates	AUTO
Time servers	0.pool.ntp.org,1.pool.ntp.org,2.pool.ntp.org
Time zone	America/Los_Angeles
UCS Profiles	<0 in submode>

### 2.5.5 Advanced cmsh Features

This section describes some advanced features of cmsh and may be skipped on first reading.

#### Command Line Editing

Command line editing and history features from the readline library are available. <http://tiswww.case.edu/php/chet/readline/rluserman.html> provides a full list of key-bindings.

For users who are reasonably familiar with the bash shell running with readline, probably the most useful and familiar features provided by readline within cmsh are:

- tab-completion of commands and arguments
- being able to select earlier commands from the command history using <ctrl>-r, or using the up- and down-arrow keys

#### History And Timestamps

The history command within cmsh explicitly displays the cmsh command history as a list.

The `--timestamps|-t` option to the history command displays the command history with timestamps.

#### Example

```
[bright80->device[node001]]% history | tail -3
162 use node001
163 history
164 history | tail -3
[bright80->device[node001]]% history -t | tail -3
163 Thu Dec 3 15:15:18 2015 history
164 Thu Dec 3 15:15:43 2015 history | tail -3
165 Thu Dec 3 15:15:49 2015 history -t | tail -3
```

### Mixing cmsh And Unix Shell Commands

It is often useful for an administrator to be able to execute unix shell commands while carrying out cluster management tasks. The cluster manager shell, `cmsh`, therefore allows users to execute commands in a subshell if the command is prefixed with a “!” character:

#### Example

```
[mycluster]% !hostname -f
mycluster.cm.cluster
[mycluster]%
```

Executing the `!` command by itself will start an interactive login sub-shell. By exiting the sub-shell, the user will return to the `cmsh` prompt.

Besides simply executing commands from within `cmsh`, the output of operating system shell commands can also be used within `cmsh`. This is done by using the “backtick syntax” available in most unix shells.

#### Example

```
[mycluster]% device use `hostname`
[mycluster->device[mycluster]]% status
mycluster ..... [ UP ]
[mycluster->device[mycluster]]%
```

### Output Redirection

Similar to unix shells, `cmsh` also supports output redirection to the shell through common operators such as `>`, `>>` and `|`.

#### Example

```
[mycluster]% device list > devices
[mycluster]% device status >> devices
[mycluster]% device list | grep node001
```

Type	Hostname (key)	MAC (key)	Category
PhysicalNode	node001	00:E0:81:2E:F7:96	default

### The ssh Command

The `ssh` command is run from within the device mode of `cmsh`. If an `ssh` session is launched from within `cmsh`, then it clears the screen and is connected to the specified node. Exiting from the `ssh` session returns the user back to the `cmsh` launch point.

#### Example

```
[bright80]% device ssh node001
<screen is cleared>
<some MOTD text and login information is displayed>
[root@node001 ~]# exit
```

```

Connection to node001 closed.
[bright80]% device use bright80
[bright80->device[bright80]]% #now let us connect to the head node from the head node object
[bright80->device[bright80]]% ssh
<screen is cleared>
<some MOTD text and login information is displayed>
[root@bright80 ~]# exit
logout
Connection to bright80 closed.
[bright80->device[bright80]]%

```

An alternative to running `ssh` within `cmsh` is to launch it in a subshell anywhere from within `cmsh`, by using `!ssh`.

### The `time` Command

The `time` command within `cmsh` is a simplified version of the standard unix `time` command.

The `time` command takes as its argument a second command that is to be executed within `cmsh`. On execution of the `time` command, the second command is executed. After execution of the `time` command is complete, the time the second command took to execute is displayed.

#### Example

```

[bright80->device]% time ds node001
node001 ..... [ UP ]
time: 0.108s

```

### The `watch` Command

The `watch` command within `cmsh` is a simplified version of the standard unix `watch` command.

The `watch` command takes as its argument a second command that is to be executed within `cmsh`. On execution of the `watch` command, the second command is executed every 2 seconds by default, and the output of that second command is displayed.

The repeat interval of the `watch` command can be set with the `--interval|-n` option. A running `watch` command can be interrupted with a `<Ctrl>-c`.

#### Example

```

[bright80->device]% watch newnodes
screen clears
Every 2.0s: newnodes Thu Dec 3 13:01:45 2015
No new nodes currently available.

```

#### Example

```

[bright80->device]% watch -n 3 status -n node001,node002
screen clears
Every 3.0s: status -n node001,node002 Thu Jun 30 17:53:21 2016
node001 .....[ UP ]
node002 .....[ UP ]

```

### Looping Over Objects With `foreach`

It is frequently convenient to be able to execute a `cmsh` command on several objects at once. The `foreach` command is available in a number of `cmsh` modes for this purpose. A `foreach` command takes a list of space-separated object names (the keys of the object) and a list of commands that must be enclosed by parentheses, i.e.: “(” and “)”. The `foreach` command will then iterate through the objects, executing the list of commands on the iterated object each iteration.

**Basic syntax for the `foreach` command:** The basic `foreach` syntax is:

```
foreach <object1> <object2> ... ( <command1>; <command2> ... )
```

### Example

```
[mycluster->device]% foreach node001 node002 (get hostname; status)
node001
node001 ..... [ UP ]
node002
node002 ..... [ UP ]
[mycluster->device]%
```

With the `foreach` command it is possible to perform `set` commands on groups of objects simultaneously, or to perform an operation on a group of objects.

**Advanced options for the `foreach` command:** The `foreach` command advanced options can be viewed from the help page:

```
[root@bright80 ~]# cmsh -c "device help foreach"
```

The options can be classed as: grouping options, adding options, conditional options, and looping options.

- **Grouping options:** `-n|--nodes`, `-g|--group`, `-g|--category`, `-r|--rack`, `-h|--chassis`, `-e|--overlay`, `-l|--role`

In the device mode of `cmsh`, for example, the `foreach` command has grouping options for selecting devices. These options can be used to select the nodes to loop over, instead of passing a list of objects to `foreach` directly. For example, the `--category` (`-c`) option takes a node category argument, while the `--node` (`-n`) option takes a node-list argument. Node-lists (specification on page 37) can use the following syntax:

```
<node>, ..., <node>, <node> .. <node>
```

### Example

```
[demo->device]% foreach -c default (status)
node001 ..... [ DOWN ]
node002 ..... [ DOWN ]
[demo->device]% foreach -g rack8 (status)
...
[demo->device]% foreach -n node001,node008..node016,node032 (status)
...
[demo->device]%
```

- **Adding options:** `--clone`, `--add`

The `--clone` (`-o`) option allows the cloning (section 2.5.3) of objects in a loop. In the following example, from device mode, `node001` is used as the base object from which other nodes from `node022` up to `node024` are cloned:

### Example

```
[bright80->device]% foreach --clone node001 -n node022..node024 ( )
[bright80->device*]% list | grep node
Type           Hostname (key) Ip
```

```

-----
PhysicalNode  node001      10.141.0.1
PhysicalNode  node022      10.141.0.22
PhysicalNode  node023      10.141.0.23
PhysicalNode  node024      10.141.0.24
[bright80->device*]% commit

```

To avoid possible confusion: the cloned objects are merely objects (placeholder schematics and settings, with some different values for some of the settings, such as IP addresses, decided by heuristics). So it is explicitly not the software disk image of `node001` that is duplicated by object cloning to the other nodes by this action at this time.

The `--add (-a)` option creates the device for a specified device type, if it does not exist. Valid types are shown in the help output, and include `physicalnode`, `headnode`, `ibswitch`.

- **Conditional options:** `--status`, `--quitionunknown`

The `--status (-s)` option allows nodes to be filtered by the device status (section 2.1.1).

### Example

```

[bright80->device]% foreach -n node001..node004 --status UP (get IP)
10.141.0.1
10.141.0.3

```

The `--quitionunknown (-q)` option allows the `foreach` loop to be exited when an unknown command is detected.

- **Looping options:** `*`, `--verbose`

The wildcard character `*` with `foreach` implies all the objects that the `list` command lists for that mode. It is used without grouping options:

### Example

```

[myheadnode->device]% foreach * (get ip; status)
10.141.253.1
switch01 ..... [ DOWN ]
10.141.255.254
myheadnode ..... [ UP ]
10.141.0.1
node001 ..... [ CLOSED ]
10.141.0.2
node002 ..... [ CLOSED ]
[myheadnode->device]%

```

Another example that lists all the nodes per category, by running the `listnodes` command within category mode:

### Example

```

[bright80->category]% foreach * (get name; listnodes)
default
Type      Hostname  MAC              Category  Ip          Network        Status
-----
PhysicalNode  node001  FA:16:3E:79:4B:77  default  10.141.0.1  internalnet  [ UP ]
PhysicalNode  node002  FA:16:3E:41:9E:A8  default  10.141.0.2  internalnet  [ UP ]
PhysicalNode  node003  FA:16:3E:C0:1F:E1  default  10.141.0.3  internalnet  [ UP ]

```

The `--verbose (-v)` option displays the loop headers during a running loop with time stamps, which can help in debugging.

**Node List Syntax**

Node list specifications, as used in the `foreach` specification and elsewhere, can be of several types. These types are best explained with node list specification examples:

- **adhoc (with a comma):**  
example: `node001,node003,node005,node006`
- **sequential (with two dots or square brackets):**  
example: `node001..node004`  
or, equivalently: `node00[1-4]`  
which is: `node001,node002,node003,node004`
- **sequential extended expansion (only for square brackets):**  
example: `node[001-002]s[001-005]`  
which is:  
`node001s001 node001s002 node001s003 node001s004 node001s005`  
`node002s001 node002s002 node002s003 node002s004 node002s005`
- **rack-based:**  
This is intended to hint which rack a node is located in. Thus:
  - example: `r[1-2]n[01-03]`  
which is: `r1n01,r1n02,r1n03,r2n01,r2n02,r2n03`  
This might hint at two racks, `r1` and `r2`, with 3 nodes each.
  - example: `rack[1-2]node0[1-3]`  
which is: `rack1node01,rack1node02,rack1node03,rack2node01,rack2node02,rack2node03`  
Essentially the same as the previous one, but for nodes that were named more verbosely.
- **sequential exclusion (negation):**  
example: `node001..node005,-node002..node003`  
which is: `node001,node004,node005`
- **sequential stride (every <stride> steps):**  
example: `node00[1..7:2]`  
which is: `node001,node003,node005,node007`
- **mixed list:**  
The square brackets and the two dots input specification cannot be used at the same time in one argument. Other than this, specifications can be mixed:
  - example: `r1n001..r1n003,r2n003`  
which is: `r1n001,r1n002,r1n003,r2n003`
  - example: `r2n003,r[3-5]n0[01-03]`  
which is: `r2n003,r3n001,r3n002,r3n003,r4n001,r4n002,r4n003,r5n001,r5n002,r5n003`
  - example: `node[001-100],-node[004-100:4]`  
which is: every node in the 100 nodes, except for every fourth node.

**Setting grouping syntax with the `groupingsyntax` command:** “Grouping syntax” here refers to usage of dots and square brackets. In other words, it is syntax of how a grouping is marked so that it is accepted as a list. The list that is specified in this manner can be for input or output purposes.

The `groupingsyntax` command sets the grouping syntax using the following options:

- `bracket`: the square brackets specification.
- `dot`: the two dots specification.
- `auto`: the default. Setting `auto` means that:
  - either the `dot` or the `bracket` specification are accepted as input,
  - the `dot` specification is used for output.

The chosen `groupingsyntax` option can be made persistent by adding it to the `cmshrc` dotfiles, or to `/etc/cmshrc` (section 2.5.1).

### Example

```
[root@bright80 ~]# cat .cm/cmsh/.cmshrc
groupingsyntax auto
```

### The bookmark And goto Commands

**Bookmarks:** A *bookmark* in `cmsh` is a location in the `cmsh` hierarchy.

A bookmark can be

- set with the `bookmark` command
- reached using the `goto` command

A bookmark is set with arguments to the `bookmark` command within `cmsh` as follows:

- The user can set the current location as a bookmark:
  - by using no argument. This is the same as setting no name for it
  - by using an arbitrary argument. This is the same as setting an arbitrary name for it
- Apart from any user-defined bookmark names, `cmsh` automatically sets the special name: `"-"`. This is always the previous location in the `cmsh` hierarchy that the user has just come from.

All bookmarks that have been set can be listed with the `-l|--list` option.

**Reaching a bookmark:** A bookmark can be reached with the `goto` command. The `goto` command can take the following as arguments: a blank (no argument), any arbitrary bookmark name, or `"-"`. The bookmark corresponding to the chosen argument is then reached.

### Example

```
[mycluster]% device use node001
[mycluster->device[node001]]% bookmark
[mycluster->device[node001]]% bookmark -l
Name                Bookmark
-----
-                    home;device;use node001;
-                    home;
[mycluster->device[node001]]% home
[mycluster]% goto
[mycluster->device[node001]]% goto -
[mycluster]% goto
[mycluster->device[node001]]% bookmark dn1
[mycluster->device[node001]]% goto -
[mycluster]% goto dn1
[mycluster->device[node001]]%
```



**Saving bookmarks, and making them persistent:** Bookmarks can be saved to a file, such as `mysaved`, with the `-s|--save` option, as follows:

#### Example

```
[mycluster]% bookmark -s mysaved
```

Bookmarks can be made persistent by setting `(.)cmshrc` files (page 18) to load a previously-saved bookmarks file whenever a new `cmsh` session is started. The `bookmark` command loads a saved bookmark file using the `-x|--load` option.

#### Example

```
[root@bright80 ~]# cat .cm/cmsh/.cmshrc
bookmark -x mysaved
```

## 2.6 Cluster Management Daemon

The *cluster management daemon* or *CMDaemon* is a server process that runs on all nodes of the cluster (including the head node). The cluster management daemons work together to make the cluster manageable. When applications such as `cmsh` and Bright View communicate with the cluster, they are actually interacting with the cluster management daemon running on the head node. Cluster management applications never communicate directly with cluster management daemons running on non-head nodes.

The *CMDaemon* application starts running on any node automatically when it boots, and the application continues running until the node shuts down. Should *CMDaemon* be stopped manually for whatever reason, its cluster management functionality becomes unavailable, making it hard for administrators to manage the cluster. However, even with the daemon stopped, the cluster remains fully usable for running computational jobs using a workload manager.

The only route of communication with the cluster management daemon is through TCP port 8081. The cluster management daemon accepts only SSL connections, thereby ensuring all communications are encrypted. Authentication is also handled in the SSL layer using client-side X509v3 certificates (section 2.3).

On the head node, the cluster management daemon uses a MySQL database server to store all of its internal data. Raw monitoring data, on the other hand, is stored as binary data outside of the MySQL database (section 13.8).

### 2.6.1 Controlling The Cluster Management Daemon

It may be useful to shut down or restart the cluster management daemon. For instance, a restart may be necessary to activate changes when the cluster management daemon configuration file is modified. The cluster management daemon operation can be controlled through the following init script arguments to `service cmd`:

Service Operation For <code>cmd</code>	Description
<code>stop</code>	stop the cluster management daemon
<code>start</code>	start the cluster management daemon
<code>restart</code>	restart the cluster management daemon

...continues

...continued

Service Operation For cmd	Description
status	report whether cluster management daemon is running
full-status	report detailed statistics about cluster management daemon
upgrade	update database schema after version upgrade ( <i>expert only</i> )
debugon	enable debug logging ( <i>expert only</i> )
debugoff	disable debug logging ( <i>expert only</i> )

### Example

Restarting the cluster management daemon on the head node of a cluster:

```
[root@mycluster ~]# service cmd restart
Redirecting to /bin/systemctl restart cmd.service
[root@mycluster ~]#
```

### Example

Viewing the resources used by CMDaemon, and some other useful information:

```
[root@bright80 etc]# service cmd full-status
CMDaemon version 1.7 is running (active).

Current Time: Thu, 03 Dec 2015 15:43:20 CET
Startup Time: Thu, 03 Dec 2015 15:42:30 CET
Uptime: 50 seconds

CPU Usage: 4.20251u 1.17037s (10.7%)
Memory Usage: 98.9MB

Sessions Since Startup: 7
Active Sessions: 7

Number of occupied worker-threads: 1
Number of free worker-threads: 11

Connections handled: 119
Requests processed: 119
Total read: 324.7KB
Total written: 42.8KB

Average request rate: 2.38 requests/s
Average bandwidth usage: 6.5KB/s
```

### Example

Restarting the cluster management daemon on a sequence of regular nodes, node001 to node040, of a cluster:

```
[root@mycluster ~]# pdsh -w node00[1-9],node0[1-3][0-9],node040 service cmd restart
```

This uses `pdsh`, the parallel shell command (section 13.1).

### 2.6.2 Configuring The Cluster Management Daemon

Many cluster configuration changes can be done by modifying the cluster management daemon configuration file. For the head node, the file is located at:

```
/cm/local/apps/cmd/etc/cmd.conf
```

For regular nodes, it is located inside of the software image that the node uses.

Appendix C describes the supported configuration file directives and how they can be used. Normally there is no need to modify the default settings.

After modifying the configuration file, the cluster management daemon must be restarted to activate the changes.

### 2.6.3 Configuring The Cluster Management Daemon Logging Facilities

CMDaemon generates log messages from specific internal subsystems, such as Workload Management, Service Management, Monitoring, Certs, and so on. By default, none of those subsystems generate detailed (debug-level) messages, as that would make the log file grow rapidly.

#### CMDaemon Global Debug Mode

It is possible to enable a global debug mode in CMDaemon using `cmdaemonctl`:

##### Example

```
[root@bright80 ~]# cmdaemonctl -h
cmdaemonctl [OPTIONS...] COMMAND ...
```

Query or send control commands to the cluster manager daemon.

```
-h --help          Show this help
```

Commands:

```
debugon           Turn on CMDaemon debug
debugoff          Turn off CMDaemon debug
full-status       Display CMDaemon status
```

```
[root@bright80 ~]# cmdaemonctl debugon
CMDaemon debug level on
```

Stopping debug level logs from running for too long by executing `cmdaemonctl debugoff` is a good idea, especially for production clusters. This is important in order to prevent swamping the cluster with unfeasibly large logs.

#### CMDaemon Subsystem Debug Mode

CMDaemon subsystems can generate debug logs separately per subsystem, including by severity level. This can be done by modifying the logging configuration file at:

```
/cm/local/apps/cmd/etc/logging.cmd.conf
```

Within this file, a section with a title of `#Available Subsystems` lists the available subsystems that can be monitored. These subsystems include MON (for monitoring), DB (for database), HA (for high availability), CERTS (for certificates), CEPH (for Ceph), OPENSTACK (for OpenStack), and so on.

For example, to set only CMDaemon debug output for Monitoring, at a severity level of warning, the file contents for the section `severity` might look like:

##### Example

```
Severity {
    warning: MON
}
```

Further details on setting debug options are given within the `logging.cmd.conf` file.

The logging configuration can be reloaded without having to restart CMDaemon, by restarting the `rsyslogd` system messages logger service with:

### Example

```
[root@bright80 etc]# systemctl restart rsyslog.service
```

## 2.6.4 Configuration File Modification, And The `FrozenFile` Directive

As part of its tasks, the cluster management daemon modifies a number of system configuration files. Some configuration files are completely replaced, while other configuration files only have some sections modified. Appendix A lists all system configuration files that are modified.

A file that has been generated entirely by the cluster management daemon contains a header:

```
# This file was automatically generated by cmd. Do not edit manually!
```

Such a file will be entirely overwritten, unless the `FrozenFile` configuration file directive (Appendix C, page 597) is used to keep it frozen.

Sections of files that have been generated by the cluster management daemon will read as follows:

```
# This section of this file was automatically generated by cmd. Do not edit manually!
# BEGIN AUTOGENERATED SECTION -- DO NOT REMOVE
...
# END AUTOGENERATED SECTION    -- DO NOT REMOVE
```

Such a file has only the auto-generated sections entirely overwritten, unless the `FrozenFile` configuration file directive is used to keep these sections frozen.

The `FrozenFile` configuration file directive in `cmd.conf` is set as suggested by this example:

### Example

```
FrozenFile = { "/etc/dhcpd.conf", "/etc/postfix/main.cf" }
```

If the generated file or section of a file has a manually modified part, and when not using `FrozenFile`, then during overwriting an event is generated, and the manually modified configuration file is backed up to:

```
/var/spool/cmd/saved-config-files
```

Using `FrozenFile` can be regarded as a configuration technique (section 3.15.3), and one of various possible configuration techniques (section 3.15.1).

## 2.6.5 Configuration File Conflicts Between The Standard Distribution And Bright Cluster Manager For Generated And Non-Generated Files

While Bright Cluster Manager changes as little as possible of the standard distributions that it manages, there can sometimes be unavoidable issues. In particular, sometimes a standard distribution utility or service generates a configuration file that conflicts with what the configuration file generated by Bright Cluster Manager carries out (Appendix A).

For example, the Red Hat security configuration tool `system-config-securitylevel` can conflict with what `shorewall` (section 7.2 of the *Installation Manual*) does, while the Red Hat Authentication Configuration Tool `authconfig` (used to modify the `/etc/pam.d/system-auth` file) can conflict with the configuration settings set by Bright Cluster Manager for LDAP and PAM.

In such a case the configuration file generated by Bright Cluster Manager must be given precedence, and the generation of a configuration file from the standard distribution should be avoided. Sometimes using a fully or partially frozen configuration file (section 2.6.4) allows a workaround. Otherwise, the

functionality of the Bright Cluster Manager version usually allows the required configuration function to be implemented.

Details on the configuration files installed and updated by the package management system, for files that are “non-generated” (that is, not of the kind in section 2.6.4 or in the lists in Appendixes A.1, A.2 and A.3), are given in Appendix A.4.



# 3

## Configuring The Cluster

After Bright Cluster Manager software has been installed on the head node, the cluster must be configured. For convenience, the regular nodes on the cluster use a default software image stored on the head node. The image is supplied to the regular nodes during a process called provisioning (Chapter 5), and both the head node and the regular nodes can have their software modified to suit exact requirements (Chapter 11). This chapter however goes through a number of basic cluster configuration aspects that are required to get all the hardware up and running on the head and regular nodes.

Section 3.1 explains how some of the main cluster configuration settings can be changed.

Section 3.2 details how the internal and external network parameters of the cluster can be changed.

Section 3.3 describes the setting up of network bridge interfaces.

Section 3.4 describes VLAN configuration.

Section 3.5 describes the setting up of network bond interfaces.

Section 3.6 covers how InfiniBand and Omni-Path are set up.

Section 3.7 describes how Baseboard Management Controllers such as IPMI and iLO are set up.

Section 3.8 describes how switches are set up.

Section 3.9 explains how disk layouts are configured, as well as how diskless nodes are set up.

Section 3.10 describes how NFS volumes are exported from an NFS server and mounted to nodes using the integrated approach of Bright Cluster Manager.

Section 3.11 describes how services can be run from Bright Cluster Manager.

Section 3.12 describes how a rack can be configured and managed with Bright Cluster Manager.

Section 3.13 describes how a GPU unit such as the Dell PowerEdge C410x can be configured with Bright Cluster Manager.

Section 3.14 describes how custom scripts can replace some of the default scripts in use.

Section 3.15 discusses configuration alternatives that are not based on CMDaemon.

More elaborate aspects of cluster configuration such as power management, user management, package management, and workload management are covered in later chapters.

### 3.1 Main Cluster Configuration Settings




Figure 3.1: Cluster Settings

In Bright View, the Settings window for the Cluster resource (figure 3.1), which represents the overall cluster object, allows changes to be made to some of the main cluster settings. The values can in some cases be overridden by more specific configuration levels, such as category-level or node-level configuration. The main cluster settings in figure 3.1 are related to the cluster name-related settings, cluster networking, and some miscellaneous global cluster settings.

#### 3.1.1 Cluster Configuration: Various Name-Related Settings

In the Settings window, the following settings are used for names throughout the cluster.

- Cluster name: (default name: Bright 8.0-stable Cluster).
- Default category: (default name: default)
- Default software image: (default name: default-image)
  - Node name: the base prefix (default prefix name: node)
  - Node digits size: number of digits in suffix of node name (default size: 3)



### 3.1.2 Cluster Configuration: Some Network-Related Settings

These following network-related settings are also described in the context of external network settings for the cluster object, in section 3.2.3, as well as in the quickstart in Chapter 1 of the *Installation Manual*.

#### Nameserver And Search Domains Used By Cluster

The settings window can be used to set the IP address of the nameserver and the names of the search domains for the cluster.

By default, the nameserver is the internal (regular-nodes-facing) IP address of the head node. Multiple nameservers can be added. If the value is set to 0.0.0.0, then the address supplied via DHCP to the head node is used. Alternatively, a static value can be set.

Instead of using the GUI, the changes to the `nameserver` and `searchdomain` values can instead be carried out using `cmsh` in `partition` mode (page 59).

The names of the search domains used by the cluster have a limit of 6 search domains. This is a hardcoded limit imposed by the Linux operating system. Use of FQDNs is advised as a workaround instead of trying to set more search domains.

#### Changing The Order In `resolv.conf`

For clusters CMDaemon by default automatically writes the `/etc/resolv.conf` by using the following sources, and in following order:

1. Global network
2. Other networks
3. Category search domains
4. Partition search domains

Because Linux only supports 6 entries in `/etc/resolv.conf`, it is sometimes useful to exclude or reorder the preceding sources.

For a network object, `Revision` can be set a value of `search_domain_index`, with a number appended in the format `:<index>`. If the number appended is `:0`, then the domain name for the network is not used. Otherwise, the number at the end specifies the position of the domain name:

#### Example

```
[bright80]% network use ibnet
[bright80->network[ibnet]]% show
...
Revision                               search_domain_index:1
```

The ordering priority of the category and partition search domains can also be changed by appending a number in the format `:<index>` to the domain name:

#### Example

```
[bright80]% partition
[bright80->partion[base]]% get searchdomains
brightcomputing.com:1
domain.test:6
```

If an index is set for one search domain, then the use of indices for all search domains is recommended. Search domains without indices are handled automatically by CMDaemon.

CMDaemon sorts all search domains according to index, and writes `/etc/resolv.conf` with the 6 that have the lowest index, with the lowest index first.

### Externally Visible IP Address

The externally visible IP address are public (non-RFC 1918) IP addresses to the cluster. These can be set to be visible on the external network.

### Time server(s)

Time server hostnames can be specified for the NTP client on the head node.

### Time Zone

The time zone setting for the cluster is applied to the time that the cluster uses.

- In Bright View, the time zone can be selected from a menu displayed by clicking on the Time zone menu selection (figure 3.1).
- In `cmsh`, the time zone can be selected in partition mode, using the `base` object. Tab-completion prompting after entering “`set timezone`” displays a list of possible time zones, from which one can be chosen:

#### Example

```
[bright80]% partition use base
[bright80->partition[base]]% set timezone america/los_angeles
[bright80->partition*[base*]]% commit
```

### 3.1.3 Miscellaneous Settings

#### BMC (IPMI) Settings

The BMC (Baseboard Management Controller) access settings can be configured by clicking on the BMC Settings option in Bright View. This opens up a subwindow with the following settings:

- User name: (default: `bright`)
- Password: (default: random string generated during head node installation)
- User ID: (default: 4)
- Power reset delay: During a reset, this is the time, in seconds, that the machine is off, before it starts powering up again (default: 0)

#### Administrator E-mail Setting

By default, the distribution which Bright Cluster Manager runs on sends e-mails for the administrator to the root e-mail address. The administrator e-mail address can be changed within Bright Cluster Manager so that these e-mails are received elsewhere.

- In Bright View, an e-mail address can be set in the Administrator e-mail field (figure 3.1).
- In `cmsh`, the e-mail address (or space-separated addresses) can be set in partition mode, using the `base` object as follows:

#### Example

```
[bright80]% partition use base
[bright80->partition[base]]% set administratore-mail goldstein@oceania.com\
    obrien@oceania.com
[bright80->partition*[base*]]% commit
```

The following critical states or errors cause e-mails to be sent to the e-mail address:

- By default, a month before the cluster license expires, a reminder e-mail is sent to the administrator account by CMDaemon. A daily reminder is sent if the expiry is due within a week.
- A service on the head node that fails on its first ever boot.
- When an automatic failover fails on the head or regular node.

### SMTP Relay Host Mailserver Setting

The head node uses Postfix as its SMTP server. The default base distribution configuration is a minimal Postfix installation, and so has no value set for the SMTP relay host. To set its value:

- in Bright View: the `Relay Host` field sets the SMTP relay host for the cluster resource
- in `cmsh`: the `relayhost` property can be set for the base object within `partition` mode:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% partition use base
[bright80-> partition[base]]% set relayhost mail.example.com
[bright80-> partition[base*]]% commit
```

Postfix on the regular nodes is configured to use the head node as a relay host and is normally left untouched by the administrator.

Further Postfix changes can be done directly to the configuration files as is done in the standard distribution. The changes must be done after the marked auto-generated sections, and should not conflict with the auto-generated sections.

A convenient way to check mail is functioning is to run Bright Cluster Manager's `testemail` command. The command is run from within the main mode of `cmsh`. It sends a test e-mail out using CMDaemon:

```
[root@bright80 ~]# mailq; ls -al /var/spool/mail/root
Mail queue is empty
-rw----- 1 root mail 0 Sep  8 11:11 /var/spool/mail/root
[root@bright80 ~]# cmsh -c "main; testemail"
Mail delivered to postfix
You have new mail in /var/spool/mail/root
[root@bright80 ~]# mailq; ls -al /var/spool/mail/root
Mail queue is empty
-rw----- 1 root mail 749 Sep  8 11:12 /var/spool/mail/root
```

The test e-mail destination is the administrator e-mail address discussed in the preceding section.

### Failover Settings

To access the high availability (HA) feature of the cluster for head nodes, the administrator can click on the `Failover` option in Bright View. This opens up a subwindow that can be used to configure HA-related parameters (section 15.4.6).

### Failover Groups Settings

To access the high availability feature of the cluster for groups of regular nodes, the administrator can click on the `Failover groups` option in Bright View. This opens up a subwindow that can be used to configure failover-groups-related parameters (section 15.5).

### 3.1.4 Limiting The Maximum Number Of Open Files

#### Configuring The System Limit On Open Files: The `/proc/sys/fs/file-max` Setting

The maximum number of open files allowed on a running Linux operating system is determined by `/proc/sys/fs/file-max`. To configure this setting so that it is persistent, the Linux operating system uses a `/etc/sysctl.conf` file and `*.conf` files under `/etc/sysctl.d/`. Further information on these files can be found via the man page, `man(5) sysctl.conf`. Bright Cluster Manager adheres to this standard method, and places a settings file `90-cm-sysctl.conf` in the directory `/etc/sysctl.d`.

By default, the value set for `file-max` by Bright Cluster Manager is 65536. A head node typically is not used to run applications that will exceed this value. However cluster administrators with larger clusters or with custom needs can change the value according to need.

#### Configuring The User Limit On Open Files: The `nofile` Setting

The maximum number of open files allowed for a user can be seen on running `ulimit -n`. The value is defined by the `nofile` parameter of `ulimit`.

By default the value set by Bright Cluster Manager is 65536.

Ulimit limits are limits to restrict the resources used by users. If the `pam_limits.so` module is used to apply `ulimit` limits, then the resource limits can be set via the `/etc/security/limits.conf` file and `*.conf` files in the `/etc/security/limits.d` directory. Further information on these files can be found via the man page, `man(5) limits.conf`.

Resource limits that can be set for user login sessions include the number of simultaneous login sessions, the number of open files, and memory limits.

The maximum number of open files for a user is unlimited by default in an operating system that is not managed by Bright Cluster Manager. However, it is set to 65536 for a system managed by Bright Cluster Manager. The `nofile` value is defined by Bright Cluster Manager in:

- in `/etc/security/limits.d/91-cm-limits.conf` on the head node
- in `/cm/images/<software image name>/etc/security/limits.d/91-cm-limits.conf` in the software image that the regular node picks up.

The values set in `91-cm-limits.conf` are typically sufficient for a user session, unless the user runs applications that are resource hungry and consume a lot of open files.

#### Deciding On Appropriate Ulimit Limit And System Limit Values

Decreasing the `nofile` value in `/etc/security/limits.d/91-cm-limits.conf` (but leaving the `/proc/sys/fs/file-max` untouched), or increasing `/proc/sys/fs/file-max` (but leaving the `nofile` value of 65536 per session as is), may help the system stay under the maximum number of open files allowed.

In general, users should not be allowed to use the head node as a compilation server, or as a testbed, before running their applications. This is because user errors can unintentionally cause the head node to run out of resources and crash it.

Depending what is running on the the server, and the load on it, the administrator may wish to increase the resource limit values.

A very rough rule-of-thumb that may be useful as a first approximation to set `file-max` optimally is suggested in the kernel source code. The suggestion is to simply multiply the system memory (in MB) by 10 per MB, and make the resulting number the `file-max` value. For example, if the node has 128 GB of memory, then 1280000 can be set as the `file-max` value.

Fine-tuning to try and ensure that the operating system no longer runs out of file handles, and to try and ensure the memory limits for handling the load are not exceeded, is best achieved via an empirical trial-and-error approach.

## 3.2 Network Settings

A simplified quickstart guide to setting up the external head node network configuration on a vendor-prepared cluster is given in Chapter 6 of the *Installation Manual*. This section (3.2) covers network configuration more thoroughly.

After the cluster is set up with the correct license as explained in Chapter 4 of the *Installation Manual*, the next configuration step is to define the networks that are present (sections 3.2.1 and 3.2.2).

During Bright Cluster Manager installation at least three default network objects were created:

**internalnet:** the primary internal cluster network, and the default management network. This is used for booting non-head nodes and for all cluster management communication. In the absence of other internal networks, **internalnet** is also used for storage and communication between compute jobs. Changing the configuration of this network is described on page 61 under the subheading “Changing Internal Network Parameters For The Cluster”.

**externalnet:** the network connecting the cluster to the outside world (typically a corporate or campus network). Changing the configuration of this network is described on page 57 under the subheading “Changing External Network Parameters For The Cluster”. This is the only network for which Bright Cluster Manager also supports IPv6.

**globalnet:** the special network used to set the domain name for nodes so that they can be resolved whether they are cloud nodes or not. This network is described further on page 64 under the subheading “Changing The Global Network Parameters For The Cluster”.

For a Type 1 cluster (section 3.3.6 of the *Installation Manual*) the internal and external networks are illustrated conceptually by figure 3.2.




Figure 3.2: Network Settings Concepts

The configuration of network settings is completed when, after having configured the general network settings, specific IP addresses are then also assigned to the interfaces of devices connected to the networks.

- Changing the configuration of the head node external interface is described on page 58 under the subheading “The IP address of the cluster”.

- Changing the configuration of the internal network interfaces is described on page 62 under the subheading “The IP addresses and other interface values of the internal network”.
  - How to set a persistent identity for an interface—for example, to ensure that a particular interface that has been assigned the name `eth3` by the kernel keeps this name across reboots—is covered in section 5.8.1, page 180.
- Changing the configuration of `globalnet` is described on page 64 under the subheading “Changing The Global Network Parameters For The Cluster”. IP addresses are not configured at the `globalnet` network level itself.

### 3.2.1 Configuring Networks

The `network` mode in `cmsh` gives access to all network-related operations using the standard object commands. Section 2.5.3 introduces `cmsh` modes and working with objects.

In Bright View, a network can be configured via the clickpath `Networking→Networks`, which opens up the `Networks` subwindow (figure 3.3):

Networks					
NAME	NETMASK BITS	▲ BASE ADDRESS	DOMAIN NAME	TYPE	OPTIONS
<input type="checkbox"/> <code>globalnet</code>	0	0.0.0.0	<code>cm.cluster</code>	GLOBAL	Edit ▼
<input type="checkbox"/> <code>internalnet</code>	16	10.141.0.0	<code>eth.cluster</code>	INTERNAL	Edit ▼
<input type="checkbox"/> <code>externalnet</code>	24	192.168.200.0	<code>openstacklocal</code>	EXTERNAL	Edit ▼

Revert Add Delete Save

Figure 3.3: Networks

In the context of the OSI Reference Model, each network object represents a layer 3 (i.e. Network Layer) IP network, and several layer 3 networks can be layered on a single layer 2 network (e.g. routes on an Ethernet segment).

Selecting a network such as `internalnet` or `externalnet` in the resource tree displays, for example, by double-clicking the row, opens up the `Overview` window of that network. The `Overview` window by default lists the device names and device properties that are in the network. For example the `internal` network typically has some nodes, switches, and other devices attached to it, each with their IP addresses and interface (figure 3.4).

Network <code>internalnet</code>				
Overview	TYPE	HOSTNAME	INTERFACE	IP
Settings	Node	<code>node005</code>	BOOTIF	10.141.0.5
	Node	<code>node004</code>	BOOTIF	10.141.0.4
	Node	<code>node003</code>	BOOTIF	10.141.0.3
	Node	<code>node002</code>	BOOTIF	10.141.0.2
	Node	<code>node001</code>	BOOTIF	10.141.0.1
	Node	<code>pj-tr</code>	<code>eth0</code>	10.141.255.254

Back Revert Delete Save

Figure 3.4: Network Overview

Selecting the `Settings` option opens a scrollable pane that allows a number of network properties to be changed (figure 3.5).

The screenshot shows the 'Network internalnet' settings page. On the left, a sidebar has 'Overview' and 'Settings' (highlighted). The main content area is divided into sections. The first section contains 'name' (text input: internalnet), 'Domain Name' (text input: eth.cluster), 'Type' (dropdown: Internal), and 'MTU' (text input: 1500). The second section contains 'Node booting' (radio buttons: Enabled, Disabled), 'Lock down dhcpd' (radio buttons: Enabled, Disabled), and 'Management allowed' (radio buttons: Enabled, Disabled). The third section contains 'Base address' (text input: 10.141.0.0), 'Broadcast address' (text input: 10.141.255.255), 'Dynamic range start' (text input: 10.141.160.0), 'Dynamic range end' (text input: 10.141.167.255), 'Netmask bits' (dropdown: 16), and 'Gateway' (text input: 0.0.0.0). At the bottom, there are four buttons: Back, Revert, Delete, and Save.

Figure 3.5: Network Settings

The properties of figure 3.5 are introduced in table 3.2.1.

Property	Description
name	Name of this network.
Domain Name	DNS domain associated with the network.
Type	Menu options to set the network type. Options are <code>Internal</code> , <code>External</code> , <code>Tunnel</code> , <code>Global</code> , <code>Cloud</code> , or <code>NetMap network</code> .
MTU	Maximum Transmission Unit. The maximum size of an IP packet transmitted without fragmenting.
Node booting	Enabling means nodes are set to boot from this network (useful in the case of nodes on multiple networks). For an internal subnet called <code>&lt;subnet&gt;</code> , when node booting is set, CMDaemon adds a subnet configuration <code>/etc/dhcpd.&lt;subnet&gt;.conf</code> on the head node, which is accessed from <code>/etc/dhcpd.conf</code> .

...continues

...continued

Property	Description
Lock down dhcpd	Enabling means new nodes are not offered a PXE DHCP IP address from this network, i.e. DHCPD is “locked down”. A DHCP “deny unknown-clients” option is set by this action, so no new DHCP leases are granted to unknown clients for the network. Unknown clients are nodes for which Bright Cluster Manager has no MAC addresses associated with the node. <ul style="list-style-type: none"> <li>• It can be set in Bright View via the <b>Networking</b> resource, selecting a network item, and then choosing <b>Node booting</b> from within <b>Settings</b>.</li> <li>• It can be set in <code>cmsh</code> via the <code>network</code> mode, selecting a network, and then setting <code>nodebooting</code> to <code>yes</code>.</li> </ul>
Management allowed	Enabling means that the network has nodes managed by the head node.
Base address	Base address of the network (also known as the <i>network address</i> ).
Broadcast address	Broadcast address of the network.
Dynamic range start/end	Start/end IP addresses of the DHCP range temporarily used by nodes during PXE boot on the internal network. These are addresses that do not conflict with the addresses assigned and used by nodes during normal use.
Netmask bits	Prefix-length, or number of bits in netmask. The part after the “/” in CIDR notation.
Gateway	Default route IP address

Table 3.2.1: Network Configuration Settings

In basic networking concepts, a network is a range of IP addresses. The first address in the range is the *base address*. The length of the range, i.e. the *subnet*, is determined by the *netmask*, which uses CIDR notation. CIDR notation is the so-called / (“slash”) representation, in which, for example, a CIDR notation of 192.168.0.1/28 implies an IP address of 192.168.0.1 with a traditional netmask of 255.255.255.240 applied to the 192.168.0.0 network. The netmask 255.255.255.240 implies that bits 28–32 of the 32-bit dotted-quad number 255.255.255.255 are unmasked, thereby implying a 4-bit-sized host range of 16 (i.e.  $2^4$ ) addresses.

The `sipcalc` utility installed on the head node is a useful tool for calculating or checking such IP subnet values (man `sipcalc` or `sipcalc -h` for help on this utility):

### Example

```
user@bright80:~$ sipcalc 192.168.0.1/28
-[ipv4 : 192.168.0.1/28] - 0

[CIDR]
Host address           - 192.168.0.1
Host address (decimal) - 3232235521
Host address (hex)     - C0A80001
Network address        - 192.168.0.0
Network mask           - 255.255.255.240
Network mask (bits)    - 28
Network mask (hex)     - FFFFFFF0
Broadcast address      - 192.168.0.15
Cisco wildcard         - 0.0.0.15
Addresses in network   - 16
```



Network range	- 192.168.0.0 - 192.168.0.15
Usable range	- 192.168.0.1 - 192.168.0.14

Every network has an associated DNS domain which can be used to access a device through a particular network. For `internalnet`, the default DNS domain is set to `cm.cluster`, which means that the hostname `node001.cm.cluster` can be used to access device `node001` through the primary internal network. If a dedicated storage network has been added with DNS domain `storage.cluster`, then `node001.storage.cluster` can be used to reach `node001` through the storage network. Internal DNS zones are generated automatically based on the network definitions and the defined nodes on these networks. For networks marked as external, no DNS zones are generated.

### 3.2.2 Adding Networks

Once a network has been added, it can be used in the configuration of network interfaces for devices.

In Bright View the Add button in the Networks subwindow (figure 3.3) can be used to add a new network. After the new network has been added, the Settings pane (figure 3.5) can be used to further configure the newly-added network.

In `cmsh`, a new network can be added from within network mode using the `add` or `clone` commands.

The default assignment of networks (`internalnet` to Management network and `externalnet` to External network) can be changed using Bright View, via the Settings window of the cluster object (figure 3.1).

In `cmsh` the assignment to Management network and External network can be set or modified from the base object in partition mode:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% partition use base
[bright80->partition[base]]% set managementnetwork internalnet; commit
[bright80->partition[base]]% set externalnetwork externalnet; commit
```

### 3.2.3 Changing Network Parameters

After both internal and external networks are defined, it may be necessary to change network-related parameters from their original or default installation settings.

#### Changing The Head Or Regular Node Hostname

To reach the head node from inside the cluster, the alias `master` may be used at all times. Setting the hostname of the head node itself to `master` is not recommended.

The name of a cluster is sometimes used as the hostname of the head node. The cluster name, the head node hostname, and the regular node hostnames, all have their own separate names as a property of their corresponding objects. The name can be changed in a similar manner for each.

For example, to change the hostname of the head node, the device object corresponding to the head node must be modified.

- In Bright View, the click path for modifying the host name is `Devices→Head Nodes→Edit→Settings→Hostname→Save`. That is, under the `Devices` resource, the `Head Nodes` option is selected. The `Edit` button can then be used to edit the host. This opens up a pane, and the `Settings` option can then be selected. The `Hostname` record can then be modified (figure 3.6), and saved by clicking on the `Save` button. When setting a hostname, a domain is not included.

After the change, as suggested by Bright View, the head node must be rebooted.

Head node **bright80**

Overview > Settings > System Information > Processes >

Hostname ⓘ bright80 Tag ⓘ 00000000a000

Mac ⓘ FA:16:3E:8D:C3:36

Rack ⓘ >

Interfaces ⓘ >  
eth0 - 10.141.255.254, eth1 - 192.168.200.236

PXE Label ⓘ  
PXE Label

Ethernet switch ⓘ >

Back Revert Delete Save Actions ▾

Figure 3.6: Head Node Settings

- In `cmsh`, the hostname of the head node can also be changed, via device mode:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use bright80
[bright80->device[bright80]]% set hostname foobar
[foobar->device*[foobar*]]% commit
[foobar->device[foobar]]%
Tue Jan 22 17:35:29 2013 [warning] foobar: Reboot required: Hostname changed
[foobar->device[foobar]]% quit
[root@bright80 ~]# sleep 30; hostname -f foobar.cm.cluster
[root@bright80 ~]#
```

The prompt string shows the new hostname after a short time, when a new shell is started.

After the hostname has been set, as suggested by `cmsh`, the head node must be rebooted.

### Adding Hostnames To The Internal Network

Additional hostnames, whether they belong to the cluster nodes or not, can be added as name/value pairs to the `/etc/hosts` file(s) within the cluster. This should be done only outside the specially-marked CMDaemon-managed section. It can be done to the file on the head node, or to the file on the software image for the regular nodes, or to both, depending on where the resolution is required.

However, for hosts that are on the internal network of the cluster, such as regular nodes, it is easier and wiser to avoid adding additional hostnames via `/etc/hosts`.

Instead, it is recommended to let Bright Cluster Manager manage host name resolution for devices on the `internalnet` through its DNS server on the `internalnet` interface. The host names can be added to the `additionalhostnames` object, from within `interfaces` submode for the head node. The `interfaces` submode is accessible from the device mode. Thus, for the head node, with `eth1` as the interface for `internalnet`:

### Example

```
[bright80]% device use bright80
[bright80->device[bright80]]% interfaces
[bright80->device[bright80]->interfaces]% use eth1
[bright80->device[bright80]->interfaces[eth1]]% set additionalhostnames test
[bright80->device*[bright80*]->interfaces*[eth1*]]% commit
[bright80->device[bright80]->interfaces[eth1]]%
Fri Oct 12 16:48:47 2012 [notice] bright80: Service named was restarted
[bright80->device[bright80]->interfaces[eth1]]% !ping test
PING test.cm.cluster (10.141.255.254) 56(84) bytes of data.
...
```

Multiple hostnames can be added as space-separated entries.

The `named` service automatically restarts within about 20 seconds after committal, implementing the configuration changes. This kind of restart is a feature (section 3.11.1) of changes made to service configurations by Bright View or `cmsh`.

### Changing External Network Parameters For The Cluster

**The external network parameters of the cluster:** When a cluster interacts with an external network, such as a company or a university network, its connection behavior is determined by the settings of two objects: firstly, the external network settings of the `Networks` resource, and secondly, by the cluster network settings.

1. **The external network object** contains the network settings for all objects configured to connect to the external network, for example, a head node. Network settings are configured in Bright View under the `Networking` resource, then under the `Networks` subwindow, then within the `Settings` option for a selected network. Figure 3.5 shows a settings window for when the `internalnet` item has been selected, but in the current case the `externalnet` item must be selected instead. The following parameters can then be configured:

- the IP network parameters of the cluster (but not the IP address of the cluster):
  - Base address: the network address of the external network (the “IP address of the external network”). This is not to be confused with the IP address of the cluster, which is described shortly after this.
  - Broadcast address: the broadcast address of the external network. This is not to be confused with the IP address of the internal network (page 54).
  - Dynamic range start and Dynamic range end: Not used by the external network configuration.
  - Netmask bits: the netmask size, or prefix-length, of the external network, in bits.
  - Gateway: the default route for the external network.
- the network name (what the external network itself is called), by default this is `externalnet` on a newly installed Type 1 cluster,
- the Domain Name: the network domain (LAN domain, i.e. what domain machines on the external network use as their domain),
- the External network checkbox: this is checked for a Type 1 cluster,
- and MTU size (the maximum value for a TCP/IP packet before it fragments on the external network—the default value is 1500).

If the cluster is running the Bright Cluster Manager for OpenStack edition then some OpenStack parameters are also set:

- OpenStack network type: the OpenStack network type. Choices are: `None`, `Flat`, `VLAN Host`, `VLAN`, `Other`, `VXLAN Host`, `FloatingIps`

- `OpenStack DNS Format`: the format for instances that have a floating IP address assigned to them.
  - `OpenStack network is shared`: If enabled, the OpenStack network is a shared, snooperable network.
  - `OpenStack alloc pool start/end`: the start/end addresses of the OpenStack allocation.
  - `OpenStack VLAN Range/ID`: The VLAN range and ID (if using VLANs).
  - `OpenStack Host network`: Defaults to `vlanhostnet` (for VLANs) or `vxlانhostnet` (for VXLانs)
  - `OpenStack Physical network name`: Name of the OpenStack physical network, defaults to `internalnet`
2. **The cluster object** contains other network settings used to connect to the outside. These are configured in the `Settings` options of the cluster object resource in Bright View (figure 3.1):
- e-mail address(es) for the cluster administrator,
  - any additional external name servers used by the cluster to resolve external host names. As an aside: by default, only the head node name server is configured, and by default it only serves hosts on the internal network via the internal interface. Enabling the `PublicDNS` directive (Appendix C) allows the head node name server to resolve queries about internal hosts from external hosts via any interface, including the external interface.
  - the DNS search domain (what the cluster uses as its domain),
  - and NTP time servers (used to synchronize the time on the cluster with standard time) and time zone settings.

These settings can also be adjusted in `cmsh` in the base object under `partition` mode.

Changing the networking parameters of a cluster (apart from the IP address of the cluster) therefore requires making changes in the settings of the two preceding objects.

**The IP address of the cluster:** The cluster object itself does not contain an IP address value. This is because it is the cluster network topology type that determines whether a direct interface exists from the cluster to the outside world. Thus, the IP address of the cluster in the Type 1, Type 2, and Type 3 configurations (section 3.3.6 of the *Installation Manual*) is defined by the cluster interface that faces the outside world. For Type 1, this is the interface of the head node to the external network (figure 3.2). For Type 2 and Type 3 interfaces the cluster IP address is effectively that of an upstream router, and thus not a part of Bright Cluster Manager configuration. Thus, logically, the IP address of the cluster is not a part of the cluster object or external network object configuration.

For a Type 1 cluster, the head node IP address can be set in Bright Cluster Manager, separately from the cluster object settings. This is then the IP address of the cluster according to the outside world.

**Setting the network parameters of the cluster and the head node IP address:** These values can be set using Bright View or `cmsh`:

**With Bright View:** The cluster network object and associated settings are accessed as follows:

**The external network object:**

The external network object is accessed via the click path

Networking→Networks→externalnet→Edit→Settings

which reaches the window shown in figure 3.7:

The screenshot shows a web-based configuration interface for a network. On the left, there is a sidebar with 'Overview' and 'Settings' (selected). The main area is titled 'Network internalnet'. It contains several sections of settings:

- name:** internalnet
- Domain Name:** eth.cluster
- Type:** Internal (dropdown)
- MTU:** 1500
- Node booting:** Enabled (button)
- Lock down dhcpd:** Enabled (button)
- Management allowed:** Enabled (button)
- Base address:** 10.141.0.0
- Broadcast address:** 10.141.255.255
- Dynamic range start:** 10.141.160.0
- Dynamic range end:** 10.141.167.255
- Netmask bits:** 16 (dropdown)
- Gateway:** 0.0.0.0
- OpenStack network type:** None (dropdown)
- OpenStack DNS Format:** \${uuid}
- OpenStack network is shared:** Enabled (button)

At the bottom, there are four buttons: Back, Revert, Delete, and Save.

Figure 3.7: Network Settings For External Network

**The cluster object:**

The cluster object and associated settings are accessed as shown in figure 3.1

**The head node IP address:**

For a head node `bright80`, where the IP address is used by the interface `eth0`, the static IP address can be set via the clickpath `Devices→Head Nodes→Edit [bright80]→Settings→Interfaces[eth0]→IP` (figure 3.8).

**With `cmsh`:** The preceding Bright View configuration can also be done in `cmsh`, using the `network`, `partition` and `device` modes, as in the following example:

**Example**

```
[bright80]% network use externalnet
[bright80->network[externalnet]]% set baseaddress 192.168.1.0
[bright80->network*[externalnet*]]% set netmaskbits 24
[bright80->network*[externalnet*]]% set gateway 192.168.1.1
[bright80->network*[externalnet*]]% commit
[bright80->network[externalnet]]% partition use base
[bright80->partition[base]]% set nameservers 192.168.1.1
[bright80->partition*[base*]]% set searchdomains x.com y.com
[bright80->partition*[base*]]% append timeservers ntp.x.com
```




Figure 3.8: Setting The IP Address On A Head Node In Bright View

```
[bright80->partition*[base*]]% commit
[bright80->partition[base]]% device use bright80
[bright80->device[bright80]]% interfaces
[bright80->device[bright80]->interfaces]% use eth1
[bright80->device[bright80]->interfaces[eth1]]% set ip 192.168.1.176
[bright80->device[bright80]->interfaces*[eth1*]]% commit
[bright80->device[bright80]->interfaces[eth1]]%
```

After changing the external network configurations, a reboot of the head node is necessary to activate the changes.

**Using DHCP to supply network values for the external interface:** Connecting the cluster via DHCP on the external network is not generally recommended for production clusters. This is because DHCP-related issues can complicate networking troubleshooting compared with using static assignments.

For a Type 1 network, the cluster and head node can be made to use some of the DHCP-supplied external network values as follows:

- In Bright View, the DHCP setting of figure 3.8 can be set to Enabled
- Alternatively, in `cmsh`, within interfaces mode for the head node interface, the value of the parameter DHCP can be set:

```
[bright80->device[bright80]->interfaces[eth0]]% set dhcp yes
```

The gateway address, the name server(s), and the external IP address of the head node are then obtained via a DHCP lease. Time server configuration for `externalnet` is not picked up from the DHCP server, having been set during installation (figure 3.28 in Chapter 3 of the *Installation Manual*). The time servers can be changed using Bright View as in figure 3.1, or using `cmsh` in `partition` mode as in the preceding example. The time zone can be changed similarly.

It is usually sensible to reboot after implementing these changes in order to test the changes are working as expected.

### Changing Internal Network Parameters For The Cluster

When a cluster interacts with the internal network that the regular nodes and other devices are on, its connection behavior with the devices on that network is determined by settings in:

1. the internal network of the `Networks` resource (page 61)
2. the cluster network for the internal network (page 62)
3. the individual device network interface (page 62)
4. the node categories network-related items for the device (page 63), in the case of the device being a regular node.

In more detail:

**1. The internal network object:** has the network settings for all devices connecting to the internal network, for example, a login node, a head node via its `internalnet` interface, or a managed switch on the internal network. In Bright View, the settings can be configured under the `Networking` resource, then under the `Networks` subwindow, then within the `Settings` option for the `internalnet` item (figure 3.5). In `cmsh` the settings can be configured by changing the values in the `internalnet` object within `cmsh`'s `network` mode. Parameters that can be changed include:

- the IP network parameters of the internal network (but not the internal IP address):
  - “Base address”: the internal network address of the cluster (the “IP address of the internal network”). This is not to be confused with the IP address of the internal network interface of the head node. The default value is `10.141.0.0`.
  - “Netmask bits”: the netmask size, or prefix-length, of the internal network, in bits. The default value is `16`.
  - Gateway: the default gateway route for the internal network. If unset, or `0.0.0.0` (the default), then its value is decided by the DHCP server on the head node, and nodes are assigned a default gateway route of `10.141.255.254`, which corresponds to using the head node as a default gateway route for the interface of the regular node. The effect of this parameter is overridden by any default gateway route value set by the value of `Default gateway` in the node category.
  - “Dynamic range start” and “Dynamic range end”: These are the DHCP ranges for nodes. DHCP is unset by default. When set, unidentified nodes can use the dynamic IP address values assigned to the node by the node-installer. These values range by default from `10.141.128.0` to `10.141.143.255`. Using this feature is not generally recommended, in order to avoid the possibility of conflict with the static IP addresses of identified nodes.
  - Allow node booting: This allows nodes to boot from the provisioning system controlled by `CMDaemon`. The parameter is normally set for the management network (that is the network over which `CMDaemon` communicates to manage nodes) but booting can instead be carried out over a separate physical non-management network. Booting over InfiniBand or Omni-Path is one of the possibilities (section 5.1.3). Only if the `Allow node booting` option is ticked does ticking the “Don’t allow new nodes to be booted from this network” checkbox have any effect, and stop new nodes from booting. New nodes are those nodes which are detected but the cluster cannot identify based on `CMDaemon` records. Details are given in Chapter 5 about booting, provisioning, and how a node is detected as new.
- the “domain name” of the network. This is the LAN domain, which is the domain machines on this network use as their domain. By default, set to `cm.cluster`.

- the network name, or what the internal network is called. By default, set to `internalnet`.
- The MTU size, or the maximum value for a TCP/IP packet before it fragments on this network. By default, set to 1500.

**2. The cluster object:** has other network settings that the internal network in the cluster uses. These particulars are configured in the `Settings` option of the cluster object resource in Bright View (figure 3.1). The `cmsh` equivalents can be configured from the `base` object in `partition` mode. Values that can be set include:

- the “`Management network`”. This is the network over which `CMDaemon` manages the nodes. Management means that `CMDaemon` on the head node communicates with `CMDaemons` on the other nodes. The communication includes `CMDaemon` calls and monitoring data. By default, the management network is set to `internalnet` for Type 1 and Type 2 networks, and `managementnet` in Type 3 networks. It is a partition-level cluster-wide setting by default. Partition-level settings can be overridden by the category level setting, and node-level settings can override category level or partition level settings.
- the “`Node name`” can be set to decide the prefix part of the node name. By default, set to `node`.
- the “`Node digits`” can be set to decide the possible size of numbers used for suffix part of the node name. By default, set to 3.
- the “`Default category`”. This sets the category the nodes are in by default. By default, it is set to `default`.
- the “`Default software image`”. This sets the image the nodes use by default, for new nodes that are not in a category yet. By default, it is set to `default-image`.
- the “`Name server`”. This sets the name server used by the cluster. By default, it is set to the head node. The default configuration uses the internal network interface and serves only internal hosts. Internal hosts can override using this value at category level (page 64). By default external hosts cannot use this service. To allow external hosts to use the service for resolving internal hosts, the `PublicDNS` directive (Appendix C) must be set to `True`.

**3. The internal IP addresses and other internal interface values:** In Bright View, the network for a node, such as a physical node `node001`, can be configured via a clickpath `Devices→Physical Nodes[node001]→Interface`. The subwindow that opens up then allows network configuration to be done for such nodes in a similar way to figure 3.8.

In `cmsh` the configuration can be done by changing properties from the `interfaces` submode that is within the `device` mode for the node.

The items that can be set include:

- the `Network device name`: By default, this is set to `BOOTIF` for a node that boots from the same interface as the one from which it is provisioned.
- the `Network`: By default, this is set to a value of `internalnet`.
- the `IP address`: By default, this is automatically assigned a static value, in the range `10.141.0.1` to `10.141.255.255`, with the first node being given the first address. Using a static IP address is recommended for reliability, since it allows nodes that lose connectivity to the head node to continue operating. The static address can be changed manually, in case there is an IP address or node ID conflict due to an earlier inappropriate manual intervention.

Administrators who want DHCP addressing on the internal network, despite the consequences, can set it via a checkbox.



- `onnetworkpriority`: This sets the priority of DNS resolution queries for the interface on the network. The range of values that it can take is from 0 to 4294967295. Resolution takes place via the interface with the higher value.

The default priority value for a network interface is set according to its type. These defaults are:

Type	Value
Bridge	80
Bond	70
Physical	60
VLAN	50
Alias	40
Tunnel	30
Netmap	20
BMC	10

- `Additional Hostname`: In the case of nodes this is in addition to the default node name set during provisioning. The node name set during provisioning takes a default form of `node<3 digit number>`, as explained earlier on page 62 in the section describing the cluster object settings.

For, example, a regular node that has an extra interface, `eth1`, can have its values set as follows:

#### Example

```
[bright80] device interfaces node001
[bright80->device[node001]->interfaces]% add physical eth1
[bright80->...->interfaces*[eth1*]]% set network externalnet
[bright80->...->interfaces*[eth1*]]% set additionalhostnames extra01
[bright80->...->interfaces*[eth1*]]% set ip 10.141.1.1
[bright80->...->interfaces*[eth1*]]% commit
[bright80->...->interfaces[eth1]]% ..
[bright80->...->interfaces]% ..
[bright80->device[node001]]% reboot
```

**4. Node category network values:** are settings for the internal network that can be configured for node categories. For example, for the default category called `default` this can be carried out:

- via Bright View, using the `Settings` option for `Node categories`. This is in the clickpath `Grouping→Node categories[default-image]→Settings`
- or via the `category mode` in `cmsh`, for the `default node category`.

If there are individual node settings that have been configured in Bright View or `cmsh`, then the node settings override the corresponding category settings for those particular nodes.

The category properties involved in internal networking that can be set include:

- `Default gateway`: The default gateway route for nodes in the node category. If unset, or `0.0.0.0` (the default), then the node default gateway route is decided by the internal network object `Gateway` value. If the default gateway is set as a node category value, then nodes use the node category value as their default gateway route instead.

- **Management network:** The management network is the network used by CMDaemon to manage devices. The default setting is a property of the node object. It can be set as a category property.
- **Name server, Time server, Search domain:** The default setting for these on all nodes is set by the node-installer to refer to the head node, and is not configurable at the node level using Bright View or `cmsh`. The setting can however be set as a category property, either as a space-separated list of entries or as a single entry, to override the default value.

**Application To Generic Network Devices:** The preceding details for the internal network parameters of the cluster, starting from page 61, are applicable to regular nodes, but they are often also applicable to generic network devices (section 2.1.1). Benefits of adding a generic device to be managed by Bright Cluster Manager include that:

- the name given to the device during addition is automatically placed in the internal DNS zone, so that the device is accessible by name
- the device status is automatically monitored via a SYN ping (Appendix G.2.1).
- the device can be made to work with the health check and metric framework. The scripts used in the framework will however almost certainly have to be customized to work with the device

After changing network configurations, a reboot of the device is necessary to activate the changes.

### Changing The Global Network Parameters For The Cluster

The global network `globalnet` is a unique network used to set up a common name space for all nodes in a cluster in Bright Cluster Manager. It is required in Bright Cluster Manager because of the added cloud extension functionality, described in the *Cloudbursting Manual*. Regular nodes and regular cloud nodes are thus both named under the `globalnet` domain name, which is `cm.cluster` by default. So, for example, if default host names for regular nodes (`node001`, `node002`, ...) and regular cloud nodes (`cnode001`, `cnode002`, ...) are used, node addresses with the domain are:

- `node001.cm.cluster` for `node001`
- `cnode001.cm.cluster` for `cnode001`

The only parameter that can be sensibly changed on `globalnet` is the domain name, which is `cm.cluster` by default.

Removing `globalnet` should not be done because it will cause various networking failures, even for clusters deploying no cloud nodes.

Details on how resolution is carried out with the help of `globalnet` are given in section 6.4.1 of the *Cloudbursting Manual*.

### Setting Static Routes

To route via a specific gateway, the `staticroutes` submode can be used. This can be set for regular nodes and head nodes via the `device` mode, and for node categories via the `category` mode.

On a newly-installed cluster with a type 1 network (section 3.3.6 of the *Installation Manual*), a node by default routes packets using the head node as the default gateway.

If the administrator would like to configure a regular node to use another gateway to reach a printer on another subnet, as illustrated by figure 3.9:




Figure 3.9: Example Of A Static Route To A Printer On Another Subnet

then an example session for setting the static route is as follows:

### Example

```
[root@bright80 ~]# cmsh
[bright80 ]% device use node001
[bright80->device[node001]]%
[bright80->device[node001]]% staticroutes
[bright80->device[node001]->staticroutes]% list
Name (key)                Gateway                Destination
-----
[bright80->device[node001]->staticroutes]% add printeroute
[bright80->...[printeroute*]]% set gateway 10.141.1.1
[bright80->...[printeroute*]]% set destination 192.168.0.3
[bright80->...[printeroute*]]% set networkdevicename bootif
[bright80->...[printeroute*]]% commit
[bright80->...[printeroute]]% show
Parameter                  Value
-----
Destination                 192.168.0.3/32
Gateway                     10.141.1.1
Name                         printeroute
Network Device Name         bootif
Revision
[bright80->device[node001]->staticroutes[printeroute]]% exit
[bright80->device[node001]->staticroutes]% list
Name (key)                Gateway                Destination
-----
printeroute                10.141.1.1            192.168.0.3/32
[bright80->device[node001]->staticroutes]% exit; exit
[bright80->device]% reboot node001
```

In the preceding example, the regular node `node001`, with IP address 10.141.0.1 can connect to a host 192.168.0.3 outside the regular node subnet using a gateway with the IP addresses 10.141.1.1 and 192.168.0.1. The route is given the arbitrary name `printerroute` for administrator and CMDaemon convenience, because the host to be reached in this case is a print server. The `networkdevicename` is given the interface name `bootif`. If another device interface name is defined in CMDaemon, then that can be used instead. If there is only one interface, then `networkdevicename` need not be set.

After a reboot of the node, the route that packets from the node follow can be seen with a `traceroute` or similar. The `ping` utility with the `-R` option can often track up to 9 hops, and can be used to track the route:

### Example

```
[root@bright80 ~]# ssh node001 ping -c1 -R 192.168.0.3
PING 192.168.0.3 (192.168.0.3) 56(124) bytes of data.
64 bytes from 192.168.0.3: icmp_seq=1 ttl=62 time=1.41 ms
RR:      10.141.0.1
         10.141.1.1
         192.168.0.1
         192.168.0.3
         192.168.0.3
         192.168.0.1
         10.141.1.1
         10.141.0.1

--- 192.168.0.3 ping statistics ---
1 packets transmitted, 1 received, 0% packet loss, time 1ms
rtt min/avg/max/mdev = 1.416/1.416/1.416/0.000 ms
[root@bright80->device[node001]->staticroutes]%
```

The routing is achieved by CMDaemon making sure that whenever the network interface is brought up, the OS of the regular node runs a routing command to configure the routing tables. The command executed for the given example is either:

```
route add -host 192.168.0.3 gw 10.141.1.1
```

or its modern `iproute2` equivalent:

```
ip route add 192.168.0.3 via 10.141.1.1
```

If the device `bootif` is `eth0`—which is often the case—then the command is run from the network interface configuration file: `/etc/sysconfig/network-scripts/ifcfg-eth0` (or `/etc/sysconfig/network/ifcfg-eth0` in SUSE).

## 3.3 Configuring Bridge Interfaces

Bridge interfaces can be used to divide one physical network into two separate network segments at layer 2 without creating separate IP subnets. A bridge thus connects the two networks together at layer 3 in a protocol-independent way.

The network device name given to the bridge interface is of the form `br<number>`. The following example demonstrates how to set up a bridge interface in `cmsh`, where the name `br0` is stored by the parameter `networkdevicename`.

### Example

```
[bright80->device[node001]->interfaces]% add bridge br0
[bright80->...->interfaces*[br0*]]% set network internalnet
```

```
[bright80->...->interfaces*[br0*]]% set ip 10.141.1.1
[bright80->...->interfaces*[br0*]]% show
Parameter                                Value
-----
Additional Hostnames
DHCP                                      no
Forward Delay                            0
IP                                        10.141.1.1
Interfaces
MAC                                       00:00:00:00:00:00
Network                                  internalnet
Network device name                      br0
Revision
SpanningTreeProtocol                    no
Type                                     bridge
```

A bridge interface is composed of one or more physical interfaces. The IP and network fields of the member interfaces must be empty:

### Example

```
[bright80->...->interfaces*[br0*]]% set interfaces eth1 eth2; exit
[bright80->...->interfaces*]% clear eth1 ip; clear eth1 network
[bright80->...->interfaces*]% clear eth2 ip; clear eth2 network
[bright80->...->interfaces*]% use br0; commit
```

The BOOTIF interface is also a valid interface option.

Currently, the following bridge properties can be set:

- **SpanningTreeProtocol:** sets the spanning tree protocol to be on or off. The default is off.
- **Forward Delay:** sets the delay for forwarding Ethernet frames, in seconds. The default is 0.

Additional properties, if required, can be set manually using the `brctl` command in the OS shell.

When listing interfaces in `cmsh`, if an interface is a member of a bond (or bridge) interface, then the corresponding bond or bridge interface name is shown in parentheses after the member interface name:

### Example

```
[headnode->device[node001]->interfaces]% list
Type      Network device name  IP      Network
-----
bond      bond0 [prov]          10.141.128.1  internalnet
bridge    br0                   10.141.128.2  internalnet
physical  eth0                  10.141.0.1    internalnet
physical  eth1 (bond0)          0.0.0.0
physical  eth2 (bond0)          0.0.0.0
physical  eth3 (br0)            0.0.0.0
physical  eth4 (br0)            0.0.0.0
```

It is possible to create a bridge interface with no IP address configured, that is, with an IP address of 0.0.0.0. This can be done for security reasons, or when the number of available IP addresses on the network is scarce. As long as such a bridge interface has a network assigned to it, it is properly configured on the nodes and functions as a bridge on the network.

### 3.4 Configuring VLAN interfaces

A VLAN (Virtual Local Area Network) is an independent logical LAN within a physical LAN network. VLAN tagging is used to segregate VLANs from each other. VLAN tagging is the practice of inserting a VLAN ID tag into a packet frame header, so that each packet can be associated with a VLAN.

The physical network then typically has sections that are VLAN-aware or VLAN-unaware. The nodes and switches of the VLAN-aware section are configured by the administrator to decide which traffic belongs to which VLAN.

A VLAN interface can be configured for an interface within Bright Cluster Manager using `cmsh` or Bright View.

#### 3.4.1 Configuring A VLAN Interface Using `cmsh`

In the following `cmsh` session, a regular node interface that faces a VLAN-aware switch is made VLAN-aware, and assigned a new interface—an alias interface. It is also assigned a network, and an IP address within that network:

##### Example

```
[root@bright80 ~]# cmsh
[bright80]% device interfaces node001
[bright80->device[node001]->interfaces]% list
Type          Network device name  IP          Network
-----
physical      BOOTIF [prov]          10.141.0.1  internalnet
[bright80->device[node001]->interfaces]% list -h | tail -4
Arguments:
  type
    alias, bmc, bond, bridge, netmap, physical, tunnel, vlan

[bright80->device[node001]->interfaces]% add vlan BOOTIF.1
[bright80->device*[node001*]->interfaces*[BOOTIF.1*]]% commit
[bright80->device[node001]->interfaces[BOOTIF.1]]% show

Parameter          Value
-----
Additional Hostname
DHCP                no
IP                  0.0.0.0
MAC                 00:00:00:00:00:00
Network
Network device name BOOTIF.1
Reorder HDR         no
Revision
Type                vlan
[bright80->...[BOOTIF.1]]% set network internalnet
[bright80->...[BOOTIF.1*]]% set ip 10.141.2.1; commit
```

#### 3.4.2 Configuring A VLAN Interface Using Bright View

Within Bright View a VLAN interface can be configured by selecting the node with that interface, selecting its Settings option, then selecting the Interfaces option. In the Network Interfaces window that opens up, the Network VLAN interface option is selected and a dialog opens up allowing an IP address, network, and other options to be set (figure 3.10).




Figure 3.10: Configuring A VLAN via Bright View

## 3.5 Configuring Bonded Interfaces

### 3.5.1 Adding A Bonded Interface

The Linux bonding driver allows multiple physical network interfaces that have been configured previously (for example, as on page 63) to be bonded as a single logical bond interface. The behavior of such interfaces is determined by their bonding mode. The modes provide facilities such as hot standby or load balancing.

The driver is included by default on head nodes. To configure a non-head node to use a bonded interface, a Linux kernel module called the `bonding` module must be included in the kernel modules list of the software image of the node. A bonding interface can then be created, and its properties set as follows:

#### Example

```
[bright80->device[node001]->interfaces]% add bond bond0
[...->device*[node001*]->interfaces*[bond0*]]% set network internalnet
[...->device*[node001*]->interfaces*[bond0*]]% set ip 10.141.128.1
[...->device*[node001*]->interfaces*[bond0*]]% set mode 3
[...->device*[node001*]->interfaces*[bond0*]]% set interfaces eth1 eth2
```

Each bonded interface has a unique set of object properties, called bonding options, that specify how the bonding device operates. The bonding options are a string containing one or more options formatted as `option=value` pairs, with pairs separated from each other by a space character.

A bonded interface also always has a mode associated with it. By default it is set to 0, corresponding to a balanced round-robin packet transmission.

The 7 bonding modes are:

- 0 – balance-rr
- 1 – active-backup
- 2 – balance-xor
- 3 – broadcast
- 4 – 802.3ad
- 5 – balance-tlb
- 6 – balance-alb

Technically, outside of Bright View or `cmsh`, the bonding mode is just another bonding option specified as part of the options string. However in Bright Cluster Manager the bonding mode value is set up using the dedicated `mode` property of the bonded interface, for the sake of clarity. To avoid conflict with the value of the `mode` property, trying to commit a bonding mode value as an `option=value` pair will fail validation.

### 3.5.2 Single Bonded Interface On A Regular Node

A single bonded interface on a node can be configured and coexist in several ways on nodes with multiple network interfaces. Possibilities and restrictions are illustrated by the following:

- The bonded interface may be made up of two member interfaces, and a third interface outside of the bond could be the boot interface. (The boot interface is the node interface used to PXE boot the node before the kernel loads (section 5.1)).
- The boot interface could itself be a member of the bonded interface. If the boot interface is a member of a bonded interface, then this is the first bonded interface when interfaces are listed as in the example on page 67.
- The bonded interface could be set up as the provisioning interface. However, the provisioning interface cannot itself be a member of a bonded interface. (The provisioning interface is the node's interface that picks up the image for the node after the initial ramdisk is running. Chapter 5 covers this in more detail).
- A bonded interface can be set up as the provisioning interface, while having a member interface which is used for PXE booting.

### 3.5.3 Multiple Bonded Interface On A Regular Node

A node can also have multiple bonded interfaces configured. Possibilities and restrictions are illustrated by the following:

- Any one of the configured bonded interfaces can be configured as the provisioning interface. However, as already mentioned in the case of single bond interfaces (section 3.5.2), a particular member of a bonded interface cannot be made the provisioning interface.
- When a bonded interface is set as the provisioning interface, then during the node-installer phase of boot, the node-installer brings up the necessary bonded interface along with all its member interfaces so that node provisioning is done over the bonded interface.

### 3.5.4 Bonded Interfaces On Head Nodes And HA Head Nodes

It is also possible to configure bonded interfaces on head nodes.

For a single head node setup, this is analogous to setting up bonding on regular nodes.

For a high availability (HA) setup (chapter 15), bonding is possible for `internalnet` as well as for `externalnet`, but it needs the following extra changes:

- For the bonded interface on `internalnet`, the shared internal IP alias interface name (the value of `networkdevicename`, for example, `eth0:0` in figure 15.1) for that IP address should be renamed to the bonded alias interface name on `internalnet` (for example, `bond0:0`).
- For the bonded interface on `externalnet`, the shared external IP alias interface name (the value of `networkdevicename`, for example, `eth1:0` in figure 15.1) for that IP address should be renamed to the bonded alias interface name on `externalnet` (for example, `bond1:0`).
- Additionally, when using a bonded interface name for the internal network, the value of the provisioning network interface name (the value of `provisioninginterface`, for example, `eth0`) for the head nodes, must be changed to the name of the bonded interface (for example, `bond0`).



[prov]) on the internal network. The provisioninginterface value setting is described further on page 164.

### Example

```
[headnode1->device[headnode1->interfaces]% list
```

Type	Network device name	IP	Network
alias	bond0:0	10.141.255.252	internalnet
alias	bond1:0	10.150.57.1	externalnet
bond	bond0 [prov]	10.141.255.254	internalnet
bond	bond1	10.150.57.3	externalnet
physical	eth0 (bond0)	0.0.0.0	
physical	eth1 (bond0)	0.0.0.0	
physical	eth2 (bond1)	0.0.0.0	
physical	eth3 (bond1)	0.0.0.0	

### 3.5.5 Tagged VLAN On Top Of a Bonded Interface

It is possible to set up a tagged VLAN interface on top of a bonded interface. There is no requirement for the bonded interface to have an IP address configured in this case. The IP address can be set to 0.0.0.0, however a network must be set.

### Example

```
[headnode1->device[node001->interfaces]% list
```

Type	Network device name	IP	Network
bond	bond0	0.0.0.0	internalnet
physical	eth0 [prov]	10.141.0.1	internalnet
physical	eth1 (bond0)	0.0.0.0	
physical	eth2 (bond0)	0.0.0.0	
vlan	bond0.3	10.150.1.1	othernet

### 3.5.6 Further Notes On Bonding

If using bonding to provide failover services, `miimon`, which is off by default (set to 0), should be given a value. The `miimon` setting is the time period in milliseconds between checks of the interface carrier state. A common value is `miimon=100`.

When listing interfaces in `cmsh`, if an interface is a member of a bond or bridge interface, then the corresponding bonded or bridge interface name is shown in parentheses after the member interface name. Section 3.3, on configuring bridge interfaces, shows an example of such a listing from within `cmsh` on page 67.

More on bonded interfaces (including a detailed description of bonding options and modes) can be found at <http://www.kernel.org/doc/Documentation/networking/bonding.txt>.

## 3.6 Configuring InfiniBand And Omni-Path Interfaces

On clusters with an InfiniBand interconnect, the InfiniBand Host Channel Adapter (HCA) in each node must be configured before it can be used. A similar requirement applies for Omni-Path and its fabric controller. Bright Cluster Manager manages InfiniBand and Omni-Path configuration in the same way. Therefore Omni-Path management is usually also implied whenever InfiniBand is discussed in the Bright Cluster Manager manuals.

This section describes how to set up the InfiniBand service on the nodes for regular use. Setting up InfiniBand for booting and provisioning purposes is described in Chapter 5, while setting up InfiniBand for NFS is described in section 3.10.5.

### 3.6.1 Installing Software Packages

On a standard Bright Cluster Manager cluster, the OFED (OpenFabrics Enterprise Distribution) packages that are part of the Linux base distribution are used. These packages provide RDMA implementations allowing high bandwidth/low latency interconnects on OFED hardware. The implementations can be used by InfiniBand hardware, and iWarp protocol hardware such as the hardware-accelerated RDMA over ethernet provided by Intel.

By default, all relevant OFED packages are installed on the head node and software images. It is possible to replace the distribution OFED with an OFED provided by the Bright Cluster Manager repository or another custom version. The replacement can be for the entire cluster, or only for certain software images. Administrators may choose to switch to a different OFED version if the HCAs used are not supported by the distribution OFED version, or to increase performance by using an OFED version that has been optimized for a particular HCA. Installing the Bright Cluster Manager OFED and Omni-Path packages is covered in section 7.6 and section 7.7 respectively of the *Installation Manual*.

If the InfiniBand network is enabled during installation, then the `rdma` script runs during the `init` stage of booting up for the enabled nodes. For SLES and Linux distributions based on versions prior to Red Hat 6, the `openibd` script is used instead of the `rdma` script.

The `rdma` or `openibd` script takes care of loading the relevant InfiniBand HCA kernel modules. When adding an InfiniBand network after installation, it may be necessary to use `chkconfig` manually to configure the `rdma` or `openibd` script to be run at boot-time on the head node and inside the software images.

### 3.6.2 Subnet Managers

Every InfiniBand subnet requires at least one subnet manager to be running. The subnet manager takes care of routing, addressing and initialization on the InfiniBand fabric. Some InfiniBand switches include subnet managers. However, on large InfiniBand networks or in the absence of a switch-hosted subnet manager, a subnet manager needs to be started on at least one node inside of the cluster. When multiple subnet managers are started on the same InfiniBand subnet, one instance will become the active subnet manager whereas the other instances will remain in passive mode. It is recommended to run 2 subnet managers on all InfiniBand subnets to provide redundancy in case of failure.

On a Linux machine that is not running Bright Cluster Manager, an administrator sets a subnet manager service<sup>1</sup> to start at boot-time with a command such as: “`chkconfig opensm on`”. However, for clusters managed by Bright Cluster Manager, a subnet manager is best set up using CMDaemon. There are two ways of setting CMDaemon to start up the subnet manager on a node at boot time:

1. by assigning a role.

In `cmsh` this can be done with:

```
[root@bright80 ~]# cmsh -c "device roles <node>; assign subnetmanager; commit"
```

where `<node>` is the name of a node on which it will run, for example: `bright80`, `node001`, `node002`...

In Bright View, the subnet manager role is assigned by selecting a head node or regular node from the `Devices` resource, and assigning it the “Subnet manager role”. The clickpath for this, for a node `node002` for example, is `Devices→Physical Nodesnode002→Settings→Roles→Add[Subnet manager role]`.

2. by setting the service up. Services are covered more generally in section 3.11.

In `cmsh` this is done with:

#### Example

---

<sup>1</sup>usually `opensm`, but `opensmd` in SLES

```
[root@bright80 ~]# cmsh
[bright80]% device services node001
[bright80->device[node001]->services]% add opensm
[bright80->device[node001]->services*[opensm*]]% set autostart yes
[bright80->device[node001]->services*[opensm*]]% set monitored yes
[bright80->device[node001]->services*[opensm*]]% commit
[bright80->device[node001]->services[opensm]]%
```

In Bright View the subnet manager service is configured by selecting a head node or regular node from the resources tree, and adding the service to it. The clickpath for this, for a node node002 for example, is: Devices→Physical Nodesnode002→Settings→Services[Service].

When the head node in a cluster is equipped with an InfiniBand HCA, it is a good candidate to run as a subnet manager for smaller clusters.

On large clusters a dedicated node is recommended to run the subnet manager.

### 3.6.3 InfiniBand Network Settings

Although not strictly necessary, it is recommended that InfiniBand interfaces are assigned an IP address (i.e. IP over IB). First, a network object in the cluster management infrastructure should be created. The procedure for adding a network is described in section 3.2.2. The following settings are recommended as defaults:

Property	Value
Name	ibnet
Domain name	ib.cluster
Type	internal
Base address	10.149.0.0
Netmask bits	16
MTU	up to 4k in datagram mode up to 64k in connected mode

By default, an InfiniBand interface is set to datagram mode. It can be configured to run in connected mode by setting the `connectedmode` property:

#### Example

```
[bright80->device[node001]->interfaces[ib0]]% set connectedmode yes
```

For nodes that are PXE booting or are getting provisioned over InfiniBand, the mode setting in the node-installer script has to be changed accordingly.

#### Example

```
[root@bright80 ~]# echo datagram > /cm/node-installer/scripts/ipoib_mode
```

Once the network has been created all nodes must be assigned an InfiniBand interface on this network. The easiest method of doing this is to create the interface for one node device and then to clone that device several times.

For large clusters, a labor-saving way to do this is using the `addinterface` command (section 3.7.1) as follows:

```
[root@bright80 ~]# echo "device
addinterface -n node001..node150 physical ib0 ibnet 10.149.0.1
commit" | cmsb -x
```

When the head node is also equipped with an InfiniBand HCA, it is important that a corresponding interface is added and configured in the cluster management infrastructure.

### Example

Assigning an IP address on the InfiniBand network to the head node:

```
[bright80->device[bright80->interfaces]% add physical ib0
[bright80->device[bright80->interfaces*[ib0*]]% set network ibnet
[bright80->device[bright80->interfaces*[ib0*]]% set ip 10.149.255.254
[bright80->device[bright80->interfaces*[ib0*]]% commit
```

As with any change to the network setup, the head node needs to be restarted to make the above change active.

### 3.6.4 Verifying Connectivity

After all nodes have been restarted, the easiest way to verify connectivity is to use the ping utility

### Example

Pinging node015 while logged in to node014 through the InfiniBand interconnect:

```
[root@node014 ~]# ping node015.ib.cluster
PING node015.ib.cluster (10.149.0.15) 56(84) bytes of data.
64 bytes from node015.ib.cluster (10.149.0.15): icmp_seq=1 ttl=64
time=0.086 ms
...
```

If the ping utility reports that ping replies are being received, the InfiniBand is operational. The ping utility is not intended to benchmark high speed interconnects. For this reason it is usually a good idea to perform more elaborate testing to verify that bandwidth and latency are within the expected range.

The quickest way to stress-test the InfiniBand interconnect is to use the Intel MPI Benchmark (IMB), which is installed by default in /cm/shared/apps/imb/current. The setup.sh script in this directory can be used to create a template in a user's home directory to start a run.

### Example

Running the Intel MPI Benchmark using openmpi to evaluate performance of the InfiniBand interconnect between node001 and node002:

```
[root@bright80 ~]# su - cmsupport
[cmsupport@bright80 ~]$ cd /cm/shared/apps/imb/current/
[cmsupport@bright80 current]$ ./setup.sh
[cmsupport@bright80 current]$ cd ~/BenchMarks/imb/3.2.2
[cmsupport@bright80 3.2.2]$ module load openmpi/gcc
[cmsupport@bright80 3.2.2]$ module initadd openmpi/gcc
[cmsupport@bright80 3.2.2]$ make -f make_mpi2
[cmsupport@bright80 3.2.2]$ mpirun -np 2 -machinefile ../nodes IMB-MPI1 PingPong
#-----
# Benchmarking PingPong
# #processes = 2
#-----
#bytes #repetitions      t[usec]    Mbytes/sec
```

0	1000	0.78	0.00
1	1000	1.08	0.88
2	1000	1.07	1.78
4	1000	1.08	3.53
8	1000	1.08	7.06
16	1000	1.16	13.16
32	1000	1.17	26.15
64	1000	1.17	52.12
128	1000	1.20	101.39
256	1000	1.37	177.62
512	1000	1.69	288.67
1024	1000	2.30	425.34
2048	1000	3.46	564.73
4096	1000	7.37	530.30
8192	1000	11.21	697.20
16384	1000	21.63	722.24
32768	1000	42.19	740.72
65536	640	70.09	891.69
131072	320	125.46	996.35
262144	160	238.04	1050.25
524288	80	500.76	998.48
1048576	40	1065.28	938.72
2097152	20	2033.13	983.71
4194304	10	3887.00	1029.07

# All processes entering MPI\_Finalize

To run on nodes other than node001 and node002, the `../nodes` file must be modified to contain different hostnames. To perform other benchmarks, the `PingPong` argument should be omitted.

## 3.7 Configuring BMC (IPMI/iLO) Interfaces

Bright Cluster Manager can initialize and configure the baseboard management controller (BMC) that may be present on devices. This ability can be set during the installation on the head node (section 3.3.7 of the *Installation Manual*), or it can be set after installation as described in this section. The IPMI, iLO, or UCS interface that is exposed by a BMC is treated in the cluster management infrastructure as a special type of network interface belonging to a device. In the most common setup a dedicated network (i.e. IP subnet) is created for BMC communication. The `10.148.0.0/16` network is used by default for BMC interfaces by Bright Cluster Manager.

### 3.7.1 BMC Network Settings

The first step in setting up a BMC is to add the BMC network as a network object in the cluster management infrastructure. The procedure for adding a network is described in section 3.2.2. The following settings are recommended as defaults:

Property	Value
Name	bmcnet, ilonet, or ipminet
Domain name	bmc.cluster, ilo.cluster, or ipmi.cluster
External network	false
Base address	10.148.0.0
Netmask bits	16
Broadcast address	10.148.255.255

Once the network has been created, all nodes must be assigned a BMC interface, of type `bmc`, on this network. The easiest method of doing this is to create the interface for one node device and then to clone that device several times.

For larger clusters this can be laborious, and a simple `bash` loop can be used to do the job instead:

```
[bright80 ~]# for ((i=1; i<=150; i++)) do
echo "
device interfaces node$(printf '%03d' $i)
add bmc ipmi0
set network bmcnet
set ip 10.148.0.$i
commit"; done | cmsh -x      # -x usefully echoes what is piped into cmsh
```

The preceding loop can conveniently be replaced with the `addinterface` command, run from within the device mode of `cmsh`:

```
[bright80 ~]# echo "
device
addinterface -n node001..node150 bmc ipmi0 bmcnet 10.148.0.1
commit" | cmsh -x
```

The help text for `addinterface` gives more details on how to use it.

In order to be able to communicate with the BMC interfaces, the head node also needs an interface on the BMC network. Depending on how the BMC interfaces are physically connected to the head node, the head node has to be assigned an IP address on the BMC network one way or another. There are two possibilities for how the BMC interface is physically connected:

- When the BMC interface is connected to the primary internal network, the head node should be assigned an alias interface configured with an IP address on the BMC network.
- When the BMC interface is connected to a dedicated physical network, the head node must also be physically connected to this network. A physical interface must be added and configured with an IP address on the BMC network.

## Example

Assigning an IP address on the BMC network to the head node using an alias interface:

```
[bright80->device[bright80->interfaces]% add alias eth0:0
[bright80->device[bright80->interfaces*[eth0:0*]]% set network bmcnet
[bright80->device[bright80->interfaces*[eth0:0*]]% set ip 10.148.255.254
[bright80->device[bright80->interfaces*[eth0:0*]]% commit
[bright80->device[bright80->interfaces[eth0:0]]%
Mon Dec 6 05:45:05 bright80: Reboot required: Interfaces have been modified
[bright80->device[bright80->interfaces[eth0:0]]% quit
[root@bright80 ~]# service network restart
```

As with any change to the network setup, the head node needs to be restarted to make the above change active, although in this particular case restarting the `network` service would suffice.

### 3.7.2 BMC Authentication

The node-installer described in Chapter 5 is responsible for the initialization and configuration of the BMC interface of a device. In addition to a number of network-related settings, the node-installer also configures BMC authentication credentials. By default BMC interfaces are configured with username `bright` and a random password that is generated during the installation of the head node. The password is stored by `CMDaemon`. It can be managed from `cmsh` from within the `base` object of `partition`

mode, in the `bmcsettings` submode. This means that by default, each BMC in the cluster has that username and password set during node boot.

For example, the current values of the BMC username and password for the entire cluster can be obtained and changed as follows:

### Example

```
[bright80]% partition use base
[bright80->partition[base]]% bmcsettings
[bright80->partition[base]->bmcsettings]% get username
bright
[bright80->partition[base]->bmcsettings]% get password
Za4ohnilohMa2zew
[bright80->partition[base]->bmcsettings]% set username bmcadmin
[bright80->partition*[base*]->bmcsettings*]% set password
enter new password: *****
retype new password: *****
[bright80->partition*[base*]->bmcsettings*]% commit
```

In Bright View, selecting the cluster item in the resources pane, and then using the `Settings` option, allows the BMC settings to be edited.

It is possible to set the BMC authentication credentials cluster-wide, category, or per node. As usual, category settings override cluster-wide settings, and node settings override category settings. The relevant properties are:

Property	Description
BMC User ID	User type. Normally set to 4 for administrator access.
BMC User Name	User name
BMC Password	Password for specified user name

The Bright Cluster Manager stores the configured BMC username and password. These are used:

- to configure the BMC interface from the node-installer
- to authenticate to the BMC interface after it has come up

BMC management operations, such as power cycling nodes and collecting hardware metrics, can then be performed.

### 3.7.3 Interfaces Settings

#### Interface Name

It is recommended that the network device name of a BMC interface start with `ipmi` or `ilo`, according to whether the BMC is running with IPMI or iLO. Numbers are appended to the base name, resulting in, for example: `ipmi0`.

#### Obtaining The IP address

BMC interfaces can have their IP addresses configured statically, or obtained from a DHCP server.

Only a node with a static BMC IP address has BMC power management done by Bright Cluster Manager. A node with a DHCP-assigned BMC IP address, requires custom BMC power management (section 4.1.4) due to its dynamic nature.

## 3.8 Configuring Switches And PDUs

### 3.8.1 Configuring With The Manufacturer's Configuration Interface

Network switches and PDUs that will be used as part of the cluster should be configured with the PDU/switch configuration interface described in the PDU/switch documentation supplied by the manufacturer. Typically the interface is accessed by connecting via a web browser or telnet to an IP address preset by the manufacturer.

The IP address settings of the PDU/switch must match the settings of the device as stored by the cluster manager.

- In Bright View, this is done by selecting the `Switches` resource, selecting the particular switch from within that resource (or adding it via the `Add` button), then filling in the values in the associated `Settings` window that comes up (figure 3.11). The IP address can then be set and saved.
- In `cmsh` this can be done in device mode, with a `set` command:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]% set switch01 ip 10.141.253.2
[bright80->device*]% commit
```

### 3.8.2 Configuring SNMP

Moreover, in order to allow the cluster management software to communicate with the switch or PDU, SNMP must be enabled and the SNMP community strings should be configured correctly. By default, the SNMP community strings for switches and PDUs are set to `public` and `private` for respectively read and write access. If different SNMP community strings have been configured in the switch or PDU, the `readstring` and `writestring` properties of the corresponding switch device should be changed.

#### Example

```
[bright80]% device use switch01
[bright80->device[switch01]]% get readstring
public
[bright80->device[switch01]]% get writestring
private
[bright80->device[switch01]]% set readstring public2
[bright80->device*[switch01*]]% set writestring private2
[bright80->device*[switch01*]]% commit
```

Alternatively, these properties can also be set via Bright View from the `Switches` resource, selecting the switch, and then modifying the string settings by accessing them using the `Edit` button.

### 3.8.3 Uplink Ports

Uplink ports are switch ports that are connected to other switches. CMDaemon must be told about any switch ports that are uplink ports, or the traffic passing through an uplink port will lead to mistakes in what CMDaemon knows about port and MAC correspondence. Uplink ports are thus ports that CMDaemon is told to ignore.

To inform CMDaemon about what ports are uplink ports, Bright View or `cmsh` are used:

- In Bright View, the switch is selected from the `Switches` resource option folder, and the `Edit` option opens up a settings window for that switch (figure 3.11). The port number corresponding to uplink port number is filled in the blank field beside the “Uplink:” label. More uplinks can be appended by clicking on the ⊕ widget. The state is saved with the `Save` button.






Figure 3.11: Notifying CMDaemon About Uplinks With Bright View

- In `cmsh`, the switch is accessed from the `device` mode. The uplink port numbers can be appended one-by-one with the `append` command, or set in one go by using space-separated numbers.

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]% set switch01 uplinks 15 16
[bright80->device*]% set switch02 uplinks 01
[bright80->device*]% commit
successfully committed 3 Devices
```

### 3.8.4 The `showport` MAC Address to Port Matching Tool

The `showport` command can be used in troubleshooting network topology issues, as well as checking and setting up new nodes (section 5.4.2).

#### Basic Use Of `showport`

In the `device` mode of `cmsh` is the `showport` command, which works out which ports on which switch are associated with a specified MAC address.

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]% showport 00:30:48:30:73:92
switch01:12
```

When running `showport`, CMDaemon on the head node queries all switches until a match is found.

If a switch is also specified using the “-s” option, then the query is carried out for that switch first. Thus the preceding example can also be specified as:

```
[bright80->device]% showport -s switch01 00:30:48:30:73:92
switch01:12
```

If there is no port number returned for the specified switch, then the scan continues on other switches.

### Mapping All Port Connections In The Cluster With `showport`

A list indicating the port connections and switches for all connected devices that are up can be generated using this script:

#### Example

```
#!/bin/bash
for nodename in $(cmsh -c "device; foreach * (get hostname)")
do
    macad=$(cmsh -c "device use $nodename; get mac")
    echo -n "$macad $nodename "
    cmsh -c "device showport $macad"
done
```

The script may take a while to finish its run. It gives an output like:

#### Example

```
00:00:00:00:00:00 switch01: No ethernet switch found connected to this mac address
00:30:48:30:73:92 bright80: switch01:12
00:26:6C:F2:AD:54 node001: switch01:1
00:00:00:00:00:00 node002: No ethernet switch found connected to this mac address
```

### 3.8.5 Disabling Port Detection

An administrator may wish to disable node identification based on port detection. For example, in the case of switches with buggy firmware, the administrator may feel more comfortable relying on MAC-based identification. Disabling port detection can be carried out by clearing the `ethernet switch` setting of a node, a category, or a group. For example, in `cmsh`, for a node:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use node001
[bright80->device[node001]]% clear ethernet switch
[bright80->device*[node001*]]% commit
[bright80->device[node001]]%
```

Or, for example for the default category, with the help of the `foreach` command:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]]% foreach -c default (clear ethernet switch); commit
```

### 3.8.6 The `switchoverview` Command

Also within `device` mode, the `switchoverview` command gives an overview of MAC addresses detected on the ports, and some related properties. The command works using SNMP queries. Output is similar to the following (some lines ellipsized):

```
[bright80->device]% switchoverview dell-switch1
Device: dell-switch1
State : [ UP ]
Model : 24G Ethernet Switch

Port Assignment:
```

Port	Status	Assigned	Uplink	Speed	Detected
-----					
1	UP		false	1 Gb/s	-
2	UP		false	1 Gb/s	-
3	UP		false	1 Gb/s	74:86:7A:AD:3F:2F, node3
4	UP		false	1 Gb/s	74:86:7A:AD:43:E9, node4
...					
11	UP		false	1 Gb/s	74:86:7A:AD:44:D8, node11
12	UP		false	1 Gb/s	74:86:7A:AD:6F:55, node12
...					
23	UP		false	1 Gb/s	74:86:7A:E9:3E:85, node23
24	UP		false	1 Gb/s	74:86:7A:AD:56:DF, node24
49	UP		false	10 Gb/s	74:86:7A:AD:68:FD, node1
50	UP		false	10 Gb/s	74:86:7A:AD:41:A0, node2
53	UP	node34	false	1 Gb/s	5C:F9:DD:F5:78:3D, node34
54	UP	node35	false	1 Gb/s	5C:F9:DD:F5:45:AC, node35
...					
179	UP		false	1 Gb/s	24:B6:FD:F6:20:6F, 24:B6:FD:FA:64:2F, 74:86:7A:DF:7E:4C, 90:B1:1C:3F:3D:A9, 90:B1:1C:3F:51:D1, D0:67:E5:B7:64:0F, D0:67:E5:B7:61:20
180	UP		false	100 Mb/s	QDR-switch
205	UP		true	10 Gb/s	-
206	DOWN		false	10 Gb/s	-
...					

```
[bright80 ->device]%
```

### 3.9 Disk Layouts: Disked, Semi-Diskless, And Diskless Node Configuration

Configuring the disk layout for head and regular nodes is done as part of the initial setup (section 3.3.17 of the *Installation Manual*). For regular nodes, the disk layout can also be re-configured by Bright Cluster Manager once the cluster is running. For a head node, however, the disk layout cannot be re-configured after installation by Bright Cluster Manager, and head node disk layout reconfiguration must then therefore be treated as a regular Linux system administration task, typically involving backups and resizing partitions.

The remaining parts of this section on disk layouts therefore concern regular nodes, not head nodes.

#### 3.9.1 Disk Layouts

A disk layout is specified using an XML schema (Appendix D.1). The disk layout typically specifies the devices to be used, its partitioning scheme, and mount points. Possible disk layouts include the following:

- Default layout (Appendix D.3)
- Hardware RAID setup (Appendix D.4)
- Software RAID setup (Appendix D.5)
- LVM setup (Appendix D.7)
- Diskless setup (Appendix D.9)
- Semi-diskless setup (Appendix D.10)

#### 3.9.2 Disk Layout Assertions

Disk layouts can be set to *assert*

- that particular hardware be used, using XML element tags such as `vendor` or `requiredSize` (Appendix D.11)
- custom assertions using an XML `assert` element tag to run scripts placed in CDATA sections (Appendix D.12)

### 3.9.3 Changing Disk Layouts

A disk layout applied to a category of nodes is inherited by default by the nodes in that category. A disk layout that is then applied to an individual node within that category overrides the category setting. This is an example of the standard behavior for categories, as mentioned in section 2.1.3.

By default, the cluster is configured with a standard layout specified in section D.3. The layouts can be accessed from Bright View or `cmsh`, as is illustrated by the example in section 3.9.4, which covers changing a node from disked to diskless mode:

### 3.9.4 Changing A Disk Layout From Disked To Diskless

The XML schema for a node configured for diskless operation is shown in Appendix D.9. This can often be deployed as is, or it can be modified during deployment using Bright View or `cmsh` as follows:

#### Changing A Disk Layout Using Bright View

To change a disk layout with Bright View, the current disk layout is accessed by selecting a node category or a specific node from the resource tree. In the Settings pane, the `Disk setup` field can be edited. Clicking on the `Browse` button shows several possible configurations that can be loaded up, and if desired, edited to suit the situation (figure 3.12). To switch from the existing disk layout to a diskless




Figure 3.12: Changing A Disked Node To A Diskless Node With Bright View

one, the diskless XML configuration is loaded and saved to the node or node category.

#### Changing A Disk Layout Using `cmsh`

To edit an existing disk layout from within `cmsh`, the existing XML configuration is accessed by editing the `disksetup` property in `device` mode for a particular node, or by editing the `disksetup` property in `category` mode for a particular category. Editing is done using the `set` command, which opens up a text editor:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use node001
[bright80->device[node001]]% set disksetup
```

After editing and saving the XML configuration, the change is then committed to CMDaemon with the `commit` command.

If the `disksetup` setting for a device is deleted, using the `clear` command, then the category level `disksetup` property is used by the device. This is in accordance with the usual behavior for node values that override category values (section 2.1.5).

Instead of editing an existing disk layout, another XML configuration can also be assigned. A diskless configuration may be chosen and set as follows:

#### Example

```
[bright80->device[node001]]% set disksetup /cm/local/apps/cmd/\  
etc/htdocs/disk-setup/slave-diskless.xml
```

In these preceding Bright View and `cmsh` examples, after committing the change and rebooting the node, the node then functions entirely from its RAM, without using its own disk.

However, RAM is usually a scarce resource, so administrators often wish to optimize diskless nodes by freeing up the RAM on them from the OS that is using the RAM. Freeing up RAM can be accomplished by providing parts of the filesystem on the diskless node via NFS from the head node. That is, mounting the regular node with filesystems exported via NFS from the head node. The details of how to do this are a part of section 3.10, which covers the configuration of NFS exports and mounts in general.

### 3.10 Configuring NFS Volume Exports And Mounts

NFS allows unix NFS clients shared access to a filesystem on an NFS server. The accessed filesystem is called an NFS volume by remote machines. The NFS server exports the filesystem to selected hosts or networks, and the clients can then mount the exported volume locally.

An unformatted filesystem cannot be used. The drive must be partitioned beforehand with `fdisk` or similar partitioning tools, and its filesystem formatted with `mkfs` or similar before it can be exported.

In Bright Cluster Manager, the head node is typically used to export an NFS volume to the regular nodes, and the regular nodes then mount the volume locally.

- For RHEL6, the client module and server module for NFS over RDMA are provided by default as a combined kernel module. The module is built with the compile option:

- `CONFIG_SUNRPC_XPRT_RDMA`

- In RHEL7 only the client module is provided by default. The module is built with the compile option:

- `CONFIG_SUNRPC_XPRT_RDMA_CLIENT`

The server module is not provided by default, and must be compiled by the administrator explicitly for the NFS server node. The module can be built by using the compile option:

- `CONFIG_SUNRPC_XPRT_RDMA_SERVER`

However, this is currently (January 2015) unstable and unsupported by Red Hat. The server module may be useable for custom-built kernel versions beyond 3.17. The Bright Computing suggestion for an administrator who needs a very fast network filesystem, is Lustre (section 7.8 of the *Installation Manual*) over InfiniBand.

If auto-mounting is used, then the configuration files for exporting should be set up on the NFS server, and the mount configurations set up on the software images. The service “`autofs`” or the equivalent can be set up using Bright View via the “`Services`” option (section 3.11) on the head and regular nodes or node categories. With `cmsh` the procedure to configure auto-mounting on the head and regular nodes could be:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use bright80
[bright80->device[bright80]]% services
[bright80->device[bright80]->services]% add autofs
[bright80->device*[bright80*]->services*[autofs*]]% show
Parameter                                Value
-----
Autostart                                no
Belongs to role                          no
Monitored                                no
Revision
Run if                                   ALWAYS
Service                                  autofs
[bright80->device*[bright80*]->services*[autofs*]]% set autostart yes
[bright80->device*[bright80*]->services*[autofs*]]% commit
[bright80->device[bright80]->services[autofs]]% category use default
[bright80->category[default]]% services
[bright80->category[default]->services]% add autofs
[bright80->category*[default*]->services*[autofs*]]% set autostart yes
[bright80->category*[default*]->services*[autofs*]]% commit
[bright80->category[default]->services[autofs]]%
```

Filesystems imported via an auto-mount operation must explicitly be excluded in `excludelistupdate` by the administrator, as explained in section 5.6.1, page 176.

The rest of this section describes the configuration of NFS for static mounts, using Bright View or `cmsh`.

Sections 3.10.1 and 3.10.2 explain how exporting and mounting of filesystems is done in general by an administrator using Bright View and `cmsh`, and considers some mounting behavior that the administrator should be aware of.

Section 3.10.3 discusses how filesystems in general on a diskless node can be replaced via mounts of NFS exports.

Section 3.10.4 discusses how the root (/) filesystem on a diskless node can be replaced via mounts of NFS exports.

Section 3.10.5 discusses how OFED InfiniBand or iWarp drivers can be used to provide NFS over RDMA.

### 3.10.1 Exporting A Filesystem Using Bright View And `cmsh`

#### Exporting A Filesystem Using Bright View

As an example, if an NFS volume exists at “`bright80:/modeldata`” it can be exported using Bright View as follows:

The `bright80` head node is selected via the clickpath `Devices→Head nodes[bright80]→Settings→Filesystem exports`. This shows the list of exports (figure 3.13):




Figure 3.13: NFS Exports From A Head Node Viewed Using Bright View

Using the Add button, a new entry (figure 3.14) can be configured with values as shown:




Figure 3.14: Setting Up An NFS Export Using Bright View

For this example, the value for “Name” is set arbitrarily to “Fluid Model Data”, the value for Path is set to /modeldata, and the value for Network is set from the selection menu to allowing

access to `internalnet` (by default `10.141.0.0/16` in CIDR notation).

By setting the `Write` option to `Disabled`, read-only access is kept.

Saving this preceding configuration means the NFS server now provides NFS access to this filesystem for `internalnet`.

The network can be set to other network values using CIDR notation. It can also be set to particular hosts such as just `node001` and `node002`, by specifying a value of `"node001 node002"` instead. Other settings and options are also possible and are given in detail in the man pages for `exports(5)`.

### Exporting A Filesystem Using `cmsh`

The equivalent to the preceding Bright View NFS export procedure can be done in `cmsh` by using the `fsexports` submode on the head node (some output elided):

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use bright80
[bright80->device[bright80]]% fsexports
[...->fsexports]% add "Fluid Model Data"
[...->fsexports*[Fluid Model Data*]]% set path /modeldata
[...[Fluid Model Data*]]% set hosts 10.141.0.0/16
[...[Fluid Model Data*]]% commit
[...->fsexports[Fluid Model Data]]% list | grep Fluid
```

Name (key)	Path	Hosts	Write
Fluid Model Data	/modeldata	10.141.0.0/16	no

### 3.10.2 Mounting A Filesystem Using Bright View And `cmsh`

Continuing on with the export example from the preceding section, the administrator decides to mount the remote filesystem over the default category of nodes. Nodes can also mount the remote filesystem individually, but that is usually not a common requirement in a cluster. The administrator also decides not to re-use the exported name from the head node. That is, the remote mount name `modeldata` is not used locally, even though NFS allows this and many administrators prefer to do this. Instead, a local mount name of `/modeldatagpu` is used, perhaps because it avoids confusion about which filesystem is local to a person who is logged in, and perhaps to emphasize the volume is being mounted by nodes with GPUs.

#### Mounting A Filesystem Using Bright View

Thus, in Bright View, values for the remote mount point (`bright80:/modeldata`), the filesystem type (`nfs`), and the local mount point (`/modeldatagpu`) can be set in category mode, while the remaining options stay at their default values (figure 3.15):






Figure 3.15: Setting Up NFS Mounts On A Node Category Using Bright View

Saving the configuration saves the values, creating the local mount point, and the volume can now be accessed by nodes in that category.

#### Mounting A Filesystem Using `cmsh`

The equivalent to the preceding Bright View NFS mount procedure can be done in `cmsh` by using the `fsmounts` submode, for example on the `default` category. The `add` method under the `fsmounts` submode sets the mountpoint path, in this case `/modeldatagpu` (some output elided):

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% category use default
[bright80->category[default]]% fsmounts
[bright80->category[default]->fsmounts]% add /modeldatagpu
[bright80->...[/modeldatagpu*]]% set device bright80:/modeldata
[bright80->...[/modeldatagpu*]]% set filesystem nfs
[bright80->category*[default*]->fsmounts*[/modeldatagpu*]]% commit
[bright80->category[default]->fsmounts[/modeldatagpu]]%
Device          Mountpoint (key)  Filesystem
-----
...
bright80:/modeldata  /modeldatagpu    nfs
[bright80->category[default]->fsmounts[/modeldatagpu]]% show
Parameter      Value
-----
Device          bright80:/modeldata
Dump            no
Filesystem      nfs
Filesystem Check 0
Mount options   defaults
Mountpoint      /modeldatagpu
```

Values can be set for “Mount options” other than default. For example, the “noac” flag can be added as follows:

```
[bright80->...[/modeldatagpu]]% set mountoptions defaults,noac; commit
```

Mounting a CIFS might use:

```
[bright80->...[/modeldatagpu]]% set mountoptions gid,users,file_mode=0666,dir_mode=0777,\
iocharset=iso8859-15,credentials=/path/to/credential
[bright80->...[/modeldatagpu*]]% commit
```

### General Considerations On Mounting A Filesystem

There may be a requirement to segregate the access of nodes. For example, in the case of the preceding, because some nodes have no associated GPUs.

Besides the “Allowed hosts” options of NFS exports mentioned earlier in section 3.10.1, Bright Cluster Manager offers two more methods to fine tune node access to mount points:

- Nodes can be placed in another category that does not have the mount point.
- Nodes can have the mount point set, not by category, but per device within the `Nodes` resource. For this, the administrator must ensure that nodes that should have access have the mount point explicitly set.

Other considerations on mounting are that:

- When adding a mount point object:
  - The settings take effect right away by default on the nodes or node categories.
  - If `noauto` is set as a mount option, then the option only takes effect on explicitly mounting the filesystem.
  - If “AutomaticMountAll=0” is set as a `CMDaemon` option, then `CMDaemon` changes to `/etc/fstab` are written to the file, but the `mount -a` command is not run by `CMDaemon`. However, the administrator should be aware that since `mount -a` is run by the distribution during booting, a node reboot implements the mount change.
- While a mount point object may have been removed, `umount` does not take place until reboot, to prevent mount changes outside of the cluster manager. If a `umount` needs to be done without a reboot, then it should be done manually, for example, using the `pdsh` or `pexec` command (section 13.1), to allow the administrator to take appropriate action if unmounting goes wrong.
- When manipulating mount points, the administrator should be aware which mount points are inherited by category, and which are set for the individual node.
  - In `cmsh`, the category a mount belongs to is displayed in brackets. This is displayed from within the `fsmounts` submode of the `device` mode for a specified node:

#### Example

```
[root@bright80 ~]# cmsh -c "device; fsmounts node001; list"
```

Device	Mountpoint (key)	Filesystem
[default] none	/dev/pts	devpts
[default] none	/proc	proc
[default] none	/sys	sysfs
[default] none	/dev/shm	tmpfs
[default] \$localnfserv+	/cm/shared	nfs
[default] bright80:/home	/home	nfs
bright80:/cm/shared/exa+	/home/examples	nfs

```
[root@bright80 ~]#
```

To remove a mount point defined at category level for a node, it must be removed from within the category, and not from the specific node.

### Mount Order Considerations

Care is sometimes needed in deciding the order in which mounts are carried out.

- For example, if both `/usr/share/doc` and a replacement directory subtree `/usr/share/doc/compat-gcc-34-3.4.6java` are to be used, then the stacking order should be that `/usr/share/doc` is mounted first. This order ensures that the replacement directory subtree overlays the first mount. If, instead, the replacement directory were the first mount, then it would be overlaid, inaccessible, and inactive.
- There may also be dependencies between the subtrees to consider, some of which may prevent the start up of applications and services until they are resolved. In some cases, resolution may be quite involved.

The order in which such mounts are mounted can be modified with the `up` and `down` commands within the `fsmounts` submode of `cmsh`.

### 3.10.3 Mounting A Filesystem Subtree For A Diskless Node Over NFS

#### NFS Vs `tmpfs` For Diskless Nodes

For diskless nodes (Appendix D.9), the software image (section 2.1.2) is typically installed from a provisioning node by the node-installer during the provisioning stage, and held as a filesystem in RAM on the diskless node with the `tmpfs` filesystem type.

It can be worthwhile to replace subtrees under the diskless node filesystem held in RAM with subtrees provided over NFS. This can be particularly worthwhile for less frequently accessed parts of the diskless node filesystem. This is because, although providing the files over NFS is much slower than accessing it from RAM, it has the benefit of freeing up RAM for tasks and jobs that run on diskless nodes, thereby increasing the cluster capacity.

An alternative “semi-diskless” way to free up RAM is to use a local disk on the node itself for supplying the subtrees. This is outlined in Appendix D.10.

#### Moving A Filesystem Subtree Out Of `tmpfs` To NFS

To carry out subtree provisioning over NFS, the subtrees are exported and mounted using the methods outlined in the previous examples in sections 3.10.1 and 3.10.2. For the diskless case, the exported filesystem subtree is thus a particular path under `/cm/images/<image>`<sup>2</sup> on the provisioning node, and the subtree is mounted accordingly under `/` on the diskless node.

While there are no restrictions placed on the paths that may be mounted in Bright Cluster Manager 8.0, the administrator should be aware that mounting certain paths such as `/bin` is not possible.

When Bright View or `cmsh` are used to manage the NFS export and mount of the subtree filesystem, then `tmpfs` on the diskless node is reduced in size due to the administrator explicitly excluding the subtree from `tmpfs` during provisioning.

An example might be to export `/cm/images/default-image` from the head node, and mount the directory available under it, `usr/share/doc`, at a mount point `/usr/share/doc` on the diskless node. In `cmsh`, such an export can be done by creating an FS export object corresponding to the software image object `defaultimage` with the following indicated properties (some prompt output elided):

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use bright80; fsexports
[bright80->device[bright80]->fsexports]% add defaultimage
[bright80...defaultimage*]]% set path /cm/images/default-image
[bright80...defaultimage*]]% set hosts 10.141.0.0/16
[bright80...defaultimage*]]% commit
```

<sup>2</sup>by default `<image>` is `default-image` on a newly-installed cluster

```
[bright80...defaultimage]]% list | grep defaultimage
```

Name (key)	Path	Hosts	Write
defaultimage	/cm/images/default-image	10.141.0.0/16	no

As the output to `list` shows, the NFS export should be kept read-only, which is the default. Appropriate parts of the export can then be mounted by a node or node category. The mount is defined by setting the mount point, the `nfs` filesystem property, and the export device. For example, for a node category (some output elided):

```
[br...defaultimage]]% category use default
[bright80->category[default]]% fsmounts
[bright80->category[default]->fsmounts]% add /usr/share/doc
[bright80->...[/usr/share/doc*]]% set device bright80:/cm/images/default-image/user/share/doc
[bright80->...[/usr/share/doc*]]% set filesystem nfs
[bright80->category*[default*]->fsmounts*[/usr/share/doc*]]% commit
[bright80->category[default]->fsmounts[/usr/share/doc]]% list
```

Device	Mountpoint (key)	Filesystem
...	...	...
bright80:/cm/images/usr/share/doc	/usr/share/doc	nfs

```
[bright80->category[default]->fsmounts[/usr/share/doc]]% show
```

Parameter	Value
Device	bright80:/cm/images/default-image/usr/share/doc
Dump	no
Filesystem	nfs
Filesystem Check	0
Mount options	defaults
Mountpoint	/usr/share/doc

Other mount points can be also be added according to the judgment of the system administrator. Some consideration of mount order may be needed, as discussed on page 89 under the subheading “Mount Order Considerations”.

### An Example Of Several NFS Subtree Mounts

The following mounts save about 500MB from `tmpfs` on a diskless node with CentOS 6, as can be worked out from the following subtree sizes:

```
[root@bright80 ~]# cd /cm/images/default-image/
[root@bright80 default-image]# du -sh usr/share/locale usr/java usr/share/doc usr/src
262M    usr/share/locale
78M     usr/java
107M    usr/share/doc
45M     usr/src
```

The filesystem mounts can then be created using the techniques in this section. After doing that, the result is then something like (some lines omitted):

```
[root@bright80 default-image]# cmsh
[bright80]% category use default; fsmounts
[bright80->category[default]->fsmounts]% list -f device:53,mountpoint:17
```

device	mountpoint (key)
...	...
master:/cm/shared	/cm/shared

```

master:/home                               /home
bright80:/cm/images/default-image/usr/share/locale /usr/share/locale
bright80:/cm/images/default-image/usr/java       /usr/java
bright80:/cm/images/default-image/usr/share/doc   /usr/share/doc
bright80:/cm/images/default-image/usr/src         /usr/src
[bright80->category[default]->fsmounts]%

```

Diskless nodes that have NFS subtree configuration carried out on them can be rebooted to start them up with the new configuration.

### 3.10.4 Mounting The Root Filesystem For A Diskless Node Over NFS

Mounting the root filesystem over NFS is a special case of mounting filesystem subtrees for a diskless node over NFS (section 3.10.3). The difference this time is that an initial root filesystem is deployed on the node via NFS as part of the standard Linux boot procedure. Some `tmpfs` mounts are then overlaid on top of parts of this filesystem.

The node being configured must have a disk setup that is diskless (section 3.9.4) for its node or node category.

If configuring a node category, it can be configured as follows on a CentOS 6 or 7 system:

1. The full diskless disk setup is partitioned first:

```

[root@bright80 ~]# cmsh
[bright80]% category use default
[bright80->category[default]]% set disksetup /cm/images/default-image/cm/local/apps/cmd/\
etc/htdocs/disk-setup/slave-diskless.xml
[bright80->category*[default*]]% commit    #puts full OS in RAM

```

2. Then the default image is exported to the internal network:

```

[bright80->category[default]]% device use master; fsexports
[bright80->device[bright80]->fsexports]% add /cm/images/default-image
...->fsexports*[cm/images/default-image*]]% set hosts internalnet
...->fsexports*[cm/images/default-image*]]% set name default@internal
...->fsexports*[default@internal*]]% commit    #exports default image
[bright80->device[bright80]->fsexports[default@internal]]% quit

```

3. The exported root filesystem is now mounted over the initial root filesystem:

```

[root@bright80 ~]# cmsh -c "category use default; fsmounts; add /; set\
device master:/cm/images/default-image; set mountoptions defaults,ro;\
set filesystem nfs; commit"    #adds readonly root via nfs

```

The root filesystem should be read-only during normal use. However, when the main system starts up after provisioning, a distribution start up script mounts the root filesystem as read-write. One way to get it back to a read-only state again is to set a finalize script (section 3.15.4) that arranges for the drive to remount itself as read-only after the system is fully up. The remount can be done with an `rc.local` file, which runs after all the other `rc` start up scripts have run. A suitable finalize script is then:

```

#!/bin/bash
echo "mount -o remount,ro /" >> /localdisk/etc/rc.local

```

4. The filesystem for `/` however has plenty of parts that need to be writable too. These are now mounted back in minimal subtrees into RAM. Keeping these mounts minimal means that the RAM used by the node is minimal. These read/write subtrees can be specified in a file, with one line per subtree:

```

[root@bright80 ~]# cat mountfiles    #for centos 6
/var/cache

```

```

/var/log
/var/lock
/var/run
/var/tmp
/var/spool
/tmp
/dev
/cm/local/apps/cmd/etc
/cm/local/apps/openldap/etc
/cm/local/apps/sge/var
/cm/local/apps/torque/var
/cm/local/apps/slurm/var
/cm/local/apps/pbspro/var
/cm/local/apps/openlava/var
/etc

```

For CentOS 7 the subtrees are slightly different:

```

[root@bright80 ~]# cat mountfiles          #for centos 7
/var/cache
/var/log
/var/tmp
/var/spool
/tmp
/dev
/cm/local/apps/cmd/etc
/cm/local/apps/openldap/etc
/cm/local/apps/sge/var
/cm/local/apps/torque/var
/cm/local/apps/slurm/var
/cm/local/apps/pbspro/var
/cm/local/apps/openlava/var
/etc
/run
/var/lib #required by postfix and rpc-statd

```

The `/cm/local/apps/openlava/var` directory does not exist by default, and so it should only be placed in `mountfiles` if the OpenLava software has been installed (section 7.5.6). The various workload manager `/var` directories for SGE/Torque/Slurm/PBS Pro/OpenLava are only needed if these workload managers are to be set up and used.

The subtrees can be mounted with a `for` loop:

```

[root@bright80 ~]# (echo "category use default; fsmounts"
  for i in $(<mountfiles)
  do
    echo "add $i; set device tmpfs; set filesystem tmpfs; exit"
  done
  echo "commit" ) | cmlsh

```

If there is further software in the root filesystem that needs write access, that too should be mounted back into RAM.

The diskless nodes cannot be powered off with a simple `poweroff` or rebooted with a `reboot`. This is because the parts of the filesystem required to carry out these actions are unmounted before they are called in the diskless configuration. The `-f|--force` option to these commands forces a `poweroff` or `reboot`, but should only be used after first cleanly unmounting any writable shared filesystems, such as `/cm/shared` and `/home`. This is because the forcing options interrupt I/O syncing when invoked, which can result in a corrupted filesystem.

### 3.10.5 Configuring NFS Volume Exports And Mounts Over RDMA With OFED Drivers

If running NFS over RDMA, then at least NFS version 4.0 is recommended. NFS version 3 will also work with RDMA, but uses iPoIB encapsulation instead of native verbs. NFS version 4.1 uses the RDMA Connection Manager (`librdmacm`), instead of the InfiniBand Connection Manager (`ib_cm`) and is thereby also able to provide pNFS.

The administrator can set the version of NFS used by the cluster by setting the value of `Nfsvers` in the file `/etc/nfsmount.conf` on all the nodes, including the head node.

#### Drivers To Use For NFS over RDMA Must Be From The Parent Distribution

The use of the RDMA protocol (section 3.6) to provide NFS, by installing updated Bright Cluster Manager OFED drivers (section 7.6 of the *Installation Manual*) is currently not supported. This is because these drivers are packaged by Bright Computing from the vendor (Mellanox or Qlogic) releases, and the vendor releases themselves do not support NFS over RDMA.

However, NFS over RDMA does work within Bright Cluster Manager with the OFED drivers that the parent distribution provides, in the case of RHEL6/SL6/CENTOS6. For the remaining distributions, this option can be selected, but NFS will fall back to using the default NFS TCP/IP protocol.

When using NFS over RDMA, `ibnet`, the IP network used for InfiniBand, should be set. Section 3.6.3 explains how that can be done.

#### Exporting With Bright View And `cmsh` Using NFS Over RDMA

With the drivers installed, a volume export can be carried out using NFS over RDMA.

The procedure using Bright View is much the same as done in section 3.10.1 (“Exporting A Filesystem Using Bright View”), except for that the `ibnet` network should be selected instead of the default `internalnet`, and the “NFS over RDMA” checkbox should be ticked.

The procedure using `cmsh` is much the same as done in section 3.10.1 (“Exporting A Filesystem Using `cmsh`”), except that the `ibnet` network (normally with a recommended value of 10.149.0.0/16) should be set, and the `rdma` option should be set.

#### Example

(based on the example in section 3.10.1)

```
...
[...->fsexports*[Fluid Model Data*]]% set path /modeldata
[...[Fluid Model Data*]]% set hosts ibnet
[...[Fluid Model Data*]]% set rdma yes
[...[Fluid Model Data*]]% commit
...
```

#### Mounting With Bright View And `cmsh` Using NFS Over RDMA

The mounting of the exported filesystems using NFS over RDMA can then be done.

The procedure using Bright View is largely like that in section 3.10.2, (“Mounting A Filesystem Using Bright View”), except that the `Device` entry must point to `master.ib.cluster` so that it resolves to the correct NFS server address for RDMA, and the checkbox for `NFS over RDMA` must be ticked.

The procedure using `cmsh` is similar to that in section 3.10.2, (“Mounting A Filesystem Using `cmsh`”), except that device must be mounted to the `ibnet`, and the `rdma` option must be set, as shown:

#### Example

(based on the example in section 3.10.2)

```
...
[bright80->category[default]->fsmounts]% add /modeldatagpu
[bright80->...[/modeldatagpu*]]% set device bright80.ib.cluster:/modeldata
[bright80->...[/modeldatagpu*]]% set filesystem nfs
```

```
[bright80->...[/modeldatapgu*]]% set rdma yes
[bright80->category*[default*]->fsmounts*[/modeldatapgu*]]% commit
...
```

### 3.11 Managing And Configuring Services

#### 3.11.1 Why Use The Cluster Manager For Services?

The unix services can be managed from the command line using the standard distribution tools:

```
chkconfig
```

and

```
service <service name> start|stop|status|...
```

where *<service name>* indicates a service such as `mysqld`, `mariabd`, `nfs`, `postfix` and so on.

Already installed services can also be brought under Bright Cluster Manager control, and started and stopped with Bright View and `cmsh` tools.

An additional convenience that comes with the cluster manager tools is that some `CMDaemon` parameters useful for managing services in a cluster are very easily configured, whether on the head node, a regular node, or for a node category. These parameters are:

- `monitored`: checks periodically if a service is running. Information is displayed and logged the first time it starts or the first time it dies
- `autostart`: restarts a failed service that is being `monitored`.
  - If `autostart` is set to `on`, and a service is stopped using Bright Cluster Manager, then no attempts are made to restart the service. Attempted autostarts become possible again only after Bright Cluster Manager starts the service again.
  - If `autostart` is set to `on`, and if a service is removed using Bright Cluster Manager, then the service is stopped before removal.
  - If `autostart` is `off`, then a service that has not been stopped by `CMDaemon` still undergoes an attempt to restart it, if
    - \* `CMDaemon` is restarted
    - \* its configuration files are updated by `CMDaemon`, for example in other modes, as in the example on page 57.
- `runif`: (only honored for nodes used as part of a high-availability configuration (chapter 15)) whether the service should run with a state of:
  - `active`: run on the active node only
  - `passive`: run on the passive only
  - `always`: run both on the active and passive
  - `preferpassive`: preferentially run on the passive if it is available. Only honored for head nodes.

The details of a service configuration remain part of the configuration methods of the service software itself.

- Thus Bright Cluster Manager can run actions on typical services only at the generic service level to which all the unix services conform. This means that `CMDaemon` can run actions such as starting and stopping the service. If the restarting action is available in the script, then `CM-Daemon` can also run that. An `init` script example can be found within the file `/usr/share/doc/initscripts-<version>/sysvinitfiles` in RHEL6 and derivatives.



- The operating system configuration of the service itself, including its persistence on reboot, remains under control of the operating system, and is not handled by CMDaemon. So, stopping a service within CMDaemon means that by default the service will still start up on reboot. Running `chkconfig` from the command line can be used to configure the service to no longer start up on reboot.

Bright Cluster Manager can be used to keep a service working across a failover event with an appropriate `runif` setting and appropriate failover scripts such as the `Prefailover` script and the `Postfailover` script (section 15.4.6). The details of how to do this will depend on the service.

### 3.11.2 Managing And Configuring Services—Examples

If, for example, the CUPS software is installed (`yum install cups`), then the CUPS service can be managed in several ways:

#### Managing The Service From The Regular Shell, Outside Of CMDaemon

Standard unix commands from the bash prompt work, as shown by this session:

```
[root@bright80 ~]# chkconfig cups on
[root@bright80 ~]# service cups start
```

#### Managing The Service From `cmsh`

**Starting the service in `cmsh`:** The following session illustrates adding the CUPS service from within `device` mode and the `services` submode. The device in this case is a regular node, `node001`, but a head node can also be chosen. Monitoring and auto-starting are also set in the session (some lines elided):

```
[bright80]% device services node001
[bright80->device[node001]->services]% add cups
[bright80->device*[node001*]->services*[cups*]]% show
Parameter                                     Value
-----
Autostart                                     no
Belongs to role                               no
Monitored                                    no
...
Run if                                         ALWAYS
Service                                       cups
...
[bright80->device*[node001*]->services*[cups*]]% set monitored on
[bright80->device*[node001*]->services*[cups*]]% set autostart on
[bright80->device*[node001*]->services*[cups*]]% commit
[bright80->device[node001]->services[cups]]%
Apr 14 14:02:16 2017 [notice] node001: Service cups was started
[bright80->device[node001]->services[cups]]%
```

**Other service options in `cmsh`:** Within `cmsh`, the `start`, `stop`, `restart`, and `reload` options to the `service <service name> start|stop|restart|...`

command can be used to manage the service at the `services` submode level. For example, continuing with the preceding session, stopping the CUPS service can be done by running the `cups` service command with the `stop` option as follows:

```
[bright80->device[node001]->services[cups]]% stop
Fri Apr 14 14:03:40 2017 [notice] node001: Service cups was stopped
Successfully stopped service cups on: node001
[bright80->device[node001]->services[cups]]%
```

The service is then in a STOPPED state according to the status command.

```
[bright80->device[node001]->services[cups]]% status
cups                                [STOPPED]
```

Details on how a state is used when monitoring a service are given in the section “Monitoring A Service With `cms`h And Bright View” on page 97.

Continuing from the preceding session, the CUPS service can also be added for a node category from category mode:

```
[bright80->device[node001]->services[cups]]% category
[bright80->category]% services default
[bright80->category[default]->services]% add cups
```

As before, after adding the service, the monitoring and autostart parameters can be set for the service. Also as before, the options to the service `<service name> start|stop|restart|... command` can be used to manage the service at the services submode level. The settings apply to the entire node category (some lines elided):

### Example

```
[bright80->category*[default*]->services*[cups*]]% show
...
[bright80->category*[default*]->services*[cups*]]% set autostart yes
[bright80->category*[default*]->services*[cups*]]% set monitored yes
[bright80->category*[default*]->services*[cups*]]% commit
[bright80->category[default]->services[cups]]%
Fri Apr 14 14:06:27 2017 [notice] node002: Service cups was started
Fri Apr 14 14:06:27 2017 [notice] node005: Service cups was started
Fri Apr 14 14:06:27 2017 [notice] node004: Service cups was started
Fri Apr 14 14:06:27 2017 [notice] node003: Service cups was started
[bright80->category[default]->services[cups]]% status
[bright80->category[default]->services[cups]]% status
node001..... cups                [STOPPED ]
node002..... cups                [  UP   ]
node003..... cups                [  UP   ]
node004..... cups                [  UP   ]
node005..... cups                [  UP   ]
```

### Managing The Service From Bright View

Using Bright View, a service can be managed from a Services option, accessible from the Settings option of

- Head Nodes, for example via a clickpath of  
Devices→Head Nodes[bright80]→Settings→Services
- Physical Nodes, for example via a clickpath of  
Devices→Physical Nodes[node001]→Settings→Services
- Node categories, for example via a clickpath of  
Grouping→Node categories[default]→Settings→Services

Figure 3.16 shows the Services subwindow accessed from the default software image, which is an item within the “Node Categories” subwindow. By default, there are no services set by the category for nodes.




Figure 3.16: Operating System Services Subwindow In Bright View

The service `<service name> start|stop|restart...` command options `start`, `stop`, `restart`, and so on, are displayed as options in the service configuration window.

The existence of the service itself can be managed using the `Add`, `Remove`, and, if the service already exists, the `Edit` button. The change can be reverted with the `Revert` button.

Figure 3.17 shows CUPS being set up from an `Add` dialog in the services subwindow. The subwindow is accessible via the `[Add]` button of figure 3.16.




Figure 3.17: Setting Up A Service Using Bright View

For a service in the services subwindow, clicking on the `Status` button in figure 3.16 displays a grid of the state of services on a running node as either `Up` or `Down`.

### Monitoring A Service With `cmsh` And Bright View

The service is in a `DOWN` state if it is not running, and in a `FAILING` state if it is unable to run after 10 auto-starts in a row. Event messages are sent during these first 10 auto-starts. After the first 10 auto-starts, no more event messages are sent, but autostart attempts continue.

In case an autostart attempt has not yet restarted the service, the `reset` option may be used to attempt an immediate restart. The `reset` option is not a service option in the regular shell, but is used by `CMDaemon` (within `cmsh` and Bright View) to clear a `FAILING` state of a service, reset the attempted auto-starts count to zero, and attempt a restart of the service.

The monitoring system sets the `ManagedServicesOk` health check (Appendix G.2.1) to a state of

FAIL if any of the services it monitors is in the FAILING state. In `cmsh`, the statuses of the services are listed by running the `latesthealthdata` command (section 12.6.3) from `device` mode.

Standard `init.d` script behavior is that the script return a non-zero exit code if the service is down, and a zero exit code if the service is up. A non-zero exit code makes Bright Cluster Manager decide that the service is down, and should be restarted.

However, some scripts return a non-zero exit code even if the service is up. These services therefore have Bright Cluster Manager attempt to start them repetitively, even though they are actually running.

This behavior is normally best fixed by setting a zero exit code for when the service is up, and a non-zero exit code for when the service is down.

### Removing A Service From CMDaemon Control Without Shutting It Down

Removing a service from Bright Cluster Manager control while `autostart` is set to `on` stops the service on the nodes:

```
[bright80->category[default]->services]% add cups
[bright80->category*[default*]->services*[cups*]]% set monitored on
[bright80->category*[default*]->services*[cups*]]% set autostart on
[bright80->category*[default*]->services*[cups*]]% commit; exit
[bright80->category[default]->services]% remove cups; commit
Wed May 23 12:53:58 2012 [notice] node001: Service cups was stopped
```

In the preceding `cmsh` session, `cups` starts up when the `autostart` parameter is committed, if `cups` is not already up.

The behavior of having the service stop on removal is implemented because it is usually what is wanted.

However, sometimes the administrator would like to remove the service from CMDaemon control without it shutting down. To do this, `autostart` must be set to `off` first.

```
[bright80->category[default]->services]% add cups
[bright80->category*[default*]->services*[cups*]]% set monitored on
[bright80->category*[default*]->services*[cups*]]% set autostart off
[bright80->category*[default*]->services*[cups*]]% commit; exit
Wed May 23 12:54:40 2012 [notice] node001: Service cups was started
[bright80->category[default]->services]% remove cups; commit
[bright80->category[default]->services]% !# no change: cups stays up
```

## 3.12 Managing And Configuring A Rack

### 3.12.1 Racks

A cluster may have local nodes grouped physically into racks. A rack is 42 units in height by default, and nodes normally take up one unit.

#### Racks Overview

**Racks overview in Bright View:** The Racks overview pane can be opened up in Bright View via the clickpath `Datacenter Infrastructure→Racks` (figure 3.18). Racks can then be added, removed, or edited from that pane.

Within the Racks pane:

- a new rack item can be added with the `Add` button.
- an existing rack item can be edited with the `Edit` button, or by double-clicking on the item itself in the pane.

These actions bring up the rack configuration pane (figure 3.19).




Figure 3.18: Racks Overview Pane Using Bright View

**Racks overview in cmsh:** The rack mode in cmsh allows racks defined in the cluster manager to be listed:

```
[bright80->rack]% list
```

Name (key)	Room	x-Coordinate	y-Coordinate	Height
rack2	skonk works	2	0	42
racknroll		1	0	42

### Rack Configuration Settings

**Rack configuration settings in Bright View:** The Settings pane for editing a rack item selected from the Racks pane is shown in figure 3.19.




Figure 3.19: Rack Configuration Settings Using Bright View

The rack item configuration settings are:

- **Name:** A unique name for the rack item. Names such as rack001, rack002 are a sensible choice
- **Room:** A unique name for the room the rack is in.
- **Position:** The *x*- and *y*-coordinates of the rack in a room. These coordinates are meant to be a hint for the administrator about the positioning of the racks in the room, and as such are optional, and can be arbitrary. The **Notes** field can be used as a supplement or as an alternative for hints.

- Height: by default this is the standard rack size of 42U.
- Bottom of rack is position 1: Normally, a rack uses the number 1 to mark the top and 42 to mark the bottom position for the places that a device can be positioned in a rack. However, some manufacturers use 1 to mark the bottom instead. Ticking the checkbox records the numbering layout accordingly for all racks, if the checkboxed rack is the first rack seen in Rackview.

**Rack configuration settings in cmsh:** In cmsh, tab-completion suggestions for the set command in rack mode display the racks available for configuration. On selecting a particular rack (for example, rack2 as in the following example), tab-completion suggestions then display the configuration settings available for that rack:

### Example

```
[bright80->rack]% set rack
rack1 rack2 rack3
[bright80->rack]% set rack2
height          name          revision      width          y-coordinate
inverted        notes          room          x-coordinate
```

The configuration settings for a particular rack obviously match with the parameters associated with and discussed in figure 3.19. The only slightly unobvious match is the Boolean parameter `inverted` in cmsh, which simply corresponds directly to “Bottom of rack is position 1” in Bright View.

Setting the values can be done as in this example:

### Example

```
[bright80->rack]% use rack2
[bright80->rack[rack2]]% set room "skonk works"
[bright80->rack*[rack2*]]% set x-coordinate 2
[bright80->rack*[rack2*]]% set y-coordinate 0
[bright80->rack*[rack2*]]% set inverted no
[bright80->rack*[rack2*]]% commit
[bright80->rack[rack2]]%
```

## 3.12.2 Assigning Devices To A Rack

Devices such as nodes, switches, and chassis, can be assigned to racks.

By default, no such devices are assigned to a rack.

Devices can be assigned to a particular rack and to a particular position within the rack as follows:

### Assigning Devices To A Rack Using Bright View

Using Bright View, a device such as a node `node001` can be assigned to a rack via the clickpath `Devices→Physical Nodes[node001]→Settings→Rack` (figure 3.20):




Figure 3.20: Rack Assignment Using Bright View

**Assigning Devices To A Rack Using cmsh**

Using `cmsh`, the assignment can be done to a rack as follows:

```
[bright80->device]% foreach -n node001..node003 (set deviceheight 1; se\
t deviceposition 2; set rack rack2)
[bright80->device*]% commit
Successfully committed 3 Devices
[bright80->device]%
```

**The Convention Of The Top Of The Device Being Its Position**

Since rack manufacturers usually number their racks from top to bottom, the position of a device in a rack (using the parameter `Position` in Bright View, and the parameter `deviceposition` in `cmsh`) is always taken to be where the top of the device is located. This is the convention followed even for the less usual case where the rack numbering is from bottom to top.

A position on a rack is 1U of space. Most devices have a height that fits in that 1U, so that the top of the device is located at the same position as the bottom of the device, and no confusion is possible. The administrator should however be aware that for any device that is greater than 1U in height such as, for example, a blade enclosure chassis (section 3.12.3), the convention means that it is the position of the top of the device that is where the device is considered to be. The position of the bottom of the device is ignored.

**3.12.3 Assigning Devices To A Chassis****A Chassis As A Physical Part Of A Cluster**

In a cluster, several local nodes may be grouped together physically into a chassis. This is common for clusters using blade systems. Clusters made up of blade systems use less space, less hardware, and less electrical power than non-blade clusters with the same computing power. In blade systems, the blades are the nodes, and the chassis is the blade enclosure.

A blade enclosure chassis is typically 6 to 10U in size, and the node density for server blades is typically 2 blades per unit with 2014 technology.

### Chassis Configuration And Node Assignment

**Basic chassis configuration and node assignment with Bright View:** Adding and removing chassis from a list of chassis in Bright View can be done via the clickpath `Devices→Chassis`. This opens up a Chassis pane that provides an overview of the list of chassis.

Within the Chassis pane, each chassis can further have an individual subpane opened for it. Each individual chassis configuration can be added, edited, or deleted via this chassis subpane (figure 3.21).




Figure 3.21: Bright View Chassis Subpane

The options that can be set within the subpane include the following:

- **Hostname:** a name that can be assigned to the chassis operating system
- **Mac:** the MAC address of the chassis
- **Rack:** the rack in which the chassis is placed
- **Members:** the Members menu option allows devices to be assigned to a chassis (figure 3.22). An item within the Device set can be any item from the subsets of Node, Switch, Power Distribution Unit, Generic Device, Rack Sensor, and Gpu Unit. These items can be filtered for viewing, depending on whether they are Assigned (members of the chassis), Not assigned (not members of the chassis), or they can All be viewed (both Assigned and Not assigned items).
- **Layout:** how the nodes in a chassis are laid out visually.
- **Network:** which network the chassis is attached to.
- **Username, Password:** the user name and password to access the chassis operating system
- **Power control, Custom power script, Custom power script argument:** power-related items for the chassis.
- **Userdefined1, Userdefined2:** administrator-defined variables that can be used by CMDaemon.






Figure 3.22: Bright View Chassis Members Menu Options

**Basic chassis configuration and node assignment with cmsh:** The chassis mode in cmsh allows configuration related to a particular chassis. Tab-completion suggestions for a selected chassis with the set command show possible parameters that may be set:

#### Example

```
[bright80->device[chassis1]]% set
containerindex          ip          powerdistributionunits
custompingscript        layout      rack
custompingscriptargument mac          revision
custompowerscript        members      slots
custompowerscriptargument model        tag
defaultgateway           network     userdefined1
deviceheight             notes       userdefined2
deviceposition           partition  username
ethernet switch          password
hostname                 powercontrol
```

Whether the suggested parameters are actually supported depends on the chassis hardware. For example, if the chassis has no network interface of its own, then the ip and mac address settings may be set, but cannot function.

The “positioning” parameters of the chassis within the rack can be set as follows with cmsh:

#### Example

```
[bright80->device[chassis1]]% set rack rack2
[bright80->device*[chassis1*]]% set deviceposition 1; set deviceheight 6
[bright80->device*[chassis1*]]% commit
```

The members of the chassis can be set as follows with cmsh:

#### Example

```
[bright80->device[chassis1]]% append members bright80 node001..node005
[bright80->device*[chassis1*]]% commit
```

### 3.13 Configuring A GPU Unit, And Configuring GPU Settings

#### 3.13.1 GPUs And GPU Units

GPUs (Graphics Processing Units) are processors that are heavily optimized for executing certain types of parallel processing tasks. GPUs were originally used for rendering graphics, and one GPU typically has hundreds of cores. When used for general processing, they are sometimes called General Processing GPUs, or GPGPUs. For convenience, the “GP” prefix is not used in this manual.

A GPU is typically placed on a PCIe card. GPUs can be physically inside the node that uses them, or they can be physically external to the node that uses them. As far as the operating system on the node making use of the physically external GPUs is concerned, the GPUs are internal to the node.

If the GPUs are physically external to the node, then they are typically in a *GPU unit*. A GPU unit is a chassis that hosts only GPUs. It is typically able to provide GPU access to several nodes, usually via PCIe extender connections. This ability means that external GPUs typically require more configuration than internal GPUs.

#### 3.13.2 GPU Unit Configuration Example: The Dell PowerEdge C410x

An example of a GPU unit is the Dell PowerEdge C410x, which comes in a 3U chassis size, has up to 16 Tesla M-series GPUs (in the form of cards in slots) inside it, and can allocate up to 4 GPUs per node.

It can be configured to work with Bright Cluster Manager as follows:

1. The GPUs in the unit are assigned to nodes using the direct web interface provided by the Baseboard Management Controller (BMC) of the C410x. This configuration is done outside of Bright Cluster Manager. The assignment of the GPUs can be done only according to the fixed groupings permitted by the web interface.

For example, if the unit has 16 GPUs in total (1, 2,..., 16), and there are 4 nodes in the cluster (node001, node002,..., node004), then an appropriate GPU indices mapping to the node may be:

- node001 is assigned 1, 2, 15, 16
- node002 is assigned 3, 4, 13, 14
- node003 is assigned 5, 6, 11, 12
- node004 is assigned 7, 8, 9, 10

This mapping is decided by accessing the C410x BMC with a browser, and making choices within the “Port Map” resource (figure 3.23). 4 mappings are displayed (Mapping 1, 2, 3, 4), with columns displaying the choices possible for each mapping. In the available mapping choices, the iPass value indicates a port, which corresponds to a node. Thus iPass 1 is linked to node001, and its corresponding PCIE values (1, 2, 15, 16) are the GPU indices here. Each iPass port can have 0 (N/A), 2, or 4 PCIE values associated with it, so that the GPU unit can supply up to 4 GPUs to each node.

The GPU indices (PCIE values) (that is, the numbers 1, 2,..., 16) are used to identify the card in Bright Cluster Manager. The lowest GPU index associated with a particular node—for example, 5 (rather than 6) for node03—is used to make Bright Cluster Manager aware in the next step that an association exists for that node, as well as aware which the first GPU card associated with it is.

2. The GPUs can be assigned to the nodes in Bright Cluster Manager as follows:

First, the GPU unit holding the GPUs can be assigned to the GPU unit resource. This can be carried out by adding the hostname of the GPU unit, for example in `cmsh` with:

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]% add gpuunit schwartz
```




Figure 3.23: Assigning GPUs To Nodes With The C410x web interface

This drops the administrator into the `gpuunit` object, which has the hostname `schwartz` here. The equivalent addition in Bright View can be done via `Devices→GPU Units→Add` button. Next, the IP address, network, and BMC user name and password can be set to appropriate values:

### Example

```
[bright80->device*[schwartz*]]% set ip 10.148.0.10
[bright80->device*[schwartz*]]% set network bmcnet
[bright80->device*[schwartz*]]% bmcsettings
[bright80->device*[schwartz*]->bmcsettings]% set username darkhelmet
[bright80->device*[schwartz*]->bmcsettings*]% set userid 1002
[bright80->device*[schwartz*]->bmcsettings*]% set password 12345
[bright80->device*[schwartz*]->bmcsettings*]% commit
```

Here, it is assumed that a BMC network that the BMC network interface is connected to has already been created appropriately. If it is not already set up, then the network can be configured as described in section 3.7.

The value of `owners` must be set to the list of nodes that have access to GPUs.

Also, the reserved variable, `userdefined1` must be set to a key=value pair, so that each key (the node in owner) has a value (the PCIE values), assigned to it:

### Example

```
[bright80->device[schwartz]]% set owners node001 node002 node003 node004
[bright80->device*[schwartz*]]% set userdefined1 node001=1,2,15,16 node002=3,4,13,\
14 node003=5,6,11,12 node004=7,8,9,10
[bright80->device*[schwartz*]]% commit
```

As a convenience, if the indices are all separated by 1, as in the case of node004 here, only the lowest index need be set for that node. The line setting the `userdefined1` value can thus equivalently be carried out with:

### Example

```
[bright80->device[schwartz*]]% set userdefined1 node001=1,2,15,16 node002=3,4,13,\
14 node003=5,6,11,12 node004=7
```

Once these values are committed, Bright Cluster Manager is able to track GPU assignment consistently and automatically.

3. Finally, CUDA drivers should be installed on the relevant nodes so that they can make use of the GPUs. The details on how to do this are given in section 7.5 of the *Installation Manual*.

### 3.13.3 Configuring GPU Settings

The `gpusettings` Submode In `cmsh`

In `cmsh`, GPUs can be configured for a specified node, via `device` mode.

Going into the `gpusettings` submode for that node then allows a range to be specified for a range of GPUs:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use node001
[bright80->device[node001]]% gpusettings
[bright80->device[node001]->gpusettings]% add 1-3 ; commit
```

GPUs can also be configured for a specified category, via `category` mode. For example, using the category default, then entering into the `gpusettings` submode allows a range to be set for the range of GPUs:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% category use default
[bright80->category[default]]% gpusettings
[bright80->category[default]->gpusettings]% list
GPU range (key)  Power limit  ECC mode      Compute mode  Clock speeds
-----
[bright80->category[default]->gpusettings]% add 1-3 ; commit
[bright80->category[default]->gpusettings[1-3]]% show
Parameter                      Value
-----
Clock speeds
Compute mode
ECC mode
...
```

As usual, GPU settings for a node override those for a category (section 2.1.3).

After a name has been set, the following GPU settings may be specified, if supported, from within the `gpusettings` submode:

- `clockspeeds`: The clock speed (frequency in MHz) choices are:
  - `max#max`: maximum for both memory and graphics

- `min#min`: minimum for both memory and graphics
- `<number for memory>#<number for graphics>`: other possible combinations for memory and graphics, as suggested by tab-completion
- `computemode`: Contexts can be computed with the following values for this mode:
  - `Default`: Multiple contexts are allowed
  - `Exclusive thread`: Only one context is allowed per device, usable from one thread at a time
  - `Exclusive process`: Only one context is allowed per device, usable from multiple threads at a time. This mode option is valid for CUDA 4.0 and higher. Earlier CUDA versions ran only in this mode.
  - `Prohibited`: No contexts are allowed per device
- `eccmode`: Sets the ECC bit error check, with:
  - `enabled`
  - `disabled`

When ECC is enabled:

- Single bit errors are detected, using the `EccSBitGPU` metric (page 650), and corrected automatically.
- Double bit errors are also detected, using the `EccDBitGPU` metric (page 650), but cannot be corrected.

The `gpureset` and `gpuclearecc` commands (page 108) are relevant for this setting.

- `gpureset`: After changing the `eccmode` setting, the GPU must be reset to make the new value active.
- `gpuclearecc`: This is used to clear ECC counts for the GPU.
- `name`: range values can be set as follows:
  - `all`: The GPU settings apply to all GPUs on the node.
  - `<number>`: The GPU settings apply to an individual GPU, for example: 1
  - `<number range>`: The GPU settings apply to a range of GPUs, for example: 1, 3–5
- `operationmode`: The operation mode values for the GPU are:
  - `All on`: All of the GPU node is made available for calculations
  - `Compute`: Only the computing section is made available for calculations. Graphics section calculations are not possible.
  - `Low Double precision`: A mode that spares resources and power if little double precision use is expected
- `persistence mode`:
  - `Enabled`: If the mode is enabled, then the NVIDIA driver is kept loaded, even if nothing is actively using it. This reduces loading latency when running CUDA programs.
- `powerlimit`: The administrator-defined upper power limit for the GPU. Only valid if `powermode` is Supported.
  - `min`: The minimum upper power limit that the hardware supports.

- max: The maximum upper power limit that the hardware supports.
  - <number>: An arbitrary upper power limit, specified as a number between min and max
  - default: Upper power limit based on the default hardware value.
- powermode:
    - Supported: Allows power management functions.

If no value is specified for a GPU setting, then the hardware default is used.

Within `cmsh`, the `gpureset` and `gpuclearecc` commands can be executed at a node or category level, and also executed for specified nodes. The `cmsh` help text for these commands (`help gpureset` and `help gpuclearecc`) gives details, including node range specifications.

- The `gpureset` command carries out a power reset. It is executed only if there are no processes using the GPU. Possible processes using the GPU can be CUDA applications, X, monitoring applications, or other calculations. The device is all done with the reset in about 2 seconds.

#### Example

```
[bright80->device]% gpureset -c default 1,3-6
```

This resets GPUs 1, 3, 4, 5, and 6 in the default category.

The command can be used to reset GPUs without rebooting the node, or to reset some hung GPUs.

- The `gpuclearecc` command clears the ECC counts for the GPU. The ECC counts are of two types:
  - volatile: Resets when the driver unloads. Resets on power cycle.
  - aggregate: Persists when the driver unloads. Resets on power cycle.

By default, both types are cleared when the command is run, but each type can be cleared separately.

#### Example

```
[bright80->device]% gpuclearecc -c default 1,3-6 -a
```

This clears the aggregate ECC counts for the GPUs 1, 3, 4, 5, and 6 in the default category.

### The `gpusettings` Submode In Bright View

In Bright View the GPU settings can be accessed within the settings options for a device with a GPU. For example, if a regular node, `node001`, has a GPU, then the clickpath would be: `Devices`→`Physical Nodes`[`node001`]→`Edit`→`Settings`→`GPU Settings`, which opens up the GPU Settings subpane for that node (figure 3.24). Similarly, GPU settings can also be accessed within the Category resource, selecting a category item, and then selecting the GPU Settings subpane.

## 3.14 Configuring Custom Scripts

Some scripts are used for custom purposes. These are used as replacements for certain default scripts, for example, in the case of non-standard hardware where the default script does not do what is expected. The custom scripts that can be set, along with their associated arguments are:

- `custompowerscript` and `custompowerscriptargument`
- `custompingscript` and `custompingscriptargument`
- `customremoteconsolescript` and `customremoteconsolescriptargument`

The environment variables of `CMDaemon` (section 3.3.1 of the *Developer Manual*) can be used in the scripts. Successful scripts, as is the norm, return 0 on exit.




Figure 3.24: GPU Settings Subpane For A Node

### 3.14.1 `custompowerscript`

The use of custom power scripts is described in section 4.1.4.

### 3.14.2 `custompingscript`

The following example script:

#### Example

```
#!/bin/bash
/bin/ping -c1 $CMD_IP
```

can be defined and set for the cases where the default built-in ping script, cannot be used.

By default, the node device states are detected by the built-in ping script (section 5.5) using a type of PING called TCP SYN ping. This results in the statuses that can be seen on running the list command of `cmsh` in device mode. An example output, formatted for convenience, is:

#### Example

```
[root@bright80]# cmsh -c "device; format hostname:15, status:15; list"
hostname (key)  status
-----
bright80       [  UP   ]
node001        [  UP   ]
node002        [  UP   ]
```

If some device is added to the cluster that blocks such pings, then the built-in ping can be replaced by the custom ping of the example, which relies on standard ICMP ping.

However, the replacement custom ping script need not actually use a variety of ping at all. It could be a script running web commands to query a chassis controller, asking if all its devices are up. The script simply has to provide an exit status compatible with expected ping behavior. Thus an exit status of 0 means all the devices are indeed up.

### 3.14.3 `customremoteconsolescript`

A custom remote console script can be used to replace the built-in remote console utility. This might be used, for example, to allow the administrator remote console access through a proprietary KVM switch client to its KVM switch.

## 3.15 Cluster Configuration Without Execution By CMDaemon

### 3.15.1 Cluster Configuration: The Bigger Picture

The configurations carried out in this chapter so far are based almost entirely on configuring nodes, via a CMDaemon front end (`cmsh` or Bright View), using CMDaemon to execute the change. Indeed, much of this manual is about this too because it is the preferred technique. It is preferred:

- because it is intended by design to be the easiest way to do common cluster tasks,
- and also generally keeps administration overhead minimal in the long run since it is CMDaemon rather than the system administrator that then takes care of tracking the cluster state.

There are however other cluster configuration techniques besides execution by CMDaemon. To get some perspective on these, it should be noted that cluster configuration techniques are always fundamentally about modifying a cluster so that it functions in a different way. The techniques can then for convenience be separated out into modification techniques that rely on CMDaemon execution and techniques that do not, as follows:

1. **Configuring nodes with execution by CMDaemon:** As explained, this is the preferred technique. The remaining techniques listed here should therefore usually only be considered if the task cannot be done with Bright View or `cmsh`.
2. **Replacing the node image:** The image on a node can be replaced by an entirely different one, so that the node can function in another way. This is covered in section 3.15.2. It can be claimed that since it is CMDaemon that selects the image, this technique should perhaps be classed as under item 1. However, since the execution of the change is really carried out by the changed image without CMDaemon running on the image, and because changing the entire image to implement a change of functionality is rather extreme, this technique can be given a special mention outside of CMDaemon execution.
3. **Using a `FrozenFile` directive:** Applied to a configuration file, this directive prevents CMDaemon from executing changes on that file for nodes. During updates, the frozen configuration may therefore need to be changed manually. The prevention of CMDaemon acting on that file prevents the standard cluster functionality that would run based on a fully CMDaemon-controlled cluster configuration. The `FrozenFile` directive is introduced in section 2.6.4, and covered in the configuration context in section 3.15.3.
4. **Using an `initialize` or `finalize` script:** This type of script is run during the `initrd` stage, much before CMDaemon on the regular node starts up. It is run if the functionality provided by the script is needed before CMDaemon starts up, or if the functionality that is needed cannot be made available later on when CMDaemon is started on the regular nodes. CMDaemon does not execute the functionality of the script itself, but the script is accessed and set on the `initrd` via a CMDaemon front end (Appendix E.2), and executed during the `initrd` stage. It is often convenient to carry out minor changes to configuration files inside a specific image in this way, as shown by the example in Appendix E.5. The `initialize` and `finalize` scripts are introduced in section 3.15.4.
5. **A shared directory:** Nodes can be configured to access and execute a particular software stored on a shared directory of the cluster. CMDaemon does not execute the functionality of the software itself, but is able to mount and share directories, as covered in section 3.10.



Finally, outside the stricter scope of cluster configuration adjustment, but nonetheless a broader way to modify how a cluster functions, and therefore mentioned here for more completeness, is:

6. **Software management:** the installation, maintenance, and removal of software packages. Standard post-installation software management based on repositories is covered in sections 11.2–11.6. Third-party software management from outside the repositories, for software that is part of Bright Cluster Manager is covered in Chapter 7 of the *Installation Manual*.

Third-party software that is not part of Bright Cluster Manager can be managed on the head node usually like to any other Linux system, under `/opt` or other recommended locations. If required by the other nodes, then the software should typically be set up by the administrator so that it can be accessed via a shared filesystem.

### 3.15.2 Making Nodes Function Differently By Image

#### Making All Nodes Function Differently By Image

To change the name of the image used for an entire cluster, for example after cloning the image and modifying it (section 3.15.2), the following methods can be used:

- in Bright View, via `Cluster→Settings→Cluster name`
- or in `cmsh` from within the `base` object of `partition mode`

A system administrator more commonly sets the software image on a per-category or per-node basis (section 3.15.2).

#### Making Some Nodes Function Differently By Image

For minor changes, adjustments can often be made to node settings via `initialize` and `finalize` scripts so that nodes or node categories function differently (section 3.15.4).

For major changes on a category of nodes, it is usually more appropriate to have nodes function differently from each other by simply carrying out image changes per node category with CMDaemon. Carrying out image changes per node is also possible. As usual, node settings override category settings.

Setting a changed image for a category can be done as follows with `cmsh`:

1. The image on which the new one will be based is cloned. The cloning operation not only copies all the settings of the original (apart from the name), but also the data of the image:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% softwareimage
[bright80->softwareimage]% clone default-image imagetwo
[bright80->softwareimage*[imagetwo*]]% commit
Thu Aug 11 15:44:44 2011 [notice] bright80: Started to copy: /cm/\
images/default-image -> /cm/images/imagetwo
[bright80->softwareimage*[imagetwo*]]%
Thu Aug 11 15:53:22 2011 [notice] bright80: Copied: /cm/images/de\
fault-image -> /cm/images/imagetwo
[bright80->softwareimage[imagetwo]]%
```

2. After cloning, the settings can be modified in the new object. For example, if the kernel needs to be changed to suit nodes with different hardware, kernel modules settings are changed (section 5.3.2) and committed. This creates a new image with a new ramdisk.

Other ways of modifying and committing the image for the nodes are also possible, as discussed in sections 11.2–11.6 of this chapter.

3. The modified image that is to be used by the differently functioning nodes is placed in a new category in order to have the nodes be able to choose the image. To create a new category easily, it can simply be cloned. The image that the category uses is then set:

```
[bright80->softwareimage[imagetwo]]% category
[bright80->category]% clone default categorytwo
[bright80->category*[categorytwo*]]% set softwareimage imagetwo
[bright80->category*[categorytwo*]]% commit
[bright80->category[categorytwo]]%
```

4.
  - For just one node, or a few nodes, the node can be set from device mode to the new category (which has the new image):

```
[bright80->category[categorytwo]]% device
[bright80->device]% use node099
[bright80->device[node099]]% set category categorytwo
[bright80->device*[node099*]]% commit; exit
```

- If there are many nodes, for example node100 sequentially up to node200, they can be set to that category using a `foreach` loop like this:

#### Example

```
[bright80->device]% foreach -n node100..node200 (set category categorytwo)
[bright80->device*]% commit
```

5. Rebooting restarts the nodes that are assigned to the new category with the new image.

### 3.15.3 Making All Nodes Function Differently From Normal Cluster Behavior With

#### FrozenFile

Configuration changes carried out by Bright View or `cmsh` often generate, restore, or modify configuration files (Appendix A).

However, sometimes an administrator may need to make a direct change (without using Bright View or `cmsh`) to a configuration file to set up a special configuration that cannot otherwise be done.

The `FrozenFile` directive to `CMDaemon` (Appendix C) applied to such a configuration file stops `CMDaemon` from altering the file. The frozen configuration file is generally applicable to all nodes and is therefore a possible way of making all nodes function differently from their standard behavior.

Freezing files is however best avoided, if possible, in favor of a `CMDaemon`-based method of configuring nodes, for the sake of administrative maintainability.

### 3.15.4 Adding Functionality To Nodes Via An `initialize` Or `finalize` Script

`CMDaemon` can normally be used to allocate different images per node or node category as explained in section 3.15.2. However, some configuration files do not survive a reboot (Appendix A), sometimes hardware issues can prevent a consistent end configuration, and sometimes drivers need to be initialized before provisioning of an image can happen. In such cases, an `initialize` or `finalize` script (sections 5.4.5, 5.4.11, and Appendix E.5) can be used to initialize or configure nodes or node categories.

These scripts are also useful because they can be used to implement minor changes across nodes:

#### Example

Supposing that some nodes with a particular network interface have a problem auto-negotiating their network speed, and default to 100Mbps instead of the maximum speed of 1000Mbps. Such nodes can be set to ignore auto-negotiation and be forced to use the 1000Mbps speed by using the `ETHTOOL_OPTS` configuration parameter in their network interface configuration file: `/etc/sysconfig/network-scripts/ifcfg-eth0` (or `/etc/sysconfig/network/ifcfg-eth0` in SUSE).

The `ETHTOOL_OPTS` parameter takes the options to the “`ethtool -s <device>`” command as options. The value of `<device>` (for example `eth0`) is specified by the filename that is used by the configuration file itself (for example `/etc/sysconfig/network-scripts/ifcfg-eth0`). The `ethtool` package is installed by default with Bright Cluster Manager. Running the command:

```
ethtool -s autoneg off speed 1000 duplex full
```

turns out after some testing to be enough to reliably get the network card up and running at 1000Mbps on the problem hardware.

However, since the network configuration file is overwritten by node-installer settings during reboot, a way to bring persistence to the file setting is needed. One way to ensure persistence is to append the configuration setting to the file with a `finalize` script, so that it gets tagged onto the end of the configuration setting that the node-installer places for the file, just before the network interfaces are taken down again in preparation for `init`.

The script may thus look something like this for a Red Hat system:

```
#!/bin/bash

## node010..node014 get forced to 1000 duplex
if [[ $CMD_HOSTNAME = node01[0-4] ]]
then
echo 'ETHTOOL_OPTS="speed 1000 duplex full"'>>/localdisk/etc/sysconfig/network-scripts/ifcfg-eth0
fi
```

### 3.15.5 Examples Of Configuring Nodes With Or Without CMDaemon

A node or node category can often have its software configured in CMDaemon via Bright View or `cmsh`:

#### Example

**Configuring a software for nodes using Bright View or `cmsh`:** If the software under consideration is CUPS, then a node or node category can manage it from Bright View or `cmsh` as outlined in section 3.11.2.

A counterexample to this is:

#### Example

**Configuring a software for nodes without using Bright View or `cmsh`<sup>3</sup>, using an image:** Software images can be created with and without CUPS configured. Setting up nodes to load one of these two images via a node category is an alternative way of letting nodes run CUPS.

Whether node configuration for a particular functionality is done with CMDaemon, or directly with the software, depends on what an administrator prefers. In the preceding two examples, the first example, that is the one with Bright View or `cmsh` setting the CUPS service, is likely to be preferred over the second example, where an entire separate image must be maintained. A new category must also be created in the second case.

Generally, sometimes configuring the node via Bright Cluster Manager, and not having to manage images is better, sometimes configuring the software and making various images to be managed out of it is better, and sometimes only one of these techniques is possible anyway.

<sup>3</sup>except to link nodes to their appropriate image via the associated category

**Configuring Nodes Using Bright View Or `cmsh`: Category Settings**

When configuring nodes using Bright View or `cmsh`, configuring particular nodes from a node category to overrule the state of the rest of its category (as explained in section 2.1.3) is sensible for a small number of nodes. For larger numbers it may not be organizationally practical to do this, and another category can instead be created to handle nodes with the changes conveniently.

The CUPS service in the next two examples is carried out by implementing the changes via Bright View or `cmsh` acting on `CMDaemon`.

**Example**

**Setting a few nodes in a category:** If only a few nodes in a category are to run CUPS, then it can be done by enabling CUPS just for those few nodes, thereby overriding (section 2.1.3) the category settings.

**Example**

**Setting many nodes to a category:** If there are many nodes that are to be set to run CUPS, then a separate, new category can be created (cloning it from the existing one is easiest) and those many nodes are moved into that category, while the image is kept unchanged. The CUPS service setting is then set at category level to the appropriate value for the new category.

In contrast to these two examples, the software image method used in section 3.15.2 to implement a functionality such as CUPS would load up CUPS as configured in an image, and would not handle it via `CMDaemon`<sup>3</sup>. So, in section 3.15.2, software images prepared by the administrator are set for a node category. Since, by design, images are only selected for a category, a node cannot override the image used by the category other than by creating a new category, and using it with the new image. The administrative overhead of this can be inconvenient.

Administrators would therefore normally prefer letting `CMDaemon` track software functionality across nodes as in the last two examples, rather than having to deal with tracking software images manually. Indeed, the `roles` assignment option (section 2.1.5) is just a special pre-configured functionality toggle that allows `CMDaemon` to set categories or regular nodes to provide certain functions, typically by enabling services.

# 4

## Power Management

Aspects of power management in Bright Cluster Manager include:

- managing the main power supply to nodes through the use of power distribution units, baseboard management controllers, or CMDaemon
- monitoring power consumption over time
- setting CPU scaling governors for power-saving
- setting power-saving options in workload managers
- ensuring the passive head node can safely take over from the active head during failover (Chapter 15)
- allowing cluster burn tests to be carried out (Chapter 8 of the *Installation Manual*)

The ability to control power inside a cluster is therefore important for cluster administration, and also creates opportunities for power savings. This chapter describes the Bright Cluster Manager power management features.

In section 4.1 the configuration of the methods used for power operations is described.

Section 4.2 then describes the way the power operations commands themselves are used to allow the administrator turn power on or off, reset the power, and retrieve the power status. It explains how these operations can be applied to devices in various ways.

Section 4.3 briefly covers monitoring power.

Section 4.4 describes how CMDaemon can set CPU defaults to control some of the CPU-dependent power consumption.

The integration of power saving with workload management systems is covered in the chapter on Workload Management (section 7.9).

### 4.1 Configuring Power Parameters

Several methods exist to control power to devices:

- Power Distribution Unit (PDU) based power control
- IPMI-based power control (for node devices only)
- Custom power control
- HP iLO-based power control (for node devices only)
- Cisco UCS-based power control (for node devices only)
- Dell DRAC-based power control (for node devices only)

#### 4.1.1 PDU-Based Power Control

For PDU-based power control, the power supply of a device is plugged into a port on a PDU. The device can be a node, but also anything else with a power supply, such as a switch. The device can then be turned on or off by changing the state of the PDU port.

To use PDU-based power control, the PDU itself must be a device in the cluster and be reachable over the network.

The `PowerDistributionUnits` menu option, accessible via the clickpath `Devices[device]→Settings` pane for each device plugged into the PDU, can then be used to configure the PDU ports that control the device. Figure 4.1 shows the menu option in the Settings window for a head node device, `bright80`, as accessed via the clickpath `Devices→Head Nodes[bright80]→Settings`.




Figure 4.1: Power Section In The Head Node Settings

If the menu option is clicked, then a subpane opens that allows each device plugged into the PDU to have PDU ports added and removed. For the APC brand of PDUs, the `Power control` property in the window of figure 4.1 should be set to `apc`, or the list of PDU ports is ignored by default. Overriding the default is described in section 4.1.3.

Since nodes may have multiple power feeds, there may be multiple PDU ports defined for a single device. The cluster management infrastructure takes care of operating all ports of a device in the correct order when a power operation is done on the device.

It is also possible for multiple devices to share the same PDU port. This is the case for example when *twin nodes* are used (i.e. two nodes sharing a single power supply). In this case, all power operations on one device apply to all nodes sharing the same PDU port.

If the PDUs defined for a node are not manageable, then the node's baseboard management controllers (that is, IPMI/iLO and similar) are assumed to be inoperative and are therefore assigned an unknown state. This means that dumb PDUs, which cannot be managed remotely, are best not assigned to nodes in Bright Cluster Manager. Administrators wishing to use Bright Cluster Manager to record that a dumb PDU is assigned to a node can deal with it as follows:

- in Bright View the `Notes` field or the `Userdefined1/Userdefined2` fields can be used.

- in `cmsh` the equivalent is accessible when using the node from device mode, and running “set notes”, “set userdefined1”, or “set userdefined2”.

For PDUs that are manageable:

- In `cmsh`, power-related options can be accessed from device mode, after selecting a device:

#### Example

```
[bright80]% device use node001
[bright80->device[node001]]% show | grep -i power
Custom power script argument
Ipmi/iLO power reset delay          0
Power control                       apc
PowerDistributionUnits              apc01:6 apc01:7
```

The power status of a node can be accessed with:

#### Example

```
[bright80->device[node001]]% power status
```

If the node is up and has one or more PDUs assigned to it, then the power status is one of ON, OFF, RESET, FAILED, or UNKNOWN:

Power Status	Description
ON	Power is on
OFF	Power is off
RESET	Shows during the short time the power is off during a power reset. The reset is a hard power off for PDUs, but can be a soft or hard reset for other power control devices.
FAILED	Power status script communication failure.
UNKNOWN	Power status script timeout

### 4.1.2 IPMI-Based Power Control

IPMI-based power control relies on the baseboard management controller (BMC) inside a node. It is therefore only available for node devices. Blades inside a blade chassis typically use IPMI for power management. Section 3.7 describes setting up networking and authentication for IPMI/iLO/UCS interfaces.

To carry out IPMI-based power control operations, the `Power control` property in figure 4.1 must be set to the IPMI interface through which power operations should be relayed. Normally this IPMI interface is configured to be `ipmi0`. Any list of configured APC PDU ports displayed in the GUI is ignored by default when the `Power control` property is not `apc`.

#### Example

Configuring power parameters settings for all the nodes using `cmsh`, with IPMI interfaces that are called `ipmi0`:

```
[mycluster]% device
[...device]% foreach allphysicalnodes (set powercontrol ipmi0; commit)
```

### Example

Configuring power parameters settings for a node using `cmsh` with APC:

```
[mycluster]% device use node001
[...device[node001]]% set powerdistributionunits apc01:6 apc01:7 apc01:8
[...device*[node001*]]% get powerdistributionunits
apc01:6 apc01:7 apc01:8
[...device*[node001*]]% removefrom powerdistributionunits apc01:7
[...device*[node001*]]% get powerdistributionunits
apc01:6 apc01:8
[...device*[node001*]]% set powercontrol apc
[...device*[node001*]]% get powercontrol
apc
[...device*[node001*]]% commit
```

#### 4.1.3 Combining PDU- and IPMI-Based Power Control

By default when nodes are configured for IPMI Based Power Control, any configured PDU ports are ignored. However, it is sometimes useful to change this behavior.

For example, in the `CMDaemon` configuration file directives in `/cm/local/apps/cmd/etc/cmd.conf` (introduced in section 2.6.2 and listed in Appendix C), the default value of `PowerOffPDUOutlet` is `false`. It can be set to `true` on the head node, and `CMDaemon` restarted to activate it.

With `PowerOffPDUOutlet` set to `true` it means that `CMDaemon`, after receiving an IPMI-based power off instruction for a node, and after powering off that node, also subsequently powers off the PDU port. Powering off the PDU port shuts down the BMC, which saves some additional power—typically a few watts per node. When multiple nodes share the same PDU port, the PDU port only powers off when all nodes served by that particular PDU port are powered off.

When a node has to be started up again the power is restored to the node. It is important that the node BIOS is configured to automatically power on the node when power is restored.

#### 4.1.4 Custom Power Control

For a device which cannot be controlled through any of the standard existing power control options, it is possible to set a custom power management script. This is then invoked by the cluster management daemon on the head node whenever a power operation for the device is done.

Power operations are described further in section 4.2.

##### Using `custompowerscript`

To set a custom power management script for a device, the `powercontrol` attribute is set by the administrator to `custom` using either Bright View or `cmsh`, and the value of `custompowerscript` is specified by the administrator. The value for `custompowerscript` is the full path to an executable custom power management script on the head node(s) of a cluster.

A custom power script is invoked with the following mandatory arguments:

```
myscript <operation> <device>
```

where `<device>` is the name of the device on which the power operation is done, and `<operation>` is one of the following:

```
ON
OFF
```



RESET  
STATUS

On success a custom power script exits with exit code 0. On failure, the script exits with a non-zero exit-code.

#### Using `custompowerscriptargument`

The mandatory argument values for `<operation>` and `<device>` are passed to a custom script for processing. For example, in `bash` the positional variables `$1` and `$2` are typically used for a custom power script. A custom power script can also be passed a further argument value by setting the value of `custompowerscriptargument` for the node via `cmsh` or Bright View. This further argument value would then be passed to the positional variable `$3` in `bash`.

An example custom power script is located at `/cm/local/examples/cmd/custompower`. In it, setting `$3` to a positive integer delays the script via a `sleep` command by `$3` seconds.

An example that is conceivably more useful than a `sleep $3` command is to have a `wakeonlan $3` command instead. If the `custompowerscriptargument` value is set to the MAC address of the node, that means the MAC value is passed on to `$3`. Using this technique, the power operation ON can then carry out a Wake On LAN operation on the node from the head node.

Setting the `custompowerscriptargument` can be done like this for all nodes:

```
#!/bin/bash
for nodename in $(cmsh -c "device; foreach * (get hostname)")
do
    macad=`cmsh -c "device use $nodename; get mac"`
    cmsh -c "device use $nodename; set customscriptargument $macad; commit"
done
```

The preceding material usefully illustrates how `custompowerscriptargument` can be used to pass on arbitrary parameters for execution to a custom script.

However, the goal of the task can be achieved in a simpler and quicker way using the environment variables available in the cluster management daemon environment (section 3.3.1 of the *Developer Manual*). This is explained next.

#### Using Environment Variables With `custompowerscript`

Simplification of the steps needed for custom scripts in CMDaemon is often possible because there are values in the CMDaemon environment already available to the script. A line such as:

```
env > /tmp/env
```

added to the start of a custom script dumps the names and values of the environment variables to `/tmp/env` for viewing.

One of the names is `$CMD_MAC`, and it holds the MAC address string of the node being considered.

So, it is not necessary to retrieve a MAC value for `custompowerscriptargument` with a `bash` script as shown in the previous section, and then pass the argument via `$3` such as done in the command `wakeonlan $3`. Instead, `custompowerscript` can simply call `wakeonlan $CMD_MAC` directly in the script when run as a power operation command from within CMDaemon.

### 4.1.5 Hewlett Packard iLO-Based Power Control

#### iLO Configuration During Installation

If “Hewlett Packard” is chosen as the node manufacturer during installation (section 3.3.5 of the *Installation Manual*), and the nodes have an iLO management interface, then Hewlett-Packard’s iLO management package, `hponcfg`, is installed by default on the nodes and head nodes.

### iLO Configuration After Installation

If “Hewlett Packard” has not been specified as the node manufacturer during installation then it can be configured after installation as follows:

The `hponcfg` rpm package is normally obtained and upgraded for specific HP hardware from the HP website. Using an example of `hponcfg-3.1.1-0.noarch.rpm` as the package downloaded from the HP website, and to be installed, the installation can then be done on the head node, the software image, and in the node-installer as follows:

```
rpm -iv hponcfg-3.1.1-0.noarch.rpm
rpm --root /cm/images/default-image -iv hponcfg-3.1.1-0.noarch.rpm
rpm --root /cm/node-installer -iv hponcfg-3.1.1-0.noarch.rpm
```

To use iLO on a node, the iLO interface of the node is set up just like the IPMI interfaces as outlined in section 4.1.2. That is, using “`set powercontrol ilo0`” instead of “`set powercontrol ipmi0`”. The cluster manager treats HP iLO interfaces just like regular IPMI interfaces, except that the interface names are `ilo0`, `ilo1`... instead of `ipmi0`, `ipmi1`...

For example, nodes in the default category can be brought under iLO power control as follows:

#### Example

```
[mycluster]% device foreach -c default (set powercontrol ilo0)
[mycluster]% device commit
```

### 4.1.6 Dell racadm-based Power Control

Dell `racadm` configuration is covered on page ??.

## 4.2 Power Operations

Power operations may be carried out on devices from either Bright View or `cmsh`. There are four main power operations:

- Power On: power on a device
- Power Off: power off a device
- Power Reset: power off a device and power it on again after a brief delay
- Power Status: check power status of a device

### 4.2.1 Power Operations With Bright View

In Bright View, buttons for executing On/Off/Reset operations are to be found via the **Actions** button. The **Actions** button is available when specific device has been selected. For example, for a head node `bright80` the button can be seen via the clickpath `Devices→Head Nodes[bright80]→Settings`, as illustrated in figure 4.1. Clicking on the button makes power operation buttons available figure 4.2.




Figure 4.2: Actions Button, Accessing The Power Operations

### 4.2.2 Power Operations Through `cmsh`

All power operations in `cmsh` are done using the `power` command in `device` mode. Some examples of usage are now given:

- Powering on node001, and nodes from node018 to node033 (output truncated):

#### Example

```
[mycluster]% device power -n node001,node018..node033 on
apc01:1 ..... [  ON   ] node001
apc02:8 ..... [  ON   ] node018
apc02:9 ..... [  ON   ] node019
...
```

- Powering off all nodes in the `default` category with a 100ms delay between nodes (some output elided):

#### Example

```
[mycluster]% device power -c default -d 0.1 off
apc01:1 ..... [ OFF   ] node001
apc01:2 ..... [ OFF   ] node002
...
apc23:8 ..... [ OFF   ] node953
```

- Retrieving power status information for a group of nodes:

#### Example

```
[mycluster]% device power -g mygroup status
apc01:3 ..... [  ON   ] node003
apc01:4 ..... [ OFF   ] node004
```

The help text for the `power` command is:

Name:

`power` - Manipulate or retrieve power state of devices

Usage:

```
power [OPTIONS] status
power [OPTIONS] on
power [OPTIONS] off
power [OPTIONS] reset
power [OPTIONS] cancel
```

Options:

```
-n, --nodes <node>
    List of nodes, e.g. node001..node015,node20..node028,node030 or
    ^/some/file/containing/hostnames

-g, --group <group>
    Include all nodes that belong to the node group, e.g. testnodes
    or test01,test03
```

```

-c, --category <category>
    Include all nodes that belong to the category, e.g. default or
    default,gpu

-r, --rack <rack>
    Include all nodes that are located in the given rack, e.g rack01
    or rack01..rack04

-h, --chassis <chassis>
    Include all nodes that are located in the given chassis, e.g
    chassis01 or chassis03..chassis05

-e, --overlay <overlay>
    Include all nodes that are part of the given overlay, e.g
    overlay1 or overlayA,overlayC

-l, --role <role>
    Filter all nodes that have the given role

-p, --powerdistributionunitport <pdu:port>(list)
    perform power operation directly on power distribution units. Use
    port '*' for all ports

-b, --background
    Run in background, output will come as events

-d, --delay <seconds>
    Wait <seconds> between executing two sequential power commands.
    This option is ignored for the status command

-s, --status <states>
    Only run power command on nodes in specified states, e.g. UP,
    "CLOSED|DOWN", "INST.*"

-f, --force
    Force power command on devices which have been closed

```

#### Examples:

```

power status          Display power status for all devices or current device
power on -n node001   Power on node001

```

## 4.3 Monitoring Power

Monitoring power consumption is important since electrical power is an important component of the total cost of ownership for a cluster. The monitoring system of Bright Cluster Manager collects power-related data from PDUs in the following metrics:

- PDUBankLoad: Phase load (in amperes) for one (specified) bank in a PDU
- PDULoad: Total phase load (in amperes) for one PDU

Chapter 12 on cluster monitoring has more on metrics and how they can be visualized.

## 4.4 CPU Scaling Governors

A cluster with CPU cores that run at a higher frequency consumes more power. A cluster administrator may therefore wish to implement schemes to control the CPU core frequencies, so that cluster power consumption is controlled.

### 4.4.1 The Linux Kernel And CPU Scaling Governors

In technology, a governor is the term used for a speed regulator. In computing, *CPU Scaling Governors* are power schemes that regulate what is commonly known as the CPU speed, or more precisely known as the CPU core clock frequency. The Linux kernel uses the *CPUFreq Governors* interface to implement these power schemes. The following governor values are currently commonly available to the interface:

Governor	Policy Description For CPU Frequency
performance	set to the highest allowed
userspace	set to that determined by root
ondemand	set according to demand, aggressively
conservative	set according to demand, non-aggressively
powersave	set to the lowest allowed

### 4.4.2 The Governor List According To `sysinfo`

Not all governors may be available for a particular CPU. Also, new governors may appear as new hardware is released. However, the hardware-defined list of governors that the kernel does detect as being available to a node `<hostname>` can always be seen in Bright Cluster Manager:

- in Bright View from within the CPU information, within the System Information pane of the host. For example, the clickpath for the head node host `bright80` is `Devices→Head Nodes[bright80]→System Information`, and the information is displayed in the `PROCESSORS` subpane under the `AVAILABLEGOVERNORS` column.
- in `cmsh`, by using the `sysinfo <hostname>` command, in device mode

The list can be displayed under `cmsh` in a form such as:

#### Example

```
[bright80->device[bright80]]% sysinfo
System Information
-----
...
Number of Cores      12
Core 0              Six-Core AMD ... performance (ondemand, userspace)
Core 1              Six-Core AMD ... performance (ondemand, userspace)
...
```

The governor in active operation for the cores is displayed outside the parentheses—in the example it is `performance`. The other two available, but inactive ones, are enclosed by parentheses—in the example they are `ondemand` and `userspace`. This list is essentially a hardware-defined list because its members depend only on the chip used. Which one of the members is active is however decided by a software setting for the governor value.

### 4.4.3 Setting The Governor

CPU scaling—Cool ‘n’ Quiet (AMD) or SpeedStep (Intel)—must be enabled in the BIOS for the governor to operate. Values for the governor may then be set in the BIOS. If a governor value is set in the BIOS, then the operating system cannot override it. If no value is set in the BIOS, then the value is set by the operating system.

On a running system, the cluster administrator can set the CPU governor value by using the CM-Daemon front ends as follows:

- In Bright View:
  - if the `Node Categories` resource is chosen, and a particular category is selected, then a `Settings` windows option for that category allows setting the `Scaling governor` to:
    - \* a single value.
    - \* multiple values. These can be set as a comma-separated list. This should not be confused with the hardware-defined list (section 4.4.2).
  - if the `Nodes` or `Head Nodes` resources are chosen, and a node selected from there, then its `Settings` window option allows its `Scaling governor` value to be set only to a single value.
- In `cmsh`:
  - if `category mode`, is used, and the category is chosen, then the `scalinggovernor` can be set to:
    - \* a single value.
    - \* multiple values. These can be set as a comma-separated list
  - if `device mode` is chosen, and a head or regular node selected from there, then its `scalinggovernor` value can be set only to a single value

If a list is set for scaling governors in Bright Cluster Manager, at category level, then the first value in the list is applicable to all the nodes in that category. If that fails for any of the nodes, for example if a node does not support this value, then the next value is attempted, and so on, until the node is assigned a governor value. This allows configuration according to preferred order to take place at category level.

As usual, configuration of a value at node level overrides the category value. However, in contrast with the setting that is possible at the category level, only a single value is possible at node level. This is because, if a specific node comes to the attention of the administrator for a custom governor value, then that node can be assigned the value decided by the administrator.

### Example

```
[bright80->]% device use node001
[bright80->device[node001]]% sysinfo
System Information
-----
...
Number of Cores      12
Core 0               Six-Core AMD ... performance (ondemand, userspace)
Core 1               Six-Core AMD ... performance (ondemand, userspace)
...
Core 11              Six-Core AMD ... performance (ondemand, userspace)

[bright80->device[node001]]% category use default
[bright80->category[default]]% set scalinggovernor ondemand,userspace,performance
[bright80->category[default]]% device use node001
```

```
[bright80->device[node001]]% sysinfo
System Information
-----
...
Number of Cores      12
Core 0               Six-Core AMD ... ondemand (userspace, performance)
Core 1               Six-Core AMD ... ondemand (userspace, performance)
...
Core 11              Six-Core AMD ... ondemand (userspace, performance)
```





# 5

## Node Provisioning

This chapter covers *node provisioning*. Node provisioning is the process of how nodes obtain an image. Typically, this happens during their stages of progress from power-up to becoming active in a cluster, but node provisioning can also take place when updating a running node.

Section 5.1 describes the stages leading up to the loading of the kernel onto the node.

Section 5.2 covers configuration and behavior of the provisioning nodes that supply the software images.

Section 5.3 describes the configuration and loading of the kernel, the ramdisk, and kernel modules.

Section 5.4 elaborates on how the node-installer identifies and places the software image on the node in a 13-step process.

Section 5.5 explains node states during normal boot, as well node states that indicate boot problems.

Section 5.6 describes how running nodes can be updated, and modifications that can be done to the update process.

Section 5.7 explains how to add new nodes to a cluster so that node provisioning will work for these new nodes too. The Bright View and `cmsh` front ends for creating new node objects and properties in CMDaemon are described.

Section 5.8 describes troubleshooting the node provisioning process.

### 5.1 Before The Kernel Loads

Immediately after powering up a node, and before it is able to load up the Linux kernel, a node starts its boot process in several possible ways:

#### 5.1.1 PXE Booting

By default, nodes boot from the network when using Bright Cluster Manager. This is called a *network boot*, or sometimes a *PXE boot*. It is recommended as a BIOS setting for nodes. The head node runs a `tftpd` server from within `xinetd`, which supplies the boot loader from within the default software image (section 2.1.2) offered to nodes.

The boot loader runs on the node and displays a menu (figure 5.1) based on loading a menu module within a configuration file. The default configuration files offered to nodes are located under `/tftpboot/pxelinux.cfg/` on the head node.

The default configuration files give instructions to the menu module of `PXElinux`. The instruction set used is documented at <http://www.syslinux.org/wiki/index.php/Comboot/menu.c32>, and includes the `TIMEOUT`, `LABEL`, `MENU LABEL`, `DEFAULT`, and `MENU DEFAULT` instructions.

#### The PXE `TIMEOUT` Instruction

During the display of the PXE boot menu, a selection can be made within a timeout period to boot the node in a several ways. Among the options are some of the install mode options (section 5.4.4). If no




Figure 5.1: PXE boot menu options

selection is made by the user within the timeout period, then the `AUTO` install mode option is chosen by default.

In the PXE menu configuration files under `pxelinux.cfg/`, the default timeout of 5 seconds can be adjusted by changing the value of the `"TIMEOUT 50"` line. This value is specified in deciseconds.

### Example

```
TIMEOUT 300    # changed timeout from 50 (=5 seconds)
```

### The PXE LABEL And MENU LABEL Instructions

**LABEL:** The menu configuration files under `pxelinux.cfg/` contain several multiline `LABEL` statements.

Each `LABEL` statement is associated with a kernel image that can be loaded from the PXE boot menu along with appropriate kernel options.

Each `LABEL` statement also has a text immediately following the `LABEL` tag. Typically the text is a description, such as `linux`, `main`, `RESCUE`, and so on. If the PXE menu module is not used, then tab completion prompting displays the list of possible text values at the PXE boot prompt so that the associated kernel image and options can be chosen by user intervention.

**MENU LABEL:** By default, the PXE menu module is used, and by default, each `LABEL` statement also contains a `MENU LABEL` instruction. Each `MENU LABEL` instruction also has a text immediately following the `MENU LABEL` tag. Typically the text is a description, such as `AUTO`, `RESCUE` and so on (figure 5.1). Using the PXE menu module means that the list of the `MENU LABEL` text values is displayed when the

PXE boot menu is displayed, so that the associated kernel image and options can conveniently be selected by user intervention.

### The PXE `DEFAULT` And `MENU DEFAULT` Instructions

**DEFAULT:** If the PXE menu module is not used and if no `MENU` instructions are used, and if there is no user intervention, then setting the same text that follows a `LABEL` tag immediately after the `DEFAULT` instruction, results in the associated kernel image and its options being run by default after the timeout.

By default, as already explained, the PXE menu module is used. In particular it uses the setting: `DEFAULT menu.c32` to enable the menu.

**MENU DEFAULT:** If the PXE menu module is used and if `MENU` instructions are used, and if there is no user intervention, then setting a `MENU DEFAULT` tag as a line within the multiline `LABEL` statement results in the kernel image and options associated with that `LABEL` statement being loaded by default after the timeout.

### The `CMDaemon` `PXE Label` Setting For Specific Nodes

The `MENU DEFAULT` value by default applies to every node using the software image that the PXE menu configuration file under `pxelinux.cfg/` is loaded from. To override its application on a per-node basis, the value of `PXE Label` can be set for each node.

- Some simple examples of overriding the default `MENU DEFAULT` value are as follows:

For example, using `cmsh`:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use node001
[bright80->device[node001]]% set pxelabel MEMTEST ; commit
```

Carrying it out for all nodes in the `default` category can be done, for example, with:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]% foreach -c default (set pxelabel MEMTEST)
[bright80->device*]% commit
```

The value of `pxelabel` can be cleared with:

#### Example

```
[root@bright80 ~]# cmsh -c "device; foreach -c default (clear pxelabel); commit"
```

In Bright View, the PXE label can be set from the `Settings` window for a node (figure 5.2).

- A more complicated example of overriding the default `MENU DEFAULT` value now follows. Although it helps in understanding how PXE labels can be used, it can normally be skipped because the use case for it is unlikely, and the details are involved.

In this example, `pxelabel` is set by the administrator via Bright View or `cmsh` to `localdrive`. This will then set the node to boot from the first local drive and not the node-installer. This is a setting that is discouraged since it usually makes node management harder, but it can be used by




Figure 5.2: Bright View PXE Label option

administrators who do not wish to answer any prompt during node boot, and also want the node drives to have no risk of being overwritten by the actions of the node-installer, and also want the system to be up and running quite fully, even if not necessarily provisioned with the latest image from the head node.

Here, the overwriting-avoidance method relies on the nodes being associated with a configuration file under `pxelinux.cfg` at the time that the `localdrive` setting is done. However, nodes that are unidentified, or are identified later on, will have their `MENU DEFAULT` value still set to a default `pxelabel` value set in the files under `/tftpboot/pxelinux.cfg/`, which is the value `linux` by default, and which is associated with a code block in that file with the label `LABEL linux`. To make such (as yet) unidentified nodes boot to a `localdrive` setting instead, requires modifying the files under `/tftpboot/pxelinux.cfg/`, so that the `MENU DEFAULT` line is associated with the code block of `LABEL localdrive` rather than the code block of `LABEL linux`.

There are two methods other than using the preceding `pxelabel` method to deal with the risk of overwriting. Unlike the `pxelabel` method however, these methods can interrupt node booting, so that the node does not progress to being fully up until the administrator takes further action:

1. If it is acceptable that the administrator manually enters a confirmation as part of the boot process when a possible overwrite risk is found, then the `datanode` method (section 5.4.4) can be used.
2. If it is acceptable that the boot process halts on detecting a possible overwrite risk, then the XML assertions method (Appendix D.11) is recommended.

### Changing The Install Mode Or Default Image Offered To Nodes

The selections offered by the PXE menu are pre-configured by default so that the `AUTO` menu option by default loads a kernel, runs the `AUTO` install mode, and eventually the `default-image` software image is provisioned.

Normally administrators should not be changing the install mode, kernel, or kernel options in the PXE menu configuration files under `pxelinux.cfg/`.

More on changing the install mode is given in section 5.4.4. More on changing software images, image package management, kernels, and kernel options, is to be found in Chapter 11.

### 5.1.2 iPXE Booting From A Disk Drive

Also by default, on disked nodes, iPXE software is placed on the drive during node installation. If the boot instructions from the BIOS for PXE booting fail, and if the BIOS instructions are that a boot attempt should then be made from the hard drive, it means that a PXE network boot attempt is done again, as instructed by the bootable hard drive. This can be a useful fallback option that works around certain BIOS features or problems.

### 5.1.3 iPXE Booting Using InfiniBand

On clusters that have InfiniBand hardware, it is normally used for data transfer as a service after the nodes have fully booted up (section 3.6). InfiniBand can also be used for PXE booting (described here) and used for node provisioning (section 5.3.3). However these uses are not necessary, even if InfiniBand is used for data transfer as a service later on, because booting and provisioning is available over Ethernet by default. This section (about boot over InfiniBand) may therefore safely be skipped when first configuring a cluster.

Bootting over InfiniBand via PXE is enabled by carrying out these 3 steps:

1. Making the Bright Cluster Manager aware that nodes are to be booted over InfiniBand. This can be done during the initial installation on the head node by marking the option “Allow booting over InfiniBand” (figure 3.11 of the *Installation Manual*). Alternatively, if the cluster is already installed, then node booting (section 3.2.3, page 61) can be set from `cmsh` or Bright View as follows:
  - (a) From `cmsh`’s `network` mode: If the InfiniBand network name is `ibnet`, then a `cmsh` command that will set it is:  

```
cmsh -c "network; set ibnet nodebooting yes; commit"
```
  - (b) From Bright View: The Settings window for the InfiniBand network, for example `ibnet`, can be accessed from the Networking resource via the clickpath `Networking→Networks[ibnet]→Edit→Settings` (this is similar to figure 3.5, but for `ibnet`). The `Node booting` option for `ibnet` is then enabled and saved.

If the InfiniBand network does not yet exist, then it must be created (section 3.2.2). The recommended default values used are described in section 3.6.3. The MAC address of the interface in `CMDaemon` defaults to using the GUID of the interface.

The administrator should also be aware that the interface from which a node boots, (conveniently labeled `BOOTIF`), must not be an interface that is already configured for that node in `CMDaemon`. For example, if `BOOTIF` is the device `ib0`, then `ib0` must not already be configured in `CMDaemon`. Either `BOOTIF` or the `ib0` configuration should be changed so that node installation can succeed.

2. Flashing iPXE onto the InfiniBand HCAs. (The ROM image is obtained from the HCA vendor).
3. Configuring the BIOS of the nodes to boot from the InfiniBand HCA. For PXE booting over Omni-Path, older Omni-Path cards may need to have UEFI firmware installed on them, and the only supported boot mode is then UEFI.

Administrators who enable iPXE booting almost always wish to provision over InfiniBand too. Configuring provisioning over InfiniBand is described in section 5.3.3.

### 5.1.4 Booting From The Drive

Besides network boot, a node can also be configured to start booting and get to the stage of loading up its kernel entirely from its drive, just like a normal standalone machine, by setting `PXE LABEL` to `localdrive` (page 127).

### 5.1.5 The Boot Role

The action of providing a PXE boot image via DHCP and TFTP is known as providing *node booting*.

Roles in general are introduced in section 2.1.5. The *boot role* is one such role that can be assigned to a regular node. The boot role configures a regular node so that it can then provide node booting. The role cannot be assigned or removed from the head node—the head node always has a boot role.

The boot role is assigned by administrators to regular nodes if there is a need to cope with the scaling limitations of TFTP and DHCP. TFTP and DHCP services can be overwhelmed when there are large numbers of nodes making use of them during boot. An example of the scaling limitations may be observed, for example, when, during the powering up and PXE boot attempts of a large number of regular nodes from the head node, it turns out that random different regular nodes are unable to boot, apparently due to network effects.

One implementation of boot role assignment might therefore be, for example, to have a several groups of racks, with each rack in a subnet, and with one regular node in each subnet that is assigned the boot role. The boot role regular nodes would thus take the DHCP and TFTP load off the head node and onto themselves for all the nodes in their associated subnet, so that all nodes of the cluster are then able to boot without networking issues.

## 5.2 Provisioning Nodes

The action of transferring the software image to the nodes is called *node provisioning*, and is done by special nodes called the *provisioning nodes*. More complex clusters can have several provisioning nodes configured by the administrator, thereby distributing network traffic loads when many nodes are booting.

Creating provisioning nodes is done by assigning a *provisioning role* to a node or category of nodes. Similar to how the head node always has a boot role (section 5.1.5), the head node also always has a provisioning role.

### 5.2.1 Provisioning Nodes: Configuration Settings

The provisioning role has several parameters that can be set:

Property	Description
<code>allImages</code>	<p>The following values decide what images the provisioning node provides:</p> <ul style="list-style-type: none"> <li>• <code>onlocaldisk</code> (the default): all images on the local disk, regardless of any other parameters set</li> <li>• <code>onlocaldiskexceptsharedimages</code>: all images on the local disk, except for shared images</li> <li>• <code>onsharedstorage</code>: all images on the shared storage, regardless of any other parameters set</li> <li>• <code>no</code>: only images listed in the <code>localimages</code> or <code>sharedimages</code> parameters, described next</li> </ul>
<code>localimages</code>	A list of software images on the local disk that the provisioning node accesses and provides. The list is used only if <code>allImages</code> is “no”.
<code>sharedimages</code>	A list of software images on the shared storage that the provisioning node accesses and provides. The list is used only if <code>allImages</code> is “no”
<code>Provisioning slots</code>	The maximum number of nodes that can be provisioned in parallel by the provisioning node. The optimum number depends on the infrastructure. The default value is 10, which is safe for typical cluster setups. Setting it lower may sometimes be needed to prevent network and disk overload.
<code>nodegroups</code>	<p>A list of node groups (section 2.1.4). If set, the provisioning node only provisions nodes in the listed groups. Conversely, nodes in one of these groups can only be provisioned by provisioning nodes that have that group set. Nodes without a group, or nodes in a group not listed in <code>nodegroups</code>, can only be provisioned by provisioning nodes that have no <code>nodegroups</code> values set. By default, the <code>nodegroups</code> list is unset in the provisioning nodes.</p> <p>The <code>nodegroups</code> setting is typically used to set up a convenient hierarchy of provisioning, for example based on grouping by rack and by groups of racks.</p>

A provisioning node keeps a copy of all the images it provisions on its local drive, in the same directory as where the head node keeps such images. The local drive of a provisioning node must therefore have enough space available for these images, which may require changes in its disk layout.

### 5.2.2 Provisioning Nodes: Role Setup With `cmsh`

In the following `cmsh` example the administrator creates a new category called `misc`. The default category `default` already exists in a newly installed cluster.

The administrator then assigns the role called `provisioning`, from the list of available assignable roles, to nodes in the `misc` category. After the `assign` command has been typed in, but before entering the command, tab-completion prompting can be used to list all the possible roles. Assignment creates an association between the role and the category. When the `assign` command runs, the shell drops into the level representing the provisioning role.

If the role called `provisioning` were already assigned, then the `use provisioning` command would drop the shell into the `provisioning` role, without creating the association between the role and the category.

As an aside from the topic of provisioning, from an organizational perspective, other assignable roles include monitoring, storage, and failover.

Once the shell is within the role level, the role properties can be edited conveniently.

For example, the nodes in the `misc` category assigned the provisioning role can have `default-image` set as the image that they provision to other nodes, and have 20 set as the maximum number of other nodes to be provisioned simultaneously (some text is elided in the following example):

### Example

```
[bright80]% category add misc
[bright80->category*[misc*]]% roles
[bright80->category*[misc*]->roles]% assign provisioning
[bright80...*]->roles*[provisioning*]]% set allimages no
[bright80...*]->roles*[provisioning*]]% set localimages default-image
[bright80...*]->roles*[provisioning*]]% set provisioningslots 20
[bright80...*]->roles*[provisioning*]]% show
Parameter                                Value
-----
All Images                               no
Include revisions of local images        yes
Local images                             default-image
Name                                      provisioning
Nodegroups
Provisioning associations                 <0 internally used>
Revision
Shared images
Type                                      ProvisioningRole
Provisioning slots                        20
[bright80->category*[misc*]->roles*[provisioning*]]% commit
[bright80->category[misc]->roles[provisioning]]%
```

Assigning a provisioning role can also be done for an individual node instead, if using a category is deemed overkill:

### Example

```
[bright80]% device use node001
[bright80->device[node001]]% roles
[bright80->device[node001]->roles]% assign provisioning
[bright80->device*[node001*]->roles*[provisioning*]]%
...
```

A role change configures a provisioning node, but does not directly update the provisioning node with images. After carrying out a role change, Bright Cluster Manager runs the `updateprovisioners` command described in section 5.2.4 automatically, so that regular images are propagated to the provisioners. The propagation can be done by provisioners themselves if they have up-to-date images. CMDaemon tracks the provisioning nodes role changes, as well as which provisioning nodes have up-to-date images available, so that provisioning node configurations and regular node images propagate efficiently. Thus, for example, image update requests by provisioning nodes take priority over provisioning update requests from regular nodes.

### 5.2.3 Provisioning Nodes: Role Setup With Bright View

The provisioning configuration outlined in `cmsh` mode in section 5.2.2 can be done via Bright View too, as follows:



A misc category can be added via the clickpath Grouping→Node Categories→Add→Node Category→Settings. The node category should be given a name misc (figure 5.3), and saved.




Figure 5.3: Bright View: Adding A misc Category

The Roles window can then be opened from within the misc category. To add a role, the Add button in the Roles window is clicked. A scrollable list of available roles is then displayed, (figure 5.4).




Figure 5.4: Bright View: Setting A provisioning Role

After selecting a role, then navigating via the Back buttons to the Settings menu of figure 5.3, the role can be saved using the Save button there.

The role has properties which can be edited (figure 5.5).

The screenshot shows the Bright View interface for configuring a provisioning role. On the left, a sidebar contains 'Categories' and 'Node category misc'. The main content area is divided into two panels. The left panel, titled 'Roles', displays a table with columns 'NAME' and 'OPTIONS'. It lists a role named 'provisioning' with an 'Edit' button. The right panel, titled 'Provisioning role provisioning', contains a form for editing the role. The form includes the following fields and controls:

- Name:** A text input field containing 'provisioning'.
- maxProvisioningNodes:** A numeric input field containing '10'.
- All images:** A dropdown menu set to 'no'.
- Images:** Two dropdown menus, one for 'default-image' (set to 'None') and one for 'login-image' (set to 'None').
- Include revisions of local ima...:** A toggle switch with 'Enabled' and 'Disabled' buttons, currently set to 'Enabled'.
- revision:** A text input field containing 'revision'.

At the bottom of each panel are navigation buttons: 'Back', 'Revert', 'Add', and 'Delete' for the Roles panel; and 'Back', 'Revert', and 'Delete' for the Provisioning role provisioning panel.

Figure 5.5: Bright View: Configuring A provisioning Role

The `Provisioning slots` setting decides, for example, how many images can be supplied simultaneously from the provisioning node, while the `Images` and `All images` settings decide what images the provisioning node supplies. As before, the setting can be saved using the Save button of figure 5.3.

The images offered by the provisioning role should not be confused with the software image setting of the `misc` category itself, which is the image the provisioning node requests for itself from the category.

#### 5.2.4 Provisioning Nodes: Housekeeping

The head node does housekeeping tasks for the entire provisioning system. Provisioning is done on request for all non-head nodes on a first-come, first-serve basis. Since provisioning nodes themselves, too, need to be provisioned, it means that to cold boot an entire cluster up quickest, the head node should be booted and be up first, followed by provisioning nodes, and finally by all other non-head nodes. Following this start-up sequence ensures that all provisioning services are available when the other non-head nodes are started up.

Some aspects of provisioning housekeeping are discussed next:

##### Provisioning Node Selection

When a node requests provisioning, the head node allocates the task to a provisioning node. If there are several provisioning nodes that can provide the image required, then the task is allocated to the provisioning node with the lowest number of already-started provisioning tasks.

##### Limiting Provisioning Tasks With `MaxNumberOfProvisioningThreads`

Besides limiting how much simultaneous provisioning per provisioning node is allowed with `Provisioning Slots` (section 5.2.1), the head node also limits how many simultaneous provisioning tasks are allowed to run on the entire cluster. This is set using the `MaxNumberOfProvisioningThreads` directive in the head node's `CMDaemon` configuration file, `/etc/cmd.conf`, as described in Appendix C.

**Provisioning Tasks Deferral and Failure**

A provisioning request is *deferred* if the head node is not able to immediately allocate a provisioning node for the task. Whenever an ongoing provisioning task has finished, the head node tries to re-allocate deferred requests.

A provisioning request *fails* if an image is not transferred. 5 retry attempts at provisioning the image are made in case a provisioning request fails.

A provisioning node that is carrying out requests, and which loses connectivity, has its provisioning requests remain allocated to it for 180 seconds from the time that connectivity was lost. After this time the provisioning requests fail.

**Provisioning Role Change Notification With `updateprovisioners`**

The `updateprovisioners` command can be accessed from the `softwareimage` mode in `cmsh`. It can also be accessed from Bright View, via the clickpath Provisioning→Provisioning requests→Update provisioning nodes.

In the examples in section 5.2.2, changes were made to provisioning role attributes for an individual node as well as for a category of nodes. This automatically ran the `updateprovisioners` command.

The `updateprovisioners` command runs automatically if `CMDaemon` is involved during software image changes or during a provisioning request. If on the other hand, the software image is changed outside of the `CMDaemon` front ends (Bright View and `cmsh`), for example by an administrator adding a file by copying it into place from the bash prompt, then `updateprovisioners` should be run manually to update the provisioners.

In any case, if it is not run manually, it is scheduled to run every midnight by default.

When the default `updateprovisioners` is invoked manually, the provisioning system waits for all running provisioning tasks to end, and then updates all images located on any provisioning nodes by using the images on the head node. It also re-initializes its internal state with the updated provisioning role properties, i.e. keeps track of what nodes are provisioning nodes.

The default `updateprovisioners` command, run with no options, updates all images. If run from `cmsh` with a specified image as an option, then the command only does the updates for that particular image. A provisioning node undergoing an image update does not provision other nodes until the update is completed.

**Example**

```
[bright80]% softwareimage updateprovisioners
Provisioning nodes will be updated in the background.

Sun Dec 12 13:45:09 2010 bright80: Starting update of software image(s)\
provisioning node(s). (user initiated).
[bright80]% softwareimage updateprovisioners [bright80]%
Sun Dec 12 13:45:41 2010 bright80: Updating image default-image on prov\
isioning node node001.
[bright80]%
Sun Dec 12 13:46:00 2010 bright80: Updating image default-image on prov\
isioning node node001 completed.
Sun Dec 12 13:46:00 2010 bright80: Provisioning node node001 was updated
Sun Dec 12 13:46:00 2010 bright80: Finished updating software image(s) \
on provisioning node(s).
```

**Provisioning Role Draining And Undraining Nodes With `drain`, `undrain`**

The `drain` and `undrain` commands to control provisioning nodes are accessible from within the `softwareimage` mode of `cmsh`.

If a node is put into a `drain` state, then all currently active provisioning requests continue until they are completed. However, the node is not assigned any further pending requests, until the node is put back into an `undrain` state.

### Example

```
[bright80->softwareimage]% drain -n master
Nodes drained
[bright80->softwareimage]% provisioningstatus
Provisioning subsystem status
Pending request:          node001, node002
Provisioning node status:
+ bright80
  Slots:                  1 / 10
  State:                  draining
  Active nodes:           node003
  Up to date images:      default-image
[bright80->softwareimage]% provisioningstatus
Provisioning subsystem status
Pending request:          node001, node002
Provisioning node status:
+ bright80
  Slots:                  0 / 10
  State:                  drained
  Active nodes:           none
  Up to date images:      default-image
```

To drain all nodes at once, the `--role` option can be used, with `provisioning` role as its value. All pending requests then remain in the queue, until the nodes are undrained again.

### Example

```
[bright80->softwareimage]% drain --role provisioning
...Time passes. Pending
  requests stay in the queue. Then
  admin undrains it...
[bright80->softwareimage]% undrain --role provisioning
```

### Provisioning Node Update Safeguards And `provisioningnodeautooupdatetimerout`

The `updateprovisioners` command is subject to safeguards that prevent it running too frequently. The minimum period between provisioning updates can be adjusted with the parameter `provisioningnodeautooupdatetimerout`, which has a default value of 300s.

When the head node receives a provisioning request, it checks if the last update of the provisioning nodes is more than the timeout period. If this is the case an update is triggered. The update is disabled if the timeout is set to zero (`false`).

The parameter can be accessed and set within `cmsh` from `partition` mode:

### Example

```
[root@bright80 ]# cmsh
[bright80]% partition use base
[bright80->partition[base]]% get provisioningnodeautooupdatetimerout
[bright80->partition[base]]% 300
[bright80->partition[base]]% set provisioningnodeautooupdatetimerout 0
[bright80->partition*[base*]]% commit
```

Within Bright View the parameter is accessible via the clickpath:

Cluster→Partition[base]→Provisioning Node Auto Update Timeout.

To prevent provisioning an image to the nodes, the `locked` state (section 5.4.7) can be used. A `locked` state defers the provisioning request, until the image is unlocked once more.

## 5.3 The Kernel Image, Ramdisk And Kernel Modules

A *software image* is a complete Linux filesystem that is to be installed on a non-head node. Chapter 11 describes images and their management in detail.

The head node holds the head copy of the software images. Whenever files in the head copy are changed using CMDaemon, the changes automatically propagate to all provisioning nodes via the `updateprovisioners` command (section 5.2.4).

### 5.3.1 Booting To A “Good State” Software Image

When nodes boot from the network in simple clusters, the head node supplies them with a *known good state* during node start up. The known good state is maintained by the administrator and is defined using a software image that is kept in a directory of the filesystem on the head node. Supplementary filesystems such as `/home` are served via NFS from the head node by default.

For a diskless node the known good state is copied over from the head node, after which the node becomes available to cluster users.

For a disked node, by default, the hard disk contents on specified local directories of the node are checked against the known good state on the head node. Content that differs on the node is changed to that of the known good state. After the changes are done, the node becomes available to cluster users.

Each software image contains a Linux kernel and a ramdisk. These are the first parts of the image that are loaded onto a node during early boot. The kernel is loaded first. The ramdisk is loaded next, and contains driver modules for the node’s network card and local storage. The rest of the image is loaded after that, during the node-installer stage (section 5.4).

### 5.3.2 Selecting Kernel Driver Modules To Load Onto Nodes

#### Kernel Driver Modules With `cmsh`

In `cmsh`, the modules that are to go on the ramdisk can be placed using the `kernelmodules` submode of the `softwareimage` mode. The order in which they are listed is the attempted load order.

Whenever a change is made via the `kernelmodules` submode to the kernel module selection of a software image, CMDaemon automatically runs the `createramdisk` command. The `createramdisk` command regenerates the ramdisk inside the `initrd` image and sends the updated image to all provisioning nodes, to the image directory, set by default to `/cm/images/default-image/boot/`. The original `initrd` image is saved as a file with suffix `".orig"` in that directory. An attempt is made to generate the image for all software images that CMDaemon is aware of, regardless of category assignment, unless the image is protected from modification by CMDaemon with a `FrozenFile` directive (Appendix C).

The `createramdisk` command can also be run manually from within the `softwareimage` mode.

#### Kernel Driver Modules With Bright View

In Bright View the selection of kernel modules for a particular image, is carried out through the `Software images` resource, and then choosing the `Kernel modules` menu option of that image. For example, for the image `default-image` (clickpath `Software images[default-image]→Edit→Settings→Kernel modules`, leading to figure 5.6).




Figure 5.6: Bright View: Selecting Kernel Modules For Software Images

New kernel modules can be added using the `Add` button, existing kernel modules can be removed using the `Delete` button, and kernel module parameters can be edited using the `Edit` button.

### Manually Regenerating A Ramdisk

Regenerating a ramdisk manually via `cmsh` or Bright View is useful if the kernel or modules have changed without using `CMDaemon`. For example, after running a YUM update which has modified the kernel or modules of the nodes (section 11.3). In such a case, the distribution would normally update the ramdisk on the machine, but this is not done for the extended ramdisk for nodes in Bright Cluster Manager. Not regenerating the Bright Cluster Manager ramdisk for nodes after such an update means the nodes may fail on rebooting during the loading of the ramdisk (section 5.8.4).

An example of regenerating the ramdisk is seen in section 5.8.5.

### Implementation Of Kernel Driver Via Ramdisk Or Kernel Parameter

Sometimes, testing or setting a kernel driver as a kernel parameter may be more convenient. How to do that is covered in section 11.3.4.

### 5.3.3 InfiniBand Provisioning

On clusters that have InfiniBand hardware, it is normally used for data transfer as a service after the nodes have fully booted up (section 3.6). It can also be used for PXE booting (section 5.1.3) and for node provisioning (described here), but these are not normally a requirement. This section (about InfiniBand node provisioning) may therefore safely be skipped in almost all cases when first configuring a cluster.

During node start-up on a setup for which InfiniBand networking has been enabled, the `init` process runs the `rdma` script. For SLES and distributions based on versions prior to Red Hat 6, the `openib` script is used instead of the `rdma` script. The script loads up InfiniBand modules into the kernel. When the cluster is finally fully up and running, the use of InfiniBand is thus available for all processes that request it. Enabling InfiniBand is normally set by configuring the InfiniBand network when installing the head node, during the `Additional Network Configuration` screen (figure 3.11 of the *Installation Manual*).

Provisioning nodes over InfiniBand is not implemented by default, because the `init` process, which handles initialization scripts and daemons, takes place only after the node-provisioning stage launches. InfiniBand modules are therefore not available for use during provisioning, which is why, for default kernels, provisioning in Bright Cluster Manager is done via Ethernet.

Provisioning at the faster InfiniBand speeds rather than Ethernet speeds is however a requirement

for some clusters. To get the cluster to provision using InfiniBand requires both of the following two configuration changes to be carried out:

1. configuring InfiniBand drivers for the ramdisk image that the nodes first boot into, so that provisioning via InfiniBand is possible during this pre-init stage
2. defining the provisioning interface of nodes that are to be provisioned with InfiniBand. It is assumed that InfiniBand networking is already configured, as described in section 3.6.

The administrator should be aware that the interface from which a node boots, (conveniently labeled `BOOTIF`), must not be an interface that is already configured for that node in `CMDaemon`. For example, if `BOOTIF` is the device `ib0`, then `ib0` must not already be configured in `CMDaemon`. Either `BOOTIF` or the `ib0` configuration should be changed so that node installation can succeed.

How these two changes are carried out is described next:

### InfiniBand Provisioning: Ramdisk Image Configuration

An easy way to see what modules must be added to the ramdisk for a particular HCA can be found by running `rdma` (or `openibd`), and seeing what modules do load up on a fully booted regular node.

One way to do this is to run the following lines as root:

```
[root@bright80 ~]# { service rdma stop; lsmod | cut -f1 -d" "; }>/tmp/a
[root@bright80 ~]# { service rdma start; lsmod | cut -f1 -d" "; }>/tmp/b
```

The `rdma` service in the two lines should be replaced by `openibd` service instead when using SLES, or distributions based on versions of Red Hat prior to version 6.

The first line stops the InfiniBand service, just in case it is running, in order to unload its modules, and then lists the modules on the node.

The second line starts the service, so that the appropriate modules are loaded, and then lists the modules on the node again. The output of the first step is stored in a file `a`, and the output from the second step is stored in a file `b`.

Running `diff` on the output of these two steps then reveals the modules that get loaded. For `rdma`, the output may display something like:

### Example

```
[root@bright80 ~]# diff /tmp/a /tmp/b
1,3c1
< Unloading OpenIB kernel modules:
< Failed to unload ib_core
<
[FAILED]
---
> Loading OpenIB kernel modules:
[ OK ]
4a3,14
> ib_ipoib
> rdma_ucm
> ib_ucm
> ib_uverbs
> ib_umad
> rdma_cm
> ib_cm
> iw_cm
> ib_addr
> ib_sa
> ib_mad
> ib_core
```

As suggested by the output, the modules `ib_ipoib`, `rdma_ucm` and so on are the modules loaded when `rdma` starts, and are therefore the modules that are needed for this particular HCA. Other HCAs may cause different modules to be loaded.

For a default Red Hat from version 7 onwards, the `rdma` service can only be started; it cannot be stopped. Finding the modules that load can therefore only be done once for the default configuration, until the next reboot.

The InfiniBand modules that load are the ones that the `initrd` image needs, so that InfiniBand can be used during the node provisioning stage. The administrator can therefore now create an `initrd` image with the required InfiniBand modules.

Loading kernel modules into a ramdisk is covered in general in section 5.3.2. A typical Mellanox HCA may have an `initrd` image created as follows (some text ellipsized in the following example):

### Example

```
[root@bright80 ~]# cmsh
[bright80]% softwareimage use default-image
[bright80->softwareimage[default-image]]% kernelmodules
[bright80...age[default-image]->kernelmodules]% add mlx4_ib
[bright80...age*[default-image*]->kernelmodules*[mlx4_ib*]]% add ib_ipoib
[bright80...age*[default-image*]->kernelmodules*[ib_ipoib*]]% add ib_umad
[bright80...age*[default-image*]->kernelmodules*[ib_umad*]]% commit
[bright80->softwareimage[default-image]->kernelmodules[ib_umad]]%
Tue May 24 03:45:35 2011 bright80: Initial ramdisk for image default-im\
age was regenerated successfully.
```

If the modules are put in another image instead of `default-image`, then the default image that nodes boot from should be set to the new image (section 3.15.2).

### InfiniBand Provisioning: Network Configuration

It is assumed that the networking configuration for the final system for InfiniBand is configured following the general guidelines of section 3.6. If it is not, that should be checked first to see if all is well with the InfiniBand network.

The provisioning aspect is set by defining the provisioning interface. An example of how it may be set up for 150 nodes with a working InfiniBand interface `ib0` in `cmsh` is:

### Example

```
[root@bright80~]# cmsh
[bright80]% device
[bright80->device]% foreach -n node001..node150 (set provisioninginterface ib0)
[bright80->device*]% commit
```

## 5.4 Node-Installer

After the kernel has started up, and the ramdisk kernel modules are in place on the node, the node launches the node-installer.

The node-installer interacts with `CMDaemon` on the head node and takes care of the rest of the boot process.

As an aside, the node-installer modifies some files (Appendix A.3) on the node it is installing to, so that they differ from the otherwise-expected pre-init stage Linux system. Such modifications can be prevented by a `frozenFilesPerNode` or `frozenFilesPerCategory` directive, as documented within `/cm/node-installer/scripts/node-installer.conf`, and illustrated on page 598.

Once the node-installer has completed its tasks, the local drive of the node has a complete Linux pre-init stage system. The node-installer ends by calling `/sbin/init` from the local drive and the boot process then proceeds as a normal Linux boot.

The steps the node-installer goes through for each node are:



1. requesting a node certificate (section 5.4.1)
2. deciding or selecting node configuration (section 5.4.2)
3. starting up all network interfaces (section 5.4.3)
4. determining install-mode type and execution mode (section 5.4.4)
5. running `initialize` scripts (section 5.4.5)
6. checking partitions, mounting filesystems (section 5.4.6)
7. synchronizing the local drive with the correct software image (section 5.4.7)
8. writing network configuration files to the local drive (section 5.4.8)
9. creating an `/etc/fstab` file on the local drive (section 5.4.9)
10. installing GRUB bootloader if configured by Bright Cluster Manager (section 5.4.10), and initializing SELinux if it has been installed and configured (Chapter 9 of the *Installation Manual*)
11. running `finalize` scripts (section 5.4.11)
12. unloading specific drivers no longer needed (section 5.4.12)
13. switching the root device to the local drive and calling `/sbin/init` (section 5.4.13)

These 13 node-installer steps and related matters are described in detail in the corresponding sections 5.4.1–5.4.13.

#### 5.4.1 Requesting A Node Certificate

Each node communicates with the CMDaemon on the head node using a certificate. If no certificate is found, it automatically requests one from CMDaemon running on the head node (figure 5.7).




Figure 5.7: Certificate Request

The certificate is stored on the head node in `/cm/node-installer/certificates/` by MAC address.

### Null Cipher Certificates

By default, a null cipher is used on internal networks such as `internalnet`, to keep communications speedy. Using encryption on even these networks is sometimes a requirement in very unusual situations. In that case, setting the advanced configuration flag `AllowNullCipherNetwork=0` in `cmd.conf` (Appendix C, page 610) forces encryption on after `CMDaemon` is restarted. By default, its value is 1.

### Certificate Auto-signing

*Certificate auto-signing* means the cluster management daemon automatically signs a certificate sign request that has been requested by a node. Certificate auto-signing can be configured from within partition mode of `cmsh`, with the `signinstallercertificates` parameter. It can take one of the following values:

- AUTO (the default)
- MANUAL

### Example

```
[bright80 ~]# cmsh
[bright80]% partition
[bright80->partition[base]]% set signinstallercertificates auto
```

For untrusted networks, it may be wiser to approve certificate requests manually to prevent new nodes being added automatically without getting noticed.

Disabling certificate auto-signing for all networks can be done by setting `signinstallercertificates` to `MANUAL`.

Instead of disabling certificate autosigning for all networks, a finer tuning can be carried out for individual networks. This requires that `signinstallercertificates` be set to `AUTO` in partition mode. The `allowautosign` parameter in network mode can then be set for a particular network, and it can take one of the the following values:

- Always
- Automatic (the default)
- Never

### Example

```
[bright80 ~]# cmsh
[bright80]% network use internalnet
[bright80->network[internalnet]]% set allowautosign automatic[TAB][TAB]
always      automatic  never
```

Section 2.3 has more information on certificate management in general.

### Certificate Storage And Removal Implications

After receiving a valid certificate, the node-installer stores it in `/cm/node-installer/certificates/<node mac address>/` on the head node. This directory is NFS exported to the nodes, but can only be accessed by the `root` user. The node-installer does not request a new certificate if it finds a certificate in this directory, valid or invalid.

If an invalid certificate is received, the screen displays a communication error. Removing the node's corresponding certificate directory allows the node-installer to request a new certificate and proceed further.

### 5.4.2 Deciding Or Selecting Node Configuration

Once communication with the head node CMDaemon is established, the node-installer tries to identify the node it is running on so that it can select a configuration from CMDaemon's record for it, if any such record exists. It correlates any node configuration the node is expected to have according to network hardware detected. If there are issues during this correlation process then the administrator is prompted to select a node configuration until all nodes finally have a configuration.

#### Possible Node Configuration Scenarios

The correlations process and corresponding scenarios are now covered in more detail:

It starts with the node-installer sending a query to CMDaemon to check if the MAC address used for net booting the node is already associated with a node in the records of CMDaemon. In particular, it checks the MAC address for a match against the existing *node configuration* properties, and decides whether the node is *known* or *new*.

- the node is **known** if the query matches a node configuration. It means that node has been booted before.
- the node is **new** if no configuration is found.

In both cases the node-installer then asks CMDaemon to find out if the node is connected to an Ethernet switch, and if so, to which port. Setting up Ethernet switches for port detection is covered in section 3.8.

If a port is detected for the node, the node-installer queries CMDaemon for a node configuration associated with the detected Ethernet switch port. If a port is not detected for the node, then either the hardware involved with port detection needs checking, or a node configuration must be selected manually.

There are thus several scenarios:

1. The node is new, and an Ethernet switch port is detected. A node configuration associated with the port is found. The node-installer suggests to the administrator that the new node should use this configuration, and displays the configuration along with a confirmation dialog (figure 5.8). This suggestion can be interrupted, and other node configurations can be selected manually instead through a sub-dialog (figure 5.9). By default (in the main dialog), the original suggestion is accepted after a timeout.




Figure 5.8: Scenarios: Configuration Found, Confirm Node Configuration




Figure 5.9: Scenarios: Node Selection Sub-Dialog

- The node is new, and an Ethernet switch port is detected. A node configuration associated with the port is not found. The node-installer then displays a dialog that allows the administrator to either retry Ethernet switch port detection (figure 5.10) or to drop into a sub-dialog to manually select a node configuration (figure 5.9). By default, port detection is retried after a timeout.




Figure 5.10: Scenarios: Unknown Node, Ethernet Port Detected

3. The node is new, and an Ethernet switch port is not detected. The node-installer then displays a dialog that allows the user to either retry Ethernet switch port detection (figure 5.11) or to drop into a sub-dialog to manually select a node configuration (figure 5.9). By default, port detection is retried after a timeout.




Figure 5.11: Scenarios: Unknown Node, No Ethernet Port Detected

4. The node is known, and an Ethernet switch port is detected. The configuration associated with the

port is the same as the configuration associated with the node's MAC address. The node-installer then displays the configuration as a suggestion along with a confirmation dialog (figure 5.8). The suggestion can be interrupted, and other node configurations can be selected manually instead through a sub-dialog (figure 5.9). By default (in the main dialog), the original suggestion is accepted after a timeout.

5. The node is known, and an Ethernet switch port is detected. However, the configuration associated with the port is not the same as the configuration associated with the node's MAC address. This is called a *port mismatch*. This type of port mismatch situation occurs typically during a mistaken *node swap*, when two nodes are taken out of the cluster and returned, but their positions are swapped by mistake (or equivalently, they are returned to the correct place in the cluster, but the switch ports they connect to are swapped by mistake). To prevent configuration mistakes, the node-installer displays a port mismatch dialog (figure 5.12) allowing the user to retry, accept a node configuration that is associated with the detected Ethernet port, or to manually select another node configuration via a sub-dialog (figure 5.9). By default (in the main port mismatch dialog), port detection is retried after a timeout.




Figure 5.12: Scenarios: Port Mismatch Dialog

6. The node is known, and an Ethernet switch port is not detected. However, the configuration associated with the node's MAC address does have an Ethernet port associated with it. This is also considered a port mismatch. To prevent configuration mistakes, the node-installer displays a port mismatch dialog similar to figure 5.12, allowing the user to retry or to drop into a sub-dialog and manually select a node configuration that may work.

However, a more likely solution in most cases is to:

- either clear the switch port configuration in the cluster manager so that switch port detection is not attempted. For example, for node001, this can be done by running this `cmsh` command on the head node:  
`cmsh -c "device clear node001 ethernetswitch"`
- or enable switch port detection on the switch. This is usually quite straightforward, but may

require going through the manuals or software application that the switch manufacturer has provided.

By default (in the port mismatch dialog), port detection is retried after a timeout. This means that if the administrator clears the switch port configuration or enables switch port detection, the node-installer is able to continue automatically with a consistent configuration.

7. The node is known, and an Ethernet switch port is detected. However, the configuration associated with the node's MAC address has no Ethernet switch port associated with it. This is not considered a port mismatch but an unset switch port configuration, and it typically occurs if switch port configuration has not been carried out, whether by mistake or deliberately. The node-installer displays the configuration as a suggestion along with a confirmation dialog (figure 5.13). The suggestion can be interrupted, and other node configurations can be selected manually instead using a sub-dialog. By default (in the main dialog) the configuration is accepted after a timeout.




Figure 5.13: Scenarios: Port Unset Dialog

A truth table summarizing the scenarios is helpful:

Scenario	Node known?	Switch port detected?	Switch port configuration found?	Switch port configuration conflicts with node configuration?
1	No	Yes	Yes	No
2	No	Yes	No	No
3	No	No	No	No
4	Yes	Yes	Yes	No
5	Yes	Yes	Yes	Yes (configurations differ)
6	Yes	No	Yes	Yes (port expected by MAC configuration not found)
7	Yes	Yes	No	No (port not expected by MAC configuration)

In these scenarios, whenever the user manually selects a node configuration in the prompt dialog, an attempt to detect an Ethernet switch port is repeated. If a port mismatch still occurs, it is handled by the system as if the user has not made a selection.

### Summary Of Behavior During Hardware Changes

The logic of the scenarios means that an unpreconfigured node always boots to a dialog loop requiring manual intervention during a first install (scenarios 2 and 3). For subsequent boots the behavior is:

- If the node MAC hardware has changed (scenarios 1, 2, 3):
  - if the node is new and the detected port has a configuration, the node automatically boots to that configuration (scenario 1).
  - else manual intervention is needed (scenarios 2, 3)
- If the node MAC hardware has not changed (scenarios 4, 5, 6, 7):
  - if there is no port mismatch, the node automatically boots to its last configuration (scenarios 4, 7).
  - else manual intervention is needed (scenarios 5, 6).

### The `newnodes` Command

**newnodes basic use:** New nodes that have not been configured yet can be detected using the `newnodes` command from within the device mode of `cmsh`. A new node is detected when it reaches the node-installer stage after booting, and contacts the head node.

### Example

```
[bright80->device]% newnodes
The following nodes (in order of appearance) are waiting to be assigned:
MAC                               First appeared           Detected on switch port
-----
00:0C:29:01:0F:F8  Mon, 14 Feb 2011 10:16:00 CET  [no port detected]
```

At this point the node-installer is seen by the administrator to be looping, waiting for input on what node name is to be assigned to the new node.

The nodes can be uniquely identified by their MAC address or switch port address.

The port and switch to which a particular MAC address is connected can be discovered by using the `showport` command (section 3.8.4). After confirming that they are appropriate, the `ethernet switch` property for the specified device can be set to the port and switch values.

### Example

```
[bright80->device]% showport 00:0C:29:01:0F:F8
switch01:8
[bright80->device]% set node003 ethernet switch switch01:8
[bright80->device*]% commit
```

When the node name (node003 in the preceding example) is assigned, the node-installer stops looping and goes ahead with the installation to the node.

The preceding basic use of `newnodes` is useful for small numbers of nodes. For larger number of nodes, the advanced options of `newnodes` may help carry out node-to-MAC assignment with less effort.



**newnodes advanced use—options:** The list of MAC addresses discovered by a `newnodes` command can be assigned in various ways to nodes specified by the administrator. Node objects should be created in advance to allow the assignment to take place. The easiest way to set up node objects is to use the `--clone` option of the `foreach` command (section 2.5.5).

The advanced options of `newnodes` are particularly useful for quickly assigning node names to specific physical nodes. All that is needed is to power the nodes up in the right order. For nodes with the same hardware, the node that is powered up first reaches the stage where it tries to connect with the node-installer first. So its MAC address is detected first, and arrives on the list generated by `newnodes` first. If some time after the first node is powered up, the second node is powered up, then its MAC address becomes the second MAC address on the list, and so on for the third, fourth, and further nodes.

When assigning node names to a physical node, on a cluster that has no such assignment already, the first node that arrived on the list gets assigned the name `node001`, the second node that arrived on the list gets assigned the name `node002` and so on.

The advanced options are shown in `device` mode by running the `help newnodes` command. The options can be introduced as being of three kinds: straightforward, grouping, and miscellaneous:

- The straightforward options:

```
-n|--nodes
-w|--write
-s|--save
```

Usually the most straightforward way to assign the nodes is to use the `-n` option, which accepts a list of nodes, together with a `-w` or `-s` option. The `-w` (`--write`) option sets the order of nodes to the corresponding order of listed MAC addresses, and is the same as setting an object in `cmsh`. The `-s` (`--save`) option is the same as setting and committing an object in `cmsh`, so `-s` implies a `-w` option is run at the same time.

So, for example, if 8 new nodes are discovered by the node-installer on a cluster with no nodes so far, then:

### Example

```
[bright80->device]% newnodes -w -n node001..node008
```

assigns (but does not commit) the sequence `node001` to `node008` the new MAC address according to the sequence of MAC addresses displaying on the list.

- The grouping options:

```
-g|--group
-c|--category
-h|--chassis
-r|--rack
```

The “`help newnodes`” command in `device` mode shows assignment options other than `-n` for a node range are possible. For example, the assignments can also be made for a group (`-g`), per category (`-c`), per chassis (`-h`), and per rack (`-r`).

- The miscellaneous options:

```
-f|--force
-o|--offset
```

By default, the `newnodes` command fails when it attempts to set a node name that is already taken. The `-f` (`--force`) option forces the new MAC address to be associated with the old node name. When used with an assignment grouping, (node range, group, category, chassis, or rack) all the nodes in the grouping lose their node-to-MAC assignments and get new assignments. The `-f` option should therefore be used with care.

The `-o` (`--offset`) option takes a number `<number>` and skips `<number>` nodes in the list of detected unknown nodes, before setting or saving values from the assignment grouping.

Examples of how to use the advanced options follow.

**newnodes advanced use—range assignment behavior example:** For example, supposing there is a cluster with nodes assigned all the way up to node022. That is, CMDaemon knows what node is assigned to what MAC address. For the discussion that follows, the three nodes node020, node021, node022 can be imagined as being physically in a rack of their own. This is simply to help to visualize a layout in the discussion and tables that follow and has no other significance. An additional 3 new, that is unassigned, nodes are placed in the rack, and allowed to boot and get to the node-installer stage.

The `newnodes` command discovers the new MAC addresses of the new nodes when they reach their node-installer stage, as before (the switch port column is omitted in the following text for convenience):

### Example

```
[bright80->device]% newnodes
MAC                First appeared
-----
00:0C:29:EF:40:2A  Tue, 01 Nov 2011 11:42:31 CET
00:0C:29:95:D3:5B  Tue, 01 Nov 2011 11:46:25 CET
00:0C:29:65:9A:3C  Tue, 01 Nov 2011 11:47:13 CET
```

The assignment of MAC to node address could be carried out as follows:

### Example

```
[bright80->device]% newnodes -s -n node023..node025
MAC                First appeared                Hostname
-----
00:0C:29:EF:40:2A  Tue, 01 Nov 2011 11:42:31 CET  node023
00:0C:29:95:D3:5B  Tue, 01 Nov 2011 11:46:25 CET  node024
00:0C:29:65:9A:3C  Tue, 01 Nov 2011 11:47:13 CET  node025
```

Once this is done, the node-installer is able to stop looping, and to go ahead and install the new nodes with an image.

The physical layout in the rack may then look as indicated by this:

before	after	MAC
node020	node020	
node021	node021	
node022	node022	
	node023	...A
	node024	...B
	node025	...C

Here, node023 is the node with the MAC address ending in A.

If instead of the previous `newnodes` command, an offset of 1 is used to skip assigning the first new node:

### Example

```
[bright80->device]% newnodes -s -o 1 node024..node025
```

then the rack layout looks like:

before	after	MAC
node020	node020	
node021	node021	
node022	node022	
	<i>unassigned</i>	...A
	node024	...B
	node025	...C

Here, *unassigned* is where node023 of the previous example is physically located, that is, the node with the MAC address . . . A. The lack of assignment means there is actually no association of the name node023 with that MAC address, due to the `newnodes` command having skipped over it with the `-o` option.

If instead the assignment is done with:

### Example

```
[bright80->device]% newnodes -s 1 node024..node026
```

then the node023 name is unassigned, and the name node024 is assigned instead to the node with the MAC address . . . A, so that the rack layout looks like:

before	after	MAC
node020	node020	
node021	node021	
node022	node022	
	node024	...A
	node025	...B
	node026	...C

**newnodes advanced use—assignment grouping example:** Node range assignments are one way of using `newnodes`. However assignments can also be made to a category, a rack, or a chassis. For example, with Bright View, assigning node names to a rack can be done from the `Racks` option of the node. For example, to add a node001 to a rack1, the clickpath would be:

```
Devices→Settings[node001]→Rack[rack1].
```

In `cmsh`, the assignment of multiple node names to a rack can conveniently be done with a `foreach` loop from within `device` mode:

### Example

```
[bright80->device]% foreach -n node020..node029 (set rack rack02)
[bright80->device*]% commit
[bright80->device]% foreach -n node030..node039 (set rack rack03)
[bright80->device*]% commit
```

The assignment of node names with the physical node in the rack can then be arranged as follows: If the nodes are identical hardware, and are powered up in numerical sequence, from `node020` to `node039`, with a few seconds in between, then the list that the basic `newnodes` command (without options) displays is arranged in the same numerical sequence. Assigning the list in the rack order can then be done by running:

### Example

```
[bright80->device]% newnodes -s -r rack02..rack03
```

If it turns out that the boot order was done very randomly and incorrectly for all of `rack02`, and that the assignment for `rack02` needs to be done again, then a simple way to deal with it is to bring down the nodes of `rack02`, then clear out all of the `rack02` current MAC associations, and redo them according to the correct boot order:

### Example

```
[bright80->device]% foreach -r rack02 ( clear mac ) ; commit
[...removes MAC association with nodes from CMDaemon...]

[...now reboot nodes in rack02 in sequence (not with Bright Cluster Manager)i...]

[bright80->device]% newnodes

[...shows sequence as the nodes come up..]

[bright80->device]% newnodes -s -r rack02

[...assigns sequence in boot order...]
```

**newnodes advanced use—assignment forcing example:** The `--force` option can be used in the following case: Supposing that `node022` fails, and a new node hardware comes in to replace it. The new regular node has a new MAC address. So, as explained by scenario 3 (section 5.4.2), if there is no switch port assignment in operation for the nodes, then the node-installer loops around, waiting for intervention.<sup>1</sup>

This situation can be dealt with from the command line by:

- accepting the node configuration at the regular node console, via a sub-dialog
- accepting the node configuration via `cmsh`, without needing to be at the regular node console:

```
[bright80->device]% newnodes -s -f -n node022
```

### 5.4.3 Starting Up All Network Interfaces

At the end of section 5.4.2, the node-installer knows which node it is running on, and has decided what its node configuration is.

#### Starting Up All Provisioning Network Interfaces

It now gets on with setting up the IP addresses on the provisioning interfaces required for the node-installer, while taking care of matters that come up on the way:

<sup>1</sup>with switch port assignment in place, scenario 1 means the new node simply boots up by default and becomes the new `node022` without further intervention

**Avoiding duplicate IP addresses:** The node-installer brings up all the network interfaces configured for the node. Before starting each interface, the node-installer first checks if the IP address that is about to be used is not already in use by another device. If it is, then a warning and retry dialog is displayed until the IP address conflict is resolved.

**Using `BOOTIF` to specify the boot interface:** `BOOTIF` is a special name for one of the possible interfaces. The node-installer automatically translates `BOOTIF` into the name of the device, such as `eth0` or `eth1`, used for network booting. This is useful for a machine with multiple network interfaces where it can be unclear whether to specify, for example, `eth0` or `eth1` for the interface that was used for booting. Using the name `BOOTIF` instead means that the underlying device, `eth0` or `eth1` in this example, does not need to be specified in the first place.

**Halting on missing kernel modules for the interface:** For some interface types like VLAN and channel bonding, the node-installer halts if the required kernel modules are not loaded or are loaded with the wrong module options. In this case the kernel modules configuration for the relevant software image should be reviewed. Recreating the ramdisk and rebooting the node to get the interfaces up again may be necessary, as described in section 5.8.5.

### Bringing Up Non-Provisioning Network Interfaces

Provisioning interfaces are by default automatically brought up during the init stage, as the node is fully booted up. The BMC and non-provisioning interfaces on the other hand have a different behavior:

**Bringing Up And Initializing BMC Interfaces:** If a BMC interface is present and powered up, then it is expected to be running at least with layer 2 activity (ethernet). It can be initialized in the node configuration (section 3.7) with an IP address, netmask and user/password settings so that layer 3 (TCP/IP) networking works for it. BMC networking runs independently of node networking.

**Bringing up non-BMC, non-provisioning network interfaces:** Non-provisioning interfaces are inactive unless they are explicitly brought up. Bright Cluster Manager can configure how these non-provisioning interfaces are brought up by using the `bringupduringinstall` parameter, which can take the following values:

- `yes`: Brings the interface up during the pre-init stage
- `no`: Keeps the interface down during the pre-init stage. This is the default for non-provisioning interfaces.
- `yesandkeep`: Brings the interface up during the pre-init stage, and keeps it up during the transition to the init stage.

### Bringing Up And Keeping Up Provisioning Network Interfaces

The preceding `bringupduringinstall` parameter is not generally supported for provisioning interfaces. However the `yesandkeep` value does work for provisioning interfaces too, under some conditions:

- `yesandkeep`: Brings the interface up during the pre-init stage, and keeps it up during the transition to the init stage, for the following provisioning devices:
  - Ethernet device interfaces using a leased DHCP address
  - InfiniBand device interfaces running with distribution OFED stacks

### Restarting The Network Interfaces

At the end of this step (i.e. section 5.4.3) the network interfaces are up. When the node-installer has completed the remainder of its 13 steps (sections 5.4.4–5.4.13), control is handed over to the local `init` process running on the local drive. During this handover, the node-installer brings down all network devices. These are then brought back up again by `init` by the distribution's standard networking `init` scripts, which run from the local drive and expect networking devices to be down to begin with.

### 5.4.4 Determining Install-mode Type And Execution Mode

Stored *install-mode* values decide whether synchronization is to be applied fully to the local drive of the node, only for some parts of its filesystem, not at all, or even whether to drop into a maintenance mode instead.

Related to install-mode values are execution mode values (page 157) that determine whether to apply the install-mode values to the next boot, to new nodes only, to individual nodes or to a category of nodes.

Related to execution mode values is the confirmation requirement toggle value (page 159) in case a full installation is to take place.

These values are merely determined at this stage; nothing is executed yet.

#### Install-mode Values

The install-mode can have one of four values: `AUTO`, `FULL`, `MAIN` and `NOSYNC`. It should be understood that the term “install-mode” implies that these values operate only during the node-installer phase.<sup>2</sup>

- If the install-mode is set to `FULL`, the node-installer re-partitions, creates new filesystems and synchronizes a full image onto the local drive according a *partition layout*. This process wipes out all pre-boot drive content.

A partition layout (Appendix D) includes defined values for the partitions, sizes, and filesystem types for the nodes being installed. An example of a partition layout is the default partition layout (Appendix D.3).

- If the install-mode is set to `AUTO`, the node-installer checks the partition layout of the local drive against the node's stored configuration. If these do not match because, for example, the node is new, or if they are corrupted, then the node-installer recreates the partitions and filesystems by carrying out a `FULL` install. If however the drive partitions and filesystems are healthy, the node-installer only does an incremental software image synchronization. Synchronization tends to be quick because the software image and the local drive usually do not differ much.

Synchronization also removes any extra local files that do not exist on the image, for the files and directories considered. Section 5.4.7 gives details on how it is decided what files and directories are considered.

- If the install-mode is set to `MAIN`, the node-installer halts in maintenance mode, allowing manual investigation of specific problems. The local drive is untouched.
- If the install-mode is set to `NOSYNC`, and the partition layout check matches the stored XML configuration, then the node-installer skips synchronizing the image to the node, so that contents on the local drive persist from the previous boot. An exception to this is the node certificate and key, that is the files `/cm/local/apps/cmd/etc/cert.{pem|key}`. These are updated from the head node if missing.

If however the partition layout does not match the stored configuration, a `FULL` image sync is triggered. Thus, for example, a burn session (Chapter 8 of the *Installation Manual*), with the default

<sup>2</sup>For example, `imageupdate` (section 5.6.2), which is run by `CMDaemon`, ignores these settings, which is as expected. This means that, for example, if `imageupdate` is run with `NOSYNC` set, then the head node image is still synchronized over as usual to the regular node while the node is up. It is only during node boot, during the installer stage, that setting `NOSYNC` prevents synchronization.

burn configuration which destroys the existing partition layout on a node, will trigger a FULL image sync on reboot after the burn session.

The NOSYNC setting should therefore not be regarded as a way to protect data. Ways to preserve data across node reboots are discussed in the section that discusses the FULL install confirmation settings (page 159).

NOSYNC is useful during mass planned node reboots when set with the `nextinstallmode` option of device mode. This sets the nodes to be provisioned, during the next boot only, without an image sync:

### Example

```
[bright80]% device foreach -n node001..node999 (set nextinstallmode nosync)
[bright80]% device commit
```

### Install-mode Logging

The decision that is made is normally logged to the node-installer file, `/var/log/node-installer` on the head node.

### Example

```
08:40:58 node001 node-installer: Installmode is: AUTO
08:40:58 node001 node-installer: Fetching disks setup.
08:40:58 node001 node-installer: Setting up environment for initialize scripts.
08:40:58 node001 node-installer: Initialize script for category default is empty.
08:40:59 node001 node-installer: Checking partitions and filesystems.
08:40:59 node001 node-installer: Updating device status: checking disks
08:40:59 node001 node-installer: Detecting device '/dev/sda': found
08:41:00 node001 node-installer: Number of partitions on sda is ok.
08:41:00 node001 node-installer: Size for /dev/sda1 is ok.
08:41:00 node001 node-installer: Checking if /dev/sda1 contains ext3 filesystem.
08:41:01 node001 node-installer: fsck.ext3 -a /dev/sda1
08:41:01 node001 node-installer: /dev/sda1: recovering journal
08:41:02 node001 node-installer: /dev/sda1: clean, 129522/1250928 files, 886932/5000000 blocks
08:41:02 node001 node-installer: Filesystem check on /dev/sda1 is ok.
08:41:02 node001 node-installer: Size for /dev/sda2 is wrong.
08:41:02 node001 node-installer: Partitions and/or filesystems are missing/corrupt. (Exit code\
18, signal 0)
08:41:03 node001 node-installer: Creating new disk layout.
```

In this case the node-installer detects that the size of `/dev/sda2` on the disk no longer matches the stored configuration, and triggers a full re-install. For further detail beyond that given by the node-installer log, the `disks` script at `/cm/node-installer/scripts/disks` on the head node can be examined. The node-installer checks the disk by calling the `disks` script. Exit codes, such as the 18 reported in the log example, are defined near the top of the `disks` script.

### Install-mode's Execution Modes

Execution of an install-mode setting is possible in several ways, both permanently or just temporarily for the next boot. Execution can be set to apply to categories or individual nodes. The node-installer looks for install-mode execution settings in this order:

1. The "New node `installmode`" property of the node's category. This decides the install mode for a node that is detected to be new.

It can be set for the default category using a clickpath such as:

Grouping→Node categories[default]→Edit→Settings→Install mode

or using `cmsh` with a one-liner such as:

```
cmsh -c "category use default; set newnodeinstallmode FULL; commit"
```

By default, the “New node installmode” property is set to FULL.

2. The Install-mode setting as set by choosing a PXE menu option on the console of the node before it loads the kernel and ramdisk (figure 5.14). This only affects the current boot. By default the PXE menu install mode option is set to AUTO.



Figure 5.14: PXE Menu With Install-mode Set To AUTO

3. The “Next boot install-mode” property of the node configuration. This can be set for a node such as node001 using a clickpath such as:

Devices→Physical Nodes[node001]→Edit→Settings→Install mode

It can also be set using cmsh with a one-liner like:

```
cmsh -c "device use node001; set nextinstallmode FULL; commit"
```

The property is cleared when the node starts up again, after the node-installer finishes its installation tasks. So it is empty unless specifically set by the administrator during the current uptime for the node.

4. The install-mode property can be set in the node configuration using Bright View via Devices→Physical Nodes[node001]→Edit→Settings→Install mode or using cmsh with a one-liner such as:

```
cmsh -c "device use node001; set installmode FULL; commit"
```



By default, the `install-mode` property is auto-linked to the property set for `install-mode` for that category of node. Since the property for that node's category defaults to `AUTO`, the property for the `install-mode` of the node configuration defaults to "`AUTO (Category)`".

5. The `install-mode` property of the node's category. This can be set using Bright View with a clickpath such as:

Grouping→Node categories[default]→Edit→Settings→Install mode

or using `cmsh` with a one-liner such as:

```
cmsh -c "category use default; set installmode FULL; commit"
```

As already mentioned in a previous point, the `install-mode` is set by default to `AUTO`.

6. A dialog on the console of the node (figure 5.15) gives the user a last opportunity to overrule the `install-mode` value as determined by the node-installer. By default, it is set to `AUTO`:




Figure 5.15: Install-mode Setting Option During Node-Installer Run

#### FULL Install Confirmation via `datanode` Setting

Related to execution mode values is the ability to carry out a `FULL` install only after explicit confirmation. This must be set in order to prompt for a confirmation, when a `FULL` installation is about to take place. If it is set, then the node-installer only goes ahead with the `FULL` install after the administrator has explicitly confirmed it.

The property can be set in the node configuration of, for example, `node001` with Bright View via the clickpath

Devices→Physical Nodes[`node001`]→Edit→Settings→Data node[Enabled]

Alternatively, the parameter `datanode` can be set using a `cmsh` one-liner as follows:

```
[root@bright80 ]# cmsh -c "device use node001; set datanode yes; commit"
```

The property can also be set at a category or other levels.

**Why the FULL install confirmation is useful:** The reason for such a setting is that a FULL installation can be triggered by disk or partition changes, or by a change in the MAC address. If that happens, then:

- considering a drive, say, `/dev/sda` that fails, this means that any drive `/dev/sdb` would then normally become `/dev/sda` upon reboot. In that case an unwanted FULL install would not only be triggered by an install-mode settings of FULL, but also by the install-mode settings of AUTO or NOSYNC. Having the new, “accidental” `/dev/sda` have a FULL install is unlikely to be the intention, since it would probably contain useful data that the node-installer earlier left untouched.
- considering a node with a new MAC address, but with local storage containing useful data from earlier. In this case, too, an unwanted FULL install would not only be triggered by an install-mode setting of FULL, but also by the install-mode settings AUTO or NOSYNC.

Thus, in cases where nodes are used to store data, an explicit confirmation before overwriting local storage contents is a good idea. However, by default, no confirmation is asked for when a FULL installation is about to take place.

**Carrying out the confirmation:** When the confirmation is required, then it can be carried out by the administrator as follows:

- From the node console. A remote console launched from `cmsh` will also work.
- From `cmsh`, within device mode, using the `installerinteractions` command (some output elided):

### Example

```
[bright80->device]% installerinteractions -w -n node001 --confirm
Hostname  Action
-----
node001   Requesting FULL Install (partition mismatch)
[bright80->device]%
...07:57:36 [notice] bright80: node001 [ INSTALLER_CALLINGINIT ]...
[bright80->device]%
...07:58:20 [notice] bright80: node001 [   UP   ]
```

Besides confirmation, the `installerinteractions` command has options that include letting it:

- deny the installation, and put it into maintenance mode
- carry out a dry-run
- carry out its actions for node groupings such as: node lists, node categories, node groups, chassis, racks.

Further details on the command can be viewed by running `help installerinteractions`.

**An alternative way to avoid overwriting node storage:** There is an alternative method to prevent data loss on nodes due to a FULL install. The alternative does not require setting `datanode`. Instead, it uses XML assertions to confirm that the physical drive is recognized (Appendix D.11).

**A way to overwrite a specified block device:** A related method is that sometimes, for reasons of performance or convenience, it may be desirable to clear data on particular block devices for a node, and carry it out during the next boot only. This can be done by setting the block device names to be cleared as values to the parameter `Block devices cleared on next boot`. The values can be set in `cmsh` as follows:

```
[bright80->device[node001]]% append blockdevicesclearedonnextboot /dev/sda /dev/sdb ; commit
```

The value of `blockdevicesclearedonnextboot` is automatically cleared after the node is re-booted.

#### 5.4.5 Running Initialize Scripts

An *initialize script* is used when custom commands need to be executed before checking partitions and mounting devices (section 3.15.4). For example, to initialize some not explicitly supported hardware, or to do a RAID configuration lookup for a particular node. In such cases the custom commands are added to an initialize script. How to edit an initialize script is described in Appendix E.2.

An initialize script can be added to both a node's category and the node configuration. The node-installer first runs an initialize script, if it exists, from the node's category, and then an initialize script, if it exists, from the node's configuration.

The node-installer sets several environment variables which can be used by the initialize script. Appendix E contains an example script documenting these variables.

Related to the initialize script is the *finalize script* (section 5.4.11). This may run after node provisioning is done, but just before the `init` process on the node runs.

#### 5.4.6 Checking Partitions, RAID Configuration, Mounting Filesystems

##### Behavior As Decided By The Install-Mode Value

In section 5.4.4 the node-installer determines the install-mode value, along with when to apply it to a node.

**AUTO:** The install-mode value is typically set to default to `AUTO`. If `AUTO` applies to the current node, it means the node-installer then checks the partitions of the local drive and its filesystems and recreates them in case of errors. Partitions are checked by comparing the partition layout of the local drive(s) against the drive layout as configured in the node's category configuration and the node configuration.

After the node-installer checks the drive(s) and, if required, recreates the layout, it mounts all filesystems to allow the drive contents to be synchronized with the contents of the software image.

**FULL or MAIN:** If install-mode values of `FULL` or `MAIN` apply to the current node instead, then no partition checking or filesystem checking is done by the node-installer.

**NOSYNC:** If the install-mode value of `NOSYNC` applies, then if the partition and filesystem checks both show no errors, the node starts up without getting an image synced to it from the provisioning node. If the partition or the filesystem check show errors, then the node partition is rewritten, and a known good image is synced across.

##### Behavior As Decided By XML Configuration Settings

The node-installer is capable of creating advanced drive layouts, including LVM setups, and hardware and software RAID setups. Drive layout examples and relevant documentation are in Appendix D.

The XML description used to set the drive layouts can be deployed for a single device or to a category of devices.

**Hardware RAID:** Bright Cluster Manager supports hardware RAID levels 0, 1, 5, 10, and 50, and supports the following options:

Option	
• <b>stripe size:</b>	64kB
	128kB
	256kB
	512kB
	1024kB

Option	
• <b>cache policy:</b>	Cached
	Direct

Option		Description
• <b>read policy:</b>	NORA	No Read Ahead
	RA	Read Ahead
	ADRA	Adaptive Read

Option		Description
• <b>write policy:</b>	WT	Write Through
	WB	Write Back

### 5.4.7 Synchronizing The Local Drive With The Software Image

After having mounted the local filesystems, these can be synchronized with the contents of the software image associated with the node (through its category). Synchronization is skipped if `NOSYNC` is set, and takes place if install-mode values of `FULL` or `AUTO` are set. Synchronization is delegated by the node-installer to the CMDaemon provisioning system. The node-installer just sends a provisioning request to CMDaemon on the head node.

For an install-mode of `FULL`, or for an install-mode of `AUTO` where the local filesystem is detected as being corrupted, full provisioning is done. For an install-mode of `AUTO` where the local filesystem is healthy and agrees with that of the software image, sync provisioning is done.

The software image that is requested is available to nodes by default. It can however be set to a `locked` state, which means that the request is held in the queue until it is no longer in a `locked` state. This is sometimes useful for making changes to an image when nodes are booting.

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% softwareimage use default-image
[bright80->softwareimage[default-image]]% set locked yes
[bright80->softwareimage*[default-image*]]% commit
```

For an unlocked image, on receiving the provisioning request, CMDaemon assigns the provisioning task to one of the provisioning nodes. The node-installer is notified when image synchronization starts, and also when the image synchronization task ends—whether it is completed successfully or not.

**Exclude Lists:** `excludelistsyncinstall` And `excludelistfullinstall`

What files are synchronized is decided by an *exclude list*. An exclude list is a property of the node category, and is a list of directories and files that are excluded from consideration during synchronization. The excluded list that is used is decided by the type of synchronization chosen: `full` or `sync`:

- A `full` type of synchronization rewrites the partition table of the node, then copies the filesystem from a software image to the node, using a list to specify files and directories to exclude from consideration when copying over the filesystem. The list of exclusions used is specified by the `excludelistfullinstall` property.

The intention of `full` synchronization is to allow a complete working filesystem to be copied over from a known good software image to the node. By default the `excludelistfullinstall` list contains `/proc/`, `/sys/`, and `lost+found/`, which have no content in Bright Cluster Manager's default software image. The list can be modified to suit the requirements of a cluster, but it is recommended to have the list adhere to the principle of allowing a complete working node filesystem to be copied over from a known good software image.

- A `sync` type of synchronization uses the property `excludelistsyncinstall` to specify what files and directories to exclude from consideration when copying parts of the filesystem from a known good software image to the node. The `excludelistsyncinstall` property is in the form of a list of exclusions, or more accurately in the form of two sub-lists.

The contents of the sub-lists specify the parts of the filesystem that should be retained or not copied over from the software image during `sync` synchronization when the node is booting. The intention behind this is to have the node boot up quickly, updating only the files from the image to the node that need updating due to the reboot of the node, and otherwise keeping files that are already on the node hard disk unchanged. The contents of the sub-lists are thus items such as the node log files, or items such as the `/proc` and `/sys` pseudo-fileSYSTEMS which are generated during node boot.

The administrator should be aware that nothing on a node hard drive can be regarded as persistent because a FULL sync takes place if any error is noticed during a partition or filesystem check.

Anything already on the node that matches the content of these sub-lists is not overwritten by image content during an `excludelistsyncinstall` sync. However, image content that is not on the node is copied over to the node only for items matching the first sub-list. The remaining files and directories on the node, that is, the ones that are not in the sub-lists, lose their original contents, and are copied over from the software image.

A `cmsh` one-liner to get an exclude list for a category is:

```
cmsh -c "category use default; get excludelistfullinstall"
```

Similarly, to set the list:

```
cmsh -c "category use default; set excludelistfullinstall; commit"
```

where a text-editor opens up to allow changes to be made to the list. In Bright View the clickpath is:

```
Grouping→Node Categories→Edit→Node Category→Settings→Exclude list full install
```

Image synchronization is done using `rsync`, and the syntax of the items in the exclude lists conforms to the "INCLUDE/EXCLUDE PATTERN RULES" section of the `rsync(1)` man page, which includes patterns such as `"**"`, `"?"`, and `"[:alpha:]"`.

The `excludelistfullinstall` and `excludelistsyncinstall` properties decide how a node synchronizes to an image during boot. For a node that is already fully up, the related `excludelistupdate` property decides how a running node synchronizes to an image without a reboot event, and is discussed in section 5.6.

**Interface Used To Receive Image Data:** `provisioninginterface`

For regular nodes with multiple interfaces, one interface may be faster than the others. If so, it can be convenient to receive the image data via the fastest interface. Setting the value of `provisioninginterface`, which is a property of the node configuration, allows this.

By default it is set to `BOOTIF` for regular nodes. Using `BOOTIF` is not recommended for node configurations with multiple interfaces.

When listing the network interfaces in `cmsh`, the provisioning interface has a `[prov]` flag appended to its name.

**Example**

```
[bright80->device[node001]->interfaces]% list
Type          Network device name  IP              Network
-----
physical      BOOTIF [prov]         10.141.0.1      internalnet
physical      eth1                  10.141.1.1      internalnet
physical      eth2                  10.141.2.1      internalnet
```

**Head nodes and `provisioninginterface`:** A head node in a single-head cluster does not use the `provisioninginterface` setting.

Head nodes in a failover configuration (Chapter 15), however, do have a value set for `provisioninginterface`, corresponding to the interface on the head that is being provisioned over `internalnet` by the other head (`eth0` in figure 15.1).

**Transport Protocol Used For Image Data:** `provisioningtransport`

The `provisioningtransport` property of the node sets whether the image data is sent encrypted or unencrypted to the node from the provisioner. The property value is set via the device mode for the receiving node to one of these values:

- `rsyncdaemon`, which sends the data unencrypted
- `rsyncssh`, which sends the data encrypted

The `provisioningtransport` value can be set for all nodes, including provisioning nodes, head nodes, and cloud-director (section 3.2 of the *Cloudbursting Manual*) nodes. Because encryption severely increases the load on the provisioning node, using `rsyncssh` is only suggested if the users on the network cannot be trusted. By default, `provisioningtransport` is set to `rsyncdaemon`. If high availability (chapter 15) is set up with the head nodes exposed to the outside world on the external network, the administrator should consider setting up `rsyncssh` for the head nodes.

The `rsyncssh` transport requires passwordless root access via `ssh` from the provisioner to the node being provisioned. This is configured by default in the default Bright Cluster Manager nodes. However, if a new image is created with the `--exclude` options for `cm-create-image` as explained in (section 11.6.2), the keys must be copied over from `/root/.ssh/` on the existing nodes.

**Tracking The Status Of Image Data Provisioning:** `provisioningstatus`

The `provisioningstatus` command within the `softwareimage` mode of `cmsh` displays an updated state of the provisioning system. As a one-liner, it can be run as:

```
bright80:~ # cmsh -c "softwareimage provisioningstatus"
Provisioning subsystem status:      idle, accepting requests
Update of provisioning nodes requested: no
Maximum number of nodes provisioning: 10000
Nodes currently provisioning:      0
Nodes waiting to be provisioned:    <none>
Provisioning node bright80:
```

```

Max number of provisioning nodes:      10
Nodes provisioning:                    0
Nodes currently being provisioned:     <none>

```

The `provisioningstatus` command has several options that allow the requests to be tracked. The `-r` option displays the basic status information on provisioning requests, while the `-a` option displays all status information on provisioning requests. Both of these options display the request IDs.

The Bright View equivalent to `provisioningstatus` is accessed via the clickpath:

Provisioning→Provisioning nodes

By default, it displays basic status information on provisioning requests.

#### Tracking The Provisioning Log Changes: `synclog`

For a closer look into the image file changes carried out during provisioning requests, the `synclog` command from device mode can be used (lines elided in the following output):

#### Example

```

[bright80->device]% synclog node001
Tue, 11 Jan 2011 13:27:17 CET - Starting rsync daemon based provisioning. Mode is SYNC.

sending incremental file list
./
...
deleting var/lib/ntp/etc/localtime
var/lib/ntp/var/run/ntp/
...
sent 2258383 bytes  received 6989 bytes  156232.55 bytes/sec
total size is 1797091769  speedup is 793.29

Tue, 11 Jan 2011 13:27:31 CET - Rsync completed.

```

#### Aborting Provisioning With `cancelprovisioningrequest`

The `cancelprovisioningrequest` command cancels provisioning.

Its usage is:

```
cancelprovisioningrequest [OPTIONS] [<requestid> ...]
```

To cancel all provisioning requests, it can be run as:

```
bright80:~ # cmsh -c "softwareimage cancelprovisioningrequest -a"
```

The `provisioningstatus` command of `cmsh` can be used to find request IDs. Individual request IDs, for example 10 and 13, can then be specified in the `cancelprovisioningrequest` command, as:

```
bright80:~ # cmsh -c "softwareimage cancelprovisioningrequest 10 13"
```

The help page for `cancelprovisioningrequest` shows how to run the command on node ranges, groups, categories, racks, and chassis.

#### 5.4.8 Writing Network Configuration Files

In the previous section, the local drive of the node is synchronized according to install-mode settings with the software image from the provisioning node. The node-installer now sets up configuration files for each configured network interface. These are files like:

```
/etc/sysconfig/network-scripts/ifcfg-eth0
```

for Red Hat, Scientific Linux, and CentOS, while SUSE would use:

```
/etc/sysconfig/network/ifcfg-eth0
```

These files are placed on the local drive.

When the node-installer finishes its remaining tasks (sections 5.4.9–5.4.13) it brings down all network devices and hands over control to the local `/sbin/init` process. Eventually a local `init` script uses the network configuration files to bring the interfaces back up.

#### 5.4.9 Creating A Local `/etc/fstab` File

The `/etc/fstab` file on the local drive contains local partitions on which filesystems are mounted as the `init` process runs. The actual drive layout is configured in the category configuration or the node configuration, so the node-installer is able to generate and place a valid local `/etc/fstab` file. In addition to all the mount points defined in the drive layout, several extra mount points can be added. These extra mount points, such as NFS imports, `/proc`, `/sys` and `/dev/shm`, can be defined and managed in the node's category and in the specific configuration of the node configuration, using Bright View or `cmsh` (section 3.10.2).

#### 5.4.10 Installing GRUB Bootloader

By default, a node-installer boots from the software image on the head node via the network.

Optionally, the node-installer installs a boot record on the local drive if the `installbootrecord` property of the node configuration or node category is set to `on`, so that the next boot can be from the local drive.

For a hard drive boot to work:

1. hard drive booting must be set to have a higher priority than network booting in the BIOS of the node. Otherwise regular PXE booting occurs, despite whatever value `installbootrecord` has.
2. the GRUB bootloader with a boot record must be installed in the MBR of the local drive, overwriting the default iPXE boot record.

If the administrator is not using the default software image, but is using a custom software image (section 11.6.1), and if the image is based on a running node filesystem that has not been built directly from a parent distribution, then the GRUB boot configuration may not be appropriate for a standalone GRUB boot to work. This is because the parent distribution installers often use special logic for setting up the GRUB boot configuration. Carrying out this same special logic for all distributions using the custom software image creation tool `cm-create-image` (section 11.6.2) is impractical.

Providing a custom working image from a standalone node that has been customized after direct installation from the parent distribution, ensures the GRUB boot configuration layout of the custom image is as expected by the parent distribution. This then allows a standalone GRUB boot on the node to run properly.

With a working custom software image, to set the GRUB bootloader in Bright View, the `Install boot record` option must be enabled and saved in the node configuration or in the node category.

The `cmsh` equivalents are commands like:

```
cmsh -c "device use node001; set installbootrecord yes; commit"
```

or

```
cmsh -c "category use default; set installbootrecord yes; commit"
```

Arranging for the two items in the preceding list ensures that the next boot is from GRUB on the hard drive. However, the `BOOTIF` needs to be changed for booting to be successful. How it can be changed, and why it needs to be changed, is described next.



### Changing BOOTIF To Ensure The Node Can Be Standalone

If the BIOS is set to boot from the hard drive, and the boot record has been installed as in the previous two items, then the node boots via the boot record on the hard drive.

BOOTIF is the default value for the network interface for a node that is configured as a Bright software image. However, the BOOTIF interface is undefined during hard drive booting, because it depends on the network provisioning setup, which is not running. This means that the networking interface would fail during hard drive boot for a standard image. To remedy this, the interface should be set to a defined network device name, such as `eth0`, or the modern equivalents such as `en01` (section 5.8.1). The defined network device name, as the kernel sees it, can be found by logging into the node and taking a look at the output of `ip link`:

#### Example

```
[root@bright80 ~]# ssh node001 ip link
1: lo: <LOOPBACK,UP,LOWER_UP> mtu 65536 qdisc noqueue...
2: eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc ...
```

In Bright Cluster Manager the provisioning interface is mandatory, even if it is not provisioning. So it is set to the value of kernel-defined network device name instead of BOOTIF:

#### Example

```
[bright80]% device interfaces node001
[bright80->device[node001]->interfaces]% list
Type          Network device name  IP          Network
-----
physical      BOOTIF [prov]           10.141.0.1  internalnet
[bright80->device[node001]->interfaces]% set bootif networkdevicename eth0
[bright80->device*[node001*]->interfaces*]% commit
[bright80->device[node001]->interfaces]% list
Type          Network device name  IP          Network
-----
physical      eth0 [prov]           10.141.0.1  internalnet
Tue Mar 31 13:46:44 2020 [notice] bright80: node001 [  UP  ], restart required (eth0)
```

In the preceding example, the kernel-defined network device name is assumed to be `eth0`. It should be modified as required.

In addition, the new IP address is assumed to be on the same internal network. If the administrator intends the node to be standalone on another network, then the network and the IP address can be set to appropriate values.

When interface changes are carried out to make the node standalone, warnings show up saying that a reboot is required. A reboot of the node should be done when the interface configuration is complete.

During reboot, the node then boots from the hard drive as a standalone, with a non-BOOTIF network interface.

### Bringing A Node That Boots From Its Hard Drive Back Into A Cluster

If the node is to be brought back into the cluster, then simply unsetting “Install boot record” and rebooting the node does not restore its iPXE boot record and hence its ability to iPXE boot. To restore the iPXE boot record, the node can be booted from the default image copy on the head node via a network boot again. Typically this is done by manual intervention during node boot to select network booting from the BIOS of the node.

Setting the value of `provisioninginterface` in `cmsh` for the node to `BOOTIF` is also recommended.

As suggested by the Bright Cluster Manager iPXE boot prompt, setting network booting to work from the BIOS (regular “PXE” booting) is preferred to the relatively roundabout way of iPXE booting from the disk.

### SELinux Initialization For Hard Drive Boot And PXE Boot

If configured, SELinux (Chapter 9 of the *Installation Manual*) is initialized at this point. For a boot from the hard drive, the initialization occurs if an SELinux filesystem has been saved to disk previously. For a PXE boot, the initialization takes place if the `SELinuxInitialize` directive is set to `true` in the `node-installer.conf` file.

#### 5.4.11 Running Finalize Scripts

A *finalize script* is similar to an *initialize script* (section 5.4.5), only it runs a few stages later in the node-provisioning process.

In the context of configuration (section 3.15.4) it is used when custom commands need to be executed after the preceding mounting, provisioning, and housekeeping steps, but before handing over control to the node's local `init` process. For example, custom commands may be needed to:

- initialize some not explicitly supported hardware before `init` takes over
- supply a configuration file for the software image that cannot simply be added to the software image and used by `init` because it needs node-specific settings
- load a slightly altered standard software image on particular nodes, typically with the change depending on automatically detecting the hardware of the node it is being loaded onto. While this could also be done by creating a full new software image and loading it on to the nodes according to the hardware, it usually turns out to be better for simplicity's sake (future maintainability) to minimize the number of software images for the cluster.

The custom commands used to implement such changes are then added to the *finalize script*. How to edit a *finalize script* is described in Appendix E.2.

A *finalize script* can be added to both a node's category and the node configuration. The node-installer first runs a *finalize script*, if it exists, from the node's category, and then a *finalize script*, if it exists, from the node's configuration.

The node-installer sets several environment variables which can be used by the *finalize script*. Appendix E contains an example script which documents these variables.

#### 5.4.12 Unloading Specific Drivers

Many kernel drivers are only required during the installation of the node. After installation they are not needed and can degrade node performance.

Baseboard Management Controllers (BMCs, section 3.7) that use IPMI drivers are an egregious example of this. The IPMI drivers are required to have the node-installer configure the IP address of any IPMI cards. Once the node is configured, these drivers are no longer needed, but they continue to consume significant CPU cycles and power if they stay loaded, which can affect job performance.

To solve this, the node-installer can be configured to unload a specified set of drivers just before it hands over control to the local `init` process. This is done by editing the `removeModulesBeforeInit` setting in the node-installer configuration file `/cm/node-installer/scripts/node-installer.conf`. By default, the IPMI drivers are placed in the `removeModulesBeforeInit` setting.

To pick up IPMI-related data values, IPMI access is then carried out over the network without the drivers.

#### 5.4.13 Switching To The Local `init` Process

At this point the node-installer is done. The node's local drive now contains a complete Linux installation and is ready to be started. The node-installer hands over control to the local `/sbin/init` process, which continues the boot process and starts all runlevel services. From here on the boot process continues as if the machine was started from the drive just like any other regular Linux machine.

## 5.5 Node States

During the boot process, several state change messages are sent to the head node CMDaemon or detected by polling from the head node CMDaemon. The most important node states for a cluster after boot up are introduced in section 2.1.1. These states are described again, along with some less common ones to give a more complete picture of node states.

### 5.5.1 Node States Icons In Bright View

In the node icons used by Bright View :

- Nodes in the UP state are indicated by an up-arrow.
  - If all health checks (section 12.2.4) for the node are successful, the up-arrow is green.
  - If there is a health check that fails or if the node requires a reboot, the up-arrow is red.
- Nodes in the DOWN state are indicated by a blue down-arrow.

### 5.5.2 Node States Shown In `cmsh`

In `cmsh`, the node state can be found using the `status` command from device mode for a node:

#### Example

```
[bright80->device]% status -n node001..node002
node001 ..... [  UP  ] restart-required, health check failed
node002 ..... [ DOWN ] (hostname changed) restart-required
```

Devices in general can have their states conveniently listed with the `list -f` (page 27) command:

#### Example

```
[bright80->device]% list -f "hostname:10, status:48"
hostname ( status
-----
apc01      [  UP  ]
bright80   [  UP  ]
devhp      [  UP  ]
node001    [  UP  ] restart-required, health check failed
node002    [ DOWN ] (hostname changed) restart-required
```

The reason for a red icon as shown in section 5.5.1 can be found within the parentheses. In this example it is (hostname changed).

### 5.5.3 Node States Indicating Regular Start Up

During a successful boot process the node goes through the following states:

- **INSTALLING.** This state is normally entered as soon as the node-installer has determined on which node the node-installer is running. Within this state, information messages display indicating what is being done while the node is in the **INSTALLING** state. Possible messages under the status column for the node within `cmsh` are normally, in sequence:
  1. node-installer started
  2. Optionally, the following two messages:
    - (a) waiting for user input
    - (b) installation was resumed
  3. checking disks

4. recreating partitions and filesystems
5. mounting disks
6. One of these following two messages:
  - (a) waiting for FULL provisioning to start
  - (b) waiting for SYNC provisioning to start
7. provisioning started, waiting for completion
8. provisioning complete
9. initializing SELinux

Between steps 1 and 3 in the preceding, these optional messages can also show up:

- If burn mode is entered or left:
  - running burn-in tests
  - burn-in test completed successfully
- If maintenance mode is entered:
  - entered maintenance mode
- INSTALLER\_CALLINGINIT. This state is entered as soon as the node-installer has handed over control to the local `init` process. The associated message normally seen with it in `cmsh` is:
  - switching to local root
- UP. This state is entered as soon as the CMDaemon of the node connects to the head node CMDaemon.

#### 5.5.4 Node States That May Indicate Problems

Other node states are often associated with problems in the boot process:

- DOWN. This state is registered as soon as the CMDaemon on the regular node is no longer detected by CMDaemon on the head node. In this state, the state of the regular node is still tracked, so that CMDaemon is aware if the node state changes.
- CLOSED. This state is appended to the UP or DOWN state of the regular node by the administrator, and causes most CMDaemon monitoring actions for the node to cease. The state of the node is however still tracked by default, so that CMDaemon is aware if the node state changes.

The CLOSED state can be set from the device mode of `cmsh` using the `close` command. The help text for the command gives details on how it can be applied to categories, groups and so on. The `-m` option sets a message by the administrator for the closed node or nodes.

#### Example

```
root@b52 ~]# cmsh
[b52]% device
[b52->device]% close -m "fan dead" -n node001,node009,node020
Mon May 2 16:32:01 [notice] b52: node001 ...[ DOWN/CLOSED ] (fan dead)
Mon May 2 16:32:01 [notice] b52: node009 ...[ DOWN/CLOSED ] (fan dead)
Mon May 2 16:32:01 [notice] b52: node020 ...[ DOWN/CLOSED ] (fan dead)
```

When the CLOSED state is set for a device, CMDaemon commands can still attempt to act upon it. For example, in the device mode of `cmsh`:

- `open`: This is the converse to the `close` command. It has the same options, including the `-m` option that logs a message. It also has the following extra options:
  - \* `--reset`: Resets whatever the status is of the `devicestatus` check. However, this reset by itself does not solve any underlying issue. The issue may still require a fix, despite the status having been reset.  
For example, the `--reset` option can be used to reset the restart-required flag (section 5.5.2). However, the reason that set the restart-required flag is not solved by the reset. Restarts are required for regular nodes if there have been changes in the following: network settings, disk setup, software image, or category.
  - \* `-f|--failbeforetdown <count>`: Specifies the number of failed pings before a device is marked as down (default is 1).
- `drain` and `undrain` (Appendix G.3.1)
- For nodes that have power control<sup>3</sup>:
  - \* `power -f on`
  - \* `power -f off`
  - \* `power -f reset`

In Bright View, the `Drain` and `Undrain` menu items can be accessed, for a node `node001` for example, via the clickpath:

Devices→Physical Nodes[node001]→Edit→Settings→Actions→Workload→Drain/Undrain.

CMDaemon on the head node only maintains device monitoring logs for a device that is in the `UP` state. If the device is in a state other than `UP`, then CMDaemon only tracks its state, and can display the state if queried.

For example: if a node displays the state `UP` when queried about its state, and is given a ‘close’ command, it then goes into a `CLOSED` state. Querying the node state then displays the state `UP/CLOSED`. It remains in that `CLOSED` state when the node is powered down. Querying the node state after being powered down displays `DOWN/CLOSED`. Next, powering up the node from that state, and having it go through the boot process, has the node displaying various `CLOSED` states during queries. Typically the query responses show it transitioning from `DOWN/CLOSED`, to `INSTALLING/CLOSED`, to `INSTALLER_CALLINGINIT/CLOSED`, and ending up displaying the `UP/CLOSED` state.

Thus, a node set to a `CLOSED` state remains in a `CLOSED` state regardless of whether the node is in an `UP` or `DOWN` state. The only way out of a `CLOSED` state is for the administrator to tell the node to open via the `cmsh` “open” option discussed earlier. The node, as far as CMDaemon is concerned, then switches from the `CLOSED` state to the `OPEN` state. Whether the node listens or not does not matter—the head node records it as being in an `OPENING` state for a short time, and during this time the next `OPEN` state (`UP/OPEN`, `DOWN/OPEN`, etc) is agreed upon by the head node and the node.

When querying the state of a node, an `OPEN` tag is not displayed in the response, because it is the “standard” state. For example, `UP` is displayed rather than `UP/OPEN`. In contrast, a `CLOSED` tag is displayed when it is active, because it is a “special” state.

The `CLOSED` state is normally set to take a node that is unhealthy out of the cluster management system. The node can then still be in the `UP` state, displaying `UP/CLOSED`. It can even continue running workload jobs in this state, since workload managers run independent of CMDaemon. So, if the workload manager is still running, the jobs themselves are still handled by the workload manager, even if CMDaemon is no longer aware of the node state until the node is re-opened. For this reason, draining a node is often done before closing a node, although it is not obligatory.

<sup>3</sup>power control mechanisms such as PDUs, BMCs using IPMI/HP iLO, and custom power scripts are described in Chapter 4

- **OPENING.** This transitional state is entered as soon as the CMDaemon of the node rescinds the **CLOSED** state with an “open” command from `cmsh`. The state usually lasts no more than about 5 seconds, and never more than 30 seconds in the default configuration settings of Bright Cluster Manager. The help text for the `open` command of `cmsh` gives details on its options.
- **INSTALLER\_FAILED.** This state is entered from the **INSTALLING** state when the node-installer has detected an unrecoverable problem during the boot process. For instance, it cannot find the local drive, or a network interface cannot be started. This state can also be entered from the **INSTALLER\_CALLINGINIT** state when the node takes too long to enter the **UP** state. This could indicate that handing over control to the local `init` process failed, or the local `init` process was not able to start the CMDaemon on the node. Lastly, this state can be entered when the previous state was **INSTALLER\_REBOOTING** and the reboot takes too long.
- **INSTALLER\_UNREACHABLE.** This state is entered from the **INSTALLING** state when the head node CMDaemon can no longer ping the node. It could indicate the node has crashed while running the node-installer.
- **INSTALLER\_REBOOTING.** In some cases the node-installer has to reboot the node to load the correct kernel. Before rebooting it sets this state. If the subsequent reboot takes too long, the head node CMDaemon sets the state to **INSTALLER\_FAILED**.

## 5.6 Updating Running Nodes

Changes made to the contents of the software image for nodes, kept on the head node, become a part of any other provisioning nodes according to the housekeeping system on the head node (section 5.2.4).

Thus, when a regular node reboots, the latest image is installed from the provisioning system onto the regular node via a provisioning request (section 5.4.7).

However, updating a running node with the latest software image changes is also possible without rebooting it. Such an update can be requested using `cmsh` or Bright View, and is queued and delegated to a provisioning node, just like a regular provisioning request. The properties that apply to the regular provisioning an image also apply to such an update. For example, the value of the `provisioninginterface` setting (section 5.4.7) on the node being updated determines which interface is used to receive the image. In `cmsh` the request is submitted with the `imageupdate` option (section 5.6.2), while in Bright View, it is submitted, for a node `node001` for example, using the click-path:

Devices→Physical Nodes[`node001`]→Edit→Settings→Actions→Software image→Update node (section 5.6.3). The `imageupdate` command and “Update node” menu option use a configuration file called `excludelistupdate`, which is, as its name suggests, a list of exclusions to the update.

The `imageupdate` command and “Update node” button update what is on a running node from a stored image. The converse, that is, to update a stored image from what is on a running node, can be also be carried out. This converse can be viewed as grabbing from a node and synchronizing what is grabbed to an image. It can be done using `grabimage` (`cmsh`), or `Synchronize` (Bright View), and involves further exclude lists `excludelistgrab` or `excludelistgrabnew`. The `grabimage` command and `Synchronize` option are covered in detail in section 11.5.2.

### 5.6.1 Updating Running Nodes: Configuration With `excludelistupdate`

The exclude list `excludelistupdate` used by the `imageupdate` command is defined as a property of the node’s category. It has the same structure and `rsync` patterns syntax as that used by the exclude lists for provisioning the nodes during installation (section 5.4.7).

### Distinguishing Between The Intention Behind The Various Exclude Lists

The administrator should note that it is the `excludelistupdate` list that is being discussed here, in contrast with the `excludelistsyncinstall/excludelistfullinstall` lists which are discussed in section 5.4.7, and also in contrast with the `excludelistgrab/excludelistgrabnew` lists of section 11.5.2.

So, for the `imageupdate` command the `excludelistupdate` list concerns an *update* to a running system, while for installation `sync` or `full` provisioning, the corresponding exclude lists (`excludelistsyncinstall` and `excludelistfullinstall`) from section 5.4.7 are about an *install* during node start-up. Because the copying intention during updates is to be speedy, the `imageupdate` command synchronizes files rather than unnecessarily overwriting unchanged files. Thus, the `excludelistupdate` exclusion list it uses is actually analogous to the `excludelistsyncinstall` exclusion list used in the `sync` case of section 5.4.7, rather than being analogous to the `excludelistfullinstall` list.

Similarly, the `excludelistgrab/excludelistgrabnew` lists of section 11.5.2 are about a *grab* from the running node to the image.

- The `excludelistgrab` list here is intended for the case of synchronizing the existing image with the running node, and is thus analogous to the `excludelistsyncinstall` exclusion list.
- The `excludelistgrabnew` list here is intended for the case of copying a full image from the running node, and is thus analogous to the `excludelistfullinstall` list.

The following table summarizes this:

During:	Exclude list used is:	Copy intention:
update	<code>excludelistupdate</code>	sync, image to running node
install	<code>excludelistfullinstall</code>	full, image to starting node
	<code>excludelistsyncinstall</code>	sync, image to starting node
grab	<code>excludelistgrabnew</code>	full, running node to image
	<code>excludelistgrab</code>	sync, running node to image

The preceding table is rather terse. It may help to understand it if is expanded with some in-place footnotes, where the footnotes indicate what actions can cause the use of the exclude lists:

During:	Exclude list used is:	Copy intention:
update eg: <code>imageupdate</code>	<code>excludelistupdate</code>	sync, image to running node
install eg: node-provisioning process during pre- init stage depending on <code>installmode</code> decision	<code>excludelistfullinstall</code> eg: node provisioning with <code>installmode FULL</code>  <code>excludelistsyncinstall</code> eg: node provisioning AUTO with healthy partition	full, image to starting node    sync, image to starting node
grab eg: <code>grabimage (cmsh),</code> Synchronize to image (Bright View), and Grab to image (Bright View)	<code>excludelistgrabnew</code> <code>grabimage -i/Grab</code> to image  <code>excludelistgrab</code> <code>grabimage/Synchronize</code> image	full, running node to image   sync, running node to image

#### The Exclude List Logic For `excludelistupdate`

During an `imageupdate` command, the synchronization process uses the `excludelistupdate` list, which is a list of files and directories. One of the cross checking actions that may run during the synchronization is that the items on the list are excluded when copying parts of the filesystem from a known good software image to the node. The detailed behavior is as follows:

The `excludelistupdate` list is in the form of two sublists. Both sublists are lists of paths, except that the second sublist is prefixed with the text `"no-new-files: "` (without the double quotes). For the node being updated, all of its files are looked at during an `imageupdate` synchronization run. During such a run, the logic that is followed is:

- if an excluded path from `excludelistupdate` exists on the node, then nothing from that path is copied over from the software image to the node
- if an excluded path from `excludelistupdate` does not exist on the node, then
  - if the path is on the first, non-prefixed list, then the path is copied over from the software image to the node.
  - if the path is on the second, prefixed list, then the path is not copied over from the software image to the node. That is, no new files are copied over, like the prefix text implies.

This is illustrated by figure 5.16.






Figure 5.16: Exclude list logic

The files and directories on the node that are not in the sub-lists lose their original contents, and are copied over from the software image. So, content not covered by the sub-lists at that time is normally not protected from deletion.

Thus, the provisioning system excludes paths described according to the `excludelistupdate` property.

The provisioning system also excludes a statically-imported filesystem on a node if the filesystem is a member of the following special list: NFS, Lustre, FUSE, CephFS, CIFS, PanFS, FhGFS, BeeGFS, GlusterFS, or GPFS. If this exclusion were not done, then all data on these imported filesystems would

be wiped, since they are not part of the software image. The automatic exclusion for these imported filesystems does not rely on the `excludelist` values maintained by `CMDaemon`—instead, `CMDaemon` carries out the check on-the-fly when provisioning starts.

Statically-imported filesystems that have their mounts managed by Bright Cluster Manager via the `fsmounts` mode can be excluded from being mounted on the nodes in the first place, by removing them from the listed mounts within the `fsmounts` mode.

Imported filesystems not on the special list can have their data wiped out during provisioning or sync updates, if the statically-imported filesystems are placed in the image manually—that is, if the filesystems are mounted manually into the image on the head node via `/etc/fstab` without using `cmsh` or Bright View.

**Filesystems mounted dynamically, that is, with an auto-mounter cannot have their appearance or disappearance detected reliably.** Any filesystem that may be imported via an auto-mount operation must therefore explicitly be excluded by the administrator manually adding the filesystem to the exclude list. This is to prevent an incorrect execution of `imageupdate`. Neglecting to do this may wipe out the filesystem, if it happens to be mounted in the middle of an `imageupdate` operation.

### Editing An Exclude List

A sample `cmsh` one-liner which opens up a text editor in a category so that the exclude list for updates can be edited is:

```
cmsh -c "category use default; set excludelistupdate; commit"
```

Similarly, the exclude list for updates can also be edited in Bright View via the clickpath:

```
Grouping→Node categories[default-image]→Settings→Exclude list update
```

### Provisioning Modifications Via `excludelistmanipulatescript`

Sometimes the administrator has a need to slightly modify the execution of exclude lists during provisioning. The `excludelistmanipulatescript` file takes as an input the exclude list inherited from a category, modifies it in some way, and then produces a new exclude list. Conceptually it is a bit like how an administrator might use `sed` if it worked without a pipe. As usual, setting it for node level overrides the category level.

A script that manipulates the exclude lists of a node can be specified as follows within `cmsh`:

```
[bright80]% device use node001
[bright80->device[node001]]% set excludelistmanipulatescript
(a vi session will start. A script is edited and saved)
[bright80->device[node001*]]% commit
```

The script can be as simple as:

### Example

```
#!/bin/bash

echo "- *"
echo 'no-new-files: - *'
```

If provisioning a node from the head node, then the script modifies the node-provisioning exclude lists—`excludelistfullinstall`, `excludelistsyncinstall`, and `excludelistupdate`—so that they appear to contain these items only:

```
- *
no-new-files: - *
```

The provisioning node then excludes everything during provisioning.

Careful editing and testing of the script is advised. Saving a script with just a single whitespace, for example, usually has undesirable results.

A more useful script template is the following:

### Example

```
#!/bin/bash

while read; do
    echo "$REPLY"
done

echo "# This and next line added by category excludelistmanipulatescript."
echo "# The command line arguments were: $@"
```

The provisioning exclude lists are simply read in, then sent out again without any change, except that the last two lines add comment lines to the exclude lists that are to be used.

Internally, the arguments taken by the `excludelistmanipulatescript` are the destination path and the sync mode (one of `install|update|full|grab|grabnew`). This can be seen in the output of `$@`, if running an `imageupdate` command to execute a dry run with the preceding example:

```
[bright80]% device use node001
[bright80->device[node001]]% get excludelistmanipulatescript
  (the script is put in)
[bright80->device[node001*]]% commit; imageupdate
Performing dry run (use synclog command to review result, then pass -w to perform real update)...
Wed Apr 15 04:55:46 2015 [notice] bright80: Provisioning started: sendi\
ng bright80:/cm/images/default-image to node001:/, mode UPDATE, dry run\
= yes, no data changes!
[bright80->device[node001]]%
Wed Apr 15 04:55:51 2015 [notice] bright80: Provisioning completed: sen\
t bright80:/cm/images/default-image to node001:/, mode UPDATE, dry run \
= yes, no data changes!
imageupdate [ COMPLETED ]
```

An excerpt from the sync log, after running the `synclog` command, then shows output similar to (some output elided):

```
...
- /cm/shared/*
- /cm/shared/
- /home/*
- /home/
- /cm/shared/apps/torque/*
- /cm/shared/apps/torque/
# This and next line added by category excludelistmanipulatescript.
# The command line arguments were: update /
```

```
Rsync output:
sending incremental file list
cm/local/apps/cmd/scripts/healthchecks/configfiles/
...
```

Here, the sync mode is `update` and the destination path is `"/`. Which of the exclude lists is being modified can be determined by the `excludelistmanipulatescript` by parsing the sync mode.

The bash variable that accepts the exclude list text is set to a safely-marked form using curly braces. This is done to avoid expansion surprises, due to wild card characters in the exclude lists. For example, if `$REPLY` were used instead of `${REPLY}`, and the script were to accept an exclude list line containing `"- /proc/*"`, then it would give quite confusing output.

Two further exclude list files that modify standard provisioning behavior are `excludelistfailover` and `excludelistnormal`. These are discussed in section 15.4.8.

### 5.6.2 Updating Running Nodes: With `cmsh` Using `imageupdate`

Using a defined `excludelistupdate` property (section 5.6.1), the `imageupdate` command of `cmsh` is used to start an update on a running node:

#### Example

```
[bright80->device]% imageupdate -n node001
Performing dry run (use synclog command to review result, then pass -w to perform real update)...
Tue Jan 11 12:13:33 2011 bright80: Provisioning started on node node001
[bright80->device]% imageupdate -n node001: image update in progress ...
[bright80->device]%
Tue Jan 11 12:13:44 2011 bright80: Provisioning completed on node node001
```

By default the `imageupdate` command performs a dry run, which means no data on the node is actually written. Before passing the `"-w"` switch, it is recommended to analyze the `rsync` output using the `synclog` command (section 5.4.7).

If the user is now satisfied with the changes that are to be made, the `imageupdate` command is invoked again with the `"-w"` switch to implement them:

#### Example

```
[bright80->device]% imageupdate -n node001 -w
Provisioning started on node node001
node001: image update in progress ...
[bright80->device]% Provisioning completed on node node001
```

### 5.6.3 Updating Running Nodes: With Bright View Using the `Update node` Option

In Bright View, an image update can be carried out by selecting the specific node or category, for example `node001`, and updating it via the clickpath:

```
Devices→Physical Nodes[node001]→Edit→Settings→Actions→Software image→Update node
```

### 5.6.4 Updating Running Nodes: Considerations

Updating an image via `cmsh` or Bright View automatically updates the provisioners first via the `updateprovisioners` command (section 5.2.4) if the provisioners have not been updated in the last 5 minutes. The conditional update period can be set with the `provisioningnodeautoupdatetimetypeout` parameter (section 5.2.4).

So, with the default setting of 5 minutes, if there has been an update within the last 5 minutes, then provisioners do not get an updated image when doing the updates. Running the `updateprovisioners` command just before running the `imageupdate` command therefore usually makes sense.

Also, when updating services, the services on the nodes may not restart since the `init` process may not notice the replacement.

For these reasons, especially for more extensive changes, it can be safer for the administrator to simply reboot the nodes instead of using `imageupdate` to provision the images to the nodes. A reboot by default ensures that a node places the latest image with an `AUTO` install (section 5.4.7), and restarts all services.

The `Reinstall node` option, which can be run, for example, on a node `node001`, using a clickpath of `Devices→Physical Nodes[node001]→Edit→Settings→Actions→Software image→Reinstall node` also does the same as a reboot with default settings, except for that it unconditionally places the latest image with a `FULL` install, and so may take longer to complete.

## 5.7 Adding New Nodes

How the administrator can add a single node to a cluster is described in section 1.3 of the *Installation Manual*. This section explains how nodes can be added in ways that are more convenient for larger numbers of nodes.

### 5.7.1 Adding New Nodes With `cmsh` And Bright View Add Functions

Node objects can be added from within the device mode of `cmsh` by running the `add` command:

#### Example

```
[bright80->device]% add physicalnode node002 10.141.0.2
[bright80->device*[node002*]% commit
```

The Bright View equivalent of this is following the clickpath:

`Devices→Physical Nodes→Add→Settings→Hostname`  
then adding the value `node002` to `Hostname`, and saving it.

When adding the node objects in `cmsh` and Bright View, some values (IP addresses for example) may need to be filled in before the object validates. For regular nodes, there should be an interface and an IP address for the network that it boots from, as well as for the network that manages the nodes. A regular node typically has only one interface, which means that the same interface provides boot and management services. This interface is then the boot interface, `BOOTIF`, during the pre-init stage, but is also the management interface, typically `eth0` or whatever the device is called, after the pre-init stage. The IP address for `BOOTIF` is normally provided via `DHCP`, while the IP address for the management interface is set to a static IP address that is set via `cmsh` or Bright View by the administrator.

Adding new node objects as “placeholders” can also be done from `cmsh` or Bright View. By placeholders, here it is meant that an incomplete node object is set. For example, sometimes it is useful to create a node object with the MAC address setting unfilled because it is still unknown. Why this can be useful is covered shortly.

## 5.8 Troubleshooting The Node Boot Process

During the node boot process there are several common issues that can lead to an unsuccessful boot. This section describes these issues and their solutions. It also provides general hints on how to analyze boot problems.

### 5.8.1 Node Fails To PXE Boot

Possible reasons to consider if a node is not even starting to PXE boot in the first place:

- `DHCP` may not be running. A check can be done to confirm that `DHCP` is running on the internal network interface (usually `eth0`):

```
[root@bright80 ~]# ps u -C dhcpd
USER PID %CPU %MEM VSZ  RSS TTY STAT START TIME COMMAND
root 2448 0.0 0.0 11208 436 ?    Ss   Jan22 0:05 /usr/sbin/dhcpd eth0
```

This may indicate that `Node booting` is disabled in Bright View (figure 3.5, page 53) and needs to be enabled. The equivalent in `cmsh` is to check if the response to:

```
cmsh -c "network use internalnet; get nodebooting"
```

needs to be set to `yes`.

- The DHCP daemon may be “locked down” (section 3.2.1, figure 3.5, table 3.2.1). New nodes are granted leases only if `lockdowndhcpd` is set to `no` in `cmsh`, or `Lock down dhcpd` is disabled in Bright View for the network.
- A rogue DHCP server may be running. If there are all sorts of other machines on the network the nodes are on, then it is possible that there is a rogue DHCP server active on it, perhaps on an IP address that the administrator has forgotten, and interfering with the expected PXE booting. Such stray DHCP servers should be eliminated.

In such a case, removing all the connections and switches and just connecting the head node directly to a problem node, NIC-to-NIC, should allow a normal PXE boot to happen. If a normal PXE boot then does happen, it indicates the problem is indeed due to a rogue DHCP server on the more-connected network.

- The boot sequence may be set wrongly in the BIOS. The boot interface should normally be set to be the first boot item in the BIOS.
- There may a bad cable connection. This can be due to moving the machine, or heat creep, or another physical connection problem. Firmly inserting the cable into its slot may help. Replacing the cable or interface as appropriate may be required.
- There may a problem with the switch. Removing the switch and connecting a head node and a regular node directly with a cable can help troubleshoot this.

Disabling the Spanning Tree Protocol (STP) functions of a managed switch is recommended.

- The cable may be connected to the wrong interface. By default, `eth0` is normally assigned the internal network interface, and `eth1` the external network interface on the head node for a type 1 network. However:
  - The two interfaces can be confused when physically viewing them and a connection to the wrong interface can therefore be made.
  - It is also possible that the administrator has changed the default assignment.
  - If the node is booting from iPXE (that is from a hard drive), for the very first time, and there is more than one interface on the node, then the interface assignment is not guaranteed in Red Hat and derivatives before version 7.

The node running a version before RHEL7 can therefore end up unable to pick up the provisioning image from the interface that is in use for provisioning. Moving the provisioning cable to the correct interface on the node at this very first boot resolves this issue.

### Interface Naming Conventions Post-RHEL7

The documentation at:

[https://access.redhat.com/documentation/en-US/Red\\_Hat\\_Enterprise\\_Linux/7/html/Networking\\_Guide/ch-Consistent\\_Network\\_Device\\_Naming.html](https://access.redhat.com/documentation/en-US/Red_Hat_Enterprise_Linux/7/html/Networking_Guide/ch-Consistent_Network_Device_Naming.html)

describes the persistent naming convention for interfaces in RHEL7. This convention sets an interface assignment on iPXE boot for multiple interfaces that is also valid by default during the very first iPXE boot. This means that an administrator can know which interface is used for provisioning and can connect the provisioning cable accordingly.

### Reverting To The Pre-RHEL7 Interface Naming Conventions

To revert to the pre-RHEL7 behavior, the text:

```
net.ifnames=0 biosdevname=0
```

can be appended to the line starting with `GRUB_CMDLINE_LINUX` in `/etc/default/grub` within the head node. For this:

- \* The `biosdevname` parameter only works if the dev helper is installed. The dev helper is available from the `biosdevname` RPM package. The parameter also requires that the system supports SMBIOS 2.6 or ACPI DSM.
- \* The `net.ifnames` parameter is needed if `biosdevname` is not installed.

### Example

```
GRUB_CMDLINE_LINUX="rd.lvm.lv=centos/swap vconsole.keymap=us \
crashkernel=auto rd.lvm.lv=centos/root vconsole.font=latarcyr\
heb-sun16 rhgb quiet net.ifnames=0 biosdevname=0"
```

A cautious system administrator may back up the original `grub.cfg` file:

```
[root@bright80 ~]# cp --preserve /boot/grub2/grub.cfg /boot/grub2/grub.cfg.orig
```

The GRUB configuration should be generated with:

```
[root@bright80 ~]# grub2-mkconfig -o /boot/grub2/grub.cfg
```

For a regular node, the text `net.ifnames=0 biosdevname=0` can be appended to the `kernelparameters` property, for an image selected from `softwareimage` mode.

### Example

```
[bright80->softwareimage]% list
Name (key)          Path
-----
default-image       /cm/images/default-image
openstack-image     /cm/images/openstack-image
[bright80->softwareimage]% use default-image
[bright80->softwareimage[default-image]]% append kernelparameters " net.ifnames=0 biosdevname=0"
[bright80->softwareimage*[default-image*]]% commit
```

The `append` command requires a space at the start of the quote, in order to separate the kernel parameters from any pre-existing ones.

The connections should be checked to eliminate these possibilities.

- The TFTP server that sends out the image may have hung. During a normal run, an output similar to this appears when an image is in the process of being served:

```
[root@bright80 ~]# ps ax | grep [t]ftp
7512 ?        Ss          0:03 in.tftpd --maxthread 500 /tftpboot
```

If the TFTP server is in a zombie state, the head node should be rebooted. If the TFTP service hangs regularly, there is likely a networking hardware issue that requires resolution.

Incidentally, grepping the process list for a TFTP service returns nothing when the head node is listening for TFTP requests, but not actively serving a TFTP image. This is because the TFTP service runs under `xinet.d` and is called on demand. Running

```
[root@bright80 ~]# chkconfig --list
```

should include in its output the line:

```
tftp:      on
```

if TFTP is running under xinet.d.

- The xinetd server on the head node that manages the TFTP service in RHEL6 may be hung. If so, then it should be restarted.
- The switchover process from TFTP to HTTP may have hung. During a normal provisioning run, assuming that CMDaemon uses the default AdvancedConfig setting of PXEBootOverHTTP=1 (Appendix C), TFTP is used to load the initial boot loader, but the kernel and ramdisk are loaded up via HTTP for speed. Some hardware has problems with switching over to using HTTP.

In that case, setting PXEBootOverHTTP=0 keeps the node using TFTP for loading the kernel and ramdisk, and should work. Another possible way to solve this is to upgrade the PXE boot BIOS to a version that does not have this problem.

- Sometimes a manufacturer releases hardware with buggy drivers that have a variety of problems. For instance: Ethernet frames may be detected at the interface (for example, by `ethtool`), but TCP/IP packets may not be detected (for example, by `wireshark`). In that case, the manufacturer should be contacted to upgrade their driver.
- The interface may have a hardware failure. In that case, the interface should be replaced.

### 5.8.2 Node-installer Logging

If the node manages to get beyond the PXE stage to the node-installer stage, then the first place to look for hints on node boot failure is usually the node-installer log file. The node-installer runs on the node that is being provisioned, and sends logging output to the syslog daemon running on that node. This forwards all log data to the IP address from which the node received its DHCP lease, which is typically the IP address of the head node or failover node. In a default Bright Cluster Manager setup, the `local5` facility of the syslog daemon is used on the node that is being provisioned to forward all node-installer messages to the log file `/var/log/node-installer` on the head node.

After the node-installer has finished running, its log is also stored in `/var/log/node-installer` on the regular nodes.

If there is no node-installer log file anywhere yet, then it is possible that the node-installer is not yet deployed on the node. Sometimes this is due to a system administrator having forgotten to change a provisioning-related configuration setting. One possibility is that the `nodegroups` setting (section 5.2.1), if used, may be misconfigured. Another possibility is that the image was set to a `locked` state (section 5.4.7). The `provisioningstatus -a` command can indicate this:

#### Example

```
[bright80->softwareimage]% provisioningstatus -a | grep locked
Scheduler info:  requested software image is locked, request deferred
```

To get the image to install properly, the `locked` state should be removed for a locked image.

#### Example

```
[root@bright80 ~]# cmsh -c "softwareimage foreach * (get name; get locked)"
default-image
yes
[root@bright80 ~]# cmsh -c "softwareimage; foreach * (set locked no); commit"
[root@bright80 ~]# cmsh -c "softwareimage foreach * (get name; get locked)"
default-image
no
```



The node automatically picks up the image after it is unlocked.

Optionally, extra log information can be written by enabling debug logging, which sets the syslog importance level at `LOG_DEBUG`. To enable debug logging, the `debug` field is changed in `/cm/node-installer/scripts/node-installer.conf`.

From the console of the booting node the log file is generally accessible by pressing `Alt+F7` on the keyboard. Debug logging is however excluded from being viewed in this way, due to the output volume making this impractical.

A booting node console can be accessed remotely if Serial Over LAN (SOL) is enabled (section 13.7), to allow the viewing of console messages directly. A further depth in logging can be achieved by setting the kernel option `loglevel=N`, where `N` is a number from 0 (`KERN_EMERG`) to 7 (`KERN_DEBUG`).

### 5.8.3 Provisioning Logging

The provisioning system sends log information to the CMDaemon log file. By default this is in `/var/log/cmdaemon` on the local host, that is, the provisioning host. The host this log runs on can be configured with the CMDaemon directive `SyslogHost` (Appendix C).

The image synchronization log file can be retrieved with the `synclog` command running from device mode in `cmsh`. Hints on provisioning problems are often found by looking at the tail end of the log.

If the tail end of the log shows an `rsync` exit code of 23, then it suggests a transfer error. Sometimes the cause of the error can be determined by examining the file or filesystem for which the error occurs.

### 5.8.4 Ramdisk Fails During Loading Or Sometime Later

One issue that may come up after a software image update via `yum`, `zypper`, or `apt-get` (section 11.4), is that the ramdisk stage may fail during loading or sometime later, for a node that is rebooted after the update. This occurs if there are instructions to modify the ramdisk by the update. In a normal machine the ramdisk would be regenerated. In a cluster, the extended ramdisk that is used requires an update, but Bright Cluster Manager is not aware of this. Running the `createramdisk` command from `cmsh` (section 5.3.2) generates an updated ramdisk for the cluster, and solves the failure for this case.

### 5.8.5 Ramdisk Cannot Start Network

The ramdisk must activate the node's network interface in order to fetch the node-installer. To activate the network device, the correct kernel module needs to be loaded. If this does not happen, booting fails, and the console of the node displays something similar to figure 5.17.

```

Creating initial device nodes
Setting up hotplug.
Creating block device nodes.
Loading ehci-hcd.ko module
Loading ohci-hcd.ko module
Loading uhci-hcd.ko module
Loading jbd.ko module
Loading ext3.ko module
Loading sunrpc.ko module
Loading nfs_acl.ko module
Loading fscache.ko module
Loading lockd.ko module
Loading nfs.ko module
Loading scsi_mod.ko module
Loading sd_mod.ko module
Loading libata.ko module
Loading ahci.ko module
Waiting for driver initialization.
Creating root device.
Finished original ramdisk.
Can't configure the ethernet device used for booting.
You should probably insert the correct kernel module into the ramdisk.
Boot failed.
/bin/sh: can't access tty: job control turned off
#

```

Figure 5.17: No Network Interface

To solve this issue the correct kernel module should be added to the software image's kernel module configuration (section 5.3.2). For example, to add the e1000 module to the default image using `cmsh`:

### Example

```

[mc]% softwareimage use default-image
[mc->softwareimage[default-image]]% kernelmodules
[mc->softwareimage[default-image]->kernelmodules]% add e1000
[mc->softwareimage[default-image]->kernelmodules[e1000]]% commit
Initial ramdisk for image default-image was regenerated successfully
[mc->softwareimage[default-image]->kernelmodules[e1000]]%

```

After committing the change it typically takes about a minute before the initial ramdisk creation is completed via a `mkinitrd` run by `CMDaemon`.

### 5.8.6 Node-Installer Cannot Create Disk Layout

When the node-installer is not able to create a drive layout it displays a message similar to figure 5.18. The node-installer log file (section 5.8.2) contains something like:

```

Mar 24 13:55:31 10.141.0.1 node-installer: Installmode is: AUTO
Mar 24 13:55:31 10.141.0.1 node-installer: Fetching disks setup.
Mar 24 13:55:31 10.141.0.1 node-installer: Checking partitions and
filesystems.
Mar 24 13:55:32 10.141.0.1 node-installer: Detecting device '/dev/sda':
not found
Mar 24 13:55:32 10.141.0.1 node-installer: Detecting device '/dev/hda':
not found
Mar 24 13:55:32 10.141.0.1 node-installer: Can not find device(s) (/dev/sda /dev/hda).
Mar 24 13:55:32 10.141.0.1 node-installer: Partitions and/or filesystems
are missing/corrupt. (Exit code 4, signal 0)
Mar 24 13:55:32 10.141.0.1 node-installer: Creating new disk layout.

```

```
Mar 24 13:55:32 10.141.0.1 node-installer: Detecting device '/dev/sda':  
not found  
Mar 24 13:55:32 10.141.0.1 node-installer: Detecting device '/dev/hda':  
not found  
Mar 24 13:55:32 10.141.0.1 node-installer: Can not find device(s) (/dev/sda /dev/hda).  
Mar 24 13:55:32 10.141.0.1 node-installer: Failed to create disk layout.  
(Exit code 4, signal 0)  
Mar 24 13:55:32 10.141.0.1 node-installer: There was a fatal problem. This node can not be\  
installed until the problem is corrected.
```




Figure 5.18: No Disk

One reason may be that the drive may be disabled in the BIOS. It should be enabled.

Another reason may be that the drive order was changed. This could happen if, for example, a defective motherboard has been replaced. The drive order should be kept the same as it was before a motherboard change.

Another reason may be due to SSDs that have a hardware jumper or toggle switch that sets a drive to read-only mode. A read-only mode drive will typically fail at this point. The drive should be made writeable.

One of the most common reasons is that the correct storage driver is not being loaded. To solve this issue, the correct kernel module should be added to the software image's kernel module configuration (section 5.3.2).

Experienced system administrators work out what drivers may be missing by checking the results of hardware probes. For example, going into the node-installer shell using **Alt-F2**, and then looking at the output of **lspci**, shows a list of hardware detected in the PCI slots and gives the chipset name of the storage controller hardware in this case:

#### Example

```
[<installer> root@node001 ~]# lspci | grep SCSI  
00:10.0 Serial Attached SCSI controller: LSI Logic / Symbios Logic SAS2\  
008 PCI-Express Fusion-MPT SAS-2 [Falcon] (rev 03)
```

The next step is to Google with likely search strings based on that output.

The Linux Kernel Driver DataBase (LKDDb) is a hardware database built from kernel sources that lists driver availability for Linux. It is available at <http://cateee.net/lkddb/>. Using the Google search engine's "site" operator to restrict results to the cateee.net web site only, a likely string to try might be:

### Example

```
SAS2008 site:cateee.net
```

The search result indicates that the `mpt2sas` kernel module needs to be added to the node kernels. A look in the modules directory of the software image shows if it is available:

### Example

```
find /cm/images/default-image/lib/modules/ -name "*mpt2sas*"
```

If it is not available, the driver module must then be obtained. If it is a source file, it will need to be compiled. By default, nodes run on standard distribution kernels, so that only standard procedures need to be followed to compile modules.

If the module is available, it can be added to the default image, by using `cmsh` in `softwareimage` mode to create the associated object. The object is given the same name as the module, i.e. `mp2sas` in this case:

### Example

```
[bright80]% softwareimage use default-image
[bright80->softwareimage[default-image]]% kernelmodules
[bright80->softwareimage[default-image]->kernelmodules]% add mpt2sas
[bright80->softwareimage[default-image]->kernelmodules*[mpt2sas*]]% commit
[bright80->softwareimage[default-image]->kernelmodules[mpt2sas]]%
Thu May 19 16:54:52 2011 [notice] bright80: Initial ramdisk for image de\
fault-image is being generated
[bright80->softwareimage[default-image]->kernelmodules[mpt2sas]]%
Thu May 19 16:55:43 2011 [notice] bright80: Initial ramdisk for image de\
fault-image was regenerated successfully.
[bright80->softwareimage[default-image]->kernelmodules[mpt2sas]]%
```

After committing the change it can take some time before ramdisk creation is completed—typically about a minute, as the example shows. Once the ramdisk is created, the module can be seen in the list displayed from `kernelmodules` mode. On rebooting the node, it should now continue past the disk layout stage.

### 5.8.7 Node-Installer Cannot Start BMC (IPMI/iLO) Interface

In some cases the node-installer is not able to configure a node's BMC interface, and displays an error message similar to figure 5.19.




Figure 5.19: No BMC Interface

Usually the issue can be solved by adding the correct BMC (IPMI/iLO) kernel modules to the software image's kernel module configuration. However, in some cases the node-installer is still not able to configure the BMC interface. If this is the case the BMC probably does not support one of the commands the node-installer uses to set specific settings, or there may be a hardware glitch in the BMC.

#### The `setupBmc` Node-Installer Configuration Setting

To solve this issue, setting up BMC interfaces can be disabled globally by setting the `setupBmc` field in the node-installer configuration file `/cm/node-installer/scripts/node-installer.conf` to `false`. Doing this disables configuration of all BMC interfaces by the node-installer. A custom `finalize` script (Appendix E) can then be used to run the required commands instead.

The `setupBmc` field in the node-installer should not be confused with the `SetupBMC` directive in `cmd.conf` (Appendix C). The former is about enabling the BMC interface, while the latter is about enabling automated passwords to the BMC interface (an interface that must of course be enabled in the first place to work).

#### The `failOnMissingBmc` Node-Installer Configuration Setting

If the kernel modules for the BMC are loaded up correctly, and the BMC is configured, but it is not detected by the node-installer, then the node-installer halts by default. This corresponds to the setting `failOnMissingBmc = true` in the node-installer configuration file `/cm/node-installer/scripts/node-installer.conf`. Toggling this to `false` skips BMC network device detection, and lets the node-installer continue past the BMC detection and configuration stage. This can be convenient, for example, if the BMC is not yet configured and the aim is to get on with setting up the rest of the cluster.

#### The `failOnFailedBmcCommand` Node-Installer Configuration Setting

If a BMC command fails, then the node-installer by default terminates node installation. The idea behind this is to allow the administrator to fix the problem. Sometimes, however, hardware can wrongly signal a failure. That is, it can signal a false failure, as opposed to a true failure.

A common case is the case of `ipmitool`. `ipmitool` is used by Bright Cluster Manager to configure

the BMC. With most hardware vendors it works as expected, signaling success and failure correctly. As per the default behavior: with success, node installation proceeds, while with failure, it terminates.

With certain hardware vendors however `ipmitool` fails with an exit code 1, even though the BMC is properly configured. Again, as per the default behavior: success has node installation proceed, while failure has node installation terminate. Only this time, because the failure signal is incorrect, the termination on failure is also incorrect behavior.

To get around the default behavior for false failure cases, the administrator can force the node-installer to set the value of `failOnFailedBmcCommand` to `false` in the node-installer configuration file `/cm/node-installer/scripts/node-installer.conf`. The installation then skips past the false failure.

### BMC Hardware Glitch And Cold Reset

Sometimes, typically due to a hardware glitch, a BMC can get into a state where it is not providing services, but the BMC is still up (responding to pings). Contrariwise, a BMC may not respond to pings, but still respond to IPMI commands. A fix for such glitchy states is usually to power cycle the BMC. This is typically done, either physically, or by using a BMC management tool such as `ipmitool`.

Physically resetting the power supply to the BMC is done typically by pulling the power cable out and then pushing it in again. For typical rack-based servers the server can just be pulled out and in again. Just doing a shutdown of the server with the power cable still in place normally does not power down the BMC.

BMC management does allow the BMC to power down and be reset from software, without having to physically handle the server. This software-based *cold reset* is a BIOS-manufacturer-dependent feature. A popular tool used for managing BMCs that can do such a cold reset is `ipmitool`. This can be run remotely, but also on the node console if the node cannot be reached remotely.

With `ipmitool`, a cold reset is typically carried out with a command such as:

```
[root@bright80 ~]# module load ipmitool
[root@bright80 ~]# ipmitool -U <bmcusername> -P <bmcpassword> -H <host IP> -I lanplus mc reset cold
```

The values for `<bmcusername>` and `<bmcpassword>` can be obtained as shown in section 3.7.2.

### Other BMC Troubleshooting

Some more specific commands for handling IPMI might be via the `service ipmi <option>` commands, which can show the IPMI service has failed to start up:

#### Example

```
[root@bright80 ~]# service ipmi status
Redirecting to /bin/systemctl status ipmi.service
ipmi.service - IPMI Driver
Loaded: loaded (/usr/lib/systemd/system/ipmi.service; disabled; vendor preset: enabled)
Active: inactive (dead)
```

In the preceding session the driver has simply not been started up. It can be started up with the `start` option:

#### Example

```
[root@bright80 ~]# service ipmi start
Redirecting to /bin/systemctl start ipmi.service
Job for ipmi.service failed because the control process exited with error code. See "systemctl status ipmi.service" and "journalctl -xe" for details.
```

In the preceding session, the start up failed. The service status output shows:

#### Example

```
[root@bright80 ~]# service ipmi status -l
Redirecting to /bin/systemctl status -l ipmi.service
ipmi.service - IPMI Driver
Loaded: loaded (/usr/lib/systemd/system/ipmi.service; disabled; vendor preset: enabled)
Active: failed (Result: exit-code) since Mon 2016-12-19 14:34:27 CET; 2min 3s ago
Process: 8930 ExecStart=/usr/libexec/openipmi-helper start (code=exited, status=1/FAILURE)
Main PID: 8930 (code=exited, status=1/FAILURE)

Dec 19 14:34:27 bright80 systemd[1]: Starting IPMI Driver...
Dec 19 14:34:27 bright80 openipmi-helper[8930]: Startup failed.
Dec 19 14:34:27 bright80 systemd[1]: ipmi.service: main process exited, code=exited, status=1/\
FAILURE
Dec 19 14:34:27 bright80 systemd[1]: Failed to start IPMI Driver.
Dec 19 14:34:27 bright80 systemd[1]: Unit ipmi.service entered failed state.
Dec 19 14:34:27 bright80 systemd[1]: ipmi.service failed.
```

Further details can be found in the journal:

### Example

```
[root@bright80 ~]# journalctl -xe | grep -i ipmi
...
-- Unit ipmi.service has begun starting up.
Dec 19 14:34:27 bright80 kernel: ipmi message handler version 39.2
Dec 19 14:34:27 bright80 kernel: IPMI System Interface driver.
Dec 19 14:34:27 bright80 kernel: ipmi_si: Unable to find any System Interface(s)
Dec 19 14:34:27 bright80 openipmi-helper[8930]: Startup failed.
...
```

In the preceding session, the failure is due to a missing BMC interface (Unable to find any System Interface(s)). A configured BMC interface should show an output status similar to:

### Example

```
[root@bright80 ~]# service ipmi status
Redirecting to /bin/systemctl status ipmi.service
ipmi.service - IPMI Driver
Loaded: loaded (/usr/lib/systemd/system/ipmi.service; disabled; vendor preset: enabled)
Active: active (exited) since Mon 2016-12-19 14:37:10 CET; 2min 0s ago
Process: 61019 ExecStart=/usr/libexec/openipmi-helper start (code=exited, status=0/SUCCESS)
Main PID: 61019 (code=exited, status=0/SUCCESS)
Dec 19 14:37:10 bright80 systemd[1]: Starting IPMI Driver...
Dec 19 14:37:10 bright80 systemd[1]: Started IPMI Driver.
```

Sometimes the issue may be an incorrect networking specification for the BMC interfaces. MAC and IP details that have been set for the BMC interface can be viewed with the `lan print` option to `ipmitool`:

### Example

```
[root@bright80 ~]# module load ipmitool
[root@bright80 ~]# ipmitool lan print
Set in Progress      : Set Complete
Auth Type Support    : MD5 PASSWORD
Auth Type Enable     : Callback : MD5 PASSWORD
                   : User      : MD5 PASSWORD
                   : Operator  : MD5 PASSWORD
```

```

: Admin      : MD5 PASSWORD
: OEM        :
IP Address Source : Static Address
IP Address       : 93.184.216.34
Subnet Mask      : 255.255.255.0
MAC Address      : aa:bb:01:02:cd:ef
SNMP Community String : public
IP Header        : TTL=0x00 Flags=0x00 Precedence=0x00 TOS=0x00
BMC ARP Control  : ARP Responses Enabled, Gratuitous ARP Disabled
Gratuitous ARP Intrvl : 0.0 seconds
Default Gateway IP : 93.184.216.1
Default Gateway MAC : 00:00:00:00:00:00
Backup Gateway IP  : 0.0.0.0
Backup Gateway MAC : 00:00:00:00:00:00
802.1q VLAN ID    : Disabled
802.1q VLAN Priority : 0
RMCP+ Cipher Suites : 0,1,2,3,4,6,7,8,9,11,12,13,15,16,17,18
Cipher Suite Priv Max : caaaaaaaaaaaaaa
: X=Cipher Suite Unused
: c=CALLBACK
: u=USER
: o=OPERATOR
: a=ADMIN
: O=OEM

```

During normal operation the metrics (Appendix G) displayed by Bright Cluster Manager are useful. However, if those are not available for some reason, then the direct output from BMC sensor metrics may be helpful for troubleshooting:

### Example

```

[root@bright80 ~]# module load ipmitool
[root@bright80 ~]# ipmitool sensor list all
# ipmitool sensor list
Ambient Temp | 22.000 | degrees C | ok | na | na | na | 38.000 | 41.000 | 45.000
AVG Power | 300.000 | Watts | ok | na | na | na | na | na | na
Fan 1 Tach | 4125.000 | RPM | ok | na | 750.000 | na | na | na | na
...

```



# 6

## User Management

Users and groups for the cluster are presented to the administrator in a single system paradigm. That is, if the administrator manages them with the Bright Cluster Manager, then the changes are automatically shared across the cluster (the single system).

Bright Cluster Manager runs its own LDAP service to manage users, rather than using unix user and group files. In other words, users and groups are managed via the centralizing LDAP database server running on the head node, and not via entries in `/etc/passwd` or `/etc/group` files.

Sections 6.1 and 6.2 cover the most basic aspects of how to add, remove and edit users and groups using Bright Cluster Manager.

Section 6.3 describes how an external LDAP server can be used for authentication services instead of the one provided by Bright Cluster Manager.

Section 6.4 discusses how users can be assigned only selected capabilities when using Bright View or `cmsh`, using profiles with sets of tokens.

### 6.1 Managing Users And Groups With Bright View

Within Bright View:

- users can be managed via the clickpath `Identity Management→Users`
- groups can be managed via the clickpath `Identity Management→Groups`.

For users (figure 6.1) the LDAP entries for regular users are displayed. These entries are editable and each user can then be managed in further detail.

There is already one user on a newly installed Bright Cluster Manager: `cmsupport`. This user has no password set by default, which means (section 6.2.2) no logins to this account are allowed by default. Bright Cluster Manager uses the user `cmsupport` to run various diagnostics utilities, so it should not be removed, and the default contents of its home directory should not be removed.

There are five buttons, `Revert`, `Add`, `Delete`, `Save`, and `Edit` available in the window:

1. `Add`: allows users to be added via a dialog (figure 6.2). These additions can be committed via the `Save` button.




Figure 6.1: Bright View User Management

The screenshot shows the 'User fred' configuration dialog. It contains various input fields for user details. The 'User name' field is 'fred' and 'User ID' is '1001'. 'Common name' and 'Sur name' are both 'fred'. 'Group ID' is 'fred'. 'Login shell' is '/bin/bash' and 'Home directory' is '/home/fred'. There are fields for 'Password' and 'Confirm'. 'email' is 'email'. 'Profile' is 'none'. At the bottom, there are fields for 'Shadow min' (0), 'Shadow max' (999999), 'Shadow warning' (7), and 'Inactive' (0). 'Last change' is 'Friday, April 21, 2017' and 'Expiration date' is 'Friday, January 1, 2038'. Buttons at the bottom include 'Back', 'Revert', 'Delete', and 'Save'.

Figure 6.2: Bright View User Management: Add Dialog

An explanation of the less obvious items in the dialog follows:

- **Shadow warning:** The number of days, before the password expires, that the user is warned of the expiry
- **Shadow max:** The maximum number of days the password is valid
- **Shadow min:** The minimum number of days required between password changes. A value

of zero means the user may change their password at any time

- **Inactive:** The number of days of inactivity allowed for the user before the account is blocked. A value of zero means the user is never blocked
- **Profile:** The preconfigured capability that the user is assigned. Available settings are:
  - **admin:** Allows the user to run Bright View with the same privileges as user `admin`
  - **cloudjob:** Allows the user to run `cmsub`, the cloud job submission utility (section 4.7 of the *User Manual*, and section 4.4 of the *Cloudbursting Manual*)
  - **portal:** Allows the user to access the user portal
  - **readonly:** Allows the user to run Bright View without the ability to modify settings.
  - **none:** (default). Prevents the user from using Bright View

A profile setting only takes effect if the certificate for the user is used. User certificates are only persistent for a cluster with a permanent license (page 67 of the *Installation Manual*), so the administrator should check the license is not a temporary license before attempting to use this feature. Section 6.4 explains the concepts of capabilities, profiles, certificates, and tokens.

2. **Save:** saves the as-yet-uncommitted **Add** or **Edit** operations. When saving an addition:
  - User and group ID numbers are automatically assigned from UID and GID 1000 onwards. Normally Red Hat and similar distributions assign from 500 onwards, while SUSE assigns from 1000 onwards.
  - A home directory is created and a login shell is set. Users with unset passwords cannot log in.
3. **Edit:** allows user attributes to be modified via a dialog similar to the **Add** dialog of figure 6.2.
4. **Revert:** discards unsaved edits that have been made via the **Edit** button. The reversion goes back to the last save.
5. **Delete:** deletes selected rows of users. By default, their home directories are not deleted.

Group management in Bright View is carried out via the clickpath `Identity Management`→`Groups`. Clickable LDAP object entries for regular groups then show up, similar to the user entries already covered. Management of these entries is done with the same button functions as for user management.

## 6.2 Managing Users And Groups With `cmsh`

User management tasks as carried out by Bright View in section 6.1, can be carried with the same end results in `cmsh` too.

A `cmsh` session is run here in order to cover the functions corresponding to the user management functions of Bright View of section 6.1. These functions are run from within the `user` mode of `cmsh`:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% user
[bright80->user]%
```

### 6.2.1 Adding A User

This part of the session corresponds to the functionality of the **Add** button operation in section 6.1. In user mode, the process of adding a user `maureen` to the LDAP directory is started with the `add` command:

### Example

```
[bright80->user]% add maureen
[bright80->user*[maureen*]]%
```

The `cmsh` utility helpfully drops into the user object just added, and the prompt shows the user name to reflect this. Going into user object would otherwise be done manually by typing `use maureen` at the user mode level.

Asterisks in the prompt are a helpful reminder of a modified state, with each asterisk indicating that there is an unsaved, modified property at that asterisk's level.

The modified command displays a list of modified objects that have not yet been committed:

### Example

```
[bright80->user*[maureen*]]% modified
State  Type                      Name
-----
+      User                      maureen
```

Running `show` at this point reveals a user name entry, but empty fields for the other properties of user `maureen`. So the account in preparation, while it is modified, is clearly not yet ready for use:

### Example

```
[bright80->user*[maureen*]]% show
Parameter                      Value
-----
Common name
Expiration date                2038/1/1
Group ID
Home directory
Inactive                       0
Last change                    1970/1/1
Login shell
Password                       < not set >
Profile
Revision
Shadow max                     999999
Shadow min                     0
Shadow warning                  7
User ID
User name                      maureen
email
```

## 6.2.2 Saving The Modified State

This part of the session corresponds to the functionality of the `Save` button operation in section 6.1.

In section 6.2.1 above, user `maureen` was added. `maureen` now exists as a proposed modification, but has not yet been committed to the LDAP database.

Running the `commit` command now at the `maureen` prompt stores the modified state at the user `maureen` object level:

### Example

```
[bright80->user*[maureen*]]% commit
[bright80->user[maureen]]% show
Parameter                      Value
-----
Common name                    maureen
```

```

Expiration date      2038/1/1
Group ID             1002
Home directory       /home/maureen
Inactive             0
Last change          2011/5/30
Login shell          /bin/bash
Password             *****
Profile
Revision
Shadow max           999999
Shadow min           0
Shadow warning       7
User ID              1002
User name            maureen

```

If, however, `commit` were to be run at the user mode level without dropping into the `maureen` object level, then instead of just that modified user, all modified users would be committed.

When the `commit` is done, all the empty fields for the user are automatically filled in with defaults based the underlying Linux distribution used. Also, as a security precaution, if an empty field (that is, a “not set”) password entry is committed, then a login into the account is not allowed. So, in the example, the account for user `maureen` exists at this stage, but still cannot be logged into until the password is set. Editing passwords and other properties is covered in section 6.2.3.

The default permissions for file and directories under the home directory of the user are defined by the `umask` settings in `/etc/login.defs`, as would be expected if the administrator were to use the standard `useradd` command. Setting a path for the `homedirectory` parameter for a user sets a default home directory path. By default the default path is `/home/<username>` for a user `<username>`. If `homedirectory` is unset, then the default is determined by the `HomeRoot` directive (Appendix C).

### 6.2.3 Editing Properties Of Users And Groups

This corresponds roughly to the functionality of the `Edit` button operation in section 6.1.

In the preceding section 6.2.2, a user account `maureen` was made, with an unset password as one of its properties. Logins to accounts with an unset password are refused. The password therefore needs to be set if the account is to function.

#### Editing Users With `set` And `clear`

The tool used to set user and group properties is the `set` command. Typing `set` and then either using `tab` to see the possible completions, or following it up with the `enter` key, suggests several parameters that can be set, one of which is `password`:

#### Example

```

[bright80->user[maureen]]% set
Name:
    set - Set specific user property

Usage:
    set [user] <parameter> <value> [<value> ...]

Arguments:
    user
        userID of the user, omit if current is set

Parameters:
    Revision ..... Object revision
    commonname ..... Full user name

```

```

email ..... email
expirationdate ..... Indicates the date on which the user login will be disabled
groupid ..... Base group of this user
hadoophdfsaccess .... Home directories on specified Hadoop HDFS
homedirectory ..... Home directory
inactive ..... Indicates the number of days of inactivity allowed for the user
loginshell ..... Login shell
password ..... Password
profile ..... Profile for Authorization
shadowmax ..... Indicates the maximum number of days for which the user password
                  remains valid.
shadowmin ..... Indicates the minimum number of days required between password changes
shadowwarning ..... The number of days of advance warning given to the user before the
                  user password expires
surname ..... Surname
userid ..... User id number
username ..... User name

```

```
[bright80->user[maureen]]%
```

Continuing the session from the end of section 6.2.2, the password can be set at the user context prompt like this:

#### Example

```

[bright80->user[maureen]]% set password seteca5tr0n0my
[bright80->user*[maureen*]]% commit
[bright80->user[maureen]]%

```

At this point, the account `maureen` is finally ready for use.

The converse of the `set` command is the `clear` command, which clears properties:

#### Example

```
[bright80->user[maureen]]% clear password; commit
```

#### Editing Groups With `append` And `removefrom`

While the above commands `set` and `clear` also work with groups, there are two other commands available which suit the special nature of groups. These supplementary commands are `append` and `removefrom`. They are used to add extra users to, and remove extra users from a group.

For example, it may be useful to have a `printer` group so that several users can share access to a printer. For the sake of this example (continuing the session from where it was left off in the preceding), `tim` and `fred` are now added to the LDAP directory, along with a group `printer`:

#### Example

```

[bright80->user[maureen]]% add tim; add fred
[bright80->user*[fred*]]% exit; group; add printer
[bright80->group*[printer*]]% commit
[bright80->group[printer]]% exit; exit; user
[bright80->user*]%

```

The context switch that takes place in the preceding session should be noted: The context of user `maureen` was eventually replaced by the context of group `printer`. As a result, the group `printer` is committed, but the users `tim` and `fred` are not yet committed, which is indicated by the asterisk at the user mode level.

Continuing onwards, to add users to a group the `append` command is used. A list of users `maureen`, `tim` and `fred` can be added to the group `printer` like this:

### Example

```
[bright80->user*]% commit
Successfully committed 2 Users
[bright80->user]% group use printer
[bright80->group[printer]]% append groupmembers maureen tim fred; commit
[bright80->group[printer]]% show
```

Parameter	Value
Group ID	1003
Group members	maureen tim fred
Group name	printer

To remove users from a group, the `removefrom` command is used. A list of specific users, for example, `tim` and `fred`, can be removed from a group like this:

```
[bright80->group[printer]]% removefrom groupmembers tim fred; commit
[bright80->group[printer]]% show
```

Parameter	Value
Group ID	1003
Group members	maureen
Group name	printer

The `clear` command can also be used to clear members—but it also clears all of the extras from the group:

### Example

```
[bright80->group[printer]]% clear groupmembers
[bright80->group*[printer*]]% show
```

Parameter	Value
Group ID	1003
Group members	
Group name	printer

The `commit` command is intentionally left out at this point in the session in order to illustrate how reversion is used in the next section.

## 6.2.4 Reverting To The Unmodified State

This corresponds roughly to the functionality of the `Revert` button operation in section 6.1.

This section (6.2.4) continues on from the state of the session at the end of section 6.2.3. There, the state of group `printers` was cleared so that the extra added members were removed. This state (the state with no group members showing) was however not yet committed.

The `refresh` command reverts an uncommitted object back to the last committed state.

This happens at the level of the object it is using. For example, the object that is being handled here is the properties of the group object `printer`. Running `revert` at a higher level prompt—say, in the group mode level—would revert everything at that level and below. So, in order to affect only the properties of the group object `printer`, the `refresh` command is used at the group object `printer` level prompt. It then reverts the properties of group object `printer` back to their last committed state, and does not affect other objects:

### Example

```
[bright80->group*[printer*]]% refresh
[bright80->group[printer]]% show
Parameter                               Value
-----
Group ID                               1003
Group members                           maureen
Group name                              printer
```

Here, the user `maureen` reappears because she was stored in the last save. Also, because only the group object `printer` has been committed, the asterisk indicates the existence of other uncommitted, modified objects.

### 6.2.5 Removing A User

Removing a user using `cmsh` corresponds roughly to the functionality of the `Delete` button operation in section 6.1.

The `remove` command removes a user or group. The useful `“-d|--data”` flag added to the end of the username removes the user’s home directory too. For example, within `user` mode, the command `“remove user maureen -d; commit”` removes user `maureen`, along with her home directory. Continuing the session at the end of section 6.2.4 from where it was left off, as follows, shows this result:

#### Example

```
[bright80->group[printer]]% user use maureen
[bright80->user[maureen]]% remove -d; commit
Successfully removed 1 Users
Successfully committed 0 Users
[bright80->user]% !ls -d /home/* | grep maureen    #no maureen left behind
[bright80->user]%
```

## 6.3 Using An External LDAP Server

Sometimes, an external LDAP server is used to serve the user database. If, instead of just using the database for authentication, the user database is also to be managed, then its LDAP schema must match the Bright Cluster Manager LDAP schema.

By default, Bright Cluster Manager runs an LDAP health check using the `cmsupport` user on the LDAP server. The LDAP health check may need to be modified or disabled by the administrator to prevent spurious health warnings with an external LDAP server:

### Modifying Or Disabling The `ldap` Healthcheck

**Modifying the `ldap` health check:** To keep a functional `ldap` health check with an external LDAP server, a permanent external LDAP user name, for example `ldapcheck`, can be added. This user can then be set as the parameter for Bright Cluster Manager’s `ldap` health check object that is used to monitor the LDAP service. Health checks and health check objects are discussed in Chapter 12.

- If user management is not configured to work on `CMDaemon` for the external LDAP server, then the user management tool that is used with the external LDAP server should be used by the administrator to create the `ldapcheck` user instead.
- If user management is still being done via `CMDaemon`, then an example session for configuring the `ldap` script object to work with the new external LDAP user is (some prompt text elided):

#### Example



```
[root@bright80 ~]# cmsh
[bright80]% user
[bright80->user]% add ldapcheck; commit
[bright80->user[ldapcheck]]% monitoring setup ldap
[bright80->monitoring->setup[ldap]]% show
Parameter                               Value
-----
Arguments
...
[bright80->monitoring->setup[ldap]]% set arguments "ldapcheck"; commit
[bright80->monitoring->setup[ldap]]%
```

**Disabling the ldap health check:** Instead of modifying the ldap health check to work when using an external LDAP server, it can be disabled entirely via Bright View or cmsh.

- Bright View: the ldap health check is disabled via the clickpath:

```
Monitoring→Data Producers→ldap→Edit
```

- cmsh: the disabled parameter of the ldap health check object is set to yes. The disabled parameter for the ldap health check can be set as follows:

```
[root@bright80 ~]# cmsh -c "monitoring setup use ldap; set disabled yes; commit"
```

### Configuring The Cluster To Authenticate Against An External LDAP Server

The cluster can be configured in different ways to authenticate against an external LDAP server.

For smaller clusters, a configuration where LDAP clients on all nodes point directly to the external server is recommended. An easy way to set this up is as follows:

- On the head node:
  - In distributions that are:
    - \* derived from prior to RHEL 6: the URIs in `/etc/ldap.conf`, and in the image file `/cm/images/default-image/etc/ldap.conf` are set to point to the external LDAP server.
    - \* derived from the RHEL 6.x series: the file `/etc/ldap.conf` does not exist. The files in which the changes then need to be made are `/etc/nslcd.conf` and `/etc/pam_ldap.conf`. To implement the changes, the `nslcd` daemon must then be restarted, for example with `service nslcd restart`.
    - \* derived from RHEL 7.x series: the file `/etc/ldap.conf` does not exist. The files in which the changes then need to be made are `/etc/nslcd.conf` and `/etc/openldap/ldap.conf`. To implement the changes, the `nslcd` daemon must then be restarted, for example with `service nslcd restart`.
  - the `updateprovisioners` command (section 5.2.4) is run to update any other provisioners.
- Then, the configuration files are updated in the software images that the nodes use. If the nodes use the `default-image`, and if the nodes are based on RHEL7 and derivatives, then the files to update are `/cm/images/default-image/etc/nslcd.conf` and `/cm/images/default/etc/openldap/ldap.conf`. After the configuration change has been made, and the nodes have picked up the new configuration, the regular nodes can then carry out LDAP lookups.
  - Nodes can simply be rebooted to pick up the updated configuration, along with the new software image.

- Alternatively, to avoid a reboot, the `imageupdate` command (section 5.6.2) can be run to pick up the new software image from a provisioner.
- The CMDaemon configuration file `cmd.conf` (Appendix C) has LDAP user management directives. These may need to be adjusted:
  - If another LDAP tool is to be used for external LDAP user management instead of `cmsh`, then altering `cmd.conf` is not required, and Bright Cluster Manager’s user management capabilities do nothing in any case.
  - If, however, system users and groups are to be managed via `cmsh`, then CMDaemon, too, must refer to the external LDAP server instead of the default LDAP server. This configuration change is actually rare, because the external LDAP database schema is usually an existing schema generated outside of Bright Cluster Manager, and so it is very unlikely to match the Bright Cluster Manager LDAP database schema. To implement the changes:
    - \* On the node that is to manage the database, which is normally the head node, the `LDAPHost`, `LDAPUser`, `LDAPPass`, and `LDAPSearchDN` directives in `cmd.conf` are changed so that they refer to the external LDAP server.
    - \* CMDaemon is restarted to enable the new configurations.

For larger clusters the preceding solution can cause issues due to traffic, latency, security and connectivity fault tolerance. If such occur, a better solution is to replicate the external LDAP server onto the head node, hence keeping all cluster authentication local, and making the presence of the external LDAP server unnecessary except for updates. This optimization is described in the next section.

### 6.3.1 External LDAP Server Replication

This section explains how to set up replication for an external LDAP server to an LDAP server that is local to the cluster, if improved LDAP services are needed. Section 6.3.2 then explains how this can then be made to work with a high availability setup.

Typically, the Bright Cluster Manager LDAP server is configured as a replica (consumer) to the external LDAP server (provider), with the consumer refreshing its local database at set timed intervals. How the configuration is done varies according to the LDAP server used. The description in this section assumes the provider and consumer both use OpenLDAP.

#### External LDAP Server Replication: Configuring The Provider

It is advisable to back up any configuration files before editing them.

The provider is assumed to be an external LDAP server, and not necessarily part of the Bright Cluster Manager cluster. The LDAP TCP ports 389 and 689 may therefore need to be made accessible between the consumer and the provider by changing firewall settings.

If a provider LDAP server is already configured then the following synchronization directives must be in the `slapd.conf` file to allow replication:

```
index entryCSN eq
index entryUUID eq
overlay syncprov
syncprov-checkpoint <ops> <minutes>
syncprov-sessionlog <size>
```

The `openldap` documentation (<http://www.openldap.org/doc/>) has more on the meanings of these directives. If the values for `<ops>`, `<minutes>`, and `<size>` are not already set, typical values are:

```
syncprov-checkpoint 1000 60
```

and:

```
syncprov-sessionlog 100
```

To allow the consumer to read the provider database, the consumer's access rights need to be configured. In particular, the `userPassword` attribute must be accessible. LDAP servers are often configured to prevent unauthorized users reading the `userPassword` attribute.

Read access to all attributes is available to users with replication privileges. So one way to allow the consumer to read the provider database is to bind it to replication requests.

Sometimes a user for replication requests already exists on the provider, or the root account is used for consumer access. If not, a user for replication access must be configured.

A replication user, `syncuser` with password `secret` can be added to the provider LDAP with adequate rights using the following `syncuser.ldif` file:

```
dn: cn=syncuser,<suffix>
objectClass: person
cn: syncuser
sn: syncuser
userPassword: secret
```

Here, `<suffix>` is the suffix set in `slapd.conf`, which is originally something like `dc=example,dc=com`. The `syncuser` is added using:

```
ldapadd -x -D "cn=root,<suffix>" -W -f syncuser.ldif
```

This prompts for the root password configured in `slapd.conf`.

To verify `syncuser` is in the LDAP database the output of `ldapsearch` can be checked:

```
ldapsearch -x "(sn=syncuser)"
```

To allow access to the `userPassword` attribute for `syncuser` the following lines in `slapd.conf` are changed, from:

```
access to attrs=userPassword
  by self write
  by anonymous auth
  by * none
```

to:

```
access to attrs=userPassword
  by self write
  by dn="cn=syncuser,<suffix>" read
  by anonymous auth
  by * none
```

Provider configuration is now complete and the server can be restarted using `service ldap restart`, or for RHEL 7.x: `service slapd restart`.

### External LDAP Server Replication: Configuring The Consumer(s)

The consumer is an LDAP server on a Bright Cluster Manager head node. It is configured to replicate with the provider by adding the following lines to `/cm/local/apps/openldap/etc/slapd.conf`:

```
syncrepl rid=2
  provider=ldap://external.ldap.server
  type=refreshOnly
  interval=01:00:00:00
  searchbase=<suffix>
  scope=sub
  schemachecking=off
  binddn="cn=syncuser,<suffix>"
  bindmethod=simple
  credentials=secret
```

Here:

- The `rid=2` value is chosen to avoid conflict with the `rid=1` setting used during high availability configuration (section 6.3.2).
- The provider argument points to the external LDAP server.
- The interval argument (format DD:HH:MM:SS) specifies the time interval before the consumer refreshes the database from the external LDAP. Here, the database is updated once a day.
- The credentials argument specifies the password chosen for the `syncuser` on the external LDAP server.

More on the `syncrepl` directive can be found in the `openldap` documentation (<http://www.openldap.org/doc/>).

The configuration files must also be edited so that:

- The `<suffix>` and `rootdn` settings in `slapd.conf` both use the correct `<suffix>` value, as used by the provider.
- The base value in `/etc/ldap.conf` uses the correct `<suffix>` value as used by the provider. This is set on all Bright Cluster Manager nodes including the head node(s). If the `ldap.conf` file does not exist, then the note on page 199 about RHEL versions applies.

Finally, before replication takes place, the consumer database is cleared. This can be done by removing all files, except for the `DB_CONFIG` file, from under the configured database directory, which by default is at `/var/lib/ldap/`.

The consumer is restarted using `service ldap restart`. This replicates the provider's LDAP database, and continues to do so at the specified intervals.

### 6.3.2 High Availability

#### No External LDAP Server Case

If the LDAP server is not external—that is, if the Bright Cluster Manager is set to its high availability configuration, with its LDAP servers running internally, on its own head nodes—then by default LDAP services are provided from both the active and the passive node. The high-availability setting ensures that CMDaemon takes care of any changes needed in the `slapd.conf` file when a head node changes state from passive to active or vice versa, and also ensures that the active head node propagates its LDAP database changes to the passive node via a `syncprov/syncrepl` configuration in `slapd.conf`.

#### External LDAP Server With No Replication Locally Case

In the case of an external LDAP server being used, but with no local replication involved, no special high-availability configuration is required. The LDAP client configuration in `/etc/ldap.conf` simply remains the same for both active and passive head nodes, pointing to the external LDAP server. The file `/cm/images/default-image/etc/ldap.conf`, in each software image also point to the same external LDAP server. If the `ldap.conf` files referred to here in the head and software images do not exist, then the note on page 199 about RHEL versions applies.

#### External LDAP Server With Replication Locally Case

In the case of an external LDAP server being used, with the external LDAP provider being replicated to the high-availability cluster, it is generally more efficient for the passive node to have its LDAP database propagated and updated only from the active node to the passive node, and not updated from the external LDAP server.

The configuration should therefore be:

- an active head node that updates its consumer LDAP database from the external provider LDAP server

- a passive head node that updates its LDAP database from the active head node's LDAP database

Although the final configuration is the same, the sequence in which LDAP replication configuration and high availability configuration are done has implications on what configuration files need to be adjusted.

1. For LDAP replication configuration done after high availability configuration, adjusting the new suffix in `/cm/local/apps/openldap/etc/slapd.conf` and in `/etc/ldap.conf` on the passive node to the local cluster suffix suffices as a configuration. If the `ldap.conf` file does not exist, then the note on page 199 about RHEL versions applies.
2. For high availability configuration done after LDAP replication configuration, the initial LDAP configurations and database are propagated to the passive node. To set replication to the passive node from the active node, and not to the passive node from an external server, the provider option in the `syncrepl` directive on the passive node must be changed to point to the active node, and the suffix in `/cm/local/apps/openldap/etc/slapd.conf` on the passive node must be set identical to the head node.

The high availability replication event occurs once only for configuration and database files in Bright Cluster Manager's high availability system. Configuration changes made on the passive node after the event are therefore persistent.

## 6.4 Tokens And Profiles

*Tokens* can be assigned by the administrator to users so that users can carry out some of the operations that the administrator do with Bright View or `cmsh`. Every cluster management operation requires that each user, including the administrator, has the relevant tokens in their *profile* for the operation.

The tokens for a user are grouped into a profile, and such a profile is typically given a name by the administrator according to the assigned capabilities. For example the profile might be called `readmonitoringonly` if it allows the user to read the monitoring data only, or it may be called `powerhandler` if the user is only allowed to carry out power operations. Each profile thus consists of a set of tokens, typically relevant to the name of the profile, and is typically assigned to several users.

The profile is stored as part of the authentication certificate (section 2.3) which is generated for running authentication operations to the cluster manager for the certificate owner.

Profiles are handled with the `profiles` mode of `cmsh`, or from the `Profiles` window, accessible via a clickpath of `Identity Management`→`Profiles`

The following preconfigured profiles are available from `cmsh`:

Profile name	Default Tasks Allowed
<code>admin</code>	all tasks
<code>cloudjob</code>	cloud job submission
<code>cmhealth</code>	health-related prejob tasks
<code>cmpam</code>	Bright Cluster Manager PAM tasks
<code>node</code>	node-related
<code>portal</code>	user portal viewing
<code>power</code>	device power
<code>readonly</code>	view-only

The available preconfigured profiles in `cmsh` can be seen by running the `list` command in `profile` mode. Another way to see them is by using tab-completion prompting, as follows:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% profile
[bright80->profile]% show <TAB> <TAB>
admin cloudjob cmhealth cmpam node portal power readonly
```

The tokens, and other properties of a particular profile can be seen within profile mode as follows:

### Example

```
[bright80->profile]% show readonly
Parameter      Value
-----
Name           readonly
Non user       no
Revision
Services       CMDevice CMNet CMPart CMMon CMJob CMAuth CMServ CMUser CMSession CMMain CMGui CMP+
Tokens         GET_DEVICE_TOKEN GET_CATEGORY_TOKEN GET_NODEGROUP_TOKEN POWER_STATUS_TOKEN GET_DE+
```

For screens that are not wide enough to view the parameter values, the values can also be listed:

### Example

```
[bright80->profile]% get readonly tokens
GET_DEVICE_TOKEN
GET_CATEGORY_TOKEN
GET_NODEGROUP_TOKEN
...
```

A profile can be set with cmsh for a user within user mode as follows:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% user use conner
[bright80->user[conner]]% get profile

[bright80->user[conner]]% set profile readonly; commit
```

## 6.4.1 Modifying Profiles

A profile can be modified by adding or removing appropriate tokens to it. For example, the `readonly` group by default has access to the burn status and burn log results. Removing the appropriate tokens stops users in that group from seeing these results.

In cmsh the removal can be done from within profile mode as follows:

```
[root@bright80 ~]# cmsh
[bright80]% profile use readonly
[...[readonly]]% removefrom tokens burn_status_token get_burn_log_token
[bright80]%->profile*[readonly*]]% commit
```

Tab-completion after typing in `removefrom tokens` helps in filling in the tokens that can be removed.

In Bright View (figure 6.3), the same removal action can be carried out via the clickpath:

Identity Management→Profiles→readonly→Edit→Tokens

In the resulting display it is convenient to maximize the window. Also convenient is running a search for `burn`, which will show the relevant tokens, `BURN_STATUS_TOKEN` and `GET_BURN_LOG_TOKEN`, as well as the subgroup they are in `device`. The ticks can be removed from the `BURN_STATUS_TOKEN` and `GET_BURN_LOG_TOKEN` checkboxes, and the changed settings can then be saved.




Figure 6.3: Bright View Profile Token Management

### 6.4.2 Creation Of Custom Certificates With Profiles, For Users Managed By Bright Cluster Manager's Internal LDAP

Custom profiles can be created to include a custom collection of capabilities in `cmsh` and Bright View. Cloning of profiles is also possible from `cmsh`.

A certificate file, with an associated expiry date, can be created based on a profile. The time of expiry for a certificate cannot be extended after creation. An entirely new certificate is required after expiry of the old one.

The creation of custom certificates using `cmsh` (page 207) or Bright View (page 208) is described later on. After creating such a certificate, the `openssl` utility can be used to examine its structure and properties. In the following example most of the output has been elided in order to highlight the expiry date (30 days from the time of generation), the common name (`democert`), the key size (2048), profile properties (`readonly`), and system login name (`peter`), for such a certificate:

```
[root@bright80]# openssl x509 -in peterfile.pem -text -noout
Data:
  ...
    Not After : Sep 21 13:18:27 2014 GMT
  Subject: ... CN=democert
           Public-Key: (2048 bit)
  ...
  X509v3 extensions:
    1.3.6.1.4.4324.1:
      ..readonly
    1.3.6.1.4.4324.2:
      ..peter
[root@bright80]#
```

However, using the `openssl` utility for managing certificates is rather inconvenient. Bright Cluster Manager provides more convenient ways to do so, as described next.

#### Listing Certificates

All certificates that have been generated by the cluster are noted by `CMDaemon`.

**Listing certificates with cmsh:** Within the `cert` mode of `cmsh`, the `listcertificates` command lists all cluster certificates and their properties:

```
[root@bright80 ~]# cmsh -c "cert; listcertificates"
Serial num Days left  Profile  Country  Name                      Revoked
-----
1           36451      admin   US       Administrator             Yes
10          9         readonly ef       democert                  Yes
11          36496      node    NL       52-54-00-de-e3-6b        No
12          36496      node    NL       52-54-00-44-fb-85        No
13          36496      admin   UK       otheradmin                No
...
```

**Listing certificates with Bright View:** The Bright View equivalent for listing certificates is via the click-path `Identity Management`→`Certificates` (figure 6.4):

Certificates						
NAME	REVOKED	SERIAL ...	REMAI...	PROFILE	COUNTRY	OPTIONS
<input type="checkbox"/> Administrator	false	2	36478 da...	admin	US	Edit ▼
<input type="checkbox"/> CMHealth	false	3	36478 da...	cmhealth	US	Edit ▼
<input type="checkbox"/> CMHealth	false	4	36478 da...	cmhealth	US	Edit ▼
<input type="checkbox"/> CMPam	false	5	36478 da...	cmpam	US	Edit ▼
<input type="checkbox"/> PJ-tr	false	1	36478 da...		US	Edit ▼
<input type="checkbox"/> WebPortal	false	6	36478 da...	portal	US	Edit ▼
<input type="checkbox"/> bright80	false	17	36488 da...		US	Edit ▼
<input type="checkbox"/> fa-16-3e-09-2c-79	false	10	36478 da...	node	US	Edit ▼

Figure 6.4: Bright View Certificates List Window

In the certificates list, node certificates that are generated by the node-installer (section 5.4.1) for each node for CMDaemon use are listed.

Custom certificates are also listed in the certificate lists.

### Creating A Custom Certificate

Unlike node certificates, which are normally system-generated, custom certificates are typically generated by a user with the appropriate tokens in their profile, such as `root` with the `admin` profile. Such a user can create a certificate containing a specified profile, as discussed in the next section, by using:

- `cmsh`: with the `createcertificate` operation from within `cert` mode
- Bright View: via the clickpath `Identity Management`→`Users`→`Edit`→`Profile` to set the Profile.

**Creating a new certificate for cmsh users:** Creating a new certificate in `cmsh` is done from `cert` mode using the `createcertificate` command, which has the following help text:

```
[bright80->cert]% help createcertificate
Name:
    createcertificate - Create a new certificate
```



Usage:

```
createcertificate <key-length> <common-name> <organization> <organizational-unit> <locality> <state> <country> <profile> <sys-login> <days> <key-file> <cert-file>
```

Arguments:

```
key-file
    Path to key file that will be generated

cert-file
    Path to pem file that will be generated
```

Accordingly, as an example, a certificate file with a read-only profile set to expire in 30 days, to be run with the privileges of user `peter`, can be created with:

### Example

```
createcertificate 2048 democert a b c d ef readonly peter 30 /home/peter\
/peterfile.key /home/peter/peterfile.pem
```

```
Fri Aug 22 06:18:27 2014 [notice] bright80: New certificate request with ID: 1
[bright80->cert]% createcertificate 2048 democert a b c d ef readonly pe\
ter 30 /home/peter/peterfile.key /home/peter/peterfile.pem
Certificate key written to file: /home/peter/peterfile.key
Certificate pem written to file: /home/peter/peterfile.pem
```

The certificates are owned by the owner generating them, so they are root-owned if `root` was running `cmsh`. This means that user `peter` cannot use them until their ownership is changed to user `peter`:

### Example

```
[root@bright80 ~]# cd /home/peter
[root@bright80 peter]# ls -l peterfile.*
-rw----- 1 root root 1704 Aug 22 06:18 peterfile.key
-rw----- 1 root root 1107 Aug 22 06:18 peterfile.pem
[root@bright80 peter]# chown peter:peter peterfile.*
```

Other users must have the certificate ownership changed to their own user names. Users associated with such a certificate can then carry out `cmdaemon` tasks that have a read-only profile, and `CMDaemon` sees such users as being user `peter`. Two ways of being associated with the certificate are:

1. The paths to the `pem` and `key` files can be set with the `-i` and `-k` options respectively of `cmsh`. For example, in the home directory of `peter`, for the files generated in the preceding session, `cmsh` can be launched with these keys with:

```
[peter@bright80 ~] cmsh -i peterfile.pem -k peterfile.key
[bright80]% quit
```

2. If the `-i` and `-k` options are not used, then `cmsh` searches for default keys. The default keys for `cmsh` are under these paths under `$HOME`, in the following order of priority:

- (a) `.cm/admin.{pem,key}`
- (b) `.cm/cert.{pem,key}`

**Creating a custom certificate for Bright View users:** As in the case of `cmsh`, a Bright View user having a sufficiently privileged tokens profile, such as the `admin` profile, can create a certificate and key file for themselves or another user. This is done by associating a value for the `Profile` from the `Add or Edit` dialog for the user (figure 6.2).

The certificate files, `cert.pem` and `cert.key`, are then automatically placed in the following paths and names, under `$HOME` for the user:

- `.cm/admin.{pem,key}`
- `.cm/cert.{pem,key}`

Users that authenticate with their user name and password when running Bright View use this certificate for their Bright View clients, and are then restricted to the set of tasks allowed by their associated profile.

### 6.4.3 Creation Of Custom Certificates With Profiles, For Users Managed By An External LDAP

The use of an external LDAP server instead of Bright Cluster Manager's for user management is described in section 6.3. Generating a certificate for an external LDAP user must be done explicitly in Bright Cluster Manager. The `external-user-cert.py` script, available under `/cm/local/apps/cmd/scripts/`, does this, embedding the user and profile in the certificate during the process. It has the following usage:

Usage:

For a single profile:

```
external-user-cert.py <profile> <user> [<user> ... ] --home=<home-prefix> [-g <group>] [-p <port>]
```

For several profiles:

```
external-user-cert.py --home=<home-prefix> --file=<inputfile> [-g <group>] [-p <port>]
                        where lines of <inputfile> have the syntax
                        <profile> <user> [<user> ... ]
```

The `-p <port>` option must be set if `CMDaemon` is using a non-standard SSL port

Here,

- `<profile>` should be a valid profile
- `<user>` should be an existing user
- `<home-prefix>` is usually `/home`
- `<group>` is a group, such as `wheel`
- `<port>` is a port number, such as the `CMDaemon` SSL port 8081

One or more external LDAP user certificates can be created by the script. The certificate files generated are `cert.pem` and `cert.key`. They are stored in the home directory of the user.

For example, a user `spongebob` that is managed on the external server, can have a read-only certificate generated with:

```
# external-user-cert.py readonly spongebob --home=/home
```

If the home directory of `spongebob` is `/home/spongebob`, then the key files that are generated are `/home/spongebob/.cm/cert.key` and `/home/spongebob/.cm/cert.pem`.

Assuming no other keys are used by `cmsh`, a `cmsh` session that runs as user `spongebob` with `readonly` privileges can now be launched:

```
$ module load cmsh  
$ cmsh
```

If other keys do exist, then they may be used according to the logic explained in item 2 on page 207.

#### 6.4.4 Logging The Actions Of CMDaemon Users

The following directives allow control over the logging of CMDaemon user actions.

- `CMDaemonAudit`: Enables logging
- `CMDaemonAuditorFile`: Sets log location
- `DisableAuditorForProfiles`: Disables logging for particular profiles

Details on these directives are given in Appendix C.



# Workload Management

For clusters that have many users and a significant load, a workload management system allows a more efficient use of resources to be enforced for all users than if there were no such system in place. This is because without resource management, there is a tendency for each individual user to over-exploit common resources.

When a workload manager is used, the user submits a batch (i.e. non-interactive) job to it. The workload manager assigns resources to the job, and checks the current availability as well as checking its estimates of the future availability of the cluster resources that the job is asking for. The workload manager then schedules and executes the job based on the assignment criteria that the administrator has set for the workload management system. After the job has finished executing, the job output is delivered back to the user.

Among the hardware resources that can be used for a job are GPUs. Installing CUDA software to enable the use of GPUs is described in section 7.5 of the *Installation Manual*.

The details of job submission from a user's perspective are covered in the *User Manual*.

Sections 7.1–7.5 cover the installation procedure to get a workload manager up and running.

Sections 7.6 –7.7 describe how Bright View and `cmsh` are used to view and handle jobs, queues and node drainage.

Section 7.8 shows examples of workload manager assignments handled by Bright Cluster Manager.

Section 7.9 ends the chapter by describing the power saving features of workload managers.

## 7.1 Workload Managers Choices

Some workload manager packages are installed by default, others require registration from the distributor before installation.

During cluster installation, a workload manager can be chosen (figure 3.22 of the *Installation Manual*) for setting up. The choices are:

- None
- Slurm v17.02.11 (default)
- Grid Engine 2011.11p1. An open source development of Sun Grid Engine (SGE)  
A flavor of SGE is Univa Grid Engine (UGE) (section 7.5.2) developed by Univa. Bright Cluster Manager 8.0 supports integration with UGE versions 8.2.0 and higher at the time of writing of this section (October 2017).
- Torque v6.1.1 and its built-in scheduler
- Torque v6.1.1 and the Maui scheduler
- Torque v6.1.1 and the Moab scheduler

- PBS Pro CE v14.1.0
- PBS Pro v14.2.1

These workload managers can also be chosen and set up later using the `wlm-setup` tool (section 7.3).

Besides the preceding workload managers, the installation of the following workload managers is also possible, and described in their own sections:

- OpenLava v3.3.3 (section 7.5.6)
- Load Sharing Facility (LSF) v9, v10 (section 7.5.7)

## 7.2 Forcing Jobs To Run In A Workload Management System

Another preliminary step is to consider forcing users to run jobs only within the workload management system. Having jobs run via a workload manager is normally a best practice.

For convenience, the Bright Cluster Manager defaults to allowing users to login via `ssh` to a node, using the authorized keys files stored in each users directory in `/home` (section 2.3.2). This allows users to run their processes outside the workload management system without restriction. For clusters with a significant load this policy results in a sub-optimal use of resources, since such unplanned-for jobs disturb any already-running jobs.

Disallowing user logins to nodes, so that users have to run their jobs through the workload management system, means that jobs are then distributed to the nodes only according to the planning of the workload manager. If planning is based on sensible assignment criteria, then resources use is optimized—which is the entire aim of a workload management system in the first place.

### 7.2.1 Disallowing User Logins To Regular Nodes Via `cmsh`

The `usernodelogin` setting of `cmsh` restricts direct user logins from outside the workload manager, and is thus one way of preventing the user from using node resources in an unaccountable manner. The `usernodelogin` setting is applicable to node categories only, rather than to individual nodes.

In `cmsh` the attribute of `usernodelogin` is set from within `category mode`:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% category use default
[bright80->category[default]]% set usernodelogin onlywhenjob
[bright80->category*[default*]]% commit
```

The attributes for `usernodelogin` are:

- `always` (the default): This allows all users to `ssh` directly into a node at any time.
- `never`: This allows no user other than `root` to directly `ssh` into the node.
- `onlywhenjob`: This allows the user to `ssh` directly into the node when a job is running on it. It typically also prevents other users from doing a direct `ssh` into the same node during the job run, since typically the workload manager is set up so that only one job runs per node. However, an `ssh` session that is already running is not automatically terminated after the job is done.
  - Some cluster administrators may wish to allow some special user accounts to override the `onlywhenjob` setting, for example for diagnostic purposes. Before giving the details of how to override the setting, some background explanation is probably useful:  
The `onlywhenjob` setting works with the PAM system, and adds the following line to `/etc/pam.d/sshd` on the regular nodes:

account                      required                      pam\_bright.so

Nodes with the `onlywhenjob` restriction can be configured to allow a particular set of users to access them despite the restriction by whitelisting them in the PAM system, as follows: Within the software image *<node image>* used by the node, that is under `/cm/images/<node image>`, the administrator can add the set of user accounts to the file `etc/security/pam_bright.d/pam_whitelist.conf`. This file is installed in the software image by the `cm-libpam` package.

Other adjustments to PAM configuration, such as the number of attempted logins and the associated wait time per login, can be carried by editing the `/etc/security/pam_bright.d/cm-check-alloc.conf` file.

The image can then be updated to implement the whitelist, by running the `imageupdate` command in `cmsh` (section 5.6.2), or by clicking the `Update node` option in Bright View (section 5.6.3).

### 7.2.2 Disallowing User Logins To Regular Nodes Via Bright View

In Bright View, user node login access is set via a category setting, for example for the `default` category via the clickpath:

Grouping→Node categories[default]→Edit→Settings→User node login  
(figure 7.1):




Figure 7.1: Disallowing User Logins To Nodes Via Bright View

### 7.2.3 Disallowing Other User Processes Outside Of Workload Manager User Processes

Besides disabling user logins, administrators may choose to disable interactive jobs in the workload management system as an additional measure to prevent users from starting jobs on other nodes.

Administrators may also choose to set up scripts that run after job execution. Such scripts can terminate user processes outside the workload manager, as part of a policy, or for general administrative hygiene. These are `Epilog` scripts and are part of the workload manager.

The workload management system documentation has more on configuring these options.

## 7.3 Installation Of Workload Managers

Normally the administrator selects a workload manager to be used during Bright Cluster Manager installation (figure 3.22 of the *Installation Manual*). A workload manager may however also be added and configured after Bright Cluster Manager has been installed, using `wlm-setup`.

### 7.3.1 Setting Up, Enabling, And Disabling The Workload Manager With `wlm-setup`

The following options from `wlm-setup` must be chosen to set up, enable or disable a workload manager for Bright Cluster Manager:

- `-w` or `--wlmmanager`: the **workload manager** option, together with `<name>`, the workload manager name. The value of `<name>` can be one of
  - `slurm`
  - `sge`
  - `uge` (This has a prerequisite that the packages must be installed from the UGE site first, as explained in section 7.5.3)
  - `torque` (Torque with its built-in scheduler)
  - `torquemaui` (Torque with the Maui scheduler)
  - `torquemoad` (Torque with the Moab scheduler)
  - `pbspro` (PBS Pro commercial edition)
  - `pbspro-ce` (PBS Pro Community Edition)
  - `lsf`
  - `openlava` (This has a prerequisite that the packages must be installed first, as explained in section 7.5.6)

and for the named workload manager, either:

- `-s` or `--setup`: the **setup** option. This does a basic setup of the workload manager, initializing the database for the workload manager, setting up default queues, and enabling the workload manager clients for the default category. It can optionally take the further options of section 7.3.2
- or
- `-e` or `--enable`: the **enable** option. Enabling assigns workload manager client roles and default queues to the applicable node categories. This option need not be run if the `setup` option has just run. CMDaemon attempts to run workload managers that have been enabled.
  - `-p` or `--powersave` option will also allow power management, for `slurm` only, for Slurm clients only, for non-head nodes only. Independently of `wlm-setup`, power management can also be allowed by using Slurm roles (section 7.9.1) without using `wlm-setup`. When using Slurm roles, the `powersavingallowed` parameter in the `slurmclient` role allows power management for head nodes too if set for a head node, in the unlikely case that the administrator finds it is acceptable to power off a head node that is not running Slurm jobs. If power saving is allowed for a node, then the `powersavingenabled` parameter in the `slurmserver` role is what actually enables power management for that node.
- or
- `-d` or `--disable`: the **disable** option, which disables the workload manager
  - `-p` or `--powersave` option will disallow power management only, for `slurm` only, for Slurm clients only.
- or
- `-i` or `--image`: the **image** option, which places the job execution daemons in software images, for example when a new node category is added to the cluster. The default image directory is `/cm/images/default-image`.

The `--setup` option of `wlm-setup` installs a workload manager package along with its scheduler. Roles, queues, and databases used by the workload manager are initialized on the head. Software images stored on the head node are also set up. However, the nodes themselves are only updated after a reboot, or manually running `imageupdate` (section 5.6.2)—the idea being to avoid an automatic



update so that an administrator is encouraged to check via a dry-run if unintended consequences would happen.

The `enable` and `disable` options of `wlm-setup` are the same as those that take place during role assignment (sections 7.4.1 and 7.4.2). These options therefore make CMDaemon enable or disable the workload manager as a service.

For example, setting up SGE can be done as follows:

#### Example

```
[root@bright80 ~]# wlm-setup -w sge -s
      Disabling sge services ..... [ OK ]
      Initializing sge setup ..... [ OK ]
      Installing sge qmaster ..... [ OK ]
      Updating image services ..... [ OK ]
      Updating qmaster config ..... [ OK ]
      Creating default sge setup ..... [ OK ]
      Setting permissions ..... [ OK ]
      Enabling sge services ..... [ OK ]
```

For example, Slurm job daemons can be installed in the node image `new-image` as follows:

#### Example

```
wlm-setup -w slurm -i -u /cm/images/new-image
```

If there are provisioning nodes, the `updateprovisioners` command (section 5.2.4) should be run after the software image is changed. The nodes can then simply be rebooted to pick up the new image, or alternatively, to avoid rebooting, the `imageupdate` command (section 5.6.2) places a new image on the node from the provisioner.

### 7.3.2 Other Options With `wlm-setup`

A full list of options to `wlm-setup` can be seen by running it with the `-h|--help` option. The list shows other options besides the ones listed in section 7.3.1. These other options are run as further options to the `-s|--setup` option, and are:

- **included images** The `included images` option (`-u` or `--updateimages <[image1[, image2, ...]>`) includes the comma-separated list of images
- **excluded images** The `excluded images` option (`-x` or `--excludeimages <[image1[, image2, ...]>`) excludes the comma-separated list of images
- **offload** The `offload` option (`-o` or `--offload`) deals with setting up, enabling or disabling a workload manager server running on another specified node, other than the default head node:

#### Example

```
wlm-setup -w slurm -s -o node003
```

- **head as a compute node** This option (`-m` or `--mcompute`) sets the head node to join in as a compute node for job execution tasks in a workload management system. This can be significantly worthwhile on smaller clusters:

#### Example

```
wlm-setup -w slurm -s -m
```

- **slots** The slots option (`-n` or `--slots`) sets the maximum allowed value of slots, and is typically set to the number of cores per node:

#### Example

```
wlm-setup -w torque -s -n 4
```

For workload managers, slots is the number of logical CPUs set per node.

- It is not recommended to set the number of slots to be greater than the number of cores for non-threading applications. That is because in such a case, when all the slots are running jobs, the maximum speed at which the jobs can run is usually reduced in comparison with the one-slot-per-core case, and the efficiency at which they run is also less.
- However increasing the slots value to be greater than the number of cores may improve performance for applications that are optimized to use threading, if they are running on cores that have hyperthreading enabled. Because enabling hyperthreading can increase power consumption and can result in unexpected performance issues, benchmarking is advised.

The number of slots can also be adjusted outside of `wlm-setup`, after setup, by using Bright Cluster Manager to set it in the workload manager client role.

**SGE and slots:** In SGE, `wlm-setup` sets the number of slots in a complex (`man (5) complex`) configuration file.

In practice, for SGE this means that the system administrator manually sets the number of slots to the number of cores per node during the initial Bright Cluster Manager installation, or during `wlm-setup`, or using `cmsh` or Bright View, just like in the other workload managers. The complex configuration file value is set automatically according to this value.

If an end user explicitly requests slots for a job `myjob` with:

#### Example

```
qsub -l slots=2 myjob
```

then SGE tries to allocate a node with 2 free slots. If there are no nodes with more than one slot, then `myjob` will not run.

The difference in comparison with the other workload managers occurs when a user needs to use a parallel engine driver such as Open MPI. In that case, the requested number of slots in SGE can be used by MPI processes as well as regular non-MPI processes. Thus, the user submission request:

#### Example

```
qsub -l slots=2 -pe openmpi 32 myjob
```

means that enough nodes with 2 free slots each should be made available to run all the 32 MPI processes being requested. Again, if there are no nodes with more than one slot, the job will not run. If `slots=2` is not specified in the `qsub` line, then the MPI processes are spread across whatever cores are available, if there are nodes with one or more free slots.

- **archives** The archives option (`-a` or `--archives-location`) sets the directory path to the archives files used for software installation. This is valid for UGE or LSF only.

#### Example

```
wlm-setup -w lsf -s -a /root/lsf
```

- **categories** The categories option (`-c` or `--categories`) assigns the client role to a comma-separated list of categories instead of to the default category. The default category takes the value `default` by default. The default value for a category can be changed to another existing category by setting the value for the `defaultcategory` attribute for the base object in `partition` mode:

#### Example

```
[bright80]% partition use base
[bright80->partition[base]]% get defaultcategory
default
[bright80->partition[base]]% set defaultcategory fast; commit
```

#### Example

```
wlm-setup -w slurm -s -c fast,superfast,ludicrous
```

- **license** The license option (`-l` or `--license <host:port,...>`) sets the host and port pairings up for use with a dedicated license server for PBSPro.

### 7.3.3 Prolog And Epilog Scripts

#### What Prolog And Epilog Scripts Do

The workload manager runs prolog scripts before job execution, and epilog scripts after job execution. The purpose of these scripts can include:

- checking if a node is ready before submitting a job execution that may use it
- preparing a node in some way to handle the job execution
- cleaning up resources after job execution has ended.

The administrator can run custom prolog or epilog scripts for the queues from CMDaemon for SGE, LSF, or OpenLava, by setting such scripts in the Bright View or `cmsh` front ends. Default epilogs and prologs are created automatically when a new queue is created.

#### Example

```
[bright80->jobqueue]% add lsf newq
[bright80->jobqueue*(lsf)->newq*] show | grep . | grep -i epilog
Epilog /cm/local/apps/cmd/scripts/epilog
Prolog/Epilog user root
```

For Torque/PBS Pro and Slurm, there are global prolog and epilog scripts, but editing them is not recommended. Indeed, in order to discourage editing them, the scripts cannot be set via the cluster manager front ends. Instead the scripts must be placed by the administrator in the software image, and the relevant nodes updated from the image.

#### Detailed Workings Of Prolog And Epilog Scripts

Even though it is not recommended, some administrators may nonetheless wish to link and edit the scripts directly for their own needs, outside of the Bright View or `cmsh` front ends. A more detailed explanation of how the prolog scripts work therefore follows:

The prolog scripts have names and function according to their locations. The scripts are placed in two directories:

1. In the **main scripts directory**, at:

```
/cm/local/apps/cmd/scripts/
```

In this directory, a main prolog script, `prolog`, can call a sequence of rc.d-style prolog scripts for a particular workload manager in an rc.d-style directory.

2. **rc.d-style prolog directory**, at:

```
/cm/local/apps/<workload manager>/var/prologs/
```

In this directory, prolog scripts, if they exist, are stored in a directory path associated with the workload manager name. The names of the scripts have suffixes and prefixes associated with them that make them run in special ways, as follows:

- **suffixes used in the rc.d-style directory:**
  - `-prejob` script runs prior to all jobs
  - `-cmsub`: script runs prior to job run in a cloud
  - `-mic`: script runs prior to job run in a MIC
  - `-michost`: script runs prior to job started on a MIC host
- **prefixes used in the rc.d-style directory:**
  - `00-` to
  - `99-`

Number prefixes determine the order of script execution. This is like for SysV-style `rc.d` names, where scripts with the lower number are run earlier. Hence the terminology “rc.d-style” associated with these prolog scripts.

The script names can therefore look like:

### Example

- `00-prolog-prejob`
- `10-prolog-cmsub`
- `15-prolog-mic`

Return values for the rc.d-style scripts have these meanings:

- `0`: the next script in the directory is run.
- *A non-zero return value*: no further scripts are executed from the rc.d-style directory.

Often, the script in an rc.d-style prolog directory is not a real script but a symlink, with the symlink going to a general script located in the main scripts directory. In that case, this general script is then able to take care of what is expected of the symlink. The name of the symlink, and destination file, usually hints at what the script is expected to do.

For example, the Torque workload manager uses the symlink `10-prolog-prejob` within the rc.d-style directory `/cm/local/apps/torque/var/prologs/`. The symlink links to the script `prolog-prejob` within the main scripts directory `/cm/local/apps/cmd/scripts/`. In this case, the script is expected to run prior to the job.

Epilog script paths follow the same pattern as prolog scripts, with “epilog” substituted in the path name for “prolog”. However, the only suffix form allowed in the rc.d-style directory is `-cmsub`.

The Torque/PBS Pro and Slurm prolog and epilog scripts are global in effect.

### Workload Manager Package Configuration For Prolog And Epilog Scripts

Each workload manager package configures prolog- and epilog-related scripts or links during installation, as follows:

- **Slurm**
  - `prolog-prejob`: in the main scripts directory, is assigned to `PrologSlurmctld` in `/etc/slurm/slurm.conf`. It runs by default during job execution, and is executed with `slurm` user permissions.
  - `prolog`: in the main scripts directory, is assigned to the variable `Prolog` in `/etc/slurm/slurm.conf`. The script executes the `<number>-prolog{-cmsub|-mic|-michost|-prejob}` scripts located in the `rc.d-style` directory, if they exist. By default, none exist. The `epilog` script in the main scripts directory follows the same pattern, with the appropriate name changes.
- **SGE, LSF/OpenLava**
  - `prolog`: in the main scripts directory, executes any `<number>-prolog{-cmsub|-mic|-michost|-prejob}` scripts located in the `rc.d-style` directory, if they exist.  
It is set by default to execute `10-prolog-prejob` in the `rc.d-style` directory. This in turn is configured as a symlink to `prolog-prejob` in the main scripts directory, which is able to handle the execution of scripts in a general manner. Any further scripts in the `rc.d-style` directories, whether for prologs or epilogs, are then also processed
- **PBS Pro/Torque**
  - `mom_priv/prologue`: (with the `-ue` ending) in the `rc.d-style` directory, is a symlink to `prolog` in the main scripts directory. This in turn executes any `<number>-prolog{-cmsub|-mic|-michost|-prejob}` scripts located in the `rc.d-style` directory, if they exist. Similar to this are the `epilogue` scripts in the `rc.d-style` directory.

## 7.4 Enabling, Disabling, And Monitoring Workload Managers

After a workload manager package is installed and initialized with `wlm-setup` (section 7.3), it can also be enabled or (if already enabled) disabled, with `wlm-setup`. Enabling and disabling means the workload management services start or stop.

Alternatively, a workload manager can be enabled or disabled by the administrator with Bright View or `cmsh`. This is described further on in this section.

In Bright Cluster Manager 8.0, workload managers can even run concurrently. For example, Slurm, SGE, and Torque can run at the same time in the cluster, for example with one workload manager assigned to one category. However, this can easily lead to confusion. Running only one workload manager is a more sane practice, and is strongly urged for production environments.

From the Bright View or `cmsh` point of view a workload manager consists of

- a workload manager server, usually on the head node
- workload manager clients, usually on the compute nodes

For the administrator, enabling or disabling the servers or clients is then simply a matter of assigning or unassigning a particular workload manager server or client role on the head or compute nodes, as deemed appropriate.

The administrator typically also sets up an appropriate workload manager environment module (`slurm`, `sge`, `torque`, `pbspro`, or `openlava`) so that it is loaded up for the end user (section 2.2.3).

### 7.4.1 Enabling And Disabling A Workload Manager With Bright View

A particular workload manager package may be set up, but the workload manager may not be enabled. This can happen, for example, if using `wlm-setup` (section 7.3) to install the package without enabling it. It may also happen, for example, if disabling a workload manager that was previously enabled.

The workload manager client and server can be enabled from Bright View by assigning the appropriate role to it. Within the role, the properties of the workload manager may be further configured.

#### Workload Manager Role Assignment To An Individual Node With Bright View

**Workload Manager Server** A server or client, for example, Torque server, can be assigned to a node, for example `bright80`, via the clickpath:

Devices→Head Nodes**bright80**→Settings→Roles→Torque server role.

The large number of roles means that using the filter to narrow down the search, using text from role, is usually convenient (figure 7.2).




Figure 7.2: Workload Management Role Assignment On A Head Node

Options can be set within the workload manager, within the role. For example, for Torque, the Maui or Moab schedulers must be set as options instead of Torque's built-in scheduler, when enabling Torque with Maui or Moab. The workload manager server role is then saved with the selected options (figure 7.3). For starting it up on non-head nodes (but not for a head node), the `imageupdate` command (section 5.6.2) is then run. The workload manager server process and any associated schedulers then automatically start up.




Figure 7.3: Workload Management Role Assignment Options On A Head Node

**Workload Manager Client** Similarly, the workload manager client process can be enabled on a node or head node by having the workload manager client role assigned to it. Some basic options can be set for the client role right away.

Saving the role, and then running `imageupdate` (section 5.6.2), automatically starts up the client process with the options chosen, and managed by CMDaemon.

#### Workload Manager Role Assignment To A Category With Bright View

While workload manager role assignment can be done as described in the preceding text for individual non-head nodes, it is usually more efficient to assign roles using categories due to the large number of compute nodes in typical clusters.

All non-head nodes are by default placed in the `default` category. This means that by default roles in the category are automatically assigned to all non-head nodes, unless by way of exception an individual node configuration overrides the category setting and uses its own role setting instead.

Viewing the possible workload manager roles for the category `default` is done by using the click-path:

Grouping→Node categories[default]→Edit→Settings→Roles→Add

Using the filter to narrow down the search is usually convenient. Once the role is selected its options can be edited and saved.

For compute nodes, the role assigned is usually a workload manager client. The assigned role for a compute node allows queues and GPUs to be specified, and other parameters depending on the workload manager used.

The workload manager server role can also be assigned to a non-head node. For example, a Torque server role can be carried out by a non-head node. This is the equivalent to the `offload` option of `wlm-setup`. As in the individual node assignment case, for Torque with Maui or Torque with Moab, the Maui scheduler or the Moab scheduler options must be set if these schedulers are to be used.

Saving the roles with their options and then running `imageupdate` (section 5.6.2) automatically starts up the newly-configured workload manager.

#### Workload Manager Role Options With Bright View

Each compute node role (workload manager client role) has options that can be set for GPUs, Queues, and Slots.

- `Slots`, in a workload manager, corresponds in Bright Cluster Manager to:

- the CPUs setting (a `NodeName` parameter) in Slurm's `slurm.conf`
- the `np` setting in Torque and PBS Pro,

and is normally set to the number of cores per node.

In LSF and OpenLava, setting the number of slots for the client role to 0 means that the client node does not run jobs on itself, but becomes a submit host, which means it is able to forward jobs to other client nodes.

- Queues with a specified name are available in their associated role after they are created. The creation of queues is described in sections 7.6.2 (using Bright View) and 7.7.2 (using `cmsh`).

Among the other options displayed are installation path or spool path settings.

All server roles also provide the option to enable or disable the `External Server` setting. Enabling it means that the server is no longer managed by Bright Cluster Manager, but provided by an external device.

An external Torque server role on an enabled node also means that additional scheduler services—Maui or Moab—are not started, nor are they monitored, on that node.

The `cmsh` equivalent of this is described on page 224.

#### 7.4.2 Enabling And Disabling A Workload Manager With `cmsh`

A particular workload manager package may be set up, but not enabled. This can happen, for example, if using `wlm-setup` (section 7.3) on the package without enabling it. The workload manager client and server can be enabled from `cmsh` by assigning it from within the `roles` submode. Within the assigned role, the properties of the workload manager may be further configured.

##### Workload Manager Role Assignment To A Category With `cmsh`

Workload manager role assignment of a node category is done using `category` mode, using the category name, and assigning a role from the `roles` submode:

##### Example

```
[root@bright80 ~]# cmsh
[bright80]% category
[bright80->category]% use default
[bright80->category[default]]% roles
[bright80->category[default]->roles]% assign torqueclient
[bright80->category[default]->roles*[torqueclient*]]% commit
[bright80->category[default]->roles[torqueclient]]%
```

After workload manager roles are assigned or unassigned, and after running `imageupdate` (section 5.6.2) for non-head nodes, the associated workload manager services automatically start up or stop as appropriate.

##### Workload Manager Role Assignment To An Individual Node With `cmsh`

In `cmsh`, assigning a workload manager role to a head node is done in `device` mode, using `master` as the device, and assigning the workload manager role from the `roles` submode:

##### Example

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]% use bright80
[bright80->device[bright80]]% roles
[bright80->device[bright80]->roles]% assign torqueserver
[bright80->device*[bright80*]->roles*[torqueserver*]]% commit
[bright80->device[bright80]->roles[torqueserver]]%
```



For regular nodes, role assignment is done via `device` mode, using the node name, and assigning a role from the `roles` submode:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]% use node001
[bright80->device[node001]]% roles
[bright80->device[node001]->roles]% assign torqueclient
[bright80->device[node001]->roles*[torqueclient*]]% commit
[bright80->device[node001]->roles[torqueclient]]%
```

Role assignment values set in `device` mode have precedence over any role assignment values set in `category` mode for that node. This means, for example, that if a node is originally in a node category with a `torqueclient` role and queues set, then when the node is assigned a `torqueclient` role from `device` mode, its queue properties are empty by default.

### Setting Options For Workload Manager Settings With `cmsh`

In the preceding text, it is explained how the workload manager client or server is assigned a role (such as `torqueclient` or `torqueserver`) within the `roles` submode. It is done from within a main mode of `category` or `devices`.

**Options for workload managers in general:** Whatever the main mode used, the workload manager settings can then be handled with the usual object commands introduced in section 2.5.3. For example, the number of slots can be set for Torque clients as follows:

### Example

```
[bright80->category[default]->roles[torqueclient]]% show
Parameter                                Value
-----
All Queues                               yes
GPUs                                      0
Name                                      torqueclient
Queues                                    shortq longq
Revision
Slots                                     4
Type                                      TorqueClientRole
[bright80->category[default]->roles[torqueclient]]% set slots 5
[bright80->category*[default*]->roles*[torqueclient*]]% commit
[bright80->category[default]->roles[torqueclient]]%
```

**Options for the Torque variants:** In particular, the `Scheduler` parameter can be set from an assigned `torqueserver` role:

### Example

```
[bright80->device[bright80]->roles]% set torqueserver scheduler
backfill builtin maui moab torque
[bright80->device[bright80]->roles]% use torqueserver
[bright80->device[bright80]->roles[torqueserver]]% show
Parameter                                Value
-----
External Server                           no
Name                                      torqueserver
```

```

Revision
Scheduler                               torque
Type                                    TorqueServerRole
[bright80->device[bright80]->roles[torqueserver]]% set scheduler moab
[bright80->device[bright80]->roles[torqueserver*]]% commit

```

In the preceding example, the available schedulers list can be displayed using tab-completion, and the Moab scheduler is then enabled. Running `imageupdate` (section 5.6.2) for non-head nodes ensures that the built-in Torque scheduler stops and the Moab scheduler starts. It is possible to switch to the Maui scheduler with the same approach. The Moab or Maui schedulers do however need to be installed before starting them in this manner.

In Bright View, when the Torque server is selected as a role for the node, a scheduler service can then be selected from a drop-down menu. Selecting a new scheduler and saving it enables the new scheduler. Running `imageupdate` (section 5.6.2) for non-head nodes stops the previous scheduler and starts the newly-selected and -enabled scheduler.

**Option to set an external workload manager:** A workload manager can be set to run as an external server from within a device mode role:

#### Example

```

[bright80->device[bright80]->roles[torqueserver]]% set externalserver on
[bright80->device[bright80]->roles[torqueserver*]]% commit

```

For convenience, setting it on the head node is recommended.

If an external server is set for the `torqueserver` role, and uses the schedulers Maui or Moab, then these scheduler services are not started or monitored on the device. The device is the head node, if the earlier recommendation for convenience is followed. The default setting of `torque` remains the scheduler.

The Bright View equivalent of configuring `externalserver` is described on page 222.

### 7.4.3 Monitoring The Workload Manager Services

By default, the workload manager services are monitored. The Bright Cluster Manager attempts to restart the services using the service tools (section 3.11), unless the role for that workload manager service is disabled, or the service has been stopped (using `cmsh`). Workload manager roles and corresponding services can be disabled using `wlm-setup` (section 7.3.1), Bright View (section 7.4.1), or `cmsh` (section 7.4.2).

The daemon service states can be viewed for each node via the shell, `cmsh`, or Bright View (section 3.11).

Queue submission and scheduling daemons normally run on the head node. From Bright View their states are viewable via the clickpath to the services running on the node (figure 3.16), for example, for a head node:

```
Devices→Physical Nodes[bright80]→Settings→Services
```

The job execution daemons run on compute nodes. Their states are viewable via a similar clickpath.

From `cmsh` the services states are viewable from within device mode, using the `services` command. One-liners from the shell to illustrate this are (output elided):

#### Example

```

[root@bright80 ~]# cmsh -c "device services node001; status"
      sgeexecd[  UP  ]
[root@bright80 ~]# cmsh -c "device services bright80; status"
      ...
      sge[  UP  ]

```

## 7.5 Configuring And Running Individual Workload Managers

Bright Cluster Manager deals with the various choices of workload managers in as generic a way as possible. This means that not all features of a particular workload manager can be controlled, so that fine-tuning must be done through the workload manager configuration files. Workload manager configuration files that are controlled by Bright Cluster Manager should normally not be changed directly because Bright Cluster Manager overwrites them. However, overwriting by CMDaemon is prevented on setting the directive:

```
FreezeChangesTo<workload manager>Config = <true|false>
```

in `cmd.conf` (Appendix C), where `<workload manager>` takes the value of `Slurm`, `SGE`, `Torque`, `PBSPPro`, or `OpenLava`, as appropriate. The value of the directive defaults to `false`.

A list of configuration files that are changed by CMDaemon, the items changed, and the events causing such a change are listed in Appendix H.

A very short guide to some specific workload manager commands that can be used outside of the Bright Cluster Manager 8.0 system is given in Appendix F.

### 7.5.1 Configuring And Running Slurm

#### Slurm Versions

Bright Cluster Manager version 8.0, from release version 8.0-17 onwards, is integrated with Slurm by using one of the following packages:

- `slurm`. This is based on Slurm version 17, and is updated in the Bright Cluster Manager repositories for important updates from upstream. At the time of writing (July 2019) the package is based on Slurm release 17.02.11. This is the recommended version for production clusters, and is installed by default.
- `slurm18`. This is based on Slurm version 18, and is updated in the Bright Cluster Manager repositories for important updates from upstream. At the time of writing (July 2019) the package is based on Slurm release 18.08.8. This version is provided because it may have new features that are absent in previous versions. It has been heavily tested, and is suitable for production use.
- `slurm19`. This is based on Slurm version 19, and is updated in the Bright Cluster Manager repositories for important updates from upstream. At the time of writing (July 2019) the package is based on Slurm release 19.05.1. This version is provided because it may have new features that are absent in previous versions. However, version 19 has not been as heavily tested and is therefore not recommended for production use at the time of writing.

The package `slurm-latest`, which in earlier Bright Cluster Manager 8.0 releases had up to Slurm version 18.08.7 as the latest release, is obsolete from version 8.0-17 onward. It should be replaced by removing the `slurm-latest` package and installing either `slurm18`, or `slurm19`.

It is left up to the cluster administrator to decide which version to use.

Bright Cluster Manager provides a similar level of workload manager integration for the supported Slurm packages.

If switching from one package to another—for example from `slurm` to `slurm18`, then the administrator must uninstall the `slurm` package first, in order to avoid a conflict between the versions.

The following example demonstrates how to remove the existing `slurm` package and update to another `slurm19` for RHEL-based distributions:

#### Example

```
[root@bright80 ~]# rpm -qa | grep slurm | xargs -p rpm -e
[root@bright80 ~]# rpm -qa -r /cm/images/default-image | grep slurm | xargs -p rpm -r
```

```
/cm/images/default-image -e
[root@bright80 ~]# yum install slurm19-client slurm19-slurmdbd slurm19-perlapi slurm19-contribs
slurm19
[root@bright80 ~]# yum install --installroot=/cm/images/default-image slurm19-client
```

If either `slurm`, or `slurm18`, or `slurm19` is installed, then the administrator can run `wlm-setup` using the workload manager name `slurm`—that is without the 18 or 19 suffix—to set up Slurm. The roles at node level, or category level—`slurmserver` and `slurmclient`—work with all Slurm versions.

### Configuring Slurm

After package setup is done with `wlm-setup` (section 7.3), Slurm software components are installed in `/cm/shared/apps/slurm/current`.

Slurm clients and servers can be configured to some extent via role assignment (sections 7.4.1 and 7.4.2).

Using `cmsh`, advanced option parameters can be set under the `slurmclient` role:

For example, the number of cores per socket can be set:

#### Example

```
[bright80->category[default]->roles[slurmclient]]% set corespersocket 2
[bright80->category*[default*]->roles*[slurmclient*]]% commit
```

or some GPUs can be added to Slurm:

#### Example

```
[bright80->category[default]->roles[slurmclient]]% set gpus 2
[bright80->...->roles*[slurmclient*]]% append gpudevices /dev/nvidia0
[bright80->...->roles*[slurmclient*]]% append gpudevices /dev/nvidia1
[bright80->category*[default*]->roles*[slurmclient*]]% commit
```

The parameter value for a Slurm option in `slurm.conf` is set by `CMDaemon`, if its value is not 0.

A parameter value of 0 means that the default values of Slurm are used. These usually have the value: 0.

The advanced options that `CMDaemon` manages for Slurm are:

Bright View Option	Slurm Option	Description
Features	Feature=<string> entry in the file slurm.conf	Arbitrary strings can be entered to indicate some characteristics of a node, one string per entry. For example: text1 text2 and so on. These become part of the: Feature=text1,text2... attribute to the NodeName=<node name> entry line in <code>slurm.conf</code> , as indicated in <code>man(5)</code> <code>slurm.conf</code> . The strings also become added attributes to the <code>GresTypes</code> entry of that file. Default: blank.

...continues

...continued

Bright View Option	Slurm Option	Description
GPU devices	File=<device> entries in the file gres.conf	<p>This is only implemented if the number of GPUs has been set by the administrator using Bright Cluster Manager, by setting the basic Slurm client option GPUs. The GPUs option is seen, for example, in Bright View, via the clickpath Grouping→Node categories[default]→Edit→SettingsRoles→slurmclient→GPUs.</p> <p>Each device detected on the host node can be added as an entry. For example:</p> <pre>/dev/nvidia0 /dev/nvidia1 and so on. These become part of the: Name=gpu File=&lt;device&gt; lines in gres.conf, as indicated in man(5) gres.conf. Default: blank</pre>
Slots	CPU	Number of logical processors on the node. Default: 0
Sockets	Sockets	Processor chips on node. Default: 0
Cores per socket	CoresPerSocket	Number of cores per socket. Default: 0
ThreadsPerCore	ThreadsPerCore	Number of logical threads for a single core. Default: 0
Boards	Boards	Number of baseboards in a node. Default: 0
SocketsPerBoard	SocketsPerBoard	Number of processor chips on baseboard. Default: 0
RealMemory	RealMemory	Size of real memory on the node, MB. Default: 0
NodeHostname	NodeHostname	Default: as defined by Slurm's NodeName parameter.

...continues

...continued

Bright View Option	Slurm Option	Description
NodeAddr	NodeAddr	Default: as set by Slurm's NodeHostname parameter.
State	State	State of the node with user jobs. Possible Slurm values are: DOWN, DRAIN, FAIL, FAILING, and UNKNOWN. Default: UNKNOWN
Weight	Weight	The priority of the node for scheduling. Default: 0
Port	Port	Port that slurmd listens to on the compute node. Default: as defined by SlurmdPort parameter. If SlurmdPort is not specified during build: Default: 6818
TmpDisk	TmpDisk	Total size of Slurm's temporary filesystem, TmpFS, typically /tmp, in MB. TmpFS is the storage location available to user jobs for temporary storage. Default: 0
Options	extra options	Extra options that are added to slurm.conf

Further Slurm documentation is available:

- via man pages under /cm/shared/apps/slurm/current/man.
- as HTML documentation in the directory /usr/share/doc/slurm-17.02.11/html
- at the Slurm website at <http://slurm.schedmd.com/documentation.html>

Slurm is set up with reasonable defaults, but administrators familiar with Slurm can reconfigure the configuration file /cm/shared/apps/slurm/var/etc/slurm.conf using the JavaScript-based configuration generator in /usr/share/doc/slurm-17.02.11/html/configurator.html in a web browser. If the file becomes mangled beyond repair, the original default can be regenerated once again by re-installing the Slurm package, then running the script /cm/shared/apps/slurm/var/cm/cm-restore-db-password, and then running wlm-setup.

### Running Slurm

Slurm can be disabled and enabled with the wlm-setup tool (section 7.3) during package installation itself. Alternatively, role assignment and role removal also enables and disables Slurm from Bright View (section 7.4.1) or cmsh (section 7.4.2).

The Slurm workload manager runs these daemons:

#### 1. as servers:

- (a) slurmdbd: The database that tracks job accounting. It is part of the slurmdbd service.
- (b) slurmctld: The controller daemon. Monitors Slurm processes, accepts jobs, and assigns resources. It is part of the slurm service.
- (c) munged: The authentication (client-and-server) daemon. It is part of the munge service.

2. as clients:

- (a) `slurmd`: The compute node daemon that monitors and handles tasks allocated by `slurmctld` to the node. It is part of the `slurm` service.
- (b) `slurmstepd`: A temporary process spawned by the `slurmd` compute node daemon to handle Slurm job steps. It is not initiated directly by users or administrators.
- (c) `munged`: The authentication (client-and-server) daemon. It is part of the `munge` service.

Logs for the daemons are saved on the node that they run on. Accordingly, the locations are:

- `/var/log/slurmdbd`
- `/var/log/slurmd`
- `/var/log/slurmctld`
- `/var/log/munge/munged.log`

## 7.5.2 Configuring And Running SGE

There are several flavors of SGE available since around 2010.

The reference implementation for Bright Cluster Manager is Open Grid Scheduler (OGS), and is provided by the Bright Computing repository. References to SGE in the manuals therefore imply OGS. If other flavors of SGE are meant, then it is stated explicitly. For example, in the section for Univa Grid Engine (UGE, section 7.5.3), UGE means UGE, and not SGE.

### Configuring SGE

After installation and initialization, SGE has reasonable defaults, with `$SGE_ROOT` set to `/cm/shared/apps/sge/current`.

Administrators familiar with SGE can reconfigure it using the template files in `/cm/shared/apps/sge/var/cm/templates/`, which define the queues, host-groups and parallel environments that the `wlm-setup` utility uses. To configure the head node for use with SGE, the `install_qmaster` wrapper script under `$SGE_ROOT` is run. To configure a software image for use with SGE the `install_execd` wrapper script under `$SGE_ROOT` is run.

By default, the SGE application is installed in `/cm/shared/apps/sge/current`, the SGE documentation in `/cm/shared/docs/sge/current`, and job examples in `/cm/shared/examples/workload/sge/jobscripts/`.

### Running SGE

SGE can be disabled and enabled with the `wlm-setup` tool (section 7.3) during package installation itself. Alternatively, role assignment and role removal also enables and disables SGE from Bright View (sections 7.4.1) or `cmsh` (section 7.4.2).

The SGE workload manager runs the following two daemons:

1. an `sge_qmaster` daemon running on the head node. This handles queue submissions and schedules them according to criteria set by the administrator.
2. an `sge_execd` execution daemon running on each compute node. This accepts, manages, and returns the results of the jobs on the compute nodes.

Messages from the `qmaster` daemon are logged under:

`/cm/shared/apps/sge/current/default/spool/`

On the associated compute nodes the execution log `messages` exists (alongside other job tracking files and directories) at:

```
/cm/local/apps/sge/var/spool/node<number>/messages
```

where `node<number>` is the node name, for example:

```
node001, node002 ...
```

### SGE Submission And Execution Hosts

The login, submission, and execution role assignment and behavior for SGE follow the corresponding UGE examples for submission and execution hosts, as described on page 232.

### 7.5.3 Installing, Configuring, And Running UGE

The workload manager, Univa Grid Engine (UGE), is a flavor of SGE (section 7.5.2) developed by Univa. Bright Cluster Manager 8.0 supports integration with UGE versions 8.2.0 and higher at the time of writing of this section (October 2017). Older versions can also be supported, as detailed in the Bright Computing Knowledge Base (<https://kb.brightcomputing.com>).

UGE should be picked up directly from the Univa website at <http://www.univa.com>.

The installation and integration of UGE version 8.2.0 into Bright Cluster Manager 8.0 can be carried out as in the following steps:

1. These UGE tar.gz file collections should be downloaded from the Univa website to a directory on the head node:
  - Binary files:  
The 64-bit bundle  

```
ge-<uge_ver>-bin-lx-amd64.tar.gz
```

or the 32-bit bundle  

```
ge-<uge_ver>-bin-lx-x86.tar.gz
```
  - Common files: `ge-<uge_ver>-common.tar.gz`

Here `<uge_ver>` is the UGE version, for example: `8.2.0`

To avoid installation issues, a check should be done to ensure that during the download, the `tar.gz` files have not been renamed, or that their names not been changed to upper case. Both packages must be located in the same directory before installation.

If a failover setup already exists, then the installation should be done on the active head node in the steps that follow.

2. The `cm-uge` package should be installed from the Bright Computing repository:

#### Example

- For RHEL-based distributions:

```
[root@bright80 ~]# yum install cm-uge
```

- For SLES distributions:

```
[root@bright80 ~]# zypper install cm-uge
```



The package installs, amongst others, the following template files under `/cm/shared/apps/uge/var/cm/`:

- (a) An environment module template, `uge.module.template`
- (b) An installation configuration template, `inst_template.conf.template`
- (c) Some other template files for a default GE configuration, under the directory `templates`

The templates decide the configuration of UGE (section “*Configuring UGE*”, page 232).

The original files 2a and 2b, with the `.template` suffix, should never be modified by the administrator. The administrator can change the parameters affected by the installation configuration from their default values by copying these original files to the same directory without the `.template` suffix, and then editing the `.conf` file:

### Example

```
[root@bright80 ~]# cd /cm/shared/apps/uge/var/cm
[root@bright80 cm]# cp inst_template.conf.template inst_template.conf
[root@bright80 cm]# vi inst_template.conf
```

The copied file, `inst_template.conf`, can be changed by the administrator to decide the location of UGE software and how UGE handles jobs, if needed. The changed file overrides the settings suggested by the `.template` file, when the Bright Cluster Manager utility `wlm-setup` runs in the next step of the installation procedure.

Some of the values in the key-value pairs in the file are enclosed by percentage signs, `%`. Such flagged values should not be modified, since they are replaced by Bright Cluster Manager values by `wlm-setup` during installation.

Values not enclosed by percentage signs are not replaced by `wlm-setup`. Such unflagged values can, if needed, be tuned in the copied file by the administrator. These values are then kept by `wlm-setup` during installation, and used when UGE is run.

3. `wlm-setup` is run. The directory where the downloaded UGE files are located is specified with the `-a` option.

### Example

```
[root@bright80 ~]# wlm-setup -w uge -s -a /root/uge
```

The `wlm-setup` step is actually a wrapper here. It runs the `inst_sge` script that comes with UGE, as one of its actions. The `inst_sge` script should not normally be run directly in a cluster that runs Bright Cluster Manager.

4. The nodes are rebooted. The UGE command `qhost` then displays an output similar to:

### Example

```
[root@bright80 ~]# module load uge
[root@bright80 ~]# qhost
```

HOSTNAME	ARCH	NCPU	NSOC	NCOR	NTHR	NLOAD	...
global	-	-	-	-	-	-	...
node001	lx-amd64	8	1	1	8	0.01	...
node002	lx-amd64	8	1	1	8	0.01	...
node003	lx-amd64	8	1	1	8	0.01	...
node004	lx-amd64	8	1	1	8	0.01	...

The output in the preceding example has been truncated for this manual, for convenience.

### Configuring UGE

After installation and initialization, UGE has reasonable defaults, with `$SGE_ROOT` set to `/cm/shared/apps/uge/current`.

By default, the UGE application is installed in `/cm/shared/apps/uge/current`, and job examples are kept in `/cm/shared/examples/workload/sge/jobscripts/`.

### Running UGE

The UGE workload manager runs the following two daemons:

1. an `sge_qmaster` daemon running on the head node. This handles queue submissions and schedules them according to criteria set by the administrator.
2. an `sge_execd` execution daemon running on each compute node. This accepts, manages, and returns the results of the jobs on the compute nodes.

Messages from the qmaster daemon are logged under:

```
/cm/shared/apps/uge/current/default/spool/
```

On the associated compute nodes the execution log `messages` exists, alongside other job tracking files and directories, at:

```
/cm/local/apps/uge/var/spool/node<number>/messages
```

where `node<number>` is the node name, for example:

```
node001, node002 ...
```

### Submission And Execution Hosts

In UGE terminology, a *submission host*, or *submit host*, is a node that is allowed to submit jobs. An execution host is a node on which the computational part of the job is executed.

#### Standard Bright Cluster Manager Use

In a standard Bright Cluster Manager configuration, a *submission host* or *execution host* in UGE are configured as follows:

**Submission host:** If one of the following 2 conditions is met, in node or category properties for the host:

1. Both the `ugeserver` and `login` roles are assigned to the host
- or
2. Both the `ugeclient` and `login` roles are assigned to the host

then the host is managed by Bright Cluster Manager automatically as a submit host in UGE.

**Execution host:** A submit host is typically not configured by administrators to run jobs. Thus, in Bright Cluster Manager, a submit host cannot normally be assigned a `ugeclient` role, in order to run as an execution host. For unusual situations, the advanced configuration directive `AdditionalExecHosts` described next, can be used to allow the submit host to run as an execution host.

#### Non-standard Bright Cluster Manager Use

For non-standard configurations, where the UGE service or login service is managed outside of Bright Cluster Manager control, advanced configuration directives allow the cluster to be aware of the situation.

1. If the `ugeclient` role cannot be added, for instance due to the UGE service being managed outside of Bright Cluster Manager, then the submit hosts that are to be execution hosts can be specified in the advanced configuration directive, `AdditionalExecHosts`, in the `cmd.conf` file, as follows:

#### Example

```
AdvancedConfig = {"AdditionalExecHosts=node002,login01"}
```

2. If the host has a `ugeclient` role, but the cluster is configured so that no `login` role can be added to a node that is to be a submit host, for instance due to the login service being managed outside of Bright Cluster Manager, then the execution hosts that are to be submit hosts can be specified in the advanced configuration directive, `AdditionalSubmitHosts`, in the `cmd.conf` file, as follows:

#### Example

```
AdvancedConfig = {"AdditionalSubmitHosts=node002,login01"}
```

### Parallel Environments

A parallel environment (PE) allows the configuration of applications that use shared or distributed memory. The main—but not sole—purpose of a PE is to provide a job environment within which MPI applications can run, using various MPI libraries. PEs can be provided by the cluster software or hardware vendor, as well as distributed with UGE itself. Default PEs are provided for various MPI libraries, such as Open MPI, MVAPICH, and so on. The default PEs are automatically added to UGE when `wlm-setup` installs UGE.

The `CMDaemon` front ends, i.e. `cmsh` or Bright View, can be used to add, remove, or modify the existing PE. Each node or node category with a `ugeserver` role has a `Parallel Environments` submodule. In the `Parallel Environments` submodule, each PE is represented as a separate object with associated properties. For example, the following session displays Open MPI properties (some text elided):

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device roles bright80
[bright80->device[bright80]->roles]% assign ugeserver; commit
[bright80->...->roles[ugeserver]]% parallelenvironments
[bright80->...->roles[ugeserver]->parallelenvironments]% show openmpi
```

Parameter	Value
Accounting Summary	yes
Allocation Rule	\$round_robin
Control Slaves	yes
Daemon Forks Slaves	yes
Extra Parameter	
Job Is First Task	no
Master Forks Slaves	no
Name	openmpi
Slots	999999
Start Procedure Arguments	NONE
Stop Procedure Arguments	NONE
Urgency Slots	min
User Lists	NONE
User Lists	NONE

The values shown in the preceding example are defaults.

## Database Recovery

By default, Bright Cluster Manager configures UGE to use flat file, or classic spooling as its format for the `sge_qmaster` spool. Typically this can handle thousands of jobs a day without running into performance issues, and it is the current (May 2015) recommendation for stability reasons.

For larger clusters it is possible to use Berkeley DB as the spooling format. This comes with a number of utilities, some of which can be useful for UGE spool maintenance and debugging, such as `db_recover`, `db_verify`, and others.

The Berkeley DB utilities that come with UGE are modified versions of the ones that are shipped with the parent distribution Berkeley DB packages. The UGE versions include extra sanity tests for the UGE spool database, and it is best to use them instead of the standard versions. The utilities can be found in on the head node under:

```
/cm/shared/apps/uge/current/utilbin/lx-amd64/
```

This directory is not added to the `$PATH` when loading the UGE environment with `module load uge`.

The full Berkeley DB documentation for these tools is part of the UGE distribution. A local HTML format copy of the documentation is available at:

```
/cm/shared/apps/uge/current/doc/berkeleydb/db_*.html
```

## GPU And MIC Management

When managing host resources such as GPU or Xeon Phi (MIC) cards, UGE 8.1.0 and higher allows the accelerators to be configured via a resource map, RSMAP. This is a complex (`man (5) complex`) value type defined on the host. RSMAP values restrict how much of a resource is used concurrently from a host, attaches identifiers to the resource used, and assigns the identifiers to the jobs when they get dispatched to that host. Bright Cluster Manager automatically configures UGE execution hosts with `gpu` and `phi` RSMAP resources.

The `ugeclient` role can configure GPUs by using the following `cmsh` parameters:

- `GPU devices`: a list of GPU names that are attached to a job by UGE.
- `Gpus`: the number of GPUs on a host.

The `GPU devices` parameter has a higher priority than `Gpus`, so that if names are set in `GPU devices`, then they are always used.

GPUs can also be bound to particular CPU sockets and CPU cores, using a *topology mask*.

The mask is defined with a set of characters. In principle, the mask is applied to the computing units available for a device. The computing units correspond to processing units, and are grouped as CPU sockets, cores, and hardware threads. These correspond to the letters S, C, T. In the mask. An uppercase character allows a device to use a computing unit, while a lowercase character forbids it, as indicated by the following table:

Table 7.5.3: Mask Composition

Unit To Mask	Enable Unit with	Disable Unit with
Socket	S	s
Core	C	c
Hardware Thread	T	t

In practice, `s` and `t` are currently (May 2015) ignored, so that only cores can be masked.

Some mask examples:

- `SCcSCC`: This is a two-core two-socket system. The first socket cannot be used, while both cores on the second socket can be used.
- `SCcCCScCC`: This is a four-core two-socket system. The first socket has its first, third, and fourth cores available, and the second socket has its third and fourth cores available.

Some configuration examples from `cmsh` and the corresponding RSMAP complex attribute values on the host:

- Naming 2 GPUs:

```
[root@bright80 ~]# cmsh
[bright80]% category roles default
[bright80->device[bright80]->roles]% assign ugeclient; commit
[bright80->device[bright80]->roles[ugeclient]] show | grep -i gpu
GPU devices                gpu0 gpu1
GPUs                        2
```

The RSMAP attribute value is then:

`GPU=2 (gpu0 gpu1)`

- Allow GPUs to use only different sockets:

```
[bright80->device[bright80]->roles[ugeclient]]% show | grep -i gpu
GPU devices                gpu0:SCCCCScccc gpu1:ScCCCSCCCC
GPUs                        0
```

The RSMAP attribute value is then:

`GPU=2 (gpu0:SCCCCScccc gpu1:ScCCCSCCCC)`

- Allow Xeon Phi resources to set up sockets in a spaced-out way:

Here, 4 MICs `mic0` to `mic3` have their cores enabled as follows: The first core of `mic0`, the second core of `mic1`, the third core of `mic2` and the fourth core of `mic3`. The remaining cores of the MICs are disabled:

```
[bright80->device[bright80]->roles[ugeclient]]% show | grep mic
MIC devices                mic0:SCccc mic1:ScCcc mic2:ScCCc mic3:ScCCc
```

As is seen here, MICs are set up very much like GPUs, and also within the `ugeclient` role. The only differences are that the parameters that are set differ according to the accelerator used:

- while for GPUs topology masks are set for the `GPU devices` parameter, for MICs topology masks are set for the `MIC devices` parameter
- while for GPUs the number of GPUs is manually specified in the `Gpus` parameter, for MICs the number of MICs is counted automatically and there is no equivalent parameter.

The RSMAP attribute value in this example is then:

`MIC=4 (mic0:SCccc mic1:ScCcc mic2:ScCCc mic3:ScCCc)`

Further detailed information about RSMAP and topology mask usage can be found in the *Univa Grid Engine Administrator's Guide*.

#### 7.5.4 Configuring And Running Torque

Torque is a resource manager controlling the jobs and compute nodes it talks with. Torque has its own built-in scheduler, but since this is quite basic, the open source Maui and the proprietary Moab schedulers are recommended alternatives.

### Configuring Torque

The Torque package is installed, but not set up by default on Bright Cluster Manager 8.0. If it is not set up during installation (figure 3.22 of the *Installation Manual*), it can be set up later on using the `wlm-setup` tool (section 7.3).

The execution daemon, `pbs_mom` is already in the software images by default and does not need to be installed, even if Maui or Moab are added.

The Torque services can be enabled and disabled via role assignment as described in section 7.4. Resources such as the number of GPUs are configured in that section too for the node or node category in order to set up the corresponding resource definitions in the Torque configuration files.

Torque software components are installed in `/cm/shared/apps/torque/current`, also referred to as the `PBS_HOME`. The `torque` environment module, which sets `$PBS_HOME` and other environment variables, must be loaded in order to submit jobs to Torque. The `man` pages for Torque are then accessible, with `$MANPATH` set to `$PBS_HOME/man`.

Torque documentation is available at the Adaptive Computing website at <http://www.adaptivecomputing.com/resources/docs/>, including various versions of the Torque administrator manual.

Torque examples are available under `/cm/shared/examples/workload/torque/jobscripts/`

### Installing The Maui Scheduler Package

If Maui is to be installed, the Maui scheduler source version 3.3.1 must be picked up from the Adaptive Computing website at <http://www.adaptivecomputing.com/support/download-center/maui-cluster-scheduler/> (registration required). The source file must be installed over the zero-sized placeholder file on the head node at `/usr/src/redhat/SOURCES/maui-3.3.1.tar.gz`.

Maui documentation is available at <http://docs.adaptivecomputing.com/maui/index.php>.

The RPM file is built from the source and patches are applied, by running the `rpmbuild` command on the head node using the Bright Maui spec file as follows:

```
rpmbuild -bb /usr/src/redhat/SPECS/maui.spec
```

The installation can then be done with:

```
rpm -i /usr/src/redhat/RPMS/x86_64/maui-3.3.1-58_cm8.0.x86_64.rpm
```

The exact version of the rpm file to install may differ from the version shown here. The version freshly generated by the `rpmbuild` process is what should be used.

CMDaemon needs to be aware the scheduler is Maui for nodes in a Torque server role. This can be configured using `wlm-setup` to enable the `torquemaui` option (as shown in section 7.3.1), or using Bright View to set the scheduler from the Roles window (as shown in section 7.4.1), or using `cmsh` to assign the scheduler from within the assigned `torqueserver` role (as shown in section 7.4.2).

### Installing The Moab Scheduler Package

Moab is not installed by default in Bright Cluster Manager 8.0. Moab and related products must be purchased from Adaptive Computing. Bright Cluster Manager 8.0 expects the init script for Moab to be located in the file `/etc/init.d/moab`. Other files such as the Moab binaries and libraries can be installed in `/cm/shared/apps/moab/<moab.version>` or any other preferred location.

The Moab install documentation should be followed carefully. Issues needing attention during the Moab installation, at least for the Moab version 7 series, include the following: if using Torque and if the `--with-torque=<path>` option is not specified, then library paths for Torque and Moab must be set in Moab's `ldconfig` configuration file.

This can be by appending them with, for example:

```
appsdir="/cm/shared/apps"
```

```
ldsodir="/etc/ld.so.conf.d"
echo $appsdir/torque/current/lib >> $ldsodir/moab.conf
echo $appsdir/moab/<version>/lib >> $ldsodir/moab.conf
ldconfig
```

Alternatively, the following lines can be added at the beginning of the Moab init.d script:

```
export LD_LIBRARY_PATH=/cm/shared/apps/torque/current/lib:$LD_LIBRARY_PATH
export LD_LIBRARY_PATH=/cm/shared/apps/moab/<version>/lib:$LD_LIBRARY_PATH
```

CMDaemon needs to be aware the scheduler is Moab for nodes in a Torque server role. This can be configured using `wlm-setup` to enable the `torquemoad` option (section 7.3.1), or using Bright View to set the scheduler role (as shown in section 7.4.1) or using `cmsh` to assign the scheduler from within the assigned `torqueserver` role (as shown in section 7.4.2).

### Running Torque And Schedulers

The Torque resource manager runs the following daemons:

1. a `pbs_server` daemon. This handles submissions acceptance, and talks to the execution daemons on the compute nodes when sending and receiving jobs. It writes logs to the `/cm/shared/apps/torque/var/spool/server_logs` directory on its node. Queues for this service are configured with the `qmgr` command.
2. a `pbs_mom` execution daemon running on the nodes that are assigned the compute role. This accepts, manages, and returns the results of jobs on the compute nodes. It writes logs to the `/cm/local/apps/torque/var/spool/mom_logs` directory on the compute nodes.
3. a `trqauthd` authentication daemon, in version 4.0 and above. This service is used by Torque clients to authorize user connections to the `pbs_server` server daemon. When `torqueclient` or `torqueserver` roles are assigned in `cmsh`/Bright View, the authentication service is added automatically to relevant nodes so that user commands can be executed on those nodes. This allows the schedulers health check to execute Torque user utilities on compute nodes.

If the `torqueserver` is running as an external server (pages 222, 224), then `trqauthd` must run on the external server too.

**Job submission from a non-computing node:** The `trqauthd` daemon is also needed by Torque users on a job submit node, if the submit node does not have a Torque role (`torqueclient` or `torqueserver`) assigned to it already. For example, some customized clusters use a category of node that is a login node. So, there may be login nodes named `<login01>`, `<login02>`, and so on. The login node does no computation itself, but users simply log into it to submit jobs. In that case, a minimal way to change the configuration of the node is as follows:

- (a) The submit hosts are added to the Torque configuration database so that Torque knows about them:

#### Example

```
qmgr -c 'set server submit_hosts = <login01>'
qmgr -c 'set server submit_hosts += <login02>'
qmgr -c 'set server submit_hosts += <login03>'
...
```

The names become part of the `qmgr` database configuration. This configuration can be viewed by running:

```
qmgr -c "p s"
```

- (b) The `/etc/init.d/trqauthd` script is copied from the head node to the login/submit node software image. Running `imageupdate` then places the script on the running login/submit nodes. Adding the `trqauthd` service to the list of services being monitored is recommended. Adding a service so that it is monitored and automatically restarted if needed is explained in section 3.11.

Jobs are however not be executed unless the scheduler daemon is also running. This typically runs on the head node and schedules jobs for compute nodes according to criteria set by the administrator. The possible scheduler daemons for Torque are:

- `pbs_sched` if Torque's built-in scheduler itself is used. It writes logs to the `/cm/shared/apps/torque/var/spool/sched_logs` directory.
- `maui` if the Maui scheduler is used. It writes logs to `/cm/shared/apps/maui/var/spool/log`.
- `moab` if the Moab scheduler is used. Log files are written to the spool directory. For example: `/cm/shared/apps/moab/moab.version/spool/moab.log` if Moab is installed in `/cm/shared/apps/moab/<moab.version>`.

### 7.5.5 Configuring And Running PBS Pro

#### PBS Pro Versions

Bright Cluster Manager provides two versions of PBS Pro:

- PBS Pro. This is the commercial version. The PBS Pro commercial edition is available under a 90-day trial license.
- PBS Pro Community Edition (or CE). This is the edition with community support (<http://pbspro.org>).

Both versions can be installed as a selection option during Bright Cluster Manager 8.0 installation, at the point when a workload manager must be selected (figure 3.22 of the *Installation Manual*). Alternatively they can be installed later on, when the cluster has already been set up.

When no particular edition is specified in the Bright Cluster Manager documentation, then the text is valid for both editions.

If Bright Cluster Manager has already been set up without PBS Pro, then the `wlm-setup` tool (section 7.3) should be used to install and initialize a PBS Pro edition.

#### Installing PBS Pro

Both PBS Pro commercial and PBS Pro CE can be installed and initialized via `wlm-setup`:

#### Example

```
[root@bright80 ~]# wlm-setup -w pbspro -s
```

or

```
[root@bright80 ~]# wlm-setup -w pbspro-ce -s
```

Installing one automatically disables the other.

The software components are installed and initialized by default under the `PBS_HOME` directory, which is either:

```
/cm/shared/apps/pbspro/current
```

or

```
/cm/shared/apps/pbspro-ce/current
```

as appropriate.

Users must load the `pbspro` environment module, which sets `PBS_HOME` and other environment variables, in order to use either edition of PBS Pro.



### PBS Pro Configuration

PBS Pro documentation is available at <http://www.pbsworks.com/SupportDocuments.aspx>.

By default, PBS Pro examples are available under the directory `/cm/shared/examples/workload/pbspro/jobscripts/`

Some PBS Pro configuration under Bright Cluster Manager can be done using roles. The roles are the same for both the commercial and the CE editions:

- In Bright View the roles setting allows the configuration of PBS Pro client and server roles.
  - For the PBS Pro server role, the role is enabled, for example on a head node `bright80`, via a clickpath of:  
 Devices→Head Nodes→`bright80`→Settings→Roles→Add→PBS pro server role
    - \* Within the role window for the server role, its installation path and server spool path can be specified.
  - For the PBS Pro client role, the role is enabled along a similar clickpath, just ending at PBS pro client role. The number of slots, GPUs and other properties can be specified, and queues can be selected.
- In `cmsh` the client and server roles can be managed for the individual nodes in `device mode`, or managed for a node category in `category mode`.

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device roles bright80
[bright80->device[bright80]->roles]% assign pbsproserver; commit
[bright80->device[bright80]->roles[pbsproserver]]% show
Parameter                               Value
-----
External Server                          no
Name                                     pbsproserver
Provisioning associations                 <0 internally used>
Revision
Type                                     PbsProServerRole
Prefix                                  /cm/shared/apps/pbspro/current
Spool                                   /cm/shared/apps/pbspro/var/spool
...
[bright80->device[bright80]->roles[pbsproserver]]% set prefix /srv/pbspro/current; commit
```

Cloudbursting with cluster extension may need special handling for PBS Pro. If this feature is needed, then the administrator should contact Bright Computing support via the website <https://support.brightcomputing.com>.

Further configuration of PBS Pro is done using its `qmgr` command and is covered in the PBS Pro documentation.

### Running PBS Pro

PBS Pro runs the following four daemons:

1. a `pbs_server` daemon running, typically on the head node. This handles submissions acceptance, and talks to the execution daemons on the compute nodes when sending and receiving jobs. It writes logs to the `var/spool/server_logs/` directory that is under `/cm/shared/apps/pbspro` or `/cm/shared/apps/pbspro-ce` on the nodes it is associated with. Queues for this service are configured with the `qmgr` command.

2. a `pbs_sched` scheduler daemon, also typically running on the head node. It writes logs to the `var/spool/sched_logs/` directory under `/cm/shared/apps/pbspro` or `/cm/shared/apps/pbspro-ce`.
3. a `pbs_mom` execution daemon running on each compute node. This accepts, manages, and returns the results of jobs on the compute nodes. It writes logs on the head node to the `var/spool/mon_logs/` directory under `/cm/shared/apps/pbspro` or `/cm/shared/apps/pbspro-ce`, and to `/cm/local/apps/pbspro/var/spool/mom_logs/` on the compute nodes.
4. a `pbs_comm` communication daemon usually running on the head node. This handles communication between PBS Pro daemons, except for server-to-scheduler and server-to-server daemons communications. It writes logs to the head node under the relative directory `var/spool/comm_logs/`, under `/cm/shared/apps/pbspro` or `/cm/shared/apps/pbspro-ce`, and writes logs to the compute nodes under `/cm/local/apps/pbspro/var/spool/comm_logs/`.

### 7.5.6 Installing, Configuring And Running OpenLava

*At the time of writing (November 2016), OpenLava from version 3 onward was subject to a copyright infringement claim by IBM. At the request of the OpenLava founder, its packages are now no longer distributed with Bright Cluster Manager. Text in this section that refers to such packages is now invalid until the situation is resolved.*

#### Prerequisites To Installing OpenLava

The OpenLava version 3.3.3 packages are available from the Bright Cluster Manager repositories, and can be installed on the head node, or active head node in a failover setup, with:

#### Example

```
[root@bright80 ~]# yum install openlava
```

Similarly, the client package can be installed in a software image such as `default-image` with:

#### Example

```
[root@bright80 ~]# yum --installroot=/cm/images/default-image install openlava-client
```

The `updateprovisioners` (section 5.2.4) and `imageupdate` (section 5.6.2) commands can be used to implement the changes on all running nodes.

#### Installing OpenLava

After package installation has been carried out, OpenLava installation can be done on the cluster with `wlm-setup` (section 7.3):

```
wlm-setup -w openlava -s
```

#### Configuring OpenLava

After installation of OpenLava using `wlm-setup` (section 7.3), OpenLava software components are installed in `/cm/shared/apps/openlava/current`.

Documentation for OpenLava is available via `man` pages under `/cm/shared/apps/openlava/current/share/man`. Further documentation is available online at: <http://www.openlava.org/documentation/documentation.html>.

Reasonable defaults are used for OpenLava, but administrators familiar with OpenLava can reconfigure it by modifying the configuration files under `/cm/shared/apps/openlava/var/etc/`.

The OpenLava environment module can be set to automatically load for users as described in section 2.2.3.

Within the OpenLava module environment, running the OpenLava command `bhosts` displays something like:

```
[root@bright80 ~]# bhosts
HOST_NAME    STATUS    JL/U    MAX    NJOBS    RUN    SSUSP    USUSP    RSV
node001      ok        -       2       0       0       0       0       0
node002      ok        -       2       0       0       0       0       0
node003      unavail   -       1       0       0       0       0       0
node004      closed    -       1       0       0       0       0       0
node005      ok        -       1       0       0       0       0       0
bright80     ok        -       0       0       0       0       0       0
```

### Running OpenLava

OpenLava can be disabled and enabled with the `wlm-setup` tool (section 7.3) during package installation itself. Alternatively, role assignment and role removal also enables and disables OpenLava from Bright View (section 7.4.1) or `cmsh` (section 7.4.2).

All compute nodes (sometimes called passive OpenLava masters in OpenLava terminology) have the same set of daemons. One node (it can be a regular node or it can be a head node) takes on the role of active OpenLava master. It is enough to assign only the `openlavaserver` role to each node or node category that is running the daemons. The nodes used to submit an OpenLava job take on the `openlavaclient` role, but do not have the daemons running on them.

The OpenLava workload manager daemons are:

- daemons that can run on the active OpenLava master node:
  - `mbatchd`: The active OpenLava master batch daemon. Started by the batch daemon on a passive OpenLava master. Responsible for the overall state of OpenLava jobs. Receives job submissions, and information query requests. Manages jobs held in queues. Dispatches jobs to hosts as determined by `mbschd`. It is a part of the `openlava` service.
  - `mbschd`: The batch scheduler daemon. Works with `mbatchd`. Started by `mbatchd`. Makes scheduling decisions based on job requirements and policies.
- daemons that can run on both on the active and passive OpenLava master nodes):
  - `sbatchd`: The standard batch `openlava` daemon. It is a part of the `openlava` service.
  - `lim`: The load information manager daemon. Collects built-in load indices that reflect the load situations of CPU, memory, disk space, I/O, and interactive activities on individual hosts. It is a part of the `openlava` service.
  - `res`: The remote execution manager daemon. Executes user tasks on remote hosts. It is a part of the `openlava` service.
  - `pim`: The process information manager daemon. Is responsible for monitoring all jobs and monitoring every process created for all jobs running on the node.

`lim`, `res`, and `sbatchd` daemons maintain log files in:

```
/cm/local/apps/openlava/var/log
```

Batch accounting files are shared by all potential active OpenLava master nodes. The spools are stored in the `work` directory:

```
/cm/shared/apps/openlava/var/work/logdir.
```

### 7.5.7 Installing, Configuring, And Running LSF

IBM prefers to make LSF available directly from their Passport Advantage Online website, which is why it is not available as an option in the installation carried out by Bright Cluster Manager 8.0 in figure 3.22 of the *Installation Manual*.

## Installing LSF

The workload manager LSF versions 9 or 10 are installed and integrated into Bright Cluster Manager 8.0 with the following steps:

1. The following LSF files should be downloaded from the IBM web site into a directory on the head node:
  - Installation package: `lsf<lsf_ver>_lsfinstall_linux_<cpu_arch>.tar.Z`
  - Distribution package: `lsf<lsf_ver>_linux<kern_ver>-glibc<glibc_ver>-<cpu_arch>.tar.Z`
  - Documentation package: `lsf<lsf_ver>_documentation.tar.Z`
  - License file: `platform_lsf_<lic_type>_entitlement.dat`

Here:

- `<lsf_ver>` is the LSF version, for example: 9.1.1
- `<kern_ver>` is the Linux kernel version, for example: 2.6
- `<glibc_ver>` is the glibc library version, for example: 2.3
- `<cpu_arch>` is the CPU architecture, for example: x86\_64
- `<lic_type>` is the license type, for example: std

A check should be done to ensure that the `tar.Z` files have not been renamed or had their names changed to lower case during the download, in order to avoid installation issues. All 4 files must be in the same directory before installation.

In case of an existing failover setup, the installation is done on the active head node.

2. The `cm-lsf` package must be installed from the Bright Computing repository:

```
[root@bright80 ~]# yum install cm-lsf    #RHEL-based distributions
```

or

```
[root@bright80 ~]# zypper install cm-lsf    #SLES distributions.
```

The `cm-lsf` package contains a template environment module file and an installation configuration file. The installation configuration file may be tuned by administrator if required. It is passed to the `lsfinstall` script distributed with LSF, which is executed by `wlm-setup` during setup. To change the default values in the installation configuration file, the administrator should copy the template file first and then change the copied file:

```
[root@bright80 ~]# cd /cm/shared/apps/lsf/var/cm/
[root@bright80 cm]# cp install.config.template install.config
[root@bright80 cm]# vi install.config
```

The `install.config` file can be changed by the administrator to decide the location of LSF software and some other LSF configuration options, if needed. The changed file overrides the settings suggested by the `.template` file, when the Bright Cluster Manager utility `wlm-setup` runs in the next step of the installation procedure.

A few of the values in the key-value pairs in the file are enclosed by percentage signs, `%`. Such “flagged” values should not be modified, since they are replaced by Bright Cluster Manager values by `wlm-setup` during installation.

Values not enclosed by percentage signs are left alone by `wlm-setup`. Such “unflagged” values can, if needed, be tuned in the file copy by the administrator. These values are then kept by `wlm-setup` during installation, and used when LSF is run.

3. `wlm-setup` is run. The directory where the LSF files were downloaded is specified with the `-a` option.

#### Example

```
[root@bright80 ~]# wlm-setup -w lsf -s -a /root/lsf
```

4. The nodes are then rebooted, and the LSF command `bhosts` then displays an output similar to:

#### Example

```
[root@bright80 ~]# module load lsf
[root@bright80 ~]# bhosts
```

HOST_NAME	STATUS	JL/U	MAX	NJOBS	RUN	SSUSP	...
bright80	ok	-	2	0	0	0	...
head2	ok	-	0	0	0	0	...
node001	ok	-	1	0	0	0	...
node002	ok	-	1	0	0	0	...
node003	unavail	-	1	0	0	0	...
node004	closed	-	1	0	0	0	...
node005	ok	-	1	0	0	0	...

The output in the preceding example has been truncated for this manual, for convenience.

The installation status can be checked with:

```
[root@bright80 ~]# /etc/init.d/lsf status
Show status of the LSF subsystem
lim (pid 21138) is running...
res (pid 17381) is running...
sbatchd (pid 17383) is running...
```

while default queues can be seen by running:

```
[root@bright80 ~]# module load lsf
[root@bright80 ~]# bqueues
```

QUEUE_NAME	PRIO	STATUS	MAX	JL/U	JL/P	...
owners	43	Open:Active	-	-	-	...
priority	43	Open:Active	-	-	-	...
night	40	Open:Active	-	-	-	...
chkpnt_rerun_qu	40	Open:Active	-	-	-	...
short	35	Open:Active	-	-	-	...
license	33	Open:Active	-	-	-	...
normal	30	Open:Active	-	-	-	...
interactive	30	Open:Active	-	-	-	...
idle	20	Open:Active	-	-	-	...

The output in the preceding example has been truncated for this manual, for convenience.

### Configuring LSF

**LSF server configuration:** After installation, the following `CMDaemon` settings can be specified for the LSF server role:

- `prefix`: this sets the path to the root of the LSF installation.
- `var`: this sets the path to the `var` directory of LSF

These settings can be specified as follows:

- **Within Bright View:** For example for a head node `bright80`, via a clickpath of `Devices→Head Nodes→bright80→Settings→Roles→Add→LSF server role`
- **Within `cmsh`:** For a particular category in the `category` mode, or a particular device in the `device` mode, the `roles` submode is chosen. Within the `roles` submode, the `lsfserver` parameter can be set. The following example shows how to set the `LSF prefix` parameter for the default category.

### Example

```
[root@bright80~]# cmsh
[bright80]% category use default; roles
[bright80->category[default]->roles]% assign lsfserver; commit
[bright80->...[lsfserver]]% set prefix /cm/shared/apps/lsf/current2
[bright80->...[lsfserver*]]% commit
```

**LSF client configuration:** After installation, the following `CMDaemon` settings can be specified for the LSF client role:

- **Queues** A restricted list of queues named “`qname1`”, “`qname2`” and so on can be set using a command syntax like this instead:

```
set queues <qname1> [<qname2> ...]
```

Alternatively, these, and other queues can be added or deleted using Bright View (section 7.6.2) or `cmsh` (section 7.7.2).




Figure 7.4: Bright View access to LSF configuration options via roles window options

- **Options** The options that can be set for a regular node `node001`, via figure 7.4, reached via a clickpath of `Devices→Physical Nodes[node001]→Edit→Settings→Roles→Add→LSF client role` are:

- **Slots:** The number of CPUs per node. By default LSF tries to determine the value automatically. If the number of slots is set to 0, then the node becomes an LSF submit host, so that no jobs can run on the host, but users can submit their jobs from this host using the LSF utilities.
- **GPUs:** The number of GPUs per node
- **Queues:** All queues.
- **Advanced button:** This brings up a dialogue that allows GPU devices to be added.

From `cmsh` these properties are accessible from within the appropriate node or category `roles` submode (section 7.4.2).

**Submission hosts:** By default, all compute nodes to which the `lsfclient` role is assigned, also become submission hosts. This happens because when the `Slots` parameter is not set to 0, then Bright Cluster Manager configures the node as a server (in the LSF terminology). This means that LSF users can submit their jobs from those compute nodes.

If the administrator wants to allow users to submit their jobs from a non-compute node—for example from a login node—then the following steps can be followed to configure submission:

1. The `lsfclient` role is assigned to that node and the parameter `Slots` is set to 0 in the role.
2. The `lsf` service is stopped by the administrator using `cmsh` or Bright View. It must not be stopped by system utilities such as `systemctl`, because Bright Cluster Manager starts the service again automatically if the `lsfclient` role has been assigned to the node.
3. The LSF cluster `<cluster name>` has a configuration file `/cm/shared/apps/lsf/var/conf/lsf.cluster.<cluster name>` inside which the administrator must specify a value for `model` and a value for `type` for the node. These values are specified in the appropriate columns of the `Host` section of the configuration file. The possible values that can be specified are defined in the appropriate section of `/cm/shared/apps/lsf/var/conf/lsf.shared`. Specifying the values is needed because the `lsf` service is stopped, and LSF cannot then pick up those values from the service.
4. On the LSF master node, the administrator must run `lsconfig reconfig` in order to apply the change in the cluster configuration file.

Configuring a node according to the preceding steps then allow users to submit their jobs from that node, but none of the submitted jobs gets scheduled to run on that node.

**Data-Aware Scheduling With `cmsub`:** The ability to use `cmsub` to submit jobs to cloud nodes, as described in section 4.7 of the *User Manual*, is called *data-aware scheduling*. Data-aware scheduling is enabled for LSF as follows:

1. If LSF is not under the control of `CMDaemon` because the directive `FreezeChangesToLSFConfig` (page 596) is active, and if the `cloudtransfers` queue does not exist in LSF, then the queue should be added manually into the following configuration file:

```
$LSF_ENVDIR/lsbatch/<clustername>/configdir/lsb.queues
```

The default value for `$LSF_ENVDIR` is `/cm/shared/apps/openlava/var/etc/`.

2. In order to run the cloud prolog script as the root user, `/etc/lsf.sudoers` must be configured. By default this file does not exist. Its ownership must be root. It must also have read-write permissions for root only, i.e. its unix permissions can be set with `chmod 600 /etc/lsd.sudoers`. To execute the `PRE_EXEC` script as root, `LSB_PRE_POST_EXEC_USER=root` should be set in `lsf.sudoers`:

```
[root@bright80 ~]$ echo "LSB_PRE_POST_EXEC_USER=root" >> /etc/lsf.sudoers
[root@bright80 ~]$ chmod 600 /etc/lsf.sudoers
```

3. The changes are applied by restarting the hosts:

```
[root@bright80 ~]$ badmin hrestart all
```

**Further configuration:** For further configuration the *Administering Platform LSF* manual provided with the LSF software should be consulted.

### Running LSF

Role assignment and role removal enables and disables LSF from Bright View (sections 7.4.1) or `cmsh` (section 7.4.2).

An active LSF master (typically, but not necessarily on a head node) has the following LSF-related processes or services running on it:

Process/Service	Description
<code>res</code>	Remote Execution Server*
<code>sbatchd</code>	client batch job execution daemon*
<code>mbatchd</code>	master batch job execution daemon
<code>eauth</code>	External Authentication method
<code>lim</code>	Load Information Manager*
<code>pim</code>	Process Information Manager*
<code>pem</code>	Process Execution Manager*
<code>vemkd</code>	Platform LSF Kernel Daemon
<code>egosc</code>	Enterprise Grid Orchestrator service controller
<code>mbschd</code>	master batch scheduler daemon

\*These services/processes run on compute nodes.

Non-active LSF-masters running as compute nodes run the processes marked with an asterisk only.

Logs for LSF processes and services are kept under `/cm/shared/apps/lsf/log/` (or `$LSF_TOP/log/` if the value of `$LSF_TOP` during installation is other than the recommended `/cm/shared/apps/lsf/`).

## 7.6 Using Bright View With Workload Management

Viewing the workload manager services from Bright View is described in section 7.4.3. The HPC (High Performance Computing) icon, which looks like a speedometer, is the Bright View resource that allows access to:

- jobs
- queues

These items are described next.

### 7.6.1 Jobs Display And Handling In Bright View

The clickpath `HPC→Jobs` opens a window that displays displays a list of job IDs, along with the scheduler, user, queue, and status of the job



### 7.6.2 Queues Display And Handling In Bright View

The clickpath `HPC`→`Job queues` displays a list of queues available (figure 7.5).




Figure 7.5: Workload Manager Queues

Queues can be added or deleted. An `Edit` button allows existing queue parameters to be set, for example as in figure 7.6.




Figure 7.6: Workload Manager Queue Parameters Configuration

## 7.7 Using `cmsh` With Workload Management

### 7.7.1 Jobs Display And Handling In `cmsh: jobs` Mode

#### `jobs` Mode In `cmsh`: Top Level

At the top level of `jobs` mode, the administrator can view all jobs regardless of scheduler type with the `list` command:

#### Example

```
[bright80->jobs]% list
Type          Job ID      User          Queue          Status
-----
SGEJob        620          maud          all.q           r
SGEJob        621          maud          qw              qw
TorqueJob     90.bright80+ maud          hydroq          R
```

Also within the jobs mode, the hold, release, suspend, resume, show, and remove commands act on jobs when used with a specified scheduler type and job ID. Continuing with the example:

```
[bright80->jobs]% suspend torque 90.bright80.cm.cluster
Success
[bright80->jobs]% list
Type          jobid      User          Queue          Status
-----
SGEJob        620          maud          all.q           r
SGEJob        621          maud          qw              qw
TorqueJob     90.bright80+ maud          hydroq          S
```

While at the jobs mode top level, the suspended job here can be made to resume using suspend's complementary command—resume. However, resume along with the other commands can also be executed within a scheduler submode, as is shown shortly.

#### jobs **Mode In** cmsh: **The scheduler Submode**

Setting the scheduler type sets the scheduler submode, and can be done thus (continuing with the preceding example):

```
[bright80->jobs]% scheduler torque
[bright80->jobs(torque)]%
```

The submode restriction can be unset with: scheduler "".

The top level job mode commands executed within the scheduler submode then only apply to jobs running under that scheduler. The list and resume commands, for example, then only apply only to jobs running under torque (continuing with the example):

```
[bright80->jobs(torque)]% list; !#no sge jobs listed now - only torque
Type          Job ID      User          Queue          Status
-----
TorqueJob     90.bright80+ maud          hydroq          S
[bright80->jobs(torque)]% resume 90.bright80.cm.cluster; !#torque job
Success
[bright80->jobs(torque)]% list; !#only torque jobs
Type          Job ID      User          Queue          Status
-----
TorqueJob     90.bright80+ maud          hydroq          R
```

#### jobs **Mode in** cmsh: **The show Command**

The show command for a particular scheduler and job lists details of the job. Continuing with the preceding example:

```
[bright80->jobs(torque)]% show 90.bright80.cm.cluster;
Parameter          Value
-----
Arguments          -q hydroq /home/maud/sleeper.sh
Executable
In queue
Job ID             90.bright80.cm.cluster
```

```

Job name           sleeper.sh
Mail list
Mail options       a
Maximum wallclock time 02:00:00
Memory usage       0
Nodes              node001
Notify by mail     yes
Number of processes 1
Priority           0
Queue             hydroq
Run directory      /home/maud
Running time       809
Status            R
Stderr file        bright80.cm.cluster:/home/maud/sleeper.sh.e90
Stdout file        bright80.cm.cluster:/home/maud/sleeper.sh.o90
Submission time    Fri Feb 18 12:49:01 2011
Type              TorqueJob
User              maud

```

#### jobs Mode in cmsh: The list Command

The `list` command lists the currently pending and running tasks, and recently completed tasks. For example, on a cluster with nodes `node001` to `node004` there may be a job ID of 27 that is running. The output of `list` might then be:

#### Example

```

[bright80->jobs(slurm)]% list
Type   Job ID User  Queue Running time Status      Nodes
-----
Slurm  25     fred  defq  2s          COMPLETED node001..node004
Slurm  26     fred  defq  22s         COMPLETED node001..node004
Slurm  27     fred  defq  10s         RUNNING    node001..node004
Slurm  28     fred  defq  0s          PENDING
Slurm  29     fred  defq  0s          PENDING

```

#### Example

#### jobs Mode in cmsh: The filter Command

The `filter` command lists all jobs, and offers ways to filter the displayed output.

The `filter` command without any options is a bit like an extension of the `list` command in that it lists currently pending and running jobs, although in a different format. However, in addition, it also lists past tasks, with their start and end times.

An example of the output format, somewhat simplified for clarity, is:

#### Example

```

[bright80->jobs(slurm)]% filter
Job ID Job name      User  Queue Submit time Start time End time Nodes      Exit code
-----
2      hello           fred  defq  15:00:51  15:00:51  15:00:52 node001      0
3      mpirun          fred  defq  15:03:17  15:03:17  15:03:18 node001      0
...
25     slurmhello.sh    fred  defq  16:17:30  16:17:31  16:17:33 node001..node004 0
26     slurmhello.sh    fred  defq  16:18:39  16:18:40  16:19:02 node001..node004 0
27     slurmhello.sh    fred  defq  16:18:41  16:19:03  16:19:25 node001..node004 0
28     slurmhello.sh    fred  defq  16:18:41  N/A       N/A       node001..node004 0
29     slurmhello.sh    fred  defq  16:18:42  N/A       N/A       node001..node004 0

```

In the preceding example, the start and end times for jobs 28 and 29 are not yet available because the jobs are still pending.

Because all jobs—historic and present—are displayed by the `filter` command, it means that finding a particular job in the output displayed can be hard.

The following options to the `filter` command are therefore made available in order to find a particular job:

- `--pending`: Display only all pending jobs.
- `--running`: Display only all running jobs.
- `--ended`: Display only all jobs that ended successfully.
- `--failed`: Display only all jobs that failed.
- `-u|--user`: Display only jobs for a specified user `user`.

It may take about a minute for CMDaemon to become aware of job data. This means that, for example, a job submitted 10s ago may not show up in the output.

Further options to `filter` can be seen by running the command `help filter` in jobs mode.

#### jobs **Mode in cmsh: The statistics Command**

The `statistics` command without any options displays an overview of states for all past and present jobs:

##### Example

```
[bright80->jobs]% statistics
```

Interval	User	Group	Account	Pending	Running	Finished	Error	Nodes
N/A				0	1	20	0	13

The jobs statistics can be split across users. An example of the output format in this case, somewhat simplified for clarity, is:

##### Example

```
[bright80->jobs(slurm)]% statistics --user
```

User	Pending	Running	Finished	Error	Nodes
alice	0	0	2	0	1
bob	0	0	5	0	4
charline	0	1	2	0	2
dennis	0	0	6	0	4
eve	0	0	4	0	1
frank	0	0	1	0	1

The job statistics can be displayed over various time periods, if there are jobs within the period. An example of the output format, somewhat simplified for clarity, for an interval of 60s is:

##### Example

```
[bright80->jobs(slurm)]% statistics --interval 60
```

Interval	Pending	Running	Finished	Error	Nodes
15:00:00 - 15:01:00	0	0	1	0	1
15:03:00 - 15:04:00	0	0	7	0	7
15:04:00 - 15:05:00	0	0	1	1	2

15:06:00 – 15:07:00	0	0	3	0	7
15:07:00 – 15:08:00	0	0	1	0	0
15:08:00 – 15:09:00	0	0	6	0	8
16:17:00 – 16:18:00	0	0	1	0	4
16:19:00 – 16:20:00	0	0	9	0	36
16:20:00 – 16:21:00	0	0	6	0	24
16:21:00 – 16:22:00	0	0	3	0	12

### Job Directives

The administrator can configure the following CMDaemon advanced configuration directives for job information processing:

- **JobInformationKeepCount:** The maximal number of jobs that are kept in the cache, default 8192, maximal value 1 million.
- **JobInformationKeepDuration:** How long to keep jobs in the cache, default 28 days.
- **JobInformationMinimalJobDuration:** Minimal duration for jobs to place them in the cache, default 0s.
- **JobInformationFlushInterval:** Over what time period to flush the cache to storage.
- **JobInformationDisabled:** Disables job information processing.
- **CacheJobsTime:** job information is removed from memory after that time.

### 7.7.2 Job Queues Display And Handling In cmsh: jobqueue Mode

Properties of scheduler job queues can be viewed and set in jobqueue mode.

#### jobqueue Mode In cmsh: Top Level

If a scheduler submode is not set, then the list, qstat, and listpes commands operate, as is expected, on all queues for all schedulers.

At the top level of jobqueue mode:

- **list** lists the queues associated with a scheduler.

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% jobqueue
[bright80->jobqueue]% list
Type          Name
-----
sge            all.q
torque         default
torque         hydroq
torque         longq
torque         shortq
```

- **qstat** lists statistics for the queues associated with a scheduler.

#### Example

```
[bright80->jobqueue]% qstat
===== sge =====
Queue      Load      Total      Used      Available
```

all.q	0.1	1	0	1
===== torque =====				
Queue	Running	Queued	Held	Waiting
-----				
default	0	0	0	0
hydroq	1	0	0	0
longq	0	0	0	0
shortq	0	0	0	0
===== pbspro =====				
Queue	Running	Queued	Held	Waiting
-----				

- `listpes` lists the parallel environment available for schedulers

### Example

(some details elided)

```
[bright80->jobqueue]% listpes
Scheduler      Parallel Environment
-----
sge             make
sge             mpich
...
sge             openmpi_ib
```

- `scheduler` sets the scheduler submode

### Example

```
[bright80->jobqueue]% scheduler torque
Working scheduler is torque
[bright80->jobqueue(torque)]%
```

The submode can be unset using: `scheduler ""`

### jobqueue Mode In cmsh: The scheduler Submode

If a scheduler submode is set, then commands under `jobqueue` mode operate only on the queues for that particular scheduler. For example, within the torque submode of `jobqueue` mode, the `list` command shows only the queues for torque.

### Example

```
[bright80->jobqueue]% list
Type      Name
-----
sge       all.q
torque    default
torque    longq
torque    shortq
[bright80->jobqueue]% scheduler torque
Working scheduler is torque
[bright80->jobqueue(torque)]% list
Type      Name
-----
torque    default
torque    longq
torque    shortq
```

**jobqueue Mode In cmlsh: Other Object Manipulation Commands**

The usual object manipulation commands of section 2.5.3 work at the top level mode as well as in the scheduler submode:

**Example**

```
[bright80->jobqueue]% list torque
Type          Name
-----
torque        default
torque        longq
torque        shortq
[bright80->jobqueue]% show torque longq
Parameter          Value
-----
Maximal runtime    23:59:59
Minimal runtime    00:00:00
Queue type         Execution
Routes
Type               torque
name               longq
nodes              node001.cm.cluster node002.cm.cluster
[bright80->jobqueue]% get torque longq maximalruntime
23:59:59
[bright80->jobqueue]%
[bright80->jobqueue]% scheduler torque
Working scheduler is torque
[bright80->jobqueue(torque)]% list
Type          Name
-----
torque        default
torque        longq
torque        shortq
[bright80->jobqueue(torque)]% show longq
Parameter          Value
-----
Maximal runtime    23:59:59
Minimal runtime    00:00:00
Queue type         Execution
Routes
Type               torque
name               longq
nodes              node001.cm.cluster node002.cm.cluster
[bright80->jobqueue(torque)]% get longq maximalruntime
23:59:59
[bright80->jobqueue(torque)]% use longq
[bright80->jobqueue(torque)->longq]% show
Parameter          Value
-----
Maximal runtime    23:59:59
Minimal runtime    00:00:00
Queue type         Execution
Routes
Type               torque
name               longq
nodes              node001.cm.cluster node002.cm.cluster
```

```
[bright80->jobqueue(torque)->longq]% get maximalruntime
23:59:59
```

### 7.7.3 Nodes Drainage Status And Handling In `cmsh`

Running the device mode command `drainstatus` displays if a specified node is in a Drained state or not. In a Drained state jobs are not allowed to start running on that node.

Running the device mode command `drain` puts a specified node in a Drained state:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device
[bright80->device]% drainstatus
```

Node	Queue	Status
node001	workq	
node002	workq	

```
[bright80->device]% drain node001
```

Node	Queue	Status
node001	workq	Drained

The `undrain` command unsets the Drained state so that jobs may start running on the node again.

The `drain`, `undrain`, and `drainstatus` commands have the same grouping options. The grouping options can make the command apply to not just one node, but to a list of nodes, a group of nodes, a category of nodes, a rack, a chassis, an overlay, a role, or a status. Continuing the example:

```
[bright80->device]% drain -c default; !# for a category of nodes
```

Node	Queue	Status
node001	workq	Drained
node002	workq	Drained

The help text for each command indicates the syntax:

#### Example

```
[root@bright80 ~]# cmsh -c "device help drain"
Name:  drain - Drain jobs (not data) on a set of nodes

Usage:  drain [OPTIONS/node]

Options:  -n, --nodes node(list)
           List of nodes, e.g.
           node001..node015,node020..node028,node030 or
           ^/some/file/containing/hostnames

           -g, --group group(list)
           Include all nodes that belong to the node group, e.g.
           testnodes or test01,test03

           -c, --category category(list)
           Include all nodes that belong to the category, e.g. default
           or default,gpu

           -r, --rack rack(list)
```



```

    Include all nodes that are located in the given rack, e.g
    rack01 or rack01..rack04

-h, --chassis chassis(list)
    Include all nodes that are located in the given chassis, e.g
    chassis01 or chassis03..chassis05

-e, --overlay overlay(list)
    Include all nodes that are part of the given overlay, e.g
    overlay1 or overlayA,overlayC

-l, --role role
    Filter all nodes that have the given
    role

-s, --status <status>
    Only run command on nodes with specified status, e.g. UP,
    "CLOSED|DOWN", "INST.*"

-t,--setactions <actions>
    set drain actions, actions already set will be removed
    (comma-separated)

-a,--appendactions <actions>
    append drain actions to already existing drain actions
    (comma-separated)

-e,--removeactions <actions>
    remove drain actions

-l, --clearactions
    remove all drain actions

-i, --listactions
    list all drain actions

```

```

Examples: drain                Drain the current node
         drain node001         Drain node001
         drain -r rack01       Drain all nodes in rack01
         drain --setactions reboot Drain the current node, and reboot when all jobs are complet

```

#### 7.7.4 Launching Jobs With `cm-launcher`

Some MPI distributions occasionally leave processes behind that cannot be killed from the workload manager. To prevent this situation from occurring, Bright Cluster Manager provides the `cm-launcher` wrapper for the `mpirun` command, which tracks and kills such processes. The tracking relies on knowing what processes the workload manager launches, so it can only run from within a suitable workload manager. Currently, suitable workload managers are Torque or SGE.

In the following job script examples, instead of having users use:

##### Example

```
mpirun <...>
```

which may not have a job clean up properly after it ends, users can use:

##### Example

```
cm-launcher mpirun <...>
```

which cleans up properly after the job ends. Here, `<...>` is used to indicate the mix of options, programs and arguments used with `mpirun`.

**For Torque** `cm-launcher` can be used if the default Torque epilogue script provided by the Bright Cluster Manager Torque package is present, at `/cm/local/apps/torque/var/spool/mom_priv/epilogue`.

**For SGE** the procedure is as follows:

- A symlink to `cm-launcher` is created to the `<arch>` SGE functions directory library

```
ln -s /cm/shared/apps/sge/var/cm/cm-launcher /cm/shared/apps/sge/current/bin/<arch>
```

- SGE's `epilog` (spelled without the `“-ue”` ending) script is set either for a particular queue, or globally.
  - To set it for a particular queue, for example, for the default queue `all.q`, the following `cmsh` commands can be run:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% jobqueue
[bright80->jobqueue]% scheduler sge
Working scheduler is sge
[bright80->jobqueue(sge)]% set all.q epilog /cm/shared/apps/sge/var/cm/epilog
[bright80->jobqueue*(sge)]% commit
Successfully committed 1 JobQueues
[bright80->jobqueue(sge)]%
```

- To set it globally for all queues, that is, not just the queue `all.q` but all the other queues as well, the following SGE configuration command is used:

```
qconf -mconf global
```

This starts up an editor acting on the `global` configuration setting. The `epilog` line entry is modified to:

```
epilog /cm/shared/apps/sge/var/cm/epilog
```

## 7.8 Examples Of Workload Management Assignment

### 7.8.1 Setting Up A New Category And A New Queue For It

Suppose a new node with processor optimized to handle Shor's algorithm is added to a cluster that originally has no such nodes. This merits a new category, `shornodes`, so that administrators can configure more such new nodes efficiently. It also merits a new queue, `shorq`, so that users are aware that they can submit suitably optimized jobs to this category.

Ways to configure the cluster manager for this are described next.

#### A New Category And A New Queue With Bright View

To create a new queue, the clickpath `HPC→Job queues` is selected, and the `Add` button is used to add a particular workload manager job queue scheduler, for example `PBS pro job queues`. The queue options must be configured—at least given a name—from the dialog window (figure 7.7).

The screenshot shows the 'Job Queues' management interface. On the left, a table lists existing queues: 'shorq' (checked), 'shornodes', 'default', and 'nisc'. The 'shorq' queue is selected, and its configuration is shown on the right. The configuration includes:

- Name:** shorq
- Queue type:** Execution
- Routes:** Routes
- Minimal runtime:** 00:00:00
- Maximal runtime:** 240:00:00
- Default runtime:** Default runtime
- Maximal queueable:** 0
- Priority:** 0
- Started:** Enabled (button)
- Enabled:** Enabled (button)
- ACL host enable:** Enabled (button)

At the bottom, there are buttons for 'Revert', 'Add', 'Delete', 'Save', and 'Back'.

Figure 7.7: Adding A New Queue Via Bright View

The queue option configuration is saved, and then the job queue scheduler configuration is saved.

Next, a new category can be added via the clickpath **Grouping→Node categories→Add**. Parameters in the new category can be set—at least the category name should be set—to suit the new machines (figure 7.8).

The screenshot shows the 'Node categories' management interface. On the left, a table lists existing categories: 'shornodes', 'default', and 'nisc'. The 'shornodes' category is selected, and its configuration is shown on the right. The configuration includes:

- Name:** shornodes
- Use exclusively for:** (dropdown menu)
- User node login:** ALWAYS
- Filesystem mounts:** (dropdown menu)
- Roles:** (dropdown menu)
- Static routes:** (dropdown menu)
- GPU Settings:** (dropdown menu)

At the bottom, there are buttons for 'Revert', 'Add', 'Delete', 'Save', and 'Back'.

Figure 7.8: Cloning A New Category Via Bright View

The name `shornodes` can therefore be set here.

Another option within the category is to set the queue. The queue, `shorq`, is therefore set here for this new category. Setting a queue for the category means configuring the options of the queue scheduler role, for example `PBS Pro client` role, for the category. Continuing from within the **Node categories options** window of figure 7.8, the relative clickpath to set a queue is **Roles→Add→PBS pro client role→Edit**. From the queue scheduler options settings window that opens up, the appropriate queues can be selected via a checkbox tick (figure 7.9).




Figure 7.9: Setting A Queue For A New Category Via Bright View

In this case, the `shorq` created earlier on in figure 7.7 is presented for selection. After ticking the checkbox, the configuration settings can then be saved—for this example it means going back up through the levels and clicking on the `Save` button at the node category settings level (the right hand window shown in figure 7.8), and also going up one more level to click the `Save` button on the node category list window (the left hand window shown in figure 7.8).

Nodes that are to use the queue should be members of the `shornodes` category. The final step is then to allocate such nodes to the category. This can be done, for example for a `node001`, by going into the settings of the node, via the clickpath `Devices→Physical Nodes[node001]→Edit→Settings→Category` and setting the category to `shornodes`.

#### A New Category And A New Queue With `cmsh`

The preceding example can also be configured in `cmsh` as follows:

The new queue can be added from within `jobqueue` mode, for the workload manager. For example, if Slurm is enabled:

```
[bright80]% jobqueue add shorq
[bright80->jobqueue*(slurm)->shorq*]% commit
```

The new category, `shornodes`, can be created by cloning an old category, such as `default`:

```
[bright80->jobqueue(slurm)->shorq]% category
[bright80->category]% clone default shornodes
[bright80->category*[shornodes*]]% commit
```

Then, going into the `roles` submode, appropriate workload manager roles can be assigned, and appropriate queues can be appended and committed for that category:

```
[bright80->category[shornodes]]% roles
[bright80->category[shornodes]->roles]% assign slurmclient; commit
[bright80->category[shornodes]->roles[slurmclient]]% append queues shorq
[bright80->category[shornodes*]->roles*]% commit
```

The nodes belonging to the `shornodes` category can then be placed by going into `device` mode to select the nodes to be placed in that category. For example:

```
[bright80->category[shornodes]->roles]% device use node002
[bright80->device[node002]]% set category shornodes
[bright80->device*[node002*]]% commit
```

### 7.8.2 Setting Up A Prejob Check

#### How It Works

Measurables such as health checks (section 12.2.4) by default run as scheduled tasks over regular intervals. They can optionally be configured to run on demand instead, or as prejob checks, that is, before a job is run.

If a health check is configured with the `prejob` setting, then its response is the same as that of a health check, that is:

- If the response to a `prejob` health check is `PASS`, then it shows that the node is displaying healthy behavior for that particular health check.
- If the response to a `prejob` health check is `FAIL`, then it implies that the node is unhealthy, at least for that particular health check.

The reason a `prejob` health check is treated more carefully is that, if the node it has just run on is unhealthy, then it means that a job submitted to the node may fail, may not be able to start, or may even vanish outright. The way it can vanish in some cases, without any information beyond the job submission “event horizon” leads to this behavior sometimes being called the *Black Hole Node Syndrome*.

It can be troublesome for a system administrator to pinpoint the reason for such job failures, since a node may only fail under certain conditions that are hard to reproduce later on. It is therefore a good policy to disallow passing a job to a node which has just been flagged as unhealthy by a health check. Thus, a sensible action (section 12.2.6) taken by a `prejob` health check on receiving a `FAIL` response would be to put the node in a `Drained` state (section 7.7.3). The `drain` state means that Bright Cluster Manager arranges a rescheduling of the job so that the job runs only on nodes that are believed to be healthy. In hindsight it should also be obvious that a node in a `drain` state can still accept jobs, if the jobs are run from outside of `CMDaemon` control. Thus, for example if jobs are submitted via workload managers that are not integrated with `CMDaemon`, then such jobs are not stopped from running on the node.

A node that has been put in a `Drained` state with a health check is not automatically undrained. The administrator must clear such a state manually.

The `failedprejob` health check (page 662) is enabled by default, and logs any prejob health check passes and failures. By default there are no prejob health checks configured, so by default this health check should always pass.

#### Configuration Using Bright View

To configure the monitoring of nodes with a prejob check in Bright View, the clickpath:

Monitoring Configuration→Data Producers→Monitoring data producers→Edit→When↓Pre job is used to set the `When` value for when it runs. In this case, `When` is set to `Pre job`.

#### Configuration Using `cmsh`

Within `cmsh`, the equivalent can be carried out as follows:

#### Example

For example, for the `ib` health check:

```
[bright80->monitoring->setup]% get ib when
Timed
[bright80->monitoring->setup]% set ib when <TAB><TAB>
on\ demand pre\ job timed
[bright80->monitoring->setup]% set ib when pre\ job
[bright80->monitoring->setup*]% commit
```

#### Configuration Outside Of `CMDaemon`

For more unusual prejob checking requirements, further details on how prologs are configured are given in section 7.3.3.

## 7.9 Power Saving Features

This section discusses power saving options for workload managers:

- a mechanism specifically for Slurm (section 7.9.1)
- a more general mechanism, `cm-scale` for nodes in a cluster managed by Bright Cluster Manager (section 7.9.2)

### 7.9.1 Slurm

Slurm provides a power saving mechanism that allows nodes in a client role to go into a power save mode. Power saving is disallowed by default for the head node. If power saving is allowed, then it must be enabled on the nodes where it is to function.

#### Allowing And Enabling Power Saving On Slurm

Power saving can be allowed and enabled at the category or node level as follows:

**Using Bright View:** If using Bright View, then the clickpaths are as follows:

For individual nodes, for example a node `node001`, it is:

Devices→Physical Nodes[`node001`]→Edit→Settings→Roles→Slurm client role  
→Power Saving Allowed (figure 7.10)




Figure 7.10: Allowing Power Save In Slurm With Bright View For A Category

while for a node category, for example `default`, it is:

Grouping→Node categories[`default`]→Edit→SettingsRoles→Slurm client role  
→Power Saving Allowed

**Using `cmsh`:** If using `cmsh`, then within `category` or `device` mode, the `slurmclient` role is chosen from the `roles` submenu.

- To allow power saving, the value for `powersavingallowed` is set to `yes` within the `slurmclient` role, and the setting is committed.

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device roles node001
[bright80->device[node001]->roles]% set slurmclient powersavingallowed yes; commit
```

- To enable power saving, the `powersavingenabled` parameter can be set to `yes` in the `slurmserver` role, as shown in the following example:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% device roles bright80
[bright80->device[bright80]->roles]% set slurmserver powersavingenabled yes; commit
```

The `slurmserver` role is typically assigned to the head node.

Additional power saving configuration file parameters are described in the Slurm power saving guide at [http://slurm.schedmd.com/power\\_save.html](http://slurm.schedmd.com/power_save.html)

### 7.9.2 The `cm-scale` Service

#### `cm-scale` Introduction

The `cm-scale` service can be used by an administrator to reduce the energy and storage costs of compute nodes by changing their power state, or their existence state, according to workload demands. That is, `cm-scale` automatically scales a cluster up or down, on-demand, by powering up physical nodes, cloud nodes, or virtual nodes. The scaling is carried out according to settings in the `ScaleServer` role which set the nodes that are to use the `cm-scale` service.

The `cm-scale` service runs as a daemon. It collects information about workloads from different workload engines, such as HPC workload managers and Mesos, and it uses knowledge of the nodes in the cluster. In the case of HPC jobs, the daemon also gathers knowledge of the queues that the jobs are to be assigned to.<sup>1</sup> Based on the workload engine information and queues knowledge, the `cm-scale` service can clone and start compute nodes when the workloads are ready to start. The service also stops or terminates compute nodes, when no queued or running workloads remain on the managed nodes.

#### `cm-scale` Use Cases

The `cm-scale` service can be considered as a basis for the construction of different kinds of dynamic data centers. Within such centers, nodes can be automatically re-purposed from one workload engine setup to another, or they can be powered on and off based on the current workload demand.

A few use cases are discussed next, to show how this basis can be built upon:

1. An organization wants to run PBS Pro and Slurm on the same cluster, but how much one workload engine is used relative to the other varies over time. For this case, nodes can be placed in the same pool and shared. When a node finishes an existing job, the `cm-scale` service can then re-purpose that node from one node category to another if needed, pretty much immediately. The re-purposing decision for the node is based on the jobs situation in the PBS Pro and Slurm queues.
2. An organization would like to use their cluster for both Mesos frameworks and for Torque jobs. For this case, the admin adds Mesos- and Torque-related settings to the `ScaleServer` role. Using these settings, the `cm-scale` service then switches nodes from one configuration overlay to another. For example, if Slurm jobs are pending and there is a free Mesos node, then the node is turned into a Slurm node pretty much immediately.
3. An organization has a small cluster with Slurm installed on it, and would like to be able to run more jobs on it. This can be carried out using Bright Cluster Manager's Cluster Extension cloud-bursting capability (Chapter 3 of the *Cloudbursting Manual*) to extend the cluster when there are too many jobs for the local cluster. The extension to the cluster is made to a public cloud provider, such

<sup>1</sup>HPC SGE/UGE jobs have no queue assignment by default, and are therefore ignored by default. Adding a line such as:

```
-q all.q
```

to the `var/default/common/sge_request` file, under `/cm/shared/apps/sge/` (or `/cm/shared/apps/uge/`) assigns SGE (or UGE) jobs to the `all.q` queue by default, so that `cm-scale` considers them.

as AWS or Azure. For this case, the users can use the `cmsub` utility (section 4.4 of the *Cloudbursting Manual*) to submit their cloud jobs, and Slurm `sbatch` for their regular jobs. The `cm-scale` service then tracks the Slurm queues, and decides whether or not new cloud nodes should be added from the cloud as extensions to the local network and queues. When the jobs are finished, then the cloud nodes are terminated automatically. Cluster extension typically takes several minutes from prepared images, and longer if starting up from scratch, but in any case this change takes longer than simple re-purposing does.

4. An organization runs PBS Pro only and would like to power down free, local, physical nodes automatically, and start up such nodes when new jobs come in, if needed. In this case, `cm-scale` follows the queues and decides to stop or to start the nodes automatically depending on workload demand. Nodes typically power up in several minutes, so this change takes longer than simple re-purposing does.
5. An organization uses OpenStack as a private cloud, and would like to extend Slurm partitions into that OpenStack private cloud. In this case, `cm-scale` can clone Bright-managed instances in OpenStack (Chapter 5.3 of the *OpenStack Deployment Manual*), and adds them to Slurm's network and partitions. Cloning an instance can take several minutes, so that this change takes longer than simple re-purposing does.

#### `cm-scale` Restrictions

1. Two workload engines of the same kind cannot be served by `cm-scale` on the same Bright Cluster Manager cluster. For example, two Slurm instances cannot be managed, but Slurm and LSF can.
2. When the service considers whether or not the node is suited for the workload, it considers only the number of CPU cores requested by the workload. It does not consider other types of resources. For example, if a workload needs Xeon Phi, then `cm-scale` does not verify if the node actually includes Xeon Phi.

#### `cm-scale` Setup

The `cm-scale`-related files are placed in a local directory when the administrator installs the `cm-scale` package. If `cm-scale` is needed on a non-head node, then the package should be installed in the corresponding software image. The administrator also typically configures the default user environment for users of the service, so that the `cm-scale` modules environment automatically loads up (section 2.2.3).

The `cm-scale` service does not require any special setup scripts or wizards to run. In order to start using the service, it is enough to assign the `ScaleServer` role to the nodes, and to configure the role properly by setting the role attributes. Unassigning the role stops the `cm-scale` service.

The service writes logs to `/var/log/cm-scale.log`. Running the `cm-scale` daemon in the foreground for debugging or demonstration purposes is also possible, using the `-f` option, and the logs are then duplicated to STDOUT:

#### Example

```
root@bright80$ module load cm-scale
root@bright80$ cm-scale -f
[...]
```

#### `cm-scale` Comparison With `cm-scale-cluster`

Versions of Bright Cluster Manager prior to 8.0 had the `cm-scale-cluster` utility, which provided similar functionality to the current `cm-scale` utility. However, the older utility did not allow workloads (jobs) to be considered for more than one workload manager at a time, and also supported only HPC workload managers as workload engines.

The current `cm-scale` service on the other hand, allows, for example, Slurm and Torque workloads to be considered on the same cluster, and also supports other types of workload engines besides HPC workload managers.



Furthermore, the `cm-scale` utility does not use a `crontab` entry. The old `cm-scale-cluster` utility required `cron` to run it regularly, because only one iteration of decision-making was performed by it. The new `cm-scale` utility, on the other hand, runs the decision-making loop internally within the `cm-scale` daemon. The decision-making interval is set in the `ScaleServer` role.

#### `cm-scale` And The `ScaleServer` Role

The `ScaleServer` role is configured by the administrator and typically assigned to head nodes:

#### Example

```
[bright80]% device use master
[bright80->device[bright80]]% roles
[bright80->device[bright80]->roles]% assign scaleserver
[bright80->device*[bright80*]->roles*[scaleserver*]]% show
Parameter                                     Value
-----
Add services                                yes
Name                                         scaleserver
Provisioning associations                    <0 internally used>
Revision
Type                                         ScaleServerRole
Engines                                     <0 in submode>
Dry Run                                     no
Debug                                       no
Run Interval                               180
Log File                                   /var/log/cm-scale.log
Spool                                       /var/spool/cm-scale
Resource Providers                          <0 in submode>
[bright80->device*[bright80*]->roles*[scaleserver*]]%
```

An overview of the parameters and submodes is given next. An example showing how they can be configured is given afterwards, on page 269.

**ScaleServer role global parameters:** The `ScaleServer` role contains the following global parameters for controlling the `cm-scale` service itself:

- **Dry Run:** If set, then the service runs in dry run mode. In this mode it may claim that actions have been carried out on the nodes that use the `cm-scale` service, however, no action is actually carried out on nodes. This mode is useful for demonstration or debug purposes
- **Log File:** path to the log file, with a default path of `/var/log/cm-scale.log`
- **Run Interval:** interval, in seconds, between `cm-scale` decision-making
- **Spool:** directory where temporary files are created by the service

**ScaleServer role submodes:** Within the `ScaleServer` role are the following three submodes:

- **resourceproviders:** define the nodes used by `cm-scale`
- **engines:** define the engines used by `cm-scale`. This can be an instance of the type `hpc` or `mesos`.
  - **trackers (within engines submode):** define the trackers used by `cm-scale`

The parameters are enforced only when the next decision-making iteration takes place.

### cm-scale Resource providers

The `cm-scale` service allows nodes to change state according to the workload demand. These managed nodes are defined by the administrator within the `resourceproviders` submode of `ScaleServer`. Bright Cluster Manager 8.0 supports two types of resource providers: `static` and `dynamic` node providers.

**Static node provider:** When managed nodes are well-known and will not be extended or shrunk dynamically, then a `static` node provider can be used. Specifying settings for the `static` node provider allows `cm-scale` to power on, power off, or re-purpose nodes, based on `nodegroups` or a list of nodes specified with a node list syntax (page 37).

The `static` node provider supports the following properties:

- **Enabled:** The static node provider is currently enabled.
- **Nodes:** A list of nodes managed by `cm-scale`. These can be regular local compute nodes (`nodes`), cluster extension cloud compute nodes (`cnodes`), and Bright-managed OpenStack virtual compute nodes (`vnodes`). For the purposes of this section on `cm-scale`, these compute nodes can conveniently be called `nodes`, `cnodes`, and `vnodes`. Since compute nodes are typically the most common cluster nodes, significant resources can typically be saved by having the `cm-scale` service decide on whether to bring them up or down according to demand.
  - `cnodes` and `vnodes` can be cloned and terminated as needed. Cloning and terminating saves on cloud storage costs associated with keeping virtual machine images.
  - regular local compute nodes can be started and stopped as needed. This reduces power consumption.
- **Nodegroups:** List of nodegroups with nodes to be managed by `cm-scale`. Node groups are classed into *types*. The class of node group types is independent of the class of node types, and should not be confused with it. Node types can be `physicalnode`, `cloudnode`, `virtualnode`, `headnode`, `mic`, `ethernet switch` and others, and are shown in the first column of the output of the default `list` command in `device` mode. Node group types currently (May 2017) consist only of `Normal` and `Storage pair`. Only node groups of type `Normal` can currently be managed by `cm-scale`.
- **Priority:** The provider priority. Nodes in the pool of a provider with a higher priority are used first by workloads. By default a resource provider has a priority value 0. These priority values should not be confused with the fairsharing priorities of page 268.

**Dynamic node provider:** When managed nodes can be cloned or removed from the configuration, then a `dynamic` node provider should be used. A compute node that is managed by `cm-scale` as a `dynamic` node provider is configured as a template node within the `dynamic` submode of the `ScaleServer` role.

The `dynamic` node provider supports the following properties:

- **Template Node:** A node that will be used as a template for cloning other nodes in the pool. The following restrictions apply to the template node:
  - A workload manager client role must be assigned with a positive number of slots.
  - New node names should not conflict with the node names of nodes in a `nodegroup` defined for the queue.
  - A specific template node is restricted to a specific queue.

A template node only has to exist as an object in Bright Cluster Manager, with an associated node image. A template node does not need to be up and running physically in order for it to be used to create clones. Sometimes, however, an administrator may want it to run too, like the other nodes that are based upon it, in which case the `Start Template Node` and `Stop Template Node` values apply:

- `Start Template Node`: The template node specified in the `Template Node` parameter is also started automatically on demand.
- `Stop Template Node`: The template node specified in the `Template Node` parameter is also stopped automatically on demand.
- `Never Terminate`: Number of cloud nodes that are never terminated even if no jobs need them. If there are this number or fewer cloud nodes, then `cm-scale` no longer terminates them. Cloud nodes that cannot be terminated can, however, still be powered off, allowing them to remain configured in Bright Cluster Manager. As an aside, local nodes that are under `cm-scale` control are powered off automatically when no jobs need them, regardless of the `Never Terminate` value.
- `Enabled`: Node provider is currently enabled.
- `Priority`: Node provider priority.
- `Node Range`: Range of nodes that can be created and managed by `cm-scale`.
- `Network Interface`: Which node network interface is changed on cloning (incremented).
- `Remove Nodes`: Should the new node be removed from Bright Cluster Manager when the node terminates? If the node is not going to be terminated, but just stopped, then it is never removed.
- `Leave Failed Nodes`: If nodes are discovered to be in a state of `INSTALLER_FAILED` or `INSTALLER_UNREACHABLE` (section 5.5.4) then this setting decides if they can be left alone, so that the administrator can decide what to do with them later on.
- `Default Resources`: List of default resources, in format `[name=value]`.
  - `cpu`: value is the number of CPUs
  - `mem`: value is in bytes

These must be set when no real node instance is associated with a node defined in Bright Cluster Manager.

**Extra nodes settings for node providers:** Both the dynamic and static node providers support extra node settings. If configured, then `cm-scale` can start the extra nodes before the first workload is started, and can stop them after the last job from the managed queue is finished.

The most common use case scenario for extra nodes in the case of cloud nodes is a cloud director node. The cloud director node provisions cloud compute nodes and performs other management operations in a cloud.

In the case of non-cloud non-head nodes, extra nodes can be, for example, a license server, a provisioning node, or an additional storage node.

The configuration settings include:

- `Extra Nodes`: A list of extra nodes.
- `Extra Node Idle Time`: The maximum time, in seconds, that extra nodes can remain unused. The `cm-scale` service checks for the existence of queued and active workloads using the extra node, when the time elapsed since the last check reaches `Extra Node Idle Time`. If there are workloads using the extra node, then the time elapsed is reset to zero and a time stamp is written

into the file `cm-scale.state` under the directory set by the `Spool` role parameter. The time stamp is used to decide when the next check is to take place. Setting `Extra Node Idle Time=0` means the extra node is stopped whenever it is found to be idle, and started again whenever workloads require it, which may result in a lot of stops and starts.

- **Extra Node Start:** Extra node is started by `cm-scale` before the first compute node is started.
- **Extra Node Stop:** Extra node is stopped by `cm-scale` after the last compute node stops.

The following table summarizes the default attributes in `cmsh` for the resource providers:

Parameter	static	dynamic
Revision		
Type	ScaleStaticNodesProvider	ScaleDynamicNodesProvider
Nodes		N/A
Template Node	N/A	
Start Template Node	N/A	no
Stop Template Node	N/A	no
Remove Nodes	N/A	no
Leave Failed Nodes	N/A	yes
Never Terminate	N/A	32
Node Range	N/A	
Network Interface	N/A	tun0
Name	static	dynamic
Enabled	yes	yes
Nodegroups		N/A
Priority	0	0
Whole Time	0	0
Stopping Allowance Period	0	0
Extra Node		
Extra Node Idle Time	3600	3600
Extra Node Start	yes	yes
Extra Node Stop	yes	yes
Default Resources		
Options		

In the preceding table, the entry N/A means that the parameter is not available for the corresponding resource provider.

#### `cm-scale` Time Quanta Optimization

*Time quanta optimization* is an additional feature that `cm-scale` can use for further cost-saving with certain cloud providers.

For instance, Amazon charges per whole unit of time, or *time quantum*, used per cloud node, even if only a fraction of that unit of time was actually used. The aim of Bright Cluster Manager's time quanta optimization is to keep a node up as long as possible within the already-paid-for time quantum, but without incurring further cloud provider charges for a node that is not currently useful. That is, the aim is to:

- keep a node up if it is running jobs in the cloud
- keep a node up if it is not running jobs in the cloud, if its cloud time has already been paid for, until that cloud time is about to run out
- take a node down if it is not running jobs in the cloud, if its cloud time is about to run out, in order to avoid being charged another unit of cloud time

Time quanta optimization is implemented with some guidance from the administrator for its associated parameters. The following parameters are common for both `static` and `dynamic` node resource providers:

- **Whole time.** A compute node running time (in minutes) before it is stopped if no workload requires it. Currently (May 2017) Amazon's time quantum is 60 minutes. By default, Bright Cluster Manager uses a value of `Whole Time=0`, which is a special value that means `Whole Time` is ignored. Ignoring it means that Bright Cluster Manager does no time quanta optimization to try to optimize how costs are minimized, but instead simply takes down nodes when they are no longer running jobs.
- **Stopping Allowance Period.** A time (in minutes) just before the end of the `Whole Time` period, prior to which all power off (or terminate) operations must be started. The parameter associated with time quanta optimization is the `Stopping Allowance Period`. This parameter can also be set by the administrator. The `Stopping Allowance Period` can be understood by considering the *last call time period*. The last call time period is the period between the last call time, and the time that the next whole-time period starts. If the node is to be stopped before the next whole-time charge is applied, then the last call time period must be at least more than the maximum time period that the node takes to stop. The node stopping period in a cluster involves cleanly stopping many processes, rather than just terminating the node instance, and can therefore take some minutes. The maximum period in minutes allowed for stopping the node can be set by the administrator in the parameter `Stopping Allowance Period`. By default, `Stopping Allowance Period=0`. Thus, for nodes that are idling and have no jobs scheduled for them, only if the last call time period is more than `Stopping Allowance Period`, does `cm-scale` stop the node.

The preceding parameters are explained next.

Figure 7.11 illustrates a time line with the parameters used in time quanta optimization.




Figure 7.11: Time Quanta Optimization

The algorithm that `cm-scale` follows, with and without time quanta optimization, can now be described using the two parameters explained so far:

1. `cm-scale` as part of its normal working, checks every `Run Interval` seconds to see if it should start up nodes on demand or shut down idling nodes.
2. If it sees idling nodes, then:

- (a) If `Whole Time` has not been set, or is 0, then there is no time quanta optimization that takes place. The `cm-scale` service then just goes ahead as part of its normal working, and shuts down nodes that have nothing running on them or nothing about to run on them.
- (b) If a non-zero `Whole Time` has been set, then a time quanta optimization attempt is made. The `cm-scale` service calculates the time period until the next time quantum from public cloud starts. This time period is the current *closing time period*. Its value changes each time that `cm-scale` is run. If
  - the current closing time period is long enough to let the node stop cleanly before the next time quantum starts, and
  - the next closing time period—as calculated by the next `cm-scale` run but also running within the current time quantum—is not long enough for the node to stop cleanly before the next quantum starts

then the current closing time period starts at a time called the *last call*.

In drinking bars, the last call time by a bartender allows some time for a drinker to place the final orders. This allows a drinker to finish drinking in a civilized manner. The drinker is meant to stop drinking before closing time. If the drinker is still drinking beyond that time, then a vigilant law enforcement officer will fine the bartender.

Similarly, the last call time in a scaling cluster allows some time for a node to place its orders to stop running. It allows the node to finish running cleanly. The node is meant to stop running before the next time quantum starts. If the node is still running beyond that time, then a vigilant cloud provider will charge for the next whole time period.

The last call time is the last time that `cm-scale` can run during the current whole-time period and still have the node stop cleanly within that current whole-time period, and before the next whole-time period starts. Thus, when `Whole Time` has been set to a non-zero time:

- i. If the node is at the last call time, then the node begins with stopping
- ii. If the node is not at the last call time, then the node does not begin with stopping

The algorithm goes back again to step 1.

#### `cm-scale` Fairsharing Priority Calculations And Node Management

At intervals of `Run Interval`, `cm-scale` collects workloads using trackers configured in the `ScaleServer` role, and puts all the workloads in a single internal queue. This queue is then sorted by priorities. The priorities are calculated for each workload using the following fairsharing formula:

$$p_{ij} = a_i \times k_1 + e_j \times k_2$$

where:

$p_{ij}$  is the global priority for the  $i$ -th workload of the  $j$ -th engine. Its value is used to re-order the queue.

$a_i$  is the age of the workload. That is, how long has passed since the  $i$ -th job submission, in seconds. This typically dominates the priority calculation, and makes older workloads become higher priority.

$k_1$  is the age factor. This is `agefactor` that can be set in the engine submode of the `ScaleServer` role. Usually it is 1.

$e_j$  is the engine priority. This is `priority` in the engine submode of the `ScaleServer` role.

$k_2$  is the engine factor. This is `enginefactor` in the engine submode of the `ScaleServer` role.

When all the workload priorities are calculated and the queue is re-ordered, then `cm-scale` starts to find appropriate nodes for workloads, from the top of the queue where the higher priority workloads are, to the bottom. This way a higher priority engine has a greater chance of getting nodes for its workloads than a lower priority engine.

**cm-scale Simple Static Node Provider Usage Example**

The example session that follows explains how a static node provider (page 264) can be configured and used. The session considers a default cluster with a head node and 5 regular nodes which have been previously defined in Bright Cluster Manager configuration. 3 of the regular nodes are powered down at the start of the run. The power control for the nodes must be functioning properly, or otherwise `cm-scale` cannot power nodes on and off.

The head node has the Slurm server role by default, and the regular nodes run with the Slurm client role by default. So, on a freshly-installed cluster, the `roleoverview` command should show something like:

**Example**

```
[bright80->device[bright80]]% roleoverview | head -2 ; roleoverview | grep slurm
```

Role	Nodes	Categories	Nodes up
slurmclient	node001..node005	default	2 of 5
slurmserver	bright80		1 of 1

A test user, `fred` can be created by the administrator (section 6.2), and an MPI `hello` executable based on the `hello.c` code (from section 3.3.3 of the *User Manual*) can be built:

**Example**

```
[fred@bright80 ~]$ module add shared openmpi/gcc/64/1.10.3 slurm
[fred@bright80 ~]$ mpicc hello.c -o hello
```

A batch file `slurmhello.sh` (from section 5.3.1 of the *User Manual*) can be set up. Restricting it to 1 process per node so that it spreads over nodes easier for the purposes of the test can be done with the settings:

**Example**

```
[fred@bright80 ~]$ cat slurmhello.sh
#!/bin/sh
#SBATCH -o my.stdout
#SBATCH --time=30 #time limit to batch job
#SBATCH --ntasks=1
#SBATCH --ntasks-per-node=1
module add shared openmpi/gcc/64/1.10.1 slurm

mpirun /home/fred/hello
```

The user `fred` can now flood the default queue, `defq`, with the batch file:

**Example**

```
[fred@bright80 ~]$ while (true); do sbatch slurmhello.sh; done
```

After putting enough jobs into the queue (a few thousand should be enough, and keeping it less than 5000 would be sensible) the flooding can be stopped with a `ctrl-c`.

The activity in the queue can be watched:

**Example**

```
[root@bright80 ~]# watch "squeue | head -3 ; squeue | tail -3"
```

```
Every 2.0s: squeue | head -3 ; squeue | tail -3 Thu Sep 15 10:33:17 2016
```

JOBID	PARTITION	NAME	USER	ST	TIME	NODES	NODELIST (REASON)
6423	defq	slurmhel	fred	CF	0:00	1	node001
6424	defq	slurmhel	fred	CF	0:00	1	node002
6572	defq	slurmhel	fred	PD	0:00	1	(Priority)
6422	defq	slurmhel	fred	R	0:00	1	node001
6423	defq	slurmhel	fred	R	0:00	1	node002

The preceding indicates that node001 and node002 are being kept busy running the batch jobs, while the remaining nodes are not in use.

The administrator can check on the job status via the job metrics of cmsh too, using the options to the filter command, such as `--pending` or `--running`:

### Example

```
[root@bright80 ~]# cmsh -c "jobs ; watch filter --running -u fred"
Every 2.0s: filter --running -u fred Wed May 7 12:50:05 2017
Job ID Job name User Queue Submit time Start time End time Nodes Exit code
-----
406 slurmhello.sh fred defq 16:16:56 16:27:21 N/A node001,node002 0
```

and eventually, when jobs are no longer running, it should show something like:

```
[root@bright80 ~]# cmsh -c "jobs ; watch filter --running -u fred"
Every 2.0s: filter --running Wed May 7 12:56:53 2017
No jobs found
```

So far, the cluster is queuing or running jobs without `cm-scale` being used.

The next steps are to modify the behavior by bringing in `cm-scale`. The administrator assigns the `ScaleServer` role to the head node. Within the role a new static node provider, Slurm engine, and queue tracker for the `defq` are set as follows:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device roles master
[bright80->device[bright80->roles]% use scaleserver
[bright80->device[bright80->roles[scaleserver]]% resourceproviders
...->roles[scaleserver]->resourceproviders% add static pool1
...->roles[scaleserver]->resourceproviders[pool1]% set nodes node001..node005
...->roles[scaleserver]->resourceproviders[pool1]% commit
...->roles[scaleserver]->resourceproviders[pool1]% ..;..
...->roles[scaleserver]]% engines
...->roles[scaleserver]->engines% add hpc slurm
...->roles[scaleserver]->engines[slurm1]% set workloadmanager slurm
...->roles[scaleserver]->engines[slurm1]% trackers
...->roles[scaleserver]->engines[slurm1]->trackers% add queue tr1
...->roles[scaleserver]->engines[slurm1]->trackers[tr1]% set queue defq
...->roles[scaleserver]->engines[slurm1]->trackers[tr1]% commit
...->roles[scaleserver]->engines[slurm1]->trackers[tr1]]%
```

The nodes `node001..node005` should already be in the queue `defq`, as assigned to them by default when they were assigned the `SlurmClient` role. With these settings, they can now be powered up or



down on demand by `cm-scale` service, depending on the number of jobs that are pending. When the new `ScaleServer` role is committed in `cmsh` or Bright View, then the `cm-scale` service is started. If needed, the administrator can check the log file `/var/log/cm-scale` to see what the service is doing.

On each iteration `cm-scale` checks whether the node states should be changed. Thus after a while, the nodes `node003`..`node005` are started. Once up, they can start to process the jobs in the queue too.

Watching the running jobs should show something like:

### Example

```
[root@bright80 ~]# cmsh -c "jobs ; watch filter --running"
```

```
Every 2.0s: filter --running                               Thu Sep  8 13:01:59 2016
Job ID Job name      User Queue Submit time      Start time      Nodes  Exit code
-----
16498  slurmhello.sh fred defq  07/05/2017 12:44:20 07/05/2017 13:20:58 node003 0
16499  slurmhello.sh fred defq  07/05/2017 12:44:20 07/05/2017 13:20:58 node002 0
```

Eventually, `cm-scale` finds that all jobs have been dealt with, and the nodes are then powered down.

**High-availability and using a configuration overlay for the `ScaleServer` role:** For high-availability clusters, where there are two head nodes, the `scaleserver` should run on the active head node. One labor-intensive way to set this up is to assign the service to both the head nodes, and match the `scaleserver` settings on both head nodes. A simpler way is to define a configuration overlay for the head nodes for the `scaleserver`. If the head nodes are `bright80-1` and `bright80-2`, then a configuration overlay called `brightheads` can be created and assigned the service as follows:

### Example

```
[bright80-1]% configurationoverlay add brightheads
[bright80-1->configurationoverlay*[brightheads*]]% append nodes bright80-1 bright80-2
[bright80-1->configurationoverlay*[brightheads*]]% roles
[bright80-1->configurationoverlay*[brightheads*]->roles]% assign scaleserver
[bright80-1->configurationoverlay*[brightheads*]->roles*[scaleserver*]]%
```

The `scaleserver` can then be configured within the configuration overlay instead of on a single head as was done previously in the example of page 270. After carrying out a `commit`, the `scaleserver` settings modifications are then mirrored automatically between the two head nodes.

Outside the `scaleserver` settings, one extra modification is to set the `cm-scale` service to run on a head node if the head node is active. This can be done with:

### Example

```
[bright80-1->configurationoverlay[brightheads]->roles[scaleserver]]% device services bright80-1
[bright80-1->device[bright80-1]->services]% use cm-scale
[bright80-1->device[bright80-1]->services[cm-scale]]% set runif active
[bright80-1->device*[bright80-1*]->services*[cm-scale*]]% commit
[bright80-1->device[bright80-1]->services]% device use bright80-2
[bright80-1->device[bright80-2]->services]% use cm-scale
[bright80-1->device[bright80-2]->services[cm-scale]]% set runif active
[bright80-1->device*[bright80-2*]->services*[cm-scale*]]% commit
```

The result is a `scaleserver` that runs when the head node is active.

### cm-scale Simple Dynamic Node Provider Usage Example

The following example session explains how a dynamic node provider (page 264) can be configured and used. The session considers a default cluster with a head node and 2 regular nodes which have been previously defined in Bright Cluster Manager configuration, and also 1 cloud director node and 2 cloud compute nodes. The cloud nodes can be configured using `cm-cluster-extension`. Only the head node is running at the start of the session, while the regular nodes and cloud nodes are all powered down at the start of the run.

At the start, the device status shows something like:

#### Example

```
[bright80->device]% ds
eu-west-1-cnode001 ..... [ DOWN ] (Unassigned)
eu-west-1-cnode002 ..... [ DOWN ] (Unassigned)
eu-west-1-cnode003 ..... [ DOWN ] (Unassigned)
eu-west-1-director ..... [ DOWN ]
node001 ..... [ DOWN ]
node002 ..... [ DOWN ]
bright80 ..... [ UP ]
```

The power control for the regular nodes must be functioning properly, or otherwise `cm-scale` cannot power them on and off.

The head node has the Slurm server role by default, and the regular nodes run with the Slurm client role by default. So, on a freshly-installed cluster, the `roleoverview` command should show something like:

#### Example

```
[bright80->device[bright80]]% roleoverview
```

Role	Nodes	Categories	Nodes up
boot	bright80		1 of 1
cgroupsupervisor	eu-west-1-cnode001..eu-west-1-cnode002 ,eu-west-1-director,node001..node002 ,bright80	aws-cloud-director,default ,eu-west-1-cloud-node	1 of 6
clouddirector	eu-west-1-director		0 of 1
cloudgateway	bright80		1 of 1
login	bright80		1 of 1
master	bright80		1 of 1
monitoring	bright80		1 of 1
provisioning	eu-west-1-director,bright80		1 of 2
slurmclient	eu-west-1-cnode001..eu-west-1-cnode002 ,node001..node002	default,eu-west-1-cloud-node	0 of 3
slurmserver	bright80		1 of 1
storage	eu-west-1-director,bright80	aws-cloud-director	1 of 2

A test user, `fred` can be created by the administrator (section 6.2), and an MPI `hello` executable based on the `hello.c` code (from section 3.3.3 of the *User Manual*) can be built:

#### Example

```
[fred@bright80 ~]$ module add shared openmpi/gcc/64/1.10.3 slurm
[fred@bright80 ~]$ mpicc hello.c -o hello
```

A batch file `slurmhello.sh` (from section 5.3.1 of the *User Manual*) can be set up. Restricting it to 1 process per node so that it spreads over nodes easier for the purposes of the test can be done with the settings:

### Example

```
[fred@bright80 ~]$ cat slurmhello.sh
#!/bin/sh
#SBATCH -o my.stdout
#SBATCH --time=30 #time limit to batch job
#SBATCH --ntasks=1
#SBATCH --ntasks-per-node=1
module add shared openmpi/gcc/64/1.10.1 slurm

mpirun /home/fred/hello
```

A default cluster can queue or run jobs without `cm-scale` being used. The default behavior is modified in the next steps, which bring in the `cm-scale` service:

The administrator assigns the `ScaleServer` role to the head node.

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device roles master
[bright80->device[bright80]->roles]% assign scaleserver
```

Within the assigned `scaleserver` role, a new dynamic node provider can be set, and properties for the dynamic pool of nodes can be set for the cloud compute nodes. Here the properties that are set are `priority` (page 264), `templatenode` (page 264), `noderange` (page 265), and `extranodes` (page 265).

### Example

```
[bright80->device*[bright80*]->roles*[scaleserver*]]% resourceproviders
...->roles[scaleserver]->resourceproviders% add dynamic pool2
...resourceproviders*[pool2*]]% set priority 2
...resourceproviders*[pool2*]]% set noderange eu-west-1-cnode001..eu-west-1-cnode002
...resourceproviders*[pool2*]]% set templatenode eu-west-1-cnode001
...resourceproviders*[pool2*]]% set extranodes eu-west-1-director
...resourceproviders*[pool2*]]% commit
...resourceproviders[pool2]]%
```

The regular compute nodes, `node001..node002` should be specified as nodes in the static pool.

The administrator may notice the similarity of dynamic and static pool configuration. The Bright Cluster Manager front end has deliberately been set up to present dynamic pool and static pool nodes to the cluster administrator as two different configuration methods. This is because separating the pool types as dynamic and static pools is simpler for the cluster administrator to deal with. This way, regular compute nodes are treated, not as a special case of a dynamic pool, but simply as static pool nodes. The fundamental reason behind this separate treatment is because physical nodes cannot “materialize” dynamically with properties in the way the cloud compute nodes—which are virtualized nodes—can, due to the need to associate a MAC address with a physical node.

Assigning regular compute nodes to a static pool can be done in a similar way to what was shown before in the example on page 270.

Continuing with the current session, the nodes `node001..node002` are added to the static pool of nodes, `on-premises-nodes`. For this example they are set to a lower priority than the cloud nodes:

### Example

```
...->roles[scaleserver]->resourceproviders]% add static on-premises-nodes
...->roles*[scaleserver*]->resourceproviders*[on-premises-nodes*]]% set nodes node001..node002
...->roles*[scaleserver*]->resourceproviders*[on-premises-nodes*]]% set priority 1
...->roles*[scaleserver*]->resourceproviders*[on-premises-nodes*]]% commit
...->roles[scaleserver]->resourceproviders[on-premises-nodes]]%
```

What this lower priority means is that a node that is not up and is in the static pool of nodes, is only powered on after all the cloud nodes are powered on and busy running jobs. If there happen to be nodes from the static pool that are already up, but are not running jobs, then these nodes take a job, despite the lower priority of the static pool, and irrespective of whether the dynamic pool nodes are in use. The `cm-scale` parameters `MIX_LOCATIONS` (page 283) or `PIN_QUEUES=true` (page 286) can override the effect of job prioritizing.

A Slurm engine, and queue tracker for the `defq` are set as follows:

### Example

```
...]->roles[scaleserver]]% engines
...]->roles[scaleserver]->engines]% add hpc slurm2
...*]->roles*[scaleserver*]->engines*[slurm2]]% set workloadmanager slurm
...*]->roles*[scaleserver*]->engines*[slurm2]]% trackers
...*]->roles*[scaleserver*]->engines*[slurm2]->trackers]% add queue tr2
...*]->roles*[scaleserver*]->engines*[slurm2]->trackers*[tr2*]]% set queue defq
...*]->roles*[scaleserver*]->engines*[slurm*]->trackers*[tr2*]]% commit
...->roles[scaleserver]->engines[slurm1]->trackers[tr2]]%
```

The nodes `node001..node002` and `eu-west-1-cnode001..eu-west-1-cnode002` should already be in the queue `defq` by default, ready to run the jobs:

### Example

```
...->roles[scaleserver]->engines[slurm1]->trackers[tr2]]% jobqueue use slurm defq ; get nodes
eu-west-1-cnode001
eu-west-1-cnode002
node001
node002
```

The `roleoverview` (page 272) command is also handy for an overview, and to confirm that the role assignment of these nodes are all set to the `SlurmClient` role:

With these settings, the nodes in the dynamic pool can now be powered up or down on demand by `cm-scale` service, depending on the number of jobs that are pending. When the new `ScaleServer` role is committed in `cmsh` or `Bright View`, then the `cm-scale` is run periodically. Each time it is run, `cm-scale` checks whether the node states should be changed. If needed, the administrator can check the log file `/var/log/cm-scale` to see what the service is doing.

Job submission can now be carried out, and the `scaleserver` assignment carried out earlier scales the cluster to cope with jobs according to the configuration that has been carried out in the session.

Before submitting the batch jobs, the administrator or user can check the jobs that are queued and running with the `squeue` command. If there are no jobs yet submitted, the output is simply the `squeue` headers, with no job IDs listed:

### Example

```
[fred@bright80 ~]$ squeue
JOBID PARTITION      NAME      USER ST      TIME  NODES NODELIST(REASON)
```

As in the previous example for the static pool only case (page 269), a way for user `fred` to flood the default queue `defq` is to run the batch file in a loop:

### Example

```
[fred@bright80 ~]$ while (true); do sbatch slurmhello.sh; done
Submitted batch job 1
Submitted batch job 2
Submitted batch job 3
...
```

After putting enough jobs into the queue (a few thousand should be enough, not more than five thousand would be sensible), the flooding can be stopped with a ctrl-c.

The changes in the queue can be watched by user fred:

### Example

```
[fred@bright80 ~]$ watch "squeue | head -5 ; squeue | tail -4"
Every 2.0s: squeue | head -5 ; squeue | tail -4          Wed Nov 22 16:08:52 2017
```

JOBID	PARTITION	NAME	USER	ST	TIME	NODES	ODELIST (REASON)
1	defq	slurmhel	fred	PD	0:00	1	(Resources)
2	defq	slurmhel	fred	PD	0:00	1	(Resources)
3	defq	slurmhel	fred	PD	0:00	1	(Resources)
4	defq	slurmhel	fred	PD	0:00	1	(Resources)
3556	defq	slurmhel	fred	PD	0:00	1	(Resources)
3557	defq	slurmhel	fred	PD	0:00	1	(Resources)
3558	defq	slurmhel	fred	PD	0:00	1	(Resources)
3559	defq	slurmhel	fred	PD	0:00	1	(Resources)

The head -4 and tail -4 filters here are convenient for showing just the first 4 rows and last 4 rows of the very long squeue output, and skipping the bulk of the queue.

The preceding output illustrates how, with the jobs queued up, nothing is being processed yet from jobs number 1 to 3559 due to the resources not yet being available.

At this point cm-scale should have noticed that jobs are queued and that resources are needed to handle the jobs.

At the start of this example session the cloud director is not up. So, cm-scale powers it up. This can be seen by running the ds command, or from CMDaemon info messages:

```
[bright80->device]% ds | grep director
eu-west-1-director [ DOWN ]
then some time later:
eu-west-1-director [ PENDING ] (External ip assigned: 34.249.166.63, setting up tunnel)
then some time later:
eu-west-1-director [ INSTALLING ] (node installer started)
then some time later:
eu-west-1-director [ INSTALLER_CALLINGINIT ] (switching to local root)
then some time later:
eu-west-1-director [ UP ]
```

If the cloud director is yet to be provisioned to the cloud from the head node for the very first time (“from scratch”), then that can take a while. Then, because the cloud compute nodes are in turn provisioned from the cloud director, it takes a while for the cloud compute nodes to be ready to run the jobs. So, the jobs just have to wait around in the queue until the cloud compute nodes are ready, before they are handled. Fortunately, the startup of a cloud director is by default much faster after the very first time.

A quick aside about how provisioning is speeded up the next time around: The cloud compute nodes will be stopped if they are idle, and after there are no more jobs in the queue, because the jobs have all

been dealt with. Then, when the `extranodeidletime` setting has been exceeded, the cloud director is also stopped. The next time that jobs are queued up, all the cloud nodes are provisioned from a stopped state, rather than from scratch, and so they are ready for job execution much faster. Therefore, unlike the first time, the jobs queued up the next time are processed with less waiting around.

Getting back to how things proceed in the example session after the cloud director is up: `cm-scale` then provisions the cloud compute nodes `eu-west-1-node001` and `eu-west-1-node002` from the cloud director.

### Example

```
[bright80->device]% ds | grep cnode
eu-west-1-cnode001 ..... [ PENDING ] (Waiting for instance to start)
eu-west-1-cnode002 ..... [ PENDING ] (Waiting for instance to start)
then some time later:
eu-west-1-cnode002 [      INSTALLING      ] (node installer started)
eu-west-1-cnode001 [      INSTALLING      ] (node installer started)
and so on
```

Once these cloud compute nodes reach the state of UP, they can start to process the jobs in the queue. The queue activity then would show something like:

### Example

*when the dynamic pool nodes are being readied for job execution:*

```
[fred@bright80 ~]$ squeue | head -5 ; squeue | tail -4
JOBID PARTITION      NAME      USER ST      TIME  NODES NODELIST(REASON)
    1      defq slurmhel    fred PD      0:00     1 (Resources)
    2      defq slurmhel    fred PD      0:00     1 (Resources)
    3      defq slurmhel    fred PD      0:00     1 (Resources)
    4      defq slurmhel    fred PD      0:00     1 (Resources)
  3556      defq slurmhel    fred PD      0:00     1 (Resources)
  3557      defq slurmhel    fred PD      0:00     1 (Resources)
  3558      defq slurmhel    fred PD      0:00     1 (Resources)
  3559      defq slurmhel    fred PD      0:00     1 (Resources)
```

*then later:*

```
JOBID PARTITION      NAME      USER ST      TIME  NODES NODELIST(REASON)
   11      defq slurmhel    fred CF      0:00     1 eu-west-1-cnode001
   12      defq slurmhel    fred CF      0:00     1 eu-west-1-cnode002
   13      defq slurmhel    fred CF      0:00     1 (priority)
   14      defq slurmhel    fred CG      0:00     1 (priority)
  3556      defq slurmhel    fred PD      0:00     1 (Priority)
  3557      defq slurmhel    fred PD      0:00     1 (Priority)
  3558      defq slurmhel    fred PD      0:00     1 (Priority)
  3559      defq slurmhel    fred PD      0:00     1 (Priority)
```

*then later, when `cm-scale` sees all of the dynamic pool is used up, the lower priority static pool gets started up:*

```
JOBID PARTITION      NAME      USER ST      TIME  NODES NODELIST(REASON)
   165      defq slurmhel    fred CF      0:00     1 eu-west-1-cnode001
   166      defq slurmhel    fred CF      0:00     1 node001
   168      defq slurmhel    fred CG      0:00     1 node002
  3556      defq slurmhel    fred PD      0:00     1 (Priority)
  3557      defq slurmhel    fred PD      0:00     1 (Priority)
  3558      defq slurmhel    fred PD      0:00     1 (Priority)
```

```

3559      defq slurmhel      fred PD      0:00      1 (Priority)
167       defq slurmhel      fred R       0:00      1 eu-west-1-cnnode002

```

In `cmsh`, the priority can be checked with:

#### Example

```

[bright80 ->device[bright80]->roles[scaleserver]->resourceproviders]% list
Name (key)      Priority      Enabled
-----
on-premises-nodes 1          yes
pool2           2          yes

```

Also in `cmsh`, the jobs can be listed via `jobs` mode:

#### Example

```

[bright80->jobs(slurm)]% list | head -5 ; list | tail -4
Type  Job ID User  Queue Running time Status      Nodes
-----
Slurm 334    fred  defq  1s          COMPLETED eu-west-1-cnnode001
Slurm 336    fred  defq  1s          COMPLETED node001
Slurm 3556   fred  defq  0s          PENDING
Slurm 3557   fred  defq  0s          PENDING
Slurm 3558   fred  defq  0s          PENDING
Slurm 3559   fred  defq  0s          PENDING
Slurm 335    fred  defq  1s          RUNNING    eu-west-1-cnnode002
[bright80->jobs(slurm)]%

```

Eventually, when the queue has been fully processed, the jobs are all gone:

#### Example

```

[fred@bright80 ~]$ squeue
JOBID PARTITION      NAME      USER ST      TIME  NODES NODELIST(REASON)

```

With the current configuration the cloud compute nodes in the dynamic pool `pool2` are powered up before the regular compute nodes in the static pool `on-premises-pool`. That is because the cloud compute nodes have been set by the administrator in this example to have a higher priority. This is typically suboptimal, and is actually configured this way just for illustrative purposes. In a real production cluster, the priority of regular nodes is typically going to be set higher than that for cloud compute nodes, because using on-premises nodes is likely to be cheaper.

The administrator can also check on the job status via the job metrics of `cmsh` too, using the options to the `filter` command, such as `--pending` or `--running`:

Initially, before the jobs are being run, something like this will show up:

#### Example

```

[root@bright80 ~]# cmsh -c "jobs ; watch filter --running -u fred"
Every 2.0s: filter --running -u fred                                Wed Nov 22 16:03:18 2017
No jobs found

```

Then, eventually, when the jobs are being run, the cloud nodes, which have a higher priority, start job execution, so that the output looks like:

#### Example

```

Every 2.0s: filter --running -u fred                                Wed Nov 22 16:50:35 2017
Job ID Job name      User Queue Submit time Start time End time Nodes      Exit code
-----
406    slurmhello.sh fred defq  16:16:56   16:27:21   N/A    eu-west1-cnnode001 0
407    slurmhello.sh fred defq  16:16:56   16:27:21   N/A    eu-west1-cnnode002 0

```

and eventually the regular on-site nodes which are originally down are started up by the ScaleServer and are also listed.

#### cm-scale **Engines**

Each workload engine considered by `cm-scale` must be configured within the `engines` submode within the `ScaleServer` role. Bright Cluster Manager 8.0 supports the following workload engines:

- Slurm
- PBS Professional (community and commercial versions)
- Torque
- LSF
- openlava
- UGE
- SGE
- Mesos

Engines can be of two types:

- `hpc`: for all HPC workload managers
- `mesos`: for Mesos

Both these engine types have the following parameters and submode in common, although their values may differ:

- **Workloads Per Node**: The Number of workloads that can be scheduled to run on the same node at the same time.
- **Priority**: The engine priority
- **Age Factor**: Fairsharing coefficient for workload age
- **Engine Factor**: Fairsharing coefficient for engine priority
- **Max Nodes**: The maximum number of running nodes allowed
- **Workload Manager** (only for an engine of the `hpc` type): A workload manager name
- **Trackers**: Enters the workload trackers submode



**cm-scale Trackers**

A workload tracker is a way to specify the workload and its node requirements to `cm-scale`. For HPC, the tracker may be associated with a specific queue, and `cm-scale` then tracks the jobs in that queue.

One or more trackers can be named and enabled within the `trackers` submode, which is located within the `engines` submode of the `ScaleServer` role. A queue (for workload managers) or a load (for Mesos) can be assigned to each tracker.

**Example**

There are two types of tracker objects supported in Bright Cluster Manager 8.0:

- **queue:** Used with an HPC type engine, where each workload (job) is associated with a particular queue. The attribute `Type` takes the value `ScaleHpcQueueTracker`, and the attribute `Queue` is set to the queue name for the job.
- **load:** Used with a `mesos` type engine, because no particular workload is defined by Mesos. The attribute `Type` takes the value `ScaleMesosEngine`, and a load level can be calculated and tracked for nodes.

The following settings are common for both types of trackers:

- **Enabled:** Enabled means that workloads from this tracker are considered by `cm-scale`.
- **Assign Category:** A node category name that should be assigned to the managed nodes. When a node is supposed to be used by a workload, then `cm-scale` should assign the node category to that node. If the node is already running, and has no workloads running on it, but its category differs from the category specified for the jobs of the queue, then the node is drained, stopped and restarted on the next decision-making iteration of `cm-scale`, and takes on the assigned category. Further details on this are given in the section on dynamic nodes repurposing, page 280.
- **Primary Overlays:** A list of configuration overlays.

If a workload is associated with the tracker for which the overlays are specified by `Primary Overlays`, then the Bright Cluster Manager-managed nodes are appended to those configuration overlays by `cm-scale`. This takes place after the node is removed from the previous overlays that it is associated with.

If the node is already running, but has not yet been appended to the overlays specified for the workloads of the tracker, then the node is restarted when no other workloads run on the node, before going on to run the workloads with the new overlays.

- When a workload is associated with the tracker that has `Primary Overlays` set, then the pool of `cm-scale`-managed nodes is checked.

The check is to decide on if a node is to be made available for the workload.

If the node is appended to the `Primary Overlays` already and is not running workloads, then `cm-scale` simply hands over a workload from the tracker to run on the node.

If the node is not appended to the `Primary Overlays` already, and is not running workloads, then `cm-scale` prepares and boots the node as follows:

- \* the node is drained and rebooted if it is up, or
- \* the node is undrained and merely booted if it is not up

The node is removed from any previous overlays that it was with, before booting up, and it is appended to the new overlays of `Primary Overlays`.

The `queue` type tracker has only one parameter specific to the tracker: `Queue`. This is set to the workload queue that is being tracked.

The `load` type tracker has several parameters:

- **Mesos Cluster:** Associated mesos cluster instance defined by Bright Cluster Manager configuration.
- **Load Threshold:** Mesos cluster load threshold that triggers nodes being added or removed
- **Scale Nodes:** Number of nodes that are
  - added when **Load Threshold** is reached
  - or removed when more than **Scale Nodes** are unused.

#### cm-scale **Dynamic Nodes Repurposing**

Sometimes it is useful to share the same nodes among several queues, and reuse the nodes for jobs from other queues. This can be done by dynamically assigning node categories. Different settings, or a different software image, then run on the re-assigned node after reprovisioning.

The feature is enabled by setting **Assign Category** parameter in the tracker settings.

For example, the following case uses Slurm as the workload engine, and sets up two queues **chem\_q** and **phys\_q**. Assuming in this example that jobs that are to go to **chem\_q** require chemistry software on the node, but jobs for **phys\_q** require physics software on the node, and that for some reason the softwares cannot run on the node at the same time. Then, the nodes can be repurposed dynamically. That is, the same node can be used for chemistry or physics jobs by setting up the appropriate configuration for it. In this case the same node can be used by jobs that require a different configuration, software, or even operating system. The trackers configuration may then look as follows:

#### Example

```
[bright80->device[bright80]->roles[scaleserver]->engines[slurm]->trackers[chem]]% show
Parameter                                     Value
-----
Type                                           ScaleHpcQueueTracker
Name                                           chem
Queue                                          chem_q
Enabled                                       yes
Assign Category                             chem_cat
Primary Overlays
[bright80->device[bright80]->roles[scaleserver]->engines[slurm]->trackers[chem]]% use phys
[bright80->device[bright80]->roles[scaleserver]->engines[slurm]->trackers[phys]]% show
Parameter                                     Value
-----
Type                                           ScaleHpcQueueTracker
Name                                           chem
Queue                                          chem_q
Enabled                                       yes
Assign Category                             phys_cat
Primary Overlays
[bright80->device[bright80]->roles[scaleserver]->engines[slurm]->trackers[phys]]%
```

Assuming that initially there are two nodes, **node001** and **node002**, both in category **chem\_cat**. Then, when **cm-scale** finds a pending job in queue **phys\_q**, it may decide to assign category **phys\_cat** to either **node001**, or to **node002**. In this way the number of nodes serving queue **phys\_q** increases and number of nodes serving **chem\_q** decreases, in order to handle the current workload. When the job is finished, the old node category is not assigned back to the node, until a new job appears in **chem\_q** and requires this node to have the old category.

**cm-scale Pending Reasons**

This section is related only to HPC engines (workload managers). In this section, the term job is used instead of workload.

If `cm-scale` makes a decision on how many nodes should be started for a job, then it checks the status of the job first. If the job status is `pending`, then it checks the list of *pending reasons* for that job. The checks are to find pending reasons that prevent the job from starting when more free nodes become available.

A pending reason can be one of the following 3 types:

**Type 1:** allows a job to start when new free nodes become available

**Type 2:** prevents a job from starting on particular nodes only

**Type 3:** prevents a job from starting anywhere

Each pending reason has a text associated with it. The text is usually printed by the workload manager job statistics utilities. The list of pending reasons texts of types 1 and 2 can be found in the pending reasons exclude file, `/cm/local/apps/cm-scale/lib/trackers/hpcqueue/pending_reasons/WLM.exclude`, where WLM is a name of workload manager specified in the configuration of the engine in `ScaleServer` role.

In the pending reasons exclude file, the pending reason texts are listed as one reason per line. The reasons are grouped in two sublists, with headers:

- [IGNORE\_ALWAYS]
- [IGNORE\_NO\_NODE]

The [IGNORE\_ALWAYS] sublist lists the type 1 pending reason texts. If a job has only this group of reasons, then `cm-scale` considers the job as ready to start, and attempts to create or boot compute nodes for it.

The [IGNORE\_NO\_NODE] sublist lists the type 2 pending reason texts. If the reason does not specify the hostname of a new free node at the end of a pending reason after the colon (":"), then the job can start on the node. If the reason does specify the hostname of a new free node after the colon, and if the hostname is owned by one of the managed nodes—nodes that can be stopped/started/created by `cm-scale`—then the job is considered as one that is not to start, when nodes become available.

If a job has a pending reason text that is not in the pending reasons exclude file, then it is assumed to be a type 3 reason. New free nodes for such a job do not get the job started.

If there are several pending reason texts for a job, then `cm-scale` checks all the pending reasons one by one. If all reasons are from the `IGNORE_ALWAYS` or `IGNORE_NO_NODE` sublists, and if a pending reason text matched in the `IGNORE_NO_NODE` sublist does not include hostnames for the managed nodes, only then will the job be considered as one that can be started just with new nodes.

**Custom pending reasons:** If the workload manager supports them, then custom pending reason texts are also supported. The administrator can add a pending reason text to one of the sections in the pending reasons exclude file.

The `cm-scale` service checks only if the pending reason text for the job starts with a text from the pending reasons file. It is therefore enough to specify just a part of the text of the reason in order to make `cm-scale` take it into account. Regular expressions are also supported. For example, the next two pending reason expressions are equivalent when used to match the pending reason text `Not enough job slot(s)`:

**Example**

- Not enough

- Not enough `[a-z]* slot(s)`

The workload manager statistics utility can be used to find out what custom pending reason texts there are, and to add them to the pending reasons file. To do this, some test job can be forced to have such a pending reason, and the output of the job statistics utility can then be copy-pasted. For example, LSF shows custom pending reasons that look like this:

### Example

Customized pending reason number `<integer>`

Here, `<integer>` is an identifier (an unsigned integer) for the pending reason, as defined by the administrator.

### Number Of CPU Cores Calculation

The `cm-scale` service uses the number of CPU cores on a node in order to map workloads to the node. The calculation of this number is optimized for many node scenarios.

For each node, at the beginning of each `cm-scale` iteration, the following procedure is followed step-by-step to determine the CPU cores number. The procedure for the current iteration stops when a step yields a non-zero value, otherwise the next step is tried.

1. If the engine is a workload manager, then the workload manager client role is considered and its slots parameter is used. In the very unusual case of several workload manager roles assigned to the node at the same time, then the minimum number of slots is calculated.
2. If the node is a cloud node, then its flavor `Type` parameter in the case of EC2, or `VMSize` in case of Azure, is used. These parameters are accessible via `cmsh`, within `device` mode for the cloud node, within the `cloudsettings` submode. For EC2 nodes the flavor value (`Type`) can be set to a long statement such as: "62 EC2 Compute Units (16 virtual cores with 3.00 EC2 Compute Units each)", and for this statement 16 is used as the number of CPU cores. If the flavor is not defined on the node, then its cloud provider is considered.
3. If a template node is defined in the dynamic node provider, and it is a cloud node, then the template node flavor is used for the CPU core number in the same way as shown in the preceding step.
4. If the `Default Resources` parameter (in a resource provider) contains "`cpus=N`", where `N` is a number of CPU cores, then `N` is used.
5. If the node exists at this moment (for example, it is not just cloned in Bright Cluster Manager), then the CPU cores number is requested from `CMDaemon`, which collects nodes system information. This is used as one of the last methods because it is slow.
6. If the node is defined in the `ScaleServer` role via the dynamic resource provider, then the CPU cores number is retrieved from its template node. This method is as slow as the preceding method. It is therefore not recommended when many nodes are managed by `cm-scale`, otherwise the iteration can take several minutes. In such a case, setting the slots parameter manually is typically wiser, so that step 1 is the step that decides the CPU cores number.

If `cm-scale` does not manage to find a value for the node, then it prints a warning in the log file and does not make use of the node during the iteration. It is usually wise for the administrator to set the slots parameter manually for nodes that otherwise persistently stay unused, so that resources are not wasted.

**cm-scale Locations**

Sometimes it makes sense to restrict the workload manager to run jobs only on a defined subset of nodes. For example, if a user submits a multi-node job, then it is typically better to run all the job processes either on the on-premises nodes, or on the cloud nodes. That is, without mixing the node types used for the job. The *locations* feature of *cm-scale* allows this kind of restriction for HPC workload managers.

The *cm-scale* configuration allows one of these two modes to be selected:

1. *forced location*: when the workload is forced to use one of the locations chosen by *cm-scale*,
2. *unforced location*: when workloads are free to run on any of the compute nodes that are already managed (running, freed or started) by *cm-scale*.

In Bright Cluster Manager 8.0, for a forced location, *cm-scale* supports these three different locations:

1. *local*: on-premises nodes,
2. *cloud*: AWS instances (Chapter 3 of the *Cloudbursting Manual*) or Azure instances (Chapter 5 of the *Cloudbursting Manual*)
3. *virtual*: OpenStack Bright-managed virtual nodes (Chapter 5.3 of the *OpenStack Deployment Manual*)

The mode is selected by setting the `MIX_LOCATIONS` parameter in the configuration file `/cm/local/apps/cm-scale/lib/config.py`. To have a changed setting take effect, the *cm-scale* service must be restarted.

For SGE, LSF, openlava and PBS Pro, the compute nodes must already have their configuration defined. These workload managers are therefore not compatible in Bright Cluster Manager 8.0 with the *cm-scale* dynamic resource node provider when using `MIX_LOCATIONS`, because the nodes could be removed and added automatically, and thus lose the location resource assignment. Bright Cluster Manager 8.0 does not support automatic assignment of the custom resources to the nodes of the mentioned workload managers. For now, only a static resource provider can be used with those workload managers when `MIX_LOCATIONS` is set to `False`. For Slurm and Torque this restriction is not applied.

**Slurm** Slurm does not allow the assignment of node properties (features, in Slurm terminology) to jobs if no node exists that is labelled by this property. Thus all properties used must be added to some node. This can be the template node in the case of a dynamic resource provider, or it can be an appropriate off-premises node in case of static resource provider use.

For example, in order to assign the `local` location feature to all nodes in the `default` category, the following `cmsh` commands can be executed:

**Example**

```
[root@bright80 ~]# cmsh
[bright80]% category roles default
[bright80->category[default]->roles]% use slurmclient
[bright80->category[default]->roles[slurmclient]]% append features local
[bright80->category*[default*]->roles*[slurmclient*]]% commit
```

**Torque** Torque, like Slurm, also does not allow node properties to be added as a job restriction if no node exists with the property assigned to it. Thus all properties used must be added to some node beforehand. For example, the properties `local`, `virtual` and `cloud` can be assigned to a template node in the case of dynamic resource provider use, while they can be assigned to an appropriate on-premises node in case of static resource provider use.

In order to assign the `local` location property to all nodes in the `default` category, the following `cmsh` commands can be carried out:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% category use default
[bright80->category[default]]% roles
[bright80->category[default]->roles]% use torqueclient
[bright80->category[default]->roles[torqueclient]]% append properties local
[bright80->category*[default*]->roles*[torqueclient*]]% commit
[bright80->category[default]->roles[torqueclient]]%
```

**PBS Pro** If PBS Pro or PBS Pro Community Edition is used, then in order to allow `cm-scale` to restrict the jobs to use one of the locations, the administrator has to first ensure that the `location` resource is configured in PBS Pro.

- The definition of the resource has to be present in `$PBS_HOME/server_priv/resourcedef` file
- The resource name should be in the resources list in the `$PBS_HOME/sched_priv/sched_config` file

In order to apply the changes, the `pbs` service needs to be restarted.

A node, for example `node001`, can be labelled with the location resource as follows:

### Example

```
qmgr -c "set node node001 resources_available.location=local"
```

**SGE (OGS) and UGE** To allow `cm-scale` to restrict LSF and openlava jobs, the administrator has to add a new generic resource called `location`. The resource is added as a string type complex value, using the following command:

### Example

```
qconf -mc
```

The new complex is added with a line formatted as follows:

### Example

```
location loc RESTRING == YES NO NONE 0 NO
```

The location should then be assigned to the appropriate nodes. In order to assign the location to a node, the administrator can use the `qconf -me` command, appending `location=<location>` to the `complex_values` parameter. Here `<location>` is one of the three locations supported by `cm-scale`.

**LSF and openlava** In order to allow `cm-scale` to restrict LSF and openlava jobs, the administrator has to create a new generic resource called `location`. The resource is added as dynamic string resource manually in `/cm/shared/apps/lsf/var/conf/lsf.shared` into the resource section. For example, if the header of the section is:

### Example

```
RESOURCENAME TYPE INTERVAL INCREASING DESCRIPTION
```

then the following line defines the resource:

### Example

```
location String () () (Node location)
```

To verify that the resource is added, the following command can be run:

### Example

```
lsinfo | grep location
```

When the resource is defined, then it should be assigned to the nodes. The change is performed manually in the cluster configuration file, for example in `/cm/shared/apps/lsf/var/conf/lsf.cluster.cluster1`.

The administrator needs to append `location=<location>` to resources of the nodes, where `<location>` is one of the available three locations supported by `cm-scale`.

Thus:

- `location=cloud` is added to all cloud nodes managed by `cm-scale`
- `location=local` is added to all on-premises nodes
- `location=virtual` to OpenStack virtual machine instances.

For example, if there are two nodes, `node001` (an on-premises node) and `cnode001` (a cloud node), then the host lines might look as follows:

### Example

```
node001      !    !    1    (mg location=local)
cnode001     !    !    1    (mg location=cloud)
```

After the resources are defined and assigned, then the following command needs to be run in order to apply the changes in the workload manager:

### Example

```
lsadmin reconfig
```

### Azure Storage Accounts Assignment

If an Azure node is cloned manually from some node or node template, then the Azure node gets the same storage account as the node it has been cloned from. This may slow the nodes down if too many nodes use the same storage account. The `cm-scale` utility can therefore assign different storage accounts to nodes that are cloned like this.

The maximum number of nodes for such a storage account is defined by the `AZURE_DISK_ACCOUNT_NODES` parameter. This parameter has a value of 20 by default, and can be changed in the configuration file `/cm/local/apps/cm-scale/lib/config.py`. The `cm-scale` utility must be restarted after the change.

The newly-cloned-by-`cm-scale` Azure node gets a randomly-generated storage account name if other storage accounts already have enough nodes associated with them. That is, if other storage accounts have `AZURE_DISK_ACCOUNT_NODES` or more nodes.

The storage account name is assigned in the node cloud settings in storage submode. For example, in `cmsh`, the assigned storage accounts can be viewed as follows:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device use cnode001
[bright80->device[cnode001]]% cloudsettings
[bright80->device[cnode001]->cloudsettings]% storage
```



```
[bright80->...[cnode001]->cloudsettings->storage]% get root-disk storageaccountname
azurepaclogzjus1
[bright80->...[cnode001]->cloudsettings->storage]% get node-installer-disk storageaccountname
azurepaclogzjus1
[bright80->device[cnode001]->cloudsettings->storage]% ..
[bright80->device[cnode001]->cloudsettings]% get bootdiagnosticsstorageaccountname
azurepaclogzjus1
[bright80->device[cnode001]->cloudsettings]%
```

If a node is terminated and removed from the Bright configuration, then the storage account remains in Azure. It has to be explicitly manually removed by the administrator.

### Mapping HPC Jobs To Particular Nodes

By default, `cm-scale` assumes that an HPC job submitted to a particular queue can take a node from outside the queue. This is because by assigning a category, or moving the node to a configuration overlay, the node will be moved to the appropriate queue eventually. From this point of view, the nodes form a single resource pool, and the nodes in the pool are repurposed on demand.

In some scenarios there is a need for certain types of HPC jobs run only on particular types of nodes, without the nodes being repurposed. A typical example: jobs with GPU code require cloud nodes that have access to GPU accelerators, while jobs that do not have GPU code can use the less expensive non-GPU cloud nodes. For this case then, the GPU cloud node is started when the GPU job requires a node, and otherwise a non-GPU node is started.

Job segregation is achieved in `cm-scale` as follows:

1. `PIN_QUEUES` is set to `True` in the configuration file `/cm/local/apps/cm-scale/lib/config.py`. It is `False` by default. The `cm-scale` service should then be restarted to apply the change.
2. A new queue is created, or an existing one is used. The queue is used for the jobs that require a particular node type.
3. The particular node type is added to this queue. If the node is already defined in Bright Cluster Manager, then the administrator can assign the queue to the node in the workload manager client role. For example, if the workload manager is Slurm, then the queue is assigned to the nodes in the `slurmclient` role. If the node has not been defined yet and will be cloned on demand (according to the dynamic resource provider settings, page 264), then its template node is assigned to the queue. When a new node is cloned from the template, the queue is then inherited from the template node.
4. The previous two steps are repeated for each job type.

After that, if a user submits a job to one of the queues, then `cm-scale` starts or clones a node that is linked with the job queue.

The following `cmsh` session snippet shows a configuration example:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device roles master
[bright80->device[bright80]->roles]% use scaleserver
[bright80->...roles[scaleserver]]% resourceproviders
[bright80->...roles[scaleserver]->resourceproviders]% add dynamic rp1
[bright80->...roles[scaleserver]->resourceproviders*[rp1*]]% set templatename tnode1
[bright80->...roles[scaleserver]->resourceproviders*[rp1*]]% set noderange cnode001..cnode100
[bright80->...roles[scaleserver]->resourceproviders*[rp1*]]% commit
[bright80->...roles[scaleserver]->resourceproviders*[rp1*]]% clone rp2
[bright80->...roles[scaleserver]->resourceproviders*[rp2*]]% set templatename tnode2
```



```
[bright80->...roles[scaleserver]->resourceproviders*[rp2*]]% set noderange cnode101..cnode200
[bright80->...roles[scaleserver]->resourceproviders*[rp2*]]% commit
[bright80->...roles[scaleserver]->resourceproviders*[rp2*]]% ..;..
[bright80->...roles[scaleserver]]% engines
[bright80->...roles[scaleserver]->engines]% add hpc sl
[bright80->...roles[scaleserver]->engines*[e1*]]% set workloadmanager slurm
[bright80->...roles[scaleserver]->engines*[e1*]]% trackers
[bright80->...roles[scaleserver]->engines*[e1*]->trackers]]% add queue tr1
[bright80->...roles[scaleserver]->engines*[e1*]->trackers*[tr1*]]% set queue q1
[bright80->...roles[scaleserver]->engines*[e1*]->trackers*[tr1*]]% commit
[bright80->...roles[scaleserver]->engines*[e1*]->trackers*[tr1*]]% clone tr2
[bright80->...roles[scaleserver]->engines*[e1*]->trackers*[tr2*]]% set queue q2
[bright80->...roles[scaleserver]->engines*[e1*]->trackers*[tr2*]]% commit
[bright80->...roles[scaleserver]->engines*[e1*]->trackers*[tr2*]]% category
[bright80->category]% clone default cat1
[bright80->category*[cat1*]]% roles
[bright80->category*[cat1*]->roles*]% assign slurmclient
[bright80->category*[cat1*]->roles*[slurmclient*]]% set queues q1
[bright80->category*[cat1*]->roles*[slurmclient*]]% commit
[bright80->category[cat1]->roles[slurmclient*]]% category clone cat1 cat2
[bright80->category*[cat2*]->roles*[slurmclient*]]% set queues q2
[bright80->category*[cat2*]->roles*[slurmclient*]]% commit
[bright80->category[cat2]->roles[slurmclient*]]% device use tnode1
[bright80->device[tnode1]]% set category cat1
[bright80->device*[tnode1*]]% commit
[bright80->device[tnode1]]% device use tnode2
[bright80->device[tnode2]]% set category cat2
[bright80->device*[tnode2*]]% commit
[bright80->device[tnode2]]%
```

Using the preceding configuration, the user may submit a job with a regular workload manager submission utility specifying the queue `q1` or `q2`, depending on whether the job requires nodes that should be cloned from `tnode1` or from `tnode2`.

### How To Exclude Unused Nodes From Being Stopped

If a node is idle, then by default `cm-scale` automatically stops or terminates the node.

However, in some cases there may be a need to start a node on demand, and when it becomes idle, there may be a need to keep the node running. This can be useful if the administrator would like to investigate the performance of an application, or to debug some issues. After completing the investigation or debug session, the administrator can stop the node manually.

The parameter `KEEP_RUNNING_RANGES` keeps such nodes from being stopped or terminated. The parameter should be added to the configuration file `/cm/local/apps/cm-scale/lib/config.py`. To have the changed setting take effect, the `cm-scale` service must be restarted.

`KEEP_RUNNING_RANGES` defines a map of resource provider names to node name ranges.

Extra nodes can be added to the range of the nodes. However, if the extra node must not be stopped or terminated by `cm-scale`, then for each resource provider that has such an extra node, the value of `extranodestop` must be set to `yes`.

In the following example, nodes `cnode002`, `cnode003`, `cnode004`, and `cnode010`, are associated with the `azurenodes1` resource provider. They are therefore never stopped or terminated by `cm-scale`. They are only started on demand by `cm-scale`.

The nodes `cnode012` and `cnode014` are associated with the `azurenodes2` resource provider. They are therefore also not stopped or terminated by `cm-scale`.

### Example

```

opts = {
  [...]
  "KEEP_RUNNING_RANGES": {
    "azurenodes1": "cnode002..cnode004,cnode010",
    "azurenodes2": "cnode012,cnode014"
  }
}

```

#### cm-scale Queue Node Placeholders

**Job Rejection For Exceeding Total Cluster Resources:** At the time of job submission, the workload manager checks the total available number of slots (used and unused) in a queue. This is the sum of the available slots (used and unused) provided by each node in that queue.

- Jobs that require less than the total number of slots are normally made to wait until more slots become available.
- Jobs that require more than this total number of slots are normally rejected outright by the workload manager, without being put into a wait state. This is because workload managers normally follow a logic that relies on the assumption that if the job demands more slots than can exist on the cluster as it is configured at present, then the cluster will never have enough slots to allow a job to run.

**Assuming The Resources Can Never Be Provided:** The latter assumption, that a cluster will never have enough slots to allow a job to run, is not true when the number of slots is dynamic, as is the case when `cm-scale` is used. When `cm-scale` starts up nodes, it adds them to a job queue, and the workload manager is automatically configured to allow users to submit jobs to the enlarged queue. That is, the newly available slots are configured as soon as possible so that waiting jobs are dealt with as soon as possible. For jobs that have already been rejected, and are not waiting, this is irrelevant, and users would have to submit the jobs once again.

Ideally, in this case, the workload manager should be configured to know about the number of nodes and slots that can be started up in the future, even if they do not exist yet. Based on that, jobs that would normally be rejected, could then also get told to wait until the resources are available, if it turns out that configured future resources will be enough to run the job.

**Slurm Resources Planning With Placeholders:** Slurm allows nodes that do not exist yet to be defined. These are nodes with hostnames that do not resolve, and have the Slurm setting of `state=FUTURE`. Bright Cluster Manager allows Slurm to add such “fake” nodes to Slurm queues dynamically, when not enough real nodes have yet been added. Bright Cluster Manager supports this feature only for Slurm at present.

This feature is not yet implemented for the other workload managers because they require the host-name of nodes that have been added to the workload manager configuration to be resolved.

Within the Slurm server role it is possible to set a list of placeholder objects within the `placeholder` submode of `cmsh`. Each placeholder allows the following values to be set:

- `queue`: the maximum number of nodes
- `maxnodes`: the maximum number of nodes that this queue allows
- `basenodename`: the base node name that is used when a new node name is generated
- `templatename`: a template node that is used to provide user properties taken from its `slurmclient` role when new fake nodes are added.

For example, the following `cmsh` session uses the head node with an existing `slurmserver` role to illustrate how the Slurm queue `defq` could be configured so that it always has a maximum of 32 nodes, with the nodes being like `node001`:

### Example

```
[root@bright80 ~]# scontrol show part defq | grep " Nodes="
Nodes=node001
[root@bright80 ~]# cmsh
[bright80]% device roles master
[bright80->device[bright80]->roles]% use slurmservice
[bright80->...]->roles[slurmservice]% placeholders
[bright80->...mserver]->placeholders]% add defq
[bright80->...*]->placeholders*[defq*]]% set maxnodes 32
[bright80->...*]->placeholders*[defq*]]% set basenodename placeholder
[bright80->...*]->placeholders*[defq*]]% set templatename node001
[bright80->...*]->placeholders*[defq*]]% commit
[bright80->...*]->placeholders[defq]]%
[root@bright80 ~]# scontrol show part defq | grep " Nodes="
Nodes=node001,placeholder[01-31]
```

If a new real node is added to the queue, then the number of placeholder nodes is decreased by one.

The placeholders can also be configured in Bright View via the Slurm server role options. For example, for a node node001, using the clickpath:

Devices→Physical Nodes[node001]→Edit→Settings→Roles→Slurm server role  
→Placeholders

## 7.10 Cgroups

Linux system processes and all their future children can be aggregated into sets. These sets can be made into hierarchical groups with specialized behavior using the Control Groups (cgroups) mechanism. The behaviour is controlled by different subsystems that are attached to the cgroup. A subsystem may, for example, allow particular CPU cores to be allocated, or it may restrict memory, or it may swap usage by processes that belong to the group, and so on.

Details about Linux cgroups and their subsystems can be found at <https://www.kernel.org/doc/Documentation/cgroups-v1/cgroups.txt>.

As far as workload management is concerned, it makes sense to distinguish between workload manager cgroup settings and system-wide cgroup parameters. The workload manager cgroup settings allow the administrator to configure a workload manager to use cgroups in a particular way, whereas the system-wide cgroup settings allow the administrator to manage cgroups whether a workload manager is used or not.

### 7.10.1 Cgroups Settings For Workload Managers

If the workload manager allows cgroups usage, then Bright Cluster Manager provides capabilities to manage the cgroup parameters within the workload manager.

#### Slurm

Slurm supports 3 cgroups-related plugins. These are all enabled by default, and are:

1. `proctrack/cgroup`: enables process tracking and suspend/resume capability using cgroups. This plugin is more reliable for tracking and control than the former `proctrack/linux`.
2. `task/cgroup`: provides the ability to
  - confine jobs and steps to their allocated cpuset
  - bind tasks to sockets, cores and threads
  - confine jobs and steps to specific memory resources and gres devices

3. `jobacct_gather/cgroup`: collects accounting statistics for jobs, steps and tasks using the `cpuacct`, `memory`, and `blkio` cgroups subsystems.

Slurm uses 2 configuration files to store the parameters and devices used for cgroups support:

1. `/etc/slurm/cgroup.conf`: defines parameters used by Slurm's Linux cgroup-related plugins. The file contains a section that is autogenerated by `CMDaemon`, with cgroups-related parameters defined in the `SlurmServer` role.
2. `/etc/slurm/cgroup_allowed_devices_file.conf`: declares devices that need to be allowed by default for all jobs. The syntax of this file accepts one device per line. It permits wildcard definitions such as `/dev/sda*` or `/dev/cpu/*/*`. The path to this file can be changed in `cmsh` using the `AllowedDevicesFile` option within the `cgroups` submode of the `SlurmServer` role.

For Slurm, the administrator can manage cgroups parameters using `cmsh` by going into the `cgroups` submode of the `SlurmServer` role. Parameters that can be managed include:

Parameter	Description	Configuration Parameter In <code>cgroups.conf</code>
Auto Mount*	Force Slurm to mount a cgroup subsystems if they are not mounted yet	CgroupAutomount
Mount Point	Where cgroups root is mounted	CgroupMountpoint
Task Affinity*	Set a default task affinity to bind each step task to a subset of the allocated cores using <code>sched_setaffinity</code>	TaskAffinity
Release Agent Dir	Directory containing Slurm cgroup release_agent files	CgroupReleaseAgentDir
Allowed Devices File	File used to declare the default devices for all the jobs, if <code>ConstrainDevices</code> is true	AllowedDevicesFile
Constrain Cores*	Constrain allowed cores to the subset of allocated resources	ConstrainCores
Constrain RAM Space*	Constrain the job's RAM usage	ConstrainRAMSpace
Constrain Swap Space*	Constrain the job's swap space usage	ConstrainSwapSpace
Constrain Devices*	Constrain the job's allowed devices based on GRES allocated resources	ConstrainDevices
Allowed RAM Space	Percentage memory (default is 100%) out of the allocated RAM allowed for the job cgroup RAM. If this percentage is exceeded, then the job steps will be killed and a warning message will be written to standard error.	AllowedRAMSpace

...continues

...continued

Parameter	Description	Configuration Parameter In <code>cgroups.conf</code>
Allowed Swap Space	Percent allocated memory allowed for the job cgroup swap space	AllowedSwapSpace
Max RAM Percent	Maximum percent of total RAM for a job	MaxRAMPercent
Max Swap Percent	Maximum percent of total RAM for the amount of RAM+Swap that may be used for a job	MaxSwapPercent
Min RAM Space	Minimum MB for the memory limits defined by Allowed RAM Space and Allowed Swap Space	MinRAMSpace

---

\* Boolean (takes `yes` or `no` as a value)

The options are always written in the `cgroup.conf` file.

## UGE

Univa Grid Engine allows cgroups settings to be defined at two levels.

- Globally: The parameters can be set globally in the global configuration. Bright Cluster Manager defines cgroups global settings in the `cgroups` submode of the `UGEServer` role.
- Per host: The parameters can be overridden in the host configuration for particular hosts. Bright Cluster Manager defines cgroups host settings in the `cgroups` submode of the `UGEClient` role.

The global and host level cgroups parameters are the same, and are as follows:

Parameter	Description	Configuration Parameter In <code>qconf</code>
Auto Mount*	Force UGE to mount a cgroup subsystems if they are not mounted yet	mount
Cpuset	If true, then core binding is done by the cgroup cpuset subsystem	cpuset

---

...continues

*...continued*

Parameter	Description	Configuration Parameter In <code>qconf</code>
Freezer	If true, then it enables the cgroup freezer subsystem for job suspension and resumption	<code>freezer</code>
Freeze PE Tasks	If true and the freezer subsystem is turned on, then the master task is suspended, and all slave tasks of the parallel job are also frozen	<code>freeze_pe_tasks</code>
Killing	If true then UGE signals all processes forked/started by the job until all of them are killed	<code>killing</code>
Forced NUMA	If true then on NUMA machines only local memory (memory in the same NUMA zone) is allowed to be used when the job requested memory allocation with <code>-mbind cores:strict</code>	<code>forced_numa</code>
Virtual Memory Limit	Specifies if virtual memory can be limited with cgroups	<code>h_vmem_limit</code>
Memory Free Hard	If true then kernel ensures that the job does not use more main memory than required	<code>h_mem_free_hard</code>
Memory Free Soft	If true, and the hard memory limit is turned off, then the requested memory with <code>m_mem_free</code> is a soft limit	<code>h_mem_free_soft</code>

*...continues*

...continued

Parameter	Description	Configuration Parameter In <code>qconf</code>
Min Memory Limit	A host based minimum memory limit, in bytes or values like 10M, 1G	<code>min_memory_limit</code>

\* Boolean (takes `yes` or `no` as a value)

The options are updated in UGE only when cgroups are enabled in the UGEServer or UGEClient roles. To enable them, `enabled` must be set to `true` within the `cgroups` submode of the role. By default only global cgroups settings are enabled in UGE.

### OGS

The Open Grid Scheduler version currently-supported by Bright Cluster Manager does not support Linux cgroups.

### PBS Pro

PBS Professional supports cgroups through a set of special Python hooks. The account manager at Altair must be contacted by the administrator in order to install these hooks.

### Torque

The Torque versions distributed with Bright Cluster Manager are built with cgroups support. In particular, `--enable-cpuset` is used with `configure` script. No special cgroups-related parameters are provided by Torque.

### LSF

LSF allows resource enforcement to be controlled with the Linux cgroup memory and cpuset subsystems. By default, when LSF is set up with `wlm-setup`, then both subsystems are enabled for LSF jobs. If job processes on a host use more memory than the defined limit, then the job is immediately killed by the Linux cgroup memory subsystem. The cgroups-related configuration options are available in `cmsh` or Bright View, and can be found in the `cgroups` submode of the LSFServer role:



Parameter	Description	Configuration Parameter In <code>lsf.conf</code>
Resource Enforce	Controls resource enforcement through the Linux cgroups memory and cpuset subsystem, on Linux systems with cgroups support. The resource can be either <code>memory</code> or <code>cpu</code> , or both <code>cpu</code> and <code>memory</code> , in either order (default: <code>memory cpu</code> )	LSB_RESOURCE_ENFORCE
Process Tracking*	This parameter, when enabled, has LSF track processes based on job control functions such as termination, suspension, resume, and other signals, on Linux systems which support the cgroups freezer subsystem	LSF_PROCESS_TRACKING
Linux Cgroup Accounting*	When enabled, processes are tracked based on CPU and memory accounting for Linux systems that support cgroup's memory and <code>cpuacct</code> subsystems	LSF_LINUX_CGROUP_ACCT

\* Boolean (takes `yes` or `no` as a value)

The options are updated in LSF only when cgroups is enabled in the LSFServer role. To enable cgroups, `enabled` must be set to `true` in the `cgroups` submode of the role. By default cgroups is set to enabled in LSF.

### OpenLava

OpenLava allows batch jobs to enforce CPU and memory usage during runtime. The cgroups-related configuration options are available in `cmsh` or Bright View, and can be found in the `cgroups` submode of the OpenLavaServer role:

Parameter	Description	Configuration Parameter In <code>lsf.conf</code>
Bind CPU	Enable this parameter to bind processes to CPU cores (default: <code>true</code> )	SBD_BIND_CPU
Mount Point	Where cgroups root is mounted (enables memory usage enforcement)	OL_CGROUP_ROOT

\* Boolean (takes `yes` or `no` as a value)

By default the CPU and memory enforcement mentioned here are enabled in OpenLava.

### 7.10.2 Managed Cgroups

In order to control cgroups behaviour Bright Cluster Manager introduces a new node role: CgroupSupervisor. The role is used for two purposes:

- to help collect job metrics based on cgroups
- to allow the configuration of permanent cgroups, managed by CMDaemon

When a cgroup is created manually (for example, using the `mkdir` command, then by default it disappears after the node reboots. An administrator may wish to have persistent cgroups. The current method of creating permanent cgroups is using the `cgconfig` service. The service allows the creation

of cgroup hierarchies, attaches the cgroup subsystems to the hierarchies, and manages the subsystems and the cgroups.

When the CgroupSupervisor role is assigned to a node or node category, then the `cgconfig` service is started and monitored by CMDaemon on that node or node category. CMDaemon manages the autogenerated section in the main configuration file of the service, `/etc/cgconfig.conf`. This file contains three types of entries—mount, group and template. CMDaemon manages the group and template entries on all Linux systems and in addition manages the mount entries on non-systemd systems.

Each group entry in `/etc/cgconfig.conf` describes one hierarchy of cgroups. A template entry, described further on, can be helpful when cgroup rules are defined. A mount entry defines where cgroup controllers should be mounted.

In the CgroupSupervisor role, the administrator can add a new permanent cgroup within the `cgroups` submode of the role. Configuration of each cgroup defined in the role is written by CMDaemon to `/etc/cgconfig.conf`, and is managed by the `cgconfig` service. The cgroup object that can be accessed from `cmsh` or Bright View allows a list of cgroup controllers (accessible from the `controllers` submode in the cgroup object) to be defined. In turn, each controller object in the `controllers` submode has a list of properties that depend on the controller type. Available controller types are the following:

- `cgroupcontrollerblkio`: blkio controller
- `cgroupcontrollercpuset`: cpuset controller
- `cgroupcontrollerhugetlb`: hugetlb controller
- `cgroupcontrollernetprio`: net\_prio controller
- `cgroupcontrollercpu`: cpu controller
- `cgroupcontrollerdevices`: devices controller
- `cgroupcontrollermemory`: memory controller
- `cgroupcontrollerns`: ns (namespaces) controller
- `cgroupcontrollercpuacct`: cpuacct controller
- `cgroupcontrollerfreezer`: freezer controller
- `cgroupcontrollernetcls`: net\_cls controller
- `cgroupcontrollerperf`: perf\_event controller

In `cmsh`, the permanent (managed) cgroup is created and configured from within the CgroupSupervisor role:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% device roles master
[bright80->device[bright80]->roles]% assign cgroupsupervisor; commit
[bright80->device[bright80]->roles[cgroupsupervisor]]% show
```

Parameter	Value
Cgroups	<2 in submode>
Collect Metrics	no
Name	cgroupsupervisor
Root	/sys/fs/cgroup
Type	CgroupSupervisorRole

```
[bright80->device[bright80]->roles[cgroupsupervisor]]% cgroups
[bright80->device[bright80]->roles[cgroupsupervisor->cgroups]]% add cg1
[bright80->device[bright80]->roles[cgroupsupervisor->cgroups*[cg1*]]]% show
Parameter                                Value
-----
Lookup                                  cg1
Controllers                             <0 in submode>
Is Template                             no
Managed                                yes
Name                                     cg1
Rules                                   <0 in submode>
Admin Group                             root
Admin User                              root
Task Group                              root
Task User                               root
[bright80->device*[bright80*]->roles*[cgroupsupervisor*]->cgroups*[cg1*]]% controllers
[bright80->...*]->cgroups*[cg1*]->controllers]% add cgroupcontroller<TAB><TAB>
cgroupcontrollerblkio      cgroupcontrollercpuset    cgroupcontrollerhugetlb
cgroupcontrollerlnetprio   cgroupcontrollercpu      cgroupcontrollerdevices
cgroupcontrollermemory     cgroupcontrollerlens     cgroupcontrollercpuacct
cgroupcontrollerfreezer    cgroupcontrollernetcls   cgroupcontrollerperf
[bright80->...*]->cgroups*[cg1*]->controllers]% add cgroupcontrollermemory memory
[bright80->...*]->cgroups*[cg1*]->controllers*[memory*]]% show
Parameter                                Value
-----
Enabled                                  yes
Extra Parameters
Kmem Limit
Kmem TCP Limit
Limit
Memory And Swap Limit
Move Charge At Immigrate          no
Name                               memory
OOM Control                        yes
Soft Limit
Swappiness                         60
Type                               CgroupControllerMemory
[bright80->...*]->cgroups*[cg1*]->controllers*[memory*]]% commit
[bright80->device[bright80]->roles[cgroupsupervisor]->cgroups[cg1]->controllers[memory]]%
```

Different cgroup controller types have different set of properties. When a new controller is added into the managed cgroup, then the controller name is required, but it can be any string. If the Enabled parameter for a controller is set to false, then cgroup configuration will not include the settings of that controller.

Each Group entry in `/etc/cgconfig.conf` creates a new cgroups hierarchy, sets permissions for the hierarchy and for the tasks virtual files, and configures subsystems attached to the hierarchy. The cgroup that is created in the example above would lead to the following content in `/etc/cgconfig.conf`:

### Example

```
[root@bright80 ~]# cat /etc/cgconfig.conf

# This section of this file was automatically generated by cmd. Do not edit manually!
# BEGIN AUTOGENERATED SECTION -- DO NOT REMOVE
group cg1
```

```

    perm
        admin
            uid = root;
            gid = root;

        task
            uid = root;
            gid = root;

memory
    memory.swappiness="60";
    memory.move_charge_at_immigrate="0";
    memory.oom_control="1";

# END AUTOGENERATED SECTION    -- DO NOT REMOVE

[root@bright80 ~]#

```

For operating systems that run without systemd (RHEL/SL/CentOS < 7.0 and SLES < 12), a managed cgroup also allows rules to be configured that allow processes to be moved into this cgroup automatically. For this functionality, the `cgrd` service is used. This starts the `cgrulesengd` daemon. For systemd systems this functionality is not available, because systemd prevents the `cgrd` service from doing its job. At the time of writing (January 2016) systemd does not as yet provide functionality similar to the `cgrd` service.

The `cgrulesengd` daemon (started by the `cgrd` service) reads the process movement rules from `/etc/cgrules.conf`, which can be managed by `CMDaemon`. In order to define a new rule, the administrator can add it in the `rules` submode in `cgroup` mode as follows:

### Example

```

[bright80->device[bright80]->roles[cgroupsupervisor]->cgroups[cg1]]% rules
[bright80->device[bright80]->roles[cgroupsupervisor]->cgroups[cg1]->rules]% add alice
[bright80->...[cgroupsupervisor*]->cgroups*[cg1*]->rules*[alice*]]% set controllernames cpuset
[bright80->...[cgroupsupervisor*]->cgroups*[cg1*]->rules*[alice*]]% show
Parameter                               Value
-----
Command
Controller Names                        cpuset
User                                    alice
[bright80->...[cgroupsupervisor*]->cgroups*[cg1*]->rules*[alice*]]% commit
[bright80->...[cgroupsupervisor]->cgroups[cg1]->rules[alice]]%

```

The rule name is the name of the user that the rule is applied to. It is possible to use an asterisk to define a rule for all users. The command in the rule can be set in order to apply rules only for processes spawned by that command. For example if `Command` is set to `ftp`, then when the user runs the `ftp` command, the FTP process is automatically moved to the specified cgroup, and restrictions set for the cgroup are automatically applied to that FTP process.

The rule created in the preceding example creates the following configuration file for `cgrd`:

### Example

```

[root@bright80 ~]# cat /etc/cgrules.conf

# This section of this file was automatically generated by cmd. Do not edit manually!

```

```
# BEGIN AUTOGENERATED SECTION -- DO NOT REMOVE
alice cpuset cgl
# END AUTOGENERATED SECTION    -- DO NOT REMOVE

[root@bright80 ~]#
```

It is also possible to define a template cgroup that is not created in the filesystem until a process of the specified user is started. There are several variables that can be used for specifying cgroup paths in such templates:

- %u – is replaced with the name of the user who owns the current process. If name resolution fails, UID is used instead.
- %U – is replaced with the UID of the specified user who owns the current process.
- %g – is replaced with the name of the user group that owns the current process, or with the GID if name resolution fails.
- %G – is replaced with the GID of the cgroup that owns the current process.
- %p – is replaced with the name of the current process. PID is used in case of name resolution failure.
- %P – is replaced with the of the PID of the current processes.

For example if the cgroup name is `users/%u`, then setting a rule for user `alice` in the cgroup creates a new cgroup `users/alice` and places the new processes of the user into that cgroup automatically.

More information on cgroup templates is available under `man 5 cgconfig.conf` and `man 5 cgregd.conf`.



# 8

## Containerization

Containerization is a technology that allows processes to be isolated by combining cgroups, linux namespaces, and images. Cgroups are described in section 7.10. Linux namespaces represent independent spaces for different operating system facilities: process IDs, network interfaces, mount points, inter-process communication resources and others. Such cgroups and namespaces allow processes to be isolated from each other by separating the available resources as much as possible.

A component of a container is the container image, which is a file that contains one or several layers. The layers cannot be altered as far the container is concerned, and a snapshot of the image can be used for other containers. A union file system is used to combine these layers into a single image. Union file systems allow files and directories of separate file systems to be transparently overlaid, forming a single coherent file system.

Cgroup, namespaces and image are the basis of a container. When the container is created, then a new process can be started within the container. Containerized processes running on a single machine all share the same operating system kernel, so they start instantly. No process is allowed to change the layers of the image. All changes are applied on a temporary layer created on top of the image, and these changes destroyed when the container is removed.

There are several ways to manage the containers, but the most powerful approaches use Docker, also known as Docker Engine (section 8.1), and Kubernetes (section 8.3). Docker manages containers on individual hosts, while Kubernetes manages containers across a cluster. Bright Cluster Manager integrates both of these solutions, so that setup, configuration and monitoring of containers becomes an easily-managed part of Bright Cluster Manager.

### 8.1 Docker Engine

Docker integration for Docker version 1.12.6 is supported by Bright Cluster Manager 8.0 for RHEL/SL/CentOS versions 7.2 and above, and for SLES versions 12 and above.

Docker Engine (or just Docker) is a tool for container management. Docker allows containers and their images to be created, controlled, and monitored on a host using Docker command line tools or the Docker API.

*Swarm mode*, which allows containers to spawn on several hosts, is not formally supported by Bright Cluster Manager 8.0. This is because Bright Cluster Manager 8.0 provides Kubernetes for this purpose instead.

Docker provides a utility called `docker`, and two daemons called `dockerd` and `containerd`.

Additional functionality includes pulling the container image from a specific image registry, configuring the container network, setting `systemd` limits, and attaching volumes.

#### Docker Hub Remote Registry

When a user creates a new container, an image specified by the user should be used. The images are kept either locally on a host, or in a registry. By default, Docker searches for images in Docker Hub, which is a cloud-hosted public and private registry service. Docker Hub serves a huge collection of existing

images that users can make use of. Every user is allowed to create a new account, and to upload and share images with other users. Using the Docker client, a user can search for already-published images, and then pull them down to a host in order to build containers from them.

When an image is found in the registry, then Docker verifies if the latest version of the image has already been downloaded. If it has not, then Docker downloads the images, and stores them locally. It also tries to synchronize them when a new container is created. When the latest image is downloaded, Docker creates a container from the image layers that are formatted to be used by a union file system. Docker can make use of several union file system variants, including AUFS, btrfs, vfs, and DeviceMapper.

### Local Image Registry Services

Besides using Docker Hub for the registry service, the administrator can also install a local registry service on the cluster. There are two types of such registry services provided by Docker Inc. The first one is the open source version of the registry, and can be useful if the registry is used by trusted users. This version can be installed with the Bright Cluster Manager utility `cm-docker-registry-setup`.

The second registry that can be installed is the Docker Trusted Registry, which is a proprietary, commercial version supported by Docker Inc. The commercial version provides extended functionality. The administrator can download and install this manually according to the official Docker Inc. instructions.

#### 8.1.1 Docker Setup

Bright Cluster Manager provides the following Docker packages:

- `cm-docker-engine`: docker binaries
- `cm-containerd`: tools to control runC
- `cm-runc`: CLI tool for containers
- `cm-python-docker-py`: a python library that provides python hooks to the Docker API

These packages can be installed by the administrator with the `yum` or `zypper` commands.

Typically, however, the administrator is expected to simply run the Bright Cluster Manager `cm-docker-setup` utility. The utility takes care of the installation of `cm-docker-engine` (docker binaries) and `cm-python-docker-py` packages and also takes care of Docker setup. For Bright Cluster Manager 8.0 the utility must be run with the `-e|--engine` option.

The `cm-docker-setup` utility asks several questions, such as which Docker registries are to be used, what nodes Docker is to be installed on, which volume backend to configure, and so on. If `cm-docker-setup` is run with the `-y` option, then the default values are used.

When the questions have been answered, the utility:

- installs the `cm-docker-engine`, `cm-containerd`, `cm-runc` and `cm-python-docker-py` packages, if they are not yet installed
- then assigns the `DockerHost` and `Containerd` roles to the node categories or head nodes that were specified
- adds healthchecks to the Bright Cluster Manager monitoring configuration
- performs the initial configuration of Docker.

#### Example

```
[root@bright80 ~]# cm-docker-setup -e -y
Run docker on head node (default: "no"):
    no,
    yes
```



```
Node categories (default: "default", set to "none" if you don't want to deploy
against any categories):
```

```
    default,
    none
```

```
Additional docker registries (default: none):
```

```
Storage backend (default: devicemapper):
```

```
    default,
    devicemapper
```

```
Use block device (default: no):
```

```
    no,
    yes
```

```
Loopback file size in GB for containers data (default: 100)
```

```
Loopback file size in GB for metadata (default: 2):
```

```
Setting up docker engine ...
```

```
Docker Engine has been setup successfully.
```

```
The compute nodes where docker will run must be rebooted.
```

The regular nodes on which Docker is to run should then be restarted. The restart operation provisions the updated images from the image directory onto the nodes.

The `cm-docker-engine` package also includes a module (section 2.2) file, `docker`, which must be loaded in order to use the `docker` command. By default only the administrator can run the `docker` commands after setup (some output ellipsized):

### Example

```
[root@bright80 ~]# ssh node001
[root@node001 ~]# module load docker
[root@node001 ~]# docker info
Containers: 0
Images: 0
...
Docker Root Dir: /var/lib/docker
[root@node001 ~]#
```

Or, for example, importing a container with Docker may result in the following output:

### Example

```
[root@node001 ~]# module load docker
[root@node001 ~]# docker ps --format ".ID: .Image"
270f80462a79: perl
c422ed0dc9dc: perl
99bf78eb18de: busybox
ff2d0a29ce9f: gcr.io/google_containers/pause:0.8.0
7833a3dfa45b: gcr.io/google_containers/pause:0.8.0
ce487ea2a9ec: gcr.io/google_containers/pause:0.8.0
[root@node001 ~]#
```

Regular users should however use Kubernetes instead of Docker commands. After Docker has been installed, Kubernetes can be set up, as covered in section 8.3.

## 8.1.2 Integration With Workload Managers

Bright Cluster Manager does not provide integration of Docker with workload managers. The administrator can however tune the workload managers in some cases to enable Docker support.

- LSF – An open beta version of LSF with Docker support is available from the IBM web site. This LSF version allows jobs to run in Docker containers, and monitors the container resources per job.
- OpenLava – OpenLava provides a job starter script. If the script is configured as a job starter, then all jobs start in Docker containers. Details on this are available at [https://github.com/openlava/openlava/blob/master/examples/docker/docker\\_integration.txt](https://github.com/openlava/openlava/blob/master/examples/docker/docker_integration.txt).
- PBS Pro – Altair provides a hook script that allows jobs to start in Docker containers. Altair should be contacted to obtain the script and instructions.

### 8.1.3 DockerHost Role

When `cm-docker-setup` is executed, the DockerHost role is assigned to nodes or categories. The DockerHost role is responsible for Docker service management and configuration.

The parameters that CMDaemon can configure in the DockerHost role, and the corresponding Docker options, are shown in table 8.1:

Parameter	Description	Option To docker
Debug*	Enable debug mode (default: no)	-D
Default Ulimits	Set the default ulimit options for all containers	--default-ulimit
Enable SELinux*	Enable selinux support in Docker daemon (default: yes)	--selinux-enabled
Log Level	Set the daemon logging level. In order of increasing verbosity: fatal, error, warn, info, debug. (default: info)	-l --log-level
Spool	Root of the Docker runtime (default: /var/lib/docker)	-g --graph
Tmp dir	Location for temporary files. Default: <code>\$&lt;spool&gt;/tmp</code> , where <code>\$&lt;spool&gt;</code> is replaced by the path to the Docker runtime root directory	\$DOCKER_TMPDIR
API Sockets	Daemon socket(s) to connect to (default: <code>unix:///var/run/docker.sock</code> )	-H --host
Bridge	Attach containers to a network bridge (not defined by default)	-b --bridge
Iptables*	Enable Iptables rules (default: yes)	--iptables
MTU	Set the containers network MTU, in bytes (default: 0, which does not set the MTU at all)	--mtu
User Namespace Remap	User/Group setting for user namespaces (not defined by default). It can be set to any of <code>&lt;UID&gt;</code> , <code>&lt;UID:GID&gt;</code> , <code>&lt;username&gt;</code> , <code>&lt;username:groupname&gt;</code> . If it is used, then <code>user_namespace.enable=1</code> must be set in the kernel options for the relevant nodes, and those nodes must be rebooted to pick up the new option.	--userns-remap

...continues

...continued

Parameter	Description	Option To <code>docker</code>
Insecure Registries	If registry access uses HTTPS but does not have proper certificates distributed, then the administrator can make Docker accept this situation by adding the registry to this list (empty by default)	<code>--insecure-registry</code>
Certificates Path	Path to Docker certificates (default: <code>/etc/docker</code> )	<code>\$DOCKER_CERT_PATH</code>
Enable TLS*	Use TLS (default: no)	<code>--tls</code>
TLS CA	Trust only certificates that are signed by this CA (not defined by default)	<code>--tlscacert</code>
TLS Certificate	Path to TLS certificate file (not defined by default)	<code>--tlscert</code>
TLS Key	Path to TLS key file (not defined by default)	<code>--tlskey</code>
Verify TLS*	Use TLS and verify the remote (default: no)	<code>--tlsverify</code>
Storage Backends	Docker storage backends	
Containerd Socket	Path to containerd socket (default: <code>/run/containerd/containerd.sock</code> )	<code>--containerd</code>
Options	Additional parameters for <code>docker daemon</code>	

\* Boolean (takes yes or no as a value)

**Table 8.1:** DockerHost role and docker options

#### 8.1.4 Iptables

By default Iptables rules have been added to nodes that function as a Docker host, to let network traffic go from the containers to outside the pods network. If this conflicts with other software that uses Iptables, then this option can be disabled. For example, if the `docker::host` has already been assigned to the nodes via the `default` category, then the Iptables rules that are set can be disabled by setting the `iptables` parameter in the `Docker::Host` role to no:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% category use default
[bright80->category[default]]% roles
[bright80->category[default]->roles]% use docker::host
[bright80->category[default]->roles[Docker::Host]]% set iptables no
[bright80->category*[default*]->roles*[Docker::Host*]]% commit
```

#### 8.1.5 Storage Backends

A core part of the Docker model is the efficient use of containers based on layered images. To implement this, Docker provides different storage backends, also called storage drivers, that rely heavily on various filesystem features in the kernel or volume manager. Some storage backends perform better than others, depending on the circumstances.

The default storage backend configured by `cm-docker-setup` is `devicemapper`. Storage backends supported by Docker are listed in table 8.2:

Technology	Description	Backend Name
VFS	Very simple fallback backend that has no copy-on-write support. Creating a new layer based on another layer is done by making a deep copy of the base layer into a new directory. Not recommended for production usage.	<code>vfs</code>
Device Mapper	This is a kernel-based framework that has been included in the mainline Linux kernel since version 2.6.9. It underpins many advanced volume management technologies on Linux. The driver stores every image and snapshot on its own virtual device and works at the block level rather than the file level.	<code>devicemapper</code>
Btrfs	It is included in the mainline Linux kernel and its on-disk-format is now considered stable. However, many of its features are still under heavy development.	<code>btrfs</code>
AUFS	This was the first storage backend that Docker used. It includes the following features: fast container startup time, efficient use of storage, and efficient use of memory. AUFS is not included in the mainline Linux kernel, and some Linux distributions also do not support AUFS.	<code>aufs</code>
ZFS	This is a filesystem that supports many advanced storage technologies, including: volume management, snapshots, checksumming, compression, deduplication, and replication. ZFS can be installed on Linux, however, for now the ZFS Docker storage driver is not recommended for production use.	<code>zfs</code>
OverlayFS	This is a modern union filesystem that is similar to AUFS, but with a simpler design, and also potentially faster. It has been in the mainline Linux kernel since version 3.18. OverlayFS is still relatively young, and administrators should therefore be cautious before using it in production Docker environments.	<code>overlay</code>

**Table 8.2:** Docker storage backends

To find out which storage driver is set on the daemon, the `docker info` command can be used:

### Example

```
[root@bright80 ~]# module load docker
[root@bright80 ~]# docker info
Containers: 74
Images: 18
Storage Driver: devicemapper
Pool Name: docker-253:3-2819682-pool
Pool Blocksize: 65.54 kB
Backing Filesystem: extfs
Data file: /dev/loop0
Metadata file: /dev/loop1
Data Space Used: 2.687 GB
Data Space Total: 107.4 GB
Data Space Available: 25.44 GB
Metadata Space Used: 6.55 MB
Metadata Space Total: 2.147 GB
```

```
Metadata Space Available: 2.141 GB
Udev Sync Supported: true
Deferred Removal Enabled: false
Data loop file: /var/lib/docker/devicemapper/devicemapper/data
Metadata loop file: /var/lib/docker/devicemapper/devicemapper/metadata
<...>
```

Docker data volumes are not controlled by the storage driver. Reads and writes to data volumes bypass the storage driver. It is possible to mount any number of data volumes into a container. Multiple containers can also share one or more data volumes.

More information about Docker storage backends is available at <https://docs.docker.com/engine/userguide/storagedriver>.

### Device Mapper Driver Settings Support

Bright Cluster Manager supports only device mapper driver settings, but the settings of other backends can be added by using the `Options` parameter in the `DockerHost` role. By default the device mapper storage backend is added automatically, and can be configured in the `storagebackends` submode of the `DockerHost` role:

### Example

```
[bright80->device[bright80]->roles[dockerhost]]% storagebackends
[bright80->device[bright80]->roles[dockerhost]->storagebackends]% use devicemapper
[bright80->device[bright80]->roles[dockerhost]->storagebackends[devicemapper]]% show
Parameter                                     Value
-----
Blk Discard                                  yes
Block Size                                   64K
Filesystem                                   xfs
Loop Data Size                               100GB
Loop Device Size                             2GB
Loop Metadata Size                           2GB
Mkfs Arguments
Mount Options
Name                                          devicemapper
Pool Device
Type                                          DockerStorageDeviceMapperBackend
```

The device mapper backend parameters are described in table 8.3:

Parameter	Description	Option to docker
Blk Discard*	Enables or disables the use of <code>blkdiscard</code> when removing device mapper devices (default: <code>yes</code> )	<code>dm.blkdiscard</code>
Block Size	Custom blocksize to use for the thin pool (default: 64kB)	<code>dm.blocksize</code>
Filesystem	Filesystem type to use for the base device (default: <code>xfs</code> )	<code>dm.fs</code>

...continues

...continued

Parameter	Description	Option to docker
Loop Data Size	Size to use when creating the loopback file for the data virtual device which is used for the thin pool (default: 100GB)	dm.loopdatasize
Loop Device Size	Size to use when creating the base device, which limits the size of images and container (not set by default)	dm.basesize
Loop Metadata Size	Size to use when creating the loopback file for the metadadata device which is used for the thin pool (default: 2GB)	dm.loopmetadatasize
Mkfs Arguments	Extra mkfs arguments to be used when creating the base device	dm.mkfsarg
Mount Options	Extra mount options used when mounting the thin devices	dm.mountopt
Pool Device	Custom block storage device to use for the thin pool (not set by default)	dm.thinpooldev

\* Boolean (takes yes or no as a value)

**Table 8.3:** Device mapper backends and docker options

### 8.1.6 The Container Daemon Service And RunC Runtime

#### ContainerdHost Role

When `cm-docker-setup` is executed, the ContainerdHost role is assigned to nodes or categories together with the DockerHost role. The ContainerdHost role runs the container daemon, as a service called `containerd`. The daemon controls the runC runtime, which is the default execution component of Docker Engine.

#### The RunC Runtime

The runC runtime handles OCI (Open Container Initiative) images and manages their lifecycle according the Open Containers runtime specification. Users can replace the runC binary on their system with an alternative runtime—for example with execution components that have a preferred security or performance, as they become available—but still reap the benefits of using the Docker API.

#### Parameters And Configuration For ContainerdHost And RunC

The parameters that CMDaemon can configure in the ContainerdHost role, and the corresponding `containerd` options, are shown in table 8.4:

Parameter	Description	Option To containerd
Debug*	Enable debug mode (default: no)	--debug
Listen Address	Address on which gRPC API will listen (default: <code>unix:///run/containerd/containerd.sock</code> )	--listen

...continues

...continued

Parameter	Description	Option To containerd
Runtime	Name of the OCI-compliant runtime to use when executing containers (default: <code>runc</code> )	<code>--runtime</code>
Runtime Arguments	Additional runtime arguments	<code>--runtime-args</code>
Spool	Runtime state directory (default: <code>/run/containerd</code> )	<code>--state-dir</code>
Start Timeout	Timeout duration (in seconds) for waiting on a container to start before it is killed (default: 60)	<code>--start-timeout</code>
Retain Count	Number of past events to keep in the event log (default: 500)	<code>--retain-count</code>
Options	Additional parameters for <code>containerd</code> daemon	

\* Boolean (takes `yes` or `no` as a value)

**Table 8.4:** *ContainerdHost* role settings And *containerd* options

The root directory path for Container daemon setup takes the following format:

`/cm/local/apps/containerd/<version>`.

### Packages And Installation

The `cm-containerd` RPM package: is available from the Bright repository. It is installed automatically by the `cm-docker-setup` package, and it provides or sets up:

- the `containerd` service
- the `containerd` environment module file (section 2.2 of this manual, and 7.1 of the *Installation Manual*). Users must load this when accessing the `containerd` service.
- the `ctr` command-line utility. The `ctr` utility allows users to interact with the Container daemon. If Docker is used, then the `ctr` utility is not normally needed during regular use, but it can be used for debugging purposes.

### Example

```
[root@bright80 ~]# module load containerd
[root@bright80 ~]# ctr containers
ID                PATH                STATUS  PROCESSES
964f59[...]       /var/run/docker/libcontainerd/964f59[...]  running  init
f2107a[...]       /var/run/docker/libcontainerd/f2107a[...]  running  init
0483b3[...]       /var/run/docker/libcontainerd/0483b3[...]  running  init
b48daf[...]       /var/run/docker/libcontainerd/b48daf[...]  running  init
%[root@bright80 ~]#
```

The `cm-runc` RPM package: is available from the Bright repository. It is installed automatically by `cm-docker-setup`, and it provides or sets up:

- the default Docker runtime, which is the `runc` binary. The `runc` binary can create and manage OCI containers. A user can also create a container manually with it, but typically users don't use it directly if Docker is installed.
- the `runc` environment module file. Users must load this before using `runC`.

### 8.1.7 Docker Monitoring

When `cm-docker-setup` runs, it configures and runs the following Docker healthchecks:

1. makes a test API call to the endpoint of the Docker daemon
2. checks containers to see that none is in a dead state

## 8.2 Docker Registry

An optional Docker Registry is available for local storage of Docker images.

### 8.2.1 Docker Registry Setup

The Docker registry can be installed via the `cm-docker-registry-setup` command-line utility. It can also be installed via Bright View as follows:

1. The administrator launches Bright View at `https://headnode:8081/bright-view`
2. The clickpath Containers→Docker→Docker Registry wizard is started
3. One or more nodes are ticked for Docker registry Deployment. The address, port, and the root directory for storing the container images are configured.
4. In the summary page, ticking the Ready for deployment box lets the administrator go ahead with deploying the registry.
5. When deployment is complete, container images become ready for use.

### 8.2.2 DockerRegistry Role

The DockerRegistry role is used to configure and manage the `registry` daemon, which provides storage and APIs for container images.

The DockerRegistry role parameters are described in table 8.5:

Parameter	Description	Option to registry
Address	Address to bind (default: <code>:5000</code> )	<code>http.addr</code>
Certificate	File containing x509 Certificate used by Docker Registry daemon (default: <code>/etc/docker-registry/cert/registry.pem</code> )	<code>http.tls.certificate</code>
Headers	Headers (default: <code>"X-Content-Type-Options=nosniff"</code> )	<code>http.headers</code>
Host	Host (default: <code>docker-registry</code> )	<code>http.host</code>
Key	File containing x509 private key used by Docker Registry daemon (default: <code>/etc/docker-registry/cert/registry.key</code> )	<code>http.tls.key</code>
Relative URLs*	Relative URLs (default: <code>no</code> )	<code>http.relativeurls</code>

...continues



...continued

Parameter	Description	Option to registry
Repository Prefix	Repository prefix (empty by default)	http.prefix
Storage Drivers	Docker storage backends (filesystem.rootdirectory default: /var/lib/docker-registry)	storage

\* Boolean (takes yes or no as a value)

**Table 8.5:** DockerRegistry role parameters and registry options

Further details on the registry daemon can be found at <https://github.com/docker/distribution>.

## 8.3 Kubernetes

Kubernetes is an open-source platform for automating deployment, scaling, and operations of application containers across clusters of hosts. With Kubernetes, it is possible to:

- scale applications on the fly
- seamlessly update running services
- optimize hardware usage by using only the resources that are needed

Bright Cluster Manager provides the administrator with the required packages, allows Kubernetes to be set up on cluster, and manages and monitors Kubernetes. More information about the design of Kubernetes, its command line interfaces, and other Kubernetes-specific details, can be found at the official online documentation at <https://kubernetes.io/docs/>.

Bright Cluster Manager 8.0 at the time of writing of this section (October 2017) supports Kubernetes v1.6.4 integration on RHEL/SL/CentOS versions 7.2 and higher, and on SLES version 12 and higher.

### 8.3.1 Kubernetes Setup

Bright Cluster Manager provides seven Kubernetes-related packages:

1. cm-kubernetes-master
  2. cm-kubernetes-node
  3. cm-etcd
  4. cm-flannel
  5. cm-kubernetes-dns
  6. cm-kubernetes-dashboard
  7. cm-heapster
- The packages cm-kubernetes-master, cm-etcd, cm-flannel, cm-kubernetes-dns, cm-kubernetes-dashboard, and cm-heapster are installed on the head node.
  - The packages cm-kubernetes-node, cm-flannel, and cm-kubernetes-dns are installed on all Kubernetes cluster nodes.
  - The package cm-etcd contains distributed key-value storage binaries in etcd that are required by Kubernetes and Flannel.

- The package `cm-flannel` is used to provide a virtual network that gives a subnet to each host for use with container runtimes. Pods then have reachable IP addresses across the Kubernetes cluster (section 8.3.6).
- The packages `cm-kubernetes-dns`, `cm-kubernetes-dashboard` and `cm-heapster` are Kubernetes add-ons:
  - The `cm-kubernetes-dns` package provides DNS support for Kubernetes services in order to not have to use virtual IP addresses directly.
  - The `cm-kubernetes-dashboard` package provides a web user interface for easy cluster administration and metrics visualization.
  - The `cm-heapster` package collects cluster-wide resource usage metrics, exposes these metrics via an API, and enables the `HorizontalPodAutoscaler` feature.

The packages are installed automatically from the repository when the administrator runs `cm-kubernetes-setup` from the command line.

### Kubernetes Setup From The Command Line

The command line utility has the following usage synopsis:

```
[root@bright80 ~]# cm-kubernetes-setup -h
# cm-kubernetes-setup -h
usage: Kubernetes Setup cm-kubernetes-setup [-v] [-h] [-c <config_file>]
                                           [--dev] [--tests]
                                           [--undo-on-error]
                                           [--on-error-action debug,remotedebug,undo,abort]
                                           [--output-remote-execution-runner]
                                           [--json-output <path_to_file>]
                                           [--play-scenario <path_to_file>]
                                           [--rec-scenario <path_to_file>]
                                           [--skip-rpms] [--add-user]
                                           [--add-certs] [--remove]

common:
  Common arguments
  -v                      Verbose output
  -h, --help              Print this screen
  -c <config_file>        Load runtime configuration for modules from a YAML config file

advanced:
  Various *advanced* configuration options flags.
  --dev                  Enables additional command line arguments
  --tests                Test integrity of the utility by running Unit Tests
  --undo-on-error        Upon encountering a critical error, instead of asking the user for
                           choice, setup will undo (revert) the deployment stages.
  --on-error-action debug,remotedebug,undo,abort
                           Upon encountering a critical error, instead of asking the user for
                           choice, setup will undo (revert) the deployment stages.
  --output-remote-execution-runner
                           Format output for CMDaemon
  --json-output <path_to_file>
                           Generate a file containing json-formatted summary of the deployment
  --play-scenario <path_to_file>
                           Reproduce wizard scenario recorded before
  --rec-scenario <path_to_file>
                           Record wizard scenario

installing Kubernetes:
```

```

Flags for installing or managing Kubernetes
--skip-rpms           Skip the any stages which install packages. Requires packages to be
                      already installed.
--add-user            Create a new user to Kubernetes
--add-certs           Generate certificates for Kubernetes
removing Kubernetes:
Flags for removing Kubernetes
--remove             Remove Kubernetes

```

The `cm-kubernetes-setup` utility should be executed on the console.

The `--add-user` option can be used to make a user a Kubernetes user.

**Dealing With A Pre-existing Docker Installation:** Docker is required for Kubernetes configured by Bright Cluster Manager. The setup wizard checks if Docker has been installed (page 302), and automatically installs Docker, if needed. However, if Docker has already been configured on the same category of nodes on which Kubernetes is to be installed, then the installation stops, because overriding the existing Docker configuration may not be what is wanted. To override the existing Docker configuration, Docker for that category should first be disabled with the `cm-docker-setup -d` command.

When the Kubernetes installation is carried out using `cm-kubernetes-setup`, the administrator answers several questions. These include questions about the node categories which should be configured to run the Kubernetes services, the service and pod networks parameters, the port numbers that will be configured for the daemons, whether to install specific add-ons, and so on. The `-y|--yes` option to `cm-kubernetes-setup` uses the default values. After the questions have been answered, appropriate roles will be assigned, the new Kubernetes cluster will be added, health checks will be added to the monitoring configuration, and Kubernetes daemons certificates will be generated:

### Example

```

[root@bright80 ~]# cm-kubernetes-setup -y
Running sanity checks ...
[ OK ] Cluster is clean. No Kubernetes setup detected.

0 error(s) detected.

Sanity checks passed. Kubernetes Setup can continue.
Setting up Kubernetes...
Configuring monitoring ...

Kubernetes has been setup successfully.
The compute nodes where pods will run must be rebooted.

```

### Testing Kubernetes

To test that Kubernetes can function, the `cluster-info` command can be run. For example, on the head node, `bright80`:

### Example

```

[root@bright80 ~]# module load kubernetes
[root@bright80 ~]# kubectl cluster-info
Kubernetes master is running at https://bright80:6443

```

To further debug and diagnose cluster problems, use `'kubectl cluster-info dump'`.

After `cm-kubernetes-setup` finishes, and the regular nodes have been rebooted, the state of the nodes can be found by running the `get nodes` command:

### Example

```
[root@bright80 ~]# kubectl get nodes
NAME      STATUS   AGE      VERSION
node001   Ready    1h       v1.6.1+b0b7a32
node002   Ready    1h       v1.6.1+b0b7a32
node003   Ready    1h       v1.6.1+b0b7a32
```

The administrator can now configure the cluster to suit the particular site requirements.

### 8.3.2 Disabling Kubernetes

The Kubernetes configuration can be removed using the text-based `cm-kubernetes-setup` utility with the `--remove` option as follows (some output ellipsized):

#### Example

```
# cm-kubernetes-setup --remove
Executing 30 stages
##### Starting execution for 'Kubernetes Setup'
Connecting to CMDaemon
- kubernetes
## Progress: 3
#### stage: kubernetes: Search Kube Clusters
## Progress: 6
#### stage: kubernetes: Check Kube Cluster Exists
## Progress: 10
#### stage: kubernetes: Close Shorewall Port On Headnode
Closing port 6443 in Shorewall
Restarting shorewall
## Progress: 13
#### stage: kubernetes: Get Docker Objects
## Progress: 16
#### stage: kubernetes: Get Kube Objects
## Progress: 20
#### stage: kubernetes: Get Node Objects
## Progress: 23
#### stage: kubernetes: Unassign Role From Nodes
## Progress: 26
...
## Progress: 60
#### stage: kubernetes: Unassign Role From Categories
...
## Progress: 96
#### stage: kubernetes: Remove Kube Objects
## Progress: 100
#### stage: kubernetes: Remove Docker Objects

Took:      00:07 min.
Progress: 100/100
##### Finished execution for 'Kubernetes Setup', status: completed
Kubernetes Setup finished!
```

Using the `--remove` option removes the Kubernetes cluster configuration from Bright Cluster Manager, unassigns Kubernetes-related roles—including the `EtcdHost`, `FlannelHost` and `FlannelConfiguration` roles—and removes Kubernetes health checks. The command does not remove packages that were installed with a `cm-kubernetes-setup` command before that.

After the disabling procedure has finished, the cluster has no Kubernetes configured and running.

### 8.3.3 Kubernetes Cluster

Kubernetes allows several Kubernetes clusters to be configured. These are separated sets of hosts with different certificates, users and other global settings. Bright Cluster Manager 8.0 supports only one Kubernetes cluster. During the Kubernetes setup the Kubernetes cluster name will be asked, and a new object with the cluster settings is then added into the CMDaemon configuration. The administrator can change the settings of the cluster from within the `kubernetes` mode of `cmsh` or within the `Kubernetes Clusters` options window of Bright View, accessible via the clickpath `Containers→Kubernetes Clusters`.

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% kubernetes list
Name (key)
-----
default
[bright80]% kubernetes use default
[bright80->kubernetes[default]]% show
Parameter                               Value
-----
Notes
Revision
Name                                     default
Authorization Mode                       ABAC
Authorization Policy File                /cm/local/apps/kubernetes/var/etc/auth-policy.jsonl
User Policies                           <2 in submode>
Kube Config                             /cm/local/apps/kubernetes/var/etc/kubeconfig
Kube Config Template                    <371 bytes>
CA                                       /cm/local/apps/kubernetes/var/etc/kubeca.pem
Kubernetes Certificate                  /cm/local/apps/kubernetes/var/etc/kube.pem
Kubernetes Key                          /cm/local/apps/kubernetes/var/etc/kube.key
Cluster Domain                          cluster.local.
Etcd Prefix                             /kube-apiserver
Etcd Servers                             http://master:5001
Service Network                         kubeservicenet
Pod Network                             kubepodnet

[bright80->kubernetes[default]]%
```

The preceding `kubernetes` mode parameters are described in table 8.6:

Parameter	Description
Authorization Mode	Selects how to authorize on the secure port (default: ABAC (Attribute-Based Access Control))
Authorization Policy File	File with authorization policy
User Policies	User authorization policies available

...continues

...continued

Parameter	Description
Kube Config	Path to a kubeconfig file, specifying how to authenticate to API server
Kube Config Template	Template for system kubeconfig file
CA	If set, any request presenting a client certificate signed by one of the authorities in the <code>--client-ca-file</code> option used by the Kubernetes API server is authenticated with an identity corresponding to the <code>CommonName</code> of the client certificate
Kubernetes Certificate	File containing x509 certificate used by the Kubernetes daemons
Kubernetes Key	File containing x509 private key used by the Kubernetes daemons
Cluster Domain	Domain for this cluster
Etcd Prefix	The prefix for all resource paths in <code>etcd</code> (excluding Flannel)
Etcd Servers	List of <code>etcd</code> servers to watch (format: <code>http://&lt;IP address&gt;:&lt;port number&gt;</code> )
Service Network	Network from which the service cluster IP addresses will be assigned, in IPv4 CIDR format. Must not overlap with any IP address ranges assigned to nodes for pods. Default: <code>172.29.0.0/16</code>
Pod Network	Network where pod IP addresses will be assigned from

**Table 8.6:** *kubernetes mode parameters*

### 8.3.4 Kubernetes Roles

Kubernetes roles include the following roles:

- EtcdHost (page 317)
- FlannelHost (page 317)
- FlannelConfiguration (page 318)
- KubernetesApiServer (page 319)
- KubernetesController (page 321)
- KubernetesScheduler (page 322)
- KubernetesProxy (page 323)
- KubernetesNode (page 324)
- KubernetesDNS (page 327)

- `KubernetesDashboard` (page 327)
- `KubernetesHeapster` (page 328)

When nodes are configured using Kubernetes roles, then settings in these roles may sometimes use the same pointer variables—for example the certificates path, or the Kubernetes cluster instance. Pointer variables such as these have definitions that are shared across the roles, as indicated by the parameter description tables for the roles, and which are described in the following pages.

### EtcdHost Role

The `EtcdHost` role is used to configure and manage the `etcd` service. The `etcd` service manages the `etcd` database, which is a hierarchical distributed key-value database. The database is used by Kubernetes to store its configurations. The `EtcdHost` role parameters are described in table 8.7:

Parameter	Description	Option to <code>etcd</code>
Member Name	The human-readable name for this <code>etcd</code> member ( <code>\$hostname</code> will be replaced by the node hostname)	<code>--name</code>
Spool	Path to the data directory (default: <code>/var/lib/etcd</code> )	<code>--data-dir</code>
Advertise Client URLs	List of client URLs for this member to advertise publicly (default: <code>http://\$hostname:5001</code> )	<code>--advertise-client-urls</code>
Advertise Peers URLs	List of peer URLs for this member to advertise to the rest of the cluster (default: <code>http://\$hostname:5002</code> )	<code>--initial-advertise-peer-urls</code>
Listen Client URLs	List of URLs to listen on for client traffic (default: <code>http://\$hostname:5001</code> , <code>http://127.0.0.1:2379</code> )	<code>--listen-client-urls</code>
Listen Peer URLs	List of URLs to listen on for peer traffic (default: <code>http://\$hostname:5002</code> )	<code>--listen-peer-urls</code>
Snapshot Count	Number of committed transactions that trigger a snapshot to disk (default: 5000)	<code>--snapshot-count</code>
Debug*	Drop the default log level to <code>DEBUG</code> for all subpackages (default: <code>no</code> )	<code>--debug</code>
Options	Additional parameters for the <code>etcd</code> daemon (empty by default)	

\* Boolean (takes `yes` or `no` as a value)

**Table 8.7:** *EtcdHost* role parameters and `etcd` options

The `etcd` settings are updated by Bright Cluster Manager in `/cm/local/apps/etcd/current/etc/cm-etcd.conf`.

Further details on the `etcd` store can be found at <https://kubernetes.io/docs/admin/etcd/>.

### FlannelHost Role

The `FlannelHost` role is used to configure and manage the `flanneld` daemon, which is a node agent that runs on each node. The `flanneld` daemon creates a inter-host, cluster-wide network for pods.

Parameter	Description	Option to flanneld
Etcd Endpoints	Address list of the Etcd clusters (default: <code>http://master:5001</code> )	<code>--etcd-endpoints</code>
Etcd Key Prefix	Namespace inside Etcd store for network data (default: <code>/coreos.com/network</code> )	<code>--etcd-prefix</code>
Interface Name	Interface to use for inter-host communication (empty by default)	<code>--iface</code>
Log Level	Log level (default: 0)	<code>-v</code>

**Table 8.8:** *FlannelHost* role parameters and *flanneld* options

The *FlannelHost* role parameters are described in table 8.8:

Further details on the *flanneld* daemon can be found at <https://github.com/coreos/flannel>.

### FlannelConfiguration Role

The *FlannelConfiguration* role is used to configure and manage the Flannel networking configuration into an Etcd cluster. The parameters in this role should be kept in sync with the *FlannelHost* role.

The *FlannelConfiguration* role parameters are described in table 8.9:

Parameter	Description
Etcd Endpoints	Address list of the Etcd clusters (default: <code>http://master:5001</code> )
Etcd Key Prefix	Namespace inside Etcd store for network data (default: <code>/coreos.com/network</code> )
Network	Name of the pod network (default: <code>kubepodnet</code> ) used by the entire Flannel network. It refers to a network object called <code>podnetwork</code> , specified in the Kubernetes cluster. The <code>podnetwork</code> object has a default CIDR of <code>172.29.0.0/16</code> as one of its attributes.
subnetlen	The size of the subnet prefix length allocated to each host. A value of 0 implies the default value of 24, unless the network is smaller than a /24 network, for example: /26 (in which case the prefix length for the subnet is greater by one, in this example: /27). (default: 0)

...continues



*...continued*

Parameter	Description
<code>subnetmax</code>	The end of the IP range which the subnet allocation should end with (default: the last subnet of <code>Network</code> )
<code>subnetmin</code>	The beginning of IP range which the subnet allocation should start with (default: the first subnet of <code>Network</code> )
<code>Networking Backends</code>	Type of backend to use and specific configurations for that backend (default: <code>udp</code> ) The default port that is used for the backend is 7890.

**Table 8.9:** *FlannelConfiguration* role parameters**KubernetesApiServer Role**

The Kubernetes API Server role is used to configure and manage the `kube-apiserver` daemon. The `kube-apiserver` daemon is a Kubernetes API server that validates and configures data for the Kubernetes API objects. The API objects include pods, services, and replication controllers. The API Server processes REST operations, and provides a front end to the shared state of the cluster through which all the other components interact.

The `KubernetesApiServer` role parameters are described in table 8.10:

Parameter	Description	Option to kube-apiserver
Kubernetes Cluster	The Kubernetes cluster instance (pointer)	
Insecure API Port	The port on which to serve unsecured, unauthenticated access (disabled by default)	--insecure-port
Secure API Port	The port on which to serve HTTPS with authentication and authorization. If 0, then HTTPS will not be served at all. (default: 6443)	--secure-port
Insecure Bind Address	IP address to serve on (default: 127.0.0.1)	--insecure-bind-address
Secure Bind Address	The IP address on which to serve the read- and secure ports (default: 0.0.0.0)	--bind-address
Admission Control	Ordered list of plug-ins to control the admission of resources into the cluster) (default: AlwaysAdmin)	--admission-control
Allowed Privileged*	If true, allow privileged containers (default: no)	--allow-privileged
Event TTL	Time period that events are retained. Empty by default, and a format example: 1h0m0s	--event-ttl

...continues

...continued

Parameter	Description	Option to kube-apiserver
Kubelet Timeout	Kubelet port timeout (default: 5s)	--kubelet-timeout
Log Level	Log level (default: 0)	--v
Log To StdErr*	Logging to stderr means it goes into the systemd journal (default: yes)	--logtostderr
Options	Additional parameters for the kube-apiserver daemon (empty by default)	

\* Boolean (takes yes or no as a value)

**Table 8.10:** *KubernetesApiServer role parameters and kube-apiserver options*

Further details on the Kubernetes API Server can be found at <https://kubernetes.io/docs/admin/kube-apiserver/>.

### KubernetesController Role

The Kubernetes Controller role is used to configure and manage the kube-controller-manager daemon that embeds the core control loops shipped with Kubernetes. In Kubernetes, a controller is a control loop that watches the shared state of the cluster through the API server, and it makes changes in order to try to move the current state towards the desired state. Examples of controllers that ship with Kubernetes at the time of writing (March 2017) are the replication controller, endpoints controller, namespace controller, and serviceaccounts controller.

The KubernetesController role parameters are described in table 8.11:

Parameter	Description	Option to kube-controller-manager
Kubernetes Cluster	The Kubernetes cluster instance (pointer)	
Address	IP address to serve on (default: 0.0.0.0)	--address
Port	Port to serve on (default: 10252)	--port
Concurrent Endpoint Syncs	Number of endpoint syncing operations that will be done concurrently. (default: 5)	--concurrent-endpoint-syncs
Concurrent Rc Syncs	The number of replication controllers that are allowed to sync concurrently. 5	--concurrent-rc-syncs
Namespace Sync Period	Period for syncing namespace life-cycle updates	--namespace-sync-period
Node Monitor Grace Period	Period for syncing NodeStatus in NodeController	--node-monitor-grace-period

...continues

...continued

Parameter	Description	Option to kube-controller-manager
Node Monitor Period	Period the running Node is allowed to be unresponsive before marking it unhealthy	--node-monitor-period
Node Startup Grace Period	Period the starting Node is allowed to be unresponsive before marking it unhealthy	--node-startup-grace-period
Node Sync Period	Period for syncing nodes from cloud-provider	--node-sync-period
Pod Eviction Timeout	Grace period for deleting pods on failed nodes	--pod-eviction-timeout
Pv Claim Binder Sync Period	Period for syncing persistent volumes and persistent volume claims	--pvclaimbinder-sync-period
Register Retry Count	Number of retries for initial node registration	--register-retry-count
Resource Quota Sync Period	Period for syncing quota usage status in the system	--resource-quota-sync-period
Log Level	Log level (default: 0)	--v
Log To StdErr*	Logging to stderr means getting it into the systemd journal (default: yes)	--logtostderr
Options	Additional parameters for the kube-controller-manager daemon	

\* Boolean (takes yes or no as a value)

**Table 8.11:** *KubernetesController role parameters and kube-controller-manager options*

Further details on the Kubernetes controller manager can be found at <https://kubernetes.io/docs/admin/kube-controller-manager/>.

### KubernetesScheduler Role

The KubernetesScheduler role is used to configure and manage the kube-scheduler daemon. The Kubernetes scheduler defines pod placement, taking into account the individual and collective resource requirements, quality of service requirements, hardware/software/policy constraints, affinity and anti-affinity specifications, data locality, inter-workload interference, deadlines, and so on.

The KubernetesScheduler role parameters are described in table 8.12:

Parameter	Description	Option to kube-scheduler
Kubernetes Cluster	The Kubernetes cluster instance (pointer)	

...continues

...continued

Parameter	Description	Option to kube-scheduler
Address	IP address to serve on (default: 0.0.0.0)	--address
Scheduler Port	Port to serve on (default: 10253)	--port
Algorithm Provider	The scheduling algorithm provider to use (default: DefaultProvider)	--algorithm-provider
Policy Config	File with scheduler policy configuration (default: /cm/local/apps/kubernetes/var/etc/scheduler-policy.json)	--policy-config-file
Log Level	Log level (default: 0)	--v
Log To StdErr*	Logging to stderr means getting it into the systemd journal (default: yes)	--logtostderr
Options	Additional parameters for the kube-scheduler daemon	

\* Boolean (takes yes or no as a value)

**Table 8.12:** *KubernetesScheduler role parameters and kube-scheduler options*

Further details on the Kubernetes scheduler can be found at <https://kubernetes.io/docs/admin/kube-scheduler/>.

### KubernetesProxy Role

The KubernetesProxy role is used to configure and manage kube-proxy daemon. The kube-proxy daemon runs on each node, and reflects services as defined in the Kubernetes API. It can do simple TCP and UDP stream-forwarding or round-robin TCP and UDP forwarding across a set of backends.

The KubernetesProxy role parameters are described in table 8.13:

Parameter	Description	Configuration Parameter Passed To kube-proxy
Kubernetes Cluster	The Kubernetes cluster instance (pointer)	
Address	IP address to serve on (default: 0.0.0.0)	--address
Proxy Port Range Start	Bottom of range of host ports that may be consumed in order to proxy service traffic (not set by default)	--proxy-port-range
Proxy Port Range End	Top of range of host ports that may be consumed in order to proxy service traffic (not set by default)	--proxy-port-range
Masquerade All	If using the pure iptables proxy, SNAT everything (default: yes)	--masquerade-all
Health Check Address	IP address for the health check server to serve on	--healthz-port
Health Check Port	Port to bind the health check server to serve on (default: 10251, use 0 to disable)	--healthz-port
Oom Score Adjust	The <code>oom_score_adj</code> value for the kube-proxy process, in range [-999, 999] (default: -999)	--oom-score-adj
Log Level	Log level (default: 0)	--v
Log To StdErr*	Logging to stderr means it goes in the systemd journal (default: yes)	--logtostderr
Options	Additional parameters for the kube-scheduler daemon	

\* Boolean (takes yes or no as a value)

**Table 8.13:** *KubernetesProxy* role parameters and kube-proxy options

Further details on the Kubernetes network proxy can be found at <https://kubernetes.io/docs/admin/kube-proxy/>.

### KubernetesNode Role

The `KubernetesNode` role is used to configure and manage the `kubelet` daemon, which is the primary node agent that runs on each node. The `kubelet` daemon takes a set of pod specifications, called *PodSpecs*, and ensures that the containers described in the `PodSpecs` are running and healthy.

The `KubernetesNode` role parameters are described in table 8.14:

Parameter	Description	Option to kubelet
Kubernetes Cluster	The Kubernetes cluster instance (pointer)	

...continues

*...continued*

Parameter	Description	Option to kubelet
Address	IP address to serve on (default: 0.0.0.0)	--address
Kubelet Port	Port that the HTTP service of the node runs on (default: 10250)	--port
Enable Server*	Enable server mode of Kubelet	--enable-server
Host Network Sources	List of sources from which Kubelet allows pods use of the host network (default: file)	--host-network-sources
Hostname Override	If non-empty, use this string as identification instead of the actual hostname (not set by default)	--hostname-override
Manifests Path	Path to the config file or directory of files (default: /cm/local/apps/kubernetes/var/etc/manifests)	--pod-manifest-path
Spool	Directory path for managing Kubelet files (default: /cm/local/apps/kubernetes/var/kubelet)	--root-dir
Cgroup Root	Optional root cgroup to use for pods	--cgroup-root
Docker Endpoint	Docker endpoint address to connect to (default: unix:///var/run/docker.sock)	--docker-endpoint
Docker Spool	Absolute path to the Docker state root directory (default: /var/lib/docker)	--docker-root
Resource Container	Absolute name of the resource-only container to create and run the Kubelet in (default: /kubelet)	--resource-container
Allowed Privileged*	If true, allow privileged containers (default: no)	--allow-privileged
Labels	List of node labels	
Register On Start*	Register the node with the API server (default: yes)	--register-node
Eviction minimum reclaim	Minimum amount of resources reclaimed in an eviction (default: imagefs.available=1Gi)	--eviction-minimum-reclaim
Hard eviction	Hard eviction constraints (default: imagefs.available<1%)	--eviction-hard
Max Pods	Number of pods that can run on this node	--max-pods
Max pod eviction grace period	Maximum allowed grace period (in seconds) allowed to terminated pods (default: 60)	--eviction-max-pod-grace-period

*...continues*

...continued

Parameter	Description	Option to kubelet
Soft eviction	Soft eviction constraints (default: imagefs.available<5%)	--eviction-soft
Soft eviction grace period	Soft eviction grace period (default: imagefs.available=1m30s)	--eviction-soft-grace-period
File Check Frequency	Duration between checking configuration files for new data (default: 20s)	--file-check-frequency
HTTP Flush Frequency	Duration between checking HTTP for new data (default: 20s)	--http-check-frequency
Node Status Update Frequency	The absolute free disk space, in MB, to maintain (default: 10s)	--node-status-update-\frequency
Run Once*	If true, exit after spawning pods from local manifests or remote URLs (default: no)	--runonce
Streaming Connection Idle Timeout	Maximum time a streaming connection can be idle before the connection is automatically closed (default: 1h)	--streaming-connection-\idle-timeout
Sync Frequency	Maximum period between synchronizing running containers and config (default: 10s)	--sync-frequency
Image GC High Threshold	Percent of disk usage after which image garbage collection is always run (default: 90)	--image-gc-high-\threshold
Image GC Low Threshold	Percent of disk usage before which image garbage collection is never run (default: 80)	--image-gc-low-\threshold
Low Disk Space Threshold	Absolute free disk space, in MB, to maintain (default: 256)	--low-diskspace-\threshold-mb
Oom Score Adjust	The oom_score_adj value for the kube-proxy process, in range [-999, 999] (default: -999)	--oom-score-adj
Log Level	Log level (default: 0)	--v
Log To StdErr*	Logging to stderr means it gets into the systemd journal (default: yes)	--logtostderr
Options	Additional parameters for the kube-scheduler daemon	

\* Boolean (takes yes or no as a value)

**Table 8.14:** *KubernetesNode role parameters and kubelet options*

Further details on the kubelet daemon can be found at <https://kubernetes.io/docs/admin/kubelet/>.



### KubernetesDNS Role

The KubernetesDNS role is used to configure and manage the `kube-dns` daemon, which is the DNS server for internal service discovery. The `kube-dns` daemon reads the IP addresses of services and pods from Etcd, and resolves domain names for them. If a domain name is not found because the domain is external to the Kubernetes cluster, then KubeDNS forwards the request to the main DNS server.

The KubernetesDNS role parameters are described in table 8.15:

Parameter	Description	Option to kube-dns
Kubernetes Cluster	The Kubernetes cluster instance (pointer)	
Bind Address	IP address to serve on (default: 0.0.0.0)	--dns-bind-address
Advertise Address	IP address for service discovery (default: 0.0.0.0)	
Port	Port that the DNS service runs on (default: 53)	--dns-port
Healthchecks Port	Port used for health checks (default: 18081)	--healthz-port
Options	Additional parameters for the kube-dns daemon	

**Table 8.15:** KubernetesDNS role parameters and kube-dns options

Further details on the `kube-dns` daemon can be found at <https://kubernetes.io/docs/admin/dns/>.

### KubernetesDashboard Role

The KubernetesDashboard role is used to configure and manage the `dashboard` daemon, which is the web user interface for GUI cluster administration and metrics visualization. The `dashboard` daemon connects to the API server and can be used both directly via the API server under `/ui`, e.g. `https://master:6443/ui`, or by `kubectl proxy`, e.g. `http://localhost:8081/ui`.

The KubernetesDashboard role parameters are described in table 8.16:

Parameter	Description	Option to dashboard
Kubernetes Cluster	The Kubernetes cluster instance (pointer)	
Port	Port that the HTTP service of the node runs on (default: 19090)	--port
Advertise Address	IP address for service discovery (default: 0.0.0.0)	
Options	Additional parameters for the dashboard daemon	

**Table 8.16:** KubernetesDashboard role parameters and dashboard options

Further details on the `dashboard` daemon can be found at <https://github.com/kubernetes/dashboard/>.

### KubernetesHeapster Role

The KubernetesHeapster role is used to configure and manage the `heapster` daemon, which is the Kubernetes add-on for container cluster monitoring and performance analysis. The `heapster` daemon collects and interprets metrics such as compute resource usage, lifecycle events, and so on. It exposes cluster metrics via an API, and enables the `HorizontalPodAutoscaler` feature.

With Horizontal Pod Autoscaling, Kubernetes automatically scales the number of pods in a replication controller, deployment or replica set, based on observed CPU usage. Besides basing on CPU usage, other application-provided metrics may also be used, but with alpha support only at the time of writing (May 2017).

The Horizontal Pod Autoscaler is implemented as a Kubernetes API resource and a controller. The resource determines the behavior of the controller. The controller periodically adjusts the number of replicas in a replication controller or deployment, in order to match the observed average CPU usage to a target specified by the user.

The KubernetesHeapster role parameters are described in table 8.17:

Parameter	Description	Option to <code>heapster</code>
<code>Kubernetes Cluster</code>	The Kubernetes cluster instance (pointer)	
<code>Port</code>	Port that the HTTP API service of the node runs on (default: 8082)	<code>--heapster-port</code>
<code>Advertise Address</code>	IP address for service discovery (default: 0.0.0.0)	
<code>Options</code>	Additional parameters for the <code>heapster</code> daemon	

**Table 8.17:** *KubernetesHeapster role parameters and heapster options*

Further details on the `heapster` daemon can be found at <https://github.com/kubernetes/heapster>.

### 8.3.5 Security Model

The Kubernetes security model allows authentication using a certificate authority (CA), with the user and daemon certificates signed by a Kubernetes CA<sup>1</sup>. The CA model is the model that Bright Cluster Manager configures by default for Kubernetes, so that certificate use is forced for any communication within Kubernetes. During Kubernetes setup, and also when the Bright Cluster Manager license is updated, a Kubernetes CA is generated and signed by the CMDaemon master node certificate. The certificates are put into `/cm/local/apps/kubernetes/var/etc/`, and `/etc/kubernetes/` is made a link to this directory.

In Kubernetes terminology a user is a unique identity accessing the Kubernetes API server, which may be a human or an automated process. For example an administrator or a pod developer are human users, but kubelet represents an infrastructure user. Both types of users are authorized and authenticated in the same way against the API server.

Kubernetes uses client certificates, tokens, or HTTP basic authentication methods to authenticate users for API calls. Bright Cluster Manager configures client certificate usage by default. The authentication is performed by the API server by validating the user certificate, where the common name of the subject is used as the user name for the request.

In Kubernetes, authorization happens as a separate step from authentication. Authorization applies to all HTTP accesses on the main (secure) API server port. The authorization check for any request

<sup>1</sup>The Kubernetes CA should not be confused with the Bright Cluster Manager CA. While it is conceivable to use the Bright Cluster Manager CA for this purpose, it makes more sense to use a separate CA for Kubernetes. This is because the Kubernetes public certificates are meant for regular users, unlike Bright Cluster Manager public certificates

compares attributes of the context of the request (such as user, resource, and namespace) with access policies. Any API call must be allowed by a policy in order to proceed. By default the policy file is `/cm/local/apps/kubernetes/var/etc/auth-policy.jsonl`, which represents policies in a special format (JSONL, json lines). The file is updated by CMDaemon automatically when user policies are changed.

The user policies definitions can be managed in a Kubernetes cluster using `cmsh` via the `userpolicies` submode:

### Example

```
[root@bright80 ~]# cmsh
[bright80]% kubernetes use default
[bright80->kubernetes[default]]% userpolicies
[bright80->kubernetes[default]->userpolicies]% list
Name (key)    Resources    Namespaces
-----
all
readonly
[bright80->kubernetes[default]->userpolicies]% show readonly
Parameter          Value
-----
Is Read Only        yes
Name                 readonly
Namespaces
Resources
Revision
[bright80->kubernetes[default]->userpolicies]%
```

The policies can also be managed using Bright View, via the clickpath Containers→Kubernetes Clusters→User Policies (figure 8.1):




Figure 8.1: Bright View: accessing Kubernetes user policies

By default only 2 user policies are defined:

- `all`: allows a user to have read/write access for all resources
- `readonly`: allows a user only read access for all resources

Parameter	Description	Policy file setting
Is Read Only	When true, means that the policy only applies to GET operations	readonly
Namespaces	Namespaces the policy is applied to	namespace
Resources	Resources from a URL, such as pods, that the policy is applied to	resource

**Table 8.18:** *userpolicy mode and policy file setting options*

The configuration parameter that is put in the policy file (policy file setting value), is associated with the parameter (key) described in table 8.3.5:

The policies are applied to particular users when Authentication Mode is set to ABAC (Attribute-Based Access Control) for a Kubernetes cluster instance. The Authentication mode can be set using `cmsh` or Bright View. The policy can be applied to a user via `cmsh` via the `user` mode, and adding one or several policies to the `Kubernetes Policies` string list.

### Example

```
[root@bright80 ~]# cmsh
[bright80]% user
[bright80->user]% add newuser
[bright80->user*[newuser*]]% set kubernetespolicies all
[bright80->user*[newuser*]]% commit
[bright80->user[newuser]]%
```

When the policy configuration file is updated by `CMDaemon`, `kube-apiserver` is restarted automatically in order to apply the new user policies. By default, the policy file allows the user `kube` to have read/write access, because this user is set as a common name in the Kubernetes daemon certificates, and allows the Kubernetes daemons to authenticate against the API server.

If the administrator applies the policies to a new user, then `CMDaemon` generates a new user certificate for that user and puts the certificate into the `$HOME/.cm/` directory. At the same time the `$HOME/.kubeconfig` file is generated based on the `KubeConfigTemplate` parameter in the Kubernetes cluster object. If the `$HOME/.kubeconfig` file already exists then `CMDaemon` does not change it.

### 8.3.6 Networking Model

Kubernetes expects all pods to have unique IP addresses, which are reachable from within the cluster. This can be implemented in several ways, including adding pod network interfaces to a network bridge created on each host, or by using 3rd party tools to manage pod virtual networks. Bright Cluster Manager 8.0 by default sets up Flannel, a network manager, for this purpose.

Flannel is a virtual network manager that assigns a subnet to each host for use with the container runtime. Bright Cluster Manager allows the IP address range of the pod networks to be configured. This IP address range is split by Flannel into subnetworks. Each subnetwork is assigned to one, and only one, host in the cluster at a time. Within the host subnetwork, one IP address for each pod within the host. All IP addresses that Flannel manages are reachable across the cluster.

- **Network:** IPv4 network in CIDR format used by the entire Flannel network. The CIDR is defined by a `network`, specified in `KubernetesController` as the `podnetwork` parameter. By default `cm-kubernetes-setup` creates the network with CIDR `172.29.0.0/16`.

- `SubnetLen`: This number sets the size of the subnetwork allocated to each host. By default it is 24.
- `Backend`: Type of backend to use, and configurations for that backend. By default Bright Cluster Manager 8.0 uses a UDP backend. The default port that is used for the backend is 7890.

With the default setup Flannel can create up to 256 subnetworks, and allocate 254 IP addresses in each of the subnetworks. This means that by default the cluster can run up to 65024 pods, each with a unique IP address. If the number of allocated IP addresses need to be modified, then the administrator can change the pod network mask using `cmsh` or Bright View, and can also change the `SubnetLen` value via the advanced configuration flag.

By default, pods get their IP addresses from Docker. When Flannel is used, the Docker daemon gets its parameters from the file `/run/flannel/docker` created by `flanneld`. The parameters specify how Docker should configure network interfaces for pods. One of the parameters is the IPv4 subnetwork, in CIDR format, that is allocated by Flannel for a particular host. Flannel guarantees that IP addresses allocated from that subnetwork will never conflict with the IP address allocated from the subnetworks defined for Docker running on other hosts.

The path that a TCP/IP packet takes between two pods running on different hosts is illustrated by figure 8.2.




Figure 8.2: Path of TCP/IP packet passed from a pod running on one host to a pod running on another host

An explanation of this figure follows:

- The process running inside a pod connects to a second pod running on different host. The packet goes from the process to the local network interface visible from inside the pod (usually `eth0`).
- The packet goes from the `eth0` interface of the first pod to the bridge created by Docker, because `eth0` has been added to it here. The bridge is usually called `docker0`
- The packet is transferred from the `docker0` bridge to the `flannel0` interface.
- The packet gets transferred from the `flannel0` interface to the `flanneld` daemon. The virtual network device `/dev/net/tun` is used by `flanneld` for this.
- `flanneld` sends the packet through the network using the IP address of the remote, second, pod. If the UDP backend of Flannel is used, then the packets are transferred between `flanneld` daemons using the UDP protocol.
- The packet is received by `flanneld` running on the remote host, and goes to the second pod in the reverse order that it followed when leaving the first pod. That is, it goes through the second host via the `flannel0` network interface and the `docker0` bridge network interface before reaching the second pod.

### 8.3.7 Kubernetes Monitoring

When `cm-kubernetes-setup` runs it configures the following Kubernetes-related healthchecks:

1. `KubernetesChildNode`: checks if all the expected agents and services are up and running for active nodes
2. `KubernetesComponentsStatus`: checks if all the daemons running on a node are healthy
3. `KubernetesNodesStatus`: checks if Kubernetes nodes have a status of `Ready`
4. `KubernetesPodsStatus`: checks if all the pods are in one of these states: `Running`, `Succeeded`, or `Pending`

### 8.3.8 Setup Of A Storage Class For Ceph

Pods running on Kubernetes can use Ceph as a distributed storage system to store data in a persistent way.

Instead of creating Kubernetes `PersistentVolumes` everytime, a modern and practical way is using the `StorageClass` feature.

Further documentation on `StorageClass` is available at:

- <http://blog.kubernetes.io/2016/10/dynamic-provisioning-and-storage-in-kubernetes.html>
- <https://kubernetes.io/docs/concepts/storage/persistent-volumes/#storageclasses>

This section assumes a working Ceph cluster. Ceph installation for Bright Cluster Manager is covered in Chapter 4 of the *OpenStack Deployment Manual*.

A new pool `kube` can be created with a replication factor of 3:

#### Example

```
[root@bright80 ~]# ceph osd pool create kube 100 100
pool 'kube' created
[root@bright80 ~]# ceph osd pool set kube size 3
set pool 1 size to 3
[root@bright80 ~]# ceph osd pool set kube min_size 1
set pool 1 min_size to 1
```

The parameters settings in the preceding example are documented at the Ceph website, at

- <http://docs.ceph.com/docs/master/rados/operations/pools/> for documentation on Ceph operations
- <http://docs.ceph.com/docs/master/rados/configuration/pool-pg-config-ref/> for documentation on Ceph pool and PG (placement group) configuration

The pods of a given namespace have to have access to the Ceph RBD images created to back the volumes.

A kube client can be created with:

#### Example

```
[root@bright80 ~]# ceph auth get-or-create client.kube mon 'allow r' osd 'allow rwx pool=kube'
[client.kube]
    key = AQCN0vdZpYewBBAWvld7c7/XbEvj7QO7N0THg==
```

A list of the current users, and their access control can be viewed with (some output elided):

### Example

```
[root@bright80 ~]# ceph auth list
installed auth entries:

osd.0
    key: AQC9M/dZw8HPNRAAT+X8mGSgRUkjLnQo38j4EA==
    caps: [mon] allow rwx
    caps: [osd] allow *
osd.1
...
client.admin
    key: AQCnM/dZONOPMxAAwqY9ADbJV+6i2Uq/ZNqh5A==
    auid: 0
    caps: [mds] allow *
    caps: [mgr] allow *
    caps: [mon] allow *
    caps: [osd] allow *
...
client.kube
    key: AQCnOvdZpYewBBAWvld7c7/XbEvj7QO7N0THg==
    caps: [mon] allow r
    caps: [osd] allow rwx pool=kube
```

The admin user must be able to create images in the pool. The admin configuration must therefore look like the section for `client.admin` in the preceding example.

Similarly, the kube user must be able to map images. The kube configuration must therefore look similar to `sectino` for `client.kube` in the preceding example.

A Kubernetes secret must be created in the `kube-system` namespace, using the Ceph admin key:

```
[root@bright80 ~]# kubectl create secret generic ceph-secret --type="kubernetes.io/rbd" \
--from-literal=key=$(ceph auth get-key client.admin) --namespace=kube-system
secret "ceph-secret" created
```

A Kubernetes secret must be created in the default namespace, and in every Kubernetes namespace that needs storage, using the Ceph user key:

```
[root@bright80 ~]# kubectl create secret generic ceph-secret-user --type="kubernetes.io/rbd" \
--from-literal=key=$(ceph auth get-key client.kube) --namespace=default
secret "ceph-secret-user" created
```

Ceph monitor `<IP address>:<port>` values can be found by running `ceph mon stat`:

### Example

```
[root@bright80 ~]# ceph mon stat
el: 3 mons at {node001=10.141.0.1:6789/0,node002=10.141.0.2:6789/0,node003=10.141.0.3:6789/0},\
election epoch 38, quorum 0,1,2 node001,node002,node003
```

A `storage-class.yml` file can then be created, similar to:

```
apiVersion: storage.k8s.io/v1
kind: StorageClass
metadata:
  name: fast
provisioner: kubernetes.io/rbd
parameters:
  monitors: 10.141.0.1:6789,10.141.0.2:6789,10.141.0.3:6789
```

```
adminId: admin
adminSecretName: ceph-secret
adminSecretNamespace: kube-system
pool: kube
userId: kube
userSecretName: ceph-secret-user
```

Details about the StorageClass parameters can be found at: <https://kubernetes.io/docs/concepts/storage/persistent-volumes/#ceph-rbd>

The Kubernetes storage class for Ceph RBD can now be created:

```
[root@bright80 ~]# kubectl apply -f storage-class.yml
storageclass "fast" created
```

To verify it has been created, the new StorageClass can be listed with:

```
[root@bright80 ~]# kubectl get sc
NAME          PROVISIONER
fast          kubernetes.io/rbd
```

## 8.4 Singularity

Bright Cluster Manager provides an application containerization tool called Singularity. Singularity is designed to execute containers as if they are just native applications on a host computer, and to work with HPC. Singularity users can therefore run Singularity containers just as they run any other program on an HPC cluster.

### 8.4.1 Use Cases

Adding Singularity to Bright Cluster Manager brings a stronger integration of containerization with HPC. While Docker and Kubernetes can work within HPC, some drawbacks still prevent the use of HPC resources in the way that HPC users and administrators are used to.

Besides the use of Singularity containers in HPC jobs, Singularity users can create portable images with their applications. Singularity images are files that represent the container filesystem. These images can be copied from one environment (cluster) to another and executed without modification. Thus, when a user creates a container image file, it is up to the user what files, or which RPMs, to install in the image. For example, the user can create an image file that bundles Open MPI with the user's application. This guarantees that the application will be able to run if it requires that MPI implementation, even if no MPI libraries are installed on the execution host or if there is some version incompatibility.

There is no need for a special configuration inside workload managers in order to use Singularity. This is because the containers are designed to be run like any application on the system. Users need just to use the image file as the usual script or binary to be executed in their jobscripts or in a shell. The `singularity` command can also be used to apply special options to the container, when executing the image file in the jobscript or shell.

### 8.4.2 Package `cm-singularity`

Singularity is packaged for SLES12 and RHEL7 and derivatives. It is available from the YUM or Zypper repositories from version 7.3 of Bright Cluster Manager onwards, and is distributed as a package called `cm-singularity`. The package should be installed in the software image for each node. The user is able to run a Singularity image only if the Singularity package is installed on the node. In order to allow users to build an image, it makes sense to install the package on the head and login nodes as well. The tool does not provide services that run in the background, so a simple installation of the package is enough to start using it.

Singularity contexts are always run as the user running them. This means that there is no risk in allowing the containers to have access to, and interact with, the file system of the host.



This means that, if an image is created by the root user on a machine, then the files that require root access inside the image, still need to be allowed root permissions on any other machine. Thus, if a user creates an image on a laptop, and adds a file that can be read only by the root user, then when the container is started on another machine by a regular user, that regular user has no access to the root-only readable file inside the container.

While there is no daemon running as root, nor any persistent processes that an attacker may use to escalate privileges, there is a need to run some system calls as root so that the container is encapsulated. For this part of the run flow, there is a single SUID binary called Sexec (Singularity Exec). This is a simple binary that is as small as possible, and which the Singularity developers claim has been audited by multiple security experts.

### 8.4.3 MPI Integration

Because of the nature of Singularity, all MPI implementations should work fine inside a Singularity container. The developers of the tool have spent a lot of effort in making Singularity aware of Open MPI, as well as adding a Singularity module into Open MPI so that running at extreme scale is as efficient as possible. However, in some cases, starting an MPI process may not be as optimal as execution outside the container. So, specifically for Open MPI, Singularity provides a special mechanism to handle the execution of MPI processes. It adds all the MPI processes of the same MPI application to the same container on a host. This also reduces the application startup time. The Open MPI daemon `orted` in this case is not added to the running container, which means the overhead of starting up daemons is reduced.

When an Open MPI application that has been packaged to an image is started, the following steps take place:

1. `mpirun` is called;
2. `mpirun` forks and executes `orted`;
3. `orted` initializes the PMI (process management interface);
4. `orted` forks as many times as the number of processes per node requested;
5. the container image is started in each fork (because it is the original command specified in `mpirun` arguments);
6. each container process executes the command (that is, the MPI application) passed inside the given container;
7. each of the MPI process links to the dynamic Open MPI library, which loads shared libraries with `dlopen` system call;
8. Open MPI libraries connect back to the original `orted` process via PMI;
9. all non-shared memory communication then occurs through the PMI, and then passes on to local network interfaces.

Additional information about Singularity usage can be found in chapter 11 of the *User Manual*. The official web site of the tool is <https://www.sylabs.io/singularity>.



# 9

## Mesos

### 9.1 Mesos Introduction

#### 9.1.1 Concepts

*Mesos* is a resource manager developed by the Apache Software Foundation as a project. Apache Mesos provides efficient resource isolation and sharing across distributed applications or frameworks.

A *Mesos cluster* consists of *master nodes* that manage *agent nodes*<sup>1</sup>, and *Mesos frameworks* that run *tasks* on the agent nodes.

Mesos sits between the application layer and the operating system, and makes it easier to deploy and manage tasks in large-scale clustered environments more efficiently. Mesos tasks can run on a dynamically shared pool of nodes, and can be run inside Docker containers.

*Marathon* is an orchestration framework for running tasks. Marathon is installed on Mesos agent nodes.

#### 9.1.2 Installation Notes

Bright Cluster Manager provides the administrator with the required packages and utilities to allow Mesos to be set up on a cluster. Bright Cluster Manager also manages and monitors Mesos.

Mesos installs with:

- Mesos-DNS, a DNS server for Mesos nodes and applications. Mesos-DNS is typically installed on the Bright Cluster Manager head node.
- Mesos Proxy, a server that proxies Mesos HTTP requests to the agent nodes via the Mesos master nodes. The Mesos Proxy itself is normally installed on Mesos master nodes.

The following are also supplied as options during Mesos deployment:

- Marathon, the Mesos orchestration framework for running tasks. Marathon is documented at <https://mesosphere.github.io/marathon/docs/>.
- ZooKeeper, a synchronizing configuration information service. Mesos needs this, and during the setup, either an existing ZooKeeper cluster can be used, or a new ZooKeeper cluster can be created. If a new ZooKeeper cluster is created, then it uses the same nodes as the Mesos masters.

Mesos is documented online at: <https://mesos.apache.org/documentation/latest/>.

An odd number of master nodes must be used. Running with one master is possible, but in that case there is no high availability (HA).

---

<sup>1</sup>As the Apache Mesos documentation at <http://mesos.apache.org/documentation/latest/architecture/>, says: "(...keyword 'slave' is deprecated in favor of 'agent', driver-based frameworks will still receive offers with slave ID, whereas frameworks using the v1 HTTP API receive offers with agent ID)." [text retrieved 2017-22-05]

The tasks are run on Mesos agent nodes, so the administrator should ensure that there are enough of these, and that they are powerful enough to suit the requirements.

After the installation process is completed, links to the Mesos and Marathon web interfaces become available via Bright View. Bright View is a GUI front end that runs from any modern web browser, and connects to a special webservice served from the cluster, typically at a URL of the form:

```
https://<head node address>:8081/bright-view/
```

### 9.1.3 Installation Options

Mesos can be installed with the following options:

- Docker
- Mesos Proxy
- Marathon framework
- Mesos-DNS

### 9.1.4 Mesos Installation Packages

Bright Cluster Manager has the following Mesos-related packages:

1. `cm-mesos`
2. `cm-zookeeper`
3. `cm-marathon`
4. `cm-mesos-dns`

The packages `cm-mesos`, `cm-zookeeper`, `cm-marathon` and `cm-mesos-dns` are always installed on the headnode, and also on agent nodes which were selected.

Mesos can be installed via the `cm-mesos-setup` command-line installer or via the Bright View wizard (section 9.2).

Multiple Mesos clusters can be installed and managed with Bright Cluster Manager.

## 9.2 Using The `cm-mesos-setup` Utility To Deploy, Uninstall, And Scale Mesos

The Ncurses-based `cm-mesos-setup` utility is a part of the `cluster-tools` package that comes with Bright Cluster Manager. When carrying out a deployment, if the Mesos packages are not installed, then the utility installs them.

The `cm-mesos-setup` utility is run as root from the head node, and allows the administrator to carry out the following tasks:

- Mesos deployment (section 9.2.1)
- Mesos uninstallation (section 9.2.2)
- Mesos masters scaling (section 9.2.3)

The options can be selected from the main menu that is first displayed when the utility runs (figure 9.1):




Figure 9.1: Mesos Script Main Menu

### 9.2.1 Deployment Of Mesos

Choosing the `Deploy` option starts the deployment wizard (sections 9.2.1- 9.2.1).

#### Configuration Overlays

Names are requested for the Mesos configuration overlays (figure 9.2):




Figure 9.2: Configuration Overlays Creation

The configuration overlays are

- the Mesos master configuration overlay
- the Mesos agent configuration overlay

#### Mesos Master Nodes Selection

Nodes are then selected for the Mesos masters (figure 9.3):




Figure 9.3: Mesos Master Nodes Selection

An odd number of nodes must be selected. If just one node is selected, then there is no high availability in the Mesos cluster.

All Mesos master nodes must be accessible from outside the Bright cluster in order to access the web management interfaces.

The Mesos Proxy (section 9.2.1), Mesos web interface (section 9.2.1), and Marathon web interface (section 9.2.1) ports are all opened on the head node automatically. If a firewall other than the Bright-managed Shorewall is used, then the ports must be opened manually.

### Mesos Agent Nodes Selection

Nodes are then selected for the Mesos agents (figure 9.4):




Figure 9.4: Mesos Agent Nodes Selection

For convenience, using Mesos Proxy (section 9.2.1) is strongly recommended.

If Mesos Proxy is not deployed, then the administrator must make sure that all Mesos agent nodes are accessible from outside the Bright cluster, in order to access the Mesos web management interface.

### Mesos Cluster Configuration

Some Mesos cluster configuration parameters are then asked for (figure 9.5):




Figure 9.5: Mesos Cluster Configuration

The parameters are:

- The name of the Mesos cluster
- The HTTP(S) port for the Mesos web interface
- IP that the Mesos web server will listen on

If the Mesos Proxy (section 9.2.1) is deployed, then the Mesos web interface should be accessed from outside the cluster via its IP address.

#### Mesos Cluster Internal Network

An internal network should then be selected for the Mesos cluster (figure 9.6):




Figure 9.6: Mesos Cluster Internal Network

The Mesos cluster internal network is used for internal communications within the Mesos cluster.

#### ZooKeeper Cluster Deployment

If a ZooKeeper cluster already exists, then either the existing one can be used, or a new one can be created (figure 9.7):




Figure 9.7: ZooKeeper Cluster Type Selection

### ZooKeeper Cluster Selection

If using an existing ZooKeeper cluster, it should be selected (figure 9.8):




Figure 9.8: ZooKeeper Cluster Selection

### ZooKeeper Cluster Configuration

If, instead, a new ZooKeeper cluster is created, or if there is no existing ZooKeeper cluster, then a new ZooKeeper cluster should be configured (figure 9.9):



Figure 9.9: ZooKeeper Cluster Configuration

The parameters that need values are:

- The name of the ZooKeeper cluster
- The port for client connections
- The port for non-leaders connections to the leader
- The port for leader elections



### Marathon Deployment

The Marathon framework can then be selected for deployment (figure 9.10):




Figure 9.10: Marathon Deployment

Marathon is used to orchestrate long-living apps and other Mesos frameworks.

### Marathon Configuration

If Marathon has been selected for deployment, then it needs to be configured (figure 9.11):




Figure 9.11: Marathon Configuration

The parameters that need values are:

- The HTTPS port for the Marathon web interface
- The IP address that the Marathon web server listens on

If the Mesos Proxy (section 9.2.1) is deployed, then the Mesos web interface should be accessed from outside the cluster via its IP address.

### Mesos-DNS Deployment

Mesos-DNS can then be selected for deployment: (figure 9.12):




Figure 9.12: Mesos-DNS Deployment

Mesos-DNS is a DNS server for the Mesos cluster entities: nodes, frameworks, and tasks. It is integrated with the Bright Cluster Manager DNS server, which runs on the Bright head node.

### Mesos-DNS Node Selection




Figure 9.13: Mesos-DNS Node Selection

If Mesos-DNS has been selected for deployment, then a node must be selected for it (figure 9.13):

### Mesos Proxy Deployment

The Mesos Proxy can then be selected for deployment (figure 9.14):




Figure 9.14: Mesos Proxy Deployment

Using Mesos Proxy proxies the Mesos agent nodes from the network, by proxying all HTTP requests. However, the Mesos master nodes still face the network directly.

### Mesos Proxy Configuration

If Mesos Proxy has been selected for deployment, then it must be configured (figure 9.15):




Figure 9.15: Mesos Proxy Configuration

The parameters that need values are:

- The external domain for the Mesos cluster. This is used to access Mesos master nodes. All master nodes must be within that domain.
- The HTTPS port for the Mesos Proxy.
- The IP address that the Mesos Proxy listens on.

For example, for:

an external domain: `<external-domain>`

any master: `<any-mesos-master>`

and the Mesos Proxy port: `<mesos-proxy-port>`

- The Mesos web interface is accessed via the URL:  
`https://<any-mesos-master>.<external-domain>:<mesos-proxy-port>`
- The Marathon web interface is accessed via the URL:  
`https://<any-mesos-master>.<external-domain>:<mesos-proxy-port>/marathon`

### Docker Deployment

Docker can then be selected for deployment (figure 9.16):




Figure 9.16: Docker Deployment

If Docker is deployed, then Mesos tasks are run within Docker containers.

### Deployment Summary

The summary screen of the wizard allows the planned deployment configuration to be displayed, saved, deployed, or simply exited from (figure 9.17):



Figure 9.17: Deployment Summary

### Command Line Installation

If a configuration file, `cm-mesos-setup.conf`, has been saved, then it can be used to install a Mesos cluster automatically as follows:

```
cm-mesos-setup -c cm-mesos-setup.conf
```

### 9.2.2 Uninstallation Of Mesos

If the `Uninstall` option of the main menu (page 338) is chosen, a process to uninstall a Mesos cluster is started.

#### Uninstall Cluster Selection

After the administrator reconfirms that a Mesos cluster is to be removed, the wizard asks for a particular instance to be selected for removal (figure 9.18):




Figure 9.18: Uninstall Cluster Selection

The uninstallation process is then executed.

### 9.2.3 Masters Scaling

With the `Scale` option in the main menu (page 338), the number of master nodes in the Mesos cluster can be scaled up and down.

#### Scale Cluster Selection

A Mesos cluster is first selected for scaling (figure 9.19):




Figure 9.19: Scale Cluster Selection

#### Scale Master Nodes Selection

New master nodes must then be selected for the Mesos cluster (figure 9.20):




Figure 9.20: Scale Master Nodes Selection

The scaling process is then executed.

## 9.3 Using Bright View To Install And Manage Mesos

The Bright View GUI (section 2.4) provides browser-based methods to deploy Mesos, and to manage Mesos settings for an already-deployed Mesos cluster.

### 9.3.1 Mesos Installation Wizard Using Bright View

Deployment can be carried out with the Mesos Wizard. The clickpath for this wizard in Bright View is `Containers→Mesos→Mesos Wizard`. This opens up a wizard overview window (figure 9.21):




Figure 9.21: Mesos Installation Wizard With Bright View

To carry out the deployment, the fields in the GUI screens of the Bright View wizard can be followed. The options that are made available are very close to the set of options in the Ncurses wizard of section 9.2.1.

### 9.3.2 Mesos Settings Management With Bright View

Once a Mesos instance has been deployed, the clickpath `Containers→Mesos→Mesos cluster→<Mesos instance>→Overview` opens up a Mesos cluster overview screen for the Mesos instance (figure 9.22):

**Mesos Clusters**

NAME	OPTIONS
<input type="checkbox"/> default	<input type="button" value="Edit"/> ▼

**Mesos cluster object default**

Overview >

Settings >

**OVERVIEW**

Mesos UI ⓘ  
<https://dt-wrk.bright:10443/mesos/>

Marathon UI ⓘ  
<https://dt-wrk.bright:10443/service/marathon/>

**NODES CONFIGURED FOR MESOS**

TYPE	NAME	ROLE
Configura...	mesos-m...	marathon
Physical n...	node001	Mesos::D...
Configura...	mesos-m...	Mesos::M...
Configura...	mesos-m...	Mesos::Pr...
Configura...	mesos-sl...	Mesos::Sl...

Revert Add Delete Save Back Revert Delete Save

Figure 9.22: Mesos Cluster Overview With Bright View

The screen provides a general overview of the Mesos instance, and also provides web URLs that link to the Mesos-provided web interfaces for Mesos and Marathon.

For the same instance, the clickpath Containers→Mesos→Mesos cluster→<Mesos instance>→Settings opens up the Mesos cluster instance settings screen (figure 9.23):

Mesos Clusters		Mesos cluster object default	
NAME	OPTIONS	Overview	Settings
<input type="checkbox"/> default	<button>Edit</button>		<p>Name <small>?</small></p> <input type="text" value="default"/> <p>ZooKeeper Cluster <small>?</small></p> <input type="text" value="zookeeper-mesos"/> <p>Internal network <small>?</small></p> <input type="text" value="internalnet"/> <p>External domain <small>?</small></p> <input type="text" value="External domain"/> <p>Enable SSL <small>?</small></p> <div> <span>Enabled</span> <span>Disabled</span> </div> <p>Notes <small>?</small></p> <input type="text" value="Notes"/>

Revert Add Delete Save
Back
Revert Delete Save

Figure 9.23: Mesos Cluster Settings With Bright View

Some detailed settings for the Mesos instance can be viewed and managed from this screen.

## 9.4 Network Configuration

If Mesos Proxy has been installed, then the administrator must make sure that all Mesos master nodes are exposed to the network. Otherwise, all Mesos agents must also be exposed to the network.

If Mesos DNS has been installed, then the administrator needs to add the Bright Cluster Manager head node to the list of resolvers.

## 9.5 Mesos Objects

### 9.5.1 Mesos Cluster

The Mesos cluster object managed by Bright Cluster Manager contains some general Mesos cluster configuration parameters.

One way the settings can be changed is from within Bright View, via the clickpath:

Containers→Mesos→Mesos cluster (figure 9.23):

An alternative way to change the settings is from `mesos` mode in `cmsh`:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% mesos list
Name (key)
-----
default
[bright80]% mesos use default
[bright80->mesos[default]]% show
Parameter                                     Value
-----
```



```

Base type           MesosCluster
Lookup              default
Modified            no
Removed             no
UID                 171798691847
Revision
Name                default
ZooKeeper Cluster  zookeeper-mesos
Internal network    globalnet
External domain     brightcomputing.com
Enable SSL          yes
Notes
[bright80->mesos[default]]%

```

The parameters of `mesos` mode are described in table 9.1:

Parameter	Description
Name	Name of the Mesos cluster
ZooKeeper Cluster	ZooKeeper cluster instance (pointer)
Internal network	Network used by Mesos services
External domain	Domain name used to reach the cluster members from the external network
Enable SSL*	Use SSL connections among cluster members
Notes	Some notes to the cluster

\* Boolean (takes `yes` or `no` as a value)

**Table 9.1:** `mesos` mode parameters

### 9.5.2 MesosMaster Role

The MesosMaster role is used for configuring Mesos master services. The MesosMaster role parameters are described in table 9.2:

Parameter	Description	Option to <code>mesos-master</code>
Mesos Cluster	Mesos cluster instance (pointer)	<code>--cluster</code>
Bind IP	IP address to serve on	<code>--ip</code>

...continues

...continued

Parameter	Description	Option to <code>mesos-master</code>
Bind port	Port number to bind	<code>--port</code>
Hostname	Hostname to advertise to other peers	<code>--hostname</code>
Advertise IP	IP address advertised to reach this instance	<code>--advertise_ip</code>
Advertise port	Port number advertised to reach this instance	<code>--advertise_port</code>
Work directory	Path to data directory	<code>--work_dir</code>
Log directory	Path to log directory	<code>--log_dir</code>
CA file	Path to root certificate authority file	<code>LIBPROCESS_SSL_CA_FILE</code>
SSL Certificate file	Path to SSL certificate file	<code>LIBPROCESS_SSL_CERT_FILE</code>
SSL Key file	Path to SSL key file	<code>LIBPROCESS_SSL_KEY_FILE</code>
Options	Additional parameters for the <code>mesos-master</code> daemon	

**Table 9.2:** *MesosMaster* role parameters and `mesos-master` daemon options

The `mesos-master` settings are updated by Bright Cluster Manager in `/cm/local/apps/mesos/var/etc/mesos-master`.

### 9.5.3 MesosSlave Role

The `MesosSlave` role is used for configuring Mesos slave services. The `MesosSlave` role parameters are described in table 9.3:

Parameter	Description	Option to <code>mesos-slave</code>
Mesos Cluster	Mesos cluster instance (pointer)	
Bind address	IP address to serve on	<code>--ip</code>
Port	Port number to bind	<code>--port</code>
Advertise IP	IP address advertised to reach this instance	<code>--advertise_ip</code>

...continues

...continued

Parameter	Description	Option to <code>mesos-slave</code>
Advertise bind port	Port number advertised to reach this instance	<code>--advertise_port</code>
Hostname	Hostname to advertise	<code>--hostname</code>
Containerizers	Allowed containerizers for task isolation	<code>--containerizers</code>
Image Providers	Container images providers	<code>--image_providers</code>
Isolation	Isolation providers for containers	<code>--isolation</code>
Allowed CPUs	Number of allowed CPUs per agent	<code>--resources</code>
Allowed GPUs	Number of allowed GPUs per agent	<code>--resources</code>
Allowed memory	Amount of allowed memory per agent	<code>--resources</code>
Allowed disk	Amount of allowed disk space per agent	<code>--resources</code>
Resources	Total consumable resources per agent	<code>--resources</code>
Executor Registration Timeout	Timeout before considering an executor to be hung at startup	<code>--executor_registration_timeout</code>
Work directory	Path to the data directory	<code>--work_dir</code>
Log directory	Path to log directory	<code>--log_dir</code>
CA file	Path to the root certificate authority file	<code>LIBPROCESS_SSL_CA_FILE</code>
SSL Certificate file	Path to SSL certificate file	<code>LIBPROCESS_SSL_CERT_FILE</code>
SSL Key file	Path to SSL key file	<code>LIBPROCESS_SSL_KEY_FILE</code>
Attributes	Key value pairs for user-defined resources	<code>--attributes</code>
Options	Additional parameters for <code>mesos-slave daemon</code>	

**Table 9.3:** *MesosSlave role parameters and `mesos-slave daemon` options*

The `mesos-slave` settings are updated by Bright Cluster Manager in `/cm/local/apps/mesos/var/etc/mesos-slave`.

### 9.5.4 Marathon Role

The Marathon role is used to configure Marathon services. The Marathon role parameters are described in table 9.4:

Parameter	Description	Option to marathon
Mesos Cluster	Mesos cluster instance (pointer)	
HTTP port	Port number to bind for the web service	--http_port
HTTP Address	IP address to bind for the web service	--http_address
HTTPS port	Port number to bind for the secure web service	--https_port
HTTPS Address	IP address to bind for the secure web service	--https_address
Hostname	Hostname to advertise to Mesos	--hostname
Task launch timeout	Timeout in ms before considering a task to be hung at startup	--task_launch_timeout
Mesos CA file	Path to SSL root certificate authority file	LIBPROCESS_SSL_CA_FILE
Mesos Certificate file	Path to Mesos SSL certificate file	LIBPROCESS_SSL_CERT_FILE
Mesos SSL Key file	Path to Mesos SSL key file	LIBPROCESS_SSL_KEY_FILE
SSL Certificate bundle file	Path to SSL certificate bundle file	--ssl_keystore_path
Options	Additional parameters for marathon daemon	
Debug*	Enable debug mode	--logging_level

\* Boolean (takes yes or no as a value)

**Table 9.4:** Marathon role parameters and marathon daemon options

Marathon settings are updated by Bright Cluster Manager in /cm/local/apps/marathon/var/etc/marathon.

### 9.5.5 MesosDNS Role

The MesosDNS role is used to configure Mesos DNS services. Its role parameters are described in table 9.5:

Parameter	Description
Mesos Cluster	The Mesos cluster instance (pointer)
Refresh time	Period in seconds over which DNS records are updated
Bind port	Port number to bind
Options	Additional parameters for the <code>mesos-dns</code> daemon

**Table 9.5:** *MesosDNS role parameters*

The MesosDNS role settings are updated by Bright Cluster Manager in `/cm/local/apps/mesos-dns/var/etc/mesos-dns`.

### 9.5.6 MesosProxy Role

The MesosProxy role is used for configuring a proxy for Mesos HTTP requests. Its role parameters are described in table 9.6:

Parameter	Description
Mesos Cluster	The Mesos cluster instance (pointer)
Bind IP	IP address to serve on
Bind http port	HTTP port to bind
Bind https port	HTTPS port to bind
Enable SSL*	Use SSL certificates
Mesos master URL	URL of Mesos master to proxy
Marathon URL	URL of Marathon service to proxy
Proxy CA file	Path to root certificate authority file for the proxy
SSL Certificate file	Path to SSL certificate file for the proxy
SSL Key file	Path to SSL key file for the proxy

\* Boolean (takes `yes` or `no` as a value)

**Table 9.6:** *MesosDNS role parameters*

The MesosProxy settings are updated by Bright Cluster Manager in `/cm/local/apps/mesos/var/etc/mesos-proxy`.

## 9.6 Using Mesos

### 9.6.1 Accessing The Non-Bright Mesos And Marathon Web Interfaces

After Mesos has been installed and set up for the network, the native Mesos and Marathon web GUIs can be accessed.

#### Mesos And Marathon GUI Interfaces Via Proxy

If Mesos Proxy has been set up on a Master node, *<any-master-node>*, and is assigned a proxy port, *<proxy-port>*, then the interfaces are available at:

```
https://<any-master-node>:<proxy-port>/mesos
```

and

```
https://<any-master-node>:<proxy-port>/marathon
```

#### Mesos And Marathon GUI Interfaces Directly

If Mesos Proxy has not been set up, then the GUI interfaces are available as follows:

Via the Mesos port, *<mesos-port>*, as defined by the port option in the MesosMaster role parameters of Table 9.2:

```
http(s)://<any-master-node>:<mesos-port>
```

and via the Marathon port, *<mesos-port>*, as defined by the port option in the Marathon role parameters of Table 9.4:

```
http(s)://<any-master-node>:<marathon-port>
```

#### Mesos And Marathon GUI Interfaces Lookup

The links for these can also be found in Bright View, in the window accessed via the clickpath:

Containers→Mesos→Mesos cluster→Edit→Overview (figure 9.22):

### 9.6.2 Spawning And Checking On A Test Application

#### Spawning A Test Application With Marathon

A test application can be spawned by going to the Marathon Web interface main page and clicking on the `Create Application` button. In the window that opens up (figure 9.24), the value of `ID` can be set to `test`, and `Command` can be set to:

```
while [ true ]; do echo test; sleep 10; done
```

Figure 9.24: Marathon Application Creation

After clicking the `Create Application` button, the application is spawned (figure 9.25):

Name	CPU	Memory	Status	Running Instances	Health
test	1.0	128 MiB	Running	1 of 1	

Figure 9.25: Marathon Applications

### Checking On A Test Application With Mesos

If `Sandbox` in the `Active Tasks` table of the main page of the Mesos GUI is clicked (figure 9.26), then the `stdout` and `stderr` of the application can be checked in real time (figure 9.27).

**Cluster:** default  
**Leader:** node001.cm.cluster:5050  
**Version:** 1.2.0  
**Built:** a month ago by root  
**Started:** 3 days ago  
**Elected:** 11 minutes ago

**LOG**

**Agents**

State	Count
Activated	3
Deactivated	0
Unreachable	0

**Tasks**

State	Count
Staging	0
Starting	0
Running	0
Unreachable	0
Killing	0
Finished	0
Killed	0
Failed	0
Lost	0
Orphan	0

**Resources**

Resource	Available	Used
CPU	100%	0%
GPU	0	0
Mem	100%	0%
Disk	100%	0%

**Active Tasks**

Framework ID	Task ID	Task Name	State	Started	Host
51369ea6-8728-430a-8b51-52fa7bbc9e54-0000	test.4a772135-33c3-11e7-b0cc-fa163ea5a381	test	RUNNING	6 minutes ago	node003.cm.cluster

**Unreachable Tasks**

Framework ID	Task ID	Task Name	Started	Agent ID
No unreachable tasks.				

**Completed Tasks**

Framework ID	Task ID	Task Name	State	Started	Stopped	Host
51369ea6-8728-430a-8b51-52fa7bbc9e54-0000	test.1320deb4-33c3-11e7-b0cc-fa163ea5a381	test	KILLED	7 minutes ago	7 minutes ago	node003.cm.cluster
51369ea6-8728-430a-8b51-52fa7bbc9e54-0000	test.47d1eb82-334c-11e7-b0da-fa163e9e948d	test	KILLED	14 hours ago	8 minutes ago	node005.cm.cluster

**Orphan Tasks**

Framework ID	Task ID	Task Name	State	Started	Stopped	Host
No orphan tasks.						

Figure 9.26: Mesos Web UI

**Master / Agent / Browse**

`/ var / lib / mesos-slave / slaves / 51369ea6-8728-430a-8b51-52fa7bbc9e54-52 / frameworks / 51369ea6-8728-430a-8b51-52fa7bbc9e54-0000 / executors / test.4a772135-33c3-11e7-b0cc-fa163ea5a381 / runs / 3894ad7c-3041-4e13-964f-3f347be3eef6`

mode	nlink	uid	gid	size	mtime	Download
-rw-r--r--	1	root	root	168 B	May 08 09:52	<a href="#">stderr</a> Download
-rw-r--r--	1	root	root	5 KB	May 08 09:58	<a href="#">stdout</a> Download

Figure 9.27: Mesos Web UI Sandbox



```

Overwriting environment variable 'HOST', original: 'node003.cm.clu
Overwriting environment variable 'MARATHON_APP_RESOURCE_CPUS', ori
Overwriting environment variable 'MARATHON_APP_RESOURCE_GPU', ori
Overwriting environment variable 'PORT_10000', original: '24458',
Overwriting environment variable 'MESOS_TASK_ID', original: 'test.
Overwriting environment variable 'PORT', original: '24458', new: '
Overwriting environment variable 'MARATHON_APP_RESOURCE_MEM', orig
Overwriting environment variable 'PORTS', original: '24458', new:
Overwriting environment variable 'MARATHON_APP_RESOURCE_DISK', ori
Overwriting environment variable 'MARATHON_APP_LABELS', original:
Overwriting environment variable 'MARATHON_APP_ID', original: '/te
Overwriting environment variable 'PORT0', original: '24458', new:
Overwriting environment variable 'PORT_DEFAULT', original: '24458'
test
test
test
test
test
test
test
test
test
test
test
test
test

```

Figure 9.28: Mesos Application Stdout

## 9.7 Scaling

The number of both master and agent Mesos nodes can be scaled. To scale the number of agent nodes, nodes can simply be added or removed to the Mesos slave configuration overlay. The name of the overlay can be configured during the setup process.

To scale the number of master nodes, the `cm-mesos-setup` utility should be used. The number of Mesos master nodes must be odd (section 9.2.1).



# 10

## BeeGFS

### 10.1 BeeGFS Introduction

#### 10.1.1 BeeGFS Concepts

BeeGFS is a high-performance parallel file system, developed by the Fraunhofer Competence Center for High Performance Computing, and optimized for intensive I/O. It uses a distributed metadata architecture designed for scalability and flexibility. More information about BeeGFS can be found at the official online documentation at <https://www.beegfs.io/content/documentation/>.

Bright Cluster Manager provides packages to allow BeeGFS to be deployed, managed, and monitored on a Bright cluster. The deployment tool provided by Bright Cluster Manager is `cm-beegfs-setup` (section 10.2).

A BeeGFS cluster consists of a management server, one or more metadata servers and one or more storage servers. Clients should have client servers running on them.

If high-availability is required, then the administrator needs to arrange for it separately.

Since BeeGFS is a parallel filesystem, it means that adding more nodes increases not only the storage capacity, but also system performance. BeeGFS can work with any local file system for data storage as long as it is POSIX compliant.

Versions of BeeGFS before 7.2 have an optional graphical user interface called Admon (section 10.3.4), which is integrated with Bright Cluster Manager. This has been dropped in version 7.2. The BeeGFS Mon monitoring service is on the roadmap for future Bright Cluster Manager integration.

#### 10.1.2 BeeGFS Installation Notes And Options

By default all logging is done to the systemd journal. The installation logs can be viewed using:

```
journalctl -u 'beegfs-*'.
```

If Admon is used, then it cannot use journalled logs by default. Logging into a file is needed instead.

Log locations can be changed using `cmsh` or Bright View at any moment after installation, by editing BeeGFS roles for the corresponding configuration overlays (section 10.2.1). After the changes are made, the Admon service must be manually restarted on the Admon node (section 10.2.1):

#### Example

```
systemctl restart beegfs-admon.service
```

Authentication is possible for the BeeGFS cluster via a shared secret file.

BeeGFS can be installed with these options:

- Admon (for versions of BeeGFS before 7.2)
- Shared secret file

## 10.2 Deployment And Uninstallation Of BeeGFS With `cm-beegfs-setup`

Deployment and uninstallation for a Bright Cluster Manager can be carried out with the Ncurses-based `cm-beegfs-setup` utility. The utility is a part of a `cluster-tools` package that comes with Bright Cluster Manager. If the BeeGFS packages are not installed, then the utility installs them.

The `cm-beegfs-setup` utility can be run as root from the head node. The first Ncurses screen that shows up is the main menu for operations (figure 10.1)




Figure 10.1: BeeGFS Script Main Menu

In the main menu, the administrator can choose to:

- Deploy BeeGFS (section 10.2.1)
- Uninstall BeeGFS (section 10.2.2)
- Simply exit the Ncurses session

### 10.2.1 Deployment Of BeeGFS

If the `Deploy` option is chosen, then the deployment wizard starts.

#### Configuration Overlays

The wizard firsts asks for names for the configuration overlays (figure 10.2):




Figure 10.2: Configuration Overlays Creation

These overlay names are for :

- the BeeGFS metadata configuration overlay

- the BeeGFS storage configuration overlay
- the BeeGFS client configuration overlay

### Select Management Node

The next screen (figure 10.3) then asks for a node to be selected to be the BeeGFS management server:




Figure 10.3: Management Node

### Select Metadata Nodes

The next screen (figure 10.4) then asks for nodes to be selected to be the BeeGFS metadata servers:




Figure 10.4: Select Metadata Nodes

### Select Storage Nodes

The next screen (figure 10.5) asks for nodes to be selected to be the BeeGFS storage servers:




Figure 10.5: Select Storage Nodes

### Select Client Nodes

The next screen (figure 10.6) asks for nodes to be selected to be the client nodes:




Figure 10.6: Select Client Nodes

### Admon Deployment

The next screen (figure 10.7) asks if the Admon GUI for BeeGFS is to be deployed:




Figure 10.7: Admon Deployment

### Select Admon Node

If Admon installation is chosen, then the wizard asks (figure 10.8) for a node to be selected for Admon use:




Figure 10.8: Select Admon Node

### Management Server Configuration

The next screen (figure 10.9) asks for some configuration parameters for the BeeGFS management server to be set:




Figure 10.9: Management Server Configuration

The values required are for the:

- Path to a data directory
- Management server TCP port
- Management server UDP port

### Metadata Server Configuration

The next screen (figure 10.10) asks for input on configuring the BeeGFS metadata servers:




Figure 10.10: Metadata Server Configuration

The values required are for the:

- Path to a data directory
- Metadata server TCP port
- Metadata server UDP port

### Storage Server Configuration

The next screen (figure 10.11) asks for input on setting some configuration parameters for the BeeGFS storage servers:




Figure 10.11: Storage Server Configuration

The items required are for the:

- Path to a data directory
- Storage server TCP port
- Storage server UDP port

### Client Configuration

The next screen (figure 10.12) asks for input on configuring the BeeGFS clients:






Figure 10.12: Client Configuration

The inputs required are for the:

- Client UDP port
- Helper TCP port

### Admon Configuration

If Admon has been chosen for installation, then the wizard asks (figure 10.13) for some configuration settings for Admon:




Figure 10.13: Admon Configuration

The input values required are:

- Path to the database file
- Admon HTTP port
- Admon UDP port

After installation is complete, the Admon jar file can be downloaded (section 10.3.4).

### Authentication Configuration

In the next screen, (figure 10.14) a path must be specified for the shared secret file:




Figure 10.14: Authentication Configuration

This is a file with arbitrary content. If it is set, then it must exist on all BeeGFS nodes.

### Deployment Summary

Finally, the wizard displays a deployment summary (figure 10.15):



Figure 10.15: Deployment Summary

From this screen the deployment process can be started, the deployment configuration can be viewed and saved, or the wizard can simply be exited.

### Command Line Installation

If a configuration file is saved from a `cm-beegfs-setup` run, then it can be used to install a BeeGFS cluster automatically:

#### Example

```
cm-beegfs-setup -c cm-beegfs-setup.conf
```

### 10.2.2 Uninstalling BeeGFS

If the `Uninstall` option is chosen from the main menu (figure 10.1), then the uninstallation process starts.

An extra `Are you sure?` prompt is thrown in the way first, to help avoid a mistaken removal. After confirmation, a BeeGFS instance must then be selected for the removal, by selecting its management node (figure 10.16):

#### Uninstall Management Node Selection




Figure 10.16: Uninstall Management Node Selection

The uninstallation process then starts. It can take several minutes in order to ensure that services are stopped properly, so that errors and junk files are avoided.

## 10.3 Managing The Deployed BeeGFS Instance

A BeeGFS cluster consists of:

- One Management node
- Some Metadata nodes
- Some Storage nodes

Information about the right number of nodes to use can be found at [https://www.beegfs.io/docs/whitepapers/Picking\\_the\\_right\\_Number\\_of\\_Targets\\_per\\_Server\\_for\\_BeeGFS\\_by\\_ThinkParQ.pdf](https://www.beegfs.io/docs/whitepapers/Picking_the_right_Number_of_Targets_per_Server_for_BeeGFS_by_ThinkParQ.pdf)

BeeGFS clients should have client servers running on them.

### 10.3.1 Setup

Associated with BeeGFS are the following BeeGFS-related packages, most of which provide services:

1. `beegfs-mgmd`
2. `beegfs-meta`
3. `beegfs-storage`
4. `beegfs-client`
5. `beegfs-helperd`
6. `beegfs-utils`
7. `beegfs-admon`

The repository from which these packages are picked up is added to the repositories list when BeeGFS is installed by Bright Cluster Manager (section 10.2), and the packages are then installed on all of the cluster nodes. The services are assignable by the cluster administrator to cluster devices as roles (BeeGFS objects, section 10.3.2), and the configuration of these roles is determined by role parameters (object attributes).

### 10.3.2 BeeGFS Objects

#### BeeGFSManagement Role

The BeeGFSManagement role is used to configure BeeGFS management services. The role parameters are described in table 10.1:

Parameter	Description	Option to beegfs-mgmt
Data directory	Path to data directory	storeMgmtDirectory
Allow new servers	Allow new servers registration	sysAllowNewServers
Allow new storage targets	Allow new storage targets registration	sysAllowNewTargets
Authentication file	Path to shared secret authentication file	connAuthFile
Backlog TCP	TCP listen backlog size	connBacklogTCP
Interfaces file	Path to file with interfaces list	connInterfacesFile
Management port TCP	TCP port for management service	connMgmtPortTCP
Management port UDP	UDP port for management service	connMgmtPortUDP
Net filter file	Path to file with list of allowed IP subnets	connNetFilterFile
Log level	Log level	logLevel
No log date	Do not show date along with time in log	logNoDate
Number of log lines	Number of lines in log file, after which it will be rotated	logNumLines

...continues

*...continued*

Parameter	Description	Option to beegfs-mgmt d
Number of log rotated files	Number of old log files to keep	logNumRotatedFiles
Log file	Path to log file, empty means logs go to the journal	logStdFile
Enable Quota	Enable quota	quotaEnableEnforcement
Quota query GID file	Path to file with GIDs to be checked by quota	quotaQueryGIDFile
Quota query GID range	GID range to be checked by quota	quotaQueryGIDRange
Quota query UID file	Path to file with UIDs to be checked by quota	quotaQueryUIDFile
Quota query UID range	UID range to be checked by quota	quotaQueryUIDRange
Quota query type	Query type for quota	quotaQueryType
Quota query with system users groups	Allow also system users/groups to be checked by quota	quotaQueryWithSystemUsersGroups
Quota update interval	Quota update interval	quotaUpdateIntervalMin
Target offline timeout	Timeout for targets on storage server to be considered offline when no target status received	sysTargetOfflineTimeoutSecs
Client auto remove time	Time after which an unreachable node is considered dead	tuneClientAutoRemoveMins
Number of workers	Number of worker threads	tuneNumWorkers
Meta dynamic pools	Raise lower limits if difference in capacity becomes too large between targets	tuneMetaDynamicPools

*...continues*

...continued

Parameter	Description	Option to beegfs-mgmt.d
Meta inodes low limit	Metadata inode free space pool threshold	tuneMetaInodesLowLimit
Meta inodes emergency limit	Metadata inode free space pool threshold	tuneMetaInodesEmergencyLimit
Meta space low limit	Metadata space free space pool threshold	tuneMetaSpaceLowLimit
Meta space emergency limit	Metadata space free space pool threshold	tuneMetaSpaceEmergencyLimit
Storage dynamic pools	Raise lower limits if difference in capacity becomes too large between targets	tuneStorageDynamicPools
Storage inodes low limit	Storage inode free space pool threshold	tuneStorageInodesLowLimit
Storage inodes emergency limit	Storage inode free space pool threshold	tuneStorageInodesEmergencyLimit
Storage space low limit	Storage space free space pool threshold	tuneStorageSpaceLowLimit
Storage space emergency limit	Storage space free space pool threshold	tuneStorageSpaceEmergencyLimit

**Table 10.1:** BeeGFSManagement role parameters and beegfs-mgmt.d options

The beegfs-mgmt.d settings are updated by Bright Cluster Manager in /etc/beegfs/beegfs-mgmt.d.conf.

### BeeGFSMetadata Role

The BeeGFSMetadata role is used for configuring BeeGFS metadata services. The role parameters are described in Table 10.2:

Parameter	Description	Option to beegfs-meta
-----------	-------------	-----------------------

...continues

*...continued*

Parameter	Description	Option to beegfs-meta
Data directory	Path to the data directory	storeMetaDirectory
Management node	Node with a management role	sysMgmtHost
Authentication file	Path to the shared secret authentication file	connAuthFile
Backlog TCP	TCP listen backlog	connBacklogTCP
Fallback expiration	Time after which a connection to a fallback interface expires	connFallbackExpirationSecs
Interfaces file	Path to the file with a list of interfaces for communication	connInterfacesFile
Max internode number	Max number of simultaneous connections to the same node	connMaxInternodeNum
Meta port TCP	TCP port for metadata service	connMetaPortTCP
Meta port UDP	UDP port for metadata service	connMetaPortUDP
Net filter file	Path to a file with a list of allowed IP subnets	connNetFilterFile
Use RDMA	Use RDMA	connUseRDMA
RDMA type of service	RDMA type of service	connRDMATypeOfService
Tcp only filter file	Path to a file with a list of no DRMA IP ranges	connTcpOnlyFilterFile
Log level	Log level	logLevel
No log date	Do not show date along with time in log	logNoDate
Number of log lines	Number of lines in log file, after which	logNumLines

*...continues*

...continued

Parameter	Description	Option to beegfs-meta
	it will be rotated	
Number of log rotated files	Number of old log files to keep	logNumRotatedFiles
Log file	Path to the log file, empty means logs go to the journal	logStdFile
Client xattrs	Enable client-side extended attributes	storeClientXAttrs
Client ACLs	Enable handling and storage of client-side ACLs client-side ACLs	storeClientACLs
Use extended attributes	Store metadata as extended attributes or not	storeUseExtendedAttribs
Target attachment file	File with a list of targets to be grouped within the same domain for randominternode	sysTargetAttachmentFile
Target offline timeout	Timeout for targets on a storage server to be considered offline when no target status is received	sysTargetOfflineTimeoutSecs
Allow user set pattern	Allow non-privileged users to modify stripe pattern settings for directories they own	sysAllowUserSetPattern
Bind to numa zone	Zero-based NUMA zone number to which all threads of metadata process should be bound	tuneBindToNumaZone
Number of stream listeners	The number of threads waiting for incoming data events	tuneNumStreamListeners
Number of workers	Number of worker threads	tuneNumWorkers
Target chooser	The algorithm to choose storage targets for file creation	tuneTargetChooser

...continues



*...continued*

Parameter	Description	Option to beegfs-meta
Use aggressive stream poll	Actively poll for events instead of sleeping until an event occurs	tuneUseAggressiveStreamPoll
Use per user msg queues	Use per-user queues for pending requests	tuneUsePerUserMsgQueues

**Table 10.2:** BeeGFSMetadata role parameters and beegfs-meta options

The beegfs-meta settings are updated by Bright Cluster Manager in `/etc/beegfs/beegfs-meta.conf`.

### BeeGFSStorage Role

The BeeGFSStorage role is used for configuring BeeGFS storage services. The role parameters are described in Table 10.3:

Parameter	Description	Option to beegfs-storage
Data directories	Path to the data directories	storeStorageDirectory
Management node	Node with a management role	sysMgmtHost
Authentication file	Path to the shared secret authentication file	connAuthFile
Backlog TCP	TCP listen backlog	connBacklogTCP
Interfaces file	Path to the file with a list of interfaces for communication	connInterfacesFile
Max internode number	Max number of simultaneous connections to the same node	connMaxInternodeNum
Storage port TCP	TCP port for storage service	connStoragePortTCP
Storage port UDP	UDP port for storage service	connStoragePortUDP
Net filter file	Path to a file with a list of allowed IP subnets	connNetFilterFile

*...continues*

...continued

Parameter	Description	Option to beegfs-storage
Use RDMA	Use RDMA	connUseRDMA
RDMA type of service	RDMA type of service	connRDMATypeOfService
Tcp only filter file	Path to a file with a list of subnets with no RDMA	connTcpOnlyFilterFile
Log level	Log level	logLevel
No log date	Do not show date along with time in log	logNoDate
Number of log lines	Number of lines in log file, after which it will be rotated	logNumLines
Number of log rotated files	Number of old log files to keep	logNumRotatedFiles
Log file	Path to the log file, empty means logs go to the journal	logStdFile
Resync safety threshold	Add an extra amount of time to the last successful communication timestamp in case of a potential cache loss	sysResyncSafetyThresholdMins
Target offline timeout	Timeout until targets on a storage server are considered offline when no target status is received	sysTargetOfflineTimeoutSecs
Bind to numa zone	Zero-based NUMA zone number to which all threads of metadata process should be bound	tuneBindToNumaZone
File read ahead size	Byte range submitted to the kernel for read-ahead after number of bytes was already read from target	tuneFileReadAheadSize
File read ahead trigger size	Number of bytes read after which the read-ahead is triggered	tuneFileReadAheadTriggerSize
File read size	Maximum amount of data server	tuneFileReadSize

...continues

...continued

Parameter	Description	Option to beegfs-storage
	should read in a single operation	
File write size	Maximum amount of data server should write in a single operation	tuneFileWriteSize
File write sync size	Number of bytes after which kernel advised to commit data	tuneFileWriteSyncSize
Number of resync gather slaves	Number of threads to gather filesystem information for a buddy mirror resync	tuneNumResyncGatherSlaves
Number of resync slaves	Number of threads to sync filesystem information for a buddy mirror resync	tuneNumResyncSlaves
Number of stream listeners	Number of threads waiting for incoming data events	tuneNumStreamListeners
Number of workers	Number of worker threads	tuneNumWorkers
Use aggressive stream poll	Actively poll for events instead of sleeping until an event occur	tuneUseAggressiveStreamPoll
Use per target workers	Create a separate set of workers and attach it for each storage target	tuneUsePerTargetWorkers
Use per user msg queues	Use per-user queues for pending requests	tuneUsePerUserMsgQueues
Worker buffer size	Size of network and io buffers, allocated for each worker	tuneWorkerBufSize

**Table 10.3:** BeeGFSStorage role parameters and beegfs-storage options

The beegfs-storage settings are updated by Bright Cluster Manager in /etc/beegfs/beegfs-storage.conf.

### BeeGFSAdmon Role

The BeeGFSAdmon role is used for configuring BeeGFS admon services. The role parameters are described in Table 10.4:

Parameter	Description	Option to beegfs-admon
Database file	Path to the database	databaseFile
Management node	Node with a management role	sysMgmtHost
Clear database	Delete database on startup	clearDatabase
Query interval	Interval for querying servers for new statistics data	queryInterval
Authentication file	Path to the shared secret authentication file	connAuthFile
Fallback expiration	Time after which a connection to a fallback interface expires	connFallbackExpirationSecs
Interfaces file	Path to the file with a list of interfaces for communication	connInterfacesFile
Max internode number	Max number of simultaneous connections to the same node	connMaxInternodeNum
HTTP port	TCP port for built-in web server	httpPort
Admon port UDP	UDP port for admon service	connAdmonPortUDP
Net filter file	Path to a file with a list of allowed IP subnets	connNetFilterFile
Tcp only filter file	Path to a file with a list of no RDMA IP ranges	connTcpOnlyFilterFile
Log level	Log level	logLevel
No log date	Do not show date along with time in log	logNoDate
Number of log lines	Number of lines in log file, after which it will be rotated	logNumLines

...continues

...continued

Parameter	Description	Option to beegfs-admon
Number of log rotated files	Number of old log files to keep	logNumRotatedFiles
Log file	Path to the log file, empty means logs go to the journal	logStdFile
Enable mail	Enable email notification	mailEnabled
Smtplib send type	How to send the email to an SMTP server	mailSmtplibSendType
Sendmail path	Path to the sendmail binary	mailSendmailPath
Check interval time	Interval for checking for new events that must be mailed	mailCheckIntervalTimeSec
Minimal down time	Interval of node downtime after which it should be reported	mailMinDownTimeSec
Mail recipients	Email addresses to send notifications to	mailRecipient
Resend mail time	Time after which to send email again as a reminder	mailResendMailTimeMin
Mail sender	Email notification from address	mailSender
SMTP server	SMTP server to use for sending emails	mailSmtplibServer
Number of workers	Number of worker threads	tuneNumWorkers

**Table 10.4:** BeeGFSAdmon role parameters and beegfs-admon options

The beegfs-admon settings are updated by Bright Cluster Manager in `/etc/beegfs/beegfs-admon.conf`.

### BeeGFSClient Role

The BeeGFSClient role is used for configuring BeeGFS client and helperd services. The role parameters are described in the table 10.5 and the table 10.6:

Parameter	Description	Option to beegfs-client
Management node	Node with a management role	sysMgmtdHost
Authentication file	Path to the shared secret authentication file	connAuthFile
Client port UDP	UDP port for client service	connClientPortUDP
Helper port TCP	TCP port for helper service	connHelperdPortTCP
Communication retry time	Time for retries in case of a network failure	connCommRetrySecs
Fallback expiration time	Time after which a connection to a fallback interface expires	connFallbackExpirationSecs
Interfaces file	Path to file with list of communication interfaces	connInterfacesFile
Max internode number	Maximum simultaneous connections to the same node	connMaxInternodeNum
Net filter file	Path to a file with a list of allowed IP subnets	connNetFilterFile
Use RDMA	Use RDMA	connUseRDMA
RDMA buffers number	Number of RDMA buffers	connRDMABufNum
RDMA buffer size	Maximum size of a buffer that will be sent over the network	connRDMABufSize
RDMA type of service	RDMA type of service	connRDMATypeOfService
Tcp only filter file	Path to a file with a list of no RDMA IP ranges	connTcpOnlyFilterFile
Log level	Log level	logLevel

...continues

*...continued*

Parameter	Description	Option to beegfs-client
Enable Quota	Enable quota	quotaEnabled
Create hardlinks as symlinks	Create a symlink when an application tries to create a hardlink	sysCreateHardlinksAsSymlinks
Mount sanity check ms	Time in ms that server has to respond after mount sanity check	sysMountSanityCheckMS
Session check on close	Check for valid sessions on storage server when a file is closed	sysSessionCheckOnClose
Sync on close	Sync file content on close	sysSyncOnClose
Target offline timeout	Timeout until all storage targets are considered offline when no target state updates can be fetched from management server	sysTargetOfflineTimeoutSecs
Update target states time	Interval for storage targets states check	sysUpdateTargetStatesSecs
Enable xattrs	Enable xattrs	sysXAttrsEnabled
Enable ACLs	Enable ACLs	sysACLsEnabled
File cache type	File read/write cache type	tuneFileCacheType
Preferred meta file	Path to a file with preferred metadata servers	tunePreferredMetaFile
Preferred storage file	Path to a file with preferred storage targets	tunePreferredStorageFile
Remote fsync	Should fsync be executed on server to flush cached file	tuneRemoteFSync
Use global append locks	Should files, opened in append mode, be protected by locks on local machine (false) or on servers (true)	tuneUseGlobalAppendLocks

*...continues*

...continued

Parameter	Description	Option to beegfs-client
Use global file locks	Should advisory locks be checked on local machine (false) or on servers (true)	tuneUseGlobalFileLocks

**Table 10.5:** BeeGFSClient role parameters and beegfs-client options

The beegfs-client settings are updated by Bright Cluster Manager in `/etc/beegfs/beegfs-client.conf`.

Parameter	Description	Option to beegfs-client
Authentication file	Path to the shared secret authentication file	connAuthFile
Helper port TCP	TCP port for helper service	connHelperdPortTCP
No log date	Do not show date along with time in log	logNoDate
Number of log lines	Number of lines in log file, after which it is rotated	logNumLines
Number of log rotated files	Number of old log files to keep	logNumRotatedFiles
Log file	Path to the log file, empty means logs go to the journal	logStdFile
Helper workers number	Number of worker threads for helper service	tuneNumWorkers

**Table 10.6:** BeeGFSClient role parameters and beegfs-helperd options

The beegfs-helperd settings are updated by Bright Cluster Manager within `/etc/beegfs/beegfs-helperd.conf`.

### 10.3.3 Usage

#### Accessing The Filesystem


After the installation process finishes, the BeeGFS filesystem can be accessed on the client nodes or on the head node. The default mount point is `/mnt/beegfs`, which can be changed within `/etc/beegfs/beegfs-mounts.conf`.

### 10.3.4 Admon Interface

After Admon is installed, then the Admon GUI jar file can be downloaded from the Admon node `<admon-node>`, via the Admon port `<admon-http-port>`, using a URL of the form (figure 10.17):

```
http://<admon-node>:<admon-http-port>
```





[Download BeeGFS Admon GUI \(java .jar\)](#)

Figure 10.17: BeeGFS Admon client download

When the administrator runs the client, configuration options are requested (figure 10.18). The host-name of the Admon node should be specified:

A screenshot of a configuration dialog box titled 'Please provide some information on how to connect to the BeeGFS administration and monitoring daemon.' It contains four input fields: 'Hostname where the daemon runs' with '10.2.61.102', 'HTTP-Port the daemon uses' with '8000', 'Internal desktop resolution' with '2048x2048', and 'Log level' with a dropdown menu set to '3'. At the bottom are 'Save' and 'Abort' buttons.

Figure 10.18: BeeGFS Admon client configuration

Authentication is then requested by Admon (figure 10.19):

A screenshot of a login dialog box. It has a 'Username' dropdown menu with 'Administrator' selected, a 'Password' text input field, and a 'Login' button. Below the button is the BeeGFS logo, which consists of a stylized bee icon and the text 'BeeGFS'.

Figure 10.19: BeeGFS Admon client login

There are two users by default:

- `Information`, with the default password `information`. This user can only view BeeGFS statistics.
- `Administrator`, with the default password `admin`. This user can carry out BeeGFS administration.

It is highly recommended to change the default passwords after the first login.

After a successful login, the Admon interface becomes available for use (figure 10.20):




Figure 10.20: BeeGFS Admon client login

More information about Admon is at <http://www.beegfs.com/wiki/AdmonLogin>.

# 11

## Post-Installation Software Management

Some time after Bright Cluster Manager has been installed, administrators may wish to manage other software on the cluster. This means carrying out software management actions such as installation, removal, updating, version checking, and so on.

Since Bright Cluster Manager is built on top of an existing Linux distribution, it is best that the administrator use distribution-specific package utilities for software management.

Packages managed by the distribution are hosted by distribution repositories. SUSE and RHEL distributions require the purchase of their license in order to access their repositories. The other distributions do not.

Packages managed by Bright Cluster Manager are hosted by the Bright Computing repository. Access to the Bright Computing repositories also requires a license (Chapter 4 of the *Installation Manual*). Available packages for a particular Bright Cluster Manager version and distribution can be viewed via the *package dashboard* at <https://support.brightcomputing.com/packages-dashboard/>.

There may also be software that the administrator would like to install that is outside the default packages collection. These could be source files that need compilation, or packages in other repositories.

A software image (section 2.1.2) is the filesystem that a node picks up from a provisioner (a head node or a provisioning node) during provisioning. A subtopic of software management on a cluster is software image management—the management of software on a software image. By default, a node uses the same distribution as the head node for its base image along with necessary minimal, cluster-mandated changes. A node may however deviate from the default, and be customized by having software added to it in several ways.

This chapter covers the techniques of software management for the cluster.

Section 11.1 describes the naming convention for a Bright Cluster Manager RPM package.

Section 11.2 describes how an RPM package is managed for the head node.

Section 11.3 describes how a kernel RPM package can be managed on a head node or image.

Section 11.4 describes how an RPM package can be managed on the software image.

Section 11.5 describes how a software other than an RPM package can be managed on a software image.

Section 11.6 describes how custom software images are created that are completely independent of the existing software image distribution and version.

### 11.1 Bright Cluster Manager Packages And Their Naming Convention

Like the distributions it runs on top of, Bright Cluster Manager uses either .rpm packages, managed by RPM (RPM Package Manager), or .deb (Debian) packages, managed by APT (Advanced Package Tool). For example, the `cmdaemon` package built by Bright Cluster Manager has the following .rpm and .deb packages:

```
cmdaemon-8.0-127661_cm8.0_8eabf447b8.x86_64.rpm
cmdaemon_8.0-127661-cm8.0-f315823e4a_amd64.deb
```

The file name has the following structure:

*package-version-revision\_cm.x.y\_hash.architecture.rpm*

and

*package\_version-revision-cm.x.y-hash\_architecture.deb*

where:

- *package* (cmdaemon) is the name of the package
- *version* (8.0) is the version number of the package
- *revision* (127661) is the revision number of the package
- *cm* is used to indicate it is a package built by Bright Computing for the cluster manager
- *x.y* (8.0) is the version of Bright Cluster Manager for which the RPM was built
- *hash* (8eabf447b8 or f315823e4a) is a hash, and is only present for Bright Cluster Manager packages. It is used for reference by the developers of Bright Cluster Manager.
- *architecture* (x86\_64 for RPMs or amd64 for APT) is the architecture for which the package was built. The architecture name of x86\_64 or amd64 refers the same 64-bit x86 physical hardware in either case.

The differences in .rpm versus .deb package names are just some underbar/hyphen (\_/-) changes, the hash (only for Bright Cluster Manager packages), and the architecture naming convention.

Among the distributions supported by Bright Cluster Manager, only Ubuntu uses .deb packages. The rest of the distributions use .rpm packages.

### Querying The Packages

To check whether Bright Computing or the distribution has provided a file that is already installed on the system, the package it has come from can be found.

**For RPM-based systems:** `rpm -qf` can be used with the full path of the file:

#### Example

```
[root@bright80 ~]# rpm -qf /usr/bin/zless
gzip-1.5.-8.el7.x86_64
[root@bright80 ~]# rpm -qf /cm/local/apps/cmd/sbin/cmd
cmdaemon-8.0-127642_cm8.0d2f835c895.x86_64
```

In the example, `/usr/bin/zless` is supplied by the distribution, while `/cm/local/apps/cmd/sbin/cmd` is supplied by Bright Computing, as indicated by the “\_cm” in the nomenclature.

**For APT-based systems:** A similar check can be done using `dpkg -S` to find the .deb package that provided the file, and then `dpkg -s` on the package name to reveal further information:

#### Example

```
[root@bright80:~# dpkg -S /cm/local/apps/cmd/etc/cmd.env
cmdaemon: /cm/local/apps/cmd/etc/cmd.env
[root@bright80:~# dpkg -s cmdaemon
Package: cmdaemon
Status: install ok installed
Priority: optional
Section: devel
Installed-Size: 123130
Maintainer: Cluster Manager Development <dev@brightcomputing.com>
Architecture: amd64
Version: 8.0-127523-cm8.0-8eabf447b8
Provides: cmdaemon
...
```

As an aside, system administrators should be aware that the Bright Computing version of a package is provided and used instead of a distribution-provided version for various technical reasons. The most important one is that it is tested and supported by Bright Cluster Manager. Replacing the Bright Computing version with a distribution-provided version can result in subtle and hard-to-trace problems in the cluster, and Bright Computing cannot offer support for a cluster that is in such a state, although some guidance may be given in special cases.

More information about the RPM Package Manager is available at <http://www.rpm.org>, while APT is documented for Ubuntu at <http://manpages.ubuntu.com/manpages/>.

## 11.2 Managing Packages On The Head Node

### 11.2.1 Managing RPM Or .deb Packages On The Head Node

Once Bright Cluster Manager has been installed, distribution packages and Bright Cluster Manager software packages are conveniently managed using the `yum`, `zypper` or `apt-get` repository and package managers. The `zypper` tool is recommended for use with the SUSE distribution, the `apt-get` utility is recommended for use with Ubuntu, and `yum` is recommended for use with the other distributions that Bright Cluster Manager supports. YUM is not set up by default in SUSE, and it is better not to install and use it with SUSE unless the administrator is familiar with configuring YUM.

#### Listing Packages On The Head Node With YUM and Zypper

For YUM and `zypper`, the following commands list all available packages:

```
yum list
or
zypper refresh; zypper packages
```

For `zypper`, the short command option `pa` can also be used instead of `packages`.

#### Listing Packages On The Head Node With APT

For Ubuntu, the `apt-cache` command is used to view available packages. To generate the cache used by the command, the command:

```
apt-cache gencaches
```

can be run.

A verbose list of available packages can then be seen by running:

```
apt-cache dumpavail
```

It is usually more useful to use the `search` option to search for the package with a regex:

```
apt-cache search <regex>
```

### Updating/Installing Packages On The Head Node

To install a new package called `<package name>` into a distribution, the corresponding package managers are used as follows:

```
yum install <package name>
zypper in <package name>          #for SLES
apt-get install <package name>    #for Ubuntu
```

Installed packages can be updated by the corresponding package manager as follows:

```
yum update
zypper refresh; zypper up          #refresh recommended to update package metadata
apt-get update; apt-get upgrade    #update recommended to update package metadata
```

**An aside on the differences between the `update`, `refresh/up`, and `update/upgrade` options of the package managers:** The `update` option in YUM by default installs any new packages. On the other hand, the `refresh` option in zypper, and the `update` option in APT only update the meta-data (the repository indices). Only if the meta-data is up-to-date will an `update` via zypper, or an `upgrade` via `apt-get` install any newly-known packages. For convenience, in the Bright Cluster Manager manuals, the term `update` is used in the YUM sense in general—that is, to mean including the installation of new packages—unless otherwise stated.

Bright Computing maintains YUM and zypper repositories of its packages at:

```
http://updates.brightcomputing.com/yum
```

and updates are fetched by YUM and zypper for Bright Cluster Manager packages from there by default, to overwrite older package versions by default.

For Ubuntu, the Bright Computing `.deb` package repositories are at:

```
http://updates.brightcomputing.com/deb
```

Accessing the repositories manually (i.e. not using `yum`, `zypper`, or `apt-get`) requires a username and password. Authentication credentials are provided upon request. For more information on this, `support@brightcomputing.com` should be contacted.

### Cleaning Package Caches On The Head Node

The repository managers use caches to speed up their operations. Occasionally these caches may need flushing to clean up the index files associated with the repository. This can be done by the appropriate package manager with:

```
yum clean all
zypper clean -a    #for SUSE
apt-get clean      #for Ubuntu
```

### Signed Package Verification

As an extra protection to prevent Bright Cluster Manager installations from receiving malicious updates, all Bright Cluster Manager packages are signed with the Bright Computing GPG public key (0x5D849C16), installed by default in `/etc/pki/rpm-gpg/RPM-GPG-KEY-cm` for Red Hat, Scientific Linux, and CentOS packages. The Bright Computing public key is also listed in Appendix B.

The first time YUM or zypper are used to install updates, the user is asked whether the Bright Computing public key should be imported into the local repository packages database. Before answering with a “Y”, yum users may choose to compare the contents of `/etc/pki/rpm-gpg/RPM-GPG-KEY-cm` with the key listed in Appendix B to verify its integrity. Alternatively, the key may be imported into the local RPM database directly, using the following command:

```
rpm --import /etc/pki/rpm-gpg/RPM-GPG-KEY-cm
```

With APT the Bright Cluster Manager keyring is already imported into `/etc/apt/trusted.gpg.d/brightcomputing-archive-cm.gpg` if the `cm-config-apt` package, provided by the Bright Computing repository, has been installed. The `cm-config-apt` package is installed by default for the Ubuntu edition of Bright Cluster Manager.

### Third Party Packages

Installation of the following third party packages, most of which are repackaged by Bright Computing for installation purposes, is described in Chapter 7 of the *Installation Manual*. These are installed mostly on the head node, but some packages work as a server and client process, with the clients installed and running on the regular nodes:

Most of the third party packages in the following list are repackaged by Bright Computing for installation purposes. These are installed mostly on the head node, but some packages work as a server and client process, with the clients installed and running on the regular nodes. The packages are described in Chapter 7 of the *Installation Manual*:

- Modules (section 7.1)
- Shorewall (section 7.2)
- Compilers (section 7.3):
  - GCC (section 7.3.1)
  - Intel Compiler Suite (section 7.3.2)
  - PGI High-Performance Compilers (section 7.3.3)
  - AMD Open64 Compiler Suite (section 7.3.4)
  - FLEXlm License Daemon (section 7.3.5)
- Intel Cluster Checker (section 7.4)
- CUDA (section 7.5)
- Lustre (section 7.8)

Exclusion of packages on the head node can be carried out as explained in section 11.3.2, where the kernel package is used as an example for exclusion.

### Gnome And KDM Installation—Disabling `network-manager`

`NetworkManager` interferes with the custom network management of Bright Cluster Manager and should thus never be enabled.

When installing the cluster from bare metal using the Bright Cluster Manager installer, if the X11 graphical user installation option checkbox is ticked, then `NetworkManager` is disabled by using a `finalize` script, so that Bright Cluster Manager’s networking is able to work properly.

However, some time after the cluster is configured, the administrator may wish to install the Gnome or KDE graphical desktop environment. This can be done in YUM or APT. For example in RHEL the installation can be carried out with:

```
yum groupinstall "GNOME Desktop"
```

The Network Manager package is a dependency of the Gnome and KDE desktops, and is therefore automatically installed by the package manager command. As a result, the `NetworkManager` service is enabled, and the distribution defaults are to have it run. However, because this interferes with the custom network management of Bright Cluster Manager, the `NetworkManager` should be disabled.

Disabling Network Manager can be done as follows:

- On RHEL 6 and derivatives:

#### Example

```
[root@bright80 ~]# service NetworkManager status
NetworkManager (pid 1527) is running...
[root@bright80 ~]# chkconfig NetworkManager off
[root@bright80 ~]# service NetworkManager stop
```

- On RHEL 7 and derivatives, and Ubuntu:

#### Example

```
[root@bright80 ~]# systemctl status NetworkManager.service
[root@bright80 ~]# systemctl disable NetworkManager.service
```

- On SLES-based systems:

#### Example

YAST can be used to disable `NetworkManager` by going to `Network Devices` → `Network Settings` → `Global Options` → `Network Setup Method`, and setting the option: `Traditional Method with ifup`.

### 11.2.2 Installation Of Packages On The Head Node That Are Not .deb And Not .rpm Packages

Sometimes a package is not packaged as an RPM or .deb package by Bright Computing or by the distribution. In that case, the software can usually be treated as for installation onto a standard distribution. There may be special considerations on placement of components that the administrator may feel appropriate due to the particulars of a cluster configuration.

For example, for compilation and installation of the software, some consideration may be made of the options available on where to install parts of the software within the default shared filesystem. A software may have a compile option, say `--prefix`, that places an application `<application>` in a directory specified by the administrator. If the administrator decides that `<application>` should be placed in the shared directory, so that everyone can access it, the option could then be specified as: `"--prefix=/cm/shared/apps/<application>"`.

Other commonly provided components of software for the applications that are placed in shared may be documentation, licenses, and examples. These may similarly be placed in the directories `/cm/shared/docs`, `/cm/shared/licenses`, and `/cm/shared/examples`. The placement may be done with a compiler option, or, if that is not done or not possible, it could be done by modifying the placement by hand later. It is not obligatory to do the change of placement, but it helps with cluster administration to stay consistent as packages are added.

Module files (section 2.2 of this manual, and 7.1 of the *Installation Manual*) may sometimes be provided by the software, or created by the administrator to make the application work for users easily with the right components. The directory `/cm/shared/modulefiles` is recommended for module files to do with such software.

To summarize the above considerations on where to place software components, the directories under `/cm/shared` that can be used for these components are:



```
/cm/shared/  
|-- apps  
|-- docs  
|-- examples  
|-- licenses  
`-- modulefiles
```

## 11.3 Kernel Management On A Head Node Or Image

Care should be taken when updating a head node or software image. This is particularly true when custom kernel modules compiled against a particular kernel version are being used.

### 11.3.1 Installing A Standard Distribution Kernel Into An Image

A standard distribution kernel is treated almost like any other package in a distribution. This means that for head nodes, installing a standard kernel is done according to the normal procedures of managing a package on a head node (section 11.2), while for regular nodes, installing a standard distribution kernel onto a regular node is done according to the normal procedures of managing an package inside an image, via a changed root (chroot) directory (section 11.4), but with some special aspects that are discussed in this section.

#### Kernel Package Name Formats

For RHEL, individual kernel package names take a form such as:

```
kernel-3.10.0-327.3.1.el7.x86_64.rpm
```

The actual one suited to a cluster varies according to the distribution used. RPM Packages with names that begin with “kernel-devel-” are development packages that can be used to compile custom kernels, and are not required when installing standard distribution kernels.

For Ubuntu, individual Linux kernel image package names take a form such as:

```
linux-image-*.deb
```

or

```
linux-signed-image-*.deb
```

Running `apt-cache search linux | grep 'kernel image'` shows the various packaged kernel images in the distribution.

When updating a kernel (section 11.3.3), an extra consideration for a head or software image is that third-party drivers may need to be re-installed or rebuilt for that kernel. This is necessary in the case of OFED drivers used instead of the standard distribution drivers. Details on re-installing or rebuilding such OFED drivers are given in section 7.6 of the *Installation Manual*.

#### Extra Considerations

When installing a kernel, besides the `chroot` steps of section 11.4, extra considerations for software images are:

- The kernel must also be explicitly set in `CMDaemon` (section 11.3.3) before it may be used by the regular nodes.
- Some GRUB-related errors with a text such as “grubby fatal error: unable to find a suitable template” typically show up during the installation of a kernel package in the software image. These occur due to a failure to find the partitions when running the post-install scripts in the `chroot` environment. They can simply be ignored because the nodes do not boot from partitions configured by GRUB.
- Warnings such as: `warning: Failed to read auxiliary vector, /proc not mounted?` may come up, due to `/proc` not being in use in the software image. These can also simply be ignored.

- The ramdisk must be regenerated using the `createramdisk` command (section 11.4.3).

As is standard for Linux, both head or regular nodes must be rebooted to use the new kernel.

### 11.3.2 Excluding Kernels And Other Packages From Updates

#### Specifying A Kernel Or Other Package For Update Exclusion

Sometimes it may be desirable to exclude the kernel from updates on the head node.

- When using `yum`, to prevent an automatic update of a package, the package is listed after using the `--exclude` flag. So, to exclude the kernel from the list of packages that should be updated, the following command can be used:

```
yum --exclude kernel update
```

To exclude a package such as `kernel` permanently from all YUM updates, without having to specify it on the command line each time, the package can instead be excluded inside the repository configuration file. YUM repository configuration files are located in the `/etc/yum.repos.d` directory, and the packages to be excluded are specified with a space-separated format like this:

```
exclude = <package 1> <package 2> ...
```

- The `zypper` command can also carry out the task of excluding the kernel package from getting updated when updating. To do this, the kernel package is first locked (prevented from change) using the `addlock` command, and the `update` command is run. Optionally, the kernel package is unlocked again using the `removelock` command:

```
zypper addlock kernel
zypper update
zypper removelock kernel          #optional
```

- One APT way to upgrade the software while excluding the kernel image package is to first update the system, then to mark the kernel as a package that is to be held, and then to upgrade the system. Optionally, after the upgrade, the `hold` mark can be removed:

```
apt-get update
apt-mark hold <linux-image-version>
apt-get upgrade
apt-mark unhold <linux-image-version>          #optional
```

The complementary way to carry out an upgrade in APT while holding the kernel back, is to use *pinning*. Pinning can be used to set dependency priorities during upgrades. Once set, it can hold a particular package back while the rest of the system upgrades.

#### Specifying A Repository For Update Exclusion

Sometimes it is useful to exclude an entire repository from an update on the head node. For example, the administrator may wish to exclude updates to the parent distribution, and only want updates for the cluster manager to be pulled in. In that case, in RHEL-derivatives a construction such as the following may be used to specify that only the repository IDs matching the glob `cm*` are used, from the repositories in `/etc/yum.repos.d/`:

```
[root@bright80 ~]# yum repolist
...
repo id                repo name                status
base                   CentOS-6 - Base          6,356+11
cm-rhel6-8.0           Cluster Manager 8.0      316+13
```

```
cm-rhel6-8.0-updates Cluster Manager 8.0      514
extras              CentOS-6 - Extras        14
updates             CentOS-6 - Updates       391
repolist: 7,591
[root@bright80 ~]# yum --disablerepo=* --enablerepo=cm* update
```

In Ubuntu, repositories can be added or removed by editing the repository under `/etc/apt/sources.list.d/`, or by using the `add-apt-repository` command.

### 11.3.3 Updating A Kernel In A Software Image

A kernel is typically updated in the software image by carrying out a package installation using the chroot environment (section 11.4), or specifying a relative root directory setting.

Package dependencies can sometimes prevent the package manager from carrying out the update, for example in the case of OFED packages (section 7.6 of the *Installation Manual*). In such cases, the administrator can specify how the dependency should be resolved.

Parent distributions are by default configured, by the distribution itself, so that only up to 3 kernel images are kept during YUM updates or `apt-get` upgrades. The distribution default value is however overridden by a Bright Cluster Manager default value, so that kernel images are never removed during YUM updates, or `apt-get upgrade`, by default.

For a software image, if the kernel is updated by the package manager, then the kernel is not used on reboot until it is explicitly enabled with either Bright View or `cmsh`.

- To enable it using Bright View, the Kernel version entry for the software image should be set. This can be accessed via the clickpath Provisioning→Software images→Edit→Settings→Kernel version (figure 11.1).




Figure 11.1: Updating A Software Image Kernel With Bright View

- To enable the updated kernel from `cmsh`, the `softwareimage` mode is used. The `kernelversion` property of a specified software image is then set and committed:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% softwareimage
[bright80]->softwareimage% use default-image
[bright80->softwareimage[default-image]]% set kernelversion 3.10.0-327.3.1.el7.x86_64
[bright80->softwareimage*[default-image*]]% commit -w
```

Tab-completion suggestions for the `set kernelversion` command will display the available values for the kernel version.

### 11.3.4 Setting Kernel Options For Software Images

A standard kernel can be booted with special options that alter its functionality. For example, a kernel can boot with `apm=off`, to disable Advanced Power Management, which is sometimes useful as a workaround for nodes with a buggy BIOS that may crash occasionally when it remains enabled.

In Bright View, to enable booting with this kernel option setting, the clickpath Provisioning→Software images→Edit→Settings→Kernel parameters (figure 11.1) is used to set the kernel parameter to `apm=off` for that particular image.

In `cmsh`, the equivalent method is to modify the value of “kernel parameters” in `softwareimage` mode for the selected image:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% softwareimage
[bright80]->softwareimage% use default-image
[bright80->softwareimage[default-image]]% append kernelparameters " apm=off"
[bright80->softwareimage*[default-image*]]% commit
```

Often kernel options load up modules and their parameters. Making module loading persist after reboot and setting module loading order is covered in section 5.3.2

Some kernel options may require changes to be made in the BIOS settings in order to function.

### 11.3.5 Kernel Driver Modules

Bright Computing provides some packages which install new kernel drivers or update kernel drivers. Such packages generally require the `kernel-devel` package. In this section, the `kernel-devel-check` utility is first described, followed by the various drivers that Bright Computing provides.

#### Kernel Driver Modules: `kernel-devel-check` Compilation Check

The distribution’s `kernel-devel` package is required to compile kernel drivers for its kernel. It must be the same version and release as the kernel running on the node.

To check the head node and software images for the installation status of the `kernel-devel` package, the Bright Cluster Manager utility `kernel-devel-check` is run from the head node:

#### Example

```
[root@mycluster ~]# kernel-devel-check
Head node: mycluster
Found kernel development rpm package kernel-devel-3.10.0-327.3.1.el7.x86_64

Software image: default-image
No kernel development directories found, probably no kernel development package installed.
Kernel development rpm package kernel-devel-3.10.0-327.3.1.el7.x86_64 not found
If needed, try to install the kernel development package with:
# chroot /cm/images/default-image yum install kernel-devel-3.10.0-327.3.1.el7.x86_64
```

```
Software image: default-image1
```

```
No kernel development directories found, probably no kernel development package installed.
Kernel development rpm package kernel-devel-3.10.0-327.3.1.el7.x86_64 not found
If needed, try to install the kernel development package with:
# chroot /cm/images/default-image1 yum install kernel-devel-3.10.0-327.3.1.el7.x86_64
```

As suggested by the output of `kernel-devel-check`, running a command on the head node such as:

```
[root@mycluster ~]# chroot /cm/images/default-image1 yum install kernel-devel-3.10.0-327.3.1.\
el7.x86_64el6.x86_64
```

installs a `kernel-devel` package, to the software image called `default-image1` in this case. The package version suggested corresponds to the kernel version set for the image, rather than necessarily the latest one that the distribution provides.

### Kernel Driver Modules: Improved Intel Wired Ethernet Drivers

**Improved Intel wired Ethernet drivers—what they are:** The standard distributions provide Intel wired Ethernet driver modules as part of the kernel they provide. Bright Computing provides an improved version of the drivers with its own `intel-wired-ethernet-drivers` package. The package contains more recent versions of the Intel wired Ethernet kernel drivers: `e1000`, `e1000e`, `igb`, `igbvf`, `ixgbe` and `ixgbev`. They often work better than standard distribution modules when it comes to performance, features, or stability.

**Improved Intel wired Ethernet drivers—replacement mechanism:** The improved drivers can be installed on all nodes.

For head nodes, the standard Intel wired Ethernet driver modules on the hard drive are overwritten by the improved versions during package installation. Backing up the standard driver modules before installation is recommended, because it may be that some particular hardware configurations are unable to cope with the changes, in which case reverting to the standard drivers may be needed.

For regular nodes, the standard distribution wired Ethernet drivers are not overwritten into the provisioner's software image during installation of the improved drivers package. Instead, the standard driver modules are removed from the kernel and the improved modules are loaded to the kernel during the `init` stage of boot.

For regular nodes in this "unwritten" state, removing the improved drivers package from the software image restores the state of the regular node, so that subsequent boots end up with a kernel running the standard distribution drivers from on the image once again. This is useful because it allows a very close-to-standard distribution to be maintained on the nodes, thus allowing better distribution support to be provided for the nodes.

If the software running on a fully-booted regular node is copied over to the software image, for example using the "Grab to image" button (section 11.5.2), this will write the improved driver module into the software image. Restoring to the standard version is then no longer possible with simply removing the improved drivers packages. This makes the image less close-to-standard, and distribution support is then less easily obtained for the node.

Thus, after the installation of the package is done on a head or regular node, for every boot from the next boot onwards, the standard distribution Intel wired Ethernet drivers are replaced by the improved versions for fully-booted kernels. This replacement occurs before the network and network services start. The head node simply boots from its drive with the new drivers, while a regular node initially starts with the kernel using the driver on the software image, but then if the driver differs from the improved one, the driver is unloaded and the improved one is compiled and loaded.

**Improved Intel wired Ethernet drivers—installation:** The drivers are compiled on the fly on the regular nodes, so a check should first be done that the `kernel-devel` package is installed on the regular nodes (section 11.3.5).

If the regular nodes have the `kernel-devel` package installed, then the following `yum` commands are issued on the head node, to install the package on the head node and in the `default-image`:

### Example

```
[root@mycluster ~]# yum install intel-wired-ethernet-drivers
[root@mycluster ~]# chroot /cm/images/default-image
[root@mycluster /]# yum install intel-wired-ethernet-drivers
```

For SUSE, the equivalent `zypper` commands are used ("`zypper in`" instead of "`yum install`").

### Kernel Driver Modules: CUDA Driver Installation

CUDA drivers are drivers the kernel uses to manage GPUs. These are compiled on the fly for nodes with GPUs in Bright Cluster Manager. The details of how this is done is covered in the CUDA software section (section 7.5 of the *Installation Manual*).

### Kernel Driver Modules: OFED And OPA Stack Installation

By default, the distribution provides the OFED stack used by the kernel to manage the InfiniBand or RDMA interconnect. Installing a Bright Cluster Manager repository OFED stack to replace the distribution version is covered in section 7.6 of the *Installation Manual*. Some guidance on placement into `initrd` for the purpose of optional InfiniBand-based node provisioning is given in section 5.3.3.

Installing a Bright Cluster Manager repository Omni-Path (OPA) stack is covered in section 7.7 of the *Installation Manual*.

## 11.4 Managing A Package In A Software Image And Running It On Nodes

### 11.4.1 Installing From Head Into The Image: Changing The Root Directory Into Which The Packages Are Deployed

Managing packages (including the kernel) inside a software image is most easily done while on the head node, using a "change root" mechanism with `rpm`, `yum`, `zypper`, or `apt-get`. The change root mechanism can be used as a package manager option, or can be invoked as a standalone command.

#### Change Root As An Option In The Package Manager Command

**Using the `rpm` command:** The `rpm` command supports the `--root` flag. To install an RPM package inside the default software image while in the head node environment, using the repositories of the head node, the command can be used as follows:

### Example

```
rpm --root /cm/images/default-image -ivh /tmp/libxml2-2.6.16-6.x86_64.rpm
```

**Using the `yum` command:** The `yum` command allows more general updates with a change root option. For example, all packages in the default image can be updated using `yum` for RHEL and derivatives with:

### Example

```
yum --installroot=/cm/images/default-image update    #for RHEL variants
```

**Using the `zypper` command:** For SLES, `zypper` can be used as follows to update the image:

### Example

```
zypper --root /cm/images/default-image up            #for SLES
```

**Change Root With `chroot`, Then Running The Package Manager Commands**

If the repositories used by the software image are the same as the repositories used by the head node, then the `chroot` command can be used instead of the `--installroot/--root` options to get the same result as the package manager options. That is, the same result is accomplished by first `chrooting` into an image, and subsequently executing the `rpm`, `yum`, or `zypper` commands without `--root` or `--installroot` arguments. Thus:

**For RHEL and derivatives:**

**Example**

```
chroot /cm/images/default-image
yum update      #for RHEL variants
```

**For SLES:**

**Example**

```
chroot /cm/images/default-image
zypper up       #for SLES
```

**For Ubuntu:** For Ubuntu and APT, the software image requires having the `/proc`, `/sys`, and `/dev` directories available during the package installation. This can be achieved by mounting these filesystems into the image, then using the `chroot` command to treat the image directory as the root directory from where the installation is to be carried out. After installation, the `chroot` jail should be exited, and after that, the directories should be umounted from the image.

**Example**

```
root@bright80:~# mount -o bind /dev /cm/images/default-image/dev
root@bright80:~# mount -o bind /proc /cm/images/default-image/proc
root@bright80:~# mount -o bind /sys /cm/images/default-image/sys
root@bright80:~# chroot /cm/images/default-image
root@bright80:/# apt-get update ; apt-get upgrade      #for Ubuntu
...
root@bright80:/# exit #out of chroot
root@bright80:/# umount /cm/images/default-image/{proc,sys,dev}
```

**Excluding Packages And Repositories From The Image**

Sometimes it may be desirable to exclude a package or a repository from an image.

- If using `yum --installroot`, then to prevent an automatic update of a package, the package is listed after using the `--exclude` flag. For example, to exclude the kernel from the list of packages that should be updated, the following command can be used:

```
yum --installroot=/cm/images/default-image --exclude kernel update
```

To exclude a package such as `kernel` permanently from all YUM updates, without having to specify it on the command line each time, the package can instead be excluded inside the repository configuration file of the image. YUM repository configuration files are located in the `/cm/images/default-image/etc/yum.repos.d` directory, and the packages to be excluded are specified with a space-separated format like this:

```
exclude = <package 1> <package 2> ...
```

- The `zypper` command can also carry out the task of excluding a package from getting updated when during update. To do this, the package is first locked (prevented from change) using the `addlock` command, then the `update` command is run, and finally the package is unlocked again using the `removelock` command. For example, for the kernel package:

```
zypper --root /cm/images/default-image addlock kernel
zypper --root /cm/images/default-image update
zypper --root /cm/images/default-image removelock kernel
```

- Sometimes it is useful to exclude an entire repository from an update to the image. For example, the administrator may wish to exclude updates to the base distribution, and only want Bright Cluster Manager updates to be pulled into the image. In that case, a construction like the following may be used to specify that, for example, from the repositories listed in `/cm/images/default-image/etc/yum.repos.d/`, only the repositories matching the pattern `cm*` are used:

```
[root@bright80 ~]# cd /cm/images/default-image/etc/yum.repos.d/
[root@bright80 yum.repos.d]# yum --installroot=/cm/images/default-image --disablerepo=* --enablerepo=cm* update
```

- For Ubuntu, excluding a repository can be carried out by removing the repository under `/etc/apt/sources.list.d/`, or by using the `add-apt-repository` command.

#### 11.4.2 Installing From Head Into The Image: Updating The Node

If the images are in place, then the node that use those images do not run those images until they have the changes placed on the nodes. Rebooting the nodes that use the software images is a straightforward way to have those nodes start up with the new images. Alternatively, the nodes can usually simply be updated without a reboot (section 5.6), if no reboot is required by the underlying Linux distribution.

#### 11.4.3 Installing From Head Into The Image: Possible Issues When Using `rpm --root`, `yum --installroot` Or `chroot`

- The update process with YUM or zypper on an image will fail to start if the image is being provisioned by a provisioner at the time. The administrator can either wait for provisioning requests to finish, or can ensure no provisioning happens by setting the image to a locked state (section 5.4.7), before running the update process. The image can then be updated. The administrator normally unlocks the image after the update, to allow image maintenance by the provisioners again.

##### Example

```
[root@bright80 ~]# cmsh -c "softwareimage use default-image; set locked yes; commit"
[root@bright80 ~]# yum --installroot /cm/images/default-image update
[root@bright80 ~]# cmsh -c "softwareimage use default-image; set locked no; commit"
```

- The `rpm --root` or `yum --installroot` command can fail if the versions between the head node and the version in the software image differ significantly. For example, installation from a Scientific Linux 5 head node to a Red Hat 6 software image is not possible with those commands, and can only be carried out with `chroot`.
- While installing software into a software image with an `rpm --root`, `yum --installroot` or with a `chroot` method is convenient, there can be issues if daemons start up in the image.

For example, installation scripts that stop and re-start a system service during a package installation may successfully start that service within the image's `chroot` jail and thereby cause related,



unexpected changes in the image. Pre- and post- (un)install scriptlets that are part of RPM packages may cause similar problems.

Bright Computing's RPM packages are designed to install under chroot without issues. However packages from other repositories may cause the issues described. To deal with that, the cluster manager runs the `chrootprocess` health check, which alerts the administrator if there is a daemon process running in the image. The `chrootprocess` also checks and kills the process if it is a `crond` process.

- For some package updates, the distribution package management system attempts to modify the ramdisk image. This is true for kernel updates, many kernel module updates, and some other packages. Such a modification is designed to work on a normal machine. For a regular node on a cluster, which uses an extended ramdisk, the attempt does nothing.

In such cases, a new ramdisk image must nonetheless be generated for the regular nodes, or the nodes will fail during the ramdisk loading stage during start-up (section 5.8.4).

The ramdisk image for the regular nodes can be regenerated manually, using the `createramdisk` command (section 5.3.2).

- Trying to work out what is in the image from under chroot must be done with some care.

For example, under chroot, running `uname -a` returns the kernel that is currently running—that is the kernel outside the chroot. This is typically not the same as the kernel that will load on the node from the filesystem under chroot. It is the kernel in the filesystem under chroot that an unwary administrator may wrongly expect to detect on running the `uname` command under chroot.

To find the kernel version that is to load from the image, the software image kernel version property (section 11.3.3) can be inspected using the cluster manager with:

#### Example

```
cmsh -c "softwareimage; use default-image; get kernelversion"
```

## 11.5 Managing Non-RPM Software In A Software Image And Running It On Nodes

Sometimes, packaged software is not available for a software image, but non-packaged software is. This section describes the installation of non-packaged software onto a software image in these two cases:

1. copying only the software over to the software image (section 11.5.1)
2. placing the software onto the node directly, configuring it until it is working as required, and syncing that back to the software image using Bright Cluster Manager's special utilities (section 11.5.2)

As a somewhat related aside, completely overhauling the software image, including changing the base files that distinguish the distribution and version of the image is also possible. How to manage that kind of extreme change is covered separately in section 11.6.

However, this current section (11.5) is about modifying the software image with non-RPM software while staying within the framework of an existing distribution and version.

In all cases of installing software to a software image, it is recommended that software components be placed under appropriate directories under `/cm/shared` (which is actually outside the software image).

So, just as in the case for installing software to the head node in section 11.2.2, appropriate software components go under:

```
/cm/shared/  
|-- apps  
|-- docs  
|-- examples  
|-- licenses  
`-- modulefiles
```

### 11.5.1 Managing The Software Directly On An Image

The administrator may choose to manage the non-packaged software directly in the correct location on the image.

For example, the administrator may wish to install a particular software to all nodes. If the software has already been prepared elsewhere and is known to work on the nodes without problems, such as for example library dependency or path problems, then the required files can simply be copied directly into the right places on the software image.

The `chroot` command may also be used to install non-packaged software into a software image. This is analogous to the `chroot` technique for installing packages in section 11.4:

#### Example

```
cd /cm/images/default-image/usr/src  
tar -xvzf /tmp/app-4.5.6.tar.gz  
chroot /cm/images/default-image  
cd /usr/src/app-4.5.6  
./configure --prefix=/usr  
make install
```

Whatever method is used to install the software, after it is placed in the software image, the change can be implemented on all running nodes by running the `updateprovisioners` (section 5.2.4) and `imageupdate` (section 5.6.2) commands.

### 11.5.2 Managing The Software Directly On A Node, Then Syncing Node-To-Image

#### Why Sync Node-To-Image?

Sometimes, typically if the software to be managed is more complex and needs more care and testing than might be the case in section 11.5.1, the administrator manages it directly on a node itself, and then makes an updated image from the node after it is configured, to the provisioner.

For example, the administrator may wish to install and test an application from a node first before placing it in the image. Many files may be altered during installation in order to make the node work with the application. Eventually, when the node is in a satisfactory state, and possibly after removing any temporary installation-related files on the node, a new image can be created, or an existing image updated.

Administrators should be aware that until the new image is saved, the node loses its alterations and reverts back to the old image on reboot.

The node-to-image sync can be seen as the converse of the image-to-node sync that is done using `imageupdate` (section 5.6.2).

The node-to-image sync discussed in this section is done using the “Grab to image” or “Synchronize image” menu option from Bright View, or using the “`grabimage`” command with appropriate options in `cmsh`. The sync automatically excludes network mounts and parallel filesystems such as Lustre and GPFS, but includes any regular disk mounted on the node itself.

Some words of advice and a warning are in order here

- The cleanest, and recommended way, to change an image is to change it directly in the node image, typically via changes within a `chroot` environment (section 11.5.1).

- Changing the deployed image running on the node can lead to unwanted changes that are not obvious. While many unwanted changes are excluded because of the `excludelistgrab*` lists during a node-to-image sync, there is a chance that some unwanted changes do get captured. These changes can lead to unwanted or even buggy behavior. The changes from the original deployed image should therefore be scrutinized with care before using the new image.
- For scrutiny, the `bash` command:

```
vimdiff <(cd image1; find . | sort) <(cd image2; find . | sort)
```

run from `/cm/images/` shows the changed files for image directories `image1` and `image2`, with uninteresting parts folded away. The `<(commands)` construction is called *process substitution*, for administrators unfamiliar with this somewhat obscure technique.

### Node-To-Image Sync Using Bright View

In Bright View, saving the node state from, for example, `node001` to a new image is done by selecting the appropriate menu option from the clickpath `Devices→Physical Nodes[node001]→Edit→Settings→Actions→Software image→option` (figure 11.2).




Figure 11.2: Synchronizing From A Node To A Software Image In Bright View

The possible options for saving a node state to an image are:

1. The `Grab to image` option: This opens up a dialog offering an image to sync to. Selecting the image creates a new image, grabbing what is to go to the image from the node. It wipes out whatever (if anything) is in the selected image, except for a list of excluded items. The excluded items are specified in the “Exclude list grabbing to a new image” list, available under Node Categories via the clickpath `Grouping→Node categories[default-image]→Settings→Exclude list grab new`. The exclude list is known as `excludelistgrabnew` (page 403) in `cmsh`.
2. The `Synchronize image` option: This does a sync from the node back to the software image that the node is provisioned with, using evaluation based on file change detection between the node

and the image. It is thus a synchronization to the already existing software image that is currently in use by the node.

The items that it excludes from the synchronization are specified in the “Exclude list image grab” list, available under Node Categories via the clickpath Grouping→Node categories[default-image]→Settings→Exclude list grab. This exclude list is known as `excludelistgrab` (page 403) in `cmsh`.

The synchronize option can be viewed by the administrator as being a more “gentle” way to carry out a node-to-image sync, compared to the grab option—that is, a “gentle sync” that tries to avoid wiping out existing files, versus a “violent grab” that can wipe out existing files.

The exclude lists are there to ensure, among other things, that the configuration differences between nodes are left alone for different nodes with the same image. The exclude lists are simple by default, but they conform in structure and patterns syntax in the same way that the exclude lists detailed in section 5.4.7 do, and can therefore be quite powerful.

The images that are available for selection with the `Grab to image` option can be existing images, while the image that the `Synchronize image` option syncs to is the existing image. If such existing images are known to work well with nodes, then overwriting them with a new image on a production system may be reckless. A wise administrator who has prepared a node that is to write an image would therefore follow a process similar to the following instead of simply overwriting an existing image:

1. A new image is created into which the node state can be written. This can be done by adding a new image in the clickpath Provisioning→Software images→Add, and setting a name for the image, for example: `newimage`. The node state with the software installed on it would then be saved using the `Grab to image` option, and choosing the image name `newimage` as the image to save it to.
2. A new category is then copied over from the old category. Within the new category the old image is changed to the new image. That is, image that is in `Software image` section—is changed to the new image `newimage`, and the result is saved.
3. Some nodes are set to the new category to test the new image. This is done by making some nodes members of the new category from within the `Settings` option of the node, and saving the change.
4. The nodes in the new category are made to pick up and run their new images. This can be done with a reboot of those nodes.
5. After sufficient testing, all remaining nodes can be moved to using the new image, and the old image is removed if no longer needed.

#### Node-To-Image Sync Using `cmsh`

The preceding Bright View method can alternatively be carried out using `cmsh` commands. The `cmsh` equivalent to the `Synchronize image` option is the `grabimage` command, available from device mode. The `cmsh` equivalent to the `Grab to image` option is the `grabimage -i` command, where the `-i` option specifies the new image it will write to. As before, that image must be created or cloned beforehand.

Cloning an image for use, setting a category of nodes that will use it, and then synchronizing a node that has the new software setup over to the new image on the provisioner might be carried out as follows via `cmsh`:

```
[root@bright80 ~]# cmsh
[bright80]% softwareimage
[bright80->softwareimage]% clone default-image default-image1
[bright80->softwareimage*[default-image1]]% commit
```

```
[bright80->softwareimage[default-image1]]% category
[bright80->category]% clone default default1
[bright80->category*[default1*]]% commit
[bright80->category[default1]]% set softwareimage default-image1
[bright80->category*[default1*]]% commit
[bright80->category[default1]]% device
[bright80->device]% grabimage -w -i default-image1 node001
[bright80->device]%
Mon Jul 18 16:13:00 2011 [notice] bright80: Provisioning started on node node001
[bright80->device]%
Mon Jul 18 16:13:04 2011 [notice] bright80: Provisioning completed on node node001
```

The `grabimage` command without the `-w` option simply does a dry-run so that the user can see in the provisioning logs what should be grabbed, without having the changes actually carried out. Running `grabimage -w` instructs `CMDaemon` to really write the image.

When writing out the image, two exclude lists may be used:

- The `excludelistgrabnew` object. This is used with `grabimage` with the `-i` option. The list can be accessed and edited under `cmsh`, in its `category` mode for a node image, as the `excludelistgrabnew` object. It corresponds to the “Exclude list grabbing to a new image” exclusion list associated with the `Grab to image` option (page 401) in Bright View.
- The `excludelistgrab` object. This is used with the `grabimage` command, run without the `-i` option. The list can be accessed and edited under `cmsh`, in its `category` mode for a node image, as the `excludelistgrab` object. It corresponds to the “Exclude list image grab” exclusion list associated with the `Synchronize image` option (page 401) in Bright View.

## 11.6 Creating A Custom Software Image

By default, the software image used to boot non-head nodes is based on the same version and release of the Linux distribution as used by the head node. However, sometimes an image based on a different distribution or a different release from that on the head node may be needed.

A custom software image is created typically by building an entire filesystem image from a regular node. The node, which is never a head node, is then called the *base host*, with the term “base” used to indicate that it has no additional cluster manager packages installed. The distribution on the base host, is called the *base distribution* and is a selection of packages derived from the *parent distribution* (Red Hat, Scientific Linux etc). A *base distribution package* is a package or rpm that is directly provided by the vendor of the parent distribution which the base distribution is based on, and is not provided by Bright Cluster Manager.

Creating a custom software image consists of two steps. The first step (section 11.6.1) is to create a *base (distribution) archive* from an installed base host. The second step (section 11.6.2) is to create the image from the base archive using a special utility, `cm-create-image`.

### 11.6.1 Creating A Base Distribution Archive From A Base Host

#### Structure Of The Base Distribution Archive

The step of creating the base distribution archive is done by creating an archive structure containing the files that are needed by the non-head node.

The filesystem that is archived in this way can differ from the special way that a Linux distribution unpacks and installs its filesystem on to a machine. This is because the distribution installer often carries out extra changes, for example in GRUB boot configuration. The creation of the base distribution archive is therefore a convenience to avoid working with the special logic of a distribution installer, which will vary across distributions and versions. Instead, the filesystem and contents of a node on which this parent distribution is installed—i.e. the end product of that logic—is what is dealt with.

The archive can be a convenient and standard `tar.gz` file archive (sometimes called the “base tar”), or, taking the step a little further towards the end result, the archive can be a fully expanded archive file tree.

### Repository Access Considerations When Intending To Build A Base Distribution Archive

For convenience, the archive should be up-to-date. So, the base host used to generate the base distribution archive should ideally have updated files. If, as is usual, the base host is a regular node, then it should ideally be up to date with the repositories that it uses. Therefore running `yum update` or `zypper up` on the base host image, and then provisioning the image to the base host, is recommended in order to allow the creation of an up-to-date base distribution archive.

However sometimes updates are not possible or desirable for the base host. This means that the base host archive that is put together from the base host filesystem is an un-updated archive. The custom image that is to be created from the archive must then be also be created without accessing the repositories, in order to avoid dependency problems with the package versions. Exclusion of access to the repositories is possible by specifying options to the `cm-create-image` command, and is described in section 11.6.2.

### Examples Of How To Build A Base Distribution Archive

In the following example, a base distribution `tar.gz` archive `/tmp/BASEDIST.tar.gz` is created from the base host `basehost64`:

#### Example

```
ssh root@basehost64 \
"tar -cz --acls --xattrs \
--exclude /etc/HOSTNAME --exclude /etc/localtime \
--exclude /proc --exclude /lost+found --exclude /sys \
--exclude /root/.ssh --exclude /var/lib/dhcpd/* \
--exclude /media/floppy --exclude /etc/motd \
--exclude /root/.bash_history --exclude /root/CHANGES \
--exclude /etc/udev/rules.d/*persistent*.rules \
--exclude /var/spool/mail/* --exclude /rhn \
--exclude /etc/sysconfig/rhn/systemid --exclude /tmp/* \
--exclude /var/spool/up2date/* --exclude /var/log/* \
--exclude /etc/sysconfig/rhn/systemid.save \
--exclude /root/mbox --exclude /var/cache/yum/* \
--exclude /etc/cron.daily/rhn-updates /" > /tmp/BASEDIST.tar.gz
```

Or alternatively, a fully expanded archive file tree can be created from `basehost64` by `rsync`ing to an existing directory (here it is `/cm/images/new-image`):

#### Example

```
rsync -av --acls --xattrs --hard-links --numeric-ids \
--exclude=/etc/HOSTNAME --exclude=/etc/localtime --exclude=/proc \
--exclude=/lost+found --exclude=/sys --exclude=/root/.ssh \
--exclude=/var/lib/dhcpd/* --exclude=/media/floppy \
--exclude=/etc/motd --exclude=/root/.bash_history \
--exclude=/root/CHANGES --exclude=/var/spool/mail/* \
--exclude=/etc/udev/rules.d/*persistent*.rules \
--exclude=/rhn --exclude=/etc/sysconfig/rhn/systemid \
--exclude=/etc/sysconfig/rhn/systemid.save --exclude=/tmp/* \
--exclude=/var/spool/up2date/* --exclude=/var/log/* \
--exclude=/root/mbox --exclude=/var/cache/yum/* \
--exclude=/etc/cron.daily/rhn-updates \
root@basehost64:/ /cm/images/new-image/
```

The `--acls`, `--xattrs`, and `--hard-links` options are only explicitly required—if they are valid—for earlier distribution versions of RHEL and SLES and their derivatives. This is indicated by the following table:

Used by default?	<code>--acls</code>	<code>--xattrs</code>	<code>--hard-links</code>
before RHEL7	no	no	no
before SLES12	*	*	no
RHEL7 and beyond	yes	yes	yes
SLES 12 and beyond	yes	yes	yes

\* The `--acls` `--xattrs` options in both examples are invalid before SLES12, so can be dropped.

The defaults can be modified by adjusting the `AdvancedConfig` options `RsyncHardLinks` (page 605), `RsyncXattrs` (page 605), and `RsyncAcls` (page 605).

For distribution versions RHEL7 and its derivatives, and also for SLES12, extended attributes and ACLs are used as `rsync` options by default. This is expected to continue for future distribution versions.

To use SELinux on compute nodes for RHEL7 and its derivatives, `RsyncXattrs` must be explicitly disabled (that is, extended attributes must not be copied).

For versions of RHEL and derivatives prior to RHEL7, the `--acls` and `--xattrs` options should be specified explicitly. For versions of SLES prior to SLES12, the `--acls` and `--xattrs` options are invalid, so can be dropped.

Having built the archive by following the examples suggested, the first step in creating the software image is now complete.

### 11.6.2 Creating The Software Image With `cm-create-image`

The second step, that of creating the image from the base archive, now needs to be done. This uses the `cm-create-image` utility, which is part of the `cluster-tools` package.

The `cm-create-image` utility uses the base archive as the base for creating the image. By default, it expects that the base distribution repositories be accessible just in case files need to be fetched from a repository package.

Thus, when the `cm-create-image` utility is run with no options, the image created mostly picks up the software only from the base archive. However, the image picks up software from the repository packages:

- if it is required as part of a dependency, or
- if it is specified as part of the package selection file (page 409).

If a repository package file is used, then it should be noted that the repository package files may be more recent compared with the files in the base archive. This can result in an image with files that are perhaps unexpectedly more recent in version than what might be expected from the base archive, which may cause compatibility issues. To prevent this situation, the `--exclude` option (section 11.2) can be used to exclude updates for the packages that are not to be updated.

Repository access can be directly to the online repositories provided by the distribution, or it can be to a local copy. For RHEL, online repository access can be activated by registering with the Red Hat Network (section 5.1 of the *Installation Manual*). Similarly, for SUSE, online repository access can be activated by registering with Novell (section 5.2 of the *Installation Manual*). An offline repository can be constructed as described in section 11.6.3 of this manual.

**Usage Of The `cm-create-image` Command**

The usage information for `cm-create-image` lists options and examples:

USAGE: `cm-create-image` <OPTIONS1> [OPTIONS2]

**OPTIONS1:**

-----

```
-a | --fromarchive <archive>  Create software image from archive file
                               of supported base distribution. Supported
                               file formats are .tar, .tgz, .tar.gz,
                               .tbz, and .tar.bz2. The extension must
                               match the format.

-d | --fromdir    <dir path>   Create software image from existing
                               directory that already has valid base
                               distribution.

-h | --fromhost   <hostname>   Create software image from running host

-n | --imagename  <name>       Name of software image to create in
                               cluster management daemon database.
```

**OPTIONS2:**

-----

```
-i | --imagedir <dir name>    Name of directory to be created in
                               /cm/images.
                               Contents of archive file are extracted
                               into this directory (default: name
                               specified with -n).

-r | --recreate               Recreate directory specified by -i or
                               default, if it exists.
                               Default behavior: directory is overwritten

-s | --skipdist               Skip install of base distribution packages

-e | --excludecmrepo          Do not copy default cluster manager repo
                               files. (Use this option when the repo
                               files have been already modified in the
                               image directory, and hence must not be
                               overwritten.)

-f | --forcecreate            Force non-interactive mode

-u | --updateimage            If image specified by -n already exists,
                               then it is updated, with the new parameters

-b | --basedistrepo <file>    Use this as the repo configuration file
                               for fetching required distribution
                               packages (cannot be used with -e).

-c | --cmrepo <file>         Use this as the repo configuration file
                               for fetching required cluster manager
                               packages (cannot be used with -e).

-m | --minimal                Install only a minimal set of packages,
                               relevant for the cluster management
                               daemon to function. Use with -s option, to
                               also prevent additional distribution
                               packages from being installed.

-w | --hwvendor               Install hardware vendor specific packages.
                               Valid choices are: dell|cray|ciscoucs|hp|
                               ibm|supermicro|other

-l | --resolvconf              resolv.conf to be used inside image dir,
                               during image creation (by default
                               /etc/resolv.conf from head node is used)

-x | --excludecm              <list> List of CM packages to exclude (comma-
```



```

                                separated)
-o | --exclude-from      <file>  File containing the exclude patterns in the
                                format of the 'rsync' command. See the
                                'exclude/include pattern rules' in the
                                documentation of 'rsync' for more information.
-j | --excludedist       <list>  List of distribution packages to exclude
                                (comma-separated)
-q | --excludehwvendor  <list>  List of hardware vendor packages to
                                exclude (comma-separated)
-g | --enableextrarepo  <value>  Argument must be the special string
                                'public' or path to a directory that has
                                the Bright DVD/ISO mounted.

```

#### EXAMPLES:

-----

1. `cm-create-image -a /tmp/RHEL6.tar.gz -n rhel6-image`
2. `cm-create-image -a /tmp/RHEL6.tar.gz -n rhel6-image -i /cm/images/test-image`
3. `cm-create-image -d /cm/images/SLES11-image -n sles11-image`
4. `cm-create-image -h node001 -n node001-image`
5. `cm-create-image -a /tmp/RHEL6.tar.gz -n rhel6-image -i /cm/images/new-image -r`
6. `cm-create-image -a /tmp/RHEL6.tar.gz -n rhel6-image -i /cm/images/new-image -u`
7. `cm-create-image -d /cm/images/new-image -n bio-image -s -e`
8. `cm-create-image -d /cm/images/new-image -n bio-image -s -b /tmp/rhel6-updates.repo`
9. `cm-create-image -d /cm/images/new-image -n bio-image -s -c /tmp/cm-rhel6.repo`
10. `cm-create-image -d /cm/images/new-image -n bio-image -s -m`

#### Explanations Of The Examples In Usage Of `cm-create-image`

Explanations of the 10 examples in the usage text follow:

1. In the following, a base distribution archive file, `/tmp/RHEL6.tar.gz`, is written out to a software image named `rhel6-image`:

```
cm-create-image --fromarchive /tmp/RHEL6.tar.gz --imagename rhel6-image
```

The image with the name `rhel6-image` is created in the CMDaemon database, making it available for use by `cmsh` and Bright View. If an image with the above name already exists, then `/cm/create-image` will exit and advise the administrator to provide an alternate name.

By default, the image name specified sets the directory into which the software image is installed. Thus here the directory is `/cm/images/rhel6-image/`.

2. Instead of the image getting written into the default directory as in the previous item, an alternative directory can be specified with the `--imagedir` option. Thus, in the following, the base distribution archive file, `/tmp/RHEL6.tar.gz` is written out to the `/cm/images/test-image` directory. The software image is given the name `rhel6-image`:

```
cm-create-image --fromarchive /tmp/RHEL6.tar.gz --imagename rhel6-image --imagedir \
/cm/images/test-image
```

3. If the contents of the base distribution file tree have been transferred to a directory, then no extraction is needed. The `--fromdir` option can then be used with that directory. Thus, in the following, the archive has already been transferred to the directory `/cm/images/SLES11-image`, and it is that directory which is then used to place the image under a directory named `/cm/images/sles11-image/`. Also, the software image is given the name `sles11-image`:

```
cm-create-image --fromdir /cm/images/SLES11-image --imagename sles11-image
```

4. A software image can be created from a running node using the `--fromhost` option. This option makes `cm-create-image` behave in a similar manner to `grabimage` (section 11.5.2) in `cmsh`. It requires passwordless access to the node in order to work. Generic nodes, that is nodes outside the cluster, can also be used. An image named `node001-image` can then be created from a running node named `node001` as follows:

```
cm-create-image --fromhost node001 --imagename node001-image
```

By default the image goes under the `/cm/images/node001-image/` directory.

5. If the destination directory already exists, the `--recreate` option can be used to recreate the existing directory. The administrator should be aware that this means removal of the content of any existing directory of the same name. Thus, in the following, the content under `/cm/images/new-image/` is deleted, and new image content is taken from the base distribution archive file, `/tmp/RHEL6.tar.gz` and then placed under `/cm/images/new-image/`. Also, the software image is given the name `rhel6-image`:

```
cm-create-image --fromarchive /tmp/RHEL6.tar.gz --imagename rhel6-image --imagedir \
/cm/images/new-image --recreate
```

If the `--recreate` option is not used, then the contents are simply overwritten, that is, the existing directory contents are copied over by the source content. It also means that old files on the destination directly may survive unchanged because the new source may not have filenames matching those.

6. The destination directory can also just be updated without removing the existing contents, by using the option `--updateimage`. The option is almost the same as the “contents are simply overwritten” behavior described in example 5, but it actually works like an `rsync` command. Thus, in the following, the base distribution archive file, `/tmp/RHEL6.tar.gz`, is used to update the contents under the directory `/cm/images/new-image/`. The name of the image is also set to `rhel6-image`.

```
cm-create-image --fromarchive /tmp/RHEL6.tar.gz --imagename rhel6-image --imagedir \
/cm/images/new-image --updateimage
```

7. With the default Bright Cluster Manager, the head node provisions a software image based on the parent distribution to the other nodes. The software image which runs on the nodes provides a selection of distribution packages from the parent distribution.

The default software image is thus a selection of Red Hat packages, if the head node uses Red Hat, or a selection of SUSE packages if the head node uses SUSE, and so on. The other packages for the software image are supplied by Bright Computing.

When creating a custom software image, and if using the `--skipdist` flag with `cm-create-image`, then Bright Cluster Manager packages are added to the software image, but no parent distribution packages are added. Thus in the following, the packages made available to `cm-create-image` in the directory `/cm/images/new-image`, are installed into the image named `bio-image`; however, no packages matching parent distribution packages are installed (because of the `--skipdist` option). Furthermore, transfer of the packages takes place only if they are newer than the files already in the `bio-image` image (because of the `--updateimage` option):

```
cm-create-image --fromdir /cm/images/new-image --imagename bio-image --skipdist --updateimage
```

So, only Bright Cluster Manager packages are updated to the image `bio-image` in the directory `/cm/images/bio-image`.

8. The `--basedistro` flag is used together with a `.repo` file. The file defines the base distribution repository for the image. The file is copied over into the repository directory of the image, (`/etc/yum.repos.d/` for Red Hat and similar, or `/etc/zypp/repos.d/` for SLES).
9. The `--cmrepo` flag is used together with a `.repo` file. The file defines the cluster manager repository for the image. The file is copied over into the repository directory of the image, (`/etc/yum.repos.d/` for Red Hat and similar, or `/etc/zypp/repos.d/` for SLES).
10. The `--minimal` flag tells `cm-create-image` to install only a limited number of Bright packages and its dependencies, which are required for the cluster management daemon to run the node. This also means that no Bright configuration RPMs will be installed, and all existing system configuration files will remain untouched. The minimal package selection list is read from `/cm/local/apps/cluster-tools/config/minimal`. The word “minimal” primarily refers to Bright Cluster Manager, and it is still required to use the `--skipdist` option explained earlier, in order to prevent additional parent distribution packages from being installed. This is because “minimal” in the context of the parent distribution can vary a lot depending on the requirements of different users, and is beyond the scope of `cm-create-image`.

```
cm-create-image --fromdir /cm/images/new-image --imagename bio-image --skipdist --minimal
```

#### Package Selection Files In `cm-create-image`

Regarding explanation 7 in the preceding explanations text, the selection of packages on the head node is done using a *package selection file*.

Package selection files are available in `/cm/local/apps/cluster-tools/config/`. For example, if the base distribution of the software image being created is CentOS6, then the configuration file used is:

```
/cm/local/apps/cluster-tools/config/CENTOS6-config-dist.xml
```

The package selection file is made up of a list of XML elements, specifying the name of the package, architecture and image type. For example:

```
...
<package image="slave" name="apr" arch="x86_64"/>
<package image="slave" name="apr-util" arch="x86_64"/>
<package image="slave" name="atk-devel" arch="x86_64"/>
<package image="slave" name="autoconf" arch="noarch"/>
...
```

The minimal set of packages in the list defines the minimal distribution that works with Bright Cluster Manager, and is the base-distribution set of packages, which may not work with some features of the distribution or Bright Cluster Manager. To this minimal set the following packages may be added to create the custom image:

- Packages from the standard repository of the parent distribution. These can be added to enhance the custom image or to resolve a dependency of Bright Cluster Manager. For example, in the (parent) Red Hat distribution, packages can be added from the (standard) main Red Hat channel to the base-distribution.
- Packages from outside the standard repository, but still from inside the parent distribution. These can be added to enhance the custom image or to resolve a dependency of Bright Cluster Manager. For example, outside the main Red Hat channel, but still within the parent distribution,

there is a supplementary packages channel (Red Hat 5) or an optional packages channel (Red Hat 6). Packages from these optional/supplementary channels can be added to the base-distribution to enhance the capabilities of the image or resolve dependencies of Bright Cluster Manager. Section 7.5.1 of the *Installation Manual* considers an example of such a dependency for the CUDA package.

Unless the required distribution packages and dependencies are installed and configured, particular features of Bright Cluster Manager, such as CUDA, cannot work correctly or cannot work at all.

The package selection file also contains entries for the packages that can be installed on the head (`image="master"`) node. Therefore non-head node packages must have the `image="slave"` attribute.

### Kernel Module Selection By `cm-create-image`

For an image created by `cm-create-image`, with a distribution `<dist>`, the default list of kernel modules to be loaded during boot are read from the file `/cm/local/apps/cluster-tools/config/<dist>-slavekernelmodules`.

`<dist>` can take the value `CENTOS6`, `CENTOS7`, `RHEL6u7`, `RHEL6u8`, `RHEL7u2`, `RHEL7u3`, `SL6`, `SL7`, `SLES11sp2`, `SLES11sp3`, `SLES11sp4`, `SLES12`, `SLES12sp1`, `SLES12sp2`.

If custom kernel modules are to be added to the image, they can be added to this file.

### Output And Logging During A `cm-create-image` Run

The `cm-create-image` run goes through several stages: validation, sanity checks, finalizing the base distribution, copying Bright Cluster Manager repository files, installing distribution package, finalizing image services, and installing Bright Cluster Manager packages. An indication is given if any of these stages fail.

Further detail is available in the logs of the `cm-create-image` run, which are kept in `/var/log/cmcreateimage.log.<image name>`, where `<image name>` is the name of the built image.

### Default Image Location

The default-image is at `/cm/images/default-image`, so the image directory can simply be kept as `/cm/images/`.

During a `cm-create-image` run, the `--imagedir` option allows an image directory for the image to be specified. This must exist before the option is used.

More generally, the full path for each image can be set:

- Using Bright View via the clickpath `Provisioning→Software images→Software Images→Edit→Settings→Path`
- In `cmsh` within `softwareimage` mode, for example:

```
[bright80->softwareimage]% set new-image path /cm/higgs/new-images
```

- At the system level, the images or image directory can be symlinked to other locations for organizational convenience

### Workload Manager Reconfiguration On The Custom Regular Node Image

After a custom regular node image has been created by `cm-create-image`, and the workload manager on the custom node image is to be managed by Bright Cluster Manager, then the manager typically needs to be reconfigured. This can be done by running the `wlm-setup` utility using the `--image` option with the path to the custom node image (section 7.3).

### 11.6.3 Configuring Local Repositories For Linux Distributions, And For The Bright Cluster Manager Package Repository, For A Software Image

Using local instead of remote repositories can be useful in the following cases:

- for clusters that have restricted or no internet access.
- for the RHEL and SUSE Linux distributions, which are based on a subscription and support model, and therefore do not have free access to their repositories.
- for creating a custom image with the `cm-create-image` command introduced in section 11.6.2, using local base distribution repositories.

The administrator can choose to access an online repository provided by the distribution itself via a subscription as described in Chapter 5 of the *Installation Manual*. Another way to set up a repository is to set it up as a local repository, which may be offline, or perhaps set up as a locally-controlled proxy with occasional, restricted, updates from the distribution repository.

In the three procedures that follow, the first two procedures explain how to create and configure a local offline SLES zypper or RHEL YUM repository for the subscription-based base distribution packages. These first two procedures assume that the corresponding ISO/DVD has been purchased/downloaded from the appropriate vendors. The third procedure then explains how to create a local offline YUM repository from the Bright Cluster Manager ISO for CentOS so that a cluster that is completely offline still has a complete and consistent repository access.

Thus, a summary list of what these procedures are about is:

- Setting up a local repository for SLES (page 411)
- Setting up a local repository for RHEL (page 412)
- Setting up a local repository for CentOS and Bright from the Bright Cluster Manager ISO for CentOS (page 412)

#### Configuring Local Repositories For SLES For A Software Image

For SLES11 SP0, SLES11 SP1, and SLES11 SP2, the required packages are spread across two DVDs, and hence two repositories must be created. Assuming the image directory is `/cm/images/sles11sp1-image`, while the names of the DVDs are `SLES-11-SP1-SDK-DVD-x86_64-GM-DVD1.iso` and `SLES-11-SP1-DVD-x86_64-GM-DVD1.iso`, then the contents of the DVDs can be copied as follows:

```
mkdir /mnt1 /mnt2
mkdir /cm/images/sles11sp1-image/root/repo1
mkdir /cm/images/sles11sp1-image/root/repo2
mount -o loop,ro SLES-11-SP1-SDK-DVD-x86_64-GM-DVD1.iso /mnt1
cp -ar /mnt1/* /cm/images/sles11sp1-image/root/repo1/
mount -o loop,ro SLES-11-SP1-DVD-x86_64-GM-DVD1.iso /mnt2
cp -ar /mnt2/* /cm/images/sles11sp1-image/root/repo2/
```

The two repositories can be added for use by zypper in the image, as follows:

```
chroot /cm/images/sles11sp1-image
zypper addrepo /root/repo1 "SLES11SP1-SDK"
zypper addrepo /root/repo2 "SLES11SP1"
exit (chroot)
```

### Configuring Local Repositories For RHEL For A Software Image

For RHEL distributions, the procedure is almost the same. The required packages are contained in one DVD.

```
mkdir /mnt1
mkdir /cm/images/rhel-image/root/repo1
mount -o loop,ro RHEL-DVD1.iso /mnt1
cp -ar /mnt1/* /cm/images/rhel-image/root/repo1/
```

The repository is added to YUM in the image, by creating the repository file `/cm/images/rhel-image/etc/yum.repos.d/rhel-base.repo` with the following contents:

```
[base]
name=Red Hat Enterprise Linux $releasever - $basearch - Base
baseurl=file:///root/repo1/Server
gpgcheck=0
enabled=1
```

### Configuring Local Repositories For CentOS And Bright Computing For A Software Image

**Mounting the ISOs** The variable `$imagedir` is assigned as a shortcut for the software image that is to be configured to use a local repository:

```
imagedir=/cm/images/default-image
```

If the ISO is called `bright-centos.iso`, then its filesystem can be mounted by the root user on a new mount, `/mnt1`, as follows:

```
mkdir /mnt1
mount -o loop bright-centos.iso /mnt1
```

The head node can then access the ISO filesystem.

The same mounted filesystem can also be mounted with the `bind` option into the software image. This can be done inside the software image by the root user, in the same relative position as for the head node, as follows:

```
mkdir $imagedir/mnt1
mount -o bind /mnt1 $imagedir/mnt1
```

This allows an operation run under the `$imagedir` in a chroot environment to access the ISO filesystem too.

**Creating YUM repository configuration files:** YUM repository configuration files can be created:

- **for the head node:** A repository configuration file

```
/etc/yum.repos.d/cm6.1-dvd.repo
```

can be created, for example, for a release tagged with a `<subminor>` number tag, with the content:

```
[bright-repo]
name=Bright Cluster Manager DVD Repo
baseurl=file:///mnt1/data/packages/8.0-<subminor>
enabled=1
gpgcheck=1
exclude = slurm* pbspro* sge* torque* cm-hwloc
```

- **for the regular node image:** A repository configuration file

```
$imagedir/etc/yum.repos.d/cm6.1-dvd.repo
```

can be created. This file is in the image directory, but it has the same content as the previous head node yum repository configuration file.

**Verifying that the repository files are set up right:** To verify the repositories are usable on the head node, the YUM cache can be cleaned, and the available repositories listed:

```
[root@bright80 ~]# yum clean all
[root@bright80 ~]# yum repolist -v
bright-repo                      Bright Cluster Manager DVD Repo
...
```

To carry out the same verification on the image, these commands can be run with `yum --installroot=$imagedir` substituted in place of just `yum`.

The ISO repository should show up, along with any others that are accessible. Connection attempts that fail to reach a network-based or local repositories display errors. If those repositories are not needed, they can be disabled from within their configuration files.

#### 11.6.4 Creating A Custom Image From The Local Repository

After having created the local repositories for SLES, RHEL or CentOS (section 11.6.3), a custom software image based on one of these can be created. For example, for CentOS, in a directory given the arbitrary name `offlineimage`:

```
cm-create-image -d $imagedir -n offlineimage -e -s
```

The `-e` option prevents copying the default cluster manager repository files on top of the image being created, since they may have been changed by the administrator from their default status. The `-s` option prevents installing additional base distribution packages that might not be required.





# 12

## Cluster Monitoring

Bright Cluster Manager monitoring allows a cluster administrator to monitor anything that can be monitored in the cluster. Much of the monitoring consists of pre-defined sampling configurations. If there is anything that is not configured, but the data on which it is based can be sampled, then monitoring can be configured for it too, by the administrator.

The monitoring data can be viewed historically, as well as on demand. The historical monitoring data can be stored raw, and optionally also as consolidated data—a way of summarizing data.

The data can be handled raw and processed externally, or it can be visualized within Bright View in the form of customizable charts. Visualization helps the administrator spot trends and abnormal behavior, and is helpful in providing summary reports for managers.

Monitoring can be configured to set off alerts based on triggers, and pre-defined or custom actions can be carried out automatically, depending on triggers. The triggers can be customized according to user-defined conditional expressions.

Carrying out such actions automatically after having set up triggers for them means that the monitoring system can free the administrator from having to carry out these chores.

In this chapter, the monitoring system is explained with the following approach:

1. A basic example is first presented in which processes are run on a node. These processes are monitored, and trigger an action when a threshold is exceeded.
2. With this easy-to-understand example as a basic model, the various features and associated functionality of the Bright Cluster Manager monitoring system are then described and discussed in further depth. These include visualization of data, concepts, configuration, monitoring customization and `cmsh` use.

### 12.1 A Basic Monitoring Example And Action

#### 12.1.1 Synopsis Of Basic Monitoring Example

In section 12.1, after an overview (section 12.1.1), a minimal basic example of monitoring a process is set up (section 12.1.2) and used (section 12.1.3). The example is contrived, with the aim being to present a basic example that covers a part of what the monitoring system is capable of handling. The basic example gives the reader a structure to keep in mind, around which further details are fitted and filled in during the coverage in the rest of this chapter.

For the basic example, a user runs a large number of pointless CPU-intensive processes on a head node which is normally very lightly loaded. An administrator can monitor user mode CPU load usage throughout the cluster, and notices this usage spike. After getting the user to stop wasting CPU cycles, the administrator may decide that putting a stop to such processes automatically is a good idea. The administrator can set that up with an action that is triggered when a high load is detected. The action that is taken after triggering, is to stop the processes (figure 12.1).




Figure 12.1: Monitoring Basic Example: CPU-intensive Processes Started, Detected And Stopped

The basic example thus illustrates how Bright Cluster Manager monitoring can be used to detect something on the cluster and how an action can be set up and triggered based on that detection.

### 12.1.2 Before Using The Basic Monitoring Example—Setting Up The Pieces

#### Running A Large Number Of Pointless CPU-Intensive Processes

One way to simulate a user running pointless CPU-intensive processes is to run several instances of the standard unix utility, `yes`. The `yes` command sends out an endless number of lines of “y” texts. It is typically used in scripts to answer dialog prompts for confirmation.

The administrator can run 8 subshell processes in the background from the command line on the head node, with `yes` output sent to `/dev/null`, as follows:

```
for i in {1..8}; do ( yes > /dev/null & ); done
```

Running “`mpstat 2`” shows usage statistics for each processor, updating every 2 seconds. It shows that `%user`, which is user mode CPU usage percentage, is close to 90% on an 8-core or less head node when the 8 subshell processes are running.

#### Setting Up The Kill Action

To stop the pointless CPU-intensive `yes` processes, the command `killall yes` can be used. The administrator can make it a part of a script `killallyes`:

```
#!/bin/bash
killall yes
```

and make the script executable with a `chmod 700 killallyes`. For convenience, it may be placed in the `/cm/local/apps/cmd/scripts/actions` directory where some other action scripts also reside.

### 12.1.3 Using The Monitoring Basic Example

Now that the pieces are in place, the administrator can use Bright View to add the `killallyesaction` action to its action list, and then set up a trigger for the action:

#### Adding The Action To The Actions List

In Bright View:

- The clickpath

Monitoring Configuration→Actions→Monitoring Actions→killprocess→Clone

is used to clone the structure of an existing action. The `killprocess` action is convenient because it is expected to function in a similar way, so its options should not have to be modified much. However, any action could be cloned and the clone modified in appropriate places.

- The name of the cloned action is changed. That is, the administrator sets Name to `killallyesaction`. This is just a sensible label—the name can be arbitrary.
- Script is set to the path `/cm/local/apps/cmd/scripts/actions/killallyes`, which is where the script was placed earlier (page 416).

After saving, the `killallyesaction` action becomes part of the list of monitoring actions (figure 12.2).




Figure 12.2: Bright View Monitoring Configuration: Adding An Action

#### Setting Up A Trigger Using CPUUser On The Head Node(s)

The clickpath

Monitoring Configuration→Triggers→Failing health checks→Clone

can be used to configure a monitoring trigger, by cloning an existing trigger. A trigger is a sample state condition that runs an action. In this case, the sample state condition may be that the metric (section 12.2.3) `CPUUser` must not exceed 50. If it does, then an action (`killallyesaction`) is run, which should kill the `yes` processes.

- `CPUUser` is a measure of the time spent in user mode CPU usage per second, and is measured in jiffy intervals per second.
- A jiffy interval is a somewhat arbitrary time interval that is predefined for kernel developers per platform. It is the minimum amount of time that a process has access to the CPU before the kernel can switch to another task.

Unlike `%user` from the `top` command, a jiffy interval is not a percentage.

To configure this, the trigger attributes can be modified as follows (figure 12.3):




Figure 12.3: Bright View Monitoring Configuration: Setting A Trigger

- A name is set for the trigger. The name can be arbitrary, and `killallyestrigger` is used in this example.
- the trigger is made active by enabling it
- the trigger can be set to run an action script if the sample state crosses over into a state that meets the trigger condition. That is, `Enter actions` is configured for a particular condition.

The condition under which the `Enter actions` action script is run in the example, can simply be when `CPUUser` on the head node is above 50. Such a condition can be set by setting an expression in the `expression` subwindow. In this subwindow (figure 12.4):

The screenshot shows the Bright View Monitoring Configuration interface. On the left is a sidebar with navigation options: Data Producers, Measurables, Consolidators, Actions, Triggers (selected), Health status, All Health checks, and Standalone Monitored Entities. The main area is divided into two panels. The left panel, titled 'trigger', shows configuration for 'killallyestrigger' with fields for Name (killallyestrigger), Severity (10), State flapping count (5), During actions (a dropdown), State flapping actions (a dropdown), and Mark entity as unknown (Enabled/Disabled buttons). The right panel, titled 'Monitoring Compare Expression killallyesregex', shows configuration for the expression with fields for Type (Monitoring Compare Expression), Name (killallyesregex), Entities (bright80), Measurables (CPUUser), Parameters (Parameters), Operator (GT), Value (50), Use raw (Enabled/Disabled buttons), and revision (revision). At the bottom are buttons for Revert, Delete, and Save.

Figure 12.4: Bright View Monitoring Configuration: Setting An Expression

- A name is set for the expression. The name can be arbitrary, and `killallyesregex` is used for Name in this example.
- An entity is set. In this case, the entity being monitored is the head node. If the head node is called `bright80` in this example, then `bright80` is the value set for entities. An entity is often simply a device, but it can be any object that `CMDaemon` stores.
- A measurable is set. In this case, Measurables is set to `CPUUser`.
- An operator and threshold value are set. In this case `GT`, which is the greater than operator, and `50` which is a significant amount of `CPUUser` time in jiffies/s, are set for Operator and Value.

After saving the configuration, the `killallyesregex` regular expression evaluates the data being sampled for the `killallyestrigger` trigger. If the expression is `TRUE`, then the trigger launches the `killallyesaction` action.

### The Result

In the preceding section, an action was added, and a trigger was set up with a monitoring expression.

With a default installation on a newly installed cluster, the measurement of `CPUUser` is done every 120s (the period can be modified in the Data Producer window of Bright View, as seen in figure 12.9). The basic example configured with the defaults thus monitors if `CPUUser` on the head node has crossed the bound of 50 jiffies/s every 120s.

If `CPUUser` is found to have entered—that is crossed over from below the value and gone into the zone beyond 50 jiffies—then the `killallyesregex` regular expression notices that. Then, the trigger it is configured for, `killallyestrigger` trigger, runs the `killallyesaction` action, which runs the `killallyes` script. The `killallyes` script kills all the running `yes` processes. Assuming the system is trivially loaded apart from these `yes` processes, the `CPUUser` metric value then drops to below 50 jiffies.

To clarify what “found to have entered” means in the previous paragraph:

After an `Enter` trigger condition has been met for a sample, the first sample immediately after that does not ever meet the `Enter` trigger condition, because an `Enter` threshold crossing condition requires the previous sample to be below the threshold.

The second sample can only launch an action if the `Enter` trigger condition is met and if the preceding sample is below the threshold.

Other non-yes CPU-intensive processes running on the head node can also trigger the `killallyes` script. Since the script only kills yes processes, leaving any non-yes processes alone, it would in such a case run unnecessarily. This is a deficiency due to the contrived and simple nature of the basic example which is being illustrated here. In a production case the action script is expected to have a more sophisticated design.

At this point, having gone through section 12.1, the reader is expected to have a rough idea of how monitoring, triggers, trigger conditional expressions, and actions work. The following sections in this chapter cover the concepts and features for Bright Cluster Manager monitoring in greater detail.

## 12.2 Monitoring Concepts And Definitions

A discussion of the concepts of monitoring, along with definitions of terms used, is appropriate at this point. The features of the monitoring system in Bright Cluster Manager covered later on in this chapter will then be understood more clearly.

### 12.2.1 Measurables

Measurables are measurements (sample values) that are obtained via data producers (section 12.2.10) in CMDaemon's monitoring system. The measurements can be made for nodes, head nodes, other devices, or other *entities*.

#### Types Of Measurables

Measurables can be:

- *enummetrics*: measurements with a small number of states. The states can be pre-defined, or user-defined. Further details on enummetrics are given in section 12.2.2.
- *metrics*: measurements with number values, and `no data`, as possible values. For example, values such as: -13113143234.5, 24, 9234131299. Further details on metrics are given in section 12.2.3.
- *health checks*: measurements with the states `PASS`, `FAIL`, and `UNKNOWN` as possible states, and `no data` as another possible state, when none of the other states are set. Further details on health checks are given in section 12.2.4.

#### no data And Measurables

If no measurements are carried out, but a sample value needs to be saved, then the sample value is set to `no data` for a measurable. This is a defined value, not a null data value. *metrics* and *enummetrics* can therefore also take the `no data` value.

#### Entities And Measurables

An entity is a concept introduced in Bright Cluster Manager version 8.0.

Normally, a device, or a category or some similar grouping is a convenient idea to keep in mind as an entity, for concreteness.

The default entities in a new installation of Bright Cluster Manager are the following:

```
device category partition[base] softwareimages
```

However, more generally, an entity can be an object from the following top level modes of `cmsh`:

```
bigdata category ceph cloud configurationoverlay device etcd hadoop jobqueue
jobs kubernetes mesos network nodegroup openstack partition profile puppet rack
softwareimage zookeeper
```

For example, a software image object that is to be provisioned to a node is an entity, with some of the possible attributes of the entity being the name, kernelversion, creationtime, or locked attributes of the image:

```
[root@bright80 ~]# cmsh -c "softwareimage use default-image; show"
Parameter                               Value
-----
Creation time                           Thu, 08 Jun 2017 18:15:13 CEST
Enable SOL                              no
Kernel modules                          <44 in submode>
Kernel parameters
Kernel version                          3.10.0-327.3.1.el7.x86_64
Locked                                  no
Name                                     default-image
...
```

Because measurements can be carried out on such a variety of entities, it means that the monitoring and conditional actions that can be carried out on a Bright Cluster Manager cluster can be very diverse. This makes entities a powerful and versatile concept in Bright Cluster Manager's monitoring system for managing clusters.

### Listing Measurables Used By An Entity

In `cmsh`, for an entity, such as a device within `device` mode, a list of the measurables used by that device can be viewed with the `measurables` command.

#### Example

```
[bright80->device]% measurables node001
Type      Name      Parameter  Class  Producer
-----
Enum      DeviceStatus
HealthCheck ManagedServicesOk
HealthCheck defaultgateway
HealthCheck diskspace
HealthCheck dmesg
OS
dmesg
...
```

The subsets of these measurables—enummetrics, metrics, and health checks—can be listed with the `enummetrics` (section 12.2.2), `metrics` (section 12.2.3), or `healthchecks` (section 12.2.4) command.

In Bright View, all the entities that are using health checks can be viewed via the clickpath:

Monitoring→All Health Checks (figure 12.22 section 12.4.7)

### Listing Measurables From monitoring Mode

Similarly, under `monitoring` mode, within the `measurable` submode, the list of measurable objects that can be used can be viewed with a `list` command:

#### Example

```
[bright80->monitoring]% measurable list
Type      Name (key)      Parameter  Class  Producer
-----
Enum      DeviceStatus
HealthCheck ManagedServicesOk
HealthCheck Mon::Storage
HealthCheck chrootprocess
HealthCheck cmsh
OS
chrootprocess
cmsh
...
```

The subsets of these measurables—enummetrics, metrics, and health checks—can be listed with: `list enum` (section 12.2.2), `list metric` (section 12.2.3), or `list healthcheck` (section 12.2.4).

In Bright View, the equivalent to listing the measurables can be carried out via the clickpath:

Monitoring configuration→Measurables (figure 12.10, section 12.4.2)

and listing the subsets of the measurables is possible using column filtering (figure 12.11, section 12.4.2).

### Viewing Parameters For A Particular Measurable From `monitoring` Mode

Within the `measurable` submode, parameters for a particular measurable can be viewed with the `show` command for that particular measurable:

#### Example

```
[bright80->monitoring->measurable]% use devicestatus
[bright80->monitoring->measurable[DeviceStatus]]% show
```

Parameter	Value
Class	Internal
Consolidator	none
Description	The device status
Disabled	no (DeviceState)
Maximal age	0s (DeviceState)
Maximal samples	4,096 (DeviceState)
Name	DeviceStatus
Parameter	
Producer	DeviceState
Revision	
Type	Enum

### 12.2.2 Enummetrics

An *enummetric* is a measurable for an entity that can only take a limited set of values. At the time of writing (June 2017), `DeviceStatus` is the only enummetric. This may change in future versions of Bright Cluster Manager.

The full list of possible values for the enummetric `DeviceStatus` is:

`up`, `down`, `closed`, `installing`, `installer_failed`, `installer_rebooting`, `installer_callinginit`, `installer_unreachable`, `installer_burning`, `burning`, `unknown`, `opening`, `going_down`, `virtual_smpnode_member`, `pending`, and `no data`.

The enummetrics available for use can be listed from within the `measurable` submode of the `monitoring` mode:

#### Example

```
[bright80->monitoring->measurable]% list enum
```

Type	Name (key)	Parameter	Class	Producer
Enum	DeviceStatus		Internal	DeviceState

```
[bright80->monitoring->measurable]%
```

The list of enummetrics that is configured to be used by an entity, such as a device, can be viewed with the `enummetrics` command for that entity:

#### Example



```
[bright80->device]% enummetrics node001
```

Type	Name	Parameter	Class	Producer
Enum	DeviceStatus		Internal	DeviceState

```
[bright80->device]%
```

The states that the entity has been through can be viewed with a `dumpmonitoringdata` command:

### Example

```
[bright80->device]% dumpmonitoringdata -99d now devicestatus node001
```

Timestamp	Value	Info
2017/07/03 16:07:00.001	down	
2017/07/03 16:09:00.001	installing	
2017/07/03 16:09:29.655	no data	
2017/07/03 16:11:00	up	
2017/07/12 16:05:00	up	

The parameters of an enummetric such as `devicestatus` can be viewed and set from monitoring mode, from within the `measurable` submode (page 422).

### 12.2.3 Metrics

A *metric* for an entity is typically a numeric value for an entity. The value can have units associated with it.

In the basic example of section 12.1, the metric value considered was `CPUUser`, measured at the default regular time intervals of 120s.

The value can also be defined as `no data`. `no data` is substituted for a null value when there is no response for a sample. `no data` is not a null value once it has been set. This means that there are no null values stored for monitored data.

Other examples for metrics are:

- `LoadOne` (value is a number, for example: 1.23)
- `WriteTime` (value in ms/s, for example: 5 ms/s)
- `MemoryFree` (value in readable units, for example: 930 MiB, or 10.0 GiB)

A metric can be a built-in, which means it comes with Bright Cluster Manager as integrated code within `CMDaemon`. This is based on `c++` and is therefore much faster than the alternative. The alternative is that a metric can be a standalone script, which means that it typically can be modified more easily by an administrator with scripting skills.

The word *metric* is often used to mean the script or object associated with a metric as well as a metric value. The context makes it clear which is meant.

A list of metrics in use can be viewed in `cmsh` using the `list` command from monitoring mode:

### Example

```
[bright80->monitoring]% measurable list metric
```

Type	Name (key)	Parameter	Class	Producer
Metric	AlertLevel	count	Internal	AlertLevel
Metric	AlertLevel	maximum	Internal	AlertLevel
...				

In Bright View, the metrics can be viewed with the clickpath:

Monitoring configuration→Measurables (figure 12.10, section 12.4.2)

and then clicking on the filter widget to select `Metric` (figure 12.11, section 12.4.2).

A list of metrics in use by an entity can be viewed in `cmsh` using the `metrics` command for that entity. For example, for the entity `node001` in `mode` devices:

#### Example

```
[bright80->devices]% metrics node001
```

Type	Name	Parameter	Class	Producer
Metric	AlertLevel	count	Internal	AlertLevel
Metric	AlertLevel	maximum	Internal	AlertLevel
...				

The parameters of a metric such as `AlertLevel:count` can be viewed and set from monitoring mode, from within the `measurable` submenu, just as for the other measurables:

#### Example

```
[bright80->monitoring->measurable]% use alertlevel:count
[bright80->monitoring->measurable[AlertLevel:count]]% show
```

Parameter	Value
Class	Internal
Consolidator	default
Cumulative	no
Description	Number of active triggers
Disabled	no
Maximal age	0s
Maximal samples	0
Maximum	0
Minimum	0
Name	AlertLevel
Parameter	count
Producer	AlertLevel
Revision	
Type	Metric

The equivalent Bright View clickpath to edit the parameters is:

Monitoring configuration→Measurables→Edit

### 12.2.4 Health Check

A *health check* value is a response to a check carried out on an entity. The response indicates the health of the entity for the check that is being carried out.

For example, the `ssh2node` health check, which runs on the head node to check if the SSH port 22 access to regular nodes is reachable.

A health check is run at a regular time interval, and can have the following possible values:

- **PASS:** The health check succeeded. For example, if `ssh2node` is successful, which suggests that an `ssh` connection to the node is fine.

- **FAIL:** The health check failed. For example, if `ssh2node` was rejected. This suggests that the `ssh` connection to the node is failing.
- **UNKNOWN:** The health check did not succeed, did not fail, but had an unknown response. For example, if `ssh2node` has a timeout, for example due to routing or other issues. It means that it is unknown whether the connection is fine or failing, because the response that came in is unknown. Typically the administrator should investigate this further.
- **no data:** The health check did not run, so no data was obtained. For example, if `ssh2node` is disabled for some time, then no data values were obtained during this time. Since the health check is disabled, it means that `no data` cannot be recorded during this time by `ssh2node`. However, because having a `no data` value in the monitoring data for this situation is a good idea—explicitly knowing about having no data is helpful for various reasons—then `no data` values can be set, by `CMDaemon`, for samples that have no data.

Other examples of health checks are:

- `diskspace`: check if the hard drive still has enough space left on it
- `mounts`: check mounts are accessible
- `mysql`: check status and configuration of MySQL is correct
- `hpraid`: check RAID and health status for certain HP RAID hardware

These and others can be seen in the directory: `/cm/local/apps/cmd/scripts/healthchecks`.

### Health Checks

In Bright View, the health checks that can be configured for all entities can be seen with the clickpath:

Monitoring configuration→Measurables (figure 12.10, section 12.4.2)

and then clicking on the filter widget to select `Health Check` (figure 12.11, section 12.4.2).

Options can be set for each health check by clicking through via the `Edit` button.

### All Configured Health Checks

In Bright View, health checks that have been configured for all entities can be seen with the clickpath:

Monitoring configuration→All Health Checks (section 12.4.7)

The view can be filtered per column.

### Configured Health Checks For An Entity

An overview can be seen for a particular entity `<entity>` via the clickpath:

Monitoring configuration→Health status→`<entity>`→Show

### Severity Levels For Health Checks, And Overriding Them

A health check has a settable severity (section 12.2.7) associated with its response defined in the trigger options.

For standalone healthchecks, the severity level defined by the script overrides the value in the trigger. For example, `FAIL 40` or `UNKNOWN 10`, as is set in the `hpraid` health check (`/cm/local/apps/cmd/scripts/healthchecks/hpraid`).

Severity values are processed for the `AlertLevel` metric (section 12.2.8) when the health check runs.

### Default Templates For Health Checks And Triggers

A health check can also launch an action based on any of the response values.

Monitoring triggers have the following default templates:

- Failing health checks: With a default severity of 15
- Passing health checks: With a default severity of 0
- Unknown health checks: With a default severity of 10

The severity level is one of the default parameters for the corresponding health checks. These defaults can also be modified to allow an action to be launched when the trigger runs, for example, sending an e-mail notification whenever any health check fails.

With the default templates, the actions are by default set for all health checks. However, specific actions that are launched for a particular measurable instead of for all health checks can be configured. To do this, one of the templates can be cloned, the trigger can be renamed, and an action can be set to launch from a trigger. The reader should be able to recognize that in the basic example of section 12.1 this is how, when the metric measurable `CPUUser` crosses 50 jiffies, the `killallyestrigger` is activated, and the `killallyes` action script is run.

#### 12.2.5 Trigger

A *trigger* is a threshold condition set for a sampled measurable. When a sample crosses the threshold condition, it enters or leaves a zone that is demarcated by the threshold.

A trigger zone also has a settable severity (section 12.2.7) associated with it. This value is processed for the `AlertLevel` metric (section 12.2.8) when an action is triggered by a threshold event.

Triggers are discussed further in section 12.4.5.

#### 12.2.6 Action

In the basic example of section 12.1, the action script is the script added to the monitoring system to kill all `yes` processes. The script runs when the condition is met that `CPUUser` crosses 50 jiffies.

An *action* is a standalone script or a built-in command that is executed when a condition is met, and has exit code 0 on success. The condition that is met can be:

- A `FAIL`, `PASS`, `UNKNOWN`, or `no data` from a health check
- A trigger condition. This can be a `FAIL` or `PASS` for conditional expressions.
- State flapping (section 12.2.9).

The actions that can be run are listed from within the `action` submode of the monitoring mode.

#### Example

```
[bright80->monitoring->action]% list
```

Type	Name (key)	Run on	Action
DrainAction	Drain	Active	Drain node from all WLM
EmailAction	Send e-mail	Active	Send e-mail
EventAction	Event	Active	Send an event to users with connected client
ImageUpdateAction	ImageUpdate	Active	Update the image on the node
PowerOffAction	PowerOff	Active	Power off a device
PowerOnAction	PowerOn	Active	Power on a device
PowerResetAction	PowerReset	Active	Power reset a device
RebootAction	Reboot	Node	Reboot a node
ScriptAction	killallyesaction	Node	/cm/local/apps/cmd/scripts/actions/killallyes
ScriptAction	killprocess	Node	/cm/local/apps/cmd/scripts/actions/killprocess.pl

ScriptAction	remount	Node	/cm/local/apps/cmd/scripts/actions/remount
ScriptAction	testaction	Node	/cm/local/apps/cmd/scripts/actions/testaction
ShutdownAction	Shutdown	Node	Shutdown a node
UndrainAction	Undrain	Active	Undrain node from all WLM







The Bright View equivalent is accessible via the clickpath:

Monitoring configuration→Actions (figure 12.17, section 12.4.4)

Configuration of monitoring actions is discussed further in section 12.4.4.

### 12.2.7 Severity

*Severity* is a positive integer value that the administrator assigns for a trigger. It takes one of these 6 suggested values:

Value	Name	Icon	Description
0	debug		debug message
0	info		informational message
10	notice		normal, but significant, condition
20	warning		warning conditions
30	error		error conditions
40	alert		action must be taken immediately

Severity levels are used in the `AlertLevel` metric (section 12.2.8). They can also be set by the administrator in the return values of health check scripts (section 12.2.4).

By default the severity value is 15 for a health check `FAIL` response, 10 for a health check `UNKNOWN` response, and 0 for a health check `PASS` response (section 12.2.4).

### 12.2.8 AlertLevel

*AlertLevel* is a special metric. It is sampled and re-calculated when an event with an associated *Severity* (section 12.2.7) occurs. There are three types of *AlertLevel* metrics:

1. `AlertLevel (count)`: the *number* of events that are at `notice` level and higher. The aim of this metric is to alert the administrator to the *number* of issues.
2. `AlertLevel (max)`: simply the maximum severity of the latest value of all the events. The aim of this metric is to alert the administrator to the severity of the *most important* issue.
3. `AlertLevel (sum)`: the *sum* of the latest severity values of all the events. The aim of this metric is to alert the administrator to the *overall severity* of issues.

### 12.2.9 Flapping

*Flapping*, or *State Flapping*, is when a measurable trigger that is detecting changes (section 12.4.5) that are too frequent. That is, the measurable goes in and out of the zone too many times over a number of samples. In the basic example of section 12.1, if the `CPUUser` metric crossed the threshold zone 5 times within 5 minutes (the default values for flap detection), then it would by default be detected as flapping. A flapping alert would then be recorded in the event viewer, and a flapping action could also be launched if configured to do so.

### 12.2.10 Data Producer

A data producer produces measurables. Sometimes it can be a group of measurables, as in the measurables provided by a data producer that is being used:

### Example

```
[bright80->monitoring->measurable]% list -f name:25,producer:15 | grep ProcStat
BlockedProcesses      ProcStat
CPUGuest              ProcStat
CPUIdle               ProcStat
CPUIrq                ProcStat
CPUNice               ProcStat
CPUSoftIrq            ProcStat
CPUSteal              ProcStat
CPUSystem             ProcStat
CPUUser               ProcStat
CPUWait               ProcStat
CtxtSwitches          ProcStat
Forks                 ProcStat
Interrupts            ProcStat
RunningProcesses      ProcStat
```

Sometimes it may just be one measurable, as provided by a used data producer:

### Example

```
[bright80->monitoring->measurable]% list -f name:25,producer:15 | grep ssh2node
ssh2node              ssh2node
```

It can even have no measurables, and just be an empty container for measurables that are not in use yet.

In cmsh all possible data producers (used and unused) can be listed as follows:

### Example

```
[bright80->monitoring->setup]% list
```

The equivalent in Bright View is via the clickpath:

Monitoring Configuration→Data Producers

The data producers configured for an entity, such as a head node `bright80`, can be listed with the `monitoringproducers` command:

### Example

```
[bright80->device[bright80]]% monitoringproducers
```

Type	Name	Arguments	Measurables	Node execution filters
AlertLevel	AlertLevel		3 / 231	<0 in submode>
CMDaemonState	CMDaemonState		1 / 231	<0 in submode>
ClusterTotal	ClusterTotal		18 / 231	<1 in submode>
Collection	NFS		32 / 231	<0 in submode>
Collection	sdt		0 / 231	<0 in submode>
DeviceState	DeviceState		1 / 231	<1 in submode>
HealthCheckScript	chrootprocess		1 / 231	<1 in submode>
HealthCheckScript	cmsh		1 / 231	<1 in submode>
HealthCheckScript	defaultgateway		1 / 231	<0 in submode>
HealthCheckScript	diskspace		1 / 231	<0 in submode>
HealthCheckScript	dmesg		1 / 231	<0 in submode>

HealthCheckScript	exports	1 / 231	<0 in submode>
HealthCheckScript	failedprejob	1 / 231	<1 in submode>
HealthCheckScript	hardware-profile	0 / 231	<1 in submode>
HealthCheckScript	ib	1 / 231	<0 in submode>
HealthCheckScript	interfaces	1 / 231	<0 in submode>
HealthCheckScript	ldap	1 / 231	<0 in submode>
HealthCheckScript	lustre	1 / 231	<0 in submode>
HealthCheckScript	mounts	1 / 231	<0 in submode>
HealthCheckScript	mysql	1 / 231	<1 in submode>
HealthCheckScript	ntp	1 / 231	<0 in submode>
HealthCheckScript	oomkiller	1 / 231	<0 in submode>
HealthCheckScript	opalinkhealth	1 / 231	<0 in submode>
HealthCheckScript	rogueprocess	1 / 231	<1 in submode>
HealthCheckScript	schedulers	1 / 231	<0 in submode>
HealthCheckScript	smart	1 / 231	<0 in submode>
HealthCheckScript	ssh2node	1 / 231	<1 in submode>
Job	JobSampler	0 / 231	<1 in submode>
JobQueue	JobQueueSampler	7 / 231	<1 in submode>
MonitoringSystem	MonitoringSystem	36 / 231	<1 in submode>
ProcMemInfo	ProcMemInfo	10 / 231	<0 in submode>
ProcMount	ProcMounts	2 / 231	<0 in submode>
ProcNetDev	ProcNetDev	18 / 231	<0 in submode>
ProcNetSnmpp	ProcNetSnmpp	21 / 231	<0 in submode>
ProcPidStat	ProcPidStat	5 / 231	<0 in submode>
ProcStat	ProcStat	14 / 231	<0 in submode>
ProcVMStat	ProcVMStat	6 / 231	<0 in submode>
Smart	SmartDisk	0 / 231	<0 in submode>
SysBlockStat	SysBlockStat	20 / 231	<0 in submode>
SysInfo	SysInfo	5 / 231	<0 in submode>
UserCount	UserCount	3 / 231	<1 in submode>

The displayed data producers are the ones configured for the entity, even if there are no measurables used by the entity.

Data producer configuration in Bright View is discussed further in section 12.4.1.

### 12.2.11 Conceptual Overview: The Main Monitoring Interfaces Of Bright View

Bright View has its own display modes, event and action results logs, and account handling screen. These can be selected via the 5 icons in the top right corner of the Bright View standard display (figure 12.5):




Figure 12.5: Bright View: Top Right Corner Icons

The 5 icons are described from left to right next:

1. Settings mode is the display that is shown when Bright View first starts up.

Within Settings mode is the Monitoring Configuration resource. This resource should not be confused with the Bright View Monitoring mode, which is launched by the next icon in

figure 12.5. Monitoring configuration is about configuring how items are monitored and how their data values are collected, and is discussed further in section 12.4.

2. The `Monitoring` mode is the other mode that can be displayed in Bright View. Clicking on this icon opens up views for monitoring graphs. These views allow visualization of the data values collected, according to the specifications of the `Bright View Settings` mode. The visualization allows graphs to be configured, and is discussed further in section 12.3.
3. The `Events` icon allows logs of events (section 12.9.1) to be viewed.
4. The `Actions results` icon allows the logs of the results of actions to be viewed.
5. The `Account` handling icon allows account settings to be managed for the Bright View user.

The monitoring aspects of the first two icons are discussed in greater detail in the sections indicated.

## 12.3 Monitoring Visualization With Bright View

The `Monitoring` icon in the menu bar of Bright View (item 2 in figure 12.5) launches an intuitive visualization tool that is the main GUI tool for getting a feel of the system's behavior over periods of time. With this tool the measurements and states of the system can be viewed as resizable and overlayable graphs. The graphs can be zoomed in and out on over a particular time period, the graphs can be laid out on top of each other or the graphs can be laid out as a giant grid. The graph scale settings can also be adjusted, stored and recalled for use the next time a session is started.

An alternative to Bright View's visualization tool is the command-line `cmsh`. This has the same functionality in the sense that data values can be selected and studied according to configurable parameters with it (section 12.6). The data values can even be plotted and displayed on graphs with `cmsh` with the help of unix pipes and graphing utilities. However, the strengths of monitoring with `cmsh` lie elsewhere: `cmsh` is more useful for scripting or for examining pre-decided metrics and health checks rather than a quick visual check over the system. This is because `cmsh` needs more familiarity with options, and is designed for text output instead of interactive graphs. Monitoring with `cmsh` is discussed in sections 12.5 and 12.6.

Visualization of monitoring graphs with Bright View is now described.

### 12.3.1 The Monitoring Window

If the `Monitoring` icon is clicked on from the menu bar of Bright View (figure 12.5), then a monitoring window for visualizing data opens up. By default, this displays blank plot panels—graph axes with a time scale going back some time on the  $x$ -axis, and with no  $y$ -axis measurable data values plotted (figure 12.6).






Figure 12.6: Bright View Monitoring Window: Blank Plot Panel

### Finding And Selecting The Measurable To Be Plotted

To plot measurables, the entity which it belongs to should be selected from the navigation menu on the left-hand side. Once that has been selected, a class for that measurable can be chosen, and then the measurable itself can be selected. For example, to plot the measurable `CPUUser` for a head node `bright80`, it can be selected from the navigation clickpath `Device`→`bright80`→`CPU`→`CPUUser`.

Sometimes, finding a measurable is easier with the Search box. Typing in `CPUUser` there shows all the measurables with that text (figure 12.7). The search is case-insensitive.




Figure 12.7: Bright View Monitoring Window: Search Box In Navigation

The search box can handle some simple regexes too, with `.`, `*` and `|` taking their usual meaning:

### Example

- `node001.*cpuuser`: select a measurable with a data path that starts with `node001` and ends with `cpuuser`, with 0 or more characters of any kind in between.

- `(node001|node002) .*cpuuser`: as for preceding example, but including `node002` as an alternative to `node001`.

The `/` (forward slash) allows filtering according to the data path. It corresponds to the navigation depth in the tree hierarchy:

### Example

- `node001/cpu/cpuuser`: search for a measurable with a data path that matches `node001/cpu/cpuuser`

### Plotting The Measurable

Once the measurable is selected, it can be drag-and-dropped into a plot panel. This causes the data values to be plotted.

When a measurable is plotted into a panel, two graph plots are displayed. The smaller, bottom plot, represents the polled value as a bar chart. The larger, upper plot, represents an interpolated line graph. Different kinds of interpolations can be set. To get a quick idea of the effect of different kinds of interpolations, <https://bl.ocks.org/mbostock/4342190> is an interactive overview that shows how they work on a small set of values.

The time axes can be expanded or shrunk using the mouse wheel in the graphing area of the plot panel. The resizing is carried out centered around the position of the mouse pointer.

## 12.4 Monitoring Configuration With Bright View

This section is about the configuration of monitoring for measurables, and about setting up trigger actions.

If Bright View is running in the standard `Settings` mode, which is the first icon in figure 12.5, page 429, then selecting `Monitoring Configuration` from the resources section makes the following menu items available for managing or viewing:

- `Data Producers` (section 12.4.1)
- `Measurables` (section 12.4.2)
- `Consolidators` (section 12.4.3)
- `Actions` (section 12.4.4)
- `Triggers` (section 12.4.5)
- `Health status` (section 12.4.6)
- `All Health checks` (section 12.4.7)
- `Standalone Monitored Entities` (section 12.4.8)



Figure 12.8: Bright View Monitoring Configuration Settings

These settings (figure 12.8) are now discussed in detail.

#### 12.4.1 Monitoring Configuration: Data Producers

The `Data Producers` window lists all the data producers. Data producers are introduced in section 12.2.10.

Each data producer can have its settings edited within a subwindow. For example, the `ProcStat` data producer, which produces data for several measurables, including `CPUUser`, has the settings shown in figure 12.9:




Figure 12.9: Bright View Monitoring Configuration Data Producer Settings

When the data producer takes samples to produce data, run length encoding (RLE) is used to compress the number of samples that are stored as data. Consolidation is carried out on the RLE samples. Consolidation in Bright Cluster Manager means gathering several data values, and making one value from them over time periods. Consolidation is done as data values are gathered. The point at which data values are discarded, if ever, is thus not dependent on consolidation.

Some remarks about some of the data producer settings that are seen in the subwindow of figure 12.9:

- **Maximal samples:** the maximum number of RLE samples that are kept. If set to 0, then the number of samples is not considered.
- **Maximal Age:** the maximum age of RLE samples that are kept. If Maximal Age is set to 0 then the sample age is not considered.

With Maximal samples and Maximal Age, the first of the rules that is reached is the one that causes the exceeding RLE samples to be dropped.


Samples are kept forever if Maximal samples and Maximal Age are both set to 0. This is discouraged due to the risk of exceeding the available data storage space.

- **Interval:** the interval between sampling, in seconds.
- **Offset:** A time offset from start of sampling. Some sampling depends on other sampling to be carried out first. This is used, for example, by data producers that rely on sampling from other data producers. For example, the `AggregateNode` data producer, which has measurables such as `TotalCPUIdle` and `TotalMemoryFree`. The samples for `AggregateNode` depend upon the `ProcStat` data producer, which produces the `CPUIdle` measurable; and the `ProcMemInfo` data producer, which produces the `MemoryFree` measurable.
- **Fuzzy offset:** a multiplier in the range from 0 to 1. It is multiplied against the sampling time interval to fix a maximum value for the time offset for when the sampling takes place. The actual offset used per node is a pseudo-random range up to that maximum time offset.

- **Consolidator:** By default, set to the `default` group. The `default` group consolidates (summarizes) the RLE samples over periods of an hour, a day, and a week. Consolidators are explained further in section 12.4.3.
- **Node execution filters:** A way to filter execution (restrict execution) of the data producer. If not set, then the data producer runs on all nodes managed by CMDaemon. Filters can be for nodes, types, overlays, resources, and categories.
- **Execution multiplexer:** A way to multiplex execution (have execution work elsewhere) for a data producer. A data producer runs on the entity that it is being executed on, as defined by the node execution filter setting. A data producer can also gather samples from other nodes, types, overlays, and resources. The entities from which it can sample are defined into groups called execution multiplexers. Execution multiplexers can thus be node multiplexers, type multiplexers, overlay multiplexers, or resource multiplexers.
- **When:** This has three possible values:
  - **Timed:** Data producer is run at a periodic `Interval`. This is the default.
  - **Pre job:** Data producer is only run before a job, in the prolog of the job. This is typically a check as part of the workload manager process (section 7.8.2).
  - **On demand:** Data producer is only run on demand, and not at a periodic `Interval`.
- **Only when idle:** By default a data producer runs regardless of how busy the nodes are. However, if the `Only when idle` setting is enabled, then the data producer runs only when the node is idle. Idle is a condition that is defined by the metric condition `LoadOne>1` (page 651).

### 12.4.2 Monitoring Configuration: Measurables

The Measurables window lists the available measurables (figure 12.10):



NAME	TYPE	PARAMETER	CLASS	OPTIONS
<input type="checkbox"/> AlertLevel	Metric	count	Internal	Edit
<input type="checkbox"/> AlertLevel	Metric	maximum	Internal	Edit
<input type="checkbox"/> AlertLevel	Metric	sum	Internal	Edit
<input type="checkbox"/> BlockedProcesses	Metric		OS	Edit
<input type="checkbox"/> BufferMemory	Metric		Memory	Edit
<input type="checkbox"/> BytesRecv	Metric	eth0	Network	Edit
<input type="checkbox"/> BytesRecv	Metric	eth1	Network	Edit
<input type="checkbox"/> BytesSent	Metric	eth0	Network	Edit

Figure 12.10: Bright View Monitoring Configuration Measurables

There are many measurables. It can therefore be useful to use the filtering-by-column option at the top of the columns. Each filtering option also has a search box associated with it (figure 12.11):




Figure 12.11: Bright View Monitoring Configuration Measurables Column Filter

From the measurables window, a subwindow can be opened with the `Edit` button for a measurable. This accesses the options for a particular measurable (figure 12.12):




Figure 12.12: Bright View Monitoring Configuration Measurables Options Subwindow

The options shown include the sampling options: `Maximal age`, `Maximal samples`, `Consolidator`. The sampling options work as described for data producers (section 12.4.1).

Other options for a metric are setting the `Maximum` and `Minimum` values, the `Unit` used, and whether the metric is `Cumulative`.

If a metric is cumulative, then it is monotonic. Monotonic means that the metric only increments (is

cumulative), as time passes. In other words, if the metric is plotted as a graph against time, with time on the  $x$ -axis, then the metric never descends. Normally the increments are from the time of boot onwards, and the metric resets at boot. For example, the number of bytes received at an interface is cumulative, and resets at boot time.

Usually the cluster administrator is only interested in the differential value of the metric per sample interval. That is, the change in the value of the current sample, from its value in the preceding sample. For example, bytes/second, rather than total number of bytes up to that time from boot.

### 12.4.3 Monitoring Configuration: Consolidators

#### Introduction To Consolidators

The concept of consolidators is explained using simple ascii graphics in Appendix K, while the `cmsh` interface to the `consolidators` submode is discussed in section 12.5.2.

In this current section, the Bright View interface to consolidators is discussed.

In Bright View, the `Consolidators` window lists all consolidator groups (figure 12.13).




Figure 12.13: Bright View Monitoring Configuration Consolidator Groups

Subwindows allow the component consolidators to be created or modified (figure 12.14).




Figure 12.14: Bright View Monitoring Configuration Consolidator Groups Components

There are two pre-existing consolidator groups: `default` and `none`.

#### The `none` Consolidator Group

The `none` consolidator group, has no consolidators. Using a consolidator of `none` for a measurable or data producer means that samples are not consolidated. This can be dangerous if the cluster is more likely to run out of space due to unrestrained sampling, as can occur, for example, if `Maximal Age` and

Maximal samples (section 12.4.1) for data producers are both set to 0.

### The default Consolidator Group

The default consolidator group consists of the consolidators `hour`, `day`, and `week`. These are, unsurprisingly, defined to consolidate the samples in intervals of an hour, day, or week.

A consolidated value is generated on-the-fly. So, for example, during the hour that samples of a measurable come in, the `hour` consolidator uses the samples to readjust the consolidated value for that hour. When the hour is over, the consolidated value is stored for that hour as the data value for that hour, and a new consolidation for the next hour begins.

Consolidator values are kept, as for sample values, until the `Maximal Age` and `Maximal sample` settings prevent data values being kept.

### Other Consolidator Group Possibilities

Other sets of custom intervals can also be defined. For example, instead of the default consolidator group, (`hour`, `day`, `week`), a similar group called `decimalminutes` consolidator group, (`1min`, `10min`, `100min`, `1000min`, `10000min`) could be created with the appropriate intervals (figure 12.15):




Figure 12.15: Bright View Monitoring Configuration Consolidators: `decimalminutes` Consolidator Group

### Consolidator Item Settings

Consolidator items are members of the consolidator groups. The items have settings as properties, and can be managed (figure 12.16).




Figure 12.16: Bright View Monitoring Configuration Consolidators: Consolidator Item Settings



For the consolidator of `hour`, within the default consolidators group, the clickpath to edit its properties is:

Monitoring Configuration→Consolidators[default]→Edit→Consolidator[hour]→Edit

The properties that can be set for a consolidator item are:

- **Name:** The name of the consolidator item. By default, for the consolidator group `default`, the consolidator items with names of `Day`, `Hour`, and `Month` are already set up, with appropriate values for their corresponding fields.
- **Maximal samples:** The maximum number of samples that are stored for that consolidator item. This should not be confused with the `Maximal samples` of the measurable being consolidated.
- **Interval:** The time period (in seconds) covered by the consolidator sample. For example, the consolidator with the name `Hour` has a value of 3600. The property should not be confused with the time period between samples of the measurable being consolidated.
- **Offset:** The time offset from the default consolidation time, explained in more detail shortly.
- **Kind:** The kind of consolidation that is done on the raw data samples. The value of `kind` is set to `average` by default. The output result for a processed set of raw data—the consolidated data point—is an average, a maximum or a minimum of the input raw data values. `Kind` can thus have the value `Average`, `Maximum`, or `Minimum`. The value of `kind` is set to `average` by default.

For a given consolidator, when one `Kind` is changed to another, the historically processed data values become inconsistent with the newer data values being consolidated. Previous consolidated data values for that consolidator are therefore discarded during such a change.

To understand what `Offset` means, the `Maximal samples` of the measurable being consolidated can be considered. This is the maximum number of raw data points that the measurable stores. When this maximum is reached, the oldest data point is removed from the measurable data when a new data point is added. Each removed data point is gathered and used for data consolidation purposes.

For a measurable that adds a new data point every `Interval` seconds, the time  $t_{\text{raw gone}}$ , which is how many seconds into the past the raw data point is removed, is given by:

$$t_{\text{raw gone}} = (\text{Maximal samples})_{\text{measurable}} \times (\text{Interval})_{\text{measurable}}$$

This value is also the default consolidation time, because the consolidated data values are normally presented from  $t_{\text{raw gone}}$  seconds ago, to further into the past. The default consolidation time occurs when the `Offset` has its default, zero value.

If however the `Offset` period is non-zero, then the consolidation time is offset, because the time into the past from which consolidation is presented to the user,  $t_{\text{consolidation}}$ , is then given by:

$$t_{\text{consolidation}} = t_{\text{raw gone}} + \text{Offset}$$

The monitoring visualization graphs then show consolidated data from  $t_{\text{consolidation}}$  seconds into the past, to further into the past<sup>1</sup>.

#### 12.4.4 Monitoring Configuration: Actions

Actions are introduced in section 12.2.6. The `Actions` window (figure 12.17) displays actions that Bright Cluster Manager provides by default, and also displays any custom actions that have been created:

<sup>1</sup> For completeness: the time  $t_{\text{consolidation gone}}$ , which is how many seconds into the past the consolidated data goes and is viewable, is given by an analogous equation to that of the equation defining  $t_{\text{raw gone}}$ :

$$t_{\text{consolidation gone}} = (\text{Maximalsamples})_{\text{consolidation}} \times (\text{Interval})_{\text{consolidation}}$$




Figure 12.17: Bright View Monitoring Configuration: Actions

The `killalives` script from the basic example of section 12.1 would show up here if it has been implemented.

Actions are triggered, by triggers (section 12.4.5).

By default, the following actions exist:

- **Poweron:** Powers on the node
- **PowerOff:** Powers off the node
- **PowerReset:** Hard resets the node
- **Drain:** Drains the node (does not allow new jobs on that node)
- **Undrain:** Undrains the node (allows new jobs on that node)
- **Reboot:** Reboots node via the operating system
- **Shutdown:** Shuts the node down via the operating system
- **ImageUpdate:** Updates the node from the software image
- **Event:** Sends an event to users connected with `cmsh` or Bright View
- **killprocess:** A script to kill a process
- **remount:** A script to remount all devices
- **testaction:** A test script
- **Send e-mail to administrators:** Sends an e-mail out

The preceding actions show their options when the associated `Edit` button is clicked. A subwindow with options opens up. The following options are among those then displayed:

- **Run on:** What nodes the action should run on. Choices are:
  - **active:** the action runs on the active node only
  - **node:** the action runs on the triggering node

- **Allowed time:** The time interval in the 24 hour clock cycle that the action is allowed to start running. The interval can be restricted further to run within certain days of the week, months of the year, or dates of the month. Days and months must be specified in lower case. Monitoring Configuration: Actions: Allowed time Rather than defining a formal syntax, some examples are given, with explanations:
  - `november-march`: November to March. April to October are forbidden.
  - `november-march{monday-saturday}`: As in the preceding, but all Sundays are also forbidden.
  - `november-march{monday-saturday{13:00-17:00}}`: Restricted to the period defined in the preceding example, and with the additional restriction that the action can start running only during the time 13:00-17:00.
  - `09:00-17:00`: All year long, but during 09:00-17:00 only.
  - `monday-friday{9:00-17:00}`: All year long, but during 9:00-17:00 only, and not on Saturdays or Sundays.
  - `november-march{monday-saturday{13:00-17:00}}`: Not in April to October. In the other months, only on Mondays to Saturdays, from 13:00-17:00.
  - `may-september{monday-friday{09:00-18:00};saturday-sunday{13:00-17:00}}`: May to September, with: Monday to Friday 09:00-18:00, and Saturday to Sunday 13:00-17:00.
  - `may{1-31}`: All of May.
  - `may, september{1-15}`: All of May, and only September 1-15.
  - `may, september{1-15{monday-friday}}`: All of May. And only September 1-15 Monday to Friday.

The following action scripts have some additional options:

- **Send e-mail to administrators:** Additional options here are:
  - `info`: the body of the e-mail message
  - `recipients`: a list of recipients
  - `all admins`: uses the list of users in the Administrator e-mail setting in `partition[base] mode`
- **killprocess, and testaction:** Additional options for these are:
  - `arguments`: text that can be used by the script.
  - `script`: The location of the script on the file system.

#### 12.4.5 Monitoring Configuration: Triggers

Triggers are introduced in section 12.2.5. The `Triggers` window (figure 12.18) allows actions (section 12.2.6) to be triggered based on conditions defined by the cluster administrator.




Figure 12.18: Bright View Monitoring Configuration: Triggers

### Change Detection For Triggers

Triggers launch actions by detecting changes in the data of configured measurables. The detection of these changes can happen:

- When a threshold is crossed. That is: the latest sample value means that either the value has entered a zone when it was not in the zone in the preceding sample, or the latest sample means that the value has left a zone when it was in the zone in the preceding sample
- When the zone remains crossed. That is: the latest sample as well as the preceding sample are both within the zone of a crossed threshold.
- When state flapping is detected. This is when the threshold is crossed repeatedly (5 times by default) within a certain time period (5 minutes by default).

The monitoring configuration dialog triggers have four possible action launch configuration options to cover these cases:

1. **Enter actions:** if the sample has entered into the zone and the previous sample was not in the zone. This is a threshold-crossing change.
2. **Leave actions:** if the sample has left the zone and the previous sample was in the zone. This is also a threshold-crossing change.
3. **During actions:** if the sample is in the zone, and the previous sample was also in the zone.
4. **State flapping actions:** if the sample is entering and leaving the zone within a particular period (State flapping period, 5 minutes by default) a set number of times (State flapping count, 5 by default).

### Pre-defined Triggers: Passing, Failing, And Unknown Health Checks

By default, the only triggers that are pre-defined are the following three health check triggers, which use the `Enter` actions launch configuration option, and which have the following default behavior:

- `Failing` health checks: If a health check fails, then on entering the state of the health check failing, an event is triggered as the action, and a severity of 15 is set for that health check.
- `Passing` health checks: If a health check passes, then on entering the state of the health check passing, an event is triggered as the action, and a severity of 0 is set for that health check.
- `Unknown` health checks: If a health check has an unknown response, then on entering the state of the health check returning an unknown response, an event is triggered as the action, and a severity of 10 is set for that health check.

### Adding Custom Triggers: Any Measurable, Any Action

More triggers can be added. The `killallyestrigger` example from the basic example of section 12.1, seen in figures 12.3 and 12.4, is one such example.

Actions are launched from triggers. The action for the trigger can be set to a predefined action or a custom action.

### The Expression Subwindow For A Trigger

Clicking on the `expression` option in `Trigger` window of figure 12.18 opens up the expression sub-window. The expression for the trigger can then be configured by setting the entity, measurable, parameter, comparison operator, and measurable value, as shown in figure 12.19:


Figure 12.19: Bright View Monitoring Configuration: Triggers Expression

The trigger launch is carried out when, during sampling, `CMDaemon` evaluates the expression as being true.

#### 12.4.6 Monitoring Configuration: Health status

The `Health status` window (figure 12.20) displays all the nodes, and summarizes the results of all the health checks that have been run against them over time, by presenting a table of the associated

severity levels (section 12.2.7):




The screenshot shows the Bright View interface with the 'Monitoring Health Overview' window. The left sidebar contains a menu with 'Health status' selected. The main table displays monitoring data for various entities.

ENTITY	MAXIMAL SEVERITY OF ALL ...	TOTAL SEVERITY OF ALL ...	TOTAL COUNT OF A...	OPTIONS
pj-b80dev	15	15	1	Show
node001	0	0	0	Show
node002	0	0	0	Show
node003	0	0	0	Show
node004	0	0	0	Show
node005	0	0	0	Show
westeurope-director	0	0	0	Show
westeurope-cnode001	0	0	0	Show
westeurope-cnode002	0	0	0	Show

Figure 12.20: Bright View Monitoring Configuration: Health Status

In the example shown in figure 12.20 the first entity shows a severity issue, while the other devices are fine. Details of the individual health checks per node can be viewed in a subwindow using the Show button for a node.

Clicking on the Show button for the first entity in this example opens up a subwindow (figure 12.21). For this example the issue turns out to be due to an UNKNOWN status in the ssh2node measurable.




The screenshot shows the 'Monitoring Health Overview' subwindow for the entity 'pj-b80dev'. The table lists individual health checks for this entity.

ENTITY	MEASURABLE	TYPE	STATUS	FROM	TO
pj-b80dev	ssh2node	Network	UNKNOWN	Wednesday, May 2...	Friday, June 30, 201...
pj-b80dev	dmesg	OS	PASS	Wednesday, May 2...	Friday, June 30, 201...
pj-b80dev	ib	OS	PASS	Wednesday, May 2...	Friday, June 30, 201...
pj-b80dev	interfaces	Network	PASS	Wednesday, May 2...	Friday, June 30, 201...
ni-b80dev	ManagedServicesOk	Internal	PASS	Wednesday, May 2...	Tuesday, June 13, 2...

Figure 12.21: Bright View Monitoring Configuration: Health Status For An Entity

#### 12.4.7 Monitoring Configuration: All Health Checks



The screenshot shows the 'Monitoring Health Checks' window in Bright View. The table lists health checks for all entities.

ENTITY	MEASURABLE	TYPE	STATUS	AGE
bright80	ManagedServicesOk	Internal	PASS	53s
bright80	Mon::Storage	Internal/Monitoring/Sto...	PASS	8m 53s
bright80	chrootprocess	OS	PASS	52s
bright80	cmsh	Internal	PASS	53s
bright80	cpucheck	OS	PASS	22h 8m 53s
bright80	defaultgateway	Network	PASS	52s
bright80	diskname	Disk	PASS	53s

Figure 12.22: Bright View Monitoring Configuration: All Health Checks For All Entities

The All Health checks window shows all the running health checks for all entities. If the filtering-by-column option at the top of the column for the node is used to show the results for that node only, then the results are similar to what the Show button for a node produces in section 12.4.6, figure 12.21.

#### 12.4.8 Monitoring Configuration: Standalone Monitored Entities

The Standalone Monitored Entities window allows the cluster administrator to define a standalone entity. A standalone entity is one that is not managed by Bright Cluster Manager—which means that no CMDaemon is running on it to gather data and for managing it—but the entity can still be monitored. For example, a workstation that is running the Bright View browser could be the standalone entity. This could have its connectivity monitored by pinging it from the head node with a custom script.

### 12.5 The monitoring Mode Of cmsh

This section covers how to use cmsh to configure monitoring. The monitoring mode in cmsh corresponds generally to the Monitoring Configuration resource of Bright View in section 12.4. Similarly to how monitoring subwindows are accessed in Bright View, the monitoring mode of cmsh is itself is not used directly, except as a way to access the monitoring configuration submodes of cmsh.

For this section some familiarity is assumed with handling of objects as described in the introduction to working with objects (section 2.5.3). When using cmsh's monitoring mode, the properties of objects in the submodes are how monitoring settings are carried out.

The monitoring mode of cmsh gives access to 5 modes under it:

#### Example

```
[root@myheadnode ~]# cmsh
[myheadnode]% monitoring help | tail -6
===== Monitoring =====
action ..... Enter action mode
consolidator ..... Enter consolidator mode
measurable ..... Enter measurable mode
setup ..... Enter monitoring configuration setup mode
standalone ..... Enter standalone entity mode
trigger ..... Enter trigger mode
```

For convenience, a tree for monitoring submodes is shown in figure 12.23.




Figure 12.23: Submodes Under monitoring Mode

Sections 12.5.1–12.5.6 give examples of how objects are handled under these monitoring modes. To avoid repeating similar descriptions, section 12.5.1 is relatively detailed, and is often referred to by the other sections.

### 12.5.1 The `action` Submode

The `action` submode under the `monitoring` mode of `cmsh` allows monitoring actions to be configured. This mode in `cmsh` corresponds to the Bright View clickpath:

```
Monitoring Configuration→Actions
```

described earlier in section 12.4.4:

The `action` mode handles action objects in the way described in the introduction to working with objects (section 2.5.3). A typical reason to handle action objects—the properties associated with an action script or action built-in—might be to view the actions available, or to add a custom action for use by, for example, a metric or health check.

Some examples of how the `action` mode is used are now give.

#### The `action` Submode: `list`, `show`, And `get`

The `list` command by default lists the names and properties of actions available from `action` mode in a table:

#### Example

```
[myheadnode]% monitoring action
[myheadnode->monitoring->action]% list
```

Type	Name (key)	Run on	Action
DrainAction	Drain	Active	Drain node from all WLM
EmailAction	Send e-mail to	Active	Send e-mail



	administrator		
EventAction	Event	Active	Send an event to users with connected client
ImageUpdateAction	ImageUpdate	Active	Update the image on the node
PowerOffAction	PowerOff	Active	Power off a device
PowerOnAction	PowerOn	Active	Power on a device
PowerResetAction	PowerReset	Active	Power reset a device
RebootAction	Reboot	Node	Reboot a node
ScriptAction	killprocess	Node	/cm/local/apps/cmd/scripts/actions/killprocess.pl
ScriptAction	remount	Node	/cm/local/apps/cmd/scripts/actions/remount
ScriptAction	testaction	Node	/cm/local/apps/cmd/scripts/actions/testaction
ShutdownAction	Shutdown	Node	Shutdown a node
UndrainAction	Undrain	Active	Undrain node from all WLM

The preceding shows the actions available on a newly installed system.

The show command of cmsh displays the individual parameters and values of a specified action:

### Example

```
[myheadnode->monitoring->action]% show poweroff
Parameter                               Value
-----
Action                                 Power off a device
Allowed time
Disable                                no
Name                                   PowerOff
Revision
Run on                                 Active
Type                                   PowerOffAction
```

Instead of using list, a convenient way to view the possible actions is to use the show command with tab-completion suggestions:

### Example

```
[myheadnode->monitoring->action]% show<TAB><TAB>
drain      killprocess  powerreset  send\ e-mail\ to\ administrators  undrain
event      poweroff      reboot      shutdown
imageupdate poweron          remount      testaction
```

The get command returns the value of an individual parameter of the action object:

### Example

```
[myheadnode->monitoring->action]% get poweroff runon
active
```

**The action Submode:** add, use, remove, commit, refresh, modified, set, clear, **And** validate  
In the basic example of section 12.1, in section 12.1.2, the killallyes action was cloned from a similar script using a clone option in Bright View.

The equivalent can be done with a clone command in cmsh. However, using the add command instead, while it requires more steps, makes it clearer what is going on. This section therefore covers adding the killallyes script of section 12.1.2 using the add command.

When add is used: an object is added, the object is made the current object, and the name of the object is set, all at the same time. After that, set can be used to set values for the parameters within the object, such as a path for the value of the parameter command.

Adding an action requires that the type of action be defined. Just as tab-completion with `show` comes up with action suggestions, in the same way, using tab-completion with `add` comes up with type suggestions.

Running the command `help add` in the action mode also lists the possible types. These types are `drain`, `e-mail`, `event`, `imageupdate`, `poweroff`, `poweron`, `powerreset`, `reboot`, `script`, `servicerestart`, `servicestart`, `servicestop`, `shutdown`, `undrain`.

The syntax for the `add` command takes the form:

```
add <type> <action>
```

If there is no `killallyes` action already, then the name is added in the action mode with the `add` command, and the `script` type, as follows:

### Example

```
[myheadnode->monitoring->action]% add script killallyes
[myheadnode->monitoring->action*[killallyes*]]%
```

Using the `add` command drops the administrator into the `killallyes` object level, where its properties can be set. A successful commit means that the action is stored in `CMDaemon`.

The converse to the `add` command is the `remove` command, which removes an action that has had the `commit` command successfully run on it.

The `refresh` command can be run from outside the object level, and it removes the action if it has not yet been committed.

The `use` command is the usual way of "using" an object, where "using" means that the object being used is referred to by default by any command run. So if the `killallyes` object already exists, then `use killallyes` drops into the context of an already existing object (i.e. it "uses" the object).

The `set` command sets the value of each individual parameter displayed by a `show` command for that action. The individual parameter `script` can thus be set to the path of the `killallyes` script:

### Example

```
[...oring->action*[killallyes*]]% set script /cm/local/apps/cmd/scripts/actions/killallyes
```

The `clear` command can be used to clear the value that has been set for `script`.

The `validate` command checks if the object has all required values set to sensible values. So, for example, `commit` only succeeds if the `killallyes` object passes validation.

Validation does not check if the script itself exists. It only does a sanity check on the values of the parameters of the object, which is another matter. If the `killallyes` script does not yet exist in the location given by the parameter, it can be created as suggested in the basic example of section 12.1, in section 12.1.2. In the basic example used in this chapter, the script is run only on the head node. If it were to run on regular nodes, then the script should be copied into the disk image.

The `modified` command lists changes that have not yet been committed.

## 12.5.2 The `consolidator` Submode

The `consolidator` mode of `cmsh` allows consolidators to be managed, and is the equivalent of the `consolidators` window (section 12.4.3) in Bright View.

The `consolidator` mode deals with groups of consolidators. One such group is `default`, and the other is `none`, as discussed earlier in section 12.4.3:

```
[bright80->monitoring->consolidator]% list
Name (key)           Consolidators
-----
default              hour, day, week
none                 <0 in submode>
```

Each `consolidators` entry can have its parameters accessed and adjusted.  
For example, the parameters can be viewed with:

### Example

```
[bright80->monitoring->consolidator]% use default
[bright80->monitoring->consolidator[default]]% show
Parameter                                Value
-----
Consolidators                            hour, day, week
Name                                     default
Revision
[bright80->monitoring->consolidator[default]]% consolidators
[bright80->monitoring->consolidator[default]->consolidators]% list
Name (key)                               Interval
-----
day                                       1d
hour                                    1h
week                                    1w
[bright80->monitoring->consolidator[default]->consolidators]% use day
[bright80->monitoring->consolidator[default]->consolidators[day]]% show
Parameter                                Value
-----
Interval                                1d
Kind                                    AVERAGE
Maximal age                             0s
Maximal samples                          4096
Name                                     day
Offset                                   0s
Revision
[bright80->monitoring->consolidator[default]->consolidators[day]]%
```

For the day consolidator shown in the preceding example, the number of samples saved per day can be doubled with:

### Example

```
[bright80->monitoring->consolidator[default]->consolidators[day]]% set maximalsamples 8192
[bright80->monitoring->consolidator*[default*]->consolidators*[day*]]% commit
```

Previously consolidated data is discarded with this type of change, if the number of samples is reduced. Changing parameters should therefore be done with some care.

A new `consolidators` group can be created if needed.

A Bright View way, where a `decimalminutes` group is created, is discussed in the example in section 12.4.3, page 438.

A `cmsh` way, where a `max-per-day` group is created, is discussed in the following section:

### Creation Of A Consolidator In cmsh

A new consolidator group, `max-per-day`, can be added to the default consolidator groups of `default` and `none`, with:

### Example

```
[bright80]% monitoring consolidator
[bright80->monitoring->consolidator]% add max-per-day
[... [max-per-day*]]%
```

Within this new group, a new consolidator item, `max-per-day` can also be defined. The item can be defined so that it only calculates the maximum value per day, using the `kind` setting. Another setting is `interval`, which defines the interval with which the old data is compressed:

### Example

```
[...[max-per-day*]]% consolidators
[...[max-per-day*]->consolidators]% add max-per-day
[...[max-per-day*]]% set interval 1d
[...[max-per-day*]]% set kind maximum
[...[max-per-day*]]% show
Parameter          Value
-----
Interval           1d
Kind                maximum
Maximal age         0s
Maximal samples     4096
Name                max-per-day
Offset              0s
Revision
[...[max-per-day*]]% commit
```

### 12.5.3 The measurable Submode

The `measurable` submode under the `monitoring` mode of `cmsh` handles measurable objects, that is: metrics, health checks, and enummetrics. This mode corresponds to the Bright View clickpath:

Monitoring Configuration→Measurables

covered earlier in section 12.4.2.

Measurable objects represent the configuration of scripts or built-ins. The properties of the objects are handled in `cmsh` in the way described in the introduction to working with objects (section 2.5.3).

A typical reason to handle measurable objects might be to view the measurables already available, or to remove a measurable that is in use by an entity.

Measurables cannot be added from this mode. To add a measurable, its associated data producer must be added from `monitoring setup` mode (section 12.5.4).

This section goes through a `cmsh` session giving some examples of how this mode is used.

**The measurable Submode:** `list`, `show`, `And` `get`

In `measurable` mode, the `list` command by default lists the names of all measurable objects along with parameters, their class, and data producer.

### Example

```
[bright80->monitoring->measurable]% list
```

type	name (key)	parameter	class	producer
Enum	DeviceStatus		Internal	DeviceState
HealthCheck	ManagedServicesOk		Internal	CMDaemonState
HealthCheck	Mon::Storage		Internal/Monitoring/Storage	MonitoringSystem
Metric	nfs_v3_server_total		Disk	NFS
Metric	nfs_v3_server_write		Disk	NFS
...				

The above example illustrates a list with some of the measurables that can be set for sampling on a newly installed system. A full list typically contains over two hundred items.

The `list` command in `measurable` submode can be run as:

- `list metric`: to display only metrics
- `list healthcheck`: to display only health checks
- `list enum`: to display only enummetrics

The `show` command of the measurable submode of monitoring mode displays the parameters and values of a specified measurable, such as, for example `CPUUser`, `devicestatus`, or `diskspace`:

### Example

#### Example

```
[myheadnode->monitoring->measurable]% show cpuuser
Parameter      Value
-----
Class          CPU
Consolidator    default (ProcStat)
Cumulative      yes
Description     CPU time spent in user mode
Disabled        no (ProcStat)
Gap             0 (ProcStat)
Maximal age     0s (ProcStat)
Maximal samples 4,096 (ProcStat)
Maximum         0
Minimum         0
Name            CPUUser
Parameter
Producer        ProcStat
Revision
Type            Metric
Unit            Jiffies
[myheadnode->monitoring->measurable]% show devicestatus
Parameter      Value
-----
Class          Internal
Consolidator    none
Description     The device status
Disabled        no (DeviceState)
Gap             0 (DeviceState)
Maximal age     0s (DeviceState)
Maximal samples 4,096 (DeviceState)
Name            DeviceStatus
Parameter
Producer        DeviceState
Revision
Type            Enum
[myheadnode->monitoring->measurable]% show diskspace
Parameter      Value
-----
Class          Disk
Consolidator    - (diskspace)
Description     checks free disk space
Disabled        no (diskspace)
Gap             0 (diskspace)
Maximal age     0s (diskspace)
Maximal samples 4,096 (diskspace)
```

Name	diskspace
Parameter	
Producer	diskspace
Revision	
Type	HealthCheck

The Gap setting here is a number. It sets how many samples are allowed to be missed before a value of NaN is set for the value of the metric.

As detailed in section 12.5.1, tab-completion suggestions for the `show` command suggest the names of objects that can be used, with the `use` command in this mode. For `show` in `measurable` mode, tab-completion suggestions suggests over 200 possible objects:

### Example

```
[bright80->monitoring->measurable]% show
Display all 221 possibilities? (y or n)
alertlevel:count      iotime:vda          mon::storage::engine::elements  oomkiller
alertlevel:maximum    iotime:vdb          mon::storage::engine::size      opalinkhealth
alertlevel:sum         ipforwdatagrams     mon::storage::engine::usage     packetsrecv:eth0
blockedprocesses      ipfragcreates       mon::storage::message::elements packetsrecv:eth1
buffermemory          ipfragfails         mon::storage::message::size     packetssent:eth0
bytesrecv:eth0        ipfragoks           mon::storage::message::usage    packetssent:eth1
...
```

The single colon (":") indicates an extra parameter for that measurable.

Because there are a large number of metrics, it means that grepping a metrics list is sometimes handy.

When listing and grepping, it is usually a good idea to allow for case, and be aware of the existence of the parameter column. For example, the `AlertLevel` metric shown in the first lines of the tab-completion suggestions of the `show` command of the previous example, shows up as `alertlevel`. However the `list` command displays it as `AlertLevel`. There are also several parameters associated with the `AlertLevel` command. So using the case-insensitive `-i` option of `grep`, and using the `head` command to display the headers is handy:

### Example

```
[bright80->monitoring->measurable]% list | head -2 ; list metric | grep -i alertlevel
type      name (key)      parameter  class      producer
-----
Metric    AlertLevel      count      Internal   AlertLevel
Metric    AlertLevel      maximum    Internal   AlertLevel
Metric    AlertLevel      sum        Internal   AlertLevel
```

The `get` command returns the value of an individual parameter of a particular health check object:

### Example

```
[myheadnode->monitoring->measurable]% get oomkiller description
Checks whether oomkiller has come into action (then this check returns FAIL)
[myheadnode->monitoring->measurable]%
```

### The measurable Submode: The has Command

The `has` command is used with a measurable to list the entities that use the measurable. Typically these are nodes, but it can also be other entities, such as the `base` partition.

### Example

```
[bright80->monitoring->measurable]% has alertlevel:sum
bright80
node001
node002
[bright80->monitoring->measurable]% use devicesup
[bright80->monitoring->measurable[DevicesUp]]% has
base
```

The remaining commands in measurable mode, such as use, remove, commit, refresh, modified, set, clear, and validate; all work as outlined in the introduction to working with objects (section 2.5.3). More detailed usage examples of these commands within a monitoring mode are given in the earlier section covering the action submode (section 12.5.1).

### The measurable Submode: An Example Session On Viewing And Configuring A Measurable

A typical reason to look at metrics and health check objects—the properties associated with the script or built-in—might be, for example, to view the operating sampling configuration for an entity.

This section goes through a cmsh session giving an example of viewing and configuring a health check from the measurable submode, under monitoring mode.

In the basic example of section 12.1, a trigger was set up from Bright View to check if the CPUUser metric was above 50 jiffies, and if so, to launch an action.

A functionally equivalent task can be set up by creating and configuring a health check, because metrics and health checks are so similar in concept. This is done here to illustrate how cmsh can be used to do something similar to what was done with Bright View in the basic example. A start is made on the task by creating a health check data producer, and configuring its measurable properties. using the setup mode under the monitoring mode of cmsh. The task is completed in the section on the setup mode in section 12.5.4.

To start the task, cmsh's add command is used, and the type is specified, to create the new object:

#### Example

```
[root@myheadnode ~]# cmsh
[myheadnode]% monitoring setup
[myheadnode->monitoring->setup]% add healthcheck cpucheck
[myheadnode->monitoring->setup*[cpucheck*]]%
```

The show command shows the parameters.

The values for description, runinbash, script, and class should be set:

#### Example

```
[...->setup*[cpucheck*]]% set script /cm/local/apps/cmd/scripts/healthchecks/cpucheck
[...->setup*[cpucheck*]]% set description "CPUUser under 50%?"
[...->setup*[cpucheck*]]% set runinbash yes
[...->setup*[cpucheck*]]% set class OS
[...->setup*[cpucheck*]]% commit
[myheadnode->monitoring->setup[cpucheck]]%
```

On running commit, the data producer cpucheck is created, and a measurable cpucheck is also created:

#### Example

```
[myheadnode->monitoring->setup[cpucheck]]% exit; exit
[myheadnode->monitoring]% setup list | grep -i cpucheck
HealthCheckScript      cpucheck          1 / 222      <0 in submode>
[myheadnode->monitoring]% measurable list | grep -i cpucheck
HealthCheck  cpucheck          OS          cpucheck
```

Since the `cpucheck` script does not yet exist in the location given by the parameter `script`, it needs to be created. One ugly bash script that can do a health check is:

```
#!/bin/bash

## echo PASS if CPUUser < 50
## cpu is a %, ie: between 0 and 100

cpu=`mpstat 1 1 | tail -1 | awk '{print $3}'`
comparisonstring="$cpu" < 50

if (( $(bc <<< "$comparisonstring") )); then
    echo PASS
else
    echo FAIL
fi
```

The script should be placed in the location suggested by the object, `/cm/local/apps/cmd/scripts/healthchecks/cpucheck`, and made executable with a `chmod 700`.

The `cpucheck` object is handled further within the `cmsh` monitoring setup mode in section 12.5.4 to produce a fully configured health check.

#### 12.5.4 The setup Submode

##### The setup Submode: Introduction

The setup submode under the monitoring mode of `cmsh` allows access to all the data producers. This mode in `cmsh` corresponds to the Bright View clickpath:

Monitoring Configuration→Data Producers

covered earlier in section 12.4.1.

##### The setup Submode: Data Producers And Their Associated Measurables

The list of data producers in setup mode should not be confused with the list of measurables in measurable mode. Data producers are not the same as measurables. Data producers produce measurables, although it is true that the measurables are often named the same as, or similar to, their data producer.

In `cmsh`, data producers are in the `Name (key)` column when the `list` command is run from the setup submode:

##### Example

```
[bright80->monitoring->setup]% list
```

Type	Name (key)	Arguments	Measurables	Node execution filters
AggregateNode	AggregateNode		8 / 222	<1 in submode>
AlertLevel	AlertLevel		3 / 222	<1 in submode>
CMDaemonState	CMDaemonState		1 / 222	<0 in submode>
ClusterTotal	ClusterTotal		18 / 222	<1 in submode>
Collection	BigDataTools		0 / 222	<2 in submode>
Collection	Cassandra		0 / 222	<1 in submode>
...				

In the preceding example, the `AlertLevel` data producer has 3 / 222 as the value for measurables. This means that this `AlertLevel` data producer provides 3 measurables out of the 222 configured measurables. They may be enabled or disabled, depending on whether the data producer is enabled or disabled, but they are provided in any case.



To clarify this point: if the `list` command is run from `setup` mode to list producers, then the producers that have configured measurables are the ones that have 1 or more as the numerator value in the Measurables column. Conversely, the data producers with 0 in the numerator of the Measurables column have no configured measurables, whether enabled or disabled, and are effectively just placeholders until the software for the data producers is installed.

So, comparing the list of producers in `setup` mode with the measurables in `measurable` mode:

### Example

In `measurable` mode, the three `AlertLevel` measurables (the 3 out of 222) produced by the `AlertLevel` producer can be seen with:

```
[bright80->monitoring->measurable]% list | head -2; list | grep AlertLevel
```

Type	Name (key)	Parameter	Class	Producer
Metric	AlertLevel	count	Internal	AlertLevel
Metric	AlertLevel	maximum	Internal	AlertLevel
Metric	AlertLevel	sum	Internal	AlertLevel

On the other hand, in `measurable` mode, there are no measurables seen for `BigDataTools` (the 0 out of 222) produced by the `BigDataTools` producer, when running, for example: `list | head -2; list | grep BigDataTools`.

### The setup Submode: Listing Nodes That Use A Data Producer

The `nodes` command can be used to list the nodes on which a data producer *<data producer>* runs. It is run in the `setup` submode level of the `monitoring` mode as:

```
nodes <data producer>
```

### Example

```
[bright80->monitoring->setup]% list | head -2; list | grep mount
```

Type	Name (key)	Arguments	Measurables	Node execution filters
HealthCheckScript	mounts		1 / 229	<0 in submode>

```
[bright80->monitoring->setup]% nodes mounts
node001..node003,bright80
```

### The setup Submode: Data Producers Properties

Any data producer from the full list in `setup` mode can, if suitable, be used to provide a measurable for any entity.

An example is the data producer `AlertLevel`. Its properties can be seen using the `show` command:

### Example

```
[bright80->monitoring->setup]% show alertlevel
```

Parameter	Value
Automatic reinitialize	yes
Consolidator	default
Description	Alert level as function of all trigger severities
Disabled	no
Execution multiplexer	<1 in submode>
Fuzzy offset	0
Gap	0
Interval	2m

Maximal age	0s
Maximal samples	4096
Measurables	3 / 222
Name	AlertLevel
Node execution filters	<1 in submode>
Notes	<0 bytes>
Offset	1m
Only when idle	no
Revision	
Type	AlertLevel
When	Timed

These properties are described in section 12.4.1. Most of these properties are inherited by the measurables associated with the data producer, which in the `AlertLevel` data producer case are `alertlevel:count`, `alertlevel:maximum`, and `alertlevel:sum`.

### The setup Submode: Deeper Submodes

One level under the `setup` submode of monitoring mode are 3 further submodes (modes deeper than submodes are normally also just called submodes for convenience, rather than sub-submodes):

- `nodeexecutionfilters`
- `executionmultiplexers`
- `jobmetricsettings`

**Node execution filters:** A way to filter execution (restrict execution) of the data producer. If not set, then the data producer runs on all nodes managed by `CMDaemon`. Filters can be for nodes, types, overlays, resources, and categories.

Running the `nodes` command for a data producer lists which nodes the execution of the data producer is run on.

### Example

```
[myhost->monitoring->setup]% nodes procmeminfo
mon001..mon003,myhost,osd001,osd002,node001,node002
[myhost->monitoring->setup]% nodes ssh2node
myhost
```

Restricting a data producer, such as `rogueprocess` (page 664), to run on a particular list of nodes can be carried out as follows on a cluster that is originally in its default state:

### Example

```
[bright80->monitoring->setup[rogueprocess]]% nodeexecutionfilters
[bright80->monitoring->setup[rogueprocess]->nodeexecutionfilters]% add<TAB><TAB>
category lua      node      overlay  resource type
[...tup[rogueprocess]->nodeexecutionfilters]% add node justthese
[...tup*[rogueprocess*]->nodeexecutionfilters*[justthese*]]% show
Parameter          Value
-----
Filter operation     Include
Name                 justthese
Nodes
Revision
Type                 Node
```

```
[...tup*[rogueprocess*]->nodeexecutionfilters*[justthese*]]% set nodes node001,node002
[...tup*[rogueprocess*]->nodeexecutionfilters*[justthese*]]% show
Parameter                                Value
-----
Filter operation                         Include
Name                                    justthese
Nodes                                    node001,node002
Revision
Type                                    Node
[...tup*[rogueprocess*]->nodeexecutionfilters*[justthese*]]% commit
```

This way, the `rogueprocess` health check runs on just those nodes (node001, node002), and none of the others.

A data producer can also be set up so that it is run on a particular list of nodes filtered by resource. An example of where setting this kind of thing up is useful, is for nodes associated with the active head resource. Most data producers that are used by the cluster run on an active head node. Thus, for example, the `cpucheck` healthcheck from page 453 can be restricted to run on the active head node only, by setting the node execution filter to the resource value `Active`, as follows:

### Example

```
[bright80->monitoring->setup[cpucheck]]% nodeexecutionfilters
[bright80->monitoring->setup[cpucheck]->nodeexecutionfilters]% add<TAB><TAB>
category lua      node      overlay resource type
[...tup[cpucheck]->nodeexecutionfilters]% add resource
[...tup[cpucheck]->nodeexecutionfilters]% add resource "Active head node"
[...tup*[cpucheck*]->nodeexecutionfilters*[Active head node*]]% show
Parameter                                Value
-----
Filter
Name                                    Active head node
Operator                                OR
Resources
Revision
Type                                    MonitoringResourceExecutionFilter
[...tup*[cpucheck*]->nodeexecutionfilters*[Active head node*]]% set resources Active
[...tup*[cpucheck*]->nodeexecutionfilters*[Active head node*]]% show
Parameter                                Value
-----
Filter
Name                                    Active head node
Operator                                OR
Resources                                Active
Revision
Type                                    MonitoringResourceExecutionFilter
[...tup*[cpucheck*]->nodeexecutionfilters*[Active head node*]]% commit
```

**Execution multiplexer:** A way to multiplex execution (have execution work elsewhere) for a data producer. A data producer runs on the entity that it is being executed on, as defined by the node execution filter setting. A data producer can also gather samples from other nodes, types, overlays, and resources. The entities from which it can sample are defined into groups called execution multiplexers. Execution multiplexers can thus be node multiplexers, type multiplexers, overlay multiplexers, or resource multiplexers.

The mode can be entered with:

### Example

```
[bright80->monitoring->setup[cpucheck]]% executionmultiplexers
```

Running the commands: `help add`, or `help set`, can be used to show the valid syntax in this submode.

Most data producers run on a head node, but sample from the regular nodes. So, for example, the `cpucheck` healthcheck from page 453 can be set to sample from the regular nodes by setting to execution multiplexing to nodes of type `Nodes` as follows:

### Example

```
[bright80->monitoring->setup[cpucheck]->executionmultiplexers]% add<TAB><TAB>
lua      resource  type
[bright80->monitoring->setup[cpucheck]->executionmultiplexers]% add type nodes

[bright80->monitoring->setup*[cpucheck*]->executionmultiplexers*[nodes*]]% show
Parameter                                     Value
-----
Name                                           nodes
Revision
Type                                           MonitoringTypeExecutionMultiplexer
Types
[bright80->monitoring->setup*[cpucheck*]->executionmultiplexers*[nodes*]]% set types nodes
[bright80->monitoring->setup*[cpucheck*]->executionmultiplexers*[nodes*]]% show
Parameter                                     Value
-----
Name                                           nodes
Revision
Type                                           MonitoringTypeExecutionMultiplexer
Types                                           Node
[bright80->monitoring->setup*[cpucheck*]->executionmultiplexers*[nodes*]]% commit
```

Nodes now sample `cpucheck` from the regular nodes.

**Job Metrics Settings:** Job metrics settings are a submode for setting job metric collection options for the `JobSampler` data producer (section 12.8.3).

### 12.5.5 The `standalone` Submode

The `standalone` submode under the `monitoring` mode of `cmsh` allows entities that are not managed by Bright Cluster Manager to be configured for monitoring. This mode in `cmsh` corresponds to the Bright View clickpath:

```
Monitoring Configuration->Standalone Monitored Entities
```

covered earlier in section 12.4.8.

The monitoring for such entities has to avoid relying on a `CMDaemon` that is running on the entity. An example might be a chassis that is monitored via a ping script running on the Bright Cluster Manager head node.

### 12.5.6 The `trigger` Submode

The `trigger` submode under the `monitoring` mode of `cmsh` allows actions to be configured according to the result of a measurable.

This mode in `cmsh` corresponds to the Bright View clickpath:

```
Monitoring Configuration->Triggers
```

covered earlier in section 12.4.5.

By default, there are 3 triggers:

### Example

```
[bright80->monitoring->trigger]% list
Name (key)           Expression           Enter actions During actions Leave actions
-----
Failing health checks  (*, *, *) == FAIL    Event
Passing health checks  (*, *, *) == PASS    Event
Unknown health checks  (*, *, *) == UNKNOWN Event
```

Thus, for a passing, failing, or unknown health check, an event action takes place if entering a state change. The default severity level of a passing health check does not affect the AlertLevel value. However, if the failing or unknown health checks are triggered on entering a state change, then these will affect the AlertLevel value.

### The trigger Submode: Setting An Expression

In the basic example of section 12.1, a trigger to run the `killallyes` script was configured using Bright View.

The expression that was set for the `killallyes` script in the basic example using Bright View can also be set in `cmsh`. For example:

### Example

```
[bright80->monitoring->trigger]% add killallyestrigger
[bright80->monitoring->trigger*[killallyestrigger*]]% show
Parameter           Value
-----
Disabled             no
During actions
Enter actions
Leave actions
Mark entity as failed  yes
Mark entity as unknown no
Name                 killallyestrigger
Revision
Severity             10
State flapping actions
State flapping count   5
State flapping period  5m
expression            (*, *, *) == FAIL
[bright80->monitoring->trigger*[killallyestrigger*]]% expression
[bright80->monitoring->trigger*[killallyestrigger*]->expression[]% show
Parameter           Value
-----
Entities
Measurables
Name
Operator             EQ
Parameters
Revision
Type                 MonitoringCompareExpression
Use raw              no
Value                FAIL
```

```
[bright80->monitoring->trigger*[killallyesttrigger*]->expression[]]% set entities bright80
[bright80->monitoring->trigger*[killallyesttrigger*]->expression*[]]% set measurables CPUUser
[bright80->monitoring->trigger*[killallyesttrigger*]->expression*[]]% set operator GT
[bright80->monitoring->trigger*[killallyesttrigger*]->expression*[]]% set value 50
[bright80->monitoring->trigger*[killallyesttrigger*]->expression*[]]% commit
[bright80->monitoring->trigger*[killallyesttrigger*]->expression*[]]% set name killallyesregex
Field                                Message
-----
actions                               Warning: No actions were set
===== killallyesttrigger =====
[bright80->monitoring->trigger[killallyesttrigger]->expression[killallyesregex]]% exit
[bright80->monitoring->trigger[killallyesttrigger]->expression]% exit
[bright80->monitoring->trigger[killallyesttrigger]]% set enteractions killallyesname
[bright80->monitoring->trigger*[killallyesttrigger*]]% commit
[bright80->monitoring->trigger[killallyesttrigger]]%
```

The expression format is shown in `cmsh` as:

(<entity>, <measurable>, <parameter>) <comparison operator> <value>

Here:

- an entity, as described in section 12.2.1, can be, for example, a node, category, device, or software image. To include more than one entity for the comparison, the alternation (pipe, |) symbol can be used, with double quotes to enclose the expression.

### Example

```
...[killallyesttrigger*]->expression[]]% set entities "bright80|node001|compute|gpuimage"
```

In the preceding example, the entity `compute` could be a category, and the entity `gpuimage` could be a software image.

- a measurable (section 12.2.1) can be a health check, a metric, or an enumetric. For example: `CPUUsage`. Alternation works for <measurable> in a similar way to that for <entity>.
- a parameter is a further option to a measurable. For example, the `FreeSpace` metric can take a mount point as a parameter. Alternation works for <parameter> in a similar way to that for <entity>.
- the comparison operator can be:
  - EQ: equivalent to, displayed as ==
  - NE: not equivalent to, displayed as !=
  - GT: greater than, displayed as >
  - LT: less than, displayed as <

If the user uses an arithmetic symbol such as `>` in `cmsh` as an unescaped entry, then the entry may unintentionally be interpreted by the shell. That is why the two-letter entries are used instead for entry, even though when displayed they display like the arithmetic symbols for easier recognition.

- the value can be a string, or a number.

The regex evaluates to `TRUE` or `FALSE`. The trigger runs its associated action in the case of `TRUE`.

The wildcard `*` implies any entity, measurable, or parameter when used with the appropriate position according to the syntax of the expression format.

Using `.` `*` is also possible to match zero or more of any characters.

Some further expression matching examples:

### Example

True for any failing health check:

```
(*, *, *) == FAILED
```

### Example

True for any nearly full local disk (less than 10MB left):

```
(*, FreeSpace, sd[a-z]) < 10MB
```

### Example

True for any cloud node that is too expensive (price more than more than 10\$):

```
(.*cnode.*, Price, *) > 10$
```

At the end of section 12.5.3 a script called `cpucheck` was built. This script was part of a task to use health checks instead of metrics to set up the functional equivalent of the behavior of the basic example of section 12.1. In this section the task is continued and completed as follows:

```
[bright80->monitoring->trigger]% expression killallyestrigger
[...trigger[killallyestrigger]->expression[killallyesregex]]% get measurables
CPUUser
[...trigger[killallyestrigger]->expression[killallyesregex]]% set measurables cpucheck
[...trigger*[killallyestrigger*]->expression*[killallyesregex*]]% commit
```

## 12.6 Obtaining Monitoring Data Values

The monitoring data values that are logged by devices can be used to generate graphs using the methods in section 12.3. However, sometimes an administrator would like to have the data values that generate the graphs instead, perhaps to import them into a spreadsheet for further direct manipulation, or to pipe them into a utility such as `gnuplot`.

### 12.6.1 Getting The List Of Measurables For An Entity: The `measurables`, `metrics`, `healthchecks` And `enummetrics` Commands

The measurables for a specified entity can be seen with the `measurables` command, and the measurable subtypes can be seen with the corresponding measurable subset commands: `metrics`, `healthchecks` and `enummetrics`. The results look quite similar to the results of the measurable submode of the `monitoring` mode (section 12.5.3). However, for entities, the measurables are a sublist of the full number of measurables listed in the `measurable` submode, which in turn are only the list of measurables for the data producers that have been enabled.

For example, within `device` mode where the entities are typically the head node and regular nodes, running `metrics` with a specified entity shows only the metrics that are configured for that entity. Thus if the entity is a head node, then only head node metrics are shown; and if the entity is a regular node, only regular node metrics are shown:

### Example

```
[bright80->device]% enummetrics node001
```

Type	Name	Parameter	Class	Producer
Enum	DeviceStatus		Internal	DeviceState

```
[bright80->device]% use bright80
[bright80->device[bright80]]% measurables
```

Type	Name	Parameter	Class	Producer
Enum	DeviceStatus		Internal	DeviceState
HealthCheck	ManagedServicesOk		Internal	CMDaemonState
HealthCheck	Mon::Storage		Internal/Monitoring/Storage	MonitoringSystem
...				

```
[bright80->device[bright80]]% exit
[bright80->device]% metrics node001
```

Type	Name	Parameter	Class	Producer
Metric	AlertLevel	count	Internal	AlertLevel
Metric	AlertLevel	maximum	Internal	AlertLevel
Metric	AlertLevel	sum	Internal	AlertLevel
Metric	BlockedProcesses		OS	ProcStat
...				

Typically the number of metrics listed on the head node will differ from those listed on a regular node. Whatever each number is, it cannot be more than the number of metrics seen in the number of metrics listed in the `measurable` submode of section 12.5.3.

The preceding example shows the measurables listing commands being carried out on head nodes and regular nodes. These commands can be used on other entities too. For example, the base partition in partition mode, where the measurables can be listed with:

### Example

```
[bright80->device]% partition use base
[bright80->partition[base]]% measurables
```

Type	Name	Parameter	Class	Producer
Metric	CoresTotal		Total	ClusterTotal
Metric	CoresUp		Total	ClusterTotal
Metric	DevicesClosed		Total	ClusterTotal
Metric	DevicesDown		Total	ClusterTotal
...				

The values for metric samples and health checks can be obtained from within device mode in various ways, and are explained next.

## 12.6.2 On-Demand Metric Sampling And Health Checks

### The `samplenow` Command For On-Demand Measurable Samples

An administrator can do live sampling, or sampling on-demand, for specified entities by using the `samplenow` command. The command has the following syntax:

```
samplenow [OPTIONS] [<entity>] [<measurable> ...]
```

The command can be run without options when an entity object, such as a node is used (output truncated):

### Example



```
[bright80->device]% use bright80
[bright80->device[bright80]]% samplenow
```

Measurable	Parameter	Type	Value	Age	Info
AlertLevel	count	Internal	0	2.01s	
AlertLevel	maximum	Internal	0	2.01s	
AlertLevel	sum	Internal	0	2.01s	
BlockedProcesses		OS	0 processes	2.01s	
BufferMemory		Memory	847 KiB	2.01s	
...					

The entity used can also be in other modes that have measurables, such as the base partition (output truncated):

### Example

```
[bright80->device]% partition use base
[bright80->partition[base]]% samplenow
```

Measurable	Parameter	Type	Value	Age	Info
CoresTotal		Total	24	0.001s	
CoresUp		Total	24	0.001s	
DevicesClosed		Total	0	0.001s	
DevicesDown		Total	0	0.001s	
DevicesTotal		Total	0	0.001s	
DevicesUp		Total	0	0.001s	
...					

### The `-n|--nodes` Option

The `-n` option is used to sample specified nodes or node ranges:

### Example

```
[bright80->partition[base]]% device
[bright80->device]% samplenow -n node001..node002 loadone
```

Entity	Measurable	Parameter	Type	Value	Age	Info
node001	LoadOne		OS	0.04	0.08s	
node002	LoadOne		OS	0	0.077s	

### The `--metrics` And `--checks` Option

For a particular entity:

- All metrics can be sampled on demand with the `--metrics` option
- All health checks can be sampled on demand with the `--checks` option

### Example

```
[bright80->device]% samplenow --metrics loadone loadfifteen --n node001,node002
```

Entity	Measurable	Parameter	Type	Value	Age	Info
node001	LoadOne		OS	0.04	0.08s	
node002	LoadOne		OS	0	0.077s	

```
[bright80->device]% samplenow --checks -n node001..node002
```

Entity	Measurable	Parameter	Type	Value	Age	Info
node001	ManagedServicesOk		Internal	PASS	0.177s	

```

node001      defaultgateway      Network  PASS    0.145s
node001      diskspace           Disk     PASS    0.16s
node001      dmesg              OS       PASS    0.177s
[bright80->device]% samplenow --checks diskspace -n node001..node002
Entity      Measurable      Parameter Type      Value      Age      Info
-----
node001      diskspace           Disk     PASS    0.095s
node002      diskspace           Disk     PASS    0.097s
[bright80->device]%

```

### The `-s|--status` Option

Nodes in device mode which have a status of UP, as seen by the status command, can be sampled with the `-s|--status` option:

### Example

```

[bright80->device]% samplenow -s UP
Entity      Measurable      Parameter Type      Value      Age      Info
-----
bright80    AlertLevel      count      Internal  0          4.67s
bright80    AlertLevel      maximum    Internal  0          4.67s
bright80    AlertLevel      sum        Internal  0          4.67s
bright80    BlockedProcesses OS          0 processes 4.67s
bright80    BufferMemory     Memory     847 KiB   4.67s
bright80    BytesRecv       eth0       Network   357 MiB   4.67s
bright80    BytesRecv       eth1       Network   78.7 MiB  4.67s
...

```

The preceding example is truncated because it is quite lengthy. However, on the screen, for the device mode, it shows all the sample values for the measurables for all the entities—head node and regular nodes—that are up.

To restrict the results to node001 only, it can be run as:

### Example

```

[bright80->device]% samplenow -s UP -n node001
Measurable      Parameter Type      Value      Age      Info
-----
AlertLevel      count      Internal  0          0.081s
AlertLevel      maximum    Internal  0          0.081s
AlertLevel      sum        Internal  0          0.081s
...

```

Sampling according to a device status value other than UP is also possible.

The help text for the `samplenow` command gives further details on its possible options.

The `latestmetricdata` and `latesthealthdata` commands (section 12.6.3) displays the results from the latest metric and health samples that have been gathered by the cluster, rather than sampling on demand.

The `dumpmonitoringdata` command (section 12.6.4) displays monitoring data gathered over a period of time in a variety of formats.

## 12.6.3 The Latest Data And Counter Values—The `latest*data` And

### `latestmetriccounters` Commands

Within device mode, the values obtained by the latest measurable sampling run can be displayed for a specified entity with the `latestmonitoringdata`, `latestmetricdata` and `latesthealthdata` commands:

- **latestmetricdata:** The `latestmetricdata` command for a specified entity displays the most recent metric value that has been obtained by the monitoring system for each metric used by the entity. For displaying metrics on-demand in `cmsh`, the `samplenow --metrics` command (page 463) can be used for a specified entity.
- **latesthealthdata:** The `latesthealthdata` command for a specified entity displays the most recent value that has been obtained by the monitoring system for each health check used by the entity. For displaying health check responses on demand in `cmsh`, the `samplenow --checks` command (page 463) can be used for a specified entity.
- **latestmonitoringdata:** The `latestmonitoringdata` command for a specified entity combines the output of the `latesthealthdata` and `latestmetricdata` commands, i.e. it displays the latest samples of the measurables for that entity. For displaying measurables on-demand in `cmsh`, the `samplenow` command (page 462) can be run without options, for a specified entity.

The `latestmetriccounters` command, on the other hand, displays the latest cumulative counter values of the cumulative metrics in use by the entity.

### Using The `latest*data` Commands

When using the `latest*data` commands, the device must be specified (some output elided):

#### Example

```
[bright80->device]% use node001
[bright80->device[node001]]% latestmetricdata
```

Measurable	Parameter	Type	Value	Age	Info
AlertLevel	count	Internal	0	1m 12s	FAIL schedulers
AlertLevel	maximum	Internal	0	1m 12s	FAIL schedulers
AlertLevel	sum	Internal	0	1m 12s	
BlockedProcesses		OS	0 processes	1m 12s	
BufferMemory		Memory	847 KiB	1m 12s	
BytesRecv	eth0	Network	311.611 B/s	1m 12s	
BytesRecv	eth1	Network	0 B/s	1m 12s	
BytesSent	eth0	Network	349.953 B/s	1m 12s	
BytesSent	eth1	Network	0 B/s	1m 12s	
CPUGuest		CPU	0 Jiffies	1m 12s	
...					

Valid device grouping options and other options can be seen in the help text for the `latestmetricdata` and `latesthealthdata` commands.

#### Example

```
[bright80->device]% help latestmetricdata
Name: Latestmetricdata - Display the latest metric data

Usage: latestmetricdata [OPTIONS] [<entity>]

Options:
  -v, --verbose
        Be more verbose

  -n, --nodes <node>
        List of nodes, e.g. node001..node015,node020..node028,node030
        or ^/some/file/containing/hostnames
```

```

-g, --group <group>
    Include all nodes that belong to the node group, e.g. testnodes
    or test01,test03
...

```

By default the data values are shown with human-friendly units. The `--raw` option displays the data values as raw units.

### Using The `latestmetriccounter` Command

The `latestmetriccounter` is quite similar to the `latestmetricdata` command, except that it displays only cumulative metrics, and displays their accumulated counts since boot. The `latestmonitoringcounter` command is an alias for this command.

### Example

```

[bright80->device]% latestmonitoringcounters node001

```

Measurable	Parameter	Type	Value	Age	Info
BytesRecv	eth0	Network	286 MiB	11.7s	
BytesRecv	eth1	Network	0 B	11.7s	
BytesSent	eth0	Network	217 MiB	11.7s	
BytesSent	eth1	Network	0 B	11.7s	
CPUGuest		CPU	0 Jiffies	11.7s	
CPUIdle		CPU	60.1 MJiffies	11.7s	
CPUIrq		CPU	0 Jiffies	11.7s	
CPUNice		CPU	66 Jiffies	11.7s	

```

...

```

The reader can compare the preceding example output against the example output of the `latestmetricdata` command (page 465) to become familiar with the meaning of cumulative output.

## 12.6.4 Data Values Over A Period—The `dumpmonitoringdata` Command

The `dumpmonitoringdata` command displays monitoring data values over a specified period. This is for an entity, such as a node in device mode, or the base partition in partition mode, or an image in softwareimage mode.

### Using The `dumpmonitoringdata` Command

A concise overview of the `dumpmonitoringdata` command can be displayed by typing in “help `dumpmonitoringdata`” in a `cmsh` mode that has entities.

The usage of the `dumpmonitoringdata` command consists of the following options and mandatory arguments:

```

dumpmonitoringdata [OPTIONS] <start-time> <end-time> <measurable> [entity]

```

**The mandatory arguments:** The mandatory arguments for the times, the measurables being dumped, and the entities being sampled, have values that are specified as follows:

- The measurable `<measurable>` for which the data values are being gathered must always be given. Measurables currently in use can conveniently be listed by running the `measurables` command (section 12.6.1).
- If `[entity]` is not specified when running the `dumpmonitoringdata` command, then it must be set by specifying the entity object from its parent mode of `cmsh` (for example, with `use node001` in device mode). If the mode is device mode, then the entity can also be specified via the options as a list, a group, an overlay, or a category of nodes.

- The time pair *<start-time>* or *<end-time>* can be specified as follows:
  - *Fixed time format*: The format for the times that make up the time pair can be:
    - \* [YY/MM/DD] HH:MM[:SS]  
(If YY/MM/DD is used, then each time must be enclosed in double quotes)
    - \* The unix epoch time (seconds since 00:00:00 1 January 1970)
  - *now*: For the *<end-time>*, a value of `now` can be set. The time at which the `dumpmonitoringdata` command is run is then used.
  - *Relative time format*: One item in the time pair can be set to a fixed time format. The other item in the time pair can then have its time set relative to the fixed time item. The format for the non-fixed time item (the relative time item) can then be specified as follows:
    - \* For the *<start-time>*, a number prefixed with “-” is used. It indicates a time that much earlier to the fixed end time.
    - \* For the *<end-time>*, a number prefixed with “+” is used. It indicates a time that much later to the fixed start time.
    - \* The number values also have suffix values indicating the units of time, as seconds (s), minutes (m), hours (h), or days (d).

The relative time format is summarized in the following table:

Unit	<i>&lt;start-time&gt;</i>	<i>&lt;end-time&gt;</i>
seconds:	-<number>s	+<number>s
minutes:	-<number>m	+<number>m
hours:	-<number>h	+<number>h
days:	-<number>d	+<number>d

**The options:** The options applied to the samples are specified as follows:

Option	Argument(s)	Description
-v, --verbose		show the rest of the line on a new line instead of cutting it off
-i, --intervals	<number>	number of samples to show
-u, --unix		use a unix timestamp instead of using the default date format
-d, --delimiter	"<string>"	set the delimiter to a character
-m, --sum		sum over specified devices
-x, --max		maximum over specified devices
--min		minimum over specified devices
--avg		average over specified devices
--raw		show the metric value without units
--human		show the metric value with units (default).
--consolidationinterval		retrieve data from the consolidator with specified interval
--consolidationoffset		retrieve data from the consolidator with specified (interval, offset)

...continues

...continued

Option	Argument(s)	Description
<b>The following options are valid only for device mode:</b>		
-n, --nodes	<list>	for list of nodes
-g, --groups	<list>	for list of groups
-c, --categories	<list>	for list of categories
-r, --racks	<list>	for list of racks
-h, --chassis	<list>	for list of chassis
-e, --overlay	<overlay>	Include all nodes in overlay
-l, --role	<role>	Filter all nodes in role
-s, --status	<state>	for nodes in state UP, OPENING, DOWN, and so on

### Notes And Examples Of dumpmonitoringdata Command Use

Notes and examples of how the dumpmonitoringdata command can be used now follow:

**Fixed time formats:** Time pairs can be specified for fixed times:

#### Example

```
[bright80->device[node001]]% dumpmonitoringdata 18:00:00 18:02:00 loadone
Timestamp                Value      Info
-----
2017/08/30 17:58:00      0.02
2017/08/30 18:00:00      0.01
2017/08/30 18:02:00      0.02
```

Double quotes are needed for times with a YY/MM/DD specification:

#### Example

```
[bright80->device[node001]]% dumpmonitoringdata "17/08/30 18:00" "17/08/30 18:02" loadone
Timestamp                Value      Info
-----
2017/08/30 17:58:00      0.02
2017/08/30 18:00:00      0.01
2017/08/30 18:02:00      0.02
```

Unix epoch time can also be set:

#### Example

```
[bright80->device[node001]]% !date -d "Aug 30 18:00:00 2017" +%s
1504108800
[bright80->device[node001]]% dumpmonitoringdata 1504108800 1504108920 loadone
Timestamp                Value      Info
-----
2017/08/30 17:58:00      0.02
2017/08/30 18:00:00      0.01
2017/08/30 18:02:00      0.02
```

**Intervals and interpolation:** The `-i|--intervals` option interpolates the data values that are to be displayed. The option needs *<number>* samples to be specified. This then becomes the number of interpolated samples across the given time range. Using “`-i 0`” outputs only the non-interpolated stored samples—the raw data—and is the default.

### Example

```
[bright80->device]% dumpmonitoringdata -i 0 -10m now loadone node001
```

Timestamp	Value	Info
2017/07/21 14:56:00	0.01	
2017/07/21 14:58:00	0.14	
2017/07/21 15:00:00	0.04	
2017/07/21 15:02:00	0.04	
2017/07/21 15:04:00	0.08	
2017/07/21 15:06:00	0.08	

If the number of intervals is set to a non-zero value, then the last value is always no data, since it cannot be interpolated.

### Example

```
[bright80->device]% dumpmonitoringdata -i 3 -10m now loadone node001
```

Timestamp	Value	Info
2017/07/21 21:49:36	0	
2017/07/21 21:54:36	0.0419998	
2017/07/21 21:59:36	no data	

A set of nodes can be specified for the dump:

```
[bright80->device]% dumpmonitoringdata -n node001..node002 -5m now cpuidle
```

Entity	Timestamp	Value	Info
node001	2017/07/20 20:14:00	99.8258	Jiffies
node001	2017/07/20 20:16:00	99.8233	Jiffies
node001	2017/07/20 20:18:00	99.8192	Jiffies
node001	2017/07/20 20:20:00	99.8475	Jiffies
node002	2017/07/20 20:14:00	99.7917	Jiffies
node002	2017/07/20 20:16:00	99.8083	Jiffies
node002	2017/07/20 20:18:00	99.7992	Jiffies
node002	2017/07/20 20:20:00	99.815	Jiffies

```
[bright80->device]%
```

**Summing values:** The `-m|--sum` option sums a specified metric for specified devices, for a set of specified times. For 2 nodes, over a period 2 hours ago, with values interpolated over 3 time intervals, the option can be used as follows:

### Example

```
[bright80->device]% dumpmonitoringdata -2h now -i 3 loadone -n node00[1-2] --sum
```

Timestamp	Value	Info
2017/07/20 18:30:27	0.0292462	
2017/07/20 19:30:27	0	
2017/07/20 20:30:27	no data	

Each entry in the values column in the preceding table is the sum of `loadone` displayed by `node001`, and by `node002`, at that time, as can be seen from the following corresponding table:

### Example

```
[bright80->device]% dumpmonitoringdata -2h now -i 3 loadone -n node00[1-2]
```

Entity	Timestamp	Value	Info
node001	2017/07/20 18:30:27	0	
node001	2017/07/20 19:30:27	0	
node001	2017/07/20 20:30:27	no data	
node002	2017/07/20 18:30:27	0.0292462	
node002	2017/07/20 19:30:27	0	
node002	2017/07/20 20:30:27	no data	

Each `loadone` value shown by a node at a time shown in the preceding table, is in turn an average interpolated value, based on actual data values sampled for that node around that time.

**Displaying according to status:** The `-s|--status` option selects only for nodes with the specified state. A state is one of the values output by the `cmsh` command `ds` or `device status`. It is also one of the values returned by the enummetric `DeviceStatus` (section 12.2.2).

### Example

```
[bright80->device]% dumpmonitoringdata -2m now loadone -s up
```

Entity	Timestamp	Value	Info
bright80	2017/07/21 15:00:00	0.35	
bright80	2017/07/21 15:02:00	0.53	
node001	2017/07/21 14:12:00	0.04	
node001	2017/07/21 15:02:00	0.04	
node002	2017/07/21 15:00:00	0.22	
node002	2017/07/21 15:02:00	0.21	

```
[bright80->device]%
```

The argument to `-s|--status` can be specified with simple regexes, which are case insensitive. For example, `inst.*` covers the states `installing`, `installer_failed`, `installer_rebooting`, `installer_callinginit`, `installer_unreachable`, `installer_burning`.

**Some non-interpolating RLE quirks:** When a sample measurement is carried out, if the sample has the same value as the two preceding it in the records, then the “middle” sample is discarded from storage.

Thus, when viewing the sequence of output of non-interpolated samples, identical values do not exceed two entries one after the other. This is a common compression technique known as Run Length Encoding (RLE). It can have some implications in the output of the `dumpmonitoringdata` command.

### Example

```
[bright80->device[node001]]% dumpmonitoringdata -10m now threadsused:cmd
```

Timestamp	Value	Info
2017/07/21 11:16:00	42	
2017/07/21 11:20:00	42	
2017/07/21 11:22:00	41	
2017/07/21 11:24:00	42	
2017/07/21 11:26:00	42	



In the preceding example, data values for the number of threads used by CMDaemon are dumped for the last 10 minutes.

Because of RLE, the value entry around 11:18:00 in the preceding example is skipped. It also means only 2 of the same values are seen a row sequence at most. This means that 42 is not the answer to everything.

For a non-interpolated value, the nearest value in the past, relative to the time of sampling, is used as the sample value for the time of sampling. This means that for non-interpolated values, some care may need to be taken due to another aspect of the RLE behavior: The time over which the samples are presented may not be what a naive administrator may expect when specifying the time range. For example, if the administrator specifies a 10 minute time range as follows:

### Example

```
[bright80->softwareimage]% dumpmonitoringdata -10m now nodesup default-image
Timestamp                Value          Info
-----
2017/07/13 16:43:00      2
2017/07/20 17:37:00      2
[bright80->softwareimage]%
```

then here, because the dump is for non-interpolated values, it means that the nearest value in the past, relative to the time of sampling, is used as the sample value. For values that are unlikely to change much, it means that rather than 10 minutes as the time period within which the samples are taken, the time period can be much longer. Here it turns out to be about 7 days because the nodes happened to be booted then.

### 12.6.5 Monitoring Data Health Overview—The `monitoringhealthoverview` Command

In figure 12.20, section 12.4.6, the Bright View clickpath

```
Monitoring→Health Status
```

showed an overview of the health status of all nodes.

The `cmsh` equivalent is the `monitoringhealthoverview` command, which is run from within device mode. If run without using a device, then it provides a summary of the alert levels for all nodes.

The help text in `cmsh` explains the options for the `monitoringhealthoverview` command. The command can be run with options to restrict the display to specified nodes, and also to display according to the sort order of the alert level values.

### Example

```
[bright80->device]% monitoringhealthoverview -n node00[1-3]
Device      Sum      Maximum      Count      Age      Info
-----
node001     30       15           2         50.7s    hot, fan high
node002     30       15           2         50.7s    hot, fan high
node003     15       15           1         50.7s    hot
```

### 12.6.6 Monitoring Data About The Monitoring System—The `monitoringinfo` Command

The `monitoringinfo` command provides information for specified head nodes or regular nodes about the monitoring subsystem. The help text shows the options for the command. Besides options to specify the nodes, there are options to specify what monitoring information aspect is shown, such as storage, cache, or services.

## Example

```
[bright80->device]% monitoringinfo -n node001
```

Service	Queued	Handled	Cache miss	Stopped	Suspended	Last operation
Mon::CacheGather	0	0	0	yes	no	-
Mon::DataProcessor	0	0	0	yes	no	-
Mon::DataTranslator	0	932,257	0	no	no	Mon Jul 24 11:34:00
Mon::EntityMeasurableCache	0	0	0	no	no	Thu Jul 13 16:39:52
Mon::MeasurableBroker	0	0	0	no	no	-
Mon::Replicate::Collector	0	0	0	yes	yes	-
Mon::Replicate::Combiner	0	0	0	yes	yes	-
Mon::RepositoryAllocator	0	0	0	yes	no	-
Mon::RepositoryTrim	0	0	0	yes	no	-
Mon::TaskInitializer	0	30	0	no	no	Thu Jul 13 16:39:52
Mon::TaskSampler	30	233,039	0	no	no	Mon Jul 24 11:34:00
Mon::Trigger::Actuator	0	0	0	yes	no	-
Mon::Trigger::Dispatcher	0	0	0	yes	no	-

Cache	Size	Updates	Requests
ConsolidatorCache	0	17	0
EntityCache	10	17	935,280
GlobalLastRawDataCache	87	17	0
LastRawDataCache	142	17	427,301
MeasurableCache	231	17	935,230

Cache	Up	Down	Closed
DeviceStateCache	3	0	0

Replicator	First	Last	Requests	Samples	Sources
ReplicateRequestHandler	-	-	0	0	

Cache	Queued	Delivered	Handled	Pickup
Cache	0	120	932,257	7,766

Plotter	First	Last	Count	Samples	Sources	Requests
RequestDispatcher	-	-	0	0	0	-
RequestHandler	-	-	0	0	0	-

Storage	Elements	Disk size	Usage	Free disk
Mon::Storage::Engine	0	0 B	0.0%	-
Mon::Storage::Message	0	0 B	0.0%	-
Mon::Storage::RepositoryId	0	0 B	0.0%	-

## 12.7 The User Portal

### 12.7.1 Accessing The User Portal

The user portal is compatible with most browsers using reasonable settings. For Internet Explorer, version 9 or later is required.

The user portal is located by default on the head node. For a head node `bright80`, it is accessible to users for a login via a browser at the URL `http://bright80`, or more directly via `https://bright80:8081/userportal`. The state of the cluster can then be viewed by the users via an interactive interface.

The first time a browser is used to login to the portal, a warning about the site certificate being untrusted appears.

The certificate is a self-signed certificate (the X509v3 certificate of Chapter 4 of the *Installation Manual*), generated and signed by Bright Computing, and the attributes of the cluster owner are part of the certificate. However, Bright Computing is not a recognized Certificate Authority (CA) like the CAs that are recognized by a browser, which is why the warning appears.

The SSL configuration file is located at `/etc/httpd/conf.d/ssl.conf`. Within `ssl.conf`, by default the PEM-encoded server certificate is set to `/etc/pki/tls/certs/localhost.crt`. The entry should be changed if generating and installing the certificate elsewhere. A key-based certificate can be used instead, with a private key then expected by the `ssl.conf` file at `etc/pki/tls/private/localhost.key`.

For a portal that is not accessible from the outside world, such as the internet, the warning about Bright Computing not being a recognized Certificate Authority is not an issue, and the user can simply accept the “untrusted” certificate.

For a portal that is accessible via the internet, some administrators may regard it as more secure to ask users to trust the self-signed certificate rather than external certificate authorities. Alternatively the administrator can replace the self-signed certificate with one obtained by a standard CA, if that is preferred.

### 12.7.2 Setting A Common Username/Password For The User Portal

By default, each user has their own username/password login to the portal. Removing the login is not possible, because the portal is provided by CMDaemon, and users must connect to CMDaemon.

However, a possible workaround is to set a shared (common) username/password for all users. This requires that some parts at the head and tail of the file `/cm/local/apps/cmd/etc/htdocs/userportal/app/controllers/AuthController.js` be edited.

#### Example

```
[root@bright80 ~]# cd /cm/local/apps/cmd/etc/htdocs/userportal/app/controllers
[root@bright80 controllers]# head AuthController.js          #####just looking at head
'use strict';

app.controller('AuthController', function($scope, $log, $location, $window, $timeout, AUTH,\
AUTH_EVENTS, AuthService) {
  $scope.credentials = {
    username: '',
    password: ''
  };

  $scope.pwFieldAttr = 'password';
  $scope.pwOpenEyeIcon = true;

[root@bright80 controllers]# tail AuthControllers.js        #####now looking at tail
  $timeout(doKeepAlive, AUTH.keepAlive);
};

function init() {
  doKeepAlive();
};
```

```

init();

});
[root@bright80 controllers]# vi AuthControllers.js          #####now edit
editor opens up

```

Within the editor that opens up, the changes that should be made can be as follows:

- The empty values for `username` and `password` seen in the first few lines of the file should be changed to a user name and password that all users will use. In the example that follows, the username and password are set to the same string (`userportalreadaccess`), but they can also be set to differ from each other.
- The line immediately after the `init()` line, seen in the last few lines, should have a new “bypass” line inserted.

After the changes have been saved and the editor is exited, the result the looks like (altered parts shown in bold):

```

[root@bright80 controllers]# head AuthController.js
'use strict';

app.controller('AuthController', function($scope, $log, $location, $window, $timeout, AUTH,\
AUTH_EVENTS, AuthService) {
  $scope.credentials = {
    username: 'userportalreadaccess',
    password: 'userportalreadaccess'
  };

  $scope.pwFieldAttr = 'password';
  $scope.pwOpenEyeIcon = true;
[root@bright80 controllers]# tail AuthControllers.js
  $timeout(doKeepAlive, AUTH.keepAlive);
};

function init() {
  doKeepAlive();
};

init();
  $scope.doLogin($scope.credentials);
});

```

The administrator should create the user `userportalreadaccess`, and set a password for it. All users can then only access the user portal via the common username/password combination.

If the `cm-webportal` package is updated, then the changes in `AuthControllers.js` will be overwritten.

### 12.7.3 User Portal Home Page

The default user portal home page allows a quick glance to convey the most important cluster-related information for users (figure 12.24):




Figure 12.24: User Portal: Overview Page

The following items are displayed on the default home page, which is the overview page:

- a Message Of The Day. This can be edited in `/cm/local/apps/cmd/etc/htdocs/userportal/app/partials/messageOfTheDay.html`
- links to the documentation for the cluster
- contact information. This can be edited in `/cm/local/apps/cmd/etc/htdocs/userportal/app/partials/contact.html`
- an overview of the cluster state, displaying some cluster parameters.
  - This can conveniently be set to refresh automatically every 60 seconds, for example, by inserting an HTML meta attribute:

#### Example

```
<meta http-equiv="refresh" content="60">
```

in the line immediately after the `<body ng-controller="ApplicationController">` line in `/cm/local/apps/cmd/etc/htdocs/userportal/index.html`

Other user-accessible pages are available by default, and are described further in Chapter 12 of the *User Manual*. The default pages that are available can be configured from the `/cm/local/apps/cmd/etc/htdocs/userportal/index.html` page.

The user portal is designed to serve files only, and will not run executables such as PHP or similar CGI scripts.

## 12.8 Job Monitoring

Most HPC administrators set up device-centric monitoring to keep track of cluster node resource use. This means that metrics are selected for devices, and the results can then be seen over a period of time.

The results can be viewed as a graph or data table, according to the viewing option chosen. This is covered in the other sections of this chapter.

Users can also select a job that is currently running, or that has recently run, and get metrics for nodes, jobs, and accumulated metrics per user. This is known as *job monitoring*. It is covered in this section (section 12.8), and uses *job metrics*.

### 12.8.1 Job Metrics

Job metrics collection uses `cgroups` (section 7.10). Thus each job should be associated by a workload manager with a unique cgroup automatically. Bright Cluster Manager configures the following workload managers to run jobs in cgroups:

- Slurm
- UGE
- LSF
- OpenLava
- Torque

Notes:

1. OGS for now does not support cgroups.
2. PBS Pro can be configured to run with cgroups, but this configuration is not provided by Bright Cluster Manager 8.0 and job metrics are not supported with PBS Pro. To enable cgroups in PBS Pro, Altair should be asked for a special hook script for cgroups configuration.

Different workload managers use different cgroup controllers when creating a cgroup for a job. The controllers enable different metric collections to be carried out by the Linux kernel. In order to have the same set of collected metrics for each of the workload managers, Bright Cluster Manager configures `systemd` to mount the following cgroup controllers to the same directory:

- `blkio`
- `cpuacct`
- `memory`
- `freezer`

For example: Slurm job metrics collection uses the following cgroup directories structure:

#### Example

```
[root@node001 ~]# cd /sys/fs/cgroup/
[root@node001 cgroup]# tree -d --charset=C -L 2 | grep blkio
|-- blkio -> blkio,cpuacct,memory,freezer
|-- blkio,cpuacct,memory,freezer
|-- cpuacct -> blkio,cpuacct,memory,freezer
|-- freezer -> blkio,cpuacct,memory,freezer
|-- memory -> blkio,cpuacct,memory,freezer
```

The directory

`blkio,cpuacct,memory,freezer`

is created, the appropriate cgroup controllers are mounted, the directory links are created, and this is all carried out automatically by `systemd`.

### Example

```
[root@node001 ~]# grep JoinControllers /etc/systemd/system.conf
JoinControllers=blkio,cpuacct,memory,freezer
[root@node001 ~]#
```

The following table lists some of the most useful job metrics that Bright Cluster Manager can monitor and visualize. In the table, the text *<device>* denotes a block device name, such as *sda*.

Metric Name	Description	Cgroup Source File
blkio.time:<device>	Time job had I/O access to device	blkio.time_recursive
blkio.sectors:<device>	Sectors transferred to or from specific devices by a cgroup	blkio.sectors_recursive
blkio.io_serviced_read:<device>	Read I/O operations	blkio.io_serviced_recursive
blkio.io_serviced_write:<device>	Write I/O operations	blkio.io_serviced_recursive
blkio.io_serviced_sync:<device>	Synchronous I/O operations	blkio.io_serviced_recursive
blkio.io_serviced_async:<device>	Asynchronous I/O operations	blkio.io_serviced_recursive
blkio.io_service_read:<device>	Bytes read	blkio.io_service_bytes_recursive
blkio.io_service_write:<device>	Bytes written	blkio.io_service_bytes_recursive
blkio.io_service_sync:<device>	Bytes transferred synchronously	blkio.io_service_bytes_recursive
blkio.io_service_async:<device>	Bytes transferred asynchronously	blkio.io_service_bytes_recursive
cpuacct.usage	Total CPU time consumed by all job processes	cpuacct.usage
cpuacct.stat.user	User CPU time consumed by all job processes	cpuacct.stat
cpuacct.stat.system	System CPU time consumed by all job processes	cpuacct.stat
memory.usage	Total current memory usage	memory.usage_in_bytes
memory.memsw.usage	Sum of current memory plus swap space usage	memory.memsw.usage_in_bytes

...continues

...continued

Metric Name	Description	Cgroup Source File
memory.memsw.max_usage	Maximum amount of memory and swap space used	memory.memsw.max_usage_in_bytes
memory.failcnt	How often the memory limit has reached the value set in memory.limit_in_bytes	memory.failcnt
memory.memsw.failcnt	How often the memory plus swap space limit has reached the value set in memory.memsw.limit_in_bytes	memory.memsw.failcnt
memory.stat.swap	Total swap usage	memory.stat
memory.stat.cache	Total page cache, including tmpfs (shmem)	memory.stat
memory.stat.mapped_file	Size of memory-mapped mapped files, including tmpfs (shmem)	memory.stat
memory.stat.unevictable	Memory that cannot be re-claimed	memory.stat

The third column in the table shows the precise source file name that is used when the value is retrieved. These files are all virtual files, and are created as the cgroup controllers are mounted to the cgroup directory. In this case several controllers are mounted to the same directory, which means that all the virtual files will show up in that directory, and in its associated subdirectories—job cgroup directories—when the job runs.

The metrics in the preceding table are enabled by default. There are also over 40 other advanced metrics that can be enabled, as described in the following table:

Metric Name	Description	Cgroup Source File
blkio.io_service_time_read:<device>	Total time between request dispatch and request completion according to CFQ scheduler for I/O read operations	blkio.io_service_time_recursive
blkio.io_service_time_write:<device>	Total time between request dispatch and request completion according to CFQ scheduler for I/O write operations	blkio.io_service_time_recursive
blkio.io_service_time_sync:<device>	Total time between request dispatch and request completion according to CFQ scheduler for I/O synchronous operations	blkio.io_service_time_recursive

...continues



...continued

Metric Name	Description	Cgroup Source File
blkio.io_service_time_async:<device>	Total time between request dispatch and request completion according to CFQ scheduler for I/O asynchronous operations	blkio.io_service_time_recursive
blkio.io_wait_time_read:<device>	Total time spent waiting for service in the scheduler queues for I/O read operations	blkio.io_wait_time_recursive
blkio.io_wait_time_write:<device>	Total time spent waiting for service in the scheduler queues for I/O write operations	blkio.io_wait_time_recursive
blkio.io_wait_time_sync:<device>	Total time spent waiting for service in the scheduler queues for I/O synchronous operations	blkio.io_wait_time_recursive
blkio.io_wait_time_async:<device>	Total time spent waiting for service in the scheduler queues for I/O asynchronous operations	blkio.io_wait_time_recursive
blkio.io_merged_read:<device>	Number of BIOS requests merged into requests for I/O read operations	blkio.io_merged_recursive
blkio.io_merged_write:<device>	Number of BIOS requests merged into requests for I/O write operations	blkio.io_merged_recursive
blkio.io_merged_sync:<device>	Number of BIOS requests merged into requests for I/O synchronous operations	blkio.io_merged_recursive
blkio.io_merged_async:<device>	Number of BIOS requests merged into requests for I/O asynchronous operations	blkio.io_merged_recursive
blkio.io_queued_read:<device>	Number of requests queued for I/O read operations	blkio.io_queued_recursive
blkio.io_queued_write:<device>	Number of requests queued for I/O write operations	blkio.io_queued_recursive
blkio.io_queued_sync:<device>	Number of requests queued for I/O synchronous operations	blkio.io_queued_recursive

...continues

...continued

Metric Name	Description	Cgroup Source File
blkio.io_queued_async:<device>	Number of requests queued for I/O asynchronous operations	blkio.io_queued_recursive
cpu.stat.nr_periods	Number of period intervals (as specified in <code>cpu.cfs_period_us</code> ) that have elapsed	cpu.stat
cpu.stat.nr_throttled	Number of times processes have been throttled (that is, not allowed to run because they have exhausted all of the available time as specified by their quota)	cpu.stat
cpu.stat.throttled_time	Total time duration for which processes have been throttled	cpu.stat
memory.stat.rss	Anonymous and swap cache, not including tmpfs (shmem)	memory.stat
memory.stat.pgpgin	Number of pages paged into memory	memory.stat
memory.stat.pgpgout	Number of pages paged out of memory	memory.stat
memory.stat.active_anon	Anonymous and swap cache on active least-recently-used (LRU) list, including tmpfs (shmem)	memory.stat
memory.stat.inactive_anon	Anonymous and swap cache on inactive LRU list, including tmpfs (shmem)	memory.stat
memory.stat.active_file	File-backed memory on active LRU list	memory.stat
memory.stat.inactive_file	File-backed memory on inactive LRU list	memory.stat
memory.stat.hierarchical\_memory_limit	Memory limit for the Hierarchy that contains the memory cgroup of job	memory.stat
memory.stat.hierarchical\_memsw_limit	Memory plus swap limit for Hierarchy that contains the memory cgroup of job	memory.stat

If job metrics are set up (section 12.8.3), then:

1. on virtual machines, block device metrics may be unavailable because of virtualization.
2. for now, the metrics are retrieved from cgroups created by the workload manager for each job. When the job is finished the cgroup is removed from the filesystem along with all the collected

data. Retrieving the jobs metric data therefore means that CMDaemon must sample the cgroup metrics before the job is finished. If CMDaemon is not running during a time period for any reason, then the metrics for that time period cannot be collected, even if CMDaemon starts later.

3. block device metrics are collected for each block device by default. Thus, if there are  $N$  block devices, then there are  $N$  collected block device metrics. The monitored block devices can be excluded as described in section 12.8.3.

### 12.8.2 Job Information Retention

Each job adds a set of metric values to the monitoring data. The longer a job runs, the more data is added to the database. By default, old values are cleaned up from the database in order to limit its size. In Bright Cluster Manager 8.0 there are four advanced configuration flags to control the job data retention, with names and default values as follows:

Advanced Configuration Flag	Default value
JobInformationKeepDuration	2419200
JobInformationKeepCount	8192
JobInformationMinimalJobDuration	0
JobInformationFlushInterval	600

- **JobInformationKeepDuration:** If a job has finished more than that many seconds ago, then it will be removed along with all its monitoring data from the database. By default it is set to 28 days ( $24 \times 3600 \times 28$  seconds).
- **JobInformationKeepCount:** If the total number of jobs is greater than ( $\text{JobInformationKeepCount} + 10\%$ ), then the job record and its data content are discarded, starting from the oldest job first, until the total number of jobs remaining becomes JobInformationKeepCount. The default value of JobInformationKeepCount is 8192. If it is set to 0, then none of the job records and content are removed.
- **JobInformationMinimalJobDuration:** If set, then jobs that run for less than this number of seconds are not stored in the cache. Its default value of 0 seconds means that all jobs are handled.
- **JobInformationFlushInterval:** If this interval, in seconds, is set, then the cache is flushed to the database with that interval. Its default value is 10 minutes ( $10 \times 60$  seconds). Values of around 30 seconds or less will conflict with the default CMDaemon maintenance timeout value of 30 seconds, and will mostly simply add load.

### 12.8.3 Job Metrics Sampling Configuration

CMDaemon collects job metrics from the cgroups in which a job runs. The administrator can tune some low level metric collection options for the JobSampler data producer in the jobmetricsettings submode:

#### Example

```
[bright80->monitoring->setup[JobSampler]->jobmetricsettings]% show
Parameter                                     Value
-----
Enable Advanced Metrics                      no
Exclude Devices                             loop, sr
Exclude Metrics
Include Devices
```

Include Metrics  
Revision

The configuration parameters are:

Parameter Name	Description
Enable Advanced Metrics	Enables advanced metrics
Exclude Devices	Block devices for which job metrics will not collect metrics
Include Devices	If the list is not empty then only block device metrics for these devices will be collected, while for other devices the metrics will be skipped
Enable Advanced	Indicates whether advanced job metrics should be enabled (options: true, false)
Exclude Metrics	List of metric names that should not be collected
Include Metrics	List of metric names that should be added to metric collection

The parameter `Exclude Metrics` can be used to exclude metrics that are currently enabled. For example, if advanced metrics collection is enabled then `Exclude Metrics` allows either default or advanced metrics to be excluded by name.

#### 12.8.4 Job Monitoring In `cmsh`

Using `cmsh`, the following commands allow job metrics and historical information to be retrieved within jobs mode:

**filter** The command provides filtered historic job-related information. It does not provide metrics data. The command and its options can be use to:

- retrieve running, pending, failed or finished jobs information
- select job data using regular expressions to filter by job ID
- list jobs by user name, user group, or workload manager

#### Example

```
[bright80->jobs(slurm)]% filter --limit 2
Job ID Job name User Queue Start time End time Nodes Exit code
-----
10 slurm.job cmsupport defq 02/02/2016 13:58:22 03/02/2016 00:58:24 node001 0
11 slurm.job cmsupport defq 02/02/2016 13:58:22 03/02/2016 00:58:24 node001 0
[bright80->jobs(slurm)]%
```

The data shown is retrieved from the running workload manager, as well as from the accounting file or database maintained by the workload manager.

Further details of the options to `filter` can be seen by running `help filter`.

**dumpmonitoringdata** The `dumpmonitoringdata` command for job metrics is somewhat similar to the `dumpmonitoringdata` command for device metrics (section 12.6.4), and shows monitoring data for a job ID over a period of time. Options allow metric values to be retrieved and filtered over a period of time. The user can also specify custom periods or select according to the user name of the job owner.

The usage of the `dumpmonitoringdata` command for job metrics is:

```
dumpmonitoringdata [OPTIONS] [<start-time> <end-time>] <metric> <job ID>
```

### Example

```
[bright80->jobs(slurm)]% dumpmonitoringdata "16/02/02 19:30" "16/02/02 19:50" memory.usage 10
# From Tue Feb  2 19:30:00 2016 to Tue Feb  2 19:50:00 2016
# Nodes: node001
```

Time	Value	Info Message
Tue Feb  2 19:30:00 2016	1.14062 MiB	
Tue Feb  2 19:32:00 2016	1.14062 MiB	
Tue Feb  2 19:34:00 2016	1.14453 MiB	
Tue Feb  2 19:36:00 2016	1.14844 MiB	
Tue Feb  2 19:38:00 2016	1.15234 MiB	
Tue Feb  2 19:40:00 2016	1.15625 MiB	
Tue Feb  2 19:42:00 2016	1.16016 MiB	
Tue Feb  2 19:44:00 2016	1.16406 MiB	
Tue Feb  2 19:46:00 2016	1.16406 MiB	
Tue Feb  2 19:48:00 2016	1.16797 MiB	
Tue Feb  2 19:50:00 2016	1.17188 MiB	

```
[bright80->jobs(slurm)]%
```

The data is shown per node if the job uses several nodes.

Further details of the options to `dumpmonitoringdata` for job metrics can be seen by running `help dumpmonitoringdata` within `jobs` mode.

**statistics** The `statistics` command shows basic statistics for historical job information. It allows statistics to be filtered per user or user group, and workload manager. The format of the output can be specified with the `--format` option. The statistics can be grouped by hour, day, week or a custom interval.

### Example

```
[bright80->jobs(slurm)]% statistics
```

Interval	User	Group	Pending	Running	Finished	Error	Nodes
N/A			0	7	32	0	34

```
[bright80->jobs(slurm)]%
```

Further details of the options to `statistics` can be seen by running `help statistics`.

## 12.9 Event Viewer

Monitoring in Bright Cluster Manager is normally taken by developers to mean how sampling with data producers is handled. However, cluster administrators using this manual typically consider watching and handling events in Bright Cluster Manager to also be a part of a more general concept of monitoring. This manual is aimed at cluster administrators, and therefore this section on event viewing and handling is placed in the current Cluster Monitoring chapter.

Bright Cluster Manager events can be handled and viewed in several ways.

### 12.9.1 Viewing Events In Bright View

In Bright View, events can be viewed by clicking on the `Events` icon of figure 12.5. This opens up a window with a sortable set of columns listing the events in the events log, and with by default with the most recent events showing up first.

### 12.9.2 Viewing Events In `cmsh`

The `events` command is a global `cmsh` command. It allows events to be viewed at several severity levels (section 12.2.7), and allows old events to be displayed. The usage and synopsis of the `events` command is:

```
Usage:      events
           events on [broadcast|private]
           events off [broadcast|private]
           events level <level>
           events clear
           events details <id> [<id>]
           events <number> [level]
           events follow
```

Arguments:

```
level info,notice,warning,error,alert
```

Running the command without any option shows event settings, and displays any event messages that have not been displayed yet in the session:

#### Example

```
[bright80->device]% events
Private events:    off
Broadcast events: on
Level:            notice
custom .....[  RESET  ]  node001
```

Running the command with options allows the viewing and setting of events as follows:

- `on [broadcast|private]`: event messages are displayed as they happen in a session, with `cmsh` prompts showing in between messages:
  - If only `on` is set, then all event messages are displayed as they happen:
    - \* either to all open `cmsh` sessions, and also in Bright View event viewer panes, if the event or its trigger has the “broadcast” property.
    - \* or only in the `cmsh` session that is running the command, if the event or its trigger has the “private” property.
  - If the further option `broadcast` is set, then the event message is displayed as it happens in all open `cmsh` sessions, and also in all Bright View event viewer panes, if the event or its trigger has the “broadcast” property.
  - If the further option `private` is set, then the event message is displayed as it happens only in the `cmsh` session that ran the command, if the event or its trigger has the “private” property.
- `off [broadcast|private]`: disallows viewing of event messages as they happen in a session. Event messages that have not been displayed due to being forbidden with these options, are displayed when the `events` command is run without any options in the same session.

- If only `off` is set, then no event message is displayed as it happens in the session. This is regardless of the “broadcast” or “private” property of the event or its trigger.
  - If the further option `broadcast` is set, then the event message is not displayed as it happens, if the event or its trigger has the “broadcast” property.
  - If the further option `private` is set, then the event message is not displayed as it happens, if the event or its trigger has the “private” property.
- `level <info|notice|warning|error|alert>`: sets a level. Messages are then displayed for this and higher levels.
  - `clear`: clears the local `cmsh` event message cache. The cache indexes some of the events.
  - `details <id>`: shows details for a specific event with the index value of `<id>`, which is a number that refers to an event.
  - `<number> [info|notice|warning|error|alert]`: shows a specified `<number>` of past lines of events. If an optional level (`info, notice, ...`) is also specified, then only that level and higher (more urgent) levels are displayed.
  - `follow`: follows event messages in a `cmsh` session, similar to `tail -f /var/log/messages`. This is useful, for example, in tracking a series of events in a session without having the `cmsh` prompt showing. The output can also be filtered with the standard unix text utilities, for example:  
`events follow | grep node001`

A common example of events that send private messages as they happen are events triggered by the `updateprovisioners` command, which has the “private” property. The following example illustrates how setting the event viewing option to `private` controls what is sent to the `cmsh` session. Some of the output has been elided or truncated for clarity:

### Example

```
[bright80->softwareimage]% events on private
Private events:  on
[bright80->softwareimage]% updateprovisioners
Provisioning nodes will be updated in the background.
[bright80->softwareimage]%
Tue Apr 29 01:19:12 2014 [notice] bright80: Provisioning started: sendi...
[bright80->softwareimage]%
Tue Apr 29 01:19:52 2014 [notice] bright80: Provisioning completed: sen...
updateprovisioners [ COMPLETED ]
[bright80->softwareimage]% !#events were indeed seen in cmsh session
[bright80->softwareimage]% !#now block the events and rerun update:
[bright80->softwareimage]% events off private
Private events:  off
[bright80->softwareimage]% updateprovisioners
Provisioning nodes will be updated in the background.
[bright80->softwareimage]% !#let this 2nd update run for a while
[bright80->softwareimage]% !#(time passes)
[bright80->softwareimage]% !#nothing seen in cmsh session.
[bright80->softwareimage]% !#show a 2nd update did happen:
[bright80->softwareimage]% events 4 | grep -i provisioning
Tue Apr 29 01:19:12 2014 [notice] bright80: Provisioning started: sendi...
Tue Apr 29 01:19:52 2014 [notice] bright80: Provisioning completed: sen...
Tue Apr 29 01:25:37 2014 [notice] bright80: Provisioning started: sendi...
Tue Apr 29 01:26:01 2014 [notice] bright80: Provisioning completed: sen...
```

### 12.9.3 Using The Event Bucket From The Shell For Events And For Tagging Device States

#### Event Bucket Default Behavior

The Bright Cluster Manager *event bucket* accepts input piped to it, somewhat like the traditional unix “bit bucket”, `/dev/null`. However, while the bit bucket simply accepts any input and discards it, the event bucket accepts a line of text and makes an event of it. Since the event bucket is essentially an event processing tool, the volumes that are processed by it are obviously less than that which `/dev/null` can handle.

By default, the location of the event bucket is at `/var/spool/cmd/eventbucket`, and a message can be written to the event pane like this:

#### Example

```
[root@bright80 ~]# echo "Some text" > /var/spool/cmd/eventbucket
```

This adds an event with, by default, the `info` severity level, to the event pane, with the *InfoMessage* “Some text”.

### 12.9.4 InfoMessages

InfoMessages are optional messages that inform the administrator of the reason for the status change of a measurable, or an event in the cluster.

Measurable scripts can use file descriptor 3 within their scripts to write an InfoMessage:

#### Example

```
echo "Drive speed unknown: Reverse polarity" >&3
```

#### Event Bucket Severity Levels


To write events at specific severity levels (section 12.2.7), and not just at the `info` level, the appropriate text can be prepended from the following to the text that is to be displayed:

```
EVENT_SEVERITY_DEBUG:
EVENT_SEVERITY_INFO:
EVENT_SEVERITY_NOTICE:
EVENT_SEVERITY_WARNING:
EVENT_SEVERITY_ERROR:
EVENT_SEVERITY_ALERT:
```

#### Example

```
echo "EVENT_SEVERITY_ERROR:An error line" > /var/spool/cmd/eventbucket
```

The preceding example displays an output notification in the Bright View event viewer as shown in figure 12.25:



	CREATION TIME	MESSAGE	SEVERITY	SOURCE DEVICE
▲	Mon Jul 03 2017 17:45:...	An error line	error	bright80
●	Mon Jul 03 2017 17:45:...	Some text	notice	bright80
●	Mon Jul 03 2017 17:34:...	The trigger 'Passing health checks' is active because the measurable 'schedulers' is PASS	notice	node001
●	Mon Jul 03 2017 17:34:...	The trigger 'Passing health checks' is active because the measurable 'ntp' is PASS	notice	node001

Figure 12.25: Bright View Monitoring: Event Bucket Message Example

#### Event Bucket Filter

Regex expressions can be used to conveniently filter out the user-defined messages that are about to go into the event bucket from the shell. The filters used are placed in the event bucket filter, located by default at `/cm/local/apps/cmd/etc/eventbucket.filter`.



### Event Bucket CMDaemon Directives

The name and location of the event bucket file and the event bucket filter file can be set using the `EventBucket` and `EventBucketFilter` directives from the CMDaemon configuration file directives (Appendix C).

### Adding A User-Defined Message To A Device State With The Event Bucket

While the event bucket is normally used to send a message to the event viewer, it can instead be used to add a message to the state of a device. The line passed to the `echo` command then has the message and device specified in the following format:

```
STATE.USERMESSAGE[.device]:[message].
```

The device can be anything with a status property, such as, for example, a node, a switch, or a chassis.

#### Example

```
echo "STATE.USERMESSAGE.node001:just right" > /var/spool/cmd/eventbucket
```

The state then shows as:

```
cmsh -c "device ; status node001"
node001 ..... (just right) [  UP  ]
```

If the device is not specified, then the current host of the shell that is executing the `echo` command is used. For example, running these commands from the head node, `bright80`, as follows:

#### Example

```
echo "STATE.USERMESSAGE:too hot" > /var/spool/cmd/eventbucket
ssh node001 'echo "STATE.USERMESSAGE:too cold" > /var/spool/cmd/eventbucket'
```

yields these states:

```
cmsh -c "device ; status bright80"
bright80 ..... (too hot) [  UP  ]
cmsh -c "device ; status node001"
node001 ..... (too cold) [  UP  ]
```

The added text can be cleared with echoing a blank message to that device. For example, for `node001` that could be:

```
echo "STATE.USERMESSAGE.node001:" > /var/spool/cmd/eventbucket
```



# 13

## Day-to-day Administration

This chapter discusses several tasks that may come up in day-to-day administration of a cluster running Bright Cluster Manager.

### 13.1 Parallel Shells: `pdsh` And `pexec`

#### What `pdsh` And `pexec` Do

The cluster management tools include two parallel shell execution commands:

- `pdsh` (parallel distributed shell, section 13.1.1), runs from within the OS shell. That is, `pdsh` executes its commands from within `bash` by default.
- `pexec` (parallel execute, section 13.1.2, runs from within `CMDaemon`. That is, `pexec` executes its commands from within the `cmsh` front end.

A one-time execution of `pdsh` or `pexec` can run one or more shell commands on a group of nodes in parallel.

#### A Warning About Power Surge Risks With `pdsh` And `pexec`

Some care is needed when running `pdsh` or `pexec` with commands that affect power consumption. For example, running commands that power-cycle devices in parallel over a large number of nodes can be risky because it can put unacceptable surge demands on the power supplies.

Within `cmsh`, executing a `power reset` command from `device` mode to power cycle a large group of nodes is much safer than running a parallel command to do a reset using `pdsh` or `pexec`. This is because the `CMDaemon` power reset powers up nodes after a deliberate delay between nodes (section 4.2).

#### Which Command To Use Out Of `pdsh` And `pexec`

The choice of using `pdsh` or `pexec` commands is mostly up to the administrator. The only time that running `pdsh` from `bash` is currently required instead of running `pexec` from within `cmsh`, is when stopping and restarting `CMDaemon` on a large number of regular nodes (section 2.6.1). This is because a command to stop `CMDaemon` on a regular node, that itself relies on being run from a running `CMDaemon` on a regular node, can obviously give unexpected results.

#### 13.1.1 `pdsh` In The OS Shell

##### Packages Required For `pdsh`

By default, the following packages must be installed from the Bright Cluster Manager repositories to the head node for `pdsh` to function fully:

- `pdsh`
- `genders`

- `pdsh-mod-cmupdown`
- `pdsh-mod-genders`
- `pdsh-rcmd-exec`
- `pdsh-ssh`

The `pdsh` utility is modular, that is, it gets extra functionality through the addition of modules.

The `genders` package is used to generate a default `/etc/genders` configuration file. The file is used to decide what and how nodes are to be used or excluded by default, when used with `pdsh`. Configuration details can be found in `man pdsh(1)`. The configuration can probably best be understood by viewing the file itself and noting that Bright Cluster Manager in the default configuration associates the following *genders* with a list of nodes:

- `all`: all the nodes in the cluster, head and regular nodes.
- `category=default`: the nodes that are in the default category
- `computenode`: regular nodes
- `headnode`: node or nodes that are head nodes.

In a newly-installed cluster using default settings, the `genders category=default` and `computenode` have the same list of nodes to begin with.

The default `/etc/genders` file has a section that is generated and maintained by `CMDaemon`, but the file can be altered by the administrator outside the `CMDaemon`-maintained section. However, it is not recommended to change the file manually frequently. For example, tracking node states with this file is not recommended. Instead, the package `pdsh-mod-cmupdown` provides the `-v` option for node state tracking functionality, and how to use this and other `pdsh` options is described in the next section.

### pdsh Options

In the OS shell, running `pdsh -h` displays the following help text:

```
Usage: pdsh [-options] command ...
-S          return largest of remote command return values
-h          output usage menu and quit
-V          output version information and quit
-q          list the option settings and quit
-b          disable ^C status feature (batch mode)
-d          enable extra debug information from ^C status
-l user     execute remote commands as user
-t seconds  set connect timeout (default is 10 sec)
-u seconds  set command timeout (no default)
-f n        use fanout of n nodes
-w host,host,... set target node list on command line
-x host,host,... set node exclusion list on command line
-R name     set rcmd module to name
-M name,... select one or more misc modules to initialize first
-N          disable hostname: labels on output lines
-L          list info on all loaded modules and exit
-v          exclude targets if they are down
-g query,... target nodes using genders query
-X query,... exclude nodes using genders query
-F file     use alternate genders file `file'
-i          request alternate or canonical hostnames if applicable
-a          target all nodes except those with "pdsh_all_skip" attribute
-A          target all nodes listed in genders database
available rcmd modules: ssh,exec (default: ssh)
```

Further options and details are given in `man pdsh(1)`.

### Examples Of pdsh Use

For the examples in this section, a cluster can be considered that is set up with two nodes, with the state of node001 being UP and that of node002 being DOWN:

```
[root@bright80 ~]# cmsh -c "device status"
node001 ..... [   UP   ]
node002 ..... [  DOWN  ]
bright80 ..... [   UP   ]
```

In the examples, the outputs for pdsh could be as follows for the pdsh options considered:

**-A:** With this pdsh option an attempt is made to run the command on all nodes, regardless of the node state:

#### Example

```
[root@bright80 ~]# pdsh -A hostname
node001: node001
node002: ssh: connect to host node002 port 22: No route to host
pdsh@bright80: node002: ssh exited with exit code 255
bright80: bright80
```

**-v:** With this option an attempt is made to run the command only on nodes nodes that are in the state UP:

#### Example

```
[root@bright80 ~]# pdsh -A -v hostname
node001: node001
bright80: bright80
```

**-g:** With this option, and using, for example, `computenode` as the genders query, only nodes within `computenode` in the `/etc/genders` file are considered for the command. The `-v` option then further ensures that the command runs only on a node in `computenode` that is up. In a newly-installed cluster, regular nodes are assigned to `computenode` by default, so the command runs on all regular nodes that are up in a newly-installed cluster:

#### Example

```
[root@bright80 ~]# pdsh -v -g computenode hostname
node001: node001
```

**-w:** This option allows a node list (`man pdsh(1)`) to be specified on the command line itself:

#### Example

```
[root@bright80 ~]# pdsh -w node00[1-2] hostname
node001: node001
node002: ssh: connect to host node002 port 22: No route to host
pdsh@bright80: node002: ssh exited with exit code 255
```

**-x:** This option is the converse of **-w**, and excludes a node list that is specified on the command line itself:

### Example

```
[root@bright80 ~]# pdsh -x node002 -w node00[1-2] hostname
node001: node001
```

### The dshbak Command

The **dshbak** (distributed shell backend formatting filter) command is a filter that reformats **pdsh** output. It comes with the **pdsh** package.

Running **dshbak** with the **-h** option displays:

```
[root@bright80 ~]# dshbak -h
Usage: dshbak [OPTION]...
-h          Display this help message
-c          Coalesce identical output from hosts
-d DIR      Send output to files in DIR, one file per host
-f          With -d, force creation of DIR
```

Further details can be found in `man dshbak(1)`.

For the examples in this section, it is assumed that all the nodes in the cluster are now up. That is, **node002** used in the examples of the preceding section is now also up. Some examples to illustrate how **dshbak** works are then the following:

### Without dshbak:

#### Example

```
[root@bright80 ~]# pdsh -A ls /etc/services /etc/yp.conf
bright80: /etc/services
bright80: /etc/yp.conf
node001: /etc/services
node001: ls: cannot access /etc/yp.conf: No such file or directory
pdsh@bright80: node001: ssh exited with exit code 2
node002: /etc/services
node002: /etc/yp.conf
```

### With dshbak, with no dshbak options:

#### Example

```
[root@bright80 ~]# pdsh -A ls /etc/services /etc/yp.conf | dshbak
node001: ls: cannot access /etc/yp.conf: No such file or directory
pdsh@bright80: node001: ssh exited with exit code 2
-----
bright80
-----
/etc/services
/etc/yp.conf
-----
node001
-----
/etc/services
-----
node002
```

```
-----
/etc/services
/etc/yp.conf
[root@bright80 ~]#
```

With dshbak, with the `-c` (coalesce) option:

#### Example

```
[root@bright80 ~]# pdsh -A ls /etc/services /etc/yp.conf | dshbak -c
node001: ls: cannot access /etc/yp.conf: No such file or directory
pdsh@bright80: node001: ssh exited with exit code 2
-----
node002,bright80
-----
/etc/services
/etc/yp.conf
-----
node001
-----
/etc/services
[root@bright80 ~]#
```

The dshbak utility is useful for creating human-friendly output in clusters with larger numbers of nodes.

### 13.1.2 pexec In cmsh

In cmsh, the pexec command is run from device mode:

#### Example

```
[bright80->device]% pexec -n node001,node002 "cd ; ls"

[node001] :
anaconda-ks.cfg
install.log
install.log.syslog

[node002] :
anaconda-ks.cfg
install.log
install.log.syslog
```

### 13.1.3 pexec In Bright View

In Bright View, pexec is hidden, but executed in a GUI wrapper, using the clickpath `Cluster→Run` command.

For large numbers of nodes, rendering the output into the node subpanes (little boxes) can take a long time. To improve the Bright View experience, selecting the `Single text` view icon instead of the `Grouped` view icon speeds up the rendering significantly, but at the cost of removing the borders of the subpanes.

Ticking the `Join output` checkbox places output that is the same for particular nodes, into the same subpane.

Running parallel shell commands from cmsh instead of in Bright View is faster in most cases, due to less graphics rendering overhead.

### 13.1.4 Using The `-j|-join` Option Of `pexec` In `cmsh`

The output of the `pexec` command by default can come out in a sequence depending on node response time. To make it more useful for an administrator, order can be imposed on the output. Checking consistency across nodes is then trivial. For example, to see if all nodes have the same mounts on a cluster with 10 nodes, of which `node002` is down:

#### Example

```
[bright80->device]% pexec -j -c default "mount|sort"
Nodes down:          node002
[node002]
Node down

[node001,node003..node010]
/dev/hda1 on / type ext3 (rw,noatime,nodiratime)
/dev/hda2 on /var type ext3 (rw,noatime,nodiratime)
/dev/hda3 on /tmp type ext3 (rw,nosuid,nodev,noatime,nodiratime)
/dev/hda6 on /local type ext3 (rw,noatime,nodiratime)
master:/cm/shared on /cm/shared type nfs
(rw,rsize=32768,wsiz=32768,hard,intr,addr=10.141.255.254)
master:/home on /home type nfs
(rw,rsize=32768,wsiz=32768,hard,intr,addr=10.141.255.254)
none on /dev/pts type devpts (rw,gid=5,mode=620)
none on /dev/shm type tmpfs (rw)
none on /proc/sys/fs/binfmt_misc type binfmt_misc (rw)
none on /proc type proc (rw,nosuid)
none on /sys type sysfs (rw)
```

Here, the `-j` option joins up identical fields (like the standard unix text utility, `join`). Additional order is imposed by sorting the output of each mount command within `bash` before the `-j` option operates from `cmsh`. The `-c` option executes the command on the `default` category of nodes.

### 13.1.5 Other Parallel Commands

Besides `pexec`, `CMDaemon` has several other parallel commands:

**pkill:** parallel kill

Synopsis:

```
pkill [OPTIONS] <tracker> [<tracker> ... ]
```

**plist:** List the parallel commands that are currently running, with their tracker ID

Synopsis:

```
plist
```

**pping:** ping nodes in parallel

Synopsis:

```
pping [OPTIONS]
```

**pwait:** wait for parallel commands that are running to complete

Synopsis:

```
pwait [OPTIONS] <tracker> [<tracker> ...]
```

Details on these parallel commands, including examples, can be seen by executing the `help` command within the `device` mode of `cmsh` for a parallel command, `<pcommand>`, as follows:



```
[bright80->device]%help <pcommand>
```

## 13.2 Getting Support With Cluster Manager Issues

Bright Cluster Manager is constantly undergoing development. While the result is a robust and well-designed cluster manager, it is possible that the administrator may run into a feature that requires technical help from Bright Computing or Bright Computing's resellers. This section describes how to get support for such issues.

### 13.2.1 Support Via E-mail

If the reseller from whom Bright Cluster Manager was bought offers direct support, then the reseller should be contacted.

Otherwise the primary means of support is via the website <https://support.brightcomputing.com>. This allows the administrator to submit a support request via a web form, and opens up a trouble ticket. It is a good idea to try to use a clear subject header, since that is used as part of a reference tag as the ticket progresses. Also helpful is a good description of the issue. The followup communication for this ticket goes via standard e-mail.

The document "How To Ask Questions The Smart Way" at <http://www.catb.org/esr/faqs/smart-questions.html> is quite readable, and explains how to submit a good technical query on online forums. While the document is not entirely relevant to the support provided by Bright Computing, it is true that many of the principles covered there are also useful when sending a query to Bright Computing when trying to resolve an issue. A read through the document may therefore be helpful before submitting a query to Bright Computing.

If the issue appears to be a bug, then a bug report should be submitted. It is helpful to include as many details as possible to ensure the development team is able to reproduce the apparent bug. The policy at Bright Computing is to welcome such reports, to provide feedback to the reporter, and to resolve the problem.

If there is apparently no response from Bright Computing over e-mail, checking the spam folder is advised. Mail providers have been known to flag mails as spam, even in mid-thread. Users in China should also be aware that mails from Bright Computing may be deleted by accident by the Golden Shield Project operated by the Chinese Ministry of Public Security.

As a supplement to e-mail support, Bright Computing also provides the `cm-diagnose` (section 13.2.2) and the `request-remote-assistance` (section 13.2.3) utilities to help resolve issues. The use of third-party screen-sharing utilities (section 13.2.4) is also possible.

### 13.2.2 Reporting Cluster Manager Diagnostics With `cm-diagnose`

The diagnostic utility `cm-diagnose` is run from the head node and gathers data on the system that may be of use in diagnosing issues. To view its options, capabilities, and defaults, it can be run as "`cm-diagnose --help`". For particular issues it may be helpful to change some of the default values to gather data in a more targeted way.

When run without any options, it runs interactively, and allows the administrator to send the resultant diagnostics file to Bright Computing directly. The output of a `cm-diagnose` session looks something like the following (the output has been made less verbose for easy viewing):

#### Example

```
[root@bright80 ~]# cm-diagnose
To be able to contact you about the issue, please provide
your e-mail address (or support ticket number, if applicable):
franknfurter@example.com
```

```
To diagnose any issue, it would help if you could provide a description
about the issue at hand.
```

```

Do you want to enter such description? [Y/n]

End input with ctrl-d
I tried X, Y, and Z on the S2464 motherboard. When that didn't work, I
tried A, B, and C, but the florbish is grommicking.
Thank you.

If issues are suspected to be in the cmdaemon process, a gdb trace of
that process is useful.
In general such a trace is only needed if Bright Support asks for this.
Do you want to create a gdb trace of the running CMDaemon? [y/N]

Proceed to collect information? [Y/n]

Processing master
  Processing commands
  Processing file contents
  Processing large files and log files
  Collecting process information for CMDaemon
  Executing CSMH commands
  Finished executing CSMH commands

Processing default-image
  Processing commands
  Processing file contents

Creating log file: /root/bright80_609.tar.gz

Cleaning up

Automatically submit diagnostics to
http://support.brightcomputing.com/cm-diagnose/ ? [Y/n] y

Uploaded file: bright80_609.tar.gz
Remove log file (/root/bright80_609.tar.gz)? [y/N] y
[root@bright80 ~]

```

### 13.2.3 Requesting Remote Support With `request-remote-assistance`

During the process of solving a ticket, a lengthy and time-consuming e-mail exchange between the cluster administrator and Bright Computing may be required before a resolution to the issue is reached. The `request-remote-assistance` utility can be run after a ticket has been opened up for a case, and speeds up resolution by avoiding this exchange, so is generally recommended to obtain the quickest resolution for such problems.

The `request-remote-assistance` utility allows a Bright Computing engineer to securely tunnel into the cluster without a change in firewall or `ssh` settings of the cluster.

With `request-remote-assistance`:

- It must be allowed to access the `www` and `ssh` ports of Bright Computing's internet servers.
- For some problems, the engineer may wish to power cycle a node. In that case, indicating what node the engineer can power cycle should be added to the option for entering additional information.
- Administrators familiar with `screen` may wish to run it within a `screen` session and detach it.

It is run as follows:

### Example

```
[root@bright80 ~]# request-remote-assistance

This tool helps securely set up a temporary ssh tunnel to
sandbox.brightcomputing.com.

Allow a Bright Computing engineer ssh access to the cluster? [Y/n]

Enter additional information for Bright Computing (eg: related
ticket number, problem description)? [Y/n]

End input with ctrl-d
Ticket 1337 - the florbish is grommicking

Thank you.

Added temporary Bright public key.
```

After the administrator has responded to the `Enter additional information...` entry, and has typed in the `ctrl-d`, the utility tries to establish the connection. The screen clears, and the secure tunnel opens up, displaying the following notice:

```
REMOTE ASSISTANCE REQUEST
#####
A connection has been opened to Bright Computing Support.
Closing this window will terminate the remote assistance
session.
-----

Hostname: bright80.NOFQDN
Connected on port: 7000

ctrl-c to terminate this session
```

Bright Computing support automatically receives an e-mail alert that an engineer can now securely tunnel into the cluster. The session activity is not explicitly visible to the administrator. When the engineer has ended the session, the administrator may remove the secure tunnel with a `ctrl-c`, and the display then shows:

```
Tunnel to sandbox.brightcomputing.com terminated.
Removed temporary Bright public key.
[root@bright80 ~]#
```

The Bright Computing engineer is then no longer able to access the cluster.

The preceding tunnel termination output may also show up automatically, without a `ctrl-c` from the administrator, within seconds after the connection session starts. In that case, it typically means that a firewall is blocking access to SSH and WWW to Bright Computing's internet servers.

### 13.2.4 Requesting Remote Support With A Shared Screen Utility

If the `request-remote-assistance` utility (section 13.2.3) is restricted or otherwise disallowed by the site policy, then it may be permitted to allow a Bright support engineer to access the site using a third party shared screen utility that the administrator is comfortable with. In that case, possible options include:

- Zoom (preferred)

- WebEx
- join.me

Other screensharing options may also be possible. The support engineer and the administrator need to agree upon the option to be used, and decide upon a time (and time zone) for the shared screen session.

## 13.3 Backups

### 13.3.1 Cluster Installation Backup

Bright Cluster Manager does not include facilities to create backups of a cluster installation. A clone of the head node can however be created by PXE booting the new head node, and following the procedure in section 15.4.8.

When setting up a backup mechanism, it is recommended that the full filesystem of the head node (i.e. including all software images) is backed up. Unless the regular node hard drives are used to store important data, it is not necessary to back them up.

If no backup infrastructure is already in place at the cluster site, the following open source (GPL) software packages may be used to maintain regular backups:

- **Bacula:** Bacula is a mature network based backup program that can be used to backup to a remote storage location. If desired, it is also possible to use Bacula on nodes to back up relevant data that is stored on the local hard drives. More information is available at <http://www.bacula.org>

Bacula requires ports 9101-9103 to be accessible on the head node. Including the following lines in the Shorewall rules file for the head node allows access via those ports from an IP address of 93.184.216.34 on the external network:

#### Example

```
ACCEPT net:93.184.216.34 fw tcp 9101
ACCEPT net:93.184.216.34 fw tcp 9102
ACCEPT net:93.184.216.34 fw tcp 9103
```

The Shorewall service should then be restarted to enforce the added rules.

- **rsnapshot:** rsnapshot allows periodic incremental filesystem snapshots to be written to a local or remote filesystem. Despite its simplicity, it can be a very effective tool to maintain frequent backups of a system. More information is available at <http://www.rsnapshot.org>.

Rsnapshot requires access to port 22 on the head node.

### 13.3.2 Local Database And Data Backups And Restoration

The CMDaemon database is stored in the MySQL `cmdaemon` database, and contains most of the stored settings of the cluster.

Monitoring data values are stored as binaries in the filesystem, under `/var/spool/cmd/monitoring`.

The administrator is expected to run a regular backup mechanism for the cluster to allow restores of all files from a recent snapshot. As an additional, separate, convenience:

- For the CMDaemon database, the entire database is also backed up nightly on the cluster filesystem itself ("local rotating backup") for the last 7 days.
- For the monitoring data, the raw data records are not backed up locally, since these can get very large. However, the configuration of the monitoring data, which is stored in the CMDaemon database, is backed up for the last 7 days too.

### Database Corruption Messages And Repairs

A corrupted MySQL database is commonly caused by an improper shutdown of the node. To deal with this, when starting up, MySQL checks itself for corrupted tables, and tries to repair any such by itself. Detected corruption causes an event notice to be sent to cmsh or Bright View.

When there is database corruption, InfoMessages in the `/var/log/cmdaemon` log may mention:

- “Unexpected eof found” in association with a table in the database,
- “can’t find file” when referring to an entire missing table,
- locked tables,
- error numbers from table handlers,
- “Error while executing” a command.

If a basic repair is to be carried out on a database, CMDaemon should first be stopped.

#### Example

```
[root@headnode ~]# service cmd stop
[root@headnode ~]# myisamchk --recover /var/lib/mysql/mysql/user.MYI
[root@headnode ~]# service cmd start
```

If basic repair fails, more extreme repair options—`man myisamchk(1)` suggests what—can then be tried out.

Another example: If CMDaemon is unable to start up due to a corrupted database, then messages in the `/var/log/cmdaemon` file might show something like:

#### Example

```
Oct 11 15:48:19 solaris CMDaemon: Info: Initialize cmdaemon database
Oct 11 15:48:19 solaris CMDaemon: Info: Attempt to set provisioningNetwo\
rk (280374976710700) not an element of networks
Oct 11 15:48:19 solaris CMDaemon: Fatal: Database corruption! Load Maste\
rNode with key: 280374976782569
Oct 11 15:48:20 solaris CMDaemon: Info: Sending reconnect command to all\
nodes which were up before master went down ...
Oct 11 15:48:26 solaris CMDaemon: Info: Reconnect command processed.
```

Here it is CMDaemon’s “Database corruption” message that the administrator should be aware of, and which suggests database repairs are required for the CMDaemon database. The severity of the corruption, in this case not even allowing CMDaemon to start up, may mean a restoration from backup is needed. How to restore from backup is explained in the next section.

### Restoring From The Local Backup

If the MySQL database repair tools of the previous section do not fix the problem, then, for a failover configuration, the `dbreclone` option (section 15.4.2) should normally provide a CMDaemon database that is current.

**Cloning extra databases:** The file `/cm/local/apps/cluster-tools/ha/conf/extradbclone.xml.template` can be used as a template to create a file `extradbclone.xml` in the same directory. The `extradbclone.xml` file can then be used to define additional databases to be cloned. Running the `/cm/local/apps/cmd/scripts/cm-update-mycnf` script then updates `/etc/my.cnf`. The database can then be cloned with this new MySQL configuration by running

```
cmha dbreclone <passive>
```

where *<passive>* is the hostname of the passive headnode.

If the head node is not part of a failover configuration, then a restoration from local backup can be done. The local backup directory is `/var/spool/cmd/backup`, with contents that look like (some text elided):

### Example

```
[root@solaris ~]# cd /var/spool/cmd/backup/
[root@solaris backup]# ls -l
total 280
...
-rw----- 1 root root 33804 Oct 10 04:02 backup-Mon.sql.gz
-rw----- 1 root root 33805 Oct 9 04:02 backup-Sun.sql.gz
-rw----- 1 root root 33805 Oct 11 04:02 backup-Tue.sql.gz
...
```

The CMDaemon database snapshots are stored as `backup-<day of week>.sql.gz`. In the example, the latest backup available in the listing for CMDaemon turns out to be `backup-Tue.sql.gz`.

The latest backup can then be ungzipped and piped into the MySQL database for the user `cmdaemon`. The password, *<password>*, can be retrieved from `/cm/local/apps/cmd/etc/cmd.conf`, where it is configured in the `DBPass` directive (Appendix C).

### Example

```
gunzip backup-Tue.sql.gz
service cmd stop #(just to make sure)
mysql -ucmdaemon -p<password> cmdaemon < backup-Tue.sql
```

Running “`service cmd start`” should have CMDaemon running again, this time with a restored database from the time the snapshot was taken. That means, that any changes that were done to the cluster manager after the time the snapshot was taken are no longer implemented.

Monitoring data is not kept in a database, but in files (section 13.8).

## 13.4 Revision Control For Images

Bright Cluster Manager 7 introduced support for the implementations of Btrfs provided by the distributions. Btrfs makes it possible to carry out revision control for images efficiently.

### 13.4.1 Btrfs: The Concept And Why It Works Well In Revision Control For Images

Btrfs, often pronounced “butter FS”, is a Linux implementation of a copy-on-write (COW) filesystem.

A COW design for a filesystem follows the principle that, when blocks of old data are to be modified, then the new data blocks are written in a new location (the COW action), leaving the old, now superseded, copy of the data blocks still in place. Metadata is written to keep track of the event so that, for example, the new data blocks can be used seamlessly with the contiguous old data blocks that have not been superseded.

This is in contrast to the simple overwriting of old data that a non-COW filesystem such as Ext3fs carries out.

A result of the COW design means that the old data can still be accessed with the right tools, and that rollback and modification become a natural possible feature.

“Cheap” *revision control* is thus possible.

Revision control for the filesystem is the idea that changes in the file system are tracked and can be rolled back as needed. “Cheap” here means that COW makes tracking changes convenient, take up very little space, and quick. For an administrator of Bright Cluster Manager, cheap revision control is interesting for the purpose of managing software images.

This is because for a non-COW filesystem such as Ext3fs, image variations take a large amount of space, even if the variation in the filesystem inside the image is very little. On the other hand, image variations in a COW filesystem such as Btrfs take up near-minimum space.

Thus, for example, the technique of using initialize and finalize scripts to generate such image variations on the fly (section 3.15.4) in order to save space, can be avoided by using a Btrfs partition to save the full image variations instead.

“Expensive” revision control on non-COW filesystems is also possible. It is merely not recommended, since each disk image takes up completely new blocks, and hence uses up more space. The administrator will then have to consider that the filesystem may become full much earlier. The degree of restraint on revision control caused by this, as well as the extra consumption of resources, means that revision control on non-COW filesystems is best implemented on test clusters only, rather than on production clusters.

### 13.4.2 Btrfs Availability And Distribution Support

Btrfs has been part of the Linux kernel since kernel 2.6.29-rc1. Depending on which Linux distribution is being used on a cluster, it may or may not be a good idea to use Btrfs in a production environment, as in the worst case it could lead to data loss.

Btrfs is available from Red Hat as a technology preview release in versions 6 and 7 for now. That means it is not officially supported by Red Hat. The Btrfs version used in the 2.6 kernel series, used by RHEL6.x is quite old, which means that it may not be fully stable. Btrfs users who would like significantly more features and stability will prefer the 3.x kernel series, used by RHEL7.x. Btrfs has been deprecated since RHEL7.4.

Btrfs is also available from SUSE. SLES12 uses a 3.12 series kernel, which has a fully stable and supported implementation of Btrfs.

While Bright Computing has not experienced any problems with storing software images on Btrfs using RHEL6, it is highly advisable to keep backups of important software images on a non-Btrfs filesystems when Btrfs is used on these Linux distributions.

An issue with using `cm-clone-install` with Btrfs is described on page 561.

### 13.4.3 Installing Btrfs To Work With Revision Control Of Images In Bright Cluster Manager

#### Installation Of `btrfs-progs`

To install a Btrfs filesystem, the `btrfs-progs` packages must be installed from the distribution repository first (some lines elided):

#### Example

```
[root@bright80 ~]# yum install btrfs-progs
...
Resolving Dependencies
--> Running transaction check
---> Package btrfs-progs.x86_64 0:0.20-0.2.git91d9eec.el6 will be installed
...
Total download size: 297 k
Installed size: 2.4 M
...
Complete!
```

#### Creating A Btrfs Filesystem

The original images directory can be moved aside first, and a new images directory created to serve as a future mount point for Btrfs:

### Example

```
[root@bright80 ~]# cd /cm/
[root@bright80 cm]# mv images images2
[root@bright80 cm]# mkdir images
```

A block device can be formatted as a Btrfs filesystem in the usual way by using the `mkfs.btrfs` command on a partition, and then mounted to the new images directory:

### Example

```
[root@bright80 cm]# mkfs.btrfs /dev/sdc1
[root@bright80 cm]# mount /dev/sdc1 /cm/images
```

If there is no spare block device, then, alternatively, a file with zeroed data can be created, formatted as a Btrfs filesystem, and mounted as a loop device like this:

### Example

```
[root@bright80 cm]# dd if=/dev/zero of=butter.img bs=1G count=20
20+0 records in
20+0 records out
21474836480 bytes (21 GB) copied, 916.415 s, 23.4 MB/s
[root@bright80 cm]# mkfs.btrfs butter.img
```

```
WARNING! - Btrfs Btrfs v0.20-rc1 IS EXPERIMENTAL
WARNING! - see http://btrfs.wiki.kernel.org before using
```

```
fs created label (null) on butter.img
        nodesize 4096 leafsize 4096 sectorsize 4096 size 20.00GB
Btrfs Btrfs v0.20-rc1
[root@bright80 cm]# mount -t btrfs butter.img images -o loop
[root@bright80 cm]# mount
...
/cm/butter.img on /cm/images type btrfs (rw,loop=/dev/loop0)
```

### Migrating Images With `cm-migrate-images`

The entries inside the `/cm/images/` directory are the software images (file trees) used to provision nodes.

Revision tracking of images in a Btrfs filesystem can be done by making the directory of a specific image a *subvolume*. Subvolumes in Btrfs are an extension of standard unix directories with versioning. The files in a subvolume are tracked with special internal Btrfs markers.

To have this kind of version tracking of images work, image migration cannot simply be done with a `cp -a` or a `mv` command. That is, moving images from the `images2` directory in the traditional filesystem, over to images in the `images` directory in the Btrfs filesystem command with the standard `cp` or `mv` command is not appropriate. This is because the images are to be tracked once they are in the Btrfs system, and are therefore not standard files any more, but instead extended, and made into subvolumes.

The migration for Bright Cluster Manager software images can be carried out with the utility `cm-migrate-image`, which has the usage:

```
cm-migrate-image <path to old image> <path to new image>
```

where the old image is a traditional directory, and the new image is a subvolume.

### Example



```
[root@bright80 cm]# cm-migrate-image /cm/images2/default-image /cm/images/default-image
```

The `default-image` directory, or more exactly, subvolume, must not exist in the Btrfs filesystem before the migration. The subvolume is created only for the image basename that is migrated, which is `default-image` in the preceding example.

In the OS, the `btrfs` utility is used to manage Btrfs. Details on what it can do can be seen in the `btrfs(8)` man page. The state of the loop filesystem can be seen, for example, with:

### Example

```
[root@bright80 cm]# btrfs filesystem show /dev/loop0
Label: none  uuid: 6f94de75-2e8d-45d2-886b-f87326b73474
    Total devices 1 FS bytes used 3.42GB
    devid    1 size 20.00GB used 6.04GB path /dev/loop0
```

```
Btrfs Btrfs v0.20-rc1
```

```
[root@bright80 cm]# btrfs subvolume list /cm/images
ID 257 gen 482 top level 5 path default-image
```

The filesystem can be modified as well as merely viewed with `btrfs`. However, instead of using the utility to modify image revisions directly, it is recommended that the administrator use Bright Cluster Manager to manage image version tracking, since the necessary functionality has been integrated into `cmsh` and Bright View.

### 13.4.4 Using `cmsh` For Revision Control Of Images

#### Revision Control Of Images Within `softwareimage` Mode

The following commands and extensions can be used for revision control in the `softwareimage` mode of `cmsh`:

- `newrevision <parent software image name> "textual description"`  
Creates a new revision of a specified software image. For that new revision, a revision number is automatically generated and saved along with time and date. The new revision receives a name of the form:

`<parent software image name>@<revision number>`

A new Btrfs subvolume:

`/cm/images/<parent software image name>-<revision number>`

is created automatically for the revision. From now on, this revision is a self-contained software image and can be used as such.

- `revisions [-a|--all] <parent software image name>`  
Lists all revisions of specified parent software image in the order they were created, and associates the revision with the revision number under the header ID. The option `-a|--all` also lists revisions that have been removed.
- `list [-r|--revisions]`  
The option `-r|--revisions` has been added to the `list` command. It lists all revisions with their name, path, and kernel version. A parent image is the one at the head of the list of revisions, and does not have `@<revision number>` in its name.
- `setparent [parent software image name] <revision name>`  
Sets a revision as a new parent. The action first saves the image directory of the current, possibly altered, parent directory or subvolume, and then attempts to copy or snapshot the directory or

subvolume of the revision into the directory or subvolume of the parent. If the attempt fails, then it tries to revert all the changes in order to get the directory or subvolume of the parent back to the state it was in before the attempt.

- `remove [-a|--all] [-d|--data] <parent software image name>`  
Running `remove` without options removes the parent software image. The option `-a|--all` removes the parent and all its revisions. The option `-d|--data` removes the actual data. To run the `remove` command, any images being removed should not be in use.

### Revision Control Of Images Within category Mode

The `category` mode of `cmsh` also supports revision control.

Revision control can function in 3 kinds of ways when set for the `softwareimage` property at category level.

To explain the settings, an example can be prepared as follows: It assumes a newly-installed cluster with Btrfs configured and `/cm/images` migrated as explained in section 13.4.3. The cluster has a default software image `default-image`, and two revisions of the parent image are made from it. These are automatically given the paths `default-image@1` and `default-image@2`. A category called `storage` is then created:

#### Example

```
[bright80->softwareimage]% newrevision default-image "some changes"
[bright80->softwareimage]% newrevision default-image "more changes"
[bright80->softwareimage]% revisions default-image
ID      Date                               Description
-----
1       Wed, 07 May 2014 05:28:06 PDT    some changes
2       Wed, 07 May 2014 05:28:55 PDT    more changes
[bright80->softwareimage]% list -r
Name (key)      Path                               Kernel version
-----
default-image   /cm/images/default-image          2.6.32-431.11.2.el6.x86_64
default-image@1 /cm/images/default-image-1        2.6.32-431.11.2.el6.x86_64
default-image@2 /cm/images/default-image-2        2.6.32-431.11.2.el6.x86_64
[bright80->softwareimage]% category add storage; commit
```

With the cluster set up like that, the 3 kinds of revision control functionalities in `category` mode can be explained as follows:

#### 1. Category revision control functionality is defined as unset

If the administrator sets the `softwareimage` property for the category to an image without any revision tags:

#### Example

```
[bright80->category]% set storage softwareimage default-image
```

then nodes in the `storage` category take no notice of the revision setting for the image set at category level.

#### 2. Category revision control sets a specified revision as default

If the administrator sets the `softwareimage` property for the category to a specific image, with a revision tag, such as `default-image@1`:

**Example**

```
[bright80->category]% set storage softwareimage default-image@1
```

then nodes in the `storage` category use the image `default-image@1` as their image if nothing is set at node level.

**3. Category revision control sets the latest available revision by default**

If the administrator sets the `softwareimage` property for the category to a parent image, but tagged with the reserved keyword `tag latest`:

**Example**

```
[bright80->category]% set storage softwareimage default-image@latest
```

then nodes in the `storage` category use the image `default-image@2` if nothing is set at node level. If a new revision of `default-image` is created later on, with a later tag (`@3`, `@4`, `@5...`) then the property takes the new value for the revision, so that nodes in the category will use the new revision as their image.

**Revision Control For Images—An Example Session**

This section uses a session to illustrate how image revision control is commonly used, with commentary along the way. It assumes a newly installed cluster with Btrfs configured and `/cm/images` migrated as explained in section 13.4.3.

First, a revision of the image is made to save its initial state:

```
[bright80->softwareimage]% newrevision default-image "Initial state"
```

A new image `default-image@1` is automatically created with a path `/cm/images/default-image-1`. The path is also a subvolume, since it is on a Btrfs partition.

The administrator then makes some modifications to the parent image `/cm/images/default-image`, which can be regarded as a “trunk” revision, for those familiar with SVN or similar revision control systems. For example, the administrator could install some new packages, edit some configuration files, and so on. When finished, a new revision is created by the administrator:

```
[bright80->softwareimage]% newrevision default-image "Some modifications"
```

This image is then automatically called `default-image@2` and has the path `/cm/images/default-image-2`. If the administrator then wants to test the latest revision on nodes in the `default` category, then this new image can be set at category level, without having to specify it for every node in that category individually:

```
[bright80->category]% set default softwareimage default-image@2
```

At this point, the content of `default-image` is identical to `default-image@2`. But changes done in `default-image` will not affect what is stored in revision `default-image@2`.

After continuing on with the parent image based on the revision `default-image@2`, the administrator might conclude that the modifications tried are incorrect or not wanted. In that case, the administrator can roll back the state of the parent image `default-image` back to the state that was previously saved as the revision `default-image@1`:

```
[bright80->softwareimage]% setparent default-image default-image@1
```

The administrator can thus continue experimenting, making new revisions, and trying them out by setting the `softwareimage` property of a category accordingly. Previously created revisions `default-image@1` and `default-image@2` will not be affected by these changes. If the administrator would like to completely purge a specific unused revision, such as `default-image@2` for example, then it can be done with the `-d|--data` option:

```
[bright80->softwareimage]% remove -d default-image@2
```

The `-d` does a forced recursive removal of the `default-image-2` directory, while a plain `remove` without the `-d` option would simply remove the object from `CMDaemon`, but leave `default-image-2` alone. This `CMDaemon` behavior is not unique for `Btrfs`—it is true for traditional filesystems too. It is however usually very wasteful of storage to do this with non-COW systems.

## 13.5 BIOS Configuration And Updates

Bright Cluster Manager includes a number of tools that can be used to configure and update the BIOS of nodes. All tools are located in the `/cm/shared/apps/cmbios/nodebios` directory on the head node. The remainder of this section assumes that this directory is the current working directory.

Due to the nature of BIOS updates, it is highly recommended that these tools are used with great care. Incorrect use may render nodes unusable.

Updating a BIOS of a node requires booting it from the network using a specially prepared DOS image. From the `autoexec.bat` file, one or multiple automated BIOS operations can be performed.

### 13.5.1 BIOS Configuration

In order to configure the BIOS on a group of nodes, an administrator needs to manually configure the BIOS on a reference node using the conventional method of entering BIOS Setup mode at system boot time. After the BIOS has been configured, the machine needs to be booted as a node. The administrator may subsequently use the `cmospull` utility on the node to create a snapshot of the reference node's NVRAM contents.

#### Example

```
ssh node001 /cm/shared/apps/cmbios/nodebios/cmospull > node001.nvram
```

After the NVRAM settings of the reference node have been saved to a file, the settings need to be copied to the generic DOS image so that they can be written to the NVRAM of the other nodes.

The generic DOS image is located in `/cm/shared/apps/cmbios/nodebios/win98boot.img`. It is generally a good idea to copy the generic image and make changes to the copy only.

#### Example

```
cp -a win98boot.img flash.img
```

To modify the image, it is first mounted:

```
mount -o loop flash.img /mnt
```

When the DOS image has been mounted, the utility that writes out the NVRAM data needs to be combined with the NVRAM data into a single DOS executable. This is done by appending the NVRAM data to the `cmosprog.bin` file. The result is a DOS `.COM` executable.

#### Example

```
cat cmosprog.bin node001.nvram > cmosprog.com
```

The generated `.COM` is then copied to the image and should be started from the `autoexec.bat` file. Note that DOS text files require a carriage return at the end of every line.

### Example

```
cp cmosprom.com /mnt
/bin/echo -e "A:\\\\cmosprom.com\r" >> /mnt/autoexec.bat
```

After making the necessary changes to the DOS image, it is unmounted:

```
umount /mnt
```

After preparing the DOS image, it is booted as described in section 13.5.3.

### 13.5.2 Updating BIOS

Upgrading the BIOS to a new version involves using the DOS tools that were supplied with the BIOS. Similar to the instructions above, the flash tool and the BIOS image must be copied to the DOS image. The file `autoexec.bat` should be altered to invoke the flash utility with the correct parameters. In case of doubt, it can be useful to boot the DOS image and invoke the BIOS flash tool manually. Once the correct parameters have been determined, they can be added to the `autoexec.bat`.

After a BIOS upgrade, the contents of the NVRAM may no longer represent a valid BIOS configuration because different BIOS versions may store a configuration in different formats. It is therefore recommended to also write updated NVRAM settings immediately after flashing a BIOS image (section 13.5.1).

The next section describes how to boot the DOS image.

### 13.5.3 Booting DOS Image

To boot the DOS image over the network, it first needs to be copied to software image's `/boot` directory, and must be world-readable.

### Example

```
cp flash.img /cm/images/default-image/boot/bios/flash.img
chmod 644 /cm/images/default-image/boot/bios/flash.img
```

An entry is added to the PXE boot menu to allow the DOS image to be selected. This can easily be achieved by modifying the contents of `/cm/images/default-image/boot/bios/menu.conf`, which is by default included automatically in the PXE menu. By default, one entry `Example` is included in the PXE menu, which is however invisible as a result of the `MENU HIDE` option. Removing the `MENU HIDE` line will make the BIOS flash option selectable. Optionally the `LABEL` and `MENU LABEL` may be set to an appropriate description.

The option `MENU DEFAULT` may be added to make the BIOS flash image the default boot option. This is convenient when flashing the BIOS of many nodes.

### Example

```
LABEL FLASHBIOS
  KERNEL memdisk
  APPEND initrd=bios/flash.img
  MENU LABEL ^Flash BIOS
#  MENU HIDE
  MENU DEFAULT
```

The `bios/menu.conf` file may contain multiple entries corresponding to several DOS images to allow for flashing of multiple BIOS versions or configurations.

### 13.6 Hardware Match Check With The `hardware-profile` Data Producer

Often a large number of identical nodes may be added to a cluster. In such a case it is a good practice to check that the hardware matches what is expected. This can be done easily as follows:

1. The new nodes, say node129 to node255, are committed to a newly-created category `newbunch` as follows (output truncated):

```
[root@bright80 ~]# cmsh -c "category add newbunch; commit"
[root@bright80 ~]# for i in {129..255}
> do
> cmsh -c "device; set node00$i category newbunch; commit"
> done
Successfully committed 1 Devices
Successfully committed 1 Devices
```

For larger clusters, reducing the time wasted in opening up `cmsh` can be done by replacing the offending `for` loop with a construction that is more elegant, but less familiar to most people:

```
[root@bright80 ~]# for ((i=129; i<=255; i++)) do echo "
> device
> set node00$i category newbunch
> commit"; done | cmsh
```

2. The hardware profile of one of the new nodes, say node129, is saved into the category `newbunch`. This is done using the `node-hardware-profile` health check script:

#### Example

```
[root@bright80 ~]# /cm/local/apps/cmd/scripts/healthchecks/node-hardware-pr\
ofile -n node129 -s newbunch
```

The profile is intended to be the reference hardware against which all the other nodes should match, and is saved under the directory `/cm/shared/apps/cmd/hardware-profiles/`, and further under the directory name specified by the `-s` option, which in this case is `newbunch`.

3. The `hardware-profile` data producer (section 12.2.10) can then be enabled, and the sampling frequency set as follows:

```
[root@bright80 ~]# cmsh
[bright80]% monitoring setup use hardware-profile
[bright80->monitoring->setup[hardware-profile]]% set interval 600; set disabled no; commit
```

The `hardware-profile` data producer should also be set to the category `newbunch` created in the earlier step. This can be done by creating a category group within the `nodeexecutionfilters` submodule. Within that group, categories can be set for where the hardware check is to run. For the example, it is just run on one category, `newbunch`:

```
[bright80->monitoring->setup[hardware-profile]]% nodeexecutionfilters
[bright80->...-profile->nodeexecutionfilters]% add category filterhwp
[bright80->...-profile->nodeexecutionfilters*[filterhwp*]]% set categories newbunch
[bright80->...-profile->nodeexecutionfilters*[filterhwp*]]% commit
```

4. `CMDaemon` then automatically alerts the administrator if one of the nodes does not match the hardware of that category during the first automated check. In the unlikely case that the reference node is itself faulty, then that will also be obvious because all—or almost all, if more nodes are faulty—of the other nodes in that category will then be reported “faulty” during the first check.

## 13.7 Serial Over LAN Console Access

Direct console access to nodes is not always possible. Other possibilities to access the node are:

1. **SSH access via an ssh client.** This requires that an `ssh` server runs on the node and that it is accessible via the network. Access can be via one of the following options:
  - a regular SSH client, run from a `bash` shell
  - via an `ssh` command run from the `device` mode of `cmsh`
  - via an `ssh` terminal launched from Bright View via the clickpath:  
`Devices→Nodes→node→Connect→ssh.`
2. **Remote shell via CMDaemon.** This is possible if CMDaemon is running on the node and accessible via Bright View or `cmsh`.
  - An interactive root shell session can be started up on a node via the clickpath:  
`Devices→Nodes→node→Connect→Root shell.`  
This session is connected to the node via CMDaemon, and runs `bash` by default.
  - For `cmsh`, in `device` mode, running the command `rshell node001` launches an interactive `bash` session connected to `node001` via CMDaemon.
3. **Connecting via a serial over LAN console.** If a serial console is configured, then a serial over LAN (SOL) console can be accessed from `cmsh` (`rconsole`).

Item 3 in the preceding list, SOL access, is very useful for administrators, and is covered next more thoroughly with:

- some background notes on serial over LAN console access (section 13.7.1)
- the configuration of SOL with `cmsh` (section 13.7.3)
- the `conman` SOL logger and viewer (section 13.7.4)

### 13.7.1 Background Notes On Serial Console And SOL

Serial ports are data ports that can usually be enabled or disabled for nodes in the BIOS.

If the serial port of a node is enabled, it can be configured in the node kernel to redirect a console to the port. The serial port can thus provide what is called serial console access. That is, the console can be viewed using a terminal software such as `minicom` (in Linux) or `Hyperterminal` (in Windows) on another machine to communicate with the node via the serial port, using a null-modem serial cable. This has traditionally been used by system administrators when remote access is otherwise disabled, for example if `ssh` access is not possible, or if the TCP/IP network parameters are not set up right.

While traditional serial port console access as just described can be useful, it is inconvenient, because of having to set arcane serial connection parameters, use the relatively slow serial port and use a special serial cable. Serial Over LAN (SOL) is a more recent development of serial port console access, which uses well-known TCP/IP networking over a faster Ethernet port, and uses a standard Ethernet cable. SOL is thus generally more convenient than traditional serial port console access. The serial port DB-9 or DB-25 connector and its associated 16550 UART chip rarely exist on modern servers that support SOL, but they are nonetheless usually implied to exist in the BIOS, and can be “enabled” or “disabled” there, thus enabling or disabling SOL.

SOL is a feature of the BMC (Baseboard Management Controller) for IPMI 2.0 and iLO. It is enabled by configuring the BMC BIOS. When enabled, data that is going to the BMC serial port is sent to the BMC LAN port. SOL clients can then process the LAN data to display the console. As far as the node kernel is concerned, the serial port is still just behaving like a serial port, so no change needs to be made in kernel configuration in doing whatever is traditionally done to configure serial connectivity. However, the console is now accessible to the administrator using the SOL client on the LAN.

SOL thus allows SOL clients on the LAN to access the Linux serial console if

1. SOL is enabled and configured in the BMC BIOS
2. the serial console is enabled and configured in the node kernel
3. the serial port is enabled and configured in the node BIOS

The BMC BIOS, node kernel, and node BIOS therefore all need to be configured to implement SOL console access.

**Background Notes: BMC BIOS Configuration**

The BMC BIOS SOL values are usually enabled and configured as a submenu or pop-up menu of the node BIOS. These settings must be manually made to match the values in Bright Cluster Manager, or vice versa.

During a factory reset of the node, it is likely that a SOL configuration in the cluster manager will no longer match the configuration on the node BIOS after the node boots. This is because the cluster manager cannot configure these. This is in contrast to the IP address and user authentication settings of the BMC (section 3.7), which the cluster manager is able to configure on reboot.

**Background Notes: Node Kernel Configuration**

Section 13.7.3 explains how SOL access configuration is set up for the node kernel using `cmsh`. SOL access configuration on the node kernel is serial access configuration on the node kernel as far as the system administrator is concerned; the only difference is that the word “serial” is replaced by “SOL” in Bright Cluster Manager’s `cmsh` front end to give a cluster perspective on the configuration.

**Background Notes: Node BIOS Configuration**

Since BIOS implementations vary, and serial port access is linked with SOL access in various ways by the BIOS designers, it is not possible to give short and precise details on how to enable and configure them. The following rules-of-thumb, if followed carefully, should allow most BMCs to be configured for SOL access with Bright Cluster Manager:

- Serial access, or remote access via serial ports, should be enabled in the BIOS, if such a setting exists.
- The node BIOS serial port settings should match the node configuration SOL settings (section 13.7.3). That means, items such as “SOL speed”, “SOL Flow Control”, and “SOL port” in the node configuration must match the equivalent in the node BIOS. Reasonable values are:
  - SOL speed: 115200bps. Higher speeds are sometimes possible, but are more likely to have problems.
  - SOL flow control: On. It is however unlikely to cause problems if flow control is off in both.
  - SOL port: COM1 (in the BIOS serial port configuration), corresponding to `ttyS0` (in the node kernel serial port configuration). Alternatively, COM2, corresponding to `ttyS1`. Sometimes, the BIOS configuration display indicates SOL options with options such as: “COM1 as SOL”, in which case such an option should be selected for SOL connectivity.
  - Terminal type: VT100 or ANSI.
- If there is an option for BIOS console redirection after BIOS POST, it should be disabled.
- If there is an option for BIOS console redirection before or during BIOS POST, it should be enabled.
- The administrator should be aware that the BMC LAN traffic, which includes SOL traffic, can typically run over a dedicated NIC or over a shared NIC. The choice of dedicated or shared is toggled, either in the BIOS, or via a physical toggle, or both. If BMC LAN traffic is configured to run on the shared NIC, then just connecting a SOL client with an Ethernet cable to the dedicated BMC NIC port shows no console.



- The node BIOS values should manually be made to match the values in Bright Cluster Manager, or vice versa.

### 13.7.2 SOL Console Configuration With Bright View

In Bright View, SOL configuration settings can be carried out per image via the clickpath Provisioning→Software Images→*image*→Edit→Settings

If the Enable SOL option is set to Yes then the kernel option to make the Linux serial console accessible is used after the node is rebooted.

This means that if the serial port and SOL are enabled for the node hardware, then after the node reboots the Linux serial console is accessible over the LAN via an SOL client.

If SOL is correctly configured in the BIOS and in the image, then access to the Linux serial console is possible via the `minicom` serial client running on the computer (from a bash shell for example), or via the `rconsole` serial client running in `cmsh`.

### 13.7.3 SOL Console Configuration And Access With `cmsh`

In `cmsh`, the serial console kernel option for a software image can be enabled within the `softwareimage` mode of `cmsh`. For the default image of `default-image`, this can be done as follows:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% softwareimage use default-image

[bright80->softwareimage[default-image]]% set enablesol yes
[bright80->softwareimage*[default-image*]]% commit
```

The SOL settings for a particular image can be seen with the `show` command:

```
[bright80->softwareimage[default-image]]% show | grep SOL
Parameter                               Value
-----
Enable SOL                             yes
SOL Flow Control                       yes
SOL Port                               ttyS1
SOL Speed                              115200
```

Values can be adjusted if needed with the `set` command.

On rebooting the node, the new values are used.

To access a node via an SOL client, the node can be specified from within the `device` mode of `cmsh`, and the `rconsole` command run on the head node:

```
[root@bright80 ~]# cmsh
[bright80]% device use node001
[bright80->device[node001]]% rconsole
```

### 13.7.4 The `conman` Serial Console Logger And Viewer

In Bright Cluster Manager, the console viewer and logger service `conman` is used to connect to an SOL console and log the console output.

If the “Enable SOL” option in Bright View, or if the `enablesol` in `cmsh` is enabled for the software image, then the `conman` configuration is written out and the `conman` service is started.

### Logging The Serial Console

The data seen at the serial console is then logged via SOL to the head node after reboot. For each node that has logging enabled, a log file is kept on the head node. For example, for `node001` the log file would be at `/var/log/conman/node001.log`. To view the logged console output without destroying terminal settings, using `less` with the `-R` option is recommended, as in: `less -R /var/log/conman/node001.log`.

### Using The Serial Console Interactively

**Viewing quirk during boot:** In contrast to the logs, the console viewer shows the initial booting stages of the node as it happens. There is however a quirk the system administrator should be aware of:

Normally the display on the physical console is a copy of the remote console. However, during boot, after the remote console has started up and been displaying the physical console for a while, the physical console display freezes. For the Linux 2.6 kernel series, the freeze occurs just before the ramdisk is run, and means that the display of the output of the launching `init.d` services is not seen on the physical console (figure 13.1).





Figure 13.1: Physical Console Freeze During SOL Access

The freeze is only a freeze of the display, and should not be mistaken for a system freeze. It occurs because the kernel is configured during that stage to send to only one console, and that console is the remote console. The remote console continues to display its progress (figure 13.2) during the freeze of the physical console display.

The image shows a remote console window with a menu bar at the top containing 'File', 'Virtual Machine', 'View', and 'Send Key'. Below the menu bar is a toolbar with icons for 'Console' (selected), 'Details', 'Run', 'Pause', 'Shut Down', and 'Fullscreen'. The main area of the window displays a black terminal with white text showing system boot logs. The logs include messages from rtc\_cmos, cpuidle, usbcore, usbhid, TCP, XFRM, NET, and Cluster Manager Ramdisk. The text is as follows:

```
rtc_cmos 00:01: RTC can wake from S4
rtc_cmos 00:01: rtc core: registered rtc_cmos as rtc0
rtc0: alarms up to one day, 114 bytes nvram
cpuidle: using governor ladder
cpuidle: using governor menu
usbcore: registered new interface driver hiddev
usbcore: registered new interface driver usbhid
usbhid: v2.6:USB HID core driver
TCP cubic registered
Initializing XFRM netlink socket
NET: Registered protocol family 17
registered taskstats version 1
rtc_cmos 00:01: setting system clock to 2012-05-25 13:57:11 UTC (1337954231)
Initializing network drop monitor service
Freeing unused kernel memory: 1244k freed
Write protecting the kernel read-only data: 10240k
Freeing unused kernel memory: 1040k freed
Freeing unused kernel memory: 1756k freed

=====
Cluster Manager Ramdisk v3.0
=====
Running original ramdisk.
Loading xen-netfront module
Loading xen-blkfront module
```

Figure 13.2: Remote Console Continues During SOL Access During Physical Console Freeze

Finally, just before login is displayed, the physical console once more (figure 13.3) starts to display what is on the remote console (figure 13.4).




Figure 13.3: Physical Console Resumes After Freeze During SOL Access




Figure 13.4: Remote Console End Display After Boot

The physical console thus misses displaying several parts of the boot progress.

**Exit sequence:** The `conman` console viewer session can be exited with the sequence `& .` (the last entry in the sequence being a period). Strictly speaking, the `& .` sequence must actually be preceded by an `<ENTER>`.

**The console buffer issue when accessing the remote console:** A feature of SOL console clients is that the administrator is not presented with any text prompt from the node that is being accessed. This is useful in some cases, and can be a problem in others.

An example of the issue is the case where the administrator has already logged into the console and typed in a command in the console shell, but has no intention of pressing the `<ENTER>` key until some other tasks are first carried out. If the connection breaks at this point, then the command typed in is held in the console shell command buffer, but is not displayed when a remote serial connection is re-established to the console—the previously entered text is invisible to the client making the connection. A subsequent `<ENTER>` would then attempt to execute the command. This is why an `<ENTER>` is not sent as the last key sequence during automated SOL access, and it is left to the administrator to enter the appropriate key strokes.

To avoid commands in the console shell buffer inadvertently being run when taking over the console remotely, the administrator can start the session with a `<CTRL>-u` to clear out text in the shell before pressing `<ENTER>`.

## 13.8 Managing Raw Monitoring Data

From Bright Cluster Manager version 8.0 onwards, the raw monitoring data values are stored as binary data under `/var/spool/cmd/monitoring` instead of as binary data within MySQL or MariaDB. The reason behind this change was to significantly increase performance. The monitoring subsystem in Bright Cluster Manager was thoroughly rewritten for this change.

### 13.8.1 Monitoring Subsystem Disk Usage With The `monitoringinfo --storage` Option

The disk usage by the monitoring subsystem can be viewed using the `monitoringinfo` command with the `--storage` option:

#### Example

```
[bright80->device]% monitoringinfo master --storage
```

Storage	Elements	Disk size	Usage	Free disk
Mon::Storage::Engine	1,523	1.00 GiB	1.28%	14.1 GiB
Mon::Storage::Message	1	16.0 MiB	0.000%	-
Mon::Storage::RepositoryId	1,528	47.7 KiB	100.0%	-

The Engine component stores the raw monitoring data. It grows in 1GB increments each time its usage reaches 100%.

### 13.8.2 Estimating The Required Size Of The Storage Device

The final size of the monitoring directory can be estimated with the Bright Cluster Manager script, `cm-bright-monitoring-usage.py`.

The size estimate assumes that there are no changes in configuration, or large numbers of running jobs.

The size estimate value is the maximum value it will take if the cluster runs forever. It is therefore an over-estimate in practice.

#### Example

```
[root@bright80 ~]# /cm/local/apps/cmd/scripts/monitoring/cm-bright-monitoring-usage.py
```

```

Number of used entities:      6
Number of used measurables:  231
Number of measurables:       231
Number of data producers:    95
Number of consolidators:     2

```

```

Current monitoring directory: /var/spool/cmd/monitoring
Monitoring directory size:    1.024 GB
Maximal directory size:      1.125 GB

```

### 13.8.3 Moving Monitoring Data Elsewhere

A procedure to move monitoring data from the default `/var/spool/cmd/monitoring/` directory to a new directory is as follows:

1. A new directory in which monitoring should be saved is picked
2. The `MonitoringPath` directive (page 603) is given the new directory as its value.
3. `CMDaemon` is stopped (`service cmd stop`).
4. The `/var/spool/cmd/monitoring/` directory is moved to the new directory.
5. `CMDaemon` is restarted (`service cmd start`).

### 13.8.4 Deleting All Monitoring Data

A procedure to delete all monitoring data from the default `/var/spool/cmd/monitoring/` directory is as follows:

1. On the active head node, the `CMDaemon` service can be stopped with:  

```
pdsh -g all service cmd stop
```
2. On both head nodes, the monitoring data is removed with:  

```
rm -f /var/spool/cmd/monitoring/*
```
3. On both head nodes, the associated database tables for the `CMDaemon` user are cleared with a session run on each head node.

The `CMDaemon` database user is `cmdaemon` by default, but the value can be checked with a `grep` on the `cmd.conf` file:

```

[root@bright80 ~]# grep ^DBUser /cm/local/apps/cmd/etc/cmd.conf
DBUser = "cmdaemon"

```

Similarly, the password for the `cmdaemon` user can be found with a `grep` as follows:

```

[root@bright80 ~]# grep ^DBPass /cm/local/apps/cmd/etc/cmd.conf
DBPass = "slarti8813bartfahrt"

```

The monitoring measurables can then be deleted by running a session on each head node as follows:

#### Example

```

[root@bright80 ~]# mysql -ucmdaemon -p
Enter password:
Welcome to the MariaDB monitor.  Commands end with ; or \g.

```

```
Your MariaDB connection id is 2909
Server version: 5.5.56-MariaDB MariaDB Server
```

Copyright (c) 2000, 2017, Oracle, MariaDB Corporation Ab and others.

Type 'help;' or '\h' for help. Type '\c' to clear the current input statement.

```
MariaDB [(none)]> use cmdaemon;
Database changed
MariaDB [cmdaemon]> truncate MonitoringMeasurables;
MariaDB [cmdaemon]> truncate MonitoringMeasurableMetrics;
MariaDB [cmdaemon]> truncate MonitoringMeasurableHealthChecks;
MariaDB [cmdaemon]> truncate MonitoringMeasurableEnums;
MariaDB [cmdaemon]> truncate EntityMeasurables;
MariaDB [cmdaemon]> truncate EnumMetricValues;
MariaDB [cmdaemon]> exit
repeat on other head node
```

4. On both head nodes, CMDaemon can then be restarted with:

```
service cmd start
```

5. On the active head node, after the command:

```
cmha status
```

shows all is OK, the CMDaemon service can be started on the active node again. The OK state should be achieved in about 15 seconds.

The CMDaemon service is started with, for example:

```
pdsh -g computenode service cmd start
```





# 14

## MIC Configuration

### 14.1 Introduction

The Intel Many Integrated Core (MIC) architecture combines many Intel CPU cores onto a single chip. Bright Cluster Manager supports the PCIe implementation of the Intel MIC architecture, called the Intel Xeon Phi. In this section the terms MIC, coprocessor, or (MIC) card, mean the Intel Xeon Phi, while a MIC host means a node where a MIC card is installed.

The MIC architecture, k1om, is quite similar to x86\_64. Usually an application written for x86\_64 CPU can simply be rebuilt using special compiler flags. Thus, Linux can run inside a coprocessor. Bright Cluster Manager provides special packages with names ending in `-k1om`, which provide executable binary files built to run only inside a MIC. Another set of packages with names beginning with `intel-mic-` is installed on the MIC host.

To install and configure MICs to work with Bright Cluster Manager, the administrator:

- installs the MIC software using YUM or zypper;
- does the initial configuration of a set of MICs in a cluster using `cm-mic-setup`;

The following can then be done for the MIC, using `cmsh`:

- tuning of coprocessor parameters. These parameters form the `mic<INDEX>.conf` (section 14.3.1) configuration file.
- monitoring of metrics/health checks of MIC cards.
- configuring workload manager queues for MICs just as for regular nodes. For now, only Slurm supports this feature.
- addition/removal of NFS mount points using `cmsh`.
- enabling/disabling third party software overlays loaded during MIC booting.
- tuning the network interface parameters.

In the preceding list, the value of `<INDEX>` is a number 0,1,2,...,31, and is called the *container index parameter* (section 3) of the MIC host. It corresponds to the MIC identification number of the card on the host. Thus the first card on the host has an `<INDEX>` value of 0, and the card is then identified as `mic0`.

### 14.2 MIC Software Installation

In order for MIC cards to function properly on a host hardware, large BAR (Base Address Registers) support (MMIO addressing greater than 4GB) must be enabled. The platform and/or BIOS vendor should be contacted to check if changing this setting is applicable to the platform used.

### 14.2.1 MIC Software Packages

As software for the MIC, Intel provides the Intel MIC Platform Software Stack (MPSS). This is made up of system software and libraries for low-level coprocessor management. Distribution-specific builds of the MPSS source packages are used by Bright Cluster Manager to manage MIC cards, and are picked up from the Bright Computing repositories. The Bright Cluster Manager administrator should not pick up the MPSS packages from Intel directly.

#### MIC Software Packages: Distribution Naming Convention

Linux distributions currently supported by Bright Cluster Manager are those based on RHEL 6.4 (CentOS 6.4 and Scientific Linux 6.4), RHEL 6.5, RHEL 6.6, RHEL 7.0, and SUSE Linux Enterprise Server 11 SP2 and SP3. The packages suffix, which is either `-rhel6.4`, `-rhel6.5`, `-rhel6.6`, `-rhel7.0`, `-suse11.2`, or `-suse11.3`, identifies the MIC package that is to be installed appropriately.

Distribution Based On	Suffix On Package
RHEL 6.4	<code>-rhel6.4</code>
RHEL 6.5	<code>-rhel6.5</code>
RHEL 6.6	<code>-rhel6.6</code>
RHEL 7.0	<code>-rhel7.0</code>
SLES 11 SP2	<code>-suse11.2</code>
SLES 11 SP3	<code>-suse11.3</code>

For example, the MPSS runtime-related packages, together with other RPMs distributed with MPSS, are repackaged by Bright Cluster Manager as `.rpm` files, and have names that start:

#### Example

- `intel-mic-runtime-rhel6.4`
- `intel-mic-runtime-rhel6.5`
- `intel-mic-runtime-rhel6.6`
- `intel-mic-runtime-rhel7.0`
- `intel-mic-runtime-suse11.2`
- `intel-mic-runtime-suse11.3`

The suffix is omitted for convenience in this manual.

#### MIC Software Packages: Names

The full list of packages, without the distribution suffix tags, is:

- `intel-mic-driver`: Intel MIC driver, built during host boot;
- `intel-mic-flash`: Intel MIC flash files, to flash the cards (section 14.4);
- `intel-mic-ofed`: OFED drivers and libraries for MIC. The OFED drivers on the running systems are built during host boot, from source packages packed inside the `intel-mic-ofed` package. The source packages are:
  - `intel-mic-ofed-kmod`: Host-side MIC InfiniBand Drivers
  - `intel-mic-ofed-libibscif`: Intel SCIF Userspace Driver
  - `intel-mic-ofed-ibpd`: InfiniBand Proxy Daemon

- `intel-mic-runtime`: Intel MIC runtime environment
- `intel-mic-sdk`: Intel MIC SDK. This includes the Intel MIC GNU tool chain to perform cross compilation (for `x68_64` and for `k1om`), and the Intel MIC kernel development tools and sources.
- `intel-mic-perf`: Benchmarks for measuring the performance of the Intel MIC cards.
- `intel-mic-ldap`: Intel MIC LDAP files.
- `intel-mic-src`: MPSS source archives.
- `intel-mic-doc`: Intel MIC documentation files.

The minimum set of packages to be installed in a host software image—or on a head node, if coprocessors are installed on the head node—consists of `intel-mic-driver`, `intel-mic-ofed`, `intel-mic-runtime`, and `intel-mic-flash`.

The entire set of the packages can be installed on an RHEL-based operating system with a command in the following format:

```
yum install intel-mic-*-<suffix> --installroot=<image>
```

For example:

```
yum install intel-mic-*-rhel6.6 --installroot=/cm/images/michost-image
```

For SLES the set of packages can be installed with a command in the following format:

```
zypper install intel-mic-*-<suffix> -R <image>
```

If using non-Bright repository OFED stacks, then the following OFED stacks provide their own SCIF drivers:

- the QLogic OFED stack with a version greater than 7.3
- the OFED stack from OFA with version 3.5

These stacks conflict with the Bright-packaged versions. The Bright Computing `intel-mic-ofed` package described earlier on should be removed by the administrator, if one of these non-Bright repository OFED stacks is installed.

Bright Computing also provides a set of `k1om` pre-built packages, which are installed on the head node. They can be removed if Slurm is not used:

- `slurm-client-k1om`
- `munge-k1om`

An additional `k1om` pre-built package that is installed is `strace-k1om`. This can typically be used for debugging issues, and may be used by Bright Computing support when tracing problems.

Because the `k1om` packages are installed in `/cm/shared/`, they are available to each node in the cluster, as well as to the MIC cards. For now, only the Slurm Workload Manager can be started within the MIC in Bright Cluster Manager, and requires all of these `k1om` packages to be installed on the head node. The other workload managers that Bright Cluster Manager supports are supported with the MIC, but cannot be started from within the MIC.

### 14.2.2 MIC Environment MIC Commands

The `module` command (section 2.2) can be used to load the MIC environment variables as follows:

```
module add intel/mic/runtime
```

The following Intel MPSS commands, among others, can then be executed from the `intel-mic-runtime` and other `intel-mic-*` packages:

- `micinfo`: retrieves information about a MIC system configuration.
- `micflash`: updates the coprocessor flash, queries the flash version on the coprocessor, and saves a copy of the flash image loaded in the coprocessor to a directory on the host. If executed without a path to the firmware file or directory, then a compatible image is searched for inside `/usr/share/mpss/flash/`. If `-device all` is specified as an option, then the firmware of all MIC cards on a host will be updated. Available options are described in `man(1) micflash`.
- `micsmc`: monitors coprocessors.
- `micctrl`: controls and configures a MIC.
- `miccheck`: verifies a coprocessor system configuration by running a diagnostic test suite.
- `micnativeloadex`: copies a MIC native binary to a specified coprocessor and executes it.
- `micrasd`: logs hardware errors reported by MIC devices.

### 14.2.3 Bright Computing MIC Tools

The Bright Computing repository also provides:

- `cm-mic-setup`: This tool is provided by the `cluster-tools` package. This configures MICs in a Bright Cluster Manager enabled cluster, and is described further in section 14.3.1
- `cm-mic-postcode`: This tool is provided by the `cluster-tools-slave` package. This returns a human-readable description of the POST code returned by the coprocessor during power on and boot, thus identifying the stage that the card is at during the boot process. A hex representation of the MIC POST code can be found by reading the `/sys/class/mic/mic<INDEX>/post_code` file.

### 14.2.4 MIC OFED Installation

OFED communication can improve data throughput because there is then no additional copy into the host system memory. Direct data transfers can also take place on the SCIF (Symmetric Communications Interface) between the MIC OFED HCA driver on the host machine and the corresponding MIC OFED HCA driver on the MIC. For MICs that are on the same host, the MIC OFED kernel modules can be used to enable MIC-to-MIC RDMA communication over OFED.

There are 3 widely-used OFED software stack implementations: OFA, QLogic (now known as Intel True Scale), and Mellanox. The latest OFED versions for the HCAs used can be looked up in the Intel MPSS User Guide, available from <https://software.intel.com/en-us/articles/intel-manycore-platform-software-stack-mpss>.

The release notes for the OFED stacks indicate which stack versions are supported by MICs. For example, version OFED-3.5.2-MIC supports the following distribution releases:

- RedHat EL6.2 2.6.32-220.el6
- RedHat EL6.3 2.6.32-279.el6
- RedHat EL6.4 2.6.32-358.el6
- RedHat EL6.5 2.6.32-431.el6

- RedHat EL7.0 3.10.0-123.el7 \*
- SLES11 SP2 3.0.13-0.27-default
- SLES11 SP3 3.0.76-0.11-default \*

### Packages Installation

By default, the parent distribution version of the OFED stack is installed on Bright Cluster Manager. A QLogic (Intel True Scale) OFED stack or Mellanox OFED stack packaged by Bright Computing can also be used, and their installation on the host are described in section 7.6 of the *Installation Manual*. To use a MIC with OFED, however, requires the installation of a MIC-capable OFED stack, provided by the Intel `intel-mic-ofed` package listed previously (section 14.2.1).

To install the `intel-mic-ofed` package on a host requires that the `kernel-ib-devel` and `kernel-ib` OFED packages, if they are installed, must first be removed manually. They can be removed as follows:

- For a head node:

```
rpm -e kernel-ib-devel kernel-ib
```

- For a regular node with image `<image>`:

```
rpm -e kernel-ib-devel kernel-ib --root=/cm/images/<image>
```

After the MIC OFED stack has been installed, the host must be rebooted to implement it. By default the MIC OFED stack is compiled and installed on boot. It is also possible to build and install MIC OFED within a software image, by running the build service outside of MIC host boot, using the `install` argument:

```
chroot <image> /etc/init.d/intel-mic-ofed install
```

Such an installation may be useful when it is not possible to build drivers during MIC host boot. For example, when the node root filesystem is located on a shared filesystem, such as on NFS, and certain directories are read-only, then a build during MIC host boot fails. However, building outside of MIC host boot means that the installation must be repeated separately whenever the MIC host kernel changes.

Logs for the MIC OFED driver build are found at:

- `/var/log/intel-mic-ofed-driver.log`: This logs the `/var/log/intel-mic-ofed` script
- `/var/log/intel-mic-ofed-driver-build.log`: This logs the `gcc` compiler and `rpmbuild` utility messages

### The `ofed-mic` Service

The `ofed-mic` service running on the MIC host serves the MIC OFED kernel modules. If one of the MICs belonging to that host is not in an UP state, then:

- The `ofed-mic` service will fail. That is, its return code will not be 0, and the `ManagedServicesOK` health check (page 97) response is `FAIL`.
- No attempt to start the `ofed-mic` service on a host is carried out by Bright Cluster Manager during this `FAIL` state.

## 14.3 MIC Configuration

### 14.3.1 Using `cm-mic-setup` To Configure MICs

#### Introduction

The `cm-mic-setup` utility is used to set up the initial configuration of MIC hosts and cards in Bright Cluster Manager. Adding new cards is done interactively by default, or otherwise automatically.

- Everything done by `cm-mic-setup` can be done manually using `cmsh`. However, using `cmsh` is not recommended because it is easy for an administrator to forget something and make a mistake. Configuring MICs via `cmsh` is covered in section 14.3.2.

#### Running The Command

A command synopsis of `cm-mic-setup` is:

```
cm-mic-setup -a <MIC>... -m <MICHOSTNAME>... -n <MICNETWORK> [OPTIONS]
```

Here:

- `<MIC>` is the MIC card being added
- `<MICHOSTNAME>` is the MIC host, as specified according to the *hostname range format*
- `<MICNETWORK>` is a network that the MIC cards are in. Any new network can be set up for this. For a Type 1 or Type 2 network (section 3.3.6 of the *Installation Manual*), `internalnet` is the default.

The details of the `cm-mic-setup` command syntax and hostname range format are given in the manual page, `man(8) cm-mic-setup`.

When `cm-mic-setup` is run:

- In interactive mode, questions are asked about the configuration settings of particular card(s) and host(s) (IP addresses of host and card, bridge name and so on).
- In automatic mode, all parameters are configured by default, except that default values can be overwritten using extra options in the command line. The log file of all `cm-mic-setup` actions is kept in `/var/log/cm-mic-setup.log`.

When adding a new MIC, `cm-mic-setup` goes through these steps:

1. The new MIC device is added to Bright Cluster Manager
2. If it has not already been done
  - a network bridge interface is added to a MIC host interface
  - the management physical network interface is added to the bridge
  - the physical network interface IP address is assigned to the bridge
  - and the IP address of the physical network interface is cleared.
3. A range of free IP addresses can be assigned to the MIC card interfaces for a specific MIC host (`mic0, mic1, mic2...`). The ranges are calculated using
  - a specified network base address (`x.y.0.0`)
  - network base offset (typically `0.0.z.0`, with  $z \neq 0$ . The offset must be specified for netmasks other than a CIDR value of `/16`)
  - and stride (`s`).

The dotted quad representation of the range is then as indicated by the series:

```
x.y.z.(s*n), x.y.z.(s*n+1), x.y.z.(s*n+2), ... x.y.z.(s*n+(s-1))
= x.y.z.(s*n), ... x.y.z.(s*(n+1)-1)
```

In the series,  $n$  is a number (0,1,2,3...) identified with the MIC host. The stride is thus the number of addresses in the range associated with that MIC host. The first line shows that the range starts here from  $s*n+0$  and ends at  $s*n+(s-1)$  in the end quad of the IP address. The MIC interfaces are given these IP addresses by default. The stride is thus a way of regularizing the IP addresses of the MIC cards associated with a MIC host.

A worked example of this follows: If the specified network is the internal network, then its base address is 10.141.0.0 with a netmask of in CIDR notation of /16, and the network base offset defaults to 0.0.128.0. For a stride of 8, the IP address range that will be allocated for the second (i.e.,  $n=1$ ) node is:

```
x.y.z.(s*n) ... x.y.z.(s*(n+1)-1)
= 10.141.128.8 ... 10.141.128.15
```

Here, 10.141.128.8 is the first MIC card IP address at the second node, and 10.141.128.9 is the next MIC card IP address at the second node.

If the stride is not specified, then a default stride is calculated as the maximum taken from the numbers of MICs per MIC host.

4. The `mic<INDEX>` physical network interface is added to the MIC host interfaces (i.e. on the regular nodes). The value of `<INDEX>` is typically the “number” of the MIC card on the host, starting with 0 for the first card, 1 for the second and so on. An example of adding a network interface is shown on page 63.

```
[bright80->device[node001]->interfaces]% add physical mic0
```

5. The `mic0` physical network interface is added to the MIC card interfaces (i.e., to the MIC card nodes). The IP address is picked up from the previously calculated IP range to the interface in the earlier step 3.

```
[bright80->device[node001-mic0]->interfaces% add physical mic0
```

6. Default filesystem mount points are added to the MIC device. These are `/dev/pts` for `pts`, `/dev/shm` for `tempfs`, `/sys` for `sysfs`, `/proc` for `proc`, and `/cm/shared` and `/home` for `NFS`.
7. Default overlays are added to the MIC. These are `cm-mounts` and a set of workload manager overlays. For Slurm the overlays `cm-munge`, `cm-munge-key` and `cm-slurm` are added.
8. The `MICHost` role is assigned to the MIC host.

A reboot of the MIC hosts is prompted for in the interactive mode. The non-interactive mode does not prompt for a reboot, and does not carry out a reboot. A reboot of the MIC hosts is however needed after `cm-mic-setup` is run, for the MIC hosts to function correctly.

### 14.3.2 Using `cmsh` To Configure Some MIC Properties

A MIC is a first class device in Bright Cluster Manager, which means it is very similar to a regular cluster node, rather than like, for example, a relatively dumb switch. So, when a new card is added, a cluster administrator can manage the MIC card with `cmsh` like the other nodes in the cluster:

1. MIC network interfaces can be managed from the `interfaces` submode:

```
[bright80->device[node002-mic0]->interfaces]% list
Type      Network device name  IP           Network
-----
physical  mic0                        10.141.128.4 internalnet
```

2. A MIC has a category type, MIC, associated with it. This is similar to nodes, which have a category type of node. MIC categories are analogous to node categories (section 2.1.3), and are therefore accessed from the category mode of cmsh. The idea behind a MIC category is essentially the same as that for a node category: to manage configuration settings in the cluster in a single place (i.e. in cmsh) for a group of items of a particular type (i.e. nodes or MIC cards).

By default, the mic-default MIC category is created when the cm-mic-setup script is run for the first time. Within the mic-default category are defined, among others:

- the default filesystem mounts (fsmounts)
- MIC settings (micsettings)
  - overlays (overlay)
  - powermanagement (powermanagement)
- roles (roles).

Just as for regular node categories, properties are inherited by default from the category. Thus, if some property is set in micsettings, then this property is used by default in the particular MIC item unless it is overwritten.

3. MIC-specific options can be tuned in the micsettings submode of the device mode or category mode:

```
[bright80->category[mic-default]->micsettings]% show
Parameter                                     Value
-----
Boot On Start                               yes
Cgroup Memory                               disabled
Console                                     hvc0
Crash Dump Dir                              /var/crash/mic/
Crash Dump Limit                            16
Extra Command Line
Overlays                                    <4 in submode>
Power Management                            cpufreq_on;corec6_on;pc3_on;pc6_on
Root Device                                /var/mpss/mic${index}.image.gz
Root Device Type                            ramfs
Shutdown Timeout                            300
Type                                         XeonPhiSettings
User Authentication Type                     merge
Verbose Logging                             yes
Base                                         /usr/share/mpss/boot/initramfs-knightscorner.cpio.gz
Common Dir                                  /var/mpss/common
Common Dir File List
Mic Dir                                      /var/mpss/mic${index}
Mic Dir File List
OS Image Address Map                        /usr/share/mpss/boot/System.map-knightscorner
OS Image Kernel                            /usr/share/mpss/boot/bzImage-knightscorner
Type Of Base                                CPIO
```

In the preceding listing, the text `${index}` is the container index parameter of the MIC node (section 14.1). The text is replaced by the value of when the MIC identification number is set for the card on the host.



### Example

```
[bright80]% device use node001-mic0
[bright80->device[node001-mic0]]% get containerindex
0
```

4. Overlays which are used to enable and disable third party software in the MIC can be changed from the `overlays` submode of the `micsettings` submode.
5. Mount points can be configured just like for regular node mount points, but with one exception: If a directory is to be mounted from a MIC host to its own MIC, then the `$michost` variable can be used. On MIC boot this variable is substituted with the hostname of the MIC host.

All other MIC node parameters are similar to the parameters of a regular node.

### 14.3.3 Using MIC Overlays To Place Software On The MIC

A MIC overlay is used to make software available from a MIC host to a MIC. Usually this is software that is heavily accessed during a code run, such as drivers or parts of applications where access speed is a priority. It can also be software that can only be executed on the MIC, such as init scripts. The memory available to the MIC (8 to 16 GB at the time of writing in December 2014) is much lower than that of a regular node, so that large amounts of data cannot be placed in it. A relatively much slower remote-mounted filesystem is normally what is used instead for access to larger amounts of data.

Ignoring mounts, the MIC filesystem on the MIC is built up in several layers, starting with the fundamental binaries layer, adding some more required layers, and ending with a software overlay that the administrator installs for the end user applications. Each layer on the MIC is configured by using a “layer” source. The source can be

- a directory
- individual files
- files packed in RPMs

The source depends on the overlay `type`, on the MIC host, as is described further on. The source used is assigned a corresponding *source configuration parameter*. The parameter is one of `Base`, `CommonDir`, `MicDir`, and `Overlay`. Each of these parameters has a default setting, but if needed, the administrator can modify them via the CMDaemon front end, `cmsh`.

Each overlay has three important parameters: `type`, `source` and `target`. These determine what type of file or files are transferred from a specified source, to a target on the MIC file system. The overlay `type` parameter can be set to the following values:

- `file` – setting this means that a single k10m RPM file in the directory specified by `source` is to be copied over to the MIC file system. The file is placed in the `/RPMs-to-install` directory on the MIC file system. When the MIC card boots, the `init` process tries to install the RPM within the MIC. No `target` type can be set for `file`.
- `filelist` – setting this means that files from the directory specified by `source` are to be copied over to the MIC file system from the directory that `source` is set to. The files are placed in the directory specified by `target`.
- `rpm` – setting this means that a single file specified in `source` is to be installed, not copied, over to the MIC file system. No `target` type can be set for `rpm`.
- `simple` – setting this means that all files found under the directory specified by `source` are to be copied over to the MIC file system. The file is placed in the directory specified by `target` and the owner and permission are configured to match the files on the host.

In the case of `filelist`, each target file, typically given a name ending in `.filelist`, describes the files, directories, links, that are to be copied over from the layer directory on the MIC host, and laid out in the MIC filesystem on the MIC. The filelist content also includes *nods*. Nods (with a nod to the `mknod(1)` command) are used to set, for special devices on the MIC, such as `/dev/console`:

- the device type: character `c` or block, `b`
- the major and minor values
- perms, uid and gid.

The canonical details on these and other parameters at the time of writing (December 2014) can be found in Intel MPSS User Guide, provided with each MPSS release: *Intel Xeon Phi Coprocessor Many-core Platform Software Stack (MPSS) Boot Configuration Guide*. In revision 3.4 of that guide the details are found in section 16.1: *The File System Creation Process*.

The layers are laid out in the MIC according to the following sequence of directory configuration parameters:

1. **Base:** This is a MIC host path to a zipped CPIO archive that contains the basic MIC Coprocessor binaries that were installed during RPM installation.
2. **CommonDir:** This MIC host directory contains a common filesystem structure that does not change during use of the MIC for compute purposes. Files in this directory are not wiped out during MPSS installation updates.
3. **MicDir:** This MIC host directory contains per MIC information files. Most of these files are created during MIC configuration. These values do not change if the MIC hardware does not change. However restarting the `mpssd` daemon will reconfigure the values, so changing them by hand is not advisable.
4. **Overlay:** Depending on its type, this can be a file, RPM or MIC host directory. It can contain additional sets of files that may be laid over the MIC filesystem that has been built in the layers so far. More than one `Overlay` parameter can be assigned by an administrator, who can thus use MIC overlays to make application software available to the MIC.
  - The default assignment is named `cm-mounts`. The associated directory and filelist are configured with default values when `cm-mic-setup` (section 14.3.1, step 7) is used. A MIC using these defaults creates the default mount points for the NFS directories.
  - Slurm is offered as a configuration choice when `cm-mic-setup` or `Create MICs` are run. If selected, then the names `cm-munge`, `cm-munge-key` and `cm-slurm` are also assigned to the `Overlay` parameter, and their associated directories and filelists are configured with default values too. Among others, these overlays place `slurm` and `munge` init scripts, the `munge` key file, and also the configuration file `gres.conf`, inside the MICs.

These overlays have the following default directory and filelist settings:

```
[bright80->category[mic-default]->micsettings->overlay]% list -f name:12,source:47
name (key)    source
-----
cm-mounts     /var/mpss/cm-mounts-mic${index}
cm-slurm      /cm/shared/apps/slurm/current/klom-arch
cm-munge      /cm/shared/apps/munge/current/klom-arch
cm-munge-key  /etc/munge/munge.key

[bright80->category[mic-default]->micsettings->overlay]% list -f name:12,target:54
name (key)    target
```

```

-----
cm-mounts      /var/mpss/cm-mounts-mic${index}.filelist
cm-slurm       /cm/shared/apps/slurm/current/klom-arch/slurm.filelist
cm-munge       /cm/shared/apps/munge/current/klom-arch/munge.filelist
cm-munge-key   /etc/munge/munge.key

[micdev->category[mic-default]->micsettings->overlay]% list -f name:12,type:10
name (key)     type
-----
cm-mounts      filelist
cm-slurm       filelist
cm-munge       filelist
cm-munge-key   file

```

The administrator generally only needs to consider the overlay layer(s), because MPSS and Bright Cluster Manager configuration takes care of the other “OS-like” layers with sensible default values. Thus, adding a MIC application as an overlay controlled by Bright Cluster Manager can be done, for example, according to the following procedure:

### Example

1. A new layer directory can be created on the MIC host:  
`mkdir /cm/local/apps/myapp/klom/`
2. Files, directories, and links for the MIC application can then be placed inside the layer directory:  
`cp -r klomapplication /cm/local/apps/myapp/klom/`
3. A descriptor file, `myapp.filelist`, can be constructed according to the `filelist` syntax, and placed in the layer directory’s topmost level.
4. A new overlay object is created via `cmsh`, with the `Overlay` directory configuration parameter set to `/cm/local/apps/myapp/klom/`, and the `filelist` descriptor set to `/cm/local/apps/myapp/klom/myapp.filelist`
5. On restarting the MIC, the MIC application becomes available on the MIC.

## 14.4 MIC Card Flash Updates

After all the necessary `intel-mic-*` and `*-klom` packages have been installed for the first time, the hosts should be rebooted to make the MIC commands available for use. The card flash images should then be updated, and the hosts rebooted after that too.

The flash update procedure on, for example, two MIC hosts `node001` and `node002`, can be carried out as follows:

Backslashes in the following 5-step procedure indicate line splits, which means that any commands running across such line splits should be input as one long line:

1. The MPSS service on the MIC hosts is stopped:

```

[root@bright80 ~]$ cmsh
[bright80]% device
[bright80->device]% foreach -n node001..node002 (services; stop mpss)
...

```

2. Using the `micctrl` command with appropriate options, the ready state is awaited (`-w`) on each MIC host after a forced (`-f`) reset (`-r`) of the host:

```
[bright80->device]% pexec -n node001..node002 "module load
intel/mic/runtime && micctrl -r -f -w"
```

```
[node001] :
mic0: ready
mic1: ready
```

```
[node002] :
mic0: ready
mic1: ready
```

```
[bright80->device]%
```

For the sake of clarity: The reset option brings a MIC to a ready state (ready for boot), which means it is **DOWN** in Bright Cluster Manager terminology. The `-h` option shows an options help text for the `micctrl` command.

3. The firmware can then be updated. Some output has been elided for brevity in the listed output:

```
[bright80->device]% pexec -n node001..node002 "module load intel/mic/runtime\
&& micflash -v -update -noreboot -device all"
```

```
[node001]
```

```
No image path specified - Searching: /usr/share/mpss/flash
```

```
mic0: Flash image: /usr/share/mpss/flash/EXT_HP2_C0_0390-02.rom.smc
```

```
mic1: Flash image: /usr/share/mpss/flash/EXT_HP2_C0_0390-02.rom.smc
```

```
mic0: Updating flash: 10%
```

```
mic1: Updating flash: 10%
```

```
mic0: Updating flash: 40%
```

```
mic1: Updating flash: 40%
```

```
mic0: Updating flash: 56%
```

```
mic1: Updating flash: 56%
```

```
mic0: Updating SMC: 0%
```

```
mic1: Updating SMC: 0%
```

```
mic0: Updating SMC: 10%
```

```
mic1: Updating SMC: 10%
```

```
mic0: Updating SMC: 22%
```

```
mic1: Updating SMC: 22%
```

```
mic0: Updating SMC: 35%
```

```
mic1: Updating SMC: 35%
```

```
mic0: Updating SMC: 59%
```

```
mic1: Updating SMC: 59%
```

```
mic0: Updating SMC: 96%
```

```
mic1: Updating SMC: 96%
```

```
mic0: Transitioning to ready state: POST code: 3C
```

```
mic1: Transitioning to ready state: POST code: 3C
```

```
mic0: Transitioning to ready state: POST code: 3d
mic1: Transitioning to ready state: POST code: 3d

mic0: Transitioning to ready state: POST code: 09
mic1: Transitioning to ready state: POST code: 09

mic0: Done: Flash update successful: SMC update successful
mic1: Done: Flash update successful: SMC update successful

[node002] :

...
```

Some older MIC cards need a modified `micflash` command from that used in the preceding output. Intel designates MIC card core step versions with A0, A1, B0 and so on. For card versions older than C0, the `-smcbootloader` option must be added to the `micflash` command. This brings the SMC bootloader software up to or beyond version 1.8, which is a requirement.

4. The MPSS service is started:

```
[bright80->device]% foreach -n node001..node002 (services; start mpss)
```

5. The hosts are rebooted:

```
[bright80->device]% foreach -n node001..node002 (power reset)
```

Rebooting the hosts also automatically reboots the MICs.

Further details on flashing the MIC are given in the *Intel MPSS User Guide*.

## 14.5 Other MIC Administrative Tasks

After the procedures of installing and configuring the MPSS software, and re-flashing the MIC, the Bright Cluster Manager is in an understandably disturbed state. It should be allowed about a 10 to 15 minute period to settle down, so that it can start populating its metrics and health checks with sensible values. Warnings during the settling down period can be ignored. After the system has settled down to a steady state, any persistent warnings can be taken more seriously.

### 14.5.1 How CMDaemon Manages MIC Cards

When the `michost` role is assigned to a host, CMDaemon starts and monitors these services:

- `mpss` services. This is an Intel Manycore Platform Software Stack (Intel MPSS) service which is runs the `mpssd` daemon. The version of MPSS that Bright Cluster Manager currently (January 2015) supports is 3.4.x.

The `mpssd` daemon controls the initialization and booting of coprocessor cards based on a set of configuration files located at `/etc/mpss/`. The daemon is started and stopped as an operating system service and instructs the cards to boot or shutdown. It supplies the final filesystem image to the cards when requested. Further details about the `mpssd` daemon and its configuration files are given in the *Intel Xeon Phi Coprocessor Many-core Platform Software Stack (MPSS) Getting Started Guide*.

- The `ofed-mic` service. This provides the OFED interface between a coprocessor and `ofed` drivers running on its host.

Near the end of a successful boot of the coprocessor, CMDaemon executes the `finalize` script `/cm/local/apps/cmd/scripts/finalize-mic` for the MIC. The `finalize` script prepares the card

to be used by users: It clears the IP address of the MIC interface, adds the MIC interface to the network bridge interface, adds the workload manager user (if necessary), and finally executes the `prepare-mic` script on the card via `ssh`.

The `prepare-mic` script mounts NFS shared directories, starts workload manager daemons, and makes sure that `coi_daemon` is running with `micuser` user permissions. The script also forbids all regular users from accessing the MIC via SSH, apart from the user running a job via the job prolog, or a job running as `micuser`. The `root` user always has access to the MIC card.

### 14.5.2 Using Workload Managers With MIC

After a new MIC card is added and the `michost` role is assigned to its host, CMDaemon can configure the workload manager that is currently in use to use this card as follows:

- For Slurm:
  - The MIC is added to the workload manager as a new computing node.
  - The MIC is added to job queues if the workload manager client role is assigned to the MIC in `cmsh`.
  - Node properties `michost` and `miccard` are assigned to the MIC host and the MIC card correspondingly.
  - A special prolog script is enabled for the host, if it has not already been enabled. The prolog script is at `/cm/local/apps/cmd/scripts/prolog-michost`.
- For all workload managers:
  - A new generic resource type `mic` is added, and the workload manager daemon on the host is configured to be aware about new available generic resources.

Bright Cluster Manager supports two main use case scenarios for coprocessors:

#### 1. Native k10m application.

This currently only works with Slurm.

The user's application is built to be used on k10m CPU architecture and executed inside MIC card. In this case the user should request nodes with the property `miccard` on its job submission. The workload manager processes this job just like a regular job executed inside the regular node.

Before the job is executed, the MIC hosts prolog script (`/cm/local/apps/cmd/scripts/prolog-michost`) is invoked on all hosts which are used by the job, in order to prepare MIC cards for the job.

#### 2. Code offloading by the application.

To carry out code offloading, the user's application is created to be executed on an x86\_64 host, but uses special instructions to offload part of its code to one or more coprocessors installed on the host locally. The user needs to request the `michost` property or a particular number of MIC generic resources for each host during its job submission.

The application is executed on specified hosts and the workload manager sets an `OFFLOAD_DEVICES` environment variable, which controls the selection of MICs available to a job's offloading code.

The offloaded code is executed with the user's permissions inside the MICs. If no MICs are configured on the host, the `OFFLOAD_DEVICES` variable is set to -1. This causes the code to ignore the offload directives and run its routines on the host's CPU(s).

Before the job is executed, the MIC prolog script (`/cm/local/apps/cmd/scripts/prolog-mic`) is invoked on MIC to prepare the card for the job.

In both cases, prolog scripts eventually execute the `prepare-mic` script (`/cm/local/apps/cmd/scripts/prepare-mic`), located on the MIC (the same script as executed within `finalize` script). This script prepares the card for use by a particular user.

### 14.5.3 Mounting The Root Filesystem For A MIC Over NFS

In section 3.10.4, the configuration of a diskless node with its root filesystem provided over NFS was described.

This section (section 14.5.3), assumes that the steps described in section 3.10.4 have been carried out, so that a diskless node is now up and running. If a MIC is installed on such a diskless host, then this host, which is now a MIC host, can be configured so that NFS provides it with a root filesystem, as follows:

1. The MIC and OFED MIC drivers should be built and installed in an appropriate software image. This is to reduce the number of directories mounted to the `tmpfs` filesystem.

The drivers can be built and installed in a software image called `root-over-nfs` as follows:

#### Example

```
[root@bright80 ~]# chroot /cm/images/root-over-nfs
[root@bright80 /]# chkconfig --del intel-mic-driver
[root@bright80 /]# chkconfig --del intel-mic-ofed
[root@bright80 /]# /etc/init.d/intel-mic-driver install
Building and installing mic driver [ OK ]
[root@bright80 /]# /etc/init.d/intel-mic-ofed install
Building and installing intel-mic-ofed-kmod [ OK ]
Building and installing intel-mic-ofed-ibpd [ OK ]
Building and installing intel-mic-ofed-libibscif [ OK ]
```

The `intel-mic-ofed` command should not be run with a `start` argument when the drivers are installed inside the software image. This is because the script would then restart the `openibd` service.

Log entries for the install process can be seen under `/var/log`, in `intel-mic-driver.log`, `intel-mic-ofed-driver.log`, and `intel-mic-ofed-driver-build.log`.

2. The new filesystem mount point, accessible under the `fsmounts` submode, should be set to point to the appropriate node category. If the node category name is `root-over-nfs`, then the configuration can be done using `cmsh` as follows:

#### Example

```
[root@bright80 ~]# cmsh
[bright80]% category fsmounts root-over-nfs
[bright80->category[root-over-nfs]->fsmounts]% add /var/mpss
[bright80->/var/mpss*]]% set device tmpfs
[bright80->/var/mpss*]]% set filesystem tmpfs
[bright80->/var/mpss*]]% commit
```

3. The MIC host must be rebooted to implement the changes.

### 14.5.4 MIC Metrics

Metrics are listed in Appendix G.1.1. The use of the metric collection `mic` (page 651) means that MIC metrics with working sensors are able to monitor MIC-related values.

The exact metrics that can be monitored vary according to the MIC hardware.

### 14.5.5 User Management On The MIC

A current user in the context of MIC use is a user that starts a job via a workload manager. By default, a current user is added to the `micuser` group within the MIC, in `/etc/group`, and the value:

```
AllowGroups root micuser
```

is appended to `/etc/ssh/sshd_config` within the MIC at the same time. This then allows only users from `micuser` group and the `root` user to have ssh access to the MIC during job execution.

The default user management behavior can be altered in `cmsh` by adding the following parameters to `mic<N>.conf`:

- `UserAuthenticationType`: user authentication type used for a MIC. Possible values: `Local`, `None`. Default: `Local`
- `UserAuthenticationLowUID`: lowest ID of a user which will be added. Possible values: any 32-bit positive number. Default: `500`
- `UserAuthenticationHighUID`: highest ID of a user which will be added. Possible values: any 32-bit positive number. Default: `65000`

Users with user IDs in the range:

```
UserAuthenticationLowUID–UserAuthenticationHighUID
```

will be added to the MIC. Although any 32-bit user ID may be entered, a value of `500` or more is recommended for the lowest value. If `UserAuthenticationType=None` is specified, the `/etc/passwd` file on the card will default to one containing the `root`, `sshd`, and `micuser` accounts.

In `/etc/mpss/cm-mpss.conf`, the parameters that are used by MIC related scripts provided by Bright Cluster Manager are:

- `SSHD_ALLOW_GROUPS`: indicates what will be set as the value to `AllowGroups` in `/etc/ssh/sshd_config` within all MICs of the host. Possible values are:
  - *<any quoted string>*: Default: `"root micuser"`
  - `UNUSED`: This value means that
    - \* `AllowGroups` will not be appended in `/etc/ssh/sshd_config`
    - \* the current user will not be added to the `micuser` group
    - \* all users can ssh into the MIC even if they have no job running on it.
- `RESTART_COI_DAEMON`: indicates if `coi_daemon` will be restarted with the current user permissions. If the value is `YES`, then `coi_daemon` restarts when the MIC is booted, and also each time when `prolog-mic` script is executed on MIC or the `prolog-michost` script is executed on the host. Default: `YES`

If `/etc/mpss/cm-mpss.conf` is changed, then the MICs should be restarted to apply the changes.



# 15

## High Availability

### 15.0 Introduction

#### 15.0.1 Why Have High Availability?

In a cluster with a single head node, the head node is a single point of failure for the entire cluster. It is often unacceptable that the failure of a single machine can disrupt the daily operations of a cluster.

#### 15.0.2 High Availability Is Possible On Head Nodes, And Also On Regular Nodes

The high availability (HA) feature of Bright Cluster Manager therefore allows clusters to be set up with two head nodes configured as a failover pair, with one member of the pair being the active head.

Especially with smaller clusters, it is often convenient to run all services on the head node. However, an administrator may want or need to run a service on a regular node instead. For example, a workload manager, or NFS could be run on a regular node. If a service disruption is unacceptable here, too, then HA can be configured for regular nodes too. For regular nodes, HA is done differently compared with head nodes.

By default, in this and other chapters, HA is about a head node failover configuration. When it is otherwise, then it is made explicitly clear in the manuals that it is regular node HA that is being discussed.

#### 15.0.3 High Availability Usually Uses Shared Storage

HA is typically configured using shared storage (section 15.1.5), such as from an NFS service, which typically provides the `/home` directory on the active (section 15.1.1) head, and on the regular nodes.

#### 15.0.4 Organization Of This Chapter

The remaining sections of this chapter are organized as follows:

- **HA On Head Nodes**
  - Section 15.1 describes the concepts behind HA, keeping the Bright Cluster Manager configuration in mind.
  - Section 15.2 describes the normal user-interactive way in which the Bright Cluster Manager implementation of a failover setup is configured.
  - Section 15.3 describes the implementation of the Bright Cluster Manager failover setup in a less user-interactive way, which avoids using the Ncurses dialogs of section 15.2
  - Section 15.4 describes how HA is managed with Bright Cluster Manager after it has been set up.
- **HA On Regular Nodes**
  - Section 15.5 describes the concepts behind HA for regular nodes, and how to configure HA for them.

- **HA And Workload Manager Jobs**

- Section 15.6 describes the support for workload manager job continuation during HA failover.

## 15.1 HA Concepts

### 15.1.1 Primary, Secondary, Active, Passive

**Naming:** In a cluster with an HA setup, one of the head nodes is named the *primary* head node and the other head node is named the *secondary* head node.

**Mode:** Under normal operation, one of the two head nodes is in *active* mode, whereas the other is in *passive* mode.

The difference between naming versus mode is illustrated by realizing that while a head node which is primary always remains primary, the mode that the node is in may change. Thus, the primary head node can be in passive mode when the secondary is in active mode. Similarly the primary head node may be in active mode while the secondary head node is in passive mode.

The difference between active and passive is that the active head takes the lead in cluster-related activity, while the passive follows it. Thus, for example, with MySQL transactions, CMDaemon carries them out with MySQL running on the active, while the passive trails the changes. This naturally means that the active corresponds to the master, and the passive to the slave, in the MySQL master-slave replication mode that MySQL is run as.

### 15.1.2 Monitoring The Active Head Node, Initiating Failover

In HA the passive head node continuously monitors the active head node. If the passive finds that the active is no longer operational, it will initiate a *failover sequence*. A failover sequence involves taking over resources, services and network addresses from the active head node. The goal is to continue providing services to compute nodes, so that jobs running on these nodes keep running.

### 15.1.3 Services In Bright Cluster Manager HA Setups

There are several services being offered by a head node to the cluster and its users.

#### Services Running On Both Head Nodes

One of the design features of the HA implementation in Bright Cluster Manager is that whenever possible, services are offered on both the active as well as the passive head node. This allows the capacity of both machines to be used for certain tasks (e.g. provisioning), but it also means that there are fewer services to move in the event of a failover sequence.

On a default HA setup, the following key services for cluster operations are always running on both head nodes:

- **CMDaemon:** providing certain functionality on both head nodes (e.g. provisioning)
- **DHCP:** load balanced setup
- **TFTP:** requests answered on demand, under xinetd
- **LDAP:** running in replication mode (the active head node LDAP database is pulled by the passive)
- **MySQL:** running in master-slave replication mode (the active head node MySQL database is pulled by the passive)
- **NTP**
- **DNS**

When an HA setup is created from a single head node setup, the above services are automatically reconfigured to run in the HA environment over two head nodes.

**Provisioning role runs on both head nodes** In addition, both head nodes also take up the *provisioning role*, which means that nodes can be provisioned from both head nodes. As the passive head node is then also provisioned from the active, and the active can switch between primary and secondary, it means both heads are also given a value for `provisioninginterface` (section 5.4.7).

For a head node in a single-headed setup, there is no value set by default. For head nodes in an HA setup, the value of `provisioninginterface` for each head node is automatically set up by default to the interface device name over which the image can be received when the head node is passive.

The implications of running a cluster with multiple provisioning nodes are described in detail in section 5.2. One important aspect described in that section is how to make provisioning nodes aware of image changes.

From the administrator's point of view, achieving awareness of image changes for provisioning nodes in HA clusters is dealt with in the same way as for single-headed clusters. Thus, if using `cmsh`, the `updateprovisioners` command from within `softwareimage` mode is used, whereas if Bright View is used, then the clickpath `Provisioning→Provisioning requests→Update provisioning nodes` can be followed (section 5.2.4)

### Services That Migrate To The Active Node

Although it is possible to configure any service to migrate from one head node to another in the event of a failover, in a typical HA setup only the following services migrate:

- NFS
- The User Portal
- Workload Management (e.g. SGE, Torque/Maui)

#### 15.1.4 Failover Network Topology

A two-head failover network layout is illustrated in figure 15.1.




Figure 15.1: High Availability: Two-Head Failover Network Topology

In the illustration, the primary **head1** is originally a head node before the failover design is implemented. It is originally set up as part of a Type 1 network (section 3.3.6 of the *Installation Manual*), with an internal interface **eth0**, and an external interface **eth1**.

When the secondary head is connected up to help form the failover system, several changes are made.

#### HA: Network Interfaces

Each head node in an HA setup typically has at least an external and an internal network interface, each configured with an IP address.

In addition, an HA setup uses two virtual IP interfaces, each of which has an associated virtual IP address: the external shared IP address and the internal shared IP address. These are shared between the head nodes, but only one head node can host the address and its interface at any time.

In a normal HA setup, a shared IP address has its interface hosted on the head node that is operating in active mode. On failover, the interface migrates and is hosted on the head node that then becomes active.

When head nodes are also being used as login nodes, users outside of the cluster are encouraged

to use the shared external IP address for connecting to the cluster. This ensures that they always reach whichever head node is active. Similarly, inside the cluster, nodes use the shared internal IP address wherever possible for referring to the head node. For example, nodes mount NFS filesystems on the shared internal IP interface so that the imported filesystems continue to be accessible in the event of a failover.

Shared interfaces are implemented as alias interfaces on the physical interfaces (e.g. `eth0:0`). They are activated when a head node becomes active, and deactivated when a head node becomes passive.

### HA: Dedicated Failover Network

In addition to the normal internal and external network interfaces on both head nodes, the two head nodes are usually also connected using a direct dedicated network connection, `eth2` in figure 15.1. This connection is used between the two head nodes to monitor their counterpart's availability. It is called a *heartbeat* connection because the monitoring is usually done with a regular heartbeat-like signal between the nodes such as a ping, and if the signal is not detected, it suggests a head node is dead.

To set up a failover network, it is highly recommended to simply run a UTP cable directly from the NIC of one head node to the NIC of the other, because not using a switch means there is no disruption of the connection in the event of a switch reset.

#### 15.1.5 Shared Storage

Almost any HA setup also involves some form of shared storage between two head nodes to preserve state after a failover sequence. For example, user home directories must always be available to the cluster in the event of a failover.

In the most common HA setup, the following two directories are shared:

- `/home`, the user home directories
- `/cm/shared`, the shared tree containing applications and libraries that are made available to the nodes

The shared filesystems are only available on the active head node. For this reason, it is generally recommended that users login via the shared IP address, rather than ever using the direct primary or secondary IP address. End-users logging into the passive head node by direct login may run into confusing behavior due to unmounted filesystems.

Although Bright Cluster Manager gives the administrator full flexibility on how shared storage is implemented between two head nodes, there are generally three types of storage used: NAS, DAS, and DRBD.

### NAS

In a Network Attached Storage (NAS) setup, both head nodes mount a shared volume from an external network attached storage device. In the most common situation this would be an NFS server either inside or outside of the cluster.

Because imported mounts can typically not be re-exported (which is true at least for NFS), nodes typically mount filesystems directly from the NAS device.

### DAS

In a Direct Attached Storage (DAS) setup, both head nodes share access to a block device that is usually accessed through a SCSI interface. This could be a disk-array that is connected to both head nodes, or it could be a block device that is exported by a corporate SAN infrastructure.

Although the block device is visible and can physically be accessed simultaneously on both head nodes, the filesystem that is used on the block device is typically not suited for simultaneous access. Simultaneous access to a filesystem from two head nodes must therefore be avoided because it generally leads to filesystem corruption. Only special purpose parallel filesystems such as GPFS and Lustre are capable of being accessed by two head nodes simultaneously.

## DRBD

In a setup with DRBD (Distributed Replicated Block Device), both head nodes mirror a physical block device on each node device over a network interface. This results in a virtual shared DRBD block device. A DRBD block device is effectively a DAS block device simulated via a network. DRBD is a cost-effective solution for implementing shared storage in an HA setup. While a DRBD device itself is not configured by the cluster manager, a DRBD device that is already configured is recreated by the cluster manager. Recreating means that data on the DRBD device is wiped.

The use of DRBD is not recommended by Bright Cluster Manager, and RHEL7 and CentOS7 no longer provide packages for it.

## Custom Shared Storage With Mount And Unmount Scripts

The cluster management daemon on the two head nodes deals with shared storage through a *mount script* and an *unmount script*. When a head node is moving to active mode, it must acquire the shared filesystems. To accomplish this, the other head node first needs to relinquish any shared filesystems that may still be mounted. After this has been done, the head node that is moving to active mode invokes the *mount script* which has been configured during the HA setup procedure. When an active head node is requested to become *passive* (e.g. because the administrator wants to take it down for maintenance without disrupting jobs), the *unmount script* is invoked to release all shared filesystems.

By customizing the *mount* and *unmount* scripts, an administrator has full control over the form of shared storage that is used. Also an administrator can control which filesystems are shared.

Mount scripts paths can be set via `cmsh` or Bright View (section 15.4.6).

### 15.1.6 Guaranteeing One Active Head At All Times

Because of the risks involved in accessing a shared filesystem simultaneously from two head nodes, it is vital that only one head node is in active mode at any time. To guarantee that a head node that is about to switch to active mode will be the only head node in active mode, it must either receive confirmation from the other head node that it is in passive mode, or it must make sure that the other head node is powered off.

## What Is A Split Brain?

When the passive head node determines that the active head node is no longer reachable, it must also take into consideration that there could be a communication disruption between the two head nodes. Because the “brains” of the cluster are communicatively “split” from each other, this is called a *split brain* situation.

Since the normal communication channel between the passive and active may not be working correctly, it is not possible to use only that channel to determine either an inactive head or a split brain with certainty. It can only be suspected.

Thus, on the one hand, it is possible that the head node has, for example, completely crashed, becoming totally inactive and thereby causing the lack of response. On the other hand, it is also possible that, for example, a switch between both head nodes is malfunctioning, and that the active head node is still up and running, looking after the cluster as usual, and that the head node in turn observes that the passive head node seems to have split away from the network.

Further supporting evidence from the dedicated failover network channel is therefore helpful. Some administrators find this supporting evidence an acceptable level of certainty, and configure the cluster to decide to automatically proceed with the failover sequence, while others may instead wish to examine the situation first before manually proceeding with the failover sequence. The implementation of automatic vs manual failover is described in section 15.1.7. In either implementation, *fencing*, described next, takes place until the formerly active node is powered off.

## Going Into Fencing Mode

To deal with a suspected inactive head or split brain, a passive head node that notices that its active counterpart is no longer responding, first goes into *fencing* mode from that time onwards. While a node

is fencing, it will try to obtain proof via another method that its counterpart is indeed inactive.

Fencing, incidentally, does not refer to a thrust-and-parry imagery derived from fencing swordplay. Instead, it refers to the way all subsequent actions are tagged and effectively fenced-off as a backlog of actions to be carried out later. If the head nodes are able to communicate with each other before the passive decides that its counterpart is now inactive, then the fenced-off backlog is compared and synced until the head nodes are once again consistent.

### Ensuring That The Unresponsive Active Is Indeed Inactive

There are two ways in which “proof” can be obtained that an unresponsive active is inactive:

1. By asking the administrator to manually confirm that the active head node is indeed powered off
2. By performing a power-off operation on the active head node, and then checking that the power is indeed off to the server. This is also referred to as a STONITH (Shoot The Other Node In The Head) procedure

It should be noted that just pulling out the power cable is not the same as a power-off operation (section 15.2.4).

Once a guarantee has been obtained that the active head node is powered off, the fencing head node (i.e. the previously passive head node) moves to active mode.

### Improving The Decision To Initiate A Failover With A Quorum Process

While the preceding approach guarantees one active head, a problem remains.

In situations where the passive head node loses its connectivity to the active head node, but the active head node is communicating without a problem to the entire cluster, there is no reason to initiate a failover. It can even result in undesirable situations where the cluster is rendered unusable if, for example, a passive head node decides to power down an active head node just because the passive head node is unable to communicate with any of the outside world (except for the PDU feeding the active head node).

One technique used by Bright Cluster Manager to reduce the chances of a passive head node powering off an active head node unnecessarily is to have the passive head node carry out a quorum procedure. All nodes in the cluster are asked by the passive node to confirm that they also cannot communicate with the active head node. If more than half of the total number of nodes confirm that they are also unable to communicate with the active head node, then the passive head node initiates the STONITH procedure and moves to active mode.

#### 15.1.7 Automatic Vs Manual Failover

Administrators have a choice between creating an HA setup with automatic or manual failover. In case of automatic failover, an active head node is powered off when it is no longer responding at all, and a failover sequence is initiated automatically.

In case of manual failover, the administrator is responsible for initiating the failover when the active head node is no longer responding. No automatic power off is done, so the administrator is asked to confirm that the previously active node is powered off.

For automatic failover to be possible, power control must be defined for both head nodes. If power control is defined for the head nodes, automatic failover is attempted by default. However, it is possible to disable automatic failover. In `cmsh` this is done by setting the `disableautomaticfailover` property, which is a part of the HA-related parameters (section 15.4.6):

```
[root@bright80 ~]# cmsh
[bright80]% partition failover base
[bright80->partition[base]->failover]% set disableautomaticfailover yes
[bright80->partition*[base*]->failover*]% commit
```



With Bright View it is carried out via the clickpath Cluster→Partition[base]→Settings→Failover→Disable automatic failover

If no power control has been defined, or if automatic failover has been disabled, or if the power control mechanism is not working (for example due to inappropriate, broken or missing electronics or hardware), then a failover sequence must always be initiated manually by the administrator.

In addition, if automatic failover is enabled, but the active head is still slightly responsive (the so-called *mostly dead* state, described in section 15.4.2), then the failover sequence must also be initiated manually by the administrator.

### 15.1.8 HA And Cloud Nodes

As far as the administrator is concerned, HA setup remains the same whether a Cluster Extension is configured or not, and whether a Cluster On Demand is configured or not. Behind the scenes, on failover, any networks associated with the cloud requirements are taken care of by Bright Cluster Manager.

## 15.2 HA Setup Procedure Using `cmha-setup`

After installation (Chapter 3 of the *Installation Manual*) and license activation (Chapter 4 of the *Installation Manual*) an administrator may wish to add a new head node, and convert Bright Cluster Manager from managing an existing single-headed cluster to managing an HA cluster.

### Is An HA-Enabled License Required?

To convert a single-headed cluster to an HA cluster, the existing cluster license should first be checked to see if it allows HA. The `verify-license` command run with the `info` option can reveal this in the MAC address field:

#### Example

```
verify-license /cm/local/apps/cmd/etc/cert.{pem,key} info | grep ^MAC
```

HA-enabled clusters display two MAC addresses in the output. Single-headed clusters show only one.

If an HA license is not present, it should be obtained from the Bright Cluster Manager reseller, and then be activated and installed (Chapter 4 of the *Installation Manual*).

### Existing User Certificates Become Invalid

Installing the new license means that any existing user certificates will lose their validity (page 67 of the *Installation Manual*) on Bright View session logout. This means:

- If LDAP is managed by Bright Cluster Manager, then on logout, new user certificates are generated, and a new Bright View login session picks up the new certificates automatically.
- For LDAPs other than that of Bright Cluster Manager, the user certificates need to be regenerated.

It is therefore generally good practice to have an HA-enabled license in place before creating user certificates and profiles if there is an intention of moving from a single-headed to an HA-enabled cluster later on.

### The `cmha-setup` Utility For Configuring HA

The `cmha-setup` utility is a special tool that guides the administrator in building an HA setup from a single head cluster. It is not part of the cluster manager itself, but is a cluster manager tool that interacts with the cluster management environment by using `cmsh` to create an HA setup. Although it is in theory also possible to create an HA setup manually, using either Bright View or `cmsh` along with additional steps, this is not supported, and should not be attempted as it is error-prone.

A basic HA setup is created in three stages:

1. **Preparation** (section 15.2.1): the configuration parameters are set for the shared interface and for the secondary head node that is about to be installed.



2. **Cloning** (section 15.2.2): the secondary head node is installed by cloning it from the primary head node.
3. **Shared Storage Setup** (section 15.2.3): the method for shared storage is chosen and set up.

An optional extra stage is:

4. **Automated Failover Setup** (section 15.2.4): Power control to allow automated failover is set up.

### 15.2.1 Preparation

The following steps prepare the primary head node for the cloning of the secondary. The preparation is done only on the primary, so that the presence of the secondary is not actually needed during this stage.

0. It is recommended that all nodes except for the primary head node are powered off, in order to simplify matters. The nodes should in any case be power cycled or powered back on after the basic HA setup stages (sections 15.2.1-15.2.3, and possibly section 15.2.4) are complete.
1. To start the HA setup, the `cmha-setup` command is run from a `root` shell on the primary head node.
2. Setup is selected from the main menu (figure 15.2).




Figure 15.2: `cmha-setup` Main menu

3. Configure is selected from the Setup menu.
4. A license check is done. Only if successful does the setup proceed further. If the cluster has no HA-enabled license, a new HA-enabled license must first be obtained from the Bright Cluster Manager reseller, and activated (section 4.3 of the *Installation Manual*).
5. The virtual shared internal alias interface name and virtual shared internal IP alias address are set.
6. The virtual shared external alias interface name and virtual shared external IP alias address are set. To use DHCP assignments on external interfaces, 0.0.0.0 can be used.
7. The host name of the passive is set.

8. Failover network parameters are set. The failover network physical interface should exist, but the interface need not be up. The network name, its base address, its netmask, and domain name are set. This is the network used for optional heartbeat monitoring.
9. Failover network interfaces have their name and IP address set for the active and passive nodes.
10. The primary head node may have other network interfaces (e.g. InfiniBand interfaces, a BMC interface, alias interface on the BMC network). These interfaces are also created on the secondary head node, but the IP address of the interfaces still need to be configured. For each such interface, when prompted, a unique IP address for the secondary head node is configured.
11. The network interfaces of the passive head node are reviewed and can be adjusted as required. DHCP assignments on external interfaces can be set by using an IP address of 0.0.0.0.
12. A summary screen displays the planned failover configuration. If alterations need to be made, they can be done via the next step.
13. The administrator is prompted to set the planned failover configuration. If it is not set, the main menu of `cmha-setup` is re-displayed.
14. If the option to set the planned failover configuration is chosen, then a password for the MySQL root user is requested. The procedure continues further after the password is entered.
15. Setup progress for the planned configuration is displayed (figure 15.3).




Figure 15.3: `cmha-setup` Setup Progress For Planned Configuration

16. Instructions on what to run on the secondary to clone it from the primary are displayed (figure 15.4).

### 15.2.2 Failover Cloning

There are actually two kinds of cloning possible. Both types use the `/cm/cm-clone-install` command described further on in this section. The two cloning types are:

- **Failover cloning:** A passive head node can be created from the active head node. This uses the `--failover` option to create a copy that is very similar to the active head node, but with changes to make it a passive head, ready for failover purposes.




Figure 15.4: cmha-setup Instructions To Run On Secondary For Cloning

- **Re-cloning:** An active head node can be created from the active head node. This uses the `--clone` option to create an exact copy (re-clone) the head node.

The process described in this section PXE boots the passive from the active, thereby loading a special rescue image from the active that allows cloning from the active to the passive to take place. This section is therefore about failover cloning. How to carry out re-cloning is described in section 15.4.8.

After the preparation has been done by configuring parameters as outlined in section 15.2.1, the failover cloning of the head nodes is carried out. In the cloning instructions that follow, the active node refers to the primary node and the passive node refers to the secondary node. However this correlation is only true for when an HA setup is created for the first time, and it is not necessarily true if head nodes are replaced later on by cloning.

These cloning instructions may also be repeated later on if a passive head node ever needs to be replaced, for example, if the hardware is defective (section 15.4.8). In that case the active head node can be either the primary or secondary.

1. The passive head node is PXE booted off the internal cluster network, from the active head node. It is highly recommended that the active and passive head nodes have identical hardware configurations. The BIOS clock of the head nodes should match and be set to the local time. Typically, the BIOS of both head nodes is also configured so that a hard disk boot is attempted first, and a PXE boot is attempted after a hard disk boot failure, leading to the Cluster Manager PXE Environment menu of options. This menu has a 5s time-out.
2. In the Cluster Manager PXE Environment menu, before the 5s time-out, "Start Rescue Environment" is selected to boot the node into a Linux ramdisk environment.
3. Once the rescue environment has finished booting, a login as root is done. No password is required (figure 15.5).
4. The following command is executed (figure 15.6):  
`/cm/cm-clone-install --failover`
5. When prompted to enter a network interface to use, the interface that was used to boot from the internal cluster network (e.g. `eth0`, `eth1`, ...) is entered. There is often uncertainty about what interface name corresponds to what physical port. This can be resolved by switching to another console and using `"ethtool -p <interface>"`, which makes the NIC corresponding to the interface blink.

```

-----
*Welcome to the Cluster Manager rescue environment*
-----

Creating failover/clone nodes:

# /CM/CM-clone-install --failover
# /CM/CM-clone-install --clone --hostname=new-hostname [--reboot]
# /CM/CM-clone-install --failover [--reboot]

Other useful commands:

# pdmenu          "Menu frontend to programs!"
# dhcpup dhcpcd   "Setup wired network connection!"
# wificonfig      "Setup wireless network connection!"
# mnsetup         "Setup mail and news!"
# lynx (or) links "WWW browsers!" # rtin (or) slrn "Newsreaders!"

You can use 'backup-mbr' to backup/restore the MBR.

login: root
-----

ClusterManager login: root

```

Figure 15.5: Login Screen After Booting Passive Into Rescue Mode From Active

6. If the provided network interface is correct, a `root@master's password` prompt appears. The administrator should enter the root password.
7. An opportunity to view or edit the master disk layout is offered.
8. A confirmation that the contents of the specified disk are to be erased is asked for.
9. The cloning takes place. The “syncing” stage usually takes the most time. Cloning progress can also be viewed on the active by selecting the “Install Progress” option from the Setup menu. When viewing progress using this option, the display is automatically updated as changes occur.
10. After the cloning process has finished, a prompt at the console of the passive asks if a reboot is to be carried out. A “y” is typed in response to this. The passive node should be set to reboot off its hard drive. This may require an interrupt during reboot, to enter a change in the BIOS setting, if for example, the passive node is set to network boot first.
11. Continuing on now on the active head node, `Finalize` is selected from the Setup menu of `cmha-setup`.
12. The MySQL root password is requested. After entering the MySQL password, the progress of the `Finalize` procedure is displayed, and the cloning procedure continues.
13. The cloning procedure of `cmha-setup` pauses to offer the option to reboot the passive. The administrator should accept the reboot option. After reboot, the cloning procedure is complete. The administrator can then go to the main menu and quit from there or go on to configure “Shared Storage” (section 15.2.3) from there.

A check can already be done at this stage on the failover status of the head nodes with the `cmha` command, run from either head node:

### Example

```

ClusterManager login: root
Welcome to Linux 2.6.32-220.23.1.el6.x86_64.
No mail.
# /CM/cm-clone-install --failover
Network interface to use [default: eth0]:
Please wait while authentication is being set up....
root@master's password:
Please wait while installation begins...
Verifying license ..... [ OK ]
Getting build config ..... [ OK ]
Getting disk layout ..... [ OK ]
The head node disk layout is saved in /CM/__masterdisksetup.xml
lv - view, e - edit, c - continue |: c
The contents of the following disks will be erased.
/dev/sda
Do you want to continue [yes/no]? yes
Getting mount points ..... [ OK ]
Partitioning hard drive ..... [ OK ]
Syncing hard drive ..... [ OK ]
Finalizing installation ..... [ OK ]
Do you want to reboot[y/n]:_

```

Figure 15.6: Cloning The Passive From The Active Via A Rescue Mode Session

```

[root@bright80 ~]# cmha status
Node Status: running in active master mode

```

```

Failover status:
bright80* -> master2
  backupper [ OK ]
  mysql [ OK ]
  ping [ OK ]
  status [ OK ]
master2 -> bright80*
  backupper [ OK ]
  mysql [ OK ]
  ping [ OK ]
  status [ OK ]

```

Here, the mysql, ping and status states indicate that HA setup completed successfully. The backupper (backup ping) state uses the dedicated failover network route for its checks, and starts working as soon as the passive head node has been rebooted.

### 15.2.3 Shared Storage Setup

After cloning the head node (section 15.2.2), the last basic stage of creating an HA setup is setting up shared storage. The available shared storage forms are NAS and DAS. The use of DRBD is not recommended by Bright Cluster Manager, but is still available as a form of shared storage at the time of writing (January 2016), for the distributions that still provide it.

#### NAS

1. In the cmha-setup main menu, the “Shared Storage” option is selected.
2. NAS is selected.
3. The parts of the head node filesystem that are to be copied to the NAS filesystems are selected. By default, these are /home and /cm/shared as suggested in section 15.1.5. The point in the filesystem where the copying is done is the future mount path to where the NAS will share the shared filesystem.

An already-configured export that is not shared is disabled in `/etc/exports` by `cmha-setup`. This is done to prevent the creation of stale NFS file handles during a failover. Sharing already-existing exports is therefore recommended. Storage can however be dealt with in a customized manner with mount and unmount scripts (page 540).

4. The NFS host name is configured. Also, for each head node filesystem that is to be copied to the NAS filesystem, there is an associated path on the NAS filesystem where the share is to be served from. These NFS volume paths are now configured.
5. If the configured NFS filesystems can be correctly mounted from the NAS server, the process of copying the local filesystems onto the NAS server begins.

## DAS

A prerequisite to the DAS configuration steps that follow is that the partitions exist on the DAS device that is to be used for shared storage. These should be created manually if required, before running `cmha-setup`.

1. In the `cmha-setup` main menu, the “Shared Storage” option is selected.
2. DAS is selected.
3. The filesystems that are to be shared over the cluster are selected by the administrator. The filesystems that are shared are typically `/cm/shared` and `/home`, but this is not mandatory.
4. The filesystems that are to be shared are assigned DAS partitions by the administrator. For example, the administrator may specify these as `/dev/sdc1` for `/home` and `/dev/sdd3` for `/cm/shared`.
5. The administrator can choose to create a filesystem on the proposed DAS device.
  - Creating the filesystem on the device means any existing filesystems and files on the device are wiped during creation.
  - Otherwise, the existing filesystem and files on the DAS device remain.
6. A filesystem type is set from a choice of `ext3`, `ext4`, `xfs`.
7. A summary screen is presented showing the proposed changes.
8. After filesystems have been created, the current contents of the shared directories are copied onto the shared filesystems and the shared filesystems are mounted over the old non-shared filesystems.
9. The administrator should check that the partitions are visible from both head nodes using, for example, the `fdisk -l` command on the device. If the partitions on the DAS are created or modified, or appear only after the passive head is running due to a hardware-related reason after the passive head is powered on, then the kernel on the passive head may not have reread the partition table. A power cycle of the head nodes is recommended if the partitions are not seen properly.

## DRBD

If a DRBD device is used that already has data on it, then it should be backed up by the administrator, and restored after the `cmha-setup` procedure is complete. This is because the device content is erased by re-creation of the device partitions that takes place during the procedure. The procedure is carried out as follows:

1. In the `cmha-setup` main menu, the “Shared Storage” option is selected.

2. DRBD is selected.
3. The parts of the filesystem that should be placed on DRBD filesystems are selected.
4. The host names of the primary and secondary head nodes and the physical disk partitions to use on both head nodes are entered.
5. That the contents of the listed partitions can be erased on both head nodes is confirmed. After DRBD based filesystems have been created, the current contents of the shared directories are copied onto the DRBD based filesystems and the DRBD based filesystems are mounted over the old non-shared filesystems.
6. Once the setup process has completed, “DRBD Status/Overview” is selected to verify the status of the DRBD block devices.

### 15.2.4 Automated Failover And Relevant Testing

A power-off operation on the active head node server does not mean the same as just pulling out the power cable to the active head node. These actions typically have different effects, and should therefore not be confused with each other. During the power-off operation, the BMC remains up. However, in the case of pulling out the power cable, the BMC is typically turned off too. If the BMC is not reachable, then it means that verifying that the active head has been terminated is uncertain. This is because the data that CMDaemon can access implies a logical possibility that there is a network failure rather than a head node failure. CMDaemon therefore does not carry out an automatic failover if the power cable is pulled out.

For automatic failover to work, the two head nodes must be able to power off their counterpart. This is done by setting up power control (Chapter 4).

#### Testing If Power Control Is Working

The “device power status” command in `cmsh` can be used to verify that power control is functional:

#### Example

```
[master1]% device power status -n mycluster1,mycluster2
apc03:21 ..... [  ON   ] mycluster1
apc04:18 ..... [  ON   ] mycluster2
```

#### Testing The BMC Interface Is Working

If a BMC (Baseboard Management Controller, section 3.7) such as IPMI or iLO is used for power control, it is possible that a head node is not able to reach its own BMC interface over the network. This is especially true when no dedicated BMC network port is used. In this case, `cmsh -c "device power status"` reports a failure for the active head node. This does not necessarily mean that the head nodes cannot reach the BMC interface of their counterpart. Pinging a BMC interface can be used to verify that the BMC interface of a head node is reachable from its counterpart.

#### Example

Verifying that the BMC interface of `mycluster2` is reachable from `mycluster1`:

```
[root@mycluster1 ~]# ping -c 1 mycluster2.bmc.cluster
PING mycluster2.bmc.cluster (10.148.255.253) 56(84) bytes of data.
64 bytes from mycluster2.bmc.cluster (10.148.255.253): icmp_seq=1
ttl=64 time=0.033 ms
```

Verifying that the BMC interface of `mycluster1` is reachable from `mycluster2`:

```
[root@mycluster2 ~]# ping -c 1 mycluster1.bmc.cluster
PING mycluster1.bmc.cluster (10.148.255.254) 56(84) bytes of data.
64 bytes from mycluster1.bmc.cluster (10.148.255.254): icmp_seq=1
ttl=64 time=0.028 ms
```

### Testing Automated Failover Against A Simulated Crash

A normal (graceful) shutdown of an active head node, does not cause the passive to become active, because HA assumes a graceful failover means there is no intention to trigger a failover. To carry out testing of an HA setup with automated failover, it is therefore useful to simulate a kernel crash on one of the head nodes. The following command crashes a head node instantly:

```
echo c > /proc/sysrq-trigger
```

After the active head node freezes as a result of the crash, the passive head node powers off the machine that has frozen and switches to active mode. A hard crash like this can cause a database replication inconsistency when the crashed head node is brought back up and running again, this time passively, alongside the node that took over. This is normally indicated by a `FAILED` status for the output of `cmha status` for MySQL (section 15.4). Database administration with the `dbreclone` command (section 15.4) may therefore be needed to synchronize the databases on both head nodes to a consistent state. Because `dbreclone` is a resource-intensive utility, it is best used during a period when there are few or no users. It is generally only used by administrators when they are instructed to do so by Bright support.

A passive node can also be made active without a crash of the active-until-then node, by using the “`cmha makeactive`” command on the passive (section 15.4.2). Manually running this is not needed in the case of a head node crash in a cluster where power management has been set up for the head nodes, and the automatic failover setting is not disabled.

## 15.3 Running `cmha-setup` Without Ncurses, Using An XML Specification

### 15.3.1 Why Run It Without Ncurses?

The text-based Ncurses GUI for `cmha-setup` is normally how administrators should set up a failover configuration.

The express mode of `cmha-setup` allows an administrator to skip the GUI. This is useful, for example, for scripting purposes and speeding deployment. A further convenience is that this mode uses a human-editable XML file to specify the network and storage definitions for failover.

Running `cmha-setup` without the GUI still requires some user intervention, such as entering the root password for MySQL. The intervention required is scriptable with, for example, Expect, and is minimized if relevant options are specified for `cmha-setup` from the `-x` options.

### 15.3.2 The Syntax Of `cmha-setup` Without Ncurses

The express mode (`-x`) options are displayed when “`cmha-setup -h`” is run. The syntax of the `-x` options is indicated by:

```
cmha-setup [ -x -c <configfile> [-s <type>] [-i|-f[-r]] [-p <mysqlrootpassword>] ]
```

The `-x` options are:

- `-c|--config <configfile>`: specifies the location of `<configfile>`, which is the failover configuration XML file for `cmha-setup`. The file stores the values to be used for setting up a failover head node. The recommended location is at `/cm/local/apps/cluster-tools/ha/conf/failoverconf.xml`.
- `-i|--initialize`: prepares a failover setup by setting values in the CMDaemon database to the values specified in the configuration file. This corresponds to section 15.2.1. The administrator is



prompted for the MySQL root password unless the `-p` option is used. The `-i` option of the script then updates the interfaces in the database, and clones the head node in the CMDaemon database. After this option in the script is done, the administrator normally carries clones the passive node from the active, as described in steps 1 to 10 of section 15.2.2.

- `-f|--finalize`: After the passive node is cloned as described in steps 1 to 10 of section 15.2.2, the finalize option is run on the active node to run the non-GUI finalize procedure. This is the non-GUI version of steps 11 to 13 of section 15.2.2.
  - `-r|--finalizereboot`: makes the passive reboot after the finalize step completes.
- `-s|--sharedstorage <type>`: specifies the shared storage *<type>* out of a choice of `nas`, `das` or `drbd`.
- `-p|--pass <mysqlrootpassword>`: specifies the MySQL root password. Leaving this out means the administrator is prompted to type in the password during a run of the `cmha-setup` script when using the `-x` options.

There is little attempt at validation with the express mode, and invalid entries can cause the command to hang.

### 15.3.3 Example `cmha-setup` Run Without Ncurses

#### Preparation And Initialization:

After shutting down all nodes except for the active head node, a configuration is prepared by the administrator in `/cm/local/apps/cluster-tools/ha/conf/failoverconf.xml`. The administrator then runs `cmha-setup` with the initialization option on the active:

```
[root@bright80 ~]# cd /cm/local/apps/cluster-tools/ha/conf
[root@bright80 conf]# cmha-setup -x -c failoverconf.xml -i
Please enter the mysql root password:
  Initializing failover setup on master      ..... [ OK ]
    Updating shared internal interface      ..... [ OK ]
    Updating shared external interface      ..... [ OK ]
Updating extra shared internal interfaces    ..... [ OK ]
    Updating failover network               ..... [ OK ]
    Updating primary master interfaces      ..... [ OK ]
      Cloning master node                  ..... [ OK ]
    Updating secondary master interfaces    ..... [ OK ]
    Updating failover network interfaces    ..... [ OK ]
      Updating Failover Object             ..... [ OK ]
```

The preceding corresponds to the steps in section 15.2.1.

#### PXE Booting And Cloning The Passive:

The passive head node is then booted up via PXE and cloned as described in steps 1 to 10 of section 15.2.2.

#### Finalizing On The Active And Rebooting The Passive:

Then, back on the active head node the administrator continues the session there, by running the finalization option with a reboot option:

```
[root@bright80 conf]# cmha-setup -x -c failoverconf.xml -f -r
Please enter the mysql root password:
  Updating secondary master mac address      ..... [ OK ]
  Initializing failover setup on master2    ..... [ OK ]
    Cloning database                        ..... [ OK ]
```

```

                Update DB permissions ..... [ OK ]
    Checking for dedicated failover network ..... [ OK ]
A reboot has been issued on master2

```

The preceding corresponds to steps 11 to 13 of section 15.2.2.

### Adding Storage:

Continuing with the session on the active, setting up a shared storage could be done with:

```
[root@bright80 conf]# cmha-setup -x -c failoverconf.xml -s nas
```

The preceding corresponds to carrying out the NAS procedure of section 15.2.3.

## 15.4 Managing HA

Once an HA setup has been created, the tools in this section can be used to manage the HA aspects of the cluster.

### 15.4.1 Changing An Existing Failover Configuration

Changing an existing failover configuration is usually done most simply by running through the HA setup procedure of section 15.2 again, with one exception. The exception is that the existing failover configuration must be removed by using the “Undo Failover” menu option between steps 2 and 3 of the procedure described in section 15.2.1.

### 15.4.2 cmha Utility

A major command-line utility for interacting with the HA subsystem, for regular nodes as well as for head nodes, is `cmha`. It is part of the Bright Cluster Manager `cluster-tools` package. Its usage information is:

```

[root@mycluster1 ~]# cmha
Usage: cmha < status | makeactive [node] | dbreclone <host> |
       nodestatus [name] >

```

```

status                Retrieve and print high availability status
                       of head nodes.

```

```

nodestatus [groups]  Retrieve and print high availability status
                       of failover [groups] (comma separated list of group
                       names. If no argument is given, then the status of
                       all available failover groups is printed.

```

```

makeactive [node]    Make the current head node the active head node. If
                       [node] is specified, then make [node] the active
                       node in the failover group that [node] is part of.

```

```

dbreclone <host>     Clone MySQL database from this head node to
                       <host> (hostname of failover head node).

```

Some of the information and functions of `cmha` can also be carried out via `CMDaemon`:

- For `cmsh`, the following commands can be run from within the base object in partition mode:
  - For the head node, the `status` and `makeactive` commands are run from within the `failover` submode.
  - For regular nodes the `nodestatus` and `makeactive [node]` commands are run from within the `failovergroups` submode.

The `dbreclone` option cannot be carried out in Bright View or `cmsh` because it requires stopping CMDaemon.

The `cmha` options `status`, `makeactive`, and `dbreclone` are looked at in greater detail next:

#### `cmha status`: Querying HA Status

Information on the failover status is displayed thus:

#### Example

```
[root@mycluster1 ~]# cmha status
Node Status: running in active master mode
```

Failover status:

```
mycluster1* -> mycluster2
  backupper [ OK ]
  mysql     [ OK ]
  ping      [ OK ]
  status    [ OK ]
mycluster2 -> mycluster1*
  backupper [ OK ]
  mysql     [ OK ]
  ping      [ OK ]
  status    [ OK ]
```

The `*` in the output indicates the head node which is currently active. The `status` output shows 4 aspects of the HA subsystem from the perspective of each head node:

HA Status	Description
backupper	the other head node is reachable via the dedicated failover network. This backup ping uses the failover route instead of the internal net route. It is a SYN ping.
mysql	MySQL replication status
ping	the other head node is reachable over the primary management network. It is a SYN ping.
status	CMDaemon running on the other head node responds to REST calls

By default, Bright Cluster Manager prepares to carry out the failover sequence (the sequence that includes a STONITH) when all three of `ping`, `backupper` and `status` are not OK on a head node. If these three are not OK, then the active node is *all dead* according to `cmha`. One way of initiating failover is thus by causing a system crash (section 15.2.4).

It can typically take about 30s for the `cmha status` command to output its findings in the case of a recently crashed head node.

#### `cmha makeactive`: Initiate Failover

If automatic failover is enabled (section 15.1.7), then the failover sequence attempts to complete automatically if power management is working properly, and the `cmha status` shows `ping`, `backupper` and `status` as failed.

If automatic failover is disabled, then a manual failover operation must be executed to have a failover operation take place. A manual failover operation can be carried out with the “`cmha makeactive`” command:

#### Example

To initiate a failover manually:

```
[root@mycluster2 ~]# cmha makeactive
Proceeding will initiate a failover sequence which will make this node
(mycluster2) the active master.
```

```
Are you sure ? [Y/N]
```

```
Y
```

```
Your session ended because: CMDaemon failover, no longer master
mycluster2 became active master, reconnecting your cmsh ...
```

On successful execution of the command, the former active head node simply continues to run as a passive head node.

The `cmha makeactive` command assumes both head nodes have no problems preventing the execution of the command.

#### `cmha makeactive` edge case—the mostly dead active:

- For a manual failover operation, if the execution of the `cmha makeactive` command has problems, then it can mean that there is a problem with the initially active head node being in a sluggish state. That is, neither fully functioning, nor all dead. The active head node is thus in a state that is still powered on, but what can be called *mostly dead*. Mostly dead means slightly alive (not all of ping, backupping, and status are FAILED), while all dead means there is only one thing that can sensibly be done to make sure the cluster keeps running—that is, to make the old passive the new active.

Making an old passive the new active is only safe if the old active is guaranteed to not come back as an active head node. This guarantee is set by a STONITH (page 541) for the old active head node, and results in a former active that is now all dead. STONITH thus guarantees that head nodes are not in conflict about their active and passive states. STONITH can however still fail in achieving a clean shutdown when acting on a mostly dead active head node, which can result in unclean filesystem or database states.

Thus, the mostly dead active head node may still be in the middle of a transaction, so that shutting it down may cause filesystem or database corruption. Making the passive node also active then in this case carries risks such as mounting filesystems accidentally on both head nodes, or carrying out database transactions on both nodes. This can also result in filesystem and database corruption.

It is therefore left to the administrator to examine the situation for corruption risk. The decision is either to power off a mostly dead head node, i.e. STONITH to make sure it is all dead, or whether to wait for a recovery to take place. When carrying out a STONITH on the mostly dead active head node, the administrator must power it off *before* the passive becomes active for a manual failover to take place with minimal errors. The `cmha dbreclone` option may still be needed to restore a corrupted database after such a power off, after bringing the system back up.

- For an automated failover configuration, powering off the mostly dead active head node is not carried out automatically due to the risk of filesystem and database corruption. A mostly dead active node with automatic failover configuration therefore stays mostly dead either until it recovers, or until the administrator decides to do a STONITH manually to ensure it is all dead. Here, too, the `cmha dbreclone` option may still be needed to restore a corrupted database after such a power off, after bringing the system back up.

#### `cmha dbreclone`: Cloning The CMDaemon Database

The `dbreclone` option of `cmha` clones the CMDaemon state database from the head node on which `cmha` runs to the head node specified after the option. It is normally run in order to clone the database from the active head node to the passive—running it from the passive to the active can cause a loss

of database entries. Running the `dbreclone` option can be used to retrieve the MySQL CMDaemon state database tables, if they are, for example, unsalvageably corrupted on the destination node, and the source node has a known good database state. Because it is resource intensive, it is best run when there are few or no users. It is typically only used by administrators after being instructed to do so by Bright support.

### Example

```
[root@bright80 ~]# cmha status
Node Status: running in active master mode

Failover status:
bright80* -> head2
  backupping   [ OK ]
  mysql        [ OK ]
  ping         [ OK ]
  status       [ OK ]
head2 -> bright80*
  backupping   [ OK ]
  mysql        [FAILED] (11)
  ping         [ OK ]
  status       [ OK ]
[root@bright80 ~]# cmha dbreclone head2
Proceeding will cause the contents of the cmdaemon state database on he\
ad2 to be resynchronized from this node (i.e. bright80 -> head2)

Are you sure ? [Y/N]
Y
Waiting for CMDaemon (3113) to terminate...
[ OK ]
Waiting for CMDaemon (7967) to terminate...
[ OK ]

cmdaemon.dump.8853.sql          100% 253KB 252.9KB/s 00:00
slurmacctdb.dump.8853.sql      100%  11KB 10.7KB/s 00:00
Waiting for CMDaemon to start... [ OK ]
Waiting for CMDaemon to start... [ OK ]
[root@bright80 ~]# cmha status
Node Status: running in active master mode

Failover status:
bright80* -> head2
  backupping   [ OK ]
  mysql        [ OK ]
  ping         [ OK ]
  status       [ OK ]
head2 -> bright80*
  backupping   [ OK ]
  mysql        [ OK ]
  ping         [ OK ]
  status       [ OK ]
```

### 15.4.3 States

The state a head node is in can be determined in three different ways:

- 1 By looking at the message being displayed at login time.

### Example

```
-----
Node Status: running in active master mode
-----
```

2 By executing `cmha status`.

### Example

```
[root@mycluster ~]# cmha status
Node Status: running in active master mode
...
```

3 By examining `/var/spool/cmd/state`.

There are a number of possible states that a head node can be in:

State	Description
INIT	Head node is initializing
FENCING	Head node is trying to determine whether it should try to become active
ACTIVE	Head node is in active mode
PASSIVE	Head node is in passive mode
BECOMEACTIVE	Head node is in the process of becoming active
BECOMEPASSIVE	Head node is in the process of becoming passive
UNABLETOBECOMEACTIVE	Head node tried to become active but failed
ERROR	Head node is in error state due to unknown problem

Especially when developing custom mount and unmount scripts, it is quite possible for a head node to go into the `UNABLETOBECOMEACTIVE` state. This generally means that the mount and/or unmount script are not working properly or are returning incorrect exit codes. To debug these situations, it is helpful to examine the output in `/var/log/cmdaemon`. The “`cmha makeactive`” shell command can be used to instruct a head node to become active again.

#### 15.4.4 Failover Action Decisions

A table summarizing the scenarios that decide when a passive head should take over is helpful:

Event on active	Reaction on passive	Reason
Reboot	Nothing	Event is usually an administrator action. To make the passive turn active, an administrator would run “ <code>cmha makeactive</code> ” on it.

...continues

...continued

Event on active	Reaction on passive	Reason
Shutdown	Nothing	As above.
Unusably sluggish or freezing system by state pingable with SYN packets	Nothing	1. Active may still unfreeze. 2. Shared filesystems may still be in use by the active. Concurrent use by the passive taking over therefore risks corruption. 3. Mostly dead head can be powered off by administrator after examining situation (section 15.4.2).
Become passive in response to <code>"cmha makeactive"</code> run on passive	Become active when former active becomes passive	As ordered by administrator
Active dies	Quorum called, may lead to passive becoming new active	Confirms if active head is dead according to other nodes too. If so, then a "power off" command is sent to it. If the command is successful, the passive head becomes the new active head.

### 15.4.5 Keeping Head Nodes In Sync

#### What Should Be Kept In Sync?

- It is a best practice to carry out a manual `updateprovisioners` command on the active head node, immediately after a regular node software image change has been made.

A successful run of the `updateprovisioners` command means that in the event of a failover, the formerly passive head node already has up-to-date regular node software images, which makes further administration simpler.

The background behind why it is done can be skipped, but it is as follows:

An image on the passive head node, which is a node with a provisioning role, is treated as an image on any other provisioning node. This means that it eventually synchronizes to a changed image on the active head node. By default the synchronization happens at midnight, which means images may remain out-of-date for up to 24 hours.

Since the passive head is a provisioning node, it also means that an attempt to provision regular nodes from it with the changed image will not succeed if it happens too soon after the image change event on the active head. "Too soon" means within the `autoupdate` period defined by the parameter `provisioningnodeautoupdate timeout` (page 138).

If on the other hand the `autoupdate timeout` is exceeded, then by itself this does not lead to the image on the passive head node becoming synchronized with an image from the active head node. Such synchronization only takes place as part of regular housekeeping (at midnight by default). Or it takes place if a regular node sends a provisioning request to the passive head node, which can take place during the reboot of the regular node.

This synchronization logic is followed to reduce the load on the head node. The only pitfall in this is the case when an administrator changes an image on the active head node, and then soon after that the passive head node becomes active as part of a failover, without the images having

had enough time to synchronize. In that case the formerly passive node ends up with out-of-date software images.

- Changes controlled by CMDaemon are synchronized automatically.

If the output of `cmha status` is not OK, then it typically means that the CMDaemon databases of the active head node and the passive head node are not synchronized. This situation may be resolved by waiting, typically for several minutes. If the status does not resolve on its own, then this indicates a more serious problem which should be investigated further.

- If filesystem changes are made on an active head node without using CMDaemon (`cmsh` or Bright View), and if the changes are outside the shared filesystem, then these changes should normally also be made by the administrator on the passive head node. For example:
  - RPM installations/updates (section 11.2)
  - Applications installed locally
  - Files (such as drivers or values) placed in the `/cm/node-installer/` directory and referred to by `initialize` (section 5.4.5) and `finalize` scripts (section 5.4.11)
  - Any other configuration file changes outside of the shared filesystems

The reason behind not syncing everything automatically is to guarantee that a change that breaks a head node is not accidentally propagated to the passive. This way there is always a running head node. Otherwise, if automated syncing is used, there is a risk of ending up with two broken head nodes at the same time.

If the cluster is being built on bare metal, then a sensible way to minimize the amount of work to be done is to install a single head cluster first. All packages and applications should then be placed, updated and configured on that single head node until it is in a satisfactory state. Only then should HA be set up as described in section 15.2, where the cloning of data from the initial head node to the secondary is described. The result is then that the secondary node gets a well-prepared system with the effort to prepare it having only been carried out once.

### Avoiding Encounters With The Old Filesystems

It should be noted that when the shared storage setup is made, the contents of the shared directories (at that time) are copied over from the local filesystem to the newly created shared filesystems. The shared filesystems are then mounted on the mountpoints on the active head node, effectively hiding the local contents.

Since the shared filesystems are only mounted on the active machine, the old filesystem contents remain visible when a head node is operating in passive mode. Logging into the passive head node may thus confuse users and is therefore best avoided.

### Updating Services On The Head Nodes And Associated Syncing

The services running on the head nodes described in section 15.1.3 should also have their packages updated on both head nodes.

For the services that run simultaneously on the head nodes, such as CMDaemon, DHCP, LDAP, MySQL, NTP and DNS, their packages should be updated on both head nodes at about the same time. A suggested procedure is to stop the service on both nodes around the same time, update the service and ensure that it is restarted.

The provisioning node service is part of the CMDaemon package. The service updates images from the active head node to all provisioning nodes, including the passive head node, if the administrator runs the command to update provisioners. How to update provisioners is described in section 15.1.3.

For services that migrate across head nodes during failover, such as NFS and Workload Management, it is recommended (but not mandated) to carry out this procedure: the package on the passive node (called the secondary for the sake of this example) is updated to check for any broken package



behavior. The secondary is then made active with `cmha makeactive` (section 15.4.2), which automatically migrates users cleanly off from being serviced by the active to the secondary. The package is then updated on the primary. If desired, the primary can then be made active again. The reason for recommending this procedure for services that migrate is that, in case the update has issues, the situation can be inspected somewhat better with this procedure.

### 15.4.6 High Availability Parameters

There are several HA-related parameters that can be tuned. Accessing these via Bright View is described in section 15.4.6. In `cmsh` the settings can be accessed in the `failover` submode of the `base` partition.

#### Example

```
[mycluster1]% partition failover base
[mycluster1->partition[base]->failover]% show
```

Parameter	Value
Dead time	10
Disable automatic failover	no
Failover network	failovernet
Init dead	30
Keep alive	1
Mount script	
Postfailover script	
Prefailover script	
Quorum time	60
Revision	
Secondary headnode	
Unmount script	
Warn time	5

Dead time

When a passive head node determines that the active head node is not responding to any of the periodic checks for a period longer than the `Dead time` seconds, the active head node is considered dead and a quorum procedure starts. Depending on the outcome of the quorum, a failover sequence may be initiated.

Disable automatic failover

Setting this to `yes` disables automated failover. Section 15.1.7 covers this further.

Failover network

The `Failover network` setting determines which network is used as a dedicated network for the backupper (backup ping) heartbeat check. The heartbeat connection is normally a direct cable from a NIC on one head node to a NIC on the other head node. The network can be selected via tab-completion suggestions. By default, without a dedicated failover network, the possibilities are `nothing`, `externalnet` and `internalnet`.

Init dead

When head nodes are booted simultaneously, the standard `Dead time` might be too strict if one head node requires a bit more time for booting than the other. For this reason, when a head node boots (or more exactly, when the cluster management daemon is starting), a time of `Init dead` seconds is used rather than the `Dead time` to determine whether the other node is alive.

Keep alive

The `Keep alive` value is the time interval, in seconds, over which the passive head node carries out a check that the active head node is still up. If a dedicated failover network is used, 3 separate heartbeat

checks are carried out to determine if a head node is reachable.

#### Mount script

The script pointed to by the `Mount script` setting is responsible for bringing up and mounting the shared filesystems.

#### Postfailover script

The script pointed to by the `Postfailover script` setting is run by `cmdaemon` on both head nodes. The script first runs on the head that is now passive, then on the head that is now active. It runs as soon as the former passive has become active. It is typically used by scripts mounting an NFS shared storage so that no more than one head node exports a filesystem to NFS clients at a time.

#### Prefailover script

The script pointed to by the `Prefailover script` setting is run by `cmdaemon` on both head nodes. The script first runs on the (still) active head, then on the (still) passive head. It runs as soon as the decision for the passive to become active has been made, but before the changes are implemented. It is typically used by scripts unmounting an NFS shared storage so that no more than one head node exports a filesystem to NFS clients at a time. When unmounting shared storage, it is very important to ensure that a non-zero exit code is returned if unmounting has problems, or the storage may become mounted twice during the `Postfailover script` stage, resulting in data corruption.

#### Quorum time

When a node is asked what head nodes it is able to reach over the network, the node has `Quorum time` seconds to respond. If a node does not respond to a call for quorum within that time, it is no longer considered for the results of the quorum check.

#### Secondary headnode

The `Secondary headnode` setting is used to define the secondary head node to the cluster.

#### Unmount script

The script pointed to by the `Unmount script` setting is responsible for bringing down and unmounting the shared filesystems.

#### Warn time

When a passive head node determines that the active head node is not responding to any of the periodic checks for a period longer than `Warn time` seconds, a warning is logged that the active head node might become unreachable soon.

### 15.4.7 Viewing Failover Via Bright View

#### Accessing `cmsh` HA Parameters (partition failover base) Via Bright View

The Bright View equivalents of the `cmsh` HA parameters in section 15.4.6 are accessed from the clickpath `Cluster→Partition[base]→Settings→Failover`

### 15.4.8 Re-cloning A Head Node

Some time after an HA setup has gone into production, it may become necessary to re-install one of the head nodes, for example if one of the head nodes were replaced due to hardware failure.

To re-clone a head node from an existing active head node, the head node hardware that is going to become the clone can be PXE-booted into the rescue environment, as described in section 15.2.2. Instead of running the `cm-clone-install --failover` command as in that section, the following command can be run:

```
[root@bright80 ~]# /cm/cm-clone-install --clone --hostname=<new host name>
```

If the clone is merely intended as a backup, then the clone hardware does not have to match the head node. For a backup, typically the most important requirement is then that a clone drive should not run out of space—that is, its drive should be as large as, or larger than the matching drive of the head node.

If the clone is to be put to work as a head node, then, if the MAC address of one of the head nodes has changed, it is typically necessary to request that the product key is unlocked, so that a new license can be obtained (section 4.3 of the *Installation Manual*).

### Exclude Lists And Cloning

Some files are normally excluded from being copied across from the head node to the clone, because syncing them is not appropriate.

The following exclude files are read from inside the directory `/cm/` on the clone node when the `cm-clone-install` command is run (step 4 in section 15.2.2).

- `excludelistnormal`: used to exclude files to help generate a clone of the other head node. It is read when running the `cm-clone-install` command without the `--failover` option.
- `excludelistfailover`: used to exclude files to help generate a passive head node from an active head node. It is read when running the `cm-clone-install --failover` command.

In a default cluster, there is no need to alter these exclude files. However some custom head node configurations may require appending a path to the list.

The cloning that is carried out is logged in `/var/log/clone-install-log`.

### Exclude Lists In Perspective

The exclude lists `excludelistfailover` and `excludelistnormal` described in the preceding paragraphs should not be confused with the exclude lists of section 5.6.1. The exclude lists of section 5.6.1:

- `excludelistupdate`
- `excludelistfullinstall`
- `excludelistsyncinstall`
- `excludelistgrabnew`
- `excludelistgrab`
- `excludelistmanipulatescript`

are Bright View or `cmsh` options, and are maintained by `CMDaemon`. On the other hand, the exclude lists introduced in this section (15.4.8):

- `excludelistfailover`
- `excludelistnormal`

are not Bright View or `cmsh` options, are not modified with `excludelistmanipulatescript`, are not maintained by `CMDaemon`, but are made use of when running the `cm-clone-install` command.

### Btrfs And `cm-clone-install`

If a partition with Btrfs (section 13.4.1) is being cloned using `cm-clone-install`, then by default only mounted snapshots are cloned.

If all the snapshots are to be cloned, then the `--btrfs-full-clone` flag should be passed to the `cm-clone-install` command. This flag clones all the snapshots, but it is carried out with duplication (i.e. bypassing the COW method), which means the filesystem size can increase greatly.

## 15.5 HA For Regular Nodes

HA for regular nodes is available from Bright Cluster Manager version 7.0 onwards.

### 15.5.1 Why Have HA On Regular Nodes?

HA for regular nodes can be used to add services to the cluster and make them HA. Migrating the default existing HA services that run on the head node is not recommended, since these are optimized and integrated to work well as is. Instead, good candidates for this feature are other, extra, services that can run, or are already running, on regular nodes, but which benefit from the extra advantage of HA.

### 15.5.2 Comparing Head And Regular Node HA

Many of the features of HA for regular nodes are as for head nodes. These include:

#### Head And Regular Node HA: Some Features In Common

Power control is needed for all HA nodes, in order to carry out automatic failover (section 15.1.7).

Warn time and dead time parameters can be set (section 15.4.6).

Mount and unmount scripts (page 540).

Pre- and post- failover scripts (section 15.4.6).

Disabling or enabling automatic failover (section 15.1.7).

A virtual shared IP address that is presented as the virtual node that is always up (section 15.1.4).

Some differences between head and regular node HA are:

#### Head And Regular Node HA: Some Features That Differ

Head Node HA	Regular Node HA
Only one passive node.	Multiple passive nodes defined by failover groups.
Can use the optional failover network and backupper heartbeat.	No failover network. Heartbeat checks done via regular node network.
Configured within <code>failover</code> submode of partition mode (section 15.4.6).	Configured within <code>failovergroups</code> submode of partition mode (section 15.5.3).
Installed with <code>cmha-setup</code> (section 15.2).	Installed by administrator using a procedure similar to section 15.5.3.
Requires Bright Cluster Manager Advanced Edition license.	Available in both Standard and Advanced Edition.
A quorum procedure (section 15.1.6). If more than half the nodes can only connect to the passive, then the passive powers off the active and becomes the new active.	Active head node does checks. If active regular node is apparently dead, it is powered off (STONITH). Another regular node is then made active.

### Failover Groups

Regular nodes use *failover groups* to identify nodes that are grouped for HA. Two or more nodes are needed for a failover group to function. During normal operation, one member of the failover group is active, while the rest are passive. A group typically provides a particular service.

#### 15.5.3 Setting Up A Regular Node HA Service

In `cmsh` a regular node HA service, CUPS in this example, can be set up as follows:

##### Making The Failover Group

A failover group must first be made, if it does not already exist:

##### Example

```
[bright80->partition[base]->failovergroups]% status
No active failover groups
[bright80->partition[base]->failovergroups]% add cupsgroup
[bright80->partition*[base*]->failovergroups*[cupsgroup*]]% list
Name (key)          Nodes
-----
cupsgroup
```

By default, CUPS is provided in the standard image, in a stopped state. In Bright View a failover group can be added via the clickpath `Cluster→Partition[base]→Settings→Failover groups→Add`

##### Adding Nodes To The Failover Group

Regular nodes can then be added to a failover group. On adding, Bright Cluster Manager ensures that one of the nodes in the failover group becomes designated as the active one in the group (some text elided):

##### Example

```
[bright80->...[cupsgroup*]]% set nodes node001..node002
[bright80->...[cupsgroup*]]% commit
[bright80->...[cupsgroup*]]%
...Failover group cupsgroup, make node001 become active
...Failover group cupsgroup, failover complete. node001 became active
[bright80->partition[base]->failovergroups[cupsgroup]]%
```

##### Setting Up A Server For The Failover Group

The CUPS server needs to be configured to run as a service on all the failover group nodes. The usual way to configure the service is to set it to run only if the node is active, and to be in a stopped state if the node is passive:

##### Example

```
[bright80->partition[base]->failovergroups[cupsgroup]]% device
[bright80->device]% foreach -n node001..node002 (services; add cups; \
set runif active; set autostart yes; set monitored yes)
[bright80->device]% commit
Successfully committed 2 Devices
[bright80->device]%
Mon Apr  7 08:45:54 2014 [notice] node001: Service cups was started
```

### Setting And Viewing Parameters And Status In The Failover Group

**Knowing which node is active:** The status command shows a summary of the various failover groups in the failovergroups submode, including which node in each group is currently the active one:

#### Example

```
[bright80->partition[base]->failovergroups]% status
Name           State       Active      Nodes
-----
cupsgroup      ok          node001     node001,node002 [  UP  ]
```

**Making a node active:** To set a particular node to be active, the makeactive command can be used from within the failover group:

#### Example

```
[bright80->partition[base]->failovergroups]% use cupsgroup
[bright80->...]->failovergroups[cupsgroup]]% makeactive node002
node002 becoming active ...
[bright80->partition[base]->failovergroups[cupsgroup]]%
... Failover group cupsgroup, make node002 become active
...node001: Service cups was stopped
...node002: Service cups was started
...Failover group cupsgroup, failover complete. node002 became active
```

An alternative is to simply use the cmha utility (section 15.4.2):

#### Example

```
[root@bright80 ~]# cmha makeactive node002
```

**Parameters for failover groups:** Some useful regular node HA parameters for the failover group object, cupsgroup in this case, can be seen with the show command:

#### Example

```
[bright80->partition[base]->failovergroups]% show cupsgroup
Parameter                                           Value
-----
Automatic failover after graceful shutdown         no
Dead time                                           10
Disable automatic failover                         no
Mount script
Name                                                 cupsgroup
Nodes                                                node001,node002
Postfailover script
Prefailover script
Revision
Unmount script
Warn time                                           5
```

### Setting Up The Virtual Interface To Make The Server An HA Service

The administrator then assigns each node in the failover group the same alias interface name and IP address dotted quad on its physical interface. The alias interface for each node should be assigned to start up if the node becomes active.

#### Example

```
[bright80->device]% foreach -n node001..node002 (interfaces; add alias \
bootif:0 ; set ip 10.141.240.1; set startif active; set network internalnet)
[bright80->device*]% commit
Successfully committed 2 Devices
[bright80->device]% foreach -n node001..node002 (interfaces; list)
Type          Network device name  IP          Network
-----
alias          BOOTIF:0             10.141.240.1  internalnet
physical       BOOTIF [prov]          10.141.0.1   internalnet
Type          Network device name  IP          Network
-----
alias          BOOTIF:0             10.141.240.1  internalnet
physical       BOOTIF [prov]          10.141.0.2   internalnet
```

Optionally, each alias node interface can conveniently be assigned a common arbitrary additional host name, perhaps associated with the server, which is CUPS. This does not result in duplicate names here because only one alias interface is active at a time. Setting different additional hostnames for the alias interface to be associated with a unique virtual IP address is not recommended.

### Example

```
[bright80->...interfaces*[BOOTIF:0*]]% set additionalhostnames cups
[bright80->...interfaces*[BOOTIF:0*]]% commit
```

The preceding can also simply be included as part of the `set` commands in the `foreach` statement earlier when the interface was created.

The nodes in the failover group should then be rebooted.

Only the virtual IP address should be used to access the service when using it as a service. Other IP addresses may be used to access the nodes that are in the failover group for other purposes, such as monitoring or direct access.

### Service Configuration Adjustments

A service typically needs to have some modifications in its configuration done to serve the needs of the cluster.

CUPS uses port 631 for its service and by default it is only accessible to the local host. Its default configuration is modified by changing some directives within the `cupsd.conf` file. For example, some of the lines in the default file may be:

```
# Only listen for connections from the local machine.
Listen localhost:631
...
# Show shared printers on the local network.
...
BrowseLocalProtocols

...
<Location />
    # Restrict access to the server...
    Order allow,deny

</Location>
...
```

Corresponding lines in a modified `cupsd.conf` file that accepts printing from hosts on the internal network could be modified and end up looking like:

```
# Allow remote access
Port 631
...
# Enable printer sharing and shared printers.
...
BrowseAddress @LOCAL
BrowseLocalProtocols CUPS dnssd
...
<Location />
  # Allow shared printing...
  Order allow,deny
  Allow from 10.141.0.0/16
</Location>
...
```

The operating system that ends up on the failover group nodes should have the relevant service modifications running on those nodes after these nodes are up. In general, the required service modifications could be done:

- with an `initialize` or `finalize` script, as suggested for minor modifications in section 3.15.4
- by saving and using a new image with the modifications, as suggested for greater modifications in section 3.15.2, page 111.

### Testing Regular Node HA

To test that the regular node HA works, the active node can have a simulated crash carried out on it like in section 15.2.4.

#### Example

```
ssh node001
echo c > /proc/sysrq-trigger
~.
```

A passive node then takes over.

### 15.5.4 The Sequence Of Events When Making Another HA Regular Node Active

The active head node tries to initiate the actions in the following sequence, after the `makeactive` command is run (page 564):



Sequence Of Events In Making Another HA Regular Node Active	
---	--

All	Run pre-failover script
Active	Stop service
	Run umount script (stop and show <code>exit&gt;0</code> on error)
	Stop active IP address
	Start passive IP address
	Start services on passive. Active is now passive
Passive	Stop service
	Run mount script
	Stop passive IP address.
	Start active IP address.
	Start service. Passive is now active.
All	Post-failover script

The actions are logged by CMDaemon.

The following conditions hold for the sequence of actions:

- The remaining actions are skipped if the active `umount` script fails.
- The sequence of events on the initial active node is aborted if a STONITH instruction powers it off.
- The actions for `All` nodes is done for that particular failover group, for all nodes in that group.

## 15.6 HA And Workload Manager Jobs

Workload manager jobs continue to run through a failover handover if conditions allow it.

The 3 conditions that must be satisfied are:

1. The workload manager setup must have been carried out
  - (a) during initial installation  
or
  - (b) during a run of `wlm-setup`
2. The HA storage setup must support the possibility of job continuity for that workload manager. This support is possible for the workload manager and HA storage pairings indicated by the following table:

Table 15.6: HA Support For Jobs Vs Shared Filesystems

WLM	DRBD	DAS	NAS
Slurm	Y	Y	Y
OGS	Y	Y	Y

...continues

Table 15.6: HA Support For WLM Jobs Vs Shared Filesystems...continued

WLM	DRBD	DAS	NAS
UGE	Y	Y	Y
Torque	Y	Y	Y
PBSPPro	N	N	Y
LSF	N	N	Y
OpenLava	N	N	Y

As the table shows, PBS Pro, LSF and OpenLava are not able to support HA for jobs on DRBD or DAS filesystems. This is because they require daemons to run on the passive and active nodes at the same time, in order to provide access to `/cm/shared` at all times. During failover the daemons normally cannot run on the node that has failed, which means that the DAS and DRBD storage types cannot provide access to `/cm/shared` during this time. Job continuity cannot therefore be supported for these workload manager and storage type combinations.

- Jobs must also not fail due to the shared filesystem being inaccessible during the short period that it is unavailable during failover. This usually depends on the code in the job itself, rather than the workload manager, since workload manager clients by default have timeouts longer than the dead time during failover.

Already-submitted jobs that are not yet running continue as they are, and run when the resources become available after the failover handover is complete, unless they fail as part of the Bright Cluster Manager pre-job health check configuration.

# 16

## Dell BIOS Management

### 16.1 Introduction

Dell BIOS management in Bright Cluster Manager means that for nodes that run on Dell hardware, the BIOS settings and BIOS firmware updates can be managed via the standard Bright front end utilities to CMDaemon, Bright View and `cmsh`.

In turn, CMDaemon configures the BIOS settings and applies firmware updates to each node via a standard Dell utility called `racadm`. The `racadm` utility is part of the Dell OpenManage software stack.

The Dell hardware supported is listed in the following table:

Models
--------

14G
-----

R430, R630, R730, R730XD, R930
--------------------------------

FC430, FC630, FC830
---------------------

M630, M830
------------

C6320
-------

Bright Cluster Manager supports iDRAC Express and iDRAC Enterprise for these models too. This chapter describes the Dell BIOS management integration features, with:

- An introduction to the integration features (section 16.1)
- The prerequisites for the integration to work (section 16.2)
- A description of settings management in Bright View and `cmsh` (section 16.3)
- A troubleshooting FAQ (section 16.4)

### 16.2 Prerequisites For BIOS Management

- The utility `racadm` must be present on the Bright Cluster Manager head node. The utility is installed on the head node if Dell is selected as the node hardware manufacturer during Bright Cluster Manager installation (section 3.3.5 of the *Installation Manual*).
- IPMI must be working on all of the servers. This means that it should be possible to communicate out-of-band from the head node to all of the compute nodes, via the IPMI IP address.
- iDRAC management privileges must be enabled for all the nodes for the Bright BMC user (username: `bright`, userid: 4). This operation has to be performed manually. This privilege cannot be enabled during node provisioning by Bright during the BMC configuration step.

## 16.3 BIOS settings

### 16.3.1 Initializing The BIOS Settings Via `cmsh`

Initially, by default, there are no values set for the BIOS settings in the nodes or categories. An administrator therefore typically imports the values for the nodes from the cluster, in order for Bright Cluster Manager to have an initial configuration. An example of how each node in Bright Cluster Manager can have its BIOS values defined is:

#### Example

```
[bright80->device]% foreach -n node002..node008 (dellsettings; importlive; commit; )
```

Similarly, a category can have BIOS settings defined by taking a single node with suitable settings, and running the `importlive` command with that node being used as the settings for that category.

#### Example

```
[bright80->category[default]]% dellsettings; importlive node009; commit
```

As usual with CMDaemon values, settings at the node level override settings at the category level. To clear settings at the node level for each node within a category default, the `clearsettings` command can be used:

#### Example

```
[bright80->device]% foreach -c default (dellsettings; clearsettings; commit; )
```

The `importlive` operation can only be performed from within `cmsh` at the time of writing (December 2017). The operation will also become available in Bright View updates in Bright Cluster Manager 8.0 later on.

### 16.3.2 Managing The BIOS Settings Via Bright View

The Dell BIOS settings can be accessed via Bright View, using settings within the node or within the category, using the clickpaths:

Devices→Nodes→Edit→Settings→Dell Settings

or:

Grouping→Node Categories→Settings→Dell Settings

If CMDaemon is able to communicate with the `racadm` utility the Dell Settings can then be configured (figure 16.1).

Some extra Dell-related fields can also be seen in the `SYS INFO COLLECTOR` subpane for a node, under the clickpath:

Devices→Nodes→Edit→Settings→System Overview

The motherboard manufacturer, name, and system manufacturer are among the values collected in this subpane.

### The Dell Settings Subwindow




Figure 16.1: Selection of a node node001, then opening the Dell Settings subwindow

The BIOS Settings subwindow gives access to some basic BIOS properties, including:

- (figure 16.1) boot order, whether to apply the configuration changes immediately or on the next boot, and serial communication settings
- (figure 16.2) a `devicefirmware` subwindow, where the BIOS firmware can be set.
- (figure 16.2) a `nics` subwindow, where the NIC properties can be viewed and set.
- (figure 16.3) performance and power profiles, processor frequency and memory refresh rates.




Figure 16.2: `devicefirmware` and `nics` subwindow access from the Dell Settings subwindow




Figure 16.3: Performance profiles, processor/memory BIOS settings in the Dell Settings subwindow

### The devicefirmware Subwindow




Figure 16.4: Dell settings firmware window

The `devicefirmware` subwindow (figure 16.4) allows a path to be set to the location on the head node where the firmware has been placed by the administrator. This path is then used when a firmware update is carried out with the `devicefirmware` subwindow for nodes or node categories.

HTTP, FTP, or TFTP access can also be specified using IPV4 addresses. These options assume that a firmware Catalog file exist at the HTTP, FTP or TFTP servers that host the firmware files. A firmware update is carried out with the `racdm update` command. The `racdm` software only updates particular kinds of firmware. The `racdm` documentation should be referred to for supported firmware file formats.

### Example

```
/cm/shared/firmwares/BIOS_YKH49_WN64_1.3.6.EXE
```

```
tftp://10.2.4.3
```

```
ftp://10.2.4.3
```

```
http://10.2.4.3
```

For FTP access, a username and password should be set.

### 16.3.3 Applying Dell Settings And Firmware Updates Via Bright View

To save modifications to the Dell settings, the usual way of saving the properties is followed. In this case it is the `Save` button in the window that opens up the `Dell Settings` subwindow, that is used to save the properties.

### 16.3.4 Managing The BIOS Settings Via `cmsh`

In `cmsh`, the Dell BIOS settings are available under the `dellsettings` submode. The `dellsettings` submode is available under a node or category object. If no Dell settings are yet configured, then a new local object is created automatically. The new object is saved using `commit`.

#### BIOS: Listing Properties

The Dell BIOS properties can be viewed with the `show` command run within the submode:

### Example

```
[bright80->category[default]->dellsettings]% show
```

Parameter	Value
Revision	
applyImmediately	no
biosBootOrder	
collaborativeCpuPerfCtrl	no
devicefirmware	<submode>
energyEfficientTurbo	no
energyPerformanceBias	MaxPower
failsafeBaudRate	115200
ioNonPostedPrefetch	yes
l3Cache	no
logicalProcessor	no
memFrequency	MaxPerf
memPatrolScrub	Standard
memRefreshRate	1x
mmioAbove4Gb	no
modelName	
monitorMWait	no
nics	<0 in submode>
nodeInterleaving	no
numberOfCores	
proc1TurboCoreNum	All
proc2TurboCoreNum	All
procC1E	no
procCStates	no
procPwrPerf	MaxPerf
procTurboMode	no

redirectionAfterBoot	no
remoteTerminal	Vt100Vt220
serialCommunication	Off
serialPort	Serial1Com1Serial2Com2
serviceTag	
snoopMode	HomeSnoop
sysprofile	Custom
turboBoost	no
uncoreFrequency	DynamicUFS

### BIOS: Setting Properties

Tab-completion suggestions for the `set` show the possible properties that can be modified.

#### Example

```
[bright80->category[default]->dellsettings]% set <TAB><TAB>
applyimmediately collaborativecpuperfctrl monitormwait ...
...
```

Tab-completion suggestions for a particular property, such as `monitormwait`, show the possible values that can be taken by a property with a selection of options. A property can then be set and committed:

#### Example

```
[bright80->category[default]->dellsettings]% set monitormwait <TAB><TAB>
no yes
[bright80->category[default]->dellsettings]% set monitormwait yes
[bright80->category*[default]*->dellsettings]% commit
```

### BIOS: Importing Properties With `importlive`

The `importlive` command imports the Dell settings for a category from an existing node configuration.

#### Example

```
[bright80->category*[default*]->dellsettings]% help importlive
importlive - Imports current live dell settings
Usage:
```

```
[-f] importlive node001
```

#### Options:

```
-f, --forcerefresh
    Force cmdaemon to refresh its cached live DellSettings copy, before importing
```

#### Examples:

```
importlive           Imports current live dell settings
```

```
[bright80->category*[default*]->dellsettings]% importlive node001
[bright80->category*[default*]->dellsettings]% commit
[bright80->category[default]->dellsettings]%
```

### Firmware Updates

Firmware update configurations can be listed and set within the `firmware` submode:

#### Example



```
[bright80->category*[default*]->dellsettings]% firmware
[bright80->category*[default*]->dellsettings->firmware]% show
Parameter          Value
-----
Readonly            no
Revision
clearConfig         no
ftpPassword
ftpUser
path
```

#### Applying Settings For Dell With `applydellsettings`

The `applydellsettings` command of `cmsh` is used to apply BIOS or firmware configuration changes to a node. The command is available from within `device` mode.

When `applydellsettings` is run, a background task is immediately automatically started to apply the settings. The progress can be monitored with the `task` submode, and the list of current background tasks can be viewed using the `task list` command.

#### Example

```
[bright80->device[node001]]% applydellsettings
[bright80->device[node001]]% task list
```

Details for each task can be shown with the `show` command, run from within the `task` submode.

#### Example

```
[bright80->task]% show 1
...
```

If applying a Dell settings task has failed, then the `Log` property of the task should show a detailed error message explaining why.

#### Example

```
[bright80->task]% show 1
...
Log:  ERROR: Unable to connect to RAC at specified IP address.
```

#### Viewing Live BIOS And Firmware Settings With `showlive`

The `showlive` command of `cmsh` displays the BIOS values currently used by the node. These are not necessarily the same as the currently configured values, because the currently configured values may not yet have been pushed to the node. The `showlive` command is available from within the `dellsettings` submode, which is under the `node` or `category` object. If live settings have not yet been fetched, then the operation can be forced with the `-f` option.

#### Example

```
[bright80->device[node001]->dellsettings]% showlive
[bright80->device[node001]->dellsettings]% showlive -f
Parameter          Value
-----
Readonly            no
Revision
applyImmediately    no
biosBootOrder        NIC.Embedded.1-1-1, NIC.Mezzanine.1A-1,...
collaborativeCpuPerfCtrl  no
```

```

devicefirmware          <submode>
energyEfficientTurbo     no
energyPerformanceBias    MaxPower
failsafeBaudRate         115200
l3Cache                  yes
logicalProcessor         no
memFrequency             MaxPerf
memPatrolScrub           Standard
memRefreshRate           1x
mmioAbove4Gb             no
modelName
monitorMWait            yes
nics                     <2 in submode>
nodeInterleaving         no
numberOfCores            All
proc1TurboCoreNum        All
proc2TurboCoreNum        All
procC1E                  no
procCStates              no
procPwrPerf              MaxPerf
procTurboMode            no
redirectionAfterBoot     yes
remoteTerminal           Vt100Vt220
serialCommunication      OnConRedirAuto
serialPort               Serial1Com2Serial2Com1
serviceTag
snoopMode                ClusterOnDie
sysprofile                PerfOptimized
turboBoost               no
uncoreFrequency          DynamicUFS
[bright80->device[node001]->dellsettings]%

```

## 16.4 Frequently Asked Questions

1. Where are the log files for the Apply and Firmware update operations?

All Apply actions are logged in `/var/log/cm-dell-manage.log` on the head node, and all Firmware update actions are logged to `/var/log/cm-dell-manage.log` on the node itself.

2. Why does the Bright View display of the BIOS setting display nothing?

This is likely because the required information is not fetched using `racadm` when the node booted for the first time. To force this operation at the time of request, the `showlive -f` command from `cmsh` should be used (page 575). It is generally a good idea to run that command if unsure about the status of current and planned BIOS settings for the next boot.

```
[bright80->device[node001]->dellsettings]% showlive -f
```

3. Why do the Bright View Dell settings for a node show no configured BIOS or NIC device settings?

This is because there are no Dell settings configured for a node. Settings can be initialized using `cmsh` with the `importlive` command. If there is no live information for the node yet, then the command `importlive -f` can be used:

### Example

```
[bright80->device[node001]->dellsettings]% importlive -f
```

4. Why do the `showlive -f` or `importlive -f` commands fail, saying that the BMC user privileges are insufficient in the reports in `/var/log/cm-dell-manage.log`?

This is because the default BMC user `bright` with user id 4 does not have sufficient privileges to perform this operation. The default BMC user, user ID, and password that the CMDaemon uses for performing this operation, should be changed to a BMC user that has iDRAC management privileges. This can be done from the `Settings` window of the node or category in Bright View:

Devices→Nodes→Edit→Settings→BMC settings

Grouping→Node Categories→Settings→BMC settings  
or from each node or base partition submode in `cmsh`.





# Generated Files

This appendix contains lists of all system configuration files which are generated automatically by the node-installer or CMDaemon. These are files generated on the head nodes (section A.1), in the software images (section A.2), and on the regular nodes (section A.3). These files should not be confused with configuration files that are merely installed (section A.4).

Section 2.6.4 describes how system configuration files on all nodes are written out using the Cluster Management Daemon. The Cluster Management Daemon is introduced in section 2.6.4 and its configuration directives are listed in Appendix C.

All of these configuration files may be listed as `Frozen Files` in the Cluster Management Daemon configuration file to prevent them from being generated automatically. The files can be frozen for the head node by setting the directive at `/cm/local/apps/cmd/etc/cmd.conf`. They can also be frozen on the regular nodes by setting the directive in the software image, by default at `/cm/images/default-image/cm/local/apps/cmd/etc/cmd.conf`.

## A.1 Files Generated Automatically On Head Nodes

Files generated or modified automatically on the head node by CMDaemon:

File	Method	Comment
/etc/aliases	Section	
/etc/dhclient.conf	Entire file	Red Hat only
/etc/dhcpd.conf	Entire file	
/etc/dhcpd.internalnet.conf	Entire file	For internal networks other than internalnet, corresponding files are generated if node booting (table 3.2.1) is enabled
/etc/exports	Section	
/etc/fstab	Section	
/etc/genders	Section	
/etc/haproxy/haproxy.cfg	Section	
/etc/hosts	Section	
/etc/hosts.equiv	Section	
/etc/localtime	Entire file	Copied from zoneinfo
/etc/named.conf	Entire file	For zone additions use /etc/named.conf.include <sup>1</sup> . For options additions, use /etc/named.conf.global.options.include
/etc/ntp.conf	Section	
/etc/ntp/step-tickers	Section	Red Hat only
/etc/openstack-dashboard/local_settings	Section	

...continues

...continued

File	Method	Comment
/etc/postfix/canonical	Section	
/etc/postfix/main.cf	Section	
/etc/postfix/generic	Section	
/etc/resolv.conf	Section	
/etc/shorewall/interfaces	Section	
/etc/shorewall/masq	Section	
/etc/shorewall/netmap	Section	
/etc/shorewall/policy	Section	
/etc/shorewall/zones	Section	
/etc/slurm/gres.conf	Section	
/etc/slurm/slurm.conf	Section	
/etc/slurm/slurmdbd.conf	Section	
/etc/slurm/topology.conf	Section	
/etc/sysconfig/bmccfg	Entire file	BMC configuration
/etc/sysconfig/clock	Section	
/etc/sysconfig/dhcpd	Entire file	
/etc/sysconfig/network	Section	Red Hat only
/etc/sysconfig/network/ routes	Section	SUSE only
/etc/sysconfig/network/ ifcfg-*	Section	SUSE only
/etc/sysconfig/network/dhcp	Section	SUSE only
/etc/sysconfig/ network-scripts/ifcfg-*	Section	Red Hat only
/etc/HOSTNAME	Entire file	SUSE only
/tftpboot/mtu.conf	Entire file	Bright Computing configuration
/var/named/*.zone <sup>1</sup>	Entire file	Red Hat only. For custom additions use /var/ named/*.zone.include
/var/lib/named/*.zone <sup>1</sup>	Entire file	SUSE only. For custom additions use /var/ lib/named/*.zone.include

<sup>1</sup> User-added zone files ending in \*.zone that are placed for a corresponding zone statement in the include file /etc/named.conf.include are wiped by CMDaemon activity. Another pattern, eg: \*.myzone, must therefore be used instead

## A.2 Files Generated Automatically In Software Images:

Files generated automatically in software images

File	Generated By	Method	Comment
/boot/vmlinuz	CMDaemon	Symlink	
/boot/initrd	CMDaemon	Symlink	
/boot/initrd-*	CMDaemon	Entire file	
/etc/aliases	CMDaemon	Section	
/etc/hosts	CMDaemon	Section	
/etc/init/serial.conf	CMDaemon	Section	only in Red Hat, not in RHEL7.x
/etc/inittab	CMDaemon	Section	SUSE only
/etc/localtime	CMDaemon	Entire file	
/etc/mkinitrd_cm.conf	CMDaemon	Section	Red Hat only
/etc/modprobe.d/bright-cmdaemon.conf	CMDaemon	Section	
/etc/postfix/main.cf	CMDaemon	Section	
/etc/securetty	CMDaemon	Section	
/etc/sysconfig/clock	CMDaemon	Section	
/etc/sysconfig/init	CMDaemon	Section	only in Red Hat, not in RHEL7.x
/etc/sysconfig/network/dhcp	CMDaemon	Section	SUSE only



## A.3 Files Generated Automatically On Regular Nodes

Files generated automatically on regular nodes

File	Generated By	Method	Comment
/etc/aliases	CMDaemon	Section	
/etc/exports	CMDaemon	Section	
/etc/fstab	Node-installer	Section	
/etc/hosts	Node-installer	Section	
/etc/init/serial.conf	CMDaemon	Section	Red Hat only, not in RHEL7.x
/etc/inittab	CMDaemon	Section	SUSE only
/etc/mkinitrd_cm.conf	CMDaemon	Section	Red Hat only
/etc/modprobe.d/bright-cmdaemon.conf	CMDaemon	Section	
/etc/pam.d/sshd	CMDaemon	Section	
/etc/ntp.conf	Node-installer	Entire file	
/etc/ntp/step-tickers	Node-installer	Entire file	Red Hat only
/etc/postfix/main.cf	Node-installer and CMDaemon	Section	
/etc/resolv.conf	Node-installer	Entire file	
/etc/securetty	CMDaemon	Section	
/etc/slurm/gres.conf	CMDaemon	Section	
/etc/slurm/slurm.conf	CMDaemon	Section	
/etc/sysconfig/clock	CMDaemon	Section	
/etc/sysconfig/init	CMDaemon	Section	Red Hat only, not in RHEL7.x
/etc/sysconfig/network	Node-installer	Entire file	
/etc/sysconfig/network/dhcp	CMDaemon	Section	SUSE only
/etc/sysconfig/network/ifcfg-*	Node-installer	Entire file	SUSE only, not ifcfg-lo
/etc/sysconfig/network-scripts/ifcfg-*	Node-installer	Entire file	Red Hat only, not ifcfg-lo
/etc/HOSTNAME	Node-installer	Entire file	

## A.4 Files Not Generated, But Installed.

This appendix (Appendix A) is mainly about generated configuration files. This section (A.4) of the appendix discusses a class of files that is not generated, but may still be confused with generated files. The discussion in this section clarifies the issue, and explains how to check if non-generated installed files differ from the standard distribution installation.

A design goal of Bright Cluster Manager is that of minimal interference. That is, to stay out of the way of the distributions that it works with as much as is reasonable. Still, there are inevitably cluster manager configuration files that are not generated, but installed from a cluster manager package. A cluster manager configuration file of this kind overwrites the distribution configuration file with its own special settings to get the cluster running, and the file is then not maintained by the node-installer or CMDaemon. Such files are therefore not listed on any of the tables in this chapter.

Sometimes the cluster file version may differ unexpectedly from the distribution version. To look into this, the following steps may be followed:

**Is the configuration file a Bright Cluster Manager version or a distribution version?** A convenient way to check if a particular file is a cluster file version is to grep for it in the packages list for the cluster packages. For example, for `nsswitch.conf`:

```
[root@bright80 ~]# repoquery -l $(repoquery -a | grep -F _cm8.0) | grep nsswitch.conf$
```

The inner `repoquery` displays a list of all the packages. By grepping for the cluster manager version string, for example `_cm8.0` for Bright Cluster Manager 8.0, the list of cluster manager packages is found. The outer `repoquery` displays the list of files within each package in the list of cluster manager packages. By grepping for `nsswitch.conf$`, any file paths ending in `nsswitch.conf` in the cluster manager packages are displayed. The output is:

```
/cm/conf/etc/nsswitch.conf
/cm/conf/etc/nsswitch.conf
/cm/node-installer/etc/nsswitch.conf
```

Files under `/cm/conf` are placed by Bright Cluster Manager packages when updating the head node. From there they are copied over during the post-install section of the RPM to where the distribution version configuration files are located by the cluster manager, but only during the initial installation of the cluster. The distribution version file is overwritten in this way to prevent RPM dependency conflicts of the Bright Cluster Manager version with the distribution version. The configuration files are not copied over from `/cm/conf` during subsequent reboots after the initial installation. The `cm/conf` files are however updated when the Bright Cluster Manager packages are updated. During such a Bright Cluster Manager update, a notification is displayed that new configuration files are available.

Inverting the cluster manager version string match displays the files not provided by Bright Cluster Manager. These are normally the files provided by the distribution:

```
[root@bright80 ~]# repoquery -l $(repoquery -a | grep -F -v _cm8.0) | grep nsswitch.conf$
/etc/nsswitch.conf
/etc/nsswitch.conf
/usr/share/doc/yp-tools-2.9/nsswitch.conf
```

**Which package provides the file in Bright Cluster Manager and in the distribution?** The packages that provide these files can be found by running the “`yum whatprovides *`” command on the paths given by the preceding output, for example:

```
~# yum whatprovides */cm/conf/etc/nsswitch.conf
```

This reveals that some Bright Cluster Manager LDAP packages can provide an `nsswitch.conf` file. The file is a plain file provided by the unpacking and placement that takes place when the package is installed. The file is not generated or maintained periodically after placement, which is the reason why this file is not seen in the tables of sections A.1, A.2, and A.3 of this appendix.

Similarly, looking through the output for

```
~# yum whatprovides */etc/nsswitch.conf
```

shows that `glibc` provides the distribution version of the `nsswitch.conf` file, and that there is also a `node-installer` version of this file available from the Bright Cluster Manager packages.

**What are the differences between the Bright Cluster Manager version and the distribution versions of the file?** Sometimes it is helpful to compare a distribution version and cluster version of `nsswitch.conf` to show the differences in configuration. The versions of the RPM packages containing the `nsswitch.conf` can be downloaded, their contents extracted, and their differences compared as follows:

```
~# mkdir yumextracted ; cd yumextracted
~# yumdownloader glibc-2.12-1.107.el6.x86_64.rpm
~# rpm2cpio glibc-2.12-1.107.el6.x86_64.rpm | cpio -idmv
~# yumdownloader cm-config-ldap-client-6.0-45_cm8.0.noarch.rpm
~# rpm2cpio cm-config-ldap-client-6.0-45_cm8.0.noarch.rpm | cpio -idmv
~# diff etc/nsswitch.conf cm/conf/etc/nsswitch.conf
...
```

**What are the configuration files in an RPM package?** An RPM package allows files within it to be marked as configuration files. Files marked as configuration files can be listed with `rpm -qc <package>`. Optionally, piping the list through “`sort -u`” filters out duplicates.

### Example

```
~# rpm -qc glibc | sort -u
/etc/ld.so.cache
/etc/ld.so.conf
/etc/localtime
/etc/nsswitch.conf
/usr/lib64/gconv/gconv-modules
/var/cache/ldconfig/aux-cache
```

**How does an RPM installation deal with local configuration changes? Are there configuration files or critical files that Bright Cluster Manager misses?** Whenever an RPM installation detects a file with local changes, it can treat the local system file as if:

1. the local system file is frozen<sup>1</sup>. The installation does not interfere with the local file, but places the updated file as an `.rpmnew` file in the same directory.
2. the local system file is not frozen. The installation changes the local file. It copies the local file to an `.rpmsave` file in the same directory, and installs a new file from the RPM package.

When building the Bright Cluster Manager packages, the package builders can specify which of these two methods apply. When dealing with the built package, the system administrator can use an `rpm query` method to determine which of the two methods applies for a particular file in the package. For example, for `glibc`, the following query can be used and grepped:

```
rpm -q --queryformat '%{FILENAMES}\t%{FILEFLAGS:fflags}\n' glibc | egr\
ep '[:space:]].*(c|n).*$' | sort -u
/etc/ld.so.cache cmng
/etc/ld.so.conf cn
/etc/localtime cn
/etc/nsswitch.conf cn
/usr/lib64/gconv/gconv-modules cn
/usr/lib/gconv/gconv-modules cn
/var/cache/ldconfig/aux-cache cmng
```

<sup>1</sup>This freezing should not be confused with the `FrozenFile` directive (Appendix C), where the file or section of a file is being maintained by `CMDaemon`, and where freezing the file prevents `CMDaemon` from maintaining it.

Here, the second column of the output displayed shows which of the files in the package have a configuration (c) flag or a noreplace (n) flag. The c flag without the n flag indicates that an .rpmsave file will be created, while a c flag together with an n flag indicates that an .rpmnew file will be created.

In any case, files that are not marked as configuration files are overwritten during installation.

So:

- If a file is not marked as a configuration file, and it has been customized by the system administrator, and this file is provided by an RPM package, and the RPM package is updated on the system, then the file is overwritten silently.
- If a file is marked as a configuration file, and it has been customized by the system administrator, and this file is provided by an RPM package, and the RPM package is updated on the system, then it is good practice to look for .rpmsave and .rpmnew versions of that file, and run a comparison on detection.

Bright Cluster Manager should however mark all critical files as configuration files in the Bright Cluster Manager packages.

Sometimes, RPM updates can overwrite a particular file that the administrator has changed locally and then would like to keep frozen.

To confirm that this is the problem, the following should be checked:

- The `--queryformat` option should be used to check that file can indeed be overwritten by updates. If the file has an n flag (regardless of whether it is a configuration file or not) then overwriting due to RPM updates does not happen, and the local file remains frozen. If the file has no n flag, then replacement occurs during RPM updates.

For files with no n flag, but where the administrator would still like to freeze the file during updates, the following can be considered:

- The file text content should be checked to see if it is a CMDaemon-maintained file (section 2.6.4), or checked against the list of generated files (Appendix A). This is just to make sure to avoid confusion about how changes are occurring in such a file.
  - If it is a CMDaemon-maintained file, then configuration changes put in by the administrator will also not persist in the maintained section of the file unless the `FrozenFile` directive (section C) is used to freeze the change.
  - If it is only a section that CMDaemon maintains, then configuration changes can be placed outside of the maintained section.

Wherever the changes are placed in such a file, these changes are in any case by default overwritten on RPM updates if the file has no n flag.

- Some regular node updates can effectively be maintained in a desired state with the help of a finalize script (Appendix E).
- Updates can be excluded from YUM/zypper (section 11.3.2), thereby avoiding the overwriting of that file by the excluded package.

A request to change the package build flag may be sent to Bright Computing if the preceding suggested options are unworkable.

B

# Bright Computing Public Key


-----BEGIN PGP PUBLIC KEY BLOCK-----

Version: GnuPG v1.4.0 (GNU/Linux)

mQGibEqtYegRBADStdQjnlXxbYorXbFGncF2IcMFiNA7hamART4w7hjtWZoKGHbC  
zSLsQTmgZO+FZs+tXcZa50LjGwhpxT6qhCe8Y7zIh2vwKrKlaAVKj2PUU28vKj1p  
2W/OIiG/HKLTahLiCk0L3ahP0evJHh8B7elC1rZOTKTBB6qIUbC5vHtjiwCgydm3  
THLJsKnwk4qZetluTupldOEANcZJ1nZxZzN6ZAMkIBrct8GivWC1T1nBG4UwjHd  
EDcGlREJxpg/OhpEP8TY1e0YUKRWvMqSVChPzkLUTIIsd/O4RGTw0PGCo6Q3TLXpM  
RVoonyPR1tRymPNZyW8VJeTUE0kdlCqZykp1sRb3jFAiJIRCMBrC854i/jRXmo  
foTPBACJQyoEH9Qfe3VcqR6+vR2tX91PvkxS7A5AnJIRs3Sv6yM4oV+7k/HrfYKt  
fyl6widteBq1870s4x3NYXmmne7lzlGxBfAxzPG9rtjRSXyVxc+KGVd6gKeCV6d  
o7kS/LJHRI0Lb5G4NZRFy5CGqg64liJwp/f2J4uyRbC8b+/LQbQ7QnJpZ2h0IENv  
bXB1dGluZyBEZXZlbG9wbWVudCBUZWFtIDxkZXZAYnJpZ2h0Y29tcHV0aW5nLmNv  
bT6IXgQTEQIAHgUCSqlih6AlbAwYLCQgHAwIDFQIDAxYCAQIeAQIXgAAKCRDvaS9m  
+k3m0JO0AKC0GLTZiqoCQ6TRWW2ijjITEQ8CXACgg3o4oVbrG67VFzHUntcA0YTE  
DXW5Ag0ESqlih6xAlAMJiaZI/0EqnrhSfiMsMT3sxz3mZkrQQ82Fob7s+S7nnMl8  
A8btPzLlK8NzZytCglrIwPCYG6vfza/nkvYKEPh/f2it941bh7qiu4rBLqr+kGx3  
zepSMRqIzW5FpIrUgDZOL9J+tWSSUtPW0YQ5jBBJrgJ8LQy9dK2RhAOLuHfbOSVB  
JLIwNKxafkhMRwDoUNS4BiZKWYPFu47vd8fm67IPT1nMl0iCOR/QBn29MYuWnBcw  
61344pd/IjOu3gM6YBqmRRU6yBeVi0TxxbYYnWcts6tEGAlTjHUOQ7gxVp4RDia2  
jLVtbee8H464wxkkC3SSkng216RaBBaOaAykhzcAAwUH/iG4WsJHFW3+CRhUqy51  
jnmb1FTFO8KQXI8JlPXM0h6vv0PtP5rw5D5V2cyVe2i4ez9Y8XMVfcbf601ptKyY  
bRUjQq+9SNjt12ESU67YyLstSN68ach9Af03PoSZIKkiNwfa0+VBILv2Mhn7xd74  
5L0M/eJ7lHSpeJA2Rzs6szc234Ob/VxGfGWjogaK3NElSYOzQo+/k0VMdMWsQm/8  
Ras19IA9P5j1SbcZQlH1PjndS4x4XQ8P41ATczsIDyWhsJC51rTuw9/QO7fqvvPn  
xsRz1pFmiiN7I4JLjw0nAlXexn4EaeVa7Eb+uTjvxJZNdShs7Td74OmlF7RKFccI  
wLuISQQYEQIACQUCSqlih6wIbDAAKCRDvaS9m+k3m0C/oAJshMMKrLPhjCdZyHbBl  
e19+5JABUwCfU0PoawBN0HzDnfr3MLaTgCwjsEE=  
=WJX7

-----END PGP PUBLIC KEY BLOCK-----





# CMDaemon Configuration File Directives

This appendix lists all configuration file directives that may be used in the cluster management daemon configuration file. If a change is needed, then the directives are normally changed on the head node, or on both head nodes in the high availability configuration, in:

`/cm/local/apps/cmd/etc/cmd.conf`

The directives can also be set in some cases for the regular nodes, via the software image in `/cm/images/default-image/cm/local/apps/cmd/etc/cmd.conf` on the head node. Changing the defaults already there is however not usually needed, and is not recommended.

Only one directive is valid per `cmd.conf` file.

To activate changes in a `cmd.conf` configuration file, the `cmd` service associated with it must be restarted.

- For the head node this is normally done with the command:

```
service cmd restart
```

- For regular nodes, `cmd` running on the nodes is restarted. Often, the image should be updated before `cmd` is restarted. How to carry out these procedures for a directive is described with an example where the `FrozenFile` directive is activated on a regular node on page 597.

## Master directive

**Syntax:** `Master = hostname`

**Default:** `Master = master`

The cluster management daemon treats the host specified in the `Master` directive as the head node. A cluster management daemon running on a node specified as the head node starts in *head* mode. On a regular node, it starts in *node* mode.

## Port directive

**Syntax:** `Port = number`

**Default:** `Port = 8080`

The *number* used in the syntax above is a number between 0 and 65535. The default value is 8080.

The `Port` directive sets the value of the port of the cluster management daemon to listen for non-SSL HTTP calls. By default, this happens only during init. All other communication with the cluster management daemon is carried out over the SSL port. Pre-init port adjustment can be carried out in the `node-installer.conf` configuration.

## SSLPort directive

**Syntax:** `SSLPort = number`

**Default:** `SSLPort = 8081`

The *number* used in the syntax above is a number between 0 and 65535. The default value is 8081.

The `SSLPort` directive sets the value of the SSL port of the cluster management daemon to listen for SSL HTTP calls. By default, it is used for all communication of CMDaemon with Bright View and `cmsh`, except for when CMDaemon is started up from `init`.

## SSLPortOnly directive

**Syntax:** `SSLPortOnly = yes|no`

**Default:** `SSLPortOnly = no`

The `SSLPortOnly` directive allows the non-SSL port to be disabled. During normal running, both SSL and non-SSL ports are listening, but only the SSL port is used. By default, the non-SSL port is only used during CMDaemon start up.

If `PXEBootOverHTTP` (page 608) is set to 1, then `SSLPortOnly` must be set to `no`.

## CertificateFile directive

**Syntax:** `CertificateFile = filename`

**Default:** `CertificateFile = "/cm/local/apps/cmd/etc/cert.pem"`

The `CertificateFile` directive specifies the PEM-format certificate which is to be used for authentication purposes. On the head node, the certificate used also serves as a software license.

## PrivateKeyFile directive

**Syntax:** `PrivateKeyFile = filename`

**Default:** `PrivateKeyFile = "/cm/local/apps/cmd/etc/cert.key"`

The `PrivateKeyFile` directive specifies the PEM-format private key which corresponds to the certificate that is being used.

## CACertificateFile directive

**Syntax:** `CACertificateFile = filename`

**Default:** `CACertificateFile = "/cm/local/apps/cmd/etc/cacert.pem"`

The `CACertificateFile` directive specifies the path to the Bright Cluster Manager PEM-format root certificate. It is normally not necessary to change the root certificate.

## RandomSeedFile directive

**Syntax:** `RandomSeedFile = filename`

**Default:** `RandomSeedFile = "/dev/urandom"`

The `RandomSeedFile` directive specifies the path to a source of randomness.

## DHParamFile directive

**Syntax:** `DHParamFile = filename`



**Default:** `DHParamFile = "/cm/local/apps/cmd/etc/dh1024.pem"`

The `DHParamFile` directive specifies the path to the Diffie-Hellman parameters.

## SSLHandshakeTimeout directive

**Syntax:** `SSLHandshakeTimeout = number`

**Default:** `SSLHandshakeTimeout = 10`

The `SSLHandShakeTimeout` directive controls the time-out period (in seconds) for SSL handshakes.

## SSLSessionCacheExpirationTime directive

**Syntax:** `SSLSessionCacheExpirationTime = number`

**Default:** `SSLSessionCacheExpirationTime = 300`

The `SSLSessionCacheExpirationTime` directive controls the period (in seconds) for which SSL sessions are cached. Specifying the value 0 can be used to disable SSL session caching.

## DBHost directive

**Syntax:** `DBHost = hostname`

**Default:** `DBHost = "localhost"`

The `DBHost` directive specifies the hostname of the MySQL database server.

## DBPort directive

**Syntax:** `DBPort = number`

**Default:** `DBPort = 3306`

The `DBPort` directive specifies the TCP port of the MySQL database server.

## DBUser directive

**Syntax:** `DBUser = username`

**Default:** `DBUser = cmdaemon`

The `DBUser` directive specifies the username used to connect to the MySQL database server.

## DBPass directive

**Syntax:** `DBPass = password`

**Default:** `DBPass = "<random string set during installation>"`

The `DBPass` directive specifies the password used to connect to the MySQL database server.

## DBName directive

**Syntax:** `DBName = database`

**Default:** `DBName = "cmdaemon"`

The `DBName` directive specifies the database used on the MySQL database server to store CMDaemon related configuration and status information.

### DBUnixSocket directive

**Syntax:** `DBUnixSocket = filename`

**Default:** `DBUnixSocket = "/var/lib/mysql/mysql.sock"`

The `DBUnixSocket` directive specifies the named pipe used to connect to the MySQL database server if it is running on the same machine.

### DBUpdateFile directive

**Syntax:** `DBUpdateFile = filename`

**Default:** `DBUpdateFile = "/cm/local/apps/cmd/etc/cmdaemon_upgrade.sql"`

The `DBUpdateFile` directive specifies the path to the file that contains information on how to upgrade the database from one revision to another.

### EventBucket directive

**Syntax:** `EventBucket = filename`

**Default:** `EventBucket = "/var/spool/cmd/eventbucket"`

The `EventBucket` directive (section 12.9.3) specifies the path to the named pipe that is created to listen for incoming events from a user.

### EventBucketFilter directive

**Syntax:** `EventBucketFilter = filename`

**Default:** `EventBucketFilter = "/cm/local/apps/cmd/etc/eventbucket.filter"`

The `EventBucketFilter` directive (section 12.9.3) specifies the path to the file that contains regular expressions used to filter out incoming messages on the event-bucket.

### LDAPHost directive

**Syntax:** `LDAPHost = hostname`

**Default:** `LDAPHost = "localhost"`

The `LDAPHost` directive specifies the hostname of the LDAP server to connect to for user management.

### LDAPUser directive

**Syntax:** `LDAPUser = username`

**Default:** `LDAPUser = "root"`

The `LDAPUser` directive specifies the username used when connecting to the LDAP server.

### LDAPPass directive

**Syntax:** `LDAPPass = password`

**Default:** `LDAPPass = "<random string set during installation>"`

The `LDAPPass` directive specifies the password used when connecting to the LDAP server. It can be changed following the procedure described in Appendix I.

### LDAPReadOnlyUser directive

**Syntax:** `LDAPReadOnlyUser = username`

**Default:** `LDAPReadOnlyUser = "readonlyroot"`

The `LDAPReadOnlyUser` directive specifies the username that will be used when connecting to the LDAP server during LDAP replication. The user is a member of the "rogroup" group, whose members have a read-only access to the whole LDAP directory.

### LDAPReadOnlyPass directive

**Syntax:** `LDAPReadOnlyPass = password`

**Default:** `LDAPReadOnlyPass = "<random string set during installation>"`

The `LDAPReadOnlyPass` directive specifies the password that will be used when connecting to the LDAP server during LDAP replication.

### LDAPSearchDN directive

**Syntax:** `LDAPSearchDN = dn`

**Default:** `LDAPSearchDN = "dc=cm,dc=cluster"`

The `LDAPSearchDN` directive specifies the Distinguished Name (DN) used when querying the LDAP server.

### HomeRoot directive

**Syntax:** `HomeRoot = path`

**Default:** `HomeRoot = "/home"`

The `HomeRoot` directive specifies the default user home directory used by `CMDaemon`. It is used for automatic mounts, exports, and when creating new users.

### DocumentRoot directive

**Syntax:** `DocumentRoot = path`

**Default:** `DocumentRoot = "/cm/local/apps/cmd/etc/htdocs"`

The `DocumentRoot` directive specifies the directory mapped to the web-root of the `CMDaemon`. The `CMDaemon` acts as a HTTP-server, and can therefore in principle also be accessed by web-browsers.

### SpoolDir directive

**Syntax:** `SpoolDir = path`

**Default:** `SpoolDir = "/var/spool/cmd"`

The `SpoolDir` directive specifies the directory which is used by the `CMDaemon` to store temporary and semi-temporary files.

## EnableJSON directive

**Syntax:** EnableJSON = true|false

**Default:** EnableJSON = true

The EnableJSON directive allows Bright View. If the administrator or other user create other JSON-dependent utilities, these require the directive to be true too.

## CMDaemonAudit directive

**Syntax:** CMDaemonAudit = yes|no

**Default:** CMDaemonAudit = no

When the CMDaemonAudit directive is set to yes, and a value is set for the CMDaemon auditor file with the CMDaemonAuditorFile directive, then CMDaemon actions are time-stamped and logged in the CMDaemon auditor file.

## CMDaemonAuditorFile directive

**Syntax:** CMDaemonAuditorFile = *filename*

**Default:** CMDaemonAuditorFile = "/var/spool/cmd/audit.log"

The CMDaemonAuditorFile directive sets where the audit logs for CMDaemon actions are logged. The log format is:

*(time stamp) profile [IP-address] action (unique key)*

### Example

```
(Mon Jan 31 12:41:37 2011) Administrator [127.0.0.1] added Profile: arbitprof(4294967301)
```

## DisableAuditorForProfiles directive

**Syntax:** DisableAuditorForProfiles = { *profile* [,*profile*] ... }

**Default:** DisableAuditorForProfiles = {node}

The DisableAuditorForProfiles directive sets the profile for which an audit log for CMDaemon actions is disabled. A profile (section 2.3.4) defines the services that CMDaemon provides for that profile user. More than one profile can be set as a comma-separated list. Out of the profiles that are available on a newly-installed system: node, admin, cmhealth, and readonly; only the profile node is enabled by default. New profiles can also be created via the profile mode of cmsh or via the clickpath Identity Management→Profiles→ of Bright View, thus making it possible to disable auditing for arbitrary groups of CMDaemon services.

## EventLogger directive

**Syntax:** EventLogger = true|false

**Default:** EventLogger = false

The EventLogger directive sets whether to log events. If active, then by default it logs events to /var/spool/cmd/events.log on the active head. If a failover takes place, then the event logs on both heads should be checked and merged for a complete list of events.

The location of the event log on the filesystem can be changed using the EventLoggerFile directive (page 595).

Whether events are logged in files or not, events are cached and accessible using `cmsh`. The number of events cached by `CMDaemon` is determined by the parameter `MaxEventHistory` (page 595).

## EventLoggerFile directive

**Syntax:** `EventLoggerFile = filename`

**Default:** `EventLogger = "/var/spool/cmd/events.log"`

The `EventLogger` directive sets where the events seen in the event viewer (section 12.9.1) are logged.

## MaxEventHistory directive

**Syntax:** `AdvancedConfig = {"MaxEventHistory=number", ...}`

**Default:** `MaxEventHistory=8192`

`MaxEventHistory` is a parameter of the `AdvancedConfig` (page 602) directive.

By default, when not explicitly set, the maximum number of events that is retained by `CMDaemon` is 8192. Older events are discarded.

The parameter can take a value from 0 to 1000000. However, `CMDaemon` is less responsive with larger values, so in that case, setting the `EventLogger` directive (page 594) to true, to activate logging to a file, is advised instead.

## PublicDNS directive

**Syntax:** `PublicDNS = true|false`

**Default:** `PublicDNS = false`

By default, internal hosts are resolved only if requests are from the internal network. Setting `PublicDNS` to true allows the head node name server to resolve internal network hosts for any network, including networks that are on other interfaces on the head node. Separate from this directive, port 53/UDP must also be opened up in Shorewall (section 7.2 of the *Installation Manual*) if DNS is to be provided for queries from an external network.

## LockDownDhcpd directive

**Syntax:** `LockDownDhcpd = true|false`

**Default:** `LockDownDhcpd = false`

`LockDownDhcpd` is a deprecated legacy directive. If set to true, a global DHCP “deny unknown-clients” option is set. This means no new DHCP leases are granted to unknown clients for all networks. Unknown clients are nodes for which Bright Cluster Manager has no MAC addresses associated with the node. The directive `LockDownDhcpd` is deprecated because its globality affects clients on all networks managed by Bright Cluster Manager, which is contrary to the general principle of segregating the network activity of networks.

The recommended way now to deny letting new nodes boot up is to set the option for specific networks by using `cmsh` or Bright View (section 3.2.1, figure 3.5, table 3.2.1). Setting the `cmd.conf` `LockDownDhcpd` directive overrides `lockdowndhcpd` values set by `cmsh` or Bright View.

## MaxNumberOfProvisioningThreads directive

**Syntax:** `MaxNumberOfProvisioningThreads = number`

**Default:** `MaxNumberOfProvisioningThreads = 10000`

The `MaxNumberOfProvisioningThreads` directive specifies the cluster-wide total number of nodes that can be provisioned simultaneously. Individual provisioning servers typically define a much lower bound on the number of nodes that may be provisioned simultaneously.

## SetupBMC directive

**Syntax:** `SetupBMC = true|false`

**Default:** `SetupBMC = true`

Configure the username and password for the BMC interface of the head node and regular nodes automatically. (This should not be confused with the `setupBmc` field of the node-installer configuration file, described in section 5.8.7.)

## BMCSessionTimeout directive

**Syntax:** `BMCSessionTimeout = number`

**Default:** `BMCSessionTimeout = 2000`

The `BMCSessionTimeout` specifies the time-out for BMC calls in milliseconds.

## SnmpSessionTimeout directive

**Syntax:** `SnmpSessionTimeout = number`

**Default:** `SnmpSessionTimeout = 500000`

The `SnmpSessionTimeout` specifies the time-out for SNMP calls in microseconds.

## PowerOffPDUOutlet directive

**Syntax:** `PowerOffPDUOutlet = true|false`

**Default:** `PowerOffPDUOutlet = false`

Enabling the `PowerOffPDUOutlet` directive allows PDU ports to be powered off for clusters that have both PDU and IPMI power control. Section 4.1.3 has more on this.

## DisableBootLogo directive

**Syntax:** `DisableBootLogo = true|false`

**Default:** `DisableBootLogo = false`

When `DisableBootLogo` is set to `true`, the Bright Cluster Manager logo is not displayed on the first boot menu when nodes PXE boot.

## StoreBIOSTimeInUTC directive

**Syntax:** `StoreBIOSTimeInUTC = true|false`

**Default:** `StoreBIOSTimeInUTC = false`

When `StoreBIOSTimeInUTC` is set to `true`, the system relies on the time being stored in BIOS as being UTC rather than local time.

## FreezeChangesTo<wlm>Config directives: FreezeChangesToCondorConfig directive

**FreezeChangesToPBSPro directive****FreezeChangesToSGEConfig directive****FreezeChangesToUGEConfig directive****FreezeChangesToSlurmConfig directive****FreezeChangesToTorqueConfig directive****FreezeChangesToOpenLavaConfig directive****FreezeChangesToLSFConfig directive****Syntax:** FreezeChangesTo<*wlm*>Config= true|false**Default:** FreezeChangesTo<*wlm*>Config = false

When FreezeChangesTo<*wlm*>Config is set to true, CMDaemon does not make any modifications to the workload manager configuration. Workload managers for which this value can be set are:

- Condor
- PBSPro
- SGE
- UGE
- Slurm
- Torque
- OpenLava
- LSF

**FrozenFile directive****Syntax:** FrozenFile = { *filename*[, *filename*]... }**Example:** FrozenFile = { "/etc/dhcpd.conf", "/etc/postfix/main.cf" }

The FrozenFile directive is used to prevent the CMDaemon-maintained sections of configuration files from being automatically generated. This is useful when site-specific modifications to configuration files have to be made.

To avoid problems, the file that is frozen should not be a symlink, but should be the ultimate destination file. The `readlink -f <symlinkname>` command returns the ultimate destination file of a symlink called <symlinkname>. This is also the case for an ultimate destination file that is reached via several chained symlinks.

**FrozenFile directive for regular nodes****FrozenFile directive for regular nodes for CMDaemon**

The FrozenFile directive can be used within the `cmd.conf` file of the regular node.

**Example**

To freeze the file `/etc/named.conf` on the regular nodes running with the image `default-image`, the file:

```
/cm/images/default-image/cm/local/apps/cmd/etc/cmd.conf
```

can have the following directive set in it:

```
FrozenFile = { "/etc/named.conf" }
```

The path of the file that is to be frozen on the regular node must be specified relative to the root of the regular node.

The running node should then have its image updated. This can be done with the `imageupdate` command in `cmsh` (section 5.6.2), or the `Update` node button in Bright View (section 5.6.3). After the update, CMDaemon should be restarted within that category of nodes:

### Example

```
[root@bright80 ~]# pdsh -v -g category=default service cmd restart
node002: Waiting for CMDaemon (25129) to terminate...
node001: Waiting for CMDaemon (19645) to terminate...
node002: [ OK ]
node001: [ OK ]
node002: Waiting for CMDaemon to start...[ OK ]
node001: Waiting for CMDaemon to start...[ OK ]
```

### FrozenFile directive for regular nodes for the node-installer

CMDaemon directives only affect files on a regular node after CMDaemon starts up on the node during the init stage. So files frozen by the CMDaemon directive stay unchanged by CMDaemon after this stage, but they may still be changed before this stage.

Freezing files so that they also stay unchanged during the pre-init stage—that is during the node-installer stage—is possible with node-installer directives.

Node-installer freezing is independent of CMDaemon freezing, which means that if a file freeze is needed for the entire startup process as well as beyond, then both a node-installer as well as a CMDaemon freeze are sometimes needed.

Node-installer freezes can be done with the node-installer directives in `/cm/node-installer/scripts/node-installer.conf`, introduced in section 5.4:

- `frozenFilesPerNode`
- `frozenFilesPerCategory`

### Example

Per node:

```
frozenFilesPerNode = "*/localdisk/etc/ntp.conf", "node003:/localdisk/etc/hosts"
```

Here, the `*` wildcard means that no restriction is set. Setting `node003` means that only node003 is frozen.

### Example

Per category:

```
frozenFilesPerCategory = "mycategory:/localdisk/etc/sysconfig/network-scripts/ifcfg-eth1"
```

Here, the nodes in the category `mycategory` are prevented from being changed by the node-installer.



### The Necessity Of A `FrozenFile` Directive

In a configuration file after a node is fully up, the effect of a statement earlier on can often be overridden by a statement later in the file. So, the following useful behavior is independent of whether `FrozenFile` is being used for a configuration file or not: A configuration file, for example `/etc/postfix/main.cf`, with a configuration statement in an earlier `CMDaemon`-maintained part of the file, for example:

```
mydomain = eth.cluster
```

can often be overridden by a statement later on outside the `CMDaemon`-maintained part of the file:

```
mydomain = eth.gig.cluster
```

Using `FrozenFile` in `CMDaemon` or the node-installer can thus sometimes be avoided by the use of such overriding statements later on.

Whether overriding later on is possible depends on the software being configured. It is true for postfix configuration files, for example, but it may not be so for the configuration files of other applications.

### EaseNetworkValidation directive

**Syntax:** `EaseNetworkValidation = 0|1|2`

**Default:** `EaseNetworkValidation = 0`

`CMDaemon` enforces certain requirements on network interfaces and management/node-booting networks by default. In heavily customized setups, such as is common in Type 3 networks (section 3.3.6 of the *Installation Manual*), the user may wish to disable these requirements.

- 0 enforces all requirements.
- 1 allows violation of the requirements, with validation warnings. This value should never be set except under instructions from Bright support.
- 2 allows violation of the requirements, without validation warnings. This value should never be set except under instructions from Bright support.

### CustomUpdateConfigFileScript directive

**Syntax:** `CustomUpdateConfigFileScript = filename`

**Default:** *commented out in the default `cmd.conf` file*

Whenever one or more entities have changed, the custom script at *filename*, specified by a full path, is called 30s later. Python bindings can be used to get information on the current setup.

### ConfigDumpPath directive

**Syntax:** `ConfigDumpPath = filename`

**Default:** `ConfigDumpPath = /var/spool/cmd/cmdaemon.config.dump`

The `ConfigDumpPath` directive sets a dump file for dumping the configuration used by the power control script `/cm/local/apps/cmd/scripts/pctl/pctl`. The `pctl` script is a fallback script to allow power operations if `CMDaemon` is not running.

- If no directive is set (`ConfigDumpPath = ""`), then no dump is done.
- If a directive is set, then the administrator must match the variable `cmdconfigfile` in the powercontrol configuration file `/cm/local/apps/cmd/scripts/pctl/config.py` to the value of `ConfigDumpPath`. By default, the value of `cmdconfigfile` is set to `/var/spool/cmd/cmdaemon.config.dump`.

## SyslogHost directive

**Syntax:** SyslogHost = *hostname*

**Default:** SyslogHost = "localhost"

The SyslogHost directive specifies the hostname of the syslog host.

## SyslogFacility directive

**Syntax:** SyslogFacility = *facility*

**Default:** SyslogFacility = "LOG\_LOCAL6"

The default value of LOG\_LOCAL6 is set in:

- /etc/syslog.conf in Red Hat 5 and variants
- /etc/rsyslog.conf in Red Hat 6 and variants
- /etc/syslog-ng/syslog-ng.conf in SLES versions

These are the configuration files for the default syslog daemons `syslog`, `rsyslog`, and `syslog-ng`, respectively, that come with the distribution. Bright Cluster Manager redirects messages from CMDaemon to `/var/log/cmdaemon` only for the default syslog daemon that the distribution provides. So, if another syslog daemon other than the default is used, then the administrator has to configure the non-default syslog daemon facilities manually.

The value of *facility* must be one of: LOG\_KERN, LOG\_USER, LOG\_MAIL, LOG\_DAEMON, LOG\_AUTH, LOG\_SYSLOG or LOG\_LOCAL0..7

## ResolveToExternalName directive

**Syntax:** ResolveToExternalName = true|false

**Default:** ResolveToExternalName = false

The value of the ResolveToExternalName directive determines under which domain name the primary and secondary head node hostnames are visible from within the head nodes, and to which IP addresses their hostnames are resolved. Enabling this directive resolves the head nodes' hostnames to the IP addresses of their external interfaces.

- On head nodes and regular nodes in both single-head and failover clusters with ResolveToExternalName disabled, the master hostname and the actual hostname of the head node (e.g. head1, head2) by default always resolve to the internal IP address of the head node.
- The ResolveToExternalName directive has no effect on the regular nodes unless they query the DNS on the head node, bypassing the `/etc/hosts` file. What this means is that with ResolveToExternalName enabled or disabled, the regular nodes resolve the hostname of any head node to an IP address located on the internal cluster network by default when resolved using the `/etc/hosts` file, for example using standard `ping` with the default node name resolution settings sequence. The regular nodes however resolve according to the DNS server's configuration if querying the DNS server querying directly.

The following points describe more exhaustively how this directive influences the resolution of hostnames to IP addresses for head and regular nodes in the cluster:

- On the head node of a single-head cluster, if ResolveToExternalName is enabled, the master hostname and the actual hostname of the head node, e.g. head, then both resolve to the external IP address of the head node.

- On head nodes of a failover cluster, if `ResolveToExternalName` is enabled, the actual head hostnames, e.g. `head1` and `head2`, then also both resolve to their external IP address. However, the `master` hostname stays resolved to the internal shared IP address. This is because Bright Cluster Manager uses `master` within its code base, and there is no need to have the failover configuration have a shared external IP address in the code base.
- On regular nodes in a single-head cluster, if `ResolveToExternalName` is enabled, then the `master` hostname or the actual hostname of the head node (e.g. `head`) both stay resolved to the internal IP address of the head node when using `/etc/hosts`. However they resolve to the external IP address of the head node when the DNS service is used.
- On regular nodes in a failover cluster, if `ResolveToExternalName` is enabled, the `master` hostname then still resolves to the shared internal IP. The actual hostnames of the head nodes, e.g. `head1` and `head2`, also still resolve to the internal IP address of the respective head nodes if resolved via `/etc/hosts`. However, they resolve to the external IP addresses of the respective head nodes if resolved by querying the DNS.

The behavior discussed in the preceding points can be summarized by Table C:

Table C: `ResolveToExternalName` Directive Effects

on simple head, resolving:		on failover head, resolving:			on regular node, resolving:		Using the DNS?
master	head	master	head1	head2	master	head(s)	
<b>ResolveToExternalName = False</b>							
I	I	I	I	I	I	I	No
I	I	I	I	I	I	I	Yes
<b>ResolveToExternalName = True</b>							
E	E	I	E	E	I	I	No
E	E	I	E	E	I	E	Yes

Key: I: resolves to internal IP address of head  
E: resolves to external IP address of head

The system configuration files on the head nodes that get affected by this directive include `/etc/hosts` and, on SLES systems, also the `/etc/HOSTNAME`. Also, the DNS zone configuration files get affected.

Additionally, in both the single-head and failover clusters, using the “`hostname -f`” command on a head node while `ResolveToExternalName` is enabled results in the host’s Fully Qualified Domain Name (FQDN) being returned with the host’s external domain name. That is, the domain name of the network that is specified as the “External network” in the base partition in `cmsh` (the output of “`cmsh -c "partition use base; get externalnetwork"`”).

Modifying the value of the `ResolveToExternalName` directive and restarting the `CMDaemon` while important system services (e.g. `Torque`) are running should not be done. Doing so is likely to cause problems with accessing such services due to them then running with a different domain name than the one with which they originally started.

On a tangential note that is closely, but not directly related to the `ResolveToExternalName` directive: the cluster can be configured so that the “`hostname -f`” command executed on a regular node returns the FQDN of that node, and so that the FQDN in turn resolves to an external IP for that regular node. The details on how to do this are in the Bright Cluster Manager Knowledge Base at <http://kb.brightcomputing.com/>. A search query for FQDN leads to the relevant entry.

## AdvancedConfig directive

**Syntax:** `AdvancedConfig = { "<key1>=<value1>", "<key2>=<value2>", ... }`

**Default:** *Commented out in the default `cmd.conf` file*

The `AdvancedConfig` directive is not part of the standard directives. It takes a set of key/value pairs as parameters, with each key/value pair allowing a particular functionality, and is quite normal in that respect. However, the functionality of a parameter to this directive is often applicable only under restricted conditions, or for non-standard configurations. The `AdvancedConfig` parameters are therefore generally not recommended, nor are they documented, for use by the administrator.

Like for the other directives, only one `AdvancedConfig` directive line is used. This means that whatever functionality is to be enabled by this directive, its corresponding parameters must be added to that one line. These key/value pairs are therefore added by appending them to any existing `AdvancedConfig` key/value pairs, which means that the directive line can be a long list of key/value pairs to do with a variety of configurations.

## GlobalConfig directive

**Syntax:** `GlobalConfig = { "<key1>=<value1>", "<key2>=<value2>", ... }`

**Default:** *not in the default `cmd.conf` file*

The `GlobalConfig` directive is not part of the standard directives. It takes a set of key/value pairs as parameters, with each key/value pair allowing a particular functionality, and is quite normal in that respect. However, the parameter to this directive only needs to be specified on the head node. The non-head node `CMDaemons` take this value upon connection, which means that the `cmd.conf` file on the non-head nodes do not need to have this specified. This allows nodes with a boot role (section 5.1.5) to carry out, for example, `PXEBootOverHTTP` (page 608).

Like for the other directives, only one `GlobalConfig` directive line is used. This means that whatever functionality is to be enabled by this directive, its corresponding parameters must be added to that one line. These key/value pairs are therefore added by appending them to any existing `GlobalConfig` key/value pairs, which means that the directive line can be a long list of key/value pairs to do with a variety of configurations.

## ScriptEnvironment directive

**Syntax:** `ScriptEnvironment = { "CMD_ENV1=<value1>", "CMD_ENV2=<value2>", ... }`

**Default:** *Commented out in the default `cmd.conf` file*

The `ScriptEnvironment` directive sets extra environment variables for `CMDaemon` and child processes.

For example, if `CMDaemon` is running behind a web proxy, then the environment variable `http_proxy` may need to be set for it. If, for example, the proxy is the host `brawndo`, and it is accessed via port 8080 using a username/password pair of `joe/electrolytes`, then the directive becomes:

```
ScriptEnvironment = { "http_proxy=joe:electrolytes@brawndo:8080" }
```

## BurnSpoolDir directive

**Syntax:** `BurnSpoolDir = path`

**Default:** `BurnSpoolDir = "/var/spool/burn/"`

The `BurnSpoolDir` directive specifies the directory under which node burn log files are placed. The log files are logged under a directory named after the booting MAC address of the NIC of the node. For example, for a MAC address of `00:0c:29:92:55:5e` the directory is `/var/spool/burn/00-0c-29-92-55-5e`.

## IdleThreshold directive

**Syntax:** `IdleThreshold = number`

**Default:** `IdleThreshold = 1.0`

The `IdleThreshold` directive sets a threshold value for `loadone`. If `loadone` exceeds this value, then data producers that have `Only when idle` (page 435) set to `true` (enabled), will not run. If the data producer is sampled on a regular node rather than on the head node, then `cmd.conf` on the regular node should be modified and its `CMDaemon` restarted.

## MonitoringPath directive

**Syntax:** `AdvancedConfig = {"MonitoringPath=path", ...}`

**Default:** Implicit value: `"MonitoringPath=/var/spool/cmd/monitoring/"`

`MonitoringPath` is a parameter of the `AdvancedConfig` (page 602) directive.

Its value determines the path of the directory in which monitoring data is saved (section 13.8).

## MaxServiceFailureCount directive

**Syntax:** `AdvancedConfig = {"MaxServiceFailureCount=number", ...}`

**Default:** Implicit value: `"MaxServiceFailureCount=10"`

`MaxServiceFailureCount` is a parameter of the `AdvancedConfig` (page 602) directive.

Its value determines the number of times a service failure event is logged (page 97). Restart attempts on the service still continue when this number is exceeded.

## InitdScriptTimeout directive

**Syntax:** `AdvancedConfig = {"InitdScriptTimeout[.service]=timeout", ...}`

**Default:** Implicit value: `"InitdScriptTimeout=30"`

`InitdScriptTimeout` is a parameter of the `AdvancedConfig` (page 602) directive. It can be set globally or locally:

- **Global (all services)**

`InitdScriptTimeout` can be set as a global value for init scripts, by assigning *timeout* as a period in seconds. If an init script fails to start up its service within this period, then `CMDaemon` kills the service and attempts to restart it.

- If `InitdScriptTimeout` has a value for *timeout* set, then all init scripts have a default timeout of *timeout* seconds.
- If `InitdScriptTimeout` has no *timeout* value set, then all init scripts have a default timeout of 30 seconds.

- **Local (for a specific service)**

If `InitdScriptTimeout.service` is assigned a *timeout* value, then the init script for that *service* times out in *timeout* seconds. This timeout overrides, for that service only, any existing global default timeout.

When a timeout happens for an init script attempting to start a service, the event is logged. If the number of restart attempts exceeds the value determined by the `MaxServiceFailureCount` directive (page 603), then the event is no longer logged, but the restart attempts continue.

## Example

An fhgfs startup takes a bit longer than 30 seconds, and therefore times out with the default timeout value of 30s. This results in the following logs in `/var/log/cmdaemon`:

```
cmd: [SERVICE] Debug: ProgramRunner: /etc/init.d/fhgfs-client restart
[DONE] 0 9
cmd: [SERVICE] Debug: /etc/init.d/fhgfs-client restart, exitcode = 0,
signal = 9
```

Here, *service* is `fhgfs-client`, so setting the parameter can be done with:

```
AdvancedConfig = { ..., "initdScriptTimeout.fhgfs-client=60", ...}
```

This allows a more generous timeout of 60 seconds instead.

Restarting CMDaemon then should allow the fhgs startup to complete

```
# service cmd restart
```

A more refined approach that avoids a complete CMDaemon restart would be to execute a `reset` (page 97) on the `fhgfs-client` from within CMDaemon, as follows:

```
[bright80->category[default]->services[fhgfs-client]]% reset fhgfs-client
Successfully reset service fhgfs-client on: node001,node002
[bright80->category[default]->services[fhgfs-client]]%
```

## CMDaemonListenOnInterfaces directive

**Syntax:** `AdvancedConfig = {"CMDaemonListenOnInterfaces=<interfaces>", ...}`

**Default:** *all interfaces listening to port 8081*

`CMDaemonListenOnInterfaces` is a parameter of the `AdvancedConfig` (page 602) directive.

When set explicitly, CMDaemon listens only to the interfaces listed in `<interfaces>`. The form of `<interfaces>` is a comma-separated list of interface device names:

### Example

```
CMDaemonListenOnInterfaces=eth0,eth1,eth0:0,eth0:1
```

If the interface list item `lo` is omitted from the list of names, it will still be listened to. This is because CMDaemon must always be able to talk to itself on the loopback interface.

## CookieCooldownTime directive

**Syntax:** `AdvancedConfig = {"CookieCooldownTime=number from 60 to 86400"}`

**Default:** 900

`CookieCooldownTime` is a parameter of the `AdvancedConfig` (page 602) directive.

It defines the number of seconds until the Bright View connection to CMDaemon times out, if there is no user activity at the Bright View client side.

## OpenStackVXLANGroup directive

**Syntax:** `AdvancedConfig = {"OpenStackVXLANGroup=IP address"}`

**Default:** 224.0.0.1

`OpenStackVXLANGroup` is a parameter of the `AdvancedConfig` (page 602) directive.

It defines the multicast address used by OpenStack for broadcast traffic with VXLAN networking (page 29 of the *OpenStack Deployment Manual*). If an application already uses the default IP address, then another IP address can be specified for VXLAN networking needs with this directive.

## MaxSGEJobLimit

**Syntax:** `MaxSGEJobLimit = number`

**Default:** Implicit value: `MaxSGEJobLimit = 0`

This sets the maximum number of lines that is displayed in the jobs window. By default it is set to 0, which means there is no limit set.

However, if the number of jobs is very large, then parsing them takes time, and can result in a high load on CMDaemon. Setting a limit can help CMDaemon cope with such a case.

## RsyncHardLinks directive

**Syntax:** `AdvancedConfig = {"RsyncHardLinks=0|1", ...}`

**Default:** 1

`RsyncHardLinks` is a parameter of the `AdvancedConfig` (page 602) directive. It controls, for the `rsync` command, the hard links preservation option: `-H|--hard-links`

If `RsyncHardLinks` is set to:

- 1: then `rsync` copies hard links
- 0: then `rsync` does not copy hard links

## RsyncXattrs directive

**Syntax:** `AdvancedConfig = {"RsyncXattrs=-1|0|1", ...}`

**Default:** -1

`RsyncXattrs` is a parameter of the `AdvancedConfig` (page 602) directive. It controls, for the `rsync` command, the extended attributes command line option: `-X|--xattrs`

If `RsyncXattrs` is set to:

- 1: then `rsync` copies extended attributes
- 0: then `rsync` does not copy extended attributes
- -1: then `rsync` follows the default setting for whether or not to copy extended attributes.

The default setting copies extended attributes only if the distribution version:

- is RHEL7 (and derivatives) and above,
- or SLES12 and above

## RsyncAcls directive

**Syntax:** `AdvancedConfig = {"RsyncAcls=-1|0|1", ...}`

**Default:** -1

`RsyncAcls` is a parameter of the `AdvancedConfig` (page 602) directive. It controls, for the `rsync` command, the access control list (ACL) command line option: `-A|--acls`

If `RsyncAcls` is set to:

- 1: then `rsync` copies ACLs
- 0: then `rsync` does not copy ACLs



- -1: then `rsync` follows the default setting for whether or not to copy ACLs.

The default setting copies ACLs only if the distribution version:

- is RHEL7 (and derivatives), and above,
- or SLES12 and above

### **<wlm>Timeout directives:**

#### **CondorTimeout directive**

#### **PBSPROTimeout directive**

#### **SGETimeout directive**

#### **SlurmTimeout directive**

#### **TorqueTimeout directive**

#### **OpenLavaTimeout directive**

#### **LSFTimeout directive**

**Syntax:** `AdvancedConfig = {"<wlm>Timeout=<number>", ...}`

where: `<wlm>` is one of:

`Condor | PBSPRO | SGE | Slurm | Torque | OpenLava | LSF`

**Default:** 120

`<wlm>Timeout` is a parameter of the `AdvancedConfig` (page 602) directive. It is the maximum time, in seconds, that CMDaemon will wait for a response from the job scheduler of the workload manager. Increasing this value is sometimes needed for clusters with demanding job loads. Workload managers for which this value can be set are:

- Condor
- PBSPRO
- SGE
- Slurm
- Torque
- OpenLava
- LSF

### **SlurmDisableAccountingParsing directive**

**Syntax:** `AdvancedConfig = {"SlurmDisableAccountingParsing=0|1", ...}`

**Default:** 0

`SlurmDisableAccountingParsing` is a parameter of the `AdvancedConfig` (page 602) directive. If set to 1, it disables collection of accounting information for the Slurm workload manager.

### **JobsSamplingMetricsInterval directive**

**Syntax:** `AdvancedConfig = {"JobsSamplingMetricsInterval=<number>", ...}`

**Default:** 60

`JobsSamplingMetricsInterval` is a parameter of the `AdvancedConfig` (page 602) directive. Its value is a time period, in seconds, and it applies only to metrics associated with job queues. Such metric



sampling is carried out with this time period if job queues are added, or if job queues are re-created after disappearing.

## MembershipQueryInterval directive

**Syntax:** `AdvancedConfig = {"MembershipQueryInterval=<number>", ...}`

**Default:** 4

`MembershipQueryInterval` is a parameter of the `AdvancedConfig` (page 602) directive. Its value is a time period, in seconds. This time period value elapses between the checks that `CMDaemon` makes to determine the node states (section 5.5) in a cluster. If the network is very congested, then a larger value can be used to reduce the network load caused by these checks.

## AddUserScript directive

**Syntax:** `AdvancedConfig = {"AddUserScript=<path>", ...}`

**Default:** *none*

`AddUserScript` is a parameter of the `AdvancedConfig` (page 602) directive. If this parameter is set to a path leading to a script, and if a new user is added using `cmsh` or `Bright View`, then the script is automatically run by `CMDaemon`, with the username of the new user automatically passed as the first argument to the script. The script has a default timeout of 5 seconds.

## AddUserScriptPasswordInEnvironment directive

**Syntax:** `AdvancedConfig = {"AddUserScriptPasswordInEnvironment=0|1", ...}`

**Default:** 0

`AddUserScriptPasswordInEnvironment` is a parameter of the `AdvancedConfig` (page 602) directive. If this parameter is set to 1, then `CMDaemon` passes the `CMD_USER_PASSWORD` environment variable to the script defined by the `AddUserScript` directive.

## RemoveUserScript directive

**Syntax:** `AdvancedConfig = {"RemoveUserScript=<path>", ...}`

**Default:** *none*

`RemoveUserScript` is a parameter of the `AdvancedConfig` (page 602) directive. If this parameter is set to a path leading to a script, and if an existing user is removed using `cmsh` or `Bright View`, then the script is automatically run by `CMDaemon`. The script has a default timeout of 5 seconds.

## AddUserScriptTimeout directive

**Syntax:** `AdvancedConfig = {"AddUserScriptTimeout=<number>", ...}`

**Default:** 5

`AddUserScriptTimeout` is a parameter of the `AdvancedConfig` (page 602) directive. It sets the timeout value in seconds, for the script set by `AddUserScript`.

## RemoveUserScriptTimeout directive

**Syntax:** `AdvancedConfig = {"RemoveUserScriptTimeout=<number>", ...}`

**Default:** 5

`RemoveUserScriptTimeout` is a parameter of the `AdvancedConfig` (page 602) directive. It sets the timeout value in seconds, for the script set by `RemoveUserScript`.

## AdditionalSubmitHosts directive

## AdditionalExecHosts directive

### Syntax:

```
AdvancedConfig = {"AdditionalSubmitHosts=<host1>,<host2>,...", ...}
or
AdvancedConfig = {"AdditionalExecHosts=<host1>,<host2>,...", ...}
```

**Default:** *none*

The `AdditionalSubmitHosts` and `AdditionalExecHosts` directives are parameters of the `AdvancedConfig` (page 602) directive.

These directives can be used to make Bright Cluster Manager aware of the existence of a submit host or execution host that is outside of Bright Cluster Manager control. The directives are typically used with SGE and UGE workload managers so that CMDaemon does not remove such hosts from the workload manager configuration file during a configuration file maintenance run. An example of their use is given on page 232.

## MicLDAPBase directive

**Syntax:** `AdvancedConfig = {"MicLDAPBase=<domain>"}`

**Default:** *none*

The `MicLDAPBase` directive is a parameter of the `AdvancedConfig` (page 602) directive. Setting it to a domain overrides the default value of the LDAP base address on the MIC when its `/etc/ldap.conf` is initialized.

## MicLDAPServer directive

**Syntax:** `AdvancedConfig = {"MicLDAPServer=<server>"}`

**Default:** *none*

The `MicLDAPServer` directive is a parameter of the `AdvancedConfig` (page 602) directive. Setting it to a server name overrides the default value of the MIC LDAP server name when its `/etc/ldap.conf` is initialized.

## MicLDAPForceCustomBase directive

**Syntax:** `AdvancedConfig = {"MicLDAPForceCustomBase=1|0"}`

**Default:** 0

The `MicLDAPForceCustomBase` directive is a parameter of the `AdvancedConfig` (page 602) directive. Setting it to 1 overrides the default globalnetwork base address used for the base LDAP address with the `MicLDAPBase` address.

## PXEBootOverHTTP directive

**Syntax:** `GlobalConfig = {"PXEBootOverHTTP=1|0"}`

**Syntax:** `AdvancedConfig = {"PXEBootOverHTTP=1|0"}`

**Default:** 1

The `PXEBootOverHTTP` directive is a parameter of the `GlobalConfig` (page 602) directive. It is also a parameter of the `AdvancedConfig` (page 602) directive.

The `AdvancedConfig` directive is set on the `cmd.conf` per node image to apply it to the associated nodes. The `GlobalConfig` directive is set on the `cmd.conf` file of the head node(s), which applies the value to all nodes.

If the directive is set to a value of 0, then the provisioner sends the initial boot loader, kernel, and ramdisk via TFTP, to the provisioning node.

If the directive is set to a value of 1, which is the default value, then

- The initial boot loader is still loaded up via TFTP, since very few devices support boot loading over HTTP. However, the kernel and ramdisk are now loaded up via HTTP, which is faster and more reliable.
- The administrator must manually set the value of `SSLPortOnly` (page 590) to `no`, if needed.
- `CMDaemon` manages the configuration of `/etc/dhcpd.conf` and `/etc/dhcpd.<network name>.conf` on the head node, unless these files are frozen (page 597).
- `CMDaemon` provides the HTTP server on port 8080, accessible via `http://master:8080/tftpboot`.

## AutomaticMountAll directive

**Syntax:** `AutomaticMountAll=0|1`

**Default:** 1

If the `AutomaticMountAll` directive is set to the default of 1, then a `mount -a` operation is carried out when a mount change is carried out by `CMDaemon`.

The `mount -a` operation is to do with attempting to mount devices listed in `/etc/fstab`. It should not be confused with auto-mounting of filesystems, which is to do with mounting an arbitrary device to a filesystem automatically.

If the `AutomaticMountAll` directive is set to 0, then `/etc/fstab` is written, but the `mount -a` command is not run by `CMDaemon`. However, the administrator should be aware that since `mount -a` is run by the distribution during booting, a node reboot implements the mount change.

## AllowImageUpdateWithAutoMount directive

**Syntax:** `AdvancedConfig = {"AllowImageUpdateWithAutoMount=0|1|2|3"}`

**Default:** 0

The `AllowImageUpdateWithAutoMount` directive is a parameter of the `AdvancedConfig` (page 602) directive. The values it takes decide how an auto-mounted filesystem should be dealt with during image updates. It must be set per software image.

Value	Description
0	If auto-mount is running, abort provisioning (default)
1	If auto-mount is running, warn but continue
2	Do not check auto-mount status. This saves a little time, but it risks data loss, unless the automounted filesystem has been added to <code>excludelistupdate</code> .
3	Pretend auto-mount is running. This prevents an image update

How an auto-mounted filesystem can be configured using the `autofs` service in Bright Cluster Manager is discussed in section 3.10. The need for adding the automounted filesystem to

`excludelistupdate` is discussed on page 176.

## DNS::options\_allow-query directive

**Syntax:** `AdvancedConfig = {"DNS::options_allow-query=<subnet1>, <subnet2>, ..."}"`

**Default:** `unset`

The `DNS::options_allow-query` directive is a parameter of the `AdvancedConfig` (page 602) directive. If a subnet value is specified, in CIDR notation, then that subnet can query the DNS running on the head node. Setting a subnet places an entry within the `allow-query` section of `/etc/named.conf`.

The standard directive `PublicDNS` (page 595) simply adds the entry `0.0.0.0/0` to the `allow-query` section and can be used if no specific subnet needs to be added.

## CassandraDefaultDataCenter directive

**Syntax:** `AdvancedConfig = {"CassandraDefaultDataCenter=<string>"}`

**Default:** `CassandraDefaultDataCenter=DC1`

The `CassandraDefaultDataCenter` directive is a parameter of the `AdvancedConfig` (page 602) directive. It sets the default datacenter for Cassandra (page 87 of the *Big Data Deployment Manual*). The default default value is `DC1`.

## CassandraDefaultRack directive

**Syntax:** `AdvancedConfig = {"CassandraDefaultRack=<string>"}`

**Default:** `CassandraDefaultRack=RAC1`

The `CassandraDefaultRack` directive is a parameter of the `AdvancedConfig` (page 602) directive. It sets the default rack for Cassandra (page 87 of the *Big Data Deployment Manual*). The default default value is `RAC1`.

## AllowNullCipherNetwork directive

**Syntax:** `AdvancedConfig = {"AllowNullCipherNetwork=0|1"}`

**Default:** `AllowNullCipherNetwork=1`

The `AllowNullCipherNetwork` directive is a parameter of the `AdvancedConfig` (page 602) directive. If it uses the default value of 1, which is recommended, then communication on internal networks is unencrypted. Changing the value to 0 sets encryption on for the internal network, and should only be done for unusual cases.

## CipherList directive

**Syntax:** `AdvancedConfig = {"CipherList=<ciphers>"}`

**Default:** `CipherList=ALL:!aNULL:!eNULL`

The `CipherList` directive is a parameter of the `AdvancedConfig` (page 602) directive. It sets the cipher list of the OpenSSL suite that CMDaemon negotiates with clients. Ciphers in the cipher list can be viewed with:

### Example

```
[root@bright80 ~]# openssl ciphers -v
ECDHE-RSA-AES256-GCM-SHA384 TLSv1.2 Kx=ECDH    Au=RSA  Enc=AESGCM(256) Mac=AEAD
```

```

ECDHE-ECDSA-AES256-GCM-SHA384 TLSv1.2 Kx=ECDH      Au=ECDSA Enc=AESGCM(256) Mac=AEAD
ECDHE-RSA-AES256-SHA384 TLSv1.2 Kx=ECDH      Au=RSA Enc=AES(256) Mac=SHA384
ECDHE-ECDSA-AES256-SHA384 TLSv1.2 Kx=ECDH      Au=ECDSA Enc=AES(256) Mac=SHA384
ECDHE-RSA-AES256-SHA SSLv3 Kx=ECDH      Au=RSA Enc=AES(256) Mac=SHA1
...

```

The columns are: the cipher name, SSL protocol, key exchange used, authentication mechanism, encryption used, and MAC digest algorithm.

Ciphers can be specified for the `CipherList` directive according to the specification described in `man (1) ciphers`. For example, as:

### Example

```
AdvancedConfig = {"CipherList=ALL:!aNULL:!ADH:!eNULL:!LOW:!EXP:RC4+RSA:+HIGH:+MEDIUM"}
```

## JobInformationDisabled directive

**Syntax:** `AdvancedConfig = {"JobInformationDisabled=0|1"}`

**Default:** `JobInformationDisabled=0`

The `JobInformationDisabled` directive is a parameter of the `AdvancedConfig` (page 602) directive. If set to 1 it fully disables job-based monitoring (section 12.8).

For a cluster that is running millions of jobs at a time, job-based monitoring can typically consume significant resources. The monitoring of data for so many small jobs is typically not useful and not of interest. For such a case, setting this directive improves cluster performance.

## JobInformationKeepDuration directive

**Syntax:** `AdvancedConfig = {"JobInformationKeepDuration=<number>", ...}`

**Default:** `JobInformationKeepDuration=2419200`

The `JobInformationKeepDuration` directive is a parameter of the `AdvancedConfig` (page 602) directive. It takes on a value in seconds. If a job has finished more than that many seconds ago, then it will be removed along with all its monitoring data from the database. By default it is set to 28 days ( $24 \times 3600 \times 28$  seconds).

## ActionLoggerFile directive

**Syntax:** `AdvancedConfig = {"ActionLoggerFile=filename"}`

**Default:** `/var/spool/cmd/actions.log`

The directive is a parameter of the `AdvancedConfig` (page 602) directive. Its value overrides the default path.

The directive needs to be implemented per node or image.

## ActionLoggerOnSuccess directive

**Syntax:** `AdvancedConfig = {"ActionLoggerOnSuccess=0|1"}`

**Default:** `ActionLoggerOnSuccess=0`

By default, only failed actions are logged. Successful actions are also logged if setting `ActionLoggerOnSuccess=1`. The directive needs to be implemented per node or image.

The log file shows timestamped output with one line per run for an action script, with the script response.

**Example**

```
(time) /path/to/action/script [ timeout ]  
(time) /path/to/action/script [ failed ] (exit code: 1)  
(time) /path/to/action/script [ success ]          <=== only if advanced config
```

# D

## Disk Partitioning And RAID Configuration

Disk partitioning is initially configured on the head node and regular nodes during installation (section 3.3.17 of the *Installation Manual*).

For the head node it cannot be changed from within the Bright Cluster Manager after implementation, and the head node is therefore not considered further in this section.

For regular nodes, partitioning can be changed after the initial configuration, by specifying a particular set of values according to the XML partitioning schema described in section D.1.

For example, for regular nodes, changing the value set for the XML tag of:

```
<xs:element name='filesystem'>
```

decides which filesystem type out of `ext2`, `ext3`, `ext4`, `xfs`, and so on, is used. The changes are implemented during the node partitioning stage of the node-installer (section 5.4.6).

Diskless operation can also be implemented by using an appropriate XML file. This is introduced in section 3.9.1.

Software or hardware RAID configuration can also be set for the regular nodes. The layouts must be specified following the XML schema files stored on the head node in the directory `/cm/node-installer/scripts/`:

- Software RAID configuration is set in the global partitioning XML schema file `disks.xsd` (section D.1).
- Hardware RAID configuration is set in the separate hardware RAID XML schema file `raid.xsd` (section D.2).

### D.1 Structure Of Partitioning Definition—The Global Partitioning XML Schema File

In Bright Cluster Manager, regular node partitioning setups have their global structure defined using an XML schema, which is installed on the head node in `/cm/node-installer/scripts/disks.xsd`. This schema does not include a hardware RAID description. The hardware RAID schema is defined separately in the file `raid.xsd` (section D.2).

Examples of schemas in use, with and without hardware RAID, are given in sections D.3 and beyond.

An XML file can be validated against a schema using the `xmllint` tool:

#### Example

```
[root@bright80 ~]# xmllint --noout --schema /cm/node-installer/scripts/disks.xsd \
/cm/local/apps/cmd/etc/htdocs/disk-setup/slave-diskless.xml
/cm/local/apps/cmd/etc/htdocs/disk-setup/slave-diskless.xml validates
[root@bright80 ~]#
```

## XML schema for partitioning

```
<?xml version='1.0'?>
```

```
<!--
```

```
#
```

```
# Copyright (c) 2004-2014 Bright Computing, Inc. All Rights Reserved.
```

```
#
```

```
# This software is the confidential and proprietary information of
# Bright Computing, Inc.("Confidential Information"). You shall not
# disclose such Confidential Information and shall use it only in
# accordance with the terms of the license agreement you entered into
# with Bright Computing, Inc.
```

This is the XML schema description of the partition layout XML file.

It can be used by software to validate partitioning XML files.

There are however a few things the schema does not check:

- There should be exactly one root mountpoint (/), unless diskless.
- There can only be one partition with a 'max' size on a particular device.
- Something similar applies to logical volumes.
- The 'auto' size can only be used for a swap partition.
- Partitions of type 'linux swap' should not have a filesystem.
- Partitions of type 'linux raid' should not have a filesystem.
- Partitions of type 'linux lvm' should not have a filesystem.
- Partitions of type 'unspecified' should not have a filesystem.
- If a raid is a member of another raid then it can not have a filesystem.
- Partitions, which are listed as raid members, should be of type 'linux raid'.
- If diskless is not set, there should be at least one device.
- The priority tag is only valid for partitions which have type set to "linux swap".

```
-->
```

```
<xs:schema xmlns:xs='http://www.w3.org/2001/XMLSchema' elementFormDefault='qualified'>
```

```
  <xs:element name='diskSetup'>
```

```
    <xs:complexType>
```

```
      <xs:sequence>
```

```
        <xs:element name='diskless' type='diskless' minOccurs='0' maxOccurs='1' />
```

```
        <xs:element name='device' type='device' minOccurs='0' maxOccurs='unbounded' />
```

```
        <xs:element name='raid' type='raid' minOccurs='0' maxOccurs='unbounded' />
```

```
        <xs:element name='volumeGroup' type='volumeGroup' minOccurs='0' maxOccurs='unbounded' />
```

```
        <xs:element name='subVolumes' type='subVolumes' minOccurs='0' maxOccurs='unbounded' />
```

```
      </xs:sequence>
```

```
    </xs:complexType>
```

```
    <xs:key name='partitionAndRaidIds'>
```

```
      <xs:selector xpath='./raid|./partition' />
```

```
      <xs:field xpath='@id' />
```

```
    </xs:key>
```

```
    <xs:keyref name='raidMemberIds' refer='partitionAndRaidIds'>
```

```
      <xs:selector xpath='./raid/member' />
```

```
      <xs:field xpath='.' />
```

```
    </xs:keyref>
```



```

<xs:keyref name='volumeGroupPhysicalVolumes' refer='partitionAndRaidIds'>
  <xs:selector xpath='../volumeGroup/physicalVolumes/member' />
  <xs:field xpath='.' />
</xs:keyref>

<xs:keyref name='subVolumeIds' refer='partitionAndRaidIds'>
  <xs:selector xpath='../subVolumes' />
  <xs:field xpath='@parent' />
</xs:keyref>

<xs:unique name='raidAndVolumeMembersUnique'>
  <xs:selector xpath='../member' />
  <xs:field xpath='.' />
</xs:unique>

<xs:unique name='deviceNodesUnique'>
  <xs:selector xpath='../device/blockdev' />
  <xs:field xpath='.' />
  <xs:field xpath='@mode' />
</xs:unique>

<xs:unique name='mountPointsUnique'>
  <xs:selector xpath='../mountPoint' />
  <xs:field xpath='.' />
</xs:unique>

<xs:unique name='assertNamesUnique'>
  <xs:selector xpath='../assert' />
  <xs:field xpath='@name' />
</xs:unique>

</xs:element>

<xs:complexType name='diskless'>
  <xs:attribute name='maxMemSize' type='memSize' use='required' />
</xs:complexType>

<xs:simpleType name='memSize'>
  <xs:restriction base='xs:string'>
    <xs:pattern value='([0-9]+[MG])|100%|[0-9][0-9]%|[0-9]%|0' />
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name='stripeSize'>
  <xs:restriction base='xs:string'>
    <xs:pattern value='4|8|16|32|64|128|256|512|1024|1K|2048|2K|4096|4K' />
    <xs:pattern value='8192|8K|16384|16K|32768|32K|65536|64K|131072|128K' />
    <xs:pattern value='262144|256K|524288|512K|1048576|1024K|1M' />
    <xs:pattern value='2097152|2048K|2M|4194304|4096K|4M' />
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name='size'>
  <xs:restriction base='xs:string'>

```

```

    <xs:pattern value='max|auto|[0-9]+[MGT]'/>
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name='relativeOrAbsoluteSize'>
  <xs:restriction base='xs:string'>
    <xs:pattern value='max|auto|[0-9]+[MGT]|[0-9]+([.][0-9]+)?%|[0-9]+/[0-9]+'/>
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name='extentSize'>
  <xs:restriction base='xs:string'>
    <xs:pattern value='([0-9])+M'/>
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name='blockdevName'>
  <xs:restriction base='xs:string'>
    <xs:pattern value='/dev/.+'/>
  </xs:restriction>
</xs:simpleType>

<xs:complexType name='blockdev'>
  <xs:simpleContent>
    <xs:extension base="blockdevName">
      <xs:attribute name="mode" default='normal'>
        <xs:simpleType>
          <xs:restriction base="xs:string">
            <xs:pattern value="normal|cloud|both"/>
          </xs:restriction>
        </xs:simpleType>
      </xs:attribute>
    </xs:extension>
  </xs:simpleContent>
</xs:complexType>

<xs:complexType name='device'>
  <xs:sequence>
    <xs:element name='blockdev' type='blockdev' minOccurs='1' maxOccurs='unbounded'/>
    <xs:element name='vendor' type='xs:string' minOccurs='0' maxOccurs='1'/>
    <xs:element name='requiredSize' type='size' minOccurs='0' maxOccurs='1'/>
    <xs:element name='assert' minOccurs='0' maxOccurs='unbounded'>
      <xs:complexType>
        <xs:simpleContent>
          <xs:extension base='xs:string'>
            <xs:attribute name='name' use='required'>
              <xs:simpleType>
                <xs:restriction base='xs:string'>
                  <xs:pattern value='[a-zA-Z0-9-]+'/>
                </xs:restriction>
              </xs:simpleType>
            </xs:attribute>
            <xs:attribute name='args' type='xs:string'/>
          </xs:extension>
        </xs:simpleContent>
      </xs:complexType>
    </xs:element>
  </xs:sequence>

```

```

        </xs:complexType>
    </xs:element>
    <xs:element name='alignMiB' type='xs:boolean' minOccurs='0' maxOccurs='1' />
    <xs:element name='partition' type='partition' minOccurs='1' maxOccurs='unbounded' />
</xs:sequence>
<xs:attribute name='origin' type='xs:string' />
</xs:complexType>

<xs:complexType name='partition'>
    <xs:sequence>
        <xs:element name='cephosdassociation' type='xs:string' minOccurs='0' maxOccurs='1' />
        <xs:element name='size' type='relativeOrAbsoluteSize' />
        <xs:element name='type'>
            <xs:simpleType>
                <xs:restriction base='xs:string'>
                    <xs:enumeration value='linux' />
                    <xs:enumeration value='linux swap' />
                    <xs:enumeration value='linux raid' />
                    <xs:enumeration value='linux lvm' />
                    <xs:enumeration value='unspecified' />
                </xs:restriction>
            </xs:simpleType>
        </xs:element>
        <xs:group ref='filesystem' minOccurs='0' maxOccurs='1' />
        <xs:element name='priority' minOccurs='0' maxOccurs='1'>
            <xs:simpleType>
                <xs:restriction base='xs:integer'>
                    <xs:minInclusive value='0' />
                    <xs:maxInclusive value='32767' />
                </xs:restriction>
            </xs:simpleType>
        </xs:element>
    </xs:sequence>
    <xs:attribute name='id' type='xs:string' use='required' />
    <xs:attribute name='partitiontype' type='xs:string' />
</xs:complexType>

<xs:group name='filesystem'>
    <xs:sequence>
        <xs:element name='filesystem'>
            <xs:simpleType>
                <xs:restriction base='xs:string'>
                    <xs:enumeration value='ext2' />
                    <xs:enumeration value='ext3' />
                    <xs:enumeration value='ext4' />
                    <xs:enumeration value='xfs' />
                    <xs:enumeration value='btrfs' />
                    <xs:enumeration value='zfs' />
                    <xs:enumeration value='fat32' />
                    <xs:enumeration value='fat' />
                </xs:restriction>
            </xs:simpleType>
        </xs:element>
        <xs:element name='mkfsFlags' type='xs:string' minOccurs='0' maxOccurs='1' />
        <xs:element name='mountPoint' type='xs:string' minOccurs='0' maxOccurs='1' />
    </xs:sequence>
</xs:group>

```

```

    <xs:element name='mountOptions' type='xs:string' default='defaults' minOccurs='0' />
  </xs:sequence>
</xs:group>

<xs:complexType name='raid'>
  <xs:sequence>
    <xs:element name='member' type='xs:string' minOccurs='2' maxOccurs='unbounded' />
    <xs:element name='level' type='xs:int' />
    <xs:choice minOccurs='0' maxOccurs='1'>
      <xs:group ref='filesystem' />
      <xs:sequence>
        <xs:element name='swap'><xs:complexType /></xs:element>
        <xs:element name='priority' minOccurs='0' maxOccurs='1'>
          <xs:simpleType>
            <xs:restriction base="xs:integer">
              <xs:minInclusive value="0" />
              <xs:maxInclusive value="32767" />
            </xs:restriction>
          </xs:simpleType>
        </xs:element>
      </xs:sequence>
    </xs:choice>
  </xs:sequence>
  <xs:attribute name='id' type='xs:string' use='required' />
</xs:complexType>

<xs:complexType name='volumeGroup'>
  <xs:sequence>
    <xs:element name='name' type='xs:string' />
    <xs:element name='extentSize' type='extentSize' />
    <xs:element name='physicalVolumes'>
      <xs:complexType>
        <xs:sequence>
          <xs:element name='member' type='xs:string' minOccurs='1' maxOccurs='unbounded' />
        </xs:sequence>
      </xs:complexType>
    </xs:element>
    <xs:element name='logicalVolumes'>
      <xs:complexType>
        <xs:sequence>
          <xs:element name='volume' type='logicalVolume' minOccurs='1' maxOccurs='unbounded' />
        </xs:sequence>
      </xs:complexType>
    </xs:element>
  </xs:sequence>
</xs:complexType>

<xs:complexType name='logicalVolume'>
  <xs:sequence>
    <xs:element name='name' type='xs:string' />
    <xs:element name='size' type='size' />
    <xs:element name='stripes' minOccurs='0' maxOccurs='1'>
      <xs:simpleType>
        <xs:restriction base="xs:integer">
          <xs:minInclusive value="1" />
        </xs:restriction>
      </xs:simpleType>
    </xs:element>
  </xs:sequence>
</xs:complexType>

```

```

        <xs:maxInclusive value="32768"/>
      </xs:restriction>
    </xs:simpleType>
  </xs:element>
  <xs:element name='stripeSize' type='stripeSize' minOccurs='0' maxOccurs='1'/>
  <xs:group ref='filesystem' minOccurs='0' maxOccurs='1'/>
</xs:sequence>
</xs:complexType>

<xs:complexType name='subVolumes'>
  <xs:sequence>
    <xs:element name='subVolume' type='subVolume' minOccurs='1' maxOccurs='unbounded'/>
  </xs:sequence>
  <xs:attribute name='parent' type='xs:string' use='required'/>
</xs:complexType>

<xs:complexType name='subVolume'>
  <xs:sequence>
    <xs:element name='mountPoint' type='xs:string'/>
    <xs:element name='mountOptions' type='xs:string'/>
  </xs:sequence>
</xs:complexType>
</xs:schema>

```

### Examples Of Element Types In XML Schema

Name Of Type	Example Values
size	10G, 128M, 1T, 2.5T, 1/3, 33.333%, auto, max
device	/dev/sda, /dev/hda, /dev/cciss/c0d0
partition	linux, linux raid, linux swap, unspecified
filesystem	ext2, ext3, ext4, xfs

## D.2 Structure Of Hardware RAID Definition—The Hardware RAID XML Schema File

Hardware RAID can be specified using an XML schema, stored on the head node in /cm/node-installer/scripts/raid.xsd. The full schema specification is listed here, while schema examples are listed in section D.4.1.

```

<?xml version="1.0" encoding="ISO-8859-1" ?>

<!--
#
# Copyright (c) 2004-2010 Bright Computing, Inc. All Rights Reserved.
#
# This software is the confidential and proprietary information of
# Bright Computing, Inc. ("Confidential Information"). You shall not
# disclose such Confidential Information and shall use it only in
# accordance with the terms of the license agreement you entered into
# with Bright Computing, Inc.

```

This is the XML schema description of the hardware RAID layout XML file.  
It can be used by software to validate partitioning XML files.

There are however a few things the schema does not check:

- All of the spans (drive groups) in an raidArray must have the same number of drives.
- There can only be one volume with a 'max' size on a particular array and this must be the last volume in the array.
- If there is only one enclosure defined for a particular RAID controller the actual enclosureID can be omitted by using "auto" instead. Otherwise, the actual enclosureID must be specified.

-->

```
<xs:schema xmlns:xs="http://www.w3.org/2001/XMLSchema">
```

```
  <xs:simpleType name="raidLevel">
    <xs:restriction base="xs:nonNegativeInteger">
      <xs:pattern value="0|1|5|10|50"/>
    </xs:restriction>
  </xs:simpleType>
```

```
  <xs:simpleType name="volumeSize">
    <xs:restriction base="xs:string">
      <xs:pattern value="[0-9]1,5[MGT]|max"/>
    </xs:restriction>
  </xs:simpleType>
```

```
  <xs:simpleType name="stripeSize">
    <xs:restriction base="xs:string">
      <xs:pattern value="8K|16K|32K|64K|128K|256K|512K|1024K"/>
    </xs:restriction>
  </xs:simpleType>
```

```
  <xs:simpleType name="cachePolicy">
    <xs:restriction base="xs:string">
      <xs:pattern value="Cached|Direct"/>
    </xs:restriction>
  </xs:simpleType>
```

```
  <!--
    NORA  : No Read Ahead
    RA    : Read Ahead
    ADRA  : Adaptive Read
  -->
```

```
  <xs:simpleType name="readPolicy">
    <xs:restriction base="xs:string">
      <xs:pattern value="NORA|RA|ADRA"/>
    </xs:restriction>
  </xs:simpleType>
```

```
  <!--
    WT    : Write Through
    WB    : Write Back
  -->
```

```
  <xs:simpleType name="writePolicy">
```

```

    <xs:restriction base="xs:string">
      <xs:pattern value="WT|WB"/>
    </xs:restriction>
  </xs:simpleType>

  <xs:simpleType name="enclosureID">
    <xs:restriction base="xs:string">
      <xs:pattern value="auto|[0-9]{1,4}"/>
    </xs:restriction>
  </xs:simpleType>

  <xs:simpleType name="slotNumber">
    <xs:restriction base="xs:nonNegativeInteger">
      <xs:pattern value="[0-9]{1,2}"/>
    </xs:restriction>
  </xs:simpleType>

  <xs:element name="raidSetup">
    <xs:complexType>
      <xs:sequence>

        <xs:element name="raidArray" minOccurs="0" maxOccurs="unbounded">
          <xs:complexType>
            <xs:sequence>

              <xs:element name="level" type="raidLevel"/>

              <xs:element name="raidVolume" maxOccurs="unbounded">
                <xs:complexType>
                  <xs:sequence>

                    <xs:element name="stripeSize" type="stripeSize"/>

                    <xs:element name="cachePolicy" type="cachePolicy"/>

                    <xs:element name="readPolicy" type="readPolicy"/>

                    <xs:element name="writePolicy" type="writePolicy"/>

                    <xs:element name="size" type="volumeSize"/>

                  </xs:sequence>
                </xs:complexType>
              </xs:element>

            <xs:choice>

              <xs:element name="device" maxOccurs="unbounded">
                <xs:complexType>
                  <xs:sequence>

                    <xs:element name="enclosureID" type="enclosureID"/>

                    <xs:element name="slotNumber" type="slotNumber"/>

```

```

        </xs:sequence>
      </xs:complexType>
    </xs:element>

    <xs:element name="span" minOccurs="2" maxOccurs="8">
      <xs:complexType>
        <xs:sequence>

          <xs:element name="device" maxOccurs="unbounded">
            <xs:complexType>
              <xs:sequence>

                <xs:element name="enclosureID" type="enclosureID"/>

                <xs:element name="slotNumber" type="slotNumber"/>

              </xs:sequence>
            </xs:complexType>
          </xs:element>

          </xs:sequence>
        </xs:complexType>
      </xs:element>

    </xs:choice>

  </xs:sequence>
</xs:complexType>
</xs:element>

</xs:sequence>
</xs:complexType>
</xs:element>

</xs:schema>

```

### D.3 Example: Default Node Partitioning

The following example follows the schema specification of section D.1, and shows the default layout used for regular nodes:

#### Example

```

<?xml version="1.0" encoding="UTF-8"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <device>
    <blockdev>/dev/sda</blockdev>
    <blockdev>/dev/hda</blockdev>
    <blockdev>/dev/vda</blockdev>
    <blockdev>/dev/xvda</blockdev>
    <blockdev>/dev/cciss/c0d0</blockdev>
    <blockdev mode="cloud">/dev/sdb</blockdev>
    <blockdev mode="cloud">/dev/hdb</blockdev>
    <blockdev mode="cloud">/dev/vdb</blockdev>
  </device>
</diskSetup>

```



```

<blockdev mode="cloud">/dev/xvdb</blockdev>
<blockdev mode="cloud">/dev/xvdf</blockdev>
<partition id="a1">
  <size>20G</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint>/</mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</partition>
<partition id="a2">
  <size>6G</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint>/var</mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</partition>
<partition id="a3">
  <size>2G</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint>/tmp</mountPoint>
  <mountOptions>defaults,noatime,nodiratime,nosuid,nodev</mountOptions>
</partition>
<partition id="a4">
  <size>12G</size>
  <type>linux swap</type>
</partition>
<partition id="a5">
  <size>max</size>
  <type>linux</type>
  <filesystem>ext3</filesystem>
  <mountPoint>/local</mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</partition>
</device>
</diskSetup>

```

The example assumes a single disk. Another disk can be added by adding another pair of `<device><device>` tags and filling in the partitioning specifications for the next disk. Because multiple `blockdev` tags are used, the node-installer first tries to use `/dev/sda`, then `/dev/hda`, then `/dev/vda` (virtio disks), then `/dev/xvda` (xen disks), and so on. Cloud devices can also be accessed using the `mode="cloud"` option. Removing block devices from the layout if they are not going to be used does no harm.

For each partition, a `size` tag is specified. Sizes can be specified using megabytes (e.g. 500M), gigabytes (e.g. 50G) or terabytes (e.g. 2T or 4.5T). Relative sizes, without units, can be used in the form of fractions (e.g. 2/3) or percentages (e.g. 70%), which can be useful for disk sizes that are not known in advance.

Small differences in size do not trigger a full install for existing relative partitions.

For swap partitions, a size of `auto` sets a swap partition to twice the node memory size. If there is more than one swap partition, then the `priority` tag can be set so that the partition with the higher priority is used first.

For a device, the attribute `max` for a `size` tag forces the last device in the partition to use all remaining space, and if needed, adjusts the implementation of the sequence of `size` tags in the remaining partitions accordingly. The use of `max` for a partition is convenient.

In the example, all filesystems are specified as `ext3`. Valid alternatives are `ext2`, `ext4` and `xfs`.

The `mount` man page has more details on mount options. If the `mountOptions` tag is left empty, its value defaults to `defaults`.

## D.4 Example: Hardware RAID Configuration

A prerequisite with hardware RAID is that it must be enabled and configured properly in the BIOS.

If it is enabled and configured correctly, then the hardware RAID configuration can be defined or modified by setting the `hardwareraidconfiguration` parameter in `device` or `category` mode:

### Example

```
[root@bright80 ~]# csmsh
[bright80]% category use default
[bright80->category[default]]% set hardwareraidconfiguration
```

This opens up an editor in which the XML file can be specified according to the schema in section D.2. XML validation is carried out.

### D.4.1 RAID level 0 And RAID 10 Example

In the following configuration the node has two RAID arrays, one in a RAID 0 and the other in a RAID 10 configuration:

- The RAID 0 array contains three volumes and is made up of two hard disks, placed in slots 0 and 1. The volumes have different values for the options and policies.
- The RAID 10 array consists of just one volume and has two spans, in slots 2 and 3. Each span has two hard disks.

### Example

```
<raidSetup>
  <raidArray>
    <level>0</level>

    <raidVolume>
      <stripeSize>64K</stripeSize>
      <cachePolicy>Direct</cachePolicy>
      <readPolicy>NORA</readPolicy>
      <writePolicy>WT</writePolicy>
      <size>40G</size>
    </raidVolume>

    <raidVolume>
      <stripeSize>128K</stripeSize>
      <cachePolicy>Direct</cachePolicy>
      <readPolicy>RA</readPolicy>
      <writePolicy>WB</writePolicy>
      <size>80G</size>
    </raidVolume>

    <raidVolume>
      <stripeSize>256K</stripeSize>
      <cachePolicy>Cached</cachePolicy>
      <readPolicy>ADRA</readPolicy>
      <writePolicy>WT</writePolicy>
```

```

    <size>100G</size>
  </raidVolume>

  <device>
    <enclosureID>auto</enclosureID>
    <slotNumber>0</slotNumber>
  </device>

  <device>
    <enclosureID>32</enclosureID>
    <slotNumber>1</slotNumber>
  </device>
</raidArray>

<raidArray>
  <level>10</level>

  <raidVolume>
    <stripeSize>64K</stripeSize>
    <cachePolicy>Direct</cachePolicy>
    <readPolicy>NORA</readPolicy>
    <writePolicy>WT</writePolicy>
    <size>40G</size>
  </raidVolume>

  <span>
    <device>
      <enclosureID>auto</enclosureID>
      <slotNumber>2</slotNumber>
    </device>

    <device>
      <enclosureID>auto</enclosureID>
      <slotNumber>3</slotNumber>
    </device>
  </span>

  <span>
    <device>
      <enclosureID>auto</enclosureID>
      <slotNumber>4</slotNumber>
    </device>

    <device>
      <enclosureID>auto</enclosureID>
      <slotNumber>5</slotNumber>
    </device>
  </span>
</raidArray>
</raidSetup>

```

## D.5 Example: Software RAID

The following example shows a simple software RAID setup:

### Example

```
<?xml version="1.0" encoding="ISO-8859-1"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
           xsi:noNamespaceSchemaLocation="schema.xsd">

  <device>
    <blockdev>/dev/sda</blockdev>
    <partition id="a1">
      <size>25G</size>
      <type>linux raid</type>
    </partition>
  </device>

  <device>
    <blockdev>/dev/sdb</blockdev>
    <partition id="b1">
      <size>25G</size>
      <type>linux raid</type>
    </partition>
  </device>

  <raid id="r1">
    <member>a1</member>
    <member>b1</member>
    <level>1</level>
    <filesystem>ext3</filesystem>
    <mountPoint></mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </raid>

</diskSetup>
```

The `level` tag specifies the RAID level used. The following are supported:

- 0 (striping without parity)
- 1 (mirroring)
- 4 (striping with dedicated parity drive)
- 5 (striping with distributed parity)
- 6 (striping with distributed double parity)

The `member` tags must refer to an `id` attribute of a `partition` tag, or an `id` attribute of a another `raid` tag. The latter can be used to create, for example, RAID 10 configurations.

The administrator must ensure that the correct RAID kernel module is loaded (section 5.3.2). Including the appropriate module from the following is usually sufficient: `raid0`, `raid1`, `raid4`, `raid5`, `raid6`.

## D.6 Example: Software RAID With Swap

The `<swap></swap>` tag is used to indicate a swap partition in a RAID device specified in the XML schema of section D.1. For example, the following marks a 1GB RAID 1 partition as being used for swap, and the second partition for an `ext3` filesystem:

```
<?xml version="1.0" encoding="UTF-8"?>
```

```

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <device>
    <blockdev>/dev/sda</blockdev>
    <partition id="a1">
      <size>1G</size>
      <type>linux raid</type>
    </partition>
    <partition id="a2">
      <size>max</size>
      <type>linux raid</type>
    </partition>
  </device>
  <device>
    <blockdev>/dev/sdb</blockdev>
    <partition id="b1">
      <size>1G</size>
      <type>linux raid</type>
    </partition>
    <partition id="b2">
      <size>max</size>
      <type>linux raid</type>
    </partition>
  </device>
  <raid id="r1">
    <member>a1</member>
    <member>b1</member>
    <level>1</level>
    <swap></swap>
  </raid>
  <raid id="r2">
    <member>a2</member>
    <member>b2</member>
    <level>1</level>
    <filesystem>ext3</filesystem>
    <mountPoint></mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </raid>
</diskSetup>

```

As in section D.5, the appropriate RAID modules must be loaded beforehand.

## D.7 Example: Logical Volume Manager

This example shows a simple LVM setup:

### Example

```

<?xml version="1.0" encoding="UTF-8"?>
<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <device>
    <blockdev>/dev/sda</blockdev>
    <blockdev>/dev/hda</blockdev>
    <blockdev>/dev/vda</blockdev>
    <blockdev>/dev/xvda</blockdev>
    <blockdev>/dev/cciss/c0d0</blockdev>

```

```

<blockdev mode="cloud"/>dev/sdb</blockdev>
<blockdev mode="cloud"/>dev/hdb</blockdev>
<blockdev mode="cloud"/>dev/vdb</blockdev>
<blockdev mode="cloud"/>dev/xvdb</blockdev>
<blockdev mode="cloud"/>dev/xvdf</blockdev>
<partition id="a1">
  <size>512M</size>
  <type>linux</type>
  <filesystem>ext2</filesystem>
  <mountPoint>/boot</mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</partition>
<partition id="a2">
  <size>16G</size>
  <type>linux swap</type>
</partition>
<partition id="a3">
  <size>max</size>
  <type>linux lvm</type>
</partition>
</device>
<volumeGroup>
  <name>vg01</name>
  <extentSize>8M</extentSize>
  <physicalVolumes>
    <member>a3</member>
  </physicalVolumes>
  <logicalVolumes>
    <volume>
      <name>lv00</name>
      <size>max</size>
      <filesystem>ext3</filesystem>
      <mountPoint>/</mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </volume>
    <volume>
      <name>lv01</name>
      <size>8G</size>
      <filesystem>ext3</filesystem>
      <mountPoint>/tmp</mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </volume>
  </logicalVolumes>
</volumeGroup>
</diskSetup>

```

The member tags must refer to an id attribute of a partition tag, or an id attribute of a raid tag.

The administrator must ensure that the `dm-mod` kernel module is loaded when LVM is used.

## D.8 Example: Logical Volume Manager With RAID 1

This example shows an LVM setup, but with the LVM partitions mirrored using RAID 1:

### Example

```
<?xml version="1.0" encoding="ISO-8859-1"?>
```

```

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xsi:no\
NamespaceSchemaLocation="schema.xsd">

<device>
  <blockdev>/dev/sda</blockdev>
  <partition id="a1">
    <size>512M</size>
    <type>linux raid</type>
  </partition>
  <partition id="a2">
    <size>max</size>
    <type>linux raid</type>
  </partition>
</device>

<device>
  <blockdev>/dev/sdb</blockdev>
  <partition id="b1">
    <size>512M</size>
    <type>linux raid</type>
  </partition>
  <partition id="b2">
    <size>max</size>
    <type>linux raid</type>
  </partition>
</device>

<raid id="r1">
  <member>a1</member>
  <member>b1</member>
  <level>1</level>
  <filesystem>ext3</filesystem>
  <mountPoint>/boot</mountPoint>
  <mountOptions>defaults,noatime,nodiratime</mountOptions>
</raid>

<raid id="r2">
  <member>a2</member>
  <member>b2</member>
  <level>1</level>
</raid>

<volumeGroup>
  <name>vg01</name>
  <extentSize>8M</extentSize>
  <physicalVolumes>
    <member>r2</member>
  </physicalVolumes>

  <logicalVolumes>
    <volume>
      <name>lv00</name>
      <size>50G</size>
      <filesystem>ext3</filesystem>
      <mountPoint>/</mountPoint>
    </volume>
  </logicalVolumes>
</volumeGroup>

```

```

    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </volume>
  <volume>
    <name>lv01</name>
    <size>25G</size>
    <filesystem>ext3</filesystem>
    <mountPoint>/tmp</mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </volume>
  <volume>
    <name>lv02</name>
    <size>25G</size>
    <filesystem>ext3</filesystem>
    <mountPoint>/var</mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </volume>
</logicalVolumes>
</volumeGroup>

</diskSetup>

```

## D.9 Example: Diskless

This example shows a node configured for diskless operation:

### Example

```

<?xml version="1.0" encoding="UTF-8"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <diskless maxMemSize="90%"></diskless>
</diskSetup>

```

An example of the implementation of a diskless configuration is given in section 3.9.3.

In diskless mode the software image is transferred by the node-installer to a RAM-based filesystem on the node called `tmpfs`.

The obvious advantage of running from RAM is the elimination of the physical disk, cutting power consumption and reducing the chance of hardware failure. On the other hand, some of the RAM on the node is then no longer available for user applications.

### Special considerations with diskless mode:

- **Recommended minimum RAM size:** The available RAM per node should be sufficient to run the OS and the required tasks. At least 4GB is recommended for diskless nodes.
- **The `tmpfs` size limit:** The maximum amount of RAM that can be used for a filesystem is set with the `maxMemSize` attribute. A value of 100% allows all of the RAM to be used. The default value is 90%. A value of 0, without the % sign, removes all restrictions.

A limit does not however necessarily prevent the node from crashing, as some processes might not deal properly with a situation when there is no more space left on the filesystem.

- **Persistence issues:** While running as a diskless node, the node is unable to retain any non-shared data each time it reboots. For example the files in `/var/log/*`, which are normally preserved by the exclude list settings for diskless nodes, are lost from RAM during diskless mode reboots.



- **Leftover disk issues:** Administrators in charge of sensitive environments should be aware that the disk of a node that is now running in diskless mode still contains files from the last time the disk was used, unless the files are explicitly wiped.
- **Reducing the software image size in `tmpfs` on a diskless node:** To make more RAM available for tasks, the software image size held in RAM can be reduced:
  - by removing unnecessary software from the image.
  - by mounting parts of the filesystem in the image over NFS during normal use. This is especially worthwhile for less frequently accessed parts of the image (section 3.10.3).

## D.10 Example: Semi-diskless

Diskless operation (section D.9) can also be mixed with certain parts of the filesystem on the local physical disk. This frees up RAM which the node can then put to other use. In this example all data in `/local` is on the physical disk, the rest in RAM.

### Example

```
<?xml version="1.0" encoding="UTF-8"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
           xsi:noNamespaceSchemaLocation="schema.xsd">
  <diskless maxMemSize="0"></diskless>
  <device>
    <blockdev>/dev/sda</blockdev>
    <partition id="a1">
      <size>max</size>
      <type>linux</type>
      <filesystem>ext3</filesystem>
      <mountPoint>/local</mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </partition>
  </device>
</diskSetup>
```

When nodes operate in semi-diskless mode the node-installer always uses `excludelistfullinstall` (section 5.4.7) when synchronizing the software image to memory and disk.

An alternative to using a local disk for freeing up RAM is to use NFS storage, as is described in section 3.10.3.

## D.11 Example: Preventing Accidental Data Loss

Optional tags, `vendor` and `requiredSize`, can be used to prevent accidentally repartitioning the wrong drive. Such a tag use is shown in the following example.

### Example

```
<?xml version="1.0" encoding="ISO-8859-1"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
           xsi:noNamespaceSchemaLocation="schema.xsd">
  <device>
    <blockdev>/dev/sda</blockdev>
    <vendor>Hitachi</vendor>
```

```

    <requiredSize>200G</requiredSize>

    <partition id="a1">
      <size>max</size>
      <type>linux</type>
      <filesystem>ext3</filesystem>
      <mountPoint></mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </partition>

  </device>
  <device>
    <blockdev>/dev/sdb</blockdev>
    <vendor>BigRaid</vendor>
    <requiredSize>2T</requiredSize>

    <partition id="b1">
      <size>max</size>
      <type>linux</type>
      <filesystem>ext3</filesystem>
      <mountPoint>/data</mountPoint>
      <mountOptions>defaults,noatime,nodiratime</mountOptions>
    </partition>

  </device>
</diskSetup>

```

If a `vendor` or a `requiredSize` element is specified, it is treated as an assertion which is checked by the node-installer. The node-installer reads the drive vendor string from `/sys/block/<drive name>/device/vendor`. For the assertion to succeed, the ratio of actual disk size to the value specified by `requiredSize`, should be at least 0.85:1, and at most 1:0.85.

That is: to be able to get past the `requiredSize` assertion, the actual drive size as seen from `fdisk -l` should be 85% to about 118% of the asserted size.

If any assertion fails, no partitioning changes will be made to any of the specified devices.

For assertions with drives that are similar or identical in size, and are from the same vendor, the `requiredSize` and `vendor` elements are not enough to differentiate between the drives. In such cases, custom assertions (section D.12) can be set for particular drives.

Specifying device assertions is recommended for nodes that contain important data because it protects against a situation where a drive is assigned to an incorrect block device. This can happen, for example, when the first drive, for example `/dev/sda`, in a multi-drive system is not detected (e.g. due to a hardware failure) which could cause the second drive to become known as `/dev/sda`, potentially causing much woe.

As an aside, `CMDaemon` does offer another way, outside of assertions, to avoid wiping out drive data automatically. This is done in `cmsh` by setting the value of `datanode` to `yes` (section 5.4.4).

## D.12 Example: Using Custom Assertions

The following example shows the use of the `assert` tag, which can be added to a device definition:

### Example

```

<?xml version="1.0" encoding="ISO-8859-1"?>

<diskSetup xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
  xsi:noNamespaceSchemaLocation="schema.xsd">

```

```

<device>
  <blockdev>/dev/sda</blockdev>
  <assert name="modelCheck" args="WD800AAJS">
    <![CDATA[
      #!/bin/bash
      if grep -q $1 /sys/block/$ASSERT_DEV/device/model; then
        exit 0
      else
        exit 1
      fi
    ]]>
  </assert>

  <partition id="a1">
    <size>max</size>
    <type>linux</type>
    <filesystem>ext3</filesystem>
    <mountPoint></mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </partition>

</device>
<device>
  <blockdev>/dev/sdb</blockdev>
  <vendor>BigRaid</vendor>
  <requiredSize>2T</requiredSize>

  <partition id="b1">
    <size>max</size>
    <type>linux</type>
    <filesystem>ext3</filesystem>
    <mountPoint>/data</mountPoint>
    <mountOptions>defaults,noatime,nodiratime</mountOptions>
  </partition>

</device>
</diskSetup>

```

The `assert` tag is similar to the `vendor` and `size` tags described in section D.11.

It can be used to define custom assertions. The assertions can be implemented using any script language.

The script can access the environment variables `ASSERT_DEV` (eg: `sda`) and `ASSERT_NODE` (eg: `/dev/sda`) during the node-installer stage.

Each `assert` needs to be assigned an arbitrary name and can be passed custom parameters. A non-zero exit code in the assertion causes the node-installer to halt.



# E

## Example `initialize` And `finalize` Scripts

The node-installer executes any `initialize` and `finalize` scripts at particular stages of its 13-step run during node-provisioning (section 5.4). They are sometimes useful for troubleshooting or workarounds during those stages. The scripts are stored in the CMDaemon database, rather than in the filesystem as plain text files, because they run before the node's `init` process takes over and establishes the final filesystem.

### E.1 When Are They Used?

They are sometimes used as an alternative configuration option out of a choice of other possible options (section 3.15.1). As a solution it can be a bit of a hack, but sometimes there is no reasonable alternative other than using an `initialize` or `finalize` script.

**An `initialize` script:** is used well before the `init` process starts, to execute custom commands before partitions and mounting devices are checked. Typically, `initialize` script commands are related to partitioning, mounting, or initializing special storage hardware. Often an `initialize` script is needed because the commands in it cannot be stored persistently anywhere else.

**A `finalize` script:** (also run before `init`, but shortly before `init` starts) is used to set a file configuration or to initialize special hardware, sometimes after a hardware check. It is run in order to make software or hardware work before, or during the later `init` stage of boot. Thus, often a `finalize` script is needed because its commands must be executed before `init`, and the commands cannot be stored persistently anywhere else, or it is needed because a choice between (otherwise non-persistent) configuration files must be made based on the hardware before `init` starts.

### E.2 Accessing From Bright View And `cmsh`

The `initialize` and `finalize` scripts are accessible for viewing and editing:

- In Bright View, via the `Node Categories` or `Nodes` window, under the `Settings` window. The clickpaths for these are:
  - `Grouping`→`Node categories[default]`→`Edit`→`Settings`
  - `Devices`→`Physical Nodes[node001]`→`Edit`→`Settings`
- In `cmsh`, using the `category` or `device` modes. The `get` command is used for viewing the script, and the `set` command to start up the default text editor to edit the script. Output is truncated in the two following examples at the point where the editor starts up:

**Example**

```
[root@bright80 ~]# cmsh
[bright80]% category use default
[bright80->category[default]]% show | grep script
Parameter                                Value
-----
Finalize script                          <1367 bytes>
Initialize script                        <0 bytes>
[bright80->category[default]]% set initializescript
```

**Example**

```
[bright80]% device use node001
[bright80->device[node001]]%
[bright80->device[node001]]% set finalizescript
```

**E.3 Environment Variables Available To initialize And finalize Scripts**

For the initialize and finalize scripts, node-specific customizations can be made from a script using environment variables. The following table shows the available variables with some example values:

Table E: Environment Variables For The initialize And Finalize Scripts

Variable	Example Value
CMD_ACTIVE_MASTER_IP	10.141.255.254
CMD_CATEGORY	default
CMD_CHASSIS	chassis01
CMD_CHASSIS_IP	10.141.1.1
CMD_CHASSIS_PASSWORD	ADMIN
CMD_CHASSIS_SLOT	1
CMD_CHASSIS_USERNAME	ADMIN
CMD_CLUSTERNAME	Bright 8.0 Cluster
CMD_DEVICE_HEIGHT	1
CMD_DEVICE_POSITION	10
CMD_DEVICE_TYPE	SlaveNode
CMD_ETHERNETSWITCH	switch01:1
CMD_FSEXPORT__SLASH_cm_SLASH_node-installer_ALLOWWRITE	no
CMD_FSEXPORT__SLASH_cm_SLASH_node-installer_HOSTS	10.141.0.0/16
CMD_FSEXPORT__SLASH_cm_SLASH_node-installer_PATH	/cm/node-installer
CMD_FSEXPORTS	_SLASH_cm_SLASH_node-installer
CMD_FSMOUNT__SLASH_cm_SLASH_shared_DEVICE	master:/cm/shared
CMD_FSMOUNT__SLASH_cm_SLASH_shared_FILESYSTEM	nfs
CMD_FSMOUNT__SLASH_cm_SLASH_shared_MOUNTPOINT	/cm/shared
CMD_FSMOUNT__SLASH_cm_SLASH_shared_OPTIONS	rsize=32768, wsize=32768, \
	hard, intr, async
CMD_FSMOUNT__SLASH_dev_SLASH_pts_DEVICE	none
CMD_FSMOUNT__SLASH_dev_SLASH_pts_FILESYSTEM	devpts
CMD_FSMOUNT__SLASH_dev_SLASH_pts_MOUNTPOINT	/dev/pts
CMD_FSMOUNT__SLASH_dev_SLASH_pts_OPTIONS	gid=5, mode=620
CMD_FSMOUNT__SLASH_dev_SLASH_shm_DEVICE	none
CMD_FSMOUNT__SLASH_dev_SLASH_shm_FILESYSTEM	tmpfs
CMD_FSMOUNT__SLASH_dev_SLASH_shm_MOUNTPOINT	/dev/shm

...continues

Table E: Environment Variables For The initialize And Finalize Scripts...continued

Variable	Example Value
CMD_FSMOUNT__SLASH_dev_SLASH_shm_OPTIONS	defaults
CMD_FSMOUNT__SLASH_home_DEVICE	master:/home
CMD_FSMOUNT__SLASH_home_FILESYSTEM	nfs
CMD_FSMOUNT__SLASH_home_MOUNTPOINT	home
CMD_FSMOUNT__SLASH_home_OPTIONS	rsize=32768, wsize=32768, \ hard, intr, async
CMD_FSMOUNT__SLASH_proc_DEVICE	none
CMD_FSMOUNT__SLASH_proc_FILESYSTEM	proc
CMD_FSMOUNT__SLASH_proc_MOUNTPOINT	/proc
CMD_FSMOUNT__SLASH_proc_OPTIONS	defaults, nosuid
CMD_FSMOUNT__SLASH_sys_DEVICE	none
CMD_FSMOUNT__SLASH_sys_FILESYSTEM	sysfs
CMD_FSMOUNT__SLASH_sys_MOUNTPOINT	/sys
CMD_FSMOUNT__SLASH_sys_OPTIONS	defaults
CMD_FSMOUNTS *	_SLASH_dev_SLASH_pts _SLASH_proc _SLASH_sys _SLASH_dev_SLASH_shm _SLASH_cm_SLASH_shared _SLASH_home
CMD_GATEWAY	10.141.255.254
CMD_HOSTNAME	node001
CMD_INSTALLMODE	AUTO
CMD_INTERFACE_eth0_IP **	10.141.0.1
CMD_INTERFACE_eth0_MTU **	1500
CMD_INTERFACE_eth0_NETMASK **	255.255.0.0
CMD_INTERFACE_eth0_TYPE **	physical
CMD_INTERFACES *	eth0 eth1 eth2 ipmi0
CMD_IP	10.141.0.1
CMD_MAC	00:00:00:00:00:01
CMD_PARTITION	base
CMD_PASSIVE_MASTER_IP	10.141.255.253
CMD_PDUS	
CMD_POWER_CONTROL	custom
CMD_RACK	rack01
CMD_RACK_HEIGHT	42
CMD_RACK_ROOM	serverroom
CMD_ROLES	sgeclient storage
CMD_SHARED_MASTER_IP	10.141.255.252
CMD_SOFTWAREIMAGE_PATH	/cm/images/default-image
CMD_SOFTWAREIMAGE	default-image
CMD_TAG	00000000a000
CMD_USERDEFINED1	var1
CMD_USERDEFINED2	var2

\* The value for this variable is a string with spaces, not an array. Eg:

CMD\_FSMOUNTS="\_SLASH\_dev\_SLASH\_pts\_SLASH\_proc\_SLASH\_sys\_SLASH\_dev\_SLASH\_shm ..."

\*\* The name of this variable varies according to the interfaces available. So,

eth0 can be replaced by eth1, eth2, ipmi0, and so on.



## E.4 Using Environment Variables Stored In Multiple Variables

Some data values, such as those related to interfaces (CMD\_INTERFACES\_\*), mount points (CMD\_FSMOUNT\_\_SLASH\_\*) and exports (CMD\_FSEXPORT\_\_SLASH\_cm\_\_SLASH\_node-installer\_\*) are stored in multiple variables. The following finalize script set for node001 shows how they can be used:

### Example

```
[head->device*[node001*]]% get finalizescript
#!/bin/bash
echo "These are the interfaces:" >> /localdisk/env
CMD_ENV=`env`
function parser {
    for s in TYPE IP NETMASK; do
        echo $((grep CMD_INTERFACE_${1/:/-}_${s} | grep -Po "[\w.]+${s}") <<< "${CMD_ENV[@]}")
    done
}
for interface in $CMD_INTERFACES
do
    read -r type ip mask <<< $(parser $interface)

    echo $interface type=$type >> /localdisk/env
    echo $interface ip=$ip >> /localdisk/env
    echo $interface netmask=$mask >> /localdisk/env
done
```

The technique of storage of values in a file under the path within the node of /localdisk/ is described later on in section E.5.2. When the node boots up and runs the finalize script, then files stored under /localdisk/, end up under the path of / after the node is fully up.

The detailed workings of the parser function in the preceding bash script are not easy, but the result is that the parser function returns output so that the interface type, IP address, and netmask are listed for each interface. The parser works for physical interfaces, VLAN interfaces, and alias interfaces. For example, if there are two interfaces, eth0 and eth0:1, then the file env might be seen to have the following data:

### Example

```
[root@head ~]# ssh node001 cat /env
These are the interfaces:
eth0 type=physical
eth0 ip=10.141.0.1
eth0 netmask=255.255.0.0
eth0:1 type=alias
eth0:1 ip=10.141.0.2
eth0:1 netmask=255.255.0.0
```

For remotely mounted devices, the name of the environment variables for mount entries have the following naming convention:

Description	Naming Convention
volume	CMD_FSMOUNT_<x>_DEVICE
mount point	CMD_FSMOUNT_<x>_MOUNTPOINT
filesystem type	CMD_FSMOUNT_<x>_FILESYSTEM
mount point options	CMD_FSMOUNT_<x>_OPTIONS

For the names, the entries `<x>` are substituted with the local mount point path, such as `"/cm/shared"`, but with the `"/` character replaced with the text `"_SLASH_"`. So, for a local mount point path `"/cm/shared"`, the name of the associated volume environment variable becomes `CMD_FSMOUNT__SLASH_cm_SLASH_shared_DEVICE`.

A similar naming convention is applicable to the names of the environment variables for the export entries:

Description	Naming Convention
exported system writable?	<code>CMD_FSEXPORT_&lt;y&gt;_ALLOWWRITE</code>
allowed hosts or networks	<code>CMD_FSEXPORT_&lt;y&gt;_HOSTS</code>
path on exporter	<code>CMD_FSMOUNT_&lt;y&gt;_PATH</code>

Here, the entry `<y>` is replaced by the file path to the exported filesystem on the exporting node. This is actually the same as the value of `"CMD_FSMOUNT_<y>_PATH"`, but with the `"/` character replaced with the text `"_SLASH_"`.

The entries for the local mount values and the export values in the table in section E.3 are the default values for a newly installed cluster. If the administrator wishes to add more devices and mount entries, this is done by configuring `fsexports` on the head node, and `fsmounts` on the regular nodes, using Bright View or `cmsh` (section 3.10).

## E.5 Storing A Configuration To A Filesystem

### E.5.1 Storing With Initialize Scripts

The `initialize` script (section 5.4.5) runs after the install-mode type and execution have been determined (section 5.4.4), but before unloading specific drivers and before partitions are checked and filesystems mounted (section 5.4.6). Data output cannot therefore be written to a local drive. It can however be written by the script to the `tmpfs`, but data placed there is lost quite soon, namely during the `pivot_root` process that runs when the node-installer hands over control to the `init` process running from the local drive. However, if needed, the data can be placed on the local drive later by using the `finalize` script to copy it over from the `tmpfs`.

Due to this, and other reasons, a `finalize` script is easier to use for an administrator than an `initialize` script, and the use of the `finalize` script is therefore preferred.

### E.5.2 Ways Of Writing A Finalize Script To Configure The Destination Nodes

#### Basic Example—Copying A File To The Image

For a `finalize` script (section 5.4.11), which runs just before switching from using the `ramdrive` to using the local hard drive, the local hard drive is mounted under `/localdisk`. Data can therefore be written to the local hard drive if needed, but is only persistent until a reboot, when it gets rewritten. For example, predetermined configuration files can be written from the NFS drive for a particular node, or they can be written from an image prepared earlier and now running on the node at this stage, overwriting a node-installer configuration:

#### Example

```
#!/bin/bash
cp /etc/myapp.conf.overwrite /localdisk/etc/myapp.conf
```

This technique is used in a `finalize` script example in section 3.15.4, except that an append operation is used instead of a copy operation, to overcome a network issue by modifying a network configuration file slightly.

There are two important considerations for most `finalize` scripts:

#### 1. Running A Finalize Script Without `exit 0` Considered Harmful

**Failed Finalize Script Logic Flow:** For a default configuration without a finalize script, if PXE boot fails from the network during node provisioning, the node then goes on to attempt booting from the local drive via iPXE (section 5.1.2).

However, if the configuration has a finalize script, such as in the preceding example, and if the finalize script fails, then the failure is passed to the node installer.

**Avoiding Remote Node Hang During A Finalize Script:** `exit 0` **Recommended:** If the node-installer fails, then no attempt is made to continue booting, and the node remains hung at that stage. This is usually undesirable, and can also make remote debugging of a finalize script annoying.

Adding an `exit 0` to the end of the finalize script is therefore recommended, and means that an error in the script will still allow the node-installer to continue with an attempt to boot from the local drive.

**Debugging Tips When A Node Hangs During A Finalize Script:** If there is a need to understand the failure, then if the node-installer hangs, the administrator can ssh into the node into the node-installer environment, and run the finalize script manually to debug it. Once the bug has been understood, the script can be copied over to the appropriate location in the head node, for nodes or categories.

Additional aid in understanding a failure may be available by looking through the node-installer logs. The debug mode for the node-installer can be enabled by setting `debug=true` instead of `debug=false` in the file `/cm/node-installer/scripts/node-installer.conf`.

## 2. Protecting A Configuration File Change From Provisioning Erasure With `excludelistupdate`

In the preceding example, the finalize script saves a file `/etc/myapp.conf` to the destination nodes.

To protect such a configuration file from erasure, its file path must be covered in the second sublist in the `excludelistupdate` list (section 5.6.1).

### Copying A File To The Image—Decision Based On Detection

Detection within a basic `finalize` script is useful extra technique. The `finalize` script example of section 3.15.4 does detection too, to decide if a configuration change is to be done on the node or not.

A further variation on a `finalize` script with detection is a script selecting from a choice of possible configurations. A symlink is set to one of the possible configurations based on hardware detection or detection of an environment variable. The environment variable can be a node parameter or similar, from the table in section E.3. If it is necessary to overwrite different nodes with different configurations, then the previous `finalize` script example might become something like:

#### Example

```
#!/bin/bash
if [[ $CMD_HOSTNAME = node00[1-7] ]]
then ln -s /etc/myapp.conf.first /localdisk/etc/myapp.conf
fi
if [[ $CMD_HOSTNAME = node01[5-8] ]]
then ln -s /etc/myapp.conf.second /localdisk/etc/myapp.conf
fi
if [[ $CMD_HOSTNAME = node02[3-6] ]]
then ln -s /etc/myapp.conf.third /localdisk/etc/myapp.conf
fi
```

In the preceding example, the configuration file in the image has several versions: `/etc/myapp.conf.<first|second|third>`. Nodes `node001` to `node007` are configured with the first version, nodes `node015` to `node018` with the second version, and nodes `node023` to `node026` with the third version. It is convenient to add more versions to the structure of this decision mechanism.

### Copying A File To The Image—With Environmental Variables Evaluated In The File

Sometimes there can be a need to use the CMDaemon environmental variables within a finalize script to specify a configuration change that depends on the environment.

For example a special service may need a configuration file, `test`, that requires the hostname `myhost`, as a `parameter=value` pair:

#### Example

```
SPECIALSERVICEPARAMETER=myhost
```

Ideally the placeholder value `myhost` would be the hostname of the node rather than the fixed value `myhost`. Conveniently, the CMDaemon environmental variable `CMD_HOSTNAME` has the name of the host as its value.

So, inside the configuration file, after the administrator changes the host name from its placeholder name to the environmental variable:

```
SPECIALSERVICE=${CMD_HOSTNAME}
```

then when the node-installer runs the finalize script, the file could be modified in-place by the finalize script, and `${CMD_HOSTNAME}` be substituted by the actual hostname.

A suitable finalize Bash script, which runs an in-line Perl substitution, is the following:

```
#!/bin/bash
perl -p -i -e 's/\$\{([^\}]+\)\}/defined $ENV{$1} ? $ENV{$1} : $&/eg' /localdisk/some/directory/file
```

Here, `/some/directory/file` means that, if for example the final configuration file path for the node is to be `/var/spool/test` then the file name should be set to `/localdisk/var/spool/test` inside the finalize script.

The finalize script replaces all lines within the file that have environmental variable names of the form:

```
PARAMETER=${<environmental variable name>}
```

with the value of that environment variable. Thus, if `<environmental variable name>` is `CMD_HOSTNAME`, then that variable is replaced by the name of the host.

### E.5.3 Restricting The Script To Nodes Or Node Categories

As mentioned in section 2.1.3, node settings can be adjusted within a category. So the configuration changes to `ifcfg-eth0` is best implemented per node by accessing and adjusting the finalize script per node if only a few nodes in the category are to be set up like this. If all the nodes in a category are to be set up like this, then the changes are best implemented in a finalize script accessed and adjusted at the category level. Accessing the scripts at the node and category levels is covered in section E.2.

People used to normal object inheritance behavior should be aware of the following when considering category level and node level finalize scripts:

With objects, a node item value overrules a category level value. On the other hand, finalize scripts, while treated in an analogous way to objects, cannot always inherit properties from each other in the precise way that true objects can. Thus, it is possible that a finalize script run at the node level may not have anything to do with what is changed by running it at the category level. However, to allow it to resemble the inheritance behavior of object properties a bit, the node-level finalize script, if it exists, is always run after the category-level script. This gives it the ability to “overrule” the category level.

# F

## Workload Managers Quick Reference

### F.1 Slurm

Slurm is a GPL-licensed workload management system and developed largely at Lawrence Livermore National Laboratory. The name was originally an acronym for Simple Linux Utility for Resource Management, but the acronym is deprecated because it no longer does justice to the advanced capabilities of Slurm.

The Slurm service and outputs are normally handled using the Bright View or `cmsh` front end tools for CMDaemon (section 7.4).

From the command line, direct Slurm commands that may sometimes come in useful include the following:

- `sacct`: used to report job or job step accounting information about active or completed jobs.

#### Example

```
# sacct -j 43 -o jobid,AllocCPUS,NCPUS,NNodes,NTasks,ReqCPUS
      JobID  AllocCPUS      NCPUS      NNodes      NTasks      ReqCPUS
-----
43              1          1          1          1          1
```

- `salloc`: used to allocate resources for a job in real time. Typically this is used to allocate resources and spawn a shell. The shell is then used to execute `srun` commands to launch parallel tasks.
- `sattach` used to attach standard input, output, and error plus signal capabilities to a currently running job or job step. One can attach to and detach from jobs multiple times.
- `sbatch`: used to submit a job script for later execution. The script typically contains one or more `srun` commands to launch parallel tasks.
- `sbcast`: used to transfer a file from local disk to local disk on the nodes allocated to a job. This can be used to effectively use diskless compute nodes or provide improved performance relative to a shared filesystem.
- `scancel`: used to cancel a pending or running job or job step. It can also be used to send an arbitrary signal to all processes associated with a running job or job step.
- `scontrol`: the administrative tool used to view and/or modify Slurm state. Note that many `scontrol` commands can only be executed as user root.

#### Example

```
[fred@bright80 ~]$ scontrol show nodes
NodeName=bright80 Arch=x86_64 CoresPerSocket=1
  CPUAlloc=0 CPUErr=0 CPUTot=1 CPULoad=0.05 Features=(null)
...
```

- **sinfo**: reports the state of partitions and nodes managed by Slurm. It has a wide variety of filtering, sorting, and formatting options.

#### Example

```
bright80:~ # sinfo -o "%9P %.5a %.10l %.6D %.6t %C %N"
PARTITION AVAIL  TIMELIMIT  NODES  STATE CPUS(A/I/O/T) NODELIST
defq*      up    infinite      1  alloc 1/0/0/1 bright80
```

- **smap**: reports state information for jobs, partitions, and nodes managed by Slurm, but graphically displays the information to reflect network topology.
- **squeue**: reports the state of jobs or job steps. It has a wide variety of filtering, sorting, and formatting options. By default, it reports the running jobs in priority order and then the pending jobs in priority order.

#### Example

```
bright80:~ # squeue -o "%.18i %.9P %.8j %.8u %.2t %.10M %.6D %C %R"
JOBID PARTITION  NAME  USER ST   TIME  NODES CPUS NODELIST(REASON)
   43      defq  bash  fred  R  16:22      1  1 bright80
...
```

- **srund**: used to submit a job for execution or initiate job steps in real time. **srund** has a wide variety of options to specify resource requirements, including: minimum and maximum node count, processor count, specific nodes to use or not use, and specific node characteristics (so much memory, disk space, certain required features, etc.). A job can contain multiple job steps executing sequentially or in parallel on independent or shared nodes within the job's node allocation.
- **smap**: reports state information for jobs, partitions, and nodes managed by Slurm, but graphically displays the information to reflect network topology.
- **strigger**: used to set, get or view event triggers. Event triggers include things such as nodes going down or jobs approaching their time limit.
- **sview**: a graphical user interface to get and update state information for jobs, partitions, and nodes managed by Slurm.

There are man pages for these commands. Full documentation on Slurm is available online at: <http://slurm.schedmd.com/documentation.html>.

## F.2 Sun Grid Engine

Sun Grid Engine (SGE) is a workload management system that was originally made available under an Open Source license by Sun Microsystems. It forked off into various versions in 2010 and its future is unclear at the time of writing, but it remains in widespread use. Bright Cluster Manager 8.0 uses version 6.2 update 5 patch 2 of Grid Scheduler, which is a bugfix-patched version of the last SGE release from Sun Microsystems, and is made available on sourceforge at <http://gridscheduler.sourceforge.net/>.

SGE services should be handled using CMDaemon, as explained in section 7.4. However SGE can break in obtuse ways when implementing changes, so the following notes are sometimes useful in getting a system going again:

- The `sge_qmaster` daemon on the head node can be started or stopped using `/etc/init.d/sgemaster.sge1 start|stop`, or alternatively via `qconf -{s|k}m`.
- The `sge_execd` execution daemon running on each compute node accepts, manages, and returns the results of the jobs on the compute nodes. The daemon can be started or stopped via `/etc/init.d/sgeexecd start|stop`, or alternatively deregistered from `qmaster` via `qconf -{s|k}s`.
- To see why a queue is in an error state, `qstat -explain E` shows the reason. Queues in an error state can be cleared with a `qmod -c <queue name>`.

SGE can be configured and managed generally with the command line utility `qconf`, which is what most administrators become familiar with. A GUI alternative, `qmon`, is also provided.

SGE commands are listed below. The details of these are in the `man` page of the command and the SGE documentation.

- `qalter`: modify existing batch jobs
- `qacct`: show usage information from accounting data
- `qconf`: configure SGE
- `qdel`: delete batch jobs
- `qhold`: place hold on batch jobs
- `qhost`: display compute node queues, states, jobs
- `qlogin`: start login-based interactive session with a node
- `qmake`: distributed, parallel make utility
- `qmod`: suspend/enable queues and jobs
- `qmon`: configure SGE with an X11 GUI interface
- `qping`: check `sge_qmaster` and `sge_execd` status
- `qquota`: list resource quotas
- `qresub`: create new jobs by copying existing jobs
- `qrdel`: cancel advance reservations
- `qrls`: release batch jobs from a held state
- `qrsh`: start `rsh`-based interactive session with node
- `qrstat`: show status of advance reservations
- `qsub`: submit advanced reservation
- `qselect`: select queues based on argument values
- `qsh`: start `sh` interactive session with a node
- `qstat`: show status of batch jobs and queues
- `qsub`: submit new jobs (related: `qalter`, `qresub`)
- `qtcssh`: start `csh`-based interactive session with a node

### F.3 Torque

The following commands can be used to manage Torque:

**Torque resource manager commands:**

- `qalter`: alter batch job
- `qdel`: delete batch job
- `qhold`: hold batch jobs
- `qrls`: release hold on batch jobs
- `qstat`: show status of batch jobs
- `qsub`: submit job
- `qmgr`: batch policies and configurations manager
- `qenable`: enable input to a destination
- `qdisable`: disable input to a destination
- `tracejob`: trace job actions and states

These direct commands are capable of modifying properties that CMDaemon does not manage, as well as properties that CMDaemon does manage. CMDaemon however overwrites the properties that are managed by CMDaemon with values recalled from the CMDaemon database, typically within a few minutes, if the values are changed directly via the direct commands.

Further information on these and other commands is available in the appropriate man pages and on-line documentation at <http://www.adaptivecomputing.com/resources/docs/>. The Torque administrator manual is also available from there.

### F.4 PBS Pro

The following commands can be used in PBS Pro to view queues:

```
qstat          query queue status
qstat -a       alternate form
qstat -r       show only running jobs
qstat -q       show available queues
qstat -rn      only running jobs, w/ list of allocated nodes
qstat -i       only idle jobs
qstat -u username show jobs for named user
```

Other useful commands are:

```
tracejob id      show what happened today to job id
tracejob -n d id search last d days

qmgr             administrator interface to batch system

qterm           terminates queues (but cm starts pbs_server again)

pbsnodes -a      list available worker nodes in queue
```

The commands of PBS Pro are documented in the *PBS Professional 11.0 Reference Guide*. There is further extensive documentation for PBS Pro administrators in the *PBS Professional 11.0 Administrator's Guide*. Both of these guides are available at the PBS Works website at <http://www.pbsworks.com/SupportDocuments.aspx>.



## F.5 OpenLava

OpenLava is a free, GNU GPLv2 licensed workload management system based on Platform LSF. The OpenLava source is available on github at <https://github.com/openlava/openlava/>.

OpenLava is a fork of Platform Lava, released under GNU GPLv2. This in turn is based on a stripped-down version of Platform LSF 4.2. *Versions beyond 2.2 are at the time of writing (November 2016) subject to an IBM copyright infringement claim. On request of the OpenLava founder, the packages beyond version 2.2 are not redistributed.*

OpenLava services and outputs are normally handled using the Bright View or `cmsh` front end tools for CMDaemon (section 7.4).

From the command line, direct OpenLava commands that may sometimes come in useful include the following:

- **badmin:** the administrative tool used to control and monitor OpenLava. It provides the following commands: `ckconfig`, `reconfig`, `mbdrestart`, `qopen`, `qclose`, `qact`, `qinact`, `hopen`, `hclose`, `hrestart`, `hshutdown`, `hstartup`, `hhist`, `mbdhist`, `hist`, `sbdtime`, `mbdtime` and `mbddebug`.
- **bjobs:** displays information about OpenLava jobs.
- **brun:** used to force a pending OpenLava job to run immediately on specified hosts.
- **bbot:** used to change the queue position of a pending OpenLava job, or a pending job array element, to affect the order in which jobs are considered for dispatch.
- **bchkpnt:** used to checkpoint one or more checkpointable OpenLava jobs.
- **bhosts:** displays information about static and dynamic resources of hosts.
- **bkill:** sends signals to kill, suspend, or resume unfinished openlava jobs.
- **bmgroup:** displays information about host OpenLava groups.
- **bmig:** used to migrate checkpointable or rerunnable OpenLava jobs.
- **bmod:** used to modify job submission options of an OpenLava job.
- **bparams:** displays information about configurable system parameters in `lsb.params`.
- **bpeek:** displays the stdout and stderr output of an unfinished OpenLava job.
- **bqueues:** displays information about OpenLava queues.
- **brequeue:** used to kill and requeue an OpenLava job.
- **brestart:** used to restart checkpointed OpenLava jobs.
- **bresume:** used to resume one or more suspended OpenLava jobs.
- **bstop:** used to suspend unfinished OpenLava jobs.
- **bsub:** used to submit a batch job to OpenLava.
- **bswitch:** used to switch unfinished OpenLava jobs from one queue to another.
- **btopy:** used to move a pending OpenLava job relative to the first job in the queue.
- **bugroup:** displays information about user groups.
- **busers:** displays information about users and user groups.

- `lshosts`: displays information about resources defined on hosts.
- `lsload`: displays the current state of the host about its ability to run batch jobs and remote tasks.
- `lsinfo`: displays information about load indices.
- `lsid`: displays the current OpenLava version number, the cluster name, and the active OpenLava master node name.
- `lsmon`: displays load information for OpenLava hosts.
- `lsplace`: displays hosts available to execute OpenLava jobs.
- `lsrccp`: used to copy files remotely using OpenLava.

Full documentation on OpenLava is available online at: <http://openlava.org/documentation/documentation.html>.

# G

## Metrics, Health Checks, Enummetrics, And Actions

This appendix describes the metrics (section G.1), health checks (section G.2), enummetrics (section 12.2.2), and actions (section G.3), along with their parameters, in a newly-installed cluster. Metrics, health checks, enummetrics, and actions can each be standalone scripts, or they can be built-ins. Standalone scripts can be those supplied with the system, or they can be custom scripts built by the administrator. Scripts often require environment variables, as described in section 3.3.1 of the *Developer Manual*. On success scripts must exit with a status of 0, as is the normal practice.

### G.1 Metrics And Their Parameters

A list of metric names can be viewed, for example, for the head node, using `cmsh` as follows (section 12.5.3):

```
[bright80 ~]# cmsh -c "monitoring measurable; list metric"
```

Metrics are listed in this section as three types: regular metrics (section G.1.1), NFS metrics (section G.1.2), and monitoring system metrics (section G.1.3).

#### G.1.1 Regular Metrics

Table G.1.1: List Of Metrics

Metric	Description
AlertLevel	Indicates the healthiness of a device based on severity of events (section 12.2.8). The lower it is, the better. There are 3 parameters it can take: <ul style="list-style-type: none"><li>count: the number of active triggers</li><li>maximum: the maximum alert level of all active triggers</li><li>sum: the average alert level of all active triggers</li></ul>

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
AvgJobDuration	Average Job Duration of current jobs
BlockedProcesses	Blocked processes waiting for I/O
BufferMemory	System memory used for buffering
BytesRecv*	Bytes/s received <sup>‡</sup>
BytesSent*	Bytes/s sent <sup>‡</sup>
CPUGuest	CPU time spent in guest mode.
CPUIdle	CPU time spent in idle mode.
CPUIrq	CPU time spent in servicing IRQ.
CPUNice	CPU time spent in nice mode.
CPUSoftIrq	CPU time spent in servicing soft IRQ.
CPUSteal	CPU time spent in steal mode.
CPUSystem	CPU time spent in system mode.
CPUUser	CPU time spent in user mode.
CPUWait	CPU time spent in I/O wait mode.
CacheMemory	System memory used for caching.
CompletedJobs	Successfully completed jobs
CoresTotal	Total number of known cores for all nodes
CoresUp	Number of cores for all nodes marked as UP
CtxtSwitches*	Context switches/s
Current_1**	First current seen by BMC sensor, in amps (file: sample_ipmi)
Current_2**	Second current seen by BMC sensor, in amps (file: sample_ipmi)
DevicesClosed	Number of devices not marked as UP or DOWN
DevicesDown	Number of devices marked as DOWN
DevicesTotal	Total number of devices
DevicesUp	Number of devices in status UP. A node (head, regular, virtual, cloud, VSMP) or GPU Unit is not classed as a device. A device can be an item such as a switch, PDU, chassis, or rack, if the item is enabled and configured for management.
DropRecv*	Packets/s received and dropped <sup>‡</sup>
DropSent*	Packets/s sent and dropped <sup>‡</sup>
EccDBitGPU**	Total number of double bit ECC errors (file: sample_gpu)
EccSBitGPU**	Total number of single bit ECC errors (file: sample_gpu)
ErrorsRecv*	Packets/s received with error <sup>‡</sup>
ErrorsSent*	Packets/s sent with error <sup>‡</sup>
EstimatedDelay	Estimated delay time to execute jobs
FailedJobs	Failed completed jobs
Forks*	Forked processes/s
FrameErrors*	Packet framing errors/s <sup>‡</sup>
FreeSpace	Free space for non-root. Takes mount point as a parameter
GPUUnitsClosed	Number of GPU units not marked as UP or DOWN
GPUUnitsDown	Number of GPU units marked as DOWN
GPUUnitsTotal	Total number of GPU Units
GPUUnitsUp	Number of GPU units marked as UP

Table G.1.1: List Of Metrics...continued

Name	Description
HardwareCorruptedMemory	Hardware corrupted memory detected by ECC
IOInProgress	I/O operations in progress <sup>†</sup>
IOTime	I/O operations time in milliseconds/s <sup>†</sup>
Interrupts	System interrupts
IpForwDatagrams*	Input IP datagrams/s to be forwarded
IpFragCreates*	IP datagram fragments/s generated
IpFragFails*	IP datagrams/s which needed to be fragmented but could not
IpFragOKs*	IP datagrams/s successfully fragmented
IpInAddrErrors*	Input datagrams/s discarded because the IP address in their header was not a valid address
IpInDelivers*	Input IP datagrams/s successfully delivered
IpInDiscards*	Input IP datagrams/s discarded
IpInHdrErrors*	Input IP datagrams/s discarded due to errors in their IP headers
IpInReceives*	Input IP datagrams/s, including ones with errors, received from all interfaces
IpInUnknownProtos*	Input IP datagrams/s received but discarded due to an unknown or unsupported protocol
IpOutDiscards*	Output IP datagrams/s discarded
IpOutNoRoutes*	Output IP datagrams/s discarded because no route could be found
IpOutRequests*	Output IP datagrams/s supplied to IP in requests for transmission
IpReasmOKs*	IP datagrams/s successfully re-assembled
IpReasmReqds*	IP fragments/s received needing re-assembly
LoadFifteen	Load average on 15 minutes
LoadFive	Load average on 5 minutes
LoadOne	Load average on 1 minute
MICsClosed	Number of MICs not marked as UP or DOWN
MICsDown	Number of MICs marked as DOWN
MICsTotal	Total number of MICs
MICsUp	Number of MICs marked as UP
MajorPageFaults*	Page faults/s that require I/O
MemoryAvailable	Available system memory
MemoryFree	Free system memory
MemoryTotal	Total system memory
MemoryUsed	Used system memory
MemoryUsed:cmd	Used system memory for process cmd
MergedReads*	Merged reads/s <sup>†</sup>
MergedWrites*	Merged writes/s <sup>†</sup>
mic	MIC metrics collection (file: sample_mic)
NodesClosed	Number of nodes not marked as UP or DOWN
NodesDown	Number of nodes marked as DOWN
NodesInQueue	Number of nodes in the queue
NodesTotal	Total number of nodes
NodesUp	Number of nodes in status UP

Table G.1.1: List Of Metrics...continued

Name	Description
OccupationRate	<p>Cluster occupation rate—a normalized cluster load percentage. 100% means all cores on all nodes are fully loaded.</p> <p>The calculation is done as follows: LoadOne on each node is mapped to a value, calibrated so that LoadOne=1 corresponds to 100% per node. The maximum allowed for a node in the mapping is 100%. The average of these mappings taken over all nodes is the OccupationRate.</p> <p>A high value can indicate the cluster is being used optimally. However, a value that is 100% most of the time suggests the cluster may need to be expanded.</p>
PacketsRecv*	Packets/s received <sup>†</sup>
PacketsSent*	Packets/s sent <sup>†</sup>
PageFaults*	Page faults/s
PageIn	Number of bytes the system has paged in from disk
PageOut	Number of bytes the system has paged out to disk
PageSwapIn	Number of bytes the system has swapped in from disk
PageSwapOut	Number of bytes the system has swapped out to disk
ProcessCount	Total number of all processes running in the OS
QueuedJobs	Queued jobs
ReadTime*	Read time in milliseconds/s <sup>†</sup>
Reads*	Reads/s completed successfully <sup>†</sup>
RunningJobs	Running jobs
RunningProcesses	Running processes
SMARTHDATemp	Temperature of a Hard Disk Assembly <sup>†</sup>
SMARTReallocSecCnt	SMART reallocated sectors count <sup>†</sup>
SMARTSeekErrRate	SMART seek errors/s <sup>†</sup>
SMARTSeekTimePerf	SMART average seek time <sup>†</sup>
SMARTSoftReadErrRate	SMART software read errors/s <sup>†</sup>
SectorsRead*	Sectors/s read successfully/s <sup>†</sup>
SectorsWritten*	Sectors/s written successfully <sup>†</sup>
SwapFree	Free swap memory
SwapTotal	Total swap memory
SwapUsed	Used swap memory
SystemTime:cmd	System time used by CMDaemon
TcpCurrEstab	TCP connections that are either ESTABLISHED or CLOSE-WAIT
TcpInErrs*	Input IP segments/s received in error
TcpRetransSegs*	Total number of IP segments/s re-transmitted
ThreadsUsed:cmd	Threads used by CMDaemon
TotalCPUIdle	Cluster-wide core usage in idle tasks (sum of all CPUIdle metric percentages)
TotalCPUSystem	Cluster-wide core usage in system mode (sum of all CPUSystem metric percentages)
TotalCPUUser	Cluster-wide core usage in user mode (sum of all CPUUser metric percentages)

Table G.1.1: List Of Metrics...continued

Name	Description
TotalMemoryFree	Cluster-wide total of memory free
TotalMemoryUsed	Cluster-wide total of memory used
TotalSwapFree	Cluster-wide total swap free
TotalSwapUsed	Cluster-wide total swap used
TotalUser	Total number of known users
TotalUserLogin	Total number of logged in users
UdpInDatagrams*	Input UDP datagrams/s delivered to UDP users
UdpInErrors*	Input UDP datagrams/s received that could not be delivered/s for other reasons (no port excl.)
UdpNoPorts*	Received UDP datagrams/s for which there was no application at the destination port
UniqueUserLogin	Number of unique users logged in
Uptime*	System uptime per second. Ie, ideally=1, but in practice has jitter effects
UsedSpace	Total used space by a mount point. Takes mount point as a parameter.
UserTime:cmd	User time used by CMDaemon
VirtualMemoryUsed:cmd	Virtual memory used by CMDaemon
WriteTime*	Write time in milliseconds/s <sup>†</sup>
Writes*	Writes/s completed successfully <sup>†</sup>
blkio.io_service_async	Bytes transferred to or from specified device as seen by the CFQ scheduler <sup>†</sup>
blkio.io_service_read	Bytes transferred to or from specified device as seen by the CFQ scheduler <sup>†</sup>
blkio.io_service_sync	Bytes transferred to or from specified device as seen by the CFQ scheduler <sup>†</sup>
blkio.io_service_write	Bytes transferred to or from specified device as seen by the CFQ scheduler <sup>†</sup>
blkio.io_wait_time_async	Total time I/O operations on specified device by a cgroup spent waiting for service in the scheduler queues <sup>†</sup>
blkio.io_wait_time_read	Total time I/O operations on specified device by a cgroup spent waiting for service in the scheduler queues <sup>†</sup>
blkio.io_wait_time_sync	Total time I/O operations on specified device by a cgroup spent waiting for service in the scheduler queues <sup>†</sup>
blkio.io_wait_time_write	Total time I/O operations on specified device by a cgroup spent waiting for service in the scheduler queues <sup>†</sup>
blkio.sectors	Number of sectors transferred to or from specified device <sup>†</sup>
blkio.time	Time that processes had I/O access to specified device <sup>†</sup>
cpuacct.stat.system	System CPU time consumed by processes
cpuacct.stat.user	User CPU time consumed by processes
cpuacct.usage	Total CPU time consumed by processes
memory.cache	Page cache, including tmpfs (shmem)
memory.failcnt	Number of times that the memory limit has reached the value set in memory.limit_in_bytes
memory.mapped_file	Size of memory-mapped mapped files, including tmpfs
memory.swap_incnt	Number of times that the memory plus swap space limit has reached the value set in memory.memsw.limit_in_bytes

...continues

Table G.1.1: List Of Metrics...continued

Name	Description
<code>memory.memsw.max_usage</code>	Maximum amount of memory and swap space used by processes
<code>memory.memsw.usage</code>	Sum of current memory usage plus swap space used by processes
<code>memory.swap</code>	Swap usage
<code>memory.unevictable</code>	Memory that cannot be reclaimed
<code>memory.usage</code>	Total current memory usage by processes

\* Cumulative metric. I.e. the metric is derived from cumulative raw measurements taken at two different times, according to:

$$metric_{time_2} = \frac{measurement_2 - measurement_1}{time_2 - time_1}$$

\*\* Standalone scripts, not built-ins.

If sampling from a head node, the script is in directory: `/cm/local/apps/cmd/scripts/metrics/`

For regular nodes, the script is in directory: `/cm/images/default-image/cm/local/apps/cmd/scripts/metrics/`

† Takes block device name (`sda`, `sdc` and so on) as parameter

‡ Takes interface device name (`eth0`, `eth1` and so on) as parameter

### G.1.2 NFS Metrics

The NFS metrics correspond to `nfsstat` output, and are shown in table G.1.2.



Table G.1.2: NFS Metrics

NFS Metric	Description
nfs_client_packet_packets	NFS client packets statistics: packets
nfs_client_packet_tcp	NFS client package statistics: TCP/IP packets
nfs_client_packet_tcpconn	NFS client package statistics: TCP/IP connections
nfs_client_packet_udp	NFS client package statistics: UDP packets
nfs_client_rpc_authrefrsh	NFS Client RPC statistics: authenticated refreshes to RPC server
nfs_client_rpc_calls	NFS Client RPC statistics: calls
nfs_client_rpc_retrans	NFS Client RPC statistics: re-transmissions
nfs_server_file_anon	NFS Server file statistics: anonymous access
nfs_server_file_lookup	NFS Server file statistics: look-ups
nfs_server_file_ncachedir	NFS Server file statistics: ncachedir
nfs_server_file_stale	NFS Server file statistics: stale files
nfs_server_packet_packets	NFS Server packet statistics: packets
nfs_server_packet_tcp	NFS Server packet statistics: TCP/IP packets
nfs_server_packet_tcpconn	NFS Server packet statistics: TCP/IP connections
nfs_server_packet_udp	NFS Server packet statistics: UDP packets
nfs_server_reply_hits	NFS Server reply statistics: hits
nfs_server_reply_misses	NFS Server reply statistics: misses
nfs_server_reply_nocache	NFS Server reply statistics: no cache
nfs_server_rpc_badauth	NFS Server RPC statistics: bad authentication
nfs_server_rpc_badcalls	NFS Server RPC statistics: bad RPC requests
nfs_server_rpc_badclnt	NFS Server RPC statistics: badclnt
nfs_server_rpc_calls	NFS Server RPC statistics: all calls to NFS and NLM
nfs_server_rpc_xdrcll	NFS Server RPC statistics: malformed XDR calls
nfs_v3_client_access	NFSv3 client statistics: access
nfs_v3_client_fsinfo	NFSv3 client statistics: static file system information

...continues

Table G.1.2: NFS Metrics

NFS Metric	Description
nfs_v3_client_fsstat	NFSv3 client statistics: dynamic file system status
nfs_v3_client_getattr	NFSv3 client statistics: file system attributes
nfs_v3_client_lookup	NFSv3 client statistics: lookup
nfs_v3_client_pathconf	NFSv3 client statistics: configuration path
nfs_v3_client_read	NFSv3 client statistics: reads
nfs_v3_client_total	NFSv3 client statistics: total
nfs_v3_server_access	NFSv3 server statistics: access
nfs_v3_server_create	NFSv3 server statistics: create
nfs_v3_server_fsinfo	NFSv3 server statistics: static file system information
nfs_v3_server_fsstat	NFSv3 server statistics: dynamic file system information
nfs_v3_server_getattr	NFSv3 server statistics: file system attributes gets
nfs_v3_server_lookup	NFSv3 server statistics: file name look-ups
nfs_v3_server_mkdir	NFSv3 server statistics: directory creation
nfs_v3_server_null	NFSv3 server statistics: null operations
nfs_v3_server_pathconf	NFSv3 server statistics: retrieve POSIX information
nfs_v3_server_read	NFSv3 server statistics: reads
nfs_v3_server_readdirplus	NFSv3 server statistics: REaddirPLUS procedures
nfs_v3_server_readlink	NFSv3 server statistics: Symbolic link reads
nfs_v3_server_setattr	NFSv3 server statistics: file system attribute sets
nfs_v3_server_total	NFSv3 server statistics: total
nfs_v3_server_write	NFSv3 server statistics: writes

### G.1.3 Monitoring System Metrics

The monitoring system metrics correspond to metrics for the monitoring data storage itself. These are shown in table G.1.3.

Table G.1.3: Monitoring System Metrics

Monitoring System Metric	Description
Mon::CacheGather::handled	Cache gathers handled/s
Mon::CacheGather::miss	Cache gathers missed/s
Mon::DataProcessor::handled	Data processors handled/s
Mon::DataProcessor::miss	Data processors missed /s
Mon::DataTranslator::handled	Data translators handled/s
Mon::DataTranslator::miss	Data translators missed/s
Mon::EntityMeasurableCache::handled	Measurable cache handled/s
Mon::EntityMeasurableCache::miss	Measurable cache missed/s

...continues

Table G.1.3: Monitoring System Metrics...continued

Monitoring System Metric	Description
Mon::MeasurableBroker::handled	Measurable broker handled/s
Mon::MeasurableBroker::miss	Measurable broker missed/s
Mon::Replicate::Collector::handled	Replication collection handled/s
Mon::Replicate::Collector::miss	Replication collection missed/s
Mon::Replicate::Combiner::handled	Replication combiner handled/s
Mon::Replicate::Combiner::miss	Replication combiner missed/s
Mon::RepositoryAllocator::handled	Repository allocator handled/s
Mon::RepositoryAllocator::miss	Repository allocator missed/s
Mon::RepositoryTrim::handled	Repository trim handled/s
Mon::RepositoryTrim::miss	Repository trim missed/s
Mon::Storage::Engine::elements	Storage engine data elements, in total
Mon::Storage::Engine::size	Storage engine size, in bytes
Mon::Storage::Engine::usage	Storage engine usage
Mon::Storage::Message::elements	Storage message data elements, in total
Mon::Storage::Message::size	Storage message size in bytes
Mon::Storage::Message::usage	Storage message usage
Mon::Storage::RepositoryId::elements	Storage repository ID data elements, in total
Mon::Storage::RepositoryId::size	Storage repository ID, size, in bytes
Mon::Storage::RepositoryId::usage	Repository ID usage
Mon::TaskInitializer::handled	Task initializer handled/s
Mon::TaskInitializer::miss	Task initializer missed/s
Mon::TaskSampler::handled	Task sampler handled/s
Mon::TaskSampler::miss	Task sampler missed/s
Mon::Trigger::Actuator::handled	Trigger actuators handled/s
Mon::Trigger::Actuator::miss	Trigger actuators missed/s
Mon::Trigger::Dispatcher::handled	Trigger dispatchers handled/s
Mon::Trigger::Dispatcher::miss	Trigger dispatchers missed/s

### G.1.4 Parameters For Metrics

Metrics have the parameters indicated by the left column in the following example:

#### Example

```
[bright80->monitoring->measurable[CPUUser]]% show
```

Parameter	Value
Class	CPU
Consolidator	default (ProcStat)
Cumulative	yes
Description	CPU time spent in user mode
Disabled	no (ProcStat)
Gap	0 (ProcStat)
Maximal age	0s (ProcStat)
Maximal samples	4,096 (ProcStat)
Maximum	0
Minimum	0
Name	CPUUser
Parameter	
Producer	ProcStat
Revision	
Type	Metric
Unit	Jiffies

If the value is inherited from the producer, then it is shown in parentheses next to the value. An inherited value can be overwritten by setting it directly for the parameter of a measurable.

The meanings of the parameters are:

**Class:** A choice assigned to a metric. It can be an internal type, or it can be a standalone class type. A slash (/) is used to separate class levels. A partial list of the class values is:

- **Internal:** An internal metric
- **Internal/Monitoring/Service:** An internal metric for monitoring a service
- **Internal/Monitoring/Storage:** An internal metric for monitoring storage
- **Total:** Total cluster-wide activity for the metric
- **OS:** Operating system activity
- **CPU:** CPU-related activity
- **Disk:** Disk-related activity
- **Workload:** Workload-related activity
- **Workload/Jobs:** Workload-related jobs activity
- **Workload/Slurm:** Workload-related slurm activity
- **Network:** Network-related activity
- **Memory:** Memory-related activity
- **Process:** Process-related activity

**Consolidator:** This is described in detail in sections 12.4.3 and 12.5.2

**Cumulative:** If set to `no`, then the raw value is treated as not cumulative (for example, `CoresUp`), and the raw value is presented as the metric value.

If set to `yes`, then the metric is treated as being cumulative, which means that a rate (per second) value is presented.

More explicitly: When set to `yes`, it means that the raw sample used to calculate the metric is expected to be cumulative, like, for example, the bytes-received counter for an Ethernet interface. This in turn means that the metric is calculated from the raw value by taking the difference in raw sample measurement values, and dividing it by the time period over which the raw values are sampled. Thus, for example:

- The bytes-received raw measurements, which accumulate as the packets are received, and are in bytes, and have `Cumulative` set to `yes`, and then have a corresponding metric, `BytesRecv`, with a value in bytes/second.
- The system uptime raw measurements, which accumulate at the rate of 1 second per second, and are in seconds, have `Cumulative` set to `yes`, and have a corresponding metric, `Uptime`, with a value that uses no units. Ideally, the metric has a value of 1, but in practice the measured value varies a little due to jitter.

**Description:** Description of the raw measurement used by the metric. Empty by default.

**Disabled:** If set to `no` (default) then the metric runs.

**Gap:** The number of samples that are allowed to be missed before a value of `NaN` is set for the value of the metric.

**Maximal age:** the maximum age of RLE samples that are kept. If `Maximal age` is set to 0 then the sample age is not considered. Units can be `w`, `d`, `h`, `m`, `s` (weeks, days, hours, minutes, seconds), with `s` as the default.

**Maximal samples:** the maximum number of RLE samples that are kept. If `Maximal samples` is set to 0 then the number of sample age is not considered.

**Maximum:** the default minimum value the y-axis maximum will take in graphs plotted in Bright View.<sup>1</sup>

**Minimum:** the default maximum value the y-axis minimum will take in graphs plotted in Bright View.<sup>1</sup>

**Name:** The name given to the metric.

**Parameter:** Parameter used for this metric. For example, `eth0` with the metric `BytesRecv`

**Producer:** The data producer that produces the metric

**Revision:** User-definable revision number for the object

**Type:** This can be one of `metric`, `healthcheck`, or `enummetric`

**Unit:** A unit for the metric. For example: `B/s` (bytes/second) for `BytesRecv` metric, or unit-less for the `Uptime` metric. A percent is indicated with `%`

<sup>1</sup>To clarify the concept, if `maximum=3`, `minimum=0`, then a data-point with a y-value of 2 is plotted on a graph with the y-axis spanning from 0 to 3. However, if the data-point has a y-value of 4 instead, then it means the default y-axis maximum of 3 is re-sized to 4, and the y-axis will now span from 0 to 4.

## G.2 Health Checks And Their Parameters

A list of health checks can be viewed, for example, for the head node, using `cmsh` as follows (section 12.5.3):

```
[bright80 ~]# cmsh -c "monitoring measurable; list healthcheck"
```

Health checks (section 12.2.4) are listed and described in this section.

### G.2.1 Health Checks

Table G.2.1: List Of Health Checks

Name	Query (script response is PASS/FAIL)
ManagedServicesOk*	Are CMDaemon-monitored services all OK? If the response is FAIL, then at least one of the services being monitored is failing. After correcting the problem with the service, a reset of the service is normally carried out (section 3.11, page 97).
Mon::Storage	Is space available for the monitoring system metrics (section G.1.3)?
chrootprocess	Are there daemon processes running using chroot in software images? (here: yes = FAIL). On failure, kill cron daemon processes running in the software images.
beegfs	Is BeeGFS properly connected as expected to all the nodes? Unreachable nodes and failed routes are listed in InfoMessages.
cmsh	Is <code>cmsh</code> available?
defaultgateway	Is there a default gateway available?
dellnss	If running, is the Dell NFS Storage Solution healthy?
diskspace	Is there less disk space available to non-root users than any of the space parameters specified? <i>The space parameters can be specified as MB, GB, TB, or as percentages with %. The default severity of notices from this check is 10, when one space parameter is used. For more than one space parameter, the severity decreases by 10 for each space parameter, sequentially, down to 10 for the last space parameter. By default a space parameter of 10% is assumed. Another, also optional, non-space parameter, the filesystem mount point parameter, can be specified after the last space parameter to track filesystem space, instead of disk space. A metric-based alternative to tracking filesystem space changes is to use the built-in metric <code>freespace</code> (page 650) instead.</i>

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL)								
	Examples:								
	<ul style="list-style-type: none"> <li>• diskspace 10% less than 10% space = FAIL, severity 10</li> <li>• diskspace 10% 20% 30% less than 30% space = FAIL, with severity levels as indicated: <table> <tr> <th>space left</th><th>severity</th></tr> <tr> <td>10%</td><td>30</td></tr> <tr> <td>20%</td><td>20</td></tr> <tr> <td>30%</td><td>10</td></tr> </table> </li> <li>• diskspace 10GB 20GB less than 20GB space = FAIL, severity 10 less than 10GB space = FAIL, severity 20</li> <li>• diskspace 10% 20% /var For the filesystem /var: less than 20% space = FAIL, severity 10 less than 10% space = FAIL, severity 20</li> </ul>	space left	severity	10%	30	20%	20	30%	10
space left	severity								
10%	30								
20%	20								
30%	10								

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL)
dmesg	Is dmesg output OK? <i>Regexes to parse the output can be constructed in the configuration file at /cm/local/apps/cmd/scripts/healthchecks/configfiles/dmesg.py</i>
docker	Is Docker running OK? Checks for Docker server availability and corruption, dead containers, proper endpoints
dockerregistry	Is the Docker registry running OK? Checks registry endpoint and registry availability
exports	Are all filesystems as defined by the cluster management system exported?
etcd	Are the core etcd processes of Kubernetes running OK? Checks endpoints and interfaces
failedprejob	Are there failed prejob health checks (section 7.8.2)? Here: yes = FAIL. By default, the job ID is saved under /cm/shared/apps/<scheduler>/var/cm/: <ul style="list-style-type: none"> <li>• On FAIL, in failedprejobs.</li> <li>• On PASS, in allprejobs</li> </ul> <p>The maximum number of IDs stored is 1000 by default. The maximum period for which the IDs are stored is 30 days by default. Both these maxima can be set with the failedprejob health check script.</p>
failover	Is the failover status okay?
gpuhealth_quick	Is all well with the GPUs according to a quick check? <i>A configuration file for this is at /cm/local/apps/cmd/scripts/healthchecks/configfiles/gpuhealth.ini</i>
gpuhealth_extended	Is all well with the GPUs according to more resource-intensive tests? <i>Using this test according to a regular schedule is not advised because it can affect the running of current jobs</i>
hpraid	Are the HP Smart Array controllers OK?
ib	Is the InfiniBand Host Channel Adapter working properly? <i>A configuration file for this health check is at /cm/local/apps/cmd/scripts/healthchecks/configfiles/ib.py</i>
ieel_alerts	Are there not too many alerts (INFO, WARNING, or ERROR) from IEEL? (A FAIL response happens when there are too many alerts, and a PASS happens if there are not too many alerts)

...continued



Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL)
ieel_lnetstate	If the node is a Lustre server node, then is the Luster network status OK?
interfaces	Are the interfaces all up and OK?
ipmihealth	Is the BMC (IPMI or iLO) health OK? Uses the script <code>sample_ipmi</code> .
kuberneteschildnode	Are all Kubernetes child nodes up?
kubernetescomponen\	Are all expected agents and services up and running for active nodes?
tsstatus	
kubernetesnodessta\	Is the status for all Kubernetes nodes OK?
tus	
kubernetespodsstat\	Is the status for all pods OK?
us	
ldap	Can the ID of the user be looked up with LDAP?
lustre	Is the Lustre filesystem running OK?
marathon	Is Marathon running OK?
mesosmaster	Is the Mesos master running OK?
mesosslave	Is the Mesos slave running OK?
messagequeue	Is the OpenStack Message Queue (RabbitMQ) running OK?
megaraid	Are the MegaRAID controllers OK? <i>The proprietary MegaCli software from LSI (<a href="http://www.lsi.com">http://www.lsi.com</a>) is needed for this health check.</i>
mounts	Are all mounts defined in the fstab OK?
mysql	Is the status and configuration of MySQL correct?
node-hardware-prof\	Is the specified node's hardware configuration during health check use
ile	unchanged? <i>The options to this script are described using the "-h" help option. Before this script is used for health checks, the specified hardware profile is usually first saved with the -s option. Eg: "node-hardware-profile -n node001 -s hardwarenode001"</i>
ntp	Is NTP synchronization happening?
oomkiller	Has the oomkiller process run? Yes=FAIL. The oomkiller health check checks if the oomkiller process has run. The configuration file <code>/cm/local/apps/cmd/scripts/healthchecks/configfiles/oomkiller.conf</code> for the oomkiller health check can be configured to reset the response to PASS after one FAIL is logged, until the next oomkiller process runs. The processes killed by the oomkiller process are logged in <code>/var/spool/cmd/save-oomkilleraction</code> . <i>A consideration of the causes and consequences of the killed processes is strongly recommended. A reset of the node is generally recommended.</i>

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL)
opalinkhealth	Are the quality and the integrity of the Intel OPA HFI link OK?
openstackaddremove	Is the addition and removal of objects in Keystone, Neutron, Nova, Cinder, Glance, and Heat working OK?
openstackagents	Are the agents (OpenStack service components) OK?
openstackauth	Is the authentication for Keystone, Neutron, Nova, Cinder, Glance, and Heat working OK?
openstackconfiguration	Are some basic configuration options for OpenStack working OK?
openstackdashboard	Is the Horizon dashboard login working OK?
openstackportstatus	Within OpenStack, are DHCP, router ports, and router gateway ports of the Neutron service all up?
openstackresponse	Is Keystone is responsive and are the endpoints of each service pingable?
openstackvmsok	Are the virtual machines under OpenStack running OK?
portchecker	Is the specified port on the specified host open for TCP (default) or UDP connections?
rogueprocess	<p>Are the processes that are running legitimate (ie, not 'rogue')? Besides the FAIL/PASS/UNKNOWN response to CMDaemon, also returns a list of rogue process IDs to file descriptor 3 (InfoMessages), which the <code>killprocess</code> action (page 667) can then go ahead and kill.</p> <p>Illegitimate processes are processes that should not be running on the node. An illegitimate process is at least one of the following, by default:</p> <ul style="list-style-type: none"> <li>• not part of the workload manager service or its jobs</li> <li>• not a root- or system-owned process</li> <li>• in the state Z, T, W, or X. States are described in the <code>ps</code> man pages in the section on "PROCESS STATE CODES"</li> </ul>

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL)
	Rogue process criteria can be configured in the file <code>/cm/local/apps/cmd/scripts/healthchecks/configfiles/rogueprocess.py</code> within the software image. To implement a changed criteria configuration, the software image used by systems on which the health check is run should be updated (section 5.6). For example, using: <code>cmsh -c "device; imageupdate -c default -w"</code> for the default category of nodes.
schedulers	Are the queue instances of all schedulers on a node healthy ?
smart	<p>Is the SMART response healthy? The severities can be configured in the file <code>/cm/local/apps/cmd/scripts/healthchecks/configfiles/smart.conf</code>.</p> <p>By default, if a drive does not support the SMART commands and results in a "Smart command failed" info message for that drive, then the healthcheck is configured to give a PASS response. This is because the mere fact that the drive is a non-SMART drive should not be a reason to conclude that the drive is unhealthy.</p> <p>The info messages can be suppressed by setting a whitelist of the disks to be checked within <code>/cm/local/apps/cmd/scripts/healthchecks/smart</code>.</p>
ssh2node	<p>Is passwordless ssh root login from head to node working?</p> <p>Some details of its behavior are:</p> <ul style="list-style-type: none"> <li>• If root ssh login to the head node has been disabled, then the health check fails on the head node.</li> <li>• The healthcheck <code>ssh2node</code> fails if ssh certificate-based access, to a regular head node that is in the UP state, fails. The UP state is determined by whether CMDaemon is running on that node.</li> <li>• If the regular node is in a DOWN state—which could be due to CMDaemon being down, or the node having been powered off gracefully, or the node suffering a sudden power failure—then the health check responds with a PASS. The idea here is to check key access, and decouple it from the node state.</li> </ul>

...continued

Table G.2.1: List Of Health Checks...continued

Name	Query (response is PASS/FAIL)
swraid	Are the software RAID arrays healthy?
testhealthcheck	<i>A health check script example for creating scripts, or setting a mix of PASS/FAIL/UNKNOWN responses. The source includes examples of environment variables that can be used, as well as configuration suggestions.</i>
zookeeper	Are Zookeeper components healthy?

\* built-ins, not standalone scripts.

If sampling from a head node, a standalone script is in directory:

/cm/local/apps/cmd/scripts/healthchecks/

If sampling from a regular node, a standalone script is in directory:

/cm/images/default-image/cm/local/apps/cmd/scripts/healthchecks/

## G.2.2 Parameters For Health Checks

Health checks have the parameters indicated by the left column in the example below:

### Example

```
[myheadnode->monitoring->measurable]% show cmsh
Parameter                                Value
-----
Class                                    Internal
Consolidator                            - (cmsh)
Description                              Checks whether cmsh is available, i.e. can we
                                         use cmsh for the default cluster?
Disabled                                 no (cmsh)
Gap                                       0 (cmsh)
Maximal age                              0s (cmsh)
Maximal samples                          4,096 (cmsh)
Name                                      cmsh
Parameter                                cmsh
Producer                                 cmsh
Revision
Type                                      HealthCheck
```

If the value is inherited from the producer, then it is shown in parentheses next to the value. An inherited value can be overwritten by setting it directly for the parameter of a measurable.

The parameters are a subset of the parameters for metrics described in section G.1.4.

## G.3 Actions And Their Parameters

### G.3.1 Actions

Table G.3.1: List Of Actions

Name	Description
Drain	Allows no new processes on a compute node from the workload manager. This means that already running jobs are permitted to complete. Usage Tip: Plan for undrain from another node becoming active
Send e-mail to administrators	Sends mail using the mailserver that was set up during server configuration. Default destination is root@localhost. The e-mail address that it is otherwise sent to is specified by the recipient parameter for this action.
Event	Send an event to users with a connected client
ImageUpdate	Update the image on the node
PowerOff	Powers off, hard
PowerOn	Powers on, hard
PowerReset	Power reset, hard
Reboot	Reboot via the system, trying to shut everything down cleanly, and then start up again
killprocess*	Kills processes listed in STDIN with KILL (-9) signal. Format: killprocess <PID1[,<PID2>,...]> This action is designed to work with rogueprocess (page 664)
remount*	remounts all defined mounts
testaction*	An action script example for users who would like to create their own scripts. The source has helpful remarks about the environment variables that can be used as well as tips on configuring it generally
Shutdown	Power off via system, trying to shut everything down cleanly
Undrain node	Allow processes to run on the node from the workload manager

\* standalone scripts, not built-ins.

If running from a head node, the script is in directory: /cm/local/apps/cmd/scripts/actions/

If running from a regular node, the script is in directory: /cm/images/default-image/cm/local/apps/cmd/scripts/actions/

### G.3.2 Parameters For A Monitoring Action

The default monitoring actions are listed in section 12.4.4.

All actions have in common the parameters shown by the left column, illustrated by the example below for the drain action:

#### Example

```
[myheadnode->monitoring->action]% show drain
Parameter      Value
-----
Action          Drain node from all WLM
Allowed time
Disable         no
Name            Drain
Revision
Run on          Active
Type            DrainAction
```

Out of the full list of default actions, the actions with only the common parameter settings are:

- `Poweron`: Powers off the node
- `PowerOff`: Powers off the node
- `PowerReset`: Hard resets the node
- `Drain`: Drains the node (does not allow new jobs on that node)
- `Undrain`: Undrains the node (allows new jobs on that node)
- `Reboot`: Reboots node via the operating system.
- `Shutdown`: Shuts the node down via the operating system.
- `ImageUpdate`: Updates the node from the software image
- `Event`: Sends an event to users connected with `cmsh` or Bright View

### Extra Parameters For Some Actions

The following actions have extra parameters:

#### Action of the type `ScriptAction`:

- `killprocess`: A script that kills a specified process
- `testaction`: A test script
- `remount`: A script to remount all devices

The extra parameters for an action of type `ScriptAction` are:

- `Arguments`: List of arguments that are taken by the script
- `Node environment`: Does the script run in the node environment?
- `Script`: The script path
- `timeout`: Time within which the script must run before giving up

#### Action of the type `EmailAction`:

- `Send e-mail to administrators`: Sends an e-mail out, by default to the administrators

The extra parameters for an action of type `EmailAction` are:

- `All administrators`: sends the e-mail to the list of users in the `Administrator e-mail setting` in `partition[base]` mode
- `Info`: the body of the e-mail message
- `Recipients`: a list of recipients

# H

## Workload Manager Configuration Files Updated By CMDaemon

This appendix lists workload manager configuration files changed by CMDaemon, events causing such change, and the file or property changed.

### H.1 Slurm

File/Property	Updates What?	Updated During
/etc/slurm/slurm.conf	head node	Add/Remove/Update nodes, hostname change
/etc/slurm/slurmdbd.conf	head node	Add/Remove/Update nodes, hostname change
/etc/slurm/gres.conf	all nodes	Add/Remove/Update nodes
/etc/slurm/topology.conf	head node	Add/Remove/Update nodes

### H.2 Grid Engine (SGE/UGE)

File/Property	Updates What?	Updated During
\$ROOT/default/common/host_aliases	head node	hostname/domain change, failover
\$ROOT/default/common/act_qmaster	head node	hostname/domain change, failover

### H.3 Torque

File/Property	Updates What?	Updated During
\$ROOT/spool/server_name	head node	hostname/domain change, failover
\$ROOT/spool/torque.cfg	head node	hostname/domain change, failover
\$ROOT/server_priv/acl_svr/acl_hosts	head node	hostname/domain change, failover
\$ROOT/spool/server_priv/acl_svr/operators	head node	hostname change, failover
\$ROOT/spool/server_priv/nodes	head node	Add/Remove/Update nodes
\$ROOT/mom_priv/config	software image	hostname change, failover

### H.4 PBS Pro

File/Property	Updates What?	Updated During
/etc/pbs.conf	head node, software image	hostname/domain change, failover
\$ROOT/server_priv/acl_svr/operators	head node	hostname change, failover
\$ROOT/spool/server_priv/nodes	head node	Add/Remove/Update nodes
\$ROOT/server_priv/acl_hosts	head node	Add/Remove/Update nodes

## H.5 LSF

File/Property	Updates What?	Updated During
\$LSF_TOP/conf/lsf.conf	head node	hostname/domain change, failover
\$LSF_TOP/conf/hosts	cloud-director	add/remove/update cloud nodes
\$LSF_TOP/conf/lsbatch/<clustername>/ configdir/lsb.queues	head node	add/remove/update nodes
\$LSF_TOP/conf/lsbatch/<clustername>/ configdir/lsb.hosts	head node	add/remove/update nodes
\$LSF_TOP/conf/lsf.cluster.<clustername>	head node	add/remove/update nodes

The default value of \$LSF\_TOP in Bright Cluster Manager  
is /cm/shared/apps/lsf

## H.6 OpenLava

File/Property	Updates What?	Updated During
\$LSF_ENVDIR/lsf.conf	head node	hostname/domain change, failover
\$LSF_ENVDIR/hosts	cloud-director	add/remove/update cloud nodes
\$LSF_ENVDIR/lsf.cluster.<clustername>	head node	add/remove/update nodes
\$LSF_ENVDIR/lsb.queues	head node	add/remove/update nodes
\$LSF_ENVDIR/lsb.hosts	head node	add/remove/update nodes

The default value of \$LSF\_ENVDIR in Bright Cluster Manager  
is /cm/shared/apps/openlava/var/etc/





# Changing The LDAP Password

The administrator may wish to change the LDAP root password. This procedure has two steps:

- setting a new password for the LDAP server (section I.1), and
- setting the new password in `cmd.conf` (section I.2).

It is also a good idea to do some checking afterwards (section I.3).

## I.1 Setting A New Password For The LDAP Server

An encrypted password string can be generated as follows:

```
[root@bright80 ~]# module load openldap
[root@bright80 ~]# slappasswd
New password:
Re-enter new password:
SSHAJ/3wyO+IqyAwhh8Q4obL8489CWJlHpLg
```

The input is the plain text password, and the output is the encrypted password. The encrypted password is set as a value for the `rootpw` tag in the `slapd.conf` file on the head node:

```
[root@bright80 ~]# grep ^rootpw /cm/local/apps/openldap/etc/slapd.conf
rootpw SSHAJ/3wyO+IqyAwhh8Q4obL8489CWJlHpLg
```

The password can also be saved in plain text instead of as an SSHA hash generated with `slappasswd`, but this is considered insecure.

After setting the value for `rootpw`, the LDAP server is restarted:

```
[root@bright80 ~]# service ldap restart          #Centos 6
[root@bright80 ~]# service slapd restart         #Centos 7
```

## I.2 Setting The New Password In `cmd.conf`

The new LDAP password (the plain text password that generated the encrypted password after entering the `slappasswd` command in section I.1) is set in `cmd.conf`. It is kept as clear text for the entry for the `LDAPPass` directive (Appendix C):

```
[root@bright80 ~]# grep LDAPPass /cm/local/apps/cmd/etc/cmd.conf
LDAPPass = "Mysecretldappassw0rd"
```

CMDaemon is then restarted:

```
[root@bright80 ~]# service cmd restart
```

### I.3 Checking LDAP Access

For a default configuration with user `cmsupport` and domain `cm.cluster`, the following checks can be run from the head node (some output truncated):

- anonymous access:

```
[root@bright80 ~]# ldapsearch -x
# extended LDIF
#
# LDAPv3
# base <dc=cm,dc=cluster> (default) with scope subtree
...
```

- root cn without a password (this should fail):

```
[root@bright80 ~]# ldapsearch -x -D 'cn=root,dc=cm,dc=cluster'
ldap_bind: Server is unwilling to perform (53)
  additional info: unauthenticated bind (DN with no password) disallowed
[root@bright80 ~]#
```

- root cn with a password (this should work):

```
[root@bright80 ~]# ldapsearch -x -D 'cn=root,dc=cm,dc=cluster' -w Mysecretldappassw0rd
# extended LDIF
#
# LDAPv3
# base <dc=cm,dc=cluster> (default) with scope subtree
...
```



# Tokens

This appendix describes authorization tokens available for profiles. Profiles are introduced in Section 6.4:

Table J: List Of Tokens

Service and token name	User can...
<b>Service: CMAuth</b>	
GET_PROFILE_TOKEN	Retrieve list of profiles and profile properties
ADD_PROFILE_TOKEN	Add a new profile
MODIFY_PROFILE_TOKEN	Modify existing user profile
GET_CMSSERVICES_TOKEN	Get a list of available CMDaemon services
<b>Service: CMCeph</b>	
GET_CEPH_TOKEN	Get Ceph properties
ADD_CEPH_TOKEN	Add new Ceph configuration
UPDATE_CEPH_TOKEN	Update Ceph configuration
CEPH_KEYS_TOKEN	Manipulate Ceph keys
CEPH_CLUSTER_SERVICES_TOKEN	List Ceph services
CEPH_SET_DECOMMISSION_TOKEN	Decommission Ceph nodes
CEPH_GET_DECOMMISSION_TOKEN	Get decommissioning information
UPDATE_CEPH_STATE_TOKEN	Update Ceph state
GENERIC_CEPH_COMMAND_TOKEN	Run generic Ceph command
<b>Service: CMCert</b>	
ISSUE_CERTIFICATE_TOKEN	Accept certificate request and issue signed certificate
GET_CERTIFICATE_REQUEST_TOKEN	List pending certificate requests
RECREATE_COMPONENT_CERTIFICATE_TOKEN	Recreate component certificate

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
REMOVE_CERTIFICATE_REQUEST_TOKEN	Cancel certificate request
GET_CERTIFICATE_TOKEN	Show certificate information
REVOKE_CERTIFICATE_TOKEN	Revoke a certificate
UNREVOKE_CERTIFICATE_TOKEN	Unrevoke a revoked certificate
GET_AUTOSIGN_TOKEN	Get information on certificate auto-signing CMDaemon's private key
SET_AUTOSIGN_TOKEN	Enable certificate auto-signing with CMDaemon's private key
<b>Service: CMCloud</b>	
GET_CLOUD_PROVIDER_TOKEN	Get cloud provider information
ADD_CLOUD_PROVIDER_TOKEN	Add a new cloud provider
UPDATE_CLOUD_PROVIDER_TOKEN	Update cloud provider settings
EC2_ACCESS_STRING_TOKEN	Get/set Amazon EC2 access string
GET_CLOUD_REGION_TOKEN	Access Amazon EC2 region
GET_CLOUD_AMI_TOKEN	Access Amazon EC2 AMI
GET_CLOUD_TYPE_TOKEN	Access Amazon instance type
GET_KERNEL_INITRD_MD5SUM_TOKEN	Retrieve MD5 sum of initial ramdisk
PUT_USERDATA_TOKEN	Set AWS user data in AWS
TERMINATE_NODE_TOKEN	Terminate cloud nodes
GET_AWS_KEY_TOKEN	Retrieve AWS key
SET_CLOUDDIRECTOR_TOKEN	Modify the properties of the cloud director
CLOUD_DIRECTOR_NEW_IP_TOKEN	Set the new External IP of the cloud director
GET_CONSOLE_OUTPUT_TOKEN	Retrieve the console output of the cloud director for debugging purposes
SET_CLOUDERRORS_TOKEN	
GET_CLOUD_STATIC_IPS_TOKEN	Get the static IP list of the cloud nodes
GET_CLOUD_VIRTUAL_NETWORK_INTERFACES_TOKEN	Get list of EC2 VPN interfaces (e.g. tun0)
SEND_CLOUD_STORAGE_ACTION_TOKEN	Send cloud storage action
VPC_MAGIC_CALL_TOKEN	(Internal use only)
ALLOCATE_STATIC_IP_TOKEN	Allocate static IP to cloud director
UNALLOCATE_STATIC_IP_TOKEN	De-allocate static IP
ALLOCATE_CLOUD_VIRTUAL_NETWORK_INTERFACE_TOKEN	Allocate virtual cloud network interface
UNALLOCATE_CLOUD_VIRTUAL_NETWORK_INTERFACE_TOKEN	De-allocate virtual cloud network interface
ATTACH_CLOUD_VIRTUAL_NETWORK_INTERFACE	Start a VPN tunnel to a cloud node

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
DETACH_CLOUD_VIRTUAL_NETWORK_INTERFACE	Stop a VPN tunnel to a cloud node
ADD_CLOUD_JOB_DESCRIPTION_TOKEN	Add cloud job description
GET_CLOUD_JOB_DESCRIPTION_TOKEN	Get cloud job description
GET_ALL_CLOUD_JOB_DESCRIPTION_TOKEN	Get all cloud job description
SUBMIT_CLOUD_JOB_DESCRIPTION_TOKEN	Submit cloud job description
UPDATE_CLOUD_JOB_DESCRIPTION_TOKEN	Update cloud job description
<b>Service: CMDevice</b>	
SNMP_STRING_TOKEN	Get ethernet switch SNMP public string
CHASSIS_USER_PASSWORD_TOKEN	Get/set chassis username and password
BMC_USERNAME_PASSWORD_TOKEN	View/set BMC (e.g. HP ilo4, IPMI) username and password
GET_DEVICE_TOKEN	View all device properties
GET_DEVICE_BY_PORT_TOKEN	View list of devices according to the ethernet switch port that they are connected to
ADD_DEVICE_TOKEN	Add a new device
UPDATE_DEVICE_TOKEN	Update device properties
GET_CATEGORY_TOKEN	Get list of categories
ADD_CATEGORY_TOKEN	Create new category
UPDATE_CATEGORY_TOKEN	Update a category property
GET_NODEGROUP_TOKEN	Get list of nodegroups
ADD_NODEGROUP_TOKEN	Add a new nodegroup
UPDATE_NODEGROUP_TOKEN	Update nodegroup properties (e.g. add a new member node)
GET_DEVICE_STATUS_TOKEN	Get device status (e.g. UP as well as status string e.g. restart required)
SET_DEVICE_STATUS_TOKEN	Set device status (only via RPC API calls)
POWER_ON_TOKEN	Power on a device using BMC or PDU power control
POWER_OFF_TOKEN	Power off a device
POWER_CYCLE_TOKEN	Power reset a device
POWER_STATUS_TOKEN	Get power status e.g on or off
POWER_RESULT_TOKEN	Get the result of the previous power command e.g. failed
SHUTDOWN_NODE_TOKEN	Shutdown a remote node managed by CMDaemon
REBOOT_NODE_TOKEN	Reboot a remote a node
FORCE_RECONNECT_TOKEN	Force remote client to reconnect (RPC API)
NODE_IDENTIFY_TOKEN	Identify a node (RPC API, used by node installer)

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
NODE_GET_MOUNTPOINTS_TOKEN	Get list of mountpoints defined for a node
PPING_TOKEN	Run parallel ping
BURN_STATUS_TOKEN	Get burn status
GET_BURN_LOG_TOKEN	Retrieve burn log
GET_SYNC_LOG_TOKEN	Get rsync provisioning log
GET_PORT_BY_MAC_TOKEN	Determine to which switch port a given MAC is connected to.
SYSINFO_COLLECTOR_TOKEN	Get information about a node (executes dmidecode)
UPDATE_CONFIG_TOKEN	Update node configuration
GET_LIVE_UCS_TOKEN	Get UCS live status
SET_LIVE_UCS_TOKEN	Set UCS live
VALIDATE_UCS_TOKEN	Validate UCS configuration
START_KVM_UCS_TOKEN	Start UCS KVM console
GET_UCS_LOG_TOKEN	Retrieve UCS log
CLEAR_UCS_LOG_TOKEN	Clear Cisco UCS log
CONVERT_XML_TO_UCS_TOKEN	Parse and serialize XML UCS configuration so that CM-Daemon can use it
GET_EXCLUDE_LIST_TOKEN	Retrieve the various exclude lists
INSTALLER_REBOOT_REQUIRED_TOKEN	Set restart-required flag (typically set by CMDaemon)
ADD_REMOTE_NODE_INSTALLER_INTERACTION_TOKEN	Add a node-installer interaction (Used by CMDaemon)
REMOVE_REMOTE_NODE_INSTALLER_INTERACTION_TOKEN	Remove a node installer interaction
GET_REMOTE_NODE_INSTALLER_INTERACTIONS_TOKEN	Get list of pending installer interactions
UPDATE_REMOTE_NODE_INSTALLER_INTERACTIONS_TOKEN	Update installer interactions (e.g. confirm full provisioning)
GET_CLUSTAT	Get cluster status (RPC API, Internal)
SET_CLUSTAT	Set cluster status (RPC API, Internal)
<b>Service: CMGui</b>	
GET_CLUSTER_OVERVIEW_TOKEN	Get cluster overview
GET_NODE_OVERVIEW_TOKEN	Get node overview
GET_NETSWITCH_OVERVIEW_TOKEN	Get switch overview
GET_PDU_OVERVIEW_TOKEN	Get PDU overview
GET_NODE_STATUS_TOKEN	Get node status
GET_HADOOP_HDFS_OVERVIEW_TOKEN	Get HDFS overview
GET_CEPH_OVERVIEW_TOKEN	Get Ceph overview
GET_OPENSTACK_OVERVIEW_TOKEN	Get OpenStack overview

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
GET_OPENSTACK_TENANT_OVERVIEW_TOKEN	Get OpenStack VM overview
<b>Service: CMHadoop</b>	
GET_HADOOP_HDFS_TOKEN	Get list of HDFS filesystems
ADD_HADOOP_HDFS_TOKEN	Add a new HDFS filesystem object
UPDATE_HADOOP_HDFS_TOKEN	Update HDFS object properties
HADOOP_BALANCER_TOKEN	Set balancer properties
HADOOP_BALANCER_STATUS_TOKEN	Get status of balancer
HADOOP_CLUSTER_SERVICES_TOKEN	Start/stop Hadoop services on nodes
HADOOP_FORMAT_HDFS_TOKEN	Format an HDFS filesystem
HADOOP_SET_DECOMMISSION_TOKEN	Decommission a Hadoop worker node
HADOOP_GET_DECOMMISSION_TOKEN	Get commissioning status of Hadoop nodes
<b>Service: CMJob</b>	
GET_JOB_TOKEN	Get list of jobs that are currently running
HOLD_JOB_TOKEN	Place a job on hold
SUSPEND_JOB_TOKEN	Suspend a job
RESUME_JOB_TOKEN	Resume suspended job
RELEASE_JOB_TOKEN	Release a held job
UPDATE_JOB_TOKEN	Update job run-timer parameters
SUBMIT_JOB_TOKEN	Submit a job using JSON
GET_JOBQUEUE_TOKEN	Retrieve list of job queues and properties
UPDATE_JOBQUEUE_TOKEN	Modify job queues
ADD_JOBQUEUE_TOKEN	Add a new job queue
GET_PE_TOKEN	Get list of SGE parallel environments
DRAIN_TOKEN	Drain a node
DRAIN_OVERVIEW_TOKEN	Obtain list of drained nodes
<b>Service: CMMain</b>	
GET_LICENSE_INFO_TOKEN	Retrieve information about BCM license
GET_VERSION_TOKEN	Get CMDaemon version and revision
GET_SERVER_STATUS_TOKEN	Headnode status (e.g. ACTIVE, BECOMEACTIVE etc.)
GET_CLUSTER_SETUP_TOKEN	Get cluster configuration
PING_TOKEN	TCP SYN ping managed devices
PCOPY_TOKEN	Copy a specified file in parallel to a list of nodes
READ_FILE_TOKEN	Read a text file. The text file will be serialized as a JSON object
SAVE_FILE_TOKEN	Save a file on a remote node
UPDATE_SELF_TOKEN	Update a category property

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
CMDAEMON_FAILOVER_TOKEN	Set CMDaemon failover condition achieved
CMDAEMON_QUORUM_TOKEN	Set CMDaemon quorum achieved
GENERIC_CALL_TOKEN	Make a generic call
REPORT_CRITICAL_ERROR_TOKEN	View critical error report
SET_SERVICESTATE_TOKEN	Set the state of a service
GET_SERVICESTATE_TOKEN	Get the state of a service
GET_BACKGROUND_TASKS_TOKEN	Get background tasks
CANCEL_BACKGROUND_TASKS_TOKEN	Cancel background tasks
CALL_EXTENSION_TOKEN	
<b>Service: CMMon</b>	
GET_MONCONF_TOKEN	Get monitoring configuration settings
UPDATE_MONCONF_TOKEN	Update monitoring configuration settings
GET_METRIC_TOKEN	Get metric settings
UPDATE_METRIC_TOKEN	Update metric settings
ADD_METRIC_TOKEN	Add metric settings
GET_HEALTHCHECK_TOKEN	Get health check settings
UPDATE_HEALTHCHECK_TOKEN	Update health check settings
ADD_HEALTHCHECK_TOKEN	Add health check settings
GET_THRESHACTION_TOKEN	Get threshold action settings
UPDATE_THRESHACTION_TOKEN	Update threshold action settings
ADD_THRESHACTION_TOKEN	Add threshold action settings
GET_MONITORING_DATA_TOKEN	Get monitoring data settings
SIGNAL_THRESHOLD_EXCEEDED_TOKEN	See if signal threshold exceeded
MONITORING_INTERNAL_TOKEN	Set up internal monitoring
PREJOB_TOKEN	Set up prejob check
FAKE_MONITORING_TOKEN	Set up fake monitoring
ONDEMAND_TOKEN	Sample on demand
ONDEMAND_RESULT_TOKEN	Read sample results on demand.
GET_METRICCLASS_TOKEN	Get metric class settings
<b>Service: CMNet</b>	
GET_NETWORK_TOKEN	Get network settings
ADD_NETWORK_TOKEN	Add network settings
UPDATE_NETWORK_TOKEN	Update network settings
<b>CMOpenStack</b>	
GET_OPENSTACK_TOKEN	Get OpenStack settings
ADD_OPENSTACK_TOKEN	Add OpenStack settings

...continues



Table J: List Of Tokens...continued

Service and token name	User can...
UPDATE_OPENSTACK_TOKEN	Update OpenStack settings
OPENSTACK_USERNAMES_ _PASSWORDS_TOKEN	Get/set username and password settings
OPENSTACK_MANAGE_USER_ INSTANCES_TOKEN	Get/set user instances
OPENSTACK_VIEW_CONSOLE_LOG_ TOKEN	View OpenStack console log
OPENSTACK_TERMINATE_USER_ INSTANCES_TOKEN	Terminate OpenStack user instances
OPENSTACK_EXECUTE_SETUP_TOKEN	
OPENSTACK_GET_SETUP_ EXECUTION_TOKEN	Execute OpenStack setup
OPENSTACK_REMOVE_SETUP_ EXECUTION_TOKEN	Not execute OpenStack setup
GET_OPENSTACK_VNC_URL_TOKEN	Get OpenStack VNC URL
<b>Service: CMPart</b>	
GET_PARTITION_TOKEN	Get partition settings
ADD_PARTITION_TOKEN	Add partition settings
UPDATE_PARTITION_TOKEN	Update partition settings
GET_RACK_TOKEN	Get rack settings
ADD_RACK_TOKEN	Add rack settings
UPDATE_RACK_TOKEN	Update rack settings
GET_SOFTWAREIMAGE_TOKEN	Get softwareimage settings
ADD_SOFTWAREIMAGE_TOKEN	Add softwareimage settings
UPDATE_SOFTWAREIMAGE_TOKEN	Update softwareimage settings
REMOVE_SOFTWAREIMAGE_TOKEN	Remove softwareimage settings
UPDATE_PROVISIONERS_TOKEN	Update provisioners settings
UPDATE_PROVISIONING_NODE_ TOKEN	Update provisioning node
CMDAEMON_FAILOVER_STATUS_ TOKEN	Obtain status of failover
<b>Service: CMProc</b>	
GET_PROCESS_TOKEN	Retrieve list of processes that are currently running on a device managed by CMDaemon
GET_SHARED_MEM_TOKEN	Get shared memory
GET_SEMAPHORE_TOKEN	Get semaphore
GET_MSGQUEUE_TOKEN	Get message queue status
CLEAN_IPC_TOKEN	Clear IPC state
SEND_SIGNAL_TOKEN	Send signal to a process
START_SHELL_TOKEN	Start SSH session

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
START_MINICOM_TOKEN	Start minicom serial session
EXEC_COMMAND_TOKEN	Execute a command on a headnode
NODE_EXEC_COMMAND_TOKEN	Remotely execute a command on a compute node
NODE_EXEC_COMMAND_MAINTENANCE_TOKEN	Execute a maintenance command (used by CMDaemon)
EXEC_INTERNAL_COMMAND_TOKEN	Execute internal command (defined in the source code, RPC API, internal)
<b>Service: CMProv</b>	
GET_FSPART_TOKEN	Get FSPart (internal)
ADD_FSPART_TOKEN	Set FSPart (internal)
UPDATE_FSPART_TOKEN	Update FSPart (internal)
REMOVE_FSPART_TOKEN	Remove FSPart (internal)
RUN_PROVISIONINGPROCESSORJOB_TOKEN	Start and run a provisioning job (nodes with a provisioning role)
UPDATE_PROVISIONINGPROCESSORJOB_TOKEN	Update status of running provisioning jobs (CMDaemon)
REQUEST_PROVISIONING_TOKEN	Request provisioning (nodes with a provisioning role)
MANAGE_RSYNC_DAEMON_TOKEN	Manage the rsync process (CMDaemon)
IMAGEUPDATE_TOKEN	Send image changes to nodes
UPDATEPROVISIONERS_TOKEN	Synchronize software images across provisioning systems (requires at least two provisioners)
PROVISIONERS_STATUS_TOKEN	Check status of provisioners e.g. images are in sync
CANCEL_PROVISIONING_REQUEST_TOKEN	Cancel provisioning request
GRAB_IMAGEUPDATE_TOKEN	Grab changes from node to software image and vice versa
<b>Service: CMServ</b>	
GET_OSSERVICE_TOKEN	Get system service information
START_OSSERVICE_TOKEN	Start system services (service foo start)
STOP_OSSERVICE_TOKEN	Stop system services
CALLINIT_OSSERVICE_TOKEN	Call init (useful for the node-installer itself)
RESTART_OSSERVICE_TOKEN	Restart system services
RELOAD_OSSERVICE_TOKEN	Reload system services
RESET_OSSERVICE_TOKEN	Reset system services
<b>Service: CMSession</b>	
GET_SESSION_TOKEN	Retrieve session information
REGISTER_NODE_SESSION_TOKEN	Register new nodes in a special CMDaemon session (node-installer)

...continues

Table J: List Of Tokens...continued

Service and token name	User can...
END_SESSION_TOKEN	Terminate sessions
HANDLE_EVENT_TOKEN	Handle events
GET_BROADCAST_EVENTS_TOKEN	Receive broadcast events
<b>Service: CMUser</b>	
GET_USER_TOKEN	Retrieve user information
ADD_USER_TOKEN	Add a new LDAP user
UPDATE_USER_TOKEN	Modify an existing LDAP user
GET_GROUP_TOKEN	Retrieve group information
ADD_GROUP_TOKEN	Add a new LDAP group
UPDATE_GROUP_TOKEN	Modify an existing LDAP group



# K

## Understanding Consolidation

### K.1 Introduction

Consolidation is discussed in the sections on using consolidation in the Monitoring chapter (sections 12.4.3 and 12.5.2).

However, it may be confusing to have the concept of consolidation discussed in the same place as the use of consolidation. Also, the algebra that appears in that discussion (page 439) may not appeal to people. There are many who would like an explanation that may be more intuitive, even if it is less rigorous..

Therefore, in this section a more informal and visual approach is taken to explain consolidation.

### K.2 What Is Consolidation?

Consolidation is the compression of data, for data values that have been measured over a fixed interval.

The compression is nothing particularly sophisticated. It is carried out by using applying a simple mathematical function: the average, the maximum, or the minimum.

### K.3 Raw Data And Consolidation

Suppose raw data is sampled every 2 minutes.

And the raw data values are consolidated every 10 minutes.

A visual representation of the data values available to the system is:

```
          --- time --->
raw:      | | | | | | | | | | | | | | | |
consolidated:  |         |         |         |         |
```

Here, every “|” indicates a data point, so that the visual shows 5 times as many raw data points as consolidated data values.

In the preceding visual it makes no sense to use consolidated data since the data values for raw data and consolidated data overlap. I.e., the more accurate raw data values exist for the entire period.

As time passes, the intention is to start dropping old raw data, to save space on the disk.

For example, for the first 20 minutes in the following visual, there are no longer raw data values available:

#### Example

```
          --- time --->
raw:      | | | | | | | | | | | | | | | |
consolidated:  |         |         |         |         |
```

But the consolidated data points for this period are still available to the system.

When the data values are plotted in Bright View graphs, periods without raw data values automatically have consolidated data values used.

So a combination of both data sources is used, which can be visually represented with:

#### Example

```

          --- time --->
plot:      |          |          | | | | | | | | | | | | | |

```

That behavior holds true for `cmsh` too.

The behavior illustrated in the last visual assumes that the cluster has been UP for long enough that raw data is being dropped.

In this case, “long enough” means at least 7 days.

However, because RLE (Run Length Encoding) is used to compress the sampled monitoring data values on disk, this minimal “long enough” time can be (much) longer than 7 days. It depends on how much the measurable that is being sampled is changing as each sample is taken. If it is not changing, then RLE can compress over a longer time period.

The `forks` metric changes very quickly, and thus can do little RLE compression. That makes it a good choice for demonstrating the kind of output that the preceding visuals imply.

## K.4 A Demonstration Of The Output

So, as a demonstration, the last 7 days for `forks` are now shown, with the data values in the middle elided:

#### Example

```
[bright80->device[bright80]]% dumpmonitoringdata -7d now forks
Timestamp                               Value                               Info
-----
2018/10/17 10:30:00                     2.76243 processes/s
2018/10/17 11:30:00                     2.52528 processes/s
2018/10/17 12:30:00                     2.53972 processes/s
...
2018/10/24 10:42:00                     2.66669 processes/s
2018/10/24 10:44:00                     2.63333 processes/s
2018/10/24 10:46:00                     2.64167 processes/s
```

The first part of the output shows samples listed every hour. These are the consolidated data values.

The last part of the output shows samples listed every 2 minutes. These are the raw data value values.

I.e.: consolidated data values are used beyond a certain time in the past.

If the administrator would like to explore this further, then displaying only consolidation values is possible in `cmsh` by using the `--consolidationinterval` option of the `dumpmonitoringdata` command:

#### Example

```
[bright80->device[bright80]]% dumpmonitoringdata --consolidationinterval 1h -7d now forks
Timestamp                               Value                               Info
-----
2019/01/07 11:39:06                     2.65704 processes/s
2019/01/07 12:30:00                     2.60111 processes/s
2019/01/07 13:30:00                     2.58328 processes/s
```

...

```
[bright80->device[bright80]]% dumpmonitoringdata --consolidationinterval 1d -7d now forks
```

Timestamp	Value	Info
2019/01/07 18:09:06	2.59586	processes/s
2019/01/08 13:00:00	2.58953	processes/s
2019/01/09 06:06:06	2.58854	processes/s

```
[bright80->device[bright80]]% dumpmonitoringdata --consolidationinterval 1w -7d now forks
```

Timestamp	Value	Info
2019/01/08 11:15:12.194	2.59113	processes/s