

53-1002600-01
28 September 2012



Brocade ICX 6650

Administration Guide

Supporting FastIron Software Release 07.5.00

BROCADE

Copyright © 2006-2012 Brocade Communications Systems, Inc. All Rights Reserved.

Brocade, Brocade Assurance, the B-wing symbol, BigIron, DCX, Fabric OS, FastIron, MLX, NetIron, SAN Health, ServerIron, TurboIron, VCS, and VDX are registered trademarks, and AnyIO, Brocade One, CloudPlex, Effortless Networking, ICX, NET Health, OpenScript, and The Effortless Network are trademarks of Brocade Communications Systems, Inc., in the United States and/or in other countries. Other brands, products, or service names mentioned may be trademarks of their respective owners.

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Brocade. Brocade reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Brocade sales office for information on feature and product availability. Export of technical data contained in this document may require an export license from the United States government.

The authors and Brocade Communications Systems, Inc. shall have no liability or responsibility to any person or entity with respect to any loss, cost, liability, or damages arising from the information contained in this book or the computer programs that accompany it.

The product described by this document may contain "open source" software covered by the GNU General Public License or other open source license agreements. To find out which open source software is included in Brocade products, view the licensing terms applicable to the open source software, and obtain a copy of the programming source code, please visit <http://www.brocade.com/support/oscd>.

Brocade Communications Systems, Incorporated

Corporate and Latin American Headquarters
Brocade Communications Systems, Inc.
130 Holger Way
San Jose, CA 95134
Tel: 1-408-333-8000
Fax: 1-408-333-8101
E-mail: info@brocade.com

Asia-Pacific Headquarters
Brocade Communications Systems China HK, Ltd.
No. 1 Guanghua Road
Chao Yang District
Units 2718 and 2818
Beijing 100020, China
Tel: +8610 6588 8888
Fax: +8610 6588 9999
E-mail: china-info@brocade.com

European Headquarters
Brocade Communications Switzerland Sàrl
Centre Swissair
Tour B - 4ème étage
29, Route de l'Aéroport
Case Postale 105
CH-1215 Genève 15
Switzerland
Tel: +41 22 799 5640
Fax: +41 22 799 5641
E-mail: emea-info@brocade.com

Asia-Pacific Headquarters
Brocade Communications Systems Co., Ltd. (Shenzhen WFOE)
Citic Plaza
No. 233 Tian He Road North
Unit 1308 - 13th Floor
Guangzhou, China
Tel: +8620 3891 2000
Fax: +8620 3891 2111
E-mail: china-info@brocade.com

Document History

Title	Publication number	Summary of changes	Date
<i>Brocade ICX 6650 Administration Guide</i>	53-1002600-01	New document	September 2012

Contents

About This Document

Audience	xiii
Supported hardware and software	xiii
Brocade ICX 6650 slot and port numbering	xiii
Document conventions	xiv
Notice to the reader	xv
Related publications	xvi
Additional information	xvi
Getting technical help	xvii
Document feedback	xvii

Chapter 1

Management Applications

Management port overview	1
How the management port works	1
CLI Commands for use with the management port	2
Logging on through the CLI	3
Online help	4
Command completion	4
Scroll control	4
Line editing commands	5
Using slot number, and port number with CLI commands	5
CLI nomenclature on Brocade ICX 6650 models	6
Searching and filtering output from CLI commands	6
Using special characters in regular expressions	8
Creating an alias for a CLI command	10

Chapter 2

Basic Software Features

Basic system parameter configuration	14
Entering system administration information	15
SNMP parameter configuration	15
Displaying virtual routing interface statistics	18
Disabling Syslog messages and traps for CLI access	18
Cancelling an outbound Telnet session	20
Specifying an SNMP server	20

Configuring the device as an SNMP server	23
Displaying SNMP server information	25
Enabling broadcast mode for an SNMP client	25
Setting the system clock	26
Limiting broadcast, multicast, and unknown unicast traffic. . .	28
CLI banner configuration	28
Local MAC address for Layer 2 management traffic	30
Basic port parameter configuration	31
Assigning a port name	31
Port speed and duplex mode modification	32
Downgrading the Brocade ICX 6650 front panel ports from 10 GbE to 1 GbE port speed	33
Enabling auto-negotiation maximum port speed advertisement and down-shift	33
Modifying port duplex mode	34
Disabling or re-enabling a port	35
Flow control configuration	35
Symmetric flow control on Brocade ICX 6650 devices	37
Interpacket Gap (IPG) on a Brocade ICX 6650 switch.	39
Changing the Gbps fiber negotiation mode	39
Port priority (QoS) modification	40
Port flap dampening configuration	40
Port loop detection	43

Chapter 3

Operations, Administration, and Maintenance

OAM Overview	50
Software versions installed and running on a device.	50
Determining the flash image version running on the device ..	50
Displaying the boot image version running on the device	51
Displaying the image versions installed in flash memory.	51
Flash image verification	52
Image file types	53
Software upgrades	53
Viewing the contents of flash files	53
Using SNMP to upgrade software	54
Software reboot	56
Software boot configuration notes	56
Displaying the boot preference	56
Loading and saving configuration files	57
Replacing the startup configuration with the running configuration	58
Replacing the running configuration with the startup configuration	58
Logging changes to the startup-config file	58
Copying a configuration file to or from a TFTP server	59
Dynamic configuration loading	59
Maximum file sizes for startup-config file and running-config .	61

Loading and saving configuration files with IPv6	62
Using the IPv6 copy command	62
Copying a file from an IPv6 TFTP server	63
IPv6 ncopy command	64
IPv6 TFTP server file upload	65
Using SNMP to save and load configuration information	66
Erasing image and configuration files	67
System reload scheduling	67
Reloading at a specific time	67
Reloading after a specific amount of time	68
Displaying the amount of time remaining before a scheduled reload	68
Canceling a scheduled reload	68
Diagnostic error codes and remedies for TFTP transfers	68
Network connectivity testing	69
Pinging an IPv4 address	69
Tracing an IPv4 route	71

Chapter 4

Ports on Demand Licensing

Ports on Demand Overview	73
Ports on Demand terminology	74
PoD licensing rules	74
PoD licensing configuration tasks	74
Obtaining a PoD license	75
Viewing PoD licensing information from the Brocade software portal	80
Transferring a PoD license	82
Syslog message information	82
Ports on Demand Licensing	82
Front panel PoD	82
Rear panel Flexible Ports on Demand	83
PoD licenses	83
Enabling ports on the front panel	84
Deleting a ICX6650-10G-LIC-POD license	86
Enabling ports on the rear panel	87
Disabling the FPoD ports on the rear panel	89
Deleting a 10 GbE or 40 GbE license	90
Viewing information about PoD licenses	91
Viewing the LID and the software packages installed in the device	91
Displaying general license information for PoD ports	92
Displaying the license configuration for PoD ports for the Brocade ICX 6650	94
Configuration considerations when configuring PoD for Brocade ICX 6650 devices	96

Chapter 5

IPv6 Configuration on Brocade ICX 6650 Switch

Full Layer 3 IPv6 feature support	101
IPv6 addressing overview	101
IPv6 address types.	102
IPv6 stateless auto-configuration	104
IPv6 CLI command support	104
IPv6 host address on a Layer 2 switch	106
Configuring a global or site-local IPv6 address with a manually configured interface ID	107
Configuring a link-local IPv6 address as a system-wide address for a switch.	107
Configuring the management port for an IPv6 automatic address configuration	108
Configuring basic IPv6 connectivity on a Layer 3 switch.	108
Enabling IPv6 routing.	108
IPv6 configuration on each router interface	108
Configuring IPv4 and IPv6 protocol stacks.	111
IPv6 management on Brocade ICX 6650 devices (IPv6 host support)	112
Configuring IPv6 management ACLs	112
Restricting SNMP access to an IPv6 node.	113
Specifying an IPv6 SNMP trap receiver	113
Configuring SNMP V3 over IPv6	113
Configuring SNTP over IPv6.	113
Secure Shell, SCP, and IPv6	113
IPv6 Telnet	114
IPv6 traceroute.	114
Configuring name-to-IPv6 address resolution using IPv6 DNS resolver	115
Defining an IPv6 DNS entry.	115
Pinging an IPv6 address	116
Configuring an IPv6 Syslog server	117
Viewing IPv6 SNMP server addresses	117
Disabling router advertisement and solicitation messages	118
Disabling IPv6 on a Layer 2 switch.	118
Static IPv6 route configuration.	118
IPv6 over IPv4 tunnels	121
IPv6 over IPv4 tunnel configuration notes.	121
Configuring a manual IPv6 tunnel	121
Clearing IPv6 tunnel statistics	122
Displaying IPv6 tunnel information.	123
ECMP load sharing for IPv6	126
Disabling or re-enabling ECMP load sharing for IPv6	127
Changing the maximum load sharing paths for IPv6	127
Enabling support for network-based ECMP load sharing for IPv6	127
Displaying ECMP load-sharing information for IPv6	127

IPv6 ICMP feature configuration	128
Configuring ICMP rate limiting	128
Enabling IPv6 ICMP redirect messages	129
IPv6 neighbor discovery configuration	129
IPv6 neighbor discovery configuration notes	130
Neighbor solicitation and advertisement messages	130
Router advertisement and solicitation messages	131
Neighbor redirect messages	131
Setting neighbor solicitation parameters for duplicate address detection	131
Setting IPv6 router advertisement parameters	132
Prefixes advertised in IPv6 router advertisement messages	134
Setting flags in IPv6 router advertisement messages	135
Enabling and disabling IPv6 router advertisements	135
Configuring reachable time for remote IPv6 nodes	136
IPv6 MTU	136
Configuration notes and feature limitations for IPv6 MTU	136
Changing the IPv6 MTU	137
Static neighbor entries configuration	137
Limiting the number of hops an IPv6 packet can traverse	138
IPv6 source routing security enhancements	138
Clearing global IPv6 information	138
Clearing the IPv6 cache	139
Clearing IPv6 neighbor information	139
Clearing IPv6 routes from the IPv6 route table	140
Clearing IPv6 traffic statistics	140
Displaying global IPv6 information	140
Displaying IPv6 cache information	140
Displaying IPv6 interface information	141
Displaying IPv6 neighbor information	144
Displaying the IPv6 route table	145
Displaying local IPv6 routers	146
Displaying IPv6 TCP information	147
Displaying IPv6 traffic statistics	151

Chapter 6

SNMP Access

SNMP overview	155
SNMP community strings	156
Encryption of SNMP community strings	156
Adding an SNMP community string	156
Displaying the SNMP community strings	158

User-based security model	159
Configuring your NMS	159
Configuring SNMP version 3 on Brocade ICX 6650 devices.	159
Defining the engine id	159
Defining an SNMP group	160
Defining an SNMP user account	161
Defining SNMP views	163
SNMP version 3 traps	164
Defining an SNMP group and specifying which view is notified of traps	164
Defining the UDP port for SNMP v3 traps	165
Trap MIB changes	165
Specifying an IPv6 host as an SNMP trap receiver	166
SNMP v3 over IPv6	166
Specifying an IPv6 host as an SNMP trap receiver	166
Viewing IPv6 SNMP server addresses	167
Displaying SNMP Information	167
Displaying the Engine ID	167
Displaying SNMP groups	168
Displaying user information	168
Interpreting varbinds in report packets	168
SNMP v3 configuration examples	169
Simple SNMP v3 configuration	169
More detailed SNMP v3 configuration	169

Chapter 7

Foundry Discovery Protocol (FDP) and Cisco Discovery Protocol (CDP) Packets

FDP Overview	171
FDP configuration	172
Displaying FDP information	173
Clearing FDP and CDP information	176
CDP packets	177
Enabling interception of CDP packets globally	177
Enabling interception of CDP packets on an interface	177
Displaying CDP information	178
Clearing CDP information	180

Chapter 8

LLDP and LLDP-MED

LLDP terms used in this chapter	182
LLDP overview	183
Benefits of LLDP	184
LLDP-MED overview	184
Benefits of LLDP-MED	185
LLDP-MED class	186

General LLDP operating principles	186
LLDP operating modes	186
LLDP packets	187
TLV support	188
MIB support	191
Syslog messages	191
LLDP configuration	192
LLDP configuration notes and considerations	192
Enabling and disabling LLDP	193
Enabling support for tagged LLDP packets	193
Changing a port LLDP operating mode	193
Maximum number of LLDP neighbors	195
Enabling LLDP SNMP notifications and Syslog messages ..	196
Changing the minimum time between LLDP transmissions ..	197
Changing the interval between regular LLDP transmissions ..	198
Changing the holdtime multiplier for transmit TTL	198
Changing the minimum time between port reinitializations ..	199
LLDP TLVs advertised by the Brocade device	199
LLDP-MED configuration	206
Enabling LLDP-MED	207
Enabling SNMP notifications and Syslog messages for LLDP-MED topology changes	207
Changing the fast start repeat count	208
Defining a location id	209
Defining an LLDP-MED network policy	215
LLDP-MED attributes advertised by the Brocade device	217
Displaying LLDP statistics and configuration settings	218
LLDP configuration summary	218
Displaying LLDP statistics	219
Displaying LLDP neighbors	221
Displaying LLDP neighbors detail	222
Displaying LLDP configuration details	222
Resetting LLDP statistics	223
Clearing cached LLDP neighbor information	224

Chapter 9

Hardware Component Monitoring

Digital optical monitoring	225
Digital optical monitoring configuration limitations	225
Enabling digital optical monitoring	225
Setting the alarm interval	226
Displaying information about installed media	226
Viewing optical monitoring information	228
Syslog messages for optical transceivers	230

Chapter 10

Syslog

About Syslog messages	232
-----------------------------	-----

Displaying Syslog messages.	232
Enabling real-time display of Syslog messages.	233
Enabling real-time display for a Telnet or SSH session.	233
Displaying real-time Syslog messages.	234
Syslog service configuration.	234
Displaying the Syslog configuration.	234
Disabling or re-enabling Syslog.	238
Specifying a Syslog server.	238
Specifying an additional Syslog server.	239
Disabling logging of a message level.	239
Changing the number of entries the local buffer can hold.	239
Changing the log facility.	240
Displaying interface names in Syslog messages.	241
Displaying TCP or UDP port numbers in Syslog messages.	241
Retaining Syslog messages after a soft reboot.	242
Clearing the Syslog messages from the local buffer.	242

Chapter 11

Network Monitoring

Basic system management.	243
Viewing system information.	243
Viewing configuration information.	244
Viewing port statistics.	245
Viewing STP statistics.	247
Clearing statistics.	248
Viewing egress queue counters.	249
RMON support.	250
Maximum number of entries allowed in the RMON control table.	250
Statistics (RMON group 1).	251
History (RMON group 2).	253
Alarm (RMON group 3).	253
Event (RMON group 9).	253
sFlow.	254
sFlow version 5.	254
sFlow support for IPv6 packets.	255
sFlow configuration considerations.	256
Configuring and enabling sFlow.	257
Enabling sFlow forwarding.	263
sFlow version 5 feature configuration.	264
Displaying sFlow information.	267
Utilization list for an uplink port.	270
Utilization list for an uplink port command syntax.	270
Displaying utilization percentages for an uplink.	271

Appendix A	Syslog messages	
Appendix B	NIAP-CCEVS Certification	
	NIAP-CCEVS certified Brocade equipment and Ironware releases299
	Local user password changes299
Index		

About This Document

The Brocade ICX 6650 is a ToR (Top of Rack) Ethernet switch for campus LAN and classic Ethernet data center environments.

Audience

This document is designed for system administrators with a working knowledge of Layer 2 and Layer 3 switching and routing.

If you are using a Brocade Layer 3 Switch, you should be familiar with the following protocols if applicable to your network: IP, RIP, OSPF, BGP, ISIS, PIM, and VRRP.

Supported hardware and software


This document is specific to the Brocade ICX 6650 running FastIron 7.5.00.

Brocade ICX 6650 slot and port numbering


Many CLI commands require users to enter port numbers as part of the command syntax, and many **show** command outputs display port numbers. The port numbers are entered and displayed in stack-unit/slot number/port number format. In all Brocade ICX 6650 inputs and outputs, the stack-unit number is always 1.

The ICX 6650 contains the following slots and Ethernet ports:

- Slot 1 is located on the front of the ICX 6650 device and contains ports 1 through 56. Ports 1 through 32 are 10 GbE. Ports 33 through 56 are 1/10 GbE SFP+ ports. Refer to the following figure.



- Slot 2 is located on the back of the ICX 6650 device and contains ports 1 through 3 on the top row and port 4 on the bottom row. These ports are 2x40 GbE QSFP+. Refer to the following figure.



- Slot 3 is located on the back of the ICX 6650 device and contains ports 1 through 8. These ports are 4 x 10 GbE breakout ports and require the use of a breakout cable. Refer to the previous figure.

Document conventions

This section describes text formatting conventions and important notice formats used in this document.

Text formatting

The narrative-text formatting conventions that are used are as follows:

bold text	Identifies command names Identifies the names of user-manipulated GUI elements Identifies keywords and operands Identifies text to enter at the GUI or CLI
<i>italic text</i>	Provides emphasis Identifies variables Identifies paths and Internet addresses Identifies document titles
<code>code text</code>	Identifies CLI output Identifies command syntax examples

For readability, command names in the narrative portions of this guide are presented in mixed lettercase: for example, **switchShow**. In actual examples, command lettercase is all lowercase.

Command syntax conventions

Command syntax in this manual follows these conventions:

command	Commands are printed in bold.
--option, option	Command options are printed in bold.
-argument, arg	Arguments.

[]	Optional elements appear in brackets.
<i>variable</i>	Variables are printed in italics. In the help pages, values are <u>underlined</u> or enclosed in angled brackets < >.
...	Repeat the previous element, for example “member[;member...]”
value	Fixed values following arguments are printed in plain font. For example, --show WWN
	Boolean. Elements are exclusive. Example: --show -mode egress ingress

Notes, cautions, and warnings

The following notices and statements are used in this manual. They are listed below in order of increasing severity of potential hazards.

NOTE

A note provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

ATTENTION

An Attention statement indicates potential damage to hardware or data.



CAUTION

A Caution statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



DANGER

A Danger statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

Notice to the reader

This document might contain references to the trademarks of the following corporations. These trademarks are the properties of their respective companies and corporations.

These references are made for informational purposes only.

Corporation	Referenced Trademarks and Products
Microsoft Corporation	Windows, Windows NT, Internet Explorer
Oracle Corporation	Oracle, Java
Netscape Communications Corporation	Netscape
Mozilla Corporation	Mozilla Firefox

Corporation	Referenced Trademarks and Products
Sun Microsystems, Inc.	Sun, Solaris
Red Hat, Inc.	Red Hat, Red Hat Network, Maximum RPM, Linux Undercover

Related publications

The following Brocade documents supplement the information in this guide:

- *Brocade ICX 6650 Release Notes*
- *Brocade ICX 6650 Hardware Installation Guide New*
- *Brocade ICX 6650 Administration Guide*
- *Brocade ICX 6650 Platform and Layer 2 Configuration Guide*
- *Brocade ICX 6650 Layer 3 Routing Configuration Guide*
- *Brocade ICX 6650 Security Configuration Guide*
- *Brocade ICX 6650 IP Multicast Configuration Guide*
- *Brocade ICX 6650 Diagnostic Reference*
- *Unified IP MIB Reference*
- *Ports-on-Demand Licensing for the Brocade ICX 6650*

The latest versions of these guides are posted at <http://www.brocade.com/ethernetproducts>.

Additional information

This section lists additional Brocade and industry-specific documentation that you might find helpful.

Brocade resources

To get up-to-the-minute information, go to <http://my.brocade.com> to register at no cost for a user ID and password.

White papers, online demonstrations, and data sheets are available through the Brocade website at:

<http://www.brocade.com/products-solutions/products/index.page>

For additional Brocade documentation, visit the Brocade website:

<http://www.brocade.com>

Release notes are available on the MyBrocade website.

Other industry resources

For additional resource information, visit the Technical Committee T11 website. This website provides interface standards for high-performance and mass storage applications for Fibre Channel, storage management, and other applications:

<http://www.t11.org>

For information about the Fibre Channel industry, visit the Fibre Channel Industry Association website:

<http://www.fibrechannel.org>

Getting technical help

To contact Technical Support, go to

<http://www.brocade.com/services-support/index.page>

for the latest e-mail and telephone contact information.

Document feedback

Quality is our first concern at Brocade and we have made every effort to ensure the accuracy and completeness of this document. However, if you find an error or an omission, or you think that a topic needs further development, we want to hear from you. Forward your feedback to:

documentation@brocade.com

Provide the title and version number of the document and as much detail as possible about your comment, including the topic heading and page number and your suggestions for improvement.

Brocade ICX 6650 slot and port numbering

In this chapter

- [Management port overview](#) 1
- [Logging on through the CLI](#) 3
- [Using slot number, and port number with CLI commands](#) 5

[Table 1](#) lists the Brocade ICX 6650 switch and the management application features the switch supports. These features are supported in full Layer 3 software images.

TABLE 1 Supported management application features

Feature	Brocade ICX 6650
Management port	Yes
industry-standard Command Line Interface (CLI), including support for: <ul style="list-style-type: none">• Serial and Telnet access• Alias command• On-line help• Command completion• Scroll control• Line editing• Searching and filtering output• Special characters	Yes

Management port overview

The management port is an out-of-band port that customers can use to manage their devices without interfering with the in-band ports. The management port is widely used to download images and configurations and for Telnet sessions.

How the management port works

The following rules apply to management ports:

- Only packets that are specifically addressed to the management port MAC address or the broadcast MAC address are processed by the Layer 2 Switch or Layer 3 Switch. All other packets are filtered out.
- No packet received on a management port is sent to any in-band ports, and no packets received on in-band ports are sent to a management port.
- A management port is not part of any VLAN
- Protocols are not supported on the management port.

1 Management port overview

- Creating a management VLAN disables the management port on the device.

For switches, any in-band port may be used for management purposes. A router sends Layer 3 packets using the MAC address of the port as the source MAC address.

CLI Commands for use with the management port

The following CLI commands can be used with a management port.

To display the current configuration, use the **show running-config interface management** command.

```
Brocade(config-if-mgmt)#ip addr 10.44.9.64/24
Brocade(config)#show running-config interface management 1
interface management 1
ip address 10.44.9.64 255.255.255.0
```

Syntax: show running-config interface management <num>

To display the current configuration, use the **show interfaces management** command.

```
Brocade(config)#show interfaces management 1
GigEthernetmgmt1 is up, line protocol is up
Hardware is GigEthernet, address is 748e.f80c.5f40(bia 748e.f80c.5f40a)
Configured speed auto, actual 1Gbit, configured duplex fdx, actual fdx
Configured mdi mode AUTO, actual none
BPRU guard is disabled, ROOT protect is disabled
Link Error Dampening is Disabled
STP configured to OFF, priority is level0, mac-learning is enabled
Flow Control is config disabled, oper enabled
Mirror disabled, Monitor disabled
Not member of any active trunks
Not member of any configured trunks
No port name
IPG MII 0 bits-time, IPG GMII 0 bits-time
IP MTU 1500 bytes
300 second input rate: 83728 bits/sec, 130 packets/sec, 0.01% utilization
300 second output rate: 24 bits/sec, 0 packets/sec, 0.00% utilization
39926 packets input, 3210077 bytes, 0 no buffer
Received 4353 broadcasts, 32503 multicasts, 370 unicasts
0 input errors, 0 CRC, 0 frame, 0 ignored
0 runs, 0 giants
22 packets output, 1540 bytes, 0 underruns
Transmitted 0 broadcasts, 6 multicasts, 16 unicasts
0 output errors, 0 collisions
```

Syntax: show interfaces management <num>

To display the management interface information in brief form, enter the **show interfaces brief management** command.

```
Brocade(config)#show interfaces brief management 1
```

Port	Link	State	Dupl	Speed	Trunk	Tag	Pri	MAC	Name
mgmt1	Up	None	Full	1G	None	No	0	748e.f80c.5f40	

Syntax: show interfaces brief management <num>

To display management port statistics, enter the **show statistics management** command.

```
Brocade(config)#show statistics management 1
Port   Link   State   Dupl   Speed   Trunk   Tag   Pri   MAC           Name
mgmt1  Up     None    Full   1G      None    No    0     748e.f80c.5f40

Port mgmt1 Counters:
    InOctets3210941OutOctets1540
    InPkts39939OutPackets22
InBroadcastPkts4355OutbroadcastPkts0
InMultiastPkts35214OutMulticastPkts6
InUnicastPkts370OutUnicastPkts16
InBadPkts0
InFragments0
InDiscards0OutErrors0
CRC      0   Collisions0
InErrors0 LateCollisions0
InGiantPkts0
InShortPkts0
InJabber0
InFlowCtrlPkts0OutFlowCtrlPkts0
InBitsPerSec83728OutBitsPerSec24
InPktsPerSec130OutPktsPerSec0
InUtilization0.01%OutUtilization0.00%
```

Syntax: **show statistics management** <num>

To display the management interface statistics in brief form, enter the **show statistics brief management** command.

```
Brocade(config)#show statistics brief management 1
PortIn PktsOut PktsTrunkIn ErrorsOut Errors
mgmt1399462200

Total399452200
```

Syntax: **show statistics brief management** <num>

Logging on through the CLI

Once an IP address is assigned to a Brocade device running Layer 2 software or to an interface on the Brocade device running Layer 3 software, you can access the CLI either through the direct serial connection to the device or through a local or remote Telnet session.

You can initiate a local Telnet or SNMP connection by attaching a cable to a port and specifying the assigned management station IP address.

The commands in the CLI are organized into the following levels:

- **User EXEC** – Lets you display information and perform basic tasks such as pings and traceroutes.
- **Privileged EXEC** – Lets you use the same commands as those at the User EXEC level plus configuration commands that do not require saving the changes to the system-config file.

1 Logging on through the CLI

- **CONFIG** – Lets you make configuration changes to the device. To save the changes across reboots, you need to save them to the system-config file. The CONFIG level contains sub-levels for individual ports, for VLANs, for routing protocols, and other configuration areas.

NOTE

By default, any user who can open a serial or Telnet connection to the Brocade device can access all these CLI levels. To secure access, you can configure Enable passwords or local user accounts, or you can configure the device to use a RADIUS or TACACS/TACACS+ server for authentication. refer to the Brocade ICX 6650 Switch Security Configuration Guide.

Online help

To display a list of available commands or command options, enter “?” or press Tab. If you have not entered part of a command at the command prompt, all the commands supported at the current CLI level are listed. If you enter part of a command, then enter “?” or press Tab, the CLI lists the options you can enter at this point in the command string.

If you enter an invalid command followed by ?, a message appears indicating the command was unrecognized. An example is given below.

```
Brocade(config)#rooter ip
Unrecognized command
```

Command completion

The CLI supports command completion, so you do not need to enter the entire name of a command or option. As long as you enter enough characters of the command or option name to avoid ambiguity with other commands or options, the CLI understands what you are typing.

Scroll control

By default, the CLI uses a page mode to paginate displays that are longer than the number of rows in your terminal emulation window. For example, if you display a list of all the commands at the global CONFIG level but your terminal emulation window does not have enough rows to display them all at once, the page mode stops the display and lists your choices for continuing the display. An example is given below.

```
aaa
all-client
appletalk
arp
boot
some lines omitted for brevity...

ipx
lock-address
logging
mac
--More--, next page: Space, next line:
Return key, quit: Control-c
```

The software provides the following scrolling options:

- Press the **Space bar** to display the next page (one screen at a time).

- Press the **Return** or **Enter** key to display the next line (one line at a time).
- Press **Ctrl+C** or **Ctrl+Q** to cancel the display.

Line editing commands

The CLI supports the following line editing commands. To enter a line-editing command, use the CTRL+key combination for the command by pressing and holding the CTRL key, then pressing the letter associated with the command.

TABLE 2 CLI line editing commands

Ctrl+Key combination	Description
Ctrl+A	Moves to the first character on the command line.
Ctrl+B	Moves the cursor back one character.
Ctrl+C	Escapes and terminates command prompts and ongoing tasks (such as lengthy displays), and displays a fresh command prompt.
Ctrl+D	Deletes the character at the cursor.
Ctrl+E	Moves to the end of the current command line.
Ctrl+F	Moves the cursor forward one character.
Ctrl+K	Deletes all characters from the cursor to the end of the command line.
Ctrl+L; Ctrl+R	Repeats the current command line on a new line.
Ctrl+N	Enters the next command line in the history buffer.
Ctrl+P	Enters the previous command line in the history buffer.
Ctrl+U; Ctrl+X	Deletes all characters from the cursor to the beginning of the command line.
Ctrl+W	Deletes the last word you typed.
Ctrl+Z	Moves from any CONFIG level of the CLI to the Privileged EXEC level; at the Privileged EXEC level, moves to the User EXEC level.

Using slot number, and port number with CLI commands

Many CLI commands require users to enter port numbers as part of the command syntax, and many **show** command outputs display port numbers. The port numbers are entered in the following format: *stack-unit/slot/port*.

The ports are labelled on the front panels of the devices.

CLI nomenclature on Brocade ICX 6650 models

When you enter CLI commands that include the port number as part of the syntax, you must use the stack unit/slot number/port number format. The unit number is 1. For example, the following commands change the CLI from the global CONFIG level to the configuration level for the first port on the device:

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e1000-1/1/1)#
```

Syntax: `ethernet <stack-unit>/<slot>/<port>`

Searching and filtering output from CLI commands

You can filter CLI output from **show** commands and at the –More– prompt. You can search for individual characters, strings, or construct complex regular expressions to filter the output.

Searching and filtering output from Show commands

You can filter output from **show** commands to display lines containing a specified string, lines that do not contain a specified string, or output starting with a line containing a specified string. The search string is a regular expression consisting of a single character or string of characters. You can use special characters to construct complex regular expressions. Refer to [“Using special characters in regular expressions”](#) on page 8 for information on special characters used with regular expressions.

Displaying lines containing a specified string

The following command filters the output of the **show interface** command for port 1/1/2 so it displays only lines containing the word “Internet”. This command can be used to display the IP address of the interface.

```
Brocade#show interface ethernet 1/1/2 | include Internet
Internet address is 192.168.1.11/24, MTU 1518 bytes, encapsulation ethernet
```

Syntax: `<show-command> | include <regular-expression>`

NOTE

The vertical bar (|) is part of the command.

Note that the regular expression specified as the search string is case sensitive. In the example above, a search string of “Internet” would match the line containing the IP address, but a search string of “internet” would not.

Displaying lines that do not contain a specified string

The following command filters the output of the **show who** command so it displays only lines that do not contain the word “closed”. This command can be used to display open connections to the Brocade device.


```

Brocade#show who | exclude closed
Console connections:
    established
    you are connecting to this session
    2 seconds in idle
Telnet connections (inbound):
    1      established, client ip address 192.168.9.37
    27 seconds in idle
Telnet connection (outbound):
SSH connections:

```

Syntax: <show-command> | **exclude** <regular-expression>

Displaying lines starting with a specified string

The following command filters the output of the **show who** command so it displays output starting with the first line that contains the word “SSH”. This command can be used to display information about SSH connections to the Brocade device.

```

Brocade#show who | begin SSH
SSH connections:
    1      established, client ip address 192.168.9.210
    7 seconds in idle
    2      closed
    3      closed
    4      closed
    5      closed

```

Syntax: <show-command> | **begin** <regular-expression>

Searching and filtering output at the --More-- prompt

The --More-- prompt displays when output extends beyond a single page. From this prompt, you can press the Space bar to display the next page, the Return or Enter key to display the next line, or Ctrl+C or Q to cancel the display. In addition, you can search and filter output from this prompt.

At the --More-- prompt, you can press the forward slash key (/) and then enter a search string. The Brocade device displays output starting from the first line that contains the search string, similar to the **begin** option for **show** commands. An example is given below.

```

--More--, next page: Space, next line: Return key, quit: Control-c
/telnet

```

The results of the search are displayed.

```

searching...
telnet           Telnet by name or IP address
temperature      temperature sensor commands
terminal         display syslog
traceroute       TraceRoute to IP node
undebug          Disable debugging functions (see also 'debug')
undetele         Undetele flash card files
whois            WHOIS lookup
write            Write running configuration to flash or terminal

```

1 Using slot number, and port number with CLI commands

To display lines containing only a specified search string (similar to the **include** option for **show** commands) press the plus sign key (+) at the **--More--** prompt and then enter the search string.

```
--More--, next page: Space, next line: Return key, quit: Control-c
+telnet
```

The filtered results are displayed.

```
filtering...
telnet                      Telnet by name or IP address
```

To display lines that do not contain a specified search string (similar to the **exclude** option for **show** commands) press the minus sign key (-) at the **--More--** prompt and then enter the search string.

```
--More--, next page: Space, next line: Return key, quit: Control-c
-telnet
```

The filtered results are displayed.

```
filtering...
temperature                temperature sensor commands
terminal                   display syslog
traceroute                 TraceRoute to IP node
undebug                    Disable debugging functions (see also 'debug')
undetele                   Undetele flash card files
whois                      WHOIS lookup
write                      Write running configuration to flash or terminal
```

As with the commands for filtering output from **show** commands, the search string is a regular expression consisting of a single character or string of characters. You can use special characters to construct complex regular expressions. See the next section for information on special characters used with regular expressions.

Using special characters in regular expressions

You use a regular expression to specify a single character or multiple characters as a search string. In addition, you can include special characters that influence the way the software matches the output against the search string. These special characters are listed in the following table.

TABLE 3 Special characters for regular expressions

Character	Operation
.	The period matches on any single character, including a blank space. For example, the following regular expression matches "aaz", "abz", "acz", and so on, but not just "az": a.z
*	The asterisk matches on zero or more sequential instances of a pattern. For example, the following regular expression matches output that contains the string "abc", followed by zero or more Xs: abcX*

TABLE 3 Special characters for regular expressions (Continued)

Character	Operation
+	<p>The plus sign matches on one or more sequential instances of a pattern. For example, the following regular expression matches output that contains "de", followed by a sequence of "g"s, such as "deg", "degg", "deggg", and so on:</p> <p>deg+</p>
?	<p>The question mark matches on zero occurrences or one occurrence of a pattern. For example, the following regular expression matches output that contains "dg" or "deg":</p> <p>de?g</p> <p>NOTE: Normally when you type a question mark, the CLI lists the commands or options at that CLI level that begin with the character or string you entered. However, if you enter Ctrl+V and then type a question mark, the question mark is inserted into the command line, allowing you to use it as part of a regular expression.</p>
^	<p>A caret (when not used within brackets) matches on the beginning of an input string. For example, the following regular expression matches output that begins with "deg":</p> <p>^deg</p>
\$	<p>A dollar sign matches on the end of an input string. For example, the following regular expression matches output that ends with "deg":</p> <p>deg\$</p>
_	<p>An underscore matches on one or more of the following:</p> <ul style="list-style-type: none"> • , (comma) • { (left curly brace) • } (right curly brace) • ((left parenthesis) •) (right parenthesis) • The beginning of the input string • The end of the input string • A blank space <p>For example, the following regular expression matches on "100" but not on "1002", "2100", and so on.</p> <p>_100_</p>
[]	<p>Square brackets enclose a range of single-character patterns. For example, the following regular expression matches output that contains "1", "2", "3", "4", or "5":</p> <p>[1-5]</p> <p>You can use the following expression symbols within the brackets. These symbols are allowed only inside the brackets.</p> <ul style="list-style-type: none"> • ^ – The caret matches on any characters except the ones in the brackets. For example, the following regular expression matches output that does not contain "1", "2", "3", "4", or "5": <p>[^1-5]</p> <ul style="list-style-type: none"> • - The hyphen separates the beginning and ending of a range of characters. A match occurs if any of the characters within the range is present. See the example above.
	<p>A vertical bar separates two alternative values or sets of values. The output can match one or the other value. For example, the following regular expression matches output that contains either "abc" or "defg":</p> <p>abc defg</p>
()	<p>Parentheses allow you to create complex expressions. For example, the following complex expression matches on "abc", "abcabc", or "defg", but not on "abcdefgdefg":</p> <p>((abc)+) ((defg)?)</p>

1 Using slot number, and port number with CLI commands

If you want to filter for a special character instead of using the special character as described in the table above, enter “\” (backslash) in front of the character. For example, to filter on output containing an asterisk, enter the asterisk portion of the regular expression as “*”.

```
Brocade#show ip route bgp | include \*
```

Creating an alias for a CLI command

You can create **aliases** for CLI commands. An alias serves as a shorthand version of a longer CLI command. For example, you can create an alias called **shoro** for the CLI command **show ip route**. Then when you enter **shoro** at the command prompt, the **show ip route** command is executed.

To create an alias called **shoro** for the CLI command **show ip route**, enter the **alias shoro = show ip route** command.

```
Brocade(config)#alias shoro = show ip route
```

Syntax: [no] **alias** <alias-name> = <cli-command>

The <alias-name> must be a single word, without spaces.

After the alias is configured, entering **shoro** at either the Privileged EXEC or CONFIG levels of the CLI, executes the **show ip route** command.

To create an alias called **wrsbc** for the CLI command **copy running-config tftp 10.10.10.10 test.cfg**, enter the following command.

```
Brocade(config)#alias wrsbc = copy running-config tftp 10.10.10.10 test.cfg
```

To remove the **wrsbc** alias from the configuration, enter one of the following commands.

```
Brocade(config)#no alias wrsbc
```

or

```
Brocade(config)#unalias wrsbc
```

Syntax: **unalias** <alias-name>

The specified <alias-name> must be the name of an alias already configured on the Brocade device.

To display the aliases currently configured on the Brocade device, enter the following command at either the Privileged EXEC or CONFIG levels of the CLI.

```
Brocade#alias
      wrsbc      copy running-config tftp 10.10.10.10 test.cfg
      shoro      show ip route
```

Syntax: **alias**

Configuration notes for creating a command alias

The following configuration notes apply to this feature:

- You cannot include additional parameters with the alias at the command prompt. For example, after you create the **shoro** alias, **shoro bgp** would not be a valid command.

- If configured on the Brocade device, authentication, authorization, and accounting is performed on the actual command, not on the alias for the command.
- To save an alias definition to the startup-config file, use the **write memory** command.

1 Using slot number, and port number with CLI commands

Basic Software Features

In this chapter

- [Basic system parameter configuration](#) 14
- [Specifying an SNTP server](#) 20
- [Configuring the device as an SNTP server](#)..... 23
- [Basic port parameter configuration](#) 31

Table 4 lists the Brocade ICX 6650 switch and the basic software features the switch supports. These features are supported in full Layer 3 software images, except where explicitly noted.

TABLE 4 Supported basic software features

Feature	Brocade ICX 6650
Basic System Parameters	
System name, contact, and location	Yes
SNMP trap receiver and trap source address	Yes
Virtual routing interface statistics via SNMP	Yes
Disable Syslog messages and traps for CLI access	Yes
Cancelling an outbound Telnet session	Yes
System time using a Simple Network Time Protocol (SNTP) server or local system counter	Yes
Enabling broadcast mode for SNTP client	Yes
System clock	Yes
Packet-based broadcast, multicast, and unknown-unicast limits	Yes
CLI banners	Yes
Local MAC address for Layer 2 management traffic	Yes
Basic Port Parameters	
Port name	Yes
10/100/1000 port speed	Yes
Auto-negotiation	Yes
Auto-negotiation maximum port speed advertisement and down-shift	Yes

TABLE 4 Supported basic software features

Feature	Brocade ICX 6650
Duplex mode	Yes
Port status (enable or disable)	Yes
Flow control: <ul style="list-style-type: none"> Responds to flow control packets, but does not generate them 	Yes
Symmetric flow control <ul style="list-style-type: none"> Can transmit and receive 802.3x PAUSE frames 	Yes
Auto-negotiation and advertisement of flow control	Yes
Interpacket Gap (IPG) adjustment	Yes
Gbps fiber negotiate mode	Yes
QoS priority	Yes
Port flap dampening	Yes
Port loop detection	Yes

Basic system parameter configuration

Brocade devices are configured at the factory with default parameters that allow you to begin using the basic features of the system immediately. However, many of the advanced features such as VLANs or routing protocols for the device must first be enabled at the system (global) level before they can be configured. If you use the Command Line Interface (CLI) to configure system parameters, you can find these system level parameters at the Global CONFIG level of the CLI.

NOTE

Before assigning or modifying any router parameters, you must assign the IP subnet (interface) addresses for each port.

NOTE

For information about configuring IP addresses, DNS resolver, DHCP assist, and other IP-related parameters, refer to the Brocade ICX 6650 Switch Layer 3 Routing Configuration Guide.

NOTE

For information about the Syslog buffer and messages, refer to [Appendix A, “Syslog messages”](#).

The procedures in this section describe how to configure the basic system parameters listed in [Table 4](#).

Entering system administration information

You can configure a system name, contact, and location for a Brocade device and save the information locally in the configuration file for future reference. This information is not required for system operation but is suggested. When you configure a system name, the name replaces the default system name in the CLI command prompt.

The name, contact, and location each can be up to 255 alphanumeric characters.

Here is an example of how to configure a system name, system contact, and location.

```
Brocade(config)# hostname zappa
zappa(config)# snmp-server contact Support Services
zappa(config)# snmp-server location Centerville
zappa(config)# end
zappa# write memory
```

Syntax: `hostname <string>`

Syntax: `snmp-server contact <string>`

Syntax: `snmp-server location <string>`

The text strings can contain blanks. The SNMP text strings do not require quotation marks when they contain blanks but the host name does.

NOTE

The **chassis name** command does not change the CLI prompt. Instead, the command assigns an administrative ID to the device.

SNMP parameter configuration

Use the procedures in this section to perform the following configuration tasks:

- Specify a Simple Network Management Protocol (SNMP) trap receiver.
- Specify a source address and community string for all traps sent by the device.
- Change the holddown time for SNMP traps
- Disable individual SNMP traps. (All traps are enabled by default.)
- Disable traps for CLI access that is authenticated by a local user account, a RADIUS server, or a TACACS/TACACS+ server.

NOTE

To add and modify “get” (read-only) and “set” (read-write) community strings, refer to the Brocade ICX 6650 Switch Security Configuration Guide.

Specifying an SNMP trap receiver

You can specify a trap receiver to ensure that all SNMP traps sent by the Brocade device go to the same SNMP trap receiver or set of receivers, typically one or more host devices on the network. When you specify the host, you also specify a community string. The Brocade device sends all the SNMP traps to the specified hosts and includes the specified community string. Administrators can therefore filter for traps from a Brocade device based on IP address or community string.

2 Basic system parameter configuration

When you add a trap receiver, the software automatically encrypts the community string you associate with the receiver when the string is displayed by the CLI. If you want the software to show the community string in the clear, you must explicitly specify this when you add a trap receiver. In either case, the software does not encrypt the string in the SNMP traps sent to the receiver.

To specify the host to which the device sends all SNMP traps, use one of the following methods.

To add a trap receiver and encrypt the display of the community string, enter commands such as the following.

To specify an SNMP trap receiver and change the UDP port that will be used to receive traps, enter a command such as the following.

```
Brocade(config)# snmp-server host 2.2.2.2 0 mypublic port 200
Brocade(config)# write memory
```

Syntax: `snmp-server host <ip-addr> [0 | 1] <string> [port <value>]`

The `<ip-addr>` parameter specifies the IP address of the trap receiver.

The `0 | 1` parameter specifies whether you want the software to encrypt the string (**1**) or show the string in the clear (**0**). The default is **0**.

The `<string>` parameter specifies an SNMP community string configured on the Brocade device. The string can be a read-only string or a read-write string. The string is not used to authenticate access to the trap host but is instead a useful method for filtering traps on the host. For example, if you configure each of your Brocade devices that use the trap host to send a different community string, you can easily distinguish among the traps from different Brocade devices based on the community strings.

The command in the example above adds trap receiver 2.2.2.2 and configures the software to encrypt display of the community string. When you save the new community string to the startup-config file (using the **write memory** command), the software adds the following command to the file.

```
snmp-server host 2.2.2.2 1 <encrypted-string>
```

To add a trap receiver and configure the software to encrypt display of the community string in the CLI, enter commands such as the following.

```
Brocade(config)# snmp-server host 2.2.2.2 0 FastIron-12
Brocade(config)# write memory
```

The **port <value>** parameter allows you to specify which UDP port will be used by the trap receiver. This parameter allows you to configure several trap receivers in a system. With this parameter, a network management application can coexist in the same system. Brocade devices can be configured to send copies of traps to more than one network management application.

Specifying a single trap source

You can specify a single trap source to ensure that all SNMP traps sent by the Layer 3 switch use the same source IP address. For configuration details, refer to the Brocade ICX 6650 Switch Layer 3 Routing Configuration Guide.

Setting the SNMP trap holddown time

When a Brocade device starts up, the software waits for Layer 2 convergence (STP) and Layer 3 convergence (OSPF) before beginning to send SNMP traps to external SNMP servers. Until convergence occurs, the device might not be able to reach the servers, in which case the messages are lost.

By default, a Brocade device uses a one-minute holddown time to wait for the convergence to occur before starting to send SNMP traps. After the holddown time expires, the device sends the traps, including traps such as “cold start” or “warm start” that occur before the holddown time expires.

You can change the holddown time to a value from one second to ten minutes.

To change the holddown time for SNMP traps, enter a command such as the following at the global CONFIG level of the CLI.

```
Brocade(config)# snmp-server enable traps holddown-time 30
```

The command in this example changes the holddown time for SNMP traps to 30 seconds. The device waits 30 seconds to allow convergence in STP and OSPF before sending traps to the SNMP trap receiver.

Syntax: [no] snmp-server enable traps holddown-time <secs>

The <secs> parameter specifies the number of seconds and can be from 1 – 600 (ten minutes). The default is 60 seconds.

Disabling SNMP traps

Brocade devices come with SNMP trap generation enabled by default for all traps. You can selectively disable one or more of the following traps.

NOTE

By default, all SNMP traps are enabled at system startup.

SNMP Layer 2 traps

The following traps are generated on devices running Layer 2 software:

- SNMP authentication keys
- Power supply failure
- Fan failure
- Cold start
- Link up
- Link down
- Bridge new root
- Bridge topology change
- Locked address violation

SNMP Layer 3 traps

The following traps are generated on devices running Layer 3 software:

- SNMP authentication key

- Power supply failure
- Fan failure
- Cold start
- Link up
- Link down
- Bridge new root
- Bridge topology change
- Locked address violation
- BGP4
- OSPF
- VRRP
- VRRP-E

To stop link down occurrences from being reported, enter the following.

```
Brocade(config)# no snmp-server enable traps link-down
```

Syntax: [no] snmp-server enable traps <trap-type>

Displaying virtual routing interface statistics

You can enable SNMP to extract and display virtual routing interface statistics from the ifXTable (64-bit counters).

The following describes the limitations of this feature:

- The Brocade device counts traffic from all virtual interfaces (VEs). For example, in a configuration with two VLANs (VLAN 1 and VLAN 20) on port 1, when traffic is sent on VLAN 1, the counters (VE statistics) increase for both VE 1 and VE 20.
- The counters include all traffic on each virtual interface, even if the virtual interface is disabled.
- The counters include traffic that is denied by ACLs or MAC address filters.

To enable SNMP to display VE statistics, enter the **enable snmp ve-statistics** command.

```
Brocade(config)# enable snmp ve-statistics
```

Syntax: [no] enable snmp ve-statistics

Use the **no** form of the command to disable this feature once it is enabled.

Note that the above CLI command enables SNMP to display virtual interface statistics. It does not enable the CLI to display the statistics.

Disabling Syslog messages and traps for CLI access

Brocade devices send Syslog messages and SNMP traps when a user logs into or out of the User EXEC or Privileged EXEC level of the CLI. The feature applies to users whose access is authenticated by an authentication-method list based on a local user account, RADIUS server, or TACACS/TACACS+ server.

NOTE

The Privileged EXEC level is sometimes called the “Enable” level, because the command for accessing this level is **enable**.

The feature is enabled by default.

Examples of Syslog messages for CLI access

When a user whose access is authenticated by a local user account, a RADIUS server, or a TACACS or TACACS+ server logs into or out of the CLI User EXEC or Privileged EXEC mode, the software generates a Syslog message and trap containing the following information:

- The time stamp
- The user name
- Whether the user logged in or out
- The CLI level the user logged into or out of (User EXEC or Privileged EXEC level)

NOTE

Messages for accessing the User EXEC level apply only to access through Telnet. The device does not authenticate initial access through serial connections but does authenticate serial access to the Privileged EXEC level. Messages for accessing the Privileged EXEC level apply to access through the serial connection or Telnet.

The following examples show login and logout messages for the User EXEC and Privileged EXEC levels of the CLI.

```
Brocade# show logging
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
Buffer logging: level ACDMEINW, 12 messages logged
level code: A=alert C=critical D=debugging M=emergency E=error
I=informational N=notification W=warning
Static Log Buffer:
Dec 15 19:04:14:A:Fan 1, fan on right connector, failed

Dynamic Log Buffer (50 entries):
Oct 15 18:01:11:info:dg logout from USER EXEC mode
Oct 15 17:59:22:info:dg logout from PRIVILEGE EXEC mode
Oct 15 17:38:07:info:dg login to PRIVILEGE EXEC mode
Oct 15 17:38:03:info:dg login to USER EXEC mode
```

Syntax: show logging

The first message (the one on the bottom) indicates that user “dg” logged in to the CLI User EXEC level on October 15 at 5:38 PM and 3 seconds (Oct 15 17:38:03). The same user logged into the Privileged EXEC level four seconds later.

The user remained in the Privileged EXEC mode until 5:59 PM and 22 seconds. (The user could have used the CONFIG modes as well. Once you access the Privileged EXEC level, no further authentication is required to access the CONFIG levels.) At 6:01 PM and 11 seconds, the user ended the CLI session.

Disabling the Syslog messages and traps

Logging of CLI access is enabled by default. If you want to disable the logging, enter the following commands.

2 Specifying an SNTP server

```
Brocade(config)# no logging enable user-login
Brocade(config)# write memory
Brocade(config)# end
Brocade# reload
```

Syntax: [no] logging enable user-login

Cancelling an outbound Telnet session

If you want to cancel a Telnet session from the console to a remote Telnet server (for example, if the connection is frozen), you can terminate the Telnet session by doing the following.

1. At the console, press **Ctrl+^** (Ctrl+Shift-6).
2. Press the **X** key to terminate the Telnet session.

Pressing **Ctrl+^** twice in a row causes a single **Ctrl+^** character to be sent to the Telnet server. After you press **Ctrl+^**, pressing any key other than **X** or **Ctrl+^** returns you to the Telnet session.

Specifying an SNTP server

The Brocade device can be configured as a Simple Network Time Protocol (SNTP) client. You can configure the Brocade device to consult up to three SNTP servers for the current system time and date. The first server configured will be used unless it becomes unreachable, in which case the Brocade device will attempt to synchronize with the other SNTP servers (if any) in the order in which they were configured.

NOTE

Brocade devices do not retain time and date information across power cycles. Unless you want to reconfigure the system time counter each time the system is reset, Brocade recommends that you use the SNTP feature as described below.

To identify an SNTP server with IP address 10.99.8.95 to act as the clock reference for a Brocade device, enter the following.

```
Brocade(config)# sntp server 10.99.8.95
```

Syntax: [no] sntp server { <ip-address> | <hostname> | ipv6 <ipv6-address> } [<sntp-version>] [authentication-key <key-ID> <key-string>]

The <sntp-version> parameter specifies the SNTP version the server is running and can be from 1 – 4. The default is 4. The SNTP version is automatically set to 4, unless a different SNTP version is specified in the device startup configuration. You can configure up to three SNTP servers by entering three separate **sntp server** commands.

The order in which the SNTP servers are configured is the order in which they are consulted. The server that was configured first is the first server consulted after the poll cycle; the next server will be consulted only if a positive ACK is not received from the first one.

To specify an IPv6 address for the SNTP server, use the **ipv6** option.

The **authentication-key** option allows you to configure an authentication key for communication with the SNTP server. When the authentication key is configured for an SNTP client, it is used only for an SNTP unicast client. You must assign a unique server *<key-ID>* and pre-share *<key-string>*. The *<key-ID>* and pre-share *<key-string>* are used together to create the MD5 checksum. The MD5 checksum is used for authentication for request and reply messages with the SNTP server. The *<key-ID>* is the symmetric key shared with the upstream server, and accepts values from 1 to 4,294,967,295. The *<key-string>* is the authentication string itself, and can take up to 16 characters. If the *<key-string>* variable consists of only numerical characters, you must enclose the numerical characters in double quotes.

Modification of the authentication key fields is not supported. To change the key ID or key string, remove the time server using the **no sntp server...** command, then reconfigure the server with the new key.

By default, the Brocade device polls its SNTP server every 30 minutes (1800 seconds). To configure the Brocade device to poll for clock updates from a SNTP server every 15 minutes, enter the following.

```
Brocade(config)# sntp poll-interval 900
```

Syntax: [no] sntp poll-interval <16-131072>

To display information about SNTP associations, enter the **show sntp associations** command.

```
Brocade# show sntp associations
  address      ref clock      st  when  poll  delay  disp
~10.95.6.102   0.0.0.0         16  202    4    0.0    5.45
~10.95.6.101   0.0.0.0         16  202    0    0.0    0.0
* synced, ~ configured
```

Syntax: show sntp associations

The following table describes the information displayed by the **show sntp associations** command.

TABLE 5 Output from the **show sntp associations** command

Field	Description
(leading character)	One or both of the following: * Synchronized to this peer ~ Peer is statically configured
address	IP address of the peer
ref clock	IP address of the peer reference clock, or the reference ID of the external clock source if the peer is stratum 1. Examples of external clock source IDs: GPS, CDMA, WWV (Ft.Collins US Radio 2.5, 5, 10, 15 MHz), CESM (calibrated Cesium clock), etc.
st	NTP stratum level of the peer
when	Amount of time since the last NTP packet was received from the peer. A negative number indicates the system has never received any synchronization message from the specified server.
poll	The poll interval of the peer relative to the server.
delay	The total delay time in milliseconds along the path to the root clock.
disp	The dispersion of the root path in milliseconds.

2 Specifying an SNTP server

To display detailed information about SNTP associations, enter the **show sntp associations details** command.

```
Brocade# show sntp associations details
10.99.8.95 configured,insane, unsynched,invalid, stratum 16
ref ID 0.0.0.0,time 0.0 (Jan 1 00:00:00)
our mode client, peer mode unspec, our poll intvl 15, peer poll intvl 0
root delay 0.0 msec, root disp 0.0
delay 0 msec, offset 0 msec
precision 2**0, version 0
org time 0.0 (Jan 1 00:00:00)
rcv time 0.0 (Jan 1 00:00:00)
xmt time 0.0 (Jan 1 00:00:00)
```

Syntax: show sntp associations details

The following table describes the information displayed by the **show sntp associations details** command.

TABLE 6 Output from the **show sntp associations details** command

Field	Description
IP address	The IP address of the SNTP server. The IP address is an IPv4 or an IPv6 address.
configured or dynamic	The SNTP server is either configured, or the last responsive broadcast server that is found dynamically.
authenticated	If MD5 authentication is enabled for the peer.
sane or insane	If the SNTP server passes sanity checks.
synched or unsynched	If the system is synchronized or unsynchronized to the NTP peer.
valid or invalid	If the peer time is valid or invalid.
stratum	The NTP stratum level of the peer.
reference ID	The IP address of the peer (if any) to which the unit is synchronized. The reference ID can also refer to the external clock source if the peer is stratum 1. Examples of external clock source IDs: GPS, CDMA, WWV (Ft.Collins US Radio 2.5, 5, 10, 15 MHz), CESM (calibrated Cesium clock), etc.
time	The reference time stamp.
our mode	The mode relative to the peer. The mode can be a client or a broadcast client.
peer mode	Peer mode relative to us.
our poll intvl	The system poll interval relative to the peer.
peer poll intv	The poll interval of the peer relative to the server.
root delay	The total delay time in milliseconds along the path to the root clock.
root disp	The dispersion of the root path in milliseconds.
delay	The round trip delay to the peer in milliseconds.
offset	The offset of the peer clock relative to the system clock.

Field	Description
precision	The precision of the system clock in Hz.
version	The NTP version of the peer. The version can be from 1 - 4.
org time	The original timestamp of the system clock. The original timestamp is what the client has sent to the server.
rcv time	The receive timestamp of the system clock.
xmt time	The transmit timestamp of the system clock.

To display information about SNTP status, enter the **show sntp status** command.

```
Brocade# show sntp status
Clock is synchronized, stratum = 4, reference clock = 10.70.20.23
precision is 2**-20
reference time is 3489354594.3780510747
clock offset is 0.0000 msec, root delay is 0.41 msec
root dispersion is 0.11 msec, peer dispersion is 0.00 msec
sntp poll-interval is 10 secs
```

Syntax: show sntp status

The following table describes the information displayed by the **show sntp status** command.

TABLE 7 Output from the **show sntp status** command

Field	Description
unsynchronized	System is not synchronized to an NTP peer.
synchronized	System is synchronized to an NTP peer.
stratum	NTP stratum level of the upstream time server.
reference clock	IP address of the peer reference clock, or the reference ID of the external clock source if the peer is stratum 1. Examples of external clock source IDs: GPS, CDMA, WWV (Ft.Collins US Radio 2.5, 5, 10, 15 MHz), CESM (calibrated Cesium clock), etc.
precision	Precision of this system's clock (in Hz)
reference time	Reference time stamp
clock offset	Offset of clock to synchronized peer
root delay	Total delay along the path to the root clock
root dispersion	Dispersion of the root path
peer dispersion	Dispersion of the synchronized peer
sntp poll-interval	Shows how often the Brocade device polls for clock updates from an SNTP server.

Configuring the device as an SNTP server

You can configure the Brocade ICX 6650 device to function as an SNTP server to its downstream clients. When using the device as an SNTP server, you can also set it to use its own internal clock as the reference source if an upstream server becomes unavailable.

2 Configuring the device as an SNTP server

To use the device as a an SNTP server, enter a command such as the following at the Privileged EXEC level.

```
Brocade(config)# sntp server-mode use-local-clock authentication-key abc123
Brocade(config)# write memory
```

The above example configures the device to operate as an SNTP server with the local clock as a reference backup and an authentication key of “abc123” and writes the configuration changes to memory.

Syntax: [no] **sntp server-mode** [**use-local-clock** [**stratum** <stratum-number>]] [**authentication-key** <key-string>]

- The **use-local-clock** option causes the Brocade device to use the local clock as a reference source if an upstream reference source becomes unavailable. The SNTP stratum number is set to 1 by default. You may specify a different stratum number using the **stratum** option; <stratum-number> must be between 1 and 15. When the internal clock is serving as the SNTP reference source, the Brocade device will use the specified stratum number (or the default value of 1). When it is synchronized with the upstream server, the Brocade device will use the upstream server’s stratum number plus 1.
If you do not include the **use-local-clock** option the Brocade device will function as specified by RFC 4330: when the Brocade device loses upstream synchronization, it will respond to client SNTP requests with a “kiss-of-death” response (stratum value=0).

NOTE

To enable the **use-local-clock** option, you must set the internal clock of the Brocade device either by SNTP synchronization (see [“Specifying an SNTP server”](#) on page 20) or by using the **clock set** command (see [“Setting the system clock”](#) on page 26). Until the internal clock is set, the Brocade device will continue to rely exclusively on an upstream SNTP server if one is reachable. If none, the SNTP server of the Brocade device is disabled (down).

-
- To require a code string for authentication of SNTP communication from clients, use the **authentication-key** option and enter a key string of up to 16 characters. When this option is used, authentication parameters are required in clients’ SNTP request messages. If authentication fails, the Brocade device will reply with stratum 0 and a reference ID code of “CRYP” (cryptographic authentication or identification failed), and messages received without the required parameters will be dropped.

NOTE

Once entered, the authentication key cannot be viewed. Using the **show running-config** command will show output similar to the following when an authentication key has been set:

```
sntp server-mode authentication-key 2 $QHMiR3NzQA=
```

The **2** indicates that the key is encrypted using base-64 encryption; the characters following the 2 are the encrypted authentication string.

NOTE

You cannot enable or disable the **use-local-clock** option (or its stratum number) or change the authentication string when the SNTP server is up. To change these settings after enabling SNTP server mode, you must disable server mode using the command **no sntp server-mode**, then re-enable it with the new parameters.

Displaying SNTP server information

Use the **show sntp server-mode** command to display the status of the SNTP server and its configuration.

```
Brocade# show sntp server-mode
Status          : up
Stratum         : 1
Authentication   : md5
Clock source    : local-clock
Last 5 unique downstream client responses generated :
Client Address      Reference Time
10.20.79.91         15:57:48 Pacific Tue Aug 07 2012

10.20.79.63         15:56:26 Pacific Tue Aug 07 2012

10.20.79.110        15:52:08 Pacific Tue Aug 07 2012
```

Syntax: show sntp server-mode

TABLE 8 Output from the **show sntp server-mode** command

Field	Description
status	The operational state of the SNTP server. “ Up ” means that the SNTP port is open; “ down ” means that the SNTP port is closed. (If sntp server-mode is disabled, the show sntp server-mode command will display the message “SNTP server is not operational.”)
stratum	Stratum number of this server. The range is from 1 through 15. If the device is synchronized to an upstream SNTP server, this will show that server’s stratum number +1. If the device is unsynchronized and using the use-local-clock option, this will show the user-specified stratum number (or the default value of “ 1 ” if no stratum has been configured).
authentication	Authentication key used. If authentication has been configured successfully, this displays “ md5 .” If not, it displays “ none .”
clock source	The source of the reference time. When the reference source is an upstream SNTP server, this will show the IP address of the upstream server. When the internal clock of the device is being used as the reference, this will show “ local-clock .”
last upstream sync	The last upstream time-server synchronization, displayed in timestamp format. This field is not displayed if the time source is the local clock.
last responses sent to clients	The last responses sent to downstream clients (maximum of five unique clients), displayed in reverse chronological order. Each entry shows the IP address of the client and the timestamp sent.

Enabling broadcast mode for an SNTP client

The Brocade device can be configured as an SNTP client. You can enable an SNTP client to function in a broadcast mode when the NTP server is within the same LAN, and the expected delay in response to calibrate the system clock is minimal. In a broadcast mode, the SNTP client will not send queries to the NTP server. The SNTP client will listen to any number of NTP servers on the

2 Configuring the device as an SNTP server

network until the last message is received from the system clock. To update the system clock with the last message received, you can enable the SNTP client to either listen to all NTP broadcast servers on any interface, or enable the SNTP client to listen to only one specific NTP broadcast server.

To enable an SNTP client in a broadcast mode to listen to all NTP servers on any interface, enter the **sntp broadcast client** command.

```
Brocade(config)#sntp broadcast client
```

Syntax: sntp broadcast client

The **sntp broadcast client** command enables an SNTP client to listen to all NTP servers, and update the client's clock with the last message received from any NTP server.

To enable an SNTP client to listen to only one specific IPv4 NTP broadcast server, enter the following commands.

```
Brocade(config)#sntp broadcast client
Brocade(config)#sntp broadcast server 1.1.1.1
```

To enable an SNTP client to listen to only one specific IPv6 NTP broadcast server, enter the following commands.

```
Brocade(config)#sntp broadcast client
Brocade(config)#sntp broadcast server ipv6 2001:DB8:2:1::1
```

Syntax: sntp broadcast server [<ip-address> | ipv6 <ipv6-address>]

The **sntp broadcast client** command must be configured with the **sntp broadcast server** command to allow for an SNTP client to listen to only one specific NTP server.

When both unicast and broadcast modes are enabled for an SNTP client, the priority by which the NTP server is used to update the client's clock is as follows.

1. The last responsive unicast server.
2. The broadcast server on any interface.

Setting the system clock

In addition to SNTP support, Brocade switches and routers also allow you to set the system time counter. Using the **clock set** command starts the system clock with the time and date you specify.

NOTE

The time counter setting is not retained across power cycles. For more details about SNTP, refer to [“Specifying an SNTP server”](#) on page 20.

To set the system time and date to 10:15:05 on October 15, 2012, enter the following command.

```
Brocade# clock set 10:15:05 10-15-2012
```

Syntax: [no] clock set <hh:mm:ss> <mm-dd-yy> | <mm-dd-yyyy>

To synchronize the time counter with your SNTP server time, enter the following command.

```
Brocade# sntp sync
```

Syntax: sntp sync

By default, Brocade switches and routers do not change the system time for daylight saving time. To enable daylight saving time, enter the **clock summer-time** command.

```
Brocade(config)# clock summer-time
```

Syntax: [no] clock summer-time

Although SNTP servers typically deliver the time and date in Greenwich Mean Time (GMT), you can configure the Brocade device to adjust the time for any one-hour offset from GMT or for one of the following U.S. time zones:

- US Pacific (default)
- Alaska
- Aleutian
- Arizona
- Central
- East-Indiana
- Eastern
- Hawaii
- Michigan
- Mountain
- Pacific
- Samoa

The default is US Pacific.

To change the time zone to Australian East Coast time (which is normally 10 hours ahead of GMT), enter the **clock timezone gmt** command.

```
Brocade(config)# clock timezone gmt gmt+10
```

Syntax: [no] clock timezone gmt | us <time-zone>

You can enter one of the following values for <time-zone>:

- US time zones (**us**): alaska, aleutian, arizona, central, east-indiana, eastern, hawaii, michigan, mountain, pacific, samoa.
- GMT time zones (gmt): gmt+0:00 to gmt+12:00 in increments of 1, and gmt-0:00 to gmt-12:00 in decrements of 1 are supported.

New start and end dates for US daylight saving time

NOTE

This feature applies to US time zones only.

The system will automatically change the system clock to Daylight Saving Time (DST), in compliance with the new federally mandated start of daylight saving time, which is extended one month beginning in 2007. The DST will start at 2:00am on the second Sunday in March and will end at 2:00am on the first Sunday in November.

2 Configuring the device as an SNTP server

The DST feature is automatic, but to trigger the device to the correct time, the device must be configured to the US time zone, not the GMT offset. To configure your device to use the US time zone, enter the **clock timezone us pacific** command.

```
Brocade(config)# clock timezone us pacific
```

Syntax: [no] **clock timezone us** <timezone-type>

Enter pacific, eastern, central, or mountain for <timezone-type>.

This command must be configured on every device that follows the US DST.

To verify the change, run a **show clock** command.

```
Brocade# show clock
```

Limiting broadcast, multicast, and unknown unicast traffic

Brocade devices can forward all flooded traffic at wire speed within a VLAN. However, some third-party networking devices cannot handle high rates of broadcast, multicast, or unknown-unicast traffic. If high rates of traffic are being received by the Brocade device on a given port of that VLAN, you can limit the number of broadcast, multicast, or unknown-unicast packets received each second on that port. For more information about limiting broadcast, multicast, and unknown unicast traffic, refer to the Brocade ICX 6650 Switch Security Configuration Guide.

CLI banner configuration

Brocade ICX 6650 devices can be configured to display a greeting message on users' terminals when they enter the Privileged EXEC CLI level or access the device through Telnet. In addition, a Brocade device can display a message on the Console when an incoming Telnet CLI session is detected.

Setting a message of the day banner

You can configure the Brocade device to display a message on a user terminal when he or she establishes a Telnet CLI session. For example, to display the message "Welcome to Brocade ICX 6650!" when a Telnet CLI session is established.

```
Brocade(config)# banner motd $ (Press Return)
Enter TEXT message, End with the character '$'.
Welcome to Brocade ICX 6650! $
```

A delimiting character is established on the first line of the **banner motd** command. You begin and end the message with this delimiting character. The delimiting character can be any character except " (double-quotation mark) and cannot appear in the banner text. In this example, the delimiting character is \$ (dollar sign). The text in between the dollar signs is the contents of the banner. The banner text can be up to 4000 characters long, which can consist of multiple lines.

Syntax: [no] **banner motd** <delimiting-character>

To remove the banner, enter the **no banner motd** command.

NOTE

The **banner** *<delimiting-character>* command is equivalent to the **banner motd** *<delimiting-character>* command.

NOTE

If you are using a Web client to view the message of the day, and your banners are very wide, with large borders, you may need to set your PC display resolution to a number greater than the width of your banner. For example, if your banner is 100 characters wide and the display is set to 80 characters, the banner may distort, or wrap, and be difficult to read. If you set your display resolution to 120 characters, the banner will display correctly.

Requiring users to press the Enter key after the message of the day banner

In earlier IronWare software releases, users were required to press the Enter key after the Message of the Day (MOTD) was displayed, prior to logging in to the Brocade device on a console or from a Telnet session. Now, this requirement is disabled by default. Unless configured, users do not have to press Enter after the MOTD banner is displayed.

For example, if the MOTD "Authorized Access Only" is configured, by default, the following messages are displayed when a user tries to access the Brocade device from a Telnet session.

```
Authorized Access Only ...
Username:
```

The user can then login to the device.

However, if the requirement to press the **Enter key** is enabled, the following messages are displayed when accessing the switch from Telnet.

```
Authorized Access Only ...
Press <Enter> to accept and continue the login process....
```

The user must press the **Enter key** before the login prompt is displayed.

Also, on the console, the following messages are displayed if the requirement to press the **Enter key** is disabled.

```
Press Enter key to login
Authorized Access Only ...
User Access Verification
Please Enter Login Name:
```

However, if the requirement to press the **Enter key** after a MOTD is enabled, the following messages are displayed when accessing the switch on the console.

```
Press Enter key to login
Authorized Access Only ...
Press <Enter> to accept and continue the login process....
```

The user must press the Enter key to continue to the login prompt.

To enable the requirement to press the **Enter key** after the MOTD is displayed, enter a command such as the following.

```
Brocade(config)# banner motd require-enter-key
```

Syntax: [no] **banner motd require-enter-key**

Use the **no** form of the command to disable the requirement.

Setting a privileged EXEC CLI level banner

You can configure the Brocade device to display a message when a user enters the Privileged EXEC CLI level.

Example

```
Brocade(config)# banner exec_mode # (Press Return)
Enter TEXT message, End with the character '#'.
You are entering Privileged EXEC level
Do not foul anything up! #
```

As with the **banner motd** command, you begin and end the message with a delimiting character; in this example, the delimiting character is #(pound sign). The delimiting character can be any character except " (double-quotation mark) and cannot appear in the banner text. The text in between the pound signs is the contents of the banner. Banner text can be up to 4000 characters, which can consist of multiple lines.

Syntax: [no] **banner exec_mode** <delimiting-character>

To remove the banner, enter the **no banner exec_mode** command.

Displaying a console message when an incoming Telnet session is detected

You can configure the Brocade device to display a message on the Console when a user establishes a Telnet session. This message indicates where the user is connecting from and displays a configurable text message.

Example

```
Brocade(config)# banner incoming $ (Press Return)
Enter TEXT message, End with the character '$'.
Incoming Telnet Session!! $
```

When a user connects to the CLI using Telnet, the following message appears on the Console.

```
Telnet from 10.157.22.63
Incoming Telnet Session!!
```

As with the **banner motd** command, you begin and end the message with a delimiting character; in this example, the delimiting character is \$(dollar sign). The delimiting character can be any character except " (double-quotation mark) and cannot appear in the banner text. The text in between the dollar signs is the contents of the banner. Banner text can be up to 4000 characters, which can consist of multiple lines.

Syntax: [no] **banner incoming** <delimiting-character>

To remove the banner, enter the **no banner incoming** command.

Local MAC address for Layer 2 management traffic

By default, Brocade Layer 2 devices use the MAC address of the first port as the MAC address for Layer 2 management traffic. For example, when the Brocade device receives an ARP request for its management IP address, it responds with the first port MAC address. This may cause problems in some configurations where the Brocade device uses the same MAC address for management traffic as for switched traffic.

You can configure the Brocade device to use a different MAC address for Layer 2 management traffic than for switched traffic. When you issue the **use-local-management-mac**, the Brocade device changes a local bit in the first port MAC address and uses this MAC address for management traffic. The second bit of the first port MAC address is changed to 2. For example, if the MAC address is 748e.f80c.5f40 after the feature is enabled, the switch uses 728e.f80c.5f40 for management functions. Switched traffic will continue to use the first port MAC address without the local bit setting.

Example

```
Brocade(config)# use-local-management-mac
Brocade(config)# write memory
Brocade(config)# end
Brocade# reload
```

Syntax: [no] **use-local-management-mac**

NOTE

You must save the configuration and reload the software to place the change into effect.

NOTE

This feature is only available for the switch code. It is not available for router code.

Basic port parameter configuration

The procedures in this section describe how to configure the port parameters shown in [Table 4](#).

All Brocade ports are pre-configured with default values that allow the device to be fully operational at initial startup without any additional configuration. However, in some cases, changes to the port parameters may be necessary to adjust to attached devices or other network requirements.

Assigning a port name

A port name can be assigned to help identify interfaces on the network. You can assign a port name to physical ports, virtual interfaces, and loopback interfaces.

To assign a name to a port.

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# port-name Marsha
```

Syntax: **port-name** <text>

The <text> parameter is an alphanumeric string. The name can be up to 64 characters long. The name can contain blanks. You do not need to use quotation marks around the string, even when it contains blanks.

Port speed and duplex mode modification

The Gigabit Ethernet copper ports are designed to auto-sense and auto-negotiate the speed and duplex mode of the connected device. If the attached device does not support this operation, you can manually enter the port speed to operate at either 10, 100, or 1000 Mbps. The default and recommended setting is 10/100/1000 auto-sense.

NOTE

You can modify the port speed of copper ports only; this feature does not apply to fiber ports.

NOTE

For optimal link operation, copper ports on devices that do not support 803.3u must be configured with like parameters, such as speed (10,100,1000), duplex (half, full), MDI/MDIX, and Flow Control.

Port speed and duplex mode configuration syntax

The following commands change the port speed of copper interface 1/1/1 on a Brocade ICX 6650 device from the default of 10/100/1000 auto-sense, to 100 Mbps operating in full-duplex mode.

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# speed-duplex 100-full
```

Syntax: `speed-duplex <value>`

where *<value>* can be one of the following:

- 10-full – 10 Mbps, full duplex
- 10-half – 10 Mbps, half duplex
- 100-full – 100 Mbps, full duplex
- 100-half – 100 Mbps, half duplex
- 1000-full-master – 1 Gbps, full duplex master
- 1000-full-slave – 1 Gbps, full duplex slave
- auto – auto-negotiation

The default is **auto** (auto-negotiation).

Use the **no** form of the command to restore the default.

NOTE

On Brocade ICX 6650 devices, when setting the speed and duplex-mode of an interface to 1000-full, configure one side of the link as master (**1000-full-master**) and the other side as slave (**1000-full-slave**).

NOTE

On Brocade ICX 6650 devices, after you remove 10 Gbps speed from the running configuration, plugging in a 1G optic SFP transceiver into a 10 Gbps port causes the software to fail to revert the ports back from the default 10G LRM mode to 1 Gbps speed. Remove the 1G SFP transceiver and plug in the 10G optic SFP+transceiver so that the devices go into default 10 Gbps LRM mode.

Downgrading the Brocade ICX 6650 front panel ports from 10 GbE to 1 GbE port speed

Ports 1/1/1 through 1/1/56 port speed can be downgraded from 10 GbE to 1 GbE port speed.

NOTE

Ports 1/1/33 through 1/1/56 can only be downgraded to 1 GbE port speed if you have downloaded the ICX6650-10G-LIC-POD license onto the device. If the license is not downloaded onto the device, the port is in an error-disabled state at 10 GbE port speed when attempting to downgrading the port to 1 GbE port speed.

1. Enter the **speed-duplex** command on a single, multiple, or interface range as shown in the following example.

```
Brocade(config)# interface ethernet 1/3/1
Brocade(config-if-e10000-1/3/1)# speed-duplex 1000-full-master
```

Syntax: [no] **speed-duplex** [10g-full | 1000-full-master]

The **10g-full** option enables the port speed to 10 Gbps.

The **1000-full-master** option enables the port speed to 1 Gbps.

2. Enter the **write memory** command to save the configuration.

Ports 1/1/1 through 1/1/56 are downgraded to 1 Gbps speed. A system reload is not required. Use the **no speed-duplex** command to disable the port speed.

Enabling auto-negotiation maximum port speed advertisement and down-shift

NOTE

For optimal link operation, link ports on devices that do not support 803.3u must be configured with like parameters, such as speed (10,100,1000), duplex (half, full), MDI/MDIX, and Flow Control.

Maximum Port speed advertisement and **Port speed down-shift** are enhancements to the auto-negotiation feature, a mechanism for accommodating multi-speed network devices by automatically configuring the highest performance mode of inter-operation between two connected devices.

Port speed down-shift enables Gbps copper ports on the Brocade device to establish a link at 1000 Mbps over a 4-pair wire when possible, or to down-shift to 100 Mbps if the medium is a 2-pair wire.

Maximum port speed advertisement enables you to configure an auto-negotiation maximum speed that Gbps copper ports on the Brocade device will advertise to the connected device. You can configure a port to advertise a maximum speed of either 100 Mbps or 10 Mbps. When the maximum port speed advertisement feature is configured on a port that is operating at 100 Mbps maximum speed, the port will advertise 10/100 Mbps capability to the connected device. Similarly, if a port is configured at 10 Mbps maximum speed, the port will advertise 10 Mbps capability to the connected device.

The port speed down-shift and maximum port speed advertisement features operate dynamically at the physical link layer between two connected network devices. They examine the cabling conditions and the physical capabilities of the remote link, then configure the speed of the link segment according to the highest physical-layer technology that both devices can accommodate.

The port speed down-shift and maximum port speed advertisement features operate dynamically at the physical link layer, independent of logical trunk group configurations. Although Brocade recommends that you use the same cable types and auto-negotiation configuration on all members of a trunk group, you could utilize the auto-negotiation features conducive to your cabling environment. For example, in certain circumstances, you could configure each port in a trunk group to have its own auto-negotiation maximum port speed advertisement or port speed down-shift configuration.

Maximum port speed application notes

- Port speed down-shift and maximum port speed advertisement work only when auto-negotiation is enabled (CLI command **speed-duplex auto**). If auto-negotiation is OFF, the device will reject the port speed down-shift and maximum port speed advertisement configuration.
- When port speed down-shift or maximum port speed advertisement is enabled on a port, the device will reject any configuration attempts to set the port to a forced speed mode (100 Mbps or 1000 Mbps).
- When the port speed down-shift feature is enabled on a combo port, the port will not support true media automatic detection, meaning the device will not be able to detect and select the fiber or copper connector based on link availability.

Modifying port duplex mode

You can manually configure a 10/100 Mbps port to accept either full-duplex (bi-directional) or half-duplex (uni-directional) traffic.

NOTE

You can modify the port duplex mode of copper ports only. This feature does not apply to fiber ports.

Port duplex mode and port speed are modified by the same command.

Port duplex mode configuration syntax

To change the port speed of interface 1/1/1 from the default of 10/100/1000 auto-sense to 10 Mbps operating at full-duplex, enter the following.

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# speed-duplex 10-full
```

Syntax: **speed-duplex** <value>

The <value> can be one of the following:

- 10-full
- 10-half
- 100-full
- 100-half
- auto (default)

Disabling or re-enabling a port

A port can be made inactive (disable) or active (enable) by selecting the appropriate status option. The default value for a port is enabled.

To disable port 1/1/1 of a Brocade device, enter the following.

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# disable
```

You also can disable or re-enable a virtual interface. To do so, enter commands such as the following.

```
Brocade(config)# interface ve 1
Brocade(config-vif-1)# disable
```

Syntax: disable

To re-enable a virtual interface, enter the **enable** command at the Interface configuration level. For example, to re-enable virtual interface v1, enter the **enable** command.

```
Brocade(config-vif-1)# enable
```

Syntax: enable

Flow control configuration

Flow control (802.3x) is a QoS mechanism created to manage the flow of data between two full-duplex Ethernet devices. Specifically, a device that is oversubscribed (is receiving more traffic than it can handle) sends an 802.3x PAUSE frame to its link partner to temporarily reduce the amount of data the link partner is transmitting. Without flow control, buffers would overflow, packets would be dropped, and data retransmission would be required.

All Brocade ICX 6650 devices support *asymmetric* flow control, meaning they can receive PAUSE frames but cannot transmit them.

Flow control configuration notes

- Auto-negotiation of flow control is not supported on 10 Gbps and 40 Gbps ports, fiber ports, and copper or fiber combination ports.
- When any of the flow control commands are applied to a port that is up, the port will be disabled and re-enabled.
- For 10 Gbps and 40 Gbps ports, the **show interface** <stack-unit>/<slot>/<port> display shows Flow Control is enabled or Flow Control is disabled, depending on the configuration.
- When flow-control is enabled, the hardware can only advertise PAUSE frames. It does not advertise Asym.

Disabling or re-enabling flow control

You can configure the Brocade ICX 6650 device to operate with or without flow control. Flow control is enabled by default globally and on all full-duplex ports. You can disable and re-enable flow control at the Global CONFIG level for all ports. When enabled globally, you can disable and re-enable flow control on individual ports.

2 Basic port parameter configuration

To disable flow control, enter the **no flow-control** command.

```
Brocade(config)# no flow-control
```

To turn the feature back on, enter the **flow-control** command.

```
Brocade(config)# flow-control
```

Syntax: [no] flow-control

NOTE

For optimal link operation, link ports on devices that do not support 803.3u must be configured with like parameters, such as speed (10,100,1000), duplex (half, full), MDI/MDIX, and Flow Control.

Negotiation and advertisement of flow control

By default, when flow control is enabled globally and auto-negotiation is ON, flow control is enabled and advertised on 10/100/1000M ports. If auto-negotiation is OFF or if the port speed was configured manually, then flow control is not negotiated with or advertised to the peer. For details about auto-negotiation, refer to [“Port speed and duplex mode modification”](#) on page 32.

To disable flow control capability on a port, enter the following commands.

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# no flow-control
```

To enable flow control negotiation, enter the following commands.

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# flow-control neg-on
Error - This command is not supported for fiber ports and gbic copper optics
```

The error message is displayed because auto-negotiation of flow control is not supported on 10 Gbps and 40 Gbps ports.

Syntax: [no] flow-control [neg-on]

- **flow-control** [default] - Enable flow control, flow control negotiation, and advertise flow control
- **no flow-control neg-on** - Disable flow control negotiation
- **no flow-control** - Disable flow control, flow control negotiation, and advertising of flow control

After flow control negotiation is enabled using the **flow-control neg-on** command option, flow control is enabled or disabled depending on the peer advertisement.

Commands may be entered in IF (single port) or MIF (multiple ports at once) mode.

Example

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# no flow-control
```

This command disables flow control on port 1/1/1.

```
Brocade(config)# interface ethernet 1/1/1 to 1/1/2
Brocade(config-mif-1/1/1-1/1/2)# no flow-control
```

This command disables flow control on ports 1/1/1 to 1/1/2.

Displaying flow-control status

The **show interface** <stack-unit>/<slot>/<port> command displays configuration, operation, and negotiation status where applicable.

For example, issuing the command for 10/100/1000M port 1/1/36 displays the following output.

```
Brocade# show interfaces ethernet 1/1/36
10GigabitEthernet1/1/36 is up, line protocol is up
  Hardware is 10GigabitEthernet, address is 748e.f80c.5f40 (bia 748e.f80c.5f40)
  Interface type is 10Gig SFP+
  Configured speed 10Gbit, actual 10Gbit, configured duplex fdx, actual fdx
  Member of L2 VLAN ID 1, port is untagged, port state is FORWARDING
  BPDU guard is Disabled, ROOT protect is Disabled
  Link Error Dampening is Disabled
  STP configured to ON, priority is level0, mac-learning is enabled
  Flow Control is enabled
  Mirror disabled, Monitor disabled
  Not member of any active trunks
  Not member of any configured trunks
  No port name
  MTU 10200 bytes, encapsulation ethernet
  300 second input rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  300 second output rate: 96 bits/sec, 0 packets/sec, 0.00% utilization
  0 packets input, 0 bytes, 0 no buffer
  Received 0 broadcasts, 0 multicasts, 0 unicasts
  0 input errors, 0 CRC, 0 frame, 0 ignored
  0 runs, 0 giants
  1 packets output, 64 bytes, 0 underruns
  Transmitted 0 broadcasts, 1 multicasts, 0 unicasts
  0 output errors, 0 collisions
  Relay Agent Information option: Disabled
```

Egress queues:

Queue counters	Queued packets	Dropped Packets
0	0	0
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0

Symmetric flow control on Brocade ICX 6650 devices

In addition to *asymmetric* flow control, Brocade ICX 6650 devices support *symmetric* flow control, meaning they can both receive and transmit 802.3x PAUSE frames.

By default on Brocade ICX 6650 devices, packets are dropped from the end of the queue at the egress port (tail drop mode), when the maximum queue limit is reached. Conversely, when symmetric flow control is enabled, packets are guaranteed delivery since they are managed at the ingress port and no packets are dropped.

Symmetric flow control addresses the requirements of a lossless service class in an Internet Small Computer System Interface (iSCSI) environment.

About XON and XOFF thresholds

An 802.3x PAUSE frame is generated when the buffer limit at the ingress port reaches or exceeds the port's upper watermark threshold (XOFF limit). The PAUSE frame requests that the sender stop transmitting traffic for a period of time. The time allotted enables the egress and ingress queues to be cleared. When the ingress queue falls below the port's lower watermark threshold (XON limit), an 802.3x PAUSE frame with a quanta of 0 (zero) is generated. The PAUSE frame requests that the sender resume sending traffic normally.

NOTE

In Brocade ICX 6650, you cannot change the default XON and XOFF values.

Each 1G , 10G, and 40G port is configured with a default total number of buffers as well as a default XOFF and XON threshold.

TABLE 9 XON and XOFF default thresholds (Apply to both Jumbo or non-Jumbo mode)

	Limit when Jumbo disabled / % of buffer limit	Limit when Jumbo enabled / % of buffer limit
1G or 10G ports		
Total buffers	256	256
XOFF	192 (78%)	192 (78%)
XON	136 (56%)	136 (56%)
40G ports		
Total buffers	960	960
XOFF	832 (87%)	832 (87%)
XON	720 (75%)	720 (75%)

Configuration notes and feature limitations for symmetric flow control

Note the following configuration notes and feature limitations before enabling symmetric flow control.

- Symmetric flow control is supported on Brocade ICX 6650 devices.
- Symmetric flow control is supported on all 1 Gbps, 10 Gbps, and 40 Gbps data ports.
- To use this feature, 802.3x flow control must be enabled globally and per interface on the Brocade ICX 6650 device. By default, 802.3x flow control is enabled, but can be disabled with the **no flow-control** command.
- The following QoS features are not supported together with symmetric flow control:
 - dynamic buffer allocation (CLI command **qd-descriptor** and **qd-buffer**)
 - Buffer profiles (CLI command **buffer-profile port-region**) is not supported for scheduler profiles.
 - DSCP-based QoS (CLI command **trust dscp**)
- Head of Line (HOL) blocking may occur when symmetric flow control is enabled. This means that a peer can stop transmitting traffic streams unrelated to the congestion stream.

Enabling and disabling symmetric flow control

By default, symmetric flow control is disabled and tail drop mode is enabled. However, because flow control is enabled by default on all full-duplex ports, these ports will always honor received 802.3x Pause frames, whether or not symmetric flow control is enabled.

To enable symmetric flow control globally on all full-duplex data ports of a standalone unit, enter the **symmetric-flow-control enable** command.

```
Brocade(config)# symmetric-flow-control enable
```

Syntax: [no] **symmetric-flow-control enable**

To disable symmetric flow control once it has been enabled, use the **no** form of the command.

Interpacket Gap (IPG) on a Brocade ICX 6650 switch

You can configure an IPG for each port. An IPG is a configurable time delay between successive data packets. You can configure an IPG with a range from 48-120 bit times in multiples of 8, with a default of 96. The IPG may be set from either the interface configuration level or the multiple interface level. You configure IPG at the interface level on 1 Gbps ports only. The command you use depends on the interface type on which IPG is being configured.

The default interpacket gap is 96 bits-time, which is 9.6 microseconds for 10 Mbps Ethernet, 960 nanoseconds for 100 Mbps Ethernet, 96 nanoseconds for 1 Gbps Ethernet, and 9.6 nanoseconds for 10 Gbps Ethernet.

IPG configuration notes

- IPG configuration commands are based on "port regions". All ports within the same port region should have the same IPG configuration. If a port region contains two or more ports, changes to the IPG configuration for one port are applied to all ports in the same port region. When you enter a value for IPG, the CLI displays the ports to which the IPG configuration is applied.

Example

```
Brocade(config-if-e10000-1/2/1)# ipg 48
```

Syntax: **ipg** <decimal>

The <decimal> variable specifies a range between 48 to 120, in multiples of 8.

- When you enter a value for IPG, the device applies the closest valid IPG value for the port mode to the interface. For example, if you specify 120 for a 1 Gbps Ethernet port in 1 Gbps mode, the device assigns 112 as the closest valid IPG value to program into hardware.
- When an IPG is applied to a trunk group, it applies to all ports in the trunk group. When you are creating a new trunk group, the IPG setting on the primary port is automatically applied to the secondary ports.
- This feature is supported on 10/100/1000M ports.

Changing the Gbps fiber negotiation mode

The globally configured Gbps negotiation mode is the default mode for all Gbps fiber ports. You can override the globally configured default and set individual ports to the following:

- **Negotiate-full-auto** – The port first tries to perform a handshake with the other port to exchange capability information. If the other port does not respond to the handshake attempt, the port uses the manually configured configuration information (or the defaults if an administrator has not set the information). This is the default.
- **Auto-Gbps** – The port tries to perform a handshake with the other port to exchange capability information.
- **Negotiation-off** – The port does not try to perform a handshake. Instead, the port uses configuration information manually configured by an administrator.

To change the mode for individual ports, enter commands such as the following.

```
Brocade(config)# interface ethernet 1/1/1 to 1/1/2
Brocade(config-mif-1/1/1-1/1/2)# gig-default auto-gig
```

This command overrides the global setting and sets the negotiation mode to auto-Gbps for ethernet ports 1/1/1– 1/1/2.

Syntax: `gig-default neg-full-auto | auto-gig | neg-off`

NOTE

When Gbps negotiation mode is turned off (CLI command **gig-default neg-off**), the Brocade device may inadvertently take down both ends of a link. This is a hardware limitation for which there is currently no workaround.

Port priority (QoS) modification

You can give preference to the inbound traffic on specific ports by changing the Quality of Service (QoS) level on those ports. For information and procedures, refer to the Brocade ICX 6650 Switch Platform and Layer 2 Configuration Guide.

Port flap dampening configuration

Port Flap Dampening increases the resilience and availability of the network by limiting the number of port state transitions on an interface.

If the port link state toggles from up to down for a specified number of times within a specified period, the interface is physically disabled for the specified wait period. Once the wait period expires, the port link state is re-enabled. However, if the wait period is set to zero (0) seconds, the port link state will remain disabled until it is manually re-enabled.

Port flap dampening configuration notes

- When a flap dampening port becomes a member of a trunk group, that port, as well as all other member ports of that trunk group, will inherit the primary port configuration. This means that the member ports will inherit the primary port flap dampening configuration, regardless of any previous configuration.
- The Brocade device counts the number of times a port link state toggles from "up to down", and not from "down to up".
- The sampling time or window (the time during which the specified toggle threshold can occur before the wait period is activated) is triggered when the first "up to down" transition occurs.
- "Up to down" transitions include UDLD-based toggles, as well as the physical link state.

Configuring port flap dampening on an interface

This feature is configured at the interface level.

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# link-error-disable 10 3 10
```

Syntax: [no] **link-error-disable** <toggle-threshold> <sampling-time-in-sec> <wait-time-in-sec>

The <toggle-threshold> is the number of times a port link state goes from up to down and down to up before the wait period is activated. Enter a value from 1 - 50.

The <sampling-time-in-sec> is the amount of time during which the specified toggle threshold can occur before the wait period is activated. The default is 0 seconds. Enter 1 – 65535 seconds.

The <wait-time-in-sec> is the amount of time the port remains disabled (down) before it becomes enabled. Enter a value from 0 – 65535 seconds; 0 indicates that the port will stay down until an administrative override occurs.

Configuring port flap dampening on a trunk

You can configure the port flap dampening feature on the primary port of a trunk using the **link-error-disable** command. Once configured on the primary port, the feature is enabled on all ports that are members of the trunk. You cannot configure port flap dampening on port members of the trunk.

Enter commands such as the following on the primary port of a trunk.

```
Brocade(config)# interface ethernet 1/1/3
Brocade(config-if-e10000-1/1/3)# link-error-disable 10 3 10
```

Re-enabling a port disabled by port flap dampening

A port disabled by port flap dampening is automatically re-enabled once the wait period expires; however, if the wait period is set to zero (0) seconds, you must re-enable the port by entering the following command on the disabled port.

```
Brocade(config)# interface ethernet 1/1/3
Brocade(config-if-e10000-1/1/3)# no link-error-disable 10 3 10
```

Displaying ports configured with port flap dampening

Ports that have been disabled due to the port flap dampening feature are identified in the output of the **show link-error-disable** command. The following shows an example output.

```
Brocade# show link-error-disable
Port 1/1/3 is forced down by link-error-disable.
```

Use the **show link-error-disable all** command to display the ports with the port flap dampening feature enabled.

2 Basic port parameter configuration

```

Brocade# show link-error-disable all
Port      -----Config-----      -----Oper-----
#          Threshold  Sampling-Time  Shutoff-Time  State  Counter
-----
1/1/3      1                14            3             Idle   N/A
1/1/32     2                20            Indefinite    Idle   N/A
1/1/56     1                10            Indefinite    Down   N/A
1/2/1      10               3             10            Idle   N/A
1/3/4      4                10            2             Idle   N/A
1/3/8      1                10            Indefinite    Idle   N/A

```

Table 10 defines the port flap dampening statistics displayed by the **show link-error-disable all** command.

TABLE 10 Output of show link-error-disable

Column	Description
Port #	The port number.
Threshold	The number of times the port link state will go from up to down and down to up before the wait period is activated.
Sampling-Time	The number of seconds during which the specified toggle threshold can occur before the wait period is activated.
Shutoff-Time	The number of seconds the port will remain disabled (down) before it becomes enabled. A zero (0) indicates that the port will stay down until an administrative override occurs.
State	The port state can be one of the following: <ul style="list-style-type: none"> • Idle – The link is normal and no link state toggles have been detected or sampled. • Down – The port is disabled because the number of sampled errors exceeded the configured threshold. • Err – The port sampled one or more errors.
Counter	<ul style="list-style-type: none"> • If the port state is Idle, this field displays N/A. • If the port state is Down, this field shows the remaining value of the shutoff timer. • If the port state is Err, this field shows the number of errors sampled.

Syntax: show link-error-disable [all]

Syslog messages for port flap dampening

The following Syslog messages are generated for port flap dampening.

- If the threshold for the number of times that a port link toggles from “up” to “down” then “down” to “up” has been exceeded, the following Syslog message is displayed.

```
0d00h02m10s:I:ERR_DISABLE: Link flaps on port ethernet 16 exceeded threshold; port in err-disable state
```
- If the wait time (port is down) expires and the port is brought up the following Syslog message is displayed.

```
0d00h02m41s:I:ERR_DISABLE: Interface ethernet 16, err-disable recovery timeout
```

Port loop detection

This feature allows the Brocade device to disable a port that is on the receiving end of a loop by sending test packets. You can configure the time period during which test packets are sent.

Types of loop detection

There are two types of loop detection; Strict Mode and Loose Mode. In Strict Mode, a port is disabled only if a packet is looped back to that same port. Strict Mode overcomes specific hardware issues where packets are echoed back to the input port. In Strict Mode, loop detection must be configured on the physical port.

In Loose Mode, loop detection is configured on the VLAN of the receiving port. Loose Mode disables the receiving port if packets originate from any port or VLAN on the same device. The VLAN of the receiving port must be configured for loop detection in order to disable the port.

Recovering disabled ports

Once a loop is detected on a port, it is placed in Err-Disable state. The port will remain disabled until one of the following occurs:

- You manually disable and enable the port at the Interface Level of the CLI.
- You enter the command **clear loop-detection**. This command clears loop detection statistics and enables all Err-Disabled ports.
- The device automatically re-enables the port. To set your device to automatically re-enable Err-Disabled ports, refer to [“Configuring the device to automatically re-enable ports”](#) on page 44.

Port loopback detection configuration notes

- Loopback detection packets are sent and received on both tagged and untagged ports. Therefore, this feature cannot be used to detect a loop across separate devices.

The following information applies to Loose Mode loop detection:

- With Loose Mode, two ports of a loop are disabled.
- Different VLANs may disable different ports. A disabled port affects every VLAN using it.
- Loose Mode floods test packets to the entire VLAN. This can impact system performance if too many VLANs are configured for Loose Mode loop detection.

NOTE

Brocade recommends that you limit the use of Loose Mode. If you have a large number of VLANs, configuring loop detection on all of them can significantly affect system performance because of the flooding of test packets to all configured VLANs. An alternative to configuring loop detection in a VLAN-group of many VLANs is to configure a separate VLAN with the same tagged port and configuration, and enable loop detection on this VLAN only.

NOTE

When loop detection is used with L2 loop prevention protocols, such as spanning tree (STP), the L2 protocol takes higher priority. Loop detection cannot send or receive probe packets if ports are blocked by L2 protocols, so it does not detect L2 loops when STP is running because loops within a VLAN have been prevented by STP. Loop detection running in Loose Mode can detect and break L3

loops because STP cannot prevent loops across different VLANs. In these instances, the ports are not blocked and loop detection is able to send out probe packets in one VLAN and receive packets in another VLAN. In this way, loop detection running in Loose Mode disables both ingress and egress ports.

Enabling loop detection

Use the **loop-detection** command to enable loop detection on a physical port (Strict Mode) or a VLAN (Loose Mode). Loop detection is disabled by default. The following example shows a Strict Mode configuration.

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# loop-detection
```

The following example shows a Loose Mode configuration.

```
Brocade(config)# vlan20
Brocade(config-vlan-20)# loop-detection
```

By default, the port will send test packets every one second, or the number of seconds specified by the **loop-detection-interval** command. Refer to [“Configuring a global loop detection interval”](#) on page 44.

Syntax: [no] loop-detection

Use the [no] form of the command to disable loop detection.

Configuring a global loop detection interval

The loop detection interval specifies how often a test packet is sent on a port. When loop detection is enabled, the loop detection time unit is 0.1 second, with a default of 10 (one second). The range is from 1 (one tenth of a second) to 100 (10 seconds). You can use the **show loop-detection status** command to view the loop detection interval.

To configure the global loop detection interval, enter a command similar to the following.

```
Brocade(config)# loop-detection-interval 50
```

This command sets the loop-detection interval to 5 seconds (50 x 0.1).

To revert to the default global loop detection interval of 10, enter one of the following.

```
Brocade(config)# loop-detection-interval 10
```

OR

```
Brocade(config)# no loop-detection-interval 50
```

Syntax: [no] loop-detection-interval <number>

where <number> is a value from 1 to 100. The system multiplies your entry by 0.1 to calculate the interval at which test packets will be sent.

Configuring the device to automatically re-enable ports

To configure the Brocade ICX 6650 device to automatically re-enable ports that were disabled because of a loop detection, enter the **errdisable recovery cause loop-detection** command.

```
Brocade(config)# errdisable recovery cause loop-detection
```

The above command will cause the Brocade ICX 6650 device to automatically re-enable ports that were disabled because of a loop detection. By default, the device will wait 300 seconds before re-enabling the ports. You can optionally change this interval to a value from 10 to 65535 seconds. Refer to [“Specifying the recovery time interval”](#) on page 45.

Syntax: [no] errdisable recovery cause loop-detection

Use the [no] form of the command to disable this feature.

Specifying the recovery time interval

The recovery time interval specifies the number of seconds the Brocade ICX 6650 device will wait before automatically re-enabling ports that were disabled because of a loop detection. (Refer to [“Configuring the device to automatically re-enable ports”](#) on page 44.) By default, the device will wait 300 seconds. To change the recovery time interval, enter a command such as the following.

```
Brocade(config)# errdisable recovery interval 120
```

The above command configures the device to wait 120 seconds (2 minutes) before re-enabling the ports.

To revert back to the default recovery time interval of 300 seconds (5 minutes), enter one of the following commands.

```
Brocade(config)# errdisable recovery interval 300
```

OR

```
Brocade(config)# no errdisable recovery interval 120
```

Syntax: [no] errdisable recovery interval <seconds>

where <seconds> is a number from 10 to 65535.

Clearing loop-detection

To clear loop detection statistics and re-enable all ports that are in Err-Disable state because of a loop detection, enter the **clear loop-detection** command.

```
Brocade# clear loop-detection
```

Displaying loop-detection information

Use the **show loop-detection status** command to display loop detection status, as shown.

```
Brocade# show loop-detection status
loop detection packets interval: 10 (unit 0.1 sec)
index port/vlan  status                                # errdis  sent-pkts  recv-pkts
1      vlan1      0 errdis port                                0         452        0
2      vlan2      0 errdis port                                0         34         0
3      vlan3      0 errdis port                                0         32         0
4      vlan4      0 errdis port                                0         30         0
5      vlan5      0 errdis port                                0         29         0
```

If a port is errdisabled in Strict mode, it shows “ERR-DISABLE by itself”. If it is errdisabled due to its associated vlan, it shows “ERR-DISABLE by vlan ?”

2 Basic port parameter configuration

The following command displays the current disabled ports, including the cause and the time.

```
Brocade# show loop-detection disable
Number of err-disabled ports: 2
You can re-enable err-disable ports one by one by "disable" then "enable"
under interface config, re-enable all by "clear loop-detect", or
configure "errdisable recovery cause loop-detection" for automatic recovery
```

index	port	caused-by	disabled-time
1	1/1/1	vlan 1	00:00:10
2	1/1/9	vlan 1	00:00:10

This example shows the disabled ports, the cause, and the time the port was disabled. If loop-detection is configured on a physical port, the disable cause will show "itself". For VLANs configured for loop-detection, the cause will be a VLAN.

The following command shows the hardware and software resources being used by the loop-detection feature.

```
Vlans configured loop-detection use 1 HW MAC
Vlans not configured but use HW MAC: 1 10
```

	alloc	in-use	avail	get-fail	limit	get-mem	size	init
configuration pool	16	6	10	0	3712	6	15	16
linklist pool	16	10	6	0	3712	10	16	16

Displaying loop detection resource information

Use the **show loop-detection resource** command to display the hardware and software resource information on loop detection.

```
Brocade# show loop-detection resource
Vlans configured loop-detection use 1 HW MAC
Vlans not configured but use HW MAC: 1 10
```

	alloc	in-use	avail	get-fail	limit	get-mem	size	init
configuration pool	16	6	10	0	3712	6	15	16
linklist pool	16	10	6	0	3712	10	16	16

Syntax: show loop-detection resource

[Table 11](#) describes the output fields for this command.

TABLE 11 Field definitions for the **show loop-detection resource** command

Field	Description
This command displays the following information for the configuration pool and the linklist pool.	
alloc	Memory allocated
in-use	Memory in use
avail	Available memory
get-fail	The number of get requests that have failed
limit	The maximum memory allocation
get-mem	The number of get-memory requests

TABLE 11 Field definitions for the **show loop-detection resource** command (Continued)

Field	Description
size	The size
init	The number of requests initiated

Displaying loop detection configuration status on an interface

Use the **show interface** command to display the status of loop detection configuration on a particular interface.

```
Brocade# show interface ethernet 1/1/1
10GigabitEthernet1/1/1 is disabled, line protocol is down
  Hardware is 10GigabitEthernet, address is 748e.f80c.5f40(bia 748e.f80c.5f40a)
  Interface type is 1Gig Copper SFP (miniGBIC)
  Configured speed 1Gbit, actual unknown, configured duplex fdx, actual unknown
  Member of 1 L2 VLANs, port is tagged, port state is DISABLED
  BPDU guard is Disabled, ROOT protect is Disabled
  Link Error Dampening is Enabled
  STP configured to ON, priority is level0, mac-learning is enabled
Loop Detection is ENABLED
  Flow Control is disabled
  Mirror disabled, Monitor disabled
  Not member of any active trunks
  Not member of any configured trunks
  No port name
  MTU 10200 bytes, encapsulation ethernet
  300 second input rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  300 second output rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  0 packets input, 0 bytes, 0 no buffer
  Received 0 broadcasts, 0 multicasts, 0 unicasts
  0 input errors, 0 CRC, 0 frame, 0 ignored
  0 runs, 0 giants
  0 packets output, 0 bytes, 0 underruns
  Transmitted 0 broadcasts, 0 multicasts, 0 unicasts
  0 output errors, 0 collisions
  Relay Agent Information option: Disabled
```

Egress queues:

Queue counters	Queued packets	Dropped Packets
0	0	0
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0

Syslog message due to disabled port in loop detection

The following message is logged when a port is disabled due to loop detection. This message also appears on the console.

```
Loop-detection: port 1/1/35 (vlan=1), put into errdisable state
```

The Errdisable function logs a message whenever it re-enables a port.

2 Basic port parameter configuration

Operations, Administration, and Maintenance

In this chapter

• OAM Overview	50
• Software versions installed and running on a device	50
• Image file types	53
• Software upgrades	53
• Viewing the contents of flash files	53
• Using SNMP to upgrade software	54
• Software reboot	56
• Displaying the boot preference	56
• Loading and saving configuration files	57
• System reload scheduling	67
• Diagnostic error codes and remedies for TFTP transfers	68
• Network connectivity testing	69

Table 12 lists the Brocade ICX 6650 switch and the operations, administration, and maintenance (OAM) features the switch supports. These features are supported only in full Layer 3 software images, except where explicitly noted.

TABLE 12 Supported operations, administration, and maintenance features

Feature	Brocade ICX 6650
Flash and boot code verification	Yes
Flash image verification	Yes
Software upgrade via CLI	Yes
Software upgrade via SNMP	Yes
Hitless support:	Yes (PBR only)
• PBR	
• GRE Tunnels	
• IPv6 to IPv4 Tunnels	
Software reboot	Yes
Show boot preference	Yes
Load and save configuration files	Yes
System reload scheduling	Yes
Diagnostic error codes and remedies for TFTP transfers	Yes
IPv4 ping	Yes
IPv4 traceroute	Yes

OAM Overview

For easy software image management, all Brocade ICX 6650 devices support the download and upload of software images between the flash modules on the devices and a Trivial File Transfer Protocol (TFTP) server on the network.

Brocade devices have two flash memory modules:

- **Primary flash** – The default local storage device for image files and configuration files.
- **Secondary flash** – A second flash storage device. You can use the secondary flash to store redundant images for additional booting reliability or to preserve one software image while testing another one.

Only one flash device is active at a time. By default, the primary image will become active upon reload.

You can update the software contained on a flash module using TFTP to copy the update image from a TFTP server onto the flash module. In addition, you can copy software images and configuration files from a flash module to a TFTP server.

NOTE

Brocade devices are TFTP clients but not TFTP servers. You must perform the TFTP transaction from the Brocade device. You cannot “put” a file onto the Brocade device using the interface of your TFTP server.

NOTE

If you are attempting to transfer a file using TFTP but have received an error message, refer to [“Diagnostic error codes and remedies for TFTP transfers”](#) on page 68.

Software versions installed and running on a device

Use the following methods to display the software versions running on the device and the versions installed in flash memory.

Determining the flash image version running on the device

To determine the flash image version running on a device, enter the **show version** command at any level of the CLI. Some examples are shown below.

Brocade ICX 6650 devices

To determine the flash image version running on a Brocade ICX 6650 device, enter the **show version** command at any level of the CLI. The following shows an example output.

```
Brocade#show version
Copyright (c) 1996-2012 Brocade Communications Systems, Inc. All rights reserved.
  UNIT 1: compiled on Jul 31 2012 at 21:55:03 labeled as ICXLS07500
           (11358772 bytes) from Secondary ICXLS07500.bin
  SW: Version 07.5.00T321
  Boot-Monitor Image size = 524288, Version:07.5.00T320 (fxz07500B1)
  HW: Stackable ICX6650-64
=====
```

```

UNIT 1: SL 1: ICX6650-64 56-port Management Module
      Serial #: CEN2525H006
      License: BASE_SOFT_PACKAGE (LID: egpHKHKjFFL)
      P-ENGINE 0: type EC02, rev 01
=====
UNIT 1: SL 2: ICX6650-64 4-port 160G Module
=====
UNIT 1: SL 3: ICX6650-64 8-port 80G Module
=====
      800 MHz Power PC processor 8544E (version 0021/0022) 400 MHz bus
      65536 KB flash memory
      1024 MB DRAM
      STACKID 1 system uptime is 23 hours 12 minutes 8 seconds
=====
                                HARDWARE INFORMATION
UNIT NAME      : ICX6650-64
HW REVISION    : 2 (BETA)
Board ID       : 4(ICX6650)

                                CPLD INFORMATION
CPLD code is RD revision
CPLD CODE REVISION = 6
=====
The system : started=warm start reloaded=by "reload"
*** NOT FOR PRODUCTION ***

```

The version information is shown in bold type in this example:

- “07.5.00T321” indicates the flash code version number. The “T321” is used by Brocade for record keeping.
- “labeled as ICXLS07500” indicates the flash code image label. The label indicates the image type and version and is especially useful if you change the image file name.
- “Secondary ICXLS07500.bin” indicates the flash code image file name that was loaded.

Displaying the boot image version running on the device

To determine the boot image running on a device, enter the **show flash** command at any level of the CLI. The following shows an example output.

```

Brocade#show flash
Stack unit 1:
  Compressed Pri Code size = 12849087, Version:07.5.00T323 (ICXLR07500B1.bin)
  Compressed Sec Code size = 12848889, Version:07.5.00T323 (ICXLR07500b1.bin)
  Compressed Boot-Monitor Image size = 524288, Version:07.5.00T7f5
  Code Flash Free Space = 21843968

```

The boot code version is shown in bold type.

Displaying the image versions installed in flash memory

Enter the **show flash** command to display the boot and flash images installed on the device. An example of the command output is shown in [“Displaying the boot image version running on the device”](#) on page 51:

- The “Compressed Pri Code size” line lists the flash code version installed in the primary flash area.

- The “Compressed Sec Code size” line lists the flash code version installed in the secondary flash area.
- The “Boot Monitor Image size” line lists the boot code version installed in flash memory. The device does not have separate primary and secondary flash areas for the boot image. The flash memory module contains only one boot image.

Flash image verification

The Flash Image Verification feature allows you to verify boot images based on hash codes, and to generate hash codes where needed. This feature lets you select from three data integrity verification algorithms:

- **MD5** - Message Digest algorithm (RFC 1321)
- **SHA1** - US Secure Hash Algorithm (RFC 3174)
- **CRC** - Cyclic Redundancy Checksum algorithm

Flash image CLI commands

Use the following command syntax to verify the flash image:

Syntax: `verify md5 | sha1 | crc32 <ASCII string> | primary | secondary [<hash code>]`

- **md5** – Generates a 16-byte hash code
- **sha1** – Generates a 20-byte hash code
- **crc32** – Generates a 4 byte checksum
- **ascii string** – A valid image filename
- **primary** – The primary boot image (primary.img)
- **secondary** – The secondary boot image (secondary.img)
- **hash code** – The hash code to verify

The following examples show how the **verify** command can be used in a variety of circumstances.

To generate an MD5 hash value for the secondary image, enter the following command.

```
Brocade#verify md5 secondary
Brocade#.....Done
Size = 2044830, MD5 01c410d6d153189a4a5d36c955653862
```

To generate a SHA-1 hash value for the secondary image, enter the following command.

```
Brocade#verify sha secondary
Brocade#.....Done
Size = 2044830, SHA1 49d12d26552072337f7f5fcaef4cf4b742a9f525
```

To generate a CRC32 hash value for the secondary image, enter the following command.

```
Brocade#verify crc32 secondary
Brocade#.....Done
Size = 2044830, CRC32 b31fcbcb0
```

To verify the hash value of a secondary image with a known value, enter the following commands.

```
Brocade#verify md5 secondary 01c410d6d153189a4a5d36c955653861
Brocade#.....Done
Size = 2044830, MD5 01c410d6d153189a4a5d36c955653862
Verification FAILED.
```

In the previous example, the codes did not match, and verification failed. If verification succeeds, the output will look like this.

```
Brocade#verify md5 secondary 01c410d6d153189a4a5d36c955653861
Brocade#.....Done
Size = 2044830, MD5 01c410d6d153189a4a5d36c955653861
Verification SUCCEEDED.
```

The following examples show this process for SHA-1 and CRC32 algorithms.

```
Brocade#verify sha secondary 49d12d26552072337f7f5fcaef4cf4b742a9f525
Brocade#.....Done
Size = 2044830, sha 49d12d26552072337f7f5fcaef4cf4b742a9f525
Verification SUCCEEDED.
```

and

```
Brocade#verify crc32 secondary b31fcabc0
Brocade#.....Done
Size = 2044830, CRC32 b31fcabc0
Verification SUCCEEDED.
```

Image file types

This section lists the uboot, router, and switch image file types supported and how to install them on the Brocade ICX 6650 switches. For information about a specific version of code, refer to the release notes.

TABLE 13 Software image files

Product	uboot image	Router image	Switch image
Brocade ICX 6650	fxz07500.bin	fxz07500.bin	ICXLR07500.bin

Software upgrades

Refer to the release notes for instructions about upgrading the software.

Viewing the contents of flash files

The **copy flash console** command can be used to display the contents of a configuration file, backup file, or renamed file stored in flash memory. The file contents are displayed on the console when the command is entered at the CLI.

To display a list of files stored in flash memory, enter the **show files** command at the device configuration prompt.

The following shows an example command output.

3 Using SNMP to upgrade software

```
Brocade#show dir
12703628 [4e58] primary
  12706082 [4e58] secondary
    668 [0000] $$$license
    463 [0000] startup-config.backup
    512 [0000] meta_data.bin
    432 [0000] startup-config
25411785 bytes 6 File(s)
21843968 bytes free
```

Syntax: show dir

To display the contents of a flash configuration file, enter a command such as the following from the User EXEC or Privileged EXEC mode of the CLI:

```
Brocade#copy flash console startup-config.backup
ver 07.5.00RC1T323
!
stack unit 1
  module 1 icx6650-64-56-port-management-module
  module 2 icx6650-64-4-port-160g-module
  module 3 icx6650-64-8-port-80g-module
!
!
!
!
!
!
!
!
!
!
ip default-network 10.20.68.129/8

!
!
interface management 1
  ip address 10.20.68.144 255.255.255.0
!
!
!
!
!
```

Syntax: copy flash console <filename>

For <filename>, enter the name of a file stored in flash memory.

Using SNMP to upgrade software

You can use a third-party SNMP management application such as HP OpenView to upgrade software on a Brocade device.

NOTE

The syntax shown in this section assumes that you have installed HP OpenView in the “/usr” directory.

NOTE

Brocade recommends that you make a backup copy of the startup-config file before you upgrade the software. If you need to run an older release, you will need to use the backup copy of the startup-config file.

1. Configure a read-write community string on the Brocade device, if one is not already configured. To configure a read-write community string, enter the following command from the global CONFIG level of the CLI.

```
snmp-server community <string> ro | rw
```

where *<string>* is the community string and can be up to 32 characters long.

2. On the Brocade device, enter the following command from the global CONFIG level of the CLI.

```
no snmp-server pw-check
```

This command disables password checking for SNMP set requests. If a third-party SNMP management application does not add a password to the password field when it sends SNMP set requests to a Brocade device, by default the Brocade device rejects the request.

3. From the command prompt in the UNIX shell, enter the following command.

```
/usr/OV/bin/snmpset -c <rw-community-string> <brcd-ip-addr> 1.3.6.1.4.1.1991.1.1.2.1.5.0  
ipaddress <tftp-ip-addr> 1.3.6.1.4.1.1991.1.1.2.1.6.0 octetstringascii <file-name>  
1.3.6.1.4.1.1991.1.1.2.1.7.0 integer <command-integer>
```

where

<rw-community-string> is a read-write community string configured on the Brocade device.

<brcd-ip-addr> is the IP address of the Brocade device.

<tftp-ip-addr> is the TFTP server IP address.

<file-name> is the image file name.

<command-integer> is one of the following.

20 – Download the flash code into the primary flash area.

22 – Download the flash code into the secondary flash area.

Software reboot

You can use boot commands to immediately initiate software boots from a software image stored in primary or secondary flash on a Brocade device or from a BootP or TFTP server. You can test new versions of code on a Brocade device or choose the preferred boot source from the console boot prompt without requiring a system reset.

NOTE

It is very important that you verify a successful TFTP transfer of the boot code **before** you reset the system. If the boot code is not transferred successfully but you try to reset the system, the system will not have the boot code with which to successfully boot.

By default, the Brocade device first attempts to boot from the image stored in its primary flash, then its secondary flash, and then from a TFTP server. You can modify this booting sequence at the global CONFIG level of the CLI using the **boot system...** command.

To initiate an immediate boot from the CLI, enter one of the **boot system...** commands.

NOTE

When using the **boot system tftp** command, the IP address of the device and the TFTP server should be in the same subnet.

Software boot configuration notes

- If you are booting the device from a TFTP server through a fiber connection, use the following command: **boot system tftp <ip-address> <filename> fiber-port**.

Displaying the boot preference

Use the **show boot-preference** command to display the boot sequence in the startup config and running config files. The boot sequence displayed is also identified as either user-configured or the default.

The following example shows the default boot sequence preference.

```
Brocade#show boot-preference
Boot system preference (Configured):
    Use Default
Boot system preference(Default):
    Boot system flash primary
    Boot system flash secondary
```

The following example shows a user-configured boot sequence preference.

```
Brocade#show boot-preference
Boot system preference(Configured):
    Boot system tftp 10.20.67.106 icxlr07500.bin

Boot system preference(Default):
    Boot system flash primary
    Boot system flash secondary
```

Syntax: show boot-preference

The results of the **show run** command for the configured example above appear as follows.

```

Brocade#show run
Current configuration:
!
ver 07.5.00B1T323
!
stack unit 1
  module 1 icx6650-64-56-port-management-module
  module 2 icx6650-64-4-port-160g-module
  module 3 icx6650-64-8-port-80g-module
!
!
trunk ethe 1/2/1 to 1/2/2
trunk ethe 1/2/3 to 1/2/4
!
vlan 1 name DEFAULT-VLAN by port
!
vlan 10 by port
!
vlan 20 by port
!
!
!
!
traffic-policy TPD1 rate-limit fixed 125 exceed-action Drop
!
!
!
!
fpod-40g-enable group 2
optical-monitor
chassis poll-time 200
ip show-portname
ip route 0.0.0.0 0.0.0.0 10.21.112.1
!
logging console
fdp run

!
!
router pim

!
end

```

Loading and saving configuration files

For easy configuration management, all Brocade devices support both the download and upload of configuration files between the devices and a TFTP server on the network.

You can upload either the startup configuration file or the running configuration file to the TFTP server for backup and use in booting the system:

- **Startup configuration file** – This file contains the configuration information that is currently saved in flash. To display this file, enter the **show configuration** command at any CLI prompt.

- **Running configuration file** – This file contains the configuration active in the system RAM but not yet saved to flash. These changes could represent a short-term requirement or general configuration change. To display this file, enter the **show running-config** or **write terminal** command at any CLI prompt.

Each device can have one startup configuration file and one running configuration file. The startup configuration file is shared by both flash modules. The running configuration file resides in DRAM.

When you load the startup-config file, the CLI parses the file three times.

1. During the first pass, the parser searches for **system-max** commands. A **system-max** command changes the size of statically configured memory.
2. During the second pass, the parser implements the **system-max** commands if present and also implements trunk configuration commands (**trunk** command) if present.
3. During the third pass, the parser implements the remaining commands.

Replacing the startup configuration with the running configuration

After you make configuration changes to the active system, you can save those changes by writing them to flash memory. When you write configuration changes to flash memory, you replace the startup configuration with the running configuration.

To replace the startup configuration with the running configuration, enter the following command at any Enable or CONFIG command prompt.

```
Brocade#write memory
```

Replacing the running configuration with the startup configuration

If you want to back out of the changes you have made to the running configuration and return to the startup configuration, enter the following command at the Privileged EXEC level of the CLI.

```
Brocade#reload
```

Logging changes to the startup-config file

You can configure a Brocade device to generate a Syslog message when the startup-config file is changed. The trap is enabled by default.

The following Syslog message is generated when the startup-config file is changed.

```
startup-config was changed
```

If the startup-config file was modified by a valid user, the following Syslog message is generated.

```
startup-config was changed by <username>
```

To disable or re-enable Syslog messages when the startup-config file is changed, use the following command.

Syntax: [no] logging enable config-changed

Copying a configuration file to or from a TFTP server

To copy the startup-config or running-config file to or from a TFTP server, use one of the following methods.

NOTE

For details about the **copy** and **ncopy** commands used with IPv6, refer to [“Using the IPv6 copy command”](#) on page 62 and [“IPv6 ncopy command”](#) on page 64.

NOTE

You can name the configuration file when you copy it to a TFTP server. However, when you copy a configuration file from the server to a Brocade device, the file is always copied as “startup-config” or “running-config”, depending on which type of file you saved to the server.

To initiate transfers of configuration files to or from a TFTP server using the CLI, enter one of the following commands:

- **copy startup-config tftp** <tftp-ip-addr> <filename> – Use this command to upload a copy of the startup configuration file from the Layer 2 Switch or Layer 3 Switch to a TFTP server.
- **copy running-config tftp** <tftp-ip-addr> <filename> – Use this command to upload a copy of the running configuration file from the Layer 2 Switch or Layer 3 Switch to a TFTP server.
- **copy tftp startup-config** <tftp-ip-addr> <filename> – Use this command to download a copy of the startup configuration file from a TFTP server to a Layer 2 Switch or Layer 3 Switch.

Dynamic configuration loading

You can load dynamic configuration commands (commands that do not require a reload to take effect) from a file on a TFTP server into the running-config on the Brocade device. You can make configuration changes off-line, then load the changes directly into the device running-config, without reloading the software.

Dynamic configuration usage considerations

- Use this feature only to load configuration information that does not require a software reload to take effect. For example, you cannot use this feature to change statically configured memory (**system-max** command).
- Do not use this feature if you have deleted a trunk group but have not yet placed the changes into effect by saving the configuration and then reloading. When you delete a trunk group, the command to configure the trunk group is removed from the device running-config, but the trunk group remains active. To finish deleting a trunk group, save the configuration (to the startup-config file), then reload the software. After you reload the software, then you can load the configuration from the file.
- Do not load port configuration information for secondary ports in a trunk group. Since all ports in a trunk group use the port configuration settings of the primary port in the group, the software cannot implement the changes to the secondary port.

Preparing the configuration file

A configuration file that you create must follow the same syntax rules as the startup-config file the device creates.

- The configuration file is a script containing CLI configuration commands. The CLI reacts to each command entered from the file in the same way the CLI reacts to the command if you enter it. For example, if the command results in an error message or a change to the CLI configuration level, the software responds by displaying the message or changing the CLI level.
- The software retains the running-config that is currently on the device, and changes the running-config only by adding new commands from the configuration file. If the running config already contains a command that is also in the configuration file you are loading, the CLI rejects the new command as a duplicate and displays an error message. For example, if the running-config already contains a command that configures ACL 1, the software rejects ACL 1 in the configuration file, and displays a message that ACL 1 is already configured.
- The file can contain global CONFIG commands or configuration commands for interfaces, routing protocols, and so on. You cannot enter User EXEC or Privileged EXEC commands.
- The default CLI configuration level in a configuration file is the global CONFIG level. Thus, the first command in the file must be a global CONFIG command or “!”. The ! (exclamation point) character means “return to the global CONFIG level”.

NOTE

You can enter text following “!” as a comment. However, the “!” is not a comment marker. It returns the CLI to the global configuration level.

NOTE

If you copy-and-paste a configuration into a management session, the CLI ignores the “!” instead of changing the CLI to the global CONFIG level. As a result, you might get different results if you copy-and-paste a configuration instead of loading the configuration using TFTP.

- Make sure you enter each command at the correct CLI level. Since some commands have identical forms at both the global CONFIG level and individual configuration levels, if the CLI response to the configuration file results in the CLI entering a configuration level you did not intend, then you can get unexpected results.

For example, if a trunk group is active on the device, and the configuration file contains a command to disable STP on one of the secondary ports in the trunk group, the CLI rejects the commands to enter the interface configuration level for the port and moves on to the next command in the file you are loading. If the next command is a spanning-tree command whose syntax is valid at the global CONFIG level as well as the interface configuration level, then the software applies the command globally. Here is an example.

The configuration file contains these commands.

```
interface ethernet 1/1/7
no spanning-tree
```

The CLI responds like this.

```
Brocade(config)#interface ethernet 1/1/7
Error - cannot configure secondary ports of a trunk
Brocade(config)#no spanning-tree
Brocade(config)#
```

- If the file contains commands that must be entered in a specific order, the commands must appear in the file in the required order. For example, if you want to use the file to replace an IP address on an interface, you must first remove the old address using “no” in front of the **ip address** command, then add the new address. Otherwise, the CLI displays an error message and does not implement the command. Here is an example.

The configuration file contains these commands.

```
interface ethernet 1/1/7
ip address 10.10.10.69/24
```

The running-config already has a command to add an address to port 11, so the CLI responds like this.

```
Brocade(config)#interface ethernet 1/1/7
Brocade(config-if-e10000-1/1/7)#ip add 10.10.10.69/24
Error: can only assign one primary ip address per subnet
Brocade(config-if-e10000-1/1/7)#
```

To successfully replace the address, enter commands into the file as follows.

```
interface ethernet 1/1/7
no ip address 10.20.20.69/24
ip address 10.10.10.69/24
```

This time, the CLI accepts the command, and no error message is displayed.

```
Brocade(config)#interface ethernet 1/1/7
Brocade(config-if-e10000-1/1/7)#no ip add 10.20.20.69/24
Brocade(config-if-e10000-1/1/7)#ip add 10.10.10.69/24
Brocade(config-if-e10000-1/1/7)
```

- Always use the **end** command at the end of the file. The **end** command must appear on the last line of the file, by itself.

Loading the configuration information into the running-config

To load the file from a TFTP server, use either of the following commands:

- **copy tftp running-config** <ip-addr> <filename>
- **ncopy tftp** <ip-addr> <filename> **running-config**

NOTE

If you are loading a configuration file that uses a truncated form of the CLI command **access-list**, the software will not go into batch mode.

For example, the following command line *will initiate* batch mode.

```
access-list 131 permit host pc1 host pc2
```

The following command line *will not* initiate batch mode.

```
acc 131 permit host pc1 host pc2
```

Maximum file sizes for startup-config file and running-config

Each Brocade device has a maximum allowable size for the running-config and the startup-config file. If you use TFTP to load additional information into a device running-config or startup-config file, it is possible to exceed the maximum allowable size. If this occurs, you will not be able to save the configuration changes.

The maximum size for the running-config and the startup-config file is 640K each.

To determine the size of a running-config or startup-config file, copy it to a TFTP server, then use the directory services on the server to list the size of the copied file. To copy the running-config or startup-config file to a TFTP server, use one of the following commands:

- Commands to copy the running-config to a TFTP server:
 - **copy running-config tftp** <ip-addr> <filename>
 - **ncopy running-config tftp** <ip-addr> <from-name>
- Commands to copy the startup-config file to a TFTP server:
 - **copy startup-config tftp** <ip-addr> <filename>
 - **ncopy startup-config tftp** <ip-addr> <from-name>

Loading and saving configuration files with IPv6

This section describes the IPv6 **copy** and **ncopy** commands.

Using the IPv6 copy command

The **copy** command for IPv6 allows you to do the following:

- Copy a file from a specified source to an IPv6 TFTP server
- Copy a file from an IPv6 TFTP server to a specified destination

Copying a file to an IPv6 TFTP server

You can copy a file from the following sources to an IPv6 TFTP server:

- Flash memory
- Running configuration
- Startup configuration

Copying a file from flash memory

For example, to copy the primary or secondary boot image from the device flash memory to an IPv6 TFTP server, enter a command such as the following.

```
Brocade#copy flash tftp 2001:DB8:e0ff:7837::3 test.img secondary
```

This command copies the secondary boot image named test.img from flash memory to a TFTP server with the IPv6 address of 2001:DB8:e0ff:7837::3.

Syntax: **copy flash tftp** <ipv6-address> <source-file-name> **primary** | **secondary**

The <ipv6-address> parameter specifies the address of the TFTP server. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The <source-file-name> parameter specifies the name of the file you want to copy to the IPv6 TFTP server.

The **primary** keyword specifies the primary boot image, while the **secondary** keyword specifies the secondary boot image.

Copying a file from the running or startup configuration

For example, to copy the running configuration to an IPv6 TFTP server, enter a command such as the following.


```
Brocade#copy running-config tftp 2001:DB8:e0ff:7837::3 newrun.cfg
```

This command copies the running configuration to a TFTP server with the IPv6 address of 2001:DB8:e0ff:7837::3 and names the file on the TFTP server newrun.cfg.

Syntax: `copy running-config | startup-config tftp <ipv6-address> <destination-file-name>`

Specify the **running-config** keyword to copy the running configuration file to the specified IPv6 TFTP server.

Specify the **startup-config** keyword to copy the startup configuration file to the specified IPv6 TFTP server.

The `tftp <ipv6-address>` parameter specifies the address of the TFTP server. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The `<destination-file-name>` parameter specifies the name of the file that is copied to the IPv6 TFTP server.

Copying a file from an IPv6 TFTP server

You can copy a file from an IPv6 TFTP server to the following destinations:

- Flash memory
- Running configuration
- Startup configuration

Copying a file to flash memory

For example, to copy a boot image from an IPv6 TFTP server to the primary or secondary storage location in the device flash memory, enter a command such as the following.

```
Brocade#copy tftp flash 2001:DB8:e0ff:7837::3 test.img secondary
```

This command copies a boot image named test.img from an IPv6 TFTP server with the IPv6 address of 2001:DB8:e0ff:7837::3 to the secondary storage location in the device flash memory.

Syntax: `copy tftp flash <ipv6-address> <source-file-name> primary | secondary`

The `<ipv6-address>` parameter specifies the address of the TFTP server. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The `<source-file-name>` parameter specifies the name of the file you want to copy from the IPv6 TFTP server.

The **primary** keyword specifies the primary storage location in the device flash memory, while the **secondary** keyword specifies the secondary storage location in the device flash memory.

Copying a file to the running or startup configuration

For example, to copy a configuration file from an IPv6 TFTP server to the running or startup configuration, enter a command such as the following.

```
Brocade#copy tftp running-config 2001:DB8:e0ff:7837::3 newrun.cfg overwrite
```

This command copies the newrun.cfg file from the IPv6 TFTP server and overwrites the running configuration file with the contents of newrun.cfg.

NOTE

To activate this configuration, you must reload (reset) the device.

Syntax: `copy tftp running-config | startup-config <ipv6-address> <source-file-name> [overwrite]`

Specify the **running-config** keyword to copy the running configuration from the specified IPv6 TFTP server.

The `<ipv6-address>` parameter specifies the address of the TFTP server. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The `<source-file-name>` parameter specifies the name of the file that is copied from the IPv6 TFTP server.

The **overwrite** keyword specifies that the device should overwrite the current configuration file with the copied file. If you do not specify this parameter, the device copies the file into the current running or startup configuration but does not overwrite the current configuration.

IPv6 ncopy command

The **ncopy** command for IPv6 allows you to do the following:

- Copy a primary or secondary boot image from flash memory to an IPv6 TFTP server.
- Copy the running configuration to an IPv6 TFTP server.
- Copy the startup configuration to an IPv6 TFTP server
- Upload various files from an IPv6 TFTP server.

Copying a primary or secondary boot image from flash memory to an IPv6 TFTP server

For example, to copy the primary or secondary boot image from the device flash memory to an IPv6 TFTP server, enter a command such as the following.

```
Brocade#ncopy flash primary tftp 2001:DB8:e0ff:7837::3 primary.img
```

This command copies the primary boot image named `primary.img` from flash memory to a TFTP server with the IPv6 address of `2001:DB8:e0ff:7837::3`.

Syntax: `ncopy flash primary | secondary tftp <ipv6-address> <source-file-name>`

The **primary** keyword specifies the primary boot image, while the **secondary** keyword specifies the secondary boot image.

The **tftp** `<ipv6-address>` parameter specifies the address of the TFTP server. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The `<source-file-name>` parameter specifies the name of the file you want to copy from flash memory.

Copying the running or startup configuration to an IPv6 TFTP server

For example, to copy a device running or startup configuration to an IPv6 TFTP server, enter a command such as the following.

```
Brocade#ncopy running-config tftp 2001:DB8:e0ff:7837::3 bakrun.cfg
```

This command copies a device running configuration to a TFTP server with the IPv6 address of 2001:DB8:e0ff:7837::3 and names the destination file bakrun.cfg.

Syntax: `ncopy running-config | startup-config tftp <ipv6-address> <destination-file-name>`

Specify the **running-config** keyword to copy the device running configuration or the **startup-config** keyword to copy the device startup configuration.

The **tftp <ipv6-address>** parameter specifies the address of the TFTP server. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The **<destination-file-name>** parameter specifies the name of the running configuration that is copied to the IPv6 TFTP server.

IPv6 TFTP server file upload

You can upload the following files from an IPv6 TFTP server:

- Primary boot image.
- Secondary boot image.
- Running configuration.
- Startup configuration.

Uploading a primary or secondary boot image from an IPv6 TFTP server

For example, to upload a primary or secondary boot image from an IPv6 TFTP server to a device flash memory, enter a command such as the following.

```
Brocade#ncopy tftp 2001:DB8:e0ff:7837::3 primary.img flash primary
```

This command uploads the primary boot image named primary.img from a TFTP server with the IPv6 address of 2001:DB8:e0ff:7837::3 to the device primary storage location in flash memory.

Syntax: `ncopy tftp <ipv6-address> <source-file-name> flash primary | secondary`

The **tftp <ipv6-address>** parameter specifies the address of the TFTP server. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The **<source-file-name>** parameter specifies the name of the file you want to copy from the TFTP server.

The **primary** keyword specifies the primary location in flash memory, while the **secondary** keyword specifies the secondary location in flash memory.

Uploading a running or startup configuration from an IPv6 TFTP server

For example to upload a running or startup configuration from an IPv6 TFTP server to a device, enter a command such as the following.

```
Brocade#ncopy tftp 2001:DB8:e0ff:7837::3 newrun.cfg running-config
```

This command uploads a file named newrun.cfg from a TFTP server with the IPv6 address of 2001:DB8:e0ff:7837::3 to the device.

Syntax: `ncopy tftp <ipv6-address> <source-file-name> running-config | startup-config`

The **tftp** *<ipv6-address>* parameter specifies the address of the TFTP server. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The *<source-file-name>* parameter specifies the name of the file you want to copy from the TFTP server.

Specify the **running-config** keyword to upload the specified file from the IPv6 TFTP server to the device. The device copies the specified file into the current running configuration but does not overwrite the current configuration.

Specify the **startup-config** keyword to upload the specified file from the IPv6 TFTP server to the device. The device copies the specified file into the current startup configuration but does not overwrite the current configuration.

Using SNMP to save and load configuration information

You can use a third-party SNMP management application such as HP OpenView to save and load a configuration on a Brocade device. To save and load configuration information using HP OpenView, use the following procedure.

NOTE

The syntax shown in this section assumes that you have installed HP OpenView in the “/usr” directory.

1. Configure a read-write community string on the Brocade device, if one is not already configured. To configure a read-write community string, enter the following command from the global CONFIG level of the CLI.

snmp-server community *<string>* **ro | rw**

where *<string>* is the community string and can be up to 32 characters long.

2. On the Brocade device, enter the following command from the global CONFIG level of the CLI.

no snmp-server pw-check

This command disables password checking for SNMP set requests. If a third-party SNMP management application does not add a password to the password field when it sends SNMP set requests to a Brocade device, by default the Brocade device rejects the request.

3. From the command prompt in the UNIX shell, enter the following command.

```
/usr/OV/bin/snmpset -c <rw-community-string> <fdry-ip-addr> 1.3.6.1.4.1.1991.1.1.2.1.5.0
ipaddress <tftp-ip-addr> 1.3.6.1.4.1.1991.1.1.2.1.8.0 octetstringascii <config-file-name>
1.3.6.1.4.1.1991.1.1.2.1.9.0 integer <command-integer>
```

where

<rw-community-string> is a read-write community string configured on the Brocade device.

<fdry-ip-addr> is the IP address of the Brocade device.

<tftp-ip-addr> is the TFTP server IP address.

<config-file-name> is the configuration file name.

<command-integer> is one of the following:

20 – Upload the startup-config file from the flash memory of the Brocade device to the TFTP server.

21 – Download a startup-config file from a TFTP server to the flash memory of the Brocade device.

22 – Upload the running-config from the flash memory of the Brocade device to the TFTP server.

23 – Download a configuration file from a TFTP server into the running-config of the Brocade device.

NOTE

Option **23** adds configuration information to the running-config on the device, and does not replace commands. If you want to replace configuration information in the device, use “no” forms of the configuration commands to remove the configuration information, then use configuration commands to create the configuration information you want. Follow the guidelines in [“Dynamic configuration loading”](#) on page 59.

Erasing image and configuration files

To erase software images or configuration files, use the commands described below. These commands are valid at the Privileged EXEC level of the CLI:

- **erase flash primary** erases the image stored in primary flash of the system.
- **erase flash secondary** erases the image stored in secondary flash of the system.
- **erase startup-config** erases the configuration stored in the startup configuration file; however, the running configuration remains intact until system reboot.

System reload scheduling

In addition to reloading the system manually, you can configure the Brocade device to reload itself at a specific time or after a specific amount of time has passed.

NOTE

The scheduled reload feature requires the system clock. You can use a Simple Network Time Protocol (SNTP) server to set the clock or you can set the device clock manually. Refer to [“Specifying an SNTP server”](#) on page 20 or [“Setting the system clock”](#) on page 26.

Reloading at a specific time

To schedule a system reload for a specific time, use the **reload at** command. For example, to schedule a system reload from the primary flash module for 6:00:00 AM, April 1, 2003, enter the following command at the global CONFIG level of the CLI.

```
Brocade#reload at 06:00:00 04-01-03
```

Syntax: **reload at** <hh:mm:ss> <mm-dd-yy> [**primary** | **secondary**]

<hh:mm:ss> is the hours, minutes, and seconds.

<mm-dd-yy> is the month, day, and year.

primary | secondary specifies whether the reload is to occur from the primary code flash module or the secondary code flash module. The default is **primary**.

Reloading after a specific amount of time

To schedule a system reload to occur after a specific amount of time has passed on the system clock, use **reload after** command. For example, to schedule a system reload from the secondary flash one day and 12 hours later, enter the following command at the global CONFIG level of the CLI.

```
Brocade#reload after 01:12:00 secondary
```

Syntax: **reload after** <dd:hh:mm> [**primary | secondary**]

<dd:hh:mm> is the number of days, hours, and minutes.

primary | secondary specifies whether the reload is to occur from the primary code flash module or the secondary code flash module.

Displaying the amount of time remaining before a scheduled reload

To display how much time is remaining before a scheduled system reload, enter the following command from any level of the CLI.

```
Brocade#show reload
```

Canceling a scheduled reload

To cancel a scheduled system reload using the CLI, enter the following command at the global CONFIG level of the CLI.

```
Brocade#reload cancel
```

Diagnostic error codes and remedies for TFTP transfers

This section describes the error messages associated with TFTP transfer of configuration files, software images or flash images to or from a Brocade device.

Error code	Message	Explanation and action
1	Flash read preparation failed.	A flash error occurred during the download. Retry the download. If it fails again, contact customer support.
2	Flash read failed.	
3	Flash write preparation failed.	
4	Flash write failed.	
5	TFTP session timeout.	TFTP failed because of a time out. Check IP connectivity and make sure the TFTP server is running.

Error code	Message	Explanation and action
6	TFTP out of buffer space.	The file is larger than the amount of room on the device or TFTP server. If you are copying an image file to flash, first copy the other image to your TFTP server, then delete it from flash. (Use the erase flash... CLI command at the Privileged EXEC level to erase the image in the flash.) If you are copying a configuration file to flash, edit the file to remove unnecessary information, then try again.
7	TFTP busy, only one TFTP session can be active.	Another TFTP transfer is active on another CLI session, or network management system. Wait, then retry the transfer.
8	File type check failed.	You accidentally attempted to copy the incorrect image code into the system. For example, you might have tried to copy a Chassis image into a Compact device. Retry the transfer using the correct image.
16	TFTP remote - general error.	The TFTP configuration has an error. The specific error message describes the error. Correct the error, then retry the transfer.
17	TFTP remote - no such file.	
18	TFTP remote - access violation.	
19	TFTP remote - disk full.	
20	TFTP remote - illegal operation.	
21	TFTP remote - unknown transfer ID.	
22	TFTP remote - file already exists.	
23	TFTP remote - no such user.	

Network connectivity testing

After you install the network cables, you can test network connectivity to other devices by pinging those devices. You also can observe the LEDs related to network connection and perform trace routes.

For more information about observing LEDs, refer to the *Brocade ICX 6650 Hardware Installation Guide*.

Pinging an IPv4 address

NOTE

This section describes the *IPv4 ping* command. For details about *IPv6 ping*, refer to [“Pinging an IPv6 address”](#) on page 116.

To verify that a Brocade device can reach another device through the network, enter a command such as the following at any level of the CLI on the Brocade device:

```
Brocade> ping 192.33.4.7
```

Syntax: `ping <ip addr> | <hostname> [source <ip addr>] [count <num>] [timeout <msec>] [ttl <num>] [size <byte>] [quiet] [numeric] [no-fragment] [verify] [data <1-to-4 byte hex>] [brief [max-print-per-sec <number>]]`

NOTE

If the device is a Brocade Layer 2 Switch or Layer 3 Switch, you can use the host name only if you have already enabled the Domain Name Server (DNS) resolver feature on the device from which you are sending the ping. Refer to Brocade ICX 6650 Switch Layer 3 Routing Configuration Guide.

The required parameter is the IP address or host name of the device.

The **source** `<ip addr>` specifies an IP address to be used as the origin of the ping packets.

The **count** `<num>` parameter specifies how many ping packets the device sends. You can specify from 1 – 4294967296. The default is 1.

The **timeout** `<msec>` parameter specifies how many milliseconds the Brocade device waits for a reply from the pinged device. You can specify a timeout from 1 – 4294967296 milliseconds. The default is 5000 (5 seconds).

The **ttl** `<num>` parameter specifies the maximum number of hops. You can specify a TTL from 1 – 255. The default is 64.

The **size** `<byte>` parameter specifies the size of the ICMP data portion of the packet. This is the payload and does not include the header. You can specify from 0 – 4000. The default is 16.

The **no-fragment** parameter turns on the “don’t fragment” bit in the IP header of the ping packet. This option is disabled by default.

The **quiet** parameter hides informational messages such as a summary of the ping parameters sent to the device and instead only displays messages indicating the success or failure of the ping. This option is disabled by default.

The **verify** parameter verifies that the data in the echo packet (the reply packet) is the same as the data in the echo request (the ping). By default the device does not verify the data.

The **data** `<1 – 4 byte hex>` parameter lets you specify a specific data pattern for the payload instead of the default data pattern, “abcd”, in the packet data payload. The pattern repeats itself throughout the ICMP message (payload) portion of the packet.

NOTE

For numeric parameter values, the CLI does not check that the value you enter is within the allowed range. Instead, if you do exceed the range for a numeric value, the software rounds the value to the nearest valid value.

The **brief** parameter causes ping test characters to be displayed. The following ping test characters are supported:

- ! Indicates that a reply was received.
- . Indicates that the network server timed out while waiting for a reply.
- U Indicates that a destination unreachable error PDU was received.
- I Indicates that the user interrupted ping.

NOTE

The number of ! characters displayed may not correspond to the number of successful replies by the **ping** command. Similarly, the number of . characters displayed may not correspond to the number of server timeouts that occurred while waiting for a reply. The "success" or "timeout" results are shown in the display as "Success rate is XX percent (X/Y)".

The optional **max-print-per-sec** *<number>* parameter specifies the maximum number of target responses the Brocade device can display per second while in brief mode. You can specify from 0 – 2047. The default is 511.

NOTE

If you address the ping to the IP broadcast address, the device lists the first four responses to the ping.

Tracing an IPv4 route

NOTE

This section describes the *IPv4* **traceroute** command. For details about *IPv6* **traceroute**, refer to ["IPv6 traceroute"](#) on page 114.

Use the **traceroute** command to determine the path through which a Brocade device can reach another device. Enter the command at any level of the CLI.

The CLI displays trace route information for each hop as soon as the information is received. Traceroute requests display all responses to a given TTL. In addition, if there are multiple equal-cost routes to the destination, the Brocade device displays up to three responses by default.

```
Brocade> traceroute 192.33.4.7
```

Syntax: **traceroute** *<host-ip-addr>* [**maxttl** *<value>*] [**minttl** *<value>*] [**numeric**] [**timeout** *<value>*] [**source-ip** *<ip-addr>*]

Possible and default values are as follows.

minttl – minimum TTL (hops) value: Possible values are 1 – 255. Default value is 1 second.

maxttl – maximum TTL (hops) value: Possible values are 1 – 255. Default value is 30 seconds.

timeout – Possible values are 1 – 120. Default value is 2 seconds.

numeric – Lets you change the display to list the devices by their IP addresses instead of their names.

source-ip *<ip-addr>* – Specifies an IP address to be used as the origin for the traceroute.

3 Network connectivity testing

Ports on Demand Licensing

In this chapter

- Ports on Demand terminology 74
- PoD licensing rules 74
- PoD licensing configuration tasks 74
- Viewing PoD licensing information from the Brocade software portal 80
- Transferring a PoD license 82
- Syslog message information..... 82
- Ports on Demand Licensing 82
- Viewing information about PoD licenses 91

Ports on Demand Overview

The Brocade ICX 6650 device features Ports on Demand licensing. With Ports on Demand licensing, software features do not require licenses and you can add port licenses as needed.

The Brocade ICX 6650 device supports:

- 56 front-panel, dual-speed 1/10 GbE SFP+ ports
- 4 rear-panel 40 GbE QSFP+ ports
- 2 rear-panel 4x10 GbE QSFP+ breakout ports.

When a license is ordered, an entitlement certificate or e-mail message, along with a transaction key, are issued to the customer by Brocade as proof of purchase. The transaction key and License ID (LID) of the Brocade device are used to generate a license key from the Brocade software licensing portal. The license key is contained within a license file, which is downloaded to the customer's PC, where the file can then be transferred to a TFTP or SCP server, and then uploaded to the Brocade device.

[Table 14](#) lists the Brocade ICX 6650 and the Ports on Demand (PoD) licensing features the switch supports.

TABLE 14 Supported Ports on Demand features

Feature	Brocade ICX 6650
License generation	Yes
License query	Yes
Deleting a license	Yes

Ports on Demand terminology

Ports on Demand licensing uses the following terms:

- **Entitlement certificate** – The proof-of-purchase certificate (paper-pack) issued by Brocade when a license is purchased. The certificate contains a unique transaction key that is used in conjunction with the License ID of the Brocade device to generate and download a PoD license from the Brocade software portal.
- **Transaction key** – A unique key, along with the LID, used to generate a PoD license from the Brocade software portal. The transaction key is issued by Brocade when a license is purchased. The transaction key is delivered according to the method specified when the order is placed:
 - **Paper-pack** – The transaction key is recorded on an entitlement certificate, which is mailed to the customer.
 - **Electronic** – The transaction key is contained in an e-mail message, which is sent instantly to the customer after the order is placed. The customer receives the e-mail message within a few minutes after the order is placed, though the timing will vary depending on the network, Internet connection, and so on.

If a delivery method is not specified at the time of the order, the key will be delivered by the way of paper-pack.

- **License ID (LID)** – This is a character string (not necessarily numbers) that uniquely identifies the Brocade device. The LID is used in conjunction with a transaction key to generate and download a PoD license from the Brocade software portal. The PoD license is tied to the LID of the Brocade device for which the license was ordered and generated.
- **License file** – The file containing the license key produced by the Brocade software portal when the license is generated. The license file will enable additional ports on the specific device once installed.

PoD licensing rules

The following licensing rules apply to Brocade ICX 6650 devices:

- A license is tied to the unique LID of the switch for which the license was ordered. Therefore, a license can only be used on the device which LID is used to generate the license. It cannot be used on any other device.
- More than one license can be installed per device.

PoD licensing configuration tasks

To obtain and install a PoD license, follow the configuration tasks listed in [Table 15](#).

TABLE 15 Configuration tasks for Ports on Demand licensing

Configuration task	Reference
1 Order the desired license.	For a list of available licenses and associated license SKU numbers, refer to Table 17 on page 84.
2 When you receive the transaction key, retrieve the LID of the Brocade device. If you received the transaction key by way of paper-pack, record the LID on the entitlement certificate in the space provided.	“Viewing the LID and the software packages installed in the device” on page 91
3 Log in to the Brocade software portal to generate and obtain the license file.	“Obtaining a PoD license” on page 75
4 Upload the license file to the Brocade device.	“Enabling ports on the front panel” on page 84 “Enabling ports on the rear panel” on page 87
5 Verify that the license is installed.	“Displaying general license information for PoD ports” on page 92

Obtaining a PoD license

To generate and obtain a PoD license, complete the following steps.

1. Order a PoD license. Refer to [Table 17](#) on page 84 for a list of available licenses and associated license SKU numbers.
2. When you receive the paper-pack or electronic transaction key, retrieve the LID of your Brocade device by entering the **show version** command on the device. Refer to [“Viewing the LID and the software packages installed in the device”](#) on page 91.” for an example command output.

If you received a paper-pack transaction key, write the LID in the space provided on the entitlement certificate.

NOTE

Do not discard the entitlement certificate or the e-mail message with the electronic key. Keep it in a safe place in case it is needed for technical support or product replacement (RMAs).

3. Log in to the Brocade software portal at <http://swportal.brocade.com> and complete the PoD license request. If you do not have a login ID and password, request access by following the instructions on the screen. Refer to [Figure 1](#) on page 76.

Figure 1 shows the **Software Portal Login** window.

FIGURE 1 Brocade Software Portal Login window

International

Brocade

Products Solutions & Technology Services & Support Education Partnerships Company

Search

Log In

User ID:
(e.g. John.Doe@abc.com)

Password:

Take me to: Software Licensing

LOG IN »

[Forgot your ID or password?](#) [Help](#)

Register with Brocade

Register your Brocade products and gain access to MyBrocade, Brocade Communities and Brocade Training.

REGISTER NOW »

If you did not receive your registration activation email, [Click Here](#)

Unlock powerful online tools such as Support Cases and Knowledge Base when you purchase a **Brocade Technical Support plan**

LEARN MORE »

[RSS Feeds](#) | [Contact Us](#) | [Site Map](#) | [Privacy](#) | [Legal](#) | [Careers](#) | [Investor Relations](#)

From the **License Management** menu, select **Brocade IP/ADP > License Generation with Transaction key**. The **IP/ADP License Generation** window displays.

FIGURE 2 License Management Welcome window




Figure 3 shows the **IP/ADP License Generation** window for generating a license using a transaction key and LID.

FIGURE 3 IP/ADP License Generation window

IP/ADP Licence Generation

Please check the Unique ID to make sure it is correct! License install failure may result!

Customer Information	
* Indicates required field	
Customer email ID*	<input type="text"/>
Site Name	<input type="text"/>
Technical Contact	<input type="text"/>
Company Name	<input type="text"/>
City	<input type="text"/>
State/Province	<input type="text"/>
Zip/Postal Code	<input type="text"/>
Country	Select Country <input type="button" value="v"/>
Phone	<input type="text"/>

E-mail Notification Information	
Self	<input type="text" value="support1@brocade.com"/>
<input type="checkbox"/> Other e-mail address(es)	<input type="text"/>

Unit Information	
Unique ID Type*	LID <input type="button" value="v"/>
Unit's Unique ID*	<input type="text"/>
Transaction Key*	<input type="text"/>
<input type="button" value="Add"/>	

<input type="checkbox"/> I have read and accept the Brocade End User License Agreement	
<input type="button" value="Generate"/>	<input type="button" value="Cancel"/>

Enter the required information.

- For a description of the field, move the pointer over the field.
- An asterisk next to a field indicates that the information is required.

NOTE

You can generate more than one license at a time. For each license request, enter the **Unit's Unique License ID** and **Transaction Key**, and click **Add**.

When you have finished entering the required information, read the Brocade End User License Agreement, and select the **I have read and accept the Brocade End User License Agreement** check box.

Click the **Generate** button to generate the license. Figure 4 shows the **IP/ADP License Generation Result** window, which displays an order summary and the results of the license request.

- If the license request is successful, the **Status** field shows "Success" and the **License File** field contains a hyperlink to the generated license file. The license file is automatically sent by e-mail to the specified customer e-mail address.
- If the license request fails, the **Status** field indicates the reason it failed and the action to be taken.

FIGURE 4 IP/ADP License Generation Result window

IP/ADP License Generation - Result

Customer Information	
Customer email ID	partner501@company.com
Site Name	
Technical Contact	
Company Name	
City	
State/Province	
Zip/Postal Code	
Country	
Phone	

Following Generated Licenses have been sent to Email ID(s): **partner501@company.com**

ID Type	Unique Id	Transaction Key	Description	Status	License File
LID	pkeguceGFHM	A0D57D0038E39D9427131B	BR-NI-CES-2048-L3U	Success	License Key

Generate Another License

4. Download the license file to your PC by either clicking the hyperlink in the **License File** field or saving the license file from the e-mail attachment.

5. Upload the license file to the Brocade device.
6. Use the **show license** command to verify that the license is correctly installed on the device.

Viewing PoD licensing information from the Brocade software portal

This section describes other PoD licensing tasks supported from the Brocade software portal. You can use the **License Query** option to view PoD license information for a particular unit, transaction key, or both. You can export the report to Excel for sharing or archiving purposes.

Depending on the status of the license (for example, whether the license was generated), the report will include the following Information:

- Hardware part number, serial number, and description
- Software part number, serial number, and description
- Date the license was installed
- Transaction key
- LID
- Feature name
- Product line

To display information about the license, select **Brocade IP/ADP > License Query**.

The **License Query** window displays. (Refer to Figure 5).

FIGURE 5 License Query window

The screenshot shows a web-based form titled "IP/ADP Unit License Query". The form contains three input fields: "ID Type" (a dropdown menu with "LID" selected), "Unit ID" (a text input field), and "Transaction key" (a text input field). Below these fields are two buttons: "Search" and "Cancel".

- To view software license information for a particular unit, enter the LID in the **Unit ID** field and click **Search**.
- To view software license information for a particular transaction key, enter the unique number in the **Transaction key** field and click **Search**.

NOTE

The transaction search will not return any results if the transaction key has not been activated.

Figure 6 shows an example of the license query results.

FIGURE 6 License Query Results window

BROCADE support1 Log Out

License Management

IP/ADP Unit License Query

IP/ADP Unit License Query

ID Type: LID

Unit ID:

Transaction key: FD8D0E5BD8842E13D32C5

Search Cancel

Level	Part Number	Serial Number	Installed Date	License File	Transaction Key	LID	Feature Name	Description	Product Line
1	NI-CER-2048C-AC	NICERAC1099				pkegtceGFOO		NI CER 2048C 1 500W AC BASE SW	NICER2048
2	BR-NI-CER-2048-ADV	UA200001757	02-Feb-2010	License File	FD8D0E5BD8842E13D32C5D	pkegtceGFOO	BR-NI-CER-2048-ADV	BR-NI-CER-2048-ADV	CER 2048C

Export to excel

Contact Us | Site Map | Privacy | Legal | Investor Relation

In this example, the line items for Level 1 display hardware-related information and the line items for Level 2 display software-related information. If the query was performed before the transaction key was generated, the first row (Level 1) would not appear as part of the search results. Similarly, if the query was performed before the license was generated, some of the information in the second row would not be displayed.

Transferring a PoD license

A license can be transferred between Brocade devices if both the following conditions are true:

- The device is under an active support contract.
- The license is being transferred between two similar models (for example, from a 24-port model to another 24-port model or from a 48-port model to another 48-port model).

NOTE

Transferring a license is only available internally for TAC, and externally for designated partners with specific accounts in the Brocade software portal. Contact your Brocade representative for more information.

Syslog message information

Table 16 lists the syslog messages that are supported for software-based licensing.

TABLE 16 Syslog messages

Message level	Message	Explanation
Informational	Router License: Normal license package <license_name> with LID <LID_number> is added on <unit_id>	The license package has been added.
Informational	Router License: Normal license package <license_name> with LID <LID_number> is removed on <unit_id>	The license package has been deleted.

Ports on Demand Licensing


The Brocade ICX 6650 has the following ports:

Front panel PoD

The front panel has the following fixed PoD ports:

- Ports 1/1/1 to 1/1/32 are enabled by default.
- Ports 1/1/33 to 1/1/56 are disabled by default and are in an error-disabled state. For a detailed description of the port states (up, down, or error-disabled), refer to [“Configuration considerations when configuring PoD for Brocade ICX 6650 devices”](#) on page 96.

Refer to [Figure 7](#) below for an illustration of the front panel ports.

FIGURE 7 Brocade ICX 6650 front panel

Rear panel Flexible Ports on Demand


The rear panel has 6 QSFP+ ports:

- 2 pairs of 40 ports that are error-disabled by default. For a detailed description of the port states (up, down, or error-disabled), refer to [“Configuration considerations when configuring PoD for Brocade ICX 6650 devices”](#) on page 96.
- 2 ports that can be converted to eight ports using a breakout cable. The ports are error-disabled by default. For a detailed description of the port states (up, down, or error-disabled), refer to [“Configuration considerations when configuring PoD for Brocade ICX 6650 devices”](#) on page 96.

The ports on the rear panel are categorized into groups. Each group requires a Flexible PoD (FPoD) license to enable the ports. For more information about using the FPoD license with a group of ports, refer to [“Disabling the FPoD ports on the rear panel”](#) on page 89.

- Group 1 = Ports 1/2/1 - 1/2/2. When enabled, these ports operate at 40 GbE.
- Group 2 = Ports 1/2/3 - 1/2/4. When enabled, these ports operate at 40 GbE.
- Group 3 = Ports 1/3/1-4, 1/3/5-8. When enabled, these breakout ports operate at 10 GbE.

Refer to [Figure 8](#) for an illustration of the rear panel ports.

FIGURE 8 Brocade ICX 6650 rear panel

PoD licenses

[Table 17](#) lists the PoD license SKUs for the Brocade ICX 6650, the license names, and the function of each license.

TABLE 17 PoD licenses

License SKU	License Name	Function
ICX6650-8P10G-POD	ICX6650-10G-LIC-POD	<p>Enables ports 1/1/33- 1/1/56 in blocks of eight in sequential order. You need three ICX6650-8P10G-POD licenses to enable all front panel ports. When you purchase a license, a new transaction key is generated as you upgrade to a higher port capacity. Purchase the following:</p> <ul style="list-style-type: none"> 8 port capacity = 1 ICX6650-8P10G-POD license. Enables ports 1/1/33 - 1/1/40. 16 port capacity = 2 ICX6650-8P10G-POD licenses. Enables ports 1/1/33 - /1/1/48. 24 port capacity = 3 ICX6650-8P10G-POD licenses. Enables ports 1/1/33- 1/1/56.
ICX6650-2P40G-POD	ICX6650-40G-LIC-POD	<p>Enables the rear panel ports by port groups. You need three ICX6650-2P40G-POD licenses to enable all rear panel ports. Purchase the following:</p> <ul style="list-style-type: none"> 2 port capacity = 1 ICX6650-2P40G-POD license. Enables one group out of the 3 groups (group 1, group 2, or group 3). 4 port capacity = 2 ICX6650-2P40G-POD licenses. Enables two groups out of the three groups. 6 port capacity = 3 ICX6650-2P40G-POD licenses. Enables all three groups.

NOTE

Trial licenses are not available for PoD licensing.

Enabling ports on the front panel

By default, ports 1/1/33 to 1/1/56 are in an error-disabled state. Use the ICX6650-10G-LIC-POD license to enable these ports. Once enabled, the ports are up at 10 GbE port speed.

One ICX6650-10G-LIC-POD license enables eight ports at a time in sequential order. Refer to [Table 17](#) for a list PoD licenses.

1. Download the ICX6650-10G-LIC-POD license from the Brocade software portal onto the Brocade device.
2. Place the license file on a TFTP or SCP server to which the Brocade device has access to.
3. Use TFTP or SCP to copy the file to the license database of the Brocade device.

To use TFTP to copy the file to the license database of the Brocade device, enter the following command.

```
Brocade# copy tftp license 10.120.54.185 lic.xml unit 1
Brocade#Flash Memory Write (8192 bytes per dot)
Copy Software License from TFTP to Flash Done.
```

Syntax: `copy tftp license [IP_address| ipv6_address] license_filename_on_host unit unit_id`

The `IP_address` variable is the address of the IPv4 TFTP server.

The `ipv6_address` variable is the address of the IPv6 TFTP server.

The `license_filename_on_host` variable is the file name of the license file.

The `unit unit_id` variable specifies a unit for which you want to add a software license file. The `unit_id` variable is 1.

If you attempt to download the same license twice on the device, the following error message is displayed on the console.

```
Can't add the license string - 93 (DUPLICATE_LICENSE)
```

NOTE

SSH and Secure Copy (SCP) must be enabled on the Brocade device before the procedures in this section can be performed. For details, refer to the *Brocade ICX 6650 Switch Security Configuration Guide*.

To copy the file from an SCP-enabled client to the license database of a specific unit, enter the following command.

```
scp license.xml terry@10.20.91.39:license:1
```

In the example, the license is copied to unit 1.

Syntax: `scp license_file_on_host user@IP_address:license:unit id`

The `unit_id` variable specifies a unit for which you want to add a software license file. The `unit_id` variable is 1.

4. Insert an SFP+ optical transceiver to enable ports to 10 GbE speed.
5. Insert an SFP+ or SFP optical transceiver to enable the ports to 1 GbE speed.
6. Repeat step 1 through step 3 above to enable ports 1/1/33 to 1/1/48.
7. Repeat step 1 through step 3 above to enable ports 1/1/33 to 1/1/56.

By default, once the license is installed, the ports are up in 10 GbE port speed. You do not need to use the **speed-duplex** command, or reload the system to enable the ports to 10 GbE port speed. As you upgrade from a lower port to a higher port capacity license, the new license replaces the previous license.

Deleting a ICX6650-10G-LIC-POD license

When downgrading to a lower port capacity license using the ICX6650-10G-LIC-POD license, you must first delete the higher port capacity license and then re-install the lower port capacity license in your system. A reload is required for the license to take effect.

1. Delete the 16-port ICX6650-10G-LIC-POD license file from the device.

```
Brocade#license delete unit 1 index 1
```

2. Use TFTP or SCP to copy the 8-port ICX6650-10G-LIC-POD license file to the license database of the device.

To use TFTP to copy the file to the license database of the Brocade device, enter the following command.

```
Brocade# copy tftp license 10.120.54.185 lic.xml unit 1
Brocade#Flash Memory Write (8192 bytes per dot)
Copy Software License from TFTP to Flash Done.
```

Syntax: `copy tftp license [IP_address| ipv6_address] license_filename_on_host unit unit_id`

The `IP_address` variable is the address of the IPv4 TFTP server.

The `ipv6_address` variable is the address of the IPv6 TFTP server.

The `license_filename_on_host` variable is the filename of the license file.

The `unit unit_id` variable specifies a unit for which you want to add a software license file. The `unit_id` variable is 1.

If you attempt to download the same license twice on the device, the following error message is displayed on the console.

```
Can't add the license string - 93 (DUPLICATE_LICENSE)
```

NOTE

SSH and Secure Copy (SCP) must be enabled on the Brocade device before the procedures in this section can be performed. For details, refer to the *Brocade ICX 6650 Switch Security Configuration Guide*.

To copy the file from an SCP-enabled client to the license database of a specific unit, enter the following command.

```
scp license.xml terry@10.20.91.39:license:1
```

In the example above, the license is copied to unit 1.

Syntax: `scp license_file_on_host user@IP_address:license:unit id`

The `unit_id` variable specifies a unit for which you want to add a software license file. The `unit_id` variable is 1.

3. Reload the device for the 8-port ICX6650-10G-LIC-POD license file to take effect.

```
Brocade#reload
```

4. Use the **show pod** command to display configuration information for the 8-port ICX6650-10G-LIC-POD license.


```

Brocade#show pod
Unit-Id: 1
PoD 10G license capacity: 8
PoD 10G license capacity used: 8
PoD 40G license capacity: 6
PoD 40G license capacity used: 6

PoD-ports      Lic-Available Lic-Used
1/1/33         Yes         Yes
1/1/34         Yes         Yes
1/1/35         Yes         Yes
1/1/36         Yes         Yes
1/1/37         Yes         Yes
1/1/38         Yes         Yes
1/1/39         Yes         Yes
1/1/40         Yes         Yes
1/1/41         No          No
1/1/42         No          No
1/1/43         No          No
1/1/44         No          No
1/1/45         No          No
1/1/46         No          No
1/1/47         No          No
1/1/48         No          No
1/1/49         No          No
1/1/50         No          No
1/1/51         No          No
1/1/52         No          No
1/1/53         No          No
1/1/54         No          No
1/1/55         No          No
1/1/56         No          No

```

Syntax: show pod

For more information about the **license delete** command, refer to [“Deleting a 10 GbE or 40 GbE license”](#) on page 90.

Enabling ports on the rear panel

By default, ports on the rear panel are in an error-disabled state. Use the ICX6650-40G-LIC-POD license to enable these ports. Once enabled, ports 1/2/1 through 1/2/4 are at 40 GbE port speed, and ports 1/3/1 through 1/3/8 are at 10 GbE port speed.

1. Download the ICX6650-40G-LIC-POD license from the Brocade software portal.
2. Place the license file on a TFTP or SCP server to which the Brocade device has access.
3. Use TFTP or SCP to copy the file to the license database of the Brocade device.

To use TFTP to copy the file to the license database of the Brocade device, enter the following command.

```
Brocade# copy tftp license 10.120.54.185 lic.xml unit 1
```

Syntax: `copy tftp license [IP_address | ipv6_address] license_filename_on_host unit unit_id`

The `IP_address` variable is the address of the IPv4 TFTP server.

The `ipv6_address` variable is the address of the IPv6 TFTP server.

The `license_filename_on_host` variable is the file name of the license file.

The `unit unit_id` variable specifies a unit for which you want to add a software license file. The `unit_id` variable is 1.

If you attempt to download the same license twice on the device, the following error message is displayed on the console.

```
Can't add the license string - 93 (DUPLICATE_LICENSE)
```

NOTE

SSH and Secure Copy (SCP) must be enabled on the Brocade device before the procedures in this section can be performed. For details, refer to the *Brocade ICX 6650 Switch Security Configuration Guide*.

To copy the file from an SCP-enabled client to the license database of a specific unit, enter the following command.

```
scp license.xml terry@10.20.91.39:license:1
```

In the example, the license is copied to unit 1.

Syntax: `scp license_file_on_host user@IP_address:license:unit id`

The `unit_id` variable specifies a unit for which you want to add a software license file. The `unit_id` variable is 1.

4. Insert the 40 GbE QSFP optical transceiver for ports 1/2/1 through 1/2/4.
5. Insert the QSFP+ to 4 SFP+ copper breakout cable or the breakout capable QSFP+ optical transceiver for ports 1/3/1 through 1/3/8.
6. Enter the following command.

```
Brocade(config)# fpod-40g-enable group 1
Brocade(config)# fpod-40g-enable group 2
```

Syntax: `[no] fpod-40g-enable group groupID`

Enter one of the following values for `groupID`:

1 = Ports 1/2/1 - 1/2/2

2 = Ports 1/2/3 - 1/2/4

3 = Ports 1/3/1 - 1/3/8

The ports in the group are enabled without a system reload. The port status is up in 30 seconds.

You can use the `no fpod-40g-enable group groupID` command to disable the port speed for the groups specified. The ports become non-operational and revert back to the default state, error-disabled. A system reload is not required. For more information about disabling the port speed for groups using the `no fpod-40g-enable group groupID` command, refer to [“Disabling the FPoD ports on the rear panel”](#) on page 89.

7. Use the `show pod` and `show license` commands to display information on port licensing. Refer to [“Displaying general license information for PoD ports”](#) on page 92, and [“Displaying the license configuration for PoD ports for the Brocade ICX 6650”](#) on page 94.

Disabling the FPoD ports on the rear panel

Enter the following command to disable the ports in group 1.

```
Brocade(config)# no fpod-40g-enable group 1
```

Ports 1/2/1 and 1/2/2 in group 1 are disabled. With a 2-port capacity license, you can choose to enable any one group out of the three groups (group 1, group 2, or group 3). For example, if you want to disable the ports in group 1 and enable the ports in group 2, perform the following steps.

1. Disable ports for group 1.

```
Brocade(config)# no fpod-40g-enable group 1
```

2. Enable ports for group 2.

```
Brocade(config)# fpod-40g-enable group 2
```

Ports 1/2/3 and 1/2/4 are enabled. A system reload is not required.

With a 4-port capacity license, you can choose to enable any two groups out of the three groups. For example, if you want to enable the ports in group 3, but you have already enabled the ports in group 1 and group 2, you must first disable the ports in group 1 or group 2. If you do not disable the ports in group 1 or group 2, the following error message displays on the CLI.

```
Brocade(config)#fpod-40g-enable group 3
Error: 40G PoD license capacity has been exceeded
```

The error message implies that you have exceeded the license capacity for this unit. To enable ports in group 3, perform the following steps.

1. Disable ports in group 1 or 2.

```
Brocade(config)# no fpod-40g-enable group 2
```

2. Enable ports in group 3.

```
Brocade(config)# fpod-40g-enable group 3
```

3. Use the **show pod** command to display configuration information for the groups enabled as shown in the example output below.

4 Ports on Demand Licensing

```
Brocade(config)#show pod
Unit-Id: 1
PoD 10G license capacity: 24
PoD 10G license capacity used: 24
PoD 40G license capacity: 4
PoD 40G license capacity used: 4
```

PoD-ports	Lic-Available	Lic-Used
1/1/33	Yes	Yes
1/1/34	Yes	Yes
1/1/35	Yes	Yes
1/1/36	Yes	Yes
1/1/37	Yes	Yes
1/1/38	Yes	Yes
1/1/39	Yes	Yes
1/1/40	Yes	Yes
1/1/41	Yes	Yes
1/1/42	Yes	Yes
1/1/43	Yes	Yes
1/1/44	Yes	Yes
1/1/45	Yes	Yes
1/1/46	Yes	Yes
1/1/47	Yes	Yes
1/1/48	Yes	Yes
1/1/49	Yes	Yes
1/1/50	Yes	Yes
1/1/51	Yes	Yes
1/1/52	Yes	Yes
1/1/53	Yes	Yes
1/1/54	Yes	Yes
1/1/55	Yes	Yes
1/1/56	Yes	Yes
1/2/1	Yes	Yes
1/2/2	Yes	Yes
1/2/3	No	No
1/2/4	No	No
1/3/1	Yes	Yes
1/3/2	Yes	Yes
1/3/3	Yes	Yes
1/3/4	Yes	Yes
1/3/5	Yes	Yes
1/3/6	Yes	Yes
1/3/7	Yes	Yes
1/3/8	Yes	Yes

Syntax: show pod

Deleting a 10 GbE or 40 GbE license

A PoD license remains in the license database until it is deleted.

To delete all PoD (10 GbE or 40 GbE) license files from a unit, enter the following command at the privileged EXEC level of the CLI.

```
Brocade# license delete unit 1 all
```

To delete a specific license file from a unit, enter the following command at the privileged EXEC level of the CLI.

```
Brocade# license delete unit 1 index 1
```

Syntax: `license delete unit unit_id [all | index license_index]`

The *unit_id* variable specifies the unit ID number. The unit ID number is 1.

The **all** option allows you to delete all license files for a specific unit.

The **index *license_index*** option specifies the software license file, and is generated by the member unit. The license index number is the license file you want to delete from a unit.

Deleting a 10 GbE or 40 GbE license requires a system reload for the command to take effect.

Viewing information about PoD licenses

This section describes the **show** commands associated with PoD licensing. These commands are issued on the Brocade device, at any level of the CLI.

NOTE

You can also view information about PoD licenses from the Brocade software portal. Refer to [“Viewing PoD licensing information from the Brocade software portal”](#) on page 80.

Viewing the LID and the software packages installed in the device

Brocade devices that ship during and after the release of PoD licensing have the License ID (LID) imprinted on the label affixed to the device. You also can use the **show version** CLI command to view the LID on these devices, and on devices that shipped before the release of PoD licensing.

Use the **show version** command to display the serial number, software and hardware license package name, and LID of all units in the device. The following example is sample output from a Brocade ICX 6650 device with the package, ICX6650_L3_SOFT_PACKAGE, installed on unit 1.

NOTE

The software package name is not the same as the license name.

4 Viewing information about PoD licenses

```
Brocade#show version
Copyright (c) 1996-2012 Brocade Communications Systems, Inc. All rights
reserved.
  UNIT 1: compiled on Jul 16 2012 at 20:00:20 labeled as ICXLR07500B1
          (12849087 bytes) from Primary ICXLR07500B1.bin
          SW: Version 07.5.00B1T323
          Boot-Monitor Image size = 524288, Version:07.5.00T320 (fxz07500b006)
          HW: Stackable ICX6650-64
=====
UNIT 1: SL 1: ICX6650-64 56-port Management Module
      Serial #: CEN0316H00W
      License: ICX6650_L3_SOFT_PACKAGE (LID: egpFIGLjFFy)
      P-ENGINE 0: type EC02, rev 01
=====
UNIT 1: SL 2: ICX6650-64 4-port 160G Module
=====
UNIT 1: SL 3: ICX6650-64 8-port 80G Module
=====
      800 MHz Power PC processor 8544E (version 0021/0022) 400 MHz bus
      65536 KB flash memory
      1024 MB DRAM
      STACKID 1 system uptime is 4 days 20 hours 39 minutes 48 seconds
=====
                          HARDWARE INFORMATION
UNIT NAME      : ICX6650-64
HW REVISION    : 1 (ALPHA)
Board ID      : 4(ICX6650)
                          CPLD INFORMATION
CPLD code is RD revision
CPLD CODE REVISION = 5
=====
The system : started=warm start  reloaded=by "reload"
*** NOT FOR PRODUCTION ***
```

Displaying general license information for PoD ports

To display general license information about the PoD license in the device, use the **show license** command. The **show license** command only displays software license information for a unit, not hardware license information, as shown in the following example.

```
Brocade#show license
Index      License Name      Lid      License Type  Status  License Period  License Capacity
Stack unit 1:
1          ICX6650-10G-LIC-POD  egpHKHKjFFL  Normal      Active  Unlimited      24
2          ICX6650-40G-LIC-POD  egpHKHKjFFL  Normal      Active  Unlimited      6
```

Syntax: show license

To display PoD license information for unit 1 on a Brocade ICX 6650 device, enter the **show license unit unit_id** command. In the following example, the 10 GbE and 40 GbE Brocade ICX 6650 PoD licenses are installed on unit 1.

```
Brocade#show license unit 1
Index      License Name      Lid      License Type  Status  License Period  License Capacity
Stack unit 1:
1          ICX6650-10G-LIC-POD  egpHKHKjFFL  Normal      Active  Unlimited      24
2          ICX6650-40G-LIC-POD  egpHKHKjFFL  Normal      Active  Unlimited      6
```

Syntax: **show license** [unit unit_id]

The **unit unit_id** parameter specifies the unit ID number.

[Table 18](#) describes the information displayed by the **show license unit unit_id** command

TABLE 18 Output from the show license unit command

Field	Description
Index	The index number specifies the PoD license file for a specific unit. The index number is generated by the member unit.
License Name	The name of license installed for the license index number on the unit.
Lid	The license ID. This number is embedded in the Brocade device.
License Type	Indicates the license is normal (permanent).
Status	Indicates the status of the license: <ul style="list-style-type: none"> • Valid – A license is valid if the LID matches the serial number of the device for which the license was purchased, and the package name is recognized by the system. • Invalid – The LID does not match the serial number of the device for which the license was purchased. • Active – The license is valid and in effect on the device. • Not used – The license is not in effect on the device.
License Period	The license type is normal (permanent). The field displays Unlimited.
License Capacity	The port capacity of the PoD license. The 10 GbE PoD license consists of an 8-, 16-, or 24-port capacity license. The 40 GbE PoD license consists of 2-, 4-, or 6-port capacity license.

To display detailed information about a specific license on unit 1, use the **show license unit unit_id [index index_number]** command. The following example shows sample output.

```
Brocade#show license unit 1 index 1
License information for unit 1 license <1>:
+license name:      ICX6650-10G-LIC-POD
+lid:               egpHKHKjFFL
+license type:      normal
+status:            active
+license period:    unlimited
```

Syntax: **show license unit unit_id** [index index_number]

The **unit unit_id** variable specifies the unit ID number. The unit ID number is 1.

The **index license_index** option specifies the software license file, and is generated by the member unit.

Table 19 describes the information displayed by the **show license unit *unit_id* [*index index_number*]** command.

TABLE 19 Output from the **show license *unit_id* [*index index_number*]** command

Field	Description
+license name	The name of the license installed on the unit.
+lid	The license ID. This number is embedded in the Brocade device.
+license type	Indicates the license is normal (permanent).
+status	Indicates the status of the license: <ul style="list-style-type: none"> • Valid – A license is valid if the LID matches the serial number of the device for which the license was purchased, and the package name is recognized by the system. • Invalid – The LID does not match the serial number of the device for which the license was purchased. • Active – The license is valid and in effect on the device. • Not used – The license is not in effect on the device.
+license period	The license type is normal (permanent), This field displays Unlimited.

Displaying the license configuration for PoD ports for the Brocade ICX 6650

To display the license configuration for PoD ports in the system, enter the **show pod** command at the CLI level. In the following output, the 16-port capacity license is used for the 10 GbE PoD license, and the 6-port capacity license is used for the 40 GbE PoD license.


```

Brocade(config)#show pod
Unit-Id: 1
PoD 10G license capacity: 16
PoD 10G license capacity used: 16
PoD 40G license capacity: 6
PoD 40G license capacity used: 6

```

PoD-ports	Lic-Available	Lic-Used
1/1/33	Yes	Yes
1/1/34	Yes	Yes
1/1/35	Yes	Yes
1/1/36	Yes	Yes
1/1/37	Yes	Yes
1/1/38	Yes	Yes
1/1/39	Yes	Yes
1/1/40	Yes	Yes
1/1/41	Yes	Yes
1/1/42	Yes	Yes
1/1/43	Yes	Yes
1/1/44	Yes	Yes
1/1/45	Yes	Yes
1/1/46	Yes	Yes
1/1/47	Yes	Yes
1/1/48	Yes	Yes
1/1/49	No	No
1/1/50	No	No
1/1/51	No	No
1/1/52	No	No
1/1/53	No	No
1/1/54	No	No
1/1/55	No	No
1/1/56	No	No
1/2/1	Yes	Yes
1/2/2	Yes	Yes
1/2/3	Yes	Yes
1/2/4	Yes	Yes
1/3/1	Yes	Yes
1/3/2	Yes	Yes
1/3/3	Yes	Yes
1/3/4	Yes	Yes
1/3/5	Yes	Yes
1/3/6	Yes	Yes
1/3/7	Yes	Yes
1/3/8	Yes	Yes

Syntax: show pod

[Table 20](#) describes the information displayed in the output of the **show pod** command.

TABLE 20 Output from the show pod command

Field	Description
Unit-Id	The unit ID number of the PoD.
PoD license capacity	The port capacity of the PoD license (10 GbE or 40 GbE license) that is purchased. The PoD 10 GbE license consists of an 8-, 16-, or 24-port capacity license. The PoD 40 GbE license consists of a 2-, 4-, or 6-port capacity license.
PoD license capacity used	The port capacity of the PoD license (10 GbE or 40 GbE license) that is in use by the port. The PoD 10 GbE license consists of an 8-, 16-, or 24-port capacity license. The PoD 40 GbE license consists of a 2-, 4-, or 6-port capacity license.
PoD-ports	The list of PoD ports in the PoD unit.
Lic-Available	Whether the license is available for the port.
Lic-Used	Whether the license is used by the port.

Configuration considerations when configuring PoD for Brocade ICX 6650 devices

Consider the following when configuring PoD for Brocade ICX 6650 devices:

- You can add a ICX6650-2P40G-POD license to any configuration. For example, you can add a ICX6650-2P40G-POD license to a base 32-port configuration.
- In a trunk formation, if there is no license upon bootup or hot swap of a unit, a port is disabled. This does not affect the trunk formation.
- A 10 GbE or 40 GbE port can be in one of the following port states:
 - Error-disabled (invalid license)
 - Down
 - Up

A port is in an error-disabled (invalid license) state when there is no license installed in the device. An invalid license implies that you have incorrectly installed a license that is not tied to the device. When a physical link is established between two devices, but a license is not installed in the device, the port remains in an error-disabled state. A port is operational only when you install the correct license in the device. The **show interface ethernet** command displays the port in the ERROR_DISABLED state because there is no license installed, and there is no physical link between two devices. The following example output is from a Brocade ICX 6650 device.

```

Brocade# show interface ethernet 1/1/33
10GigabitEthernet1/1/33 is ERR-DISABLED (invalid license), line protocol is
down
  Hardware is 10GigabitEthernet, address is 748e.f80c.5f40(bia 748e.f80c.5f40)
  Interface type is unknown
  Configured speed 10Gbit, actual unknown, configured duplex fdx, actual
unknown
  Member of L2 VLAN ID 1, port is untagged, port state is DISABLED
  BPDU guard is Disabled, ROOT protect is Disabled
  Link Error Dampening is Disabled
  STP configured to ON, priority is level0, mac-learning is enabled
  Flow Control is enabled
  Mirror disabled, Monitor disabled
  Not member of any active trunks
  Not member of any configured trunks
  No port name

```

A port is in a down state when there is no physical link between two devices, and a license is installed in the device. The **show interface ethernet** command displays the port in the down state. The following example output is from a Brocade ICX 6650 device.

```

Brocade# show interface ethernet 1/1/33
10GigabitEthernet1/1/33 is down, line protocol is down
  Hardware is 10GigabitEthernet, address is 748e.f80c.5f40(bia 748e.f80c.5f40)
  Interface type is unknown
  Configured speed 10Gbit, actual unknown, configured duplex fdx, actual
unknown
  Member of L2 VLAN ID 1, port is untagged, port state is BLOCKING
  BPDU guard is Disabled, ROOT protect is Disabled
  Link Error Dampening is Disabled
  STP configured to ON, priority is level0, mac-learning is enabled
  Flow Control is enabled
  Mirror disabled, Monitor disabled
  Not member of any active trunks
  Not member of any configured trunks
  No port name

```

A port is in an up state when a physical link is established between two devices, and a license is installed in the device. The **show interface ethernet** command displays the port in the up state. The following example output is from a Brocade ICX 6650 device.

```

Brocade# show interface ethernet 1/2/1
40GigabitEthernet1/2/1 is up, line protocol is up
  Hardware is 40GigabitEthernet, address is 748e.f80c.5f40(bia 748e.f80c.5f40)
  Interface type is 40Gig Copper
  Configured speed 40Gbit, actual 40Gbit, configured duplex fdx, actual fdx
  Configured mdi mode AUTO, actual none
  Member of 1 L2 VLANs, port is tagged, port state is FORWARDING
  BPDU guard is Disabled, ROOT protect is Disabled
  Link Error Dampening is Disabled
  STP configured to ON, priority is level0, mac-learning is enabled
  Flow Control is enabled
  Mirror disabled, Monitor disabled
  Member of active trunk ports 1/2/1,1/2/2,1/2/3,1/2/4, primary port
  Member of configured trunk ports 1/2/1,1/2/2,1/2/3,1/2/4, primary port
  No port name

```

4 Viewing information about PoD licenses

IPv6 Configuration on Brocade ICX 6650 Switch

In this chapter

- Full Layer 3 IPv6 feature support 101
- IPv6 addressing overview 101
- IPv6 CLI command support 104
- IPv6 host address on a Layer 2 switch 106
- Configuring basic IPv6 connectivity on a Layer 3 switch 108
- IPv6 management on Brocade ICX 6650 devices (IPv6 host support) . . . 112
- Static IPv6 route configuration 118
- IPv6 over IPv4 tunnels. 121
- ECMP load sharing for IPv6 126
- IPv6 ICMP feature configuration. 128
- IPv6 neighbor discovery configuration. 129
- IPv6 MTU 136
- Static neighbor entries configuration. 137
- Limiting the number of hops an IPv6 packet can traverse. 138
- IPv6 source routing security enhancements 138
- Clearing global IPv6 information 138
- Displaying global IPv6 information 140

Table 21 lists the Brocade ICX 6650 switch and the IPv6 features the switch supports. These features are supported full Layer 3 software images, except where explicitly noted.

TABLE 21 Supported IPv6 features on Brocade ICX 6650 devices

Feature	Brocade ICX 6650
Global IPv6 address	Yes
IPv6 access list ¹	Yes
IPv6 access-list (management ACLs)	Yes
Site-local IPv6 address	Yes
Link-local IPv6 address	Yes
IPv4 and IPv6 host stacks	Yes
IPv6 copy ¹	Yes
IPv6 ncopy ¹	Yes
IPv6 debug	Yes

TABLE 21 Supported IPv6 features on Brocade ICX 6650 devices

Feature	Brocade ICX 6650
IPv6 ping	Yes
IPv6 traceroute	Yes
DNS server name resolution	Yes
Logging (Syslog)	Yes
RADIUS ¹	Yes
SCP	Yes
SSH	Yes
SNMP	Yes
SNMP traps	Yes
SNTP	Yes
Telnet	Yes
TFTP ¹	Yes
Router advertisement and solicitation	Yes
IPv6 static routes	Yes
IPv6 over IPv4 tunnels	Yes
ECMP load sharing	Yes
IPv6 ICMP	Yes
IPv6 routing protocols ¹	Yes
ICMP redirect messages	Yes
IPv6 neighbor discovery	Yes
IPv6 Layer 3 forwarding	Yes
IPv6 redistribution	Yes
IPv6 MTU	Yes
Static neighbor entries	Yes
Hop limit for IPv6 packets	Yes
Clear IPv6 global information	Yes
IPv6 source routing security enhancements	Yes

¹The following IPv6 features, listed in Table 21, are documented in other chapters or sections of this guide:

- IPv6 access list – Brocade ICX 6650 Switch Security Configuration Guide
- IPv6 copy – [“Using the IPv6 copy command”](#) on page 62
- IPv6 ncopy – [“IPv6 ncopy command”](#) on page 64
- RADIUS – Brocade ICX 6650 Switch Security Configuration Guide
- TFTP – [“Loading and saving configuration files with IPv6”](#) on page 62

- IPv6 routing protocols – Various chapters

Full Layer 3 IPv6 feature support

The following IPv6 Layer 3 features are supported:


- IPv6 unicast routing (multicast routing is not supported)
- OSPF V3
- RIPng
- IPv6 ICMP redirect messages
- IPv6 route redistribution
- IPv6 static routes
- IPv6 over IPv4 tunnels in hardware
- IPv6 Layer 3 forwarding

IPv6 addressing overview

IPv6 was designed to replace IPv4, the Internet protocol that is most commonly used currently throughout the world. IPv6 increases the number of network address bits from 32 (IPv4) to 128 bits, which provides more than enough unique IP addresses to support all of the network devices on the planet into the future. IPv6 is expected to quickly become the network standard.

An IPv6 address is composed of 8 fields of 16-bit hexadecimal values separated by colons (:). [Figure 9](#) shows the IPv6 address format.

FIGURE 9 IPv6 address format



As shown in [Figure 9](#), HHHH is a 16-bit hexadecimal value, while H is a 4-bit hexadecimal value. The following is an example of an IPv6 address.

2001:DB8:0000:0200:002D:D0FF:FE48:4672

Note that this IPv6 address includes hexadecimal fields of zeros. To make the address less cumbersome, you can do the following:

- Omit the leading zeros; for example, 2001:0:0:200:2D:D0FF:FE48:4672.
- Compress the successive groups of zeros at the beginning, middle, or end of an IPv6 address to two colons (::) once per address; for example, 2001:DB8::200:2D:D0FF:FE48:4672.

When specifying an IPv6 address in a command syntax, keep the following in mind:

- You can use the two colons (::) only once in the address to represent the longest successive hexadecimal fields of zeros

- The hexadecimal letters in IPv6 addresses are not case-sensitive

As shown in [Figure 9](#), the IPv6 network prefix is composed of the left-most bits of the address. As with an IPv4 address, you can specify the IPv6 prefix using the `<prefix>/<prefix-length>` format, where the following applies.

The `<prefix>` parameter is specified as 16-bit hexadecimal values separated by a colon.

The `<prefix-length>` parameter is specified as a decimal value that indicates the left-most bits of the IPv6 address.

The following is an example of an IPv6 prefix.

2001:DB8:49EA:D088::/64

IPv6 address types

As with IPv4 addresses, you can assign multiple IPv6 addresses to a switch interface. [Table 22](#) presents the three major types of IPv6 addresses that you can assign to a switch interface.

A major difference between IPv4 and IPv6 addresses is that IPv6 addresses support **scope**, which describes the topology in which the address may be used as a unique identifier for an interface or set of interfaces.

Unicast and multicast addresses support scoping as follows:

- Unicast addresses support two types of scope: global scope and local scope. In turn, local scope supports site-local addresses and link-local addresses. [Table 22](#) describes global, site-local, and link-local addresses and the topologies in which they are used.
- Multicast addresses support a scope field, which [Table 22](#) describes.

TABLE 22 IPv6 address types

Address type	Description	Address structure
Unicast	An address for a single interface. A packet sent to a unicast address is delivered to the interface identified by the address.	<p>Depends on the type of the unicast address:</p> <ul style="list-style-type: none"> • Aggregatable global address—An address equivalent to a global or public IPv4 address. The address structure is as follows: a fixed prefix of 2000::/3 (001), a 45-bit global routing prefix, a 16-bit subnet ID, and a 64-bit interface ID. • Site-local address—An address used within a site or intranet. (This address is similar to a private IPv4 address.) A site consists of multiple network links. The address structure is as follows: a fixed prefix of FEC0::/10 (1111 1110 11), a 16-bit subnet ID, and a 64-bit interface ID. • Link-local address—An address used between directly connected nodes on a single network link. The address structure is as follows: a fixed prefix of FE80::/10 (1111 1110 10) and a 64-bit interface ID. • IPv4-compatible address—An address used in IPv6 transition mechanisms that tunnel IPv6 packets dynamically over IPv4 infrastructures. The address embeds an IPv4 address in the low-order 32 bits and the high-order 96 bits are zeros. The address structure is as follows: 0:0:0:0:0:0:A.B.C.D. • Loopback address—An address (0:0:0:0:0:0:1 or ::1) that a switch can use to send an IPv6 packet to itself. You cannot assign a loopback address to a physical interface. • Unspecified address—An address (0:0:0:0:0:0:0 or ::) that a node can use until you configure an IPv6 address for it.
Multicast	An address for a set of interfaces belonging to different nodes. Sending a packet to a multicast address results in the delivery of the packet to all interfaces in the set.	A multicast address has a fixed prefix of FF00::/8 (1111 1111). The next 4 bits define the address as a permanent or temporary address. The next 4 bits define the scope of the address (node, link, site, organization, global).
Anycast	An address for a set of interfaces belonging to different nodes. Sending a packet to an anycast address results in the delivery of the packet to the closest interface identified by the address.	<p>An anycast address looks similar to a unicast address, because it is allocated from the unicast address space. If you assign a unicast address to multiple interfaces, it is an anycast address. An interface assigned an anycast address must be configured to recognize the address as an anycast address.</p> <p>An anycast address can be assigned to a switch only.</p> <p>An anycast address must not be used as the source address of an IPv6 packet.</p>

A switch automatically configures a link-local unicast address for an interface by using the prefix of FE80::/10 (1111 1110 10) and a 64-bit interface ID. The 128-bit IPv6 address is then subjected to duplicate address detection to ensure that the address is unique on the link. If desired, you can override this automatically configured address by explicitly configuring an address.

NOTE

Brocade ICX 6650 devices support RFC 2526, which requires that within each subnet, the highest 128 interface identifier values reserved for assignment as subnet anycast addresses. Thus, if you assign individual IPv6 addresses within a subnet, the second highest IPv6 address in the subnet does not work.

IPv6 stateless auto-configuration

Brocade routers use the IPv6 stateless autoconfiguration feature to enable a host on a local link to automatically configure its interfaces with new and globally unique IPv6 addresses associated with its location. The automatic configuration of a host interface is performed without the use of a server, such as a Dynamic Host Configuration Protocol (DHCP) server, or manual configuration.

The automatic configuration of a host interface works in the following way: a switch on a local link periodically sends switch advertisement messages containing network-type information, such as the 64-bit prefix of the local link and the default route, to all nodes on the link. When a host on the link receives the message, it takes the local link prefix from the message and appends a 64-bit interface ID, thereby automatically configuring its interface. (The 64-bit interface ID is derived from the MAC address of the host's NIC.) The 128-bit IPv6 address is then subjected to duplicate address detection to ensure that the address is unique on the link.

The duplicate address detection feature verifies that a unicast IPv6 address is unique before it is assigned to a host interface by the stateless auto configuration feature. Duplicate address detection uses neighbor solicitation messages to verify that a unicast IPv6 address is unique.

NOTE

For the stateless auto configuration feature to work properly, the advertised prefix length in switch advertisement messages must always be 64 bits.

The IPv6 stateless autoconfiguration feature can also automatically reconfigure a host's interfaces if you change the ISP for the host's network. (The host's interfaces must be renumbered with the IPv6 prefix of the new ISP.)

The renumbering occurs in the following way: a switch on a local link periodically sends advertisements updated with the prefix of the new ISP to all nodes on the link. (The advertisements still contain the prefix of the old ISP.) A host can use the addresses created from the new prefix and the existing addresses created from the old prefix on the link. When you are ready for the host to use the new addresses only, you can configure the lifetime parameters appropriately using the **ipv6 nd prefix-advertisement** command. During this transition, the old prefix is removed from the switch advertisements. At this point, only addresses that contain the new prefix are used on the link.

IPv6 CLI command support

Table 23 lists the IPv6 CLI commands supported.

TABLE 23 IPv6 CLI command support

IPv6 command	Description	Switch code	Router code
clear ipv6 cache	Deletes all entries in the dynamic host cache.		X
clear ipv6 mld-snooping	Deletes MLD-snooping-related counters or cache entries.	X	X
clear ipv6 neighbor	Deletes all dynamic entries in the IPv6 neighbor table.	X	X
clear ipv6 ospf	Clears OSPF-related entries.		X
clear ipv6 rip	Clears RIP-related entries.		X
clear ipv6 route	Deletes all dynamic entries in the IPv6 route table.		X
clear ipv6 traffic	Resets all IPv6 packet counters.	X	X

TABLE 23 IPv6 CLI command support (Continued)

IPv6 command	Description	Switch code	Router code
clear ipv6 tunnel	Clears statistics for IPv6 tunnels		X
copy tftp	Downloads a copy of a Brocade software image from a TFTP server into the system flash using IPv6.	X	X
debug ipv6	Displays IPv6 debug information.	X	X
ipv6 access-class	Configures access control for IPv6 management traffic.	X	X
ipv6 access-list	Configures an IPv6 access control list for IPv6 access control.	X	X
ipv6 address	Configures an IPv6 address on an interface (router) or globally (switch)	X	X
ipv6 debug	Enables IPv6 debugging.	X	X
ipv6 dns domain-name	Configures an IPv6 domain name.	X	X
ipv6 dns server-address	Configures an IPv6 DNS server address.	X	X
ipv6 enable	Enables IPv6 on an interface.	X	X
ipv6 hop-limit	Sets the IPv6 hop limit.		X
ipv6 icmp	Configures IPv6 ICMP parameters		X
ipv6 load-sharing	Enables IPv6 load sharing		X
ipv6 mld-snooping	Configures MLD snooping	X	X
ipv6 mtu	Configures the maximum length of an IPv6 packet that can be transmitted on a particular interface.		X
ipv6 nd	Configures neighbor discovery.		X
ipv6 neighbor	Maps a static IPv6 address to a MAC address in the IPv6 neighbor table.		X
ipv6 ospf	Configures OSPF V3 parameters on an interface.		X
ipv6 prefix-list	Builds an IPv6 prefix list.		X
ipv6 redirects	Enables the sending of ICMP redirect messages on an interface.		X
ipv6 rip	Configures RIPng parameters on an interface		X
ipv6 route	Configures an IPv6 static route.		X
ipv6 router	Enables an IPv6 routing protocol.		X
ipv6 traffic-filter	Applies an IPv6 ACL to an interface.	X	X
ipv6 unicast-routing	Enables IPv6 unicast routing.		X
log host ipv6	Configures the IPv6 Syslog server.	X	X
ping ipv6	Performs an ICMP for IPv6 echo test.	X	X
show ipv6	Displays some global IPv6 parameters, such as IPv6 DNS server address.	X	X
show ipv6 access-list	Displays configured IPv6 access control lists.	X	X
show ipv6 cache	Displays the IPv6 host cache.		X

TABLE 23 IPv6 CLI command support (Continued)

IPv6 command	Description	Switch code	Router code
show ipv6 interface	Displays IPv6 information for an interface.		X
show ipv6 mld-snooping	Displays information about MLD snooping.	X	X
show ipv6 neighbor	Displays the IPv6 neighbor table.	X	X
show ipv6 ospf	Displays information about OSPF V3.		X
show ipv6 prefix-lists	Displays the configured IPv6 prefix lists.		X
show ipv6 rip	Displays information about RIPng.		X
show ipv6 route	Displays IPv6 routes.		X
show ipv6 router	Displays IPv6 local routers.		X
show ipv6 tcp	Displays information about IPv6 TCP sessions.	X	X
show ipv6 traffic	Displays IPv6 packet counters.	X	X
show ipv6 tunnel	Displays information about IPv6 tunnels.	X	X
snmp-client ipv6	Restricts SNMP access to a certain IPv6 node.	X	X
snmp-server host ipv6	Specifies the recipient of SNMP notifications.	X	X
sntp server ipv6	Enables the Brocade device to send SNTP packets over IPv6.	X	X
telnet	Enables a Telnet connection from the Brocade device to a remote IPv6 host using the console.	X	X
traceroute ipv6	Traces a path from the Brocade device to an IPv6 host.	X	X

IPv6 host address on a Layer 2 switch

In a Layer 3 (router) configuration, each port can be configured separately with an IPv6 address. This is accomplished using the interface configuration process that is described in [“IPv6 configuration on each router interface”](#) on page 108.

In a Layer 2 (switch) configuration, individual ports cannot be configured with an IP address (IPv4 or IPv6). In this situation, the switch has one IP address for the management port and one IP address for the system. This has previously been supported for IPv4 but not for IPv6.

There is support for configuring an IPv6 address on the management port as described in [“Configuring the management port for an IPv6 automatic address configuration”](#) on page 108, and for configuring a system-wide IPv6 address on a Layer 2 switch. Configuration of the system-wide IPv6 address is exactly like configuration of an IPv6 address in router mode, except that the IPv6 configuration is at the Global CONFIG level instead of at the Interface level.

The process for defining the system-wide interface for IPv6 is described in the following sections:

- [“Configuring a global or site-local IPv6 address with a manually configured interface ID”](#) on page 107
- [“Configuring a link-local IPv6 address as a system-wide address for a switch”](#) on page 107

NOTE

When configuring an IPv6 host address on a Layer 2 switch that has multiple VLANs, make sure the configuration includes a designated management VLAN that identifies the VLAN to which the global IP address belongs. Refer to the Brocade ICX 6650 Switch Security Configuration Guide.

Configuring a global or site-local IPv6 address with a manually configured interface ID

To configure a global or site-local IPv6 address with a manually-configured interface ID, such as a system-wide address for a switch, enter a command similar to the following at the Global CONFIG level.

```
Brocade(config)#ipv6 address 2001:DB8:12D:1300:240:D0FF:FE48:4000:1/64
```

Syntax: `ipv6 address <ipv6-prefix>/<prefix-length>`

You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

You must specify the `<prefix-length>` parameter in decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

Configuring a link-local IPv6 address as a system-wide address for a switch

To enable IPv6 and automatically configure a global interface enter commands such as the following.

```
Brocade(config)#ipv6 enable
```

This command enables IPv6 on the switch and specifies that the interface is assigned an automatically computed link-local address.

Syntax: `[no] ipv6 enable`

To override a link-local address that is automatically computed for the global interface with a manually configured address, enter a command such as the following.

```
Brocade(config)#ipv6 address 2001:DB8::240:D0FF:FE48:4672 link-local
```

This command explicitly configures the link-local address 2001:DB8::240:D0FF:FE48:4672 for the global interface.

Syntax: `ipv6 address <ipv6-address> link-local`

You must specify the `<ipv6-address>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The **link-local** keyword indicates that the router interface should use the manually configured link-local address instead of the automatically computed link-local address.

Configuring the management port for an IPv6 automatic address configuration

You can have the management port configured to automatically obtain an IPv6 address. This process is the same for any other port and is described in detail in the section [“Configuring a global IPv6 address with an automatically computed EUI-64 interface ID”](#) on page 110

Configuring basic IPv6 connectivity on a Layer 3 switch

To configure basic IPv6 connectivity on a Brocade Layer 3 Switch, you must do the following:

- Enable IPv6 routing globally on the switch
- Configure an IPv6 address or explicitly enable IPv6 on each router interface over which you plan to forward IPv6 traffic
- Configure IPv4 and IPv6 protocol stacks. (This step is mandatory only if you want a router interface to send and receive both IPv4 and IPv6 traffic.)

All other configuration tasks in this chapter are optional.

Enabling IPv6 routing

By default, IPv6 routing is disabled. To enable the forwarding of IPv6 traffic globally on the Layer 3 switch, enter the following command.

```
Brocade(config)#ipv6 unicast-routing
```

Syntax: [no] ipv6 unicast-routing

To disable the forwarding of IPv6 traffic globally on the Brocade device, enter the **no** form of this command.

IPv6 configuration on each router interface

To forward IPv6 traffic on a router interface, the interface must have an IPv6 address, or IPv6 must be explicitly enabled. By default, an IPv6 address is not configured on a router interface.

If you choose to configure a global or site-local IPv6 address for an interface, IPv6 is also enabled on the interface. Further, when you configure a global or site-local IPv6 address, you must decide on one of the following in the low-order 64 bits:

- A manually configured interface ID.
- An automatically computed EUI-64 interface ID.

If you prefer to assign a link-local IPv6 address to the interface, you must explicitly enable IPv6 on the interface, which causes a link-local address to be automatically computed for the interface. If preferred, you can override the automatically configured link-local address with an address that you manually configure.

This section provides the following information:

- Configuring a global or site-local address with a manually configured or automatically computed interface ID for an interface.
- Automatically or manually configuring a link-local address for an interface.
- Configuring IPv6 anycast addresses

Configuring a global or site-local IPv6 address on an interface

Configuring a global or site-local IPv6 address on an interface does the following:

- Automatically configures an interface ID (a link-local address), if specified.
- Enables IPv6 on that interface.

Additionally, the configured interface automatically joins the following required multicast groups for that link:

- Solicited-node multicast group 2001:DB8:0:0:0:1:FF00::/104 for each unicast address assigned to the interface.
- Solicited-node for subnet anycast address for each unicast assigned address
- Solicited-node for anycast address 2001:DB8:0:0:0:1:FF00::0000
- All-nodes link-local multicast group 2001:DB8::1
- All-routers link-local multicast group 2001:DB8::2

The neighbor discovery feature sends messages to these multicast groups. For more information, refer to [“IPv6 neighbor discovery configuration”](#) on page 129.

Configuring a global or site-local IPv6 address with a manually configured interface ID

To configure a global or site-local IPv6 address, including a manually configured interface ID, for an interface, enter commands such as the following.

```
Brocade(config)#interface ethernet 1/2/1
Brocade(config-if-e1000-3/1)#ipv6 address 2001:DB8:12D:1300:240:D0FF:
FE48:4672:/64
```

These commands configure the global prefix 2001:DB8:12d:1300::/64 and the interface ID ::240:D0FF:FE48:4672, and enable IPv6 on Ethernet interface 1/2/1.

Syntax: `ipv6 address <ipv6-prefix>/<prefix-length>`

You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

To configure a /122 address on a VE enter commands similar to the following.

```
Brocade(config-vlan-11)#interface vell
Brocade(config-vif-11)#ipv6 add 2001:DB8::1/122
Brocade(config-vif-11)#show ipv6 interface
Routing Protocols : R - RIP  O - OSPF
Interface      Status      Routing  Global Unicast Address
VE 11          up/up          2001:DB8:1/122
Brocade(config-vif-11)#sh ipv6 route
IPv6 Routing Table - 1 entries:
Type Codes:  C - Connected, S - Static, R - RIP, O - OSPF, B - BGP
OSPF Sub Type Codes:  O - Intra, Oi - Inter, O1 - Type1 external, O2 - Type2
external
```

5 Configuring basic IPv6 connectivity on a Layer 3 switch

Type	IPv6 Prefix	Next Hop Router	Interface	Dis/Metric
C	2001:DB8/122	::	ve 11	0/0

Configuring a global IPv6 address with an automatically computed EUI-64 interface ID

To configure a global IPv6 address with an automatically computed EUI-64 interface ID in the low-order 64-bits, enter commands such as the following.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 address 2001:DB8:12D:1300::/64 eui-64
```

These commands configure the global prefix 2001:DB8:12d:1300::/64 and an interface ID, and enable IPv6 on ethernet interface 1/1/1.

Syntax: `ipv6 address <ipv6-prefix>/<prefix-length> eui-64`

You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

The **eui-64** keyword configures the global address with an EUI-64 interface ID in the low-order 64 bits. The interface ID is automatically constructed in IEEE EUI-64 format using the interface's MAC address.

Configuring a link-local IPv6 address on an interface

To explicitly enable IPv6 on a router interface without configuring a global or site-local address for the interface, enter commands such as the following.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 enable
```

These commands enable IPv6 on Ethernet interface 1/1/1 and specify that the interface is assigned an automatically computed link-local address.

Syntax: `[no] ipv6 enable`

NOTE

When configuring VLANs that share a common tagged interface with a physical or Virtual Ethernet (VE) interface, Brocade recommends that you override the automatically computed link-local address with a manually configured unique address for the interface. If the interface uses the automatically computed address, which in the case of physical and VE interfaces is derived from a global MAC address, all physical and VE interfaces will have the same MAC address.

To override a link-local address that is automatically computed for an interface with a manually configured address, enter commands such as the following.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 address 2001:DB8::240:D0FF:FE48:4672
link-local
```

These commands explicitly configure the link-local address 2001:DB8::240:D0FF:FE48:4672 for ethernet interface 1/1/1.

Syntax: `ipv6 address <ipv6-address> link-local`

You must specify the `<ipv6-address>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The **link-local** keyword indicates that the router interface should use the manually configured link-local address instead of the automatically computed link-local address.

Configuring an IPv6 anycast address on an interface

In IPv6, an **anycast** address is an address for a set of interfaces belonging to different nodes. Sending a packet to an anycast address results in the delivery of the packet to the closest interface configured with the anycast address.

An anycast address looks similar to a unicast address, because it is allocated from the unicast address space. If you assign an IPv6 unicast address to multiple interfaces, it is an anycast address. On the Brocade device, you configure an interface assigned an anycast address to recognize the address as an anycast address.

For example, the following commands configure an anycast address on interface 1/1/1.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 address 2001:DB8::/64 anycast
```

Syntax: `ipv6 address <ipv6-prefix>/<prefix-length> [anycast]`

IPv6 anycast addresses are described in detail in RFC 1884. See RFC 2461 for a description of how the IPv6 Neighbor Discovery mechanism handles anycast addresses.

Configuring IPv4 and IPv6 protocol stacks

One situation in which you must configure a router to run both IPv4 and IPv6 protocol stacks is if it is deployed as an endpoint for an IPv6 over IPv4 tunnel.

Each router interface that will send and receive both IPv4 and IPv6 traffic must be configured with an IPv4 address and an IPv6 address. (An alternative to configuring a router interface with an IPv6 address is to explicitly enable IPv6 using the **ipv6 enable** command. For more information about using this command, refer to [“Configuring a link-local IPv6 address on an interface”](#) on page 110.)

To configure a router interface to support both the IPv4 and IPv6 protocol stacks, use commands such as the following.

```
Brocade(config)#ipv6 unicast-routing
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ip address 192.168.1.1 255.255.255.0
Brocade(config-if-e10000-1/1/1)#ipv6 address 2001:DB8:12d:1300::/64 eui-64
```

These commands globally enable IPv6 routing and configure an IPv4 address and an IPv6 address for Ethernet interface 1/1/1.

Syntax: `[no] ipv6 unicast-routing`

To disable IPv6 traffic globally on the router, enter the **no** form of this command.

Syntax: `ip address <ip-address> <sub-net-mask> [secondary]`

You must specify the `<ip-address>` parameter using 8-bit values in dotted decimal notation.

You can specify the `<sub-net-mask>` parameter in either dotted decimal notation or as a decimal value preceded by a slash mark (/).

The **secondary** keyword specifies that the configured address is a secondary IPv4 address.

To remove the IPv4 address from the interface, enter the **no** form of this command.

Syntax: `ipv6 address <ipv6-prefix>/<prefix-length> [eui-64]`

This syntax specifies a global or site-local IPv6 address. For information about configuring a link-local IPv6 address, refer to [“Configuring a link-local IPv6 address on an interface”](#) on page 110.

You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

The **eui-64** keyword configures the global address with an EUI-64 interface ID in the low-order 64 bits. The interface ID is automatically constructed in IEEE EUI-64 format using the interface’s MAC address. If you do not specify the **eui-64** keyword, you must manually configure the 64-bit interface ID as well as the 64-bit network prefix. For more information about manually configuring an interface ID, refer to [“Configuring a global or site-local IPv6 address on an interface”](#) on page 109.

IPv6 management on Brocade ICX 6650 devices (IPv6 host support)

You can configure a Brocade ICX 6650 switch to serve as an IPv6 host in an IPv6 network. An **IPv6 host** has IPv6 addresses on its interfaces, but does not have full IPv6 routing enabled on it.

This section describes the IPv6 host features supported on Brocade ICX 6650 devices.

Configuring IPv6 management ACLs

When you enter the **ipv6 access-list** command, the Brocade device enters the IPv6 Access List configuration level, where you can access several commands for configuring IPv6 ACL entries. After configuring the ACL entries, you can apply them to network management access features such as Telnet, SSH, Web, and SNMP.

NOTE

Unlike IPv4, there is no distinction between standard and extended ACLs in IPv6.

Example

```
FastIron(config)#ipv6 access-list netw
FastIron(config-ipv6-access-list-netw)#
```

Syntax: `[no] ipv6 access-list <ACL name>`

The `<ACL name>` variable specifies a name for the IPv6 ACL. An IPv6 ACL name cannot start with a numeral, for example, **1access**. Also, an IPv4 ACL and an IPv6 ACL cannot share the same name.

Restricting SNMP access to an IPv6 node

You can restrict SNMP access to the device to the IPv6 host whose IP address you specify. To do so, enter a command such as the following.

```
Brocade(config)#snmp-client ipv6 2001:DB8:89::23
```

Syntax: `snmp-client ipv6 <ipv6-address>`

The `<ipv6-address>` you specify must be in hexadecimal format using 16-bit values between colons as documented in RFC 2373.

Specifying an IPv6 SNMP trap receiver

You can specify an IPv6 host as a trap receiver to ensure that all SNMP traps sent by the device will go to the same SNMP trap receiver or set of receivers, typically one or more host devices on the network. To do so, enter a command such as the following.

```
Brocade(config)#snmp-server host ipv6 2001:DB8:89::13
```

Syntax: `snmp-server host ipv6 <ipv6-address>`

The `<ipv6-address>` you specify must be in hexadecimal format using 16-bit values between colons as documented in RFC 2373.

Configuring SNMP V3 over IPv6

Brocade ICX 6650 devices support IPv6 for SNMP version 3. For more information about how to configure SNMP, refer to [Chapter 6, “SNMP Access”](#).

Configuring Sntp over IPv6

To enable the Brocade device to send Sntp packets over IPv6, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#sntp server ipv6 2001:DB8::400
```

Syntax: `sntp server ipv6 <ipv6-address>`

The `<ipv6-address>` is the IPv6 address of the Sntp server. When you enter the IPv6 address, you do not need to specify the prefix length. A prefix length of 128 is implied.

Secure Shell, SCP, and IPv6

Secure Shell (SSH) is a mechanism that allows secure remote access to management functions on the Brocade device. SSH provides a function similar to Telnet. You can log in to and configure the Brocade device using a publicly or commercially available SSH client program, just as you can with Telnet. However, unlike Telnet, which provides no security, SSH provides a secure, encrypted connection to the Brocade device.

To open an SSH session between an IPv6 host running an SSH client program and the Brocade device, open the SSH client program and specify the IPv6 address of the device. For more information about configuring SSH on the Brocade device, refer to the Brocade ICX 6650 Switch Security Configuration Guide.

IPv6 Telnet

Telnet sessions can be established between a Brocade device to a remote IPv6 host, and from a remote IPv6 host to the Brocade device using IPv6 addresses.

The **telnet** command establishes a Telnet connection from a Brocade device to a remote IPv6 host using the console. Up to five **read-access** Telnet sessions are supported on the router at one time. **Write-access** through Telnet is limited to one session, and only one outgoing Telnet session is supported on the router at one time. To see the number of open Telnet sessions at any time, enter the **show telnet** command.

Example

To establish a Telnet connection to a remote host with the IPv6 address of 2001:DB8::1, enter the following command.

```
Brocade#telnet ipv6 2001:DB8::1
```

Syntax: **telnet** <ipv6-address> [<port-number> | **outgoing-interface ethernet** <stack-unit>/<slot>/<port> | ve <number>]

The <ipv6-address> parameter specifies the address of a remote host. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The <port-number> parameter specifies the port number on which the Brocade device establishes the Telnet connection. You can specify a value between 1 - 65535. If you do not specify a port number, the Brocade device establishes the Telnet connection on port 23.

If the IPv6 address you specify is a link-local address, you must specify the **outgoing-interface ethernet <stack-unit>/<slot>/<port> | ve <number>** parameter. This parameter identifies the interface that must be used to reach the remote host. Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1. If you specify a VE interface, also specify the VE number.

Establishing a Telnet session from an IPv6 host

To establish a Telnet session from an IPv6 host to the Brocade device, open your Telnet application and specify the IPv6 address of the Layer 3 Switch.

IPv6 traceroute

NOTE

This section describes the **IPv6 traceroute** command. For details about **IPv4 traceroute**, refer to [“Tracing an IPv4 route”](#) on page 71.

The **traceroute** command allows you to trace a path from the Brocade device to an IPv6 host.

The CLI displays trace route information for each hop as soon as the information is received. Traceroute requests display all responses to a minimum TTL of 1 second and a maximum TTL of 30 seconds. In addition, if there are multiple equal-cost routes to the destination, the Brocade device displays up to three responses.

For example, to trace the path from the Brocade device to a host with an IPv6 address of 2001:DB8:349e:a384::34, enter the following command:

```
Brocade#traceroute ipv6 2001:DB8:349e:a384::34
```

Syntax: `traceroute ipv6 <ipv6-address>`

The <ipv6-address> parameter specifies the address of a host. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.

Configuring name-to-IPv6 address resolution using IPv6 DNS resolver

The Domain Name Server (DNS) resolver feature lets you use a host name to perform Telnet and ping commands. You can also define a DNS domain on a Brocade device and thereby recognize all hosts within that domain. After you define a domain name, the Brocade device automatically appends the appropriate domain to the host and forwards it to the domain name server.

For example, if the domain “example.com” is defined on a Brocade device, and you want to initiate a ping to host “EXA01” on that domain, you need to reference only the host name in the command instead of the host name and its domain name. For example, you could enter either of the following commands to initiate the ping.

```
Brocade#ping ipv6 exa01
Brocade#ping ipv6 exa01.example.com
```

Defining an IPv6 DNS entry

IPv6 defines new DNS record types to resolve queries for domain names to IPv6 addresses, as well as IPv6 addresses to domain names. Brocade devices running IPv6 software support AAAA DNS records, which are defined in RFC 1886.

AAAA DNS records are analogous to the A DNS records used with IPv4. They store a complete IPv6 address in each record. AAAA records have a type value of 28.

To establish an IPv6 DNS entry for the device, enter the following command.

```
Brocade(config)#ipv6 dns domain-name companyA.com
```

Syntax: `[no] ipv6 dns domain-name <domain name>`

To define an IPv6 DNS server address, enter the following command.

```
Brocade(config)#ipv6 dns server-address 2001:DB8::1
```

Syntax: `[no] ipv6 dns server-address <ipv6-addr> [<ipv6-addr>] [<ipv6-addr>] [<ipv6-addr>]`

As an example, in a configuration where ftp6.companyA.com is a server with an IPv6 protocol stack, when a user pings ftp6.companyA.com, the Brocade device attempts to resolve the AAAA DNS record. In addition, if the DNS server does not have an IPv6 address, as long as it is able to resolve AAAA records, it can still respond to DNS queries.

Pinging an IPv6 address

NOTE

This section describes the *IPv6 ping* command. For details about *IPv4 ping*, refer to “[Pinging an IPv4 address](#)” on page 69.

The **ping** command allows you to verify the connectivity from a Brocade device to an IPv6 device by performing an ICMP for IPv6 echo test.

For example, to ping a device with the IPv6 address of 2001:DB8:847f:a385:34dd::45 from the Brocade device, enter the following command.

```
Brocade#ping ipv6 2001:DB8:847f:a385:34dd::45
```

Syntax: **ping ipv6** <ipv6-address> [**outgoing-interface** [<port> | **ve** <number>]] [**source** <ipv6-address>] [**count** <number>] [**timeout** <milliseconds>] [**ttl** <number>] [**size** <bytes>] [**quiet**] [**numeric**] [**no-fragment**] [**verify**] [**data** <1-to-4 byte hex>] [**brief**]

- The <ipv6-address> parameter specifies the address of the router. You must specify this address in hexadecimal using 16-bit values between colons as documented in RFC 2373.
- The **outgoing-interface** keyword specifies a physical interface over which you can verify connectivity. If you specify a physical interface, such as an Ethernet interface, you must also specify the port number of the interface. If you specify a virtual interface, such as a VE, you must specify the number associated with the VE.
- The **source** <ipv6-address> parameter specifies an IPv6 address to be used as the origin of the ping packets.
- The **count** <number> parameter specifies how many ping packets the router sends. You can specify from 1 - 4294967296. The default is 1.
- The **timeout** <milliseconds> parameter specifies how many milliseconds the router waits for a reply from the pinged device. You can specify a timeout from 1 - 4294967296 milliseconds. The default is 5000 (5 seconds).
- The **ttl** <number> parameter specifies the maximum number of hops. You can specify a TTL from 1 - 255. The default is 64.
- The **size** <bytes> parameter specifies the size of the ICMP data portion of the packet. This is the payload and does not include the header. You can specify from 0 - 4000. The default is 16.
- The **no-fragment** keyword turns on the "do not fragment" bit in the IPv6 header of the ping packet. This option is disabled by default.
- The **quiet** keyword hides informational messages such as a summary of the ping parameters sent to the device, and instead only displays messages indicating the success or failure of the ping. This option is disabled by default.
- The **verify** keyword verifies that the data in the echo packet (the reply packet) is the same as the data in the echo request (the ping). By default the device does not verify the data.

- The **data** *<1 - 4 byte hex>* parameter lets you specify a specific data pattern for the payload instead of the default data pattern, "abcd", in the packet's data payload. The pattern repeats itself throughout the ICMP message (payload) portion of the packet.

NOTE

For parameters that require a numeric value, the CLI does not check that the value you enter is within the allowed range. Instead, if you do exceed the range for a numeric value, the software rounds the value to the nearest valid value.

- The **brief** keyword causes ping test characters to be displayed. The following ping test characters are supported.

! Indicates that a reply was received.

. Indicates that the network server timed out while waiting for a reply.

U Indicates that a destination unreachable error PDU was received.

I Indicates that the user interrupted ping.

Configuring an IPv6 Syslog server

To enable IPv6 logging, specify an IPv6 Syslog server. Enter a command such as the following.

```
Brocade(config)#log host ipv6 2001:DB8:e0bb::4/128
```

Syntax: `log host ipv6 <ipv6-address> [<udp-port-num>]`

The *<ipv6-address>* must be in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The *<udp-port-num>* optional parameter specifies the UDP application port used for the Syslog facility.

Viewing IPv6 SNMP server addresses

Some of the **show** commands display IPv6 addresses for IPv6 SNMP servers. The following shows an example output for the **show snmp server** command.

```
Brocade#show snmp server
```

```
Contact:
```

```
    Location:
```

```
Community(ro): .....
```

```
Traps
```

```
    Warm/Cold start: Enable
```

```
        Link up: Enable
```

```
        Link down: Enable
```

```
        Authentication: Enable
```

```
    Locked address violation: Enable
```

```
    Power supply failure: Enable
```

```
        Fan failure: Enable
```

```
    Temperature warning: Enable
```

```
        STP new root: Enable
```

```
    STP topology change: Enable
```

```
vsrp: Enable

Total Trap-Receiver Entries: 4

Trap-Receiver IP-Address      Port-Number Community
-----
1      192.147.201.100      162      .....
2      2001:DB8::200      162      .....
3      192.147.202.100      162      .....
4      2001:DB8::200      162      .....
```

Disabling router advertisement and solicitation messages

Router advertisement and solicitation messages enable a node on a link to discover the routers on the same link. By default, router advertisement and solicitation messages are permitted on the device. To disable these messages, configure an IPv6 access control list that denies them. The following shows an example configuration.

Example

```
Brocade(config)#ipv6 access-list rtradvert
Brocade(config)#deny icmp any any router-advertisement
Brocade(config)#deny icmp any any router-solicitation
Brocade(config)#permit ipv6 any any
```

Disabling IPv6 on a Layer 2 switch

IPv6 is enabled by default in the Layer 2 switch code. If desired, you can disable IPv6 on a global basis on a device running the switch code. To do so, enter the following command at the Global CONFIG level of the CLI.

```
Brocade(config)#no ipv6 enable
```

Syntax: no ipv6 enable

To re-enable IPv6 after it has been disabled, enter **ipv6 enable**.

NOTE

IPv6 is disabled by default in the router code and must be configured on each interface that will support IPv6.

Static IPv6 route configuration

NOTE

Static IPv6 route configuration is supported only with the IPv6 Layer 3 PROM and the full Layer 3 image.

You can configure a static IPv6 route to be redistributed into a routing protocol, but you cannot redistribute routes learned by a routing protocol into the static IPv6 routing table.

Before configuring a static IPv6 route, you must enable the forwarding of IPv6 traffic on the Layer 3 switch using the **ipv6 unicast-routing** command and enable IPv6 on at least one interface by configuring an IPv6 address or explicitly enabling IPv6 on that interface. For more information on performing these configuration tasks, refer to [“Configuring IPv4 and IPv6 protocol stacks”](#) on page 111.

Configuring a static IPv6 route

To configure a static IPv6 route for a destination network with the prefix 2001:DB8::0/32, a next-hop gateway with the global address 2001:DB8:0:ee44::1, and an administrative distance of 110, enter the following command.

```
Brocade(config)#ipv6 route 2001:DB8::0/32 2001:DB8:0:ee44::1 distance 110
```

Syntax: **ipv6 route** <dest-ipv6-prefix>/<prefix-length> <next-hop-ipv6-address> [<metric>] [distance <number>]

To configure a static IPv6 route for a destination network with the prefix 2001:DB8::0/32 and a next-hop gateway with the link-local address 2001:DB8:1 that the Layer 3 switch can access through Ethernet interface 1/2/1, enter the following command.

```
Brocade(config)#ipv6 route 2001:DB8::0/32 ethernet 1/2/1 2001:DB8:1
```

Syntax: **ipv6 route** <dest-ipv6-prefix>/<prefix-length> [**ethernet** <stack-unit>/<slot>/<port> | **ve** <num>] <next-hop-ipv6-address> [<metric>] [distance <number>]

Specify Ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

To configure a static IPv6 route for a destination network with the prefix 2001:DB8::0/32 and a next-hop gateway that the Layer 3 switch can access through tunnel 1, enter the following command.

```
Brocade(config)#ipv6 route 2001:DB8::0/32 tunnel 1
```

Syntax: **ipv6 route** <dest-ipv6-prefix>/<prefix-length> <interface> <port> [<metric>] [distance <number>]

[Table 24](#) describes the parameters associated with this command and indicates the status of each parameter.

TABLE 24 Static IPv6 route parameters

Parameter	Configuration details	Status
The IPv6 prefix and prefix length of the route's destination network.	<p>You must specify the <code><dest-ipv6-prefix></code> parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.</p> <p>You must specify the <code><prefix-length></code> parameter as a decimal value. A slash mark (/) must follow the <code><ipv6-prefix></code> parameter and precede the <code><prefix-length></code> parameter.</p>	Mandatory for all static IPv6 routes.
<p>The route's next-hop gateway, which can be one of the following:</p> <ul style="list-style-type: none"> • The IPv6 address of a next-hop gateway. • A tunnel interface. 	<p>You can specify the next-hop gateway as one of the following types of IPv6 addresses:</p> <ul style="list-style-type: none"> • A global address. • A link-local address. <p>If you specify a global address, you do not need to specify any additional parameters for the next-hop gateway. If you specify a link-local address, you must also specify the interface through which to access the address. You can specify one of the following interfaces:</p> <ul style="list-style-type: none"> • An Ethernet interface. • A tunnel interface. • A virtual interface (VE). <p>If you specify an Ethernet interface, also specify the port number associated with the interface. If you specify a VE or tunnel interface, also specify the VE or tunnel number. You can also specify the next-hop gateway as a tunnel interface. If you specify a tunnel interface, also specify the tunnel number.</p>	Mandatory for all static IPv6 routes.
The route's metric.	You can specify a value from 1 – 16.	Optional for all static IPv6 routes. (The default metric is 1.)
The route's administrative distance.	You must specify the distance keyword and any numerical value.	Optional for all static IPv6 routes. (The default administrative distance is 1.)

A metric is a value that the Layer 3 switch uses when comparing this route to other static routes in the IPv6 static route table that have the same destination. The metric applies only to routes that the Layer 3 switch has already placed in the IPv6 static route table.

The administrative distance is a value that the Layer 3 switch uses to compare this route with routes from other route sources that have the same destination. (The Layer 3 switch performs this comparison before placing a route in the IPv6 route table.) This parameter does not apply to routes that are already in the IPv6 route table. In general, a low administrative distance indicates a preferred route. By default, static routes take precedence over routes learned by routing protocols. If you want a dynamic route to be chosen over a static route, you can configure the static route with a higher administrative distance than the dynamic route.

IPv6 over IPv4 tunnels


NOTE

This feature is supported only with the IPv6 Layer 3 PROM and the full Layer 3 image.

To enable communication between isolated IPv6 domains using the IPv4 infrastructure, you can manually configure IPv6 over IPv4 tunnels that provide static point-point connectivity.

As shown in [Figure 10](#), these tunnels encapsulate an IPv6 packet within an IPv4 packet.

FIGURE 10 IPv6 over an IPv4 tunnel



In general, a manually configured tunnel establishes a permanent link between switches in IPv6 domains. A manually configured tunnel has explicitly configured IPv4 addresses for the tunnel source and destination.

This tunneling mechanism requires that the Layer 3 switch at each end of the tunnel run both IPv4 and IPv6 protocol stacks. The Layer 3 switches running both protocol stacks, or dual-stack routers, can interoperate directly with both IPv4 and IPv6 end systems and routers. Refer to [“Configuring IPv4 and IPv6 protocol stacks”](#) on page 111.

IPv6 over IPv4 tunnel configuration notes

- The local tunnel configuration must include both source and destination addresses.
- The remote side of the tunnel must have the opposite source/destination pair.
- A tunnel interface supports static and dynamic IPv6 configuration settings and routing protocols.
- Duplicate Address Detection (DAD) is not currently supported with IPv6 tunnels. Make sure tunnel endpoints do not have duplicate IP addresses.
- Neighbor Discovery (ND) is not supported with IPv6 tunnels.
- If a tunnel source port is a multi-homed IPv4 source, the tunnel will use the first IPv4 address only. For proper tunnel operation, use the **ip address** option.

Configuring a manual IPv6 tunnel

You can use a manually configured tunnel to connect two isolated IPv6 domains. You should deploy this point-to-point tunnelling mechanism if you need a permanent and stable connection.

To configure a manual IPv6 tunnel, enter commands such as the following on a Layer 3 Switch running both IPv4 and IPv6 protocol stacks on each end of the tunnel.

```

Brocade(config)#interface tunnel 1
Brocade(config-tunif-1)#tunnel source ethernet 1/1/1
Brocade(config-tunif-1)#tunnel destination 192.162.100.1
Brocade(config-tunif-1)#tunnel mode ipv6ip
Brocade(config-tunif-1)#ipv6 enable

```

This example creates tunnel interface 1 and assigns a link local IPv6 address with an automatically computed EUI-64 interface ID to it. The IPv4 address assigned to Ethernet interface 1/1/1 is used as the tunnel source, while the IPv4 address 192.168.100.1 is configured as the tunnel destination. The tunnel mode is specified as a manual IPv6 tunnel. Finally, the tunnel is enabled. Note that instead of entering **ipv6 enable**, you could specify an IPv6 address, for example, **ipv6 address 2001:DB8:384d:34::/64 eui-64**, which would also enable the tunnel.

Syntax: [no] interface tunnel <number>

For the <number> parameter, specify a value between 1 – 8.

Syntax: [no] tunnel source <ipv4-address> | ethernet <stack-unit>/<slot>/<port> | loopback <number> | ve <number>

The tunnel source can be an IP address or an interface.

For <ipv4-address>, use 8-bit values in dotted decimal notation.

The **ethernet** | **loopback** | **ve** parameter specifies an interface as the tunnel source. Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

If you specify a loopback, VE, or interface, also specify the loopback, VE, or number, respectively.

Syntax: [no] tunnel destination <ipv4-address>

Specify the <ipv4-address> parameter using 8-bit values in dotted decimal notation.

Syntax: [no] tunnel mode ipv6ip

ipv6ip indicates that this is an IPv6 manual tunnel.

Syntax: ipv6 enable

The **ipv6 enable** command enables the tunnel. Alternatively, you could specify an IPv6 address, which would also enable the tunnel.

Syntax: ipv6 address <ipv6-prefix>/<prefix-length> [eui-64]

The **ipv6 address** command enables the tunnel. Alternatively, you could enter **ipv6 enable**, which would also enable the tunnel.

Specify the <ipv6-prefix> parameter in hexadecimal format using 16-bit values between colons as documented in RFC 2373.

Specify the <prefix-length> parameter as a decimal value. A slash mark (/) must follow the <ipv6-prefix> parameter and precede the <prefix-length> parameter. The **eui-64** keyword configures the global address with an EUI-64 interface ID in the low-order 64 bits. The interface ID is automatically constructed in IEEE EUI-64 format using the interface's MAC address.

Clearing IPv6 tunnel statistics

You can clear statistics (reset all fields to zero) for all IPv6 tunnels or for a specific tunnel interface.

For example, to clear statistics for tunnel 1, enter the following command at the Privileged EXEC level or any of the Config levels of the CLI.

```
Brocade#clear ipv6 tunnel 1
```

To clear statistics for all IPv6 tunnels, enter the following command.

```
Brocade#clear ipv6 tunnel
```

Syntax: `clear ipv6 tunnel [<number>]`

The *<number>* parameter specifies the tunnel number.

Displaying IPv6 tunnel information

Use the commands in this section to display the configuration, status, and counters associated with IPv6 tunnels.

Displaying a summary of tunnel information

To display a summary of tunnel information, enter the following command at any level of the CLI.

```
Brocade#show ipv6 tunnel
IP6 Tunnels
  Tunnel  Mode           Packet Received  Packet Sent
  1       configured    0                0
  2       configured    0                22419
```

Syntax: `show ipv6 tunnel`

This display shows the following information.

TABLE 25 IPv6 tunnel summary information

Field	Description
Tunnel	The tunnel interface number.
Mode	The tunnel mode. Possible modes include the following: <ul style="list-style-type: none"> configured – Indicates a manually configured tunnel.
Packet Received	The number of packets received by a tunnel interface. Note that this is the number of packets received by the CPU. It does not include the number of packets processed in hardware.
Packet Sent	The number of packets sent by a tunnel interface. Note that this is the number of packets sent by the CPU. It does not include the number of packets processed in hardware.

Displaying tunnel interface information

To display status and configuration information for tunnel interface 1, enter the following command at any level of the CLI.

```

Brocade#show interfaces tunnel 1
Tunnell is up, line protocol is up
  Hardware is Tunnel
  Tunnel source ve 30
  Tunnel destination is 2.2.2.10
  Tunnel mode ipv6ip
  No port name
  MTU 1480 bytes, encapsulation IPV4

```

Syntax: `show interfaces tunnel <number>`

The *<number>* parameter indicates the tunnel interface number for which you want to display information.

This display shows the following information.

TABLE 26 IPv6 tunnel interface information

Field	Description
Tunnel interface status	<p>The status of the tunnel interface can be one of the following:</p> <ul style="list-style-type: none"> • up – The tunnel mode is set and the tunnel interface is enabled. • down – The tunnel mode is not set. • administratively down – The tunnel interface was disabled with the disable command.
Line protocol status	<p>The status of the line protocol can be one of the following:</p> <ul style="list-style-type: none"> • up – IPv4 connectivity is established. • down – The line protocol is not functioning and is down.
Hardware is tunnel	The interface is a tunnel interface.
Tunnel source	<p>The tunnel source can be one of the following:</p> <ul style="list-style-type: none"> • An IPv4 address • The IPv4 address associated with an interface/port.
Tunnel destination	The tunnel destination can be an IPv4 address.
Tunnel mode	<p>The tunnel mode can be the following:</p> <ul style="list-style-type: none"> • ipv6ip – indicates a manually configured tunnel
Port name	The port name configured for the tunnel interface.
MTU	The setting of the IPv6 maximum transmission unit (MTU).

Displaying interface level IPv6 settings

To display Interface level IPv6 settings for tunnel interface 1, enter the following command at any level of the CLI.

```

Brocade#show ipv6 interface tunnel 1
Interface Tunnel 1 is up, line protocol is up
  IPv6 is enabled, link-local address is 2001:DB8::3:4:2 [Preferred]
  Global unicast address(es):
    2001:DB8::1 [Preferred], subnet is 2001:DB8::/64
    2001:DB8::1[Preferred], subnet is 2001:DB8::/64
  Joined group address(es):
    2001:DB8::1:ff04:2
    2001:DB8::5
    2001:DB8::1:ff00:1
    2001:DB8::2
    2001:DB8::1
  MTU is 1480 bytes
  ICMP redirects are enabled
  No Inbound Access List Set
  No Outbound Access List Set
  OSPF enabled

```

The display command above reflects the following configuration.

```

Brocade#show running-config interface tunnel 1
!
interface tunnel 1
  port-name ManualTunnel1
  tunnel mode ipv6ip
  tunnel source loopback 1
  tunnel destination 2.1.1.1
  ipv6 address 2001:DB8::1/64
  ipv6 address 2001:DB8::1/64
  ipv6 ospf area 0

```

This display shows the following information.

TABLE 27 Interface level IPv6 tunnel information

Field	Description
Interface Tunnel status	<p>The status of the tunnel interface can be one of the following:</p> <ul style="list-style-type: none"> up – IPv4 connectivity is established. down – The tunnel mode is not set. administratively down – The tunnel interface was disabled with the disable command.
Line protocol status	<p>The status of the line protocol can be one of the following:</p> <ul style="list-style-type: none"> up – IPv6 is enabled through the ipv6 enable or ipv6 address command. down – The line protocol is not functioning and is down.

ECMP load sharing for IPv6

The IPv6 route table selects the best route to a given destination from among the routes in the tables maintained by the configured routing protocols (BGP4, OSPF, static, and so on). The IPv6 route table can contain more than one path to a given destination. When this occurs, the Brocade device selects the path with the lowest cost for insertion into the routing table. If more than one path with the lowest cost exists, all of these paths are inserted into the routing table, subject to the configured maximum number of load sharing paths (by default 4). The device uses ***Equal-Cost Multi-Path (ECMP) load sharing*** to select a path to a destination.

When a route is installed by routing protocols or configured static route for the first time, and the IPv6 route table contains multiple, equal-cost paths to that route, the device checks the IPv6 neighbor for each next hop. Every next hop where the link layer address has been resolved will be stored in hardware. The device will initiate neighbor discovery for the next hops whose link layer addresses are not resolved. The hardware will hash the packet and choose one of the paths. The number of paths would be updated in hardware as the link layer gets resolved for a next hop.

If the path selected by the device becomes unavailable, the IPv6 neighbor should change state and trigger the update of the destination in the hardware.

Brocade devices support network-based ECMP load-sharing methods for IPv6 traffic. The Brocade device distributes traffic across equal-cost paths based on a XOR of some bits from the MAC source address, MAC destination address, IPv6 source address, IPv6 destination address, IPv6 flow label, IPv6 next header. The software selects a path based on a calculation involving the maximum number of load-sharing paths allowed and the actual number of paths to the destination network. This is the default ECMP load-sharing method for IPv6.

You can manually disable or enable ECMP load sharing for IPv6 and specify the number of equal-cost paths the device can distribute traffic across. In addition, you can display information about the status of ECMP load-sharing on the device.

Disabling or re-enabling ECMP load sharing for IPv6

ECMP load sharing for IPv6 is enabled by default. To disable the feature, enter the following command.

```
Brocade(config)#no ipv6 load-sharing
```

If you want to re-enable the feature after disabling it, you must specify the number of load-sharing paths. The maximum number of paths the device supports is a value from 2 – 8. By entering a command such as the following, IPv6 load-sharing will be re-enabled.

```
Brocade(config)#ipv6 load-sharing 4
```

Syntax: [no] ipv6 load-sharing<num>

The <num> parameter specifies the number of paths and can be from 2 – 8. The default is 4.

Changing the maximum load sharing paths for IPv6

By default, IPv6 ECMP load sharing allows traffic to be balanced across up to four equal paths. You can change the maximum number of paths the device supports to a value from 2 – 8.

To change the number of ECMP load sharing paths for IPv6, enter a command such as the following.

```
Brocade(config)#ipv6 load-sharing 6
```

Syntax: [no] ipv6 load-sharing [<num>]

The <num> parameter specifies the number of paths and can be from 2 – 8. The default is 4.

Enabling support for network-based ECMP load sharing for IPv6

Network-based ECMP load sharing is supported. In this configuration, traffic is distributed across equal-cost paths based on the destination network address. Routes to each network are stored in CAM and accessed when a path to a network is required. Because multiple hosts are likely to reside on a network, this method uses fewer CAM entries.

Displaying ECMP load-sharing information for IPv6

To display the status of ECMP load sharing for IPv6, enter the following command.

```
Brocade#show ipv6
Global Settings
  unicast-routing enabled, hop-limit 64
  No Inbound Access List Set
  No Outbound Access List Set
  Prefix-based IPv6 Load-sharing is Enabled, Number of load share paths: 4
```

Syntax: show ipv6

IPv6 ICMP feature configuration

As with the Internet Control Message Protocol (ICMP) for IPv4, ICMP for IPv6 provides error and informational messages. Implementation of the stateless auto configuration, neighbor discovery, and path MTU discovery features use ICMP messages.

This section explains how to configure following IPv6 ICMP features:

- ICMP rate limiting
- ICMP redirects

Configuring ICMP rate limiting

You can limit the rate at which IPv6 ICMP error messages are sent out on a network. IPv6 ICMP implements a token bucket algorithm.

To illustrate how this algorithm works, imagine a virtual bucket that contains a number of tokens. Each token represents the ability to send one ICMP error message. Tokens are placed in the bucket at a specified interval until the maximum number of tokens allowed in the bucket is reached. For each error message that ICMP sends, a token is removed from the bucket. If ICMP generates a series of error messages, messages can be sent until the bucket is empty. If the bucket is empty of tokens, error messages cannot be sent until a new token is placed in the bucket.

You can adjust the following elements related to the token bucket algorithm:

- The interval at which tokens are added to the bucket. The default is 100 milliseconds.
- The maximum number of tokens in the bucket. The default is 10 tokens.

For example, to adjust the interval to 1000 milliseconds and the number of tokens to 100 tokens, enter the following command.

```
Brocade(config)# ipv6 icmp error-interval 1000 100
```

Syntax: `ipv6 icmp error-interval <interval> [<number-of-tokens>]`

The interval in milliseconds at which tokens are placed in the bucket can range from 0 – 2147483647. The maximum number of tokens stored in the bucket can range from 1 – 200.

NOTE

If you retain the default interval value or explicitly set the value to 100 milliseconds, output from the **show run** command does not include the setting of the **ipv6 icmp error-interval** command because the setting is the default.

Also, if you configure the interval value to a number that does not evenly divide into 100000 (100 milliseconds), the system rounds up the value to a next higher value that does divide evenly into 100000. For example, if you specify an interval value of 150, the system rounds up the value to 200.

ICMP rate limiting is enabled by default. To disable ICMP rate limiting, set the interval to zero.

Enabling IPv6 ICMP redirect messages

NOTE

This feature is supported only with the IPv6 Layer 3 PROM and the full Layer 3 image.

You can enable a Layer 3 switch to send an IPv6 ICMP redirect message to a neighboring host to inform it of a better first-hop router on a path to a destination. By default, the sending of IPv6 ICMP redirect messages by a Layer 3 switch is disabled. (For more information about how ICMP redirect messages are implemented for IPv6, refer to [“IPv6 neighbor discovery configuration”](#) on page 129.)

NOTE

This feature is supported on Virtual Ethernet (VE) interfaces only.

For example, to enable the sending of IPv6 ICMP redirect messages on VE 2, enter the following commands.

```
Brocade(config)#interface ve2
Brocade(config-vif-2)#ipv6 redirects
```

To disable the sending of IPv6 ICMP redirect messages after it has been enabled on VE 2, enter the following commands.

```
Brocade(config)#interface ve2
Brocade(config-vif-2)#no ipv6 redirects
```

Syntax: [no] ipv6 redirects

Use the **show ipv6 interface** command to verify that the sending of IPv6 ICMP redirect messages is enabled on a particular interface.

IPv6 neighbor discovery configuration

The neighbor discovery feature for IPv6 uses IPv6 ICMP messages to do the following tasks:

- Determine the link-layer address of a neighbor on the same link.
- Verify that a neighbor is reachable.
- Track neighbor routers.

An IPv6 host is required to listen for and recognize the following addresses that identify itself:

- Link-local address.
- Assigned unicast address.
- Loopback address.
- All-nodes multicast address.
- Solicited-node multicast address.
- Multicast address to all other groups to which it belongs.

You can adjust the following IPv6 neighbor discovery features:

- Neighbor solicitation messages for duplicate address detection.
- Router advertisement messages:

- Interval between router advertisement messages.
- Value that indicates a router is advertised as a default router (for use by all nodes on a given link).
- Prefixes advertised in router advertisement messages.
- Flags for host stateful autoconfiguration.
- Amount of time during which an IPv6 node considers a remote node reachable (for use by all nodes on a given link).

IPv6 neighbor discovery configuration notes

NOTE

For all solicitation and advertisement messages, Brocade uses seconds as the unit of measure instead of milliseconds.

- If you add a port to a port-based VLAN, and the port has IPv6 neighbor discovery configuration, the system will clean up the neighbor discovery configuration from the port and display the following message on the console.


```
ND6 port config on the new member ports removed
```
- Neighbor discovery is not supported on tunnel interfaces.

Neighbor solicitation and advertisement messages

Neighbor solicitation and advertisement messages enable a node to determine the link-layer address of another node (neighbor) on the same link. (This function is similar to the function provided by the Address Resolution Protocol [ARP] in IPv4.) For example, node 1 on a link wants to determine the link-layer address of node 2 on the same link. To do so, node 1, the source node, multicasts a neighbor solicitation message. The neighbor solicitation message, which has a value of 135 in the Type field of the ICMP packet header, contains the following information:

- **Source address:** IPv6 address of node 1 interface that sends the message.
- **Destination address:** solicited-node multicast address (2001:DB8:0:0:0:1:FF00::/104) that corresponds the IPv6 address of node 2.
- Link-layer address of node 1.
- A query for the link-layer address of node 2.

After receiving the neighbor solicitation message from node 1, node 2 replies by sending a neighbor advertisement message, which has a value of 136 in the Type field of the ICMP packet header. The neighbor solicitation message contains the following information:

- **Source address:** IPv6 address of the node 2 interface that sends the message.
- **Destination address:** IPv6 address of node 1.
- Link-layer address of node 2.

After node 1 receives the neighbor advertisement message from node 2, nodes 1 and 2 can now exchange packets on the link.

After the link-layer address of node 2 is determined, node 1 can send neighbor solicitation messages to node 2 to verify that it is reachable. Also, nodes 1, 2, or any other node on the same link can send a neighbor advertisement message to the all-nodes multicast address (2001:DB8:1) if there is a change in their link-layer address.

Router advertisement and solicitation messages

Router advertisement and solicitation messages enable a node on a link to discover the routers on the same link.

Each configured router interface on a link sends out a router advertisement message, which has a value of 134 in the Type field of the ICMP packet header, periodically to the all-nodes link-local multicast address (2001:DB8::1).

A configured router interface can also send a router advertisement message in response to a router solicitation message from a node on the same link. This message is sent to the unicast IPv6 address of the node that sent the router solicitation message.

At system startup, a host on a link sends a router solicitation message to the all-routers multicast address (FF01). Sending a router solicitation message, which has a value of 133 in the Type field of the ICMP packet header, enables the host to automatically configure its IPv6 address immediately instead of awaiting the next periodic router advertisement message.

Because a host at system startup typically does not have a unicast IPv6 address, the source address in the router solicitation message is usually the unspecified IPv6 address (0:0:0:0:0:0:0:0). If the host has a unicast IPv6 address, the source address is the unicast IPv6 address of the host interface sending the router solicitation message.

Entering the **ipv6 unicast-routing** command automatically enables the sending of router advertisement messages on all configured router Ethernet interfaces. You can configure several router advertisement message parameters. For information about disabling the sending of router advertisement messages and the router advertisement parameters that you can configure, refer to [“Enabling and disabling IPv6 router advertisements”](#) on page 135 and [“Setting IPv6 router advertisement parameters”](#) on page 132.

Neighbor redirect messages

After forwarding a packet, by default, a router can send a neighbor redirect message to a host to inform it of a better first-hop router. The host receiving the neighbor redirect message will then readdress the packet to the better router.

A router sends a neighbor redirect message only for unicast packets, only to the originating node, and to be processed by the node.

A neighbor redirect message has a value of 137 in the Type field of the ICMP packet header.

Setting neighbor solicitation parameters for duplicate address detection

Although the stateless auto configuration feature assigns the 64-bit interface ID portion of an IPv6 address using the MAC address of the host's NIC, duplicate MAC addresses can occur. Therefore, the duplicate address detection feature verifies that a unicast IPv6 address is unique before it is assigned to a host interface by the stateless auto configuration feature. Duplicate address detection verifies that a unicast IPv6 address is unique.

If duplicate address detection identifies a duplicate unicast IPv6 address, the address is not used. If the duplicate address is the link-local address of the host interface, the interface stops processing IPv6 packets.

NOTE

Duplicate Address Detection (DAD) is not currently supported with IPv6 tunnels. Make sure tunnel endpoints do not have duplicate IP addresses.

You can configure the following neighbor solicitation message parameters that affect duplicate address detection while it verifies that a tentative unicast IPv6 address is unique:

- The number of consecutive neighbor solicitation messages that duplicate address detection sends on an interface. By default, duplicate address detection sends three neighbor solicitation messages without any follow-up messages.
- The interval in seconds at which duplicate address detection sends a neighbor solicitation message on an interface. By default, duplicate address detection sends a neighbor solicitation message every 1000 milliseconds.

For example, to change the number of neighbor solicitation messages sent on Ethernet interface 1/2/1 to two and the interval between the transmission of the two messages to 9 seconds, enter the following commands.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 nd dad attempt 2
Brocade(config-if-e10000-1/1/1)#ipv6 nd ns-interval 9000
```

Syntax: `[no] ipv6 nd dad attempt <number>`

Syntax: `[no] ipv6 nd ns-interval <number>`

For the number of neighbor solicitation messages, specify a number from 0 – 255. The default is 3. Configuring a value of 0 disables duplicate address detection processing on the specified interface. To restore the number of messages to the default value, use the **no** form of this command.

For the interval between neighbor solicitation messages and the value for the retrans timer in router advertisements, specify a number from 0 – 4294967295 milliseconds. The default value for the interval between neighbor solicitation messages is 1000 milliseconds. The default value for the retrans timer is 0. Brocade does not recommend very short intervals in normal IPv6 operation. When a non-default value is configured, the configured time is both advertised and used by the router itself. To restore the default interval, use the **no** form of this command.

Setting IPv6 router advertisement parameters

You can adjust the following parameters for router advertisement messages:

- The interval (in seconds) at which an interface sends router advertisement messages. By default, an interface sends a router advertisement message every 200 seconds.
- The "router lifetime" value, which is included in router advertisements sent from a particular interface. The value (in seconds) indicates if the router is advertised as a default router on this interface. If you set the value of this parameter to 0, the router is not advertised as a default router on an interface. If you set this parameter to a value that is not 0, the router is advertised as a default router on this interface. By default, the router lifetime value included in router advertisement messages sent from an interface is 1800 seconds.
- The hop limit to be advertised in the router advertisement.

When adjusting these parameter settings, Brocade recommends that the interval between router advertisement transmission be less than or equal to the router lifetime value if the router is advertised as a default router. For example, to adjust the interval of router advertisements to 300 seconds and the router lifetime value to 1900 seconds on Ethernet interface 1/1/1, enter the following commands.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 nd ra-interval 300
Brocade(config-if-e10000-1/1/1)#ipv6 nd ra-lifetime 1900
Brocade(config-if-e10000-1/1/1)#ipv6 nd ra-hop-limit 1
```

Here is another example with a specified range.

```
Brocade(config)#interface ethernet 1/1/2
Brocade(config-if-e10000-1/1/2)#ipv6 nd ra-interval range 33 55
Brocade(config-if-e10000-1/1/2)#ipv6 nd ra-lifetime 1900
Brocade(config-if-e10000-1/1/2)#ipv6 nd ra-hop-limit 1
```

Syntax: [no] **ipv6 nd ra-interval** <number> | <min range value> <max range value>

Syntax: [no] **ipv6 nd ra-lifetime** <number>

Syntax: **ipv6 nd ra-hop-limit** <number>

<number> is a value from 0 – 255. The default is 64.

The **ipv6 nd ra-interval** <number> can be a value between 3 – 1800 seconds. The default is 200 seconds. The actual RA interval will be from .5 to 1.5 times the configured or default value. For example, in the above configuration, for **ipv6 nd ra-interval 300**, the range would be 150 – 450. To restore the default interval of 200 seconds, use the no form of the command.

The **ipv6 nd ra-interval range** <min range value> <max range value> command lets you specify a range of values instead of a single value.

The <min range value> specifies the minimum number of seconds allowed between sending unsolicited multicast router advertisements from the interface. The default is 0.33 times the <max range value> if the <max range value> is greater than or equal to 9 seconds. Otherwise, the default is the value specified by the <max range value>. The <min range value> can be a number between -3 – (.75 x <max range value>).

The <max range value> parameter specifies the maximum number of seconds allowed between sending unsolicited multicast router advertisements from the interface. This number can be between 4 – 1800 seconds and must be greater than the <min range value> x 1.33. The default is 600 seconds.

The **ipv6 nd ra-lifetime** <number> is a value between 0 – 9000 seconds. To restore the router lifetime value of 1800 seconds, use the **no** form of the command.

The **ipv6 nd ra-hop-limit** <number> is a value from 0 – 255. The default is 64.

NOTE

By default, router advertisements will always have the MTU option. To suppress the MTU option, use the following command at the Interface level of the CLI: **ipv6 nd suppress-mtu-option**.

Prefixes advertised in IPv6 router advertisement messages

By default, router advertisement messages include prefixes configured as addresses on router interfaces using the **ipv6 address** command. You can use the **ipv6 nd prefix-advertisement** command to control exactly which prefixes are included in router advertisement messages. Along with which prefixes the router advertisement messages contain, you can also specify the following parameters:

- **Valid lifetime**—(Mandatory) The time interval (in seconds) in which the specified prefix is advertised as valid. The default is 2592000 seconds (30 days). When the timer expires, the prefix is no longer considered to be valid.
- **Preferred lifetime**—(Mandatory) The time interval (in seconds) in which the specified prefix is advertised as preferred. The default is 604800 seconds (7 days). When the timer expires, the prefix is no longer considered to be preferred.
- **Onlink flag**—(Optional) If this flag is set, the specified prefix is assigned to the link upon which it is advertised. Nodes sending traffic to addresses that contain the specified prefix consider the destination to be reachable on the local link.
- **Autoconfiguration flag**—(Optional) If this flag is set, the stateless auto configuration feature can use the specified prefix in the automatic configuration of 128-bit IPv6 addresses for hosts on the local link, provided the specified prefix is aggregatable, as specified in RFC 2374.

For example, to advertise the prefix 2001:DB8:a487:7365::/64 in router advertisement messages sent out on Ethernet interface 1/1/1 with a valid lifetime of 1000 seconds, a preferred lifetime of 800 seconds, and the Onlink and Autoconfig flags set, enter the following commands.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 nd prefix-advertisement
2001:DB8:a487:7365::/64 1000 800 onlink autoconfig
```

Syntax: **[no] ipv6 nd prefix-advertisement** <ipv6-prefix>/<prefix-length> <valid-lifetime> <preferred-lifetime> **[autoconfig] [onlink]**

You must specify the <ipv6-prefix> parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

You must specify the <prefix-length> parameter as a decimal value. A slash mark (/) must follow the <ipv6-prefix> parameter and precede the <prefix-length> parameter.

The valid lifetime and preferred lifetime is a numerical value between 0 – 4294967295 seconds. The default valid lifetime is 2592000 seconds (30 days), while the default preferred lifetime is 604800 seconds (7 days).

To remove a prefix from the router advertisement messages sent from a particular interface, use the **no** form of this command.

Setting flags in IPv6 router advertisement messages

An IPv6 router advertisement message can include the following flags:

- **Managed Address Configuration**—This flag indicates to hosts on a local link if they should use the stateful autoconfiguration feature to get IPv6 addresses for their interfaces. If the flag is set, the hosts use stateful autoconfiguration to get addresses as well as non-IPv6-address information. If the flag is not set, the hosts do not use stateful autoconfiguration to get addresses and if the hosts can get non-IPv6-address information from stateful autoconfiguration is determined by the setting of the Other Stateful Configuration flag.
- **Other Stateful Configuration**—This flag indicates to hosts on a local link if they can get non-IPv6 address autoconfiguration information. If the flag is set, the hosts can use stateful autoconfiguration to get non-IPv6-address information.

NOTE

When determining if hosts can use stateful autoconfiguration to get non-IPv6-address information, a set Managed Address Configuration flag overrides an unset Other Stateful Configuration flag. In this situation, the hosts can obtain nonaddress information. However, if the Managed Address Configuration flag is not set and the Other Stateful Configuration flag is set, then the setting of the Other Stateful Configuration flag is used.

By default, the Managed Address Configuration and Other Stateful Configuration flags are not set in router advertisement messages. For example, to set these flags in router advertisement messages sent from Ethernet interface 1/1/1, enter the following commands.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 nd managed-config-flag
Brocade(config-if-e10000-1/1/1)#ipv6 nd other-config-flag
```

Syntax: [no] ipv6 nd managed-config-flag

Syntax: [no] ipv6 nd other-config-flag

To remove either flag from router advertisement messages sent on an interface, use the **no** form of the respective command.

Enabling and disabling IPv6 router advertisements

If IPv6 unicast routing is enabled on an Ethernet interface, by default, this interface sends IPv6 router advertisement messages. However, by default, non-LAN interface types, for example, tunnel interfaces, do not send router advertisement messages.

To disable the sending of router advertisement messages on an Ethernet interface, enter commands such as the following.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 nd suppress-ra
```

To enable the sending of router advertisement messages on a tunnel interface, enter commands such as the following.

```
Brocade(config)#interface tunnel 1
Brocade(config-tnif-1)#no ipv6 nd suppress-ra
```

Syntax: [no] ipv6 nd suppress-ra

Configuring reachable time for remote IPv6 nodes

You can configure the duration (in seconds) that a router considers a remote IPv6 node reachable. By default, a router interface uses the value of 30 seconds.

The router advertisement messages sent by a router interface include the amount of time specified by the **ipv6 nd reachable-time** command so that nodes on a link use the same reachable time duration. By default, the messages include a default value of 0.

Brocade does not recommend configuring a short reachable time duration, because a short duration causes the IPv6 network devices to process the information at a greater frequency.

For example, to configure the reachable time of 40 seconds for Ethernet interface 1/1/1, enter the following commands.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 nd reachable-time 40
```

Syntax: [no] **ipv6 nd reachable-time** <seconds>

For the <seconds> parameter, specify a number from 0 – 3600 seconds. To restore the default time, use the **no** form of this command.

NOTE

The actual reachable time will be from .5 to 1.5 times the configured or default value.

IPv6 MTU

The IPv6 maximum transmission unit (MTU) is the maximum length of an IPv6 packet that can be transmitted on a particular interface. If an IPv6 packet is longer than an MTU, the host that originated the packet fragments the packet and transmits its contents in multiple packets that are shorter than the configured MTU.

By default, in *non-jumbo mode*, the maximum Ethernet MTU size is 1500 bytes. When **jumbo** is enabled, the default maximum Ethernet MTU size is 10200.

Configuration notes and feature limitations for IPv6 MTU

- The IPv6 MTU command is applicable to VEs and physical IP interfaces. It applies to traffic routed between networks.
- You cannot use this command to set Layer 2 maximum frame sizes per interface. The global **jumbo** command causes all interfaces to accept Layer 2 frames.
- For non-jumbo mode, you can configure an IPv6 MTU greater than 1500 bytes, although the default remains at 1500 bytes. The value of the MTU you can define depends on the following:
 - For a physical port, the maximum value of the MTU is the equal to the maximum frame size of the port minus 18 (Layer 2 MAC header + CRC).
 - If the size of a jumbo packet received on a port is equal to the maximum frame size – 18 (Layer 2 MAC header + CRC) and if this value is greater than the outgoing port's IPv4/IPv6 MTU, then it will be forwarded in the CPU.

- For a virtual routing interface, the maximum value of the MTU is the maximum frame size configured for the VLAN to which it is associated, minus 18 (Layer 2 MAC header + CRC). If a maximum frame size for a VLAN is not configured, then configure the MTU based on the smallest maximum frame size of all the ports of the VLAN that corresponds to the virtual routing interface, minus 18 (Layer 2 MAC header + CRC).

Changing the IPv6 MTU

To define IPv6 maximum transmission unit (MTU) globally, enter the **ipv6 mtu** command at the Global CONFIG level of the CLI:

```
Brocade(config)#ipv6 mtu 1300
```

You can configure the IPv6 MTU on individual interfaces. For example, to configure the MTU on Ethernet interface 1/2/1 as 1280 bytes, enter the following commands.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#ipv6 mtu 1280
```

Syntax: [no] **ipv6 mtu** <bytes>

For <bytes>, specify a value between 1280 – 1500, or 1280 – 10200 if **jumbo** mode is enabled. If a nondefault value is configured for an interface, router advertisements include an MTU option.

Static neighbor entries configuration

In some special cases, a neighbor cannot be reached using the neighbor discovery feature. In this situation, you can add a static entry to the IPv6 neighbor discovery cache, which causes a neighbor to be reachable at all times without using neighbor discovery. (A static entry in the IPv6 neighbor discovery cache functions like a static ARP entry in IPv4.)

NOTE

A port that has a statically assigned IPv6 entry cannot be added to a VLAN.

NOTE

Static neighbor configurations will be cleared on secondary ports when a trunk is formed.

For example, to add a static entry for a neighbor with the IPv6 address 2001:DB8:2678:47b and link-layer address 2001.DB8.8641 that is reachable through Ethernet interface 1/1/1, enter the **ipv6 neighbor** command.

```
Brocade(config)#ipv6 neighbor 2001:DB8:2678:47b ethernet 1/1/1 2001.DB8.8641
```

Syntax: [no] **ipv6 neighbor** <ipv6-address> **ethernet** <stack-unit>/<slot>/<port> | **ve** <ve-number> [**ethernet** <stack-unit>/<slot>/<port>] <link-layer-address>

The <ipv6-address> parameter specifies the address of the neighbor.

The **ethernet** | **ve** parameter specifies the interface through which to reach a neighbor. Specify the Ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1. If you specify a VE, specify the VE number and then the Ethernet port numbers associated with the VE. The link-layer address is a 48-bit hardware address of the neighbor.

5 Limiting the number of hops an IPv6 packet can traverse

If you attempt to add an entry that already exists in the neighbor discovery cache, the software changes the already existing entry to a static entry.

To remove a static IPv6 entry from the IPv6 neighbor discovery cache, use the **no** form of this command.

Limiting the number of hops an IPv6 packet can traverse

By default, the maximum number of hops an IPv6 packet can traverse is 64. You can change this value to between 0 – 255 hops. For example, to change the maximum number of hops to 70, enter the following command.

```
Brocade(config)#ipv6 hop-limit 70
```

Syntax: [no] **ipv6 hop-limit** <number>

Use the **no** form of the command to restore the default value.

hop-limit 0 will transmit packets with default (64) hop limit.

<number> can be from 0 – 255.

IPv6 source routing security enhancements

The IPv6 specification (RFC 2460) specifies support for IPv6 source-routed packets using a type 0 Routing extension header, requiring device and host to process the type 0 routing extension header. However, this requirement may leave a network open to a DoS attack.

A security enhancement disables sending IPv6 source-routed packets to IPv6 devices. (This enhancement conforms to RFC 5095.)

By default, when the router drops a source-routed packet, it sends an ICMP Parameter Problem (type 4), Header Error (code 0) message to the packet's source address, pointing to the unrecognized routing type. To disable these ICMP error messages, enter the following command:

```
Brocade(config)# no ipv6 icmp source-route
```

Syntax: [no] **ipv6 icmp source-route**

Use the **ipv6 icmp source-route** form of the command to enable the ICMP error messages.

Clearing global IPv6 information

You can clear the following global IPv6 information:

- Entries from the IPv6 cache.
- Entries from the IPv6 neighbor table.
- IPv6 routes from the IPv6 route table.
- IPv6 traffic statistics.

Clearing the IPv6 cache

You can remove all entries from the IPv6 cache or specify an entry based on the following:

- IPv6 prefix.
- IPv6 address.
- Interface type.

For example, to remove entries for IPv6 address 2001:DB8::1, enter the following command at the Privileged EXEC level or any of the Config levels of the CLI.

```
Brocade#clear ipv6 cache 2001:DB8::1
```

Syntax: `clear ipv6 cache [<ipv6-prefix>/<prefix-length> | <ipv6-address> | ethernet <stack-unit>/<slot>/<port> | tunnel <number> | ve <number>]`

You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373. You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

You must specify the `<ipv6-address>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The **ethernet | tunnel | ve** parameter specifies the interfaces for which you can remove cache entries. Specify the Ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1. If you specify a VE or tunnel interface, also specify the VE or tunnel number, respectively.

Clearing IPv6 neighbor information

You can remove all entries from the IPv6 neighbor table or specify an entry based on the following:

- IPv6 prefix
- IPv6 address
- Interface type

For example, to remove entries for Ethernet interface 1/2/1, enter the following command at the Privileged EXEC level or any of the CONFIG levels of the CLI.

```
Brocade#clear ipv6 neighbor ethernet 1/2/1
```

Syntax: `clear ipv6 neighbor [<ipv6-prefix>/<prefix-length> | <ipv6-address> | ethernet <stack-unit>/<slot>/<port> | ve <number>]`

You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373. You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

You must specify the `<ipv6-address>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The **ethernet | ve** parameter specifies the interfaces for which you can remove cache entries. Specify the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1. If you specify a VE, also specify the VE number.

Clearing IPv6 routes from the IPv6 route table

You can clear all IPv6 routes or only those routes associated with a particular IPv6 prefix from the IPv6 route table and reset the routes.

For example, to clear IPv6 routes associated with the prefix 2001:DB8::/32, enter the following command at the Privileged EXEC level or any of the Config levels of the CLI.

```
Brocade#clear ipv6 route 2001:DB8::/32
```

Syntax: `clear ipv6 route [<ipv6-prefix>/<prefix-length>]`

The `<ipv6-prefix>/<prefix-length>` parameter clears routes associated with a particular IPv6 prefix. You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373. You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

Clearing IPv6 traffic statistics

To clear all IPv6 traffic statistics (reset all fields to zero), enter the following command at the Privileged EXEC level or any of the Config levels of the CLI.

```
Brocade(config)#clear ipv6 traffic
```

Syntax: `clear ipv6 traffic`

Displaying global IPv6 information

You can display output for the following global IPv6 parameters:

- IPv6 cache
- IPv6 interfaces
- IPv6 neighbors
- IPv6 route table
- Local IPv6 routers
- IPv6 TCP connections and the status of individual connections
- IPv6 traffic statistics

Displaying IPv6 cache information

The IPv6 cache contains an IPv6 host table that has indices to the next hop gateway and the router interface on which the route was learned.

To display IPv6 cache information, enter the following command at any CLI level.

```

Brocade#show ipv6 cache
Total number of cache entries: 10
Total number of cache entries: 10

```

	IPv6 Address	Next Hop	Port
1	2001:DB8::2	LOCAL	tunnel 2
2	2001:DB8::106	LOCAL	ethe 1/1/1
3	2001:DB8::110	DIRECT	ethe 1/1/2
4	2001:DB8:46a::1	LOCAL	ethe 1/1/3
5	2001:DB8::2e0:52ff:fe99:9737	LOCAL	ethe 1/1/4
6	2001:DB8::fff:ffff:feff:ffff	LOCAL	loopback 2
7	2001:DB8::c0a8:46a	LOCAL	tunnel 2
8	2001:DB8::c0a8:46a	LOCAL	tunnel 6
9	2001:DB8::1	LOCAL	loopback 2
10	2001:DB8::2e0:52ff:fe99:9700	LOCAL	ethe 1/1/5

Syntax: `show ipv6 cache [<index-number> | <ipv6-prefix>/<prefix-length> | <ipv6-address> | ethernet <stack-unit>/<slot>/<port> | ve <number> | tunnel <number>]`

The `<index-number>` parameter restricts the display to the entry for the specified index number and subsequent entries.

The `<ipv6-prefix>/<prefix-length>` parameter restricts the display to the entries for the specified IPv6 prefix. You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373. You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

The **ethernet | ve | tunnel** parameter restricts the display to the entries for the specified interface. The `<ipv6-address>` parameter restricts the display to the entries for the specified IPv6 address. You must specify this parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

Specify the ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1. If you specify a VE interface, also specify the VE number. If you specify a tunnel interface, also specify the tunnel number.

This display shows the following information.

TABLE 28 IPv6 cache information fields

Field	Description
Total number of cache entries	The number of entries in the cache table.
IPv6 Address	The host IPv6 address.
Next Hop	The next hop, which can be one of the following: <ul style="list-style-type: none"> Direct – The next hop is directly connected to the router. Local – The next hop is originated on this router. <code><ipv6 address></code> – The IPv6 address of the next hop.
Port	The port on which the entry was learned.

Displaying IPv6 interface information

To display IPv6 interface information, enter the following command at any CLI level.

5 Displaying global IPv6 information

```
Brocade#show ipv6 interface
Routing Protocols : R - RIP  O - OSPF
Interface      Status      Routing  Global Unicast Address
Ethernet 1/1/1 down/down  R
Ethernet 1/1/2 down/down
Ethernet 1/1/3 up/up                2001:DB8::c017:101/64
Ethernet 1/1/4 up/up                2001:DB8::c019:101/64
VE 4           down/down
VE 14          up/up                2001:DB8::c060:101/64
Loopback 1     up/up                2001:DB8::1/128
Loopback 2     up/up                2001:DB8::303:303/128
Loopback 3     up/up
```

Syntax: `show ipv6 interface [<interface> [<stack-unit>/<slot>/<port> | <number>]]`

The `<interface>` parameter displays detailed information for a specified interface. For the interface, you can specify the **Ethernet**, **loopback**, **tunnel**, or **VE** keywords. Specify the Ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1. If you specify a loopback, tunnel, or VE interface, also specify the number associated with the interface.

This display shows the following information.

TABLE 29 General IPv6 interface information fields

Field	Description
Routing protocols	A one-letter code that represents a routing protocol that can be enabled on an interface.
Interface	The interface type, and the port number or number of the interface.
Status	The status of the interface. The entry in the Status field will be either “up/up” or “down/down”.
Routing	The routing protocols enabled on the interface.
Global Unicast Address	The global unicast address of the interface.

To display detailed information for a specific interface, enter a command such as the following at any CLI level.


```

Brocade#show ipv6 interface ethernet 1/1/1
Interface Ethernet 1/1/1 is up, line protocol is up
  IPv6 is enabled, link-local address is 2001:DB8::2e0:52ff:fe99:97
  Global unicast address(es):
  Joined group address(es):
    2001:DB8::9
    2001:DB8::1:ff99:9700
    2001:DB8::2
    2001:DB8::1
  MTU is 1500 bytes
  ICMP redirects are enabled
  ND DAD is enabled, number of DAD attempts: 3
  ND reachable time is 30 seconds
  ND advertised reachable time is 0 seconds
  ND retransmit interval is 1 seconds
  ND advertised retransmit interval is 0 seconds
  ND router advertisements are sent every 200 seconds
  ND router advertisements live for 1800 seconds
  No Inbound Access List Set
  No Outbound Access List Set
  RIP enabled

```

This display shows the following information.

TABLE 30 Detailed IPv6 interface information fields

Field	Description
Interface/line protocol status	The status of interface and line protocol. If you have disabled the interface with the disable command, the status will be “administratively down”. Otherwise, the status is either “up” or “down”.
IPv6 status/link-local address	The status of IPv6. The status is either “enabled” or “disabled”. Displays the link-local address, if one is configured for the interface.
Global unicast address(es)	Displays the global unicast address(es), if one or more are configured for the interface.
Joined group address(es)	The multicast address(es) that a router interface listens for and recognizes.
MTU	The setting of the maximum transmission unit (MTU) configured for the IPv6 interface. The MTU is the maximum length an IPv6 packet can have to be transmitted on the interface. If an IPv6 packet is longer than an MTU, the host that originated the packet fragments the packet and transmits its contents in multiple packets that are shorter than the configured MTU.
ICMP	The setting of the ICMP redirect parameter for the interface.
ND	The setting of the various neighbor discovery parameters for the interface.
Access List	The inbound and outbound access control lists applied to the interface.
Routing protocols	The routing protocols enabled on the interface.

Displaying IPv6 neighbor information

You can display the IPv6 neighbor table, which contains an entry for each IPv6 neighbor with which the router exchanges IPv6 packets.

To display the IPv6 neighbor table, enter the following command at any CLI level.

```
Brocade(config)#show ipv6 neighbor
Total number of Neighbor entries: 42
IPv6 Address                               LinkLayer-Addr State Age Port   vlan  IsR
2001:DB8:8::25                             6400.0dbb.b541 STALE 163 e 1/1/41 5 0
2001:DB8::b200:ddf:fe99:4ff5                b000.0d99.4ff5 STALE 162 e 1/1/41 5 0
2001:DB8:8::28                             0000.0d9b.4257 STALE 163 e 1/1/41 5 0
2001:DB8:8::2b                             c000.0d35.a8e1 STALE 163 e 1/1/41 5 0
2001:DB8::6600:ddf:febb:b541                6400.0dbb.b541 STALE 162 e 1/1/41 5
```

Syntax: `show ipv6 neighbor [<ipv6-prefix>/<prefix-length> | <ipv6-address> | <interface> [<stack-unit>/<slot>/<port>] | <number>]`

The `<ipv6-prefix>/<prefix-length>` parameters restrict the display to the entries for the specified IPv6 prefix. You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373. You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

The `<ipv6-address>` parameter restricts the display to the entries for the specified IPv6 address. You must specify this parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The `<interface>` parameter restricts the display to the entries for the specified router interface. For this parameter, you can specify the **Ethernet** or **VE** keywords. Specify the Ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1. If you specify a VE interface, also specify the VE number.

This display shows the following information.

TABLE 31 IPv6 neighbor information fields

Field	Description
Total number of neighbor entries	The total number of entries in the IPv6 neighbor table.
IPv6 Address	The 128-bit IPv6 address of the neighbor.
Link-Layer Address	The 48-bit interface ID of the neighbor.
State	<p>The current state of the neighbor. Possible states are as follows:</p> <ul style="list-style-type: none"> • INCOMPLETE – Address resolution of the entry is being performed. • *REACH – The static forward path to the neighbor is functioning properly. • REACH – The forward path to the neighbor is functioning properly. • STALE – This entry has remained unused for the maximum interval. While stale, no action takes place until a packet is sent. • DELAY – This entry has remained unused for the maximum interval, and a packet was sent before another interval elapsed. • PROBE – Neighbor solicitation are transmitted until a reachability confirmation is received.

TABLE 31 IPv6 neighbor information fields (Continued)

Field	Description
Age	The number of seconds the entry has remained unused. If this value remains unused for the number of seconds specified by the ipv6 nd reachable-time command (the default is 30 seconds), the entry is removed from the table.
Port	The physical port on which the entry was learned.
vlan	The VLAN on which the entry was learned.
IsR	Determines if the neighbor is a router or host: 0 – Indicates that the neighbor is a host. 1 – Indicates that the neighbor is a router.

Displaying the IPv6 route table

To display the IPv6 route table, enter the following command at any CLI level.

```
Brocade#show ipv6 route
IPv6 Routing Table - 58 entries:
Type Codes:  C - Connected, S - Static, R - RIP, O - OSPF, B - BGP
OSPF Sub Type Codes:  O - Intra, Oi - Inter, O1 - Type1 external, O2 - Type2 external
Type IPv6 Prefix                Next Hop Router                Interface  Dis/Metric
C  2001:DB8:9::/64                ::                             ve 1009    0/0
C  2001:DB8:a::/64                ::                             ve 1010    0/0
C  2001:DB8:b::/64                ::                             ve 1011    0/0
C  2001:DB8:c::/64                ::                             ve 1012    0/0
C  2001:DB8:d::/64                ::                             ve 1013    0/0
C  2001:DB8:e::/64                ::                             ve 1014    0/0
C  2001:DB8:f::/64                ::                             ve 1015    0/0
C  2001:DB8:10::/64              ::                             ve 1016    0/0
C  2001:DB8:11::/64              ::                             ve 1017    0/0
C  2001:DB8:12::/64              ::                             ve 1018    0/0
C  2001:DB8:13::/64              ::                             ve 1019    0/0
```

Syntax: `show ipv6 route [<ipv6-address> | <ipv6-prefix>/<prefix-length> | bgp | connect | ospf | rip | static | summary]`

The `<ipv6-address>` parameter restricts the display to the entries for the specified IPv6 address. You must specify the `<ipv6-address>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373.

The `<ipv6-prefix>/<prefix-length>` parameters restrict the display to the entries for the specified IPv6 prefix. You must specify the `<ipv6-prefix>` parameter in hexadecimal using 16-bit values between colons as documented in RFC 2373. You must specify the `<prefix-length>` parameter as a decimal value. A slash mark (/) must follow the `<ipv6-prefix>` parameter and precede the `<prefix-length>` parameter.

The **bgp** keyword restricts the display to entries for BGP4 routes.

The **connect** keyword restricts the display to entries for directly connected interface IPv6 routes.

The **ospf** keyword restricts the display to entries for OSPFv3 routes.

The **rip** keyword restricts the display to entries for RIPng routes.

The **static** keyword restricts the display to entries for static IPv6 routes.

The **summary** keyword displays a summary of the prefixes and different route types.

The following table lists the information displayed by the **show ipv6 route** command.

TABLE 32 IPv6 route table fields

Field	Description
Number of entries	The number of entries in the IPv6 route table.
Type	The route type, which can be one of the following: <ul style="list-style-type: none"> • C – The destination is directly connected to the router. • S – The route is a static route. • R – The route is learned from RIPv6. • O – The route is learned from OSPFv3. • B – The route is learned from BGP4.
IPv6 Prefix	The destination network of the route.
Next-Hop Router	The next-hop router.
Interface	The interface through which this router sends packets to reach the route's destination.
Dis/Metric	The route's administrative distance and metric value.

To display a summary of the IPv6 route table, enter the following command at any CLI level.

```
Brocade#show ipv6 route summary
IPv6 Routing Table - 7 entries:
  4 connected, 2 static, 0 RIP, 1 OSPF, 0 BGP
  Number of prefixes:
  /16: 1 /32: 1 /64: 3 /128: 2
```

The following table lists the information displayed by the **show ipv6 route summary** command.

TABLE 33 IPv6 route table summary fields

Field	Description
Number of entries	The number of entries in the IPv6 route table.
Number of route types	The number of entries for each route type.
Number of prefixes	A summary of prefixes in the IPv6 route table, sorted by prefix length.

Displaying local IPv6 routers

The Brocade device can function as an IPv6 host, instead of an IPv6 router, if you configure IPv6 addresses on its interfaces but do not enable IPv6 routing using the **ipv6 unicast-routing** command.

From the IPv6 host, you can display information about IPv6 routers to which the host is connected. The host learns about the routers through their router advertisement messages. To display information about the IPv6 routers connected to an IPv6 host, enter the following command at any CLI level.

```
Brocade#show ipv6 router
Router 2001:DB8::2e0:80ff:fe46:3431 on Ethernet 50, last update 0 min
Hops 64, Lifetime 1800 sec
Reachable time 0 msec, Retransmit time 0 msec
```

Syntax: show ipv6 router

If you configure your Brocade device to function as an IPv6 router (you configure IPv6 addresses on its interfaces and enable IPv6 routing using the **ipv6 unicast-routing** command) and you enter the **show ipv6 router** command, you will receive the following output.

```
No IPv6 router in table
```

Meaningful output for this command is generated for Brocade devices configured to function as IPv6 hosts only.

This display shows the following information.

TABLE 34 IPv6 local router information fields

Field	Description
Router <ipv6 address> on <interface> <port>	The IPv6 address for a particular router interface.
Last update	The amount of elapsed time (in minutes) between the current and previous updates received from a router.
Hops	The default value that should be included in the Hop Count field of the IPv6 header for outgoing IPv6 packets. The hops value applies to the router for which you are displaying information and should be followed by IPv6 hosts attached to the router. A value of 0 indicates that the router leaves this field unspecified.
Lifetime	The amount of time (in seconds) that the router is useful as the default router.
Reachable time	The amount of time (in milliseconds) that a router assumes a neighbor is reachable after receiving a reachability confirmation. The reachable time value applies to the router for which you are displaying information and should be followed by IPv6 hosts attached to the router. A value of 0 indicates that the router leaves this field unspecified.
Retransmit time	The amount of time (in milliseconds) between retransmissions of neighbor solicitation messages. The retransmit time value applies to the router for which you are displaying information and should be followed by IPv6 hosts attached to the router. A value of 0 indicates that the router leaves this field unspecified.

Displaying IPv6 TCP information

You can display the following IPv6 TCP information:

- General information about each TCP connection on the router, including the percentage of free memory for each of the internal TCP buffers.
- Detailed information about a specified TCP connection.

To display general information about each TCP connection on the router, enter the following command at any CLI level.

5 Displaying global IPv6 information

```
Brocade#show ipv6 tcp connections
Local IP address:port <-> Remote IP address:port TCP state
192.168.182.110:23 <-> 192.168.8.186:4933 ESTABLISHED
192.168.182.110:8218 <-> 192.168.182.106:179 ESTABLISHED
192.168.182.110:8039 <-> 192.168.2.119:179 SYN-SENT
192.168.182.110:8159 <-> 192.168.2.102:179 SYN-SENT
2001:DB8::110:179 <-> 2001:DB8::106:8222 ESTABLISHED (1440)
Total 5 TCP connections

TCP MEMORY USAGE PERCENTAGE
FREE TCP = 98 percent
FREE TCP QUEUE BUFFER = 99 percent
FREE TCP SEND BUFFER = 97 percent
FREE TCP RECEIVE BUFFER = 100 percent
FREE TCP OUT OF SEQUENCE BUFFER = 100 percent
```

Syntax: show ipv6 tcp connections

This display shows the following information.

TABLE 35 General IPv6 TCP connection fields

Field	Description
Local IP address:port	The IPv4 or IPv6 address and port number of the local router interface over which the TCP connection occurs.
Remote IP address:port	The IPv4 or IPv6 address and port number of the remote router interface over which the TCP connection occurs.
TCP state	<p>The state of the TCP connection. Possible states include the following:</p> <ul style="list-style-type: none">• LISTEN – Waiting for a connection request.• SYN-SENT – Waiting for a matching connection request after having sent a connection request.• SYN-RECEIVED – Waiting for a confirming connection request acknowledgment after having both received and sent a connection request.• ESTABLISHED – Data can be sent and received over the connection. This is the normal operational state of the connection.• FIN-WAIT-1 – Waiting for a connection termination request from the remote TCP, or an acknowledgment of the connection termination request previously sent.• FIN-WAIT-2 – Waiting for a connection termination request from the remote TCP.• CLOSE-WAIT – Waiting for a connection termination request from the local user.• CLOSING – Waiting for a connection termination request acknowledgment from the remote TCP.• LAST-ACK – Waiting for an acknowledgment of the connection termination request previously sent to the remote TCP (which includes an acknowledgment of its connection termination request).• TIME-WAIT – Waiting for enough time to pass to be sure the remote TCP received the acknowledgment of its connection termination request.• CLOSED – There is no connection state.
FREE TCP = <percentage>	The percentage of free TCP control block (TCP) space.

TABLE 35 General IPv6 TCP connection fields (Continued)

Field	Description
FREE TCP QUEUE BUFFER = <percentage>	The percentage of free TCP queue buffer space.
FREE TCP SEND BUFFER = <percentage>	The percentage of free TCP send buffer space.
FREE TCP RECEIVE BUFFER = <percentage>	The percentage of free TCP receive buffer space.
FREE TCP OUT OF SEQUENCE BUFFER = <percentage>	The percentage of free TCP out of sequence buffer space.

To display detailed information about a specified TCP connection, enter a command such as the following at any CLI level.

```
Brocade#show ipv6 tcp status 2001:DB8::110 179 2000:4::106 8222
TCP: TCP = 0x217fc300
TCP: 2000:4::110:179 <-> 2000:4::106:8222: state: ESTABLISHED Port: 1
  Send: initial sequence number = 242365900
  Send: first unacknowledged sequence number = 242434080
  Send: current send pointer = 242434080
  Send: next sequence number to send = 242434080
  Send: remote received window = 16384
  Send: total unacknowledged sequence number = 0
  Send: total used buffers 0
  Receive: initial incoming sequence number = 740437769
  Receive: expected incoming sequence number = 740507227
  Receive: received window = 16384
  Receive: bytes in receive queue = 0
  Receive: congestion window = 1459
```

Syntax: `show ipv6 tcp status <local-ip-address> <local-port-number> <remote-ip-address> <remote-port-number>`

The <local-ip-address> parameter can be the IPv4 or IPv6 address of the local interface over which the TCP connection is taking place.

The <local-port-number> parameter is the local port number over which a TCP connection is taking place.

The <remote-ip-address> parameter can be the IPv4 or IPv6 address of the remote interface over which the TCP connection is taking place.

The <remote-port-number> parameter is the local port number over which a TCP connection is taking place.

This display shows the following information.

TABLE 36 Specific IPv6 TCP connection fields

Field	Description
TCP = <i><location></i>	The location of the TCP.
<i><local-ip-address> <local-port-number> <remote-ip-address> <remote-port-number> <state> <port></i>	This field provides a general summary of the following: <ul style="list-style-type: none"> • The local IPv4 or IPv6 address and port number. • The remote IPv4 or IPv6 address and port number. • The state of the TCP connection. For information on possible states, refer to Table 35 on page 148. • The port numbers of the local interface.
Send: initial sequence number = <i><number></i>	The initial sequence number sent by the local router.
Send: first unacknowledged sequence number = <i><number></i>	The first unacknowledged sequence number sent by the local router.
Send: current send pointer = <i><number></i>	The current send pointer.
Send: next sequence number to send = <i><number></i>	The next sequence number sent by the local router.
Send: remote received window = <i><number></i>	The size of the remote received window.
Send: total unacknowledged sequence number = <i><number></i>	The total number of unacknowledged sequence numbers sent by the local router.
Send: total used buffers <i><number></i>	The total number of buffers used by the local router in setting up the TCP connection.
Receive: initial incoming sequence number = <i><number></i>	The initial incoming sequence number received by the local router.
Receive: expected incoming sequence number = <i><number></i>	The incoming sequence number expected by the local router.
Receive: received window = <i><number></i>	The size of the local router's receive window.
Receive: bytes in receive queue = <i><number></i>	The number of bytes in the local router's receive queue.
Receive: congestion window = <i><number></i>	The size of the local router's receive congestion window.

Displaying IPv6 traffic statistics

To display IPv6 traffic statistics, enter the following command at any CLI level.

```
Brocade#show ipv6 traffic
IP6 Statistics
  36947 received, 66818 sent, 0 forwarded, 36867 delivered, 0 rawout
  0 bad vers, 23 bad scope, 0 bad options, 0 too many hdr
  0 no route, 0 can not forward, 0 redirect sent
  0 frag recv, 0 frag dropped, 0 frag timeout, 0 frag overflow
  0 reassembled, 0 fragmented, 0 ofragments, 0 can not frag
  0 too short, 0 too small, 11 not member
  0 no buffer, 66819 allocated, 21769 freed
  0 forward cache hit, 46 forward cache miss

ICMP6 Statistics
Received:
  0 dest unreachable, 0 pkt too big, 0 time exceeded, 0 param prob
  2 echo req, 1 echo reply, 0 mem query, 0 mem report, 0 mem red
  0 router soli, 2393 router adv, 106 nei soli, 3700 nei adv, 0 redirect
  0 bad code, 0 too short, 0 bad checksum, 0 bad len
  0 reflect, 0 nd toomany opt, 0 badhopcount
Sent:
  0 dest unreachable, 0 pkt too big, 0 time exceeded, 0 param prob
  1 echo req, 2 echo reply, 0 mem query, 0 mem report, 0 mem red
  0 router soli, 2423 router adv, 3754 nei soli, 102 nei adv, 0 redirect
  0 error, 0 can not send error, 0 too freq
Sent Errors:
  0 unreachable no route, 0 admin, 0 beyond scope, 0 address, 0 no port
  0 pkt too big, 0 time exceed transit, 0 time exceed reassembly
  0 param problem header, 0 nexthheader, 0 option, 0 redirect, 0 unknown

UDP Statistics
  470 received, 7851 sent, 6 no port, 0 input errors

TCP Statistics
  57913 active opens, 0 passive opens, 57882 failed attempts
  159 active resets, 0 passive resets, 0 input errors
  565189 in segments, 618152 out segments, 171337 retransmission
```

Syntax: show ipv6 traffic

This **show ipv6 traffic** command displays the following information.

Field	Description
IPv6 statistics	
received	The total number of IPv6 packets received by the router.
sent	The total number of IPv6 packets originated and sent by the router.
forwarded	The total number of IPv6 packets received by the router and forwarded to other routers.
delivered	The total number of IPv6 packets delivered to the upper layer protocol.
rawout	This information is used by Brocade Technical Support.

5 Displaying global IPv6 information

Field	Description (Continued)
bad vers	The number of IPv6 packets dropped by the router because the version number is not 6.
bad scope	The number of IPv6 packets dropped by the router because of a bad address scope.
bad options	The number of IPv6 packets dropped by the router because of bad options.
too many hdr	The number of IPv6 packets dropped by the router because the packets had too many headers.
no route	The number of IPv6 packets dropped by the router because there was no route.
can not forward	The number of IPv6 packets the router could not forward to another router.
redirect sent	This information is used by Brocade Technical Support.
frag rcv	The number of fragments received by the router.
frag dropped	The number of fragments dropped by the router.
frag timeout	The number of fragment timeouts that occurred.
frag overflow	The number of fragment overflows that occurred.
reassembled	The number of fragmented IPv6 packets that the router reassembled.
fragmented	The number of IPv6 packets fragmented by the router to accommodate the MTU of this router or of another device.
ofragments	The number of output fragments generated by the router.
can not frag	The number of IPv6 packets the router could not fragment.
too short	The number of IPv6 packets dropped because they are too short.
too small	The number of IPv6 packets dropped because they do not have enough data.
not member	The number of IPv6 packets dropped because the recipient is not a member of a multicast group.
no buffer	The number of IPv6 packets dropped because there is no buffer available.
forward cache miss	The number of IPv6 packets received for which there is no corresponding cache entry.
ICMP6 statistics	
Some ICMP statistics apply to both Received and Sent, some apply to Received only, some apply to Sent only, and some apply to Sent Errors only.	
Applies to received and sent	
dest unreachable	The number of Destination Unreachable messages sent or received by the router.
pkt too big	The number of Packet Too Big messages sent or received by the router.
time exceeded	The number of Time Exceeded messages sent or received by the router.
param prob	The number of Parameter Problem messages sent or received by the router.
echo req	The number of Echo Request messages sent or received by the router.
echo reply	The number of Echo Reply messages sent or received by the router.
mem query	The number of Group Membership Query messages sent or received by the router.
mem report	The number of Membership Report messages sent or received by the router.

Field	Description (Continued)
mem red	The number of Membership Reduction messages sent or received by the router.
router soli	The number of Router Solicitation messages sent or received by the router.
router adv	The number of Router Advertisement messages sent or received by the router.
nei soli	The number of Neighbor Solicitation messages sent or received by the router.
nei adv	The number of Router Advertisement messages sent or received by the router.
redirect	The number of redirect messages sent or received by the router.
Applies to received only	
bad code	The number of Bad Code messages received by the router.
too short	The number of Too Short messages received by the router.
bad checksum	The number of Bad Checksum messages received by the router.
bad len	The number of Bad Length messages received by the router.
nd toomany opt	The number of Neighbor Discovery Too Many Options messages received by the router.
badhopcount	The number of Bad Hop Count messages received by the router.
Applies to sent only	
error	The number of Error messages sent by the router.
can not send error	The number of times the node encountered errors in ICMP error messages.
too freq	The number of times the node has exceeded the frequency of sending error messages.
Applies to sent errors only	
unreach no route	The number of Unreachable No Route errors sent by the router.
admin	The number of Admin errors sent by the router.
beyond scope	The number of Beyond Scope errors sent by the router.
address	The number of Address errors sent by the router.
no port	The number of No Port errors sent by the router.
pkt too big	The number of Packet Too Big errors sent by the router.
time exceed transit	The number of Time Exceed Transit errors sent by the router.
time exceed reassembly	The number of Time Exceed Reassembly errors sent by the router.
param problem header	The number of Parameter Problem Header errors sent by the router.
nextheader	The number of Next Header errors sent by the router.
option	The number of Option errors sent by the router.
redirect	The number of Redirect errors sent by the router.
unknown	The number of Unknown errors sent by the router.
UDP statistics	
received	The number of UDP packets received by the router.
sent	The number of UDP packets sent by the router.
no port	The number of UDP packets dropped because the packet did not contain a valid UDP port number.

5 Displaying global IPv6 information

Field	Description (Continued)
input errors	This information is used by Brocade Technical Support.
TCP statistics	
active opens	The number of TCP connections opened by the router by sending a TCP SYN to another device.
passive opens	The number of TCP connections opened by the router in response to connection requests (TCP SYNs) received from other devices.
failed attempts	This information is used by Brocade Technical Support.
active resets	The number of TCP connections the router reset by sending a TCP RESET message to the device at the other end of the connection.
passive resets	The number of TCP connections the router reset because the device at the other end of the connection sent a TCP RESET message.
input errors	This information is used by Brocade Technical Support.
in segments	The number of TCP segments received by the router.
out segments	The number of TCP segments sent by the router.
retransmission	The number of segments that the router retransmitted because the retransmission timer for the segment had expired before the device at the other end of the connection had acknowledged receipt of the segment.

SNMP Access

In this chapter

- [SNMP overview](#) 155
- [SNMP community strings](#) 156
- [User-based security model](#) 159
- [Defining SNMP views](#) 163
- [SNMP version 3 traps](#) 164
- [Displaying SNMP Information](#) 167
- [SNMP v3 configuration examples](#) 169

[Table 37](#) lists individual Brocade ICX 6650 switches and the SNMP access methods they support. These features are supported in full Layer 3 software images, except where explicitly noted.

TABLE 37 Supported SNMP access features

Feature	Brocade ICX 6650
SNMP v1, v2, v3	Yes
Community strings	Yes
User-based security model for SNMP v3	Yes
SNMP v3 traps	Yes
Defining the UDP port for SNMP v3 traps	Yes
SNMP v3 over IPv6	Yes
AES encryption for SNMP v3	Yes

SNMP overview

SNMP is a set of protocols for managing complex networks. SNMP sends messages, called protocol data units (PDUs), to different parts of a network. SNMP-compliant devices, called agents, store data about themselves in Management Information Bases (MIBs) and return this data to the SNMP requesters.

The Brocade ICX 6650 Switch Security Configuration Guide introduces a few methods used to secure SNMP access. This chapter presents additional methods for securing SNMP access to Brocade devices. It contains the following sections:

- [“SNMP community strings”](#)
- [“User-based security model”](#)
- [“SNMP v3 configuration examples”](#)

- [“SNMP version 3 traps”](#)
- [“Displaying SNMP Information”](#)
- [“SNMP v3 configuration examples”](#)

Restricting SNMP access using ACL, VLAN, or a specific IP address constitute the first level of defense when the packet arrives at a Brocade device. The next level uses one of the following methods:

- Community string match In SNMP versions 1 and 2
- User-based model in SNMP version 3

SNMP views are incorporated in community strings and the user-based model.

SNMP community strings

SNMP versions 1 and 2 use community strings to restrict SNMP access. You can configure as many additional read-only and read-write community strings as you need. The number of strings you can configure depends on the memory on the device. There is no practical limit.

NOTE

If you delete the startup-config file, the device automatically re-adds the default “public” read-only community string the next time you load the software.

Encryption of SNMP community strings

The software automatically encrypts SNMP community strings. Users with read-only access or who do not have access to management functions in the CLI cannot display the strings.

Encryption is enabled by default. You can disable encryption for individual strings or trap receivers if desired. Refer to the next section for information about encryption.

Adding an SNMP community string

The default SNMP community name (string) on a device is “public” with read only privilege.

You can assign other SNMP community strings, and indicate if the string is encrypted or clear. By default, the string is encrypted.

To add an encrypted community string, enter commands such as the following.

```
Brocade(config)#snmp-server community private rw
Brocade(config)#write memory
```

Syntax: `snmp-server community [0 | 1] <string>
ro | rw [view <viewname>] [<standard-ACL-name> | <standard-ACL-id>]`

The `<string>` parameter specifies the community string name. The string can be up to 32 characters long.

The `ro` | `rw` parameter specifies whether the string is **read-only (ro)** or **read-write (rw)**.

NOTE

If you issue a **no snmp-server community public ro** command and then enter a **write memory** command to save that configuration, the “public” community name is removed and will have no SNMP access. If for some reason the device is brought down and then brought up, the “no snmp-server community public ro” command is restored in the system and the “public” community string has no SNMP access.

The **0 | 1** parameter affects encryption for display of the string in the running-config and the startup-config file. Encryption is enabled by default. When encryption is enabled, the community string is encrypted in the CLI regardless of the access level you are using.

The encryption option can be omitted (the default) or can be one of the following:

- **0** – Disables encryption for the community string you specify with the command. The community string is shown as clear text in the running-config and the startup-config file. Use this option if you do not want the display of the community string to be encrypted.
- **1** – Assumes that the community string you enter is encrypted, and decrypts the value before using it.

NOTE

If you want the software to assume that the value you enter is the clear-text form, and to encrypt display of that form, do not enter **0** or **1**. Instead, omit the encryption option and allow the software to use the default behavior.

NOTE

If you specify encryption option **1**, the software assumes that you are entering the encrypted form of the community string. In this case, the software decrypts the community string you enter before using the value for authentication. If you accidentally enter option **1** followed by the clear-text version of the community string, authentication will fail because the value used by the software will not match the value you intended to use.

Configuring `snmp-server community private rw` adds the read-write SNMP community string “private”. When you save the new community string to the startup-config file (using the **write memory** command), the software adds the following command to the file.

```
snmp-server community 1 <encrypted-string> rw
```

To add a non-encrypted community string, you must explicitly specify that you do not want the software to encrypt the string. Here is an example.

```
Brocade(config)#snmp-server community 0 private rw
Brocade(config)#write memory
```

The command in this example adds the string “private” in the clear, which means the string is displayed in the clear. When you save the new community string to the startup-config file, the software adds the following command to the file.

```
snmp-server community 0 private rw
```

The **view <viewname>** parameter is optional. It allows you to associate a view to the members of this community string. Enter up to 32 alphanumeric characters. If no view is specified, access to the full MIB is granted. The view that you want must exist before you can associate it to a community string. Here is an example of how to use the view parameter in the community string command.

```
Brocade(config)#snmp-s community myread ro view sysview
```

The command in this example associates the view “sysview” to the community string named “myread”. The community string has read-only access to “sysview”. For information on how to create views, refer to [“SNMP v3 configuration examples”](#) on page 169.

The `<standard-ACL-name> | <standard-ACL-id>` parameter is optional. It allows you to specify which ACL group will be used to filter incoming SNMP packets. You can enter either the ACL name or its ID. Here are some examples.

```
Brocade(config)#snmp-s community myread ro view sysview 2
Brocade(config)#snmp-s community myread ro view sysview myACL
```

The command in the first example indicates that ACL group 2 will filter incoming SNMP packets; whereas, the command in the second example uses the ACL group called “myACL” to filter incoming packets. Refer to the Brocade ICX 6650 Switch Security Configuration Guide for more information.

NOTE

To make configuration changes, including changes involving SNMP community strings, you must first configure a read-write community string using the CLI. Alternatively, you must configure another authentication method and log on to the CLI using a valid password for that method.

Displaying the SNMP community strings

To display the configured community strings, enter the following command at any CLI level.

```
Brocade#show snmp server
Contact: Marshall
Location: Copy Center
Community(ro): public
Community(rw): private
Traps
    Cold start: Enable
    Link up: Enable
    Link down: Enable
    Authentication: Enable
    Locked address violation: Enable
    Power supply failure: Enable
    Fan failure: Enable
    Temperature warning: Enable
    STP new root: Enable
    STP topology change: Enable
    ospf: Enable

Total Trap-Receiver Entries: 4
Trap-Receiver IP Address      Community
1          192.95.6.211
2          192.95.5.21
```

Syntax: show snmp server

NOTE

If display of the strings is encrypted, the strings are not displayed. Encryption is enabled by default.

User-based security model

SNMP version 3 (RFC 2570 through 2575) introduces a User-Based Security model (RFC 2574) for authentication and privacy services.

SNMP version 1 and version 2 use community strings to authenticate SNMP access to management modules. This method can still be used for authentication. In SNMP version 3, the User-Based Security model of SNMP can be used to secure against the following threats:

- Modification of information
- Masquerading the identity of an authorized entity
- Message stream modification
- Disclosure of information

SNMP version 3 also supports View-Based Access Control Mechanism (RFC 2575) to control access at the PDU level. It defines mechanisms for determining whether or not access to a managed object in a local MIB by a remote principal should be allowed. (refer to [“SNMP v3 configuration examples”](#) on page 169.)

Configuring your NMS

In order to use the SNMP version 3 features.

1. Make sure that your Network Manager System (NMS) supports SNMP version 3.
2. Configure your NMS agent with the necessary users.
3. Configure the SNMP version 3 features in Brocade ICX 6650 devices.

Configuring SNMP version 3 on Brocade ICX 6650 devices

Follow the steps given below to configure SNMP version 3 on Brocade devices.

1. Enter an engine ID for the management module using the **snmp-server engineid** command if you will not use the default engine ID. Refer to [“Defining the engine id”](#) on page 159.
2. Create views that will be assigned to SNMP user groups using the **snmp-server view** command. refer to [“SNMP v3 configuration examples”](#) on page 169 for details.
3. Create ACL groups that will be assigned to SNMP user groups using the **access-list** command.
4. Create user groups using the **snmp-server group** command. Refer to [“Defining an SNMP group”](#) on page 160.
5. Create user accounts and associate these accounts to user groups using the **snmp-server user** command. Refer to [“Defining an SNMP user account”](#) on page 161.

If SNMP version 3 is not configured, then community strings by default are used to authenticate access.

Defining the engine id

A default engine ID is generated during system start up. To determine what the default engine ID of the device is, enter the **show snmp engineid** command and find the following line:

```
Local SNMP Engine ID: 800007c70300e05290ab60
```

See the section “[Displaying the Engine ID](#)” on page 167 for details.

The default engine ID guarantees the uniqueness of the engine ID for SNMP version 3. If you want to change the default engine ID, enter the **snmp-server engineid local** command.

```
Brocade(config)#snmp-server engineid local 800007c70300e05290ab60
```

Syntax: [no] **snmp-server engineid local** <hex-string>

The **local** parameter indicates that engine ID to be entered is the ID of this device, representing an SNMP management entity.

NOTE

Each user localized key depends on the SNMP server engine ID, so all users need to be reconfigured whenever the SNMP server engine ID changes.

NOTE

Since the current implementation of SNMP version 3 does not support Notification, remote engine IDs cannot be configured at this time.

The <hex-string> variable consists of 11 octets, entered as hexadecimal values. There are two hexadecimal characters in each octet. There should be an even number of hexadecimal characters in an engine ID.

The default engine ID has a maximum of 11 octets:

- Octets 1 through 4 represent the agent's SNMP management private enterprise number as assigned by the Internet Assigned Numbers Authority (IANA). The most significant bit of Octet 1 is "1". For example, "000007c7" is the ID for Brocade Communications, Inc. in hexadecimal. With Octet 1 always equal to "1", the first four octets in the default engine ID is always "800007c7" (which is 1991 in decimal).
- Octet 5 is always 03 in hexadecimal and indicates that the next set of values represent a MAC address.
- Octets 6 through 11 form the MAC address of the lowest port in the management module.

NOTE

Engine ID must be a unique number among the various SNMP engines in the management domain. Using the default engine ID ensures the uniqueness of the numbers.

Defining an SNMP group

SNMP groups map SNMP users to SNMP views. For each SNMP group, you can configure a read view, a write view, or both. Users who are mapped to a group will use its views for access control.

To configure an SNMP user group, enter a command such as the following.

```
Brocade(config)#snmp-server group admin v3 auth read all write all
```

Syntax: [no] **snmp-server group** <groupname> **v1 | v2 | v3** **auth | noauth | priv** [**access** <standard-ACL-id>] [**read** <viewstring> | **write** <viewstring>]

NOTE

This command is not used for SNMP version 1 and SNMP version 2. In these versions, groups and group views are created internally using community strings. (refer to “[SNMP community strings](#)” on page 156.) When a community string is created, two groups are created, based on the community string name. One group is for SNMP version 1 packets, while the other is for SNMP version 2 packets.

The **group** <groupname> parameter defines the name of the SNMP group to be created.

The **v1**, **v2**, or **v3** parameter indicates which version of SNMP is used. In most cases, you will be using v3, since groups are automatically created in SNMP versions 1 and 2 from community strings.

The **auth** | **noauth** parameter determines whether or not authentication will be required to access the supported views. If auth is selected, then only authenticated packets are allowed to access the view specified for the user group. Selecting **noauth** means that no authentication is required to access the specified view. Selecting **priv** means that an authentication password will be required from the users.

The **access** <standard-ACL-id> parameter is optional. It allows incoming SNMP packets to be filtered based on the standard ACL attached to the group.

The **read** <viewstring> | **write** <viewstring> parameter is optional. It indicates that users who belong to this group have either read or write access to the MIB.

The <viewstring> variable is the name of the view to which the SNMP group members have access. If no view is specified, then the group has no access to the MIB.

The value of <viewstring> is defined using the **snmp-server view** command. The SNMP agent comes with the "all" default view, which provides access to the entire MIB; however, it must be specified when creating the group. The "all" view also allows SNMP version 3 to be backwards compatible with SNMP version 1 and version 2.

NOTE

If you will be using a view other than the "all" view, that view must be configured before creating the user group. Refer to the section “[SNMP v3 configuration examples](#)” on page 169, especially for details on the include | exclude parameters.

Defining an SNMP user account

The **snmp-server user** command does the following:

- Creates an SNMP user.
- Defines the group to which the user will be associated.
- Defines the type of authentication to be used for SNMP access by this user.
- Specifies one of the following encryption types used to encrypt the privacy password:
 - Data Encryption Standard (DES) – A symmetric-key algorithm that uses a 56-bit key.
 - Advanced Encryption Standard (AES) – The 128-bit encryption standard adopted by the U.S. government. This standard is a symmetric cipher algorithm chosen by the National Institute of Standards and Technology (NIST) as the replacement for DES.

Here is an example of how to create an SNMP User account.

```
Brocade(config)#snmp-s user bob admin v3 access 2 auth md5 bobmd5 priv des bobdes
```

The CLI for creating SNMP version 3 users has been updated as follows.

Syntax: `[no] snmp-server user <name> <groupname> v3`
`[[access <standard-ACL-id>]`
`[[encrypted] [auth md5 <md5-password> | sha <sha-password>]`
`[priv [encrypted] des <des-password-key> | aes <aes-password-key>]]]`

The `<name>` parameter defines the SNMP user name or security name used to access the management module.

The `<groupname>` parameter identifies the SNMP group to which this user is associated or mapped. All users must be mapped to an SNMP group. Groups are defined using the **snmp-server group** command.

NOTE

The SNMP group to which the user account will be mapped should be configured before creating the user accounts; otherwise, the group will be created without any views. Also, ACL groups must be configured before configuring user accounts.

The **v3** parameter is required.

The **access** `<standard-ACL-id>` parameter is optional. It indicates that incoming SNMP packets are filtered based on the ACL attached to the user account.

NOTE

The ACL specified in a user account overrides the ACL assigned to the group to which the user is mapped. If no ACL is entered for the user account, then the ACL configured for the group will be used to filter packets.

The **encrypted** parameter means that the MD5 or SHA password will be a digest value. MD5 has 16 octets in the digest. SHA has 20. The digest string has to be entered as a hexadecimal string. In this case, the agent need not generate any explicit digest. If the **encrypted** parameter is not used, the user is expected to enter the authentication password string for MD5 or SHA. The agent will convert the password string to a digest, as described in RFC 2574.

The **auth md5 | sha** parameter is optional. It defines the type of encryption that the user must have to be authenticated. Choose between MD5 or SHA encryption. MD5 and SHA are two authentication protocols used in SNMP version 3.

The `<md5-password>` and `<sha-password>` define the password the user must use to be authenticated. These password must have a minimum of 8 characters. If the encrypted parameter is used, then the digest has 16 octets for MD5 or 20 octets for SHA.

NOTE

Once a password string is entered, the generated configuration displays the digest (for security reasons), not the actual password.

The **priv [encrypted]** parameter is optional after you enter the md5 or sha password. The **priv** parameter specifies the encryption type (DES or AES) used to encrypt the privacy password. If the **encrypted** keyword is used, do the following:

- If DES is the privacy protocol to be used, enter **des** followed by a 16-octet DES key in hexadecimal format for the `<des-password-key>`. If you include the encrypted keyword, enter a password string of at least 8 characters.

- If AES is the privacy protocol to be used, enter **aes** followed by the AES password key. For a small password key, enter 12 characters. For a big password key, enter 16 characters. If you include the encrypted keyword, enter a password string containing 32 hexadecimal characters.

Defining SNMP views

SNMP views are named groups of MIB objects that can be associated with user accounts to allow limited access for viewing and modification of SNMP statistics and system configuration. SNMP views can also be used with other commands that take SNMP views as an argument. SNMP views reference MIB objects using object names, numbers, wildcards, or a combination of the three. The numbers represent the hierarchical location of the object in the MIB tree. You can reference individual objects in the MIB tree or a subset of objects from the MIB tree.

To configure the number of SNMP views available on the Brocade device, enter the following command.

```
Brocade(config)#system-max view 15
```

Syntax: **system-max view** <number-of-views>

This command specifies the maximum number of SNMPv2 and v3 views that can be configured on a device. The number of views can be from 10 – 65536. The default is 10 views.

To add an SNMP view, enter one of the following commands.

```
Brocade(config)#snmp-server view Maynes system included
Brocade(config)#snmp-server view Maynes system.2 excluded
Brocade(config)#snmp-server view Maynes 2.3.*.6 included
Brocade(config)#write mem
```

NOTE

The **snmp-server view** command supports the MIB objects as defined in RFC 1445.

Syntax: [no] **snmp-server view** <name> <mib_tree> **included** | **excluded**

The <name> parameter can be any alphanumeric name you choose to identify the view. The names cannot contain spaces.

The <mib_tree> parameter is the name of the MIB object or family. MIB objects and MIB sub-trees can be identified by a name or by the numbers called Object Identifiers (OIDs) that represent the position of the object or sub-tree in the MIB hierarchy. You can use a wildcard (*) in the numbers to specify a sub-tree family.

The **included** | **excluded** parameter specifies whether the MIB objects identified by the <mib_family> parameter are included in the view or excluded from the view.

NOTE

All MIB objects are automatically excluded from any view unless they are explicitly included; therefore, when creating views using the **snmp-server view** command, indicate which portion of the MIB you want users to access.

For example, you may want to assign the view called “admin” a community string or user group. The “admin” view will allow access to the Brocade MIBs objects that begin with the 1.3.6.1.4.1.1991 object identifier. Enter the following command.

```
Brocade(config)#snmp-server view admin 1.3.6.1.4.1.1991 included
```

You can exclude portions of the MIB within an inclusion scope. For example, if you want to exclude the snAgentSys objects, which begin with 1.3.6.1.4.1.1991.1.1.2 object identifier from the admin view, enter a second command such as the following.

```
Brocade(config)#snmp-server view admin 1.3.6.1.4.1.1991.1.1.2 excluded
```

NOTE

Note that the exclusion is within the scope of the inclusion.

To delete a view, use the no parameter before the command.

SNMP version 3 traps

Brocade devices support SNMP notifications in SMIPv2 format. This allows notifications to be encrypted and sent to the target hosts in a secure manner.

Defining an SNMP group and specifying which view is notified of traps

The SNMP group command allows configuration of a viewname for notification purpose, similar to the read and write view. The default viewname is "all", which allows access to the entire MIB.

To configure an SNMP user group, first configure SNMP v3 views using the **snmp-server view** command. Refer to [“SNMP v3 configuration examples”](#) on page 169. Then enter a command such as the following.

```
Brocade(config)#snmp-server group admin v3 auth read all write all
notify all
```

Syntax: [no] snmp-server group <groupname>
 v1 | v2 | v3
 auth | noauth | priv
 [access <standard-ACL-id>] [read <viewstring> | write <viewstring> | notify <viewstring>]

The **group** <groupname> parameter defines the name of the SNMP group to be created.

The **v1**, **v2**, or **v3** parameter indicates which version of SNMP to use. In most cases, you will use v3, since groups are automatically created in SNMP versions 1 and 2 from community strings.

The **auth** | **noauth** parameter determines whether or not authentication will be required to access the supported views. If auth is selected, then only authenticated packets are allowed to access the view specified for the user group. Selecting **noauth** means that no authentication is required to access the specified view. Selecting **priv** means that an authentication password will be required from the users.

The **access** <standard-ACL-id> parameter is optional. It allows incoming SNMP packets to be filtered based on the standard ACL attached to the group.

The **read** <viewstring> | **write** <viewstring> parameter is optional. It indicates that users who belong to this group have either read or write access to the MIB.

The **notify** view allows administrators to restrict the scope of varbind objects that will be part of the notification. All of the varbinds need to be in the included view for the notification to be created.

The *<viewstring>* variable is the name of the view to which the SNMP group members have access. If no view is specified, then the group has no access to the MIB.

Defining the UDP port for SNMP v3 traps

The SNMP host command enhancements allow configuration of notifications in SMIv2 format, with or without encryption, in addition to the previously supported SMIv1 trap format.

You can define a port that receives the SNMP v3 traps by entering a command such as the following.

```
Brocade(config)#snmp-server host 192.168.4.11 version v3 auth security-name port 4/1
```

Syntax: [no] snmp-server host *<ip-addr>* | *<ipv6-addr>* version [v1 | v2c *<community-string>* | v3 auth | noauth | priv *<security-name>*] [port *<trap-UDP-port-number>*]

The *<ip-addr>* parameter specifies the IP address of the host that will receive the trap.

For **version**, indicate one of the following

For SNMP version 1, enter **v1** and the name of the community string (*<community-string>*). This string is encrypted within the system.

NOTE

If the configured version is v2c, then the notification is sent out in SMIv2 format, using the community string, but in cleartext mode. To send the SMIv2 notification in SNMPv3 packet format, configure v3 with auth or privacy parameters, or both, by specifying a security name. The actual authorization and privacy values are obtained from the security name.

For SNMP version 2c, enter **v2** and the name of the community string. This string is encrypted within the system.

For SNMP version 3, enter one of the following depending on the authorization required for the host:

- **v3 auth** *<security-name>*: Allow only authenticated packets.
- **v3 no auth** *<security-name>*: Allow all packets.
- **v3 priv** *<security-name>*: A password is required

For **port** *<trap-UDP-port-number>*, specify the UDP port number on the host that will receive the trap.

Trap MIB changes

To support the SNMP V3 trap feature, the Brocade Enterprise Trap MIB was rewritten in SMIv2 format, as follows:

- The MIB name was changed from FOUNDRY-SN-TRAP-MIB to FOUNDRY-SN-NOTIFICATION-MIB
- Individual notifications were changed to NOTIFICATION-TYPE instead of TRAP-TYPE.
- As per the SMIv2 format, each notification has an OID associated with it. The root node of the notification is snTraps (OID enterprise.foundry.0). For example, OID for snTrapRunningConfigChanged is {snTraps.73}. Earlier, each trap had a trap ID associated with it, as per the SMIv1 format.

Backward compatibility with SMIv1 trap format

The Brocade device will continue to support creation of traps in SMIv1 format, as before. To allow the device to send notifications in SMIv2 format, configure the device as described above. The default mode is still the original SMIv1 format.

Specifying an IPv6 host as an SNMP trap receiver

You can specify an IPv6 host as a trap receiver to ensure that all SNMP traps sent by the device will go to the same SNMP trap receiver or set of receivers, typically one or more host devices on the network. To do so, enter a command such as the following.

```
Brocade(config)#snmp-server host ipv6 2001:DB8:89::13
```

Syntax: `snmp-server host ipv6 <ipv6-address>`

The `<ipv6-address>` must be in hexadecimal format using 16-bit values between colons as documented in RFC 2373.

SNMP v3 over IPv6

Some Brocade ICX 6650 devices support IPv6 for SNMP version 3.

Restricting SNMP Access to an IPv6 Node

You can restrict SNMP access so that the Brocade device can only be accessed by the IPv6 host address that you specify. To do so, enter a command such as the following.

```
Brocade(config)#snmp-client ipv6 2001:DB8:89::23
```

Syntax: `snmp-client ipv6 <ipv6-address>`

The `<ipv6-address>` must be in hexadecimal format using 16-bit values between colons as documented in RFC 2373.

Specifying an IPv6 host as an SNMP trap receiver

You can specify an IPv6 host as a trap receiver to ensure that all SNMP traps sent by the Brocade device will go to the same SNMP trap receiver or set of receivers, typically one or more host devices on the network. To do so, enter the **snmp-server host ipv6** command.

```
Brocade(config)#snmp-server host ipv6 2001:DB8:89::13
```

Syntax: `snmp-server host ipv6 <ipv6-address>`

The `<ipv6-address>` must be in hexadecimal format using 16-bit values between colons as documented in RFC 2373.

Viewing IPv6 SNMP server addresses

Many of the existing **show** commands display IPv6 addresses for IPv6 SNMP servers. The following example shows output for the **show snmp server** command.

```
Brocade#show snmp server
    Contact:
    Location:
Community(ro): .....
Traps
    Warm/Cold start: Enable
    Link up: Enable
    Link down: Enable
    Authentication: Enable
    Locked address violation: Enable
    Power supply failure: Enable
    Fan failure: Enable
    Temperature warning: Enable
    STP new root: Enable
    STP topology change: Enable
    vsrp: Enable

Total Trap-Receiver Entries: 4
Trap-Receiver IP-Address      Port-Number Community
1      192.147.201.100      162      .....
2      2001:DB8::200      162      .....
3      192.147.202.100      162      .....
4      2001:DB8::200      162      .....
```

Displaying SNMP Information

This section lists the commands for viewing SNMP-related information.

Displaying the Engine ID

To display the engine ID of a management module, enter a command such as the following.

```
Brocade#show snmp engineid
Local SNMP Engine ID: 800007c70300e05290ab60
Engine Boots: 3
Engine time: 5
```

Syntax: **show snmp engineid**

The engine ID identifies the source or destination of the packet.

The engine boots represents the number of times that the SNMP engine reinitialized itself with the same engine ID. If the engineID is modified, the boot count is reset to 0.

The engine time represents the current time with the SNMP agent.

Displaying SNMP groups

To display the definition of an SNMP group, enter a command such as the following.

```
Brocade#show snmp group
groupname = exceptifgrp
security model = v3
security level = authNoPriv
ACL id = 2
readview = exceptif
writeview = <none>
```

Syntax: show snmp group

The value for security level can be one of the following.

Security level	Authentication
<none>	If the security model shows v1 or v2, then security level is blank. User names are not used to authenticate users; community strings are used instead.
noauthNoPriv	Displays if the security model shows v3 and user authentication is by user name only.
authNoPriv	Displays if the security model shows v3 and user authentication is by user name and the MD5 or SHA algorithm.

Displaying user information

To display the definition of an SNMP user account, enter a command such as the following.

```
Brocade#show snmp user
username = bob
ACL id = 2
group = admin
security model = v3
group ACL id = 0
authtype = md5
authkey = 3aca18d90b8d172760e2dd2e8f59b7fe
privtype = des, privkey = 1088359afb3701730173a6332d406eec
engine ID= 800007c70300e052ab0000
```

Syntax: show snmp user

Interpreting varbinds in report packets

If an SNMP version 3 request packet is to be rejected by an SNMP agent, the agent sends a report packet that contains one or more varbinds. The varbinds contain additional information, showing the cause of failures. An SNMP manager application decodes the description from the varbind. The following table presents a list of varbinds supported by the SNMP agent.

Varbind object Identifier	Description
1. 3. 6. 1. 6. 3. 11. 2. 1. 3. 0	Unknown packet data unit.
1. 3. 6. 1. 6. 3. 12. 1. 5. 0	The value of the varbind shows the engine ID that needs to be used in the snmp-server engineid command
1. 3. 6. 1. 6. 3. 15. 1. 1. 1. 0	Unsupported security level.
1. 3. 6. 1. 6. 3. 15. 1. 1. 2. 0	Not in time packet.
1. 3. 6. 1. 6. 3. 15. 1. 1. 3. 0	Unknown user name. This varbind may also be generated: <ul style="list-style-type: none"> • If the configured ACL for this user filters out this packet. • If the group associated with the user is unknown.
1. 3. 6. 1. 6. 3. 15. 1. 1. 4. 0	Unknown engine ID. The value of this varbind would be the correct authoritative engineID that should be used.
1. 3. 6. 1. 6. 3. 15. 1. 1. 5. 0	Wrong digest.
1. 3. 6. 1. 6. 3. 15. 1. 1. 6. 0	Decryption error.

SNMP v3 configuration examples

The following sections present examples of how to configure SNMP v3.

Simple SNMP v3 configuration

```
Brocade(config)#snmp-s group admingrp v3 priv read all write all notify all
Brocade(config)#snmp-s user adminuser admingrp v3 auth md5 <auth password> priv
<privacy password>
Brocade(config)#snmp-s host <dest-ip> version v3 privacy adminuser
```

More detailed SNMP v3 configuration

```
Brocade(config)#snmp-server view internet internet included
Brocade(config)#snmp-server view system system included
Brocade(config)#snmp-server community ..... ro
Brocade(config)#snmp-server community ..... rw
Brocade(config)#snmp-server contact isc-operations
Brocade(config)#snmp-server location sdh-pillbox
Brocade(config)#snmp-server host 192.91.255.32 .....
Brocade(config)#snmp-server group ops v3 priv read internet write system
Brocade(config)#snmp-server group admin v3 priv read internet write internet
Brocade(config)#snmp-server group restricted v3 priv read internet
Brocade(config)#snmp-server user ops ops v3 encrypted auth md5
ab8e9cd6d46e7a270b8c9549d92a069 priv encrypted des
0e1b153303b6188089411447dbc32de
Brocade(config)#snmp-server user admin admin v3 encrypted auth md5
0d8a2123f91bfbd8695fef16a6f4207b priv encrypted des
18e0cf359fce4fcd60df19c2b6515448
Brocade(config)#snmp-server user restricted restricted v3 encrypted auth md5
261fd8f56a3ad51c8bcec1e4609f54dc priv encrypted des
d32e66152f89de9b2e0cb17a65595f43
```

6 SNMP v3 configuration examples

Foundry Discovery Protocol (FDP) and Cisco Discovery Protocol (CDP) Packets

In this chapter

- [FDP Overview](#) 171
- [CDP packets](#) 177

Table 38 lists the Brocade ICX 6650 switch and the discovery protocols the switch supports. These features are supported in full Layer 3 software images, except where explicitly noted.

TABLE 38 Supported discovery protocol features

Feature	Brocade ICX 6650
Foundry Discovery Protocol (FDP) for IPv4 and IPv6 traffic	Yes
Cisco Discovery Protocol (CDP) for IPv4 and IPV6 traffic	Yes

FDP Overview

The Foundry Discovery Protocol (FDP) enables Brocade ICX 6650 devices to advertise themselves to other Brocade devices on the network. When you enable FDP on a Brocade ICX 6650 device, the device periodically advertises information including the following:

- Hostname (device ID)
- Product platform and capability
- Software version
- VLAN and Layer 3 protocol address information for the port sending the update. IP, IPX, and AppleTalk Layer 3 information is supported.

A Brocade ICX 6650 device running FDP sends FDP updates on Layer 2 to MAC address 01-E0-52-CC-CC-CC. Other Brocade devices listening on that address receive the updates and can display the information in the updates. Brocade devices can send and receive FDP updates on Ethernet interfaces.

FDP is disabled by default.

NOTE

If FDP is not enabled on a Brocade device that receives an FDP update or the device is running a software release that does not support FDP, the update passes through the device at Layer 2.

FDP configuration

The following sections describe how to enable Foundry Discovery Protocol (FDP) and how to change the FDP update and hold timers.

Enabling FDP globally

To enable a Brocade ICX 6650 device to globally send FDP packets, enter the following command at the global CONFIG level of the CLI.

```
Brocade(config)# fdp run
```

Syntax: [no] fdp run

The feature is disabled by default.

Enabling FDP at the interface level

By default, FDP is enabled at the interface level after FDP is enabled on the device.

When FDP is enabled globally, you can disable and re-enable FDP on individual ports.

Disable FDP by entering commands such as the following:

```
Brocade(config)# interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)# no fdp enable
```

Enable or reenable FDP by entering commands such as the following:

```
Brocade(config-if-e10000-1/1/1)# fdp enable
```

Syntax: [no] fdp enable

Specifying the IP management address to advertise

When FDP is enabled, by default, the Brocade ICX 6650 device advertises one IPv4 address and one IPv6 address to its FDP neighbors. If desired, you can configure the device to advertise only the IPv4 management address or only the IPv6 management address. You can set the configuration globally on a Layer 2 switch, or on an interface on a Layer 3 switch.

For example, to configure a Layer 2 switch to advertise the IPv4 address, enter the following command at the Global CONFIG level of the CLI:

```
Brocade(config)# fdp advertise ipv4
```

To configure a Layer 3 switch to advertise the IPv6 address, enter the following command at the Interface level of the CLI:

```
Brocade(config-if-e10000-1/1/1)# fdp advertise ipv6
```

Syntax: fdp advertise ipv4 | ipv6

Changing the FDP update timer

By default, a Brocade ICX 6650 device enabled for FDP sends an FDP update every 60 seconds. You can change the update timer to a value from 5 – 900 seconds.

To change the FDP update timer, enter a command such as the following at the global CONFIG level of the CLI.

```
Brocade(config)# fdp timer 120
```

Syntax: [no] **fdp timer** <secs>

The <secs> parameter specifies the number of seconds between updates and can be from 5 – 900 seconds. The default is 60 seconds.

Changing the FDP hold time

By default, a Brocade ICX 6650 device that receives an FDP update holds the information until one of the following events occurs:

- The device receives a new update.
- 180 seconds have passed since receipt of the last update. This is the hold time.

Once either of these events occurs, the device discards the update.

To change the FDP hold time, enter the **fdp holdtime** command at the global CONFIG level of the CLI.

```
Brocade(config)# fdp holdtime 360
```

Syntax: [no] **fdp holdtime** <secs>

The <secs> parameter specifies the number of seconds a Brocade device that receives an FDP update can hold the update before discarding it. You can specify from 10 – 255 seconds. The default is 180 seconds.

Displaying FDP information

You can display the following Foundry Discovery Protocol (FDP) information:

- FDP entries for Brocade neighbors
- Individual FDP entries
- FDP information for an interface on the device you are managing
- FDP packet statistics

NOTE

If the Brocade device has intercepted CDP updates, then the CDP information is also displayed.

Displaying neighbor information

To display a summary list of all the Brocade neighbors that have sent FDP updates to this Brocade device, enter the **show fdp neighbor** command.

```
Brocade#show fdp neighbors
```

Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
S - Switch, H - Host, I - IGMP, r - Repeater

(*) indicates a CDP device

Device ID	Local Interface	Holdtm	Capability	Platform	Port ID
ICX6650-64 Rou	ethernet1/1/1	133	Router	ICX6650-64	ethernet1/3/1
ICX6650-64 Rou	ethernet1/1/2	133	Router	ICX6650-64	ethernet1/3/2
ICX6650-64 Rou	ethernet1/1/3	133	Router	ICX6650-64	ethernet1/3/3
ICX6650-64 Rou	ethernet1/1/4	133	Router	ICX6650-64	ethernet1/3/4
(*)CISCO3750	ethernet1/1/5	169	S I	cisco WS-C3	
GigabitEthernet1/0/5					
ICX6650-64 Rou	ethernet1/1/9	163	Router	ICX6650-64	ethernet1/1/9
ICX6650-64 Rou	ethernet1/1/10	163	Router	ICX6650-64	ethernet1/1/10
ICX6650-64 Rou	ethernet1/1/25	122	Router	ICX6650-64	ethernet1/1/25
ICX6650-64 Rou	ethernet1/1/26	122	Router	ICX6650-64	ethernet1/1/26

Syntax: `show fdp neighbor [ethernet <stack-unit>/<slot>/<port>] [detail]`

The `ethernet <stack-unit>/<slot>/<port>` parameter lists the information for updates received on the specified ethernet interface. Stack-unit is 1.

The `detail` parameter lists detailed information for each device.

The `show fdp neighbor` command, without optional parameters, displays the following information.

TABLE 39 Summary FDP and CDP neighbor information

This line...	Displays...
Device ID	The hostname of the neighbor.
Local Int	The interface on which this Brocade device received an FDP or CDP update for the neighbor.
Holdtm	The maximum number of seconds this device can keep the information received in the update before discarding it.
Capability	The role the neighbor is capable of playing in the network.
Platform	The product platform of the neighbor.
Port ID	The interface through which the neighbor sent the update.

To display detailed information, enter the `show fdp neighbor detail` command.

```
Brocade# show fdp neighbor detail
Device ID: ICX6650-64 Router
          configured as tag-type8100
Entry address(es):
  IP address: 10.20.79.91
Platform: ICX6650-64 Router, Capabilities: Router
Interface: ethernet1/1/1
Port ID (outgoing port): ethernet1/3/1 is UNTAGGED in VLAN 1
Holdtime : 133 seconds
Brocade Communications Systems, Inc. ICX6650-64, IronWare Version 07.5.00B1T323
Compiled on Jul 16 2012 at 20:00:20 labeled as ICXLR07500B1
Device ID: ICX6650-64 Router
          configured as tag-type8100
Entry address(es):
```


The **show fdp neighbor detail** command displays the following information.

TABLE 40 Detailed FDP and CDP neighbor information

Parameter	Definition
Device ID	The hostname of the neighbor. In addition, this line lists the VLAN memberships and other VLAN information for the neighbor port that sent the update to this device.
Entry address(es)	The Layer 3 protocol addresses configured on the neighbor port that sent the update to this device. If the neighbor is a Layer 2 Switch, this field lists the management IP address.
Platform	The product platform of the neighbor.
Capabilities	The role the neighbor is capable of playing in the network.
Interface	The interface on which this device received an FDP or CDP update for the neighbor.
Port ID	The interface through which the neighbor sent the update.
Holdtime	The maximum number of seconds this device can keep the information received in the update before discarding it.
Version	The software version running on the neighbor.

Displaying FDP entries

To display the detailed neighbor information for a specific device, enter the **show fdp entry <device-id>** command.

```

Brocade#show fdp entry rpru43
Device ID: rpru43
           configured as tag-type8100
Entry address(es):
  IP address: 10.20.67.98
  IPv6 address (Global): 2001:DB8:2
Platform: ICX6650-64 Router, Capabilities: Router
Interface: ethernet1/1/6
Port ID (outgoing port): ethernet1/1/6 is TAGGED in following VLAN(s):
  1000
Holdtime : 157 seconds
Brocade Communications Systems, Inc. ICX6650-64, IronWare Version 07.5.00B1T323
23 Compiled on Jun 28 2012 at 18:54:50 labeled as ICXLR07500B1
Device ID: rpru43
           configured as tag-type8100
Entry address(es):
  IP address: 10.20.67.98
  IPv6 address (Global): 2001:DB8:2
Platform:ICX6650-64 Router , Capabilities: Router
Interface: ethernet1/1/7

```

Syntax: **show fdp entry * | <device-id>**

The *** | <device-id>** parameter specifies the device ID. If you enter *****, the detailed updates for all neighbor devices are displayed. If you enter a specific device ID, the update for that device is displayed. For information about the display, refer to [Table 40](#).

Displaying FDP information for an interface

To display FDP information for an interface, enter a command such as the following.

```
BrocadeA# show fdp interface ethernet 1/1/1
FastEthernet2/3 is up, line protocol is up
  Encapsulation ethernet
  Sending FDP packets every 5 seconds
  Holdtime is 180 seconds
```

This example shows information for Ethernet port 1/1/1. The port sends FDP updates every 5 seconds. Neighbors that receive the updates can hold them for up to 180 seconds before discarding them.

Syntax: `show fdp interface [ethernet <stack-unit>/<slot>/<port>]`

The **ethernet <stack-unit>/<slot>/<port>** parameter lists the information only for the specified ethernet interface. Stack-unit is 1.

Displaying FDP and CDP statistics

To display FDP and CDP packet statistics, enter the following command.

```
BrocadeA# show fdp traffic
CDP/FDP counters:
  Total packets output: 6, Input: 5
  Hdr syntax: 0, Chksum error: 0, Encaps failed: 0
  No memory: 0, Invalid packet: 0, Fragmented: 0
  Internal errors: 0
```

Syntax: `show fdp traffic`

Clearing FDP and CDP information

You can clear the following FDP and CDP information:

- Information received in FDP and CDP updates
- FDP and CDP statistics

The same commands clear information for both FDP and CDP.

Clearing FDP and CDP neighbor information

To clear the information received in FDP and CDP updates from neighboring devices, enter the following command.

```
Brocade# clear fdp table
```

Syntax: `clear fdp table`

NOTE

This command clears all the updates for FDP and CDP.

Clearing FDP and CDP statistics

To clear FDP and CDP statistics, enter the following command.

```
Brocade# clear fdp counters
```

Syntax: clear fdp counters

CDP packets

Cisco Discovery Protocol (CDP) packets are used by Cisco devices to advertise themselves to other Cisco devices. By default, Brocade devices forward these packets without examining their contents. You can configure a Brocade device to intercept and display the contents of CDP packets. This feature is useful for learning device and interface information for Cisco devices in the network.

Brocade devices support intercepting and interpreting CDP version 1 and version 2 packets.

NOTE

The Brocade device can interpret only the information fields that are common to both CDP version 1 and CDP version 2.

NOTE

When you enable interception of CDP packets, the Brocade device drops the packets. As a result, Cisco devices will no longer receive the packets.

Enabling interception of CDP packets globally

To enable the device to intercept and display CDP packets, enter the following command at the global CONFIG level of the CLI.

```
Brocade(config)# cdp run
```

Syntax: [no] cdp run

The feature is disabled by default.

Enabling interception of CDP packets on an interface

You can disable and enable CDP at the interface level.

You can enter commands such as the following.

```
Brocade(config)# interface ethernet 1/1/1  
Brocade(config-if-e10000-1/1/1)# cdp enable
```

Syntax: [no] cdp enable

By default, the feature is enabled on an interface once CDP is enabled on the device.

Displaying CDP information

You can display the following CDP information:

- Cisco neighbors
- CDP entries for all Cisco neighbors or a specific neighbor
- CDP packet statistics

Displaying neighbors

To display the Cisco neighbors the Brocade device has learned from CDP packets, enter the **show fdp neighbors** command.

```
Brocade# show fdp neighbors
Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater
(*) indicates a CDP device
```

Device ID	Local Interface	Holdtm	Capability	Platform	Port ID
ICX6650-64 Rou	ethernet1/1/1	133	Router	ICX6650-64	ethernet1/3/1
ICX6650-64 Rou	ethernet1/1/2	133	Router	ICX6650-64	ethernet1/3/2
ICX6650-64 Rou	ethernet1/1/3	133	Router	ICX6650-64	ethernet1/3/3
ICX6650-64 Rou	ethernet1/1/4	133	Router	ICX6650-64	ethernet1/3/4
(*)CISCO3750	ethernet1/1/5	169	S I	cisco WS-C3	

GigabitEthernet1/0/5

To display detailed information for the neighbors, enter the **show fdp neighbors detail** command.

```
Brocade# show fdp neighbors detail
Device ID: ICX6650-64 Router
           configured as tag-type8100
Entry address(es):
  IP address: 10.20.79.91
Platform: ICX6650-64 Router, Capabilities: Router
Interface: ethernet1/1/1
Port ID (outgoing port): ethernet1/3/1 is UNTAGGED in VLAN 1
Holdtime : 133 seconds
Brocade Communications Systems, Inc. ICX6650-64, IronWare Version 07.5.00B1T323
Compiled on Jul 16 2012 at 20:00:20 labeled as ICXLR07500B1
Device ID: ICX6650-64 Router
           configured as tag-type8100
```

To display information about a neighbor attached to a specific port, enter a command such as the following.

```

Brocade# show fdp neighbors ethernet 1/1/1
Device ID: Router
Entry address(es):
  IP address: 192.95.6.143
Platform: cisco RSP4, Capabilities: Router
Interface: Eth 1/1/1, Port ID (outgoing port): FastEthernet5/0/0
Holdtime : 127 seconds
Version :
Cisco Internetwork Operating System Software
IOS (tm) RSP Software (RSP-JSV-M), Version 12.0(5)T1, RELEASE SOFTWARE
(fc1)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Thu 19-Aug-99 04:12 by cmong

```

Syntax: `show fdp neighbors [detail | ethernet <stack-unit>/<slot>/<port>]`

Specify the Ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

Displaying CDP entries

To display CDP entries for all neighbors, enter the **show fdp entry** command.

```

Brocade# show fdp entry *
Device ID: Router
      configured as tag-type8100
Entry address(es):
  IP address: 10.20.67.98
  IPv6 address (Global): 2001:DB8:2
Platform: ICX6650-64 Router, Capabilities: Router
Interface: ethernet1/1/6
Port ID (outgoing port): ethernet1/1/6 is TAGGED in following VLAN(s):
  1000
Holdtime : 128 seconds
Brocade Communications Systems, Inc. ICX6650-64 Router, IronWare Version
07.5.00B1T323 23 Compiled on Jun 28 2012 at 18:54:50 labeled as ICXLR07500B1

```

To display CDP entries for a specific device, specify the device ID, as shown in the following example.

```

Brocade# show fdp entry CISCO3750
Device ID: CISCO3750
Entry address(es):
Platform: cisco WS-C3750G-24TS, Capabilities: Switch, IGMP
Interface: ethernet1/1/5, Port ID (outgoing port): GigabitEthernet1/0/5
Holdtime : 130 seconds
Cisco Internetwork Operating System Software
IOS (tm) C3750 Software (C3750-I5-M), Version 12.2(18)SE, RELEASE SOFTWARE (fc1)
Copyright (c) 1986-2004 by cisco Systems, Inc.
Compiled Wed 04-Feb-04 20:29 by antonino

```

Syntax: `show fdp entry * | <device-id>`

Displaying CDP statistics

To display CDP packet statistics, enter the **show fdp traffic** command.

```
Brocade# show fdp traffic
CDP counters:
  Total packets output: 0, Input: 3
  Hdr syntax: 0, Chksum error: 0, Encaps failed: 0
  No memory: 0, Invalid packet: 0, Fragmented: 0
```

Syntax: **show fdp traffic**

Clearing CDP information

You can clear the following CDP information:

- Cisco Neighbor information
- CDP statistics

To clear the Cisco neighbor information, enter the **clear fdp table** command.

```
Brocade# clear fdp table
```

Syntax: **clear fdp table**

To clear CDP statistics, enter the following command.

```
Brocade# clear fdp counters
```

Syntax: **clear fdp counters**

LLDP and LLDP-MED

In this chapter

- [LLDP terms used in this chapter](#) 182
- [LLDP overview](#) 183
- [LLDP-MED overview](#) 184
- [General LLDP operating principles](#) 186
- [MIB support](#) 191
- [Syslog messages](#) 191
- [LLDP configuration](#) 192
- [LLDP-MED configuration](#) 206
- [LLDP-MED attributes advertised by the Brocade device](#) 217
- [Resetting LLDP statistics](#) 223
- [Clearing cached LLDP neighbor information](#) 224

Table 41 lists the Brocade ICX 6650 switch and the Link Layer Discovery Protocol (LLDP) features the switch supports. These features are supported in full Layer 3 software images, except where explicitly noted.

TABLE 41 Supported LLDP features

Feature	Brocade ICX 6650
LLDP	Yes
LLDP-MED	Yes
Support for tagged LLDP packets	Yes
IPv4 management address advertisement	Yes
IPv6 management address advertisement	Yes
LLDP operating mode setting per port	Yes
Setting the maximum number of LLDP neighbors	Yes
SNMP and Syslog messages	Yes
LLDP transmission intervals	Yes
Holdtime multiplier for transmit TTL	Yes
Configuring the minimum time between port reinitializations	Yes
Fast start repeat count for LLDP-MED	Yes
Location ID for LLDP-MED	Yes

TABLE 41 Supported LLDP features

Feature	Brocade ICX 6650
LLDP-MED network policy	Yes
LLDP statistics and configuration details	Yes

This chapter describes how to configure the following protocols:

Link layer discovery protocol (LLDP) – The Layer 2 network discovery protocol described in the IEEE 802.1AB standard, *Station and Media Access Control Connectivity Discovery*. This protocol enables a station to advertise its capabilities to, and to discover, other LLDP-enabled stations in the same 802 LAN segments.

LLDP media endpoint devices (LLDP-MED) – The Layer 2 network discovery protocol extension described in the ANSI/TIA-1057 standard, *LLDP for Media Endpoint Devices*. This protocol enables a switch to configure and manage connected Media Endpoint devices that need to send media streams across the network (e.g., IP telephones and security cameras).

LLDP enables network discovery between Network Connectivity devices (such as switches), whereas LLDP-MED enables network discovery at the edge of the network, between Network Connectivity devices and media Endpoint devices (such as IP phones).

The information generated by LLDP and LLDP-MED can be used to diagnose and troubleshoot misconfigurations on both sides of a link. For example, the information generated can be used to discover devices with misconfigured or unreachable IP addresses, and to detect port speed and duplex mismatches.

LLDP and LLDP-MED facilitate interoperability across multiple vendor devices. Brocade devices running LLDP can interoperate with third-party devices running LLDP.

The Brocade LLDP and LLDP-MED implementation adheres to the IEEE 802.1AB and TIA-1057 standards.

LLDP terms used in this chapter

Endpoint device – An LLDP-MED device located at the network edge, that provides some aspect of IP communications service based on IEEE 802 LAN technology. An Endpoint device is classified in one of three class types (I, II, or III) and can be an IP telephone, softphone, or conference bridge, among others.

LLDP agent – The protocol entity that implements LLDP for a particular IEEE 802 device. Depending on the configured LLDP operating mode, an LLDP agent can send and receive LLDP advertisements (frames), or send LLDP advertisements only, or receive LLDP advertisements only.

LLDPDU (LLDP Data Unit) – A unit of information in an LLDP packet that consists of a sequence of short variable length information elements, known as **TLVs**. LLDP pass-through is not supported in conformance to IEEE standard.

MIB (Management Information Base) – A virtual database that identifies each manageable object by its name, syntax, accessibility, and status, along with a text description and unique object identifier (OID). The database is accessible by a Network Management Station (NMS) using a management protocol such as the Simple Network Management Protocol (SNMP).

Network connectivity device – A forwarding 802 LAN device, such as a router, switch, or wireless access point.

Station – A node in a network.

TLV (Type-Length-Value) – An information element in an LLDPDU that describes the type of information being sent, the length of the information string, and the value (actual information) that will be transmitted.

TTL (Time-to-Live) – Specifies the length of time that the receiving device should maintain the information acquired through LLDP in its MIB.


LLDP overview

LLDP enables a station attached to an IEEE 802 LAN/MAN to advertise its capabilities to, and to discover, other stations in the same 802 LAN segments.

The information distributed by LLDP (the advertisement) is stored by the receiving device in a standard Management Information Base (MIB), accessible by a Network Management System (NMS) using a management protocol such as the Simple Network Management Protocol (SNMP). The information also can be viewed from the CLI, using **show LLDP** commands.

Figure 11 illustrates LLDP connectivity

FIGURE 11 LLDP connectivity



Benefits of LLDP


LLDP provides the following benefits:

- Network Management:
 - Simplifies the use of and enhances the ability of network management tools in multi-vendor environments
 - Enables discovery of accurate physical network topologies such as which devices are neighbors and through which ports they connect
 - Enables discovery of stations in multi-vendor environments
- Network Inventory Data:
 - Supports optional system name, system description, system capabilities and management address
 - System description can contain the device product name or model number, version of hardware type, and operating system
 - Provides device capability, such as switch, router, or WLAN access point
- Network troubleshooting:
 - Information generated by LLDP can be used to detect speed and duplex mismatches
 - Accurate topologies simplify troubleshooting within enterprise networks
 - Can discover devices with misconfigured or unreachable IP addresses

LLDP-MED overview

LLDP-MED is an extension to LLDP. This protocol enables advanced LLDP features in a Voice over IP (VoIP) network. Whereas LLDP enables network discovery between Network Connectivity devices, LLDP-MED enables network discovery between Network Connectivity devices and media Endpoints such as, IP telephones, softphones, VoIP gateways and conference bridges

.[Figure 12](#) demonstrates LLDP-MED connectivity.

FIGURE 12 LLDP-MED connectivity

Benefits of LLDP-MED

LLDP-MED provides the following benefits:

- Vendor-independent management capabilities, enabling different IP telephony systems to interoperate in one network.
- Automatically deploys network policies, such as Layer 2 and Layer 3 QoS policies and Voice VLANs.
- Supports E-911 Emergency Call Services (ECS) for IP telephony
- Collects Endpoint inventory information
- Network troubleshooting
 - Helps to detect improper network policy configuration

LLDP-MED class

An LLDP-MED class specifies an Endpoint type and its capabilities. An Endpoint can belong to one of three LLDP-MED class types:

- **Class 1 (Generic endpoint)** – A Class 1 Endpoint requires basic LLDP discovery services, but does not support IP media nor does it act as an end-user communication appliance. A Class 1 Endpoint can be an IP communications controller, other communication-related server, or other device requiring basic LLDP discovery services.
- **Class 2 (Media endpoint)** – A Class 2 Endpoint supports media streams and may or may not be associated with a particular end user. Device capabilities include media streaming, as well as all of the capabilities defined for Class 1 Endpoints. A Class 2 Endpoint can be a voice/media gateway, conference, bridge, media server, etc..
- **Class 3 (Communication endpoint)** – A Class 3 Endpoint supports end user IP communication. Capabilities include aspects related to end user devices, as well as all of the capabilities defined for Class 1 and Class 2 Endpoints. A Class 3 Endpoint can be an IP telephone, softphone (PC-based phone), or other communication device that directly supports the end user.

Discovery services defined in Class 3 include location identifier (ECS/E911) information and inventory management.

The LLDP-MED device class is advertised when LLDP-MED is enabled on a port.

[Figure 12](#) illustrates LLDP-MED connectivity and supported LLDP-MED classes.

General LLDP operating principles

LLDP and LLDP-MED use the services of the Data Link sublayers, Logical Link Control and Media Access Control, to transmit and receive information to and from other **LLDP Agents** (protocol entities that implement LLDP).

LLDP is a one-way protocol. An LLDP agent can transmit and receive information to and from another LLDP agent located on an adjacent device, but it cannot solicit information from another LLDP agent, nor can it acknowledge information received from another LLDP agent.

LLDP operating modes

When LLDP is enabled on a global basis, by default, each port on the Brocade device will be capable of transmitting and receiving LLDP packets. You can disable a port's ability to transmit and receive LLDP packets, or change the operating mode to one of the following:

- Transmit LLDP information only
- Receive LLDP information only

LLDP transmit mode

An LLDP agent sends LLDP packets to adjacent LLDP-enabled devices. The LLDP packets contain information about the transmitting device and port.

An LLDP agent initiates the transmission of LLDP packets whenever the transmit countdown timing counter expires, or whenever LLDP information has changed. When a transmit cycle is initiated, the LLDP manager extracts the MIB objects and formats this information into TLVs. The TLVs are inserted into an LLDPDU, addressing parameters are prepended to the LLDPDU, and the information is sent out LLDP-enabled ports to adjacent LLDP-enabled devices.

LLDP receive mode

An LLDP agent receives LLDP packets from adjacent LLDP-enabled devices. The LLDP packets contain information about the transmitting device and port.


When an LLDP agent receives LLDP packets, it checks to ensure that the LLDPDUs contain the correct sequence of mandatory TLVs, then validates optional TLVs. If the LLDP agent detects any errors in the LLDPDUs and TLVs, it drops them in software. TLVs that are not recognized but do not contain basic formatting errors, are assumed to be valid and are assigned a temporary identification index and stored for future possible alter retrieval by network management. All validated TLVs are stored in the neighbor database.

LLDP packets

LLDP agents transmit information about a sending device/port in packets called LLDP Data Units (LLDPDUs). All the LLDP information to be communicated by a device is contained within a single 1500 byte packet. A device receiving LLDP packets is not permitted to combine information from multiple packets.

As shown in [Figure 13](#), each LLDPDU has three mandatory TLVs, an End of LLDPDU TLV, plus optional TLVs as selected by network management.

FIGURE 13 LLDPDU packet format



M = mandatory TLV (required for all LLDPDUs)

Each LLDPDU consists of an untagged Ethernet header and a sequence of short, variable length information elements known as type, length, value (TLV).

TLVs have Type, Length, and Value fields, where:

- **Type** identifies the kind of information being sent
- **Length** indicates the length (in octets) of the information string
- **Value** is the actual information being sent (for example, a binary bit map or an alpha-numeric string containing one or more fields).

TLV support

This section lists the LLDP and LLDP-MED TLV support.

LLDP TLVs

There are two types of LLDP TLVs, as specified in the IEEE 802.3AB standard:

- **Basic management TLVs** consist of both optional general system information TLVs as well as mandatory TLVs.

Mandatory TLVs cannot be manually configured. They are always the first three TLVs in the LLDPDU, and are part of the packet header.

General system information TLVs are optional in LLDP implementations and are defined by the Network Administrator.

Brocade devices support the following Basic Management TLVs:

- Chassis ID (mandatory)
- Port ID (mandatory)
- Time to Live (mandatory)
- Port description
- System name
- System description
- System capabilities
- Management address
- End of LLDPDU
- **Organizationally-specific TLVs** are optional in LLDP implementations and are defined and encoded by individual organizations or vendors. These TLVs include support for, but are not limited to, the IEEE 802.1 and 802.3 standards and the TIA-1057 standard.

Brocade devices support the following Organizationally-specific TLVs:

- **802.1 organizationally-specific TLVs**
 - Port VLAN ID
 - VLAN name TLV
- **802.3 organizationally-specific TLVs**
 - MAC/PHY configuration/status
 - Power through MDI
 - Link aggregation
 - Maximum frame size

LLDP-MED TLVs

Brocade devices honor and send the following LLDP-MED TLVs, as defined in the TIA-1057 standard:

- LLDP-MED capabilities
- Network policy
- Location identification
- Extended power-via-MDI

Mandatory TLVs

When an LLDP agent transmits LLDP packets to other agents in the same 802 LAN segments, the following mandatory TLVs are always included:

- Chassis ID
- Port ID
- Time to Live (TTL)

This section describes the above TLVs in detail.

Chassis ID

The Chassis ID identifies the device that sent the LLDP packets.

There are several ways in which a device may be identified. A chassis ID subtype, included in the TLV and shown in [Table 42](#), indicates how the device is being referenced in the Chassis ID field.

TABLE 42 Chassis ID subtypes

ID subtype	Description
0	Reserved
1	Chassis component
2	Interface alias
3	Port component
4	MAC address
5	Network address
6	Interface name
7	Locally assigned
8 – 255	Reserved

Brocade ICX 6650 devices use chassis ID subtype 4, the base MAC address of the device. Other third party devices may use a chassis ID subtype other than 4. The chassis ID will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
Chassis ID (MAC address): 748e.f80c.5f40
```

The chassis ID TLV is always the first TLV in the LLDPDU.

Port ID

The Port ID identifies the port from which LLDP packets were sent.

There are several ways in which a port may be identified, as shown in [Figure 43](#). A port ID subtype, included in the TLV, indicates how the port is being referenced in the Port ID field.

TABLE 43 Port ID subtypes

ID subtype	Description
0	Reserved
1	Interface alias
2	Port component
3	MAC address
4	Network address
5	Interface name
6	Agent circuit ID
7	Locally assigned
8 – 255	Reserved


Brocade ICX 6650 devices use port ID subtype 3, the permanent MAC address associated with the port. Other third party devices may use a port ID subtype other than 3. The port ID appears similar to the following on the remote device, and in the CLI display output on the Brocade device (show lldp local-info).

```
Port ID (MAC address): 748e.f80c.5f40
```

The LLDPDU format is shown in [“LLDPDU packet format”](#) on page 187.

The Port ID TLV format is shown below.

FIGURE 14 Port ID TLV packet format



TTL value

The Time to Live (TTL) Value is the length of time the receiving device should maintain the information acquired by LLDP in its MIB.

The TTL value is automatically computed based on the LLDP configuration settings. The TTL value will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (show lldp local-info).

```
Time to live: 40 seconds
```


If the TTL field has a value other than zero, the receiving LLDP agent is notified to completely replace all information associated with the LLDP agent/port with the information in the received LLDPDU.

If the TTL field value is zero, the receiving LLDP agent is notified that all system information associated with the LLDP agent/port is to be deleted. This TLV may be used, for example, to signal that the sending port has initiated a port shutdown procedure.

The LLDPDU format is shown in [“LLDPDU packet format”](#) on page 187.

The TTL TLV format is shown below.

FIGURE 15 TTL TLV packet format



MIB support

Brocade ICX 6650 devices support the following standard management information base (MIB) modules:

- LLDP-MIB
- LLDP-EXT-DOT1-MIB
- LLDP-EXT-DOT3-MIB
- LLDP-EXT-MED-MIB

Syslog messages

Syslog messages for LLDP provide management applications with information related to MIB data consistency and general status. These Syslog messages correspond to the `IldpRemTablesChange` SNMP notifications. Refer to [“Enabling LLDP SNMP notifications and Syslog messages”](#) on page 196.

Syslog messages for LLDP-MED provide management applications with information related to topology changes. These Syslog messages correspond to the `IldpXMedTopologyChangeDetected` SNMP notifications. Refer to [“Enabling SNMP notifications and Syslog messages for LLDP-MED topology changes”](#) on page 207.

LLDP configuration

This section describes how to enable and configure LLDP.

[Table 44](#) lists the LLDP global-level tasks and the default behavior/value for each task.

TABLE 44 LLDP global configuration tasks and default behavior /value

Global task	Default behavior / value when LLDP is enabled
Enabling LLDP on a global basis	Disabled
Specifying the maximum number of LLDP neighbors per device	Automatically set to 392 neighbors per device
Specifying the maximum number of LLDP neighbors per port	Automatically set to 4 neighbors per port
Enabling SNMP notifications and Syslog messages	Disabled
Changing the minimum time between SNMP traps and Syslog messages	Automatically set to 2 seconds when SNMP notifications and Syslog messages for LLDP are enabled
Enabling and disabling TLV advertisements	When LLDP transmit is enabled, by default, the Brocade device will automatically advertise LLDP capabilities, except for the system description, VLAN name, and power-via-MDI information, which may be configured by the system administrator. Also, if desired, you can disable the advertisement of individual TLVs.
Changing the minimum time between LLDP transmissions	Automatically set to 2 seconds
Changing the interval between regular LLDP transmissions	Automatically set to 30 seconds
Changing the holdtime multiplier for transmit TTL	Automatically set to 4
Changing the minimum time between port reinitializations	Automatically set to 2 seconds

LLDP configuration notes and considerations

- LLDP is supported on Ethernet interfaces only.
- If a port is 802.1X-enabled, the transmission and reception of LLDP packets will only take place while the port is authorized.
- Cisco Discovery Protocol (CDP) and Brocade Discovery Protocol (FDP) run independently of LLDP. Therefore, these discovery protocols can run simultaneously on the same device.
- By default, the Brocade device limits the number of neighbors per port to four, and staggers the transmission of LLDP packets on different ports, in order to minimize any high-usage spikes to the CPU.
- By default, the Brocade device forwards
- Ports that are in blocking mode (spanning tree) can still receive LLDP packets from a forwarding port.
- Auto-negotiation status indicates what is being advertised by the port for 802.3 auto-negotiation.

Enabling and disabling LLDP

LLDP is enabled by default on individual ports. However, to run LLDP, you must first enable it on a global basis (on the entire device).

To enable LLDP globally, enter the following command at the global CONFIG level of the CLI.

```
Brocade(config)#lldp run
```

Syntax: [no] lldp run

Enabling support for tagged LLDP packets

By default, Brocade devices do not accept tagged LLDP packets from other vendors' devices. To enable support, apply the command **lldp tagged-packets process** at the Global CONFIG level of the CLI. When enabled, the device will accept incoming LLDP tagged packets if the VLAN tag matches any of the following:

- a configured VLAN on the port
- the default VLAN for a tagged port
- the configured untagged VLAN for a dual-mode port

To enable support for tagged LLDP packets, enter the following command.

```
Brocade(config)#lldp tagged-packets process
```

Syntax: [no] lldp tagged-packets process

Changing a port LLDP operating mode

LLDP packets are not exchanged until LLDP is enabled on a global basis. When LLDP is enabled on a global basis, by default, each port on the Brocade device will be capable of transmitting and receiving LLDP packets. You can disable a port's ability to transmit and receive LLDP packets, or change the operating mode to one of the following:

- Transmit LLDP information only
- Receive LLDP information only

You can configure a different operating mode for each port on the Brocade device. For example, you could disable the receipt and transmission of LLDP packets on port e 1/1/1, configure port e 1/1/3 to only receive LLDP packets, and configure port e 1/1/5 to only transmit LLDP packets.

The following sections show how to change the operating mode.

Enabling and disabling receive and transmit mode

To disable the receipt and transmission of LLDP packets on individual ports, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#no lldp enable ports e 1/1/1 e 1/1/2
```

The above command disables LLDP on ports 1/1/1 and 1/1/2. These ports will not transmit nor receive LLDP packets.

To enable LLDP on a port after it has been disabled, enter the following command.

```
Brocade(config)#lldp enable ports e 1/2/1
```

Syntax: [no] lldp enable ports ethernet <stack-unit>/<slot>/<port> | all

Use the **[no]** form of the command to disable the receipt and transmission of LLDP packets on a port. Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

NOTE

When a port is configured to both receive and transmit LLDP packets and the MED capabilities TLV is enabled, LLDP-MED is enabled as well. LLDP-MED is not enabled if the operating mode is set to receive only or transmit only.

Enabling and disabling receive only mode

When LLDP is enabled on a global basis, by default, each port on the Brocade ICX 6650 device will be capable of transmitting and receiving LLDP packets. To change the LLDP operating mode from receive and transmit mode to receive only mode, simply disable the transmit mode. Enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#no lldp enable transmit ports e 1/1/1 e 1/1/2 e 1/1/3
```

The above command changes the LLDP operating mode on ports 1/1/1, 1/1/2, and 1/1/3 from transmit and receive mode to receive only mode.

To change a port LLDP operating mode from transmit only to receive only, first disable the transmit only mode, then enable the receive only mode. Enter commands such as the following.

```
Brocade(config)#no lldp enable transmit ports e 1/1/4 e 1/1/5 e 1/1/6
Brocade(config)#lldp enable receive ports e 1/1/4 e 1/1/5 e 1/1/6
```

The above commands change the LLDP operating mode on ports 1/1/4, 1/1/5, and 1/1/6, from transmit only to receive only. Note that if you do not disable the transmit only mode, you will configure the port to both transmit and receive LLDP packets.

NOTE

LLDP-MED is not enabled when you enable the receive only operating mode. To enable LLDP-MED, you must configure the port to both receive and transmit LLDP packets. Refer to [“Enabling and disabling receive and transmit mode”](#) on page 193.

Syntax: [no] lldp enable receive ports ethernet <stack-unit>/<slot>/<port> | all

Use the **no** form of the command to disable the receive only mode. Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Enabling and Disabling Transmit Only Mode

When LLDP is enabled on a global basis, by default, each port on the Brocade device will be capable of transmitting and receiving LLDP packets. To change the LLDP operating mode to transmit only mode, simply disable the receive mode. Enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#no lldp enable receive ports e 1/1/1 e 1/1/2 e 1/1/3
```

The above command changes the LLDP operating mode on ports 1/1/1, 1/1/2, and 1/1/3 from transmit and receive mode to transmit only mode. Any incoming LLDP packets will be dropped in software.

To change a port LLDP operating mode from receive only to transmit only, first disable the receive only mode, then enable the transmit only mode. For example, enter commands such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#no lldp enable receive ports e 1/1/4 e 1/1/5
Brocade(config)#lldp enable transmit ports e 1/1/4 e 1/1/5
```

The above commands change the LLDP operating mode on ports 1/1/4 and 1/1/5 from receive only mode to transmit only mode. Any incoming LLDP packets will be dropped in software. Note that if you do not disable receive only mode, you will configure the port to both receive and transmit LLDP packets.

NOTE

LLDP-MED is not enabled when you enable the transmit only operating mode. To enable LLDP-MED, you must configure the port to both receive and transmit LLDP packets. Refer to [“Enabling and disabling receive and transmit mode”](#) on page 193.

Syntax: [no] lldp enable transmit ports ethernet <stack-unit>/<slot>/<port> | all

Use the **no** form of the command to disable the *transmit only* mode. Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Maximum number of LLDP neighbors

You can change the limit of the number of LLDP neighbors for which LLDP data will be retained, per device as well as per port.

Specifying the maximum number of LLDP neighbors per device

You can change the maximum number of neighbors for which LLDP data will be retained for the entire system.

For example, to change the maximum number of LLDP neighbors for the entire device to 26, enter the following command.

```
Brocade(config)#lldp max-total-neighbors 26
```

Syntax: [no] lldp max-total-neighbors <value>

Use the **[no]** form of the command to remove the static configuration and revert to the default value of 392.

The <value> variable is a number between 16 and 8192. The default number of LLDP neighbors per device is 392.

Use the **show lldp** command to view the configuration.

Specifying the maximum number of LLDP neighbors per port

You can change the maximum number of LLDP neighbors for which LLDP data will be retained for each port. By default, the maximum number is four and you can change this to a value between one and 64.

For example, to change the maximum number of LLDP neighbors to six, enter the following command.

```
Brocade(config)#lldp max-neighbors-per-port 6
```

Syntax: [no] lldp max-neighbors-per-port <value>

Use the **no** form of the command to remove the static configuration and revert to the default value of four.

The <value> variable is a number from 1 to 64. The default is number of LLDP neighbors per port is four.

Use the **show lldp** command to view the configuration.

Enabling LLDP SNMP notifications and Syslog messages

SNMP notifications and Syslog messages for LLDP provide management applications with information related to MIB data updates and general status.

When you enable LLDP SNMP notifications, corresponding Syslog messages are enabled as well. When you enable LLDP SNMP notifications, the device will send traps and corresponding Syslog messages whenever there are changes to the LLDP data received from neighboring devices.

LLDP SNMP notifications and corresponding Syslog messages are disabled by default. To enable them, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#lldp enable snmp notifications ports e 1/1/1 to 1/1/2
```

The above command enables SNMP notifications and corresponding Syslog messages on ports 1/1/1 and 1/1/2. By default, the device will send no more than one SNMP notification and Syslog message within a five second period. If desired, you can change this interval. Refer to [“Specifying the minimum time between SNMP traps and Syslog messages”](#) on page 197.

Syntax: [no] lldp enable snmp notifications ports ethernet <stack-unit>/<slot>/<port> | all

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Specifying the minimum time between SNMP traps and Syslog messages

When SNMP notifications and Syslog messages for LLDP are enabled, the device will send no more than one SNMP notification and corresponding Syslog message within a five second period. If desired, you can throttle the amount of time between transmission of SNMP traps (lldpRemTablesChange) and Syslog messages from five seconds up to a value equal to one hour (3600 seconds).

NOTE

Because LLDP Syslog messages are rate limited, some LLDP information given by the system will not match the current LLDP statistics (as shown in the **show lldp statistics** command output).

To change the minimum time interval between traps and Syslog messages, enter a command such as the following.

```
Brocade(config)#lldp snmp-notification-interval 60
```

When the above command is applied, the LLDP agent will send no more than one SNMP notification and Syslog message every 60 seconds.

Syntax: [no] lldp snmp-notification-interval <seconds>

The <seconds> variable is a value between 5 and 3600. The default is 5 seconds.

Changing the minimum time between LLDP transmissions

The LLDP transmit delay timer limits the number of LLDP frames an LLDP agent can send within a specified time frame. When you enable LLDP, the system automatically sets the LLDP transmit delay timer to two seconds. If desired, you can change the default behavior from two seconds to a value between 1 and 8192 seconds.

NOTE

The LLDP transmit delay timer must not be greater than one quarter of the LLDP transmission interval (CLI command **lldp transmit-interval**).

The LLDP transmit delay timer prevents an LLDP agent from transmitting a series of successive LLDP frames during a short time period, when rapid changes occur in LLDP. It also increases the probability that multiple changes, rather than single changes, will be reported in each LLDP frame.

To change the LLDP transmit delay timer, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#lldp transmit-delay 7
```

The above command causes the LLDP agent to wait a minimum of seven seconds after transmitting an LLDP frame and before sending another LLDP frame.

Syntax: [no] lldp transmit-delay <seconds>

The <seconds> variable is a value between 1 and 8192. The default is two seconds. Note that this value must not be greater than one quarter of the LLDP transmission interval (CLI command **lldp transmit-interval**).

Changing the interval between regular LLDP transmissions

The LLDP transmit interval specifies the number of seconds between regular LLDP packet transmissions. When you enable LLDP, by default, the device will wait 30 seconds between regular LLDP packet transmissions. If desired, you can change the default behavior from 30 seconds to a value between 5 and 32768 seconds.

To change the LLDP transmission interval, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#lldp transmit-interval 40
```

The above command causes the LLDP agent to transmit LLDP frames every 40 seconds.

Syntax: [no] lldp transmit-interval <seconds>

The <seconds> variable is a value from 5 to 32768. The default is 30 seconds.

NOTE

Setting the transmit interval or transmit holdtime multiplier, or both, to inappropriate values can cause the LLDP agent to transmit LLDPDUs with TTL values that are excessively high. This in turn can affect how long a receiving device will retain the information if it is not refreshed.

Changing the holdtime multiplier for transmit TTL

The holdtime multiplier for transmit TTL is used to compute the actual time-to-live (TTL) value used in an LLDP frame. The TTL value is the length of time the receiving device should maintain the information in its MIB. When you enable LLDP, the device automatically sets the holdtime multiplier for TTL to four. If desired, you can change the default behavior from four to a value between two and ten.

To compute the TTL value, the system multiplies the LLDP transmit interval by the holdtime multiplier. For example, if the LLDP transmit interval is 30 and the holdtime multiplier for TTL is 4, then the value 120 is encoded in the TTL field in the LLDP header.

To change the holdtime multiplier, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#lldp transmit-hold 6
```

Syntax: [no] lldp transmit-hold <value>

The <value> variable is a number from 2 to 10. The default value is 4.

NOTE

Setting the transmit interval or transmit holdtime multiplier, or both, to inappropriate values can cause the LLDP agent to transmit LLDPDUs with TTL values that are excessively high. This in turn can affect how long a receiving device will retain the information if it is not refreshed.

Changing the minimum time between port reinitializations

The LLDP re-initialization delay timer specifies the minimum number of seconds the device will wait from when LLDP is disabled on a port, until it will honor a request to re-enable LLDP on that port. When you enable LLDP, the system sets the re-initialization delay timer to two seconds. If desired, you can change the default behavior from two seconds to a value between one and ten seconds.

To set the re-initialization delay timer, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#lldp reinit-delay 5
```

The above command causes the device to wait five seconds after LLDP is disabled, before attempting to honor a request to re-enable it.

Syntax: [no] lldp reinit-delay <seconds>

The <seconds> variable is a value from 1 – 10. The default is two seconds.

LLDP TLVs advertised by the Brocade device

When LLDP is enabled on a global basis, the Brocade device will automatically advertise the following information, except for the features noted:

General system information:

- Management address
- Port description
- System capabilities
- System description (not automatically advertised)
- System name

802.1 capabilities:

- VLAN name (not automatically advertised)
- Untagged VLAN ID

802.3 capabilities:

- Link aggregation information
- MAC/PHY configuration and status
- Maximum frame size
- Power-via-MDI information (not automatically advertised)

The above TLVs are described in detail in the following sections.

NOTE

The system description, VLAN name, and power-via-MDI information TLVs are not automatically enabled. The following sections show how to enable these advertisements.

General system information for LLDP

Except for the system description, the Brocade device will advertise the following system information when LLDP is enabled on a global basis:

- Management address
- Port description
- System capabilities
- System description (not automatically advertised)
- System name

Management Address

A management address is normally an IPv4 or IPv6 address that can be used to manage the device. Management address advertising has two modes: default, or explicitly configured. The default mode is used when no addresses are configured to be advertised for a given port. If any addresses are configured to be advertised for a given port, then only those addresses are advertised. This applies across address types, so for example, if just one IPv4 address is explicitly configured to be advertised for a port, then no IPv6 addresses will be advertised for that port (since none were configured to be advertised), even if IPv6 addresses are configured within the system.

If no management address is explicitly configured to be advertised, the Brocade ICX 6650 device will use the first available IPv4 address and the first available IPv6 address (so it may advertise IPv4, IPv6 or both). A Layer 3 switch will select the first available address of each type from those configured on the following types of interfaces, in the following order of preference:

- Physical port on which LLDP will be transmitting the packet
- Virtual router interface (VE) on a VLAN that the port is a member of
- Dedicated management port
- Loopback interface
- Virtual router interface (VE) on any other VLAN
- Other physical port
- Other interface

For IPv6 addresses, link-local and anycast addresses will be excluded from these searches.

If no IP address is configured on any of the above, the port's current MAC address will be advertised.

To advertise a IPv4 management address, enter a command such as the following:

```
Brocade(config)#lldp advertise management-address ipv4 10.157.2.1 ports e 1/1/1
```

The management address will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**):

```
Management address (IPv4): 10.157.2.1
```

Syntax: [no] lldp advertise management-address ipv4 <ipv4 address> ports ethernet <stack-unit>/<slot>/<port> | all

To support an IPv6 management address, there is a similar command that has equivalent behavior as the IPv4 command.

To advertise an IPv6 management address, enter a command such as the following:

```
Brocade(config)#lldp advertise management-address ipv6 2001:DB8:90 ports e 1/1/3
```

Syntax: [no] lldp advertise management-address ipv6 <ipv6 address> ports ethernet <stack-unit>/<slot>/<port> | all

The `<ipv4 address>` or `<ipv6 address>` or both variables are the addresses that may be used to reach higher layer entities to assist discovery by network management. In addition to management addresses, the advertisement will include the system interface number associated with the management address.

Specify the ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

You can list all of the ports individually; use the keyword to specify a range of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Port description

The port description TLV identifies the port from which the LLDP agent transmitted the advertisement. The port description is taken from the ifDescr MIB object from MIB-II.

By default, the port description is automatically advertised when LLDP is enabled on a global basis. To disable advertisement of the port description, enter a command such as the following.

```
Brocade(config)#no lldp advertise port-description ports e 1/1/1 to 1/1/5
```

The port description will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
Port description: "GigabitEthernet20"
```

Syntax: `[no] lldp advertise port-description ports ethernet <stack-unit>/<slot>/<port> | all`

Specify the ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

System capabilities

The system capabilities TLV identifies the primary functions of the device and indicates whether these primary functions are enabled. The primary functions can be one or more of the following (more than one for example, if the device is both a bridge and a router):

- Repeater
- Bridge
- WLAN access point
- Router
- Telephone
- DOCSIS cable device
- Station only (devices that implement end station capability)
- Other

System capabilities for Brocade devices are based on the type of software image in use (e.g., Layer 2 switch or Layer 3 router). The enabled capabilities will be the same as the available capabilities, except that when using a router image (base or full Layer 3), if the global route-only feature is turned on, the bridge capability will not be included, since no bridging takes place.

By default, the system capabilities are automatically advertised when LLDP is enabled on a global basis. To disable this advertisement, enter a command such as the following.

```
Brocade(config)#no lldp advertise system-capabilities ports e 1/1/1 to 1/1/5
```

The system capabilities will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
System capabilities :   bridge
Enabled capabilities:   bridge
```

Syntax: [no] lldp advertise system-capabilities ports ethernet <stack-unit>/<slot>/<port> | all

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

System description

The system description is the network entity, which can include information such as the product name or model number, the version of the system hardware type, the software operating system level, and the networking software version. The information corresponds to the sysDescr MIB object in MIB-II.

To advertise the system description, enter a command such as the following.

```
Brocade(config)#lldp advertise system-description ports e 1/1/1 to 1/1/5
```

The system description will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
+ System description : "Brocade Communications, Inc.
IronWare Version 04.0.00b256T3e1 Compiled on Sep 04 2007 at 0\
3:54:29 labeled as SXS04000b256"
```

NOTE

The contents of the show command output will vary depending on which TLVs are configured to be advertised.

Syntax: [no] lldp advertise system-description ports ethernet <stack-unit>/<slot>/<port> | all

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

System name

The system name is the system administratively assigned name, taken from the sysName MIB object in MIB-II. The sysName MIB object corresponds to the name defined with the CLI command **hostname**.

By default, the system name is automatically advertised when LLDP is enabled on a global basis. To disable this advertisement, enter a command such as the following.

```
Brocade(config)#no lldp advertise system-name ports e 1/1/1 to 1/1/5
```

The system name will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
System name: "ICX6650-64 "
```

Syntax: [no] **lldp advertise system-name ports ethernet** <stack-unit>/<slot>/<port> | **all**

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

802.1 capabilities

Except for the VLAN name, the Brocade ICX 6650 device will advertise the following 802.1 attributes when LLDP is enabled on a global basis:

- VLAN name (not automatically advertised)
- Untagged VLAN ID

VLAN name

The VLAN name TLV contains the name and VLAN ID of a VLAN configured on a port. An LLDPDU may include multiple instances of this TLV, each for a different VLAN.

To advertise the VLAN name, enter a command such as the following.

```
Brocade(config)#lldp advertise vlan-name vlan 99 ports e 1/1/1 to 1/1/5
```

The VLAN name will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
VLAN name (VLAN 99): "Voice-VLAN-99"
```

Syntax: `[no] lldp advertise vlan-name vlan <vlan ID> ports ethernet <stack-unit>/<slot>/<port> | all`

For `<vlan ID>`, enter the VLAN ID to advertise.

Specify the ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

Untagged VLAN ID

The port VLAN ID TLV advertises the Port VLAN Identifier (PVID) that will be associated with untagged or priority-tagged frames. If the port is not an untagged member of any VLAN (i.e., the port is strictly a tagged port), the value zero will indicate that.

By default, the port VLAN ID is automatically advertised when LLDP is enabled on a global basis. To disable this advertisement, enter a command such as the following.

```
Brocade(config)#no lldp advertise port-vlan-id ports e 1/1/1 to 1/1/5
```

The untagged VLAN ID will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
Port VLAN ID: 99
```

Syntax: `[no] lldp advertise port-vlan-id ports ethernet <stack-unit>/<slot>/<port> | all`

Specify the ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

802.3 capabilities

Except for Power-via-MDI information, the Brocade ICX 6650 device will advertise the following 802.3 attributes when LLDP is enabled on a global basis:

- Link aggregation information
- MAC/PHY configuration and status
- Maximum frame size
- Power-via-MDI information (not automatically advertised)

Link aggregation TLV

The **link-aggregation** time, length, value (TLV) indicates the following:

- Whether the link is capable of being aggregated

- Whether the link is currently aggregated
- The primary trunk port

Brocade devices advertise link aggregation information about standard link aggregation (LACP) as well as static trunk configuration.

By default, link-aggregation information is automatically advertised when LLDP is enabled on a global basis. To disable this advertisement, enter a command such as the following.

```
Brocade(config)#no lldp advertise link-aggregation ports e 1/1/5
```

Syntax: [no] lldp advertise link-aggregation ports ethernet <stack-unit>/<slot>/<port> | all

The link aggregation advertisement will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
Link aggregation: not capable
```

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

MAC and PHY configuration status

The MAC and PHY configuration and status TLV includes the following information:

- Auto-negotiation capability and status
- Speed and duplex mode
- Flow control capabilities for auto-negotiation
- Port speed down-shift and maximum port speed advertisement
- If applicable, indicates if the above settings are the result of auto-negotiation during link initiation or of a manual set override action

The advertisement reflects the effects of the following CLI commands:

- speed-duplex
- flow-control
- gig-default
- link-config

By default, the MAC/PHY configuration and status information are automatically advertised when LLDP is enabled on a global basis. To disable this advertisement, enter a command such as the following.

```
Brocade(config)#no lldp advertise mac-phy-config-status ports e 1/1/1 to 1/1/5
```

The MAC/PHY configuration advertisement will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
+ 802.3 MAC/PHY          : auto-negotiation enabled
   Advertised capabilities: 10baseT-HD, 10baseT-FD, 100baseTX-HD,
100baseTX-FD,
   fdxSPause, fdxBPause, 1000baseT-HD, 1000baseT-FD
   Operational MAU type: 100BaseTX-FD
```

Syntax: [no] lldp advertise mac-phy-config-status ports ethernet <stack-unit>/<slot>/<port> | all

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

Maximum frame size

The maximum frame size TLV provides the maximum 802.3 frame size capability of the port. This value is expressed in octets and includes the four-octet Frame Check Sequence (FCS). The default maximum frame size is 1522. The advertised value may change depending on whether the **aggregated-vlan** or **jumbo** CLI commands are in effect.

NOTE

On 48GC modules in non-jumbo mode, the maximum size of ping packets is 1486 bytes and the maximum frame size of tagged traffic is no larger than 1581 bytes.

By default, the maximum frame size is automatically advertised when LLDP is enabled on a global basis. To disable this advertisement, enter a command such as the following.

```
Brocade(config)#no lldp advertise max-frame-size ports e 1/1/1 to 1/1/5
```

The maximum frame size advertisement will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
Maximum frame size: 1522 octets
```

Syntax: [no] lldp advertise max-frame-size ports ethernet <stack-unit>/<slot>/<port> | all

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

LLDP-MED configuration

This section provides the details for configuring LLDP-MED.

Table 45 lists the global and interface-level tasks and the default behavior/value for each task.

TABLE 45 LLDP-MED configuration tasks and default behavior / value

Task	Default behavior / value
Global CONFIG-level tasks	
Enabling LLDP-MED on a global basis	Disabled
Enabling SNMP notifications and Syslog messages for LLDP-MED topology change	Disabled
Changing the Fast Start Repeat Count	<p>The system automatically sets the fast start repeat count to 3 when a Network Connectivity Device receives an LLDP packet from an Endpoint that is newly connected to the network.</p> <p>NOTE: The LLDP-MED fast start mechanism is only intended to run on links between Network Connectivity devices and Endpoint devices. It does not apply to links between LAN infrastructure elements, including between Network Connectivity devices, or to other types of links.</p>
Interface-level tasks	
Defining a location ID	Not configured
Defining a network policy	Not configured

Enabling LLDP-MED

When LLDP is enabled globally, LLDP-MED is enabled if the LLDP-MED capabilities TLV is also enabled. By default, the LLDP-MED capabilities TLV is automatically enabled. To enable LLDP, refer to [“Enabling and disabling LLDP”](#) on page 193.

NOTE

LLDP-MED is not enabled on ports where the LLDP operating mode is receive only or transmit only. LLDP-MED is enabled on ports that are configured to both receive and transmit LLDP packets and have the LLDP-MED capabilities TLV enabled.

Enabling SNMP notifications and Syslog messages for LLDP-MED topology changes

SNMP notifications and Syslog messages for LLDP-MED provide management applications with information related to topology changes. For example, SNMP notifications can alert the system whenever a remote Endpoint device is connected to or removed from a local port. SNMP notifications identify the local port where the topology change occurred, as well as the device capability of the remote Endpoint device that was connected to or removed from the port.

When you enable LLDP-MED SNMP notifications, corresponding Syslog messages are enabled as well. When you enable LLDP-MED SNMP notifications, the device will send traps and Syslog messages when an LLDP-MED Endpoint neighbor entry is added or removed.

SNMP notifications and corresponding Syslog messages are disabled by default. To enable them, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#lldp enable snmp med-topo-change-notifications ports e 1/1/1 to 1/1/5
```

Syntax: `no lldp enable snmp med-topo-change-notifications ports ethernet <stack-unit>/<slot>/<port> | all`

Specify the ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

Changing the fast start repeat count

The fast start feature enables a Network Connectivity Device to initially advertise itself at a faster rate for a limited time when an LLDP-MED Endpoint has been newly detected or connected to the network. This feature is important where rapid availability is crucial for applications such as emergency call service location (E911).

The fast start timer starts when a Network Connectivity Device receives the first LLDP frame from a newly detected Endpoint.

The **LLDP-MED fast start repeat count** specifies the number of LLDP packets that will be sent during the LLDP-MED fast start period. By default, the device will send three packets at one-second intervals. If desired, you can change the number of packets the device will send per second, up to a maximum of 10.

NOTE

The LLDP-MED fast start mechanism is only intended to run on links between Network Connectivity devices and Endpoint devices. It does not apply to links between LAN infrastructure elements, including between Network Connectivity devices, or to other types of links.

To change the LLDP-MED fast start repeat count, enter commands such as the following.

```
Brocade(config)#lldp med fast-start-repeat-count 5
```

The above command causes the device to send five LLDP packets during the LLDP-MED fast start period.

Syntax: `[no] lldp med fast-start-repeat-count <value>`

where *value* is a number from 1 to 10, which specifies the number of packets that will be sent during the LLDP-MED fast start period. The default is 3.

Defining a location id

The LLDP-MED Location Identification extension enables the Brocade ICX 6650 device to set the physical location that an attached Class III Endpoint will use for location-based applications. This feature is important for applications such as IP telephony, for example, where emergency responders need to quickly determine the physical location of a user in North America that has just dialed 911.

For each port, you can define one or more of the following location ID formats:

- Geographic location (coordinate-based)
- Civic address
- Emergency Call Services (ECS) Emergency Location Identification Number (ELIN)

The above location ID formats are defined in the following sections.

Coordinate-based location

Coordinate-based location is based on the IETF RFC 3825 [6] standard, which specifies a Dynamic Host Configuration Protocol (DHCP) option for the coordinate-based geographic location of a client.

When you configure an Endpoint location information using the coordinate-based location, you specify the latitude, longitude, and altitude, along with **resolution indicators** (a measure of the accuracy of the coordinates), and the reference **datum** (the map used for the given coordinates).

To configure a coordinate-based location for an Endpoint device, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#lldp med location-id coordinate-based latitude
-78.303 resolution 20 longitude 34.27 resolution 18 altitude meters 50 resolution
16 wgs84
```

Syntax: [no] lldp med location-id coordinate-based

latitude <degrees> **resolution** <bits>

longitude <degrees> **resolution** <bits>

altitude floors <number> **resolution** <bits> | **meters** <number> **resolution** <bits>
<datum>

latitude <degrees> is the angular distance north or south from the earth equator measured through 90 degrees. Positive numbers indicate a location north of the equator and negative numbers indicate a location south of the equator.

resolution <bits> specifies the precision of the value given for latitude. A smaller value increases the area within which the device is located. For latitude, enter a number between 1 and 34.

longitude <degrees> is the angular distance from the intersection of the zero meridian. Positive values indicate a location east of the prime meridian and negative numbers indicate a location west of the prime meridian.

resolution <bits> specifies the precision of the value given for longitude. A smaller value increases the area within which the device is located. For longitude resolution, enter a number between 1 and 34.

altitude floors <number> is the vertical elevation of a building above the ground, where 0 represents the floor level associated with the ground level at the main entrance and larger values represent floors that are above (higher in altitude) floors with lower values. For example, 2 for the 2nd floor. Sub-floors can be represented by non-integer values. For example, a mezzanine between floor 1 and floor 2 could be represented as 1.1. Similarly, the mezzanines between floor 4 and floor 5 could be represented as 4.1 and 4.2 respectively. Floors located below ground level could be represented by negative values.

resolution <bits> specifies the precision of the value given for altitude. A smaller value increases the area within which the device is located. For floors resolution, enter the value 0 if the floor is unknown, or 30 if a valid floor is being specified.

altitude meters <number> is the vertical elevation in number of meters, as opposed to floors.

resolution <bits> specifies the precision of the value given for altitude. A smaller value increases the area within which the device is located. For meters resolution, enter a value from 0 to 30.

<Datum> is the map used as the basis for calculating the location. Specify one of the following:

- **wgs84** – (geographical 3D) – World Geodesic System 1984, CRS Code 4327, Prime Meridian Name: Greenwich
- **nad83-navd88** – North American Datum 1983, CRS Code 4269, Prime Meridian Name: Greenwich; The associated vertical datum is the North American Vertical Datum of 1988 (NAVD88). Use this datum when referencing locations on land. If land is near tidal water, use nad83-mllw (below).
- **nad83-mllw** – North American Datum 1983, CRS Code 4269, Prime Meridian Name: Greenwich; The associated vertical datum is mean lower low water (MLLW). Use this datum when referencing locations on water, sea, or ocean.

Example coordinate-based location configuration

The following shows an example coordinate-based location configuration for the Sears Tower, at the following location.

103rd Floor
233 South Wacker Drive
Chicago, IL 60606

```
Brocade(config)#lldp med location-id coordinate-based latitude 41.87884
resolution 18 longitude 87.63602 resolution 18 altitude floors 103 resolution 30
wgs84
```

The above configuration shows the following:

- Latitude is 41.87884 degrees north (or 41.87884 degrees).
- Longitude is 87.63602 degrees west (or 87.63602 degrees).
- The latitude and longitude resolution of 18 describes a geo-location area that is latitude 41.8769531 to latitude 41.8789062 and extends from -87.6367188 to -87.6347657 degrees longitude. This is an area of approximately 373412 square feet (713.3 ft. x 523.5 ft.).
- The location is inside a structure, on the 103rd floor.
- The WGS 84 map was used as the basis for calculating the location.

Example coordinate-based location advertisement

The coordinate-based location advertisement will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```

+ MED Location ID
  Data Format: Coordinate-based
  Latitude Resolution : 20 bits
  Latitude Value     : -78.303 degrees
  Longitude Resolution : 18 bits
  Longitude Value    : 34.27 degrees
  Altitude Resolution : 16 bits
  Altitude Value     : 50. meters
  Datum             : WGS 84

```

Configuring civic address location

When you configure a media Endpoint location using the address-based location, you specify the location the entry refers to, the country code, and the elements that describe the civic or postal address.

To configure a civic address-based location for LLDP-MED, enter commands such as the following at the Global CONFIG level of the CLI.

```

Brocade(config)#lldp med location-id civic-address refers-to client country US
elem 1 CA elem 3 "Santa Clara" elem 6 "4980 Great America Pkwy" elem 24 95054 elem
27 5 elem 28 551 elem 29 office elem 23 "John Doe"

```

Syntax: `[no] lldp med location-id civic-address refers-to <elem> country <country code> elem <CA type> <value> [elem <CA type> <value>] [elem <CA type> <value>]....`

refers-to <elem> describes the location that the entry refers to. Specify one of the following:

- client
- dhcp-server
- network-element

where **dhcp-server** or **network-element** should only be used if it is known that the Endpoint is in close physical proximity to the DHCP server or network element.

<country code> is the two-letter ISO 3166 country code in capital ASCII letters.

Example

- CA – Canada
- DE – Germany
- JP – Japan
- KR – Korea
- US – United States

<CA type> is a value from 0 – 255, that describes the civic address element. For example, a CA type of 24 specifies a postal or zip code. Valid elements and their types are listed in [Table 46](#).

<value> is the actual value of the elem <CA type>, above. For example, 95123 for the postal or zip code. Acceptable values are listed in [Table 46](#), below.

NOTE

If the value of an element contains one or more spaces, use double quotation marks (") at the beginning and end of the string. For example, `elem 3 "Santa Clara"`.

TABLE 46 Elements used with civic address

Civic Address (CA) type	Description	Acceptable values / examples
0	Language	The ISO 639 language code used for presenting the address information.
1	National subdivisions (state, canton, region, province, or prefecture)	Examples: Canada – Province Germany – State Japan – Metropolis Korea – Province United States – State
2	County, parish, gun (JP), or district (IN)	Examples: Canada – County Germany – County Japan – City or rural area Korea – County United States – County
3	City, township, or shi (JP)	Examples: Canada – City or town Germany – City Japan – Ward or village Korea – City or village United States – City or town
4	City division, borough, city district, ward, or chou (JP)	Examples: Canada – N/A Germany – District Japan – Town Korea – Urban district United States – N/A
5	Neighborhood or block	Examples: Canada – N/A Germany – N/A Japan – City district Korea – Neighborhood United States – N/A
6	Street	Examples: Canada – Street Germany – Street Japan – Block Korea – Street United States – Street
16	Leading street direction	N (north), E (east), S (south), W (west), NE, NW, SE, SW
17	Trailing street suffix	N (north), E (east), S (south), W (west), NE, NW, SE, SW
18	Street suffix	Acceptable values for the United States are listed in the United States Postal Service Publication 28 [18], Appendix C. Example: Ave, Place
19	House number	The house number (street address) Example: 1234

TABLE 46 Elements used with civic address (Continued)

Civic Address (CA) type	Description	Acceptable values / examples
20	House number suffix	A modifier to the house number. It does not include parts of the house number. Example: A, 1/2
21	Landmark or vanity address	A string name for a location. It conveys a common local designation of a structure, a group of buildings, or a place that helps to locate the place. Example: UC Berkeley
22	Additional location information	An unstructured string name that conveys additional information about the location. Example: west wing
23	Name (residence and office occupant)	Identifies the person or organization associated with the address. Example: Textures Beauty Salon
24	Postal / zip code	The valid postal / zip code for the address. Example: 95054-1234
25	Building (structure)	The name of a single building if the street address includes more than one building or if the building name is helpful in identifying the location. Example: Law Library
26	Unit (apartment, suite)	The name or number of a part of a structure where there are separate administrative units, owners, or tenants, such as separate companies or families who occupy that structure. Common examples include suite or apartment designations. Example: Apt 27
27	Floor	Example: 4
28	Room number	The smallest identifiable subdivision of a structure. Example: 7A
29	Placetype	The type of place described by the civic coordinates. For example, a home, office, street, or other public space. Example: Office
30	Postal community name	When the postal community name is defined, the civic community name (typically CA type 3) is replaced by this value. Example: Alviso
31	Post office box (P.O. box)	When a P.O. box is defined, the street address components (CA types 6, 16, 17, 18, 19, and 20) are replaced with this value. Example: P.O. Box 1234
32	Additional code	An additional country-specific code that identifies the location. For example, for Japan, this is the Japan Industry Standard (JIS) address code. The JIS address code provides a unique address inside of Japan, down to the level of indicating the floor of the building.

TABLE 46 Elements used with civic address (Continued)

Civic Address (CA) type	Description	Acceptable values / examples
128	Script	The script (from ISO 15924 [14]) used to present the address information. Example: Latn NOTE: If not manually configured, the system assigns the default value Latn
255	Reserved	

Example civic address location advertisement

The Civic address location advertisement will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
+ MED Location ID
  Data Format: Civic Address
  Location of: Client
  Country    : "US"
  CA Type    : 1
  CA Value   : "CA"
  CA Type    : 3
  CA Value   : "Santa Clara"
  CA Type    : 6
  CA Value   : "4980 Great America Pkwy."
  CA Type    : 24
  CA Value   : "95054"
  CA Type    : 27
  CA Value   : "5"
  CA Type    : 28
  CA Value   : "551"
  CA Type    : 29
  CA Value   : "office"
  CA Type    : 23
  CA Value   : "John Doe"
```

Configuring emergency call service

The Emergency Call Service (ECS) location is used specifically for Emergency Call Services applications.

When you configure a media Endpoint location using the emergency call services location, you specify the Emergency Location Identification Number (ELIN) from the North America Numbering Plan format, supplied to the Public Safety Answering Point (PSAP) for ECS purposes.

To configure an ECS-based location for LLDP-MED, enter a command such as the following at the Global CONFIG level of the CLI.

```
Brocade(config)#lldp med location-id ecs-elin 4082071700
```

Syntax: [no] lldp med location-id ecs-elin <number> ports ethernet <stack-unit>/<slot>/<port> | all

The <number> variable is a number from 10 to 25 digits in length.

Specify the ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Example ECS ELIN location advertisements

The ECS ELIN location advertisement will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
+ MED Location ID
  Data Format: ECS ELIN
  Value      : 4082071700
```

Defining an LLDP-MED network policy

An LLDP-MED network policy defines an Endpoint VLAN configuration (VLAN type and VLAN ID) and associated Layer 2 and Layer 3 priorities that apply to a specific set of applications on a port.

NOTE

This feature applies to applications that have specific real-time network policy requirements, such as interactive voice or video services. It is not intended to run on links other than between Network Connectivity devices and Endpoints, and therefore does not advertise the multitude of network policies that frequently run on an aggregated link.

To define an LLDP-MED network policy for an Endpoint, enter a command such as the following.

```
Brocade(config)#lldp med network-policy application voice tagged vlan 99 priority
3 dscp 22 port e 1/1/3
```

The network policy advertisement will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
+ MED Network Policy
  Application Type : Voice
  Policy Flags    : Known Policy, Tagged
  VLAN ID        : 99
  L2 Priority     : 3
  DSCP Value     : 22
```

NOTE

Endpoints will advertise a policy as “unknown” in the **show lldp neighbor detail** command output, if it is a policy that is required by the Endpoint and the Endpoint has not yet received it.

LLDP-MED network policy configuration syntax

The CLI syntax for defining an LLDP-MED network policy differs for tagged, untagged, and priority tagged traffic. Refer to the appropriate syntax, below.

For tagged traffic

Syntax: [no] lldp med network-policy application <application type> tagged vlan <vlan ID> priority <0 – 7> dscp <0 – 63> ports ethernet <stack-unit>/<slot>/<port> | all

For untagged traffic

Syntax: [no] lldp med network-policy application <application type> untagged dscp <0 – 63> ports ethernet <stack-unit>/<slot>/<port> | all

For priority-tagged traffic

Syntax: [no] lldp med network-policy application <application type> priority-tagged priority <0 – 7> dscp <0 – 63> ports ethernet <stack-unit>/<slot>/<port> | all

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

The <application type> variable indicates the primary function of the applications defined by this network policy. Application type can be one of the following:

- **guest-voice** – Limited voice service for guest users and visitors with their own IP telephony handsets or similar devices that support interactive voice services.
- **guest-voice-signaling** – Limited voice service for use in network topologies that require a different policy for guest voice signaling than for guest voice media.
- **softphone-voice** – Softphone voice service for use with multi-media applications that work in association with VoIP technology, enabling phone calls direct from a PC or laptop. Softphones do not usually support multiple VLANs, and are typically configured to use an untagged VLAN or a single tagged data-specific VLAN. Note that when a network policy is defined for use with an untagged VLAN, the Layer 2 priority field is ignored and only the DSCP value is relevant.
- **streaming-video** – Applies to broadcast- or multicast-based video content distribution and similar applications that support streaming video services requiring specific network policy treatment. Video applications that rely on TCP without buffering would not be an intended use of this application type.
- **video-conferencing** – Applies to dedicated video conferencing equipment and similar devices that support real-time interactive video/audio services.
- **video-signaling** – For use in network topologies that require a separate policy for video signaling than for video media. Note that this application type should not be advertised if all the same network policies apply as those advertised in the video conferencing policy TLV.
- **voice** – For use by dedicated IP telephony handsets and similar devices that support interactive voice services.
- **voice-signaling** – For use in network topologies that require a different policy for voice signaling than for voice media. Note that this application type should not be advertised if all the same network policies apply as those advertised in the voice policy TLV.
- **tagged vlan** <vlan id> specifies the tagged VLAN that the specified application type will use.
- **untagged** indicates that the device is using an untagged frame format.
- **priority-tagged** indicates that the device uses priority-tagged frames. In this case, the device uses the default VLAN (PVID) of the ingress port.

- **priority** <0 – 7> indicates the Layer 2 priority value to be used for the specified application type. Enter 0 to use the default priority.
- **dscp** <0 – 63> specifies the Layer 3 Differentiated Service codepoint priority value to be used for the specified application type. Enter 0 to use the default priority.

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

LLDP-MED attributes advertised by the Brocade device

LLDP-MED attributes are only advertised on a port if LLDP-MED is enabled (which is done by enabling the LLDP-MED capabilities TLV), the port operating mode is *receive* and *transmit* (the default), and the port has received an LLDP-MED advertisement from an Endpoint. By default, the Brocade device will automatically advertise the following LLDP-MED attributes when the above criteria are met:

- LLDP-MED capabilities
- Location ID
- Network policy
- Power-via-MDI information

NOTE

Although the Location ID and Network policy attributes are automatically advertised, they will have no effect until they are actually defined.

LLDP-MED capabilities

When enabled, LLDP-MED is enabled, and the LLDP-MED capabilities TLV is sent whenever any other LLDP-MED TLV is sent. When disabled, LLDP-MED is disabled and no LLDP-MED TLVs are sent.

The LLDP-MED capabilities advertisement includes the following information:

- The supported LLDP-MED TLVs
- The device type (Network Connectivity device or Endpoint (Class 1, 2, or 3))

By default, LLDP-MED information is automatically advertised when LLDP-MED is enabled. To disable this advertisement, enter a command such as the following.

```
Brocade(config)#no lldp advertise med-capabilities ports e 1/1/1 to 1/1/5
```

NOTE

Disabling the LLDP-MED capabilities TLV disables LLDP-MED.

To re-enable the LLDP-MED Capabilities TLV (and LLDP-MED) after it has been disabled, enter a command such as the following.

```
Brocade(config)#lldp advertise med-capabilities ports e 1/1/1 to 1/1/5
```

The LLDP-MED capabilities advertisement will appear similar to the following on the remote device, and in the CLI display output on the Brocade device (**show lldp local-info**).

```
+ MED capabilities: capabilities, networkPolicy, location, extendedPSE
MED device type : Network Connectivity
```

Syntax: [no] lldp advertise med-capabilities ports ethernet <stack-unit>/<slot>/<port> | all

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually. Note that using the keyword **all** may cause undesirable effects on some ports. For example, if you configure all ports to advertise their VLAN name, and the configuration includes ports that are not members of any VLAN, the system will warn of the misconfigurations on non-member VLAN ports. The configuration will be applied to all ports, however, the ports that are not members of any VLAN will not send VLAN name advertisements.

Displaying LLDP statistics and configuration settings

You can use the following CLI **show** commands to display information about LLDP settings and statistics:

- **show lldp** – Displays a summary of the LLDP configuration settings.
- **show lldp statistics** – Displays LLDP global and per-port statistics.
- **show lldp neighbors** – Displays a list of the current LLDP neighbors.
- **show lldp neighbors detail** – Displays the details of the latest advertisements received from LLDP neighbors.
- **show lldp local-info** – Displays the details of the LLDP advertisements that will be transmitted on each port.

This above **show** commands are described in this section.

LLDP configuration summary

To display a summary of the LLDP configuration settings on the device, enter the **show lldp** command at any level of the CLI.

The following shows an example report.

```
Brocade#show lldp
LLDP transmit interval      : 10 seconds
LLDP transmit hold multiplier : 4 (transmit TTL: 40 seconds)
LLDP transmit delay        : 1 seconds
LLDP SNMP notification interval : 5 seconds
LLDP reinitialize delay     : 1 seconds
LLDP-MED fast start repeat count : 3

LLDP maximum neighbors      : 392
LLDP maximum neighbors per port : 4
```

Syntax: show lldp

The following table describes the information displayed by the **show lldp statistics** command.

Field	Description
LLDP transmit interval	The number of seconds between regular LLDP packet transmissions.
LLDP transmit hold multiplier	The multiplier used to compute the actual time-to-live (TTL) value of an LLDP advertisement. The TTL value is the transmit interval multiplied by the transmit hold multiplier.
LLDP transmit delay	The number of seconds the LLDP agent will wait after transmitting an LLDP frame and before transmitting another LLDP frame.
LLDP SNMP notification interval	The number of seconds between transmission of SNMP LLDP traps (IldpRemTablesChange) and SNMP LLDP-MED traps (IldpXMedTopologyChangeDetected).
LLDP reinitialize delay	The minimum number of seconds the device will wait from when LLDP is disabled on a port, until a request to re-enable LLDP on that port will be honored.
LLDP-MED fast start repeat count	The number of seconds between LLDP frame transmissions when an LLDP-MED Endpoint is newly detected.
LLDP maximum neighbors	The maximum number of LLDP neighbors for which LLDP data will be retained, per device.
LLDP maximum neighbors per port	The maximum number of LLDP neighbors for which LLDP data will be retained, per port.

Displaying LLDP statistics

The **show lldp statistics** command displays an overview of LLDP neighbor detection on the device, as well as packet counters and protocol statistics. The statistics are displayed on a global basis.

The following shows an example report.

8 LLDP-MED attributes advertised by the Brocade device

```
Brocade#show lldp statistics
Last neighbor change time: 23 hours 50 minutes 40 seconds ago

Neighbor entries added      : 14
Neighbor entries deleted    : 5
Neighbor entries aged out   : 4
Neighbor advertisements dropped : 0
```

Port	Tx Pkts	Rx Pkts	Rx Pkts	Rx Pkts	Rx TLVs	Rx TLVs	Neighbors
	Total	Total	w/Errors	Discarded	Unrecognz	Discarded	Aged Out
1	60963	75179	0	0	0	0	4
2	0	0	0	0	0	0	0
3	60963	60963	0	0	0	0	0
4	60963	121925	0	0	0	0	0
5	0	0	0	0	0	0	0
6	0	0	0	0	0	0	0
7	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0
9	0	0	0	0	0	0	0
10	60974	0	0	0	0	0	0
11	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0
13	0	0	0	0	0	0	0
14	0	0	0	0	0	0	0

Syntax: show lldp statistics

NOTE

You can reset LLDP statistics using the CLI command **clear LLDP statistics**. Refer to [“Resetting LLDP statistics”](#) on page 223.

The following table describes the information displayed by the **show lldp statistics** command.

Field	Description
Last neighbor change time	The elapsed time (in hours, minutes, and seconds) since a neighbor last advertised information. For example, the elapsed time since a neighbor was last added, deleted, or its advertised information changed.
Neighbor entries added	The number of new LLDP neighbors detected since the last reboot or since the last time the clear lldp statistics all command was issued.
Neighbor entries deleted	The number of LLDP neighbors deleted since the last reboot or since the last time the clear lldp statistics all command was issued.
Neighbor entries aged out	The number of LLDP neighbors dropped on all ports after the time-to-live expired. Note that LLDP entries age out naturally when a port cable or module is disconnected or when a port becomes disabled. However, if a disabled port is re-enabled, the system will delete the old LLDP entries.
Neighbor advertisements dropped	The number of valid LLDP neighbors the device detected, but could not add. This can occur, for example, when a new neighbor is detected and the device is already supporting the maximum number of neighbors possible. This can also occur when an LLDPDU is missing a mandatory TLV or is not formatted correctly.
Port	The local port number.
Tx Pkts Total	The number of LLDP packets the port transmitted.

Field	Description
Rx Pkts Total	The number of LLDP packets the port received.
Rx Pkts w/Errors	The number of LLDP packets the port received that have one or more detectable errors.
Rx Pkts Discarded	The number of LLDP packets the port received then discarded.
Rx TLVs Unrecognz	The number of TLVs the port received that were not recognized by the LLDP local agent. Unrecognized TLVs are retained by the system and can be viewed in the output of the show LLDP neighbors detail command or retrieved through SNMP.
Rx TLVs Discarded	The number of TLVs the port received then discarded.
Neighbors Aged Out	The number of times a neighbor information was deleted because its TTL timer expired.

Displaying LLDP neighbors

The **show lldp neighbors** command displays a list of the current LLDP neighbors per port.

The following shows an example report.

```
Brocade#show lldp neighbors
Lcl Port Chassis ID      Port ID      Port Description      System Name
1/1/1    748e.f80c.5f40  748e.f80c.5f40  10GigabitEthernet1/3/1  ICX6650-64 Ro~
1/1/2    748e.f80c.5f40  748e.f80c.5f40  10GigabitEthernet1/3/2  ICX6650-64 Ro~
1/1/3    748e.f80c.5f40  748e.f80c.5f40  10GigabitEthernet1/3/3  ICX6650-64 Ro~
1/1/4    748e.f80c.5f40  748e.f80c.5f40  10GigabitEthernet1/3/4  ICX6650-64 Ro~
1/1/53   748e.f80c.5f40  748e.f80c.5f40  10GigabitEthernet1/3/5  ICX6650-64 Ro~
1/1/54   748e.f80c.5f40  748e.f80c.5f40  10GigabitEthernet1/3/6  ICX6650-64 Ro~
1/1/55   748e.f80c.5f40  748e.f80c.5f40  10GigabitEthernet1/3/7  ICX6650-64 Ro~
1/1/56   748e.f80c.5f40  748e.f80c.5f40  10GigabitEthernet1/3/8  ICX6650-64 Ro~
```

Syntax: show lldp neighbors

The following table describes the information displayed by the **show lldp neighbors** command.

Field	Description
Lcl Port	The local LLDP port number.
Chassis ID	The identifier for the chassis. Brocade devices use the base MAC address of the device as the Chassis ID.
Port ID	The identifier for the port. Brocade devices use the permanent MAC address associated with the port as the port ID.
Port Description	The description for the port. Brocade devices use the ifDescr MIB object from MIB-II as the port description.
System Name	The administratively-assigned name for the system. Brocade devices use the sysName MIB object from MIB-II, which corresponds to the CLI hostname command setting. NOTE: A tilde (~) at the end of a line indicates that the value in the field is too long to display in full and is truncated.

Displaying LLDP neighbors detail

The **show lldp neighbors detail** command displays the LLDP advertisements received from LLDP neighbors.

The following shows an example **show lldp neighbors detail ports ethernet 1/1/1** report.

NOTE

The **show lldp neighbors detail** output will vary depending on the data received. Also, values that are not recognized or do not have a recognizable format, may be displayed in hexadecimal binary form.

```
Brocade#show lldp neighbors detail ports ethernet 1/1/1
Local port: 1/1/1
Neighbor: 748e.f80c.5f40, TTL 110 seconds
+ Chassis ID (MAC address): 748e.f80c.5f40
+ Port ID (MAC address): 748e.f80c.5f40
+ Time to live: 120 seconds
+ System name      : "ICX6650-64 Router"
+ Port description  : "10GigabitEthernet1/3/1"
+ System capabilities : bridge, router
  Enabled capabilities: bridge, router
+ 802.3 MAC/PHY      : auto-negotiation supported, but disabled
  Operational MAU type : b40GbaseCR4
+ Link aggregation: not capable
+ Maximum frame size: 1522 octets
+ Port VLAN ID: 1
+ Management address (IPv4): 10.20.79.110
```

A backslash (\) at the end of a line indicates that the text continues on the next line.

Except for the following field, the fields in the above output are described in the individual TLV advertisement sections in this chapter.

Field	Description
Neighbor	The source MAC address from which the packet was received, and the remaining TTL for the neighbor entry.

Syntax: **show lldp neighbors detail** [**ports ethernet** <stack-unit>/<slot>/<port> | **all**]

If you do not specify any ports or use the keyword **all**, by default, the report will show the LLDP neighbor details for all ports.

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Displaying LLDP configuration details

The **show lldp local-info** command displays the local information advertisements (TLVs) that will be transmitted by the LLDP agent.

NOTE

The **show lldp local-info** output will vary based on LLDP configuration settings.

The following shows an example report.

```
Brocade#show lldp local-info ports ethernet 1/1/1
Local port: 1/1/1
+ Chassis ID (MAC address): 748e.f80c.5f40
+ Port ID (MAC address): 748e.f80c.5f40
+ Time to live: 120 seconds
+ System name      : "ICX6650-64 Router"
+ Port description  : "10GigabitEthernet1/1/1"
+ System capabilities : bridge, router
  Enabled capabilities: bridge, router
+ 802.3 MAC/PHY      : auto-negotiation supported, but disabled
  Operational MAU type : b10GbaseCX4
+ Link aggregation: not capable
+ Maximum frame size: 1522 octets
+ Port VLAN ID: 1
+ Management address (IPv4): 10.20.79.91
```

NOTE

The contents of the **show** output will vary depending on which TLVs are configured to be advertised.

A backslash (\) at the end of a line indicates that the text continues on the next line.

The fields in the above output are described in the individual TLV advertisement sections in this chapter.

Syntax: **show lldp local-info** [**ports ethernet** <stack-unit>/<slot>/<port> | **all**]

If you do not specify any ports or use the keyword **all**, by default, the report will show the local information advertisements for all ports.

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Resetting LLDP statistics

To reset LLDP statistics, enter the **clear lldp statistics** command at the Global CONFIG level of the CLI. The Brocade device will clear the global and per-port LLDP neighbor statistics on the device (refer to [“Displaying LLDP statistics”](#) on page 219).

```
Brocade#clear lldp statistics
```

Syntax: **clear lldp statistics** [**ports ethernet** <stack-unit>/<slot>/<port> | **all**]

If you do not specify any ports or use the keyword **all**, by default, the system will clear lldp statistics on all ports.

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

8 Clearing cached LLDP neighbor information

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Clearing cached LLDP neighbor information

The Brocade device clears cached LLDP neighbor information after a port becomes disabled and the LLDP neighbor information ages out. However, if a port is disabled then re-enabled before the neighbor information ages out, the device will clear the cached LLDP neighbor information when the port is re-enabled.

If desired, you can manually clear the cache. For example, to clear the cached LLDP neighbor information for port e 1/1/1, enter the following command at the Global CONFIG level of the CLI.

```
Brocade#clear lldp neighbors ports e 1/1/1
```

Syntax: `clear lldp neighbors [ports ethernet <stack-unit>/<slot>/<port> | all]`

If you do not specify any ports or use the keyword **all**, by default, the system will clear the cached LLDP neighbor information for all ports.

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can list all of the ports individually, use the keyword **to** to specify ranges of ports, or a combination of both. To apply the configuration to all ports on the device, use the keyword **all** instead of listing the ports individually.

Hardware Component Monitoring

In this chapter

- [Digital optical monitoring](#) 225

[Table 47](#) lists the Brocade ICX 6650 switch and the hardware monitoring features the switch supports. These features are supported in full Layer 3 software images.

TABLE 47 Supported hardware monitoring features

Feature	Brocade ICX 6650
Digital optical monitoring	Yes

Digital optical monitoring

You can configure your Brocade ICX 6650 device to monitor optical transceivers in the system, either globally or by specified ports. When this feature is enabled, the system will monitor the temperature and signal power levels for the optical transceivers in the specified ports. Console messages and Syslog messages are sent when optical operating conditions fall below or rise above the XFP, SFP, and SFP+ manufacturer recommended thresholds.

Digital optical monitoring configuration limitations

A Brocade ICX 6650 switch can monitor a maximum of 24 SFPs and 12 XFPs.

Enabling digital optical monitoring

To enable optical monitoring on all Brocade ICX 6650-qualified optics installed in the device, use the following command.

```
Brocade(config)#optical-monitor
```

To enable optical monitoring on a specific port, use the following command.

```
Brocade(config)#interface ethernet 1/1/1
Brocade(config-if-e10000-1/1/1)#optical-monitor
```

To enable optical monitoring on a range of ports, use the following command.

```
Brocade(config)#interface ethernet 1/1/1 to 1/1/2
Brocade(config-mif-1/1/1-1/1/2)#optical-monitor
```

Syntax: `[no] optical-monitor`

Use the **no** form of the command to disable digital optical monitoring.

Setting the alarm interval

You can optionally change the interval between which alarms and warning messages are sent. The default interval is three minutes. To change the interval, use the following command.

```
Brocade(config)#interface ethernet 1/1/1 to 1/1/2
Brocade(config-mif-1/1/1-1/1/2)#optical-monitor 10
```

Syntax: [no] **optical-monitor** [<alarm-interval>]

For <alarm-interval>, enter a value between 1 and 65535. Enter 0 to disable alarms and warning messages.

NOTE

The commands **no optical-monitor** and **optical-monitor 0** perform the same function. That is, they both disable digital optical monitoring.

Displaying information about installed media

Use the **show media**, **show media slot**, and **show media ethernet** commands to obtain information about the media devices installed per device, per slot, and per port. The results displayed from these commands provide the Type, Vendor, Part number, Version and Serial number of the SFP, SFP+, or XFP optical device installed in the port. If there is no SFP, SFP+, or XFP optical device installed in a port, the "Type" field will display "EMPTY".

Use the **show media** command to obtain information about the media devices installed in a device.

```
Brocade#show media
Port 1/1/1:  Type : 10GE Twinax      1M (SFP +)
Port 1/1/2:  Type : 10GE Twinax      1M (SFP +)
Port 1/1/3:  Type : 10GE Twinax      1M (SFP +)
Port 1/1/4:  Type : 10GE Twinax      1M (SFP +)
Port 1/1/5:  Type : 1G M-TX(SFP)
Port 1/1/6:  Type : 1G M-TX(SFP)
Port 1/1/7:  Type : EMPTY
Port 1/1/8:  Type : EMPTY
Port 1/1/9:  Type : 10GE Twinax      3M (SFP +)
Port 1/1/10: Type : 10GE Twinax      3M (SFP +)
Port 1/1/11: Type : EMPTY
Port 1/1/12: Type : EMPTY
Port 1/1/13: Type : EMPTY
Port 1/1/14: Type : EMPTY
Port 1/1/15: Type : 10GE SR 300m (SFP +)
Port 1/1/16: Type : EMPTY
Port 1/1/17: Type : EMPTY
Port 1/1/18: Type : EMPTY
Port 1/1/19: Type : EMPTY
Port 1/1/20: Type : EMPTY
Port 1/1/21: Type : EMPTY
Port 1/1/22: Type : EMPTY
Port 1/1/23: Type : EMPTY
Port 1/1/24: Type : EMPTY
Port 1/1/25: Type : 10GE Twinax      3M (SFP +)
Port 1/1/26: Type : 10GE Twinax      3M (SFP +)
Port 1/1/27: Type : EMPTY
Port 1/1/28: Type : EMPTY
Port 1/1/29: Type : EMPTY
```

```

Port 1/1/30: Type : EMPTY
Port 1/1/31: Type : EMPTY
Port 1/1/32: Type : EMPTY
Port 1/1/33: Type : EMPTY
Port 1/1/34: Type : EMPTY
Port 1/1/35: Type : EMPTY
Port 1/1/36: Type : EMPTY
Port 1/1/37: Type : EMPTY
Port 1/1/38: Type : EMPTY
Port 1/1/39: Type : 10GE Twinax    3M (SFP +)
Port 1/1/40: Type : 10GE Twinax    3M (SFP +)
Port 1/1/41: Type : EMPTY
Port 1/1/42: Type : EMPTY
Port 1/1/43: Type : EMPTY
Port 1/1/44: Type : EMPTY
Port 1/1/45: Type : EMPTY
Port 1/1/46: Type : EMPTY
Port 1/1/47: Type : EMPTY
Port 1/1/48: Type : EMPTY
Port 1/1/49: Type : EMPTY
Port 1/1/50: Type : EMPTY
Port 1/1/51: Type : EMPTY
Port 1/1/52: Type : EMPTY
Port 1/1/53: Type : 10GE Twinax    1M (SFP +)
Port 1/1/54: Type : 10GE Twinax    1M (SFP +)
Port 1/1/55: Type : 10GE Twinax    1M (SFP +)
Port 1/1/56: Type : 10GE Twinax    1M (SFP +)
Port 1/2/1:  Type : 40GE-SR4 100m (QSFP+)
Port 1/2/2:  Type : EMPTY
Port 1/2/3:  Type : 40GE-SR4 100m (QSFP+)
Port 1/2/4:  Type : 40GE-SR4 100m (QSFP+)
Port 1/3/1:  Type : EMPTY
Port 1/3/2:  Type : EMPTY
Port 1/3/3:  Type : EMPTY
Port 1/3/4:  Type : EMPTY
Port 1/3/5:  Type : EMPTY
Port 1/3/6:  Type : EMPTY
Port 1/3/7:  Type : EMPTY
Port 1/3/8:  Type : EMPTY

```

Use the **show media slot** command to obtain information about the media device installed in a slot.

```

Brocade#show media slot 1
Port 1/1/1: Type : 10GE Cable 1m (SFP +)
            Vendor: BROCADE           Version: A
            Part# : 58-0000051-01      Serial#: MAM112210012JNF1
Port 1/1/2: Type : 10GE Cable 1m (SFP +)
            Vendor: BROCADE           Version: A
            Part# : 58-0000051-01      Serial#: MAM112210012JNF2
Port 1/1/3: Type : 10GE Cable 1m (SFP +)
            Vendor: BROCADE           Version: A
            Part# : 58-0000051-01      Serial#: MAM112210012JNF3
Port 1/1/4: Type : 10GE Cable 1m (SFP +)
            Vendor: BROCADE           Version: A
            Part# : 58-0000051-01      Serial#: MAM112210012JNF4
Port 1/1/5: Type : EMPTY
Port 1/1/6: Type : EMPTY
Port 1/1/7: Type : EMPTY
Port 1/1/8: Type : EMPTY
Port 1/1/9: Type : 10GE SR 300m (SFP +)

```

```

Vendor: BROCADE          Version: A
Part# : 57-0000075-01    Serial#: AAF209450000A9K
Port 1/1/10: Type : 10GE LR 10km (SFP +)
Vendor: BROCADE          Version: A
Part# : 57-0000076-01    Serial#: ADF209100000D4P
Port 1/1/11: Type : 1G M-SX(SFP)
Vendor : Brocade         Version:
Part# : AFBR-5715PZ-FD   Serial#: AA0910S4YAF
Port 1/1/12: Type : 1G M-SX(SFP)
Vendor : Brocade         Version:
Part# : AFBR-5710PZ-FD   Serial#: AM0850SCTHH

```

Use the **show media ethernet** command to obtain information about the media device installed in a port.

```

Brocade#show media ethernet 1/2/1
Port 1/2/1: Type : 40GE-SR4 100m (QSFP+)
Vendor: BROCADE          Version: A
Part# : 57-1000129-01    Serial#: ATA111491001893

```

Syntax: **show media** [**slot** <slot> | **ethernet** <stack-unit>/<slot>/<port>]

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

Viewing optical monitoring information

You can view temperature and power information for qualified SFP, SFP+, and QSFP+ transceivers installed in a Brocade ICX 6650 device.

Use the **show optic** command to view information about an SFP, SFP+, and QSFP+ transceivers installed in a particular port. The following shows example output from a 40GBASE-SR4 fiber optic. The fiber optic has 4 channels for TX, RX.

Optical monitoring feature will not work in the following scenarios:

- The port is DOWN.
- The the optic module does not support optical monitoring.

```

Brocade(config)#show optic 1/2/1
40GBASE_SR4
=====
Port  Temperature      Voltage      Rx Power      Tx Bias Current
+---+-----+-----+-----+-----+
1/2/1  42.6640 C    005.1911 dBm -001.1560 dBm  7.332 mA
      Normal      Normal      Normal      Normal

Chan Rx Power #1  Rx Power #2    Rx Power #3    Rx Power #4
+---+-----+-----+-----+-----+
      -001.1560 dBm -001.0846 dBm -001.3507 dBm -001.1221 dBm
      Normal      Normal      Normal      Normal

Chan Tx Bias #1    Tx Bias #2    Tx Bias #3    Tx Bias #4
+---+-----+-----+-----+-----+
      7.332 mA      7.412 mA      7.208 mA      7.222 mA
      Normal      Normal      Normal      Normal

```

Syntax: **show optic** <stack-unit>/<slot>/<port>

Specify the ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

NOTE

The **show optic** function takes advantage of information stored and supplied by the manufacturer of the SFP, SFP+, and QSFP+ transceiver. This information is an optional feature of the Multi-Source Agreement standard defining the optical interface. Not all component suppliers have implemented this feature set. In such cases where the SFP, SFP+, and QSFP+ transceiver does not supply the information, a “Not Available” message will be displayed for the specific port on which the module is installed.

The following table describes the information displayed by the **show optic** command.

TABLE 48 Output from the show optic command

Field	Description
Port	The Brocade port number.
Temperature	<ul style="list-style-type: none"> The operating temperature, in degrees Celsius, of the optical transceiver. The alarm status, as described in Table 49.
Tx Power	<ul style="list-style-type: none"> The transmit power signal, in decibels (dB), of the measured power referenced to one milliwatt (mW). The alarm status, as described in Table 49.
Rx Power	<ul style="list-style-type: none"> The receive power signal, in decibels (dB), of the measured power referenced to one milliwatt (mW). The alarm status, as described in Table 49.
Tx Bias Current	<ul style="list-style-type: none"> The transmit bias power signal, in milliamperes (mA). The alarm status, as described in Table 49.

For Temperature, Tx Power, Rx Power, and Tx Bias Current in the **show optic** command output, values are displayed along with one of the following alarm status values: Low-Alarm, Low-Warn, Normal, High-Warn or High-Alarm. The thresholds that determine these status values are set by the manufacturer of the optical transceivers. [Table 49](#) describes each of these status values.

TABLE 49 Alarm status value description

Status value	Description
Low-Alarm	Monitored level has dropped below the "low-alarm" threshold set by the manufacturer of the optical transceiver.
Low-Warn	Monitored level has dropped below the "low-warn" threshold set by the manufacturer of the optical transceiver.
Normal	Monitored level is within the "normal" range set by the manufacturer of the optical transceiver.
High-Warn	Monitored level has climbed above the "high-warn" threshold set by the manufacturer of the optical transceiver.
High-Alarm	Monitored level has climbed above the "high-alarm" threshold set by the manufacturer of the optical transceiver.

Viewing optical transceiver thresholds

The thresholds that determine the alarm status values for an optical transceiver are set by the manufacturer of the SFP, SFP+, and QSFP+. To view the thresholds for a qualified optical transceiver in a particular port, use the **show optic threshold** command as shown below.

```

Brocade#show optic thresholds 1/1/4
Port 1/1/4 optical monitor thresholds:
Temperature High alarm          5a00      90.0000 C
Temperature Low alarm           fb00      -5.0000 C
Temperature High warning        5500      85.0000 C
Temperature Low warning         0000       0.0000 C
TX Bias High alarm              1482      10.500 mA
TX Bias Low alarm               04e2       2.500 mA
TX Bias High warning            1482      10.500 mA
TX Bias Low warning             04e2       2.500 mA
TX Power High alarm             4e20      003.0102 dBm
TX Power Low alarm              04ec     -008.9962 dBm
TX Power High warning           1edc     -001.0237 dBm
TX Power Low warning            0c62     -004.9894 dBm
RX Power High alarm             4e20      003.0102 dBm
RX Power Low alarm              013b     -015.0168 dBm
RX Power High warning           1edc     -001.0237 dBm
RX Power Low warning            013b     -015.0168 dBm

```

Syntax: `show optic threshold <stack-unit>/<slot>/<port>`

Specify the ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

For Temperature, Supply Voltage, TX Bias, TX Power, and RX Power, values are displayed for each of the following four alarm and warning settings: High alarm, Low alarm, High warning, and Low warning. The hexadecimal values are the manufacturer internal calibrations, as defined in the SFF-8472 standard. The other values indicate at what level (above the high setting or below the low setting) the system should send a warning message or an alarm. Note that these values are set by the manufacturer of the optical transceiver, and cannot be configured.

Syslog messages for optical transceivers

The system generates Syslog messages for optical transceivers in the following circumstances:

- The temperature, supply voltage, TX Bias, TX power, or TX power value goes above or below the high or low warning or alarm threshold set by the manufacturer.
- The optical transceiver does not support digital optical monitoring.
- The optical transceiver is not qualified, and therefore not supported by Brocade.

For details about the above Syslog messages, refer to [Appendix A, “Syslog messages”](#).

Syslog

In this chapter

- [About Syslog messages](#) 232
- [Displaying Syslog messages](#)..... 232
- [Syslog service configuration](#)..... 234

Table 50 lists the Brocade ICX 6650 switch and the Syslog features the switch supports. These features are supported in full Layer 3 software images, except where explicitly noted.

TABLE 50 Supported Syslog features

Feature	Brocade ICX 6650
Syslog messages	Yes
Real-time display of Syslog messages	Yes
Real-time display for Telnet or SSH sessions	Yes
Show log on all terminals	Yes
Time stamps	Yes
Multiple Syslog server logging (up to 6 Syslog servers)	Yes
Disabling logging of a message level	Yes
Changing the number of entries the local buffer can hold	Yes
Changing the log facility	Yes
Displaying Interface names in Syslog messages	Yes
Displaying TCP and UDP port numbers in Syslog messages	Yes
Retaining Syslog messages after a soft reboot	Yes
Clearing Syslog messages from the local buffer	Yes

This chapter describes how to display Syslog messages and how to configure the Syslog facility, and lists the Syslog messages that Brocade ICX 6650 devices can display during standard operation. Refer to “[Syslog](#)” on page 231 for a list of Syslog messages.

About Syslog messages

Brocade software can write syslog messages to provide information at the following severity levels:

- Emergencies
- Alerts
- Critical
- Errors
- Warnings
- Notifications
- Informational
- Debugging

The device writes the messages to a local buffer.

You also can specify the IP address or host name of up to six Syslog servers. When you specify a Syslog server, the Brocade ICX 6650 device writes the messages both to the system log and to the Syslog server.

Using a Syslog server ensures that the messages remain available even after a system reload. The Brocade local Syslog buffer is cleared during a system reload or reboot, but the Syslog messages sent to the Syslog server remain on the server.

NOTE

To enable the Brocade ICX 6650 device to retain Syslog messages after a soft reboot (**reload** command). Refer to [“Retaining Syslog messages after a soft reboot”](#) on page 242.

The Syslog service on a Syslog server receives logging messages from applications on the local host or from devices such as a Layer 2 Switch or Layer 3 Switch. Syslog adds a time stamp to each received message and directs messages to a log file. Most Unix workstations come with Syslog configured. Some third party vendor products also provide Syslog running on NT.

Syslog uses UDP port 514 and each Syslog message thus is sent with destination port 514. Each Syslog message is one line with Syslog message format. The message is embedded in the text portion of the Syslog format. There are several subfields in the format. Keywords are used to identify each subfield, and commas are delimiters. The subfield order is insensitive except that the text subfield should be the last field in the message. All the subfields are optional.

Displaying Syslog messages

To display the Syslog messages in the device local buffer, enter the **show logging** command at any level of the CLI. The following shows an example display output.

```
Brocade>#show logging
```

```
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
  Buffer logging: level ACDMEINW, 3 messages logged
    level code: A=alert C=critical D=debugging M=emergency E=error
                I=informational N=notification W=warning
```

```
Static Log Buffer:
```

```
Dec 15 19:04:14:A:Fan 1, fan on right connector, failed
```

Dynamic Log Buffer (50 entries):

```
Dec 15 18:46:17:I:Interface ethernet 4, state up
Dec 15 18:45:21:I:Bridge topology change, vlan 4095, interface 4, changed
state to forwarding
Dec 15 18:45:15:I:Warm start
```

For information about the Syslog configuration information, time stamps, and dynamic and static buffers, refer to [“Displaying the Syslog configuration”](#) on page 234.

Enabling real-time display of Syslog messages

By default, to view Syslog messages generated by a Brocade ICX 6650 device, you need to display the Syslog buffer or the log on a Syslog server used by the Brocade ICX 6650 device.

You can enable real-time display of Syslog messages on the management console. When you enable this feature, the software displays a Syslog message on the management console when the message is generated. However, to enable display of real-time Syslog messages in Telnet or SSH sessions, you also must enable display within the individual sessions.

To enable real-time display of Syslog messages, enter the following command at the global CONFIG level of the CLI.

```
Brocade(config)#logging console
```

Syntax: [no] logging console

This command enables the real-time display of Syslog messages on the serial console. You can enter this command from the serial console or a Telnet or SSH session.

Enabling real-time display for a Telnet or SSH session

To also enable the real-time display for a Telnet or SSH session, enter the following command from the Privileged EXEC level of the session.

```
telnet@Brocade#terminal monitor
Syslog trace was turned ON
```

Syntax: terminal monitor

Notice that the CLI displays a message to indicate the status change for the feature. To disable the feature in the management session, enter the **terminal monitor** command again. The command toggles the feature on and off.

```
telnet@Brocade#terminal monitor
Syslog trace was turned OFF
```

Here is an example of how the Syslog messages are displayed.

```
telnet@Brocade#terminal monitor
Syslog trace was turned ON
SYSLOG: <9>Brocade, Power supply 2, power supply on left connector, failed

SYSLOG: <14>Brocade, Interface ethernet 6, state down

SYSLOG: <14>Brocade, Interface ethernet 2, state up
```

Displaying real-time Syslog messages

Any terminal logged on to a Brocade switch can receive real-time Syslog messages when the **terminal monitor** command is issued.

Syslog service configuration

The procedures in this section describe how to perform the following Syslog configuration tasks:

- Specify a Syslog server. You can configure the Brocade device to use up to six Syslog servers. (Use of a Syslog server is optional. The system can hold up to 1000 Syslog messages in an internal buffer.)
- Change the level of messages the system logs.
- Change the number of messages the local Syslog buffer can hold.
- Display the Syslog configuration.
- Clear the local Syslog buffer.

Logging is enabled by default, with the following settings:

- Messages of all severity levels (Emergencies – Debugging) are logged.
- By default, up to 50 messages are retained in the local Syslog buffer. This can be changed.
- No Syslog server is specified.

Displaying the Syslog configuration

To display the Syslog parameters currently in effect on a Brocade device, enter the following command from any level of the CLI.

```
Brocade>#show logging
```

```
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
  Buffer logging: level ACDMEINW, 3 messages logged
  level code: A=alert C=critical D=debugging M=emergency E=error
              I=informational N=notification W=warning
```

```
Static Log Buffer:
```

```
Dec 15 19:04:14:A:Fan 1, fan on right connector, failed
```

```
Dynamic Log Buffer (50 entries):
```

```
Dec 15 18:46:17:I:Interface ethernet 1/4, state up
```

```
Dec 15 18:45:21:I:Bridge topology change, vlan 4095, interface 4, changed
state to forwarding
```

```
Dec 15 18:45:15:I:Warm start
```

Syntax: show logging

The Syslog display shows the following configuration information, in the rows above the log entries themselves.

TABLE 51 CLI display of Syslog buffer configuration

Field	Definition
Syslog logging	The state (enabled or disabled) of the Syslog buffer.
messages dropped	The number of Syslog messages dropped due to user-configured filters. By default, the software logs messages for all Syslog levels. You can disable individual Syslog levels, in which case the software filters out messages at those levels. Refer to “Disabling logging of a message level” on page 239. Each time the software filters out a Syslog message, this counter is incremented.
flushes	The number of times the Syslog buffer has been cleared by the clear logging command. Refer to “Clearing the Syslog messages from the local buffer” on page 242.
overruns	The number of times the dynamic log buffer has filled up and been cleared to hold new entries. For example, if the buffer is set for 100 entries, the 101st entry causes an overrun. After that, the 201st entry causes a second overrun.
level	The message levels that are enabled. Each letter represents a message type and is identified by the key (level code) below the value. If you disable logging of a message level, the code for that level is not listed.
messages logged	The total number of messages that have been logged since the software was loaded.
level code	The message levels represented by the one-letter codes.

Static and dynamic buffers

The software provides two buffers:

- Static – logs power supply failures, fan failures, and temperature warning or shutdown messages
- Dynamic – logs all other message types

In the static log, new messages replace older ones, so only the most recent message is displayed. For example, only the most recent temperature warning message will be present in the log. If multiple temperature warning messages are sent to the log, the latest one replaces the previous one. The static buffer is not configurable.

The message types that appear in the static buffer do not appear in the dynamic buffer. The dynamic buffer contains up to the maximum number of messages configured for the buffer (50 by default), then begins removing the oldest messages (at the bottom of the log) to make room for new ones.

The static and dynamic buffers are both displayed when you display the log.

```
Brocade#show logging
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
  Buffer logging: level ACDMEINW, 3 messages logged
  level code: A=alert C=critical D=debugging M=emergency E=error
              I=informational N=notification W=warning
```

Static Log Buffer:

```
Dec 15 19:04:14:A:Fan 1, fan on right connector, failed
Dec 15 19:00:14:A:Fan 2, fan on left connector, failed
```

Dynamic Log Buffer (50 entries):

```
Dec 15 18:46:17:I:Interface ethernet 4, state up
Dec 15 18:45:21:I:Bridge topology change, vlan 4095, interface 4, changed
state to forwarding
Dec 15 18:45:15:I:Warm start
```

Notice that the static buffer contains two separate messages for fan failures. Each message of each type has its own buffer. Thus, if you replace fan 1 but for some reason that fan also fails, the software replaces the first message about the failure of fan 1 with the newer message. The software does not overwrite the message for fan 2, unless the software sends a newer message for fan 2.

Clearing log entries

When you clear log entries, you can selectively clear the static or dynamic buffer, or you can clear both. For example, to clear only the dynamic buffer, enter the following command at the Privileged EXEC level.

```
Brocade#clear logging dynamic-buffer
```

Syntax: clear logging [dynamic-buffer | static-buffer]

You can specify **dynamic-buffer** to clear the dynamic buffer or **static-buffer** to clear the static buffer. If you do not specify a buffer, both buffers are cleared.

Time stamps

The contents of the time stamp differ depending on whether you have set the time and date on the onboard system clock:

- If you have set the time and date on the onboard system clock, the date and time are shown in the following format.

mm dd hh:mm:ss

where

- *mm* – abbreviation for the name of the month
- *dd* – day
- *hh* – hours
- *mm* – minutes
- *ss* – seconds

For example, “Oct 15 17:38:03” means October 15 at 5:38 PM and 3 seconds.

- If you have not set the time and date on the onboard system clock, the time stamp shows the amount of time that has passed since the device was booted, in the following format.

`<num>d<num>h<num>m<num>s`

where

- `<num>d` – day
- `<num>h` – hours
- `<num>m` – minutes
- `<num>s` – seconds

For example, “188d1h01m00s” means the device had been running for 188 days, 11 hours, one minute, and zero seconds when the Syslog entry with this time stamp was generated.

Example of Syslog messages on a device with the onboard clock set

The example shows the format of messages on a device where the onboard system clock has been set. Each time stamp shows the month, the day, and the time of the system clock when the message was generated. For example, the system time when the most recent message (the one at the top) was generated was October 15 at 5:38 PM and 3 seconds.

```
Brocade#show logging
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
  Buffer logging: level ACDMEINW, 38 messages logged
  level code: A=alert C=critical D=debugging M=emergency E=error
              I=informational N=notification W=warning
```

```
Static Log Buffer:
Dec 15 19:04:14:A:Fan 1, fan on right connector, failed
Dec 15 19:00:14:A:Fan 2, fan on left connector, failed
```

```
Dynamic Log Buffer (50 entries):
Oct 15 17:38:03:warning:list 101 denied tcp 10.157.22.191(0)(Ethernet 18
0010.5alf.77ed) -> 10.99.4.69(http), 1 event(s)
Oct 15 07:03:30:warning:list 101 denied tcp 10.157.22.26(0)(Ethernet 18
0010.5alf.77ed) -> 10.99.4.69(http), 1 event(s)
Oct 15 06:58:30:warning:list 101 denied tcp 10.157.22.198(0)(Ethernet 18
0010.5alf.77ed) -> 10.99.4.69(http), 1 event(s)
```

Example of Syslog messages on a device with the onboard clock not set

The example shows the format of messages on a device where the onboard system clock is not set. Each time stamp shows the amount of time the device had been running when the message was generated. For example, the most recent message, at the top of the list of messages, was generated when the device had been running for 21 days, seven hours, two minutes, and 40 seconds.

10 Syslog service configuration

```
Brocade#show logging
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
  Buffer logging: level ACDMEINW, 16 messages logged
  level code: A=alert C=critical D=debugging M=emergency E=error
              I=informational N=notification W=warning

Static Log Buffer:
0d00h00m17s:I:System: Stack unit 1   Power supply 2   is up

0d00h00m14s:A:System: Stack unit 1 Temperature 53.0 C degrees, warning level 0.0
  C degrees, shutdown level 85.0 C degrees
0d00h00m14s:W:System: Temperature is over warning level on unit 1

Dynamic Log Buffer (50 lines):
3d00h21m29s:I:running-config was changed by   from console
2d21h52m07s:I:running-config was changed by   from console
1d11h35m29s:I:VLAN: Id 20 deleted by user from console session
1d02h42m03s:I:running-config was changed by   from console
0d00h01m38s:D:DHCP: Stopped DHCP Client service
0d00h00m14s:I:System: Interface ethernet 1/2/4, state up
0d00h00m14s:I:System: Interface ethernet 1/2/3, state up
0d00h00m14s:I:System: Interface ethernet 1/2/2, state up
0d00h00m14s:I:System: Interface ethernet 1/2/1, state up
0d00h00m14s:I:System: Interface ethernet mgmt1, state up
0d00h00m08s:D:DHCP: starting dhcp client service on 69 port(s)
```

Disabling or re-enabling Syslog

Syslog is enabled by default. To disable it, enter the **logging on** command at the global CONFIG level.

```
Brocade(config)#no logging on
```

Syntax: [no] **logging on** [<udp-port>]

The <udp-port> parameter specifies the application port used for the Syslog facility. The default is 514.

To re-enable logging, re-enter the **logging on** command.

```
Brocade(config)#logging on
```

This command enables local Syslog logging with the following defaults:

- Messages of all severity levels (Emergencies – Debugging) are logged.
- Up to 50 messages are retained in the local Syslog buffer.
- No Syslog server is specified.

Specifying a Syslog server

To specify a Syslog server, enter the **logging host** command.

```
Brocade(config)#logging host 10.0.0.99
```

Syntax: **logging host** <ip-addr> | <server-name>

Specifying an additional Syslog server

To specify an additional Syslog server, enter the **logging host** *<ip-addr>* command again. You can specify up to six Syslog servers.

```
Brocade(config)#logging host 10.0.0.99
```

Syntax: **logging host** *<ip-addr>* | *<server-name>*

Disabling logging of a message level

To change the message level, disable logging of specific message levels. You must disable the message levels on an individual basis.

For example, to disable logging of debugging and informational messages, enter the following commands.

```
Brocade(config)#no logging buffered debugging
Brocade(config)#no logging buffered informational
```

Syntax: **[no] logging buffered** *<level>* | *<num-entries>*

The *<level>* parameter can have one of the following values:

- alerts
- critical
- debugging
- emergencies
- errors
- informational
- notifications
- warnings

The commands in the example above change the log level to notification messages or higher. The software will not log informational or debugging messages. The changed message level also applies to the Syslog servers.

Changing the number of entries the local buffer can hold

You also can use the **logging buffered** command to change the number of entries the local Syslog buffer can store. For example.

```
Brocade(config)#logging buffered 100
Brocade(config)#write mem
Brocade(config)#exit
Brocade#reload
```

Syntax: **logging buffered** *<num>*

The default number of messages is 50.

For Layer 2 switches, you can set the Syslog buffer limit from 1 – 100 entries. For Layer 3 switches, you can set the Syslog buffer limit from 1 – 1000 entries.

Local buffer configuration notes

- You must save the configuration and reload the software to place the change into effect.
- If you decrease the size of the buffer, the software clears the buffer before placing the change into effect.
- If you increase the size of the Syslog buffer, the software will clear some of the older locally buffered Syslog messages.

Changing the log facility

The Syslog daemon on the Syslog server uses a facility to determine where to log the messages from the Brocade device. The default facility for messages the Brocade device sends to the Syslog server is “user”. You can change the facility using the following command.

NOTE

You can specify only one facility. If you configure the Brocade device to use two Syslog servers, the device uses the same facility on both servers.

```
Brocade(config)#logging facility local0
```

Syntax: `logging facility <facility-name>`

The <facility-name> can be one of the following:

- kern – kernel messages
- user – random user-level messages
- mail – mail system
- daemon – system daemons
- auth – security or authorization messages
- syslog – messages generated internally by Syslog
- lpr – line printer subsystem
- news – netnews subsystem
- uucp – uucp subsystem
- sys9 – cron/at subsystem
- sys10 – reserved for system use
- sys11 – reserved for system use
- sys12 – reserved for system use
- sys13 – reserved for system use
- sys14 – reserved for system use
- cron – cron/at subsystem
- local0 – reserved for local use
- local1 – reserved for local use
- local2 – reserved for local use

- local3 – reserved for local use
- local4 – reserved for local use
- local5 – reserved for local use
- local6 – reserved for local use
- local7 – reserved for local use

Displaying interface names in Syslog messages

By default, an interface slot number (if applicable) and port number are displayed when you display Syslog messages. If you want to display the name of the interface instead of its number, enter the following command:

```
Brocade(config)# ip show-portname
```

This command is applied globally to all interfaces on Layer 2 Switches and Layer 3 Switches.

Syntax: [no] ip show-portname

By default, Syslog messages show the interface type, such as “ethernet”, “pos”, and so on. For example, you see the following

```
SYSLOG: <14>Jun 27 16:17:02 10.20.68.32 System: Interface ethernet 1/1/4, state up
```

However, if ip show-portname is configured and a name has been assigned to the port, the port name replaces the interface type as shown in the example below.

```
SYSLOG: <14>Jun 27 16:18:33 10.20.68.32 System: Interface port4 1/1/4, state up
```

Also, when you display the messages in the Syslog, you see the interface name under the Dynamic Log Buffer section. The actual interface number is appended to the interface name. For example, if the interface name is "lab" and its port number is "2", you see "lab2" displayed as in the example below:

```
Brocade# show logging
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
  Buffer logging: level ACDMEINW, 3 messages logged
    level code: A=alert C=critical D=debugging M=emergency E=error
                I=informational N=notification W=warning
Static Log Buffer:
Dec 15 19:04:14:A:Fan 1, fan on right connector, failed
Dynamic Log Buffer (50 entries):
Dec 15 18:46:17:I:Interface ethernet Lab2, state up
Dec 15 18:45:15:I:Warm start
```

Displaying TCP or UDP port numbers in Syslog messages

The command **ip show-service-number-in-log** allows you to change the display of TCP or UDP application information from the TCP or UDP well-known port name to the TCP or UDP port number. For example, when this command is in effect, the Brocade device will display **http** (the well-known port name) instead of **80** (the port number) in the output of show commands, and other commands that contain application port information. By default, Brocade devices display TCP or UDP application information in named notation.

To display TCP or UDP port numbers instead of their names, enter the following command.

```
Brocade(config)#ip show-service-number-in-log
```

Syntax: [no] ip show-service-number-in-log

Retaining Syslog messages after a soft reboot

You can configure the device to save the System log (Syslog) after a soft reboot (**reload** command).

Syslog reboot configuration considerations

- If the Syslog buffer size was set to a different value using the CLI command **logging buffered**, the System log will be cleared after a soft reboot, even when this feature (**logging persistence**) is in effect. This will occur only with a soft reboot immediately following a Syslog buffer size change. A soft reboot by itself will not clear the System log. To prevent the system from clearing the System log, leave the number of entries allowed in the Syslog buffer unchanged.
- This feature does not save Syslog messages after a hard reboot. When the Brocade device is power-cycled, the Syslog messages are cleared.
- If **logging persistence** is enabled and you load a new software image on the device, you must first clear the log if you want to reload the device. (Refer to [“Clearing the Syslog messages from the local buffer”](#) on page 242.)

To configure the device to save the System log messages after a soft reboot, enter the following command.

```
Brocade(config)#logging persistence
```

Syntax: [no] logging persistence

Enter **no logging persistence** to disable this feature after it has been enabled.

Clearing the Syslog messages from the local buffer

To clear the Syslog messages stored in the local buffer of the Brocade device, enter the **clear logging** command.

```
Brocade#clear logging
```

Syntax: clear logging

.

Network Monitoring

In this chapter

- [Basic system management.](#) 243
- [RMON support.](#) 250
- [sFlow.](#) 254
- [Utilization list for an uplink port](#) 270

Table 52 lists the Brocade ICX 6650 switch and the network monitoring features the switch supports. These features are supported in full Layer 3 software images, except where explicitly noted.

TABLE 52 Supported network monitoring features

Feature	Brocade ICX 6650
Egress queue counters	Yes
Remote monitoring (RMON)	Yes
Specifying the maximum number of entries allowed in the RMON Control Table	Yes
sFlow version 2	Yes
sFlow version 5 (default)	Yes
sFlow support for IPv6 packets	Yes
Uplink utilization lists	Yes

Basic system management

The following sections contain procedures for basic system management tasks.

Viewing system information

You can access software and hardware specifics for a Brocade Layer 2 Switch or Layer 3 Switch. For software specifics, refer to [“Software versions installed and running on a device”](#) on page 50.

To view the software and hardware details for the system, enter the **show version** command. The following shows an example output.

11 Basic system management

```
Brocade#show version
Copyright (c) 1996-2012 Brocade Communications Systems, Inc. All rights reserved.
  UNIT 1: compiled on Jul 31 2012 at 21:55:03 labeled as ICXLS07500
            (11358772 bytes) from Secondary ICXLS07500.bin
  SW: Version 07.5.00T321
  Boot-Monitor Image size = 524288, Version:07.5.00T320 (fxz07500B1)
  HW: Stackable ICX6650-64
=====
UNIT 1: SL 1: ICX6650-64 56-port Management Module
      Serial #: CEN2525H006
      License: BASE_SOFT_PACKAGE (LID: egpHKHKjFFL)
      P-ENGINE 0: type EC02, rev 01
=====
UNIT 1: SL 2: ICX6650-64 4-port 160G Module
=====
UNIT 1: SL 3: ICX6650-64 8-port 80G Module
=====
      800 MHz Power PC processor 8544E (version 0021/0022) 400 MHz bus
      65536 KB flash memory
      1024 MB DRAM
STACKID 1 system uptime is 23 hours 12 minutes 8 seconds
=====
                                HARDWARE INFORMATION
UNIT NAME      : ICX6650-64
HW REVISION    : 2 (BETA)
Board ID       : 4(ICX6650)
                                CPLD INFORMATION
CPLD code is RD revision
CPLD CODE REVISION = 6
=====
The system : started=warm start  reloaded=by "reload"
*** NOT FOR PRODUCTION ***
```

The following hardware details are listed in the output of the **show version** command:

- Chassis type
- PROM type (if applicable)
- Chassis serial number
- Management and interface module serial numbers and ASIC types

For a description of the software details in the output of the **show version** command, refer to [“Software versions installed and running on a device”](#) on page 50.

Syntax: **show version**

Viewing configuration information

You can view a variety of configuration details and statistics with the **show** option. The **show** option provides a convenient way to check configuration changes before saving them to flash.

The show options available will vary for Layer 2 Switches and Layer 3 Switches and by configuration level.

To determine the available show commands for the system or a specific level of the CLI, enter the following command.

```
Brocade#show ?
```

Syntax: `show <option>`

You also can enter “show” at the command prompt, then press the TAB key.

Viewing port statistics

Port statistics are polled by default every 10 seconds.

You can view statistics for ports by entering the following **show** commands:

- `show interfaces`
- `show configuration`
- `show statistics`

To display the statistics, enter a command such as the following.

```
Brocade#show statistics ethernet 1/1/1
Port Link State Dupl Speed Trunk Tag Priori MAC Name
1/1/1 Up Forward Half 100M None No level0 748e.f80c.5f40

Port 1/1/1 Counters:
      InOctets          3200      OutOctets          256
      InPkts            50      OutPkts            4
InBroadcastPkts        0      OutBroadcastPkts    3
InMulticastPkts        48      OutMulticastPkts    0
InUnicastPkts          2      OutUnicastPkts      1
      InBadPkts          0
      InFragments        0
      InDiscards          0      OutErrors          0
      CRC                0      Collisions          0
      InErrors            0      LateCollisions      0
      InGiantPkts         0
      InShortPkts         0
      InJabber            0
InFlowCtrlPkts         0      OutFlowCtrlPkts     0
InBitsPerSec           264      OutBitsPerSec        16
InPktsPerSec           0      OutPktsPerSec        0
InUtilization           0.00%    OutUtilization        0.00%
```

Syntax: `show statistics [ethernet <stack-unit>/<slot>/<port>`

Specify the Ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

[Table 53](#) lists the statistics displayed in the output of the **show statistics** command.

TABLE 53 Port statistics

Parameter	Description
Port configuration	
Port	The port number.
Link	The link state.

TABLE 53 Port statistics (Continued)

Parameter	Description
State	The STP state.
Dupl	The mode (full-duplex or half-duplex).
Speed	The port speed (10M, 100M, or 1000M).
Trunk	The trunk group number, if the port is a member of a trunk group.
Tag	Whether the port is a tagged member of a VLAN.
Priori	The QoS forwarding priority of the port (level0 – level7).
MAC	The MAC address of the port.
Name	The name of the port, if you assigned a name.
Statistics	
InOctets	The total number of good octets and bad octets received.
OutOctets	The total number of good octets and bad octets sent.
InPkts	The total number of packets received. The count includes rejected and local packets that are not sent to the switching core for transmission.
OutPkts	The total number of good packets sent. The count includes unicast, multicast, and broadcast packets.
InBroadcastPkts	The total number of good broadcast packets received.
OutBroadcastPkts	The total number of good broadcast packets sent.
InMulticastPkts	The total number of good multicast packets received.
OutMulticastPkts	The total number of good multicast packets sent.
InUnicastPkts	The total number of good unicast packets received.
OutUnicastPkts	The total number of good unicast packets sent.
InBadPkts	The total number of packets received for which one of the following is true: <ul style="list-style-type: none"> • The CRC was invalid. • The packet was oversized. • Jabbers: The packets were longer than 1518 octets and had a bad FCS. • Fragments: The packets were less than 64 octets long and had a bad FCS. • The packet was undersized (short).
InFragments	The total number of packets received for which both of the following was true: <ul style="list-style-type: none"> • The length was less than 64 bytes. • The CRC was invalid.
InDiscards	The total number of packets that were received and then dropped due to a lack of receive buffers.
OutErrors	The total number of packets with internal transmit errors such as TX underruns.
CRC	The total number of packets received for which all of the following was true: <ul style="list-style-type: none"> • The data length was between 64 bytes and the maximum allowable frame size. • No Collision or Late Collision was detected. • The CRC was invalid.
Collisions	The total number of packets received in which a Collision event was detected.
InErrors	The total number of packets received that had Alignment errors or phy errors.

TABLE 53 Port statistics (Continued)

Parameter	Description
LateCollisions	The total number of packets received in which a Collision event was detected, but for which a receive error (Rx Error) event was not detected.
InGiantPkts	<p>The total number of packets for which all of the following was true:</p> <ul style="list-style-type: none"> • The data length was longer than the maximum allowable frame size. • No Rx Error was detected. <p>NOTE: Packets are counted for this statistic regardless of whether the CRC is valid or invalid.</p>
InShortPkts	<p>The total number of packets received for which all of the following was true:</p> <ul style="list-style-type: none"> • The data length was less than 64 bytes. • No Rx Error was detected. • No Collision or Late Collision was detected. <p>NOTE: Packets are counted for this statistic regardless of whether the CRC is valid or invalid.</p>
InJabber	<p>The total number of packets received for which all of the following was true:</p> <ul style="list-style-type: none"> • The data length was longer than the maximum allowable frame size. • No Rx Error was detected. • The CRC was invalid.
InFlowCtrlPkts	The total number of flow control packets received.
OutFlowCtrlPkts	The total number of flow control packets transmitted.
InBitsPerSec	The number of bits received per second.
OutBitsPerSec	The number of bits sent per second.
InPktsPerSec	The number of packets received per second.
OutPktsPerSec	The number of packets sent per second.
InUtilization	The percentage of the port bandwidth used by received traffic.
OutUtilization	The percentage of the port bandwidth used by sent traffic.

Viewing STP statistics

You can view a summary of STP statistics for Layer 2 Switches and Layer 3 Switches. STP statistics are by default polled every 10 seconds.

To view spanning tree statistics, enter the **show span** command. To view STP statistics for a VLAN, enter the **span vlan** command.

Clearing statistics

You can clear statistics for many parameters using the **clear** command.

To determine the available **clear** commands for the system, enter the **clear** command at the Privileged EXEC level of the CLI.

```
Brocade#clear ?
```

Syntax: **clear** <option>

You also can enter “clear” at the command prompt, then press the TAB key.

Viewing egress queue counters

The **show interface** command displays the number of packets on a port that were queued for each QoS priority (traffic class) and dropped because of congestion.

NOTE

These counters do not include traffic on management ports or for a stack member unit that is down.

The egress queue counters display at the end of the **show interface** command output as shown in the following example.

```
Brocade#show interface e 1/1/1
GigabitEthernet1/1/1 is up, line protocol is up
  Hardware is GigabitEthernet, address is 748e.f80c.5f40(bia 748e.f80c.5f40)
  Configured speed auto, actual 1Gbit, configured duplex fdx, actual fdx
  Configured mdi mode AUTO, actual none
  Member of L2 VLAN ID 52, port is untagged, port state is FORWARDING
  BPDU guard is Disabled, ROOT protect is Disabled
  Link Error Dampening is Disabled
  STP configured to ON, priority is level0, mac-learning is enabled
  Flow Control is config enabled, oper enabled, negotiation disabled
  mirror disabled, monitor disabled
  Not member of any active trunks
  Not member of any configured trunks
  No port name
  Inter-Packet Gap (IPG) is 96 bit times
  IP MTU 1500 bytes
  300 second input rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  300 second output rate: 256 bits/sec, 0 packets/sec, 0.00% utilization
  0 packets input, 0 bytes, 0 no buffer
  Received 0 broadcasts, 0 multicasts, 0 unicasts
  0 input errors, 0 CRC, 0 frame, 0 ignored
  0 runts, 0 giants
  215704 packets output, 13805066 bytes, 0 underruns
  Transmitted 0 broadcasts, 215704 multicasts, 0 unicasts
  0 output errors, 0 collisions
  Relay Agent Information option: Disabled
```

Egress queues:

Queue counters	Queued packets	Dropped Packets
0	0	0
1	0	0
2	1	0
3	0	0
4	0	0
5	0	0
6	0	0
7	215703	0

Syntax: **show interface** [ethernet <stack-unit>/<slot>/<port>]

Specify the Ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

Table 54 defines the egress queue statistics displayed in the output.

TABLE 54 Egress queue statistics

Parameter	Description
Queue counters	The QoS traffic class.
Queued packets	The number of packets queued on the port for the given traffic class.
Dropped packets	The number of packets for the given traffic class that were dropped because of congestion.

Clearing the egress queue counters

You can clear egress queue statistics (reset them to zero), using the **clear statistics** and **clear statistics ethernet <port>** command.

Syntax: **clear statistics** [**ethernet** <stack-unit>/<slot>/<port>]

Specify the Ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

RMON support

The Brocade RMON agent supports the following groups. The group numbers come from the RMON specification (RFC 1757):

- Statistics (RMON Group 1)
- History (RMON Group 2)
- Alarms (RMON Group 3)
- Events (RMON Group 9)

The CLI allows you to make configuration changes to the control data for these groups, but you need a separate RMON application to view and display the data graphically.

Maximum number of entries allowed in the RMON control table

You can specify the maximum number of entries allowed in the RMON control table, including alarms, history, and events. The maximum number of RMON entries supported is 32768.

To set the maximum number of allowable entries to 3000 in the RMON history table, enter commands such as the following.

```
Brocade(config)#system-max rmon-entries 3000
Brocade(config)#write mem
Brocade(config)#exit
Brocade#reload
```

NOTE

You must save the change to the startup-config file and reload or reboot. The change does not take effect until you reload or reboot.

Syntax: **system-max rmon-entries** <value>

where <value> is 32768.

Statistics (RMON group 1)

Count information on multicast and broadcast packets, total packets sent, undersized and oversized packets, CRC alignment errors, jabbers, collision, fragments and dropped events is collected for each port on a Brocade Layer 2 Switch or Layer 3 Switch.

The statistics group collects statistics on promiscuous traffic across an interface. The interface group collects statistics on total traffic into and out of the agent interface.

No configuration is required to activate collection of statistics for the Layer 2 Switch or Layer 3 Switch. This activity is by default automatically activated at system start-up.

You can view a textual summary of the statistics for all ports by entering the following CLI command.

```
Brocade#show rmon statistics
Ethernet statistics 1 is active, owned by monitor
Interface 1/1 (ifIndex 1) counters
      Octets          0
      Drop events     0
      Broadcast pkts  0
      CRC alignment errors 0
      Oversize pkts   0
      Jabbers         0
      64 octets pkts  0
      128 to 255 octets pkts 0
      512 to 1023 octets pkts 0
      Packets         0
      Multicast pkts  0
      Undersize pkts  0
      Fragments       0
      Collisions      0
      65 to 127 octets pkts 0
      256 to 511 octets pkts 0
      1024 to 1518 octets pkts 0
```

Syntax: `show rmon statistics [ethernet <stack-unit>/<slot>/<port>]`

Specify the Ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can use the physical port number or the SNMP port number. The physical port number is based on the product. The SNMP numbers of the ports start at 1 and increase sequentially.

This command shows the following information.

TABLE 55 Export configuration and statistics

Parameter	Definition
Octets	The total number of octets of data received on the network. This number includes octets in bad packets. This number does not include framing bits but does include Frame Check Sequence (FCS) octets.
Drop events	Indicates an overrun at the port. The port logic could not receive the traffic at full line rate and had to drop some packets as a result. The counter indicates the total number of events in which packets were dropped by the RMON probe due to lack of resources. This number is not necessarily the number of packets dropped, but is the number of times an overrun condition has been detected.
Packets	The total number of packets received. This number includes bad packets, broadcast packets, and multicast packets.
Broadcast pkts	The total number of good packets received that were directed to the broadcast address. This number does not include multicast packets.
Multicast pkts	The total number of good packets received that were directed to a multicast address. This number does not include packets directed to the broadcast address.

TABLE 55 Export configuration and statistics (Continued)

Parameter	Definition
CRC alignment errors	The total number of packets received that were from 64 – 1518 octets long, but had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). The packet length does not include framing bits but does include FCS octets.
Undersize pkts	The total number of packets received that were less than 64 octets long and were otherwise well formed. This number does not include framing bits but does include FCS octets.
Fragments	The total number of packets received that were less than 64 octets long and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). It is normal for this counter to increment, since it counts both runts (which are normal occurrences due to collisions) and noise hits. This number does not include framing bits but does include FCS octets.
Oversize packets	The total number of packets received that were longer than 1518 octets and were otherwise well formed. This number does not include framing bits but does include FCS octets. NOTE: 48GC modules do not support count information on oversized packets and report 0.
Jabbers	The total number of packets received that were longer than 1518 octets and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). NOTE: This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms. This number does not include framing bits but does include FCS octets. NOTE: 48GC modules do not support count information on jabbers and report 0.
Collisions	The best estimate of the total number of collisions on this Ethernet segment.
64 octets pkts	The total number of packets received that were 64 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
65 to 127 octets pkts	The total number of packets received that were 65 – 127 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
128 to 255 octets pkts	The total number of packets received that were 128 – 255 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
256 to 511 octets pkts	The total number of packets received that were 256 – 511 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
512 to 1023 octets pkts	The total number of packets received that were 512 – 1023 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
1024 to 1518 octets pkts	The total number of packets received that were 1024 – 1518 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.

History (RMON group 2)

All active ports by default will generate two history control data entries per active Brocade Layer 2 Switch port or Layer 3 Switch interface. An active port is defined as one with a link up. If the link goes down the two entries are automatically deleted.

Two history entries are generated for each device:

- A sampling of statistics every 30 seconds
- A sampling of statistics every 30 minutes

The history data can be accessed and displayed using any of the popular RMON applications

A sample RMON history command and its syntax is shown below.

```
Brocade(config)#rmon history 1 interface ethernet 1/1/1 buckets 10 interval 10
owner nyc02
```

Syntax: **rmon history** <entry-number> **interface** [**ethernet** <stack-unit>/<slot>/<port>] **buckets** <number> **interval** <sampling-interval> **owner** <text-string>

Specify the Ethernet port in the <stack-unit>/<slot>/<port> format. Stack-unit is 1.

You can modify the sampling interval and the bucket (number of entries saved before overwrite) using the CLI. In the above example, owner refers to the RMON station that will request the information.

NOTE

To review the control data entry for each port or interface, enter the **show rmon history** command.

Alarm (RMON group 3)

Alarm is designed to monitor configured thresholds for any SNMP integer, time tick, gauge or counter MIB object. Using the CLI, you can define what MIB objects are monitored, the type of thresholds that are monitored (falling, rising or both), the value of those thresholds, and the sample type (absolute or delta).

An alarm event is reported each time that a threshold is exceeded. The alarm entry also indicates the action (event) to be taken if the threshold be exceeded.

A sample CLI alarm entry and its syntax is shown below.

```
Brocade(config)#rmon alarm 1 ifInOctets.6 10 delta rising-threshold 100 1 falling
threshold 50 1 owner nyc02
```

Syntax: **rmon alarm** <entry-number> <MIB-object.interface-num> <sampling-time> <sample-type> <threshold-type> <threshold-value> <event-number> <threshold-type> <threshold-value> <event-number> **owner** <text-string>

Event (RMON group 9)

There are two elements to the Event Group—the **event control table** and the **event log table**.

The event control table defines the action to be taken when an alarm is reported. Defined events can be found by entering the CLI command, `show event`. The Event Log Table collects and stores reported events for retrieval by an RMON application.

A sample entry and syntax of the event control table is shown below.

```
Brocade(config)#rmon event 1 description 'testing a longer string' log-and-trap
public owner nyc02
```

Syntax: `rmon event <event-entry> description <text-string> log | trap | log-and-trap owner <rmon-station>`

sFlow

NOTE

Brocade ICX 6650 devices support sFlow version 5 by default.

sFlow is a standards-based protocol that allows network traffic to be sampled at a user-defined rate for the purpose of monitoring traffic flow patterns and identifying packet transfer rates on user-specified interfaces.

When sFlow is enabled on a Layer 2 or Layer 3 switch, the system performs the following sFlow-related tasks:

- Samples traffic flows by copying packet header information
- Identifies ingress and egress interfaces for the sampled flows
- Combines sFlow samples into UDP packets and forwards them to the sFlow collectors for analysis
- Forwards byte and packet count data, or counter samples, to sFlow collectors

sFlow is described in RFC 3176, "InMon Corporation's sFlow: A Method for Monitoring Traffic in Switched and Routed Networks".

NOTE

You can use QoS queue 1 for priority traffic, even when sFlow is enabled on the port. QoS queue 1 is reserved for sFlow and is not used by other packets. Any non-sFlow packets assigned to QoS queue 1 will be directed to QoS queue 0.

sFlow version 5

sFlow version 5 enhances and modifies the format of the data sent to the sFlow collector. sFlow version 5 introduces several new sFlow features and also defines a new datagram syntax used by the sFlow agent to report flow samples and interface counters to the sFlow collector.

sFlow version 5 adds support for the following:

- sFlow version 5 datagrams
- Sub-agent support
- Configurable sFlow export packet size
- Support for the new data field and sample type length in flow samples
- Configurable interval for exporting Brocade-specific data structure

sFlow version 5 is backward-compatible with sFlow version 2. By default, the sFlow agent exports sFlow version 5 flow samples by default, but you can configure the device to export the data in sFlow version 2 format. You can switch between sFlow version 2 and sFlow version 5 formats. The sFlow collector automatically parses each incoming sample and decodes it based on the version number.

The configuration procedures for sFlow version 5 are the same as for sFlow version 2, except where explicitly noted. Configuration procedures for sFlow are in the section [“Configuring and enabling sFlow”](#) on page 257. The features and CLI commands that are specific to sFlow version 5 are described in the section [“sFlow version 5 feature configuration”](#) on page 264.

sFlow support for IPv6 packets

The Brocade implementation of sFlow features support IPv6 packets. This support includes extended router information and extended gateway information in the sampled packet. Note that sFlow support for IPv6 packets exists only on devices running software that supports IPv6.

The configuration procedures for this feature are the same as for IPv4, except where the collector is a link-local address on a Layer 3 switch. For details refer to [“Specifying the collector”](#) on page 258.

Extended router information

IPv6 sFlow sampled packets include the following extended router information:

- IP address of the next hop router
- Outgoing VLAN ID
- Source IP address prefix length
- Destination IP address prefix length

Note that in IPv6 devices, the prefix lengths of the source and destination IP addresses are collected if BGP is configured and the route lookup is completed. In IPv4 devices, this information is collected only if BGP is configured on the devices.

Extended gateway information

If BGP is enabled, extended gateway information is included in IPv6 sFlow sampled packets, including the following BGP information about a packet destination route:

- The autonomous system (AS) number for the router
- The source IP AS of the route
- The source peer AS for the route
- The AS patch to the destination

NOTE

AS communities and local preferences are not included in the sampled packets.

To obtain extended gateway information, use “struct extended_gateway” as described in RFC 3176.

IPv6 packet sampling

IPv6 sampling is performed by the packet processor. The system uses the sampling rate setting to selectively mark the monitoring bit in the header of an incoming packet. Marked packets tell the CPU that the packets are subject to sFlow sampling.

sFlow configuration considerations

This section lists the sFlow configuration considerations on Brocade ICX 6650 devices.

You can use QoS queue 1 for priority traffic, even when sFlow is enabled on the port. QoS queue 1 is reserved for sFlow and is not used by other packets. Any non-sFlow packets assigned to QoS queue 1 will be directed to QoS queue 0.

sFlow and hardware support

- Brocade ICX 6650 devices support sFlow packet sampling of inbound traffic only. These devices do not sample outbound packets. However, Brocade ICX 6650 devices support byte and packet count statistics for both traffic directions.
- sFlow is supported on all Ethernet ports (10/100, Gbps, and 10 Gbps)

sFlow and CPU utilization

Enabling sFlow may cause a slight and noticeable increase of up to 20% in CPU utilization. In typical scenarios, this is normal behavior for sFlow, and does not affect the functionality of other features on the switch.

sFlow and source address

The sampled sFlow data sent to the collectors includes an `agent_address` field. This field identifies the IP address of the device that sent the data:

- On a Layer 2 Switch, `agent_address` is the Layer 2 Switch management IP address. You must configure the management IP address in order to export sFlow data from the device. If the switch has both an IPv4 and IPv6 address, the `agent_address` is the IPv4 address. If the switch has an IPv6 address only, the `agent_address` is the global IPv6 address.
- On a Layer 3 Switch with IPv6 interfaces only, sFlow looks for an IPv6 address in the following order, and uses the first address found:
 - The first IPv6 address on the lowest-numbered loopback interface
 - The first IPv6 address on the lowest-numbered VE interface
 - The first IPv6 address on any interface
- On a Layer 3 Switch with both IPv4 and IPv6 interfaces, or with IPv4 interfaces only, sFlow looks for an IP address in the following order, and uses the first address found:
 - The IPv4 router ID configured by the `ip router-id` command
 - The first IPv4 address on the lowest-numbered loopback interface
 - The first IPv4 address on the lowest-numbered virtual interface
 - The first IPv4 address on any interface

NOTE

The device uses the router ID only if the device also has an IP interface with the same address. Router ID is not supported on IPv6 devices.

NOTE

If an IP address is not already configured when you enable sFlow, the feature uses the source address 0.0.0.0. To display the agent_address, enable sFlow, then enter the **show sflow** command. Refer to [“Enabling sFlow forwarding”](#) on page 263 and [“Displaying sFlow information”](#) on page 267.

NOTE

In sFlow version 5, you can set an arbitrary IPv4 or IPv6 address as the sFlow agent IP address. Refer to [“Specifying the sFlow agent IP address”](#) on page 265.

sFlow and source port

By default, sFlow sends data to the collector out of UDP source port 8888, but you can specify a different source port. For more information, refer to [“Changing the sFlow source port”](#) on page 263.

sFlow and sampling rate

The **sampling rate** is the average ratio of the number of packets incoming on an sFlow enabled port, to the number of flow samples taken from those packets. sFlow sampling can affect performance in some configurations.

Note that on the Brocade ICX 6650 devices, the configured sampling rate and the actual rate are the same. The software does not adjust the configured sampling rate as on other Brocade devices.

Configuring and enabling sFlow

NOTE

The commands in this section apply to sFlow version 2 and sFlow version 5. CLI commands that are specific to sFlow version 5 are documented in [“sFlow version 5 feature configuration”](#) on page 264.

To configure sFlow, perform the following tasks:

- Optional – If your device supports sFlow version 5, change the version used for exporting sFlow data
- Specify collector information. The collector is the external device to which you are exporting the sFlow data. You can specify up to four collectors.
- Optional – Change the polling interval
- Optional – Change the sampling rate
- Optional – Change the sFlow source port
- Enable sFlow globally
- Enable sFlow forwarding on individual interfaces
- Enable sFlow forwarding on individual trunk ports
- If your device supports sFlow version 5, configure sFlow version 5 features

NOTE

If you change the router ID or other IP address value that sFlow uses for its agent_address, you need to disable and then re-enable sFlow to cause the feature to use the new source address.

Specifying the collector

sFlow exports traffic statistics to an external collector. You can specify up to four collectors. You can specify more than one collector with the same IP address if the UDP port numbers are unique. You can have up to four unique combinations of IP addresses and UDP port numbers.

Specifying an sFlow collector on IPv4 devices

To specify an sFlow collector on an IPv4 device, enter a command such as the following.

```
Brocade(config)#sflow destination 10.10.10.1
```

This command specifies a collector with IPv4 address 10.10.10.1, listening for sFlow data on UDP port 6343.

Syntax: [no] sflow destination <ip-addr> [<dest-udp-port>]

The <ip-addr> parameter specifies the IP address of the collector.

The <dest-udp-port> parameter specifies the UDP port on which the sFlow collector will be listening for exported sFlow data. The default port number is 6343.

The sampled sFlow data sent to the collectors includes an agent_address field. This field identifies the device that sent the data. Refer to [“sFlow and source address”](#) on page 256.

Specifying an sFlow collector on IPv6 devices

To specify an sFlow collector on an IPv6 device, enter a command such as the following.

```
Brocade(config)#sflow destination ipv6 2001:DB8:0::0b:02a
```

This command specifies a collector with IPv6 address 2001:DB8:0::0b:02a, listening for sFlow data on UDP port 6343.

Syntax: [no] sflow destination ipv6 <ip-addr> [<dest-udp-port>]

The <ip-addr> parameter specifies the IP address of the collector.

The <dest-udp-port> parameter specifies the UDP port on which the sFlow collector will be listening for exported sFlow data. The default port number is 6343.

If the IPv6 address you specify is a link-local address on a Layer 3 switch, you must also specify the **outgoing-interface ethernet** <stack-unit>/<slot>/<port> or the **ve** <port-num>. This identifies the outgoing interface through which the sampled packets will be sent.

The sampled sFlow data sent to the collectors includes an agent_address field. This field identifies the device that sent the data. Refer to “[sFlow and source address](#)” on page 256.

Changing the polling interval

The polling interval defines how often sFlow byte and packet counter data for a port are sent to the sFlow collectors. If multiple ports are enabled for sFlow, the Brocade ICX 6650 device staggers transmission of the counter data to smooth performance. For example, if sFlow is enabled on two ports and the polling interval is 20 seconds, the Brocade ICX 6650 device sends counter data every ten seconds. The counter data for one of the ports are sent after ten seconds, and counter data for the other port are sent after an additional ten seconds. Ten seconds later, new counter data for the first port are sent. Similarly, if sFlow is enabled on five ports and the polling interval is 20 seconds, the Brocade device sends counter data every four seconds.

The default polling interval is 20 seconds. You can change the interval to a value from 1 to any higher value. The interval value applies to all interfaces on which sFlow is enabled. If you set the polling interval to 0, counter data sampling is disabled.

To change the polling interval, enter a command such as the following at the global CONFIG level of the CLI.

```
Brocade(config)#sflow polling-interval 30
```

Syntax: [no] sflow polling-interval <secs>

The <secs> parameter specifies the interval and can be from 1 to any higher value. The default is 20 seconds. If you specify 0, counter data sampling is disabled.

Changing the sampling rate

The sampling rate is the average ratio of the number of packets incoming on an sFlow-enabled port, to the number of flow samples taken from those packets.

You can change the default (global) sampling rate. You also can change the rate on an individual port, overriding the default sampling rate of 512. With a sampling rate of 512, on average, one in every 512 packets forwarded on an interface is sampled.

Configuration considerations

The sampling rate is a fraction in the form $1/N$, meaning that, on average, one out of every N packets will be sampled. The **sflow sample** command at the global level or port level specifies N , the denominator of the fraction. Thus a higher number for the denominator means a lower sampling rate since fewer packets are sampled. Likewise, a lower number for the denominator means a higher sampling rate because more packets are sampled. For example, if you change the denominator from 512 to 128, the sampling rate increases because four times as many packets will be sampled.

NOTE

Brocade recommends that you do not change the denominator to a value lower than the default. Sampling requires CPU resources. Using a low denominator for the sampling rate can cause high CPU utilization.

Configured rate and actual rate

When you enter a sampling rate value, this value is the *configured rate* as well as the *actual sampling rate*.

Change to global rate

If you change the global sampling rate, the change is applied to all sFlow-enabled ports **except** those ports on which you have already explicitly set the sampling rate. For example, suppose that sFlow is enabled on ports 1/1/1, 1/1/2, and 1/1/3. If you configure the sampling rate on port 1/1/1 but leave the other two ports using the default rate, then a change to the global sampling rate applies to ports 1/1/2 and 1/1/3 but not port 1/1/1. sFlow assumes that you want to continue using the sampling rate you explicitly configured on an individual port even if you globally change the sampling rate for the other ports.

Module rate

While different ports on a module may be configured to have different sampling rates, the hardware for the module will be programmed to take samples at a single rate (the module sampling rate). The module sampling rate will be the highest sampling rate (i.e. lowest number) configured for any of the ports on the module.

When ports on a given module are configured with different sampling rates, the CPU discards some of the samples supplied by the hardware for ports with configured sampling rates which are lower than the module sampling rate. This is referred to as subsampling, and the ratio between the port sampling rate and the module sampling rate is known as the subsampling factor. For example, if the module in slot 1 has sFlow enabled on ports 1/1/1 and 1/1/3, and port 1/1/1 is using the default sampling rate of 512, and port 1/1/3 is configured explicitly for a rate of 2048, then the module sampling rate will be 512 because this is the highest port sampling rate (lowest number). The subsampling factor for port 1/1/1 will be 1, meaning that every sample taken by the hardware will be exported, while the subsampling factor for port 1/1/3 will be 4, meaning that one out of every four samples taken by the hardware will be exported. Whether a port's sampling rate is configured explicitly, or whether it uses the global default setting, has no effect on the calculations.

You do not need to perform any of these calculations to change a sampling rate. For simplicity, the syntax information in this section lists the valid sampling rates. You can display the rates you entered for the default sampling rate, module rates, and all sFlow-enabled ports by entering the **show sflow** command. Refer to [“Displaying sFlow information”](#) on page 267.

Sampling rate for new ports

When you enable sFlow on a port, the port's sampling rate is set to the global default sampling rate. This also applies to ports on which you disable and then re-enable sFlow. The port does not retain the sampling rate it had when you disabled sFlow on the port, even if you had explicitly set the sampling rate on the port.

Changing the default sampling rate

To change the default (global) sampling rate, enter a command such as the following at the global CONFIG level of the CLI.

```
Brocade(config)#sflow sample 2048
```

Syntax: [no] sflow sample <num>

The <num> parameter specifies the average number of packets from which each sample will be taken. The software rounds the value you enter to the next higher odd power of 2. This value becomes the actual default sampling rate and is one of the following:

- 2
- 8
- 32
- 128
- 512
- 2048
- 4096
- 8192
- 32768
- 131072
- 524288
- 2097152
- 8388608
- 33554432
- 134217728
- 536870912
- 2147483648

For example, if the configured sampling rate is 1000, then the actual rate is 2048 and 1 in 2048 packets are sampled by the hardware.

Changing the sampling rate of a module

You cannot change a module sampling rate directly. You can change a module sampling rate only by changing the sampling rate of a port on that module.

Changing the sampling rate on a port

You can configure an individual port to use a different sampling rate than the global default sampling rate. This is useful in cases where ports have different bandwidths. For example, if you are using sFlow on 10/100 ports and Gbps Ethernet ports, you might want to configure the Gbps ports to use a higher sampling rate (and thus gather fewer samples per number of packets) than the 10/100 ports.

To change the sampling rate on an individual port, enter a command such as the following at the configuration level for the port.

```
Brocade(config-if-1/1)#sflow sample 8192
```

Syntax: [no] sflow sample <num>

The <num> parameter specifies the average number of packets from which each sample will be taken. The software rounds the value you enter up to the next odd power of 2. The actual sampling rate becomes one of the values listed in [“Changing the default sampling rate”](#).

NOTE

Configuring a sampling rate on a port that is the primary port of a trunk applies that same sampling rate to all ports in the trunk.

Changing the sampling rate for a trunk port

You can configure an individual static trunk port to use a different sampling rate than the global default sampling rate. This feature is also supported on LACP trunk ports. This feature is useful in cases where ports have different bandwidths. For example, if you are using sFlow on 10/100 ports and Gbps Ethernet ports, you might want to configure the Gbps ports to use a higher sampling rate (and thus gather fewer samples per number of packets) than the 10/100 ports.

To configure a static trunk port to use a different sampling rate than the global default sampling rate, enter commands such as the following:

```
Brocade(config)#trunk e 1/1/1 to 1/1/2
Brocade(config-trunk-1/1/1-1/1/2)sflow sample 8192
```

Syntax: [no] sflow sample <num>

The <num> parameter specifies the average number of packets from which each sample will be taken. The software rounds the value you enter up to the next odd power of 2. The actual sampling rate becomes one of the values listed in [“Changing the default sampling rate”](#).

NOTE

Configuring a sampling rate on only the port that is the primary port of a trunk automatically applies that same sampling rate to all ports in the trunk.

Changing the sFlow source port

By default, sFlow sends data to the collector using UDP source port 8888, but you can change the source UDP port to any port number in the range 1025-65535.

To change the source UDP port, enter a command such as the following:

```
Brocade(config)#sflow source-port 8000
```

Syntax: [no] sflow source-port <num>

The <num> parameter specifies the sFlow source port.

Enabling sFlow forwarding

sFlow exports data only for the interfaces on which you enable sFlow forwarding. You can enable sFlow forwarding on Ethernet interfaces.

To enable sFlow forwarding, perform the following:

- Globally enable the sFlow feature
- Enable sFlow forwarding on individual interfaces
- Enable sFlow forwarding on individual trunk ports

NOTE

Before you enable sFlow, make sure the device has an IP address that sFlow can use as its source address. Refer to [“sFlow and source address”](#) on page 256 for the source address requirements.

NOTE

When you enable sFlow forwarding on an 802.1X-enabled interface, the samples taken from the interface include the username used to obtain access to either or both the inbound and outbound ports, if that information is available. For information about 802.1X, refer to the Brocade ICX 6650 Switch Security Configuration Guide.

Command syntax for enabling sFlow forwarding

This section shows how to enable sFlow forwarding.

Globally enabling sFlow forwarding

To enable sFlow forwarding, you must first enable it on a global basis, then on individual interfaces or trunk ports, or both.

To globally enable sFlow forwarding, enter the following command.

```
Brocade(config)#sflow enable
```

You can now enable sFlow forwarding on individual ports as described in the next two sections.

Syntax: [no] sflow enable

Enabling sFlow forwarding on individual interfaces

To enable sFlow forwarding enter commands such as the following.

```

Brocade(config)#sflow enable
Brocade(config)#interface ethernet 1/1/1 to 1/1/4
Brocade(config-mif-1/1/1-1/1/4)#sflow forwarding

```

These commands globally enable sFlow, then enable sFlow forwarding on Ethernet ports 1/1/1 – 1/1/4. You must use both the **sflow enable** and **sflow forwarding** commands to enable the feature.

Syntax: [no] sflow enable

Syntax: [no] sflow forwarding

Enabling sFlow forwarding on individual trunk ports

This feature is supported on individual ports of a static trunk group. It is also supported on LACP trunk ports.

NOTE

When you enable sFlow forwarding on a trunk port, only the primary port of the trunk group forwards sFlow samples.

To enable sFlow forwarding on a trunk port, enter commands such as the following.

```

Brocade(config)#sflow enable
Brocade(config)#trunk e 1/1/1 to 1/1/4
Brocade(config-trunk-1/1/1-1/1/4)#config-trunk-ind
Brocade(config-trunk-1/1/1-1/1/4)#sflow forwarding e 1/1/2

```

These commands globally enable sFlow, then enable sFlow forwarding on trunk port ethernet 1/1/2. You must use both the **sflow enable** and **sflow forwarding** commands to enable the feature.

Syntax: [no] sflow enable

Syntax: [no] sflow forwarding

sFlow version 5 feature configuration

NOTE

The commands in this section are supported when sFlow version 5 is enabled on the device. These commands are not supported with sFlow version 2. sFlow version 5 also supports all of the sFlow configuration commands in [“Configuring and enabling sFlow”](#) on page 257.

When sFlow version 5 is enabled on the device, you can do the following:

- Specify the sFlow version (version 2 or version 5)
- Specify the sFlow agent IP address
- Specify the maximum flow sample size
- Export CPU and memory usage Information to the sFlow collector
- Specify the polling interval for exporting CPU and memory usage information to the sFlow collector
- Export CPU-directed data (management traffic) to the sFlow collector

Egress interface ID for sampled broadcast and multicast packets

For broadcast and multicast traffic, the egress interface ID for sampled traffic is always 0x80000000. When broadcast and multicast packets are sampled, they are usually forwarded to more than one port. However, the output port field in an sFlow datagram supports the display of one egress interface ID only. Therefore, the sFlow version 5 agent always sets the output port ID to 0x80000000 for broadcast and multicast packets that are sampled.

Specifying the sFlow version format

If your device supports sFlow version 5, you can optionally specify the version used for exporting sFlow data. Refer [“Specifying the sFlow agent IP address”](#).

Specifying the sFlow agent IP address

The sampled sFlow data sent to the collectors includes an agent_address field. This field identifies the device (the sFlow agent) that sent the data. By default, the device automatically selects the sFlow agent IP address based on the configuration, as described in the section [“sFlow and source address”](#) on page 256. Alternatively, you can configure the device to instead use an arbitrary IPv4 or IPv6 address as the sFlow agent IP address.

To specify an IPv4 address as the sFlow agent IP address, enter a command such as the following

```
Brocade(config)#sflow agent-ip 10.10.10.1
```

Syntax: [no] sflow agent-ip <ipv4-addr>

The <ipv4-addr> specifies the address of the device that sent the data.

To specify an IPv6 address as the sFlow agent IP address, enter a command such as the following.

```
Brocade(config)#sflow agent-ip 2001:DB8:D0FF:FE48:4672
```

Syntax: [no] sflow agent-ip <ipv6-addr>

The <ipv6-addr> specifies the address of the device that sent the data.

Specifying the version used for exporting sFlow data

By default, when sFlow is enabled globally on the Brocade ICX 6650 device, the sFlow agent exports sFlow data in version 5 format. You can change this setting so that the sFlow agent exports data in version 2 format. You can switch between versions without rebooting the device or disabling sFlow.

NOTE

When the sFlow version number is changed, the system will reset sFlow counters and flow sample sequence numbers.

To specify the sFlow version used for exporting sFlow data, enter the following command.

```
Brocade(config)#sflow version 2
```

Syntax: [no] sflow version 2 | 5

The default is 5.

Specifying the maximum flow sample size

With sFlow version 5, you can specify the maximum size of the flow sample sent to the sFlow collector. If a packet is larger than the specified maximum size, then only the contents of the packet up to the specified maximum number of bytes is exported. If the size of the packet is smaller than the specified maximum, then the entire packet is exported.

For example, to specify 1024 bytes as the maximum flow sample size, enter the following command.

```
Brocade(config)# sflow max-packet-size 1024
```

Syntax: [no] sflow max-packet-size <size>

For both sFlow version 2 and version 5, the default maximum flow sample size is 256 bytes.

For sFlow version 5, the maximum flow sample size is 1300 bytes.

Exporting CPU and memory usage information to the sFlow collector

With sFlow version 5, you can optionally configure the sFlow agent on the Brocade device to export information about CPU and memory usage to the sFlow collector.

To export CPU usage and memory usage information, enter the following command.

```
Brocade(config)# sflow export system-info
```

Syntax: [no] sflow export system-info

By default, CPU usage information and memory usage information are not exported.

Specifying the polling interval for exporting CPU and memory usage information to the sFlow collector

The polling interval defines how often sFlow data for a port is sent to the sFlow collector. With sFlow version 5, you can optionally set the polling interval used for exporting CPU and memory usage information.

For example, to set the polling interval for exporting CPU and memory usage information to 30 seconds, enter the following command.

```
Brocade(config)# sflow export system-info 30
```

Syntax: [no] sflow export system-info <seconds>

You can specify a polling interval from 5 seconds to 1,800 seconds (30 minutes). The default polling interval for exporting CPU and memory usage information is 300 seconds (5 minutes).

Exporting CPU-directed data (management traffic) to the sFlow collector

You can select which and how often data destined to the CPU (for example, Telnet sessions) is sent to the sFlow collector.

CLI commands allow you to do the following:

- Enable the sFlow agent to export CPU-directed data
- Specify the sampling rate for exported CPU-directed data

Enabling the sFlow agent to export CPU-directed data

To enable the sFlow agent on a Brocade ICX 6650 device to export data destined to the CPU to the sFlow collector, enter the following command.

```
Brocade(config)# sflow export cpu-traffic
```

Syntax: [no] sflow export cpu-traffic

By default, this feature is disabled. The sFlow agent does not send data destined to the CPU to the sFlow collector.

Specifying the sampling rate for exported CPU-directed data

The sampling rate is the average ratio of the number of packets incoming on an sFlow-enabled port, to the number of flow samples taken from those packets. You can optionally set the sampling rate for CPU-directed data exported to the sFlow collector. For example, to set this sampling rate to 2048, enter the following command.

```
Brocade(config)# sflow export cpu-traffic 2048
```

Syntax: [no] sflow export cpu-traffic <rate>

The default sampling rate depends on the Brocade device being configured. Refer to [“Changing the sampling rate”](#) on page 259 for the default sampling rate for each kind of Brocade device.

Displaying sFlow information

To display sFlow configuration information and statistics, enter the following command at any level of the CLI.

```

Brocade#show sflow
Flow version: 5
sFlow services are enabled.
sFlow agent IPv6 address: 2001:DB8:2
2 collector destinations configured:
Collector IPv6 2001:DB8:1, UDP 6343
Collector IP 10.37.224.233, UDP 6343
Configured UDP source port: 2000
Polling interval is 20 seconds.
Configured default sampling rate: 1 per 100 packets.
Actual default sampling rate: 1 per 100 packets.
The maximum sFlow sample size: 1300.
exporting cpu-traffic is enabled.
exporting cpu-traffic sample rate: 10.
83715 UDP packets exported
8931 sFlow flow samples collected.
sFlow ports: ethe 1/1/11 ethe 1/1/32 ethe 1/2/1
Module Sampling Rates
-----
Port Sampling Rates
-----
Port=1/1/11, configured rate=25, actual rate=25
Port=1/1/32, configured rate=10, actual rate=10
Port=1/2/1, configured rate=10, actual rate=10

```

Syntax: show sflow

The show sflow command displays the following information.

TABLE 56 sFlow information

Parameter	Definition
sFlow version	The version of sFlow enabled on the device, which can be one of the following: <ul style="list-style-type: none"> • 2 • 5
sFlow services	The feature state, which can be one of the following: <ul style="list-style-type: none"> • disabled • enabled
sFlow agent IP address	The IP address that sFlow is using in the agent_address field of packets sent to the collectors. Refer to “sFlow and source address” on page 256.
Collector	The collector information. The following information is displayed for each collector: <ul style="list-style-type: none"> • IP address • UDP port If more than one collector is configured, the line above the collectors indicates how many have been configured.
Configured UDP source port	The UDP source port used to send data to the collector.
Polling interval	The port counter polling interval.
Configured default sampling rate	The configured global sampling rate. If you changed the global sampling rate, the value you entered is shown here. The actual rate calculated by the software based on the value you entered is listed on the next line, “Actual default sampling rate”.
Actual default sampling rate	The actual default sampling rate.

TABLE 56 sFlow information (Continued)

Parameter	Definition
The maximum sFlow sample size	The maximum size of a flow sample sent to the sFlow collector.
exporting cpu-traffic	Indicates whether or not the sFlow agent is configured to export data destined to the CPU (e.g., Telnet sessions) to the sFlow collector: <ul style="list-style-type: none"> • enabled • disabled
exporting cpu-traffic sample rate	The sampling rate for CPU-directed data, which is the average ratio of the number of incoming packets on an sFlow-enabled port, to the number of flow samples taken from those packets.
exporting system-info	Indicates whether or not the sFlow agent is configured to export information about CPU and memory usage to the sFlow collector: <ul style="list-style-type: none"> • enabled • disabled
exporting system-info polling interval	Specifies the interval, in seconds, that sFlow data is sent to the sFlow collector.
UDP packets exported	The number of sFlow export packets the Brocade ICX 6650 device has sent. NOTE: Each UDP packet can contain multiple samples.
sFlow samples collected	The number of sampled packets that have been sent to the collectors.
sFlow ports	The ports on which you enabled sFlow.
Module Sampling Rates	The configured and actual sampling rates for each module. If a module does not have any sFlow-enabled ports, the rates are listed as 0.
Port Sampling Rates	The configured and actual sampling rates for each sFlow-enabled port. The Subsampling factor indicates how many times the sampling rate of the port's module is multiplied to achieve the port's sampling rate. Because of the way the actual sampling rates are computed, the Subsampling factors are always whole numbers.

Clearing sFlow statistics

To clear the UDP packet and sFlow sample counters in the **show sflow** display, enter the following command.

```
Brocade#clear statistics
```

Syntax: clear statistics

This command clears the values in the following fields of the **show sflow** display:

- UDP packets exported
- sFlow samples collected

NOTE

This command also clears the statistics counters used by other features.

Utilization list for an uplink port

You can configure uplink utilization lists that display the percentage of a given uplink port bandwidth that is used by a specific list of downlink ports. The percentages are based on 30-second intervals of RMON packet statistics for the ports. Both transmit and receive traffic is counted in each percentage.

NOTE

This feature is intended for ISP or collocation environments in which downlink ports are dedicated to various customers' traffic and are isolated from one another. If traffic regularly passes between the downlink ports, the information displayed by the utilization lists does not provide a clear depiction of traffic exchanged by the downlink ports and the uplink port.

Each uplink utilization list consists of the following:

- Utilization list number (1, 2, 3, or 4)
- One or more uplink ports
- One or more downlink ports

Each list displays the uplink port and the percentage of that port bandwidth that was utilized by the downlink ports over the most recent 30-second interval.

You can configure up to four bandwidth utilization lists.

Utilization list for an uplink port command syntax

To configure an uplink utilization list, enter commands such as the following. The commands in this example configure a link utilization list with port 1/1/1 as the uplink port and ports 1/1/2 and 1/1/3 as the downlink ports.

```
Brocade(config)#relative-utilization 1 uplink eth 1/1/1 downlink eth 1/1/2 to
1/1/3
Brocade(config)#write memory
```

Syntax: `[no] relative-utilization <num> uplink ethernet <stack-unit>/<slot>/<port> [to <stack-unit>/<slot>/<port>] downlink ethernet <stack-unit>/<slot>/<port> [to <stack-unit>/<slot>/<port>]`

The `<num>` parameter specifies the list number. You can configure up to four lists. Specify a number from 1 – 4.

The **uplink ethernet** parameters and the port numbers you specify after the parameters indicate the uplink ports.

The **downlink ethernet** parameters and the port numbers you specify after the parameters indicate the downlink ports.

Specify the Ethernet port in the `<stack-unit>/<slot>/<port>` format. Stack-unit is 1.

Displaying utilization percentages for an uplink

After you configure an uplink utilization list, you can display the list to observe the percentage of the uplink bandwidth that each of the downlink ports used during the most recent 30-second port statistics interval. The number of packets sent and received between the two ports is listed, as well as the ratio of each individual downlink port packets relative to the total number of packets on the uplink.

To display an uplink utilization list, enter a command such as the following at any level of the CLI.

```
Brocade#show relative-utilization 1
uplink: ethe 1
30-sec total uplink packet count = 3011
packet count ratio (%)
  1/ 2:60   1/ 3:40
```

In this example, ports 1/1/2 and 1/1/3 are sending traffic to port 1/1/1. Port 1/1/2 and port 1/1/3 are isolated (not shared by multiple clients) and typically do not exchange traffic with other ports except for the uplink port, 1/1/1.

Syntax: `show relative-utilization <num>`

The `<num>` parameter specifies the list number.

NOTE

The example above represents a pure configuration in which traffic is exchanged only by ports 1/1/2 and 1/1/1, and by ports 1/1/3 and 1/1/1. For this reason, the percentages for the two downlink ports equal 100%. In some cases, the percentages do not always equal 100%. This is true in cases where the ports exchange some traffic with other ports in the system or when the downlink ports are configured together in a port-based VLAN.

In the following example, ports 1/1/2 and 1/1/3 are in the same port-based VLAN.

```
Brocade#show relative-utilization 1
uplink: ethe 1
30-sec total uplink packet count = 3011
packet count ratio (%)
  1/ 2:100   1/ 3:100
```

Here is another example showing different data for the same link utilization list. In this example, port 1/1/2 is connected to a hub and is sending traffic to port 1/1/1. Port 1/1/3 is unconnected.

```
Brocade#show relative-utilization 1
uplink: ethe 1
30-sec total uplink packet count = 2996
packet count ratio (%)
  1 /2:100   1/ 3:---
```

11 Utilization list for an uplink port

Syslog messages

Table 57 lists all of the Syslog messages. Note that some of the messages apply only to Layer 3 Switches.

NOTE

This chapter does not list Syslog messages that can be displayed when a debug option is enabled.

The messages are listed by message level, in the following order, then by message type:

- Emergencies (none)
- Alerts
- Critical
- Errors
- Warnings
- Notifications
- Informational
- Debugging

TABLE 57 Brocade Syslog messages

Message level	Message	Explanation
Alert	<num-modules> modules and 1 power supply, need more power supply!!	Indicates that the chassis needs more power supplies to run the modules in the chassis. The <num-modules> parameter indicates the number of modules in the chassis.
Alert	Fan <num>, <location>, failed	A fan has failed. The <num> is the fan number. The <location> describes where the failed fan is in the chassis.
Alert	MAC Authentication failed for <mac-address> on <portnum>	RADIUS authentication was successful for the specified <mac-address> on the specified <portnum>; however, the VLAN returned in the RADIUS Access-Accept message did not refer to a valid VLAN or VLAN ID on the Brocade device. This is treated as an authentication failure.
Alert	MAC Authentication failed for <mac-address> on <portnum> (Invalid User)	RADIUS authentication failed for the specified <mac-address> on the specified <portnum> because the MAC address sent to the RADIUS server was not found in the RADIUS server users database.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Alert	MAC Authentication failed for <mac-address> on <portnum> (No VLAN Info received from RADIUS server)	RADIUS authentication was successful for the specified <mac-address> on the specified <portnum>; however, dynamic VLAN assignment was enabled for the port, but the RADIUS Access-Accept message did not include VLAN information. This is treated as an authentication failure.
Alert	MAC Authentication failed for <mac-address> on <portnum> (Port is already in another radius given vlan)	RADIUS authentication was successful for the specified <mac-address> on the specified <portnum>; however, the RADIUS Access-Accept message specified a VLAN ID, although the port had previously been moved to a different RADIUS-assigned VLAN. This is treated as an authentication failure.
Alert	MAC Authentication failed for <mac-address> on <portnum> (RADIUS given vlan does not exist)	RADIUS authentication was successful for the specified <mac-address> on the specified <portnum>; however, the RADIUS Access-Accept message specified a VLAN that does not exist in the Brocade configuration. This is treated as an authentication failure.
Alert	MAC Authentication failed for <mac-address> on <portnum> (RADIUS given VLAN does not match with TAGGED vlan)	Multi-device port authentication failed for the <mac-address> on a tagged port because the packet with this MAC address as the source was tagged with a VLAN ID different from the RADIUS-supplied VLAN ID.
Alert	Management module at slot <slot-num> state changed from <module-state> to <module-state>.	Indicates a state change in a management module. The <slot-num> indicates the chassis slot containing the module. The <module-state> can be one of the following: <ul style="list-style-type: none"> • active • standby • crashed • coming-up • unknown
Alert	OSPF LSA Overflow, LSA Type = <lsa-type>	Indicates an LSA database overflow. The <lsa-type> parameter indicates the type of LSA that experienced the overflow condition. The LSA type is one of the following: <ul style="list-style-type: none"> • 1 – Router • 2 – Network • 3 – Summary • 4 – Summary • 5 – External
Alert	OSPF Memory Overflow	OSPF has run out of memory.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Alert	Power supply <num>, <location>, failed	A power supply has failed. The <num> is the power supply number. The <location> describes where the failed power supply is in the chassis.
Alert	System: Module in slot <slot-num> encountered PCI config read error: Bus <PCI-bus-number>, Dev <PCI-device-number>, Reg Offset <PCI-config-register-offset>.	The module encountered a hardware configuration read error.
Alert	System: Module in slot <slot-num> encountered PCI config write error: Bus <PCI-bus-number>, Dev <PCI-device-number>, Reg Offset <PCI-config-register-offset>.	The module encountered a hardware configuration write error.
Alert	System: Module in slot <slot-num> encountered PCI memory read error: Mem Addr <memory-address>	The module encountered a hardware memory read error. The <memory-address> is in hexadecimal format.
Alert	System: Module in slot <slot-num> encountered PCI memory write error: Mem Addr <memory-address>.	The module encountered a hardware memory write error. The <memory-address> is in hexadecimal format.
Alert	System: Module in slot <slot-num> encountered unrecoverable PCI bridge validation failure. Module will be deleted.	The module encountered an unrecoverable (hardware) bridge validation failure. The module will be disabled or powered down.
Alert	System: Module in slot <slot-num> encountered unrecoverable PCI config read failure. Module will be deleted.	The module encountered an unrecoverable hardware configuration read failure. The module will be disabled or powered down.
Alert	System: Module in slot <slot-num> encountered unrecoverable PCI config write failure. Module will be deleted.	The module encountered an unrecoverable hardware configuration write failure. The module will be disabled or powered down.
Alert	System: Module in slot <slot-num> encountered unrecoverable PCI device validation failure. Module will be deleted.	The module encountered an unrecoverable (hardware) device validation failure. The module will be disabled or powered down.
Alert	System: Module in slot <slot-num> encountered unrecoverable PCI memory read failure. Module will be deleted.	The module encountered an unrecoverable hardware memory read failure. The module will be disabled or powered down.
Alert	System: Module in slot <slot-num> encountered unrecoverable PCI memory write failure. Module will be deleted.	The module encountered an unrecoverable hardware memory write failure. The module will be disabled or powered down.
Alert	System: No Free Tcam Entry available. System will be unstable	In FWS devices, the limit for the TCAM routing entries has been reached. You must reboot the device.
Alert	System: Temperature is over shutdown level, system is going to be reset in <num> seconds	The chassis temperature has risen above shutdown level. The system will be shut down in the amount of time indicated.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Alert	Temperature <degrees> C degrees, warning level <warn-degrees> C degrees, shutdown level <shutdown-degrees> C degrees	Indicates an over temperature condition on the active module. The <degrees> value indicates the temperature of the module. The <warn-degrees> value is the warning threshold temperature configured for the module. The <shutdown-degrees> value is the shutdown temperature configured for the module.
Critical	Authentication shut down <portnum> due to DOS attack	Denial of Service (DoS) attack protection was enabled for multi-device port authentication on the specified <portnum>, and the per-second rate of RADIUS authentication attempts for the port exceeded the configured limit. The Brocade device considers this to be a DoS attack and disables the port.
Debug	BGP4: Not enough memory available to run BGP4	The device could not start the BGP4 routing protocol because there is not enough memory available.
Debug	DOT1X: Not enough memory	There is not enough system memory for 802.1X authentication to take place. Contact Brocade Technical Support.
Error	No of prefixes received from BGP peer <ip-addr> exceeds maximum prefix-limit...shutdown	The Layer 3 Switch has received more than the specified maximum number of prefixes from the neighbor, and the Layer 3 Switch is therefore shutting down its BGP4 session with the neighbor.
Informational	IPv6: IPv6 protocol disabled on the device from <session-id>	IPv6 protocol was disabled on the device during the specified session.
Informational	IPv6: IPv6 protocol enabled on the device from <session-id>	IPv6 protocol was enabled on the device during the specified session.
Informational	MAC Filter applied to port <port-id> by <username> from <session-id> (filter id=<filter-ids>)	Indicates a MAC address filter was applied to the specified port by the specified user during the specified session. <session-id> can be console, telnet, ssh, web, or snmp. <filter-ids> is a list of the MAC address filters that were applied.
Informational	MAC Filter removed from port <port-id> by <username> from <session-id> (filter id=<filter-ids>)	Indicates a MAC address filter was removed from the specified port by the specified user during the specified session. <session-id> can be console, telnet, ssh, web, or snmp. <filter-ids> is a list of the MAC address filters that were removed.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Informational	Security: Password has been changed for user <username> from <session-id>	Password of the specified user has been changed during the specified session ID or type. <session-id> can be console, telnet, ssh, web, or snmp.
Informational	<device-name> : Logical link on interface ethernet <slot#/port#> is down.	The specified ports were logically brought down while singleton was configured on the port.
Informational	<device-name>: Logical link on interface ethernet <slot#/port#> is up.	The specified ports were logically brought up while singleton was configured on the port.
Informational	<user-name> login to PRIVILEGED mode	A user has logged into the Privileged EXEC mode of the CLI. The <user-name> is the user name.
Informational	<user-name> login to USER EXEC mode	A user has logged into the USER EXEC mode of the CLI. The <user-name> is the user name.
Informational	<user-name> logout from PRIVILEGED mode	A user has logged out of Privileged EXEC mode of the CLI. The <user-name> is the user name.
Informational	<user-name> logout from USER EXEC mode	A user has logged out of the USER EXEC mode of the CLI. The <user-name> is the user name.
Informational	ACL <ACL id> added deleted modified from console telnet ssh web snmp session	A user created, modified, deleted, or applied an ACL through a Web, SNMP, console, SSH, or Telnet session.
Informational	Bridge is new root, vlan <vlan-id>, root ID <root-id>	A Spanning Tree Protocol (STP) topology change has occurred, resulting in the Brocade device becoming the root bridge. The <vlan-id> is the ID of the VLAN in which the STP topology change occurred. The <root-id> is the STP bridge root ID.
Informational	Bridge root changed, vlan <vlan-id>, new root ID <string>, root interface <portnum>	A Spanning Tree Protocol (STP) topology change has occurred. The <vlan-id> is the ID of the VLAN in which the STP topology change occurred. The <root-id> is the STP bridge root ID. The <portnum> is the number of the port connected to the new root bridge.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Informational	Bridge topology change, vlan <vlan-id>, interface <portnum>, changed state to <stp-state>	A Spanning Tree Protocol (STP) topology change has occurred on a port. The <vlan-id> is the ID of the VLAN in which the STP topology change occurred. The <portnum> is the port number. The <stp-state> is the new STP state and can be one of the following: <ul style="list-style-type: none"> • disabled • blocking • listening • learning • forwarding • unknown
Informational	Cold start	The device has been powered on.
Informational	DHCP : snooping on untrusted port <portnum>, type <number>, drop	The device has indicated that the DHCP client receives DHCP server reply packets on untrusted ports, and packets are dropped.
Informational	DOT1X : port <portnum> - mac <mac address> Cannot apply an ACL or MAC filter on a port member of a VE (virtual interface)	The RADIUS server returned an IP ACL or MAC address filter, but the port is a member of a virtual interface (VE).
Informational	DOT1X : port <portnum> - mac <mac address> cannot remove inbound ACL	An error occurred while removing the inbound ACL.
Informational	DOT1X : port <portnum> - mac <mac address> Downloading a MAC filter, but MAC filter have no effect on router port	The RADIUS server returned an MAC address filter, but the <portnum> is a router port (it has one or more IP addresses).
Informational	DOT1X : port <portnum> - mac <mac address> Downloading an IP ACL, but IP ACL have no effect on a switch port	The RADIUS server returned an IP ACL, but the <portnum> is a switch port (no IP address).
Informational	DOT1X : port <portnum> - mac <mac address> Error - could not add all MAC filters	The Brocade device was unable to implement the MAC address filters returned by the RADIUS server.
Informational	DOT1X : port <portnum> - mac <mac address> Invalid MAC filter ID - this ID doesn't exist	The MAC address filter ID returned by the RADIUS server does not exist in the Brocade configuration.
Informational	DOT1X : port <portnum> - mac <mac address> Invalid MAC filter ID - this ID is user defined and cannot be used	The port was assigned a MAC address filter ID that had been dynamically created by another user.
Informational	DOT1X : port <portnum> - mac <mac address> is unauthorized because system resource is not enough or the invalid information to set the dynamic assigned IP ACLs or MAC address filters	802.1X authentication failed for the Client with the specified <mac address> on the specified <portnum> either due to insufficient system resources on the device, or due to invalid IP ACL or MAC address filter information returned by the RADIUS server.
Informational	DOT1X : port <portnum> - mac <mac address> Port is already bound with MAC filter	The RADIUS server returned a MAC address filter, but a MAC address filter had already been applied to the port.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Informational	DOT1X : port <portnum> - mac <mac address> This device doesn't support ACL with MAC Filtering on the same port	The RADIUS server returned a MAC address filter while an IP ACL was applied to the port, or returned an IP ACL while a MAC address filter was applied to the port.
Informational	DOT1X Port <portnum> is unauthorized because system resource is not enough or the invalid information to set the dynamic assigned IP ACLs or MAC address filters	802.1X authentication could not take place on the port. This happened because strict security mode was enabled and one of the following occurred: <ul style="list-style-type: none"> Insufficient system resources were available on the device to apply an IP ACL or MAC address filter to the port Invalid information was received from the RADIUS server (for example, the Filter-ID attribute did not refer to an existing IP ACL or MAC address filter)
Informational	DOT1X: Port <portnum> currently used vlan-id changes to <vlan-id> due to dot1x-RADIUS vlan assignment	A user has completed 802.1X authentication. The profile received from the RADIUS server specifies a VLAN ID for the user. The port to which the user is connected has been moved to the VLAN indicated by <vlan-id>.
Informational	DOT1X: Port <portnum> currently used vlan-id is set back to port default vlan-id <vlan-id>	The user connected to <portnum> has disconnected, causing the port to be moved back into its default VLAN, <vlan-id>.
Informational	DOT1X: Port <portnum>, AuthControlledPortStatus change: authorized	The status of the interface controlled port has changed from unauthorized to authorized.
Informational	DOT1X: Port <portnum>, AuthControlledPortStatus change: unauthorized	The status of the interface controlled port has changed from authorized to unauthorized.
Informational	Enable super port-config read-only password deleted added modified from console telnet ssh web snmp OR Line password deleted added modified from console telnet ssh web snmp	A user created, re-configured, or deleted an Enable or Line password through the Web, SNMP, console, SSH, or Telnet session.
Informational	ERR_DISABLE: Interface ethernet <port-number>, err-disable recovery timeout	Errdisable recovery timer expired and the port has been reenabled.
Informational	ERR_DISABLE: Interface ethernet 16, err-disable recovery timeout	If the wait time (port is down and is waiting to come up) expires and the port is brought up the following message is displayed.
Informational	ERR_DISABLE: Link flaps on port ethernet 16 exceeded threshold; port in err-disable state	The threshold for the number of times that a port link toggles from "up" to "down" and "down" to "up" has been exceeded.
Informational	Interface <portnum>, line protocol down	The line protocol on a port has gone down. The <portnum> is the port number.
Informational	Interface <portnum>, line protocol up	The line protocol on a port has come up. The <portnum> is the port number.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Informational	Interface <portnum>, state down	A port has gone down. The <portnum> is the port number.
Informational	Interface <portnum>, state up	A port has come up. The <portnum> is the port number.
Informational	MAC Based Vlan Disabled on port <port id>	A MAC Based VLAN has been disabled on a port
Informational	MAC Based Vlan Enabled on port <port id>	A MAC Based VLAN has been enabled on a port.
Informational	MAC Filter added deleted modified from console telnet ssh web snmp session filter id = <MAC filter ID>, src mac = <Source MAC address> any, dst mac = <Destination MAC address> any	A user created, modified, deleted, or applied this MAC address filter through the Web, SNMP, console, SSH, or Telnet session.
Informational	MSTP: BPDU-guard interface ethernet <port-number> detect (Received BPDU), putting into err-disable state.	BPDU guard violation occurred in MSTP.
Informational	OPTICAL MONITORING: port <port-number> is not capable.	The optical transceiver is qualified by Brocade, but the transceiver does not support digital optical performance monitoring.
Informational	Port <p> priority changed to <n>	A port priority has changed.
Informational	Port <portnum>, srcip-security max-ipaddr-per-int reached.Last IP=<ipaddr>	The address limit specified by the srcip-security max-ipaddr-per-interface command has been reached for the port.
Informational	Port <portnum>, srcip-security max-ipaddr-per-int reached.Last IP=<ipaddr>	The address limit specified by the srcip-security max-ipaddr-per-interface command has been reached for the port.
Informational	Security: console login by <username> to USER PRIVILEGE EXEC mode	The specified user logged into the device console into the specified EXEC mode.
Informational	Security: console logout by <username>	The specified user logged out of the device console.
Informational	Security: telnet SSH login by <username> from src IP <ip-address>, src MAC <mac-address> to USER PRIVILEGE EXEC mode	The specified user logged into the device using Telnet or SSH from either or both the specified IP address and MAC address. The user logged into the specified EXEC mode.
Informational	Security: telnet SSH logout by <username> from src IP <ip-address>, src MAC <mac-address> to USER PRIVILEGE EXEC mode	The specified user logged out of the device. The user was using Telnet or SSH to access the device from either or both the specified IP address and MAC address. The user logged out of the specified EXEC mode.
Informational	SNMP read-only community read-write community contact location user group view engineld trap [host] [<value-str>] deleted added modified from console telnet ssh web snmp session	A user made SNMP configuration changes through the Web, SNMP, console, SSH, or Telnet session. [<value-str>] does not appear in the message if SNMP community or engineld is specified.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Informational	SNMP Auth. failure, intruder IP: <ip-addr>	A user has tried to open a management session with the device using an invalid SNMP community string. The <ip-addr> is the IP address of the host that sent the invalid community string.
Informational	SSH telnet server enabled disabled from console telnet ssh web snmp session [by user <username>]	A user enabled or disabled an SSH or Telnet session, or changed the SSH enable/disable configuration through the Web, SNMP, console, SSH, or Telnet session.
Informational	startup-config was changed or startup-config was changed by <user-name>	A configuration change was saved to the startup-config file. The <user-name> is the user ID, if they entered a user ID to log in.
Informational	STP: Root Guard Port <port-number>, VLAN <vlan-ID> consistent (Timeout).	Root guard unblocks a port.
Informational	STP: Root Guard Port <port-number>, VLAN <vlan-ID> inconsistent (Received superior BPDU).	Root guard blocked a port.
Informational	STP: VLAN <vlan id> BPDU-Guard on Port <port id> triggered (Received BPDU), putting into err-disable state	The BPDU guard feature has detected an incoming BPDU on {vlan-id, port-id}
Informational	STP: VLAN <vlan id> Root-Protect Port <port id>, Consistent (Timeout)	The root protect feature goes back to the consistent state.
Informational	STP: VLAN <vlan id> Root-Protect Port <port id>, Inconsistent (Received superior BPDU)	The root protect feature has detected a superior BPDU and goes into the inconsistent state on {vlan-id, port-id}.
Informational	STP: VLAN <vlan-id> BPDU-guard port <port-number> detect (Received BPDU), putting into err-disable state	STP placed a port into an errdisable state for BPDU guard.
Informational	STP: VLAN 1 BPDU-guard port <port-number> detect (Received BPDU), putting into err-disable state.	BPDU guard violation in occurred in STP or RSTP.
Informational	Syslog server <IP-address> deleted added modified from console telnet ssh web snmp OR Syslog operation enabled disabled from console telnet ssh web snmp	A user made Syslog configuration changes to the specified Syslog server address, or enabled or disabled a Syslog operation through the Web, SNMP, console, SSH, or Telnet session.
Informational	SYSTEM: Optic is not Brocade-qualified (<port-number>)	Brocade does not support the optical transceiver.
Informational	System: Fan <fan id> (from left when facing right side), ok	The fan status has changed from fail to normal.
Informational	System: Fan speed changed automatically to <fan speed>	The system automatically changed the fan speed to the speed specified in this message.
Informational	System: No free TCAM entry. System will be unstable	There are no TCAM entries available.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Informational	System: Static Mac entry with Mac Address <mac-address> is added from the <unit>/<slot>/<port> to <unit>/<slot>/<port> on VLANs <vlan-id> to <vlan-id>	A MAC address is added to a range of interfaces, which are members of the specified VLAN range.
Informational	System: Static Mac entry with Mac Address <mac-address> is added to ethe <unit>/<slot>/<port> to <unit>/<slot>/<port> on <vlan-id>	A MAC address is added to a range of interfaces, which are members of the specified VLAN.
Informational	System: Static Mac entry with Mac Address <mac-address> is added to portnumber <unit>/<slot>/<port> on VLAN <vlan-id>	A MAC address is added to an interface and the interface is a member of the specified VLAN.
Informational	System: Static Mac entry with Mac Address <mac-address> is deleted from ethe <unit>/<slot>/<port> to <unit>/<slot>/<port> on <vlan-id>	A MAC address is deleted from a range of interfaces, which are members of the specified VLAN.
Informational	System: Static Mac entry with Mac Address <mac-address> is deleted from ethe <unit>/<slot>/<port> to <unit>/<slot>/<port> on VLANs <vlan-id> to <vlan-id>	A MAC address is deleted from a range of interfaces, which are members of the specified VLAN range.
Informational	System: Static Mac entry with Mac Address <mac-address> is deleted from portnumber <unit>/<slot>/<port> on <vlan-id>	A MAC address is deleted from an interface and the interface is a member of the specified VLAN.
Informational	System: Static Mac entry with Mac Address <mac-address> is deleted from portnumber <unit>/<slot>/<port> on VLANs <vlan-id> to <vlan-id>	A MAC address is deleted from an interface and the interface is a member of the specified VLAN range.
Informational	telnet SSH web access [by <username>] from src IP <source ip address>, src MAC <source MAC address> rejected, <n> attempts	There were failed web, SSH, or Telnet login access attempts from the specified source IP and MAC address. <ul style="list-style-type: none"> [by <user> <username>] does not appear if telnet or SSH clients are specified. <n> is the number of times this SNMP trap occurred in the last five minutes, or other configured number of minutes.
Informational	Trunk group (<ports>) created by 802.3ad link-aggregation module.	802.3ad link aggregation is configured on the device, and the feature has dynamically created a trunk group (aggregate link). The <ports> is a list of the ports that were aggregated to make the trunk group.
Informational	user <username> added deleted modified from console telnet ssh web snmp	A user created, modified, or deleted a local user account through the Web, SNMP, console, SSH, or Telnet session.
Informational	vlan <vlan id> added deleted modified from console telnet ssh web snmp session	A user created, modified, or deleted a VLAN through the Web, SNMP, console, SSH, or Telnet session.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Informational	Warm start	The system software (flash code) has been reloaded.
Informational	vlan <vlan-id> Bridge is RootBridge <mac-address> (MgmtPriChg)	802.1W changed the current bridge to be the root bridge of the given topology due to administrative change in bridge priority.
Informational	vlan <vlan-id> Bridge is RootBridge <mac-address> (MsgAgeExpiry)	The message age expired on the Root port so 802.1W changed the current bridge to be the root bridge of the topology.
Informational	vlan <vlan-id> interface <portnum> Bridge TC Event (DOT1wTransition)	802.1W recognized a topology change event in the bridge. The topology change event is the forwarding action that started on a non-edge Designated port or Root port.
Informational	vlan <vlan-id> interface <portnum> STP state -> <state> (DOT1wTransition)	802.1W changed the state of a port to a new state: forwarding, learning, blocking. If the port changes to blocking, the bridge port is in discarding state.
Informational	vlan <vlan-id> New RootBridge <mac-address> RootPort <portnum> (BpduRcvd)	802.1W selected a new root bridge as a result of the BPDUs received on a bridge port.
Informational	vlan <vlan-id> New RootPort <portnum> (RootSelection)	802.1W changed the port role to Root port, using the root selection computation.
Notification	ACL exceed max DMA L4 cam resource, using flow based ACL instead	<p>The port does not have enough Layer 4 CAM entries for the ACL.</p> <p>To correct this condition, allocate more Layer 4 CAM entries. To allocate more Layer 4 CAM entries, enter the following command at the CLI configuration level for the interface:</p> <p>ip access-group max-l4-cam <num></p>
Notification	ACL insufficient L4 cam resource, using flow based ACL instead	The port does not have a large enough CAM partition for the ACLs
Notification	ACL insufficient L4 session resource, using flow based ACL instead	<p>The device does not have enough Layer 4 session entries.</p> <p>To correct this condition, allocate more memory for sessions. To allocate more memory, enter the following command at the global CONFIG level of the CLI interface:</p> <p>system-max session-limit <num></p>
Notification	ACL port fragment packet inspect rate <rate> exceeded on port <portnum>	<p>The fragment rate allowed on an individual interface has been exceeded.</p> <p>The <rate> indicates the maximum rate allowed.</p> <p>The <portnum> indicates the port.</p> <p>This message can occur if fragment throttling is enabled.</p>

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	ACL system fragment packet inspect rate <rate> exceeded	The fragment rate allowed on the device has been exceeded. The <rate> indicates the maximum rate allowed. This message can occur if fragment throttling is enabled.
Notification	Authentication Disabled on <portnum>	The multi-device port authentication feature was disabled on the on the specified <portnum>.
Notification	Authentication Enabled on <portnum>	The multi-device port authentication feature was enabled on the on the specified <portnum>.
Notification	BGP Peer <ip-addr> DOWN (IDLE)	Indicates that a BGP4 neighbor has gone down. The <ip-addr> is the IP address of the neighbor BGP4 interface with the Brocade device.
Notification	BGP Peer <ip-addr> UP (ESTABLISHED)	Indicates that a BGP4 neighbor has come up. The <ip-addr> is the IP address of the neighbor BGP4 interface with the Brocade device.
Notification	DHCP : snooping on untrusted port <portnum>, type <number>, drop	Indicates that the DHCP client receives DHCP server reply packets on untrusted ports, and packets are dropped.
Notification	DOT1X issues software but not physical port down indication of Port <portnum> to other software applications	The device has indicated that the specified is no longer authorized, but the actual port may still be active.
Notification	DOT1X issues software but not physical port up indication of Port <portnum> to other software applications	The device has indicated that the specified port has been authenticated, but the actual port may not be active.
Notification	DOT1X: Port <port_id> Mac <mac_address> -user <user_id> - RADIUS timeout for authentication	The RADIUS session has timed out for this 802.1x port.
Notification	Local ICMP exceeds <burst-max> burst packets, stopping for <lockup> seconds!!	The number of ICMP packets exceeds the <burst-max> threshold set by the ip icmp burst command. The Product Name device may be the victim of a Denial of Service (DoS) attack. All ICMP packets will be dropped for the number of seconds specified by the <lockup> value. When the lockup period expires, the packet counter is reset and measurement is restarted.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	Local TCP exceeds <burst-max> burst packets, stopping for <lockup> seconds!!	The number of TCP SYN packets exceeds the <burst-max> threshold set by the ip tcp burst command. The Product Name device may be the victim of a TCP SYN DoS attack. All TCP SYN packets will be dropped for the number of seconds specified by the <lockup> value. When the lockup period expires, the packet counter is reset and measurement is restarted.
Notification	Local TCP exceeds <num> burst packets, stopping for <num> seconds!!	Threshold parameters for local TCP traffic on the device have been configured, and the maximum burst size for TCP packets has been exceeded. The first <num> is the maximum burst size (maximum number of packets allowed). The second <num> is the number of seconds during which additional TCP packets will be blocked on the device. NOTE: This message can occur in response to an attempted TCP SYN attack.
Notification	MAC Authentication RADIUS timeout for <mac_address> on port <port_id>	The RADIUS session has timed out for the MAC address for this port.
Notification	MAC Authentication succeeded for <mac-address> on <portnum>	RADIUS authentication was successful for the specified <mac-address> on the specified <portnum>.
Notification	Module was inserted to slot <slot-num>	Indicates that a module was inserted into a chassis slot. The <slot-num> is the number of the chassis slot into which the module was inserted.
Notification	Module was removed from slot <slot-num>	Indicates that a module was removed from a chassis slot. The <slot-num> is the number of the chassis slot from which the module was removed.
Notification	OSPF interface state changed, rid <router-id>, intf addr <ip-addr>, state <ospf-state>	Indicates that the state of an OSPF interface has changed. The <router-id> is the router ID of the Brocade device. The <ip-addr> is the interface IP address. The <ospf-state> indicates the state to which the interface has changed and can be one of the following: <ul style="list-style-type: none"> • down • loopback • waiting • point-to-point • designated router • backup designated router • other designated router • unknown

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF intf authen failure, rid <router-id>, intf addr <ip-addr>, pkt src addr <src-ip-addr>, error type <error-type>, pkt type <pkt-type>	<p>Indicates that an OSPF interface authentication failure has occurred. The <router-id> is the router ID of the Product Name device. The <ip-addr> is the IP address of the interface on the Product Name device. The <src-ip-addr> is the IP address of the interface from which the Product Name device received the authentication failure. The <error-type> can be one of the following:</p> <ul style="list-style-type: none"> • bad version • area mismatch • unknown NBMA neighbor • unknown virtual neighbor • authentication type mismatch • authentication failure • network mask mismatch • hello interval mismatch • dead interval mismatch • option mismatch • unknown <p>The <packet-type> can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state ack • unknown

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF intf config error, rid <router-id>, intf addr <ip-addr>, pkt src addr <src-ip-addr>, error type <error-type>, pkt type <pkt-type>	<p>Indicates that an OSPF interface configuration error has occurred.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the interface on the Product Name device.</p> <p>The <src-ip-addr> is the IP address of the interface from which the Product Name device received the error packet.</p> <p>The <error-type> can be one of the following:</p> <ul style="list-style-type: none"> • bad version • area mismatch • unknown NBMA neighbor • unknown virtual neighbor • authentication type mismatch • authentication failure • network mask mismatch • hello interval mismatch • dead interval mismatch • option mismatch • unknown <p>The <packet-type> can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state ack • unknown
Notification	OSPF intf rcvd bad pkt, rid <router-id>, intf addr <ip-addr>, pkt src addr <src-ip-addr>, pkt type <pkt-type>	<p>Indicates that an OSPF interface received a bad packet.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the interface on the Product Name device.</p> <p>The <src-ip-addr> is the IP address of the interface from which the Product Name device received the authentication failure.</p> <p>The <packet-type> can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state ack • unknown

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF intf rcvd bad pkt: Bad Checksum, rid <ip-addr>, intf addr <ip-addr>, pkt size <num>, checksum <num>, pkt src addr <ip-addr>, pkt type <type>	<p>The device received an OSPF packet that had an invalid checksum.</p> <p>The rid <ip-addr> is the Brocade router ID.</p> <p>The intf addr <ip-addr> is the IP address of the Brocade interface that received the packet.</p> <p>The pkt size <num> is the number of bytes in the packet.</p> <p>The checksum <num> is the checksum value for the packet.</p> <p>The pkt src addr <ip-addr> is the IP address of the neighbor that sent the packet.</p> <p>The pkt type <type> is the OSPF packet type and can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state acknowledgement • unknown (indicates an invalid packet type)
Notification	OSPF intf rcvd bad pkt: Bad Packet type, rid <ip-addr>, intf addr <ip-addr>, pkt size <num>, checksum <num>, pkt src addr <ip-addr>, pkt type <type>	<p>The device received an OSPF packet with an invalid type.</p> <p>The parameters are the same as for the Bad Checksum message. The pkt type <type> value is "unknown", indicating that the packet type is invalid.</p>
Notification	OSPF intf rcvd bad pkt: Invalid packet size, rid <ip-addr>, intf addr <ip-addr>, pkt size <num>, checksum <num>, pkt src addr <ip-addr>, pkt type <type>	<p>The device received an OSPF packet with an invalid packet size.</p> <p>The parameters are the same as for the Bad Checksum message.</p>
Notification	OSPF intf rcvd bad pkt: Unable to find associated neighbor, rid <ip-addr>, intf addr <ip-addr>, pkt size <num>, checksum <num>, pkt src addr <ip-addr>, pkt type <type>	<p>The neighbor IP address in the packet is not in the list of OSPF neighbors in the Brocade device.</p> <p>The parameters are the same as for the Bad Checksum message.</p>

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF intf retransmit, rid <router-id>, intf addr <ip-addr>, nbr rid <nbr-router-id>, pkt type is <pkt-type>, LSA type <lsa-type>, LSA id <lsa-id>, LSA rid <lsa-router-id>	<p>An OSPF interface on the Product Name device has retransmitted a Link State Advertisement (LSA).</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the interface on the Product Name device.</p> <p>The <nbr-router-id> is the router ID of the neighbor router.</p> <p>The <packet-type> can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state ack • unknown <p>The <lsa-type> is the type of LSA.</p> <p>The <lsa-id> is the LSA ID.</p> <p>The <lsa-router-id> is the LSA router ID.</p>
Notification	OSPF LSDB approaching overflow, rid <router-id>, limit <num>	<p>The software is close to an LSDB condition.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <num> is the number of LSAs.</p>
Notification	OSPF LSDB overflow, rid <router-id>, limit <num>	<p>A Link State Database Overflow (LSDB) condition has occurred.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <num> is the number of LSAs.</p>
Notification	OSPF max age LSA, rid <router-id>, area <area-id>, LSA type <lsa-type>, LSA id <lsa-id>, LSA rid <lsa-router-id>	<p>An LSA has reached its maximum age.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <area-id> is the OSPF area.</p> <p>The <lsa-type> is the type of LSA.</p> <p>The <lsa-id> is the LSA ID.</p> <p>The <lsa-router-id> is the LSA router ID.</p>

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF nbr state changed, rid <router-id>, nbr addr <ip-addr>, nbr rid <nbr-router-id>, state <ospf-state>	<p>Indicates that the state of an OSPF neighbor has changed.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the neighbor.</p> <p>The <nbr-router-id> is the router ID of the neighbor.</p> <p>The <ospf-state> indicates the state to which the interface has changed and can be one of the following:</p> <ul style="list-style-type: none"> • down • attempt • initializing • 2-way • exchange start • exchange • loading • full • unknown
Notification	OSPF originate LSA, rid <router-id>, area <area-id>, LSA type <lsa-type>, LSA id <lsa-id>, LSA router id <lsa-router-id>	<p>An OSPF interface has originated an LSA.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <area-id> is the OSPF area.</p> <p>The <lsa-type> is the type of LSA.</p> <p>The <lsa-id> is the LSA ID.</p> <p>The <lsa-router-id> is the LSA router ID.</p>

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF virtual intf authen failure, rid <router-id>, intf addr <ip-addr>, pkt src addr <src-ip-addr>, error type <error-type>, pkt type <pkt-type>	<p>Indicates that an OSPF virtual routing interface authentication failure has occurred.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the interface on the Product Name device.</p> <p>The <src-ip-addr> is the IP address of the interface from which the Product Name device received the authentication failure.</p> <p>The <error-type> can be one of the following:</p> <ul style="list-style-type: none"> • bad version • area mismatch • unknown NBMA neighbor • unknown virtual neighbor • authentication type mismatch • authentication failure • network mask mismatch • hello interval mismatch • dead interval mismatch • option mismatch • unknown <p>The <packet-type> can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state ack • unknown

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF virtual intf config error, rid <router-id>, intf addr <ip-addr>, pkt src addr <src-ip-addr>, error type <error-type>, pkt type <pkt-type>	<p>Indicates that an OSPF virtual routing interface configuration error has occurred. The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the interface on the Product Name device.</p> <p>The <src-ip-addr> is the IP address of the interface from which the Product Name device received the error packet.</p> <p>The <error-type> can be one of the following:</p> <ul style="list-style-type: none"> • bad version • area mismatch • unknown NBMA neighbor • unknown virtual neighbor • authentication type mismatch • authentication failure • network mask mismatch • hello interval mismatch • dead interval mismatch • option mismatch • unknown <p>The <packet-type> can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state ack • unknown
Notification	OSPF virtual intf rcvd bad pkt, rid <router-id>, intf addr <ip-addr>, pkt src addr <src-ip-addr>, pkt type <pkt-type>	<p>Indicates that an OSPF interface received a bad packet.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the interface on the Product Name device.</p> <p>The <src-ip-addr> is the IP address of the interface from which the Product Name device received the authentication failure.</p> <p>The <packet-type> can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state ack • unknown

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF virtual intf retransmit, rid <router-id>, intf addr <ip-addr>, nbr rid <nbr-router-id>, pkt type is <pkt-type>, LSA type <lsa-type>, LSA id <lsa-id>, LSA rid <lsa-router-id>	<p>An OSPF interface on the Product Name device has retransmitted a Link State Advertisement (LSA).</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the interface on the Product Name device.</p> <p>The <nbr-router-id> is the router ID of the neighbor router.</p> <p>The <packet-type> can be one of the following:</p> <ul style="list-style-type: none"> • hello • database description • link state request • link state update • link state ack • unknown <p>The <lsa-type> is the type of LSA.</p> <p>The <lsa-id> is the LSA ID.</p> <p>The <lsa-router-id> is the LSA router ID.</p>
Notification	OSPF virtual intf state changed, rid <router-id>, area <area-id>, nbr <ip-addr>, state <ospf-state>	<p>Indicates that the state of an OSPF virtual routing interface has changed.</p> <p>The <router-id> is the router ID of the router the interface is on.</p> <p>The <area-id> is the area the interface is in.</p> <p>The <ip-addr> is the IP address of the OSPF neighbor.</p> <p>The <ospf-state> indicates the state to which the interface has changed and can be one of the following:</p> <ul style="list-style-type: none"> • down • loopback • waiting • point-to-point • designated router • backup designated router • other designated router • unknown

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	OSPF virtual nbr state changed, rid <router-id>, nbr addr <ip-addr>, nbr rid <nbr-router-id>, state <ospf-state>	<p>Indicates that the state of an OSPF virtual neighbor has changed.</p> <p>The <router-id> is the router ID of the Product Name device.</p> <p>The <ip-addr> is the IP address of the neighbor.</p> <p>The <nbr-router-id> is the router ID of the neighbor.</p> <p>The <ospf-state> indicates the state to which the interface has changed and can be one of the following:</p> <ul style="list-style-type: none"> • down • attempt • initializing • 2-way • exchange start • exchange • loading • full • unknown
Notification	Transit ICMP in interface <portnum> exceeds <num> burst packets, stopping for <num> seconds!!	<p>Threshold parameters for ICMP transit (through) traffic have been configured on an interface, and the maximum burst size for ICMP packets on the interface has been exceeded.</p> <p>The <portnum> is the port number.</p> <p>The first <num> is the maximum burst size (maximum number of packets allowed).</p> <p>The second <num> is the number of seconds during which additional ICMP packets will be blocked on the interface.</p> <p>NOTE: This message can occur in response to an attempted Smurf attack.</p>
Notification	Transit TCP in interface <portnum> exceeds <num> burst packets, stopping for <num> seconds!	<p>Threshold parameters for TCP transit (through) traffic have been configured on an interface, and the maximum burst size for TCP packets on the interface has been exceeded.</p> <p>The <portnum> is the port number.</p> <p>The first <num> is the maximum burst size (maximum number of packets allowed).</p> <p>The second <num> is the number of seconds during which additional TCP packets will be blocked on the interface.</p> <p>NOTE: This message can occur in response to an attempted TCP SYN attack.</p>

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Notification	VRRP intf state changed, intf <portnum>, vrid <virtual-router-id>, state <vrrp-state> VRRP (IPv6) intf state changed, intf <portnum>, vrid <virtual-router-id>, state <vrrp-state>	A state change has occurred in a Virtual Router Redundancy Protocol (VRRP) or VRRP-E IPv4 or IPv6 interface. The <portnum> is the port or interface where VRRP or VRRP-E is configured. The <virtual-router-id> is the virtual router ID (VRID) configured on the interface. The <vrrp-state> can be one of the following: <ul style="list-style-type: none"> • init • master • backup • unknown
Warning	DOT1X security violation at port <portnum>, malicious mac address detected: <mac-address>	A security violation was encountered at the specified port number.
Warning	Dup IP <ip-addr> detected, sent from MAC <mac-addr> interface <portnum>	Indicates that the Product Name device received a packet from another device on the network with an IP address that is also configured on the Brocade device. The <ip-addr> is the duplicate IP address. The <mac-addr> is the MAC address of the device with the duplicate IP address. The <portnum> is the Brocade port that received the packet with the duplicate IP address. The address is the packet source IP address.
Warning	IGMP/MLD no hardware vidx, broadcast to the entire vlan. rated limited number	IGMP or MLD snooping has run out of hardware application VLANs. There are 4096 application VLANs per device. Traffic streams for snooping entries without an application VLAN are switched to the entire VLAN and to the CPU to be dropped. This message is rate-limited to appear a maximum of once every 10 minutes. The rate-limited number shows the number on non-printed warnings.
Warning	IGMP/MLD: <vlanId>(<portId>) is V1 but rcvd V2 from nbr <ipAddr>	Port has received a query with a MLD version that does not match the port MLD version. This message is rated-limited to appear a maximum of once every 10 hours.
Warning	Latched low RX Power TX Power TX Bias Current Supply Voltage Temperature warning alarm warning, port <port-number>	The optical transceiver on the given port has risen above or fallen below the alarm or warning threshold.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Warning	list <ACL-num> denied <ip-proto> <src-ip-addr> (<src-tcp/udp-port>) (Ethernet <portnum> <mac-addr>) -> <dst-ip-addr> (<dst-tcp/udp-port>), 1 event(s)	Indicates that an Access Control List (ACL) denied (dropped) packets. The <ACL-num> indicates the ACL number. Numbers 1 – 99 indicate standard ACLs. Numbers 100 – 199 indicate extended ACLs. The <ip-proto> indicates the IP protocol of the denied packets. The <src-ip-addr> is the source IP address of the denied packets. The <src-tcp/udp-port> is the source TCP or UDP port, if applicable, of the denied packets. The <portnum> indicates the port number on which the packet was denied. The <mac-addr> indicates the source MAC address of the denied packets. The <dst-ip-addr> indicates the destination IP address of the denied packets. The <dst-tcp/udp-port> indicates the destination TCP or UDP port number, if applicable, of the denied packets.
Warning	Locked address violation at interface e<portnum>, address <mac-address>	Indicates that a port on which you have configured a lock-address filter received a packet that was dropped because the packet source MAC address did not match an address learned by the port before the lock took effect. The e<portnum> is the port number. The <mac-address> is the MAC address that was denied by the address lock. Assuming that you configured the port to learn only the addresses that have valid access to the port, this message indicates a security violation.
Warning	mac filter group denied packets on port <portnum> src macaddr <mac-addr>, <num> packets	Indicates that a MAC address filtergroup configured on a port has denied packets. The <portnum> is the port on which the packets were denied. The <mac-addr> is the source MAC address of the denied packets. The <num> indicates how many packets matching the values above were dropped during the five-minute interval represented by the log entry.
Warning	multicast no software resource: resource-name, rate limited number	IGMP or MLD snooping has run out of software resources. This message is rate-limited to appear a maximum of once every 10 minutes. The rate-limited number shows the number of non-printed warnings.

TABLE 57 Brocade Syslog messages (Continued)

Message level	Message	Explanation
Warning	No global IP! cannot send IGMP msg.	The device is configured for ip multicast active but there is no configured IP address and the device cannot send out IGMP queries.
Warning	No of prefixes received from BGP peer <ip-addr> exceeds warning limit <num>	<p>The Layer 3 Switch has received more than the allowed percentage of prefixes from the neighbor.</p> <p>The <ip-addr> is the IP address of the neighbor.</p> <p>The <num> is the number of prefixes that matches the percentage you specified. For example, if you specified a threshold of 100 prefixes and 75 percent as the warning threshold, this message is generated if the Layer 3 Switch receives a 76th prefix from the neighbor.</p>
Warning	NTP server <ip-addr> failed to respond	<p>Indicates that a Simple Network Time Protocol (SNTP) server did not respond to the device query for the current time.</p> <p>The <ip-addr> indicates the IP address of the SNTP server.</p>
Warning	rip filter list <list-num> <direction> V1 V2 denied <ip-addr>, <num> packets	<p>Indicates that a RIP route filter denied (dropped) packets.</p> <p>The <list-num> is the ID of the filter list.</p> <p>The <direction> indicates whether the filter was applied to incoming packets or outgoing packets. The value can be one of the following:</p> <ul style="list-style-type: none"> • in • out <p>The V1 or V2 value specifies the RIP version (RIPv1 or RIPv2).</p> <p>The <ip-addr> indicates the network number in the denied updates.</p> <p>The <num> indicates how many packets matching the values above were dropped during the five-minute interval represented by the log entry.</p>
Warning	Temperature is over warning level.	The chassis temperature has risen above the warning level.

A Syslog messages

NIAP-CCEVS Certification

Some Brocade devices have passed the Common Criteria (CC) certification testing. This testing is sponsored by the National Information Assurance Partnership (NIAP) - Common Criteria Evaluation and Validation Scheme (CCEVS). For more information regarding the NIAP-CCEVS certification process refer to the following link: <http://www.niap-ccevs.org/>.

In an effort to maintain a proper level of security as it relates to access to network infrastructure resources, Brocade recommends that all Brocade hardware be installed within a secure location that is accessible by approved personnel only.

NIAP-CCEVS certified Brocade equipment and Ironware releases

The Business Continuity Manager is NIAP-CCEVS certified. The following IronWare software release must be used to remain compliant with this certification:

TABLE 58 NIAP-CCEVS certified Brocade equipment and IronWare software releases

Brocade product	Brocade IronWare software version	Discussed in
Brocade ICX 6650 Family	7.5.00	<i>Brocade ICX 6650 Administration Guide</i>

Local user password changes

Please note that if existing usernames and passwords have been configured on a Brocade Device with specific privilege levels (super-user, read-only, port-config), and if you attempt to change a user's password by executing the following syntax:

```
Brocade-Device(config)# user brcdreadonly password value
```

The privilege level of this particular user will be changed from its current value to "super-user". The "super-user" level username and password combination provides full access to the Brocade command line interface (CLI). To prevent this from occurring, use the following syntax:

```
Brocade-Device(config)# user fdryreadonly privilege value password value
```

B Local user password changes

Index

A

- alarm interval, setting, 226
- alarm status values, 229

B

- banner configuration, 28
- banner, setting a privileged EXEC CLI level, 30
- boot preference, displaying, 56
- broadcast, multicast, and unknown traffic
 - limiting, 28

C

- CDP
 - clearing information, 176, 180
 - clearing statistics, 177
 - displaying entries, 179
 - displaying information, 178
 - displaying neighbors, 178
 - displaying packet statistics, 176
 - displaying statistics, 180
 - enabling interception of packets globally, 177
 - enabling interception of packets on an interface, 177
- Cisco Discovery Protocol (CDP) overview, 177

command

- alias, 10
- banner exec_mode, 30
- banner incoming, 30
- banner motd, 28
- clear, 248
- clear fdp counters, 177, 180
- clear fdp table, 176, 180
- clear ipv6 cache, 139
- clear ipv6 neighbor, 139
- clear ipv6 route, 140
- clear ipv6 traffic, 140
- clear ipv6 tunnel, 122
- clear lldp neighbors, 224
- clear LLDP statistics, 220
- clear lldp statistics, 223
- clear logging, 236, 242
- clear statistics, 250, 269
- clock set, 26
- clock summer-time, 27
- clock timezone gmt, 27
- clock timezone us, 28
- copy flash console, 53, 54
- copy flash tftp, 62
- copy running-config, 63
- copy running-config tftp, 59
- copy startup-config tftp, 59
- copy tftp flash, 63
- copy tftp running-config, 61
- copy tftp startup-config, 59
- disable, 35
- enable, 35
- enable snmp ve-statistics, 18
- end, 59, 61
- erase flash primary, 67
- erase flash secondary, 67
- erase startup-config, 67
- errdisable recovery interval, 45
- fdp advertise ipv4 | ipv6, 172
- fdp holdtime, 173
- fdp timer, 173
- flow-control, 36
- hostname, 15
- interface tunnel, 122
- ip address, 111
- ip show-portname, 241
- ip show-service-number-in-log, 241
- ipv6 access-list, 112
- ipv6 address, 107, 109, 112, 122
- ipv6 dns domain-name, 115
- ipv6 dns server-address, 115
- ipv6 enable, 107, 110, 122
- ipv6 hop-limit, 138
- ipv6 icmp error-interval, 128
- ipv6 icmp source-route, 138
- ipv6 nd dad attempt, 132
- ipv6 nd managed-config-flag, 135
- ipv6 nd ns-interval, 132
- ipv6 nd other-config-flag, 135
- ipv6 nd prefix-advertisement, 134
- ipv6 nd ra-hop-limit, 133
- ipv6 nd ra-interval, 133
- ipv6 nd ra-lifetime, 133
- ipv6 nd reachable-time, 136
- ipv6 nd suppress-ra, 135
- ipv6 neighbor, 137
- ipv6 unicast-routing, 111, 131
- lldp advertise mac-phy-config-status ports, 205
- lldp advertise management-address ipv4, 200
- lldp advertise max-frame-size ports, 206
- lldp advertise max-frame-size ports ethernet, 206
- lldp advertise port-description ports ethernet, 201
- lldp advertise port-vlan-id ports ethernet, 204
- lldp advertise system-capabilities ports ethernet, 202
- lldp advertise system-description ports ethernet, 202
- lldp advertise vlan-name vlan, 204
- lldp enable ports, 193
- lldp enable ports ethernet, 194
- lldp enable receive ports, 195
- lldp enable snmp notifications ports

- ethernet, 196
- lldp enable transmit ports, 194
- lldp enable transmit ports ethernet, 195
- lldp max-neighbors-per-port, 196
- lldp max-total-neighbors, 195
- lldp med location-id civic-address, 211
- lldp med location-id coordinate-based, 209
- lldp med location-id ecs-elin, 214
- lldp med network-policy application, 216
- lldp snmp-notification-interval, 197
- lldp transmit-delay, 197
- lldp transmit-hold, 198
- lldp transmit-interval, 197, 198
- logging buffered, 239
- logging console, 233
- logging enable config-changed, 58
- logging enable user-login, 20
- logging facility, 240
- logging host, 239
- logging on, 238
- logging persistence, 242
- loop-detection, 44
- loop-detection-interval, 44
- ncopy, 64
- ncopy running-config tftp, 62
- optical-monitor, 225, 226
- ping, 70, 116
- port-name, 31
- relative-utilization, 270
- reload after, 68
- reload at, 67
- reload cancel, 68
- rmon alarm, 253
- rmon history, 253
- sflow agent-ip, 265
- sflow enable, 263, 264
- sflow export cpu-traffic, 267
- sflow export system-info, 266
- sflow forwarding, 264
- sflow forwarding, 264
- sflow max-packet-size, 266
- sflow polling-interval, 259
- sflow sample, 261, 262
- sflow source-port, 263
- sflow version 2 | 5, 266
- show clock, 28
- show interfaces management, 2
- show logging, 19
- show media, 226
- show running-config interface
 - management, 2
 - show snmp associations, 21
 - show snmp server-mode, 25
 - show snmp status, 23
 - show statistics management, 3
 - show who, 6
 - snmp-client ipv6, 113
 - snmp-server community, 55, 66, 157
 - snmp-server contact, 15
 - snmp-server enable traps holdddown-time, 17
 - snmp-server engineid local, 160
 - snmp-server group, 160, 164
 - snmp-server host, 16
 - snmp-server host ipv6, 113
 - snmp-server location, 15
 - snmp-server pw-check, 55, 66
 - snmp-server user, 161
 - snmp-server view, 163
 - snmp broadcast client, 26
 - snmp broadcast server, 26
 - snmp poll-interval, 21
 - snmp server, 20
 - snmp server ipv6, 113
 - snmp server-mode, 24
 - snmp sync, 27
 - speed-duplex, 32, 34
 - symmetric-flow-control, 39
 - system-max rmon-entries, 250
 - system-max view, 163
 - telnet, 114
 - terminal monitor, 233
 - traceroute, 71, 114
 - traceroute ipv6, 114
 - tunnel destination, 122
 - tunnel mode ipv6ip, 122
 - tunnel source, 122
 - use-local-management-mac, 31
 - write memory, 16
- command line interface
 - banner configuration, 28
 - creating an alias for a command, 10
 - logging in, 3
 - nomenclature on Chassis-based models, 6
 - security levels, 3

- command output
 - egress queue statistics, 250
 - IPv6 tunnel interface information, 124
 - sFlow information, 268
 - show fdp neighbor, 174
 - show ipv6 cache, 141
 - show ipv6 interface, 142
 - show ipv6 neighbor, 144
 - show ipv6 route command, 146
 - show ipv6 router, 147
 - show ipv6 tcp connections, 148
 - show ipv6 tcp status, 150
 - show ipv6 traffic, 151
 - show link-error-disable, 42
 - show lldp neighbors, 221
 - show lldp statistics, 219, 220
 - show loop-detection resource, 46
 - show optic, 229
 - show sflow, 268
 - show snmp associations, 21
 - show snmp associations details, 22
 - show snmp server-mode, 25
 - show snmp status, 23
- commands
 - line editing, 5
 - searching and filtering output, 6
- configuration
 - basic port parameter, 31
 - basis system parameters, 14
 - dynamic loading, 59
 - entering system information, 15
 - flow control, 35
 - Interpacket Gap (IPG), 39
 - IPv4 and IPv6 protocol stack, 111
 - IPv6 connectivity on a Layer 3 switch, 108
 - IPv6 management ACLs, 112
 - IPv6 management port, 108
 - IPv6 neighbor discovery, 129
 - IPv6 static neighbor entries, 137
 - IPv6 Syslog server, 117
 - loading and saving files, 57
 - manual IPv6 tunnel, 121
 - port flap dampening, 40
 - SNMP parameters, 15
 - SNMP V3 and SNMP over IPv6, 113
 - static IPv6 route, 118
 - viewing information, 244
- configuration file
 - copying to or from TFTP server, 59
 - running, 57
 - startup, 57

- configuration files
 - loading and saving with IPv6, 62

D

- diagnostic error codes, 68
- digital optical monitoring, 225
- disabling Syslog messages and traps, 19
- dynamic configuration loading, 59

E

- egress queue counters
 - viewing on FCX devices, 249
- egress queue counters, clearing, 250
- EMCP load sharing for IPv6, 126
- error codes used for diagnostics, 68

F

- FCX devices
 - viewing egress queue counters, 249
- FDP
 - changing the hold time, 173
 - changing the update timer, 172
 - clearing information, 176
 - clearing statistics, 177
 - configuration, 172
 - displaying entries, 175
 - displaying information, 173
 - displaying packet statistics, 176
 - enabling at the interface level, 172
 - enabling globally, 172
 - specifying the IP management address, 172
- feature support
 - basic software, 13
 - Foundry Discovery Protocol (FDP) and Cisco Discovery Protocol (CDP) packets, 171
 - hardware component monitoring, 225
 - IPv6 configuration on FastIron X series, FCX series, and ICX series switches, 99
 - Link Layer Discovery Protocol (LLDP), 181
 - management applications, 1
 - network monitoring, 243
 - Operations, Administration, and

- Maintenance (OAM), 49
- SNMP access, 155
- software-based licensing, 73
- Syslog, 231
- flash image
 - CLI commands, 52
 - determining version running on device, 50
 - file types, 53
 - verification, 51, 52
- flash memory
 - copying a file to, 63
- flow control
 - configuration, 35
 - configuration notes, 35, 38
 - disabling or re-enabling, 35
 - displaying status, 37
 - enabling and disabling, 39
 - negotiation and advertisement, 36
 - symmetric and asymmetric, 37
- Foundry Discovery Protocol (FDP) overview, 171

I

- ICMP
 - configuring rate limiting, 128
 - enabling redirect messages, 129
- ICMP feature configuration for IPv6, 128

- Interface
 - enable, 35
 - flow-control, 36
 - gig-default, 40
 - ip address, 111
 - ipv6 address, 109, 110, 111, 112
 - ipv6 address eui, 110
 - ipv6 address link-local, 110
 - ipv6 enable, 110
 - ipv6 mtu, 137
 - ipv6 nd dad attempt, 132
 - ipv6 nd managed-config-flag, 135
 - ipv6 nd ns-interval, 132
 - ipv6 nd other-config-flag, 135
 - ipv6 nd prefix-advertisement, 134
 - ipv6 nd ra-interval, 133
 - ipv6 nd ra-lifetime, 133
 - ipv6 nd reachable-time, 136
 - ipv6 nd suppress-ra, 135
 - ipv6 redirects, 129
 - link-error-disable, 41
 - optical-monitor, 225
 - port-name, 31
 - speed-duplex, 32, 34
- Interpacket Gap (IPG) configuration, 39
- IPv4 and IPv6
 - protocol stack configuration, 111
- IPv4 route, tracing, 71
- IPv6
 - address types, 102
 - addressing overview, 101
 - changing the MTU, 137
 - clearing global information, 138
 - clearing neighbor information, 139
 - clearing routes from IPv6 route table, 140
 - clearing the cache, 139
 - clearing traffic statistics, 140
 - clearing tunnel statistics, 122
 - configuring a global or site-local address, 107
 - configuring a link-local address as a system-wide address for a switch, 107
 - configuring a manual tunnel, 121
 - configuring a Syslog server, 117
 - configuring address resolution using DNS resolver, 115
 - configuring anycast address, 111
 - configuring basic connectivity on a Layer 3

- switch, 108
- configuring ICMP rate limiting, 128
- configuring IPv6 management ACLs, 112
- configuring on each router interface, 108
- configuring reachable time for remote nodes, 136
- configuring SNMP V3, 113
- configuring SNTTP, 113
- configuring the management port, 108
- defining a DNS entry, 115
- disabling on a Layer 2 switch, 118
- disabling router advertisement and solicitation messages, 118
- disabling router advertisement and solicitation messages, 118
- displaying cache information, 140
- displaying ECMP load-sharing information, 127
- displaying global information, 140
- displaying interface information, 141
- displaying interface-level settings, 124
- displaying local routers, 146
- displaying neighbor information, 144
- displaying route table, 145
- displaying TCP information, 147
- displaying traffic statistics, 151
- displaying tunnel information, 123
- ECMP load sharing, 126
- enabling and disabling router advertisements, 135
- enabling ICMP redirect messages, 129
- enabling routing, 108
- full layer supported features, 101
- host address on a Layer 2 switch, 106
- ICMP feature configuration, 128
- limiting the number of hops a packet can traverse, 138
- management on FastIron X series devices, 112
- maximum transmission unit (MTU), 136
- neighbor discovery configuration, 129
- neighbor redirect messages, 131
- neighbor solicitation and advertisement messages, 130
- pinging and address, 116
- prefixes advertised in router messages, 134
- router advertisement and solicitation messages, 131
- secure shell and SCP, 113
- setting flags in router advertisement messages, 135
- setting neighbor solicitation parameters,

- 131
- setting router advertisement parameters, 132
- source routing security enhancements, 138
- specifying an SNMP trap receiver, 113
- stateless auto-configuration, 104
- static neighbor entries configuration, 137
- static route configuration, 118
- static route parameters, 120
- supported CLI commands, 104
- telnet, 114
- traceroute, 114
- viewing SNMP server address, 117
- IPv6 host support, 112
- IPv6 over IPv4 tunnels, 121
- IPv6 TFTP server file upload, 65

L

- Layer 2 switch
 - IPv6 host address, 106
- license file
 - deleting, 90
- Licensing
 - Ports on Demand, 82
 - show license, 91
- Licensing for Ports on Demand, 92
- Link layer discovery protocol (LLDP), description of, 182
- LLDP
 - 802.1 capabilities when enabled, 203
 - 802.3 capabilities when enabled on a global basis, 204
 - basic management TLV, 188
 - benefits, 184
 - changing a port operating mode, 193
 - changing the holdtime multiplier, 198
 - changing the interval between regular transmissions, 198
 - changing the minimum time between port reinitializations, 199
 - changing the minimum time between transmissions, 197
 - clearing cached LLDP neighbor information, 224
 - configuration summary, 218
 - displaying neighbors detail, 222
 - enabling and disabling, 193
 - enabling SNMP notifications and Syslog

- messages, 196
- enabling support for tagged packets, 193
- general operating principles, 186
- general system information, 199
- global configuration tasks, 192
- MIB support, 191
- organizationally-specific TLVs, 188
- overview, 183
- packets, 187
- receive mode, 187
- resetting statistics, 223
- specifying the maximum number of LLDP neighbors per port, 196
- specifying the maximum number of neighbors per device, 195
- specifying the minimum time between SNMP traps and Syslog messages, 197
- Syslog messages, 191
- terms used in chapter, 182
- TLVs advertised by Brocade device, 199
- transmit mode, 186
- LLDP media endpoint devices (LLDP-MED),
 - description of, 182
- LLDP_MED
 - benefits, 185
 - general operating principles, 186
 - overview, 184
- LLDP-MED
 - attributes advertised by the Brocade device, 217
 - capabilities, 217
 - class, 186
 - configuration tasks, 206
 - configuring civic address location, 211
 - configuring emergency call service, 214
 - coordinate-based location, 209
 - defining a location ID, 209
 - defining a network policy, 215
 - displaying statistics and configuration settings, 218
 - elements used with civic address, 212
 - enabling, 207
 - enabling SNMP notifications and Syslog messages, 207
 - example civic address location advertisement, 214
 - fast start repeat count, 208
 - TLVs, 189
- logging, 239
- logging changes to, 58

- loop detection
 - clearing, 45
 - configuring a global interval, 44
 - displaying resource information, 46
 - enabling, 44
 - specifying the recovery time interval, 45

M

- MAC address
 - using for Layer 2 traffic, 31
- management application feature support, 1
- management port
 - commands, 2
 - overview, 1
 - rules, 1
- media, displaying information, 226
- MTU for IPv6, 136

N

- negotiation mode, changing the speed, 39
- network connectivity testing, 69
- NIAP-CCEVS certification, 299

O

- Operations, Administration, and Maintenance (OAM)
 - overview, 50
- optical monitoring, viewing, 228
- optical transceiver thresholds, viewing, 229
- optical transceivers
 - Syslog messages, 230

P

- ping
 - IPv6 address, 116
- port configuration
 - assigning a port name, 31
 - disabling or re-enabling a port, 35
 - enabling port speed, 33
 - modifying port duplex mode, 34
 - modifying port speed and duplex mode, 31
- port flap dampening configuration, 40

- port loop detection, 43
- port statistics
 - parameters, 245
 - viewing, 245

R

RMON

- alarm (group 3), 253
- event (group 9), 253
- export configuration and statistics, 251
- history (group 2), 253
- maximum number of entries allowed in control table, 250
- statistics, 251

RMON support, 250

S

- search string, using special characters, 8
- secure copy (SCP)
 - using to install a software license, 85, 86, 88
- secure shell (SSH)
 - and IPv6, 113
- sFlow
 - and CPU utilization, 256
 - and hardware support, 256
 - and sampling rate, 257
 - and source address, 256
 - and source port, 257
 - changing the polling interval, 259
 - changing the sampling rate, 259
 - changing the source port, 263
 - clearing statistics, 269
 - command syntax for sFlow forwarding, 263
 - configuration considerations, 256
 - configuring and enabling, 257
 - configuring version 5 features, 264
 - displaying information, 267
 - enabling forwarding, 263
 - exporting CPU and memory usage information, 266
 - extended gateway information, 255
 - extended router information, 255
 - IPv6 packet sampling, 256
 - overview, 254
 - specifying the collector, 258
 - specifying the maximum flow sample size,

- 266
- specifying the polling interval, 266
- specifying the version used for exporting sFlow data, 266
- support for IPv6 packets, 255
- uplink utilization list configuration, 270
- utilization list for an uplink port command syntax, 270
- version 5, 254

show command

- ipv6 inter tunnel, 124
- show boot-preference, 56
- show clock, 28
- show dir, 53
- show fdp entry, 175, 179
- show fdp neighbor, 173
- show fdp neighbors, 178
- show fdp traffic, 180
- show flash, 51
- show interface, 37, 249
- show interfaces tunnel, 124
- show ipv6, 127
- show ipv6 cache, 140
- show ipv6 interface, 141
- show ipv6 neighbor, 144
- show ipv6 route, 145
- show ipv6 router, 146
- show ipv6 tcp connections, 147
- show ipv6 tcp status, 149
- show ipv6 traffic, 151
- show ipv6 tunnel, 123
- show link-error-disable, 41
- show lldp, 218
- show lldp local-info, 205, 215, 218, 222
- show lldp neighbors, 221
- show lldp neighbors detail, 222
- show lldp statistics, 197, 220
- show lldp statisticsLLDP
 - displaying statistics, 219
- show logging, 232, 234, 235
- show loop-detection resource, 46
- show loop-detection status, 45
- show media slot, 227
- show optic, 228
- show optic threshold, 229
- show relative-utilization, 271
- show rmon statistics, 251
- show sflow, 260, 268
- show snmp engineid, 159, 167
- show snmp group, 168
- show snmp server, 117, 158, 167
- show snmp user, 168
- show snmp associations, 21
- show snmp status, 23
- show span, 247
- show statistics ethernet, 245
- show version, 50, 244
- snmp server-mode, 25
- span vlan, 247

Simple Network Time Protocol (SNTP), 20

SNMP

- community strings, 156
- configuring V3 over IPv6, 113
- configuring version 3 on Brocade devices, 159
- defining a group, 160
- defining a user account, 161
- defining the engine ID, 159
- defining the UDP port for traps, 165
- defining views, 163
- disabling traps, 17, 18, 19
- displaying groups, 168
- displaying the community strings, 158
- displaying the engine ID, 167
- displaying user information, 168
- encryption of community strings, 156
- interpreting varbinds in report packets, 168
- IPv6 support, 166
- Layer 2 generated traps, 17
- Layer 3 generated traps, 17
- overview, 155
- restricting access to an IPv6 node, 113
- setting the trap holddown time, 17
- specifying a single trap source, 16
- specifying a trap receiver, 15
- specifying an IPv6 host as trap receiver, 166
- specifying an IPv6 trap receiver, 113
- trap MIB changes, 165
- user-based security model, 159
- using to save and load configuration information, 66
- using to upgrade software, 54
- v3 configuration examples, 169
- version 3 traps, 164
- viewing IPv6 server addresses, 117, 167

SNMP parameter configuration, 15

SNTP

- configuring Brocade device to function as server, 23
- configuring over IPv6, 113
- displaying server information, 25
- enabling broadcast mode for client, 25
- specifying a server, 20

software image files, 53

software license

- terminology, 74
- transferring, 82
- viewing from the Brocade software portal, 80
- viewing information about, 91

- software licensing
 - configuration tasks, 74
 - obtaining a license, 75
- software reboot, 56
- software upgrade, 54
- special characters used in search string, 8
- SSH
 - using to install a software license, 85, 86, 88
- startup configuration, 58
- static IPv6 route configuration, 118
- static IPv6 route parameters, 120
- statistics
 - clearing, 248
 - displaying virtual routing interface, 18
 - enabling SNMP VE, 18
- STP statistics, viewing, 247
- Syslog
 - changing the log facility, 240
 - changing the number of entries the local buffer can hold, 239
 - clearing log entries, 236
 - clearing messages from the local buffer, 242
 - CLI display of buffer configuration, 235
 - disabling, 19
 - disabling logging of a message level, 239
 - disabling or re-enabling, 238
 - displaying interface names in messages, 241
 - displaying messages, 232
 - displaying real-time messages, 234
 - displaying TCP or UDP port numbers in messages, 241
 - displaying the configuration, 234
 - enabling real-time display for a Telnet or SSH session, 233
 - enabling real-time display of messages, 233
 - message due to disabled port in loop detection, 47
 - message types, 273
 - messages for CLI access, 19
 - messages for port flap dampening, 42
 - messages on a device with the onboard clock set, 237
 - messages supported for software-based

- licensing, 82
- overview, 232
- retaining messages after a soft reboot, 242
- service configuration, 234
- specifying a server, 238
- specifying an additional server, 239
- static and dynamic buffers, 235
- time stamps, 236
- Syslog messages
 - disabling, 18
- system clock
 - setting, 26
- system management
 - basic, 243
 - viewing information, 243
- system reload scheduling, 67

T

- Telnet
 - cancelling an outbound session, 20
 - testing network connectivity, 69
- TFTP
 - server file upload, 65
 - transfer remedies, 68
- thresholds
 - XON and XOFF, 38
- tracing an IPv4 route, 71
- Trunk
 - sflow-subsampling ethernet, 262
- trunk port
 - changing the sampling rate, 262
- Tunnel
 - ipv6 address, 122
 - ipv6 enable, 122
 - tunnel destination, 122
 - tunnel mode ipv6ip, 122
 - tunnel source, 122

V

- viewing system information, 243
- virtual routing interface statistics, 18
- VLAN
 - loop-detection, 44

X

XON and XOFF
thresholds, 38

