

操作说明书 Instruction Manual

PS 8000 DT Laboratory Power Supply



PS 8016-20 DT: 09 200 130 PS 8160-04 DT: 09	9 200 135
PS 8032-10 DT: 09 200 131 PS 8080-40 DT: 09	9 200 136
PS 8065-05 DT: 09 200 132 PS 8080-60 DT: 09	9 200 137
PS 8032-20 DT: 09 200 133 PS 8360-10 DT: 09	9 200 138
PS 8065-10 DT: 09 200 134 PS 8360-15 DT: 09	9 200 139

BUIK GmbH

-般信息

关于

Elektro-Automatik GmbH & Co. KG

Helmholtzstrasse 31-33

41747 Viersen Germany

电话: +49 2162 / 37850

- 传真: +49 2162 / 16230
- 网站: www.elektroautomatik.cn
- 邮箱: ea1974@elektroautomatik.cn

© Elektro-Automatik

严禁翻印、复制或部分错误地使用该说明书,否则将承担相应的法律后果。

人有生命危险!

危险电压

本产品输出电压可能上升至危险级别(>60V_{DC})!

产品上所有带电元件必须有外遮盖。输出端的所有操作必须在 产品与主电源(电源开关关闭)断开时才能执行,且可只有受 训过电流危险知识的专业人员执行此类操作。负载与本产品间 的任何连接必须有防碰擦装置。连到功率输出端的应用设备必 须配置好,并且有保险丝熔断保护,这样可防止使用过程中由 于过载或误操作损坏产品或更严重事情发生。

🥂 注意!

产品或输出关闭后,直流输出端在一定时间内仍存在危险电 压!

🚺 请谨记

- 请仅在铭板标示电压下操作本产品。
- 请勿将任何机械零件,特别是金属件,插入通风孔内。
- 请不要在本产品周围使用任何液体物质,以免进入产品内。
- 请勿将高于电源供应器额定电压的电压源连接到产品上。
- 从后板插槽安装接口卡时,请遵循一般防静电规则。
- 只能在产品完全关闭(电源开关为关闭状态)后插入和取出 接口卡。
- 产品老化以及超负荷使用都可能导致如按钮、旋钮类的产品控制件操作不稳定。
- 请勿将电压源反接到直流输出端! 产品可能会被损坏。
- 请勿将那些可能会产生高于产品额定电压的电压源连到直流输出端!

С

= ±
55-5-
2K AX

目录表 CI	N
而在	<u></u>
1. 介绍	5
2. 技术规格	5 5
2.1 注前面似和亚小语····································	8
3.1 产品图	8
3.2 插图说明	9
3.3 供应清单	9
4. 一般信息	9
4.1 序言/安全警告	9
4.2 前々	9 9
5. 安装	9
5.1 目检	9
5. 2 与市电的连接	9
5.3 直流输出端	9
5.4 "感测"端(远程感测)	9
5.5 按山下细信	9
0. 珠IF	0
6.2 控制面板上各按钮	0
6.2.1 Preset Voltage按钮	0
6.2.2 Preset UVL / OVP按钮	1
6.2.3 Preset Power按钮	1
6.2.5 Memory Select M1-M5按钮	1 1
6.2.6 Memory Start / Memory Save >3s按钮	2
6.2.7 Local按钮	2
6.2.8 Lock / Unlock按钮	2
6.2.9 Output On / Output Off按钮	2
6.3.1 按钮	3
6.4 调节设定值	3
7. 产品特性	3
7.1 用电源开关打开	3
7.2 用电源开关关闭	3
7.3 转全远程控制模式1 7.4 对压圾磁	3
7.5 讨温报警	3
7.6 调整电压、电流或功率	4
7.7 远程感测被激活	4
7.8 市电出现欠压或过压	4
/.9 连接个问尖型的贝戟	4
8. 广	5
9.	0
10. 俣拟按口	6
10.2 应用举例	7
10.3 各引脚描述	8
11. 其它 1	9
11.1 终端系统总线的功能	9
11.1.1 王从模式下的串联	9
□□.□.2 共学忌线俣玌卟的廾ು	:U 21
12 其它附件和洗项功能	21
12.1 附件和选项	21
12.2 固件更新	!1



1. 介绍

PS 8000 DT系列实验室电源因其桌面式外壳,特别适用于学校、实验室和工厂使用。

除电源产品的标准功能外,用户还可定义和恢复5组不同的预设 值,或使用可在0...5V或0...10V普通电压范围内工作的内置模拟 接口。从而提供一简易的监控本产品或完全远程控制的方法。

可选数字接口卡通过电脑实现更宽范围的控制和监控功能。1000W以上型号的特点为有一可调功率调整线路,以及"System Bus"端,它能实现主-从操作下的串联或共享总线下的并联。

通过接口卡的使用可轻易地将产品整合于现有系统内,且根本 不需配置接口卡或仅需配置少数设定值。

本产品通过接口卡可连接其他类型电源,并借此控制它们。或 者通过外置控制系统,如PLC-可编程控制器,对本产品进行 控制和监测。

本产品由微处理器控制,得以使之能准确、快速地测量并显示 各实际值。

主功能一览:

- 0...100%范围内的设定电压和电流
- 0...110% U_{Nom}可调过压门限
- 0...100%可调功率 (1kW型号起)
- 插拔式接口卡(CAN, USB, RS232, IEEE/GPIB, Ethernet/LAN, Profibus)
- 外部控制和监测用模拟接口,用0...5V或0...10V (可选)控制
 0...100%的范围值
- 功率级别: 320W, 640W, 1000W和1500W
- 温控风扇
- 状态(OT, OVP, CC, CV, CP)指示灯
- 5种可选内存集
- 串联时的主-从操作 (1kW型号起)
- 并联时的共享总线操作 (1kW型号起)
- Vector™兼容的CAN系统
- 免费的Windows软件
- LabView[™] VIs

2. 技术规格

2.1 控制面板和显示器

型号

显示器:	点阵显示, 202 x 32点
	分三个区域
旋钮:	2个旋钮,9+2个按钮

显示格式

额定值限定最大可调范围。

电压和电流的实际值同时显示,而过压门限设定值、欠压极限、 电流和功率(1kW型号起)则分开显示。

电压的显示

 分辨率:
 4位数

 格式:
 0.00V...99.99V

 0.0V...999.9V

电流的显示

分辨率: 格式: 4位数 0.000A…9.999A 0.00A…99.99A

功率的显示 (1k₩型号起)

分辨率:	4 位数
格式:	0.000kW9.999kW

2. 2 各型号详细规格

	PS 8016-20 DT	PS 8032-10 DT	PS 8065-05 DT	PS 8032-20 DT	PS 8065-10 DT	
电源输入						
输入电压	90264V AC	90264V AC	90264V AC	90264V AC	90264V AC	
输入电压功率降额	-	-	-	-	-	
230V时输入电流	max. 1.8A	max. 1.8A	max. 1.8A	max. 3.2A	max. 3.4A	
100V时输入电流	max. 3.8A	max. 3.8A	max. 3.8A	max. 7.5A	max. 7.5A	
输入频率	4565Hz	4565Hz	4565Hz	4565Hz	4565Hz	
输入保险丝	T 8A	T 8A	T 8A	T 8A	T 8A	
功率因数值	> 0.99	> 0.99	> 0.99	> 0.99	> 0.99	
输出 - 电压						
额定电压U _{Nom}	16V	32V	65V	32V	65V	
可调范围	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	
市电波动范围在±10% △U _{IN} 时的稳定度	< 0.02%	< 0.02%	< 0.02%	< 0.02%	< 0.02%	
带载10…90%时的稳定度	< 0.05%	< 0.05%	< 0.05%	< 0.05%	< 0.05%	
纹波 LF BWL 20MHz	< 4mV RMS	< 10mV RMS	< 20mV RMS	< 8mV RMS	< 10mV RMS	
纹波 HF BWL 20MHz	< 40mV P-P	< 100mV P-P	< 150mV P-P	< 100mV P-P	< 150mV P-P	
精确度*	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	
显示器分辨率	10mV	10mV	10mV	10mV	10mV	
远程感测补偿	max. 2V	max. 2V	max. 2V	max. 2V	max. 2V	
过压保护门限(可调)	017.6V	035.2V	071.5V	035.2V	071.5V	
输出 - 电流						
额定电流I _{Nom}	20A	10A	5A	20A	10A	
可调范围	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	
市电波动范围在±10% △U _{IN} 时的稳定度	< 0.05%	< 0.05%	< 0.05%	< 0.05%	< 0.05%	
带载0…100% ∆U _{out} 时的稳定度	< 0.15%	< 0.15%	< 0.15%	< 0.15%	< 0.15%	
纹波 LF BWL 20MHz	< 10mA RMS	< 7mA RMS	< 3mA RMS	< 10mA RMS	< 3mA RMS	
纹波 HF BWL 20MHz	< 60mA P-P	< 35mA P-P	< 12mA P-P	< 65mA P-P	< 25mA P-P	
精确度*	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	
显示器分辨率	10mA	10mA	1mA	10mA	10mA	
负载从1090%瞬态恢复时间	< 2ms	< 2ms	< 2ms	< 2ms	< 2ms	
输出 - 功率						
额定功率P _{Nom}	320W	320W	325W	640W	650W	
降低额定功率	-	-	-	-	-	
可调范围	-	-	-	-	-	
精确度*	-	-	-	-	-	
调节分辨率	-	-	-	-	-	
效率	≤ 90.5%	≤ 89%	≤ 93%	≤ 90.5%	≤ 91%	
其它						
制冷	风扇	风扇	风扇	风扇	风扇	
环境温度	050°C	050°C	050°C	050°C	050°C	
储存温度	-2070°C	-2070°C	-2070°C	-2070°C	-2070°C	
相对湿度	< 80%	< 80%	< 80%	< 80%	< 80%	
尺寸 (WxHxD)	330x118x308mm	330x118x308mm	330x118x308mm	330x118x308mm	330x118x308mm	
重量	6,5kg	6,5kg	6,5kg	6,5kg	6,5kg	
并联用Share bus	无	无	无	无	无	
产品编号	09200130	09200131	09200132	09200133	09200134	
串联		可抄	l行,总电压最高可达6	500V		
并联						
湿度	<80%					
绝缘耐压	输入端对输出端: 2500V; 输出端对外壳: 500V					
安全标准			EN 60950			
EMC标准	EN 61326, EN 55022 等级 B					
过压等级						
模拟编程						
电压范围		C)5V 或 010V (可选	<u>)</u>		
	1		≤ 0.2%			
输入阻抗			约 53kΩ			
		<i>.</i>				

举例:一台80V型号产品的电压精确度最少为0.2%,即为160mV。当设定5V电压时,且允许最大误差为160mV, 故得出实际值可能在4.84V和 5.16V.之间。



CN

6

	PS 8160-04 DT	PS 8080-40 DT	PS 8360-10 DT	PS 8080-60 DT	PS 8360-15 DT		
电源输入							
输入电压	90264V AC	90264V AC	90264V AC	90264V AC	90264V AC		
输入电压功率降额	-	-	-	90150V	90150V		
230V时输入电流	max. 3.2A	max. 4.8A	max. 7.5A	max. 7.5A	max. 7.5A		
100V时输入电流	max. 7.5A	max. 11.4A	max. 11.4A	max. 11.4A	max. 11.4A		
输入频率	4565Hz	4565Hz	4565Hz	4565Hz	4565Hz		
输入保险丝	T 8A	T 16A	T 16A	T 16A	T 16A		
功率因数值	> 0.99	> 0.99	> 0.99	> 0.99	> 0.99		
输出 - 电压							
额定电压U _{Nom}	160V	80V	360V	80V	360V		
可调范围	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	0V…U _{Nom}		
市电波动范围在±10% △U _{IN} 时的稳定度	< 0.02%	< 0.02%	< 0.02%	< 0.02%	< 0.02%		
带载10…90%时的稳定度	< 0.05%	< 0.05%	< 0.05%	< 0.05%	< 0.05%		
纹波 LF BWL 20MHz	< 20mV RMS	< 4mV RMS	< 11mV RMS	< 4mV RMS	< 8mV RMS		
纹波 HF BWL 20MHz	< 120mV P-P	< 10mV P-P	< 30mV P-P	< 10mV P-P	< 50mV P-P		
	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%		
	100mV	10mV	100mV	10mV	100mV		
	max. 2V	max. 2.5V	max. 8V	max. 2.5V	max. 8V		
过压保护门限(可调)	0176V	088V	0396V	088V	0396V		
输出 - 电流							
额定电流I _{Nom}	4A	40A	10A	60A	15A		
	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}		
市电波动范围在±10% ΔU _{IN} 时的稳定度	< 0.05%	< 0.05%	< 0.05%	< 0.05%	< 0.05%		
带载0…100% ΔU₀₀π时的稳定度	< 0.15%	< 0.15%	< 0.15%	< 0.15%	< 0.15%		
纹波 LF BWL 20MHz	< 1mA RMS	< 7mA RMS	< 0.45mA RMS	< 7mA RMS	< 0.45mA RMS		
纹波 HF BWL 20MHz	< 3mA P-P	< 19mA P-P	< 1mA P-P	< 19mA P-P	< 1mA P-P		
	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%		
显示器分辨率	1mA	10mA	10mA	10mA	10mA		
	< 2ms	< 2ms	< 2ms	< 2ms	< 2ms		
输出 - 功率							
·····································	640W	1000W	1000W	1500W	1500W		
隆低额定功率	-	-	-	1000W	1000W		
可调药用	_	0P _{Nom}	0P _{Nom}	0P _{Nom}	0P _{Nom}		
	-	≤ 1%	≤ 1%	≤ 1%	≤ 1%		
调节分辨家	_	1W	1W	1W	1W		
	< 92%	< 93%	< 92%	< 93%	< 9.3%		
	_ 02.70	- 0070	_ 02 /0	_ 0070	_ 00/0		
<u>来し</u>	风扇		风扇	风扇	図扇		
—————————————————————————————————————	0 50°C	0 50°C	0 50°C	0 50°C	0 50°C		
小说温及 ————————————————————————————————————	-20 70°C	-20 70°C	-20 70°C	-20 70°C	-20 70°C		
相对温度	< 80%	< 80%	< 80%	< 80%	< 80%		
	330v118v308mm	330v118v388mm	330v118v388mm	330v118v388mm	330v118v388mm		
了(IIXIIXD) 香島	6 5kg	8 5kg	8.5kg	8 5kg	8.5kg		
<u>王里</u> 並昭田Share bus	 		0,5Kg 古		0,5kg 左		
	00200135	行	行	行	10200130		
) 叩/// 5 	09200133	09200130 可划	1 09200130	09200137	09200139		
一	凹 八11, 空 以 S n are bus n 取 多 注 夜 1000 W 以 上 的 30 台 广 品 2000/ 2000/ 2000/ 30 日 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一						
徑 皮 	<u>۲۵۷%</u> ۵۵ کی						
地球耐压	· · · · · · · · · · · · · · · · · · ·						
女 至 标 / 性		F •••	EN 60950	1 D			
EMC标准	EN 61326, EN 55022 等级 B						
过压等级	────────────────────────────────────						
			等级				
保护等级			等级丨				
保护等级 模拟编程			等级				
保护等级 模拟编程 电压范围		(等级 Ⅰ 0…5V 或 0…10V (可选				
保护等级 模拟编程 电压范围 设定/实际值精确度		(等级 Ⅰ 05V 或 010V (可选 ≤0.2%	i)			

举例:一台80V型号产品的电压精确度最少为0.2%,即为160mV。当设定5V电压时,且允许最大误差为160mV, 故得出实际值可能在4.84V和 5.16V.之间。

CN



3.2 插图说明

- A- 电源开关
- B- 控制面板
- C- 电源输出
- D-模拟接口,15脚,母座
- E- 外接数字接口卡插槽
- F- 系统总线
- G- 风扇

H- 输入保险丝 (具体值请看章节"2.2 各型号详细规格") J- 电源输入插座, 3脚, IEC 60320

3.3 供应清单

- 1 x 电源供应器
- 1 x 印刷版使用说明书
- 1 x 电源线
- 1 x 系统总线插头

4. 一般信息

4.1 序言/安全警告

本说明书和产品专给对电源有基本了解的人士使用。不应给无基本电器知识的人士操作,因本说明书未作此方面描述。操作不当和未遵守安全说明的操作,可能会损坏产品或丧失产品保修权!

4.2 制冷

要保持外壳底部进风孔和后板排风孔的清洁,以确保良好的冷却。注意产品后方至少10cm以内无任何物体阻挡,以保障空 气流通顺畅。

4.3 拆开产品

若要拆开产品或用工具从产品内部拆除零件,可能会有高压触 电的危险。必须将本产品与主电源断开后方可进行,否则用户 自行承担风险。

有受过电流危险知识训练的人员方可进行相关的维护或修理。

5. 安装

5.1 目检

收到本产品后,请检查是否有外观受损痕迹。如有,请不要操 作本产品,应立即联系您的供应商。

5.2 与市电的连接

本产品通过电源线接地。故仅可与带接地触点的电源插座相 连。且连线中间不可接无接地触点的延伸线!

还装有5x20mm的保险丝(具体数值请看规格参数表),从电源插座内可拆装更换。

5.3 直流输出端

功率输出端位于产品前部。

本输出端**无**保险!为避免损坏负载设备,应随时注意负载机的额定值。

连接线的直径取决于多个条件,像输出电流、线长和环境温度。

建议使用长为1.5m的连线:

10A以下:	0,75mm²	15A 以下:	1,5mm²
30A以下:	4mm²	40A 以下:	6mm²
60A以下:	16mm²		
针对 每根线 (弹	性线)。		
+A 11 4 . " TH 4	" 却 ナ ☆ い	サナツ亜 可返せ市	+17 +· 나나

输出"+"和"-"极未接地,若有必要,可将其中一极接地。

🥂 注意!

对于1000W和1500W型号产品,直流输出端的4mm前板插座最大 仅能承受32A的电流!

<u> (</u>注意!

将其中一输出极接地时,请随时检查负载(如电子负载)的其中 一极是否也已接地。否则将引起短路!

🚹 注意!

串联时请注意输出极的电位转移!此时仅建议接地到最低电 位的极点上。

5.4 "感测"端(远程感测)

为补偿负载线上(每根线最大1V)的压降,电源可"感测"负载 端而不是输出端的电压。它将调整输出电压以使负载获得所需 电压。

将远程感测线连到产品后方"System Bus"端子的1和2引脚上。见章节3.1。

<u>介</u>注意!

(+) 感测端只能与负载设备(+)端相连,(-)感测端与(-)端 相连!否则会损坏两头的产品。

详情也可参考章节7.7。

5.5 接口卡插槽

可选择给本产品配上接口卡。接口卡插槽位于产品后端。更多 信息见章节"9.数字接口卡"。



图 4. 控制面板

操作 6

显示器 6.1

图4描绘了点阵显示器和控制面板全图。正常操作时,显示器显 示实际电压(左边)和电流(右边),以及产品状态(中间) 。在预设模式下, 左显示区域显示电压设定值(预设电压), 过压保护阀值(预设OVP)或欠压极限(预设UVL)设定值。 右显示区域显示电流(预设电流)或功率设定值(预设功率, 仅针对1kW以上型号)。在产品设置模式下,显示器显示可调 参数和设定。

中间的状态区域则显示下列状态:

- CV 恒压调整 (只有当输出为"on"时)
- **OT**-过温错误

OVP-过压错误

CC - 恒流调整 (只有当输出为"on"时)

CP - 恒功率调整 (只有当输出为"on"时)

Fine - 旋钮启用时细调

PF - 电源故障(输入电压故障,自6.0固件版本后方显示)

图解:

- (1) 左显示区域:实际电压或V, UVL, OVP的设定值。
- (2)-状态区域:显示状态,如CC,CV等。
- (3) 右显示区域:实际电流或I, P的设定值。
- (4)-控制按钮:设定产品条件等。
- (5) 右旋钮:调节I和P设定值,以及在产品设定模式下的各项 设定。
- (6) 预设按钮:转为显示设定值。
- (7) 左旋钮:调节V、UVL和OVP设定值,以及产品设定模式 下的各项参数。

控制面板上各按钮 6.2



正常操作模式下,该按钮可将实际输出电压值的显示转为预设输 出电压值的显示(即:预设模式)。左显示区域将显示如下:



预设模式下,左旋钮(Voltage / UVL / OVP)用来调节设定电 压,其操作与在正常操作方式下的一样。调节值会立即传输到 输出端!

提示

设定值的调节由欠压阀值UVL限制。见章节6.2.2。

按两下该按钮立即退出预设模式,或者,如果没按预设按钮或 有任一设定值被更改,则5s后自动退出。

由模拟或数字接口控制的远程控制模式下,可用预设模式检测 远程输入的电压设定值。

用LOCK键可锁定该按钮。见章节6.2.8详述。

内存选择模式下,用该按钮可转为显示所选内存集的电压设定 值,但是<u>不会</u>传输到输出端。左显示区域将显示如下:



E





正常操作模式下,该按钮可将欠压极限(按一下)或过压保护 阀值(按两下)实际值的显示转为其设定值的显示。

左显示区域将显示如下:

Preset OVP		Preset UVL	
88.00V		2.00V	
	与		

欠压极限(UVL)仅仅是输出电压的调节极限。意思是,如果UVL 设为0以外的任何值,则只能将电压设定值向下调低至UVL值。同样,UVL值只能往上调高至电压设定值。

左旋钮(Voltage / UVL / OVP)用来调节0...Uset范围内的UVL值。

按两下按钮,转为显示过压保护阀值预设值(OVP)。这个数值 始终在0...110% U_{Nom}范围内。

按三下按钮立即退出预设模式,或者,如果没按预设按钮或有 任一设定值被更改,则5s后自动退出。

由数字接口控制的远程控制模式下,可用预设模式检测远程输入的OVP设定值。

用LOCK键可锁定该按钮。见章节6.2.8详述。

内存选择模式下,该按钮可转为显示所选内存集的UVL值或OVP 值,但是<u>不会</u>立即生效。左显示区域将显示如下:



6.2.3 Preset Power按钮

Preset Preset Preset Preset Voltage UVL /OVP Power Current



正常操作模式下,该按钮可将实际电流值的显示转为输出功率 预设值(预设模式)。

仅1kW以上多数型号才有可调功率调整,右显示区域将显示如下:



预设模式下,右旋钮(Current / Power)用来调节0...100% P_{Nom} 范围内的功率设定值。调节值会立即传输到输出端!

按两下该按钮立即退出预设模式,或者,如果没按预设按钮或 有任一设定值被更改,则**5s**后自动退出。

用LOCK键可锁定该按钮。见章节6.2.8详述。

模拟或数字接口控制的远程控制模式下,可用预设模式检测远 程输入的功率设定值。

内存选择模式下,用该按钮可转为显示所选内存集的功率设定 值(仅针对1kW以上型号),但是<u>不会</u>传输到输出端。右显示 区域将显示如下:

Memory 1: P 1.200kW

6.2.4 Preset Current按钮



正常操作模式下,该按钮可将实际输出电流值的显示转为预设 输出电流值(预设模式)。

右显示区域将显示如下:

Preset	Current
45.60A	

预设模式下,右旋钮(Current / Power)可在正常操作模式下一样,调节0...100% I_{Nom}范围内的电流设定值。调节值会立即传输到输出端!

按两下该按钮立即退出预设模式,或者,如果没按预设按钮或 有任一设定值被更改,则5s后自动退出。

由模拟或数字接口控制的远程控制模式下,可用预设模式检测 远程输入的电流设定值。

用LOCK键可锁定该按钮。见章节6.2.8详述。

内存选择模式下,用该按钮可转为显示所选内存集的电流设定值,但是<u>不会</u>传输到输出端。右显示区域将显示如下:



6.2.5 Memory Select M1-M5按钮

Memory Select M1 - M5

该按钮在5个内存集间循环,每个内存集都有U、I、P、以及 UVL和OVP的设定值。在这儿可编辑、存储或提交所选内存 集。该按钮只有在输出为off 时才工作。内存模式和所选内存 集号显示如下:



用该按钮用户可执行下列操作:

a) 调节值

输出关闭,短按按钮,显示器变为第一个内存集,如上所示。

现在可调节所选内存集的电压(左)和电流(右)设定值。推动相应 预设按钮可访问其它可调值。

再按按钮,会循环显示至内存集5,然后退出内存模式。

只要产品一直处于打开状态,调节后的数值会一直保留,但是 不会提交给输出设定值,也未存储下来!保存调节值请见章节 6.2.6。

用LOCK键可锁定该按钮。见章节6.2.8详述。



Memory Start Memory Save >3s

该按钮用来将选定的内存集设定值提交给输出,或保存内存设定。该按钮只有当输出为**off**时才工作。

用该按钮用户可执行下列操作:

b) 仅提交

输出关闭,选择内存集(1-5),短按按钮 --> 内存集值提交为输 出设定值,然后退出内存模式。要使用新值,先用Output On 按钮或远程控制打开输出。



提交设定值不会保存它们!

c) 仅存储

输出关闭,选择一个或多个内存集,按需要调节数值,按住按 钮超过**3s**-->所有内存集被保存,但不会被提交给输出。输出 仍为关闭状态,保存内存集后退出内存模式。

也可利用数字接口(除GPIB外)通过远程控制和相应指令来 定义内存集。

用LOCK键可锁定该按钮。见章节6.2.8详述。

6.2.7 Local按钮



本按钮激活或终止LOCAL模式。在LOCAL模式下不可进入远 程控制模式。LOCAL模式由"Local"灯指示。只要LOCAL未激 活, "Remote"灯就指示产品通过模拟或数字接口处于远程 控制模式。

用LOCK键可锁定该按钮。见章节6.2.8详述。

🚺 提示

激活LOCAL模式将会即刻从远程控制模式退出(模拟或数字 控制),并锁定产品,不再允许继续远程控制产品,直到再 次退出LOCAL模式。

🚺 提示

LOCAL模式只是暂时的,关闭产品后不会保存。

6.2.8 Lock / Unlock按钮



本按钮激活或终止控制面板锁定。LOCK模式下锁定所有的按 钮,除LOCK按钮外。锁定控制面板可防止无意使用按钮和旋 钮。

🚺 提示

激活LOCK模式会即刻退出任何预设或记忆模式,如果有任何 此类模式被激活。显示器会返回实际值的正常显示。

🚺 提示

自6.02版固件版本的产品,当产品关闭时LOCK模式会被保存,重启后则恢复。

6.2.9 Output On / Output Off按钮



只要产品未处于遥控模式,可用此按钮手动打开或关闭电源输。 输出状态通过按钮上面的"Output On"或"Output Off"LED 灯指示出来。输出打开时,在显示器中间状态区域显示当前工 作中的调整模式CC、CV或CP(仅针对1kW以上型号)。

用LOCK键可锁定该按钮。见章节6.2.8详述。

输出的打开可通过模拟接口的13脚(REM-SB)来阻止。见章 节 "10. 模拟接口"。

此按钮还可用来确认错误消息。详情请见7.4和7.5章节。



6.3 其它控制键

6.3.1 按钮

这两个旋钮有推动功能。推动任何一个或两个会有下列作用:

a) 细调模式 (Fine)

短按任何一按钮可启用或停用细调模式。如果激活"Fine", 所有设定值、阀值和极限值都按最小的幅度调节,不管当前为 何种模式(预设,内存等)。在状态显示区域以"Fine"文字 显示出来。也可参考下面章节"6.4 调节设定值"。

b) 产品设置

当输出为off时,同时按住两个按钮,时间>3s,可将产品改至 产品设置。按相同方式可退出。

6.4 调节设定值

1. 手工操作

在手工操作下,两旋钮可按预定幅度(见下表)在0%至100%的额定电压和电流设定值间连续调节。若想设置OVP和UVL, 需按一下或两下Preset UVL/OVP按钮。若想设置功率设定值 (1kW以上型号),需按Preset Power按钮。

● 提示
OVP值可能会低于电压设定值,只要一打开输出,实际电压
达到OVP阀值,就会出现OV错误!

可通过细调或粗调手动完成设定值的设置,默认为粗调。需 Fine-细调时按任意一个旋钮来激活,幅度为1。

coarse-粗调则按额定值的下列步宽来进行(也可参考技术规 格):

电压 / OVP / UVL			电流		
额定值	粗调	细调	额定值	粗调	细调
16V	0.1V	0.01V	4A	0.05A	0.001A
32V	0.2V	0.01V	5A	0.05A	0.001A
65V	0.V	0.01V	10A	0.1A	0.01A
80V	0.5V	0.01V	15A	0.1A	0.01A
160V	1V	0.1V	20A	0.2A	0.01A
360V	2V	0.1V	40A	0.5A	0.01A
			60A	0.5A	0.01A

功率				
额定值	粗调	细调		
1000W	0.01kW	0.001kW		
1500W	0.01kW	0.001kW		

🚺 提示

可调设定值的分辨率在某些型号上要高于输出电压分辨率。故 有可能发生执行2或3个步宽后才能改变输出电压。

2. 通过模拟接口远程控制

请参考章节"10. 模拟接口"。

3. 通过数字接口卡远程控制

请参考章节"9.数字接口卡"。

7. 产品特性

7.1 用电源开关打开

电源开关位于产品前端。打开产品后,显示器将显示一些信息:生产商名称,地址和标识,产品类型和固件版本。在设置模式下(见"8.产品设置")出现"AutoPwOn"(自动打开电源)选项,它决定产品打开时的输出状态。默认状态下为"on",意思是可恢复产品最后关闭时U、I、P的设定值,OVP和UVL值,以及输出条件。如果该选项为"off",U和I设定值设为0,P的设定值为100%,OVP设为最大值,UVL为最小值,输出在每一次开启后打开。

7.2 用电源开关关闭

用电源开关关闭产品如电源断电一样。它会保存最后的设定值 和输出条件。短时间过后,功率输出和风扇关闭,再过几秒钟 后,产品完全关闭。

7.3 转至远程控制模式

a) <u>模拟接口</u>:如果产品没被LOCAL模式限制,或早已经数字接口激活远程模式,"Remote"引脚可将产品转换到远程控制模式。于是VSEL (1), CSEL (2),以及REM-SB(13)引脚的设定值可被使用。传输给这些引脚的输出状态和设定值即刻被设置。从远程控制返回后,输出关闭。

b) <u>数字接口</u>:如果产品没被LOCAL模式限制,或早已经模拟 接口激活远程控制,通过相关指令(此处为:对象)转为数字 远程控制,并保留输出状态和设定值,直至被更改。退出远程 控制,会自动关闭输出。

7.4 过压报警

过压报警可以因内部缺陷(输出电压上升且不可控)或外部电压太高而引起。过压保护(OVP)将关闭输出,并在显示器上以"OV"文字和AI上的"OVP"引脚指示此报警信息。

如果清除过压原因,输出会再次打开,但需先确认此报警信息。在手工操作模式下,以按下Output On/Off按钮为确认方式,在模拟遥控模式下是"REM-SB"引脚,而在数字遥控模式下为相关指令。会出现"OV"状态文本和OVP信号。只要报警仍然存在,则不打开输出。

OV报警会被记录到内部警报缓冲区内。通过数字接口可读取 该缓冲区内信息(除用SCPI语言编程的外)。读取缓冲区信 息也表示确认报警信息。

🚺 提示

OV报警状态优先于OT报警状态,当两个错误同时出现时 会覆盖 "OT" 状态文字,但不确认该报警信息。

7.5 过温报警

一旦因内部过热而出现过温(OT)错误,则关断输出,且出现 "OT"状态文字。同时,,Output On"灯会闪烁,指示出产品一 旦冷却后即自动重启。如果不想这样,可手工关闭输出。LED 灯停止闪烁,输出就不会自动启动。

OT错误要被确认。如果输出已关闭,产品已冷却下了,可用 Output On/Off按钮,或通过,REM-SB"引脚,亦或相关指令 再次打开输出。如果输出为打开状态,可按一下Output On/ Off按钮,或给"REM-SB"引脚一由高至底的触发,或使用 相关指令先确认该报警信息,然后关闭输出。

,如果产品在冷却后还是关闭的,可使用**Output on**按钮或 "REM-SB"引脚或相关指令来打开

OT报警会被记入内部报警缓冲区。通过数字接口可读取该缓 冲区内信息(除用SCPI语言编程的外)。读取缓冲区信息也 表示确认报警信息。

🚺 提示

E

OT报警状态对于OV错误报警而言,优先级别较低一些。当两个报警同时出现时, "OV"会覆盖"OT"状态文字,但不确认该报警信息。

7.6 调整电压、电流或功率

电源的输出电压和负载的阻值决定输出电流。只要输出电流低于设定电流极限值,产品以恒压(CV)模式操作,且以"CV"状态文字指示出来。

如果输出电流受限于电流设定值或额定电流,产品会转为恒流 模式(CC),并以"CC"状态文字指示出来。

输出功率在1kW以上的多数型号有一额外特征,即具有 0...P_{Nom}的可调功率极限。如果产品实际电流和电压超过可调 功率极限,即激活该功能,并覆盖恒压或恒流调整模式。功率 极限最初影响输出电压。因为电压、电流和功率极限相互影 响,有可能出现像下面这样的不同状况:

例1: 产品进入恒压模式,然后限制了功率,因此,输出电压 减少。较低的输出电压导致输出电流减小。如果负载阻值减 小,输出电流会再次上升,输出电压进一步下降。

例2: 产品进入恒流模式,输出电压有负载阻值决定。于是限制了功率,根据P=U*I公式,输出电压和电流减少。如果电流设定值减少,输出电流和电压也会减少。产品的两个值,实际功率将低到之前设定的功率极限以下,产品由恒功率调整(CP)转为恒流调整(CC)。

7.7 远程感测被激活

远程感测操作用来补偿电源和负载间连线的压降。因为这受限 于一定水平,建议按照输出电流选择适当直径的连线,以将压 降减到最小。

感测输入端位于产品后板,System Bus端子上。按正确极性 连线到此。电源会自动检测外部感应端,并通过负载的实际电 压而非输出电压,来补偿输出电压,从而按照电源与负载间的 压降值提升输出电压。最大补偿值请见规格参数表。也可参考 下图5。

7.8 市电出现欠压或过压

本产品的特征为采用主动式功率因素和宽范围的输入。意为,可在90V...264V,输入电压下操作。90V以下的输入电压被认为是断电,或完全关闭产品,它会保存产品最后条件,关断功率输出。

CN

1 注意!

应避免输入端长期欠压或过压!

🚺 提示

1500W功率的产品在输入电压低于约150V时降额至1000W。

7.9 连接不同类型的负载

不同类型的负载,如阻性负载(台灯,电阻),电子负载或感性 负载(马达),性能不同,它们会对电源起反作用。例如,马达 会产生一反电压,导致电源因过压保护而关断输出。

电子负载有电压、电流和功率调整线路,他们与电源的相互作用,可能会提高输出纹波或其它多余的副作用。电阻负载几乎 100%中性。故建议在安排应用时要考虑负载的特性。





产品设置 8.

产品设置目的在于调节某些操作参数。当输出关闭后方可访问。 长按旋钮上的两个按钮(见章节6.3)超过2s即可。退出设置并 存储设定的操作方式与之相同。通常有三个基本设置,见下面。 其它设定仅在配上数字接口卡时才出现。

基本设置:

参数: AutoPwr	0n	Def	ault: c	n.			
可设置值: on,	off						
		 			 		_

解释: "on" --> 在产品被关闭或停电前,最后输出状态和设 定值被保存下来。这可保证产品在恢复电源后可继续按最后的 设定自动运作。

"off" --> 每次产品打开后,输出也被打开, U, UVL和I的设 定值被设为0%,P为100%,而OVP为110%。

	- , •
参数: AI range	默认值: 0-10
可设置值: 0-5, 0-10	
解释:通过模拟接口选择使用的	电压范围。
参数: Contrast	默认值: 70
可设置值: 50100	
解释:调整LCD显示器的对比度	; , 0
下列设置适用于 <u>所有</u> 接口卡:	
参数: Device node	默认值: 1
可设置值: 130	
解释:选择产品位址(产品节点	,来自CAN专业术语)。当将
产品应用于总线系统(CAN或GP	IB)时,每台产品必须有一独特
的地址!	
参数: Baud	
设置值: 10k,25k,50k,100	ðk,125k,250k,500k,1M
解释:选择CAN传输波特率。	
参数: Base ID	默认值: 0×000
设置值: 0×0000×7FC	(02044)
解释:通过三个IDs(Vector兼容 统的基本ID(BAID)。根据调整后 台产品。因此只有在第四步时才f 钮可将显示器从十进制值转为十	, DBC文件)来定义CAN ID系 的基本ID,这三个IDs预留给一 能调节这些参数。推动任何一旋 六进制值显示。
只有当ID Sys=Vector 被逆 参数ID Sys。	¹ 走定后方出现这个参数,见下面
只有当ID Sys=Vector 被逆 参数ID Sys。 参数: Broad ID	5. 地理学校会会、現代の主要がある。 ただしていた。 ただいでは、 ただいで、 たたいで、 たいで たいで、
只有当ID Sys = Vector 被逆 参数ID Sys。 参数: Broad ID 设置值: 0×0000×7FF	选定后方出现这个参数,见下面 默认值: 0×7FF (02047)

系统的广播ID (BCID)。这个ID是产品用来给同一总线上的多 台产品广播信息的第四个ID。仅以十六进制值显示。目的在于 所有产品的这个ID调节成相同值,从而可通过设定值或产品状 态同时控制这些产品。

只有当ID Sys = Vector 被选定后方出现这个参数,见下面 参数ID Sys。

默认值: 0

E

可设置值: 0...31 解释:选择重定位识别段(RID)。可参考CAN专业术语或IF-C1 CAN接口卡的说明书,查阅更多信息。

参数: Bus term

可设置值: yes, no

解释: 启用/停用CAN接口卡的总线终止电阻。仅在产品位于总 线终端时需要。

默认值: yes

参数:	ID	Sys		默认值:	Vector
可设置	值 :	Vector,	normal		

解释:选择CAN ID系统(IDSY)。用"Normal"设定,针对旧 CAN ID系统,每台产品使用两个CAN IDs。这两个ID由,Device node"(如上)与"RID"(如上)创建而成。也可参考 接口卡的使用说明书, CAN ID计算方法的描述。

其它ID系统就选择"Uector",每台产品使用三个CAN ID, 因此才能使用所谓的DBC文档,将产品应用到公司的Vector软 件中。选择这个ID系统时,与设定相关的两个ID(如上)被激 活,用户可调节用来定义三个ID的基本ID,以及一个广播ID(如有使用)。

利用RS232接口卡-IF-R1才可进行下列设置:

参数: Bau	лd		默认信	í: 57600
可设置值:	9600,	19200,	38400,	57600

解释:选择以波特率为单位的串行传输速率。利用RS232不可 配置其它参数,但可这样定义:

奇偶性 = 奇数 停止位 = 1 数据位 = 8 必须在电脑上设置相同的配置。

利用Profibus接口卡-IF-PB1才可进行下列设置:

参数: Profib)US	默认值:	1
可设置值: 1-:	125		

解释: 定义产品的Profibus地址。该地址与产品节点分开使用, 以在现场总线系统上进入产品内部。

PS 8000 DT 系列 产品说明书

参数: RID

9. 数字接口卡

本产品支持下列插拔式接口卡:

IF-U1 (USB)

IF-R1 (RS232)

IF-C1 (CAN)

IF-G1 (GPIB/IEEE)

IF-E1 / IF-E1B (Ethernet/LAN + USB)

IF-PB1 (Profibus + USB)

这些卡插入产品后仅需进行少数设置或不需任何设置。即使替 换成另外一不同类型卡,仍能保留前一张卡的具体设置。因此 不用每次插入一张卡就设置一次。

关于接口卡的详细技术规格和操作,以及将产品应用于总线系统的说明,或用电脑(LabView等)控制产品,都可在IF卡用户操作说明书中找到。

🤨 注意!

仅在产品被完全关闭(用电源开关)后才可插入或取出接口卡!

关于插拔式接口卡的配置请看章节"8.产品设置"。

数字接口允许电脑设置电压,电流和功率,以及OVP阀值与欠 压极限值UVL。当转为远程控制模式时,产品保留最后的设定 值,直至被更改。因此可传送任意的设定值仅用来控制电压, 而电流值保持不变。

数字接口(除GPIB外)传输的设定值永远为百分数,对应100% (hex: 0x6400)的额定值,或110%(hex: 0x6E00)的OVP阀值。使 用GPIB卡时,任何值都按实际十进制值输入。

另外,数字接口卡允许查询和设定大量其它功能和数值。更多 详情请参考接口卡的使用说明书。

10. 模拟接口

10.1 一般信息

内置、非隔离15脚模拟接口(AI)位于产品后端,提供下列功能:

CN

- 远程控制输出电流和电压
- 远程控制输出功率 (仅针对1kW以上型号)
- 远程控制输出电压
- 远程监控(OT, OVP, CC, CV)状态
- 远程监控实际数值
- 远程打开/关闭输出

模拟接口(简称: Al)通常能结合起来远程控制电源产品的电流, 电压和功率(针对1kW以上型号)。即,用Al来调节电压的同 时,不可用前板旋钮调节电流,反之亦然。1kW以下型号的输 出功率不需功率设定值PSEL,因此不需输入。

由于不可用AI调节OVP阀值,故需在远程控制模式前以手动设定。用设定按钮转为预设模式,显示转化后的设定值,传输给AI设定值引脚,作为它的电压。为了设置合适的设定值,用户可借助外电压,或3脚的参考输出电压。

AI能通过普通的0...5V或0...10V范围工作,它们对应0...100%的 额定值。产品设置模式(见章节,,8.产品设置")下可选择所需 电压范围。输出引脚3的参考电压与选择的设定范围有关,要么 为5V,或者为10V。

以下适用:

0-5V: 参考电压=5V,0...5V设定电压相当于0...100%的额定电压,在实际输出端,则相当于0...100%的实际数值。

0-10V: 参考电压 = 10V, 0...10V设定电压相当于0...100%的额 定电压,在实际输出端则对应0...100%的实际数值。

若输入超过极限的设定值,如>5V,当已选择0...5V电压范围,则将有关设定值减至100%而限制。

请注意:

- 用模拟电压来控制产品需用 "REMOTE" (5)引脚转为远程 控制模式。
- 连接控制电源的应用设备前,要保证所有连线正确,并检查应 用设备不会输入高于指定电压的电压(最大12V)。
- REM-SB (程待机, 13引脚)引脚要优先于Output On按钮。 意思是,如果该引脚定义输出状态为"off",除非已激活 LOCAL模式。该模式会锁定所有接口,阻值其访问产品。也 可见"6.2.7 Local按钮"。
- 模拟接口的地与输出负极相连。





输出关闭

"REM-SB"引脚一直都为工作状态,因此它不依靠远程模式。在无外部手段的条件下可用来关闭输出。具体操作是,利用一低阻连接件,如开关、开集三极管或继电器,将该引脚接到地(DGND),这样就可关闭输出。

CI

🚺 注意

例如PLC的数字输出脚可能无法正确操作,因其阻抗可能不够 低。故需随时检查您外部控制设备的技术规格。



远程控制电流和电压

VREF和接地脚之间有两电位器,VSEL和CSEL输入端上有一 滑动器。利用前板上的旋钮可控制电源,将它当作电流源或电 压源用。如果VREF输出脚的电流最大为3mA,则需使用至少 为10kOhm的电位器。

这儿显示的是带功率调整特点的产品型号,功率设定值束缚于 VREF,因此为100%。





远程控制功率

与上述例子相似,但是用可调功率极限来完成。(仅适用于具 有功率调节功能的产品型号)



10. 3	0.3 各引脚描述					
引脚	名称	类型 (1	描述	水平	电气参数	
1	VSEL	AI	设定值:电压	0…10V 或 0…5V 对应 U _{Nom} 的 0100%	精确度 < 0,2%	
2	CSEL	AI	设定值:电流	0…10V 或 0…5V 对应 INom 的 0100%	阻值 R _i >100k	
3	VREF	AO	参考电压	10V 或 5V	I _{Max} = +5mA 时,精确度 < 0.2% 短路保护对 AGND	
4	DGND	POT	数字控制信号参考电位		+Vcc, 控制和状态信号	
5	REMOTE	DI	在内控和外控间切换	外控 = LOW, ULow <1V 内控 = HIGH, Uнigh > 4V 内控 = HIGH	电压范围 = 0 …30V 输出 5V 时,I _{Max} = +1mA 发送:开集电极对 DGND	
6	OT/PF	DO	过温错误 电源故障 ⁽⁴	错误 = HIGH, U _{High} > 4V 无错误 = LOW, U _{Low} <1V	准开集电极上拉至 Vcc ⁽² 输出 5V 时,电流最大 +1mA U _{CE} = 0.3V 时,I _{Max} = -10mA U _{Max} = 030V 对 DGND 有短路保护	
7	N.C.				不连	
8	PSEL ⁽³	AI	设定值: 功率	010V 或 05V 对应 P _{Nom} 的 0100%	精确度 < 0.5% 阻值 R _i >100k	
9	VMON	AO	实际值: 电压	010V 或 05V 对应 U _{Nom} 的 0100%	I _{Max} = +2mA 时,精确度 < 0.2%	
10	CMON	AO	实际值: 电流	010V 或 05V 对应 I _{Nom} 的 0100%	短路保护对 AGND	
11	AGND	РОТ	模拟信号参考电位		-SEL, -MON, VREF 信号	
12	+Vcc	AO	辅助电压输出 (Ref: DGND)	1113V	I _{Max} = 20mA 短路保护对 DGND	
13	REM-SB	DI	输出关闭	关 = LOW, U _{Low} <1V 开 = HIGH, U _{High} > 4V 开 = OPEN	电压范围 = 030V 输出 5V 时,I _{Max} = +1mA 发送:开集电极对 DGND	
14	OVP	DO	过压错误	OVP = HIGH, U _{High} > 4V 无 OVP = LOW, U _{Low} <1V	准开集电极上拉至 Vcc ⁽² 输出 5V 时,电流最大 +1mA	
15	CV	DO	指示电压调整启用	CV = LOW, U _{Low} <1V CC = HIGH, U _{High} >4V	U _{CE} = 0.3V 时,I _{Max} = -10mA U _{Max} = 030V 短路保护对 DGND	

(1 AI = 模拟输入, AO =模拟输出, DI = 数字输入, DO = 数字输出, POT =电位 ⁽² 内控 Vcc 约为14.3V

⁽³仅针对1kW以上型号

《 仅有对1600以上至 5

⁽⁴ Power fail-电源故障 = PFC或输入端出现故障(仅自6.01固件版本后的才会报告)



CN



11. 其它

11.1 终端系统总线的功能

带8个引脚的System Bus端子位于产品后端,用来连接远程感测线或串联或并联多台产品。 各引脚分布说明:

- 1: 感测 +
- 2: 感测 -
- 3: 主机输出电流
- 4: 主机输出电压
- 5: 辅机输入电流
- 6:辅机输入电压
- 7:共享总线
- 1. 共子总线

8:地

<u> 1</u> 注意!

3-8引脚的功能如下面段落描述,仅对输出功率为**1000W**以上的产品才有用。

11.1.1 主从模式下的串联

串联时,建议只针对具有相同输出电流的产品,否则额定输出 电流最低的产品将定义为系统的最大电流。

一台设备总是下一台的主机,然后这个下一台成为辅机和再下 一台的主机,如此类推。连接两台以上产品时,建议将某一台 作为主机,其它为辅机。辅机由主机通过**System Bus**端字的 辅机输入引脚**3**和4来控制。可同时控制其电压和电流,也可分 开控制。

图8为连线举例。由主机提供电压和电流。如果只控制电压或电流其中一个,那另外一个的设定值应设为100%。

要远程控制整个系统,经模拟或数字接口控制主机即可。读出 实际值时,电流监控值会代表整个系统的电流,但是电压监控 值仅代表主机的输出电压。若想获得实际读数,可将串联(只 有当所有产品为同型号时适用)在一起的多台产品的实际电压 相乘,或者分开读出它们。



主机必须总是那台最低电压的产品!



1 注意!

若需将其中一个直流输出端接地,鉴于安全考虑,建议将输出 端接到最低电压上,即: 主机的负极(-)输出端。

鉴于安全和隔离的原因,需考虑下面一些限制和规则:

- 串联时任何一台产品的负直流输出端对地(PE)的电压不可上 升到 >300V的电位!
- 共享总线端不可连线!
- 串联中各产品模拟接口的地(AGND, DGND)不可相互连接!
- 远程感测端不可连线!

举例:额定电压为360V的两台同型号产品,比如:PSI 8360-10 DT。按计算,它们串联后的总电压可能高达720V。鉴于产 品负输出端的电位,第二台产品的负直流端电压可能会上升到 360V。这是绝对不允许的!所以必须将较低电位的产品限制到 某一最大值。下图阐述了最后形成的总电压将为660V。



11.1.2 共享总线模式下的并联

注意: 该操作仅针对额定功率为以上的产品!

🎦 注意!

只有相同型号(输出电压和电流相同)的产品才可执行操作 模式。

CN

若想增加输出电流,可通过共享总线的连接,并联两台或更多 同型号的产品。

需要进行下列连接:将所有产品的(+)直流输出极相互连接。所 有产品**System Bus**端子的7(共享总线)和8(地)引脚并联 连接。如果还需远程感测,则将所有感测+和感测-的输入脚并 联后与负载连接。也可见图9为连线举例。

重点:在此连接下,最小输出电压的产品决定整个系统的输出 电压。意思是,每一台机根据其调整数值,都可控。故建议选 择一台机来控制整个系统,并将其它产品的设定值调到最大。

🚺 提示

若有一台产品因过热(OT)或过压(OVP)而出现故障或不工作, 整个系统都不会提供功率输出,直至故障被清除才回复。

远要远程控制整个系统,经模拟或数字接口控制主机即可。读 出实际值时,电压监控值会代表整个系统的电压,但是电流监 控值仅代表主机的输出电流。若想获得实际读数,可将并联 (只有具有相同输出电流的产品适用)在一起的多台产品的实 际电流相乘,或者分开读出它们。



11.2 连网

下图描述了多台产品在数控状态下以星形(USB, RS232)或车形(CAN, GPIB)配置的连网举例。

适用总线系统和接口的限制和技术规格。

通过**USB**,一台电脑可控制多达30台产品,且需使用带特制电源的USB集线器。这也基本适用于RS232。区别在于操作和线长。

通过**CAN**,每个地址段上的多达30台电源,可容入新的或现 有的CAN总线系统。它们由产品节点和RID(见"8.产品设 置")组成。

通过**GPIB**,每一条总线限制最多15台从机产品。一台电脑上可 安装多台主机,这样能增加可编址单元数。



图10. 通过USB或RS232连网

12. 其它附件和选项功能

12.1 附件和选项

有下列附件可供:

a) USB-转−模拟接口控制器 UTA12

经USB(电脑这边)和产品内部模拟接口可远程控制。

b) 数字接口卡

还配USB, RS232, CAN, GPIB/IEEE (仅SCPI) 或以太网/ LAN (仅SCPI)或Profibus用可插拔式数字接口卡。接口卡详情 请看接口卡说明书。

C

有下列选项功能可供:

a) High Speed Ramping-高速跃变

通过减少输出电容容量来增加输出电压的动态。必须指出的是 其它相关输出值也会增加,如纹波!这是个永久性更改,不可 更改回来。

12.2 固件更新

只有当产品出现错误行为或者应用新功能时才需进行产品固件 更新。

要更新一台产品固件,需要用到某一数字接口卡,新的固件文档,称作"更新工具"的Windows软件,也可从网站上下载。

下列这些接口卡才能用于固件更新:

- IF-U1 (USB)
- IF-R1 (RS232)
- IF-E1 (USB端口)
- IF-PB1 (USB端口)

如果手上没有一张上述接口卡,则不可更新。请立即联系您的 产品销售方寻求解决方案。

产品对应的更新工具和固件文档可从产品制造商网站获取,或 者发邮件索取。更新工具将会指导用户整个半自动更新过程。



PS 8000 DT 系列 产品说明书 E

General

About

Elektro-Automatik GmbH & Co. KG

Helmholtzstrasse 31-33

41747 Viersen

Germany

Phone: +49 2162 / 37850

Fax: +49 2162 / 16230

Web: www.elektroautomatik.de

Mail: ea1974@elektroautomatik.de

© Elektro-Automatik

Reprint, duplication or partly, wrong use of this user instruction manual are prohibited and might be followed by legal consequences.

🛕 Danger to life!

Hazardous voltage

The output voltage of some models can rise up to hazardous levels of $>60V_{\text{DC}}!$

All live parts have to be covered. All actions at the output terminals have to be done while the unit is switched off from the mains (mains switch OFF) and may only be executed by personnel which is instructed about the hazards of electrical current. Any connection between the load and the unit (at the output terminals) have to be scoop-proof. Applications connected to the power output must be configured and fused in a way that prevents the use of these to cause a damage or worse to the unit by overload or malfunction.

1 Caution!

The DC output can still have hazardous voltage for a certain time after the output or the device has been switched off!

Keep in mind:

- Only operate the device at a mains voltage as stipulated on the type plate
- Never insert mechanical parts, especially from metal, through the air ventilation slots
- Avoid any use of liquids of any kind in the proximity of the device, they might get into it
- Do not connect voltage sources to the device which are able to generate voltages higher than the nominal voltage of the device
- In order to equip interface cards into the slot at the rear, the common ESD provisions have to be followed
- The interface card may only be plugged and unplugged while the unit is completely switched off (mains switch OFF)
- Aging of the device, as well heavy use may result in unpredictable behaviour of control elements like pushbuttons and rotary knobs.
- Do not connect external voltage sources with reversed polarity to the DC output! The device will be damaged.
- Avoid connecting external voltage sources to the DC output, especially those who can generate voltages higher than specified for the device!

Table of contents

	Page
1. Introduction	25
2. Technical specifications	25
2.1 Control panel and display	25
2.2 Technical specifications	26
3. Device description	28
3.1 Views	28
3.2 Legend	29
3.3 Scope of delivery	29
4. General	29
4.1 Prologue / Warning	29
4.2 Cooling	29
4.3 Maintenance / repair	
5. Installation	29
5.1 VISUAI CRECK	
5.2 Mains connection	29
5.5 DC output terminal	29
5.5 Interface card slot	29 29
6 Handling	20 20
6.1 The display	
6.2 Pushbuttons on the control panel	
6.2.1 Pushbutton Preset Voltage	
6.2.2 Pushbutton Preset UVL / OVP	
6.2.3 Pushbutton Preset Power	31
6.2.4 Pushbutton Preset Current	31
6.2.5 Pushbutton Memory Select M1-M5	32
6.2.6 Pushbutton Memory Start / Memory Save >3s	32
6.2.7 Pushbutton Local	32
6.2.8 Pushbutton Lock / Unlock	32
6.2.9 Pushbutton Output On / Output Off	
6.3 Other control elements	
6.3.1 Rotary knops	
0.4 Aujusting set values	
7. Device characteristics	
7.1 Switching of by power switch	
7.2 Switching on by power switch	
7.4 Overvoltage alarms	
7.5 Overtemperature alarms	
7.6 Voltage, current and power regulation	
7.7 Remote sense operation	
7.8 Mains undervoltage or overvoltage	35
7.9 Connecting different types of loads	35
8. Device setup	35
9. Digital interface cards	36
10 Analogue interface	37
10.1 General	
10.2 Application examples.	
10.3 Pin specification	
11. Other applications	40
11.1 Functions of terminal System Bus	40
11.1.1 Series connection in Master-Slave mode	40
11.1.2 Parallel connection	41
11.2 Networking	42
12. Miscellaneous	42
12.1 Accessories and options	42
12.2 Firmware update	42



EN

1. Introduction

The laboratory power supplies of the series PS 8000 DT are ideally suited for school, laboratory and workshop use because of their desktop case.

Apart from standard functions of power supplies the user can define and recall 5 different presets of set values or make use of the integrated analogue interface, that can handle the common voltage ranges of 0...5V or 0...10V. This offers a way of easily monitoring the device as well as total remote control.

The optionally available, digital interface cards provide an even wider spectrum of control and monitoring functions by means of a PC. Models from 1000W feature an adjustable power regulation circuit, as well as a "System Bus" terminal which enables series connection as master-slave or parallel connection with share bus.

The integration into existent systems is done very comfortably by using an interface card, while there is no need to configure the card at all or with only a few settings.

Via the analogue interface, a power supply can als be operated in connection to other power supply units, controlling these via the interface. Or they can be controlled and monitored by an external control system, like a PLC.

The devices are microprocessor-controlled and thus delivers fast and accurate measurement and indication of actual values.

The main functions at a glance:

- Set voltage and current, each with 0...100%
- Adjustable overvoltage threshold 0...110% U_{Nom}
- Adjustable power 0...100% (models from 1kW)
- Pluggable, digital interface cards (CAN, USB, RS232, IEEE/ GPIB, Ethernet/LAN, Profibus)
- Analogue interface for external control and monitoring with 0...5V or 0...10V (selectable) for 0...100%
- Power ratings of 320W, 640W, 1000W and 1500W
- Temperature controlled fan
- Status indication (OT, OVP, CC, CV, CP)
- · 5 selectable memory sets
- Master-Slave operation for series connection (from 1kW)
- Share-Bus for parallel operation (models from 1kW)
- Vector[™] compatible CAN system
- Free Windows software
- LabView[™] VIs

2. Technical specifications

2.1 Control panel and display

Туре

Display:	Dot matrix display 202 x 32 dots, seperated into three areas
Knobs:	2 rotary knobs, 9+2 pushbuttons

Display formats

The nominal values define the maximum adjustable range.

Actual values of voltage and current are displayed simultaneously, the set values of the overvoltage threshold, the undervoltage limit, voltage, current and power (models from 1kW) are displayed seperately.

Display of voltage values

Resolution:	4 digits
Formats:	0.00V99.99V
	0.0V999.9V

Display of current values

Resolution:	4 digits
Formats:	0.000A9.999A
	0.00A99.99A

Display of power values (models from 1kW)

Resolution:	4 digits
Formats:	0.000kW9.999kW

2.2 Technical specifications

	PS 8016-20 DT	PS 8032-10 DT	PS 8065-05 DT	PS 8032-20 DT	PS 8065-10 DT
Mains input					
Input voltage	90264V AC	90264V AC	90264V AC	90264V AC	90264V AC
Input voltage with derating	-	-	-	-	-
Input current at 230V	max. 1.8A	max. 1.8A	max. 1.8A	max. 3.2A	max. 3.4A
Input current at 100V	max. 3.8A	max. 3.8A	max. 3.8A	max. 7.5A	max. 7.5A
Input frequency	4565Hz	4565Hz	4565Hz	4565Hz	4565Hz
Input fuse	T 8A	T 8A	T 8A	T 8A	T 8A
Power factor	> 0.99	> 0.99	> 0.99	> 0.99	> 0.99
Output - Voltage					
Nominal voltage U _{Nom}	16V	32V	65V	32V	65V
Adjustable range	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}
Stability at mains fluctuation ±10% ΔU IN	< 0.02%	< 0.02%	< 0.02%	< 0.02%	< 0.02%
Stability at 1090% load	< 0.05%	< 0.05%	< 0.05%	< 0.05%	< 0.05%
Ripple LF BWL 20MHz	< 4mV RMS	< 10mV RMS	< 20mV RMS	< 8mV RMS	< 10mV RMS
Ripple HF BWL 20MHz	< 40mV P-P	< 100mV P-P	< 150mV P-P	< 100mV P-P	< 150mV P-P
Accuracy*	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%
Resolution of display	10mV	10mV	10mV	10mV	10mV
Remote sense compensation	max. 2V	max. 2V	max. 2V	max. 2V	max. 2V
Overvoltage protection	0 17.6\/	0 35 2\/	0 71 5\/	0 35 21/	0 71.51/
threshold (adjustable)	017.00	055.2 V	071.50	055.2V	071.50
Output - Current					
Nominal current I _{Nom}	20A	10A	5A	20A	10A
Adjustable range	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}
Stability at mains fluctuation $\pm 10\% \Delta U_{IN}$	< 0.05%	< 0.05%	< 0.05%	< 0.05%	< 0.05%
Stability at 0…100% ∆U _{OUT}	< 0.15%	< 0.15%	< 0.15%	< 0.15%	< 0.15%
Ripple LF BWL 20MHz	< 10mA RMS	< 7mA RMS	< 3mA RMS	< 10mA RMS	< 3mA RMS
Ripple HF BWL 20MHz	< 60mA P-P	< 35mA P-P	< 12mA P-P	< 65mA P-P	< 25mA P-P
Accuracy*	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%
Resolution of display	10mA	10mA	1mA	10mA	10mA
Transient recovery time 1090% load	< 2ms	< 2ms	< 2ms	< 2ms	< 2ms
Output - Power					
Nominal power P _{Nom}	320W	320W	325W	640W	650W
Nominal power at derating	-	-	-	-	-
Adjustable range	-	-	-	-	-
Accuracy*	-	-	-	-	-
Resolution of adjustment	-	-	-	-	-
Efficiency	≤ 90.5%	≤ 89%	≤ 93%	≤ 90.5%	≤ 91%
Miscellaneous					
Cooling	by fan	by fan	by fan	by fan	by fan
Ambient temperature	050°C	050°C	050°C	050°C	050°C
Storage temperature	-2070°C	-2070°C	-2070°C	-2070°C	-2070°C
Humidity rel.	< 80%	< 80%	< 80%	< 80%	< 80%
Dimensions (WxHxD)	330x118x308mm	330x118x308mm	330x118x308mm	330x118x308mm	330x118x308mm
Weight	6,5kg	6,5kg	6,5kg	6,5kg	6,5kg
Sharebus for parallel connection	no	no	no	no	no
Article number	09200130	09200131	09200132	09200133	09200134
Series connection		possible	, up to max. 600V tota	l voltage	
Parallel connection	possible, max. 30 units, models from 1000W via Share bus				
Humidity			<80%		
Isolation		Input to outpu	t: 2500V, Output to en	closure: 500V	
Safety	EN 60950				
EMC standards		EN	61326, EN 55022 Clas	SS B	
Overvoltage class			Class II		
Protection class			Class I		
Analogue programming					
Voltage range		0	5V or 010V (selecta	ble)	
Accuracy set/actual values			≤ 0.2%		
Input impedance	approx. 53kΩ				

* Related to the nominal value, the accuracy defines the maximum allowed deviation between set value and actual value.

Example: a 65V model has min. 0.2% voltage accuracy. This is 130mV. When setting a voltage of 5V and with an allowed maximum deviation of 130mV, the resulting actual value could be between 4.87V and 5.13V.



EN

	PS 8160-04 DT	PS 8080-40 DT	PS 8360-10 DT	PS 8080-60 DT	PS 8360-15 DT
Mains input					
Input voltage	90264V AC	90264V AC	90264V AC	90264V AC	90264V AC
Input voltage with derating	-	-	-	90150V	90150V
Input current at 230V	max. 3.2A	max. 4.8A	max. 7.5A	max. 7.5A	max. 7.5A
Input current at 100V	max. 7.5A	max. 11.4A	max. 11.4A	max. 11.4A	max. 11.4A
Input frequency	4565Hz	4565Hz	4565Hz	4565Hz	4565Hz
Input fuse	T 8A	T 16A	T 16A	T 16A	T 16A
Power factor	> 0.99	> 0.99	> 0.99	> 0.99	> 0.99
Output - Voltage					
Nominal voltage U _{Nom}	160V	80V	360V	80V	360V
Adjustable range	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}	0VU _{Nom}
Stability at mains fluctuation $\pm 10\% \Delta U_{IN}$	< 0.02%	< 0.02%	< 0.02%	< 0.02%	< 0.02%
Stability at 1090% load	< 0.05%	< 0.05%	< 0.05%	< 0.05%	< 0.05%
Ripple LF BWL 20MHz	< 20mV RMS	< 4mV RMS	< 11mV RMS	< 4mV RMS	< 8mV RMS
Ripple HF BWI 20MHz	< 120mV P-P	< 10mV P-P	< 30mV P-P	< 10mV P-P	< 50mV P-P
Accuracy*	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%
Resolution of display	100mV	10mV	100mV	10mV	100mV
Remote sense compensation	max. 2V	max. 2.5V	max. 8V	max. 2.5V	max. 8V
Overvoltage protection	0.4701/		0.0001/		0.0001/
threshold (adjustable)	0176V	088V	0396V	088V	0396V
Output - Current					
Nominal current I _{Nom}	4A	40A	10A	60A	15A
Adjustable range	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}	0A…I _{Nom}
Stability at mains fluctuation ±10% $\Delta U_{\text{ IN}}$	< 0.05%	< 0.05%	< 0.05%	< 0.05%	< 0.05%
Stability at 0…100% ∆U _{OUT}	< 0.15%	< 0.15%	< 0.15%	< 0.15%	< 0.15%
Ripple LF BWL 20MHz	< 1mA RMS	< 7mA RMS	< 0.45mA RMS	< 7mA RMS	< 0.45mA RMS
Ripple HF BWL 20MHz	< 3mA P-P	< 19mA P-P	< 1mA P-P	< 19mA P-P	< 1mA P-P
Accuracy*	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%	≤ 0.2%
Resolution of display	1mA	10mA	10mA	10mA	10mA
Transient recovery time 1090% load	< 2ms	< 2ms	< 2ms	< 2ms	< 2ms
Output - Power					
Nominal power P _{Nom}	640W	1000W	1000W	1500W	1500W
Nominal power at derating	-	-	-	1000W	1000W
Adjustable range	-	0P _{Nom}	0P _{Nom}	0P _{Nom}	0P _{Nom}
Accuracy*	-	≤ 1%	≤ 1%	≤ 1%	≤ 1%
Resolution of adjustment	-	1W	1W	1W	1W
Efficiency	≤ 92%	≤ 93%	≤ 92%	≤ 93%	≤ 93%
Miscellaneous					
Cooling	by fan	by fan	by fan	by fan	by fan
Ambient temperature	050°C	050°C	050°C	050°C	050°C
Storage temperature	-2070°C	-2070°C	-2070°C	-2070°C	-2070°C
Humidity rel.	< 80%	< 80%	< 80%	< 80%	< 80%
Dimensions (WxHxD)	330x118x308mm	330x118x388mm	330x118x388mm	330x118x388mm	330x118x388mm
Weight	6,5kg	8,5kg	8,5kg	8,5kg	8,5kg
Sharebus for parallel connection	no	yes	yes	yes	yes
Article number	09200135	09200136	09200138	09200137	09200139
Series connection		possible	, up to max. 600V tota	l voltage	
Parallel connection		possible, max. 30	units, models from 100	00W via Share bus	
Humidity		-	<80%		
Isolation		Input to output	t: 2500V, Output to en	closure: 500V	
Safety	FN 60950				
EMC standards		EN	61326. EN 55022 Clas	s B	
Protection class			Class I		
			010001		
Voltage range		0	5 or 0 10 (selects	hle)	
	+	0	< 0.2%	,	
			= 0.2 /0 approx 53k0		
input impedance	1		appion. 00K12		

* Related to the nominal value, the accuracy defines the maximum allowed deviation between set value and actual value.

Example: a 65V model has min. 0.2% voltage accuracy. This is 130mV. When setting a voltage of 5V and with an allowed maximum deviation of 130mV, the resulting actual value could be between 4.87V and 5.13V.

E

FN

About the device	EN
3. Device description	
3.1 Views	
POWER SUPPLY DS 8050-60 DT 080V / 060A Voltage CV Current Voltage Current Voltage VUL/OVP Power	Memory Select Momory Start Memory Start Memory Save >38 • Remote • Local • Lock • Unlock • Output Off
Sigure 1. Frent view	>
Figure 1. Front view	
<figure>SymmetryS</figure>	Image: state stat
max. 32A max. 63A max. 63A max	1500W)
28 Date: 02-09-2012	Instruction Manual PS 8000 DT Series

3.2 Legend

- A Power switch
- B Control panel
- C Power output
- D Analogue interface, 15pole, female
- E Slot for digital extension cards
- F System Bus
- G Fan
- H Input fuse (for value see "2. Technical specifications")
- J Power input socket, 3pole, IEC 60320

3.3 Scope of delivery

- 1 x Power supply unit
- 1 x Printed user manual
- 1 x Mains cord
- 1 x Plug for System Bus

4. General

4.1 Prologue / Warning

This user instruction manual and the device are intended to be used by users who know about the principle of a power supply. The handling of the device should not be left to persons who are unaware of the basic terms of electrotechnology, because these are not described in this manual. Inappropriate handling and non-observance to the safety instructions may lead to a damage of the device or loss of warranty!

4.2 Cooling

The air inlets in the bottom side and the air outlets on the rear have to be kept clean to ensure proper cooling. Take care of at least 10cm distance at the rear to any surrounding objects in order to guarantee unimpeded air flow.

4.3 Maintenance / repair

When opening the unit or removing parts from the inside with tools there is risk of electric shock by dangerous voltages. Open the unit only at your own risk and disconnect it from the mains before.

Any servicing or repair may only be carried out by trained personnel, which is instructed about the hazards of electrical current.

5. Installation

5.1 Visual check

After receipt, the unit has to be checked for signs of physical damage. If any damage is found, the unit may not be operated. Also contact your dealer immediately.

5.2 Mains connection

The unit is grounded via the mains cord. Thus the unit may only be operated at a mains socket with grounding contact. This must not be interrupted by an extension cable without ground conductor!

The unit is fused with a 5 x 20mm safety fuse (for value see technical specs table), which is accessible on the rear.

5.3 DC output terminal

The power output is located on the front of the device.

The output is **not** fused! In order to avoid damage to the load application, always take care for the nominal values of the load.

The cross section of the load leads depends on several conditions, like the output current, the lead length and the ambient temperature.

Up to 1.5m lead length we recommend to use:

up to 10A :	0,75mm²	up to 15A :	1,5mm²
up to 30A :	4mm ²	up to 40A :	6mm²
up to 60A :	16mm ²		

per cable (flexible wire).

The outputs "+" and "-" are not grounded, so that **one** of them may be grounded if necessary.

Attention!

The 4mm socket on the DC output terminals of the 1000W and 1500W models is only specified up to 32A!

Attention!

When grounding one of the output poles always check if one of the poles of the load (eg. electronic load) is also grounded. This could result in a short-circuit!

1 Attention!

Watch the potential shift of the output poles when using series connection! Grounding is hereby only recommended at the pole with the lowest potential against ground.

5.4 Terminal "Sense" (Remote sense)

In order to compensate the voltage drop along the load leads (max. 1V per lead), the power supply can "sense" the voltage at the load instead at the output. It will regulate the output voltage so that the desired voltage is provided to the load.

The connection for remote sense is done at the terminal **"Sy-stem Bus**" on the rear side, pins 1 and 2. See section 3.1.

Attention!

(+) Sense must only be connected to (+) at the load application and (–) Sense must only be connected to (–)! Else both systems can take damage.

For additional information also see section 7.7.

5.5 Interface card slot

The unit can be equipped with an optional interface card. The slot to insert the card is located at the rear side. Further information about the interface cards can be found in section "9. Digital interface cards".



Figure 4. Control panel

6. Handling

6.1 The display

Figure 4 depicts an overview of the dot matrix display and the control panel. During normal operation, the display areas show the actual values of voltage (left side) and current (right side) and device status (middle). In preset mode, the left display area shows the set values of voltage (Preset Voltage), of the overvoltage protection threshold (Preset OVP) or the undervoltage limit (Preset UVL). The right display area shows the set values of current (Preset Current) or power (Preset Power, only models from 1kW). In the device setup the display is used to show adjustable parameters and settings.

The status area in the middle can show following status:

- CV Constant voltage regulation (only when output is "on")
- OT Overtemperature error
- **OVP** Overvoltage error
- CC Constant current regulation (only when output is "on")
- CP Constant power regulation (only when output is "on")
- Fine Fine adjustment for both rotary knobs active
- PF Power fail (input voltage failure, from firmware 6)

Legend:

- (1) Left display area: Actual voltage or set value U, UVL, OVP
- (2) Status area: status display like CC, CV etc.
- (3) Right display area: Actual current or set value I, P
- (4) Control buttons: Setting the device condition etc.
- (5) Rotary knob right: Set value adjustment of I and P, as well as settings in the device setup
- (6) Preset buttons: Switching to set value display
- (7) Rotary knob left: Set value adjustment of U, UVL, OVP, as well as parameters in the device setup

6.2 Pushbuttons on the control panel

6.2.1 Pushbutton Preset Voltage



During normal operation, this button is used to switch the display from actual to preset value of the output voltage (i.e. preset mode). The left display area will then show like this:



In preset mode, the left rotary knob (**Voltage / UVL / OVP**) is used to adjust the voltage set value the same way as during normal operation. The adjusted value is instantly transferred to the output.

🚺 Note

The set value adjustment can be limited by the undervoltage threshold UVL. Also see 6.2.2.

A second push leaves the preset mode instantly or it will end automatically, if no preset button is pushed or any set value is altered within 5 seconds.

During remote control by analogue or digital interface, the preset mode can be used to check the voltage set value that is given from remote.

The button might be locked by the condition **LOCK.** See 6.2.8.

In memory selection mode the button is also used to switch to the voltage set value of the selected memory set, but in this mode the set value is not transferred to the output. The left display area will then show like this:



EA



6.2.2 Pushbutton Preset UVL / OVP



During normal operation, this button is used to switch the display from actual voltage to the set value of the undervoltage limit (one push) or the overvoltage protection threshold (two pushes). The left display area will then show like this:



The undervoltage limit (UVL) is only an adjustment limit for the output voltage value. It means, if UVL is set to anything above 0, the voltage set value can only be adjusted down to the UVL value. In the same way, the UVL value can only be adjusted up to the voltage set value.

The left rotary knob (Voltage / UVL / OVP) is used to adjust the UVL value from $0...U_{Set}$.

A second push of the button changes to overvoltage protection threshold preset (OVP). This value can always be adjusted from $0...110\% U_{Nom}$.

A third push leaves the preset mode instantly or it ends automatically, if no preset button is pushed or any set value is altered within 5 seconds.

During remote control by digital interface, the preset mode can be used to check the OVP set value that is given from remote.

The button might be locked by the condition **LOCK.** See 6.2.8.

In memory selection mode the button is also used to switch to the UVL or OVP value of the selected memory set, but in this mode the values <u>are not</u> active yet. The left display area will then show like this:



6.2.3 Pushbutton Preset Power



During normal operation, this button is used to switch the display from actual current to preset value of the output power (i.e. preset mode).

Only models from **1kW** feature an adjustable power regulation and will show like this on the right display area:



In preset mode, the right rotary knob (**Current / Power**) is used to adjust the power set value from $0...100\% P_{Nom}$. The adjusted value is instantly transferred to the output.

A second push leaves the preset mode instantly or it ends automatically, if no preset button is pushed or any set value is altered within 5 seconds.

The button might be locked by the condition LOCK. See 6.2.8.

During remote control by analogue or digital interface, the preset mode can be used to check the power set value that is given from remote.

In memory selection mode the button is also used to switch to the power set value (only models from 1kW) of the selected memory set, but in this mode the set value <u>is not</u> transferred to the output. The right display area will then show like this:

Μ	e m	ory	1:	Ρ	
1	. 2 0	0 k V	V		

6.2.4 Pushbutton Preset Current

Preset	Preset	Preset	Preset
Voltage	UVL /OVP	Power	Current

During normal operation, this button is used to switch the display from actual to preset value of the output current (i.e. preset mode).

The right display area will then show like this:

Preset	Current
45.60A	

In preset mode, the right rotary knob (**Current / Power**) is used to adjust the set value of current from 0...100% I_{Nom} the same way as in normal operation. The adjusted value is instantly transferred to the output.

A second push leaves the preset mode instantly or it ends automatically, if no preset button is pushed or any set value is altered within 5 seconds.

During remote control by analogue or digital interface, the preset mode can be used to check the current set value that is given from remote.

The button might be locked by the condition LOCK. See 6.2.8.

In memory selection mode the button is also used to switch to the current set value of the selected memory set, but in this mode the set value <u>is not</u> transferred to the output. The right display area will then show like this:



6.2.5

Memory Select M1 - M5

This button cycles through the 5 memory sets, each with set values for U, I and P, as well as UVL and OVP. From here, the selected memory set can be edited, stored or submitted. The button only works if the output is **off**. The memory mode and the selected memory set number are displayed like this:

Memory 1: U	Memory 1: I
12.00V	45.60A

Pushbutton Memory Select M1-M5

Following options of use:

a) Adjust values

Output off, short push of the button, the display changes to the first memory set, as displayed above.

Now the set values of U (left) and I (right) of the selected memory set can be adjusted. The other adjustable values can be accessed by pushing the corresponding preset buttons.

Further pushes will cycle through the memory sets up to number 5 and then exit memory mode.

The adjusted values remain as long the device is powered on, but are not submitted to the output set values **and are not saved yet! For saving see section 6.2.6.**

The button might be locked by the condition LOCK. See 6.2.8.

6.2.6 Pushbutton Memory Start / Memory Save >3s

		_
L.	 	-

Memory Start Memory Save >3s

This pushbutton is either used to submit the values of the selected memory set to the output or to save the memory set. The button only works if the output is **off**.

Following options of use:

b) Submit only

Output off, memory set is selected (1-5), button is pushed **shortly** --> the values of the memory set are submitted to the output and the memory mode exits. In order to use the new set values, the output is switched on as usual by button **Output On** or by remote control.



Submitting the values does not save them!

c) Save only

Output off, select memory set(s), adjust the values as desired, then push the button >3s --> all memory sets are saved, but none is submitted to the output. The output remains off, the memory mode exits after saving.

The memory sets can also be defined by remote control and corresponding commands using a digital interface (except GPIB). They're stored immediately.

The button might be locked by the condition **LOCK.** See 6.2.8.

6.2.7 Pushbutton Local



This pushbutton activates or deactivate the LOCAL mode. In LOCAL mode, no remote control of the device is possible. LOCAL mode is indicated by LED "Local". As long as LOCAL is not active, the LED "Remote" indicates an active remote control by analogue or digital interface.

The button might be locked by the condition LOCK. See 6.2.8.

🚺 Note

Activation of LOCAL mode results in immediate return from remote control (analogue or digital) and locks the device against further attempts to control it remotely, until LOCAL is cleared again.

] Note

LOCAL condition is only temporary and will not be stored when switching the device off.

6.2.8 Pushbutton Lock / Unlock



This pushbutton activates or deactivates the control panel lock. The LOCK mode locks all buttons, except the LOCK button itself, and the rotary knobs against unintended operation.

🚺 Note

Activation of the LOCK mode instantly exits any preset or memory mode, if currently active. The display will return to normal display of actual values.

🚺 Note

Since firmware 6.02, LOCK mode will be stored when the device is switched off and restored after power-on.

6.2.9 Pushbutton Output On / Output Off



This pushbutton is used to manually switch the power output on or off, as long as the device is not in remote control mode. The output condition is always indicated by the LEDs "Output On" or "Output Off". If the output is switched on, the device indicates the currently active regulation mode CC, CV or CP (only models from 1kW) in the status area in the middle of the display.

The button might be locked by the condition **LOCK.** See 6.2.8.

Switching the output on may be inhibited by pin 13 (REM-SB) of the analogue interface. See section "10. Analogue interface".

The button also acknowledges the errors. See sections 7.4 and 7.5 fore more information.





6.3 Other control elements

6.3.1 Rotary knobs

Both of the rotary knobs have a push button function. Pushing any or both of these will effect following:

a) Fine adjustment mode (Fine)

A short push of any of both buttons activates or deactivates the fine adjustment mode for manual operation. If "Fine" is active, all set values, thresholds and limits can be adjusted in smallest possible steps, no matter what mode is currently active (preset, memory ect.). It is indicated by the status text "Fine" in the status area. Also see section "6.4 Adjusting set values" below.

b) Device setup

Pushing **both** buttons together for >3s while the output is **off** changes to device setup. It is left the same way.

6.4 Adjusting set values

1. In manual operation

During manual operation, both rotary knobs are used to continuously adjust the set values of voltage and current from 0% to 100% nominal value in predefined steps (see table). In order to set the values for OVP and UVL the button **Preset UVL**/ **OVP** has to pushed once or twice. In order to set the power set value (models from 1kW only) the button **Preset Power** has to be pushed.

Note

The OVP value can be lower than the voltage set value and will cause an OV error as soon as the output is switched on and the actual voltage reaches the OVP threshold!

Setting values manually can be done in fine or coarse steps, whereas coarse is default. **Fine** is required to be activated by the one of rotary knob pushbuttons and has a step width of 1.

For **coarse** adjustment, following step widths apply in dependency of the nominal values (also refer to technical specs):

Voltage / OVP / UVL		Current			
Nom. val.	Coarse	Fine	Nom. val.	Coarse	Fine
16V	0.1V	0.01V	4A	0.05A	0.001A
32V	0.2V	0.01V	5A	0.05A	0.001A
65V	0.5V	0.01V	10A	0,1A	0.01A
80V	0.5V	0.01V	15A	0.1A	0.01A
160V	1V	0.1V	20A	0.2A	0.01A
360V	2V	0.1V	40A	0.5A	0.01A
			60A	0.5A	0.01A

Power			
Nominal value	Coarse	Fine	
1000W	0.01kW	0.001kW	
1500W	0.01kW	0.001kW	
		0.000	

Note

The resolution of the set value adjustment in some cases is, depending on the nominal values, higher than the one of the output voltage. Thus it can happen that the output voltage only changes every 2 or 3 steps.

2. In remote control via analogue interface

See section "10. Analogue interface".

3. In remote control via digital interface card

See section "9. Digital interface cards".

7. Device characteristics

7.1 Switching on by power switch

The power switch is located at the front. After switching on, the device will show some information in the display: manufacturer's name, address and logo, device type and firmware version. In the device setup (see section "8. Device setup") there is an option "AutoPwrOn" (auto power-on) that determines the output condition after the device is switched on. Default is "on" and means, that the set values of U, I, P, the values of OVP and UVL and the output condition are restored to what was present when the device was switched off the last time. In case the option is set to "off", the set values of U and I are set to 0, the set value of P to 100%, OVP to max., UVL to min. and the output is switched on after every start.

7.2 Switching off by power switch

Switching the device off by power switch is handled as mains blackout. The device will save the last set values and output condition. After a short time, power output and fans will be switched off and after a few seconds more, the device will be completely off.

7.3 Switching to remote control

a) <u>Analogue interface</u>: Pin "Remote" switches the device to remote control, if not inhibited by LOCAL mode or remote control by digital interface already being active. The set values pins VSEL, CSEL and PSEL (only required with models from 1kW), as well as REM-SB are then in command. The output condition and the set values which are put into the pins are immediately set. After return from remote control, the output will be switched off.

b) <u>Digital interface</u>: Switching to remote control is done by the corresponding command (here: object), if not inhibited by LOCAL mode or remote control via analogue interface already being active. It keeps output state and set values until altered. Leaving remote control automatically switches the output off.

7.4 Overvoltage alarms

An overvoltage alarm can occur due to an internal defect (output voltage rises uncontrolledly) or by a too high voltage from external. The overvoltage protection (OVP) will switch off the output and indicate the alarm on the display by the status text "OV" and on the pin "OVP" of the analogue interface.

If the cause of the overvoltage is removed, the alarm has to be acknowledged first. In manual operation, it is done by pushing button **Output On/Off**, in analogue remote control with pin "REM-SB" and in digital remote control by the corresponding command. Then status text "OV" and OVP signal will disappear. If the alarm is still present, the output will not be switched on.

OV alarms are recorded into the internal alarm buffer. This buffer can be read out via a digital interface, except those using SCPI language. Reading the buffer will also acknowledge.

] Note

The status of an OV alarm has priority over the status of an OT alarm and will overwrite the status text "OT" in case both alarms occur the same time and are not yet acknowledged.

7.5 Overtemperature alarms

As soon as an overtemperature (OT) alarm occurs by internal overheating, the output is switched off and the status text "OT" is indicated. Simultaneously, the LED "Output On" will flash, indicating that the output will automatically switch on again as soon as the device has cooled down. In case this is not wanted, the output can be switched off manually. Then the LED stops flashing and the output won't switch on automatically.

If the output is off after the device has cooled down, it can be switched on again by using button **Output On/Off** or pin "REM-SB" or the corresponding command. If the output is on, pushing button **Output On/Off** once or giving pin "REM-SB" a high-to-low toggle or using the corresponding command first acknowledges the alarm and then switches the output off.

OT alarms are recorded into the internal alarm buffer. This buffer can be read out via a digital interface (except those using SCPI language). Reading the buffer will also acknowledge.

🚺 Note

The status of an OT alarm has lower priority than an OV alarm and the status text "OT" will be overwritten by "OV" in case both alarms occur the same time and are not yet acknowledged.

7.6 Voltage, current and power regulation

The output voltage of the power supply and the resistance of the load determine the output current. If this current is lower than the current limitation set by the current set value, then the device is working in constant voltage (CV) regulation, indicated by the status text "CV".

If the output current is limited by the current set value or by the nominal current, the device will change to constant current (CC) regulation mode, indicated by the status text "CC".

Models from 1kW output power additionally feature an adjustable power limitation for $0...P_{Nom}$. It becomes active and overrides constant voltage or constant current regulation mode, if the product of actual current and actual voltage exceeds the adjusted power limitation or nominal power of the device. The power limitation primarily affects the output voltage. Because voltage, current and power limitation affect each other, various situations like these may occur:

Example 1: the device is in constant voltage regulation, then the power is limited down. As a result, the output voltage is decreased. A lower output voltage results in a lower output current. In case the resistance of the load is then decreased, the output current will rise again and the output voltage will sink further.

Example 2: the device is in constant current regulation, the output voltage is defined by the resistance of the load. Then the power is limited down. Output voltage and current are decreasing to values according to the formula P = U * I. If the current set value is then decreased, the output current would also decrease and thus the output voltage. The product of both values, the actual power, would sink below the previously set power limit and the device would change from constant power regulation (CP) to constant current regulation (CC).



7.7 Remote sense operation

Remote sense operation is used to compensate voltage drops along the leads between power supply and load. Because this compensation is limited to a certain level, it is recommended to match the cross section of the load leads to the output current and thus minimise the voltage drop.

The sense input is located on the rear, at terminal **System Bus**, where the sense leads are connected to the load with correct polarity. The power supply will detect the external sense automatically and compensate the output voltage by the actual voltage at the load instead of the output. The output voltage will be raised by the value of the voltage drop between power supply and load. For maximum compensation see technical specifications. Also see figure 5 below.

7.8 Mains undervoltage or overvoltage

The device features an rectification with active PFC and a wide range input. This means, it can be operated at input voltages of approx. 90V...264V. Input voltages outside this range are considered as blackout, respectively as complete switch-off and will store the last condition, as well as switch off the power output.

1 Attention!

Permanent input undervoltage or overvoltage must be avoided!

Note

Models with 1500W nominal power will derate the output power down to 1000W at input voltages below approx.150V.

7.9 Connecting different types of loads

Different types of loads, such as ohmic loads (lamp, resistor), electronic loads or inductive loads (motor) behave differently and can retroact to the power supply. For example, motors can induce a countervoltage which may cause the overvoltage protection of the power supply to shut off the output.

Electronic loads have regulator circuits for voltage, current and power that can counteract to the ones of the power supply and may result in increased output ripple or other, unwanted side effects. Ohmic loads are almost 100% neutral. It is recommended to consider the load situation when planning applications.

8. Device setup

The device setup is intended to adjust certain operation parameters. It can only be accessed while the output is off. Push both pushbuttons of the rotary knobs (also see section 6.3) simultaneously for longer than 2s. Leaving the setup and storage of the settings is done the same way. Three elementary settings are always available, see below. Other settings are only available if a digital interface card is equipped.

Elementary settings:

Parameter: AutoPwr0n		Default: on	
Settings: on,	off		

Meaning: "on" --> device restores the last output state and set values of last time the device was switched off or a blackout occured. The purpose is to make the unit automatically continue operation after a blackout.

"off" --> the output is switched on and the set values of U, UVL and I are set to 0%, P to 100% and OVP to 110%, everytime the unit is powered.

Parameter: RI	range	Default: 0-10
Settings: 0-5,	0-10	
Meaning: selec	ts the contro	ol voltage range to use with the

Meaning: selects the control voltage range to use with the analogue interface. Further details in section 10.

Parameter: Contrast	Default: 70

Settings: 50...100

Adjusts the contrast of the LCD display.

For **all** interface cards this setting applies:

Parameter: Device	node	Default: 1
Settings: 130		

Meaning: Selects the device's address (i.e. device node, term taken from the CAN terminology). When using the device on a bus system (CAN or GPIB), every device must have a unique address!

Following settings only with CAN interface IF-C1:

Parameter: Baud	Default: 100k				
Settings: 10k,25k,50k,	100k,	125k,	250k,	500k,	1M
Meaning: Selects the CAN	transmis	sion ba	ud rate		

Parameter: Base	ID	Default: 0×000
Settings: 0×000.	0x7FC	(02044)

Meaning: Defines the base ID (BAID) for the CAN ID system with three IDs (Vector compatible, dbc files). Three IDs are reserved for a device, based upon the adjusted base ID. Thus this values is only adjustable in steps of four. Display can be switched from decimal to hexadecimal by pushing any of the rotary knobs.

Only available, if ID Sys = Vector has been selected. See below at parameter ID Sys.



Instruction Manual PS 8000 DT Series

Parameter: Broad ID Default: 0×7FF Settings: 0x000...0x7FF (0...2047)

Meaning: Adjusts the broadcast ID (BCID) for the CAN ID system with three IDs (Vector compatible, dbc files). This extra ID is a fourth ID for the device which can be used for broadcast messages to multiple units on a bus. Purpose if this ID is to adjust it to the same value on all units that are targeted to be controlled simultaneously by set values or device conditions. Display can be switched from decimal to hexadecimal by pushing any of the rotary knobs.

Only available, if ID Sys = Vector has been selected. See below at parameter ID Sus.

Parameter: RID	Default: 🙆
Settings: 031	

Meaning: Selects the relocatable identifier segment (RID). Refer to CAN terminology or instruction manual of the IF-C1 CAN interface card for further information.

Parameter: Bus term

Settings: yes, no

Meaning: activates/deactives the bus termination resistor of the CAN interface card. This is required if the device is at the end of the bus.

Parameter:	ID	Sys	Default: Vec

Settings: Vector, normal

tor.

Default: yes

Meaning: Selects the CAN ID systems (IDSY). With "Normal", the former, old CAN ID system with two CAN IDs per unit is used, where the IDs are built from "Device node" (see above) and "RID" (see above). Also see the external user manual for the interface cards regarding the calculation scheme of the CAN IDs.

The other ID system, selected with "Uector", uses three CAN IDs per unit and it thus enables the use of so-called DBC files to implement the device into Vector company software. By selecting this ID system, two ID related settings (see above) become active, where the user adjusts a base ID that defines the three CAN IDs, plus a broadcast ID (if used).

Following settings only with RS232 interface IF-R1:

Parameter: Baud		Default: 57600		
Settings: 9600,	19200,	38400,	57600	

Meaning: Selects the serial transmission baudrate (in baud). Further parameters for the RS232 are not configurable, but defined as follows:

Parity = odd Stop bits = 1Data bits = 8 and have to be set to the same configuration at the PC.

Following settings only with Profibus interface IF-PB1:

Parameter: Profibus	Default: 1
Settings: 1-125	

Meaning: Defines the Profibus address of the device. This address is used apart from the device node to implement and access the unit on a field bus system.

9. Digital interface cards

The device supports following pluggable interface cards:

IF-U1 (USB)

IF-R1 (RS232) IF-C1 (CAN)

IF-G1 (GPIB/IEEE)

IF-E1 / IF-E1B (Ethernet/LAN + USB)

IF-PB1 (Profibus + USB)

The cards require only a little or no setup after insertion. The card specific settings are stored and kept, even if the card is replaced by one of different type. Thereby it is not necessary to configure the card settings everytime a card is inserted.

Details about the technical specs of the interface cards and the handling, as well as instructions to implement the device into a bus system or to control the device by means of a PC (LabView etc.) can be found in the user manual for the IF cards.

Attention!

Insertion or removal only if the device is completely switched off (power switch)!

About configuration of the interfaces see section "8. Device setup".

The digital interface cards allow to set voltage, current and power, as well as the OVP threshold and undervoltage limit UVL by means of a PC. When changing to remote control mode, the device keeps the last set values until they're altered. Hence it would be possible to control only voltage by sending arbitrary set values and the current set value would remain unaltered.

Set values given by the digital interface (except GPIB) are always percentage and correspond at 100% (hex: 0x6400), resp. at 110% (hex: 0x6E00) for the OVP threshold, to the nominal values of the device. Using GPIB, any value is given as real decimal value.

Furthermore, the digital interfaces allow to guery and set a lot of other features and values. For details refer to the user manual of the interface cards.



10. Analogue interface

10.1 General

The integrated, non-isolated, 15 pole analogue interface (AI) is located on the rear and offers following main features:

- · Remote control of output current and voltage
- Remote control of output power (only models from 1kW)
- Remote monitoring of status (OT, OVP, CC, CV)
- Remote monitoring of actual values
- · Remotely switching the output on/off

The analogue interface (short: AI) allows to remotely control current, voltage and power (models from 1kW) of the power supply, but always in combination. It means, that it's not possible to adjust voltage via the AI and the current with the rotary knob on the front at the same time, or vice versa. Models below 1kW output power don't require the power set value PSEL and thus it must not be given.

The OVP threshold can not be adjusted via the AI, so it's required to set it manually on the device before using the remote control. Switching to preset mode with the preset buttons shows the translated set values, that are put into the set value pins of the AI as voltages. In order to put in appropriate set values, the user can either use an external voltage source or the reference output voltage on pin 3.

The AI can be operated with the common 0...5V or 0...10V ranges, each corresponding to 0...100% nominal values. The desired control voltage range is selected in the device setup (see section "8. Device setup"). The reference voltage at output pin 3 is related to the chosen setting and will be either 5V or 10V.

Following applies:

0-5V: Reference voltage = 5V, 0...5V set value voltage correspond to 0...100% nominal value, 0...100% actual value correspond to 0...5V at the actual value outputs (CMON, VMON).

0-10V: Reference voltage = 10V, 0...10V set value voltage correspond to 0...100% nominal value, 0...100% actual value correspond to 0...10V at the actual value outputs (CMON, VMON).

Putting in set values that exceed the limit, for example >5V while the 0...5V range is selected, is intercepted by clipping the corresponding set value to 100%.

Usage instructions:

- Controlling the device with analogue voltages requires to switch it to remote control with pin "REMOTE" (5).
- Before connecting the application that is used to control the power supply, make sure to wire all leads correctly and check if the application is unable to put in voltages higher than specified (max. 12V).
- The input REM-SB (remote standby, pin 13) overrides the pushbutton Output On. It means, the output can not be switched on by the button if the pin defines the output state as "off" , except LOCAL mode is active. This mode locks all interface from access to the device. Also see "6.2.7 Pushbutton Local".
- The grounds of the analogue interface are related to minus output.

10.2 Application examples Pin overview



Never connect grounds of the analogue interface to minus (negative) output of an external control application (PLC, for example), if that control application is otherwise connected to the neative power supply output (ground loop). Load current may flow over the control leads and damage the device!



Figure 6



Figure 7

EA

Output off

Pin "REM-SB" is always operative and does not depend on the remote control mode. It can be used to switch off the output without extra means, except in LOCAL mode which only allows manual control for the device. Switching the output off is done by connecting the pin to ground (DGND) via a low-resistive contact like a switch, open collector transistor or relay.

Note

A digital output of, for example, a PLC may not be able to do this correctly, because it might not be low-resistive enough. Always check the technical specifications of your external control application.



Remote control of current and voltage

Two potentiometers between VREF and ground, sliders at the inputs VSEL and CSEL. The power supply can be controlled as with the rotary knobs on the front and can either operate as current or voltage source. In compliance with the max. 3mA for the VREF output, potentiometers with at least 10kOhm have to be used.

The power set value is here, for models with power regulation feature, tied to VREF and thus 100%.



Remote control with power

Similiar to the example above, but with adjustable power limit (only applicable for models with power adjustment).

FN





10.3 Pin specification

Pin	Name	Type ⁽¹	Description	Level	Electrical specification	
1	VSEL	AI	Set value: voltage	010V or 05V correspond to 0100% of U_{Nom}	Accuracy < 0,2%	
2	CSEL	AI	Set value: current	010V or 05V correspond to 0100% of I_{Nom}	Impedance R _i >100k	
3	VREF	AO	Reference voltage	10V or 5V	Accuracy < 0.2% at I _{Max} = +5mA Short-circuit-proof against AGND	
4	DGND	POT	Reference potential for digital control signals		For +Vcc, control and status signals	
5	REMOTE	DI	Toggle between internal or external control	External = LOW, U _{Low} <1V Internal = HIGH, U _{High} > 4V Internal = open	U range = 0 …30V I _{Max} = +1mA at 5V Sender: Open collector against DGND	
6	OT/PF	DO	Overtemperature error / Power fail error ⁽⁴	Error = HIGH, U _{High} > 4V no error = LOW, U _{Low} <1V	Quasi open collector with pull-up to Vcc ⁽² At 5V at the output there will be max.+1mA $I_{Max} = -10mA$ at $U_{CE} = 0.3V$ $U_{Max} = 030V$ Short-circuit-proof against DGND	
7	N.C.				Not connected	
8	PSEL ⁽³	AI	Set value: power	010V or 05V correspond to 0100% of P_{Nom}	Accuracy < 0.5% Impedance R _i >100k	
9	VMON	AO	Actual value: voltage	010V or 05V correspond to 0100% of U_{Nom}	Accuracy < 0.2% at I_{Max} = +2mA	
10	CMON	AO	Actual voltage: current	010V or 05V correspond to 0100% of I_{Nom}	Short-circuit-proof against AGND	
11	AGND	POT	Reference potential for analogue signals		For -SEL, -MON, VREF signals	
12	+Vcc	AO	Auxiliary voltage output (Ref: DGND)	1113V	I _{Max} = 20mA Short-circuit-proof against DGND	
13	REM-SB	DI	Output off	off = LOW, $U_{Low} < 1V$ on = HIGH, $U_{High} > 4V$ on = OPEN	U range = 030V I _{Max} = +1mA at 5V Sender: Open-Collector against DGND	
14	OVP	DO	Overvoltage error	$OV = HIGH, U_{High} > 4V$ no OV = LOW, U _{Low} <1V	Quasi open collector with pull-up to $Vcc^{(2)}$ At 5V at the output there will be max.+1mA	
15	CV	DO	Indication of voltage regulation active	$CV = LOW, U_{Low} < 1V$ $CC = HIGH, U_{High} > 4V$	$U_{Max} = -1000$ at $U_{CE} = 0.3V$ $U_{Max} = 030V$ Short-circuit-proof against DGND	

⁽¹ AI = Analogue input, AO = Analogue output, DI = Digital input, DO = Digital output, POT = Potential

⁽² Internal Vcc, approx. 14.3V

⁽³ Only with models from 1kW

⁽⁴ Power fail = input failure or PFC (reported only since firmware 6.01)

F١

11. Other applications

11.1 Functions of terminal System Bus

The 8pole terminal **System Bus** is located on the rear and is used to connect leads for remote sense or to wire multiple devices for series or parallel connection.

Pin assignment:

- 1 : Sense +
- 2 : Sense -
- 3 : Master output Current
- 4 : Master output Voltage
- 5 : Slave input Current
- 6 : Slave input Voltage
- 7 : Share Bus
- 8 : Ground

1 Attention!

The functions of pins 3-8 are only available with models from 1000W output power.

11.1.1 Series connection in Master-Slave mode

For a series connection, it is recommended to use only devices with identical output current, else the unit with the lowest nominal output current will define the maximum current of the system. One unit is always the master of the next unit, which becomes slave, and so on. When connecting more than two units, it is recommended to consider one certain unit as master and any other as slave. The slave(s) are controlled by the master via the slave input pins 3 and 4 of the terminal **System Bus**. Voltage and current can be controlled simultaneously, but also seperately.

For an example wiring see figure 8 below. Voltage and current are here given by the master. In case only one of both, voltage or current, is going to be controlled, the other set value should be set to 100%.

In order to control the whole system remotely, it is sufficient to control the master via its analogue or digital interface. When reading actual values, the current monitor value will represent the overall system current, but the voltage monitor only the output voltage of the master. In order to get accurate readings, either the actual voltage is multiplied by the number of unit in the series connection (only applicable if all are same type) or all units will have to be read seperately.

Attention!

The master unit must always be the one with the lowest potential!

Attention!

In case one of the DC outputs shall be grounded it is advised, for safety reasons, to ground the outputs with the lowest potential, i.e. the negative (-) output of the master.



There are some more restrictions and rules to consider because of safety and isolation reasons:

- No negative DC output pole of a unit in the series connection may be raised to a potential >300V against ground (PE)!
- The Share bus must not be wired!
- The grounds (AGND, DGND) of the analogue interfaces of the units must not be wired to each other!
- Remote sense must not be wired!

Example: Two identical units with 360V nominal voltage, for example PSI 8360-10 DT, shall be connected in series. When calculating, the total voltage of that series connection could go up to 720V. Looking at the resulting potentials on the negative outputs of the units, the 2nd unit's negative DC pole could be raised to 360V. This is not permitted! So the lower unit has to be limited to a certain maximum. The figure below clarifies that the resulting total voltage would be 660V:



11.1.2 Parallel connection

Note: only available with devices from 1kW nominal power!

1 Attention!

Only units of the same type (voltage and current) must be used for this operation mode.

In order to increase the output current, two or more units of the same type can be connected in parallel, using the Share bus connection.

Follwing connections are required: connect all (+) DC outputs of the units to each other and all (–) DC outputs to each other. Pin 7 (Share Bus) and pin 8 (Ground) of terminal **System Bus** of all units are also connected in parallel. In case remote sense is also required, all Sense+ and all Sense - inputs are connected in parallel and also with the load. Also see the example wiring in figure 9.1

Important: in this connection the unit with the lowest output voltage determines the output voltage of the system. It means, that every unit can be in control, depending on the adjusted values. It is thus recommended to select a unit that shall control the system and adjust the set of the other units to maximum.

🚺 Note

In case a unit malfunctions or fails due to overheating (OT) or overvoltage (OVP), the whole system can't provide power anymore until the failure is removed.

In order to control the whole system remotely, it is sufficient to control the master via its analogue or digital interface. When reading actual values, the voltage monitor value will represent the overall system voltage, but the current monitor only the output current of the master. In order to get accurate readings, either the actual current is multiplied by the number of units in the parallel connection (only applicable if all have the same nominal output current) or all units will have to be read seperately.



11.2 Networking

The figures below depict networking examples for the digital control of multiple devices in star-shaped (USB, RS232) or bus-like (CAN, GPIB) configurations.

Limitations and technical specifications of the bus systems and the interfaces apply.

With **USB**, up to 30 units can be controlled with one PC, appropriate USB hubs with custom power supply assumed. This basically applies to RS232, too. Differences lie in the handling and the cable lengths.

With **CAN**, up to 30 power supplies per address segment can be integrated into a new or existing CAN bus system. They are addressed by the device node and the RID (see "8. Device setup).

With **GPIB**, there is a limitation of max. 15 slave units on a bus. Multiple GPIB masters can be installed in a PC in order to increase the number of addressable units.



Figure 10. USB or RS232 networking



Figure 11. CAN networking example, also applies to GPIB

12. Miscellaneous

12.1 Accessories and options

Following accessories are available:

a) USB-to-Analogue interface UTA12

Galvanically isolated remote control via USB (on PC side) and the device internal analogue interface.

b) Digital interface cards

Pluggable and retrofittable, digital interface cards for USB, RS232, CAN, GPIB/IEEE (SCPI only), Profibus or Ethernet/ LAN (SCPI only) are available. Details about the interfaces can be found in the interface cards manual.

Following options are available:

a) High Speed Ramping

Increased dynamics of the output voltage by reduced output capacity. It must be pointed out, that other output related values, like for example the ripple, also increase! This is a permanent modification which is not switchable.

12.2 Firmware update

A firmware update of the device should only be done if the device shows erroneous behaviour or if new features have been implemented.

In order to update a device, it requires a certain digital interface card, a new firmware file and a Windows software called "Update tool", which is available as internet download.

These interfaces are qualified to be used for a firmware update:

- IF-U1 (USB)
- IF-R1 (RS232)
- IF-E1 (USB port)
- IF-PB1 (USB port)

In case none of the above interface types is at hand, the device can not be updated. Please contact your dealer for a solution.

The update tool and the particular firmware file for your device are obtainable from the website of the device manufacturer, or are mailed upod request. The update too will guide the user through the semi-automatic update process.



EA-Elektro-Automatik GmbH & Co. KG

研发 - 生产 - 销售一体化 Development - Production - Sales

> Helmholtzstraße 31-33 41747 Viersen Germany

Tel: +49 (0)2162 / 37 85-0 Fax: +49 (0)2162 / 16 230 ea1974@elektroautomatik.de www.elektroautomatik.cn