Installation Manual 20002158, Rev DP June 2022

# Micro Motion<sup>™</sup> ELITE<sup>™</sup> Coriolis Flow and Density Sensors





**MICRO MOTION**<sup>®</sup>

#### Safety messages

Safety messages are provided throughout this manual to protect personnel and equipment. Read each safety message carefully before proceeding to the next step.

#### Safety and approval information

This Micro Motion product complies with all applicable European directives when properly installed in accordance with the instructions in this manual. Refer to the EU declaration of conformity for directives that apply to this product. The following are available: the EU Declaration of Conformity, with all applicable European directives, and the complete ATEX installation drawings and instructions. In addition, the IECEx installation instructions for installations outside of the European Union and the CSA installation instructions for installations in North America are available at Emerson.com or through your local Micro Motion support center.

Information affixed to equipment that complies with the Pressure Equipment Directive, can be found at Emerson.com. For hazardous installations in Europe, refer to standard EN 60079-14 if national standards do not apply.

#### **Other information**

Troubleshooting information can be found in the Configuration Manual. Product data sheets and manuals are available from the Micro Motion web site at Emerson.com.

#### **Return policy**

Follow Micro Motion procedures when returning equipment. These procedures ensure legal compliance with government transportation agencies and help provide a safe working environment for Micro Motion employees. Micro Motion will not accept your returned equipment if you fail to follow Micro Motion procedures.

Return procedures and forms are available on our web support site at Emerson.com, or by calling the Micro Motion Customer Service department.

### Contents

Chapter 1	Before you begin	5
	1.1 About this document	5
	1.2 Hazard messages	5
	1.3 Related documentation	5
Chapter 2	Planning	7
	2.1 Installation checklist	7
	2.2 Best practices	8
	2.3 Temperature limits	9
	2.4 Recommendations for hygienic and self-draining applications	12
Chapter 3	Mounting	15
	3.1 Recommendations for lifting heavy meters	15
	3.2 Mount the sensor	17
	3.3 Rotate junction box or 800 core processor (optional)	18
	3.4 Mount electronics of high-temperature sensors	19
	3.5 Mount a CMF010 sensor to a wall or pole	22
	3.6 Mount a CMFS007, CMFS010, or CMFS015 sensor in a bracket	23
	3.7 Mount a CMFS025, CMFS040, or CMFS050 sensor in a wall mount bracket	24
	3.8 Secure wafer-style process connections	25
	3.9 Attach extended electronics	
Chapter 4	Transmitter power and I/O wiring	
	4.1 Options for wiring	29
	4.2 Connect 4-wire cable	
	4.3 Connect the 9-wire cable	35
Chapter 5	Grounding	37
Chapter 6	Supplementary information	
	6.1 Purge the sensor case	
	6.2 Pressure relief	41

### 1 Before you begin

### 1.1 About this document

This document provides information on planning, mounting, wiring, and grounding the ELITE sensor.

The information in this document assumes that users understand basic transmitter and sensor installation, configuration, and maintenance concepts and procedures.

### 1.2 Hazard messages

This document uses the following criteria for hazard messages based on ANSI standards Z535.6-2011 (R2017).

#### **DANGER**

Serious injury or death will occur if a hazardous situation is not avoided.

#### 

Serious injury or death could occur if a hazardous situation is not avoided.

#### 

Minor or moderate injury will or could occur if a hazardous situation is not avoided.

#### NOTICE

Data loss, property damage, hardware damage, or software damage can occur if a situation is not avoided. There is no credible risk of physical injury.

**Physical access** 

#### 🔔 WARNING

Unauthorized personnel can potentially cause significant damage and/or misconfiguration of end users' equipment. Protect against all intentional or unintentional unauthorized use.

Physical security is an important part of any security program and fundamental to protecting your system. Restrict physical access to protect users' assets. This is true for all systems used within the facility.

### 1.3 Related documentation

You can find all product documentation at Emerson.com.

See any of the following documents for more information:

- The hazardous area approvals documentation shipped with the sensor or available at www.emerson.com/flowmeasurement.
- Micro Motion ELITE Coriolis Flow and Density Meters Product Data Sheet
- Micro Motion 9-Wire Flowmeter Cable Preparation and Installation Manual
- Micro Motion High Temperature Solutions Best Practices Guide
- The transmitter installation guide and the transmitter configuration and use guide

### 2 Planning

### 2.1 Installation checklist

□ If you plan to mount the transmitter in a hazardous area:

#### WARNING

Make sure that the hazardous area specified on the approval tag is suitable for the environment in which the meter will be installed.

- Verify that the local ambient and process temperatures are within the limits of the meter.
- □ If your sensor has an integral transmitter, no wiring is required between the sensor and transmitter. Follow the wiring instructions in the transmitter installation manual for signal and power wiring.
- □ If your transmitter has remote-mounted electronics, follow the instructions in this manual for wiring between the sensor and the transmitter, and then follow the instructions in the transmitter installation manual for power and signal wiring.

Cable type	To transmitter	Maximum length
Micro Motion 9-wire	9739 MVD transmitter	1,000 ft (305 m)
	All other MVD transmitters	60 ft (18 m)
Micro Motion 4-wire	All 4-wire MVD transmitters	<ul> <li>— 1,000 ft (305 m) without Ex-approval</li> </ul>
		<ul> <li>500 ft (152 m) with IIC rated sensors</li> </ul>
		<ul> <li>1,000 ft (305 m) with IIB rated sensors</li> </ul>

#### Table 2-1: Maximum lengths for Micro Motion cable

#### Table 2-2: Maximum lengths for user-supplied 4-wire cable

Wire function	Wire size	Maximum length
Power (VDC)	22 AWG (0.326 mm <sup>2</sup> )	300 ft (91 m)
	20 AWG (0.518 mm <sup>2</sup> )	500 ft (152 m)
	18 AWG (0.823 mm²)	1,000 ft (305 m)
Signal (RS-485)	22 AWG (0.326 mm²) or larger	1,000 ft (305 m)

□ For optimal performance, install the sensor in the preferred orientation. The sensor will work in any orientation as long as the flow tubes remain full of process fluid.

Process	Primary preferred orientation	Secondary preferred orientation	Alternate suitable orientation
Liquids & slurries	t D		
	t D	Ū	, Ļ
Gases	+ ↓ ↓ ↓		
	Liquid with bu	bbles Wet ga	35
Two-phase			

#### Table 2-3: Preferred sensor orientation

□ Install the meter so that the flow direction arrow on the sensor case matches the actual forward flow of the process. (Flow direction is also software-selectable.)

### 2.2 Best practices

- There are no pipe run requirements for Micro Motion sensors. Straight runs of pipe upstream or downstream are unnecessary.
- If the sensor is installed in a vertical pipeline, liquids and slurries should flow upward through the sensor. Gases should flow downward.
- Keep the sensor tubes full of process fluid.
- For halting flow through the sensor with a single valve, install the valve downstream from the sensor.

 The sensor does not require external supports. The flanges will support the sensor in any orientation. (Some sensor models installed in very small, flexible pipeline have optional installation instructions that allow for external supports.)

### 2.2.1 High temperature best practices

- Perform steam injection downstream of the Coriolis meter
- Use steam traps to eliminate condensation and steam flashing
- Control fast acting valves to prevent hammer shock
- Install the meter symmetrically (not tilted)
- Use heat jacket symmetrically (avoid electric or oil trace on just one side)
- To avoid plugging for plugging prone applications, apply heat slowly and uniformly during startup
- Perform slow and controlled switch-over from ethane to de-coking process

For more information, refer to the Micro Motion High Temperature Solutions Best Practices Guide.

### 2.3 Temperature limits


Sensors can be used in the process and ambient temperature ranges shown in the temperature limit graphs. For the purposes of selecting electronics options, temperature limit graphs should be used only as a general guide. If your process conditions are close to the gray area, consult with your Micro Motion representative.

#### 

Temperature limits may be further restricted by hazardous area approvals that are necessary to avoid potential injury to personnel and damage to equipment. Refer to the hazardous area approvals documentation shipped with the sensor or available at www.emerson.com/flowmeasurement for specific temperature ratings for each model and configuration.

#### Note


- In all cases, the electronics cannot be operated where the ambient temperature is below -40 °F (-40 °C) or above 140 °F (60 °C). If a sensor is to be used where the ambient temperature is outside of the range permissible for the electronics, the electronics must be remotely located where the ambient temperature is within the permissible range, as indicated by the shaded areas of the temperature limit graphs.
- The extended-mount electronics option allows the sensor case to be insulated without covering the transmitter, core processor, or junction box, but does not affect temperature ratings. When insulating the sensor case at elevated process temperatures above 140 °F (60 °C), ensure electronics are not enclosed in insulation as this may lead to electronics failure.
- For the CMFS007 sensor, the difference between the process fluid temperature and the average temperature of the case must be less than 210 °F (99 °C)



#### Ambient and process temperature limits for CMFS007, CMFS025–CMFS150

T<sub>amb</sub> = Ambient temperature °F (°C) T<sub>proc</sub> = Process temperature °F (°C) A = All available electronic options B= Remote mount electronics only

### Ambient and process temperature limits for CMF<sup>\* \* \*</sup>M/L/H/P (excludes special order cryogenic modifications) and CMFS010-015




T<sub>amb</sub> = Ambient temperature °F (°C)

T<sub>proc</sub> = Process temperature °F (°C)

A = All available electronic options

B = Remote mount electronics only


C = Recommend special order cryogenic sensor options when operating at a process temperature below -148  $^{\circ}$ F (-100  $^{\circ}$ C)




#### Ambient and process temperature limits for special order cryogenic ELITE meters

 $T_{amb}$  = Ambient temperature °F (°C)  $T_{proc}$  = Process temperature °F (°C) A = All available electronic options B = Remote mount electronics only

#### Ambient and process temperature limits for high temperature ELITE meters



 $T_{amb}$  = Ambient temperature °F (°C)  $T_{proc}$  = Process temperature °F (°C) A = All available electronic options B = Remote mount electronics only



#### Ambient and process temperature limits for super duplex ELITE meters

 $T_{\text{proc}}$  = Process temperature °F (°C)

A = All available electronic options

B= Remote mount electronics only

#### Note

For super duplex models operating above 351 °F (177.2 °C), consult the factory before purchase.

2.4


### **Recommendations for hygienic and self**draining applications

CMFS sensors are certified EHEDG TYPE EL CLASS I for hygienic applications when installed vertically with the process fitting and gasket combinations listed in the Position Paper of the EHEDG Test Methods Subgroup (available at https://www.ehedg.org). Other process connections/gasket combinations may be used provided they have been evaluated and successfully tested for in-place cleanability according to the latest edition of EHEDG Document 2. Refer to the Micro Motion ELITE Coriolis Flow and Density Meters Product Data Sheet for further information about fitting options.

For optimal cleanability and drainability:

- If possible, install the sensor in a vertical pipeline with the process fluid flowing upward through the sensor.
- If the sensor must be installed in a horizontal pipeline, drainage is accomplished by air purge evacuation of the pipeline circuit.
- For clean-in-place (CIP) applications, Micro Motion recommends using the generally-• accepted flow velocity of at least 1.5 m/s for cleaning the sensor.
- The gap between the electronics housing and sensor body should be inspected periodically. Manually clean this gap when necessary.

#### Figure 2-1: Installation for self-draining applications



- A. Process pipeline
- B. Direction of normal process flow
- C. Direction of drainage

### 3 Mounting

### 3.1 Recommendations for lifting heavy meters

Heavy meters (those over 50 lb (23 kg)), and even lighter meters that must be installed in elevated or difficult-to-reach places, usually require additional consideration when transporting or lifting them into their installation location.

• Safe handling during transportation and installation is the responsibility of the installer.

#### 

Know and follow all safety practices and regulations for your facility and for any lifting/rigging equipment being used in order to prevent injury.

- A professional rigging crew with proper equipment should be used.
- Typical equipment for handling heavy meters includes the following:
  - Fixed hoist boom trucks or cranes
  - Continuous web belt slings
  - Eye to eye web belt slings
  - Two leg wire rope slings
- Lift a meter by its case.
- Do not lift a meter by its electronics (junction box, transmitter, or any electrical fittings) or by its purge fittings.
- It may be useful to identify the meter center of gravity.
- Protect the sealing surfaces on the process fittings with factory-installed flange protectors or comparable field-installed protection.





Figure 3-2: Center of gravity for large meters



A. Typical center of gravity

#### Note

Complete and detailed dimensional drawings can be found through the Actions link after a meter is selected in the online Sizing and Selection tool.

### 3.2 Mount the sensor

#### NOTICE


- Lifting the sensor by the electronics or purge connections can damage the device.
- To reduce the risk of collecting liquid in the electronics housing, do not orient transmitters or sensor junction boxes with their conduit openings pointing upward.

#### Procedure

Mount the sensor.

#### Notes


- Do not use the sensor to support the piping.
- The sensor does not require external supports. The flanges will support the sensor in any orientation. Some sensor models installed in small, flexible pipelines have optional installation instructions that allow for external supports.



## 3.3 Rotate junction box or 800 core processor (optional)

An integrally mounted junction box or 800 core processor can be rotated to one of eight possible positions in 45 degree increments.

Figure 3-3: Parts for rotating the junction box or 800 core processor on the sensor



- A. Housing
- B. Clamping ring
- C. Clamping ring screw
- D. Feedthrough
- E. Alignment notches

#### Note

The 800 core processor is shown in this figure. The junction box has a somewhat different appearance.


#### Procedure

- 1. Loosen the clamping ring screw and remove the clamping ring.
- 2. Gently separate the housing from the feedthrough, but only until there is sufficient clearance from the alignment notches to rotate the housing.
- 3. Rotate the housing to the desired position and in line with the alignment notches.
- 4. Seat the housing onto the feedthrough.
- 5. Replace the clamping ring and tighten the clamping ring screw.

### 3.4 Mount electronics of high-temperature sensors

The electronics of high-temperature sensors are attached to the end of a 32 in (813 mm) pre-installed flexible conduit. The electronics must be separately mounted on a wall or instrument pole.

#### Figure 3-4: Components of a high-temperature sensor




- A. Sensor
- B. Electronics
- C. Mounting bracket
- D. Flexible conduit with minimum bend radius 6 in (152 mm)

With some large meter sizes, the meter may ship with the electronics attached to the sensor case. The meter cannot be operated in this configuration. Detach the electronics bracket from the sensor case and then proceed to mount the electronics to a wall or instrument pole as described below.

#### Important

Do not operate the meter while the electronics are attached to the sensor case.

#### Figure 3-5: Removing electronics from the sensor case




A. Detach electronics from sensor case and mount to a wall or instrument pole

#### Procedure

• For wall mounting, use four 0.3 in (8 mm) bolts to secure the mounting bracket.


Figure 3-6: Wall-mount components



- A. Wall or flat surface
- B. Electronics (enhanced core processor shown)
- C. Flexible conduit

• For mounting to an instrument pole, use a 2 in (51 mm) U-bolt pipe kit to secure the mounting bracket.

#### Figure 3-7: Pole-mount components



- A. Instrument pole
- B. Electronics (enhanced core processor shown)
- C. Flexible conduit

### 3.5 Mount a CMF010 sensor to a wall or pole

The CMF010 sensor has an optional mounting configuration for use with small or flexible pipeline. If the pipeline adequately supports the sensor, you can skip this procedure.

#### Procedure

1. Locate the optional mounting holes. For sensors with a junction box, the junction box must be rotated to the side to expose the mounting holes.

Figure 3-8: Optional mounting

- A. Two user-supplied 0.3 in (8 mm) bolts
- B. Junction box or core processor (junction box shown)
- C. Mounting surface
- 2. If necessary, install rigid standoffs between the sensor and the mounting surface.
- 3. Using two user-supplied 0.3 in (8 mm) bolts with a minimum length 2.25 in (57 mm), secure the sensor case to the mounting surface.


## 3.6 Mount a CMFS007, CMFS010, or CMFS015 sensor in a bracket

The CMFS007, CMFS010, and CMFS015 sensors have an optional mounting bracket for use with small or flexible pipeline. If the pipeline adequately supports the sensor, skip this procedure.

#### **Procedure**

- 1. Secure the mounting bracket to a wall or other flat surface with four user-supplied 0.3 in (8 mm) bolts.
- 2. Place the sensor into the bracket.
- 3. Secure the sensor in the bracket with the supplied 0.3 in (8 mm) U-bolts.

#### Figure 3-9: Mounting bracket for CMFS007, CMFS010, and CMFS015



- A. Mounting bracket
- B. Mounting holes
- C. Supplied U-bolts


## 3.7 Mount a CMFS025, CMFS040, or CMFS050 sensor in a wall mount bracket

The CMFS025, CMFS040, and CMFS050 sensors have an optional wall mounting bracket.

#### Procedure

1. Assemble the bracket.

Figure 3-10: Assembled wall mounting bracket for CMFS025, CMFS040, and CMFS050



- 2. Attach the bracket to the wall using fasteners appropriate for the mounting surface.
- 3. Place the sensor into the bracket.
- 4. Secure the sensor in the bracket with the supplied fasteners.

Figure 3-11: CMFS025, CMFS040, or CMFS050 wall mounted using bracket



### 3.8 Secure wafer-style process connections

A wafer-style connection lets you clamp the sensor into the pipeline. A wafer installation kit is shipped with a wafer-style sensor.


#### Procedure

- 1. Make sure that the bolts provided are rated for your process connection.
- 2. Slip the sensor alignment rings over each end of the sensor wafer; then insert the sensor between the process connections in the pipeline.

#### Tip

Micro Motion recommends installing gaskets (user-supplied).

#### Figure 3-12: Wafer-style connection components




- A. Flange nut
- B. Gasket (user-supplied)
- C. Alignment ring
- D. Flange bolt
- E. Sensor wafer
- 3. Insert the flange bolts through both process connections and thread the flange nuts onto the bolts.
- 4. With your fingers, tighten the flange nuts.
- 5. Rotate the sensor alignment rings in the direction that pushes the bolts outward.

#### Tip

Rotate both sensor alignment rings until the assembly is centered and tight.

#### Figure 3-13: Alignment ring usage



- A. Direction to rotate the alignment ring
- B. Direction the flange bolts are pushed
- C. Flange bolt
- 6. With a wrench, tighten the nuts in an alternating order.

### 3.9 Attach extended electronics

If your installation has a sensor with extended electronics, you will need to install the extender onto the sensor case.

Extended core processors are matched at the factory to specific sensors. Keep each core processor together with the sensor with which it was shipped.


#### NOTICE

Keep the extender and feedthrough clean and dry. Moisture or debris in the extender or feedthrough can damage electronics and result in measurement error or flowmeter failure.

#### Procedure

1. Remove and recycle the plastic cap from the feedthrough on the sensor.

#### Figure 3-14: Feedthrough and extender components



- A. Transmitter or core processor
- B. Extender
- C. O-ring
- D. Feedthrough
- E. Clamping ring
- F. Clamping screw
- G. Plastic plug
- H. Plastic cap
- 2. Loosen the clamping screw and remove the clamping ring. Leave the O-ring in place on the feedthrough.
- 3. Remove and recycle the plastic plug from the extender.
- 4. Fit the extender onto the feedthrough by carefully aligning the notches on the bottom of the extender with the notches on the feedthrough.
- 5. Close the clamping ring and tighten the clamping screw to 13 in lbf (1.47 N m) to 18 in lbf (2.03 N m).

### 4 Transmitter power and I/O wiring

### 4.1 **Options for wiring**

The wiring procedure you follow depends on which electronics option you have.

Table 4-1: Wiring procedures by electronics option	Table 4-1: Wiring	procedures by	/ electronics	option
--	-------------------	---------------	---------------	--------

Electronics option	Wiring procedure
Integral transmitter	The transmitter is already connected to the sensor. No wiring is required between sensor and transmitter. See the transmitter installation manual for wiring the power and signal cable to the transmitter.
Extended electronics	The electronics are separated from the sensor by an extender and must be attached as described in Attach extended electronics. There is no wiring required because the physical connection includes the electrical connection.
MVD <sup>™</sup> Direct Connect <sup>™</sup>	There is no transmitter to wire. See the Micro Motion MVD Direct Connect Meters Installation Manual Micro Motion MVD Direct Connect Meters manual for wiring the power and signal cable between the sensor and the direct host.
Integral core processor with remote transmitter	The core processor is already connected to the sensor. Connect a 4-wire cable between the core processor and transmitter. Refer to Connect 4-wire cable.
Remote core processor attached to transmitter	Connect a 9-wire cable between the sensor and the transmitter/ core processor. Refer to Connect the 9-wire cable, as well as the Micro Motion 9-Wire Flowmeter Cable Preparation and Installation Manual.
Remote core processor separate from transmitter – double-hop	<ul> <li>Connect a 4-wire cable between the core processor and transmitter. Refer to Connect 4-wire cable.</li> <li>Connect a 9-wire cable between the sensor and the core processor. Refer to Connect the 9-wire cable , as well as the Micro Motion 9-Wire Flowmeter Cable Preparation and Installation Manual.</li> </ul>

### 

Make sure the hazardous area specified on the sensor approval tag is suitable for the environment in which the sensor will be installed. Failure to comply with the requirements for intrinsic safety in a hazardous area could result in an explosion resulting in injury or death.

#### NOTICE

Fully close and tighten all housing covers and conduit openings. Improperly sealed housings can expose electronics to moisture, which can cause measurement error or flowmeter failure. Inspect and grease all gaskets and O-rings.

### 4.2 Connect 4-wire cable

### 4.2.1 4-wire cable types and usage

Micro Motion offers two types of 4-wire cable: shielded and armored. Both types contain shield drain wires.

The cable supplied by Micro Motion consists of one pair of red and black 18 AWG (0.823 mm<sup>2</sup>) wires for the VDC connection, and one pair of white and green 22 AWG (0.326 mm<sup>2</sup>) wires for the RS-485 connection.

User-supplied cable must meet the following requirements:

- Twisted pair construction.
- Applicable hazardous area requirements, if the core processor is installed in a hazardous area.
- Wire gauge appropriate for the cable length between the core processor and the transmitter, or the host.

Wire gauge	Maximum cable length
VDC 22 AWG (0.326 mm <sup>2</sup> )	300 ft (91 m)
VDC 20 AWG (0.518 mm <sup>2</sup> )	500 ft (152 m)
VDC 18 AWG (0.823 mm <sup>2</sup> )	1,000 ft (305 m)
RS-485 22 AWG (0.326 mm²) or larger	1,000 ft (305 m)

### 4.2.2 Prepare a cable with a metal conduit


#### Procedure

- 1. Remove the core processor cover using a flat-blade screw driver.
- 2. Run the conduit to the sensor.
- 3. Pull the cable through the conduit.
- 4. Cut the drain wires and let them float at both ends of the conduit.

### 4.2.3 Prepare a cable with user-supplied cable glands

#### Procedure

- 1. Remove the core processor cover using a flat-blade screw driver.
- 2. Pass the wires through the gland nut and gland body.




- 3. Terminate the RS-485 shield and drain wires to the housing internal grounding screw.
- 4. Assemble the gland according to vendor instructions.

### 4.2.4 Prepare a cable with Micro Motion-supplied cable glands

#### Procedure

- 1. Remove the core processor cover using a flat-blade screw driver.
- 2. Pass the wires through the gland nut and clamping insert.



- A. Gland nut
- B. Clamping insert
- 3. Strip the cable jacket.

Option	Description
NPT gland type	Strip 4.5 in (114 mm)
M20 gland type	Strip 4.25 in (108 mm)

- 4. Remove the clear wrap and filler material.
- 5. Strip most of the shielding.

Option	Description
NPT gland type	Strip all but 0.75 in (19 mm)
M20 gland type	Strip all but 0.5 in (13 mm)

6. Wrap the drain wires twice around the shield and cut off the excess drain wires.




- A. Drain wires wrapped around shield
- 7. For foil (shielded cable) only:

### **Note** For braided (armored cable) skip this step and contine to the next step.


Option	Description
NPT gland	a. Slide the shielded heat shrink over the drain wires. Ensure that the wires are completely covered.
type	<ul> <li>Apply 250 °F (121.1 °C) heat to shrink the tubing. Do not burn the cable.</li> </ul>
	c. Position the clamping insert so the interior end is flush with the braid of the heat shrink.
	AB
	A. Shielded heat shrink B. After heat is applied
M20 gland type	Trim 0.3 in (8 mm).
	A. Trim

8. Assemble the gland by folding the shield or braid back over the clamping insert and 0.125 in (3 mm) past the O-ring.



A. Shield folded back

- 9. Install the gland body into the conduit opening on the core processor housing.
- 10. Insert the wires through the gland body and tighten the gland nut onto the gland body.



A. Shield folded back


B. Gland body

### 4.2.5 Connect the wires to the core processor terminals


After the 4-wire cable has been prepared and shielded (if required), connect the individual wires of the 4-wire cable to the terminals on the core processor.

#### Procedure

- 1. Connect the wires to the core processor terminals.
  - If you are connecting to a standard core processor, use the following image and connections:



- A. Terminal 1 (Power supply +): Red wire
- B. Terminal 2 (Power supply -): Black wire
- C. Terminal 3 (RS-485/A): White wire
- D. Terminal 4 (RS-485/B): Green wire
- If you are connecting to an enhanced core processor, use the Enhanced core processor and connections:



- A. Terminal 1 (Power supply +): Red wire
- B. Terminal 2 (Power supply -): Black wire
- C. Terminal 3 (RS-485/A): White wire
- D. Terminal 4 (RS-485/B): Green wire
- 2. Reinstall the core processor cover.
- 3. Torque the cover screws to:
  - For aluminum housing: 10 in lbf (1.13 N m) to 13 in lbf (1.47 N m)
  - For stainless steel housing: minimum 19 in lbf (2.15 N m)

If properly seated, there will be no gap between cover and base.

4. Connect the wires to the transmitter terminals using the transmitter installation manual.

### 4.3 Connect the 9-wire cable

#### Procedure

- 1. Prepare and install the cable according to the instructions in the Micro Motion 9-Wire Flowmeter Cable Preparation and Installation Manual.
- 2. Insert the stripped ends of the individual wires into the terminal blocks of the junction box.

Ensure that no bare wires remain exposed.

- 3. Match the wires color for color. For wiring at the transmitter or remote core processor, refer to the transmitter documentation.
- 4. Tighten the screws to hold the wires in place.
- 5. Ensure integrity of gaskets; then tightly close and seal the junction box cover and all housing covers.
- 6. Refer to the transmitter installation manual for signal and power wiring instructions.

### 5 Grounding

The meter must be grounded according to the standards that are applicable at the site. The customer is responsible for knowing and complying with all applicable standards.

#### Prerequisites

Use the following guides for grounding practices:

- In Europe, IEC 60079-14 is applicable to most installations, in particular sections 16.2.2.3 and 16.2.2.4.
- In the USA and Canada, ISA 12.06.01 Part 1 provides examples with associated applications and requirements.

If no external standards are applicable, follow these guidelines to ground the sensor:

- Use copper wire, 14 AWG (2.08 mm<sup>2</sup>) or larger wire size.
- Keep all ground leads as short as possible, less than 1  $\Omega$  impedance.
- Connect ground leads directly to earth or follow plant standards.

#### NOTICE

Ground the flow meter to earth or follow ground network requirements for the facility. Improper grounding can cause measurement error.

#### Procedure

- Check the joints in the pipeline.
  - If the joints in the pipeline are ground-bonded, the sensor is automatically grounded and no further action is necessary (unless required by local code).
  - If the joints in the pipeline are not grounded, connect a ground wire to the grounding screw located on the sensor electronics.

#### Tip

The sensor electronics may be a transmitter, core processor, or junction box. The grounding screw may be internal or external.

### 6 Supplementary information

### 6.1 Purge the sensor case

#### Prerequisites

Make sure the following are available before beginning the purge procedure:

- PTFE<sup>™</sup> tape
- Argon or nitrogen gas sufficient to purge the sensor case

If the sensor has purge fittings, they should remain sealed at all times. The sensor is purged of all oxygen and sealed at the factory. If the purge plugs are never removed, it is not necessary to purge or re-seal the sensor. For more information, contact customer support.

Whenever a purge plug is removed from the sensor case, you must purge the case again.

#### Procedure

1. Shut down the process, or set control devices for manual operation.

NOTICE

Before performing the case purging procedure, shut down the process or set the control devices for manual operation. Performing the purge procedure while the flow meter is operating could affect measurement accuracy, resulting in inaccurate flow signals.

2. Remove both purge plugs from the sensor case. If purge lines are being used, open the valve in the purge lines.

#### 🔔 WARNING

- If a rupture disk has been installed on the purge fitting, stay clear of the rupture disk pressure relief area. High-pressure fluid escaping from the sensor can cause severe injury or death. Orient the sensor so that personnel and equipment will not be exposed to any discharge along the pressure relief path.
- Take all necessary precautions when removing purge plugs. Removing a purge plug compromises the secondary containment of the sensor and could expose the user to process fluid.
- Improper pressurization of the sensor case could result in injury.

#### NOTICE

If a rupture disk has been installed on the purge fitting, use thread protectors when removing the purge fitting so as not to damage the disk membrane surrounding the rupture disk.

3. Prepare the purge plugs for reinstallation by wrapping them with 2–3 turns of PTFE tape.

4. Connect the supply of nitrogen or argon gas to the inlet purge connection or open inlet purge line. Leave the outlet connection open.

#### NOTICE

- Exercise caution to avoid introducing dirt, moisture, rust, or other contaminants into the sensor case.
- If the purge gas is heavier than air (such as argon), locate the inlet lower than the outlet, so that the purge gas will displace air from bottom to top.
- If the purge gas is lighter than air (such as nitrogen), locate the inlet higher than the outlet, so that the purge gas will displace air from top to bottom.
- 5. Make sure that there is a tight seal between the inlet connection and sensor case, so that air cannot be drawn by suction into the case or purge line during the purging process.
- 6. Run purge gas through the sensor.

The purge time is the amount of time required for full exchange of atmosphere to inert gas. The larger the line size, the greater amount of time is required to purge the case. If purge lines are being used, increase the purge time to fill the additional volume of the purge line.

#### Important

Keep the purge gas pressure below 7.25 psi (0.5 bar).

Sensor model	Purge rate	Time, in minutes
CMF010	20 ft3/h (566.3 l/h)	1
CMF025	20 ft3/h (566.3 l/h)	1
CMF050	20 ft3/h (566.3 l/h)	2
CMF100	20 ft3/h (566.3 l/h)	5
CMF200	20 ft3/h (566.3 l/h)	12
CMF300	20 ft3/h (566.3 l/h)	30
CMF350	20 ft3/h (566.3 l/h)	45
CMF400	20 ft3/h (566.3 l/h)	55
CMFHC2	20 ft3/h (566.3 l/h)	100
CMFHC3	20 ft3/h (566.3 l/h)	170
CMFHC4	20 ft3/h (566.3 l/h)	268
CMFS007	20 ft3/h (566.3 l/h)	1½
CMFS010	20 ft3/h (566.3 l/h)	1½
CMFS015	20 ft3/h (566.3 l/h)	1½
CMFS025	20 ft3/h (566.3 l/h)	41⁄2
CMFS040	20 ft3/h (566.3 l/h)	41⁄2
CMFS050	20 ft3/h (566.3 l/h)	41⁄2

#### Table 6-1: Purge time

#### Table 6-1: Purge time (continued)

Sensor model	Purge rate	Time, in minutes
CMFS075	20 ft3/h (566.3 l/h)	6
CMFS100	20 ft3/h (566.3 l/h)	6
CMFS150	20 ft3/h (566.3 l/h)	6

7. At the appropriate time, shut off the gas supply; then immediately seal the purge outlet and inlet connections with the purge plugs.


Avoid pressurizing the sensor case. If pressure inside the case elevates above atmospheric pressure during operation, the flow meter density calibration will be inaccurate.

8. Make sure that the purge fitting seals are tight so that air cannot be drawn by suction into the sensor case.

### 6.2 Pressure relief

ELITE sensors are available with a rupture disk installed on the case. Rupture disks vent process fluid from the sensor case in the unlikely event of a flow tube breach. Some users connect a pipeline to the rupture disk to help contain escaping process fluid. For more information about rupture disks, contact customer service.

If the sensor has a rupture disk, keep it installed at all times, as it would otherwise be necessary to re-purge the case. If the rupture disk is activated by a tube breach, the seal in the rupture disk will be broken, and the Coriolis meter should be removed from service.



#### 

- Orient the sensor so that personnel and equipment will not be exposed to any discharge along the pressure relief path.
- Stay clear of the rupture disk pressure relief area. High-pressure fluid escaping from the sensor can cause severe injury or death.

#### Important

If using a rupture disk, the housing can no longer assume a secondary containment function.

#### NOTICE

Removing the purge fitting, blind plug, or rupture disks compromises the Ex-i Safety Certification, the Ex-tc Safety Certification, and the IP-rating of the Coriolis meter. Any modification to the purge fitting, blind plug, or rupture disks must maintain a minimum of IP66/IP67 Ratings.

### 

20002158 Rev. DP 2022

For more information: www.emerson.com

©2022 Micro Motion, Inc. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. Micro Motion, ELITE, ProLink, MVD and MVD Direct Connect marks are marks of one of the Emerson Automation Solutions family of companies. All other marks are property of their respective owners.



**MICRO MOTION**<sup>®</sup>