


Fluke 190-104, Fluke 190-204 ScopeMeter 190 Series II

Users Manual



LIMITED WARRANTY & LIMITATION OF LIABILITY

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is three years for the test tool and one year for its accessories. The warranty period begins on the date of shipment. Parts, product repairs and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries or to any product which, in Fluke's opinion, has been misused, altered, neglected or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center or send the product, with a description of the difficulty, postage and insurance prepaid (FOB Destination), to the nearest Fluke authorized service center. Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that the failure was caused by misuse, alteration, accident or abnormal condition of operation or handling, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, WHETHER ARISING FROM BREACH OF WARRANTY OR BASED ON CONTRACT, TORT, RELIANCE OR ANY OTHER THEORY.

Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.

Fluke Corporation, P.O. Box 9090, Everett, WA 98206-9090 USA, or

Fluke Industrial B.V., P.O. Box 90, 7600 AB, Almelo, The Netherlands

SERVICE CENTERS

To locate an authorized service center, visit us on the World Wide Web:

http://www.fluke.com

or call Fluke using any of the phone numbers listed below:

+1-888-993-5853 in U.S.A. and Canada

+31-40-2675200 in Europe

+1-425-446-5500 from other countries

Table of Contents

Chapter	Title	Page
	Unpacking the Test Tool Kit	
	Safe Use of Li-ion battery pack	
1	Using the Scope and Meter	11
	Powering the Test Tool	11
	Resetting the Test Tool	
	Navigating a Menu	
	Hiding Key Labels and Menus	
	Key Illumination	14
	Input Connections	
	Making Input Connections	
	Adjusting the Probe Type Settings	
	Selecting an Input Channel	
	Displaying an Unknown Signal with Connect-and-View™	18
	Making Automatic Scope Measurements	19

	Making Automatic Meter Measurements	20
	Freezing the Screen	
	Using Average, Persistence and Glitch Capture	23
	Acquiring Waveforms	
	Pass - Fail Testing	34
	Analyzing Waveforms	35
2	Using The Recorder Functions	37
	Opening the Recorder Main Menu	37
	Plotting Measurements Over Time (TrendPlot™)	
	Recording Scope Waveforms In Deep Memory (Scope Record)	
	Analyzing a TrendPlot or Scope Record	44
3	Using Replay, Zoom and Cursors	45
	Replaying the 100 Most Recent Scope Screens	45
	Zooming in on a Waveform	
	Making Cursor Measurements	49
4	Triggering on Waveforms	53
	Setting Trigger Level and Slope	54
	Using Trigger Delay or Pre-trigger	
	Automatic Trigger Options	
	Triggering on Edges	57
	Triggering on Video Signals	60
	Triggering on Pulses	62
5	Using Memory and PC	65

	Using the USB Ports	65
	Saving and Recalling	
	Using FlukeView [®]	74
6	Tips	75
	Using the Standard Accessories	75
	Using the Independently Floating Isolated Inputs	77
	Using the Tilt Stand	80
	Kensington®-lock	80
	Fixing the Hangstrap	81
	Resetting the Test Tool	81
	Suppressing Key Labels and Menu's	82
	Changing the Information Language	82
	Adjusting the Contrast and Brightness	83
	Changing Date and Time	83
	Saving Battery Life	84
	Changing the Auto Set Options	86
7	Maintaining the Test Tool	87
	Cleaning the Test Tool	87
	Storing the Test Tool	
	Charging the Batteries	88
	Replacing the Battery Pack	89
	Calibrating the Voltage Probes	91
	Displaying Version and Calibration Information	
	Displaying Battery Information	93
	Parts and Accessories	94
	Troubleshooting	99

Fluke 190-104, Fluke 190-204 Users Manual

8	Specifications	99
	Introduction	99
	Four Input Oscilloscope	
	Automatic Scope Measurements	103
	Meter	
	Recorder	106
	Zoom, Replay and Cursors	107
	Miscellaneous	
	Environmental	110
	<u> </u>	111
	10:1 Probe	112
	Electromagnetic Immunity	113

Declaration of Conformity

for

Fluke 190-104, Fluke 190-204

ScopeMeter® test tools

Manufacturer

Fluke Industrial B.V. Lelyweg 14 7602 EA Almelo The Netherlands

Statement of Conformity

Based on test results using appropriate standards, the product is in conformity with Electromagnetic Compatibility Directive 2004/108/EC Low Voltage Directive 2006/95/EC

Sample tests

Standards used:

EN 61010-1: 2001 Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use

> EN 61326-1: 2006 Electrical equipment for measurements and laboratory use -EMC requirements-

Li-ion battery tested acc. to EN/IEC62133

The tests have been performed in a typical configuration.

This Conformity is indicated by the symbol **C**, i.e. "Conformité Européenne".

Unpacking the Test Tool Kit

The following items are included in your test tool kit:

Note

When new, the rechargeable Li-ion battery is not fully charged. See Chapter 7.




Figure 1. ScopeMeter Test Tool Kit

#	Description	
1	ScopeMeter Test Tool	
2	Hang Strap (see Chapter 6 for mounting instructions	
3	Power Adapter (country dependent)	
4	10:1 Voltage Probe Set (red) a) 10:1 Voltage Probe (red) b) Hook Clip for Probe Tip (black) c) Ground Lead with Mini Alligator Clip (black) d) Ground Spring for Probe Tip (black) e) Insulation Sleeve (black)	
5	10:1 Voltage Probe Set (blue) a) 10:1 Voltage Probe (blue) b) Hook Clip for Probe Tip (black) c) Ground Lead with Mini Alligator Clip (black) d) Ground Spring for Probe Tip (black) e) Insulation Sleeve (black)	
6	10:1 Voltage Probe Set (gray) a) 10:1 Voltage Probe (gray) b) Hook Clip for Probe Tip (black) c) Ground Lead with Mini Alligator Clip (black) d) Ground Spring for Probe Tip (black) e) Insulation Sleeve (black)	

7	10:1 Voltage Probe Set (green) a) 10:1 Voltage Probe (green) b) Hook Clip for Probe Tip (black) c) Ground Lead with Mini Alligator Clip (black) d) Ground Spring for Probe Tip (black) e) Insulation Sleeve (black)
8	USB interface cable for PC connection (USB-A to mini-USB-B)
9	Safety Information sheet + CD ROM with Users Manual (multi-language) and FlukeView ScopeMeter Software for Windows demo package (with restricted functionality)
10	Shipment box (basic version only)

Fluke 190-104 and 190-204 -S versions include also the following items (SCC290 kit):

#	Description
11	FlukeView ScopeMeter Software for Windows activation key (converts FlukeView DEMO status into full operational status).
12	Hard Shell Carrying Case

Safety Information: Read First


Read all safety information before you use the product.

Specific warning and caution statements, where they apply, appear throughout the manual.

A "Warning" identifies conditions and actions that pose hazard(s) to the user.

A "Caution" identifies conditions and actions that may damage the product.

The following international symbols are used on the product and in this manual:



⚠ Warning

To avoid electrical shock or fire:

- Use only the Fluke power supply, Model BC190 (Power Adapter).
- Before use check that the selected/indicated range on the BC190 matches the local line power voltage and frequency.
- For the BC190/808 universal Power Adapter only use line cords that comply with the local safety regulations.

Note:

To accommodate connection to various line power sockets, the BC190/808 universal Power Adapter is equipped with a male plug that must be connected to a line cord appropriate for local use. Since the adapter is isolated, the line cord does not need to be equipped with a terminal for connection to protective ground. Since line cords with a protective grounding terminal are more commonly available you might consider using these anyhow.

Marning

To avoid electrical shock or fire if a product input is connected to more than 42 V peak (30 Vrms) or 60 V dc:

- Use only insulated voltage probes, test leads and adapters supplied with the product, or indicated by Fluke as suitable for the Fluke 190-104 and 190-204 ScopeMeter series.
- Before use, inspect voltage probes, test leads and accessories for mechanical damage and replace when damaged.
- Remove all probes, test leads and accessories that are not in use.
- Always connect the power adapter first to the ac outlet before connecting it to the product.
- Do not touch voltages >30 V ac rms, 42 V ac peak, or 60 V dc.
- Do not connect the ground spring (figure 1, item d) to voltages higher than 42 V peak (30 Vrms) from earth ground.
- Do not apply more than the rated voltage, between the terminals or between each terminal and earth ground.

- Do not apply input voltages above the rating of the instrument. Use caution when using 1:1 test leads because the probe tip voltage will be directly transmitted to the product.
- Do not use exposed metal BNC connectors.
 Fluke offers cables with plastic, safety designed BNC connectors suitable for the ScopeMeter product, see Chapter 7 'Optional accessories'.
- Do not insert metal objects into connectors.
- Use the product only as specified, or the protection supplied by the product can be compromised.
- Carefully read all instructions.
- Do not use the product if it operates incorrectly.
- Do not use and disable the product if it is damaged.
- Keep fingers behind the finger guards on the probes.
- Use only correct measurement category (CAT), voltage, and amperage rated probes, test leads, and adapters for the measurement.

- Do not exceed the Measurement Category (CAT) rating of the lowest rated individual component of a product, probe, or accessory.
- Do not use the product around explosive gas, vapor, or in damp or wet environments.
- Measure a known voltage first to make sure that the product operates correctly.
- Examine the case before you use the product.
 Look for cracks or missing plastic. Carefully look at the insulation around the terminals.
- Do not work alone.
- Comply with local and national safety codes.
 Use personal protective equipment (approved rubber gloves, face protection, and flame resistant clothes) to prevent shock and arc blast injury where hazardous live conductors are exposed.
- The battery door must be closed and locked before you operate the product.
- Do not operate the product with covers removed or the case open. Hazardous voltage exposure is possible.
- Remove the input signals before you clean the product.
- Use only specified replacement parts.

Voltage ratings that are mentioned in the warnings, are given as limits for "working voltage". They represent V ac rms (50-60 Hz) for ac sinewave applications and as V dc for dc applications.

Measurement Category IV refers to the overhead or underground utility service of an installation.

Measurement Category III refers to distribution level and fixed installation circuits inside a building.

The terms 'Isolated' or 'Electrically floating' are used in this manual to indicate a measurement in which the product input BNC is connected to a voltage different from earth ground.

The isolated input connectors have no exposed metal and are fully insulated to protect against electrical shock.

The BNC jacks can independently be connected to a voltage above earth ground for isolated (electrically floating) measurements and are rated up to 1000 Vrms CAT III and 600 Vrms CAT IV above earth ground.

If Safety Features are Impaired

Use of the product in a manner not specified may impair the protection provided by the equipment.

Do not use test leads if they are damaged. Examine the test leads for damaged insulation, exposed metal, or if the wear indicator shows.

Whenever it is likely that safety has been impaired, the product must be turned off and disconnected from the line power. The matter should then be referred to qualified personnel. Safety is likely to be impaired if, for example, the product fails to perform the intended measurements or shows visible damage.

Safe Use of Li-ion battery pack

The battery pack Fluke model BP291 (52 Wh) has been tested in accordance with the UN Manual of Tests and Criteria Part III Subsection 38.3 (ST/SG/AC.10/11/Rev.3) – more commonly known as the UN T1..T8 – tests, and have been found to comply with the stated criteria. The battery pack has been tested acc. to EN/IEC62133. As a result they can be shipped unrestricted internationally by any means.

Recommendations to safe storage of battery pack.

- Do not store battery packs near heat or fire. Do not store in sunlight.
- Do not remove a battery pack from its original packaging until required for use.
- When possible, remove the battery pack from the equipment when not in use.
- Fully charge the battery pack before storing it for an extended period to avoid a defect.
- After extended periods of storage, it may be necessary to charge and discharge the battery packs several times to obtain maximum performance.
- Keep the battery pack out of the reach of children and animals.
- Seek medical advise if a battery or part of it has been swallowed.

Recommendations to safe use of the battery pack.

- The battery pack needs to be charged before use.
 Use only Fluke approved power adapters to charge the battery pack. Refer to Fluke's safety instructions and Users Manual for proper charging instructions.
- Do not leave a battery on prolonged charge when not in use.
- The battery pack gives the best performance when operated at normal room temperature 20 °C ± 5 °C (68 °F ± 9 °F).
- Do not put battery packs near heat or fire. Do not put in sunlight.
- Do not subject battery packs to severe impacts such as mechanical shock
- Keep the battery pack clean and dry. Clean dirty connectors with a dry, clean cloth
- Do not use any charger other than that specifically provided for use with this equipment.
- Do not use any battery which is not designed or recommended by Fluke for use with the Product.
- Take careful notice of correct placement of the battery in the product or the External Battery Charger.
- Do not short-circuit a battery pack. Do not keep battery packs in a place where the terminals can be

- shorted by metal objects (e.g. coins, paperclips, pens or other).
- Never use a battery pack or charger showing visible damage.
- Bateries contain hazardous chemicals that can cause burns or explode. If exposure to chemicals occurs, clean with water en get medical aid. Repair the product before use if the battery leaks.
- Alteration of battery pack: there shall be no attempt to open, modify, reform or repair a battery pack, which appears to be malfunctioning, or which has been physically damaged.
- Do not disassemble or crush battery packs
- Use the battery only in the application for which it is intended.
- Retain the original product information for future reference.

Recommendations to safe transport of battery packs

- The battery pack must adequately be protected against short-circuit or damage during transport.
- Always consult the IATA guidelines describing safe air transport of Li-ion batteries.
- Check-in luggage: battery packs are only allowed when installed in the Product.

- Hand carried luggage: a number of battery packs as required for normal and individual use is allowed.
- Always consult national/local guidelines that are applicable for shipment by mail or other transporters.
- A maximum of 3 battery packs may be shipped by mail. The package must be marked as follows: PACKAGE CONTAINS LITHIUM-ION BATTERIES (NO LITHIUM METAL).

Recommendations to safe disposal of a battery pack.

- A failed battery pack shall be properly disposed of in accordance with local regulations.
- Dispose of properly: do not dispose of the battery as unsorted municipal waste. Go to Fluke's website for recycling information.
- Dispose in discharged condition and cover the battery terminals with isolation tape.

Fluke 190-104, Fluke190-204

Users Manual

Chapter 1 Using the Scope and Meter

About this Chapter

This chapter provides a step-by-step introduction to the scope and meter functions of the test tool. The introduction does not cover all of the capabilities of the functions but gives basic examples to show how to use the menus and perform basic operations.

Powering the Test Tool

Follow the procedure (steps 1 through 3) in Figure 2 to power the test tool from a standard ac outlet. See Chapter 6 for instructions on using battery power.



Turn the test tool on with the on/off key.

The test tool powers up in its last setup configuration.





Figure 2. Powering the Test Tool

Resetting the Test Tool

If you want to reset the test tool to the factory settings, do the following:



The test tool turns on, and you should hear a double beep, indicating the reset was successful.

4 Release the USER key.

Now look at the display; you will see a screen that looks like Figure 3.




Figure 3. The Screen After Reset


Navigating a Menu

The following example shows how to use the test tool's menus to select a function. Subsequently follow steps 1 through 4 to open the scope menu and to choose an item.



Note

To hide the labels for full screen view, press the CLEAR key. Press the CLEAR key again to show the labels again. This toggling enables you to check the labels without affecting your settings.







Figure 4. Basic Navigation



Note

Pressing the blue arrow keys lets you to step through a menu without changing the settings.

To exit the menu at any moment press [4] (CLOSE)

13

Hiding Key Labels and Menus

You can close a menu or hide key label at any time:



Hide any key label, press again to display the key label again (toggle function).

A displayed menu will be closed.

To display menus or key labels, press one of the yellow menu keys, e.g. the **scope** key.

You can also close a menu using the F4 soft key CLOSE.

Key Illumination

Some keys are provided with an illumination LED. For an explanation of the LED function see the table below.

		The display is off, test tool is running. See Chapter 6 'Tips' section 'Setting the Display AUTO-Off timer '. in all other situations
	OII:	in all other situations
HOLD RUN	On:	Measurements are stopped, the screen is frozen. (HOLD)
	Off:	Measurements are running. (RUN)
A B C D	On: Off:	The range key, the move up/down key, and the F1F4 key labels, apply to the illuminated channel key(s).
	On:	Manual operating mode.
MANUAL AUTO		Automatic operating mode, optimizes the trace position, range, time base and triggering (Connect-and-View TM)
TRICOER	On:	signal is triggered
TRIGGER		signal is not triggered
	Flas	hing: waiting for a trigger at 'Single
		Shot' or 'On Trigger' trace update.

Input Connections

Look at the top of the test tool. The test tool has four safety BNC jack signal inputs.

Isolated input architecture allows independent floating measurements with each input.




Figure 5. Measurement Connections

Making Input Connections

To make measurements on four channels, connect the red voltage probe to input A, the blue voltage probe to input B, the grey voltage probe to input C and the green voltage probe to input D. Connect the short ground leads of **each** voltage probe to its **own** reference potential. (See Figure 6.)

⚠ Warning

To avoid electrical shock use the insulation sleeve (Figure 1 item 4e, 5e, 6e, 7e) if you use the probes without the probe tip or the ground spring.

Notes

- To maximally benefit from having independently isolated floating inputs and to avoid problems caused by improper use, read Chapter 6: "Tips".
- For an accurate indication of the measured signal, it is necessary to match the probe to the test tool's input channel. See section 'Calibrating the voltage Probes' in Chapter 7.

15





Figure 6. Scope Connections

Adjusting the Probe Type Settings

To obtain correct measurement results the test tool probe type settings must correspond to the connected probe types. To select the input A probe setting do the following:



Selecting an Input Channel

To select an input channel, do the following:




Press the required channel key (A...D):



- the channel is turned on



- labels for the F1...F4 keys are shown. Press the channel key again to turn the labels off/on (toggle).



- the channel key illumination is turned on



If the channel key is illuminated, the RANGE and MOVE UP/DOWN keys are now assigned to the indicated channel.

To assign the RANGE and MOVE up down keys to multiple channels, keep one channel key pressed, then press another channel key.

Tip

To set multiple channels to the same range (V/div) as, for example, input A, do the following:

- Select the input A measurement function, probe setting and input options for all involved channels
- press and hold A
- press B and/or C and/or D
- release A

Notice that all pressed keys are illuminated now. The MOVE UP/DOWN key and the RANGE mV/V key applies to all involved input channels.

Displaying an Unknown Signal with Connect-and-View™

The Connect-and-View feature lets the test tool display complex, unknown signals automatically. This function optimizes the position, range, time base, and triggering and assures a stable display of virtually any waveform. If the signal changes, the setup is automatically adjusted to maintain the best display result. This feature is especially useful for quickly checking several signals.

To enable the Connect-and-View feature when the test tool is in MANUAL mode, do the following:

1 MANUAL AUTO

Perform an Auto Set. **AUTO** appears at the top right of the screen, the key illumination is off.

The bottom line shows the range, the time base, and the trigger information.

The waveform identifier (A) is visible on the right side of the screen, as shown in Figure 7. The input A zero icon at the left side of the screen identifies the ground level of the waveform.

2 MANUAL AUTO

Press a second time to select the manual range again. MANUAL appears at the top right of the screen, the key illumination is on.




Figure 7. The Screen After an Auto Set


Use the light-gray **RANGE**, **TIME** and **MOVE** keys at the bottom of the keypad to change the view of the waveform manually.

Making Automatic Scope Measurements

The test tool offers a wide range of automatic scope measurements. In addition to the waveforms you can display four numeric readings: **Reading 1 ... 4**. These readings are selectable independently, and the measurements can be done on the input A , input B, input C or input D waveform


To choose a frequency measurement for input A, do the following:





Observe that the top left of the screen displays the Hz measurement. (See Figure 8.)

To choose also a **Peak-Peak** measurement for Input B as second reading, do the following:



19




Figure 8 shows an example of the screen with two readings. The character size will be reduced when more then two readings are on.





Figure 8. Hz and V peak-peak as Scope Readings


Making Automatic Meter Measurements

The test tool offers a wide range of automatic meter measurements. You can display four large numeric readings: **Reading 1 ... 4**. These readings are selectable independently, and the measurements can be done on the input A, B, C or input D waveform. In METER mode the waveforms are not displayed. The 20 kHz HF rejection filter (see Working with Noisy Waveforms on page 29) is always on in the METER mode.

Selecting a Meter Measurement

To choose a current measurement for input A, do the following:





You will see a screen like in Figure 9.





Figure 9. Meter Screen

Making Relative Meter Measurements

A relative measurement displays the present measurement result relative to a defined reference value.

The following example shows how to perform a relative voltage measurement. First obtain a reference value:



Now the large reading is the actual input value minus the stored reference value. The actual input value is displayed below the large reading (ACTUAL: xxxx), see Figure 10.





Figure 10. Making a Relative Measurement

You can use this feature when, for example, you need to monitor input activity (voltage, temperature) in relation to a known good value.

Adjusting the reference value

To adjust the reference value, do the following:



Freezing the Screen


You can freeze the screen (all readings and waveforms) at any time.

1	HOLD RUN	Freeze the screen. HOLD appears at the right of the reading area. The key illumination is on.
2	HOLD RUN	Resume your measurement. The key illumination is off.


Using Average, Persistence and Glitch Capture

Using Average for Smoothing Waveforms

To smooth the waveform, do the following:



23



You can use the average functions to suppress random or uncorrelated noise in the waveform without loss of bandwidth. Waveform samples with and without smoothing are shown in Figure 11.

Smart average

In the normal average mode occasional deviations in a waveform just distort the averaged wave shape, and do not show up on screen clearly. When a signal really changes, for instance when you probe around, it takes quite some time before the new wave shape is stable. With smart averaging you can quickly probe around, and incidental waveform changes like a line flyback in video show up on screen instantly.





Figure 11. Smoothing a Waveform

Using Persistence, Envelope and Dot-Join to Display Waveforms

You can use Persistence to observe dynamic signals.



Select **Display: Dot-join: Off** to display measured samples only. Dot join off may be useful when measuring for example modulated signals or video signals.

Select **Display: Normal** to turn the envelope mode off and the dot-join function on.





Figure 12. Using Persistence to Observe Dynamic Signals

Displaying Glitches

To capture glitches on a waveform, do the following:




You can use this function to display events (glitches or other asynchronous waveforms) of 8 ns (8 nanoseconds, due to ADC's with 125 MS/s sampling speed) or wider, or you can display HF modulated waveforms.

When you select the 2 mV/div range Glitch Detect will automatically be turned Off. In the 2 mV/div range you can set Glitch Detect On manually.

Suppressing High Frequency Noise

Switching the glitch detection off (**Glitch**: **Off**) will suppress the high frequency noise on a waveform. Averaging will suppress the noise even more.




See also Using Average for Smoothing Waveforms on page 23.


Glitch capture and average do not affect bandwidth. Further noise suppression is possible with bandwidth limiting filters. See Working with Noisy Waveforms on page 29.

Acquiring Waveforms

Setting the Acquisition Speed and Waveform Memory Depth

To set the acquisition speed, do the following:






See also Table 2 in Chapter 8.

Selecting AC-Coupling

After a reset, the test tool is dc-coupled so that ac and dc voltages appear on the screen.

Use ac-coupling when you wish to observe a small ac signal that rides on a dc signal. To select ac-coupling, do the following:




Observe that the bottom left of the screen displays the ac-coupling icon: \mathbf{h}_{\bullet} .

You can define how Auto Set affects this setting, see Chapter 6 'Changing the Auto Set Options'.

27

Reversing the Polarity of the Displayed Waveform

To invert, for example the input A waveform, do the following:




For example, a negative-going waveform is displayed as positive-going waveform which may provide a more meaningful view. An inverted display is identified by an inversed trace identifier () at the right of the waveform, and in the status line below the waveform.

Variable Input Sensitivity

The variable input sensitivity allows you to adjust any input sensitivity continuously, for example to set the amplitude of a reference signal to exactly 6 divisions.


The input sensitivity of a range can be increased up to 2.5 times, for example between 10 mV/div and 4 mV/div in the 10 mV/div range.

To use the variable input sensitivity on for example input A, do the following:




An Auto Set will turn off the variable input sensitivity. You can now select the required input range. Keep in mind that the sensitivity will increase when you start adjusting the variable sensitivity (the displayed trace amplitude will increase).





At the bottom left of the screen the text A Var is displayed.

Selecting Variable will turn off cursors and automatic input ranging.




Note

Variable input sensitivity is not available in the Mathematics functions (+ - x and Spectrum).

Working with Noisy Waveforms

To suppress high frequency noise on waveforms, you can limit the working bandwidth to 20 kHz or 20 MHz. This function smoothes the displayed waveform. For the same reason, it improves triggering on the waveform.

To choose HF reject on for example input A, do the following:



Tip

To suppress noise without loss of bandwidth, use the average function or turn off **Display Glitches**.

29


Using Mathematics Functions +, -, x, XY-mode


You can add (+), subtract (-), or multiply (x) two waveforms. The test tool will display the mathematical result waveform and the source waveforms.

The XY-mode provides a plot with one input on the vertical axis and the second input on the horizontal axis.

The Mathematics functions perform a point-to-point operation on the involved waveforms.

To use a Mathematics function, do the following:





The sensitivity range of the mathematical result is equal to the sensitivity range of the least sensitive input divided by the scale factor.

Using Mathematics Function Spectrum (FFT)


The Spectrum function shows the spectral content of the input A, B, C or D waveform in the input trace color. It performs an FFT (Fast Fourier Transform) to transform the amplitude waveform from the time domain into the frequency domain.


To reduce the effect of side-lobes (leakage) it is recommended to use Auto windowing. This will automatically adapt the part of the waveform that is analyzed to a complete number of cycles

Selecting Hanning, Hamming or no windowing results in a faster update, but also in more leakage.

Ensure that the entire waveform amplitude remains on the screen.

To use the Spectrum function, do the following:





You will see a screen that looks like Figure 13.

Observe that the top right of the screen displays SPECTRUM.

If it displays LOW AMPL a spectrum measurement cannot be done as the waveform amplitude is too low.

31

If it displays WRONG TB the time base setting does not enable the test tool to display an FFT result. It is either too slow, which can result in aliasing, or too fast, which results in less than one signal period on the screen.

7	F1	Perform a spectrum analysis on trace A, B, C or D.
8	F2	Set the horizontal amplitude scale to linear or logarithmic.
9	F3	Set the vertical amplitude scale to linear or logarithmic.
10	F4	Turn the spectrum function off/on (toggle function).





Figure 13. Spectrum measurement

Comparing Waveforms

You can display a fixed reference waveform with the actual waveform for comparison.

To create a reference waveform and to display it with the actual waveform, do the following:





Select **On** to display the reference waveform. This can be:

- the last used reference waveform (if not available no reference waveform will be shown).
- the envelope waveform if the persistence function Envelope is on.

Select **Recall...** to recall a saved waveform (or waveform envelope) from memory and use it as a reference waveform.

Select **New...** to open the **NEW REFERENCE** menu.



If you selected **New...** continue at step 5, else go to step 6.



Select the width of an additional envelope to be added to the momentary waveform.

33


6



Store the momentary waveform and display it permanently for reference. The display also shows the actual waveform.

To recall a saved waveform from memory and use it as a reference waveform, refer also to Chapter 5 Recalling Screens with Associated Setups.

Example of reference waveform with an additional envelope of ± 2 pixels:



black pixels: basic waveform gray pixels: \pm 2 pixels envelope

1 vertical pixel on the display is 0.04 x range/div

1 horizontal pixel on the display is 0.0333 x range/div.

Pass - Fail Testing

You can use a reference waveform as a test template for the actual waveform. If at least one sample of a waveform is outside the test template, the failed or passed scope screen will be stored. Up to 100 screens can be stored. If the memory is full, the first screen will be deleted in favor of the new screen to be stored.

The most appropriate reference waveform for the Pass-Fail test is a waveform envelope.

To use the Pass - Fail function using a waveform envelope, do the following:

1 Display a reference waveform as described in the previous section "Comparing Waveforms"

2 ENTER

From the **Pass Fail Testing**: menu select

Store "Fail": each scope screen with samples outside the reference will be stored

Store "Pass": each scope screen with no samples outside the reference will be stored

Each time a scope screen is stored you will hear a beep. Chapter 3 provides information on how to analyze the stored screens.

Analyzing Waveforms

You can use the analysis functions **cursor**, **zoom** and **REPLAY** to perform detailed waveform analysis. These functions are described in Chapter 3: "*Using Cursors*, *Zoom and Replay*".

35

Fluke 190-104, Fluke 190-204

Users Manual

Chapter 2 Using The Recorder Functions

About this Chapter

This chapter provides a step-by-step introduction to the recorder functions of the test tool. The introduction gives examples to show how to use the menus and perform basic operations.

Opening the Recorder Main Menu

First choose a measurement in scope or meter mode. Now you can choose the recorder functions from the recorder main menu. To open the main menu, do the following:

Open the recorder main menu. (See Figure 14).





Figure 14. Recorder Main Menu

Plotting Measurements Over Time (TrendPlot™)

Use the TrendPlot function to plot a graph of Scope or Meter measurements (readings) as function of time.

Starting a TrendPlot Function

To start a TrendPlot, do the following:



The test tool continuously records the digital readings of the measurements and displays these as a graph. The TrendPlot graph rolls from right to left like a paper chart recorder.

Observe that the recorded time from start appears at the bottom of the screen. The present reading appears on top of the screen. (See Figure 15.)

Note

When simultaneously TrendPlotting two readings, the screen area is split into two sections of four divisions each. When simultaneously TrendPlotting three or four readings, the screen area is split into three or four sections of two divisions each.




Figure 15. TrendPlot Reading

When the test tool is in automatic mode, automatic vertical scaling is used to fit the TrendPlot graph on the screen.



Plotting Measurements Over Time (TrendPlot™)

the recorder function.

6 F1 Set RECORDER to RUN to restart.

Note

Scope TrendPlot is not possible on cursor related measurements. As an alternative you may use FlukeView logging of readings.

Displaying Recorded Data

When in normal view (NORMAL), only the twelve most recently recorded divisions are displayed on screen. All previous recordings are stored in memory.

VIEW ALL shows all data in memory:

7 Display an overview of the full waveform.


Press repeatedly to toggle between normal view (NORMAL) and overview (VIEW ALL)

When the recorder memory is full, an automatic compression algorithm is used to compress all samples into half of the memory without loss of transients. The other half of the recorder memory is free again to continue recording.

Changing the Recorder Options

At the lower right of the display, the status line indicates a time. You can choose this time to represent either the start time of the recording ('Time of Day') or the time elapsed since the start of the recording ('From Start').

To change the time reference, proceed from step 6 as follows:



Turning Off the TrendPlot Display


9 Exit the recorder function.

Recording Scope Waveforms In Deep Memory (Scope Record)

The **SCOPE RECORD** function is a roll mode that logs a long waveform of each active input. This function can be used to monitor waveforms like motion control signals or the power-on event of an Uninterruptable Power Supply (UPS). During recording, fast transients are captured. Because of the deep memory, recording can be done for more than one day. This function is similar to the roll mode in many DSO's but has deeper memory and better functionality.

Starting a Scope Record Function

To record for example the input A and input B waveform, do the following:



The waveform moves across the screen from right to left like on a normal chart recorder. (See Figure 16).




Figure 16. Recording Waveforms

Observe that the screen displays the following:

- Time from start at the top of the screen.
- The status at the bottom of the screen which includes the time/div setting as well as the total timespan that fits the memory.

Note

For accurate recordings it is advised to let the instrument first warm up for five minutes.

Displaying Recorded Data

In Normal view, the samples that roll off the screen are stored in deep memory. When the memory is full, recording continues by shifting the data in memory and deleting the first samples out of memory.

In View All mode, the complete memory contents are displayed on the screen.


Press to toggle between VIEW ALL (overview of all recorded samples) and NORMAL view.

You can analyze the recorded waveforms using the Cursors and Zoom functions. See Chapter 3: "Using Replay, Zoom and Cursors".

Using Scope Record in Single Sweep Mode

Use the recorder **Single Sweep** function to automatically stop recording when the deep memory is full.

Continue from step 3 of the previous section:



Using Triggering to Start or Stop Scope Record

To record an electrical event that causes a fault, it might be useful to start or stop recording on a trigger signal:


Start on trigger to start recording; recording stops when the deep memory is full

Stop on trigger to stop recording.

Stop when untriggered to continue recording as long as a next trigger comes within 1 division in view all mode.

To set up the test tool, continue from step 3 of the previous section:





During recording samples are continuously saved in deep memory. The last twelve recorded divisions are displayed on the screen. Use View All to display the full memory contents.

Note

To learn more about the Single Shot trigger function, see Chapter 4 "Triggering on Waveforms".




Figure 17. Triggered Single Sweep Recording

Analyzing a TrendPlot or Scope Record

From a TrendPlot or Scope Record you can use the analysis functions CURSORS and ZOOM to perform detailed waveform analysis. These functions are described in Chapter 3: "Using Replay, Zoom and Cursors".

Chapter 3 Using Replay, Zoom and Cursors

About this Chapter

This chapter covers the capabilities of the analysis functions **Cursor**, **Zoom**, and **Replay**. These functions can be used with one or more of the primary functions Scope, TrendPlot or Scope Record.

It is possible to combine two or three analysis functions. A typical application using these functions follows:


- First replay the last screens to find the screen of special interest.
- Then zoom in on the signal event.
- Finally, make measurements using the cursors.

Replaying the 100 Most Recent Scope Screens

When you are in scope mode, the test tool automatically stores the 100 most recent screens. When you press the HOLD key or the REPLAY key, the memory contents are frozen. Use the functions in the REPLAY menu to "go back in time" by stepping through the stored screens to find the screen of your interest. This feature lets you capture and view signals even if you did not press HOLD.

Replaying Step-by-Step

To step through the last scope screens, do the following:



Observe that the bottom of the waveform area displays the replay bar with a screen number and related time stamp:






Figure 18. Replaying a Waveform


The replay bar represents all 100 stored screens in memory. The licon represents the picture being displayed on the screen (in this example: SCREEN -51). If the bar is partly white, the memory is not completely filled with 100 screens.

From this point you can use the zoom and cursor functions to study the signal in more detail.

Replaying Continuously

You can also replay the stored screens continuously, like playing a video tape.

To replay continuously, do the following:



Wait until the screen with the signal event of interest appears.

3 Stop the continuous replay.

Turning Off the Replay Function



Capturing 100 Intermittents Automatically

When you use the test tool in triggered mode, 100 *triggered* screens are captured.


By combining the trigger possibilities with the capability of capturing 100 screens for later replay, you can leave the test tool unattended to capture intermittent signal anomalies. This way you could use Pulse Triggering to trigger and capture 100 intermittent glitches or you could capture 100 UPS startups.

For triggering, see Chapter 4: "Triggering on Waveforms".

Zooming in on a Waveform

To obtain a more detailed view of a waveform, you can zoom in on a waveform using the **zoom** function.

To zoom in on a waveform, do the following:



Tip

Even when the key labels are not displayed at the bottom of the screen, you can still use the arrow keys to zoom in and out. You can also use the s TIME ns key to zoom in and out.




Figure 19. Zooming in a Waveform

Observe that the bottom of the waveform area displays the zoom ratio, position bar, and time/div (see Figure 19). The zoom range depends on the amount of data samples stored in memory.

Turning Off the Zoom Function




Making Cursor Measurements

Cursors allow you to make precise digital measurements on waveforms. This can be done on live waveforms, recorded waveforms, and on saved waveforms.

Using Horizontal Cursors on a Waveform

To use the cursors for a voltage measurement, do the following:



Note

Even when the key labels are not displayed at the bottom of the screen, you still can use the arrow keys. This allows full control of both cursors while having full screen view.





Figure 20. Voltage Measurement with Cursors


The screen shows the voltage difference between the two cursors and the voltage at the cursors. (See Figure 20.)

Use horizontal cursors to measure the amplitude, high or low value, or overshoot of a waveform.

Using Vertical Cursors on a Waveform

To use the cursors for a time measurement (T, 1/T), for a mVs-mAs-mWs measurement, or for an RMS measurement of the trace section between the cursors, do the following:








Figure 21. Time Measurement with Cursors

8 Move the right cursor to the desired position on the waveform.

The screen shows the time difference between the cursors and the voltage difference between the two markers. (See Figure 21.)

9 Select **OFF** to turn off the cursors.

Notes

- For mVs select probe type 'Voltage'.
- For mAs select probe type 'Current'.
- For mWs select mathematical function x, and probe type 'Voltage' for one channel and 'Current' for the other channel.


Using Cursors on a Mathematical Result (+ - x) Waveform

Cursor measurements on, for examle, a AxB waveform give a reading in Watts if input A measures (milli)Volts and input B measures (milli)Amperes.

For other cursor measurements on, for example, a A+B, A-B or AxB waveform no reading will be available if the input A and input B measurement unit are different.


Using Cursors on Spectrum Measurements

To do a cursor measurent on a spectrum, do the following:



Making Rise Time Measurements

To measure rise time, do the following:



The reading shows the risetime from 10%-90% of the trace amplitude.




Figure 22. Risetime Measurement

Chapter 4 Triggering on Waveforms

About this Chapter

This chapter provides an introduction to the trigger functions of the test tool. Triggering tells the test tool when to begin displaying the waveform. You can use fully automatic triggering, take control of one or more main trigger functions (semi-automatic triggering), or you can use dedicated trigger functions to capture special waveforms.

Following are some typical trigger applications:

 Use the Connect-and-View[™] function to have full automatic triggering and instant display of virtually any waveform.

- If the signal is unstable or has a very low frequency, you can control the trigger level, slope, and trigger delay for a better view of the signal. (See next section.)
- For dedicated applications, use one of the three manual trigger functions:
 - Edge triggering
 - Video triggering
 - Pulse Width triggering

Setting Trigger Level and Slope

The Connect-and-View[™] function enables hands-off triggering to display complex unknown signals.


When your test tool is in manual range, do the following:



Perform an auto set. **AUTO** appears at the top right of the screen.

Automatic triggering assures a stable display of virtually any signal.

From this point, you can take over the basic trigger controls such as level, slope and delay. To optimize trigger level and slope manually, do the following:






Figure 23. Screen with all Trigger Information

4



Adjust the trigger level.

At the bottom of the screen the trigger parameters are displayed (See Figure 23). For example, **Trig: AJ** means that input A is used as the trigger source with a positive slope.

When a valid trigger signal is found, the trigger key will be lit and the trigger parameters appear in black.

When no trigger is found, the trigger parameters appear in gray, ands the key light will be off.

Using Trigger Delay or Pre-trigger

You can begin to display the waveform some time before or after the trigger point has been detected. Initially, you have a half screen (6 divisions) of pre-trigger view (negative delay).

To set the trigger delay, do the following:

5 Hold down to adjust the trigger delay.

Observe that the trigger icon **I** on the screen moves to show the new trigger position. When the trigger position moves left off of the screen, the trigger icon changes into to indicate that you have selected a trigger delay. Moving the trigger icon to the right on the display gives you a pre-trigger view. This allows you to see what happened before the trigger event, or what caused the trigger.

In case of a trigger delay, the status at the bottom of the screen will change. For example:

AJ →1500.0ms

This means that input A is used as the trigger source with a positive slope. The 500.0 ms indicates the (positive) delay between trigger point and waveform display.

When a valid trigger signal is found, the trigger key will be lit and the trigger parameters appear in black.

When no trigger is found, the trigger parameters appear in gray, ands the key light will be off.




Figure 24. Trigger Delay or Pre-trigger View

Figure 24 shows an example of a trigger delay of 500 ms (top) and an example of pre-trigger view of 8 divisions (bottom).


Automatic Trigger Options

In the trigger menu, settings for automatic triggering can be changed as follows. (See also Chapter 1: "Displaying an Unknown Signal with Connect-and-View")



Note

The TRIGGER key labels can differ depending on the latest trigger function used.



If the frequency range of the automatic triggering is set to > 15 Hz, the Connect-and-View™ function responds more quickly. The response is quicker because the test tool is instructed not to analyze low frequency signal components. However, when you measure frequencies lower than 15 Hz, the test tool must be instructed to analyze low frequency components for automatic triggering:




Select > 1 Hz and return to the measurement screen.

Triggering on Edges

If the signal is unstable or has a very low frequency, use edge triggering to obtain full manual trigger control.

To trigger on rising edges of the input A waveform, do the following:



When **Free Run** is selected, the test tool updates the screen even if there are no triggers. A trace always appears on the screen.

When **On Trigger** is selected, the test tool needs a trigger to display a waveform. Use this mode if you want to update the screen *only* when valid triggers occur.

When **Single Shot** is selected, the test tool waits for a trigger. After receiving a trigger, the waveform is displayed and the instrument is set to HOLD.

In most cases it is advised to use the Free Run mode:



Observe that the key labels at the bottom of the screen have adapted to allow further selection of specific edge trigger settings:



Users Manual

Triggering on Noisy Waveforms

To reduce jitter on the screen when triggering on noisy waveforms, you can use a trigger filter. Continue from step 3 of the previous example as follows:



When **Noise Reject** is on, an increased trigger gap will be applied.

When **HF Reject** is on, HF noise on the (internal) trigger signal will be suppressed.

Making a Single Acquisition

To catch single events, you can perform a **single shot** acquisition (one-time screen update). To set up the test tool for a single shot of the input A waveform, continue from step 3 (page 57) again:



The word MANUAL appears at the top of the screen indicating that the test tool is waiting for a trigger. As soon as the test tool receives a trigger, the waveform is displayed and the instrument is set to hold. This is indicated by the word HOLD at top of the screen.

The test tool will now have a screen like Figure 25.

Arm the test tool for a new single shot.

Tip

The test tool stores all single shots in the replay memory. Use the Replay function to look at all the stored single shots (see Chapter3).




Figure 25. Making a Single Shot Measurement

N-Cycle Triggering

N-Cycle triggering enables you to create a stable picture of for example n-cycle burst waveforms.


Each next trigger is generated after the waveform has crossed the trigger level N times in the direction that complies with the selected trigger slope.

To select N-Cycle triggering, continue from step 3 (page 57) again:

4	ENTER	Select On Trigger or Single Shot , jump to Trigger Filter .
5	ENTER	Select a Trigger Filter or set it Off .
6	ENTER	Set NCycle to On

Observe that the key labels at the bottom of the screen have been changed to allow further selection of specific N-Cycle trigger settings:

EDGE TRIG	SLOPE	LEVEL \$	TRIGGER
A B C D	[1 X]	NCYCLE ↔	OPTIONS



Traces with N-Cycle triggering (N=2) and without N-Cycle triggering are shown in Figure 26.





Figure 26. N-Cycle triggering

Triggering on Video Signals

To trigger on a video signal, first select the standard of the video signal you are going to measure:






Figure 27. Measuring Interlaced Video Signals

Select a video standard or Non interlaced... and return.


If you select Non interlaced a scan rate selection menu will open.

Trigger level and slope are now fixed.

Observe that the key labels at the bottom of the screen have been changed to allow further selection of specific video trigger settings.

Triggering on Video Frames

Use **FIELD 1** or **FIELD 2** to trigger either on the first half of the frame (odd) or on the second half of the frame (even). To trigger on the second half of the frame, do the following:



The signal part of the even field is displayed on the screen.


Triggering on Video Lines

Use **ALL LINES** to trigger on all line synchronization pulses (horizontal synchronization).



The signal of one line is displayed on the screen. The screen is updated with the signal of the next line immediately after the test tool triggers on the horizontal synchronization pulse.

To view a specific video line in more detail, you can select the line number. For example, to measure on video line 123, continue from step 6 as follows:




The signal of line 123 is displayed on the screen. Observe that the status line now also shows the selected line number. The screen is continuously updated with the signal of line 123.


Triggering on Pulses

Use pulse width triggering to isolate and display specific pulses that you can qualify by time, such as glitches, missing pulses, bursts or signal dropouts.

Detecting Narrow Pulses

To set the test tool to trigger on narrow positive pulses shorter than 5 ms, do the following:






The test tool is now prepared to trigger on narrow pulses only. Observe that the trigger key labels at the bottom of the screen have been adapted to set the pulse conditions:



To set the pulse width to 5 ms, do the following:



All narrow positive pulses shorter than 5 ms are now displayed on the screen. (See Figure 28).

Tip

The test tool stores all triggered screens in the replay memory. For example, if you setup your triggering for glitches, you can capture 100 glitches with time stamps. Use the REPLAY key to look at all the stored glitches.






Figure 28. Triggering on Narrow Glitches

Finding Missing Pulses

The next example covers finding missing pulses in a train of positive pulses. In this example it is assumed that the pulses have a 100 ms distance between the rising edges. If the time accidently increases to 200 ms, a pulse is missing. To set the test tool to trigger on such missing pulses, let it trigger on gaps bigger than about 110 ms.

Do the following:






The test tool is now prepared to trigger on pulses that are more than a selectable time in duration. Observe that the trigger menu at the bottom of the screen has been adapted to set the pulse condition:



To set the pulse width to 110 ms, continue as follows:






Figure 29. Triggering on Missing Pulses

Chapter 5 Using Memory and PC

About this Chapter

This chapter provides a step-by-step introduction to the general functions of the test tool that can be used in the three main modes: Scope, Meter, or Recorder. You will find information on computer communication at the end of this chapter.

Using the USB Ports

The test tool is provided with two USB ports:

- a USB-host port to connect an external flash memory drive ('USB-stick') for data storage.
- a mini-USB-B port which allows you to connect the test tool to a PC for remote control and data transfer under PC-control, see Using FlukeView[®] on page 74.

The ports are fully isolated from the input channels and are covered with dust covers when not in use.




Figure 30. Test Tool USB Connections

Saving and Recalling

You can:

- Save screens and setups to internal memory, and recall them again from memory. The test tool has 15 'screen and setup' memories, 2 'record and setup' memories, and 1 screen image memory. See also Table 1.
- Save up to 256 screens and setups to a USB memory device, and recall them again from memory.
- Name saved screens and setups according to your own preferences.
- Recall screens and recordings to analyze the screen image at a later date.
- Recall a setup to continue a measurement with the recalled operating configuration.

Notes

Saved data are stored in non-volatile Flash memory.

Not saved instrument data are stored in RAM memory and will be kept at least 30 seconds when the battery is removed when no power is supplied via the BC190 power adapter.

Table 1. Test Tool Internal Memory

Mode	Memory locations		
	15x	2x	1x
METER	Setup +	-	Screen image
	1 screen		
SCOPE	Setup +	Setup +	Screen image
	1 screen	100 replay	
		screens	
SCOPE REC	-	Setup +	Screen image
		record data	
TRENDPLOT	-	Setup +	Screen image
		trendplot data	

In persistence mode the most recently written trace will be saved, not all persistence traces.

In the displayed file list of stored screens and setups the following symbols are used:



setup + 1 screen



setup + replay screens/record data



setup + trendplot data




screen image (imagexxx.bmp)


Saving Screens with Associated Setups

To save for example a screen+setup in Scope mode, do the following:



From this point the screen is frozen.





To resume your measurements press



All memories in use

If no free memory locations are available a message pops up that proposes to you to overwrite the oldest data set. Do one of the following:

If you don't want to overwrite the oldest data set,

- press [3], then delete one or more memory locations, and save again.

If you want to overwrite the oldest data set,


- press F4 .


Editing names

To name the screen+setup according to your own preferences, continue from step 4 as follows:

5	F1	Open the EDIT NAME menu
6	F2	Skip to a new character position.
7	ENTER	Select another character and press ENTER to accept your choice.
		Repeat 6 and 7 until done.
8	F1	Accept the name and return to the SAVE AS menu.
9	ENTER	Highlight OK SAVE to save the actual screen using the edited name.

To modify the default name generated by the test tool, continue from step 8 as follows:





Notes

The 'record+setup' memory locations store more than just what is visible on the screen. In TrendPlot or Scope Record mode the full recording is saved. In scope mode you can save all 100 replay screens in a single record+setup memory location. The table below shows what you can store for the various test tool modes.

To save a TrendPlot press STOP first.

Saving Screens in .bmp Format (Print Screen)

To save a screen in bitmap (.bmp) format, do the following:



The file is saved using a fixed name (IMAGE) and a serial number, for example IMAGE004.bmp.

If no free memory locations are available a message pops up that proposes to you to overwrite the oldest data set. Do one of the following:

If you don't want to overwrite the oldest data set,


- press [3], then delete one or more memory locations, and save again.

If you want to overwrite the oldest data set,

- press F4 .


Deleting Screens with Associated Setups

To delete a screen and associated setup, do the following:



Recalling Screens with Associated Setups

To recall a screen+setup, do the following:




Observe that the recalled waveform is displayed and that **HOLD** appears on the screen. From this point you can use cursors and zoom for analysis or you can print the recalled screen.

To recall a screen as a reference waveform to compare it to an actually measured waveform, see Chapter 1 'Comparing Waveforms'.

Recalling a Setup Configuration


To recall a setup configuration, do the following:




From this point you continue in the new operating configuration.

Viewing Stored Screens

To scroll through the memories while looking at the stored screens, do the following:





Note:

In the VIEW mode the replay screens of a saved 'record+setup' cannot be viewed! Only the screen at the instant of saving can be reviewed in this way. To see all replay screens recall them from memory using the RECALL option.

Renaming Stored Screens and Setup Files

To modify the name of stored files, do the following:

1	SAVE	Display the SAVE key labels.	
		SAVE RECALL □ → INT FILE OPTIONS	
2	F4	Open the FILE OPTIONS menu.	
3	F1	Select the source, internal memory (INT) or a USB device.	
4		Highlight RENAME.	
5	ENTER	Accept your choice and jump to the filename field.	


6		Highlight the file to be renamed.
7	ENTER	Open the RENAME menu.
8	F2	Skip to a new character position.
9		Select another character.
	ENTER	Repeat 8 and 9 until done.
10	F1	Accept the name and return to the RENAME menu.

Copying-Moving Stored Screens and Setup Files

You can copy or move a file from internal memory to a USB device or from a USB device to internal memory.

To copy or to move a file, do the following:

1	SAVE	Display the SAVE key labels.	
		SAVE RECALL	
2	F4	Open the FILE OPTIONS menu.	
3	F1	Select the source, internal memory (INT) or a USB device. The other memory will become the destination.	
4		Highlight copy to copy or move to move (copy and delete source) a file.	
5	ENTER	Accept your choice and jump to the filename field.	



Using FlukeView®

With the FlukeView[®] software you can upload waveform data and screen bitmaps to your PC or notebook computer for further processing.

USB drivers for the test tool and a FlukeView[®] Demo version with restricted functionality are available on the CD-ROM included in the shipment.

Connecting to a Computer

To connect the test tool to a PC or notebook computer and use the FlukeView software for Windows® (SW90W), do the following:

- Use a USB-A to mini-USB-B interface cable to connect a computer to the mini USB PORT of the test tool (See Figure 31).
- Install the test tool USB drivers, see Appendix A.
- Install the FlukeView[®] Demo version. For information about installing and using the FlukeView[®]
 ScopeMeter software see the FlukeView[®] Users Manual on the CD ROM.




Figure 31. Connecting a Computer

Notes

- The optional kit SCC290 contains an activation code to convert the FlukeView[®] Demo version into a fully operational version.
- A complete FlukeView® version can be ordered using ordering code SW90W. For use with the Fluke 190-104 and Fluke 190-204 ScopeMeter test tools FlukeView® ScopeMeter release V5.0 or higher is required.
- The test tool input channels are electrically isolated from the USB port.

Chapter 6 Tips

About this Chapter

This chapter gives you information and tips on how you can make the best use of the test tool.

Using the Standard Accessories

The following illustrations show the use of the standard accessories such as voltage probes, test leads, and the various clips.




Figure 32. HF Voltage Probe Connection Using Ground Spring

Warning

To avoid electrical shock or fire, do not connect the ground spring to voltages higher than 30 Vrms from earth ground.




Figure 33. Electronic Connections for Measurements Using Hook Clips and Alligator Clip Grounding

Warning

To avoid electrical shock, re-apply the insulation sleeve (Fig. 1 item 4e-7e) over the probe tip when the hook clip is not used. This also avoids the risk of accidently interconnecting the reference contact of multiple probes when groundleads are connected.

Using the Independently Floating Isolated Inputs

You can use the independently floating isolated inputs to measure signals that are independently floating from each other.

Independently floating isolated inputs offer additional safety and measurement capabilities compared to inputs with common references or grounds.

Measuring Using Independently Floating Isolated Inputs

The test tool has independently floating isolated inputs. Each input section (A, B, C and D) has its own signal input and its own reference input. The reference input of each input section is electrically isolated from the reference inputs of the other input sections. The isolated input architecture makes the test tool about as versatile as having four independent instruments. The advantages of having independently floating isolated inputs are:

- It allows simultaneous measurement of independently floating signals.
- Additional safety. Since the commons are not directly connected, the chance of causing short circuit when measuring multiple signals is greatly reduced.

 Additional safety. When measuring in systems with multiple grounds, the ground currents induced are kept to a minimum.

Because the references are not connected together inside the test tool, each reference of the used inputs must be connected to a reference voltage.

Independently floating isolated inputs are still coupled by parasitic capacitance. This can occur between the input references and the environment, and between the input references mutually (see Figure 34). For this reason, you should connect the references to a system ground or another stable voltage. If the reference of an input is connected to a high speed and / or high voltage signal, you should be aware of parasitic capacitance. (See Figure 34, Figure 36, Figure 37 and Figure 38.)

Note

The input channels are electrically isolated from the USB port and from the power adapter input.




Figure 34. Parasitic capacitance between probes, instrument and environment

Warning

To avoid electrical shock, always use the insulation sleeve (Fig. 1 item 4e-7e) or the probe tip when using the probe reference (ground) lead. The voltage applied to the reference lead is also present on the ground ring near the probe tip, see Figure 35.




Figure 35. Probe Tip




Figure 36. Parasitic capacitance between analog and digital reference




Figure 37. Correct connection of reference leads




Figure 38. Wrong connection of reference leads

Noise that is picked up by reference lead D can be transmitted by parasitic capacitance to the analog input amplifier.

Using the Tilt Stand

The test tool is equipped with a tilt stand, allowing viewing from an angle while placed on a table. The typical position is shown in Figure 39.




Figure 39. Using the Tilt Stand

Note

An optional Hanging Hook, ordering code HH290, can be attached to the rear of the test tool. The hook enables you to hang the test tool at a convenient viewing position, for example a cabinet door or a separation wall.

Kensington®-lock

The test tool is provided with a security slot compatible with a Kensington[®] lock, see Figure 39.

The Kensington Security Slot along with a locking cable provides physical security against thefts of opportunity. Locking cables can be obtained from, for example, laptop computer accessory dealers.

Fixing the Hangstrap

A hang strap is supplied with the test tool. The figure below shows how to attach the strap correctly to the test tool.





Figure 40. Fixing the Hangstrap

Resetting the Test Tool

If you want to reset the test tool to the factory settings, without clearing the memories, do the following:



The test tool turns on, and you should hear a double beep, indicating the reset was successful.

4 USER Release.

Suppressing Key Labels and Menu's

You can close a menu or hide key label at any time:



Hide any key label, press again to display the key label again (toggle function).

A displayed menu will be closed.

To display menus or key labels, press one of the yellow menu keys, e.g. the **SCOPE** key.

You can also close a menu using the F4 softkey CLOSE.


Changing the Information Language

During operation of the test tool, messages may appear at the bottom of the screen. You can select the language in which these messages are displayed. In this example you can select English or French. To change the language from English to French, do the following:



Adjusting the Contrast and Brightness

To adjust the contrast and backlight brightness, do the following:



Note

The new contrast and brightness are stored until a new adjustment is made.

To save battery power, the test tool is in economic brightness mode when operated on the battery. The high brightness intensity increases when you connect the power adapter.

Note

Using dimmed light lengthens maximum battery power operation. See Chapter 8 'Specifications', section 'Miscellaneous'.

Changing Date and Time

The test tool has a date and time clock. For example, to change the date to 19 April, 2012, do the following:



7 ENTER

Choose **DD/MM/YY**, accept the new date.

You can change the time in a similar way by opening the **Time Adjust...** menu (steps 2 and 3.)

Saving Battery Life

When operated on the battery, the test tool conserves power by shutting itself down. If you have not pressed a key for at least 30 minutes, the test tool turns itself off automatically.

Automatic power shutdown will not occur if TrendPlot or Scope Record is on, but the backlight will dim. Recording will continue even if the battery is low, and retention of memories is not jeopardized.


To save battery life without automatic power shutdown you can use the display AUTO-off option. The display will be turned off after the selected time (30 seconds or 5 minutes).

Note

If the power adapter is connected, there is no automatic power shutdown, and the display AUTO-off function is inactive.


Setting the Power Down Timer

Initially the power shutdown time is 30 minutes. You can set the power shutdown time to 5 minutes as following:



Setting the Display AUTO-off Timer

Initially the display AUTO-off timer is disabled (no automatic display turn off). You can set the display AUTO-off timer to 30 seconds or to 5 minutes as following:



The display will be turned off after the selected time is elapsed.


To turn on the display again do one of the following:

- Press any key. The Display Auto-Off timer starts again and the display will be turned off when the time has elapsed.
- Connect the power adapter; the Auto-Off timer is inactive now.

85

Changing the Auto Set Options

With the next procedure you can choose how auto set behaves when you press the AUTO-MANUAL (auto set) key.



If the frequency range is set to > 15 Hz, the Connect-and-View function responds more quickly. The response is quicker because the test tool is instructed not to analyze low frequency signal components. However, when you measure frequencies lower than 15 Hz, the test tool must be instructed to analyze low frequency components for automatic triggering:



Select 1 Hz and up, then jump to Input Coupling:

When you press the AUTO-MANUAL (auto set) key, the input coupling can either be set to dc or left unchanged:



Select Unchanged.

When you press the **AUTO-MANUAL** (auto set) key glitch capture can either be set to On or left unchanged:



Select Unchanged.

Note

The auto set option for the signal frequency is similar to the automatic trigger option for the signal frequency. (See Chapter 4: "Automatic Trigger Options"). However, the auto set option determines the behavior of the auto set function and shows only effect when you press the auto set key.

Chapter 7 Maintaining the Test Tool

About this Chapter

This chapter covers basic maintenance procedures that can be performed by the user. For complete service, disassembly, repair, and calibration information, see the Service Manual. (www.fluke.com)

Warning

- Have an approved technician repair the product.
- Use only specified replacement parts.
- Before carrying out any maintenance, carefully read the safety information at the beginning of this manual.

Cleaning the Test Tool

Warning

Remove the input signals before you clean the test tool.

Clean the test tool with a damp cloth and a mild soap. Do not use abrasives, solvents, or alcohol. These may damage the text on the test tool.

Storing the Test Tool

If you are storing the test tool for an extended period of time, charge the Li-ion (Lithium-ion) batteries before storing.

Charging the Batteries

At delivery, the Li-ion batteries may be empty and must be charged for 5 hours (with the test tool turned off) to reach full charge.

When fully charged, the batteries provide up to 7 hours (single channel, time base slower than 1 μ s/div) of use if the backlight is dimmed (see Chapter 6 'Adjusting the Contrast and brightness).

To charge the batteries and power the instrument, connect the power adapter as shown in Figure 41. To charge the batteries more quickly, turn off the test tool.

Caution

To avoid overheating of the batteries during charging, do not exceed the allowable ambient temperature given in the specifications.

Note

No damage will occur if the power adapter is connected for long periods, e.g., during the weekend. The instrument then automatically switches to trickle charging.




Figure 41. Charging the Batteries

Alternatively, you may choose to exchange the battery (Fluke accessory BP291) with a fully charged one, and use the external battery charger EBC290 (optional Fluke accessory).

Replacing the Battery Pack

Warning

Use only the Fluke BP291 for replacement!

When no adapter power is supplied, data saved in the test tool memory is maintained if the battery is replaced within 30 seconds. To avoid loss of data, do one of the following before removing the battery:

- Store the data on a computer or a USB device.
- Connect the power adapter.

To replace the battery pack, proceed as follows:

- 1. Remove all probes and/or test leads
- 2. Remove the standup or fold it to the test tool
- 3. Unlock the battery cover (Figure 42)
- 4. Lift the battery cover and remove it, (Figure 43)
- 5. Lift one side of the battery and remove it (Figure 44)
- 6. Install a battery and close the battery cover.




Figure 42. Unlocking the Battery Cover




Figure 43. Removing the Battery Cover






Figure 44. Removing the Battery

Calibrating the Voltage Probes

To meet full user specifications, you need to adjust the voltage probes for optimal response. The calibration consists of a high frequency adjustment and a dc calibration for 10:1 probes and 100:1 probes. The probe calibration matches the probe to the input channel.

This example shows how to calibrate the 10:1 voltage probes:








Figure 45. Adjusting Voltage Probes


A message appears asking you whether to start the 10:1 probe calibration.

6 F4 Start the probe calibration.

A message appears telling you how to connect the probe. Connect the red 10:1 voltage probe to input A and to the probe calibration reference signal as shown in Figure 45.

Adjust the trimmer screw in the probe housing until a pure square wave is displayed.

For instructions to access the trimmer screw in the probe housing see the probe instruction sheet.



8 F4 Continue with DC calibration.

Automatic DC calibration is only possible for 10:1 voltage probes.

The test tool automatically calibrates itself to the probe. During calibration you should not touch the probe. A message indicates when the DC calibration has completed successfully.

9 F4 Return.


Repeat the procedure for the blue 10:1 voltage probe on input B, the gray 10:1 voltage probe on input C and the green 10:1 voltage probe on input D.

Note

When using 100:1 voltage probes, choose 100:1 attenuation to perform an adjustment.

Displaying Version and Calibration Information

You can display version number and calibration date:



The screen gives you information about the model number with software version, the serial number, the calibration number with latest calibration date, and installed (software) options.

The test tool specifications (see Chapter 8) are based on a 1 year calibration cycle.

Recalibration must be carried out by qualified personnel. Contact your local Fluke representative for recalibration.

Displaying Battery Information

The battery information screen provides information about the batterystatus and battery serial number.

To display the screen proceed from step 2 in the previous section as follows:



'Level' indicates the available battery capacity as a percentage of the present maximum battery capacity.

'Time to Empty' indicates a calculated estimate for the remaining operating time.

Parts and Accessories

The following tables list the user-replaceable parts and specific optional accessories for the various test tool models. For more optional accessories, see www.fluke.com.

To order replacement parts or additional accessories, contact your Fluke representative.

Replacement Parts

Item		Ordering Code
Power Adapter available models: Universal Europe 230 V, 50 and 60 Hz North America 120 V, 50 and 60 Hz United Kingdom 240 V, 50 and 60 Hz Japan 100 V, 50 and 60 Hz	(U)	BC190/801 BC190/813 BC190/804 BC190/806
Australia 240 V, 50 and 60 Hz Universal 115 V/230 V, 50 and 60 Hz * * UL listing applies to BC190/808 with UL listed line plug adapter for North America.	(UL)	BC190/807 BC190/808
The 230 V rating of the BC190/808 is not for use in North America. For other countries, a line plug adapter complying with the applicable National Requirements must be used.		

Replacement Parts (continued)

Item		Ordering Code
Voltage Probe Set (Red or Blue or Gray or Green), designed for use with the Fluke 190-104 and Fluke 190-204 test tool. The set includes the following items (not available separately): 10:1 Voltage Probe (red or blue or gray or green) Hook Clip for Probe Tip (black) Ground Lead with Mini Alligator Clip (black) Ground Spring for Probe Tip (black) Insulation Sleeve (black)	ŰL)	VPS410-R (red) VPS410-B (blue) VPS410-G (gray) VPS410-V (green)
See Figure 1 on page 2 for item reference.		
See the VPS410 instruction sheet for voltage/CAT ratings.		
Replacement Set for Voltage Probe	(UL)	RS400
The set includes the following items (not available separately): 1x Hook Clip for Probe Tip (black) 1x Ground Lead with Mini Alligator Clip (black) 2x Ground Spring for Probe Tip (black) 2x Insulation Sleeve for Probe Tip (black)		
See Figure 1 on page 2 for item reference.		
See the VPS410 instruction sheet for voltage/CAT ratings.		
Li-ion battery 7 hours operating capacity (52 Wh)		BP291
Hangstrap		946769

Optional Accessories

Item	Ordering Code
Probe Accessory Extension Set	AS400
The set includes the following items (not available separately): 1x Industrial Alligator for Probe Tip (black) 1x 2-mm Test Probe for Probe Tip (black) 1x 4-mm Test Probe for Probe Tip (black) 1x Industrial Alligator for 4 mm Banana Jack (black) 1x Ground Lead with 4-mm Banana Jack (black)	
Software & Carrying Case Kit.	SCC290
Set contains the following parts: • FlukeView Software activation key, to convert the FlukeView demo version into an operational version. • Hard Shell Carrying Case C290	
FlukeView® ScopeMeter® Software for Windows® (full version)	SW90W
Hard Shell Carrying Case	C290
External Battery Charger, charges BP291 externally using BC190	EBC290
High Working Voltage Ruggedized Probe, 100:1, bicolor (red/black), 150 MHz, category rating 1000V CAT III / 600V CAT IV, working voltage (between probe tip and reference lead) 2000V in a CAT III environment/ 1200V in a CAT IV environment.	VPS420-R
Hanging Hook; allows the test tool to be hung on a cabinet door or separation wall.	HH290

Optional accessories (continued)

50 Ohm Coaxial Cable Set; includes 3 cables (1 red, 1 gray, 1 black), 1.5 m length with safety designed insulated BNC connectors.	PM9091
50 Ohm Coaxial Cable Set; includes 3 cables (1 red, 1 gray, 1 black), 0.5 m length with safety designed insulated BNC connectors.	PM9092
Safety designed BNC T-piece, Male BNC to dual female BNC (fully isolated).	PM9093

Troubleshooting

The Test Tool Shuts Down After a Short Time

- The batteries may be empty. Check the battery symbol at the top right of the screen. A symbol indicates that the batteries are empty and must be charged. Connect the BC190 power adapter.
- The test tool is still on but the 'display auto off' timer is active, see Chapter 6 'Setting the Display AUTO-off Timer'. To turn the display on press any key (restarts the 'display AUTO-off' timer), or connect the BC190 power adapter.

The Screen Remains Black

Make sure that the test tool is on (press



You might have a problem with the screen contrast.
 Press USER, then press F4 . Now you can use the arrow keys to adjust the contrast.

The display 'auto off' timer is active, see Chapter 6
'Setting the Display AUTO-off Timer'. To turn the
display on press any key (restarts the 'display AUTO off' timer), or connect the BC190 power adapter.

The Test Tool Cannot Be Turned Off

If the test tool cannot be turned off due to a software hangup, do the following:

Keep the ON/OFF key pressed for at least 5 seconds.

FlukeView Does Not Recognize The Test Tool

- Make sure that the test tool is turned on.
- Make sure that the interface cable is properly connected between the test tool and the PC. Use only the test tool mini USB port for communication with a computer!
- Make sure that the USB driver has been correctly installed, see Appendix A.

Battery Operated Fluke Accessories Do Not Function

 When using battery operated Fluke accessories, always first check the battery condition of the accessory with a Fluke multimeter.

Chapter 8 Specifications

Introduction

Performance Characteristics

FLUKE guarantees the properties expressed in numerical values with the stated tolerance. Specified non-tolerance numerical values indicate those that could be nominally expected from the mean of a range of identical ScopeMeter test tools.

The Test Tool meets the specified accuracy 30 minutes and two complete acquisitions after power on. Specifications are based on a 1-year calibration cycle.

Environmental Data

The environmental data mentioned in this manual are based on the results of the manufacturer's verification procedures.

Safety Characteristics

The test tool has been designed and tested in accordance with Standards EN/IEC 61010.1 (2001-02) Pollution Degree 2 (According to CE marking), ANSI/ISA S82.01 (1994), CAN/CSA-C22.2 No. 1010.1 (including approval), Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use.

This manual contains information and warnings that must be followed by the user to ensure safe operation and to keep the instrument in a safe condition. Use of this equipment in a manner not specified by the manufacturer may impair protection provided by the equipment.

Four Input Oscilloscope

Isolated Inputs A,B, C and D (Vertical)

Bandwidth, DC Coupled FLUKE 190-204 FLUKE 190-104	
Lower Frequency Limit, AC Coupled with 10:1 probedirect (1:1)	
Rise Time FLUKE 190-204 FLUKE 190-104	
Analog Bandwidth Limiters	20 MHz and 20 kHz
Input Coupling	AC, DC
Polarity	Normal, Inverted
Sensitivity Ranges with 10:1 probe2 direct (1:1)	
Dynamic Range	
Trace Positioning Range	±4 divisions
Input Impedance on BNC DC Coupled 1 M Ω (±	1 %)//14 pF (±2 pF)

Max. Input Voltage with 10:1 probe
Vertical Accuracy±(2.1 % + 0.04 range/div) 2 mV/div:±(2.9 % + 0.08 range/div)
For voltage measurements with 10:1 probe, add probe accuracy, see section '10:1 Probe' on page 112
Digitizer Resolution8 bits, separate digitizer for each input
Horizontal
Maximum Time Base Speed 10 ns/div
Minimum Time Base Speed (Scope Record) 2 min/div
Real Time Sampling Rate (for both inputs simultaneously)
FLUKE190-204:
10 ns to 4 μs /divup to 2.5 GS/s
10 ns to 4 μs /div (3 or 4 channel) up to 1.25 GS/s
10 μs to 120 s/div20 MS/s
FLUKE 190-104:
20 ns to 4 μs /divup to 1.25 GS/s
10 μs to 120 s/div20 MS/s
Record Length: see table below.

Table 2. Record Lenth (Samples/points per input)			
Mode	Glitch Detect On	Glitch Detect Off	Max. Samplerate
Scope - Normal	300 min/max pairs	3k true samples compressed into 1 screen (300 samples per screen)	2.5 GS/s (FLUKE 190-204 and 1 or 2 channels on)
Scope - Fast	300 min/max pairs	300 true samples	1.25 GS/s (All models and 3 or 4 channels on)
Scope - Full	300 min/max pairs	10k true samples, compressed into 1 screen. Use Zoom and Scroll to see waveform details	of 4 channels on)
Scope Record Roll		30k to 37.5k samples	4x 125 MS/s
Trend Plot		> 18k min/max/ average values per measurement	Up to 5 measurements per second

Glitch Detection	
5 μs to 120 s/div	displays glitches as fast as 8 ns
Waveform Display	A, B, C, D,
Ma	ath (+, -, x, X-Y mode, spectrum)
Normal, A	verage, Persistence, Reference
Time Base Accuracy	±(100 ppm + 0.04 div)

Trigger and Delay

Trigger Modes	Automatic, Edge,
	Video, Pulse Width, N-Cycle
Trigger Delay	up to +1200 divisions
Pre Trigger View	one full screen length
Delay	12 div to +1200 div
Max. Delay	60 s at 5 s/div

Automatic Connect-and-View Trigger

Source	A, B, C, D
Slope	Positive, Negative, Dual
:	

Edge Trigger

Screen UpdateFree Run, On Trigger, Single Shot	
Source A, B, C, D	
Slope Positive, Negative, Dual	
Trigger Level Control Range ±4 divisions	
Trigger Sensitivity DC to 5 MHz at >5 mV/div	
150 MHz (FLUKE 190-104) 2 divisions	

Video Trigger

Standards	.PAL, PAL+, NTSC, SECAM, Non-interlaced
Modes	Lines, Line Select, Field 1 or Field 2
Source	А
Polarity	Positive, Negative
Sensitivity	0.7 division sync level

Pulse Width Trigger

Screen Update On Trigger, Single Shot
Trigger Conditions T, >T, =T (± 10 %), $\neq T(\pm 10$ %)
SourceA
Polarity Positive or negative pulse
Pulse Time Adjustment Range0.01 div. to 655 div.
with a minimum of 300 ns ($<$ T, $>$ T) or 500 ns ($=$ T, \neq T),
a maximum of 10 s,
and a resolution of 0.01 div. with a minimum of 50 ns

Continuous Auto Set

Autoranging attenuators and time base, automatic Connect-and-View™ triggering with automatic source selection.

Modes

Normal	15 Hz to max. Dandwidtr
Low Frequency	1 Hz to max. bandwidth
Minimum Amplitude A, B, C,	D
DC to 1 MHz	10 mV
1 MHz to max_bandwidth	20 m\

Automatic Capturing Scope Screens

Capacity100 Scope Screens

For viewing screens, see Replay function.

Automatic Scope Measurements

The accuracy of all readings is within \pm (% of reading + number of counts) from 18 °C to 28 °C. Add 0.1x (specific accuracy) for each °C below 18 °C or above 28 °C. For voltage measurements with 10:1 probe, add probe accuracy, see section '10:1 Probe' on page 112. At least 1.5 waveform period must be visible on the screen.

General

Inputs A, B,	C and D
DC Common Mode Rejection (CMRR)	.>100 dB
AC Common Mode Rejection at 50, 60, or 400 Hz	>60 dB

DC Voltage (VDC)

Do Voltage (VDO)	
Maximum Voltage with 10:1 probedirect (1:1)	
Maximum Resolution with 10:1 probedirect (1:1)	
Full Scale Reading	999 counts
Accuracy at 5 s to 10 µs/div 2 mV/div5 mV/div to 100 V/div Normal Mode AC Rejection at 5	±(1.5 % + 5 counts)

AC Voltage (VAC)

Maximum Voltage with 10:1 probe 1000 V direct (1:1) 300 V
Maximum Resolution with 10:1 probe
Full Scale Reading999 counts
Accuracy DC coupled: DC to 60 Hz±(1.5 % +10 counts)
AC coupled, low frequencies: 50 Hz direct (1:1)
AC or DC coupled, high frequencies: 60 Hz to 20 kHz
Normal Mode DC Rejection>50 dB

Fluke 190-104, Fluke190-204

Users Manual

All accuracies are valid if:

- The waveform amplitude is larger than one division
- At least 1.5 waveform period is on the screen

AC+DC Voltage (True RMS)

	1000 V
Maximum Resolution	
with 10:1 probe	1 mV
direct (1:1)	100 μV
Full Scale Reading	1100 counts
Accuracy	
DC to 60 Hz	±(1.5 % + 10 counts)
	±(2.5 % + 15 counts)
20 kHz to 1 MHz	±(5 % + 20 counts)
1 MHz to 25 MHz	±(10 % + 20 counts)
For higher frequencies the	instrument's frequency roll off
starts affecting accuracy.	. ,

Amperes (AMP)

With Optional Current Pro	bbe or Current Shunt
Ranges	same as VDC, VAC, VAC+DC
Probe Sensitivity	100 µV/A, 1 mV/A, 10 mV/A,
100 mV/A, 400 m\	V/A, 1 V/A, 10 V/A, and 100 V/A

Accuracy	same as VDC, VAC, VAC+DC
(a	dd current probe or current shunt accuracy)

Peak

Modes	. Max peak, Min peak, or peak-to-peak
	1000 V
	on 10 mV 1 mV
Full Scale Reading	,800 counts
•	peak

Frequency (Hz)

Range	1.000 Hz to full bandwidth
Full Scale Reading	999 counts
Accuracy	
1 Hz to full bandwidth	±(0.5 % +2 counts)
(5 s/div to 10 ns/div and 10	periods on the screen).

Duty Cycle (DUTY)

Range	4.0 % to 98.0 %
Resolution	0.1 % (when period > 2 div)
Full Scale Reading	999 counts (3-digit display)
Accuracy (logic or pulse)	±(0.5 % +2 counts)
Pulse Width (PULSE)	
Resolution (with GLITCH off)1/100 division
Full Scale Reading	999 counts
Accuracy 1 Hz to full bandwidth	±(0.5 % +2 counts)
Vpwm	
!	sure on pulse width modulated ke motor drive inverter outputs
on the av	now the effective voltage based verage value of samples over a r of periods of the fundamental frequency
Accuracy	as Vrms for sinewave signals

Power (A and B, C and D)

	ratio between Watts and VA0.00 to 1.00
corresponding s	RMS reading of multiplication samples of input A or C (volts) and Input B or D (amperes)999 counts
	Vrms x Arms999 counts
VA Reactive (VAR)Full Scale Reading	$\sqrt{((VA)^2-W^2)}$ 999 counts
Phase (A and B, C and	D)
Range	180 to +180 degrees
Resolution	1 degree
	±2 degrees ±3 degrees

Temperature (TEMP)

With Optional Temperature Probe (°F not for Japan)

· · · · · · · · · · · · · · · · · · ·	
Ranges (°C or °F)40.0 to +100.0 °)
-100 to +250 °)
-100 to +500 °)
-100 to +1000 s)
-100 to + 2500 °)
Probe Sensitivity 1 mV/°C and 1 mV/°F	:
Accuracy ±(1.5 % + 5 counts))

(add temperature probe accuracy for overall accuracy)

Decibel (dB)

dBV	dB relative to one volt
dBm	. dB relative to one mW in 50 Ω or 600 Ω
dB on	VDC, VAC, or VAC+DC
Accuracy	same as VDC, VAC, VAC+DC

Meter

Four of the Automatic Scope Measurements as defined above may be displayed at the same time, using larger screen area for convenient reading, suppressing the scope waveform information. For specifications see Automatic scope Measurements above.

Recorder

TrendPlot (Meter or Scope, Channel A ,B, C, D)

Chart recorder that plots a graph of min and max values of Meter or Scope measurements over time.

Measurement Speed	>5 measurements/s
Time/Div	5 s/div to 30 min/div
Record Size (min, max, avera	age)≥18000 points
Recorded Time Span	60 min to 22 days
Time Reference	time from start, time of day

Scope Record

Records scope waveforms in deep memory while displaying the waveform in Roll mode.

Source	Input A, B, C, D
Max. Sample Speed (5 ms/c	div to 1 min/div)4x125 MS/s
Glitch capture (5 ms/div to 1	min/div)8 ns
Glitch capture (2 min/div)	8 ns
Time/Div in normal mode	5 ms/div to 2 min/div
Record Size	.30k to 37.5k points per trace
Recorded Time Span	6 s to 48 hours

Acquisition Modes	Single Sweep
·	Continuous Roll
	Start/Stop on Trigger
Time Reference	time from start, time of day

Zoom, Replay and Cursors

Zoom

Zoom ranges from full record overview to detailed view of individual samples

Replay

Displays a maximum of 100 captured quad input Scope screens.

Replay modes Step by Step, Replay as Animation

Cursor Measurements

Cursor Modes	single vertical cursor dual vertical cursors dual horizontal cursors (Scope mode)
Markers	automatic markers at cross points
Measurements	value at cursor 1 value at cursor 2
differe	ence between values at cursor 1 and 2 time between cursors, RMS between cursors
	Time of Day (Recorder modes)
	Time from Start (Recorder modes)
	Rise Time, fall time
Ax	s (current over time between cursors)
Vx	s (voltage over time between cursors)
Wxs(p	ower over time between cursors using
	powertrace AxB or CxD)

Users Manual

Miscellaneous

Display

Display Auto-OFF time (battery saving).......30 seconds, 5 minutes or disabled



Rechargeable Li-ion Battery (model BP 291):

toonargoable Erion Battery (moder Br 201).			
Operating Time up to 7 hours (Low Intensity)			
Charging Time 5 hours			
Capacity/Voltage 52 Wh / 10.8 V			
Life Time (> 80 % capacity) 300x charge/discharge			
Allowable ambient			
temperature during charging: 0 to 40 °C (32 to 104 °F)			
Auto power down			
time (battery saving): 5 min, 30 min or disabled			

Power Adapter BC190:

- BC190/801 European line plug 230 V ±10 %
- BC190/813 North American line plug 120 V ±10 %
- BC190/804 United Kingdom line plug 230 V ±10 %
- BC190/806 Japanese line plug 100 V ±10 %
- BC190/807 Australian line plug 230 V ±10 %
- BC190/808 Universal switchable adapter 115 V ±10 % or 230 V ±10 %, with plug EN60320-2.2G

Line Frequency 50 and 60 Hz

Probe Calibration

Manual pulse adjustment and automatic DC adjustment with probe check

Memory

- a quad (4 channel) input TrendPlot
- a guad (4 channel) input Scope Record
- 100 quad (4 channel) input Scope screens (Replay)

Mechanical

Size	. 265 x 190 x 70 mm (10.5 x 7.5 x 2.8 in)
Weight	2.2 kg (4.8 lbs) including battery

Interface Ports

Two USB ports provided. Ports are fully insulated from instrument's floating measurement circuitry.

- A USB-host port directly connects to external flash memory drive ('USB-stick') for storage of waveform data, measurement results, instrument settings and screen copies.
- A mini-USB-B is provided which allows for interconnection to PC for remote control and data transfer using SW90W (FlukeView[®] software for Windows [®]).
- Remote control and data transfer via mini-USB not possible when saving or recalling data to or from the USB-stick.

Environmental

EnvironmentalMIL-PRF-28800F, Class 2
Temperature Operating: battery installed
$\begin{array}{llllllllllllllllllllllllllllllllllll$
Altitude Operating: CATIII 600V, CATII 1000V 3 km (10 000 feet) CATIV 600V, CATIII 1000V
Vibration (Sinusoidal) max. 3 g
Vibration (Random) 0.03 g ² /Hz
Shock max. 30 g

Electromagnetic Compatibility (EMC)			
Emission and immunity	EN-IEC61326-1 (2005-12)		
Enclosure Protection	IP51, ref: IEC60529		



Designed for 1000 V Measurement Category III, 600 V Measurement Category IV, Pollution Degree 2, per:

- EN/IEC 61010.1 (2001-02) Pollution Degree 2 (According to CE marking)
- ANSI/ISA S82.01 (1994)
- CAN/CSA-C22.2 No. 1010.1 (including approval)

⚠ Max. Input Voltages

Directly	300 V CAT IV
Via 10:1 probe	1000 V CAT III
	600 V CAT IV

Max. Floating Voltage

From any terminal to earth ground	1000 V	CAT III
	600 V	CAT IV
Between any terminal	1000 V	CAT III
	600 V	CAT IV

Voltage ratings are given as "working voltage". They should be read as Vac-rms (50-60 Hz) for AC sinewave applications and as Vdc for DC applications.

MAX. INPUT VOLTAGE (Vrms)




Figure 46. Max. Input Voltage vs. Frequency

Note

Measurement Category IV refers to the overhead or underground utility service of an installation.

Measurement Category III refers to distribution level and fixed installation circuits inside a building..




Figure 47. Safe Handling: Max. Voltage Between Scope References, and Between Scope References and earth ground.

10:1 Probe

Accuracy

Probe accuracy when adjusted on the test tool:	
DC to 20 kHz±	1 %
20 kHz to 1 MHz±	2 %
1 MHz to 25 MHz±	3 %
For higher frequencies the probe's roll off starts affecti	ing
he accuracy.	

For further probe specifications see the instruction sheet supplied with the VPS410 probe set.

Electromagnetic Immunity

The Fluke 190-104 and Fluke 190-204 test tools, including standard accessories, conform with the EEC directive 2004/108/EC for EMC immunity, as defined by EN-61326-1, with the addition of the following tables.

Trace disturbance with VPS410 voltage probe shorted (Scope Mode, 10 ms/div):

Table 3. (E - 3V/m)

Frequency	No Disturbance	Disturbance < 10% of full scale	Disturbance > 10% of full scale
80 MHz – 450 MHz	All other ranges	100 and 200 mV/div	2.5, 10, 20, 50 mV/div
450 MHz – 2.7 GHz	All ranges		

Fluke 190-104, Fluke190-204

Users Manual

Index

—1—

10:1 Voltage, 95 100:1 Voltage probe, 97

—A—

Accessories, 75, 94
Accessory Extension Set, 97
AC-Coupling, 27
Acquiring the Waveform, 27
Acquisition Speed, 27
Add waveforms, 30
Altitude, 110
Amperes, 104
Analysis Functions, 45, 107
AS400 Accessory Extension Set, 97
Auto Set, 102

Automatic Connect-and-View Trigger, 102 Automatic Power Shutdown, 84 Automatic Scope Measurements, 19 Automatic Triggering, 56 Average, 23, 26 smart, 24

—B—

Bandwidth, 100 Battery Charging, 2, 88 Indicator, 88 information, 93 Life, 84 Replacing, 89 Battery Charger, 97 battery pack safe disposal, 9 safe transport, 8 safe use, 7, 8 storage, 7 BC190 safety, 4 BC190 Power Adapter, 94 BP291 Li-ion Battery, 95

<u></u>с—

C290 Hard Case, 97
Calibrating the Test Tool, 93
Calibrating Voltage Probes, 91, 108
calibration
date, 93
number, 93
Capturing 100 Screens, 47, 102
Case, 97
Charge Time, 108
Charging, 88
Cleaning, 87

Fluke 190-104, Fluke 190-204

Users Manual

Clear Menu, 14, 82 Comparing Waveforms, 33 Connect-and-View, 18, 53, 102 Connecting a Computer, 74 Connections, 15 Contrast, 83 Copy files, 73 Cursors Measurements, 49

—D—

Date, 83
DC Voltage (VDC), 103
DC-Coupling, 27
Decibel (dB), 106
Delay, Trigger, 101
Deleting Screens, 70
Display, 108
Display AUTO-off, 84, 85
Displaying Recorded Data, 39, 42
Documenting Screens, 74
Dot-Join, 25
Dual Slope Triggering, 54
Duty Cycle, 105

—E—

Earth Ground, 6

EBC290 Battery Charger, 97
Edge Trigger, 57, 102
Electrical Shock, 5
Electrically Floating, 6
Electromagnetic Compatibility
emission, 110
immunity, 110
EMC, 110
Emission, 110
Envelope Mode, 25
Environmental, 110
Environmental Data, 99

—F—

FFT, 31
Filtering, 29
FlukeView, 97
FlukeView demo package, 3
FlukeView®
 activation code, 74
 Activation Key, 3
 demo version, 74
 installation, 74
 Software, 3
Freezing the Screen, 23
Frequency (Hz), 104
Frequency Response, 100

—G—

Glitch Capture, 26 Ground Leads, 3, 95 Ground Spring, 3, 95

—H—

Hanging Hook, 80, 97 Hangstrap, 81 Hard Case, 3, 97 HF Voltage Probe Connection, 76 HH290 Hanging Hook, 97 Hook Clips, 3, 95 Horizontal Cursors, 49 Humidity, 110 Hz, 104



Immunity, 110
Information Language, 82
Input A Measurement, 19
Input B Measurement, 19
Input Connections, 15
Input Impedance, 100
Input Sensitivity
Variable, 28

Insulation Sleeve, 3, 95 Interface, 109 Inverted Waveform, 28 Isolated, 6



Key light, 14

—L—

Language, 82 Li-ION Battery, 88 Lissajous, 30 locking cable, 80

—M—

Maintenance, 87 mAs, 50 Mathematics Functions, 30 Max. Floating Voltage, 111 Max. Input Voltage, 111 Power, 105 Measurement Category, 6 Measurement Connections, 15 Measurements, 19 Mechanical, 109 Memory, 108 model number, 93 Move files, 73 Multiply waveforms, 30 mVs, 50 mWs. 50

—N—

Navigating a Menu, 13 N-Cycle Triggering, 59 Noise suppression, 26 Noisy Waveforms, 29 trigger on, 58 Non interlaced video, 60

Operating Time, 108 Oscilloscope, 100

—P—

Parts, 94
Pass - Fail Testing, 34
Peak, 104
Performance Characteristics, 99

Persistence, 25 Phase, 105 Polarity, 28 Power, 108 Power Adapter, 94 Power Down Timer. 84 Power Factor, 105 Power Factor (Power...), 19 power shutdown, 84 Powering the Test Tool, 11 Pre Trigger, 55 Print Screen, 69 Probe Accessory Extension Set, 97 Probe Calibration, 91, 108 Probe Replacement Set, 95 Probe Type, 16, 21 Pulse Trigger, 62 Pulse Width, 105 Pulse Width Trigger, 102

—R—

Readings, 19, 20 Recalibrating, 93 Recalling Screens, 70 Recalling Setups, 71 Record Length, 101 Record+Setup Memory, 69

Fluke 190-104, Fluke 190-204

Users Manual

Recorder, 106 Recorder Options, 40 Recording Waveforms, 41 Reference value, 22 Reference waveform, 33 Relative Measurements, 21 Renaming files, 72 Replaceable Parts, 94 Replacement Set, 95 Replacing Batteries, 89 Replay, 45, 69, 107 Reset, 12 Resetting the Test Tool. 12. 81 Reversing the Polarity, 28 Rise Time, 52, 100 RMS, 50 RMS Voltage, 103 Roll Mode Function, 106 RS400 Replacement Set, 95

—S—

Safety, 111 Safety Characteristics, 99 Safety Requirements, 1 Sampling Rate, 100 Saving, 67 Saving Screens, 69 SCC290.97 Scope, 100 Scope Cursor Measurements, 107 Scope Measurements, 19 Scope Record, 106 start on trigger, 43 stop on trigger, 43 Scope Record, 41 Screen Contrast, 83 Screen Without Menus, 14, 82 security, 80 serial number, 93 Shock, 110 Single Shot, 58 Single Sweep Mode, 42 Slope, 102 Slow Variations, 38 Smoothing waveforms, 23, 26 Software, 97 Software Version, 93 Specifications, 99 Spectrum, 31 Spike Capture, 26 Stand, 80 Storing, 87 Subtract waveforms, 30 SW90W Software, 3, 74, 97

—T—

Temperature, 106, 110 Tilt Stand. 80 Time, 83 Time Base, 100 time measurement. 50 TrendPlot. 106 Trigger Delay, 55, 101 Level. 54 Modes, 101 Pre-trigger, 55 Slope, 54 Trigger Sensitivity, 102 Triggering Automatic, 56, 102 Dual Slope, 54 N-Cycle, 59 On Edges, 57 On Pulses, 62 On Video, 60 On Waveforms, 53 Troubleshooting, 99 TV Trigaering, 60

—U—

Unpacking, 2 USB drivers, 74 USB Interface Cable, 3 USB Ports, 65 USB stick, 65



VA, 105 VA (Power...), 19 VA Reactive, 105 VA Reactive (Power...), 19 Vertical Accuracy, 100 Vertical Cursors, 50 Vibration, 110
Video Frames, 61
Video Lines, 61
Video Trigger, 60, 102
Viewing Stored Screens, 71
Voltage Probe Set, 3
Voltage probe set 100:1, 97
Voltage Probes, 3, 95
VP410 Voltage Probe, 95
VPS420-R probe 100:1, 97
Vpwm, 19, 105

-W-

Watt, 105 Watts (Power...), 19 Waveform Mathematics, 30
WAVEFORM OPTIONS, 23
Waveform storage, 67
Waveforms
comparing, 33

—X—

XY mode, 30

—Z—

Zoom, 48, 107

Fluke 190-104, Fluke 190-204 Users Manual

Appendices

Appendix	Title	Page
Α	Installing USB Drivers	A-1
В	Battery Pack MSDS	B-1

Appendix A Installing USB Drivers

Introduction

The Fluke 190 Series II ScopeMeter comes with a USB interface (connector: USB type "B mini") for communication with a computer. To be able to communicate with the instrument, drivers need to be loaded onto the computer. This document describes how to install the drivers on a Windows XP computer. Installing on other Windows versions will be similar.

Drivers for Windows XP, Vista and Win 7 are available from the Windows Driver Distribution Center, and can be downloaded automatically if your computer is connected to the internet.

The drivers have passed Windows Logo Verification and are signed by Microsoft Windows Hardware Compatibility Publisher. This is required for installation on Win 7.

Note:

The Fluke 190 Series II instrument requires two drivers to be loaded in sequence.

- 1st it requires installation of the Fluke 190 ScopeMeter USB driver
- 2nd it requires installation of the Fluke USB Serial port

Both of these drivers need to be installed to be able to communicate with the ScopeMeter!

Installing the USB Drivers

To install the USB drivers, do the following:

1 Connect the Fluke 190 Series II instrument to the PC. The USB cable can be plugged in and out (hot-swap) when both the computer and the instrument are on. It is not required to power off.

When there is no driver loaded for the Fluke 190 Series II instrument, Windows will show that there is New Hardware detected, and the Wizard for installing new hardware will open.

Depending on your PC settings, Windows may ask for permission to search the Windows Update Web site on the internet for the latest revision. When you have an internet connection it is advised to select "Yes" and click Next. To install drivers from the CD-ROM or from a location on the hard drive select "No, not this time".




2 In the following window click 'Next' to install the software automatically.

Windows will download the drivers automatically from the Windows Driver Distribution Center on the internet. If there is no connection to the internet, you need to load the CD-ROM, supplied with the ScopeMeter, which contains the drivers.

3 Follow the instructions on screen.

When the driver has finished installation click 'Finish' to complete the first step of the driver installation.





4 After completing the first step the New Hardware Wizard will start again to install the USB Serial Port Driver.


Click 'Next' to install the software automatically.

Windows will download the drivers automatically from the Windows Driver Distribution Center on the internet. If there is no connection to the internet, you need to load the CD-ROM, supplied with the ScopeMeter, which contains the drivers.

5 Follow the instructions on screen.

When the driver finished installation click 'Finish' to complete the final step of the driver installation.

You are now ready to use the ScopeMeter with FlukeView Software SW90W from version V5.0 onwards.






To check if the drivers are loaded properly, connect the ScopeMeter 190 Series II to your computer and open the Device Manager. (See the Help file of your computer how to open the device manager for your Windows version)

From the device manager click on the + sign to Expand the 'Universal Serial Bus controllers'. The 'Fluke 190 ScopeMeter' should be listed here.

From the device manager click on the + sign to Expand the 'Ports (COM & LPT)' Universal Serial Bus controllers. The 'Fluke USB Serial Port COM(5)' should be listed here.

Note that the COM port number may differ and is automatically assigned by Windows.



Notes

- Sometimes application software may require a different port number. (for example in the range Com 1..4).
 In this situation the COM port number can be changed manually.
 To manually assign a different COM port number right click on 'Fluke USB Serial Port COM(5)' and select properties. From the Properties menu, select the Port Settings tab, and click 'Advanced...' to change the port number.
- Sometimes other applications installed on the PC automatically occupy the newly created port. On most situations it is sufficient to unplug the Fluke 190 Series II ScopeMeter USB cable shortly and then reconnect the cable.

Appendix B Battery Pack MSDS

Li-ion Battery Pack

Contact Fluke for a Battery Material Safety Data Sheet (MSDS) or Compliance Information.