



# Massey Harris Massey Ferguson

Service Manual

## MF202 & MF204

### Ag & Industrial

Service Manual

JENSALES.COM

or Call 800-443-0625



THIS IS A MANUAL PRODUCED BY JENSALES INC. WITHOUT THE AUTHORIZATION OF  
MASSEY HARRIS MASSEY FERGUSON OR IT'S SUCCESSORS. MASSEY HARRIS MASSEY FERGUSON AND IT'S SUCCESSORS  
ARE NOT RESPONSIBLE FOR THE QUALITY OR ACCURACY OF THIS MANUAL.

TRADE MARKS AND TRADE NAMES CONTAINED AND USED HEREIN ARE THOSE OF OTHERS,  
AND ARE USED HERE IN A DESCRIPTIVE SENSE TO REFER TO THE PRODUCTS OF OTHERS.

MH-S-MF202,204

Type:	Continental Z134
Fuel:	gasoline
Aspiration:	natural
Displacement:	134 ci [2.2 L]
Power:	35 hp [26.1 kW]
Cooling:	liquid
Chassis:	4x2 2WD
Brakes:	drum

1958: 301172  
 1959: 303158  
 1960: 305108  
 1961: 306169  
 1962: 306779  
 1963: 307923  
 1964: 309222  
 1965: 310067  
 1966: 311084  
 1967: 9A1001

Ford/ Massey Gray (M.F. Light Gray)	M1022	CML-0002
Massey Ferguson Charcoal Gray	M1056	CML-0038
Massey Ferguson Silver Gray		CML-2006
Massey Ferguson Industrial Yellow		CML-3045
Light Gray	M1011	CML-0008
Ferguson Gray	30419	Stock #476
Flint Gray	M1026	CML-0030
Flint Gray Metallic	M1025	Stock #449
French Silver Mist Gray	M1071	CML-2000
Green Metallic (Ferguson)		CML-6524
Red	M1041	Stock #467
Red 1956- 1971	M1017	CML-5051
Straw Yellow	M1020	CML-3052
Dark Safety Yellow		CML-3019
Industrial Yellow	M1023	CML-3002
Construction Yellow	M1055	CML-3003
Apache Yellow		Stock #468
Bright Industrial Yellow		CML-3028
Metallic Brown		CML-8004

INDEX

MF 202-204 SERVICE MANUAL  
1448 800 M1

Steering .....

Engine .....

Clutches .....

Instant Reverse Transmission .....

Manual Shuttle Transmission (Single Clutch) .....

Manual Shuttle Transmission (Dual Clutch) .....

6-Speed Transmission (Single Clutch) .....

6-Speed Transmission (Dual Clutch) .....

Drive Axle .....

Internal Hydraulics .....

MANUAL PREVIEW  
JENSALES®  
purchase full manual at

**JENSALES.COM**  
**or Call 800-443-0625**

CLICK ANYWHERE FOR MORE DETAILS

GROUP IV - SECTION A - PART 4

# PART 4—MANUAL AND POWER STEERING GEAR HOUSING—MF AND TO 35 TRACTORS

## INDEX

	PAGE
Removing Manual Steering Housing . . . . .	1
Disassemble Manual Steering . . . . .	2
Reassemble Manual Steering . . . . .	2
Adjusting Manual Steering . . . . .	4
Removing Power Steering Housing . . . . .	4
Disassemble Power Steering . . . . .	4
Reassemble Power Steering . . . . .	5
Adjusting Power Steering . . . . .	7
Trouble-Shooting . . . . .	8

## DESCRIPTION

The 35 Tractor uses a screw and recirculating ball-nut type steering gear with two pinion shafts which control the steering linkage. The nut is supported on the groove steering shaft by recirculating ball bearings which moves the nut vertically when the shaft is turned. Teeth are cut in the upper side of the nut and is engaged in the left pinion shaft gear, which in turn is engaged with the right pinion shaft gear. See Fig. 1.

## REMOVING MANUAL STEERING HOUSING

The steering gear housing and instrument panel can be removed as an assembly by the following procedures:

1. Tip the hood assembly forward and drain the cooling system.
2. Disconnect heat sending unit, wires and starter motor cable.
3. Disconnect tractorometer cable, choke rod and oil gauge line. (On Diesel models, disconnect tractorometer cable, fuel shut-off rod and throttle control rod.)
4. Remove air cleaner hose, shut off fuel and remove fuel line.




Fig. 1 - 35 Manual Steering Gear Assembly

5. Remove mounting bolts at rear of fuel tank and block-up between tank and rocker arm cover.
6. Remove battery and disconnect drag links from steering arms.
7. Remove bolt securing housing to transmission case also bolt at rear of engine block and lift steering housing assembly from tractor.



Fig. 15 - Installing Power Rack Guide  
1. Power Rack Guide 2. Shims

tained at the rim of steering wheel. Tighten adjusting screw locknut.

4. Install the power rack guide cover and shims and tighten the allen-head retaining screws. Adjust the pre-load on this cover by the use of shims until an additional 1/8 to 1/4 pounds pull is added to the previous reading at the rim of the steering wheel. Shims are available for this adjustment in .003, .005 and .010" thick. See Fig. 15. After all adjustments are made, the total pull to turn the wheel through a 3-inch arc at the center range should be 2-1/8 to 2-3/4 pounds.

5. Connect all lines and fill power steering reservoir with type "A" automatic transmission fluid 1/4" above filter. Start tractor and operate the steering in each direction to bleed all air out of the system, then recheck oil level in reservoir.

## TROUBLE-SHOOTING

### *Problem - Loss of power assistance*

#### **Possible Cause**

- a. Insufficient fluid in reservoir.
- b. Low pump pressure.
- c. Faulty control valve, plungers and springs.
- d. Damaged or restricted hose or tubing.
- e. Oil by-passing piston in cylinder.
- f. Steering linkage binding.

#### **Correction**

Fill reservoir 1/4" above filter.

Check pump relief valve set pressure 1100 psi.

Check plunger and springs. Install new, if damaged or worn.

Check and replace, if necessary.

If the steering gear housing fills up and the pump reservoir lowers, oil may be passing by piston in cylinder. Check and replace worn parts.

Remove steering drag links and check by moving steering mechanism by hand. Should turn easily with front of tractor raised.

### *Problem - Erratic power steering*

#### **Possible Cause**

- a. Sticking or binding control valve spool.
- b. Improperly tightened thrust nut, No. 1, Fig. 12, at top of control valve.

#### **Correction**

Remove control valve assembly; clean all parts in solvent and lubricate with type "A" automatic oil. If this does not correct, replace with a new valve only and spool assembly.

Torque nut 20-30 ft.-lbs., then back off 1/4 turn and stake.

# PART 5—POWER STEERING PUMPS—MF 35, 50 AND 65 TRACTORS

INDEX			
Description	Page	Description	Page
Reassemble Cessna Pump	3	Reassemble Cessna Pump	3
Servicing Pump (Gas Tractors)	1	Servicing Pump (Diesel Tractors)	4
Removing Pump from Tractor	2	Servicing Separate Reservoir	5
Disassemble Barnes Pump	2	Disassemble Wooster Pump	5
Reassemble Barnes Pump	2	Reassemble Wooster Pump	6
Checking Pump Pressure	3	Disassemble and Reassemble	
Disassemble Cessna Pump	3	Cessna Pump	7

## DESCRIPTION

The power steering pump is constant running, gear type and is driven by the camshaft gear train. The pump delivers a volume of oil to the system with a regulated pressure of 1100 to 1200 psi, except on the MF 65 Diesel with the direct injection engine, tractor Serial No. 685 996 and up, which has a regulated pressure of 1500 psi. A relief valve is located in the pump to maintain this pressure.




Fig. 1 - Barnes Power Steering Pump

1. Mounting Bolt 2. Return Line 3. Name Plate 4. Pressure Line

## SERVICING PUMP (Gas Tractors)

The power steering pumps listed in this section are used on MF and TO 35, 40 and 50 Tractors, also MF 65 Tractors. The early model 35, 40, 50 and 65 Gas Tractors use the Barnes pump, which can be identified by a tag on the housing; see Fig. 1. This pump can be replaced for service by a Cessna pump which is also used on late model gas tractors. See Fig. 2 for identification of this pump.




Fig. 2 - Cessna Power Steering Pump

*NOTE: The pump drive gear used on the 35, 40 and 50 gasoline model tractors is different from that used on the 65 gasoline tractors.*

## GROUP VI - SECTION H - PART 3

# PART 3—FRONT AXLE AND STEERING— MF 2135 TRACTORS

## INDEX

	Page		Page
ENGINE-DRIVEN STEERING PUMP —		Reassembly .....	17
DIESEL MODEL .....	2	Power Steering Gear Housing — MF 2135 .....	18
Filling The Reservoir .....	2	Disassembly .....	18
Removal .....	2	Inspection .....	19
Disassembly .....	2	Reassembly .....	19
Inspection .....	3		
Reassembly .....	3	SERVICING THE POWER STEERING	
Installation .....	4	CYLINDERS — MF 2135 .....	22
ENGINE-DRIVEN STEERING PUMP —		SERVICING THE FRONT AXLE .....	22
GASOLINE MODEL .....	4	MF 2135 Turf .....	22
Filling The Reservoir .....	4	Removal .....	22
Removal .....	5	Installation .....	23
Disassembly .....	5	MF 2135 .....	23
Inspection .....	6	Removal .....	23
Reassembly .....	6	Installation .....	24
Installation .....	6		
		ADJUSTMENTS .....	24
SERVICING THE STEERING GEAR HOUSINGS ..	7	Toe-In .....	24
Preparations For Servicing Steering		Front Axle Wheel Bearings .....	25
Gear Housings .....	7	MF 2135 Turf .....	25
Completing Tractor Reassembly .....	10	MF 2135 .....	25
Power Steering Gear Housing — MF 2135 Turf ..	12	Axle Pivot Pin End-Play — MF 2135 .....	25
Disassembly .....	12	Power Steering Gear Housing .....	26
Inspection .....	14	MF 2135 Turf .....	26
Reassembly .....	14	MF 2135 .....	26
Manual Steering Gear Housing — MF 2135 Turf .	17	Manual Steering Gear Housing — MF 2135 Turf .	27
Disassembly .....	17		
Inspection .....	17	SPECIFICATIONS .....	27

or Call 800-443-0625

This Part of the Manual contains the recommended procedures that should be followed while servicing the steering system on the MF 2135 and MF 2135 Turf Tractors.

GROUP I - SECTION B - PART 4  
LUBRICATION SYSTEM SERVICING

INDEX

	Page		Page
Oil Pan . . . . .	2	Oil Filter . . . . .	6
Oil Intake Screen Assembly . . . . .	2	Oil Pressure Gauge . . . . .	6
Oil Pump. . . . .	3	Crankcase Ventilation . . . . .	6

The Z-134 Engine uses a full pressure lubrication system in which oil from the crankcase is pumped, under pressure, to all of the bearing surfaces in the engine.

The essential parts of this system are the crankcase and oil supply, oil pump, screened oil intake, drilled oil passages, oil filter, relief valve in the oil pump, pressure gauge and oil level indicator.

In operation, oil is pressure fed to the main bearings, crank pins, camshaft and rocker shaft. By using a timed hole in the crankshaft, oil is spurt fed to the timing gears, cylinders and pistons. The tappets, wrist pins and governor are splash fed. Refer to Figure Nos. 1 & 2.

The capacity of the oil crankcase is 6 U.S. quarts when the filter is changed. If the filter is not changed the capacity is 5 U.S. quarts.




Fig. 1 - Engine Oiling System (Side View)

GROUP I SECTION B PART 5  
COOLING SYSTEM SERVICING

INDEX

	Page
Radiator . . . . .	2
Water Pump . . . . .	2
Thermostat . . . . .	5
Fan Belt . . . . .	6

The cooling system for the Z-134 engine consists of a pressure type radiator and cap, fan, water pump, thermostat, hoses and the circulation passages. Radiator capacity is 10 U.S. quarts.

The coolant in the system is drawn into the pump through the lower radiator hose and is circulated around the wet sleeves, through the passage-ways, into the head as shown in Fig. 1. The coolant then circulates through the engine head and passes out through the outlet elbow, through the hose and thermostat and into the top of the radiator where it moves downward and is cooled. When the engine is cold and the thermostat is closed, the coolant cannot move through the upper hose and into the radiator. Therefore, a passage has been drilled from the head through the block and into the water pump housing. Before the thermostat opens, the warm water from the head returns through this passage to the pump and is pumped into the block. This recirculation gives a uniform warm-up without hot or cold spots. When the block is uniformly warm, the thermostat opens and allows sufficient flow through the radiator to give the necessary cooling.




Fig. 1 - Engine Cooling System

# CLUTCHES—INDUSTRIAL TRACTORS

## INDEX

	Page
NINE (9") INCH SINGLE AND "SPLIT TORQUE" TYPE CLUTCHES .....	2
Disassembly .....	3
Inspection .....	3
Reassembly .....	3
ELEVEN (11") INCH SINGLE CLUTCH .....	5
Disassembly .....	5
Inspection .....	5
Reassembly .....	6
TWELVE (12") INCH SINGLE CLUTCH .....	8
Disassembly .....	8
Inspection .....	9
Reassembly .....	9
DUAL CLUTCH (11" Primary/9" Secondary) .....	10
Disassembly .....	11
Inspection .....	12
Reassembly .....	13
TROUBLE-SHOOTING .....	16

This Part contains service information pertaining to disassembly, inspection and reassembly of the clutches installed on the Massey-Ferguson Industrial Tractors. (Torque Converter repair information is contained in the Part which covers the Instant Reverse Transmission.)

Clutch removal, installation and adjustment procedures may be found by referring to the appropriate Section of this Manual pertaining to the Tractor using the particular clutch assembly.

or Call 800-443-0625

# INSTANT REVERSE TRANSMISSION AND TORQUE CONVERTER FOR INDUSTRIAL TRACTORS

INDEX			Page		Page
INTRODUCTION .....	1	Inspection .....	12		
DESCRIPTION .....	1	Assembly and Installation .....	13		
TORQUE CONVERTER .....	1	CLUTCH PACKS .....	13		
Disassembly .....	1	Removal .....	14		
Inspection .....	4	Disassembly .....	16		
Reassembly .....	4	Inspection .....	18		
OIL DISTRIBUTOR MANIFOLD .....	7	Assembly .....	19		
Disassembly .....	8	Installation .....	24		
Removing the Valve .....	8	TWO-SPEED TRANSMISSION .....	26		
Disassembling the Valve .....	8	Disassembly .....	26		
Inspection of Oil Distributor Manifold .....	8	Inspection .....	28		
Assembly and Installation .....	10	Assembly .....	29		
Valve .....	10	PLANETARY GEAR ASSEMBLY .....	29		
Oil Distributor Manifold .....	10	Removal .....	29		
PUMP .....	11	Disassembly .....	30		
Removal .....	11	Assembly .....	30		
Disassembly .....	12	Installation .....	31		

## INTRODUCTION

This Section covers the overhaul procedures for the Instant Reverse Transmission and Torque Converter. Procedures for testing, adjusting and trouble-shooting, as well as removal and re-installation of the transmission and torque converter, will be found in each particular section of this Manual that covers equipment utilizing the Instant Reverse Transmission.

## DESCRIPTION

The Instant Reverse Transmission consists of a torque converter, a pair of hydraulically actuated multiple disc clutches, and a two-speed sliding spur gear-type transmission, with a rear-mounted two-speed planetary reduction assembly.

## TORQUE CONVERTER

The Torque Converter consists of three major components: (1) a turbine assembly, (2) an impeller or pump assembly, and (3) a stator and sprag (or one-way clutch assembly).

## DISASSEMBLY

1. Place the torque converter, hub down, on a clean work bench. Stabilize the converter by placing the hub through a hole in the bench, or use an improvised wooden cradle.
2. Remove the cover to impeller mounting bolts. See Fig. 3.

*NOTE: Check to make sure that the ring gear and front cover is marked, where the ring gear is bolted to the front cover, before disassembling units.*

3. Remove the front cover.




Fig. 1 - Instant Reverse Transmission

4. Remove and discard the cover "O"-Ring seal. See Fig. 4.

5. Remove the turbine thrust washer. See Fig. 5.

6. Grasp the turbine by its hub and lift it out of the impeller. See Fig. 6.

7. Drain any remaining oil from the turbine assembly.

8. Lift the stator and sprag assembly out of the impeller.



Fig. 2 - Torque Converter




Fig. 3 - Torque Converter  
1. Drain Capscrews

# SERVICING THE MANUAL SHUTTLE SINGLE CLUTCH TRANSMISSION

## INDEX

	Page
INTRODUCTION .....	2
DISASSEMBLING THE TRANSMISSION.....	2
SERVICING INPUT SHAFT, PINION GEARS AND RETAINER ASSEMBLY .....	4
Disassembly .....	4
Inspecting and Servicing Component Parts .....	5
Reassembly .....	5
SERVICING PLANETARY ASSEMBLY.....	6
Disassembly.....	6
Inspection .....	7
Reassembly .....	7
REASSEMBLING THE TRANSMISSION .....	7




Fig. 1 - Sectional View of Transmission Having Splined-Type Countershaft

# SERVICING THE MANUAL SHUTTLE DUAL CLUTCH TRANSMISSION

## INDEX

	Page
INTRODUCTION .....	2
DISASSEMBLING THE TRANSMISSION .....	2
SERVICING INPUT SHAFT, PINION GEARS AND RETAINER ASSEMBLY .....	5
Disassembly .....	5
Inspecting and Servicing Component Parts .....	5
Reassembly .....	7
SERVICING PLANETARY ASSEMBLY .....	9
Disassembly .....	9
Inspection .....	9
Reassembly .....	9
REASSEMBLING THE TRANSMISSION .....	9




Fig. 1 - Sectional View of Transmission Having Splined-Type Countershaft

# STANDARD 6-SPEED TRANSMISSION (Single Clutch)

## INDEX

Page

DISASSEMBLING THE TRANSMISSION.....	2
SERVICING THE INPUT SHAFT AND RETAINER ASSEMBLY .....	4
Disassembly.....	4
Inspection .....	4
Reassembly .....	6
SERVICING THE PLANETARY ASSEMBLY .....	7
Disassembly .....	7
Inspection .....	7
Reassembly .....	7
REASSEMBLING THE TRANSMISSION .....	7

This Section contains the overhaul procedures for the standard 6-speed transmission (single clutch). Although some components will vary slightly, (depending upon the unit in which the transmission is installed) the overhaul procedures will remain the same. *Refer to the Tractor Parts Book to ensure that the correct parts are ordered.*

For instructions pertaining to removal and re-installation from the tractor using this transmission, refer to the appropriate tractor "write-up".

**JENSALES.COM**

**or Call 800-443-0625**

# STANDARD 6-SPEED TRANSMISSION (Dual Clutch)

## INDEX

	Page
DISASSEMBLING THE TRANSMISSION .....	2
SERVICING THE INPUT SHAFT AND RETAINER ASSEMBLY .....	5
Disassembly .....	5
Inspection .....	6
Reassembly .....	6
SERVICING THE PLANETARY ASSEMBLY .....	6
Disassembly .....	6
Inspection .....	7
Reassembly .....	7
REASSEMBLING THE TRANSMISSION .....	7

This Section contains the recommended overhaul procedures for the standard 6-speed transmission (dual clutch), removed from the tractor and placed on a stand. Although some components will vary slightly, (depending upon the unit in which the transmission is installed i. e. gasoline or diesel engine) the basic overhaul procedures will remain the same. *Refer to the Tractor Parts Book to ensure that the correct parts are ordered.*

For instructions pertaining to removal and re-installation from the tractor using this transmission, refer to the appropriate tractor "write-up".

or Call 800-443-0625

## DRIVE AXLE ASSEMBLY

## NON-PLANETARY TYPE

## CONTENTS

	Page		Page
SPECIFICATIONS .....	1	DRIVE PINION ASSEMBLY .....	14
General .....	1	Disassembly .....	14
Fastener Torques .....	1	Inspection .....	16
Lubrication .....	1	Reassembly .....	17
GENERAL DESCRIPTION .....	1	DIFFERENTIAL CARRIER ASSEMBLY .....	19
AXLE SHAFT ASSEMBLY .....	3	Disassembly .....	19
Removal .....	3	Inspection .....	20
Disassembly .....	4	Reassembly .....	21
Inspection .....	5	CARRIER BEARING PRE-LOAD	
Reassembly .....	6	ADJUSTMENT .....	23
Installation .....	6	RING GEAR AND PINION BACKLASH	
Lubrication .....	7	ADJUSTMENT .....	28
End-Play Adjustment .....	7	Alternate Adjustment Procedure .....	29
AXLE HOUSING ASSEMBLY .....	8	BRAKES — DRUM TYPE (2" x 14") .....	30
Disassembly .....	8	Specifications .....	30
Inspection .....	9	Description and General Inspection .....	30
Reassembly .....	10	Brake Drum .....	31
DIFFERENTIAL LOCK .....	11	Brake Shoes .....	32
Disassembly .....	11	Backing Plate Assembly .....	33
Inspection .....	12	Adjustment — Outline .... (Refer to Specific tractor	
Reassembly .....	12	Model for details)	

Reassembly ..... 12

**or Call 800-443-0625**

191

# INTERNAL HYDRAULIC SYSTEM—INDUSTRIAL TRACTORS

INDEX	
	Page
INTRODUCTION .....	1
HYDRAULIC LIFT COVER .....	2
Removing the Hydraulic Lift Cover .....	2
Installing the Hydraulic Lift Cover .....	3
Disassembling Hydraulic Lift Cover .....	3
Reassembling the Hydraulic Lift Cover .....	5
Servicing the Master Control Spring .....	6
Adjusting the Hydraulic Lift Cover .....	7
FINAL ADJUSTMENTS OF THE HYDRAULIC SYSTEM .....	8
DASH POT ASSEMBLY .....	9
Removing the Dash Pot Assembly .....	9
Installing the Dash Pot Assembly .....	10
Disassembling the Dash Pot .....	10
Reassembling the Dash Pot .....	10
HYDRAULIC PUMP .....	10
Removing the Hydraulic Pump .....	10
Disassembling the Hydraulic Pump .....	10
Disassembling the Control Valve .....	11
Servicing the Control Valve and Oscillator .....	12
Reassembling the Control Valve .....	12
Servicing the Valve Chambers .....	12
Inspecting the Valve Chambers .....	13
Reseating the Valve Seats .....	13
Reassembling the Hydraulic Pump .....	14
Installing the Hydraulic Pump .....	15
LUBRICATION .....	15
TROUBLE-SHOOTING .....	15
QUICK SERVICE CHECKS .....	17

## INTRODUCTION

This Part pertains to servicing the Internal Hydraulic System on all Industrial Tractors so equipped, except the following models:

MF 202 Prior to Serial #310 243  
 MF 203 Prior to Serial #659 002 089  
 MF 204 Prior to Serial #344 355  
 MF 205 Prior to Serial #659 101 226  
 MF 302 Prior to Serial #119 700 705  
 MF 304 Prior to Serial #119 750 647

For servicing the Hydraulic System on the previously mentioned models, refer to Group III, Section A, Part 4.

Tractors after the serial nos. listed above will have the Response Control located on the right side of the center housing as shown in Fig. 1.

The lift links can be raised into transport position with either the Draft Control Lever or the Position Control Lever.

To operate the Hydraulic system in Position Control, the Draft Control Lever must be all the way to the rear of the quadrant. The lower links can then be positioned by the Position Control Lever. When the Position Control Lever is moved toward the rear of the quadrant, the lower links will raise. When moved toward the forward side of the quadrant, the lower links will lower in proportion to the position of the lever. This lever is used for attaching and operating equipment that is not draft controlled.

To operate the system in Draft Control, the Position Control Lever must be placed in transport position (to the rear of the quadrant against the stop). The Draft Control Lever, which is on the outer quadrant, is provided with an adjustable locator. This

## PART 4—INTERNAL HYDRAULIC SYSTEM— MF 135, 150 AND 165 TRACTORS

INDEX			Page
	Page		Page
Description and Operation .....	1	Hydraulic Pump .....	10
Hydraulic Lift Cover .....	1	Removing the Hydraulic pump .....	11
Removing the Hydraulic lift cover .....	3	Disassembling the hydraulic pump .....	11
Installing the Hydraulic lift cover .....	3	Disassembling the Control Valve .....	12
Disassembling Hydraulic lift cover .....	4	Servicing the Control Valve	
Reassembling the Hydraulic lift cover .....	5	and Oscillator .....	13
Servicing the Master control spring .....	6	Reassembling the Control Valve .....	13
Adjusting the Hydraulic lift cover .....	7	Servicing the Valve Chambers .....	14
Final Adjustments of the Hydraulic		Inspecting the Valve Chambers .....	14
System .....	9	Reseating the Valve Seats .....	15
Dash Pot Assembly .....	10	Reassembling the Hydraulic Pump .....	15
Removing the Dash Pot assembly .....	10	Installing the Hydraulic Pump .....	16
Installing the Dash Pot assembly .....	10	Lubrication .....	17
Disassembling the Dash Pot .....	10	Trouble-Shooting .....	17
Reassembling the Dash Pot .....	10	Quick Service Checks .....	19

### DESCRIPTION AND OPERATION

The Hydraulic System described in this part is similar to the one used on the MF 35, 50 and 65 Tractors. It has Draft Control through the top link and Master Control Spring, also Position Control regulated by the operator.

One difference in the two systems is that the MF 35, 50 and 65 Tractors have a slow response control which restricts the dropping of the implement by regulating the amount of travel of the control valve to an exhaust position. On this system, the rate of lowering an implement is controlled by a dash pot, which retards the control valve toward the exhaust position. This enables the tractor to be operated in slow response over an uneven terrain and still maintain an even depth of the implement. The control valve is spring-loaded toward the intake side, rather than toward the exhaust, as is the earlier system. The hydraulic system can be raised into transport position or lowered position with either the draft control lever or the position control lever. Fig. 1 shows a view of the lift cover assembly, stand-pipe and the hydraulic pump assembly positioned as they would appear in the tractor — also shows identification of Controls.

To operate the hydraulic system in position control, the draft control lever must be all the way to the rear of the quadrant. The lower links can then be positioned by the position control lever. When the position control lever is moved toward the rear of the quadrant, the lower links will raise. When moved toward the forward side of the quadrant, the lower links will lower in proportion to the position of the lever. This lever is used for attaching implements and for operating implements that are not draft controlled.

To operate the system in draft control, the position control lever must be placed in transport position (to the rear of the quadrant against stop). The draft control lever, which is on the outer quadrant, is provided with an adjustable locator which allows the operator to lower the implement to the same depth each time. When operating in draft control, the implement is raised to transport and lowered with the draft control lever.

### HYDRAULIC LIFT COVER

The hydraulic lift cover is mounted on top