









Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0
	OVEM OTHER SETTIP GUIDE PACK	
	The following document is a Quick set-up guide for the Vacuum generator <b>OVEM-20-H-B-G(P)O-OE-N-2P</b> for installations within Volvo Cars.	
	Please note: For more detailed information, please consult the manufacturer's manual which is the primary reference for correct and safe use is.	
	Prepared by Marc Mertens - ISM Festo BE Johan Thielemans- Festo BE	



Торіс	:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who <sup>-</sup>	Го:	Commissioning / Maintenance	Revision 1.0
Page	Index		
Page	e Index		3
1.	Safety		4
2.	Notes		5
3.	Connections		6
4.	OVEM Layout		7
5.	Flow Diagrams		8
6.	Typical Vacuum Distrib	oution	9
7.	Single point lesson for	showing settings for Output A	10
8.	Single point lesson for	editing settings for Output A	11
9.	Single point lesson for	setting Duration Pulse	12
10.	General Principal of op	veration	13
11.	LS power saver Trouble	eshooting	14
12.	Troubleshooting Table	1 (Manual Extract)	15
13.	Troubleshooting Table	2 (Manual Extract)	16
14.	Vacuum Generator - ci	rcuit	17
15.	Vacuum Generator - ci	rcuit single valve	
16.	Vacuum Generator - ci	rcuit valve terminal	



Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0

### 1. Safety

- Please read the relevant manual on the OVEM vacuum handling unit to ensure safe use of the unit, available on the Festo Website.
- Compressed air is dangerous, depressurise systems before carrying out installation / maintenance tasks.





Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0

#### 2. Notes

- 1. The correct size/type unit must have been selected to suit the relevant application. The laval nozzle size width of available units varies from 05/07/10/14/20. (Volvo cars default = 20). Full reference code for projects is: OVEM-20-H-B-G(P)O-0E-N-2P
- 2. The unit should be mounted to allow access to top & front, 3 button controls, to allow removal and cleaning of filter elements and unrestricted exhaust. It is designed for internal use only.
- 3. The OVEM unit requires an air supply, set up to 4 bar pressure (max.), with a flow adequate to suit the application, see manual/software for relevant calculations. By default, when the air supply is connected, vacuum will be generated.
- 4. The unit requires a 24VDC power supply cable with provision for two outputs and one input. Pre SEPT. 2015 part ref #171175.



Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0

### **3.** Connections



Pin allocation		
Plug M12x1, 5-pin	Pin	Meaning
		OVEM2P/2N/PU/NU/PI/NI
1	1	Supply voltage +24 V DC
	2	Output B (function depending on variant)
2-(++++)-4	3	0 V
5	4	Output A (switching output for vacuum sensor)
3	5	Switching input In
		(vacuum ON/OFF and ejector pulse)
	00	

0







Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0

### 5. Flow Diagrams



Fig. 3: Operating states of the OVEM



	Icon	Icon Description		Modes		
			RUN	NOHS	EDIT	TEACH
	111.11	Switching output set/not set	Х		8	
		Switching output selected / not selected		х	х	х
	Segment Switch	There is a signal at the switch input	x			
	input In lights up	Manual override active			x	
	Г	Threshold value comparator	-	х	x	
	j sr	Window comparator		x	x	
NO NO	ITL [msec]	Reject pulse (time setting)		x	x	
Teachi	[SP]	Switchingpoint		Х	Х	Γ
Option	[SP][min]	Lower switching point (switching point - min.)		Х	Х	Γ
Lock	[SP] [max]	Upper switching point (switching point - max.)		Х	Х	
	[SP] [max]	Diagnosis: Limit value evacuation time		х	x	
	L [SP] [max]	Diagnosis: Limit value pressurization time		x	x	
	[HY]	Hysteresis		x	X	┢
	[NO]	Switching character, of normally open contact		X	X	t
	INC]	Switching character, of normally closed contact		X	X	t
	[min] / [max]	Extreme values: min./max. measured input value (In A1) <sup>1)</sup>		x		
	<b>r</b> [min][msec]	Min. evacuation time		x		
	[max] [msec]	Min.evacuation time		х		
	<b>L</b> [min][msec]	Min. pressurization time		x		
	L [max] [msec]	Max. pressurization time		x		
	[Teach]	Teach mode active				Х
	[Option]	Air-save function active	X	X	X	t





Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0

### 6. Typical Vacuum Distribution



Installations of vacuum systems should keep tubing lengths from OVEM to cups as short as possible and maintain legs of equal lengths.





Topic:		OVEM Quick setup Guide – Quick setup guide	<b>pack</b> 28.10.2015
Who To	):	Commissioning / Maintenance	Revision 1.0
7. Si	ingle p	point lesson for showing settings for Output A	
1a.	From the Displays	RUN screen Press A once to view set point of output A the value in mbar (e.g. 0.700)	SP Option
1b.	Press aga Displays	ain to see Hysteresis of Output A the value in mbar (e.g 0.250)	ALZ S U AT Option
1c.	Press aga Displays	ain to see Min. Flow Retained Value the value in mbar (e.g 0.400)	
1d.	Press aga Displays Press aga	ain to see Max. Flow Retained Value the value in mbar (e.g 0.700) ain to return to RUN screen	





Topic:		OVEM Quick setup Guide – Quick setup gui	de pack 28.10.2015
Who To:		Commissioning / Maintenance	Revision 1.0
8. S	ingle j	point lesson for editing settings for Output A	
2a.	From RUI i)	N screen press edit button once While A is flashing press and release edit again	365
2b.	Press edi i)	t again to view set point of output A in -mbar. Press A to increase, B to decrease	sp Option
2c.	Press edi i)	t again to see Hysteresis of Output A. Press A to increase, B to decrease	CC 5 C
2d.	Press and i) ii)	d release edit, NO or NC output option Press A to change, the one flashing is the one selected Press the Edit button to confirm the selection	NO NC

1	
1	
VO	LVO
6	



Topic:		OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:		Commissioning / Maintenance	Revision 1.0
9.	Single p	ooint lesson for setting Duration Pulse	
3a.	From the i) ii)	RUN screen Press edit button. Press button B, yellow B icon will flash Press button B again, white Led bar will flash	
3b.	Press edi i)	t button, reject time setting will be displayed. Press A to increase time and B to decrease. (ms)	
3c.	Press edi <b>if</b> LED bar v	t button, the FORC option will be displayed. <b>required and in a SAFE state</b> , press A to switch off vacuum <b>required and in a SAFE state</b> , press B to force eject pulse vill appear each time A or B is pressed, indicating the solenoid is energised.	F. Q. F. C. Option





Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0

#### **10.** General Principal of operation

- 1. Vacuum cups come in good contact with part, vacuum turned on. (output off).
- 2. A good seal contact allows vacuum level to climb to set point.
- 3. If set point reached, output A/B is switched, output is given to controls, and next operation can be enabled.
- 4. If LS (power saver function) is enabled and good part contact seal is achieved, the air consumption will shut off provided the vacuum is within the set parameters (e.g. threshold hysteresis), if after more than 1 second the vacuum drops below the set level then the air consumption will switch back on to raise the level of vacuum back to the required set level again. This process will continue until the part needs to be removed, thus reducing air consumption.
- 5. When the part needs to be removed, the reject input signal needs to be applied by the control system.
- 6. While the reject signal is applied, it switches off the vacuum solenoid, and drives the reject solenoid for the set time only (40 9999ms. Default =200ms) (See Page 11 to change).
- 7. The flow of air during the reject time set can be increased or decreased by the turning the screw on the front of the OVEM unit, clockwise reduces flow, anti-clockwise increases flow. It is important that the balance of reject time, flow (front screw) speed of breakaway, allow the part to break free of the vacuum cups completely.
- 8. The Vacuum will come back on again as soon as the reject input is removed.





Topic:	OVEM Quick setup Guide	– Quick setup guide pack	28.10.2015	
Who To:       Commissioning / Maintenance       Revision 1         11. LS power saver Troubleshooting				
Description		Remedy		
LS (Low power	r consumption) mode does not operate	High leakage rate in the vacuum circuit – Check all joints an are well mated.	nd ensure cups	
LS (Low power consumption) mode operates once only, (LCD display [min][max] flash.)		Part "bounced" against seals more than once in 1 second (1Hz) - Check mechanical seal at vacuum cups		
Press A button - if Error 38 is displayed then the unit has deactivated the LS mode and vacuum is operating at full flow and thus using higher volume of compressed air.				
This condition wil and released.	ll automatically revert to LS after the next reject pulse has been applied			



Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0

# 12. Troubleshooting Table 1 (Manual Extract)

Diag-	Description	Display in		
nostic stage		RUN mode	SHOW mode	TEACH mode
0	<ul> <li>EverythingOK</li> </ul>	No display		
1	<ul> <li>Still no function limitation, but operating parameters become worse.</li> <li>Message at switch output Out B (logical channel di 1 active)</li> </ul>	Segments [min] and [max] flash synchronously	Display fault code before each SHOW menu	Segments[min] and [max] flash synchronously
2	<ul> <li>Function still guaranteed, but with limitations (higher energy consumption,) – "emergency operation", servicing urgently required</li> <li>Message at switch output Out B (logical channels di 1 or di 2 active)</li> </ul>	LCD display and [min][max] flash	Display fault code before each SHOW menu	LCD display and [min][max] flash
3	<ul> <li>Function no longer guaranteed.</li> <li>Message at switch output Out B (logical channels di 1 or di 2 active) and all controllable outputs of the device inactive</li> </ul>	All segments flash and LCD display show the current fault	All segments flash except for LCD display	Cannot be reached because buttons are blocked



Topic:	OVEM Quick setup Guide – Quick setup guide pack	28.10.2015
Who To:	Commissioning / Maintenance	Revision 1.0

### **13. Troubleshooting Table 2 (Manual Extract)**

Er34			
	Evacuation time exceeded in 2 of 5 cycles	Check for leakage	
Er36	Pressurization time exceeded in 2 of 5 cycles	Check for leakage	
Er33	Solenoid valve does not switch or not correctly. Plunger does not move, current through solenoid coil not sufficient, short circuit in solenoid coil	Press mechanical manual override several times. Check supply voltage. If there is no improvement, the device is defective. Send device to Festo.	
Er35	The set threshold of the evacuation time is exceeded double the value in 2 of 5 cycles	Check for leakage	
Er37	The set threshold of the pressurization time is exceeded double the value in 2 of 5 cycles	Check for leakage	
Er38	Switching frequency of the air-save function lies over the limit value 1 Hz	Check for leakage	
	Possible fault when switching on the air-save function, switching point not logical	Reset input	
Er17 <sup>4)</sup>	Undervoltage in power supply < 15 V	Check the power supply	
Er01	Device defective	Exchange device	
Er02 Er08	Reserved for extensions	-	
Er13 Er16	Reserved for extensions	<u>ш</u>	
	r33 r35 r37 r37 r01 r02 r08 r13 r16 lflash syn	F733       Solenoid valve does not switch or not correctly.         Plunger does not move, current through solenoid coil not sufficient, short circuit in solenoid coil         F735       The set threshold of the evacuation time is exceeded double the value in 2 of 5 cycles         F737       The set threshold of the pressurization time is exceeded double the value in 2 of 5 cycles         F737       The set threshold of the pressurization time is exceeded double the value in 2 of 5 cycles         F738       Switching frequency of the air-save function lies over the limit value 1 Hz         Possible fault when switching on the air-save function, switching point not logical         F717 4)       Undervoltage in power supply < 15 V	

Tab. 15: Fault code of the vacuum generator







