



Leader in  
Level Measurement

# Installation and Operating Instructions

ThePoint™ Series Point Level Switch  
Auto Calibration or Manual Calibration  
Selectable

Telephone: +1 215-674-1234  
Fax: +1 215-674-2731  
E-mail: [drexelbrook.service@ametek.com](mailto:drexelbrook.service@ametek.com)  
Website: [www.drexelbrook.com](http://www.drexelbrook.com)

AMETEK Drexelbrook makes no warranty of any kind with regard to the material contained in this manual, including, but not limited to, implied warranties or fitness for a particular purpose. Drexelbrook shall not be liable for errors contained herein or for incidental or consequential damages in connection with the performance or use of material.

© AMETEK Drexelbrook

# ThePoint™ Series Point Level Switch

## Auto Calibration or Manual Calibration Selectable



## **Contents**

# Contents

<b>Section 1:</b>	<b>Introduction .....</b>	<b>1</b>
1.1	System Description .....	1
1.2	Technology .....	1
1.3	Model Number .....	2
1.4	Housing Dimensions .....	4
<b>Section 2:</b>	<b>Installation .....</b>	<b>5</b>
2.1	Unpacking .....	5
2.2	Mounting and Installation Guidelines .....	5
2.3	Installation of Flush-Mounted Sensing Elements .....	7
2.4	Input Wiring .....	8
2.5	Output Wiring – Relay Version .....	8
2.6	Output and LED Status .....	9
2.7	Electronic Unit .....	10
2.8	Spark Protection .....	11
2.9	Sensing Element Connection .....	12
2.10	Calibration .....	14
<b>Section 3:</b>	<b>Troubleshooting .....</b>	<b>23</b>
3.1	Testing Sensing Element .....	23
3.2	Testing Electronic Unit .....	24
3.3	Testing Relay Circuits .....	25
3.4	Over Range .....	25
3.5	Under Range .....	25
3.6	Testing Integral Cable .....	26
3.7	Testing Remote Cable .....	26
3.8	Factory Assistance .....	27
3.9	Field Service .....	27
3.10	Customer Training .....	27
3.11	Equipment Return .....	28
3.12	RF Point Level Troubleshooting Guide .....	29
<b>Section 4:</b>	<b>Specifications .....</b>	<b>31</b>
4.1	Approvals Available .....	32
<b>Section 5:</b>	<b>Control Drawings .....</b>	<b>33</b>
5.1	FM / FMc Control Drawings .....	33
5.2	ATEX Control Drawings .....	44
5.3	Heavy Duty Spark Protection .....	50
5.4	Adding a Padded Capacitor .....	52
5.5	Dual Seal Assembly for 700 Series Sensing Elements .....	55
<b>Shortening or Lengthening Sensing Element .....</b>		<b>A1</b>
<b>CE Installation Supplement .....</b>		<b>A2</b>

## **Section 1**

## Section 1: Introduction

### 1.1 System Description


The AMETEK Drexelbrook ThePoint™ Series uses No-Cal™ technology to detect the presence or absence of material without calibration or initiation via setpoint adjustments, push-buttons or magnets.



**Material to be measured must be below sensor when power is applied.**

Installation is simple and easy. Simply apply power and ThePoint system is ready to detect the presence or absence of material. Since ThePoint instrument does not require calibration or setpoint adjustments, it is capable of operating in non-dedicated tanks regardless of the material being measured.


### 1.2 Technology



**Figure 1-1**  
**Simple Capacitance**  
**Probe**  
**(Insulating Media)**

In a simple capacitance probe type sensing element, when the level rises and material covers the probe, the capacitance within the circuit between the probe and the media (conductive applications) or the probe and the vessel wall (insulating applications) increases. This is due to the dielectric constant ( $k$ ) of the material, which causes a bridge imbalance. The signal is demodulated (rectified), amplified and the output is increased. There are drawbacks, however, especially when there is coating of the probe.

An RF Admittance level transmitter is the next generation. Although similar to the capacitance concept, ThePoint employs a radio frequency signal and adds the Cote-Shield™ circuitry within the Electronics Unit.



**Figure 1-2**  
**RF Admittance Probe**  
**with Cote-Shield**

This patented Cote-Shield™ circuitry is designed into ThePoint series and enables the instrument to ignore the effect of buildup or material coating on the sensing element. The sensing element is mounted in the vessel and provides a change in RF admittance indicating presence or absence of material. The Cote-Shield™ element of the sensor prevents the transmission of RF current through the coating on the sensing element. The only path to ground available for the RF current is through the material being measured.

The result is an accurate measurement regardless of the amount of coating on the probe, making it by far the most versatile technology, good for very wide range conditions from cryogenics to high temperature, from vacuum to 10,000 psi pressure, and works with all types of materials.

## 1.3 Model Number

Technology				
P	RF Admittance			
Measurement Type				
N	Std Auto Cal	H	Hi Sense .5 pF Auto Cal	<div>NOTICE</div> <div>All Calibration modes are built into the standard unit. Modes can be changed in the field as required (See Section 2.9.9)</div>
L	Std 2 pF Fixed	P	Hi Sense .5 pF Fixed	
T	10 pF Auto Cal	G	Hi Sense Manual	
V	10 pF Fixed	M	Std Sense Manual	
Input				
L	Universal Power Supply 19-250 VAC, 18-200 VDC			
Output				
1	One DPDT Relay, dry contacts, 5A, 120VAC (Min 100 mA / 12 VDC)			
2	One DPDT Relay, gold plated contacts (Max 200 mA / 12 VDC)			
Housing				
0	No Approvals(Remote), NEMA 4X/IP66, M20 X 1.5 conduit entries			
1	No Approvals, NEMA 4X/IP66, ¾" conduit entries			
2	ATEX / IECEx, NEMA 4X/IP66, M20 X 1.5 conduit entries			
3	FM / FMc approved, NEMA 4X/IP66, ¾" conduit entries			
5	No Approvals, NEMA 4X/IP66, M20 conduit entries, Dual Seal, Perm-a-Seal Sensors – only			
6	FM / FMc approved (Integral), No Approvals (Remote), NEMA 4X/IP66, ¾" conduit entries, Dual Seal, Perm-a-Seal Sensors – only			
7	FM / FMc approved (Remote), NEMA 4X/IP66, ¾" conduit entries, Dual Seal, Perm-a-Seal Sensors – only			
8	No Approvals (Integral), NEMA 4X/IP66, ¾" conduit entries, Dual Seal, Perm-a-Seal Sensors – only			
9	FM / FMc approved (Integral), No Approvals (Remote), NEMA 4X/IP66, M20 conduit entries, Dual Seal, Perm-a-Seal Sensors – only			
A	No Approvals (Remote), NEMA 4X/IP66, ¾" conduit entries, Dual Seal,Perm-a-Seal Sensors – only			
B	FM / FMc approved (Remote), NEMA 4X/IP66, ¾" conduit entries, Dual Seal, Perm-a-Seal Sensors – only			
Electronics				
0	Integral	7	Rmt. w/ (25 ft.) Tri-Ax Cable	E Rmt. w/ (75 ft.) 1st 10ft Hi-Temp. Cbl.
1	Remote, no cable	8	Rmt. w/ (50 ft.) Tri-Ax Cable	F Rmt. w/ (5 ft.) G.P. Cable
2	Rmt. w/ 3 m (10 ft.) G.P. cable	9	Rmt. w/ (75 ft.) Tri-Ax Cable	G Rmt. w/ (5 ft.) Tri-Ax Cable
3	Rmt. w/ 7.6 m (25 ft.) G.P. cable	A	Rmt. w/ (10 ft.) Hi-Temp. Cable	H Rmt. w/ (10 ft.) Tri-Ax Cable
4	Rmt. w/ 10.6 m (35 ft.) G.P. cable	B	Rmt. w/ (25 ft.) 1st 10ft Hi-Temp. Cbl.	J Rmt. w/ (35 ft.) Tri-Ax Cable
5	Rmt. w/ 15.2 m (50 ft.) G.P. cable	C	Rmt. w/ (35 ft.) 1st 10ft Hi-Temp. Cbl.	K Rmt. w/ (5 ft.) Hi-Temp. Cable
6	Rmt. w/ 23 m (75 ft.) G.P. cable	D	Rmt. w/ (50 ft.) 1st 10ft Hi-Temp. Cbl.	
Sensing Element				
	Application	Sensing Element	Pressure/Temperature	Wetted Parts
00	General purpose	700-1202-001 remote 700-1202-021 integral	13.8 bar @ 232°C (200 PSI @ 450°F)	316SS and PEEK
01	Floating roof with cable attachment and brass bottom weight	700-1202-012 remote 700-1202-022 integral	13.8 bar @ 232°C (200 PSI @ 450°F)	316SS, Brass, and PEEK
02	General purpose, longer insertion lengths with cable attachment and 316SS bottom weight	700-1202-014 remote 700-1202-024 integral	13.8 bar @ 232°C (200 PSI @ 450°F)	316SS and PEEK
03	Proximity	700-1202-018 remote 700-1202-028 integral	13.8 bar @ 232°C (200 PSI @ 450°F)	316SS and PEEK with 76 mm (3) 316SS proximity plate
04	General purpose, high temperature and pressure	700-1202-041 remote 700-1202-042 integral	69 bar @ 121°C (1000 PSI @ 250°F) 20.7 bar @ 232°C (300 PSI @ 450°F)	316SS and PEEK
06	General purpose with FDA approved materials of construction	700-1202-031 remote 700-1202-032 integral	13.8 bar @ 232°C (200 PSI @ 450°F)	316SS and FDA grade PEEK
07	General purpose Granular materials	700-1202-010 remote 700-1202-020 integral	13.8 bar @ 232°C (200 PSI @ 450°F)	316SS and PEEK with 7/8 inch dia. 316SS collar
09	General purpose Granular materials with FDA approved	700-1202-033 remote 700-1202-034 integral	13.8 bar @ 232°C (200 PSI @ 450°F)	316SS and FDA grade PEEK with 7/8 inch dia. 316SS collar
10	Corrosive liquids (2)(4)(9)	700-0001-018 remote	3.4 bar @ 149°C (50 PSI @ 300°F)	PFA
11	General purpose, TFE compatibility required	700-0201-005 int/rem	69 bar @ 38°C (1000 PSI @ 100°F) 34.5 bar @ 149°C (500psi @ 300°F)	316SS and TFE
12	Corrosive material, higher pressure	700-0201-005 int/rem Hastelloy C	69 bar @ 38°C (1000 PSI @ 100°F) 34.5 bar @ 149°C (500psi @ 300°F)	Hastelloy C and TFE
13	Sanitary (3) Non 3A	700-0201-019 int/rem	13.8 bar @ 149°C (200 PSI @ 300°F)	316/316L SS and TFE
14	General Purpose, LP	700-0202-002 int/rem	3.4 bar @ 149°C (50 PSI @ 300°F)	316SS and TFE
15	Heavy duty, agitated tanks or material with high bulk density (1)	700-0202-043 remote	69 bar @ 38°C (1000 PSI @ 100°F) 34.5 bar @ 149°C (500psi @ 300°F)	316SS and TFE
16	High Integrity Seal for Hazardous Materials	700-0002-360 int/rem	34.5 bar @ 149°C (500 PSI @ 300°F)	PFA
17	Sanitary (3) Non 3A LP	700-0202-029 int/rem	3.4 bar @ 149°C (50 PSI @ 300°F)	316SS and TFE
18	Corrosive material, higher pressure with waterlike viscosity (4)	700-0001-022 int/rem	69 bar @ 38°C (1000 PSI @ 100°F) 34.5 bar @ 149°C (500 PSI @ 300°F)	TFE
19	Interface Measurement	700-0002-023 int/rem	69 bar @ 38°C (1000 PSI @ 100°F) 34.5 bar @ 149°C (500 PSI @ 300°F)	316SS and TFE
20	Miniature Pilot Plant Sensor (1)(7)	700-0209-002 remote	6.9 bar @ 121°C (100 PSI @ 250°F) 0 bar @ 232°C (0 PSI @ 450°F)	316 SS and TFE

Continued on Next Page



## 1.3 Model Number (continued)

Continued from Previous Page

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

### NPT Threads

A1B	¾"NPT	316SS
A1C	¾"NPT	Hastelloy C
A1P	¾"NPT	PFA

A2B	1"NPT	316SS
A2C	1"NPT	Hastelloy C

### Sanitary TriClamps

C2B	1"TriClamp	316SS	C5B	2-1/2" TriClamp	316SS
C3B	1½"TriClamp	316SS	C6B	3" TriClamp	316SS
C4B	2"TriClamp	316SS	C7B	4" TriClamp	316SS


### DIN Flanges

E01	25 mm	16 bar	RF 316/316L SS	E02	25 mm	16 bar	RF CS
EP1	25 mm	40 bar	RF 316/316L SS	EP2	25 mm	40 bar	RF CS
EQ1	50 mm	16 bar	RF 316/316L SS	EQ2	50 mm	16 bar	RF CS
ER1	50 mm	40 bar	RF 316/316L SS	ER2	50 mm	40 bar	RF CS
ES1	80 mm	16 bar	RF 316/316L SS	ES2	80 mm	16 bar	RF CS
ET1	80 mm	40 bar	RF 316/316L SS	ET2	80 mm	40 bar	RF CS
EU1	100 mm	16 bar	RF 316/316L SS	EU2	100 mm	16 bar	RF CS
EV1	100 mm	40 bar	RF 316/316L SS	EV2	100 mm	40 bar	RF CS
EW1	150 mm	16 bar	RF 316/316L SS	EW2	150 mm	16 bar	RF CS
EX1	150 mm	40 bar	RF 316/316L SS	EX2	150 mm	40 bar	RF CS

### ANSI Flanges

DA1	1"	150#	RF 316/316L SS	DA2	1"	150#	RF CS
DB1	1½"	150#	RF 316/316L SS	DB2	1½"	150#	RF CS
DC1	2"	150#	RF 316/316L SS	DC2	2"	150#	RF CS
DD1	2½"	150#	RF 316/316L SS	DD2	2½"	150#	RF CS
DE1	1"	300#	RF 316/316L SS	DE2	1"	300#	RF CS
DF1	1½"	300#	RF 316/316L SS	DF2	1½"	300#	RF CS
DG1	2"	300#	RF 316/316L SS	DG2	2"	300#	RF CS
DH1	2½"	300#	RF 316/316L SS	DH2	2½"	300#	RF CS
DI1	3"	150#	RF 316/316L SS	DI2	3"	150#	RF CS
DJ1	3"	300#	RF 316/316L SS	DJ2	3"	300#	RF CS
DK1	4"	150#	RF 316/316L SS	DK2	4"	150#	RF CS
DL1	4"	300#	RF 316/316L SS	DL2	4"	300#	RF CS
DM1	6"	150#	RF 316/316L SS	DM2	6"	150#	RF CS
DN1	6"	300#	RF 316/316L SS	DN2	6"	300#	RF CS

## 1.4 Housing Dimensions



**Figure 1-3**  
**Compartment Housing Detail**

## Section 2: Installation


### 2.1 Unpacking

Carefully remove the contents of the shipping carton and check each item against the packing list before destroying any packing material. If there is any shortage or damage, immediately report it to the factory at 1+ 215-674-1234.

### 2.2 Mounting and Installation Guidelines

#### CAUTION:

ThePoint instrument must not be powered before it is installed in the application with material below the sensing element.



ThePoint instrument can be mounted vertically or horizontally or at an angle. Mounting location should be as free as possible from vibration, corrosive atmospheres, and any possibility of mechanical damage. Ambient temperatures at electronics should be between -30 to 70° C (-22 to 158° F).


#### NOTE:

To reduce possibility of damage caused by water in conduit, install drip loop and breather drain in conduit to purge any accumulating moisture as shown in Figure 2-1.




After system is installed and level is below sensing element, apply power. ThePoint series instrument does not require any calibration or setpoint adjustments and is ready to detect change in level.

**WRONG**  
Allows Moisture Infiltration



Use only cable supplied by  
AMETEK Drexelbrook

**CORRECT**




If properly installed, the green LED will light when power is applied. Neither the green nor red LED should be flashing. If either of the LEDs are flashing, refer to, **Section 4, Troubleshooting**.




*Cable fittings supplied are weather-resistant. They are NOT certified as explosion proof (XP) or flameproof (d) unless they are specifically marked.*

**WRONG**  
Allows Moisture Infiltration




**CORRECT**



**Figure 2-1**  
*Recommended Conduit Connection*


## 2.2 Mounting and Installation Guidelines (continued)



### WARNING:

ThePoint equipment is rated explosion proof. When installing in explosion hazardous areas [rated “potentially hazardous” (EU) or “hazardous classified” (USA)] observe all national and local regulations as well as specifications in the certificate.

Mount sensing element using the following installation guidelines. *Refer to Figure 2-2.*



**Figure 2-2**  
**Installation Considerations**

- When installing ThePoint instrument, ambient temperature at electronics must not exceed 70°C (158°F).
- When installing flange-mounted sensing elements, keep mating surfaces and bolts free of paint and corrosion to ensure proper electrical contact with vessel. Avoid using excessive amounts of Teflon™ tape when installing threaded sensing elements.
- Install systems with threaded NPT connection via wrench flats on the process connection ONLY.
- Locate sensing element to avoid enhancing electrostatic discharge from process medium, as is good practice with any thermowell, displacer, or sampler. This includes correct bonding to tank or silo wall.
- If installation area is rated explosion proof and requires conduit seal fittings, they should be used in accordance with company standards and local codes.




## 2.2 Mounting and Installation Guidelines (continued)

- Do not mount a Cote-Shield sensing element through a nozzle that exceeds length of first insulator.
- Ensure that there are no obstructions or agitator blades to interfere with sensing element.
- Rigid sensing elements can be mounted at any angle.

## 2.3 Installation of Flush-Mounted Sensing Elements

These instructions apply to all flush on/off sensing elements, models 700-0207-001, 700-0207-002, 700-0207-003, 700-0207-004, 700-0207-006. These systems will sense presence of material (no flow or plugged chute) and absence of material (flow or empty chute) at the sensing element. The Flush Sensing Element will ignore free falling material.



### Sensing Element at the Top of a Chute.

- The flush sensing element should be mounted **In The Flow Stream**. These sensing elements are designed and built to withstand the impact of coal, rock, wood, chips, etc. This location is important to prevent excessive build up of material on the face of the sensing element.
- Excessive build up, typically consisting of wet and/or sticky fines, can occur if the sensing element is protected from falling material.

### Sensing Element in an angle chute.

- Do not mount on the top or bottom.
- Best mounted on either side

### Sensing Element at the Bottom

- Mount on any side.
- Low-Level sensors can be used to detect a plug or to insure that a seal is present (chute is full at this point).


## 2.4 Input Wiring



### WARNING:

If ThePoint instrument is located in a hazardous environment, do not open enclosure cover or make/break any electrical connections without first disconnecting electrical power at the source. Ensure that wiring, electrical fittings and conduit connections conform to electrical codes for the specific location and hazard level.

ThePoint instrument uses a universal power supply and can be operated from any source between 19 to 250 VAC or 18 to 200 VDC. The universal power supply automatically detects input voltage regardless of polarity and does not require jumper changes. *See Figure 2-3.*



**Figure 2-3**  
**Input Wiring**




### IMPORTANT

Ground Must be Provided for Proper Operation and Safety.

## 2.5 Output Wiring – Relay Version









ThePoint series instrument is supplied with two sets of contacts using one 5A DPDT alarm relay. *See Figure 2-4.*



**Figure 2-4**  
**Relay Wiring**

## 2.6 Output and LED Status


There are two status LEDs located on top of Electronic Unit. The green LED is used to indicate that unit has power. The red LED is used to indicate condition of the relay. *See Figure 2-6.*

Tank Condition	Relay Status
 <p>High Level FailSafe Tank Empty</p>	
 <p>High Level FailSafe Tank Full</p>	
 <p>Low Level FailSafe Tank Empty</p>	
 <p>Low Level FailSafe Tank Full</p>	

**Figure 2-5**  
**Output and LED Status**  
*Note: Relays Shown as Powered State*

## 2.7 Electronic Unit

Remove housing lid to access status LEDs, time delay adjustment, and configuration jumpers. *See Figure 2-6.*



*Figure 2-6  
Electronic Unit Adjustments*

### 2.7.1 Time Delay

**TIME DELAY** adjustment is used to avoid an oscillating relay output due to agitation or waves in the vessel. The time delay adjustment can be field adjusted from 0 to 60 seconds. Unit is shipped with time delay setting at zero seconds.



The Time Delay adjustment is a 270-Degree turn pot and is at zero seconds when in the full counter-clockwise position. Do not force the pot past the stop or damage will occur.

### 2.7.2 Time Delay Action


**TIME DELAY ACTION** describes whether the relay contacts are delayed from going into the alarm state or recovering from an alarm state.

- **FWD:** delays system from coming out of alarm.
- **REV:** delays system from going into alarm.
- The instrument is supplied with time delay action set in forward mode (**FWD**) position.
- Time delay action is field-selectable using the Time Delay Jumper located on top of Electronic Unit. *See Figure 2-6.*




### 2.7.3 Failsafe

**FAILSAFE** describes the level condition that causes the output relay to de-energize, and also the state of the relay upon loss of power.



- **High Level Failsafe (HLFS).** The relay will de-energize when level is high, indicating high level upon loss of power. (N.O. contacts open and N.C. contacts closed)



- **Low Level Failsafe (LLFS).** The relay will de-energize when level is low, indicating low level upon loss of power. (N.O. contacts open and N.C. contacts closed)

- Instrument is supplied with failsafe jumper set in high level (**HLFS**) position.
- Failsafe is field-selectable using the Failsafe Jumper located on top of Electronic Unit. *See Figure 2-6.*

### 2.7.4 ReCal Button, Memory Reset

If power has been applied to ThePoint prior to installation (on a test bench) or, if ThePoint is moved from one vessel to another, **RECAL** is necessary. RECAL allows the system's software to capture the air capacitance generated by the sensing element in tank.

Merely press and hold the RECAL button (shown in Figure 2-6) for five (5) seconds. After five seconds, ThePoint's two LED's flash for sixty seconds before the recalibration occurs. (Removing power from the system while the LED's are flashing will reset the memory immediately upon next power up).



***Do not push the Recal button without first ensuring that the material being measured is below the sensing element.***

The system is now ready for installation.

## 2.8 Spark Protection


Applications involving insulating granulars and insulating liquids may produce a static discharge that can damage the electronics. The RF series instrument is supplied with integral heavy-duty spark protection to prevent static discharges from damaging the electronic circuits.

## 2.9 Sensing Element Connection (Integral Sensing Elements)

Sensing element connects to the rear side of the circuit board and is factory-installed.




The sensing element is sealed to the housing and cannot be removed without permanent damage.



**Figure 2-7**  
**Sensing Element Connection**  
**(Integral Housing)**

## 2.9 Sensing Element Connection (continued)

For ThePoint instruments mounted remotely from sensing element, cable connections from sensing element to Electronic Unit are made to terminals beneath the Electronic Unit. *See Figure 2-8.*



**Figure 2-8**  
**Sensing Element Connection**  
**(Remote Housing)**

## 2.10 Calibration

ThePoint™ level measurement switch features both Auto-Cal and manual calibration. The standard Auto-Calibration mode is applicable to most liquid and slurry point level measurements. If preferred, the manual calibration can be used and is recommended for some application. ThePoint electronic unit has auto and manual calibration modes built into the standard unit and can be accessed through a simple routine (see section 2.10.4). The inclusion of these calibration modes allows the Drexelbrook RF Point Level Products application flexibility that is far greater than any other point level product on the market. This RF Point Level switch can be used in Liquids, Solids, Slurries, and Interface applications.

### 2.10.1 Selecting the Calibration Mode for your application.

The following table is a list of measurement types and the recommended calibration mode for each of these applications. ThePoint has eight calibration modes however; only four are used on the majority of applications.



ThePoint will be shipped in the standard Auto-Cal mode #2 unless pre-ordered in a specific mode. To determine if the ThePoint has been shipped in a mode other than #2, look at the label on the inside of the unit housing. The model number will start with PXL1. The “X” indicates the pre-set mode typically an “L” for mode #2.

#### Common Calibration Modes

- Mode 2 = L - Fixed Cal 2pF: 2pF differential, set point locked 2pF above starting capacitance
- Mode 6 = P - Fixed Cal 0.5pF: 0.5pF differential, set point locked 0.5pF above starting capacitance
- Mode 7 = M - Manual calibration standard sensitivity – pots adjusts from 0 to 65pF
- Mode 8 = G - Manual calibration High sensitivity – pot adjusts from 0 to 27 pF

Additional calibration modes for specialty applications (consult factory)

Mode # 1 = N	Auto Mode 2pF
Mode # 3 = T	Auto Mode 10pF
Mode # 4 = V	Auto Mode 10pF
Mode # 5 = H	Auto Mode 0.5pF

*For explanation of mode See Section 2.10.4*

## 2.10.1 Selecting the Calibration Mode for your application (Continued)

### Application Guide

(For instructions on how to access alternate modes see 2.10.4)

Application	Calibration Mode
Liquids and Slurries	Auto-Cal Mode #2
Granular /Solids with Bulk Density greater than 20#’s per cubic foot	Manual Cal Mode #7
Granular/Solids with Bulk Density Under 20#’s per cubic foot	Manual Cal Mode #8 (high sensitivity)
Interface Measurement	Manual calibration Mode #7
Plugged Chute Indication for Solids (Bulk density greater than 20 #’s per cubic foot)	Manual calibration Mode #7
Plugged Chute Indication for Solids (Bulk density under 20 #’s per cubic foot)	Manual calibration Mode #8 (high sensitivity)

## 2.10.2 Using ThePoint with Auto-Calibration mode #2

After ThePoint is installed in the vessel, simply apply power. ThePoint electronic unit will auto calibrate.



### Caution

The material being measured must be below the sensing element when power is applied (Sensing element uncovered).



### Note:

If power has been applied to ThePoint prior to installation (on a test bench) or, if ThePoint is moved from one vessel to another, **RECAL** is necessary. RECAL allows the system's software to capture the air capacitance generated by the sensing element in tank.

Merely press and hold the RECAL button (shown in Figure 2-6) for five (5) seconds. After five seconds, ThePoint's two LED's flash for sixty seconds before the recalibration occurs. (Removing power from the system while the LED's are flashing will reset the memory immediately upon next power up).

Calibration is complete.

### 2.10.3 Using ThePoint with Manual Calibration modes #7, and 8



#### **Warning!**

Before removing the explosion-proof housing cover in a potentially hazardous area, make certain that the area is safe. When calibration is complete, the cover must be replaced.

Make sure that ThePoint is set to either mode #7 (standard Sensitivity) or mode #8 (high sensitivity).

See section 2.10.4 for mode selection procedure.

Locate the manual calibration pot on the top of ThePoint electronic unit (see figure 2-6).

The adjustment pot located on the top of the unit controls the point at which the relay operates. A red LED indicates that the relay is de-energized.

Full range of the pot is 25 turns. Each rotation of the pot changes the operating point by 4pF (Mode #7 standard Sensitivity) or 1pF (mode #8 high sensitivity).

Turning adjustment clockwise will raise level at which relay operates. Turning the adjustment counterclockwise will lower the level at which the relay operates.



#### **Calibration Procedures**















For water-based conducting applications using bare metal sensing elements, turn the adjustment point full clockwise. No other adjustment is required.

### 2.10.3 Manual Calibration modes #7, and 8 (Continued)

#### Manual Calibration

When material level can be moved

Make certain that ThePoint is in manual calibration mode #7 or 8 See Section 2.10.4










Configuration Settings	Adjustment Potentiometer	RED LED	Notes	
Fail Safe = High Level  Time delay set to zero (full counter clockwise – DO NOT FORCE PAST STOP)  Time delay action = either	Turn counter clockwise until RED LED is ON  	RED LED ON  	Material being measured must be below sensor at least twelve inches	
	Turn clockwise until RED LED just goes OFF  	RED LED OFF  		
		RED LED will come ON  	Raise material level in vessel until sensor is covered	
	Turn clockwise counting the number of turns until the RED LED goes OFF (or 25 turns whichever comes first)  	RED LED OFF (Or 25 turns whichever comes first)    If red LED is not off, skip next step		
	Turn counter clockwise one half the number of turns counted  	RED LED will come ON  		
	<b>Calibration is Complete</b>			

### 2.10.3 Manual Calibration modes #7, and 8 (Continued)

#### Manual Calibration

When material level **can not** be moved

Make certain that ThePoint is in manual calibration mode #7 or 8 See Section 2.10.4

Configuration Settings	Adjustment Potentiometer	RED LED	Notes	
Fail Safe = High Level  Time delay set to zero (full counter clockwise – DO NOT FORCE PAST STOP)  Time delay action = either	Turn counter clockwise until RED LED is ON  	RED LED ON  	Material being measured must be below sensor at least twelve inches	
	Turn clockwise until RED LED just goes OFF  	RED LED OFF  		
Turn Adjustment Potentiometer Clockwise the number of turns indicated in the table below for your material type		RED LED OFF  		

Material Being Measured	Mode #7 (Standard Sensitivity)	Mode # 8 (High Sensitivity)
Conductive Materials (Water-Based) see note #1	15 Turns(Note 2)	20 Turns
Insulating Liquids, Organics, Oil, Plastics	1/2 Turn	2 Turns
Granular/Solid materials above 50#/ft3	1/2 Turn	2 Turns
Granular/Solid materials 25-50#/ft3	1/2 Turn	1 Turn
Granular/Solid materials less than 20#/ ft3	Use High Sensitivity Mode #8	3/4 Turn
Moist Granular Plugged Chute Applications using flush mount 700-0207 series sensing element (See Note 3)	1 turn	4 turns
Dry Granular Plugged Chute Applications using flush mount 700-0207 series sensing element	Use High Sensitivity Mode #8	½ turn

**Calibration is Complete**



### 2.10.3 Manual Calibration modes #7, and 8 (Continued)

**Note 1:** Most water based materials can be considered conductive, such as acids, bases, salt solutions, water based slurries, and very wet granular materials. Carbon black and powdered metals conduct even without water.

**Note 2:** With conducting materials, if heavy build up is anticipated, calibration adjustment can be turned to its clockwise limit.

**Note 3:** Some Wet Granular materials can be extremely conductive and may require special calibration or different electronic units. If the standard calibration in the table does not provide satisfactory results, please contact the field service department at 215-674-1234.

#### Nonvolatile Memory

ThePoint has Nonvolatile memory which allows the unit to re-start after power outages without recalibrating.

When ThePoint is powered for the first time the internal microprocessor records and stores the “Air” value. This is the uncovered capacitance value of the sensor mounted in the vessel. ThePoint will also store the last covered value and the last uncovered value.

Whenever ThePoint is powered it uses these values as a reference point to determine its current condition (normal or alarm).

## 2.10.4 Accessing the Calibration Modes

1. On the top side of ThePoint, temporarily remove the shunt from the “Time Delay Selection Jumper” (see Fig. 2) and place it on pins 1 & 2 of the 3-pin connector. Pin 1 is closet to the LEDS. The green LED will go out and the red LED will begin to flash. The number of flashes indicates which mode the unit is in (1 through 8).
2. To switch modes, press and hold the ReCal button next to the 3-pin connector. The unit will cycle through the modes.

First it will flash the current mode setting, then progress through all of the settings.

### For Example:

The red LED will flash once indicating mode 1. Then it will flash twice-indicating mode 2. Then mode 3, etc.

Release the button when it reaches the desired mode. The red LED will now flash indicating which mode the unit is in.




3. Remove the shunt from pins 1 & 2 on the 3-pin connector and replace the shunt on the “Time Delay Selection Jumper”. The unit will remain in the selected mode. Write the new mode # on the inside of the lid label for future reference
4. After setting the mode follow procedure in section 2.8.2 for mode 2 & 6. For modes 7 and 8, follow the appropriate manual calibration procedure as described in section 2.10.3.

### Failsafe Jumper

Up = High Level  
Down = Low Level

### Time Delay Jumper

Up = Forward Acting  
Down = Reverse Acting



ReCal Button

3 Pin Connector



*Do not push the ReCal button without first ensuring that the material being measured is below the sensing element.*

### Electronic Unit Adjustments

## 2.10.4 Accessing the Calibration Modes (Continued)

### Code Designation - Definition of Modes

<b>L</b>	<b>Mode 2:</b> Fixed Cal 2pF: 2pF differential, set point locked 2pF above starting capacitance
<b>M</b>	<b>Mode 7:</b> Manual calibration standard sensitivity – pots adjusts from 0 to 65pF
<b>G</b>	<b>Mode 8:</b> Manual calibration High sensitivity – pot adjusts from 0 to 27 pF
<b>P</b>	<b>Mode 6:</b> Fixed Cal 0.5pF: 0.5pF differential, set point locked 0.5pF above starting capacitance

### Code Designation - Other Calibration Modes

<b>N</b>	<b>Mode 1:</b> Auto-Cal 2pF: 2pF differential, set point varies depending on material
<b>T</b>	<b>Mode 3:</b> Auto-Cal 10pF: 10pF differential, set point varies depending on material
<b>V</b>	<b>Mode 4:</b> Fixed Cal 10pF: 10pF differential, set point locked 10pF above starting capacitance
<b>H</b>	<b>Mode 5:</b> Auto-Cal 0.5pF: 0.5pF differential, set point varies depending on material

### Determining the Current Calibration Mode

ThePoint will be shipped in the Auto-Cal mode #2 unless pre-ordered in a specific mode. To determine if the ThePoint has been shipped in a mode other than #2, look at the label on the blue electronic unit. The model number will be 385-0051-012-0X. The “X” indicates the pre-set mode typically a “2” for mode #2

If the Mode has been changed after receiving the unit, the person changing the mode should have made a note of the new mode on the label inside the lid of the housing.

If there is no note on the lid or if there is a question as to what the current mode is, the following procedure can be used:

On the topside of ThePoint, temporarily remove the shunt from the “Time Delay Selection Jumper” (see Fig. 2) and place it on pins 1 & 2 of the 3-pin connector. The green LED will go out and the red LED will begin to flash. The number of flashes indicates which mode the unit is in (1 through 8).

After determining the current mode, replace the shunt on the “Time Delay Selection Jumper”.

## **Section 3**

## Section 3: Troubleshooting




### WARNING

If ThePoint instrument is located in a hazardous environment, do not open enclosure cover or make/break any electrical connections without first disconnecting electrical power at the source. Ensure that wiring, electrical fittings and conduit connections conform to electrical codes for the specific location and hazard level.


### 3.1 Testing Sensing Element

To test the sensing element, disconnect the integral cable as discussed in Section 2.9. See Figure 3-1.



Expect the following measurements:

For Three-terminal Probes:  
under sensor side  
of integral cable...



Measured Resistance (Sensor dry and clean):

Center Wire - Ground	$\infty$ Ohms
Center Wire - Shield	$\infty$ Ohms
Shield - Ground	$\infty$ Ohms

Resistance readings must be taken  
using an analog ohmmeter set to Rx1000 scale.

When tank level is known to be below the sensor,  
minimum acceptable values are:

Center Wire - Ground	1000 Ohms.
Center Wire - Shield	600 Ohms.
Shield - Ground	300 Ohms.

If the readings are less than the minimum  
acceptable values:

1. Check to see if tank is full, or if a severe coating is present.
2. Clean sensor and re-measure the sensor resistances.

Note:



Low resistance readings are acceptable if the sensor is covered with a conductive liquid. Also, low resistance readings can be the result of material lodging in a long mounting nozzle. Refer to Figure 2-2.

Note:



A reading of zero (0) Ohms usually indicates a metal-to-metal short circuit. Check for contact with tank wall, mounting nozzle, or other tank structure.

**Figure 3-1**  
**Testing Sensing Element**


## 3.2 Testing Electronic Unit

Use the following steps to test the electronic unit:



1. Be sure environment is safe before removing lid from housing.

2. Observe **FAILSAFE** jumper on circuit board on top of electronic unit (shown in Figure 2-6). Move jumper from current setting to alternate setting [**HLFS** to **LLFS** or vice versa]. Alarm & relay should change state.



3. If possible to access sensing element with material below sensor, or remove ThePoint from vessel, touch tip of sensor with your finger, while holding any bare metal portion of instrument housing with other hand. Alarm & relay should change state.

4. If ThePoint changes state while moving jumper, but not while touching sensing element, in most cases, integral cable is faulty. *See Section - 3.6, Testing Integral Cable.*



5. If ThePoint is stuck in one state:




A. Remove power.

B. Disconnect coax cable that joins sensing element to electronic unit. *See Section - 2.9, Sensing Element Connection.*

C. Apply power.

D. Repeat step 2.

E. If ThePoint changes state with sensing element disconnected, in most cases, sensing element is faulty. *See Section - 3.1, Testing Sensing Element.*



6. If there was no Change of state in either step 2 or step 3 and unit appears dead:

A. Remove and then reapply power.

B. Press **RESET** (shown in Figure 2-6).

C. Observe the two LEDs flashing for about 60 seconds.

D. Green LED should be lit after 60 seconds.

E. Touch sensing element with your finger.

F. Alarm & relay should change state. If so, circuit board is working properly.


G. Reinstall instrument and press **RESET**.

7. If ThePoint fails all of above tests, in most cases instrument is faulty. Use replacement electronic unit to determine the fault. Consult factory.

### 3.3 Testing Relay Circuits

Use the following steps to check out the relay circuits:

1. Relay connections consist of a double-pole double-throw (DPDT) relay.
2. The relay contacts are brought out to terminal strips for external switching. *See Figure 3-2.*
3. Relay operation may generally be heard as an audible click when background noise is not too high. Connect ohmmeter to relay contacts to determine if they are switching.



*Figure 3-2  
Relay Circuit Operation*



### 3.4 Over Range

If the GREEN LED is flashing, the instrument has detected the uncovered sensing element capacitance exceeds the limits of the transmitter. *Consult factory instructions.*

### 3.5 Under Range


If the RED LED is flashing, the instrument has detected the sensing element capacitance is too small. *Consult factory for sensing element capacitor values.*

### 3.6 Testing Integral Cable



**Figure 3-3**  
**Testing Integral Cable**

### 3.7 Testing Remote Cable



**Figure 3-4**  
**Testing Remote Cable**



## 3.8 Factory Assistance

AMETEK Drexelbrook can answer any questions about ThePoint series instrument. Call Customer Service at +1 215 674-1234.

If you require assistance and attempts to locate the problem have failed:

Contact your local Drexelbrook representative,



**Telephone** the Service department toll-free:

- +1 215 674-1234

**FAX:** Service Department + 215-443-5117

**E-mail:** [drexelbrook.service@ametek.com](mailto:drexelbrook.service@ametek.com)

Please provide the following information:

- Instrument Model Number
- Sensing Element Model Number and Length
- Original Purchase Order Number
- Material being measured
- Temperature
- Pressure
- Agitation
- Brief description of the problem
- Checkout procedures that have failed

## 3.9 Field Service

Trained field servicemen are available on a time-plus-expense basis to assist in start-ups, diagnosing difficult application problems, or in-plant training of personnel. Contact the service department for further details.

## 3.10 Customer Training

Periodically, AMETEK Drexelbrook instrument training seminars for customers are held at the factory. These sessions are guided by Drexelbrook engineers and specialists, and provide detailed information on all aspects of level measurement, including theory and practice of instrument operation. For more information write to:  
AMETEK Drexelbrook, Communications/ Training Group  
or call 215-674-1234.

### 3.11 Equipment Return

In order to provide the best service, any equipment being returned for repair or credit must be pre-approved by the factory.

In many applications, sensing elements are exposed to hazardous materials.

- **OSHA mandates** that our employees be informed and protected from hazardous chemicals.
- **Material Safety Data Sheets (MSDS)** listing the hazardous materials to which the sensing element has been exposed **MUST** accompany any repair.
- It is your responsibility to fully disclose all chemicals and **decontaminate** the sensing element.



**To obtain a return authorization (RA#),** contact the Service department at 215-674-1234.

Please provide the following information:

- Model Number of Return Equipment
- Serial Number
- Original Purchase Order Number
- Process Materials to which the equipment has been exposed.
- MSDS sheets for any hazardous materials
- Billing Address
- Shipping Address
- Purchase Order Number for Repairs
- Please include a purchase order even if the repair is under warranty. If repair is covered under warranty, you will not be charged.

Ship equipment freight prepaid to:  
AMETEK DREXELBROOK  
205 KEITH VALLEY ROAD  
HORSHAM, PA 19044-1499  
COD shipments will not be accepted.

### 3.12 RF Point Level Troubleshooting Guide

Symptom	Possible Cause	Solution	See Section
Switch is in alarm and will not clear	Sensor is coated by a conductive material and the Cote-Shield™ element does not extend far enough into the vessel	Need a sensor with a longer Cote-Shield element. Rule of thumb is nozzle length + expected wall coating + 2 inches.	Section 2.2
	Fail Safe switch is set to the wrong setting	Check to make sure the fail safe switch is in the correct position	Section 2.6.3
	Active section of sensor is touching an internal structure or material is bridging active to ground.	May be able to shorten sensor (consult factory) or relocate sensor.	Appendix A
	Connection cable or harness between unit and sensor is damaged	Check connection cable for shorts, opens, or damage and proper termination	Section 3.6
	Flexible sensor is swaying and active is touching vessel or structure	Add 1 or 2 seconds of reverse acting time delay.	Section 2.6.1
Switch stays in alarm for extended period after level falls below sensor	Material bridging from active to tank structure	May be able to shorten sensor (consult factory) or relocate sensor.	Appendix A
	Time delay may be active	Make sure time delay pot is full counterclockwise.	Section 2.6.1
Switch does not respond to material	There may not be enough active to “see” an insulating material	Try changing to high sensitivity or adding active length to sensor	Section 2.9.5 Appendix A
	Switch was calibrated with sensor covered by material	Make sure material level is below sensor and re-calibrate	Section 2.9
	Granular material – Active section is not getting enough coverage due to angle of repose	Relocate sensor to get more coverage or lengthen active. Changing to high sensitivity may also help.	Section 2.9.5 Appendix A
	Connection cable or harness between unit and sensor is damaged	Check connection cable for shorts, opens, or damage and proper termination	Section 3.6
Switch delays in responding to material	Reverse acting time delay may be active	Check time delay settings to make sure they are correct	Section 2.6.1
LED's are Flashing	Flashing LED's indicate one of two things. Over Range / Under Range	Consult instruction manual to determine which of the three symptoms are experienced.	Section 3.4 Section 3.5
Over Range indicates that the standing capacitance of the sensing element in the vessel is too large to allow calibration	A long sensing element may generate too much standing capacitance to calibrate out	Padding is required – consult factory	Section 3.4
	The sensor could be touching an internal tank structure	May be able to shorten sensor (consult factory) or relocate sensor.	Appendix A
	Switch was calibrated with sensor covered by material	Make sure material level is below sensor and re-calibrate	Section 2.9
	Improper wiring connection (Remote Switches)	Check remote cable connections to confirm they are correct.	Section 3.6
Under Range indicates that the electronic unit is not seeing enough capacitance.	ThePoint™ - Electronic unit is not attached to back board Probe to shield short Check probe and cable resistances	Remove electronic unit and make certain that connection pins are not damaged. Re inset electronic unit making sure it is connected to back board.	Section 3.5 Section 3.1 Section 3.5
	Unit is damaged	Consult factory	Section 3.8
Green Power LED is out	Electronic unit is not getting power	Check power source to make sure proper power is supplied and connections are correct	Section 2.3
	Electronic unit is damaged	Consult factory	Section 3.8
Unit does not respond when pressing the Calibration Button	Cal button only operates when switch is set to Auto-Cal mode	Check to make sure switch is in Auto-Cal	Section 2.9.5
	Electronic Unit is damaged	Consult Factory	Section 3.8

## **Section 4**

## Section 4: Specifications

<b>Technology:</b>	RF/ Capacitance
<b>Calibration:</b>	None
<b>Modes of Operation:</b>	High and Low level
<b>Repeatability:</b>	2 mm (0.08 inch) conductive liquids
<b>Response Time:</b>	less than 1 second
<b>Time Delay:</b>	0 to 60 seconds forward and reverse acting
<b>Ambient Electronics:</b>	40 to 70°C (-40 to 158°F)
<b>Storage Temperature:</b>	-40 to 85° C (-40 to 185° F)
<b>Indicators:</b>	LEDs: Green Power, Red relay
<b>Power supply:</b>	Universal Supply 19 to 250 Vac 18 to 200 Vdc auto-detecting without jumper changes
<b>Power consumption:</b>	2 watts maximum
<b>Relay Contacts:</b>	(one) DPDT
<b>Maximum Contact Load:</b>	5A / 30 Vdc 5A / 250 Vac
<b>Maximum Switching Capacity:</b>	2000 VA / 150 Watt
<b>Minimum Contact Load (DC):</b>	100 mA / 12 Vdc 0 to 200 mA / 12 VDC (Optional)
<b>Housing (electronics):</b>	Powder-coated aluminum with two cable entries
<b>Cable entry:</b>	M20 x 1.5 or ¾-inch NPT
<b>Ingress Protection:</b>	IP66 NEMA 4X
<b>Approvals:</b>	ATEX, FM / FMc, IECEX

## 4.1 Approvals Available



### Remote:

Explosion-proof for Class I, Division 1, Groups A, B, C, and D;  
Dust-Ignition proof for Class II, III, Division 1, Groups E, F, and G;  
Non-incendiary for Class I, Division 2, Groups A, B, C, & D;  
Suitable for Class II, III, Division 2, Groups F & G hazardous outdoor Type 4, 4X, IP66 (classified) locations with Intrinsically Safe connections to Class I, II, III, Division 1, Groups A, B, C, D, E, F, and G hazardous (classified) locations in accordance with Control Drawing 420-0004-181-CD.



### Integral:

[Same, but Group A does not apply]



### ATEX

#### Integral

II 2G Ex db ia IIC T5 Gb

II 2D Ex tb ia IIIC T95 oC Db

-30°C < T<sub>o</sub> < 70°C

#### Remote

II 2 (1)G Ex db [ ia Ga] IIC T5 Gb

II 2 (1)D Ex tb [ ia Ga] IIIC T95 oC Db

-30°C < T<sub>o</sub> < 70°C

FM 16ATEX0024X

### IECE<sub>x</sub>

#### Integral

Ex db ia II C T5 Gb

Ex tb ia IIIC T90°C Db

-30°C < T<sub>o</sub> < 70°C

#### Remote

Ex db [ia Ga] IIC T5 Gb

Ex tb [ia Ga] IIIC T95°C Db


IECE<sub>x</sub> FMG 10.0017X

## Section 5: Control Drawings

## 5.1 FM / FMc Control Drawings

NO. 420-0004-181-CD

SHT 1 OF 11



MODEL NUMBERING SYSTEM FOR FM APPROVED INTEGRAL SYSTEMS - SEE SHEETS 8 AND 9

NOTES:

1. INSTALLATIONS IN CANADA MUST BE IN ACCORDANCE WITH THE CANADIAN ELECTRICAL CODE (C22.1) AS APPLICABLE.
2. THE INSTALLATION MUST BE IN ACCORDANCE WITH NATIONAL ELECTRICAL CODE (ANSI/NFPA 70).
3. CABLE FITTINGS SUPPLIED ARE "WEATHER RESISTANT". THEY ARE NOT CERTIFIED AS "EXPLOSIONPROOF" (XP) OR "FLAMEPROOF" (d) UNLESS THEY ARE MARKED. REPLACE WITH APPROPRIATE SEAL FITTINGS AS REQUIRED.
4. USE SUPPLY WIRING RATED FOR 90°C OR HIGHER WHEN AMBIENT IS ABOVE 50°C.
5. USE COPPER WIRING ONLY.
6. ASSOCIATED APPARATUS MUST NOT GENERATE MORE THAN 250 VOLTS.
7. NO REVISIONS TO THIS DRAWING WITHOUT FM APPROVAL.
8. UNUSED OPENINGS MUST BE PROPERLY SEALED TO MAINTAIN ENCLOSURE ENVIRONMENTAL AND/OR HAZARDOUS LOCATION RATINGS.

CERTIFIED		6	6-18-111	JEN	6-22-18	COPYRIGHT	2018	FM/FMc CONTROL DRAWING FOR "ThePoint" SERIES CLASS 1, DIVISION 1, GROUP B (INTEGRAL)	
PO #	by	5	4-10-102	THP	12-15-10	AMETEK	DREXELBROOK	ISS	6
ENG		4	2-09-102	SCA	2-6-09	SCALE	NONE	SHT. 1	OF 11
USER		3	1-06-216	THP	1-29-07	ALL DIMENSIONS IN INCHES (MM)		420-0004-181-CD	
		2	2-04-216	THP	2-26-04	DR.	JHM 6-22-18		
DE #		1	ISS/EDO/DSR	NO.	APP'D	DATE	CK.	JEN 6-22-18	

215-674-1234  
FAX 215-674-2731205 KEITH VALLEY RD.  
HORSHAN, PA 19044-9986


**AMETEK®**  
**DREXELBROOK**

SHT 2 OF 11



1. INSTALLATION IN CANADA MUST BE IN ACCORDANCE WITH THE CANADIAN ELECTRICAL CODE (C22.1) AS APPLICABLE.

1. INSTALLATION IN CANADA MUST BE IN ACCORDANCE WITH THE CANADIAN ELECTRICAL CODE (C22.1) AS AMENDED.
2. THE INSTALLATION MUST BE IN ACCORDANCE WITH NATIONAL ELECTRICAL CODE® ANSI/NFPA 70.
3. CABLE FITTINGS SUPPLIED ARE "WEATHER RESISTANT". THEY ARE NOT CERTIFIED AS "EXPLOSIONPROOF" (XP) OR "FLAMEPROOF" (d) UNLESS THEY ARE MARKED. REPLACE WITH APPROPRIATE SEAL FITTINGS AS REQUIRED.
4. USE SUPPLY WIRING RATED FOR 90°C OR HIGHER WHEN AMBIENT IS ABOVE 50°C.
5. USE COPPER WIRING ONLY.
6. ASSOCIATED APPARATUS MUST NOT GENERATE MORE THAN 250 VOLTS.
7. NO REVISIONS TO THIS DRAWING WITHOUT FM APPROVAL.
8. UNUSED OPENINGS MUST BE PROPERLY SEALED TO MAINTAIN ENCLOSURE ENVIRONMENTAL AND/OR HAZARDOUS LOCATION RATINGS.

CERTIFIED	b y _____		6	6-18-111	JEN	6-22-18	COPYRIGHT 2018	 <b>DREXELBROOK</b>	FM/FMC CONTROL DRAWING FOR "ThePoint" SERIES CLASS 1, II, III DIVISION 1, GROUPS C-G (INTEGRAL)	ISS. 2 SHT. 2 OF 11 420-0004-181-CD
PO #	5		4-10-102	THP	12-15-10	AMETEK DREXELBROOK				
ENG	4		2-09-102	SGA	2-6-09	SCALE NONE				
USER	3		1-06-216	THP	1-29-07	UNLESS OTHERWISE STATED ALL DIMENSIONS IN INCHES (MM)				
	2		2-04-216	THP	2-26-04	DR. JHM 6-22-18				
#	ISS. FPD/DRS NO.		APP' D	DATE	JEN 6-22-18		205 KEITH VALLEY RD. 215-674-1234			



## 5.1 FM / FMc Control Drawings (Continued)

NO. 420-0004-181-CD SHT 3 OF 11

**EXPLOSIONPROOF TRANSMITTER ENCLOSURE  
(INTEGRAL PROBE)**

DIVISION 2 CLASS I GROUPS A-D; CLASS II GROUPS F-G; CLASS III  
SENSING ELEMENTS ARE INTRINSICALLY SAFE FOR ABOVE CLASSIFICATIONS.

**HAZARDOUS (CLASSIFIED) AREA**

**NON-HAZARDOUS AREA**

EQUIPMENT MUST NOT USE OR  
GENERATE MORE THAN 250 VAC.

EXPLOSIONPROOF AND FLAMEPROOF ENCLOSURE TYPE 4, 4X, IP66

CONDUIT OR OTHER SUITABLE CABLING SYSTEM

CONDUIT SEAL

RELAY CONNECTIONS 30VDC OR 250 VAC (MAXIMUM) TERMINALS 4-9

INPUT VOLTAGE 18-200 VDC 19-250 VAC 50-60 Hz, 2W CHASSIS GROUND 1 TERMINALS 2-3

FLANGE OR THREADED MOUNTING

SENSING ELEMENT

DIVISION 1 CLASS I GROUPS A-D; CLASS II GROUPS E-G; CLASS III  
MODEL NUMBERING SYSTEM FOR FM APPROVED INTEGRAL SYSTEMS - SEE SHEETS 8 AND 9.

NOTES:

1. INSTALLATION IN CANADA MUST BE IN ACCORDANCE WITH THE CANADIAN ELECTRICAL CODE (C22.1) AS APPLICABLE.
2. THE INSTALLATION MUST BE IN ACCORDANCE WITH NATIONAL ELECTRICAL CODE® ANSI/NFPA 70.
3. CABLE FITTINGS SUPPLIED ARE "WEATHER RESISTANT"; THEY ARE NOT CERTIFIED AS "EXPLOSIONPROOF" (XP) OR "FLAMEPROOF" (d)
4. UNLESS THEY ARE MARKED, REPLACE WITH APPROPRIATE SEAL FITTINGS AS REQUIRED.
5. USE SUPPLY WIRING RATED FOR 90°C OR HIGHER WHEN AMBIENT IS ABOVE 50°C.
6. USE COPPER WIRING ONLY.
7. ASSOCIATED APPARATUS MUST NOT GENERATE MORE THAN 250 VOLTS.
8. NO REVISIONS TO THIS DRAWING WITHOUT FM APPROVAL.
9. UNUSED OPENINGS MUST BE PROPERLY SEALED TO MAINTAIN ENCLOSURE ENVIRONMENTAL AND/OR HAZARDOUS LOCATION RATINGS.

CERTIFIED	by	6	6-18-111	JEN	6-22-18	COPYRIGHT	2018
PO #		5	4-10-102	THP	12-15-10	AMETEK	DREXELBROOK
ENG		4	2-09-102	SGA	2-6-09	SCALE	NONE
USER		3	1-06-216	THP	1-29-07	SCALE DIMENSIONS IN INCHES (MM)	
		2	2-04-216	THP	2-26-04	DR.	JHM 6-22-18
ISS.	EDD/DSR NO. APP'D				DATE	CK.	JEN 6-22-18
DE #							

FM/FMc CONTROL DRAWING FOR  
"ThePoint" SERIES  
DIVISION 2, (INTEGRAL)

215-674-1234  
FAX 215-674-2731


205 KEITH VALLEY RD  
HORSHAM, PA 19044-9986

420-0004-181-CD SHT. 3 OF 11 ISS. 6


SHT 4 OF 11




## 5.1 FM / FMc Control Drawings (Continued)



## 5.1 FM / FMc Control Drawings (Continued)



## 5.1 FM / FMc Control Drawings (Continued)





# 5.1 FM / FMc Control Drawings (Continued)

700-0001-001	700-0002-053	700-0018-124
700-0001-002	700-0002-054	700-0018-126
700-0001-004	700-0002-055	700-0018-134
700-0001-005	700-0002-056	700-0018-144
700-0001-007	700-0002-057	700-0018-222
700-0001-012	700-0002-059	700-0018-226
700-0001-013	700-0002-060	700-0018-234
700-0001-014	700-0002-061	700-0018-242
700-0001-016	700-0002-062	700-0018-243
700-0001-022	700-0002-063	700-0018-245
700-0001-023	700-0002-064	700-0018-246
700-0001-024	700-0002-321	700-0018-262
700-0001-026	700-0002-360	700-0021-001
700-0001-029	700-0003-009	700-0021-002
700-0001-034	700-0004-038	700-0021-003
700-0001-035	700-0004-045	700-0021-007
700-0001-038	700-0004-050	700-0021-008
700-0001-039	700-0005-012	700-0201-005
700-0001-042	700-0005-014	700-0201-008
700-0001-044	700-0005-018	700-0201-009
700-0001-045	700-0005-028	700-0201-010
700-0001-051	700-0005-035	700-0201-015
700-0001-052	700-0005-038	700-0201-016
700-0001-053	700-0005-045	700-0201-018
700-0001-054	700-0005-048	700-0201-025
700-0001-061	700-0005-054	700-0201-026
700-0001-062	700-0005-114	700-0201-035
700-0001-063	700-0005-148	700-0201-036
700-0001-064	700-0005-214	700-0201-105
700-0001-324	700-0005-314	700-0201-108
700-0001-344	700-0005-348	700-0201-109
700-0002-012	700-0005-354	700-0201-118
700-0002-018	700-0008-122	700-0201-135
700-0002-021	700-0008-123	700-0202-002
700-0002-022	700-0008-124	700-0202-004
700-0002-023	700-0008-126	700-0202-019
700-0002-024	700-0008-134	700-0202-023
700-0002-025	700-0008-144	700-0202-024
700-0002-027	700-0008-222	700-0202-033
700-0002-028	700-0008-226	700-0202-036
700-0002-029	700-0008-234	700-0202-043
700-0002-033	700-0008-242	700-0202-102
700-0002-035	700-0008-243	700-0204-038
700-0002-036	700-0008-245	700-0204-045
700-0002-037	700-0008-246	700-0204-048
700-0002-039	700-0008-262	700-0221-002
700-0002-041	700-0009-002	700-1202-001
700-0002-042	700-0009-024	700-1202-018
700-0002-043	700-0011-001	700-1202-021
700-0002-044	700-0011-003	700-1202-022
700-0002-047	700-0011-004	700-1202-024
700-0002-051	700-0011-015	700-1202-028
700-0002-052	700-0018-122	700-1202-041
	700-0018-123	700-1202-042

COPYRIGHT 2018  
AMETEK DREXELBROOK

SCALE NONE  
UNLESS OTHERWISE STATED  
ALL DIMENSIONS IN INCHES (MM)

DR. JHM 6-22-18  
CK. JEN 6-22-18

CERTIFIED by \_\_\_\_\_

PO # \_\_\_\_\_

ENG \_\_\_\_\_

USER \_\_\_\_\_

DE # \_\_\_\_\_

6	6-18-111	JEN	6-22-18
5	4-10-102	THP	12-15-10
4	2-09-102	SGA	2-6-09
3	1-06-216	THP	2-26-04
ISS.	EDO/DSR NO.	APP'D	DATE

**AMETEK®**  
**DREXELBROOK**

205 KEITH VALLEY RD  
HORSHAM, PA 19044-9986

215-674-1234  
FAX 215-674-2731

FM/FMc APPROVED  
"ThePoint"  
MODEL NUMBERING SYSTEM

420-0004-181-CD

SHT. 9 OF 11  
ISS. 6

NO. 420-0004-181-CD

SHT. 9 OF 11





## 5.1 FM / FMc Control Drawings (Continued)

COLUMNS 9 AND UP DO NOT AFFECT SAFETY											
1	2	3	4	5	6	7	8	9	10	11	12
P	a	L	b	c	d	e	e	*	*	*	*
						3	9				700-0029-105 <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">6</span>
						5	0				700-0207-001
							1				700-0207-002
							2				700-0207-003
							3				700-0207-004
							5				700-0207-006 <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">6</span>
						6	0				700-0204-038
							1				700-0204-002
							2				700-0204-048
							3				700-0204-024 <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">6</span>
							7				700-3201-001 <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">6</span>
<p>MODEL NUMBERS OF APPROVED REMOTE SENSING ELEMENTS</p> <p>701-mnop-qrst LEVEL PROBE</p> <p>l = FAMILY NO. 0, 4  m = FAMILY NO. 0 THROUGH 9, BLANK  n = FAMILY NO. 0 THROUGH 9, BLANK  o = 0 THROUGH 9, BLANK  p = 0 THROUGH 9  q = FAMILY NO. 0 THROUGH 9, BLANK  r = FAMILY NO. 0 THROUGH 9, BLANK  s = FAMILY NO. 0 THROUGH 9  t = 14 CHARACTER EXPANDED NUMBERING SYSTEM, DOES NOT AFFECT SAFETY</p>											

COPYRIGHT 2018  
 AMETEK DREXELBROOK  
 SCALE NONE  
UNLESS OTHERWISE STATED  
ALL DIMENSIONS IN INCHES (MM)  
 DR. JHM 6-22-18  
 CK. JEN 6-22-18

CERTIFIED \_\_\_\_\_ by \_\_\_\_\_  
 PO # \_\_\_\_\_  
 ENG \_\_\_\_\_  
 USER \_\_\_\_\_  
 DE # \_\_\_\_\_

420-0004-181-CD  
 FM/FMc APPROVED  
 ADDITIONAL REMOTE  
 SENSING ELEMENTS  
 420-0004-181-CD  
 SHT. 11 OF 11  
 ISS. 6

6	6-18-111	JEN	6-22-18	<p style="font-size: small;">205 KEITH VALLEY RD HORSHAM, PA 19044-9986</p> <p style="font-size: x-small;">215-674-1234 FAX 215-674-2731</p>
5	4-10-102	THP	12-15-10	
4	2-09-102	SGA	2-6-09	
3	1-06-216	THP	2-26-04	
ISS.	EDO/DSR NO.	APP'D	DATE	



SHT 1 OF 6


NOTES:

1. ALWAYS INSTALL TO CODES/REQUIREMENTS/DIRECTIVES AS MANDATED BY THE AUTHORITY HAVING JURISDICTION.
2. USE SUPPLY WIRING RATED FOR 90°C OR HIGHER WHEN AMBIENT IS ABOVE 50°C. USE COPPER WIRING ONLY.
3. UNUSED OPENINGS MUST BE PROPERLY SEALED TO MAINTAIN ENCLOSURE ENVIRONMENTAL AND/OR HAZARDOUS LOCATION RATINGS.
4. INSTALLATIONS ARE TO BE IN ACCORDANCE WITH IEC 60079-14.
5. NO REVISIONS TO THIS DOCUMENT WITHOUT FM APPROVAL.
6. **SEE PAGE 6 FOR SPECIFIC CONDITIONS OF USE:**

CERTIFIED	by _____				
PO #	6	1-22-109	SGA	1-28-22	COPYRIGHT 2022
ENG	5	9-14-119	SGA	12-6-16	AMETEK DREXELBROOK
USER	4	9-14-119	NOT RELEASED	SCALE NONE	ALL DIMENSIONS STATED
	3	1-06-216	THP	2-17-06	UNLESS OTHERWISE STATED
	2	3-04-215	THP	4-7-04	ALL DIMENSIONS IN INCHES (MM)
					DR. JEN 1-28-22
					TDH 1-28-22
ISS. #	EDD/DSR NO.	APP'D	DATE	CK.	

205 KEITH VALLEY RD  
HOBBS, PA 16044-9086

215-674-1284  
FAX 215-674-2731



ATEX/IECEX  
CONTROL DRAWING FOR  
"ThePoint" PXLX SERIES  
ZONE 1 OR 2 (INTEGRAL)

420-0004-186-CD

SHT. 1 OF 6

ISS. 6

## 5.2 ATEX Control Drawings (Continued)

NO. 420-0004-186-CD


SHT 2 OF 6

POTENTIALLY HAZARDOUS AREA	EXPLOSIVE GAS AND DUST ATMOSPHERE	NON-HAZARDOUS AREA
PROBE ENCLOSURE 285-0001-062 285-0001-063 285-0001-064 285-0001-065 285-0001-067	II 2(I)G Ex db [Ia Ga] IIC T5 Gb II 2(I)D Ex fb [Ia Ga] IIC T95°C Db -30°C ≤ Ta ≤ 70°C FM 16ATEX0024X	
(SENSING ELEMENTS ARE INTRINSICALLY SAFE FOR ABOVE CLASSIFICATIONS. SEE SHEETS 4, 5 & 6 FOR MODEL NUMBERS.) MODEL NUMBERING SYSTEM FOR ATEX/IECEX APPROVED SYSTEMS - SEE SHEETS 4, 5 & 6		
⑥ NOTES: 1. ALWAYS INSTALL TO CODES/REQUIREMENTS/DIRECTIVES AS MANDATED BY THE AUTHORITY HAVING JURISDICTION. 2. USE SUPPLY WIRING RATED FOR 90°C OR HIGHER WHEN AMBIENT IS ABOVE 50°C. USE COPPER WIRING ONLY. 3. UNUSED OPENINGS MUST BE PROPERLY SEALED TO MAINTAIN ENCLOSURE ENVIRONMENTAL AND/OR HAZARDOUS LOCATION RATINGS. 4. INSTALLATIONS ARE TO BE IN ACCORDANCE WITH IEC 60079-14. 5. NO REVISIONS TO THIS DOCUMENT WITHOUT FM APPROVAL. 6. SEE PAGE 6 FOR SPECIFIC CONDITIONS OF USE.		

CERTIFIED	by _____	6	1-22-109	SGA	COPYRIGHT 2022	<b>AMETEK®</b> <b>DREXELBROOK</b> <small>215-674-1234 FAX 215-674-2731</small> <small>205 KEITH VALLEY RD HORSHAM, PA 19044-9986</small>
PO #		5	9-14-119	SGA	AMETEK DREXELBROOK	
ENG		4	9-14-119	NOT RELEASED	SCALE NONE	
USER		3	1-06-216	THP	UNLESS OTHERWISE STATED ALL DIMENSIONS IN INCHES (MM)	
DE #		2	3-04-215	THP	DR. JEN 1-28-22	
		ISS.	EDD/DSR NO.	APP'D	DATE	CK.


## 5.2 ATEX Control Drawings (Continued)

1	2	3	4	5	6	7	8	9	10	11	12	COLUMNS 9 AND UP DO NOT AFFECT SAFETY
P	a	L	b	2	0	c	d	*	*	*	*	
	a											a = MODE N = STD AUTO CAL
												L = STD 2pF FIXED
												T = 10pF AUTO CAL
												V = 10pF FIXED CAL
												H = HI SENSE .5pF AUTO CAL
												P = HI SENSE .5pF FIXED
												G = HI SENSE MANUAL
												M = STD SENSE MANUAL
			b									b = OUTPUT 1 = 1 DPDT RELAY 2 = 1 GOLD DPDT RELAY
				2								M20 ATEX SYSTEMS
						c	d					c = 0,2 d = 0,1,2,3,4,6,7,8,9 cd = SENSING ELEMENTS
												<b>SENSING ELEMENTS</b>
						0	0					700-1202-021 KEMA 10ATEX0009U
							1					700-1202-022 KEMA 10ATEX0009U
							2					700-1202-024 KEMA 10ATEX0009U
							3					700-1202-028 KEMA 10ATEX0009U
							4					700-1202-042 KEMA 10ATEX0009U
							6					700-1202-032 KEMA 10ATEX0009U
							7					700-1202-020 KEMA 10ATEX0009U
							9					700-1202-034 KEMA 10ATEX0009U
						2	2					700-1202-052 KEMA 10ATEX0009U
							3					700-1202-046 KEMA 10ATEX0009U
							4					700-1202-016 KEMA 10ATEX0009U
							8					700-1202-056 KEMA 10ATEX0009U
<div style="display: flex; justify-content: space-between; align-items: flex-end;"> <div style="width: 45%;"> <p>COPYRIGHT 2022 AMETEK DREXELBROOK</p> <p>SCALE NONE UNLESS OTHERWISE STATED ALL DIMENSIONS IN INCHES (MM)</p> <p>DR. JEN 1-28-22 CK. TDH 1-28-22</p> </div> <div style="width: 45%;"> <p>CERTIFIED by _____</p> <p>PO # _____</p> <p>ENG _____</p> <p>USER _____</p> <p>DE # _____</p> </div> </div>												
6	1-22-109	SGA	1-28-22					ATEX/IECEX APPROVED "ThePoint" RXLX SERIES MODEL NUMBERING SYSTEM ( INTEGRAL )				
5	9-14-119	SGA	12-6-16									
4	9-14-119	NOT RELEASED										
3	1-06-216	THP	2-17-06									
ISS.	EDO/DSR NO.	APP'D	DATE	205 KEITH VALLEY RD HORSHAM, PA 19044-9986				215-674-1234 FAX 215-674-2731				
420-0004-186-CD <div style="float: right; text-align: right;">             SHT. 3 OF 6              ISS. 6           </div>												




NO. 420-0004-402-CD

SHT 3 OF 6

## 5.2 ATEX Control Drawings (Continued)

1								2				3				4			
								COLUMNS 9 AND UP DO NOT AFFECT SAFETY											
1	2	3	4	5	6	7	8	9	10	11	12								
P	a	L	b	2	c	d	e	*	*	*	*								
A	a											a = MODE	N = STANDARD AUTO CAL						
													L = STANDARD 2pF FIXED						
													T = 10 pF AUTO CAL						
													V = 10 pF FIXED						
													H = HI SENSE .5pF AUTO CAL						
B													P = HI SENSE .5pF FIXED						
													G = HI SENSE MANUAL						
													M = STANDARD SENSE MANUAL						
												b = OUTPUT 1 = 1 DPDT RELAY 2 = 1 GOLD DPDT RELAY							
												c = 1-9, A-K - CABLE OPTIONS (REMOTE)							
C												d = 0-3, 5, 6, OR Z SENSING ELEMENTS							
												e = 0-9, OR Z SENSING ELEMENTS							
												SENSING ELEMENTS							
								0	0			700-1202-001							
								1				700-1202-012							
D								2				700-1202-014							
								3				700-1202-018							
								4				700-1202-041							
								6				700-1202-031							
								7				700-1202-010							
E								9				700-1202-033							
								1	0			700-0001-018							
								1				700-0201-005							
								2				700-0201-005... HAST-C							
								3				700-0201-019							
F								4				700-0202-002							
								5				700-0202-043							
								6				700-0002-360							
								7				700-0202-029							
								8				700-0001-022							
G								9				700-0002-023							
								2	0			700-0209-002							
								1				700-1202-051							
								5				700-1202-045							
								6				700-1202-015							
H								7				700-0002-027							
								9				700-1202-055							
	ATEX APPROVED, REMOTE												MORE ON PAGE 5						
	X	6	1-22-109		UPDATE CONDITIONS OF USE				SEE TITLE BLOCK										
	ZONE	ISS	EDO #		DESCRIPTION				APP'D		DATE								
<div style="display: flex; justify-content: space-between; align-items: center;"> <div>  </div> <div> <div style="border: 1px solid black; padding: 2px; font-weight: bold; font-size: 1.2em;">A</div> </div> <div> 420-0004-186-CD </div> <div> SHT OF 4 6 </div> <div> ISS 6 </div> </div>																			

## 5.2 ATEX Control Drawings (Continued)

1								2				3				4																																																							
								COLUMNS 9 AND UP DO NOT AFFECT SAFETY																																																															
1	2	3	4	5	6	7	8	9	10	11	12																																																												
P	a	L	b	2	c	d	e	*	*	*	*																																																												
A								a = MODE				N = STANDARD AUTO CAL				A																																																							
												L = STANDARD 2pF FIXED																																																											
												T = 10 pF AUTO CAL																																																											
												V = 10 pF FIXED																																																											
												H = HI SENSE .5pF AUTO CAL																																																											
												P = HI SENSE .5pF FIXED																																																											
												G = HI SENSE MANUAL																																																											
												M = STANDARD SENSE MANUAL																																																											
b								b = OUTPUT 1 = 1 DPDT RELAY 2 = 1 GOLD DPDT RELAY																																																															
c								c = 1-9, A-K - CABLE OPTIONS (REMOTE)																																																															
d								d = 0-3, 5, 6, OR Z SENSING ELEMENTS																																																															
e								e = 0-9, OR Z SENSING ELEMENTS																																																															
3								SENSING ELEMENTS																																																															
1								700-0029-001																																																															
2								700-0029-002																																																															
3								700-0029-003																																																															
4								700-0029-004																																																															
5								700-0029-005																																																															
6								700-0029-102																																																															
7								700-0029-103																																																															
8								700-0029-104																																																															
9								700-0029-105																																																															
5								700-0207-001																																																															
1								700-0207-002																																																															
2								700-0207-003																																																															
3								700-0207-004																																																															
5								700-0207-006																																																															
6								700-0204-038																																																															
1								700-0204-002																																																															
2								700-0204-048																																																															
3								700-0204-024																																																															
Z								Z				SEE SHEET 6 FOR ADDITIONAL APPROVED SENSING ELEMENTS																																																											
D ATEX APPROVED, REMOTE D																																																																							
<table border="1"> <tr> <td>X</td><td>6</td><td>1-22-109</td><td colspan="10">UPDATE CONDITIONS OF USE.</td><td colspan="3">SEE TITLE BLOCK</td> </tr> <tr> <td>ZONE</td><td>ISS</td><td>EDO #</td><td colspan="10">DESCRIPTION</td><td>APP'D</td><td>DATE</td> </tr> </table>																X	6	1-22-109	UPDATE CONDITIONS OF USE.										SEE TITLE BLOCK			ZONE	ISS	EDO #	DESCRIPTION										APP'D	DATE																									
X	6	1-22-109	UPDATE CONDITIONS OF USE.										SEE TITLE BLOCK																																																										
ZONE	ISS	EDO #	DESCRIPTION										APP'D	DATE																																																									
<table border="1"> <tr> <td colspan="12">REVISION HISTORY</td> <td colspan="2"></td> </tr> <tr> <td colspan="12">  </td> <td colspan="2">A</td> </tr> <tr> <td colspan="12">420-0004-186-CD</td> <td>SHT OF</td><td>5 6</td> </tr> <tr> <td colspan="12"></td> <td>ISS</td><td>6</td> </tr> </table>																REVISION HISTORY																										A		420-0004-186-CD												SHT OF	5 6													ISS	6
REVISION HISTORY																																																																							
												A																																																											
420-0004-186-CD												SHT OF	5 6																																																										
												ISS	6																																																										

## 5.2 ATEX Control Drawings (Continued)

### MODEL NUMBERS OF APPROVED INTRINSICALLY SAFE SENSING ELEMENTS

#### 700-mnop-qrs-t LEVEL PROBE

- m = FAMILY NO. 0 THROUGH 9, BLANK  
 n = FAMILY NO. 0 THROUGH 9, BLANK  
 o = 0 THROUGH 9, BLANK  
 p = 0 THROUGH 9  
 q = FAMILY NO. 0 THROUGH 9, BLANK  
 r = FAMILY NO. 0 THROUGH 9, BLANK  
 s = FAMILY NO. 0 THROUGH 9  
 t = 14 CHARACTER EXPANDED NUMBERING SYSTEM, DOES NOT AFFECT SAFETY

#### NOTES:

1. MAXIMUM PROCESS TEMPERATURE 290°C
2. MAXIMUM SENSOR CAPACITANCE <1 MICROFARAD
3. MAXIMUM INSERTION LENGTH, RIGID SENSOR, 30 FEET (9.144 METERS)
4. MAXIMUM INSERTION LENGTH, FLEXIBLE SENSOR, 2000 FEET (609.6 METERS)
5. SENSING ELEMENT ENCLOSURE IP66 (IP RATING DOES NOT APPLY TO SPECIAL SENSORS SUPPLIED WITHOUT A 285- SERIES SENSING ELEMENT ENCLOSURE).

#### SPECIFIC CONDITIONS OF USE:

PaLb20cd, ThePoint, Level Switch with Integral Sensor, 700-mnop-qrs-t ThePoint Remote Sensor

1. Care must be taken when installing the aluminum enclosure that even in the event of rare incidents, an ignition source due to impact or friction between the enclosure and iron / steel is excluded.
2. The partially insulated sensing element shall be installed and used in such a way that the danger of electrostatic charge is excluded.
3. The equipment shall be installed in such a way that the risk of electrostatic discharge and propagating brush discharges caused by rapid flow of dust is excluded.

PaLb2cde, ThePoint Level Switch Sensor.

1. Consult the manufacturer if dimensional information on the flameproof joints is necessary.
2. The partially insulated sensing element shall be installed and used in such a way that the danger of electrostatic charge is excluded.
3. The equipment shall be installed in such a way that the risk of electrostatic discharge and propagating brush discharges caused by rapid flow of dust is excluded.

COPYRIGHT 2022  
AMETEK DREXELBROOK

SCALE NONE  
UNLESS OTHERWISE STATED  
ALL DIMENSIONS IN INCHES (MM)

DR. JEN 1-28-22  
CK. JDH 1-28-22

CERTIFIED by \_\_\_\_\_  
PO # \_\_\_\_\_  
ENG \_\_\_\_\_  
USER \_\_\_\_\_  
DE # \_\_\_\_\_

6	1-22-109	SGA	1-28-22
5	9-14-119	SGA	12-6-16
4	9-14-119	NOT RELEASED	
3	1-06-216	THP	2-17-06
ISS.	EDO/DSR NO.	APP'D	DATE

**AMETEK®**  
**DREXELBROOK**

205 KEITH VALLEY RD  
HORSHAM, PA 19044-9986

215-674-1234  
FAX 215-674-2731

ATEX/IECEx APPROVED  
"ThePoint" PXLX SERIES  
ADDITIONAL INTRINSICALLY  
SAFE SENSING ELEMENTS  
(REMOTE)

420-0004-186-CD

SHT. 6 OF 6  
ISS. 6

NO. 420-0004-186-CD

SHT. 6 OF 6

# 5.3 Heavy Duty Spark Protection

NO. 377-0001-019

SHT 1 OF 2

## TYPICAL INSTALLATION OF SPARK PROTECTORS

FIGURE -A- : CONNECTION OF THREE CONDUCTOR  
COTE SHIELD CABLE TO FLEXIBLE  
2-TERMINAL ELEMENTS: 700-0005-XXX.

FIGURE -B- : CONNECTION OF THREE CONDUCTOR  
COTE SHIELD CABLE TO RIGID  
2-TERMINAL SENSING ELEMENTS  
700-0001-XXX & 700-0002-XXX.

FIGURE -C- : CONNECTION OF THREE CONDUCTOR  
COTE SHIELD CABLE TO RIGID  
3-TERMINAL SENSING ELEMENTS:  
700-0200-XXX & 700-0202-017.

FIGURE -D- : CONNECTION OF THREE CONDUCTOR  
COTE SHIELD CABLE ON FLEXIBLE  
3-TERMINAL SENSING ELEMENT  
700-0205-XXX.

FOR HI. TEMP APPLICATIONS REFER  
TO 377-0001-016-CD.

APPROVED DRAWING

CHANGES TO THIS DRAWING  
REQUIRE AGENCY APPROVAL  
PER 440-0015-003

☐ IFM ☐ CSA ☒ KEMA

☐ 420-0004-017




FIGURE -A-




FIGURE -B-

FIGURE -C-

FIGURE -D-

CERTIFIED		by		COPYRIGHT 2004		AMETEK DREXELBROOK	
PO #	5	2-04-336	21504	SCALE	NONE	ALL DIMENSIONS IN INCHES (MM)	
ENG	4	7-93-303	JET	5-25-93	ALL DIMENSIONS IN INCHES (MM)		
USER	3	8-92-83	MPG	8-31-92	DR.	CDW	
ISS.	EDO/DSR	NO	APP'D	DATE	CK.	W 3-3-04	
DE #							

AMETEK®  
DREXELBROOK

205 KEITH VALLEY RD  
HORSHAM, PA 19044-9986

215-674-1234  
FAX 215-674-2731

377-0001-019 HEAVY DUTY  
SPARK PROTECTOR  
CUSTOMER CONNECTION  
MOUNTING & WIRING

377-0001-019-CD

SHT. 1 OF 2  
ISS. OF 2



### 5.3 Heavy Duty Spark Protection (Continued)

NO. 377-0001-019

SHT 2 OF 2

#### TYPICAL INSTALLATION OF SPARK PROTECTORS

FIGURE -E- : CONNECTION OF THREE CONDUCTOR  
COTE SHIELD CABLE IN PARALLEL  
WITH REMOTE VERIFY SWITCH.

FOR HI. TEMP APPLICATIONS REFER  
TO 377-0001-016-CD.




FIGURE -E-

**AMETEK®**  
**DREXELBROOK**

205 KEITH VALLEY RD  
HORSHAM, PA 19044-9986

215-674-1234  
FAX 215-674-2731

377-0001-019 HEAVY DUTY  
SPARK PROTECTOR  
CUSTOMER CONNECTION  
MOUNTING & WIRING

377-0001-019-CD SHT. 2 OF 2 ISS. 5

CERTIFIED	BY	COPYRIGHT 2004	AMETEK DREXELBROOK	SCALE NONE	UNLESS OTHERWISE STATED ALL DIMENSIONS IN INCHES (MM)	DR. CDW	CK. JJS	DATE	APP'D	NO.	ISS.
PO #				2-04-336	2-25-93	8-31-92					
ENG				7-93-303	JET	MPG					
USER				8-92-83							
DE #											

## 5.4 Adding a Padded Capacitor

ADDING A PADDED CAPACITOR:  
THE TUNING RANGE OF EACH POINT LEVEL SWITCH IS LIMITED. LONG INSERTION LENGTH SENSING ELEMENTS OR SENSING ELEMENTS MOUNTED IN PIPES OR NEAR METAL OBJECTS MAY GENERATE ENOUGH STANDING CAPACITANCE TO EXCEED THE TUNING RANGE OF THE SWITCH.

THE ADDITION OF AN EXTERNAL PADDING CAPACITOR WILL INCREASE THE TUNING RANGE OF THE UNIT. TUNING RANGES AND EXAMPLES OF INCREASES CAN BE FOUND FOR EACH TYPE OF POINT LEVEL ELECTRONIC SWITCH ON SHEET THREE.

WHEN A PADDING CAPACITOR IS REQUIRED, AN NPO CAPACITOR SHOULD BE ADDED TO THE PADDING TERMINALS AS INDICATED ON SHEET 2. ADDITIONAL PADS CAN BE ADDED IN PARALLEL UNIT A SATISFACTORY TUNING RANGE IS REACHED. IF A TUNING RANGE CANNOT BE REACHED, OR, IF PADDING IS IN EXCESS OF THE MAXIMUM RECOMMENDED TUNING RANGE AS INDICATED IN THE TABLE ON SHEET 3, PLEASE CONTACT THE FACTORY SERVICE DEPARTMENT.

NOTE: ON SOME TRANSMITTERS, THE PAD CAPACITOR IS SOLDERED TO TURRETS. OTHER TRANSMITTERS ATTACH THE LEADS UNDER SCREWS.

NO. 330-0009-022-CD

SHT 1 OF 3

CERTIFIED		by _____		COPYRIGHT 2013		AMETEK DREXELBROOK		PAD CAPACITOR KIT FOR POINT LEVEL SWITCHES		ISS. 330-0009-022-CD		SHT. 1 OF 3	
PO # _____	3	9-13-101	DATA	9-23-13	SCALE	NONE	ALL DIMENSIONS IN INCHES (MM)			215-674-1234 FAX 215-674-2731			
ENG _____	2	6-05-243	WS	7-6-05									
USER _____	1	7-01-303	JET	8-9-01									
DE # _____	ISS.	EDD/DSR NO.	APP'D	DATE	DR. JUS 9-20-13		OK 9-23-13						

## 5.4 Adding a Padded Capacitor (Continued)

No. 330-0009-022-CD

**ThePoint (TM)**

**INTELLIPOINT (TM)**

**LCS (TM) & LCT (TM)**

**AMETEK® DREXELBROOK**  
 205 KEITH VALLEY RD  
 HERSHEY, PA 17044-9986  
 215-674-1234  
 FAX 215-674-2731

CERTIFIED		by		COPYRIGHT 2013		AMETEK DREXELBROOK	
PO #		3	9-13-101	9-23-13	SCALE	NONE	
ENG		2	6-05-243	WS	7-6-05	UNLESS OTHERWISE STATED ALL DIMENSIONS IN INCHES (IN)	
USER		1	7-01-303	JET	8-9-01	DR. JLS 9-20-13	
ISS. EDD/USR NO.	APP'D	DATE					
DE #							

SHEET 2 OF 3

## 5.4 Adding a Padded Capacitor (Continued)

NO. 330-0009-022-CD

SHT 3 OF 3

PRODUCT	SENSITIVITY	MODEL NUMBERS	UN-PADDED TUNING RANGE	PADDING RATIO	PADDING EXAMPLE	MAX RECOMMENDED TUNING RANGE
THE POINT™ LINE POWERED	HIGH	PHL, PPL, PGL	0 TO 25pF	1:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 10pF TO 35pF	50 TO 75pF
THE POINT™ LINE POWERED	STANDARD	PNL, PLL, PTL, PVL, PML	0 TO 60pF	1:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 10pF TO 70pF	120 TO 180pF
THE POINT™ TWO WIRE	HIGH	PHT, PPT, PGT	0 TO 25pF	1:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 10pF TO 35pF	50 TO 75pF
THE POINT™ TWO WIRE	STANDARD	PNT, PLT, PTT, PVT, PMT	0 TO 60pF	1:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 10pF TO 70pF	120 TO 180pF
INTELLIPOINT™ LINE POWERED AND TWO WIRE	HIGH	RHL, RPL, RGL, RHT, RPT, RGT	0 TO 25pF	4.33:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 43pF TO 68pF	50 TO 75pF
INTELLIPOINT™ LINE POWERED AND TWO WIRE	STANDARD	RNL, RLL, RTL, RVL, RML, RNT, RLT, RIT, RVT, RMT	0 TO 100pF	4.33:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 43pF TO 143pF	200 TO 300pF
LCS	HIGH	406-6020, 406-6022	0 TO 8pF	1:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 10pF TO 18pF	16 TO 24pF
LCS	STANDARD	406-6000, 406-6002	0 TO 90pF	3:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 30pF TO 120pF	180 TO 270pF
LCT	HIGH	406-6220, 406-6222	0 TO 8pF	1:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 10pF TO 18pF	16 TO 24pF
LCT	STANDARD	406-6200, 406-6202	0 TO 90pF	3:1	ADDING A 10pF CAP WILL CHANGE THE RANGE TO 30pF TO 120pF	180 TO 270pF

**AMETEK®**  
**DREXELBROOK**

215-674-1234  
FAX 215-674-2731

205 KEITH VALLEY RD  
DREXELBROOK, PA 19044-5066


CERTIFIED		by		COPYRIGHT 2013		AMETEK DREXELBROOK	
PO #							
ENG							
USER							
ISS	3	9-13-101	10/13/13	SCALE	NONE	DATE	8-9-01
	2	6-05-243	WS	7-6-05	ALL DIMENSIONS IN INCHES (IN)		
	1	7-01-303	JET	8-9-01	DR. JIS 9-20-13		
DE #							

PAD CAPACITOR KIT  
FOR POINT LEVEL SWITCHES

330-0009-022-CD

SHT 3 OF 3

## 5.5 Dual Seal Assembly for 700 Series Sensing Elements



5.5 Dual Seal Assembly (Continued)

285-0003-02X DUAL SEAL CONFIGURATION FOR SINGLE COMPARTMENT ENCLOSURE

3 1/4 (83)

3/4" NPTF DISCHARGE PORT CONNECTION, ALUMINUM

BLOWOUT DIAPHRAGM:  
ANNUNCIATION OF PRIMARY PROCESS SEAL FAILURE INDICATED BY  
VISIBLE RUPTURE OF BLOWOUT DIAPHRAGM: MAXIMUM 110 psi  
**CAUTION:** PRESSURE MAY BE PRESENT BEFORE ANNUNCIATION OCCURS.

PRIMARY PROCESS SEAL:  
700 SERIES SENSING ELEMENT  
(SEE SHEET 3 FOR APPLICABLE SENSORS)

STAINLESS STEEL UNION  
(DO NOT LOOSEN)

8" (203)

SECONDARY PROCESS SEAL

REMOTE OR INTEGRAL TRANSMITTER ENCLOSURE

NOTES:  
1. ANSI / ISA 12.27.01-2003 FM CERTIFIED "DUAL SEAL" WHEN USED WITH AMETEK DREXELBROOK 700 SERIES SENSING ELEMENTS  
2. SEE SHEET 3 FOR 700 SERIES PRIMARY SEAL PROCESS WETTED MATERIALS.  
3. REFER TO SENSING ELEMENT TAG FOR PROCESS TEMPERATURE AND PRESSURE RATINGS.

CERTIFIED	by	COPYRIGHT	2015
PO #		AMETEK DREXELBROOK	
ENG		SCALE	NONE
USER		ALL DIMENSIONS IN INCHES (MM)	
		DR.	JEN 3-11-15
		CK.	TDH 3-11-15
DE #		ISS.	EDS/DSR NO. APP'D DATE

CONTROL DRAWING,  
DUAL SEAL ASSEMBLY  
FOR USE WITH  
700 SERIES SENSING ELEMENTS

AMETEK®  
DREXELBROOK

205 KEITH VALLEY RD  
HORSHAM, PA 19044-9966  
215-674-1234  
FAX 215-674-2731

285-0003-0XX-CD

SHT. 2 OF 3

NO. 285-0003-0XX-CD

SHT. 2 OF 3

56

## 5.5 Dual Seal Assembly (Continued)


**SENSING ELEMENTS AVAILABLE**

Sensor Model #	Primary Seal Wetted Materials
700-0001-022	TFE/316SS
700-0001-024	TFE/316SS
700-0001-026	TFE/316SS
700-0001-034	TFE/CS
700-0001-040	POLYETHYLENE/316SS
700-0001-044	PFA/316SS
700-0001-054	TFE/316SS
700-0001-064	TFE/316SS
700-0001-074	TFE/316SS
700-0001-344	PFA/316SS
700-0002-023	TFE/316SS
700-0002-024	TFE/316SS
700-0002-027	FEP/TFE/316SS
700-0002-028	TFE/316SS
700-0002-033	TFE/316SS
700-0002-037	PVDF/TFE/316SS
700-0002-040	UHMW PE/SILICONE/316SS
700-0002-044	PVDF/TFE/316SS

Sensor Model #	Primary Seal Wetted Materials
700-0002-054	FEP/TFE/316SS
700-0002-057	PVDF/TFE/316SS
700-0002-064	PVDF/TFE/316SS
700-0002-224	TFE/316SS
700-0002-321	FEP/TFE/316SS
700-0002-360	PFA/TFE/316SS
700-0005-054	PFA/TFE/316SS
700-0201-005	TFE/316SS
700-0201-025	TFE/316SS
700-0201-026	TFE/316SS
700-0201-027	TFE/316SS
700-0201-028	TFE/316SS
700-0201-035	TFE/316SS
700-0201-051	TFE/316SS
700-0201-052	TFE/316SS
700-0201-058	TFE/316SS
700-0201-059	TFE/316SS
700-0202-002	TFE/316SS

Sensor Model #	Primary Seal Wetted Materials
700-0202-053	TFE/316SS
700-0202-054	TFE/316SS
700-0202-056	TFE/316SS
700-1202-001	PEEK/316SS
700-1202-010	PEEK/316SS
700-1202-014	PEEK/316SS
700-1202-015	PEEK/316SS
700-1202-018	PEEK/316SS
700-1202-031	PEEK/316SS
700-1202-033	PEEK/316SS
700-1202-041	PEEK/316SS
700-1202-045	PEEK/316SS
700-1202-051	PEEK/316SS
700-1202-055	PEEK/316SS
700-1202-061	PEEK/316SS
700-1202-081	PEEK/316SS
700-9100-403	PEEK/316SS
700-9100-404	PEEK/316SS
700-1230-XXX-XX-XXX	PEEK/CS/316SS

CERTIFIED	by _____				COPYRIGHT 2015 AMETEK DREXELBROOK
PO # _____	_____				
ENG _____	_____				
USER _____	_____	3	2-15-111	THP	3-11-15
	_____	2	1-12-114	JEN	1-20-12
	_____	1	4-08-106	TDH	9-10-08
DATE # _____	_____				DR. JEN 3-11-15
	_____				OK. TDH 3-11-15
	_____				ISS. EDO/DSR NO. APP'D DATE



# DREXELBROOK

CONTROL DRAWING,  
DUAL SEAL ASSEMBLY  
FOR USE WITH  
700 SERIES SENSING ELEMENTS

205 KEITH VALLEY RD  
HORSHAM, PA 19044-9986

215-674-1234  
FAX 215-674-2731

285-0003-OXX-CD

SHT. 3 OF 3

## **Appendix A**



## Shortening or Lengthening Sensing Element



**CAUTION:**  
*The length of either  
 Flush Sensing  
 Elements or Insulated  
 Sensing Elements can  
 NOT be changed. Cable  
 Sensing Elements  
 can only be shortened.  
 Instructions are included  
 with each unit.*

### The Need

Sometimes your application calls for probe lengths other than the standard 18-inch or longer insertion lengths supplied. Shortening the sensing element is quite simple and can be done in the field. Lengthening the sensing element, however, is more difficult because the metal rod, typically 304 SS or 316 SS, must be welded.

### Before making any Adjustments:

- 1) Read the following instructions thoroughly.
- 2) Remove power.
- 3) Disconnect the electronics.
- 4) Protect electronics from any static discharge.
- 5) Protect electronics from any heat.

### Shortening

The bare metal center rod of the sensing element can be shortened with a hacksaw. Be careful not to cut either of the two insulators. See Figure on this page.


In applications using conductive or water-based materials, shortening is not a problem. Leave a minimum bare metal center rod length of two (2) inches.

For dry granular materials, such as powder, sand, corn, clinker, etc., you must leave a minimum bare metal center rod length of eight (8) inches. Consult the factory before shortening beyond this point.

### Lengthening

To lengthen the sensing element, an extension rod can be welded onto the end of the bare metal center rod. Make sure that the extension rod is the same metal as the sensing element.

An alternate option is to add a pipe coupling and a section of metal pipe after threading the tip of the sensing element. In this case, the metal pipe need not be identical to the metal of the sensing element.



**Note:**  
*Any changes to probe  
 length after calibration  
 requires recalibration to  
 ensure proper operation.*

## CE Installation Supplement

A. **Purpose:** To provide additional information that is required to be in compliance the CE mark of conformity and 2014/30/EU Directive.

- B. **Definitions:**
1. I/O Sensor/Measurement/Control Port -- Any port which provides level measurement, control, and/or DC power.
  2. I/O AC Power -- Any port which provides AC main power to the instrument.
  3. Housing -- Any enclosure where the sensor and transmitter are located.
  4. Non-metallic applications -- any application where the sensor is not surrounded by a metallic surface.

C. **Installation Specifics:**

### 1. I/O Sensor/Measurement/Control Ports

- Wiring must be twisted pair and run in conduit or an equivalent shielded environment (i.e. shielded braid, cable, etc.).
- The shield terminations must be grounded at the source and destination ports.
- Wiring must be run separate from AC main power and/or any signal exceeding 75 volts DC or 50 volts AC.

### 2. I/O AC Power Port

- Wiring must be run either in conduit or an equivalent shielded environment (i.e. shielded braid, cable, etc.).

---

## CE Installation Supplement

### 3. Remote Installations

- Sensor port must be connected to the transmitter port by one of following means:
  - 401-16 Probe Filter
  - Coaxial cable run in conduit.
  - Triaxial cable.

### 4. Housings

- All installations require the sensor and transmitter to be located in a closed shielded/metal housing (i.e. typically explosion-proof weatherproof housings meet this requirement)

### 5. Sensor Type/Mounting

- In all non-metallic applications the sensor must have a full concentric shield (i.e. needs to be considered when ordering).
- The sensor/sensor conduit must be grounded locally either to a metal support structure or an equivalent earth ground.

### D. Comments:

- Any deviation from these installation requirements should be reviewed with factory, prior to implementation
- These instructions are essential to insure conformity with specific EC directives.



**AMETEK, Inc.**  
**TERMS AND CONDITIONS OF SALE**

For the most current **TERMS AND CONDITIONS OF SALE** for this product,  
please visit our website:

<https://www.drexelbrook.com/support/terms-and-conditions>



205 Keith Valley Road, Horsham, PA 19044  
Telephone: +1 215-674-1234  
Fax: +1 215-674-2731  
E-mail: [drexelbrook.info@ametech.com](mailto:drexelbrook.info@ametech.com)  
Website: [www.drexelbrook.com](http://www.drexelbrook.com)