

ACE-tronics G9 ASD Installation and Operation Manual

ACE-tronics G9 Adjustable Speed Drive

TOSHIBA
Leading Innovation >>>

Document Number: 62078-000

Date: October, 2009



ACE-tronics G9 ASD Installation and Operation Manual

Document Number: 62078-000

Date: October, 2009



Introduction

Congratulations on the purchase of the new **G9 True Torque Control² Adjustable Speed Drive!**

The G9 True Torque Control² Adjustable Speed Drive (ASD) is a solid-state AC drive that features True Torque Control². Toshiba's Vector Control Algorithm enables the motor to develop high starting torque and provide compensation for motor slip, which results in smooth, quick starts and highly efficient operation. The ACE-tronics G9 ASD uses digitally-controlled pulse width modulation. The programmable functions may be accessed via the easy-to-use menu selections or via the **Direct Access Numbers** (see [page 79](#)). This feature, combined with Toshiba's high-performance software, delivers unparalleled motor control and reliability.

The ACE-tronics G9 ASD is a very powerful tool, yet surprisingly simple to operate. The user-friendly **Electronic Operator Interface (EOI)** of the ASD has an easy-to-read LCD screen. There is also a read-only LED screen with enhanced visibility that can be read from a greater distance. The **EOI** provides easy access to the many monitoring and programming features of the ASD.

The motor control software is menu-driven, which allows for easy access to the motor control parameters and quick changes when required.

To maximize the abilities of your new ACE-tronics G9 ASD, a working familiarity with this manual will be required. This manual has been prepared for the ASD installer, user, and maintenance personnel. This manual may also be used as a reference guide or for training. With this in mind, use this manual to develop a system familiarity before attempting to install or operate the device.

Important Notice

The instructions contained in this manual are not intended to cover all details or variations in equipment types, nor may it provide for every possible contingency concerning the installation, operation, or maintenance of this equipment. Should additional information be required contact your ACE World Companies Customer Support Center.

The contents of this manual shall not become a part of or modify any prior or existing agreement, commitment, or relationship. The sales contract contains the entire obligation of ACE World Companies. The warranty contained in the contract between the parties is the sole warranty of ACE World Companies and any statements contained herein do not create new warranties or modify the existing warranty.

Any electrical or mechanical modifications to this equipment without prior written consent of ACE World Companies may void all warranties and may void the UL/CUL listing or other safety certifications. Unauthorized modifications may also result in a safety hazard or equipment damage.

Misuse of this equipment could result in equipment damage or injury to personnel. In no event will ACE World Companies be responsible or liable for direct, indirect, special, or consequential damage or injury that may result from the misuse of this equipment.

About This Manual

This manual was written by the **ACE World Companies** Technical Publications Group. This group is tasked with providing technical documentation for the **G9 Adjustable Speed Drive**. Every effort has been made to provide accurate and concise information to you, our customer.

At **ACE World Companies** we're continuously searching for better ways to meet the constantly changing needs of our customers. E-mail your comments, questions, or concerns about this publication.

Manual's Purpose and Scope

This manual provides information on how to safely install, operate, maintain, and dispose of your **G9 Adjustable Speed Drive**. The information provided in this manual is applicable to the **G9 Adjustable Speed Drive** only.

This manual provides information on the various features and functions of this powerful cost-saving device, including

- Installation,
- System operation,
- Configuration and menu options, and
- Mechanical and electrical specifications.

Included is a section on general safety instructions that describe the warning labels and symbols that are used throughout the manual. Read the manual completely before installing, operating, performing maintenance, or disposing of this equipment.

This manual and the accompanying drawings should be considered a permanent part of the equipment and should be readily available for reference and review. Dimensions shown in the manual are in metric and/or the English equivalent.

Because of our commitment to continuous improvement, **ACE World Companies** reserves the right, without prior notice, to update information, make product changes, or to discontinue any product or service identified in this publication.

ACE World Companies shall not be liable for direct, indirect, special, or consequential damages resulting from the use of the information contained within this manual.

This manual is copyrighted. No part of this manual may be photocopied or reproduced in any form without the prior written consent of **ACE World Companies**.

© Copyright 2009 **ACE World Companies**.

ACE World Companies[®] is a registered trademark of **ACE World Companies**.

ACE-tronics[®] is a registered trademark of **ACE World Companies**. All other product or trade references appearing in this manual are registered trademarks of their respective owners.

TOSHIBA Leading Innovation[®] is a registered trademark of Toshiba International Corporation.

TOSHIBA[®] is a registered trademark of Toshiba Corporation.

All rights reserved.

Printed in the U.S.A.

Contacting ACE World Companies Customer Support Center

ACE World Companies Customer Support Center can be contacted to obtain help in resolving any **Adjustable Speed Drive** system problem that you may experience or to provide setup information.

The center is open from 8 a.m. to 5 p.m. (CST), Monday through Friday. The Support Center's toll free number is (800) 431-4223 / Local (817) 237-7700 / Fax (817) 237-2777.

You may also contact **ACE World Companies** by writing to:

ACE World Companies

10200 Jacksboro Highway

Fort Worth, Texas 76135

Attn: Mike Perkins

Or send an e-mail

For additional information on **ACE World Companies'** products and services, please visit our web site.

ACE World Companies Corporation

ACE-tronics G9 Adjustable Speed Drive

Please complete the Warranty Card supplied with the ACE-tronics G9 ASD and return it to **ACE World Companies** by prepaid mail. This will activate the 12 month warranty from the date of installation; but, shall not exceed 18 months from the shipping date.

Complete the following information and retain for your records.

Model Number: _____

Serial Number: _____

Project Number (if applicable): _____

Date of Installation: _____

Inspected By: _____

Name of Application: _____

Table of Contents

General Safety Information	1
Safety Alert Symbol	1
Signal Words	1
Special Symbols	2
Equipment Warning Labels	2
Qualified Personnel	2
Equipment Inspection	3
Handling and Storage	3
Disposal	3
Installation Precautions	4
Location and Ambient Requirements	4
Mounting Requirements	4
Conductor Routing and Grounding	5
Power Connections	6
Protection	6
System Integration Precautions	7
Personnel Protection	7
System Setup Requirements	8
Operational and Maintenance Precautions	9
Motor Characteristics	10
Motor Autotuning	10
Pulse Width Modulation Operation	10
Low-Speed Operation	10
Overload Protection Adjustment	10
Operation Above 60 Hz	10
Power Factor Correction	11
Light Load Conditions	11
Motor/Load Combinations	11
Load-Produced Negative Torque	12
Motor Braking	12
ASD Characteristics	13
Over-Current Protection	13
ASD Capacity	13
Using Vector Control	13

Installation and Connections	14
Installation Notes	14
Mounting the ASD	15
Connecting the ASD	16
ACE G9-120V-PCB	21
ACE G9-120V-PCB Precautions	21
Terminal Functions	22
Communications	23
Alternate I/O Terminal Board	23
ACE G9-120V-PCB Specifications/Layout	24
Electronic Operator Interface	32
EOI Operation	32
EOI Remote Mounting	32
EOI Features	33
EOI Remote Mounting	37
System Operation	40
Operation (Local)	40
Default Setting Changes	40
Save User Settings	41
Startup Wizard Requirements	42
ASD Control Configuration	45
Autotune Enable	46
Speed Control (F986)	46
Accel/Decel Times	46
Special Functions	46
Command and Frequency Mode Control	47
Command Control (F003)	47
Frequency Control (F004)	48
Override Operation	49
System Configuration and Menu Options	52
Root Menus	52
Direct Access Information	79
Direct Access Parameters/Numbers	79
Alarms, Trips, and Troubleshooting	248
Alarms and Trips	248
Alarms	249
Trips/Faults	254
Enclosure Dimensions and Conduit Plate Information	261
Enclosure Dimensions	262
Current/Voltage Specifications	270

Cable/Terminal/Torque Specifications272
Dynamic Braking Resistor Specifications274
Short Circuit Protection Recommendations276
ACE-tronics G9 ASD Optional Devices277

General Safety Information

DO NOT attempt to install, operate, maintain, or dispose of this equipment until you have read and understood all of the product safety information and directions that are contained in this manual.

Safety Alert Symbol

The **Safety Alert Symbol** is comprised of an equilateral triangle enclosing an exclamation mark. This indicates that a potential personal injury hazard exists.



Signal Words

Listed below are the signal words that are used throughout this manual followed by their descriptions and associated symbols. When the words **DANGER**, **WARNING**, or **CAUTION** are used in this manual they will be followed by important safety information that must be carefully adhered to.

The word **DANGER** preceded by the safety alert symbol indicates that an imminently hazardous situation exists that, if not avoided, will result in serious injury to personnel or loss of life.



DANGER

The word **WARNING** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided, could result in serious injury to personnel or loss of life.



WARNING

The word **CAUTION** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided, may result in minor or moderate injury.



CAUTION

The word **CAUTION** without the safety alert symbol indicates a potentially hazardous situation exists that, if not avoided, may result in equipment and property damage.

CAUTION

Special Symbols

To identify special hazards, other symbols may appear in conjunction with the **DANGER**, **WARNING**, or **CAUTION** signal words. These symbols indicate areas that require special and/or strict adherence to the procedures to prevent serious injury to personnel or loss of life.

Electrical Hazard Symbol

A symbol that is comprised of an equilateral triangle enclosing a lightning bolt that indicates a hazard of injury from electrical shock or burn.



Explosion Hazard Symbol

A symbol that is comprised of an equilateral triangle enclosing an explosion that indicates a hazard of injury from exploding parts.



Equipment Warning Labels

DO NOT attempt to install, operate, perform maintenance, or dispose of this equipment until you have read and understood all of the user directions that are contained in this manual.

Warning labels that are attached to the equipment will include the exclamation mark within a triangle. **DO NOT** remove or cover any of these labels. If the labels are damaged or if additional labels are required, contact your ACE World Companies Customer Support Center.

Labels attached to the equipment are there to provide useful information or to indicate an imminently hazardous situation that may result in property or equipment damage, serious injury, or loss of life if safe procedures or methods are not followed as outlined in this manual.

Qualified Personnel

Installation, operation, and maintenance shall be performed by **Qualified Personnel Only**. A Qualified Person is one that has the skills and knowledge relating to the construction, installation, operation, and maintenance of the electrical equipment and has received safety training on the hazards involved (Refer to the latest edition of NFPA 70E for additional safety requirements).

Qualified Personnel shall:

- Have carefully read the entire operation manual.
- Be familiar with the construction and function of the ACE-tronics G9 ASD, the equipment being driven, and the hazards involved.
- Be able to recognize and properly address hazards associated with the application of motor-driven equipment.
- Be trained and authorized to safely energize, de-energize, ground, lockout/tagout circuits and equipment, and clear faults in accordance with established safety practices.
- Be trained in the proper care and use of protective equipment such as safety shoes, rubber gloves, hard hats, safety glasses, face shields, flash clothing, etc., in accordance with established safety practices.

For additional information on workplace safety visit www.osha.gov.

Equipment Inspection

- Upon receipt of the equipment inspect the packaging and equipment for shipping damage.
- Carefully unpack the equipment and check for damaged parts, missing parts, or concealed damage that may have occurred during shipping. If any discrepancies are discovered, it should be noted with the carrier prior to accepting the shipment, if possible. File a claim with the carrier if necessary and immediately notify your ACE World Companies Customer Support Center.
- Ensure that the rated capacity and the model number specified on the nameplate conform to the order specifications.
- Modification of this equipment is dangerous and are to be performed by factory-trained representatives. When modifications are required contact your ACE World Companies Customer Support Center.
- **DO NOT** install the ASD if it is damaged or if it is missing any component(s).
- Inspections may be required after moving the equipment.
- Contact your ACE World Companies Customer Support Center to report discrepancies or for assistance if required.

Handling and Storage

- Use proper lifting techniques when moving the ACE-tronics G9 ASD; including properly sizing up the load, getting assistance, and using a forklift if required.
- Store in a well-ventilated location and preferably in the original carton if the equipment will not be used upon receipt.
- Store in a cool, clean, and dry location. Avoid storage locations with extreme temperatures, rapid temperature changes, high humidity, moisture, dust, corrosive gases, or metal particles.
- The storage temperature range of the ACE-tronics G9 ASD is -14° to 104° F (-10° to 40° C).
- **DO NOT** store the unit in places that are exposed to outside weather conditions (i.e., wind, rain, snow, etc.).
- Store in an upright position.

Disposal

Never dispose of electrical components via incineration. Contact your state environmental agency for details on disposal of electrical components and packaging in your area.

Installation Precautions

Location and Ambient Requirements

- The ACE-tronics G9 ASD is intended for permanent installations only.
- Installation should conform to the **2008 National Electrical Code — Article 110** (NEC) (*Requirements For Electrical Installations*), all regulations of the **Occupational Safety and Health Administration**, and any other applicable national, regional, or industry codes and standards.
- Select a mounting location that is easily accessible, has adequate personnel working space, and adequate illumination for adjustment, inspection, and maintenance of the equipment (refer to 2008 NEC Article 110-13).
- **DO NOT** mount the ASD in a location that would produce catastrophic results if it were to fall from its mounting location (equipment damage or injury).
- **DO NOT** mount the ASD in a location that would allow it to be exposed to flammable chemicals or gases, water, solvents, or other fluids.
- Avoid installation in areas where vibration, heat, humidity, dust, fibers, metal particles, explosive/corrosive mists or gases, or sources of electrical noise are present.
- The installation location shall not be exposed to direct sunlight.
- Allow proper clearance spaces for installation. Do not obstruct the ventilation openings. Refer to the section titled [Installation and Connections on pg. 14](#) for additional information on ventilation requirements.
- The ambient operating temperature range of the ACE-tronics G9 ASD is 14° to 104° F (-10° to 40° C).

Mounting Requirements

- Only **Qualified Personnel** should install this equipment.
- Install the unit in a secure and upright position in a well-ventilated area.
- As a minimum, the installation of the equipment should conform to the **2008 National Electrical Code — Article 110** (NEC), OSHA, as well as any other applicable national, regional, or industry codes and standards.
- Installation practices shall conform to the latest revision of NFPA 70E Electrical Safety Requirements for Employee Workplaces.
- It is the responsibility of the ASD installer/maintenance personnel to ensure that the unit is installed into an enclosure that will protect personnel against electric shock.

Conductor Routing and Grounding



- Use separate metal conduits for routing the input power, output power, and control circuits.
- A separate ground cable shall be run inside of the conduit with the input power, output power, and control circuits.
- **DO NOT** connect CC to earth ground.
- **ONLY** use the IICC terminal as the return for the V/I input.
- Always ground the unit to prevent electrical shock and to help reduce electrical noise.
- It is the responsibility of the ASD installer/maintenance personnel to provide proper grounding and branch circuit protection in accordance with the **2008 NEC** and any other applicable national, regional, or industry codes and standards.

— The Metal Of Conduit Is Not An Acceptable Ground —

Grounding Capacitor Switch

The ACE-tronics G9 ASD is equipped with noise reduction capacitors which are used to reduce the EMI leakage via the 3-phase power-input circuit and for compliance with the **Electromagnetic Compatibility Directive** (EMC).

The effective value of the capacitor may be increased, reduced, or removed entirely via the **Selector Switch**, **Switching Bar**, or the **Switching Screw** — the type used is typeform-specific.

The **Grounding Capacitor Switch** allows the user to quickly change the value of the leakage-reduction capacitance of the 3-phase input circuit without the use of tools.

See the section titled [System Grounding on pg. 18](#) for more on the [Grounding Capacitor](#).

See figures [4](#), [5](#), [6](#), and [7 on pg. 19](#) for an electrical depiction of the leakage-reduction functionality of the [Grounding Capacitor](#) and the methods used to set the capacitance value.

Power Connections



Contact With Energized Wiring Will Cause Severe Injury Or Loss Of Life.

- Turn off, lockout, and tag out all power sources before proceeding to connect the power wiring to the equipment.
- After ensuring that all power sources are turned off and isolated in accordance with established lockout/tag out procedures, connect the 3-phase power source wiring of the correct voltage to the correct input terminals and connect the output terminals to a motor of the correct voltage and type for the application (refer to NEC Article 300 – Wiring Methods and Article 310 – Conductors For General Wiring). Size the branch circuit conductors in accordance with NEC Table 310.16.
- Ensure that the 3-phase input power is **NOT** connected to the output of the ACE-tronics G9 ASD. This will damage the ASD and may cause injury to personnel.
- **DO NOT** connect resistors across terminals PA – PC or PO – PC. This may cause a fire.
- Ensure the correct phase sequence and the desired direction of motor rotation in the **Bypass** mode (if applicable).
- Turn the power on only after attaching and/or securing the front cover.

Protection

- Ensure that primary protection exists for the input wiring to the equipment. This protection must be able to interrupt the available fault current from the power line. The equipment may or may not be equipped with an input disconnect (option).
- All cable entry openings must be sealed to reduce the risk of entry by vermin and to allow for maximum cooling efficiency.
- External dynamic braking resistors must be thermally protected.
- It is the responsibility of the ASD installer/maintenance personnel to setup the **Emergency Off** braking system of the ASD. The function of the **Emergency Off** braking function is to remove output power from the drive in the event of an emergency. A supplemental braking system should also be engaged in the event of an emergency. For additional information on braking systems see parameters [F250](#) and [F304](#).

Note: *A supplemental emergency stopping system should be used with the ASD. Emergency stopping should not be a task of the ASD alone.*

- Follow all warnings and precautions and do not exceed equipment ratings.

System Integration Precautions

The following precautions are provided as general guidelines for the setup of the ACE-tronics G9 ASD within the system.

- The ACE-tronics G9 ASD is a general-purpose product. It is a system component only and the system design should take this into consideration. Please contact your ACE World Companies Customer Support Center for application-specific information or for training support.
- The ACE-tronics G9 ASD is part of a larger system and the safe operation of the ASD will depend upon observing certain precautions and performing proper system integration.
- Improperly designed or improperly installed system interlocks may render the motor unable to start or stop on command.
- The failure of external or ancillary components may cause intermittent system operation (i.e., the system may start the motor without warning).
- A detailed system analysis and job safety analysis should be performed by the systems designer and/or systems integrator before the installation of the ASD component. Contact your ACE World Companies Customer Support Center for options availability and for application-specific system integration information if required.

Personnel Protection

- Installation, operation, and maintenance shall be performed by **Qualified Personnel Only**.
- A thorough understanding of the ACE-tronics G9 ASD will be required before the installation, operation, or maintenance of the ASD.



- Rotating machinery and live conductors can be hazardous and shall not come into contact with personnel. Personnel should be protected from all rotating machinery and electrical hazards at all times.
- Insulators, machine guards, and electrical safeguards may fail or be defeated by the purposeful or inadvertent actions of workers. Insulators, machine guards, and electrical safeguards are to be inspected (and tested where possible) at installation and periodically after installation for potential hazardous conditions.
- **DO NOT** allow personnel near rotating machinery. Warning signs to this effect shall be posted at or near the machinery.
- **DO NOT** allow personnel near electrical conductors. Contact with electrical conductors can be fatal. Warning signs to this effect shall be posted at or near the hazard.
- Personal protection equipment shall be provided and used to protect employees from any hazards inherent to system operation.

System Setup Requirements

- When using the ACE-tronics G9 ASD as an integral part of a larger system, it is the responsibility of the ASD installer/maintenance personnel to ensure that there is a fail-safe in place (i.e., an arrangement designed to switch the system to a safe condition if there is a fault or failure).
- System safety features should be employed and designed into the integrated system in a manner such that system operation, even in the event of system failure, will not cause harm or result in system damage or injury to personnel (i.e., E-Off, Auto-Restart settings, System Interlocks, etc.).
- The programming setup and system configuration of the ASD may allow it to start the motor unexpectedly. A familiarity with the Auto-Restart settings are a requirement to use this product.
- Power factor improvement/correction capacitors or surge absorbers **MUST NOT** be installed on the output of the ACE-tronics G9 ASD.
- Use of the built-in system protective features is highly recommended (i.e., E-Off, Overload Protection, etc.).
- The operating controls and system status indicators should be clearly readable and positioned where the operator can see them without obstruction.
- Additional warnings and notifications shall be posted at the equipment installation location as deemed required by **Qualified Personnel**.



CAUTION

- There may be thermal or physical properties, or ancillary devices integrated into the overall system that may allow for the ACE-tronics G9 ASD to start the motor without warning. Signs to this effect must be posted at the equipment installation location.
- If a secondary magnetic contactor (MC) or an ASD output disconnect is used between the ASD and the load, it should be interlocked to halt the ASD before the secondary contact opens. If the output contactor is used for bypass operation, it must be interlocked such that commercial power is never applied to the ASD output terminals (U, V, W).
- When using an ASD output disconnect, the ASD and the motor must be stopped before the disconnect is either opened or closed. Closing the output disconnect while the 3-phase output of the ASD is active may result in equipment damage or injury to personnel.

Operational and Maintenance Precautions



WARNING



- Turn off, lockout, and tag out the main power, the control power, and instrumentation connections before proceeding to connect/disconnect the power wiring, inspecting or servicing the drive, or opening the door of the enclosure.
- The capacitors of the ACE-tronics G9 ASD maintain a residual charge for a period of time after turning off the ASD. The required time for each ASD typeform is indicated with a cabinet label and a **Charge LED** (shown for smaller ASDs in [Figure 2 on pg. 16](#); LED is located on the front panel of larger ASDs). Wait at least the minimum time indicated on the enclosure-mounted label and ensure that the **Charge LED** has gone out before opening the door of the ASD once the ASD power has been turned off.
- Turn the power on only after attaching (or closing) the front cover and **DO NOT** remove or open the front cover of the ACE-tronics G9 ASD when the power is on.
- **DO NOT** attempt to disassemble, modify, or repair the ACE-tronics G9 ASD. Contact your ACE World Companies Customer Support Center for repair information.
- **DO NOT** place any objects inside of the ACE-tronics G9 ASD.
- If the ASD should emit smoke, or an unusual odor or sound, turn the power off immediately.
- The heat sink and other components may become extremely hot to the touch. Allow the unit to cool before coming in contact with these items.
- Remove power from the ASD during extended periods of non-use.
- The system should be inspected periodically for damaged or improperly functioning parts, cleanliness, and to ensure that the connectors are tightened securely.

Motor Characteristics

Listed below are some variable speed AC motor control concepts with which the user of the **G9 Adjustable Speed Drive** should become familiar.

Motor Autotuning

Motor production methods may cause minor differences in motor operation. The negative effects of these differences may be minimized by using the **Autotune** feature of the ACE-tronics G9 ASD. **Autotuning** is a function of the ASD that measures several parameters of the connected motor and places these readings in a stored table. The software uses the information in the table to help optimize the response of the ASD to application-specific load and operational requirements. The **Autotuning** function may be enabled for automatic tuning, configured manually at **F400**, or disabled.

The measured parameters include the rotor resistance, the stator resistance, the required excitation inductance, rotational inertia values, and leakage inductance values.

Pulse Width Modulation Operation

The ACE-tronics G9 ASD uses sinusoidal **Pulse Width Modulation** (PWM) control. The output current waveform generated by the ASD approaches that of a perfect sine wave; however, the output waveform is slightly distorted. For this reason, the motor may produce more heat, noise, and vibration when operated by an ASD, rather than directly from commercial power.

Low-Speed Operation

Operating a general-purpose motor at lower speeds may cause a decrease in the cooling ability of the motor. Reducing the torque requirement of the motor at lower speeds will decrease the generated heat at lower speeds.

When the motor is to be operated at low speed (less than 50% of full speed) and at the rated torque continuously, a Toshiba VF motor (designed for use in conjunction with an ASD) is recommended.

Overload Protection Adjustment

The ACE-tronics G9 ASD software monitors the output current of the system and determines when an overload condition occurs. The overload current level is a percentage of the rating of the motor. This function protects the motor from overload.

The default setting for the overload detection circuit is set to the maximum rated current of the ASD at the factory. This setting will have to be adjusted to match the rating of the motor with which the ASD is to be used. To change the overload reference level, see [Motor Overload Protection Level 1 on pg. 175](#).

Operation Above 60 Hz

A motor produces more noise and vibration when it is operated at frequencies above 60 Hz. Also, when operating a motor above 60 Hz, the rated limit of the motor or its bearings may be exceeded; this may void the motor warranty.

Contact the motor manufacturer for additional information before operating the motor above 60 Hz.

Power Factor Correction

DO NOT connect a power factor correction capacitor or surge absorber to the output of the ACE-tronics G9 ASD.

If the ASD is used with a motor that is equipped with a capacitor for power factor correction, remove the capacitor from the motor.

Connecting either of these devices to the output of the ASD may cause the ASD to malfunction and trip, or the output device may cause an over-current condition resulting in damage to the device or the ASD.

Light Load Conditions

When a motor is operated under a continuous light load (i.e., at a load of less than 50% of its rated capacity) or it drives a load which produces a very small amount of inertia, it may become unstable and produce abnormal vibration or trips because of an over-current condition. In such a case, the carrier frequency may be lowered to compensate for this undesirable condition (see Program ⇒ Special ⇒ Carrier Frequency ⇒ [PWM Carrier Frequency](#)).

Note: When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.

Motor/Load Combinations

When the ACE-tronics G9 ASD is used in combination with one of the following motors or loads, it may result in unstable operation.

- A motor with a rated capacity that exceeds the motor capacity recommended for the ASD.
- An explosion-proof motor.

When using the ASD with an explosion-proof motor or other special motor types, lower the carrier frequency to stabilize the operation. **DO NOT** set the carrier frequency below 2.2 kHz if operating the system in the vector control mode.

Note: When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.

If the motor that is coupled to a load that has a large backlash or a reciprocating load, use one of the following procedures to stabilize its operation.

- Adjust the **S-Pattern** acceleration/deceleration setting,
- If operating in the **Vector** control mode, adjust the response time, or
- Switch to the **Constant Torque** control mode.

Load-Produced Negative Torque

When the ACE-tronics G9 ASD is used with a load that produces negative torque (an overhauling load), the over-voltage or over-current protective functions of the ASD may cause nuisance tripping.

To minimize the undesirable effects of negative torque the dynamic braking system may be used. The dynamic braking system converts the regenerated energy into heat that is dissipated using a braking resistor. The braking resistor must be suitably matched to the load. Dynamic braking is also effective in reducing the DC bus voltage during a momentary over-voltage condition.



CAUTION

If under extreme conditions the dynamic braking system or a component of this system were to fail, the dynamic braking resistor may experience an extended over-current condition. The DBR circuit was designed to dissipate excessive amounts of heat and if the extended over-current condition were allowed to exceed the circuit parameters, this condition could result in a fire hazard.

To combat this condition, the 3-phase input may be connected using contactors that are configured to open in the event of an extended DBR over-current condition or an internal circuit failure. Using a thermal sensor and/or overload protection as the 3-phase input contactor drive signal, the contactors will open and remove the 3-phase input power in the event of an extended DBR over-current or system over-voltage condition. See [Dynamic Braking Enable on pg. 140](#) for more information using Dynamic Braking with the ASD.

Motor Braking

The motor may continue to rotate and coast to a stop after being shut off due to the inertia of the load. If an immediate stop is required, a braking system should be used. The two most common types of motor braking systems used with the ACE-tronics G9 ASD are **DC Injection Braking** and **Dynamic Braking**.

For additional information on braking systems, see [DC Injection Braking on pg. 127](#) and [Dynamic Braking Enable on pg. 140](#).

ASD Characteristics

Over-Current Protection

Each ACE-tronics G9 ASD is designed for a specified operating power range. The ASD will incur a trip if the design specifications are exceeded.

However, the ASD may be operated at 115% of the specified output-current range continuously (or 110% continuously if ≥ 60 HP for the 230-volt system or if ≥ 125 HP for the 460-volt system) or at 150% for a limited amount of time as indicated in the section titled [Current/Voltage Specifications on pg. 270](#). Also, the [Stall Prevention Level](#) may be adjusted to help with nuisance over-current trips (see [F601](#)).

When using the ASD for an application to control a motor that is rated significantly less than the maximum current rating of the ASD, the over-current limit (Thermal Overload Protection) setting will have to be changed to match the FLA of the motor. For additional information on this parameter, see [Motor Overload Protection Level 1 on pg. 175](#).

ASD Capacity

The ACE-tronics G9 ASD must not be used with a motor that has a larger capacity than the ASD, even if the motor is operated under a small load. An ASD being used in this way will be susceptible to a high-output peak current which may result in nuisance tripping.

Do not apply a level of input voltage to an ASD that is beyond that which the ASD is rated. The input voltage may be stepped down when required with the use of a step-down transformer or some other type of voltage-reduction system.

Using Vector Control

Using **Vector Control** enables the system to produce very high torque over the entire operating range even at extremely low speeds. **Vector Control** may be used with or without feedback. However, using feedback increases the speed accuracy for applications requiring precise speed control.

See [F015 on pg. 85](#) for additional information on using **Vector Control**.

Installation and Connections

The ACE-tronics G9 ASD may be set up initially by performing a few simple configuration settings. To operate properly, the ASD must be securely mounted and connected to a power source (3-phase AC input at the R/L1, S/L2, and T/L3 terminals). The control terminals of the ASD may be used by connecting the terminals of the **ACE G9-120V-PCB** to the proper sensors or signal input sources (see the section titled **ACE G9-120V-PCB** on pg. 21 and **Figure 8** on pg. 24).

System performance may be further enhanced by assigning a function to the output terminals of the **ACE G9-120V-PCB** and connecting the terminals to the proper indicators or actuators (LEDs, relays, contactors, etc.).

Note: *The optional ACE-tronics G9 ASD interface boards may be used to expand the I/O functionality of the ASD.*

Installation Notes



When a brake-equipped motor is connected to the ASD, it is possible that the brake may not release at startup because of insufficient voltage. To avoid this, **DO NOT** connect the brake or the brake contactor to the output of the ASD.

If an output contactor is used for bypass operation, it must be interlocked such that commercial power is never applied to the output terminals of the ASD (U/T1, V/T2, and W/T3).

DO NOT apply commercial power to the ASD output terminals **U/T1**, **V/T2**, and **W/T3**.

Though the default settings of the ASD do not include the use of a physical discrete input terminal being programmed to the **ST** function, the system may be configured to use a physical discrete input terminal set to **ST**. When configured properly, the externally-activated **ST** terminal acts as a permissive in allowing for normal system operation. See parameter **F110** for more information on the use of the **ST** terminal.

If a secondary magnetic contactor (MC) is used between the output of the ASD and the motor, it should be interlocked such that the **ST** terminal activation is deactivated before the output contactor is opened.

DO NOT open and then close a secondary magnetic contactor between the ASD and the motor unless the ASD is off and the motor is not rotating.

Note: *Re-application of power via a secondary contact while the ASD is on or while the motor is still turning may cause ASD damage.*

The ASD input voltage should remain within 10% of the specified input voltage range. Input voltages approaching the upper or lower limit settings may require that the over-voltage and under-voltage stall protection level parameters be adjusted. Voltages outside of the permissible tolerance should be avoided.

The frequency of the input power should be ± 2 Hz of the specified input frequency.

DO NOT use an ASD with a motor that has a power rating higher than the rated output of the ASD.

The ACE-tronics G9 ASD is designed to operate NEMA B motors. Consult with the ACE World Companies Customer Support Center before using the ASD for special applications such as with an explosion-proof motor or applications with a piston load.


Disconnect the ASD from the motor before megging or applying a bypass voltage to the motor.

Interface problems may occur when an ASD is used in conjunction with some types of process controllers. Signal isolation may be required to prevent controller and/or ASD malfunction (contact your ACE World Companies Customer Support Center or the process controller manufacturer for additional information about compatibility and signal isolation).

Use caution when setting the output frequency. Over speeding a motor decreases its ability to deliver torque and may result in damage to the motor and/or the driven equipment.

Not all ACE-tronics G9 ASDs are equipped with internal primary power input fuses (typeform-dependent). When connecting two or more drives that have no internal fuse to the same power line as shown in [Figure 1](#), it will be necessary to select a circuit-breaking configuration that will ensure that if a short circuit occurs in ASD 1, only MCCB2 trips, not MCCB1. If it is not feasible to use this configuration, insert a fuse between MCCB2 and ASD 1.

Figure 1. Circuit Breaker Configuration.



Mounting the ASD

CAUTION

— The following thermal specifications apply to the 230- and the 460-Volt ASDs ONLY —

Install the unit securely in a well ventilated area that is out of direct sunlight.

The process of converting AC to DC, and then back to AC produces heat. During normal ASD operation, up to 5% of the input energy to the ASD may be dissipated as heat. If installing the ASD in a cabinet, ensure that there is adequate ventilation.

DO NOT operate the ASD with the enclosure door open.

The ambient operating temperature rating of the ACE-tronics G9 ASD is 14° to 104° F (-10° to 40° C).

When installing adjacent ASDs horizontally ACE World Companies recommends at least 5 cm of space between adjacent units. However, horizontally mounted ASDs may be installed side-by-side with no space between the adjacent units — side-by-side installations require that the top cover be removed from each ASD.

For 150 HP ASDs and above, a minimum of 50 cm of space is required above and below adjacent units and any obstruction. This space is the recommended minimum space requirement for the ASD and ensures that adequate ventilation is provided for each unit. More space will provide a better environment for cooling (see the section titled [Enclosure Dimensions and Conduit Plate Information on pg. 261](#) for additional information on mounting space requirements).

Note: Ensure that the ventilation openings are not obstructed.

Connecting the ASD



Refer to the section titled [Installation Precautions](#) on pg. 4 and the section titled [Lead Length Specifications](#) on pg. 20 before attempting to connect the ASD and the motor to electrical power.

Power Connections



Contact With Energized Wiring Will Cause Severe Injury Or Loss Of Life.

See [Figure 20](#) on pg. 30 for a system I/O connectivity schematic.

An inductor (DCL) may be connected across the **PO** and **PA/+** terminals to provide additional filtering. When not used, a jumper must be connected across these terminals.

PA/+ and **PB** are used for the DBR connection if using a braking resistor.


PC/- is the negative terminal of the DC bus.

R/L1, **S/L2**, and **T/L3** are the 3-phase input supply terminals for the ASD.

U/T1, **V/T2**, and **W/T3** are the output terminals of the ASD that connect to the motor.

The location of the **Charge LED** for the smaller typeform ASD is provided in [Figure 2](#). The **Charge LED** is located on the front door of the enclosure of the larger ASDs.

Figure 2. Typical ASD Input/Output Terminals and the [Grounding Capacitor Switch](#).



Grounding Capacitor Switch — Pull for **Small** capacitance/push for **Large** capacitance.

Power Connection Requirements

Connect the 3-phase input power to the input terminals of the ASD at **R/L1**, **S/L2**, and **T/L3** (see [Figure 3](#) for the typical electrical connection scheme). Connect the output of the ASD to the motor from the ASD terminals **U/T1**, **V/T2**, and **W/T3**. The input and output conductors and terminal lugs used shall be in accordance with the requirements listed in the section titled [Current/Voltage Specifications](#) on [pg. 270](#).

If multiple conductors are used in parallel for the input or output power and it is necessary to use separate conduits, each parallel set shall have its own conduit and not share its conduit with other parallel sets (i.e., place U1, V1, W1, and a ground wire in one conduit and U2, V2, and W2, and a ground wire in another; refer to NEC Article 300.20 and Article 310.4). National, regional, and industry electrical codes should be referenced if three or more power conductors are run in the same conduit (refer to 2008 NEC Article 310 adjustment factors).

Note: *Local and national codes should be referenced when running more than three conductors in the same conduit.*


Install a molded case circuit breaker (MCCB) or fuse between the 3-phase power source and the ASD in accordance with the fault current setting of the ASD and **2008 NEC Article 430**.

The ACE-tronics G9 ASD is designed and tested to comply with UL Standard 508C. Modifications to the ASD system or failure to comply with the short circuit protection requirements outlined in this manual may disqualify the UL rating. See [Table 23](#) on [pg. 276](#) for typeform-specific short circuit protection recommendations.

As a minimum, the installation of the ASD shall conform to **2008 NEC Article 110**, the **Occupational Safety and Health Administration** requirements, and to any other local and regional industry codes and standards.

Note: *In the event that the motor rotates in the wrong direction when powered up, reverse any two of the three ASD output power leads (U, V, or W) connected to the motor.*

Figure 3. G9 ASD/Motor Typical Connection Diagram.



System Grounding

Proper grounding helps to prevent electrical shock and to reduce electrical noise. The ACE-tronics G9 ASD is designed to be grounded in accordance with **Article 250** of the **2008 NEC** or **Section 10/Part One** of the **Canadian Electrical Code (CEC)**.

The grounding conductor shall be sized in accordance with **Article 250-122** of the **NEC** or **Part One-Table 6** of the **CEC**.

— The Metal Of Conduit Is Not An Acceptable Ground —

The input, output, and control lines of the system shall be run in separate metal conduits and each shall have its own ground conductor.

ASDs produce high-frequency noise — steps must be taken during installation to avoid the negative effects of noise. Listed below are some examples of measures that will help to combat noise problems.

- **DO NOT** install the input power wires and output power wires in the same duct or in parallel with each other, and do not bind them together.
- **DO NOT** install the input power wires, output power wires, and the wires of the control circuit in the same duct or in parallel with each other, and do not bind them together.
- Use shielded wires or twisted wires for the control circuits.
- Ensure that the grounding terminals (G/E) of the ASD are securely connected to ground.
- Connect a surge suppressor to every electromagnetic contactor and every relay installed near the ASD.
- Install noise filters as required.

Grounding Capacitor

The **Grounding Capacitor** plays a role in minimizing the effects of leakage current through the ASD system and through ground paths to other systems. Leakage current may cause the improper operation of earth-leakage current breakers, leakage-current relays, ground relays, fire alarms, and other sensors — and it may cause superimposed noise on CRT screens.

The **Grounding Capacitor Switch** allows the user to quickly change the value of the leakage-reduction capacitance of the 3-phase input circuit. See figures 4, 5, 6, and 7 on pg. 19 for an electrical depiction of the leakage-reduction functionality and the methods used to change the capacitance value. The method used is typeform-specific.

If using a 460-Volt 5 HP ASD or a 460-Volt ASD that is in the range of 7.5 HP to 25 HP, and the **U/T1**, **V/T2**, and **W/T3** connections to the motor are 100 meters or more in length, the ASD **Carrier Frequency** must be set to 4 kHz or less when activating or deactivating the **Grounding Capacitor Switch**. ASD overheating may occur if the **Carrier Frequency** is set above 4 kHz when activating or deactivating the **Grounding Capacitor Switch**.

See pg. 5 for more information on the **Grounding Capacitor Switch** and pg. 16 for the location of the switch.

Figure 4. The **Grounding Capacitor**

Switch is used on typeforms **230-volt** 0.5 HP to 10 HP and the 25 and 30 HP/**460-Volt** 1.0 HP to 250 HP.

The value may be set to **Maximum** (default setting) or to **Zero** by pushing or pulling the switch actuator, respectively.




Figure 5. The **Grounding Capacitor**

Switch is used on typeforms **230-volt** 15 HP to 20 HP and the 40 HP to 60 HP/**460-Volt** 30 HP to 100 HP.

The value may be set to **Large** (default setting) or **Small** by pushing or pulling the switch actuator, respectively.




Figure 6. The **Grounding Capacitor Bar** is used on typeforms **230-volt** 75 HP and the 100 HP/**460-Volt** 125 HP and the 150 HP.

The value may be set to **Small** (default setting) or **Large** by connecting or disconnecting the switching bar, respectively.





Figure 7. The **Grounding Capacitor Screw** is used on typeforms **460-volt** 175 HP and above.

The value may be set to **Small** (default setting) or **Large** by placing the screw in the **A** position or by placing the screw in the **B** position, respectively.



Lead Length Specifications

Adhere to the NEC and any local codes during the installation of ASD/motor systems. Excessive lead lengths may adversely effect the performance of the motor. Special cables are not required. Lead lengths from the ASD to the motor in excess of those listed in [Table 1](#) may require filters to be added to the output of the ASD. [Table 1](#) lists the suggested maximum lead lengths for the listed motor voltages.

All Toshiba **CT** motors incorporate an insulation system that is in compliance with **NEMA MG1 Part 30**.

All Toshiba **XT** motors incorporate an insulation system that is in compliance with **NEMA MG1 Part 31**.

Table 1. Lead Length Recommendations.

Model	PWM Carrier Frequency	NEMA MG-1 Part 30 Compliant Motors	NEMA MG-1 Part 31 Compliant Motors
230-Volt	All	450 feet	1000 feet
460-Volt	< 5 kHz	200 feet	600 feet
	≥ 5 kHz	100 feet	300 feet
575-Volt	< 5 kHz	75 feet	200 feet
	≥ 5 kHz	50 feet	100 feet

Note: *Contact the **ACE World Companies** Customer Support Center for application assistance when using lead lengths in excess of those listed.*

Exceeding the peak voltage rating or the allowable thermal rise time of the motor insulation will reduce the life expectancy of the motor.

*When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.*

ACE G9-120V-PCB

The ACE-tronics G9 ASD can be controlled by several input types and combinations thereof, as well as operate within a wide range of output frequency and voltage levels. This is accomplished with the use of the **ACE G9-120V-PCB** (shown in [Figure 8 on pg. 24](#)).

The **ACE G9-120V-PCB** is designed to allow for a discrete or analog signal to control the speed and/or torque of the motor.

A 120 VAC On/Off input signal may be used to activate and deactivate the discrete input terminals (i.e., F, R, Jog, etc.), or an analog voltage or current may be used to vary the speed or torque of the motor. The gain and bias of the analog control signal may be adjusted for application-specific suitability by the user.

The analog and discrete outputs of the **ACE G9-120V-PCB** may be used to annunciate an active condition or to activate an ancillary device (e.g., brake, LED, etc.).

No special programming or program changes are required to use the **ACE G9-120V-PCB**. However, application-specific setup programming may be required.

[Table 4 on pg. 25](#) lists the names, descriptions, and the default settings (of programmable terminals) of the input and output terminals of the **ACE G9-120V-PCB**.

Note: To use the input lines of the **ACE G9-120V-PCB** to provide **Run** commands the **Command Mode** setting must be set to **Terminal Board**.

[Figure 20 on pg. 30](#) shows a typical connection diagram for the ASD system.

ACE G9-120V-PCB Precautions



- The ASD contains high voltage parts. Contact with live circuits will result in electric shock.
- Ensure that the ASD system is tagged out before attempting to perform maintenance or when making adjustments to the ASD system.
- Ensure that all system/ASD power is off and that the **Charge** LED of the ASD is off.
- **DO NOT** open the door of the ASD when the ASD power is on. **DO NOT** attempt to operate the ASD with the door open. Failure to do so can lead to electric shock and may result in serious injury or loss of life.
- The **ACE G9-120V-PCB** uses 120 VAC and may cause serious injury if it is used improperly or if it comes into contact with personnel.
- PCB-mounted LEDs are active-signal indicators and are not to be used for system troubleshooting.
- **ONLY** use the **X2** terminal(s) of the **CN2** connector as the return for the discrete 120 VAC inputs.
- **DO NOT** use the **CC** terminals of the **ACE G9-120V-PCB** as a return for the 120 VAC signal. The **CC** terminals are to be used as the return lines for the DC I/O signals of the **ACE G9-120V-PCB ONLY**.
- When connecting stranded wires to the terminals of the **ACE G9-120V-PCB** ensure that there are no stray or unsecured wire strands at the terminal connection.
- Shielded cables are recommended for control line cabling.
- **DO NOT** run the control cabling within the same conduit as the power cables.

- Electrical connections, wire types, and layouts that are external to the ASD shall adhere to all local and regional codes and standards.
- Ensure that the system is properly grounded and that all grounds are secure.
- This system is to be configured and operated by **Qualified Personnel** only.

Terminal Functions

The input and output terminals of the **ACE G9-120V-PCB** are used to control and monitor the functions of the ASD.

See the [Direct Access Information on pg. 79](#) for an in-depth description of the functionality and application-specific setup requirements of the input and output terminals.

Input Terminals

Analog Inputs

The analog input terminals include the **V/I**, **RX**, and the **RR** terminals.

The **V/I** terminal is an isolated input that accepts a 0–10 VDC input voltage or 0–20 mA input current as determined by the setting of **SW2**. Only **IICC** is to be used as the return for the **V/I** input terminal.

The **RX** terminal accepts a ± 10 VDC input voltage.

The **RR** terminal accepts a 0–10 VDC input voltage.

Either analog input may be used to control the speed or torque of the motor.

Discrete Inputs

The 120 VAC discrete inputs include the **F**, **R**, **I1**, **I2**, **I3**, **I4**, **I5**, and **I6** terminals. The discrete input terminals accept a 120 VAC discrete input signal that is used to activate the terminal and the assigned function.

Discrete terminals that have a function assigned are activated for the duration of the activation. Discrete terminals with no function assigned will not respond to an input signal.

Unused discrete terminals may be assigned any of the functions listed in [Table 7 on pg. 236](#). Duplicate terminal assignments will be OR'd (either will be used to activate the assigned function).

Terminals labeled **X2** of **CN2** are the neutral return connections for the 120 VAC discrete inputs. No other terminals of the **ACE G9-120V-PCB** are to be used for the neutral return of the 120 VAC input.

CAUTION: *DO NOT use the CC terminals of the ACE G9-120V-PCB as a return for the 120 VAC input signals.*

Output Terminals

Analog Outputs

Analog outputs include the **AM**, **FM**, and **FP** output terminals. To use the output terminals a function must be assigned to the terminal.

The **AM** terminal must be further defined by parameter settings [F670](#), [F671](#), [F685](#), and [F686](#).

The **FM** terminal must be further defined by parameter settings [F005](#), [F006](#), [F681](#), [F682](#), and [F683](#).

The **FP** terminal must be further defined by parameter settings [F676](#) and [F677](#).

Discrete Outputs

The form-A output contacts of **OUT1** (A and C), **OUT2** (A and C), and the form-C output contacts **BRAKE** (A, B, and C) comprise the list of discrete output terminals. The output terminals are rated for 1 A/125 VAC.

All discrete output terminals are programmable and may be set to change state upon the occurrence of a user-selected event.

10 VDC

PP is a 10 VDC/10 mA max. output for customer use.

24 VDC

P24 is a 24 VDC/200 mA max. output for customer use.

Communications

CN4 is the 2-Wire or 4-Wire serial communications port as selected by the setting of **SW1**.

See Program ⇒ **Communications** for more information on the requirements for setting up the ASD for ASD-to-ASD communications and for ASD-to-host (i.e., PC, PLC, etc.) communications.

Alternate I/O Terminal Board

The ACE-tronics G9 ASD may also be controlled using the 24-Volt I/O Terminal Board (optional).

The 24-Volt I/O Terminal Board (P/N 3D658344_G901) control functions operate the same as the 120-Volt I/O Terminal Board with the exception that the discrete terminal activation is carried out using a **Sink** or **Source** method of terminal activation.

In the **Sink** operating mode the **CC** terminal is connected to a discrete input terminal to activate the assigned function — in the **Source** mode a 24 VDC signal is input to a discrete input terminal to activate the assigned function.

There are no software changes required to use the 24-Volt I/O Terminal Board.

ACE G9-120V-PCB Specifications/Layout

Table 2. Ratings Information.

Parameter	Rating
Isolation Voltage	850 V _{rms}
Input Voltage	0 – 120 VAC +10% — Hysteresis 60/90 ±10 VAC
Input Current (Terminal)	4.8 mA ±2.5 mA
Operating Temperature	14° to 104° F (-10° to 40° C)
Input Impedance	36 kΩ

Table 3. Connector Pin Assignments.

Connector	Pin Assignments									
	1	2	3	4	5	6	7	8	9	10
CN2	X2	F	R	I1	I2	I3	I4	I5	I6	X2
CN3	AM	FM	CC	V/I	IICC	FP				
CN5	BRAKE-A	BRAKE-B	BRAKE-C	OUT1-A	OUT1-C	OUT2-A	OUT2-C			
CN6	PP	CC	RR	RX	P24					

Figure 8. ACE G9-120V-PCB Layout.




Table 4. ACE G9-120V-PCB Default Assignment Terminal Names and Functions.

Terminal Name	Input/Output	Default Function (Also See Terminal Descriptions on pg. 26)	Circuit Config.
F	Discrete Input Apply 120 VAC to activate.	Forward Run Command — Multifunctional programmable discrete input.	Figure 10 on pg. 29.
R		Reverse Run Command — Multifunctional programmable discrete input.	
I1		Input 1 — Multifunctional programmable discrete input.	
I2		Input 2 — Multifunctional programmable discrete input.	
I3		Input 3 — Multifunctional programmable discrete input.	
I4		Input 4 — Multifunctional programmable discrete input.	
I5		Stop Limit-Switch Forward — Multifunctional programmable discrete input.	
I6		Stop Limit-Switch Reverse — Multifunctional programmable discrete input.	
OUT1	Switched Output	Brake Failure — Multifunctional programmable discrete output.	Figure 16 on pg. 29.
OUT2		Brake Release — Multifunctional programmable discrete output.	
BRAKE-A		BRAKE relay (N.O.).	Figure 19 on pg. 29.
BRAKE-B		BRAKE relay (N.C.).	
BRAKE-C		BRAKE relay (Common).	
RR	Analog Input	Multifunctional programmable analog input. (0.0 to 10 VDC input).	Figure 11 on pg. 29.
RX		Multifunctional programmable analog input (±10 VDC input).	Figure 12 on pg. 29.
V/I (Select V or I via SW2)		V — Multifunctional programmable isolated analog voltage input (0 to 10 VDC input).	Figure 13 on pg. 29.
		Frequency Mode 2 (Default Setting) — I — Multifunctional programmable isolated analog current input (4 [0] to 20 mADC input — 0 Hz to Maximum Frequency).	
AM	Analog Output	Output Current — <u>Voltage</u> output that is proportional to the output current of the ASD or to the magnitude of the function assigned to this terminal (see Table 8 on pg. 240 for assignment listing).	Figure 18 on pg. 29
FM		Output Frequency — <u>Current</u> or <u>Voltage</u> output that is proportional to the output frequency of the ASD or to the magnitude of the function assigned to this terminal (see Table 8 on pg. 240). Select Current or Voltage at F681.	
P24	DC Output	24 VDC output (200 mA max.).	Figure 14 on pg. 29.
PP		10.0 VDC/10 mA voltage source for the external use (e.g., potentiometer).	Figure 15 on pg. 29.
FP	Pulsed Output	Frequency Pulse — Multifunctional programmable output pulse train of a frequency based on the output frequency of the ASD (see Table 8 on pg. 240).	Figure 17 on pg. 29.
IICC	—	Return for the isolated V/I input terminal.	Do Not connect to Earth Gnd or to each other.
CC	—	Return for the AM , FM , RR , RX , P24 , and the PP analog terminals.	

Terminal Descriptions

The programmable terminal assignments may be accessed and changed from their default settings as mapped on [pg. 57](#) or via the **Direct Access** method: Program ⇒ Direct Access ⇒ **Applicable Parameter Number**. See the section titled [Program Mode Menu Navigation on pg. 57](#) for the applicable **Direct Access** parameter numbers.

For additional information on terminal assignments and default setting changes, see the sections titled [Default Setting Changes on pg. 40](#) and [Terminal on pg. 60](#).

See the section titled [Cable/Terminal/Torque Specifications on pg. 272](#) for information on the proper cable/terminal sizes and torque specifications when making **ACE G9-120V-PCB** connections.

F — The default setting for this terminal is **Forward** run command. The **F** input terminal is activated by applying 120 VAC to this terminal. This terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F111](#)).

R — The default setting for this terminal is **Reverse** run command. The **R** input terminal is activated by applying 120 VAC to this terminal. This terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F112](#)).

I1 — The default setting for this terminal is **Preset Speed 1** (see [Preset Speed 1 on pg. 87](#)). The **I1** input terminal is activated by applying 120 VAC to this terminal. This terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F115](#)).

I2 — This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F112](#)).

I3 — This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F115](#)).

I4 — This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F116](#)).

I5 — The default function assigned to this input terminal is **Stop Limit-Switch Forward**. Activating this terminal applies the **Stop** command and may be used to indicate the end-of-travel on any axis via a limit switch. The **Stop** command stopping method is selected at the [Limit-Switch Stopping Method](#) parameter. This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F117](#)).

I6 — The default function assigned to this input terminal is **Stop Limit-Switch Reverse**. Activating this terminal applies the **Stop** command and may be used to indicate the end-of-travel on any axis via a limit switch. The **Stop** command stopping method is selected at the [Limit-Switch Stopping Method](#) parameter. This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F118](#)).

RR — The default function to which this analog input terminal is assigned is **Frequency Mode 1** setting. The **RR** terminal accepts a 0 – 10 VDC input signal that is used to control the function to which this terminal is assigned. This input terminal may be programmed to control the speed or torque of the motor via an amplitude setting or regulate by setting a limit. The gain and bias of this terminal may be adjusted for application-specific suitability (see [F210 – F215](#)).

RX — The default function to which this analog input terminal is assigned is **Torque Command** setting. The **RX** terminal accepts a ±10 VDC input signal that is used to control the function to which this terminal is assigned. This input terminal may be programmed to raise or lower the speed or torque of the motor via an amplitude setting. This terminal may also be used to regulate the speed or torque of

a motor by setting a limit. The gain and bias of this terminal may be adjusted for application-specific suitability (see F216 – F221). See Figure 20 on pg. 30 for an electrical depiction of the **RX** terminal.

V/I — The **V/I** terminal has the dual function of being able to receive an input voltage or current. The function as a voltage input is to receive a 0 – 10 VDC input signal. The function as a current input is to receive a 0 – 20 mA input signal. Using either input type, the function is to control the 0.0 – Maximum Frequency output or the 0.0 to 250% torque output of the ASD. This is an isolated input terminal. This terminal may be programmed to control the speed or torque of the motor and cannot process both input types simultaneously. **SW2** must be set to **V** or **I** to receive a voltage or current, respectively (see Figure 8 on pg. 24). Terminal scaling is accomplished via F201 – F206. The gain and bias of this terminal may be adjusted for application-specific suitability (see F470 and F471).

P24 — +24 VDC at 200 mA power supply for customer use.

PP — The function of output **PP** is to provide a 10 VDC/10 mADC max. output that may be divided using a potentiometer or other transducer. The tapped voltage is applied to the **RR** input to provide manual control of the **RR** programmed function.

OUT1 — The default function assigned to this terminal is **Output Low Speed**. This output may be programmed to provide an indication (open or closed) that any one of the functions listed in Table 10 on pg. 242 has occurred or is active. This function may be used to signal external equipment or to activate the brake (see F130). The **OUT1** terminal is rated at 2 A/120 VAC and 2 A/30 VDC.

OUT2 — The default function assigned to this terminal is **ACC/DEC Complete**. This output may be programmed to provide an indication (open or closed) that any one of the functions listed in Table 10 on pg. 242 has occurred or is active. This function may be used to signal external equipment or to activate the brake (see F131). The **OUT2** terminal is rated at 2 A/120 VAC and 2 A/30 VDC.

FP — The default function of this output terminal is to output a series of pulses at a rate that is a function of the output frequency of the ASD (50 mA max. at 1.0 kHz to 43.3 kHz). As the output frequency of the ASD goes up so does the **FP** output pulse rate. This terminal may be programmed to provide an output pulse rate that is proportional to the magnitude of any of the user-selected items from Table 8 on pg. 240. For additional information on this terminal see F676 on pg. 188.

AM — This output terminal produces an output voltage that is proportional to the output frequency of the ASD or of the magnitude of the function assigned to this terminal. This terminal may be programmed to provide an output voltage that is proportional to the magnitude of any of the user-selected items from Table 8 on pg. 240. For additional information on this terminal see F670 on pg. 186.

FM — This output terminal produces an output current or voltage that is proportional to the output frequency of the ASD or of the magnitude of the function assigned to this terminal. This terminal may be programmed to provide an output current or voltage that is proportional to the magnitude of any of the user-selected items from Table 8 on pg. 240. For additional information on this terminal see F005 on pg. 81. The Voltage/Current output selection is performed at F681.


BRAKE-A — One of two normally open contacts that, under user-defined conditions, connect to **BRAKE-C**.

BRAKE-B — One of two normally closed contacts that, under user-defined conditions, connect to **BRAKE-C**.

BRAKE-C — **BRAKE-C** is the common leg of a single-pole double-throw form-C relay. The **BRAKE** relay is the **Fault Relay** by default, but may be programmed to any of the selections of Table 10 on pg. 242. For additional information on this terminal see F132 and Figure 9 on pg. 28.

Note: The **BRAKE-A**, **BRAKE-B**, and **BRAKE-C** contacts are rated at 2 A/120 VAC and 2 A/30 VDC.

Figure 9. BRAKE Switching Contacts.



I/O Circuit Configurations

Figure 10. Discrete Input.




Figure 11. RR Input.




Figure 12. RX Input.




Figure 13. V/I Isolated Input.




Figure 14. P24 Output.




Figure 15. PP Output.




Figure 16. OUT1/OUT2 Output.




Figure 17. FP Output.




Figure 18. AM/FM Output.






Figure 19. BRAKE Output.



Typical Connection Diagram

Figure 20. The ACE-tronics G9 ASD Typical Connection Diagram.

Note: When connecting multiple wires to any of ASD terminals, do not connect a solid wire and a stranded wire to the same terminal.



Note: The AM, FM, PP, RR, RX, and the P24 analog terminals are referenced to CC. The isolated V/I analog terminal referenced to IICC. F, R, I1, I2, I3, I4, I5, and I6 referenced to X2.

Startup and Test

Before turning on the ASD ensure that:

- **R/L1, S/L2, and T/L3** are connected to the 3-phase input power.
- **U/T1, V/T2, and W/T3** are connected to the motor.
- The 3-phase input voltage is within the specified tolerance.
- There are no shorts and all grounds are secure.
- All personnel are at a safe distance from the motor and the motor-driven equipment.

Electronic Operator Interface

The ACE-tronics G9 ASD **Electronic Operator Interface** (EOI) is comprised of an LED screen, an LCD screen, two LEDs, a rotary encoder, and five keys. These items are shown and described on [pg. 33](#).

EOI Operation

The **EOI** is the primary input/output device for the user. The **EOI** may be used to monitor system functions, input data into the system, perform diagnostics, and view performance data (e.g., motor frequency, bus voltage, torque, etc.).


The software used with the ASD is menu driven; thus, making it a select-and-click environment. The operating parameters of a motor may be selected and viewed or changed using the **EOI** (or via communications).

EOI Remote Mounting

The **EOI** may be mounted remotely using the optional **ASD-MTG-KIT9**. The kit contains all of the hardware required to mount the **EOI** of the 9-Series ASD remotely.

System operation and **EOI** operation while using the remotely-mounted **EOI** are the same as with the ASD-mounted configuration.

Figure 21. The ACE-tronics G9 ASD Electronic Operator Interface Features.



EOI Features

LED Screen — Displays the running frequency, active **Fault**, or active **Alarm** information.

Rotary Encoder — Used to access the ASD menu selections, change the value of a displayed parameter, and performs the **Enter** key function. Turn the **Rotary Encoder** either clockwise or counterclockwise to perform the **Up** or **Down** functions of the displayed menu selection. Press the **Rotary Encoder** to perform the **Enter** (select) function.

LCD Screen — Displays configuration information, performance data (e.g., output frequency, bus voltage, torque, etc.), diagnostic information, and **LED** screen information in expanded text.

Local/Remote Key — Toggles the system to and from the **Local** and **Remote** modes. The **Local/Remote** key is disabled while the **Fault** screen is displayed. The LED is on when the system is in the **Local Command** mode. The **Local** mode allows the **Command** and **Frequency** control functions to be carried out via the **EOI**.

The **Remote** mode enables the **Command** and **Frequency** control functions to be carried out via the **ACE G9-120V-PCB, RS485, Communication Card, Pulse Input**, or the settings of **F003/F004**. The selection may be made via Program ⇒ Fundamental ⇒ Standard Mode Settings ⇒ **Command Mode** or **Frequency Mode 1**, respectively.

The availability of **Local** mode control (Command and Frequency control) may be disabled via Program ⇒ Utilities ⇒ Prohibition ⇒ **Local/Remote Key Command Override** or **Local/Remote Key Frequency Override**. The availability of the **Local** mode of operation may be reinstated by changing this setting or performing a **Reset** (see **F007**).

ESC Key — Returns the system to the previous level of the menu, toggles between the **EOI Command** screen and the **Frequency Command** screen, or cancels changes made to a field if pressed while still in the reverse video mode (dark background/light text). The three functions are menu-specific.

Run Key — Issues the **Run** command while in the **Local** mode. The **Run** key LED illuminates green while stopped or red while running to alert personnel.

Mode Key — Provides a means to access the three root menus. Pressing the **Mode** key repeatedly loops the system through the three root menus (see [Figure 29 on pg. 52](#)). While looping through the root menus, the **Program** menu will display the root menu screen or the **Program** sub-menu item being accessed prior to pressing the **Mode** key.

Stop-Reset Key — This key has three functions.

1. Issues the **Off** command (decelerates to **Stop** at the programmed rate) if pressed once while in the **Local** mode in accordance with the setting of **F721**.
2. Initiates an **Emergency Off Fault** if pressed twice quickly from the **Local** or **Remote** modes. The **Emergency Off** function terminates the ASD output and stops the motor in accordance with the setting of **F603**.
3. Resets active **Faults** if pressed twice quickly. The source of the **Faults** must be determined and corrected before normal ASD operation can resume.

LED/LCD Screen

The LED screen is used to display the output frequency, active alarms and active faults, or Off.

If there are no active alarms or faults, the output frequency is displayed.

During an active alarm, the display toggles to and from the running frequency and the active alarm.

During an active fault, the fault is displayed.

Loss of the **ST** terminal activation (if so configured; see **F110**) flashes **Off**.

LED Character/Font Information

Characters displayed on the LED screen will be of the seven-segment format. Not all alpha-numeric characters are used.

Shown to the right are the seven-segment characters used on the LED screen along with the same characters as they are displayed on the LCD screen.

LCD Character Information

All alpha-numeric characters are used.

LED/LCD Screen Information			
LED	LCD	LED	LCD
A	A	1	1
b	b	2	2
C	C	3	3
d	d	4	4
E	E	5	5
F	F	6	6
G	G	7	7
H	H	8	8
I	I	9	9
J	J	0	0
L	L		
M	M		
n	n		
O	O		
P	P		
q	q		
r	r		
S	S		
t	t		
U	U		
v	v		
y	y		
-	-		

LCD Screen

The **LCD** screen is the primary user input/output information center. Parameter settings may be viewed or changed using the LCD screen module of the **EOI**. To view or change a parameter setting using the LCD screen, press the **Mode** key until the **Program** menu is displayed. Turn the **Rotary Encoder** until the desired **Primary Menu** item (see pg. 57) is within the cursor block. Press the **Rotary Encoder** to select the item from the **Primary Menu** (repeat the press-to-select function for sub-menu items).

See the section titled [Default Setting Changes on pg. 40](#) for more information on changing parameter settings.

Upon reaching the desired parameter selection the current setting may be viewed, or selected and changed by pressing the **Rotary Encoder** — the setting will take on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter setting. Press the **ESC** key while the new parameter setting is in the reverse video mode to exit the selection without saving the change or press the **Rotary Encoder** while the parameter setting is in the reverse video mode to accept the new setting.

Repeated **ESC** key entries at any time takes the menu back one level each time the **ESC** key is pressed until the **Frequency Command** screen is reached. Further **ESC** entries will toggle the system to and from the **Frequency Command** screen and the **EOI Command** menu.

Note: Changes carried out from the **EOI Command** screen will be effective for **EOI**-controlled ASD operation only. See the section titled [EOI Command Mode on pg. 53](#) for additional information on **EOI Command Mode** operations.

Primary Menus of the LCD Screen

The three primary LCD screens are displayed while accessing the associated operating modes: the **Frequency Command**, **Monitor**, and **Program Menu** screens.

Figure 22. **Frequency Command Screen.**




Figure 23. **Monitor Screen** (see pg. 54 for more on the Monitor Screen).





Figure 24. **Program Menu Screen** (see pg. 57 for more on the Program Menu Screen).



LED/LCD Screen Installation Note

When installing the LED/LCD display module of the **EOI** ensure that the left side of the display is inserted first with the top and bottom catches (see Phillips screws at underside of display) securely in place. This ensures the proper alignment and electrical connection of the CNX connector of the **LED/LCD** display module PCB. Gently hold the display in place while securing the Phillips mounting screw.

If improperly seated, the periphery of the **LED/LCD** display module will not be flush with the front panel surface and the unit will not function properly.

EOI Remote Mounting

The ASD may be controlled from a remotely-mounted **EOI**. For safety and application-specific reasons, some ASD installations will warrant that the operator not be in the vicinity during operation or that the **EOI** not be attached to the ASD housing. The **EOI** may be mounted either with or without the optional **Remote Mounting Kit** (P/N ASD-MTG-KIT). The ease of installation is enhanced by the **Remote Mounting Kit** (P/N 58333) which allows for **EOI** placement and easier cable routing.

Remote mounting will also allow for multiple **EOI** mountings at one location if controlling and monitoring several ASDs from a central location is required.

The **EOI** can operate up to nine feet away from the ASD. A **EOI** extender cable is required for remote mounting. The **EOI** extender cable is available in a nine-foot length and may be ordered through the ACE World Companies Customer Support Center.

The optional dust cover (P/N ASD-BPC) may be used to cover the front panel opening of the ASD housing after removing the **EOI**.

Remote EOI Required Hardware

EOI Mounting Hardware

- EOI Remote-Mount Housing — P/N 58333 (included with 230-volt 40-HP and above; and with the 460-volt 75 HP and above)
- 6-32 x 5/16" Pan Head Screw — P/N 50595 (4 ea.)
- #6 Split-Lock Washer — P/N 01884 (4 ea.)
- #6 Flat Washer — P/N 01885 (4 ea.)

Bezel Plate Mounting Hardware

- Bezel Plate — P/N 52291
- 10-32 Hex Nut — P/N 01922 (4 ea.)
- #10 Split-Lock Washer — P/N 01923 (4 ea.)
- #10 Flat Washer — P/N 01924 (4 ea.)
- Dust Cover — P/N ASD-BPC (Optional)

Extender Cable

- ASD-CAB10F: Cable, 9 ft.

EOI Installation Precautions

Install the unit securely in a well ventilated area that is out of direct sunlight using the four mounting holes at the rear of the **EOI**. The ambient temperature rating for the **EOI** is 14° to 104° F (-10° to 40° C).

- Select a mounting location that is easily accessible by the user.
- Avoid installation in areas where vibration, heat, humidity, dust, metal particles, or high levels of electrical noise (EMI) are present.
- Do not install the **EOI** where it may be exposed to flammable chemicals or gases, water, solvents, or other fluids.
- Turn on the power only after securing the front cover of the ASD.


EOI Remote Mounting w/o the ASD-MTG-KIT

Note: See [Figure 25](#) for the dimensions and the item locations referenced in steps 1 through 5.

1. At the **EOI** mounting location, mark the 3.80" by 3.56" hole and the four 7/32" screw holes.
2. Cut the 3.80" by 3.56" rectangular hole.
3. Drill the four 7/32" screw holes.
4. Attach and secure the **EOI** to the front side of the mounting location using the four 6-32 x 5/16" pan head screws, the #6 split lock washers, and the #6 flat washers.
5. Connect the extension cable.

EOI Mounting Dimensions

Figure 25. EOI Mounting Dimensions.




EOI Remote Mounting Using the ASD-MTG-KIT

Note: See [Figure 26](#) for the dimensions and the item locations referenced in steps 1 through 6.

1. At the **EOI** mounting location, mark the 4.60" by 4.50" hole and the four 11/32" screw holes.
2. Cut the 4.60" by 4.50" rectangular hole.
3. Drill the four 11/32" holes for the Bezel Plate mount.
4. Attach and secure the Bezel Plate to the front side of the mounting location using the four 10-32 hex nuts, #10 split lock washers, and the #10 flat washers.
5. Attach and secure the **EOI** to the front side of the Bezel Plate using the four 6-32 x 5/16" pan head screws, #6 split lock washers, and the #6 flat washers.
6. Connect the extension cable.

EOI ASD-MTG-KIT Mounting Dimensions

Figure 26. EOI Bezel Plate Mounting Dimensions.



System Operation


Operation (Local)

Note: See the section titled [EOI Features on pg. 33](#) for information on **Remote** operation.

To turn the motor on perform the following:

1. Press the **Mode** key until the **Frequency Command** screen is displayed.
2. Press the **Local/Remote** key to enter the **Local** mode (green **Local** LED illuminates).
3. Turn the **Rotary Encoder** clockwise until the desired **Frequency Command** value is displayed in the **SET** field of the LCD screen.
4. Press the **Run** key and the motor runs at the **Frequency Command** value.

Frequency Command Screen

0 ————— 100%		
SET:	0.00 Hz	
DC Voltage:		0.00%
Output Current:		0.00%
F R I1 I2 I3 I4 I5 I6		
OUT1 OUT2 BRAKE		

Note: The speed of the motor may be changed while the motor is running by using the **Rotary Encoder** to change the **Frequency Command** value.

5. Press the **Stop-Reset** key to stop the motor.

Default Setting Changes

To change a default parameter setting go to the root level of the **Program** menu. Turn the **Rotary Encoder** until the desired parameter group is within the cursor block. Press the **Rotary Encoder** to select an item or to access a subgroup (repeat if required until reaching the parameter to be changed).

Press the **Rotary Encoder** to enter the **Edit** mode and the value/setting takes on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter value/setting.

Press the **Rotary Encoder** while the parameter setting is in the reverse video mode to accept the new setting or press the **ESC** key while the new parameter setting is in the reverse video mode to exit the menu without saving the change.

For a complete listing of the **Program** mode menu selections, see the section titled [Program Mode Menu Navigation on pg. 57](#). **Program** menu items are listed and mapped for convenience. The **Direct Access Numbers** are listed where applicable.

The default settings may also be changed by entering the **Parameter Number** of the setting to be changed at the **Direct Access** menu (Program ⇒ Direct Access ⇒ *Applicable Parameter Number*). A listing of the **Direct Access Numbers** and a description of the associated parameter may be found in the section titled [Direct Access Information on pg. 79](#).

A listing of all parameters that have been changed from the default setting may be viewed sequentially by accessing the **Changed From Default** screen (Program ⇒ Utilities ⇒ Changed From Default).

The **Changed From Default** feature allows the user to quickly access the parameters that are different from the factory default settings or the post-reset settings. Once the **Changed From Default** screen is displayed, the system scrolls through all of the system parameters automatically and halts once reaching a changed parameter.

Once stopped at a changed parameter, the **Rotary Encoder** may be clicked once clockwise to continue scrolling forward or clicked once counterclockwise to begin scrolling in reverse. With each click of the **Rotary Encoder** from a stop, the system scrolls through the parameters and stops at the next parameter that has been changed.

Press the **Rotary Encoder** while stopped at a changed parameter to display the settings of the changed parameter. Press the **Rotary Encoder** to enter the **Edit** mode — the parameter value/setting takes on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter setting.


Press the **ESC** key while the setting is in the reverse video format to exit the **Edit** mode without saving the change and to resume the **Changed From Default** search. Or press the **Rotary Encoder** while the setting is in the reverse video format to save the change. Press **ESC** to return to the **Changed From Default** search.

Pressing **ESC** while the system is performing a **Changed From Default** search terminates the search. Pressing **ESC** when finished searching (or halted at a changed parameter) takes the menu back one level.

Note: *Communications setting changes will require that the ASD power be removed and then re-applied for the changes to take affect.*

Note: *Parameter F201 was changed to create the example shown in Figure 27.*

Figure 27. Changed From Default Screen.



Save User Settings

A profile of an existing setup may be saved and re-applied when required by using the **Save User Setup** feature. This function is carried out via Program ⇒ Utilities ⇒ Type Reset ⇒ **Save User Settings**.

With the initial setup saved, troubleshooting and diagnostics may be performed and the starting setup may be re-applied when finished via Program ⇒ Utilities ⇒ Type Reset ⇒ **Restore User Settings**.

Note: *EOI settings are not stored using the **Save User Settings** or using the **Restore User Settings** features (i.e., contrast setting, voltage/current units, display gradient characteristics, etc.).*

Startup Wizard Requirements



CAUTION

In the event of a power loss while programming the system using the Startup Wizard the parameter entries completed before the power loss will be retained and used by the system upon system startup. Confirm that all settings are as required for the application before system startup.

The **Startup Wizard** is used to quickly setup the commonly used parameters of the ACE-tronics G9 ASD — it queries the user for information on **Motion Control** settings and on the input and output signal parameters. The ASD may also be setup by directly accessing each of the control settings via the **Program** menu (see [pg. 57](#)) or the **Direct Access Numbers** (see [pg. 79](#)).

To run the **Startup Wizard**, go to the **Program** menu and click **Startup Wizard**.

At the subsequent screen either click **Exit** to end the **Startup Wizard** or click **Next** to continue with the wizard.

Click **Next** at each parameter screen to accept the setting and to go to the next screen.


Upon completion of the **Startup Wizard** click **Exit** to return the system to the [Frequency Command Screen](#).

Note: The **Startup Wizard** is disabled during an active **Run** command. Remove the **Run** command (deactivate **F** and/or **R**) to enable the **Startup Wizard** function.

The **Startup Wizard** queries the user for the parameter settings listed below.

- [Startup Wizard Introduction Screen](#)
- [Motor Capacity](#)
- [Motor RPM](#)
- [Motor Current](#)
- [ASD Control Configuration](#)
 - [Standard Hoist Control](#)
 - [Standard Traverse Control](#)
 - [Custom](#)
 - [Hoist](#)
 - [Traverse](#)
- [Autotune Enable](#)
- [Speed Control \(F986\)](#)
- [Accel/Decel Times](#)
- [Special Functions](#)

Figure 28. Startup Wizard Flow Chart.



See F986 on pg. 231 for specifics on the setup and functional descriptions of the associated discrete input terminals for a given **Speed Control** mode selection.

Startup Wizard Introduction Screen

The introduction screen provides an opportunity to exit the wizard before launching. Once started, the wizard must be completed to exit the program.

Select **Exit** to terminate the wizard and configure manually. Go to the **Program** screen and select the parameters to be configured.

To continue with the wizard click **Next**.

ACE Wizard		
Back	Next >	Exit
Select Exit to manually configure. Otherwise the Wizard must complete once started.		

Motor Capacity

This parameter is used to set the (Nameplate) rated capacity of the motor being used.

ACE Wizard		
Back	Next >	Exit
[F405] What is the motor rated capacity (nameplate)?		
1.00 HP		

Motor RPM

This parameter is used to set the (Nameplate) RPM of the motor being used.

ACE Wizard		
Back	Next >	Exit
[F407] What is the rated RPM (nameplate) of the motor?		
1690 RPM		

Motor Current

This parameter is used to set the (Nameplate) rated current of the motor being used.

ACE Wizard		
Back	Next >	Exit
[F406] What is the MOTOR rated current (nameplate)?		
3.4 A		

ASD Control Configuration

This parameter is used to set the operating mode of the ASD. Selections are **Standard Hoist Control**, **Standard Traverse Control**, and **Custom Control**.

ACE Wizard		
Back	Next >	Exit
Select control configuration:		
Standard Hoist Control		

Select **Standard Hoist Control** to use the ASD for **Hoist Control** and to place the following settings in effect:

Closed-Loop Vector Control.
 PG Feedback = On.
 Torque Proving = Enabled.
 1024 PG Pulse/Rotation.
 PG Encoder Phase = 2.
 PG Disconnection Detection = Enabled.
 Control = 2-Step Variable.
 I2 – I6 = Unassigned.
 OUT1 = Brake Failure (154), N.O.
 OUT2 = Brake Release (68), N.O.
 BRAKE = Brake Release (68), N.O.
 Express Stop = Disabled.
 Plugging = Disabled.
 Accel Time 1 = 3 Seconds.
 Decel Time 1 = 1.5 Seconds.

Next = Go to [Autotune Enable on pg. 46](#).

Select **Standard Traverse Control** to use the ASD for Traverse Control and to place the following settings in effect:

Constant Torque Control.
 PG Feedback = Off.
 Torque Proving = Disabled.
 Control = 2-Step Variable.
 I2 – I6 = Unassigned.
 OUT1 = Fault All (10), N.C.
 OUT2 = Always Off (254), N.O.
 BRAKE = Brake Release (68), N.O.
 Express Stop = Disabled.
 Plugging = Disabled.
 Accel Time 1 = 6 Seconds.
 Decel Time 1 = 6 Seconds.

Next = Go to [Autotune Enable on pg. 46](#).

Select **Custom** to use the ASD for application-specific **Hoist Control** or **Traverse Control** and to place the following associated settings in effect:

Select **Yes** or **No** at **Encoder Being Used?**

Hoist Control ————— **Next** —————→

Torque Proving = Enabled.
 OUT1 = Brake Failure (154), N.O.
 OUT2 = Brake Release (68), N.O.
 BRAKE = Brake Release (68), N.O.

Traverse Control

Constant Torque.
 Torque Proving = Disabled.
 OUT1 = Fault All (10), N.C.
 OUT2 = Always Off (254), N.O.
 BRAKE = Brake Release (68), N.O.
 Express Stop = Disabled.

Encoder Being Used?	No	Yes
Speed Sense	Sensorless Vector	Closed Loop
PG Feedback	Off	On
Autotune	Enabled	Enabled
Pulses/Rotation	N/A	1024
Encoder Phases	N/A	2
Disconnect Detection	N/A	Enabled
Go to Speed Control (F986) on pg. 46 .		

Autotune Enable

This parameter is used to enable/disable the **Autotune** function.

Autotune 1 = Autotune **Disabled** or **Enabled** **Autotune on Run Command**.

ACE Wizard		
Back	Next >	Exit
(F400) Autotune on Run command selection:		
Autotune Disabled		

Speed Control (F986)

2-Step Variable — **F**, **R**, and **I1**.

3-Step Variable — **F**, **R**, **I3** and **I4**.

5-Speed — **F**, **R**, and **Preset Speeds 1 – 4**.

2-Speed and **3-Speed** — Same as **5-Speed** using only the required number of **Preset Speed** settings.

Unipolar Analog (RR).

Bi-Polar Analog (RX).

ACE Wizard		
Back	Next >	Exit
(F986) What kind of speed control do you need?		
> 2-Step Variable		

Accel/Decel Times

Accel Time 1 = 10.0 S

Decel Time 1 = 10.0 S

ACE Wizard		
Back	Next >	Exit
(F010) Set deceleration time:		
> 10.0 seconds		

Special Functions

Enable **Slow-Speed Limit-Switch** — Sets **I3** and **I4** to **Slow-Speed Limit Switch Forward** and **Slow-Speed Limit Switch Reverse**, respectively.

Enable **Stop Limit-Switch** for **F** and **R** — Sets **I5** and **I6** to **Stop Limit-Switch Forward** and **Stop Limit-Switch Reverse**, respectively.

Enable Express Speed (F328).

Enable (Plugging F494).

Creep Speed LL (F492) — Sets **I4** to **Creep Speed 1 Command**.

Enable **Super Creep** — Sets **I4** to **Super Creep**.

Enable Slack Rope Detection (F867).

Speed Reference — Sets **I4** to **Frequency Reference Priority Switching**.

Enable Autotune On Run Command (F400).

Note: Enabling any of the above functions will overwrite the previous function assigned to the associated discrete input terminal.

Command and Frequency Mode Control

Command control includes instructions such as **Stop**, **Run**, **Jog**, etc. The source of the **Command** signal must be established for normal operation.

Frequency commands control the output speed of the ASD. The source of the frequency control signal must be established for normal operation.

The source of the command control and frequency control may be either internal or external. Once the source signal is selected for either function, the system may be configured to use the selected signal all of the time or switch under user-defined conditions.

Command and **Frequency** control may be carried out using any one of several control methods (signal sources) or combinations thereof. In the event that multiple control commands are received, the signal sources are assigned priority levels. The primary control method for **Command** and **Frequency** control uses the settings of **F003** and **F004**, respectively.

Command Control (F003)

The **Command Mode** selection of **F003** establishes the primary source of the command input for the ASD. However, the **Override** feature may supersede the **F003** setting as indicated in [Table 5](#).

[Table 5 on pg. 49](#) shows the hierarchy of the control sources managed by the **Override** function. The level of the control item of the hierarchy is listed from left to right, most to least, respectively. As indicated in the table, the **Override** setting may supersede the **F003** setting.

01:06
Standard Mode Selection
(F003) Command Mode Selection
Terminal Block

Placing the **EOI** in the **Local** mode selects the **RS485 2-Wire** as the **Command Mode** control source. **Local** mode operation may be superseded by other **Override** settings.

Example: With the **EOI** set to **Local**, **Communication Board** input or **RS485 4-Wire** input will supersede **EOI** control input.

The remaining control sources may be placed into the **Override** mode using communications.

The source of the **Command** control signal may be selected by:

- The **F003** setting,
- Placing an item from the **Command** signal source selections in the **Override** mode via communications, or
- Placing the **EOI** in the **Local** mode (places only the RS485 [2-Wire] or the RS485 [4-Wire] in the **Override** mode).

Possible **Command** signal source selections include the following:

- Terminal Board (default),
- EOI Keypad,
- RS485,
- Communication Option Board, or
- **F003** setting (is used if no signal sources are in the **Override** mode).

Note: The **Terminal Board** is placed in the **Override** mode for **Command** functions by assigning a discrete terminal to **Command Terminal Board Priority** and activating the terminal by applying 120 VAC. Once activated (Run command required), the **Terminal Board** settings will be used for **Override Command** control (F, R, Preset Speeds, etc.).

Frequency Control (F004)

The **Frequency Mode 1** (or the Frequency Mode 2) setting establishes the user-selected source of the frequency-control input for the ASD. The signal source selected here is used for frequency control unless the **Reference Priority Selection** parameter is configured to switch this setting automatically (see F200) or if the **Override** feature is enabled.

Table 5 on pg. 49 shows the hierarchy of the control sources managed by the **Override** function. The level of the control item of the hierarchy is listed from left to right, most to least, respectively. As indicated in the table, the **Override** setting may supersede the selection at F004.

Placing the **EOI** in the **Local** mode selects the **RS485 2-Wire** as the **Frequency Mode 1** control source. **Local** mode operation may be superseded by other **Override** settings.

Example: With the **EOI** set to **Local**, the **Communication Board** input or the **RS485 4-Wire** input will supersede **EOI** control input.

The remaining control sources may be placed into the **Override** mode using communications.

The source of the **Frequency** control signal may be selected by:

- The F004 setting,
- Placing an item from the **Frequency** control source selections in the **Override** mode via communications, or
- Placing the **EOI** in the **Local** mode (places only the RS485 [2-Wire] in the Override mode).

Possible **Frequency** control source selections include the following:

- Communication Board,
- RS485,
- EOI Keypad,
- Terminal Board (the default setting), or
- F004 setting (used if no other items are in the Override mode).

Note: The **Terminal Board** is placed in the **Override** mode for frequency control functions by assigning a discrete terminal to **V/I Terminal Priority** and activating the terminal by applying 120 VAC to the terminal. Once the discrete terminal is activated, **V/I** is used as the **Terminal Board Override** control item.

02:06
Standard Mode Selection
(F004) Frequency Mode 1
RR

Command and Frequency Control Selections

The user may select only one **Command** source and only one source for **Frequency** control. The default settings for **Command** and **Frequency** control are **Terminal Board** and **RR**, respectively.

The ASD has a command register for each item listed as a **Command** or **Frequency** source. The registers store the **Override** setting for each control source. The registers are continuously scanned to determine if any of the listed items are in the **Override** mode.

For each scan cycle, the command registers of the control sources are scanned for the **Override** setting in the order that they are listed in Table 5. The first item of the **Command** section and the first item of the **Frequency** section detected as being in the **Override** mode will be used for **Command** and **Frequency**

control, respectively. If no items are detected as being in the **Override** mode, the settings of **F003** and **F004** will be used for **Command** and **Frequency** control, respectively.

Any or all of the **Command** and **Frequency** control input sources may be placed in the **Override** mode.

Placing the ASD in the **Local** mode (Local/Remote LED on) via the **EOI** places the **RS485 2-Wire** control selection in the **Override** mode for **Command** and **Frequency** input (see the section titled **Override Operation** on pg. 49 for the proper setting). The **Local/Remote** control **Override** feature for **Command** and **Frequency** (or either) may be enabled/disabled at Program ⇒ Utilities ⇒ Prohibition ⇒ **Local/Remote** key (Command or Frequency) **Override**.

Communications may be used to place the remaining **Command** and eligible **Frequency** control input sources in the **Override** mode. Once placed in the **Override** mode this setting is valid until it is cancelled, the power supply is turned off, or the ASD is reset.

Override Operation

The signal sources of **Table 5** are scanned from left to right in the order that they are listed to determine which input sources are in the **Override** mode (active Command or Frequency command present). The first item detected as having the **Override** function turned on is the selection that is used for **Command** or **Frequency** control input.

The **Override** control setting supersedes the setting of the **Command** mode setting (**F003**) and the **Frequency** mode setting (**F004**). However, the **F003** and **F004** settings will be used in the event that the register scan returns the condition that none of the listed items have the **Override** feature turned on or a discrete input terminal is set to **Serial/Local Switch** and is activated.

Command and Frequency-Control Override Hierarchy

Table 5 lists the input conditions and the resulting output control source selections for **Command** and **Frequency** control **Override** operation.

The ASD software reads the memory locations of the listed control sources from the left to the right.

The first item to be read that has the **Override** feature turned on will be used for **Command** or **Frequency** control.

Table 5. Command and Frequency Control Hierarchy.

1	2	3	4	5	6	Priority Level
Forced F003/ F004 by I/P Terminal (Assign to Serial/ Local Switch)	Comm. Board	RS485	EOI Keypad	Terminal Board (Binary/BCD Input)	F003/F004	Command/ Frequency Mode
1	X	X	X	X	X	F003/F004 Setting
0	1	X	X	X	X	Communication Board
0	0	1	X	X	X	RS485
0	0	0	1	X	X	EOI Keypad
0	0	0	0	1	X	Terminal Board
0	0	0	0	0	F003/F004 Setting	F003/F004 Setting

Note: 1 = Override feature is turned on for that control input source; 0 = Override Off; X = Don't Care.

Command Control Selections

The following is a listing with descriptions of the Command Mode (F003) selections (Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ **Command Mode Selection**).

Settings:

0 — Terminal Board

Allows for **Command** control input via the **Terminal Board**.

1 — Not Used

Unused.

2 — EOI Keypad

Used for EOI command control.

3 — RS485

Used to transfer commands to the ASD via **RS485 4-Wire**.

4 — Communication Option Board

Use this setting if using the optional **Communication Board** for command control.

01:06
Standard Mode Selection
(F003) Command Mode Selection
Terminal Block ← (Default)

Frequency Control Selections

The following is a listing with descriptions of the Frequency Mode (F004) selections (Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1).

Settings:

1 — V/I

Used when a 0 to 10 VDC analog input or a 0 – 20 mA DC current input is used as the frequency control input. Only one input signal type may be used at a time. Set **SW2** to the desired signal type.

2 — RR

Used for a 0 to 10 VDC analog input signal.

3 — RX

Used for a ±10 VDC analog input signal.

4 — Not Used

Unused.

5 — EOI Keypad

Used for EOI frequency control.

6 — RS485

Used to transfer speed commands to the ASD via **RS485 4-Wire**.

02:06
Standard Mode Selection
(F004) Frequency Mode 1
RR ← (Default)

7 — Communication Option Board

Use this setting if using the optional **Communication Board** for frequency control.

8 — RX2 Option (AI1)

Used for a ± 10 VDC analog input signal.

9 — Option V/I

Allows for the use of the optional voltage/current frequency-control interface.

10 — UP/DOWN Frequency

A discrete terminal may be configured to increase or decrease the speed of the motor by momentarily activating the terminal by applying 120 VAC to the terminal. See [F264 on pg. 131](#) for additional information on this feature.

11 — Pulse Input Option

Used to allow the system to use a pulsed input for frequency control. See [PG Input Point 1 Setting on pg. 125](#) for additional information on this feature.

12 — Pulse Input (Motor CPU)

Used to allow the system to use a pulsed input for frequency control. See [PG Input Point 1 Setting on pg. 125](#) for additional information on this feature.

13 — Binary/BCD Input Option

Allows for discrete terminal to be used for frequency-control input.

System Configuration and Menu Options


Root Menus

The **Mode** key accesses the three primary modes of the ACE-tronics G9 ASD: the **Frequency Command** mode, the **Monitor** mode, and the **Program** mode. From either mode, press the **Mode** key to loop through to the other two modes (see Figure 29). While in the **Frequency Command** mode, pressing the **ESC** key toggles the menu to and from the **EOI Command** mode and the **Frequency Command** mode.

The **Alarm** or **Fault** information will be displayed in the event of an active **Alarm** or **Fault**. **Alarm** text will be displayed on the **Frequency Command** screen and on the LED screen when active. **Fault** information will be displayed via the **Fault** screen. See [Alarms and Trips on pg. 248](#) for more information on **Alarms** and **Trips**.

Note: *EOI Command mode changes are effective for EOI control Only.*

Figure 29. ACE-tronics G9 ASD Root Menu Navigation.



Frequency Command Mode

Frequency Setting

While operating in the **Local** mode (Local LED is illuminated on the front panel), the running frequency of the motor may be set from the **Frequency Command** screen. Using the **Rotary Encoder**, enter the **Frequency Command** value, provide a **Run** command (F and/or R), and then press the **Run** key. The motor will run at the **Frequency Command** speed and may be changed while running. See [Figure 22. on pg. 35](#) and [Operation \(Local\) on pg. 40](#) for more information on the **Frequency Command** mode.

EOI Command Mode

The **EOI Command** mode is accessed by pressing the **ESC** key from the **Frequency Command** screen.

The control settings of the **EOI Command** menu are effective for **EOI** control only.

The **EOI Command** mode provides quick access to the following menu parameters:

Direction — **Forward** or **Reverse**.

Stop Pattern — The **Decel Stop** or **Coast Stop** settings determines the method used to stop the motor when using the **Stop-Reset** key of the **EOI**. The **Decel Stop** setting enables the **Dynamic Braking** system setup at [F304](#) or the **DC Injection Braking** system setup at [F250](#), [F251](#), and [F252](#). The **Coast Stop** setting allows the motor to stop at the rate allowed by the inertia of the load.

Note: The **Stop Pattern** setting has no effect on the **Emergency Off** settings of [F603](#).

V/f Group — One of four **V/f** profiles may be selected and run. Each **V/f** profile is comprised of 4 user settings: **Base Frequency**, **Base Frequency Voltage**, **Manual Torque Boost**, and **Electronic Thermal Protection**. Expanded descriptions of these parameters may be found in the section titled [Direct Access Information on pg. 79](#).

Accel/Decel Group — One of four **Accel/Decel** profiles may be selected and run. Each of the **Accel/Decel** profiles is comprised of three user settings: **Acceleration**, **Deceleration**, and **Pattern**. Expanded descriptions of these parameters may be found in the section titled [Direct Access Information on pg. 79](#).

Feedback in Panel Mode — Enables or disables the **PID** feedback function.

Torque Limit Group — Used to select one of four preset positive torque limits to apply to the active motor (of a multiple motor configuration). The settings of profiles 1 – 4 may be setup at [F441](#), [F444](#), [F446](#), and [F448](#), respectively.

Monitor Mode

The **Monitor** mode allows the user to monitor motor performance variables, control settings, and configuration data during motor operation. The items that are viewable from this mode are listed and described below.

Note: The **Monitor** mode is a read-only mode. The settings **cannot** be changed from the **Monitor** mode. For information on how to change the values, see the section titled *Default Setting Changes on pg. 40*.

Note: Any two of the Underlined monitored items may be selected for display at the **Frequency Command** screen while running via Program \Rightarrow Utilities \Rightarrow *Main Monitor Selections* (see pg. 56 for information on using the *Main Monitor Selections* feature).

Note: The **F701** setting will determine if the Current and Voltage values displayed appear as **A** (Amps) and **V** (Voltage), or if the value is shown as a % (percentage) of the ASD rating.

Frequency at Trip — Displays the at-trip frequency.

Frequency Reference — Displays the **Frequency Setpoint**.

Output Current — Displays the **Output Current** as a percentage of the rated capacity of the ASD.

DC (Bus) Voltage — Displays the **Bus Voltage** as a percentage of the rated capacity of the ASD.

Output Voltage — Displays the **Output Voltage** as a percentage of the rated capacity of the ASD.

AM Output — Displays the **AM** output terminal value for the function assigned to the **AM** terminal.

FM Output — Displays the **FM** output terminal value for the function assigned to the **FM** terminal.

Motor OL (Overload) Real — Displays the real-time **Motor Overload** value as a percentage of the rated capacity of the motor.

Motor OL (Overload) Trip — Displays the **Motor Overload Trip** value as a percentage of the rated capacity of the motor.

Motor Load — Displays the real-time **Motor Load** as a percentage of the rated capacity of the motor.

ASD OL (Overload) Real — Displays the real-time **ASD Overload** as a percentage of the rated capacity of the ASD.

ASD OL (Overload) Trip — Displays the **ASD Overload Trip** value as a percentage of the rated capacity of the ASD.

ASD Load — Displays the **ASD Load** as a percentage of the rated capacity of the ASD.

Run Time — Displays the **Cumulative Run Time** in hours. Set to zero by selecting **Clear Run Timer** at parameter **F007**.

Compensation Frequency — Displays the **Output Frequency** after the application of the slip compensation correction value (Post Compensation Frequency).

DBR OL (Overload) Real — Displays the real-time **DBR Overload** value as a percentage of the **Dynamic Braking Resistor** capacity.

DBR OL (Overload) Trip — Displays the **DBR Overload Trip** value as a percentage of the **Dynamic Braking Resistor** capacity.

DBR Load — Displays the **DBR Load** as a percentage of the **Dynamic Braking Resistor** capacity.

Feedback (Inst) — Provides a status of the **Real Time Feedback** in Hz.

Feedback (1 Second) — Provides a status of the **1-Second Averaging** feedback in Hz.

Torque — Displays the **Output Torque** as a percentage of the rated capacity of the ASD.

Torque Reference — Displays the **Torque Reference** as a percentage of the maximum torque available.

Torque Current — Displays the torque-producing current value.

Excitation Current — Displays the current value required to produce the excitation field.

PID Feedback — Provides a status of the **PID Real Time Feedback** in Hz.

Input Power — Displays the **Input Power** in Kilowatts (kW).

Output Power — Displays the **Output Power** in Kilowatts (kW).

Pattern Group Number — Displays the active **Pattern Run Group Number**.

Pattern Cycle Number — Displays the cycle number of the active **Pattern Run Group**.

Pattern Preset — Displays the active **Preset Speed** being run of the active **Pattern Run Group**.

Pattern Time — Displays the remaining time for the active **Pattern Run Group**.

RR — Displays the **RR** input value as a percentage of the full range of the **RR** value (potentiometer input).

V/I — Displays the **V/I** input setting as a percentage of the full range of the **V/I** value.

Note: *The isolated **V/I** input terminal may receive **Current** or **Voltage** to control the output speed or the output torque. The input signal type must be selected at **SW2** on the **ACE G9-120V-PCB**.*

*The **V** input setting of **SW2** is used for the 0 – 10 VDC analog input signal and the **I** input setting of **SW2** is used for the 0 – 20 mA analog input signal. Either may be used as a frequency or torque command source. See parameter **F201** for more information on the setup of this terminal.*

RX — Displays the **RX** input setting as a percentage of the full range of the **RX** value (± 10 VDC input).

RX2 Option (AI1) — Displays the **RX2** input setting as a percentage of the full range of the **RX2** value.

Note: *The **RX2** function is available on the **Expansion IO Card Option 1** option board (P/N ETB003Z) only.*

Trip Code — Displays **None** if there are no errors, or displays one of the associated **Fault Codes** listed in [Table 15 on page 254](#) if there is an active **Fault** (e.g., E = Emergency Off).

Past Trip 1 — This function records and displays the last trip incurred. Subsequent trips will replace **Past Trip 1**. As trip records are replaced they are shifted to the next level of the **Past Trip** locations until being deleted (i.e., Past Trip 1 is moved to Past Trip 2 and then to Past Trip 3 until being shifted out of Past Trip 4). Once shifted out of **Past Trip 4** the record is deleted. If no trips have occurred since the last reset, **None** is displayed for each trip record.

Past Trip 2 — Past trip information or **None**.

Past Trip 3 — Past trip information or **None**.

Past Trip 4 — Past trip information or **None**.

***Note:** An improper ASD setup may cause some trips — reset the ASD to the **Factory Default** settings before pursuing a systemic malfunction (Program ⇒ Utilities ⇒ Type Reset ⇒ Reset to Factory Settings).*

Direction — Displays the **Direction** command (forward/reverse).

Discrete Input Terminals — Displays the status (activated = reverse video) of the discrete input terminals of the **ACE G9-120V-PCB**.

Discrete Output Terminals — Displays the status (activated = reverse video) of the discrete output lines of the **ACE G9-120V-PCB**.

Main Monitor Selections

Two (2) **Monitor Mode** items may be selected from the **Main Monitor Selections** screen to be displayed on the **Frequency Command** screen while the ASD is running.

The selected items, along with their real-time values, are displayed on the **Frequency Command** screen while running. Not all **Monitor Mode** items are available for display on the **Frequency Command** screen. The available items are underlined on [pg. 54](#) and [pg. 55](#).

Any two of the underlined items may be selected from the listing at Program ⇒ Utilities ⇒ **Main Monitor Selections**. Select an item from the **Monitor 1** listing and another item from the **Monitor 2** listing to be displayed as shown in [Figure 22. on pg. 35](#).

Program Mode Menu Navigation

The following table lists the menu items of the **Program** mode and maps the flow of the menu selections. The **Parameter Numbers** for the listed functions are provided where applicable.

The functions listed may be viewed, or selected and changed as mapped below or via the **Direct Access** method: Program ⇒ Direct Access ⇒ *Applicable Parameter Number*.

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
STARUP WIZARD	See the section titled Startup Wizard Requirements on pg. 42 for Startup Wizard setup information.		
CRANE / HOIST	Motion Control	Motion Control	F985
	Speed Control	Speed Control	F986
		Preset Speed 1	F018
		Preset Speed 2	F019
		Preset Speed 3	F020
		Preset Speed 4	F021
	Express Stop	Express Stop Enable	F493
		Express Stop Deceleration Time	F511
	Plugging	Plugging Enable	F494
		Plugging Acceleration Time	F514
		Plugging Deceleration Time	F515
	Creep Control	Creep Multiplier 1	F490
		Creep Multiplier 2	F491
		Creep Speed Lower Limit	F492
	Super Creep Control	Super Creep Pulse Count	F863
		Super Creep Repeat Delay	F864
		Super Creep Speed	F865
	Limit-Switch Control	Upper-Limit Speed at Slow-Speed Limit-Switch UP	F294
		Deceleration Time at Slow-Speed Limit-Switch UP	F283
		Stopping Time at Stop Limit-Switch UP	F284
		Upper-Limit Speed at Slow-Speed Limit-Switch DOWN	F293
		Deceleration Time at Slow-Speed Limit-Switch DOWN	F285
		Stopping Time at Stop Limit-Switch DOWN	F286
		Limit-Switch Stopping Method	F282

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
CRANE / HOIST	Express Speed	Express Speed Selection	F328
		Express Speed Switching Frequency	F330
		Express Speed Operation Switching Lower-Limit Frequency	F331
		Express Speed Waiting Time	F332
		Express Speed Detection Time	F333
		Switching Load Torque During Power Run	F335
		Express Speed Operation Heavy-Load Detection Time	F334
		Heavy-Load Torque During Power Run	F336
		Heavy-Load Torque During Fixed-Speed Power Run	F337
		Switching Load Torque During Dynamic Braking	F338
	Closed Loop Hoist Control	Brake-Failure Pulse Count	F994
		Brake-Release Torque Reference	F987
		Brake-Release Torque (Proving) Time	F988
		Brake-Release Mechanical Delay Time	F990
		Brake-Set Mechanical Delay Time	F991
		Brake-Seized Pulse Check	F993
		Load Hover Time	F997
		Brake-Failure Continual Monitoring Pulse Count	F995
		Drooping Pulses Allowed	F998
		Brake-Release Torque Stabilization Time	F989
		Brake-Seized Pulse Time	F992
		Brake-Failure Maximum Speed UP	F996
		Encoder Error Detection Time	F999
	Timed-Run	Timed-Run Run Time	F861
		Timed-Run Repeat Delay	F862
	Slack Rope	Slack Rope Detection	F867
		No Load Torque	F868
		No Load Detection Time	F869
	Bearing Greaser	Bearing Greaser (Alarm) Time	F621
		Bearing Greaser Speed Multiplier	F489

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
CRANE / HOIST	External Fault	External Fault Stopping Method	F280
	Emergency Lift	Emergency-Lift Selection	F656
		Emergency-Lift Maximum Speed	F657
		Emergency-Lift Lower-Limit Reference	F658
		Emergency-Lift Torque Proving Time	F659
	Speed Reference	Speed Reference	F116
		Frequency Mode 2	F207
FUNDAMENTAL	Acc/Dec 1	Automatic Acceleration/Deceleration	F000
		Acceleration Time 1 — UP/DOWN Frequency Accel Time	F009
		Deceleration Time 1 — UP/DOWN Frequency Decel Time	F010
		Acceleration/Deceleration Suspended Function	F349
		Acceleration Suspend Frequency	F350
		Acceleration Suspend Time	F351
		Deceleration Suspend Frequency	F352
		Deceleration Suspend Time	F353
	Frequency	Maximum Frequency	F011
		Upper-Limit Frequency	F012
		Lower-Limit Frequency	F013
		V/f Pattern	F015
		Time Limit for Lower-Limit Frequency Operation	F256
	Motor Set 1	Automatic Torque Boost	F001
		Base Frequency 1	F014
		Manual Torque Boost 1	F016
		Motor Overload Protection Level 1	F600
	Standard Mode Selection	Command Mode	F003
		Frequency Mode 1	F004
		Forward/Reverse Run	F008
		Frequency Priority	F200
		Frequency Mode 2	F207
		Frequency Mode Priority Switching Frequency	F208

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TERMINAL	Analog Output Terminals	FM Output Terminal Function	F005
		FM Output Terminal Adjustment	F006
		FM Output Gradient Characteristic	F682
		FM Bias Adjustment	F683
		FM Voltage/Current Output Switching	F681
		AM Output Terminal Function	F670
		AM Output Terminal Adjustment	F671
		AM Output Gradient Characteristic	F685
		AM Bias Adjustment	F686
		MON 1 Terminal Meter Selection	F672
		MON 1 Terminal Meter Adjustment	F673
		MON 1 Output Gradient Characteristic	F689
		MON 1 Bias Adjustment	F690
		MON 1 Voltage/Current Output Switching	F688
		MON 2 Terminal Meter Selection	F674
		MON 2 Terminal Meter Adjustment	F675
		MON 2 Output Gradient Characteristic	F692
		MON 2 Bias Adjustment	F693
		MON 2 Voltage/Current Output Switching	F691
		Pulse Output Function	F676
		Pulse Output Frequency	F677
	Input Special Functions	Input Terminal Priority	F106
		16-Bit Binary/BCD Input	F107
		V/I Analog Input Breakage Detection Level	F633
	Input Terminal Delays	Input Terminal 1 (F) Response Time	F140
		Input Terminal 2 (R) Response Time	F141
		Input Terminal 3 (I1) Response Time	F142
		Input Terminal 4 (I2) Response Time	F143
		Input Terminal 5–12 Response Time	F144
		Input Terminal 13–20 Response Time	F145

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TERMINAL	Input Terminals	Always ON Terminal Function	F110
		Input Terminal 1 (F) Function	F111
		Input Terminal 2 (R) Function	F112
		Input Terminal 3 (I1) Function	F113
		Input Terminal 4 (I2) Function	F114
		Input Terminal 5 (I3) Function	F115
		Input Terminal 6 (I4) Function	F116
		Input Terminal 7 (I5) Function	F117
		Input Terminal 8 (I6) Function	F118
		Input Terminal 9 (LI1) Function	F119
		Input Terminal 10 (LI2) Function	F120
		Input Terminal 11 (LI3) Function	F121
		Input Terminal 12 (LI4) Function	F122
		Input Terminal 13 (LI5) Function	F123
		Input Terminal 14 (LI6) Function	F124
		Input Terminal 15 (LI7) Function	F125
		Input Terminal 16 (LI8) Function	F126
		Input Terminal 17 (B12) Function	F164
		Input Terminal 18 (B13) Function	F165
		Input Terminal 19 (B14) Function	F166
		Input Terminal 20 (BI5) Function	F167
		Virtual Input Terminal Selection 1	F973
		Virtual Input Terminal Selection 2	F974
		Virtual Input Terminal Selection 3	F975
		Virtual Input Terminal Selection 4	F976
	Line Power Switching	Commercial Power/ASD Switching Output	F354
		Commercial Power/ASD Switching Frequency	F355
		ASD-Side Switching Waiting Time	F356
		Commercial Power-Side Switching Waiting Time	F357
		Commercial Power Switching Frequency Holding Time	F358

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TERMINAL	Output Terminals	Output Terminal 1 (OUT1) Function	F130
		Output Terminal 2 (OUT2) Function	F131
		Output Terminal 3 (BRAKE) Function	F132
		Output Terminal 4 (OUT3) Function	F133
		Output Terminal 5 (OUT4) Function	F134
		Output Terminal 6 (R1) Function	F135
		Output Terminal 7 (OUT5) Function	F136
		Output Terminal 8 (OUT6) Function	F137
		Output Terminal 9 (R2) Function	F138
		Output Terminal 10 (R3) Function	F168
		Output Terminal 11 (R4) Function	F169
	Reach	Low Speed Signal Output Frequency	F100
		Speed Reach Frequency	F101
		Speed Reach Detection Band	F102
DIRECT ACCESS		Parameter Number	N/A
		Unknown Numbers Displayed	
UTILITIES	Display Parameters	Automatic Function Selection	F040
		Current/Voltage Units Setup	F701
		Free Unit Multiplication Factor	F702
		Free Unit	F703
		Free Unit Display Gradient Characteristic	F705
		Free Unit Display Bias	F706
		Change Step Selection 1	F707
		Change Step Selection 2	F708
	Prohibition	Parameter Write Lockout	F700
		Command Mode/Frequency Mode Change Lockout	F736
		Lockout All Keys	F737
		Local/Remote Key Command Override	N/A
		Local/Remote Key Frequency Override	
		Skip Changed-From-Default Uninitialized Parameters	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Trace	Trace Selection	F740
		Trace Cycle	F741
		Trace Data 1	F742
		Trace Data 2	F743
		Trace Data 3	F744
		Trace Data 4	F745
	Alarm Prohibition (Prohibits an EOI alarm display ONLY — alarm still activated)	Over-Current Alarm	N/A
		ASD Overload Alarm	
		Motor Overload Alarm	
		Over-Heat Alarm	
		Over-Voltage Alarm	
		Under-Voltage of Main Power Alarm	
		Reserved (POFF) Alarm	
		Under-Current Alarm	
		Over-Torque Alarm	
		Dynamic Braking Resistor Overload Alarm	
		Bearing Greaser Alarm	
		DeviceNet/Profibus/CC-Link Alarm	
		RS485 Communications	
		Stop After Instantaneous Power-Off Alarm	
		Stop After Lower-Limit Continuous Time	
		Switch Out of Sequence	
		Heavy-Load Alarm	
		Maintenance Timer Alarm	
		Over-Torque Alarm	
		Soft Stall Alarm	
	Type Reset	Reset	F007
	Real-Time Clock Setup	Set Real-Time Clock	N/A
	Trip History (Read-Only)	Trip Number	N/A
		Trip Type	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Trip History (Read-Only)	Frequency at Trip	N/A
		Output Current	
		Output Voltage	
		Direction	
		Frequency Reference	
		DC Voltage	
		Discrete Input Terminals	
		Discrete Output Terminals	
		Run Timer	
		Post Compensation Frequency	
		Speed Feedback (Real-Time)	
		Speed Feedback (1 Second)	
		Torque Feedback	
		Torque Reference	
		Torque Current	
		Excitation Current	
		PID Feedback	
		Motor Overload Ratio	
		ASD Overload Ratio	
		DBR Overload Ratio	
		Motor Load	
		ASD Load	
		DBR Load	
		Input Power	
		Output Power	
	Changed From Default	Changed Parameters	N/A
	Contrast	Contrast Adjustment	N/A
	Version (Read-Only)	G9 EOI (Ver:DB)	N/A
		ASD Type	
		CPU Code Version	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Version (Read-Only)	CPU Code Revision	N/A
		MC Version	
		MC Revision	
		Main Board EEPROM Version	
	Main Monitor Selections	Monitor 1	
		Monitor 2	
PROTECTION	Abnormal Speed	Abnormal Speed Detection Time	F622
		Over-Speed Detection Frequency Upper Band	F623
		Over-Speed Detection Frequency Lower Band	F624
	Base Frequency Voltage	Supply Voltage Correction	F307
	DC (Injection) Braking	DC (Injection) Braking Start Frequency	F250
		DC (Injection) Braking Current	F251
		DC (Injection) Braking Time	F252
		Forward/Reverse DC (Injection) Braking Priority	F253
		Motor Shaft Fixing Control	F254
	Dynamic Braking	Dynamic Braking Enable	F304
		Dynamic Braking Resistance	F308
		Continuous Dynamic Braking Capacity	F309
		Braking Resistance Overload Time (10x Rated Torque)	F639
	Emergency Off	Emergency Off	F603
		Emergency DC Braking Control Time	F604
	Low-Current	Low-Current Trip	F610
		Low-Current Detection Current	F611
		Low-Current Detection Time	F612
		Low-Current Detection Hysteresis Width	F609
	Overload	Motor Overload Protection Configuration	F017
		Overload Reduction Start Frequency	F606
		Motor 150% Overload Time Limit	F607
		ASD Overload	F631

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
PROTECTION	Over-Torque	Over-Torque Trip	F615
		Over-Torque Detection Level During Power Running	F616
		Over-Torque Detection Level During Dynamic Braking	F617
		Over-Torque Detection Time	F618
		Over-Torque Detection Hysteresis	F619
	Phase Loss	ASD Output Phase Failure Detection	F605
		ASD Input Phase Failure Detection	F608
	Retry/Restart	Auto Restart Enable	F301
		Number of Times to Retry	F303
		Ridethrough Time	F310
		Random Mode	F312
	Stall	Over-Voltage Limit Operation	F305
		Stall Prevention Factor 1	F416
		Power Running Stall Continuous Trip Detection Time	F452
		Dynamic Braking Stall Prevention Mode	F453
		Stall Prevention Level	F601
		Over-Voltage Limit Operation Level	F626
	Trip	Retain Trip Record at Power Down	F602
	Under-Voltage/ Ridethrough	Regenerative Power Ridethrough	F302
		Synchronized Deceleration Time	F317
		Synchronized Acceleration Time	F318
		Under-Voltage Trip	F627
		Under-Voltage Detection Time	F628
		Regenerative Power Ridethrough Control Level	F629
	Special Protection Parameters	Short Circuit Detection at Start	F613
		Cooling Fan Control	F620
		Bearing Greaser (Alarm) Time	F621
		Brake Answer Wait Time	F630
FREQUENCY	Analog Filter	Analog Input Filter	F209

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FREQUENCY	Forward/Reverse Disable	Forward/Reverse Disable	F311
	Jog	Jog Frequency	F260
		Jog Stop Pattern	F261
		Panel Operation Jog Mode	F262
	UP/DOWN Frequency Functions	UP/DOWN Up Response Time	F264
		UP/DOWN Up Frequency Step	F265
		UP/DOWN Down Response Time	F266
		UP/DOWN Down Frequency Step	F267
		Initial UP/DOWN Frequency	F268
		Initial UP/DOWN Frequency Rewriting	F269
	V/I	Option V/I Terminal Voltage/Current Selection (AI2 Option Board Input)	F109
	Preset Speeds	Preset Speed 1	F018
		Preset Speed 2	F019
		Preset Speed 3	F020
		Preset Speed 4	F021
		Preset Speed 5	F022
		Preset Speed 6	F023
		Preset Speed 7	F024
		Preset Speed 8	F287
		Preset Speed 9	F288
		Preset Speed 10	F289
		Preset Speed 11	F290
		Preset Speed 12	F291
		Preset Speed 13	F292
		Preset Speed 14/Lower-Limit Slow Speed	F293
		Preset Speed 15/Upper-Limit Slow Speed	F294
	Speed Reference Setpoints	V/I Input Point 1 Setting	F201
		V/I Input Point 1 Frequency	F202
		V/I Input Point 2 Setting	F203

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FREQUENCY	Speed Reference Setpoints	V/I Input Point 2 Frequency	F204
		RR Input Point 1 Setting	F210
		RR Input Point 1 Frequency	F211
		RR Input Point 2 Setting	F212
		RR Input Point 2 Frequency	F213
		RX Input Point 1 Setting	F216
		RX Input Point 1 Frequency	F217
		RX Input Point 2 Setting	F218
		RX Input Point 2 Frequency	F219
		RX2 Option (AI1) Input Point 1 Setting	F222
		RX2 Option (AI1) Input Point 1 Frequency	F223
		RX2 Option (AI1) Input Point 2 Setting	F224
		RX2 Option (AI1) Input Point 2 Frequency	F225
		BIN Input Point 1 Setting	F228
		BIN Input Point 1 Frequency	F229
		BIN Input Point 2 Setting	F230
		BIN Input Point 2 Frequency	F231
		PG Input Point 1 Setting	F234
		PG Input Point 1 Frequency	F235
		PG Input Point 2 Setting	F236
		PG Input Point 2 Frequency	F237
		V/I Input Bias	F470
		V/I Input Gain	F471
		RR Input Bias	F472
		RR Input Gain	F473
		RX Input Bias	F474
		RX Input Gain	F475
		RX2 Option (AI1) Input Bias	F476
		RX2 Option (AI1) Input Gain	F477
		V/I Input Bias (AI2 Option Board Input)	F478
		V/I Input Gain (AI2 Option Board Input)	F479

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
SPECIAL	Acc/Dec 1 – 4	Acceleration Time 2	F500
		Deceleration Time 2	F501
		Acc/Dec Pattern 1	F502
		Acc/Dec Pattern 2	F503
		Acceleration Time 3	F510
		Express Stop Time	F511
		Express Stop Acceleration/Deceleration Pattern	F512
		Plugging Acceleration Time	F514
		Plugging Deceleration Time	F515
		Plugging Acceleration/Deceleration Pattern	F516
	Acc/Dec Special	Acc/Dec Pattern 1 – 4	F504
		Acc/Dec Switching Frequency 1	F505
		S-Pattern Acceleration Lower-Limit Adjustment	F506
		S-Pattern Acceleration Upper-Limit Adjustment	F507
		S-Pattern Deceleration Lower-Limit Adjustment	F508
		S-Pattern Deceleration Upper-Limit Adjustment	F509
		Acc/Dec Switching Frequency 2	F513
		Acc/Dec Switching Frequency 3	F517
	Carrier Frequency	PWM Carrier Frequency	F300
		Carrier Frequency Control Mode	F316
	Crane/Hoist	Express Speed Operation	F328
		Express Speed Learning Function	F329
		Automatic Express Speed Operation Frequency	F330
		Express Speed Operation Switching Lower-Limit Frequency	F331
		Express Speed Operation Load Wait Time	F332
		Express Speed Operation Detection Time	F333
		Express Speed Heavy-Load Detection Time	F334
		Switching Load Torque During Power Running	F335
		Heavy-Load Torque During Power Running	F336
		Heavy-Load Torque During Constant Power Running	F337

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
SPECIAL	Crane/Hoist	Switching Load Torque During Dynamic Braking	F338
	V/f 5-Point Setting	V/f 5-Point Setting Frequency 1	F190
		V/f 5-Point Setting Voltage 1	F191
		V/f 5-Point Setting Frequency 2	F192
		V/f 5-Point Setting Voltage 2	F193
		V/f 5-Point Setting Frequency 3	F194
		V/f 5-Point Setting Voltage 3	F195
		V/f 5-Point Setting Frequency 4	F196
		V/f 5-Point Setting Voltage 4	F197
		V/f 5-Point Setting Frequency 5	F198
		V/f 5-Point Setting Voltage 5	F199
	Frequency Control	Start Frequency	F240
		Run Frequency	F241
		Run Frequency Hysteresis	F242
		End Frequency	F243
	Special Parameters	0 Hz Dead Band Signal	F244
		0 Hz Command Output	F255
		Exciting Strengthening Coefficient	F415
		Annual Average Ambient Temperature	F634
		Rush Current Suppression Relay Activation Time	F635
		PTC 1 Thermal Selection	F637
		PTC 2 Thermal Selection	F638
	Jump Frequencies	Jump Frequency 1	F270
		Jump Frequency 1 Bandwidth	F271
		Jump Frequency 2	F272
		Jump Frequency 2 Bandwidth	F273
		Jump Frequency 3	F274
		Jump Frequency 3 Bandwidth	F275
	Operation Panel Parameters	Operation Command Clear Selection With Standby Terminal Deactivated	F719
		Panel Stop Pattern	F721

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
SPECIAL	Operation Panel Parameters	Panel Torque Command	F725
		Panel Tension Torque Bias	F727
		Panel Load Sharing Gain	F728
		Panel Override Multiplication Gain	F729
		Panel Frequency Lockout	F730
		Panel Emergency Off Lockout	F734
		Panel Reset Lockout	F735
MOTOR	Motor Set 2	Base Frequency 2	F170
		Base Frequency Voltage 2	F171
		Manual Torque Boost 2	F172
		Overload Protection Level 2	F173
	Motor Set 3	Base Frequency 3	F174
		Base Frequency Voltage 3	F175
		Manual Torque Boost 3	F176
		Overload Protection Level 3	F177
	Motor Set 4	Base Frequency 4	F178
		Base Frequency Voltage 4	F179
		Manual Torque Boost 4	F180
		Overload Protection Level 4	F181
	PM Motor	PM Motor Constant 1 (D-Axis Inductance)	F498
		PM Motor Constant 2 (Q-Axis Inductance)	F499
		Step-Out Detection-Current Level (For PM Motors)	F640
		Step-Out Detection-Current Time (For PM Motors)	F641
	Vector Motor Model	Autotune 1	F400
		Slip Frequency Gain	F401
		Autotune 2	F402
	Vector Motor Model	Motor Rated Capacity (Nameplate)	F405
		Motor Rated Current (Nameplate)	F406
		Motor Rated RPM (Nameplate)	F407
		Base Frequency Voltage 1	F409
		Motor Constant 1 (Torque Boost)	F410

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
MOTOR	Vector Motor Model	Motor Constant 2 (No Load Current)	F411
		Motor Constant 3 (Leak Inductance)	F412
		Motor Constant 4 (Rated Slip)	F413
TORQUE	Manual Torque Limit	Power Running Torque Limit 2 Level	F444
		Dynamic Braking Torque Limit 2 Level	F445
		Power Running Torque Limit 3 Level	F446
		Dynamic Braking Torque Limit 3 Level	F447
		Power Running Torque Limit 4 Level	F448
		Dynamic Braking Torque Limit 4 Level	F449
	Setpoints	V/I Input Point 1 Rate	F205
		V/I Input Point 2 Rate	F206
		RR Input Point 1 Rate	F214
		RR Input Point 2 Rate	F215
		RX Input Point 1 Rate	F220
		RX Input Point 2 Rate	F221
		RX2 Option (AI1) Input Point 1 Rate	F226
		RX2 Option (AI1) Input Point 2 Rate	F227
	Torque Control	Torque Command	F420
		Tension Torque Bias Input (Torque Control)	F423
		Load Sharing Gain Input	F424
		Forward Speed Limit Input	F425
		Forward Speed Limit Input Level	F426
		Reverse Speed Limit Input	F427
		Reverse Speed Limit Input Level	F428
		Power Running Torque Limit 1	F440
		Power Running Torque Limit 1 Level	F441
	Torque Limit	Dynamic Braking Torque Limit 1	F442
		Dynamic Braking Torque Limit 1 Level	F443
		Acceleration/Deceleration Operation After Torque Limit	F451
	Torque Speed Limiting	Speed Limit (Torque = 0) Center Value Reference	F430

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TORQUE	Torque Speed Limiting	Speed Limit (Torque = 0) Center Value	F431
		Speed Limit (Torque = 0) Band	F432
		Allow Specified Direction ONLY	F435
FEEDBACK	Drooping Control	Drooping Gain	F320
		Speed at 0% Drooping Gain	F321
		Speed at F320 Drooping Gain	F322
		Drooping Insensitive Torque	F323
		Drooping Output Filter	F324
	Feedback	PID Control Switching	F359
		PID Feedback Signal	F360
		PID Feedback Delay Filter	F361
		PID Feedback Proportional Gain	F362
		PID Feedback Integral Gain	F363
		PID Deviation Upper Limit	F364
		PID Deviation Lower Limit	F365
		PID Feedback Differential Gain	F366
		Process Upper Limit	F367
		Process Lower Limit	F368
		PID Control Wait Time	F369
		PID Output Upper Limit	F370
		PID Output Lower Limit	F371
		Process Increasing Rate	F372
		Process Decreasing Rate	F373
		Speed PI Switching Frequency	F466
	Override Control	Adding Input Selection	F660
		Multiplying Input Selection	F661
	PG	Number of PG Input Pulses	F375
		Number of PG Input Phases	F376
		PG Disconnection Detection	F377
		Simple Positioning Completion Range	F381

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FEEDBACK	PG	Current Control Proportional Gain	F458
		Speed Loop Proportional Gain	F460
		Speed Loop Stabilization Coefficient	F461
		Load Moment of Inertia 1	F462
		Second Speed Loop Proportional Gain	F463
		Second Speed Loop Stabilization Coefficient	F464
		Load Moment of Inertia 2	F465
MY FUNCTION	My Function Selection	My Function Operating Mode	F977
	My Function Unit 1	Input Function Target 1	F900
		Input Function Command 1	F901
		Input Function Target 2	F902
		Input Function Command 2	F903
		Input Function Target 3	F904
		Output Function Assigned	F905
	My Function Unit 2	Input Function Target 1	F906
		Input Function Command 1	F907
		Input Function Target 2	F908
		Input Function Command 2	F909
		Input Function Target 3	F910
		Output Function Assigned	F911
	My Function Unit 3	Input Function Target 1	F912
		Input Function Command 1	F913
		Input Function Target 2	F914
		Input Function Command 2	F915
		Input Function Target 3	F916
		Output Function Assigned	F917
	My Function Unit 4	Input Function Target 1	F935
		Input Function Command 1	F936
		Input Function Target 2	F937
		Input Function Command 2	F938

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
MY FUNCTION	My Function Unit 4	Input Function Target 3	F939
		Output Function Assigned	F940
	My Function Unit 5	Input Function Target 1	F941
		Input Function Command 1	F942
		Input Function Target 2	F943
		Input Function Command 2	F944
		Input Function Target 3	F945
		Output Function Assigned	F946
	My Function Unit 6	Input Function Target 1	F947
		Input Function Command 1	F948
		Input Function Target 2	F949
		Input Function Command 2	F950
		Input Function Target 3	F951
		Output Function Assigned	F952
	My Function Unit 7	Input Function Target 1	F953
		Input Function Command 1	F954
		Input Function Target 2	F955
		Input Function Command 2	F956
		Input Function Target 3	F957
		Output Function Assigned	F958
	My Function Data	My Function Percent Data 1	F918
		My Function Percent Data 2	F919
		My Function Percent Data 3	F920
		My Function Percent Data 4	F921
		My Function Percent Data 5	F922
		My Function Frequency Data 1	F923
		My Function Frequency Data 2	F924
		My Function Frequency Data 3	F925
		My Function Frequency Data 4	F926
		My Function Frequency Data 5	F927

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
MY FUNCTION	My Function Data	My Function Time Data 1	F928
		My Function Time Data 2	F929
		My Function Time Data 3	F930
		My Function Time Data 4	F931
		My Function Time Data 5	F932
		My Function Count Data 1	F933
		My Function Count Data 2	F934
	My Function Analog	Analog Input Function Target 11	F959
		Analog Function Assigned Object 11	F961
		Analog Input Function Target 21	F962
		Analog Function Assigned Object 21	F964
	My Function Monitor	Monitor Output Function 11	F965
		Monitor Output Function Command 11	F966
		Monitor Output Function 21	F967
		Monitor Output Function Command 21	F968
		Monitor Output Function 31	F969
		Monitor Output Function Command 31	F970
		Monitor Output Function 41	F971
		Monitor Output Function Command 41	F972
COMMUNICATIONS	Communications Adjustments	Frequency Point Selection	F810
		Point 1 Setting	F811
		Point 1 Frequency	F812
		Point 2 Setting	F813
		Point 2 Frequency	F814
	Communications	RS485 2-Wire Baud Rate	F800
		RS485 2-Wire and 4-Wire Parity	F801
		ASD Number	F802
		RS485 2-Wire and 4-Wire Communications Time-Out	F803
		RS485 2-Wire and 4-Wire Communications Time-Out Action	F804

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
COMMUNICATIONS	Communications	RS485 2-Wire Send Wait Time	F805
		RS485 2-Wire ASD-to-ASD Communications	F806
		RS485 4-Wire Baud Rate	F820
		RS485 Send Wait Time	F825
		RS485 4-Wire ASD-to-ASD Communications	F826
		RS485 4-Wire Protocol (TSB/MODBUS)	F829
		Communication Option (DeviceNet/Profibus) Setting 1	F830
		Communication Option (DeviceNet/Profibus) Setting 2	F831
		Communication Option (DeviceNet/Profibus) Setting 3	F832
		Communication Option (DeviceNet/Profibus) Setting 4	F833
		Communication Option (DeviceNet/Profibus) Setting 5	F834
		Communication Option (DeviceNet/Profibus) Setting 6	F835
		Communication Option (DeviceNet/Profibus) Setting 7	F836
		Communication Option (DeviceNet/Profibus) Setting 8	F841
		Communication Option (DeviceNet/Profibus) Setting 9	F842
		Communication Option (DeviceNet/Profibus) Setting 10	F843
		Communication Option (DeviceNet/Profibus) Setting 11	F844
		Communication Option (DeviceNet/Profibus) Setting 12	F845
		Communication Option (DeviceNet/Profibus) Setting 13	F846
		Disconnection Detection Extended Time	F850
		ASD Disposition at Disconnection	F851
		Preset Speed Operation	F852
		Communication Option Station Address Monitor	F853
		Communication Option Speed Switch Monitor DeviceNet/CC-Link	F854
		Block Write Data 1	F870
		Block Write Data 2	F871
		Block Read Data 1	F875
		Block Read Data 2	F876
		Block Read Data 3	F877
		Block Read Data 4	F878

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
COMMUNICATIONS	Communications	Block Read Data 5	F879
		Free Notes	F880
		Network Option Reset Setting	F899
	Ethernet	IP	N/A
		Sub Net	
		Gateway	
		DHCP Mode	
		MAC ID	
PASSWORD AND LOCKOUT	Enter Password		N/A
	Change Password	Enter New Password	N/A
	Lockouts	Reset From Trip	N/A
		Local/Remote	
		Run/Stop from EOI	
		Frequency Change From EOI	
		Monitor Screen	
		Parameter Access	
		Parameter Write	

Direct Access Information

The ACE-tronics G9 ASD has the ability to allow the user direct access to the motor control functions. There are two ways in which the motor control parameters may be accessed for modification: Program ⇒ Direct Access ⇒ **Applicable Parameter Number** or Program ⇒ **Applicable Menu Path**. Both methods access the parameter via the **Program** mode. Once accessed, the parameter may be viewed or changed.

The **Program** mode allows the user to develop an application-specific motor-control profile. Motor control functions may be set to accommodate application-specific power and timing requirements.

The configurable parameters of the **Program** mode that have user-accessible **Parameter Numbers** are listed and described below. The parameters that do not have a Direct Access number and are accessible via the **Program** mode menu hierarchy only are listed and described on [pg. 57](#).

Note: The setup procedures included within this section may require a **Reset** before performing the procedure. Application-specific settings may then be performed. The pre-reset conditions may be saved (see [F007](#)).

Note: Communications setting changes will require that the power be removed and then re-applied for the changes to take effect.

Direct Access Parameters/Numbers

<p>Automatic Acceleration/Deceleration</p> <p>Program ⇒ Fundamental ⇒ Acc/Dec 1</p> <p>This parameter is used to enable automatic acceleration and deceleration rates in accordance with the applied load.</p> <p>The adjusted acceleration and deceleration times range from 12.5% to 800% of the programmed values for Acceleration Time 1 — UP/DOWN Frequency Accel Time (F009) and Deceleration Time 1 — UP/DOWN Frequency Decel Time (F010).</p> <p>Settings:</p> <ul style="list-style-type: none"> Manual Automatic ACC/DEC Automatic ACC Only <p>Note: The motor and the load must be connected prior to selecting Automatic Acceleration/Deceleration.</p>	<p>Direct Access Number — F000</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Manual</p> <p>Changeable During Run — No</p>
<p>Automatic Torque Boost</p> <p>Program ⇒ Fundamental ⇒ Motor Set 1</p> <p>This parameter allows the ASD to adjust the output torque in accordance with the applied load automatically. When enabled, an Autotune is performed — the motor should be connected before performing an Autotune.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Automatic Torque Boost + Autotuning Sensorless Vector Control + Autotuning 	<p>Direct Access Number — F001</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — No</p>

Command Mode

Program ⇒ Fundamental ⇒ Standard Mode Selection

The **Command Mode Selection** establishes the source of the command input for the ASD. **Command** inputs include **Run**, **Stop**, **Forward**, etc. The **Override** feature may supersede the **Command Mode Selection** setting (see [Command and Frequency Mode Control on pg. 47](#)).

Settings:

Terminal Board
EOI Keypad
RS485
Communication Option Board

Direct Access Number — F003Parameter Type — **Selection List**Factory Default — **Terminal Board**Changeable During Run — **No**

Frequency Mode 1

Program ⇒ Fundamental ⇒ Standard Mode Selection

The **Frequency Mode 1** setting establishes the source of the frequency-control input for the ASD. The **Frequency Mode 2** setting or the **Override** feature may supersede the **Frequency Mode 1** setting (see [Command and Frequency Mode Control on pg. 47](#) and [F200](#) for additional information on this feature).

Note: Only **bolded** items from the **Settings** list below may be placed in the **Override** mode.

Settings:

V/I
RR
RX
EOI Keypad
RS485
Communication Option Board
RX2 Option (AI1)
Option V/I
UP/DOWN Frequency
Pulse Input (Option)
Pulse Input (Motor CPU)
Binary/BCD Input (Option)

Direct Access Number — F004Parameter Type — **Selection List**Factory Default — **RR**Changeable During Run — **No**

FM Output Terminal Function

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **FM** analog output terminal. The **FM** output terminal produces an output current or voltage that is proportional to the magnitude of the function assigned to this terminal (select current or voltage at [F681](#)). The available assignments for this output terminal are listed in [Table 8 on pg. 240](#).

Note: To read **voltage** at this terminal connect a 100 – 500Ω resistor from the **FM** (+) terminal to the **CC** (-) terminal. Using a voltmeter read the voltage across the 100 – 500Ω resistor.

To read **current** at this terminal connect a 100 – 500Ω resistor from the **FM** (+) terminal through a series Ammeter to the **CC** (-) terminal.

The **FM** analog output has a maximum resolution of 1/1024 and a maximum load rating of 500 ohms.

FM Terminal Setup Parameters

- [F005](#) — FM Output Terminal Function
- [F006](#) — FM Output Terminal Adjustment
- [F681](#) — FM Voltage/Current Output Switching
- [F682](#) — FM Output Gradient Characteristic
- [F683](#) — FM Bias Adjustment

FM Output Terminal Adjustment

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to calibrate the **FM** analog output.

To calibrate the **FM** analog output, connect a meter (current or voltage) as described at [F005](#).

With the ASD running at a known value (e.g., output frequency), adjust this parameter until the assigned function produces the desired DC level output at the **FM** output terminal.

See [F005](#) for additional information on this setting.

Direct Access Number — F005

Parameter Type — **Selection List**

Factory Default — **Signed Speed Feedback (Realtime)**

Changeable During Run — **Yes**

Direct Access Number — F006

Parameter Type — **Numerical**

Factory Default — **493**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

Reset

Program ⇒ Utilities ⇒ Type Reset

This feature assists the user when performing fault analysis or by allowing a quick system setup change when required. Performing a **Type Reset** results in one of the following user-selected post-reset configurations.

Settings:

- None
- 50 Hz Setting
- 60 Hz Setting
- Reset to Factory Settings
- Clear Past Trips
- Clear Run Timer (Bearing Greaser)
- Initialize Typeform
- *Save User Settings
- Restore User Settings
- Clear Cumulative Fan Timer (FE79)
- Accel/Decel Time Setting 0.01 – 600.0 Seconds
- Accel/Decel Time Setting 0.1 – 6000.0 Seconds
- Update EOI Firmware
- Set EOI Memory to Default

***Note:** User settings that are stored in the memory of the **EOI** are not saved via the **Save User Settings** selection.*

Direct Access Number — F007

Parameter Type — **Selection List**

Factory Default — **None**

Changeable During Run — **No**

Forward/Reverse Run

Program ⇒ Fundamental ⇒ Standard Mode Selection

While operating in the **Local** mode, this parameter sets the direction of motor rotation.

From the **Frequency Command** screen press the **ESC** key. At the subsequent **EOI Command** screen select the **Direction** field and change the setting. Press the **Rotary Encoder** and the new setting will be in effect.

This setting will not override parameter **F311 (Forward/Reverse Disable)**.

If either direction is disabled via parameter **F311**, the disabled direction will not be recognized if commanded by the **EOI**. If both directions are disabled via parameter **F311**, the direction command from the **EOI** will determine the direction of the motor rotation.

Settings:

- Forward
- Reverse
- Switchable F/R by EOI (Forward)
- Switchable F/R by EOI (Reverse)

Direct Access Number — F008

Parameter Type — **Selection List**

Factory Default — **Forward**

Changeable During Run — **Yes**

Acceleration Time 1 — UP/DOWN Frequency Accel Time

Program ⇒ Fundamental ⇒ Acc/Dec 1

This is a dual-function parameter. The two functions are described below.

- 1) This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the **Maximum Frequency** for the **#1 Acceleration** profile.
- 2) This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the **Maximum Frequency** during the **UP/DOWN Frequency Functions**. See [F264](#) for additional information on the **UP/DOWN Frequency Functions**.

The Accel/Decel pattern may be set using [F502](#). This parameter may be further defined by the settings of [F506 – F509](#).

Note: *An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel**, **Stall**, and **Ridethrough** settings may lengthen the actual acceleration times.*

Acceleration

The acceleration rate of a motor is determined by several factors: applied power, applied load, and the physical properties of the motor (winding parameters, motor size, etc.). The ASD will control the first of these factors: input power. The settings of the ASD will control the frequency and amplitude of the applied voltage to the motor.

Under most operating conditions, as the output frequency of the ASD goes up so does the output voltage (linear acceleration). The ASD has the ability to modify the relationship between frequency and voltage automatically to produce smoother operation or increased (starting) torque (see [F502](#)).

Deceleration Time 1 — UP/DOWN Frequency Decel Time

Program ⇒ Fundamental ⇒ Acc/Dec 1

This is a dual-function parameter. The two functions are described below.

- 1) This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz for the **#1 Deceleration** profile.
- 2) This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz during the **UP/DOWN Frequency Functions**. See [F264](#) for additional information on the **UP/DOWN Frequency Functions**.

The Accel/Decel pattern may be set using [F502](#). This parameter may be further defined by the settings of [F506 – F509](#).

Note: *A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel**, **Stall**, and **Ridethrough** settings may lengthen the actual deceleration times.*

Direct Access Number — F009Parameter Type — **Numerical**Factory Default — **3.0**Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

Direct Access Number — F010Parameter Type — **Numerical**Factory Default — **1.5**Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

<p>Maximum Frequency</p> <p>Program ⇒ Fundamental ⇒ Frequency</p> <p>This setting determines the absolute maximum frequency that the ASD can output.</p> <p>Accel/Decel times are calculated based on the Maximum Frequency setting.</p> <p>The Maximum Frequency is not limited by this setting while operating in the Drooping Control mode (see F320 for additional information on this setting).</p> <p><i>Note:</i> This setting may not be lower than the Upper-Limit Frequency setting (F012).</p>	<p>Direct Access Number — F011</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 65.0</p> <p>Changeable During Run — No</p> <p>Minimum — 30.0</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<p>Upper-Limit Frequency</p> <p>Program ⇒ Fundamental ⇒ Frequency</p> <p>This parameter sets the highest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD may output frequencies higher than the Upper-Limit Frequency (but, lower than the Maximum Frequency) when operating in the PID Control mode, Torque Control mode, or the Vector Control modes (sensorless or feedback).</p> <p><i>Note:</i> This setting may not be higher than the Maximum Frequency (F011) setting.</p>	<p>Direct Access Number — F012</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Lower-Limit Frequency</p> <p>Program ⇒ Fundamental ⇒ Frequency</p> <p>This parameter sets the lowest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD will output frequencies lower than the Lower-Limit Frequency when accelerating to the lower limit or decelerating to a stop. Frequencies below the Lower Limit may also be output when operating in the PID Control mode, Torque Control mode, or the Vector Control modes (sensorless or feedback).</p>	<p>Direct Access Number — F013</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 13.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Base Frequency 1</p> <p>Program ⇒ Fundamental ⇒ Motor Set 1</p> <p>The Base Frequency 1 setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The Base Frequency Voltage 1 parameter is set at F409.</p> <p>For proper motor operation, the Base Frequency should be set for the nameplate frequency of the motor.</p>	<p>Direct Access Number — F014</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>

V/f Pattern

Program ⇒ Fundamental ⇒ Frequency

This function establishes the relationship between the output frequency and the output voltage.

Bolded selections use the motor tuning parameters of the ASD to properly configure the ASD for the motor being used. If **Load Reactors** or **Long Lead Filters** are used, or if the capacity of the ASD is greater than the motor, manual tuning of the motor parameters may be required for optimum performance.

Settings:

Constant Torque
 Voltage Decrease Curve
Automatic Torque Boost
Sensorless Vector Control (Speed)
Sensorless Vector Control (Speed/Torque Switching)
 V/f 5-Point Curve (Go to **F190** to configure the V/f 5-point settings)
 PM Drive (Permanent Magnet)
PG Feedback Vector Control (Speed)
PG Feedback Vector Control (Speed/Torque Switching)

Note: When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.

Direct Access Number — F015

Parameter Type — **Selection List**

Factory Default — **PG Feedback Vector Control (Speed/Torque Switching)**

Changeable During Run — **No**

Manual Torque Boost 1

Program ⇒ Fundamental ⇒ Motor Set 1

The **Manual Torque Boost 1** function is used to increase the low frequency torque for high-inertia loads by increasing the output voltage at frequencies below ½ of the **Base Frequency 1 (F014)** setting.

The value programmed as a boost percentage establishes an output voltage vs. output frequency relationship to be used to start the motor or to provide smoother operation.

Direct Access Number — F016

Parameter Type — **Numerical**


Factory Default — (ASD-Dependent)

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — %



Note: Setting an excessive **Torque Boost** level may cause nuisance tripping and mechanical stress to loads.

Motor Overload Protection Configuration

Program ⇒ Protection ⇒ Overload

This parameter is used to protect the motor from an over-current condition. The type of motor being used and the **Overload/Stall** setting is selected here to better match the application.

This parameter setting may extend the **Over-Voltage Stall** time settings.

This parameter may be affected by the setting of the **Power Running Stall Continuous Trip Detection Time** (F452).

Settings:

- Overload Trip without Stall
- Overload Trip with Stall
- No Overload without Stall
- Stall Only
- V/f Motor-Overload without Stall
- V/f Motor-Overload with Stall
- V/f Motor-No Overload without Stall
- V/f Motor-Stall Only

Direct Access Number — F017

Parameter Type — Selection List

Factory Default — Overload Trip Without Stall

Changeable During Run — Yes

Preset Speed 1

Program ⇒ Frequency ⇒ Preset Speeds

Up to fifteen (15) output frequency values that fall within the **Lower-Limit** and the **Upper-Limit** range may be programmed into the ASD and output as a **Preset Speed**. This parameter assigns an output frequency to binary number 0001 and is identified as **Preset Speed 1**. The binary number is applied to **I1 – I4** of the **ACE G9-120V-PCB** to output the **Preset Speed**.

Perform the following setup to allow the system to receive **Preset Speed** control input at the **I1 – I4** terminals:

1. Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.
2. Program ⇒ Terminal ⇒ Input Terminals ⇒ **I1** (set to **Preset Speed 1**; LSB of 4-bit count). Repeat for **I2 – I4** (MSB of 4-bit count) as **Preset Speed 2 – 4**, respectively (all Normally Open).
3. Program ⇒ Frequency ⇒ Preset Speeds ⇒ **Preset Speed 1** (set an output frequency as **Preset Speed 1**; repeat for **Preset Speeds 2 – 15** as required).
4. Program ⇒ Pattern Run ⇒ Operation Mode ⇒ Preset Speed Operation Mode ⇒ **Enabled/Disabled**.

Select **Enable** to use the direction, accel/decel, and torque settings of the **Preset Speed** being run. The torque settings used will be as defined in **F170 – F181** and as selected via the associated discrete input terminals **V/f Switching 1 and 2** in **Table 7** on pg. 236.

Select **Disabled** to use the speed setting only of the **Preset Speed** being run.

5. Place the system in the **Remote** mode (Local/Remote LED Off).
6. Provide a **Run** command (activate F and/or R).

Activate **I1** to run **Preset Speed 1** (120 VAC to I1 = 0001 binary).

With **I1 – I4** configured to output **Preset Speeds (F115 – F118)**, 0001 – 1111 may be applied to **I1 – I4** of the **ACE G9-120V-PCB** to run the associated **Preset Speed**. If bidirectional operation is required **F** and **R** must be activated.

With **I1** being the least significant bit of a binary count, the **I1 – I4** settings will produce the programmed speed settings as indicated in the **Preset Speed Truth Table** to the right.

Preset Speeds are also used in the **Pattern Run** mode.

Direct Access Number — **F018**

Parameter Type — **Numerical**

Factory Default — **60.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit (F013)**

Maximum — **Upper Limit (F012)**

Units — Hz

Preset Speed Truth Table

Preset	I4 MSB	I3	I2	I1 LSB	Output
1	0	0	0	1	F018
2	0	0	1	0	F019
3	0	0	1	1	F020
4	0	1	0	0	F021
5	0	1	0	1	F022
6	0	1	1	0	F023
7	0	1	1	1	F024
8	1	0	0	0	F287
9	1	0	0	1	F288
10	1	0	1	0	F289
11	1	0	1	1	F290
12	1	1	0	0	F291
13	1	1	0	1	F292
14	1	1	1	0	F293
15	1	1	1	1	F294
<i>Note: 1 = Terminal activated.</i>					

Preset Speed 2

Program ⇒ Frequency ⇒ Preset Speeds

This parameter assigns an output frequency to binary number 0010 and is identified as **Preset Speed 2**. The binary number is applied to **I1 – I4** of the **ACE G9-120V-PCB** to output the **Preset Speed** (see **F018** for additional information on this parameter).

Direct Access Number — **F019**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit (F013)**

Maximum — **Upper Limit (F012)**

Units — Hz

Preset Speed 3 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 0011 and is identified as Preset Speed 3 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F020 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 4 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 0100 and is identified as Preset Speed 4 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F021 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 5 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 0101 and is identified as Preset Speed 5 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F022 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 6 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 0110 and is identified as Preset Speed 6 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F023 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 7 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 0111 and is identified as Preset Speed 7 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F024 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz

Automatic Function Selection

Program ⇒ Utilities ⇒ Display Parameters

This parameter setting is used to configure multiple parameters with the setting of only one parameter. From the selection below multiple parameters may be set as indicated in the table.

Once set, the selected configuration is placed in effect and remains in effect until this parameter is changed or the individual settings are changed.

Set this parameter to **Disable** to set these parameters individually.

Note: After performing the desired selection the **EOI** display returns to **Disabled** though the selected function has been carried out (i.e., without this, if selection **1** is performed, **F004** and **F207** would hold the RR terminal setting regardless of attempts to change the settings individually).

Settings:

Disabled
RR
V/I
RR or V/I Switched via Terminal Board (ACE G9-120V-PCB)
Keypad Frequency/Terminal Board Command (ACE G9-120V-PCB)
Keypad Frequency and Command

Direct Access Number — **F040**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

		User Settings					
Related Params	Default Settings	0-Disable	1-RR	2-V/I	3-RR or V/I via TB	4-Keypad/ Freq. CMD/TB	5-Keypad Freq/CMD
Command Mode F003	Terminal Board	N/C				Terminal Board	*Keypad
Frequency Mode 1 F004	RR	N/C	RR	N/C	RR	*Keypad	
I3 Terminal F117	Preset Speed 3	N/C			Freq. Ref. Priority	N/C	
Freq. Priority F200	Terminal Board	N/C	Terminal Board				
V/I Setup F201	0.0%	N/C		20.0%		N/C	
Frequency Mode 2 F207	V/I	N/C	RR	V/I		*Keypad	

N/C = No Change — the setting remains as it was before setting parameter F040.

Note: *Go to **F003** and/or **F004** and select **EOI Keypad** to use the **EOI** for control.

Low-Speed Signal Output Frequency Program ⇒ Terminal ⇒ Reach The Low-Speed Signal Output Frequency parameter sets a frequency threshold that activates the assigned output terminal for the duration that the ASD output is equal to or above this setting (see Table 10 on pg. 242 for the available output assignments).	Direct Access Number — F100 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Speed Reach Frequency Program ⇒ Terminal ⇒ Reach The Speed Reach Frequency sets a frequency threshold that, when reached or is within the bandwidth specified by parameter F102 , activates the assigned output terminal for the duration that the ASD output is within the bandwidth specified (see Table 10 on pg. 242 for the available output assignments). This setting is also a permissive when using the Express Speed function.	Direct Access Number — F101 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Speed Reach Detection Band Program ⇒ Terminal ⇒ Reach This parameter sets the bandwidth of the Speed Reach Frequency (F101) setting.	Direct Access Number — F102 Parameter Type — Numerical Factory Default — 2.50 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Input Terminal Priority Program ⇒ Terminal ⇒ Input Special Functions This parameter is used to allow the Jog and DC Injection Braking input signals to control the ASD when received via the ACE G9-120V-PCB even though the system is in the Local mode. With this parameter enabled, a Jog command or a DC Injection Braking command received from the ACE G9-120V-PCB will receive priority over commands from the EOI . See F260 for additional information on using the Jog function. See F250 – F252 for additional information on DC Injection Braking . Settings: Disabled Enabled	Direct Access Number — F106 Parameter Type — Selection List Factory Default — Disabled Changeable During Run — No

16-Bit Binary/BCD Input

Program ⇒ Terminal ⇒ Input Special Functions

The extended terminal function is used with the **Expansion IO Card Option** (P/N ETB004Z).

This parameter defines the format of the binary or BCD data when using the option card.

Note: *The **Expansion IO Card Option 2** option board is required to use this terminal.*

See the **Expansion IO Card Option 1 Instruction Manual** (P/N 58685) for additional information on the function of this terminal.

Settings:

- None
- 12-Bit Binary
- 16-Bit Binary
- 3-Digit BCD
- 4-Digit BCD
- Inverted 12-Bit Binary
- Inverted 16-Bit Binary
- Inverted 3-Digit BCD
- Inverted 4-Digit BCD

Selections using 16-bit binary or 4-digit BCD will require the configuration of terminals I1-I4 on the **ACE G9-120V-PCB** as binary bits 0 – 3 (F115 – F118). The **Frequency Mode 1** (F004) parameter must be set to **Binary/BCD**.

For proper scaling of the binary or BCD input, parameters F228 – F231 must be configured.

Direct Access Number — F107

Parameter Type — Selection List

Factory Default — None

Changeable During Run — No

Option V/I Terminal Voltage/Current Selection

Program ⇒ Frequency ⇒ V/I

This parameter is used to set the **AI2** input terminal to receive either current or voltage as a control signal.

Note: *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Settings:

- Voltage Input
- Current Input

Direct Access Number — F109

Parameter Type — Selection List

Factory Default — Voltage Input

Changeable During Run — No

Always ON Terminal Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the virtual discrete input terminal ON . As a virtual terminal, the ON control terminal exists only in memory and is considered to always be in its True (activated) state. It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations. This parameter sets the programmable ON terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 . This terminal is set to ST (Standby) to allow for ready-to-run operation and allows for the use of the discrete input terminals for other functions.	Direct Access Number — F110 Parameter Type — Selection List Factory Default — ST Changeable During Run — No
Input Terminal 1 (F) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the F discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable F terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F111 Parameter Type — Selection List Factory Default — Forward Changeable During Run — No
Input Terminal 2 (R) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the R discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable R terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F112 Parameter Type — Selection List Factory Default — Reverse Changeable During Run — No
Input Terminal 3 (I1) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the I1 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable I1 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F113 Parameter Type — Selection List Factory Default — Preset Speed 1 Changeable During Run — No
Input Terminal 4 (I2) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the I2 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable I2 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F114 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No

Input Terminal 5 (I3) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the I3 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable I3 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F115 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No
Input Terminal 6 (I4) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the I4 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable I4 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F116 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No
Input Terminal 7 (I5) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the I5 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable I5 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F117 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No
Input Terminal 8 (I6) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the I6 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable I6 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F118 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No
Input Terminal 9 (LI1) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the LI1 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable LI1 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 . Note: <i>The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.</i> See the Expansion IO Card Option 1 Instruction Manual (P/N 58685) for additional information on the function of this terminal.	Direct Access Number — F119 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No

Input Terminal 10 (LI2) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI2** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI2** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F120Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

Input Terminal 11 (LI3) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI3** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI3** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F121Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

Input Terminal 12 (LI4) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI4** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI4** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F122Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

Input Terminal 13 (LI5) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI5** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI5** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the *Expansion IO Card Option 2 Instruction Manual* (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F123Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

Input Terminal 14 (LI6) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI6** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI6** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the *Expansion IO Card Option 2 Instruction Manual* (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F124Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

Input Terminal 15 (LI7) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI7** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI7** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the *Expansion IO Card Option 2 Instruction Manual* (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F125Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

Input Terminal 16 (LI8) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI8** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI8** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the *Expansion IO Card Option 2 Instruction Manual* (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F126

Parameter Type — Selection List

Factory Default — Unassigned

Changeable During Run — No

Output Terminal 1 (OUT1) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT1** discrete output terminals **OUT1-A** and **OUT1-C**.

The **OUT1-A** to **OUT1-C** output terminals change states (open or close) as a function of a user-selected event. See [Table 10 on pg. 242](#) for listing the possible assignments for the **OUT1** terminals.

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F130

Parameter Type — Selection List

Factory Default — Brake Failure

Changeable During Run — No

Output Terminal 2 (OUT2) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT2** discrete output terminals **OUT2-A** and **OUT2-C**.

The **OUT2-A** to **OUT2-C** output terminals change states (open or close) as a function of a user-selected event. See [Table 10 on pg. 242](#) for listing the possible assignments for the **OUT2** terminals.

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F131

Parameter Type — Selection List

Factory Default — Brake Release

Changeable During Run — No

Output Terminal 3 (BRAKE) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **BRAKE** output terminals (A, B, and C) to one of the functions listed in [Table 10 on pg. 242](#).

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.


BRAKE Relay is shown in the de-energized state.

Direct Access Number — F132

Parameter Type — Selection List

Factory Default — Brake Release

Changeable During Run — No



Output Terminal 4 (OUT3) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT3** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT3** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: *The **Expansion IO Card Option 1** option board (P/N ETB003Z) is required to use this terminal.*

See the **Expansion IO Card Option 1 Instruction Manual** (P/N 58685) for additional information on the function of this terminal.

Output Terminal 5 (OUT4) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT4** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT4** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: *The **Expansion IO Card Option 1** option board (P/N ETB003Z) is required to use this terminal.*

See the **Expansion IO Card Option 1 Instruction Manual** (P/N 58685) for additional information on the function of this terminal.

Output Terminal 6 (R1) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **R1** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **R1** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: *The **Expansion IO Card Option 1** option board (P/N ETB003Z) is required to use this terminal.*

See the **Expansion IO Card Option 1 Instruction Manual** (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F133Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

Direct Access Number — F134Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

Direct Access Number — F135Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

Output Terminal 7 (OUT5) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT5** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT5** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F136Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

Output Terminal 8 (OUT6) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT6** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT6** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F137Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

Output Terminal 9 (R2) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **R2** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **R2** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*


See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F138Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

Input Terminal 1 (F) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **F** terminal input by the programmed value.



The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F140Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 2 (R) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **R** terminal input by the programmed value (see waveforms at [F140](#)).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F141Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 3 (I1) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **I1** terminal input by the programmed value (see waveforms at [F140](#)).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F142Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 4 (I2) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **I2** terminal input by the programmed value (see waveforms at [F140](#)).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F143Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 5 – 12 Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **5 – 12** terminal inputs by the programmed value (see waveforms at [F140](#)).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F144Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 13 – 20 Response Time Program ⇒ Terminal ⇒ Input Terminal Delays This parameter delays the response of the ASD to any change in the 13 – 20 terminal inputs by the programmed value (see waveforms at F140). The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.	Direct Access Number — F145 Parameter Type — Numerical Factory Default — 8.0 Changeable During Run — No Minimum — 2.0 Maximum — 200.0 Units — mS
Input Terminal 17 (B12) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the B12 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable B12 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F164 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No
Input Terminal 18 (B13) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the B13 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable B13 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F165 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No
Input Terminal 19 (B14) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the B14 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable B14 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F166 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No
Input Terminal 20 (B15) Function Program ⇒ Terminal ⇒ Input Terminals This parameter is used to set the functionality of the B15 discrete input terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable B15 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236 .	Direct Access Number — F167 Parameter Type — Selection List Factory Default — Unassigned Changeable During Run — No

Output Terminal 10 (R3) Function Program ⇒ Terminal ⇒ Output Terminals This parameter is used to set the functionality of the R3 discrete output terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable R3 terminal to any one of the user-selectable functions listed in Table 10 on pg. 242 .	Direct Access Number — F168 Parameter Type — Selection List Factory Default — Off Changeable During Run — No
Output Terminal 11 (R4) Function Program ⇒ Terminal ⇒ Output Terminals This parameter is used to set the functionality of the R4 discrete output terminal. In addition, this input terminal must be specified as Normally Open or Normally Closed . This setting assigns the function of the programmable R4 terminal to any one of the user-selectable functions listed in Table 10 on pg. 242 .	Direct Access Number — F169 Parameter Type — Selection List Factory Default — Off Changeable During Run — No
Base Frequency 2 Program ⇒ Motor ⇒ Motor Set 2 The Base Frequency 2 setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The Base Frequency Voltage 2 parameter is set at F171 . This parameter is used only when the parameters for motor set 2 are configured and selected. Motor set 2 may be selected by a properly configured input terminal (see Table 7 on pg. 236). For proper motor operation, the Base Frequency should be set for the nameplate frequency of the motor.	Direct Access Number — F170 Parameter Type — Numerical Factory Default — 60.0 Changeable During Run — Yes Minimum — 25.0 Maximum — 299.0 Units — Hz
Base Frequency Voltage 2 Program ⇒ Motor ⇒ Motor Set 2 The Base Frequency Voltage 2 setting is the Motor #2 output voltage at the Base Frequency (F170). Regardless of the programmed value, the output voltage cannot be higher than the input voltage. The actual output voltage will be influenced by the input voltage of the ASD and the Supply Voltage Compensation setting (F307). This parameter is used only when the parameters for motor set 2 are configured and selected. Motor set 2 may be selected by a properly configured input terminal (see Table 7 on pg. 236).	Direct Access Number — F171 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — Yes Minimum — 50.0 Maximum — 660.0 Units — Volts
Manual Torque Boost 2 Program ⇒ Motor ⇒ Motor Set 2 The Manual Torque Boost 2 function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the Base Frequency 2 setting (F170). See parameter F016 (Manual Torque Boost 1) for an explanation of torque boost. This parameter is used only when the parameters for motor set 2 are configured and selected. Motor set 2 may be selected by a properly configured input terminal (see Table 7 on pg. 236).	Direct Access Number — F172 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — Yes Minimum — 0.0 Maximum — 30.0 Units — %

Motor Overload Protection Level 2

Program ⇒ Motor ⇒ Motor Set 2

The **Motor Overload Protection Level 2** parameter specifies the motor overload current level for motor set 2. This value is entered as either a percentage of the full-load rating of the ASD or as the FLA of the motor.

The unit of measurement for this parameter may be set to **Amps** (A/V) or it may be set as a percentage of the ASD rating. The nameplate FLA of the motor may be entered directly when **Amps** is selected as the unit of measurement (see [F701](#) to change the display unit).

The **Motor 2 Overload Protection Level** setting will be displayed in **Amps** if the **EOI** display units are set to **A/V** rather than **%**.

Direct Access Number — F173Parameter Type — **Numerical**Factory Default — **100**Changeable During Run — **Yes**

Minimum — 10

Maximum — 100

Units — %

Base Frequency 3

Program ⇒ Motor ⇒ Motor Set 3

The **Base Frequency 3** setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The **Base Frequency Voltage 3** parameter is set at [F175](#).

This parameter is used only when the parameters for motor set 3 are configured and selected. Motor set 3 may be selected by a properly configured input terminal (see [Table 7 on pg. 236](#)).

For proper motor operation, the **Base Frequency** should be set for the nameplate frequency of the motor.

Direct Access Number — F174Parameter Type — **Numerical**Factory Default — **60.0**Changeable During Run — **Yes**

Minimum — 25.0

Maximum — 299.0

Units — Hz

Base Frequency Voltage 3

Program ⇒ Motor ⇒ Motor Set 3

The **Base Frequency Voltage 3** setting is the **Motor #3** output voltage at the **Base Frequency** ([F174](#)). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.

The actual output voltage will be influenced by the input voltage of the ASD and the **Supply Voltage Compensation** setting ([F307](#)).

This parameter is used only when the parameters for motor set 3 are configured and selected. Motor set 3 may be selected by a properly configured input terminal (see [Table 7 on pg. 236](#)).

Direct Access Number — F175Parameter Type — **Numerical**

Factory Default — (ASD-Dependent)

Changeable During Run — **Yes**

Minimum — 50.0

Maximum — 660.0

Units — Volts

Manual Torque Boost 3

Program ⇒ Motor ⇒ Motor Set 3

The **Manual Torque Boost 3** function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the **Base Frequency 3** setting ([F174](#)).

See parameter [F016](#) (**Manual Torque Boost 1**) for an explanation of torque boost.

This parameter is used only when the parameters for motor set 3 are configured and selected. Motor set 3 may be selected by a properly configured input terminal (see [Table 7 on pg. 236](#)).

Direct Access Number — F176Parameter Type — **Numerical**

Factory Default — (ASD-Dependent)

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — %

<p>Motor Overload Protection Level 3</p> <p>Program ⇒ Motor ⇒ Motor Set 3</p> <p>The Motor Overload Protection Level 3 parameter specifies the motor overload current level for motor set 3. This value is entered as either a percentage of the full-load rating of the ASD or as the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to Amps (A/V) or it may be set as a percentage of the ASD rating. The nameplate FLA of the motor may be entered directly when Amps is selected as the unit of measurement (see F701 to change the display unit).</p> <p>The Motor Overload Protection Level 3 setting will be displayed in Amps if the EOI display units are set to A/V rather than %.</p>	<p>Direct Access Number — F177</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 10</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>Base Frequency 4</p> <p>Program ⇒ Motor ⇒ Motor Set 4</p> <p>The Base Frequency 4 setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The Base Frequency Voltage 4 parameter is set at F179.</p> <p>This parameter is used only when the parameters for motor set 4 are configured and selected. Motor set 4 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p> <p>For proper motor operation, the Base Frequency should be set for the nameplate frequency of the motor.</p>	<p>Direct Access Number — F178</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 25.00</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<p>Base Frequency Voltage 4</p> <p>Program ⇒ Motor ⇒ Motor Set 4</p> <p>The Base Frequency Voltage 4 is the Motor 4 output voltage at the Base Frequency (F178). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the Supply Voltage Compensation setting (F307).</p> <p>This parameter is used only when the parameters for motor set 4 are configured and selected. Motor set 4 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p>	<p>Direct Access Number — F179</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 50.0</p> <p>Maximum — 660.0</p> <p>Units — Volts</p>
<p>Manual Torque Boost 4</p> <p>Program ⇒ Motor ⇒ Motor Set 4</p> <p>The Manual Torque Boost 4 function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the Base Frequency 4 setting (F178).</p> <p>See parameter F016 (Manual Torque Boost 1) for an explanation of torque boost.</p> <p>This parameter is used only when the parameters for motor set 4 are configured and selected. Motor set 4 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p>	<p>Direct Access Number — F180</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 30.0</p> <p>Units — %</p>

Overload Protection Level 4

Program ⇒ Motor ⇒ Motor Set 4

The **Motor 4 Overload Protection Level** parameter specifies the motor overload current level for motor set 4. This value is entered as either a percentage of the full-load rating of the ASD or as the FLA of the motor.

The unit of measurement for this parameter may be set to **Amps** (A/V) or it may be set as a percentage of the ASD rating. The nameplate FLA of the motor may be entered directly when **Amps** is selected as the unit of measurement (see F701 to change the display unit).

The **Motor 4 Overload Protection Level** setting will be displayed in **Amps** if the **EOI** display units are set to **A/V** rather than **%**.

Direct Access Number — F181

Parameter Type — Numerical

Factory Default — 100.0

Changeable During Run — Yes

Minimum — 10

Maximum — 100

Units — %

V/f 5-Point Setting Frequency 1

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Frequency 1** setting establishes the frequency that is to be associated with the voltage setting of F191 (V/f 5-Point Setting Voltage 1).

The **V/f 5-Point** settings define a custom volts per hertz relationship for the startup output of the ASD.

To enable this function, set the **V/f Pattern** (F015) selection to the **V/f 5-Point Curve** setting.

Custom **V/f Curves** may be useful in starting high inertia loads such as rotary drum vacuum filters.

Direct Access Number — F190

Parameter Type — Numerical


Factory Default — 0.00

Changeable During Run — No

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz



V/f 5-Point Setting Voltage 1

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Voltage 1** establishes the output voltage level that is to be associated with the frequency setting of **F190** (V/f 5-Point Setting Frequency 1).


The **F701** parameter setting will determine if the on-screen selection for this parameter appears in the form of a voltage (V) or as a percentage (%) of the ASD rating.

If using **Voltage** as a unit of measure and with no voltage correction (**F307** Disabled), the limit of the on-screen display value for this parameter is 200 volts for the 230-volt ASD and 400 Volts for the 460-volt ASD.

The actual output voltage is scaled to the maximum **EOI** display values (e.g., a 100-volt **EOI** display corresponds to a 115-volt actual output for the 230-volt ASD — ½ of the full display range).

If using **%** as a unit of measure and with no voltage correction (**F307** Disabled), the ASD output voltage will be the percentage setting times 230 for the 230-volt unit (or % times 460 Volts for the 460-volt unit).

See **F190** for additional information on this setting.



Direct Access Number — **F191**

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **No**

Minimum — 0.0

Maximum — 100.0

Units — V or % (**F701**)

V/f 5-Point Setting Frequency 2

Program ⇒ Special ⇒ V/f 5-Point Setting

The **Custom V/f 5-Point Setting Frequency 2** sets the frequency to be associated with the voltage setting of parameter **F193** (V/f 5-Point Setting Voltage 2).

See **F190** and **F191** for additional information on this setting.

Direct Access Number — **F192**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **No**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

V/f 5-Point Setting Voltage 2 Program ⇒ Special ⇒ V/f 5-Point Setting The V/f 5-Point Setting Voltage 2 establishes the output voltage level that is to be associated with the frequency setting of F192 (V/f 5-Point Setting Frequency 2). The F701 parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %. See F190 and F191 for additional information on this setting.	Direct Access Number — F193 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — No Minimum — 0.0 Maximum — 100.0 Units — V or % (F701)
V/f 5-Point Setting Frequency 3 Program ⇒ Special ⇒ V/f 5-Point Setting The Custom V/f 5-Point Setting Frequency 3 sets the frequency to be associated with the voltage setting of parameter F195 (V/f 5-Point Setting Voltage 3). See F190 and F191 for additional information on this setting.	Direct Access Number — F194 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — No Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
V/f 5-Point Setting Voltage 3 Program ⇒ Special ⇒ V/f 5-Point Setting The V/f 5-Point Setting Voltage 3 establishes the output voltage level that is to be associated with the frequency setting of F194 (V/f 5-Point Setting Frequency 3). The F701 parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %. See F190 and F191 for additional information on this setting.	Direct Access Number — F195 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — No Minimum — 0.0 Maximum — 100.0 Units — V or % (F701)
V/f 5-Point Setting Frequency 4 Program ⇒ Special ⇒ V/f 5-Point Setting The Custom V/f 5-Point Setting Frequency 4 sets the frequency to be associated with the voltage setting of parameter F197 (V/f 5-Point Setting Voltage 4). See F190 and F191 for additional information on this setting.	Direct Access Number — F196 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — No Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
V/f 5-Point Setting Voltage 4 Program ⇒ Special ⇒ V/f 5-Point Setting The V/f 5-Point Setting Voltage 4 establishes the output voltage level that is to be associated with the frequency setting of F196 (V/f 5-Point Setting Frequency 4). The F701 parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %. See F190 and F191 for additional information on this setting.	Direct Access Number — F197 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — No Minimum — 0.0 Maximum — 100.0 Units — V or % (F701)

V/f 5-Point Setting Frequency 5

Program ⇒ Special ⇒ V/f 5-Point Setting

The **Custom V/f 5-Point Setting Frequency 5** sets the frequency to be associated with the voltage setting of parameter **F199** (V/f 5-Point Setting Voltage 5).

See **F190** and **F191** for additional information on this setting.

Direct Access Number — F198Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **No**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

V/f 5-Point Setting Voltage 5

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Voltage 5** establishes the output voltage level that is to be associated with the frequency setting of **F198** (V/f 5-Point Setting Frequency 5).

The **F701** parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating.

The default setting is %.

See **F190** and **F191** for additional information on this setting.

Direct Access Number — F199Parameter Type — **Numerical**Factory Default — **0.0**Changeable During Run — **No**

Minimum — 0.0

Maximum — 100.0

Units — V or % (**F701**)**Frequency Priority Selection**

Program ⇒ Fundamental ⇒ Standard Mode Selection

Either **Frequency Mode 1** or **Frequency Mode 2** may control the output frequency of the ASD. This parameter determines which of the two will control the output frequency and the conditions in which control will be switched from one to the other.

Note: *Frequency Mode is abbreviated as FMODE.*

Settings:

FMODE changed by Terminal Board (ACE G9-120V-PCB)


FMODE (**F208**)

The **Frequency Mode 1** or **Frequency Mode 2** selection specifies the source of the input frequency command signal. These selections are performed at **F004** and **F207**, respectively.

If **FMODE changed by Terminal Board** is selected here, the ASD will follow the control of the discrete input terminal assigned the function of **Frequency Priority**. The discrete terminal **Frequency Priority** will toggle control to and from **Frequency Mode 1** and **Frequency Mode 2** with each activation/deactivation.

If **FMODE (F208)** is selected here, the ASD will follow the control of the **Frequency Mode 1** setting for the duration that the commanded frequency of the **Frequency Mode 1** setting is greater than the setting of **F208**.

If the commanded frequency of the **Frequency Mode 1** setting is less than or equal to the setting of **F208** the ASD will follow the setting of **Frequency Mode 2**.

Direct Access Number — F200Parameter Type — **Selection List**Factory Default — **FMODE (changed by TB)**Changeable During Run — **Yes**

If the frequency command of Frequency Mode 1 is greater than the F208 setting, Frequency Mode 1 has priority over Frequency Mode 2. If the frequency command of Frequency Mode 1 is equal to or less than the F208 setting, Frequency Mode 2 has priority.

V/I Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the isolated **V/I** input terminal when the **V/I** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **V/I** input level that is associated with the **V/I Input Point 1 Frequency (F202)** setting when operating in the **Speed** control mode or is associated with the **V/I Input Point 1 Rate (F205)** setting when operating in the **Torque Control** mode.

Note: See note on pg. 55 for additional information on the **V/I** terminal.

V/I Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **V/I** input terminal:

- Set **SW2** of the **ACE G9-120V-PCB** to **Voltage** or **Current** (see [Figure 8](#) on pg. 24).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **V/I**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **V/I** input terminal:

- Set **V/I Input Point 1 Frequency (F202)**.
- Set **V/I Input Point 1 Setting (F201)** — the input analog signal level that corresponds to the frequency setting at **V/I Input Point 1 Frequency**.
- Set **V/I Input Point 2 Frequency (F204)**.
- Set **V/I Input Point 2 Setting (F203)** — the input analog signal level that corresponds to the frequency setting at **V/I Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the **V/I** input voltage or current changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter value is entered as 0% to 100% of the **V/I** input signal range.

The **V/I** input is commonly used for a 4 – 20 mA current loop signal where 4 mA equals 20% of a 20 mA signal. Set this parameter to 20% for 4 – 20 mA current loop signal applications.

Note: When using the isolated **V/I** input terminal the **IICC** terminal must be used as the return (negative) connection.

Direct Access Number — **F201**

Parameter Type — **Numerical**

Factory Default — **0**


Changeable During Run — **Yes**

Minimum — **0**

Maximum — **100**

Units — **%**

Frequency Settings



V/I Input Point 1 Frequency Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to set the gain and bias of the V/I input terminal when the V/I terminal is used as the control input while operating in the Speed Control mode. This parameter sets V/I Input Point 1 Frequency (F202) and is the frequency that is associated with the setting of V/I Input Point 1 Setting (F201) when operating in the Speed Control mode. See V/I Input Point 1 Setting (F201) for additional information on this setting.	Direct Access Number — F202 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
V/I Input Point 2 Setting Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to set the gain and bias of the V/I input terminal when the V/I terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This parameter sets the V/I input level that is associated with V/I Input Point 2 Frequency (F204) when operating in the Speed control mode or is associated with the V/I Input Point 1 Rate (F205) when operating in the Torque Control mode. This value is entered as 0% to 100% of the V/I input signal range. See V/I Input Point 1 Setting (F201) for additional information on this setting when used for Speed control. See V/I Input Point 1 Rate (F205) for additional information on this setting when used for Torque Control .	Direct Access Number — F203 Parameter Type — Numerical Factory Default — 100 Changeable During Run — Yes Minimum — 0 Maximum — 100 Units — %
V/I Input Point 2 Frequency Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to set the gain and bias of the V/I input terminal when the V/I terminal is used as the control input while operating in the Speed Control mode. This parameter sets V/I Input Point 2 Frequency and is the frequency that is associated with the setting of V/I Input Point 2 Setting (F203) when operating in the Speed Control mode. See V/I Input Point 1 Setting (F201) for additional information on this setting.	Direct Access Number — F204 Parameter Type — Numerical Factory Default — 60.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz

V/I Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the isolated **V/I** input terminal when the **V/I** terminal is used as the control input while operating in the **Torque Control** mode.

V/I Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **V/I** input terminal:

- Set **SW2** of the **ACE G9-120V-PCB** to **Voltage** or **Current** (see [Figure 8 on pg. 24](#)).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **V/I**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **V/I** input terminal:

- Set **V/I Input Point 1 Rate (F205)**.
- Set **V/I Input Point 1 Setting (F201)** — the input analog signal level that corresponds to the torque setting at **V/I Input Point 1 Rate**.
- Set **V/I Input Point 2 Rate (F206)**.
- Set **V/I Input Point 2 Setting (F203)** — the input analog signal level that corresponds to the torque setting at **V/I Input Point 2 Rate**.
- Provide a **Run** command (F and/or R).

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **V/I** input level.

Once set, as the **V/I** input voltage changes or the **V/I** current changes, the output torque of the ASD will vary in accordance with the above settings.

This parameter sets **V/I Input Point 1 Rate** and is the output torque value that is associated with the setting of **V/I Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

Note: When using the isolated **V/I** input terminal the **IICC** terminal must be used as the return (negative) connection.

Direct Access Number — **F205**

Parameter Type — **Numerical**

Factory Default — **0.00**


Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %

Torque Settings



V/I Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **V/I** input terminal when the **V/I** terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **V/I** input level.

This parameter sets **V/I Input Point 2 Rate** and is the output torque value that is associated with the setting of **V/I Input Point 2 Setting (F203)** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

See **V/I Input Point 1 Rate (F205)** for additional information on this setting.

Direct Access Number — F206

Parameter Type — **Numerical**

Factory Default — **100.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %

Frequency Mode 2

Program ⇒ Fundamental ⇒ Standard Mode Selection

This parameter is used to set the source of the frequency command signal to be used as **Frequency Mode 2** in the event that **Frequency Mode 1** is disabled or if **Frequency Mode 2** is set up as the primary control parameter.

See **F004** and **F200** for additional information on this setting.

Settings:

V/I
RR
RX
EOI Keypad
RS485
Communication Option Board
RX2 Option (AI1)
Option V/I
UP/DOWN Frequency (ACE G9-120V-PCB)
Pulse Input (Option)
Pulse Input (Motor CPU)
Binary/BCD Input (Option)

Direct Access Number — F207

Parameter Type — **Selection List**

Factory Default — **V/I**

Changeable During Run — **Yes**

Frequency Mode Priority Switching Frequency

Program ⇒ Fundamental ⇒ Standard Mode Selection

This parameter establishes a threshold frequency that will be used as a reference when determining when to switch the output frequency control source from the **Frequency Mode 1** setting to the **Frequency Mode 2** setting.

See **F200** for additional information on this setting.

Direct Access Number — F208

Parameter Type — **Numerical**

Factory Default — **0.10**

Changeable During Run — **Yes**

Minimum — 0.10

Maximum — **Max. Freq. (F011)**

Units — Hz

Analog Input Filter

Program ⇒ Frequency ⇒ Analog Filter

Analog filtering is applied after the analog reference signal is converted to a digital signal. The type of filtering used is **Rolling Average** over time.

Settings:

- None (1 mS)
- Small (8 mS)
- Medium (16 mS)
- Large (32 mS)
- Huge (64 mS)

The analog input signal is sampled and converted to a digital signal. With no filtering applied, the resulting digital value is scaled for use by the microprocessor of the ASD.

If the filtering selection **Small** is selected, the ASD averages the last **8 mS** of sampled signal and converted (digital) values. The rolling average is updated (every 4 μ S) and scaled for use by the microprocessor.

This holds true for the **Medium**, **Large**, and **Huge** selections providing a larger sample to produce the average for use by the microprocessor.

False responses to electrical noise are eliminated with no loss in bandwidth because the value used by the ASD is the average value of several samples.

Direct Access Number — F209

Parameter Type — Selection List

Factory Default — None

Changeable During Run — Yes

RR Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RR** input level that is associated with the **RR Input Point 1 Frequency** setting when operating in the **Speed** control mode or is associated with the **RR Input Point 1 Rate** (F214) setting when operating in the **Torque Control** mode.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RR** input terminal:

- Set **RR Input Point 1 Frequency** (F211).
- Set **RR Input Point 1 Setting** (F210) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 1 Frequency**.
- Set **RR Input Point 2 Frequency** (F213).
- Set **RR Input Point 2 Setting** (F212) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 2 Frequency**.

RR Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RR** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RR**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.
- Provide a **Run** command (F and/or R).

Once set, as the **RR** input voltage changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter value is entered as 0% to 100% of the **RR** input signal range.

Direct Access Number — F210

Parameter Type — Numerical

Factory Default — 0


Changeable During Run — Yes

Minimum — 0

Maximum — 100

Units — %

Frequency Settings



RR Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RR Input Point 1 Frequency** and is the frequency that is associated with the setting of **RR Input Point 1 Setting** (F210) when operating in the **Speed Control** mode.

See **RR Input Point 1 Setting** (F210) for additional information on this setting.

Direct Access Number — F211

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz

RR Input Point 2 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RR** input level that is associated with **RR Input Point 2 Frequency (F213)** when operating in the **Speed** control mode or is associated with the **RR Input Point 1 Rate (F214)** when operating in the **Torque Control** mode.

This value is entered as 0% to 100% of the **RR** input signal range.

See **RR Input Point 1 Setting (F210)** for additional information on this setting when used for **Speed** control.

See **RR Input Point 1 Rate (F214)** for additional information on this setting when used for **Torque Control**.

RR Input Point 2 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RR Input Point 2 Frequency** and is the frequency that is associated with the setting of **RR Input Point 2 Setting (F212)** when operating in the **Speed Control** mode.

See **RR Input Point 1 Setting (F210)** for additional information on this setting.

Direct Access Number — F212

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %

Direct Access Number — F213

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

RR Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Torque Control** mode.

RR Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **RR** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RR**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **RR** input terminal:

- Set **RR Input Point 1 Rate** (F214).
- Set **RR Input Point 1 Setting** (F210) — the input analog signal level that corresponds to the torque setting at **RR Input Point 1 Rate**.
- Set **RR Input Point 2 Rate** (F215).
- Set **RR Input Point 2 Setting** (F212) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 2 Rate**.
- Provide a **Run** command (F and/or R).

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RR** input level.

Once set, as the **RR** input voltage changes, the output torque of the ASD will vary in accordance with the above settings.

This parameter sets **RR Input Point 1 Rate** and is the output torque value that is associated with the setting of **RR Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

Direct Access Number — **F214**

Parameter Type — **Numerical**


Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %



RR Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RR** input level.

This parameter sets **RR Input Point 2 Rate** and is the output torque value that is associated with the setting of **RR Input Point 2 Setting** (F212) when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

See **RR Input Point 1 Rate** (F214) for additional information on this setting.

Direct Access Number — **F215**

Parameter Type — **Numerical**

Factory Default — **100.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %

RX Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RX** input level that is associated with **RX Input Point 1 Frequency** when operating in the **Speed Control** mode or is associated with the **RX Input Point 1 Rate (F220)** when operating in the **Torque Control** mode.

RX Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RX** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RX**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RX** input terminal:

- Set **RX Input Point 1 Frequency (F217)**.
- Set **RX Input Point 1 Setting (F216)** — the input analog signal level that corresponds to the speed setting at **RX Input Point 1 Frequency**.
- Set **RX Input Point 2 Frequency (F219)**.
- Set **RX Input Point 2 Setting (F218)** — the input analog signal level that corresponds to the speed setting at **RX Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the **RX** input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter value is entered as -100% to +100% of the **RX** input signal range.

See parameter [F474](#) and [F475](#) for information on fine-tuning this terminal response.

Direct Access Number — **F216**

Parameter Type — **Numerical**


Factory Default — **0**

Changeable During Run — **Yes**

Minimum — -100

Maximum — +100

Units — %



RX Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RX Input Point 1 Frequency** and is the frequency that is associated with the setting of **RX Input Point 1 Setting (F216)** when operating in the **Speed Control** mode.

See **RX Input Point 1 Setting (F216)** for additional information on this setting.

Direct Access Number — **F217**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

RX Input Point 2 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RX** input level that is associated with **RX Input Point 2 Frequency** (F219) when operating in the **Speed** control mode or is associated with the **RX Input Point 2 Rate** (F221) when operating in the **Torque Control** mode.

This value is entered as -100% to +100% of the **RX** input signal range.

See **RX Input Point 1 Setting** (F216) for additional information on this setting when used for **Speed** control.

See **RX Input Point 1 Rate** (F220) for additional information on this setting when used for **Torque Control**.

Direct Access Number — F218

Parameter Type — Numerical

Factory Default — +100

Changeable During Run — Yes

Minimum — -100.0

Maximum — +100.0

Units — %

RX Input Point 2 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RX Input Point 2 Frequency** and is the frequency that is associated with the setting of **RX Input Point 2 Setting** (F218) when operating in the **Speed Control** mode.

See **RX Input Point 1 Setting** (F216) for additional information on this setting.

Direct Access Number — F219

Parameter Type — Numerical

Factory Default — 60.00

Changeable During Run — Yes

Minimum — 0.00.

Maximum — **Max. Freq.** (F011)

Units — Hz

RX Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Torque Control** mode.

RX Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **RX** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RX**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **RX** input terminal:

- Set **RX Input Point 1 Rate** (F220).
- Set **RX Input Point 1 Setting** (F216) — the input analog signal level that corresponds to the torque setting at **RX Input Point 1 Rate**.
- Set **RX Input Point 2 Rate** (F221).
- Set **RX Input Point 2 Setting** (F218) — the input analog signal level that corresponds to the speed setting at **RX Input Point 2 Rate** (F221).
- Provide a **Run** command (F and/or R).

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RX** input level.

Once set, as the **RX** input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter sets **RX Input Point 1 Rate** and is the output torque value that is associated with the setting of **RX Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

Direct Access Number — F220

Parameter Type — Numerical


Factory Default — 0.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %



RX Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RX** input level.

This parameter sets **RX Input Point 2 Rate** and is the output torque value that is associated with the setting of **RX Input Point 2 Setting** (F218) when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See **RX Input Point 1 Rate** (F220) for additional information on this setting.

Direct Access Number — F221

Parameter Type — Numerical

Factory Default — 100.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %

RX2 Option (AI1) Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

Note: The *Expansion IO Card Option 1* option board (P/N ETB003Z) is required to use this terminal.

This parameter sets the **RX2** (AI1) input level that is associated with **RX2** (AI1) **Input Point 1 Frequency** when operating in the **Speed Control** mode or is associated with the **RX2** (AI1) **Input Point 1 Rate** when operating in the **Torque Control** mode.

RX2 (AI1) Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RX2** (AI1) input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RX2**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RX2** (AI1) input terminal:

- Set **RX2** (AI1) **Input Point 1 Frequency** (F223).
- Set **RX2** (AI1) **Input Point 1 Setting** (F222) — the input analog signal level that corresponds to the speed setting at **RX2** (AI1) **Input Point 1 Frequency**.
- Set **RX2** (AI1) **Input Point 2 Frequency** (F225).
- Set **RX2** (AI1) **Input Point 2 Setting** (F224) — the input analog signal level that corresponds to the speed setting at **RX2** **Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the **RX2** (AI1) input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter value is entered as -100% to +100% of the **RX2** (AI1) input signal range.

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

See parameter **F476** and **F477** for information on fine-tuning the responsiveness of this terminal.

Direct Access Number — **F222**

Parameter Type — **Numerical**


Factory Default — **0**

Changeable During Run — **Yes**

Minimum — -100

Maximum — +100

Units — %



RX2 Option (AI1) Input Point 1 Frequency Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to set the gain and bias of the RX2 (AI1) input terminal when the RX2 (AI1) terminal is used as the control input while operating in the Speed Control mode. This parameter sets RX2 (AI1) Input Point 1 Frequency and is the frequency that is associated with the setting of RX2 (AI1) Input Point 1 Setting (F222) when operating in the Speed Control mode. See RX2 (AI1) Input Point 1 Setting (F222) for additional information on this setting.	Direct Access Number — F223 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
RX2 Option (AI1) Input Point 2 Setting Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to set the gain and bias of the RX2 (AI1) input terminal when the RX2 (AI1) terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This parameter sets the RX2 (AI1) input level that is associated with RX2 (AI1) Input Point 2 Frequency when operating in the Speed control mode or is associated with the RX2 (AI1) Input Point 2 Rate (F227) when operating in the Torque Control mode. This value is entered as -100% to +100% of the RX2 (AI1) input signal range. See RX2 (AI1) Input Point 1 Setting (F222) for additional information on this setting when used for Speed control. See RX2 (AI1) Input Point 1 Rate (F226) for additional information on this setting when used for Torque Control .	Direct Access Number — F224 Parameter Type — Numerical Factory Default — +100 Changeable During Run — Yes Minimum — -100 Maximum — +100 Units — %
RX2 Option (AI1) Input Point 2 Frequency Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to set the gain and bias of the RX2 (AI1) input terminal when the RX2 (AI1) terminal is used as the control input while operating in the Speed Control mode. This parameter sets RX2 (AI1) Input Point 2 Frequency and is the frequency that is associated with the setting of RX2 (AI1) Input Point 2 Setting (F224) when operating in the Speed Control mode. See RX2 (AI1) Input Point 1 Setting (F222) for additional information on this setting.	Direct Access Number — F225 Parameter Type — Numerical Factory Default — 60.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz

RX2 Option (AI1) Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Torque Control** mode.

Note: The *Expansion IO Card Option 1* option board (P/N ETB003Z) is required to use this terminal.

Direct Access Number — F226

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %

RX2 (AI1) Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **RX2** (AI1) input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RX2**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.
- Provide a **Run** command (F and/or R).

Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **RX2** (AI1) input terminal:

- Set **RX2** (AI1) **Input Point 1 Rate** (F226).
- Set **RX2** (AI1) **Input Point 1 Setting** (F222) — the input analog signal level that corresponds to the speed setting at **RX2** (AI1) **Input Point 1 Rate**.
- Set **RX2** (AI1) **Input Point 2 Rate** (F227).
- Set **RX2** (AI1) **Input Point 2 Setting** (F224) — the input analog signal level that corresponds to the speed setting at **RX** **Input Point 2 Rate** (F221).
- Provide a **Run** command (F and/or R).


Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RX2** (AI1) input level.

Once set, as the **RX2** (AI1) input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter sets **RX2** (AI1) **Input Point 1 Rate** and is the output torque value that is associated with the setting of **RX2** (AI1) **Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.



RX2 Option (AI1) Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RX2** (AI1) input level.

This parameter sets **RX2** (AI1) **Input Point 2 Rate** and is the output torque value that is associated with the setting of **RX2** (AI1) **Input Point 2 Setting** (F224) when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See **RX2** (AI1) **Input Point 1 Rate** (F226) for additional information on this setting.

Direct Access Number — F227

Parameter Type — Numerical

Factory Default — 100.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %

BIN Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **BIN** input terminals when the **BIN** terminals are used as the control input while operating in the **Speed Control** mode.

The discrete input terminals of the **ACE G9-120V-PCB** are used as the **BIN** terminals.

Direct Access Number — F228

Parameter Type — Numerical

Factory Default — 0

Changeable During Run — Yes

Minimum — 0


Maximum — 100

Units — %

BIN Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **BIN** input terminals:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **Binary/BCD**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.
- Program ⇒ Terminal ⇒ **Input Terminals**; select and set the desired discrete input terminals to **Binary Bit(s) 0 – 7** (or 0 – MSB). The binary input byte will control the speed of the motor.
- Program ⇒ Terminal ⇒ **Input Terminals**; select and set a discrete input terminal to **Binary Data Write**. Activation of the **Binary Data Write** terminal will transfer the status of the **Binary Bit(s) 0 – 7** (or 0 – MSB) to the control board for speed control.



Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **BIN** input terminals:

- Set **BIN Input Point 1 Frequency** (F229).
- Set the **BIN** input value (% of 255_D) (F228) that represents **BIN Input Point 1 Frequency**.
- Set **BIN Input Point 2 Frequency** (F231).
- Set the **BIN** input value (% of 255_D) (F230) that represents **BIN Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Note: 255_D is the decimal equivalent of the 8-bit **BIN** byte with all input terminals set to 1 (255 decimal = 11111111 binary).

Once set, as the **BIN** input signal changes are transferred to the control board, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **BIN Input Point 1 Setting** (F228) and is entered as 0% to 100% of the of the range represented by the **BIN** binary input byte 11111111 (255_D) or the binary bit(s) 0 – MSB.

<p>BIN Input Point 1 Frequency</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the speed of the BIN input terminals when the BIN terminals are used as the control input.</p> <p>This parameter sets BIN Input Point 1 Frequency and is the frequency that is associated with the setting of BIN Input Point 1 Setting (F228).</p> <p>See BIN Input Point 1 Setting (F228) for additional information on this setting.</p>	<p>Direct Access Number — F229</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>BIN Input Point 2 Setting</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the speed of the BIN input terminals when the BIN terminals are used as the control input.</p> <p>This parameter sets the BIN input signal that is associated with BIN Input Point 2 Frequency (F231).</p> <p>This value is entered as 0% to +100% of the BIN input signal range.</p> <p>See BIN Input Point 1 Setting (F228) for additional information on this setting.</p>	<p>Direct Access Number — F230</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>BIN Input Point 2 Frequency</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the speed of the BIN input terminals when the BIN terminal are used as the control input.</p> <p>This parameter sets BIN Input Point 2 Frequency and is the frequency that is associated with the setting of BIN Input Point 2 Setting (F230).</p> <p>See BIN Input Point 1 Setting (F228) for additional information on this setting.</p>	<p>Direct Access Number — F231</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Maximum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>

PG Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **PG** input terminal of the option board when a shaft-mounted encoder is used as the control input while operating in the **Speed Control** mode.

Note: See Instruction Manual P/N 58687 for additional information on the **PG Option Board**.

PG Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **PG** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **Pulse Input** (option).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ **Command Mode Selection** ⇒ (Any Setting).
- Provide a **Run** command (F and/or R).

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **PG** input terminals:

- Set **PG Point 1 Frequency (F235)**.
- Set the **PG** input value (**F234**) that represents **PG Point 1 Frequency**.
- Set **PG Point 2 Frequency (F237)**.
- Set the **PG** input value (**F236**) that represents **PG Point 2 Frequency**.

Once set, as the **PG** input pulse count rate changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets the **PG** input pulse count that represents **PG Point 1 Frequency**. The range of values for this parameter is 0% to 100% of the **PG** input pulse count range.

Note: Additional application-specific **PG** settings may be performed from the following path: Program ⇒ Feedback ⇒ **PG Settings**.

Direct Access Number — **F234**

Parameter Type — **Numerical**


Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **0**

Maximum — **100.0**

Units — **%**



PG Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **PG** input terminals when the **PG** terminal is used as the control input.

This parameter sets **PG Point 1 Frequency** and is the frequency that is associated with the setting of **PG Point 1 Setting (F234)**.

See **PG Point 1 Setting (F234)** for additional information on this setting.

Direct Access Number — **F235**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — **0.00**

Maximum — **Max. Freq. (F011)**

Units — **Hz**

PG Input Point 2 Setting Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to set the direction and speed of the PG input terminals when the PG terminals are used as the control input. This parameter sets the PG input signal that is associated with PG Point 2 Frequency (F237). This value is entered as 0% to 100% of the PG input signal range. See PG Point 1 Setting (F234) for additional information on this setting.	Direct Access Number — F236 Parameter Type — Numerical Factory Default — 100 Changeable During Run — Yes Minimum — 0 Maximum — 100 Units — %
PG Input Point 2 Frequency Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to set the direction and speed of the PG input terminals when the PG terminal are used as the control input. This parameter sets PG Point 2 Frequency (F237) and is the frequency that is associated with the setting of PG Point 2 Setting . See PG Point 1 Setting (F234) for additional information on this setting.	Direct Access Number — F237 Parameter Type — Numerical Factory Default — 60.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Start Frequency Program ⇒ Special ⇒ Frequency Control The output of the ASD will remain at 0.0 Hz until the programmed speed value exceeds this setting during startup. Once exceeded during startup, the output frequency of the ASD will accelerate to the programmed setting. Output frequencies below the Start Frequency will not be output from the ASD during startup. However, once reaching the Start Frequency , speed values below the Start Frequency may be output from the ASD. If the setting of this parameter results in an over-current condition at startup, reduce the setting of this parameter to a value less than the rated slippage of the motor. If zero-speed torque is required, set this parameter and F243 to 0.0 Hz. This setting will override the setting of F244 if this setting has a higher value. This parameter setting is used during a Jog as the Lower-Limit frequency (see F260).	Direct Access Number — F240 Parameter Type — Numerical Factory Default — 0.10 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Run Frequency Program ⇒ Special ⇒ Frequency Control This parameter establishes a center frequency (Run Frequency) of a frequency band. Parameter F242 provides a plus-or-minus value for the Run Frequency ; thus, establishing a frequency band. During acceleration, the ASD will not output a signal to the motor until the lower level of the band is reached. During deceleration, the ASD will continue to output the programmed deceleration signal to the motor until the lower level of the band is reached; at which time the output will go to 0.0 Hz.	Direct Access Number — F241 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz

Run Frequency Hysteresis Program ⇒ Special ⇒ Frequency Control This parameter provides a plus-or-minus value for the Run Frequency (F241) setting.	Direct Access Number — F242 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 30.0 Units — Hz
End Frequency Program ⇒ Special ⇒ Frequency Control This parameter sets the lowest frequency that the ASD will recognize during deceleration before the ASD goes to 0.00 Hz.	Direct Access Number — F243 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 30.0 Units — Hz
0 Hz Dead Band Signal Program ⇒ Special ⇒ Special Parameters This parameter sets an output frequency threshold that, until the commanded frequency surpasses this setting, the ASD will output 0.00 Hz to the motor. This setting will override the Start Frequency (F240) setting if this setting has a higher value.	Direct Access Number — F244 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 5.00 Units — Hz
DC (Injection) Braking Start Frequency Program ⇒ Protection ⇒ DC Braking During deceleration this is the frequency at which DC Injection Braking will start. DC Injection Braking DC Injection Braking is a braking system used with 3-phase motors. Unlike conventional brakes, there is no physical contact between the rotating shaft and a stationary brake pad or drum. When braking is required, the ASD outputs a DC current that is applied to the windings of the motor to quickly brake the motor. The braking current stops when the time entered in F252 times out. The intensity of the DC current used while braking determines how fast the motor will come to a stop and may be set at F251 . The intensity setting is entered as a percentage of the full-load current of the ASD. DC Injection Braking is also used to preheat the motor or to keep the rotor from spinning freely when the motor is off by providing a pulsating DC current into the motor at the Carrier Frequency . This feature may be enabled at F254 .	Direct Access Number — F250 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 120.00 Units — Hz
DC (Injection) Braking Current Program ⇒ Protection ⇒ DC Braking This parameter sets the percentage of the rated current of the ASD that will be used for DC Injection Braking . A larger load will require a higher setting.	Direct Access Number — F251 Parameter Type — Numerical Factory Default — 50 Changeable During Run — Yes Minimum — 0 Maximum — 100 Units — %

DC (Injection) Braking Time Program ⇒ Protection ⇒ DC Braking This parameter setting is used to set the on-time duration of the DC Injection Braking .	Direct Access Number — F252 Parameter Type — Numerical Factory Default — 1.0 Changeable During Run — Yes Minimum — 0.0 Maximum — 20.0 Units — Seconds
Forward/Reverse DC (Injection) Braking Priority Program ⇒ Protection ⇒ DC Braking This parameter setting determines if DC Injection Braking is to be used during a change in the direction of the motor. Settings: Disabled Enabled	Direct Access Number — F253 Parameter Type — Selection List Factory Default — Disabled Changeable During Run — Yes
Motor Shaft Fixing Control Program ⇒ Protection ⇒ DC Braking This parameter Enables/Disables a continuous DC injection at half of the amperage setting of F251 into a stopped motor. This feature is useful in preheating the motor or to keep the rotor from spinning freely. Motor Shaft Stationary Control starts after the DC injection brake stops the motor and continues until the ST activation ceases (if so configured; see F110), power is turned off, an Emergency Off command is received, or this parameter is changed. Enabling this feature will also require a non-zero entry at F250 . Settings: Disabled Enabled	Direct Access Number — F254 Parameter Type — Selection List Factory Default — Disabled Changeable During Run — Yes
0 Hz Command Output Program ⇒ Special ⇒ Special Parameters This parameter is used to set the go-to-zero method to be used by the ASD in the event that the ASD is commanded to go to 0 Hz. Settings: Standard (DC Injection Braking) 0 Hz Command	Direct Access Number — F255 Parameter Type — Selection List Factory Default — Standard (DC Injection Braking) Changeable During Run — No
Time Limit For Lower-Limit Frequency Operation Program ⇒ Fundamental ⇒ Frequency This parameter sets the time that the ASD is allowed to operate below the Lower-Limit setting before an alarm and subsequent fault is incurred.	Direct Access Number — F256 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — 0.0 Maximum — 600.0 Units — Seconds

Jog Run Frequency

Program ⇒ Frequency ⇒ Jog

This parameter sets the output frequency of the ASD during a **Jog**. **Jog** is the term used to describe turning the motor on for small increments of time and is used when precise positioning of motor-driven equipment is required.

The **Jog** function may be initiated from the **EOI**, remotely via the **ACE G9-120V-PCB**, or using **Communications** (for additional information on using Communications for Jogging, see the Communications manual P/N 53840).

The **Jog** function can be activated from zero Hz or from any frequency below the **Jog Run** frequency (Jog can only increase the speed). A **Jog** command will not be recognized when the running frequency is above the **Jog Run** frequency setting. The **Jog** command has priority over other **Run** commands and is not limited by the **Upper Limit** setting of parameter **F012**.

Jog commands received while running for the opposite direction will follow the programmed stopping method of **F261** until reaching zero Hz and will then ramp to the programmed **Jog Frequency** and direction.

Direct Access Number — **F260**

Parameter Type — **Numerical**

Factory Default — **5.00**

Changeable During Run — **Yes**

Minimum — **F240** Setting

Maximum — 20.00

Units — Hz

Jog Setup and Execution

To initiate a **Jog Run** from the **EOI** perform the following:

1. Enable the **Jog** function at **F262**.
2. Set the **Command Mode Selection (F003)** to **EOI Keypad**.
3. Assign the **Jog Run** setting to a discrete input terminal (see [Table 7 on pg. 236](#)).

***Note:** Any unused discrete input terminal may be used for the **Jog Run** setting.*

4. Set up a **Jog Run Frequency** at **F260**.
5. Set up a **Jog Stop Pattern** at **F261**.
6. Set the **Input Terminal Priority (F106)** function to **Disable** to receive **Jog** commands from the **EOI**.
7. Set the **Local/Remote** key to **Local**.
8. Activate the **Jog Run** terminal (from step 3) and provide a **Run** command (F or R).
9. Press the **Run** key and the ASD will output the frequency setting of **F260** for the duration of the activation.

To initiate a **Jog Run** from the **ACE G9-120V-PCB** perform the following:

1. Using the setup above, set the **Input Terminal Priority (F106)** function (from step 6) to **Enable** to receive **Jog** commands from the **ACE G9-120V-PCB** using the **Jog Run** terminal without regard to the **Local/Remote** setting.
2. Use the **Jog Run** terminal of step 3 above to activate the **Jog** function.

Jog Stop Pattern

Program ⇒ Frequency ⇒ Jog

This parameter sets the stopping method used while operating in the **Jog** mode.

Note: This parameter setting is used for the **Jog** operation only. The **Emergency Off** stopping method setting of parameter **F603** has priority over this setting and changes made here do not affect the function or setting of parameter **F603**.

Settings:

Deceleration Stop
Coast Stop
DC Injection Braking Stop

Direct Access Number — F261Parameter Type — **Selection List**Factory Default — **Deceleration Stop**Changeable During Run — **Yes**

Panel Operation Jog Mode

Program ⇒ Frequency ⇒ Jog

This parameter enables the **Jog** command to be received from the **EOI**. When disabled the **Jog** command received from the **EOI** is ignored.

Jog commands may also be received from the **ACE G9-120V-PCB**. Priority as to which is allowed to override the other is selected at **F106**.

The priority selection at **F106** enables the selected source for **Jog** control and disables the other. The **F106** setting overrides this parameter setting.

Settings:

Disabled
Enabled

Direct Access Number — F262Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

UP/DOWN Frequency (UP) Response Time

Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions

This parameter functions in conjunction with the parameter settings of **F265**, **F266**, **F267**, **F268**, and **F269**. The purpose of these settings is to setup the ASD to allow an externally-supplied discrete input signal to control the output frequency of the ASD.

This method uses the discrete input terminal settings **UP/DOWN Frequency (UP)** and **UP/DOWN Frequency (DOWN)** to change the ASD speed. Activation of either terminal increases or decreases the output frequency at the **Accel 1** or **Decel 1** rates, respectively.

Depending on the **Delay** setting, the **UP/DOWN Frequency (UP/DOWN)** terminal may perform **1)** the increase/decrease function for the duration of activation or **2)** the **UP/DOWN Frequency (UP/DOWN)** terminal may act as a momentary contact that loads a new commanded frequency upon activation.

In either case, to activate-and-hold will continue the up or down function until reaching the **Upper-Limit Frequency** or the **Lower-Limit Frequency**, respectively. At which point further activation will be ignored.

See **Figure 30** on **pg. 133** for additional information on the **UP/DOWN Frequency** function.

Setup Requirements

F003 — Selects the **Command** control source; set to **Terminal Board**.

F004 — Selects the **Frequency Control Mode 1** control source; set to **UP/DOWN Frequency**.

F207 — Selects the **Frequency Control Mode 2** control source; set to **UP/DOWN Frequency** if used.

Set one unused discrete input terminal to **UP/DOWN Frequency (UP)** and one unused discrete input terminal to **UP/DOWN Frequency (DOWN)**.

F264 — Sets the system-response delay to the initial activation of the discrete input terminal **UP/DOWN Frequency (UP)**. Also sets the response delay of subsequent terminal activations of the **UP/DOWN Frequency (UP)** terminal during an activate-and-hold.

F265 — Sets the frequency increase amount for each activation of the **UP/DOWN Frequency (UP)** terminal activation. The rate of the frequency increase is set at **Acceleration Time 1 — UP/DOWN Frequency Accel Time (F009)**.

F266 — Sets the system-response delay to the initial activation of the discrete input terminal **UP/DOWN Frequency (DOWN)**. Also sets the activation delay of subsequent terminal activations of the **UP/DOWN Frequency (DOWN)** terminal during an activate-and-hold.

F267 — Sets the frequency decrease amount for each activation of the **UP/DOWN Frequency (DOWN)** terminal activation. The rate of the frequency decrease is set at **Deceleration Time 1 — UP/DOWN Frequency Decel Time (F010)**.

F268 — At power up or after a reset, this parameter setting is used to provide a starting frequency for the **UP/DOWN Frequency** function.

F269 — At power down while running, and when enabled, this parameter writes the running frequency into the **F268** location and, upon a system restart, uses this setting as the startup frequency.

Provide a **Run** command (F or R). The motor will run at the **F268** setting.

Direct Access Number — **F264**

Parameter Type — **Numerical**

Factory Default — **0.1**


Changeable During Run — **Yes**

Minimum — **0.0**


Maximum — **10.0**

Units — **Seconds**


UP/DOWN Frequency (UP) Mode



UP/DOWN Frequency (DOWN) Mode



UP/DOWN Frequency (UP) Frequency Step Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions This parameter sets the frequency increase amount for each activation of the UP/DOWN Frequency (UP) terminal activation. The rate of the frequency increase is set at Acceleration Time 1 — UP/DOWN Frequency Accel Time (F009) . See F264 for additional information on this parameter.	Direct Access Number — F265 Parameter Type — Numerical Factory Default — 0.10 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
UP/DOWN Frequency (DOWN) Response Time Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions This parameter sets the system-response delay to the initial activation of the discrete input terminal UP/DOWN Frequency (DOWN) . Also sets the activation delay of subsequent terminal activations of the UP/DOWN Frequency (DOWN) terminal during an activate-and-hold. See F264 for additional information on this parameter.	Direct Access Number — F266 Parameter Type — Numerical Factory Default — 0.1 Changeable During Run — Yes Minimum — 0.0 Maximum — 10.0 Units — Seconds
UP/DOWN Frequency (DOWN) Frequency Step Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions This parameter sets the frequency decrease amount for each activation of the UP/DOWN Frequency (DOWN) terminal activation. The rate of the frequency decrease is set at Deceleration Time 1 — UP/DOWN Frequency Decel Time (F010) . See F264 for additional information on this parameter.	Direct Access Number — F267 Parameter Type — Numerical Factory Default — 0.10 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Initial UP/DOWN Frequency Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions At power up or after a reset, this parameter setting is used to provide a starting frequency for the UP/DOWN Frequency function. See F269 for additional information on this parameter setting.	Direct Access Number — F268 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Initial UP/DOWN Frequency Rewriting Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions At power down, and when enabled, this parameter writes the running frequency into the F268 location and, upon a system restart, uses this setting as the startup frequency. Disable this parameter and set parameter F268 to the desired startup frequency if the same starting frequency is required at each startup. Note: <i>This parameter setting may be different at each startup when enabled.</i> Settings: Disabled Enabled (Overwrite F268 at Power Off or Reset)	Direct Access Number — F269 Parameter Type — Selection List Factory Default — Enabled Changeable During Run — Yes

Figure 30. UP/DOWN Frequency Operation Control Timing Diagram.

Jump Frequency 1

Program ⇒ Special ⇒ Jump Frequencies

In conjunction with parameter **F271**, this parameter establishes a user-defined frequency range: the **Jump Frequency** and a plus-or-minus value.

During acceleration, the output frequency of the ASD will hold at the lower level of the **Jump Frequency** range until the programmed acceleration ramp reaches the upper level of the **Jump Frequency** range. At which time the output frequency of the ASD will accelerate to the upper level of the **Jump Frequency** range and continue upward as programmed.

During deceleration, the output frequency of the ASD will hold at the upper level of the **Jump Frequency** range until the programmed deceleration ramp reaches the lower level of the **Jump Frequency** range. At which time the output frequency of the ASD will decelerate to the lower level of the **Jump Frequency** range and continue downward as programmed.

Once set up and enabled, it is on in all control modes.

User-selected frequencies may be jumped to avoid the negative effects of mechanical resonance.

Direct Access Number — F270

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz

Jump Frequency 1 Bandwidth Program ⇒ Special ⇒ Jump Frequencies This parameter establishes a plus-or-minus value for Jump Frequency 1 (see F270).	Direct Access Number — F271 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 30.00 Units — Hz
Jump Frequency 2 Program ⇒ Special ⇒ Jump Frequencies Same as Jump Frequency 1 (F270) and is used when multiple frequencies are to be jumped (see the plus-or-minus value setting at F273). When multiple jump frequencies overlap, the system will recognize the lowest and the highest frequencies as one jump range.	Direct Access Number — F272 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Jump Frequency 2 Bandwidth Program ⇒ Special ⇒ Jump Frequencies This parameter establishes a plus-or-minus value for Jump Frequency 2 (F272).	Direct Access Number — F273 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 30.0 Units — Hz
Jump Frequency 3 Program ⇒ Special ⇒ Jump Frequencies Same as Jump Frequency 1 (F270) and is used when multiple frequencies are to be jumped (see the plus-or-minus value setting at F275). When multiple jump frequencies overlap, the system will recognize the lowest and the highest frequencies as one jump range.	Direct Access Number — F274 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Jump Frequency 3 Bandwidth Program ⇒ Special ⇒ Jump Frequencies This parameter establishes a plus-or-minus value for Jump Frequency 3 (F274).	Direct Access Number — F275 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 30.0 Units — Hz

External Fault Stopping Method Program ⇒ Crane/Hoist ⇒ External Fault In a multiple ASD configuration a faulted ASD signals the remaining ASDs, via a discrete input terminal, that a fault has occurred and shuts down the non-faulted ASDs. The non-faulted ASDs experience an External Fault . This parameter selects the stopping method in the event that a External Fault is incurred. Settings: Coast Stop Deceleration Stop DC Injection Braking Stop	Direct Access Number — F280 Parameter Type — Selection List Factory Default — Coast Stop Changeable During Run — No
Limit-Switch Stopping Method Program ⇒ Crane/Hoist ⇒ Limit Switch Control This parameter determines the method used to stop the motor if the Stop command is initiated via a limit switch. Settings: Coast Stop Deceleration Stop DC Injection Braking Stop	Direct Access Number — F282 Parameter Type — Selection List Factory Default — Deceleration Stop Changeable During Run — No
Deceleration Time at Slow-Speed-Limit UP Program ⇒ Crane/Hoist ⇒ Limit Switch Control Closure of the Upper-Limit Slow-Speed Limit-Switch implements the modified Upper-Limit Speed (F294) and Deceleration Time (F283) settings. This parameter sets the time to reach the modified Lower-Limit Slow Speed .	Direct Access Number — F283 Parameter Type — Numerical Factory Default — 1.5 Changeable During Run — No Minimum — 0.1 Maximum — 1.5 Units — Seconds
Stopping Time at Stop Limit-Switch UP Program ⇒ Crane/Hoist ⇒ Limit Switch Control A Stop command is initiated upon activation of the Upper-Limit Stop Limit-Switch . This parameter sets the Decel rate to be used upon activation of the Upper-Limit Stop Limit-Switch .	Direct Access Number — F284 Parameter Type — Numerical Factory Default — 1.5 Changeable During Run — No Minimum — 0.0 Maximum — 25.0 Units — Seconds
Deceleration Time At Slow-Speed Limit-Switch DOWN Program ⇒ Crane/Hoist ⇒ Limit Switch Control Closure of the Lower-Limit Slow-Speed Limit-Switch implements the modified Lower-Limit Slow Speed (F293) and Deceleration Time (F285) settings. This parameter sets the time to reach the modified Lower-Limit Slow Speed .	Direct Access Number — F285 Parameter Type — Numerical Factory Default — 1.5 Changeable During Run — No Minimum — 0.0 Maximum — 25.0 Units — Seconds

Stopping Time at Stop Limit-Switch DOWN Program ⇒ Crane/Hoist ⇒ Limit Switch Control A Stop command is initiated upon activation of the Lower-Limit Stop Limit-Switch . This parameter sets the Decel rate to be used upon activation of the Lower-Limit Stop Limit-Switch .	Direct Access Number — F286 Parameter Type — Numerical Factory Default — 1.5 Changeable During Run — No Minimum — 0.0 Maximum — 25.0 Units — Seconds
Preset Speed 8 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 1000 and is identified as Preset Speed 8 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F287 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 9 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 1001 and is identified as Preset Speed 9 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F288 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 10 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 1010 and is identified as Preset Speed 10 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F289 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 11 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 1011 and is identified as Preset Speed 11 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F290 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 12 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 1100 and is identified as Preset Speed 12 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F291 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz

Preset Speed 13 Program ⇒ Frequency ⇒ Preset Speeds This parameter assigns an output frequency to binary number 1101 and is identified as Preset Speed 13 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).	Direct Access Number — F292 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 14/Lower-Limit Slow Speed Program ⇒ Frequency ⇒ Preset Speeds This is a dual-function parameter. The two functions are described below. 1) This parameter assigns an output frequency to binary number 1110 and is identified as Preset Speed 14 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter). 2) The Lower-Limit speed and Deceleration time settings are changed once the crane approaches the end of its range (hoist or traverse). Upon approaching the end-of-range, as detected by the closure of the Lower-Limit Slow-Speed Limit-Switch , the implementation of the modified Lower-Limit Slow Speed (F293) and Deceleration Time At Slow-Speed Limit-Switch DOWN (F285) settings take effect.	Direct Access Number — F293 Parameter Type — Numerical Factory Default — 6.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Preset Speed 15/Upper-Limit Slow Speed Program ⇒ Frequency ⇒ Preset Speeds This is a dual-function parameter. The two functions are described below. 1) This parameter assigns an output frequency to binary number 1111 and is identified as Preset Speed 15 . The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter). 2) The Upper-Limit speed and Deceleration time settings are changed once the crane approaches the end of its range (hoist or traverse). Upon approaching the end-of-range, as detected by the closure of the Upper-Limit Slow-Speed Limit-Switch , the implementation of the modified Upper-Limit Slow Speed (F294) and Deceleration Time at Slow-Speed-Limit UP (F283) settings take effect.	Direct Access Number — F294 Parameter Type — Numerical Factory Default — 6.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
PWM Carrier Frequency Program ⇒ Special ⇒ Carrier Frequency This parameter sets the frequency of the Pulse Width Modulation (PWM) signal applied to the motor. Note: When operating in the Vector Control mode the carrier frequency should be set to 2.2 kHz or above. Note: If the PWM carrier frequency is set at 2.0 kHz or above, it cannot be decreased below 2.0 kHz while running. If the PWM carrier frequency is set at 1.9 kHz or below, it cannot be increased above 2.0 kHz while running. Either change requires that the ASD be stopped and restarted for the changes to take effect.	Direct Access Number — F300 Parameter Type — Numerical Factory Default — 2.5 Changeable During Run — No Minimum — 1.0 Maximum — (ASD-Dependent) Units — kHz

Auto Restart Selection

Program ⇒ Protection ⇒ Retry/Restart

This parameter **Enables/Disables** the ability of the ASD to start into a spinning motor when the **ST** activation ceases (if so configured; see [F110](#)) momentarily and is then reactivated (ST deactivation/ST activation) or after a power interruption (momentary power failure).

Settings:

- Off
- Enabled (at Power Failure)
- Enabled (at ST Activate/Deactivate)
- Enabled (at ST Activate/Deactivate or Power Failure)
- Enabled (at Run)

Direct Access Number — **F301**

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **No**

Regenerative Power Ridethrough

Program ⇒ Protection ⇒ Under-Voltage/Ridethrough

This parameter determines the motor-control response of the ASD in the event of a momentary power outage or under-voltage condition.

During a **Ridethrough**, regenerative energy is used to maintain the control circuitry settings for the duration of the **Ridethrough**; it is not used to drive the motor. The motor(s) of the system are stopped and then restarted automatically if so configured.

In a multiple-motor application, there will be a requirement to synchronize the stopping and restarting of the motors as not to cause breakage in the product being processed by the motors stopping/starting at different times (e.g., wire spools, bobbin winder for textile machines, etc.). Parameters [F317](#) and [F318](#) must be setup to synchronize motor operation as to avoid breakage in these types of applications.

Note: If used to restart the motors, the Retry setup of [F301](#) is required.

Note: The **Jog** function will not operate while in the **Synchronized Decel/Accel** mode.

Settings:

- Off
- Ridethrough On
- Decel Stop
- Synchronized ACC/DEC (TB)
- Synchronized ACC/DEC (TB + Power Off)

Direct Access Number — **F302**

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **Yes**

Ridethrough Setup Requirements

1. Select the **Ridethrough Mode** at [F302](#).
2. Select the **Ridethrough Time** at [F310](#).
3. Select the **Synchronized Stop/Start Times** at [F317/F318](#) (if required).

Note: [F317](#) and [F318](#) are not functional while operating in the **Torque** or **Position** control modes, or for the **Jog Run** function ([F260](#)).

4. Set a discrete input terminal to **Power Failure Synchronized Signal** and activate the terminal to enable the **Synchronized Accel/Decel** function.
5. Select the **Ridethrough Control Level** at [F629](#).

Number of Times to Retry

Program ⇒ Protection ⇒ Retry/Restart

After a trip has occurred, this parameter sets the number of times that an automatic system restart is attempted for a qualified trip.

The trip conditions listed below will not initiate the automatic **Retry/Restart** function:

- Input Phase Loss (Input Phase Failure)
- Output Phase Loss (Output Phase Failure)
- Output Current Protection Fault
- Output Current Detector Error
- Load Side Over-Current at Start
- Earth Fault (Ground Fault)
- Over-Current During Acceleration
- Arm Over-Current at Start-Up
- DBR Resistor Over-Current
- Low-Current
- Voltage Drop In Main Circuit
- EEPROM Data Fault (EEPROM Fault)
- Flash Memory/Gate Array/RAM-ROM Fault
- CPU Fault
- Emergency Off (EMG)
- Communication Error
- Option Fault
- Sink/Source Setting Error (not used with the ACE-tronics G9 ASD)
- Over-Speed Error
- Over-Torque
- Key Error
- External Thermal Error
- Externally-Controlled Interrupt

See the section titled [System Setup Requirements](#) on pg. 8 for additional information on this setting.

Direct Access Number — F303

Parameter Type — **Numerical**

Factory Default — **00**

Changeable During Run — **Yes**

Minimum — 00

Maximum — 10

Dynamic Braking Enable

Program ⇒ Protection ⇒ Dynamic Braking

This parameter **Enables/Disables** the **Dynamic Braking** system.

Settings:

- Off
- Enabled with Overload Detection
- Enabled without Overload Detection

Dynamic Braking uses the transistor **IGBT7** to dissipate the bus voltage when required.

IGBT7 is a standard item on the 25 HP and below ACE-tronics G9 ASD 230-volt systems and is standard on the 400 HP and below for the 460-volt systems. **IGBT7** is optional for all remaining systems.

Dynamic Braking

Dynamic Braking is used to prevent over-voltage faults during rapid deceleration or constant speed run on cyclic overhauling applications.

Dynamic Braking dissipates regenerated energy in the form of heat. When using a DBR use thermal protection.

The resistive load is connected across terminals **PA** and **PB** (non-polarized). Using a low-value, high-wattage resistance as a load for the generated current, the resistive load dissipates the induced energy.

Dynamic Braking helps to slow the load quickly; it cannot act as a holding brake.

The **Dynamic Braking** function may be setup and enabled by connecting a braking resistor from terminal **PA** to **PB** of the ASD and providing the proper information at [F304](#), [F308](#), and [F309](#).

See the section titled [Dynamic Braking Resistor Specifications on pg. 274](#) for additional information on using the DBR system and for assistance in selecting the appropriate resistor for a given application.

Direct Access Number — **F304**

Parameter Type — **Selection List**

Factory Default — **Enabled without Overload Detection**

Changeable During Run — **No**

Over-Voltage Limit Operation

Program ⇒ Protection ⇒ Stall

This parameter enables the **Over-Voltage Limit** function. This feature is used to set the upper DC bus voltage threshold that, once exceeded, will cause an **Over-Voltage Stall**.

An **Over-Voltage Stall** increases the output frequency of the ASD during deceleration for a specified time in an attempt to prevent an **Over-Voltage Trip**.

If the over-voltage threshold level setting of parameter [F626](#) is exceeded for over 4 mS, an **Over-Voltage Trip** will be incurred.

Note: This parameter setting may increase deceleration times.

Settings:

- Enabled (Over-Voltage Stall)
- Disabled
- Enabled (Forced Shorted Deceleration)
- Enabled (Forced Dynamic Braking Deceleration)

Direct Access Number — **F305**

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

Supply Voltage Correction

Program ⇒ Protection ⇒ Base Frequency Voltage

This parameter **Enables/Disables** the **Voltage Compensation** function.

When **Enabled**, this function provides a constant V/f ratio during periods of input voltage fluctuations.

Settings:

- Disabled (Output Voltage Unlimited)
- Enabled (Supply Voltage Compensation)
- Disabled (Output Voltage Limited)
- Enabled (Supply Voltage Compensation w/Output Voltage Limited)

Direct Access Number — F307

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

Dynamic Braking Resistance

Program ⇒ Protection ⇒ Dynamic Braking

This parameter is used to input the resistive value of the **Dynamic Braking Resistor** being used.

Light-duty and heavy-duty resistors vary from a few ohms to several hundred ohms. The appropriate resistance size will be typeform- and application-specific.

See the section titled [Dynamic Braking Resistor Specifications on pg. 274](#) for additional information on using the DBR system and for assistance in selecting the appropriate resistor for a given application.

Note: *Using a resistor value that is too low may result in system damage.*

Direct Access Number — F308

Parameter Type — **Numerical**

Factory Default — (ASD-Dependent)

Changeable During Run — **No**

Minimum — 0.5

Maximum — 1000.0

Units — Ω

Continuous Dynamic Braking Capacity

Program ⇒ Protection ⇒ Dynamic Braking

This parameter is used to input the wattage of the **Dynamic Braking Resistor**.

See the section titled [Dynamic Braking Resistor Specifications on pg. 274](#) for additional information on using the DBR system.

Note: *Using a resistor with a wattage rating that is too low may result in system damage.*

Direct Access Number — F309

Parameter Type — **Numerical**

Factory Default — (ASD-Dependent)

Changeable During Run — **No**

Minimum — 0.01

Maximum — 600.00

Units — kW

Ridethrough Time

Program ⇒ Protection ⇒ Retry/Restart

In the event of a momentary power outage, this parameter determines the length of the **Ridethrough** time.

The **Ridethrough** will be maintained for the number of seconds set using this parameter.

See parameter [F302](#) for additional information on the Ridethrough function.

Note: *The actual **Ridethrough Time** is load-dependent.*

Direct Access Number — F310

Parameter Type — **Numerical**

Factory Default — **2.0**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 320.0

Units — Seconds

<p>Forward Reverse Disable</p> <p>Program ⇒ Frequency ⇒ Forward/Reverse Disable</p> <p>This parameter Enables/Disables the Forward Run or Reverse Run mode.</p> <p>If either direction is disabled, commands received for the disabled direction will not be recognized.</p> <p>If both directions are disabled, the received direction command will determine the direction of the motor rotation.</p> <p>Settings:</p> <ul style="list-style-type: none"> Off Disable Reverse Run Disable Forward Run 	<p>Direct Access Number — F311</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Off</p> <p>Changeable During Run — No</p>
<p>Random Mode</p> <p>Program ⇒ Protection ⇒ Retry/Restart</p> <p>This parameter adjusts the carrier frequency randomly. This feature is effective in minimizing the negative effects of mechanical resonance.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F312</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — No</p>
<p>Carrier Frequency Control Mode</p> <p>Program ⇒ Special ⇒ Carrier Frequency</p> <p>This parameter provides for the automatic decrease of the carrier frequency.</p> <p>Select 1 to decrease the Carrier Frequency setting as a function of an increased current requirement.</p> <p>Selection 2 or 3 may also include an output voltage drop as a function of an increased current requirement. The Carrier Frequency should be set below 4 kHz.</p> <p>Settings:</p> <ul style="list-style-type: none"> No Decrease and No Limit Valid Decrease and No Limit No Decrease and Limit Small Pulse Valid Decrease and Limit Small Pulse 	<p>Direct Access Number — F316</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Valid Decrease and No Limit</p> <p>Changeable During Run — Yes</p>
<p>Synchronized Deceleration Time</p> <p>Program ⇒ Protection ⇒ Under-Voltage/Ridethrough</p> <p>In the event that the Ridethrough function activates in a multiple-motor application it will be necessary to manage the stopping motors synchronously as not to damage the product being processed (e.g., wire spools, bobbin winder for textile machines, etc.).</p> <p>This parameter is used to minimize the product breakage during a momentary power outage. This function stops multiple machines simultaneously or makes them reach their respective command frequencies simultaneously by regulating their deceleration times.</p> <p>See parameter F302 for additional information on this setting.</p>	<p>Direct Access Number — F317</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 2.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 6000.0</p> <p>Units — Seconds</p>

Synchronized Acceleration Time

Program ⇒ Protection ⇒ Under-Voltage/Ridethrough

In the event that the **Ridethrough** function activates in a multiple-motor application it will be necessary to manage the accelerating motors synchronously as not to damage the product being processed (e.g., wire spools, bobbin winder for textile machines, etc.).

This parameter is used to minimize the product breakage during a momentary power outage. This function orchestrates the acceleration of multiple machines simultaneously or makes them reach their respective command frequencies simultaneously by regulating their acceleration times.

See parameter **F302** for additional information on this setting.

Direct Access Number — F318

 Parameter Type — **Numerical**

 Factory Default — **2.0**

 Changeable During Run — **Yes**

Minimum — 0.10

Maximum — 6000.0

Units — Seconds

Drooping Gain

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the effective 100% output torque level while operating in the **Drooping Control** mode. This value is the upper torque limit of the motor being driven by a given ASD while operating in the **Drooping Control** mode.

Note: *The maximum frequency output is not limited by the setting of **F011** while operating in the **Drooping Control** mode.*

Direct Access Number — F320

 Parameter Type — **Numerical**

 Factory Default — **0.0**

 Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 100.0

Units — %

Drooping

Drooping Control, also called **Load Share**, is used to share the load among two or more mechanically coupled motors. Unlike **Stall**, which reduces the output frequency in order to limit the load once the load reaches a preset level, **Drooping** can decrease or increase the V/f setting of a motor to maintain a balance between the output torque levels of mechanically coupled motors.

Because of variances in gearboxes, sheaves, belts, motors, and since the speed of the motor is constrained by the mechanical system, one motor may experience more load than its counterpart and may become overloaded.

Drooping Control allows the overloaded motor to slow down, thus shedding load and encouraging a lightly-loaded motor to pick up the slack. The goal of **Drooping Control** is to have the same torque ratios for mechanically coupled motors.

Speed at 0% Drooping Gain

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the motor speed when at the 0% output torque gain while operating in the **Drooping Control** mode. This function determines the lowest speed that **Drooping** will be in effect for motors that share the same load.

Direct Access Number — F321

 Parameter Type — **Numerical**

 Factory Default — **0.00**

 Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 320.0

Units — Hz

Speed at F320 Drooping Gain

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the motor speed when at the 100% output torque gain while operating in the **Drooping Control** mode. This function determines the speed of the individual motors at the 100% **Drooping Gain** setting for motors that share the same load.

Direct Access Number — F322

 Parameter Type — **Numerical**

 Factory Default — **0.00**

 Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 320.0

Units — Hz

Drooping Insensitive Torque Program ⇒ Feedback ⇒ Drooping Control This parameter defines a torque range in which the Drooping Control settings will be ignored and the programmed torque settings will be followed.	Direct Access Number — F323 Parameter Type — Numerical Factory Default — 10.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 100.0 Units — %
Drooping Output Filter Program ⇒ Feedback ⇒ Drooping Control This parameter is used to set the rate of output change allowed when operating in the Drooping Control mode. Jerky operation may be reduced by increasing this setting.	Direct Access Number — F324 Parameter Type — Numerical Factory Default — 100.0 Changeable During Run — Yes Minimum — 0.1 Maximum — 200.0 Units — Radians/Second
Express-Speed Selection Program⇒ Crane/Hoist ⇒ Express Speed This parameter enables the Express Speed function by selecting an operating mode. The Express Speed function accelerates the output frequency of the ASD from the programmed speed to the setting established in F330 . Select Off to disable the Express Speed feature. Enabling the Express Speed function requires that an operating mode be selected here, and that the criteria of parameters F331 – F333 be met. Settings: Off Auto Speed (F-Motor: Up, R-Generator:Down) Auto Speed (F-Generator: Down, R-Motor:Up) F330 Setting (F-Motor: Up, R-Generator:Down) F330 Setting (F-Generator: Down, R-Motor:Up) Express Speed Setup and Run Criteria. F328 = Off or Enabled. If enabled, the following criteria must be met for Express Speed operation: ASD output speed > F331 setting. ASD output torque < F335 setting. F331 and F335 condition exists for longer than F333 setting.	Direct Access Number — F328 Parameter Type — Selection List Factory Default — Off Changeable During Run — Yes

Express-Speed Learning Function

Program ⇒ Crane/Hoist

The **Express Speed** function accelerates the output frequency of the ASD from the programmed speed to the setting established in [F330](#) and is primarily used with **Crane/Hoist** functions.

The **Express-Speed Learning Function** is to be run with the maximum load that will allow for the **Express Speed** (Auto Speed ONLY) function to be engaged. During the execution of the **Express-Speed Learning Function** parameters [F335](#), [F336](#), [F337](#), and [F338](#) are automatically adjusted and set as a function of the load.

Application-specific adjustments may be required.

Note: *This function should be setup with a light load only.*

Settings:

Off
Forward/Reverse
Forward Only

Direct Access Number — [F329](#)

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **No**

Automatic Express-Speed Operation Frequency

Program⇒ Crane/Hoist ⇒ Express Speed

This parameter establishes the speed to which the ASD will ramp when operating in the **Express Speed** mode.

Direct Access Number — [F330](#)

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **No**

Minimum — 30.00

Maximum — **Upper Limit (F012)**

Units — Hz

Express-Speed Operation Switching Lower-Limit Frequency

Program⇒ Crane/Hoist ⇒ Express Speed

This parameter sets an output frequency threshold that, once surpassed, allows the **Express Speed** function to be used.

The **Express Speed** function may be used if the frequency threshold set at this parameter and the following conditions are met:

- 1) **Express-Speed Operation Enable** is configured at [F328](#).
- 2) The output torque is less than the setting established in [F335](#) when reaching the frequency setting here.

Direct Access Number — [F331](#)

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Minimum — 30.0

Maximum — **Upper Limit (F012)**

Units — Hz

Express-Speed Operation Load Wait Time

Program⇒ Crane/Hoist ⇒ Express Speed

This parameter determines the length of time that the load requirement must meet the **Express Speed** criteria before the **Express-Speed Enable (F328)** is recognized.

Once recognized, the timer setting of [F333](#) must expire to engage the **Express Speed** function.

Direct Access Number — [F332](#)

Parameter Type — **Numerical**

Factory Default — **0.5**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 10.0

Units — Seconds

Express-Speed Operation Detection Time Program⇒ Crane/Hoist ⇒ Express Speed After the time setting of F332 times out, this parameter determines the length of time that the Express Speed criteria must be met until the Express Speed function engages.	Direct Access Number — F333 Parameter Type — Numerical Factory Default — 1.0 Changeable During Run — Yes Minimum — 0.0 Maximum — 10.0 Units — Seconds
Express-Speed Operation Heavy-Load Detection Time Program⇒ Crane/Hoist ⇒ Express Speed While operating in the Express Speed mode, this parameter determines the length of time that a load exceeding the Express Speed operation criteria may exist before the Express Speed mode is terminated and normal operation resumes.	Direct Access Number — F334 Parameter Type — Numerical Factory Default — 0.5 Changeable During Run — Yes Minimum — 0.0 Maximum — 10.0 Units — Seconds
Switching Load Torque During Power Running Program⇒ Crane/Hoist ⇒ Express Speed During power running, this parameter establishes the threshold torque level that is used to determine if the Express Speed (F328) operation may engage or remain engaged if active. This parameter is automatically adjusted during Express-Speed Learning . If the Express Speed operation is terminated normal operation resumes. <i>Note: Power running may be during forward, reverse, acceleration, or deceleration, but not during regeneration.</i>	Direct Access Number — F335 Parameter Type — Numerical Factory Default — 40.00 Changeable During Run — No Minimum — -250.00 Maximum — +250.00 Units — %
Heavy-Load Torque During Power Running Program⇒ Crane/Hoist ⇒ Express Speed During power running, this parameter establishes the threshold torque level that is used to determine if the Express Speed (F328) operation may engage or remain engaged if active. If the Express Speed operation is terminated normal operation resumes.	Direct Access Number — F336 Parameter Type — Numerical Factory Default — 150.00 Changeable During Run — Yes Minimum — -250.00 Maximum — +250.00 Units — %
Heavy-Load Torque During Fixed-Speed Power Running Program⇒ Crane/Hoist ⇒ Express Speed During constant power running, this parameter establishes the threshold torque level that is used to determine if the Express Speed (F328) operation may engage or remain engaged if active. If the Express Speed operation is terminated normal operation resumes.	Direct Access Number — F337 Parameter Type — Numerical Factory Default — 150.00 Changeable During Run — Yes Minimum — -250.00 Maximum — +250.00 Units — %

Switching Load Torque During Dynamic Braking

Program ⇒ Crane/Hoist ⇒ Express Speed

During dynamic braking, this parameter establishes the threshold torque level that is used to determine if the **Express Speed (F328)** operation may engage or remain engaged if active.

If the **Express Speed** operation is terminated normal operation resumes.

Direct Access Number — F338

Parameter Type — **Numerical**

Factory Default — **30.00**

Changeable During Run — **Yes**

Minimum — -250.00

Maximum — +250.00

Units — %

Accel/Decel Suspended Function

Program ⇒ Fundamental ⇒ Acc/Dec 1

To maintain a constant speed setting while running, this parameter may be used to suspend speed changes for a user-set length of time.

The **Accel/Decel Suspend** function is enabled by setting this parameter to either **Terminal Board Input** or to **F350 – F353**.

Selecting **Terminal Board Input** at this parameter requires that a discrete input terminal be set to **Dwell Signal** (see [Table 7 on pg. 236](#) for a listing of available settings). Upon activation of the **Dwell Signal** terminal the output frequency remains at the at-activation speed for the duration of the activation. When deactivated the programmed accel or decel ramp resumes.

Selecting **F350 – F353** at this parameter requires that the acceleration and/or the deceleration **Suspend Frequency** and **Suspend Time** settings be completed at **F350, F351, F352, and F353**. Upon reaching the frequency setting of **F350** (Accel) or **F352** (Decel), the Accel/Decel ramp will cease and the output frequency will hold at the threshold frequency setting for the time setting of **F351** for acceleration or **F353** for deceleration.

Settings:

Off

F350 – F353 Settings

Terminal Board Input (ACE G9-120V-PCB)

Direct Access Number — F349

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **Yes**

Acceleration Suspend Frequency

Program ⇒ Fundamental ⇒ Acc/Dec 1

When **Enabled** at **F349**, this parameter is used to set the frequency at which the **Acceleration Suspend** function will activate.

During acceleration, this parameter sets the frequency at which acceleration will stop and the motor will run at the setting of this parameter for the time setting of **F351**.

Direct Access Number — F350

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Acceleration Suspend Time

Program ⇒ Fundamental ⇒ Acc/Dec 1

When **Enabled** at **F349**, this parameter is used to set the duration of activation of the **Acceleration Suspend** function when initiated by reaching the **Acceleration Suspend Frequency** setting (**F350**).

Once this parameter times out the acceleration rate will resume from the point of suspension.

Direct Access Number — F351

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 10.0

Units — Seconds

Deceleration Suspend Frequency

Program ⇒ Fundamental ⇒ Acc/Dec 1

When **Enabled** at F349, this parameter is used to set the frequency at which the **Deceleration Suspend** function will activate.

During deceleration, this parameter sets the frequency at which deceleration will stop and the motor will run at the setting of this parameter for the time setting of F353.

Direct Access Number — F352Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Deceleration Suspend Time

Program ⇒ Fundamental ⇒ Acc/Dec 1

When **Enabled** at F349, this parameter is used to set the duration of activation of the **Deceleration Suspend** function when initiated by reaching the **Deceleration Suspend Frequency** setting (F352).

Once this parameter times out the deceleration rate will resume from the point of suspension.

Direct Access Number — F353Parameter Type — **Numerical**Factory Default — **0.0**Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 10.0

Units — Seconds

Commercial Power/ASD Output Switching

Program ⇒ Terminal ⇒ Line Power Switching

This parameter **Enables/Disables** the **Commercial Power/ASD Output Switching** function.

When enabled, the system may be set up to discontinue using the output of the ASD and to switch to the commercial power in the event that 1) a trip is incurred, 2) a user-set frequency is reached, or 3) if initiated by a discrete input terminal.

Once set up with the proper switching frequency and hold times, the system will switch to commercial power upon reaching the **F355** frequency criterion.

Switching may also be accomplished manually by activating the discrete input terminal **Commercial Power ASD Switching**. Terminal activation forces the ASD output speed to accelerate to the **F355** switching frequency, resulting in the ASD-to-commercial power switching.

Deactivation of the discrete input terminal starts the hold-time counter setting (**F356**) for ASD-to-commercial power switching. Once timed out the motor resumes normal commercial power operation.

Settings:

- Off
- Switch at Signal Input and Trip
- Switch at Signal Input with Switching Frequency
- Switch at Signal Input and Trip with Switching Frequency

Switching Setup Requirements

F354 — Enable the switching function.

F355 — Set the switching frequency.

F356 — (Speed) Hold -time before applying ASD output after the switching criteria has been met.

F357 — (Speed) Hold -time before applying commercial power after the switching criteria has been met.


F358 — (Speed) Hold -time of applying commercial power after the switching criteria has been met.

Set a discrete input terminal to **Commercial Power ASD Switching**.

Set **OUT1** and **OUT2** to **Commercial Power/ASD Switching 1 and 2**, respectively.

Note: Ensure that the switching directions are the same and that **F311** is set to **Permit All**.

Note: The **OUT1** and **OUT2** outputs assigned to **Commercial Power/ASD Switching Output** are used to actuate the re-routing contactors.



Direct Access Number — **F354**

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **No**

Commercial Power/ASD Switching Frequency Program ⇒ Terminal ⇒ Line Power Switching When enabled at F354 and with a properly configured discrete output terminal, this parameter sets the frequency at which the At Frequency Powerline Switching function engages. The At Frequency Powerline Switching function commands the system to discontinue using the output of the ASD and to switch to commercial power once reaching the frequency set here. See parameter F354 for additional information on this setting.	Direct Access Number — F355 Parameter Type — Numerical Factory Default — 60.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
ASD-Side Switching Waiting Time Program ⇒ Terminal ⇒ Line Power Switching This parameter determines the amount of time that the ASD will wait before outputting a signal to the motor once the switch-to-ASD-output criteria has been met. See parameter F354 for additional information on this setting.	Direct Access Number — F356 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — Yes Minimum — 0.10 Maximum — 10.00 Units — Seconds
Commercial Power Side Switching Waiting Time Program ⇒ Terminal ⇒ Line Power Switching This parameter determines the amount of time that the ASD will wait before allowing commercial power to be applied to the motor once the switch-to-commercial-power criteria has been met. See parameter F354 for additional information on this setting.	Direct Access Number — F357 Parameter Type — Numerical Factory Default — 0.62 Changeable During Run — Yes Minimum — (ASD-Dependent) Maximum — 10.00 Units — Seconds
Commercial Power Switching Freq. Holding Time Program ⇒ Terminal ⇒ Line Power Switching This parameter determines the amount of time that the connection to commercial power is maintained once the switch-to-ASD-output criteria has been met. See parameter F354 for additional information on this setting.	Direct Access Number — F358 Parameter Type — Numerical Factory Default — 2.00 Changeable During Run — Yes Minimum — 0.10 Maximum — 10.00 Units — Seconds
PID Control Switching Program ⇒ Feedback ⇒ Feedback This parameter is used to set the PID control mode. Selecting Process PID uses the upper- and lower-limit settings of parameters F367 and F368 . Selecting Speed PID uses the upper- and lower-limit settings of parameters F370 and F371 . Settings: PID Off Process PID Speed PID Easy Positioning PID (Not Used)	Direct Access Number — F359 Parameter Type — Selection List Factory Default — PID Off Changeable During Run — No

PID Feedback Signal Program ⇒ Feedback ⇒ Feedback This parameter Enables/Disables PID feedback control. When enabled, this parameter determines the source of the motor-control feedback. Settings: PID Control Disabled V/I RR RX RX2 (AI1) Option V/I PG Feedback Option Proportional-Integral-Derivative (PID) — A closed-loop control technique that seeks error minimization by reacting to three values: One that is proportional to the error, one that is representative of the error, and one that is representative of the rate of change of the error.	Direct Access Number — F360 Parameter Type — Selection List Factory Default — PID Control Disabled Changeable During Run — Yes
PID Feedback Delay Filter Program ⇒ Feedback ⇒ Feedback This parameter determines the delay in the ASD output response to the motor-control feedback signal (signal source is selected at F360).	Direct Access Number — F361 Parameter Type — Numerical Factory Default — 0.1 Changeable During Run — Yes Minimum — 0.0 Maximum — 25.0
PID Feedback Proportional Gain Program ⇒ Feedback ⇒ Feedback This parameter determines the degree that the Proportional function affects the output signal. The larger the value entered here, the quicker the ASD responds to changes in feedback.	Direct Access Number — F362 Parameter Type — Numerical Factory Default — 0.10 Changeable During Run — Yes Minimum — 0.01 Maximum — 100.0
PID Feedback Integral Gain Program ⇒ Feedback ⇒ Feedback This parameter determines the degree that the Integral function affects the output signal. The smaller the value here, the more pronounced the effect of the integral function on the output signal.	Direct Access Number — F363 Parameter Type — Numerical Factory Default — 0.10 Changeable During Run — Yes Minimum — 0.01 Maximum — 100.00
PID Deviation Upper Limit Program ⇒ Feedback ⇒ Feedback This parameter determines the maximum amount that the feedback may increase the output signal.	Direct Access Number — F364 Parameter Type — Numerical Factory Default — 60.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 60.00 Units — Hz

PID Deviation Lower Limit Program ⇒ Feedback ⇒ Feedback This parameter determines the maximum amount that the feedback may decrease the output signal.	Direct Access Number — F365 Parameter Type — Numerical Factory Default — 60.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 60.00 Units — Hz
PID Feedback Differential Gain Program ⇒ Feedback ⇒ Feedback This parameter determines the degree that the Differential function affects the output signal. The larger the value entered here, the more pronounced the effect of the differential function for a given feedback signal level.	Direct Access Number — F366 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 2.55
Process Upper Limit Program ⇒ Feedback ⇒ Feedback Selecting Process PID at parameter F359 allows for this parameter setting to function as the Upper Limit while operating in the PID Control mode.	Direct Access Number — F367 Parameter Type — Numerical Factory Default — 60.00 Changeable During Run — No Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Process Lower Limit Program ⇒ Feedback ⇒ Feedback Selecting Process PID at parameter F359 allows for this parameter setting to function as the Lower Limit while operating in the PID Control mode.	Direct Access Number — F368 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — No Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
PID Control Wait Time Program ⇒ Feedback ⇒ Feedback This parameter is used to delay the start of PID control at start up. During the wait time set here, the ASD will follow the frequency control input of the process value and the feedback input will be ignored until this setting times out. At which time the PID setup assumes control.	Direct Access Number — F369 Parameter Type — Numerical Factory Default — 0 Changeable During Run — Yes Minimum — 0 Maximum — 2400 Units — Seconds
PID Output Upper Limit Program ⇒ Feedback ⇒ Feedback Selecting Speed PID at parameter F359 allows for this parameter setting to function as the Upper Limit while operating in the PID Control mode.	Direct Access Number — F370 Parameter Type — Numerical Factory Default — 60.00 Changeable During Run — No Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz

PID Output Lower Limit Program ⇒ Feedback ⇒ Feedback Selecting Speed PID at parameter F359 allows for this parameter setting to function as the Lower Limit while operating in the PID Control mode.	Direct Access Number — F371 Parameter Type — Numerical Factory Default — 4.00 Changeable During Run — Yes Minimum — Lower Limit (F013) Maximum — Upper Limit (F012) Units — Hz
Process Increasing Rate Program ⇒ Feedback ⇒ Feedback This parameter is used to limit the rate that the output of the ASD may increase for a given difference in the speed reference and the PID feedback value.	Direct Access Number — F372 Parameter Type — Numerical Factory Default — 10.0 Changeable During Run — Yes Minimum — 0.1 Maximum — 600.0 Units — Seconds
Process Decreasing Rate Program ⇒ Feedback ⇒ Feedback This parameter is used to limit the rate that the output of the ASD may decrease for a given difference in the speed reference and the PID feedback value.	Direct Access Number — F373 Parameter Type — Numerical Factory Default — 10.0 Changeable During Run — Yes Minimum — 0.1 Maximum — 600.0 Units — Seconds
Number of PG Input Pulses Program ⇒ Feedback ⇒ PG This parameter is used to set the number of pulses output from a shaft-mounted encoder that is used to indicate one revolution of rotation (360°) of the motor or of the motor-driven equipment.	Direct Access Number — F375 Parameter Type — Numerical Factory Default — 1024 Changeable During Run — No Minimum — 12 Maximum — 9999
Number of PG Input Phases Program ⇒ Feedback ⇒ PG This parameter determines the type of information that is supplied by the phase encoder. Settings: Single Phase Two Phase	Direct Access Number — F376 Parameter Type — Selection List Factory Default — Two Phase Changeable During Run — Yes

<p>PG Disconnection Detection</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>This parameter Enables/Disables the system's monitoring of the PG connection status when using encoders with line driver outputs.</p> <p><i>Note: The PG Vector Feedback Board option is required to use this feature.</i></p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled with Filter Enabled (Detect Momentary Power Failure) 	<p>Direct Access Number — F377</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Enabled (Detect Momentary Power Failure)</p> <p>Changeable During Run — Yes</p>
<p>Simple Positioning Completion Range</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>While operating in the Positioning Control mode, this parameter sets the range of accuracy for a Stop command initiated via the ACE G9-120V-PCB.</p> <p>If the setting is too low the stop may be too abrupt.</p>	<p>Direct Access Number — F381</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — Yes</p> <p>Minimum — 1</p> <p>Maximum — 4000</p>
<p>Autotune 1</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter sets the Autotune command status.</p> <p>Selecting Reset Motor Defaults for this parameter sets parameters F410, F411, F412, and F413 to the factory default settings.</p> <p>If selecting Autotune on Run Command, Autotune Initiated by Input Terminal, or Autotune of Detail Parameters for this parameter set the Base Frequency, Base Frequency Voltage, and the Motor Rated Revolutions to the nameplate values of the motor to achieve the best possible Autotune precision.</p> <p>Settings:</p> <ul style="list-style-type: none"> Autotune Disabled Reset Motor Defaults Enable Autotune on Run Command Autotuning by Input Terminal Signal (see Table 7 on pg. 236) Motor Constant Auto Calculation 	<p>Direct Access Number — F400</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Autotune Disabled</p> <p>Changeable During Run — No</p>
<p>Slip Frequency Gain</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter provides a degree of slip compensation for a given load. A higher setting here decreases the slip allowed for a given load/ASD output ratio.</p>	<p>Direct Access Number — F401</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 70</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 150</p> <p>Units — %</p>

Autotune 2 Program ⇒ Motor ⇒ Vector Motor Model This parameter introduces a thermal element into the autotuning equation and is used to automatically adjust the Autotune parameter values as a function of increases in the temperature of the motor. Settings: Off Self-Cooled Motor Tuning Forced Air Cooled Motor Tuning	Direct Access Number — F402 Parameter Type — Selection List Factory Default — Off Changeable During Run — No
Motor Rated Capacity Program ⇒ Motor ⇒ Vector Motor Model This parameter is used to set the (Nameplate) rated capacity of the motor being used.	Direct Access Number — F405 Parameter Type — Numerical Factory Default — 11.0 Changeable During Run — Yes Minimum — 0.1 Maximum — 500.00 Units — HP
Motor Rated Current Program ⇒ Motor ⇒ Vector Motor Model This parameter is used to set the (Nameplate) current rating of the motor being used.	Direct Access Number — F406 Parameter Type — Numerical Factory Default — 20.3 Changeable During Run — Yes Minimum — 0.1 Maximum — 2000.0 Units — Amps
Motor Rated RPM Program ⇒ Motor ⇒ Vector Motor Model This parameter is used input the (Nameplate) rated speed of the motor.	Direct Access Number — F407 Parameter Type — Numerical Factory Default — 1730 Changeable During Run — Yes Minimum — 100 Maximum — 60000 Units — RPM
Base Frequency Voltage 1 Program ⇒ Vector ⇒ Vector Motor Model The Motor Base Frequency Voltage 1 is the Motor 1 output voltage at the Base Frequency (F014). Regardless of the programmed value, the output voltage cannot be higher than the input voltage. The actual output voltage will be influenced by the input voltage of the ASD and the Supply Voltage Correction setting (F307).	Direct Access Number — F409 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — Yes Minimum — 50.0 Maximum — 660.0 Units — Volts

Motor Constant 1 (Torque Boost) Program ⇒ Motor ⇒ Vector Motor Model This parameter sets the primary resistance of the motor. Increasing this value can prevent a drop in the torque of the motor at low speeds. Increasing this value excessively can result in nuisance overload tripping.	Direct Access Number — F410 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — Yes Minimum — 0.0 Maximum — 30.0 Units — %
Motor Constant 2 (No-Load Current) Program ⇒ Motor ⇒ Vector Motor Model This parameter is used to set the current level required to excite the motor. Specifying a value that is too high for this parameter may result in hunting (erratic motor operation).	Direct Access Number — F411 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — No Minimum — 10 Maximum — 90 Units — %
Motor Constant 3 (Leak Inductance) Program ⇒ Motor ⇒ Vector Motor Model This parameter is used to set the leakage inductance of the motor. A larger setting here results in higher output torque at high speeds.	Direct Access Number — F412 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — Yes Minimum — 0 Maximum — 200 Units — %
Motor Constant 4 (Rated Slip) Program ⇒ Motor ⇒ Vector Motor Model This parameter is used to set the secondary resistance of the motor. An increase in this parameter setting results in an increase of compensation for motor slip.	Direct Access Number — F413 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — Yes Minimum — 0.01 Maximum — 25.00 Units — %
Exciting Strengthening Coefficient Program ⇒ Special ⇒ Special Parameters This parameter is used to increase the magnetic flux of the motor at low-speed. This feature is useful when increased torque at low speeds is required.	Direct Access Number — F415 Parameter Type — Numerical Factory Default — 100 Changeable During Run — Yes Minimum — 100 Maximum — 130 Units — %

Stall Prevention Factor 1

Program ⇒ Protection ⇒ Stall

This parameter is to be adjusted in the event that the motor stalls when operated above the base frequency.

If a momentary heavy load occurs the motor may stall before the load current reaches the stall prevention level setting of **F601**.

A drop in the supply voltage may cause fluctuations of the load current or may cause motor vibration. A gradual adjustment of this parameter may alleviate this condition.

Start with a setting of 85 at these parameters and gradually adjust them from there one at a time until the desired results are produced.

Adjustments to this parameter may increase the load current of the motor and subsequently warrant an adjustment at the **Motor Overload Protection Level** setting.

Direct Access Number — F416Parameter Type — **Numerical**Factory Default — **100**Changeable During Run — **No**

Minimum — 10

Maximum — 250

Torque Command

Program ⇒ Torque ⇒ Torque Control

When operating in the **Torque Control** mode, this parameter allows the user to select the source of the torque command signal.

Settings:

V/I

RR

RX

Panel Keypad (**F725** Setting)

RS485 2-Wire

RS485 4-Wire

Communication Option Board

RX2 Option (AI1)

Direct Access Number — F420Parameter Type — **Selection List**Factory Default — **Panel Keypad (**F725** Setting)**Changeable During Run — **Yes**

Tension Torque Bias Input

Program ⇒ Torque ⇒ Torque Control

This parameter **Enables/Disables** the **Tension Torque Bias** input function.

This feature is enabled by selecting a **Tension Torque Bias** input signal source.

Settings:

Disabled

V/I

RR

RX

Panel Keypad (Not Used)

RS485 2-Wire

RS485 4-Wire

Communication Option Board

RX2 Option (AI1)

Direct Access Number — F423Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

Load Sharing Gain Input

Program ⇒ Torque ⇒ Torque Control

This parameter **Enables/Disables** the **Load Sharing Gain** input function.

This feature is enabled by selecting a **Load Sharing Gain** input signal source.

Settings:

Disabled
V/I
RR
RX
Panel Keypad
RS485 2-Wire
RS485 4-Wire
Communication Option Board
RX2 Option (AI1)

Direct Access Number — F424

Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes****Forward Speed Limit Input**

Program ⇒ Torque ⇒ Torque Speed Limiting

This parameter **Enables/Disables** the **Forward Speed Limit Input** control function. When enabled and operating in the **Torque Control** mode, the forward speed limit is controlled by the input selected here.

If **Setting** is selected, the value set at F426 is used as the **Forward Speed Limit** input.

Settings:

Disabled
V/I
RR
RX
F426 Setting

Direct Access Number — F425

Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes****Forward Speed Limit Level**

Program ⇒ Torque ⇒ Torque Control

This parameter provides a value to be used as the **Forward Speed Limit** setting if **F426 Setting** is selected at F425.

Direct Access Number — F426

Parameter Type — **Numerical**Factory Default — **60.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Upper Limit (F012)**

Units — Hz

Reverse Speed Limit Input

Program ⇒ Torque ⇒ Torque Control

This parameter **Enables/Disables** the **Reverse Speed Limit Input** control function. When enabled and operating in the **Torque Control** mode, the reverse speed limit is controlled by the terminal selected here. If **Setting** is selected, the value set at [F428](#) is used as the **Reverse Speed Limit** input.

Settings:

Disabled
V/I
RR
RX
[F428](#) Setting

Direct Access Number — F427Parameter Type — **Selection List**Factory Default — **F428 Setting**Changeable During Run — **Yes****Reverse Speed Limit Input Level**

Program ⇒ Torque ⇒ Torque Control

This parameter provides a value to be used as the **Reverse Speed Limit** setting if **Setting** is selected at [F427](#).

Direct Access Number — F428Parameter Type — **Numerical**Factory Default — **60.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Upper Limit (F012)**

Units — Hz

Speed Limit (Torque=0) Center Value Reference

Program ⇒ Torque ⇒ Torque Speed Limiting

The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the **Torque Control** mode. This parameter sets the input terminal that will be used to control the allowable speed variance.

Settings:

Disabled
V/I
RR
RX
[F431](#) Setting

Direct Access Number — F430Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes****Speed Limit (Torque=0) Center Value**

Program ⇒ Torque ⇒ Torque Speed Limiting

The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the **Torque Control** mode. This parameter sets the targeted speed. The plus-or-minus value (range) for this setting may be set at [F432](#).

Direct Access Number — F431Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Speed Limit (Torque=0) Band Program ⇒ Torque ⇒ Torque Speed Limiting The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the Torque Control mode. This parameter sets a plus-or-minus value (range) for the Speed Limit Torque Level (F431).	Direct Access Number — F432 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
Allow Specified Direction ONLY Program ⇒ Torque ⇒ Torque Speed Limiting This parameter Enables/Disables the Forward Run or Reverse Run mode. If either direction is disabled, commands received for the disabled direction will not be recognized. If both directions are disabled, the received direction command will determine the direction of the motor rotation. Settings Disabled Enabled	Direct Access Number — F435 Parameter Type — Selection List Factory Default — Disabled Changeable During Run — No
Power Running Torque Limit 1 Program ⇒ Torque ⇒ Torque Limit This parameter determines the source of the control signal for the positive torque limit setting. If Setting is selected, the value set at F441 is used as the Power Running Torque Limit 1 input. Settings: V/I RR RX F441 Setting	Direct Access Number — F440 Parameter Type — Selection List Factory Default — F441 Setting Changeable During Run — Yes
Power Running Torque Limit 1 Level Program ⇒ Torque ⇒ Torque Limit This parameter provides a value for the Power Running Torque Limit 1 setting if F441 Setting is selected at parameter F440. This value provides the positive torque upper limit for the #1 motor.	Direct Access Number — F441 Parameter Type — Numerical Factory Default — 250.0 (Disabled) Changeable During Run — Yes Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %

<p>Dynamic Braking Torque Limit 1</p> <p>Program ⇒ Torque ⇒ Torque Limit</p> <p>This parameter determines the source of the Regenerative Torque Limit control signal.</p> <p>If Setting is selected, the value set at F443 is used for this parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> V/I RR RX F443 Setting 	<p>Direct Access Number — F442</p> <p>Parameter Type — Selection List</p> <p>Factory Default — F443 Setting</p> <p>Changeable During Run — Yes</p>
<p>Dynamic Braking Torque Limit 1 Level</p> <p>Program ⇒ Torque ⇒ Torque Limit</p> <p>This parameter provides a value to be used as the Regeneration Torque Limit 1 if F443 Setting is selected at parameter F442.</p> <p>Set this parameter to 250% to disable this function.</p>	<p>Direct Access Number — F443</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 249.9</p> <p>Units — %</p>
<p>Power Running Torque Limit 2 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the positive torque upper limit for the #2 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F444</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>
<p>Dynamic Braking Torque Limit 2 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the negative torque upper limit for the #2 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F445</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>
<p>Power Running Torque Limit 3 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the positive torque upper limit for the #3 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F446</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>

Dynamic Braking Torque Limit 3 Level Program ⇒ Torque ⇒ Manual Torque Limit This parameter is used to set the negative torque upper limit for the #3 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.	Direct Access Number — F447 Parameter Type — Numerical Factory Default — 250.0 (Disabled) Changeable During Run — Yes Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %
Power Running Torque Limit 4 Level Program ⇒ Torque ⇒ Manual Torque Limit This parameter is used to set the positive torque upper limit for the #4 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.	Direct Access Number — F448 Parameter Type — Numerical Factory Default — 250.0 (Disabled) Changeable During Run — Yes Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %
Dynamic Braking Torque Limit 4 Level Program ⇒ Torque ⇒ Manual Torque Limit This parameter is used to set the negative torque upper limit for the #4 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.	Direct Access Number — F449 Parameter Type — Numerical Factory Default — 250.0 (Disabled) Changeable During Run — Yes Minimum — 0.00 Maximum — 250.0 (Disabled) Units — %
Accel/Decel Operation After Torque Limit Program ⇒ Torque ⇒ Torque Limit In a Crane/Hoist application that is operating using a mechanical brake, this parameter is used to minimize the delay between the brake release and the output torque reaching a level that can sustain the load. This setting may reference time or the operating speed of the motor. Settings: In Sync with Accel/Decel In Sync with Minimum Time	Direct Access Number — F451 Parameter Type — Selection List Factory Default — In Sync with Accel/Decel Changeable During Run — Yes
Power Running Stall Continuous Trip Detection Time Program ⇒ Protection ⇒ Stall This parameter is used to extend the Over-Voltage Stall (F305) and the Over-Current Stall (F017) time settings.	Direct Access Number — F452 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — 0.0 Maximum — 1.0 Units — Seconds

Dynamic Braking Stall Prevention Mode Program ⇒ Protection ⇒ Stall The function of this parameter is to disable the Over-Voltage Stall (F305) and the Over-Current Stall (F017) function during regeneration <u>only</u> . Application-specific conditions may occur that warrant disabling the Stall function during regeneration. Settings: Disabled (Stall During Dynamic Braking) Enabled (No Stall During Dynamic Braking)	Direct Access Number — F453 Parameter Type — Selection List Factory Default — Enabled Changeable During Run — Yes
Current Control Proportional Gain Program ⇒ Feedback ⇒ PG This parameter sets the sensitivity of the ASD when monitoring the output current to control speed. The larger the value entered here, the more sensitive the ASD is to changes in the received feedback.	Direct Access Number — F458 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — No Minimum — 0.0 Maximum — 100.0
Speed Loop Proportional Gain Program ⇒ Feedback ⇒ PG During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control. The larger the value entered here, the larger the change in the output speed for a given received feedback signal.	Direct Access Number — F460 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — No Minimum — 1 Maximum — 9999
Speed Loop Stabilization Coefficient Program ⇒ Feedback ⇒ PG During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control. The larger the value entered here, the quicker the response to changes in the received feedback.	Direct Access Number — F461 Parameter Type — Numerical Factory Default — 100 Changeable During Run — Yes Minimum — 1 Maximum — 9999
Load Moment of Inertia 1 Program ⇒ Feedback ⇒ PG This parameter is used for calculating accel/decel torque when compensating for load inertia while operating in the Drooping Control mode.	Direct Access Number — F462 Parameter Type — Numerical Factory Default — 35 Changeable During Run — Yes Minimum — 0 Maximum — 100
Second Speed Loop Proportional Gain Program ⇒ Feedback ⇒ PG During closed-loop operation, this parameter sets the sensitivity of the ASD when monitoring the output speed for control. The larger the value entered here, the more sensitive the ASD is to changes in the received feedback.	Direct Access Number — F463 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — No Minimum — 1 Maximum — 9999

Second Speed Loop Stabilization Coefficient Program ⇒ Feedback ⇒ PG During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control. The larger the value entered here, the quicker the response to changes in the received feedback.	Direct Access Number — F464 Parameter Type — Numerical Factory Default — 1 Changeable During Run — Yes Minimum — 1 Maximum — 9999
Load Moment of Inertia 2 Program ⇒ Feedback ⇒ PG This parameter is used for calculating accel/decel torque when compensating for load inertia while operating in the Drooping Control mode.	Direct Access Number — F465 Parameter Type — Numerical Factory Default — 35 Changeable During Run — Yes Minimum — 0 Maximum — 100
Speed PID Switching Frequency Program ⇒ Feedback ⇒ Feedback While running, this parameter establishes the threshold speed setting that is used to determine if PID control may engage or remain engaged if active.	Direct Access Number — F466 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — Max. Freq. (F011) Units — Hz
V/I Input Bias Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine-tune the bias of the V/I input terminals. <i>Note: See note on pg. 55 for additional information on the V/I terminal.</i> This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system. This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.	Direct Access Number — F470 Parameter Type — Numerical Factory Default — 127 Changeable During Run — Yes Minimum — 0 Maximum — 255
V/I Input Gain Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the gain of the V/I input terminals. <i>Note: See note on pg. 55 for additional information on the V/I terminal.</i> This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system. This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	Direct Access Number — F471 Parameter Type — Numerical Factory Default — 129 Changeable During Run — Yes Minimum — 0 Maximum — 255

RR Input Bias Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the bias of the RR input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system. This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.	Direct Access Number — F472 Parameter Type — Numerical Factory Default — 128 Changeable During Run — Yes Minimum — 0 Maximum — 255
RR Input Gain Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the gain of the RR input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system. This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	Direct Access Number — F473 Parameter Type — Numerical Factory Default — 154 Changeable During Run — Yes Minimum — 0 Maximum — 255
RX Input Bias Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the bias of the RX input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system. This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.	Direct Access Number — F474 Parameter Type — Numerical Factory Default — 127 Changeable During Run — Yes Minimum — 0 Maximum — 255
RX Input Gain Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the gain of the RX input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system. This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	Direct Access Number — F475 Parameter Type — Numerical Factory Default — 127 Changeable During Run — Yes Minimum — 0 Maximum — 255

RX2 Option (AI1) Input Bias Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the bias of the RX2 (AI1) input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system. This is accomplished by setting the input source to zero and adjusting this setting to provide a zero output from the ASD.	Direct Access Number — F476 Parameter Type — Numerical Factory Default — 128 Changeable During Run — Yes Minimum — 0 Maximum — 255
RX2 Option (AI1) Input Gain Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the gain of the RX2 (AI1) input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system. This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	Direct Access Number — F477 Parameter Type — Numerical Factory Default — 128 Changeable During Run — Yes Minimum — 0 Maximum — 255
V/I Input Bias (AI2 Option Board Input) Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the bias of the Optional AI2 input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system. This is accomplished by setting the input source to zero and adjusting this setting to provide a zero output from the ASD.	Direct Access Number — F478 Parameter Type — Numerical Factory Default — 128 Changeable During Run — Yes Minimum — 0 Maximum — 255
V/I Input Gain (AI2 Option Board Input) Program ⇒ Frequency ⇒ Speed Reference Setpoints This parameter is used to fine tune the gain of the Optional AI2 input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode. This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system. This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.	Direct Access Number — F479 Parameter Type — Numerical Factory Default — 128 Changeable During Run — Yes Minimum — 0 Maximum — 255

Bearing Greaser Speed Multiplier Program ⇒ Crane/Hoist This parameter is used to reduce the motor speed once the Bearing Greaser (Alarm) Time (F621) setting has expired. Upon expiration of the Bearing Greaser (Alarm) Time setting, the commanded speed is multiplied by the factor set at this parameter to modify the speed of the motor.	Direct Access Number — F489 Parameter Type — Numerical Factory Default — 0.50 Changeable During Run — Yes Minimum — 0.00 Maximum — 1.00
Creep Multiplier 1 Program ⇒ Crane/Hoist ⇒ Creep Control This parameter provides a modifier for the output frequency of the ASD that multiplies the commanded frequency by the value set at this parameter. The Creep Multiplier 1 function may be activated via the EOI or a discrete input terminal on the ACE G9-120V-PCB (Creep Speed 1). This parameter setting has priority over the Creep Multiplier 2 (F491) setting.	Direct Access Number — F490 Parameter Type — Numerical Factory Default — 0.10 Changeable During Run — Yes Minimum — 0.00 Maximum — 1.00
Creep Multiplier 2 Program ⇒ Crane/Hoist ⇒ Creep Control This parameter provides a modifier for the output frequency of the ASD that multiplies the commanded frequency by the value set at this parameter. The Creep Multiplier 2 function may be activated via the EOI or a discrete input terminal on the ACE G9-120V-PCB (Creep Speed 2). The Creep Multiplier 2 function is ignored if the Creep Multiplier 1 (F490) function is active.	Direct Access Number — F491 Parameter Type — Numerical Factory Default — 0.10 Changeable During Run — Yes Minimum — 0.00 Maximum — 1.00
Creep Speed Lower Limit Program ⇒ Crane/Hoist ⇒ Creep Control This parameter sets the lower limit while operating in the Creep mode. This setting supersedes the Lower-Limit Frequency setting of F013.	Direct Access Number — F492 Parameter Type — Numerical Factory Default — 0.60 Changeable During Run — No Minimum — 0.00 Maximum — 30.0 Units — Hz
Express Stop Program ⇒ Crane/Hoist This parameter Enables/Disables the ability of the ASD to use an alternate Decel rate when a Stop command is received. The Express-Stop Deceleration Time is set at F511. Settings: Disabled Enabled	Direct Access Number — F493 Parameter Type — Selection Factory Default — Disabled Changeable During Run — Yes

<p>Plugging</p> <p>Program ⇒ Crane/Hoist</p> <p>This parameter Enables/Disables the Plugging feature of the ASD. Plugging assigns alternate Acceleration and Deceleration time settings to be used during a direction change only.</p> <p>The Plugging acceleration and deceleration times are set at parameters F514 and F515, respectively.</p> <p>This parameter is further defined by the ACC/DEC Pattern selection of F516.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F494</p> <p>Parameter Type — Selection</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — Yes</p>
<p>PM Motor Constant 1 (D Axis Inductance)</p> <p>Program ⇒ Motor ⇒ PM Motor</p> <p>This parameter is used with synchronous motor applications only.</p> <p>Contact ACE World Companies Customer Support Center for information on this parameter.</p>	<p>Direct Access Number — F498</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>PM Motor Constant 2 (Q Axis Inductance)</p> <p>Program ⇒ Motor ⇒ PM Motor</p> <p>This parameter is used with synchronous motor applications only.</p> <p>Contact ACE World Companies Customer Support Center for information on this parameter.</p>	<p>Direct Access Number — F499</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>Acceleration Time 2</p> <p>Program ⇒ Special ⇒ Acc/Dec 1 – 4</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the Maximum Frequency for the #2 Deceleration profile.</p> <p>The Accel/Decel pattern may be set using F503. This parameter may be further defined by the settings of F506 – F509.</p> <p>Note: <i>An acceleration time shorter than that which the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel, Stall, and Ridethrough settings may lengthen the actual acceleration times.</i></p>	<p>Direct Access Number — F500</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 6000.0</p> <p>Units — Seconds</p>

Deceleration Time 2

Program ⇒ Fundamental ⇒ Acc/Dec 1

This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz for the **#2 Deceleration** profile.

The Accel/Decel pattern may be set using [F503](#). This parameter may be further defined by the settings of [F506 – F509](#).

***Note:** A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel**, **Stall**, and **Ridethrough** settings may lengthen the actual deceleration times.*

Direct Access Number — F501

Parameter Type — **Numerical**

Factory Default — (ASD-Dependent)

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

Acc/Dec Pattern 1Program \Rightarrow Special \Rightarrow Accel/Decel 1 – 4

This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the **#1 Accel/Decel** profile.

Settings:

Linear
S-Pattern 1
S-Pattern 2

Direct Access Number — F502


Parameter Type — Selection List

Factory Default — Linear


Changeable During Run — Yes

The figures below provide a profile of the available accel/decel patterns.


Linear acceleration and deceleration is the default pattern and is used on most applications.



S-Pattern 1 is used for applications that require quick acceleration and deceleration. This setting is also popular for applications that require shock absorption at the start of acceleration or deceleration.



S-Pattern 2 decreases the rate of change above the base frequency for acceleration and deceleration.



Acc/Dec Pattern 2

Program ⇒ Special ⇒ Accel/Decel 1 – 4

This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the **#2 Accel/Decel** profile.

See [F502](#) for additional information on this parameter.

Settings:

- Linear
- S-Pattern 1
- S-Pattern 2

Direct Access Number — F503

Parameter Type — **Selection List**

Factory Default — **Linear**

Changeable During Run — **Yes**

Acc/Dec Pattern 1 – 4

Program ⇒ Special ⇒ Acc/Dec Special

Four acceleration times and four deceleration times may be set up and run individually. One of four accel/decel times may be selected by 1) using this parameter selection, 2) by discrete input terminal, or 3) switched via user-set threshold frequencies.

This parameter is used to select one of the four configured accel/decel profiles to be used.

Settings:

Acc/Dec 1 (F009/F010)

Acc/Dec 2 (F500/F501)

Acc/Dec 3 (F510/F511)

Acc/Dec 4 (F514/F515)

Each Accel/Decel selection is comprised of an **Acceleration Time**, **Deceleration Time**, and a **Pattern** selection. Selection 1, 2, and 3 have a **Switching Frequency** setting. The **Switching Frequency** is used as a threshold frequency that, once reached, the ASD switches to the next **Acc/Dec** selection. **Switching Frequency** settings are used during acceleration and deceleration. A switching frequency setting is not required for **Acc/Dec 4**.

Acc/Dec 1 is set up using parameters F009 (Acc Time), F010 (Dec Time), F502 (Pattern), and F505 (Switching Frequency).

Acc/Dec 2 is set up using parameters F500 (Acc Time), F501 (Dec Time), F503 (Pattern), and F513 (Switching Frequency).

Acc/Dec 3 is set up using parameters F510 (Acc Time), F511 (Dec Time), F512 (Pattern), and F517 (Switching Frequency).

Acc/Dec 4 is set up using parameters F514 (Acc Time), and F515 (Dec Time), F516 (Pattern).

This parameter (F504) is used to manually select **Acc/Dec 1 – 4**.

To switch using the **ACE G9-120V-PCB**, assign the functions **Acc/Dec Switching 1** and **Acc/Dec Switching 2** to two discrete input terminals. Activation combinations of the two terminals result in the **Acc/Dec 1 – 4** selections as shown in Table 6.

Figure 31 shows the setup requirements and the resulting output frequency response when using **Switching Frequency** settings to control the **Acc/Dec** response of the ASD output.

While operating using **S-Pattern 1** the system performance may be further defined by the adjustment of parameters F506 – F509. These settings provide for upper and lower **Acc/Dec** limit adjustments. These settings are used to extend or shorten the upper or lower **Acc/Dec** curve.

Note: If operating from the **Local** mode, press **Esc** from the **Frequency Command** screen to access this parameter (ACC/DEC Group).

Accel/Decel Switching Frequency 1

Program ⇒ Special ⇒ Accel/Decel Special

This parameter sets the frequency at which the acceleration control is switched from the **Accel 1** profile to the **Accel 2** profile during a multiple-acceleration profile configuration.

Direct Access Number — F504

Parameter Type — Selection List

Factory Default — 1


Changeable During Run — Yes

Table 6.

Using combinations of discrete terminal activations Accel/Decel profiles 1–4 may be selected.

Acc/Dec Switching Truth		
A/D SW 1	A/D SW 2	Acc/Dec # Out
0	0	1
0	1	2
1	0	3
1	1	4
1 = Discrete terminal activation.		

Figure 31. Using Acc/Dec Switching.



- 1 — Accel Time 1 (F009 Setting)
- 2 — Accel Time 2 (F500 Setting)
- 3 — Accel Time 3 (F510 Setting)
- 4 — Accel Time 4 (F514 Setting)
- 5 — Decel Time 4 (F515 Setting)
- 6 — Decel Time 3 (F511 Setting)
- 7 — Decel Time 2 (F501 Setting)
- 8 — Decel Time 1 (F510 Setting)

Direct Access Number — F505

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz

S-Pattern Acceleration Lower-Limit Adjustment Program ⇒ Special ⇒ Accel/Decel Special During an S-Pattern 1 or 2 sequence, this parameter setting modifies the acceleration rate for the lower part of the acceleration curve by the percentage set here. This function is commonly used with transportation and lifting applications. See parameter F502 on pg. 170 for additional information on this setting.	Direct Access Number — F506 Parameter Type — Numerical Factory Default — 10 Changeable During Run — Yes Minimum — 0 Maximum — 50 Units — %
S-Pattern Acceleration Upper-Limit Adjustment Program ⇒ Special ⇒ Accel/Decel Special During an S-Pattern 1 or 2 sequence, this parameter setting modifies the acceleration rate for the upper part of the acceleration curve by the percentage set here. This function is commonly used with transportation and lifting applications. See parameter F502 on pg. 170 for additional information on this setting.	Direct Access Number — F507 Parameter Type — Numerical Factory Default — 10 Changeable During Run — Yes Minimum — 0 Maximum — 50 Units — %
S-Pattern Deceleration Lower-Limit Adjustment Program ⇒ Special ⇒ Accel/Decel Special During an S-Pattern 1 or 2 sequence, this parameter setting modifies the deceleration rate for the lower part of the deceleration curve by the percentage set here. This function is commonly used with transportation and lifting applications. See parameter F502 on pg. 170 for additional information on this setting.	Direct Access Number — F508 Parameter Type — Numerical Factory Default — 10 Changeable During Run — Yes Minimum — 0 Maximum — 50 Units — %
S-Pattern Deceleration Upper-Limit Adjustment Program ⇒ Special ⇒ Accel/Decel Special During an S-Pattern 1 or 2 sequence, this parameter setting modifies the deceleration rate for the upper part of the deceleration curve by the percentage set here. This function is commonly used with transportation and lifting applications. See parameter F502 on pg. 170 for additional information on this setting.	Direct Access Number — F509 Parameter Type — Numerical Factory Default — 10 Changeable During Run — Yes Minimum — 0 Maximum — 50 Units — %
Acceleration Time 3 Program ⇒ Special ⇒ Accel/Decel 1 – 4 This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the Maximum Frequency for the #3 Acceleration profile. The Accel/Decel pattern may be set using F502 . The minimum Accel/Decel time may be set using F508 . Note: <i>An acceleration time shorter than that which the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel, Stall, and Ridethrough settings may lengthen the actual acceleration times.</i>	Direct Access Number — F510 Parameter Type — Numerical Factory Default — (ASD-Dependent) Changeable During Run — Yes Minimum — 0.1 Maximum — 6000 Units — Seconds

Express Stop Decel Time

Program ⇒ Special ⇒ Accel/Decel 1 – 4

This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz during an **Express Stop**. When enabled at [F493](#), this setting is used as an alternate deceleration time.

The **Accel/Decel Pattern** may be set using [F512](#).

This parameter may be further defined by the settings of [F506](#) – [F509](#).

Note: *A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel**, **Stall**, and **Ridethrough** settings may lengthen the actual deceleration times.*

Direct Access Number — F511

Parameter Type — **Numerical**

Factory Default — **1.5**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

Express Stop Acceleration/Deceleration Pattern

Program ⇒ Special ⇒ Accel/Decel 1 – 4

This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern during an **Express Stop**.

See [F502](#) for additional information on this parameter.

Settings:

Linear

S-Pattern 1

S-Pattern 2

Direct Access Number — F512

Parameter Type — **Selection List**

Factory Default — **Linear**

Changeable During Run — **Yes**

Acceleration/Deceleration Switching Frequency 2

Program ⇒ Special ⇒ Accel/Decel Special

This parameter sets the frequency at which the acceleration control is switched from the **Accel #2** profile to the **Accel #3** profile during a multiple-acceleration profile configuration.

Direct Access Number — F513

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Plugging Acceleration Time

Program ⇒ Special ⇒ Accel/Decel 1 – 4

This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the **Maximum Frequency** during **Plugging**. When enabled at [F494](#), this setting is used as an alternate acceleration time.

The **Plugging Acc/Dec Pattern** may be selected at [F516](#).

This parameter may be further defined by the settings of [F506](#) – [F509](#).

See [F494](#) for additional information on the **Plugging** function.

Note: *An acceleration time shorter than that which the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel**, **Stall**, and **Ridethrough** settings may lengthen the actual acceleration times.*

Direct Access Number — F514

Parameter Type — **Numerical**

Factory Default — **1.5**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

<p>Plugging Deceleration Time</p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from the Maximum Frequency to 0.0 Hz during Plugging. When enabled at F494, this setting is used as an alternate deceleration time.</p> <p>The Plugging Acc/Dec Pattern may be selected at F516.</p> <p>This parameter may be further defined by the settings of F506 – F509.</p> <p>See F494 for additional information on the Plugging function.</p> <p>Note: <i>A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel, Stall, and Ridethrough settings may lengthen the actual deceleration times.</i></p>	<p>Direct Access Number — F515</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.5</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p>Plugging Acceleration/Deceleration Pattern</p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4</p> <p>This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern while Plugging.</p> <p>See F502 for additional information on this parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> Linear S-Pattern 1 S-Pattern 2 	<p>Direct Access Number — F516</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Linear</p> <p>Changeable During Run — Yes</p>
<p>Acceleration/Deceleration Switching Frequency 3</p> <p>Program ⇒ Special ⇒ Accel/Decel Special</p> <p>This parameter sets the frequency at which the acceleration control is switched from the Accel #3 profile to the Accel #4 profile during a multiple-acceleration profile configuration.</p>	<p>Direct Access Number — F517</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Motor Overload Protection Level 1</p> <p>Program ⇒ Fundamental ⇒ Motor Set 1</p> <p>This parameter specifies the motor overload current level for motor set 1. This value is entered as either a percentage of the full-load rating of the ASD or as a percentage of the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to A/V (Amps) or it may be set as a percentage of the ASD rating. The nameplate FLA of the motor may be entered directly when Amps is selected as the unit of measurement (see F701 to change the display unit).</p> <p>Motor Overload Protection Level 1 settings will be displayed in Amps if the EOI display units are set to A/V rather than %.</p>	<p>Direct Access Number — F600</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — Yes</p> <p>Minimum — 10</p> <p>Maximum — 100.0</p> <p>Units — %</p>

<p>Stall Prevention Level</p> <p>Program ⇒ Protection ⇒ Stall</p> <p>This parameter specifies the output current level at which the output frequency is reduced in an attempt to prevent a trip. The over-current level is entered as a percentage of the maximum rating of the ASD.</p> <p><i>Note: The Motor Overload Protection parameter must be enabled at F017 to use this feature.</i></p>	<p>Direct Access Number — F601</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 150</p> <p>Changeable During Run — Yes</p> <p>Minimum — 10</p> <p>Maximum — 165</p> <p>Units — % (or A; see F701 setting)</p>
<p>Retain Trip Record at Power Down</p> <p>Program ⇒ Protection ⇒ Trip</p> <p>This parameter Enables/Disables the Trip Record Retention setting. When enabled, this feature logs the trip event and retains the trip information when the system powers down. The trip information may be viewed from the (Program ⇒ Utilities ⇒) Trip History screen or the Monitor screen.</p> <p>When disabled, the trip information will be cleared when the system powers down.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F602</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — Yes</p>
<p>Emergency Off Mode</p> <p>Program ⇒ Protection ⇒ Emergency Off</p> <p>This parameter determines the method used to stop the motor in the event that an Emergency Off command is received and the system is configured to use this feature.</p> <p>This setting may also be associated with the BRAKE terminals to allow the BRAKE relay to change states when an EOFF condition occurs by setting the BRAKE output to Emergency Off Active (see F132).</p> <p><i>Note: A supplemental emergency stopping system should be used with the ASD. Emergency stopping should not be a task of the ASD alone.</i></p> <p>Settings:</p> <ul style="list-style-type: none"> Coast Stop Deceleration Stop DC Injection Braking Stop Deceleration Stop (Decel 4 setting; F515) 	<p>Direct Access Number — F603</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Coast Stop</p> <p>Changeable During Run — No</p>
<p>Emergency Off DC Braking Control Time</p> <p>Program ⇒ Protection ⇒ Emergency Off</p> <p>When DC Injection is selected at F603 this parameter determines the time that the DC Injection braking is applied to the motor.</p>	<p>Direct Access Number — F604</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 20.0</p> <p>Units — Seconds</p>

ASD Output Phase Failure Detection Program ⇒ Protection ⇒ Phase Loss This parameter Enables/Disables the monitoring of each phase of the 3-phase output signal (U, V, or W) of the ASD. If either line is missing, inactive, or not of the specified level for one second or more, the ASD incurs a trip. <i>Note: Autotune checks for phase failures regardless of this setting.</i> Settings: Disabled (No Detection) Enabled (Run at Startup and Retry) Enabled (Every Run Command and Retry) Enabled (During Run) Enabled (At Startup and During Run) Enabled (Detects an ALL-PHASE Failure ONLY - Will Not Trip, Restarts at Reconnect)	Direct Access Number — F605 Parameter Type — Selection List Factory Default — Disabled Changeable During Run — No
Overload Reduction Start Frequency Program ⇒ Protection ⇒ Overload This parameter is primarily used with V/f motors. It is used to reduce the starting frequency at which the Overload Reduction function begins and is useful during extremely low-speed motor operation. During very low-speed operation the cooling efficiency of the motor decreases. Lowering the start frequency of the Overload Reduction function aides in minimizing the generated heat and precluding an Overload trip. This function is useful in loads such as fans, pumps, and blowers that have the square reduction torque characteristic. Set parameter F607 to the desired Overload Time Limit .	Direct Access Number — F606 Parameter Type — Numerical Factory Default — 6.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 30.00 Units — Hz
Motor 150% Overload Time Limit Program ⇒ Protection ⇒ Overload This parameter establishes a time that the motor may operate at 150% of its rated current before tripping. This setting applies the time/150% reference to the individual settings of each motor (e.g., this setting references 150% of the F600 setting for the #1 motor). The unit will trip sooner than the time entered here if the overload is greater than 150%.	Direct Access Number — F607 Parameter Type — Numerical Factory Default — 300 Changeable During Run — Yes Minimum — 10 Maximum — 2400 Units — Seconds
ASD Input Phase Failure Detection Program ⇒ Protection ⇒ Phase Loss This parameter enables the 3-phase input power phase loss detection feature. A loss of either input phase (R, S, or T) results in a trip. Settings: Disabled Enabled	Direct Access Number — F608 Parameter Type — Selection List Factory Default — Enabled Changeable During Run — No

Low-Current Detection Hysteresis Width Program ⇒ Protection ⇒ Low Current During a momentary low-current condition, this parameter provides a current threshold level to which the low-current condition must return within the time setting of F612 or a Low-Current Trip will be incurred.	Direct Access Number — F609 Parameter Type — Numerical Factory Default — 10 Changeable During Run — Yes Minimum — 1 Maximum — 20 Units — %
Low-Current Trip Program ⇒ Protection ⇒ Low Current This parameter Enables/Disables the low-current trip feature. When enabled, the ASD will trip on a low-current fault if the output current of the ASD falls below the level defined at F611 and remains there for the time set at F612 . Settings: Disabled Enabled	Direct Access Number — F610 Parameter Type — Selection List Factory Default — Disabled Changeable During Run — No
Low-Current Detection Current Program ⇒ Protection ⇒ Low Current With the Low-Current Trip (F610) parameter enabled, this function sets the low-current trip threshold. The threshold value is entered as a percentage of the maximum rating of the ASD.	Direct Access Number — F611 Parameter Type — Numerical Factory Default — 0 Changeable During Run — Yes Minimum — 0 Maximum — 100 Units — % (or A; see F701 setting)
Low-Current Detection Time Program ⇒ Protection ⇒ Low Current With the Low-Current Trip (F610) parameter enabled, this function sets the time that the low-current condition must exist to cause a trip.	Direct Access Number — F612 Parameter Type — Numerical Factory Default — 0 Changeable During Run — Yes Minimum — 0 Maximum — 255 Units — Seconds
Short Circuit Detection At Start Program ⇒ Protection ⇒ Special Protection Parameters This parameter determines when the system will perform an Output Short Circuit test. Note: <i>Selection 3 is recommended for high-speed motor applications. Because of the low impedance of high-speed motors the standard-pulse setting may result in a motor malfunction.</i> Settings: Every Start (Standard Pulse) Power On or Reset (Standard Pulse) Every Start (Short Pulse) Power On or Reset (Short Pulse)	Direct Access Number — F613 Parameter Type — Selection List Factory Default — Every Start (standard pulse) Changeable During Run — No

<p>Over-Torque Trip</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>This parameter Enables/Disables the Over-Torque Tripping function.</p> <p>When enabled, the ASD trips if an output torque value greater than the setting of F616 or F617 exists for a time longer than the setting of F618.</p> <p>When disabled, the ASD does not trip due to over-torque conditions.</p> <p>Note: A discrete output terminal may be activated when an over-torque alarm occurs if so configured (see F130).</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F615</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Enabled</p> <p>Changeable During Run — No</p>
<p>Over-Torque Detection Level During Power Running</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>This parameter sets the torque threshold level that is used as a setpoint for over-torque tripping during positive torque. This setting is a percentage of the maximum rated torque of the ASD.</p> <p>This function is enabled at F615.</p>	<p>Direct Access Number — F616</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 150.00</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 250.00</p> <p>Units — %</p>
<p>Over-Torque Detection Level During Dynamic Braking</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>This parameter sets the torque threshold level that is used as a setpoint for over-torque tripping during negative torque (regen). This setting is a percentage of the maximum rated torque of the ASD.</p> <p>This function is enabled at F615.</p>	<p>Direct Access Number — F617</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 180.00</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 250.00</p> <p>Units — %</p>
<p>Over-Torque Detection Time</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>This parameter sets the amount of time that the over-torque condition may exceed the tripping threshold level set at F616 and F617 before a trip occurs.</p> <p>This function is enabled at F615.</p>	<p>Direct Access Number — F618</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 2.50</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>
<p>Over-Torque Detection Hysteresis</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>During a momentary over-torque condition, this parameter provides a torque threshold level to which the over-torque condition must return within the time setting of F618 or an Over-Torque Trip will be incurred.</p>	<p>Direct Access Number — F619</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 100.00</p> <p>Units — %</p>

Cooling Fan Control Program ⇒ Protection ⇒ Special Protection Parameters This parameter sets the cooling fan run-time command. Settings: Automatic Always On	Direct Access Number — F620 Parameter Type — Selection List Factory Default — Always On Changeable During Run — Yes
Bearing Greaser (Alarm) Time Program ⇒ Protection ⇒ Special Protection Parameters This parameter Enables/Disables the Maintenance Timer Alarm . The timer sets a run-time value in hours that, once exceeded, initiates the Maintenance Timer Alarm . This setting, in conjunction with the setting of F489 , may also affect the commanded speed of the motor by providing a value for the Bearing Greaser Speed Multiplier , if so configured. A discrete output contactor may be set to Total-Operation-Hours Alarm to control ancillary equipment (e.g., engage a brake) upon activation of the discrete output contactor. This feature is disabled by setting this parameter to Zero . See Table 10 on pg. 242 for additional information on output terminal selections.	Direct Access Number — F621 Parameter Type — Numerical Factory Default — 0 Changeable During Run — Yes Minimum — 0 Maximum — 65535 Units — Hour
Abnormal Speed Detection Time Program ⇒ Protection ⇒ Abnormal Speed This parameter sets the time that an over-speed condition must exist to cause a trip. This parameter functions in conjunction with the settings of F623 and F624 .	Direct Access Number — F622 Parameter Type — Numerical Factory Default — 1.00 Changeable During Run — Yes Minimum — 0.01 Maximum — 100.00 Units — Seconds
Over-Speed Detection Frequency Upper Band Program ⇒ Protection ⇒ Abnormal Speed This parameter sets the upper level of the Base Frequency range that, once exceeded, will cause an Over-Speed Detected alarm. This parameter functions in conjunction with the settings of F622 and F624 .	Direct Access Number — F623 Parameter Type — Numerical Factory Default — 5.00 Changeable During Run — Yes Minimum — 0.0 (Disabled) Maximum — 30.00 Units — Hz
Over-Speed Detection Frequency Lower Band Program ⇒ Protection ⇒ Abnormal Speed This parameter sets the lower level of the Base Frequency range that, once the output speed falls below this setting, will cause a Speed Drop Detected alarm. This parameter functions in conjunction with the settings of F622 and F623 .	Direct Access Number — F624 Parameter Type — Numerical Factory Default — 5.00 Changeable During Run — Yes Minimum — 0.00 (Disabled) Maximum — 30.00 Units — Hz

<p>Over-Voltage Limit Operation Level</p> <p>Program ⇒ Protection ⇒ Stall</p> <p>This parameter sets the upper DC bus voltage threshold that, once exceeded, will cause an Over-Voltage Stall. An Over-Voltage Stall increases the output frequency of the ASD during deceleration for a specified time in an attempt to prevent an Over-Voltage Trip.</p> <p>If the over-voltage condition persists for over 4 mS, an Over-Voltage Trip will be incurred.</p> <p>This parameter is enabled at F305.</p> <p><i>Note: This parameter setting may increase deceleration times.</i></p>	<p>Direct Access Number — F626</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 100</p> <p>Maximum — 150</p> <p>Units — %</p>
<p>Under-Voltage Trip</p> <p>Program ⇒ Protection ⇒ Under-Voltage/Ridethrough</p> <p>This parameter Enables/Disables the Under-Voltage Trip function.</p> <p>With this parameter Enabled, the ASD will trip if the under-voltage condition persists for a time greater than the F628 setting.</p> <p>A user-selected contact may be actuated if so configured.</p> <p>If Disabled the ASD will stop and not trip; the BRAKE contacts are not affected.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F627</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Enabled</p> <p>Changeable During Run — No</p>
<p>Under-Voltage (Trip Alarm) Detection Time</p> <p>Program ⇒ Protection ⇒ Under-Voltage/Ridethrough</p> <p>This parameter sets the time that the under-voltage condition must exist to cause an Under-Voltage Trip.</p> <p>This parameter is enabled at F627.</p>	<p>Direct Access Number — F628</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.03</p> <p>Changeable During Run — No</p> <p>Minimum — 0.01</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p>Regenerative Power Ridethrough Control Level</p> <p>Program ⇒ Protection ⇒ Under-Voltage/Ridethrough</p> <p>This parameter is activated during regeneration. It is used to set the low end of the DC bus voltage threshold that, once the bus voltage drops below this setting, activates the setting of F302 (Ridethrough Mode).</p> <p>Activation may be the result of a momentary power loss or an excessive load on the bus voltage.</p> <p>During a Ridethrough, regenerative energy is used to maintain the control circuitry settings for the duration of the Ridethrough; it is not used to drive the motor.</p> <p>The motor(s) of the system are stopped and then restarted automatically or may continue seamlessly if so configured.</p> <p>See F302 for additional information on this parameter.</p> <p><i>Note: This parameter setting may increase deceleration times.</i></p>	<p>Direct Access Number — F629</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — No</p> <p>Minimum — 55</p> <p>Maximum — 100</p> <p>Units — %</p>

Brake Answer Wait Time

Program ⇒ Protection ⇒ Special Protection Parameters

This parameter is used in conjunction with the discrete input terminal setting **Brake Answerback Input** (see [Table 7](#) on [pg. 236](#) for additional information on this feature).

After activating the discrete input terminal **Braking Request**, the setting of this parameter starts a count-down timer in which 1) a **Brake Answerback Input** response must be received or 2) the brake must release before the timer expires.

Should this timer setting expire before the **Brake Answerback Input** is returned or the brake releases, a **Brake Sequence Response Error** (E-11) is incurred. Otherwise, the brake releases and normal motor operations resume.

Direct Access Number — F630

Parameter Type — **Numerical**

Factory Default — **0.0 (Disabled)**

Changeable During Run — **Yes**

Minimum — 0.0 (Disabled)

Maximum — 10.0

Units — Seconds

ASD Overload

Program ⇒ Protection ⇒ Overload

This parameter is used to protect the ASD from an over-current condition. The standard overload rating of the ACE-tronics G9 ASD is 150% operation for 60 seconds.

This setting allows for the overload protection to be switched from the standard overload detection means (Thermal Detection and Overload) to thermal detection only.

Settings:

Thermal Detection + Overload

Thermal Detection Only

The **Thermal Detection Only** selection is used when multiple devices are installed horizontally as described on [pg. 15](#).

Direct Access Number — F631

Parameter Type — **Selection List**

Factory Default — **Thermal Detection + Overload**

Changeable During Run — **No**

V/I Analog Input Breakage Detection Level

Program ⇒ Terminal ⇒ Input Special Functions

This parameter is enabled by providing a non-zero value here. This function monitors the **V/I** input signal and if the **V/I** input signal falls below the level specified here and remains there for a period of 0.3 seconds or more a trip will be incurred (E-18).

This value is entered as 0% to 100% of the **V/I** input signal range.

Direct Access Number — F633

Parameter Type — **Numerical**

Factory Default — **0 (Disabled)**

Changeable During Run — **No**

Minimum — 1

Maximum — 100

Units — %

Annual Average Ambient Temperature

Program ⇒ Special ⇒ Special Parameters

This parameter is used in conjunction with a discrete output terminal setting to notify the operator of the remaining useful life of critical components of the ASD system.

With a discrete output terminal set to **Part Replacement Alarm** (see [Table 10 on pg. 242](#)) and the calculation derived from the parameter setting, maintenance scheduling may be enhanced.

Settings:

- Under 10° C (50° F) — 60,000 Hours
- Under 20° C (68° F) — 60,000 Hours
- Under 30° C (86° F) — 60,000 Hours
- Under 40° C (104° F) — 60,000 Hours
- Under 50° C (122° F) — 40,000 Hours
- Under 60° C (140° F) — 2,666 Hours

Direct Access Number — F634

Parameter Type — Selection List

Factory Default — Under 30°

Changeable During Run — No

Rush Current Suppression Replay Activation Time

Program ⇒ Special ⇒ Special Parameters⇒ Rush Relay Current Activation Time

At system startup, this parameter sets a time-delay for the start of the **Rush Relay** activation in an attempt to allow the DC bus voltage to reach the normal operating level before outputting a signal to the motor.

Direct Access Number — F635

Parameter Type — Numerical

Factory Default — 0.0

Changeable During Run — No

Minimum — 0.0

Maximum — 2.5

Units — Seconds

PTC1 Thermal Selection

Program ⇒ Special ⇒ Special Parameters⇒ PTC1 Thermal Selection

This parameter **Enables/Disables** the optional external thermal detection circuit of the **Expansion IO Card Option 1**. A thermistor is connected from **TH1+** to **TH1-** of **TB3** on the **Expansion IO Card Option 1**.

Should the thermistor resistance reading fall below 50Ω because of an over-temperature condition or exceed 3000Ω because of an open circuit an **External Thermal Fault** (OH2) will be incurred.

Note: While this parameter is **Enabled**, the system cannot be restarted until the thermistor value recovers to the level of 1.8 kΩ from an over-temperature condition. An **Auto-Restart** will not be initiated subsequent to an **External Thermal Trip** (OH2). A manual restart will be required in the event of an **OH2** trip.

Settings:

- Disabled
- Detect Disconnect

Direct Access Number — F637

Parameter Type — Selection List

Factory Default — Disabled

Changeable During Run — No

PTC2 Thermal Selection

Program ⇒ Special ⇒ Special Parameters⇒ PTC2 Thermal Selection

This parameter **Enables/Disables** the optional external thermal detection circuit of the **Expansion IO Card Option 2**. A thermistor is connected from **TH1+** to **TH1-** of **TB4** on the **Expansion IO Card Option 2**.

Should the thermistor resistance reading fall below 50Ω because of an over-temperature condition or exceed 3000Ω because of an open circuit an **External Thermal Fault** (OH2) will be incurred.

Note: While this parameter is **Enabled**, the system cannot be restarted until the thermistor value recovers to the level of 1.8kΩ from an over-temperature condition. An **Auto-Restart** will not be initiated subsequent to an **External Thermal Trip** (OH2). A manual restart will be required in the event of an **OH2** trip.

Settings:

Disabled
Detect Disconnect

Direct Access Number — F638

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

Braking Resistance Overload Time (10x rated torque)

Program ⇒ Protection ⇒ Dynamic Braking

This parameter sets the time that the braking resistor is allowed to sustain and overload condition before a trip is incurred.

This feature is useful for applications that have a fluctuating load or for loads that require a long deceleration time.

Direct Access Number — F639

Parameter Type — **Numerical**

Factory Default — **5.0**

Changeable During Run — **No**

Minimum — 0.1

Maximum — 600.0

Units — Seconds

Step-Out Detection Current Level

Program ⇒ Motor ⇒ PM Motor

This parameter is used with synchronous motor applications only.

Contact ACE World Companies Customer Support Center for information on this parameter.

Direct Access Number — F640

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 10

Maximum — 150

Units — % (or A; see [F701](#) setting)

Step-Out Detection Current Time

Program ⇒ Motor ⇒ PM Motor

This parameter is used with synchronous motor applications only.

Contact ACE World Companies Customer Support Center for information on this parameter.

Direct Access Number — F641

Parameter Type — **Numerical**

Factory Default — **00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 25.0

Units — Seconds

Emergency-Lift Program ⇒ Emergency Lift In the event of an encoder malfunction, this parameter may be used to Enable/Disable the Emergency Lift mode of operation. In the Emergency Lift mode of operation, the hoist-control function switches from closed-loop operation to open-loop operation and does not require or use an encoder feedback signal. This parameter may be enabled via the EOI (set this parameter to Enabled) or via a discrete input terminal (see Table 7 on pg. 236). Settings: Disabled Enabled	Direct Access Number — F656 Parameter Type — Selection Factory Default — Disabled Changeable During Run — Yes
Emergency-Lift Maximum Speed Program ⇒ Emergency Lift While operating in the Emergency Lift mode, this parameter setting determines the maximum commanded speed allowed.	Direct Access Number — F657 Parameter Type — Numerical Factory Default — 30.00 Changeable During Run — No Minimum — 0.00 Maximum — 30.00 Units — Hz
Emergency-Lift Lower Speed Limit Program ⇒ Emergency Lift When operating in the Emergency Lift mode, this parameter sets the lowest frequency that the ASD will accept as a frequency command or frequency setpoint.	Direct Access Number — F658 Parameter Type — Numerical Factory Default — 6.00 Changeable During Run — No Minimum — 0.00 Maximum — 30.0 Units — Hz
Emergency-Lift Torque Compare Time Program ⇒ Emergency Lift When operating in the Emergency Lift mode, the output-torque level requirement for the brake-release function must be met before the brake can release. This parameter is used to set a time in which the required brake-release torque criteria must be achieved. If this time setting is too short the brake will not release.	Direct Access Number — F659 Parameter Type — Numerical Factory Default — 1.0 Changeable During Run — Yes Minimum — 0.0 Maximum — 1000.0 Units — Seconds

Adding Input Selection

Program ⇒ Feedback ⇒ Override Control

This parameter **Enables/Disables** the feature that allows for the external adjustment of the **Output Frequency**.

Selecting either of the input methods listed enables this feature. The selected input is used as a modifier of the programmed **Output Frequency**.

Settings:

- Disabled
- V/I
- RR
- RX
- Panel Keypad
- RS485 2-Wire
- RS485 4-Wire
- Communication Option Board
- RX2 Option (AI1)
- Option V/I
- UP/DOWN Frequency (ACE G9-120V-PCB)
- Pulse Input (Option)
- Pulse Input (Motor CPU)
- Binary/BCD Input (Option)

Direct Access Number — F660

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

Multiplying Input Selection

Program ⇒ Feedback ⇒ Override Control

This parameter **Enables/Disables** the feature that allows for the external adjustment of the commanded frequency.

Selecting either of the input methods listed enables this feature. The selected input is used as a multiplier of the commanded frequency.

If **Setting (F729)** is selected, the % value entered at parameter **F729** is used as the multiplier of the commanded frequency.

Settings:

- Disabled
- V/I
- RR
- RX
- Setting (F729)
- RX2 Option (AI1)

Direct Access Number — F661

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

AM Output Terminal Function

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **AM** analog output terminal. The **AM** analog output terminal produces an output current that is proportional to the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 8 on pg. 240](#).

AM Terminal Setup Parameters

- F670** — Set AM Function
- F671** — Calibrate AM Terminal
- F685** — Output Response Polarity Selection
- F686** — Bias Adjustment

Direct Access Number — F670

Parameter Type — **Selection List**

Factory Default — **Output Current**

Changeable During Run — **Yes**

AM Output Terminal Adjustment

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to calibrate the **AM** analog output.

To calibrate the **AM** analog output connect a voltmeter to the **AM** and **CC** terminals.

With the ASD is running at a known value (e.g., output frequency), adjust this parameter until the associated function of parameter **F670** produces the desired DC level output at the **AM** output terminal.

See **F670** for additional information on this setting.

Direct Access Number — F671

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

MON1 Terminal Meter Selection

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **MON1** analog output terminal. The available assignments for this output terminal are listed in **Table 8** on pg. 240.

The **MON1** analog output terminal produces an output voltage or current that is proportional to the magnitude of the function assigned to this terminal.

Note: *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F672

Parameter Type — **Selection List**

Factory Default — **Output Voltage**

Changeable During Run — **Yes**

MON1 Terminal Setup Parameters

F672 — MON1 Output Function

F673 — MON1 Terminal Meter Adjustment

F688 — MON1 Voltage/Current Output Switching

F689 — MON1 Output Gradient Characteristic

F690 — MON1 Bias Adjustment Set Zero Level

MON1 Terminal Meter Adjustment

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the gain of the **MON1** output terminal and is used in conjunction with the settings of parameter **F672**.

See parameter **F672** for additional information on this setting.

Direct Access Number — F673

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

MON2 Terminal Meter Selection

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **MON2** analog output terminal. The available assignments for this output terminal are listed in [Table 8 on pg. 240](#).

The **MON2** analog output terminal produces an output voltage or current that is proportional to the magnitude of the function assigned to this terminal.

Note: *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

MON2 Terminal Setup Parameters

F674 — MON2 Output Function

F675 — MON2 Terminal Meter Adjustment

F691 — MON2 Voltage/Current Output Switching

F692 — MON2 Output Gradient Characteristic

F693 — MON2 Bias Adjustment Set Zero Level

Direct Access Number — **F674**

Parameter Type — **Selection List**

Factory Default — **Output Frequency**

Changeable During Run — **Yes**

MON2 Terminal Meter Adjustment

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the gain of the **MON2** output terminal and is used in conjunction with the settings of parameter **F674**.

See parameter **F674** for additional information on this setting.

Direct Access Number — **F675**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

FP Terminal Pulse Output Function

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter sets the functionality of the **FP** output terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

As the assigned function changes in magnitude or frequency, the pulse count of the **FP** output terminal pulse train changes in direct proportion to changes in the assigned function.

Note: *The duty cycle of the output pulse train remains at 65 ±5.0 μS.*

This parameter is used in conjunction with parameter **F677**.

Direct Access Number — **F676**

Parameter Type — **Selection List**

Factory Default — **Output Frequency**

Changeable During Run — **Yes**

Pulse Output Frequency (FP)

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter scales the **FP** output terminal by setting the pulses-per-second output signal of the **FP** terminal.

See **F676** for additional information on this parameter.

Direct Access Number — **F677**

Parameter Type — **Numerical**

Factory Default — **3.84**

Changeable During Run — **Yes**

Minimum — 1.00

Maximum — 43.20

Units — Pulses/Second

FM Voltage/Current Output Switching Program ⇒ Terminal ⇒ Analog Output Terminals This parameter is used to select the type of output signal provided at the FM terminal (i.e., voltage or current). The output voltage and current range is 0 – 10 VDC and 0 – 20 mA, respectively. See F005 for additional information on this setting. Settings: 0 – 10 V 0 – 20 mA	Direct Access Number — F681 Parameter Type — Selection List Factory Default — 0–10V Changeable During Run — No
FM Output Gradient Characteristic Program ⇒ Terminal ⇒ Analog Output Terminals This parameter sets the output response polarity of the FM output terminal. The FM output terminal response may be set to respond inversely (-) or directly (+) to the input signal. See F005 for additional information on this setting. Settings: Minus (Negative Gradient) Plus (Positive Gradient)	Direct Access Number — F682 Parameter Type — Selection List Factory Default — Plus Changeable During Run — Yes
FM Bias Adjustment Program ⇒ Terminal ⇒ Analog Output Terminals This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the FM terminal. Set the function of F005 to zero and then set this parameter to zero for proper operation. See F005 for additional information on this setting.	Direct Access Number — F683 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — -10.0 Maximum — +100.0 Units — %
AM Output Gradient Characteristic Program ⇒ Terminal ⇒ Analog Output Terminals This parameter sets the output response polarity of the AM output terminal. The AM output terminal response may be set to respond inversely (-) or directly (+) to the input signal. See F670 for additional information on this setting. Settings: Minus (Negative Gradient) Plus (Positive Gradient)	Direct Access Number — F685 Parameter Type — Selection List Factory Default — Plus Changeable During Run — Yes
AM Bias Adjustment Program ⇒ Terminal ⇒ Analog Output Terminals This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the AM terminal. Set the function set at F670 to zero and then set this parameter to zero for proper operation. See F670 for additional information on this setting.	Direct Access Number — F686 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — -10.0 Maximum — +100.0 Units — %

MON 1 Voltage/Current Output Switching Program ⇒ Terminal ⇒ Analog Output Terminals This parameter is used to set the output signal type of the MON1 output terminal. Settings -10 V – +10 V 0 – 10 V 0 – 20 mA	Direct Access Number — F688 Parameter Type — Selection List Factory Default — 0 – 10V Changeable During Run — Yes
MON 1 Output Gradient Characteristic Program ⇒ Terminal ⇒ Analog Output Terminals This parameter sets the output response polarity of the MON1 output terminal. The MON1 output terminal response may be set to respond inversely (-) or directly (+) to the input signal. See parameter F672 for additional information on this setting. Settings: Minus (Negative Gradient) Plus (Positive Gradient)	Direct Access Number — F689 Parameter Type — Selection List Factory Default — Plus Changeable During Run — Yes
MON 1 Bias Adjustment Program ⇒ Terminal ⇒ Analog Output Terminals This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the MON1 terminal. Set the assigned function of parameter F672 to zero and then set this parameter to a zero output. See parameter F672 for additional information on this setting.	Direct Access Number — F690 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — -10.0 Maximum — 100.0 Units — %
MON 2 Voltage/Current Output Switching Program ⇒ Terminal ⇒ Analog Output Terminals This parameter is used to set the output signal type of the MON2 output terminal. See parameter F674 for additional information on this setting. Settings -10 V – +10 V 0 – 10 V 0 – 20 mA	Direct Access Number — F691 Parameter Type — Selection List Factory Default — 0 – 10V Changeable During Run — Yes
MON 2 Output Gradient Characteristic Program ⇒ Terminal ⇒ Analog Output Terminals This parameter sets the output response polarity of the MON2 output terminal. The MON2 output terminal response may be set to respond inversely (-) or directly (+) to the input signal. See parameter F672 for additional information on this setting. Settings: Minus (Negative Gradient) Plus (Positive Gradient)	Direct Access Number — F692 Parameter Type — Selection List Factory Default — Plus Changeable During Run — Yes

MON 2 Bias Adjustment Program ⇒ Terminal ⇒ Analog Output Terminals This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the MON2 terminal. Set the assigned function of parameter F674 to zero and then set this parameter to a zero output. See parameter F674 for additional information on this setting.	Direct Access Number — F693 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — -10.0 Maximum — 100.0 Units — %
Parameter Write Lockout Program ⇒ Utilities ⇒ Prohibition This parameter Enables/Disables the Run and Stop keys. Settings: Enabled Disabled	Direct Access Number — F700 Parameter Type — Selection List Factory Default — Enabled Changeable During Run — Yes
Current/Voltage Units Setup Program ⇒ Utilities ⇒ Display Parameters This parameter sets the unit of measurement for current and voltage values displayed on the EOI . Settings: % A/V	Direct Access Number — F701 Parameter Type — Selection List Factory Default — % Changeable During Run — Yes
Free Unit Multiplication Factor Program ⇒ Utilities ⇒ Display Parameters This parameter provides a multiplier for the displayed speed value shown on the front panel screen of the ASD. This parameter may be used to display the rate that a commodity is being processed by the driven load in process units (i.e., units/time). Example: <i>An output frequency of 100 Hz would be displayed as 50 Hz if using a multiplier of 0.5 for this parameter.</i> Note: <i>PID frequency-limiting parameters are not affected by this setting (i.e., F364, F365, F367, and F368).</i>	Direct Access Number — F702 Parameter Type — Numerical Factory Default — 0.00 (Off) Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00
Free Unit Program ⇒ Utilities ⇒ Display Parameters This parameter is used in conjunction with F702 to set the method in which the frequency is displayed on the front panel. The multiplier setting of F702 will be applied to the display of all frequencies if All Frequencies are selected at this parameter. The multiplier setting of F702 will be applied to parameters F364 , F365 , F367 , and F368 <u>ONLY</u> if PID Process Data is selected at this parameter. Settings: All Frequencies PID Process Data	Direct Access Number — F703 Parameter Type — Selection List Factory Default — All Frequencies Changeable During Run — Yes

<p>Free Unit Display Gradient Characteristic</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>The ASD-displayed response to output speed changes will be displayed as directly proportional or inversely proportional as a function of this parameter setting.</p> <p>Selecting Negative Gradient displays an increased output speed as going more negative.</p> <p>Selecting Positive Gradient displays an increased output speed as going more positive.</p> <p>Settings:</p> <p>Minus (Negative Gradient) Plus (Positive Gradient)</p>	<p>Direct Access Number — F705</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Plus</p> <p>Changeable During Run — Yes</p>
<p>Free Display Bias</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>In conjunction with the setting of F702, this parameter sets the bias of the front panel speed display.</p> <p>The frequency entered here will be multiplied by the setting of F702 and then displayed as the zero value on the front panel screen.</p>	<p>Direct Access Number — F706</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Change Step Selection 1</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>In conjunction with the parameter setting of F708, this parameter sets the amount that the output speed will increase or decrease for each speed command change entered from the front panel using the Rotary Encoder.</p>	<p>Direct Access Number — F707</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Change Step Selection 2</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>The parameter is used to modify the degree that the setting of F707 affects the output speed changes that are input from the front panel using the Rotary Encoder.</p> <p>Selecting a zero value here disables this parameter and the resulting non-zero value of parameter setting F707 is output from the ASD.</p> <p>Selecting a non-zero value here provides a dividend that will be used in the following equation resulting in the actual output frequency applied to the motor.</p> $OutputFrequencyDisplayed = InternallyCommandedFrequency \times \frac{F708}{F707}$	<p>Direct Access Number — F708</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>

ASD Disposition at ST Deactivation

Program ⇒ Special ⇒ Operation Panel Parameters

Upon deactivation of the **ST** terminal (if so configured; see [F110](#)) while operating in the **Local** mode, the ASD output to the motor will cease — this parameter setting is used to allow for the restart of the motor (ASD output) without user intervention upon the reactivation of the **ST** terminal.

Upon reactivation of the **ST** terminal in this condition the ASD will resume the Run condition and the motor will start (Retain Panel Run Command).

This feature may be **Disabled** and the Run command must be re-initiated by the user for ASD operation (Clear Panel Run Command).

Direct Access Number — **F719**

Parameter Type — **Selection List**

Factory Default — **Retain Panel Run Command**

Changeable During Run — **Yes**



DANGER

WHEN ENABLED THE ASD WILL RESUME THE RUN CONDITION WHEN THE ST TERMINAL IS REACTIVATED.

Settings:

Clear Panel Run Command
Retain Panel Run Command

Panel Stop Pattern

Program ⇒ Special ⇒ Operation Panel Parameters

While operating in the **Local** mode this parameter determines the method used to stop the motor when the stop command is issued via the **EOI**.

The **Decel Stop** setting enables the **Dynamic Braking** system that is setup at [F304](#) or the **DC Injection Braking** system that is setup at [F250](#), [F251](#), and [F252](#).

The **Coast Stop** setting allows the motor to stop at the rate allowed by the inertia of the load.

Settings:

Deceleration Stop
Coast Stop

Note: The **Stop Pattern** setting has no effect on the **Emergency Off** settings of [F603](#). This parameter may also be accessed by pressing the **ESC** key from the **Frequency Command** screen.

Direct Access Number — **F721**

Parameter Type — **Selection List**

Factory Default — **Deceleration Stop**

Changeable During Run — **Yes**

Panel Torque Command

Program ⇒ Special ⇒ Operation Panel Parameters

This parameter provides a torque value to be used in the event that **Panel Keypad** ([F725 Setting](#)) is selected at parameter [F420](#).

Direct Access Number — **F725**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — -250.00

Maximum — +250.00

Panel Tension Torque Bias Program ⇒ Special ⇒ Operation Panel Parameters This function is not used with the ACE-tronics G9 ASD. The Tension Torque Bias selection is performed at F423 .	Direct Access Number — F727 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — -250.00 Maximum — +250.00 Units — %
Panel Load Sharing Gain Program ⇒ Special ⇒ Operation Panel Parameters This function is not used with the ACE-tronics G9 ASD. The Load Sharing Gain selection is performed at F424 .	Direct Access Number — F728 Parameter Type — Numerical Factory Default — 100.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 250.00 Units — %
Panel Override Multiplication Gain Program ⇒ Special ⇒ Operation Panel Parameters This parameter provides a value to be used in the event that Setting (F729) is selected for the Frequency Override Multiplying Input (F661) .	Direct Access Number — F729 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — -100.00 Maximum — 100.00 Units — %
Panel Frequency Lockout Program ⇒ Special ⇒ Operation Panel Parameters This function is not used with the ACE-tronics G9 ASD. Settings: Unlocked Locked	Direct Access Number — F730 Parameter Type — Selection List Factory Default — Unlocked Changeable During Run — Yes
Panel Emergency Off Lockout Program ⇒ Special ⇒ Operation Panel Parameters This function is not used with the ACE-tronics G9 ASD. Settings: Unlocked Locked	Direct Access Number — F734 Parameter Type — Selection List Factory Default — Unlocked Changeable During Run — No
Panel Reset Lockout Program ⇒ Special ⇒ Operation Panel Parameters This function is not used with the ACE-tronics G9 ASD. Settings: Unlocked Locked	Direct Access Number — F735 Parameter Type — Selection List Factory Default — Unlocked Changeable During Run — Yes

Command Mode/Frequency Mode Change Lockout Program ⇒ Utilities ⇒ Prohibition This function is not used with the ACE-tronics G9 ASD. Settings: Unlocked Locked	Direct Access Number — F736 Parameter Type — Selection List Factory Default — Locked Changeable During Run — Yes
Lockout All Keys Program ⇒ Utilities ⇒ Prohibition This function is not used with the ACE-tronics G9 ASD. Settings: Unlocked Locked	Direct Access Number — F737 Parameter Type — Selection List Factory Default — Unlocked Changeable During Run — Yes
Trace Selection Program ⇒ Utilities ⇒ Trace In conjunction with parameter F741 – F745 , this parameter is used to monitor and store 4 ASD output waveform data points. The data may be read and stored as a function of a trip (At Trip) or it may be initiated by the activation of a discrete terminal activation (At Trigger). Set a discrete input terminal to Trace Back Trigger Signal and activate the terminal to initiate the At Trigger read/store function. Table 12 on pg. 245 lists the items that may be selected for the data read/store function along with the associated communication number for each selection. The duration of the read/store cycle for the selected items is set at parameter F741 . To acquire and store the data a communications device and a PC are required. The ACE-tronics G9 ASD supports the following communications protocols: RS485 (MODBUS-RTU) Toshiba Protocol, USB Toshiba Protocol, CC-Link, ProfiBus, and DeviceNet (Refer to the manual of each protocol type for additional information). Trace data may be viewed graphically via Program ⇒ Utilities ⇒ View Trace Data . Settings: None (Disabled) At Trip At Trigger	Direct Access Number — F740 Parameter Type — Selection List Factory Default — At Trip Changeable During Run — Yes

Trace Cycle Program ⇒ Utilities ⇒ Trace This parameter sets the record time for the Trace Data events selected at F742 – F745 . See F740 for additional information on this parameter setting. Settings: 4 mS 20 mS 100 mS 1 Second 10 Seconds	Direct Access Number — F741 Parameter Type — Selection List Factory Default — 100 mS Changeable During Run — Yes
Trace Data 1 Program ⇒ Utilities ⇒ Trace Data 1 This parameter is used to select the Trace Data 1 item from Table 11 on pg. 244 to be read and stored in accordance with the setup of parameters F740 and F741 . See F740 for additional information on this parameter setting.	Direct Access Number — F742 Parameter Type — Selection List Factory Default — Output Frequency Changeable During Run — Yes
Trace Data 2 Program ⇒ Utilities ⇒ Trace Data 2 This parameter is used to select the Trace Data 2 item from Table 11 on pg. 244 to be read and stored in accordance with the setup of parameters F740 and F741 . See F740 for additional information on this parameter setting.	Direct Access Number — F743 Parameter Type — Selection List Factory Default — Freq. Reference Changeable During Run — Yes
Trace Data 3 Program ⇒ Utilities ⇒ Trace Data 3 This parameter is used to select the Trace Data 3 item from Table 11 on pg. 244 to be read and stored in accordance with the setup of parameters F740 and F741 . See F740 for additional information on this parameter setting.	Direct Access Number — F744 Parameter Type — Selection List Factory Default — Output Current Changeable During Run — Yes
Trace Data 4 Program ⇒ Utilities ⇒ Trace Data 4 This parameter is used to select the Trace Data 4 item from Table 11 on pg. 244 to be read and stored in accordance with the setup of parameters F740 and F741 . See F740 for additional information on this parameter setting.	Direct Access Number — F745 Parameter Type — Selection List Factory Default — DC Voltage Changeable During Run — Yes

RS485 2-Wire Baud Rate Program ⇒ Communications ⇒ Communication <p>This parameter plays a role in the setup of the communications network by establishing the Baud Rate of the communications link.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> 9600 19200 38400 	Direct Access Number — F800 Parameter Type — Selection List Factory Default — 19200 Changeable During Run — Yes Units — bps
RS485 2-Wire and 4-Wire Parity Program ⇒ Communications ⇒ Communication <p>This parameter plays a role in the setup of the communications network by establishing the Parity setting of the communications link.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> No Parity Even Parity Odd Parity 	Direct Access Number — F801 Parameter Type — Selection List Factory Default — Even Parity Changeable During Run — Yes
ASD Number Program ⇒ Communications ⇒ Communication <p>This parameter plays a role in the setup of the communications network by assigning an identification (ID) number to each ASD in the communications network.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p>	Direct Access Number — F802 Parameter Type — Numerical Factory Default — 0 Changeable During Run — Yes Minimum — 0 Maximum — 247
RS485 2-Wire and 4-Wire Communications Time Out Program ⇒ Communications ⇒ Communication <p>This parameter plays a role in the setup of the communications network by setting the time that no activity may exist over the communications link before the link is severed (Time Out).</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p>	Direct Access Number — F803 Parameter Type — Numerical Factory Default — 0 (Off) Changeable During Run — Yes Minimum — 0 (Off) Maximum — 100 Units — Seconds

RS485 2-Wire and 4-Wire Communications Time-Out Action

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by determining the action to be taken in the event of a time-out (Time-Out Action).

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

No Action/No Action
 Alarm/No Action
 Trip/No Action
 No Action/Alarm
 Alarm/Alarm
 Trip/Alarm
 No Action/Trip
 Alarm/Trip
 Trip/Trip

Direct Access Number — **F804**Parameter Type — **Selection List**Factory Default — **Trip/Trip**Changeable During Run — **Yes****RS485 2-Wire Send Wait Time**

Program ⇒ Communications ⇒ Communication

This parameter sets the RS485 2-Wire response delay time.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Direct Access Number — **F805**Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 2.00

Units — Seconds

RS485 2-Wire ASD-to-ASD Communications

Program ⇒ Communications ⇒ Communication

The function of this parameter is 2-fold:

- 1) In a Master/Follower configuration and while communicating via RS485 2-Wire, this parameter sets the ASD as the Master or the Follower.
- 2) This parameter determines the function of the ASD while operating as the Master or the Follower. If operating as the Master ASD, an output parameter of the Master ASD is used to control the Follower ASDs and is set here. If operating as a Follower ASD, the ASD response if an error is incurred is set here.

Note: *Select a Follower function here if **F826** is configured as a **Master Output** controller for any other ASD in the system. Otherwise, an **EOI** failure will result.*

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- Follower (Decel Stop If Error Detected)
- Follower (Continues Operation If Error Detected)
- Follower (Emergency Off If Error Detected)
- Master (Frequency Command)
- Master (Output Frequency)
- Master (Torque Reference)
- Master (Torque Command)

Direct Access Number — F806

Parameter Type — **Selection List**

Factory Default — **Follower (Decel Stop)**

Changeable During Run — **Yes**

Frequency Point Selection

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the communications reference for scaling.

See **F811** — **F814** for additional information on this setting.

Note: *Scaling the communications signal is not required for all applications.*

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- Disabled
- RS485 (2-Wire — NOT USED)
- RS485 4-Wire
- Communication Card

Direct Access Number — F810

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

Point 1 Setting

Program ⇒ Communications ⇒ Communication Reference Adjust

When enabled at [F810](#), this parameter is used to allow the user to set the gain and bias of the speed control input to the ASD when the speed control signal is received via the source selected at [F810](#) (Communications).

Gain and Bias Settings

When operating in the **Speed Control** mode and using one of the control sources from parameter [F810](#), the settings that determine the gain and bias of the input signal are:

- **Point 1 Frequency** ([F812](#)),
- the communications input signal value that represents **Point 1 Frequency**: (Point 1 Setting) [F811](#),
- **Point 2 Frequency** ([F814](#)), and
- the communications input signal value that represents **Point 2 Frequency**: (Point 2 Setting) [F813](#).

Once set, as the input signal value changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets the **Reference** input value (Point 1 Setting) that represents **Point 1 Frequency**. This value is entered as 0 to 100% of the **Reference** input value range.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Direct Access Number — F811

Parameter Type — **Numerical**


Factory Default — **0**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %



Point 1 Frequency

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the gain and bias of the **Reference** speed control input.

This parameter sets **Point 1 Frequency**.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

See [F811](#) for additional information on this setting.

Direct Access Number — F812

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Point 2 Setting

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the gain and bias of the **Reference** speed control input.

This parameter sets the **Reference** input value (Point 2 Setting) that represents **Point 2 Frequency**. This value is entered as 0 to 100% of the **Reference** input value range.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

See [F811](#) for additional information on this setting.

Direct Access Number — F813

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %

Point 2 Frequency

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the gain and bias of the **Reference** speed control input.

This parameter sets the **Point 2 Frequency**.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

See [F811](#) for additional information on this setting.

Direct Access Number — F814

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

RS485 4-Wire Baud Rate

Program ⇒ Communications ⇒ Communication

This parameter sets the RS485 baud rate.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

9600 bps

19200 bps

38400 bps

Direct Access Number — F820

Parameter Type — **Selection List**

Factory Default — **19200**

Changeable During Run — **Yes**

RS485 Send Wait Time

Program ⇒ Communications ⇒ Communication

This parameter sets the RS485 response delay time.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Direct Access Number — F825

Parameter Type — **Numerical**

Factory Default — 0.00

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 2.00

Units — Seconds

RS485 4-Wire ASD-to-ASD Communications

Program ⇒ Communications ⇒ Communication

The function of this parameter is 2-fold:

- 1) In a Master/Follower configuration and while communicating via RS485 4-Wire, this parameter sets the ASD as the Master or the Follower.
- 2) This parameter determines the function of the ASD while operating as the Master or the Follower. If operating as the Master ASD, an output parameter of the Master ASD is used to control the Follower ASDs and is set here. If operating as a Follower ASD, the ASD response if an error is incurred is set here.

Note: Select a Follower function here if **F806** is configured as a **Master Output** controller for any other ASD in the system. Otherwise, an **EOI** failure will result.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- Follower (Decel Stop If Error Detected)
- Follower (Continues Operation If Error Detected)
- Follower (Emergency Off If Error Detected)
- Master (Frequency Command)
- Master (Output Frequency)
- Master (Torque Reference)
- Master (Output Torque)

Direct Access Number — F826

Parameter Type — Selection List

Factory Default — Follower (Decel Stop)

Changeable During Run — Yes

RS485 4-Wire Protocol Selection (TSB/ModBus)

Program ⇒ Communications ⇒ Communication

This parameter sets the communications protocol for ASD-to-ASD communications.

Settings:

- Toshiba
- Modbus

Direct Access Number — F829

Parameter Type — Selection List

Factory Default — Toshiba

Changeable During Run — Yes

Communications Option (DeviceNet/Profibus) Setting 1

Program ⇒ Communications ⇒ Communication

While using the DeviceNet/Profibus communications protocol, this parameter allows the user to select the read and write information communicated between the ASD and the Host.

Read information may include the ASD fault status, ASD speed, ASD MAC ID, etc. Write information may include Enable/Disable DeviceNet commands, Forward run, ACC/DEC command, etc.

See the **DeviceNet Option Instruction Manual** (P/N 58683) for additional information on this parameter.

Settings:

- 0 – 7

Direct Access Number — F830

Parameter Type — Selection List

Factory Default — 0

Changeable During Run — Yes

Communications Option (DeviceNet/Profibus) Setting 2 Program ⇒ Communications ⇒ Communication While using the DeviceNet/Profibus communications protocol, parameters F831 – F836 allow the user to select the ASD memory location that holds the Command/Frequency/Monitoring instructions to be applied to the ASD for Communications Option Settings 2 – 7 , respectively. See the DeviceNet Option Instruction Manual (P/N 58683) for additional information on this parameter. Settings: Disabled FA06 (ALCAN Command 1) FA23 (ALCAN Command 2) FA07 (ALCAN Frequency Command, 0.01 Hz) FA33 (Torque Command, 0.01%) FA50 (Terminal Output) FA51 (Analog Output Data from Comm. [FM]) FA52 (Analog Output Data from Comm. [AM]) F601 (Stall Prevention Level, %) F441 (Power Running Torque Limit 1 Level, 0.01%) F443 (Dynamic Braking Torque Limit 1 Level, 0.01%) F460 (Speed Loop Proportional Gain) F461 (Speed Loop Stabilization Coefficient)	Direct Access Number — F831 Parameter Type — Selection List Factory Default — 0000h Changeable During Run — Yes
Communications Option (DeviceNet/Profibus) Setting 3 Program ⇒ Communications ⇒ Communication Same as F831 . See F831 for information on this parameter	Direct Access Number — F832 Parameter Type — Selection List Factory Default — 0000h Changeable During Run — Yes
Communications Option (DeviceNet/Profibus) Setting 4 Program ⇒ Communications ⇒ Communication Same as F831 . See F831 for information on this parameter	Direct Access Number — F833 Parameter Type — Selection List Factory Default — 0000h Changeable During Run — Yes
Communications Option (DeviceNet/Profibus) Setting 5 Program ⇒ Communications ⇒ Communication Same as F831 . See F831 for information on this parameter	Direct Access Number — F834 Parameter Type — Selection List Factory Default — 0000h Changeable During Run — Yes
Communications Option (DeviceNet/Profibus) Setting 6 Program ⇒ Communications ⇒ Communication Same as F831 . See F831 for information on this parameter	Direct Access Number — F835 Parameter Type — Selection List Factory Default — 0000h Changeable During Run — Yes
Communications Option (DeviceNet/Profibus) Setting 7 Program ⇒ Communications ⇒ Communication Same as F831 . See F831 for information on this parameter	Direct Access Number — F836 Parameter Type — Selection List Factory Default — 0000h Changeable During Run — Yes

Communications Option (DeviceNet/Profibus) Setting 8

Program ⇒ Communications ⇒ Communication

While using the DeviceNet/Profibus communications protocol, parameters [F841](#) – [F846](#) allow the user to select the ASD memory location that holds the Command/Frequency/Monitoring instructions to be applied to the ASD for **Communications Option Settings 8 – 13**, respectively.

See the **DeviceNet Option Instruction Manual** (P/N 58683) for additional information on this parameter.

Settings:

Disabled
 FD01 (ASD Status 1)
 FD00 (Output Frequency, 0.01 Hz)
 FD03 (Output Current, 0.01%)
 FD05 (Output Voltage, 0.01%)
 FC91 (ASD Alarm)
 FD22 (PID Feedback Value, 0.01 Hz)
 FD06 (Input Terminal Status)
 FD07 (Output Terminal Status)
 FE36 (V/I)
 FE35 (RR Input)
 FE37 (RX Input)
 FD04 (Input Voltage [DC Detection], 0.01%)
 FD16 (Realtime Speed Feedback
 FD18 (Torque, 0.01%)
 FE60 (My Monitor)
 FE61 (My Monitor)
 FE62 (My Monitor)
 FE63 (My Monitor)
 F880 (Free Notes)
 FD29 (Input Power, 0.01 kW)
 FD30 (Output Power, 0.01 kW)
 FE14 (Cumulative Operation Time, 0.01=1 Hour)
 FE40 (FM Terminal Output Monitor)
 FE41 (AM Terminal Output Monitor)

Direct Access Number — F841Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 9**

Program ⇒ Communications ⇒ Communication

Same as [F841](#). See [F841](#) for information on this parameter

Direct Access Number — F842Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 10**

Program ⇒ Communications ⇒ Communication

Same as [F841](#). See [F841](#) for information on this parameter

Direct Access Number — F843Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 11**

Program ⇒ Communications ⇒ Communication

Same as [F841](#). See [F841](#) for information on this parameter

Direct Access Number — F844Parameter Type — **Selection List**Factory Default — **0000h**Changeable During Run — **Yes**

Communications Option (DeviceNet/Profibus) Setting 12 Program ⇒ Communications ⇒ Communication Same as F841. See F841 for information on this parameter	Direct Access Number — F845 Parameter Type — Selection List Factory Default — 0000h Changeable During Run — Yes
Communications Option (DeviceNet/Profibus) Setting 13 Program ⇒ Communications ⇒ Communication Same as F841. See F841 for information on this parameter	Direct Access Number — F846 Parameter Type — Selection List Factory Default — 0000h Changeable During Run — Yes
Disconnection Detection Extended Time Program ⇒ Communications ⇒ Communication This parameter is used to set the length of time that no communications activity may exist before the communications link is disconnected.	Direct Access Number — F850 Parameter Type — Numerical Factory Default — 0.0 Changeable During Run — Yes Minimum — 0.0 Maximum — 100.0 Units — Seconds
ASD Operation at Disconnection Program ⇒ Communications ⇒ Communication This parameter is used to set the ASD action to be carried out in the event of the loss of communications. Settings: <ul style="list-style-type: none"> Stop and Terminate Communications Do Nothing (Continue Programmed Operation) Deceleration Stop Coast Stop Emergency Off Preset Speed (Setting of F852) 	Direct Access Number — F851 Parameter Type — Selection List Factory Default — Stop, Communication Release Changeable During Run — Yes
Preset Speed Operation Program ⇒ Communications ⇒ Communication This parameter is used in conjunction with parameter F806. This parameter setting is used to set the Preset Speed selection to be used if Preset Speed is selected at parameter F851. Settings: <ul style="list-style-type: none"> 0 — Disabled 1 – 15 — Preset Speed Number 	Direct Access Number — F852 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Communications Option Station Address Monitor Program ⇒ Communications ⇒ Communication This parameter is used in the setup of the communications network by reading the Media Access Code (MAC) address of the ASD that is connected to a node of the communications system. The MAC Address is set via DIP switches of the optional device. See the DeviceNet Option Instruction Manual (P/N 58683) for additional information on this parameter.	Direct Access Number — F853 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes Minimum — 0 Maximum — 255

<p>Communications Option Speed Switch Monitor DeviceNet/CC-Link</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter is used in the setup of the communications network by reading the hardware-specific settings of the option card being used with the ASD.</p> <p>If using the DEV002Z Devicenet card, this parameter reads the hardware switch SW300 setting of the Devicenet card. SW300 sets the baud rate and the MAC address of the option card that is connected to a node of the communications system.</p>	<p>Direct Access Number — F854</p> <p>Parameter Type — Hardware Selectable</p> <p>Factory Default — Option-Specific</p> <p>Changeable During Run — No</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>Timed-Run Run-Time</p> <p>Program ⇒ Crane/Hoist ⇒ Timed-Run</p> <p>This parameter sets the amount of time that the ASD outputs the commanded speed (from RR, Communications, etc.). The Timed Run is activated by assigning a discrete terminal to Timed Run and momentarily activating the assigned terminal.</p> <p>If activated longer than this time setting, the Timed Run will repeat at the rate setting of F862.</p>	<p>Direct Access Number — F861</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 5.0</p> <p>Units — Seconds</p>
<p>Timed-Run Repeat Delay</p> <p>Program ⇒ Crane/Hoist ⇒ Timed-Run</p> <p>If the Timed Run input terminal remains activated past the Timed Run duration setting (F861), this parameter setting will determine the wait-time before restarting the Timed Run sequence.</p>	<p>Direct Access Number — F862</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 5.0</p> <p>Units — Seconds</p>
<p>Super Creep Pulse Count</p> <p>Program ⇒ Crane/Hoist ⇒ Super Creep Control</p> <p>This parameter requires that a discrete input terminal be set to Super Creep for activation (see Table 7 on pg. 236). Any unused discrete input terminal may be assigned to the Super Creep function.</p> <p>Activating the Super Creep terminal rotates the motor for the amount of encoder pulses set at this parameter at the frequency setting of F865.</p> <p><i>Note: Available in closed-loop operation only.</i></p>	<p>Direct Access Number — F863</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1024</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 16383</p> <p>Units — Pulses</p>
<p>Super Creep Speed Repeat Delay</p> <p>Program ⇒ Crane/Hoist ⇒ Super Creep Control</p> <p>If the Super Creep Pulse Count (F863) discrete input terminal remains activated past the Super Creep Pulse Count setting, this parameter setting will determine the wait-time before restarting the Super Creep Pulse Count sequence.</p>	<p>Direct Access Number — F864</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 2.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 60.0</p> <p>Units — Seconds</p>

Super Creep Speed Program ⇒ Crane/Hoist ⇒ Super Creep Control This parameter sets the Super Creep Speed .	Direct Access Number — F865 Parameter Type — Numerical Factory Default — 0.60 Changeable During Run — Yes Minimum — 0.02 Maximum — 20.00 Units — Hz
Slack Rope Detection Program ⇒ Crane/Hoist ⇒ Slack Rope This parameter Enables/Disables the Slack Rope Detection function. Slack Rope Detection is used while lowering the load to determine if the load has reached the end of its travel (hit the floor, truck bed, etc.). With this parameter enabled during hoist lowering, should the load torque reach or fall below the No-Load Torque setting (F868) for the No-Load (Torque) Detection Time setting (F869), the ASD will stop automatically. Settings: Disabled Enabled	Direct Access Number — F867 Parameter Type — Selection List Factory Default — Disabled Changeable During Run — No Minimum — 0 Maximum — 1
No-Load Torque Program ⇒ Crane/Hoist ⇒ Slack Rope With the Slack Rope Detection (F867) feature enabled during hoist lowering, should the load torque reach or fall below this setting (F868) for the No-Load (Torque) Detection Time setting (F869), the ASD will stop automatically. If the load torque falls below this setting and returns to a value above this setting within the time of F869, normal operations will resume.	Direct Access Number — F868 Parameter Type — Numerical Factory Default — 20.00 Changeable During Run — No Minimum — 0.00 Maximum — 100.0 Units — %
No-Load (Torque) Detection Time Program ⇒ Crane/Hoist ⇒ Slack Rope With the Slack Rope Detection (F867) feature enabled during hoist lowering, should the load torque reach or fall below the No-Load Torque setting (F868) for the No-load (Torque) Detection Time setting (F869), the ASD will stop automatically.	Direct Access Number — F869 Parameter Type — Numerical Factory Default — 0.10 Changeable During Run — No Minimum — 0.01 Maximum — 2.00 Units — Seconds

Block Write Data 1

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be written to the ASD of the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

None
FA00 (Command 1)
FA20 (Command 2)
FA01 (Frequency)
FA50 (TB Output)
FA51 (Analog Output)

Direct Access Number — F870Parameter Type — **Selection List**Factory Default — **None**Changeable During Run — **Yes****Block Write Data 2**

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be written to the ASD of the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

None
FA00 (Command 1)
FA20 (Command 2)
FA01 (Frequency)
FA50 (TB Output)
FA51 (Analog Output)

Direct Access Number — F871Parameter Type — **Selection List**Factory Default — **None**Changeable During Run — **Yes**

Block Read Data 1

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD using the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

None
 Status Information
 Output Frequency
 Output Current
 Output Voltage
 Alarm Information
 PID Feedback Value
 Input Terminal Status
 Output Terminal Status
 V/I
 RR
 RX
 DC Voltage
 PG Feedback
 Torque
 My Monitor 1
 My Monitor 2
 My Monitor 3
 My Monitor 4
 Free Memo

Direct Access Number — F875

Parameter Type — **Selection List**

Factory Default — 0 (None)

Changeable During Run — **Yes**

Block Read Data 2

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.

See parameter [F875](#) for additional information on this setting.

Direct Access Number — F876

Parameter Type — **Selection List**

Factory Default — None

Changeable During Run — **Yes**

Block Read Data 3

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.

See parameter [F875](#) for additional information on this setting.

Direct Access Number — F877

Parameter Type — **Selection List**

Factory Default — None

Changeable During Run — **Yes**

Block Read Data 4 Program ⇒ Communications ⇒ Communication This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link. See parameter F875 for additional information on this setting.	Direct Access Number — F878 Parameter Type — Selection List Factory Default — None Changeable During Run — Yes
Block Read Data 5 Program ⇒ Communications ⇒ Communication This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link. See parameter F875 for additional information on this setting.	Direct Access Number — F879 Parameter Type — Selection List Factory Default — None Changeable During Run — Yes
Free Notes Program ⇒ Communications ⇒ Communication This is an unused parameter that has allocated memory space. The space may be used at the discretion of the user. This space may be used to store information or a note to be transferred using communications.	Direct Access Number — F880 Parameter Type — Numerical Factory Default — 0 Changeable During Run — Yes Minimum — 0 Maximum — 65534
Network Option Reset Program ⇒ Communications ⇒ Communication This parameter plays a role in the setup of the communications network by establishing the targets of a Reset command received via the communications link. Settings: Reset ASD only Reset Option Board and ASD	Direct Access Number — F899 Parameter Type — Selection List Factory Default — Reset ASD only Changeable During Run — Yes
Input Function Target 1 Program ⇒ My Function ⇒ My Function Unit 1 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal. This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F900 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 1 Program ⇒ My Function ⇒ My Function Unit 1 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F901 Parameter Type — Selection List Factory Default — 0 (NOP)

Input Function Target 2 Program ⇒ My Function ⇒ My Function Unit 1 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal. This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F902 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 2 Program ⇒ My Function ⇒ My Function Unit 1 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F903 Parameter Type — Selection List Factory Default — 0 (NOP)
Input Function Target 3 Program ⇒ My Function ⇒ My Function Unit 1 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal. This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F904 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Output Function Assigned Program ⇒ My Function ⇒ My Function Unit 1 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the Output Function Assigned terminal. This setting assigns the function of the programmable Output Function Assigned data location to one of the functions listed in the Input Setting field of Table 9 on pg. 241 . Settings: 0 – 3099 See the F977 for additional information on this parameter.	Direct Access Number — F905 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes

Input Function Target 1 Program ⇒ My Function ⇒ My Function Unit 2 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal. This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F906 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 1 Program ⇒ My Function ⇒ My Function Unit 2 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F907 Parameter Type — Selection List Factory Default — 0 (NOP)
Input Function Target 2 Program ⇒ My Function ⇒ My Function Unit 2 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal. This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F908 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 2 Program ⇒ My Function ⇒ My Function Unit 2 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F909 Parameter Type — Selection List Factory Default — 0 (NOP)
Input Function Target 3 Program ⇒ My Function ⇒ My Function Unit 2 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal. This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F910 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes

<p>Output Function Assigned</p> <p>Program ⇒ My Function ⇒ My Function Unit 2</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the Output Function Assigned terminal.</p> <p>This setting assigns the function of the programmable Output Function Assigned data location to one of the functions listed in the Input Setting field of Table 10 on pg. 242.</p> <p>Settings:</p> <p>0 – 3099</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F911</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Target 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 3</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F912</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 3</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F913</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 3</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F914</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 3</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F915</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>

Input Function Target 3 Program ⇒ My Function ⇒ My Function Unit 3 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal. This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F916 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Output Function Assigned Program ⇒ My Function ⇒ My Function Unit 3 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the Output Function Assigned terminal. This setting assigns the function of the programmable Output Function Assigned data location to one of the functions listed in the Input Setting field of Table 10 on pg. 242 . Settings: 0 – 3099 See F977 for additional information on this parameter.	Direct Access Number — F917 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
My Function Percent Data 1 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Percent Data 1 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 . Once the assigned output value reaches the threshold setting of this parameter the output value is transferred to My Function Out 1 . See F977 for additional information on this parameter.	Direct Access Number — F918 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %
My Function Percent Data 2 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Percent Data 2 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F919 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %
My Function Percent Data 3 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Percent Data 3 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F920 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %

My Function Percent Data 4 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Percent Data 4 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F921 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %
My Function Percent Data 5 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Percent Data 5 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F922 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %
My Function Frequency Data 1 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 1 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F923 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %
My Function Frequency Data 2 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 2 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F924 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %
My Function Frequency Data 3 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 3 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F925 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %
My Function Frequency Data 4 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 4 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F926 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %

My Function Frequency Data 5 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 5 . The analog signal is selected using the Input Setting number from Table 10 on pg. 242 .	Direct Access Number — F927 Parameter Type — Numerical Factory Default — 0.00 Changeable During Run — Yes Minimum — 0.00 Maximum — 200.00 Units — %
My Function Time Data 1 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the response delay of the My Function Time Data 1 terminal. The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	Direct Access Number — F928 Parameter Type — Numerical Factory Default — 0.01 Changeable During Run — Yes Minimum — 0.01 Maximum — 600.00 Units — Seconds
My Function Time Data 2 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the response delay of the My Function Time Data 2 terminal. The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	Direct Access Number — F929 Parameter Type — Numerical Factory Default — 0.01 Changeable During Run — Yes Minimum — 0.01 Maximum — 600.00 Units — Seconds
My Function Time Data 3 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the response delay of the My Function Time Data 3 terminal. The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	Direct Access Number — F930 Parameter Type — Numerical Factory Default — 0.01 Changeable During Run — Yes Minimum — 0.01 Maximum — 600.00 Units — Seconds
My Function Time Data 4 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the response delay of the My Function Time Data 4 terminal. The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	Direct Access Number — F931 Parameter Type — Numerical Factory Default — 0.01 Changeable During Run — Yes Minimum — 0.01 Maximum — 600.00 Units — Seconds

My Function Time Data 5 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the response delay of the My Function Time Data 5 terminal. The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response. Discrete terminal input activation that does not equal or exceed this setting will be ignored.	Direct Access Number — F932 Parameter Type — Numerical Factory Default — 0.01 Changeable During Run — Yes Minimum — 0.01 Maximum — 600.00 Units — Seconds
My Function Count Data 1 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the pulse-count threshold value used to trigger the discrete output COUNT1 (ON Timer) . COUNT1 (ON Timer) outputs a 1 upon reaching the threshold setting of this parameter.	Direct Access Number — F933 Parameter Type — Numerical Factory Default — 0 Changeable During Run — Yes Minimum — 0 Maximum — 9999 Units — Pulses
My Function Count Data 2 Program ⇒ My Function ⇒ My Function Data This parameter is used to set the pulse-count threshold value used to trigger the discrete output COUNT2 (ON Timer) . COUNT2 (ON Timer) outputs a 1 upon reaching the threshold setting at this parameter.	Direct Access Number — F934 Parameter Type — Numerical Factory Default — 0 Changeable During Run — Yes Minimum — 0 Maximum — 9999 Units — Pulses
Input Function Target 1 Program ⇒ My Function ⇒ My Function Unit 4 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal. This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F935 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 1 Program ⇒ My Function ⇒ My Function Unit 4 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F936 Parameter Type — Selection List Factory Default — 0 (NOP)

Input Function Target 2 Program ⇒ My Function ⇒ My Function Unit 4 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal. This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F937 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 2 Program ⇒ My Function ⇒ My Function Unit 4 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F938 Parameter Type — Selection List Factory Default — 0 (NOP)
Input Function Target 3 Program ⇒ My Function ⇒ My Function Unit 4 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal. This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F939 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Output Function Assigned Program ⇒ My Function ⇒ My Function Unit 4 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the Output Function Assigned terminal. This setting assigns the function of the programmable Output Function Assigned data location to one of the functions listed in the Input Setting field of Table 10 on pg. 242 . Settings: 0 – 3099 See F977 for additional information on this parameter.	Direct Access Number — F940 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Target 1 Program ⇒ My Function ⇒ My Function Unit 5 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal. This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F941 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes

Input Function Command 1 Program ⇒ My Function ⇒ My Function Unit 5 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F942 Parameter Type — Selection List Factory Default — 0 (NOP)
Input Function Target 2 Program ⇒ My Function ⇒ My Function Unit 5 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal. This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F943 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 2 Program ⇒ My Function ⇒ My Function Unit 5 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F944 Parameter Type — Selection List Factory Default — 0 (NOP)
Input Function Target 3 Program ⇒ My Function ⇒ My Function Unit 5 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal. This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F945 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Output Function Assigned Program ⇒ My Function ⇒ My Function Unit 5 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the Output Function Assigned terminal. This setting assigns the function of the programmable Output Function Assigned data location to one of the functions listed in the Input Setting field of Table 10 on pg. 242 . Settings: 0 – 3099 See F977 for additional information on this parameter.	Direct Access Number — F946 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes

Input Function Target 1 Program ⇒ My Function ⇒ My Function Unit 6 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal. This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F947 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 1 Program ⇒ My Function ⇒ My Function Unit 6 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F948 Parameter Type — Selection List Factory Default — 0 (NOP)
Input Function Target 2 Program ⇒ My Function ⇒ My Function Unit 6 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal. This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F949 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes
Input Function Command 2 Program ⇒ My Function ⇒ My Function Unit 6 This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function. Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977 .	Direct Access Number — F950 Parameter Type — Selection List Factory Default — 0 (NOP)
Input Function Target 3 Program ⇒ My Function ⇒ My Function Unit 6 This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal. This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241 , Table 10 on pg. 242 , or Table 12 on pg. 245 . See F977 for additional information on this parameter.	Direct Access Number — F951 Parameter Type — Selection List Factory Default — 0 (Disabled) Changeable During Run — Yes

Output Function Assigned

Program ⇒ My Function ⇒ My Function Unit 6

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the **Output Function Assigned** terminal.

This setting assigns the function of the programmable **Output Function Assigned** data location to one of the functions listed in the **Input Setting** field of [Table 10 on pg. 242](#).

Settings:

0 – 3099

See [F977](#) for additional information on this parameter.**Direct Access Number — F952**Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes****Input Function Target 1**

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 1** terminal.

This setting assigns the function of the programmable **Input Function Target 1** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.**Direct Access Number — F953**Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes****Input Function Command 1**

Program ⇒ My Function ⇒ My Function Unit 7

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/Reset function.

[Table 13 on pg. 247](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

Direct Access Number — F954Parameter Type — **Selection List**

Factory Default — 0 (NOP)

Input Function Target 2

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 2** terminal.

This setting assigns the function of the programmable **Input Function Target 2** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.**Direct Access Number — F955**Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes****Input Function Command 2**

Program ⇒ My Function ⇒ My Function Unit 7

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/Reset function.

[Table 13 on pg. 247](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

Direct Access Number — F956Parameter Type — **Selection List**

Factory Default — 0 (NOP)

Input Function Target 3

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 3** terminal.

This setting assigns the function of the programmable **Input Function Target 3** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.

Direct Access Number — F957

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Output Function Assigned

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the **Output Function Assigned** terminal.

This setting assigns the function of the programmable **Output Function Assigned** data location to one of the functions listed in the **Input Setting** field of [Table 10 on pg. 242](#).

Settings:

0 – 3099

See [F977](#) for additional information on this parameter.

Direct Access Number — F958

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Analog Input Function Target 11

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Analog Input Function Target 11** terminal.

The function selected at [F961](#) may be adjusted using the input analog control signal selected here.

Settings:

Disabled (None)
V/I
RR
RX
Optional RX2+, RX2-
Optional V/I

Direct Access Number — F959

Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes**

Analog Function Assigned Object 11

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality to which the adjustment of F959 is applied.

Settings:

Disabled (None)
 Acceleration Rate
 Upper-Limit Frequency
 Acceleration Multiplication Factor
 Deceleration Multiplication Factor
 Manual Torque Boost
 Over-Current Stall (F601)
 Thermal Protection (F600)
 Speed Loop Proportional Gain (F460)
 Drooping Gain (F320)
 PID Proportional Gain (F362)

Direct Access Number — F961Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes****Analog Input Function Target 21**

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Analog Input Function Target 21** terminal.

The function selected at F964 may be adjusted using the input analog control signal selected here.

Settings:

Disabled (None)
 V/I
 RR
 RX
 Optional RX2+, RX2-
 Optional V/I

Direct Access Number — F962Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes****Analog Function Assigned Object 21**

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality to which the adjustment of F962 is applied.

Settings:

Disabled (None)
 Acceleration Rate
 Upper-Limit Frequency
 Acceleration Multiplication Factor
 Deceleration Multiplication Factor
 Manual Torque Boost
 Over-Current Stall (F601)
 Thermal Protection (F600)
 Speed Loop Proportional Gain (F460)
 Drooping Gain (F320)
 PID Proportional Gain (F362)

Direct Access Number — F964Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes**

Monitor Output Function 11

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter Proportional.

Select the **Monitor Display Input Setting** number from [Table 12 on pg. 245](#) to output the corresponding function.

Use the Communication Number if operating using communications.

Direct Access Number — F965

Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

Monitor Output Function Command 11

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter [F965](#) selection to be recorded and output as a monitored function.

Settings:

Normal
Peak
Minimum

Direct Access Number — F966

Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

Monitor Output Function 21

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter [F968](#).

Select the **Monitor Display Input Setting** number from [Table 12 on pg. 245](#) to output the corresponding function.

Use the Communication Number if operating using communications.

Direct Access Number — F967

Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

Monitor Output Function Command 21

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter [F967](#) selection to be recorded and output as a monitored function.

Settings:

Normal
Peak
Minimum

Direct Access Number — F968

Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

Monitor Output Function 31

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter F970.

Select the **Monitor Display Input Setting** number from Table 12 on pg. 245 to output the corresponding function.

Use the Communication Number if operating using communications.

Direct Access Number — F969

Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

Monitor Output Function Command 31

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter F969 selection to be recorded and output as a monitored function.

Settings:

Normal
Peak
Minimum

Direct Access Number — F970

Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

Monitor Output Function 41

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter F972.

Select the **Monitor Display Input Setting** number from Table 12 on pg. 245 to output the corresponding function.

Use the Communication Number if operating using communications.

Direct Access Number — F971

Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

Monitor Output Function Command 41

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter F971 selection to be recorded and output as a monitored function.

Settings:

Normal
Peak
Minimum

Direct Access Number — F972

Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

Virtual Input Terminal Selection 1

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 1**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** state (activated).

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 1** terminal to one of the functions that are listed in [Table 7 on pg. 236](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F973Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No****Virtual Input Terminal Selection 2**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 2**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** state (activated).

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 2** terminal to one of the functions that are listed in [Table 7 on pg. 236](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F974Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No****Virtual Input Terminal Selection 3**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 3**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** state (activated).

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 3** terminal to one of the functions that are listed in [Table 7 on pg. 236](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F975Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No****Virtual Input Terminal Selection 4**

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 4**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** state (activated).

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 4** terminal to one of the functions that are listed in [Table 7 on pg. 236](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F976Parameter Type — **Selection List**Factory Default — **Unassigned**Changeable During Run — **No**

My Function Operating Mode

Program ⇒ My Function Selection

This parameter **Enables/Disables** the configured **My Function** feature of the ACE-tronics G9 ASD.

Settings:

- None (Disabled)
- My Signal with Terminal Board Signal (ACE G9-120V-PCB)
- My Function Always On

My Function

The **My Function** feature is configured using the settings of **F900** to **F977** and is used to enhance the programmability of the ASD by performing two programmable functions: 1) the Combined Terminal Function, and 2) Logic Operations.

Combined Input Terminal Function

Assigning more than one function to a discrete input terminal provides two advantages: it effectively expands the number of input terminals, and reduces the number of cables required to support the input/output functions (e.g., assigning **Accel/Decel Switching** selections to one terminal). Using **Virtual Terminals 1 – 4** (**F973 – F976**) are required to use this function.

In the example below, the **Accel/Decel Switching 1** terminal assignment and the **Accel/Decel Switching 2** terminal assignment will be combined as one terminal to illustrate this feature. However, any two of the discrete input terminal assignments listed in **Table 7** on **pg. 236** may be combined in this manner.

Note: *Accel/Decel Switching requires the use of two discrete input terminals to select the user-configured Accel/Decel profiles identified with the binary numbers 1 – 4 (i.e., 00=1_B, 01=2_B, 10=3_B, and 11=4_B).*

Setup (Input Terminal Example)

1. Disable the **My Function** parameter at **F977** to prevent the system from starting upon completion of the setup.
2. Assign the **Accel/Decel Switching 1** function to the **I1** terminal (**F113**).
3. Assign the **Accel/Decel Switching 2** function to **Virtual Input Terminal 1** (**F973**).
4. Set **Input Function Target 1** to **5** (**F900**). This setting assigns **I1** as the control input terminal.
5. Set **Output Function Assigned** to **21** (**F905**). This setting is a command that writes the **F113** selection (I1) to **Virtual Input Terminal 1**, activating both.

(Continued on **pg. 228**)

Direct Access Number — **F977**

Parameter Type — **Selection List**

Factory Default — **None** (Disabled)

Changeable During Run — **No**



DANGER

This parameter must always be set to **None** at the start of the **My Function** setup and remain set to **None** until all of the **My Function** parameter settings have been confirmed as being correct.

If enabled for normal operation using settings **1** or **2**, the motor may start and engage the driven equipment unexpectedly upon receiving a **Run** signal during the **My Function** setup.

Combined Input Terminal Function (Cont.)

6. Enable the **My Function** parameter at [F977](#) by selecting **My Function Always On** or selecting **My Function With TB Signal**.

If set to **My Function Always On**, the combination of **Accel/Decel Switching 1** and **Accel/Decel Switching 2** are always On (both are activated during the I1 activation).

If set to **My Function With TB Signal**, set a discrete input terminal to **My Function Run Signal** and activate it to enable **My Function**. Activate **I1** to activate the **Accel/Decel Switching 1** and **Accel/Decel Switching 2** functions. A disconnection at either terminal will terminate the **My Function** programming (discrete input terminal **My Function Run Signal** is Anded with discrete input terminal **I1**).

Activate **I1** and the **Accel/Decel Switching 1** and **Accel/Decel Switching 2** functions will be carried out using only **I1**.

With the aforementioned setup completed, provide a **Frequency Command** ([F004](#)) and the motor will run at the commanded frequency.

Combined Output Terminal Function

Output terminals may also be combined to produce one output response to multiple conditions using the computational operators of [Table 13 on pg. 247](#). Assigning more than one function to a discrete output terminal provides two advantages: it effectively expands the number of input terminals, and reduces the number of cables required to support the input/output functions (e.g., assigning Low-Speed Detection and Low-Current Detection to one output terminal). Using **Virtual Terminals 1 – 4** ([F973 – F976](#)) are required to use this function.

In the example below, the **Low Speed Signal** (detection) terminal assignment and the **Low-Current Detection** terminal assignment will be combined as one terminal output to illustrate this feature. However, any two of the discrete output terminal assignments may listed in [Table 10 on pg. 242](#) may be combined in this manner.

Setup (Output Terminal Example)

1. Disable the **My Function** parameter at [F977](#) to prevent the system from starting upon completion of the setup.
2. From Program ⇒ Direct Access ⇒ Unknown Numbers, select **Enabled**.
3. Set the **OUT1** terminal ([F130](#)) to **My Function Output 1** (222).
4. Set **Input Function Target 1** ([F900](#)) to **1004** (Low Speed Signal detection). See [Table 10 on pg. 242](#) for a complete listing of available settings.
5. Set **Input Function Target 2** ([F902](#)) to **1026** (Low-Current Alarm). See [Table 10 on pg. 242](#) for a complete listing of available settings.
6. Set **Input Function Command 1** ([F901](#)) to **AND** (3). This setting assigns an operator to the **Input Function Target 1** and the **Input Function Target 2** settings.
7. Set **Output Function Assigned** ([F905](#)) to **1222**. This setting will transfer the results of the logical AND to **My Function Output 1** (OUT1).
8. Enable the **My Function** parameter at [F977](#) by selecting **My Function Always On**.

With the aforementioned setup completed in the example, once the **Low Speed Signal** AND the **Low-Current Alarm** are active, the **OUT1** terminal is activated for the duration of the **Low-Speed/Low-Current** condition.

Direct Access Number — **F977**

Parameter Type — **Selection List**

Factory Default — **None** (Disabled)

Changeable During Run — **No**



DANGER

This parameter must always be set to **None** at the start of the **My Function** setup and remain set to **None** until all of the **My Function** parameter settings have been confirmed as being correct.

If enabled for normal operation using settings **1** or **2**, the motor may start and engage the driven equipment unexpectedly upon receiving a **Run** signal during the **My Function** setup.

Traverse Selection (Not Used With the ACE-tronics G9 ASD) Program ⇒ Special ⇒ Traverse This parameter setting is used in the setup of the Traverse control mode of operation and is used in conjunction with the discrete terminal activation of the Traverse Permission Signal . This parameter is used to enable the Traverse function. The Traverse function is activated via the discrete input terminal (see Table 7 on pg. 236). See the <i>Traverse Control Instruction Manual</i> (P/N E6581337) for additional information on this feature. Settings: Disabled Enabled	Direct Access Number — F980 Parameter Type — Selection List Factory Default — Disabled Changeable During Run — No
Traverse Acceleration Time (Not Used With the ACE-tronics G9 ASD) Program ⇒ Special ⇒ Traverse This parameter setting is used in the setup of the Traverse control mode of operation. This setting establishes the acceleration rate used during the Traverse function. See the <i>Traverse Control Instruction Manual</i> (P/N E6581337) for additional information on this feature.	Direct Access Number — F981 Parameter Type — Numerical Factory Default — 25.0 Changeable During Run — No Minimum — 0.1 Maximum — 120.0 Units — Seconds
Traverse Deceleration Time (Not Used With the ACE-tronics G9 ASD) Program ⇒ Special ⇒ Traverse This parameter setting is used in the setup of the Traverse control mode of operation. This setting establishes the deceleration rate used during the Traverse function. See the <i>Traverse Control Instruction Manual</i> (P/N E6581337) for additional information on this feature.	Direct Access Number — F982 Parameter Type — Numerical Factory Default — 25.0 Changeable During Run — No Minimum — 0.1 Maximum — 120.0 Units — Seconds
Traverse Step (Not Used With the ACE-tronics G9 ASD) Program ⇒ Special ⇒ Traverse This parameter setting is used in the setup of the Traverse control mode of operation. This setting is used as a multiplier to establish the amount that the frequency is increased or decreased while using the Traverse function. See the <i>Traverse Control Instruction Manual</i> (P/N E6581337) for additional information on this feature.	Direct Access Number — F983 Parameter Type — Numerical Factory Default — 10.0 Changeable During Run — No Minimum — 0.0 Maximum — 25.0 Units — %

Traverse Jump Step (Not Used With the ACE-tronics G9 ASD)

Program ⇒ Special ⇒ Traverse

This parameter setting is used in the setup of the **Traverse** control mode of operation. This setting is used as a multiplier to establish the amount that the frequency is increased or decreased while using the **Traverse** function when a short burst of rapid speed change is required.

See the *Traverse Control Instruction Manual* (P/N E6581337) for additional information on this feature.

Direct Access Number — F984

Parameter Type — **Numerical**

Factory Default — **10.0**

Changeable During Run — **No**

Minimum — 0.0

Maximum — 50.0

Units — %

Motion Control

Program ⇒ Crane/Hoist ⇒ Motion Control

This parameter sets the axis of motion to be controlled by the ASD.

Settings:

Closed Loop Hoist

Open Loop Hoist (Used During Emergency Lift ONLY)

Main Hoist

Bridge

Rotate

Direct Access Number — F985

Parameter Type — **Selection List**

Factory Default — **Closed Loop Hoist**

Changeable During Run — **No**

Speed Control Mode

Program ⇒ Crane/Hoist ⇒ Speed Control

This parameter setting determines the speed-control method to be used for motor control.

Settings:

Standard (ACE G9) — Normal ASD default settings and operation.

2-Step Variable

Required inputs — **F**, **R**, and **I1** (default via Startup Wizard).

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

I1 — Provides a command to accel toward the **Upper-Limit** setting when activated. **Holds** (frequency) when deactivated.

3-Step Variable

Required inputs — **F**, **R**, **I3** (default), and **I4** (default).

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

I3 — Provides a command to accel toward the **Upper-Limit** setting when activated.

I4 — Holds the **Run** frequency when activated. Returns to the **Run** command (6 Hz or stop) when deactivated.

5-Speed

Required inputs — **F**, **R**, and **Preset Speeds 1 – 4**.

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

I3 – I6 — Sequentially activates **Preset Speeds 1 – 4**. All of the preceding **Preset Speeds** must be active for a given **Preset Speed** to be output from the ASD (i.e., PS1 = PS1, PS1 & PS2 = PS2, PS1 & PS2 & PS3 = PS3, etc.). If not all of the preceding **Preset Speeds** are active, the highest **Preset Speed** number with all of the preceding **Preset Speeds** active will be output from the ASD (i.e., PS1 & PS2 & PS4 = PS2).

2- and 3-Speed

Same as **5-Speed** using only the required number of **Preset Speed** settings.

Unipolar Analog

Required inputs — **F**, **R**, and **RR** input.

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

RR — Controls the output speed from the **Lower Limit** to the **Upper Limit**.

Bi-Polar Analog

Required inputs — **F**, **R**, and **RX** input.

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

RX — Controls the output speed from the **Lower Limit** to the **Upper Limit** (Forward or Reverse).


Direct Access Number — **F986**

Parameter Type — **Selection List**


Factory Default — **2-Step Variable**

Changeable During Run — **N**

2-Step Variable operation



3-Step Variable operation



Note: Incorrectly activated discrete input terminals will result in a **Switch Out Of Order Alarm** halting the ASD (e.g., **F** and **R** activated simultaneously when not required).

To clear this condition, deactivate all discrete input terminals.

Brake-Release Torque Reference Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control This parameter sets the output torque level threshold that must be reached within the time setting of the Brake-Release Torque (Proving) Time (F988) to initiate the Brake Release during normal operation. This setting is also used as a reference during the count-down of the Brake-Release Torque Stable Time . See Figure 32 on pg. 235 for additional information on this parameter.	Direct Access Number — F987 Parameter Type — Numerical Factory Default — 100.00 Changeable During Run — Yes Minimum — 10.00 Maximum — 250.0 Units — %
Brake-Release Torque (Proving) Time Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control The output-torque level requirement for the brake-release function must be met before the brake can release. This parameter is used to set a time in which the Brake-Release Torque Reference (F988) criteria must be achieved. See Figure 32 on pg. 235 for additional information on this parameter.	Direct Access Number — F988 Parameter Type — Numerical Factory Default — 1.0 Changeable During Run — No Minimum — 0.5 Maximum — 10.0 Units — Seconds
Brake-Release Torque Stable Time Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control Once the brake signal is initiated this parameter sets the time that the output torque level must remain at or above the torque level set at F987 before the brake is released. See Figure 32 on pg. 235 for additional information on this parameter.	Direct Access Number — F989 Parameter Type — Numerical Factory Default — 0.20 Changeable During Run — Yes Minimum — 0.00 Maximum — 2.55 Units — Seconds
Brake-Release Mechanical (Delay) Time Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control This parameter sets the time for completing the Brake-Seized Pulse Check (F992) . See Figure 32 on pg. 235 for additional information on this parameter.	Direct Access Number — F990 Parameter Type — Numerical Factory Default — 0.75 Changeable During Run — No Minimum — 0.00 Maximum — 2.50 Units — Seconds
Brake-Set Mechanical (Delay) Time Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control Once the brake signal is initiated this parameter sets the time that must elapse before the brake engages. See Figure 32 on pg. 235 for additional information on this parameter.	Direct Access Number — F991 Parameter Type — Numerical Factory Default — 0.50 Changeable During Run — No Minimum — 0.00 Maximum — 2.50 Units — Seconds

Brake-Seized Pulse Check Time Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control This parameter sets the time for completing the Brake-Seized Pulse Check . With a forward or reverse signal applied to the motor, a brake that is seized closed will not allow the motor to rotate. To check for this condition, this parameter sets the minimum number of encoder pulses that are expected to occur within the time setting of F990 . See Figure 32 on pg. 235 for additional information on this parameter.	Direct Access Number — F992 Parameter Type — Numerical Factory Default — 1.00 Changeable During Run — No Minimum — 0.00 Maximum — 2.50 Units — Seconds
Brake-Seized Pulse Check Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control With a forward or reverse signal applied to the motor, a brake that is seized closed will not allow the motor to rotate. To check for this condition, this parameter sets the minimum number of encoder pulses that are expected to occur within the time setting of the Brake-Release Mechanical (Delay) Time (F990) parameter.	Direct Access Number — F993 Parameter Type — Numerical Factory Default — 20 Changeable During Run — No Minimum — 0 Maximum — 1024 Units — Pulse
Brake-Failure Pulse Count Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control If while the brake is applied the encoder pulse count reaches this setting within the time setting of the Brake-Release Torque (Proving) Time (F988) setting the system will incur a Brake Failure fault. See Figure 32 on pg. 235 for additional information on this parameter.	Direct Access Number — F994 Parameter Type — Numerical Factory Default — 100 Changeable During Run — No Minimum — 5 Maximum — 100 Units — Pulses
Continuous Monitoring Brake-Fail Pulse-Count Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control During normal operation this parameter establishes the maximum number of encoder pulses allowed after the brake is applied before a Brake Failure fault is incurred.	Direct Access Number — F995 Parameter Type — Numerical Factory Default — 200 Changeable During Run — No Minimum — 0 Maximum — 1024 Units — Pulses
Maximum Up Speed At Brake Fail Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control In the event of a brake failure this parameter setting is used as the hoist-up speed limit.	Direct Access Number — F996 Parameter Type — Numerical Factory Default — 6.00 Changeable During Run — No Minimum — 0.00 Maximum — 60.0 Units — Hz
Load Hover Time Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control This parameter sets the time that the system will hold the load before the brake is applied during a normal stop. See Figure 32 on pg. 235 for additional information on this parameter.	Direct Access Number — F997 Parameter Type — Numerical Factory Default — 5.0 Changeable During Run — No Minimum — 0.0 Maximum — 300.0 Units — Seconds

Drooping Pulses Allowed

Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control

This parameter sets the number of encoder pulses allowed in the opposite direction of the commanded direction before a **Load Drooping** fault occurs.

If commanded to lift (forward) and the load is dropping (reverse or falling), this condition is annunciated via the **Load Drooping** fault and indicates that the requirements of the load are in excess of the capability of the motor.

Direct Access Number — F998

Parameter Type — **Numerical**

Factory Default — **350**

Changeable During Run — **Yes**

Minimum — 2

Maximum — 1024

Units — Pulses

Encoder Error Detection Time

Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control

Upon receiving a frequency command, should the motor response be anything other than the commanded frequency for longer than the time set at this parameter, an encoder error is incurred.

See **Figure 32 on pg. 235** for additional information on this parameter.

Direct Access Number — F999

Parameter Type — **Numerical**

Factory Default — **0.50**

Changeable During Run — **No**

Minimum — 0.00

Maximum — 2.55

Units — Seconds

Figure 32. Closed-Loop Hoist Start and Stop Timing Diagrams.




Table 7. Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions																						
NO	NC																							
0	1	Unassigned — No operation.																						
2	3	Forward — Provides a Forward run command.																						
4	5	Reverse — Provides a Reverse run command.																						
6	7	Standby — Enables the Forward and Reverse operation commands.																						
8	9	Reset — Resets the device and any active faults.																						
10	11	Preset Speed 1 — Preset Speed 1 is used as the LSB of the 4-bit nibble that is used to select a Preset Speed .																						
12	13	Preset Speed 2 — Preset Speed 2 is used as the second bit of the 4-bit nibble that is used to select a Preset Speed .																						
14	15	Preset Speed 3 — Preset Speed 3 is used as the third bit of the 4-bit nibble that is used to select a Preset Speed .																						
16	17	Preset Speed 4 — Preset Speed 4 is used as the MSB of the 4-bit nibble that is used to select a Preset Speed .																						
18	19	Jog Run — This terminal activates a Jog for the duration of the activation. The Jog settings may be configured at F260 – F262 .																						
20	21	Emergency Off — Terminates the output signal from the ASD and may apply a brake if so configured. The braking method may be selected at F603 .																						
22	23	DC Braking — Upon activation the ASD outputs a DC current that is injected into the windings of the motor to quickly brake the motor.																						
24	25	Accel/Decel Switching 1/Accel/Decel Switching 2 — Activating combinations of discrete input terminals Accel/Decel Switching 1 and 2 allow for the selection of Accel/Decel profiles 1 – 4 as shown below. See F504 for additional information on this terminal setting.																						
26	27	<table><tr><th colspan="2">A/D SW Terminal</th><th rowspan="2">A/D Profile Selection</th></tr><tr><th>#1</th><th>#2</th></tr><tr><td>0</td><td>0</td><td>1</td></tr><tr><td>0</td><td>1</td><td>2</td></tr><tr><td>1</td><td>0</td><td>3</td></tr><tr><td>1</td><td>1</td><td>4</td></tr><tr><td colspan="3">1=Terminal Activated</td></tr></table>		A/D SW Terminal		A/D Profile Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated			<p>The settings of the A/D selections 1 – 4 are performed at F009/F010, F500/F501, F510/F511, and F514/F515, respectively.</p> <p>Accel/Decel profiles are comprised of the Accel/Decel settings, Pattern, and Switching Frequency.</p>
		A/D SW Terminal		A/D Profile Selection																				
		#1	#2																					
		0	0	1																				
		0	1	2																				
		1	0	3																				
1	1	4																						
1=Terminal Activated																								
28	29	V/f Switching 1/V/f Switching 2 — Activating combinations of discrete input terminals V/f Switching 1 and 2 allow for the selection of a V/f switching profile as listed below.																						
30	31	<table><tr><th colspan="2">V/f Switching Terminal</th><th rowspan="2">V/f Selection</th></tr><tr><th>#1</th><th>#2</th></tr><tr><td>0</td><td>0</td><td>1</td></tr><tr><td>0</td><td>1</td><td>2</td></tr><tr><td>1</td><td>0</td><td>3</td></tr><tr><td>1</td><td>1</td><td>4</td></tr><tr><td colspan="3">1=Terminal Activated</td></tr></table>		V/f Switching Terminal		V/f Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated			<p>The 1–4 settings of the V/f Switching selections are performed at parameters F170 – F181.</p>
		V/f Switching Terminal		V/f Selection																				
		#1	#2																					
		0	0	1																				
		0	1	2																				
1	0	3																						
1	1	4																						
1=Terminal Activated																								
Note: NO/NC = Normally Open/Normally Closed. Selection numbers are used when selecting using communications.																								

Table 7. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions																
NO	NC																	
32	33	Torque Limit Switching 1/Torque Limit Switching 2 — Activating combinations of discrete input terminals Torque Limit Switching 1 and 2 allow for the selection of a torque limit switching profile as listed below.																
		<table><tr><th colspan="2">Torque Limit Switching Terminal</th><th rowspan="2">Torque Limit Selection</th></tr><tr><th>#1</th><th>#2</th></tr><tr><td>0</td><td>0</td><td>1</td></tr><tr><td>0</td><td>1</td><td>2</td></tr><tr><td>1</td><td>0</td><td>3</td></tr><tr><td>1</td><td>1</td><td>4</td></tr></table>	Torque Limit Switching Terminal		Torque Limit Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1
Torque Limit Switching Terminal		Torque Limit Selection																
#1	#2																	
0	0	1																
0	1	2																
1	0	3																
1	1	4																
34	35	<table><tr><td colspan="2">1=Terminal Activated</td></tr></table>	1=Terminal Activated															
1=Terminal Activated																		
36	37	PID Off — Turns off PID control.																
38	39	Pattern Operation Group 1 — Initiates the Pattern #1 Pattern Run .																
40	41	Pattern Operation Group 2 — Initiates the Pattern #2 Pattern Run .																
42	43	Pattern Operation Continuation — Initiates a continuation of the last Pattern Run from its stopping point.																
44	45	Pattern Operation Trigger — Initiates the first Preset Speed of a Pattern Run and initiates each subsequent enabled Preset Speed with continued activations.																
46	47	External Overheat — Causes an Overheat Trip (OH) .																
48	49	Local Priority (Cancels Serial Priority) — Activation overrides all active serial control and returns the Command and Frequency control to the settings of F003 and F004 for the duration of the activation.																
50	51	Hold (3-Wire Stop) — Decelerates the motor to a stop.																
52	53	PID Differentiation/Integration Clear — Clears the PID value.																
54	55	PID Forward/Reverse Switching — Toggles the gradient characteristic of the feedback response of the V/I terminal during PID -controlled operation.																
56	57	Forced Continuous Operation — Ignore PID control settings for the duration of activation.																
58	59	Specified Speed Operation — Runs speed as commanded by the Frequency Mode setting.																
60	61	Dwell Signal — Used in conjunction with the Acceleration/Deceleration Suspend function (F349) — suspends the Accel/Decel function for the duration of the activation.																
62	63	Power Failure Synchronized Signal — Activates the Synchronized Accel/Decel function of the Regenerative Power Ridethrough feature. See F302 for additional information on this terminal setting.																
64	65	My Function Run — Activates the configured My Function feature. See F977 for additional information on this parameter.																
66	67	Autotuning Signal — Initiates the Autotune function. Set F400 to Autotuning by Input Terminal Signal .																
68	69	Speed Gain Switching — Toggles the ASD operating mode from and to Speed Control and Torque Control . Speed Control operation references parameter settings F460 and F461 . Torque Control operation references parameter settings F462 and F463 .																
70	71	Servo Lock — Holds the motor at 0 Hz until a Run command is received.																
72	73	Simple Positioning — While operating in the Positioning Control mode, activation initiates the Stop command. See F381 for additional information on this terminal setting.																
74	75	kWH Display Clear — Clears the kWH meter display.																
76	77	Trace Back Trigger — Initiates the data Read/Store function of the Trace Selection parameter. See F740 for additional information on this feature.																
78	79	Express-Speed Disable — Terminates the Express Speed operation.																
Note: NO/NC = Normally Open/Normally Closed. Selection numbers are used when selecting using communications.																		

Table 7. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions
NO	NC	
86	87	Binary Write — Writes the status of the discrete input terminals to the control board during binary input speed control.
88	89	UP/DOWN Frequency (UP) — Increases the speed of the motor for the duration of activation until reaching the Upper-Limit setting or increases the speed of the motor in steps (see F264 for additional information on this feature).
90	91	UP/DOWN Frequency (DOWN) — Decreases the speed of the motor for the duration of activation until reaching the Lower-Limit (F013) setting or decreases the speed of the motor in steps (see F264 for additional information on this feature).
92	93	UP/DOWN Frequency (Clear) — While operating in the UP/DOWN Frequency speed control mode this terminal initiates a 0 Hz output command. If operating with an activated UP/DOWN Frequency (up or down) terminal, the output goes to the Lower-Limit (F013) setting.
98	99	Forward/Reverse — This setting operates in conjunction with another terminal being set to the Run/Stop function. When configured to Run (Run/Stop activated), the activation/deactivation of this terminal changes the direction of the motor.
100	101	Run/Stop — This terminal enables the motor to run when activated and disables the motor when deactivated.
102	103	Commercial Power/ASD Switching — Initiates the ASD-to-Commercial Power switching function. See parameter F354 for additional information on this feature.
104	105	Frequency Reference Priority Switching — Toggles frequency control to and from the settings of F004 and F207.
106	107	V/I Terminal Priority — Assigns Speed control to the V/I Terminal and overrides the F004 setting.
108	109	Command Terminal Board Priority — Assigns Command control to the ACE G9-120V-PCB and overrides the F003 setting.
110	111	Edit Enable — Allows for the override of the lockout parameter setting (F700) allowing for parameter editing.
112	113	Control Switching — Toggles the system to and from the speed control and the torque control modes.
122	123	Fast Deceleration — Using dynamic braking (if enabled and supported), stops the motor at the fastest rate allowed by the load.
124	125	Preliminary Excitation — Applies an excitation current to the motor (holds shaft stationary) for the duration of the activation.
126	127	<p>Brake Request — Initiates the Brake-Release command. This setting requires that another discrete input terminal be set to Brake Answerback Input to complete the Brake-Release command and to convey the status of the braking system to the user or to a dependent subsystem.</p> <p>Once the braking release function is initiated, the Trouble Internal Timer begins to count down (Trouble Internal Timer value is set at F630). Should the count-down timer expire before the brake releases or before the Brake Answerback Input is returned, fault E-11 will occur. Otherwise, the brake releases the motor and normal motor operations resume.</p> <p>The Braking Release function is primarily used at startup; but, may be used when the brake is applied while the motor is running.</p>
130	131	<p>Brake Answerback Input — This setting is required when the Braking Request function is used. The function of this input terminal is to receive the returned status of the braking system. The returned status is either Released or Not Released.</p> <p>If Released is returned within the time setting of F630, normal system function resumes.</p> <p>If Not Released is returned or if the F630 time setting times out before either signal is returned, then fault E-11 occurs.</p> <p>The returned signal may also be used to notify the user or control a dependent subsystem.</p>
132	133	3-Step-Variable Speed Hold — Holds the run frequency for the duration of the activation.
134	135	Traverse Permission Signal — This feature is not used with the ACE-tronics G9 ASD.
136	137	Slow-Speed Limit-Switch Forward — Activating this terminal applies the modified Upper-Limit Slow Speed setting of F294 and the modified Deceleration setting of parameter F283 for the duration of the activation.
<i>Note: NO/NC = Normally Open/Normally Closed. Selection numbers are used when selecting using communications.</i>		

Table 7. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions
NO	NC	
138	139	Stop Limit-Switch Forward — Activating this terminal applies the Stop command. The deceleration rate is set at parameter F284 .
140	141	Slow-Speed Limit-Switch Reverse — Activating this terminal applies the modified Upper-Limit Slow Speed setting of F293 and the modified Deceleration setting of parameter F285 for the duration of the activation.
142	143	Stop Limit-Switch Reverse — Activating this terminal applies the Stop command. The deceleration rate is set at parameter F286 .
144	145	Emergency Lift — Activating this terminal initiates the Emergency-Lift function and continues for the duration of the activation. This feature requires that the Emergency-Lift function be enabled at F656 .
146	147	Timed Run — Activating this terminal outputs the commanded speed (from RR, Communications, etc.) for the duration of the Timed-Run Run-Time setting.
148	149	External Fault — In a multiple ASD configuration a faulted ASD signals the remaining ASDs that a fault has occurred and shuts down the non-faulted ASDs. The non-faulted ASDs receive an External Fault signal via this terminal from the faulted ASD.
150	151	Creep Speed 1 Command — Activating this terminal modifies the output frequency of the ASD by multiplying the commanded frequency by the setting at the Creep Multiplier 1 parameter. The modified output is allowed to run for the number of pulse counts of the Super Creep Pulse Count parameter.
152	153	Creep Speed 2 Command — Activating this terminal modifies the output frequency of the ASD by multiplying the commanded frequency by the setting at the parameter. The modified output is allowed to run for the number of pulse counts of the Super Creep Pulse Count parameter. This setting is ignored if Creep Multiplier #1 is active.
154	155	Brake Failure — This terminal is activated via a transducer in the event that, during closed-loop operation, encoder pulses are detected while the brake is applied.
156	157	Super Creep — Terminal activation rotates the motor for the amount of encoder pulses set at the Super Creep Pulse Count parameter at the frequency setting of Super Creep Speed parameter. Available in closed-loop operation only.
<i>Note: NO/NC = Normally Open/Normally Closed. Selection numbers are used when selecting using communications.</i>		

Table 8. Output Terminal Assignments for the **FP**, **AM**, **FM**, **MON1**, and **MON2** Output Terminals.

Output Meter Terminal Assignments and Display Item Selections			
Selection/ Comm Number	Terminal Assignment Name	Selection/ Comm Number	Terminal Assignment Name
0	Output Frequency	30	100% Meter Adjust Value
1	Frequency Reference	31	Data from Communications
2	Output Current	32	185% Meter Adjust Value
3	DC Bus Voltage	33	250% Meter Adjust Value
4	Output Voltage	34	Input Watt Hour
5	Compensated Frequency	35	Output Watt Hour
6	Speed Feedback (Realtime)	45	Gain Display
7	Speed Feedback (1 Sec Filter)	46	My Function Monitor 1 Without Sign
8	Torque	47	My Function Monitor 2 Without Sign
9	Torque Command	48	My Function Monitor 3 With Sign
11	Torque Current	49	My Function Monitor 4 With Sign (FP End)
12	Excitation Current	50	Signed Output Frequency
13	PID Feedback Value	51	Signed Frequency Reference (Before PI)
14	Motor Overload Ratio	52	Signed Compensated Frequency
15	ASD Overload Ratio	53	Signed Speed Feedback (Realtime)
16	DBR Overload Ratio	54	Signed Speed Feedback (1 Sec Filter)
17	DBR Load Ratio	55	Signed Torque
18	Input Power	56	Signed Torque Command
19	Output Power	58	Signed Torque Current
23	Option V/I Input	59	Signed PID Feedback Value
24	RR Input	60	Signed RX Input
25	V/I Input	61	Signed RX2 Option (AI1) Input
26	RX Input	62	Signed 100% Meter Adjust Value
27	RX2 Option (AI1) Input	63	Signed 185% Meter Adjust Value
28	FM Output	64	Signed 250% Meter Adjust Value
29	AM Output		

Table 9. **My Function** Input Function Target Selections.

Selection/ Communications Number	Terminal Assignment (Physical Terminals Or Memory Locations Where Virtual/Internal)	Selection/ Communications Number	Terminal Assignment (Physical Terminals Or Memory Locations Where Virtual/Internal)
0	Unassigned	17	B12
1	Forward	18	B13
2	Reverse	19	B14
3	Standby	20	B15
4	Reset	21	Virtual Input Terminal 1
5	I1	22	Virtual Input Terminal 2
6	I2	23	Virtual Input Terminal 3
7	I3	24	Virtual Input Terminal 4
8	I4	25	Internal Terminal 1
9	LI1	26	Internal Terminal 2
10	LI2	27	Internal Terminal 3
11	LI3	28	Internal Terminal 4
12	LI4	29	Internal Terminal 5
13	LI5	30	Internal Terminal 6
14	LI6	31	Internal Terminal 7
15	LI7	32	Internal Terminal 8
16	LI8		

Table 10. **My Function** Input Setting (Input Function Target) Assignments, and Parameter/Input Setting Numbers for the **BRAKE-A/B/C**, **OUT1**, **OUT2**, **OUT3–OUT6**, and **R1–R4** Terminals.

Discrete Output Terminal Assignment Selections (Positive Logic)					
Input Setting	Param. Setting	Function	Input Setting	Param. Setting	Function
1000	0	Lower-Limit Frequency	1074	74	Reverse Speed Limit (Torque Control)
1002	2	Upper-Limit Frequency	1076	76	ASD Healthy Output
1004	4	Low Speed Signal	1078	78	RS485 Communication Error
1006	6	Acceleration/Deceleration Completion	1080	80	Error Code Output 1
1008	8	Speed Reach Signal	1082	82	Error Code Output 2
1010	10	Failure BRAKE (All Trips)	1084	84	Error Code Output 3
1012	12	Failure BRAKE (Except EF, OCL, EPHO, OL2)	1086	86	Error Code Output 4
1014	14	Over-Current (OC) Alarm	1088	88	Error Code Output 5
1016	16	ASD Overload (OL1) Alarm	1090	90	Error Code Output 6
1018	18	Motor Overload (OL2) Alarm	1092	92	Specified Data Output 1
1020	20	Overheat Alarm	1094	94	Specified Data Output 2
1022	22	Over-Voltage Alarm	1096	96	Specified Data Output 3
1024	24	Main Circuit (MOFF) Under-Voltage Alarm	1098	98	Specified Data Output 4
1026	26	Low-Current Alarm	1100	100	Specified Data Output 5
1028	28	Over-Torque Alarm	1102	102	Specified Data Output 6
1030	30	DBR Overload Alarm	1104	104	Specified Data Output 7
1032	32	Emergency Off Active	1106	106	Switch Out Of Sequence
1034	34	Retry Active	1108	108	Heavy Load
1036	36	Pattern Operation Switching Output	1110	110	Positive Torque Limit
1038	38	PID Deviation Limit	1112	112	Negative Torque Limit
1040	40	Run/Stop	1114	114	External Rush Suppression Relay Activated
1042	42	Serious Failure (OCA, OCL, EF, Phase Failure, etc.)	1118	118	Completion of Stop Positioning
1044	44	Light Failure (OL, OC1, 2, 3, OP)	1120	120	L-STOP
1046	46	Commercial Power/ASD Switching Output 1	1122	122	Power Failure Synchronized Operation
1048	48	Commercial Power/ASD Switching Output 2	1124	124	Traverse Active
1050	50	Cooling Fan On/Off	1126	126	Traverse Deceleration Active
1052	52	Jogging Operation Active (Jog Run Active)	1128	128	Part Replacement Alarm
1054	54	Panel/Terminal (Board) Operation Switching	1130	130	Over-Torque Alarm
1056	56	Bearing Greaser Run-Time Alarm	1132	132	Frequency Command ½ Selection
1058	58	ProfiBus/DeviceNet/CC-Link Communication Error	1134	134	Failure BRAKE (Non-Emergency Off)
1060	60	Forward/Reverse Switching	1136	136	External Fault
1062	62	Ready for Operation 1	1138	138	Drooping Fault
1064	64	Ready for Operation 2	1140	140	Run Before Ready
1068	68	Brake Release (BR)	1142	142	Slow-Speed Limit Switch
1070	70	Alarm Status Active	1144	144	Stop Limit-Switch Forward
1072	72	Forward Speed Limit (Torque Control)	1146	146	Slow-Speed Limit Switch

Table 10. (Continued) **My Function** Input Setting (Input Function Target) Assignments, and Parameter/Input Setting Numbers for the **BRAKE-A/B/C**, **OUT1**, **OUT2**, **OUT3–OUT6**, and **R1–R4** Terminals.

Discrete Output Terminal Assignment Selections (Positive Logic)					
1148	148	Stop Speed-Limit Switch	1232	232	My Function Output 6
1150	150	Emergency Lift	1234	234	My Function Output 7
1152	152	Timed Run	1236	236	My Function Output 8
1154	154	Brake Failure	1238	238	My Function Output 9
1156	156	Brake Seized	1240	240	My Function Output 10
1158	158	Slack Rope	1242	242	My Function Output 11
1160	160	Encoder Loss	1244	244	My Function Output 12
1162	162	Fault Stop	1246	246	My Function Output 13
1222	222	My Function Output 1	1248	248	My Function Output 14
1224	224	My Function Output 2	1250	250	My Function Output 15
1226	226	My Function Output 3	1252	252	My Function Output 16
1228	228	My Function Output 4	1254	254	Always Off
1230	230	My Function Output 5			

Table 11. Trace Back Data Selections.

Selection Number	Comm. Number	Trace (Monitor) Function	Resolution/ Unit
0	FD00	Output Frequency	0.01 Hz
1	FD02	Frequency Reference	0.01 Hz
2	FD03	Output Current	0.01%
3	FD04	DC Bus Voltage	0.01%
4	FD05	Output Voltage	0.01%
5	FD15	Compensated Frequency	0.01 Hz
6	FD16	Speed Feedback (Realtime)	0.01 Hz
7	FD17	Speed Feedback (1 Sec Filter)	0.01 Hz
8	FD18	Torque	0.01%
9	FD19	Torque Command	0.01%
11	FD20	Torque Current	0.01%
12	FD21	Excitation Current	0.01%
13	FD22	PID Feedback Value	0.01 Hz
14	FD23	Motor Overload Ratio	0.01%
15	FD24	ASD Overload Ratio	0.01%
16	FD25	DBR Overload Ratio	1%
17	FD28	DBR Load Ratio	1%
18	FD29	Input Power	0.01 kW
19	FD30	Output Power	0.01 kW
23	FE39	V/I Option (AI2)	1%
24	FE35	RR Input	0.01%
25	FE36	V/I Input	0.01%
26	FE37	RX Input	0.01%
27	FE38	RX2 Option (AI1)	1%
28	FE40	FM Output	0.01%
29	FE41	AM Output	0.01%
30	FE51	Signed 100% Meter Adjust Value	1%
31	FA51	Communication Data	N/A
32	FE50	Signed 185% Meter Adjust Value	1%
33	FE67	Signed 250% Meter Adjust Value	1%
34	FE76	Input Watt-Hour	0.01 kWhr
35	FE77	Output Watt-Hour	0.01 kWhr
45	0006/0671	AM/FM Gain Display	1
46	FE60	My Function Monitor 1 (Unsigned Value)	1
47	FE61	My Function Monitor 2 (Unsigned Value)	1
48	FE62	My Function Monitor 3 (Signed Value)	1
49	FE63	My Function Monitor 4 (Signed Value)	1

Table 12. Input Function Target Selections and the Associated Communications Numbers.

Input Setting/Communication Number				Function	Resolution /Unit
AM/FM/FP Input Setting	Comm. Number	Monitor Display Input Setting	Comm. Number		
2000	FD00	3000	FE00	Output Frequency	0.01 Hz
2002	FD02	3002	FE02	Frequency Reference	0.01 Hz
2003	FD03	3003	FE03	Output Current	0.01%
2004	FD04	3004	FE04	DC Bus Voltage	0.01%
2005	FD05	3005	FE05	Output Voltage	0.01%
2015	FD15	3015	FE15	Compensated Frequency	0.01 Hz
2016	FD16	3016	FE16	Speed Feedback (Realtime) (<i>See Note 1</i>)	0.01 Hz
2017	FD17	3017	FE17	Speed Feedback (1 Sec Filter) (<i>See Note 1</i>)	0.01 Hz
2018	FD18	3018	FE18	Torque (<i>See Note 2</i>)	0.01%
2019	FD19	3019	FE19	Torque Command (<i>See Note 2</i>)	0.01%
2020	FD20	3020	FE20	Torque Current (<i>See Note 2</i>)	0.01%
2021	FD21	3021	FE21	Excitation Current	0.01%
2022	FD22	3022	FE22	PID Feedback Value	0.01 Hz
2023	FD23	3023	FE23	Motor Overload Ratio	0.01%
2024	FD24	3024	FE24	ASD Overload Ratio	0.01%
2025	FD25	3025	FE25	DBR Overload Ratio	1%
2028	FD28	3028	FE28	DBR Load Ratio	1%
2029	FD29	3029	FE29	Input Power	0.01 kW
2030	FD30	3030	FE30	Output Power	0.01 kW
		3031	FE31	Pattern Operation Group Number	0.1
		3032	FE32	Pattern Operation Cycles Remaining	1
		3033	FE33	Pattern Operation Preset Speed Number	1
		3034	FE34	Pattern Operation Preset Speed Time Remaining	0.1
2050	FD50			Express-Speed Load Torque Monitor 1	0.01%
2051	FD51			Express-Speed Load Torque Monitor 2	0.01%
		3035	FE35	RR Input	1%
		3036	FE36	V/I Input	1%
		3037	FE37	RX Input (<i>See Note 2</i>)	1%
		3038	FE38	RX2 Option (AI1) Input (<i>See Note 2</i>)	1%
		3039	FE39	RX2 Option (AI1) Input	1%
		3040	FE40	FM Output	1
		3041	FE41	AM Output	1
Note 1: If no PG feedback is used an estimated speed value is displayed.					
Note 2: My Function cannot process negative values — A negative value is processed by My Function as an absolute value.					

Table 12. (Continued) **Input Function Target** Selections and the Associated Communications Numbers.

Input Setting/Communication Number				Function	Resolution /Unit
AM/FM/FP Input Setting	Comm. Number	Monitor Display Input Setting	Comm. Number		
3050	FE50			Communication Data Output 2	
3051	FE51			Communication Data Output 1	
3052	FE52			Communication Data Output 3	
3060	FE60			My Function Monitor 1 (Output of Unsigned Value)	
3061	FE61			My Function Monitor 2 (Output of Unsigned Value)	
3062	FE62			My Function Monitor 3 (Output of Signed Value)	
3063	FE63			My Function Monitor 4 (Output of Signed Value)	
		3066	FE66	Expansion I/O Card 1 CPU Version	
		3067	FE67	Expansion I/O Card 2 CPU Version	
		3076	FE76	Integral Input Power	0.01 kW
		3077	FE77	Integral Output Power	0.01 kW
		3084	FE84	16-Bit BIN/BCD Input Value	1
Note 1: If no PG feedback is used an estimated speed value is displayed.					
Note 2: My Function cannot process negative values — A negative value is processed by My Function as an absolute value.					

Table 13. **My Function** Operator Selections.

My Function Computational Selections		
Input Function Command	Function Name	Function Description
0	NOP (No Operation)	Disables the My Function feature.
1	ST	Execute data read/transfer.
2	STN	Execute inverted data read/transfer.
3	AND	Logical product of A AND B.
4	ANDN	Logical product of A AND \overline{B} .
5	OR	Logical sum of A OR B.
6	ORN	Logical sum of A OR \overline{B} .
7	EQ	Compares data — Outputs 1 if Equal; 0 if not Equal.
8	NE	Compares data — Outputs 0 if Equal; 1 if not Equal.
9	GT	Compares data — Outputs 1 if $A > B$; 0 if $A \leq B$.
10	GE	Compares data — Outputs 1 if $A \geq B$; 0 if $A < B$.
11	LT	Compares data — Outputs 1 if $A < B$; 0 if $A \geq B$.
12	LE	Compares data — Outputs 1 if $A \leq B$; 0 if $A > B$.
13	ASUB	Outputs absolute difference between A and B — $ A - B $.
14	ON (Timer)	Enables the On response time delay settings of My Function Time Data 1 – 5 (F928 – F932) for My Function Data .
15	Off (Timer)	Enables the Off response time delay settings of My Function Time Data 1 – 5 (F928 – F932) for My Function Data .
16	COUNT1 (Timer)	Outputs a 1 upon reaching the pulse count setting of F933.
17	COUNT2 (Timer)	Outputs a 1 upon reaching the pulse count setting of F934.
18	HOLD	Outputs the peak output value since powering up or since the last reset.
19	SET	Sets data.
20	RESET	Resets data.

Alarms, Trips, and Troubleshooting

Alarms and Trips

This section provides information that assists the user in the event that a **Fault** is incurred.

If a user setting or a ASD parameter has been exceeded, or if a data transfer function produces an unexpected result, a condition that is referred to as a **Fault** is incurred.

An **Alarm** is an indication that a **Fault** is imminent if existing operating conditions continue unchanged. An **Alarm** may be associated with an output terminal to notify the operator of the condition remotely, close a contact, or engage a brake. At the least, an **Alarm** will cause an alarm code to appear on the EOI screen. [Table 14 on pg. 249](#) lists the **Alarm** codes that may be displayed during operation of the ASD.

In the event that the condition that caused the **Alarm** does not return to its normal operating level within a specified time, the ASD **Faults** and a **Trip** is incurred (**Fault** and **Trip** are sometimes used interchangeably).

A **Trip** is a safety feature (the result of a **Fault**) that disables the ASD system and removes the 3-phase power to the motor in the event that a subsystem of the ASD is malfunctioning, or one or more of the variables listed below exceeds its normal range (time and/or magnitude).

- Current,
- Voltage,
- Speed,
- Temperature,
- Torque, or
- Load.

See [Table 15 on pg. 254](#) for a listing of the potential **Trips** and the associated probable causes.

The operating conditions at the time of the trip may be used to help determine the cause of the trip. Listed below are operating conditions that may be used to assist the operator in correcting the problem or that the ASD operator should be prepared to discuss when contacting ACE World Companies Customer Support Center for assistance.

- What trip information is displayed?
- Is this a new installation?
- Has the system ever worked properly and what are the recent modifications (if any)?
- What is the ASD and motor size?
- What is the CPU version and revision level?
- What is the EOI version?
- Does the ASD trip when accelerating, running, decelerating, or when not running?
- Does the ASD reach the commanded frequency?
- Does the ASD trip without the motor attached?
- Does ASD trip with an unloaded motor?

Alarms

Table 14 lists the alarm codes that may be displayed during operation of the ASD. Each alarm code listed is accompanied by a description and a possible cause. In the event that the source of the malfunction cannot be determined, contact your ACE World Companies Customer Support Center for additional information on the condition and for an appropriate course of action.

Table 14. ACE-tronics G9 ASD Alarms.

LCD Screen	LED Screen	Description	Possible Causes
*ASD Overload	OL I	Load requirement in excess of the capability of the ASD.	<ul style="list-style-type: none"> The carrier frequency is too high. An excessive load. Acceleration time is too short. DC damping rate is set too high. The motor is starting into a spinning load after a momentary power failure. The ASD is improperly matched to the application.
Autotuning	Atn	Autotune active.	<ul style="list-style-type: none"> Autotune active.
Brake Failure	brKF	Encoder pulses greater than F994 setting detected while brake is set or during normal operation more pulses than the F995 setting occurred after applying the brake.	<ul style="list-style-type: none"> Brake Failure.
Brake Fault	brF	Encoder pulses received with brake on during torque proving or during continuous brake load-hold.	<ul style="list-style-type: none"> Pulses received from encoder during torque proving. Closed-loop Hoist Mode operation, brake is on with no Run command and encoder pulses are received.
*Brake Resistor Overload	OLr	Excessive current at the Dynamic Braking Resistor .	<ul style="list-style-type: none"> Deceleration time is too short. DBR configuration improperly set.
Brake Seized	brS	No encoder pulses received after brake release with active Run command.	<ul style="list-style-type: none"> Closed-loop Hoist Mode operation, encoder pulses less than the F993 setting received after brake release with an active Run command.
Comm1 Error	EN I	Internal communications error.	<ul style="list-style-type: none"> DeviceNet/Profibus/CC-Link Failure. Improperly programmed ASD. Improper communications settings. Improperly connected cables.
* Reset ignored if active.			

LCD Screen	LED Screen	Description	Possible Causes
Comm2 Error	Err2	External communications error.	<ul style="list-style-type: none"> • RS485 Failure. • Improperly programmed ASD. • Improper communications settings. • Improperly connected cables.
*Control Under-Voltage	P0FF	Under-voltage condition at the 5, 15, or the 24 VDC supply.	<ul style="list-style-type: none"> • Defective Control board. • Excessive load on power supply. • Low input voltage.
Drooping	droP	Encoder pulses received in excess of F998 setting of the opposite direction of the commanded frequency.	<ul style="list-style-type: none"> • Requirements of the load are in excess of the capability of the motor. • Falling load.
Emergency Lift	Lift	Hoist-control function switches from closed-loop operation to open-loop operation. Max speed UP = F657. Max speed DOWN = F656.	<ul style="list-style-type: none"> • Encoder feedback signal has been lost and discrete input terminal #144 is activated or F867 is set to Enabled.
External Fault	EFLE	Non-faulted ASD in a multiple ASD system.	<ul style="list-style-type: none"> • ASD of a multiple ASD system has faulted — the non-faulted ASD(s) incur an External Fault.
Forward Limit Switch	FLS	Forward Limit Switch Activated.	<ul style="list-style-type: none"> • Crane has approached the end-of-travel for the selected operating plane as indicated by the limit switch.
Heavy Load	HLD	Output torque requirement has exceeded the setting of F337.	<ul style="list-style-type: none"> • Load too heavy for motor. • Resets when output torque requirement drops below the setting of F337
Main Under-Voltage	U0FF	Under-voltage condition at the 3-phase AC input to the ASD.	<ul style="list-style-type: none"> • Low 3-phase utility voltage.
Maintenance Timer	LEA	Bearing Greaser Time has expired.	<ul style="list-style-type: none"> • Bearing Greaser Alarm Time setting has expired (F621). • Ambient Average Temperature Time setting has expired (F634).
Motor Overload	OLN	Load requirement in excess of the capability of the motor.	<ul style="list-style-type: none"> • V/f parameter improperly set. • Motor is locked. • Continuous operation at low speed. • Load too heavy for motor.
* Reset ignored if active.			

LCD Screen	LED Screen	Description	Possible Causes
MS Relay Off/Soft Start Alarm	OFF	Under-voltage condition at the 3-phase AC input to the ASD.	<ul style="list-style-type: none"> Low 3-phase utility voltage.
Over-Current	OC	ASD output current greater than F601 setting.	<ul style="list-style-type: none"> Defective IGBT (U, V, or W). ASD output to the motor is connected incorrectly. ASD output phase-to-phase short. The ASD is starting into a spinning motor. Motor/machine jammed. Mechanical brake engaged while the ASD is starting or while running. Accel/Decel time is too short. Voltage Boost setting is too high. Load fluctuations. ASD operating at an elevated temperature.
*Over-Heat	OH	ASD ambient temperature excessive.	<ul style="list-style-type: none"> ASD is operating at an elevated temperature. ASD is too close to heat-generating equipment. Cooling fan vent is obstructed (see Mounting the ASD on pg. 15). Cooling fan is inoperative. Internal thermistor is disconnected.
Over-Torque	OT	Torque requirement in excess of the setting of F616 or F617 for a time longer than the setting of F618.	<ul style="list-style-type: none"> ASD is not correctly matched to the application. F616 or F617 setting is too low. Obstructed load.
* Reset ignored if active.			

LCD Screen	LED Screen	Description	Possible Causes
*Over-Voltage	OP	DC bus voltage exceeds specifications.	<ul style="list-style-type: none"> ASD attempting to start into a spinning motor after a momentary power loss. Incoming utility power is above the specified range. Decel time is too short. Voltage spikes at the 3-phase input. Inductive filter required. DBR required. DBR resistance value is too high. DBR function is turned off. Over-Voltage Stall feature is turned off. System is regenerating. Load instability. Disable the Ridethrough function (F302).
Pre Over-Torque	POT	Output torque of ASD is greater than 70% of parameter F616 setting.	<ul style="list-style-type: none"> Parameter F616 requires an adjustment. Load requirement exceeds ability of the motor.
Reverse Limit Switch	RLS	Reverse Limit Switch Activated.	<ul style="list-style-type: none"> Crane has approached the end-of-travel for the selected operating plane as indicated by the limit switch.
Run Before Ready	rbR	Run command received at power up or Reset activated while running.	<ul style="list-style-type: none"> F or R terminal on during application of power or system receives a Reset while running.
Slack Rope	SLR	Output torque level is too low.	<ul style="list-style-type: none"> Closed-loop Hoist Mode operation in the reverse direction with F867 enabled, output torque is less than F868 setting for F869 time.
Switch Out Of Sequence	SOF	Run command active during power up or Reset activated while running.	<ul style="list-style-type: none"> Run command active during power up or Reset activated while running.
Timed Run	TRN	Timed Run Active.	<ul style="list-style-type: none"> Timed Run Activated via discrete input terminal. F861 set to a non-zero value.
Cumulative Run Time	CU	Run-time counter exceeded.	<ul style="list-style-type: none"> Type Reset required; select Clear Run Timer.
Torque Proving	TPF	Output torque level is too low.	<ul style="list-style-type: none"> Closed-loop Hoist Mode operation, within F988 time setting the ASD output torque level has not reached the F987 setting or is unable to maintain the F987 setting for F989 time setting during active Run command.
* Reset ignored if active.			

LCD Screen	LED Screen	Description	Possible Causes
Under-Current	UL	With the Low-Current Trip (F610) parameter enabled, the output current of the ASD is below the level defined at F611 and remains there for a time longer than the setting of F612 .	<ul style="list-style-type: none"> • The ASD is improperly matched to the application. • Motor lead disconnected.

Trips/Faults

A **Trip** is an ASD response to a **Fault** (though Fault and Trip are sometimes used interchangeably). A **Trip** is a safety feature that disables the ASD system in the event that a subsystem of the ASD is malfunctioning or a parameter setting has been exceeded.

Listed in [Table 15](#) are the **Faults** that may result in a **Trip** and the possible causes. When a **Trip** is incurred the LCD screen shows the **Fault** screen and the LED screen displays the active **Fault** code.

Table 15. ACE-tronics G9 ASD Fault Listing.

LCD Screen	LED Screen	Possible Causes
Analog Input Loss	E - 18	<ul style="list-style-type: none"> V/I signal loss. ACE G9-120V-PCB failure. P24 over-current condition. F633 setting is too high.
Analog Input Over-Voltage	E - 10	<ul style="list-style-type: none"> Over-voltage at the V/I, RX, or RR input(s).
ASD Overload	0L 1	<ul style="list-style-type: none"> Acceleration time is too short. DC Injection current is too high. Improper V/f setting. Motor running during restart. ASD or the motor is improperly matched to the application.
Autotune Error	EEn	<ul style="list-style-type: none"> Autotune readings that are significantly inconsistent with the configuration information. A non-3-phase motor is being used. Incorrect settings at F400 or F413. Using a motor that has a significantly smaller rating than the ASD. ASD output cabling is too small, too long, or is being housed in a cable tray with other cables that are producing an interfering EMF. Motor is running during the Autotune function.
	EEn 1	<ul style="list-style-type: none"> F402 adjustment required (Motor temperature is too high). F410 adjustment required (Motor Constant 1 improperly set).
	EEn2	<ul style="list-style-type: none"> F412 adjustment required (Motor Constant 3 improperly set).
	EEn3	<ul style="list-style-type: none"> Autotune setting F400 is set to Auto Calculation and there is a problem with the Motor Constant readings; F405, F406, and F407.
Brake Sequence Response Error	E - 11	<ul style="list-style-type: none"> F630 is set to a non-zero value. Braking sequence discrete input and output terminals are not setup properly.
Communication Error	Err5	<ul style="list-style-type: none"> Communication time out error. Communication malfunction. Improper or loose connection. Improper system settings.

LCD Screen	LED Screen	Possible Causes
Control Power Under-Voltage	UP2	<ul style="list-style-type: none"> This fault is caused by an under-voltage condition at the 5, 15, or the 24 VDC supply. 3-phase input voltage low.
CPU2 Fault	E-26	<ul style="list-style-type: none"> CPU malfunction. Control board malfunction.
CPU Communication Error	E-19	<ul style="list-style-type: none"> CPU data Transmit/Receive error.
CPU Fault	Err4	<ul style="list-style-type: none"> CPU malfunction. Control board malfunction.
CPU Processing Error	E-21	<ul style="list-style-type: none"> Software processed incorrectly. Make service call.
Dynamic Braking Resistor Over-Current	OLr	<ul style="list-style-type: none"> ASD inability to discharge the bus voltage during regeneration. No Dynamic Braking Resistor (DBR) installed. DBR value is too low. Deceleration time is too short. Improper DBR setup information. Defective IGBT7 (or IGBT7 ckt.). 3-phase input voltage is above specification.
Dynamic Braking Resistor Overload	OLr	<ul style="list-style-type: none"> Deceleration time is too short. Improper DBR setup information. Improper Stall setup information.
EEPROM Fault	EEP1	<ul style="list-style-type: none"> EEPROM write malfunction.
EEPROM Read Error	EEP2/EEP3	<ul style="list-style-type: none"> EEPROM read malfunction.
Emergency Off	E	<ul style="list-style-type: none"> Output signal from the ASD is terminated and a brake may be applied if so configured. Stop-Reset pressed twice at the EOI. EOFF command received remotely. ASD reset required.
Encoder Signal-Loss Error	E-12	<ul style="list-style-type: none"> ASD is configured to receive a signal from a shaft-mounted encoder and no signal is being received while running. Disconnection at the Encoder circuit. Motor is stopped and is generating torque via torque limit control. ASD is not configured properly.
External Fault	EFLE	<ul style="list-style-type: none"> In a multiple-ASD configuration, this is the fault screen display of an ASD that is not the cause of the fault, but is unable to continue with normal operations.

LCD Screen	LED Screen	Possible Causes
External Overheat	OH2	<ul style="list-style-type: none"> Excessive-heat signature received at the TB3 – TH1(+) and TH1(-) terminals. See F637 for setup information.
Flash Memory Fault	Err9	<ul style="list-style-type: none"> Flash memory malfunction.
Gate Array Fault	Err6	<ul style="list-style-type: none"> Main Gate Array is defective.
Ground Fault	EF 1/EF2	<ul style="list-style-type: none"> Ground fault at the motor. Ground fault at the output of the ASD. Current leakage to Earth Ground.
Input Phase Failure	EPH 1	<ul style="list-style-type: none"> 3-phase input to the ASD is low or missing at the R, S, or T input terminals.
Key Failure	E-17	<ul style="list-style-type: none"> Same key input for 20 seconds or more.
Logic Input Voltage Error	E-22	<ul style="list-style-type: none"> Incorrect voltage applied to the discrete input terminals.
Low Current	Err7	<ul style="list-style-type: none"> Improper Low-Current Detection level settings at F609 – F612.
Main Power Under-Voltage	UP 1	<ul style="list-style-type: none"> Input 3-phase voltage is too low. Momentary power failure longer than the time setting of F628.
Motor Overload	OL2	<ul style="list-style-type: none"> Improper V/f setting. Motor is locked. Continuous operation at low speed. Load requirement exceeds ability of the motor. Startup frequency setting adjustment required.
No Errors	none	<ul style="list-style-type: none"> No active faults.
Optional Expansion Input Terminal Board 1 Error	E-23	<ul style="list-style-type: none"> Optional Expansion Input Terminal Board 1 is defective.
Optional Expansion Input Terminal Board 2 Error	E-24	<ul style="list-style-type: none"> Optional Expansion Input Terminal Board 2 is defective.
Option Device Fault	Err8	<ul style="list-style-type: none"> Check installation, connections, and option device manual.
Output Phase Failure	EPHO	<ul style="list-style-type: none"> 3-phase output from the ASD is low or missing at the U, V, or W output terminals or at the input to the motor.

LCD Screen	LED Screen	Possible Causes
Over-Current During Acceleration	OC 1	<ul style="list-style-type: none"> • Improper V/f setting. • Restart from a momentary power outage. • The ASD is starting into a rotating motor. • ASD/Motor not properly matched. • Phase-to-phase short (U, V, or W). • Accel time too short. • Voltage Boost setting is too high. • Motor/machine jammed. • Mechanical brake engaged while the ASD is running. • ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during acceleration. On ASDs that are greater than 100 HP, this fault occurs when the ASD current exceeds 320% of the rated FLA during acceleration.
Over-Current During Deceleration	OC 2	<ul style="list-style-type: none"> • Phase-to-phase short (U, V, or W). • Deceleration time is too short. • Motor/machine jammed. • Mechanical brake engaged while the ASD is running. • ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during deceleration. On ASDs that are greater than 100 HP, it occurs when the ASD current exceeds 320% of the rated FLA during deceleration.
Over-Current During Run	OC 3	<ul style="list-style-type: none"> • Load fluctuations. • ASD is operating at an elevated temperature. • ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during a fixed-speed run or if during a fixed-speed run the ASD overheats. On ASDs that are greater than 100 HP, it occurs when the ASD current exceeds 320% of the rated FLA on a fixed-speed run.
Over-Heat	OH	<ul style="list-style-type: none"> • Cooling fan inoperative. • Ventilation openings are obstructed. • Internal thermistor is disconnected.
Overheat During Acceleration	OC IP	<ul style="list-style-type: none"> • Cooling fan inoperative. • Ventilation openings are obstructed. • Internal thermistor is disconnected. • Acceleration time is too short. • Improper V/f setting. • ASD or the motor is improperly matched to the application.

LCD Screen	LED Screen	Possible Causes
Overheat During Deceleration	OC2P	<ul style="list-style-type: none"> Cooling fan inoperative. Ventilation openings are obstructed. Internal thermistor is disconnected. Deceleration time is too short. DC Injection current is too high. ASD or the motor is improperly matched to the application.
Overheat During Run	OC3P	<ul style="list-style-type: none"> Cooling fan inoperative. Ventilation openings are obstructed. Internal thermistor is disconnected. Improper V/f setting. ASD or the motor is improperly matched to the application.
Over-Torque	OL	<ul style="list-style-type: none"> A torque requirement by the load in excess of the setting of F616 or F617 for a time longer than the setting of F618. The ASD is improperly matched to the application. The load is obstructed.
Over-Voltage During Acceleration	OP1	<ul style="list-style-type: none"> Motor running during restart.
Over-Voltage During Deceleration	OP2	<ul style="list-style-type: none"> Deceleration time is too short. DBR value is too high. DBR required (DBR setup required). Stall protection is disabled. 3-phase input voltage is out of specification. Input reactance required.
Over-Voltage During Run	OP3	<ul style="list-style-type: none"> Load fluctuations. 3-Phase input voltage out of specification. DBR required or DBR setup is incomplete.
RAM Fault	Err2	<ul style="list-style-type: none"> Internal RAM malfunction.
ROM Fault	Err3	<ul style="list-style-type: none"> Internal ROM malfunction.
Speed Error	E-13	<ul style="list-style-type: none"> Result of a motor speed that is greater than the commanded speed when using an encoder for speed control. Improper encoder connection or setup information. Defective encoder.
Step Out (for PM Motor Only)	SOUL	<ul style="list-style-type: none"> Motor shaft is locked. Output phase is open. Operating a reciprocating load.

LCD Screen	LED Screen	Possible Causes
Stop Position Retaining Error	E-25	<ul style="list-style-type: none"> Load movement while stopped. F381 setting is too low. Encoder malfunction. Creep speed is too high.
Torque Proving	EPF	<ul style="list-style-type: none"> The output torque level setting of F987 was not reached in the time setting of F988 to allow for the brake release.
Typeform Error	E4YP	<ul style="list-style-type: none"> Firmware information (typeform) loaded into the Gate Driver board is inconsistent with the device in which the firmware is being used. The Gate Driver board has been replaced. The Gate Driver board is defective.
U-Phase Over-Current	OC A1	<ul style="list-style-type: none"> Internal low impedance at the U lead of the ASD.
U, V, or W Over-Current	OC L	<ul style="list-style-type: none"> External low impedance at the U, V, or W lead of the ASD output.
V/f Control Error	E-20	<ul style="list-style-type: none"> Torque processing error. Make service call.
V-Phase Over-Current	OC A2	<ul style="list-style-type: none"> Internal low impedance at the V lead of the ASD.
W-Phase Over-Current	OC A3	<ul style="list-style-type: none"> Internal low impedance at the W lead of the ASD.

Viewing Trip Information

In the event that the condition causing an **Alarm** does not return to the normal operating level within a specified time, the ASD **Faults** and a **Trip** is incurred.

When a **Trip** occurs, the resultant error information may be viewed either from the LED screen, LCD **Fault** screen (Table 15 on pg. 254), **Monitor** screen, or the **Trip History** screen (Program ⇒ Utilities ⇒ **Trip History**).

Trip Record at Monitor Screen

The at-trip condition of the last four incurred trips may be viewed on the **Monitor** screen. The **Monitor** screen displays the records of up to four trips and catalogs each trip as **Past Trip #1** through **Past Trip #4** (see pg. 56). Once reset (Type Reset), the trip records are erased. If no trips have occurred since being powered up or since the last reset, **None** is displayed for each trip record.

The **Monitor** screen at-trip record is erased when the ASD is reset.

Note: An improper ASD setup may cause some trips — reset the ASD to the **Factory Default** settings before pursuing a systemic malfunction (Program ⇒ Utilities ⇒ Type Reset ⇒ Reset to Factory Settings).

Trip History

The **Trip History** screen records the system parameters for up to 20 trips. The recorded trips are numbered from zero to 19. Once the **Trip History** record reaches trip number 19, the oldest recorded trip will be deleted with each new record stored (first-in first-out). The **Trip #** field may be selected and scrolled through to view the recorded trip information for a given trip number. The monitored parameters are listed in Table 16 as **At-Trip Recorded Parameters** (parameter readings at the time that the trip occurred).

Table 16. Trip History Record Parameters.

At-trip Recorded Parameters			
1) Trip Number	8) Frequency Reference	15) Feedback (1 sec.)	22) ASD Overload
2) Trip Type	9) Bus Voltage	16) Torque	23) DBR Overload
3) Time and Date	10) Discrete Input Status	17) Torque Reference	24) Motor Load
4) Frequency at Trip	11) OUT1/OUT2/BRAKE Status	18) Torque Current	25) ASD Load
5) Output Current	12) Timer	19) Excitation Current	26) DBR Load
6) Output Voltage	13) Post Compensation Frequency	20) PID Value	27) Input Power
7) Direction	14) Feedback (inst.)	21) Motor Overload	28) Output Power
Trip records are comprised of the full list of monitored parameters (28).			

Clearing a Trip

Once the cause of the trip has been corrected, performing a **Reset** re-enables the ASD for normal operation.

The trip may also be cleared using either of the following methods:


- Cycling power (trip info may be saved via F602 if desired),
- Pressing the **Stop-Reset** key twice,
- Remotely via the communications channel,
- Momentarily activating the **RES** terminal of the **ACE G9-120V-PCB**, or
- Via Program ⇒ Utilities ⇒ Type Reset ⇒ **Clear Past Trip** (clears Monitor screen records only).

Enclosure Dimensions and Conduit Plate Information

The part numbering convention is shown below. Use this information for ordering and to identify the ASD typeform.

The enclosure dimensions for the available models (typeforms) are listed in [Tables 17](#) and [18](#). The conduit plates referenced are shown in [Figures 36](#), [37](#), and [38](#).

G9 Part Numbering Convention.



Note: The Type 1 enclosed versions of these drives meet or exceed the specification **UL 50- 1995, the Standard for Heating and Cooling Equipment**, and complies with the applicable requirements for installation in a compartment handling conditioned air.

Note: All ACE-tronics ASD enclosures carry an IP20 rating.

Enclosure Dimensions

Table 17. 230-Volt ACE-tronics G9 ASD Systems.

Frame	Model Number	Enclosure Figure Number	A Width (in/mm)	B Height (in/mm)	C Depth (in/mm)	Mounting Hole Dimensions (in/mm)				Conduit Plate
						D	E	R1	R2	
2	ACEG92000	Figure 33	5.2/132	11.2/285	6.1/155	8.7/220	4.5/114	0.098/2.5	0.217/5.5	Figure 36-A
	ACEG92001									
	ACEG92002									
3	ACEG92003		6.1/155	12.4/315	6.6/168	9.8/249	5.4/138	0.098/2.5	0.217/5.5	Figure 36-A
	ACEG92005									
4	ACEG92007		6.9/175	15.0/381	7.6/193	11.1/283	6.2/158	0.098/2.5	0.236/6.0	Figure 36-B
5A	ACEG92010		8.3/211	15.1/384			7.5/190			Figure 36-C
5B	ACEG92015		9.1/231	19.3/490	7.6/193	15.2/386	8.3/210	0.118/3.0	0.276/7.0	Figure 36-D
	ACEG92020									
6	ACEG92025	Figure 34	11.1/283	25.9/658	13.2/335	25.0/635	8.0/203	0.188/4.8	0.375/9.5	Figure 36-E
7B	ACEG92030	Figure 34	14.3/363	33.1/841	15.0/381	32.3/820	8.0/203	0.188/4.8	0.375/9.5	Figure 37-G
	ACEG92040									
	ACEG92050									
	ACEG92060									
9	ACEG92075	Figure 35	14.6/371	51.7/1313	17.6/447	50.2/1275	9.2/234	0.344/8.7	0.670/17.0	Figure 37-I
10	ACEG92100		15.7/399	53.1/1349		51.7/1313	9.9/252			Figure 37-J

Table 18. 460-Volt ACE-tronics G9 ASD Systems.

Frame	Model Number	Enclosure Figure Number	A Width (in/mm)	B Height (in/mm)	C Depth (in/mm)	Mounting Hole Dimensions (in/mm)				Conduit Plate			
						D	E	R1	R2				
2	ACEG94001	Figure 33	5.2/132	11.2/285	6.1/155	8.7/220	4.5/114	0.098/2.5	0.217/5.5	Figure 36-A			
	ACEG94002												
	ACEG94003												
3	ACEG94005		6.1/155	12.4/315	6.6/168	9.8/249	5.4/138	0.118/3.0	0.276/7.0	Figure 36-B			
4	ACEG94007		6.9/175	15.0/381		11.1/283	6.2/158						
	ACEG94010												
5A	ACEG94015		8.3/211	15.1/384	7.6/193	15.2/386	7.5/190	0.118/3.0	0.276/7.0	Figure 36-C			
5B	ACEG94020		9.1/231	19.3/490			8.3/210			Figure 36-D			
	ACEG94025												
6	ACEG94030	Figure 34	11.1/283	25.9/658	13.2/335	25.0/635	8.0/203	0.188/4.8	0.375/9.5	Figure 36-E			
7A	ACEG94040			30.8/782	14.3/363	29.7/754				Figure 36-F			
	ACEG94050		14.3/363	36.1/917	15.3/389	35.3/897				Figure 37-H			
8	ACEG94060												
	ACEG94075												
	ACEG94100												
9	ACEG94120	Figure 35	14.6/371	51.7/1313	17.6/447	50.2/1275	9.2/234	0.344/8.7	0.670/17	Figure 37-I			
10	ACEG94150		15.7/399	53.1/1349		51.7/1313	9.9/252			Figure 37-J			
11	ACEG94200		15.0/381	63.1/1603		61.6/1565				Figure 37-K			
12	ACEG94250		18.9/480	68.5/1740		67.0/1701	13.8/351			Figure 37-L			
13	ACEG94300		25.6/650	70.0/1778		68.5/1740	21.3/541			Figure 38-M			
	ACEG94350												

Figure 33. See Table 17 and Table 18 for Actual Dimensions.




Figure 34. See Table 17 and Table 18 for Actual Dimensions.




Figure 35. See Table 17 and Table 18 for Actual Dimensions.




Figure 36. See Table 17 and Table 18 for the Associated Device. Dimensions are in in/cm.

ØX = Concentric Knockouts for Diameter Sizes 0.5", 0.75", and 1.0" Conduit.




Figure 37. See Table 17 and Table 18 for the Associated Device. Dimensions are in in/cm.





Figure 38. See Table 17 and Table 18 for the Associated Device. Dimensions are in in/cm.



Current/Voltage Specifications

Table 19. 230-Volt UL Type-1/IP-20 Chassis Standard Ratings Table.

Model Number	Output Current 100/115% Cont. (110% Cont. ≥ 60 HP)	Overload Current 150% for 60 Seconds	Overload Current 150% for 120 Seconds	Input Voltage 3-Ph 50/60 ±2 Hz	Output Voltage 3-Ph Variable Frequency	Typical Motor HP
ACEG92000	3.5/4.0 A	N/A	5.3 A	200–240 VAC (±10%)	Input Voltage Level (Max.)	0.75
ACEG92001	4.2/4.8 A		6.3 A			1.0
ACEG92002	6.9/7.9 A		10.4 A			2.0
ACEG92003	10.0/11.5 A		15.0 A			3.0
ACEG92005	15.2/17.5 A		22.8 A			5.0
ACEG92007	23.8/27.4 A		35.7 A			7.5
ACEG92010	28.6/32.9 A		42.9 A			10
ACEG92015	46.8/53.8 A		70.2 A			15
ACEG92020	57.2/65.8 A		85.8 A			20
ACEG92025	76.3/87.8 A		114.5 A			25
ACEG92030	90.0/103.5 A		135.0 A			30
ACEG92040	104.0/119.6 A		156.0 A			40
ACEG92050	152.5/175.4 A		228.8 A			50
ACEG92060	176.0/193.6 A	264.0 A	N/A	60		
ACEG92075	221.0/243.1 A	331.5 A		75		
ACEG92100	285.0/313.5 A	427.5 A		100		

Table 20. 460-Volt UL Type-1/IP-20 Chassis Standard Ratings Table.

Model Number	Output Current 100/115% Cont. (110% Cont. ≥ 125 HP)	Overload Current 150% for 60 Seconds	Overload Current 150% for 120 Seconds	Input Voltage 3-Ph 50/60 ±2 Hz	Output Voltage 3-Ph Variable Frequency	Typical Motor HP
ACEG94001	2.7/3.1 A	N/A	4.1 A	380 – 480 VAC (±10%)	Input Voltage Level (Max.)	1.0
ACEG94002	3.6/4.1 A		5.4 A			2.0
ACEG94003	5.0/5.8 A		7.5 A			3.0
ACEG94005	9.1/10.5 A		13.7 A			5.0
ACEG94007	12.4/14.3 A		18.6 A			7.5
ACEG94010	15.3/17.6 A		23.0 A			10
ACEG94015	24.0/27.6 A		36.0 A			15
ACEG94020	28.6/32.9 A		42.9 A			20
ACEG94025	35.7/41.1 A		53.6 A			25
ACEG94030	42.0/48.3 A		63.0 A			30
ACEG94040	57.2/65.8 A		85.8 A			40
ACEG94050	68.5/78.8 A		102.8 A			50
ACEG94060	81.5/93.7 A		122.3 A			60
ACEG94075	100.8/115.9 A		151.2 A			75
ACEG94100	138.7/159.5 A		208.1 A			100
ACEG94120	179/196.9 A	268.5 A	N/A			125
ACEG94150	215/236.5 A	322.5 A				150
ACEG94200	259/284.9 A	388.5 A				200
ACEG94250	314/345.4 A	471.0 A				250
ACEG94300	387/425.7 A	580.5 A				300
ACEG94350	427/469.7 A	640.5 A				350

Cable/Terminal/Torque Specifications

Installation should conform to the 2008 **National Electrical Code Article 110** (NEC) (Requirements for Electrical Installations), all regulations of the Occupational Safety and Health Administration, and any other applicable national, regional, or industry codes and standards.

Note: The following ratings are guidelines and shall not be the sole determining factor of the lug or wire size used with the ACE-tronics G9 ASD. Application-specific applicables, wire insulation type, conductor material, and local and regional regulations are but a few of the considerations when selecting the actual lug and wire type to be used with the ASD.

Note: Cable/Terminal specifications are based on the rated current of the ASD. The specifications **Do Not** include the 10% Service Factor.

Note: Use only 75° C copper wire/cable for motor and power connections.

For additional installation information see the section titled [Installation and Connections](#) on pg. 14.

Table 21. 230-Volt ACE-tronics G9 ASD Cable/Terminal/Torque Specifications.

Model Number	MCP Rating (Amps)	Typical Wire/Cable Size		Lug Size Range		Terminal Board	Torque				
		AWG or kcmil									
		Input/Output Power		Wire-Size/Lug-Capacity for Input/Output Power		TB1 – 4 Terminals	3Ø-Input	3Ø-Output			
		Recommended	Maximum	3Ø-Input	3Ø-Output	In-Lbs./Nm					
ACEG92000	15	14	10	14 to 8		20 (3-core shield) 5.3/0.6	11.5/1.3				
ACEG92001											
ACEG92002											
ACEG92003	30	12									
ACEG92005		10									
ACEG92007	50	8	8	12 to 8			17.7/2.0				
ACEG92010		6	4	10 to 4			21/2.4				
ACEG92015	75		3	8 to 3							
ACEG92020	100										
ACEG92025	125	4	2	2	12 to 1/0		4 to 1/0	50/5.7	53/6		
ACEG92030	150	1	4/0	6 to 250	2 to 300		275/31	168/19			
ACEG92040	175	1/0									
ACEG92050	200	3/0									
ACEG92060	250	4/0									
ACEG92075	300	*3/0	*4/0	6 to 250			275/31				
ACEG92100	400	*250	*250								

Note: (*) Indicates that the item is one of a set of two parallel cables.

Table 22. 460-Volt ACE-tronics G9 ASD Cable/Terminal/Torque Specifications.

Model Number	MCP Rating (Amps)	Typical Wire/Cable Size		Lug Size Range		Terminal Board	Torque		
		AWG or kcmil						3Ø-Input	3Ø-Output
		Input/Output Power		Wire-Size/Lug-Capacity for Input/Output Power		TB1 – 4 Terminals			
		Recommended	Maximum	3Ø-Input	3Ø-Output	In-Lbs./Nm			
ACEG94001	15	14	10	14 to 8		20 (3-core shield) 5.3/0.6	11.5/1.3		
ACEG94002									
ACEG94003									
ACEG94005									
ACEG94007	20	12	8	12 to 8			17.7/2.0		
ACEG94010	30	10							
ACEG94015		8	4	10 to 4			21/2.4		
ACEG94020	50	6	3	8 to 3					
ACEG94025	75								
ACEG94030	75	4	2	12 to 1/0	4 to 1/0		50/5.7	53/6.0	
ACEG94040	100								3
ACEG94050									
ACEG94060	125	1	4/0	6 to 250	1 to 300		275/31	168/19	
ACEG94075	175	1/0							
ACEG94100	200	3/0							
ACEG94120	250	*1/0	*4/0	6 to 250			275/31		
ACEG94150	300	*2/0	*250						
ACEG94200	400	*4/0							
ACEG94250	500	*250	*350	4 to 350			375/42.4		
ACEG94300	600	**3/0	**350	0 to 500	6 to 350				
ACEG94350	700	**4/0							

Note: (*) Indicates that the item is one of a set of two parallel cables.

Note: (**) Indicates that the item is one of a set of three parallel cables.

Dynamic Braking Resistor Specifications

Thermal protection for the DBR circuit (see [Figure 39. on pg. 275](#)) or an input contactor that will open the 3-phase power input circuit (see [Figure 40. on pg. 275](#)) to the ASD in the event that a DBR over-temperature condition occurs is a requirement. If a DBR failure occurs or should a power source over-voltage condition occur the DBR thermal protection circuitry will prevent hazardous DBR temperatures.

To use the **Dynamic Braking** function the following requirements must be met:

- **Enable** the DBR function.
- Select a **Resistance Value**.
- Set the **Continuous Braking Wattage** value at [F304](#), [F308](#), and [F309](#), respectively.

Set the **Braking Resistance Overload Time** at parameter [F639](#) to establish how long the braking resistor is allowed to sustain the overload condition before a trip is incurred (the factory default setting is 5 seconds).

Light-duty and heavy-duty resistors vary from a few ohms to several hundred ohms. The appropriate resistance size will be typeform-specific and application-specific. Contact the ACE World Companies Customer Support Center for more information on your specific DBR requirements.

Heavy-duty DBRs should be wired using the same gauge wire as the motor leads. Light-duty DBRs may use one wire size smaller (AWG or kcmil) than the motor leads.

Because the heat generated by the DBR will affect the cooling capacity of the heat sink, the resistor pack should be mounted above or to the side of the ASD — **Never below the ASD**. Maintain a minimum of six inches between the resistor pack and the ASD.

The total wire length from the ASD to the DBR should not exceed 10 feet.

The wiring from the ASD to the DBR should be twisted approximately two twists per foot throughout the length of the wire.

If EMI/RFI noise is of concern, the DBR wiring should be 3-core screened cable. The screen should connect to the ASD enclosure and the resistor enclosure.

CAUTION

Though the in-line DBR fuse and the thermal relay are designed into the system to prevent a catastrophic DBR over-current condition, they are both intended to be used as backup protection **ONLY**.

A proper typeform-specific and application-specific system setup that includes using the appropriate **Dynamic Braking Resistor and Overload** settings will be required.

Figure 39. DBR Configurations.





Figure 40. Shown below is a typical connection diagram using an MCCB with a Trip Coil (TC) in lieu of an input contactor. A control transformer is required for 400-Volt models only. The primary MC is opened in the event of a DBR over-current detection. With no power supplied to the ASD the failure will not be displayed on the **EOI**; see the Trip History for failure information once restarted.



Short Circuit Protection Recommendations

Table 23. 230/240 and 400/480-Volt ASD Recommended Circuit Breaker Selection.

Model Number	HP	Continuous Output Current (Amps)	Circuit Breaker Part Number
ACEG92000	0.75	3.5	HLL36015
ACEG92001	1	4.8	HLL36015
ACEG92002	2	8.0	HLL36015
ACEG92003	3	10.0	HLL36025
ACEG92005	5	17.5	HLL36025
ACEG92007	7.5	27.5	HLL36040
ACEG92010	10	33	HLL36050
ACEG92015	15	54	HLL36070
ACEG92020	20	66	HLL36090
ACEG92025	25	76	HLL36100
ACEG92030	30	90	HLL36100
ACEG92040	40	120	HLL36125
ACEG92050	50	152	HLL36150
ACEG92060	60	176	JLL36200
ACEG92075	75	221	JLL36250
ACEG92100	100	285	LIL36300
ACEG94001	1	2.7	Consult NEC
ACEG94002	2	4.1	HLL36015
ACEG94003	3	5.8	HLL36015
ACEG94005	5	10.5	HLL36025
ACEG94007	7.5	14.3	HLL36040
ACEG94010	10	17.6	HLL36050
ACEG94015	15	27.7	HLL36070
ACEG94020	20	33	HLL36090
ACEG94025	25	41	HLL36100
ACEG94030	30	48	HLL36100
ACEG94040	40	66	HLL36125
ACEG94050	50	79	HLL36150
ACEG94060	60	94	JLL36200
ACEG94075	75	116	JLL36225
ACEG94100	100	160	JLL36250
ACEG94120	125	179	LIL36300
ACEG94150	150	215	LIL36300
ACEG94200	200	259	LIL36400
ACEG94250	250	314	LIL36400
ACEG94300	300	387	LIL36450
ACEG94350	350	434	LIL36500

ACE-tronics G9 ASD Optional Devices

The ASD may be equipped with several options which are used to expand the functionality. [Table 24](#) lists the available options and their functions.

Table 24. G9 ASD Optional Devices and Functions.

Part Identifier	Device Name	Device Function
ASD-CAB-USB	G9/G7 USB Communication Cable	Used to connect the ASD to a PC via the PC USB port.
ASD-EOI-HH-G9	Display Module Docking Station	Used to flash the 9-Series display module.
ASD-MTG-KIT9	9-Series EOI Remote Mounting Kit	Hardware used to mount 9-Series ASD EOI remotely.
ASD-TB1-SIM9	ASD Input/Output Signal Simulator	Used to simulate the ASD I/O monitor and control signals.
DEV002Z	DeviceNet Module	Allows the ASD to communicate via DeviceNet with other DeviceNet-supported equipment including a host computer.
ETB003Z	Expansion I/O Board 1	Expands the Input/Output functionality of the ASD.
ETB004Z	Expansion I/O Board 2	Expands the Input/Output functionality of the ASD.
PDP002Z	ProfiBus DP Module	Allows the ASD to communicate via ProfiBus with other ProfiBus-supported equipment including a host computer.
USB001Z	USB-to-Serial Converter	Allows for the USB port of a computer to be used as a communications port for monitoring and controlling the ASD.
VEC007Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a 5-Volt encoder).
VEC004Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a 12-Volt encoder).
VEC005Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a 15-Volt encoder).
VEC006Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a 24-Volt encoder).
Note: See the user manual of the applicable option for additional information on each item.		

Index

Numerics

0 Hz Command Output, 128
0 Hz Dead Band Signal, 127
16-Bit Binary/BCD Input, 91
24-Volt I/O Terminal Board, 23

A

Abnormal Speed Detection Time, 180
Abnormal Speed Settings, 65
Acc/Dec #1 – #4 Settings, 69
Acc/Dec Pattern 1, 170
Acc/Dec Pattern 1 – 4, 172
Acc/Dec Pattern 2, 171
Acc/Dec Special, 69
Accel/Decel #1 Settings, 59
Accel/Decel Operation After Torque Limit, 162
Accel/Decel Suspend, 147
Accel/Decel Switching Frequency 1, 172
Acceleration, 83
Acceleration Suspend Frequency, 147
Acceleration Suspend Time, 147
Acceleration Time 1, 83
Acceleration Time 2, 168
Acceleration Time 3, 173
Acceleration/Deceleration Switching Frequency 2, 174
Acceleration/Deceleration Switching Frequency 3, 175
Adding Input Selection, 186
Add-on Option 1 Error, 256
AI2, 91
AI2 (Option V/I) Input Bias, 166
Alarm Prohibition, 63
Alarms, 248, 249
Alternate I/O Terminal Board, 23
Always ON 1 Terminal 1, 92
AM, 25, 27
AM Bias Adjustment, 189
AM Output, 54
AM Output Gradient Characteristic, 189
AM Output Terminal Adjustment, 187
AM Output Terminal Function, 186
AM/FM Output, 29
Analog Filter, 66
Analog Function Assigned Object 11, 223
Analog Function Assigned Object 21, 223
Analog Input, 25
Analog Input Filter, 112
Analog Input Function Target 11, 222
Analog Input Function Target 21, 223

Analog Input Loss, 254
Analog Input Over-Voltage, 254
Analog Output, 25
Analog Output Terminals, 60
Annual Average Ambient Temperature, 183
ASD Capacity, 13
ASD Characteristics, 13
ASD Disposition at ST Deactivation, 193
ASD Input Phase Failure Detection, 177
ASD Load, 54
ASD Number, 197
ASD OL (Overload) Trip, 54
ASD Operation at Disconnect, 205
ASD Output Phase Failure Detection, 177
ASD Overload, 54, 182, 254
ASD/Motor connection diagram, 17
ASD-side Switching Wait Time, 150
At-trip Recorded Parameters, 260
Auto Restart, 138
Automatic Acceleration/Deceleration, 79
Automatic Express-Speed Operation Frequency, 145
Automatic Function Selection, 89
Automatic Torque Boost, 79
Autotune Error, 254
Autotuning, 10
Autotuning 1, 154
Autotuning 2, 155

B

Base Frequency 1, 84
Base Frequency 2, 101
Base Frequency 3, 102
Base Frequency 4, 103
Base Frequency Voltage, 65
Base Frequency Voltage 1, 155
Base Frequency Voltage 2, 101
Base Frequency Voltage 3, 102
Base Frequency Voltage 4, 103
Bearing Greaser, 58
Bearing Greaser (Alarm) Time, 180
Bearing Greaser Speed Multiplier, 167
Bezel Mounting Hardware, 37
BIN Input Point 1 Frequency, 124
BIN Input Point 1 Setting, 123
BIN Input Point 2 Frequency, 124
BIN Input Point 2 Setting, 124
Block Read Data 1, 209
Block Read Data 2, 209
Block Read Data 3, 209

- Block Read Data 4, 210
- Block Read Data 5, 210
- Block Write Data 1, 208
- Block Write Data 2, 208
- BRAKE A, B, and C switching relationship, 28
- Brake Answer Wait Time, 182
- BRAKE Output, 29
- Brake Release Mechanical (Delay) Time, 232
- Brake Sequence Response Error, 254
- Brake-Release Torque (Proving) Time, 232
- Brake-Release Torque Reference, 232
- Brake-Release Torque Stable Time, 232
- Brake-Seized Pulse Check Time, 233
- Brake-Set Mechanical (Delay) Time, 232
- Braking Resistance Overload Time (10x rated torque), 184

C

- Cable/Terminal Specifications, 272
- Carrier Frequency, 69
- Carrier Frequency Control Mode, 142
- CC, 25
- Change Password, 78
- Change Step Selection 1, 192
- Change Step Selection 2, 192
- Changed From Default, 40, 64
- Changed From Default screen, 41
- Charge LED, 9, 16
- Circuit breaker configuration, 15
- Circuit Breaker Part Number, 276
- Clearing a Trip, 260
- Clock Setup, 63
- Closed Loop Hoist Control, 58
- CM1, 249
- CM2, 250
- Command Control Selections, 50
- Command Mode, 80
- Command Mode and Frequency Mode Control, 47
- Commercial Power Switching Freq. Hold Time, 150
- Commercial Power Switching Wait Time, 150
- Commercial Power/ASD Output Switching, 149
- Commercial Power/ASD Switching Frequency, 150
- Communication Adjustments, 76
- Communication Error, 254
- Communication Settings, 76
- Communications, 76
- Communications Option (DeviceNet/Profibus) Setting 1, 202
- Communications Option (DeviceNet/Profibus) Setting 2, 203
- Communications Option (DeviceNet/Profibus) Setting 8, 204
- Communications Option Speed Switch Monitor DeviceNet/CC-Link, 206
- Communications Option Station Address Monitor, 205
- Communications setting changes, 41
- Compensation Frequency, 54
- Conduit Plate Information, 261
- Connecting the ASD, 16
- Connection Diagram, 30
- Continuous Dynamic Braking Capacity, 141
- Continuous Monitoring Brake-Fail Pulse-Count, 233
- Contrast, 64
- Control Power Under-Voltage, 255
- Cooling Fan Control, 180
- CPU Fault, 255
- CRANE / HOIST, 57
- Crane/Hoist Settings, 69
- Creep Control, 57
- Creep Multiplier 1, 167
- Creep Multiplier 2, 167
- Creep Speed Lower Limit, 167
- Current Control Proportional Gain, 163
- Current/Voltage Specifications, 270
- Current/Voltage Units Setup, 191

D

- DBR Load, 55
- DBR OL (Overload) Trip, 55
- DBR over-current, 275
- DBR Overload, 54
- DC (Injection) Braking Current, 127
- DC (Injection) Braking Start Frequency, 127
- DC (Injection) Braking Time, 128
- DC Bus Voltage, 54
- DC Injection Braking, 65
- DC Output, 25
- Deceleration Suspend Frequency, 148
- Deceleration Suspend Time, 148
- Deceleration Time 1, 83
- Deceleration Time 2, 169
- Default Setting Changes, 40
- Direct Access, 62
- Disconnection Detection Extended Time, 205
- Discrete Input, 25, 29
- Discrete Input Terminal Assignment, 236
- Discrete Input Terminals, 56
- Discrete Output, 25
- Display Bias, 192
- Display Parameters, 62
- Disposal, 3
- Drooping, 143
- Drooping Control, 73
- Drooping Gain, 143

- Drooping Insensitive Torque, 144
- Drooping Output Filter, 144
- Drooping Pulses Allowed, 234
- Dynamic, 161
- Dynamic Braking, 65, 140, 161
- Dynamic Braking Resistance, 141
- Dynamic Braking Resistor Over-Current, 255
- Dynamic Braking Resistor Overload, 255
- Dynamic Braking Stall Prevention Mode, 163
- Dynamic Braking Torque Limit 1, 161
- Dynamic Braking Torque Limit 1 Level, 161
- Dynamic Braking Torque Limit 2 Level, 161
- Dynamic Braking Torque Limit 3 Level, 162
- Dynamic Braking Torque Limit 4 Level, 162

E

- E, 255
- E-11, 254
- E-12, 255
- E-13, 258
- E-17, 256
- E-18, 254
- E-19, 255
- E-20, 259
- E-21, 255
- E-22, 256
- E-23, 256
- E-24, 256
- E-25, 259
- E-26, 255
- EEP1, 255
- EEP2, 255
- EEP3, 255
- EEPROM Data Fault, 255
- EEPROM Fault, 255
- EF1, 256
- EF2, 256
- Electronic Operator Interface, 32
- Electronic Operator Interface features, 33
- Emergency Lift, 59, 185
- Emergency Off, 34
- Emergency Off DC Injection Application Time, 176
- Emergency Off Mode Settings, 176
- Emergency Off Settings, 65
- Emergency-Lift Lower Speed Limit, 185
- Emergency-Lift Maximum Speed, 185
- Emergency-Lift Torque Compare Time, 185
- Enclosure Dimensions, 261
- Encoder Error Detection Time, 234
- End Frequency, 127
- EOI Command Mode, 53
- EOI Installation Precautions, 37
- EOI Operation, 32
- EOI Remote Mounting, 32, 37
- EOI Remote Mounting using the ASD-MTG-KIT, 39
- EOI Remote Mounting w/o the ASD-MTG-KIT, 38
- EPHI, 256
- EPHO, 256
- Equipment Inspection, 3
- ERR2, 258
- ERR3, 258
- ERR4, 255
- ERR5, 254
- ERR6, 256
- ERR7, 256
- ERR8, 256
- ERR9, 256
- ESC Key, 33
- Ethernet, 78
- ETN, 254
- ETN1, 254
- ETN2, 254
- ETN3, 254
- ETYP, 259
- Excitation Current, 55
- Exciting Strengthening Coefficient, 156
- Express Speed, 58
- Express Stop, 57, 167
- Express Stop Acceleration/Deceleration Pattern, 174
- Express Stop Decel Time, 174
- Express-Speed Learning Function, 145
- Express-Speed Operation Detection Time, 146
- Express-Speed Operation Heavy-Load Detection Time, 146
- Express-Speed Operation Load Wait Time, 145
- Express-Speed Operation Switching Lower-Limit Frequency, 145
- Express-Speed Selection, 144
- Extender Cables, 37
- External Fault, 59
- External Fault Stopping Method, 135
- External Over-Heat, 256

F

- F, 26
- Fan Control, 180
- Fault, 248
- Faults, 248

- Feedback, 73
- Feedback (1 second), 55
- Feedback (inst), 55
- Feedback Settings, 73
- FLA, 27
- Flash Memory Fault, 256
- FM, 25, 27
- FM Bias Adjustment, 189
- FM Output, 54
- FM Output Gradient Characteristic, 189
- FM Output Terminal Adjustment, 81
- FM Output Terminal Function, 81
- FM Voltage/Current Output Switching, 189
- FMOD, 107
- Forward Run/Reverse Run Disable, 142
- Forward Speed Limit Input, 158
- Forward Speed Limit Level, 158
- Forward/Reverse DC Injection Braking Priority, 128
- Forward/Reverse Disable, 67
- Forward/Reverse Run Selection, 82
- FP, 25, 27
- FP Output, 29
- FP Terminal Pulse Output Function, 188
- Free Notes, 210
- Free Unit, 191
- Free Unit Display Gradient Characteristic, 192
- Free Unit Multiplication Factor, 191
- Frequency, 66
- Frequency at Trip, 54
- Frequency Command Mode, 52
- Frequency Command Screen, 35, 40
- Frequency Control, 70
- Frequency Control Selections, 50
- Frequency Mode 1, 80
- Frequency Mode 2, 111
- Frequency Mode Control, 47
- Frequency Mode Priority Switching Frequency, 111
- Frequency Point Selection, 199
- Frequency Priority Selection, 107
- Frequency Reference, 54
- Frequency Setting, 52
- Frequency Settings, 59
- Fundamental, 59

G

- G9 Optional Devices, 277
- G9 Part Numbering Convention, 261
- Gate Array Fault, 256
- General Safety Information, 1
- Grounding Capacitor Switch, 5

H

- Handling and Storage, 3
- Heavy-Load Torque During Fixed-Speed Power Running, 146
- Heavy-Load Torque During Power Running, 146

I

- I/O Circuit Configurations, 29
- I1, 26
- I2, 26
- I3, 26
- I4, 26
- I5, 26
- I6, 26
- I1 function, 110
- IICC, 25, 30, 108, 110
- Initial UP/DOWN Frequency, 132
- Initial UP/DOWN Frequency Rewriting, 132
- Input Function Command 1, 210, 212, 213, 217, 219, 220, 221
- Input Function Command 2, 211, 212, 213, 218, 219, 220, 221
- Input Function Target 1, 210, 212, 213, 217, 218, 220, 221
- Input Function Target 2, 211, 212, 213, 218, 219, 220, 221
- Input Function Target 3, 211, 212, 214, 218, 219, 220, 222
- Input Phase Failure, 256
- Input Phase Failure Detection, 177
- Input Power, 55
- Input Special Functions, 60
- Input Terminal 1 (F) Function, 92
- Input Terminal 1 (F) Response Time, 99
- Input Terminal 10 (LI2) Function, 94
- Input Terminal 11 (LI3) Function, 94
- Input Terminal 12 (LI4) Function, 94
- Input Terminal 13 – 20 Response Time, 100
- Input Terminal 13 (LI5) Function, 95
- Input Terminal 14 (LI6) Function, 95
- Input Terminal 15 (LI7) Function, 95
- Input Terminal 16 (LI8) Function, 96
- Input Terminal 17 (B12) Function, 100
- Input Terminal 18 (B13) Function, 100
- Input Terminal 19 (B14) Function, 100
- Input Terminal 2 (R) Function, 92
- Input Terminal 2 (R) Response Time, 99
- Input Terminal 20 (B15) Function, 100
- Input Terminal 3 (I1) Function, 92
- Input Terminal 3 (ST) Response Time, 99
- Input Terminal 4 (I2) Function, 92

Input Terminal 4 (RES) Response Time, 99
Input Terminal 5 – 12 Response Time, 99
Input Terminal 5 (I3) Function, 93
Input Terminal 6 (I4) Function, 93
Input Terminal 7 (I5) Function, 93
Input Terminal 8 (I6) Function, 93
Input Terminal 9 (LI1) Function, 93
Input Terminal Delays, 60
Input Terminal Priority, 90
Input Terminals, 61
Installation and Connections, 14
Installation Notes, 14
Installation Precautions, 4
isolated V/I input, 108

J

Jog Run Frequency, 129
Jog Settings, 67
Jog Stop Pattern, 130
Jump Frequencies, 70
Jump Frequency 1, 133
Jump Frequency 1 Bandwidth, 134
Jump Frequency 2, 134
Jump Frequency 2 Bandwidth, 134
Jump Frequency 3, 134
Jump Frequency 3 Bandwidth, 134, 231, 233

K

Key Failure, 256
Keypad ASD-MTG-KIT Dimensions (mounting), 39

L

L1, 17
L2, 17
L3, 17
LCD Character Information, 34
LCD Display, 33
LCD Screen, 34, 35
LCD Screen Installation Note, 36
Lead Length Specifications, 20
LED Character/Font Information, 34
LED Display, 33
LED Screen, 34
LED/LCD Screen Information, 34
LED/LCD Screen Installation Note, 36
Light Load Conditions, 11

Limit-Switch Control, 57
Limit-Switch Stopping Method, 135
Line Power Switching, 61
Linear acceleration, 170
Load Hover Time, 233
Load Moment of Inertia 1, 163
Load Moment of Inertia 2, 164
Load Sharing Gain Input, 158
Load-produced Negative Torque, 12
Local mode, 33
Local/Remote Key, 33
Lockouts, 78
Low Current, 256
Low Current Settings, 65
Low-Current Detection Current Hysteresis Width, 178
Low-Current Detection Threshold, 178
Low-Current Trip, 178
Low-Current Trip Threshold Time, 178
Lower-Limit Frequency, 84
Lower-Limit Slow Speed, 137
Low-Speed Operation, 10
Low-Speed Signal Output Frequency, 90
Lug Size, 272

M

Main Monitor Selections, 56, 65
Main Power Under-Voltage, 256
Manual Torque Boost 1, 85
Manual Torque Boost 2, 101
Manual Torque Boost 3, 102
Manual Torque Boost 4, 103
Manual Torque Limit Settings, 72
Maximum Frequency, 84
Maximum Up Speed At Brake Fail, 233
MCP Rating, 272
Mode Key, 33
MOFF, 250
MON 1 Bias Adjustment, 190
MON 1 Output Gradient Characteristic, 190
MON 1 Voltage/Current Output Switching, 190
MON 2 Bias Adjustment, 191
MON 2 Output Gradient Characteristic, 190
MON 2 Voltage/Current Output Switching, 190
MON1 Terminal Adjustment, 187
MON1 Terminal Meter Selection, 187
MON2 Terminal Adjustment, 188
MON2 Terminal Meter Selection, 188
Monitor Mode, 54
Monitor Output Function 11, 224

- Monitor Output Function 21, 224
- Monitor Output Function 31, 225
- Monitor Output Function 41, 225
- Monitor Output Function Command 11, 224
- Monitor Output Function Command 21, 224
- Monitor Output Function Command 31, 225
- Monitor Output Function Command 41, 225
- Monitor Screen, 35
- Motion Control, 57, 230
- Motor, 71
- Motor 150% Overload Time Limit, 177
- Motor Braking, 12
- Motor Capacity, 44
- Motor Characteristics, 10
- Motor connection diagram, 17
- Motor Constant 1, 156
- Motor Constant 2, 156
- Motor Constant 3, 156
- Motor Constant 4, 156
- Motor Load, 54
- Motor OL (Overload) Trip, 54
- Motor Overload, 256
- Motor Overload Protection Configuration, 86
- Motor Overload Protection Level 1, 175
- Motor Overload Protection Level 2, 102
- Motor Overload Protection Level 3, 103
- Motor Overload Protection Level 4, 104
- Motor Overload Real, 54
- Motor Rated Capacity, 155
- Motor Rated Current, 155
- Motor Rated RPM, 155
- Motor Set #1, 59
- Motor Set #2, 71
- Motor Set #3, 71
- Motor Set #4, 71
- Motor Shaft Fixing Control, 128
- Motor/Load Combinations, 11
- Mounting the ASD, 15
- Multiplying Input Selection, 186
- My Function, 74
- My Function Analog, 76
- My Function Count Data 1, 217
- My Function Count Data 2, 217
- My Function Data, 75
- My Function Frequency Data 1, 215
- My Function Frequency Data 2, 215
- My Function Frequency Data 3, 215
- My Function Frequency Data 4, 215
- My Function Frequency Data 5, 216
- My Function Monitor, 76
- My Function Percent Data 1, 214
- My Function Percent Data 3, 214
- My Function Percent Data 4, 215
- My Function Percent Data 5, 215

- My Function Selection, 74, 227
- My Function Time Data 1, 216
- My Function Time Data 2, 216
- My Function Time Data 3, 216
- My Function Time Data 4, 216
- My Function Time Data 5, 217
- My Function Unit 1, 74

N

- Network Option Reset Settings, 210
- No-Load (Torque) Detection Time, 207
- No-Load Torque, 207
- NONE, 256
- Number of PG Input Phases, 153
- Number of PG Input Pulses, 153
- Number of Times to Retry, 139

O

- OC, 251
- OC1, 257
- OC1P, 257
- OC2, 257
- OC2P, 258
- OC3, 257
- OC3P, 258
- OCA1, 259
- OCA2, 259
- OCA3, 259
- OCR, 255
- OH, 251, 257
- OH2, 256
- OJ, 252
- OL1, 254
- OL2, 256
- OLI, 249
- OLM, 250
- OLR, 249, 255
- OP, 252
- OP1, 258
- OP2, 258
- OP3, 258
- Operation (Local), 40
- Operation Above 60 Hz, 10
- Operation Panel Parameters, 70
- Operational and Maintenance Precautions, 9
- Option V/I Terminal Voltage/Current Selection, 91
- Options, 277
- OT, 251, 258
- OUT1, 27
- Out1 Out2 BRAKE, 56

- OUT1/OUT2 Output, 29
- OUT2, 27
- Output Current, 54
- output disconnect, 8
- Output Function Assigned, 211, 213, 214, 218, 219, 221, 222
- Output Phase Failure, 256
- Output Phase Failure Detection, 177
- Output Power, 55
- Output Terminal 1 (OUT1) Function, 96
- Output Terminal 10 (R3) Function, 101
- Output Terminal 11 (R4) Function, 101
- Output Terminal 2 (OUT2) Function, 96
- Output Terminal 3 (BRAKE) Function, 96
- Output Terminal 4 (OUT3) Function, 97
- Output Terminal 5 (OUT4) Function, 97
- Output Terminal 6 (R1) Function, 97
- Output Terminal 7 (OUT5) Function, 98
- Output Terminal 8 (OUT6) Function, 98
- Output Terminal 9 (R2) Function, 98
- Output Terminals, 62
- Output Voltage, 54
- Over-Current, 251
- Over-Current During Acceleration, 257
- Over-Current During Deceleration, 257
- Over-Current During Run, 257
- Over-Current Protection, 13
- Over-Heat, 251, 257
- Over-Heat During Acceleration, 257
- Over-Heat During Deceleration, 258
- Over-Heat During Run, 258
- Overload, 65
- Overload Protection, 10
- Overload Reduction Starting Frequency, 177
- Override Control, 73
- Override mode, 49
- Override Operation, 49
- Over-Speed Detection Frequency Lower Band, 180
- Over-Speed Detection Frequency Upper Band, 180
- Over-Torque, 251, 258
- Over-Torque Detection Hysteresis, 179
- Over-Torque Detection Level (Negative Torque), 179
- Over-Torque Detection Level (Positive Torque), 179
- Over-Torque Detection Time, 179
- Over-Torque Parameters, 66
- Over-Torque Trip, 179
- Over-Voltage, 252
- Over-Voltage During Acceleration, 258
- Over-Voltage During Deceleration, 258
- Over-Voltage During Run, 258
- Over-Voltage Limit Operation, 140

- Over-Voltage Limit Operation Level, 181

P

- P24, 27
- P24 Output, 29
- PA/+, 16
- Panel Load Sharing Gain, 194
- Panel Operation Jog Mode, 130
- Panel Override Multiplication Gain, 194
- Panel Stop Pattern, 193
- Panel Tension Torque Bias, 194
- Panel Torque Command, 193
- Parameter Write Lockout, 191
- Password, 78
- Password and Lockout, 78
- Past Trip #1, 56
- Past Trip #2, 56
- Past Trip #3, 56
- Past Trip #4, 56
- Pattern Cycle Number, 55
- Pattern Group Number, 55
- Pattern Preset, 55
- Pattern Time, 55
- PC/-, 16
- Permanent Magnet (PM) Motor Constant 2, 168
- PG Disconnection Detection, 154
- PG Input Point 1 Frequency, 125
- PG Input Point 1 Setting, 125
- PG Input Point 2 Frequency, 126
- PG Input Point 2 Setting, 126
- PG Settings, 73
- Phase Loss, 66
- PID Control Switching, 150
- PID Control Wait Time, 152
- PID Deviation Lower Limit, 152
- PID Deviation Upper Limit, 151
- PID Feedback, 55
- PID Feedback Delay Filter, 151
- PID Feedback Differential (D) Gain, 152
- PID Feedback Integral (I) Gain, 151
- PID Feedback Proportional (P) Gain, 151
- PID Feedback Signal, 151
- PID Output Lower Limit, 153
- PID Output Upper Limit, 152
- Plugging, 57, 168
- Plugging Acceleration Time, 174
- Plugging Acceleration/Deceleration Pattern, 175
- Plugging Deceleration Time, 175
- PM Motor, 71, 168

- PM Motor Constant 1, 168
- PO, 16
- POFF, 250
- Point 1 Frequency, 200
- Point 1 Setting, 200
- Point 2 Frequency, 201
- Point 2 Setting, 200
- Power Connections, 16
- Power Factor Correction, 11
- Power running, 146
- Power Running Stall Continuous Trip Detection Time, 162
- Power Running Torque Limit 1, 160
- Power Running Torque Limit 1 Level, 160
- Power Running Torque Limit 2 Level, 161
- Power Running Torque Limit 3 Level, 161
- Power Running Torque Limit 4 Level, 162
- PP, 25, 27
- PP Output, 29
- Preset Speed 1, 87
- Preset Speed 10, 136
- Preset Speed 11, 136
- Preset Speed 12, 136
- Preset Speed 13, 137
- Preset Speed 14, 137
- Preset Speed 15, 137
- Preset Speed 2, 87
- Preset Speed 3, 88
- Preset Speed 4, 88
- Preset Speed 5, 88
- Preset Speed 6, 88
- Preset Speed 7, 88
- Preset Speed 8, 136
- Preset Speed 9, 136
- Preset Speed Operation Selection, 205
- Preset Speeds, 67
- Primary Menus, 35
- Process Decreasing Rate, 153
- Process Increasing Rate, 153
- Process Lower Limit, 152
- Process Upper Limit, 152
- Program Menu, 35
- Program Mode Menu Navigation, 57
- Prohibition, 62
- Protection, 65
- PTC1 Thermal Selection, 183
- PTC2 Thermal Selection, 184
- Pulse Output Frequency (FP), 188
- Pulse Width Modulation, 10
- Pulsed Output, 25
- PWM Carrier Frequency, 137

Q

- Qualified Personnel, 2

R

- R, 26
- R/L1, 16, 17
- RAM Fault, 258
- Random Mode, 142
- Reach Settings, 62
- Read Error, 255
- Real-time Clock Setup, 63
- Regenerative Power Ridethrough Control Level, 181
- Regenerative Power Ridethrough Mode, 138
- Remote EOI Required Hardware, 37
- Remote mode, 33
- Reset, 63, 82
- Restore User Settings, 41
- Retain Trip Record at Power Down, 176
- Retry, 139
- Retry/Restart, 66
- Reverse Speed Limit Input, 159
- Reverse Speed Limit Input Level, 159
- Ridethrough Time, 141
- ROM Fault, 258
- Root menu mapping, 52
- Root Menus, 52
- Rotary Encoder, 33
- Rotation in Specified Direction ONLY, 160
- RR, 25, 26, 55
- RR Input, 29
- RR Input Bias, 165
- RR Input Gain, 165
- RR Input Point 1 Frequency, 113
- RR Input Point 1 Rate, 115
- RR Input Point 1 Setting, 113
- RR Input Point 2 Frequency, 114
- RR Input Point 2 Rate, 115
- RR Input Point 2 Setting, 114
- RS485 2- and 4-wire Communications Time-Out Action, 198
- RS485 2- and 4-wire Parity, 197
- RS485 2-Wire and 4-Wire Communications Time Out, 197
- RS485 2-wire ASD-to-ASD Communications, 199
- RS485 2-Wire Baud Rate, 197
- RS485 2-wire Send Wait Time, 198
- RS485 4-Wire Baud Rate, 201
- RS485 ASD-to-ASD Communications, 202
- RS485 Protocol Selection (TSB/ModBus), 202
- RS485 Send Wait Time, 201
- Run Frequency, 126

- Run Frequency Hysteresis, 127
- Run Key, 33
- Run Time, 54
- Rush Relay Current Activation Time, 183
- RX, 25, 26, 55
- RX Input, 29
- RX Input Bias, 165
- RX Input Gain, 165
- RX Input Point 1 Frequency, 116
- RX Input Point 1 Rate, 118
- RX Input Point 1 Setting, 116
- RX Input Point 2 Frequency, 117
- RX Input Point 2 Rate, 118
- RX Input Point 2 Setting, 117
- RX2, 55
- RX2 (AI1) Input Bias, 166
- RX2 (AI1) Input Gain, 166
- RX2 (AI1) Input Point 1 Frequency, 120
- RX2 (AI1) Input Point 1 Rate, 121
- RX2 (AI1) Input Point 1 Setting, 119
- RX2 (AI1) Input Point 2 Frequency, 120
- RX2 (AI1) Input Point 2 Rate, 122
- RX2 (AI1) Input Point 2 Setting, 120

S

- S/L2, 16, 17
- Save User Settings, 41
- Second Speed Loop Proportional Gain, 163
- Second Speed Loop Stabilization Coefficient, 164
- Setpoints, 72
- Short Circuit Detection At Start, 178
- Short Circuit Protection, 276
- Simple Positioning Completion Range, 154
- Slack Rope, 58
- Slack Rope Detection, 207
- Slip Frequency Gain, 154
- SOUT, 258
- S-Pattern 1, 170
- S-Pattern 2, 170
- S-Pattern Acceleration Lower Limit Adjustment, 173
- S-Pattern Acceleration Upper Limit Adjustment, 173
- S-Pattern Deceleration Lower Limit Adjustment, 173
- S-Pattern Deceleration Upper Limit Adjustment, 173
- Special, 69
- Special Functions, 46
- Special Parameters, 70
- Special Protection Parameters, 66
- Speed at 0% Drooping Gain, 143
- Speed at F320 Drooping Gain, 143

- Speed Control, 57
- Speed Error, 258
- Speed Limit (torque=0) Band, 160
- Speed Limit (torque=0) Center Value, 159
- Speed Limit (torque=0) Center Value Reference, 159
- Speed Loop Proportional Gain, 163
- Speed Loop Stabilization Coefficient, 163
- Speed PID Switching Frequency, 164
- Speed Reach Detection Band, 90
- Speed Reach Frequency, 90
- Speed Reference Setpoints, 67
- ST (Standby), 92
- Stall, 66
- Stall Prevention Factor 1, 157
- Stall Prevention Level, 176
- Standard Mode Selection, 59
- Start Frequency, 126
- Startup Wizard Requirements, 42
- Step Out, 258
- Stepout Current Detection Level, 184
- Stepout Current Detection Time, 184
- Stopping Time at Stop Limit Switch UP, 135
- Stop-Reset Key, 34
- Super Creep Control, 57
- Supply Voltage Correction, 141
- SW2, 27
- Switching Load Torque During Dynamic Braking, 147
- Switching Load Torque During Power Running, 146
- Synchronized Acceleration Time, 143
- Synchronized Deceleration Time, 142
- System Configuration and Menu Options, 52
- System Grounding, 18
- System Integration Precautions, 7
- System Operation, 40

T

- T/L3, 16, 17
- T1, 17
- T2, 17
- T3, 17
- Tension Torque Bias Input, 157
- Terminal, 60
- Terminal Descriptions, 26
- Time Limit For Lower-Limit Frequency Operation, 128
- Timed-Run, 58
- Torque, 55, 72
- Torque Command Selection, 157
- Torque Control, 72
- Torque Current, 55

- Torque Limit Settings, 72
- Torque Reference, 55
- Torque Speed Limiting, 72, 73
- Trace, 63
- Trace Cycle, 196
- Trace Data 1, 196
- Trace Data 2, 196
- Trace Data 3, 196
- Trace Data 4, 196
- Trace Selection, 195
- Traverse Acceleration Time, 229
- Traverse Deceleration Time, 229
- Traverse Jump Step, 230
- Traverse Selection, 229
- Traverse Step, 229
- Trip Code, 55
- Trip History, 260
- Trip History (read-only), 63
- Trip Record at Monitor Screen, 260
- Trip Settings, 66
- Trouble Shooting, 248
- Type Error, 259
- Type Reset, 63

U

- U/T1, 16, 17
- UC, 253
- UL 1995, 261
- Under-Voltage Trip, 181
- Under-Voltage Trip Detection Time, 181
- Under-Voltage/Ridethrough, 66
- Unused discrete terminals, 22
- UP/DOWN Frequency (down) Frequency Step, 132
- UP/DOWN Frequency (down) Response Time, 132
- UP/DOWN Frequency (up) Frequency Step, 132
- UP/DOWN Frequency (up) Response Time, 131
- UP/DOWN Frequency Accel Time, 83
- UP/DOWN Frequency Decel Time, 83
- UP/DOWN Frequency Functions, 67
- Up/Down Frequency Operation, 133
- UP1, 256
- UP2, 255
- U-Phase Over-Current, 259
- Upper Limit Frequency, 84
- Upper-Limit Slow Speed, 137

- Utilities, 62

V

- V/f 5-Point Setting, 70
- V/f 5-Point Setting Frequency 1, 104
- V/f 5-Point Setting Frequency 2, 105
- V/f 5-Point Setting Frequency 3, 106
- V/f 5-Point Setting Frequency 4, 106
- V/f 5-Point Setting Frequency 5, 107
- V/f 5-Point Setting Voltage 1, 105
- V/f 5-Point Setting Voltage 2, 106
- V/f 5-Point Setting Voltage 3, 106
- V/f 5-Point Setting Voltage 4, 106
- V/f 5-Point Setting Voltage 5, 107
- V/f Control Error, 259
- V/f Pattern, 85
- V/I, 25, 55, 67
- V/I Analog Input Broken Wire Detection Level, 182
- V/I Input, 29
- V/I Input Bias, 164
- V/I Input Gain, 164
- V/I Input Gain (AI2 Option Board Input), 166
- V/I Input Point 1 Frequency, 109
- V/I Input Point 1 Rate, 110
- V/I Input Point 1 Setting, 108
- V/I Input Point 2 Frequency, 109
- V/I Input Point 2 Rate, 111
- V/I Input Point 2 Setting, 109
- V/T2, 16, 17
- Vector Control, 13
- Vector Motor Model, 71
- Version (read-only), 64
- Viewing Trip Information, 260
- Virtual Input Terminal 1 Selection, 226
- Virtual Input Terminal 2 Selection, 226
- Virtual Input Terminal 3 Selection, 226
- Virtual Input Terminal 4 Selection, 226
- V-Phase Over-Current, 259

W

- W/T3, 16, 17
- Warranty Card, 2
- W-Phase Over-Current, 259