



Owner's Manual

Premium AVX
Basic AVX

PC601-00026

Thank you for your purchase of the TOYOTA Genuine Car Multimedia System.
Please note that this manual explains all functions and equipment, including options.
Therefore, you may find some explanations on features or equipment not included in your Car Multimedia System.

TOYOTA DAIHATSU ENGINEERING & MANUFACTURING CO., LTD.

Contents

Important Safety Information 4

Precautions 4

Before Use 5

How to read this manual 5

Basic Operations 6

Front Panel Button Functions 6

Turning on the Unit 7

Regional Setup 7

Adjusting the volume 8

Touch screen operations 9

Pop-up menu 9

Simple Display Mode 9

HOME screen descriptions 10

Source selection screen description 11

Source control screen descriptions 13

List screen 13

Connection 14

Wired Connection 14

Bluetooth Control 15

Information for using Bluetooth® devices 15

Register the Bluetooth device 16

Bluetooth Setup 17

Playing the Bluetooth Audio Device 19

Using the Hands-Free Unit 21

Phone Setup 25

T-Link 26

Preparation 26

Connecting a smartphone 26

Mirroring Operation 26

Disc 28

Playing a disc 28

DVD/ Video-CD Basic Operation 28

Music CD/ Disc media Basic Operation 30

Search Operation 31

DVD Disc Menu Operation 31

DVD Setup 32

USB 34

Connecting a USB device 34

USB Basic Operation 34

Search Operation 35

iPod/iPhone 37

Preparation 37

iPod/iPhone Basic Operation 38

Search Operation 38

Radio 39

Radio Basic Operation 39

Memory Operation 39

Selecting Operation 40

Other External Components 41

Using the back camera 41

External audio players (AUX) 42

M-Toyota 43

Emergency Calling 43

Toyota Dealer Search 43

Setup	44
Display Adjust.....	44
Picture Adjust.....	44
System Setup.....	45
General Systems.....	45
User Interface Systems.....	46
Dual Zone Systems.....	48
Advanced Features.....	49
Controlling Audio	50
Controlling General Audio.....	50
Equalizer Control.....	51
Volume Offset.....	52
Sound Effect.....	52
Listening Position/ DTA.....	53
Steering Wheel Control	55
Operations using the steering switch.....	55
Remote control	56
Using the Remote control.....	56
Functions of the Remote control Buttons.....	57
Troubleshooting	59
Problems and Solutions.....	59
Error Messages.....	59
Appendix	61
Playable Media and Files.....	61
Region Codes in the World.....	63
DVD Language Codes.....	64
Specifications.....	65
About this Unit.....	67
For further information.....	70

For safety reasons, this owner's manual indicates items requiring particular attention with the following marks.

▲ WARNING

- This is a warning against anything which may cause death or serious injury to people if the warning is ignored. You are informed about what you must or must not do in order to reduce the risk of death or serious injury to yourself and others.

▲ CAUTION

- This is a warning against anything which may cause injury to people if the warning is ignored. You are informed about what you must or must not do in order to reduce the risk of injury to yourself and others.

NOTE

- This is a warning against anything which may cause damage to the vehicle or its equipment if the warning is ignored. You are informed about what you must or must not do in order to avoid or reduce the risk of damage to your vehicle and its equipment.
- Please read all materials, TOYOTA will not be responsible for unsatisfactory product performance due to failure to follow these instructions. Changes to product may result in differences between content of this manual and actual features of the product.

Important Safety Information

Precautions

IMPORTANT

Please read this manual carefully to ensure proper use before using this product. It is especially important that you read and observe WARNINGS and CAUTIONS in this manual. Please keep the manual in a safe and accessible place for future reference.

▲ WARNINGS

- Do not watch or fix your eyes on the unit's display for any extended period whenever you are driving.
- Do not operate the unit while driving. Keep focus on the road.
- Do not pair Bluetooth devices while driving, stop on a safe road side before attempting to pair any device.
- Do not attempt to install or service this product by yourself. Installation or servicing of this product by persons without proper training and experience in electronic equipment and automotive accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards.
- If liquid or foreign matter should get inside this product, stop your vehicle in a safe place, turn the ignition switch OFF (ACC OFF) immediately and consult your dealer or the nearest authorized Toyota Service Station. Do not use this product in this condition because doing so may result to fire, electric shock, or other failure.

📺 To ensure safe driving

Any video won't be played while driving to prevent driver's eyes from fixing on the unit's display. Stop the vehicle in a safe place and apply the parking brake before performing such function.

There are some functions you cannot perform while driving because of the same reason.

▲ CAUTIONS

- To prevent short circuit, never put or leave any metallic objects (such as coins or metallic tools) inside the unit.
- Do not allow this product to come into contact with liquids. Electric shocks as well as damage to the product, smoke, and overheating could result from contact with liquids.
- If you notice any abnormalities such as smoke, strange noise or odor from using this product, or any other abnormal signs on the LCD screen, turn off the power immediately and consult your dealer or the nearest Toyota Service Station. Using this product in this condition may result in permanent damage to the system.
- Do not disassemble or modify this product, as there are high-voltage components inside which may cause an electric shock. Be sure to consult your dealer or the nearest authorized Toyota Service Station for internal inspection, adjustments or repairs.

Before Use

■ Precautions on using this unit

- You can select a language to display menus, audio file tags, etc. See **Regional Setup (P.7)**.

■ Protecting the monitor

- To protect the monitor from damage, do not operate the monitor using a ball point pen or similar tool with a sharp tip.
- If you stick a film screen protector on the screen, it may interfere with touch panel operation.

■ Cleaning the unit

- If the faceplate of this unit is stained, wipe it with a dry soft cloth such as a silicon cloth. If the faceplate is stained badly, wipe it with a cloth moistened with neutral cleaner, then wipe it again with a clean soft dry cloth.

NOTE

- Applying spray cleaner directly to the unit may damage its mechanical parts. Wiping the faceplate with a hard cloth or using a volatile liquid such as thinner or alcohol may scratch the surface or erase the screened print.


■ Lens fogging

When you turn on the car heater in cold weather, dew may form on the lens in the disc player of the unit due to condensation. This condensation on the lens (also called lens fogging) may not allow discs to play. In such a situation, remove the disc and wait for the dew to evaporate.

■ Precautions on handling discs

- Do not touch the recording surface of the disc.
- Do not stick tape etc. on the disc, or use a disc with tape stuck on it.
- Do not use disc type accessories.
- Clean the disc from the center toward the outside rim.
- When removing a disc from this unit, pull it out horizontally.

- If the disc center hole or outside rim has burrs, use the disc only after removing the burrs with a ballpoint pen etc.
- Discs that are not round cannot be used.



- 8-cm (3 inch) discs cannot be used.
- Discs with coloring on the recording surface or discs that are dirty cannot be used.
- This unit can only play the following types of CDs.



- This unit may not correctly play discs which do not have the mark.
- You cannot play a disc that has not been finalized. (For the finalization process, see your writing software and your recorder's instruction manual.)

■ Before removing the vehicle battery

It may be necessary to take note of the different settings as the information stored in the head unit is erased by disconnecting the power cable from the battery (or removing the battery itself), however, there are some settings that will not be reset.

■ In case of trouble


Should this product fail to operate properly, contact your dealer or nearest authorized Toyota Service Station.

How to read this manual

- The screens and panels shown in this manual are just examples used to provide clear explanations of the operations. For this reason, they may be different from actual screens and panels used, or some display patterns may be different.
- **Display Language:** English is used as the default language. You can select the display language by accessing the  button function. See **Regional Setup (P.7)**.

Basic Operations

Front Panel Button Functions



NOTE

• The panels shown in this guide are examples used to provide a clear explanation of operations. For this reason, they may be different from the actual panels.

Number	Name	Function
1	Disc-loading slot	• A slot to insert a disc media.
2	Disc eject	• Ejects the disc. • Press and hold to forcibly eject the disc.
3	Home	• Displays the HOME screen.
4	Setting	• Displays the popup menu.
5	Mute	• Mutes/restores the sound.
6	Remote Sensor	• Receives the remote control signal.
7	Power	• Press and Hold : Turns on/off the unit (P.7) . • Short Press : Turns on/off "simple display mode" (P.9) .
8	-, + (Volume)	• Adjusts the volume. The volume will go up to 15 when you keep pressing + .

Turning on the Unit

This unit is turned on when the ignition switch is set to ACC or ON position, and turned off when the ignition switch is set to OFF position.

1 Set the ignition switch to ACC or ON position.

- The unit is turned on.


2 Read the caution message and touch **Agree**.



- Touching **Language** changes the display language.

● To turn off/on the unit manually:


1 Press and hold button.



- The unit is turned off/on.

Regional Setup

1 Press button.




- Popup menu appears.

2 Touch .




- System screen appears.

3 Touch **Regional**.



- Regional screen appears.

4 Set each item as follows.



■ **Language**

Select the desired language.

■ **Time Zone**

Select the time zone.

Basic Operations

■ Time Format

Select the time display format.


12-Hour (Default)/ 24-Hour

■ Clock Adjust

Adjust the date and time manually. (P.8)

Adjusting date and time

- 1 Touch **Time Zone** on the Regional screen.
- 2 Select the time zone.
- 3 Touch **Clock Adjust** on the Regional screen.
- 4 Adjust the date, then adjust the time.



- 5 Touch **Set**.


Adjusting the volume

You can adjust the volume (0 to 40).

Press **+** to increase, and press **-** to decrease.

Holding **+** increases the volume continuously to level 15.

Volume level 16 to 40 can be adjusted one step each.




Touch screen operations

To perform operations on the screen, you need to touch, touch and hold, flick or swipe to select an item or change pages.


● Touch

Touch the screen gently to select an item on the screen.



● Touch and hold

Touch the screen and keep your finger in place until the display changes or a message is displayed.




● Flick

Slide your finger quickly to the left or right on the screen to change the page. You can scroll a list screen by flicking up/ down on the screen.



● Swipe

Slide your finger up or down on the screen to scroll the screen.




Popup menu

1 Press  button.

➤ Popup menu appears.

2 Touch to display the popup menu.



The contents of the menu are as follows.

	• Displays the display control screen. (P.44)
	• Displays the picture control screen. (P.44)
	• Displays the System screen. (P.45)
	• Displays the Audio screen. (P.50)
	• Displays the T-Link Setup screen.* ¹ (P.27)
	• Displays the T-Link screen.* ^{1,*2} (P.26)
	• Displays the Hands Free screen. (P.21)
	• Displays the control screen of the current source.* ³

*¹ Premium AVX only


*² This menu is not available when a T-Link source screen is displayed. If you select this menu while using iPod or Bluetooth Audio source, a message "T-Link can not be used while using iPod / Bluetooth Audio. Would you like to switch to T-Link?" will be displayed.

*³ For Premium AVX, this menu is available when a T-Link source screen is displayed.

Simple Display Mode

When Simple Display Mode is enabled, the screen will only display time, date and current playback source information.

1 Press  button.



● **To back to the original screen:**

1 Press  button.

➤ AVX displays the original screen.

HOME screen descriptions


Most functions can be performed from the HOME screen.



- | | |
|----------|---|
| 1 | • Displays the source selection screen. (P.11) |
| 2 | • Current source information.
• Touch to display the control screen of the current source. |
| 3 | • Short-cut playback source icons (P.12) |

Display the HOME screen


- 1** Press  button.



- HOME screen appears.

Source selection screen description

You can display icons of all playback sources and options on the source selection screen.



- 1** • Returns to the previous screen.
- 2** • Changes playback sources.
For playback sources, see **P.11**.


Select the playback source

- 1** Press  button.
➤ HOME screen appears.
 - 2** Touch .
- From the screen, you can select the following sources and functions.

	• Displays the Hands Free screen. (P.21)
	• Switches to the T-Link screen from the connected iPhone/Android device.*1 (P.26)
	• Plays a Bluetooth audio player. (P.15)
	• Switches to the Radio broadcast. (P.39)
	• Plays a disc. (P.28)
	• Switches to an external component connected to the AUX input terminal. (P.42)
	• Plays files on a USB device. (P.34)
	• Plays an iPod/iPhone. (P.37)
	• Switches to the camera image screen. (P.41)
	• Turns off the AV source. (P.12)
	• Switches to the M-Toyota screen. (P.43)
	• Displays the Voice Recognition screen. (P.22)

*1 Premium AVX only.

To select the playback source on the HOME screen



The 4 items displayed on the source selection screen with large icons are shown on the HOME screen.

You can change the items displayed on this area by customizing the source selection screen. (P.12)

To turn off the AV source

- 1 Press button.
➤ HOME screen appears.
- 2 Touch .
- 3 Touch **AV Off**.



Customize Short-cut buttons on HOME screen

You can arrange the positions of the source icons as you like.

- 1 Press button.
➤ HOME screen appears.
- 2 Touch .
- 3 Touch and hold the icon which you want to move in the customizing mode.
- 4 Drag the icon to the desired position.




Source control screen descriptions

There are some functions which can be performed from most screens.

Indicators



Sub-control panel



1 All sources icon

Displays the source selection screen. (P.11)

2 Sub-control panel

  : Displays/hides the sub-control panel. This function is available in Disc and USB source.

3

Mute icon is indicated while AVX is muting.

4

Connected Bluetooth phone information.

5 Text scroll

Scrolls the displayed text.

List screen

There are some common function keys in the list screens of most sources.



1 Return

Returns to the previous screen.

2

Displays the list type selection window.

3 etc.

Keys with various functions are displayed here.

-   : Moves to the upper hierarchy level.
-  : Plays all tracks in the folder containing the current track.
-  : Jumps to the letter you entered (alphabetical search).

4

Displays a music/movie file list.

5 Text scroll

Scrolls the displayed text.


NOTE

- Depending on the current source or mode, some function key may not appear.


Connection

Wired Connection

This unit can be connected to external devices. Open the front port cover and connect the external device via the following accessory.




Connecting a USB device




^[1] Sold separately

Connecting an iPod/iPhone



^[1] Sold separately


Connecting an Android smartphone



^[1] Sold separately

Connecting an external component

You can connect an external component to the AUX input terminal.



^[1] Sold separately

⚠ WARNING

- Install the USB device/ iPod/ iPhone/ Android smartphone and Audio player in the place where it will not affect safe driving.

NOTE

- Do not keep the USB device/ iPod/ iPhone/ Android smartphone/ Audio player and USB cable in the car to avoid damage by heat.

Bluetooth Control

Using the Bluetooth function allows you to use various functions such as listening to the audio file and making/receiving a call.

Information for using Bluetooth® devices



Bluetooth is a short-range wireless radio communication technology for mobile devices such as mobile phones, portable PCs, and other devices.

Bluetooth devices can be connected without cables and communication with each other.

▲ WARNING

- While driving, do not perform complicated operations such as dialing numbers, using the phone book, etc. When you perform these operations, stop your car in a safe place.

NOTE

- Some Bluetooth devices may not be connected to this unit depending on the Bluetooth version of the device.
- This unit may not work for some Bluetooth devices.
- Connecting conditions may vary depending on your environment.
- Some Bluetooth devices are disconnected when this unit is turned off.

■ About the mobile phone and Bluetooth audio player

This unit conforms to the following Bluetooth specifications:

Version

Bluetooth Ver. 4.1

Profiles

Mobile phone:

HFP (V1.7) (Hands Free Profile)

SPP (Serial Port Profile)

PBAP (Phonebook Access Profile)

Audio player:

A2DP (Advanced Audio Distribution Profile)

AVRCP (V1.6) (Audio/Video Remote Control Profile)

Sound codec

SBC, AAC

NOTE

- The units supporting the Bluetooth function have been certified for conformity with the Bluetooth Standard according to the procedure prescribed by Bluetooth SIG. However, it may be impossible for such units to communicate with your mobile phone depending on its type.

Register the Bluetooth device

It is necessary to register the Bluetooth audio player or mobile phone in this unit before using the Bluetooth function.

You can register up to 10 Bluetooth devices.

NOTE


- Up to 10 Bluetooth devices can be registered. If an attempt is made to register the 11th Bluetooth device, the Bluetooth device connected on the earliest date will be deleted to register the 11th one.
- This AVX is compatible with the Apple Easy Pairing function. When an iPhone is connected to AVX via USB cable, a Bluetooth connection dialog appears. Please select the function and connect your iPhone.

1 Search for the unit ("Car Multimedia") from your smartphone/mobile phone.


Complete steps 1 to 4 within 30 seconds.

2 Operate your smartphone/mobile phone according to the displayed messages.

- **Confirm the request both on the smartphone/mobile phone.**



3 Select the function you want to use.



■ **Phone1 / Phone2**

Select the hands-free number to connect.

■ **Bluetooth Audio**

Put checkmark to use Bluetooth Audio.

■ **T-Link (Premium AVX only)**

Put checkmark check to use T-Link.

4 Touch Yes.

When data transmission and connection have completed, the Bluetooth telephone connection icon appears on the screen.

NOTE

- If the mobile phone supports PBAP, the phonebook data is downloaded automatically when you select **Phone1** or **Phone2**.
- For some mobile phones, you may need to operate the mobile phone to download the phonebook data.
- If the PIN Code is displayed in the message, input the PIN Code in your smartphone/mobile phone. The PIN Code is set to "0000" as the default.



Bluetooth Setup


- 1 Press  button.
➤ Popup menu appears.

- 2 Touch .



- System screen appears.

- 3 Touch **Connectivity**.



- Connectivity screen appears.

- 4 Set each parameter as follows.

■ Bluetooth

Set whether to use the Bluetooth function.

■ Device Select

Connect the Bluetooth device. **(P.17)**

■ Auto Pairing

When set to "ON", the Apple Auto Pairing function is turned on to automatically register the iPod touch or iPhone connected to this unit.

ON (Default): Turns on the Apple Auto Pairing function.

OFF: Turns off the Apple Auto Pairing function.

■ Device Name

Change the device name. **(P.18)**

■ PIN Code


Change the PIN Code. **(P.18)**

■ Device Address


Displays the media access control address.

Connect the Bluetooth device

- 1 Touch **Device Select** on the Connectivity screen.



- 2 Touch the name of the device you want to connect.




- Profile select screen appears.

NOTE

- If the icon is lighted, it means that the unit will use that device.

- 3 Set each profile as follows.



■ Phone1, Phone2

Select when the device is connected with the unit as hands-free phone 1 or 2.

■ Bluetooth Audio

Select to use as an audio player.

■ T-Link (Premium AVX only)


Select to use as the T-Link source.

- 4 Touch **Close**.


Bluetooth Control

To delete the registered Bluetooth device

1 Touch **Delete**.



2 Touch the device name to check.



■ **Select All**

Selects all Bluetooth devices.

■ **Deselect All**

Clears all check marks.

3 Touch **Delete**.

➤ Confirmation message appears.

4 Touch **Yes**.

Change the device name

1 Touch **Device Name** on the Connectivity screen.

➤ Change Device Name screen appears.

2 Touch and hold **BS**.

3 Input the device name.



4 Touch **Enter**.


Change the PIN Code

1 Touch **PIN Code** on the Connectivity screen.

➤ Change PIN Code screen appears.

2 Touch and hold **BS**.

3 Input the PIN Code.




4 Touch **Set**.

Playing the Bluetooth Audio Device

Most functions can be controlled from the source control screen.

To select Bluetooth source, touch **Audio** icon on the source selection screen. (P.11)

Bluetooth basic operation



1 Information display

- Displays the current track information.
- Connected device name.

2 Operation keys *

- : Searches for a file. See **File search (P.20)**.
- : Searches for the previous/next content.
Touch and hold to fast forward or fast backward.
- : Plays.
- : Pauses.
- : Repeats the current track/folder. Each time you touch the key, repeat modes are switched in the following sequence:
File repeat (), All songs repeat (), Repeat off ()
- : Randomly plays all tracks in the current folder. Each time you touch the key, random modes are switched in the following sequence:
All random (), Random off ()

* These items appear only when the audio player which supports AVRCP profile is connected.

3 Playing time

For confirmation of current playing position.

0:01:23 0:12:34

4

Bluetooth audio devices can be switched easily to play music. See **Bluetooth Audio Device Change (P.20)**.

NOTE

- The operation buttons, indications and information displayed on the screen differ depending on the connected device.
- If the operation keys do not appear, operate from the player.
- Depending on your mobile phone or audio player, sound may be heard and controlled but text information may not appear.
- If the volume is too low, raise it on your mobile phone or audio player.


Bluetooth Audio Device Change

Up to five Bluetooth audio device can be connected and switched easily to play music.

- 1 Touch .
 - ▶ A list of registered devices is displayed.
- 2 Touch  of device name you want to connect.
 - Touching  on the left of the connected device ( ▶) disconnects this device.



- 3 Touch  (white) on the left of the name of the device to be played.
 - ▶ (white) changes to  (Blue) and starts playback.



-  (Gray) : Not connected.
-  (White) : Connected.
-  (Blue) : During playback.

- 4 Touch .

NOTE

- If a connected Bluetooth audio device is operated to play music, connections are switched.
- When a Bluetooth source is switched to another one, its settings are deleted and the connection is restored to the connection before source switching.

File search

- 1 Touch .
- 2 Touch the desired file or folder.



When you touch a folder its contents are displayed.

- 3 Touch the desired item in the content list.
 - ▶ Playback starts.

NOTE

- For operations in the list screen, see **List screen (P.13)**.

Using the Hands-Free Unit

You can use the telephone function by connecting the Bluetooth telephone to this unit.

Make a call

- 1 Press  button.
➤ HOME screen appears.
- 2 Touch .
- 3 Touch **Phone**.
➤ Hands Free screen appears.

NOTE

- If your mobile phone supports PBAP, you can display the phone book and call lists onto the touch panel screen when the mobile phone is connected.
 - Phone book: up to 1000 entries
 - Up to 50 entries including dialed calls, received calls, and missed calls

4 Select a dialing method.



- : Call using call history
- : Call using the phonebook
- : Call by entering a phone number

● Select the mobile phone to use

When you connect two mobile phones

- 1) Touch  to select the phone you want to use.

● Phone Setup

- 1) Touch .
Phone Setup screen appears. (P.25)

NOTE

- Bluetooth hands free sound quality and performance also depend on mobile phones and carrier conditions.
- Status icons such as battery and antenna icons may differ from those displayed on the mobile phone.
- Setting the mobile phone in the private/visibility off mode can disable the hands-free function.

Call using call history

- 1 Touch .
- 2 Select the phone number from the list.



Call using the phonebook

You can use the phonebook data of the selected mobile phone to make a call. Before starting this procedure, it is necessary to download the phonebook data. For details, see **Phonebook transfer (P.24)**.

- 1 Touch .
- 2 Touch .
- 3 Select the initial.




- Special characters cannot be searched using this function.


Bluetooth Control

- Accented first characters of each name entry can be searched using the equivalent normal character of that letter. i.e. Ñ can be searched as N
- Accented characters cannot be searched in the middle of the word.

4 Select the person you want to call from the list.



5 Select the phone number from the list.



NOTE

- You can sort the phone numbers in the list by last name or first name. For details, see **Phone Setup (P.25)**.

Call by entering a phone number

- 1 Touch .
- 2 Enter a phone number with number keys.



- 3 Touch .


Voice Recognition

You can access the voice recognition function of the mobile phone connected to this unit. You can search the mobile phone phonebook by voice. (The functionality depends on the mobile phone.)

- 1 Press  button.
➤ HOME screen appears.
- 2 Touch .
- 3 Touch **Voice . (P.11)**
➤ Voice Recognition screen appears.
- 4 Start speaking.

Receive a call

- 1 Touch  to answer a phone call or  to reject an incoming call.



NOTE

- While monitoring the picture from the view camera, this screen does not appear even if a call comes in.

To end call


- 1 While talking, touch .

Operations during a call




● Adjust the volume of your voice

- 1) Touch .
- 2) Touch  or  for **Microphone Level**.



● Adjust the receiver volume

Press the - or + button.



● Mute your voice

Touch  to mute or not to mute your voice.

● Output the dial tone

Touch  to display the tone input screen. You can send tones by touching desired keys on the screen.

● Switching between speaking voice output destinations

Touching  /  each time switches speaking voice output destinations between the mobile phone and the speaker.

● Call-waiting

When you receive a new call while talking on the phone, you can answer the newly received call by touching . The current call is put on hold.

Each time you touch , the caller will change to the other one.

When you touch , the current call will end to be switched to the call waiting on hold.

● To close the Hands-Free popup screen

Touching  to close the Hands-Free popup screen. To display it again, touch  at the top of the screen.


Bluetooth Control

Phonebook transfer

You can transfer phonebook data from your Bluetooth phone using PBAP.

1 Touch  .

2 Touch  .



➤ Phonebook data transfer starts.


NOTE

- If the Phonebook contains more than 1000 entries, Phonebook data cannot be transferred.
- The phonebook data of up to 10 Bluetooth devices can be stored.
- When you connect the mobile phone of which the phonebook data is downloaded before, the downloaded data will be displayed.
- If you download the phonebook data from the same device again, the data will be overwritten.

Phonebook deletion

1 Touch  .

2 Touch the name to check.



■  .
Checks all boxes.

■  .
Clears all check marks.

3 Touch  .

➤ Confirmation message appears.

4 Touch **Yes**.

Phone Setup

You can make various settings for the Hands-Free function.

- 1 Press  button.
 - HOME screen appears.
- 2 Touch .
- 3 Touch **Phone**.
 - Hands Free screen appears.
- 4 Touch .



- Phone Setup screen appears.

5 Set each function as follows.



■ Select Phone Device

Select the mobile phone to use as the Hands-Free phone 1 or 2 from the registered device list.



Touching  or  switches the selected phone device.

■ Auto Response*

Set the automatic response time to pick-up an incoming call.

OFF (Default): Turns off the Automatic response function.

1 / 5 / 10 / 15 / 20 / 25 / 30: Sets the ringing time (second).

■ Sort Order

Set how to sort the data in the mobile phone phonebook.

First Name/Last Name: Sorts data by the first name.

Last Name/First Name (Default): Sorts data by the last name.

■ Echo Cancel

Adjust the level of echo cancellation.

Default is "0".

■ Noise Reduction

Reduce the noise generated in the surrounding environment without changing the microphone volume. Use this function when the voice of caller is not clear. Default is "0".

■ Reception Volume

Adjust the receiver volume.

Default is "15".

■ Incoming Ring Tone Volume

Adjust the ring tone volume of a new incoming call while talking.

Default is "15".

* Either the auto response time set on this unit or the time set on the mobile phone, whichever is shorter takes effect.

T-Link (Premium AVX)

You can display the same screen of the smartphone on the monitor of the unit using the T-Link source.

Preparation

1 Download "T-Link" from (Apple) App Store or Google Play.

T-Link is a free Application.

Compatible devices are the following

- iOS version 11 or later
- Android version 5.0 (Lollipop) or later/Linux kernel version 3.5 or later
- Bluetooth support

For the case if you can not find "T-Link" App in Google Play, please search again by inputting as "T-Link JVCケンウッド".

2 Pair your smartphone with AVX via Bluetooth.

See **Register the Bluetooth device (P.16)** and **Connect the Bluetooth device (P.17)**.

NOTE

- Some Android Smartphone may not be able to support 2-way Touch Control due to Smartphone's technical spec.
 - While using T-Link, Smartphone temperature may be increased due to the below factors.
 - Keep running Nav App and/or Music straming App.
 - Keep running Wi-Fi, GPS and Bluetooth.
- If you recognize that your Smartphone gets hot, please stop using T-Link and disconnect USB.

Connecting a smartphone

Connecting an iPhone

- 1 On your iPhone, launch "Settings". Touch "Control Center" and then "Customize Controls".
- 2 Touch "Screen Recording" and add to "INCLUDE" list.
- 3 Launch Control Center of your iPhone, touch and hold Screen Recording icon and then touch "T-Link" and start broadcast.

4 Connect your iPhone with AVX via Lightning to USB cable. (P.14)

Connecting an Android device

1 Connect your Android Smartphone via USB cable. (P.14)

2 Launch T-Link App on your Android Smartphone.

Press "Start now" to start capturing your Android screen.

Press "OK" to start T-Link.

Turn on "Overlay Permission" of T-Link.

Turn on "Accessibility Service" to be able to filter drive-safe apps.

3 Start to enjoy T-Link.

NOTE

- You can check "how to" tutorial in T-Link App.
- When you use T-Link first time, T-Link terms of service are displayed. It is necessary to agree to the T-Link terms of service to use this function.

Mirroring Operation

1 Operate your smartphone to activate T-Link App, then connect to this unit. (P.26)

2 Press button.

> HOME screen appears.

3 Touch .

4 Touch T-Link. (P.11)

> The caution message screen is displayed.

5 Read the caution message and touch Agree.




> T-Link screen appears.

NOTE

- T-Link is discontinued when you switch to another source screen. However, while displaying the current screen, you can switch to another source by using the steering wheel switches for "AV Source Select" on the T-Link Setup screen.
- While you use the T-Link function with an iPhone, T-Link is discontinued by the following operations. To resume the T-Link functions, disconnect the USB cable and try connecting it again.
 - Receiving a call
 - iPhone's screen recording function is stopped.
 - iPhone screen is turned off.
- Some Apps may not sound.
- While you use the T-Link function with an Android device, the software keyboard is displayed only when you operate the Android device and enable the virtual keyboard beforehand.
- For more information on T-Link, refer to the instruction manual supplied with T-Link App.
- While the T-Link function is enabled, you cannot use USB source.
- You cannot use both T-Link and iPod source at the same time.
- You cannot use both T-Link and Bluetooth Audio source at the same time.
- After you end to use the T-Link function, stop broadcast on iPhone's screen recording function. Otherwise iPod and Bluetooth Audio sources may not work correctly.
- For iPhone users, due to iOS system limitations, only one application can be open at a time. When using any navigation application, please refrain from using other applications as this will interfere with T-Link operations.
For example, if you use Waze together with Spotify, AVX will stop displaying Waze Navigation screen and only Spotify sound comes from AVX. This occurs due to iOS system limitations.

T-Link Setup

- 1 Press  button.
▶ Pop up menu appears.
- 2 Touch .
▶ T-Link Setup screen appears.
- 3 Set each item as follows.

**T-Link Device Connect**

Select the desired smartphone to use as T-Link from the registered device list.



Touching  switches the selected phone device.

Virtual Hard Key

Set whether to display the virtual hard key of the smartphone.



Virtual hard keys*

You can operate the App by these virtual hard keys in a similar way by the hard keys on the smartphone.

 /  : Changes the virtual hard keys position.

 (Android only) : Recent Apps key

 : Home key

 (Android only) : Back key

 : Closes the virtual hard keys.

NOTE

- Each function of the virtual hard keys differs depending on the connected device and may differ from the function operated on the device.
- The virtual hard keys can be displayed even if there is no hard key on the connected device.

* These keys differ depending on the connected device.

AV Source Select

While using T-Link, you can play media file in the background.

The media file from the following sources can be played.

CD/ Radio/ AUX/ AV Off

Disc


▲ WARNING

- Any video won't be played while driving to prevent driver's eyes from fixing on the unit's display. Stop the vehicle in a safe place and apply the parking brake before performing such function.

Playing a disc

Insert a disc

- 1 Insert the disc into the slot.



- ▶ The unit loads the disc and playback starts.

▲ CAUTION

- Do not insert anything other than a disc into the disc-loading slot.

● Starting the disc playback manually

- 1 Press button.
 - ▶ HOME screen appears.
- 2 Touch .
- 3 Touch **Disc**.

Eject a disc

- 1 Press button.
 - When removing a disc, pull it horizontally.

NOTE

- To forcibly eject the disc, press and hold for 2 seconds.

DVD/ Video-CD Basic Operation

Most functions can be controlled from the source control screen and playback screen.

NOTE

- The screen shot below is for DVD. It may be different from the one for Video-CD.

- 1 When the operation buttons are not displayed on the screen, touch the display.

Control screen



Sub-control panel

DVD



Video-CD



Video screen



1 Information display area

Displays the following information.

- Linear PCM, etc.:** Audio format
- Title #, Chapter #:** DVD title and chapter number
- Track #/Scene #:** Video-CD track or scene number. Scene # is displayed only when Playback control (PBC) is on.

- **Hide**: Hides the control screen.

2 Operation keys

- : Repeats the current content. Each time you touch the key, repeat modes are switched in the following sequence;

DVD: Title repeat (), Chapter repeat (), Repeat off ()

Video-CD (PBC On): Does not repeat

Video-CD (PBC Off): Track repeat (), Repeat off ()

- : Searches for the previous/next content.

Touch and hold to fast-forward or fast-backward the disc.

- : Plays or pauses.
- : Stops.

3 Playing time (DVD only)

For confirmation of current playing position. You can drag the circle left or right to change the playing position.



4 Function keys (DVD only)

- **Highlight**: Touch to display the DVD Video highlight screen. See **Highlight control (P.32)**.
- **Menu**: Touch to display the DVD Video disc menu control screen. See **DVD Disc Menu Operation (P.31)**.

5 (DVD main control screen only)

Touch to display the DVD Setup screen. See **DVD Setup (P.32)**.

6 Sub-control panel

Touch the left side of the screen to display the function panel. Touch again to close the panel.

- : Fast-forwards or fast-backward the disc. Each time you touch the key, the speed changes. 2 times, 10 times.
-  (DVD only): Plays in slow motion forward or backward.
- **PBC** (Video-CD only): Touch to turn Playback control (PBC) on or off.
- **Audio** (Video-CD only): Touch to change audio output channels.
 - **1chLL/2chLL**: Identifies the left audio output of channel 1 or 2.
 - **1chLR/2chLR**: Identifies the monaural audio output of channel 1 or 2.

- **1chRR/2chRR**: Identifies the right audio output of channel 1 or 2.
- **1chST/2chST**: Identifies the stereo audio output of channel 1 or 2.
- **LL**: Identifies the left audio output.
- **LR**: Identifies the monaural audio output.
- **RR**: Identifies the right audio output.
- **ST**: Identifies the stereo audio output.

7 Key display area

Touch to display the control screen.

NOTE

- The control screen disappears when no operation is done for 5 seconds.
- If you use a remote control, you can jump directly to the desired image by entering the chapter number, scene number, play time, etc. (**P.58**).

Music CD/ Disc media Basic Operation

Most functions can be controlled from the source control screen and playback screen.

NOTE


- In this manual, "Music CD" means a general CD which includes music tracks. "Disc media" means a CD/DVD disc which includes audio or video files.
- The screen shot below is for disc media. It may be different from the one for CD.

Control screen

Music file



Video file



Sub-control panel



1 CODEC (Premium AVX)

When a high-resolution source is played, its format information is displayed. (Disc media only)

2 Track information

Displays the information of the current track/ file. Only a file name and a folder name are displayed if there is no tag information. (Disc media only)

3 Operation keys

- : Displays the Music list (Music CD only) or the Folder List (Disc media only). For details on search operation, see **Search Operation (P.31)**.
- : Searches for the previous/next content. Touch and hold to fast-forward or fast-backward the disc.
- : Plays or pauses.
- : Repeats the current track/folder. Each time you touch the key, repeat mode switches in the following sequence; Track/ File repeat (), Folder repeat () (Disc media only), Repeat all ()
- : Randomly plays all tracks in current folder/disc. Each time you touch the key, random mode switches in the following sequence; Track random () (Music CD only), Folder random () (Disc media only), Random off ()

4 Sub-control panel (Disc media only)

Touch the left side of the screen to display the function panel. Touch again to close the panel.

- : Searches for the previous/next folder.

5 Playing time

For confirmation of current playing position. You can drag the circle left or right to change the playing position.



6 Hide (Video file only)

Hides the control screen.

Video screen



7 Key display area (Video file only)

Touch to display the control screen.

Search Operation (Music CD/ Disc media only)

You can search for a track/file.


NOTE

- For operations in the list screen, see **List screen (P.13)**.
- The screen shot below is for disc media. It may be different from the one for CD.

1 Touch .

➤ Folder List screen appears.

2 Touch the desired item in the content list.



(Disc media only)

You can search for the other folder and select to play all files in the folder.

When you touch a folder, its contents are displayed.

DVD Disc Menu Operation

You can set up some functions using the DVD-VIDEO disc menu.


1 Touch the display during playback.



2 Touch **Menu**.

➤ Menu Control screen appears.

3 Perform your desired operation as follows.



■ To display the top menu

Touch **Top**.*

■ To display the menu

Touch **Menu**.*

■ To display the previous menu

Touch **Return**.*

■ To enter selected item

Touch **Enter**.

■ To enable direct operation

Touch **Highlight** to enter the highlight control mode (P.32).

■ To move the cursor

Touch **▲**, **▼**, **◀**, **▶**.

■ To switch among subtitle languages

Touch **Subtitle**. Each time you touch this key, subtitle languages are switched.

■ To switch among audio languages

Touch **Audio**. Each time you touch this key, audio languages are switched.

Disc

■ To switch among picture angles

Touch **Angle**. Each time you touch this key, picture angles are switched.

■ To close the Menu Control screen

Touch **Hide**.

*These keys may not function depending on the disc.

■ Highlight control

Highlight control lets you control the DVD menu by touching the menu key directly on the screen.

1 Touch **Highlight** on the Menu Control screen.

2 Touch your desired item on the screen.



NOTE

- The highlight control function is cancelled automatically if you do not operate for a predetermined period of time.

DVD Setup

You can set up the DVD playback functions.

1 Touch the display during playback.




2 Touch .



> DVD Setup screen appears.

3 Set each function as follows.



■ Menu Language / Subtitle Language / Audio Language

See *Language setting (P.33)*.

■ Dynamic Range Control

Sets the dynamic range.

Wide: The dynamic range is wide.

Normal: The dynamic range is normal.

Dialog (Default): Makes the total sound volume larger than the volumes in other modes. This is effective only when the Dolby Digital software is in use.

■ Screen Ratio

Sets the screen display mode.

16:9 (Default): Displays wide pictures.

4:3 LB: Displays wide pictures in the Letter Box format (having black stripes at the top and bottom of screen).

4:3 PS: Displays wide pictures in the Pan & Scan format (showing pictures cut at the right and left ends).


📺 Language setting

This setting is for the languages used for the menu, subtitle, and voice.

1 Touch the desired item; **Menu Language, Subtitle Language, Audio Language.**

➤ Language Set screen appears.

2 Select a language.



For language codes, refer to **DVD Language Codes (P.64)**.

Touch **Close** to set the entered language and return to the DVD Setup screen.

NOTE

- To set the DVD's original language as the audio language, touch **Original**.
- The selectable languages on each setting is varied depends on the disc.

USB

▲ WARNING

- Any video won't be played while driving to prevent driver's eyes from fixing on the unit's display. Stop the vehicle in a safe place and apply the parking brake before performing such function.

Connecting a USB device

- 1 Connect the USB device to the USB port. (P.14)
- 2 Press  button.
▶ HOME screen appears.
- 3 Touch .
- 4 Touch **USB**. (P.11)

Disconnect the USB device

- 1 Press  button.
▶ HOME screen appears.
- 2 Touch a source other than **USB**.
- 3 Detach the USB device.

Usable USB device

You can use a mass-storage-class USB device with this unit.
The word "USB device" appearing in this manual indicates a flash memory device.

● About the file system

The file system should be the one of the following.

- FAT16 • FAT32 • exFAT • NTFS

NOTICE

- Install the USB device in the place where it will not affect safe driving.
- You cannot connect a USB device via a USB hub and Multi Card Reader.
- Take backups of the audio files used with this unit. The files can be erased depending on the operating conditions of the USB device. We shall have no compensation for any damage arising from any erased data.

USB Basic Operation


Most functions can be controlled from the source control screen and playback screen.

Control screen

Music file



Video file



Sub-control panel



1 CODEC (Premium AVX)

When a high-resolution source is played, its format information is displayed. (Music file only)

2 Track information

Displays the information on the current file. Only a file name and a folder name are displayed if there is no tag information.

3 Operation keys

- : Searches track/file. For details on search operation, see **Search Operation (P.35)**.
- : Searches the previous/next track/file.
Touch and hold to fast forward or fast backward.
- : Plays or pauses.
- : Repeats the current track/folder. Each time you touch the key, repeat modes are switched in the following sequence:
File repeat (), Folder repeat (), Repeat all ()
- : Randomly plays all tracks in the current folder. Each time you touch the key, random modes are switched in the following sequence:
File random (), Random off ()

4 Sub-control panel

Touch the left side of the screen to display the function panel. Touch again to close the panel.

- : Searches for the previous/next folder.

5 Playing time

For confirmation of current playing position. You can drag the circle left or right to change the playing position.



6 Hide (Video file only)

Hides the control screen.

Video screen



7 Key display area (Video file only)

Touch to display the control screen.

Search Operation

You can search music or video files by the following operations.

- 1 Touch on the USB control screen.
- 2 Touch .



- 3 Select a list type.




NOTE

- For operations on the list screen, see **List screen (P.13)**.

Category search

You can search for a file by selecting a category.

- 1 Touch **Category List**.
- 2 Select whether you search audio files or video files .
- 3 Touch the desired category.




- The list corresponding to your selection appears.
- 4 Touch to select the desired item in the list. Repeat this step until you find the desired file.

Folder search

You can search for a file according to hierarchy.

- 1 Touch **Folder List**.
- 2 Touch the desired folder.



When you touch a folder its contents are displayed.

- 3 Touch to select your desired item in the list. Repeat this step until you find the desired file.

iPod/iPhone

Preparation

Connectable iPod/iPhone

The models which have the Lightning port can be connected to this unit.

WARNING

- Firmly secure the iPod when driving. Do not let the iPod fall onto the floor, where it may become jammed under the brake or accelerator pedal.

NOTICE

- Toyota accepts no responsibility for data lost from an iPod, even if that data is lost while using this product. Please back up your iPod data regularly.
- Do not leave the iPod in direct sunlight for extended amounts of time. Extended exposure to direct sunlight can result in iPod malfunction due to the resulting high temperature.
- Do not leave the iPod in any location with high temperatures.


NOTE

- When you turn on this unit, the iPod/iPhone is charged through the unit.
- If you restart playback after connecting the iPod, the music that has been played by the iPod is played first.

Connect iPod/iPhone

- 1 Connect the iPod/iPhone to the USB port. (P.14)
 - 2 Press  button.
➤ HOME screen appears.
 - 3 Touch .
 - 4 Touch **iPod**. (P.11)
- **To disconnect the iPod/iPhone connected with the cable:**
- 1 Detach the iPod/iPhone.

iPod/iPhone Basic Operation



1 Track information

Displays the information on the current file.

2 Operation keys

- : Searches for a track/file. For details on search operation, see **Search Operation (P.38)**.
- : Searches for the previous/next track/file.
Touch and hold to fast forward or fast backward.
- : Plays or pauses.
- : Repeats the current track/album. Each time you touch the key, repeat modes are switched in the following sequence:
Song repeat (), All songs repeat (), Repeat off ()
- : Randomly plays all tracks in the current album. Each time you touch the key, random modes are switched in the following sequence:
Song random (), Random off ()

3 Playing time

For confirmation of current playing position. You can drag the circle left or right to change the playing position.




Search Operation

You can search music files by the following operation.

NOTE

- For operations on the list screen, see **List screen (P.13)**.

- 1 Touch on the iPod/iPhone control screen.
- 2 Touch the desired category.



- The list corresponding to your selection appears.


- 3 Touch to select the desired item in the list. Repeat this step until you find the desired file.

Radio

Radio Basic Operation

Most functions can be controlled from the source control screen.

To enter Radio source, touch **Radio** icon in the source selection screen. (P.11)



1 Information display

Displays the information of the current station: Frequency

2 Preset keys

Recalls the memorized station.

When touched for 2 seconds, stores the current receiving station in memory.

3 Operation keys

- **◀◀ ▶▶** : Switches to the previous/next frequency manually.
Touch and hold to tunes in a station with good reception automatically.
- **BAND** : Switches the band (FM1/ FM2, AM).
- **MONO** (FM only) : Switches the FM stereo broadcast to in monaural reception. This is effective to reduce the noise.
- **AUTO.P** : Presets stations automatically. For details, see **Auto preset memory (P.39)**.
- **LOCAL.S** (FM only) : Receives only the stations with good reception.

Memory Operation

Auto preset memory

You can store stations in memory automatically.

1 Touch **AUTO.P**.



2 Touch **Yes**.



➤ Auto preset memory starts.

Manual memory

You can store the current receiving station in memory.

1 Select a station you wish to store in memory.

2 Touch **P#** (#:1-6) in which you want to store the station for 2 seconds until a beep sounds.

Selecting Operation

Preset select

You can select memorized station.

1 Touch desired preset station.



Other External Components

Using the back camera

Back camera view

When the gear stick is aligned to the REVERSE (R) position, the screen automatically switches to full-screen back camera image. The back camera image is automatically reversed and displayed on the front screen.

CAUTION

- A clear image cannot be displayed on the screen if the back camera lens is dirty. If water droplet or mud etc. is on the lens, wash it off and wipe the lens with a soft cloth. If the lens gets extremely dirty, wash it off using a mild cleanser.
- The image quality may deteriorate depending on the usage environment, such as at night or in dark surroundings.
- The range projected by the back camera is limited.
- The parking assist guidelines are for reference purpose only. Always check with your own eyes if the surrounding is safe and there is enough space for your vehicle to be parked.
- The distance indicated by the guidelines is intended for flat road surfaces and calculated based on the ground level. If any part of the road is sunken, the accuracy of the distance indicated is reduced.
- The vehicle width and distance guidelines displayed on the back camera view may differ from the actual vehicle width and distance.
- The actual distance from bumper to bumper may be less than the distance indicated by the guidelines. If the bumper of another vehicle is displayed on the screen while backing up the vehicle, check the distance with your own eyes.
- The guidelines may not be parallel with the dividing lines of the parking space, even if they appear to be parallel.
- The distances between the guidelines and the dividing lines of the parking space may not equal, even if they appear to be equal.

- Object located higher than the back camera may not be displayed on the screen.
- The back camera view is closed automatically if the gear stick is aligned to the positions other than the REVERSE (R) position.
- The back camera view mode is to use this product as an aid while backing up. Do not use this function for entertainment purposes.

Display the camera image screen

The camera screen is displayed when you shift the gear to the reverse (R) position.



1 Back Sensor (The vehicle which equips back camera and back sensor only)

Displays the distance between you and the closest obstacle.

If you select **OFF** for **Camera Connection**, Back Sensor appears in full-screen.


To display the picture from the camera manually

1 Select **Camera** as the source. (P.11)

Other External Components


Camera Setup

- 1 Press  button.
 - Popup menu appears.
- 2 Touch .
- 3 Touch **Camera**.



- Camera screen appears.

- 4 Set each item as follows.



■ Camera Connection

Set whether to use the rear view camera.

■ Guideline

You can display parking guidelines to enable easier parking when you shift the gear to the reverse (R) position.

Default is "ON".


External audio players (AUX)

- 1 Connect an external component to the **AUX** input terminal. (P.14)
- 2 Select **AUX** as the source. (P.11)
- 3 Turn on the connected component and start playing the source.

M-Toyota

Using M-Toyota allows you to make an emergency call and search a Toyota dealer.

To enter M-Toyota source, touch **M-Toyota** icon in the source selection screen. (P.11)



NOTE

- For operations on the list screen, see **List screen (P.13)**.

Emergency Calling


Preparation

- To use the M-Toyota emergency call function, connect your mobile phone as a Bluetooth device beforehand. See **Register the Bluetooth device (P.16)** and **Connect the Bluetooth device (P.17)**.

1 Touch Emergency Call on the M-Toyota screen.

➤ Emergency Call list appears.

2 Touch the desired contact information.




Toyota Dealer Search

You can search a Toyota dealer list and confirm the dealer information.

1 Touch Toyota Dealer on the M-Toyota screen.

2 Touch to select the desired region in the list.

3 Touch the desired dealer.



➤ Dealer information screen appears.

Setup


Display Adjust

- 1 Press  button.
 > Popup menu appears.
- 2 Touch .



> Display control screen appears.

- 3 Adjust each setting as follows.



If it is hard to see the image on the screen evenly, adjust the viewing angle. The smaller the (negative) value, the more whitish the image on the screen looks.

"0" (Default) / "1" / "2" / "3"



Adjust the backlight. ("4" to "4")

Picture Adjust


You can adjust the image quality of video, menu screen, etc.

- 1 Press  button.
 > Popup menu appears.
- 2 Touch .



> Picture control screen appears.

- 3 Adjust each setting as follows.



Adjust each setting.



(Camera only)

Adjust the tint. ("4" to "4")



(Video file only)

Select a screen mode.

Full: Displays video at the ratio of 16:9.

Normal: Displays video at the ratio of 4:3.

Auto:

DVD and Video-CD: 16:9 video is displayed in the Full mode and 4:3 video is displayed in the Normal mode.


USB device and disc media: Displays video fully (vertically or horizontally) with no ratio change.

NOTE

- Settings to adjust vary depending on the current source.

System Setup

- 1 Press  button.
 > Popup menu appears.
- 2 Touch .



See the following section for each setting.


- General systems (P.45)
- Regional systems (P.7)
- Connectivity systems (P.17)
- User interface systems (P.46)
- Dual Zone systems (P.48)
- Camera systems (P.42)
- Advanced Features systems*¹ (P.49)

*¹ Premium AVX only

General Systems

You can confirm the information of this unit.

- 1 Press  button.
 > Popup menu appears.
- 2 Touch .
- 3 Touch **General**.



> General screen appears.

- 4 Set each parameter as follows.

■ Software Information

Confirm the software version of this unit.
(P.45)

■ Open Source Licenses

Display the open source licenses.


■ Restore Factory Default

Touch **Restore Factory Default** and then touch **Yes** to set all the settings to the initial default settings.

Software Information


You can confirm the software version of this unit.

- 1 Touch **Software Information** in the **General** screen.
- 2 Confirm the software version.




User Interface Systems

- 1 Press  button.
➤ Popup menu appears.
- 2 Touch .
- 3 Touch **User Interface**.



➤ User Interface screen appears.

- 4 Set each parameter as follows.



■ Beep

Turn the key touch tone on or off.
Default is "ON".

■ Background


You can change the background image.
(P.46)

■ Key Illumination Color

You can change the key color. (P.47)

Change the background image

- 1 Touch **Background** on the User Interface screen.
- 2 Select an image.



*1 Register an original image in advance.

To register an original image

You can load an image from the connected USB device and set it as the background image.

Before starting this procedure, it is necessary to connect the device which has the image to load.

- 1 Touch **User Select** on the Background screen.
- 2 Select the image to load.



3 Touch **Enter**.



- ▶ The selected image is loaded and the display returns to the Background screen.

NOTE

- Touching  rotates the image counter-clockwise.
- Touching  rotates the image clockwise.
- Picture files: JPEG (.jpg, .jpeg), PNG (.png), BMP (.bmp)

Change the key color

- 1 Touch **Key Color** on the User Interface screen.
- 2 Select a key color.



- 3 Touch .

To register an original color

You can register your original color.

- 1 Touch **User** on the Key Color screen.
- 2 Touch **Adjust**.
- 3 Use - and + to adjust each color value.



- 4 Touch .

Dual Zone Systems

You can select different sources for front and rear positions in the vehicle.


NOTE

- This function is available for the vehicle comes with Dual Zone System.
- This function doesn't work in below cars.
 - No rear speakers are equipped.
 - No Rear Monitor is equipped.

1 Press  button.
 > Popup menu appears.


2 Touch .
 > System screen appears.

3 Touch **Dual Zone**.




> Dual Zone screen appears.


4 Touch **Zone Select**.



5 Touch **Dual Zone**.



6 Set each source as follows.



■ Zone Select

Touch **Single Zone** to turn off the dual zone function.

■ Front Source / Rear Source

Select a source for each.

Rear Source; OFF/ Disc/ USB/ AUX

■ Rear Volume

Adjust the rear source volume.

NOTE

- When you select the source which does not include a video as Rear Source, the rear monitor won't display any image.
- When the "Zone Select" is set to "Dual Zone", the following functions are not available.
 - Fader (**P.50**)
 - Equalizer Control/ Sound Effect/ Listening Position/DTA (**P.51, 52, 53**)
 - High-resolution Sound Source File Playback (Premium AVX only)

Selectable combinations

Front Source	Rear Source
T-Link	OFF
Bluetooth audio	OFF/ Disc (DVD/Video-CD)/ AUX
Radio	OFF/ Disc/ USB/ AUX
Disc (DVD/ Video-CD)	OFF/ Disc/ USB/ AUX
Disc (Music CD/ Disc media)	OFF/ AUX
AUX	OFF/ Disc/ USB/ AUX
USB	OFF/ Disc (DVD/Video-CD)/ USB/ AUX
iPod	OFF/ Disc (DVD/Video-CD)/ AUX


Advanced Features (Premium AVX only)

You can set the Advanced Features system parameters, such as door lock alarm and auto folding mirror functions.

1 Press  button.
 > Popup menu appears.


2 Touch .
 > System screen appears.

3 Touch **Advanced Features**.



> Advanced Features screen appears.

4 Set each parameter as follows.



■ Door Lock Volume

Adjust the volume for door lock alarm.

■ Door Lock Sound

Select the sound for door lock alarm.


■ Auto Folding Mirror

Turn the auto folding mirror function on or off.

Controlling Audio

You can adjust various settings such as audio balance.

- 1 Press  button.
➤ Popup menu appears.
- 2 Touch .




See the following section for each setting.


- Controlling equalizer (**P.51**)
- Set listening position/ DTA (**P.53**)
- Controlling general audio (Fader/Balance) (**P.50**)
- Set volume offset (**P.52**)
- Set sound effect (**P.52**)

Controlling General Audio

- 1 Press  button.
➤ Popup menu appears.
- 2 Touch .
- 3 Touch **Fader/Balance**.



- 4 Set each parameter as follows.



■ Fader / Balance

Adjust the volume balance around the touched area.

 and  adjust the right and left volume balance.

 and  adjust the front and rear volume balance.


■ Center

Clear the adjustment.


Equalizer Control

You can adjust equalizer by selecting the optimized setting for each category.

- 1 Press  button.
 - Popup menu appears.
- 2 Touch .
 - Audio screen appears.
- 3 Touch **Equalizer**.



- 4 Touch the screen and set the Graphic Equalizer as desired.



■ Gain level (area in dotted frame)

Adjust the gain level by touching each frequency bar.

You can select a frequency bar and adjust its level by  .

■ Preset Select

Display the screen for selecting the preset equalizer curve. (P.51)

■ Preset Memory

Saves the adjusted equalizer curve as "User".



Initialize (flatten) the current EQ curve.

■ All Sources


Apply the adjusted equalizer curve to all sources. Touch **All Sources** and then touch **OK** on the confirmation screen.

■ ON/OFF (Bass Extend Settings)

When turned on, the frequencies lower than 62.5 Hz is set to the same gain level (62.5 Hz).

Recall the EQ curve

- 1 Touch **Preset Select**.
- 2 Select an EQ curve.




NOTE

- This AVX equips the below vehicle type EQ settings.
 - Sedan
 - C-SUV, H/B (Compact SUV and Hatchback)
 - MPV
 - SUV,PU (SUV and Pick Up Truck)
 - Van
- The EQ setting is optimized for each vehicle type and produce clean, distortion-free natural sound at any listening level.

Volume Offset

Finely adjust the volume of the current source to minimize the difference in volume between different sources.

- 1 Press button.
➤ Popup menu appears.
- 2 Touch .
➤ Audio screen appears.
- 3 Touch **Volume Offset**.



- 4 Touch **+** or **-** to adjust the level.



■ Initialize

Returns to the initial settings.

Touch **Initialize** and then touch **Yes** on the confirmation screen.


NOTE

- If you have increased the volume first, then reduce the volume using "Volume Offset". Switching the current source to another source suddenly may output extremely loud sound.


Sound Effect

You can set sound effects.

- 1 Press button.
➤ Popup menu appears.
- 2 Touch .
➤ Audio screen appears.
- 3 Touch **Sound Effect**.



- 4 Set each parameter as follows.



■ Bass Boost

Set the amount of bass boost.

"OFF"/"1"/"2"/"3"

■ Loudness

Set the amount of boost of low and high tones.

"OFF"/"Low"/"High"

■ Auto Sound Level

AVX automatically adjust EQ setting based of volume level or vehicle speed.

The function is varied depends on vehicle or vehicle grade.

"OFF"/"ON"

■ Space Enhancement

Select the feeling of sound space enhancement.

"OFF"/"Small"/"Medium"/"Large".

This setting is not available for the Radio source.

■ **K2 Technology**

Turn ON/OFF the K2 function.

Technology to extrapolate and supplement with proprietary algorithm, the high-frequency range that is cut off when encoding.

■ **Sound Response**

Virtually make the sound more realistic using the Digital Signal Processor (DSP) system. Select the level from "OFF"/"1"/"2"/"3".

■ **Sound Lift**


You can adjust the height of speakers virtually to suit your listening position. "OFF"/"Low"/"Middle"/"High".

Listening Position/ DTA

Listening Position/DTA allows you to improve the sound field depending on the position of the seat you sit.

Listening Position/DTA allows you to set "Listening Position" and "Front Focus". You cannot set both at the same time.

- 1 Press  button.
 - Popup menu appears.
- 2 Touch .
 - Audio screen appears.
- 3 Touch **Position/DTA**.




- Set up Listening Position (**P.53**)
- Set up Front Focus (**P.54**)

Listening Position

Adjust the sound delay time so that the sounds from different speakers arrive at the listener sitting on the selected seat at the same time.


- 1 Touch **Listening Position** on the Position/DTA screen.
- 2 Select a listening position from **Front R** (Right front), **Front L** (Left front), **Front All** (All front), and **All**.



Position DTA control


You can fine-adjust your listening position.

- 1 Touch **Adjust**.
- 2 Touch **Delay**.
- 3 Touch  or  to adjust the delay time of the selected speaker.



- 4 Touch **Level**.

- 5 Touch **<** or **>** to adjust the sound level of the selected speaker.



NOTE

- To initialize the Delay and Level settings, touch **Initialize** and **Yes** on the confirmation screen.


Front Focus

You can focus the imaginary sound image on the front of the selected seat.

- 1 Touch **Front Focus** on the Position/DTA screen.


- 2 Select a front focus position.

For **Front All** and **All**, select Priority L or R depending on which side you want to put the imaginary sound image.



Front Focus fine adjustment

- 1 Touch **Adjust**.
- 2 Touch **Delay**.
- 3 Set each parameter as follows.



■ Sound Image LR (Front)

Focus the sound image on the front of front seats.

■ Sound Image LR (Rear)


Focus the sound image on the front of rear seats.

■ Size of the Virtual Sound Field

Adjust the size of sound image to meet your taste. If the sound image is shifted from the front, move it back by **Sound Image LR (Front)** or **Sound Image LR (Rear)**.

- 4 Touch **Level**.

- 5 Touch **<** or **>** to adjust the sound level of the selected speaker.



NOTE

- To initialize the Delay and Level settings, touch **Initialize** and **Yes** on the confirmation screen.

Steering Wheel Control

This unit can be operated using the switches on the steering wheel.

NOTE

- Steering wheel control function is varied depends on vehicle and vehicle grade.

Operations using the steering switch

Key Name	Press	Press and Hold
	Volume up	Volume up continuously
	Volume down	Volume down continuously
MODE	Switch sources	Mute ON/OFF
	Select preset radio stations Select next track, file, chapter	Seek radio stations Forward Search
	Select preset radio stations Select previous track, file, chapter	Seek radio stations Reverse Search
	Receive an incoming call Make a phone call	Decline, refuse an incoming call End a phone call
	Decline, refuse an incoming call End a phone call	
VOICE	Start smartphone's Voice Recognition (Smartphone dependent)	End smartphone's Voice Recognition

Remote control

This unit can be operated using the remote control.

▲ WARNING

- Do not ingest the battery, Chemical Burn Hazard
The remote control supplied with this product contains a coin / button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Put the remote control in a place where it will not move during braking or other operations. A dangerous situation could result, if the remote control falls down and gets wedged under the pedals while driving.

▲ CAUTION

- Do not leave the battery near fire or under direct sunlight. A fire, explosion or excessive heat generation may result.
- Do not recharge, short, break up or heat the battery or place it in an open fire. Such actions may cause the battery to leak fluid. If spilled fluid comes in contact with your eyes or on clothing, immediately rinse with water and consult a physician.
- Danger of explosion if Lithium battery is incorrectly replaced. Replace only with the same or equivalent type.
- Remove the battery if the remote control is not used for a month or longer.
- When disposing of used batteries, comply with governmental regulations or environmental public institutions' rules that apply in your country/area.

Using the Remote control

Point the remote control in the direction of the front panel to operate.


- The remote control may not function properly in direct sunlight.

IMPORTANT

- Do not store the remote control in high temperatures or direct sunlight.
- Do not let the remote control fall onto the floor, where it may become jammed under the brake or accelerator pedal.

■ Removing the battery sheet

Pull the battery sheet out from the remote controller to activate the battery.




■ Changing the battery of the remote controller



- Use a commercially available button battery (CR2025).
- Insert the battery with the + and – poles aligned properly.
 - If the effectiveness of the remote controller decreases, replace the battery.

Functions of the Remote control Buttons



Key Name	Function
MODE	<ul style="list-style-type: none"> • Selects the source. (Press) • Turns off the power. (Hold)
VOL ^ v	Adjusts the volume.
ASPECT	Changes the aspect ratio. <ul style="list-style-type: none"> • To confirm the current aspect ratio setting, operate on the touch panel. (P.44)
MUTE	Lowers the volume when pressed once. Restores the previous volume when pressed twice.
▲ ▼	Selects the folder to be played. For the DVD/Video-CD source, selects the title to be played.
⏪ ⏩	Selects the track or file to be played. For the Radio source, switches to broadcast stations received by the unit. For the DVD/Video-CD source, selects the chapter/scene/track to be played.
ENT ▶	<ul style="list-style-type: none"> • Starts/pauses playback. • Performs the selected function.
DIRECT	Switches to the direct search mode. For details on the direct search mode, see Direct search mode (P.58) .
VOICE	Activates the voice control.
AM FM	Selects FM/ AM band to be received.
Numeric Keypad	1 - 6 : Enters preset station number. Allows you to enter the number to search in the direct search mode. For details on the direct search mode, see Direct search mode (P.58) .
☎	Displays the Hands Free screen. (P.21) When a call comes in, answers the call.
☎	Ends/rejects the call.

Direct search mode

Using the remote control, you can jump directly to the desired file, track chapter, etc. by entering the number corresponding to the content.

NOTE

- This operation cannot be performed for the USB device and iPod.

- 1 Press the **MODE** button several times until the desired source appears.**
- 2 Press the **DIRECT** button to select the content.**

The available contents are different depending on the source type.

 - **DVD**
Title number/Chapter number
 - **Video-CD 1.X and 2.X (PBC OFF)**
Track number
 - **Video-CD 2.X (PBC ON)**
Scene number/Track number
 - **Music CD**
Track number
 - **Radio**
Frequency value
- 3 Enter the number of the content you want to play using the numeric keypad.**
- 4 For DVD or Video-CD, music CD, press the **ENT** button.**

For Radio, press the **◀◀** or **▶▶** button.

 - The content corresponding to the number you entered is played.

Troubleshooting

Problems and Solutions

If you have problems operating this product, refer to this section. The most common problems are listed below, along with likely causes and solutions. If a solution to your problem cannot be found here, contact your dealer or your nearest Toyota Service Center.

NOTE

- Some functions of this unit may be disabled by some settings made on this unit.
- What might seem to be a malfunction in your unit may just be the result of slight misoperation.

About settings

- **Cannot select the output destination of the subsource in the dual zone.**
- **Cannot adjust the volume of the rear speakers.**
The dual zone function is disabled.
 - Set the dual zone function to on. See **Dual Zone Systems (P.48)**.

Cannot set up the equalizer.

- The dual zone function is enabled.
- Set the dual zone function to off. See **Dual Zone Systems (P.48)**.

About audio operations

Cannot select a folder.

- The random play function is enabled.
- Turn off the random function.

Cannot perform repeat play during Video-CD playback.

- The PBC function is enabled.
- Turn off the PBC function.

The specified disc does not play, but another one plays instead.

- The disc is quite dirty.
- Clean the disc. See **Precautions on handling discs (P.5)**.
- The disc is severely scratched.
- Try another disc instead.

The sound skips when an audio file is being played.

- The disc is scratched or dirty.
- Clean the disc. See **Precautions on handling discs (P.5)**.
- The recording condition is bad.
- Record the file again or use another disc.

T-Link does not sound.

- Verify that the T-Link installed device is selected in Bluetooth connection setup.
 - Raise the volume on your smartphone.
 - Try another music application. Some application does not support T-Link playback.
- (Apple Music App does not support to playback during T-Link.)

iPod or Bluetooth source does not sound.

- If you used T-Link source before, verify that the iPhone's screen recording function is stopped.

Cannot operate T-Link with touch panel operation.

- Available operation functions may differ from the ones operated on the device. Some functions do not work by operation on this unit depending on the connected device.

Error Messages

When you fail to operate the unit correctly, the cause of the failure appears as the message on the screen.

There is an error in the speaker wiring. Please check the connections.

- Protective circuit has been activated because a speaker cord has shorted or it has come in contact with the car chassis.
- Wire or insulate the speaker cord as appropriate and turn the power off and on again.

Hot Error

- When the internal temperature of this unit rises to 60°C or more, the protection circuit is activated and you may not be able to operate the unit.
- Use the unit again after reducing the temperature of the unit.

Mecha Error

- The disc player is malfunctioning.
- Eject the disc and try inserting it again.

Disc Error

- An unplayable disc is inserted.
- Change the disc. See **Playable Media and Files (P.61)**.

Read Error

- The disc is quite dirty.
- Clean the disc. See **Precautions on handling discs (P.5)**.
- Disc is upside down.
- Load the disc with the labeled side up.

Troubleshooting

Region Code Error

The disc you wanted to play has a region code that cannot be played with this unit.

- See **Region Codes in the World (P.63)** or try another disc.
-

Error 07–67

The unit is not operating correctly due to some reason or other.

- Turn the power off and on again.
-

No Device (USB device)

The USB device is selected as a source although no USB device is connected.

- Change the source to any source other than USB/iPod. Connect a USB device, and change the source to USB again.
-

Disconnected (iPod, Bluetooth audio player)

The iPod/Bluetooth audio player is selected as a source although no iPod/Bluetooth audio player is connected.

- Change the source to any source other than iPod/Bluetooth Audio. Connect an iPod/Bluetooth audio player, and change the source to iPod/Bluetooth again.
-

No Media file

The connected USB device contains no playable audio file. Media was played that doesn't have data recorded that the unit can play.

- See **Playable Media and Files (P.61)** and try another USB device.
-

USB device over current status detected.

The connected USB device is rated a current capacity higher than the allowable limit.

- Check the USB device. Some trouble may have occurred to the connected USB device.
- Change the source to any source other than USB. Remove the USB device.

Appendix

Playable Media and Files

You can play various kinds of media and files on this unit.

List of playable discs

Disc types / Standard		Support	Remark
DVD	DVD Video	○	
	DVD Audio	×	
	DVD-VR	×	
	DVD-R*1	○	<ul style="list-style-type: none"> • MP3/ WMA/ AAC/ WAV/ FLAC/ Vorbis/ MPEG1/ MPEG2/ MPEG4/ H.264/ WMV/ MKV playback • Multi-border/Multisession playback (Playback depends on authoring conditions)
	DVD-RW	○	
	DVD+R	○	
	DVD+RW	○	
	DVD-R DL (Dual layer)	○	Only video format
	DVD+R DL (Double layer)	○	
DVD-RAM	×		
CD	Music CD*1	○	
	CD-ROM	○	<ul style="list-style-type: none"> • MP3/ WMA/ AAC/ WAV/ FLAC/ Vorbis playback • Multisession is supported. • Packet write is not supported.
	CD-R	○	
	CD-RW	○	
	DTS-CD	×	
	Video CD (VCD)	○	
	Super video CD	×	
	Photo CD	×	
	CD-EXTRA	△	Only music CD session can be played.
	HDCD	△	Normal music CD sound quality
	CCCD	×	
Others	Dualdisc	×	
	Super audio CD	△	Only CD layer can be played.

○ : Playback is possible.

△ : Playback is partly possible.

× : Playback is impossible.

*1 Incompatible with 8 cm (3 inch) discs.

Use of DualDisc

When playing a "DualDisc" on this unit, the surface of the disc that is not played may be scratched while the disc is inserted or ejected. Since the music CD surface does not conform to the CD standard, playback may be impossible.

(A "DualDisc" is a disc with one surface containing DVD standard signals and the other surface containing music CD signals.)

About disc format

The disc format should be the one of the following.

- ISO 9660 Level 1/2
- Joliet
- Romeo
- Long file name

About files

The following audio and video files are supported.

Playable Audio files

	Format	Bit rate	Sampling frequency	Bit count
AAC-LC (.m4a)	MPEG2/4 AAC LC HE-AAC(V1,V2)	8 – 320kbps, VBR	16 – 48 kHz	16 bit
MP3 (.mp3)	MPEG 1/2 Audio Layer 3	8 – 320kbps, VBR	16 – 48 kHz	16 bit
WMA (.wma)	Windows Media Audio Standard L3 profile (Version 7,8,9)	8 – 320kbps	16 – 48 kHz	16 bit
Linear PCM (WAVE) (.wav)	RIFF waveform Audio Format	–	16 – 48 kHz (Disc), 16 – 192 kHz (USB)	16/ 24 bit
FLAC (.flac)	flac	–	16 – 48 kHz (Disc), 16 – 192 kHz (USB)	16/ 24 bit
Vorbis (.ogg)	vorbis	VBR	16 – 48 kHz	16 bit
DSD (.dsf, .dff)*	DSF, DSDIFF	–	2.8 MHz, 5.6 MHz, 11.2 MHz	1 bit

- If music of normal CD and other playback systems are recorded in the same disc, only the playback system recorded at the first setout is played.
- WMA and AAC files with DRM cannot be played.
- DSD sound is converted to PCM sound before playback.
- The EmChinks tag of DSDIFF is not supported.
- Although the audio files complies with the standards listed above, they may not be played depending on the types or conditions of media or device.
- This unit supports playback of High-Resolution Audio files.
It is recommended that a car audio system should be configured with all High-Resolution Audio compatible products from player to speaker to enjoy its high quality sound.

* DSD is available for Premium AVX only.

Acceptable Video files

	Profile	Max. Picture size	Max. bit rate	Audio format
MPEG-1 (.mpg, .mpeg)	–	352 × 240, 352 × 288	1.5 Mbps	MPEG Audio Layer 2
MPEG-2 (.mpg, .mpeg)	MP@ML	720 × 480, 720 × 576	8 Mbps	MPEG Audio Layer 2
H.264/MPEG-4 AVC (.mp4, .m4v, .avi, .flv, .f4v)	Baseline Profile, Main Profile	1920 × 1080 (30 fps)	8 Mbps	MP3, AAC
MPEG-4 (.mp4, .avi)	Advanced Simple Profile	1920 × 1080 (30 fps)	8 Mbps	MP3, AAC
WMV (.wmv)	Main Profile	1920 × 1080 (30 fps)	8 Mbps	WMA
MKV (.mkv)	Video format follows H.264/MPEG-4 AVC, MPEG-4, WMV			MP3, AAC, WMA, Vorbis, FLAC

- This unit can only play back files which are smaller than 4 GB.


Limitation on structure of file and folder

	Disc media	USB device
Maximum number of folder layers	8	8
Maximum number of files (per folder)	999	999
Maximum number of folders (per folder)	5000	9999
Maximum number of folders (per device)	5000	Unlimited

- You can enter a folder name and file name with 255 or fewer single-byte characters.
- Files in the folder whose folder name begins with a dot (.) cannot be played.

Region Codes in the World

The DVD players are given a region code according to the country or area it is marketed, as shown in the following map.



■ DVD disc marks



Indicates a region number. The discs with this mark can be played with any DVD player.



Indicates the number of audio languages recorded. Up to 8 languages can be recorded in a movie. You can select a favorite language.



Indicates the number of subtitled languages recorded. Up to 32 languages can be recorded.



If a DVD disc has scenes shot from multiple angles, you can select a favorite angle.



Indicates the type of screen for the image. The left mark indicates that a wide image picture (16:9) is displayed on a standard TV set screen (4:3) with a black band at both the top and bottom of the screen (letter box).

■ Operation regulatory marks

With this DVD, some functions of this unit such as the play function may be restricted depending on the location where the DVD is playing. In this case, the following marks will appear on the screen. For more information, refer to the disc manual.



■ Discs with limited period of use

Do not leave discs with a limited period of use in this unit. If you load an already expired disc, you may not be able to remove it from this unit.

DVD Language Codes

Code	Language
aa	Afar
ab	Abkhazian
af	Afrikaans
am	Amharic
ar	Arabic
as	Assamese
ay	Aymara
az	Azerbaijani
ba	Bashkir
be	Byelorussian
bg	Bulgarian
bh	Bihari
bi	Bislama
bn	Bengali, Bangla
bo	Tibetan
br	Breton
ca	Catalan
co	Corsican
cs	Czech
cy	Welsh
da	Danish
de	German
dz	Bhutani
el	Greek
en	English
eo	Esperanto
es	Spanish
et	Estonian
eu	Basque
fa	Persian
fi	Finnish
fj	Fiji
fo	Faroese
fr	French
fy	Frisian
ga	Irish
gd	Scots Gaelic
gl	Galician
gn	Guarani
gu	Gujarati
ha	Hausa
he	Hebrew
hi	Hindi
hr	Croatian
hu	Hungarian
hy	Armenian

Code	Language
ia	Interlingua
ie	Interlingue
ik	Inupiak
id	Indonesian
is	Icelandic
it	Italian
ja	Japanese
jv	Javanese
ka	Georgian
kk	Kazakh
kl	Greenlandic
km	Cambodian
kn	Kannada
ko	Korean
ks	Kashmiri
ku	Kurdish
ky	Kirghiz
la	Latin
lb	Luxembourgish
ln	Lingala
lo	Laotian
lt	Lithuanian
lv	Latvian, Lettish
mg	Malagasy
mi	Maori
mk	Macedonian
ml	Malayalam
mn	Mongolian
mo	Moldavian
mr	Marathi
ms	Malay
mt	Maltese
my	Burmese
na	Nauru
ne	Nepali
nl	Dutch
no	Norwegian
oc	Occitan
om	(Afan) Oromo
or	Oriya
pa	Punjabi
pl	Polish
ps	Pashto, Pushto
pt	Portuguese
qu	Quechua
rm	Rhaeto-Romance

Code	Language
rn	Kirundi
ro	Romanian
ru	Russian
rw	Kinyarwanda
sa	Sanskrit
sd	Sindhi
sg	Sangho
sh	Serbo-Croatian
si	Singhalese
sk	Slovak
sl	Slovenian
sm	Samoan
sn	Shona
so	Somali
sq	Albanian
sr	Serbian
ss	Siswati
st	Sesotho
su	Sundanese
sv	Swedish
sw	Swahili
ta	Tamil
te	Telugu
tg	Tajik
th	Thai
ti	Tigrinya
tk	Turkmen
tl	Tagalog
tn	Setswana
to	Tongan
tr	Turkish
ts	Tsonga
tt	Tatar
tw	Twi
uk	Ukrainian
ur	Urdu
uz	Uzbek
vi	Vietnamese
vo	Volapuk
wo	Wolof
xh	Xhosa
yo	Yoruba
zh	Chinese
zu	Zulu

Specifications

■ Monitor section

Picture Size

- : 6.8 inches (diagonal) wide
- : 151.8 mm (W) × 79.68 mm (H)

Display System

- : TN LCD panel

Drive System

- : TFT active matrix system

Number of Pixels

- : 1,152,000 (800H x 480V x RGB)

Effective Pixels

- : 99.99 %

Pixel Arrangement

- : RGB striped arrangement

Back Lighting

- : LED

■ DVD player section

D/A Converter

- : 24/ 32 bit

Audio Decoder

- : Linear PCM/ Dolby Audio/ MP3/ WMA/ AAC/ WAV/ FLAC/ Vorbis

Video Decoder

- : MPEG1/ MPEG2/ MPEG4/ WMV/ H.264/ MKV

Wow & Flutter

- : Below Measurable Limit

Frequency Response

- 96 kHz : 20 – 44,000 Hz
- 48 kHz : 20 – 22,000 Hz
- 44.1 kHz : 20 – 20,000 Hz

Total Harmonic Distortion

- : 0.030 % (1 kHz)

S/N Ratio (dB)

- : 75 dB

Dynamic Range

- : 75 dB

Disc Format

- : DVD-Video/ VIDEO-CD/ CD-DA/ DVD-R/DVD-RW/ DVD+R/+RW

Quantifying Bit Number

- : 16/ 20/ 24 bit

■ USB interface section

USB Standard

- : USB 2.0 High Speed

File System

- : FAT 16/ 32, exFAT, NTFS

Maximum Power Supply Current

- : DC 5 V  1.0 A × 1

D/A Converter

- : 24/ 32 bit

Audio Decoder

- : MP3/ WMA/ AAC/ WAV/ FLAC/ Vorbis/ DSD*
- * DSD is available for Premium AVX only.

Video Decoder

- : MPEG1/ MPEG2/ MPEG4/ WMV/ H.264/ MKV

■ Bluetooth section

Technology

- : Bluetooth Ver.4.1

Frequency

- : 2.402 – 2.480 GHz

Output Power

- : +4dBm (MAX), 0dBm (AVE), Power Class2

Maximum Communication range

- : Line of sight approx. 10m (32.8 ft)

Audio Codec

- : SBC/ AAC

Profile (Multi Profile support)

- HFP (V1.7) (Hands Free Profile)
- SPP (Serial Port Profile)
- A2DP (Advanced Audio Distribution Profile)
- AVRCP (V1.6) (Audio/Video Remote Control Profile)
- PBAP (Phonebook Access Profile)

■ FM tuner section

Frequency Range (step)

- : 87.5 MHz – 108.0 MHz (50 kHz)

Usable Sensitivity (S/N : 30 dB)

- : 9.3 dBf (0.8 μV/ 75 Ω)

Quieting Sensitivity (S/N : 46 dB)

- : 15.2 dBf (1.6 μV/ 75 Ω)

Frequency Response

- : 30 Hz – 15 kHz

S/N Ratio (dB)

- : 60 dB (MONO)

Selectivity (± 400 kHz)

- : Over 80 dB

Stereo Separation

- : 45 dB (1 kHz)

Appendix

■ AM tuner section

Frequency Range (step)

: 531 kHz – 1602 kHz (9 kHz)

Usable Sensitivity

: 28 dB μ (25 μ V)

■ Video section

Color System of External Video Input

: NTSC

External Audio Max Input Level (mini jack)

: 2 V / 25 k Ω

Video Output Level

: 1 Vp-p / 75 Ω

■ Audio section

Maximum Power (Front & Rear)

: 50 W \times 4

Typical Power Output (Front & Rear)

Full Bandwidth Power (at less than 10% THD)

: 20 W \times 4

Output frequency band

: 20 – 88,000 Hz

Speaker Impedance

: 4 – 8 Ω

Graphics equalizer

Band: 13 Band

Frequency (BAND1 – 13)

: 62.5/ 100/ 160/ 250/ 400/ 630/ 1k/ 1.6k/ 2.5k/ 4k/

6.3k/ 10k/ 16k Hz

Gain

: -9/-8/-7/-6/-5/-4/-3/-2/-1/0/1/2/3/4/5/6/7/8/9 dB

■ General

Operating Voltage

: 14.4 V (10.5 – 16 V allowable)

Maximum Current Consumption

: 15 A

Dimensions (W \times H \times D)

: 205 \times 104 \times 163.6 mm

Weight

: 2.1 kg

NOTE

- Although the effective pixels for the liquid crystal panel is given as 99.99% or more, 0.01% of pixels may not light or may light incorrectly.

Specifications are subject to change without prior notice.

About this Unit

■ Trademarks and licenses



- The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by JVC KENWOOD Corporation is under license. Other trademarks and trade names are those of their respective owners.
- Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories.
-  is a trademark of DVD Format/Logo Licensing Corporation registered in the U.S., Japan and other countries.
- This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.
- Microsoft and Windows Media are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- This software is based in part on the work of the independent JPEG Group.
- The "AAC" logo is a trademark of Dolby Laboratories.
- Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with an Apple product may affect wireless performance.
- Apple, iPhone, iPod, iPod touch, iTunes, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.
- Android, Google Play and other marks are trademarks of Google LLC.

- This product includes FontAvenue® fonts licenced by NEC Corporation. FontAvenue is a registered trademark of NEC Corporation.



- This product includes "Ubiquitous QuickBoot™" technology developed by Ubiquitous Corp. Ubiquitous QuickBoot™ is a trademark of Ubiquitous Corp. Copyright© 2017 Ubiquitous Corp. All rights reserved.



- THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)
- THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (i) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, LLC. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com).
- THIS PRODUCT IS LICENSED UNDER THE VC-1 PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE VC-1 STANDARD ("VC-1 VIDEO") AND/OR (ii) DECODE VC-1 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE VC-1 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)
- libFLAC
Copyright (C) 2000-2009 Josh Coalson
Copyright (C) 2011-2013 Xiph.Org Foundation
Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Appendix

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

- libvorbis

Copyright (c) 2002-2008 Xiph.org Foundation
Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,

WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

- libogg

Copyright (c) 2002, Xiph.org Foundation
Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

■ The marking of products using lasers

**CLASS 1
LASER PRODUCT**

The label is attached to the chassis/case and says that the component uses laser beams that have been classified as Class 1. It means that the unit is utilizing laser beams that are of a weaker class. There is no danger of hazardous radiation outside the unit.

■ FCC WARNING

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

NOTE

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
- This equipment generates, used and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.



Declaration of Conformity with regard to the RE Directive 2014/53/EU

Declaration of Conformity with regard to the RoHS Directive 2011/65/EU

Manufacturer:

JVC KENWOOD Corporation
3-12, Moriyacho, Kanagawa-ku, Yokohama-shi,
Kanagawa 221-0022, JAPAN

EU Representative:

JVCKENWOOD Europe B.V.
Amsterdamseweg 37, 1422 AC UITHOORN, THE
NETHERLANDS

English

Hereby, JVC KENWOOD declares that the radio equipment DDXGT700R/DDXGT500R is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

Français

Par la présente, JVC KENWOOD déclare que l'équipement radio DDXGT700R/ DDXGT500R est conforme à la directive 2014/53/UE. L'intégralité de la déclaration de conformité UE est disponible à l'adresse Internet suivante :

Español

Por la presente, JVC KENWOOD declara que el equipo de radio DDXGT700R/ DDXGT500R cumple la Directiva 2014/53/EU. El texto completo de la declaración de conformidad con la UE está disponible en la siguiente dirección de internet:

Português

Deste modo, a JVC KENWOOD declara que o equipamento de rádio DDXGT700R/ DDXGT500R está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade da UE está disponível no seguinte endereço de internet:

URL: <http://www.kenwood.com/cs/ce/eudoc/>

For further information

Please check the below special website for further information.
<https://19cy.jvckenwood.com>



NOTICE TO OWNER

Please retain this booklet and write the serial number of this product for identification and accurate reporting to your local police in the event of theft.

● **How to confirm the serial number of this unit.**

- ① Press  button.
- ② Touch .
- ③ Touch **General**.
- ④ Touch **Software Information**.
- ⑤ Confirm the Serial Number.

Serial Number _____

Manufacturer Model Name

Premium AVX

DDXGT700R

Basic AVX

DDXGT500R

ENGLISH

Additional Copyrights

- Apple, iPhone, iPod, iPod touch, iTunes, Apple Music, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.
- App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
- Waze is a trademark of Google LLC.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- SPOTIFY and the Spotify logo are among the registered trademark of Spotify AB.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.

INDONESIA

Hak Cipta Tambahan

- Apple, iPhone, iPod, iPod touch, iTunes, Apple Music, dan Lightning adalah merek dagang dari Apple Inc., terdaftar di AS dan di negara lain.
- App Store adalah merek layanan dari Apple Inc., yang terdaftar di A.S. dan negara lainnya.
- Waze adalah merek dagang dari Google LLC.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- SPOTIFY and the Spotify logo are among the registered trademark of Spotify AB.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.

MALAY

Lampiran Hak Cipta Tambahan

- Apple, iPhone, iPod, iPod touch, iTunes, Apple Music dan Lightning adalah tanda dagangan Apple Inc., yang didaftarkan di A.S. dan negara-negara lain.
- App Store ialah tanda perkhidmatan Apple Inc., didaftarkan di A.S. dan negara lain.
- Waze ialah tanda dagangan Google LLC.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

- SPOTIFY and the Spotify logo are among the registered trademark of Spotify AB.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.

ภาษาไทย

ลิขสิทธิ์เพิ่มเติม

- **Apple, iPhone, iPod, iPod touch, iTunes, Apple Music และ Lightning** เป็นเครื่องหมายการค้าของ **Apple Inc.**, ซึ่งจดทะเบียนในประเทศสหรัฐอเมริกา และประเทศอื่นๆ
- **App Store** เป็นเครื่องหมายบริการของ **Apple Inc.** ซึ่งจดทะเบียนในสหรัฐอเมริกาและในประเทศอื่นๆ
- **Waze** เป็นเครื่องหมายการค้าของ **Google LLC**
- **IOS** is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- **SPOTIFY and the Spotify logo** are among the registered trademark of **Spotify AB**.
- **Linux®** is the registered trademark of **Linus Torvalds** in the U.S. and other countries.
- **Wi-Fi®** is a registered trademark of **Wi-Fi Alliance®**.

TIẾNG VIỆT

Bản Quyền Bổ Sung

- **Apple, iPhone, iPod, iPod touch, iTunes, Apple Music, và Lightning** là thương hiệu của **Apple Inc.**, được đăng ký ở Hoa Kỳ và các nước khác.
- **App Store** là nhãn hiệu dịch vụ của **Apple Inc.**, được đăng ký tại Mỹ và các quốc gia khác.
- **Waze** là một nhãn hiệu của **Google LLC**.
- **IOS** is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- **SPOTIFY and the Spotify logo** are among the registered trademark of **Spotify AB**.
- **Linux®** is the registered trademark of **Linus Torvalds** in the U.S. and other countries.
- **Wi-Fi®** is a registered trademark of **Wi-Fi Alliance®**.

中文

著作權聲明

- Apple , iPhone , iPod , iPod touch , iTunes , Apple Music 和 Lightning 是 Apple Inc. 在美國或其他國家冊的商標。
- App Store 是 Apple Inc. 在美國及其他國家或地區註冊的服務商標。
- Waze 是 Google LLC 的商標。
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- SPOTIFY and the Spotify logo are among the registered trademark of Spotify AB.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.

العربية

حقوق طبع محفوظة اضافية

- تُعدُ iTunes و iPod touch و iPod و iPhone و Apple Music و Lightning علامات تجارية مسجلة لشركة Apple Inc. المسجلة في الولايات المتحدة ودول أخرى.
- تُعدُ App Store علامة تجارية لشركة Apple Inc. مسجلة في الولايات المتحدة ودول أخرى.
- Waze هي علامة تجارية لشركة Google LLC.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- SPOTIFY and the Spotify logo are among the registered trademark of Spotify AB.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.

PORTUGUÊS

Direitos Autorais Adicionais

- Apple, iPhone, iPod, iPod touch, iTunes, Apple Music e Lightning são marcas registradas da Apple Inc., registradas nos EUA e em outros países.
- App Store é uma marca de serviço da Apple Inc., registrada nos EUA e em outros países.
- Waze é uma marca registrada da Google LLC.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

- SPOTIFY and the Spotify logo are among the registered trademark of Spotify AB.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.

ESPAÑOL

Derechos de Autor adicionales

- Apple, iPhone, iPod, iPod touch, iTunes, Apple Music y Lightning son marcas comerciales de Apple Inc., registradas en los EE. UU. y en otros países.
- App Store es una marca de servicio de Apple Inc., registrada(s) en EE UU y en otros países.
- Waze es una marca comercial de Google LLC.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- SPOTIFY and the Spotify logo are among the registered trademark of Spotify AB.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.

FRANÇAIS

Droits d'auteurs additionnels

- Apple, iPhone, iPod, iPod touch, iTunes, Apple Music et Lightning sont des marques commerciales d'Apple Inc., déposées aux États-Unis et dans d'autres pays.
- App Store est une marque de service d'Apple Inc. déposée aux États-Unis et dans d'autres pays.
- Waze est une marque de Google LLC.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- SPOTIFY and the Spotify logo are among the registered trademark of Spotify AB.
- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.