



# USER MANUAL



[WWW.TRITONKEYMACHINE.COM](http://WWW.TRITONKEYMACHINE.COM)



## PLEASE FOLLOW THESE INSTRUCTIONS WHEN USING YOUR TRITON PLUS™ KEY CUTTER:

- 1** The equipment is designed to be operated at DC24V. The machine will only operate normally at 24VDC. Low/high voltage can harm the machine motor.
- 2** The cutter should be replaced on a regular basis. Delayed replacement or using a dull cutting bit can lead to inaccurate key cutting.
- 3** The cutting accuracy of the machine depends on the material type of the key blank. Select correct speed and cutting times to cut hardened key blanks.
- 4** Be sure to mount the machine on a solid secure surface. Clean the machine with a brush only. Prevent any kind of water intrusion when cleaning.
- 5** Make sure to enter correct key data and input correct key bitting number.
- 6** When using a voltage inverter to run the machine off a vehicle, always leave the vehicle running when using the machine.





# CONTENTS

---







	<b>PAGE</b>
<b>Safety.....</b>	<b>4</b>
Power Safety.....	4
Installation Safety .....	4
Usage Safety.....	5
Additional Safety Notes.....	5
<b>Part Names.....</b>	<b>8-9</b>
<b>Power Adapter .....</b>	<b>10</b>
<b>Specifications.....</b>	<b>11</b>
<b>Consumable Items .....</b>	<b>12-13</b>
Cutter.....	12
Decoder.....	13
<b>Key Clamping.....</b>	<b>14-17</b>
<b>Jaw Instructions .....</b>	<b>18</b>
S1 Jaw .....	15
S2 Jaw .....	16
S3 Jaw .....	16
S4 Jaw .....	17
<b>Standard Menu .....</b>	<b>19-21</b>
<b>Jaw Calibration.....</b>	<b>22-29</b>
<b>Search .....</b>	<b>30-31</b>
Key Blank Search .....	30
IC Card Search .....	31
<b>Settings Menu .....</b>	<b>32-36</b>
Language .....	32
Software Upgrade.....	33
Cutting Speed .....	34-35
About Us.....	36
<b>Key Decoding.....</b>	<b>37</b>
<b>Key Cutting.....</b>	<b>38-39</b>
<b>Cutting Depth Adjustment .....</b>	<b>40-41</b>
<b>Layered Cutting .....</b>	<b>42-43</b>
<b>Move .....</b>	<b>44-45</b>
<b>Code .....</b>	<b>46-47</b>
<b>Progression .....</b>	<b>48-49</b>
<b>Duplicate.....</b>	<b>50-55</b>
Single Standard Key.....	50
Double Standard Key.....	51
Single External Groove Key .....	52
Double External Groove Key.....	53
Internal Groove .....	54
Tubular Key .....	55
<b>Custom Keys.....</b>	<b>56-71</b>
<b>Favorites .....</b>	<b>72</b>
<b>Cut History .....</b>	<b>72</b>
<b>Wifi Connection .....</b>	<b>73</b>
<b>Software Activation .....</b>	<b>74</b>
<b>Warranty .....</b>	<b>75</b>

## SAFETY




### Safety Instructions

-  1 Make sure to observe the following for using the equipment safely;
  -  2 The information below is provided to enhance the user security awareness and prevent property loss. Read the safety precautions carefully for correct use.
-  Indicates that you could be injured or damage the equipment if you fail to follow the instructions.
-  Indicates that you can be seriously injured if you fail to follow the instructions.





### Power Safety

-  Never use damaged power cords or loose plugs/ sockets.
-  Do not overload power plugs. Only use outlets rated for the machine load.
-  Never pull out the plug by tugging the power cord. Remove plug from socket by pulling directly on plug.
-  Keep the equipment unplugged when not in use.
-  If the machine makes any unusual noise when in use, turn off immediately and disconnect the power right away. Then contact your dealer or our factory for advice.
-  If you are using the machine with an inverter, a 10 amp fuse is required. The vehicle should be running while the machine is in use




### Installation Safety

-  Do not install the equipment in a place with oil, dirt, moisture, dust or water intrusion as it may cause electric shock or fire.
-  Do not install near any heat source. This may cause machine overheating and failure.
-  Make sure to install the equipment on stable flat surface. The equipment weighs 35 lbs and generates minor vibration during operation. if you use the equipment on rough surface, it may lead to damage to equipment/worktable.

## Usage Safety

-  The machine cutting bit spins at high speed during operation. Keep your body, clothing and loose items away from the equipment when in use to prevent injury.
-  Keep cutting vise and machining area clear at all times. Do not place any objects in this area.
-  Placing foreign objects in the cutting area must be avoided to prevent potential injury to machine operator.
-  Overheating or incorrect voltage may lead to fire or equipment failure. Water intrusion could lead to electrical shock.

## Additional Safety Notes


-  Do not disassemble or modify the equipment. It may cause fire, electric shock and equipment failure. If you need a check-up, adjustment or repair of the equipment, please contact your dealer for repairs.
-  Keep children away from the equipment. This machine is designed for adult operation only.
-  In winter (sub-zero temperatures), the equipment will not work properly. Increase the temperature of working environment to 32 F or above for proper operation.

## Part Names



## Part Names

*Amlrglscb*



### ! ATTENTION

- Avoid touching screen with sharp objects, it is easily damaged.
- Decoder is a consumable item, replace when damaged.
- Handle decoder with care to avoid damaging.
- Triton™ is not responsible for decoder damage in any case.


## Power Adapter

### Accessories/Components for Power




**Power Switch**

**Turn On (Twist Clockwise)**




**Turn Off (Press)**



**Connect the power adapter. Rotate switch clockwise to turn on the equipment. Depress switch to turn off the equipment.**



**Equipment Specifications**

Power Input	
Voltage	DC24V/5A
Power	120W
Size	305(W) x 300(H) x 400(D)mm
Weight	35.3 lbs
Accuracy	XY Axis:0.0025mm Z Axis:0.0025mm
Spindle Speed	12000+rpm
Working Temperature Range	0-104°F
Working Humidity Range	10-90%
Usage	To cut automobile keys, residential keys, motorcycle keys, dimple keys, tubular keys, FO21 tibbe keys.


## Consumables

### Cutter

#### 1.1 Installation

#### 1.2 Disassembly


##### 1.1 Installation



#### Steps for Cutter Installation:

1. Insert the cutter into the cutter holder and push it all the way in until it stops.
2. Tighten M5 screw tightly by turning 2.5mm T-wrench clockwise.

##### 1.2 Disassembly



#### Steps for Cutter Disassembly:

1. Hold the cutter and loosen M5 screw by turning 2.5mm T-wrench counterclockwise.
2. Remove the cutter.

## Consumables

(continued...)

### Decoder

#### 2.1 Installation

#### 2.2 Disassembly

#### 2.1 Installation



#### Steps for Decoder Installation:

1. Insert the decoder into the cutter holder and push it in until it stops.
2. Tighten M5 screw tightly by turning 2.5mm T-wrench clockwise.

#### 2.2 Disassembly





#### Steps for Decoder Disassembly:

1. Hold the decoder and loosen M5 screw by turning 2.5mm T-wrench counterclockwise.
2. Remove the decoder.

## Key Clamping

### Standard Key



Install standard key at the top of the jaw



**Shoulder Align**


### Laser Key

Install laser key at the bottom of the jaw



### Standard Key

Install standard key at the top of the jaw



**Tip Align**

### Laser Key

Install laser key at the bottom of the jaw




## Key Clamping

(continued...)



***Please avoid the mistakes below when clamping keys:***



**S1 Jaw - Standard Key**



**S1 Jaw - Laser Key**





## Key Clamping



*Please avoid the mistakes below when clamping keys:*



**S2 Jaw - Single Standard Key**



**S3 Jaw - Tubular Key**





## Key Clamping

(continued...)

*Please avoid the mistakes below when clamping keys:*




**S4 Jaw - Available for Ford/Jaguar F021 Tibbe keys**



## Jaw Instructions


S1 Jaw



### Available for

Double standard keys, Single internal groove keys, Single external groove keys, Double internal groove keys, Double external groove keys, Dimple keys.


S2 Jaw



### Available for

Single standard keys.


S3 Jaw



### Available for

Tubular keys.

S4 Jaw


















### Available for

Ford F021 Tibbe (6 cuts) and Jaguar F021 Tibbe (8 cuts) keys




## Standard Menu











	Automobile		Motorcycle
	Tubular		Single Standard
	Dimple		Jaw Calibration
	Duplicate		Cut History
	Favorites		Custom Keys
	Menu		Support
	Message		Search

## Standard Menu

&amlrglscb,,,'










	Input biting numbers		Jaw Move
	Get biting numbers by key code		Input existing biting numbers to get unknown biting number
	Decode key		Cut key
	Show basic information		Collect common keys

# Standard Menu


(continued...)



Cutter				
		Please insert the cutter shown as picture.		
		You can manually set the cutting depth when cutting laser keys.		
Cutting depth				
		When cutting laser keys, you can choose 1,2 or 3 cuts to finish the cutting depth. The harder the key blank is, the more cuts that will be needed		
		When cutting laser keys, you can choose 1,2 or 3 cuts to finish the cutting depth. The harder the key blank is, the more cuts that will be needed.		
Layered Cutting				
		You can manually set the cutting depth when cutting laser keys.		
		Cancel the operation		Start cutting key

## Jaw Calibration

### 1. Automobile Key Jaw (S1-A)



#### Step 1.

Choose Automobile Key Jaw (S1)



#### Step 2.

Choose Side A (S1-A)



#### Step 3.


Change cutter to decoder, place the calibration block and fix Jaw tightly, then click "OK" button as shown in picture.



## Jaw Calibration

(continued...)

### 2. Automobile Key Jaw (S1-B)



#### Step 1.

Choose Automobile Key Jaw (S1)



#### Step 2.

Choose Side B (S1-B)




#### Step 3.

Change cutter to decoder, place the calibration block and fix Jaw tightly, then click "OK" button as shown in picture.



## Jaw Calibration

### 3. Automobile Key Jaw (S1-C)



#### Step 1.

Choose Automobile Key Jaw (S1)




#### Step 2.

Choose Side C (S1-C)



#### Step 3.


Change cutter to decoder, place the calibration block and fix Jaw tightly, then click "OK" button as shown in picture.



## Jaw Calibration


(continued...)

### 4. Automobile Key Jaw (S1-D)



#### Step 1.

Choose Automobile Key Jaw (S1)




#### Step 2.

Choose Side D (S1-D)



#### Step 3.


Change cutter to decoder, place the calibration block and fix Jaw tightly, then click "OK" button as shown in picture.






## Jaw Calibration

### 5. Single Standard Key Jaw (S2-A)




#### Step 1.

Choose Single Standard Key Jaw (S2)




#### Step 2.

Choose Side A (S2-A)



#### Step 3.

Change cutter to decoder, place the calibration block and fix Jaw tightly, then click "OK" button as shown in picture.






## Jaw Calibration


(continued...)

### 6.Single Standard Key Jaw (S2-B)




#### Step 1.

Choose Single Standard Key Jaw (S2)




#### Step 2.

Choose Side B (S2-B)




#### Step 3.

Change cutter to decoder, place the calibration block and fix Jaw tightly, then click "OK" button as shown in picture.




## Jaw Calibration

### 7. Tubular Key Jaw (S3)




#### Step 1.

Choose Tubular Key Jaw (S3)



#### Step 2.

Choose Jaw (S3)



#### Step 3.


Change cutter to decoder, place the calibration block and fix Jaw tightly, then click "OK" button as shown in picture.



## Jaw Calibration


(continued...)

### 8. Ford/Jaguar Tibbe Key Jaw (S4)




#### Step 1.

Choose  
Tibbe Key Jaw (S4)



#### Step 2.

Choose Jaw (S4)



#### Step 3.

Change cutter to decoder,  
place the calibration block  
and fix Jaw tightly, then  
click "OK" button as shown  
in picture.



# Search


## Key Blank Search


### Example: HU66 (Volkswagen, Audi, Skoda)

You can search key data by key blank

&Wmsksqr`cd\_kgjg\_pugrfa\_picw`j\_liglmpbcprmsqcrfgqdslargml,'


## Step 1.

Click  button



## Step 2.

Click "Key Blank"  
button, then input  
the key blank number




### Step 3.

Choose the corresponding key blank manufacturer



### Step 4.

Input the biting numbers and click "OK" button then "Cut" button



# Search


## ID Search


### Example:909 (Volkswagen, Audi, Skoda)

You can search key data by ID

*&Wmsksqr`cd\_kgjg\_pugrfGBdpmkGlqr\_ambcglmpbcprmsqcrfgqdslargml,'*


#### Step 1.

Click  button




#### Step 2.

Click "ID" button, then input the ID number




#### Step 3.

Choose the corresponding ID number



#### Step 4.

Input the biting numbers and click "OK" button then "Cut" button




## Settings Menu

### Language


#### Step 1.

Click  button




#### Step 2.

Click "Language" button



#### Step 3.

Choose the language you need




## Settings Menu

### Software Upgrade


#### Step 1.

Click  button



#### Step 2.

Click "Software Upgrade" button



#### Step 3.


Click "Upgrade" button to upgrade your equipment





## Settings Menu

### Cutting Speed

Step 1.

Click  button




Step 2.

Click "Settings" button

Step 3.

Click "Cutting Speed" button



Step 4.


Slide progress bar to adjust cutting speed




## Settings Menu

### Shield Override


#### Step 1.

Click  button




#### Step 2.

Click "Settings" button




#### Step 3.

Click "Others" button



#### Step 4.

Slide to "On" to allow shield to be open during cutting




## Settings Menu

### About Us


#### Step 1.

Click  button




#### Step 2.

Click "About Us" button



#### Step 3.


View details of "About Us"



## Key Decoding

### Key Decoding


#### Step 1.

Click  Decode button



#### Step 2.

1. Confirm key's position
2. Place the decoder as shown in picture
3. Click "Decode" button



#### Step 3.

Decoding...wait a moment



#### Step 4.

Decoding is done






## Key Cutting

### Example: Audi Q7

(Input known biting numbers to cut a key when the original key is lost)


#### Step 1.

Click  button  
on Home Page




#### Step 2.

Choose "Audi"  
in the list



#### Step 3.

Choose "Q7" in the list



#### Step 4.

Choose the year of  
manufacture



## Key Cutting

### Example: Audi Q7

(Input known biting numbers to cut a key when the original key is lost)

#### Step 5.


Click  button




#### Step 62.

Input known biting numbers then click "OK" button


#### Step 7.

Check if the biting numbers are correct or not, then click  button



#### Step 8.

1. Fix the key as shown in picture
2. Insert cutter
3. Click "Cut" to cut key after confirmed





 Cut

## Cutting Depth Adjustment

### Example: Honda Accord


#### Step 1.

Click  button  
on Home Page




#### Step 2.

Choose "Honda" in the list



#### Step 3.

Choose "Accord" in the list





## Cutting Depth Adjustment


### Example: Honda Accord

#### Step 4.

Choose the year of manufacture




#### Step 5.

Click  button to pop out invisible window

#### Step 6.

Change the cutting depth by using "+, -" buttons






## Layered Cutting

### Example: Audi Q7

(Input known biting numbers to cut a key when the original key is lost)

#### Step 1.

Click  button  
on Home Page




#### Step 2.

Choose "Audi"  
in the list

#### Step 3.

Choose "Q7" in the list






## Layered Cutting

### Example: Audi Q7 &amlr,'

(Input known biting numbers to cut a key when the original key is lost)

#### Step 4.

Choose year of manufacture




#### Step 5.

Click  Cut button

#### Step 6.

Choose corresponding "Layered Cutting" icon





## Move

### Example: Audi Q7

(Input known biting numbers to cut a key when the original key is lost)

#### Step 1.

Click  button  
on Home Page




#### Step 2.

Choose "Audi"  
in the list

#### Step 3.


Choose "Q7" in the list




## Move

**Example: Audi Q7** &amlr,'

(Input known biting numbers to cut a key when the original key is lost)

**Step 4.**Choose year  
of manufacture**Step 5.**Click  button**Step 6.**

Clamp moves






## Code

### Example: Honda Accord

(How to cut a key when original key is lost)

#### Step 1.

Click  button  
on Home Page




#### Step 2.

Choose "Honda"  
in the list

#### Step 3.

Choose "Accord" in the list





## Code

**Example: Honda Accord &amlr,'**


(How to cut a key when original key is lost)

**Step 4.**

Choose year of manufacture

**Step 5.**Click  button**Step 6.**


Input the code "M081" and click "Search" to get the bitting numbers




## Progression

### Example: Audi-Q7


#### Step 1.

Click  button  
on Home Page




#### Step 2.

Choose "Audi"  
in the list




#### Step 3.

Choose "Q7" the list



#### Step 4.

Choose the year of  
manufacture




## Progression

### Example: Audi Q7 &amlr,'

#### Step 5.

Click  button




#### Step 6.

Example: Input known biting numbers "234321" and keep unknown biting numbers as "?" in the input box


#### Step 7.

Make sure the biting numbers are correct, then click "Search" button




#### Step 8.

Review search result and choose the corresponding one you need




# Duplicate

## Single Standard Key



### Step 1.

Click "Duplicate" button on Home Page



### Step 2.

Click "Single Standard" button




### Step 3.

Click "Shoulder" button



### Step 4.

Click "Jaw" button




### Step 5.

Click "Cut" button after duplicating is done




# Duplicate

## Double Standard Key



### Step 1.

Click "Duplicate" button on Home Page




### Step 2.

Click "Double Standard" button



### Step 3.

Click "Shoulder" button



### Step 4.

Click "Jaw" button




### Step 5.

Click "Cut" button after duplicating is done

# Duplicate

## Single External Groove Key



### Step 1.

Click "Duplicate" button on Home Page



### Step 2.

Click "Single External Groove" button



### Step 3.

Click "Up Single Track Shoulder" button



### Step 4.


Click "Jaw" button and adjust cutter dimension

### Step 5.

Click "Cut" button after duplicating is done

# Duplicate

## Double External Groove Key



### Step 1.

Click "Duplicate" button on Home Page



### Step 2.

Click "Double External Groove" button




### Step 3.

Click "Shoulder" button



### Step 4.

Click "Jaw" button and adjust cutter dimension




### Step 5.

Click "Cut" button after duplicating is done


# Duplicate

## Internal Groove Key



### Step 1.

Click "Duplicate" button on Home Page



### Step 2.

Click "Internal Groove" button



### Step 3.

Click "Shoulder" button



### Step 4.

Click "Jaw" button and adjust cutter dimension




### Step 5.

Click "Cut" button after duplicating is done


## Duplicate

### Tubular Key & amlrglsch,,,'




#### Step 1.

Click "Duplicate" button on Home Page



#### Step 2.

Click "Tubular" button



#### Step 3.

Click "Jaw" button




#### Step 4.

Click "Cut" button after duplicating is done


## Custom Keys

### Double Standard Key




#### Step 1.

Click "Custom Keys" button on Home Page




#### Step 2.

Click "Add New Key" button




#### Step 3.

Click "Double Standard" button, then "Next" button



#### Step 4.

Click "Shoulder" button, then "Next" button



#### Step 5.

Input the parameters in space location of the key and click "Next" button

## Custom Keys

&amrlrglscb,,,'



### Step 6.

Input the parameters in space width of the key and click "Next" button



### Step 7.

Input the parameters in depth of the key and click "Next" button



### Step 8.

Input the parameters in width and click "Next" button




### Step 9.

Choose correct "Jaw" and click "Next" button



### Step 10.

Name the new key data and click "OK" button




### Step 11.

Review the key data you just added


## Custom Keys

### Single Internal Groove Key




#### Step 1.

Click "Custom Keys" button on Home Page




#### Step 2.

Click "Add New Key" button



#### Step 3.

Click "Single Internal Groove Key" button, then "Next" button



#### Step 4.

Click "Shoulder" button, then "Next" button



#### Step 5.

Choose "A" and input the parameters in space location of the key and click "Next" button



## Custom Keys

(continued...)



### Step 6.

Input the parameters in space width of the key and click "Next" button




### Step 7.

Input the parameters in depth of the key and click "Next" button



### Step 8.

Input the parameters in Width, Thickness, Cut Depth, Groove and Guide and click "Next" button




### Step 9.

Choose correct "Jaw" and click "Next" button



### Step 10.

Name the new key data and click "OK" button




### Step 11.

Review the key data you just added


## Custom Keys

### Double Internal Groove Key



#### Step 1.

Click "Custom Keys" button on Home Page




#### Step 2.

Click "Add New Key" button



#### Step 3.

Click "Double Internal Groove Key" button, then "Next" button



#### Step 4.

Click "Shoulder" button, then "Next" button



#### Step 5.

Input the parameters in space location of the key and click "Next" button

## Custom Keys

(continued...)



### Step 6.

Input the parameters in space width of the key and click "Next" button




### Step 7.

Input the parameters in depth of the key and click "Next" button




### Step 8.

Input the parameters in Width, Thickness, Cut Depth, Groove and Nose and click "Next" button




### Step 9.

Choose correct "Jaw" and click "Next" button



### Step 10.

Name the new key data and click "OK" button




### Step 11.

Review the key data you just added


## Custom Keys

### Dimple Key



#### Step 1.

Click "Custom Keys" button on Home Page



#### Step 2.

Click "Add New Key" button



#### Step 3.

Click "Dimple" button, then "Next" button



#### Step 4.

Click "Shoulder" button, then "Next" button




#### Step 5.

Input the parameters in space location of the key and click "Next" button

## Custom Keys

(continued...)



### Step 6.

Input the parameters in depth of the key and click "Next" button



### Step 7.

Input the parameters in Width & Thickness and click "Next" button




### Step 8.

Choose correct "Jaw" and click "Next" button



### Step 9.

Name the new key data and click "OK" button




### Step 10.

Review the key data you just added


## Custom Keys

### Single Standard Key




#### Step 1.

Click "Custom Keys" button on Home Page




#### Step 2.

Click "Add New Key" button



#### Step 3.

Click "Single Standard" button, then "Next" button



#### Step 4.

Click "Shoulder" button, then "Next" button



#### Step 5.

Input the parameters in space location of the key and click "Next" button

## Custom Keys

(continued...)



### Step 6.

Input the parameters in space width of the key and click "Next" button




### Step 7.

Input the parameters in depth of the key and click "Next" button




### Step 8.

Input the parameters in Width and click "Next" button



### Step 9.

Name the new key data and click "OK" button




### Step 10.

Review the key data you just added


## Custom Keys

### Single External Groove Key




#### Step 1.

Click "Custom Keys" button on Home Page




#### Step 2.

Click "Add New Key" button



#### Step 3.

Click "Single External Groove Key" button, then "Next" button



#### Step 4.

Click "Shoulder" button, then "Next" button



#### Step 5.

Choose "A" and input the parameters in space location of the key and click "Next" button



## Custom Keys

(continued...)




### Step 6.

Input the parameters in space width of the key and click "Next" button




### Step 7.

Input the parameters in depth of the key and click "Next" button




### Step 8.

Input the parameters in Width, Thickness, Cut Depth, Groove and Nose and click "Next" button




### Step 9.

Choose correct "Jaw" and click "Next" button



### Step 10.

Name the new key data and click "OK" button




### Step 11.

Review the key data you just added


## Custom Keys

### Double External Groove Key



#### Step 1.

Click "Custom Keys" button on Home Page




#### Step 2.

Click "Add New Key" button



#### Step 3.

Click "Double External Groove Key" button, then "Next" button



#### Step 4.

Click "Shoulder" button, then "Next" button



#### Step 5.

Input the key parameters in the spaces and click "Next" button

## Custom Keys

(continued...)



### Step 6.

Input the parameters in space width of the key and click "Next" button




### Step 7.

Input the parameters in depth of the key and click "Next" button



### Step 8.

Input the parameters in Width, Thickness, Cut Depth and click "Next" button




### Step 9.

Choose correct "Jaw" and click "Next" button



### Step 10.

Name the new key data and click "OK" button




### Step 11.

Review the key data you just added


## Custom Keys

### Tubular Key




#### Step 1.

Click "Custom Keys" button on Home Page




#### Step 2.

Click "Add New Key" button



#### Step 3.

Click "Tubular" button, then "Next" button



#### Step 4.

Input the parameters in space location of the key and click "Next" button




#### Step 5.

Input the parameters in depth of the key and click "Next" button

## Custom Keys

(continued...)




### Step 6.

Input the parameters in Width, Thickness, Cut Depth and click "Next" button



### Step 7.

Name the new key data and click "OK" button




### Step 8.

Review the key data you just added

## Favorites/Cut History



You can check what keys you've saved before.




You can check what keys you've cut before.

## WIFI Connection

### WIFI Connection

#### Step 1.

Click "Set Up" button on Desktop



#### Step 2.

Click "WLAN" button



Choose the available WIFI connections shown in the list

#### Step 3.



#### Step 4.

Input password and click "Connect" button




## Software Activation

### Software Activation

#### Step 1.

Open the software and log in Serial Number and Registration code



Registration

Serial Number:

Registration code:

OK




#### Step 2.

Find the label on the back cover of the equipment. The serial number and registration code are there.

#### Step 3.

Click "OK" button and complete the software activation



Registration

Serial Number:  
E23456789

Registration code:  
C0123456

OK



## Warranty

### LIMITED MANUFACTURER'S WARRANTY

Lock Labs® warrants the Triton Plus Key Cutting Machine™ in compliance with this certificate, in effect for 24 months from the date of purchase. In order to redeem the benefits provided to you by this warranty, **this documentation must be provided in tandem with a verifiable proof of purchase**, as issued by an authorized Triton Plus Key Cutting Machine™ distributor. This warranty covers the free repair or replacement of any parts deemed faulty as a result of manufacturing defects. (For the most current version of this agreement, please visit [TritonKeyMachine.com/warranty](http://TritonKeyMachine.com/warranty)).

#### This warranty does **not** cover:

- (1) Damage or malfunctions caused by natural disasters or acts of God (lightning, fire, flood, earthquakes and other external causes)
- (2) Theft, misplacement, reckless, abusive, willful or intentional conduct associated with handling and use of the Triton Plus Key Cutting Machine™
- (3) Faulty installation, repair, or maintenance by anyone other than a Lock Labs® authorized service provider
- (4) Damage to or failure of unauthorized aftermarket upgrades or add-on accessories (This includes the electrical failure of the machine due to the use of inferior or inefficient power inverters)
- (5) Consumer replaceable or consumable items, including but not limited to: cutting bits, tracers (decoders), T-wrenches (Allen wrenches), Allen-slotted threaded bolts, tip stop/calibration block, debris brush and AC power adapter
- (6) Extreme environmental conditions (including extreme temperature or humidity) leading to problems such as external condensation, overheating and mold
- (7) Usage outside of the permitted or intended uses, as described by the manufacturer
- (8) Malfunctions caused by improper operation by machine operator
- (9) Damage caused by insect infestation or rodents
- (10) Covered products that have been reported as lost or stolen
- (11) Any machine whose serial number has been altered, defaced or removed
- (12) Any machine whose software has been modified or altered beyond the normal scope of use
- (13) Damage that is secondary, or any damage that would be ordinarily covered under a primary insurance policy (e.g., car accident causes damage to the Triton Plus Key Cutting Machine™)
- (14) Protection against any other act or result not covered by this plan
- (15) Any resultant damage to the Triton Plus Key Cutting Machine™ that arises from one or more conditions described above

Except for the above cases, all qualifying malfunctions are eligible for free service within the warranty period. To assure your request for service is handled efficiently, please contact Lock Labs® customer service prior to sending us any product. We will issue you a Repair Authorization Form that must be included when shipping your product to us. Failure to do so will result in service delays.

**Shipping and Handling Policy:** Lock Labs® will contribute to the cost of shipping to and from our repair center, at our discretion, and only within the Continental United States. After preliminary assessment, if your machine malfunction is determined as uncoverable by this warranty, the entirety of all shipping costs will become your obligation. Failure to rectify any outstanding shipping or repair charges **will** result in return shipping delays.

### How to Obtain Service and Support

You may obtain service by accessing our website, [tritonkeymachine.com/support](http://tritonkeymachine.com/support), or by calling us at (888) 988-6865. Regular business hours are Monday through Friday 8am to 5pm Pacific Standard Time.

#### To receive service or support, you agree to comply with each of the terms listed below:

- (i) You will provide a copy of this warranty and a copy of your purchase, exchange and service receipts, if requested
- (ii) You will provide, to the best of your ability, information about the symptoms and causes of your issues with the Triton Plus Key Cutting Machine™
- (iii) You will respond to requests for information, including but not limited to: your product serial number, version of the software installed, any peripheral devices connected or installed on the Triton Plus Key Cutting Machine™ key machine, any error messages displayed, the actions which were taken before the Triton Plus Key Cutting Machine™ experienced the issue and the steps taken to attempt resolution of the issue
- (iv) You will follow instructions we give you, including but not limited to refraining from sending us products and accessories that are not subject to repair or replacement service (as listed above) and packing the Triton Plus Key Cutting Machine™ in accordance with the shipping instructions we will provide to you upon service agreement
- (v) **Keep your original packaging!** In the event your machine must be shipped to our repair facility, there is no safer method to ensure that the machine will arrive intact and undamaged, than if it ships in its original box with the original foam inserts. Damages incurred during shipping, due to improper packaging, will be the customer's sole responsibility
- (vi) You will be required to sign a service order disclaimer or other service order terms to obtain repairs or a replacement device. This service order disclaimer or other service order terms do not form a part of this warranty, and are a separate legal document
- (vii) **After** securing permission to send in your machine, please insert your completed Repair Authorization Form inside the box and ship to: Lock Labs Warranty and Repair Center - 5275 S. Arville Street Ste. 328, Las Vegas, NV 89118

THE LIMITED MANUFACTURER'S WARRANTY IS EXPRESSLY GIVEN AND ACCEPTED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT THEY CANNOT BE DISCLAIMED, THE IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFE OF THE EXPRESS WARRANTY. LOCK LABS SHALL HAVE NO LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES THAT ARISE FROM THE SALE OF TRITON™ PRODUCTS OR ARE A RESULT OF A BREACH OF THE LIMITED MANUFACTURER'S WARRANTY REPRODUCED ABOVE. THE REMEDIES SET FORTH IN THE LIMITED MANUFACTURER'S WARRANTY ARE THE PURCHASER'S SOLE AND EXCLUSIVE REMEDIES, AND THE ENTIRE LIABILITY OF LOCK LABS FOR ANY BREACH OF THE LIMITED MANUFACTURER'S WARRANTY. SOME STATES/JURISDICTIONS DO NOT ALLOW FOR THE DISCLAIMERS, LIMITATIONS, AND EXCLUSIONS DESCRIBED ABOVE, AND AS A RESULT, THEY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH MAY VARY FROM STATE TO STATE OR FROM ONE JURISDICTION TO ANOTHER. NO DISTRIBUTOR, DEALER, SALES REPRESENTATIVE NOR ANY OTHER PERSON HAS BEEN AUTHORIZED TO MAKE ANY AFFIRMATION, REPRESENTATION OR WARRANTY REGARDING THE PRODUCT, OTHER THAN THOSE CONTAINED IN THIS LIMITED MANUFACTURER'S WARRANTY, AND IF MADE, SHALL NOT BE ENFORCEABLE AGAINST LOCK LABS. LOCK LABS RESERVES THE RIGHT TO MODIFY THESE TERMS AND CONDITIONS AT ANY TIME, IT BEING UNDERSTOOD THAT SUCH MODIFICATION WILL NOT ALTER THE LIMITED MANUFACTURER'S WARRANTY CONDITIONS APPLICABLE TO THE PRODUCTS SOLD WHILE THESE TERMS AND CONDITIONS ARE IN EFFECT.

# TRITON

+ PLUS +



[WWW.TRITONKEYMACHINE.COM](http://WWW.TRITONKEYMACHINE.COM)



---

5275 S. Arville Street Ste. 328  
Las Vegas, NV 89118

Tel: (855) 562-5522  
Email: [info@lock-labs.com](mailto:info@lock-labs.com)