



**Synway SBO Series Gateway**

**SBO500 Gateway**

**SBO2000 Gateway**

# **User Manual**

**Version 1.6.5**

**Synway Information Engineering Co., Ltd**

**[www.synway.net](http://www.synway.net)**

# Content

<b>Content .....</b>	<b>i</b>
<b>Copyright Declaration.....</b>	<b>iii</b>
<b>Revision History.....</b>	<b>iv</b>
<b>Chapter 1 Product Introduction .....</b>	<b>1</b>
1.1 Typical Application .....	1
1.2 Feature List.....	2
1.3 Hardware Description .....	2
1.4 Alarm Info .....	5
<b>Chapter 2 Quick Guide .....</b>	<b>6</b>
<b>Chapter 3 WEB Configuration.....</b>	<b>8</b>
3.1 System Login .....	8
3.2 Operation Info .....	9
3.2.1 System Info.....	10
3.2.2 IP Status .....	12
3.2.3 Call Monitor.....	15
3.2.4 Call Count.....	16
3.2.5 Warning Information .....	17
3.3 SIP Settings .....	18
3.3.1 SIP Settings .....	19
3.3.2 SIP Trunk .....	23
3.3.3 SIP Register.....	26
3.3.4 SIP Account .....	29
3.3.5 SIP Trunk Group .....	31
3.3.6 Media Settings.....	34
3.4 Route Settings .....	36
3.4.1 Routing Parameters.....	37
3.4.2 IP to IP.....	37
3.5 Number Filter .....	40
3.5.1 Whitelist.....	41
3.5.2 Blacklist .....	43
3.5.3 Number Pool.....	44
3.5.4 Filtering Rule.....	45
3.6 Number Manipulation.....	48
3.6.1 IP to IP CallerID .....	48
3.6.2 IP to IP CalleeID .....	50
3.7 System Tools .....	51
3.7.1 Network .....	52
3.7.2 Management.....	54
3.7.3 IP Routing Table.....	57
3.7.4 Access Control.....	58
3.7.5 Centralized Manage.....	60

3.7.6	<i>SIP Account Generator</i> .....	61
3.7.7	<i>Configuration File</i> .....	62
3.7.8	<i>Signaling Capture</i> .....	63
3.7.9	<i>Signaling Call Test</i> .....	64
3.7.10	<i>Signaling Call Track</i> .....	65
3.7.11	<i>Network Speed Tester</i> .....	66
3.7.12	<i>PING Test</i> .....	67
3.7.13	<i>TRACERT Test</i> .....	68
3.7.14	<i>Modification Record</i> .....	69
3.7.15	<i>Backup &amp; Upload</i> .....	69
3.7.16	<i>Factory Reset</i> .....	70
3.7.17	<i>Upgrade</i> .....	70
3.7.18	<i>Change Password</i> .....	71
3.7.19	<i>Device Lock</i> .....	71
3.7.20	<i>Restart</i> .....	72
<b>Chapter 4 Typical Applications</b> .....		<b>73</b>
<b>Appendix A Technical Specifications</b> .....		<b>76</b>
<b>Appendix B Troubleshooting</b> .....		<b>77</b>
<b>Appendix C Technical/sales Support</b> .....		<b>78</b>

# Copyright Declaration

All rights reserved; no part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, without prior written permission from Synway Information Engineering Co., Ltd (hereinafter referred to as 'Synway').

Synway reserves all rights to modify this document without prior notice. Please contact Synway for the latest version of this document before placing an order.

Synway has made every effort to ensure the accuracy of this document but does not guarantee the absence of errors. Moreover, Synway assumes no responsibility in obtaining permission and authorization of any third party patent, copyright or product involved in relation to the use of this document.

## Revision History

Version	Date	Comments
Version 1.0.0	2015-05	Initial publication.
Version 1.6.2	2015-09	New revision
Version 1.6.3	2016-01	New revision
Version 1.6.4	2016-09	New revision
Version 1.6.5	2017-06	New revision

**Note:** Please visit our website <http://www.synway.net> to obtain the latest version of this document.

# Chapter 1 Product Introduction

Thank you for choosing Synway SBO Series Gateway!

The Synway SBO series gateway products (hereinafter referred to as 'SBO gateway') are mainly used for connecting IP or enterprise PBX with the IP telephony network or IP PBX. It provides such functions as transcoding, routing, number filtration, number manipulation and so on. Currently, only SBO500 and SBO2000 are available for you.

## 1.1 Typical Application




Figure 1-1 Typical Application

## 1.2 Feature List

Basic Features	Description				
<b>IP Call</b>	Call initiated from IP to a designated SIP trunk, via routing and number manipulation.				
<b>Number Manipulation</b>	Peels off some digits of a phone number from left/right, or adds a prefix/suffix to a phone number.				
<b>VoIP Routing</b>	Routing path: from IP to IP.				
Signaling & Protocol	Description				
<b>SIP Signaling</b>	Supported protocol: SIP V1.0/2.0, RFC3261				
<b>Voice</b>	<table border="1"> <tr> <td>CODEC</td> <td>G.711A, G.711U, G.729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K)</td> </tr> <tr> <td>DTMF Mode</td> <td>RFC2833, SIP INFO, INBAND, <i>RFC2833+Signaling, In-band+Signaling</i></td> </tr> </table>	CODEC	G.711A, G.711U, G.729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K)	DTMF Mode	RFC2833, SIP INFO, INBAND, <i>RFC2833+Signaling, In-band+Signaling</i>
CODEC	G.711A, G.711U, G.729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K)				
DTMF Mode	RFC2833, SIP INFO, INBAND, <i>RFC2833+Signaling, In-band+Signaling</i>				
Network	Description				
<b>Network Protocol</b>	Supported protocol: TCP/UDP, HTTP, ARP/RARP, DNS, NTP, TFTP, TELNET, STUN				
<b>Static IP</b>	IP address modification support				
<b>DNS</b>	Domain Name Service support				
Security	Description				
<b>Admin Authentication</b>	Support admin authentication to guarantee the resource and data security				
Maintain & Upgrade	Description				
<b>WEB Configuration</b>	Support of configurations through the WEB user interface				
<b>Language</b>	Chinese, English				
<b>Software Upgrade</b>	Support of user interface, gateway service, kernel and firmware upgrades based on WEB				
<b>Tracking Test</b>	Support of Ping and Tracert tests based on WEB				
<b>SysLog Type</b>	Three options available: ERROR, WARNING, INFO				

## 1.3 Hardware Description

The SBO gateway features 1U rackmount design and integrates embedded LINUX system within the POWERPC+DSP hardware architecture. It has 2 Kilomega-Ethernet ports (NET1 and NET2) on the chassis. See the figures below for product appearance:



Figure 1-2 Front View for SBO500



Figure 1-3 Rear View for SBO500



Figure 1-4 Left View for SBO500



Figure 1-5 Front View for SBO2000



Figure 1-6 Rear View for SBO2000



Figure 1-7 Left View for SBO2000

The table below gives a detailed introduction to the interfaces, buttons and LEDs illustrated above:

Interface	Description
<b>NET</b>	Amount: 2
	Type: RJ-45
	Bandwidth: 10/100/1000Mbps
	Self-Adaptive Bandwidth Supported
	Auto MDI/MDIX Supported
<b>Console Port</b>	Amount: 1
	Type: RS-232
	Baud Rate: 115200 bps
	Connector: RJ45 (See Figure 1-8 for signal definition) , USB
	Data Bits: 8 bits
	Stop Bit: 1 bit
	Parity Unsupported
	Flow Control Unsupported
Button	Description
<b>Power Key</b>	Power on/off the SBO gateway. You can turn on the two power keys at the same time to have the power supply working in the hot-backup mode.
<b>Reset Button</b>	Restore the gateway to factory settings.
LED	Description
<b>Power Indicator</b>	Indicates the power state. It lights up when the gateway starts up with the power cord well connected.
<b>Run Indicator</b>	Indicates the running status. For more details, refer to <a href="#">1.4 Alarm Info.</a>
<b>Alarm Indicator</b>	Alarms the device malfunction. For more details, refer to <a href="#">1.4 Alarm Info.</a>
<b>Link Indicator</b>	The green LED on the left of NET, indicating the network connection status.
<b>ACT Indicator</b>	The orange LED on the right of NET, whose flashing tells data are being transmitted.

Note: The console port is used for debugging. For the connection of SBO500, the transmitting and receiving lines of the gateway and the remote device should be cross-linked. That is, connect the transmitting line of the gateway to the receiving line of the remote device, and vice versa. The figure below illustrates the signal definition of the console port on the gateway.




Figure 1-8 Console Port Signal Definition

The SBO2000 gateway is connected via a two male end USB cable which can convert to 8 consoles (each USB port converts to 4).

For other hardware parameters, refer to [Appendix A Technical Specifications](#).

## 1.4 Alarm Info

The SBO gateway is equipped with two indicators denoting the system's running status: Run Indicator (green) and Alarm Indicator (red). The table below explains the states and meanings of the two indicators.

LED	State	Description
<i>Run Indicator</i>	Go out	System is not yet started.
	Light up	System is starting.
	Flash	Device is running normally.
<i>Alarm Indicator</i>	Go out	Device is working normally.
	Light up	Upon startup: Device is running normally. In runtime: Device goes abnormal.
	Flash	System is abnormal.

**Note:**

- The startup process consists of two stages: System Booting and Gateway Service Startup. The system booting costs about 1 minute and once it succeeds, both the run indicator and the alarm indicator light up. Then after the gateway service is successfully started and the device begins to work normally, the run indicator flashes and the alarm indicator goes out.
- During runtime, if the alarm indicator lights up or flashes, it indicates that the device goes abnormal. If you cannot figure out and solve the problem by yourself, please contact our technicians for help. Go to [Appendix C Technical/sales Support](#) to find the contact way.

## Chapter 2 Quick Guide

This chapter is intended to help you grasp the basic operations of the SBO gateway in the shortest time.

### Step 1: Confirm that your packing box contains all the following things.

- SBO Series Gateway \*1
- SBO500: Angle Bracket \*2, Rubber Foot Pad \*4, Screw for Angle Bracket \*8; SBO2000: Rubber Foot Pad \*6, Screw for Angle Bracket \*8, Front Angle Plate \*2, Back Angle Plate \*2, Earth Wire \*1, Shielded Straight Through Cable \*2
- 220V Power Cord \*2
- Warranty Card \*1
- Installation Manual \*1

### Step 2: Properly fix the SBO gateway.

If you do not need to place the gateway on the rack, simply fix the rubber foot pads. Otherwise, for the SBO500 gateway, you should first fix the 2 angle brackets onto the chassis and then place the chassis on the rack; for the SBO2000 gateway, you should first fix the front angle plates onto the chassis and then fix the chassis on the rack with the help of the back angle plates.

### Step 3: Connect the power cord.

Make sure the device is well grounded before you connect the power cord. Check if the power socket has the ground wire. If it doesn't, use the grounding stud on the rear panel of the device (See Figure 1-3) for earthing.

**Note:** Each SBO gateway has two power interfaces to meet the requirement for power supply hot backup. As long as you properly connect and turn on these two power keys, either power supply can guarantee the normal operation of the gateway even if the other fails.

### Step 4: Connect the network cable.

### Step 5: Log in the gateway.

Enter the original IP address (NET 1: 192.168.1.101 or NET 2: 192.168.0.101) of the SBO gateway in the browser to go to the WEB interface. The original username and password of the gateway are both 'admin'. For detailed instructions about login, refer to [3.1 System Login](#). We suggest you change the initial username and password via 'System Tools → Change Password' on the WEB interface as soon as possible after your first login. For detailed instructions about changing the password, refer to [3.7.18 Change Password](#). After changing the password, you are required to log in again.

### Step 6: Modify IP address of the gateway.

You can modify the IP address of the gateway via 'System Tools → Network' on the WEB interface to put it within your company's NET. Refer to [3.7.1 Network](#) for detailed instructions about IP modification. After changing the IP address, you shall log in the gateway again using your new IP address.

### Step 7: Check the channel status.

You can check the status of the channels via 'Operation Info → IP Status'. Refer to [3.2.2 IP Status](#) for detailed introductions.

### Step 8: Set routing rules for calls.

Note: For your easy understanding and manipulation, all examples given in this step do not involve registration.

Step 1: Configure the IP address of the remote SIP terminal which can establish conversations with the gateway so that the calls from other terminals will be ignored. Refer to 'SIP Settings → [SIP Trunk](#)' for detailed instructions. Click **Add New** to add a new SIP trunk, fill in 'Remote IP' and 'Remote Port' with the IP address and port of the remote SIP terminal which will initiate calls to the gateway. You may use the default values for the other configuration items.

**Example:** Provided the incoming IP address of the SIP trunk is 192.168.0.111 and the port is 5060. Add **SIP Trunk 0**; set **Remote IP** to **192.168.0.111** and **Remote Port** to **5060**. The outgoing IP address of the SIP trunk is 192.168.0.222 and the port is 5060. Add **SIP Trunk 1**; set **Remote IP** to **192.168.0.222** and **Remote Port** to **5060**.

Step 2: Add the IP address of the SIP trunks configured in Step 1 into the corresponding SIP trunk group. Refer to SIP Settings → [SIP Trunk Group](#)' for detailed instructions. Click **Add New** to add the SIP trunk group. Select the SIP trunk configured in Step 1 as 'SIP Trunks'. You may use the default values for the other configuration items.

**Example:** Add **SIP Trunk Group 0**. Check the checkbox before **0** for **SIP Trunks** and keep the default values for the other configuration items. Add **SIP Trunk Group 1**. Check the checkbox before **1** for **SIP Trunks** and keep the default values for the other configuration items.

Step 3: Add routing rules. Refer to 'Route Settings → [IP→IP](#)' for detailed instructions. Select the SIP trunk group 0 set in Step 2 as 'Call Initiator' and the SIP trunk group 1 set in Step 2 as 'Call Destination'. You may use the default values for the other configuration items.

**Example:** Select **SIP Trunk Group[0]** as **Call Initiator** and **SIP Trunk Group[1]** as **Call Destination**. Keep the default values for the other configuration items.

Step 4: Initiate a call from the SIP trunk 0 configured in Step 1 to the IP address and port of the SBO gateway. Thus you can establish a call conversation via SIP trunk[1] with the IP terminal. (Note: The format used for calling an IP address via SIP trunk is as follows: username@IP address.)

**Example:** Provided the IP address of the SBO gateway is 192.168.0.101 and the port is 5060. Provided 123 is a number which conforms to the number receiving rule of the remote device. Initiate a call from SIP trunk 0 to the IP address 192.168.0.101 (in the format: 123@192.168.0.101) and you can establish a call conversation via SIP trunk[1] to the number 123.

## Special Instructions:

- The chassis of the SBO gateway must be grounded for safety reasons, according to standard industry requirements. A simple way is earthing with the third pin on the plug or the grounding studs on the machine. No or improper grounding may cause instability in operation as well as decrease in lightning resistance.
- As the device will gradually heat up while being used, please maintain good ventilation to prevent sudden failure, ensuring that the ventilation holes (see Figure 1-4) are never jammed.
- During runtime, if the alarm indicator lights up or flashes, it indicates that the device goes abnormal. If you cannot figure out and solve the problem by yourself, please contact our technicians for help. Otherwise it may lead to a drop in performance or unexpected errors.

# Chapter 3 WEB Configuration

## 3.1 System Login

Type the IP address into the browser and enter the login interface. See Figure 3-1.



Figure 3-1 Login Interface

The gateway only serves one user, whose original username and password are both 'admin'. You can change the username and the password via 'System Tools → Change Password' on the WEB interface. For detailed instructions, refer to [3.7.18 Change Password](#).

After login, you can see the main interface as below.



Figure 3-2 Main Interface

## 3.2 Operation Info

Operation Info includes five parts: **System Info**, **IP Status**, **Call Count**, **Call Count** and **Warning Info**, showing the current running status of the gateway. See Figure 3-3.




Figure 3-3 Operation Info

### 3.2.1 System Info

System Info

<b>LAN 1</b>			
MAC Address	80:7B:85:10:0F:50		
IP Address	201.123.111.125	255.255.255.0	201.123.111.254
DNS Server	0.0.0.0		
Receive Packets	All:861929	Error:0	Drop:0
Transmit Packets	All:149366	Error:0	Drop:0
Current Speed	Receive:1.1 KB/s	Transmit:1.1 KB/s	
Work Mode	100Mb/s Full Duplex		
<b>LAN 2</b>			
MAC Address	80:7B:85:10:0F:51		
IP Address	192.168.0.109	255.255.255.0	192.168.0.254
DNS Server	0.0.0.0		
Receive Packets	All:0	Error:0	Drop:0
Transmit Packets	All:0	Error:0	Drop:0
Current Speed	Receive:0 B/s	Transmit:0 B/s	
Work Mode	Disconnected		
Runtime	3d 16h 48m 47s		
CPU Temperature	51°C		
CPU Usage Rate	4%		
Current RTP Message Data	Packet Loss Rate in Reception:0.00%	Packet Lost in Reception:0	Total Transmit Packets:0
<b>Current Version</b>			
Serial Number	000003268(500)		
WEB	1.6.5_2017041316		
Gateway	1.6.5_2017041316		
Uboot	2.1.5_201509		
Kernel	#422 SMP Tue Apr 11 09:16:39 CST 2017		
Firmware	16		

Figure 3-4 System Info Interface

See Figure 3-4 for the system info interface. You can click **Refresh** to obtain the latest system information. The table below explains the items shown in Figure 3-4.

Item	Description
<b>MAC Address</b>	MAC address of NET 1 or NET 2.
<b>IP Address</b>	The three parameters from left to right are IP address, subnet mask and default gateway of NET 1 or NET 2.
<b>DNS Server</b>	DNS server address of NET 1 or NET 2.
<b>Receive Packets, Transmit Packets</b>	The amount of receive/transmit packets after the gateway's startup, including three categories: All, Error and Drop.

<b>Current Speed</b>	The current speed of data receiving and transmitting.
<b>Work Mode</b>	The work mode of the network, including six options: 10 Mbps Half Duplex, 10 Mbps Full Duplex, 100 Mbps Half Duplex, 100 Mbps Full Duplex, 1000 Mbps Full Duplex and Disconnected.
<b>Runtime</b>	Time of the gateway keeping running normally after startup. This parameter updates every 2s.
<b>CPU Temperature</b>	Display the real time temperature of the CPU.
<b>CPU Usage Rate</b>	Display the real time usage rate of the CPU.
<b>Current RTP Message Data</b>	Display the receiving and sending information of the current RTP data.
<b>Serial Number</b>	Unique serial number of a SBO gateway.
<b>WEB</b>	Current version of the WEB interface.
<b>Gateway</b>	Current version of the gateway service.
<b>Uboot</b>	Current version of Uboot.
<b>Kernel</b>	Current version of the system kernel on the gateway.
<b>Firmware</b>	Current version of the firmware on the gateway.

### 3.2.2 IP Status









Figure 3-5 IP Status Interface

See Figure 3-5 for the IP status interface which shows the real-time status of each IP channel on the gateway.

Item	Description
<b>Channel No.</b>	The corresponding serial number of IP on the device.
<b>State</b>	Displays the channel state in real time. You can move the mouse onto the channel state icon for detailed information about the channel and the call, such as: call

direction, calling party number and called party number. The channel states include:

State	Icon	Description
<i>Idle</i>		The channel is available.
<i>Wait Answer</i>		The channel receives the ringback tone and is waiting for the called party to pick up the phone.
<i>Ringing</i>		The channel is in the ringing state.
<i>Talking</i>		The channel is in a conversation.
<i>Pending</i>		The channel is in the pending state
<i>Dialing</i>		The channel is dialing.
<i>Wait Message</i>		The channel is waiting for the message from remote PBX.

**Note:** The gateway provides the fuzzy search feature on this interface. After you click any characters on Figure 3-5 and press the 'F' button, the search box will emerge on the right top of this page. Then you can input the key characters and the gateway will locate the channel on which there is an ongoing call that conforms to the fuzzy search condition.

Take an example: As shown in Figure 3-6, after we input the character 114 to the search box, and click the **Search** button, the gateway does a fuzzy search and locates that the ongoing call whose CalledID contains the character 114 occurs on Channel 10 of Channel Group 1.

114

Status	Idle	Ringing	Wait Answer	Dialing	Talking	Pending	Wait Message
Icon							

IP Status

Channel No.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Channel Group0																																
Channel Group1																																
Channel Group2																																
Channel Group3																																
Channel Group4																																
Channel Group5																																
Channel Group6																																
Channel Group7																																
Channel Group8																																
Channel Group9																																
Channel Group10																																
Channel Group11																																
Channel Group12																																
Channel Group13																																
Channel Group14																																
Channel Group15																																
Channel Group16																																
Channel Group17																																
Channel Group18																																
Channel Group19																																
Channel Group20																																
Channel Group21																																
Channel Group22																																
Channel Group23																																
Channel Group24																																
Channel Group25																																
Channel Group26																																
Channel Group27																																
Channel Group28																																
Channel Group29																																
Channel Group30																																
Channel Group31																																

Note: If the icons display abnormally, please clear the cache and refresh this page.

Figure 3-6 Search Calls

### 3.2.3 Call Monitor


Monitoring Condition							
<input checked="" type="checkbox"/> Monitored CallerID	114	<input type="checkbox"/> Monitored CalleeID	<input type="checkbox"/> Monitored Remote Address	Monitoring LAN Port	LAN1.201.123.111.129	<input type="button" value="set"/>	
If the monitor feature does not work, <a href="#">click here</a> to download and install the monitoring plug-in.				1 Items Total 50 Items/Page Previous Next Go to Page 1 1 Pages Total			
Call Info							
Channel No.	Call Direction	Remote Address	Channel Status	CallerID	CalleeID	Start Time	Duration
242	IP Call In	201.123.111.121:5069		114	124	2016-08-26 14:03:24	00:00:45

Figure 3-7 Call Monitor Interface

See Figure 3-7 for the call monitor Interface. Here you can set a condition for call monitoring. For example, as shown in Figure 3-7, set the CallerID 114 as the monitoring condition, and after you click the **Set** button, all the calls containing the CallerID 114 will display in the Call Info list. The table below explains the items shown in Figure 3-7.

Item	Description
<b>Monitored CallerID, Monitored CalleeID, Monitored Remote Address</b>	Sets the condition for the call monitoring. You can set to monitor the calls by CallerID, CalleeID or remote address.
<b>Monitoring LAN Port</b>	Selects the LAN port which is used to monitor the calls.
<b>Channel No.</b>	The number of the channel, which starts from 0.
<b>Call Direction</b>	The direction of the monitored call.
<b>Remote Address</b>	The remote address of the monitored call.
<b>Channel Status</b>	The status of the channel which the monitored call locates at.
<b>CallerID</b>	The CallerID of the monitored call.
<b>CalleeID</b>	The CalleeID of the monitored call.
<b>Start Time</b>	The start time of the monitored call.
<b>Duration</b>	The duration of the monitored call.

Click the icon in the channel status column, and you can monitor the call in real-time. If your computer is not installed with the monitoring plug-in, click the icon and you will see a prompt asking you to set the security level. Follow the instructions to configure the IE explorer: Open it and click 'Tools > Internet Options > Security Tab'; then click 'Custom Level' and enable 'Initialize and script ActiveX controls not marked as safe for scripting'. If there is a shadow showing under

the icon, such as , it means the monitoring goes successful. Click the icon again to cancel the monitoring.

Note: If a channel has been monitored from the very beginning, the monitoring, even if not yet cancelled, will terminate once the channel is removed from the monitor list.

**Note:** This feature is unavailable for SBO2000.

### 3.2.4 Call Count

Incoming SIP Call Statistics								
SIP Index	Description	SIP Trunk Address	Current	Sum	Connection Rate	Answering Rate	Average Call Length (s)	INVITE(Times/s)
0	default	201.123.111.121	1	844	57.22%	49.88%	46	0
1	default	201.123.111.123	0	301	100.00%	40.19%	62	0

Outgoing SIP Call Statistics								
SIP Index	Description	SIP Trunk Address	Current	Sum	Connection Rate	Answering Rate	Average Call Length (s)	
0	default	201.123.111.121	0	902	60.08%	33.37%	38	
1	default	201.123.111.123	1	243	99.58%	99.17%	64	

Statistics on IP->IP Release Cause								
Release Reason	Normal Disconnection	Cancelled	Busy	No Answer	Route Failed	No Idle Resource	Failed	Others
Number	542	242	0	1	0	0	360	0
Percentage	47.33%	21.13%	0.00%	0.08%	0.00%	0.00%	31.44%	0.00%

Note: Please do not reset the Call Statistics if there is an ongoing call!

Figure 3-8 Call Count Interface

See Figure 3-8 for the call count Interface. The above list shows the detailed information about all the calls counted from the startup of the gateway service to the latest open or refresh of this interface. You can click **Reset** to count the call information again, click **Download** to download the call count logs. The table below explains the items shown in Figure 3-8.

Item	Description
<b>SIP Index</b>	The index of the SIP trunk.
<b>Description</b>	More information about each SIP trunk group.
<b>SIP Trunk Address</b>	Address of the SIP trunk, i.e. the IP address or domain name of the remote SIP terminal which will establish a call conversation with the gateway.
<b>Current</b>	The number of the current incoming/outgoing SIP calls.
<b>Sum</b>	The total number of the incoming SIP calls/ outgoing SIP calls/ IP→ PSTN calls/ PSTN→ IP calls.
<b>Connection Rate</b>	The percentage of successful calls to total calls by all method. The call methods include SIP Incoming Call, SIP Outgoing Call, IP→ PSTN call and PSTN→ IP call.
<b>Answering Rate</b>	The percentage of answered calls to total calls by all methods. The call methods include SIP Incoming Call, SIP Outgoing Call, IP→ PSTN call and PSTN→ IP call.
<b>Average Call Length</b>	The average call length for all connected calls.
<b>INVITE</b>	The number of the invite messages received per second.
<b>Release Reason</b>	Reason to release the call.
<b>Normal Disconnection</b>	Total number of the calls which are normally cleared. The corresponding SIP status code is 200.
<b>Cancelled</b>	Total number of the calls which are cancelled by the calling party. The corresponding SIP status code is 487.
<b>Busy</b>	Total number of the calls which fail as the called party has been occupied and replies a busy message. The corresponding SIP status code is 603.

<b>No Answer</b>	Total number of the calls which fail as the called party does not pick up the call in a long time or the calling party hangs up the call before the called party picks it up. The corresponding SIP status code is 403.
<b>Routing Failed</b>	Total number of the calls which fail because no routing rules are matched. The corresponding SIP status code is 488.
<b>No Idle Resource</b>	Total number of the calls which fail because no voice channel is available. The corresponding SIP status code is 486.
<b>Failed</b>	Total number of the calls which fail as the called party number does not conform to the number-receiving rule or for relative reasons. The corresponding SIP status code is other 4xx, 5xx, 6xx.
<b>Others</b>	Total number of the calls which fail because of other reasons. The corresponding SIP status code is 493.
<b>Number</b>	Total number of the calls on each state.
<b>Percentage</b>	The percentage of the calls with a release cause to total calls.

**Note:** This feature is unavailable for SBO2000.

### 3.2.5 Warning Information




Figure 3-9 Warning Information Interface

See Figure 3-9 for the Warning Information interface. All the warning information will be output

and displayed on this interface.

### 3.3 SIP Settings

SIP Settings includes six parts: **SIP**, **SIP Trunk**, **SIP Register**, **SIP Account**, **SIP Trunk Group** and **Media**. See Figure 3-10. **SIP** is used to configure the general SIP parameters; **SIP Trunk** is used to set the basic and register information of the SIP trunk; **SIP Register** is used for the registration of SIP; **SIP Account** is used for registering SIP accounts to the SIP server; **SIP Trunk Group** is to manage SIP trunks by group; and **Media** is to set the RTP port and the payload type.




Figure 3-10 SIP Settings

### 3.3.1 SIP Settings

SIP Settings

SIP Address of WAN	LAN 1: 201.123.111.17
SIP Signaling Port	5060
Send 100rel	<input type="checkbox"/> Enable
Hide CallerID	Not Hidden
Obtain CallerID from	Username of From Field
Obtain/Send CalleeID from	'Request' Field
Asserted Identity Mode	Disable
NAT Traversal	<input type="checkbox"/> Enable
SIP Transport Protocol	UDP
SIP Encryption	<input type="checkbox"/> Enable
RTP Encryption	<input type="checkbox"/> Enable
RTP Self-adaption	<input type="checkbox"/> Enable
UDP Header Checksum	<input checked="" type="checkbox"/> Enable
Rport	<input type="checkbox"/> Enable
Auto Reply of Source Address	<input type="checkbox"/> Enable
Time Limit for IMS Outgoing Calls	<input type="checkbox"/> Enable
DSCP	<input type="checkbox"/> Enable
Calls from SIP Trunk Address only	<input type="checkbox"/> Enable
Switch Signal Port if SIP Registration Failed	<input type="checkbox"/> Enable
Hang up upon Call Time-out	<input type="checkbox"/> Enable
Working Period	<input checked="" type="checkbox"/> 24 Hours
Session Timer	<input type="checkbox"/> Enable
Early Media	<input checked="" type="checkbox"/> Enable
Early Session	<input type="checkbox"/> Enable
Not Wait ACK after Sending 200 OK	<input type="checkbox"/> Enable
The Percentage of Registration Message Sending Cycle to Period of Validity(%)	70
Maximum Wait Answer Time(s)	60
Maximum Wait RTP Time(s)	0
Add Content to To Field in INVITE Message	<input type="radio"/> Yes <input checked="" type="radio"/> No
UserAgent Field	

**Note: Only one SIP Trunk can be configured and its "Local Network Port" should be set to "Any Lan" once the feature "Switch Network Port by Packet Loss Rate" is enabled.**

Figure 3-11 SIP Settings Interface

See Figure 3-11 for the SIP settings interface where you can configure the general SIP parameters. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.7.20 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-11.

Item	Description
<b>SIP Address of WAN</b>	IP address of SIP signaling for WAN, using NET 1 by default.
<b>SIP Signaling Port</b>	Monitoring port of SIP signaling. Range of value: 2000~65535, with the default value of 5060. <b>Note:</b> The value range of this configuration item and that of the RTP port set in <a href="#">Media Settings</a> cannot be overlapped.
<b>Send 100rel</b>	Sets whether to send the 100rel field, with the default value of disabled.
<b>Hide CallerID</b>	Sets whether to hide the CallerID, with the default value of <i>Not Hidden</i> .
<b>Obtain CallerID from</b>	There are two optional ways to obtain the calling party number: from Username of "From" Field or from Displayname of "From" Field. The default value is from <i>Username of "From" Field</i> .
<b>Obtain/Send CalleeID from</b>	There are two optional ways to obtain or send the called party number: from "To" Field or from "Request" Field. The default value is from <i>"Request" Field</i> .
<b>Asserted Identity Mode</b>	Sets whether to have the invite message include some header information, two options available now: P-Asserted-Identity and P-Preferred-Identity. The default value is <i>disabled</i> .
<b>Number in From Field not Manipulated</b>	Once this feature is enabled, the callerID in the From field will not be manipulated, with the default value of <i>disabled</i> . <b>Note:</b> It is valid only when the configuration item Asserted Identity Mode is enabled.
<b>NAT Traversal, Traversal Type</b>	Sets whether to enable the NAT traversal. By default this feature is disabled. There is only one traversal type: <i>Port Mapping</i> .
<b>LAN1 Mapping Address, LAN2 Mapping Address</b>	The mapping addresses of LAN1 and LAN2 in case the NAT traversal is enabled. If the port mapping is selected as the traversal type, you are required to set the mapping address on the router and fill in the corresponding information here as well. By default, only the IP address need be filled in, and the port value is just the same as the SIP signaling port.
<b>Always Use Mapping Address</b>	Once this feature is enabled, the gateway will be enforced to use the mapping address set in the above configuration item to initiate calls. By default it is <i>disabled</i> .
<b>SIP Transport Protocol</b>	There are two modes <i>UDP</i> and <i>TCP</i> available for running the SIP protocol. The default value is <i>UDP</i> . <b>Note:</b> This item is unsupported by SBO2000.
<b>SIP Encryption</b>	Once this feature is enabled, you can encrypt the SIP signal following selecting an encryption criterion and setting a key. By default it is <i>disabled</i> .
<b>Encryption Criterion</b>	The criterion used to encrypt the SIP signal. At present only VOS1.1 is supported.

<b>Key</b>	The key to encrypt the SIP signal.
<b>RTP Encryption</b>	Once this feature is enabled, you can encrypt the RTP package. By default it is <i>disabled</i> .
<b>RTP Self-adaption</b>	When this feature is enabled, the RTP reception address or port carried by the signaling message from the remote end, if not consistent with the actual state, will be updated to the actual RTP reception address or port. By default, this feature is <i>disabled</i> .
<b>UDP Header Checksum</b>	When this feature is enabled, the gateway will automatically calculate the check sum of the UDP header during RTP transmission.
<b>Rport</b>	When this feature is enabled, a corresponding Rport field will be added to the Via message of SIP. Meanwhile, the IP address and the port of the outer network will be filled into the CONTACT and VIA fields. By default, it is <i>disabled</i> .
<b>Auto Reply of Source Address</b>	Once this feature is enabled, the source address will be used by the gateway in its reply message, with the default value of <i>disabled</i> .
<b>Time Limit for IMS Outgoing Calls</b>	Once this feature is enabled, The gateway can set the time limit for the outgoing calls from the SIP registered account, with the default value of <i>disabled</i> . <b>Note:</b> This item is unsupported by SBO2000..
<b>Rated Time</b>	The limited time for the calls from the SIP registered account.
<b>SIP Registered Number Polling</b>	Once this feature is enabled, the registered account will carry out the call in a polling mode, with the default value of <i>disabled</i> .
<b>DSCP</b>	Sets whether to enable the DSCP differentiated services code point. By default, it is <i>disabled</i> .
<b>Voice Media</b>	Sets the priority of the voice media for DSCP. The voice media with a bigger value has a higher priority. The value range is 0~63, with the default value of 46.
<b>Signal Control</b>	Sets the priority of the signal control for DSCP. The signal control with a bigger value has a higher priority. The value range is 0~63, with the default value of 26.
<b>Calls from SIP Trunk Address only</b>	Once this feature is enabled, the gateway will only accept the calls from the IP addresses set in SIP Settings → SIP Trunk. By default, it is <i>disabled</i> .
<b>Switch Signal Port if SIP Registration Failed</b>	If the SIP registration fails, the SIP signaling port N will switch to N+1 for a new registration. It will continue until the registration succeeds. <b>Note:</b> This item is unsupported by SBO2000..
<b>Hang up if a Call Time-out</b>	Sets whether to enable the feature to hang up the call once it is time-out, with the default value of <i>No</i> ,
<b>Maximum Call Overtime</b>	Sets the maximum overtime for a call. Calculated by minute.
<b>Working Period, Period</b>	The work period for the gateway. You can specify a certain period for the gateway to make calls. By default, the gateway is allowed to make calls any time in the day (24 Hours).

<b>Session Timer</b>	Sets whether to enable the session refresh feature, with the default value of <i>disabled</i> . Once this feature is enabled, you are required to enter the minimum time and the timeout value.
<b>Minimum Time</b>	Sets the minimum time for refreshing the session. Value of range: 90~65535, with the default value of 150.
<b>Timeout</b>	Sets the timeout value for refreshing the session. The value cannot be less than that of Minimum Time, with the default value of 600.
<b>Early Media</b>	Once this feature is enabled, the P-Early-Media field will be included in the Invite message. The default value is <i>disabled</i> .
<b>Early Session</b>	Once this feature is enabled, the early-session field will be included in the Invite message. The default value is <i>disabled</i> .
<b>Not Wait ACK after Sending 200 OK</b>	Once this feature is enabled, the gateway does not need to wait the ACK message after sending the 200OK message. The default value is <i>disabled</i> .
<b>The Percentage of Registration Message Sending Cycle to Period of Validity</b>	Sets the percentage of the sending cycle of the SIP registration message to the validity period. Value of range: 1~200, with the default value of 70.
<b>Maximum Wait Answer Time</b>	Sets the maximum time for the SIP channel to wait for the answer from the called party of the outgoing call it initiates. If the call is not answered within the specified time period, it will be canceled by the channel automatically. The default value is 60, calculated by s.
<b>Maximum Wait RTP Time</b>	Sets the maximum time for the SIP channel to wait for the RTP packet. If no RTP packet is received within the specified time period, the channel will enter the pending state automatically and release the call. The default value is 0, calculated by s.
<b>Add Content to To Field in INVITE Message</b>	Once this feature is enabled, "user=phone" will be added to the TO field of the INVITE message. The default value is <i>disabled</i> .
<b>Add Content</b>	Sets the content to add to the TO field.
<b>UserAgent Field</b>	Sets the content of the UserAgent field. Currently, it only supports the English uppercase and lowercase letters.

### 3.3.2 SIP Trunk

By default, there is no available SIP trunk information. Click **Add New** to add a new SIP trunk. See Figure 3-12 for the SIP trunk adding interface.

SIP Trunk

Index: 0

Description: default

Remote Address:

Remote Port: 5060

Local Network Port: LAN1(201.123.111

Display CODEC

Transport Protocol: UDP

Outgoing Voice Resource: 512

Incoming Voice Resource: 512

Working Period:  24 Hours

Save
Close

Figure 3-12 Add New SIP Trunk

The table below explains the items shown in Figure 3-12.

Item	Description
<b>Index</b>	The unique index of each SIP trunk.
<b>Description</b>	More information about each SIP trunk group.
<b>Remote Address</b>	Address of the SIP trunk, i.e. the IP address or domain name of the remote SIP terminal which will establish call conversation with the gateway.
<b>Remote Port</b>	Port of the SIP trunk.
<b>Local Network Port</b>	The network port where the SIP trunk locates.
<b>Transport Protocol</b>	SIP transport protocol, providing two modes <i>UDP</i> and <i>TCP</i> . The default value is <i>UDP</i> .
<b>Outgoing Voice Resource</b>	Maximum number of voice channels for the outgoing calls allocated by the SIP trunk to the gateway.
<b>Incoming Voice Resource</b>	Maximum number of voice channels for the incoming calls allocated by the SIP trunk to the gateway.

<b>Working Period, Period</b>	The work period for the gateway, You can specify a certain period for the gateway to make calls. By default, the gateway is allowed to make calls any time in the day (24 Hours).						
<b>Display CODEC</b>	<p>Supported CODECs and their corresponding priorities for the SIP trunk to establish a call conversation. The table below explains the sub-items:</p> <table border="1" data-bbox="485 412 1374 667"> <thead> <tr> <th data-bbox="485 412 667 450">Sub-item</th> <th data-bbox="667 412 1374 450">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="485 450 667 539"><i>Priority</i></td> <td data-bbox="667 450 1374 539">Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.</td> </tr> <tr> <td data-bbox="485 539 667 667"><i>CODEC</i></td> <td data-bbox="667 539 1374 667">Seven optional CODECs are supported: <i>G711A, G711U, G729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K).</i></td> </tr> </tbody> </table> <p>See <a href="#">3.3.6 Media Settings</a> for the detailed parameters for each CODEC.</p> <p>The default CODEC for the SIP trunk is the same as that set in <a href="#">3.3.6 Media Settings</a>.</p>	Sub-item	Description	<i>Priority</i>	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.	<i>CODEC</i>	Seven optional CODECs are supported: <i>G711A, G711U, G729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K).</i>
Sub-item	Description						
<i>Priority</i>	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.						
<i>CODEC</i>	Seven optional CODECs are supported: <i>G711A, G711U, G729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K).</i>						

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings. See Figure 3-13 for the SIP Trunk Settings Interface

Check	Index	Remote Address	Remote Port	Local Network Port	Transport Protocol	Outgoing Voice Resource	Incoming Voice Resource	Voice Code List
<input type="checkbox"/>	0	201.123.111.43	5060	LAN 2(201.123.111.125)	UDP	512	512	G711A,G711U,G729,G722,iL
<input type="checkbox"/>	1	11.11.11.100	5060	LAN 1(11.11.11.101)	UDP	512	512	G711A,G711U,G729,G722,iL
<input type="checkbox"/>	2	201.123.111.123	5060	LAN 2(201.123.111.125)	UDP	512	512	G711A,G711U,G729,G722,iL

Figure 3-13 SIP Trunk Settings Interface

Click **Modify** in Figure 3-13 to modify a SIP trunk. See Figure 3-14 for the SIP trunk modification interface. The configuration items on this interface are the same as those on the **Add New SIP Trunk** interface.

The image shows a 'SIP Trunk' configuration window with the following fields and values:

- Index: 0
- Description: default
- Remote Address: 201.123.111.43
- Remote Port: 5060
- Local Network Port: LAN1(201.123.111)
- Display CODEC:
- Transport Protocol: UDP
- Outgoing Voice Resource: 512
- Incoming Voice Resource: 512
- Working Period:  24 Hours

Buttons: Save, Close

Figure 3-14 Modify SIP Trunk

To delete a SIP trunk, check the checkbox before the corresponding index in Figure 3-13 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP trunks at a time, click the **Clear All** button in Figure 3-13.

### 3.3.3 SIP Register

By default, there is no SIP register available on the gateway. Click **Add New** to add them manually. See Figure 3-15.

SIP Register

Index:

SIP Trunk No.:

▼

Username:

Password:

Register Address:

Register Port:

Domain Name:

Register Expires (s):

IMS Network:

▼

Externally Bound Address:

Externally Bound Port:

Authentication Username:


Figure 3-15 Add SIP Register Interface

The table below explains the items shown in the above figure.

Item	Description
<b>Index</b>	The unique index of each SIP register.
<b>SIP Trunk No.</b>	The number of the SIP trunk which registers to the SIP server.
<b>Username</b>	When the gateway initiates a call to SIP, this item corresponds to the username of SIP; when the gateway initiates a call to IP, this item corresponds to the displayed CallerID.
<b>Password</b>	Registration password of the gateway. To register the gateway to the SIP server, both configuration items <b>Username</b> and <b>Password</b> should be filled in.
<b>Register Address</b>	Address of the SIP server to which the SIP trunk is registered.
<b>Register Port</b>	The signaling port of the SIP trunk.
<b>Domain Name</b>	Domain name of the gateway used for SIP registry.

<b>Register Expires</b>	Validity period of the SIP registry. Once the registry is overdue, the gateway should be registered again. Range of value: 10~3600, calculated by s, with the default value of 3600.
<b>IMS Network</b>	Once this feature is enabled, the gateway will send signaling messages to the corresponding externally bound address and port when it registers to the server. Only when this feature is <i>enabled</i> will these items <b>Externally Bound Address</b> , <b>Externally Bound Port</b> and <b>Authentication Username</b> be shown.
<b>Externally Bound Address</b>	Externally bound IP address for registration.
<b>Externally Bound Port</b>	Externally bound port for registration.
<b>Authentication Username</b>	Authentication username for registration.
<b>Remaining Time</b>	Sets the remaining available time for this SIP account to make calls. <b>Note:</b> This configuration item will be displayed only when the configuration item "Time Limit for IMS Outgoing Calls" under SIP Settings is enabled.


After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings. See Figure 3-16 for the SIP Register Information List.



Check	Index	SIP Trunk No.	Username	Register Address	Register Port	Domain Name	Register Expires (s)	Register Status	IMS Network	Externally Bound Address
<input type="checkbox"/>	0	0	123	201.123.115.107	5060	--	3600	Failed	No	--

Figure 3-16 SIP Register Information List

Click **Modify** in Figure 3-16 to modify a SIP register. The configuration items on the SIP Register Modification Interface are the same as those on the **Add New SIP Register** interface.



The image shows a web-based interface for modifying SIP register settings. The window title is "SIP Register". It contains several input fields and dropdown menus, each with a label on the left and a value in the input area. At the bottom, there are two buttons: "Save" and "Close".

Field Label	Value
Index:	0
SIP Trunk No.:	0
Username:	123
Password:	...
Register Address:	201.123.115.107
Register Port:	5060
Domain Name:	
Register Expires (s):	3600
IMS Network:	No
Remaining Time (Min.):	4900

Figure 3-17 SIP Register Modification Interface

To delete a SIP register, check the checkbox before the corresponding index in Figure 3-16 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP registers at a time, click the **Clear All** button in Figure 3-16.

### 3.3.4 SIP Account

By default, there is no SIP account available on the gateway. Click **Add New** to add them manually. See Figure 3-18.




Figure 3-18 Add New SIP Account

The table below explains the items shown in above figures.

Item	Description
<b>Index</b>	The unique index of each SIP account.
<b>SIP Trunk No.</b>	The number of the SIP trunk to which the SIP account is registered.
<b>Username</b>	The registration username of the SIP account. Once the SIP account is successfully registered, the SIP server can initiate calls to the gateway via <b>Username</b> .
<b>Password</b>	The registration password of the SIP account. To register the SIP account to the SIP trunk, both configuration items <b>Username</b> and <b>Password</b> should be filled in.
<b>Register Expires</b>	The validity period of the SIP account registry. Once the registry is overdue, the SIP account should be registered again. Range of value: 10~3600, calculated by s, with the default value of 3600.
<b>Register Status</b>	The registration status of the SIP account. It is either <i>Registered</i> or <i>Failed</i> .
<b>Authentication Username</b>	Authentication username of a port, used to register the port to the SIP server when IMS network is enabled. <b>Note: This item appears only when IMS Network is enabled on the SIP trunk corresponding to this SIP account.</b>
<b>Description</b>	More information about each SIP account.
<b>Remaining Time</b>	Sets the remaining available time for this SIP account to make calls. <b>Note: This configuration item will be displayed only when the configuration item "Time Limit for IMS Outgoing Calls" under SIP Settings is enabled.</b>

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings. See Figure 3-19 for the SIP Account Settings Interface

SIP Account									
Check	Index	SIP Trunk No.	Username	Authentication Username	Register Expires (s)	Register Status	Description	Remaining Time (min.)	Modify
<input type="checkbox"/>	0	0	87	--	3600	Failed	default	5000	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-19 SIP Account Settings Interface

Click **Modify** in Figure 3-19 to modify a SIP account. See Figure 3-20 for the SIP account modification interface. The configuration items on this interface are the same as those on the **Add New SIP Account** interface.

SIP Account

Index:

SIP Trunk No.:  ▼

Username:

Password:

Register Expires (s):

Description:

Remaining Time (Min.):

Figure 3-20 Modify SIP Account

To delete a SIP account, check the checkbox before the corresponding index in Figure 3-19 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP accounts at a time, click the **Clear All** button in Figure 3-19.

### 3.3.5 SIP Trunk Group

By default, there is no SIP trunk group available on the gateway. Click **Add New** to add them manually. See Figure 3-21.

Figure 3-21 Add New SIP Trunk Group

The table below explains the items shown in Figure 3-21.

Item	Description										
<b>Index</b>	The unique index of each SIP trunk group, which is mainly used in the configuration of routing rules and number manipulation rules to correspond to SIP trunk groups.										
<b>Description</b>	More information about each SIP trunk group.										
<b>SIP Trunk Select Mode</b>	<p>When the SIP trunk group receives a call, it will choose a SIP trunk based on the select mode set by this configuration item to ring. The optional values and their corresponding meanings are described in the table below.</p> <table border="1"> <thead> <tr> <th>Option</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><i>Increase</i></td> <td>Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from the minimum.</td> </tr> <tr> <td><i>Decrease</i></td> <td>Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from the maximum.</td> </tr> <tr> <td><i>Cyclic Increase</i></td> <td>Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from SIP Trunk N+1.</td> </tr> <tr> <td><i>Cyclic Decrease</i></td> <td>Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from SIP Trunk N-1.</td> </tr> </tbody> </table>	Option	Description	<i>Increase</i>	Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from the minimum.	<i>Decrease</i>	Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from the maximum.	<i>Cyclic Increase</i>	Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from SIP Trunk N+1.	<i>Cyclic Decrease</i>	Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from SIP Trunk N-1.
Option	Description										
<i>Increase</i>	Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from the minimum.										
<i>Decrease</i>	Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from the maximum.										
<i>Cyclic Increase</i>	Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from SIP Trunk N+1.										
<i>Cyclic Decrease</i>	Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from SIP Trunk N-1.										
<b>SIP Trunks</b>	The SIP trunks in the SIP trunk group. If the checkbox before a SIP trunk is grey, it indicates that the SIP trunk has been occupied. The ticked SIP trunks herein will be displayed in the column 'SIP Trunks' in Figure 3-22.										

After configuration, click **Save** to save the settings into the gateway or click **Cancel** to cancel the settings. See Figure 3-22 for the SIP Trunk Group Setting Interface.

Figure 3-22 SIP Trunk Group Settings Interface

Click **Modify** in Figure 3-22 to modify a SIP trunk group. See Figure 3-23 for the SIP trunk group modification interface. The configuration items on this interface are the same as those on the **Add New SIP Trunk Group** interface.

Modify SIP Trunk Group

Index: 0

Description: default

SIP Trunk Select Mode: Increase

SIP Trunks:  Check All

0  1  2

Save Cancel

Figure 3-23 Modify SIP Trunk Group

To delete a SIP trunk group, check the checkbox before the corresponding index in Figure 3-22 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP trunk groups at a time, click the **Clear All** button in Figure 3-22.

### 3.3.6 Media Settings

Media Parameters

DTMF Transmit Mode	<input type="text" value="RFC2833"/>
RFC2833 Payload	<input type="text" value="101"/>
RTP Port Range	<input type="text" value="6000,20000"/>
Silence Suppression	<input type="text" value="Disable"/>
Noise Reduction	<input type="text" value="Enable"/>
JitterMode	<input type="text" value="Static Mode"/>
JitterBuffer(ms)	<input type="text" value="100"/>
JitterUnderrunLead(ms)	<input type="text" value="100"/>
JitterOverrunLead(ms)	<input type="text" value="50"/>
Voice Gain Output from IP(dB)	<input type="text" value="0"/>

**CODEC Setting**  
 Gateway Negotiation  
 Coding Sequence

Priority	CODEC	Packing Time(ms)	Bit Rate (kbps)
1	G711A	20	64
2	G711U	20	64
3	G729	20	8
4	G722	30	64
5	G723	30	6.3
6	iLBC	20	15.2
7	AMR	20	6.70
8	SILK(16K)	20	20
9	OPUS(16K)	20	20
10	SILK(8K)	20	20
11	OPUS(8K)	20	20

Figure 3-24 Media Settings Interface

See Figure 3-24 for the media settings interface where you can configure the RTP port and payload type depending on your requirements. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.7.20 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-24.

Item	Description
<b>DTMF Transmit Mode</b>	Sets the mode for the IP channel to send DTMF signals. The optional values are <i>RFC2833</i> , <i>In-band</i> , <i>Signaling</i> , <i>RFC2833+Signaling</i> and <i>In-band+Signaling</i> , with the default value of <i>RFC2833</i> .
<b>RFC2833 Payload</b>	Payload of the RFC2833 formatted DTMF signals on the IP channel. Range of value: 90~127, with the default value of 101.
<b>RTP Port Range</b>	Supported RTP port range for the IP end to establish a call conversation, Range of value: 5000~60000, with the lower limit of 5000 and the upper limit of 60000 and the difference between larger than 2048.
<b>Silence Suppression</b>	Sets whether to send comfort noise packets to replace RTP packets or never to send RTP packets to reduce the bandwidth usage when there is no voice signal throughout an IP conversation. The optional values are <i>Enable</i> and <i>Disable</i> , with the default value of <i>Disable</i> . <b>Note:</b> When G723 is selected as CODEC, this configuration setting will turn to <i>Enable</i> automatically.
<b>Noise Reduction</b>	Once this feature is enabled, the volume of the noise accompanied with the line will be reduced automatically. The default setting is <i>Enable</i> .
<b>JitterMode</b>	Sets the working mode of JitterBuffer. The optional values are <i>Static Mode</i> and <i>Adaptive Mode</i> , with the default value of <i>Static Mode</i> .
<b>JitterBuffer</b>	Acceptable jitter for data packets transmission over IP, which indicates the buffering capacity. A larger JitterBuffer means a higher jitter processing capability but as well as an increased voice delay, while a smaller JitterBuffer means a lower jitter processing capability but as well as a decreased voice delay. Range of value: 0~280, calculated by ms, with the default value of 100.
<b>JitterUnderrunLead</b>	Sets the initial delay applied to received packets upon accepting packets later than the expected value set in JitterBuffer Item. Range of value: 0~280, calculated by ms, with the default value of 100, <b>Note:</b> Only when JitterMode is set to <i>Static Mode</i> will this item be shown.
<b>JitterOverrunLead</b>	Sets the beforehand time inserted if receiving packets is ahead of time (the time of receiving is earlier than 300 minus the value set in JitterBuffer). Range of value: 0~280, calculated by ms, with the default value of 50, <b>Note:</b> Only when JitterMode is set to <i>Static Mode</i> will this item be shown.
<b>JitterMin</b>	Sets the minimum delay that can be set by the adaptive jitter function. It must be smaller than the value set in JitterBuffer. Range of value: 0~280, calculated by ms, with the default value of 80. <b>Note:</b> Only when JitterMode is set to <i>Adaptive Mode</i> will this item be shown.
<b>JitterDecreaseRatio</b>	Sets the rate of delay reduction under the adaptive mode. It defines the maximum percentage of the silence that can be removed in delay reduction. Range of value: 0~100, with the default value of 50, <b>Note:</b> Only when JitterMode is set to <i>Adaptive Mode</i> will this item be shown.
<b>JitterIncreaseMax</b>	Sets the maximum delay increased during a silence period. Range of value: 0~280, calculated by ms, with the default value of 30, <b>Note:</b> Only when JitterMode is set to <i>Adaptive Mode</i> will this item be shown.

<p><b>Voice Gain Output from IP</b></p>	<p>Adjusts the voice gain of call from IP to IP. The value must be a multiple of 3. Range of value: -24~24, calculated by dB, with the default value of 0.</p>																																																				
<p><b>CODEC Setting</b></p>	<p>Sets CODECs for the IP end to establish a call conversation. The table below explains the sub-items:</p> <table border="1" data-bbox="486 369 1364 929"> <thead> <tr> <th>Sub-item</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Gateway Negotiation Coding Sequence</td> <td>Sets the coding sequence, including two options: <i>Default Priority</i> and <i>User-defined Priority</i>, with the default value of <i>Default Priority</i>.</td> </tr> <tr> <td>Priority</td> <td>Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.</td> </tr> <tr> <td>CODEC</td> <td>Seven optional CODECs are supported: <i>G711A, G711U, G729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K)</i>.</td> </tr> <tr> <td>Packing Time</td> <td>Time interval for packing an RTP packet, calculated by ms.</td> </tr> <tr> <td>Bit Rate</td> <td>The number of thousand bits (excluding the packet header) that are conveyed per second.</td> </tr> </tbody> </table> <p>By default, all of the eleven CODECs are supported and ordered G711A, G711U, G729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K). by priority from high to low. The CODECs set here will be the default CODEC for the new added SIP trunks.</p> <p>The packing time and bit rate supported by different CODECs are listed in the table below. Those values in bold face are the default values.</p> <table border="1" data-bbox="486 1187 1364 1825"> <thead> <tr> <th>COEDC</th> <th>Packing Time (ms)</th> <th>Bit Rate (kbps)</th> </tr> </thead> <tbody> <tr> <td>G711A</td> <td>10 / <b>20</b> / 30 / 40 / 50 / 60</td> <td><b>64</b></td> </tr> <tr> <td>G711U</td> <td>10 / <b>20</b> / 30 / 40 / 50 / 60</td> <td><b>64</b></td> </tr> <tr> <td>G729</td> <td>10 / <b>20</b> / 30 / 40 / 50 / 60</td> <td><b>8</b></td> </tr> <tr> <td>G722</td> <td>10 / 20 / <b>30</b> / 40</td> <td><b>64</b></td> </tr> <tr> <td>G723</td> <td><b>30</b> / 60</td> <td>5.3 / <b>6.3</b></td> </tr> <tr> <td rowspan="2">iLBC</td> <td><b>20</b> / 40</td> <td><b>15.2</b></td> </tr> <tr> <td>30</td> <td>13.3</td> </tr> <tr> <td rowspan="2">AMR</td> <td>60</td> <td>13.3 / <b>15.2</b></td> </tr> <tr> <td><b>20</b> / 40 / 60</td> <td>4.75 / 5.15 / 5.90 / <b>6.70</b> / 7.40 / 7.95 / 10.20 / 12.20</td> </tr> <tr> <td>SILK(16K)</td> <td><b>20</b> / 40 / 60 / 80 / 100</td> <td><b>20</b></td> </tr> <tr> <td>OPUS(16K)</td> <td>10 / <b>20</b> / 40 / 60</td> <td><b>20</b></td> </tr> <tr> <td>SILK(8K)</td> <td><b>20</b> / 40 / 60 / 80 / 100</td> <td><b>20</b></td> </tr> <tr> <td>OPUS(8K)</td> <td>10 / <b>20</b> / 40 / 60</td> <td><b>20</b></td> </tr> </tbody> </table>	Sub-item	Description	Gateway Negotiation Coding Sequence	Sets the coding sequence, including two options: <i>Default Priority</i> and <i>User-defined Priority</i> , with the default value of <i>Default Priority</i> .	Priority	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.	CODEC	Seven optional CODECs are supported: <i>G711A, G711U, G729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K)</i> .	Packing Time	Time interval for packing an RTP packet, calculated by ms.	Bit Rate	The number of thousand bits (excluding the packet header) that are conveyed per second.	COEDC	Packing Time (ms)	Bit Rate (kbps)	G711A	10 / <b>20</b> / 30 / 40 / 50 / 60	<b>64</b>	G711U	10 / <b>20</b> / 30 / 40 / 50 / 60	<b>64</b>	G729	10 / <b>20</b> / 30 / 40 / 50 / 60	<b>8</b>	G722	10 / 20 / <b>30</b> / 40	<b>64</b>	G723	<b>30</b> / 60	5.3 / <b>6.3</b>	iLBC	<b>20</b> / 40	<b>15.2</b>	30	13.3	AMR	60	13.3 / <b>15.2</b>	<b>20</b> / 40 / 60	4.75 / 5.15 / 5.90 / <b>6.70</b> / 7.40 / 7.95 / 10.20 / 12.20	SILK(16K)	<b>20</b> / 40 / 60 / 80 / 100	<b>20</b>	OPUS(16K)	10 / <b>20</b> / 40 / 60	<b>20</b>	SILK(8K)	<b>20</b> / 40 / 60 / 80 / 100	<b>20</b>	OPUS(8K)	10 / <b>20</b> / 40 / 60	<b>20</b>
Sub-item	Description																																																				
Gateway Negotiation Coding Sequence	Sets the coding sequence, including two options: <i>Default Priority</i> and <i>User-defined Priority</i> , with the default value of <i>Default Priority</i> .																																																				
Priority	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.																																																				
CODEC	Seven optional CODECs are supported: <i>G711A, G711U, G729, G722, G723, iLBC, AMR, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K)</i> .																																																				
Packing Time	Time interval for packing an RTP packet, calculated by ms.																																																				
Bit Rate	The number of thousand bits (excluding the packet header) that are conveyed per second.																																																				
COEDC	Packing Time (ms)	Bit Rate (kbps)																																																			
G711A	10 / <b>20</b> / 30 / 40 / 50 / 60	<b>64</b>																																																			
G711U	10 / <b>20</b> / 30 / 40 / 50 / 60	<b>64</b>																																																			
G729	10 / <b>20</b> / 30 / 40 / 50 / 60	<b>8</b>																																																			
G722	10 / 20 / <b>30</b> / 40	<b>64</b>																																																			
G723	<b>30</b> / 60	5.3 / <b>6.3</b>																																																			
iLBC	<b>20</b> / 40	<b>15.2</b>																																																			
	30	13.3																																																			
AMR	60	13.3 / <b>15.2</b>																																																			
	<b>20</b> / 40 / 60	4.75 / 5.15 / 5.90 / <b>6.70</b> / 7.40 / 7.95 / 10.20 / 12.20																																																			
SILK(16K)	<b>20</b> / 40 / 60 / 80 / 100	<b>20</b>																																																			
OPUS(16K)	10 / <b>20</b> / 40 / 60	<b>20</b>																																																			
SILK(8K)	<b>20</b> / 40 / 60 / 80 / 100	<b>20</b>																																																			
OPUS(8K)	10 / <b>20</b> / 40 / 60	<b>20</b>																																																			

### 3.4 Route Settings

Route Settings is used to specify the routing rules for calls from IP→IP. See Figure 3-25.




Figure 3-25 Route Settings

### 3.4.1 Routing Parameters




Figure 3-26 Routing Parameters Configuration Interface

See Figure 3-26 for the routing parameters configuration interface. On this interface, you can set the routing rules for calls from IP→IP to be routing before or after number manipulation. The default value is *Route before Number Manipulate*.

After configuration, click **Save** to save the above settings into the gateway.

**Note:** This feature is unavailable for SBO2000.

### 3.4.2 IP to IP

By default, there is no IP→IP routing rule available on the gateway. Click **Add New** to add them manually. See Figure 3-27 for the IP→IP routing rule adding interface.




Figure 3-27 Add New Routing Rule (IP→IP)

The table below explains the items shown in the above figure.

Item	Description
<b><i>Index</i></b>	The unique index of each routing rule, which denotes its priority. A routing rule with a smaller index value has a higher priority. If a call matches several routing rules, it will be processed according to the one with the highest priority.
<b><i>Call Initiator</i></b>	SIP trunk group from where the call is initiated. This item can be set to a specific SIP trunk group or SIP Trunk Group [ANY] which indicates any SIP trunk group.

<p><b>CallerID Prefix, CalleeID Prefix</b></p>	<p>A string of numbers at the beginning of the calling/called party number. This item can be set to a specific string or "*" which indicates any string. These two configuration items together with <b>Call Initiator</b> can specify the calls which apply to a routing rule.</p> <p>Rule Explanation:</p> <table border="1" data-bbox="497 405 1361 797"> <thead> <tr> <th>Character</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>"0"~"9"</td> <td>Digits 0~9.</td> </tr> <tr> <td>"[ ]"</td> <td>'[ ]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','; For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.</td> </tr> <tr> <td>"_"</td> <td>'-' is used only in '[ ]' between two numbers to indicates any number between these two numbers.</td> </tr> <tr> <td>","</td> <td>',' is used to separate numbers or number ranges, representing alternatives.</td> </tr> </tbody> </table> <p>Example: Rule "0[0-3,7][6-9]" denotes the prefix is 006, 016, 026, 036, 007, 017, 027, 037, 008, 018, 028, 038, 009, 019, 029, 039, 076, 077, 078, 079.</p> <p><b>Note:</b> Multiple rules are supported for CallerID/CalleeID prefix. They are separated by ":".</p>	Character	Description	"0"~"9"	Digits 0~9.	"[ ]"	'[ ]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','; For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.	"_"	'-' is used only in '[ ]' between two numbers to indicates any number between these two numbers.	","	',' is used to separate numbers or number ranges, representing alternatives.
Character	Description										
"0"~"9"	Digits 0~9.										
"[ ]"	'[ ]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','; For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.										
"_"	'-' is used only in '[ ]' between two numbers to indicates any number between these two numbers.										
","	',' is used to separate numbers or number ranges, representing alternatives.										
<p><b>Call Destination</b></p>	<p>SIP trunk group to which the call will be routed.</p>										
<p><b>Number Filter</b></p>	<p>Number filter rule which will be applicable to this route. It is set in <b>Number Filter</b>. See <a href="#">3.5.4 Filtering Rule</a> for details.</p>										
<p><b>Description</b></p>	<p>More information about each routing rule.</p>										

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings. See Figure 3-28 for the IP→IP Routing Rule Configuration Interface.





Figure 3-28 IP→IP Routing Rule Configuration Interface

Click **Modify** in Figure 3-28 to modify a routing rule. See Figure 3-29 for the IP→IP routing rule modification interface. The configuration items on this interface are the same as those on the **Add New Routing Rule (IP→IP)** interface. Note that the item **Index** cannot be modified.



The screenshot shows a configuration window titled "IP->IP". It contains several input fields and dropdown menus:

- Call Initiator: 255
- Call Source: SIP Trunk Group [0]
- CallerID Prefix: \*
- CalleeID Prefix: \*
- Call Destination: SIP Trunk Group [0]
- Number Filter: No
- Description: default

At the bottom, there are two buttons: "Save" and "Close".

Figure 3-29 Modify Routing Rule (IP→IP)

To delete a routing rule, check the checkbox before the corresponding index in Figure 3-28 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all routing rules at a time, click the **Clear All** button in Figure 3-28.

### 3.5 Number Filter

Number Filter includes four parts: **Whitelist**, **Blacklist**, **Number Pool** and **Filtering Rule**. See Figure 3-30.




Figure 3-30 Number Filter Interface



Figure 3-33 Add New CalleelDs in Whitelist Interface

The table below explains the items shown in above figures.

Item	Description														
<b>Group</b>	The corresponding Group ID for CallerIDs/CalleelDs in the whitelist. The value range is 0~7.														
<b>No. in Group</b>	The corresponding No. for different CallerIDs/CalleelDs in a same group.														
<b>CallerID</b>	<p>CallerID in the whitelist, which must be filled in with numbers or "*" (indicating any string) and can not be left empty.</p> <p>Rule explanation:</p> <table border="1" style="border-style: dashed; width: 100%;"> <thead> <tr> <th>Character</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>"*"</td> <td>indicating any string</td> </tr> <tr> <td>"0"~"9"</td> <td>Digits 0~9.</td> </tr> <tr> <td>"x"</td> <td>A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.</td> </tr> <tr> <td>"[ ]"</td> <td>'[ ]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.</td> </tr> <tr> <td>"_"</td> <td>'_' is used only in '[ ]' between two numbers to indicates any number between these two numbers.</td> </tr> <tr> <td>" , "</td> <td>',' is used to separate numbers or number ranges, representing alternatives.</td> </tr> </tbody> </table>	Character	Description	"*"	indicating any string	"0"~"9"	Digits 0~9.	"x"	A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.	"[ ]"	'[ ]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.	"_"	'_' is used only in '[ ]' between two numbers to indicates any number between these two numbers.	" , "	',' is used to separate numbers or number ranges, representing alternatives.
Character	Description														
"*"	indicating any string														
"0"~"9"	Digits 0~9.														
"x"	A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.														
"[ ]"	'[ ]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.														
"_"	'_' is used only in '[ ]' between two numbers to indicates any number between these two numbers.														
" , "	',' is used to separate numbers or number ranges, representing alternatives.														
<b>CalleelD</b>	CalleelD in the whitelist, which must be filled in with numbers or "*" (indicating any string) and can not be left empty. The rules are the same as that of CallerID.														

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-31 to modify the CallerID or CalleelID whitelist. See Figure 3-34, Figure 3-35 for CallerIDs/CalleelDs on the Whitelist Modification interface. The configuration items on this interface are the same as those on the **Add New CallerIDs/CalleelDs in Whitelist** interface. The item *Group No.* cannot be modified.

Figure 3-34 Modify CallerIDs in Whitelist





New Number Pool interface.

The interface is titled "Number Pool" and contains the following fields and buttons:

- Group:** A dropdown menu with the value "1" selected.
- No. in Group:** A text input field containing the value "0".
- Number Range:** Two text input fields. The first contains "200" and the second contains "201", with a "--" separator between them.
- Buttons:** "Save" and "Close" buttons at the bottom.

Figure 3-39 Modify Number Pool Interface

To delete a number pool, check the checkbox before the corresponding index in Figure 3-37 and click the **Delete** button. To clear all number pools at a time, click the **Clear All** button in Figure 3-37.

### 3.5.4 Filtering Rule

Filtering Rule										
Check	No.	CallerID Whitelist	CalleeID Whitelist	CallerID Blacklist	CalleeID Blacklist	CallerID Pool in Whitelist	CallerID Pool in Blacklist	CalleeID Pool in Whitelist	CalleeID Pool in Blacklist	Original Calle
<input type="checkbox"/>	0	0	none	none	none	0	none	none	none	
<input type="checkbox"/>	1	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	2	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	3	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	4	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	5	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	6	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	7	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	8	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	9	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	10	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	11	none	none	none	none	none	none	none	none	

Buttons: Delete, Clear All, Add New

Page Info: 12 Items Total, 15 Items/Page, 1/1, First, Previous, Next, Last, Go to Page 1, 1 Pages Total

Figure 3-40 Filtering Rule Setting Interface

See Figure 3-40 for the Filtering Rule Setting Interface. A new filtering rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-41 for the Filtering Rule Adding interface.



Figure 3-41 Add New Filtering Rule

The table below explains the items shown in the above figure.

Item	Description
<b>No.</b>	The corresponding number for a filtering rule. The value range is 0~99.
<b>CallerID Whitelist</b>	The Group No. of CallerIDs saved on the whitelist setting interface.
<b>CalleelD Whitelist</b>	The Group No. of CalleelDs saved on the whitelist setting interface.
<b>CallerID Blacklist</b>	The Group No. of CallerIDs saved on the blacklist setting interface.
<b>CalleelD Blacklist</b>	The Group No. of CalleelDs saved on the blacklist setting interface.
<b>CallerID Pool in Whitelist</b>	Select a Group No. which is set in the whitelist from the number pool as the CallerID pool in whitelist.
<b>CallerID Pool in Blacklist</b>	Select a Group No. which is set in the blacklist from the number pool as the CallerID pool in blacklist.
<b>CalleelD Pool in Whitelist</b>	Select a Group No. which is set in the whitelist from the number pool as the CalleelD pool in whitelist.

<b>CalleeID Pool in Blacklist</b>	Select a Group No. which is set in the blacklist from the number pool as the CalleeID pool in blacklist.
<b>Original CalleeID Pool in Whitelist</b>	Select a Group No. which is set in the whitelist from the number pool as the original CalleeID pool in whitelist.
<b>Original CalleeID Pool in Blacklist</b>	Select a Group No. which is set in the blacklist from the number pool as the original CalleeID pool in blacklist.
<b>Description</b>	Remarks for the filtering rule. It can be any information, but can not be left empty.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-40 to modify the filtering rule. See Figure 3-42 for the filtering rule modification interface. The configuration items on this interface are the same as those on the **Add New Filtering Rule** interface.

Figure 3-42 Modify Filtering Rule Interface

To delete a filtering rule, check the checkbox before the corresponding index in Figure 3-40 and

click the **Delete** button. To clear all filtering rules at a time, click the **Clear All** button in Figure 3-40.

### 3.6 Number Manipulation

Number Manipulation includes two parts: **IP→IP CallerID** and **IP→IP CalleeID**. See Figure 3-43.




Figure 3-43 Number Manipulation

#### 3.6.1 IP to IP CallerID

By default, there is no IP→IP CallerID manipulation available on the gateway. Click **Add New** to add them manually. See Figure 3-44 for the IP→IP CallerID manipulation rule adding interface.




Figure 3-44 Add IP→IP CallerID Manipulation Rule

The table below explains the items shown in the above figure.

Item	Description
<b>Index</b>	The unique index of each number manipulation rule, which denotes its priority. A number manipulation rule with a smaller index value has a higher priority. If a call matches several number manipulation rules, it will be processed according to the one with the highest priority.
<b>Call Initiator</b>	SIP trunk group from where the call is initiated. This item can be set to a specific SIP trunk group or SIP Trunk Group[ANY] which indicates any SIP trunk group.
<b>CallerID Prefix, CalleeID Prefix</b>	A string of numbers at the beginning of the calling/called party number. This item can be set to a specific string or "*" which indicates any string. These two configuration items together with <b>Call Initiator</b> and <b>With Original CalleeID</b> can specify the calls which apply to a number manipulation rule. <b>Note:</b> Multiple CallerID/CalleeID Prefixes can be added simultaneously. They are separated by ":".
<b>With Original CalleeID</b>	If this item is set to <b>Yes</b> , it indicates that the number manipulation rule is only applicable to the calls with original CalleeID/redirecting number. The default value is <b>No</b> .
<b>Stripped Digits from Left</b>	The amount of digits to be deleted from the left end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
<b>Stripped Digits from Right</b>	The amount of digits to be deleted from the right end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
<b>Reserved Digits from Right</b>	The amount of digits to be reserved from the right end of the number. Only when the value of this item is less than the length of the current number will some digits be deleted from left; otherwise, the number will not be manipulated.
<b>Prefix to Add</b>	Designated information to be added to the left end of the current number.
<b>Suffix to Add</b>	Designated information to be added to the right end of the current number.
<b>Description</b>	More information about each number manipulation rule.

**Note:** The number manipulation is performed in 5 steps by the order of the following configuration items: **Stripped Digits from Left, Stripped Digits from Right, Reserved Digits from Right, Prefix to Add and Suffix to Add.**

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings. See Figure 3-45 for IP→IP CallerID Manipulation Interface.




Figure 3-45 IP→IP CallerID Manipulation Interface

Click **Modify** in Figure 3-45 to modify a number manipulation rule. See Figure 3-46 for the IP→IP CallerID manipulation rule modification interface. The configuration items on this interface are the same as those on the **Add IP→IP CallerID Manipulation Rule** interface. Note that the item **Index** cannot be modified.

IP->IP CallerID

Index:	<input type="text" value="255"/>
Call Initiator:	<input type="text" value="SIP Trunk Group [0]"/>
CallerID Prefix:	<input type="text" value="*"/>
CalleeID Prefix:	<input type="text" value="*"/>
With Original CalleeID:	<input type="text" value="No"/>
Stripped Digits from Left:	<input type="text" value="0"/>
Stripped Digits from Right:	<input type="text" value="0"/>
Reserved Digits from Right:	<input type="text" value="20"/>
Prefix to Add:	<input type="text"/>
Suffix to Add:	<input type="text"/>
Description:	<input type="text" value="default"/>

Figure 3-46 Modify IP→IP CallerID Manipulation Rule

To delete a number manipulation rule, check the checkbox before the corresponding index in Figure 3-45 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all number manipulation rules at a time, click the **Clear All** button in Figure 3-45.

### 3.6.2 IP to IP CalleeID

The number manipulation process for IP→IP CalleeID is almost the same as that for IP→IP CallerID; only the number to be manipulated changes from CallerID to CalleeID. See Figure 3-47 for IP→IP CalleeID manipulation interface. The configuration items on this interface are the same as those on **IP→IP CallerID Manipulation Interface** (Figure 3-45).

Number Manipulation Rules									
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	With Original CalleeID	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Pr
<input type="checkbox"/>	255	SIP Trunk Group [0]	*	*	No	0	0	20	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-47 IP→IP CalleeID Manipulation Interface

## 3.7 System Tools

System Tools is mainly for gateway maintenance. It provides such features as IP modification, time synchronization, data backup, log inquiry and connectivity check. See Figure 3-48 for details.




Figure 3-48 System Tools

### 3.7.1 Network

Network Settings

**LAN 1**

Network Type (M):

IP Address (I):

Subnet Mask (U):

Default Gateway (D):

DNS Server (P):

**LAN 2**

Network Type (M):

IP Address (I):

Subnet Mask (U):

Default Gateway (D):

DNS Server (P):

**ARP Mode**

Default Mode:

**BOND Setting**

BOND:  Yes  No

**Note:** After IP address modification, please log in again using your new IP address.

Figure 3-49 Network Settings Interface

See Figure 3-49 for the Network Settings interface. A gateway has two network ports, each of which can be configured with independent IP address, subnet mask, default gateway and DNS server. The Bond feature when enabled will make the information of LAN1 and LAN2 duplicated and backed up so as to realize the hot-backup function for LAN1 and LAN2. By default, this feature is *disabled*.

**Note: 1. The two configuration items IP Address and Default Gateway cannot be the same for NET 1 and NET 2.**

**2. By default, *Speed and Duplex Mode* is hidden, set to Automatic Detection. You can**

**click 'F' to let it display. We suggest you do not modify it because the non-automatic detection may cause abnormality in network interface.**

If the Network Detect feature is enabled, a ping test will automatically be initiated from this IP address to the gateway to check the connection status between them. By default, this feature is disabled.

After configuration, click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations. After changing the IP address, you shall log in the gateway again using your new IP address.

**Note:** The BOND setting is unsupported by SBO2000.

## 3.7.2 Management

Management Parameters

<b>WEB Management</b>	
WEB Port	<input type="text" value="80"/>
Access Setting	<input style="width: 100%;" type="text" value="IPs in Whitelist"/> <span style="float: right;">▼</span>
IP Address	<input style="width: 100%;" type="text"/> <span style="float: right; font-size: small;">IP addresses are separated by ','</span>
Time to Log out	<input type="text" value="1800"/> s
<b>SSH Management Config</b>	
SSH	<input checked="" type="radio"/> Yes <input type="radio"/> No
SSH Port	<input type="text" value="22"/>
<b>Remote Data Capture Config</b>	
Remote Data Capture	<input checked="" type="radio"/> Yes <input type="radio"/> No
<input type="checkbox"/> Capture RTP	
<b>FTP Config</b>	
FTP	<input checked="" type="radio"/> Yes <input type="radio"/> No
<b>Telnet Config</b>	
Telnet	<input checked="" type="radio"/> Yes <input type="radio"/> No
<b>Watchdog Setting</b>	
Enable Watchdog	<input checked="" type="radio"/> Yes <input type="radio"/> No
<b>SYSLOG Parameters</b>	
SYSLOG	<input checked="" type="radio"/> Yes <input type="radio"/> No
Server Address	<input type="text" value="127.0.0.1"/>
SYSLOG Level	<input style="width: 100%;" type="text" value="ERROR"/> <span style="float: right;">▼</span>
<b>TLDN Number Manipulate</b>	
TLDN Number Manipulate	<input checked="" type="radio"/> Yes <input type="radio"/> No
CVR Server	<input type="text" value="127.0.0.1"/>
CVR Port	<input type="text" value="4"/>
CVR Local Port	<input type="text" value="5"/>
<b>NAT Parameters</b>	
Monitor Self-adaption	<input checked="" type="radio"/> Yes <input type="radio"/> No
<b>Time Parameters</b>	
NTP	<input checked="" type="radio"/> Yes <input type="radio"/> No
NTP Server Address	<input type="text" value="127.0.0.1"/>
Synchronizing Cycle	<input type="text" value="3600"/> s
Daily Restart	<input checked="" type="radio"/> Yes <input type="radio"/> No
Restart Time	<input type="text" value="7"/> h <input type="text" value="13"/> m
System Time	<input type="checkbox"/> Modify <input type="text" value="2017-06-20 05:24:50"/>
Time Zone	<input type="text" value="GMT+8:00 (Beijing, Singapore, Taipei, Kuala Lumpur)"/> <span style="float: right;">▼</span>

Figure 3-50 Management Parameters Setting Interface

See Figure 3-50 for the Management Parameters Setting interface. The table below explains the items shown in the above figure.

Item	Description
<b>WEB Port</b>	The port which is used to access the gateway via WEB. The default value is 80.
<b>Access Setting</b>	Sets the IP addresses which can access the gateway via WEB. By default, all IPs are allowed. You can set an IP whitelist to allow all IPs within it to access the gateway freely. Also can set an IP blacklist to forbid all IPs within it to access the gateway.
<b>Time to Log Out</b>	The gateway will log out automatically if it is not operated during a time longer than the value of this item, calculated by s, with the default value of 1800.
<b>SSH</b>	Sets whether to enable the gateway to be accessed via SSH, with the default value of <i>No</i> .
<b>SSH Port</b>	The port which is used to access the gateway via SSH.
<b>Remote Data Capture</b>	After this feature is enabled, you can obtain the gateway data via a remote capture tool, with the default value of <i>No</i> .
<b>Capture RTP</b>	Sets whether to capture the RTP. Once this feature is enabled, the RTP package will also be captured by the selected network.
<b>FTP</b>	Sets whether to enable the FTP server, with the default value of <i>Yes</i> .
<b>Telnet</b>	Sets whether to enable the Telnet feature, with the default value of <i>Yes</i> . <b>Note:</b> By default, this configuration item is hidden. To display or hide it, you should click any part of the interface and press the “F” button.
<b>Enable Watchdog</b>	Sets whether to enable the watchdog feature, with the default value of <i>Yes</i> .
<b>SYSLOG</b>	Sets whether to enable SYSLOG. It is required to fill in <b>SYSLOG Server Address</b> and <b>SYSLOG Level</b> in case SYSLOG is enabled. By default, <b>SYSLOG</b> is disabled.
<b>Server Address</b>	Sets the SYSLOG server address for log reception.
<b>SYSLOG Level</b>	Sets the SYSLOG level. There are three options: <i>ERROR</i> , <i>WARNING</i> and <i>INFO</i> .
<b>TLDN Number Manipulate</b>	Once this feature is enabled, the gateway will send the CalleID to the number manipulation server and continue the SIP call progress using the manipulated number when it receives E1 calls. By default, it is <i>disabled</i> . <b>Note:</b> The feature is unsupported by SBO2000.
<b>CVR Server, CVR Port</b>	The IP address/ port of the server to manipulate the CalleID.
<b>CVR Local Port</b>	The port of the SBO gateway.
<b>Monitor Self-adaption</b>	Enable the NAT stun between the gateway and the monitor tool. By default, it is disabled.
<b>NTP</b>	Sets whether to enable the NTP time synchronization feature. It is required to fill in <b>NTP Server Address</b> , <b>Synchronizing Cycle</b> and <b>Time Zone</b> in case NTP is enabled. By default, <b>NTP</b> is disabled.
<b>NTP Server Address</b>	Sets the Server address for NTP time synchronization.
<b>Synchronizing Cycle</b>	Sets the cycle for NTP time synchronization.

<b>Daily Restart</b>	Sets whether to restart the gateway regularly every day at the preset <b>Restart Time</b> . By default, this feature is disabled.
<b>Restart Time</b>	Sets the time to restart the gateway regularly.
<b>System Time</b>	The system time. Check the checkbox before <b>Modify</b> and change the time in the edit box.
<b>Time Zone</b>	The time zone of the gateway.

### 3.7.3 IP Routing Table

IP Routing Table is used to set the route for the LAN port when these two network ports both transport SIP. Thus, the LAN can access some IPs in other different network segment. By default, there is no routing table available on the gateway, click **Add New** to add them manually. See Figure 3-51.




Figure 3-51 Routing Table Adding Interface


The table below explains the items shown in above figures.

Item	Description
<b>No.</b>	The number of the routing for the LAN in routing table.
<b>Destination</b>	The network segment in which the IP address is accessible for the network port.
<b>Subnet Mask</b>	The subnet mask of the network segment.
<b>Network Port</b>	The corresponding network port of the routing.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings. See Figure 3-52 for the Routing Table List.



command. See Figure 3-55.




The screenshot shows a web interface titled "Access Control Command". It features two input fields: "Index" with the value "1" and "Command" which is currently empty. Below the fields are two buttons: "Save" (highlighted in blue) and "Close".

Figure 3-55 Add Access Control Command Interface

Input a piece of command into the Command item and click **Save** to save the settings to the gateway. Click **Close** to cancel your settings. After that, click **Apply** to make the new command valid.

Click **Modify** in Figure 3-54 to modify a command. See Figure 3-56 for the Access Control Command Modification interface. The configuration items on this interface are the same as those on the **Add Access Control Command** interface. Note that the item **Index** cannot be modified.



The screenshot shows a web interface titled "Access Control Command". It features two input fields: "Index" with the value "0" and "Command" with the text "iptables -I INPUT -s 123.45.6.7 -j DROP". Below the fields are two buttons: "Save" (highlighted in blue) and "Close".

Figure 3-56 Access Control Command Modification Interface

To delete an Access Control Command, check the checkbox before the corresponding index in Figure 3-54 and click the **Delete** button, and then click the **Apply** button to make the deleted command invalid. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all access control commands at a time, click the **Clear All** button in Figure 3-54.

**Note:** 1, Currently, only the command iptables is supported by the gateway.

- 2, When you add or modify or delete commands manually, don't forget to click the **Apply** button to make your settings valid. However, when the gateway restarts or the configuration is leading-in, you need not click the **Apply** button and the commands will get valid automatically.

### 3.7.5 Centralized Manage

Centralized Manage

Centralized Manage	<input checked="" type="checkbox"/> Enable
Auto Change Default Gateway:	<input type="checkbox"/> Enable
Management Platform:	DCMS
Company Name:	<input type="text"/>
Gateway Description:	<input type="text"/>
Centralized Management Protocol:	SNMP
SNMP Version:	V2
SNMP Server Address:	127.0.0.1
<input type="checkbox"/> Monitoring Port	162
Community String:	public
Working Status:	Not Enabled

Figure 3-57 Centralized Manage Setting Interface

See Figure 3-57 for the Centralized Manage Setting interface. The gateway can register to a centralized management platform and accept the management of the platform. The table below explains the items shown in above figures.

Item	Description
<b>Auto Change Default Gateway</b>	Once this feature is enabled, the gateway will connect the DCMS via another network port automatically once the connected network cable is loosen or drawn out. The default value is disabled.
<b>Management Platform</b>	Select a management platform for the gateway to register.
<b>Company Name</b>	The company name used to register the gateway to DCMS, only valid when DCMS is selected.
<b>Gateway Description</b>	The description displayed on DCMS after the gateway is registered to DCMS, giving an easy identification of the gateway in device grouping. This item is only valid when DCMS is selected.
<b>Centralized Management Protocol</b>	Sets the centralized management protocol. It only supports SNMP currently.
<b>SNMP Version</b>	Sets the version of SNMP, three options available: V1, V2 and V3, with the default value of V2.
<b>SNMP Server Address</b>	IP address of SNMP.

<b>Monitoring Port</b>	Monitoring Port for SNMP on the gateway.
<b>Community String</b>	Community string used for information acquisition.
<b>Account</b>	The account of SNMP, only valid when the SNMP version is set to V3.
<b>Grade</b>	The grade of SNMP, three options available: Neither authenticated nor encrypted, Authenticated but not encrypted and Authenticated and encrypted, with the default value of <i>Neither authenticated nor encrypted</i> . It is only valid when the SNMP version is set to V3.
<b>Authentication Password</b>	The authentication password required to enter when the item Grade is set to Authenticated but not encrypted or Authenticated and encrypted.
<b>Encryption Password</b>	The encryption password required to enter when the item Grade is set to Authenticated and encrypted.
<b>Working Status</b>	The status of the connection between the gateway and the centralized management server. It is only valid when DCMS is selected.

### 3.7.6 SIP Account Generator




Figure 3-58 SIP Account Generator Interface

See Figure 3-58 for the SIP Account Generator interface. The gateway allows to transform the common SIP account and password to the specific format it supports, upload a file containing the SIP account and password, and modify the SIP Trunk No., Registration Validity Period, Registration Address and Description according to your requirement. Click **Save** to save your settings and upload the SIP account source file again. Then the SIP account in the format that the gateway supports will be generated. Click **Download** to check the generated SIP account.

Note: As to the upload file, only the txt. format is supported at present, and the SIP account and password must be separated by “,”.

### 3.7.7 Configuration File




Figure 3-59 Configuration File Interface

See Figure 3-59 for the Configuration File interface, including two files: SMGConfig.ini and ShConfig.ini. You can check and modify the items in these configuration files through this interface. Configurations about the gateway server, such as route rules, number manipulation, number filter and so on, are included in SMGConfig.ini; Configurations about the board are included in ShConfig.ini. You can modify these configurations on the interface directly, and then click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations.

### 3.7.8 Signaling Capture

The screenshot displays the 'Data Capture' and 'Two-way Recording' sections of the Signaling Capture interface. The 'Data Capture' section includes a dropdown menu for 'Choose a network interface to capture Data' set to 'LAN 1(201.123.111.17)', a checked 'Capture RTP' checkbox, an empty text field for 'Please designate the calling number to capture RTP!', and a text field for 'Destination address for syslog' set to '201.123.111.254'. There are 'Start' and 'Stop' buttons. The 'Two-way Recording' section has two rows of controls. The first row has dropdowns for 'Channel G' and 'Channel 0', with 'Start' and 'Stop' buttons. The second row has dropdowns for 'Channel G' and 'Channel 16', with 'Start' and 'Stop' buttons. At the bottom, there are 'Clean Data' and 'Download Log' buttons.

Figure 3-60 Signaling Capture Interface

See Figure 3-60 for the Signaling Capture interface. Data Capture is used to capture data on the network interface you choose. Click **Start** to start capturing data (up to 800M) on the corresponding network interface. SIP and SysLog are supported at present. You can input a destination address for syslog to which the syslog file will be sent. Click **Stop** to stop data capture and download the captured packets. Once the option Capture RTP is ticked, you are required to input the calling number of the RTP to be captured.

IP Two-way Recording is used to make recording of a designated channel in a specified channel group. Click **Start** to start recording data (maximum consecutively recording time: 1 minute). Click **Stop** to stop data recording and download the recorded data.

Click **Clean Data** to clean all the recording files and captured packages. Click **Download Log** to download such logs as core files, configuration files, error information and so on.

### 3.7.9 Signaling Call Test

Figure 3-61 Signaling Call Test Interface

See Figure 3-61 for the Signaling Call Test interface. This feature can help to test whether the route and the number manipulation already configured are proper or not, and whether the call can succeed or not.

The table below explains the configuration items shown in the above figure.

Item	Description
<b>Test Type</b>	The source trunk type for signaling call test.
<b>SIP Trunk Group No.</b>	The SIP trunk group number you are required to select.

<b>CallerID</b>	The CallerID for the signaling call test.
<b>CalleeID</b>	The CalleeID for the signaling call test.
<b>DTMF</b>	You can select this item to send DTMFs after the establishment of call conversation on the channel for call test.
<b>Add Invite Header, Field Name, Field Content</b>	You can add the invite header and its corresponding content.
<b>Signaling Trace</b>	The information returned during the signaling call test, helping you to learn the detailed information about the test call.

After configuration, click **Start** to execute the signaling call test; click **Clear** to clear the signaling trace information.

**Note:** The call test will be finished only if the called party ends it. That is, the gateway can not stop the testing.

### 3.7.10 Signaling Call Track




Figure 3-62 Call Track Interface

See Figure 3-62 for the Call Track Interface, including three modes: Filter CallerID, Filter CalleeID and Filter None. This is mainly used to output and save call information, facilitating call trace and problem debugging. Click **Start** to track calls, and the trace logs will be shown in the “Track Message” field; click **Stop** to stop the call track; click **Filter** to filter the trace logs according to the condition you set; click **Clear** to clear all trace logs; click **download** to download trace logs.

### 3.7.11 Network Speed Tester




Figure 3-63 Network Speed Tester Interface

See Figure 3-63 for the Network Speed Tester interface, which is used to test the network speed of the outer net where the gateway locates. Click **start**, it will select an optimal outer net to do the test. All the testing information will be displayed in the Info column.

### 3.7.12 PING Test

Figure 3-64 Ping Test Interface

See Figure 3-64 for the Ping Test interface. A Ping test can be initiated from the gateway on a designated IP address to check the connection status between them. The table below explains the configuration items shown in the above figure.

Item	Description
<b>Source IP Address</b>	Source IP address where the Ping test is initiated.
<b>Destination Address</b>	Destination IP address on which the Ping test is executed.
<b>Ping Count</b>	The number of times that the Ping test should be executed. Range of value: 1~100.
<b>Package Length</b>	Length of a data package used in the Ping test. Range of value: 56~1024 bytes.
<b>Info</b>	The information returned during the Ping test, helping you to learn the network connection status between the gateway and the destination address.

After configuration, click **Start** to execute the Ping test; click **End** to terminate it immediately.

### 3.7.13 TRACERT Test

Figure 3-65 Tracert Test Interface

See Figure 3-65 for the Tracert Test interface. A Tracert test can be initiated from the gateway on a designated IP address to check the routing status between them. The table below explains the configuration items shown in the above figure.

Item	Description
<b>Source IP Address</b>	Source IP address where the Tracert test is initiated.
<b>Destination Address</b>	Destination IP address on which the Tracert test is executed.
<b>Maximum Jumps</b>	Maximum number of jumps between the gateway and the destination address, which can be returned in the Tracert test. Range of value: 1~255.
<b>Info</b>	The information returned during the Tracert test, helping you to learn the detailed information about the jumps between the gateway and the destination address.

After configuration, click **Start** to execute the Tracert test; click **End** to terminate it immediately.

### 3.7.14 Modification Record

The screenshot displays a window titled "Modification Record" containing a list of log entries. Each entry includes a timestamp, a modification type (e.g., Mod, Add, Del), the configuration file path, and the specific parameter being changed. Below the list are two buttons: "Check" and "Download". A red note at the bottom states: "Note: Only the latest 100 pieces of modification record will be displayed. To check all the records, please click the Download button."

Timestamp	Modification Type	Configuration File	Parameter	Value	Source IP	
2017-04-17 10:42:44	Mod	Config/SMGConfig.ini-SIP4CALLOUT-siptrunks_regexpires0	3600	-->	201.123.115.107	
2017-04-17 10:42:44	Add	Config/SMGConfig.ini-SIP4CALLOUT-siptrunks_outboundaddress0	-1	-->	201.123.115.107	
2017-04-17 10:42:44	Add	Config/SMGConfig.ini-SIP4CALLOUT-siptrunks_outboundport0	-1	-->	201.123.115.107	
2017-04-17 10:42:44	Add	Config/SMGConfig.ini-SIP4CALLOUT-siptrunks_authusername0	-1	-->	201.123.115.107	
2017-04-17 10:42:45	Del	Config/SMGConfig.ini-SIPACCOUNT-sip_account0			201.123.115.107	
2017-04-17 10:42:45	Mod	Config/SMGConfig.ini-SIPACCOUNT-sip_account_max	1	-->	201.123.115.107	
2017-04-17 10:42:59	Mod	Config/SMGConfig.ini-SIP4CALLOUT-siptrunks_username0	-->	123	201.123.115.107	
2017-04-17 10:42:59	Mod	Config/SMGConfig.ini-SIP4CALLOUT-siptrunks_password0	-->	123	201.123.115.107	
2017-04-17 10:42:59	Mod	Config/SMGConfig.ini-SIP4CALLOUT-siptrunk_registeraddress0	-->	201.123.115.107	201.123.115.107	
2017-04-17 10:42:59	Mod	Config/SMGConfig.ini-SIP4CALLOUT-siptrunk_registerport0	-->	5060	201.123.115.107	
2017-04-17 10:42:59	Mod	Config/SMGConfig.ini-SIP4CALLOUT-siptrunks_regexpires0	-->	3600	201.123.115.107	
2017-04-17 10:42:59	Mod	Config/SMGConfig.ini-SIP4CALLOUT-siptrunks_register0	0	-->	1	
2017-04-17 10:45:28	Mod	Config/SMGConfig.ini-SysInfo-Language	1	-->	0	
2017-04-17 10:50:14	Mod	Config/SMGConfig.ini-SysInfo-Language	0	-->	1	
2017-04-17 10:50:53	Mod	Config/SMGConfig.ini-SysInfo-Language	1	-->	0	
2017-04-17 10:51:14	Mod	Config/SMGConfig.ini-SysInfo-Language	0	-->	1	
2017-04-17 10:54:22	Mod	Config/SMGConfig.ini-SysInfo-Language	1	-->	0	
2017-04-17 10:55:30	Mod	Config/SMGConfig.ini-ROUTE_IP2IP-Route0	255 0 * * 0 默认	-1	-->	255 0 * * 0 default -1
2017-04-17 10:59:25	Mod	Config/SMGConfig.ini-SysInfo-Language	0	-->	1	
2017-04-17 11:00:19	Mod	Config/SMGConfig.ini-SysInfo-Language	1	-->	0	
2017-04-17 11:01:03	Mod	Config/SMGConfig.ini-SysInfo-Language	0	-->	1	
2017-04-17 11:02:25	Mod	Config/SMGConfig.ini-SysInfo-Language	1	-->	0	

Figure 3-66 Modification Interface

The Modification Record interface is used to check the modification record on the web configuration. Click **Check** and the modification record will be shown on the dialog box. See Figure 3-66. Click **Download** to download the record file.

### 3.7.15 Backup & Upload

The screenshot shows two sections: "Data Backup" and "Data Upload". In the "Data Backup" section, there is a dropdown menu set to "Configuration file" and a "Backup" button. In the "Data Upload" section, there is a dropdown menu set to "Configuration file", a text input field, a "Browse..." button, and an "Upload" button. Instructions for each section are provided above the respective controls.

Figure 3-67 Backup & Upload Interface

See Figure 3-67 for the Backup and Upload interface. To back up data to your PC, you shall first

choose the file in the pull-down list and then click **Backup** to start. To upload a file to the gateway, you shall first choose the file type in the pull-down list, then select it via **Browse...**, and at last click **Upload**. The gateway will automatically apply the uploaded data to overwrite the current configurations.

### 3.7.16 Factory Reset



Figure 3-68 Factory Reset Interface

See Figure 3-68 for the Factory Reset interface. Click **Reset** to restore all configurations on the gateway to factory settings.

### 3.7.17 Upgrade




Figure 3-69 Upgrade Interface

See Figure 3-69 for the upgrade interface where you can upgrade the WEB, gateway service, kernel and firmware to new versions. Select the upgrade package “\*.tar.gz” via **Browse...** and click **Update** (The gateway will do MD5 verification before upgrading and will not start to upgrade until it passes the verification). Wait for a while and the gateway will finish the upgrade automatically. Note that clicking **Reset** can only delete the selected update file but not cancel the operation of **Update**.

### 3.7.18 Change Password



Change Password

Current Username

Current Password

New Username

New Password

Confirm New password

Note: The username and the password can consist only of numbers, letters or the underline.

Figure 3-70 Password Changing Interface

See Figure 3-70 for the Password Changing interface where you can change username and password of the gateway. Enter the current password, the new username and password, and then confirm the new password. After configuration, click **Save** to apply the new username and password or click **Reset** to restore the configurations. After changing the username and password, you are required to log in again.

### 3.7.19 Device Lock



Device Lock

Please select the condition to lock the device (Note: You are required to input the password before you modify any configuration of the selected items.)

IP  SIP

Password

Confirm Password

Figure 3-71 Device Lock Configuration Interface


See Figure 3-71 for the Device Lock Configuration interface. When you select one or more than one conditions to lock the gateway, the configurations of the gateway related to the selected conditions will be locked. That is, to modify any one of those configurations, you are required to input the lock password. Click **Lock** after setting and the device lock interface will be locked. To unlock the interface, enter your password (just the lock password) and click the **Unlock** button.



The image shows a web interface titled "Device Lock". It features a light blue header with the title. Below the header is a grey area with the label "Password" on the left and a white text input field on the right. At the bottom of the interface, there are two blue buttons: "Unlock" on the left and "Reset" on the right.

Figure 3-72 Unlock Device Interface

### 3.7.20 Restart



The image shows a web interface with two sections. The top section is titled "Service Restart" and contains the text "Click the button 'Restart' to restart the service." followed by a blue "Restart" button. The bottom section is titled "System Restart" and contains the text "Click the button 'Restart' to restart the system." followed by a blue "Restart" button.

Figure 3-73 Service/System Restart Interface

See Figure 3-73 for the Restart interface. Click **Restart** on the service restart interface to restart the gateway service or click **Restart** on the system restart interface to restart the whole gateway system.

## Chapter 4 Typical Applications




Figure 4-1 Application 1

1. Configure SIP Settings.

Figure 4-2

2. Add the IP addresses of the SIP terminal.

Figure 4-3

3. Add the SIP trunks into the corresponding SIP trunk groups.



Figure 4-4

4. Set routing parameters. You may adopt the default value 'Route before Number Manipulate' for both configuration items.




Figure 4-5

5. Set IP→IP routing rules to route calls from different SIP trunk groups to the corresponding SIP trunk groups.




Figure 4-6

6. Set number manipulation rules. When the gateway receives a call from IP, it will first check the CalleeID prefix. If the CalleeID prefix is 7 or 8, the gateway will delete it before routing the call to the corresponding SIP trunk group.




Figure 4-7

# Appendix A Technical Specifications

## Dimensions

SBO500: 440×44×267 mm<sup>3</sup>

SBO2000: 440×44×690 mm<sup>3</sup>

## Weight

SBO500: About 3.1 kg

SBO2000: About 12kg

## Environment

Operating temperature: 0 °C—40 °C

Storage temperature: -20 °C—85 °C

Humidity: 8%— 90% non-condensing

Storage humidity: 8%— 90% non-condensing

## NET

Amount: 2 (10/100/1000 BASE-TX (RJ-45))

Self-adaptive bandwidth supported

Auto MDI/MDIX supported

## Console Port

Amount: 1 (RS-232), 8 (USB\*2)

Baud rate: 115200bps

Connector: RJ45 (See [Hardware Description](#) for signal definition)

Data bits: 8 bits

Stop bit: 1 bit

Parity unsupported

Flow control unsupported

Note: Follow the above settings to configure the console port; or it may work abnormally.

## Power Requirements

Input power: 100~240V AC

Maximum power consumption:

SBO500: ≤22W

SBO2000: ≤167W

## Signaling & Protocol

SIP signaling: SIP V1.0/2.0, RFC3261

## Audio Encoding & Decoding

G.711A 64 kbps

G.711U 64 kbps

G.729 8 kbps

G723 5.3/6.3 kbps

G722 64 kbps

AMR 4.75/5.15/5.90/6.70/7.40/7.95/10.20/12.20 kbps

iLBC 15.2 kbps

SILK(16K) 20 kbps

OPUS(16K) 20 kbps

SILK(8K) 20 kbps

OPUS(8K) 20 kbps

## Sampling Rate

8kHz

## Safety

Lightning resistance: Level 4

## Appendix B Troubleshooting

### 1. What to do if I forget the IP address of the SBO gateway?

Long press the Reset button on the gateway to restore to factory settings. Thus the IP address will be restored to its default value:

NET1: 192.168.1.101

NET2: 192.168.0.101

### 2. In what cases can I conclude that the SBO gateway is abnormal and turn to Synway's technicians for help?

- a) During runtime, the run indicator does not flash or the alarm indicator lights up or flashes, and such error still exists even after you restart the device or restore it to factory settings.
- b) Voice problems occur during call conversation, such as that one party or both parties cannot hear the voice or the voice quality is unacceptable.

Other problems such as abnormal SIP trunk status, inaccessible calls, failed registrations and incorrect numbers are probably caused by configuration errors. We suggest you refer to [Chapter 3 WEB Configuration](#) for further examination. If you still cannot figure out or solve your problems, please feel free to contact our technicians.

### 3. What to do if I cannot enter the WEB interface of the SBO gateway after login?

This problem may happen on some browsers. To settle it, follow the instructions here to configure your browser. Enter 'Tools > Internet Options > Security Tab', and add the current IP address of the gateway into 'Trusted Sites'. If you change the IP address of the gateway, add your new IP address into the above settings.

## Appendix C Technical/sales Support

Thank you for choosing Synway. Please contact us should you have any inquiry regarding our products. We shall do our best to help you.

### Headquarters

Synway Information Engineering Co., Ltd

<http://www.synway.net/>

9F, Synway D&R Center, No.3756, Nanhuan Road, Binjiang District, Hangzhou, P.R.China, 310053

Tel: +86-571-88860561

Fax: +86-571-88850923

Wechat QR Code: Scan the QR code below to add us on Wechat.



### Technical Support

Tel: +86-571-88864579

Mobile: +86-18905817070

Email: [techsupport@sanhuid.com](mailto:techsupport@sanhuid.com)

Email: [techsupport@synway.net](mailto:techsupport@synway.net)

MSN: [synway.support@hotmail.com](mailto:synway.support@hotmail.com)

### Sales Department

Tel: +86-571-88860561

Tel: +86-571-88864579

Fax: +86-571-88850923

Email: [sales@synway.net](mailto:sales@synway.net)