




A74GA Series Motherboard

User's Manual

Statement:

This manual is the intellectual property of Foxconn, Inc. Although the information in this manual may be changed or modified at any time, Foxconn does not obligate itself to inform the user of these changes.

Trademark:

All trademarks are the property of their respective owners.

Version:

User's Manual V1.1 for A74GA Series motherboard.

P/N: 3A222C500-000-G

Symbol description:



Caution : refers to important information that can help you to use motherboard better, and tells you how to avoid problems.



Warning : indicating a potential risk of hardware damage or physical injury may exist.



WEEE:

The use of this symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased this product.

More information:

If you want more information about our products, please visit Foxconn's website: <http://www.foxconnchannel.com>

© All rights reserved.

All trade names are registered trademarks of respective manufacturers listed.

All images are for reference only, please refer to the physical motherboard for specific features.

Declaration of conformity



HON HAI PRECISION INDUSTRY COMPANY LTD
66 , CHUNG SHAN RD., TU-CHENG INDUSTRIAL DISTRICT,
TAIPEI HSIEN, TAIWAN, R.O.C.

declares that the product
Motherboard A74GA

is in conformity with
(reference to the specification under which conformity is declared in
accordance with 89/336 EEC-EMC Directive)

- EN 55022:1998/A2: 2003 Limits and methods of measurements of radio disturbance characteristics of information technology equipment
- EN 61000-3-2:2000 Electromagnetic compatibility (EMC)
Part 3: Limits
Section 2: Limits for harmonic current emissions
(equipment input current $\leq 16A$ per phase)
- EN 61000-3-3/A1:2001 Electromagnetic compatibility (EMC)
Part 3: Limits
Section 2: Limits of voltage fluctuations and flicker in low voltage supply systems for equipment with rated current $\leq 16A$
- EN 55024/A2:2003 Information technology equipment-Immunity characteristics limits and methods of measurement

Signature :

A handwritten signature in black ink, appearing to read 'James Liang'. The signature is fluid and cursive, with a large, stylized 'L' at the end.

Place / Date : TAIPEI/2010

Printed Name : James Liang

Declaration of conformity



Trade Name:	FOXCONN
Model Name:	A74GA
Responsible Party:	PCE Industry Inc.
Address:	458 E. Lambert Rd. Fullerton, CA 92835
Telephone:	714-738-8868
Facsimile:	714-738-8838
Equipment Classification:	FCC Class B Subassembly
Type of Product:	Motherboard
Manufacturer:	HON HAI PRECISION INDUSTRY COMPANY LTD
Address:	66 , CHUNG SHAN RD., TU-CHENG INDUSTRIAL DISTRICT, TAIPEI HSIEN, TAIWAN, R.O.C.

Supplementary Information:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Tested to comply with FCC standards.

Signature :

A handwritten signature in black ink, appearing to read 'James Liang', with a stylized flourish at the end.

Date : 2010

Installation Precautions



- Electrostatic discharge (ESD) is the sudden and momentary electric current that flows between two objects at different electrical potentials. Normally it comes out as a spark which will quickly damage your electronic equipment. Please wear an electrostatic discharge (ESD) wrist strap when handling components such as a motherboard, CPU or memory.
- Ensure that the DC power supply is turned off before installing or removing CPU, memory, expansion cards or other peripherals. It is recommended to unplug the AC power cord from the power supply outlet. Failure to unplug the power supply cord may result in serious damage to your system.



Please carefully read the following procedures to install your computer :

- It is suggested to select high-quality, certified fans in order to avoid damage to the motherboard and CPU due to high temperature. Never turn on the computer if the CPU fan is not properly installed.
- We cannot guarantee that your system can operate normally when your CPU is overclocked. Normal operation depends on the overclocking capacity of your device.
- If there is any, when connecting USB, audio, RS232 COM, IrDA or S/PDIF cables to the internal connectors on the motherboard, make sure their pinouts are matching with the connectors on the motherboard. Incorrect connections might damage the motherboard.
- When handling the motherboard, avoid touching any metal leads or connectors.
- If there is a PCI Express x16 graphics card installed in your system, we recommend using a 24-pin ATX power supply to get the best performance.
- Before turning on the power, please make sure the power supply AC input voltage setting has been configured to the local standard.
- To prevent damage to the motherboard, do not allow screws to come in contact with the motherboard circuit or its components. Also, make sure there are no leftover screws or metal components placed on the motherboard or within the computer casing.
- If you are uncertain about any installation steps or have a problem related to the use of the product, please consult a certified computer technician.



TABLE OF CONTENTS

Chapter 1 Product Introduction

Product Specifications	2
Layout	4
Back Panel Connectors	5

Chapter 2 Hardware Install

Install the CPU and CPU Cooler	8
Install the Memory	10
Install an Expansion Card	12
Install other Internal Connectors	13
Jumpers	17
Install driver and utility	19

Chapter 3 BIOS Setup

Enter BIOS Setup	22
Main Menu	22
System Information	24
Advanced BIOS Features	26
Core Releaser	28
Fox Central Control Unit	29
Advanced Chipset Features	32
Integrated Peripherals	35
Power Management Setup	39
PC Health Status	41
BIOS Security Features	42
Load Optimal Defaults	43
Save & Exit Setup	43
Exit Without Saving	43

Chapter 4 RAID Configuration

RAID Introduction	45
Install SATA Hard Disks	46
RAID Configuration	46
Create RAID Driver Disk	48
Install Windows OS	49

Technical Support :



Support

Website :

<http://www.foxconnchannel.com>

Support Website :

<http://www.foxconnsupport.com>

Worldwide Online Contact Support :

<http://www.foxconnsupport.com/inquiry.aspx>

CPU Support List :

<http://www.foxconnsupport.com/cpusupportlist.aspx>

Memory, VGA Compatibility List :

<http://www.foxconnsupport.com/complist.aspx>



Thank you for buying Foxconn A74GA Series motherboard. Foxconn products are engineered to maximize computing power, providing only what you need for break-through performance.

With advanced overclocking capability and a range of connectivity features for today multi-media computing requirements, A74GA enables you to unleash more power from your computer.

This chapter includes the following information:


- Product Specifications
- Layout
- Back Panel Connectors

1-1 Product Specifications

CPU	Support AM3 socket & Phenom™ II processors, Max processor power up to 95W For the latest CPU information, please visit: http://www.foxconnsupport.com/cpusupportlist.aspx
HyperTransport	2000MT/s
Chipset	North Bridge: AMD RS740G South Bridge: AMD SB710
Memory	4 x 240-pin DDR3 DIMM sockets Support up to 16GB memory size Dual channel DDR3 1333/1066MHz architecture
Audio	Realtek ALC662 audio chip: - High Definition Audio - 2/4/5.1-channel - Support Jack-Sensing function
LAN	Realtek RTL8111DL Gigabit LAN chip
Expansion Slots	1 x PCI Express x16 slot 1 x PCI Express x1 slot 3 x PCI slots
Storage	SB710 chipset: - 6 x SATA connectors - 300MB/s data transfer rate - Support RAID 0, 1, 10
USB	Support hot plug Support up to 12 x USB 2.0 ports (6 rear panel ports, 3 onboard USB headers supporting 6 extra ports) Support USB 2.0 protocol up to 480Mb/s
VGA	Integrated ATI Radeon2100 Graphics Support DirectX 9.0
Internal Connectors	1 x 24-pin ATX main power connector 1 x 4-pin ATX 12V power connector 1 x IDE connector 6 x SATA connectors 3 x USB 2.0 connectors (supporting 6 x USB devices) 1 x CPU fan header (4-pin) 1 x System fan header (4-pin) 1 x NB fan header (4-pin) 1 x Front Audio connector 1 x CD_IN connector 1 x Speaker connector 1 x Front panel connector 1 x Chassis intrusion alarm header (INTR) 1 x LPT header
Back Panel Connectors	1 x PS/2 keyboard port 1 x PS/2 mouse port

	1 x VGA port 1 x Serial port 6 x USB 2.0 ports 1 x RJ-45 LAN port 6-channel Audio ports
Hardware Monitor	System voltage detection CPU/System temperature detection CPU/System fan speed detection CPU/System fan speed control
PCI Express x1	Support 250MB/s (500MB/s concurrent) bandwidth Low power consumption and power management features
PCI Express x16	Support 4GB/s (8GB/s concurrent) bandwidth Low power consumption and power management features
Green Function	Support EuP Function Support ACPI (Advanced Configuration and Power Interface) Support S0 (normal), S1 (power on suspend), S3 (suspend to RAM), S4 (suspend to disk), and S5 (soft - off)
Bundled Software	FOX ONE FOX LiveUpdate FOX LOGO FOX DMI
Operating System	Support for Microsoft® Windows® 7/Vista/XP
Form Factor	ATX Form Factor, 12 inches x 8.6 inches (30.5cm x 21.8cm)


1-2 Layout



- | | |
|-----------------------------------|--------------------------------|
| 1. 4-pin ATX 12V Power Connector | 14. Front USB Connectors |
| 2. USB_PWR4 Jumper | 15. USB_PWR3 Jumper |
| 3. USB_PWR1 Jumper | 16. Front Panel Connector |
| 4. NB_FAN Header | 17. USB_PWR2 Jumper |
| 5. North Bridge: AMD RS740G | 18. SATA Connectors |
| 6. PCI Express x16 Slot | 19. IDE Connector |
| 7. Chassis Intrusion Alarm Header | 20. Speaker Connector |
| 8. PCI Express x1 Slot | 21. SYS_FAN Header |
| 9. PCI Slots | 22. 24-pin ATX Power Connector |
| 10. CD_IN Connector | 23. South Bridge: AMD SB710 |
| 11. Front Audio Connector | 24. DDR3 DIMM Slots |
| 12. LPT Connector (Optional) | 25. CPU_FAN Header |
| 13. Clear CMOS Jumper | 26. CPU Socket |

Note : The above motherboard layout is for reference only, please refer to the physical motherboard for detail.

1-3 Back Panel Connectors



1. PS/2 Mouse Port

Use the upper port (green) to connect a PS/2 mouse.

2. PS/2 Keyboard Port

Use the lower port (purple) to connect a PS/2 keyboard.

3. VGA Port

To connect with external display devices, such as monitor or LCD display.

4. Serial Port

This is output of RS232 COM1 port.

5. USB Ports

The USB ports support the USB 2.0/1.1 specification. Use these ports for USB devices such as an USB keyboard/mouse, USB printer, USB flash drive and etc.

6. Audio Ports


For the definition of each audio port, please refer to the table below :

Port	2-channel	4-channel	5.1-channel
Blue	Line In	Rear Speaker Out	Rear Speaker Out
Green	Line Out	Front Speaker Out	Front Speaker Out
Pink	Microphone In	Microphone In	Center/Subwoofer Out

7. RJ-45 LAN Port

The Ethernet LAN port provides Internet connection at up to 10/100/1000Mb/s data rate.

LAN Type	Left: Active		Right: Link	
	Status	Description	Status	Description
1000M	Off	No Link	Off	No Link
	Green Blinking	Data Activity	Off	10 Mb/s Connection
			Green	100 Mb/s Connection
			Orange	1000 Mb/s Connection



2

This chapter introduces the hardware and software installation process, including the installation of the CPU, memory, power supply, slots, pin headers and the mounting of jumpers. Caution should be exercised during the installation of these modules. Please refer to the motherboard layout prior to any installation and read the contents in this chapter carefully.

This chapter includes the following information :

- Install the CPU and CPU Cooler
- Install the Memory
- Install an Expansion Card
- Install other Internal Connectors
- Jumpers
- Install driver and utility



Please visit the following website for more supporting information about your motherboard.

CPU Support List:

<http://www.foxconnsupport.com/cpusupportlist.aspx>

Memory, VGA Compatibility List:

<http://www.foxconnsupport.com/complst.aspx>

2-1 Install the CPU and CPU Cooler






Read the following guidelines before you begin to install the CPU:

- Make sure that the motherboard supports the CPU.
- Always turn off the computer and unplug the power cord from the power supply before installing the CPU to prevent hardware damage.
- Locate the Pin-1 of the CPU. The CPU cannot be inserted if oriented incorrectly.
- Apply an even and thin layer of thermal grease on the surface of the CPU.
- Do not turn on the computer if the CPU cooler is not installed, otherwise overheating and damage of the CPU may occur.
- Set the CPU host frequency in accordance with the CPU specifications. It is not recommended that the system bus frequency be set beyond hardware specifications since it does not meet the standard requirements for the peripherals. If you want to set the frequency beyond the standard specifications, please do so according to your hardware specifications including the CPU, graphics card, memory, hard drive, etc.

Install the CPU

Locate the Pin-1 CPU triangle mark and the Pin-1 of the CPU socket.



1. Release the CPU socket lever.



2. Align Pin-1 of the CPU with the CPU socket, and gently put the CPU onto the socket.



3. When CPU is properly seated, push the CPU socket lever back to its locked position.

Install the CPU Cooler

Follow the steps below to correctly install the CPU cooler. (The following procedures use Foxconn cooler as the example.)




1. Apply and spread an even thermal grease on the surface of CPU.



2. Buckle the heatsink firmly at one side of the stand.



3. Buckle the heatsink at another side, and press the fasten lever down to tightly seat the cooler.



4. Attach the CPU cooler connector to the CPU fan header on the motherboard .



Use extreme care when removing the CPU cooler because the thermal grease may adhere to the CPU. Inadequately removing the CPU cooler may damage the CPU.

2-2 Install the Memory



Read the following guidelines before you begin to install the memory :

- Make sure that the motherboard supports the memory. It is recommended that memory of the same capacity, brand, speed, and chips be used.
- Always turn off the computer and unplug the power cord from the power outlet before installing the memory to prevent hardware damage.
- Memory modules have a foolproof design. A memory module can be installed in only one direction. If you are unable to insert the memory, switch the direction.

Dual Channel Memory Configuration

This motherboard provides four DDR3 memory sockets and supports Dual Channel Technology. When memory is installed, the BIOS will automatically check the memory in your system.

Four DDR3 memory sockets are divided into two channels :

Channel 0 : DIMM1, DIMM2

Channel 1 : DIMM3, DIMM4

The combinations of DIMM modules are :

	DIMM1	DIMM2	DIMM3	DIMM4
Single Channel	DS/SS	-	-	-
Single Channel	DS/SS	DS/SS		-
Single Channel	-	-	DS/SS	-
Single Channel	-	-	DS/SS	DS/SS
Dual Channel	DS/SS	-	DS/SS	-
Dual Channel	-	DS/SS	-	DS/SS
Dual Channel	DS/SS	DS/SS	DS/SS	DS/SS

(DS : Double Side, SS : Single Side, - : No Memory)




It is recommended that memory of the same capacity, brand, speed, and chips be used and please select dual channel first to achieve optimum performance.


Installing a Memory



Before installing a memory module, make sure to turn off the computer and unplug the power cord from the power outlet to prevent damage to the memory module. Be sure to install DDR3 DIMMs on this motherboard.




If you take a look at front side of memory module, it has asymmetric pin counts on both sides separated by a notch in the middle, so it can only fit in one direction. Follow the steps below to correctly install your memory modules into the sockets.



Step 1:

Spread the clips at both ends of the memory socket. Place the memory module onto the socket, then put your fingers on top edge of the module, and push it down firmly and seat it vertically into the memory socket.




Step 2:

The clips at both ends of the socket will snap into place when the memory module is securely inserted.

2-3 Install an Expansion Card



- Make sure the motherboard supports the expansion card. Carefully read the manual that came with your expansion card.
- Always turn off the computer and unplug the power cord from the power outlet before installing an expansion card to prevent hardware damage.



PCI Express x1



PCI Express x16



PCI



Follow the steps below to correctly install your expansion card in the expansion slot.


1. Locate an expansion slot that supports your card. Remove the metal slot cover from the chassis back panel.
2. Align the card with the slot, and press down on the card until it is fully seated in the slot.
3. Make sure the metal contacts on the card are completely inserted into the slot.
4. Secure the card's metal bracket to the chassis back panel with a screw.
5. After installing all expansion cards, replace the chassis cover.
6. Turn on your computer. If necessary, go to BIOS Setup to make any required BIOS changes for your expansion card(s).
7. Install the driver provided with the expansion card in your operating system.

Installing and Removing a PCI Express x16 Graphics Card :



• Installing a Graphics Card:

Gently insert the graphics card into the PCI Express x16 slot. Make sure the graphics card is locked by the latch at the end of the PCI Express x16 slot.



• Removing the Card:

Push the latch at the end of the PCI Express x16 slot to release the card and then pull the card straight up from the slot.



2-4 Install other Internal Connectors

Power Connectors

This motherboard uses an ATX power supply. In order not to damage any device, make sure all the devices have been installed properly before applying the power supply.

24-pin ATX power connector : PWR1


PWR1 is the ATX power supply connector. Make sure that the power supply cable and pins are properly aligned with the connector on the motherboard. Firmly plug the power supply cable into the connector and make sure it is secure.



Pin #	Definition	Pin #	Definition
1	3.3V	13	3.3V
2	3.3V	14	-12V
3	GND	15	GND
4	+5V	16	PS_ON(Soft On/Off)
5	GND	17	GND
6	+5V	18	GND
7	GND	19	GND
8	Power Good	20	NC
9	+5V SB(Stand by +5V)	21	+5V
10	+12V	22	+5V
11	+12V	23	+5V
12	3.3V	24	GND




We recommend you using a 24-pin power supply. If you are using a 20-pin power supply, you need to align the ATX power connector according to the picture.



20-Pin Power

4-pin ATX 12 V Power Connector : PWR2

Connect the 4-pin ATX 12V power supply to PWR2 and provides power to the CPU.



Pin #	Definition
1	GND
2	GND
3	+12V
4	+12V

Front Panel Connector : FP1

This motherboard includes one connector for connecting the front panel switch and LED Indicators.

Hard Disk LED Connector (HDD-LED)

Connect to the chassis front panel IDE indicator LED. It indicates the active status of the hard disks. This 2-pin connector is directional with +/- sign.

Reset Switch (RESET-SW)

Attach the connector to the Reset switch on the front panel of the case; the system will restart when the switch is pressed.

Power LED Connector (PWR-LED)




Connect to the power LED indicator on the front panel of the chassis. The Power LED indicates the system's status. When the system is in operation (S0 status), the LED is on. When the system gets into sleep mode (S1), the LED is blinking; When the system is in S3/S4 sleep state or power off mode (S5), the LED is off. This 2-pin connector is directional with +/- sign.

Power Switch Connector (PWR-SW)

Connect to the power button on the front panel of the chassis. Push this switch allows the system to be turned on and off rather than using the power supply button.


Serial ATA Connectors : SATA_1/2/3/4/5/6

The Serial ATA connector is used to connect with SATA Hard Disk or CD devices which support this feature. The current Serial ATA II interface allows up to 300MB/s data transfer rate.




Audio Connector : CD_IN

CD_IN is a Sony standard audio connector, it can be connected to a CD/DVD-ROM drive through a CD/DVD audio cable.




Audio Connector : F_AUDIO

The audio connector supports HD Audio standard. It provides the Front Audio output choice.




Chassis Intruder Alarm Connector : INTR

The connector can be connected to a security switch on the chassis. The system can detect the chassis intrusion through the function of this connector. If eventually the chassis is closed, the system will send a message out.



LPT Connector : LPT

The connector supports parallel port which can be connected to a printer or a scanner. System usually assign IRQ7 as it's default interrupt request and the parallel port has three operation mode: [SPP], [EPP], [ECP].




IDE Connector : PIDE

With the provided Ultra DMA IDE ribbon cable, you can connect to any IDE type of hard disk and CD/DVD ROM/RW drive.


USB Connectors : F_USB 1/2/3

In addition to the USB ports on the rear panel, this product also provides three 10-pin USB headers on its motherboard. By connecting through USB cables with them, user can quickly expand another six USB ports on the front panel.



Fan Connectors : CPU_FAN, SYS_FAN,NB_FAN



There are three main fan headers on this motherboard. The fan speed can be controlled and monitored in “PC Health Status” section of the BIOS Setup. These fans can be automatically turned off after the system enters S3, S4 and S5 sleeping states.



CPU_FAN/SYS_FAN/
NB_FAN

Speaker Connector : SPEAKER

The speaker connector is used to connect speaker of the chassis.



SPEAKER

2-5 Jumpers

For some features needed, users can change the jumper settings on this motherboard to modify them. This section explains how to use the various functions of this motherboard by changing the jumper settings. Users should read the following content carefully prior to modifying any jumper setting.

Description of Jumpers

- For any jumper on this motherboard, pin 1 can be identified by the bold silkscreen next to it. However, in this manual, pin 1 is simply labeled as "1".
- The following table explains different types of the jumper settings. "Closed" means placing a jumper cap on the two pins to temporarily short them. The shorting can also be done by touching two pins by a screwdriver for a few seconds, but using jumper cap is recommended. It can prevent hazardous ESD (Electrical Static Discharge) problem.


Jumper	Diagram	Definition	Description
1 □ □ □	1 ■ ■ □	1-2	Set Pin 1 and Pin 2 closed
	1 □ ■ ■	2-3	Set Pin 2 and Pin 3 closed

Clear CMOS Jumper: CLR_CMOS

The motherboard uses CMOS RAM to store the basic hardware information (such as BIOS data, date, time information, hardware password...etc.). Clear CMOS data is the fast way to go back to factory default when the BIOS settings were mistakenly modified.

The steps to clear CMOS data are :

- Turn off the computer, unplug the power cord from the power outlet.
- Remove jumper cap from pins 2-3, put it onto pins 1-2 to short them. This will clear CMOS data.
- Return the setting to its original with pins 2-3 closed.
- Plug in the power cord to your computer and turn it on.
- Go to BIOS Setup to configure new system as described in next chapter.





- Disconnect the power cable before adjusting the jumper settings.
- Do not clear the CMOS while the system is turned on.

USB device wake-up Jumper: USBPWR1 / USBPWR2/ USBPWR3 / USBPWR4

1. Set the jumper to pins 1-2 (+5V) to wake up the computer from S1 sleep mode using the connected USB devices.
2. Set the jumper to pins 2-3 (+5VSB) to wake up the computer from S3 and S4 sleep modes using the connected USB devices. At the same time, a corresponding setting must be set in BIOS as below:

Set "CMOS Setup" -> "Power Management Setup" -> "USB Wake Up From S3" to "Enabled".





- USBPWR2/ USBPWR3 is for the internal USB connectors, USBPWR1/ USBPWR4 is for the rear USB ports.
- The USB device wake-up feature requires a power supply that can provide 500mA on +5VSB lead for each USB port; otherwise, the system will not power up.
- The total current consumed must not exceed the power supply capability (+5VSB) whether under normal condition or in sleep mode.

2-6 Install driver and utility

This motherboard comes with one DVD, after installing the Operating System, you can simply put it into your DVD-ROM drive, and the main menu will be displayed on your PC screen to guide you how to install.

1. Driver

Use these options to install all the drivers for your system. You must click "AMD Chipset Driver" to install it first. After that, you can click "One Click Setup" and then choose the items you want to install, or you can click on each individual driver to install it manually.



2

2. Utility

Use these options to install additional software programs. And click "Utility Help" button to view the utility (FOX ONE, FOX LiveUpdate, FOX LOGO, FOX DMI) help manual.



3

This chapter tells how to change system settings through the BIOS Setup menus. Detailed descriptions of the BIOS parameters are also provided.

You have to run the Setup Program when the following cases occur:

1. An error message appears on the screen during the system Power On Self Test (POST) process.
2. You want to change the default CMOS settings.

This chapter includes the following information :

- Enter BIOS Setup
- Main Menu
- System Information
- Advanced BIOS Features
- Core releaser
- Fox Central Control Unit
- Advanced Chipset Features
- Integrated Peripherals
- Power Management Setup
- PC Health Status
- BIOS Security Features
- Load Optimal Defaults
- Save & Exit Setup
- Discard Changes and Exit



Since BIOS could be updated some other times, the BIOS information described in this manual is for reference only. We do not guarantee the content of this manual will remain consistent with the newly released BIOS at any given time in the future. Please visit our website for updated manual if it is available.

Enter BIOS Setup


The BIOS is the communication bridge between hardware and software, correctly setting up the BIOS parameters is critical to maintain optimal system performance. Power on the computer, when the message "**Press to enter Setup, <ESC> to boot menu**". appears at the bottom of the screen, you can press key to enter SETUP.



We do not suggest that you change the default values in the BIOS Setup, and we shall not be responsible for any damage which resulted from the change you made.

Main Menu

The main menu allows you to select from a list of setup functions together with two exit choices. Use the arrow keys to select a specific item and press <Enter> to go to the submenu.



Each item in the main menu is explained below:

► System Information

It displays the basic system configuration, such as BIOS ID, CPU Name, memory size plus system date, time and Floppy drive. They all can be viewed or set up through this menu.

► Advanced BIOS Features

The advanced system features can be set up through this menu. There are boot up settings.

► Core Releaser (Enabled only if CPU supports)

The Core Releaser function can be set up through this menu. Setting Options are [Auto] and [Disabled].

[Auto]: the 2 or 3 cores can be upgraded to 4 cores.

[Disabled]: the system will downloading default CPU core.

When the message "**Press <F3> to Setup Core Releaser,** " appears at the bottom of the screen, you can press <F3> key to set the Core Releaser to auto.



We do not guarantee all used 2 or 3 cores can be upgraded to 4 cores. If system halt or PC can not enter the Operating System, Please press and hold the Power Button until the PC powers off and restart your PC. If PC still does not work at all, it mean that this function can not be enabled. You need clear CMOS or enter BIOS manual to set disable to load default.

► **Fox Central Control Unit**

Some special proprietary features (such as overclocking) can be set up through this menu.

► **Advanced Chipset Features**

The values for the chipset can be changed through this menu, and the system performance can be optimized.

► **Integrated Peripherals**

All onboard peripherals can be set up through this menu. There are IDE devices, Super I/O devices such as Serial I/O and other USB devices... etc.

► **Power Management Setup**

All the items related with Green function features can be set up through this menu.

► **PC Health Status**

This setup enables you to read/change Fan speeds, and displays temperatures and voltages of your CPU/System.

► **BIOS Security Features**

The Supervisor/User password can be set up through this menu to prevent unauthorized use of your computer. If you set a password, the system will ask you to key in correct password before boot or access to Setup.

► **Load Optimal Defaults**

The optimal performance settings can be loaded through this menu.

► **Save & Exit Setup**


Save setting values to CMOS and exit.

► **Discard Changes and Exit**

Don't save any modifications and exit.

System Information

This sub-menu is used to set up the standard BIOS features, such as the date, time, floppy drive and so on. Use the arrow up/down keys to select an item, then use the <+> or <-> keys to change the setting.



► Date (mm:dd:yy)

<weekday><month><date> <year> format.

Day—weekday from Sun. to Sat., this message is automatically displayed by BIOS (Read Only).

Month—month from 1 to 12.

Date—date from 1st to 31st.

Year—year, set up by users.

Use [ENTER], [TAB] or [SHIFT-TAB] to select a field. Use [+] or [-] to input the value.

► Time (hh:mm:ss)

This item allows you to configure the desired time. Use [ENTER] to enter the setting, then use [TAB] to move forward a field. Use [+] or [-] to input the value.

The three fields of the setting are <hour> : <minute> : <second> respectively.

► IDE Master/Slave, SATA1#/SATA2#/SATA3#/SATA4#/SATA5#/SATA6#

While entering setup, BIOS automatically detects the presence of IDE devices. This item displays the drive information of IDE devices.

► Halt On

This category determines whether or not the computer will stop if an error is detected during powering up.

[All Errors] : All errors can result in system halt.

[All Errors But...] : All errors but keyboard or mouse or floppy can result in system halt. The halt condition can be enabled/disabled in the next two settings.

► Keyboard

The system boot will not stop for a keyboard error if you enabled this item.

► Mouse

The system boot will not stop for a mouse error if you enabled this item.

► **Model Name**

Model name of this product.

► **BIOS ID**

It displays the current BIOS ID. User can check this information and discuss with the field service people if a BIOS upgrade is needed.

► **BIOS Version**

It displays the current BIOS version. User can check this information and discuss with the field service people if a BIOS upgrade is needed.

► **Memory Size**

This item displays the current memory size. The size is depending on how many memory modules were installed in your system before powering on.


► **MAC Address**

This item shows the onboard LAN MAC address.

► **CPU Name**

It displays the current CPU name.

Advanced BIOS Features



► IDE Detect Time Out

This item is used to select the time out value for detecting ATA/ATAPI devices. If the checking time is over the set value, the system will skip it.

► MPS Revision

This feature is only applicable to multiprocessor motherboards as it specifies the version of the MPS that the motherboard will use. The MPS is a specification by which PC manufacturers design and build CPU architecture systems with two or more processors. MPS 1.1 was the original specification. MPS version 1.4 adds extended configuration tables for improved support of multiple PCI bus configurations and greater expandability in the future. In addition, MPS 1.4 introduces support for a secondary PCI bus without requiring a PCI bridge. If your operating system comes with support for MPS 1.4, you should keep the setting as the default 1.4. You also need to enable MPS 1.4 support if you need to make use of the secondary PCI bus on a motherboard that doesn't come with a PCI bridge. You should only leave it as 1.1 only if you are running an older operating system that only supports MPS 1.1.

► PCI Latency Timer

This item is used to set the PCI latency timer. The value is in unit of PCI cycle for PCI device latency timer register. Setting values are 32, 64, 96, 128, 160, 192, 224, 248.

This feature controls how long each PCI device can hold the bus before another takes over. The larger the value, the longer the PCI device can retain control of the bus. Low values for the PCI Latency Timer will reduce the effective PCI bandwidth while higher values means every PCI device will have to wait longer before they can get access to the bus, but when they do get access, they can conduct their transactions for a longer time. Normally, a default value of 64 cycles is set. Some PCI devices may not agree with longer latency times so if you start facing problems like stuttering sound or a less responsive system, reduce the latency. Higher values will actually reduce performance as too much time may be allocated to each PCI device to the disadvantage of other devices on the bus.

► Quiet Boot

This item is used to enable/disable the quiet boot.

[Disabled] : Displays the normal POST messages.

[Enabled] : Displays logo instead of POST messages.


► **Quick Boot**

While Enabled, this option allows BIOS to skip certain tests while booting, this will shorten the time needed to boot the system.

► **Bootup Num-Lock**

This item defines if the keyboard Num Lock key is active when your system is started. The available settings are: On (default) and Off.


Core Releaser



► Advanced Clock Calibration

This option is used to disable or auto the Core Releaser. The default value: [Disabled].

Fox Central Control Unit



► Super BIOS Protect

To protect the system BIOS from virus attack, there is a BIOS write-protection mechanism provided. Super BIOS Protect function protects your BIOS from being affected by viruses, e.g. CIH.


► Auto Detect PCI Clock

This option is used to auto detect PCI slot. When enabled, the system will turn off clock of the empty PCI slot to reduce EMI (Electromagnetic Interference).

► Smart BIOS / Fox Intelligent Stepping / CPU Configuration

Press <Enter> to go to its submenu.

Smart BIOS



► Smart Power LED

Smart Power LED is a feature built on your motherboard to indicate different states during

Power-On Self-Test (POST). The LED is located at the front panel, and it displays POST state by different long-short blinking intervals. You can always leave this state enabled.

System Status	Power LED Status
Normal	On
No CPU Fan	Blinking once (blinking 0.5 sec., off 0.5 sec.)
No Display	Blinking once (blinking 2 sec., off 2 sec.)
No Memory	Blinking twice
Post Error Message	Blinking thrice

3

► **Smart Boot Menu**

When PC starts, it will ask you to press [Del] key to enter setup or press [Esc] key to enter smart boot menu. If [Disabled] is selected, then pressing [Esc] has no function.

Fox Intelligent Stepping

CMOS Setup Utility - Copyright (C) 1985-2006, American Megatrends, Inc.
Fox Intelligent Stepping

CPU Clock	[200]	Help Item
Current CPU Speed	: 2800MHz, NB CLK: 2000	
CPU Multiplier Adjust	[Auto]	
CPU-NB HT Link Speed	[Auto]	
Current FSB/HTT Speed	: 1000MHz	
Memory Speed Mode	[Auto]	
Current DRAM Speed	: N/A, 1066 MHz,	
PCI Express Clock	[100]	
Spread Spectrum	[Enabled]	
Memory Voltage Control	[Disabled]	
DRAM Voltage	: 1.584 V	
NB Voltage Control	[1.2V]	

↑↓←→:Move Enter:Select +/-:Value F10:Save ESC:Exit F1:General Help
F9:Optimized Defaults

► **CPU Clock**

This option is used to adjust the CPU clock.

► **CPU Multiplier Adjust (Optional only if CPU supports)**

This option is used to adjust the CPU Clock Ratio. Multiply CPU clock with this ratio, you can get the CPU speed. Increase this ratio may overclock your CPU. This option will be displayed only if your CPU is supporting this feature.

► **CPU-NB HT Link Speed**

HT stands for HyperTransport bus. The CPU<->NB HT Speed option controls the physical speed of the CPU to Northbridge HT link. The physical speed of the link is determined by multiplying the CPU clock with the CPU<->NB HT Speed setting.

► **Memory Speed Mode**

This item is used to enable/disable provision of DRAM timing by SPD device. The Serial Presence Detect (SPD) device is a small EEPROM chip, mounted on a DDR3 memory module. It contains important information about the module's speed, size, addressing mode

and various other parameters, so that the memory controller can better access the memory device.

Select [Auto] for SPD enable mode.

Select [Limit], the DRAM speed will not exceed the specified value listed in the "Memory Speed Adjust" item. If SPD value is faster than "Memory Speed Adjust" value, it will run at the specified "Memory Speed Adjust" speed. Otherwise, SPD value is selected.

Select [Manual], then DRAM speed is manually selected according to the set value of "Memory Speed Adjust".

► **PCI Express Clock**

This option is used to adjust the speed of PCI Express slot. It increase transfers speed between chipset and graphics.

► **Spread Spectrum**

If you enabled this function, it can significantly reduce the EMI (Electromagnetic Interference) generated by the system, so to comply with FCC regulation. But if overclocking is activated, you had better disable it for more stability.


► **Memory Voltage Control**

This option is used to change the DRAM voltage in a step of 0.1V. The voltage can be incremented from 1.7V to 1.9V.

► **NB Voltage Control**

This option is used to increase the NB voltage.

CPU Configuration



This menu shows most of the CPU specifications.


► **Cool 'N' Quiet (Appear only when CPU supports)**

This option helps lowering down the CPU frequency and voltage when system is idling. When the CPU speed is slowing down, the temperature will drop as well.

► **C1E Support (Appears only when CPU supports)**

C1E represents Enhanced HALT State. It is a feature which CPU uses to reduce power consumption when in halt state. C1E drops the CPU's multiplier and voltage to lower levels when a HLT (halt) command is issued. This item is used to enable/disable the C1E support.

Advanced Chipset Features



► Memory Configuration/DRAM Timing Configuration

Press <Enter> to go to its submenu.

► CAS Latency

This item shows the CAS latency. The CAS Latency is the number of clock cycles that elapse from the time the request for data is sent to the actual memory location until the data is transmitted from the module.

► RAS/CAS Delay

This item displays a delay time (in clock cycles) between the CAS and RAS strobe signals.

► Row Precharge Time

This item shows the number of clock cycles taken between issuing of the precharge command and the active command. The DRAM row precharge time is in unit of clock cycle.

► Min Active RAS

Displays the number of clock cycles taken between a bank active command and issuing of the precharge command.

► RAS/RAS Delay

This item displays a delay time (in clock cycles) between the RAS and RAS strobe signals.

► Row Cycle

This item shows the minimum timing interval between successive active commands to the same bank. The row cycle time is in unit of clock cycle.

► Internal Graphics Mode

Enable/Disable the integrated graphics.

► Surround View

SurroundView is the ATI technology that provides multi-graphics controller display capability for both the ATI PCIe-based graphics card and the ATI integrated graphics processor (IGP). Enabling SurroundView does not impact display modes (resolution and color depth) or performance. The display mode of each output is controlled independently by the graphics controller connected to it.


1. When using a non-ATI PCI Express (PCIe) graphics card, SurroundView is not supported.

The integrated graphics processor (IGP) is automatically disabled, and the system memory

allocated to the IGP is freed for other use.

2. When installing an ATI PCIe graphics card, SurroundView is disabled by default. Enabling SurroundView in the BIOS enables the integrated graphics. which in turn makes available up to two additional graphics outputs.

Memory Configuration



► DCT Unganged Mode

DCT stands for DRAM Controller.

Ganged refers to the use of both DRAM controllers within a memory controller acting in concert to access memory. For a description of ganged (128-bit DRAM data width) and unganged (64-bit DRAM data width) DRAM modes :

Ganged channels (DDR3) :

- DCT channels A and B can be ganged as a single logical 128-bit DIMM.
- Offers highest DDR3 bandwidth.
- Requires both DIMMs in a logical pair to have identical size and timing parameters, both DCTs programmed identically.


Unganged channels

- DCT channels A and B operate as two completely independent 64-bit channels (both channels operate at the same frequency).
- Reduce DRAM page conflicts – more concurrent open dram pages.
- Better bus efficiency.

Burst lengths supported

When both DCTs are enabled in unganged mode, BIOS must initialize the frequency of each DCT in order.


DRAM Timing Configuration



► DRAM Timing Mode

When both DCTs (DRAM controller) are enabled in unganged mode, BIOS must initialize the frequency of each DCT in order, you also can configure the timings manually. Settings are : [Auto], [DCT 0], [DCT 1], [Both].
[DCT 1] and [Both] will appear only in AM2+ or AM3 CPU.

Integrated Peripherals



► IDE Configuration / USB Configuration / SuperIO Configuration

Press <Enter> to go to relative submenu.

► OnBoard LAN

This item is used to enable or disable the onboard LAN controller.


► OnBoard LAN Boot ROM

This item is used to enable or disable the onboard LAN boot optional ROM. A LAN boot ROM lets you set up a diskless workstation on the network. By installing a boot ROM in the network board, you can enable a client PC system on the network to be booted remotely.

► HD Audio Controller

This item is used to enable or disable the HD Audio Controller.

IDE Configuration



► OnBoard PCI IDE Controller

[Disabled]: Disable the integrated IDE controller.

[Enabled]: Enable the integrated IDE controller.

► OnChip SATA Channel

[Disabled] : Disable SATA controller.

[Enabled] : Enable SATA controller.

► OnChip SATA Type

This item is used to set the operating mode of your SATA ports.

Options : [Native IDE]; [RAID]; [AHCI]; [Legacy IDE].

[Native IDE] - This configures the SATA ports to support native IDE mode.

[RAID] - When you enable RAID, it means all your SATA drives must also support AHCI.

[AHCI] - The Advanced Host Controller Interface (AHCI) specification describes the register level interface for a Host Controller for Serial ATA. The specification includes a description of the hardware/software interface between system software and the host controller hardware. AHCI provides more advanced features including SATA features, but some SATA drives may not support AHCI, unless they are labeled with AHCI support in its specification.

If you have a SATA device which supports AHCI, then you can select IDE option to have fair performance (only PATA, SATA level), or you can select AHCI to get its best performance.


[Legacy IDE] - This configures the SATA ports to support legacy IDE mode which is running for old Windows system .

► SATA IDE Combined Mode

[Enable]: SATA5 and SATA6 support IDE mode only, and onboard PCI IDE controller must be enabled.

[Disable]: SATA5 and SATA6 support AHCI mode and RAID mode only.

USB Configuration




► Legacy USB Support

This item is used to enable the support for USB devices on legacy OS. If you have a USB keyboard or mouse, set to auto or enabled.

► USB 2.0 Controller Mode

This item is used to set the transmission rate mode of USB 2.0. The available settings are : [High Speed] in 480Mb/s; [Full Speed] in 12Mb/s.

SuperIO Configuration



► Serial Port1 Address

This item is used to assign the I/O address and interrupt request (IRQ) for the onboard serial port 1.

► Serial Port1 Mode

This item enables you to determine the transfer mode of the serial port 1.

► Parallel Port Address

This item is used to assign the I/O address and interrupt request (IRQ) for the onboard parallel port.


► Parallel Port Mode

This item enables you to determine the transfer mode of the parallel port.

► Parallel Port IRQ

This item is used to assign interrupt request (IRQ) for the onboard parallel port.

Power Management Setup



ACPI (Advanced Configuration and Power Interface) is an open industry standard interfaces enabling OS-directed configuration, power management, and thermal management of mobile, desktop, and server platforms. It defines five sleeping states, they are :

- S1 - The S1 sleeping state is a low wake latency sleeping state. In this state, no system context is lost (CPU or chip set) and hardware maintains all system context. (also called **Power On Suspend**)
- S3 - The S3 sleeping state is a low wake latency sleeping state where all system context is lost except system memory. CPU, cache, and chip set context are lost in this state. Hardware maintains memory context and restores some CPU and L2 configuration context. Control starts from the processor's reset vector after the wake event. (also called **Suspend to RAM**)
- S4 - The S4 sleeping state is the lowest power, longest wake latency sleeping state supported by ACPI. In order to reduce power to a minimum, it is assumed that the hardware platform has powered off all devices. Platform context is maintained. (also called **Suspend to Disk**)
- S5 - The S5 state is similar to the S4 state except that the OS does not save any context. The system is in the "soft" off state and requires a complete boot when it wakes. Software uses a different state value to distinguish between the S5 state and the S4 state to allow for initial boot operations within the BIOS to distinguish whether or not the boot is going to wake from a saved memory image.

► ACPI Suspend Type

This item is used to set the energy saving mode of the ACPI function. When you select "S1 (POS)" mode, the power is always on and computer can be resumed at any time. When you select "S3 (STR)" mode, the power will be down after a period of time. The status of the computer before it entering STR will be saved in memory, and the computer can quickly return to previous state when the STR function wakes.

► HPET Support

HPET stands for High Precision Even Timer. If you have the HPET disabled, then windows does not have access to it and therefore falls back to less accurate timing methods. This item is used to enable or disable the HPET Support.

► Energy-using Products

This item is used to enable/disable the EuP(Energy-using Products) feature. When enable, the suspend power of the chipset will be cut off in S5 suspend mode in order to reduce the power consumption of motherboard.

Enable: S1/S3/S4 is normal, S5 wake up only by pressing the power button.

Disable: Normal ACPI function.

► Resume by LAN

This item is used to enable/disable the LAN to generate a wake up.

► Resume by PCI Card

This item is used to enable/disable the PCI card to generate a wake up.

► Resume by PCIE Card

This item is used to enable/disable the PCIE card to generate a wake up.

► Resume by USB Devices

This item is used to enable/disable the USB keyboard and mouse to generate a wake up.

► Resume by PS2 Keyboard

This item is used to enable/disable the PS2 keyboard to generate a wake up.

► Resume by PS2 Mouse


This item is used to enable/disable the PS2 mouse to generate a wake up.

► Resume by RTC

This item is used to enable/disable RTC alarm event to generate a wake up.

RTC is system real time clock.

PC Health Status



Warning Temperature

This option is used to set the warning temperature for the system. When the temperature of CPU is higher than the set value, the motherboard will warn by beep or speaker.

Shut Down Temperature

This item is used to set the system temperature upper limit. When the temperature exceeds the set value, the system will shut down automatically.

This function works only when your operating system is supporting ACPI.

Case Open Warning

This item is used to enable or disable case open warning function. If your chassis support Case Open function, enable this item. It halt and show some warning message on POST after your chassis be opened.

CPU/System Temperature

The CPU/System temperature are automatically detected and displayed by the system.

CPU Fan/System/NB Fan Speed

The CPU fan/System fan speed are automatically detected and displayed by the system.

CPU Core/DRAM Voltage/ +5.0V/+12.0V

The current voltages are automatically detected and displayed by the system.

CPU Smart Fan Function / System Smart Fan Function/NB Fan Function

This option is used to enable or disable smart fan function. If your fan is 4 pin fan, you'd better enable this for suitable temperature and low fan noise.

Set “CPU Smart Fan Function”/“System Smart Fan Function”/“NB Fan Function” to [Enabled], the following items appear:

Off PWM Temperature

It allows you set a temperature value from which smart fan stops its operation.

Start PWM Temperature

It allows you set a temperature value from which smart fan starts its operation.

Start PWM Value


It allows you to set an initial PWM value to drive the fan when the temperature reaches Start value and smart fan begins its operation. The higher PWM value can achieve the faster fan

speed.

► **Slope PWM Value**

The slope controls the PWM value being stepped up or down versus temperature changes.

BIOS Security Features



► **Change Supervisor Password**

This item is used to Enter or change supervisor password. After you input Supervisor password, it then will ask you to input user password optionally.




Load Optimal Defaults

Optimal defaults are the best settings of this motherboard. Always load the Optimal defaults after updating the BIOS or after clearing the CMOS values.

Select this option and press Enter, it will pop out a dialogue box to let you load the defaults. Select <OK> and then press <Enter> to load the defaults. Select <Cancel> and press <Enter>, it will not load.


By this default, BIOS have set the optimal performance parameters of system to improve the performances of system components. But if the optimal performance parameters to be set cannot be supported by your hardware devices (for example, too many expansion cards were installed), the system might fail to work.



Save & Exit Setup

When you select this option and press <Enter>, a message will be displayed in the center of the screen:


Select [OK] to save your changes to CMOS and exit the program, select [Cancel] or <ESC> to return to the main menu.




Discard Changes and Exit

If you select this option and press <Enter>, the following message will be displayed in the center of the screen:

Select [OK] to exit CMOS without saving your modifications, select [Cancel] or <ESC> to return to the main menu.





4

This chapter will cover two topics :

- Creating a Bootable Array - Installing a new Windows XP (or Vista) in a brand new RAID system.
- Creating a Non-Bootable Array - Existing Windows XP (or Vista) system with new RAID built as data storage.

It includes the following information :

- RAID Introduction
- Install SATA Hard Disks
- RAID Configuration
- Create RAID Driver Disk
- Install Windows OS

The RAID BIOS Setup pictures shown in this chapter are for reference only, please refer to the practical screen.

4-1 RAID Introduction

RAID 0 (Striped)

RAID 0 reads and writes sectors of data interleaved among multiple drives. If any disk member fails, it affects the entire array. The disk array data capacity is equal to the number of drive members times the capacity of the smallest member. RAID 0 does not support fault tolerance.

RAID 1 (Mirror)

RAID 1 writes duplicate data onto a pair of drives and reads both sets of data in parallel. If one of the mirrored drives suffers a mechanical failure or does not respond, the remaining drive will continue to function. Due to redundancy, the drive capacity of the array is the capacity of the smallest drive.

RAID 10 (Striped Mirror)

RAID 10 is a combination of striping and mirroring. This configuration provides optimal speed and reliability, but you need four SATA hard disks.

RAID 5 (Parity)

RAID 5 provides data striping at the byte level and also stripes error correction information. This results in excellent performance and good fault tolerance. Level 5 is one of the most popular implementations of RAID.

RAID Ready

A "RAID Ready" system is a specific system configuration that, with the addition of a second Serial ATA hard drive, can be seamlessly migrated to a configuration that provides either improved storage performance or data protection from a single hard drive failure.

JBOD (Span)

JBOD stands for "Just a Bunch of Disks". Each drive is accessed as if it were on a standard SCSI host bus adapter. This is useful when a single drive configuration is needed, but it offers no speed improvement or fault tolerance. A spanned volume is a formatted partition which data is stored on more than one hard disk, yet appears as one volume. Unlike RAID, spanned volumes have no fault-tolerance, so if any disk fails, the data on the whole volume could be lost. Additionally, the system or boot partitions cannot be included in a spanned volume. FAT16/32 and NTFS file systems may be used, and the volume can span up to 32 hard disks.



The number of hard disks needed in different RAID level:

RAID Level	RAID 0	RAID 1	RAID 10	RAID 5	RAID Ready	JBOD
Disk NO.	>=2	2	>=4	>=3	>=1	>=1

4-2 Install SATA Hard Disks

1. Shut down your computer.
2. Install SATA hard disks into the drive bays.
3. Connect all the SATA power and SATA data cables.

4-3 RAID Configuration

This motherboard supports RAID 0, RAID 1 and RAID10 functions.

Hardware and software you may need here :


- A floppy drive
- A DVD-ROM drive
- A floppy disk(Or USB disk for Vista)
- A motherboard driver CD
- Several SATA hard disks
- Windows XP or Vista Install CD

RAID Enable in BIOS

1. Boot up your computer, enter the BIOS setup by pressing [Del] key during POST.
2. Set the “OnChip SATA Type” to “RAID”.
3. Press [F10] to save the setting, then PC will reboot itself.

Option ROM Utility

When PC is rebooting, press [Ctrl-F] key during POST to enter the main menu of the Option ROM Utility.



View Drive Assignment: To view the disk drive assignment status by pressing [1].

Define LD: To Create RAID by pressing [2].

Delete LD: To Delete RAID by pressing [3].

Controller Configuration: To view the SATA controller configuration by pressing [4].

Exit: Press [Esc] to exit AMD Option ROM Utility.

Create RAID array

Here we create RAID 0 as an example:

1. Press [2] in the main menu, "Define LD Menu" appears and the "LD 1" row is highlight, press [Enter], the scree is shown as below:

Option ROM Utility (c) 2008 Advanced Micro Devices, Inc.

Define LD Menu

LD No	RAID Mode	Total Drv
LD 1	RAID 0	2

Stripe Block: 64 KB Fast Init: ON
Gigabyte Boundary: ON Cache Mode: WriteThru

Drives Assignment

Channel	!D	Drive Model	Compatibilities	Capacity(GB)	Assignment
1	:	Mas XXXXXXXXXXXX	SATA XG	XX.XX	Y
2	:	Mas XXXXXXXXXXXX	SATA XG	XX.XX	Y
3	:	Mas XXXXXXXXXXXX	SATA XG	XX.XX	N
4	:	Mas XXXXXXXXXXXX	SATA XG	XX.XX	N

Keys Available

[↑] Up [↓] Down [ESC] Exit [Space] Change [Ctrl-Y] SAVE [PgUp/Dn] Page Change

2. Press [Space] to select RAID 0.
3. Use [↑] key to highlight the hard disks, change any two of the drives' "Assignment" status to "Y" by pressing [Space] or [Y].
4. Press [Ctrl-Y] to save the setting, a message prompts:

Fast Initialization Option has been selected
It will erase the MBR data of the disks.
<Press Ctrl-Y Key if you are sure to erase it>
<Press any other key to ignore this option>

5. Press [Ctrl-Y] to clear the RAID array or press any other key to continue, another prompt appears:

Press Ctrl-Y to Modify Array Capacity or press any
other key to use maximum capacity...

6. Press [Ctrl-Y] to key in the capacity of the RAID array or press any other key to set the array to its maximum. Then you will see the created array:

Option ROM Utility (c) 2008 Advanced Micro Devices, Inc.

Define LD Menu


LD No	RAID Mode	Total Drv	Capacity(GB)	Status
LD 1	RAID 0	2	XX.XX	Functional
LD 2	----	----	-----	----
LD 3	----	----	-----	----
LD 4	----	----	-----	----
LD 5	----	----	-----	----
LD 6	----	----	-----	----
LD 7	----	----	-----	----
LD 8	----	----	-----	----
LD 9	----	----	-----	----
LD10	----	----	-----	----

Keys Available

[↑] Up [↓] Down [ESC] Exit [Enter] Select

Delete RAID array

1. Press [3] in the Main Menu to enter the "Delete LD Menu".
2. Highlight the array you want to delete and press [Del] or [Alt-D] keys.
3. Press [Ctrl-Y] if you are sure to delete the array or other keys to abort.



4-4 Create RAID Driver Disk

If you want to install Windows XP on a hard disk that is configured to RAID mode, a floppy disk with RAID driver is required during the installation. For Windows Vista, you can also use a USB flash disk with RAID driver.

Create a RAID Driver Disk in Windows:

1. Boot your computer and start Windows, put the driver CD into DVD-ROM drive.
2. Insert a floppy disk/USB disk into the floppy disk drive/USB port.
3. Depending on which platform you will install, go to **CD:\Driver\AMD\RAID\Floppy\WinXP** or **WinVista**, click on RaidTool icon to start the floppy creation or copy all the files in **WinXP** or **WinVista** folder to the USB disk.
4. Follow the succeeding screen prompt to complete the process.

Create a RAID Driver Disk without entering OS:

1. Boot your computer, press [Del] during POST to enter BIOS.
2. Insert the driver CD into the optical drive.
3. Set the "1st Boot Device" to "CD/DVD-ROM", save changes and exit.
4. Press any key when the screen prompts "Press any key to boot from the optical drive.".
5. Press [1] to create a RAID driver disk when the prompt menu appears.
6. Insert a formatted floppy disk into the floppy disk drive, press [Enter] to continue.
7. Follow the instructions to complete the process.

4-5 Install Windows OS

Install Windows XP

1. Press [Del] during POST to enter BIOS.
2. Insert the Windows XP installation CD into the optical drive.
3. Set the "1st Boot Device" to "CD/DVD-ROM", save changes and exit BIOS.
4. Press [F6] as soon as you see the message "Press F6 if you need to install a 3rd party SCSI or RAID driver".
5. Insert the RAID driver floppy disk into the floppy disk drive, and press [S] to continue.
6. There will be two drivers, select "AMD AHCI Compatible RAID Controller-x86 platform" for 32bit XP or "AMD AHCI Compatible RAID Controller-x64 platform" for 64bit XP, press [Enter].
7. A confirmation message appears to double check if the driver is really what we wanted, press [Enter] to continue. Then follow the screen prompt to complete the Windows XP installation.

Install Windows Vista

1. Press [Del] during POST to enter BIOS.
2. Insert the Windows Vista installation CD into the optical drive.
3. Set the "1st Boot Device" to "CD/DVD-ROM", save changes and exit BIOS.
4. When the screen shows "No driver were founded...", select "Load Driver".
5. Insert the floppy disk/USB disk into the floppy drive/USB port, then specify the location of the driver.
6. Select "AMD AHCI Compatible RAID Controller" and press "Next".
7. After the driver is loaded, the RAID hard disk will appear. Select it and press "Next" to continue the OS installation.