
Kodak EasyShare P720 digital frame



Extended user guide

www.kodak.com

For help with your picture frame, www.kodak.com/go/digitalframesupport

Kodak

Eastman Kodak Company

Rochester, New York 14650


© Eastman Kodak Company, 2008

All screen images are simulated.

Kodak and EasyShare are trademarks of Eastman Kodak Company.

P/N 4F8172_en


Front View



- 1 LCD screen
- 2 Touch border (tap/slide)
- 3 Touch border (tap only)
- 4 Raised guide

To use the touch border, see page 3.

Back/Side View



- 1 Power button
- 2 Stand attachment slot
- 3 Frame stand (see [page 1](#))
- 4 Memory card slot - SD/SDHC, MS, xD, MMC (see [page 5](#))
- 5 Reset button
- 6 USB connector (to camera/USB device)
- 7 Memory card slot - SD/SDHC
- 8 Wall mounting holes (see [page 7](#))

Table of contents

1 Getting started	1
Setting up your frame	1
Turning on your frame	2
Using your frame's touch border	3
Setting your language	4
Enjoying your pictures immediately!	4
Inserting a memory card	5
Connecting a digital camera or other USB device	5
Turning off your frame	6
Changing your frame orientation	6
Mounting your frame on the wall	7
2 Viewing pictures	8
Accessing your pictures	8
Running a slide show	9
Viewing thumbnails (multi-up)	9
Viewing a single picture	10
Viewing pictures by filename	10
Copying pictures	11
Copying from your computer	12
Deleting pictures	15
Selecting multiple pictures	15
3 Doing more	17
Changing frame settings	17
Settings menus	17
Setting the clock and timer	19
Upgrading your firmware	20
Installing the software	21
Customizing your frame	22
Maintaining your frame and mattes	22

Learning more about your frame.....	22
4 Troubleshooting and support	23
Picture frame problems	23
Screen messages.....	25
5 Appendix	27
Digital frame specifications.....	27
Important safety instructions	28
Upgrading your software and firmware.....	28
Additional care and maintenance	28
Limited warranty	29
FCC compliance and advisory	31

1


Getting started

Welcome to your Kodak EasyShare P720 digital frame. Viewing your pictures couldn't be simpler!

Setting up your frame

Attaching the frame stand

Your frame displays pictures in landscape  orientation. To change to portrait  orientation, see [page 6](#).




Make sure the tab is secure in the slot.

Attaching the power cable



CAUTION:

Do not use this power cable with other devices, including digital cameras.



Your power cable may look different from the one pictured. Use the plug that accommodates your type of power outlet.

Turning on your frame

Power button - press and hold (for about 2 seconds), then release



Using your frame's touch border


Touch at the bottom (tap/slide) or right (tap only) border to find/highlight menu items or pictures. Press OK to select them.

NOTE: The screen is not touch-sensitive. Do not touch.



CAUTION:

Only use your finger to touch the borders. Using sharp or metal objects may damage the border or screen.



(Slider): Under slider, **slide**, or **touch and hold**

(for about 3 seconds to scroll even faster through your images), or **tap** slider arrows.


Tap Menu for more options, or tap  to resume a slide show.

If the icons disappear, tap the bottom or right border.

Setting your language

The language screen appears the first time you turn on your frame.

- Slide or tap below slider arrows to find your language, then tap OK.



To change the language at a later time:

- Tap  (Home) →  (Settings) → Language. *The language screen appears.*
Slide to find your language, then tap OK.

Enjoying your pictures immediately!

NOTE: If the software installation screen appears, dismiss it and start playing a slide show immediately. To install the software later, see [page 21](#).



- **To view your pictures or play a slide show,** insert a memory card, or connect a camera or other USB device (see [page 5](#)).

If you are at the Home screen, see [page 8](#) to start your slide show.

To change the slide show order, see [page 10](#).

Inserting a memory card


To insert a card, push the card firmly into the slot until it stops.

To remove a card from:

top card slot - push in the card to release it


side card slot - pull out the card

CAUTION: Insert a micro or mini memory card in an adapter first, or the card will get stuck in your frame.



Connecting a digital camera or other USB device

USB devices: camera, flash drive, card reader, etc. (sold separately)




Turning off your frame



- **Standby mode**—Press and hold the power button (for about 2 seconds), then release.
- **Power off**—Unplug the power cable.

Changing your frame orientation

Your frame is set up to display pictures in landscape  orientation. You can turn the stand to change it to portrait  but you must also change the setting.



Change the stand position:


- Remove the stand, turn it 90 °, and replace as shown (see [page 1](#)).

Change the setting:

- 1 Tap  (Home) →  (Settings).
- 2 Slide to highlight , then tap OK.
- 3 Slide to highlight Frame orientation, then tap OK.
- 4 Slide to highlight Portrait, then tap OK.
- 5 Tap  to exit.

Mounting your frame on the wall

Use wall-anchoring hardware (not included) to anchor your frame securely to your wall.



2

Viewing pictures

Accessing your pictures

Tap Home to access pictures from your memory card and all connected devices (see [page 5](#)). Use the touch borders to make your selections (see [page 3](#)).



- 1 Tap  (Home).

All connected sources and the Settings icon are displayed.

- 2 Slide to highlight a picture source, then:
 - Tap  (Slide show) to start a slide show.
 - OR
 - Tap OK to view thumbnails.

Picture sources and settings icons:



Memory card—appears when you insert a card ([page 5](#)). The label and icon indicate the type of card.



Camera—appears when you connect a digital camera via USB cable ([page 5](#)).



USB drive—appears when you insert a USB flash drive ([page 5](#)).



Settings—customize your frame settings. For example; set slide show durations and transitions, set viewing options, screen brightness, clock, and timer.

Running a slide show

There are two ways to start a slide show on your frame:

- Turn on the frame, then insert a card or connect a USB device—a new slide show starts automatically, replacing a currently running slide show or single view picture.
- Select a picture in thumbnails (multi-up) view or select a picture source on the Home screen, then tap  (Slide show).

Other slide show information

- A slide show plays continuously until you stop it or turn off the frame.
- You can change the slide show duration and transition style (see [page 17](#)).

Viewing thumbnails (multi-up)

There are two ways to view your pictures as thumbnails:



- Tap  (Home) then select a picture source (see [page 8](#)). Tap OK.
- Or,
- From a slide show (tap the touch-sensitive border to display the icons), or from single view, tap  (Multi-up).

To navigate through the thumbnails, slide your finger left/right along the slider at the bottom. To move even faster through the thumbnails, touch and hold until the screen changes (about 3 seconds).

To play a folder of thumbnail (multi-up) images, highlight the folder then tap  (Slide show).

Viewing a single picture

- **To view a single**, full-screen picture, highlight it in thumbnails view, then tap OK.
- **To magnify** a picture up to 8X, tap  (Menu), then tap  (Zoom). Slide from left to right under the zoom bar. To view other parts of the picture, tap . To return to 1X, slide from right to left.
- **To rotate** a picture, tap  (Menu), then tap  (Rotate).

Viewing pictures by filename

By default, the pictures on your frame are arranged and played by date, starting with the oldest. You can play the arrangement or order, by date, or alphabetically by filename.

NOTE: If a picture source with numerous images (greater than 500) takes too long to load, change the order to play by filename.

To change the play order:

- 1 Select a picture source (for example, a folder with pictures), or multiple pictures (see [page 15](#)), then tap OK.
- 2 Tap  (Viewing Options).
- 3 Highlight Sort, then tap OK.
- 4 Select a sort order:
 - Date, oldest to newest (default)
 - Date, newest to oldest
 - Filename, A - Z
 - Filename, Z - A
- 5 Tap OK.

Copying pictures

Copy pictures from your current viewing location to other connected devices (see [page 5](#)).



CAUTION:

Removing a card or disconnecting a device while copying may damage your card, pictures, or device.



- 1 Highlight a picture to copy:
In thumbnails view, slide or tap below the slider arrows to find a picture; or, display a picture in single view (see [page 10](#)).

- 2 Tap  (Menu).

- 3 Tap  (Copy), then OK.

- 4 Tap the available destination you want to copy to, then tap OK.

The picture is copied.

- 5 Tap  (Close) to close the menu.

To copy multiple pictures, see [page 15](#).




Copying from your computer

Drag and drop pictures easily from your computer to a memory card (or other removable USB device, like a flash drive), then insert the card into your frame and play a slide show right away.

- 1 Install the software that came with your frame (see [page 21](#)).
- 2 Insert a memory card into your computer or connected card reader. Or insert a removable USB device into the computer's USB port.
- 3 Double-click  (Kodak EasyShare digital display icon) on your desktop to open the software.

The memory card and connected devices appear in the Drag and Drop Zone.



- 4 Click My Devices to see the connected devices and their folders.
- 5 In Pictures and Videos, click the folder or location on your computer that contains the pictures you want to copy.

- 6 In the Viewer pane, select the pictures you want to copy, then drag and drop them to the copy location (memory card or USB device) in the Drag and Drop Zone.

The pictures are copied to the memory card or USB device.

- 7 Remove the card or USB device from your computer. Insert the card into your frame's card slot (see [page 5](#)), or connect the USB device (see [page 5](#)).

A slide show begins.


NOTE: To maintain the slide show order during playback, see [page 10](#) and select Filename, A to Z.

For more information on the features included in the Kodak EasyShare digital display software, click the Help button.

Copying pictures from EasyShare software

It's easy to copy pictures from My Collection to a memory card, then play them in a slide show on your frame.

- 1 Install the software that came with your frame (see [page 21](#)).
- 2 Insert a memory card into your computer. Or insert a removable USB device or card reader into the computer's USB port.
- 3 Double-click  (Kodak EasyShare software icon) to open the software.



- 4 Click My Collection, then select the pictures in the Viewer pane. Drag and drop them into the Picture tray.
- 5 In the menu bar, select File → Copy to.
- 6 Browse to the location to which you are copying.
The memory card, card reader, and USB device appear as removable drives.
- 7 Select *Best For Picture Frame* to resize the pictures you are copying. Full resolution is unnecessary and quickly fills up the frame's memory.
- 8 Click Copy. Pictures are copied to the copy destination (memory card or USB device).
- 9 Remove the card or USB device from your computer. Insert the card into your frame's card slot (see [page 5](#)), or connect the USB device (see [page 5](#)).
A slide show begins.

For more information on the features included in the Kodak EasyShare software, click the Help button.

Deleting pictures



CAUTION:

Removing a card or disconnecting a device while deleting may damage your card, pictures, or device.



- 1 Highlight a picture to delete:
In thumbnails view, slide or tap below the slider arrows to find a picture; or, display a picture in single view (see [page 10](#)).
- 2 Tap  (Menu).
- 3 Tap  (Delete), then tap OK
- 4 Tap Yes to confirm.
The picture is deleted.
- 5 Tap  (Close) to close the menu.
To delete multiple pictures, [see page 15](#).

Selecting multiple pictures

Use the multi-select feature to copy or delete two or more pictures or to play a slide show of selected pictures.

- 1 In multi-up (thumbnails) view, slide your finger along the bottom touch border to find a picture, then tap  (Select).
A check mark appears on the selected picture.
- 2 Continue selecting pictures.
To remove a check mark, tap  (Unselect) while the picture is highlighted.

Select/Unselect all



Select all

- In thumbnails view (page 9), tap  (Select All).

Unselect all

- To remove all check marks, tap Unselect All.

3

Doing more

Changing frame settings

The options in the Settings menu let you customize and configure your frame.

- 1 Tap  (Home), then  (Settings).
- 2 Slide or tap below the slider arrows to highlight a setting, then tap OK.
- 3 Follow the on-screen instructions. Tap OK to accept your selections.
- 4 Tap  (Back) to exit.

Settings menus

Setting	Options
Upgrade firmware This option is only displayed if the upgrade file (.img) is available on the frame (memory card, flash drive, internal memory, etc.).	Upgrade firmware —load the latest version of firmware on your frame (page 20). Exit —return to the Home screen.

Setting	Options
Viewing options	<p>Slide duration—specify how long each picture is displayed in a slide show, from 3 seconds to 1 hour. (The default is 5 seconds.)</p> <p>Frame orientation—Display your frame in landscape (default) <input type="checkbox"/> or portrait <input type="checkbox"/> orientation.</p> <p>Transitions—specify the transition style between pictures in a slide show. See screen for options. The default is Random.</p> <p>Shuffle—plays the images in random order.</p> <p>Screen Fit or Fill—</p> <p>Fit entire image <input checked="" type="checkbox"/> (default). Show the entire picture. Black borders may appear around the image.</p> <p>Fill the screen <input type="checkbox"/>. The picture fills the entire screen; some of the picture may be cut off (cropped).</p>
Brightness	Slide to adjust the screen brightness according to your lighting conditions.
Clock and timer	<p>On/Off schedule—set your frame to turn on and off at a specified time every day (page 19).</p> <p>Set time—manually set the clock to the current time (page 19).</p>
Language	Choose your language (page 4).
About	Check your frame model, serial number, and firmware version.

Setting the clock and timer

Manually setting the clock

- 1 Tap  (Home), then  (Settings).
- 2 Highlight Clock and timer, then tap OK.
- 3 Highlight Set time, then tap OK.
- 4 Slide to set the hour. Tap the right arrow to highlight the next setting (minutes), then slide to adjust it.
- 5 Tap OK to accept your changes.

Setting automatic on/off

Set your frame to turn on and off at a specified time every day.

NOTE: Set the clock before enabling auto on/off.

- 1 Tap  (Home), then  (Settings).
- 2 Highlight Clock and timer, then tap OK.
- 3 Highlight On/Off schedule, then tap OK.
The current time is displayed and the hour field is highlighted.
- 4 Slide to adjust the hour. Tap the right arrow to highlight the next setting (minutes), then slide to adjust it. Repeat to set Turn off time.
- 5 Tap Enable, then OK when you're done.

Your frame will now automatically turn on and off at the times you specified.

NOTE: Make sure the power button on the frame is On. See [page 2](#).

If your frame loses power, the clock time returns to the factory setting and the automatic on/off times, if set, are disabled. To reset the clock and re-enable your on/off times, see [Resetting the clock after losing power, page 24](#).

Upgrading your firmware

Firmware is the software that runs on your frame. To check for the latest version, visit www.kodak.com/go/digitalframedownloads.

Download the firmware to your computer, then upgrade your frame:

- 1 On your computer, go to www.kodak.com/go/digitalframedownloads.
- 2 Follow the screen directions to download the frame firmware to your computer.
- 3 Copy the IMG file to a memory card or USB flash drive, then insert into the frame. See [page 12](#) for copying files.
- 4 Tap  (Home), then  (Settings).
- 5 Highlight Firmware Upgrade, then tap OK to begin the upgrade.

IMPORTANT: *Do not turn off the frame or remove the memory card or USB flash drive during the upgrade!*

When the upgrade is complete, your frame automatically restarts. If it doesn't, press the power button on the frame to Off, then back to On.

Installing the software

Follow these directions to install the software CD that was packaged with your frame. The CD contains the Kodak EasyShare software and the Kodak EasyShare digital display software. While these software applications work well independently, both applications work together for the best experience when working with your pictures (see [page 12](#)).


- 1 Close all software applications that are open on your computer (including anti-virus software; see the anti-virus software manual for details).
- 2 Place the EasyShare software CD into the CD-ROM drive.
The Kodak EasyShare software Install Wizard opens on your computer screen.
- 3 If the Install Wizard does not appear, choose Run from the Start menu and type **d:\setup.exe** where **d** is the drive letter that contains the CD.
- 4 Follow the on-screen instructions to install the software. Select Complete to automatically install both the Kodak EasyShare software and the Kodak digital display software. Or, click Customize to choose the applications you wish to install.

NOTE: When prompted, take a few minutes to electronically register your picture frame and software. To register later, visit www.kodak.com/go/register.

- 5 If prompted, restart the computer. If you turned off anti-virus software, turn it back on.
The software icon(s) appear on your desktop when the installation is complete.

Customizing your frame

For a custom look, remove the adhesive matte (included) from its liner, align it carefully, then attach it to your frame.



When you are not using the matte, reapply it to the liner and store in a plastic bag to keep the adhesive backing clean.

Maintaining your frame and mattes

IMPORTANT: *Always disconnect the power before cleaning. Do not use water, cleaning solutions, or other adhesives on the frame or any of its parts.*

Gently wipe the frame, LCD, or matte with a clean, dry, lint-free cloth (included). For fingerprints on the frame, apply light pressure.

Learning more about your frame

www.kodak.com/go/digitalframes

Frame accessories, including decorative faceplates and custom mattes

www.kodak.com/go/digitalframesupport

Interactive troubleshooting and repairs

Interactive tutorials

FAQs

Downloads

Product registration

4

Troubleshooting and support

For step-by-step product support, visit www.kodak.com/go/digitalframesupport and select Interactive Troubleshooting & Repairs.

Picture frame problems

If..	Try one or more of the following
Frame does not turn on.	<ul style="list-style-type: none"> ■ Make sure the power cable that was included with your frame is connected securely (see page 2). ■ Unplug the power cable from the frame. Wait 5 seconds, then reconnect the cable. ■ Press and hold the power button (for about 2 seconds), then release.
Nothing happens when a memory card, camera, or USB device is connected.	<ul style="list-style-type: none"> ■ Insert a certified SD/MMC/MS/xD card with images into the designated card slot, then push to seat it (see page 5). In the top card slot, make sure the card is seated flush with the top. ■ Make sure the USB cable that was included with your camera or USB device is connected securely (see page 5). ■ Make sure the file format of your pictures is supported (see page 27). <p>NOTE: A large picture file may take time to appear.</p>
Touch border doesn't work.	<ul style="list-style-type: none"> ■ Use your finger to make your selections on the touch-sensitive borders (see page 3). <p>IMPORTANT: <i>Do not slide on the right border (tap only).</i></p> <ul style="list-style-type: none"> ■ Unplug the power cable from the frame. Wait 5 seconds, then reconnect the cable. Press and hold the power button (for about 2 seconds), then release.

If...	Try one or more of the following
Frame freezes up.	<ul style="list-style-type: none"> ■ Unplug the power cable from the frame. Wait 5 seconds, then reconnect the cable. Press and hold the power button (for about 2 seconds), then release. ■ Use a paper clip or other slim object to press the recessed reset button on the back of the frame (see page i).
You set automatic on/off but the frame doesn't turn on and off at the specified times.	<ul style="list-style-type: none"> ■ Make sure you Enabled the on/off setting after you set the times, then press OK (not Back). See page 19. ■ If your frame loses power, the clock returns to the factory setting and auto on/off times are disabled. See Resetting the clock after losing power, page 24.

Resetting the clock after losing power

If you turn off the power on the frame or otherwise lose power, the clock time returns to the factory setting and the automatic on/off times, if set, are disabled.

- When you turn the frame back on, the set time screen appears on the frame.
- Slide to set the hour. Tap the left/right arrows to highlight the previous or next setting (hour, minutes), then slide to adjust the setting.
- Tap OK.

The Home screen appears. The time is reset and the automatic on/off times (if set) are re-enabled. It is not necessary to reset the on/off times.

NOTE: If you exit the set time screen without setting the time, you can manually reset the clock and re-enable the automatic on/off times (see [page 19](#)). It is not necessary to reset the on/off times.

Screen messages

Screen message	Try one or more of the following
Create file failed.	<p>The device (memory card, USB drive, camera, etc.) you are trying to copy to is protected.</p> <ul style="list-style-type: none">■ See your device documentation to remove write protection.■ Insert or connect a different device.
Write failed. Select another location.	<p>The frame was unable to copy the picture.</p> <ul style="list-style-type: none">■ Insert a different card or device (page 5).
Unable to create file. Device write protected or full.	<p>The frame was unable to copy the picture.</p> <ul style="list-style-type: none">■ Insert a different card or device (page 5).
Disk full.	<ul style="list-style-type: none">■ Remove write protection, unlock card.■ Delete pictures from card.

Screen message	Try one or more of the following
Error attempting to open file or directory.	<ul style="list-style-type: none"> ■ Unplug the power cable from the frame. Wait 5 seconds, then reconnect the cable. Press and hold the power button (for about 2 seconds), then release. If the problem persists, contact customer support help, at www.kodak.com/go/digitalframesupport.
Error duplicate filename.	
Error occurred while closing a file.	
Error invalid filename	
Error reading from file.	
Error writing from file.	
Error writing a file.	
Error writing to a file.	
File Copy Failed!	
Internal error.	
Parameter is invalid.	
Unknown error.	

5

Appendix

Digital frame specifications

For more specifications, visit www.kodak.com/go/digitalframesupport.

Kodak EasyShare P720 digital frame	
Color display	17.8 cm (7 in.) diagonal analog LCD, 480 x 234 pixels, 16:9 aspect ratio, 154 x 87 mm (6.1 x 3.4 in.) viewable area
Internal memory	None
Power	110V AC adapter with integrated plug, model MPA-05015A (US) 110 - 240V AC adapter, model MPA-05015 (WW)
Picture formats	JPEG, EXIF 2.2
Video formats	Not supported
Music format	Not supported
Memory cards	MMC (MultiMedia Card); SD/SDHC (Secure Digital/Secure Digital High Capacity); Memory Stick, xD
Temperature	Operating: -4 to 140°F (-20 to 60°C) Storage: -22 to 185°F (-30 to 85°C)
Size	26.2 x 19.3 x 3.8 cm (10.3 x 7.6 x 1.5 in.)

Important safety instructions



CAUTION:

Do not disassemble this product; there are no user-serviceable parts inside. Refer servicing to qualified service personnel. Do not expose this product to liquid, moisture, or extreme temperatures. The use of controls, adjustments, or procedures other than those specified herein may result in exposure to shock and/or electrical or mechanical hazards. If the LCD breaks, do not touch the glass or liquid. Contact Kodak customer support.

- The use of an accessory that is not recommended by Kodak may cause fire, electric shock, or injury. For approved accessories, visit www.kodak.com/go/accessories.
- Use only a USB-certified computer equipped with a current-limiting motherboard. Contact your computer manufacturer if you have questions.

Upgrading your software and firmware

Upgrade to the latest versions of the software included on the Kodak EasyShare software CD and the frame firmware—www.kodak.com/go/digitalframedownloads. See [page 20](#) for upgrading firmware.

Additional care and maintenance

- Wipe the frame and the LCD gently with a soft, lint-free cloth (included). Do not use cleaning solutions unless designed specifically for LCD screens. Do not allow chemicals, such as suntan lotion, to contact painted surfaces.
- Service agreements are available in some countries. Contact a dealer of Kodak products for more information.
- For digital frame disposal or recycling information, contact your local authorities. In the US, visit the Electronics Industry Alliance Web site at www.eiae.org or visit www.kodak.com/go/digitalframesupport.

Limited warranty

Kodak warrants Kodak consumer electronic products and accessories ("Products"), excluding batteries, to be free from malfunctions and defects in both materials and workmanship for one year from the date of purchase. Retain the original dated sales receipt. Proof of the date of purchase will be required with any request for warranty repair.

Limited warranty coverage

Warranty service is only available from within the country where the Products were originally purchased. You may be required to ship Products, at your expense, to the authorized service facility for the country where the Products were purchased. Kodak will repair or replace Products if they fail to function properly during the warranty period, subject to any conditions and/or limitations stated herein. Warranty service will include all labor as well as any necessary adjustments and/or replacement parts. If Kodak is unable to repair or replace a Product, Kodak will, at its option, refund the purchase price paid for the Product provided the Product has been returned to Kodak along with proof of the purchase price paid. Repair, replacement, or refund of the purchase price are the sole remedies under the warranty. If replacement parts are used in making repairs, those parts may be remanufactured, or may contain remanufactured materials. If it is necessary to replace the entire Product, it may be replaced with a remanufactured Product. Remanufactured Products, parts and materials are warranted for the remaining warranty term of the original Product, or 90 days after the date of repair or replacement, whichever is longer.

Limitations

This warranty does not cover circumstances beyond Kodak's control. This warranty does not apply when failure is due to shipping damage, accident, alteration, modification, unauthorized service, misuse, abuse, use with incompatible accessories or attachments, failure to follow Kodak 's operation, maintenance or repacking instructions, failure to use items supplied by Kodak (such as adapters and cables), or claims made after the duration of this warranty. Kodak makes no other express or implied warranty for this product, and disclaims the implied warranties of

merchantability and fitness for a particular purpose. In the event that the exclusion of any implied warranty is ineffective under the law, the duration of the implied warranty will be one year from the purchase date or such longer period as required by law. The option of repair, replacement, or refund is Kodak's only obligation. Kodak will not be responsible for any special, consequential or incidental damages resulting from the sale, purchase, or use of this product regardless of the cause. Liability for any special, consequential or incidental damages (including but not limited to loss of revenue or profit, downtime costs, loss of the use of the equipment, cost of substitute equipment, facilities or services, or claims of your customers for such damages resulting from the purchase use or failure of the Product), regardless of cause or for breach of any written or implied warranty is expressly disclaimed.

Your rights

Some states or jurisdictions do not allow exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states or jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific rights, and you may have other rights which vary from state to state or by jurisdiction.

Outside the United States and Canada

In countries other than the United States and Canada, the terms and conditions of this warranty may be different. Unless a specific Kodak warranty is communicated to the purchaser in writing by a Kodak company, no warranty or liability exists beyond any minimum requirements imposed by law, even though defect, damage, or loss may be by negligence or other act.

FCC compliance and advisory



Kodak EasyShare P720 digital frame

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

FCC and Industry Canada

This device complies with Industry Canada RSS-210 and FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC et Industrie Canada

Cet appareil est conforme à la norme RSS-210 d'Industrie Canada et aux réglementations de la FCC. Son utilisation est soumise aux deux conditions suivantes : (1) cet appareil ne doit pas provoquer d'interférences nuisibles, et (2) cet appareil doit supporter les interférences reçues, y compris celles susceptibles de nuire à son bon fonctionnement.

CE

Hereby, Eastman Kodak Company declares that this Kodak product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Canadian DOC statement

DOC Class B Compliance—This Class B digital apparatus complies with Canadian ICES-003.

Observation des normes-Classe B—Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Waste Electrical and Electronic Equipment labeling

EU: It is the final user's responsibility to discard this equipment into an approved, segregated collection scheme to enable its suitable treatment/disposal and to improve human/environmental protection. For more information, see your retailer, local authority, or www.kodak.com/go/recycle.

Australian C-Tick**MPEG-4**

Use of this product in any manner that complies with the MPEG-4 visual standard is prohibited, except for use by a consumer engaging in personal and non-commercial activities.

Russian GOST-R



Eastman Kodak Company
Rochester, New York 14650

Цифровая фоторамка изготовлена в Китае; остальные элементы – в соответствии с маркировкой

China RoHS

环保使用期限 (EPUP)

在中国大陆，该值表示产品中存在的任何危险物质不得释放，以免危及人身健康、财产或环境的时间期限（以年计）。该值根据操作说明中所规定的产品正常使用而定。

Environmental Protection Use Period (EPUP)

In China, this number indicates the time period (in years) within which any hazardous substances present in the product are not expected to be released such that there is risk to human health, property, or the environment. This value is assigned based on normal use of the product as described in the operating instructions.

Product Disclosure Table

有毒有害物质或元素名称及含量标识表
table of hazardous substances' name and concentration

部件名称 Component name	有毒有害物质或元素 hazardous substances' name					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr6+)	多溴联苯 (PBB)	多溴二苯 醚 (PBDE)
数码相架电路板元件 (Digital Photo Frame circuit board components)	X	O	O	O	O	O
控制器 (Controller)	X	O	O	O	O	O
交流变压器电路板元件 (AC Adapter circuit board components)	X	O	O	O	O	O

O: 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2006规定的限量要求以下。
 X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T 11363-2006规定的限量要求。
 O: indicates hazardous substance concentration lower than MCV
 X: indicates hazardous substance concentration higher than MCV



USB 数据线

Korean Class B ITE

이 기기는 가정용으로 전자파적합등록을 한 기기로서 주거지역에서는 물론 모든 지역에서 사용할 수 있습니다.

Licensing

Supply of this product does not convey a license nor imply any right to distribute content created with this product in revenue-generating broadcast systems (terrestrial, satellite, cable and/or other distribution channels), streaming applications (via Internet, intranets and/or other networks), other content distribution systems (pay-audio or audio-on-demand applications and the like) or on physical media (compact discs, digital versatile discs, semiconductor chips, hard drives, memory cards and the like). An independent license for such use is required. For details, please visit <http://mp3licensing.com>.

Index

A

about, frame, 18
appendix, 27
automatic on/off, 18, 19

B

battery
 safety, 28
brightness, screen, 18
button
 macro/landscape, i

C

cables
 USB, connecting, 5
camera, connecting, 5
changing picture locations, 8
clock and timer, setting, 18, 19
copying
 from EasyShare software, 13

D

deleting pictures and videos, 15
displaying slide show, 9
disposal, recycling, 28

E

EasyShare software
 copying pictures from, 13
 installing, 21
error messages, 25

F

firmware
 checking version, 18
 upgrading, 17, 28
flash drive, connecting, 5
frame, picture
 changing orientation, 1
 checking model, firmware, serial
 number, 18
 setup, 1
 specifications, 27
 troubleshooting, 23
 turning on/off, 6

H

help
 frame, 23
 troubleshooting problems, 23
home
 changing picture locations, 8
 screen, 8

I

installing software, 21
internal memory
 capacity, 27

L

landscape, set orientation, 18
language
 setting, 18
 setting first time, 4

loading software, 21

M

macro/landscape button, i

multi-up view, 9

O

on/off, setting auto, 18, 19

orientation setting, 1, 18

P

pictures

copying from EasyShare software, 13

deleting, 15

location, changing, 8

selecting more than one, 15

viewing, 8

portrait, set orientation, 18

power

turning on, 6

R

recycling, disposal, 28

regulatory compliance, 31

running slide show, 9

S

safety information, 28

screen

cleaning, 28

error messages, 25

setting brightness, 18

selecting multiple pictures, 15

serial number, checking, 18

setting

auto on/off, 18, 19

language, 18

language first time, 4

screen brightness, 18

time, 18

viewing options, 18

setup

picture frame, 1

slide duration, setting, 18

slide show

running, 9

slide transitions, setting, 18

software

installing, 21

upgrading, 28

source, picture location, 8

specifications, frame, 27

storage capacity, internal memory, 27

T

thumb drive. See flash drive., 5

thumbnails, 9

time, setting, 18

transitions, slides, setting, 18

troubleshooting

error messages, 25

frame, 23

turning on/off frame, 6

U

upgrading

firmware, 17

software and firmware, 28

USB device, connecting, 5

V

viewing

full screen picture, 10

pictures/videos, 8

thumbnails, 9

W

warranty, 29