


METTLER TOLEDO

Compact scales BBA422 / BBA425 / BBK422





Congratulations on choosing the quality and precision of METTLER TOLEDO. Proper use according to this Operating Manual and regular calibration and maintenance by our factory-trained service team ensures dependable and accurate operation, protecting your investment. Contact us about a ServiceXXL agreement tailored to your needs and budget.

We invite you to register your product at www.mt.com/productregistration so we can contact you about enhancements, updates and important notifications concerning your product.

Table of contents

	Page
1 Introduction	4
1.1 Safety instructions	4
1.2 Description	5
1.3 Putting into operation	9
1.4 Disposal	11
2 Operation	12
2.1 Switching on and off	12
2.2 Zeroing / Zero point correction	12
2.3 Simple weighing	12
2.4 Weighing with tare	13
2.5 Dynamic weighing	14
2.6 Printing results	14
2.7 Cleaning	15
3 Settings in the menu	16
3.1 Operating the menu	16
3.2 Overview	18
3.3 Scale settings (SCALE)	21
3.4 Application settings (APPLICATION)	23
3.5 Terminal settings (TERMINAL)	24
3.6 Configuring interfaces (COMMUNICATION)	25
3.7 Diagnosis and printing out of the menu settings (DIAGNOS)	28
4 Interface description	29
4.1 SICS interface commands	29
4.2 TOLEDO Continuous mode	31
5 Event and error messages	33
6 Technical data and accessories	35
6.1 Technical data	35
6.2 Accessories	39
7 Appendix	40
7.1 Safety checks	40
7.2 FCC	40
8 Index	41

1 Introduction

1.1 Safety instructions

**CAUTION!**

Do not use BBA422 / BBA425 / BBK422 in hazardous areas!
Our product range includes special devices for hazardous areas.

**CAUTION!**

Scales with protection level IP65 are dust-tight and hose-proof to EN 60529. They are suitable for use in dusty environment and brief contact with liquids. Ensure that the scale is dried off again after coming into contact with liquid.

Even with degree of protection IP65 the scale should not be used in environments in which there is a risk of corrosion.

▲ Do not flood the scale or submerge it in liquid.

**DANGER!**

Electric shock hazard!

▲ Always pull out the mains plug before any work on the device.

**DANGER!**

Electric shock hazard if the mains cable is damaged!

▲ Check the mains cable for damage regularly and replace it immediately if it is damaged.

▲ On the rear side of the device, maintain a clearance of at least 1.2" (3 cm) in order to prevent the mains cable bending too much.

**CAUTION!**

On no account open the device!

The warranty is void if this stipulation is ignored. The device may only be opened by authorized persons.

▲ Call METTLER TOLEDO Service.

**CAUTION!**

Handle the compact scale with care.

The scale is a precision instrument.

- ▲ When the weighing pan has been removed, never clean the area under the load plate holder with a solid object!
- ▲ Do not put excessive loads on the scale.
- ▲ Avoid banging the weighing pan.

Note Use with foodstuffs

Parts coming into contact with foodstuffs have smooth surfaces and are easy to clean. The materials used do not splinter and are free of harmful substances.

With foodstuffs, it is recommended to use the protective cover, see section 6.2 Accessories.

- Clean the protective cover regularly and carefully.
- Replace damaged or very dirty protective cover immediately.

1.2 Description

This user manual applies to the following types of compact scales:

- Compact scale BBA422... with strain gauge weighing cell, Protection Class IP43
- Compact scale BBA425... with strain gauge weighing cell, Protection Class IP65
- Compact scale BBK422... with MonoBloc, Protection Class IP43

The compact scales are available in a small and large size in various capacities and resolutions.


The power supply is carried out via a built-in power supply device, an internal rechargeable battery with an external mains adapter or an external battery.

One of the following options can also be ordered:


- Additional interface RS232 or RS485
- Ethernet interface
- USB interface
- Digital I/O

1.2.1 Overview


- 1** Display
- 2** Scale specifications
- 3** Load plate
- 4** Adjustable feet
- 5** Keys



- 1** Power supply connection
- 2** Fast and fine pressure equalization, only with Protection Class IP65
- 3** Optional interface
- 4** (Standard) RS interface



1.2.2 Display



- 1** Active interface
- 2** Weighing range display
- 3** Battery charge level; only present on scales with a battery
- 4** Symbol for displaying net values
- 5** Symbol for dynamic weighing
- 6** Weight units
- 7** 7-segment display, 7 digits, with decimal point
- 8** Stability monitor (goes out when a stable weight value is reached)
- 9** Sign
- 10** Identification for changed or calculated weight values, e.g. higher resolution, minimum weight not reached

1.2.3 Keypad

Main functions

Key	Function in operating mode	Function in the menu
	Switching device on / off, abort	To the last menu item –End–
	Setting scale to zero	Scrolling back
	Taring scale	Scrolling forward
	Transfer key Long key press: Calling up menu	Activating menu item Accepting selected setting


Additional functions

Key	Function
	Switching weight unit
	Clear key

1.3 Putting into operation

1.3.1 Selecting or changing the location

The correct location is crucial to the accuracy of the weighing results!




→ Select a stable, vibration-free and if possible a horizontal location.

The ground must be able to safely bear the weight of the fully loaded scale.

Observe the following environmental conditions:

- No direct sunlight
- No strong drafts
- No excessive temperature fluctuations



Aligning the scale

Only scales that have been aligned precisely horizontally provide accurate weighing results.

→ Turn the adjustable feet of the scale until the spirit level's air bubble is inside the inner circle.

Major geographical location changes

The manufacturer adjusts each scale to the local gravity conditions (GEO value). In the event of major geographical location changes, this setting must be adjusted by a service technician. Certified scales must also be recertified observing the national certification regulations. These steps are not necessary for scales with an internal calibration weight.

1.3.2 Connecting the power supply



CAUTION!


Before connecting the scale to the mains, check whether the voltage value printed on the rating plate corresponds with the local mains voltage.

▲ Never connect the device if the voltage value printed on the rating plate is different to the local mains voltage.

→ Plug the mains plug into the socket.

After connection, the device performs a self-test. When the zero display appears, the device is ready to weigh.

→ Calibrate the device in order to obtain the greatest possible precision, see Section 3.3.1.



Scales with a built-in battery can work independently from the mains for approximately 30 hours in normal operation. A prerequisite for this is that the background lighting is switched off and that no peripheral devices are connected.

The device automatically switches to battery operation as soon as the mains supply is interrupted. When the mains supply is restored, the device automatically switches back to mains operation.


The battery symbol indicates the present charging level of the battery. 1 segment corresponds to approx. 25 % capacity. When the symbol flashes the battery must be charged (min. 4 hours). The charging period is extended if work is continued during charging. The battery is protected against overcharging.

The charging time of the storage battery amounts to approx. 6 hours. If the device continues to be operated during the charging process, the charging time is extended. The storage battery has a service life of approx. 1,000 charging/discharging cycles.

Note The storage battery is also suitable for permanent mains operation.

→ In order to obtain the full nominal capacity we recommend that you discharge the storage battery at regular intervals (approx. every 4 weeks) through normal operation.

1.4 Disposal



In conformance with the European Directive 2002/96 EC on Waste Electrical and Electronic Equipment (WEEE) this device may not be disposed of with domestic waste. This also applies to countries outside the EU, per their specific requirements.

→ Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment.

If you have any questions, please contact the responsible authority or the distributor from which you purchased this device.

Should this device be passed on to other parties (for private or professional use), the content of this regulation must also be related.

Thank you for your contribution to environmental protection.

If the device is equipped with a storage battery:

The nickel metal hydride (NiMH) storage battery does not contain any heavy metals. However, it may not be disposed of with the normal refuse.

→ Observe the local regulations on the disposal of materials that are hazardous to the environment.

2 Operation

2.1 Switching on and off

Switching on → Press .

The scale conducts a display test. When the weight display appears, the scale is ready to weigh.

Switching off → Press .

Before the display goes out, -OFF- appears briefly.

2.2 Zeroing / Zero point correction

Zeroing corrects the influence of slight changes on the load plate.

- Manual**
1. Unload scale.
 2. Press .

The zero display appears.

Automatic In the case of scales that cannot be certified, the automatic zero point correction can be deactivated in the menu or the amount can be changed.
As standard, the zero point of the scale is automatically corrected when the scale is unloaded.

2.3 Simple weighing

1. Place weighing sample on scale.
2. Wait until the stability monitor  goes out.
3. Read weighing result.

2.4 Weighing with tare

2.4.1 Taring

→ Place the empty container on the scale and press .

The zero display and the symbol **NET** appear.

The tare weight remains saved until it is cleared.

2.4.2 Clearing the tare

→ Press .

The symbol **NET** goes out, and the scale goes to gross mode.

If **A.CL-tr** is activated in the menu, the tare weight is automatically cleared as soon as the scale is unloaded.

2.4.3 Automatic taring

Prerequisite

A-tArE is activated in the menu under **SCALE** → **tArE**, the symbol **T** flashes in the display.

The packaging material must be heavier than 9 display steps of the scale.

→ Place the container or packaging material on the scale.

The packaging weight is automatically saved as the tare weight, the zero display and the symbol **NET** appear.

2.4.4 Chain tare

Prerequisite

The tare function **CHAIIn.tr** is activated in the menu.

With this function it is possible to tare several times if, for example, cardboard is placed between individual layers in a container.

1. Place the first container or packaging material on the scale and press .

The packaging weight is automatically saved as the tare weight, the zero display and the symbol **NET** appear.

2. Weigh the weighing sample and read/print out the result.

3. Place the second container or packaging material on the scale and press  again.

The total weight on the scale is saved as the new tare weight. The zero display appears.

4. Weigh the weighing sample in the second container and read/print the result.

5. Repeat the last two steps for other containers.

2.5 Dynamic weighing

With the dynamic weighing function, it is possible to weigh restless weighing samples such as live animals. If this function is activated, the symbol  appears in the display.

With dynamic weighing, the scale calculates the mean value from 56 weighing operations within 4 seconds.

With manual start **Prerequisite**

AVERAGE → MANUAL is selected in the menu.

The weighing sample must be heavier than 5 scale divisions.

1. Place the weighing sample on the scale and wait until it has stabilized.
2. Press  to start dynamic weighing.

During dynamic weighing, horizontal segments appear in the display, and the dynamic result is then displayed with the symbol *.

3. Unload the scale to be able to start a new dynamic weighing operation.

With automatic start **Prerequisite**

AVERAGE → AUTO is selected in the menu.

The weighing sample must be heavier than 5 scale divisions.

1. Place the weighing sample on the scale.

The scale starts the dynamic weighing automatically.

During dynamic weighing, horizontal segments appear in the display, and the dynamic result is then displayed with the symbol *.

2. Unload the scale to be able to perform a new dynamic weighing operation.

2.6 Printing results

If a printer or computer is connected to the scale, the weighing results can be printed out or sent to a computer.

→ Press .

The display contents are printed out and transferred to the computer.

2.7 Cleaning



CAUTION!

Electric shock hazard!

- ▲ Before cleaning with a damp cloth, pull out the mains plug to disconnect the unit from the power supply.



CAUTION!

When the weighing pan has been removed, never clean the area under the load plate holder with a solid object!

This could damage the weighing cell.

Other cleaning information:

- Use damp cloths.
- Do not use any acids, alkalis or strong solvents.
- Do not clean using a high-pressure cleaning unit or under running water.
- If very dirty, remove the weighing pan, protective cover (if present) and adjustable feet and clean these items separately.
- Follow all the relevant instructions regarding cleaning intervals and permissible cleaning agents.

3 Settings in the menu

Settings can be changed and functions can be activated in the menu. This enables adaptation to individual weighing requirements.

The menu consists of 6 main blocks containing various submenus on several levels.

3.1 Operating the menu

3.1.1 Calling up the menu and entering the password

The menu differentiates between 2 operating levels: Operator and Supervisor. The Supervisor level can be protected by a password. When the device is delivered, both levels are accessible without a password.

Operator menu

1. Press  and keep it pressed until CODE appears.
2. Press  again.

The menu item tErMINL appears. Only the submenu dEVICE is accessible.

Supervisor menu

1. Press  and keep it pressed until CODE appears.
2. Enter the password and confirm with .

The first menu item SCALE appears.

Note


No supervisor password has been defined when the device is first delivered. Therefore respond to the password inquiry with  when you call up the menu for the first time. If a password has still not been entered after a few seconds, the scale returns to weighing mode.

Emergency password for Supervisor access to the menu

If a password has been issued for Supervisor access to the menu and you have forgotten it, you can still enter the menu:

- Press  3 times and confirm with .

3.1.2 Selecting and setting parameters



Scrolling on one level

- Scroll forward: Press $\rightarrow T \leftarrow$.
- Scroll back: Press $\rightarrow 0 \leftarrow$.

**Activating menu items/
accepting selection**

- Press $\rightarrow \leftarrow$.

Exiting menu

1. Press $\textcircled{0}$.
The last menu item END appears.
2. Press $\rightarrow \leftarrow$.
The inquiry SAVE appears.
3. Confirm inquiry with $\rightarrow \leftarrow$ to save the settings and return to weighing mode.
-or-
→ Press $\rightarrow T \leftarrow$ to discard changes and return to weighing mode.

3.2 Overview

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Page
SCALE	CAL					21
	dISPLAY	UNIt1	g, kg, oz, lb , t			21
		UNIt2	g, kg , oz, lb, t			
		rESOLU				
		UNt.rOLL	ON, OFF			
	tArE	A-tArE	ON, OFF			22
		ChAIn.tr	ON , OFF			
		A.CL-tr	ON, OFF , 9 d			
	ZErO	AZM	OFF; 0.5 d; 1 d; 2 d; 5 d; 10 d			22
	rEStArt	ON/ OFF				22
	FILtEr	VibrAt	LOW, MEd , HIGH,			22
		ProCESS	UNIVER , dOSING			
		StAbILI	FASt, StAndrd , PrECISE			
	FAcT	tEMP	OFF, 1K, 2K, 3K, 5K			23
	Min.WEiG	ON/OFF	ON, OFF			23
		dAY.tIM	OFF, dAY, tIME			
	rESet	SUrE?				23
APPLIC	AVErAGE	OFF , AUtO, MAnuAL				23
	rESet	SUrE?				23
tERMINL	dEVICE	SLEEP	OFF , 1 min, 3 min, 5 min, 15 min, 30 min			24
		PWr OFF	OFF, 1 min, 3 min , 5 min, 15 min, 30 min			
		b.LIGHt	ON, OFF , 5 sec, 10 sec, 30 sec, 1 min			
	ACCESS	SUPErVI				24
	rESet	SUrE?				24

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Page
COMMUNI	COM 1/COM 2	MOdE	Print			25
			A.Print			
			CONtINU			
			dIALOG			
			CONt.OLd			
			dIAL.OLd			
			dt-b	GrOSS	ON, OFF	
				tArE	ON, OFF	
				nEt	ON, OFF	
			dt-G	GrOSS	ON, OFF	
				tArE	ON, OFF	
				nEt	ON, OFF	
			COnT-Wt			
			2nd.dISP			
			InSt.Prn			
		PriNtEr	Type	ASCII, LABEL		25
			tEmPLat	StdArd, tEMPLt1, tEMPLt2		
			ASci.Fmt	LINE.FMt	MULTI SINGLE FIXEd	
				LENGtH	1 ... 100	
				SEPArAt	, ;...	
				Add LF	0 ... 9	
		PARAMEt	bAUd	300 ... 38400		26
			PARity	7 nonE, 8 nonE, 7 odd, 8 odd, 7 EVEN, 8 EVEN		
			H.SHAKE	NO, XONXOFF, nEt 422, nEt 485		
			NEt.Addr	0 ... 31		
			ChECSuM	ON, OFF		
			Vcc	ON, OFF		
		rSt.COMx	SUrE?			26

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Page
COMMUNI	OPTION	EtH.NET	IP.AddrS, SUBNet, GAtEWAY			26
		USb	USb tEst			26
		diGitAL	IN 0 ... 3	OFF, ZErO, tArE, Print, CLear, Unit		26
			OUT 0 ... 3	OFF, StAbLE, bEL.Min, AbV.Min, UndErLd, OvErLd, StAr, ...		
			SEt.Pt 1			
			SEt.Pt 2			
	dEF.PrN	tEmPLt1/ tEMPLt2	LINE 1 ... LINE 8	NOT .USED, HEAdEr, GroSS, tArE, nEt, StArLN, CrLF, F FEEd		27
DIAGNOS	tEst SC	ExtErN				28
	KboArd					
	dISPLAY					
	SNr					
	LiSt					
	rESet.AL	SUrE?				

3.3 Scale settings (SCALE)

3.3.1 CAL – calibration (adjustment)

This menu item is not available for certified scales without internal calibration weight.

Internal	For scales with an internal calibration weight: 1. Unload scale. 2. Activate menu item CAL with . The scale calibrates with the internal calibration weight. -Int CAL- appears in the display. After calibration is completed, -donE- appears briefly in the display, and the scale automatically changes to the next point of the scale menu.
External	For scales without an internal calibration weight: 1. Unload scale. 2. Activate menu item CAL with . The scale determines the zero point. -0- appears in the display. The calibration weight to be placed on the scale then flashes in the display. 3. If necessary, change the weight value displayed with . 4. Place the calibration weight on the scale and confirm with . The scale calibrates with the calibration weight loaded. After calibration is completed, -donE- appears briefly in the display, and the scale automatically changes to the next point of the scale menu.

3.3.2 DISPLAY – weighing unit and display accuracy

UNIt1	Select weighing unit 1: g, kg, oz, lb, t
UNIt2	Select weighing unit 2: g, kg, oz, lb, t
rESOLU	Select readability (resolution), model-dependent
UNt.rOLL	When UNt.rOLL is switched on, the weight value can be displayed in all available units with  .
Notes	• In the case of certified scales individual sub-items of the dISPLAY menu item may not be available or only to a limited extent, depending on the respective country. • On dual-range/dual interval scales, resolutions marked with 1 1/2 are divided up into 2 weighing ranges/intervals, e.g. 2 x 3000 d.

3.3.3 TARE – tare function

A-tArE	Switching on/off automatic taring
CHAIIn.tr	Switching on/off chain tare
A.CL-tr	Switching on/off automatic clearing of the tare weight when the load is removed from scale Possible settings: OFF, ON, 9d

3.3.4 ZERO – automatic zero update

AZM	On certified scales, this menu item does not appear. Switching on/off automatic zero update and selecting zeroing range. Possible settings: OFF; 0.5 d; 1 d; 2 d; 5 d; 10 d
------------	---

3.3.5 RESTART – automatic saving of zero point and tare value

ON/OFF	When the Restart function is activated, the last zero point and tare value are saved. After switching off / on or after a power interruption, the device continues to work with the saved zero point and tare value.
---------------	---

3.3.6 FILTER – adaptation to the ambient conditions and the weighing type

VIbrAt LOW MEd HIGH	Adaptation to the ambient conditions • Very steady and stable environment. The scale works very quickly, but is very sensitive to external influences. • Normal environment. The scale operates at medium speed. • Restless environment. The scale works more slowly, but is insensitive to external influences.
PrOCESS UNIVER dOSING	Adaptation to the weighing process • Universal setting for all weighing samples and normal weighing goods • Dispensing liquid or powdery weighing samples
StAbILI FAST StAndrd PrECISE	Adjusting the stability detection • The scale operates very fast. • The scale operates at medium speed. • The scale operates with the greatest possible reproducibility. The slower the scale works, the greater the reproducibility of the weighing results.

3.3.7 FACT – automatic temperature-dependent adjustment

This menu item appears only on scales with an internal calibration weight.

tEMP	Defining the temperature difference for automatic calibration
OFF	Switching off automatic calibration in the case of a temperature difference
1K/2K/3K/5K	Automatic calibration in the case of a temperature change of 1 K, 2 K, 3 K or 5 K since the last adjustment

3.3.8 MIN.WEIG – minimum weight

This menu item appears only if the service technician has saved a minimum weight.

ON/OFF	Switching minimum weight function on/off If the weight on the scale falls below the stored minimum weight, an * appears on the display in front of the weight indicator.
---------------	---

3.3.9 RESET – resetting scale settings to factory settings

SUre?	Confirmation inquiry - Reset the scale settings to factory settings with  - Do not reset scale settings with 
--------------	--

3.4 Application settings (APPLICATION)

3.4.1 AVERAGE – determining the average weight for an unstable load

OFF	Calculating average weight switched off
Auto	Calculating average weight with automatic start of the weighing cycle
MANUAL	Calculating average weight with manual start of the weighing cycle via 

3.4.2 RESET – resetting application settings to factory settings

SUre?	Confirmation inquiry - Reset the application settings to factory settings with  - Do not reset the application settings with 
--------------	---

3.5 Terminal settings (TERMINAL)

3.5.1 DEVICE – Sleep mode, energy-saving mode and display backlighting

SLEEP	This menu item only appears on devices in mains operation. When SLEEP is activated, the scale switches off display and backlighting after the time period set when not in use. The display and backlighting are switched on again at the press of a key or if the weight changes. Possible settings: OFF, 1 min, 3 min, 5 min, 15 min, 30 min
Pwr OFF OFF / 1 min / ...	This menu item only appears on devices in battery operation. When Pwr OFF is activated, the device switches itself off automatically after approx. 3 minutes when not in use. Afterwards it has to be switched on using . Possible settings: OFF (switched off), 1 min, 3 min, 5 min, 15 min, 30 min
b.LIGHT	Switching the display backlighting on/off. Scales with a storage battery switch the background lighting off automatically by default when no action takes place at the scale for approx. 5 seconds. Possible settings: OFF (switched off), 5 sec, 10 sec, 30 sec, 1 min, ON (switched on)
Note	This menu item is accessible without a Supervisor password.

3.5.2 ACCESS – password for Supervisor menu access

SUPeRVI ENTeR.C rEtYPE.C	Password entry for Supervisor menu access Request to enter password → Enter the password and confirm with  Request to repeat the password entry → Enter the password again and confirm with 
Notes	- The password can consist of up to 4 characters. - The key  must not be part of the password. It is required for confirming the password. - The key  may only be used in combination with another key. - If you enter an impermissible code or make a typing error in the repetition, COdE.Err. appears in the display.

3.5.3 RESET – resetting terminal settings to the factory settings

SUre?	Confirmation inquiry - Reset terminal settings to the factory settings with  - Do not reset the terminal settings with 
--------------	--

3.6 Configuring interfaces (COMMUNICATION)

3.6.1 COM1/COM2 -> MODE – operating mode of the serial interface

Print	Manual data output to the printer with 
A.Print	Automatic output of stable results to the printer (e.g. for series weighing operations)
CONTINU	Ongoing output of all weight values via the interface
dIALOG	Bi-directional communication via MT-SICS commands, control of the scale via PC
CONT.OLD	As per CONTINU, see above, but with 2 fixed blanks in front of the unit (compatible with Spider 1/2/3)
dIAL.OLD	As per dIALOG, see above, but with 2 fixed blanks in front of the unit (compatible with Spider 1/2/3)
dt-b GROSS tArE nEt	DigiTOL-compatible format. • Transfer of the gross weight, identified with "B" • Transfer of the tare weight • Transfer of the net weight
dt-G	As per dt-b, see above, gross weight identified with "G"
Cont-Wt	TOLEDO Continuous mode
2nd.dISP	For connecting a second display (automatically activates the 5-V voltage supply at Pin 9)
InSt.Prn	Immediate manual data output to the printer with  (not certifiable)

3.6.2 COM1/COM2 -> PRINTER – settings for protocol printout

This menu item only appears if the mode "Print" or "A.Print" is selected.

tYPE ASCII LabEL	Select the printer type • ASCII printer, e.g. Sprinter 1 • Label printer, capable of printing graphics
tEmPLat StdArd tEmPLt1 tEmPLt2	Selecting protocol printout • Standard printout • Printout in accordance with Template 1 • Printout in accordance with Template 2
ASci.Fmt LINE.Fmt LENGtH SEPArAt Add LF	Selecting formats for the protocol printout • Line format: MULtI (multi-line), SINGLE (single-line) or FIXEd • Line length: 0 ... 100 characters, appears only with line format MULtI or FIXEd • Separator: , ; . / \ _ and space; appears only with line format SINGLE • Line feed: 0 ... 9

3.6.3 COM1/COM2 -> PARAMET – communication parameter

bAuD	Selecting baud rate: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400 baud
PArity	Selecting parity: 7 none, 8 none, 7 odd, 8 odd, 7 even, 8 even
H.SHAKE	Select handshake: NO, XONXOFF, NET 422 (network operation via the optional RS422/RS485 interface via 4-wire bus, only for COM1), NET 485 (network operation via the optional RS422/RS485 interface via 2-wire bus, only for COM1)
NET.Addr	Assigning network address: 0 ... 31, only for NET 485
ChECsUM	Activating checksum byte (appears only in TOLEDO Continuous mode)
Vcc	Switching 5V voltage, e.g. for a bar code reader, on / off

3.6.4 COM1/COM2 -> RESET COM1/RESET COM2 – resetting serial interface to factory settings

SUrE?	Confirmation inquiry - Reset interface settings to factory settings with  - Do not reset the interface settings with 
--------------	---

3.6.5 OPTION – configuring options

If no option is installed or is not yet configured, N.A. appears in the display.

Eth.NET IP.AddrS SUBNET GAtEWAY	Configuration of the Ethernet interface - Enter IP address - Enter Subnet address - Enter Gateway address
USb USb TEST	Configuration of the USB interface Test of the USB interface. After the test has been passed, rEAdY appears in the display.
diGiTAL IN 0 ... 3 OFF ZErO tArE PriNt CLEAr UNIt	Configuration of the digital inputs/outputs Configuring inputs 0 ... 3 - Input not assigned - Key  - Key  - Key  - Key  - Key 

OUT 0 ... 3	Configuring outputs 0 ... 3
OFF	• Output not assigned
StAbLE	• Stable weight value
bEL.MIN	• Minimum weight not reached
AbV.MIN	• Minimum weight reached or exceeded
UNdErLd	• Insufficient load
OVERLd	• Overload
StAr	• Changed/calculated value
bEL.SP1	• Setpoint 1 not reached
AbV.SP1	• Setpoint 1 reached or exceeded
bEL.SP2	• Setpoint 2 not reached
AbV.SP2	• Setpoint 2 reached or exceeded
SEt.Pt1	Enter value for setpoint 1
SEt.Pt2	Enter value for setpoint 2

3.6.6 DEF.PRN – configuring templates

tEMPLt1/tEMPLt2	Selecting Template 1 or Template 2
LINE 1 ... 8	Select line
NOt.USEd	• Line not used
HEAdEr	• Line as header. The contents of the header must be defined via an interface command, see Section 4.1.
GROSS	• Gross weight
tArE	• Tare weight
nEt	• Net weight
StARLN	• Line with ***
CrLF	• Line feed (blank line)
F FEEd	• Page feed

3.7 Diagnosis and printing out of the menu settings (DIAGNOS)

tEST SC Internal External	Testing scale with internal calibration weight • -Int CAL- appears in the display during the test. • After completion of the test, ideally *d=0.0g briefly appears in the display, after which the scale changes to the next menu item KboArđ. Testing scale with external calibration weight 1. The scale checks the zero point. -0- appears in the display. The test weight flashes in the display. 2. If necessary, change the weight value displayed with T. 3. Put the calibration weight on the scale and confirm with . 4. The scale checks the calibration weight put on them. 5. After the test is completed, the deviation from the last calibration briefly appears in the display, ideally *d=0.0g, after which the scale changes to the next menu item KboArđ.
KboArđ PUSH 1 ... 6	Keyboard test • Press the keys  0 T    in order. If the key works, the scale changes to the next key. Note You cannot abort the keyboard test! If you have selected the menu item KboArđ, you must press all keys.
dISPLAY	Display test: The scale displays all functioning segments
SNr	Display of the serial number
List	Printout of a list of all menu settings
rESEt.AL SUrE?	Resetting all menu settings to the factory settings Confirmation inquiry • Reset all menu settings to the factory settings with . • Do not reset the menu settings with T.

4 Interface description

4.1 SICS interface commands

The compact scales BBA422 / BBA425 / BBK422 support the command set MT-SICS (METTLER TOLEDO **S**tandard **I**nterface **C**ommand **S**et). With SICS commands, it is possible to configure, query and operate the scales from a PC. SICS commands are divided up into various levels.

4.1.1 Available SICS commands

	Command	Meaning
LEVEL 0	@	Reset the scale
	I0	Inquiry of all available SICS commands
	I1	Inquiry of SICS level and SICS versions
	I2	Inquiry of scale data
	I3	Inquiry of scale software version
	I4	Inquiry of serial number
	I6	Inquiry of weighing parameters
	S	Send stable weight value
	SI	Send weight value immediately
	SIR	Send weight value repeatedly
	Z	Zero the scale
	ZI	Zero immediately
LEVEL 1	D	Write text into display
	DW	Weight display
	K	Keyboard check
	SR	Send and repeat stable weight value
	T	Tare
	TA	Tare value
	TAC	Clear tare
	TI	Tare immediately

In the case of Levels 0 and 1, these are commands which, if implemented, will function identically with all METTLER TOLEDO scales or weighing terminals.

In addition there are also further interface commands which apply either to the entire product series or to the particular application level. This and further information on the MT-SICS command set may be found in the MT-SICS Manual (Order Number 22 011 459 or at www.mt.com) or be obtained by request from your METTLER TOLEDO customer service representative.

4.1.2 Requirements for communication between scale and PC

- The scale must be connected to the RS232, RS485, USB or Ethernet interface of a PC with a suitable cable.
- The interface of the scale must be set to "Dialog" mode, see Section 3.6.1.
- A terminal program must be available on the PC, e.g. HyperTerminal.
- The communication parameters baud rate and parity must be set in the terminal program and on the scale to the same values, see Section 3.6.3.

4.1.3 Notes on network operation via the optional interface RS422/485

Up to 32 scales can be networked with the optional RS422/485 interface. In network operation, the scales must be addressed from the computer before commands can be sent and weighing results received.

Address	Hex	ASCII
0	0x30	0
1	0x31	1
2	0x32	2
...	...	...
9	0x39	9
10	0x3A	:
11	0x3B	;
...	...	...
31	0x4F	0

Description of the steps	Host	Direction	Scale
1. Host addresses the scale, e.g. with the address 3A hex.	<ESC> :	—>	
2. Host sends a SICS command, e.g. SI	SI <CRLF>	—>	
3. The scale confirms receipt of the command and sends the address back		<—	<ESC>:
4. The scale responds to the command and returns control of the bus to the host		<—	S_S___45.02_kg <CRLF>

4.2 TOLEDO Continuous mode

4.2.1 TOLEDO Continuous commands

In TOLEDO Continuous mode the scale supports the following input commands:

Command	Meaning
P	Printing out the current result
T	Taring of the scale
Z	Zero setting of the display
C	Deleting of the current value

4.2.2 Output format in TOLEDO Continuous mode

Weight values are always transferred in TOLEDO Continuous mode in the following format:

1	Status			Field 1						Field 2						17	18
	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
STX	SWA	SWB	SWC	MSD	–	–	–	–	LSD	MSD	–	–	–	–	LSD	CR	CHK
Field 1		Cont-Wt: 6 digits for the weight value that is transferred without comma and unit															
Field 2		Cont-Wt: 6 digits for the tare weight that is transferred without comma and unit															
STX		ASCII character 02 hex, character for "start of text"															
SWA, SWB, SWC		Status words A, B, C, see below															
MSD		Most significant digit															
LSD		Least significant digit															
CR		Carriage Return, ASCII character 0D hex															
CHK		Checksum (2-complement of the binary sum of the 7 lower bits of all the characters sent beforehand incl. STX and CR)															

Status word A								
Function	Selection	Status bit						
		6	5	4	3	2	1	0
Decimal position	X00	0	1			0	0	0
	X0					0	0	1
	X					0	1	0
	0.X					0	1	1
	0.0X					1	0	0
	0.00X					1	0	1
	0.000X					1	1	0
	0.0000X					1	1	1
Numerical increment	X1			0	1			
	X2			1	0			
	X5			1	1			

Status word B	
Function/Value	Bit
Gross/Net: Net = 1	0
Sign: Negative = 1	1
Overload/Underload = 1	2
Movement = 1	3
lb/kg: kg = 1	4
1	5
Power up = 1	6

Status word C				
Function/Value				Bit
kg/lb	g	t	oz	
0	1	0	1	0
0	0	1	1	1
0	0	0	0	2
Print request = 1				3
Extended = 1				4
1				5
Tare manually, only kg = 1				6

5 Event and error messages

Error	Cause	Remedy
Display Dark	• Back lighting set too dark • No mains voltage • Unit switched off • Mains cable not plugged in • Brief fault	→ Set back lighting (b.LIGHT) brighter → Check mains → Switch on unit → Plug in mains plug → Switch device off and back on again
Insufficient load L _ _ _ _ J	• Load plate not on the scale • Weighing range not reached	→ Place load plate on the scale → Set to zero
Overload r _ _ _ _ 7	• Weighing range exceeded	→ Unload scale → Reduce preload
_ _ _ _ _	• Result not yet stable	→ If necessary adjust vibration adapter or weigh dynamically
_ _ n o _ _	• Function not permissible	→ Unload scale and set to zero
r _ _ n o _ 7 L _ _ n o _ J	• Zeroing not possible with overload or insufficient load	→ Unload scale
E r r 6	• No calibration	→ Unplug the mains plug then plug it back in; switch unit off and then back on in battery mode → Calibrate scale → Call METTLER TOLEDO Service
E r r 17	• Printout not yet ended	→ End printout → Repeat required action
E r r 18	• Switching the weighing unit impermissible during dynamic weighing	→ End dynamic weighing → Switch weighing unit
E r r 53	• EARM checksum error	→ Unplug the mains plug then plug it back in; switch unit off and then back on in battery mode → Call METTLER TOLEDO Service

Error	Cause	Remedy
Weight display unstable	• Restless installation location • Draft • Restless weighing sample • Contact between weighing pan and/or weighing sample and surroundings • Mains fault	→ Adjust vibration adapter → Avoid drafts → Dynamic weighing → Remedy contact → Check mains
Incorrect weight display	• Incorrect zeroing • Incorrect tare value • Contact between weighing pan and/or weighing sample and surroundings • Scale tilted	→ Unload scale, set to zero and repeat weighing operation → Clear tare → Remedy contact → Level scale

6 Technical data and accessories

6.1 Technical data

6.1.1 Type key

The compact scales BBA422 / BBA425 / BBK422 are available with various capacities and platforms that can be seen from the complete type designation.

Example

BBA422 – **6 PM** compact scale with capacity **6 kg** and **small platform**

BBA425 – **35 SM** compact scale with capacity **35 kg** and **large platform**

6.1.2 General data

BBA422 / BBA425 / BBK422	
Applications	• Weighing • Dynamic weighing
Settings	• Resolution selectable • Weighing unit selectable: g, kg, oz, lb, t • Taring function: manual, automatic, chain tare • Automatic zero point correction when the scale is switched on and during operation • Filter for adapting to the ambient conditions (vibration adapter) • Filter for adapting to the weighing type, e.g. dispensing (weighing process adapter) • Switch-off function, sleep mode for mains-operated devices, energy-saving mode for battery operation • Display lighting
Accuracy class OIML/NTEP	• BBA4.. III • BBK4.. II
Display	• LCD (liquid crystal display), digits 0.63" (16 mm) high, with back lighting
Keypad	• Pressure point membrane keypad • Scratch-proof labeling
Housing	• Diecast aluminum housing; chromium nickel steel weighing pan • Dimensions, see Page 37
Protection Class (IEC 529, DIN 40050, EN60529)	• BBA422 / BBK422 IP43 (not with Ethernet interface) • BBA425 IP65

BBA422 / BBA425 / BBK422	
Mains connection	Direct connection to the mains (MAINS supply voltage fluctuations up to $\pm 10\%$ of the nominal voltage): • 120 V, 60 Hz, 90 mA • 100 V, 50/60 Hz, 90 mA For battery operation: • Connection via mains adapter: 90 – 264 V, 47 – 63 Hz, 300 mA • Infeed on the unit: 24 V, 1.3 A
Battery operation	If the voltage supply is interrupted, the unit automatically switches over to battery operation
Ambient conditions	• Use Indoor use only • Altitude up to 2000 m • Temperature range BBA4.. $-10 \dots +40 \text{ }^{\circ}\text{C}$ / $14 \dots 104 \text{ }^{\circ}\text{F}$ • Temperature range BBK4.. $+10 \dots +30 \text{ }^{\circ}\text{C}$ / $50 \dots 86 \text{ }^{\circ}\text{F}$ • Installation/overvoltage category II • Pollution degree 2 • Relative humidity Maximum relative humidity 80 % for temperatures up to $31 \text{ }^{\circ}\text{C}$ / $88 \text{ }^{\circ}\text{F}$, decreasing linearly to 50 % relative humidity at $40 \text{ }^{\circ}\text{C}$ / $104 \text{ }^{\circ}\text{F}$
Interfaces	• 1 RS232 interface integrated • 1 other optional interface possible

6.1.3 Weighing ranges and readability BBA4..


The compact scales BBA4.. with strain gauge weighing cells are supplied in the configuration 1 x 15.000 d.

Model	Weighing range	Readability d	Verification value e
BBA4.. – 3 P..	6 lb / 3 kg	0.0005 lb / 0.0002 kg	0.001 lb / 0.0005 kg
BBA4.. – 6 P..	12 lb / 6 kg	0.001 lb / 0.0005 kg	0.002 lb / 0.001 kg
BBA4.. – 15 S..	30 lb / 15 kg	0.002 lb / 0.001 kg	0.005 lb / 0.002 kg
BBA4.. – 35 S..	70 lb / 35 kg	0.005 lb / 0.002 kg	0.01 lb / 0.005 kg
BBA4.. – 60 S..	120 lb / 60 kg	0.01 lb / 0.005 kg	0.02 lb / 0.01 kg

6.1.4 Weighing ranges and readability BBK4..

Model	Weighing range	Readability d	Verification value e
BBK4.. – 3 P..	6 lb / 3 kg	0.00002 lb / 0.00001 kg	0.0002 lb / 0.0001 kg
BBK4.. – 6 P..	12 lb / 6 kg	0.00005 lb / 0.00002 kg	0.0005 lb / 0.0002 kg
BBK4.. – 15 S..	30 lb / 15 kg	0.0001 lb / 0.00005 kg	0.001 lb / 0.0005 kg
BBK4.. – 35 S..	70 lb / 35 kg	0.0002 lb / 0.0001 kg	0.002 lb / 0.001 kg

6.1.5 Dimensions



	A	B	C	D	E	F	G	H	I	K	L
P ¹⁾	13.19	10.43	3.94	9.45	7.87	1.81	10.87	8.19	8.47	6.50	6.50
S ¹⁾	14.57	14.17	4.53	13.78	9.45	2.05	12.24	12.00	12.24	–	–

¹⁾ dimensions in inch

6.1.6 Net weights

Model	without battery	with battery	with internal calibration weight (without battery)
With strain gauge cell:			
BBA4.2 – ..P..	10.2 lb (4.6 kg)	11.6 lb (5.3 kg)	–
BBA4.2 – ..S..	18.0 lb (8.2 kg)	19.4 lb (8.9 kg)	–
BBA425 – ..PM	10.3 lb (4.7 kg)	11.8 lb (5.4 kg)	–
BBA425 – ..SM	18.1 lb (8.3 kg)	19.6 lb (9.0 kg)	–
With Monobloc cell:			
BBK4.2 – ..P.., extra small load plate	10.7 lb (4.9 kg)	12.2 lb (5.6 kg)	11.8 lb (5.4 kg)
BBK4.2 – ..P..	10.3 lb (4.7 kg)	11.8 lb (5.4 kg)	11.3 lb (5.2 kg)
BBK4.2 – ..S..	22.9 lb (10.5 kg)	24.4 lb (11.2 kg)	25.5 lb (11.7 kg)

6.1.7 Interface connections

The compact scale can be fitted with a maximum of 2 interfaces. The following combinations are possible:

COM1	COM2	Note
RS232	–	
RS232	RS232	
RS485	RS232	COM1 can be optionally operated as RS422 or RS485
RS232	Ethernet	10BaseT, RJ45 (not for BBA425)
RS232	USB	USB 1.1, Type B
RS232	Digital I/O	4 x in, 4 x out, D-Sub 9

6.1.8 Assignment of the interface connections

Pin	RS232 (COM1/COM2)	RS422 (4-wire, COM1)	RS485 (2-wire, COM1)	Digital I/O (COM2)
1	–	–	–	GND
2	TxD1/2	TxD1–	TxD1–/RxD1–	OUT0
3	RxD1/2	RxD1–	–	OUT1
4	–	–	–	OUT2
5	GND	GND	GND	OUT3
6	–	–	–	IN0
7	–	TxD1+	TxD1+/RxD1+	IN1
8	–	RxD1+	–	IN2
9	VCC	VCC	VCC	IN3

6.2 Accessories

Designation	Order number
Protective cover for small model	21 203 207
Protective cover for large model	21 203 206
Second display RS-PD/PASM	21 302 875
Second display ADI412	22 013 978
Second display ADI412-B, with backlighting	22 013 977
Relay box 4 for connection to digital I/O interface	22 011 967
Connection cable for relay box 4, length approx. 1.5 m	21 254 225
Anti-theft device	00 229 175
RS232 cable for PC, 39.37" (1.8 m) long	00 410 024

7 Appendix

7.1 Safety checks

The compact scales of the series BBA422 / BBA425 / BBK422 have been checked by accredited testing institutions. They have passed the safety checks listed below and carry the relevant test symbols. Production is subject to production monitoring by the inspection offices.

Country	Test symbol	Standard
Canada USA		CAN/CSA-C22.2 No. 1010.1-92 UL Std. No. 61010A-1
Other countries	CB Scheme (no identification)	IEC/EN61010-1:2001

7.2 FCC

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to both Part 15 of the FCC Rules and the radio interference regulations of the Canadian Department of Communications. These limits are designed to provide a reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the user manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Cet appareil a été testé et s'est avéré conforme aux limites prévues pour les appareils numériques de class A et à la partie 15 des règlements FCC et à la réglementation des radio-Interférences du Canadian Department of Communications. Ces limites sont destinées à fournir une protection adéquate contre les interférences néfastes lorsque l'appareil est utilisé dans un environnement commercial. Cet appareil génère, utilise et peut radier une énergie à fréquence radioélectrique; il est en outre susceptible d'engendrer des interférences avec les communications radio, s'il n'est pas installé et utilisé conformément aux instructions du mode d'emploi. L'utilisation de cet appareil dans les zones résidentielles peut causer interférences néfastes, auquel cas l'exploitant sera amené à prendre les dispositions utiles pour palier aux interférence à ses propres frais.

8 Index

A

Accessories	39
Adjustment	21
Alignment	9
Ambient conditions	36
Applications	35
Average	14, 23

C

Calibrate	21
Chain tare	13
Continuous mode	31

D

Dimensions	37
Display	7
Display accuracy	21
Dynamic weighing	14, 23

E

Error messages	33
----------------------	----

F

Filter	22
--------------	----

I

Interface protocol	31
Interfaces	
Configure	25
Connections	38

K

Keyboard	8
----------------	---

M

Mains connection	36
Menu	
Application	23
Communication	25
Diagnosis	28
Operation	16
Overview	18
Scale	21
Terminal	24
Menu structure	17

O

Operator menu	16
Options	5, 26

P

Password	16
Power supply	10
Protocol	14

R

Readability	36
Reset	
Application	23
Interface	26
Scale	23
Terminal	24
RS422/RS485	30

S

Safety checks	40
Scales types	5
Settings	35
SI/CS commands	29
Supervisor menu	16
Switching off	12
Switching on	12

T

Tare	
Automatic	13
Chain tare	13
Clear	13
Terminal settings	24
TOLEDO Continuous	31
Type key	35

W

Weighing ranges	36
Weighing unit	21
Weight	38

Z

Zeroing	12
---------------	----



22013180B

Subject to technical changes © Mettler-Toledo (Albstadt) GmbH 05/08 Printed in Germany 22013180B

Mettler-Toledo (Albstadt) GmbH

D-72458 Albstadt

Tel. ++49-7431-14 0, Fax ++49-7431-14 232

Internet: <http://www.mt.com>