

Indstilling af relæer [ACTI]:P




Table of contents

Warnings	22
Safety instructions.....	23
Declaration of C onformity.....	25
F ront and back layout.....	26
A pplications.....	27
T echnical characteristics.....	27
M ounting	27
A pplications.....	28
O rder	29
E lectrical specifications.....	29
S ensor error detection	32
C onnections	34
B lock diagram.....	35
R oute diagram.....	36
S crolling help text.....	38
C onfiguration /operating function keys.....	39
S etting of relays	40



GENERAL

WARNING!

This module is designed for connection to hazardous electric voltages. Ignoring this warning can result in severe personal injury or mechanical damage. To avoid the risk of electric shock and fire, the safety instructions of this manual must be observed and the guidelines followed. The specifications must not be exceeded, and the module must only be applied as described in the following. Prior to the commissioning of the module, this manual must be examined carefully. Only qualified personnel (technicians) should install this module.

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



HAZARDOUS VOLTAGE

WARNING!

Until the module is fixed, do not connect hazardous voltages to the module.

The following operations should only be carried out on a disconnected module and under ESD safe conditions:
Troubleshooting the module.

Repair of the module must be done by PR electronics A/S only.



Symbol identification



Triangle with an exclamation mark: Warning / demand. Potentially lethal situations.



The CE mark proves the compliance of the module with the essential requirements of the directives.

Safety instructions

DEFINITIONS:

Hazardous voltages have been defined as the ranges: 75 to 1500 Volt DC, and 50 to 1000 Volt AC.

Technicians are qualified persons educated or trained to mount, operate, and also troubleshoot technically correct and in accordance with safety regulations. Operators, being familiar with the contents of this manual, adjust and operate the knobs or potentiometers during normal operation.

RECEIPT AND UNPACKING:

Unpack the module without damaging it and make sure that the manual always follows the module and is always available. The packing should always follow the module until this has been permanently mounted.

Check at the receipt of the module whether the type corresponds to the one ordered.

ENVIRONMENT:

Avoid direct sunlight, dust, high temperatures, mechanical vibrations and shock, as well as rain and heavy moisture. If necessary, heating in excess of the stated limits for ambient temperatures should be avoided by way of ventilation.

All modules fall under Installation Category II, Pollution Degree 1, and Insulation Class II.

MOUNTING:

Only technicians who are familiar with the technical terms, warnings, and instructions in the manual and who are able to follow these should connect the module.

Should there be any doubt as to the correct handling of the module, please contact your local distributor or, alternatively,

**PR electronics A/S, Lerbakken 1Q DK-8410 Rønde, Denmark,
tel: +45 86 37 26 77.**

Mounting and connection of the module should comply with national legislation for mounting of electric materials, i.e. wire cross section, protective fuse, and location. Descriptions of Input / Output and supply connections are shown in the block diagram and side label.

The following apply to fixed hazardous voltages-connected modules:

The max. size of the protective fuse is 10 A and, together with a power switch, it should be easily accessible and close to the module.

The power switch should be marked with a label telling it will switch off the voltage to the module.

CALIBRATION AND ADJUSTMENT:

During calibration and adjustment, the measuring and connection of external voltages must be carried out according to the specifications of this manual. The technician must use tools and instruments that are safe to use.

NORMAL OPERATION:

Operators are only allowed to adjust and operate modules that are safely fixed in panels, etc., thus avoiding the danger of personal injury and damage. This means there is no electrical shock hazard, and the module is easily accessible.

CLEANING:

When disconnected, the module may be cleaned with a cloth moistened with distilled water or ethyl alcohol.

LIABILITY:

To the extent the instructions in this manual are not strictly observed, the customer cannot advance a demand against PR electronics A/S that would otherwise exist according to the concluded sales agreement.

DECLARATION OF CONFORMITY

As manufacturer

PR electronics A/S

Lerbakken 10

DK-8410 Rønde

hereby declares that the following product

Type: 5714

Name: PROGRAMMABLE LED INDICATOR

From serial No: 040189001

is in conformity with the following directives and standards:

EMC directive 89/336/EEC and later amendments

EN 61 326

This declaration is issued in compliance with article 10, subclause 1 of the EMC directive. For specification of the acceptable EMC performance level, refer to the electrical specifications for the module.

The Low Voltage directive 73/23/EEC and later amendments

EN 61 010-1

Rønde, 23 February 2004




Peter Rasmussen
Manufacturer's signatur

Front and back layout



Picture 1: Front of PRview 5714.



Picture 2: Back of PRview 5714.

Programmable LED indicator PRview 5714

- 4-digit 14 segment LED indicator
- Input for mA, V, Pt100 TC and potentiometer
- 2 relays and analogue output
- Universal voltage supply
- Front key programmable

Application:


- Display for digital readout of current, voltage, temperature or potentiometer signals.
- Process control with 2 potential free relays and / or analogue output
- For local readout in extreme wet atmospheres with a special designed splash-proof cover.

Technical characteristics:

- 4-digit LED indicator with 13.8 mm 14 segment characters. Max. display readout -1999...9999 with programmable decimal point, relay ON / OFF-indication.
- With the function front keys all operational parameters can be adjusted to any application.
- PRview 5714 is available fully-configured acc. to specifications ready for process control and visualisation.
- In versions with relay outputs the user can minimise the installation test time by activating / deactivating each relay independent of the input signal.

Mounting:

- To be mounted in board front panel. An included rubber packing must be mounted between the panel cutout hole and the display front to obtain IP65 (NEMA 4) tightness. PRview 5714 can be delivered with a special designed splash-proof cover as accessory to obtain IP67 tightness.



Order: 5714

Type	Version	Language
5714	Standard : A 2 Relays : B Analogue output : C Analogue output and 2 relays : D	English : UK Dansk : DK Français : FR Deutsch : DE Svenska : SE Italiano : IT Espanöl : ES

NB! Please order the splash-proof cover (IP 67) seperately. Order No 8335.

Electrical specifications:

Specifications range:

-20°C to +60°C

Common specifications:

Supply voltage..... 24...230 VAC ±10%
 50...60 Hz
 24...250 VDC ±20%

Max. consumption ≤ 3.5 W

Isolation voltage / operation..... 2.3 kVAC / 250 VAC

Signal- / noise ratio..... min. 60 dB (0...100 kHz)

Response time (0...90 % , 100...10 %):

Temperature input..... < 1 s

Current / Voltage input..... < 400 ms

Calibration temperature 20...28°C

Accuracy, the greater of general and basic values:

General values		
Input type	Absolute accuracy	Temperature coefficient
All	≤ ±0.1% of reading	≤ ±0.01% of reading / °C

Basic values		
Input type	Basic accuracy	Temperature coefficient
mA	$\leq \pm 4 \mu\text{A}$	$\leq \pm 0,4 \mu\text{A} / ^\circ\text{C}$
Volt	$\leq \pm 20 \mu\text{V}$	$\leq \pm 2 \mu\text{V} / ^\circ\text{C}$
Pt100	$\leq \pm 0,2^\circ\text{C}$	$\leq \pm 0,02^\circ\text{C} / ^\circ\text{C}$
Potentiometer	$\leq \pm 0,1 \Omega$	$\leq \pm 0,01 \Omega / ^\circ\text{C}$
TC -type: E, J, K, L, N, T, U	$\leq \pm 1^\circ\text{C}$	$\leq \pm 0,05^\circ\text{C} / ^\circ\text{C}$
TC -type: B, R, S, W3, W5	$\leq \pm 2^\circ\text{C}$	$\leq \pm 0,2^\circ\text{C} / ^\circ\text{C}$

Auxiliary supplies:

2 wire supply	25...15 VDC / 0...20 mA
Wire size, pin 41-46 (max.).....	1 x 1.5 mm ² multicore cable
Wire size, others (max.).....	1 x 2.5 mm ² multicore cable
Screw terminal torsion.....	0.5 Nm
Relative humidity.....	< 95% RH (non cond.)
Dimensions (HxWxD).....	48 x 96 x 120 mm
Cutout dimensions.....	44.5 x 91.5 mm
Tightness (mounted in panel).....	IP65 (IP67 with cover 8335)
Weight.....	230 g

Pt100- and potentiometer input:

Input type	Min. value	Max. value	Norm
Pt100	-200°C	+850°C	IEC 60751
Potentiometer	10 Ω	100 kΩ	-

Cable resistance pr. wire, Pt100 (max.)	50 Ω
Sensor current, Pt100	Nom. 0.2 mA
Effect of sensor cable resistance (3- / 4-wire), Pt100.....	< 0.002 Ω / Ω
Sensor error detection, Pt100	Yes
Short circuit detection, Pt100	< 15 Ω

TC input:

Type	Min. value	Max. value	Norm
B	+400°C	+1820°C	IEC 60584-1
E	-100°C	+1000°C	IEC 60584-1
J	-100°C	+1200°C	IEC 60584-1
K	-180°C	+1372°C	IEC 60584-1
L	-200°C	+900°C	DIN 43710
N	-180°C	+1300°C	IEC 60584-1
R	-50°C	+1760°C	IEC 60584-1
S	-50°C	+1760°C	IEC 60584-1
T	-200°C	+400°C	IEC 60584-1
U	-200°C	+600°C	DIN 43710
W3	0°C	+2300°C	ASTM E 988-90
W5	0°C	+2300°C	ASTM E 988-90

Cold junction compensation (CJC)..... < $\pm 1.0^\circ\text{C}$

Sensor error detection..... Yes

Sensor error current

when detecting Nom. 2 μA

else 0 μA

Current input:

Measure range..... -1...25 mA

Programmable measure ranges..... 0...20 and 4...20 mA

Input resistance..... Nom. 20 Ω + PTC 25 Ω

Voltage input:

Measure range..... -20 mV...12 VDC

Programmable measure ranges..... 0...1, 0,2...1,
0...10 and 2...10 VDC

Input resistance..... Nom. 10 MΩ

Display:

Display readout..... -1999...9999 (4 digits)

Decimal point..... Programmable

Digit height..... 13.8 mm

Display updating..... 2.2 times / s

Input outside input range is
indicated by..... Explaining text

Current output:

Signal range (span).....	0...20 mA
Programmable signal ranges.....	0...20, 4...20, 20...0 and 20...4 mA
Load (max.).....	20 mA / 800 Ω / 16 VDC
Load stability.....	≤ 0.01% of span / 100 Ω
Sensor error detection.....	0 / 3,5 / 23 mA or none
NAMUR NE 43 Upscale.....	23 mA
NAMUR NE 43 Downscale.....	3,5 mA
Current limit.....	≤ 28 mA

Relay outputs:

Max. voltage.....	250 VRMS
Max. current.....	2 A / AC
Max. AC power.....	500 VA
Max. current at 24 VDC.....	1 A
Sensor error detection.....	Make/Break/Hold

Marine approval:

Det Norske Veritas Rules for ships..... Certificat. Notes No.2.4

Observed authority requirements: Standard:

EMC 89/336/EEC:

Emission and immunity..... EN 61326

LVD 73/23/EEC..... EN 61010-1

UL, S standard for Safety:..... UL 508 and UL 873

Sensor error detection / sensor error detection outside range:

Sensor error check in 5714 variants		
Variant	Configuration	Sensor error detection:
5714A	Always:	ON
5714B	ERR1=NONE, ERR2=NONE:	OFF
	else:	ON
5714C	O.ERR=NONE:	OFF
	else:	ON
5714D	ERR1=NONE, ERR2=NONE, O.ERR=NONE:	OFF
	else:	ON

Outside range readout (IN.LO, IN.HI): At excession of the valid range of the A/D converter or the polynomial			
Input	Range	Readout	Limit
VOLT	0.1V / 0.2..1V	IN.LO	< -25 mV
		IN.HI	> 1,2 V
	0.10V / 2..10V	IN.LO	< -25 mV
		IN.HI	> 12 V
CURR	0..20mA / 4..20mA	IN.LO	< -1,05 mA
		IN.HI	> 25,05 mA
POTM	-	IN.LO	< -0,5%
		IN.HI	> 100,5%
TEMP	TC / PT-100	IN.LO	< temperature range
		IN.HI	> temperature range

Sensor error detection (SE.BR, SE.SH):			
Input	Range	Readout	Limit
CURR	Loop break (4..20mA)	SE.BR	<= 3,6 mA; >= 21 mA
		SE.SH	> ca. 750 kohm / (1,25V)
TEMP	TC	SE.BR	> ca. 15 kohm
		SE.SH	< ca. 15 ohm
	PT-100 2-wire	SE.BR	> ca. 15 kohm
		SE.SH	< ca. 15 ohm
	PT-100 3-wire	SE.BR	> ca. 15 kohm
		SE.SH	< ca. 15 ohm
	PT-100 4-wire	SE.BR	> ca. 15 kohm
		SE.SH	< ca. 15 ohm


Display readout below min. / above max. (-1.9.9.9, 9.9.9.9):			
Input	Range	Readout	Limit
CURR	All	-1.9.9.9	Display readout < -1999
		9.9.9.9	Display readout > 9999
VOLT	All	-1.9.9.9	Display readout < -1999
		9.9.9.9	Display readout > 9999
POTM	-	-1.9.9.9	Display readout < -1999
		9.9.9.9	Display readout > 9999

Readout at hardware error		
Error search	Readout	Error cause
Test of internal communication uC / ADC	HW.ER	Permanent error in ADC
Test of internal CJC sensor	CJ.ER	CJC sensor defect
Check-sum test of the configuration in RAM	RA.ER	Error in RAM
Check-sum test of the configuration in EEPROM	EE.ER	Error in EEPROM


! Error indications in the display blinks once a second. The help text explains the error.

Connections:


Supply:




Input:




Output:



Block diagram






Routing diagram

If no keys are activated for 2 minutes the display returns to default state 1.0 without saving configuration changes.

- ⬆ Increase value / choose next parameter
- ⬇ Decrease value / choose previous parameter
- Ⓚ Save the chosen parameter and go to the next menu
- Hold Ⓚ Back to previous menu / return to menu 1.0 without saving



Scrolling help text

Process Value (Normal): xxxx	INCR --> ACTIVATE AT INCREASING SIGNAL
SE.BR --> SENSOR WIRE BREAKAGE	DECR --> ACTIVATE AT DECREASING SIGNAL
SE.SH --> SENSOR SHORT CIRCUIT	HYS2
IN.HI --> INPUT OVERRANGE	xxxx --> HYSTERESIS RELAY 2
IN.LO --> INPUT UNDERANGE	
9.9.9.9 --> DISPLAY OVERRANGE	ERR2
-1.9.9.9 --> DISPLAY UNDERANGE	HOLD --> HOLD RELAY AT ERROR
HW.ER --> HARDWARE ERROR	ACT1 --> ACTIVATE RELAY AT ERROR
EE.ER --> EEPROM MEMORY ERROR	DEAC --> DEACTIVATE RELAY AT ERROR
RA.ER --> RAM MEMORY ERROR	NONE --> UNDEFINED STATUS AT ERROR
CJ.ER --> CJC SENSOR ERROR	
NO.CA --> DEVICE NOT CALIBRATED	A.OUT
FastSet (set enabled):	20-4 --> OUTPUT RANGE IN mA
REL1	20-0 --> OUTPUT RANGE IN mA
xxxx --> SETPOINT RELAY 1 - PRESS OK TO SAVE	4-20 --> OUTPUT RANGE IN mA
REL2	0-20 --> OUTPUT RANGE IN mA
xxxx --> SETPOINT RELAY 2 - PRESS OK TO SAVE	
FastSet (set disabled):	O.LO
REL1	xxxx --> DISPLAY VALUE FOR OUTPUT LOW
xxxx --> SETPOINT RELAY 1 - READ ONLY	
REL2	O.HI
xxxx --> SETPOINT RELAY 2 - READ ONLY	xxxx --> DISPLAY VALUE FOR OUTPUT HIGH
Configuration Setup:	
PASS	O.ERR
xxxx --> SET PASSWORD	23mA --> NAMUR NE43 UPSCALE AT ERROR
	3.5mA --> NAMUR NE43 DOWNSCALE AT ERROR
IN	0mA --> DOWNSCALE AT ERROR
POTM --> POTENTIOMETER INPUT	NONE --> UNDEFINED OUTPUT AT ERROR
CURR --> CURRENT INPUT	
VOLT --> VOLTAGE INPUT	E.PAS
TEMP --> TEMPERATURE SENSOR INPUT	NO --> ENABLE PASSWORD PROTECTION
	YES --> ENABLE PASSWORD PROTECTION
RANG (when volt selected)	
2-10 --> INPUT RANGE IN VOLTS	N.PAS
0-10 --> INPUT RANGE IN VOLTS	xxxx --> SELECT NEW PASSWORD
0.2-1 --> INPUT RANGE IN VOLTS	
0.0-1 --> INPUT RANGE IN VOLTS	RANG (when current selected)
	4-20 --> INPUT RANGE IN mA
DEC.P	0-20 --> INPUT RANGE IN mA
1111 --> DECIMAL POINT POSITION	
111.1 --> DECIMAL POINT POSITION	CA.LO
11.11 --> DECIMAL POINT POSITION	YES --> CALIBRATE POTENTIOMETER LOW
1.111 --> DECIMAL POINT POSITION	NO --> CALIBRATE POTENTIOMETER LOW
DI.LO	
xxxx --> DISPLAY READOUT LO W	CA.HI
DI.HI	YES --> CALIBRATE POTENTIOMETER HIGH
xxxx --> DISPLAY READOUT HIGH	NO --> CALIBRATE POTENTIOMETER HIGH
REL.U	
PERC --> SET RELAY IN PERCENTAGE	UNIT
DISP --> SET RELAY IN DISPLAY UNITS	°F FAHRENHEIT
	°C CELSIUS
REL1	TYPE
xxxx --> SETPOINT RELAY 1	TC.W5 --> TC TYPE W5
	TC.W3 --> TC TYPE W3
ACT1	TC.U --> TC TYPE U
INCR --> ACTIVATE AT INCREASING SIGNAL	TC.T --> TC TYPE T
DECR --> ACTIVATE AT DECREASING SIGNAL	TC.S --> TC TYPE S
	TC.R --> TC TYPE R
HYS1	TC.N --> TC TYPE N
xxxx --> HYSTERESIS RELAY 1	TC.L --> TC TYPE L
	TC.K --> TC TYPE K
ERR1	TC.J --> TC TYPE J
HOLD --> HOLD RELAY AT ERROR	TC.E --> TC TYPE E
ACT1 --> ACTIVATE RELAY AT ERROR	TC.B --> TC TYPE B
DEAC --> DEACTIVATE RELAY AT ERROR	PT.4W --> PT-100 4-WIRE
NONE --> UNDEFINED STATUS AT ERROR	PT.3W --> PT-100 3-WIRE
REL2	PT.2W --> PT-100 2-WIRE
xxxx --> SETPOINT RELAY 2	
ACT2	DEC.P (when temp selected)
	1111 --> DECIMAL POINT POSITION
	111.1 --> DECIMAL POINT POSITION

Configuration / Operating function keys

Documentation for routing diagram

In general:

When configuring the display you are guided through all parameters, you can choose the settings which fit the application. For each menu there is a scrolling help text which is automatically shown in the display, this starts after 5 seconds if no key has been activated.

Configuration is carried out by using the 3 function keys.

- ⬆ will increase the numerical value or choose the next parameter.
- ⬇ will decrease the numerical value or choose the previous parameter.
- Ⓚ will accept the chosen value and end the menu.

If a function does not exist in the display all parameters are skipped to make the configuration as simple as possible.

Once the configuration has been entered the display will show "----".

Pressing and holding Ⓚ will return to the previous menu or return to the default state (1.0) without saving the changed values or parameters.

If no key is activated for 2 minutes, the display will return to the default state (1.0) without saving the changed values or parameters.

Further explanations:

Fast setpoint adjustment and relay test:

These menus allow you to change the set point quickly and to check the operation of the relays.

Pressing ⬆ and ⬇ at the same time will change the state of the relay – this change is indicated by the diodes on the display.

Pressing Ⓚ will save the set point change.

Holding down Ⓚ for more than 0.5 seconds will return the unit to the default state without changing the set point

Password protection:

Using a password will stop access to the menu and parameters.

There are two levels of password protection.

Passwords between 0000... 4999 allow access to the fast set point adjustment and relay test


(Using this password stops access to all other parts of the menu)

Passwords between 5000... 9999 stop access to all parts of the menu, fast set point and relay test

(Current set point is still shown)

By using the master password 2008, all configuration menus are available.

Setting of relays [ACT1]:



Sommaire

Avertissements.....	42
Consignes de sécurité	43
Déclaration de conformité.....	45
Vu de la face avant et arrière	46
Application	47
Caractéristiques techniques	47
Montage	47
Applications.....	48
Référence de commande.....	49
Spécifications électriques	49
Détection erreur capteur.....	52
Connexions	54
Schéma de principe.....	55
Diagramme de programmation.....	56
Le menu déroulant.....	58
Configuration.....	59
Réglage de l'action du relais.....	60