



Operator's Manual

Serial Number Range

***AWP® Super
Series***

from AWPP-100000

ANSI/CSA
North America
South America
Asia

with
Maintenance
Information

Original Instructions
Fifth Edition
Second Printing
Part No. 1298033GT

Contents

| | |
|---|----|
| Introduction | 1 |
| Symbol and Hazard Pictorials Definitions..... | 5 |
| General Safety | 7 |
| Personal Safety..... | 11 |
| Work Area Safety | 12 |
| Legend | 18 |
| Controls..... | 19 |
| Inspections | 20 |
| Operating Instructions..... | 30 |
| Maintenance | 33 |
| Battery Charging Instructions | 36 |
| Transport Instructions | 37 |
| Tilt-back Operation Instructions | 41 |
| Specifications | 44 |

Copyright © 1996 Terex Corporation

Fifth Edition: Second Printing, February 2022

"Genie" and "AWP" are registered trademarks of Terex South Dakota in the U.S.A. and many other countries.

"Super Series" is a trademark of Terex South Dakota.

These machines comply with
ANSI/SAIA A92.20
CAN/CSA B354.6



Introduction


About this manual

Genie appreciates your choice of our machine for your application. Our number one priority is user safety, which is best achieved by our joint efforts. This book is an operation and daily maintenance manual for the user or operator of a Genie machine.

This manual should be considered a permanent part of your machine and should remain with the machine at all times. If you have any questions, contact Genie.

Product Identification

The machine serial number is located on the serial label.



Serial labelSerial number stamped on chassis


Intended Use and Familiarization Guide

The intended use of this machine is to lift personnel, including tools, and materials to an aerial work site. Before operating the machine, it's the operator's responsibility to read and understand this familiarization guide.


- ☒ Each person must be trained to operate a Mobile Elevating Work Platform (MEWP).
- ☒ Familiarization with the MEWP must be given to each person who is authorized, competent and trained.
- ☒ Only trained and authorized personnel should be permitted to operate the machine.
- ☒ The operator is responsible to read, understand, and obey the manufacturer's instructions and safety rules provided in the Operator's Manual.
- ☒ The Operator's Manual is located in the manual storage container, at the platform.
- ☒ For specific product applications, see **Contacting The Manufacturer**.

Introduction

Platform controls symbology and related machine movement:



Ground controls symbology and related machine movement:



Platform controls



Emergency platform lowering



Low battery indicator



Air pressure



Interlocked functions:

- All platform and ground controls.

Limitations of use:

- The intended use of this machine is to lift personnel, including tools, and materials to an aerial work site.
- Do not elevate the platform unless the machine is on firm level ground.

Introduction

Bulletin Distribution and Compliance

Safety of product users is of paramount importance to Genie. Various bulletins are used by Genie to communicate important safety and product information to dealers and machine owners.

The information contained in the bulletins is tied to specific machines using the machine model and serial number.

Distribution of bulletins is based on the most current owner on record along with their associated dealer, so it is important to register your machine and keep your contact information up to date.

To ensure safety of personnel and the reliable continued operation of your machine, be sure to comply with the action indicated in a respective bulletin.

To view any open bulletins for your machine, visit us on the web at www.genielift.com.

Contacting the Manufacturer

At times it may be necessary to contact Genie. When you do, be ready to supply the model number and serial number of your machine, along with your name and contact information. At minimum, Genie should be contacted for:

Accident reporting

Questions regarding product applications and safety

Standards and regulatory compliance information

Current owner updates, such as changes in machine ownership or changes in your contact information. See Transfer of Ownership, below.

Transfer of Machine Ownership

Taking a few minutes to update owner information will ensure that you receive important safety, maintenance and operating information that applies to your machine.

Please register your machine by visiting us on the web at www.genielift.com or by calling us toll free at 1-800-536-1800.

Introduction



Danger

Failure to obey the instructions and safety rules in this manual will result in death or serious injury.

Do Not Operate Unless:

- ☑ You learn and practice the principles of safe machine operation contained in this operator's manual.
 - 1 Avoid hazardous situations.**

Know and understand the safety rules before going on to the next section.

 - 2 Always perform a pre-operation inspection.
 - 3 Always perform function tests prior to use.
 - 4 Inspect the workplace.
 - 5 Only use the machine as it was intended.
- ☑ You read, understand and obey the manufacturer's instructions and safety rules—safety and operator's manuals and machine decals.
- ☑ You read, understand and obey employer's safety rules and worksite regulations.
- ☑ You read, understand and obey all applicable governmental regulations.
- ☑ You are properly trained to safely operate the machine.
- ☑ The first time this machine is set up for use, a breather cap is installed. See Pre-operation Inspection section for breather cap instructions.

Safety Sign Maintenance

Replace any missing or damaged safety signs. Keep operator safety in mind at all times. Use mild soap and water to clean safety signs. Do not use solvent-based cleaners because they may damage the safety sign material.

Hazard Classification

Decals on this machine use symbols, color coding, and signal words to identify the following:



Safety alert symbol—used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury.


















Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



















Indicates a property damage message.

Symbol and Hazard Pictorials Definitions


| | | | | |
|---|---|---|--|---|
|  |  |  |  |  |
| Read the operator's manual | Read the service manual | Crush hazard | No smoking | Collision hazard |
|  |  |  |  |  |
| Tip-over hazard | Tip-over hazard | Tip-over hazard | Electrocution hazard | Tip-over hazard |
|  |  |  |  |  |
| Burn hazard | Explosion hazard | Fire hazard | Refer to ourigger decal | Electrocution hazard |
|  |  |  |  |  |
| Voltage rating for power to platform | Pressure rating for air line to platform | Crush hazard | Transport diagram | Tiedown |

Symbol and Hazard Pictorials Definitions

| | | | | |
|---|---|--|---|--|
|  |  |  |  |  |
| Maintain required clearance | Outrigger load | Lifting point | Release brakes | Grounded AC 3-wire only |
|  |  |  |  |  |
| Replace damaged wires and cords | Wheel load | Lanyard anchorage points | Manual force | Wind speed |
|  |  |  |  |  |
| Maximum capacity | Use common sense and planning to control the movement of the machine on or near inclines. | Indoor | Outdoor | Emergency lowering |
|  | | | | |
| Maximum capacity including occupant, tools, materials and options | | | | |


7

General Safety




* These decals are model, option or configuration specific.

General Safety



* These decals are model, option or configuration specific.

General Safety



* These decals are model, option or configuration specific.

Personal Safety

Personal Fall Protection

Personal fall protection equipment (PFPE) is not required when operating this machine. If PFPE is required by job site or employer rules, the following shall apply:

All PFPE must comply with applicable governmental regulations and must be inspected and used in accordance with the manufacturer's instructions.

Work Area Safety

⚠ Electrocuting Hazards

This machine, even with an optional fiberglass platform, is not electrically insulated and will not provide protection from contact with or proximity to electrical current.



Keep away from the machine if it contacts energized power lines or becomes electrically charged. Personnel on the ground or in the platform must not touch or operate the machine until energized power lines are shut off.



Obey all local and governmental regulations regarding required clearance from electrical power lines. At a minimum, the required clearance contained in the chart below must be followed.

| Voltage Phase to Phase | Minimum Safe Approach Distance | |
|---------------------------|-----------------------------------|---------|
| 0 to 300V | Avoid Contact | |
| 300V to 50KV | 10 ft | 3.05 m |
| 50KV to 200KV | 15 ft | 4.60 m |
| 200KV to 350KV | 20 ft | 6.10 m |
| 350KV to 500KV | 25 ft | 7.62 m |
| 500KV to 750KV | 35 ft | 10.67 m |
| 750KV to 1000KV | 45 ft | 13.72 m |

Allow for platform movement, electrical line sway or sag, and beware of strong or gusty winds.

Do not use the machine as a ground for welding.

Do not operate an AC powered machine or a DC battery charger unless using a 3-wire grounded extension cord connected to a grounded AC circuit. Do not alter or disable 3-wire grounded plugs.

⚠ Tip-over Hazards

Do not raise the platform unless the base is level, all four outriggers are properly installed and the leveling jacks firmly contact the floor.

Do not move the machine while the platform is raised.



Do not adjust or remove the outriggers while the platform is occupied or raised.



Do not place ladders or scaffolds in the platform or against any part of this machine.

Work Area Safety

Do not place or attach fixed or overhanging loads to any part of this machine.

Do not transport tools and materials unless they are evenly distributed and can be safely handled by the person in the platform.



Do not raise the platform unless the machine is level. Do not set the machine up on a surface where it cannot be leveled using only the leveling jacks.



Do not cause a horizontal force or side load to machine by raising or lowering a fixed or overhanging load.



Do not push off or pull toward any object outside of the platform.

**Maximum allowable
manual force:**
45 lbs/200 N

Do not operate the machine near drop-offs, holes, bumps, debris, unstable or slippery surfaces or other possible hazardous conditions.

Do not alter or disable machine components that in any way affect safety and stability.

Do not replace items critical to machine stability with items of different weight or specification.

Do not tie the platform to adjacent structures.

Do not place loads outside the platform perimeter.

Use only Genie approved replacement parts.

Do not push the Genie AWP from the platform side of the machine.

When moving the machine with a forklift or other transport vehicle, the platform should be fully lowered, the machine should be turned off and no personnel shall remain in the platform.

Do not use the machine on a moving or mobile surface or vehicle.

Do not alter or modify a mobile elevating work platform without prior written permission from the manufacturer. Mounting attachments for holding tools or other materials onto the platform, toeboards, or guard rail system can increase the weight in the platform and the surface area of the platform or the load.

Work Area Safety

Standard base models with outdoor outriggers:

Do not raise the platform when wind speeds may exceed 28 mph/12.5 m/s. If wind speeds exceed 28 mph/12.5 m/s when the platform is raised, lower the platform and do not continue to operate the machine.

Standard base models with indoor outriggers:

Indoor use only. Do not raise the platform when wind speeds may exceed 0 mph/0 m/s. If wind speeds exceed 0 mph/0 m/s when platform is raised, lower the platform and do not continue to operate the machine.

Narrow or RT base models: Indoor use only. Do not raise the platform when wind speeds may exceed 0 mph/0 m/s. If wind speeds exceed 0 mph/0 m/s when platform is raised, lower the platform and do not continue to operate the machine.

Maximum capacity

| | | |
|---------|---------|--------|
| AWP-20S | 350 lbs | 159 kg |
| AWP-25S | 350 lbs | 159 kg |
| AWP-30S | 350 lbs | 159 kg |
| AWP-36S | 350 lbs | 159 kg |
| AWP-40S | 300 lbs | 136 kg |

Maximum occupants

1 person

▲ Crushing Hazard

Keep hands and limbs out of mast.

Use common sense and planning when operating the machine with the controller from the ground. Maintain safe distances between the operator, the machine and fixed objects.



Do not operate the machine in strong or gusty winds. Do not increase the surface area of the platform or the load. Increasing the area exposed to the wind will decrease machine stability.



Occupants, equipment and materials shall not exceed the maximum platform capacity.

Work Area Safety

▲ Fall Hazards



The guard rail system provides fall protection. If occupant(s) of the platform are required to wear personal fall protection equipment (PFPE) due to job site or employer rules, PFPE and its use shall be in accordance with the PFPE manufacturer's instructions and applicable governmental requirements. Attach the lanyard to the anchor provided in the platform.

Do not sit, stand, or climb on the platform guard rails. Maintain a firm footing on the platform floor at all times.

Do not exit the platform while raised. If a power failure occurs, have ground personnel activate the manual lowering valve.

Keep the platform floor clear of debris.

Lower the platform entry mid-rail or gate before operating.

▲ Collision Hazards

Operators must comply with employer, job site, and governmental rules regarding use of personal protective equipment.



Use common sense and planning to control the movement of the machine on or near inclines.

Do not lower the platform unless the area below is clear of personnel and obstructions.



Check the work area for overhead obstructions or other possible hazards.



Be aware of crushing hazards when grasping the platform guard rail.

Stay clear of descending platform.

Work Area Safety

⚠ Bodily Injury Hazard

Do not operate the machine with a hydraulic oil or air leak. An air leak or hydraulic leak can penetrate and/or burn skin.

⚠ Explosion and Fire Hazards

Do not operate the machine or charge the battery in hazardous locations or locations where potentially flammable or explosive gases or particles may be present.

⚠ Damaged Machine Hazards

Do not use a damaged or malfunctioning machine.

Conduct a thorough pre-operation inspection of the machine and test all functions before each work shift. Immediately tag and remove from service a damaged or malfunctioning machine.

Be sure all maintenance has been performed as specified in this manual and the appropriate Genie service manual.

Be sure all decals are in place and legible.

Be sure the operator's, safety, and responsibilities manuals are complete, legible, and in the storage container located on the machine.


⚠ Battery Safety

Burn Hazards



Batteries contain acid. Always wear protective clothing and eye wear when working with batteries.

Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.



The battery pack must remain in the upright position.

Do not expose the batteries or the charger to water or rain during charging.

Work Area Safety

Explosion Hazards



Keep sparks, flames, and lighted tobacco away from batteries. Batteries emit explosive gas.

Charge the battery in a well ventilated area.



Do not contact the battery terminals or the cable clamps with tools that may cause sparks.



Do not disconnect charger DC output wires from the battery when the charger is on.

Component Damage Hazard

Do not use any battery charger greater than 24V to charge the batteries.

Electrocution/Burn Hazards



Connect the battery charger to a grounded, AC 3-wire electrical outlet only.

Inspect daily for damaged cords, cables and wires. Replace damaged items before operating.

Avoid electrical shock from contact with battery terminals. Remove all rings, watches and other jewelry.

Lifting Hazard

Use the appropriate number of people and proper lifting techniques when lifting batteries.


⚠ Improper Use Hazard

Do not leave the machine unattended unless the key is removed to secure from unauthorized use.

Lockout After Each Use

- 1 Select a safe parking location—firm level surface, clear of obstruction and traffic.
- 2 Lower the platform.
- 3 Turn the key switch to the off position and remove the key to secure from unauthorized use.
- 4 Charge the batteries.

Legend




- | | | |
|---|---|--|
| 1 Lifting eye | 12 Air supply for machine | 24 Manual lowering valve (under machine) |
| 2 AC models: Circuit breaker | 13 Airline lubricator | 25 Base outrigger socket |
| 3 Outrigger storage socket | 14 DC models: Battery pack with charger | 26 Outrigger with leveling jack |
| 4 Tilt-back frame retaining pin in strut socket | 15 Hydraulic power unit | 27 Outrigger lock pin |
| 5 Tilt-back strut | 16 Winching/tie-down point | 28 Platform |
| 6 Swivel lock | 17 Bubble level | 29 Platform entry mid-rail or gate |
| 7 Tilt-back frame | 18 Base | 30 AC models: Power supply for machine |
| 8 Loading stop bracket | 19 Sliding T-handle | DC models: Power to platform |
| 9 Loading pivot bar | 20 Lanyard anchorage point | 31 Ground controls |
| 10 Forklift pocket | 21 AC outlet | 32 Mast |
| 11 Airline lubricator adjustment knob | 22 Platform controls | |
| | 23 Operator's manual storage container | |


Controls

The ground control station can be used in the event of an emergency to rescue an incapacitated person in the platform.


Ground controls - AC and DC Models



Ground controls - Air Models



Platform controls



- 1 Red Emergency Stop button
- 2 Key switch
- 3 Outrigger interlock display lights (four)
- 4 Low battery indicator light for auxiliary lowering
- 5 DC models: Low battery indicator light
- 6 Power light
- 7 Auxiliary platform lowering button
- 8 Air pressure gauge
- 9 Control activate button
- 10 Up/Down switch

Inspections



Do Not Operate Unless:

- ☑ You learn and practice the principles of safe machine operation contained in this operator's manual.

1 Avoid hazardous situations.

2 Always perform a pre-operation inspection.

Know and understand the pre-operation inspection before going on to the next section.

3 Always perform function tests prior to use.

4 Inspect the workplace.


5 Only use the machine as it was intended.

Breather Cap - AC & DC Models

Component damage will occur if the machine is operated without a breather cap. Check to make sure the breather cap is in place in the hydraulic reservoir.

The first time this machine is set up for use, the pipe plug in the hydraulic reservoir must be removed and permanently replaced with a breather cap.

A breather cap is supplied and can be found in the manual storage box.



Pre-operation Inspection Fundamentals

It is the responsibility of the operator to perform a pre-operation inspection and routine maintenance.

The pre-operation inspection is a visual inspection performed by the operator prior to each work shift. The inspection is designed to discover if anything is apparently wrong with a machine before the operator performs the function tests.

The pre-operation inspection also serves to determine if routine maintenance procedures are required. Only routine maintenance items specified in this manual may be performed by the operator.

Refer to the list on the next page and check each of the items.

If damage or any unauthorized variation from factory delivered condition is discovered, the machine must be tagged and removed from service.

Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications. After repairs are completed, the operator must perform a pre-operation inspection again before going on to the function tests.

Scheduled maintenance inspections shall be performed by qualified service technicians, according to the manufacturer's specifications and the requirements listed in the responsibilities manual.

Inspections

Pre-operation Inspection

- ☐ Be sure that the operator's, safety and responsibilities manuals are complete, legible and in the storage container located in the platform.
- ☐ Be sure that all decals are legible and in place. See Decals section.
- ☐ Check for battery fluid leaks and proper fluid level. Add distilled water if needed. See Maintenance section.
- ☐ AC & DC models: Check for hydraulic oil leaks and proper oil level. Add oil if needed. See Maintenance section.
- ☐ RT Base models: Check for proper tire pressure. Add air if needed. See Maintenance section.
- ☐ Air models: Check the oil level of the airline lubricator. See Maintenance section.
- ☐ Air models: Check the oil lubricator canister drip rate. Adjust as needed. See Maintenance section.
- ☐ Air models: Check the air filter/regulator canister. Drain water as needed. See Maintenance section.

Check the following components or areas for damage, improperly installed, or missing parts and unauthorized modifications:

- ☐ Electrical components, wiring, and electrical cables
- ☐ AC & DC models: Hydraulic power unit, reservoir, hoses, fittings, and cylinder
- ☐ Air models: Air power unit, air lines, fittings and cylinder
- ☐ Platform entry mid-rail or gate

- ☐ Sequencing cables and pulleys
- ☐ Lifting chains and idler wheels
- ☐ Nuts, bolts and other fasteners
- ☐ Mast columns and counterweight
- ☐ Breather cap
- ☐ Outriggers, leveling jacks and footpads
- ☐ Adjustable glide pads
- ☐ Lanyard anchorage points
- ☐ Casters and brakes (if equipped)

Check entire machine for:

- ☐ Cracks in welds or structural components
- ☐ Dents or damage to machine
- ☐ Excessive rust, corrosion or oxidation
- ☐ Inspect and clean battery terminals and all battery cable connections.
- ☐ Verify that all structural and other critical components are present and all associated fasteners and pins are in place and properly tightened.

Inspections



Do Not Operate Unless:

- ☒ You learn and practice the principles of safe machine operation contained in this operator's manual.
- 1 Avoid hazardous situations.
- 2 Always perform a pre-operation inspection.
- 3 Always perform function tests prior to use.**

Know and understand the function tests before going on to the next section.

- 4 Inspect the workplace.
- 5 Only use the machine as it was intended.

Function Test Fundamentals

The function tests are designed to discover any malfunctions before the machine is put into service. The operator must follow the step-by-step instructions to test all machine functions.

A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service. Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications.

After repairs are completed, the operator must perform a pre-operation inspection and function tests again before putting the machine into service.


Inspections

Function Tests


Setup

- 1 Position the machine on a firm surface directly below the desired work area.
- 2 Connect to the appropriate power source.
DC models: Connect the battery pack.
AC models: Connect to a grounded 15A AC power supply. Use a 12 gauge/3.3mm² 3-wire grounded extension cord no longer than 50 ft/13 m.
Air models: Connect the air line.
- 3 Insert the key and turn to platform control.
- 4 Pull out the red Emergency Stop button to the on position at the ground controls.
- 5 Twist to release the red Emergency Stop button at the platform controls.
- ⦿ **Result:** AC & DC models: The power light should come on.
Air models: The air pressure gauge should read 80-110 psi/5.5 - 7.8 bar.


- 6 Select an outrigger and slide it into a base socket until the outrigger lock pin snaps into place. Adjust the outrigger to level the machine and raise the base casters slightly off the ground. Level the machine using only the outriggers.



- 7 Check the interlock display lights at the ground controls. Confirm that the corresponding light is on.



- 8 Repeat this procedure for each of the remaining outriggers.
- 9 Use the bubble level and adjust the leveling jacks until the machine base is level.



Inspections

Test Emergency Stop

- 10 Push in the ground red Emergency Stop button to the off position.
- 11 Push in the control activate button and rotate the up/down switch in the direction of intended travel.
- ⊙ Result: The up/down function should not operate.
- 12 Push in the platform red Emergency Stop button to the off position.
- 13 Pull out the red Emergency Stop button at the ground controls to the on position.
- 14 Push in the control activate button and rotate the up/down switch in the direction of intended travel.
- ⊙ Result: The up/down function should not operate.

Test Outrigger Interlock


- 15 Twist to release the red Emergency Stop button at the platform controls.
- ⊙ Result: The up/down functions should operate.
- 16 Unscrew one leveling jack until the corresponding interlock display light turns off.
- ⊙ Result: The up/down function should not operate.
- 17 Return the leveling jack to the previous setting and check the bubble level.
- 18 Repeat this procedure for each outrigger.

Test Auxiliary Platform Lowering - AC & DC Models

- 19 Raise the platform slightly.
- 20 Disconnect the power source from the machine.
- 21 Turn the key switch to ground control.
- 22 Push in the auxiliary platform lowering button at the ground controls.
- ⊙ Result: The platform should lower.
- 23 Connect the power source to the machine.
- 24 Turn the key switch to platform control.
- 25 Raise the platform slightly.
- 26 Disconnect the power source from the machine.
- 27 Push in the control activate button and rotate the up/down switch in the down direction.
- ⊙ Result: The platform should lower.
- 28 Connect the power source to the machine.

Test Manual Lowering

- 29 Raise the platform slightly.
- 30 Activate the manual lowering valve located at the bottom of the hydraulic cylinder.



- ⊙ Result: The platform should lower.

Inspections



Do Not Operate Unless:

- ✓ You learn and practice the principles of safe machine operation contained in this operator's manual.

- 1 Avoid hazardous situations.
- 2 Always perform a pre-operation inspection.
- 3 Always perform function tests prior to use.

4 Inspect the workplace.

Know and understand the workplace inspection before going on to the next section.

- 5 Only use the machine as it was intended.

Workplace Inspection Checklist

Be aware of and avoid the following hazardous situations:

- ☐ drop-offs or holes
- ☐ bumps, floor obstructions, or debris
- ☐ sloped surfaces
- ☐ unstable or slippery surfaces
- ☐ overhead obstructions and high voltage conductors
- ☐ hazardous locations
- ☐ inadequate surface support to withstand all load forces imposed by the machine
- ☐ wind and weather conditions
- ☐ the presence of unauthorized personnel
- ☐ other possible unsafe conditions

Workplace Inspection Fundamentals

The workplace inspection helps the operator determine if the workplace is suitable for safe machine operation. It should be performed by the operator prior to moving the machine to the workplace.

It is the operator's responsibility to read and remember the workplace hazards, then watch for and avoid them while moving, setting up, and operating the machine.

Inspections

Inspection for Decals with Words

Determine whether the decals on your machine have words or symbols. Use the appropriate inspection to verify that all decals are legible and in place.


| Part No. | Decal Description | Qty |
|----------|--|-----|
| 27838 | Warning - Tilt-back Hazards/Instructions | 1 |
| 27857 | Caution - Pipe Plug | 1 |
| 27863 | Warning - Collision Hazard | 1 |
| 27864 | Notice - Lower Stop Bracket Before Installing Battery Pack. | 1 |
| 27872 | Danger - Tip-over Hazard, Outriggers | 1 |
| 27873 | Notice - Maintain Firm Grasp | 1 |
| 27874 | Label - Insert Retaining Pin | 1 |
| 28174 | Label - Power to Platform, 230V* | 2 |
| 28235 | Label - Power to Platform, 115V* | 2 |
| 28372 | Label - Disconnect Battery Pack Plug | 1 |
| 31070 | Danger - Tip-over Hazard, Moving | 1 |
| 31071 | Warning - Failure to Read | 1 |
| 31245 | Warning - Collision Hazard | 1 |
| 37142 | Notice - Operating Instructions | 1 |
| 38122 | Label - Manual Storage Container | 1 |
| 38142 | Label - Circuit Breaker, AC models | 1 |
| 38149 | Label - Patents | 1 |
| 41266 | Label - Interlock Display, Air Models, Standard Base* | 1 |
| 41268 | Label - Interlock Display, Air Models, Narrow Base and Rough Terrain Base* | 1 |
| 52475 | Label - Transport Tie Down | 3 |
| 72086 | Label - Lifting Point | 1 |
| 82366 | Label - Chevron Rando | 1 |
| 82780 | Label - Interlock Display* | 1 |
| 82781 | Label - Interlock Display* | 1 |
| 82802 | Label - Function Enable | 1 |
| 82907 | Danger - Battery Charger Safety | 1 |
| 82915 | Label - Manual Lowering Valve | 1 |
| 82986 | Danger - Electrocution Hazard | 1 |
| 97522 | Label - Wheel Load | 4 |
| 97523 | Label - Outrigger Load | 4 |
| 97815 | Label - Lower Mid-rail | 1 |
| 124221 | Label - Input Power, 110VAC* | 1 |

| Part No. | Decal Description | Qty |
|----------|---|-----|
| 133490 | Label - Instructions, Hand Controls* | 1 |
| 216056 | Warning - Unauthorized Use Hazard | 1 |
| 1272242 | Label - Machine Registration | 1 |
| 1280819 | Label - Warning, Prop 65 | 1 |
| 1281175 | Label - Lanyard Anchorage Point, Fall Restrained | 1 |
| 1294398 | Label - ANSI/CSA Compliant | 1 |
| 1294685 | Instructions - Annual Inspection | 1 |
| 1298492 | Label - Input Power, 100VAC* | 1 |
| 1298705 | Notice - Max. Capacity/Side Force, 350 lbs, AWP* | 1 |
| 1298706 | Danger - 20 in/50.8 cm Outrigger Reach, Indoor* | 4 |
| 1298708 | Danger - 26 in/66 cm Outrigger Reach, Indoor* | 4 |
| 1298709 | Notice - Max. Capacity/Side Force, 300 lbs, AWP* | 1 |
| 1298710 | Danger - 31 in/78.4 cm Outrigger Reach, Indoor* | 4 |
| 1298712 | Danger - 36 in/91.4 cm Outrigger Reach, Indoor* | 4 |
| 1298713 | Label - Transport Diagram | 1 |
| 1298945 | Decal - Warning, Platform Locate Light, Word* | 1 |
| 1298997 | Danger - General Safety | 1 |
| 1301031 | Danger - 40 in/101.6 cm Outrigger Reach, Indoor* | 4 |
| 1301032 | Danger - 46 in/116.8 cm Outrigger Reach, Outdoor* | 4 |
| 1301033 | Danger - 60 in/152.4 cm Outrigger Reach, Outdoor* | 4 |
| 1301034 | Danger - 75 in/190.5 cm Outrigger Reach, Outdoor* | 4 |
| 1301035 | Danger - 85 in/215.9 cm Outrigger Reach, Outdoor* | 4 |
| 1305602 | Label - Input Power, 220VAC, 12A* | 1 |

 Shading indicates decal is hidden from view, i.e. under covers

* These decals are model, option or configuration specific.

Inspections




Inspections

Inspection for Decals with Symbols

Determine whether the decals on your machine have words or symbols. Use the appropriate inspection to verify that all decals are legible and in place.


| Part No. | Decal Description | Qty |
|----------|---|-----|
| 28174 | Label – Power to Platform, 230V* | 2 |
| 28235 | Label – Power to Platform, 115V* | 2 |
| 41266 | Label - Interlock Display, Air Models, Standard Base* | 1 |
| 41288 | Label - Interlock Display, Air Models, NB/RT Base* | 1 |
| 52475 | Label – Transport Tie Down | 3 |
| 72086 | Label – Lifting Point | 1 |
| 82481 | Label – Battery/Charger Safety | 1 |
| 82780 | Label - Interlock Display AC, DC, standard models* | 1 |
| 82781 | Label - Interlock Display, AC, DC, NB/RT models* | 1 |
| 82802 | Label - Function Enable | 1 |
| 82915 | Label - Manual Lowering Valve | 1 |
| 82973 | Warning - Insert Pin | 1 |
| 82974 | Warning - Collision Hazard | 1 |
| 82976 | Danger - Wind Speed, 20 in/51 cm Outrigger* | 4 |
| 82977 | Danger - Wind Speed, 26 in/66 cm Outrigger* | 4 |
| 82978 | Danger - Wind Speed, 30.5 in/77 cm Outrigger* | 4 |
| 82979 | Danger - Wind Speed, 36 in/91 cm Outrigger* | 4 |
| 82980 | Danger - Wind Speed, 40 in/102 cm Outrigger* | 4 |
| 82984 | Danger - Wind Speed, 85 in/216 cm Outrigger* | 4 |
| 82987 | Danger - Electrocution Hazard | 1 |
| 82988 | Label - Read the Manual, Tilt-back Frame | 1 |
| 97522 | Label - Wheel Load | 4 |
| 97523 | Label - Outrigger Load | 4 |
| 97815 | Label – Lower Mid-rail | 2 |
| 114373 | Danger – Electrocution Hazard | 1 |

| Part No. | Decal Description | Qty |
|----------|--|-----|
| 124221 | Label – Input Power, 110VAC* | 1 |
| 1255889 | Label – Read the Manual | 2 |
| 1257853 | Danger - Wind Speed, 75 in/191 cm Outrigger* | 4 |
| 1257854 | Danger - Wind Speed, 60 in/152 cm Outrigger* | 4 |
| 1260610 | Danger - Wind Speed, 46 in/117 cm Outrigger* | 4 |
| 1272242 | Label – Machine Registration | 1 |
| 1281175 | Label – Lanyard Anchorage Point, Fall Restrained | 1 |
| 1294398 | Label – ANSI/CSA Compliant | 1 |
| 1298492 | Label – Input Power, 100VAC* | 1 |
| 1298707 | Notice – Max. Capacity 350 lbs, AWP* | 1 |
| 1298711 | Notice – Max. Capacity 300 lbs, AWP* | 1 |
| 1298713 | Label - Transport Diagram | 1 |
| 1299616 | Decal - Warning, Platform Locate Light, Symbol | 1 |
| 1299624 | Decal - Hazard, Load Shift | 1 |
| 1305602 | Label – Input Power, 220VAC, 12A* | 1 |

 Shading indicates decal is hidden from view, i.e. under covers

* These decals are model, option or configuration specific.

Inspections



Operating Instructions



Do Not Operate Unless:

- ☒ You learn and practice the principles of safe machine operation contained in this operator's manual.
 - 1 Avoid hazardous situations.
 - 2 Always perform a pre-operation inspection.
 - 3 Always perform function tests prior to use.
 - 4 Inspect the workplace.
 - 5 **Only use the machine as it was intended.**

Fundamentals

The Operating Instructions section provides instructions for each aspect of machine operation. It is the operator's responsibility to follow all the safety rules and instructions in the operator's, safety and responsibilities manuals.



Using the machine for anything other than lifting personnel, along with their tools and materials, to an aerial work site is unsafe and dangerous.

If more than one operator is expected to use a machine at different times in the same work shift, each operator is expected to follow all safety rules and instructions in the operator's manual. That means every new operator should perform a preoperation inspection, function tests and a work place inspection before using the machine.


Operating Instructions

Setup

- 1 Position the machine on a firm surface directly below the desired work area.
- 2 Connect to the appropriate power source.
DC models: Connect the battery pack.
AC models: Connect to a grounded 15A AC power supply. Use a 12 gauge/3.3mm² 3-wire grounded extension cord no longer than 50 ft/13 m.
Air models: Connect the air line.
- 3 Insert the key and turn to platform control.
- 4 Pull out the red Emergency Stop button at the ground controls and twist to release the red Emergency Stop at the platform controls. Be sure the power light is on or the air pressure gauge reads 80-110 psi/5.5 - 7.8 bar.
- 5 Install the outriggers and adjust to level the machine and raise the base casters slightly off the ground.



- 6 Be sure all four interlock display lights at the ground controls are on and all four outriggers are in firm contact with the ground.
- 7 Use the bubble level to make sure the machine is level.



Note: If adjustment is necessary, check the bubble level and interlock display again to make sure the machine is level and all four interlock display lights are on.

Emergency Stop


- 1 Push in the red Emergency Stop button at the platform controls or at the ground controls to stop the up function.

Platform Raise and Lower

- 1 Pull out the red Emergency Stop button to the on position at the ground controls. Twist to release the red Emergency Stop button at the platform controls.
- 2 Push in the control activate button and rotate the up/down switch in the direction of intended travel.

Manual Lowering

- 1 Activate the manual lowering valve located at the bottom of the hydraulic cylinder.



Operating Instructions

Auxiliary Platform Lowering - AC & DC Models

- 1 Turn the key switch to ground control. Pull out the red Emergency Stop button to the on position.
- 2 Activate the auxiliary platform lowering button at the ground controls.

After Each Use

- 1 Select a safe storage location—firm, level surface, weather protected, clear of obstruction and traffic.
- 2 Apply the caster brakes (if equipped) or chock the wheels to prevent the machine from rolling.
- 3 Remove the key to secure from unauthorized use.
- 4 DC models: Charge the batteries.

Maintenance



Observe and Obey:

- ☑ Only routine maintenance items specified in this manual shall be performed by the operator.
- ☑ Scheduled maintenance inspections shall be completed by qualified service technicians, according to the manufacturer's specifications and the requirements specified in the responsibilities manual.
- ☑ Dispose of material in accordance with governmental regulations.

Maintenance Symbols Legend

NOTICE

The following symbols have been used in this manual to help communicate the intent of the instructions. When one or more of the symbols appear at the beginning of a maintenance procedure, it conveys the meaning below.



Indicates that tools will be required to perform this procedure.



Indicates that new parts will be required to perform this procedure.

Check the Batteries - DC Models



Proper battery condition is essential to good machine performance and operational safety. Improper fluid levels or damaged cables and connections can result in component damage and hazardous conditions.

⚠ WARNING

Electrocution hazard. Contact with hot or live circuits may result in death or serious injury. Remove all rings, watches and other jewelry.

⚠ WARNING

Bodily injury hazard. Batteries contain acid. Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

NOTICE

Perform this test after fully charging the battery.

- 1 Put on protective clothing and eye wear.
- 2 Remove the battery vent caps.
- 3 Check the battery acid level. If needed, replenish with distilled water to the bottom of the battery fill tube. Do not overfill.
- 4 Install the battery vent caps.

Maintenance

Check the Hydraulic Oil Level



Maintaining the hydraulic oil at the proper level is essential to machine operation. Improper hydraulic oil levels can damage hydraulic components. Daily checks allow the inspector to identify changes in oil level that might indicate the presence of hydraulic system problems.

- 1 Be sure the platform is fully lowered.
 - 2 Check the sight gauge on the side of the hydraulic reservoir.
- ⊙ Result: The hydraulic oil level should be visible in the middle of the sight gauge. Do not overfill.

Hydraulic oil specifications

| | |
|--------------------|-----------------------------|
| Hydraulic oil type | Chevron Rando HD equivalent |
|--------------------|-----------------------------|

Check the Tire Pressure - RT Base Models



It is essential to maintain proper pressure in all airfilled tires. Improperly inflated tires can affect machine handling.

- 1 Check each tire with an air pressure gauge. Add air as needed.
- The proper air pressure is stamped on the tire.

Check the Air Line Lubricator Oil Level - Air Models



Maintaining the proper oil level in the lubricator canister is essential to safe operation and good machine performance. Failure to keep the lubricator canister at the proper oil level could result in unsafe operating conditions and possible component damage.

- 1 Be sure the platform is fully lowered.
 - 2 Inspect the lubricator canister for the proper oil level.
- ⊙ Result: The oil level must be within 1/2 inch/12.7 mm from the top of the lubricator canister.
- 3 To add oil, remove the oil lubricator canister from the lubricator base and fill with oil. Install the canister back onto the lubricator base.

Oil Specifications

| | |
|----------|---------------------------|
| Oil type | 10W automotive engine oil |
|----------|---------------------------|

Maintenance

Check the Oil Lubricator Canister Drip Rate - Air Models



Maintaining the proper oil drip rate into the lubricator canister is essential to safe operation and good machine performance. Failure to maintain the proper drip rate could result in machine component damage.

- 1 While raising the platform, visually inspect the oil lubricator sight gauge.
- ⦿ Result: There should be a maximum of 1 to 2 drops of oil visible in the sight gauge.
- 2 To adjust the drip rate, turn the oil flow control valve clockwise to decrease the flow or counterclockwise to increase the flow.
- 3 Repeat this procedure until the proper oil drip rate is achieved.

Check the Air Filter/Regulator Canister - Air Models



It is essential to drain the air filter/regulator canister of water to ensure good air motor performance and service life. A water-filled canister could cause the air motor to perform poorly and continued use could cause component damage.

- 1 Check the air filter/regulator canister for any water accumulation.
- 2 If water is visible, loosen the drain plug at the bottom of the canister and allow the water to drain out.
- 3 Tighten the drain plug.

Scheduled Maintenance

Maintenance performed quarterly, annually and every two years must be completed by a person trained and qualified to perform maintenance on this machine according to the procedures found in the service manual for this machine.

Machines that have been out of service for more than three months must receive the quarterly inspection before they are put back into service.

Battery Charging Instructions



Battery and Charger Instructions

Observe and Obey:

- ☒ Do not use an external charger or booster battery.
- ☒ Charge the battery in a well-ventilated area.
- ☒ Use proper AC input voltage for charging as indicated on the charger.
- ☒ Use only a Genie authorized battery and charger.

To Charge Battery

- 1 Open the battery pack lid to access the battery.
- 2 Remove the battery vent caps and check the battery acid level. If necessary, add only enough distilled water to cover the plates. Do not overfill prior to the charge cycle.
- 3 Replace the battery vent caps.
- 4 Be sure that the DC output cord is properly connected to the battery. Black to negative, red to positive.
- 5 Connect the battery charger to a grounded AC circuit.

- 6 The charger will turn off automatically when the battery is fully charged.
- 7 Check the battery acid level when the charge cycle is complete. Replenish with distilled water to the bottom of the fill tube. Do not overfill.

Dry Battery Filling and Charging Instructions

- 1 Remove the battery vent caps and permanently remove the plastic seal from the battery vent openings.
- 2 Fill each cell with battery acid (electrolyte) until the level is sufficient to cover the plates.

Do not fill to maximum level until the battery charge cycle is complete. Overfilling can cause the battery acid to overflow during charging. Neutralize battery acid spills with baking soda and water.

- 3 Install the battery vent caps.
- 4 Charge the battery.
- 5 Check the battery acid level when the charging cycle is complete. Replenish with distilled water to the bottom of the fill tube. Do not overfill.



Transport Instructions

Observe and Obey:

- ☑ Be sure the transport vehicle capacity and loading surfaces are sufficient to support the machine weight. See the serial label for the machine weight. Some pick-up truck tailgates are not strong enough to support the weight of the machine and may require reinforcement.
- ☑ Do not load the machine onto a transport vehicle unless it is parked on a level surface.
- ☑ The transport vehicle must be secured to prevent rolling while the machine is being loaded.
- ☑ The machine must be securely fastened to the transport vehicle. Use chains or straps of ample load capacity.
- ☑ Be sure to lock both swivel casters on the tilt-back frame.
- ☑ Do not transport with the machine resting on the tilt-back frame.

Lifting Instructions

The number of people required to load and unload a machine is dependent on a number of factors, including but not limited to:


- the physical condition, strength and disabilities or prior injuries of the people involved
- the vertical and horizontal distances the machine has to be moved
- the number of times the machine will be loaded or unloaded
- the stance, posture and grip used by the people involved
- the lifting techniques used
- the site conditions and weather in which the activity is being performed (i.e., slippery, icy, raining)

The appropriate number of people and proper lifting techniques must be used to prevent physical injury.

Transport Instructions


Loading for Transport

- 1 Fully lower the platform.
- 2 Push in the red Emergency Stop buttons, turn the key switch to the off position and remove the key.
- 3 Remove the outriggers from the base and place them in the storage sockets.
- 4 DC models: Disconnect the battery cable and remove the battery pack.
- 5 Inspect the entire machine for loose or unsecured items.
- 6 Slide the stop bracket to the top lock position.



All models without tilt-back frame

- a stop bracket
- b loading pivot




All models with tilt-back frame

- a stop bracket
- b loading pivot

- 7 Hook the loading pivot to the stop bracket.

- 8 Position the machine flush against the loading surface. Lower and lock the stop bracket to the lowest lock pin position above the loading surface.




- 9 All models with tilt-back frame:

Be sure both stop bracket lock pins are fully locked.


Be sure both tilt-back frame swivel casters are locked.

- 10 Slide out the T-handle until the lock pin snaps into place.

- 11 Lift the T-handle to tilt the machine onto the loading surface. Use the appropriate number of people and proper lifting techniques.



- 12 Carefully push the machine into the transport position.



- 13 Return the sliding T-handle to the stowed position.

- 14 Secure the machine base and mast to the transport vehicle. See Securing the Machine on the next page.

- 15 Reverse this procedure to unload the machine.

Transport Instructions

Winching the Machine onto a Flatbed Truck

- 1 Fully lower the platform.
- 2 Push in the red Emergency Stop buttons, turn the key switch to the off position and remove the key.
- 3 Remove the outriggers from the base and place them in the storage sockets.
- 4 Inspect the entire machine for loose or unsecured items.
- 5 Connect the cable to the winching point located at the rear of the base.
- 6 Carefully winch the machine onto the truck.
- 7 Secure the machine base and mast to the transport vehicle. See Securing the Machine.


Lifting the Machine with a Forklift

Inspect the entire machine and remove any loose or unsecured items.

Fully lower the platform. The platform must remain lowered during all loading and transport procedures.

The battery pack must be removed before lifting the machine with a forklift. Disconnect the battery plug before removing the battery pack.

Use the forklift pockets located in the rear of the chassis. Forklift pockets are only available on AWP's with a standard base. AWP's with a narrow base or a rough terrain base cannot be lifted with a forklift.



Position the forklift forks in position with the forklift pockets.

Drive forward to the full extent of the forks.

Raise the machine 6 in/15 cm and then tilt the forks back slightly to keep the machine secure.

Be sure the machine is level when lowering the forks.

Transport Instructions


Loading the Machine With a Crane

Use the lifting eye mounted on the rear mast column.

The battery pack must be removed before lifting the machine with a crane. Disconnect the battery plug before removing the battery pack.

Inspect the entire machine and remove any loose or unsecured items.

Always place the lifting hook through the lifting eye so that it points away from the machine.





Securing the Machine

Use chains or straps of ample load capacity.

Use a minimum of 2 chains or straps.

Adjust the rigging to prevent damage to the chains.



Tilt-back Operation Instructions



Tilt-back Operation Instructions

Observe and Obey:

- ☑ The retaining pin must be inserted to prevent the spring-loaded tilt-back frame from dropping.
- ☑ Do not tilt the machine back unless the area is clear of personnel and obstructions.
- ☑ Do not stand behind or under the tilt-back frame when raising or lowering it.

Tilt-back Instructions


The number of people required to lower and raise a machine using the tilt-back assembly, is dependent on a number of factors, including but not limited to:

- the physical condition, strength and disabilities or prior injuries of the people involved
- the number of times the machine will be lowered and raised using the tilt-back assembly
- the stance, posture and grip used by the people involved
- the lifting techniques used
- the site conditions and weather in which the activity is being performed (i.e., slippery, icy, raining)

The appropriate number of people and proper lifting techniques must be used to prevent physical injury.

Tilt-back Frame

The Genie AWP Super Series has a tilt-back frame which allows the machine to roll through a standard doorway. The tilt-back frame is standard equipment on standard base AWP-36S and 40S models, and optional on standard base AWP-15S, 20S, 25S and 30S models. The tilt-back frame is not available on narrow base machines or rough terrain base machines.




Tilt-back Operation Instructions



Lowering the Tilt-back Assembly

- 1 Be sure the area behind the machine and under the tilt-back frame is clear of personnel and obstructions.
- 2 Fully lower the platform.
- 3 Remove the outriggers from the base and place them in the storage sockets.

The tilt-back frame is spring loaded and will immediately fall outward when the retaining pin is removed. Maintain a firm grasp on the tiltback frame and remove the retaining pin.




- 4 Lower the tiltback frame and guide the tilt-back strut into the strut socket.
- 5 Insert the retaining pin into the strut socket.




Tilting Back the Machine

- 1 Slide out the T-handle until the lock pin snaps into place.



- 2 Lift the machine with the T-handle to mid-tilt position casters on the tilt-back frame are in contact with the floor, and the machine is supported by the extended tilt-back strut. Use the appropriate number of people and proper lifting techniques.




- 3 Continue lifting until the telescoping tilt-back strut is completely compressed.
- 4 Return the sliding T-handle to the stowed position.

Tilt-back Operation Instructions



Returning the Machine to Standing Position

- 1 Be sure the area below the machine base and T-handle is clear of personnel and obstructions.
- 2 Slide out the T-handle until the lock pin snaps into place.
- 3 Carefully pull down the T-handle until the machine rests at mid-tilt position.
- 4 Lower the machine with the T-handle until the base casters are in contact with the ground. Use the appropriate number of people and proper lifting techniques.
- 5 Return the sliding T-handle to the stowed position.




Stowing the Tilt-back Assembly

- 1 Remove the retaining pin.



- 2 Firmly grasp the tilt-back frame and remove the tilt-back strut from the strut socket.
- 3 Lift the tilt-back frame, hold in an upright position against the spring and secure with the retaining pin.



Specifications

Machine Specifications

| | |
|--------------------------|-------------------|
| Height, working maximum | |
| AWP-20S | 26 ft 1 in/8.0 m |
| AWP-25S | 30 ft 9 in/9.4 m |
| AWP-30S | 35 ft 6 in/10.8 m |
| AWP-36S | 42 ft 5 in/12.9 m |
| AWP-40S | 46 ft 3 in/14.1 m |
| Height, platform maximum | |
| AWP-20S | 20 ft 1 in/6.1 m |
| AWP-25S | 24 ft 9 in/7.5 m |
| AWP-30S | 29 ft 6 in/9.0 m |
| AWP-36S | 36 ft 6 in/11.1 m |
| AWP-40S | 40 ft 3 in/12.3 m |
| Height, stowed | |
| AWP-20S, 25S, 30S | 78 in/2.0 m |
| AWP-36S, 40S | 109.5 in/2.8 m |
| Width, All models | |
| Standard base | 29 in/73.6 cm |
| Narrow base | 22 in/55.8 cm |
| Rough terrain base | 29.5 in/75 cm |
| Length, AWP-20S | |
| Standard base | 49 in/124.5 cm |
| Narrow base | 49.8 in/126.5 cm |
| Rough terrain base | 63 in/160 cm |
| Length, AWP-25S | |
| Standard base | 51.5 in/130.8 cm |
| Narrow base | 52.3 in/132.8 cm |
| Rough terrain base | 63 in/160 cm |
| Length, AWP-30S | |
| Standard base | 53 in/134.6 cm |
| Narrow base | 54.8 in/139.2 cm |
| Rough terrain base | 63 in/160 cm |
| Length, AWP-36S | |
| Standard base | 55 in/139.7 cm |
| Length, AWP-40S | |
| Standard base | 56 in/142.2 cm |
| Weight | See Serial Label |
| Wheel load, maximum | 509 lbs/231 kg |
| Outrigger load, maximum | 400 lb/181 kg |

Lift capacity

| | |
|------------------------|----------------|
| AWP-20S, 25S, 30S, 36S | 350 lbs/159 kg |
| AWP-40S | 300 lbs/136 kg |

Power source

| | |
|-----------|---------------------------------------|
| DC Model | 12V |
| AC Model | 110V or 220V |
| Air Model | 100 psi/6.9 bar @ 80 cfm/37760 cc/sec |

| | |
|-------------------------------|---------------------------------|
| Ambient operating temperature | -20°F to 135°F -29°C to 57°C |
|-------------------------------|---------------------------------|

Platform dimensions (length x width)

| | |
|---|--|
| Standard platform gated or sliding mid-rail | 27 x 26 x 44.75 in 69 cm x 66 cm x 1.1 m |
| Gated ultra-narrow platform | 22 x 18 x 44.75 in 56 cm x 46 cm x 1.1 m |
| Gated narrow platform | 26 x 20 x 44.75 in 66 cm x 51 cm x 1.1 m |
| Standard fiberglass platform | 29 x 26.5 x 43.5 in 74 cm x 67 cm x 1.1 m |
| Narrow fiberglass platform | 26 x 22 x 43.5 in 66 cm x 56 cm x 1.1 m |

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice or obligation.

Specifications

| Outrigger Specifications - Standard base | AWP-20S | AWP-25S | AWP-30S |
|---|---------------------------------|----------------------------------|-----------------------------------|
| Outrigger footprint (l x w) Indoor | 60.75 x 52.75 in 1.5 x 1.3 m | 69.25 x 61.25 in 1.8 x 1.6 m | 75.50 x 67.50 in 1.9 x 1.7 m |
| Outrigger footprint (l x w) Outdoor | 97 x 89 in 2.46 x 2.26 m | 117.25 x 109.5 in 3.0 x 2.8 m | 117.25 x 109.50 in 3.0 x 2.8 m |
| Corner access/wall access* Indoor | 14.50/5.50 in 36.9/7.4 cm | 19.25/7.25 in 48.6/18.2 cm | 22.25/8 in 56.5/20.3 cm |
| Corner access/wall access* Outdoor | 30/16.75 in 76/42.4 cm | 32.50/17 in 82.5/43.4 cm | 50.75/28.75 in 1.3 m/73 cm |

* Corner of platform top rail to corner of wall with ability to rotate leveling jack.

| Outrigger Specifications - Standard base | AWP-36S | AWP-40S |
|---|---------------------------------|--------------------------------|
| Outrigger footprint (l x w) Indoor | 83.25 x 75.25 in 2.1 x 1.9 m | 89 x 81 in 2.3 x 2.0 m |
| Outrigger footprint (l x w) Outdoor | 139 x 131 in 3.5 x 3.3 m | 153 x 145 in 3.9 x 3.7 m |
| Corner access/wall access* Indoor | 28.50/14.25 in 72.7/36.2 cm | 31.25/14.50 in 79.4/37.1 cm |
| Corner access/wall access* Outdoor | 52/31.25 in 1.3 m/79.3 cm | 50.75/28.75 in 1.3 m/73 cm |

* Corner of platform top rail to corner of wall with ability to rotate leveling jack.

| Outrigger Specifications - Narrow base / Rough terrain base | AWP-20S | AWP-25S | AWP-30S |
|--|------------------------------|------------------------------|---------------------------|
| Outrigger footprint (l x w) Indoor Use Only | 71.25 x 58 in 1.8 x 1.5 m | 71.25 x 58 in 1.8 x 1.5 m | 83 x 74 in 2.1 x 1.8 m |
| Narrow Base or Rough Terrain base machines are Indoor Use Only, even with longer outriggers. | | | |
| Corner access/wall access* Indoor | 21/12.25 in 53.3/31.1 cm | 19.50/9.75 in 49.5/24.7cm | 22/9 in 55.8/22.8 cm |

* Corner of platform top rail to corner of wall with ability to rotate leveling jack.

California Proposition 65



WARNING

Operating, servicing and maintaining this equipment can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. These chemicals can be emitted from or contained in other various parts and systems, fluids and some component wear by-products. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your equipment and vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your equipment or vehicle and after operation. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.