

FlashRunner 2.0 Series

**High-Performance,
Standalone In-System
Programmers**

Programmer's Manual

Revision 2.22 — May 2022



Copyright © 2022 SMH Technologies

We want your feedback!

SMH Technologies is always on the lookout for new ways to improve its Products and Services. For this reason, feedback, comments, suggestions or criticisms, however small, are always welcome.

SMH Technologies S.r.l.

via Giovanni Agnelli, 1
33083 Villotta di Chions (PN) Italy
E-mail (general information): info@smh-tech.com
E-mail (technical support): support@smh-tech.com
Web: <http://www.smh-tech.com>

Important

SMH Technologies reserves the right to make improvements to FlashRunner, its documentation and software routines, without notice. Information in this manual is intended to be accurate and reliable. However, SMH Technologies assumes no responsibility for its use; nor for any infringements of rights of third parties which may result from its use.

SMH TECHNOLOGIES WILL NOT BE LIABLE FOR DAMAGES RESULTING FROM LOSS OF DATA, PROFITS, USE OF PRODUCTS, OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF.

Trademarks

SMH Technologies is the licensee of the SofTec Microsystems trademark.
All other product or service names are the property of their respective owners.

Contents

1	BEFORE STARTING.....	9
1.1	IMPORTANT NOTICE TO USERS	9
1.2	GETTING TECHNICAL SUPPORT	10
2	SYSTEM SETUP/UPGRADE	11
2.1	SOFTWARE SETUP	11
2.2	WHAT YOU NEED TO START	12
2.3	CONNECTION SETUP	13
2.4	FIRMWARE UPDATE	18
3	FLASHRUNNER WORKBENCH	20
3.1	OVERVIEW	20
3.2	OPENING WINDOW	21
3.3	TOP TOOLBAR	23
3.4	LEFT TOOLBAR.....	24
3.5	PROJECT SETUP	25
3.6	PRODUCTION CONTROL	26
3.7	PROJECT EDITOR.....	29
3.8	WIZARD.....	30
3.8.1	<i>FlashRunner selection page.....</i>	<i>31</i>
3.8.2	<i>Main page</i>	<i>32</i>
3.8.3	<i>Device selection page.....</i>	<i>33</i>
3.8.4	<i>FRB Management page.....</i>	<i>34</i>
3.8.5	<i>Communication settings page.....</i>	<i>35</i>
3.8.6	<i>Powering settings page.....</i>	<i>36</i>
3.8.7	<i>Additional parameters page.....</i>	<i>37</i>
3.8.8	<i>Command settings page.....</i>	<i>37</i>
3.8.9	<i>Additional commands page.....</i>	<i>38</i>
3.8.10	<i>Add the project to a channel</i>	<i>38</i>
3.9	ENCRYPT FRB (FRS)	39
3.10	ADVANCED FILE MANAGER	41
3.11	TERMINAL	43
3.12	LOG.....	44
3.13	MEMORY MAP TOOL.....	46
3.14	PIN MAP TOOL.....	47
3.15	ADVANCED FRB MANAGER	48

3.15.1	Add data to FRB: import from source file.....	50
3.15.2	Add data to FRB: Fill Data / Variable Data	52
3.15.3	Edit FRB block.....	53
3.15.4	Other Options.....	56
4	FLASHRUNNER COMMANDS.....	57
4.1	OVERVIEW	57
4.1.1	Host Mode	57
4.1.2	Standalone Mode.....	58
4.2	COMMAND SYNTAX.....	58
4.2.1	Sending a Command.....	58
4.2.2	Receiving the Answer.....	61
4.2.3	Numeric Parameters.....	62
4.3	COMMAND SUMMARY	63
4.4	COMMAND REFERENCE	68
4.4.1	CRC.....	69
4.4.2	CLRERR.....	70
4.4.3	CLRLOG	71
4.4.4	DELAY.....	72
4.4.5	DYNMEMCLEAR	73
4.4.6	DYNMEMCLEARHEADER	74
4.4.7	DYNMEMSET.....	75
4.4.8	DYNMEMSET2.....	76
4.4.9	DYNMEMSETHEADER	77
4.4.10	DYNMEMSETW	79
4.4.11	DYNMEMSETW2	80
4.4.12	ECHO	81
4.4.13	FRBREADCRC.....	82
4.4.14	FSCRC	83
4.4.15	FSEXIST.....	84
4.4.16	FSGETCONTROL.....	85
4.4.17	FSLS	86
4.4.18	FSLS2	87
4.4.19	FSRM	88
4.4.20	FSSETCONTROL	89
4.4.21	GENCRYPTOKEY.....	90
4.4.22	GETAVGVPROG.....	91
4.4.23	GETCOUNTER	92
4.4.24	GETDATE	93

4.4.25	GETENGSTATUS	94
4.4.26	GETFREEMEM	95
4.4.27	GETIP	96
4.4.28	GETLOGLEVEL	97
4.4.29	GETPROGRESSBAR	98
4.4.30	GETPUBKEY	99
4.4.31	GETVPROG	101
4.4.32	HELP	102
4.4.33	ISMEMENOUGH	103
4.4.34	ISPANELMODE	104
4.4.35	LICERASE	105
4.4.36	LICINSTALL	106
4.4.37	LISTLIC	107
4.4.38	LOADDRIVER	109
4.4.39	LOGIN	110
4.4.40	LOGOUT	111
4.4.41	PROGRESSBAR	112
4.4.42	REBOOT	113
4.4.43	RLYCLOSE	114
4.4.44	RLYOPEN	115
4.4.45	RUN	116
4.4.46	RSTENGSTATUS	117
4.4.47	SETADMINPWD	118
4.4.48	SETCOUNTER	119
4.4.49	SETDATE	120
4.4.50	SETDIO	121
4.4.51	SETIP	123
4.4.52	SETLOGLEVEL	124
4.4.53	SETMUX	125
4.4.54	SETPANELMODE	126
4.4.55	SGETENG	127
4.4.56	SGETERR	128
4.4.57	SGETSN	129
4.4.58	SGETVER	130
4.4.59	SGETVERALGO	131
4.4.60	SGETVERALGOLIST	132
4.4.61	SHA256	133
4.4.62	SHUFFLEDIO	134
4.4.63	SHUFFLEDIO_GETMAP	136

4.4.64	SPING	137
4.4.65	TCSETDEV	138
4.4.66	TCSETPAR	139
4.4.67	TESTVPROG	140
4.4.68	TPCMD	141
4.4.69	TPEND	142
4.4.70	TPSETDUMP	143
4.4.71	TPSETSRC	144
4.4.72	TPSTART	145
4.4.73	TPUNSETSRC	146
4.4.74	UNLOADDRIVER	147
4.4.75	VOLTAGEMONITOR	148
4.4.76	WATCHDOGFEED	150
4.4.77	WHOAMI	152
5	PROJECTS	153
5.1	EXECUTION AND TERMINATION	156
5.1.1	Standalone project execution	156
5.1.2	Remote projects execution	156
5.1.3	Projects Termination	157
5.2	PROJECT-SPECIFIC DIRECTIVES	157
5.3	LOGGING	157
5.4	COMMENTS	158
5.5	CONDITIONAL SCRIPTING	158
5.6	STANDARD TCSETPAR	160
6	SERIAL NUMBERING	161
6.1	INTRODUCTION	161
6.2	COMMAND SYNTAX	161
6.3	EXAMPLE	162
6.4	WORD ADDRESSING	163
6.5	USING DYNAMIC MEMORY WITHOUT FRB	164
7	DATA PROTECTION SYSTEM	165
7.1	USER MANAGEMENT	165
7.2	FRB ENCRYPTION	166
7.2.1	FRS performances	166
7.3	DYNAMIC DATA ENCRYPTION	168
7.4	OS CERTIFICATION	169

8	FLASHRUNNER INTERFACE LIBRARY	170
8.1	OVERVIEW	170
8.2	FLASHRUNNER INTERFACE LIBRARY OVERVIEW	170
8.3	INSTALLATION	171
8.4	INTERFACE LIBRARY REFERENCE (VERSION 1.0).....	172
8.4.1	<i>Using the Interface Library Functions</i>	172
8.4.2	<i>Return Values of the Interface Library Functions</i>	173
8.4.3	<i>Unicode Functions</i>	173
8.4.4	<i>Application examples</i>	173
8.4.5	<i>FR_OpenCommunication</i>	174
8.4.6	<i>FR_CloseCommunication</i>	175
8.4.7	<i>FR_GetAnswer</i>	176
8.4.8	<i>FR_GetFile</i>	177
8.4.9	<i>FR_GetLastErrorMessage</i>	179
8.4.10	<i>FR_SendCommand</i>	180
8.4.11	<i>FR_SendFile</i>	181
8.4.12	<i>FR_GetPublicKey</i>	182
8.4.13	<i>FR_EncryptData</i>	183
8.4.14	<i>FR_HexToAsciiStream</i>	184
8.5	INTERFACE LIBRARY REFERENCE (VERSION 2.0).....	185
8.5.1	<i>Using the C# Interface Library Class</i>	185
8.5.2	<i>Return Values of the Interface Library Methods</i>	186
8.5.3	<i>Method Reference for FR 2.0</i>	188
8.5.4	<i>FR_OpenCommunication</i>	188
8.5.5	<i>FR_CloseCommunication</i>	189
8.5.6	<i>FR_SendCommand</i>	190
8.5.7	<i>FR_GetAnswer</i>	191
8.5.8	<i>FR_GetLastErrorMessage</i>	192
8.5.9	<i>FR_GetDllVersion</i>	193
8.5.10	<i>FR_SendFile</i>	194
8.5.11	<i>FR_GetFile</i>	195
8.5.12	<i>FR_RunProject</i>	196
8.5.13	<i>FR_GetLogger</i>	197
8.5.14	<i>FR_DisposeLogger</i>	198
8.5.15	<i>FR_GetPublicKey</i>	199
8.5.16	<i>FR_EncryptData</i>	200
8.5.17	<i>FR_HexToAsciiStream</i>	201
9	FRB CONVERTER.....	202

10	VOLTAGE MONITOR.....	206
10.1	INTRODUCTION	206
10.2	COMMAND SYNTAX	207
10.3	COMPUTATIONAL LOAD	211
10.4	MEASUREMENT PROCESS.....	211
10.5	ERROR TYPES.....	213
11	PROGRESS BAR	214
11.1	INTRODUCTION	214
11.2	COMMAND SYNTAX	215
11.3	PROGRESS BAR AND DLL	217
11.4	LIMITATIONS	219
	FLASHRUNNER INTERNAL MEMORY	220
12	TROUBLESHOOTING	221
12.1	PROJECT EXECUTION FAILURES	221

1 Before Starting



Note: *an updated version of FlashRunner System Software is available on the SMH Technologies website (www.smh-tech.com). Please check it before continuing to read this documentation.*

1.1 Important Notice to Users

While every effort has been made to ensure the accuracy of all information in this document, SMH Technologies assumes no liability to any party for any loss or damage caused by errors or omissions or by statements of any kind in this document, its updates, supplements, or special editions, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause.

1.2 Getting Technical Support



Note: *Keep FlashRunner 2.0 always in a well-ventilated area in order to prevent product overheating, which could affect product performance and, if maintained for a long time, it could damage product hardware components.*

SMH Technologies is continuously working to improve FlashRunner firmware and to release programming algorithms for new devices. SMH Technologies offers a fast and knowledgeable technical support to all of its customers and is always available to solve specific problems or meet specific needs.

To get in touch with SMH Technologies, please refer to the contact information below.

Phone: +39 0434 421111

Fax: +39 0434 639021

Technical Support: support@smh-tech.com

2 System Setup/Upgrade

2.1 Software Setup

The FlashRunner system software setup installs all required components to your hard drive. These components include:

- FlashRunner 2.0 Workbench software;
- Command-line utilities and Interface Library;
- Documentation in PDF format.

To install the FlashRunner system software:

- Check the latest “**System Software**” package for FlashRunner 2.0 on SMH Technologies website;
- Follow the on-screen
- Instructions in order to install the System Software.



Note: *to install the FlashRunner system software you must log in as Administrator.*

To launch FlashRunner 2.0 Workbench under Microsoft Windows®, select **Start → Programs → SMH Technologies → FlashRunner 2.0 → FlashRunner 2.0 Workbench.**

Then click on File → Connect menu item in order to connect to FlashRunner 2.0. If the icon will change to “plugged state”, your product has been connected successfully.

2.2 What you need to start

FlashRunner 2.0 supports several devices. In order to program a specific device, you will need the following:

- A driver file (.so);
- A license file (.lic);
- An FRB file (.frb);
- A project file (.prj);

Driver files are dynamic libraries that contain routines needed to program a set of specific devices. SMH Technologies releases daily updates in order to support new devices, so when you request a new device, you'll often receive also an updated version of the driver.

License files are text files that contain a CRC key that binds together your specific FlashRunner 2.0 (by using its unique serial number) with your target device. There are different license types: license for a single target device, license for a single-family, license for a silicon manufacturer. Please ask SMH Technologies Sales Team for more information.

FRB file is the FlashRunner proprietary file format used to store customer firmware. There is a specific tool available from FlashRunner 2.0 Workbench, called FRB Manager, described on ch 3.15.

Project files are text files containing all the necessary information for setting your programming session. They contain some static information regarding the device, all user-configurable parameters and all commands which will be executed on the target device. FlashRunner 2.0 Workbench has a tool, Project Wizard, described in chapter 3.7 which allows users to create a

project from scratch only using graphical items. Once created, a project could be modified by simply editing it with a text editor. All files are stored in the user data path which can be found or changed on Tools → Settings menu items, “Paths” tab.

On the SMH Technologies website (www.smh-tech.com) you can check the full supported device list.

In order to program a specific device a specific license file for the couple “device and programmer” (identified by its serial number) must be purchased.


In addition, you can order a shared license, which binds a specific device to more serial numbers (up to 10 programmers can be included inside a license). Doing this, a single file could be installed in more programmers and enable them to program a specific target device.

You can purchase a license through our direct channel by writing to our Sales Office: sales@smh-tech.com or, if you bought FlashRunner from an SMH distributor, please contact him. Once bought a license you'll receive a package with a license file and a driver file, which must be copied to your FlashRunner 2.0 product.

2.3 Connection setup

FlashRunner 2.0 Workbench can control programmer in **Host mode** (via USB or Ethernet connection), or in **Standalone mode** (via Control Connector) which can select and run a specific project stored in its internal storage memory. For first use and, to connect it to FlashRunner 2.0 Workbench, you'll have to use FlashRunner 2.0 in Host mode.

Ethernet LAN connection settings:



Example of disconnected network card

By default, FlashRunner 2.0 IP address is 192.168.1.100, with SUBNET MASK 255.255.255.0 and gateway 192.168.1.1. After the first time connection you will be able to change this setting using SETIP command (see ch 4.4.49).



Note: LAN connector area reaches more than 50° degrees when connected to the host. Keep FlashRunner 2.0 always in a well-ventilated area to prevent product overheating, which could affect product performance and, if maintained for a long time, it could damage product hardware components.


Please use ethernet cable included in FlashRunner 2.0 box and connect it to your switch or directly to your host pc. Once connected, the red cross in the network connections icon related to your network card should disappear.

If host pc and FlashRunner 2.0 are connected through a router, please be sure that they are running in the same subnet: host pc

IP address must be included between 192.168.1.1 and 192.168.1.254 address range.

If your pc and FlashRunner 2.0 are directly connected, you'll need to set a static IP on network card used for connecting host pc with FlashRunner 2.0. Please open the network card settings window and use the following:


- IP ADDRESS: 192.168.1.X (where X is whatever number from 1 up to 254 except 100, which is FlashRunner IP)
- SUBNET MASK: 255.255.255.0
- GATEWAY: 192.168.1.100




FlashRunner 2.0 Workbench is configured by default to connect to 192.168.1.100 FlashRunner 2.0 IP address. If you'll need to change FlashRunner 2.0 IP address you can easily update also FlashRunner 2.0 Workbench settings using Tool → Settings menu item.

USB CONNECTION SETTINGS – WINDOWS® PROCEDURE:

Once connected USB cable, please check on Device Manager → Ports (COM & LPT) if you can find USB Serial Port (COMX). Where X is an integer number If not, please click Action → Scan for hardware changes.



Once found this item, please sign which COM port has been assigned to FlashRunner and use it to setup FlashRunner 2.0 Workbench software: please click on Tools → Settings, click on “Serial” connection type and put COMX value inside Port textbox.



USB CONNECTION SETTINGS – LINUX PROCEDURE:


Please check with dmesg command which device node has been assigned to FlashRunner 2.0. Usually Linux assigns ttyUSBX (where X is an integer number) device node. Please check under /dev folder if your user has write/read privileges on /dev/ttyUSBX device node. If not, please add it through chmod. Please open FlashRunner 2.0 WorkBench Tools → Settings, select Serial Connection Type and fill Port textbox with /dev/ttyUSBX.

2.4 Firmware Update

Please, note that the procedure below is referred to the latest version of GUI WorkBench.

In order to update FlashRunner 2.0 simply follow these steps:

1. Please connect to FlashRunner 2.0 using the "Connect" button at the top left of GUI WorkBench.
2. Click [here](#) to get the latest FlashRunner 2.0 firmware.
3. Click to "Update OS" in the GUI WorkBench, like in the image below.



4. Then select the file "update.tgz" that you just downloaded. The GUI WorkBench will transfer the file and it will ask to reboot the FlashRunner.
5. Please, connect again to FlashRunner using "Connect" button at the top left of GUI WorkBench.
6. Open Terminal tool available on GUI WorkBench and send on "Master" channel (selectable by toolbar on the bottom-right side) "FPGASTATICVER" command.

7. If FPGASTATICVER command answer is less than “8”, you need to manually reboot the FlashRunner two more times by doing a power cycle.
8. Please, check [here](#) to get the latest FlashRunner setup, to get the latest GUI WorkBench version, updated documentation and related tools. Please remember to uninstall the previous FlashRunner setup before installing the new one.

3 FlashRunner Workbench

3.1 Overview

FlashRunner Workbench is a simple application for PC which is able to communicate with FlashRunner 2.0, FlashRunner LAN NXG, FlashRunner LAN K NXG and FlashRunner HS. It performs the following operations:


1. Create new projects;
2. Run projects and monitor programmer status;
3. Create FRB binary files;
4. Copy projects, FRB, drivers and licenses from / to programmer;
5. Update OS and Drivers;
6. Retrieve log.

FlashRunner Workbench is compatible with all Microsoft Windows® operating systems and with Linux operating system.

3.2 Opening window

Once you run FlashRunner Workbench you'll see a window like the one below. It's designed with a top toolbar, a left toolbar and a central area that contains the recent projects.


From this window, you can create a new project or open an existing one.



After opening a project, the opening window will change and you will see the project details. The new window will be like the one in the figure below.

This window has still the same toolbars and a central area composed of 3 tabs:

1. **Project Setup:** this tab gives a review of all settings of the current project.
2. **Production Control:** this tab monitors the on-going programming session.
3. **Project Editor:** this tab allows the user to manually edit the project from an advanced text editor.




3.3 Top toolbar

From left to right, the top toolbar provides the following features:



1. **Connect button:** connect/disconnect from FlashRunner and review connection status.
2. **Send configuration button:** send project and FRB to FlashRunner.
3. **Update database:** download the latest version of the Devices.smh file, which contains all the info of the supported devices.
4. **Working mode:** set the working mode of FlashRunner (this command is not available if the unit connect is a FlashRunner HS).



5. **Send button:** click to send projects, FRBs, drivers, licenses and OS updates.
6. **Get button:** click to get projects, FRBs, drivers, licenses and logs.

3.4 Left toolbar

The left toolbar shows the most important features of FlashRunner Workbench at a sight.



Create project wizard. See ch 3.7



Edit actual / existing project



Load project



Advanced FRB manager to create / edit an FRB file



Show device list



Pin map of the devices selected in the project



Memory map of the devices selected in the project



Advanced File Manager. See ch 3.10



Terminal. See ch 3.11




Log. See 3.12


3.5 Project setup

After creating or opening a project, you will see a review of all the project settings. Moreover, you will get also information about connections and wirings, they are also available on the Pin Map Tool described in ch 3.14.

It is also possible to export this page in PDF.



3.6 Production Control



After opening a project, into Production Control tab will be loaded a widget for each channel defined inside the project. Each widget contains the following labels:

1. **Device:** shows the target device name defined for that channel.
2. **Binary File:** shows FRB file defined for that channel.
3. **Run button:** the button which starts the project only on that single channel.

4. **Prog. Time:** shows the total execution time for that channel.
5. **N° of PASS:** shows the number of successful project executions for that channel.
6. **N° of FAIL:** shows the number of failed project executions for that channel.
7. **Status:** label which reports actual channel status. There are four possible states:
 - a. **Pass:** last project execution completed successfully and the channel is idle.
 - b. **Fail:** last project execution failed and the channel is idle.
 - c. **Idle:** the channel is waiting for project execution.
 - d. **Busy:** The channel is running a project.

On the right side of Production Control there are 5 sections:


1. **Send Project to FlashRunner:** this button sends the PRJ file and FRB files to FlashRunner.
2. **General Information:**
 - a. **Project Name:** shows the project name currently loaded.
 - b. **Operator Name:** shows the operator name (the user can insert it there).
3. **Channels Information:**
 - a. **N° of Runs:** shows the total number of executions considering each channel separately.
 - b. **N° of PASS:** shows the total number of successful executions considering each channel separately.
 - c. **N° FAIL:** shows the total number of failed executions considering each channel separately.

4. **Project Information:**
 - a. **N° of Cycles:** shows the total number of project executions.
 - b. **N° Cycles PASS:** shows the total number of successful project executions.
 - c. **N° Cycles FAIL:** shows the total number of failed project executions.
 - d. **PASS Percentage:** shows the actual pass percentage over the total number of project executions.
 - e. **Avg. Cycle Time:** shows the average time of project executions.
 - f. **Max. Cycle Time:** shows the maximum time of project executions.
 - g. **Min. Cycle Time:** shows the minimum time of project executions.
 - h. **Last Cycle Time:** shows the time of the last project execution.
 - i. **Clear All:** this button will reset all the shown values.
5. **Control Room:** this section lets the user control the project executions. It is possible to launch a single project execution or to launch a stress test with multiple consecutive executions. Stress test mode can be launched with some additional settings:
 - a. **Sync. Channels:** this option, if enabled, synchronize the start of the project on all the channels (default case), otherwise each channel will run separately.
 - b. **Stop on Failure:** this option, if enabled, stops the stress test if a channel fails.
 - c. **Limited to:** this option sets a limit to the number of project executions.

3.7 Project Editor

Into the Project Editor tab, the user can find a built-in text editor which can be used to manually edit the project file.

This editor has a syntax analyzer that helps the user to avoid mistakes and simplify the recognition with different colors. When saving a project, a warning could appear if there are some unrecognized commands and they can be easily noticed because these commands are underlined in red.



The screenshot displays the Project Editor tab within a software interface. The top bar shows three tabs: 'Project Setup', 'Production Control', and 'Project Editor', with 'Project Editor' being the active tab. Below the tabs is a toolbar with icons for Save, Undo, Redo, Cut, Copy, Paste, Select All, Comment, and Export to HTML. The main editing area contains a project file with the following content:

```
1 ;Project generated by "FlashRunner WorkBench 3.03 BETA 10"
2 ;Generated for "FlashRunner 2.0"
3
4
5 ;DEVICE: R5F10AGE
6 ;DRIVER: RN55_F 02.02
7
8 !ENGINEMASK 0x0000000F
9 #LOADDRIVER librns5.f.so RENESAS RL78 R5F10AGE
10 #TCSETDEV VDDMIN 2700
11 #TCSETDEV VDDMAX 5500
12 #TCSETDEV FOSCMIN 32000000
13 #TCSETDEV FOSCMAX 32000000
14 #TCSETDEV FPLLMIN 0
15 #TCSETDEV FPLLMAX 0
16 #TCSETDEV MCUID 0x3BB3
17 #TCSETDEV IDCODE 0x00000000
18 #TCSETDEV IDCODE_MSK 0x00000000
19 #TCSETDEV CORE RL78
20 #TCSETDEV MEMMAP 0 C 0 0x00000000 0x0000FFFF 0x400 0x100 0 64 0x0 0x0 0xFF 0x0 0
21 #TCSETDEV MEMMAP 1 D 0 0x000F1000 0x000F1FFF 0x400 0x100 0 4 0x0 0x0 0xFF 0x0 0
22 #TCSETDEV DEVICE_GROUP F13
23 #TCSETDEV FLASH_TECH MF2_RL78
24 !CRC 0x8D43720B
25 #TCSETPAR FOSC 32000000
26 #TCSETPAR PROG0LIMITS 100 0 0
27 #TCSETPAR PROG1LIMITS 100 0 0
28 #TCSETPAR PROTCCLK 1000000
29 #TCSETPAR PWDOWN 100
30 #TCSETPAR PWUP 100
31 #TCSETPAR RSTDOWN 100
32 #TCSETPAR RSTDRV OPENDRAIN
33 #TCSETPAR RSTUP 100
34 #TCSETPAR VPROG0 5000
35 #TCSETPAR CMODE UART1
36 #TPSETSRC R5F10AGE.frb
37 #TPSTART
38 #TPCMD CONNECT
39 #TPCMD MASSERASE C
40 #TPCMD BLANKCHECK C
41 #VOLTAGEMONITOR ON ERROR_EXIT
42 #TPCMD PROGRAM C
```

3.8 Wizard

FlashRunner collects all the user settings related to the programming sessions in text files called “projects”. Inside each project, you'll find a set of commands (all rows beginning with “#” character are commands, see ch. 4) which, of course, could be sent one by one through our interface library, through the serial port or through “Terminal” tool of FlashRunner Workbench. Having a single file including all these settings however brings several benefits to users, which they could save on a single file all the settings needed to program a specific device and running a complete programming cycle with only one click.

Wizard tool is one of the most innovative features of FlashRunner Workbench and lets users create a complete working project using only graphic items. A set of wizard pages will guide users toward all the specific device settings. Once completed, a project file will be created inside the FlashRunner data folder (which can be found or changed on Tools → Settings menu items, “Paths” tab) and must be uploaded to FlashRunner before executing it.

3.8.1 FlashRunner selection page

You can create a new project using File → New Project. If the FlashRunner WorkBench is not connected to the FlashRunner the first wizard page will let you select the FlashRunner for which you want to create the project.




If the FlashRunner WorkBench is already connected to the FlashRunner the wizard will show you the main page (see next chapter).

3.8.2 Main page

This is the main page of the wizard to create/modify a project. If FlashRunner Workbench is connected to the FlashRunner, you'll have a set of checkboxes enabled depending on how many channels are enabled/available on the FlashRunner.


The page is structured as follow:

- On the top a name for the project can be inserted.
- On the right-top it can be selected the *Configuration Mode* which depends on the device you want to program.
- In the centre there are the available channels.
- On the left can be created a device's project.




3.8.3 Device selection page

Clicking on “Create New Device” you can select which target device you want to program. Remember that each device needs its library, written in “Driver Name” column; make sure to have this library. You can download it locally on your PC the latest version by just clicking on the driver on the “Download Driver via FTP” column.



3.8.4 FRB Management page



On the FRB management page are present some options about FRB creation and usage. First, you can choose the source:

- **Select an existing FRB file:** select an already created FRB file.
- **Quickly generate a new FRB file:** select an FRB source file and convert it with just a single click. This is the fastest way to convert a source file to FRB. The FRB is created and saved in the standard user data folder with the same filename as the selected source file (some special characters like ‘&’ are not allowed).
- **Manually compone a new FRB file:** open a new window to access advanced features about FRB file creation. See chapter “Advanced FRB Manager” for more details.
- **Use only Dynamic Memory:** this doesn’t create any FRB file, it only uses dynamic memory. See chapter “Serial Numbering”.
- **No FRB file:** this will set no FRB files.

In this window it is also possible to set the advanced option “**Ignore blank page**”: this allows FlashRunner to skip pages without any data different from the blank value. Sometimes this feature can improve flashing times, according to the device's characteristics. Be careful that this option can not be used for all devices. If you are not sure please contact our Support Team.

At the bottom of the page, the user can also open and check the memory map of the selected device. The Memory map tool is described in detail on ch 3.13.

3.8.5 Communication settings page

This page has several configurations about the communication setting:

- **Communication Protocol:** JTAG, SWD, UART, SPI...
- **Communication Frequency:** in MHz
- **Input Clock:** frequency of the External Oscillator of the device. This field is not always present.
- **PLL Clock:** frequency of the PLL of the device. This field is not always present.
- **Reset Drive and Reset Time:** select the reset-up and reset-down time. The reset drive selects how the FlashRunner manages the reset line. OPENDRAIN means that the FlashRunner, after the reset, does not drive the line. PUSH/PULL means the FlashRunner always drives the line. The choice is based on the hardware setup of the board.
- **Power Time:** the FlashRunner can be used also as a power supply for the board. If there are big capacitors, it may be necessary to increase the power-up time. It is also possible to reduce this time to save a few milliseconds.

All these settings will enter as #TCSETPAR in the final project.

Device Wizard

Communication Settings

Setup communication settings.

Communication Protocol

JTAG

Communication Frequency

Frequency

25000000

Hz

25.00 MHz

Target Device Clock Settings

Input Clock

16000000

Hz

16.00 MHz

PLL Clock

60000000

Hz

60.00 MHz

Reset Drive

OPENDRAIN

Reset Time

Reset up time

100

µs

Reset down time

100

µs

Power Time

Power up time

100

ms

Power down time

100

ms

3.8.6 Powering settings page

This page allows the user to set the values of VPROG0 and VPROG1 and their tolerance values (#TCSETPAR values). The VPROG0 is also the logical voltage of the DIO signals. VPROG1, instead, can only be used as a power supply. The tolerance for the VPROG and IPROG monitoring can be set.

On this page, it is also possible to set the relay barrier usage, to manage automatically the opening and closing of the relays.

Device Wizard

Powering Settings

Setup powering options.

VPROG0 Status

VPROG0 Enabled

VPROG0 Settings

☒ VPROG0

Voltage

3300

mV

3,300 V

☐ VPROG0 Read

Tolerance

mV

V

☐ IPROG0 Read

Tolerance

mA

A

Expected

mA

A

VPROG1 Status

VPROG1 Disabled

VPROG1 Settings

☒ VPROG1

Voltage

mV

V

☐ VPROG1 Read

Tolerance

mV

V

☐ IPROG1 Read

Tolerance

mA

A

Expected

mA

A

Relay Control Status

Relay Control Disabled

< Back

Next >


Cancel

3.8.7 Additional parameters page

This page contains some additional parameters related to the device. This page is driver and device-dependent. To know more about the settings here presented, the WIKI of the driver can be consulted.

3.8.8 Command settings page

This page contains the standard commands related to the memory regions of the device. Some commands may be disabled according to the FRB file chosen. If there is no data present for some area, the Wizard does not allow to enable the Program and Verify operations. Moreover, the Checksum, Read and Dump operations may be not available for some devices.




3.8.9 Additional commands page

This page contains some additional commands related to the device. This page is driver and device-dependent. To know more about the settings here presented, the WIKI of the driver can be consulted.

3.8.10 Add the project to a channel

Once the device is created, on the main page the user will see on the left the device. With drag and drop the user can insert the device into the desired channels.



The user can create new devices and add them to a channel. Once the project creation is ended, the user can give a name to the project and click on finish.

3.9 Encrypt FRB (FRS)

An existing FRB could be encrypted through FlashRunner Workbench software. You simply have to click on the “Encrypt FRB” button from the tools menu and choose the FRB file you want to encrypt.

Otherwise, it is also possible to check the “Encrypt FRB” option while creating the FRB from the “Advanced FRB Manager”, this will directly generate the encrypted file without creating any additional unencrypted FRB file.

The encryption method requires some key exchange with the FlashRunner, so be sure to connect it to your computer. In case the FlashRunner cannot be connected to the computer that has to encrypt the file, you can get the keys from another computer connected to the FlashRunner, then you can export the keys and import them to your computer.

During the encryption process, you will be asked to choose for which FlashRunner SN you want to encrypt data, you can choose more than one SN and only those FlashRunners will be able to decrypt the data contained in the encrypted FRB.

The new encrypted file will be placed in the same folder, with the same filename and .frs extension, which is the encrypted version of the original FRB.


If you have a project which uses the original FRB file and you want to substitute it with its encrypted version, please modify the project file with the project editor at the #TPSETSRC command line. Then send both the project and FRS file to FlashRunner.

The encryption method implemented is AES256.
This feature is available for OS versions >= 3.19.

In case you were using encrypted FRB files for OS < 3.19, you can upgrade them with a couple of clicks. In fact, You simply have to click on the “Encrypt FRB” button from the tools menu and choose the FRS file you want to upgrade.

It is also possible to generate or upgrade an encrypted FRB file from the command-line tool “[FRB Converter](#)”

3.10 Advanced file manager




Advanced File Manager is an easy tool for updating or retrieving files to/from connected FlashRunner. On the left side you'll find your local resources, on the right side you'll find FlashRunner resources, in which only five folders are available and are shown as tabs.

As the names suggest, project files (.prj) must be copied in "Project" folder, drivers (.so) must be copied in "Drivers" folder, licenses (.lic) must be copied in "License" folder, FRB files must be copied in "FRB" folder, the log file is available in "Log" folder. Once clicked a file from your local resources, please select a destination folder and then click "Send" button. Vice versa, select a file from FlashRunner folder and click "Get" button.

On the bottom of the right side you can also see the memory usage of your FlashRunner:

- **Total memory:** the amount of memory contained on the partition of the SD card.
- **Memory used:** the amount of memory that is currently used by user data.
- **Memory free:** the amount of memory that is unused.
- **Percentage:** percentage of memory used by user data.
- **Log.txt size:** size of the log file, this can grow up to 200MB, then it will be automatically resized, but 200MB are always pre-allocated.
- **Available memory:** the amount of memory that can be used by user data. This is different from “Memory free” because it also considers the 200MB of the log file.

3.11 Terminal




Host pc interacts with FlashRunner via synchronous serial communication. Host send commands and receive answers, for detailed information regarding communication syntax and available commands please see ch 4.

On the top left side of the window a label will show you which channel is selected. To send a command, write it inside the editable combo box at its right, finally, click the “Send” button. If you want to send a command to all channels simply click the “Send all” button. If you want to change the channel, please, select it with the button toolbar at the bottom right side.

Please note that the “#” character will be automatically added, if not entered.

On the left side, you have a list of buttons to quickly send the most common commands.

3.12Log



The Real-Time Log feature shows the complete tracking of FlashRunner activity.

“Communication” tab will show full communication based on received commands, while “Channel communication” will filter out communication by single channel. You can select a channel by using the bottom right toolbar. “Log” tab will show all operation executed by FlashRunner, including commands included in project files. Each row is composed with the following syntax:

```
<channel>|<log level>|<timestamp>|---<command sent>
<channel>|<log level>|<timestamp>|<command answer>
```

Example:

```
01|2|200331-16:28:10.437|---#TPCMD VERIFY F S  
01|1|200331-16:28:12.306|Time for VERIFY F S: 1.87 s  
01|2|200331-16:28:12.306|>|
```

Log Level is a number from 1 up to 6 and defines logging verbosity level. Level 1 is the more verbose, level 6 is the most concise. You can change log verbosity with SETLOGLEVEL command (check ch 4.4.52).

Timestamp shows in which moment a command has been executed. Syntax used for timestamp is:


<year><month><day>-<hour>:<min>:<sec>.<millisec>

For each command sent there could be one or more answer lines.

It is also possible to hide timestamp by unticking the “Show Datetime” check box.

3.13 Memory Map tool

This tool show the memory map of each device included into the project. The interface is very simple and contains a lot of useful information about the memory of the device.




The screenshot shows the 'Memory Map Tool' window. It displays device information for SPC584C80, SPC58 family, STMICROELECTRONICS manufacturer, and FSL_E algorithm. Below this is a table with 8 rows of memory map data. At the bottom right, there is an 'Export to PDF' button.

	Memory Type	Start Address	End Address	Memory Size	Page Size	Blank Value	Address Unit
1	[U] - UTEST	0x00400000	0x00400307	776 Byte	16	0xFF	BYTE
2	[U] - UTEST	0x00400370	0x00400FFF	3.14 KiB	16	0xFF	BYTE
3	[U] - UTEST	0x00401000	0x00401FFF	4.00 KiB	16	0xFF	BYTE
4	[G] - BAF	0x00404000	0x00407FFF	16.00 KiB	16	0xFF	BYTE
5	[A] - HSM Code	0x0060C000	0x0062FFFF	144.00 KiB	16	0xFF	BYTE
6	[B] - HSM Data	0x00680000	0x00687FFF	32.00 KiB	16	0xFF	BYTE
7	[E] - Data Flash	0x00800000	0x0081FFFF	128.00 KiB	16	0xFF	BYTE
8	[F] - Code Flash	0x00FC0000	0x013BFFFF	4.00 MiB	16	0xFF	BYTE

Export to PDF

3.14Pin Map Tool



PinMap tool is a handy feature that helps users to do cable wirings from the target device to FlashRunner ISP connector. On the top you can select the FlashRunner (2.0, NXG or HS) and see the corresponding PinMap. Clicking on one of the channels available in list will load a table on the right side of the window, which lists all signals involved for device connection on that specific channel. Once clicked, related pins will become coloured and clicking on one of them will highlight the related signal in the signals table. Please note that FlashRunner has one or two ISP connectors based on product version: FlashRunner versions with 8 or less active channels will have only one ISP connector, FlashRunner with more than 8 active channels will have two ISP connector. Please pay attention to the connector indication on top of signals table: first 8 channels are related to the master board connector, channel 9 up to 16 are related to the slave board connector.

3.15 Advanced FRB Manager

The Advanced FRB Manager is a tool to create an FRB file (i.e. FlashRunner Binary) which contains all the source files (more than one is allowed) needed to program the target device. You can find this tool via Project Wizard or by selecting Tools → FRB Manager.


Attention: converting an FRB through the Advance FRB Manager allows you to create an FRB without a device Memory Map as a reference; hence the data position of the source file can not be checked.

FRB Manager can convert the most common source file formats: RAW Binary; Intel Hex and Motorola SREC.

Advanced FRB setup will enable full features to users to let them compose their FRB file. Users can import multiple source files, edit single blocks start address and size, remove blocks and add “fill” or “variable data” blocks.

After opening the window (see the image above), the user can decide to create a new FRB by clicking the “New FRB” button or to edit an existing FRB by clicking the “Open FRB” button.


After that, the buttons on the left side will be activated and the user will be able to: add, edit, duplicate or delete a block of the FRB. The operations to edit, duplicate or delete a block will be active only after selecting a block from the list.




At the bottom of the window, the user can set the destination file and launch the conversion when the work on the FRB file is completed.

It is also possible to Select a Device (bottom left) to enable the check of the source file position respect to the memory map of the device. This operation can be skipped.

3.15.1 Add data to FRB: import from source file



Multiple source files can be added (also of different formats). Clicking on “**Add**” source file can be selected, choosing the format (binary, Intel Hex ...). The tool automatically recognizes if the file selected is compatible with the memory map of the device. If one or more blocks are read, it means that they have data outside the programmable address of the device. If two or more blocks are blue, it means that there is an overlap of data in the same addresses (more blocks have data in the same places). Green means that everything is correct.



When choosing Intel Hex, the user should also choose the encoding type: if data has been defined by words or by bytes. If you are not sure about what to select, just use the “Byte encoding” option.

Data parsing will be achieved by reading and merging all the source file rows which define adjacent data areas, each disjointed block will define a new data area and will be placed in a new row (new block).

3.15.2 Add data to FRB: Fill Data / Variable Data

The screenshot shows a dialog box titled "Add data to FRB" with a close button (X) in the top right corner. It has two tabs: "Import from source file" and "Fill Data / Variable Data". The "Fill Data / Variable Data" tab is active. Inside the tab, there is a text block that reads: "Values flashed in this area will be defined through **DYNMEMSET** command. If no dynamic data covers this area, Filling value defined below will be flashed. Please check out 'Programmer's Manual' documentation for more information." Below this text is a horizontal line. Under the line, there are three input fields: "Start Address (hex)" (empty), "Size (hex)" (empty), and "Value (hex)" (containing "FF"). Below these fields is another horizontal line. At the bottom of the dialog, there are "OK" and "Cancel" buttons. A red error message "You need to insert a valid Start Address." is displayed in the center of the dialog.

On the “Add “ window there is a second tab called “Fill Data / Variable Data”, the user can add a new block to FRB which contains the same value for each byte.

As you can see in the figure above, the user can set the start address, the size and the fill value of the block.

The new block will not impact total FRB size and could also overlap existing data.

The same procedure is valid also for variable data, in fact, the user should just choose the value that corresponds with the blank values of the device memory.

This will be used for dynamic content definition during target device programming (please check ch 6 for detailed information).

3.15.3 Edit FRB block

Source Address Setup (Byte):

Original Start Address: 0x00000000

Original Size: 0x20000 - [128.00 KiB]

New Start Address: 1000 ✓

New Size: 0x1F000 - [124.00 KiB]

☐ Link to target address

Source Start Address is Valid.

Target Address Setup (Byte):

Original Target Start Address: 0x00000000

New Target Start Address: 1000 ✓

Target Start Address is Valid.

Target Size Setup (Byte):

Remaining Size: 0x1F000 - [124.00 KiB]

New Target Size: 1000 ✓

Block Inserted: [0x00001000 - 0x00001FFF].

Restore original settings

OK Cancel

Once the user adds some data inside the new FRB file, some data rows inside the input data table will appear. If a data block overlapping occurs, two blocks involved are highlighted and the user should solve the conflict or explicitly decide to leave this conflict unresolved.

In order to modify a single data block, you need to select it on the input data table and then click on the “Edit” button, a new window will appear, like in the image above.



Data block overlapping conflicts will be solved following this rule: the last data block (in row order) will overwrite overlapping data of the first data block.

From the new window, the user will be able to edit the source start address, the target start address and the size.

If you use have selected a device, the memory map will appear at the bottom of the window. This helps to place the block in a proper memory region.

If the chosen settings don't fit any device memory regions, a warning will appear. As a result, data blocks that don't fit any device memory region will not be programmed at all on target device flash memory.

Source address Setup

This text field defines the address of the source file from which will start the block. This is only related to the source file.

The default value is the first address of the block.

Target address Setup

This text field defines from which target device address will start block. This is the actual address from which the FlashRunner will start programming the target device.

The default value corresponds with the source address.

Target Size Setup

This text field defines how many bytes will compose the block.

This corresponds to the number of bytes which will be programmed on the target device by FlashRunner.

The default value is the full block length.

Example (see image below):

The block as default starts from 0x00 and flashes data into the device from 0x00.

Setting 0x1000 in the “Source Address Setup” means that the data from 0x1000 of the source file are going to be flashed from address 0x00 of the target device.

The last operation changes the data available for the block. Originally they are 0x100000, now 0xFF000. For this reason, the “Target Size Setup” has to be changed to 0xFF000. This field means that the bytes to be considered for that block are 0xFF000.

The ”Target Address Setup”, instead, changes the target device address. 0x3000 means that the data are going to be flashed from address 0x3000 of the device, instead of 0x00.

Source Address Setup (Byte):

Original Start Address: 0x00000000

Original Size: 0x100000 - [1.00 MiB]

New Start Address: ✓

New Size: 0xFF000 - [1020.00 KiB]

☐ Link to target address

Source Start Address is Valid.

Target Address Setup (Byte):

Original Target Start Address: 0x00000000

New Target Start Address: ✓

Region Selected: [0x00000000 - 0x003FFFFF].

Target Size Setup (Byte):

Remaining Size: 0xFF000 - [1020.00 KiB]

New Target Size: ✓

Block Inserted: [0x00003000 - 0x00101FFF].

Type	Memory	Start Address	End Address	Addressing
X	External Memory	0x00000000	0x003FFFFF	Byte

Restore original settings

Byte Addressing Memory Map

OK

Cancel

3.15.4 Other Options

Other options are present in the FRB Manager window:

1. **Crop:** the start address and the size of the block can be changed. Changing the start address, all the data before that address are going to be erased. Changing the size, all the data after are going to be erased. This operation is irreversible.
2. **Remove:** the block can be removed from the creation of the FRB.
3. **Duplicate:** the block is duplicated. An overlap will be formed.
4. **Fill Gaps:** merge source blocks where the distance between them is less than the program page size of the memory selected; the value used to fill the gap is the blank value (see Memory Map). This can optimize FlashRunner performances when too many blocks are present. This operation is irreversible.
5. **Unify Contiguous Memory Regions:** treats two or more contiguous memory regions as a unique region. The FRB creator by default doesn't accept a block to cross different memory regions and it is highlighted in red. This option removes this limit.

4 FlashRunner Commands

4.1 Overview

FlashRunner is set up and controlled via ASCII-based commands. FlashRunner can receive and execute commands in two ways:

- Over a USB or Ethernet connection (**Host mode**);
- Via signals received by its “Control connector” which are able to select and run a specific project stored in its internal storage memory (**Standalone mode**).

In the first case, FlashRunner is controlled by a host system; in the latter case, FlashRunner works in standalone mode and is fully autonomous inside an integrated production system.

4.1.1 Host Mode

In Host mode, commands are sent from the host system to FlashRunner:

- By using a TCP/IP command-line utility (like Termite© on Microsoft Windows©);
- By using any programming language that is able to send and receive data to/from a host system COM port or Ethernet port (i.e. Microsoft Visual C++/Visual Basic, National Instrument LabView/LabWindows, etc.) An Interface Library is available upon which you can build your own application (see “Projects” chapter).

Alternatively, you can use the FlashRunner Workbench software to send commands to the instruments.



Note (for TCP/IP command-line utilities):

FlashRunner factory IP address is 192.168.1.100 and data is exchanged on port 1234.

4.1.2 Standalone Mode

In Standalone mode, FlashRunner does not need a connection to a host system. A group of control lines (SEL[4..0] in the “CONTROL” Connector) determines which of the 32 available projects stored in FlashRunner memory must be executed. A project is simply a text file containing a sequence of FlashRunner interface commands, plus some project-specific directives. Projects are explained in detail in the ch 4.4.73.

4.2 Command Syntax

4.2.1 Sending a Command

Each command, except project-specific directives shown in table 5.2, must start with the # character (FlashRunner Terminal tool automatically adds this character). As first glance, a command could be sent to:

- Master engine
- A single site engine
- All engines (Master engine and site engines)
- All site engines
- A subset of site engines

Each command has a different coverage, described in chapter 4.3. For example, some commands can be sent only to the master (like **#SPING**), other only to the site engines (like **#RUN**).

Each command is mainly composed by the following two parts:

1. Command name, for example: **RUN**
2. One or more parameters, each separated by a space, for example: **RUN example.prj example.frb**

The length of each command's parameter is at maximum 40 characters. All parts of the command are case sensitive.

When sending a command, the # character is always used as first character of the string.

Single Site Command:

A command sent to a single engine begins with # character followed by <channel number> (decimal value of the channel), followed by * character, followed by the command, a Carriage Return character and a final Line Feed character. Channels' number starts from 1 up to 16, the master engine is 55.

Example:

Send a command to channel 7:

*#7*RUN example.prj*

Send command to the master:

*#55*SPING*

All Site Command (site engines and master):

A command sent to all engines in parallel begins with # character, followed by the command, a Carriage Return character and a final Line Feed character:

Example:

#RUN example.prj

Subset of site engines:

A command sent to a subset of site engines begins with # character followed by <engine mask>, followed by | character, followed by the command, a Carriage Return character and a final Line Feed character. The <engine mask> is a decimal

number which identifies bitwise channels on which command must be executed.

Example:

Send a command to channels: 8, 5, 3, 2, 1.

Engine Mask: 0b10010111 = 151

#151|RUN example.prj

Send a command to all channel, but not the master.

Engine Mask: 0b11111111 = 255

#255|RUN example.prj

FlashRunner Workbench software can send commands via the Terminal tool, which automatically adds #<channel number>*. Before sending a command, please click on the bottom right side of the window the channel for which you want to send the command. See chapter 3.11 for more details.

Project files contain ENGINEMASK pseudo-command which already defines which engines will be involved for the following commands. For this reason, commands inside a project file don't need channel prefix. Thus, inside a project a command will be # character, followed by the command, a Carriage Return character and a final Line Feed character.

Example:

#TPSTART


#CONNECT

4.2.2 Receiving the Answer

After receiving a command from the host system and executing it, FlashRunner responds with an answer string. The answer string is composed of zero or more response characters, followed by one result character, followed by a final Line Feed. The character of the result is:

- > if the command has been executed successfully or
- ! if the command generated an error.

Below are two examples of answer (with and without error):



When a FlashRunner command executes successfully, FlashRunner typically answers just with the engine number followed by | character, followed by > character, see figure above, (unless the command requires data to be returned).

When a FlashRunner command generates an error, FlashRunner answers with an eight-digit hexadecimal error code followed by the ! character (see figure above).

4.2.3 Numeric Parameters

Every numeric command parameter can be expressed either in decimal or hexadecimal format. Hexadecimal numbers must be preceded by the `0x` symbol. The figure below shows three examples of usage of the `DYNMEMSET` command to write two bytes on FlashRunner dynamic memory. These two examples below are equivalent:

```
#DYNMEMSET 0x8E0400 0x2 0x00 0xFF  
#DYNMEMSET 9307136 2 0 15
```

Numeric parameters returned by FlashRunner as command answer (CRC, memory data, error codes, etc.) are expressed in hexadecimal or decimal format, depending on the case.

4.3 Command Summary

The following table summarizes all of the FlashRunner commands. Each command is fully described in the “Command Reference” section. The “Type” column describes if the command will work on channel engines (“S”) or for the master engine only (“M”).

Command Syntax	Description	Scriptable	Type	Permission
System Commands				
CRC	CRC of TCSETDEV section	NO	S	ADMIN
CLRERR	Clear the errors stack	NO	M+S	ADMIN
CLRLOG	Clear the log file	NO	M	ADMIN
DELAY	Stop every operation for an interval	YES	M	GUEST
ECHO	Echo a string	YES	S	GUEST
FSEXIST	Check if a file does exist inside FlashRunner memory	NO	M	GUEST
FSCRC	Return the CRC32 value of a file	NO	M	GUEST
FSGETCONTROL	Read control interface value	NO	M	GUEST
FSLs	List files	NO	M	GUEST
FSLs2	List files with more details	NO	M	GUEST
FSRM	Remove file	NO	M	ADMIN
FSSETCONTROL	Set control interface value	NO	M	ADMIN
GETAVGVPROG	Return the avg VPROG calculated by Voltage Monitor	YES	S	GUEST
GETCOUNTER	Get flashing counter	NO	M	GUEST
GETDATE	Return the actual FlashRunner date/time	NO	M	GUEST
GETFILE	Return file from FlashRunner	NO	M	ADMIN
GETFREEMEM	Show details about memory usage	NO	M	GUEST
GETLOGLEVEL	Gets the log verbosity level	NO	M+S	GUEST
GETIP	Return the FlashRunner IP address, netmask and gateway	NO	M	GUEST
GENCRYPTOKEY	Generate keys used to encrypt/decrypt data	NO	M	ADMIN
GETPUBKEY	Get the public key used to encrypt data	NO	M	GUEST
GETPROGRESSBAR	Return the programming percentage	NO	M	GUEST
GETVPROG	Read a power line value	NO	S	GUEST
HELP	Show help table for a driver	NO	S	GUEST

Command Syntax	Description	Scriptable	Type	Permission
ISMEMENOUGH	Check if there is enough memory	NO	M	GUEST
ISPANELMODE	Return FlashRunner working mode	NO	M	GUEST
LISTLIC	Return licenses list	NO	M	GUEST
LOGIN	Login a user account	NO	M	GUEST
LOGOUT	Logout a user account	NO	M	GUEST
REBOOT	Reboot programmer	NO	M	GUEST
SETADMINPWD	Set administrator password	NO	M	ADMIN
SETCOUNTER	Set flashing counter	NO	M	ADMIN
SETDATE	Get the actual FlashRunner date/time	NO	M	ADMIN
SETDIO	Set output state of DIO	YES	S	GUEST
SETIP	Set FlashRunner IP address	NO	M	ADMIN
SETLOGLEVEL	Set log verbosity level	NO	M+S	ADMIN
SETMUX	Drive demultiplexer	NO	M	GUEST
SETPANELMODE	Change FlashRunner working mode	NO	M	GUEST
SHA256	Calculate sha256 of a file	YES	M+S	GUEST
SHUFFLEDIO	Switch, for the indicated DIOs, the output.	YES	S	GUEST
SHUFFLEDIO_GETMAP	Get the actual DIO Map	YES	S	GUEST
TESTVPROG	Set up a defined value on VPROG lines	NO	S	GUEST
WATCHDOGFEED	Set square wave on selected channel	YES	S	GUEST
WHOAMI	Get current logged user	NO	M	GUEST
Status Commands				
GETENGSTATUS	Get actual engine status	NO	M	GUEST
SGETENG	Return the activated engines number	NO	S	GUEST
SGETERR	Return detailed error information	NO	M+S	GUEST
SGETSN	Return FlashRunner serial number	NO	M	GUEST
SGETVER	Get version	NO	M	GUEST
SGETVERALGO	Return driver version	NO	M	GUEST

Command Syntax	Description	Scriptable	Type	Permission
SGETVERALGOLIST	Get entire driver list with version	NO	M	GUEST
SPING	Ping instrument	NO	M	GUEST
RSTENGSTATUS	Reset engine status	NO	M+S	GUEST
Dynamic Memory Commands				
DYNMEMCLEAR	Clears dynamic memory	YES	S	GUEST
DYNMEMCLEARHEADER	Clears dynamic memory crypto header	YES	S	GUEST
DYNMEMSETHEADER	Defines dynamic data crypto header	YES	S	GUEST
DYNMEMSET <start addr> <len> <data> <data> ...	Defines dynamic data	YES	S	GUEST
DYNMEMSET2 <start addr> <len> <data stream>	Defines dynamic data	YES	S	GUEST
DYNMEMSETW <start addr> <len> <data> <data> ...	Defines dynamic data (word addressing)	YES	S	GUEST
DYNMEMSETW2 <start addr> <len> <data stream>	Defines dynamic data (word addressing)	YES	S	GUEST
FRB Management Commands				
FRBREADCRC	Read stored FRB CRC value	NO	M+S	GUEST
License Management				
LISTLIC	Returns licenses list	NO	M	GUEST
LISTLICAM	Returns Active Module installed license list	NO	S	ADMIN
LICERASE	Erases all Active Module licenses	NO	S	ADMIN
LICINSTALL	Install a license in an Active Module	NO	S	ADMIN
Target Configuration Commands				
TCSETDEV <dev setting name> <dev setting value>	Sets target device information	YES	S	GUEST
TCSETPAR <par name> <par value>	Sets target device parameter	YES	S	GUEST
LOADDRIVER <driver> <silicon> <family> <device>	Sets target device	YES	S	GUEST
UNLOADDRIVER	Reset target before updating a driver	YES	S	GUEST
RLYCLOSE	Closes the specified relay	YES	S	GUEST

Command Syntax	Description	Scriptable	Type	Permission
RLYOPEN	Opens the specified relay	YES	S	GUEST
VOLTAGEMONITOR <parameter> <value>	Sets working mode of the voltage monitor	YES	S	GUEST
Target Programming Commands				
TPCMD <command> [par1] [par2] ... [parn]	Executes programming command	YES	S	GUEST
TPEND	Ends programming sequence	YES	S	GUEST
TPSETDUMP <filename>	Sets data destination	YES	S	GUEST
TPSETSRC <filename>	Sets data source	YES	S	GUEST
TPSTART	Starts programming sequence	YES	S	GUEST
TPUNSETSRC	Unsets data source	YES	S	GUEST
Script Execution Commands				
RUN <script file>	Executes the specified script	NO	S	GUEST
Pseudo commands				
ENGINE	Select an engine	YES	S	
ENGINEMASK	Select an engine subset	YES	S	
CRC	CRC calculation	YES	S	

4.4 Command Reference

Each FlashRunner command is listed alphabetically and explained in the following pages.

The following conventions are used in the documentation of FlashRunner commands:

- Uppercase text indicates a command name or a command option that must be entered as shown.
E.g. `SGETVER`
- Lowercase text between `<>` indicates a command parameter name.
E.g. `TPSETDUMP <filename>`
- Lowercase text between `[]` indicates an optional command parameter.
E.g. `TPCMD <command> [par1] [par2] ... [parn]`
- A vertical bar indicates a choice between two or more command options.
E.g. `TPCMD MASSERASE F|E|C`

Please note that, except from examples, all the commands are provided without the `#<ch>*` prefix.

4.4.1 CRC

Command syntax:

CRC <crc>

Scriptable: No

Available on: Site engines

Parameters:

crc: crc value

Answer data:

Success: none.

Error: the error code.

Description:

Set the CRC value of the precedent TCSETDEV section. The value can be take from the project CRC pseudocode. This command can be used by the customer when he is using the DLLs to each command one by one.

Example:

#1*CRC 0x47546395

4.4.2 CLRERR

Command syntax:

CLRERR

Scriptable: No

Available on: Master and site engines

Parameters:

None.

Answer data:

Success: none.

Error: none.

Description:

Clears the error stack.

Example:

```
#55*CLRERR
```

```
55|>
```

4.4.3 CLRLOG

Command syntax:

CLRLOG

Scriptable: No

Available on: Master engine only

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

Clears the log file.

Example:

#55*CLRLOG

4.4.4 DELAY

Command syntax:

DELAY <ms>

Scriptable: Yes

Available on: Site engines only

Parameters:

ms: milliseconds to wait

Answer data:

Success: none.

Error: the error code.

Description:

Insert a <ms> delay between FlashRunner operations.

Example:

```
#1*DELAY 2000
```

```
1|>
```

4.4.5 DYNMEMCLEAR

Command syntax:

```
DYNMEMCLEAR <start addr> <len>
```

Scriptable: Yes

Available on: Site engines only

Parameters:

start addr: (optional) address of the dynamic memory to start clearing data to.
len: (optional) bytes number to clear.

Answer data:

Success: none.
Error: the error code.

Description:

Clears the data set on the dynamic memory area. In case no parameters are set, then all dynamic memory is cleared.

Example:

```
#1*DYNMEMCLEAR  
01|>
```

```
#1*DYNMEMCLEAR 0x0 0x10  
01|>
```

4.4.6 DYNMEMCLEARHEADER

Command syntax:

DYNMEMCLEARHEADER

Scriptable: Yes

Available on: Site engines only

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

Clears the crypto header of the dynamic data. All dynamic data sent after this command are meant to be unencrypted until another crypto header is set.

Example:

```
#1 *DYNMEMCLEARHEADER  
01 |>
```

4.4.7 DYNMEMSET

Command syntax:

```
DYNMEMSET <start addr> <len> <data_0> ... <data_n>
```

Scriptable: Yes

Available on: Site engines only

Parameters:

start addr: address of the target device to start writing data to.
len: bytes number to write (max. 16).
data: bytes to write.

Answer data:

Success: none.
Error: the error code.

Description:

Writes **len** bytes to the dynamic memory starting at address **addr**. For devices which defines size in words (check it out on Memory Map tool of FlashRunner WorkBench), see the command DYNMEMSETW. Dynamic memory is a special memory area (embedded in the FlashRunner electronics) which is typically used for storing temporary, variable data (e.g. serial numbers) before programming it to the target device. Dynamic memory retains its contents only as long as FlashRunner is powered. Both hexadecimal and decimal digits are accepted. More DYNMEMSET can be sent defining different memory areas. Please refer to chapter 6 for a detailed description.

Example:

```
#1*DYNMEMSET 0x0000 4 0x00 0x01 0x02 0x03
01|>
```

Note: Address 0x00 -> value 0x00
Address 0x01 -> value 0x01
...

4.4.8 DYNMEMSET2

Command syntax:

DYNMEMSET2 <start addr> <len> <data stream>

Scriptable: Yes

Available on: Site engines only

Parameters:

start addr: address of the target device to start writing data to.
len: number of bytes to write, max 500 (see below).
data stream: bytes stream to write defined by hexadecimal digits.

Answer data:

Success: none.
Error: the error code.

Description:

Writes **len** bytes to the dynamic memory starting at address **addr**.
Devices which defines size in words (check it out on Memory Map tool of FlashRunner WorkBench), see the command DYNMEMSETW2.
Dynamic memory is a special memory area (embedded in the FlashRunner electronics) typically used for storing temporary, variable data (e.g. serial numbers) before programming it to the target. Dynamic memory retains its contents only as long as FlashRunner is powered. More DYNMEMSET can be sent defining different memory areas.
Like all commands, the maximum number of characters for a line is 1024. This means that, depending on the first part of the command, **len** cannot be higher than 500.
Please refer to chapter 6 for a detailed description.

Example:

```
#1*DYNMEMSET2 0x0000 4 AB123402
01|>
```

Note: Address 0x00 -> value 0xAB
Address 0x01 -> value 0x12
...

4.4.9 DYNMEMSETHEADER

Command syntax:

DYNMEMSETHEADER <crypto header>

Scriptable: Yes

Available on: Site engines only

Parameters:

crypto header: bytes stream of the crypto header to use to decrypt the dynamic data defined by hexadecimal digits. The crypto header is 768 digits long (384 bytes).

Answer data:

Success: none.
Error: the error code.

Description:

Sets the crypto header of the dynamic data. All dynamic data sent after this command are meant to be encrypted until the crypto header is cleared.

Example:

```
#1*DYNMEMSETHEADER
736ADE84C5A1B1D9D27749E1D01ED3C67895170B5461243A2D7
71BA6E8E655C907551C306D1CCCC99445159EB21324D543E051
0C2C7783D332E7F36283E55097F2A8681C5C4D890573F890005
83504C47F9FC1BE9457F88D236A7720C5E5996A6E50AD524715
F997992D513F12409B29BADA6EE736CF201D56FDF1BF5965B3
7F91CBFD1992E9FB2BFE0D7804EA45DF417EB8FEF20DF88A740
E8C435D35E8540680DF2C7D5F3778E35903DE7E1F055B1B2CDC
E52F3FE73FE97952467E85D5B890957CE31DDB58D446E8BFFF0
6343ACBAFB0B51A74B43782889EBA49B9E795FB656B197D2169
E8105435EE54E6EE42801DC9C1F422AB90AE237AAD35D6BAD4C
D398ABC3BF6DF97ACB42106B02A996128E2B4065421308F209C
88AEEC2A72CF8CF95BBEC2C87A226B40B8D6257FF00D0EFC61F
A686B4E61CC319DD317FCF9C9376A6467D1AD1BA9B505A1F62A
580B974AC7397172D10130896E032D6491F8CFF1040EFD06FAA
```

2A8E228C323284141AB8A601998148B0AC8871416A727083D3E
93D
01|>

4.4.10 DYNMEMSETW

Command syntax:

DYNMEMSETW <start addr> <len> <data_0> ... <data_n>

Scriptable: Yes

Available on: Site engines only

Parameters:

start addr: address of the target device to start writing data to.
len: words number to write (max. 16).
data: words to write.

Answer data:

Success: none.
Error: the error code.

Description:

Writes **len** words to the dynamic memory starting at address **addr**. This command is only for devices which defines size in words (check it out on Memory Map tool of FlashRunner WorkBench), for other devices see the command DYNMEMSET. More DYNMEMSET can be sent defining different memory areas.
Please refer to chapter 6 for a detailed description.

Example:

```
#1*DYNMEMSETW 0x0000 4 0x2301 0x6745 0xAB89 0xEFCD  
01|>
```

Note: Address 0x00 -> value 0x01
Address 0x01 -> value 0x23
...

4.4.11 DYNMEMSETW2

Command syntax:

DYNMEMSETW2 <start addr> <len> <data stream>

Scriptable: Yes

Available on: Site engines only

Parameters:

start addr: address of the target device to start writing data to.
len: number of words to write (See the description below for the maximum value supported).
data stream: words stream to write defined by hexadecimal digits.

Answer data:

Success: none.
Error: the error code.

Description:

Writes **len** words to the dynamic memory starting at address **addr**. This command is only for devices which defines size in words (check it out on Memory Map tool of FlashRunner WorkBench), for other devices see the command DYNMEMSET2. More DYNMEMSET can be sent defining different memory areas.

Like all commands, the maximum number of characters for a line is 1024. This means that, depending on the first part of the command, **len** cannot be higher than 500.

Please refer to chapter 6 for a detailed description.

Example:

```
#1*DYNMEMSETW2 0x0000 4 0123456789ABCDEF
01|>
```

Note: Address 0x00 -> value 0x01
Address 0x01 -> value 0x23
...

4.4.12 ECHO

Command syntax:

ECHO <string>

Scriptable: Yes

Available on: Site engines only

Parameters:

<string>: the string to ECHO

Answer data:

Success: the string.

Error: the error code.

Description:

ECHO the whole command on the log and on the terminal. The maximum length of the command is 1024 characters.

Example:

```
#1*#ECHO This is a dummy string.  
01|#1*ECHO This is a dummy string.  
01>
```

4.4.13 FRBREADCRC

Command syntax:

FRBREADCRC

Scriptable: No

Available on: Master and site engines

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

Calculates CRC of the previously set FRB file. CRC value is calculated based on every FRB byte. Must be preceded by TPSETSRC command

Example:

```
#1*#TPSETSRC 128_512.frb
01>
#1*FRBREADCRC
01|CE95C071
01>
```

4.4.14 FSCRC

Command syntax:

FSCRC <type> <filename>

Scriptable: No

Available on: Master engine only

Parameters:

type: filetype you want to analyse: could be PRJ, LIB, FRB, LIC or LOG.
filename: file to be used to calculate the CRC32.

Answer data:

Success: the CRC32 value.
Error: the error code.

Description:

Calculate and return the CRC32 of a file.

The settings used to calculate the CRC32 are:

- Input reflected = off;
- Result reflected = off;
- Initial value = 0;
- Final xor value = 0.

For FRB files it just read the value from its header.

Example:

```
#55*FSCRC LIB libdefault.so
55|CRC = 0x39153D78
55|>
```

4.4.15 FSEXIST

Command syntax:

FSEXIST <type> <filename>

Scriptable: No

Available on: Master engines only

Parameters:

type: filetype you want to check: could be PRJ, LIB, FRB, LIC or LOG.
filename: file to retrieve.

Answer data:

Success: none.
Error: the error code.

Description:

Check if a file of a specific file type does exist in FlashRunner storage memory or not.

Example:

```
#55*FSEXIST PRJ test.prj
55|>
```

4.4.16 FSGETCONTROL

Command syntax:

FSGETCONTROL

Scriptable: No

Available on: Master engine only

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

Retrieves the read value from the lines belonging to control connector.

Example:

```
#55*FSGETCONTROL
55|Start line read value is: 1
55|Control lines read value is: 31
55|>
```

4.4.17 FSLS

Command syntax:

FSLS <type>

Scriptable: No

Available on: Master engine only

Parameters:

type: directory you want to list: could be PRJ, LIB, FRB, LIC or LOG..

Answer data:

Success: the current directory contents.

Error: the error code.

Description:

Lists the contents of the current directory in the FlashRunner and their size in bytes.

Example:

```
#55*FSLS PRJ
55|ATXMEGA128A4.prj - 1019
55|teridian.prj - 770
55|atxmega.prj - 1036
55|test.prj - 1067
55|>
```

4.4.18 FSLS2

Command syntax:

FSLS2 <type>

Scriptable: No

Available on: Master engine only

Parameters:

type: directory you want to list: could be PRJ, LIB, FRB, LIC or LOG..

Answer data:

Success: the current directory contents.
Error: the error code.

Description:

Lists the contents of the current directory in the FlashRunner, their size in bytes and the timestamp (GMT) of their last change.

Example:

```
#55*FSLS PRJ
55|ATXMEGA128A4.prj - 1019 - 743849183
55|teridian.prj - 770 - 1334997983
55|atxmega.prj - 1036 - 1348562783
55|test.prj - 1067 - 1569746783
55|>
```

4.4.19 FSRM

Command syntax:

FSRM <type> <filename>

Scriptable: No

Available on: Master engine only

Parameters:

type: filetype you want to remove: could be PRJ, LIB, FRB, LIC or LOG..

filename: file to remove.

Answer data:

Success: none.

Error: the error code.

Description:

Removes a file stored in the host system to FlashRunner.

The user can also use the "*" character as filename, this will remove all files from the selected folder.

To remove the log file, please use the command CLRLOG.

Example:

```
#55*FSRM PRJ test.prj
55|>
```

4.4.20 FSSETCONTROL

Command syntax:

FSSETCONTROL <signal name> <signal value>

Scriptable: No

Available on: Master engine only

Parameters:

signal name: could be BUSY|CH1|CH2...|CH16.

signal value: could be OFF|ON for BUSY signal or
OFF|PASS|FAIL for CH1...|CH16 channels.

Answer data:

Success: none.

Error: the error code.

Description:

Sets a signal belonging to control connector to a defined value.
PASS is low logic level, FAIL is high logic level.

Example:

```
#55* FSSETCONTROL CH1 PASS
55|>
```

4.4.21 GENCRYPTOKEY

Command syntax:

GENCRYPTOKEY

Scriptable: No

Available on: Site engines only

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

Generates the private and public keys used for the encryption and decryption process.

This operation requires up to one minute to be executed.

In case another pair of keys were already present, they will be overwritten and all the data encrypted with the old keys cannot be decrypted anymore.

Example:

```
#55* GENCRYPTOKEY
```

```
55|>
```

4.4.22 GETAVGVPROG

Command syntax:

GETAVGVPROG <Vprog_idx>

Scriptable: No

Available on: Site engine only

Parameters:

Vprog_idx: 0 for the VPROG0, 1 for the VPROG1

Answer data:

Success: current date.
Error: the error code.

Description:

Returns the average value of the VPROG selected. It has to be combined with the VOLTAGEMONITOR commands to enable the voltage monitoring.

Example:

```
#1*GETAVGVPROG 0
01|Average Voltage VPROG0: 3300mV
01|>
```

4.4.23 **GETCOUNTER**

Command syntax:
GETCOUNTER

Scriptable: No

Available on: Master engine only

Parameters:
None.

Answer data:
Success: none.
Error: the error code.

Description:
Returns current flash counter status. That number represents remaining flashing cycles available in **GUEST** mode.

Example:
#55*GETCOUNTER
55|16
55|>

4.4.24 GETDATE

Command syntax:

GETDATE

Scriptable: No

Available on: Master engine only

Parameters:

None.

Answer data:

Success: current date.
Error: the error code.

Description:

Returns the current date set on FlashRunner.
Date format is <sec> <min> <hour> <date> <month> <year>.
<hour> is in 24-hour time format settings.

Example:

```
#55*GETDATE
55|current date: 8 4 15, 18.39.22
55|>
```

4.4.25 GETENGSTATUS

Command syntax:

GETENGSTATUS

Scriptable: No

Available on: Site engine only

Parameters:

None.

Answer data:

Success: the average voltage of the selected VPROG.

Error: the error code.

Description:

Returns the actual engines status. The answer is composed by 16 characters, one for each channel starting from left, and value could be "P", "R", "F" or "-". "P" character stays for PASS status and means that last programming on this channel passed successfully. "R" character stays for RUN status and means that channel is still executing commands. "F" character stays for FAIL status and means that last programming on this channel failed, "-" character means that on this product, this channel is not enabled. At power up state, there is one more status, represented by "_" character, which means "idle state", so selected channel never executed any command since power up.

Example:

```
#55*GETENGSTATUS
```

```
55|P_____
```

```
55|>
```

4.4.26 GETFREEMEM

Command syntax:

GETFREEMEM

Scriptable: No

Available on: Master engine only

Parameters:

None.

Answer data:

Success: memory usage details.

Error: the error code.

Description:

This command shows memory usage details.

Total size doesn't correspond to the SD memory, it's just the size of the partition dedicated to the user data.

Usable memory is the amount of memory available considering that the log.txt file can reach at maximum 200MB. If the log file reaches that size, then it's cropped and the oldest logs are removed.

Example:

```
#55*GETFREEMEM
55|Total size: 1356.6 MB
55|Memory used: 677.1 MB
55|Memory free: 609.5 MB
55|Percentage: 53%
55|log.txt size: 0.9 MB
55|Usable memory: 410.3 MB
55|>
```

4.4.27 GETIP

Command syntax:

GETIP

Scriptable: No

Available on: Master engine only

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

Returns FlashRunner IP address, network and gateway

Example:

```
#55*GETIP
55|IP: 192.168.1.137
Netmask: 255.255.255.0
Gateway: 192.168.1.1
55|>
```

4.4.28 GETLOGLEVEL

Command syntax:

`GETLOGLEVEL`

Scriptable: No

Available on: Master and site engines

Parameters:

None.

Answer data:

`level:` log verbosity level. It's a number within [1-6] range

Description:

Returns the log verbosity level. Lower numbers mean more verbosity on log file.

Example:

```
#55*GETLOGLEVEL
55|1
55|>
```

4.4.29 GETPROGRESSBAR

Command syntax:

GETPROGRESSBAR <channel_num>

Scriptable: No

Available on: Master engine only

Parameters:

channel_num: number of the channel to get the progress bar.

Answer data:

Success: operation and progress percentage.

Error: the error code.

Description:

Returns the progress percentage of the running operation of program/verify for the selected memories by the command PROGRESSBAR. See chapter 11 for more details.

Example:

```
#55*GETPROGRESSBAR 2
```

```
55|PROGRAM F: 1%
```

```
55|>
```

4.4.30 GETPUBKEY

Command syntax:

GETPUBKEY

Scriptable: No

Available on: Site engines only

Parameters:

None.

Answer data:

Success: public key.
Error: the error code.

Description:

Returns the public key that must be used to encrypt data that can be decrypted only by that specific FlashRunner.

In case the crypto keys haven't been created yet, an error is returned.

Example:

```
#55*GETPUBKEY
55|Public key not available. Please, use #GENCRYPTOKEY
first
55|0200002F!
```

```
#55*GETPUBKEY
55|-----BEGIN PUBLIC KEY-----
MIIBOjANBgkqhkiG9w0BAQEFAAOCAQY8AMIIBigKCAYEAgceuZhUirL4gI
FXvFMTU
MwycQIgWgFrytplUbI9t4RpL+SKIEqcqZkPOBJ2HLoEgKfhQlsEst8btG
AxWgjgi
hwSeRZ/sFcYfNBq+MLm+Hvft0QRDDEKY0mh4cafJlBs8GUdGo1/pli6p1
33haIip
aaGQrsOArTt/5TMNIGEYwEx/SUbsks4SX5Dj4CWhijqmL/PQhq9p2XqL2
9TMDxtN
mJ2f/DrXHaUWrUCe6tgxCc2zt3h3ZBLaVEPs+Ntf7UtvKIRC7fmeUr9hD
z4QrOoV
60gLMorDX3zmVGqEh6GpcWYQPGcKt/v8ZeKklqdFc3h3jJma21h9E4+2R
/zRerzO
oE/h7+GGbw5uT+rFxT0iFXmchnEaCSfPmHEL8k/h6q4R8KaM9bEbGT2VD
```

```
R336saK
1nN4OfLSyx4x2kffc7WKuDpZDuwpRiNOX4tW6Mxg6VvEfBHGkvt5nqPBu
5PdmIIC
iscTdZoH3PZ87C5EuJIPDjG7P6aQSYZBlIFYTVdVbJf1AgMBAAE=
-----END PUBLIC KEY-----
55|>
```

4.4.31 GETVPROG

Command syntax:

GETVPROG <vprog line>

Scriptable: No

Available on: Site engines only

Parameters:

vprog line: vprog line to read for the selected channel. Could be 0|1.

Answer data:

Success: current voltage read value.
Error: the error code.

Description:

Returns the read value for the selected VPROG line in mV.

Example:

```
#1*GETVPROG 0
01|VPROG0=50
01|>
```

4.4.32 HELP

Command syntax:

HELP <lib_name.so>

Scriptable: No

Available on: Site engines only

Parameters:

lib_name.so: library name for which help table has to be shown

Answer data:

Success: help table.
Error: the error code.

Description:

Returns help table, which contains commands description

Example:

```
#1*HELP libpic16.so
TPCMD MASSERASE <F|E|C>
TPCMD ERASE <F> <start_addr> <size>
TPCMD BLANKCHECK <F|E|I|W> or BLANKCHECK <F|E|I|W>
<start_addr> <size>
TPCMD PROGRAM <F|E|I|W> or PROGRAM <F|E|I|W>
<start_addr> <size>
TPCMD VERIFY <F|E|I|W> <R> or VERIFY <F|E|I|W> <R>
<start_addr> <size>
TPCMD READ <F|E|I|W> <start_addr> <size>
TPCMD DUMP <F|E|I|W> <start_addr> <size>
TPCMD RUN or TPCMD RUN <delay(sec)>
TPCMD CONNECT
TPCMD DISCONNECT
01|>
```

4.4.33 ISMEMENOUGH

Command syntax:

ISMEMENOUGH <size_kB>

Scriptable: No

Available on: Master engine only

Parameters:

size_kB: Size (kB) of memory to be checked if it is available

Answer data:

Success: YES or NO.

Error: the error code.

Description:

Returns YES or NO if the size of memory asked is available.

Attention: the parameter must be expressed in kilobytes.

Example:

```
#55*ISMEMENOUGH 1024
```

```
YES
```

```
55|>
```

```
#55*ISMEMENOUGH 1048576
```

```
NO
```

```
55|>
```

4.4.34 ISPANELMODE

Command syntax:

ISPANELMODE

Scriptable: No

Available on: Master engine only

Parameters:

None.

Answer data:

Panel mode: the status of panel mode. It can be ON, OFF, 2, 3 or 4.

Description:

Returns the status of panel mode.

Example:

```
#55*ISPANELMODE
55|PANEL MODE OFF
55|>
```

```
#55*ISPANELMODE
55|PANEL MODE 2
55|>
```

4.4.35 LICERASE

Command syntax:

LICERASE

Scriptable: No

Available on: Site engines only

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

This command is available only on FlashRunner HS model.
It erases Active Module currently installed licenses.

Example:

```
#1*LICERASE
```

```
1|>
```

4.4.36 LICINSTALL

Command syntax:

LICINSTALL <license filename>

Scriptable: No

Available on: Site engines only

Parameters:

license filename: license file or can be '*'

Answer data:

Success: none.
Error: the error code.

Description:

This command is available only on FlashRunner HS model. It installs new licenses into an Active Module. Active Module is selected by sending this command to the Active Module related channel. Before applying this command you need first to download license file into FlashRunner related folder using Advanced File manager.

Example:

```
#1*LICINSTALL MTFC128GAP.lic  
1|>
```

4.4.37 LISTLIC

Command syntax:

LISTLIC

Scriptable: No

Available on: Master engines only

Parameters:

Answer data:

Success: license list.
Error: the error code.

Description:

Returns the stored license list.

Example:

```
#55*LISTLIC
*****
R7F7010274.lic
License type: DEVICE. Only R7F7010274 is activated
Serial Number: 20027
Creation Date: 14.04.2016
Expiration Date: 9999/12/31
Algorithm Name: librh850.so
Manufacturer: RENESAS
Device Code: R7F7010274
*****
STM32F103CB.lic
License type: DEVICE. Only STM32F103CB is activated
Serial Number: 20058 20059
Creation Date: 21.06.2018
Expiration Date: 9999/12/31
Algorithm Name: CORTEX
Manufacturer: STMICROELECTRONICS
Device Code: STM32F103CB
*****
55|>
```

LISTLICAM

Command syntax:

LISTLICAM

Scriptable: No

Available on: Site engines only

Parameters:

Answer data:

Success: Active Module license list.
Error: the error code.

Description:

This command is available only on FlashRunner HS model. Returns Active Module stored license list. You can only install licenses matching Active Module serial number

Example:

```
#2*LISTLICAM
#0: ADESTO - AT25Q - AT25QL641 - SERMEM4
02|>
```

4.4.38 LOADDRIIVER

Command syntax:

```
LOADDRIVER <driver name> <silicon name> <family name>  
<device name>
```

Scriptable: Yes

Available on: Site engines only

Parameters:

driver name: driver filename which supports the selected device.
silicon name: silicon producer name which supports the selected device.
family name: family name which supports the selected device.
device name: name of the selected device.

Answer data:

Success: none.
Error: the error code.

Description:

Load the driver and check the license.

Example:

```
#1*#LOADDRIVER libfsl_e.so STMICROELECTRONICS SPC58  
SPC584B70  
01|>
```

4.4.39 LOGIN

Command syntax:

LOGIN <user> <password>

Scriptable: No

Available on: Master engine only

Parameters:

user: username, you can choose between ADMIN|GUEST
password: GUEST has dummy password (any value accepted), ADMIN has dummy password until changed with SETADMINPWD command

Answer data:

Success: none
Error: the error code

Description:

Login a user, which has different command set enabled.

Example:

```
#55*LOGIN ADMIN applepie
55|>
```

4.4.40 LOGOUT

Command syntax:

LOGOUT

Scriptable: No

Available on: Master engine only

Parameters:**Answer data:**

Success: none

Error: none

Description:

It exits from ADMIN account and get back to GUEST account

Example:

```
#55*LOGOUT
```

```
55|>
```

4.4.41 PROGRESSBAR

See chapter 11 for more details.

Command syntax:

PROGRESSBAR ON <mem_type> <end_addr>

Scriptable: Yes

Available on: Site engines only

Parameters:

mem_type: the memory to monitor (i.e: F, C, D...)
end_addr: address to stop the monitoring.

Answer data:

Success: the program/verify progress is monitored.
Error: the error code.

Description:

It enables the monitoring of the program/verify process for the selected memories. It has to be used in combination with the DLL. With the new DLL in C# the user has to establish a connection with the port <FR_ip>:1236 where the FR will write the progress of the programming. From the DLL side it is necessary to open an FR_Logger and to read the communication in order to extract the programming/verify progress. With the old DLL in C, the user can use the command GETPROGRESSBAR.

Command Example:

```
#2*PROGRESSBAR ON F 0x100000  
02|>
```

4.4.42 REBOOT

Command syntax:

REBOOT

Scriptable: No

Available on: Master engine only

Parameters:

Answer data:

Success: none

Error: the error code

Description:

Reboot FlashRunner.

Example:

```
#55*REBOOT
```

```
55|>
```

4.4.43 RLYCLOSE

Command syntax:

RLYCLOSE

Scriptable: Yes

Available on: Site engines only

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

Drives related channel signal on the Relay control connector in order to close the circuit. Putting this command inside a project will drives signals related to channel subset defined by **ENGINEMASK** pseudo-command.

Example:

```
#1*RLYCLOSE
```

```
01|>
```

4.4.44 RLYOPEN

Command syntax:

RLYOPEN

Scriptable: Yes

Available on: Site engines only

Parameters:

None.

Answer data:

Success: none.
Error: the error code.

Description:

Drives related channel signal on the Relay control connector in order to open the circuit. Putting this command inside a project will drives signals related to channel subset defined by ENGINEMASK pseudo-command.

Example:

```
#1*RLYOPEN  
01|>
```

4.4.45 RUN

Command syntax:

`RUN <project name>`

Scriptable: Yes

Available on: Site engines only

Parameters:

`project name:` project filename to run.

Answer data:

Success: none.

Error: the error code.

Description:

Starts a project stored inside FlashRunner and defined by its filename. When running a project on a channel not included in the project, the command will be successfully executed, but you see a warning message into the log because nothing is actually done by that channel.

Example:

```
#1*RUN test.prj
01|>
```

4.4.46 RSTENGSTATUS

Command syntax:

RSTENGSTATUS

Scriptable: No

Available on: Master and site engines

Parameters:

Answer data:

Success: none.

Error: none.

Description:

Reset engine status internal value.

Sending it to the master will reset all engine statuses, while sending it to a single site engine will just reset that single engine status

Example:

```
#55*RSTENGSTATUS
```

```
55|>
```

4.4.47 SETADMINPWD

Command syntax:

SETADMINPWD <password>

Scriptable: No

Available on: Master engines only

Parameters:

password: new password for ADMIN user

Answer data:

Success: none.

Error: none.

Description:

Set up new password value for ADMIN user. This command is available only if you are logged as ADMIN account.

Example:

```
#55*SETADMINPW <password>
55|>
```

4.4.48 SETCOUNTER

Command syntax:

SETCOUNTER <n cycles>

Scriptable: No

Available on: Master engine only

Parameters:

n_cycles: number of allowed cycles.

Answer data:

Success: none.

Error: the error code.

Description:

Set up a flash counter. After it is set, GUEST mode will have **n_cycles** flashing cycles allowed. To stop it just use **n_cycles = 0**

Example:

```
#55*SETCOUNTER 10
55|Counter has been successfully set. It will be
active when logged in GUEST user.
55|>
```

4.4.49 SETDATE

Command syntax:

SETDATE <sec> <min> <hour> <date> <month> <year>

Scriptable: No

Available on: Master engine only

Parameters:

sec:	set seconds.
min:	set minutes.
hour:	set hours in 24-hour time format.
date:	set date.
month:	set month.
year:	set year (last two digits).

Answer data:

Success:	none.
Error:	the error code.

Description:

Sets the current date on FlashRunner.
Date format is <sec> <min> <hour> <date> <month> <year>.
<hour> is in 24-hour time format settings.

Example:

```
#55*SETDATE 51 46 21 30 11 15
55|>
```

4.4.50 SETDIO

Command syntax:

SETDIO <DIO_num> <logic_state> <reference_mV>

Scriptable: Yes

Available on: Site engine only

Parameters:

DIO_num: the number which indicates the DIO, from 0 to 7.
logic_state: 1 to indicate high level, 0 to indicate low level, H to indicate high impedance.
reference_mV: the voltage expressed in mV to be used as reference for high level. This parameter is optional if VPROG0 has been already set.

Answer data:

Success: none.
Error: the error code.

Description:

Sets the current DIO to output at the indicated voltage level. This command, for example, can be used to keep in reset a device during the programming.

In case the parameter **reference_mV** isn't set and VPROG0 hasn't been previously set, this command returns an error.

Otherwise, if the parameter **reference_mV** is set and VPROG0 has been previously set, the new voltage value is ignored.

In any case, this command doesn't enable the output of VPROG0 line, unless it has been previously enabled.

Attention: this command can cause problems if used for DIO lines controlled by the driver.

Moreover, the driver may remove the setting during the #TPSTART, for this reason should be placed after it if used in a script.

Example:

From terminal set to high DIO7:

```
#1*SETDIO 7 1 3300  
01|>
```

In the script, i.e. to keep in reset a device during the programming:

```
#TPSTART  
#SETDIO 7 1 3300  
#TPCMD CONNECT
```

4.4.51 SETIP

Command syntax:

SETIP <IP> <netmask> <gateway>

Scriptable: No

Available on: Master engine only

Parameters:

IP: new programmer IP address.
netmask: new programmer netmask.
gateway: new programmer gateway.

Answer data:

Success: none.
Error: the error code.

Description:

Sets the new network settings for LAN peripheral. Once executed, you must reboot FlashRunner in order to enable new settings.

Example:

```
#55*SETIP 192.168.1.128 255.255.255.0 192.168.1.1  
55|>
```

4.4.52 SETLOGLEVEL

Command syntax:

SETLOGLEVEL <level>

Scriptable: No

Available on: Master and site engines

Parameters:

level: log verbosity level. It's a number within [1-6] range

Answer data:

Success: none.

Error: the error code.

Description:

Sets the log verbosity level. Lower numbers mean more verbosity on log file.

Example:

```
#55*SETLOGLEVEL 1
55|>
```

4.4.53 SETMUX

Command syntax:

SETMUX <level>

Scriptable: No

Available on: Master engine only

Parameters:

level: 0 to isolate all outputs, 1 to enable first bank, 2 to enable second bank.

Answer data:

Success: none.
Error: the error code.

Description:

Sets demultiplexer. "0" value will isolate all outputs, "1" will enable the first bank and "2" value will enable the second bank. This command is used only in combination with Demultiplexer tool, available only for FlashRunner 16 channel version.

Example:

```
#55*SETMUX 1
55|>
```

4.4.54 SETPANELMODE

Command syntax:

SETPANELMODE <level>

Scriptable: No

Available on: Master engine only

Parameters:

level: 0 to work in standard mode, 1 to enable panel mode, 2 to enable eMMC 8bit mode, 3 to enable NAND mode, 4 to enable NOR mode

Answer data:

Success: none.
Error: the error code.

Description:

Enable panel mode. If programmer works in panel mode you could only load a single communication protocol for all channels. For eMMC 8bit, NAND and NOR this setting is necessary in order to program this kind of devices.

Example:

```
#55*SETPANELMODE 1
55|>
```

4.4.55 SGETENG

Command syntax:

`SGETENG`

Scriptable: No

Available on: Site engines only

Parameters:

None.

Answer data:

Success: none.

Error: the error code.

Description:

Returns the engine instance number for the requested engine.

Example:

```
#1*SGETENG
```

```
01|Engine N. 0>
```

4.4.56 SGETERR

Command syntax:

SGETERR

Scriptable: No

Available on: Master and site engines

Parameters:

None.

Answer data:

Success: the error code stack.

Error: none.

Description:

Returns the error stack related to the last error occurred on the selected engine.

Each line follows the rule:

ERR--><err num>|<desc>|[<src file>,<line num>,<func>]

Example:

```
#1*SGETERR
01|ERR-->05000007|(null)|[file ../Src/pi-
algo_api_rw.c, line 165, funct API_FrbSet()]
01|ERR-->05000007|(null)|[file ../Src/pi-algo.c,
line 350, funct cmd_TPSETSRC()]
01|ERR-->05000007|(null)|[file ../Src/cli-cmd.c,
line 305, funct cmd_RUN()]
01|>
```

4.4.57 SGETSN

Command syntax:

SGETSN

Scriptable: No

Available on: Master engine only.

Parameters:

None.

Answer data:

Success: the product serial number.
Error: none.

Description:

Returns the product serial number.

Example:

```
#55*SGETSN
55|1
55|>
```

4.4.58 SGETVER

Command syntax:
SGETVER

Scriptable: No

Available on: Master engine only.

Parameters:
None.

Answer data:
Success: The Operating System version.
Error: none.

Description:
Returns the Operating System version.

Example:
#55*SGETVER
55|2.31
55|>

4.4.59 SGETVERALGO

Command syntax:

SGETVERALGO

Scriptable: No

Available on: Site engine only.

Parameters:

None.

Answer data:

Success: algorithm version.

Error: none.

Description:

Returns the version of the driver indicated as parameter. Usually answer is a 3-digit number: 2 less significant are minor release, the other one is the major release

Example:

```
#1*SGETVERALGO libsermem.so
01|04.02
01|>
```

4.4.60 SGETVERALGOLIST

Command syntax:

SGETVERALGOLIST

Scriptable: No

Available on: Master engine only.

Parameters:

None.

Answer data:

Success: driver version list

Error: none.

Description:

Returns driver version of all drivers stored inside programmer. Usually answer is a 3-digit number: 2 less significant are minor release, the other one is the major release

Example:

```
#55*SGETVERALGOLIST
55|libsermem.so - 04.02
55|libinf_c.so - 02.03
55|libatxmega.so - 02.00
55|>
```

4.4.61 SHA256

Command syntax:

SHA256 <type> <filename>

Scriptable: Yes

Available on: Master and Sites engines.

Parameters:

type: PRJ | LIB | FRB | LIC | LOG | PRJ_FRB
file: filename for which you want to calculate SHA256

Answer data:

Success: calculated SHA256value.
Error: the error code.

Description:

Returns the calculated SHA256 of the selected file.
If you choose **PRJ_FRB** type, first it returns the SHA256 of the PRJ file selected, then it returns the SHA256 for all FRBs defined inside the project.

Example:

1.

```
#55*SHA256 FRB 1MB.frb
55|1MB.frb
bd69c6afcdec157f287c85849e1eeea684b02cb6e901d0424a8
fd5fb67393b98
55|>
```

2.

```
#55*SHA256 PRJ_FRB example.prj
55|example.prj
3e2399f4521a09e3226d3fa205f0c3eff48815537d1c79921a7
9b9349b7e1879
55|2MB.frb
bd961b1e6aa3395c990cc71dc2ab84260edef12ced7f712e1c1
a23f3df3a168b
55|>
```

4.4.62 SHUFFLEDIO

Command syntax:

SHUFFLEDIO <logic_DIO> <physical_DIO>

Or

SHUFFLEDIO <phys0->DIOx> ... <phys7->DIOx>

Scriptable: Yes, after the #TPSTART and before the #CONNECT

Available on: Site engine only

Parameters:

logic_DIO: the number which indicates the logical DIO, from 0 to 7, to move.

physical_DIO: the number which indicates the physical DIO, from 0 to 7, where to move logical DIO selected.

<phys0->DIOx>: the logical DIO wanted in the corresponding physical position.

Answer data:

Success: none.

Error: the error code.

Description:

With the first command syntax, the logical DIO selected is swapped with the logical DIO in the physical DIO selected.

With the second syntax is possible to set the whole DIO map with a single command. On first position there is the physical DIO-0 and the user has to insert the desired logical DIO. On second position there is the physical DIO-1... and so on.

Each logical DIO must have a unique physical position. In case this is not true, the DIO map is reset to the default value.

The DIO map is reset to the default value at the #TPEND.

Example:

1. Move the logical DIO-3 in the physical DIO-7. The logical DIO on physical DIO-7 is moved in the physical DIO-3.

```
#1*SHUFFLEDIO 3 7
01|>
```

The new DIO map of the example above is:

```
#1*SHUFFLEDIO_GETMAP
01|DIO MAP: 0 1 2 7 4 5 6 3
01|>
```

2. Set the whole new DIO map:

```
#1*SHUFFLEDIO 0 2 5 3 4 7 1 6
01|>
```

The new DIO map of the example above is:

```
#1*SHUFFLEDIO_GETMAP
01|DIO MAP: 0 2 5 3 4 7 1 6
01|>
```

4.4.63 SHUFFLEDIO_GETMAP

Command syntax:

SHUFFLEDIO_GETMAP

Scriptable: Yes

Available on: Site engine only

Parameters: None.

Answer data:

Success: The pinout.
Error: the error code.

Description:

Show the actual Pin Map of the channel selected of the FlashRunner. The first position indicates for the physical DIO-0 the corresponding logical DIO. The second position indicates for the physical DIO-1 the corresponding logical DIO... and so on. The logical DIO-8 is the watchdogfeed DIO.

Example:

```
#1*SHUFFLEDIO_GETMAP
01|DIO MAP: 0 2 5 3 4 7 1 6
01|>
```

In the example above we have:

1. On physical DIO-0 the logical DIO-0.
2. On physical DIO-1 the logical DIO-2.
3. On physical DIO-2 the logical DIO-5
4. On physical DIO-3 the logical DIO-3
5. On physical DIO-4 the logical DIO-4
6. On physical DIO-5 the logical DIO-7
7. On physical DIO-6 the logical DIO-1
8. On physical DIO-7 the logical DIO-6

4.4.64 **SPING**

Command syntax:

SPING

Scriptable: No

Available on: Master engine only.

Parameters:

None.

Answer data:

Success: **SPONG.**

Error: the error code.

Description:

Pings the instrument. Used to verify whether FlashRunner is connected to the host system and running correctly.

Example:

```
#55*SPING
```

```
55|SPONG
```

```
55|>
```

4.4.65 TCSETDEV

Command syntax:

TCSETDEV <par name> <par value>

Scriptable: Yes

Available on: Site engines only.

Parameters:

par name: parameter name.

par value: parameter value.

Answer data:

Success: none.

Error: the error code.

Description:

Sets device-specific and programming algorithm-specific device information. This command must be sent after the **LOADDRIVER** command and before a **TPSTART** / **TPEND** command block. Please note that CRC pseudo command is a CRC number based on TCSETDEV data and is used to prevent device info tampering. For this reason, you can't calculate the CRC but you only can copy it from a working project done with FlashRunner WorkBench software.

Example:

```
#1*TCSETDEV VDDMIN 1600
01|>
```

4.4.66 TCSETPAR

Command syntax:

TCSETPAR <par name> <par value>

Scriptable: Yes

Available on: Site engines only.

Parameters:

par name: parameter name.

par value: parameter value.

Answer data:

Success: none.

Error: the error code.

Description:

Sets device-specific and programming algorithm-specific device parameter. This command must be sent after the **LOADDRIVER** command and before a **TPSTART** / **TPEND** command block.

Example:

```
#1*TCSETPAR PWDOWN 20
01|>
```

4.4.67 TESTVPROG

Command syntax:

TESTVPROG <vprog line> <mV> <output>

Scriptable: No

Available on: Site engines only.

Parameters:

vprog line: vprog line to read for the selected channel. Could be 0|1.
mV: mV to set in output on selected vprog line for the selected channel.
output: defines if selected vprog line is in output or only defined internally as high reference value. Could be ON|OFF.

Answer data:

Success: ok.
Error: none.

Description:

Sets up a defined value on vprog lines.

Example:

```
#1*TESTVPROG 0 3300 ON  
01|>
```

4.4.68 TPCMD

Command syntax:

TPCMD <command> [par1] [par2] ... [parn]

Scriptable: Yes

Available on: Site engines only.

Parameters:

command: programming command.
par: zero or more programming command parameters.

Answer data:

Success: programming command specific.
Error: the error code.

Description:

Performs a programming operation (i.e. mass erase, program, verify, etc.) This command must be sent within a **TPSTART/TPEND** command block. Programming commands and their relative parameters are device-specific.

Example:

```
#1*TPCMD PROGRAM F  
01|>
```

4.4.69 **TPEND**

Command syntax:

TPEND

Scriptable: Yes

Available on: Site engine only.

Parameters:

Success: none.
Error: the error code.

Answer data:

Success: the product serial number.
Error: none.

Description:

Ends a programming block. This command must be preceded by a **TPSTART** command. **TPCMD** commands must be sent within a **TPSTART/TPEND** command block.

TPSTART / **TPEND** command block must be preceded by the **TCSETPAR** commands required for your specific target device. The **TPEND** command resets any previously set device-specific and programming algorithm-specific parameters.

Example:

```
#1*TPEND  
01|>
```

4.4.70 TPSETDUMP

Command syntax:

TPSETDUMP <filename>

Scriptable: Yes

Available on: Site engines only.

Parameters:

filename Name of the dump file

Answer data:

Success: none
Error: the error code.

Description:

Setup the filename which will be created on FlashRunner storage memory once **TPCMD DUMP** command will be executed. As FlashRunner executes the same project on several channels, each channel will have its own dump file. For this reason, on filename indicated with this command FlashRunner will apply prefix "**S<chN>_**", where chN is the channel number to which dump refers. Dump file are raw binary files

Example:

```
#1*TPSETDUMP dumpfile.bin  
01|>
```

4.4.71 TPSETSRC

Command syntax:

TPSETSRC <filename> **IGNORE_BLANK_PAGE**

Scriptable: Yes

Available on: Site engines only.

Parameters:

filename: name of the file in the binaries folder inside FlashRunner

IGNORE_BLANK_PAGE: optional parameter, avoid to program FRB pages which are filled with the blank value

Answer data:

Success: none.

Error: the error code.

Description:

Sets the source of data to be programmed and verified in subsequent **TPCMD** commands.

The user can also use "DYNMEM" as filename, this special keyword will set the FlashRunner to use only dynamic memory instead of an FRB file.

The maximum length of <filename.frb> is 40 characters.

Example:

```
#1*TPSETSRC test.frb
01|>
```

4.4.72 TPSTART

Command syntax:

TPSTART

Scriptable: Yes

Available on: Site engines only.

Parameters:

None.

Answer data:

Success: none.
Error: the error code.

Description:

Starts a programming block. To end a programming block, send the **TPEND** command. **TPCMD** commands must be sent within a **TPSTART/TPEND** command block.

The **TPSTART** command performs some internal initializations and prepares FlashRunner to execute subsequent **TPCMD** commands.

Example:

```
#01*TPSTART
01|>
```

4.4.73 TPUNSETSRC

Command syntax:
TPUNSETSRC

Scriptable: Yes

Available on: Site engines only.

Parameters:
None.

Answer data:
Success: none.
Error: the error code.

Description:
Unsets the source of data to be programmed and verified in subsequent **TPCMD** commands.

Example:
#1*TPUNSETSRC
01|>

4.4.74 UNLOADDRIVER

Command syntax:
UNLOADDRIVER

Scriptable: Yes

Available on: Site engines only

Parameters:
None.

Answer data:
Success: none.
Error: the error code.

Description:
Unload the driver to remove dependencies before updating the driver.

Example:
#1*#UNLOADDRIVER
01|>

4.4.75 VOLTAGEMONITOR

Reference: For detailed information refer to chapter 10.

Command syntax:

```
VOLTAGEMONITOR <parameter>
VOLTAGEMONITOR <parameter> <value>
```

Scriptable: Yes

Available on: Site engines only

Parameters:

parameter:	OFF	<i>pause monitoring</i>
value:	none.	-
parameter:	ON	<i>start/resume monitoring</i>
value: (*)	ERROR_EXIT	<i>exit operations on error</i>
value:	ERROR_CONTINUE	<i>log and continue</i>
parameter:	DYN_SAMPLE	<i>dynamic sampling mode</i>
value: (*)	ENABLED	<i>based on currently active channels</i>
value:	DISABLED	<i>constant sampling rate</i>
parameter:	READ_AVERAGE	<i>print both VPROG0 and VPROG1 Average Values.</i>
value:	VPROG0	<i>print the selected line</i>
	VPROG1	<i>print the selected line</i>
parameter:	CLEAR_AVERAGE	<i>reset both VPROG0 and VPROG1 average values</i>
value:	VPROG0	<i>clear the selected line</i>
	VPROG1	<i>clear the selected line</i>

(*) default value, if a parameter is omitted

Answer data:

Success:	none.
Error:	the error code.

Description:

Voltage monitor is enabled by default setting **VPROG** (x) limits:

```
#1*TCSETPAR PROG0LIMITS 50 0 0
```

```
#1*TCSETPAR PROG1LIMITS 100 0 0
```

- Threshold value must be greater than 1% of **VPROG**
- All the described parameters below can be omitted.

Example:

```
#1*VOLTAGEMONITOR DYN_SAMPLE ENABLED      *default
01|>
#1*VOLTAGEMONITOR DYN_SAMPLE DISABLED      user choice
01|>
#1*VOLTAGEMONITOR ON_ERROR_CONTINUE        log the error
01|>
#1*VOLTAGEMONITOR CLEAR_AVERAGE           reset values
01|>                                     for both lines
#1*TPCMD MASSERASE F
Time for Masserase [...]
01|>
#1*VOLTAGEMONITOR READ_AVERAGE            print average
01|>                                     for MASSERASE
#1*VOLTAGEMONITOR OFF                     no monitoring
01|>
#1*TPCMD BLANKCHECK F
Time for Blankcheck [...]
01|>
#1*VOLTAGEMONITOR ON_ERROR_EXIT            exit if error
01|>                                     is detected
#1*VOLTAGEMONITOR CLEAR_AVERAGE          reset values
01|>
#1*TPCMD PROGRAM F
Time for Program [...]
01|>
#1*VOLTAGEMONITOR READ_AVERAGE            print average
01|>                                     for PROGRAM
```

4.4.76 WATCHDOGFEED

Command syntax:

```
WATCHDOGFEED <frequency> <DIO_num> <duty_cycle>
[<reference_mV>]
```

Scriptable: Yes, between #TPSTART and #CONNECT

Available on: Site engine only

Parameters:

frequency: the square wave frequency in output.
DIO_num: the number which indicates the DIO, from 0 to 7.
duty_cycle: duty cycle of the square wave.
reference_mV: the voltage expressed in mV to be used as reference for high level. This parameter is optional and if not set the voltage would be the same set for the programming.

Answer data:

Success: Prints the actual frequency of the square wave.
Error: the error code.

Description:

Sets the selected DIO as output with a square wave of the indicated duty cycle and frequency.

If the **reference_mV** isn't set and VPROG0 hasn't been previously set, the square wave won't be enabled until the programming flow enables it (i.e. during the connect). Otherwise, if the VPROG0 has been previously set, the **reference_mV** is ignored.

This command doesn't enable the output of VPROG0 line, it only enables the output of the square wave on the DIO selected.

Attention: this command can cause problems if used for DIO lines controlled by the driver, please check the PinMap of the driver.

The square wave is turned off at the #TPEND command. The user can turn off it manually setting the frequency to 0. It's important to use the same DIO in the command to restore properly the pinout.

Example:

Turn on the square wave:

```
#1*WATCHDOGFEED 50 7 50 3300
01|Requested WD frequency: 50 - Actual: 50
01|>
```

Turn off the square wave. Physical DIO-7 returns to be the logic DIO-7:

```
#1*WATCHDOGFEED 0 7 50 3300
01|>
```

Script example, the wave starts in connect when there is the power on:

```
#TPSTART
#WATCHDOGFEED 50 5 50
#TPCMD CONNECT
```

Script example, the wave starts before the connect:

```
#TPSTART
#WATCHDOGFEED 50 5 50 3300
#TPCMD CONNECT
```

4.4.77 WHOAMI

Command syntax:

WHOAMI

Scriptable: Yes

Available on: Master engine only

Parameters:

None.

Answer data:

Success: Prints enabled modes and current logged user.
Error: the error code.

Description:

It returns enabled modes and current logged user.

Example:

```
#55*WHOAMI
Active users listed below. User currently logged is
highlighted with * symbol:
    ADMIN
-> GUEST
55|>
```

5 Projects

Projects are sequences of commands collected in a text file. This is a handy way to store all the target device information and user settings needed to FlashRunner. Projects are usually created with the Project Wizard tool (see ch 3.7 for more information) and stored in the user data path folder. Once created, a project could be edited with any text editor. Please check the example below:

```
;Project generated by "FlashRunner 2.0 WorkBench 2.02"

;DEVICE: ATXMEGA32E5
;DRIVER: ATXMEGA 01.07

!ENGINEMASK 0x0000FFFF
#LOADDRIVER libatxmega.so ATMEL ATXMEGA ATXMEGA32E5
#TCSETDEV VDDMIN 1600
#TCSETDEV VDDMAX 3600
#TCSETDEV FOSCMIN 0
#TCSETDEV FOSCMAX 0
#TCSETDEV FPLLMIN 0
#TCSETDEV FPLLMAX 0
#TCSETDEV MCUID 0x2918
#TCSETDEV IDCODE 0x00000000
#TCSETDEV IDCODE_MSK 0x0FFFFFFF
#TCSETDEV CORE ATXMEGA
#TCSETDEV MEMMAP 0 F 0 0x00800000 0x00808FFF 0x00000080
0x00000080 0 0 0x0 0x0 0xFF 0x0 0
#TCSETDEV MEMMAP 1 E 0 0x008C0000 0x008C03FF 0x00000020
0x00000020 0 0 0x0 0x0 0xFF 0x0 0
#TCSETDEV MEMMAP 2 U 0 0x008E0400 0x008E040F 0x00000001
0x00000001 0 0 0x0 0x0 0xFF 0x0 0
#TCSETDEV MEMMAP 3 C 0 0x008E0200 0x008E020F 0x00000001
0x00000001 0 0 0x0 0x0 0xFF 0x0 0
#TCSETDEV MEMMAP 4 L 0 0x008F0020 0x008F002F 0x00000001
0x00000001 0 0 0x0 0x0 0xFF 0x0 0
!CRC 0x25CDA0E6
```

```

#TCSETPAR PROCLK 15000000
#TCSETPAR PWDOWN 100
#TCSETPAR PWUP 100
#TCSETPAR RSTDOWN 100
#TCSETPAR RSTDRV OPENDRAIN
#TCSETPAR RSTUP 100
#TCSETPAR VPROG0 3300
#TCSETPAR CMODE PDI
#TPSETSRC vipcb6_test.frb
#DYNMEMSET 0x8E0400 7 0x00 0xFF 0xFF 0xFF 0xFF 0xFF 0x00
#TPSTART
#TPCMD CONNECT
#TPCMD MASSERASE C
#TPCMD BLANKCHECK F
#TPCMD PROGRAM F
#TPCMD VERIFY F R
#TPCMD BLANKCHECK E
#TPCMD PROGRAM E
#TPCMD VERIFY E R
#TPCMD PROGRAM U
#TPCMD PROGRAM L
#TPCMD DISCONNECT
#TPEND

```

The example above shows a simple project example that configures a channel subset for a target device. There could be more than one target device configured inside the same project, requiring another commands block (starting with !ENGINEMASK and finishing with #TPEND) which defines the new target device settings. The channel subset involved for a specific target device is defined by !ENGINEMASK command: the following number will bitwise define channels involved.

Each number in base 2 defines one channel, starting from less significative. Number value (1 or 0) defines if the channel is selected or not. For example, !ENGINEMASK 0x1A, equals to 00011010 in binary and it means that channels 2, 4 and 5 are selected.

The following section will define the target device (through #LOADDRIVER) and all the specific device information (through

#TCSETDEV command). This section will be closed by !CRC command: this number will prevent from altering the information above which contain sensitive data and would compromise the programming operation.

The next section is composed mainly of #TCSETPAR and #TPSETSRC commands, which defines a set of user-defined parameters (the result of Project Wizard settings). These commands are editable and order doesn't matter.

The last section is enclosed between #TPSTART and #TPEND commands and defines which operation will be executed on the target device. These commands are editable, the order does matter and we suggest not changing it once Project Wizard will compile this file.

Commands related to single memory types have the double syntax:

#TPCMD PROGRAM F

Will program automatically memory type areas defined by loaded FRB file.

#TPCMD PROGRAM F 0x0 0x100

Will program memory type areas defined by command parameters above. Target start address is 0x0, length 0x100. If loaded FRB doesn't contain any data in this area target device will not be programmed.

Usually double syntax is available for **PROGRAM**, **VERIFY**, **BLANKCHECK** commands.

5.1 Execution and Termination


5.1.1 Standalone project execution

FlashRunner 2.0 has a control connector, a group of control lines (SEL[4..0] in the “CONTROL” Connector, for hardware details please refer to FlashRunner 2.0 User's Manual) determines in binary logic a decimal number from 0 to 31 which will execute project named project0.prj....project31.prj.

The event that triggers script execution is the START control line becoming active (while the BUSY line is not active). This line can be easily driven by the ATE control logic.

When FlashRunner 2.0 begins executing a project, “BUSY” LED turns on.

The following diagram illustrates the typical temporal relations between the various FlashRunner 2.0 control lines.



5.1.2 Remote projects execution

Additionally, projects can be manually executed in host mode. **RUN** command (see ch 4.4.45) executes a specified project.

5.1.3 Projects Termination

Project execution ends either after FlashRunner 2.0 has executed the last project command or immediately after the first failing project command.


5.2 Project-Specific Directives

FlashRunner commands contained in a project are executed sequentially, exactly as they would be executed in Host mode. However, projects contain additional directives (not available in Host mode) indicated with “!” prefix which controls how projects are executed. The following table lists these directives. Each directive is valid from its line forward.

Directive Syntax	Description
ENGINEMASK	Defines bitwise which channels are involved for the following command section
CRC	Calculate CRC of the preceding commands to avoid specific target device data altering.

5.3 Logging

On FlashRunner, project command execution is logged. You can check at the runtime log file (see ch 6) or download the log file just by clicking the quick button on the top toolbar.



5.4 Comments

A project line may contain a comment. A comment line starts with the “;” character, FlashRunner will completely ignore that line and so can be used as a comment.

5.5 Conditional scripting

With the aim of raising the flexibility and the customization of projects, FlashRunner implements low level commands able to control the flow of the script’s commands.

The syntax used gets back to classical programming languages and shall be immediately clear to all the users who are familiar with them, because it reproduces *if, then, else* statement.

In fact, in “C” programming language control flow syntax is as follows:

```
if (expression)
    statement1
else
    statement2
```

where the else part is optional. The expression is evaluated; if it is true (that is if the *expression* has a non-zero value), statement₁ is executed. If it is false (the expression is zero) and if there is an else part, statement₂ is executed instead.¹

In FlashRunner the same goal can be achieved using the syntax below inside any project file:

```
#IFERR expression
#THEN statement1
```

¹ “The ANSI C Programming Language” 2nd ed., Brian W. Kernighan and Dennis M. Ritchie, Prentice Hall

in which *expression* is **TRUE** when the command returns “>” character (meaning that command has been executed successfully), or it is **FALSE** if the command returns an error (with correspondent error code).

Notes:

1. Please note that syntax above can be used only inside a script file and it's not recognized on the command line
2. Control flows can't be nested
3. Only one *expression* can be evaluated
4. Multiple *statements* can be executed for each case
5. If *expression* evaluation returns false, the error stack will be traced in the log file. Anyway, if all the subsequent commands will return “>”, the project will not return with an execution error.
6. A syntax error will be returned in case the script has two consecutive IFERR, or if there is an IFERR without a THEN or vice versa.

Example:

The following example is an extract from a script where the MASSERASE operation is carried out only if blank check operation returns an error, that is the device to be programmed is not blank.

```
#IFERR TPCMD BLANKCHECK F  
#THEN TPCMD MASSERASE F
```

With this approach it is often possible to reduce project execution time. This technique applies mostly to conditioning target device memory-erasing only if BLANKCHECK fails.

It is also possible to include a second statement to perform the BLANKCHECK operation one more time, just in case the first one failed. In this way it's possible to be sure that MASSERASE worked, while two operations are skipped if the first BLANKCHECK doesn't fail.

```
#IFERR TPCMD BLANKCHECK F  
#THEN TPCMD MASSERASE F  
#THEN TPCMD BLANKCHECK F
```

Please refer to your driver-specific commands before implementing conditional scripting it in your projects.

5.6 Standard TCSETPAR

Common TCSETPAR are here explained to allow the user to edit the project manually without using the Wizard:

- **CMODE:** name of the communication protocol
- **PROTCLK:** frequency of the communication
- **PWDOWN:** ms used to power up the board
- **PWUP:** ms used to power down the board
- **RSTDOWN:** us waited to reset-down the board
- **RSTUP:** us waited to reset-up the board
- **RSTDRV:** reset drive management. PUSH_PULL or OPENDRAIN.
- **VRPOG0:** voltage level of the VPROG0, it is also the logical voltage of DIO signals.
- **VPROG1:** voltage level of the VPROG1.
- **FOSC:** frequency of the external oscillator of the device
- **FPLL:** frequency of the PLL of the device

6 Serial Numbering

6.1 Introduction

Thanks to its built-in dynamic memory, FlashRunner provides you with the possibility of serial numbering during programming operations. During each programming cycle, a host system generates a serial number and transfers it to FlashRunner's dynamic memory. The content of the dynamic memory is then programmed into the target device.

6.2 Command syntax

The following example illustrates how serial numbering can be performed.

Let's assume that the serial number is composed of 4 bytes, must be programmed into target device connected to channel 1, flash starting from address 0x400, and that serial number to be programmed is 0x55 0xAA 0x22 0xFE (0x55 at address 0x400, 0xAA at address 0x401 ... and so on).

Host system transfers this serial number to FlashRunner's dynamic memory with the following command:

```
#1*DYNMEMSET 0x400 4 0x55 0xAA 0x22 0xFE
```

or with the following command:

```
#1*DYNMEMSET2 0x400 4 55AA22FE
```

And FlashRunner will apply this "patch" over FRB data. You can define more than one patch, virtually without limits (physical limit

is FlashRunner 1 GB RAM), but defined data is 16 bytes for `DYNMEMSET`, and a total of 512 bytes for the entire `DYNMEMSET2` command.

You can overwrite data which have been previously set in the same addresses, FlashRunner will automatically remove what has been previously set and write the new data. Anyway, we suggest using the command `DYNMEMCLEAR` to clear all data before setting new data.

6.3 Example

```
...
#TCSETPAR RSTUP 100
#TCSETPAR VPROG0 3300
#TCSETPAR CMODE JTAG
#TPSETSRC APH_U27_varD.frb
#DYNMEMSET 0xA0604020 4 0x39 0x30 0x41 0x46
#DYNMEMSET 0xA06040A0 3 0x44 0x48 0x31
#TPSTART
#TPCMD CONNECT
#TPCMD MASSERASE D
#TPCMD BLANKCHECK D
#TPCMD PROGRAM D
#TPCMD VERIFY D R
#TPCMD MASSERASE F
#TPCMD BLANKCHECK F
#TPCMD PROGRAM F
#TPCMD VERIFY F R
#TPCMD DISCONNECT
#TPEND
```

APH_U27_varD.frb must contains defined region at start address 0xA0604020 for 10 bytes size and 0xA06040A0 for 8 bytes size. If your source file doesn't cover this region please use FRB Manager (see ch 3.15) to define it (use Advanced FRB setup feature → Add → Variable data option).

Once defined, this data will be programmed overwriting FRB original data, together with PROGRAM command in a single step. Typically, DYNMEMSET command is not contained inside a project but it's sent manually from connected PC host; after that PC host can run the project with RUN command: FlashRunner will remember DYNAMIC data table until DYNMEMCLEAR command execution or FlashRunner power-on reset.



Note: *until #DYNMEMCLEAR command, dynamic data will be maintained during the project execution loop*

6.4 Word Addressing

Most devices don't need this kind of commands, in fact, this section is reserved for the devices which have a word addressed memory.

If you intend to use dynamic memory with them, you shouldn't use the standard commands described in the previous sections because they use byte addressing. You must use the following commands which are specifically developed for this case (as before, 0x55 at address 0x200, 0xAA at address 0x401 ... and so on):

```
#1*DYNMEMSETW 0x200 2 0xAA55 0xFE22
```

or with the following command:

```
#1*DYNMEMSETW2 0x200 2 55AA22FE
```

These commands are extremely similar to the standard ones, just pay attention to the length which is in words and to the endianness.

6.5 Using dynamic memory without FRB

Sometimes it is useful to have a very flexible solution, without using a dummy FRB just to define the addresses of memory where to set dynamic data. That's why you can directly set the dynamic memory as the source instead of an FRB file:

```
#TPSETSRC DYNMEM
```

Below you can see an example where we program and verify only the 12 bytes defined into the dynamic memory, without needing to generate any additional FRB file.

```
#TPSETSRC DYNMEM
#DYNMEMSET2 0x400120 12 E03912343484568078809A73
#TPSTART
#TPCMD CONNECT
#TPCMD PROGRAM F
#TPCMD VERIFY F R
#TPCMD DISCONNECT
#TPEND
```

7 Data Protection System

7.1 User management

User management lets users switch between two modes: Administrator mode and GUEST mode. This mechanism allows administrators to prepare FlashRunner unit with all the required settings and then drop-down privileges and allow GUESTs to limited functionalities preventing settings modifications in such settings.

ADMIN mode is enabled to execute all commands, while GUEST mode will enable only specific commands. If you want to know which commands are enabled for GUESTs please check out chapter 4.3 commands table and check XXX column.

By default, FlashRunner comes with only ADMIN mode activated. If you want to enable GUEST mode, you need first to create an ADMIN password. You can do this by using SETADMINPWD described in chapter 4.4.

```
#LOGIN ADMIN
```

```
#SETADMINPWD <new_password>
```

Once done, please remember that after reboot FlashRunner will start in GUEST mode.

If you want to disable GUEST mode and reset FlashRunner to default you just need to execute SETADMINPWD with no password value.

You can see in which state FlashRunner is by using WHOAMI command. You can easily switch between users by using LOGIN / LOGOUT commands.

7.2 FRB encryption

Each FRB could be encrypted using the FlashRunner Workbench tool (See ch 3.9).

This feature will produce a new file, with .frs extension, which is the encrypted version of the original file. New .frs file can't be encrypted anymore outside of the specified FlashRunner.

To use it, please, upload .frs to FlashRunner (using Advanced File Manager, see ch 3.10) and change #TPSETSRC filename extension on the related project, finally upload the project to FlashRunner.

To transfer public keys from a computer to another one, you have to connect the FlashRunner to the first computer and go to the “Cyber Security” tab on the “Firmware Encryption” section. From there you can press the button “Get Public Key” to obtain the public key of your FlashRunner, then press the button “Export public keys” to generate a “pubKeys.frk” file containing all the public keys memorized by that computer.

On the second computer, while following the procedure to encrypt the firmware, you will be asked to choose the SN of the FlashRunner and, from that window, you can click the “Import public keys” button to import the “pubKeys.frk” file.

See also:

- [#GENCRYPTOKEY](#)
- [#GETPUBKEY](#)

7.2.1 FRS performances

The use of Encrypted FRB (.FRS) introduces a data elaboration activity respect to a standard FRB file increasing flashing cycle times.

Other factors as:

1. Communication protocol
2. Structure of the data inside the FRS file
3. Communication frequency
4. Code flow of the driver

can influence it up to +25% for 8 TriCore devices.

7.3 Dynamic data encryption

Dynamic data (such as passwords, serial numbers and other keys that are different for each target) can be encrypted as well using the same method used to encrypt FRB.

After encrypting these data, they can only be decrypted by the specific FlashRunner selected while encrypting them.

The data can be encrypted using the DLLs. See [chapter 8](#) for more details.

See also:

- [#DYNMEMSETHEADER](#)
- [#DYNMEMCLEARHEADER](#)

7.4 OS Certification

Starting from version 3.19 the procedure of installation of the OS changes and to downgrade (or upgrade) you have to use the new certified versions.

The previous certificated versions of the OS (starting from 3.17 included) can be downloaded from our website in the OS changelog page that can be found in the Wiki section.

For older versions than OS 3.17, please contact directly our Support Team ([T:+39 0434 421111](tel:+390434421111) or support@smh-tech.com).

8 FlashRunner Interface Library

8.1 Overview

This chapter deals with interfacing FlashRunner with PC applications written by the user. This chapter assumes you have already read the previous sections of this manual and got acquainted with the instrument.

8.2 FlashRunner Interface Library Overview

FlashRunner Interface Library is a DLL which includes all of the functions that allow you to set up a communication channel with the instrument and send commands to FlashRunner.

Dynamic-link libraries (DLL) are modules that contain functions and data. A DLL is loaded at run time by its calling modules (.exe or .dll). When a DLL is loaded, it is mapped into the address space of the calling process.

FlashRunner Interface Library contains Visual C++ written routines (version 1.0.x.x) that can be used to interface the instrument from within, for example, a Microsoft Visual C++ or Visual Basic application, as well as any other programming language that supports the DLL mechanism.

It also contains a Visual C# written COM Interop class library (version 2.0.x.x) that can be used to interface the instrument not only with the above mentioned IDEs but also with Visual C#, Visual C++ CLI applications and graphical programming environments such as, for example, LabVIEW and TestStand.

For details on how to call DLL functions from within your application, please refer to your programming language's documentation.

8.3 Installation

Before to start working with the FlashRunner Interface Library, you must set up your system with all the required files and drivers. The files to be installed, into your application's directory, are:

For version 1.0:

- The **"FR_COMM.dll"** (this file must also be redistributed with your application);
- For Visual C++ only: the **"FR_COMM.lib"** and **"FR_COMM.h"** files (you must include these files in your project);
- For Visual Basic only: the **"FR_COMM.bas"** file (you must include this file in your project).

For version 2.0:

- **"FR_COMM_x86.dll"** or **"FR_COMM_x64.dll"** (these files must also be redistributed with your application);
- **"FR_COMM_x86.tlb"** or **"FR_COMM_x64.tlb"** (these files become necessary only for plain C++ applications requiring COM Interop functionalities. These files must also be redistributed with your application);
- **.NET Runtime Library 3.5** (or higher) is requested for this new version of Interface Library to work.

These files are automatically installed by the System Software setup (in your installation path).

8.4 Interface Library Reference (version 1.0)

8.4.1 Using the Interface Library Functions

When you control FlashRunner within your own application, you will typically follow the steps indicated below:

- **Open a communication channel with the instrument.**
The `FR_OpenCommunication()` function must be called prior to any other Interface Library function.
- **Send commands to the instrument and read answers back.**
Use the `FR_SendCommand()` and `FR_GetAnswer()` functions to send a command and receive the answer sent back by the instrument, respectively.
As the very first command, the user should always call a SPING command to check the communication and, optionally, also the SGETSN command to check that the connection has been established with the correct FlashRunner.
- **Transfer files to/from FlashRunner.**
Two dedicated functions, `FR_SendFile()` and `FR_GetFile()`, allow you to transfer a file from the PC to FlashRunner and vice-versa, respectively.
The `FR_SendFile()` function is typically used to upload a binary file to the instrument, while the `FR_GetFile()` function is typically used to download a log file to the PC.
- **Close the communication channel with the instrument.**
This is done by the `FR_CloseCommunication()` function.

8.4.2 Return Values of the Interface Library Functions

Most of the FlashRunner Interface Library functions return an `unsigned long` value which indicates whether the function was successfully executed (return value = 0) or not (return value other than 0). In the latter case it is possible to get extended error information by calling the function `FR_GetLastErrorMessage()`.

8.4.3 Unicode Functions

Every Interface Library function comes in two versions, an ASCII version and a Unicode version. ASCII function names end with A, while Unicode function names end with W. For example, the `FR_SendCommand()` function is available as an ASCII version as:

```
FR_COMM_ERR    WINAPI    FR_SendCommandA    (FR_COMM_HANDLE
handle, const char *command);
```

and as a Unicode version as:

```
FR_COMM_ERR    WINAPI    FR_SendCommandW    (FR_COMM_HANDLE
handle, const wchar_t *command);
```

8.4.4 Application examples

Application examples for Visual C and Visual Basic are provided in the local installation path.

8.4.5 FR_OpenCommunication

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_HANDLE WINAPI FR_OpenCommunicationA
    (const char *port,
     const char *settings);

FR_COMM_HANDLE WINAPI FR_OpenCommunicationW
    (const wchar_t *port,
     const wchar_t *settings);
```

Parameters:

port: communication port. Must be "**LAN**" for Ethernet communication "**COMx**" for USB communication, where "x" is the number of the used port.

settings: IP address and port for Ethernet communication (e.g. "192.168.1.100:1234"), baudrate for USB (e.g. "115200")

Return value:

>0: handle of the communication.

NULL: an error occurred. Call the function **FR_GetLastErrorMessage()** to get extended error information.

Description:

Creates a communication link with the instrument. Returns a communication handle that must be used by successive FlashRunner Interface Library function calls.

Note:

After opening communication, the user should always call a SPING command to check the communication and, optionally, also the SGETSN command to check that the connection has been established with the correct FlashRunner.

8.4.6 FR_CloseCommunication

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_ERR WINAPI FR_CloseCommunicationA  
    (FR_COMM_HANDLE handle);  
FR_COMM_ERR WINAPI FR_CloseCommunicationW  
    (FR_COMM_HANDLE handle);
```

Parameters:

handle: handle of communication. This is the value returned by the `FR_OpenCommunication()` function.

Return value:

0: the function was successful.
Other than 0: an error occurred. Call the `FR_GetLastErrorMessage()` function to get extended error information.

Description:

Closes the communication link with the instrument.

8.4.7 FR_GetAnswer

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_ERR WINAPI FR_GetAnswerA
    (FR_COMM_HANDLE handle,
     char *answer,
     unsigned long maxlen,
     unsigned long timeout_ms);

FR_COMM_ERR WINAPI FR_GetAnswerW
    (FR_COMM_HANDLE handle,
     wchar_t *answer,
     unsigned long maxlen,
     unsigned long timeout_ms);
```

Parameters:

handle:	handle of communication. This is the value returned by the FR_OpenCommunication() function.
answer:	the buffer that will receive the answer (\0 terminated) of the instrument.
maxlen:	maximum number of characters to receive (must be less than or equal to the answer buffer length).
timeout_ms:	timeout, in milliseconds, after which the function returns even if a complete answer has not been received.

Return value:

0:	the function was successful.
Other than 0:	an error occurred. Call the function FR_GetLastErrorMessage() to get extended error information.

Description:

Receives the answer sent by FlashRunner to the PC, in response to the **FR_SendCommand()** function. A **FR_GetAnswer()** function should always follow a **FR_SendCommand()** function.

8.4.8 FR_GetFile

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_ERR WINAPI FR_GetFileA
    (FR_COMM_HANDLE handle,
     const char *protocol,
     const char *src_filename,
     const char *dst_path,
     const char *filetype,
     FR_FileTransferProgressProc
     progress);

FR_COMM_ERR WINAPI FR_GetFileW
    (FR_COMM_HANDLE handle,
     const wchar_t *protocol,
     const wchar_t *src_filename,
     const wchar_t *dst_path,
     const wchar_t *filetype,
     FR_FileTransferProgressProc
     progress);
```

Parameters:

handle:	handle of the communication. This is the value returned by the <code>FR_OpenCommunication()</code> function.
protocol:	transfer protocol. Must be "YMODEM".
src_filename:	name of the file to be retrieved from FlashRunner, e.g. "test.prj.
dst_path:	local path where to save the file.
filetype:	could be FRB PRJ LIC LOG LIB .
progress:	address of a callback function which will receive the progress status of the file transfer operation. If not used, set this parameter to NULL.

Return value:

0:	the function was successful.
----	------------------------------

Other than 0: an error occurred. Call the function **FR_GetLastErrorMessage()** to get extended error information.

Description:

Retrieves a file from FlashRunner and stores it in a specified local path.

8.4.9 FR_GetLastErrorMessage

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
void WINAPI FR_GetLastErrorMessageA  
    (char *error_msg,  
     unsigned long string_len);  
void WINAPI FR_GetLastErrorMessageW  
    (wchar_t *error_msg,  
     unsigned long string_len);
```

Parameters:

error_msg: buffer that will receive the error message.
string_len: length of the buffer.

Return value:

none.

Description:

Most of the FlashRunner Interface Library functions return an **unsigned long** value which indicates whether the function was successfully executed (return value = 0) or not (return value other than 0). In the latter case it is possible to get extended error information by calling the function **FR_GetLastErrorMessage()** function. After the function is called, the **error_msg** buffer is cleaned

8.4.10 FR_SendCommand

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_ERR WINAPI FR_SendCommandA  
    (FR_COMM_HANDLE handle,  
     const char *command);  
FR_COMM_ERR WINAPI FR_SendCommandW  
    (FR_COMM_HANDLE handle,  
     const wchar_t *command);
```

Parameters:

handle: handle of the communication. This is the value returned by the `FR_OpenCommunication()` function.

command: string containing the FlashRunner command.

Return value:

0: the function was successful.

Other than 0: an error occurred. Call the function `FR_GetLastErrorMessage()` to get extended error information.

Description:

Sends a command to FlashRunner. To get the command answer, use the `FR_GetAnswer()` function.

8.4.11 FR_SendFile

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_ERR WINAPI FR_SendFileA
    (FR_COMM_HANDLE handle,
     const char *protocol,
     const char *src_filename,
     const char *dst_path,
     FR_FileTransferProgressProc progress);

FR_COMM_ERR WINAPI FR_SendFileW
    (FR_COMM_HANDLE handle,
     const wchar_t *protocol,
     const wchar_t *src_filename,
     const wchar_t *dst_path,
     FR_FileTransferProgressProc progress);
```

Parameters:

handle: handle of the communication. This is the value returned by the `FR_OpenCommunication()` function.

protocol: transfer protocol. Must be "YMODEM".

src_filename: name of the file (inclusive of the path) to be sent to FlashRunner, e.g. "C:\\MYBINARIES\\FLASH1.FRB".

dst_path: could be FRB|PRJ|LIC|LOG|LIB.

progress: address of a callback function which will receive the progress status of the file transfer operation. If not used, set this parameter to NULL.

Return value:

0: the function was successful.

Other than 0: an error occurred. Call the function `FR_GetLastErrorMessage()` to get extended error information.

Description:

Sends a file from the PC to a specified path of FlashRunner.

8.4.12 FR_GetPublicKey

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_ERR WINAPI FR_GetPublicKey  
    (FR_COMM_HANDLE handle);
```

Parameters:

handle: handle of the communication. This is the value returned by the **FR_OpenCommunication()** function.

Return value:

0: the function was successful.
Other than 0: an error occurred. Call the function **FR_GetLastErrorMessage()** to get extended error information.

Description:

Get the public key, for internal use of the DLL, for the encryption of the dynamic data. This is like an initialization for the successive **FR_EncryptData()** operations.

8.4.13 FR_EncryptData

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_ERR WINAPI FR_EncryptData
    (FR_COMM_HANDLE handle,
    const unsigned char* data_to_encrypt,
    unsigned int len_data,
    unsigned char* header,
    unsigned char* data_encrypted);
```

Parameters:

handle: handle of the communication. This is the value returned by the `FR_OpenCommunication()` function.

data_to_encrypt: buffer containing the data to encrypt.

len_data: length of the data to encrypt.

header: buffer containing the encrypted header in Hex format. The len is 384 bytes.

data_encrypted: buffer with the data encrypted in Hex format. The len is `len_data` aligned to 16.

Return value:

0: the function was successful.

Other than 0: an error occurred. Call the function `FR_GetLastErrorMessage()` to get extended error information.

Description:

Receive as input a buffer of data (`data_to_encrypt`). Returns the header, in Hex format, to be sent with the `#DYNMEMSETHEADER` command and the data encrypted, in Hex format, to be used with a `#DYNMEMSET` command. Both the `header` and `data_encrypted` buffers have to be converted to ASCII format. The `FR_HexToAsciiStream()` utility can be used for this task.

8.4.14 FR_HexToAsciiStream

Include file:

```
#include "FR_COMM.h"
```

Function prototypes:

```
FR_COMM_ERR WINAPI FR_HexToAsciiStream  
    (const unsigned char* data_hex,  
     unsigned int len_data,  
     char* data_ascii);
```

Parameters:

data_hex:	buffer containing the data in Hex format to be converted to ASCII.
len_data:	the length of the data in input.
data_ascii:	buffer containing the data in ASCII format

Return value:

0:	the function was successful.
Other than 0:	an error occurred. Call the function FR_GetLastErrorMessage() to get extended error information.

Description:

Converts a buffer of Hex values in the corresponding Ascii string. The output (**data_ascii**) has a dimension double of the original buffer (**data_hex**).

8.5 Interface Library Reference (version 2.0)

8.5.1 Using the C# Interface Library Class

When you control FlashRunner within your own application, you will typically follow the steps indicated below:

- **Open a communication channel with the instrument.**
The `FR_OpenCommunication()` method must be called prior to any other Interface Library method.
- **Send commands to the instrument and read answers back.**
Use the `FR_SendCommand()` and `FR_GetAnswer()` methods to send a command and receive the answer sent back by the instrument, respectively.
As the very first command, the user should always call a SPING command to check the communication and, optionally, also the SGETSN command to check that the connection has been established with the correct FlashRunner.
- **Transfer files to/from FlashRunner.**
Two dedicated methods, `FR_SendFile()` and `FR_GetFile()`, allow you to transfer a file from the PC to FlashRunner and vice-versa, respectively.
The `FR_SendFile()` method is typically used to upload a binary file to the instrument, while the `FR_GetFile()` method is typically used to download a log file to the PC.
- **Close the communication channel with the instrument.**
This is done by the `FR_CloseCommunication()` method.

-
- **Open a communication channel with the instrument for real-time logging**

This is done by the `FR_GetLogger()` function and logger read method.

- **Close the communication channel with the instrument for real-time logging**

This is done by the `FR_DisposeLogger()` method.

8.5.2 Return Values of the Interface Library Methods

Most of FlashRunner Interface Library methods return an `FR_COMM_ERRORS` enumerative value which indicates whether the function was successfully executed (return value = `RET_OK`) or not (return value other than `RET_OK`). In the latter case it is possible to get extended error information by calling the `FR_GetLastErrorMessage()` method.

Below a list of actual FR_COMM_ERRORS entries:

```
public enum FR_COMM_ERRORS
{
    RET_OK = 0,
    RET_ERR_INVALID_HANDLE,
    RET_ERR_INVALID_PORT,
    RET_ERR_INVALID_FORMAT,
    RET_ERR_LOGGER_INVALID_FORMAT,
    RET_ERR_INVALID_IP,
    RET_ERR_INVALID_BAUDRATE,
    RET_ERR_OPEN_CHANNEL,
    RET_ERR_CLOSE_CHANNEL,
    RET_ERR_CHANNEL_CLOSED,
    RET_ERR_SEND_BUFFER,
    RET_ERR_GET_BUFFER,
    RET_ERR_RECEIVE_TIMEOUT,
    RET_ERR_SEND_CHAR,
    RET_ERR_GET_CHAR,
    RET_ERR_SEND_COMMAND,
    RET_ERR_GET_ANSWER,
    RET_ERR_SEND_FILE,
    RET_ERR_GET_FILE,
    RET_ERR_YMODEM_SEND,
    RET_ERR_YMODEM_GET,
    RET_ERR_FAST_SEND,
    RET_ERR_FAST_GET,
    RET_ERR_FILE_OPEN,
    RET_ERR_INVALID_DEST_PATH,
    RET_ERR_INVALID_SOURCE_PATH,
    RET_ERR_FILE_NOT_FOUND,
    RET_ERR_EMPTY_FILE,
    RET_ERR_INVALID_COMMAND,
    RET_ERR_UNKNOWN,
    RET_ERR_INVALID_LOGGER,
}
```

8.5.3 Method Reference for FR 2.0

Before calling the methods it is necessary to instantiate a **ComManager** class object. After that it will be possible to use its methods whose descriptions follow.

8.5.4 FR_OpenCommunication

Signature:

```
FR_COMM_ERRORS FR_OpenCommunication  
(out object handle, string port, string settings);
```

Parameters:

handle	handle of the communication.
port:	communication port. Must be " LAN " for Ethernet communication " COMx " for USB communication, where "x" is the number of the used port.
settings:	IP address and port for Ethernet communication (e.g. "192.168.1.100:1234"), baudrate for USB (e.g. "115200")

Return value:

== RET_OK:	the method call was successful..
<> RET_OK:	an error occurred. Call the FR_GetLastErrorMessage() method to get extended error information.

Description:

Creates a communication link with the instrument. If successful it returns as output parameter a communication handle that must be used by successive FlashRunner Interface Library methods calls.

Note:

After opening communication, the user should always call a SPING command to check the communication and, optionally, also the SGETSN command to check that the connection has been established with the correct FlashRunner.

8.5.5 **FR_CloseCommunication**

Signature:

```
FR_COMM_ERRORS FR_CloseCommunication  
(object handle);
```

Parameters:

handle: handle of communication. This is the object obtained by the **FR_OpenCommunication()** method.

Return value:

== RET_OK: the method call was successful.
<> RET_OK: an error occurred.
Call the **FR_GetLastErrorMessage()** method to get extended error information.

Description:

Closes the communication link with the instrument.

8.5.6 **FR_SendCommand**

Signature:

```
FR_COMM_ERROR FR_SendCommand  
(object handle, string command);
```

Parameters:

handle:	handle of the communication. This is the object obtained by the FR_OpenCommunication() method.
command:	string containing the FlashRunner command (carriage return and line feed characters are added by the DLL).

Return value:

== RET_OK:	the method call was successful.
<> RET_OK:	an error occurred. Call the FR_GetLastErrorMessage() method to get extended error information.

Description:

Sends a command to FlashRunner.
According to command prefix (see 4.2.1) the number of expected answers are evaluated. To get the command answer (a unique string with all the involved channels answers), use the **FR_GetAnswer()** function.

8.5.7 FR_GetAnswer

Signature:

```
FR_COMM_ERRORS FR_GetAnswer  
(object handle, out string answer, int timeout_ms);
```

Parameters:

handle:	handle of communication. This is the object obtained by the FR_OpenCommunication() method.
answer:	the unique string containing all the expected answers from the instrument returned as an output parameter.
timeout_ms:	timeout, in milliseconds, after which the method returns even if a complete answer has not been received.

Return value:

== RET_OK:	the method call was successful.
<> RET_OK:	an error occurred. Call the FR_GetLastErrorMessage() method to get extended error information.

Description:

Receives the answer (or the answers) sent by FlashRunner to the PC, in response to a **FR_SendCommand()** method call. Normally a **FR_GetAnswer()** method should always follow a **FR_SendCommand()** method.

8.5.8 **FR_GetLastErrorMessage**

Signature:

```
string FR_GetLastErrorMessage(void);
```

Parameters:

None.

Return value:

a string containing the error message.

Description:

Most of the FlashRunner Interface Library methods return a **FR_COMM_ERRORS** value which indicates whether the function was successfully executed (return value = **RET_OK**) or not (return value other than **RET_OK**). In the latter case it is possible to get extended error information by calling the **FR_GetLastErrorMessage()** method. After the call, the error is cleaned.

8.5.9 **FR_GetDllVersion**

Signature:

```
string FR_GetDllVersion(void) ;
```

Parameters:

None.

Return value:

a string containing the current DLL version (e.g. 2.0.x.x).

Description:

Gets the current DLL assembly version.

8.5.10 FR_SendFile

Signature:

```
FR_COMM_ERRORS FR_SendFile  
(object handle, string src_filename, string  
dst_path, TransferProgressHandler progress)
```

Parameters:

handle: handle of the communication. This is the object obtained by the **FR_OpenCommunication()** method.

src_filename: name of the file (inclusive of the path) to be sent to FlashRunner, e.g. "C:\\MYBINARIES\\FLASH1.FRB".

dst_path: could be **FRB|PRJ|LIC|LOG|LIB**.

progress: a delegate object which encapsulates a callback method which will receive the progress status of the file transfer operation. If not used, set this parameter to NULL.
It must conform to the following declaration:
**delegate void TransferProgressHandler
(int progress)**

Return value:

== RET_OK: the method call was successful.

<> RET_OK: an error occurred. Call the method **FR_GetLastErrorMessage()** to get extended error information.

Description:

Sends a file from the PC to a specified path of FlashRunner.

8.5.11 FR_GetFile

Signature:

```
FR_COMM_ERRORS FR_GetFile  
(object handle, string src_filename, string  
dst_path, string file_type, TransferProgressHandler  
progress)
```

Parameters:

handle: handle of the communication. This is the object obtained by the **FR_OpenCommunication()** method.

src_filename: name of the file to be retrieved from FlashRunner, e.g. "test.prj."

dst_path: local path where to save the file.

filetype: could be **FRB|PRJ|LIC|LOG|LIB**.

progress: a delegate object which encapsulates a callback method which will receive the progress status of the file transfer operation. If not used, set this parameter to NULL.
It must conform to the following declaration:
**delegate void TransferProgressHandler
(int progress)**

Return value:

== RET_OK: the method call was successful.

<> RET_OK: an error occurred. Call the method **FR_GetLastErrorMessage()** to get extended error information.

Description:

Retrieves a file from FlashRunner and stores it in a specified local path.

8.5.12 FR_RunProject

Signature:

```
FR_COMM_ERRORS FR_RunProject  
(object handle, string project_name, int[]  
channels, int timeout_ms, ProjectExecutionHandler  
callback)
```

Parameters:

handle:	handle of the communication. This is the object obtained by the FR_OpenCommunication() method.
project_name:	name of the file to executed by FlashRunner, e.g. "test.prj."
channels:	an array of channels we want the project to be executed on (e.g. int [] channels = {1 2 3 14 15 16}).
timeout_ms:	timeout, in milliseconds, after which the method returns even if not all the channels have completed project execution.
callback:	a delegate object which encapsulates a callback method which will receive the channel id and the execution result (PASS=true or FAIL=false). If not used, set this parameter to NULL. It must conform to the following declaration: <pre>delegate void ProjectExecutionHandler(int channel, bool result);</pre>

Return value:

== RET_OK:	the method call was successful.
<> RET_OK:	an error occurred. Call the method FR_GetLastErrorMessage() to get extended error information.

Description:

Executes a project on a given set of FlashRunner's channels while receiving notifications upon individual channel project execution.

8.5.13 FR_GetLogger

Signature:

```
FR_COMM_ERRORS FR_GetLogger  
(string ip_address, out FR_Logger logger)
```

Parameters:

ip_address: IP address and port for Ethernet communication (e.g. "192.168.1.100:1235").

logger: **FR_Logger** class object used for the real-time logging.

Return value:

== RET_OK: the method call was successful.

<> RET_OK: an error occurred. Call the method **FR_GetLastErrorMessage()** to get extended error information.

Description:

Creates a communication link with the instrument for the real-time logging. If successful it returns as output parameter a **FR_Logger** object handle that must be used to read from the network stream by using its **read()** methods.

8.5.14 FR_DisposeLogger

Signature:

```
FR_COMM_ERRORS FR_DisposeLogger(FR_Logger logger)
```

Parameters:

logger: a real-time logging handle of communication. This is the object obtained by the **FR_GetLogger()** method.

Return value:

== RET_OK: the method call was successful.
<> RET_OK: an error occurred. Call the method **FR_GetLastErrorMessage()** to get extended error information.

Description:

Closes the communication link with the instrument and dispose the **FR_Logger** object.

8.5.15 FR_GetPublicKey

Signature:

`FR_COMM_ERRORS FR_GetPublicKey(object handle)`

Parameters:

handle: handle of the communication. This is the object obtained by the `FR_OpenCommunication()` method.

Return value:

`== RET_OK:` the method call was successful.
`<> RET_OK:` an error occurred. Call the method `FR_GetLastErrorMessage()` to get extended error information.

Description:

Get the public key, for internal use of the DLL, for the encryption of the dynamic data. This is like an initialization for the successive `FR_EncryptData()` operations.

8.5.16 FR_EncryptData

Signature:

```
FR_COMM_ERRORS FR_EncryptData(object handle, byte[]  
input, out byte[] output, out byte[] header)
```

Parameters:

handle:	handle of the communication. This is the object obtained by the <code>FR_OpenCommunication()</code> method.
input:	array containing the data to encrypt.
output:	array with the data encrypted in Hex format. The len is aligned to 16.
header:	array containing the encrypted header in Hex format. The len is 384 bytes.

Return value:

<code>== RET_OK:</code>	the method call was successful.
<code><> RET_OK:</code>	an error occurred. Call the method <code>FR_GetLastErrorMessage()</code> to get extended error information.

Description:

Receive as input an array of data (**input**). Returns the header, in Hex format, to be sent with the `#DYNMEMSETHEADER` command and the data encrypted, in Hex format, to be used with a `#DYNMEMSET` command. Both the **header** and **output** arrays have to be converted to ASCII format. The `FR_HexToAsciiStream()` utility can be used for this task.

8.5.17 FR_HexToAsciiStream

Signature:

```
string FR_HexToAsciiStream(byte[] input)
```

Parameters:

input: array containing the data to convert from Hex to a Ascii string.

Return value:

string: the ascii string of the Hex array in input. The length is double of the input.

Description:

Converts an array of Hex values in the corresponding Ascii string. The output (**string**) has a dimension double of the original array (**input**).

9 FRB Converter

This section explains how to use the **frbconverter.exe** tool from a terminal or a batch script. This tool is very powerful and allows you to create FRB or FRS (encrypted FRB) with almost the same features that you can find from the FlashRunner Workbench. It checks the source file addresses overlaps and if it fits device's memory map in the case a device is selected (option **-device**).

You can refer to the **-help** to see the full description of the features and the parameters that can be used. This is the list of some of them:

- **-pathDevices** *devices_smh_path*
which defines the path for Devices.smh file [Optional]. Default is frbconverter.exe directory.
- **-fillGaps** *<YES|NO>*
which enables to fill the gaps of the source file [Optional].
- **-device** *part_number*
which defines the device part number [Optional].
- **-input** *input_file_name*
which defines the input file and path. It can be used multiple times to use multiple input files.
- **-format** *input_file_format*
which defines the format of the input file. It must be used for each input file. Supported formats are:
 - **bin** – for binary files.

-
- **hex** – for Intel Hex files.
 - **s19** – for Motorola SREC files.
 - **-output** *output_file_name*
which defines the output file name and path.
 - **-offset** *offset_value*
which defines an offset and that can be used only for binary files.
 - **-pubKeys** *public_keys_path*
which defines the file path for pubKeys.frb file where public keys to encrypt the file are stored [Optional]. This can be enabled only if the output file extension is “.frs”, so only encrypted FRB files.
 - **-emmcOptimize** *Y*
which enable the “Remove Blank Pages” from source file during FRB conversion only for eMMC devices (Y/N default N) [Optional].

Some examples of typical usage below:

- **frbconverter.exe -input in.hex -format hex -output out.frb**
This simple command converts the `in.hex` file into `out.frb`.
- **frbconverter.exe -input first.s19 -format s19 -input second.bin -format bin -output out.frb**
This command converts the `first.s19` and `second.bin` file into `out.frb`.
- **frbconverter.exe -input input.bin -format bin -offset 0x200 -output out.frb**

This command converts the `input.bin` file with an offset of `0x200` into `out.frb`.

It is also possible to set zones with variable data into the FRB to be used for dynamic data. This can be done by setting as input **variable** and defining the parameters below:

- **-start_addr** *address_value*
which defines the start address of the variable data.
- **-size** *size_value*
which defines the size of the variable data.
- **-value** *fill_byte*
which defines the byte to use to fill the variable data.

Some examples of typical usage with variable data below:

- **frbconverter.exe -input variable -start_addr 0x1000 -size 0x10 -output out.frb**

This command defines a variable data from `0x1000` to `0x100F` into `out.frb`.

- **frbconverter.exe -input input.bin -format bin -offset 0x10 -input variable -start_addr 0x0 -size 0x10 -output out.frb**

This command converts the `input.bin` file with an offset of `0x10` preceded by `0x10` bytes of variable data into `out.frb`.

A simple batch file can be created with the following code:

```
set FRBCONVERTER=C:\Program Files (x86)\SMH  
Technologies\FlashRunner2\frbconverter.exe  
  
set INPUT_FILE=C:\Users\reertolupi\Desktop\myFile.s19  
set OUTPUT_FILE=C:\Users\reertolupi\Desktop\myFile.frb  
  
call "%FRBCONVERTER%" -input "%INPUT_FILE%" -format s19  
-output "%OUTPUT_FILE%"
```

From this command line tool it is also possible to encrypt an existing FRB file or to upgrade an FRS file.

Input parameters are requested in order:

- **-input** *input_file_name*
which defines the input file and path. It must be an FRB (.frb) or FRS (.frs) according to what you need to do.
- **-pubKeys** *public_keys_path*
which defines the file path for pubKeys.frk file where public keys to encrypt the file are stored.

Example:

- **frbconverter -input myOldFile.frs -pubKeys C:\...\pubKeys.frk**
This command upgrade the `myOldFile.frs` file and create a new encrypted FRB file with the same name. The old file is renamed as `myOldFile.frs.old`.

10 Voltage Monitor

10.1 Introduction

Voltage Monitor is a *new* operative system feature implemented starting from version 2.32/3.02 of the OS that keeps constantly measured the voltage level of the two **VPROG** lines available for each channel and runs in the background regardless of driver, device or number of channels in use.

The basic operating principle is that if an *under-voltage* or *over-voltage* level is detected caused by exceeding both the negative or positive boundary threshold any ongoing flashing operation can be interrupted.

Options to control operations are available therefore the monitoring can be paused or resumed by user commands that can be inserted in the file script, as well as the error can be detected to exit immediately or continue the overall flashing process and log.

Voltage Monitor can be activated without specifying any type of command or parameter. The process starts checking the power level after the activation of the **VPROG** line just after ending the *Power-up delay* defined during the *Project Wizard Creation* and stops before the power is turned off.

If any voltage error is identified, the monitor sends a signal to the operating system which will immediately disable both **VPROG** lines and terminate the execution of the running procedure. After disabling **VPROG** lines digital lines will stop also, resulting in a

variable timeout error return during the currently executed command.

10.2 Command syntax

Voltage monitor is enabled by setting voltage limits control check of the two **VPROG** lines (0 or 1) via Workbench software or scripting parameters as described below:

#TCSETPAR PROG(x) LIMITS <thr> <prm2> <prm3>

parameters explanation:

- (x) 0 or 1: specifies the **VPROG** line
- <thr> threshold in mV of the error detection for **VPROG**.

Threshold must be equal or greater than 1% of **VPROG(x)**

Example: **VPROG0** = 3300mV
minimum threshold value allowed: 33mV

Note: parameter <prm2> and parameter <prm3> are not involved with Voltage Monitor.

#TCSETPAR PROG0LIMITS <thr> 0 0 *VPROG0 threshold limit*

#TCSETPAR PROG1LIMITS <thr> 0 0 *VPROG1 threshold limit*

#TCSETPAR VPROG0 <mV> *VPROG0 Output Level*

#TCSETPAR VPROG1 <mV> *VPROG1 Output Level*

The under-voltage error is detected using the formula:

$$UVerr = Is \ Vsampled < (VprogSet \ minus \ Vthreshold)$$

The over-voltage error is detected using the formula:

$$OVer = Is \ Vsampled > (VprogSet \ plus \ Vthreshold)$$

The error detected is reported in the *Real-Time log* of the channel in which it occurs.

Error types are described later in the paragraph 10.5.

Optional commands:

#VOLTAGEMONITOR DYN_SAMPLE <value>

Parameter/values explanation:

<value> ENABLED *default

Dynamic Sampling mode is enabled by default and the time of the sampling point of each channel is dynamically adjusted to always achieve the best available sampling rate.

If the measurement is paused for any channel, the dynamic sampling algorithm (if not disabled by the user) compensates by increasing the sampling time in the other channels to reach the maximum frequency available. The sampling sequence may change due to internal task scheduling but all the channels are equally sampled.

<value> DISABLED

Fixed sampling time is obtained by disabling the *Dynamic Sampling Algorithm*, and can be calculated multiplying the minimum sampling time per channel (300uS) with the number of channels in which the monitor is activated and the number of the power supplies to control.

S.T. = 300uS * 8 channels * (vprog0=1) = 2.4mS ~ 400Hz

(continued)

#VOLTAGEMONITOR ON <value>

<value> ERROR_CONTINUE

The voltage monitor is enabled and keeps constantly monitored the subsequent operation. If an error is detected it is logged and the flashing process continues.

<value> ERROR_EXIT *(default)*

Monitoring is restarted for the current operation and forces an exit of the current command execution if an error is detected.

#VOLTAGEMONITOR OFF

Monitoring can be paused (*if not necessary for the next operation*)

#VOLTAGEMONITOR CLEAR_AVERAGE <value/no value>

<no value>

reset the average value already calculated for both lines

<value> VPROG0

<value> VPROG1

clear data for the selected line only.

#VOLTAGEMONITOR READ_AVERAGE <value/no value>

<no value>

print in the *Realtime Log terminal* both **VPROG0** and **VPROG1** average values of the sampled data starting from the beginning of operations or the last **CLEAR_AVERAGE** command.

<value> VPROG0

<value> VPROG1

print the read average value for the selected line

Usage:

```
#VOLTAGEMONITOR CLEAR_AVERAGE  
[...]  
#VOLTAGEMONITOR READ_AVERAGE
```

Commands can be added to the script to read the voltage value measured during the same operation.

Script Example:

```
[...]  
#TCSETPAR PROG0LIMITS 50 0 0  
#TCSETPAR VPROG0 3300  
[...]  
#VOLTAGEMONITOR ON ERROR CONTINUE           log only  
#VOLTAGEMONITOR CLEAR_AVERAGE               reset measure  
#TPCMD MASSERASE F                           start operation  
#VOLTAGEMONITOR READ_AVERAGE                 log measure  
#VOLTAGEMONITOR OFF                           no monitoring  
#TPCMD BLANKCHECK F                           start operation  
#VOLTAGEMONITOR ON ERROR_EXIT                 error detection  
#VOLTAGEMONITOR CLEAR_AVERAGE                 reset measure  
#TPCMD PROGRAM F                             start operation  
#VOLTAGEMONITOR READ_AVERAGE                 log measure  
#VOLTAGEMONITOR OFF                           no monitoring  
#TPCMD VERIFY F R                             start operation  
[...]
```

10.3 Computational load

Voltage Monitoring has a computation load that may reflect in 5% - 7% increase of the overall programming time measured on a 16 channels system.

10.4 Measurement Process


The measurement process starts as soon as `VPROG` is activated and stable in the output line and continues until `VPROG` is shut down.

The sampling frequency is proportional to the number of channels currently active and its value is approximately 3.3KHZ when only 1 channel of `VPROG0` is monitored.


If both `VPROG0` and `VPROG1` lines are monitored simultaneously the sampling time increases to 600us and the sampling frequency is approximately 1.6KHz.

For 8 channels of `VPROG0` monitored only, the sampling frequency is about 400Hz and for 16 channels it is about 200Hz. If `VPROG0` and `VPROG1` are both monitored, the sampling rate for 16 channels is approximately 100Hz per channel.


Sampling sequence for 8ch of VPROG0, 300uS per sample:




Sampling sequence for 8ch of VPROG0+VROG1, 300uS per sample:



Sampling sequence for 8ch of VPROG0, 300uS per sample, only odd channels are monitored:



Threshold limits:



10.5 Error Types

```
#TCSETPAR PROGOLIMITS 50 0 0
#VOLTAGEMONITOR ON ERROR_CONTINUE
```

Example of under-voltage detection and log:

```
[VoltageMonitorPoll] ch:1, * VProg0 Under Voltage ERROR:
2061mV->3300mV, [@ms: 1224]
- 2061mV: the level measured,
- 3300mV: the reference
- [@ms: 1224]: elapsed time from start of operation
→ task continue.
```

```
[VoltageMonitorPoll] ch:1, * VProg0 Over Voltage ERROR:
4180mV->3300mV, [@ms: 1551]
- 4180mV: the level measured,
- 3300mV: the reference
- [@ms: 1551]: elapsed time from start of operation
→ task continue.
```

```
#VOLTAGEMONITOR ON ERROR_EXIT
```

```
[VoltageMonitorPoll] ch:1, * VProg0 Under Voltage ERROR:
2148mV->3300mV, [@ms: 56075]
```

```
!! -> Exit Signal detected [10]: VMErrror -6 Address
0x000002dc. Process expiring...
!! -> Disabling VPROG0...
!! -> Disabling VPROG1...
```

```
[VMErrrorStatusCond] threadStatusCond[0] = TD_ERROR
VoltageMonitor has terminated the execution of command:
#TPCMD MASSERASE F
```

```
|ERR--0400001D|Voltage Monitor Error
detected|[file ../Src/voltageMonitor.c, line 456, funct
VMSignalError()]
```

11 Progress Bar

11.1 Introduction

Progress Bar is a new operative system feature implemented starting from version 2.39/3.09 of the OS. The aim is to give to the user a tool to keep monitored the programming/verify progress process.

The operating principle is to keep track of how much data of the FRB have been processed and to return a percentage value to the user. Therefore, this operation can't be used to monitor masserase or blankcheck.

This new feature is meant to be integrated using the FlashRunner DLL and to allow the user to create his own progress bar to monitor the progress of the program/verify processes. This way the user has a feedback of the operation status when this takes a long time due to the huge amount of data to program.

This chapter explains how to use this feature and its limitations.

11.2 Command Syntax

From OS 2.39/3.09 to 2.47/3.17

#PROGRESSBAR <num_memories> <start_addr_1> <size_1>

Parameters explanation:

num_memories: this is the number of memories to monitor.

Start_addr_1: start address of the first memory to monitor

Size_1: size of the first memory to monitor

...

Example of usage:

A device has a Flash (from 0x0 to 0xFFFF) and an EEPROM (from 0xF1000 to 0xF1FFF); to monitor both the memories, the command will be:

```
#PROGRESSBAR 2 0x0 0x10000 0xF1000 0x1000
```

Otherwise, to monitor only one of the two memories, the command will be:

```
#PROGRESSBAR 1 0x0 0x10000
```

Script example:

```
[...]
```

```
#PROGRESSBAR 2 0x0 0x10000 0xF1000 0x1000
```

```
#TPSTART
```

```
#TPCMD CONNECT
```

```
#TPCMD MASSERASE C
```

```
#TPCMD BLANKCHECK C
```

```
#TPCMD PROGRAM C
```

```
#TPCMD VERIFY C R
```

```
#TPCMD MASSERASE D
```

```
#TPCMD BLANKCHECK D
```

```
#TPCMD PROGRAM D
#TPCMD VERIFY D R
#TPCMD DISCONNECT
#TPEND
```

Starting from OS 2.48/3.18

Starting from OS 2.48/3.18 the progress bar has been updated to provide better performances and an easier syntax to the user.

```
#PROGRESSBAR ON <mem_type> <end_address>
```

Parameters explanation:

mem_type: character of the memory to monitor: F, D, C...

end_address: end address to monitor.

Example of usage with the device used in the previous chapter:

```
[...]
#TPSTART
#TPCMD CONNECT
#TPCMD MASSERASE C
#TPCMD BLANKCHECK C
#PROGRESSBAR ON C 0xFFFF
#TPCMD PROGRAM C
#TPCMD VERIFY C R
#TPCMD MASSERASE D
#TPCMD BLANKCHECK D
#PROGRESSBAR ON D 0xF1FFF
#TPCMD PROGRAM D
#TPCMD VERIFY D R
```

```
#TPCMD DISCONNECT
```

```
#TPEND
```

11.3 Progress Bar and DLL

To get the progress percentage can be used the **GETPROGRESSBAR** command. This command can be sent only to the Master with the following syntax:

```
#55*GETPROGRESSBAR <channel>
```

Where `<channel>` is the number of the channel to get the process percentage. There are two possible answers:

1. Progress percentage:

```
#55*GETPROGRESSBAR 2  
55|VERIFY F R: 45%  
55|>
```
2. When the run is ended (success/fail) or before the progress bar gets any data, the answer is:

```
#55*GETPROGRESSBAR 2  
55|No operation: 0%  
55|>
```

Using standard send/receive functions available in the DLL it's possible to loop this command and get the progress (please refer to chapter 8). It's suggested to introduce an appropriate timeout between two requests in order to not overload the FlashRunner and affect too much the programming performances.

The new C# DLL can be used to get the progress percentage by using the dedicated communication channel on address <FR_ip>:1236 which can be opened using the **FR_GetLogger** and then to loop the `Read` command to get the stream.


Example of usage DLL side (pseudo-code):

```
ComManager myComManager = new ComManager();
FR_Logger progress_bar;

myComManager.FR_GetLogger("192.168.1.152:1236", out progress_bar)

while (...condition...)
{
    ... Operation ...
    progress_bar.Read(out buffer, out len);
    ... Operation on the buffer ...
}
```

Example of the channel communication:



```
C:\WINDOWS\system32\cmd.exe
02|1|200901-12:38:19.344|PROGRAM F: 6%
02|1|200901-12:38:23.233|PROGRAM F: 7%
02|1|200901-12:38:27.128|PROGRAM F: 8%
02|1|200901-12:38:31.024|PROGRAM F: 9%
02|1|200901-12:38:34.972|PROGRAM F: 10%
02|1|200901-12:38:38.911|PROGRAM F: 11%
02|1|200901-12:38:42.849|PROGRAM F: 12%
02|1|200901-12:38:46.746|PROGRAM F: 13%
02|1|200901-12:38:50.635|PROGRAM F: 14%
02|1|200901-12:38:54.540|PROGRAM F: 15%
02|1|200901-12:38:58.437|PROGRAM F: 16%
02|1|200901-12:39:02.330|PROGRAM F: 17%
02|1|200901-12:39:06.222|PROGRAM F: 18%
02|1|200901-12:39:10.118|PROGRAM F: 19%
02|1|200901-12:39:14.007|PROGRAM F: 20%
02|1|200901-12:39:17.908|PROGRAM F: 21%
02|1|200901-12:39:21.850|PROGRAM F: 22%
02|1|200901-12:39:25.794|PROGRAM F: 23%
02|1|200901-12:39:29.730|PROGRAM F: 24%
02|1|200901-12:39:33.627|PROGRAM F: 25%
02|1|200901-12:39:37.518|PROGRAM F: 26%
02|1|200901-12:39:41.416|PROGRAM F: 27%
02|1|200901-12:39:45.349|PROGRAM F: 28%
02|1|200901-12:39:49.244|PROGRAM F: 29%
02|1|200901-12:39:53.141|PROGRAM F: 30%
02|1|200901-12:39:57.030|PROGRAM F: 31%
02|1|200901-12:40:00.924|PROGRAM F: 32%
02|1|200901-12:40:04.818|PROGRAM F: 33%
02|1|200901-12:40:08.713|PROGRAM F: 34%
```

If the run fails, 100% is returned from version 2.48/3.18. In the previous versions -1 was returned.

11.4 Limitations

- The use of the Progress Bar, by its nature, generates an **increase in cycle time equal to about 15% of the total**.
- The progress bar is meant to be used with devices with big memory. Using it with small devices will results in a lot of percentage jumps (i.e: from 0% to 15% and so on).
- The use of the **IGNORE_BLANK_PAGE** and/or fragmented FRB will result in percentage jumps.

From OS 2.39/3.09 to 2.47/3.17

- The progress bar can't be used if the **IGNORE_BLANK_PAGE** option is set on the **TPSETSRC** command.
- Progress bar can be used only with automatic programming/verify, not with manual commands.

FlashRunner Internal Memory

FlashRunner has an internal memory storage which collects all the data, files, information regarding your projects. Its memory is an SD card which comes by default with 64GB size.

This value can be increased up to 256GB.

If you need to increase the memory size of an already purchased product please contact your distributor

If you want to purchase a new product with an already increased memory storage, please notify that to your distributor at ordering time.

Approved SD cards for FlashRunner products are signed below:

2GB	Class10
64GB	microSDXC
128 GB	MicroSDXC
256 GB	MicroSDHC

12 Troubleshooting

This section collects a set of troubleshooting techniques to program successfully your device with FlashRunner.



Note: *Keep FlashRunner always in a well-ventilated area in order to prevent product overheating, which could affect product performance and, if maintained for a long time, it could damage product hardware components.*

12.1 Project execution failures

If you are executing a project and FlashRunner answers to project execution with FAIL please open the Real Time Log tool, described in chapter 3.12 Click on the Log tab, click on the Clear button, Run again project and check related error description. Usually a failure on “Connect” command execution means that FlashRunner and target device are not correctly communicating.

1. Please check that project is set for the exact device mounted on your board
2. Please check cable wirings using the PinMap tool described in chapter 3.14.
3. Verify you are running the correct channel
4. Verify that all connections have been wired correctly using a tester:
 - a. check which test point/connector pin implements function described on the PinMap tool and verify the continuity test point/connector pin and FlashRunner

-
- ISP connector pin. You may find useful target board schematics and target board test point map.
- b. Did you confuse RX signal with TX signal? Is the soldering rugged?
 - c. Check which device pin is connected to each test point/connector pin. Check continuity between the device pin and FlashRunner ISP connector.
 - d. Does each signal they have passive components in between that could cause interference? If capacitance or resistor are needed on some lines (check it on device datasheet) verify that they have been designed on your board under specification.
5. Is the board powered up correctly? If you are using FlashRunner VPROG1, please try with an external power supply. Does current absorption reach a realistic value? (at least 30mA)
 6. If you are using an external power supply, be sure that FlashRunner GND line is coupled with the external supplier GND line.
 7. If you are using FlashRunner VPROG0 line together with an external supply, be sure that the VPROG0 reference is the same as the one defined by target board design reference.
 8. If you are using FlashRunner VPROG1 line, you must be sure that board current absorption is less than FlashRunner model maximum current level supported. Please check FlashRunner User's Manual to get maximum current absorption on VPROG0 and VPROG1
 9. Has this board been already programmed? Firmwares could affect device startup, please try always with a device in erased state.
 10. Is there a watchdog active on the board? If yes please check how to disable it.
 11. Try slowing down communication frequency to the lowest value accepted (100kHz usually is available)
-

-
12. Try increasing PWUP, PWDOWN, RSTUP, RSTDOWN values
 13. GND reference must not float
 14. Please use an oscilloscope to check if signals are affected by “glitches”, if they are present try to compensate by putting a small capacitance between this signal and GND
 15. Signals must have a specific time frame for rising edge and falling edge. Check on datasheet which are these constraints and check if they are satisfied. If not, put a power-up resistor (resistor between GND and VPROG0) or a power-down resistor.
 16. Remember that cable wirings must be the shortest as possible. Try reducing their length, especially if they are more than 30 cm long and always use twisted and shielded cables.

In case of assistance need please open the Real Time Log tool, described in chapter 3.12. Click on the Log tab, click on the Clear button, Run again project, check related error description. Contact support@smh-tech.com attaching this error log in your email together with SGETVER command answer (please check chapter 4.4.58 for more information)