

YJKP - Manual movement

Description how to use manual functions

YJKP

Title AppNote YJKP Manual movement
Version 1.10
Document no. 100263
Originalen
Author Festo

Last saved 05.09.2019

Copyright Notice

This documentation is the intellectual property of Festo AG & Co. KG, which also has the exclusive copyright. Any modification of the content, duplication or reprinting of this documentation as well as distribution to third parties can only be made with the express consent of Festo AG & Co. KG.

Festo AG & Co KG reserves the right to make modifications to this document in whole or in part. All brand and product names are trademarks or registered trademarks of their respective owners.

Legal Notice

Hardware, software, operating systems and drivers may only be used for the applications described and only in conjunction with components recommended by Festo AG & Co. KG.

Festo AG & Co. KG does not accept any liability for damages arising from the use of any incorrect or incomplete information contained in this documentation or any information missing therefrom.

Defects resulting from the improper handling of devices and modules are excluded from the warranty.

The data and information specified in this document should not be used for the implementation of safety functions relating to the protection of personnel and machinery.

No liability is accepted for claims for damages arising from a failure or functional defect. In other respects, the regulations with regard to liability from the terms and conditions of delivery, payment and use of software of Festo AG & Co. KG, which can be found at www.festo.com and can be supplied on request, shall apply.

All data contained in this document do not represent guaranteed specifications, particularly with regard to functionality, condition or quality, in the legal sense.

The information in this document serves only as basic information for the implementation of a specific, hypothetical application and is in no way intended as a substitute for the operating instructions of the respective manufacturers and the design and testing of the respective application by the user.

The operating instructions for Festo products can be found at www.festo.com/sp.

Users of this document (application note) must verify that all functions described here also work correctly in the application. By reading this document and adhering to the specifications contained therein, users are also solely responsible for their own application.

Table of contents

- 1 Components/Software used5
 - 1.1 Application description 5
- 2 Prerequisites6
- 3 Manual control.....8
 - 3.1 Via WebVisu 8
 - 3.2 Via Host PLC..... 13

1 Components/Software used

Type/Name	Version Software/Firmware	Date of manufacture
Servo press kit YJKP	general	--
Application software YJKP (GSAY-A4-F0-Z4-1.3.5)	V1.3.5	--
Firmware controller (CECC-X)	V3.4.6	--
Firmware motor controller (CMMP-AS)	V4.0.1501.2.4	--

Table 1.1: 1 Components/Software used

1.1 Application description

This application note describes how to use manual movement and tare function via WebVisu and Host.

2 Prerequisites

Open a browser and start the WebVisu of the YJKP.

In Browser: <IP of the CECC-X>:8080/servo_press_kit.htm

The visualization of the servo-press kit is opened with 4 tabs :

- Commissioning , Program : Not active
- Operation , Diagnosis: Active

Click on **Login** to active the commissioning and program tabs. A new pop-up window appears and a password must be entered to login.

Default password: User name: Admin
Password: ServoPressKit

Festo servo_press kit

Press process ● Not ready

No.	Function	Name
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		

Active program

Program selection ▼

Maximum force
0.00 N

Maximum position
0.00 mm

Actual force
1.85 N

Actual position
0.00 mm

Actual velocity
0.01 mm/s

Cycle time
0 ms

Production
0 Parts
OK: 0
NOK: 0

Last pressing
☐ ☐ ☐ ☐ ☐

☐ Show record

Commissioning Program Operation Diagnosis

● Not ready

Login

User name


Admin

Password

.....

Cancel OK

1. go to the commissioning tab -> system settings and set the control to WebVisu.




2. In commissioning tab check, if the hardware is configured successfully (= Green) and the system is homed (= Green). You will see a **Ready** in the bottom left corner.


**Note :**

- For further information about hardware configuration and homing, please read AppNote Servo Press.


Kit YJKP Hardware Configuration and AppNote Servo Press Kit YJKP Homing.



3. Activate the servo press system with input X17.4.2 . Output X20.5.1 will turn true.



4. Set the system mode to manual (Input X3.1 high, Input X3.2 low).



The servo press is now ready for a manual operation.

3 Manual control

3.1 Via WebVisu

The manual control panel consists of the following parts:

The screenshot shows the WebVisu manual control panel with three distinct sections, each highlighted with a red border and a numbered callout:

- Section 1 (Released):** Displays 'Actual force' (18.81 N), 'Actual position' (0.00 mm), and 'Actual velocity' (-0.02 mm/s).
- Section 2 (Tare):** Includes a 'Tare' checkbox (unchecked) and an 'Offset' input field set to '0.00 N'.
- Section 3 (Motion):** Features three radio buttons for 'Absolute', 'Relative', and 'Jog' (selected). Below them are '-' and '+' buttons, and a 'Velocity' input field set to '0.00 mm/s'.

1. Cylinder status

- Release(d): activation status of the system.
- Actual force: current force value (N).
- Actual position: current position of the cylinder (mm).
- Actual velocity: current speed of the cylinder (mm/s).

2. Tare: This function is used to manipulate the actual force value.

While commissioning the YJKP, you will notice that the actual force value in WebVisu might not be equal zero (as shown in the below figure). This value is mainly influenced by the mounting position (horizontal or vertical) and the weight of all mounted parts at the load cell. Thus when you need to press with a certain amount of force, the actual force needs to be reset before starting the pressing process.

This close-up screenshot highlights two specific areas of the control panel with red boxes:

- Actual force:** Shows a value of 18.38 N.
- Tare:** Shows the 'Tare' checkbox (unchecked) and the 'Offset' input field set to 0.00 N.

How to use it:

- Check tare : Activate/Deactivate this function.
- Offset : This value is added to the actual force value.

Example:

Actual force is 18.38 N, as shown in the previous figure.

After activating the tare function and with an offset of 0 N, the new actual force will be round about 0 N.

Released

Actual force
0.22 N

Actual position
0.00 mm

Actual velocity
0.00 mm/s

Tare
☒ Tare
Offset 0.00 N

3. Motion : The control panel of the manual movement.

There are three methods in YJKP system to do a manual movement:

I. **Absolute movement:**

It is a method to move the cylinder to a target position based on the homing position of the cylinder.

Motion:
☒ Absolute
☐ Relative
☐ Jog

Move 1

Velocity 0.00 mm/2

Position 0.00 mm 3

Stop 4

1. Move: starts the movement the cylinder.
2. Velocity: Cylinder speed when moving to the target position.
3. Position: target position(mm)
4. Stop: stops the movement of the cylinder.

Example:

In this example the „Absolute“ method will be used to move the cylinder to the position 20 mm .

Set these values:

- Motion : Absolute
- Velocity : 5 mm/s
- Position : 20 mm

Motion:
☒ Absolute
☐ Relative
☐ Jog


Move

Velocity 5.00 mm/s

Position 20.00 mm

Stop


Startposition: Actual position = 7 mm



FESTO	
Released	
Actual force	19.14 N
Actual position	7.00 mm
Actual velocity	0.02 mm/s

Click on “Move” button:

The Cylinder will move from absolute position 7mm to absolute position 20mm (distance of 13mm) at speed of 5 mm/s. New actual position= 20 mm.



FESTO	
Released	
Actual force	18.12 N
Actual position	20.00 mm
Actual velocity	-0.01 mm/s

I. Relative movement:

It is a method to move the cylinder a certain distance based on the current position of the cylinder.

Motion:	
☐ Absolute	
☒ Relative	
☐ Jog	
Move 1	
Velocity	0.00 mm 2
Distance	0.00 mm 3
Stop 4	

1. Move: starts the movement of the cylinder.
2. Velocity: Cylinder speed when moving to the target position.
3. Distance: target distance (mm)

4. Stop: stops the movement of the cylinder.

Example:


In this example the „Relative“ method will be used to move the cylinder 20 mm .

Set these values:

- Motion : Relative
- Velocity : 5 mm/s
- Distance : 20 mm


Motion:	
☐ Absolute	
☒ Relative	
☐ Jog	
Move	
Velocity	5.00 mm/s
Distance	20.00 mm
Stop	

Startposition: Actual position = 7 mm




FESTO	
Released	
Actual force 19.14 N	
Actual position 7.00 mm	
Actual velocity 0.02 mm/s	

Click on “Move” button: The cylinder will move a distance of 20mm (from absolute position 7mm to absolute position 27mm). New Actual position = 27 mm.



II. Jog movement:

It is a method to move the cylinder as long as you hold the movement buttons.




1. $-$: moves the cylinder in the positive direction.
2. $+$: moves the cylinder in the negative direction.
3. Velocity: Cylinder speed when moving.


Example:

Set this velocity value:

- Velocity : 5 mm/s



Click on the “+ / – buttons” to move the cylinder in the positive/negative directions as shown in the figure :



3.2 Via Host PLC

This chapter will not describe all steps in particular, since they are basically the same like with the WebVisu (please refer to previous chapter).

It shows the needed function blocks and required inputs and outputs.

1. FB_Connect

Required inputs:

- xEnable := true;
- enTargetComMode := 1;

Required outputs:

- xActive := true;
- enActualComMode := 1;
- xConnected := true;




Figure 3-7: FB_Connect

2. FB_Manual

Required inputs:

- xEnable := true;
- xEnableSystem := True;
- xAbort := True ;
- xTare := True/False; *(manipulates the force value).*
- rTargetOffsetForceSensor := ; *(Target offset of the force sensor).*
- enTargetPosMode := ; *(Target position mode
0x00 = Jog
0x01 = Move absolute
0x02 = Move relative).*
- rTargetMotionVelocity := ; *(Cylinder speed when moving to the target position).*
- rTargetMotionPositionDistance := ; *(position/distance when using absolute/relative method)*
- xMove := True/False; *(move the cylinder when using Absolute/Relative methods).*
- xStopMove := True/False; *(stops the movement of the cylinder).*
- xJogPos := True /False; *(moves the cylinder in the positive direction).*
- xJogNeg := True/ False ; *(moves the cylinder in the negative direction).*

Required outputs:

- xActive := true;
- xSystemEnabled := True;
- xSystemIsHomed := True;
-

