

EM-1240-LX User's Manual

Fifth Edition, February 2009

www.moxa.com/product

MOXA[®]

© 2009 Moxa Inc. All rights reserved.
Reproduction without permission is prohibited.

EM-1240-LX User's Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

Copyright © 2009 Moxa Inc.
All rights reserved.
Reproduction without permission is prohibited.

Trademarks

MOXA is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document “as is,” without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Moxa Americas:

Toll-free: 1-888-669-2872

Tel: +1-714-528-6777

Fax: +1-714-528-6778

Moxa China (Shanghai office):

Toll-free: 800-820-5036

Tel: +86-21-5258-9955

Fax: +86-10-6872-3958

Moxa Europe:

Tel: +49-89-3 70 03 99-0

Fax: +49-89-3 70 03 99-99

Moxa Asia-Pacific:

Tel: +886-2-8919-1230

Fax: +886-2-8919-1231

Table of Contents

Chapter 1	Introduction	1-1
	Overview.....	1-2
	Package Checklist.....	1-2
	Product Features	1-2
	Product Specifications	1-3
	Hardware Specifications.....	1-3
	Software Specifications.....	1-4
	Hardware Block Diagram	1-5
	Appearance	1-5
	Dimensions	1-7
	Installing the EM-1240-LX.....	1-7
	LED Indicators.....	1-8
	Wiring Requirements	1-8
	Connecting the Power.....	1-9
	Grounding the EM-1240-LX	1-9
	Connecting Data Transmission Cables	1-9
	Connecting to the Network.....	1-9
	Connecting to a Serial Device	1-10
	Serial Console Port.....	1-10
	Internal SD Socket.....	1-11
	Additional Functions.....	1-11
	Reset Button	1-11
	Real-time Clock.....	1-12
Chapter 2	Getting Started	2-1
	Powering on the EM-1240-LX	2-2
	Connecting the EM-1240-LX to a PC.....	2-2
	Console Port	2-2
	Telnet.....	2-3
	Configuring the Ethernet Interface	2-4
	Installing a Secure Digital (SD) Memory Card.....	2-6
	Developing Your Applications	2-6
	Installing the EM-1240-LX Tool Chain	2-7
	Compiling Hello.c	2-7
	Uploading “Hello” to the EM-1240-LX	2-8
	Running “Hello” on the EM-1240-LX	2-9
	Make File Example Code	2-10
Chapter 3	Software Package	3-1
	EM-1240-LX Software Architecture	3-2
	Journaling Flash File System (JFFS2).....	3-3
	EM-1240-LX Software Package.....	3-4
Chapter 4	Configuring the EM-1240-LX	4-1
	Enabling and Disabling Daemons.....	4-2
	Adding a Web Page.....	4-3
	IPTABLES	4-3
	NAT.....	4-7
	NAT Example.....	4-7

	Enabling NAT at Bootup.....	4-7
	Configuring Dial-in/Dial-out Service	4-8
	Dial-out Service.....	4-8
	Dial-in Service.....	4-8
	Configuring PPPoE.....	4-8
	How to Mount a Remote NFS Server	4-9
	Dynamic Driver Module Load/Unload	4-9
	Upgrading the Kernel.....	4-10
	Upgrading the Root File System & User Directory	4-11
	Loading Factory Defaults	4-12
	Autostarting User Applications on Bootup	4-12
	Checking the Kernel and Root File System Versions.....	4-12
Chapter 5	EM-1240-LX Device API	5-1
	RTC (Real-time Clock).....	5-2
	Buzzer	5-2
	UART Interface.....	5-2
	GPIO	5-3
Appendix A	System Commands.....	A-1
	μClinux normal command utility collection	A-1
	File manager	A-1
	Editor	A-1
	Network	A-2
	Process	A-2
	Other	A-2
	Moxa Special Utilities	A-2
Appendix B	SNMP Agent with MIB II & RS-232 Like Group	B-1
Appendix C	EM-1240-LX FAQ	C-1

The Moxa EM-1240-LX Series of Mini RISC-based Ready-to-Run Embedded Computer features dual 10/100 Mbps Ethernet ports and four RS-232/422/485 serial ports in a built-in μ Clinux ARM9 module. In addition, the EM-1240-LX supports an SD memory card for storage expansion, offers high performance communication and unlimited storage in a super compact, palm-sized module. The EM-1240-LX is an ideal solution for embedded applications that use a lot of memory and must be housed in a small physical space without sacrificing performance.

In this chapter we cover the following topics:

- Overview**
- Package Checklist**
- Product Features**
- Product Specifications**
 - Hardware Specifications
 - Software Specifications
- Hardware Block Diagram**
- Appearance**
- Dimensions**
- Installing the EM-1240-LX**
- LED Indicators**
- Wiring Requirements**
 - Connecting the Power
 - Grounding the EM-1240-LX
- Connecting Data Transmission Cables**
 - Connecting to the Network
 - Connecting to a Serial Device
 - Serial Console Port
- Internal SD Socket**
- Additional Functions**
 - Reset Button
 - Real-time Clock

Overview

The EM-1240-LX Series of mini RISC-based communication platforms are ideal for your embedded applications. The EM-1240-LX comes with 4 RS-232/422/485 serial ports and dual 10/100 Mbps Ethernet LAN ports to provide users with a versatile communication platform.

The EM-1240-LX uses the Moxa ART ARM9 RISC CPU. Unlike the X86 CPU, which uses a CISC design, the ARM9's RISC design architecture and modern semiconductor technology provide the EM-1240-LX with a powerful computing engine and communication functions, but without generating too much heat. The built-in 8 MB NOR Flash ROM and 16 MB SDRAM give you enough storage capacity and an additional SD socket provides you with flexible storage expansion to run applications. The dual LAN ports built into the ARM9 make the EM-1240-LX an ideal communication platform for simple data acquisition and protocol conversion applications, and the two RS-232/422/485 serial ports allow you to connect a variety of serial devices.

The pre-installed μ CLinux operating system provides an open software operating system for software program development. Software written for desktop PCs is easily ported to the EM-1240-LX with a GNU cross compiler, so that you will not need to spend time modifying existing software code. The operating system, device drivers, and your own software can all be stored in the EM-1240-LX's Flash memory.

Package Checklist

EM-1240-LX

Mini RISC-based ready-to-run embedded computer with 4 serial ports, dual Ethernet, SD, μ CLinux OS

EM-1240-LX Series products are shipped with the following items:

- 1 EM-1240-LX embedded module
- 1 EM-1240-LX Development Kit (optional)
- Quick Installation Guide
- Document & Software CD
- Cross-over Ethernet cable
- CBL-RJ45M9-150: 150 cm, 8-pin RJ45 to male DB9 serial port cable
- CBL-RJ45F9-150: 150 cm, 8-pin RJ45 to female DB9 console port cable
- Power cord
- Product Warranty Statement

NOTE: *Notify your sales representative if any of the above items are missing or damaged.*

Product Features

EM-1240-LX Series products have the following features:

- MOXA ART ARM9 32-bit 192 MHz communication processor
- On-board 16 MB RAM, 8 MB Flash ROM
- 4 software-selectable RS-232/422/485 serial ports
- 2 10/100 Mbps Ethernet ports
- RS-232 console, with full signal and PPP support
- Ready-to-run μ CLinux Kernel 2.6.9 communication platform
- SD signal supported

Product Specifications


Hardware Specifications

Model	EM-1240 Embedded Module
CPU	Moxa ART ARM9 32-bit 192 MHz processor
RAM	16 MB
Flash	8 MB
LAN	Auto-sensing 10/100 Mbps × 2
LAN Protection	Built-in 1.5 KV magnetic isolation
Serial Ports	Four serial ports supporting RS-232/422/485 signals RS-232 signals: TxD, RxD, DTR, DSR, RTS, CTS, DCD, GND RS-422 signals: TxD+, TxD-, RxD+, RxD-, GND 4 wire RS-485 signals: TxD+, TxD-, RxD+, RxD-, GND 2 wire RS-485 signals: Data+, Data-, GND
	Serial Protection: 15 KV ESD for all signals
	Data bits: 5, 6, 7, 8
	Stop bit(s): 1, 1.5, 2
	Parity: None, even, odd, space, mark
	Flow Control: RTC/CTS, XON/XOFF
	Speed: 50 bps to 921.6 Kbps, supports Any Baudrate
Serial Console	RS-232 × 1, TxD, RxD, DTR, DSR, RTS, CTS, DCD, GND
Storage Expansion	SD signals for external Secure Digital (SD) socket connection
GPIO	GPIO × 10 (to enable GPIO, SD must be disabled.)
Real-time Clock	Yes
Watchdog Timer	Yes
Buzzer Signals	Buzzer signals reserved for external buzzer connection
LED Signals	LAN 10/100 × 2 on LAN Connector Reserve signals for the following LED connections: System Ready × 1 Serial Port Status × 4 pairs (TxD, RxD, 2 for each pair)
Reset Signal	Reserve signal for external "Reset to Default" button connection
Power Input	Accepts external 5 VDC through pin header
Dimensions (W × L)	90 × 80 mm
Operating temperature	-10 to 60°C (14 to 141°F), 5 to 95% RH
Storage temperature	-20 to 80°C (-4 to 176°F), 5 to 95% RH
Module Interface	Two 2 × 28 pin-headers; pitch: 1.27 × 1.27 (mm)

Software Specifications


Kernel	µClinux Kernel 2.6.9 Supports dynamic driver module load / unload
Protocol Stack	ARP, ICMP, IPV4, TCP, UDP, FTP, Telnet, SNMP V1/V2c, HTTP, CHAP, PAP, DHCP, NTP, NFS V2/V3, SMTP, Telnet, FTP, PPP, PPPoE
File System	JFFS2 for Kernel, Root File System (Read Only) and User Directory (Read / Write)
Msh	Minix shell command
pppd	Dial in/out over serial port daemon
PPPoE	Point-to-Point over Ethernet daemon
snmpd	SNMP V1/V2c Agent daemon
busybox	Linux normal command utility
Tinylogin	login and user manager utility
Telnetd	Telnet server daemon
telnet	Telnet client program
inetd	TCP server manager program
ftpd	FTP server program
ftp	FTP client program
boa	Web server daemon
ntpdate	Network Time Protocol client utility
Tool Chain	
Linux Tool Chain	Arm-elf-gcc (V2.95.3): C/C++ PC Cross Compiler uClibc (V0.9.26): POSIX standard C library

Hardware Block Diagram



Appearance

EM-1240 Embedded Module + Development Kit




EM-1240 Embedded Module

MOXA ART ARM9
Communication Processor




onboard 16 MB RAM

EM-1240 Development Kit




Dimensions

EM-1240 Embedded Module



EM-1240 Development Kit



Installing the EM-1240-LX

If you would like to use the EM-1240 Embedded Module and the EM-1240 Development Kit, insert the EM-1240 Embedded Module vertically onto the Development Kit. Note that the pin marked “JP4” on the Embedded Module must be matched with the pin marked “JP6” on the Development Kit; and the Pin marked “JP3” on the Embedded Module must be matched with the Pin marked “JP4” on the Development Kit. Be careful when inserting the module to avoid damaging the product.

LED Indicators

The following table explains the function of the five LED indicators located on the EM-1240-LX's top panel.

LED Name	LED Color	LED Function
Ready	Green	Power is on and functioning normally.
P1/P2 (Tx)	Green	Serial port 1 or 2 is transmitting data.
	Off	Serial port 1 or 2 is not transmitting data.
P1/P2 (Rx)	Yellow	Serial port 1 or 2 is receiving data.
	Off	Serial port 1 or 2 is not receiving data.

Wiring Requirements

This section describes how to connect the EM-1240-LX to serial devices.

You should pay attention to the following common safety precautions before proceeding with the installation of any electronic device:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.

NOTE: Do not run signal or communication wiring and power wiring in the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.

- Use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring that shares similar electrical characteristics can be bundled together.
- Keep input wiring and output wiring separate.
- It is advisable to label the wiring to all devices in the system.



ATTENTION

Safety First!

Be sure to disconnect the power cord before installing and/or wiring your EM-1240-LX.

Wiring Caution!

Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size.

If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

Temperature Caution!

Be careful when handling the EM-1240-LX. When plugged in, the EM-1240-LX's internal components generate heat, and consequently the outer casing may feel hot to the touch.

Connecting the Power

Connect the “live-wire” end of the 12-48 VDC power adaptor to the EM-1240-LX's terminal block. If the power is properly supplied, the “Ready” LED will glow a solid green after a 25 to 30 second delay.


Grounding the EM-1240-LX

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground wire from the ground screw to the grounding surface prior to connecting devices.



ATTENTION

This product should be mounted to a well-grounded mounting surface such as a metal panel.



SG: The *Shielded Ground* (sometimes called Protected Ground) contact is the left most contact of the 3-pin power terminal block connector when viewed from the angle shown here. Connect the SG wire to an appropriate grounded metal surface.

Connecting Data Transmission Cables

This section describes how to connect the EM-1240-LX to the network, serial devices, and serial COM terminal.

Connecting to the Network


Connect one end of the Ethernet cable to the EM-1240-LX's 10/100M Ethernet port and the other end of the cable to the Ethernet network. If the cable is properly connected, the EM-1240-LX will indicate a valid connection to the Ethernet in the following ways:

- The top-right LED on the connector glows a solid green when connected to a 100 Mbps Ethernet network.
- The top-left LED on the connector glows a solid orange when connected to a 10 Mbps Ethernet network.
- The LEDs will flash when Ethernet packets are being transmitted or received.

The 10/100 Mbps Ethernet LAN 1 and LAN 2 ports use 8-pin RJ45 connectors. Pinouts for these ports are given in the following diagram.

8-pin RJ45

10 Mbps indicator 100 Mbps indicator




Pin	Signal
1	ETx+
2	ETx-
3	ERx+
4	---
5	---
6	ERx-
7	---
8	---

Connecting to a Serial Device

Connect the serial cable between the EM-1240-LX and the serial device(s).

Serial ports P1 and P2 use male DB9 connectors, and can be configured for RS-232/422/485 by software. The pin assignments are shown in the following table:

DB9 Male Port



RS-232/422/485 Pinouts

Pin	RS-232	RS-422	RS-485 (4-wire)	RS-485 (2-wire)
1	DCD	TxDA(-)	TxDA(-)	---
2	RxD	TxDB(+)	TxDB(+)	---
3	TxD	RxDB(+)	RxDB(+)	DataB(+)
4	DTR	RxDA(-)	RxDA(-)	DataA(-)
5	GND	GND	GND	GND
6	DSR	---	---	---
7	RTS	---	---	---
8	CTS	---	---	---

Serial Console Port

The serial console port is a 4-pin pin-header RS-232 port. It is designed for serial console terminals, which are useful for identifying the EM-1240-LX boot up message.

Serial Console Port & Pinouts



Pin	Signal
1	TxD
2	RxD
3	NC
4	GND



Internal SD Socket

The EM-1240-LX provides an internal SD socket for storage expansion. It allows users to plug in a Secure Digital (SD) memory card compliant with the SD 1.0 standard for up to 1 GB of additional memory space. To install an additional SD card, you must first remove the EM-1240-LX's outer cover to access the slot. The internal SD socket is located on the backside of the EM-1240-LX's bottom board; you can find the SD plug-in slot at the right of the EM-1240-LX, lower than the cover screw. Plug the SD card into the socket directly and remember to press the SD card first if you want to take it out. Please note that the SD function shares the same chipset with the DIO. If you would like to enable the SD function, the DIO must be disabled. If you would like to enable the DIO, the SD function must be disabled.

Additional Functions

Reset Button

Press the **Reset** button on the EM-1240-DK continuously for at least 5 seconds to load the factory default configuration. After the factory default configuration has been loaded, the system will reboot automatically. We recommend that you only use this function if the software is not working properly and you want to load factory default settings. To reset an embedded Linux system, always use the software reboot command `/>reboot` to protect the integrity of data being transmitted or processed. The Reset button is not designed to hard reboot the EM-1240 Development Kit.



ATTENTION

Resetting to factory defaults will not format the user directory and erase all of the user's data. Loading factory defaults will only load the configuration file. The files in the EM-1240-LX that will be replaced include:

- a. /etc/boa.conf
- b. /etc/hosts
- c. /etc/inittab
- d. /etc/password
- e. /etc/ramfs.img
- f. /etc/resolv.conf
- g. /etc/version
- h. /etc/group
- i. /etc/inetd.conf
- j. /etc/motd
- k. /etc/protocols
- l. /etc/rc
- m. /etc/services
- n. /home/httpd/index.html



ATTENTION

This function only takes effect when the user directory is working correctly. If the user directory has crashed, the kernel will automatically load the factory defaults.

Real-time Clock

The EM-1240-LX's real time clock is powered by a lithium battery. We strongly recommend that you do not replace the lithium battery without the help of Moxa's support team. If the battery needs to be changed, contact the Moxa RMA service team for RMA service.



ATTENTION

The battery may explode if replaced by an incorrect type. To avoid this potential danger, always be sure to use the correct type of battery.

2

Getting Started

In this chapter, we explain the basic procedure for getting the EM-1240-LX connected and ready for your needs.

In this chapter we cover the following topics:

- ❑ **Powering on the EM-1240-LX**
- ❑ **Connecting the EM-1240-LX to a PC**
 - Console Port
 - Telnet
- ❑ **Configuring the Ethernet Interface**
- ❑ **Installing a Secure Digital (SD) Memory Card**
- ❑ **Developing Your Applications**
 - Installing the EM-1240-LX Tool Chain
 - Compiling Hello.c
 - Uploading “Hello” to the EM-1240-LX
 - Running “Hello” on the EM-1240-LX
 - Make File Example Code

Configuring the Ethernet Interface

In this section, we use the serial console to explain how to modify the EM-1240-LX's network settings.

1. Change directories by issuing the command `cd /etc`.



```
Product EM-1240 Series
For further information check:
http://www.moxa.com.tw/


# cd /etc
# |
```

State: OPEN CTS DSR RI DCD Got Break Signal

2. Type the command `vi rc` to use the VI Editor to edit the configuration file. The IP addresses for the EM-1240-LX's LAN1 and LAN2 are given as

```
ifconfig eth0 192.168.3.127
ifconfig eth1 192.168.4.127
```

as shown in the following figure. Edit these two lines to modify the static IP addresses.



```
COM8,19200,None,8,1,VT100
# /bin/sh
hostname moxa.com.tw
cat /etc/motd
ifconfig lo 127.0.0.1
ifconfig eth0 192.168.3.127 netmask 255.255.255.0
ifconfig eth1 192.168.4.127 netmask 255.255.255.0
route add default gw 192.168.3.254 dev eth0
#rtc clock to system clock
hwclock -s
#nfs portmap
portmap &
#factory & broadcast version
necid &
#simple snmp daemon
snmpd &

#Loading your driver here

#-->uart driver for /dev/ttyM0 /dev/ttyM1
#insmod /lib/modules/2.6.9-MoXaRt/kernel/drivers/char/mxser.ko

# set the serial port interface, now default set to RS232
# if you want to change, then you need modify following
"rc" line 1 of 34 --2%--
```

State: OPEN CTS DSR RI DCD Got Break Signal

3. You may also configure the EM-1240-LX to request IP addresses from a DHCP server. In this case, use the sharp sign (#) to comment out one or both “ifconfig” lines, and then add the setting about the “dhcpcd” into the rc file as below.

```
dhcpcd -p -a eth0 &
dhcpcd -p -a eth1 &
```

Note that the EM-1240-LX will send out DHCP broadcast packets, and then get the IP addresses from the first DHCP server that responds.

```
#!/bin/sh
hostname moxa.com.tw
cat /etc/motd
ifconfig lo 127.0.0.1
#ifconfig eth0 192.168.3.127 netmask 255.255.255.0
#ifconfig eth1 192.168.4.127 netmask 255.255.255.0
dhcpcd -p -a eth0 & #if you want DHCP, please set this
dhcpcd -p -a eth1 & #if you want DHCP, please set this
route add default gw 192.168.3.254 dev eth0
#rtc clock to system clock
hwclock -s
#nfs portmap
portmap &
#factory & broadcast version
necid &
#simple snmp daemon
snmpd &

#Loading your driver here

#-->uart driver for /dev/ttyM0 /dev/ttyM1
#insmod /lib/modules/2.6.9-MoXaRt/kernel/drivers/char/mxser.ko

"/etc/rc" [modified] line 1 of 36 --24--
```

4. Issue the vi “write” command to save the file, and then reboot. Since the EM-1240-LX only reads the “rc” file when booting up, you must reboot (e.g., by issuing the vi **reboot** command) for the changes to take affect.



ATTENTION

You may reset the IP address immediately by issuing the command

```
ifconfig eth0 192.168.5.127
```

(This will change the IP address of LAN1.) Issuing this command will NOT however update the “rc” file in the EM-1240-LX’s flash memory, so the next time you reboot, the IP address will revert to its previous value.


Installing a Secure Digital (SD) Memory Card

The EM-1240-LX provides an internal SD socket for storage expansion. To access this socket, perform the following steps to install the SD memory card.

Step 1: Find the exact location of the SD socket.

Step 2: Insert the SD card into the socket. Make sure the card is situated correctly.

Step 3: Push the SD card inward.



Step 4: Before using the SD card, check the `/etc/rc` file to ensure that the driver module for the SD card control is loaded. The loading sequence should be as follows:

```
insmod /lib/modules/2.6.9-MoXaRt/kernel/drivers/mmc/mmc_core.ko
insmod /lib/modules/2.6.9-MoXaRt/kernel/drivers/mmc/mmc_block.ko
insmod /lib/modules/2.6.9-MoXaRt/kernel/drivers/mmc/moxasd.ko
```

Step 5: To take out the SD memory card, press the SD card again. The card will pop out part of the way, after which you can pull it out directly.

Developing Your Applications

Step 1:

Connect the EM-1240-LX to a Linux PC.

Step 2:

Install Tool Chain (GNU Cross Compiler & uClibc).

Step 3:

Configure cross compiler and uClibc environment variables.

Step 4:

Code & compile your program.

Step 5:


Download program to the EM-1240-LX via FTP or NFS.

Step 6:

Debug the program. If the program is OK, proceed to Step 7. If the program needs to be modified, go back to Step 4.

Step 7:

Back up the user directory, and distribute the code to additional EM-1240-LX units.



Installing the EM-1240-LX Tool Chain

Linux

The PC must have the Linux Operating System pre-installed to install the EM-1240-LX Linux GNU Tool Chain. Debian 3.0R-Woody, Redhat 7.3/8.0 and compatible versions are recommended. The Tool Chain requires about 100 MB of hard disk space (on your PC). The EM-1240-LX Tool Chain can be found on the EM-1240-LX Document & Software CD. To install the Tool Chain, insert the CD into your PC and then issue the following command:

```
#mount -t iso9660 /dev/cdrom /mnt/cdrom
```

Next, run the following script from the root to install the compilers, linkers, and libraries in the `/usr/local` directory:

```
#sh /mnt/cdrom/tool-chain/linux/installer/arm-elf-moxa-toolchain-1.1.sh
```

The Tool Chain installation will take a few minutes to complete.



ATTENTION

The Tool Chain can be downloaded from Moxa's website. To do this, navigate to the EM-1240-LX product page, click the Documentation & Drivers link, and then click **Go** under Driver & Software Downloads.

Compiling Hello.c

The Tool Chain path is:

```
PATH=/usr/local/bin:$PATH
```

The EM-1240-LX CD includes several example programs. We use `Hello.c` to illustrate how to compile and run applications.

Issue the following commands from your PC to compile `Hello.c`:

```
# cd /tmp/  
# mkdir example  
# cp -r /mnt/cdrom/example/* /tmp/example
```

Go to the Hello subdirectory, and then issue the command `#make` to compile `Hello.c`. Finally, execute the program to generate `hello` and `hello.gdb`.

```
[root@localhost hello]# ls -al
total 20
drwxr-xr-x  2 root  root    4096 Aug 18 10:58 .
drwxr-xr-x  5 root  root    4096 Aug  5 10:34 ..
-rw-rw-rw-  1 root  root    1498 Jan  6  2004 elf2flt.ld
-rw-rw-rw-  1 root  root      74 Jan  6  2004 hello.c
-rw-rw-rw-  1 root  root    875 Jan  6  2004 Makefile
[root@localhost hello]# make
/usr/local/bin/arm-elf-gcc -g -O2 -pipe -Wall -I. -c -o hello.o hello.c
/usr/local/bin/arm-elf-gcc -o hello hello.o -g, -Wl, -T,/usr/local/arm-elf/lib/elf2flt.ld -elf2flt
[root@localhost hello]# ls -al
total 116
drwxr-xr-x  2 root  root    4096 Aug 18 10:59 .
drwxr-xr-x  5 root  root    4096 Aug  5 10:34 ..
-rw-rw-rw-  1 root  root    1498 Jan  6  2004 elf2flt.ld
-rwxr--r--  1 root  root   28624 Aug 18 10:59 hello
-rw-rw-rw-  1 root  root      74 Jan  6  2004 hello.c
-rwxr-xr-x  1 root  root   84543 Aug 18 10:59 hello.gdb
-rw-r--r--  1 root  root    7608 Aug 18 10:59 hello.o
-rw-rw-rw-  1 root  root    875 Jan  6  2004 Makefile
[root@localhost hello]#
```

Uploading “Hello” to the EM-1240-LX

To use FTP to upload `hello` to the EM-1240-LX, issue the following commands on the PC:

```
#ftp 192.168.3.127
ftp> cd /home
ftp> bin
ftp> put ./hello
ftp> quit
#telnet 192.168.3.127
```

```
230 User root logged in.
Remote system type is UNIX.
Using binary mode to transfer files.
ftp> ls
227 Entering Passive Mode (192,168,3,127,8,0)
150 Opening ASCII mode data connection for '/bin/ls'.
lrwxrwxrwx  1 0  0          9 home -> /mnt/home
lrwxrwxrwx  1 0  0          8 etc -> /mnt/etc
lrwxrwxrwx  1 0  0          8 tmp -> /var/tmp
drwxr-xr-x  1 0  0        32 ramdisk
drwxr-xr-x  1 0  0        32 _home
drwxr-xr-x  1 0  0        32 _etc
drwxr-xr-x  1 0  0          0 var
dr-xr-xr-x  2 0  0          0 proc
drwxr-xr-x  5 0  0       1024 mnt
drwxr-xr-x  1 0  0          32 dev
drwxr-xr-x  1 0  0          32 bin
drwxr-xr-x  1 0  0          32 lib
226 Transfer complete.
ftp> cd /home
250 CWD command successful.
ftp> pwd
257 "/mnt/home" is current directory.
ftp>
```

Running “Hello” on the EM-1240-LX

To run the **hello** program issue the following commands on the EM-1240-LX:

```
# chmod 755 hello
# ./hello
```

The words “hello world” are printed on the screen.

```

Telnet 192.168.3.127
##### # ##### ##### # ##### # #####
For further information check:
http://www.moxa.com/

Sash command shell (version 1.1.1)
/> cd home
/mnt/home> ls -al
-rw-r----- 1 0 0 28624 hello
drwxr-xr-x 2 0 0 1024 root
drwx----- 2 0 0 1024 httpd
drwxr-xr-x 5 0 0 1024 ..
drwxr-xr-x 4 0 0 1024 .
/mnt/home> chmod 755 hello
/mnt/home> ls -al
-rwxr-xr-x 1 0 0 28624 hello
drwxr-xr-x 2 0 0 1024 root
drwx----- 2 0 0 1024 httpd
drwxr-xr-x 5 0 0 1024 ..
drwxr-xr-x 4 0 0 1024 .
/mnt/home> ./hello
hello world!
/mnt/home> █

```



ATTENTION

Be sure to calculate the amount of Flash Memory used by the User File System in the Flash ROM. Use one of the following two commands to determine the amount of memory in use:

```
# df -k or # df
```

Filesystem	1k-blocks	Used	Available	Use%	Mounted on
rootfs	1525	1525	0	100%	/
/dev/rom0	1525	1525	0	100%	/
/dev/mtdblock2	4096	688	3408	17%	/mnt

If the flash memory is full, you will no longer be able to save data to the Flash ROM. To free up some memory, use the console cable to connect to the EM-1240-LX's serial console terminal, and then delete files from the Flash ROM.

Make File Example Code

The following Make File example codes are copied from the Hello example on the EM-1240-LX's CD-ROM.

```
srcdir = .
LD_FLAGS = -Wl,-elf2flt
LIBS =
CFLAGS =

# Change these if necessary

CC = arm-elf-gcc
CPP = arm-elf-gcc -E

all: hello

hello:
    $(CC) -o $@ $(CFLAGS) $(LD_FLAGS) $(LIBS) $@.c

clean:
    rm -f $(OBJS) hello core *.gdb
```

3

Software Package


This chapter includes information about the software that is used with EM-1240-LX Series products.

In this chapter, we cover the following topics:

- ❑ **EM-1240-LX Software Architecture**
 - Journaling Flash File System (JFFS2)
- ❑ **EM-1240-LX Software Package**

EM-1240-LX Software Architecture


The pre-installed μ CLinux Operating System used by the EM-1240-LX follows the standard μ CLinux architecture. This means that programs following the POSIX standard are easily ported to the EM-1240-LX with the GNU Tool Chain provided by www.uClinux.org. In addition to the Standard POSIX API, device drivers for the buzzer and UART for the serial ports are also included.



The EM-1240-LX's Flash ROM is divided into smaller partitions, including the Boot Loader, Linux Kernel & Root (/) File System Image, and User Directory partitions.

For most applications, users often spend a lot of time maintaining the operating system and modifying the system configuration. In order to save on the total cost of development and maintenance, the EM-1240-LX is specially designed to partition a "User Directory" for storing the user's system configuration parameters.

The EM-1240-LX has a built-in mechanism that prevents system crashes to help preserve system reliability. The procedure is described below.



When the Linux kernel boots up, the kernel mounts the root file system and then enables services and daemons. The kernel also looks for system configuration parameters via rc or inittab.

Normally, the kernel uses the User Directory to boot up the system. The kernel will only use the default configuration `_etc` & `_home` when the User Directory crashes.

The EM-1240-LX uses ROMFS for the Linux kernel image, Root File System, and Protected configuration, and uses JFFS2 for the User Directory.

The partition sizes are hard coded into the kernel binary. You must rebuild the kernel to change the partition sizes. The flash memory map is shown in the following table.

Flash Context	Flash Address	Size	Access control
Boot loader	0 – 0x3ffff	256 K	Read ONLY
Kernet & Root File System	0x40000– 0x3ffff	4 M	Read ONLY JFFS2
User Directory	0x400000 – 0x7ffff	4 M – 256 K	Read / Write JFFS2

Developers should store their own programs only to partitions `/etc`, `/home`, `/tmp`, and `/usr/bin`. In addition, executable files should be stored in `/usr/bin`, as doing so will allow developers to use hotkeys.

In addition to the flash file systems, a RAM based file system is mounted on `/var/`.

Journaling Flash File System (JFFS2)

The flash User Directory is formatted by the Journaling Flash File System (JFFS2), which places a compressed file system on the flash, transparent to the user.

Axis Communications in Sweden developed the Journaling Flash File System (JFFS2).

JFFS2 provides a file system directly on flash, rather than emulating a block device designed for use on flash-ROM chips. It recognizes flash-ROM chips' special write requirements, does wear-leveling to extend flash life, keeps the flash directory structure in RAM at all times, and implements a log-structured file system that is always consistent—even if the system crashes or unexpectedly powers down. It does not require `fsck` on boot up.

JFFS2, a later version of JFFS, provides improved wear-leveling and garbage-collection performance, improved RAM footprint and response to system-memory pressure, improved concurrency and support for suspending flash erases, marking of bad sectors with continued use of the remaining good sectors (thus enhancing the write-life of the devices), native data compression inside the file system design; and support for hard links.

Key features of JFFS2 are:

- Directly targeted to Flash ROM
- Robust
- Consistent across power failure
- No integrity scan (`fsck`) is required at boot time after normal or abnormal shutdown
- Explicit wear leveling
- Transparent compression

Although JFFS2 is a journaling file system, this does not preclude the loss of data. The file system will remain in a consistent state across power failures, and will always be mountable. However, if the board is powered down during a write, then the incomplete write will be rolled back on the next boot. Any writes that were already completed will not be affected.

Additional information about JFFS2 is available at

<http://sources.redhat.com/jffs2/jffs2.pdf>

<http://developer.axis.com/software/jffs/>

<http://www.linux-mtd.infradead.org/>

EM-1240-LX Software Package

bin	dev
upkernel	mtdblock1
passwd -> tinylogin	mtdr1
login -> tinylogin	mtd1
tinylogin	mtdblock0
telnetd	mtdr0
snmpd	mtd0
mail	cum1
sh	cum0
routed	ttyM1
netstat	ttyM0
arp	urandom
chat	random
pppd	zero
portmap	ttypf
ntpd	ttype
necid	ttypd
eraseall	ttypc
kversion	ttypb
init	ttypa
expand	ttyp9
inetd	ttyp8
hwclock	ttyp7
ftpd	ttyp6
ftp	ttyp5
mke2fs	ttyp4
e2fsck	ttyp3
discard	ttyp2
dhcpcd	ttyp1
cpu	ttyp0
busybox	ttyS0
boa	tty3
downramdisk	tty2
upramdisk	tty1
	tty0
	rom1
	rom0
	ptypf
	ptype
	ptypd
	ptypc
	ptypb
	ptypa
	ptyp9
	ptyp8
	ptyp7
	ptyp6
	ptyp5
	ptyp4
	ptyp3
	ptyp2
	ptyp1

bin	dev
	ptyp0 ppp pio rtc ram1 ram0 null kmem mem cua0 console tty

Configuring the EM-1240-LX

In this chapter, we describe how to configure the EM-1240-LX Series products.

The following topics are covered in this chapter:

- ❑ **Enabling and Disabling Daemons**
- ❑ **Adding a Web Page**
- ❑ **IPTABLES**
 - Observe and erase chain rules
 - Define policy for chain rules
 - Append or delete rules:
- ❑ **NAT**
 - NAT Example
 - Enabling NAT at Bootup
- ❑ **Configuring Dial-in/Dial-out Service**
 - Dial-out Service
 - Dial-in Service
- ❑ **Configuring PPPoE**
- ❑ **How to Mount a Remote NFS Server**
- ❑ **Dynamic Driver Module Load/Unload**
- ❑ **Upgrading the Kernel**
- ❑ **Upgrading the Root File System & User Directory**
- ❑ **Loading Factory Defaults**
- ❑ **Autostarting User Applications on Bootup**
- ❑ **Checking the Kernel and Root File System Versions**

Enabling and Disabling Daemons

The following daemons are enabled when the EM-1240-LX boots up for the first time.

- SNMP Agent daemon: **snmpd**
- Telnet Server / Client daemon: **telnetd**
- Internet Daemons: **inetd**
- FTP Server / Client daemon: **ftpd**
- WWW Server daemon: **boa**



ATTENTION

How to enable/disable telnet/ftp server

- Edit the file '/etc/inetd.conf'
Example (default enable):
discard dgram udp wait root /bin/discard
discard stream tcp nowait root /bin/discard
telnet stream tcp nowait root /bin/telnetd
ftp stream tcp nowait root /bin/ftpd -l
- Disable the daemon by typing '#' in front of the first character of the row.

How to enable/disable /etc/inittab www server

- Edit the file '/etc/inittab'
- Disable the www service by typing '#' in front of the first character of the row.

How to enable Network Time Protocol

ntpdate is a time adjusting client utility. The EM-1240-LX plays the role of Time client, and sends requests to the Network Time Server to request the correct time.

Set the time server address for adjusting the system time with the command:

```
/>ntpdate ntp_server_ip
```

Save the system time to the hardware's real time clock, with the command:

```
/>hwclock -w
```

Visit <http://www.ntp.org> for a recommended public NTP server list.

How to update the system time periodically with Network Time Protocol

- Create a shell script file that includes the following description.

```
#!/bin/sh  
ntpdate ntp_server_ip  
hwclock -w  
sleep 100 ← The minimum time is 100 ms.
```
- Save and make this shell script executable by typing

```
chmod 755 <shell-script_name>
```

Edit the file '/etc/inittab' by adding the following line:

```
ntp: unknown: /directory/<shell_script_name>
```

Adding a Web Page


Default Home Page address:

`/home/httpd/index.html`

You may change the default home page directory by editing the web server's configuration file, located at: `/etc/boa.conf`

Type the following command to edit the `boa.conf` file:

`/etc>vi boa.conf`



```
#
# A minimal config that makes the home page
# an unauthenticated CGI
#
ServerName nClinux
DocumentRoot /home/httpd
ScriptAlias /cgi-bin/ /home/httpd/cgi-bin/
Alias /img /home/httpd/img
# Auth /cgi-bin/cgi_demo /etc/config/config
AddType text/plain      txt
AddType image/gif       gif
AddType text/html       html
AddType text/html       htm
AddType text/xml        xml
AddType image/jpeg      jpe
AddType image/jpeg      jpeg
AddType image/jpeg      jpg
AddType image/x-icon    ico
~
~
```

To add your web page, place your home page in the following directory:

`/home/httpd/`

IPTABLES

IPTABLES is an administrative tool for setting up, maintaining, and inspecting the Linux kernel's IP packet filter rule tables. Several different tables are defined, with each table containing built-in chains and user-defined chains.

Each chain is a list of rules that apply to a certain type of packet. Each rule specifies the action to be taken with a matching packet. A rule (such as a jump to a user-defined chain in the same table) is called a "target."

The EM-1240-LX supports three types of IPTABLES tables: Filter tables, NAT tables, and Mangle tables:

A. **Filter Table**—includes three chains:

- INPUT chain
- OUTPUT chain
- FORWARD chain

B. **NAT Table**—includes three chains:

- PREROUTING chain—transfers the destination IP address (DNAT)
- POSTROUTING chain—works after the routing process and before the Ethernet device process to transfer the source IP address (SNAT)
- OUTPUT chain—produces local packets

sub-tables

Source NAT (SNAT)—changes the first source packet IP address

Destination NAT (DNAT)—changes the first destination packet IP address

MASQUERADE—a special form for SNAT. If one host can connect to the Internet, then other computers that connect to this host can connect to the Internet when the computer does not have an actual IP address.

REDIRECT—a special form of DNAT that re-sends packets to a local host independent of the destination IP address.


C. **Mangle Table**—includes two chains

PREROUTING chain—pre-processes packets before the routing process.

OUTPUT chain—processes packets after the routing process.

It has three extensions—TTL, MARK, TOS.

The following figure shows the IPTABLES hierarchy.



The EM-1240-LX supports the following sub-modules. Be sure to use the module that matches your application. You must load a module before you can use it. Use the **insmod** command to load a module.

x_tables	xt_contrack	xt_helper	xt_mark
xt_pkttype	xt_state	xt_tcpudp	xt_CLASSIFY
xt_dccp	xt_length	xt_MARK	xt_quota
xt_statistic	xt_comment	xt_dscp	xt_multiport
xt_realm	xt_string	xt_connbytes	xt_esp
xt_mac	xt_NFQUEUE	xt_sctp	xt_tcpmss
xt_limit			
arptable_filter	ip_nat	iptable_raw	ipt_hashlimit
ipt_owner	ipt_time	arp_tables	ip_nat_snmp_basic
ip_tables	ipt_iprange	ipt_recent	ipt_tos
arpt_mangle	ip_nat_tftp	ipt_addrtype	ipt_layer7
ipt_REDIRECT	ipt_TOS	ip_nat_amanda	iptable_filter
ipt_ah	ipt_LOG	ipt_REJECT	ipt_ttl
ip_nat_tftp	iptable_mangle	ipt_ecn	ipt_MASQUERADE
ipt_SAME	ipt_TTL	ip_nat_irc	iptable_nat
ipt_ECN	ipt_NETMAP	ipt_TCPMSS	ipt_ULONG

NOTE The EM-1240-LX does NOT support IPV6 and ipchains. IPTABLES supports packet filtering or NAT. Take care when setting up the IPTABLES rules. If the rules are not correct, remote hosts that connect via a LAN or PPP may be denied access. We recommend using the Serial Console to set up IPTABLES.

Click on the following links for more information about iptables.

<http://www.linuxguruz.com/iptables/>
<http://www.netfilter.org/documentation/HOWTO//packet-filtering-HOWTO.html>

Since the IPTABLES command is very complex, to illustrate the IPTABLES syntax we have divided our discussion of the various rules into three categories: **Observe and erase chain rules**, **Define policy rules**, and **Append or delete rules**.

Observe and erase chain rules

Usage:

```
# iptables [-t tables] [-L] [-n]
-t tables:      Table to manipulate (default: 'filter'); example: nat or filter.
-L [chain]: List List all rules in selected chains. If no chain is selected, all chains are listed.
-n:            Numeric output of addresses and ports.

# iptables [-t tables] [-FXZ]
-F: Flush the selected chain (all the chains in the table if none is listed).
-X: Delete the specified user-defined chain.
-Z: Set the packet and byte counters in all chains to zero.
```

Examples:

```
# iptables -L -n
```

In this example, since we do not use the `-t` parameter, the system uses the default 'filter' table. Three chains are included: INPUT, OUTPUT, and FORWARD. INPUT chains are accepted automatically, and all connections are accepted without being filtered.

```
#iptables -F
#iptables -X
#iptables -Z
```

Define policy for chain rules**Usage:**

```
# iptables [-t tables] [-P] [INPUT, OUTPUT, FORWARD, PREROUTING, OUTPUT, POSTROUTING]
[ACCEPT, DROP]
```

`-P:` Set the policy for the chain to the given target.
INPUT: For packets coming into the EM-1240-LX.
OUTPUT: For locally-generated packets.
FORWARD: For packets routed out through the EM-1240-LX.
PREROUTING: To alter packets as soon as they come in.
POSTROUTING: To alter packets as they are about to be sent out.

Examples:

```
#iptables -P INPUT DROP
#iptables -P OUTPUT ACCEPT
#iptables -P FORWARD ACCEPT
#iptables -t nat -P PREROUTING ACCEPT
#iptables -t nat -P OUTPUT ACCEPT
#iptables -t nat -P POSTROUTING ACCEPT
```

In this example, the policy accepts outgoing packets and denies incoming packets.

Append or delete rules:**Usage:**

```
# iptables [-t table] [-AI] [INPUT, OUTPUT, FORWARD] [-i interface] [-p tcp, udp, icmp,
all] [-s IP/network] [--sport ports] [-d IP/network] [--dport ports] -j [ACCEPT. DROP]
```

`-A:` Append one or more rules to the end of the selected chain.
`-I:` Insert one or more rules in the selected chain as the given rule number.
`-i:` Name of an interface via which a packet is going to be received.
`-o:` Name of an interface via which a packet is going to be sent.
`-p:` The protocol of the rule or of the packet to check.
`-s:` Source address (network name, host name, network IP address, or plain IP address).
`--sport:` Source port number.
`-d:` Destination address.
`--dport:` Destination port number.
`-j:` Jump target. Specifies the target of the rules; i.e., how to handle matched packets. For example, ACCEPT the packet, DROP the packet, or LOG the packet.

Examples:

Example 1: Accept all packets from lo interface.

```
# iptables -A INPUT -i lo -j ACCEPT
```

Example 2: Accept TCP packets from 192.168.0.1.

```
# iptables -A INPUT -i eth0 -p tcp -s 192.168.0.1 -j ACCEPT
```

Example 3: Accept TCP packets from Class C network 192.168.1.0/24.

```
# iptables -A INPUT -i eth0 -p tcp -s 192.168.1.0/24 -j ACCEPT
```

Example 4: Drop TCP packets from 192.168.1.25.

```
# iptables -A INPUT -i eth0 -p tcp -s 192.168.1.25 -j DROP
```

Example 5: Drop TCP packets addressed for port 21.

```
# iptables -A INPUT -i eth0 -p tcp --dport 21 -j DROP
```

Example 6: Accept TCP packets from 192.168.0.24 to the EM-1240-LX's port 137, 138, 139

```
# iptables -A INPUT -i eth0 -p tcp -s 192.168.0.24 --dport 137:139 -j ACCEPT
```

Example 7: Log TCP packets that visit EM-1240-LX's port 25.

```
# iptables -A INPUT -i eth0 -p all -m mac --mac-source 01:02:03:04:05:06 -j DROP
```

Example 8: Drop all packets from MAC address 01:02:03:04:05:06.

```
# iptables -A INPUT -i eth0 -p all -m mac -mac-source 01:02:03:04:05:06 -j DROP
```

NAT

NAT (Network Address Translation) protocol translates IP addresses used on one network into different IP addresses used on another network. One network is designated the inside network and the other is the outside network. Typically, the EM-1240-LX connects several devices on a network and maps local inside network addresses to one or more global outside IP addresses, and remaps the global IP addresses on incoming packets back into local IP addresses.

NOTE

Click the following link for more information about iptables and NAT:

<http://www.netfilter.org/documentation/HOWTO/NAT-HOWTO.html>

NAT Example

The IP addresses of all packets leaving LAN1 are changed to 192.168.3.127 (you will need to load the module `ipt_MASQUERADE`):

1. First load the following device drivers:

- `x_tables.ko`
- `xt_multiport.ko`
- `xt_MARK.ko`
- `xt_tcpudp.ko`
- `ip_tables.ko`
- `ip_nat.ko`
- `iptables_nat.ko`
- `ipt_MASQUERADE.ko`

2. `#echo 1 > /proc/sys/net/ipv4/ip_forward`

3. `#iptables -t nat -A POSTROUTING -o eth0 -j SNAT --to-source 192.168.3.127`
or

4. `#iptables -t nat -A POSTROUTING -o eth0 -j MASQUERADE`

Enabling NAT at Bootup

In most real world situations, you should use a simple shell script to enable NAT when the EM-1240-LX boots up, as indicated by the following:

1. setting iptables
2. `iptables-save > /home/xxx.file` (xxx.file is the user defined file name)
3. `vi /etc/rc`
4. Append `echo 1 > /proc/sys/net/ipv4/ip_forward`
5. Append `iptables-restore /home/xxx.file` (xxx.file is the user defined file name)

Configuring Dial-in/Dial-out Service

Dial-out Service

Direct cable connection:

- *Without* username and password, use:

```
/>pppd connect 'chat -v' /dev/ttyM0 38400 crtscts&
```
- *With* username and password, use:

```
/>pppd connect 'chat -v' user xxxxxx password xxxxxx /dev/ttyM0 38400 crtscts&
```

Connect Using a Modem:

- Use:

```
/>pppd connect 'chat -v ATDT<phone_number> CONNECT' user xxxxxx password xxxxxx /dev/ttyM0 38400 crtscts&
```



ATTENTION

If dial out fails, the pppd connection will be blocked, and users will need to shut down pppd, and re-dial. Since the return value is always OK (regardless of whether or not the connection is blocked), the API must be set up to check the network status to determine if the connection is complete.

Dial-in Service

Direct cable connection:

- Use either of the following:

```
/>pppd <Local_IP_Address>:<Remote_IP_Address> /dev/ttyM1 38400 local crtscts  
or  
/>pppd <Local_IP_Address>:<Remote_IP_Address> /dev/ttyM0 38400 local crtscts login  
auth
```

Connect Using a Modem:

- Use:

```
/>pppd connect 'chat -v AT CONNECT' <local_IP_Address>:<Remote_IP_Address> /dev/ttyM0  
38400 crtscts login auth
```

Configuring PPPoE

PPPoE relies on two widely accepted standards: PPP and Ethernet, which permits the use of PPPoE(Point-to-Point Over Ethernet).

PPPoE is a specification for connecting users on an Ethernet to the Internet through a common broadband medium, such as a single DSL line, wireless device or cable modem, used by many ADSL service providers. All users on the Ethernet share a common connection, so the Ethernet principles that support multiple users on a LAN combine with the PPP principles, which apply to serial connections.

- Create the Connection:

```
/>pppd pty "pppoe -I <ETHERNET_INTERFACE> -m 1412" user <USER_NAME> password  
<USER_PASSWORD>&
```

<ETHERNET_INTERFACE>: Ethernet card connected to ADSL modem, for example, eth0
 <USER_NAME>: User account, for example, moxa@adsl.net
 <USER_PASSWORD>: Password for user account

To check if PPPoE is successfully connected, use the command:

- `/>ifconfig ppp0`

How to Mount a Remote NFS Server

Currently, the EM-1240-LX only supports NFS (Network File System) clients. Users can open NFS service on a Linux PC to enable the EM-1240-LX to push data to it. The EM-1240-LX can use NFS to mount a remote disk as a local disk for data or log purposes.

1. First, the NFS server must open an export directory and allow access to the IP address. Edit the file “/etc/exports” on your Linux PC, and then run the NFS daemon. The following example gives one possibility (refer to the NFS-HOWTO document at <http://nfs.sourceforge.net/nfs-howto/server.html>):

```
/home/usr 192.168.3.1 (rw,no_root_squash,no_all_squash)
```

2. The EM-1240-LX must run the “portmap” utility. This program is enabled by default in the “/etc/rc” file. Use the following command to mount the remote NFS server:

```
/>mount -t nfs <remote-ip>:<remote-export-directory> <local-directory>
```

Dynamic Driver Module Load/Unload

Besides supporting traditional static drivers, the EM-1240-LX also supports the dynamic driver module load / unload mechanism. It allows users to load a special driver into the kernel to enable hardware features for specific applications. To load / unload a dynamic driver module, use the following commands.

Load module:

```
/>insmod <module-directory>/<module file name>
```

For example, to load the UART driver, type the following command:

```
/>insmod /lib/modules/2.6.9-MoXaRt/kernel/drivers/char/mxser.ko
```

Show module list:

```
/>lsmod
```

Unload module:

```
/>rmmod <module-name listed by lsmod command>
```

For example, to unload the UART driver, type the following command:

```
/>rmmod mxser
```

For the EM-1240-LX, the factory default is to load the UART driver **mxser.ko**. An additional driver module for controlling the SD/MMC memory card is loaded for the EM-1240-LX. The location and file name for these driver modules is given below.

UART:

```
/lib/modules/2.6.9-MoXaRt/kernel/drivers/char/mxser.ko
```

SD/MMC:

```
/lib/modules/2.6.9-MoXaRt/kernel/drivers/mmc/mmc_core.ko
```

```
/lib/modules/2.6.9-MoXaRt/kernel/drivers/mmc/mmc_block.ko
```

```
/lib/modules/2.6.9-MoXaRt/kernel/drivers/mmc/moxasd.ko
```

Upgrading the Kernel

The EM-1240-LX kernel is **em1240-1.x.bin**, which can be downloaded from www.moxa.com. You must first download this file to your PC, and then use Console Terminal or Telnet Console to copy the file to the EM-1240-LX.

You can save this file to the EM-1240-LX's RAM disk, and then upgrade the kernel. The following is a step-by-step example.

To enable the RAM disk, use the following command:

```
/>upramdisk
```

As illustrated below, after executing "upramdisk", you may use "mount" to determine if the new ramdisk was created successfully or not.

```
# upramdisk
# mount
/dev/mtdblock2 on / type jffs2 (ro,noatime)
/proc on /proc type proc (rw,nodiratime)
/dev/ram0 on /var type ext2 (rw)
/dev/mtdblock3 on /var/tmp type jffs2 (rw,noatime)
/dev/mtdblock3 on /home type jffs2 (rw,noatime)
/dev/mtdblock3 on /etc type jffs2 (rw,noatime)
/dev/mtdblock3 on /usr/bin type jffs2 (rw,noatime)
/dev/ram0 on /ramdisk type ramfs (rw)
# |
```

Use the following command to navigate to the device node:

```
/>cd ramdisk
```

Use the built-in FTP client to download the file **em1240-1.x.bin** from the PC.

```
/ramdisk>ftp <destination PC's IP>
Login Name: xxxx
Login Password: xxxx
ftp> bin
ftp> get em1240-1.x.bin
```

Use the **upkernel** command to upgrade the kernel and root file system.

```
/ramdisk>upkernel em1240-1.x.bin
/ramdisk>reboot
```

```
# upramdisk
# cd /ramdisk
# upkernel em1240-1.0.bin
To check the source file context.
The kernel source file is OK.
The version is 1.0.
This step will destory your old kernel.
Do you want to continue it ? (Y/N) : Y
Formating disk !!!
Erased 2048 Kibyte @ 0 -- 100% complete.
Format OK. Now update the kernel.
Please wait ...
Update the kernel OK. Please restart system.
#
```

Upgrading the Root File System & User Directory

The EM-1240-LX uses JFFS2 for the root file system and user directory. By default, the root file system is pre-set to READ only. The EM-1240-LX provides a read/write user's directory in the JFFS2 file system. By using this user's directory, the system configuration file and user's program can be stored on this disk.

Search the EM-1240-LX's CD-ROM for the latest user directory file, or download the file from www.moxa.com. The format is **em1240-1.x.dsk**. You must download this file to a PC first, and then use Console Terminal or Telnet Console to copy the file to the EM-1240-LX.


You can save this file to the EM-1240-LX's RAM disk, and then upgrade the user directory. The following is a step-by-step example.

To enable the RAM disk, use the following commands.

```
/>upramdisk  
>cd ramdisk
```

Use the built-in FTP client to download the em1240-1.x.dsk file from the PC.

```
/ramdisk>ftp <destination PC's IP>  
Login Name: xxxx  
Login Password: xxxx  
ftp> bin  
ftp> get em1240-1.x.dsk  
ftp>quit  
/ramdisk>upkernel /ramdisk/em1240-1.x.dsk  
/reboot
```



```
# upkernel em1240-1.0.dsk  
To check the source file context.  
The firmware source file is OK.  
The version is 1.0.  
This step will destroy your old kernel.  
Do you want to continue it ? (Y/N) : Y  
Formating disk !!!  
Erased 2560 Kibyte @ 0 -- 100% complete.  
Format OK. Now update the root filesystem.  
Please wait ...  
Update the root file system OK. Please push the reset button.  
# -
```

Loading Factory Defaults

The easiest way to “Load Factory Defaults” is with the “Upgrade User directory” operation.

Refer to the previous section, “Upgrading the Root File System & User Directory,” for an introduction.

You may also press the RESET button for more than 5 seconds to load the factory default configuration, or input the command “ldfactory” from the Telnet console to restore the factory defaults.

Autostarting User Applications on Bootup

Edit the `/etc/rc` file by adding your application program. E.g.,

```
/ap-directory/ap-program &
```

Checking the Kernel and Root File System Versions

Use the following commands to check the version of the kernel and root file system:

To check the kernel version:

```
/>kversion
```

To check the root file system (firmware) version of the EM-1240-LX, type:

```
/>fsversion
```

You may also check the user directory version of the EM-1240-LX by using the following command:

```
/>cat /etc/version
```

5

EM-1240-LX Device API

In this chapter, we discuss the Device API for the EM-1240-LX Series. We introduce the APIs for the following functions:

- RTC (Real-time Clock)**
- Buzzer**
- UART Interface**
- GPIO**

RTC (Real-time Clock)

The device node is located at `/dev/rtc`. The EM-1240-LX supports μ Clinux standard simple RTC control. You must include `<linux/rtc.h>` to use these functions.

- Function: `RTC_RD_TIME`

```
int ioctl(fd, RTC_RD_TIME, struct rtc_time *time);
```

 Description: Reads time information from RTC.
- Function: `RTC_SET_TIME`

```
int ioctl(fd, RTC_SET_TIME, struct rtc_time *time);
```

 Description: Sets RTC time.

Buzzer

The device node is located at `/dev/console`. The EM-1240-LX supports μ Clinux standard buzzer control. The EM-1240-LX's buzzer runs at a fixed frequency of 100 Hz. You must include `<sys/kd.h>` to use these functions.

- Function: `KDMKTONE`

```
ioctl(fd, KDMKTONE, unsigned int arg);
```

 Description: Buzzer will beep, as stipulated by the function arguments.

UART Interface

The normal tty device node is located at `/dev/ttyM0...ttyM1`, and the modem tty device node is located at `/dev/com0 ... com1`. The EM-1240-LX Series supports μ Clinux standard termios control. The Moxa UART Device API supports configurations `ttyM0` to `ttyM1`, as RS-232/422/485. To use these functions, after the Tool Chain package is installed, include `<moxadevice.h>` in your application.

- ```
#define RS232_MODE 0
#define RS485_2WIRE_MODE 1
#define RS422_MODE 2
#define RS485_4WIRE_MODE 3
```
- Function: `MOXA_SET_OP_MODE`  

```
int mode;
mode=which mode you want to set;
int ioctl(fd, MOXA_SET_OP_MODE, &mode)
```

 Description: Sets the interface mode.
  - Function: `MOXA_GET_OP_MODE`  

```
int mode;
int ioctl(fd, MOXA_GET_OP_MODE, &mode)
```

 Description: Gets the interface mode.

## GPIO

GPIO stands for General Purpose I/O. GPIOs are user-programmable, and can be used for either digital input or digital output, since the signals are all in TTL format.

### Moxa GPIO API

Moxa provides an API library with static link for customers using the EM-1220 or EM-1240 (note that dynamic link is not supported). Users can use source code provided by Moxa so that the `ioctl()` command can be used by the operating system to communicate with drivers.

### API List

#### **int get\_gpio\_mode(unsigned int pio)**

--to check if the current GPIO setting is DI or DO.

#### **Input:**

**unsigned int pio** - GPIO port number

Each GPIO point will be regarded as a port. We support from Port 0 to Port 9 for the EM-1240, and from Port 0 to Port 7 for the EM-1220.

#### **Output:**

1 represents DI.  
0 represents DO.

#### **Return:**

< 0 is wrong.  
= 0 is correct.

#### **int get\_gpio\_data(unsigned int pio)**

--to check the current status of the GPIO, either high or low voltage.

#### **Input:**

**unsigned int pio** - GPIO port number

Each GPIO point will be regarded as a port. We support from Port 0 to Port 9 for the EM-1240, and from Port 0 to Port 7 for the EM-1220.

#### **Output:**

1 represents high.  
0 represents low.

#### **Return:**

< 0 is wrong.  
= 0 is correct.

**int set\_gpio\_mode(unsigned int pio, int mode)**

--to configure GPIO ports to be DI ports or DO ports.

**Input:**

**unsigned int pio** - GPIO port number

Each GPIO point will be regarded as a port. We support from Port 0 to Port 9 for the EM-1240, and from Port 0 to Port 7 for the EM-1220.

**int mode**

1 represents DI.

0 represents DO.

**Output:**

1 represents high.

0 represents low.

**Return:**

< 0 is wrong.

= 0 is correct.

**int set\_gpio\_data(unsigned int pio, int data)**

--to check the current status of the GPIO, either high or low voltage, used when the GPIO points are configured as DO.

**Input:**

**unsigned int pio** - GPIO port number

Each GPIO point will be regarded as a port. We support from Port 0 to Port 9 for the EM-1240, and from Port 0 to Port 7 for the EM-1220.

**int data**

1 represents high.

0 represents low.

**Output:**

1 represents high.

0 represents low.

**Return:**

< 0 is wrong.

= 0 is correct.

## How to use the GPIO

1. The device driver must be loaded.  
> insmod gpio.ko
2. The program must include <moxadevice.h> and link to libmoxalib.a. Here is an example:  
> arm-elf-gcc -wl, -elf2flt -o TestGpioAp TestGpioAp.c -lmoxalib -lpthread

## Limits

1. Both the SD card and GPIO share the same signals. To enable the GPIO, the SD card must be disabled, and vice versa. Drivers will not automatically check if the signal is from the SD or GPIO; users must determine where the signal comes from before using the signal.
2. Both **moxaddevice.h** and **libmoxalib.a** are supported in Tool Chain v1.6 and newer versions.

## GPIO Library Source Code

```

/*
 * History:
 * Date Author Comment
 * 12-06-2005 Victor Yu. Create it.
 */
#include <stdio.h>
#include <stdlib.h>
#include <fcntl.h>

// following about GPIO API implement
#define GPIO_DEVICE_NODE "/dev/pio"

#define IOCTL_GPIO_GET_MODE 1
#define IOCTL_GPIO_SET_MODE 2
#define IOCTL_GPIO_GET_DATA 3
#define IOCTL_GPIO_SET_DATA 4

#define MAX_GPIO 10
#define GPIO_NO_ERROR -1 // the GPIO number error
#define GPIO_MODE_ERROR -2 // the GPIO mode error
#define GPIO_DATA_ERROR -3 // the GPIO data error
#define GPIO_NODE_ERROR -4 // open GPIO device node error
#define GPIO_ERROR -5 // some error, get error number from errno
#define GPIO_INPUT 1 // the GPIO mode is input
#define GPIO_OUTPUT 0 // the GPIO mode is output
#define GPIO_HIGH 1 // the GPIO data is high
#define GPIO_LOW 0 // the GPIO data is low
#define GPIO_OK 0 // function is OK

#define CHECK_GPIO_NO(p) { \
 if ((p) >= MAX_GPIO) \
 return GPIO_NO_ERROR; \
}
#define CHECK_GPIO_MODE(m) { \
 if ((m) != GPIO_INPUT && (m) != GPIO_OUTPUT) \
 return GPIO_MODE_ERROR; \
}

#define CHECK_GPIO_DATA(d) { \
 if ((d) != GPIO_HIGH && (d) != GPIO_LOW) \
 return GPIO_DATA_ERROR; \
}

```

```

typedef struct gpio_set_struct {
 int io_number;
 int mode_data;
} gpio_t;

/*
 * To get the GPIO mode now.
 * Input: unsigned int pio - the GPIO number, from 0 to MAX_GPIO-1
 * Output: < 0 - some error
 * 1 - input
 * 0 - output
 */
int get_gpio_mode(unsigned int gpio_no)
{
 int fd;
 gpio_t pset;

 CHECK_GPIO_NO(gpio_no);
 fd = open(GPIO_DEVICE_NODE, O_RDWR);
 if (fd < 0)
 return GPIO_NODE_ERROR;
 pset.io_number = gpio_no;
 if (ioctl(fd, IOCTL_GPIO_GET_MODE, &pset) != 0) {
 close(fd);
 return GPIO_ERROR;
 }
 close(fd);
 return pset.mode_data;
}

/*
 * To get the GPIO data now.
 * Input: unsigned int pio - the GPIO number, from 0 to MAX_GPIO-1
 * Output: < 0 - some error
 * 1 - high
 * 0 - low
 */
int get_gpio_data(unsigned int gpio_no)
{
 int fd;
 gpio_t pset;
 CHECK_GPIO_NO(gpio_no);
 fd = open(GPIO_DEVICE_NODE, O_RDWR);
 if (fd < 0)
 return GPIO_NODE_ERROR;
 pset.io_number = gpio_no;
 if (ioctl(fd, IOCTL_GPIO_GET_DATA, &pset) != 0) {

```

```

 close(fd);
 return GPIO_ERROR;
 }
 close(fd);
 return pset.mode_data;
}

/*
 * To set the GPIO now mode.
 * Input: unsigned int pio - the GPIO number, from 0 to MAX_GPIO-1
 * int mode - want to set mode, 1 for input, 0 for output
 * Output: < 0 - some error
 * = 0 - OK
 */
int set_gpio_mode(unsigned int gpio_no, int mode)

{
 int fd;
 gpio_t pset;

 CHECK_GPIO_NO(gpio_no);
 CHECK_GPIO_MODE(mode);
 fd = open(GPIO_DEVICE_NODE, O_RDWR);
 if (fd < 0)
 return GPIO_NODE_ERROR;
 pset.io_number = gpio_no;
 pset.mode_data = mode;
 if (ioctl(fd, IOCTL_GPIO_SET_MODE, &pset) != 0) {
 close(fd);
 return GPIO_ERROR;
 }
 close(fd);
 return GPIO_OK;
}

/*
 * To set the GPIO now data.
 * Input: unsigned int pio - the GPIO number, from 0 to MAX_GPIO-1
 * int data - 1 for high, 0 for low
 * Output: < 0 - some error
 * = 0 - OK
 */
int set_gpio_data(unsigned int gpio_no, int data)
{
 int fd;
 gpio_t pset;

```

```
CHECK_GPIO_NO(gpio_no);
CHECK_GPIO_DATA(data);
fd = open(GPIO_DEVICE_NODE, O_RDWR);
if (fd < 0)
 return GPIO_NODE_ERROR;
pset.io_number = gpio_no;
pset.mode_data = data;
if (ioctl(fd, IOCTL_GPIO_SET_DATA, &pset) != 0) {
 close(fd);
 return GPIO_ERROR;
}
close(fd);
return GPIO_OK;
}
```

# A

## System Commands

---

### µClinux normal command utility collection

#### File manager

|              |                                                                           |
|--------------|---------------------------------------------------------------------------|
| <b>cp</b>    | copy file                                                                 |
| <b>ls</b>    | list file                                                                 |
| <b>ln</b>    | make symbolic link file                                                   |
| <b>mount</b> | mount and check file system                                               |
| <b>rm</b>    | delete file                                                               |
| <b>chmod</b> | change file owner & group & user                                          |
| <b>chown</b> | change file owner                                                         |
| <b>chgrp</b> | change file group                                                         |
| <b>sync</b>  | sync file system; save system file buffer to hardware                     |
| <b>mv</b>    | move file                                                                 |
| <b>pwd</b>   | display active file directly                                              |
| <b>df</b>    | list active file system space                                             |
| <b>du</b>    | estimate file space usage                                                 |
| <b>mkdir</b> | make new directory                                                        |
| <b>rmdir</b> | delete directory                                                          |
| <b>head</b>  | print the first 10 lines of each file to standard output                  |
| <b>tail</b>  | print the last 10 lines of each file to standard output                   |
| <b>touch</b> | update the access and modification times of each file to the current time |

#### Editor

|             |                                           |
|-------------|-------------------------------------------|
| <b>vi</b>   | text editor                               |
| <b>cat</b>  | dump file context                         |
| <b>grep</b> | print lines matching a pattern            |
| <b>cut</b>  | remove sections from each line of files   |
| <b>find</b> | search for files in a directory hierarchy |
| <b>more</b> | dump file by one page                     |
| <b>test</b> | test if file exists or not                |
| <b>echo</b> | echo string                               |

## Network

|                 |                                   |
|-----------------|-----------------------------------|
| <b>ping</b>     | ping to test network              |
| <b>route</b>    | routing table manager             |
| <b>netstat</b>  | display network status            |
| <b>ifconfig</b> | set network IP address            |
| <b>tftp</b>     | tftp protocol                     |
| <b>telnet</b>   | user interface to TELNET protocol |
| <b>ftp</b>      | file transfer protocol            |
| <b>iptables</b> | iptables command                  |

## Process

|                |                         |
|----------------|-------------------------|
| <b>kill</b>    | kill process            |
| <b>killall</b> | kill process by name    |
| <b>ps</b>      | report process status   |
| <b>sleep</b>   | suspend command on time |

## Other

|                           |                                         |
|---------------------------|-----------------------------------------|
| <b>dmesg</b>              | dump kernel log message                 |
| <b>stty</b>               | set serial port                         |
| <b>mknod</b>              | make device node                        |
| <b>free</b>               | display system memory usage             |
| <b>date</b>               | print or set the system date and time   |
| <b>env</b>                | run a program in a modified environment |
| <b>clear</b>              | clear the terminal screen               |
| <b>reboot</b>             | reboot / power off/on the server        |
| <b>halt</b>               | halt the server                         |
| <b>gzip, gunzip, zcat</b> | compress or expand files                |
| <b>hostname</b>           | show system's host name                 |
| <b>tar</b>                | tar archiving utility                   |

## Moxa Special Utilities

|                         |                             |
|-------------------------|-----------------------------|
| <b>cat /etc/version</b> | show user directory version |
| <b>upramdisk</b>        | mount ramdisk               |
| <b>downramdisk</b>      | unmount ramdisk             |
| <b>kversion</b>         | show kernel version         |
| <b>setinterface</b>     | set UART interfaces program |

# B

## SNMP Agent with MIB II & RS-232 Like Group

---

The EM-1240-LX has a built-in SNMP (Simple Network Management Protocol) agent that supports RFC1317 RS-232 like group and RFC 1213 MIB-II. The following table lists the variable implementation for the EM-1240-LX.

The full SNMP object ID of EM-1240-LX is **.iso.3.6.1.4.1.8691.12.7112** and **.iso.3.6.1.4.1.8691.12.1240**.

Note: The EM-1240-LX does not support SNMP trap.

### RFC1213 MIB-II supported SNMP variables:

| system MIB  | interface MIB     | at MIB        | icmp MIB            |
|-------------|-------------------|---------------|---------------------|
| sysDescr    | ifNumber          | atTable       | icmpInMsgs          |
| sysObjectID | ifTable           | atIfIndex     | icmpInErrors        |
| sysUpTime   | ifIndex           |               | icmpInDestUnreachs  |
| sysContact  | ifDescr           | atPhysAddress | icmpInTimeExcds     |
| sysName     | ifType            | atNetAddress  | icmpInParmProbs     |
| sysLocation | ifMtu             |               | icmpInSrcQuenchs    |
| sysServices | ifSpeed           |               | icmpInRedirects     |
|             | ifPhysAddress     |               | icmpInEchos         |
|             | ifAdminStatus     |               | icmpInEchoReps      |
|             | ifOperStatus      |               | icmpInTimestamps    |
|             | ifLastChange      |               | icmpInAddrMasks     |
|             | ifInOctets        |               | icmpInAddrMaskReps  |
|             | ifInUcastPkts     |               | icmpOutMsgs         |
|             | ifInNUcastPkts    |               | icmpOutErrors       |
|             | ifInDiscards      |               | icmpOutDestUnreachs |
|             | ifInErrors        |               | icmpOutTimeExcds    |
|             | ifInUnknownProtos |               | icmpOutParmProbs    |
|             | ifOutOctets       |               | icmpOutSrcQuenchs   |
|             | ifOutUcastPkts    |               | icmpOutRedirects    |
|             | ifOutNUcastPkts   |               | icmpOutEchos        |
|             | ifOutDiscards     |               | icmpOutEchoReps     |
|             | ifOutErrors       |               | icmpOutTimestamps   |
|             | ifOutQLen         |               | icmpOutAddrMasks    |
|             | ifSpecific        |               | icmpOutAddrmaskReps |

| ip MIB                  | tcp MIB             | udp MIB         |
|-------------------------|---------------------|-----------------|
| ipForwarding            | tcpRtoAlgorithm     | udpInDatagrams  |
| ipDefaultTTL            | tcpRtoMin           | udpNoPorts      |
| ipInReceives            | tcpRtoMax           | udpInErrors     |
| ipInHdrErrors           | tcpMaxConn          | udpOutDatagrams |
| ipInAddrErrors          | tcpActiveOpens      | udpTable        |
| ipForwDatagrams         | tcpPassiveOpens     | udpLocalAddress |
| ipInUnknownProtos       | tcpAttemptFails     | udpLocalPort    |
| ipInDiscards            | tcpEstabResets      |                 |
| ipInDelivers            | tcpCurrEstab        |                 |
| ipOutRequests           | tcpInSegs           |                 |
| ipOutDiscards           | tcpOutSegs          |                 |
| ipOutNoRoutes           | tcpRetransSegs      |                 |
| ipReasmTimeout          | tcpConnTable        |                 |
| ipReasmReqds            | tcpConnState        |                 |
| ipReasmFails            | tcpConnLocalAddress |                 |
| ipFragOKs               | tcpConnLocalPort    |                 |
| ipFragFails             | tcpConnRemAddress   |                 |
| ipFragCreates           | tcpConnRemPort      |                 |
| ipAddrTable             | tcpInErrs           |                 |
| ipAdEntAddr             | tcpOutRsts          |                 |
| ipAdEntIfIndex          |                     |                 |
| ipAdEntNetMask          |                     |                 |
| ipAdEntBcastAddr        |                     |                 |
| ipAdEntReasmMaxSize     |                     |                 |
| ipRouteTable            |                     |                 |
| ipRouteDest             |                     |                 |
| ipRouteIfIndex          |                     |                 |
| ipRouteMetric1          |                     |                 |
| ipRouteMetric2          |                     |                 |
| ipRouteMetric3          |                     |                 |
| ipRouteMetric4          |                     |                 |
| ipRouteNextHop          |                     |                 |
| ipRouteType             |                     |                 |
| ipRouteProto            |                     |                 |
| ipRouteAge              |                     |                 |
| ipRouteMask             |                     |                 |
| ipRouteMetric5          |                     |                 |
| ipRouteInfo             |                     |                 |
| ipNetToMediaTable       |                     |                 |
| ipNetToMediaIfIndex     |                     |                 |
| ipNetToMediaPhysAddress |                     |                 |
| ipNetToMediaNetAddress  |                     |                 |
| ipNetToMediaType        |                     |                 |
| ipRoutingDiscards       |                     |                 |

| <b>snmp MIB</b>         |
|-------------------------|
| snmpInPkts              |
| snmpOutPkts             |
| snmpInBadVersions       |
| snmpInBadCommunityNames |
| snmpInBadCommunityUses  |
| snmpInASNParseErrs      |
| snmpInTooBigs           |
| snmpInNoSuchNames       |
| snmpInBadValues         |
| snmpInReadOnlys         |
| snmpInGenErrs           |
| snmpInTotalReqVars      |
| snmpInTotalSetVars      |
| snmpInGetRequests       |
| snmpInGetNexts          |
| snmpInSetRequests       |
| snmpInGetResponses      |
| snmpInTraps             |
| snmpOutTooBigs          |
| snmpOutNoSuchNames      |
| snmpOutBadValues        |
| snmpOutGenErrs          |
| snmpOutGetRequests      |
| snmpOutGetNexts         |
| snmpOutSetRequests      |
| snmpOutTraps            |
| snmpEnableAuthenTraps   |

**RFC1317 RS-232 like group supported variables**

| <b>rs232 MIB</b>       |
|------------------------|
| rs232Number            |
| rs232PortTable         |
| rs232PortIndex         |
| rs232PortType          |
| rs232PortInSigNumber   |
| rs232PortOutSigNumber  |
| rs232PortInSpeed       |
| rs232PortOutSpeed      |
| rs232AsyncPortTable    |
| rs232AsyncPortIndex    |
| rs232AsyncPortBits     |
| rs232AsyncPortStopBits |
| rs232AsyncPortParity   |
| rs232InSigTable        |
| rs232InSigPortIndex    |
| rs232InSigName         |
| rs232InSigState        |
| rs232OutSigTable       |
| rs232OutSigPortIndex   |
| rs232OutSigName        |
| rs232OutSigState       |



## EM-1240-LX FAQ

---

**FAQ 1** Why can I only use `vfork()`, and am not able to use `fork()`?

**Answer 1** `μClinux` only supports `vfork()`. It does not support `fork()`. Note that when using `vfork()`, the parent process will hang until the child process calls an exec group API, or exits.

**FAQ 2** When using a pthread group API, why can't I use `SIGUSR1` and `SIGUSR2`?

**Answer 2** Since a pthread group API uses `SIGUSR1` and `SIGUSR2` to do a pthread control suspend and restart the exit function, we cannot use the `SIGUSR1` and `SIGUSR2` signals. You will get the same result if you link the pthread. This means that you cannot use `-lpthread` to add an option to the linker.

**FAQ 3** What is the correct format for linking to an API?

**Answer 3** `arm-elf-gcc -Wl, -elf2flt`  
(In this example, the API converts elf format to flat format.)