

ENGLISH

**PS-900-13090
INSTRUCTION MANUAL**

CONTENTS

1. SPECIFICATIONS	1
2. CONFIGURATION	3
3. INSTALLATION.....	4
3-1. Setting up the sewing machine	4
3-1-1. Unpacking	4
3-1-2. Setting up the X-feed mechanism.....	6
3-1-3. Installation position of the thread stand	8
3-1-4. Changing the position of the thread stand to the front side of the sewing machine	9
3-1-5. Setting up the table	10
3-1-6. Setting up the switches, bobbin thread winder and switch button (asm.)	11
3-1-7. Points to be checked and precautions to be taken before turning the power ON.....	12
3-1-8. Installing the air hose.....	14
3-1-9. Cautions for the compressed air supply (source of supply air) facility....	15
3-1-10. Checking the needle entry point and hook timing.....	16
3-1-11. Checking the concentricity (How to handle the case where you have checked the timing between the needle entry and the hook as described in 3-1-10 and have found it is not correct)	18
3-2. Installing the bobbin winder device	22
3-3. Winding the bobbin thread.....	23
3-4. Precautions for installation of the machine	24
4. PREPARATION OF THE SEWING MACHINE	25
4-1. How to attach / remove the cylinder lifting plate	25
4-2. Lubricating method and check of the oil quantity	26
4-3. Attaching the needle	28
4-4. Threading the machine head	29
4-5. Bobbin replacement procedure	30
4-6. Adjusting the thread tension	31
4-7. Adjusting the thread take-up spring and the thread breakage detector plate	35
4-8. Adjusting the thread take-up stroke.....	35
4-9. Needle-to-hook relationship	36
4-10. How to wind a bobbin.....	38
4-11. Adjusting the position of the thread trimmer	39
4-12. How to confirm the amount of oil (oil splashes) in the hook.....	42

4-13. Adjusting the amount of oil in the hook	43
4-14. Adjusting the needle hole in the throat plate and the needle	44
4-15. Adjusting the disk presser pressure.....	45
4-16. Adjusting the thread end position at the beginning of sewing	46
4-17. Adjusting the electronic intermediate presser stroke	47
4-18. Adjusting the needle thread air blower.....	48
4-19. Making a template.....	49
4-20. Preparation for sewing	51
4-21. RFID (How to use the electronic label)	53
4-22. Configuration of the operation panel.....	56
4-23. Maintenance mode.....	58
4-24. List of parameters.....	59
4-25. List of error codes	65
5. MAINTENANCE OF SAWING MACHINE	82
5-1. Troubles and corrective measures (Sewing conditions)	88
5-2. Disposal of batteries.....	90
6. SUBCLASS MODEL.....	91
6-1. Barcode reader.....	91

1. SPECIFICATIONS

1	Sewing area (X,Y)(mm)	1300 × 900 (Cutting area Laser type :1090 × 860)
2	Feed motion of feeding frame	Intermittent feed (2-shaft drive by stepping motor)
3	Needle bar stroke	40 mm
4	Max. sewing speed	3,000 sti/min (When stitching pitch is 2.5 mm or less) For other stitch pitches and numbers of revolutions, refer to Fig. 1.
5	Settable stitch length	0.5 to 12.7 mm
6	Needle	DB×1 #8 (#7 to #14)
7	Hook	Double-capacity full-rotary hook
8	Intermediate presser stroke	4 mm (Standard)
9	Lift of intermediate presser	20 mm
10	Lift of disc presser	15 mm
11	Memory of pattern data	Max. 999 patterns
12	Number of patterns that can be identified	Max. 999 patterns
13	Program input method	USB
14	Data format	DXF.AI.PLT.DST
15	Main shaft servomotor power	750W
16	Power consumption	640VA
17	Input voltage	220V ± 10%
18	Mass (gross mass)	With packaging : [Standard type] 688 kg [Laser type] 762 kg Without packaging : [Standard type] 575 kg [Laser type] 649 kg
19	Dimensions	2,100 mm (W) × 2,325 mm (L) × 1,240 mm (H)
20	Operating temperature range	5 to 35 °C [Laser type] 1 to 35 °C
21	Operating humidity range	35 to 85 % (No dew condensation) [Laser type] 5 to 70 %
22	Storage temperature range	-5 to 60 °C [Laser type] -10 to 100 °C
23	Storage humidity range	20 to 85 % (No dew condensation, 85 % applies to the case where the temperature is 40 °C or lower) [Laser type] 20 to 85 % (No dew condensation)
24	Air pressure used	0.5 to 0.6 MPa
25	Needle highest position stop facility	After the completion of sewing, the needle can be brought up to its highest position.
26	Noise	- Equivalent continuous emission sound pressure level (L _{pA}) at the workstation : A-weighted value of 78.0 dB ; (Includes K _{pA} = 2.5 dB) ; according to ISO 10821- C.6.2 -ISO 11204 GR2 at 2,800 sti/min.
27	Lubricating oil	#10 (Equivalent to JUKI NEW DEFRIX OIL No. 1) #32 (Equivalent to JUKI NEW DEFRIX OIL No. 2), Lithium based grease No. 2 Grease information Manufacturer: WERATCHE Type and number: Lithium base 2# grease

Number of revolutions for sewing	Maximum number of revolutions for sewing : 3,000 sti/min			
	Number of revolutions for sewing at shipment : 2,800 sti/min			
	Maximum applicable number of revolutions for sewing at each pitch			
	Pitch	Number of Revolutions	Pitch	Number of Revolutions
	0.5 ~ 2.5 mm	3,000 sti/min	4.6 ~ 5.5 mm	1,800 sti/min
	2.6 ~ 3.0 mm	2,800 sti/min	5.6 ~ 6.5 mm	1,400 sti/min
	3.1 ~ 3.5 mm	2,500 sti/min	6.6 ~ 9.0 mm	1,100 sti/min
	3.6 ~ 4.0 mm	2,200 sti/min	9.1 ~ 9.5 mm	600 sti/min
	4.1 ~ 4.5 mm	2,000 sti/min	9.6 ~ 12.7 mm	500 sti/min


Fig. 1




Sewing of circular patterns

When sewing circular patterns diameter of which is $\phi 60$ mm or less, sewing performance of the sewing machine may be affected by overrun of the lower rotating motor depending on the pattern.

2. CONFIGURATION



- ① Machine head
- ② Table
- ③ X-axis feed mechanism
- ④ Y-axis feed mechanism
- ⑤ Cassette clamp device
- ⑥ Operation panel
- ⑦ Air control box
- ⑧ Electrical control box
- ⑨ Power switch (also used as the emergency stop switch)
- ⑩ Thread stand
- ⑪ Bobbin winder device



3. INSTALLATION


3-1. Setting up the sewing machine

3-1-1. Unpacking

- 1) Lift clamp ❶ as shown in the picture.




If the clamp is not lifted up sufficiently, unpacking will not be smoothly carried out.



- 2) Detach top cover ❷ first. Then, detach the remaining covers from the four surfaces.



- 3) Remove the plastic cover.



- 4) Remove front and rear sheet metal fittings ③ for fixing the sewing machine.
 * Tools are packed in the accessory box for the sewing machine.



- 5) Remove parts, accessories and feed mechanism from the wooden crate.



- 6) Lift the sewing machine with a forklift to bring it to the specified location. (Weight of the sewing machine: 575 kg)



WARNING :
 When working with a forklift, two or more people should handle the sewing machine while checking for safety.



- 7) Turning casters ④ , check to make sure that the sewing machine is put horizontally on the forks of the forklift. Keep the sewing machine on the forks in such a way that it does not rattle.


3-1-2. Setting up the X-feed mechanism




- 1) Detach clamping plates ① . Put the screws and nuts you have removed in the accessory box.



- 2) Unpack the X-feed mechanism.



- 3) Lay the X-feed mechanism aside the main body of the sewing machine.
Move the clamp to the center of the X-feed mechanism.



- 4) Detach rubber plug ② . Remove four nuts ③ on the opposite side with a wrench key. Take care not to allow the screws to slip off the mounting holes after you have removed the nuts. Put the nuts you have removed in the accessory box.



- 5) Aligning the screws with the taps of the X-feed support block, tighten the screws.



- 6) Connect the cable guide to the X feed mechanism. Then, tighten the screws.

3-1-3. Installation position of the thread stand



- 1) You can select one of two installation positions for the thread stand.
1. Installing the thread stand to the table at the rear side of the sewing machine



2. Installing the thread stand to the machine head at the front side of the sewing machine
See below for how to change the installation position of the thread stand.



- 2) Threading method
1. In the case you have installed the thread stand to the table at the rear side of the sewing machine




2. In the case you have installed the thread stand to the head of the sewing machine


3-1-4. Changing the position of the thread stand to the front side of the sewing machine



- 1) Remove the thread stand (asm.).



- 2) Remove the sheet metal, as shown in the figure, and attach the thread stand (asm.) to the sheet metal. Lastly, attach the relevant parts to the sewing machine.



3-1-5. Setting up the table







Fig.1

- 1) Set up the left, right and front (center) tables.
Tighten the screws as illustrated in Fig. 1.



After you have set up the right and left sub tables, check to make sure that there is a clearance between the tables and the X-feed mechanism.






- 2) Set up the front tables (left) and (right).
Secure the aforementioned parts with dedicated link plates ❶ and the nuts.

3-1-6. Setting up the switches, bobbin thread winder and switch button (asm.)



* Tools are packed in the accessory box for the sewing machine.

- 1) Secure the bobbin thread winder to the aluminum frame of the front table (right) with T-head screw ❶ and nut ❷.



- 2) Secure the power switch plate to the aluminum plate of the front table (right) with T-head screw **A** and nut **B**.


- 3) For switch button (asm.) **C**, change round the direction of assembly. Then, secure it to the aluminum plate of the front table (right) with T-head screw **A** and nut **B**. Secure the switch button (asm.) so that its three switch buttons are faced upward.

- 4) For the laser type model, also change installation of the power switch as shown in the figure.




Changes described in the aforementioned steps 3) and 4) may not be carried out depending on the usage.

3-1-7. Points to be checked and precautions to be taken before turning the power ON



- 1) Place accessory levels at the four corners of the main table and adjust the table so that the sewing machine is level.

Level






- 2) Inspect whether the electrical components and pneumatic components are correctly assembled.



- 3) Inspect whether the needle entry point is correctly aligned with the center of the needle hole in the throat plate of the sewing machine.



- 4) Inspect whether the X-feed mechanism operates smoothly.

3-1-8. Installing the air hose




WARNING :

Check to be sure that the air hose is fully inserted into the air cock before supplying the air to the machine so as to prevent the air from being blown directly to the human body. Then, carefully open the air cock.



- 1) Connecting the air hose
Connect the air hose to ❶ .



- 2) Adjustment of air pressure
Pull up air regulating knob ❷ . Then, turn it to adjust the air pressure to 0.5 - 0.6 MPa.
Then, push down air regulator knob ❷ .
Pull up air regulating knob ❸ . Then, turn it to adjust the air pressure to 0.15 MPa.
Then, push down air regulator knob ❸ .

❷ : Adjustment of the air pressure of the entire sewing machine


❸ : Adjustment of the air pressure of the disk presser

3-1-9. Cautions for the compressed air supply (source of supply air) facility

As large as 90 % of failures in pneumatic equipment (air cylinders, air solenoid valves) are caused by "contaminated air."

Compressed air contains lots of impurities such as moisture, dust, deteriorated oil and carbon particles. If such "contaminated air" is used without taking any measures, it can a cause of troubles, inviting reduction in productivity due to mechanical failures and reduced availability.

Be sure to install the standard air supply facility shown below whenever the machine provided with pneumatic equipment is used.



Cautions for main piping



- Be sure to slope main piping by a falling gradient of 1 cm per 1 m in the direction of air flow.
- If the main piping is branched off, the outlet port of the compressed air should be provided at the top part of the piping using a tee in order to prevent drain settling inside the piping from flowing out.
- Auto drains should be provided at all lower points or dead ends in order to prevent the drain from settling in those parts.

3-1-10. Checking the needle entry point and hook timing



* When the power to the sewing machine is in the ON state, reset the sewing machine first.

- 1) First, remove the auxiliary disk presser and the intermediate presser.

Check the alignment of the needle entry point of the sewing machine with the center of the throat plate. (Check the direction of 360 degrees.)



- 2) Remove the throat plate and check the hook timing. (Check the hook timing in all 360 degrees.)




*** Note: How to rotate the needle bar**

- 1) Press "Next Page" ❶ on the Main screen to display the maintenance screen.



- 2) Press "Extend" ❷ to display the Extension screen.




- 3) Press ❸ and ❹ to rotate the needle bar and the hook driving shaft saddle.


3-1-11. Checking the concentricity (How to handle the case where you have checked the timing between the needle entry and the hook as described in 3-1-10 and have found it is not correct)

1. Adjusting the concentricity between the hook driving shaft saddle and the needle bar


If the needle and the hole in the throat plate are not aligned, concentricity between them has to be adjusted. Correct the concentricity between the needle and the hole in the throat plate through the adjustment of their positions in four directions (0°, 90°, 180° and 270°).



- 1) Remove two resin covers, eye protection cover and presser foot.



- 2) Remove the throat plate and the needle.




- 3) Reset the hook driving shaft saddle to the 0° position.
- 4) Attach the concentricity adjustment jigs to the throat plate and to the needle with the respective screws.
- 5) Adjust the T-shaped jig so that the needle bar jig passes through the hole in the T-shaped jig when lowering the needle bar.




Insert needle bar jig ④ into the needle bar.

When you lower the needle bar, carefully check whether it interferes with other parts.



Adjustment of the hook driving shaft saddle and the needle bar in lateral direction:

- 6) Turn the hook driving shaft saddle by 180°. Then, check whether the hole in the T-shaped jig and the needle bar jig are laterally aligned.
- 7) If they are laterally aligned, adjustment of the hook driving shaft saddle and the needle bar in the X direction is not necessary.
- 8) If they are not laterally aligned, carry out steps 9) and beyond to adjust the alignment between the hook driving shaft saddle and the needle bar in the lateral direction.



[How to adjust the alignment between the hook driving shaft saddle and the needle bar when you have turned the hook driving shaft saddle by 180° and found that they are not aligned]


- 9) If the hole in the T-shaped jig is located x mm to the right side of the needle bar jig after you have turned No.5, adjust the hook driving shaft saddle by moving it to the left to reduce the gap to half, i.e., $x/2$ mm. (Refer to ["3-1-11.2. How to adjust the position of the hook driving shaft saddle" p.20.](#))

- 10) If the hole in the T-shaped jig is located x mm to the left of the needle bar jig, adjust the hook driving shaft saddle by moving it to the right to reduce the gap to half, i.e., $x/2$ mm.
- 11) Adjust the position of the T-shaped jig so that the needle bar jig is laterally aligned with the hole in the T-shaped jig.
- 12) Carry out the steps 6) to 12) in repetition until the needle bar jig and the hole in the T-shaped jig are laterally aligned.


Adjustment of the hook driving shaft saddle and the needle bar in longitudinal direction:

- 13) Similarly with the adjustment of the hook driving shaft saddle and the needle bar in the lateral direction, adjust them in the longitudinal direction. Turn the hook driving shaft saddle by 90° and attach the T-shaped jig to it. Then, adjust so that the needle bar jig passes through the hole in the T-shaped jig when you lower the needle bar.
- 14) Carry out the steps 6) through 12) in repetition to test and adjust the hook driving shaft saddle and the needle bar until they are longitudinally aligned.


2. How to adjust the position of the hook driving shaft saddle




- 1) Remove two screws on the front side. (With a 3 mm hexagonal wrench key)




- 2) Turn the hook driving shaft saddle and remove two screws. (With a 3 mm hexagonal wrench key)




- 3) Turn the hook driving shaft saddle. Remove two screws and take remove the metal plate. (With a 3 mm hexagonal wrench key)



- 4) Turn the hook driving shaft saddle. Remove two screws and take remove the metal plate. (With a 3 mm hexagonal wrench key)




5) Loosen four screws. (With a 8 mm hexagonal wrench key)




6) Adjustment of the hook driving shaft saddle and the needle bar in lateral direction:
There are three hexagon head bolts respectively on both sides of the hook driving shaft saddle. You can adjust the hook driving shaft saddle in the lateral direction using these hexagon head bolts. (With a 10 mm open-end wrench)

For example, when you want to adjust the hook driving shaft saddle to the left, screw in the threaded parts on the left side and screw out the threaded parts on the right side to allow the hexagon head bolt heads on the right side to come in contact with the wall to push the hook driving shaft saddle to the left. After the adjustment, screw in the threaded parts on the left side to adjust so that the bolt heads are lightly pressed against the wall. Then, tighten the four screws you have loosened in the step 5). Lastly, tighten the threaded parts of the bolts that are pressed against the wall.



7) Adjustment of the hook driving shaft saddle and the needle bar in longitudinal direction:
Loosen the four screws described in the step 5). Turn the two screws on the near side to move the hook driving shaft saddle back and forth. After the adjustment, tighten the screws described in the step 5) and tighten the two screws on the near side.



Detection plate of the hook driving shaft saddle rotation origin sensor


- 8) Put the metal plates, cover, throat plate and other parts you have removed back into place.



The detection plate of the hook driving shaft saddle rotation origin sensor is attached to the metal plate on the left side. Be careful not to mix up the right and left metal plates.


Before energizing the sewing machine, turn the hook driving shaft saddle by hand to make sure that the sensor detection plate does not come in contact with the sensor.

3-2. Installing the bobbin winder device




- 1) Insert bobbin winder disk mounting bar ❶ into hole ❷ in the bobbin winder and secure with nut ❸.

3-3. Winding the bobbin thread



4. Threading Diagram



1. Button description

- 1) Red button: emergency stop, press this button for 2 seconds will be reset.
- 2) Green button: Start
- 3) "P" key: function key, Hold down "P" key for 2 seconds to enter parameter setting, after setting is finished, press this key again for 2 seconds to keep parameter.
- 4) "+" key: numbers from 0 to 9
- 5) "-" key: numbers from 9 to 0
- 6) "<" key: turn left
- 7) ">" key: turn right

2. Indicator light

- 1) Parameter indicator light
- 2) Production failure indicator light
- 3) Stop indicator light
- 4) Work indicator light

3. Parameter setting

Hold down "P" key for 2 seconds to enter the parameter setting interface.

A: Thread length setting value:

0 to 99.9 m (when F is set to P0)

0 to 999 m (when F is set to P1)


D: Motor speed: F1 (fast), F2 (medium), F3 (slow)

F: Thread length range changeover :


P0 (0 to 99.9 m)

P1 (0 to 99.9 m)

3-4. Precautions for installation of the machine



Template




1. Depending on the size of template, the sewing machine may extend beyond the sewing machine table in X direction. Take care not to allow the machine to hit against someone standing near the table to cause injury.
2. Be sure to secure a space as wide as 500 mm or more around the sewing machine table (i.e., both in lateral and longitudinal directions).

4. PREPARATION OF THE SEWING MACHINE

4-1. How to attach / remove the cylinder lifting plate



- 1) While the power to the sewing machine is turned ON, press switch ①.




- 2) Cylinder lifting plate ② comes off upward. Remove it. (The cylinder pushes up the lifting plate.)
- 3) To install cylinder lifting plate ②, press switch ①. (The cylinder comes down to allow the cylinder lifting plate to be installed. The lifting plate is then secured with a magnet.)

4-2. Lubricating method and check of the oil quantity




WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.



1) Detach cylinder lifting plate ① .



Display A


②

2) Remove cylinder lifting plate ① .

Press ② on the Start screen A to display the screen B.


Then, press ③ to display the screen C. On the screen C, press ④ and ⑤ to rotate the bed and move lubricating rubber ⑦ of oil tank ⑥ to the outside of the bed.

Or turn the power OFF and rotate the resin cover.



Display B



③




Display C

④

⑤



- 3) Remove lubricating rubber ⑦ . Pour the supplied oil (or specified oil) into the oil tank.





- 4) The proper amount of oil in the oil tank is between the Min and Max marker lines indicated on the oil tank.

4-3. Attaching the needle



WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.



- 1) Loosen screw ① to remove the needle.



Be sure to hold the needle so that its groove ② faces toward blade point ③ of the rotary hook.

- 2) Tighten screw ① .



In the case of replacing the needle with a needle which differs in specifications, be sure to re-adjust the distance from the rotary hook to the needle. If you neglect this re-adjustment, the problems listed below can occur.


1. Stitch skipping
2. Thread fray
3. Breakage of blade point of hook
4. Breakage of needle

4-4. Threading the machine head



WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.




- 1) Put sewing machine thread ❶ on thread stand ❷ .
- 2) Pass the thread as illustrated in the figure. Insert the tip of the thread into the hole in upper rubber ❸ of the needle bar.
- 3) Press Threading switch ❹ located at the lower left of the operation panel. The thread comes out from the hole in the needle bar. Then, thread the needle and draw out the thread end through the needle eyelet by 50 to 60 mm.

4-5. Bobbin replacement procedure



WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.



(1) Removing the bobbin case

- 1) Open cover ①. Then, the bobbin can be changed.
- 2) Raise latch ① of bobbin case ③, and remove the bobbin case ③ and the bobbin ②.



Check the position of your hands and the locations of goods before opening / closing cover ① so as to prevent the goods from being caught under the cover and to prevent bodily injury. In addition, do not push cover ① with your hands placed on it.

(2) Installing the bobbin

- 1) Set the bobbin ② into bobbin case ③ in the direction shown in the figure.
- 2) Pass the thread through thread slit ① of bobbin case ③, and pull the thread as it is. By so doing, the thread will pass under the tension spring and be pulled out from thread hole ②.
- 3) Pull out the thread by 50 mm from thread opening ③.



If the bobbin ② is installed in the bobbin case orienting the reverse direction, the bobbin thread pulling out will result in an inconsistent state.

(3) Installing the bobbin case

- 1) Place the bobbin case in the hook with its knob ① tilted and fully push it into the hook until you hear it click.
- 2) Close cover ①.



If it is not fully inserted, bobbin case ③ may slip off during sewing.

4-6. Adjusting the thread tension





Fig. A



Fig. B



Fig. C

(1) Adjusting the needle thread tension

Thread tension controller No. 1 ①

When the tension disk of active tension ③ is loosened, a small amount of tension that is sufficient to control thread trimming has to remain. The remaining tension is produced by tension controller ①. It is possible to determine the length of thread trailing from the needle after automatic thread trimming by adjusting nut ② of the thread tension controller. The length of thread trailing from the needle is reduced by turning nut ② clockwise (+). It is increased by turning nut ② counterclockwise (-).

Active tension ③

The tension of active tension ③ (tension of the thread coming out of the needle eyelet) should be set as low as possible so that the threads intertwine at the center of the material (Fig. A). If the thread tension is excessively high when sewing a light-weight material, the material may become wrinkled or thread may break.

Adjust the tension by changing ① and ②.

The adjustment range is from 0 to 100. The higher the adjustment value, the higher the tension.

[Application range of ① and ②]

Save the tension setting of ① in the pattern data.

The set value will be automatically changed if you change over the pattern data.


The tension setting of ② applies to all patterns. However, it is not saved in the pattern data. This means that the setting of ② will not be changed even if you change over the pattern data.

Refer to the next page for detailed instructions on how to use active tension ③.

Fig. A: Threads are interlaced together accurately at the center of material thickness.

Fig. B: Needle thread tension is too low or bobbin thread tension is too high.

Fig. C: Needle thread tension is too high or bobbin thread tension is too low.




(2) Adjusting the bobbin thread tension

- 1) Turn tension adjusting screw **5** clockwise (in direction **A**) to increase or counterclockwise (in direction **B**) to reduce the bobbin thread tension.

Recommended value: Approximately 25 g


The bobbin case will come down slowly by its dead weight by holding it as illustrated in the figure.




(3) Method for using the AT

1. Method for setting the AT thread tension

- 1) Select the sewing pattern thread tension for which you want to set.




- 2) Press presser foot/thread tension setting button **A**.




- 3) The tension can be set by pressing default tension **B**. Input any set value you desire and carry out trial stitching.

Observing the stitches produced by trial stitching, confirm the appropriate tension set value.

- 4) Press return button **C** to return to the main screen.




- 5) Press the reset button **D** on the main screen to return to the origin.



- 6) Press in the same way as in step 2) to enter the tension setting screen, and enter the tension setting value confirmed in step 3) into tension 1 **E**.


Set the default tension **E** to "1".



Thread tension 1 at the start of sewing : 30

1. The default tension and tension 1 settings are valid from 1 to 100 (integers only).

Caution **2. To set the default tension, just check the appropriate tension by trial sewing, and set tension 1 during production.**



2. Method for changing the thread tension during sewing

- 1) Set the thread tension in the entry field of "Thread tension 1" at a midpoint of the stitching line at which you want to change the thread tension.


Thread tension setting method in the case of the picture shown on the left



Thread tension 1 at the start of sewing : 30


Thread tension from the changing point -

(To the end of sewing) : 60



- 2) If you want to change the thread tension again during sewing, set the thread tension in the entry field of "Thread tension 1" at a desired midpoint of the stitching line.

Thread tension setting method in the case of the picture shown on the left




Thread tension 1 at the start of sewing : 30

Thread tension from the first changing point - : 60


Thread tension from the second changing point -
(To the end of sewing) : 30

Caution
The thread tension set in the entry field of "Thread tension 1" remains the same until the sewing is completed.



2. Method for deleting the changes in thread tension setting during sewing

- 1) If you press "Tension 1 button" **A** and "delete button" **B**, individual thread tension settings you have set in a sewing pattern will be totally deleted.




- 2) If you want to delete the individual thread tension settings separately, move cross mark cursor (+) to the target thread tension setting position and press delete button **B**.

4-7. Adjusting the thread take-up spring and the thread breakage detector plate




WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.



- 1) Remove needle bar rotating motor cover ⑦ .
- 2) Adjusting the stroke
Loosen setscrew ② and turn thread tension controller ③ . Turning it clockwise will increase the stroke of thread take-up spring ① and, thereby, will increase the thread drawing amount.
- 3) Adjusting the pressure
To change the pressure of thread take-up spring ① , insert a thin screwdriver into the slot of thread tension post ④ while setscrew ② is tightened, and turn it. Turn it clockwise to increase the pressure of thread take-up spring ① , or counterclockwise to decrease it.
- 4) Adjusting the thread breakage detector plate
Loosen setscrew ⑥ . Adjust the position of thread breakage detector plate ⑤ so that the amount of contact between thread breakage detector plate ⑤ and thread take-up spring ① is 0 to 0.2 mm.

4-8. Adjusting the thread take-up stroke



- 1) When sewing heavy-weight materials, move thread guide ① to the left (in direction A) to increase the length of thread pulled out by the thread take-up.
- 2) When sewing light-weight materials, move thread guide ① to the right (in direction B) to decrease the length of thread pulled out by the thread take-up.
- 3) Normally, thread guide ① is positioned in a way that the center of elongated hole is aligned with the center of the screw.


4-9. Needle-to-hook relationship



WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.

(1) Needle and hook, and angle setting




- 1) Lift the needle bar from its lower dead point by 2.8 ± 0.3 mm. In this state, adjust the needle bar height and the hook position.
- 2) When observing from the front face of the sewing machine, the blade point of hook seems to overlap with the center of needle.
- 3) When observing from the side face of the sewing machine, the clearance provided between the blade point of hook and the scarf of needle is 0.03 to 0.1 mm.




If thread breakage occurs, the thread can be tangled in the hook. In such a case, remove the thread being tangled in the hook carefully. Then, re-start sewing.

- 4) As shown in the figure, the electrical shaft angle setting QEP value displayed on the operation panel becomes 440 to 445 (reference value).



(2) Position of the needle and the inner hook holder




Longitudinal position of the inner hook holder and needle: The front end of needle is aligned with the inner hook.


Lateral position of the inner hook holder and needle: The rightmost end of projection of inner hook holder is aligned with the right side of needle.

(3) Adjusting the hook timing


The timing gauge is supplied for the machine as an accessory.




Adjust the timing between the needle bar and the hook according to the standard specification.




- 1) Remove the throat plate. Place the timing gauge on the hook driving shaft saddle. At first, adjust the lower dead point of the needle bar. Loosen the needle bar connection collar screws (at two locations) at the top and bottom of the needle bar connection respectively to adjust the height of the needle bar. Then, tighten the needle bar connection collar setscrews. After you have assembled the relevant parts, check to make sure that there is no gap at the top and bottom of the needle bar connection.
- 2) Then, turn the timing gauge by 180 degrees of an angle longitudinally. Adjust the hook timing position.



4-10. How to wind a bobbin



- 1) Put bobbin ② on bobbin winder shaft ③ .
- 2) Pass sewing thread ⑥ through spool rest rod.
- 3) Pass the thread as illustrated in the figure.
- 4) Manually wind thread on bobbin ② by several turns clockwise.
- 5) Press button ④ to start winding thread on the bobbin.
- 6) When the bobbin thread amount wound on the bobbin reaches the set amount (80 %), the bobbin winder automatically stops turning. Or, press button ⑤ to stop the bobbin winder.
- 7) Trim the thread with thread trimmer ① . Detach bobbin ② .






**Amount of thread wound on a bobbin: 80 %
(recommended)**

4-11. Adjusting the position of the thread trimmer



WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.




(1) Adjusting the position of the thread trimming cam

- 1) Turn pulley ① to engage needle bearing ③ of the thread trimmer connecting rod with groove ② in the thread trimming cam.

The shipping standard of the electrical shaft angle setting parameter QEP value is 200. Finely adjust this parameter value in accordance with the difference in materials.

The moving knife is in parallel with the moving knife base



(2) Adjusting the position of the moving knife and counter knife


- 1) Attach the moving knife to the moving knife base. Push the moving knife to the right to make the tail of the moving knife in parallel with the moving knife base. At this time, the blade point of moving knife is aligned with the needle. Tighten moving knife clamping screw ①.



Blade point of moving knife is aligned with the needle





Blade point of moving knife





2) Attaching the counter knife

There is a hole in the tail section of the counter knife. Insert a 2.5-mm hexagonal wrench into the hole. Then, tighten fixing screw ② of the counter knife while aligning the tail section of the counter knife with the hexagonal wrench.



- 3) Loosen setscrew ③ of the moving knife rod. Adjust the clearance provided between the moving knife and the counter knife to 2 ± 1 mm. Then, tighten setscrew ③.



- 4) Mark the 5-mm position of the moving knife blade with a black marker pen. Adjust the counter knife pressure with counter knife pressure adjustment screw ④ (two locations). After the completion of the aforementioned adjustment, face down the moving knife and re-adjust the moving knife pressure repeatedly until both sides of the black marker on the moving knife blade are rubbed by the counter knife at the same time. In addition, try to adjust so that; the less the friction force between the moving knife and the counter knife is decreased, the better thread trimming result can be obtained.

4-12. How to confirm the amount of oil (oil splashes) in the hook




WARNING :

Be extremely careful about the operation of the machine since the amount of oil has to be checked by turning the hook at a high speed.


(1) How to confirm the amount of oil (oil splashes)

① Amount of oil (oil splashes) confirmation paper



* Use any paper available regardless of the material.

② Position to confirm the amount of oil (oil splashes)




When carrying out the procedure described below, confirm the state that the needle thread from the thread take-up lever to the needle and the bobbin thread are removed, the presser foot is lifted and the slide plate is removed. At this time, take extreme caution not to allow your fingers to come in contact with the hook.

- 1) Check to make sure that the oil quantity is adequate referring to "4-2. Lubricating method and check of the oil quantity" p. 26.
- 2) If the machine has not been sufficiently warmed up for operation, make the machine run idle for approximately fifteen minutes.
- 3) Place the amount of oil (oil splashes) confirmation paper under the hook while the sewing machine is in operation.
- 4) Confirmation of the amount of oil (oil splashes) should be completed in ten seconds.

(2) Sample showing the appropriate amount of oil (oil splashes)

Appropriate amount of oil (State of oil spots)

Splashes of oil from the hook




- 1) The state given in the figure above shows the appropriate amount of oil (oil splashes).
- 2) Check the oil amount (oil splashes) three times (on the three sheets of paper), and adjust so that it should not change.



Do not excessively increase/decrease the amount of oil in the hook. If the amount of oil is too small, the hook will be seized (the hook will be hot). If the amount of oil is too much, the sewing product may be stained with oil.


(3) Operation of the operation panel



Display A

③

- 1) Press ③ on the Start screen A to display the screen B.




- 2) Press ④ to change the number of revolutions to 2500.
Press ⑤ to run the sewing machine idle for 15 minutes. Then, measure the amount of oil.

4-13. Adjusting the amount of oil in the hook



WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.



- 1) Remove the cylinder lifting plate.
- 2) The oil amount is increased by turning screw ① in the direction of arrow A, or decreased by turning it in the direction of arrow B.
- 3) After the completion of adjustment, attach the cylinder lifting plate.



1. After the adjustment, check the oil quantity by running the sewing machine idle for approximately 30 seconds, as well as by checking it in comparison with the sample showing the adequate oil quantity. (Refer to "4-12. How to confirm the amount of oil (oil splashes) in the hook" p. 42.)
2. In the case of adjusting the hook oil quantity, firstly adjust the oil quantity by turning oil quantity adjustment screw in the direction of arrow A to increase it. Then, adjust the hook oil quantity by turning the adjustment screw in the direction of arrow B to decrease it.
3. The hook oil quantity has been factory-adjusted at the time of shipment, based on the maximum sewing speed of sewing machine. When the customer always operate the sewing machine at a low speed, the hook oil quantity may run short causing a sewing machine failure. To prevent such a failure, adjustment of the hook oil quantity is required when the customer runs the sewing machine at a low speed at all times.

4-14. Adjusting the needle hole in the throat plate and the needle




WARNING :

Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine.




In the case the needle does not come down to the center of needle hole in the throat plate, the position of the throat plate can be finely adjusted with screws ❶ ❷ and ❸ .

- 1) Loosen screws ❷ and ❸ and lightly loosen screw ❶ . Then, move the throat plate to adjust so that the needle is aligned with the center of needle hole in the throat plate.
- 2) Tighten ❶ . Then, tighten ❷ and ❸ .



4-15. Adjusting the disk presser pressure



- 1) Adjust the disk presser air cylinder pressure regulation valve **1** . Pull up nut **2** . Then, turn the nut clockwise to increase the disk presser pressure or turn it counterclockwise to decrease it. The air pressure has been factory-set to 0.15 MPa at the time of shipment. Adjust it appropriately while checking the actual sewing state.




- 2) Changing the disk presser
Check the actual sewing operation. Use the disk presser or the plastic disk presser according to the condition of actual sewing operation.


A Disk presser (factory-attached at the time of shipment)

B Plastic disk presser

When changing the disk presser with the plastic disk presser or vice versa, try to position the disk presser so that its bottom surface is in parallel with the hook cover. Adjust the height of the disk presser according to the actual material thickness (i.e., height) while taking care not to allow the disk pressers to come in contact with the intermediate presser.



4-16. Adjusting the thread end position at the beginning of sewing



It is possible to set the needle thread end position at the beginning of sewing to top side ❶ or underside ❷ of material.

Change over the setting of the wiper function between ON and OFF in accordance with these two conditions of the needle thread end position.


❶ To put the needle thread end on the top of material

Place the wiper function in OFF.


❷ To put the needle thread end on the underside of material



Place the wiper function in ON.

4-17. Adjusting the electronic intermediate presser stroke




It is necessary to adjust the intermediate presser stroke (A) appropriately since there would be the need for preventing stitch skipping depending on thickness or type of the material.

- 1) Press  ① on the main screen of electrical box.
- 2) When you press the "Machine setting parameter", ② is displayed.
When you enter the password "11111111", screen ③ is displayed.
- 3) On the screen that is displayed by pressing the "Presser follow-up setting", set the parameter (the follow-up height of presser foot has been factory-adjusted to 3 mm at the time of shipment).




4-18. Adjusting the needle thread air blower



Blow-up pipe ① blows air to blow up the thread end trailing from the needle to bring it under disk presser ② at the beginning of sewing by controlling the solenoid valve of the electrical system.

Thread end is pushed by air between the disk presser and the pattern at the beginning of sewing. In the case the thread end cannot be pushed due to the location and direction of slits on the pattern, adjust the blowing direction of the air to allow the thread end to be pushed by air.



Launch the pattern creation software to operate and process the pattern to be sewn.

On the screen that is displayed by clicking "Operation processing" ③, click ④ ("Enter I/O") and change the "I/O" to 5.

Change the "Level" to "high" ("low" refers to "turning OFF"). Click ⑤ ("Delay"). Change the "Delay (msec)" to 225.


The needle thread air blower and the wiper cannot be used simultaneously.

1. The wiper provides the function for bringing the needle thread above the presser foot.

2. The needle thread air blower provides the function for bringing the needle thread under the disk presser.



(2) Attaching the templates




Machine the upper and lower templates based on the design.

- 1) Put the upper template on the lower template, as shown in the figure, and adjust so that sewing slits **A** on the upper and lower templates are aligned.

Affix exclusive template tape (36 mm wide) to portions **1** , **2** , **3** and **4** as illustrated in the figure.

- 2) To produce more beautiful seams, it is recommended to firmly secure the material at the correct position by affixing sand tape, double-sided adhesive tape, etc. on the slits of the upper and lower templates or put positioning pins at appropriate locations in order to prevent the material slippage.


4-20. Preparation for sewing




1) Turning ON the main power switch.
Press switch **1** to turn ON the main power supply.

2) Turning ON the main air source switch
Move main air valve **2** to the right to open the main air source.


* If the operation panel freezes after you have turned the power ON, check whether the operation panel cable is connected properly.



3) Resetting the equipment

When the equipment is reset by pressing  **3**, the needle stops at its upper stop position, and the disk presser and intermediate presser go up.

4) Read the pattern data to be sewn, or directly edit the pattern data on the operation panel.
Refer to the Instruction Manual for the computer-control system for details.




5) Attaching a pattern

Moving an empty pattern (with no material), fit positioning hole **A** on the pattern positioning plate on the positioning pin. Fit other two auxiliary positioning holes **B** on the positioning sleeves and fully push them until they will go no further.

6) Reading the sewing pattern data

1. In the case an electronic label is attached to the pattern, the electrical system will automatically identify the sewing pattern program that matches the pattern from among those stored on the electronic label.
2. In the case no electronic label is attached to the pattern, manually select the sewing pattern data that matches the relevant pattern on the operation screen.

* Refer to "4-22. Configuration of the operation panel" p. 56 for how to use the electronic label.



7) Selecting the reference

In order to align the locus of sewing pattern with the sewing slits of the pattern, it is necessary to set a reference. Specifically, set the reference referring to the Instruction Manual for the electrical system scanner.

After the completion of establishment of a reference, display the operation screen. When you keep button ⑤ held pressed, the pattern locus simulation sewing starts.

Operate the sewing machine once to check whether or not the sewing pattern locus is aligned with the pattern slits. If they are not aligned, re-adjust the reference.

To stop the operation while the simulation operation is being carried out, press button ⑦ to stop it.

8) Placing the material to be sewn

1. Detaching the pattern

When you move the pattern to the reset position and press clamp button ④ on the operation panel, two air cylinders on the X-direction linear module release the pattern. Take out the pattern.

2. Placing the material

Place the material to be sewn on the pattern. Then, check that the material is neatly arranged horizontally. In addition, secure the material with the holding method that matches the pattern to prevent the material from moving out of position. If the material has an infill of feather or cotton, squeeze the material to push out air as far as possible.

9) Setting the reset, pattern on which the material is placed, and the reference

- * Carry out resetting following the step of procedure 3).
- * Handling of the pattern on which the material is placed is described in the step of procedure 5).
- * Reference setting is carried out following the step of procedure 7).

10) Starting

Press the start button ⑥ on the operation panel to start sewing. Then, the sewing machine enters the automatic sewing mode.


11) Temporary stop

If any accident occurs during sewing, press the temporary stop button ⑦ on the operation panel. Then, the sewing machine immediately stops operation.

12) Re-starting


Once the aforementioned accident is eliminated, turn temporary stop button ⑦. Then, the button pops up and the emergency stop mode is reset. Then, press start button ⑥ to re-start automatic sewing.

4-21. RFID (How to use the electronic label)



1. Attaching the electronic label

Attach electronic label ① onto the pattern with double-sided adhesive tape or the like.




2. Writing sewing pattern data


- 1) Place electronic label ① on black dot ② on the sewing machine table.



- 2) Press "Menu" ③ on the initial screen.




- 3) Press the "File Management" ④ on the menu screen.



- 4) Select sewing pattern data ⑤ you want to write on the electronic label on the memory file screen.
After you have made a selection, press "RFID" ⑥ to write the sewing pattern data on the electronic label.






3. Loading sewing pattern data

- 1) On the initial screen, press the "Self-lock" ❶ button.
- 2) Place the electronic label with the sewing pattern data written on it on the black dot on the table.
- 3) The sewing pattern data written in the electronic label is read.

4-22. Configuration of the operation panel




A	LCD portion of the touch panel	
B	PAUSE key	Used to temporarily stop sewing
C	OPEN key	Move the cylinder lifting plate up and down.
D	PRESS key	Used to move up/down the cassette holder
E	START key	Used to start sewing
F	USB port	



G	Reset button	Used to re-start the operation panel
H	COM port	RS232C

* This product is not provided with the Wi-Fi function.

Explanation of the operation panel screen





	Buttons / display	Description
①	Lock key	Used to lock the sewing pattern
②	Threading key	Used to thread the machine head
③	Main shaft speed change key	Used to change the sewing machine main shaft speed
④	Bobbin thread usage key	Used to display the amount of use of the bobbin thread and to move the screen to the setting screen *1
⑤	Sewing count key	Used to display the sewing count and to move the screen to the setting screen *1
⑥	Menu	Used to move the screen to the menu screen *1
⑦	Ready key	Used to return the sewing machine to its origin
⑧	Reference setting key	Used to move the screen to the reference setting screen *1
⑨	Trim key	Used to trim the needle thread and the bobbin thread.
⑩	Presser foot key	Used to operate the presser foot
⑪	Presser foot setting key	Used to move the screen to the presser foot setting screen *1
⑫	Page move key	Used to move the screen to the test mode screen *1
⑬	Test key	Used to operate the sewing pattern by jumping
⑭	Line segment return key	Used to return the sewing machine to the starting position of the previous continuous sewing by jumping
⑮	Line segment feed key	Used to feed the sewing machine to the starting position of the next continuous sewing by jumping
⑯	Single stitch return key	Used to return the sewing machine to the previous stitch. If this key is held pressed, fast-backward mode starts
⑰	Single stitch feed key	Used to feed the sewing machine to the next stitch. If this key is held pressed, fast-forward mode starts
⑱	File key	Used to move the screen to the sewing pattern selection screen
⑲	Sewing pattern selection	Select the sewing pattern to be used by touching it

*1. Refer to the Instruction Manual for the operation panel for details.


4-23. Maintenance mode

The maintenance mode is the mode under which the notice telling that the duration of use of the sewing machine has reached the time requiring maintenance is provided in order to extend the product life of the sewing machine. Under this mode, the maintenance screen is displayed on the operation panel. When the maintenance staff enters the user password, the maintenance screen is erased.




- 1) The maintenance screen is displayed when the time at which the sewing machine requires maintenance has come. (Approximately once every three months)

When cancel button **A** is pressed, the maintenance screen returns to the sewing screen. However, the maintenance screen is re-displayed one hour later.



- 2) When enter button **B** is pressed, the user password input screen is displayed provided that the user password has been set up in prior.

- 3) Add grease referring to **"5. MAINTENANCE OF SAWING MACHINE"** p. 82.





- 4) Enter the user password. Then, the maintenance screen returns to the sewing screen.

4-24. List of parameters

Classification of parameters	No.	Parameter name	Range	Standard value	Meaning of parameter and comment
Automatic machining	P1	Clamp is opened after the completion of automatic machining	Yes/No	Yes	Cassette clamp is lifted every time the continuous sewing cycle is completed
	P2	Number of stitches to be sewn at the beginning and end of sewing with the intermediate presser lowered	0 to 8	2	Number of stitches during which the intermediate presser presses the material at the beginning and end of sewing
	P3	Thread trimming after the completion of automatic machining	Yes/No	Yes	Thread trimming is carried out every time the continuous sewing cycle is completed.
	P4	Position to which the needle is returned after the completion of automatic machining	Origin / secondary origin	Origin	"Origin" is the origin of absolute coordinates.
					"Secondary origin" is the secondary origin (offset point) added to the pattern.
	P5	Whether or not the thread tension is required to be lowered	Yes/No	No	Whether or not the tension on the thread is loosened during jump
	P173	Clamp foot is retained when setting a reference	Yes/No	No	The clamp foot is retained while a reference is being set. On the "Main screen", keep the clamp foot held at its current position while moving the shaft. (Lifted or lowered) The "Main screen" is displayed after the operation panel is started up.
	P259	Automatic operation of the clamp	Yes/No	No	Whether the cassette clamp is turned ON at the beginning of sewing
	P240	Clamp operation in prior to the manual feed	Yes/No	No	Whether the cassette clamp is turned ON before the manual feed is carried out
	P6	Number of stitches to be sewn with overlapped at the beginning of sewing	OFF / 1 / 2	OFF	In the case of set value "1" or "2", sewing is carried out once or twice in repetition at the first needle entry position before proceeding to the next needle entry position at the time of starting the sewing machine. Setting of the number of reverse feed stitches at the beginning of sewing
					In the case of "OFF", the sewing machine does not repeat sewing
	P7	Number of stitches to be sewn at the beginning of sewing without the thread tension release mechanism	0 to 255	0	The thread tension release mechanism is turned OFF while the sewing machine sews the set number of stitches at the beginning of sewing
	P147	Height of the intermediate presser when it is lowered at the beginning of sewing	0 to 4	0.5	Intermediate presser height at the beginning of sewing
	P148	Height of the intermediate presser when it is lowered at the end of sewing	0 to 4	0.5	Intermediate presser height at the end of sewing

Classification of parameters	No.	Parameter name	Range	Standard value	Meaning of parameter and comment
Automatic machining	P161	Setting of the oscillating width of the presser foot at the beginning and end of sewing	Normal / half cut / increase	Normal	
	P172	Intermediate presser is reset after the completion of operation	Yes/No	Yes	Intermediate presser motor is reset at the end of sewing
	P248	Whether or not the shaft travel is required before setting a reference	Yes/No	Yes	
	P252	Clamp opening error at the time of setting a reference	Yes/No	No	
	P794	Output IO 1 at the end of operation	Yes/No	No	
	P796		High/Low	Low	
	P795	Output IO 2 at the end of operation	Yes/No	No	
	P797		High/Low	Low	
Startup speed	P8	First stitch startup speed (r/min)	100 to 3000	300	First stitch sewing speed
	P9	Second stitch startup speed (r/min)	100 to 3000	600	Second stitch sewing speed
	P10	Third stitch startup speed (r/min)	100 to 3000	900	Third stitch sewing speed
	P11	4th stitch startup speed (r/min)	100 to 3000	1500	4th stitch sewing speed
	P12	5th stitch startup speed (r/min)	100 to 3000	2100	5th stitch sewing speed
	P170	Number of revolutions of the reverse feed stitching (r/min)	100 to 3000	1200	Reverse feed stitching speed
	P13	Whether or not the soft start is required	Yes/No	Yes	Whether the machine is started at a low speed
	P162	Whether or not the soft start is required for the second stitch at the beginning of sewing	Yes/No	No	Whether the second stitch is sewn at a low speed
	P163	Whether or not the sewing speed reduction is required for two stitches at the end of sewing	Yes/No	No	Two stitches at the end of sewing are sewn at a low speed
Speed parameter	P14	Maximum number of revolutions of the main shaft (r/min)	100 to 4500	3000	Maximum number of revolutions of the main shaft
	P15	Jump speed (mm/min)	100 to 40000	35000	Jump speed
	P916	Inching speed of the feed (mm/min)	100 to 20000	5000	Travel speed during correction and creation of patterns
	P160	Trial stitching speed (mm/min)	100 to 60000	8000	Demonstration speed
	P17	Button sewing speed 1 after the button is pressed (mm/min)	100 to 20000	500	Eight direction keys support the case of manual movement of the box or collection of files
					Operation speed using ► icon
	P18	Button sewing speed 2 after the button is pressed (mm/min)	100 to 20000	1500	Eight direction keys are supported
					Operation speed using ►► icon

Classification of parameters	No.	Parameter name	Range	Standard value	Meaning of parameter and comment
Speed parameter	P19	Button sewing speed 3 after the button is pressed (mm/min)	100 to 20000	8000	Eight direction keys are supported Operation speed using  icon
	P174	Machine head 2 speed (mm/s)	0 to 2000	0	XY axes speed when using a laser knife
	P175	Machine head 3 speed (mm/s)	0 to 2000	0	XY axes speed when using a laser knife
	P178	Continuous inching speed	Reduce / minimum / normal	Reduce	Travel speed during pattern creation
	P773	Number of revolutions in the reverse direction (r/min)	0 to 3000	0	Reverse feed stitching speed
	P774	Number of stitches to be sewn at a limited speed at the end of sewing	0 to 30	0	Setting of the number of stitch from which the sewing speed is limited at the end of sewing a pattern
	P775	Limited sewing speed to be employed at the end of sewing	100 to 1800	0	This parameter is used in combination with P774 to obtain the specific limited speed value.
Clamp setting	P22	Prohibition of sewing during lifting of the clamp	Yes/No	Yes	Prohibition of sewing during lifting of the cassette clamp
	P25	Thread clamp starting angle at the beginning of sewing	1 to 990	10	Thread clamp ON angle at the beginning of sewing
	P26	Thread clamp ending angle at the beginning of sewing	1 to 990	10	Thread clamp OFF angle at the beginning of sewing
	P27	Thread clamp starting angle during thread trimming	1 to 990	15	Thread clamp starting angle during thread trimming
	P28	Thread clamp ending angle during thread trimming	1 to 990	180	Thread clamp ending angle during thread trimming
	P781	Whether or not the clamp is required during travel	Yes/No	No	
	P743	Delay in opening of the double clamp (ms)	0 to 5000	0	
	P744	Delay in lowering of the double clamp (ms)	0 to 5000	0	
Bobbin winder setting	P29	Bobbin winder status	Allowed / prohibited	Allowed	Bobbin winder  允许 Default state
	P30	Winding speed (r/min)	100 to 4500	2200	Bobbin winding speed
	P31	Bobbin winding time setting (s)	1 to 63000	200	Time setting of bobbin winding
Reset setting	P36	Clamp at the time of resetting	Yes/No	No	Cassette clamp comes down when returning to origin
	P264	Clamp is opened after manual resetting	Yes/No	Yes	Cassette clamp goes up when returning to origin by pressing the reset button
	P38	Return-to-origin method	XY simultaneous / X preference / Y preference	XY simultaneous	"xy simultaneous" means that the x and y axes are simultaneously reset to their origins. "x preference" means that the x axis is firstly reset to the origin, and "y preference" means that the y axis is firstly reset to the origin.

Classification of parameters	No.	Parameter name	Range	Standard value	Meaning of parameter and comment
Reset setting	P39	Return-to-origin speed (mm/min)	100 to 60000	15000	x, y axes speed during resetting to the origin
	P756-P761	Output I/O setting before resetting	OUT1 to OUT6 / No	No	Setting of IO before resetting
	P762-P797		High level / Low level	High level	
	P649	Alarm in the case of a resetting error	Yes/No	No	
	P782-P787	Output IO setting after resetting	OUT1 to OUT6 / Not set	Not set	Setting of IO after returning to the origin
	P788-P793		High level / Low level	Low level	
Setting of stop	P40	Automatic thread trimming during temporary stop	Yes/No	Yes	Whether automatic thread trimming is performed at temporary stop
	P41	Needle position during temporary stop	Upper stop position / Lower stop position	Upper stop position	Needle bar position when temporary stop
	P45	Temporary stop switch type	Yes/No	No	This parameter specifies whether the clamp is lifted at the time of pause.
			Self lock / Normal	Self lock	Soft type of temporary stop, self-locking and normal
					"Normal" automatically bounces when touched
	P799	Presser foot is not lifted during temporary stop	Yes/No	No	
Statistics settings	P49	Bobbin thread remaining amount is cleared at the time of turning the power ON	Yes/No	No	Whether the remaining amount of bobbin thread is reset to 0 (zero) when turning the power ON
	P50	Operation stops after the bobbin thread has run out	Yes/No	Yes	In the case of "Yes", the sewing machine stops when the consumed bobbin thread length has reached the "entire length".
	P51	Bobbin thread counter setting is enabled	Yes/No	Yes	In the case of "Set", statistics automatically indicate the consumed bobbin thread length
	P46	Bobbin thread counter is cleared at the time of turning the power ON	Yes/No	Yes	Whether the sewing counter is reset to 0 (zero) when turning the power ON
	P47	Operation continues after the counter has reached the set value	Yes/No	Yes	Whether the operation is continued after the sewing counter has reached the set value
	P48	Counter setting is enabled	Yes/No	Yes	Whether the sewing counter is enabled
	P52	Working hours counter	Yes/No	Yes	In the case of "Yes", the machining time statistics function is enabled
	P779	Bobbin thread count mode	IN1 to IN4 / default	Default	Statics mode of the bobbin thread amount
	P780	Adjustment value of the surplus amount of bobbin thread (mm)	0 to 600000	0	Adjustment of the bobbin thread remaining amount

Classification of parameters	No.	Parameter name	Range	Standard value	Meaning of parameter and comment
Thread clamp setting	P54	Thread clamp position at the beginning of sewing	0 to 200	0	Thread clamp position at the beginning of sewing
	P236	Laser output IO	Yes/No	No	Laser output
	P693	Enabling automatically changeable hook	Yes/No	No	
Detection of thread breakage	P55	Automatic detection of thread breakage	Yes/No	Yes	In the case of "Yes", the operation is stopped and the description of error is displayed. Thread breakage detection function
	P56	Neglect of detection of thread breakage	Yes/No	Yes	In the case of "Yes", thread trimming is automatically carried out after detection thread breakage Thread breakage is followed by thread trimming
	P57	Detection is ignored for the set number of stitches during sewing	1 to 255	3	For the number of stitches firstly set, thread breakage will not be detected
	P58	Detection of the effective number of stitches in the case of thread breakage	1 to 255	2	In the case thread breakage is detected continuously to reach the specified maximum number of broken stitches, it is assumed that thread has broken definitely.
	P237	Thread breakage output IO	Yes/No	No	
Thread breakage setting	P60	The number of revolutions of the thread trimmer main shaft (r/min)	10 to 500	260	Thread trimmer main shaft speed
	P61	Delay in the start of thread trimmer (s)	0.01 to 6.55	0.01	Delay time at the start of thread trimming
	P62	Continuous operating time of the wiper (s)	0.01 to 6.55	0.15	Wiper operating time
	P63	Delay in the lifting of presser foot after turning OFF the wiper (s)	0.01 to 6.55	0.25	Wiper OFF delay time
	P65	Whether or not the thread is trimmed during jump after sewing	Yes/No	Yes	Whether thread is trimmed at the time of jump
	P66	Whether or not the wiper is used	Yes/No	Yes	Whether the wiper is used
	P169	Thread slackening start mode	Angle / delay	Angle	Starting timing method for turning OFF the thread tension release mechanism
	P168	Thread slackening angle	0 to 999	850	Thread tension release mechanism turning-OFF angle
Energization setting	P70	The sewing machine is returned to the "stop with its needle up" state at the time of turning the power ON	Yes/No	Yes	Needle bar is at upper position when turning the power ON
	P71	Clamp is automatically returned to its origin at the time of turning the power ON	Yes/No	No	Cassette automatically returns to its origin when turning the power ON
	P73	Presser foot is lifted at the time of turning the power ON	Yes/No	Yes	Presser foot goes up when turning the power ON

Classification of parameters	No.	Parameter name	Range	Standard value	Meaning of parameter and comment
Other settings	P74	Whether or not the air pressure detection is required	Yes/No	No	In the case of "Yes", the sewing machine stops and generates the alarm if the detected air pressure is low during work
	P75	Whether or not the repetitive operation is required	Yes/No	No	"Yes" means that cyclic machining of the same file is started after turning the power ON
	P76	Repetitive machining time (min)	1 to 65535	1440	Cyclic machining total time: When the set time has elapsed, cyclic machining is stopped
	P77	Repetitive machining interval (s)	0 to 20	2	Interval from the completion of machining to re-starting of machining under the cyclic machining mode
	P78	Work ending position	Return to 0 (zero) / sewing starting position / default	Return to 0 (zero)	Return to 0 (zero): All of x / y axes coordinates return to 0 (zero); sewing machine terminates sewing; reset point
					Right side: Rightmost position within the machining range
					Sewing starting position: First sewing point of the machining file
					Default: The sewing machine stops after the completion of machining
	P395	Template recognition method	Barcode / electronic label	Electronic label	By serial number of file: Barcode identification mode
					By file name: Electronic label identification mode
	P81	Interface style	Classic / simple	Classic	Classic: Button style of the virtual body
					Simple: Flat button style
	P681	Motion mode is started before operation	XY simultaneous / X precedence / Y precedence	XY simultaneous	
	P755	Jump mode during operation	X precedence / Y precedence / XY simultaneous	X precedence	Jump travel mode
	P241	Connection to the extended screen	Yes/No	No	In the case of "Use", information on the operation file can be displayed on the external add-on display
	P79	Reverse feed after main shaft needle stops	0 to 160	0	
	P242	Voice prompt	High / medium / low / OFF	OFF	"High", "medium" and "low" respectively refer to the magnitude of sound
	P21	Enabling the memory function during power failure	Enable / disable	Enable	After re-energization of the sewing machine, the sewing sequence carried out before power failure is resumed to continue sewing from that interrupted sequence.
	P194	The file is enabled upon separation of the electronic label	Enable / disable	Disable	

4-25. List of error codes

Error Code	Error description	Fault Cause	Solution
E001	There is no reset	The machine is not reset or reset abnormally after power on	Click the "Reset" button to reset
E002	Couldn't find X zero signal	<ol style="list-style-type: none"> 1. X-axis limit sensor is bad or wiring is bad 2. The sensor or baffle screws are loose, or the mechanical jam causes the sensor not to be moved. 3. Parameter errors, such as X-axis reset direction, polarity, platen size, etc. 	<ol style="list-style-type: none"> 1. Check the sensor wiring, manually trigger the sensor, and see if there is any change in the "input test" X limit text on the screen. Replace without change 2. Check the structure 3. Reset or redirect parameters
E003	Couldn't find Y zero signal		Refer to E002 Error Handling Method
E004	Couldn't find Z zero signal		Refer to E002 Error Handling Method
E005	Couldn't find U zero signal		Refer to E002 Error Handling Method
E006	Couldn't find Extend zero signal		Refer to E002 Error Handling Method
E007	Main shaft without internal zero signal	<ol style="list-style-type: none"> 1. Main shaft encoder wiring is bad 2. The main shaft encoder is damaged 3. Power board is broken 4. The motor is broken 	<ol style="list-style-type: none"> 1. Check the wiring of the main shaft encoder 2. Replace the main shaft motor 3. Replace the power board 4. Replace the motor
E020	X axis overvoltage	<ol style="list-style-type: none"> 1. Overload when the load is too heavy and the idling speed is too fast to stop 2. The main board or power board is broken, and the X axis detection voltage exceeds 92V. 	<ol style="list-style-type: none"> 1. Decrease the idling speed 2. Screen menu auxiliary settings drive preview internal drive preview look at the current voltage of the XZ axis, if it is not between 80 92V, it means that the power board is faulty, you need to replace the power board. If one of them is within this range, it means the motherboard Bad need to change the motherboard.
E021	X axis undervoltage	<ol style="list-style-type: none"> 1. The mains voltage is too low 2. Power board failure 	<ol style="list-style-type: none"> 1. Check whether the voltage of the X axis driver is lower than 180V, and see if there are high power devices around the device that start and stop frequently; equipped with a voltage stabilizer according to the situation. 2. Replace the power board
E022	X axis hardware over current	<ol style="list-style-type: none"> 1. The X axis motor is broken or the motor wire is broken and short circuited 2. The motherboard is broken 	<ol style="list-style-type: none"> 1. Replace the motor 2. Replace the motherboard

Error Code	Error description	Fault Cause	Solution
E023	X axis driver software over-current	<ol style="list-style-type: none"> 1. The parameters are incorrect 2. The motor is stuck 3. The motor is broken or the motor wire is damaged and short circuited 4. The power board is damaged 	<ol style="list-style-type: none"> 1. Reset or redirect parameters 2. Check the machinery 3. Check and replace the motor 4. Replace the power board
E024	X axis encoder failure	<ol style="list-style-type: none"> 1. It is reported as too fast when it is moving. 2. Poor or damaged contact of the encoder cable 3. The machine is stuck causing the motor to turn 4. Motherboard is broken 5. The motor is broken 	<ol style="list-style-type: none"> 1. Decrease the idling speed 2. Check the wiring or replace the motor 3. Inspection machinery 4. Replace the motherboard 5. Replace the motor
E025	X axis disconnected	<ol style="list-style-type: none"> 1. The motor plug is not inserted or has poor contact 2. The motor wire is disconnected or damaged 3. The motherboard is broken 	<ol style="list-style-type: none"> 1. Check the wiring 2. Replace the motor 3. Replace the motherboard
E026	X axis overload	The X axis is overloaded	Lighten the load
E027	X axis position deviation is too large		Spare alarm
E028	X axis AD sampling module failure	<ol style="list-style-type: none"> 1. Abnormal startup 2. The motherboard is damaged 	<ol style="list-style-type: none"> 1. Restart 2. Replace the motherboard
E029	X axis overheated	Drive overload	Lighten the load
E030	Y axis overvoltage	<ol style="list-style-type: none"> 1. Overload when the load is too heavy and the idling speed is too fast to stop 2. The main board or power board is broken, and the Y axis detection voltage exceeds 92V. 	<ol style="list-style-type: none"> 1. Decrease the idling speed 2. Screen menu auxiliary settings drive preview internal drive preview look at the current voltage of the Y axis, if it is not between 80 92V, it means that the power board is faulty, you need to replace the power board. If one of them is within this range, it means the motherboard Bad need to change the motherboard.
E031	Y axis undervoltage	<ol style="list-style-type: none"> 1. The mains voltage is too low 2. Power board failure 	<ol style="list-style-type: none"> 1. Check whether the voltage of the Y axis driver is lower than 180V, and see if there are high power devices around the device that start and stop frequently; equipped with a voltage stabilizer according to the situation. 2. Replace the power board
E032	Y axis hardware over current	<ol style="list-style-type: none"> 1. The Y axis motor is broken or the motor wire is broken and short circuited 2. The motherboard is broken 	<ol style="list-style-type: none"> 1. Replace the motor 2. Replace the motherboard

Error Code	Error description	Fault Cause	Solution
E033	Y axis software over current	1. The parameters are incorrect 2. The motor is stuck 3. The motor is broken or the motor wire is damaged and short circuited 4. The power board is damaged	1. Reset or redirect parameters 2. Check the machinery 3. Check and replace the motor 4. Replace the power board
E034	Y axis encoder failure	1. It is reported as too fast when it is moving. 2. Poor or damaged contact of the encoder cable 3. The machine is stuck causing the motor to turn 4. Motherboard is broken 5. The motor is broken	1. Decrease the idling speed 2. Check the wiring or replace the motor 3. Inspection machinery 4. Replace the motherboard 5. Replace the motor
E035	Y axis disconnected	1. The motor plug is not inserted or has poor contact 2. The motor wire is disconnected or damaged 3. The motherboard is broken	1. Check the wiring 2. Replace the motor 3. Replace the motherboard
E036	Y axis overload	The Y axis is overloaded	Lighten the load
E037	Y axis position deviation is too large		Spare alarm
E038	Y axis AD sampling module failure	1. Abnormal startup 2. The motherboard is damaged	1. Restart 2. Replace the motherboard
E039	Y axis overheated	Drive overload	Lighten the load
E040	Z axis overvoltage	1. Overload when the load is too heavy and the idling speed is too fast to stop 2. The main board or power board is broken, and the Z axis detection voltage exceeds 92V.	1. Decrease the idling speed 2. Screen menu auxiliary settings drive preview internal drive preview look at the current voltage of the Z axis, if it is not between 80 92V, it means that the power board is faulty, you need to replace the power board. If one of them is within this range, it means the motherboard Bad need to change the motherboard.
E041	Z axis undervoltage	1. The mains voltage is too low 2. Power board failure	1. Check whether the voltage of the Z axis driver is lower than 180V, and see if there are high power devices around the device that start and stop frequently; equipped with a voltage stabilizer according to the situation. 2. Replace the power board
E042	Z axis hardware over current	1. The Z axis motor is broken or the motor wire is broken and short circuited 2. The motherboard is broken	1. Replace the motor 2. Replace the motherboard

Error Code	Error description	Fault Cause	Solution
E043	Z axis software over current	1. The parameters are incorrect 2. The motor is stuck 3. The motor is broken or the motor wire is damaged and short circuited 4. The power board is damaged	1. Reset or redirect parameters 2. Check the machinery 3. Check and replace the motor 4. Replace the power board
E044	Z axis encoder failure	1. It is reported as too fast when it is moving. 2. Poor or damaged contact of the encoder cable 3. The machine is stuck causing the motor to turn 4. Motherboard is broken 5. The motor is broken	1. Decrease the idling speed 2. Check the wiring or replace the motor 3. Inspection machinery 4. Replace the motherboard 5. Replace the motor
E045	Z axis disconnected	1. The motor plug is not inserted or has poor contact 2. The motor wire is disconnected or damaged 3. The motherboard is broken	1. Check the wiring 2. Replace the motor 3. Replace the motherboard
E046	Z axis overload	The Z axis is overloaded	Lighten the load
E047	Z axis position deviation is too large		Spare alarm
E048	Z axis AD sampling module failure	1. Abnormal startup 2. The motherboard is damaged	1. Restart 2. Replace the motherboard
E049	Z axis overheated	Drive overload	Lighten the load
E060	Main shaft overvoltage	1. The mains voltage is too high 2. Power board failure	1. Check the internal drive to preview whether the main shaft voltage is higher than 400V, check whether the AC power supply voltage fluctuates abnormally, and see if there are high power equipment around the equipment that frequently start and stop; equipped with a voltage regulator as appropriate. 2. Replace the power board
E061	Main shaft undervoltage	1. The mains voltage is too low 2. Power board failure	1. Check whether the internal drive previews the main shaft voltage lower than 180V, and see if there are high power devices around the device that frequently start and stop; equipped with a voltage regulator as appropriate. 2. Replace the power board
E062	Main shaft hardware over current	1. The X axis motor is broken or the motor wire is damaged and short circuited 2. The motherboard is damaged	1. Replace the motor 2. Replace the motherboard
E063	Main shaft software over current	1. The parameters are incorrect. 2. The motor is stuck 3. The motor is broken or the motor wire is broken and short circuited 4. Power board is broken	1. Reset or redirect parameters 2. Check the machinery 3. Check and replace the motor 4. Replace the power board
E064	Main shaft encoder failure	1. Poor encoder wiring 2. The encoder is damaged	1. Check the motor encoder wiring 2. Replace the main shaft motor

Error Code	Error description	Fault Cause	Solution
E065	Main shaft locked rotor	1. The load is too heavy 2. The main shaft is mechanically stuck	1. Lighten the load 2. Check the machine
E066	Main shaft detection for locked rotor	The main shaft load is too large	Check the main shaft mechanical structure for problems
E067	Y servo hardware protection	1. The motor is broken or the motor wire is broken and short circuited 2. The motor is stuck 3. Y servo board is broken 4. The parameters are incorrect	1. Check and replace the motor 2. Check the machinery 3. Replace Y servo board 4. Reset or redirect parameters
E068	Y servo HOC		Spare alarm
E069	Y axis AD sampling module failure	1. Abnormal startup 2. The motherboard is damaged	1. Restart 2. Replace the motherboard
E070	Y servo parameter storage exception	Abnormal memory chip	Replace the chip
E071	Y servo system parameter is abnormal	Parameter configuration error	Check parameter configuration
E072	Y axis AD sampling module failure	1. Abnormal startup 2. The motherboard is damaged	1. Restart 2. Replace the motherboard
E073	Y servo encoder disconnected	1. Y servo encoder has poor contact or disconnection 2. Y servo motor is broken 3. Y servo board is broken	1. Check the Y servo encoder line 2. Replace Y servo motor 3. Replace Y servo board
E074	Y servo encoder AB interference	1. The Y servo board program is the old version 2. Poor contact or broken wire of the servo encoder	1. Look at the screen "Internal Drive" - "Y Version Number", 1 means the old version needs to be returned to the factory to update the program 2. Check the encoder cable
E075	Y servo encoder Z interference	1. The Y servo board program is the old version 2. Poor contact or broken wire of the servo encoder	1. Look at the screen "Internal Drive" - "Y Version Number", 1 means the old version needs to be returned to the factory to update the program 2. Check the encoder cable
E076	Y servo bus undervoltage	1. Voltage drop 2. The bus load is too heavy 3. Transformer failure	1. Increase the voltage 2. Reduced load operation 3. Repair or replace the transformer
E077	Y servo software over current		Spare alarm
E078	Y servo motor overload	1. The parameters are incorrect 2. The motor is stuck 3. The motor is broken or the motor wire is damaged and short circuited 4. The power board is damaged	1. Reset or redirect parameters 2. Check the machinery 3. Check and replace the motor 4. Replace the power board
E079	Y servo motor overload	The Y axis is overloaded	Lighten the load
E080	Y servo driver overload		Refer to E026 Error Handling Method
E081	Y servo motor overheated	Motor overload	Lighten the load
E082	Y servo drive overheated		Refer to E029 Error Handling Method
E083	Y servo fan is abnormal		Spare alarm

Error Code	Error description	Fault Cause	Solution
E084	Y servo overspeed	1. The wiring of the cable and encoder cable is wrong 2. The pulse frequency output by the controller is too large 3. The electronic gear ratio is too large 4. The servo gain setting is too large	1. Whether the wiring of the servo motor power cable and encoder cable is correct and damaged 2. The pulse frequency output by the controller is too large 3. Reduce electronic gear ratio 4. Try to adjust the servo gain manually or automatically again
E085	Y Servo position deviation is too large	1. Y servo board program is an old version 2. Mechanical stuck	1. See "Internal Driver" - "Y Servo" on the screen No version number indicates that the old version needs to be returned to the factory to update the program. 2. Check the machinery
E086	Y servo bus voltage phase failure	1. Poor motor wiring 2. The motor is damaged 3. The Y servo board is damaged	1. Check the motor wiring 2. Replace the motor 3. Replace the Y servo board
E087	Y servo motor phase sequence error	Incorrect wiring phase sequence	Wiring in the correct phase sequence
E088	Y servo driver Rated current input error		Spare alarm
E089	Y servo brake resistor overload		Spare alarm
E090	Y servo absolute encoder overheat		Spare alarm
E091	Low voltage of Y servo battery	Battery exhausted	Replacement battery
E092	Y servo position information lost		Spare alarm
E093	Y servo drive and motor mismatch	Motor model does not match	Replace the servo motor
E094	Y servo origin regression failure	1. There is a problem with the encoder 2. There is a problem with the direction of the drive 3. The pulse current limiting resistance is large	1. Overhaul the encoder 2. Overhaul the drive direction 3. Lower the power supply voltage
E095	Y servo main power supply power off		Spare alarm
E096	Learning failure of Y servo offset angle		Spare alarm
E097	Y servo power break restart	1. Excessive load 2. Overheat protection 3. The screw or nut is damaged	1. Reduced load operation 2. Cooling treatment 3. Maintenance accessories
E098	Y servo initializes LAN9252 error		Spare alarm
E099	Y servo DSP and ESC communication interrupted		Spare alarm
E100	Y servo interrupts communication with host through network cable		Spare alarm

Error Code	Error description	Fault Cause	Solution
E101	Y servo PDO parameters read only		Spare alarm
E102	Y Servo PDO does not have an index to find		Spare alarm
E103	Y servo PDO setting synchronization time out of range		Spare alarm
E104	Y servo PDO data out of range		Spare alarm
E105	Y servo UVW ground fault	1. Wrong phase sequence 2. The power supply voltage is too high	1. Adjust the phase sequence 2. Lower the power supply voltage
E106	Y servo inertia identification failed		Spare alarm
E107	Y servo encoder EEPROM read and write failed		Spare alarm
E108	Y servo position positive limit		Spare alarm
E109	Y servo position negative limit		Spare alarm
E110	Y servo electronic gear ratio setting range is wrong		Spare alarm
E111	Y servo input pulse frequency too high error		Spare alarm
E112	Main shaft hardware protection	1. The motor is broken or the motor wire is damaged and short circuited 2. The motor is stuck 3. The power board main shaft module is damaged	1. Check and replace the motor 2. Check the machinery 3. Replace the power board
E113	Broken main shaft encoder	1. Poor contact or broken wire of the main shaft encoder 2. The main shaft motor is damaged	1. Check the main shaft encoder line 2. Replace the main shaft motor
E114	Main shaft encoder AB interference	1. The power board program is the old version 2. Poor contact or broken wire of the main shaft encoder	1. Look at the screen "Internal Drive" - "Version Number", 1 means the old version needs to be returned to the factory to update the program 2. Check the encoder cable
E115	Main shaft encoder Z interference		Refer to E114 Error Handling Method
E116	Main shaft multi turn data out of range		Refer to E092 Error Handling Method
E117	Main shaft absolute encoder overheating		Refer to E090 Error Handling Method
E118	Main shaft battery voltage is too low		Refer to E091 Error Handling Method
E119	Main shaft multi turn position is missing		Spare alarm
E120	Main shaft motor overload		Refer to E026 Error Handling Method

Error Code	Error description	Fault Cause	Solution
E121	Overload of main shaft drive		Refer to E026 Error Handling Method
E122	Main shaft braking resistor overload		Refer to E089 Error Handling Method
E123	Overheated main shaft motor		Refer to E415 Error Handling Method
E124	Overheated main shaft drive		Refer to E416 Error Handling Method
E125	Undervoltage of main shaft bus		Refer to E410 Error Handling Method
E126	Main shaft busbar over-pressure		Spare alarm
E127	Main shaft main power off		Spare alarm
E128	Main shaft software over-current		Refer to E412 Error Handling Method
E129	Main shaft position forward limit		Spare alarm
E130	Negative limit of main shaft position		Spare alarm
E131	Main shaft electronic gear ratio error		Spare alarm
E132	Main shaft input pulse frequency is too high		Spare alarm
E133	Excessive main shaft position deviation	1. The main shaft board program is the old version 2. Mechanical stuck	1. "Internal drive" - "main shaft" no version number means that the old version needs to be returned to the factory to update the program 2. Check the machinery
E134	Main shaft overspeed	1. Wiring error 2. The acceleration is too high 3. The grid voltage is too low 4. Low main shaft power 5. Short circuit of main shaft to ground	1. Check the line 2. Reduce acceleration 3. Check the input power 4. Select a main shaft with a large power level 5. Check whether the main shaft is short circuited to ground
E135	Principal axis origin return failed		Spare alarm
E136	Phase loss of main shaft bus voltage		Spare alarm
E137	Phase sequence error of main shaft motor	Reverse phase sequence	Measure with a multimeter to restore the correct phase sequence
E138	UVW short to ground		Refer to E105 Error Handling Method
E200	XY driver alarm	1. The driver wiring is bad 2. The drive is damaged	1. Check the wiring 2. Replace the motherboard
E201	X driver alarm		Refer to E200 Error Handling Method
E202	Y driver alarm		Refer to E200 Error Handling Method

Error Code	Error description	Fault Cause	Solution
E203	The main motor error	<ol style="list-style-type: none"> 1. The winding is normal but the work occasionally reports that the power board software and hardware are too old 2. The main shaft is stuck 3. The parameters are incorrect, such as P665 to P668 4. The main shaft encoder cable is broken or has poor contact. 5. The main shaft motor is broken 6. Power board or motherboard hardware is bad 7. The motherboard and the power board connected to the dress rehearsal line poor contact 	<ol style="list-style-type: none"> 1. See "Internal Drive Preview" - "Main shaft" - "Version Number" on the screen. If it is lower than 2, you need to update the program. 2. Manual rotation, check the machinery 3. Reset or redirect parameters 4. Check the wiring; manually turn around to see if the screen QEP changes one cycle, and see if the "main shaft 0 bit level" changes once. If there is no change, it means that the encoder wire is broken or the motor is broken or the power board is broken. 5. Replace the main shaft motor 6. Replace the power board or motherboard 7. Check the connection cable
E204	The main motor direction error	<ol style="list-style-type: none"> 1. The main motor direction parameter is set incorrectly. 2. Occasionally reported as a power board failure 	<ol style="list-style-type: none"> 1. Change the main motor direction parameter in the software or screen 2. Replace the power board
E205	Pressure box didn't put down	The current frame is in the raised state	Click the "Frame" button to lower the press frame
E206	Failure of head board	<ol style="list-style-type: none"> 1. Bad head cable 2. The head plate is damaged 3. The motherboard is damaged 	<ol style="list-style-type: none"> 1. Check the headboard connection line 2. Replace the head board 3. Replace the motherboard
E207	Input IO timeout error	<ol style="list-style-type: none"> 1. The corresponding input IO wiring or sensor is broken 2. The corresponding input IO mechanism cannot be triggered 3. Parameter or file setting error 4. The sensor or PCB board where the corresponding IO is located is broken 	<ol style="list-style-type: none"> 1. Test wiring or sensor 2. Check the mechanical structure 3. Check or redirect parameters and processing files 4. Confirm whether the corresponding IO can be triggered manually in the "input test" screen, if not, replace it.
E208	Air pressure is insufficient	<ol style="list-style-type: none"> 1. Insufficient air pressure 2. Pressure detection device failure 	<ol style="list-style-type: none"> 1. Check if the air supply is normal 2. Check the air pressure detection device
E209	Motor scissors are not in place	<ol style="list-style-type: none"> 1. The parameters are incorrect, such as the polarity of the thread trimming 2. Poor or broken wiring of trimmer zero sensor 3. The sensor or motor coupling is loose and offset 4. Scissor motor is stuck 5. Motor damage 6. The motor corresponding driver board is broken 	<ol style="list-style-type: none"> 1. Reset parameters 2. Check the wiring or replace the sensor 3. Inspection machinery 4. Check the scissors motor 5. Replace the motor 6. Replace the corresponding driver board

Error Code	Error description	Fault Cause	Solution
E210	Motor foot fault	1.Zero parameter setting error 2.If it is an external zero position, the zero position sensor wiring is bad or damaged, or the installation is loose 3.If it is the zero position of the motor encoder, the encoder line is defective or damaged. 4.The presser foot mot or is stuck or the coupling is loose. 5.Motor damage 6.The motor corresponding driver board is broken	1.Change the zero parameter P687 2.Check the wiring or replace the sensor 3.Check the encoder line or replace the motor 4.Check the mechanical structure 5.Replace the motor 6.Replace the corresponding driver board
E211	Grab line motor is not in place		Check if the zero signal of the wire gripping motor is normal
E212	Cutters are not in place	1.The sensor wiring is bad or damaged 2.Sensor mounting position deviation 3.The cutter motor is stuck or loose 4.Parameter setting error 5.Control cutter driver enable IO abnormal or gas valve failure 6.Motor damage 7.Bad control line or bad driver	1.Check the wiring or replace the sensor 2.Adjust the sensor installation position 3.Check the cutter motor 4.Reset or redirect parameters 5.Test cut to the corresponding IO function, such as lifting IO 6.Replace the motor 7.Check the line, replace the driver
E213	Broken line	1.The sewing thread is broken 2.Disconnection detection device failure 3.Parameter error	1.Thread the needle again 2.Check the disconnection detection device, and confirm the sensor on the "input test" interface 3.Reset parameters
E214	The quantity of work is full	Prompt when "Current Piece Count" reaches "Total Piece Count" in processing statistics	1.The current value of redesigned parts or the total number of piece counts 2.If you don't need to count statistics, you can turn off the piece counting function in "Statistics Settings"
E215	The bottom line has been used up	The "status used length" of the processing statistics interface is greater than or equal to "the total length of the bottom line"	1.Need to change the bobbin hook and reset the corresponding total bobbin length. 2.If you do not need to use the bottom line statistics, you can turn off this function in the "statistics settings"
E216	The file is too large	The number of stitches of the graphics file exceeds the maximum range	Need to replace small graphics files
E217	No working file	1.Under the lock file, if the electronic label does not scan the existing graphic name, press Start 2.Screen and motherboard file transfer failure	1.Need to re scan or switch graphics files 2.Check the screen cable and upgrade the motherboard and screen program

Error Code	Error description	Fault Cause	Solution
E218	Waiting for the working data	<ol style="list-style-type: none"> 1. The file is too large, the motherboard waits for the screen to transfer files during processing 2. The screen cable has poor contact or is disconnected. 3. The screen line is tied with a strong interference source 4. The screen or motherboard program is too old 5. The screen or motherboard hardware is damaged 	<ol style="list-style-type: none"> 1. Need to wait for a while to disappear automatically 2. Check the screen line 3. Separate screen wires from strong interference wires such as motor power wires 4 Upgrade the latest screen or motherboard program 5. Test whether you can upgrade the motherboard program; test whether the communication is normal in the "Test Transmission" interface, and replace the hardware if it is abnormal
E219	Electrical fault, please contact the manufacturer	Motherboard hardware exception	Contact equipment manufacturer
E220	Wrong upgrade file	<ol style="list-style-type: none"> 1. The upgrade file is not suitable for this system 2. The upgrade file is damaged 	<ol style="list-style-type: none"> 1. Use the corresponding upgrade file, such as BP01 system can only upgrade BP01 program 2. Confirm whether the upgrade file in the USB flash drive is damaged
E221	Upgrade file type error	The upgrade file is corrupted or the upgrade file is not suitable for this system.	Need to select the corresponding type of upgrade file for upgrade
E222	Could not upgrade	Motherboard hardware exception	Contact equipment manufacturer
E223	Upgrade file not the same OEM manufacturer	Upgrade file version does not match	The system is not the corresponding legal upgrade file
E224	Head board can not be connected 1.The connection	<ol style="list-style-type: none"> 1. The connection between the head board and the motherboard is broken or the interface is loose. 2. Headboard or motherboard hardware failure 	<ol style="list-style-type: none"> 1. Check the cable of the head board 2. Replace the headboard or motherboard
E225	Connecting the main control board	<ol style="list-style-type: none"> 1. The screen cable interface is loose or damaged 2. Screen or motherboard hardware failure 	<ol style="list-style-type: none"> 1. Check the screen cable for bad contact or damage 2. Replace the screen or motherboard
E226	Current file is invalid	<ol style="list-style-type: none"> 1. Upgrade without selecting the upgrade file 2. The read file is damaged or of the wrong type 3. U disk is incompatible or damaged 	<ol style="list-style-type: none"> 1. Insert U disk and select upgrade file 2. Replace the correct documents 3. Replace U disk

Error Code	Error description	Fault Cause	Solution
E227	The file transfer failed	1. The screen cable interface is loose or disconnected 2. The screen or motherboard program is too old 3. Screen or motherboard hardware failure 4. The screen line is tied with a strong interference source	1. Check the screen line 2. Upgrade the latest screen or motherboard program 3. Test whether you can upgrade the motherboard program; test whether the communication is normal in the "Test Transmission" interface, and replace the hardware if it is abnormal 4. Separate screen wires from strong interference wires such as motor power wires
E228	Data outside the range	The current graphic file data exceeds the maximum format limit	Check if the graphic data is abnormal
E229	The modified Angle is too large	Single modification of graph angle value is too large	Decrease the modified angle value
E230	Loading graph data	Processing necessary graphics data	Wait for a while before proceeding
E231	Foot follow error	1. The presser foot motor is stuck when it rotates. 2. Parameter setting error	1. Check if the presser foot motor is normal 2. Reset parameters
E232	No U disk!	1. U disk is not inserted or damaged 2. The screen U disk interface is damaged	1. Reinsert U disk or replace U disk 2. Insert other U disk interface or change screen
E233	File error!	An error occurred while reading or writing from the USB flash drive	1. Replace graphics files 2. Re insert U disk or replace U disk
E234	Graph or head offset out of bounds!	1. The file size is too large to exceed the processable range 2. The file is small but offset from the processable range 3. Head offset is out of bounds 4. The parameters are set incorrectly, such as the size of the pressure plate	1. Replace graphics with smaller height and width 2. Reset the reference point position 3. Reset the head offset value of head 2 or head 3. 4. Set the platen size corresponding to the machine
E235	This is not a working file!	File content or format error	Replace Recognizable Graphics File
E236	TF RAM error	Bad motherboard	Replace the motherboard
E237	Please set the admin password first	No administrative password is set	Need to set an administrative password first
E238	Editing is not supported	No editing instructions or files	No editing instructions or files
E239	Please contact the manufacturer	Contact the manufacturer	Contact equipment manufacturer
E240	Communication fault 2	1. Bad communication or damage to the screen leads to CAN communication failure 2. The screen or motherboard program is too old 3. The screen or motherboard is broken	1. Check the screen line 2. Upgrade the latest screen or motherboard program 3. Replace the screen or motherboard
E241	Time anomaly	Time is wrong	1. The time is illegally modified 2. The motherboard battery is low.

Error Code	Error description	Fault Cause	Solution
E242	No work IO	1. The work enable input IO signal is abnormal. 2. Parameter setting error	1. Check the corresponding IO 2. Turn off the "work enable input IO" function and set the parameter value to 0
E243	Waiting for input IO	1. Input IO signal in waiting file 2. Corresponding input IO sensor has bad contact or is damaged or unable to trigger 3. Parameter or file setting error	1. Automatically disappears when the corresponding IO is detected 2. Check sensor failure 3. Resetting parameters or processing files
E244	Execution delay	1. Execute the delay instruction in the graphics file 2. The delay time is too long	1. It disappears automatically after completing the delay 2. Reset delay as appropriate
E245	The file name is too long	The file name written in the electronic label is longer than 32 bytes (32 English or 16 Chinese characters)	Need to shorten the length of the file name before writing
E246	Please lift the presser foot first	Presser foot not raised	Click the "Presser Foot" button to raise the presser foot
E247	Frame is not pressed down	Unpressed frame	Click the "press frame" button to lower the frame
E248	Auxiliary frame is not pressed down	1. Unpressed auxiliary pressure frame 2. Parameter setting error	1. Click the corresponding IO button of the auxiliary pressure frame 2. Reset parameters
E249	Frame and auxiliary frame is not pressed down	1. Unpressed frame and auxiliary frame 2. Parameter setting error	1. Click the corresponding button to push down both the pressing frame and the auxiliary pressing frame. 2. Reset parameters
E250	Punched material has run out	Out of punching base material	Need to replace the new punch base material
E251	Reset failed	The reset fails due to various reasons, such as the origin cannot be found during reset	Go to "Auxiliary Settings" - "Test Transmission" - "Alarm Log" to see which alarms have occurred during this reset failure. Refer to the previous alarm faults to resolve these alarms and reset them.
E252	Rotating motor failure	1. Rotary motor alarm due to mechanical overload, etc. 2. The motor wire of the rotating motor is disconnected, the interface is loose, and the connection line between the motor and the driver is faulty. 3. Rotary shaft driver is broken 4. The rotating motor is broken	1. Check if the machine is stuck 2. Check the corresponding wiring 3. Replace the flashing drive 4. Replace the motor
E400	Drive board cannot be connected	Abnormal circuit of main board	Overhaul the motherboard circuit

Error Code	Error description	Fault Cause	Solution
E401	(0x) Drive board hardware protection	1. The motor is broken or the motor wire is damaged and short circuited 2. The motor is stuck 3. The driver board is damaged 4. The parameters are incorrect	1. Check and replace the motor 2. Check the machinery 3. Replace the Y servo board 4. Reset or redirect parameters Parameters for which (0x) is displayed 01: Main shaft motor 02: Hook motor 03: Upper rotating motor 04: Lower rotating motor The same applies to the following error items.
E402	(0x) Driver board HOC		Spare alarm
E403	(0x) Driver module AD module initial calibration failure		Spare alarm
E404	(0x) Drive board parameter storage error	1. Abnormal memory 2. Not enough memory	1. Maintenance memory 2. Expand memory or clear data
E405	(0x) Driver board system parameters are abnormal	There is a problem with the drive	Update drive
E406	(0x) Driver board AD sampling module is faulty		Refer to E028 Error Handling Method
E407	(0x) The driver board encoder is disconnected	1. The encoder of the driver board is poorly connected or disconnected 2. The motor is damaged 3. The motherboard is damaged	1. Check the encoder cable of the driver board 2. Replace the motor 3. Replace the motherboard
E408	(0x) Driver board encoder AB interference	1. The driver program is an old version 2. Poor contact or broken wire of the servo encoder	1. Look at the screen "Internal Drive" - "Y Servo" - "Version Number", 1 means the old version needs to be returned to the factory to update the program 2. Check the encoder cable
E409	(0x) Driver board encoder Z interference		Refer to E408 Error Handling Method
E410	(0x) Driver board bus undervoltage	1. Voltage drop 2. The bus load is too heavy 3. Transformer failure	1. Increase the voltage 2. Reduced load operation 3. Repair or replace the transformer
E411	(0x) Driver board bus overvoltage		Spare alarm
E412	(0x) Driver board software overcurrent		Refer to E023 Error Handling Method
E413	(0x) Drive board motor overload		Refer to E026 Error Handling Method
E414	(0x) Drive board drive overload	1. Excessive friction increases the operating load 2. Insufficient power or improper adjustment of internal parameters	1. Lubrication 2. Adjust the gain or adjust the parameters
E415	(0x) Driver board motor overheating		Spare alarm
E416	(0x) Driver board driver overheating		Refer to E029 Error Handling Method

Error Code	Error description	Fault Cause	Solution
E417	(0x) Drive board fan error		Spare alarm
E418	(0x) Drive board overspeed	1. Wiring error 2. The acceleration is too high 3. The grid voltage is too low 4. The driver power is low 5. The driver is shorted to ground	1. Check the line 2. Reduce acceleration 3. Check the input power 4. Choose the driver with large power level 5. Check whether the drive is short circuited to ground
E419	(0x) Driver board position deviation is too large	1. The position deviation parameter is set too small 2. Servo unit circuit board failure 3. UVW wiring of the servo motor is abnormal (wire missing) 4. Poor gain adjustment of the servo unit 5. The frequency of the position command pulse is too high 6. The load conditions do not match the specifications of the motor	1. Reset the correct parameters 2. Replace the servo unit 3. Correct the motor (encoder) wiring 4. Increase the speed loop gain and position loop gain 5. Slowly reduce the position command frequency; add smooth function; re-evaluate the electronic gear ratio 6. Re-evaluate the load or motor capacity
E420	(0x) Driver board bus voltage phase loss		Refer to E086 Error Handling Method
E421	(0x) Drive board motor phase sequence error	Reverse phase sequence	Measure with a multimeter to restore the correct phase sequence
E422	(0x) Driver board rated current input error		Spare alarm
E423	(0x) Driver board braking resistor overload		Refer to E089 Error Handling Method
E424	(0x) Driver board absolute encoder overheating		Refer to E090 Error Handling Method
E425	(0x) Driver board battery voltage is too low		Refer to E091 Error Handling Method
E426	(0x) Driver board multi turn position information lost	Battery type absolute encoder voltage is too low	Replacement battery
E427	(0x) Driver board driver and motor do not match	Driver and motor power do not match	Servo drive uses current limit; torque is limited to 50%
E428	(0x) Drive board origin return failed		Refer to E094 Error Handling Method
E429	(0x) The driver board main power is off	1. The voltage is too low 2. Power failure	1. Increase the voltage 2. Maintenance power supply
E430	(0x) Driver board offset angle failed		Spare alarm
E431	(0x) The driver board is powered off and restarted		Refer to E097 Error Handling Method
E432	(0x) Driver board initialization LAN9252 error		Spare alarm
E433	(0x) Communication between driver board DSP and ESC is interrupted		Spare alarm

Error Code	Error description	Fault Cause	Solution
E434	(0x) The communication between the driver board and the host is interrupted through a network cable		Spare alarm
E435	(0x) Driver board PDO communication parameters are read only		Spare alarm
E436	(0x) No index for driver board PDO communication		Spare alarm
E437	(0x) Driver board PDO communication synchronization time is out of range		Spare alarm
E438	(0x) Drive board initialization LAN9252 error		Spare alarm
E439	(0x) Driver board UVW short circuit		Refer to E105 Error Handling Method
E440	(0x) Drive board inertia identification failed		Spare alarm
E441	(0x) Drive board encoder EEPROM read and write failed		Spare alarm
E442	(0x) limit of driver board position		Spare alarm
E443	(0x) Negative limit of driver board position		Spare alarm
E444	(0x) Driver board electronic gear ratio range		Refer to E110 Error Handling Method
E445	(0x) Driver board input pulse frequency is too high		Refer to E132 Error Handling Method
E446	(0x) Driver board motor overheating warning		Refer to E081 Error Handling Method
E447	(0x) Drive board drive over-heat warning		Refer to E081 Error Handling Method
E448	(0x) Driver board motor overload warning		Refer to E026 Error Handling Method
E449	(0x) Drive board drive overload warning		Refer to E026 Error Handling Method
E450	(0x) Driver board position deviation too large warning		Refer to E419 Error Handling Method
E451	(0x) Driver board brake overload warning		Refer to E026 Error Handling Method
E452	(0x) Drive board forward overtravel warning	Exceeds the software limit set value set by the system	Modify setting parameters or reset
E453	(0x) Drive board reverse overtravel warning	Exceeded the set target itinerary	Press the reset button to reset
E470	(0x) driver board overpressure	Regulator failure	Overhaul voltage regulator



Error Code	Error description	Fault Cause	Solution
E471	(0x) Driver board undervoltage	1. Insufficient voltage, the external input voltage is too low 2. Harmonic interference	1. Replace the power supply or add a regulator 2. It is necessary to install a special filter at the input end of the servo drive to solve the problem
E472	(0x) Driver board hardware overcurrent	1. The power supply voltage is too large 2. The hardware is damaged, resulting in too small resistance	1. Buck treatment 2. Replace the hardware
E473	(0x) Driver board software overcurrent		Refer to E023 Error Handling Method
E474	(0x) Driver board encoder failure		Refer to E024 Error Handling Method
E475	(0x) Driver board is open		Refer to E025 Error Handling Method
E476	(0x) Drive board overload		Refer to E026 Error Handling Method
E477	(0x) The driver board is out of position		Refer to E027 Error Handling Method
E478	(0x) Driver board AD sampling failure		Refer to E028 Error Handling Method
E479	(0x) Driver board overheated		Refer to E029 Error Handling Method






5. MAINTENANCE OF SAWING MACHINE







WARNING :






Turn OFF the power before starting the work so as to prevent accidents caused by abrupt start of the sewing machine. In addition, attach the covers which have been removed before operation back in place.


No.	Region	Explanation	Operating time
1	<p>The area under the throat plate, area surrounding the hook, bobbin case and its inner portion, thread trimming area, needle bar area, areas inside and outside of the presser foot, openings of the electronic control box such as air inlet and outlet, and the regions in which thread waste, thread end and other stains are likely to remain.</p> 	<p>Clean up the surface of equipment with a tool such as an air gun. In particular, clean up the regions in which the aforementioned thread waste, thread end and other stains are likely to remain.</p>	Eight hours
2	<p>Apply grease to the upper and lower bushing of the needle bar.</p> 	<ol style="list-style-type: none"> 1. Loosen screw ❶ of the face plate. Remove the face plate. 2. Loosen screw ❷ of the needle bar lower bushing to remove it. 3. While aligning the lubricating hole of the grease gun with the tapped hole in the needle bar lower bushing, pour the grease. 4. The grease amount to be added must exceed 0.5 cm³. 5. After the lubrication, tighten the screw of the needle bar lower bushing and put the face plate back into place. Tighten the screw of the face plate. 6. Apply the grease to the flat part (baffle part) of the needle bar. 7. Use the JUKI Grease as the lubricating grease. Do not mix it with other lubricating greases. 	Operation for 720 hours

No.	Region	Explanation	Operating time
3	<p>Lubricate the hook oil tank.</p>   <p style="text-align: center;">Display A</p>  <p style="text-align: center;">Display B</p>  <p style="text-align: center;">Display C</p> 	<p>1. Detach cylinder lifting plate ①.</p> <p>2. Press ② on the Start screen A to display the screen B. Then, press ③ to display the screen C. On the screen C, press ④ and ⑤ to rotate the bed and move lubricating rubber ⑦ of oil tank ⑥ to the outside of the bed.</p>	<p>If the oil level in the oil tank drops below the lower scale marker, replenish the oil tank with the accessory (or specified #10) oil.</p>

No.	Region	Explanation	Operating time
3		<p>3. Remove lubricating rubber ⑥ . Pour the supplied oil (or specified oil) into the oil tank. Lubricate up to the upper marker line.</p> <p>4. Attach rubber plug ⑥ .</p>	
4	<p>Adding the lubricating oil to the gear box</p>  <p>Display A ②</p> <p>Display B ③</p> <p>Display C ④ ⑤</p>	<p>1. Press ② on the Start screen A to display the screen B. Then, press ③ to display the screen C. On the screen C, press ④ and ⑤ to rotate the bed and move lubricating rubber ⑦ of oil tank ⑥ to the outside of the bed.</p>	<p>Replenish the gear box with No. 32 white oil if the oil surface shown on the level gauge falls below the lower scale mark A.</p>

No.	Region	Explanation	Operating time
4		<p>2. Loosen six fastening screws ⑦ and remove gear box cover ⑤ and cap ⑥ .</p> <p>3. Pour the #32 oil into the gear box slowly.</p> <p>4. The oil surface in the gear box can be checked through the oil sight window on the side face of the frame. Stop pouring of the lubricating oil when the oil surface reaches the center part (between the H and L lines) of the oil sight window.</p> <p>5. Attach gear box cover ⑤ and cap ⑥ .</p>	
5	<p>* Dust accumulates on the needle bar upper bushing. Clean it up at regular intervals.</p> 	<p>1. Loosen screws ① and remove head cover ② .</p>	

No.	Region	Explanation	Operating time
5	   <p data-bbox="256 1182 608 1240">Direction to remove the thread guide plate</p>  	<p data-bbox="699 163 1109 275">2. Loosen assembly screws ③ of the tube to allow tube ④ to be moved to the right and left.</p> <p data-bbox="699 835 1109 1171">3. Loosen screws ⑥ and take out thread guide plate ⑤ of the head rotation section straight. * Thread guide plate ⑤ has a long thread guide under it, so be careful not to allow the thread guide to hit against the surrounding parts to protect against breakage.</p> <p data-bbox="699 1574 1109 1843">4. Remove dust from the hole from which you have removed the long thread guide with tweezers to clean it up. Or, blow air through threading hole ⑦ in the needle bar with an air gun to remove dust.</p> <p data-bbox="699 1854 1109 1955">5. After the completion of cleaning, install other parts in the order of 3 to 1.</p>	

No.	Region	Explanation	Operating time
5		<p>6. After the completion of installation of the parts, check whether or not the threading air blow is normal. If necessary, adjust the threading air blow by changing the mounting position or orientation of tube ④ .</p>	

5-1. Troubles and corrective measures (Sewing conditions)

Trouble	Cause	Corrective measures
1. The needle thread slips off at the start of bar-tacking.	<ul style="list-style-type: none"> ① Stitches are slipped at the start. ② The needle thread remaining on the needle after thread trimming is too short. ③ The bobbin thread is too short. ④ Needle thread tension at 1st stitch is too high. ⑤ Stitching pitch at 1st stitch is too small. 	<ul style="list-style-type: none"> ○ Adjust the clearance provided between the needle and the hook. ○ Set soft-start sewing at the beginning of sewing. ○ Decrease the tension of the thread tension controller No. 1. ○ Increase the tension of the thread take-up spring. ○ Decrease the bobbin thread tension. ○ Increase the clearance between the needle and the counter knife. ○ Decrease the needle thread tension at 1st stitch, and extend the duration of the AT operation at the beginning of sewing. ○ Make the stitching pitch at 1st stitch longer. ○ Decrease the needle thread tension at 1st stitch.
2. Thread often breaks or synthetic fiber thread splits finely.	<ul style="list-style-type: none"> ① The hook or the inner hook holder has scratches. ② The needle hole guide has scratches. ③ Thread enters the groove in the hook. ④ The needle thread tension is too high. ⑤ The tension of the thread take-up spring is too high. ⑥ The synthetic fiber thread melts due to heat generated on the needle. ⑦ When taking up the thread, the needle tip penetrates the thread. 	<ul style="list-style-type: none"> ○ Remove the hook and grind hook or the inner hook holder with a fine grind stone or buff them. ○ Buff the needle hole guide or replace it with a new one. ○ Detach the hook to remove the thread. ○ Decrease the needle thread tension. ○ Decrease the tension of the thread take-up spring. ○ Use the optional needle cooler. ○ Check the rough state of needle tip. ○ Use the ball-pointed needle.
3. The needle often breaks.	<ul style="list-style-type: none"> ① The needle is bent. ② The needle comes in contact with the intermediate presser. ③ The needle is too thin for the material. ④ Clearance between the needle and the hook is too small. 	<ul style="list-style-type: none"> ○ Replace the bent needle. ○ Adjust the position of the intermediate presser. ○ Replace it with a thicker needle according to the material. ○ Adjust the clearance between the needle and the hook.
4. Threads are not trimmed. (Bobbin thread only)	<ul style="list-style-type: none"> ① The counter knife is dull. ② Knife pressure of the counter knife is low. ③ The counter knife has been improperly positioned. ④ The last stitch is skipped. ⑤ Bobbin thread tension is too low. ⑥ Flopping of cloth 	<ul style="list-style-type: none"> ○ Replace the counter knife. ○ Adjust the knife pressure of the counter knife. ○ Correct the position of the counter knife. ○ Correct the timing between the needle and the hook. ○ Increase the bobbin thread tension. ○ Lower the intermediate presser height.
5. Stitch skipping often occurs.	<ul style="list-style-type: none"> ① Clearance provided between the needle and the hook is not correct. ② Position of the inner hook holder against the needle is not correct. ③ The needle is bent. ④ The needle thread after thread trimming is too long. 	<ul style="list-style-type: none"> ○ Adjust the clearance between the needle and the hook. ○ Adjust the position of the inner hook holder against the needle. ○ Replace the bent needle. ○ Decrease the tension of the thread take-up spring. ○ Increase the tension of the thread tension controller No. 1.
6. The needle thread comes out on the wrong side of the material.	<ul style="list-style-type: none"> ① The needle thread tension is not high enough. ② The needle thread after thread trimming is too long. 	<ul style="list-style-type: none"> ○ Increase the needle thread tension. ○ Increase the tension of the thread tension controller No. 1.
7. Threads break at time of thread trimming.	<ul style="list-style-type: none"> ① The knife has been improperly position. 	<ul style="list-style-type: none"> ○ Correct the position of the knife.


Trouble	Cause	Corrective measures
8. Thread end of the 1st stitch comes out on the right side of the material.	① Stitch skipping at the 1st stitch. ② Needle used and thread used are thick in terms of the inner diameter of the intermediate presser. ③ Intermediate presser is not properly positioned in terms of the needle. ④ The direction of air blower is incorrect. As a result, needle thread at the tip of needle cannot be clamped with the disc presser.	○ Increase the length of needle thread remaining at the needle after thread trimming. ○ Change the current intermediate presser with another one which has a larger inner diameter. ○ Adjust the eccentricity between intermediate presser and needle so that needle enters in the center of intermediate presser. ○ Adjust the air-blowing direction of the air blower according to the direction of sewing so that the needle thread at the tip of needle can be clamped with the disc presser.
9. The needle thread is entangled in the inner hook holder.	① The clearance provided between the inner hook holder and the inner hook is too small.	○ Adjust the clearance provided between the inner hook holder and the inner hook appropriately according to the thickness of needle thread to be used.
10. The knotting section of bobbin thread at 2nd stitch at the sewing start appears on the right side.	① The bobbin runs idle excessively. ② Bobbin thread tension is too low. ③ The needle thread tension at 1st stitch is too high.	○ Adjust the height of idling prevention spring of the bobbin case appropriately. ○ Increase the bobbin thread tension. ○ Decrease the needle thread tension at 1st stitch.
11. The sewing machine is not able to carry out perfect stitching.	① The bed fails to rotate.	○ On the operation panel, select "Menu" and "Machine Param" in the written order. Then, enter "11111111" as a password. Then, select "Rotation Setting" and set the "Rotation along graph" to "Yes". Then, set the stitch pitch for sewing patterns again.

5-2. Disposal of batteries




The operation panel has a built-in battery in order to operate the clock even when the power is turned OFF. Be sure to dispose of the battery following the local laws and regulations.



■ How to remove the battery



- 1) Release lock ① of the door at the back or side face of the sewing machine to open the door.



- 2) Remove cover setscrews ② of electrical box ③ that is located inside the door. Then, detach the front cover of the electrical box.



- 3) Slide stopper A of battery ④ in the direction of the arrow to detach battery ④.


6. SUBCLASS MODEL

6-1. Barcode reader




WARNING :

Be sure to turn OFF the power supply and air supply to the sewing machine before attaching the parts in order to protect against accidents caused by an unintended start of the sewing machine.




- 1) Secure barcode reader ② and assembly plate ① with screw ④ .

No.	Part number	Part name	Quantity
①	40269588	Barcode reader assembly plate	1
②	40235199	Barcode reader	1
③	40235588	Screw	2
④	40235200	Screw	2
⑤	40235332	Washer	2
⑥	40235331	Barcode	1



- 2) Close the regulator and pull out the air tube ⑦ .


Remove the screws ⑧ (2 pieces) from the switch assembly base ⑨ , stack the assembly plate ① and the switch assembly base ⑨ (see the left figure for the position), and tighten ① and ⑨ together with the screws ③ (2 pieces). Finally, insert the tube ⑦ and open the regulator.



- 3) Adjust the position of barcode reader ② so that it is spaced 60 ± 5 mm. Then, secure it with screw ④ . Connect the plug of the bar code reader to the panel.




When bundling the barcode cable, slightly loosen the cable near the barcode reader.



4) Take out a seal from barcode seals ⑥ provided.




One hundred barcode seals (with serial numbers from 001 to 100) are provided.



5) Stick the barcode seal to the cassette at the position that is 250 mm left from the center of cassette (setup guide) and 30 mm below the upper side of cassette.




The aforementioned sticking position is recommended. It is acceptable to stick the barcode seal at any position that will not interfere with the recognition of the barcode seal by the barcode reader.



2. Setting the barcode functions


● Setting the barcode functions on the operation panel

1) Press button **A**.




2) Press button **B**.

In the default state, the factory-set password is provided. The password is "11111111".




3) Press button **C**.




4) To allow the barcode reader to recognize the template, change **D** from "Electronic identification label" to "Barcode".

Then, press **E**.







- 5) Return to the screen of 2).
Press button **E**.




- 6) Press button **F**.



- 7) Press button **G**.
The password is "11111111".




- 8) Set the mode to "0".




● Setting the barcode number


1) Press button **A**.



2) Press button **B**.



3) Select the sewing pattern file you want to read and press button **C**.



4) Press button **D**.
Save the data.

● Cancelling the barcode number

When you want to cancel the barcode reader number, it is necessary to set the current number to the largest value (the largest one of unassigned numbers, such as 100) first. Then, change that number to "0".

Example)


1	2	3	4	5	6
		↓			
		0			

1	2	3	4	5	6
		↓			
		7 (or 8 to 100)			

When the number "3" is changed to "0", the subsequent numbers registered "4, 5 and 6" will also be erased.

To prevent the aforementioned erasure of registered numbers you do not want to erase, firstly set the barcode number to the largest available value "7", then change it to "0".

● How to use the barcode reader



1) Press button **A** to lock the pattern conversion.



The barcode is enabled by locking the pattern conversion.
When the pattern conversion is locked, pattern list **B** changes its color to gray.



2) Place the barcode seal in the cassette right under the barcode reader.

When the barcode reader recognizes the barcode, the barcode reader beeps.



If the barcode reader does not beep, adjust the vertical position of the barcode reader.
If the pattern is not converted even when the barcode reader beeps, check the self lock.



3) Check whether the pattern is converted appropriately.