

Operating manual PUK U5 M&D



PUK U5

OPERATING MANUAL (translation) "PUK U5 M&D" with welding microscope "USM"

Dear Customer,

This operating manual is intended to familiarize you with the commissioning process and operation of your PUK U5 M&D as well as the associated USM welding microscope. Please read the operating instructions carefully and follow the advice given here diligently. Disruptions and operational faults will thus be avoided. Your personal safety, constant availability and long service life can be assured by this.

THE COMMISSIONING OF THE DEVICE MUST ONLY BE UNDERTAKEN BY TRAINED SPECIALISTS AND ONLY WITHIN THE SCOPE OF APPROPRIATE USE. THE MANUFACTURER ACCEPTS NO LIABILITY FOR DAMAGES CAUSED THROUGH INAPPROPRIATE USE AND IMPROPER OPERATION. THE "GENERAL SAFETY REQUIREMENTS" AND "PERSONAL BODY PROTECTION" CHAPTERS MUST BE READ BEFORE COMMISSIONING.

Please keep these operating instructions safe.

The equipment produced by "Lampert Werktechnik GmbH" fulfils the conformity requirements of the CE mark and is constructed in accordance with the VDE guidelines.

The eye protection systems used on the "USM" welding microscope are tested and certified by DIN-CERTCO (DIN department for eye protection).

Only use original spare parts for maintenance and overhaul work. Our customer service department will naturally be happy to help you.

THE DEVICE MUST ONLY BE OPENED OR MODIFIED BY AUTHORISED CUSTOMER SERVICE PERSONNEL, OTHERWISE ALL GUARANTEES AND WARRANTIES ARE VOID.

LAMPERT WERKTECHNIK GMBH

September 2017

TABLE OF CONTENTS

A	SAFETY PRECAUTIONS – READ BEFORE USING	attached
1	WARNING AND INFORMATION SIGNS	Pg. 2
2	FIELD OF APPLICATION	Pg. 3
3	SAFETY REQUIREMENTS	
3.1	General safety requirements	Pg. 3
3.2	Personal body protection and hazards	Pg. 4
3.3	Hazards of shielding gas cylinders	Pg. 4
3.4	Risk of allergic reactions	Pg. 4
4	SETUP AND INSTALLATION	
4.1	Set-up of the device	Pg. 4
4.2	Installation conditions for multiple welding sets	
4.3	Description of the rear of the device	Pg. 5
4.4	Connection of eye protection and LED illumination of the microscope	Pg. 5
4.5	Connect shielding gas supply	Pg. 6
4.6	Inserting the electrodes into the handpiece	Pg. 6
4.7	Connect power supply	Pg. 6
4.8	Configuration of the welding microscope	Pg. 6
4.8.1	Description of the control elements	Pg. 7
5	COMMISSIONING	
5.1	Description of the front-side controls	Pg. 9
5.2	Description of menu items	Pg. 11
5.3	Switching on the device	Pg. 10
5.4	Adjusting for the correct gas flow	Pg. 11
5.5	Control level "settings"	Pg. 11
6	SELECTION OF THE WELDING PARAMETERS AND PROGRAM MEMORY	Pg. 12
6.1	Selection of the welding parameters	Pg. 12
6.2	Expert menu	Pg. 13
6.3	Help Function	Pg. 13
6.4	Programming	Pg. 14
6.5	Loading saved programs	Pg. 14
6.6	Fixation welding mode	Pg. 14
7	WELDING INSTRUCTIONS	
7.1	Introduction to welding	Pg. 15
7.2	Welding with the foot switch	Pg. 15
7.2.1	Fixation welding	Pg. 16
7.3	Basics and tips	Pg. 16
7.4	Sharpening the electrodes	Pg. 16
8	CARE OF THE SYSTEM COMPONENTS	
8.1	Care of the welding equipment	Pg. 16
8.2	Care of the microscope	Pg. 17
9	TECHNICAL DATA	Pg. 17
9.1	Technical data welding device	Pg. 17
9.2	Technical data microscope	Pg. 17
9.3	Optical data microscope	Pg. 18
9.4	Technical data LCD shutter	Pg. 18
9.5	Type plate	Pg. 18
9.6	Warning notices	Pg. 19
10	TROUBLESHOOTING	Pg. 19
10.1	Welding device	Pg. 19
10.2	Microscope	Pg. 20
11	SPARE PARTS LIST	Pg. 21
12	CONTACT	Pg. 21

1. WARNING AND INFORMATION SIGNS

	Warning! "Warning" identifies a potentially dangerous situation. If this is not avoided, the consequences can be death or severe injuries.
	Caution! "Caution!" identifies a potentially hazardous situation. If this is not avoided, the consequences can be slight or minor injuries as well as property damage.
	Note! "Note" identifies the product at risk from the hazard and possible damage to the equipment.
	Important! "Important!" designates user tips and other especially useful information. This is not a signal word for hazardous or dangerous situations.

2. APPROPRIATE USE (FIELD OF APPLICATION)

- Outdoor operation is impermissible. Use this device only in dry rooms!
- Welding on all metals and alloys that are suitable for arc welding.



GENERALLY NO LIABILITY IS ACCEPTED FOR THE DURABILITY OF THE WELDING. WE RECOMMEND THAT THE WELDING BE CHECKED IN EVERY CASE

- USM: Observation and microscopic viewing of objects through the ocular of the microscope and illumination of the working area.
- The USM unit may only be used for welding if it has been properly connected to the PUK U5 M&D fine-welding device.

3. SAFETY INSTRUCTIONS

3.1 GENERAL SAFETY REQUIREMENTS



PERSONS WHO WEAR ACTIVE IMPLANTS (HEART PACEMAKERS) MUST MAINTAIN A SAFETY DISTANCE OF 20 CM BETWEEN THE WELDING CURRENT CABLE / SOURCE OF THE WELDING CURRENT AND THE IMPLANT



The opening of the device is only permitted when undertaken by an electrician. Before opening remove the mains cable and ensure that the device is de-energized. Discharge any components in the device that could hold electrical charge.

In case of doubt or uncertainty, always consult with a specialist. Our customer support department is naturally always available to assist you with their professional trained personnel, appropriate tooling and equipment. Always use the original cables and ensure that workpiece clamps are properly attached.

Both the mains and welding currents can be a source of danger.

The device must be isolated from the mains power when undertaking any repair or maintenance work on the power source. The power socket is to be clearly blocked when undertaking any work on the system beyond minor manipulations where it is necessary to leave the workplace, even for brief periods.

The highest and thus the most dangerous voltage in the welding circuit is the no-load voltage. The highest permissible no-load voltages are recorded in the national and international regulations in accordance with the type of welding current, construction of the current source and the extent of the electrical hazard to the workplace.

If it can be assumed that risk-free operation is no longer possible, the unit must be put out of operation and secured against being unintentionally restarted.

It can be assumed that risk-free operation is no longer possible, if

- the equipment shows visible signs of damage,
- malfunctions occur,
- or the equipment is no longer working.

The PUK U5 M&D must, as standard, be operated with a mains voltage of 115 V~.

Yellow-green wire = protective earth terminal (PE). The other wires L1 and N are to be connected to the phase and neutral conductors of the power plug.

The welding device is factory-adjusted to 115 V!

This means that as a result of the tolerance range +/-10%, the system can also be operated at 110 V~. Devices configured to voltages other than 115 V will be designated as such by means of a label.

THE DEVICE MUST ONLY BE OPENED BY AUTHORISED SERVICE PERSONNEL!

IF THE DEVICE HAS BEEN CONFIGURED FOR A CUSTOM VOLTAGE, THE TECHNICAL DATA ON THE DEVICE SPECIFICATION PLATE APPLY! MAINS PLUGS MUST CORRESPOND TO THE MAINS VOLTAGE AND POWER CONSUMPTION OF THE WELDING EQUIPMENT (see technical data!)

THE FUSING FOR THE MAINS SUPPLY MUST BE MATCHED TO THE POWER CONSUMPTION OF THE WELDING EQUIPMENT!

ONLY USE THE SUPPLIED MAINS CABLE!



THE PUK U5 M&D IS A PIECE OF ELECTRICAL EQUIPMENT. NATIONAL REGULATIONS ON TESTING INTERVALS AND THE SCOPE OF REQUIRED RECURRING SAFETY-RELATED TESTS MUST BE OBSERVED.

3.2 HAZARDS AND PERSONAL BODY PROTECTION



Protective gloves must be worn when welding. The protective gloves must not contain a high proportion of easily melting plastic fibers.

Uncovered areas of the skin are exposed to UV radiation produced during welding, which will cause skin damage.

Wear suitable clothing; do not wear articles of clothing made with synthetic fibers.

The workpiece and electrode tip can become extremely hot during welding operation – risk of burns. Also sparks and spatters can never be excluded when welding.

The tip of the electrode fastened into the handpiece can present a risk of injury (stab injuries and scratches e.g. to the hands, face and eyes).



EYE PROTECTION WHEN WELDING:

Never look into the arc without eye protection; always use a welding mask with certified protective glass.

In addition to light and thermal radiation, which can cause dazzling and burning, the electric arc also emits UV radiation. With insufficient protection this invisible ultraviolet radiation causes very painful conjunctivitis, which can first be noticed hours later.

The USM welding microscope with its integrated LCD protective welding screen offers reliable protection against these risks and provides permanent protection from UV /

IR rays in both light and dark state. The protective class of the filter is defined such that dazzling by the arc is effectively prevented.

Persons who are nearby to the electric arc and assistants must also be informed of the dangers and equipped with the appropriate protection; if necessary set up protective partition walls.

EYE PROTECTION WHEN OPERATING THE LED ILLUMINATION:

Never look into the LED lamp or its reflections without eye protection; always use a welding mask with certified protective glass (min. protection class 3).



PROTECTION AGAINST SMOKES AND GASES:

When welding, especially in small spaces, ensure that there is an adequate fresh air supply or use an external extractor fan, as smoke and hazardous gases occur.



DANGER WHEN WELDING ON CONTAINERS:

It is not permitted to carry out welding on containers that have been used for storing gases, propellants, mineral oils or similar, even if they have been empty for a long time, as there is a risk of explosions caused by residues.

Particular regulations apply to fire and explosion endangered spaces.

3.3 HAZARDS OF SHIELDING GAS CYLINDERS



Observe all applicable safety measures when handling gas cylinders as well as the safety regulations for handling gases. Gas tanks must especially be secured against falling over / falling down

and heat (max. 50°C); it is particularly important to ensure they are not subjected to sunlight for extended periods and that they are protected from severe frost.

3.4 RISK OF ALLERGIC REACTIONS:



Please note that the device's raw materials that could come into contact with the operator's skin

may cause allergic reactions in susceptible people.

4. SETUP AND INSTALLATION

4.1 SET-UP OF THE DEVICE

The system is to be set up so that cooling air is able to reach all of the surfaces of the housing without hindrance. The device may not be covered! The device

is to be placed on a non-combustible surface! The device should be set up on a base that is solid, level, and insulated – ideally on a suitable workbench.

4.2 INSTALLATION CONDITIONS FOR THE PUK U5 M&D IN WELDING WORKSHOPS WITH MULTIPLE WELDING SETS




To avoid the electrical interconnection of two or more welding sets, there must be no electrical connection between sets (e.g. by way of a shared, electrically conductive welding table)!

This could result in a cumulative no-load voltage on the welding sets that exceeds the permitted voltage and causes danger to personnel!

There is also a risk of damage occurring to the welding sets involved.



Welding sets with HF ignition (high voltage ignition) generate a strong electric field (radiation), which could damage electrical devices in the vicinity.




When using welding sets with HF ignition (high voltage ignition), be sure to observe a spatial separation from the PUK U5 M&D, in order to rule out the possibility of interference and damage.

Also pay attention in this regard to the instructions from the manufacturer of the welding set with HF ignition!

4.3 DESCRIPTION OF THE REAR OF THE DEVICE

(Fig. 2)



- (1) FUSEBOX ("Fuse")
- (2) MASTER MAINS SWITCH as well as AC POWER SOCKET (for connecting the mains cable)
- (3) CONNECTION SOCKET FOR EYE PROTECTION SYSTEM AND LED MICROSCOPE ILLUMINATION
- (4) CONNECTION SOCKET FOR FOOT SWITCH AND ABSORBER (optional accessory)
- (5) TYPE PLATE
- (6) SERIAL NUMBER
- (7) PROTECTIVE GAS CONNECTION ("Argon Gas")
For 6.0 mm diameter pressure hose (max. 4.0 bar / 58 psi)
- (8) APPROVED MAINS VOLTAGE FOR THIS DEVICE

4.4 CONNECT EYE PROTECTION AND LED ILLUMINATION OF THE WELDING MICROSCOPE TO THE PUK U5 M&D:

The circular connector for the eye protection system and the LED illumination should be inserted into the connecting socket (3) on the rear of the PUK U5 M&D

welding device (marked in red and yellow colour) and is to be tightened in place with the coupling nut (hand tight).



WARNING!
ONLY SUITABLE ORIGINAL EYE PROTECTION SYSTEMS FROM LAMPERT MAY BE CONNECTED TO THE WELDING SYSTEM!

OTHER EYE PROTECTION SYSTEMS ARE NOT APPROVED AND CAN LEAD TO PERMANENT HEALTH DAMAGE OR DAMAGE TO THE WELDING DEVICE.



ALWAYS OBSERVE THE OPERATING INSTRUCTIONS FOR THE CONNECTED EYE PROTECTION SYSTEM

4.5 CONNECT SHIELDING GAS SUPPLY:

Fasten the suitable flow regulator with the corresponding tool to the shielding gas tank. ATTENTION: In doing so, always observe the enclosed special operating instructions provided. (Where possible, use argon with

min. 99.99 % purity, e.g. "Argon 4.6"). The pressure hose is to be fastened by hand with the help of the quick coupling adapter to the flow regulator as well as the shielding gas connector (7) on the rear of the device.




CHECK REGULARLY THAT ALL OF THE HOSE CONNECTIONS AND GAS HOSES ARE IN OPTIMAL CONDITION, ARE PROPERLY FASTENED AND ARE AIRTIGHT!

4.6 INSERTING THE ELECTRODES INTO THE WELDING HANDPIECE:



PLEASE ALWAYS CHECK THAT THE MACHINE IS SWITCHED OFF, PRIOR TO EXCHANGING THE ELECTRODES. THIS PREVENTS UNCONTROLLED TRIGGERING OF THE WELDING PROCESS.

(Fig. 3)



Lightly rotate the nozzle (10) back and forth and in doing so, pull it off of the handpiece (13). It is only pushed-on, not screwed in place.

Release the threaded electrode connection (12), insert a well sharpened tungsten electrode (11) and tighten up (hand-tight – do not use a tool to tighten).

Now replace the nozzle.

(Fig. 4)



The electrode must protrude approx. 4 – 6 mm out of the nozzle (Fig. 4).



ONLY USE THORIUM OXIDE FREE ORIGINAL ELECTRODES

Subsequently insert the connector of the handpiece as straight as possible into the socket (23) on the front of the PUK U5 M&D and fasten in place by tightening the

coupling nut hand-tight in a clockwise direction. Insert the connecting cable used into the socket (24) on the front side of the housing.

4.7 CONNECT POWER SUPPLY:

Insert the power cable with the mains connector into the corresponding socket (2) on the rear of the housing and

insert the mains plug into a suitable socket with the correct mains voltage.



CAUTION!

AS SOON AS THE MASTER MAINS SWITCH ON YOUR PUK U5 M&D IS SWITCHED ON, THE VOLTAGE IS APPLIED TO THE CONNECTED CROCODILE CLIPS OR CABLES. IT IS TO BE ENSURED THAT THESE PARTS ARE NOT ALLOWED TO COME INTO CONTACT


WITH ELECTRICALLY CONDUCTIVE OR EARTHED PARTS, SUCH AS THE HOUSING, ETC. IN DOING SO, THERE IS NO RISK FOR THE OPERATOR, WITH THE EXCEPTION OF POSSIBLE CIRCUMSTANCES ARISING FROM OPERATING ERROR.

4.8 CONFIGURATION OF THE WELDING MICROSCOPE



ESSENTIAL PRIOR TO THE INITIAL WELDING OPERATION: PRECISE CONFIGURATION OF THE MICROSCOPE OPTICS

4.8.1 DESCRIPTION OF THE CONTROL ELEMENTS



- (1) OCULAR
- (2) DIOPTER CONTROL
- (3) OCULAR TUBES
- (4) LOCKING SCREW
- (5) PRISM HOUSING
- (6) GLARE PROTECTION FILTER (SHUTTER)
- (7) PROTECTIVE GLASS
- (8) HEAD
- (9) ROTARY FIXING KNOB OF THE HINGED BRACKET
- (10) FOCUSING KNOB
- (11) LED LIGHTING
- (12) MAGNET SWITCH
- (13) MAGNET
- (14) SHUTTER AND LED LIGHTING CONTROL LEADS
- (15) EYE CUPS

FIRST STEPS

Stand the magnet of the supporting arm with its underside on a firm, ferromagnetic, smooth and clean base and set the magnet switch (12) to ON.



ALWAYS CHECK MICROSCOPES STABILITY AFTER FIXING.

ADJUSTING THE INTEROCULAR DISTANCE

Look through the two oculars (1) and move the ocular tubes (3) inwards or outwards by holding the prism housing (5) still and moving them in or out. The interocular distance is correct if the range of vision as viewed through

the two oculars is complete and is united into a single image. The interocular distance should be individually set for each user.

FOCUSING

Rotate the focusing knob (10) to a medium focus range. Adjust the mounting height of the microscope head: Hold the microscope head (8) with one hand, without touching one of the lenses, and use the other hand to release the screw on the head bracket. The head can now be moved.

Look through the oculars and move the microscope head up or down until the object appears focused. Now re-tighten the adjusting screw on the head bracket once more. Subsequently use the focusing knob (10) to focus the image.



THE MICROSCOPE HEAD IS UNSECURED WITH FIXING ROTARY KNOB LOOSENED.

DIOPTRE ADJUSTMENT

The sleeve for adjusting the diopter (2) is fitted to the left-hand ocular. In the normal position, the lower part of the tube is aligned to the marking on the ocular tube. In the event of differing vision in both eyes: Open the right eye only, look into the right-hand ocular and adjust the focus

using the focusing knob (10). Now look through the left-hand ocular with your left eye and adjust the focus by turning the diopter control (2) on the left tube until the image appears focused.

5. COMMISSIONING


5.1 DESCRIPTION OF THE FRONT-SIDE CONTROLS

(Fig. 1)



- (21) TOUCHSCREEN-DISPLAY with slide function
- (22) CONNECTION SOCKET FOR HANDPIECE (-)
- (23) SOCKET (-)
For connecting the blue contact clamp for fixation welding
- (24) SOCKET (+)
For connecting contact elements such as welding table, contact terminals and clamps.
- (25) ROTARY CONTROLLER
Select the welding power/time or switch to the next user level
 - Pressing the rotary controller for a short time (< 1 second) switches from the power parameter (POWER) to the pulse duration parameter (TIME). (It jumps back to power automatically after 1 second)
 - Turning the controller to the left or the right changes the selected parameter.
 - Pressing the controller for a longer time (> 1 second) switches to the next user level, see chapter 5.2.


TOUCHSCREEN



- (27) Select the material or welding program (depending on the user level) by sliding to the left or right within the selected user level. Press and hold for 2 seconds to call the save menu.
- (28) Foot switch activated
- (29) Output scale as a percentage (POWER in %)
- (30) Recommended setting range
- (31) Pulse duration scale in milliseconds (TIME in ms)
- (32) Preselect welding situation and pulse shape (depending on user level)

5.2 EXPLANATION / OVERVIEW OF MENUS

(Fig. Schematic diagram of user levels)



ONCE IT IS SWITCHED ON, THE PUK U5 M&D STARTS UP IN ITS START LEVEL (MAIN MENU). THE FOLLOWING USER LEVELS CAN BE NAVIGATED AFTER PRESSING LONGER (> 1 SEC.) THE ROTARY CONTROLLER (25):

- a) Start level (main menu):
Preselection of the material to be welded and preselection of the welding situation with display of the recommended settings range for welding power and pulse duration
- b) Expert level (if activated in the settings)
Arbitrary preselection of the various welding curves
- c) User programs and stored custom settings (if activated in the settings)
- d) Fixation welding (if activated in the settings)

- e) Settings (Language, gas valve, lighting,...)

At the start level and in "Custom Programs", sliding in the header bar on the display scrolls between the different preset materials or stored programs depending on the selected user level.

Beginners using the PUK U5 M&D system are advised to remain within the start level.

PRESSING THE SELECTED MATERIAL (27) IN THE TOP OF THE DISPLAY FOR 2 SEC. CAUSES THE PROGRAMMING MENU TO BE LAUNCHED:

- f) Selection of the memory location and saving the settings (if activated in the settings). Storing custom welding parameters (20 memory slots)
- g) Input and saving of the desired program (if activated in the settings)

5.3 SWITCHING ON THE DEVICE



First, carefully open the gas tank valve. Then switch the master mains switch (2) on the rear of the housing to the "I" position – the display shows the safety prompt regarding eye protection and the operating manual. Confirm your compliance with the safety instructions by pressing the rotary controller or by touching the touchscreen.

5.4 ADJUSTING FOR THE CORRECT GAS FLOW



PLEASE CONSIDER THAT GOOD WELDING RESULTS CAN ONLY BE ACHIEVED WITH A CORRECTLY ADJUSTED GAS FLOW.


In order to configure the correct gas flow, activate the "Gas valve" in the "Settings" menu (see chapter 5.5). This opens the gas valve in the welding device. Now set the flow regulator to the correct flow rate of approx. 2 - 3

litres/min. In doing so, also observe the instructions provided with the flow regulator. Once the gas volume is correctly adjusted, close again the "Gas valve" function by pressing the corresponding button.

5.5 OPERATING LEVEL "SETTINGS"

The "Settings" user level can be used to modify basic settings and launch various test functions.


• Gas valve:



Pressing the corresponding button causes the gas valve to be opened. This function is important in order to set the correct gas flow on the flow regulator (see chap.

5.4). Pressing the button again causes the gas valve to be closed. In addition, any other operation of the device will automatically quit that function.

• Filter test:



Pressing this button causes a shading of the eye protection filter.

This enables correct function of the eye protection filter to be checked. Pressing the button again quits the test.


• LED light:



Pressing the button enables the brightness of the LED lamp on the

welding microscope to be adjusted in 3 steps or to be switched off.


• Program memory:



You can activate or deactivate the saving and calling functions for programs that you created yourself

here. If this menu is activated, it appears as an additional user level. The user levels can be toggled by pressing the rotary controller for 1 second.


• Expert Menü:



The expert menu can be activated here. If this menu is active, it appears as an additional user level.

The user levels can be toggled by pressing the rotary controller for 1 sec. or longer.


• Fixation:



Pressing this button activates or deactivates the operating menu for fixation welding. If this menu is

activated, it appears as an additional user level. The user levels can be toggled by pressing the rotary controller for 1 sec. or permanently.

• Welding sequence:



You can press the button to preselect a "standard" or "short" basic welding sequence. If you

select "short", a shortened gas pre-flow time results in a shorter time gap for triggering in a series of welding points.


• Language:



Pressing the button with the country codes enables the system

language for the welding device to be changed. The system can be toggled between English and Spanish.

• Welding signal tone:



Pressing the button activates or deactivates the acoustic signal

that notifies the triggering of the weld.

6. SELECTION OF THE WELDING PARAMETERS AND USER LEVELS

6.1 SELECTION OF THE WELDING PARAMETERS

Pressing for a short time (< 1 second) the rotary controller (25) or touching the POWER or TIME scales on the display switches between the power (POWER) and pulse duration (TIME) parameters. It jumps back to power

(POWER) automatically after 1 second. Rotating the rotary controller or sliding the power (POWER) or pulse duration (TIME) scales changes the relevant value.

BASIC INFORMATION ABOUT THE EFFECTS OF WELDING POWER AND WELDING TIME:

POWER:

With the parameter "welding power" the strength of welding energy is set.

The size and intensity of the welding points are controlled in this way, i.e. the higher the power the larger the welding point.

With very thin materials too high a power level can also quickly result in damage, i.e. it makes sense to experiment with samples for beginners with the PUK U5 M&D system

to find the optimum power level, starting at a power of 20% or with very fine welding, even lower.

Power settings between 35 and 50% are considered medium welding powers.

Power levels above 70% are only practical in the most unusual circumstances. There is a danger of inhomogeneous welds and only experienced users should move outside this range.

WELDING TIME OR PULSE DURATION:

The welding time setting determines for how many milliseconds the welding power is applied, i.e. a longer pulse duration results in a longer and deeper application of the energy to the workpiece and thus simultaneously a greater development of heat.

With very thin materials, wires or other heat-sensitive materials it is recommended to use a shorter welding time.

Welding times of no more than 4 msec are recommended here.

With many copper alloys or other highly conductive metals a longer welding time can be advantageous in order to avoid hot cracks, starting at 10 msec.



IMPORTANT FOR SUCCESSFUL OPERATION WITH THE PUK U5 M&D:

Welding power and pulse duration must be considered in close context with each other in all cases! The total energy applied to the workpiece is comprised of these two parameter settings together - prior to welding this

must be considered carefully following an in-depth analysis of the welding task, the materials and the workpiece geometry.

SELECTION OF THE WELDING PARAMETERS ON THE PUK U5 M&D:

The welding parameters are set in two stages:



1) In the upper area of the display, select the metal to be welded by sliding over the metal names.

2) Pressing one of the 5 buttons on the lower edge of the display selects the given welding situation.

This selection causes numerous settings to be made in the background. The important information for the user is then shown on the display:

- A welding time is preselected and the recommended setting range for the selected welding situation is marked under the scale by means of a blue bar. Settings outside of the recommended blue setting range are always possible.
- The power is also preselected and the recommended setting range for the power is marked with a blue bar. Settings outside of the recommended blue setting range are always possible.

DESCRIPTION OF THE WELDING SITUATION WITH ASSOCIATED SYMBOL ON TOUCHSCREEN:

- In the start level, the meaning of the following symbols is always the same for each of the preconfigured materials.



Universal surface welding up to 0.8 mm wire.
Overlap the welding points.



Setting for edge welding from 0.3 mm wire.
Last welding point: tap handpiece to weld.



Welding at an acute angle.
Welding time low (ms). Energy high (%).



Filling grooves up to 1.0 mm wire.
Use a long ceramic nozzle.



Wire: Ø 0.4 mm. Weld from 3 sides.
More gas – about 3 liters.



PUSHING/TOUCHING THE RESPECTIVE BUTTON FOR 2 SEC. BRINGS UP AN INFO WINDOW ON THE DISPLAY. SEE 6.3 "HELP FUNCTION"

6.2 EXPERT MENU

>>>THE EXPERT MENU CAN BE ACTIVATED IN THE USER LEVEL "SETTINGS"



After activation, the expert mode appears as a separate user level, which can be accessed by pressing the rotary controller

for 1 second or permanently. The various welding characteristic curves are stored in the expert mode, which

have been developed and defined in the start level for the preconfigured metals and welding geometries. However, here they are shown without content-related assignment. This mode is designed for experienced welders who want to experiment with the various stored energy characteristic curves (pulse modulations). In this user level it is possible to choose between the various energy curves and store these together with individual settings for the output and time.



WHEN SWITCHING FROM THE MAIN MENU TO THE EXPERT MENU, THE RELEVANT SETTINGS ARE CARRIED OVER FROM THE MAIN MENU. THIS MEANS THAT THE WELDING CURVES STORED IN THE MAIN MENU CAN STILL BE VIEWED.

6.3 HELP FUNCTION




The buttons on the bottom of the display are provided with accessible info screens in all user levels. Touching / pressing the

button for 2 sec. causes the info screen to appear for the respective button, which contains explanatory information for the button's function. Touching the display button again causes the active user screen to be shown once more.

6.4 PROGRAMMING

SAVING CUSTOM PROGRAMS




program slot into which you want to store your custom settings.



lower case letters and special characters. You can use

1. Pressing the metal name for a longer time (2 seconds) calls the programming menu. In the first step, scroll/slide to the left/right to select the

3. The following screen provides the option of assigning a program name to the stored settings. The program name can comprise upper and



2. Then save your data by pressing the "next" button. Saved data cannot be deleted. It can only be overwritten.

the arrow buttons on the display to select the active cursor position and you can use the rotary controller (25) to select the desired characters.

Once the name has been entered, confirm your entry by pressing the "Save" button. After saving, you will be returned to the "Custom Programs" user level automatically, and the previously saved data is active.

6.5 LOADING SAVED PROGRAMS AND THE USER LEVEL "CUSTOM PROGRAMS"



All custom stored programs are summarised in the "Custom Programs"

user level. In the upper display area on this user level, select the relevant custom program by sliding to the left/right.

6.6 FIXATION WELDING

>>> THE FIXATION WELDING MENU CAN BE ACTIVATED FROM THE "SETTINGS" USER LEVEL.



After activation (see also point 5.5 / Settings), the fixation mode appears as a separate user level, which can be

accessed by pressing the rotary controller several times for 1 sec. or permanently.

This mode is used for the fixation of two work piece parts. See also Chapter 7.3.1.

For using the fixation mode the foot switch is required.



PLEASE NOTE: FIXATION WELDING IS PARTICULARLY WELL SUITED FOR METALS WITH LOW ELECTRICAL CONDUCTIVITY, FOR EXAMPLE: TITANIUM AND STEEL.

7. WELDING INSTRUCTIONS



NOTE!

PRIOR TO WELDING, ALWAYS CHECK THE FUNCTION OF THE EYE PROTECTION FILTER AS DESCRIBED IN CHAPTER 5.5 "FILTER TEST". IF THE EYE PROTECTION FILTER (SHUTTER) FAILS TO

SWITCH OVER FROM LIGHT TO DARK, THEN IT MUST BE IMMEDIATELY EXCHANGED BY SPECIALIST PERSONNEL.

7.1 WELDING INSTRUCTIONS

- First connect a metallic blank section of the workpiece with the contact clamp.
Lightly touch the area to be welded with the tip of the electrode until welding is carried out. In doing so, it is

important to remain in the position where initial contact is made until welding begins, i.e. neither to follow the electrode with the workpiece if it retracts slightly in the handpiece, nor to pull back.

The welding process starts automatically as soon as the electrode touches the workpiece:

- Shielding gas flows around the welding area.
- A signal tone (if activated in the settings) notifies of the arc.
- The welding protection filter is darkened.
- The arc is triggered with a slight delay and the electrode partly withdraws into the handpiece.
- The welding protection filter is lightened and the electrode returns to the initial position.
- The shielding gas supply stops or the welding process is started again by touching the workpiece.



WORK ONLY WITH EXTREMELY LIGHT CONTACT AND WITHOUT ANY PRESSURE TO THE TIP OF THE ELECTRODE!

The PUK U5 M&D is equipped with a function to prevent the electrode becoming welded to the workpiece by incorrectly pressing too hard. If a welding point has already been set and is pressed too hard to the workpiece when it comes into contact again, the welding point is not triggered; instead, an acoustic signal sounds

periodically to indicate that the electrode is pressing too hard against the workpiece. The electrode's contact to the workpiece must be stopped for a short time and the welding process must be started again.




THE WELDING PROCESS CAN BE HALTED AT ANY TIME BY MEANS OF LIFTING THE ELECTRODE AWAY FROM THE WORKPIECE.

7.2 WELDING WITH FOOT SWITCH

With the PUK U5 M&D switched off, connect the foot switch to the socket (4) marked with the blue foot switch symbol on the rear of the device. Switch the device on,

confirm the safety prompt by pressing the rotary controller or touching the screen and wait for the self-test to conclude. The device is now ready for operation.

THE FOOT SWITCH CAN BE ACTIVATED BY PRESSING AND HOLDING IT (APPROX. 2 SEC.). AN INFO MESSAGE AND A WHITE SYMBOL APPEAR IN THE DISPLAY.



Connect a metallic blank section of the workpiece with the contact clamp. Now lightly touch the workpiece with the

electrode. The eye protection system starts to turn periodically from its light to its dark setting. If the foot switch is operated in this mode, the welding process will begin automatically as described in chapter 7.1.

PRESSING AND HOLDING THE FOOT SWITCH (APPROX. 2 SEC.) (WITHOUT TOUCHING A WORKPIECE) CAUSES IT TO BE DEACTIVATED AND THE WHITE SYMBOL ON THE DISPLAY DISAPPEARS.

7.2.1 FIXATION WELDING



THE BLUE CONNECTION CABLE MAY ONLY BE CONNECTED AFTER THE MODE HAS BEEN ACTIVATED. AFTER WELDING IS COMPLETE, IT IS VITAL THAT THIS CABLE IS REMOVED AGAIN, BEFORE SWITCHING TO ANOTHER MODE, IN ORDER TO AVOID FAULTY WELDS!

Connect both of the workpieces which are to be fixed at an area of bare metal with a contact clamp, one to the blue one and the other to the black. When the two parts are touching, the welding process can be triggered, using the foot switch. The handpiece is not used during this process.

The required welding power is determined by the strength of the connection desired as well as the workpiece geometry. The welding time setting is of secondary importance in this mode, and can only be varied to a very limited extent.



AFTER WELDING HAS BEEN SUCCESSFULLY COMPLETED, AND BEFORE SWITCHING TO ANOTHER USER LEVEL, PLEASE REMOVE THE BLUE CONNECTION CABLE!



NOTE: DURING FIXATION WELDING, THE FOOT SWITCH IS ALWAYS ACTIVE, AND CANNOT BE DEACTIVATED! DURING FIXATION WELDING THE GAS PROTECTION IS DEACTIVATED!

7.3 BASICS AND TIPS IMPORTANT!

- Always work with a well sharpened electrode (see point 7.4 for information about sharpening the electrodes).
- Ensure extremely good contact between the workpiece and the contact clamp, i.e. make contact between the workpiece and the connection cable terminal at a point which is metallically blank.
- Never weld "free hand", i.e. use a hand rest. Shaking hands can cause the configured parameters to be falsified.
- Apply only light force to the electrode tip.
- Weld with the correct gas flow of 2 - 3 litres per minute and check this regularly.
- With a little experience you will notice that the angle with which you touch the workpiece with tip of the electrode affects the "direction of flow" of the welding point.
- The electrode can easily be clamped in somewhat longer for welding recessed areas.
- In many cases it is helpful to work with welding wire as a welding supplement, but never with solder.

7.4 SHARPENING THE ELECTRODES



Please switch off the machine prior to exchanging the electrodes. This prevents uncontrolled triggering of the welding process.

If possible, the electrodes should be sharpened with a diamond disk with fine or medium grain.

The recommended angle of grinding is approx. 15°.



See also the video "[Electrodes](https://www.youtube.com/LampertWelding)" on www.youtube.com/LampertWelding.

8. CARE OF THE SYSTEM COMPONENTS

8.1 CARE OF WELDING DEVICE AND WELDING MICROSCOPE

Your PUK U5 M&D as well as the welding microscope require a minimum of maintenance under normal working conditions. However, it is essential that a few points are observed in order to guarantee the functionality and to keep the spot welding device fully operational for years to come.

- Check the mains plug and cable as well as all welding and connection cables regularly for damage.
- Check that the moving parts of the handpiece move easily.
- If necessary, clean the electrode threaded assembly on the handpiece, in order to ensure optimal contact with the electrodes.
- Clean the device occasionally with a suitable cloth.
- Use the supplied dust cover to cover up the microscope after use.



IF WORK OR REPAIRS THAT ARE NOT DESCRIBED IN THESE OPERATING INSTRUCTIONS ARE NECESSARY THEN CONTACT YOUR DEALER.



WARNING!

IF FUSES REQUIRE EXCHANGING, THEN THEY MUST BE REPLACED WITH FUSES OF THE SAME TYPES AND VALUES. THE GUARANTEE IS VOID IN THE EVENT OF EXCESSIVELY HIGH FUSING!

THE DEVICE MAY ONLY BE OPENED BY A QUALIFIED ELECTRICIAN!

8.2 CARE OF THE OPTICAL COMPONENTS

Do not attempt to disassemble optical components. Please contact the local technical customer service department for repairs which are not covered by this manual.

Remove dust from the lens surface with a special brush prior to cleaning. You can obtain suitable accessories in any photography store.

Cleaning the oculars: Do not remove the oculars (1) from the ocular tubes (3).

Clean the outer surfaces. In doing so, breathe on them. Subsequently dry the lens with suitable cloth or paper for the purpose.

Dry the lens with circular movements from the centre to the outside. Do not wipe over a dried lens as they can easily be scratched.

Cleaning and exchanging the protective glass of the eye protection filter:



Never dismantle the eye protection filter (shutter)!

Only clean the surface. Use a cotton cloth with glass cleaner.

If the protective glass requires exchanging, slide it forwards out of the bracket and insert a new protective glass in the same manner.

9. TECHNICAL DATA

9.1 TECHNICAL DATA WELDING DEVICE

Device suitable for welding in dry rooms

Mains voltage	~115 V / 50 - 60 Hz +/-10 %
Mains fusing	T 6.3 A
Power consumption	400 VA
Closed-circuit voltage	30 – 43 V
No-load voltage	43 V
Duty cycle X	80 %
Max. charging time	0.8 sec.
Shielding gas	min. ARGON 99,9 %
Maximum gas pressure	4 bar / 58 psi
Protection class	I
Insulation class	B
Protection type	IP 21S
Weight	8.52 kg

9.2. TECHNICAL DATA MICROSCOPE

Optical eye protection and illumination system for exclusive use with PUK fine welding devices.

Use only in dry rooms

Operating temperature	+5 °C bis +40 °C
Lamp "LED unit"	3 W / 800 mA
Protection class	III
Insulation class	B
Protection type	IP 20
Weight	3.5 kg

9.3 OPTICAL DATA MICROSCOPE

Lens	1.0
Ocular	10 x
Working distance	140 mm
Magnification factor	10 x
Field of view	20 mm

9.4 TECHNICAL DATA LCD SHUTTER M11 (BL)

Light shade	DIN 3
Dark shade	DIN 11
Switching time	< 50 msec.
UV protection	> UV 11
IR protection	> IR 11

MARKING ON THE LCD SHUTTER: 3/11 LWT 1/1/1/3/379

Protection shade number in open state	3
Protection shade numbers in closed state	11
Manufacturer identification code	LWT
Optical quality	1
Light scattering	1
Homogeneity	1
Angular dependence	3
Number of the standard	379

Notified body for CE testing of the LCD Shutter: DIN CERTCO, Alboinstrasse 56, 12103 Berlin

9.5 TYPE PLATE

Explanation of pictographs:

A	Current	V	Voltage	IP	Protection type	Hz	Hertz
	Alternating current (AC)		Direct current	1 ~ 50-60Hz 	Mains input 1 phase / AC / 50 – 60 Hz		Read operating manual
U₀	No-load voltage	U₁	Mains voltage	U₂	Voltage at nominal load		Tungsten inert gas welding
	Earthing	I₂	Nominal welding current	I_{1max}	Power consumption under max. load	I_{1eff}	Power consumption under nominal load
X	Cyclic duration factor		Single-phase transformer		Keep away from water		

9.6 WARNING NOTICES:

	Breathing welding fumes and gases can be hazardous to your health.
	Welding sparks, hot workpiece, and hot equipment can cause fires and burns.
	Arc rays from the welding process can burn eyes and skin.
	Electro-magnetic fields can affect pacemakers.

10. TROUBLESHOOTING

10.1 WELDING DEVICE

	FAULT	CAUSE	REMEDY
1	No welding current		
	Mains master switch on, display remains off	Mains cable interrupted	Check mains cable and mains voltage
		Device fuse blown	Replace device fuse with identical fuse (same type and value)
2	No welding current		
	Mains master switch on	Welding cable connections interrupted	Check plugged connections
		Poor or zero contact to the workpiece	Establish connection to the workpiece, fasten contact clamps directly to the workpiece
3	No welding current		
	Mains master switch on	Fault due to leakage current	Switch device off and back on again If fault reoccurs, arrange for servicing of device
4	Mains fuse blows or automatic circuit breaker trips	Mains insufficiently fused or incorrect automatic circuit breaker	Fuse mains properly
		Mains protection trips during idling	Arrange for servicing of device
5	Poor welding characteristics	Incorrect shielding gas	Use inert shielding gas (Argon 4.6)
6	Poor ignition characteristics	Electrode clamped loosely in handpiece	Tighten the clamping nut in the handpiece (chap.11, no.38) <u>by hand</u> , however, tighten firmly .
7	Oxidation and rusting	Excessive gas pressure	Reduce flow rate – approx. 2 l/min is recommended
8	Severe oxidation of the welding points	Incorrect shielding gas	Use inert shielding gas (Argon 4.6)
9	Tungsten inclusions in base material	Excessive pressure of the electrodes on the workpiece	Touch workpiece with extremely light pressure.
10	Tungsten electrode welds to workpiece	Excessive pressure of the electrodes on the workpiece	Touch workpiece with extremely light pressure.

11	Tungsten electrode melts off immediately	Electrode sharpened too steeply	Use the recommended angle of grinding (approx. 15°)
12	Static discharge over the surface of the device	Special local conditions	Use special foot mat for the workspace
13	Device begins to weld immediately when touching the workpiece (no gas pre-flow)	Fault	Immediately shut down the device, arrange for servicing.
14	Device does not weld. Message on the display "Attention! Reduced welding speed!"	Max. operating temperature exceeded	Confirm by pressing "OK" on the display. Device is welding with reduced welding speed until it returns to its normal operating temperature.

10.2 MICROSCOPE

<u>PROBLEMS WITH ELECTRICAL COMPONENTS</u>			
A	The LED illumination fails to operate	Cable not connected.	Connect the plug to the connecting socket (3) marked with the red and yellow eye protection and illumination symbol on the PUK U5 M&D.
		LED faulty	Contact authorized customer service
B	Eye protection system (shutter) fails to operate	Cable connected incorrectly	Connect the plug to the connecting socket (3) marked with the red and yellow eye protection and illumination symbol on the PUK U5 M&D.
		Eye protection filter faulty	Arrange to have eye protection unit replaced by qualified personnel
<u>IMAGE QUALITY</u>			
D	Poor resolution	Oculars dirty.	Clean oculars.
E	Marks or soiling in field of vision	Oculars dirty.	Clean oculars.
		Protective glass dirty	Clean or exchange protective glass
* Note: Marks in the field of vision can also be caused by soiling in the interior of the oculars. For this reason, it is recommended to have the lenses cleaned by an authorised customer service engineer			
<u>PROBLEMS WITH MECHANICAL COMPONENTS</u>			
F	Focus is not retained	The sight slides down	Readjust the tension of the focusing knob

REPAIR


If the PUK U5 M&D or the stereo microscope should require a repair or adjustment by qualified personnel, we

always recommend to first contact your dealer or an authorized customer service.



WARNING: THE DEVICE MAY ONLY BE OPENED BY A QUALIFIED ENGINEER!

11. SPARE PARTS LIST



Handpiece

(37)	Nozzle (Ø 3 mm - Ø 4 mm)	100 150 x
(38)	Clamping nut	100 152
(39)	Chuck Ø 0.5/0.6 - 0.8 - 1 mm	100 15x
(40)	Handpiece complete	100 100 04

Gas hose:

Gas hose 6 x 4 mm (sold by the meter)	100 153
---------------------------------------	---------



PLEASE NOTE!

Nozzle (37), clamping nut (38), electrodes and chucks (39) are wearing parts and are not covered by the guarantee.

12. CONTACT

Lampert Werktechnik GmbH
Ettlebener Str. 27
97440 Werneck
Germany

Phone: +49 9722 9459 0
Fax: +49 9722 9459 100
mail@lampert.info
www.lampert.info

Text and illustrations represent the technical status at the time of printing. Subject to change.


WORKSHOP NEWS

You are interested in the possibilities of use of our fine-welding devices? Or you are searching for one or another tip on working with your PUK? Then just sign up for our newsletter on www.lampert.info!



VISIT OUR SHOWROOM!

Our video library is showing many applications from everyday goldsmith activities, our photo gallery various examples of use. Get inspired on www.lampert.info!



SECTION A: SAFETY PRECAUTIONS – READ BEFORE USING

A-1. ARC WELDING HAZARDS

- ▶ The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard.

The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-4. Read and follow all Safety Standards.

- ▶ Only qualified persons should install, operate, maintain, and repair this unit.
- ▶ During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.
- Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
 - Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.

SIGNIFICANT DC VOLTAGE exists after removal of input power on inverters.

- Turn off inverter, disconnect input power, and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use exhaust at the arc to remove welding fumes and gases.
- If ventilation is poor, use an approved air-supplied respirator.
- Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watch-person nearby. Welding fumes and gases can displace air and lower the oxygen level.

causing injury or death. Be sure the breathing air is safe.

- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.


- Wear a welding helmet fitted with a proper shade of filter to protect your face and eyes when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather and wool) and foot protection.



WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Protect yourself and others from flying sparks and hot metal.
- Do not weld where flying sparks can strike flammable material.
- Remove all flammables within 35ft (10.7m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock and fire hazards.
- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.



FLYING METAL can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.



BUILDUP OF GAS can injure or kill.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



HOT PARTS can cause severe burns.

- Do not touch hot parts bare handed.
- Allow cooling period before working on gun or torch.



MAGNETIC FIELDS can affect pacemakers.

- Pacemaker wearers keep away.
- Wearers should consult their doctor before going near arc welding, gouging, or spot welding operations.



NOISE can damage hearing.

Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder – explosion will result.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.

A-2. ADDITIONAL SYMBOLS FOR INSTALLATION, OPERATION, AND MAINTENANCE



FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.



FALLING UNIT can cause injury.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.



OVERUSE can cause OVERHEATING

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.



STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.



MOVING PARTS can cause injury.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.



WELDING WIRE can cause injury.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.



MOVING PARTS can cause injury.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.



H.F. RADIATION can cause interference.

- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive elec-tronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

A-3. Principal Safety Standards

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami FL 33126 (phone: 305-443-9353, website: www.aws.org).

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping, American Welding Society Standard AWS F4.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126 (phone: 305-443-9353, website: www.aws.org).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, P.O. Box 9101, 1 Battery March Park, Quincy, MA 02269-9101 (phone: 617-770-3000, website: www.nfpa.org and www.sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 1735 Jefferson Davis Highway, Suite 1004, Arlington, VA 22202-4102 (phone: 703-412-0900, web-site: www.cganet.com).

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards

Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3 (phone: 800-463-6727 or in Toronto 416-747-4044, website: www.csa-international.org).

Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 11 West 42nd Street, New York, NY 10036-8002 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, P.O. Box 9101, 1 Battery March Park, Quincy, MA 02269-9101 (phone: 617-770-3000, website: www.nfpa.org and www.sparky.org).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250 (there are 10 Regional Offices – phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

A-4. EMF Information

Considerations about Welding And The Effects Of Low Frequency Electric And Magnetic Fields.

Welding current, as it flows through welding cables, will cause electro-magnetic fields. There has been and still is some concern about such fields. However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power-frequency electric and magnetic fields is a human-health hazard." However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:

1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep welding power source and cables as far away from operator as practical.
5. Connect work clamp to workpiece as close to the weld as possible.

About Pacemakers: Pacemaker wearers consult your doctor first. If cleared by your doctor, then following the above procedures is recommended.

OPERATING INSTRUCTIONS

"PUK Electrode Sharpener"



Dear Customer

The manual that you hold in your hands is designed to acquaint you with the operating principles and correct maintenance of your PUK Electrode Sharpener.

Please read this manual carefully, and clearly observe the guidelines it describes; this way malfunctions and operating errors can be avoided. Adhering to the guidelines will promote the working life of the machine, and assure that it remains in constant operational readiness during this time; it will also ensure your personal safety.

THIS DEVICE MAY ONLY BE OPERATED BY QUALIFIED PERSONNEL, AND THEN ONLY FOR ITS DESIGNATED USE AND IN ACCORDANCE WITH THE GUIDELINES CONTAINED IN THIS MANUAL. THE MANUFACTURER ACCEPTS NO RESPONSIBILITY, AND IS IN NO WAY LIABLE FOR DAMAGE CAUSED BY IMPROPER USE, OR OPERATION, OF THE MACHINE.

BEFORE FIRST USING YOUR PUK ELECTRODE SHARPENER, PLEASE BE SURE TO CAREFULLY READ THE MANUAL SECTIONS "GENERAL SAFETY REQUIREMENTS", "SAFETY OPERATION AND USE OF THE PUK ELECTRODE SHARPENER" AND "PERSONAL SAFETY".

Please retain these instructions for reference.

The equipment made by "Lampert Werktechnik GmbH", fulfils the conformity requirements of CE certification and is manufactured according to VDE guidelines.

When overhauling or reconditioning our devices, we strongly advise to use original parts only. Our customer service team is at your disposal, and will gladly assist in any way they can.

THE DEVICE MAY ONLY BE OPENED, OR ALTERATIONS CARRIED OUT, BY AUTHORISED CUSTOMER SERVICE TECHNICIANS. NONCOMPLIANCE WILL RESULT IN ALL WARRANTIES AND LIABILITY CLAIMS BECOMING VOID.

Lampert Werktechnik GmbH

September 2017

TABLE OF CONTENTS

A	SAFETY NOTICES AND TERMINOLOGY USED	2
1	DESIGNATED USE	2
2	SAFETY INSTRUCTIONS	3
2-1	General safety instructions	3
2-2	Safety instructions when sharpening electrodes	3
2-3	Personal safety and potential risks	3
3	INSTALLATION	4
3-1	Setup guidelines	4
3-2	Controls, functions and features	4
3-3	Starting up	4
4	INSTRUCTIONS FOR USE	5
4-1	Operating the PUK Electrode Sharpener	5
4-2	Changing the grinding wheel	5
4-3	Care and maintenance	5
5	SERVICE AND WARRANTY	6
6	TECHNICAL DATA	6
7	DISPOSAL INFORMATION	6
8	CONTACT	6

A SAFETY NOTICES AND TERMINOLOGY USED



Warning!

“*Warning!*” Denotes a potentially dangerous situation. Failure to comply with these notices can result in serious injury or even death.



Caution!

“*Caution!*” These notices show a situation that can result in minor injury or damage to property if not complied with.



Please note!

“*Please note!*” Points out situations where ignoring the safety notice can negatively affect the result of work being carried out and damage the equipment.



Important!

“*Important!*” Notices are helpful hints and other particularly useful pieces of information. They do not indicate a potentially dangerous or harmful situation.

1. DESIGNATED USE



The PUK electrode sharpener has been designed specifically for use in conjunction with appropriate PUK precision welding devices, (machines made in, or after 2011).

The PUK electrode sharpener is approved exclusively for the sharpening of Lampert tungsten electrodes supplied by Lampert or its distributors.

Any other application of the appliance, other than the above stated, is prohibited.

2. SAFETY INSTRUCTIONS



2-1 GENERAL SAFETY INSTRUCTIONS

SAFETY AT THE WORKPLACE

- Never work in an environment where there is a risk of explosion; areas that contain flammable liquids, gases or dusts, are to be avoided. Electrical appliances produce sparks that can ignite combustible dusts or vapours.

SAFE HANDLING OF ELECTRICAL APPLIANCES

- No alterations or modifications of any kind may be made to the connecting plug of the unit.
- The PUK electrode sharpener may only be used in conjunction with appropriate PUK precision welding devices (machines made in, or after, 2011).
- The PUK electrode sharpener may only be connected to the machine via the designated connecting socket, located on the back of the PUK.
- Avoid exposure to wet or damp conditions.

SAFE OPERATION AND USE OF THE PUK ELECTRODE SHARPENER

- Always disconnect the electrode sharpener from the power supply, before changing or replacing the grinding wheel. This precautionary measure prevents an accidental operation of the device.
- As a general rule, electrical appliances must be kept out of reach of children.

! WARNING !

APPROPRIATE PROTECTIVE MEASURES MUST BE TAKEN, WHEN WORKING UNDER CONDITIONS IN WHICH HAZARDOUS, FLAMMABLE OR COMBUSTIBLE DUSTS CAN OCCUR. WEAR A PROTECTIVE MASK, AND IF NECESSARY ALSO USE A DUST EXTRACTION SYSTEM.



2-2 SAFETY INSTRUCTIONS WHEN SHARPENING ELECTRODES

This electrical appliance, including its provided grinding wheels, is only intended for the purpose of sharpening the tips of electrodes.

Only use grinding wheels which are approved and authorized for use with the PUK electrode sharpener.

Never use damaged grinding wheels.

Never put the appliance down before the grinding wheel has come to a complete stop.

Do not use the PUK electrode sharpener near combustible materials, as sparks that may occur during operation may cause these materials to ignite.

AVOIDING KICKBACK AND JAMMING

Kickback is the sudden jolt that can occur when the rotating grinding wheel becomes caught, or is jammed. A grinding wheel that becomes caught or jammed will come to a sudden stop; this is due to improper use, and can be avoided if the following appropriate safety precautions are taken.

- When sharpening, do not apply pressure to the grinding wheel. It is sufficient to guide the electrode lightly over the surface of the grinding wheel.
- When sharpening, always make sure to hold the electrode in the direction of travel of the turning grinding wheel.



2-3 PERSONAL SAFETY AND POTENTIAL RISKS

PERSONAL SAFETY

- Whenever using electrical appliances always take a common-sense approach and work with appropriate concentration.
- Wear suitable protective clothing and use eye protection or wear safety goggles. The eyes should be guarded against any foreign material that could fly out from the grinding wheel during the sharpening process; wherever appropriate, also wear a dust mask.
- Remove the Allen key before switching the appliance on.
- Always keep hair, clothing and gloves well away from any moving parts, as loose clothing, jewellery or long hair may become caught.

3. INSTALLATION

3-1 SETUP GUIDELINES

The PUK electrode sharpener is intended solely for use in dry, damp free, environments.

3-2 CONTROLS, FUNCTIONS AND FEATURES




"On/off" button (1)

Diamond grinding wheel (2)

Opening for Allen key (3)

3-3 STARTING UP

CONNECTING THE SHARPENER (depending on the configuration):



Connect the T-connector (5), which is included with the PUK electrode sharpener, to the socket marked "LED-Lamp" (4); this is located on the back of the PUK welder.

Attach the connecting plug of the PUK electrode sharpener (6), to any of the two sockets of the T-connector (5).

OR



Connect the wall power supply of the grinding motor to a 115V or 230V power outlet.

4. INSTRUCTIONS FOR USE

4-1 OPERATING THE PUK ELECTRODE SHARPENER

When using the PUK electrode sharpener for the first time, start by holding the appliance in your hand to get a feeling for the device.
Always hold the machine so that it is pointed away from your face; always wear protective goggles.



PLEASE NOTE!

Work without applying pressure to the grinding wheel.
Because of the speed of rotation of the diamond grinding wheel, it is sufficient to just guide the electrode lightly over the surface of the wheel.
Always make sure to hold the electrode, and sharpen, in the direction of travel of the turning grinding wheel. Failure to comply can result in the grinding wheel becoming jammed.

HANDLING THE APPLIANCE

The best results are achieved when the electrode is held between thumb and forefinger.

THE "ON/OFF" BUTTON

By pressing the button on the side of the PUK electrode sharpener, the appliance can be switched on. To switch the motor off again, simply release the button again.

4-2 CHANGING THE GRINDING WHEEL



BEFORE CHANGING THE DIAMOND GRINDING WHEEL:
ALWAYS DETACH THE CONNECTING PLUG OF THE PUK ELECTRODE SHARPENER FROM THE SOCKET OF THE PUK WELDER.



ONLY USE GRINDING WHEELS WHICH ARE APPROVED AND AUTHORIZED FOR USE WITH THE PUK ELECTRODE SHARPENER.

Removing the grinding wheel,:

- Slide the Allen key (1,5mm) into the opening on the side of the PUK electrode sharpener (3).
- By hand, turn the diamond grinding wheel until the Allen key slots into the recess on the side of the flange, under the grinding wheel.
- Once the Allen key has been slotted in, the grinding wheel can then be loosened by turning the Allen key in an anti-clockwise direction.



The grinding wheel can now be removed and a new one inserted. Make sure that the surface of the grinding wheel always finishes flush with the rim of the casing of the PUK electrode sharpener.

To re-tighten the new grinding wheel, follow step "b)" above and then carefully turn the Allen key in a clockwise direction again.

4-3 CARE AND MAINTENANCE

BEFORE CLEANING THE PUK ELECTRODE SHARPENER:
Always detach its connecting cable from the socket of the PUK welder.

Compressed air is most suitable for cleaning the PUK electrode sharpener. Here, when cleaning tools with compressed air, it is important to remember to always wear protective goggles. If applicable and necessary, a dust mask should also be worn.

In order to prevent risks or damage when carrying out maintenance or repair work, any necessary work should always be done by an authorized and qualified person.

5. SERVICE AND WARRANTY

All defects or damage that are the result of normal wear-and-tear, overloading the machine, or improper use and handling of the PUK electrode sharpener, are excluded from the warranty.

Should you have cause for complaint, please send the appliance, together with its purchase receipt, to your PUK distributor.

6. TECHNICAL DATA

■ Idle speed	11.700 rpm
■ Nominal speed	10.000 rpm
■ Voltage	12 V/DC
■ Rated current	0,5 A
■ Grinding speed	12 m/s
■ Weight	0,14 kg
■ Dimensions	Ø 28 x 74 mm
■ Diamond grinding wheel	Ø 20 mm

7. DISPOSAL INFORMATION

Electrical appliances, accessories and packaging should be introduced into an environmentally friendly recycling system.

8. CONTACT

Lampert Werktechnik GmbH

Ettlebener Str. 27

97440 Werneck

Phone: +49 9722 9459 0

Fax: +49 9722 9459 100

mail@lampert.info

www.lampert.info


MANUAL: REPLACING THE DIAMOND GRINDING WHEEL



Step 1: Align the grinding wheel in the housing, so that the grub screw is aligned with that side hole of the motor that is situated nearer to the front side (grinding wheel) of the grinding motor than the other hole.



Step 2: Now insert the included Allen key through the same side hole of the motor like before into the grub screw of the grinding disc and turn a half turn counterclockwise. The screw is released.



Step 3: Now insert the Allen key (or e.g. thin screwdriver) into the hole on opposite side of the housing and push the diamond wheel out, applying only light pressure.



Born in Germany.