



# MOTORTRONICS™

*Solid State AC Motor Controls*

# VMX

*Series*

**Compact Soft Starter**

**Ratings 18 - 1250A**

**USER MANUAL**



VMX604131MN - 07/12/11  
FIRMWARE VERSION 4.25

# Table of Contents

|                                              |         |                                                                    | Page |
|----------------------------------------------|---------|--------------------------------------------------------------------|------|
| <b>Chapter 1: Introduction</b>               | 1.1     | General Description .....                                          | 1    |
|                                              | 1.2     | Sizes and Ratings .....                                            | 4    |
| <b>Chapter 2 - Installation</b>              | 2.1     | Receiving and Unpacking .....                                      | 5    |
|                                              | 2.2     | Choosing a Location .....                                          | 5    |
|                                              | 2.3     | Initial Unit Inspection .....                                      | 5    |
|                                              | 2.4     | SERVICE WARNING! .....                                             | 6    |
|                                              | 2.5     | Mounting and Cleaning .....                                        | 6    |
|                                              | 2.6     | Power Terminations .....                                           | 7    |
|                                              | 2.7     | Remote Keypad Mounting .....                                       | 9    |
|                                              | 2.8     | Dimensions .....                                                   | 10   |
| <b>Chapter 3 - Motor Overload Protection</b> | 3.1     | Solid State Overload Protection .....                              | 11   |
|                                              | 3.2     | NEMA Class Trip Curves .....                                       | 13   |
| <b>Chapter 4 – Connections</b>               | 4.1     | Power Connections .....                                            | 15   |
|                                              | 4.2     | Control Connections .....                                          | 16   |
| <b>Chapter 5 – Programming</b>               | 5.1     | Introduction .....                                                 | 23   |
|                                              | 5.2     | Digital Interface .....                                            | 23   |
|                                              | 5.3     | Display Modes .....                                                | 24   |
|                                              | 5.4     | Program Mode .....                                                 | 25   |
|                                              | 5.4.5   | Fault Mode .....                                                   | 28   |
|                                              | 5.5     | The VMX Function List .....                                        | 30   |
|                                              | 5.6     | Function Descriptions .....                                        | 36   |
|                                              | 5.6.1   | Motor and Overload Functions ....                                  | 36   |
|                                              | 5.6.2   | Starting Mode .....                                                | 38   |
|                                              | 5.6.3/4 | Jog Mode / Kick Start Mode .....                                   | 42   |
|                                              | 5.6.5   | Pump-Flex Decel Mode .....                                         | 43   |
|                                              | 5.6.6   | Restart Delay .....                                                | 44   |
|                                              | 5.6.7   | Process Timer Control Mode .....                                   | 45   |
|                                              | 5.6.8   | Current and Ground Fault Protection                                | 47   |
|                                              | 5.6.9   | Lockouts, Reset & Internal Protection                              | 49   |
|                                              | 5.6.10  | Output Relays .....                                                | 56   |
|                                              | 5.6.11  | Communications .....                                               | 57   |
|                                              | 5.6.12  | System Settings .....                                              | 58   |
|                                              | 5.6.13  | Fault History and Statistical Data                                 | 60   |
| <b>Chapter 6 - Start-up</b>                  | 6.1     | Basic Startup .....                                                | 62   |
|                                              | 6.2     | Start-up Check List .....                                          | 63   |
|                                              | 6.3     | Sequence of Operation .....                                        | 63   |
|                                              | 6.4     | Testing with a smaller motor .....                                 | 64   |
| <b>Chapter 7 - Fault Conditions</b>          | 7.1     | Fault Codes and Numbers .....                                      | 64   |
| <b>Appendices</b>                            |         |                                                                    |      |
|                                              |         | Appendix 1 - Ramp Profile Details .....                            | 66   |
|                                              |         | Appendix 2: Pump-Flex® Decel Mode Application Considerations ..... | 69   |
|                                              |         | Appendix 3: Parameter Lock / User Password Instructions .....      | 72   |
|                                              |         | Appendix 4: Process Control Timer Functions .....                  | 74   |
|                                              |         | Appendix 5: External Over Load Relay Applications .....            | 82   |
|                                              |         | Appendix 6: Soft Starter Settings Record .....                     | 87   |
|                                              |         | Warranty Information .....                                         | 92   |

# Chapter 1 - Introduction

## 1.1 General Description

The **VMX Series** is a digitally programmable solid-state reduced voltage soft starter. Its six SCR design features a voltage/current ramp with an anti-oscillation circuit for smooth load acceleration. The SCRs are sized to withstand starting currents of 350% for 30 seconds and up to 600% for 10 seconds. The **VMX Series** features smooth, stepless ramp control, which reduces motor inrush current and excessive wear on the mechanical drive train components. The **VMX Series** includes a programmable keypad for setting operating parameters for the ideal starting cycle and protection features, plus easy to understand diagnostic LEDs. Starting torque, ramp time, current limit, dual ramp, and Decel control are standard features on the **VMX Series**, as well as the integrated Batch Process Timer and Time Clock Controller used for automated applications. By simply adjusting the unit's starting torque, ramp time and current limit functions, the starting electrical characteristics of the motor can be matched to the mechanical characteristics of the drive train for controlled acceleration of the load. The **VMX Series** includes solid-state electronic overload protection in addition to numerous other protective features. It requires 120VAC (220VAC optional) control power and uses dry contact inputs for Start / Stop control. Programmable auxiliary contacts and provisions for interlocking are also included.

### 1.1.1 Control Features

|                                             |                                                                                                                                                                                                                                          |
|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Acceleration Adjustments</b>             | Programmable Ramp Types:<br>Voltage Ramp (VR) or closed loop Current Ramp (CR)<br>Starting Torque: 0 - 100% of line voltage (VR)<br>or 0 - 600% of motor FLA (CR)<br>Ramp Time: 1 to 120 seconds<br>Current Limit: 200 - 600% (VR or CR) |
| <b>Dual Ramp Settings</b>                   | 4 Options:<br>Ramps 1 & 2 = VR,<br>Ramp 1 = VR, Ramp 2 = CR,<br>Ramps 1 & 2 = CR;<br>Ramp 1 = CR, Ramp 2 = VR<br>Dual Ramp Control:<br>Ramp #1 = Default,<br>Ramp #2 = Selectable via dry contact input                                  |
| <b>Deceleration Adjustments</b>             | Begin Decel Level: 0 - 100% of line voltage<br>Stop Level: 0 to 1% less than Begin Decel Level<br>Decel Time: 1 - 60 seconds<br>Programmable to Decel or coast to stop upon overload trip                                                |
| <b>Jog Settings</b>                         | Jog function selected via dry contact closure input.<br>Jog Voltage: 5 - 100%<br>Time of Jog Voltage: 1 - 20 seconds<br>Jog Current: 100 - 500%                                                                                          |
| <b>Kick Start Settings</b>                  | Kick Voltage: 10 - 100%<br>Kick Time: 0.1 - 2 seconds                                                                                                                                                                                    |
| <b>Process Timer<br/>(2 modes)</b>          | Minimum Batch Timer: Runs until timer expires<br>Maximum Batch Timer: Runs unless timer expires<br>Range: 0 - 9999 minutes                                                                                                               |
| <b>Real Time Clock (RTC)<br/>Controller</b> | 24/7 Time Clock Controller<br>Range: 1-24 hours, and 1- 7 days per week,<br>1 - 7 start events per day, works with Process Timer for run time                                                                                            |

### 1.1.2 Advanced Motor Protection Features

|                                                     |                                                                                                                                                                                                   |
|-----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Thermal Model Electronic Overload Protection</b> | A sophisticated Thermal Model of the motor operation is created in the microprocessor to accurately track all starting, stopping and running conditions thus, providing maximum motor protection. |
| <b>Two Stage Overload Curves</b>                    | Starting: Programmable for Class 5 or 10<br>Run: Programmable for Class 5 through 30 when "At-Speed" is detected.                                                                                 |
| <b>Overload Reset</b>                               | Manual (default) or automatic.                                                                                                                                                                    |
| <b>Retentive Thermal Memory</b>                     | Overload circuit retains thermal condition of the motor regardless of control power status. Unit uses real time clock to adjust for off time.                                                     |
| <b>Dynamic Reset Capacity</b>                       | Overload will not reset until thermal capacity available in the motor is enough for a successful restart. Starter learns and retains this information by monitoring previous successful starts.   |
| <b>Current Imbalance Trip</b>                       | Trip Level: 5 - 30% Imbalance in any two phases<br>Trip Delay: 1 -20 seconds                                                                                                                      |
| <b>PTC Input Trip</b>                               | Trips on greater than 750 ohms resistance on a dedicated PTC input. Can be used with an Emergency Stop or any other External Lockout.                                                             |
| <b>Over Current Trip (Electronic Shear Pin)</b>     | Trip Level: 50 - 300% of motor FLA<br>Trip Delay: 1 - 20 seconds                                                                                                                                  |
| <b>Phase Loss</b>                                   | Trips on any phase current less than 20% of unit rating.<br>Can be disabled in programming for testing with smaller loads.                                                                        |
| <b>Equipment Ground Fault Protection</b>            | Type: Residual Current Trip<br>Range: 5 – 90% of unit CT ratio<br>Trip Delay: 1 – 60 seconds                                                                                                      |
| <b>Load Loss Trip</b>                               | Under Current Trip Level: 10 –90 % of motor FLA<br>Trip Delay: 1 – 60 seconds                                                                                                                     |
| <b>Coast Down (Back Spin) Lockout Timer</b>         | Prevents restart when motor may be spinning backwards.<br>Coast Down Time Range: 1 – 60 minutes.                                                                                                  |
| <b>Starts-per-hour Lockout</b>                      | 1 – 10 successful starts per hour                                                                                                                                                                 |
| <b>Minimum Time between Starts Lockout</b>          | Range: 1 – 60 minutes between start attempts                                                                                                                                                      |
| <b>Restart Delay</b>                                | Sequential Start Feature for restarting delay after a power outage.<br>1-999 seconds after a power loss.                                                                                          |
| <b>Auto Reset</b>                                   | Can be programmed to attempt resetting after selected faults.<br>0 – 10 Attempts, 0 – 999 minutes delay between attempts.                                                                         |
| <b>Power Device Monitoring</b>                      | Shorted SCR Lockout (1 shorted SCR) and independent Shunt Trip (multiple shorted SCRs). Can be disabled in programming.                                                                           |

### 1.1.3 Design Specifications

|                                                               |                                                                                                                                          |
|---------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Type of Load:</b>                                          | Three phase AC induction motors.                                                                                                         |
| <b>AC Supply Voltage:</b>                                     | Universal, 208 - 600VAC $\pm 10\%$ , 50/60 Hz.                                                                                           |
| <b>Power Ratings:</b>                                         | 18 - 1250 Amps, 7.5 - 1000 HP @ 460V.                                                                                                    |
| <b>Unit Capacity - Continuous</b>                             | Max. Amp rating is UL Listed continuous rating.                                                                                          |
| <b>Unit Capacity - Overload Rating (Percent of motor FLA)</b> | 350% - 30 seconds.                                                                                                                       |
|                                                               | 600% - 10 seconds.                                                                                                                       |
| <b>Power Circuit</b>                                          | 6 SCRs, full phase angle firing using a hard fire picket firing circuit and "Back Porch" DC carryover to avoid motor transient problems. |
| <b>SCR Firing Angle Detection</b>                             | 6 pulse Independent Locked Phase Tracking with Auto-synchronization, prevents misfiring on unstable source frequency.                    |
| <b>SCR PIV Ratings (Peak Inverse Voltage)</b>                 | 1600V                                                                                                                                    |
| <b>Phase Rotation</b>                                         | Operates with any phase sequence, or programmable rotation trip, ABC / ACB / Off.                                                        |
| <b>Transient Protection</b>                                   | RC snubber dV/dt networks on each phase.                                                                                                 |
| <b>Cooling</b>                                                | Fan assisted convection.                                                                                                                 |
| <b>Bypass Contactor</b>                                       | Standard on all NEMA 12 enclosed units.                                                                                                  |
| <b>Units 160A and less:</b>                                   | Standard on all open panel units (-BP versions).                                                                                         |
| <b>Units 210A and over:</b>                                   | Optional on open panel units (-BP versions).                                                                                             |
| <b>Bypass Contactor Rating</b>                                | Shunt rated or can be sized for Line start rated contactor. (see charts)                                                                 |
| <b>Bypass Contactor Control</b>                               | Integral control is included, but contactor can be externally controlled as well.                                                        |
| <b>Ambient Condition Design</b>                               | Open panel mount units: 0° to 50 °C (32° to 122°F)                                                                                       |
|                                                               | Factory enclosed units: 0° to 40°C (32° to 104°F)                                                                                        |
|                                                               | 5 - 95% relative humidity.                                                                                                               |
|                                                               | 0 - 3300 ft. (1000m) above sea level without derating.                                                                                   |
| <b>Control Power</b>                                          | 120VAC (customer supplied), 240VAC optional.                                                                                             |
| <b>Inputs</b>                                                 | 6 Dry (voltage free) contact inputs using 24VDC from an internal power supply.                                                           |
| <b>Programmable Outputs</b>                                   | 3 relays, 2 each Form C (SPDT), 1 each Form A (SPST).<br>Can be programmed for 26 functions, with delays or flashing.                    |
| <b>Output Relay Contact Rating</b>                            | 5 Amps, 240VAC max. (1200VA)                                                                                                             |
| <b>Dedicated Fault Output</b>                                 | AC triac solid state switch.                                                                                                             |
|                                                               | 240VAC/DC, 50mA max.                                                                                                                     |
| <b>Approvals</b>                                              | UL Listed, Canadian UL (cUL) Listed CE Approved.                                                                                         |

## 1.2 Sizes and Ratings

The Motortronics **VMX Series** starters are current rated controllers. Max. Amp ratings are for continuous duty and must not be exceeded. Always check the motor nameplate FLA and Service Factor to ensure proper sizing.

Each size has an adjustable current range from 50% to 100% of the Max Amp rating. Table 1.2 shows the Current Ratings available.

| Table 1.2 VMX Series Range |                              |
|----------------------------|------------------------------|
| Model Number               | Current Range<br>Min. - Max. |
| VMX-18-BP                  | 9 - 18                       |
| VMX-28-BP                  | 14 - 28                      |
| VMX-39-BP                  | 19 - 39                      |
| VMX-48-BP                  | 24 - 48                      |
| VMX-62-BP                  | 36 - 62                      |
| VMX-78-BP                  | 39 - 78                      |
| VMX-92-BP                  | 46 - 92                      |
| VMX-112-BP                 | 56 - 112                     |
| VMX-150-BP                 | 75 - 150                     |
| VMX-160-BP                 | 80 - 160                     |
| VMX-210-BP or -P           | 105 - 210                    |
| VMX-276-BP or -P           | 138 - 275                    |
| VMX-360-BP or -P           | 181 - 361                    |
| VMX-450-BP or -P           | 225 - 450                    |
| VMX-550-BP or -P           | 275 - 550                    |
| VMX-600-BP or -P           | 300 - 600                    |
| VMX-862-BP or -P           | 431 - 862                    |
| VMX-900-BP or -P           | 450 - 900                    |
| VMX-1006-BP or -P          | 503 - 1006                   |
| VMX-1250-BP or -P          | 625 - 1250                   |



### 1.2.1 Selecting for Service Factor Utilization

Many NEMA design motors include a design rating referred to as Service Factor (SF) that may allow continuous operation above the nameplate current rating. If using this Service Factor, the **VMX Series** starter must be sized for the total amps used. For proper selection of the **VMX Series** starter when using SF continuously, multiply the nameplate FLA by the stated Service Factor, or use stated Service Factor Amps (SFA) if listed on the nameplate. The following excerpt is from the NEMA MG-1 standards for AC Motors that describes the issues concerning the use of Service Factor ratings.

*"When an induction motor is operated at any service factor greater than 1.0, it may have efficiency, power factor and speed different than those at rated load. Locked rotor torque and current and breakdown torque will remain the same. A motor operating continuously at any service factor greater than 1.0 will have a reduced life expectancy compared to operating at its nameplate horsepower."*

When using this feature, simply program the **VMX Series** Service Factor (F002) to the nameplate rating. (See section 5.6.1.) All other adjustments to the protection circuits are done automatically within the **VMX Series**.

### 1.2.2 Selecting for Across the Line Bypass

If you need to be able to start the motor Across-the-Line when the **VMX Series** electronics are out of service, the starter can also be selected based upon the rating of the Bypass Contactor. Some users may also elect to size their Bypass Contactors per NEMA guidelines. When doing this, please refer to the Product Selection Guide for details and notes, and see Appendix 5 for special considerations regarding Overload Protection.

#### ■ Note:

The **VMX...-BP Series** starters include the ability to connect a dry contact directly to the Bypass Contactor coil control circuit. These terminals are covered when shipped and should be used **ONLY** when necessary for Emergency Bypass operation **and** with an external Overload Relay. See Appendix 5 for additional information.

No field wiring to these terminals is necessary if this feature is not used.

## Chapter 2 - Installation

### 2.1 Receiving and Unpacking

Upon receipt of the product, you should immediately do the following:

- Carefully unpack the unit from the shipping carton and inspect it for shipping damage. *If damaged, notify the freight carrier and file a claim within 15 days of receipt.*
- Verify that the model number on the unit matches your purchase order.
- Confirm that the ratings nameplate on the unit matches or is greater than the motor's HP and current rating with which it is to be used.

### 2.2 Choosing a Location

Proper location of the **VMX Series** is necessary to achieve specified performance and normal operational lifetime. The **VMX Series** should always be installed in an area where the following conditions exist:

- Ambient operating temperature:  
Panel (open chassis) unit: 0 to 50°C (32 to 122°F)  
Enclosed unit: 0 to 40°C (32 to 104°F)
- Protected from rain, moisture and direct sun.
- Humidity: 5 to 95% non-condensing
- Free from metallic particles, conductive dust and corrosive gas.
- Free from excessive vibration. (below 0.5G)
- Open panel units must be mounted in the appropriate type of enclosure. Enclosure size and type must be suitable to dissipate heat generated by the soft starter and any other components mounted inside with it.
- **Units with –BP Bypass Contactors** produce less heat than units without. Throughout all sizes, maximum heat dissipation of the VMX...-BP Series electronics, contactor coils and fans is less than 50W.
- **Units without the –BP Bypass Contactor** (optional on 210A and above), must have ventilation adequate for heat dissipation of the SCRs. This is estimated at 4.5 watts per running load amp. For example, a 200HP 460V motor with 240FLA, the maximum wattage loss of a starter w/o bypass will be 240 x 4.5, or 1080 watts. The enclosure ventilation (or air conditioning) must be capable of dissipating the amount of heat due to this wattage loss to maintain the enclosure below temperature limits.
- Care should always be taken to maximize the available space inside of the enclosure. See section 2.5.1 or contact factory for assistance in sizing enclosures.

### 2.3 Initial Unit Inspection

Make a complete visual check of the unit for damage that may have occurred during shipping and handling. Do not attempt to continue installation or start up the unit if it is damaged.

- Check for loose mechanical assemblies or broken wires which may have occurred during transportation or handling. Loose electrical connections will increase resistance and cause the unit to function improperly.
- Prior to beginning the installation, verify that the motor and **VMX Series** unit are rated for the proper amperage and voltage.



## 2.4 SERVICE WARNING!

Do not service equipment with voltage applied! The unit can be the source of fatal electrical shocks! To avoid shock hazard, disconnect main power and control power before working on the unit. Warning labels must be attached to terminals, enclosure and control panel to meet local codes. Use Lock Out tags such as the one shown when servicing equipment.

## 2.5 Mounting and Cleaning

When drilling or punching holes in the enclosure, cover the electrical assembly to prevent metal filings from becoming lodged in areas which can cause clearance reduction or actual electrical shorts. After work is complete, thoroughly clean, vacuum the area, and re-inspect the unit for foreign material.

### 2.5.1 Clearances

Make sure there is sufficient clearance all around the unit for cooling, wiring and maintenance purposes. To conserve panel space, the **VMX Series – BP** models were designed for close vertical clearances of only 1 inch (25mm) on either side. A minimum horizontal clearance of 4" (100 mm) on the top and bottom is necessary to maximize effective airflow and cooling. Also the unit must be installed with its heat sink ribs oriented vertically and running parallel to the mounting surface. Keep in mind that these are minimums. Wiring may require more clearance, particularly on the bottom.




Figure 2.5: VMX minimum mounting clearances



## WARNING!

**Remove all sources of power before cleaning the unit.**

In dirty or contaminated atmospheres, the unit should be cleaned on a regular basis to ensure proper cooling. Do not use any chemicals to clean the unit. To remove surface dust use clean, dry compressed air only, 80 to 100 psi. A three-inch, high quality, dry paintbrush is helpful to loosen up the dust prior to using compressed air on the unit. Do not use wire brushes or other conductive cleaning materials

## 2.6 Power Terminations

All line and load power terminations are to be made to tin plated copper Bus Tabs located on each unit. Bus tabs are pre-drilled to accept industry standard bolts. Some sizes come with saddle clamp terminals, however the connecting lugs are the responsibility of the user. Motortronics recommends using crimp-on lugs, although mechanical lugs are suitable as well. The following diagrams show sizes of the bus tab holes and critical spacing between them for determining the size of lug that can be used.

**Note: All wiring must be sized according to local code standards.**




Figure 2.6.1 Critical clearances for bus tab connections




Figure 2.6.2 Critical clearances for bus tab connections

## 2.6 Power Connections (cont.)




Figure 2.6.3 Critical clearances for bus tab connections

**Note: Consult factory for bus tab critical dimensions for units 210A and above**

### 2.6.1 Power Terminals:

Connection points for units of 160A and below are saddle clamps suitable for stranded wire. Connection points for units of 210A and above are bus tabs with pre-drilled holes (see below). Use appropriate compression or mechanical lugs for termination to these bus tabs.


Suggested wire sizes and tightening torques for factory-supplied connectors for conductors rated for 75°C are shown in the chart below. Always consult local codes and industry standard practices for proper wires sizes to accommodate voltage drop and ambient conditions.

| Table 2.6: VMX Series Wire Ranges and Torque Specifications |                          |                         |                            |                                             |                      |                                        |
|-------------------------------------------------------------|--------------------------|-------------------------|----------------------------|---------------------------------------------|----------------------|----------------------------------------|
| Model Number                                                | Current Range Min.- Max. | Suggested Wire Size AWG | Tightening Torque in.-lbs. | Screw / Bolt Size                           | Tightening Torque Nm | Suggested Wire Size ISOmm <sup>2</sup> |
| VMX-18-BP                                                   | 9 - 18                   | 12                      | 35                         | 1 x M5 (included)                           | 4                    | 6                                      |
| VMX-28-BP                                                   | 14 - 28                  | 10                      |                            |                                             |                      | 10                                     |
| VMX-39-BP                                                   | 19 - 39                  | 8                       |                            |                                             |                      | 16                                     |
| VMX-48-BP                                                   | 24 - 48                  | 6                       |                            |                                             |                      | 16                                     |
| VMX-62-BP                                                   | 36 - 62                  | 4                       | 45                         | 1 x M8 (included)                           | 5                    | 25                                     |
| VMX-78-BP                                                   | 39 - 78                  | 3                       |                            |                                             |                      | 35                                     |
| VMX-92-BP                                                   | 46 - 92                  | 2                       |                            |                                             |                      | 35                                     |
| VMX-112-BP                                                  | 56 - 112                 | 2                       |                            |                                             |                      | 50                                     |
| VMX-150-BP                                                  | 75 - 150                 | 0                       | 80                         | 1 x M8 (included)                           | 9                    | 70                                     |
| VMX-160-BP                                                  | 80 - 160                 | 2/0                     |                            |                                             |                      | 70                                     |
| VMX-210-BP or -P                                            | 105 - 210                | 4/0                     | 200                        | 1 x 0.38" hole (M10) for User supplied lugs | 15                   | 120                                    |
| VMX-276-BP or -P                                            | 138 - 276                | 300 kCMIL               |                            |                                             |                      | 150                                    |
| VMX-360-BP or -P                                            | 180 - 360                | 500 kCMIL               |                            |                                             |                      | 300                                    |
| VMX-450-BP or -P                                            | 225 - 450                | 2 x 250 kCMIL           |                            |                                             |                      | 2 x 150                                |
| VMX-550-BP or -P                                            | 275 - 550                | 2 x 250 kCMIL           |                            |                                             |                      | 2 x 150                                |
| VMX-600-BP or -P                                            | 300 - 600                | TBD                     | TBD                        | TBD                                         | TBD                  | TBD                                    |
| VMX-862-BP or -P                                            | 431 - 862                | TBD                     | TBD                        | TBD                                         | TBD                  | TBD                                    |
| VMX-900-BP or -P                                            | 450 - 900                | TBD                     | TBD                        | TBD                                         | TBD                  | TBD                                    |
| VMX-1006-BP or -P                                           | 503 - 1006               | TBD                     | TBD                        | TBD                                         | TBD                  | TBD                                    |
| VMX-1250-BP or -P                                           | 625 - 1250               | TBD                     | TBD                        | TBD                                         | TBD                  | TBD                                    |

Note: TBD = To Be Determined at a later date

### 2.7 Remote Keypad Mounting


The keypad / operator interface unit can be remotely mounted up to 10' (3 meters) away from the starter, i.e. on the enclosure door. A remote mounting kit is necessary, which consists of an adaptor plate, a doorframe for NEMA 1 or NEMA 12 enclosures and a pre-assembled ribbon cable available in 1-meter length increments. Detailed assembly instructions and an enclosure cutout template are included with the kit. See Product Selection Guide for part numbers of the available kits.



## 2.8 Dimensions (consult price catalog for enclosed units)

| Table 2.8: VMX Dimensions and Weights                             |                                            |                     |                     |                     |                     |                     |                     |                       |
|-------------------------------------------------------------------|--------------------------------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|-----------------------|
| Enclosure                                                         | Model Number                               | Overall             |                     |                     | Mounting            |                     |                     | Weight<br>lbs<br>(kg) |
|                                                                   |                                            | A<br>Inches<br>(mm) | B<br>Inches<br>(mm) | C<br>Inches<br>(mm) | D<br>Inches<br>(mm) | E<br>Inches<br>(mm) | F<br>Inches<br>(mm) |                       |
| Panel (open)<br>with integral<br>bypass<br>contactor              | VMX-18-BP through<br>VMX-48-BP             | 9.06<br>(230)       | 8.00<br>(203)       | 6.68<br>(169.7)     | 8.06<br>(204.7)     | 7.00<br>(177.8)     | 0.22<br>(5.6)       | 13 (5.9)              |
|                                                                   | VMX-62-BP through<br>VMX-112-BP            | 14.00<br>(355.6)    | 8.00<br>(203)       | 6.68<br>(169.7)     | 13.25<br>(336.6)    | 6.75<br>(171.5)     | 0.28<br>(7.1)       | 23<br>(10.4)          |
|                                                                   | VMX-150-BP and<br>VMX-160-BP               | 19.21<br>(487.9)    | 8.00<br>(203)       | 6.68<br>(169.7)     | 18.25<br>(463.6)    | 6.75<br>(171.5)     | 0.28<br>(7.1)       | 35<br>(15.9)          |
|                                                                   | VMX -210-BP and<br>VMX-275-BP              | 28.50<br>(723.9)    | 12.5<br>(317.5)     | 9.03<br>(229.4)     | 27.38<br>(695.5)    | 10.75<br>(273.1)    | 0.40<br>(10.2)      | 90<br>(40.9)          |
|                                                                   | VMX-361-BP and<br>VMX-450-BP               | 29.29<br>(744)      | 12.5<br>(317.5)     | 9.03<br>(229.4)     | 27.38<br>(695.5)    | 10.75<br>(273.1)    | 0.40<br>(10.2)      | 105<br>(47.7)         |
|                                                                   | VMX-550-BP through<br>VMX -600-BP          | 30.98<br>(786.9)    | 12.5<br>(317.5)     | 9.05<br>(229.9)     | 27.38<br>(695.5)    | 10.75<br>(273.1)    | 0.40<br>(10.2)      | 120<br>(55)           |
|                                                                   | VMX-862-BP through<br>VMX-900-BP           | 44.25<br>(1124)     | 25.5<br>(647.7)     | 11.86<br>(301.3)    | 27.38<br>(695.5)    | 10.75<br>(273.1)    | 0.40<br>(10.2)      | Contact<br>Factory    |
|                                                                   | VMX-1006-BP through<br>VMX -1250-BP        | 50.77<br>(1289.6)   | 25.5<br>(647.7)     | 13.28<br>(337.3)    | 27.38<br>(695.5)    | 10.75<br>(273.1)    | 0.40<br>(10.2)      | Contact<br>Factory    |
| Panel<br>(open), fan<br>cooled,<br>without<br>bypass<br>contactor | Under 210A, use –BP version as shown above |                     |                     |                     |                     |                     |                     |                       |
|                                                                   | VMX-210-P through<br>VMX-1250-P            | 20.25<br>(514.35)   | 12.5<br>(317.5)     | 9.05<br>(229.9)     | 19.00<br>(482.6)    | 10.75<br>(273.1)    | 0.40<br>(10.16)     | Contact<br>Factory    |

Figure 2.8: VMX Dimensions



**MOTOR FLA (F001)  
must be programmed  
for unit to operate!**

### 3.1 Solid State Overload Protection

The **VMX Series** Starter provides true U.L. listed I<sup>2</sup>t Thermal Overload Protection as a built-in function of the main digital processor for maximum motor protection. It simulates the tripping action of a bi-metallic overload relay, with the accuracy and repeatability of a digital control system. It is adjustable over a wide range and can be easily programmed for different trip curves.

#### 3.1.1 Thermal Memory

The **VMX Series** microprocessor uses a sophisticated “Thermal Register” in the digital memory to keep track of motor heating and cooling over time regardless of the starter’s power status. By using non-volatile memory, the **VMX Series** does not “forget” that the motor has been running even if power to the starter is turned off and turned back on. Continuous overload protection is provided based on the true thermal condition of the motor.

#### 3.1.2 Thermal Capacity

The Thermal Register is displayed as a percentage. This percentage is the motor’s remaining thermal capacity. The percentage value begins at 100, showing that the motor is cool (has 100% of its capacity available). As the motor heats up or moves toward an overload condition, the percentage begins to drop. The Thermal Capacity is derived from the programmed motor nameplate Full Load Amps (FLA) in Function **F001**, the Service Factor rating in Function **F002**, and the Overload Trip Class in Functions **F003** and **F004**. Setting these functions to the proper values provides maximum protection and eliminates nuisance tripping.

The Remaining Thermal Capacity can be viewed by using the UP or DOWN arrow keys when in the Status Display mode. From the default Phase A Current screen (dot on right side), press the UP arrow key 4 times to display **[H100]** meaning there is 100% of the Thermal Capacity (H = Heat capacity) remaining in the motor. After starting or running, the motor will use this capacity and the display will show a lower number. For example, after a cold start, the display may read **[H065]** which indicates that the motor has 65% of its thermal capacity remaining (35% used). The Status Display screens cycle back to the beginning, so the Down arrow keys can access this display as well.

Examples:

**H 100**

**100% Thermal Capacity  
remaining at rest**

**H 057**

**57% Thermal Capacity  
remaining after starting  
(43% used)**

##### 3.1.2.a Motor Full Load (FLA) Setting

Use Function **F001** to enter motor FLA as indicated on the motor nameplate. (Do not calculate for service factor, this is programmed separately in **F002**).

##### Note:

All **VMX Series** starters are shipped from the factory with **F001** set to a default value of 0000. If **F001** is left at the factory default, the unit will not operate. If the user attempts to start the **VMX Series** without entering the motor nameplate FLA, the starter will Fault and the display will read “nFLA” (no Full Load Amps).



### 3.1.3 Disabling the Overload Protection

The Overload Protection feature can be disabled if necessary. When using external devices such as Motor Protection Relays or when the **VMX Series** is wired downstream from an existing starter, this feature can be disabled to prevent conflicts with external overload protection devices. When the **VMX Series** is controlling multiple motors, the built-in Overload protection must be disabled and individual thermal overload relays must be installed on the motor leads going to each motor (see appendix 5 for additional details). To disable the Overload Protection function, use **F005**.



#### **WARNING!**

**Do NOT disable Overload Protection unless another Thermal Overload Protection device exists in the circuit for all three phases.** Running a motor without Overload Protection presents serious risk of motor damage or fire.

#### ▪ **3.1.3.a Manual Reset**

The factory default setting is Manual Reset. This means that when the Overload Trip is activated, the starter cannot be restarted without pressing the Reset key. The Overload Trip will not reset until the motor cools down (see 3.1.3.d). The Manual Reset function is also “trip free”. Holding in the Reset key will not prevent the Overload Trip from activating and protecting the motor.




#### ▪ **Note:**

When the Overload Trip activates, the Overload LED will be on solid. When the motor cools down, the LED will begin to flash, indicating that the Overload Trip can be reset.

#### ▪ **3.1.3.b Automatic Reset**

If Automatic Reset is necessary, change from Manual Reset to Automatic Reset by using Function **F005**. (See Section 5 for details). In this mode, a 3-wire control circuit will be capable of restart when the **VMX Series** has reset itself after the cool down period.

#### **WARNING!**



Two-wire control systems may restart without warning when Auto Reset of the overload protection is selected. Extreme caution should be exercised. To prevent automatic restarting with 2-wire control systems, use external interlocking to provide sufficient warning and safety to operators. A Warning Label similar to that shown below (and the one provided in the packet with this manual) must be located where visible (on the starter enclosure and/or the driven equipment) as required by local code.

**WARNING: MOTOR CONNECTED TO THIS EQUIPMENT  
MAY START AUTOMATICALLY WITHOUT WARNING**

#### 3.1.3.c Overload Protection During Bypass

When an integral Bypass Contactor is used to shunt power around the SCRs in the **VMX Series** (as in the VMX...-BP version), overload protection is maintained as long as the **VMX Series** is directly controlling the contactor. No additional Overload Relay is **necessary for normal operation**.



#### Caution:

If a Bypass Contactor is added by the user in the field (i.e. 210A units and above), care must be taken to ensure proper power routing to ensure functioning of the Overload protection. Consult factory for assistance.

- When the Bypass Contactor on a **VMX...-BP Series** has been selected to be used for Across-the-Line restart (reference section 1.2.3), supplemental overload protection may be necessary. For this application, refer to the External Overload Relay Applications supplement and wiring diagram in Appendix 5 and section 4.2.6.a.

#### 3.1.3.d Dynamic Reset Capacity

The **VMX Series** includes the ability to dynamically track the Thermal Capacity needed for a successful restart after an overload trip. It averages the Thermal Capacity consumed in the previous three successful starts, and calculates a Thermal Capacity to Start (viewed in Function **F059**). After tripping on Overload, the Thermal Register must have regained the amount recorded in **F059** before a Reset will be allowed. If the display reads **[ Inh ]** when attempting to reset an overload trip, it is indicating that the starter is **Inhibited** from being reset.

Refer to details of Function **F071** for information on emergency override of lockouts such as this.

### 3.2 NEMA Class Trip Curves

NEMA Class trip curves are based on a common tripping point of 600% of motor Full Load Amps (FLA). Curves vary by the amount of time before the unit trips. As an example, a Class 20 curve will trip in 20 seconds at 600% of FLA. The factory default setting of Class 10 will trip in 10 seconds at 600% of FLA.

#### 3.2.1 Dual Overload Trip Curves

The **VMX Series** Soft Starter provides two separate Overload Trip Protection Curves, one for starting and one for running conditions. The starter's At-Speed detection circuit determines when the motor has reached full speed. When the At-Speed condition is reached, the overload trip curve will shift from the Start to the Run level, as programmed in Functions **F003** and **F004**. See Section 5.6.1 for programming details.


#### 3.2.2 Starting Overload Trip Curve

During the start mode, Overload Trip Curves are selectable from NEMA Class 5 through Class 20 only. The default setting of Class 10 allows protection for the overload capacity of the soft starter as well as the motor. Use a higher Trip Class only if nuisance tripping occurs with the default setting.

### 3.2.3 Running Overload Curve

During the Run mode, Overload trip curves are selectable from NEMA Class 5, 10, 15, 20, 25, and 30. Program the appropriate curve according to the characteristics of your motor and load.


### 3.2.4 Overload Trip Curve Chart



Note: Factory default setting is Class 10 for both Start and Run Overload Protection

**Figure 3.2.4: VMX Series Overload Trip Curves**

## Chapter 4 – Connections



**Figure 4.1:**  
**VMX Power Connections**

*\*Larger units (210A and above) can be ordered with fan cooling instead of Bypass Contactors, but are intended for use in NEMA 1 ventilated enclosures only. Do not use the VMX starter in a sealed enclosure without a bypass contactor.*

### 4.1 Power Connections

Referring to local code standards for wire sizing and length, connect power conductors to the unit input terminals marked L1, L2, L3 (R, S, T for IEC users). Connection points for units of 160A and below are saddle clamps suitable for stranded wire. Connection points for units of 210A and above are bus tabs with pre-drilled holes (see section 2). Use appropriate compression or mechanical lugs for termination to these bus tabs. Avoid routing power wires over the control board or display. Connect the motor leads to the unit terminals marked T1, T2, T3 (U, V, W for IEC users). If control power is present, but line power is disconnected from L1, L2, L3, the display will show **[n3PH]** indicating “no 3 Phase”.

#### Caution!



**Never interchange input and output connections to the unit. This could cause excessive voltage in the control logic circuit and may damage the unit.**

#### 4.1.1 Bypass Contactor

Bypass Contactors are integral (built-in) on all VMX...-BP (panel mount), and all VMX...-E (NEMA 12 enclosed) versions. See sections 3.2.1.c and 4.2.5 for more details on contactor control and overload protection details.

#### 4.1.2 Power Factor Correction Capacitors

Power factor correction capacitors can be connected to motors controlled by **VMX Series** starters, however they must be off-line during ramping. Connect PFC capacitors to the Line side of the starter with a separate capacitor control contactor.



#### WARNING!

**Never connect power factor correction capacitors on the load side of the unit. The SCRs will be seriously damaged if capacitors are located on the load side.**

#### 4.1.3 Grounding

Connect the ground cable to the ground terminal as labeled on the unit. Refer to the National Electrical Code or your local Code for the proper ground wire sizing and be sure that the ground connector is connected to earth ground. In ungrounded systems, it is not necessary to connect a ground to the unit however local codes should always be consulted.

#### 4.1.4 Testing

The **VMX Series** can be tested with a load smaller than the motor it was originally selected to control, however additional steps must be taken to avoid tripping on Phase Current Loss. See section 5.6.9.a under “Phase Loss Protection” for additional details on performing this task.



- **Notes:**

The unit cannot be tested without a motor or other test load connected to the load side of the unit. It may be necessary to use a load bank to test the unit without a motor.

- Line voltage will appear across the output terminals if there is no motor or load connected to the unit.

#### 4.1.5 Lightning Protection

As with all electronic power controllers, protection from damage by lightning surges is recommended in areas where lightning is a significant problem. Stationary air gap lightning arrestors should be considered and utilized on the input power source. The best method of protection is to have an Isolation Contactor in front of the starter that is open when the soft starter is not in use.

#### 4.2 Control Connections

Control connections on the **VMX Series** starter are divided into 2 groups. With the unit oriented vertically, TB1 is a 12-point DC terminal block (on the left), and TB2 is a 10 point AC terminal block (on the right side). These are removable terminal blocks for ease of connection and servicing, and are provided with different spacing (pitch) between the header pins so they are not interchangeable. Following are descriptions of control connection points.



- **Note:**

Terminal numbers are shown on the side of the first and last terminal of each block. An additional 3 point terminal on the far left side is for serial communication connections (see section 5.6.11).




Figure 4.2: Control Terminal Blocks

#### 4.2.1 AC Control Power Supply Connection




Figure 4.2.1  
Control Power Supply Connection  
TB-2

Separate AC Control Power supply is required to power the electronics of the **VMX Series** starter. 120VAC is standard, order 240 VAC (optional) if necessary for your line power supply configuration. The control voltage must be connected to terminals marked A1 and A2 of TB-2 as shown in figure 4.2.1 (these are also Terminal No.'s 21 and 22). This control voltage must be customer supplied, unless an optional control power transformer (see table below) has been supplied with the unit.

| Table 3: VMX Series AC Control Power VA Requirements |           |               |                              |                              |                                |
|------------------------------------------------------|-----------|---------------|------------------------------|------------------------------|--------------------------------|
| VMX ...-BP Model                                     | PC Boards | Fans          | -BP: Bypass Contactor Inrush | -BP: Bypass Contactor Sealed | Recommended minimum CPT Rating |
| VMX-18 to 48                                         | 48        | (inc. in PCB) | 95                           | 9                            | 100                            |
| VMX-62 to 112                                        | 48        | (inc. in PCB) | 220                          | 17                           | 250                            |
| VMX-150 to 160                                       | 48        | 72            | 298                          | 12.3                         | 500                            |
| VMX- 210 to 276*                                     | 48        | 100           | 380                          | 11.6                         | 500                            |
| VMX-360 to 450*                                      | 48        | 150           | 571                          | 14                           | 750                            |
| VMX-550*                                             | 48        | 200           | 1000                         | 29                           | 1000                           |

Note: \* -P versions (w/o bypass) still require PCB and fans, plus user supplied bypass (if any).

##### 4.2.1.a Control Power Requirements

When sizing a control power transformer for the **VMX...-BP Series** starter use the above chart for minimum sizes or supply capacity. Any additional control devices powered by the same CPT must be added to the above values to ensure proper operation of the Bypass Contactor.




##### Note:

VMX-210 and larger units are available without the Bypass Contactor, but fans are still included. CPT can be sized for fan loads only if used in NEMA 1 ventilated enclosures.

##### 4.2.1.b Control Fusing

The output relay contacts (TB2) must be protected from currents in excess of 5A by either using fuses or other suitable current protection devices.

- A dedicated fault output for use in PLC or interposing relay control is available on TB1. This opto-isolated triac switch is rated for 50mA max., 10-250V AC/DC. Any circuit connected to it must be fused accordingly.



#### 4.2.2 Three-Wire Control Connection


For standard 3-wire control, connect dry (voltage free) contacts for the Stop / Start buttons as shown on the diagram directly above the terminal strip. Connect the NO contact of the Start button to Terminal 1 (far left terminal), the common point between the Stop and Start to Terminal 2 (2<sup>nd</sup> from left) and the NC from the Stop button to Terminal 3 (3<sup>rd</sup> from left).

##### 4.2.2.a Seal In Contact

The **VMX Series** uses an internally pre-wired “seal-in” contact around the Start button (Terminals 1 and 2). No external relay or auxiliary output connection is necessary.

#### 4.2.3 Two Wire Control: Relay / PLC Connection

An alternate connection for automated or unattended operation replaces the start/stop push buttons by connecting a dry (voltage free) maintained contact closure between terminals 1 and 3 as shown in Figure 4.2.3. When this contact is closed, the **VMX Series** starter will start and run. When it is opened, it is the same as a Stop command.



##### 4.2.3.a Automatic Functions and 2 Wire Control

If using the Time Clock functions (**F032-F039**) or Auto Reset functions (**F052 – F053**), special consideration must be given to using 2 wire control. Refer to Appendix 3 for additional details and information on time clock functions, and section 5.6.9 for details on using Auto-Reset functions.



##### Note:

When a maintained contact is used for start/stop it is advisable to set the overload relay to the manual reset position. This will prevent the motor from restarting if the thermal overload trips and then cools down.




##### CAUTION!

Control Terminals 1-10 of TB1 are configured using solid state devices powered internally with a 24VDC power supply. To prevent damage to the **VMX Series** control board, use dry (unpowered) contact closures only when connecting to these terminals.

If existing 120VAC or other powered control circuit must be interfaced, use isolating relays or control the **VMX Series** with 2 wire control as shown above.


#### 4.2.4 Interlock Connection



TB1 provides a connection point for an external dry (voltage free) N.C. (Normally Closed) interlock device between terminals 4 and 5. Examples where this interlock connection would be used include low oil, high temperature, or excess vibration dropout from user supplied devices. A factory-installed jumper is provided which allows the **VMX Series** unit to operate if external interlocks are not used. If this jumper is removed and an interlock is not used, the **VMX Series** unit will not function.

#### 4.2.5 Enabling the Dual Ramp and Jog Features

TB1 includes provisions for enabling the Dual Ramp and Jog functions by using external contact closures. Both features use a common +24VDC from Terminal 7 however, they can be used independently of each other or together. See sections 5.6.2 and 5.6.3 for full function descriptions and setup.




##### 4.2.5.a Dual Ramp Command

Closing a dry (voltage free) contact between TB1, terminals 6 and 7 will enable Ramp 2, and the **VMX Series** starter will respond to the settings for Ramp 2 in **F015 - F018**. If no contact closure is present, the **VMX Series** starter defaults to the Ramp 1 parameters (**F011 - F014**). See Section 5.6.2.a for setup of the Dual Ramp Feature.

The Dual Ramp feature is useful in instances where the load changes significantly. *Example:* a loaded or unloaded conveyor belt. The characteristics for starting an unloaded conveyor can be programmed for ramp 1. The characteristics for starting a loaded conveyor can be programmed for ramp 2. Ramp 2 can also be programmed for Full Voltage / Across-the-Line starting by setting the ramp time to 0 and Current to 600%.

Dual Ramp is also useful in 2-speed motor applications. Simply use an auxiliary contact from one of the speed contactors to select Ramp 2 so that separate ramp profiles can be used.




##### 4.2.5.b Jog / Remote Command

Connecting a dry (voltage free) contact between TB1, Terminals 7 and 8 will enable the Jog feature. A Start command (Run Command or Start button) is required to activate the Jog feature. See Section 5.6.3 for setup of the Jog Function.

The Jog feature can be used for tasks such as lining up machines for blade or bit changes or inching belts along to check tracking.


This input is also used to change the function of the Serial Communications port control through **F068**. For additional information, see instructions of that function in **section 5.6.11**.



##### 4.2.5.c Using Both Commands

It may be useful to initialize the Ramp 2 and Jog command simultaneously when jogging. If this is the case, terminals 6 and 8 can be jumped together and controlled with one contact closure to Terminal 7 (the common 24VDC).

#### 4.2.6 PTC Thermistor Input




The **VMX Series** starter is provided with input terminals for connecting a PTC (Positive Temperature Coefficient) Thermistor that may be imbedded in the motor. These are specialized resistors imbedded in some motor windings that increase in resistance as the temperature increases. When the **VMX Series** detects that the PTC input resistance is too high, it initiates a PTC trip, and displays [ **PTc** ] on the readout. This is independent of the Thermal Register overload current protection and provides supplemental protection for high motor ambient temperature applications. Terminals for this input are provided with a factory jumper that must be removed if the PTC input is used. These are Terminals 9 and 10 located on TB1.

PTC resistors are also found in other devices such as bearings, air receivers, oil or coolant reservoirs and air discharge systems that may require shutdown of the motor.

#### PTC Resistor Values:

The resistance must be greater than or equal to 750  $\Omega$  at 25°C. If multiple resistors are used in the motor, the sum of all resistors in series must equal or exceed this value.



#### 4.2.6.a External Over Load Relay Connection


If an external Over Load Relay (OLR) is used (see Section 3.1.3.c and Appendix 5), connect the NC aux. contact of the OLR to the PTC input after removing the jumper. When the external OLR trips, the contact will open, opening the resistance input to the PTC circuit (the resistance goes to infinity). This indicates an immediate Over Load to the starter, which trips and displays [ **PTc** ] on the readout to differentiate from the internal Thermal Over Load trip. If multiple OLRs are used, i.e. multiple motors controlled by the same **VMX Series** starter, simply wire the Aux Contacts in series as shown in Figure 4.2.6.a. See Appendix 5 for additional information.

#### Note:

An Emergency Stop Push Button or any other field device may be wired to the PTC input using NC contacts. When the contacts open, the starter will detect it as a PTC trip. Even if a PTC is used in the motor, field devices can still be added as long as the total circuit resistance is not exceeded.

- This feature is especially useful when using Decel Control because it will immediately shut off power to the motor even if Decel is active. If used this way, instruct the users as to the trip indication issues (i.e. the display will show [ **PTc** ] and the Overload LED will be on).





#### 4.2.7 Fault Signal

An optically isolated Triac output is dedicated as a fault indicator on TB1, terminals 11 and 12, labeled “**Opto**”. The output Triac switch is rated for 10 - 250 VAC/DC, **50 mA (maximum)**. If the three programmable Output Auxiliary Relays are being used for other functions, this output can easily be hooked up to a PLC or small external relay to provide a Fault signal. This Fault Output operation is permanently fixed at “Any Trip”, duplicating the Relay setting 16 as shown in Table 5.6.10.

**This output is permanently set to this function and is not programmable.**

#### 4.2.8 Output (Auxiliary) Relay Contacts


Three programmable auxiliary relays are on TB2. The **VMX Series** starter comes with three programmable dry relay output contacts. Outputs 1 and 2 are Form C (SPDT), with a Common, N.O. and N.C. Output 3 is a Form A, (SPST), N.O. contact. It is not necessary to use the programmable output auxiliary relays in the Start / Stop circuit. An internal seal-in relay is provided elsewhere (see 4.2.2.a above). Motortronics recommends fusing all outputs with external fuses.

The relays are rated for 240 VAC, 5 A and 1200 VA.

Factory default settings for these relays are as follows:

- **AUX 1** – Run / Stop (see **F060**). This contact changes state upon a Start command, returns to normal on Stop (or Begin Decel if active).
- **AUX 2** – At-Speed / Stop (see **F061**). This contact changes state upon the **VMX Series** detecting At-Speed, and returns to normal on Stop. At-Speed is determined by the **VMX Series** detecting the current dropping after reaching End-of-Ramp, or a maximum of 30 seconds after Start.
- **AUX 3** – Any Trip (see **F062**) This contact closes when any trip condition 5 – 15 (as defined in Table 5.6.10) occurs.

**All relays can be reprogrammed for a wide variety of functions. See Section 5.6.10 for additional relay programming details.**



#### 4.2.9 Bypass Contactor Control

On **VMX...-BP** version (and NEMA 12 enclosures) starters, an internal dedicated connection is used at the factory for automatically controlling the Bypass Contactor. Field wiring for Bypass Contactor operation is not required.

- **4.2.9.a Independent Bypass Contactor Control**

The **VMX...-BP Series** starters use standard industrial contactors that can be controlled independent of the starter electronics if necessary. When doing so, it is necessary to size the starter based upon the ATL (Across-the-Line) selection chart so that the contactors are rated for ATL duty instead of normal Shunt Duty. (see section 1.2.3). Supplemental overload protection will be required (see section 3.1.3.c).

Units have external terminal blocks marked for this purpose (see Appendix 5 for drawings). A dry (voltage free) contact closure between these terminals will close the bypass contactor immediately. The Bypass Contactor coil voltage is the same as the control voltage (120VAC unless the optional 240VAC control is specified), and the voltage on these terminals is the same as the coil voltage.

**No field wiring is necessary to these terminals if this feature is not used.**

For all other styles of **VMX Series**, the At-Speed signaling can be programmed into any of the three Output relays (section 4.2.8 and Table 5.6.10).

## Chapter 5 - Programming

**MOTOR FLA (F001)  
must be programmed  
for unit to operate!**

### 5.1 Introduction

It is best to operate the motor at its full load starting conditions to achieve the proper time, torque and ramp settings. Initial factory settings are set to accommodate general motor applications and provide basic motor protection. Advanced features must be enabled via programming. The only parameter that **MUST** be set by the user is motor FLA (**F001**).

### 5.2 Digital Interface

The **VMX Series** Soft Starter includes a digital keypad with eight LEDs, seven command keys, and an LED display with four alphanumeric digits.



Figure 5.2: Digital Interface

**Table 5.2: VMX Series Display Features**

|             |                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Keys        | Reset                 | Clears the Trip indication and releases the Trip Relay.                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|             | Fn                    | Enters or exits the Program Mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|             | Up and Down Arrows    | Navigates through the Status Display Mode, scrolls up and down through the Function List, increases or decreases the value of the active (flashing) digit and scrolls through the fault history. When entering values, holding the key down for more than 2 seconds will activate Auto-step, which increases its rate the longer the key is held down.                                                                                                                                                           |
| Green LEDs  | Right and Left Arrows | Each keypress shifts the active (flashing) digit to the right or left by one position, allowing you to change higher values of functions without waiting to Auto-step though large numbers.                                                                                                                                                                                                                                                                                                                      |
|             | Power On              | Control power is available at A1 and A2                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Yellow LEDs | At Speed              | The motor is at full power and the Bypass Contactor has been commanded to pull in. The SCRs are at full conduction and current has dropped.                                                                                                                                                                                                                                                                                                                                                                      |
|             | Shunt Trip            | Two or more SCRs in opposing phases have shorted, and power is flowing to the motor in the Off mode. See section 8 for additional information.                                                                                                                                                                                                                                                                                                                                                                   |
|             | Shorted SCR           | There is no voltage drop across at least one SCR phase assembly, indicating that at least one SCR is shorted. See section 8 for additional information.                                                                                                                                                                                                                                                                                                                                                          |
|             | Over Current          | Overcurrent LED lights for three sets of fault conditions:<br>1) During start, the unit saw current exceed the normal rate of increase in the first 250ms.<br>2) During Run, current exceeded either the OC setting in <b>F042</b> for the delay set in <b>F043</b> . This LED will be accompanied by <b>oCA</b> , <b>oCC</b> or <b>oCd</b> on the display.<br>3) The unit has seen a Short Circuit exceeding 10x FLA for 12.5ms. This LED will be accompanied by <b>SCA</b> , <b>SCC</b> or <b>SCD</b> display. |
|             | Phase Loss            | One or more of the phase currents dropped below the threshold during starting or running.                                                                                                                                                                                                                                                                                                                                                                                                                        |
|             | Over Temp             | Starter has tripped due to excess heat sink temperature. This will automatically reset.                                                                                                                                                                                                                                                                                                                                                                                                                          |
|             | Over Load             | Starter has tripped due to the Thermal Register reaching 0000. The Overload must reset before this fault can be cleared.                                                                                                                                                                                                                                                                                                                                                                                         |
| Display     | 8888.                 | 4 digit 7 segment display with a decimal point on the right side indicating Phase A.                                                                                                                                                                                                                                                                                                                                                                                                                             |

### 5.3 Display Modes

There are three modes of display: The Status Display Mode, the Program Mode, and the Fault Mode.

#### 5.3.1 Status Display Mode (Default Display)

The Status Display Mode displays seven “screens” of information. Motor Currents (3 phases), Remaining Thermal Capacity, Ground Current, Remaining Time on the Process Timer, and Time Base of the Time Clock Controller. This is also the entry screen for going into the Program Mode.

Status mode:

**[0000.]** The initial display on power up is four digits and the decimal. This indicates the motor current for Phase A of the motor.

**[0000]** Scroll UP to display four digits only (no decimal). This indicates the motor current for Phase B. While viewing Phase B, press the UP arrow again to view Phase C current.

**[G000]** Scroll UP to display the “G”. This shows the value of the current flowing to ground on the motor leads.

**[H000]** Scroll UP to display the “H”. This indicates the value of the remaining thermal capacity percentage of the motor (i.e. H070 = 70% remaining thermal capacity)

**[0000]** Scroll UP again to display the Process Batch Timer (described in Section 5.6.7). If this entire screen is flashing, the Timer is active.

**[00.00]** Scroll UP to display two pairs of digits separated by a point: This indicates the time base of the Time Clock Controller (described in section 5.6.7). If the display shows [00.00], the TCC is not enabled. This follows the time settings in **F075 – F080**.

#### Example: Figure 5.3.1

##### Reading the Status Display

**[0120.]** Indicates Phase A is drawing 120 amps.

**Press the UP arrow**

**[0121]** Indicates Phase B is drawing 121 amps.  
*NOTE: Decimal points are not present in the readouts for Phases B and C.*

**Press the UP arrow**

**[0120]** Indicates Phase C is drawing 120 amps.

**Press the UP arrow**

**[G002]** Indicates that there are 2 amps of current flowing to ground in the motor leads or motor.

**Press the UP arrow**

**[H083]** Indicates the motor has 83% of its thermal capacity remaining (H = Heat).

**Press the UP arrow**

**[0060]** Indicates there is 60 minutes remaining on the Process Timer. *If flashing, the timer is active.*

**Press the UP arrow**

**[13.30]** Indicates the time base of the Time Clock Controller is 1:30 PM (24hr time). *If flashing, the time clock is active and pending the next event.*

**Press the UP arrow**

**[0120.]** Loop back to Phase A current indication

|              | Display Shows... | Means...                     |
|--------------|------------------|------------------------------|
| Press Key... | <b>0120.</b>     | Phase A Current              |
| ↑            | <b>0121</b>      | Phase B Current              |
| ↑            | <b>0120</b>      | Phase C Current              |
| ↑            | <b>G002</b>      | Ground Fault Current         |
| ↑            | <b>H083</b>      | Remaining Thermal Capacity   |
| ↑            | <b>0060</b>      | Process Timer Remaining Time |
| ↑            | <b>13.30</b>     | Time Clock Time Base         |
| ↑            | <b>0120.</b>     | Loop Back to Phase A Current |

Figure 5.3.1: Reading the Status Display

## 5.4 Program Mode

The starter must be OFF in order to enter the Program Mode.

Use the Program Mode to view or change Function (Fn) settings. To enter the Program Mode, press the **[Fn]** key once from the Status Screen described in 5.3.1 above. The first time you enter the Program Mode after power has been cycled to the starter, the initial function **[F001]** should be displayed with the selected digit flashing. If the **VMX Series** starter has been programmed and power to the unit has not been cycled, the readout will display the last function viewed or changed. To change to a different function, use the arrow keys.

### 5.4.1 Viewing Function Programming and Values

The programming of each individual Function can be viewed without making changes (values can also be viewed in the Run Mode however, no changes can be made). Each Function is signified by the letter “F” in the beginning of the data, the 4 digit value of the function follows after pushing the **[READ/ENTER]** key

- **[F001]** The “F” indicates the programmable Function.
- **[0000]** This is the present setting of the applicable function. This display may include decimals between digits depending on the function setting’s range and incremental steps.

**Example: Figure 5.4.1**  
**Viewing a Function’s Set Value:**  
**Motor FLA Setting**

**[0000.]** Indicates that Phase A is drawing no current (unit is in Off mode).

**Press the Fn key**

**[F001]** Indicates that this is Function 001 (Motor FLA).

**Press Read / Enter key to view the F001’s value**


**[0306]** Indicates that the programmed motor FLA is 360 Amps.

**Press the Fn key to return to the function**

**[F001]** Indicates that you have returned to the Function Select screen.

**Press the Fn key again to return to the Status Display Mode**

**[0000.]** Default screen.



- **Note:**  
If password protection has been enabled, the operator will need to obtain password access before function settings can be changed. See Section 5.6.12 and Appendix 3.

#### 5.4.2 Enabling Password Protection / Parameter Lock

The **VMX Series** starter is shipped with the password protection disabled (**F070 = 0**). If it becomes necessary to prevent parameters from being changed inadvertently, set the password in function **F070**. See Appendix 3 for details. If the display reads **[ Loc]** when the **[READ/ENTER]** key is pressed, the parameter lock is enabled.

#### 5.4.3 Changing a Function's Set Value

From the instructions above, after pressing the **[READ/ENTER]** key the display will show the value of that function with one digit flashing (usually the rightmost digit). Flashing indicates this is the digit to be altered (similar to cursor position). Use the UP arrow key to increment the value of the flashing digit. Use the DOWN arrow key to decrement the value of the flashing digit. Use the LEFT or RIGHT arrow to select the next digit to be altered. Values can only be changed within the Adjustment Range of the function parameter.

##### Example 1: Figure 5.4.3

##### Viewing a Function's Set Value

**[0000.]** Indicates Phase A is drawing no current (unit is in Off mode).

**Press the [Fn] key**

**[F001]** Indicates this is Function 001 (Motor FLA).

**Press [READ/ENTER] key  
to view the F001 value**

**[0048]** Indicates the programmed motor FLA is 48 Amps. The right most digit (8) is flashing, indicating that this is the digit that you will alter (cursor position).

**Press the UP Arrow key  
to increase this digit value**

**[0049]** Indicates you have increased the right most digit to a value of 9.

**Press the LEFT Arrow key  
to shift left to the next digit**

**[0049]** The second digit from the right is now flashing, indicating a new cursor position.

**Press the UP Arrow key  
to increase this digit value**

**[0059]** Indicates you have increased the 2<sup>nd</sup> to right digit to a value of 5 (10's place).

**Press [READ/ENTER] key  
to store the new value**

**[End]** The word "End" will flash briefly to indicate that the new value has been entered and accepted. After flashing once, the display will revert to showing the Function number.

##### Example 1: Setting the Motor FLA

##### Change FLA from 48 to 59A

| Press Key... | Display Shows... | Means...                         |
|--------------|------------------|----------------------------------|
|              | 0000.            | Phase A Current                  |
| Fn           | F001             | Function #1 Selected             |
| READ ENTER   | 0048.            | Previous Setting of Function #1  |
| ↑            | 0049.            | New Value of First Digit         |
| ←            | 0049.            | Cursor (flashing) Position Shift |
| ↑            | 0059.            | New Value of Second Digit        |
| READ ENTER   | End              | Value Accepted (flashes once)    |
|              | F001             | Return to Function # Display     |

Figure 5.4.3:  
Changing a Function Value

#### 5.4.3.a Changing a Value by Increments

Although it may be easier to shift the cursor position, it is also possible to increase or decrease values by pressing the UP or DOWN arrow keys successively. This will change the Function value by the incremental amount associated with that Function. The Function List shows increment values for each Function.

#### Example 2: Figure 5.4.3.a

##### Changing a Function's Value by Increments

**[0000.]** Indicates that Phase A is drawing no current (unit is in Off mode).

**Press the [Fn] key**

**[F001]** Indicates that this is Function 001 (Motor FLA). The right most digit (1) is flashing, indicating this is the digit that you will alter (cursor position)

**Press the UP Arrow key twice to increase this digit value to 3**

**[F003]** Indicates that this is Function 003 (OL Class During Start).

**Press [READ/ENTER] key to view the F003 value**

**[0010]** Indicates that the programmed OL is Class 10 during the Start Mode. Cursor flashing on right most digit.

**Press the UP Arrow key to increase this digit value**


**[0015]** Indicates that you have increased the Function value by the increment assigned to it, a value of 5 in this case.

**Press the UP Arrow key again to increase this digit value**

**[0020]** Indicates that you have again increased the Function value by the increment assigned to it.

**Press [READ/ENTER] key to store the new value**

**[End]** The word "End" will flash briefly to indicate that the new value has been entered and accepted. After flashing once, the display will revert to showing the Function number.



#### 5.4.4 Storing the Altered Value of a Function

Once the desired value is displayed, press the **[READ/ENTER]** key. This **stores** the value in memory. The readout momentarily displays **[End]** and then returns to the function code.



#### Caution!

If the Fn key is pressed or power is lost before the **[READ/ENTER]** key is pressed, the **VMX Series Starter** will not store the selected value in memory.

### 5.4.5 Fault Mode

The Fault Mode Display provides information to the operator when a fault occurs and allows the operator to review fault history. Refer to Section 7 for details. Fault codes are displayed by 3 alpha characters. The first and second characters (reading left to right) are the initials for the applicable English-language fault name. The third or right-most character can be either A, c, or d to denote when the fault occurred. "A" denotes Acceleration. "c" denotes Constant speed. "d" denotes Decel.

#### Example: Figure 5.4.5

##### Viewing a Fault and History

[ PLA.] Indicates that there was a Phase Loss during Acceleration. The Decimal point on the right signifies that this is the current fault.

##### Press the UP Arrow key

[ IBc] Displays the previous fault, a Phase Imbalance during Constant Speed (running)


##### Press the UP Arrow key

[ oLc] Displays the oldest fault, an Over Load trip during Constant speed (running).

##### Press [RESET] key

[ rSt ] Flashes once to indicate a successful Reset of the current fault. If it cannot be reset, the display will read [ inH ] for Inhibited.

[ 0000.] Returns to Default Display, indicating that the unit is ready to re-start.




This Fault History can only be accessed during a fault condition. While the active fault number is being displayed, use the Up and Down Arrow keys to scroll through the Fault History. An additional Fault History complete with Time and Date stamps is also available for viewing at any time in **F085** through **F093**.

#### 5.4.5.a Resetting Faults

Once a fault condition has been corrected, pressing the Reset key will return the readout to the Status Display mode. To reset faults, press the **[RESET]** key on the keypad. Alternatively, most faults will reset upon removal and return of control power. Over Load trips will NOT be reset in this way unless sufficient time has passed for the Thermal Register to regain sufficient capacity for a successful restart (see section 3.1).

#### 5.4.5.b Remote Reset

Because most trips can be reset by removing control power, remote reset can be accomplished this way. A NC remote contact (or push-button) can be placed in the control power supply to A1 or A2 and opened to facilitate a trip reset. See figure 5.4.5.b for a suggested connection.



- **5.4.5.c Automatic Reset**

The **VMX Series** starter provides for automatic reset on certain non-critical faults and Over Load. For non-critical fault resets, see section 5.6.9 for program details of **F052** and **F053**. For automatic Over Load reset, see section 3.1 and 5.6.1 for programming details.

- **5.4.5.d Lockout Functions**

Lockout functions such as Minimum Time Between Starts and Starts per Hour are not true fault conditions. They are based on the internal Real Time Clock (RTC). When control power is removed, the RTC value is quickly stored. Upon return of power, the timer values are updated from the RTC for elapsed time. If the Lockout Time has not expired, the **VMX Series** cannot be started. To reset the Lockout Times for emergency restart, see section 5.6.12, under **F071**.

- **5.4.5.e Changing to Default Screen During Fault**

In some cases it may be necessary to alter programmed parameters in order to test or make changes to clear a fault (such as Phase Loss) or to view the more detailed fault history in F085 – F097. To accomplish this, you must get to the Status Screen so the Fn button becomes active. When in a Fault Screen, pressing the Right or Left Arrow buttons will take you to the Status Screen. From there, you can press the **[Fn]** key to enter the Programming Mode and move to different functions.

## 5.5 The VMX Function List

### 5.5.1 Motor FLA, Service Factor and Overload Protection Functions

| Fn #        | Group                    | Function Description                                                   | Adjustment / Display Range                                                                                        | Setting Increments | Factory Setting | Section       |
|-------------|--------------------------|------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|--------------------|-----------------|---------------|
| F001        | Motor and Overload Info. | Motor Nameplate FLA<br>FLA must be programmed for starter to function. | 50-100% of Max Amp Rating.<br>Upper limit of range automatically adjusts downward as Service factor is increased. | 1 amp              | 0               | 5.6.1 and 3.2 |
| F002        |                          | Motor Nameplate Service Factor                                         | 1.00 - 1.30 SF                                                                                                    | 0.05               | 1.0 SF          |               |
| F003        |                          | Overload Class During Start                                            | NEMA / UL Class 5 - 20                                                                                            | 5                  | Class 10        |               |
| F004        |                          | Overload Class During Run                                              | NEMA / UL Class 5 - 30                                                                                            | 5                  | Class 10        |               |
| F005        |                          | Overload Reset                                                         | 0 = Manual<br>1 = Auto<br>2 = Disabled Overload                                                                   | 1                  | 0 (Manual)      |               |
| F006 - F009 |                          | Reserved for factory use                                               |                                                                                                                   |                    |                 |               |

Table 5.5.1: Motor and Overload Function Group

### 5.5.2 Starting Mode Functions

| Fn # | Group                       | Function Description                                                                         | Adjustment / Display Range                                                                       | Setting Increments | Factory Setting | Section                      |
|------|-----------------------------|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|--------------------|-----------------|------------------------------|
| F010 | Starting and Stopping Modes | Ramp Type Selection:<br>VR = Voltage Ramp<br>CR = Current PID Ramp<br>1 = Ramp 1, 2 = Ramp 2 | Setting 1 = VR1 + VR2<br>Setting 2 = CR1 + CR2<br>Setting 3 = VR1 + CR2<br>Setting 4 = CR1 + VR2 | 1                  | 1<br>VR1+VR2    | 5.6.2 and Append. 1          |
| F011 |                             | Initial Torque (VR) of Ramp 1                                                                | 0-100% Line Voltage                                                                              | 1%                 | 60%             |                              |
| F012 |                             | Initial Torque (CR) of Ramp 1                                                                | 0-600% Motor Current                                                                             | 1%                 | 200%            |                              |
| F013 |                             | Accel Ramp Time of Ramp 1                                                                    | 1-120 seconds                                                                                    | 1 second           | 10 seconds      |                              |
| F014 |                             | Max Current Limit of Ramp 1                                                                  | 200 - 600% Motor Current                                                                         | 1%                 | 350%            |                              |
| F015 |                             | Initial Torque (VR) of Ramp 2                                                                | 0-100% Line Voltage                                                                              | 1%                 | 60%             | 5.6.2, Append. 1 and 4.2.5.b |
| F016 |                             | Initial Torque (CR) of Ramp 2                                                                | 0-600% Motor Current                                                                             | 1%                 | 200%            |                              |
| F017 |                             | Accel Ramp Time of Ramp 2                                                                    | 1-120 seconds                                                                                    | 1 second           | 10 seconds      |                              |
| F018 |                             | Max Current Limit of Ramp 2                                                                  | 200 - 600% Motor Current                                                                         | 1%                 | 350%            |                              |

Table 5.5.2: Starting Mode Function Group

### 5.5.3 Jog Mode Functions

| Fn # | Group     | Function Description | Adjustment / Display Range | Setting Increments | Factory Setting | Section           |
|------|-----------|----------------------|----------------------------|--------------------|-----------------|-------------------|
| F019 | Jog Modes | Voltage Jog          | 5 – 100% Line Voltage      | 1%                 | 50%             | 5.6.3 and 4.2.5.b |
| F020 |           | Time of Voltage Jog  | 1 – 20 Seconds             | 1 second           | 10 seconds      |                   |
| F021 |           | Current Jog          | 100 – 500% Motor Current   | 1%                 | 150%            |                   |

Table 5.5.3: Jog Mode Function Group

### 5.5.4 Kick Start Mode Functions

| Fn # | Group     | Function Description | Adjustment / Display Range                 | Setting Increments | Factory Setting | Section |
|------|-----------|----------------------|--------------------------------------------|--------------------|-----------------|---------|
| F022 | Kick Mode | Kick Start Voltage   | 0 = Disabled, or<br>10 - 100% Line Voltage | 1%                 | 0 Disabled      | 5.6.4   |
| F023 |           | Kick Start Time      | 0.1 - 2 Seconds                            | 0.1second          | 0.8 seconds     |         |

Table 5.5.4: Kick Start Mode Function Group

### 5.5.5 Decel Mode Functions

| Fn # | Group                | Function Description                                | Adjustment / Display Range                                                                                                    | Setting Increments | Factory Setting | Section             |
|------|----------------------|-----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|--------------------|-----------------|---------------------|
| F024 | Pump Flex Decel Mode | Pump Flex Control / Deceleration Ramp               | 0 = Disabled (coast to stop)<br>1 = Enabled, except after OL trip<br>2 = Enabled, continued Decel even if there is an OL trip | 1                  | 0 Disabled      | 5.6.5 and Append. 2 |
| F025 |                      | Begin Decel Level (BDL), Immediate Drop Down Torque | 0 - 100 % of Output Voltage                                                                                                   | 1%                 | 60%             |                     |
| F026 |                      | Decel Shut Off Voltage                              | 0 to (BDL minus 1)% Voltage                                                                                                   | 1%                 | 30%             |                     |
| F027 |                      | Decel Ramp Time                                     | 1 – 60 Seconds                                                                                                                | 1 second           | 10 seconds      |                     |

Table 5.5.5: Pump Flex Decel Mode Function Group

### 5.5.6 Restart Function

| Fn # | Group   | Function Description                        | Adjustment / Display Range                                                        | Setting Increments | Factory Setting | Section |
|------|---------|---------------------------------------------|-----------------------------------------------------------------------------------|--------------------|-----------------|---------|
| F028 | Restart | Restart Delay Time (Sequential Start Delay) | 0 = Disabled, or<br>1-999 seconds after a Power Loss (Status can be read in F054) | 1 second           | 0 Disabled      | 5.6.6   |
| F029 |         | Reserved for Factory Use                    |                                                                                   |                    |                 |         |

Table 5.5.6: Restart Function Group

### 5.5.7 Process Timer Features

| Fn # | Group                                     | Function Description                                                                                                                                                      | Adjustment / Display Range                                                                                                                                                                                                                                                                                                                                                                                                    | Setting Increments | Factory Setting | Section                      |
|------|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|-----------------|------------------------------|
| F030 | Run Timer and Time Clock Controller Modes | Run Timer Selection                                                                                                                                                       | 0 = Disabled (No timer operation)<br>1 = Minimum (Batch) Run Timer<br>2 = Permissive Run Timer                                                                                                                                                                                                                                                                                                                                | 1                  | 0<br>Disabled   | 5.6.7<br>and<br>Append.<br>4 |
| F031 |                                           | Run Timer Time for use in F030 above                                                                                                                                      | 1-9999 minutes after a Start Command or Start Event from TCC                                                                                                                                                                                                                                                                                                                                                                  | 1                  | 1               |                              |
| F032 |                                           | 24hr Time Clock Controller (TCC) Start Event Mode.<br><br>Chose "One Shot" or 1 to 7 "Start Events" from F033 – F039<br><br>Run time for this mode comes from F030 above. | Start Event Cycle (SEC) Settings.<br><br>1 = Loop SEC every day<br>2 = Loop SEC every 2 <sup>nd</sup> day<br>3 = Loop SEC every 3 <sup>rd</sup> day<br>4 = Loop SEC every 4 <sup>th</sup> day<br>5 = Loop SEC every 5 <sup>th</sup> day<br>6 = Loop SEC every 6 <sup>th</sup> day<br>7 = Loop SEC one day per week<br>8 = Single 24hr SEC (until programmed again)<br>0 = One Shot: Start Event comes from Start command only | 1                  | 0<br>One Shot   |                              |
| F033 |                                           | Start Event #1 Start Time                                                                                                                                                 | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                    | 1                  | OFF             |                              |
| F034 |                                           | Start Event #2 Start Time                                                                                                                                                 | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                    | 1                  | OFF             |                              |
| F035 |                                           | Start Event #3 Start Time                                                                                                                                                 | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                    | 1                  | OFF             |                              |
| F036 |                                           | Start Event #4 Start Time                                                                                                                                                 | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                    | 1                  | OFF             |                              |
| F037 |                                           | Start Event #5 Start Time                                                                                                                                                 | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                    | 1                  | OFF             |                              |
| F038 |                                           | Start Event #6 Start Time                                                                                                                                                 | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                    | 1                  | OFF             |                              |
| F039 |                                           | Start Event #7 Start Time                                                                                                                                                 | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                    | 1                  | OFF             |                              |

Table 5.5.7: Run Timer and Time Clock Controller Function Group

### 5.5.8 Current and Ground Fault Protection Features

| Fn # | Group                               | Function Description         | Adjustment / Display Range                         | Setting Increments | Factory Setting | Section |
|------|-------------------------------------|------------------------------|----------------------------------------------------|--------------------|-----------------|---------|
| F040 | Current and Ground Fault Protection | Current Imbalance Trip       | 0 = Disabled, or<br>5 - 30% imbalance              | 1%                 | 0<br>Disabled   | 5.6.8   |
| F041 |                                     | Current Imbalance Trip Delay | 1 - 20 seconds                                     | 1 second           | 2<br>seconds    |         |
| F042 |                                     | Over Current Trip            | 0 = Disabled, or<br>100 - 300% of motor FLA        | 1%                 | 0<br>Disabled   |         |
| F043 |                                     | Over Current Trip Delay      | 1 - 20 seconds                                     | 1 second           | 1 second        |         |
| F044 |                                     | Under Current Trip           | 0 = Disabled, or<br>10 - 90% of motor FLA          | 1%                 | 0<br>Disabled   |         |
| F045 |                                     | Under Current Trip Delay     | 1 - 60 seconds                                     | 1 second           | 2<br>seconds    |         |
| F046 |                                     | Ground Fault Trip            | 0 = Disabled, or<br>5 - 90% of CT ratio from Fn 74 | 1%                 | 0<br>Disabled   |         |
| F047 |                                     | Ground Fault Trip Delay      | 1 - 60 seconds                                     | 1 second           | 2<br>seconds    |         |

Table 5.5.8: Current and Ground Protection Features Group

### 5.5.9 Lockouts, Reset and Internal Protection Functions

| Fn # | Group                                   | Function Description                        | Adjustment / Display Range                                                   | Setting Increments | Factory Setting    | Section |
|------|-----------------------------------------|---------------------------------------------|------------------------------------------------------------------------------|--------------------|--------------------|---------|
| F048 | Lockouts, Reset and Internal Protection | Coast Down (Back Spin) Lockout Timer        | 0 = Disabled, or 1 - 60 minutes                                              | 1 minute           | 0 Disabled         | 5.6.9   |
| F049 |                                         | Maximum Starts per Hour                     | 0 = Disabled, or 1 – 10 starts                                               | 1                  | 0 Disabled         |         |
| F050 |                                         | Minimum Time Between Starts                 | 0 = Disabled, or 1 - 60 minutes                                              | 1 minute           | 0 Disabled         |         |
| F051 |                                         | Internal Protection Settings                | 1 – 127<br>See“ F051 Definition Table”                                       | 1                  | 127 Enable all     | 5.6.9.a |
| F052 |                                         | Auto Reset on Selected Faults               | Fault Preferences 1 – 12<br>See Table 5.6.8:<br>"Auto-Reset Selected Faults" | 1                  | 4, Phase Loss only | 5.6.9.b |
| F053 |                                         | Auto Reset Attempts                         | 0 = Disabled, or 1-10 attempts                                               | 1                  | 1                  |         |
| F054 |                                         | Restart Delay Time Value Readout (for F028) | 0-999 Minutes                                                                | 1                  | 0                  | 5.6.9.c |
| F055 |                                         | Coast Down Timer Value for F048             | 1-3600 Seconds                                                               | 1                  | 0                  |         |
| F056 |                                         | Starts Per Hour Timer Value for F049        | 1-3600 Seconds                                                               | 1                  | 0                  |         |
| F057 |                                         | Starts Per Hour For F049                    | 1-10 Starts                                                                  | 1                  | 0                  |         |
| F058 |                                         | Time Value Between Starts for F050          | 1-3600 Seconds                                                               | 1                  | 0                  |         |
| F059 |                                         | Thermal Capacity to Start for F005          | 0-100 % Thermal Capacity                                                     | 1                  | 0                  |         |

Table 5.5.9: Lockouts, Reset and Internal Protection Group

### 5.5.10 Output Relay Programming Features

| Fn # | Group         | Function Description                          | Adjustment / Display Range                          | Setting Increments | Factory Setting | Section |
|------|---------------|-----------------------------------------------|-----------------------------------------------------|--------------------|-----------------|---------|
| F060 | Output Relays | Aux Relay 1 setting                           | Operation # 1 – 26: see "Aux. Relay Settings Chart" | 1                  | 1               | 5.6.10  |
| F061 |               | Aux Relay 2 setting                           | Operation # 1 – 26: see "Aux. Relay Settings Chart" | 1                  | 2               |         |
| F062 |               | Aux Relay 3 setting                           | Operation # 1 – 26: see "Aux. Relay Settings Chart" | 1                  | 16              |         |
| F063 |               | Aux. Relay Delay Timer (for Operations 23-26) | 0 (Disabled), or 1-999 seconds                      | 1 second           | 0 No Delay      |         |
| F064 |               | Reserved for factory use                      |                                                     |                    |                 |         |

Table 5.5.10: Output Relay Function Group



#### Notes:

Check wiring to each relay before changing programming to ensure there are no unintended consequences.  
Relays programmed to some protection features will not operate if function is disabled elsewhere.

### 5.5.11 Serial Communications

| Fn # | Group          | Function Description     | Adjustment / Display Range                                                                                      | Setting Increments | Factory Setting | Section |
|------|----------------|--------------------------|-----------------------------------------------------------------------------------------------------------------|--------------------|-----------------|---------|
| F065 | Communications | Communications           | 0 = Disabled<br>1 = Enabled (11Bit)<br>2 = Enabled (10Bit)                                                      | 1                  | 0               | 5.6.11  |
| F066 |                | Baud Rate                | 4.8, 9.6 and 19.2 KB                                                                                            | 3 rates            | 9.6 KB          |         |
| F067 |                | Modbus Address           | 1 - 247                                                                                                         | 1                  | 1               |         |
| F068 |                | Remote Starter Control   | 0 = Disabled<br>1 = Enabled w/ Start button<br>2 = Enabled w/o Start button<br>3 = Enabled via Jog-Remote Input | 1                  | 0               |         |
| F069 |                | Reserved for factory use |                                                                                                                 |                    |                 |         |

Table 5.5.11: Serial Communications Function Group

### 5.5.12 System Settings

| Fn #        | Group           | Function Description                | Adjustment / Display Range                                                                | Setting Increments | Factory Setting                | Section              |
|-------------|-----------------|-------------------------------------|-------------------------------------------------------------------------------------------|--------------------|--------------------------------|----------------------|
| F070        | System Settings | Parameter Lock<br>Customer Password | 0 – 999<br>0 = Disabled<br>Any Other Numbers = Password                                   | 1                  | 0<br>(displays encrypted code) | 5.6.12 and Append. 3 |
| F071        |                 | System Clear / Reset                | 0 = Disabled<br>1 = Clear THR and Lockout Timers<br>2 = Reset to Factory Default Settings | 1                  | 0                              | 5.6.12               |
| F072        |                 | Reserved for Factory Use            |                                                                                           |                    |                                |                      |
| F073        |                 | Frame Rating                        | 18 - 550                                                                                  | 1                  | By Model (defaults to 48)      | 5.6.12               |
| F074        |                 | CT Value                            | 40-1200                                                                                   | 5                  | By Model (defaults to 40)      |                      |
| F075        |                 | Year                                | 2000 - 2047                                                                               | 1 year             | 2000                           | 5.6.12.a             |
| F076        |                 | Month                               | 1 - 12                                                                                    | 1 Month            | 1                              |                      |
| F077        |                 | Day                                 | 1 - 31                                                                                    | 1 Day              | 1                              |                      |
| F078        |                 | Hour                                | 0 - 23                                                                                    | 1 Hour             | 0                              |                      |
| F079        |                 | Minute                              | 0 - 59                                                                                    | 1 Minute           | 0                              |                      |
| F080        |                 | Second                              | 0 - 59                                                                                    | 1 Second           | 0                              |                      |
| F081        |                 | Revision #                          | -                                                                                         | -                  | Factory Setting                |                      |
| F082 – F084 |                 | Reserved for factory use            |                                                                                           |                    |                                |                      |

Table 5.5.12: System Settings Function Group

### 5.5.13 Fault History and Run Time


| Fn # | Group                      | Function Description                     | Adjustment / Display Range                                      | Setting Increments | Factory Setting | Section      |
|------|----------------------------|------------------------------------------|-----------------------------------------------------------------|--------------------|-----------------|--------------|
| F085 | Fault History and Run Data | Fault History #1, Latest Fault           | 0 = No fault history, or<br>Fault # 1 - 27: see Fault code list | 1                  | 0               | 5.6.13       |
| F086 |                            | Time Stamp, Fault #1<br>Based on F078-80 | 00.00-23.59 (hh.mm)<br>[hh = 00-23; mm = 00-59]                 | 00.01              | 00.00           |              |
| F087 |                            | Date Stamp, Fault #1<br>Based on F076-77 | 01.01 – 12.31 (MM.DD)<br>[MM = 01-12; DD = 01-31]               | 00.01              | 01.01           |              |
| F088 |                            | Fault History #2, Previous Fault         | 0 = No fault history, or<br>Fault # 1 - 27: see Fault code list | 1                  | 0               |              |
| F089 |                            | Time Stamp, Fault #2                     | 00.00-23.59 (hh.mm)<br>[hh = 00-23; mm = 00-59]                 | 00.01              | 00.00           |              |
| F090 |                            | Date Stamp, Fault #2                     | 01.01 – 12.31 (MM.DD)<br>[MM = 01-12; DD = 01-31]               | 00.01              | 01.01           |              |
| F091 |                            | Fault History #3, Oldest Fault           | 0 = No fault history, or<br>Fault # 1 - 27: see Fault code list | 1                  | 0               |              |
| F092 |                            | Time Stamp, Fault #3                     | 00.00-23.59 (hh.mm)<br>[hh = 00-23; mm = 00-59]                 | 00.01              | 00.00           |              |
| F093 |                            | Date Stamp, Fault #3                     | 01.01 – 12.31 (MM.DD)<br>[MM = 01-12; DD = 01-31]               | 00.01              | 01.01           |              |
| F094 |                            | Run Time, Hours                          | 000.0 – 999.9 hours                                             | 0.1 hours          | 0               | 5.6.13.<br>a |
| F095 |                            | Run Time,<br>1000 Hour Overflow          | 0000 – 9999 thousand hours                                      | 1 k-hour           | 0               |              |
| F096 |                            | Run Cycle Counter                        | 0000 – 9999 times                                               | 1 times            | 0               |              |
| F097 |                            | Run Cycle Counter<br>10K overflow        | 0000 – 9999 10 thousand times                                   | 10k times          | 0               |              |

Table 5.5.13: Fault History and Run Data Group

## 5.6 Function Descriptions

Your **VMX Series** starter is set at the factory with typical default settings that perform well in most applications. Following are detailed descriptions of each Function and the factory default settings.

### 5.6.1 Motor and Overload Function Descriptions



#### F001= Motor FLA

**Factory Setting = 0**

**Range = 50 - 100% of Unit Max. Current.**

Set the value of this function to the motor nameplate Full Load Amps (FLA). Adjustments for service factor are not necessary when programming this function. (See note below). If the motor nameplate FLA is not available, use typical values as shown in NEC, NEMA standard MG-1 or other reputable third party source (motor manufacturer, etc.).



- **Note:**

To prevent adjusting the settings beyond the starter Max Amp rating, the range of adjustment for the Motor Nameplate FLA will vary in accordance with the Service Factor as programmed into **F002**. At the default setting of 1.0SF, the full range of adjustment from 50 - 100% of the Max Amp rating is available. As the Service Factor is increased, the FLA range will drop by an equal ratio. For example if **F002 = 1.15** (a 1.15 Service Factor), the maximum FLA programmable into **F001** will be limited to 85% of the starter Max. Amp rating (100% - 15%).

#### F002 = Service Factor

**Factory Setting = 1.0 S.F.**

**Range = 1.00 - 1.30**

Set value according to the Service Factor (SF) data provided on the motor's nameplate. This value affects several protection features so it must be accurate. Setting the SF too high may result in motor damage in an overload condition. Setting SF too low may cause nuisance trips however; a 1.0 SF setting is safest if SF is unknown.



- **Note:**

The combination of **F002** and **F001** (FLA x SF) cannot exceed the Unit Max Amp rating. If when programming **F002** you are not allowed to raise the setting, the combined total has been exceeded.

#### F003 = Overload Class During Start

**Factory Setting = 10 (Class 10)**

**Range = NEMA / UL Class 5 - 20**

Set value to the motor protection overload class required for the application. It is recommended that you try the factory setting first. (If possible, keep values for **F003** and **F004** the same.) Increase **F003** above **F004** only if nuisance tripping occurs during start. See Section 3.2 for details on trip curves.

**F004 = Overload Class During Run**

**Factory Setting = 10 (Class 10)**

**Range = 5 - 30 NEMA / UL Class**

Set value according to the instructions provided by your motor / equipment manufacturer. This trip curve will not be enabled until the motor has reached full speed.

**F005 = Overload Reset**

**Factory Setting = 0 (Manual)**

**Range = 0 – 2**

Set value to determine starter behavior after an overload condition has cleared.

**When set to 0 = Manual**, the operator must press the **[RESET]** key before restarting the motor. Once the motor windings have cooled sufficiently *AND* the **[RESET]** key is pressed, the unit will accept a restart command.

**When set to 1 = Automatic** mode, and once sufficient time has elapsed allowing motor windings to cool, the motor will be restarted upon a start command. If 2-wire control is used, the unit will restart immediately.

**When set to 2 = Disabled Overload**, the **VMX Series** will *not* trip on Motor Thermal Overload. This is provided for applications where either an external Overload Relay or Motor Protection Relay is used, or where multiple motors are connected and each one requires having an individual Overload Relay. See Appendix 5 for more details.



**WARNING:**

**Setting F005 = 1 (Automatic) may present significant operational risk.**

**When F005 = 2 (Disabled Overload), a separate external thermal overload protection device must be in the circuit.**



▪ **Note:**

Because of the risk of fire or equipment damage, cycling control power will NOT reset an Overload Trip. If **F005 = 2** (Automatic Reset), cycling control power will allow reset *ONLY* if the Thermal Register has determined that the motor has regained sufficient thermal capacity to allow it to restart successfully.

**F006 - F009 = Reserved**

### 5.6.2 Starting Mode

The **VMX Series** is capable of several different starting modes, but is set from the factory for the most common applications. A second ramp profile is available for use should it be required. Unless wired to do so, the **VMX Series** defaults to Ramp 1. This section describes functions for Ramp 1, with references to function numbers that do the same thing for Ramp 2 (if required). **Refer to Appendix 2 for a detailed description** of the differences in Ramp Profiles and their uses. All current percentages are based on the Motor FLA as programmed in **F001**.

#### F010 = Ramp Profile Selection

**Factory Setting = 1**

**Range = 1 – 4**

This Function selects the type of Ramp Profile desired. Ramp profiles can be either Voltage Ramp or Current Ramp. See Appendix 2 for details. Each Ramp Profile consists of 3 settings: Initial Torque, Ramp Time and Maximum Current Limit.

Because there are two ramps available, there are 4 settings to cover the combinations of profiles possible. If you are not using the 2<sup>nd</sup> ramp, the **VMX Series** will ignore all settings in reference to Ramp 2.

| F010 Setting | Ramp 1<br>(Dual Ramp Input Open) | Ramp 2<br>(Dual Ramp Input Closed) |
|--------------|----------------------------------|------------------------------------|
|              | Ramp Profile                     | Ramp Profile                       |
| 1            | Voltage                          | Voltage                            |
| 2            | Current                          | Current                            |
| 3            | Voltage                          | Current                            |
| 4            | Current                          | Voltage                            |

Table 5.6.2: Ramp Type selection Settings

Select Voltage Ramp by setting **F010 = 1** (factory default)

When Voltage Ramp is selected,

Set Initial Torque (Voltage) with **F011** (see below)

Set Ramp Time with **F013** (see below)

Set Maximum Current Limit with **F014** (see below)

Or;

Select Current Ramp by setting **F010 = 2**

When Current Ramp is selected,

Set Initial Torque (Current) with **F012** (see below)

Set Ramp Time with **F013** (see below)

Set Maximum Current Limit with **F014** (see below)



▪ **Note:**

When either Ramp is set to “Voltage Ramp”, the corresponding “Initial Torque (Current)” setting is ignored. Conversely, when set to “Current Ramp”, the “Initial Torque (Voltage)” is ignored.

**F011 = Initial Voltage of Ramp 1**

**Factory Setting = 60%**

**Range = 0 - 100%**

Sets the initial voltage of ramp 1 when **F010 = 1 or 3**. The initial torque level should be set to provide just enough torque to make the motor shaft begin to rotate while preventing torque shock damage to mechanical components.

**F012 = Initial Current of Ramp 1**

**Factory Setting = 200%**

**Range = 0 - 600%**

Sets the initial current of ramp 1 when **F010 = 2 or 4**. The initial torque level should be set to provide just enough torque to make the motor shaft begin to rotate while preventing torque shock damage to mechanical components.

**F013 = Accel Ramp Time of Ramp 1**

**Factory Setting = 10 seconds**

**Range = 1 - 120 seconds**

Sets the time between the initial torque set with **F011 or F012** and either the Max Current Limit set with **F014** or full output voltage. Set the time to enable soft starts without stalls. Also, consider the motor's application. For example, centrifugal pumps may require a shorter ramp time.



▪ **Note:**

Ramp time is affected by the following conditions:

1. Current limit will extend the ramp time if the motor does not reach full speed while in current limit mode.
2. Anti-oscillation circuit may shorten the ramp time if the motor reaches full speed before end of ramp.

**F014 = Max Current Limit of Ramp 1**

**Factory Setting = 350%**

**Range = 200 - 600%**

Sets the maximum motor current that the **VMX Series** starter will allow during Ramp 1. This limit applies to both voltage and current ramping. Current will be limited to this setting until either the motor reaches full speed or the over load protection feature trips (**F003**).

▪ **5.6.2.a Ramp 2 (user-optional ramp)**

This ramp is selected by closing the input for Ramp 2, TB1 – terminals 5 & 6 (see section 4.2.5). If this input is left open, the **VMX Series** will respond only to Ramp 1 settings as listed above. Since ramp 2 is always used as an alternate to the default Ramp 1, different combinations of ramp profiles can be selected in **F010**. Refer to Appendix 1 for additional information on ramp profiles.

**F015 = Initial Torque (Voltage) of Ramp 2**

**Factory Setting = 60%**

**Range = 0 - 100%**

Sets the initial voltage of Ramp 2 when **F010 = 1 or 4**. The initial torque level should be set to provide just enough torque to make the motor shaft begin to rotate while preventing torque shock damage to mechanical components.

**F016 = Initial Torque (Current) of Ramp 2**

**Factory Setting = 200%**

**Range = 0 - 600%**

Sets the initial current of Ramp 2 when **F010 = 2 or 3**. The initial torque level should be set to provide just enough torque to make the motor shaft begin to rotate while preventing torque shock damage to mechanical components.

**F017 = Accel Ramp Time of Ramp 2**

**Factory Setting = 10 seconds**

**Range = 1 - 120 seconds**

Sets the time between the initial torque set with **F015 or F016** and either the Max Current Limit set with **F018** or full output voltage. Set the time to enable soft starts without stalls. Also consider the motor's application. For example, centrifugal pumps may require a shorter time. See notes for **F013** for more details.

**F018 = Max Current Limit of Ramp 2**

**Factory Setting = 350%**

**Range = 200 - 600%**

Sets the maximum motor current that the **VMX Series** starter will allow during ramp 2. (This limit applies to both voltage and current-type ramping.) The current will be limited to this setting until either the motor reaches full speed or the over load protection feature trips (**F003**).



▪ **Note:**

Ramp 2 is often useful as a “bump start” or as a temporary Across-the-Line start mode. Consult Appendix 1 for details.

### 5.6.3 Jog Mode

The Jog Function is another user optional feature and is controlled by closing the input on TB1 Terminals 6 and 7. If this input is left open, the **VMX Series** will ignore all Jog settings. Engaging the Jog feature along with the Start / Run Command provides an output from the SCRs, but will not continue ramping to full acceleration. This feature can Jog the motor at either a preset Voltage (**F019 – F021**) or a preset Current (**F021**) depending upon the settings of the Ramp Type from **F010**, and can be initiated along with Ramp 1 or Ramp 2 (see Dual Ramp Select, Section 4.2.5 and 5.6.2.a). It is also sometimes useful to use Jog in combination with Ramp 2, see section 4.2.5.c.



**Note:** Jog functions may become disabled by Comm port function **F068** setting 3. See section 5.6.11 for details.

| Setting from F010 | Ramp 1 (Dual Ramp Input Open) |                        |                    | Ramp 2 (Dual Ramp Input Closed) |                        |                    |
|-------------------|-------------------------------|------------------------|--------------------|---------------------------------|------------------------|--------------------|
|                   | Ramp & Jog Type               | Initial Torque from... | Jog Torque from... | Ramp & Jog Type                 | Initial Torque from... | Jog Torque from... |
| 1                 | Voltage                       | F011                   | F019               | Voltage                         | F015                   | F019               |
| 2                 | Current                       | F012                   | F021               | Current                         | F016                   | F021               |
| 3                 | Voltage                       | F011                   | F019               | Current                         | F016                   | F021               |
| 4                 | Current                       | F012                   | F021               | Voltage                         | F015                   | F019               |

Table 5.6.3: Jog Settings



**Caution:** Although the Thermal Register tracks all motor current use, continuous usage of the Jog feature risks thermal motor damage or nuisance tripping.




Figure 5.6.3.1: Voltage Jog and Jog Time

#### F019 = Voltage Jog

**Factory Setting = 50%**

**Range = 5 - 100%**

Sets the voltage level of the Jog feature and is typically used to check rotation, alignment, or to slowly move a load into position. Jogging at a set voltage has no current control so the duration of the applied voltage must be limited to prevent excessive motor heating.

#### F020 = Time of Voltage Jog

**Factory Setting = 10 seconds**

**Range = 1 - 20 seconds**

Set to minimize motor heating during a voltage jog. This setting is the **maximum** allowable time for jogging the motor using voltage only.




Figure 5.6.3.2: Current Jog

#### F021 = Current Jog

**Factory Setting = 150%**

**Range = 100 - 500%**

Sets output of a current Jog. The current jog feature is typically used to check rotation, alignment, or slowly move a load into position. This is not time-limited but should be used cautiously.




Figure 5.6.4:  
Kick Start

#### 5.6.4 Kick Start Mode

Kick Start applies a pulse of voltage to the motor producing a momentary “kick” of high torque to break the motor load free from high friction or frozen components. This pulse is limited to 2 seconds.

##### F022 = Kick Start Voltage

**Factory Setting = 0 (Disabled)**

**Range = 10 - 100%**

When **F022**  $\neq$  0, a voltage “pulse” is applied before the initial torque setting of **F011** (or **F012** if Current Ramp). This sets the voltage level and the duration of the pulse is set by **F023**. This setting should be higher than **F011** (except for Dwell Starting, see below) and high enough to provide a benefit in the worst starting condition.

##### F023 = Kick Time

**Factory Setting = 0.8 seconds**

**Range = 0.1 - 2 seconds**

Sets the duration of time the Kick Start voltage is applied.




Figure 5.6.4.a:  
Dwell Start Using Kick Start

##### 5.6.4.a “Dwell” operation using Kick Start

In some applications such as chain drive machinery, the Kick Start feature can be used to slowly take up slack in the drive chain before applying full torque. This is referred to as “Dwell Starting” because the torque output stays low for a short time. To take advantage of this feature, simply set the Kick Start to the same level as the Initial Torque setting. This will only work in Voltage Ramp mode.



##### Note:

Do not use the Kick Start feature unless you determine that you need it. Using this feature may eliminate many of the mechanical and electrical benefits of using a Soft Starter.

### 5.6.5 Pump-Flex® Decel Mode (F025 through F028)

Pump-Flex® deceleration is a feature of the **VMX Series** Soft Starter that slowly decreases the applied voltage to the motor when a stop command is given, resulting in a gentle decrease in motor torque. Deceleration provides a way to extend the stopping time so that abrupt stopping does not occur. Deceleration is useful with centrifugal pumps, material handlers, and conveyors where abrupt stopping could be damaging to the equipment and/or load.

**SEE APPENDIX 2 AT THE END OF THIS MANUAL** for typical Pump-Flex® Decel feature applications and more detailed descriptions of the following functions.

**F024 = Deceleration Ramp**  
**Factory Setting = 0 (Disabled)**  
**Range = 0 – 2**

**When F024 = 0**, the deceleration feature is **disabled**.

**When F024 = 1**, the deceleration feature is **enabled** AND the overload protection feature (**F003 - F005**) remains active (power off on OL trip).

**When F024 = 2**, the deceleration feature is **enabled** and deceleration will **continue even when an overload condition trips**.



#### WARNING!

Setting F025 = 2 presents significant risk of over-heating the motor beyond its design limits which could result in motor damage and fire hazard. Do this only in circumstances where the potential for mechanical damage outweighs the risk of motor damage.




Figure 5.6.5:  
Pump-Flex Decel Ramp Settings

**F025 = Begin Decel Level (BDL)**  
**Factory Setting = 60%**  
**Range = 0 - 100% of line voltage**  
Used to drop voltage to a level where there is a noticeable effect on motor torque during initial Decel mode.

**F026 = Decel Shut Off Voltage**  
**Factory Setting = 30%**  
**Range = 0 to (BDL -1)%**  
Sets the level where the starter is turned off, corresponding to where motor torque during Decel is no longer effective. Always set this function lower than the setting of **F026**.

**F027 = Decel Ramp Time**  
**Factory Setting = 10 seconds**  
**Range = 1 - 60 seconds**  
Sets the maximum time for the deceleration ramp to go from the Begin Decel Level setting (**F026**) to the Decel Shut Off Voltage (**F027**).



#### Note:

When using the Decel function, count these cycles as additional “starts” when determining maximum starts-per-hour of the motor.



#### Caution!

Decel is **THE OPPOSITE** of braking. Enabling the Decel feature will make the motor take **LONGER** to stop than if it were simply turned off.

### 5.6.6 Restart Delay

The **VMX Series** can be programmed to delay restarting upon restoration of line power after an outage. This allows multiple units to be programmed to restart at staggered times in an effort to avoid causing additional problems with the power supply system. Another term for this is “**Sequential Start Delay**”.

#### **F028 = Restart Delay Time**

**Factory Setting = 0 (Disabled)**

**Range = 0 = Disabled (no delay), or 1 - 999 seconds**

Sets a delay time before the starter can be restarted after a complete loss of power. Use this if multiple motors are connected to a supply system that may have trouble providing adequate power to restart them all at the same time. By using different Restart Delay Times on each unit, a sequential restart can be achieved.



▪ **Note:**

This is similar to the Coast Down Lockout Timer in **F048**, however it only activates on Power Loss.

**F029 = Reserved**

### 5.6.7 Process Timer Control Mode (F030 through F039):

The following special functions allow the **VMX Series** starter to operate automatically from a Process Control Timer using an internal Real Time Clock.

Only brief descriptions of the functions are provided here.

**REFER TO APPENDIX 4 at the end of this manual for detailed operations and instructions.**



▪ **Note:**

These functions may interact with the Coast Down Lockout (**F048**), Starts-per-Hour Lockout (**F049**), Minimum Time Between Starts (**F050**), Auto-Reset (**F052 and F053**) and Restart Delay Time (**F028**) functions if enabled. Be sure to review and understand settings for these functions before using the Process Timer.

#### **F030 = Process Control Timer Selection**

**Factory Setting = 0 (Disabled)**

**Range = 0, 1, 2**

This function enables a Process Control Timer, which may be used alone or in conjunction with the Time Clock Controller feature (**F032-F039**). This timer offers two operating modes, selected by entering 1 or 2 into the function parameter:

**Setting 1 = Minimum (Batch) Run Timer:** After a Start Command, the starter runs until the batch timer expires. If stopped and restarted it will complete that batch time sequence.

**Setting 2 = Permissive Run Timer.** After a Start Event from the TCC, the starter can be started and stopped as necessary, until the timer expires.

#### **F031 = Process Timer Value**

**Factory Setting = 1**

**Range = 1 – 9999 minutes**

This function loads a value into the Process Timer above. When initialized, the value counts down towards 0.



▪ **Note:**

The above Process Control Timer in **F030 – F031** works in conjunction with the Time Clock Controller in **F032 – F039**. When the TCC is set to One-Shot (**F032 = 0**), this timer will activate whenever a Start Command is given. When **F032 =** any other setting, this timer activates according to that schedule.

**F032 = Real Time Clock Controller**

**Factory Setting = 0 (One Shot)**

**Range = 0 - 8 settings**

This function is used to select the operating mode of the 24hr / 7 Day Time Clock Controller (TCC). **F032** sets the number of days in which the TCC will repeat the Start Event Cycle up to seven discrete Start Events selected in **F033** through **F039**. After each Start Event, the **VMX Series** will run per the time value set in F030 above. If F030 = 0, the TCC settings are ignored. See Appendix 4 for additional details.

1 = 1 day per week,

2 = 2 days per week

...

7 = 7 days per week

8 = A single 24HR event, non-repeating

0 = One-Shot. When set to 0, the **VMX Series** responds only to each Start input command. Use this setting to allow the Process Timer to operate without the TCC (see Appendix 4 if F030=2).

**F033 = Event #1 Start Time**

**Factory Setting = OFF**

**Range = 00:00 through 23:59, or OFF**

This function is used to select the start time for Event #1 in the RTCC above. Once started by this event, the VMX will run the motor according to the selections entered into **F030** and **F031**.

**F034 = Event #2 Start Time**

**Factory Setting = OFF**

**Range = 00:00 through 23:59, or OFF**

This function is used to select the start time for Event #2 in the TCC above.

**F035 = Event #3 Start Time**

**Factory Setting = OFF**

**Range = 00:00 through 23:59, or OFF**

This function is used to select the start time for Event #3 in the TCC above.

**F036 = Event #4 Start Time**

**Factory Setting = OFF**

**Range = 00:00 through 23:59, or OFF**

This function is used to select the start time for Event #4 in the TCC above.

**F037 = Event #5 Start Time**

**Factory Setting = OFF**

**Range = 00:00 through 23:59, or OFF**

This function is used to select the start time for Event #5 in the TCC above.

**F038 = Event #6 Start Time**

**Factory Setting = OFF**

**Range = 00:00 through 23:59, or OFF**

This function is used to select the start time for Event #6 in the TCC above.

**F039 = Event #7 Start Time**

**Factory Setting = OFF**

**Range = 00:00 through 23:59, or OFF**

This function is used to select the start time for Event #7 in the TCC above.

### 5.6.8 Current and Ground Fault Protection Features

**F040 – F050** set extended protection features that may be used in the **VMX Series** starter. Percentages shown are all based automatically upon the Motor FLA setting from **F001** except Ground Fault, **F046**. No additional calculations are necessary.



- **Note:**  
All of these features are disabled at the factory and must be enabled via user programming as follows:

#### **F040 = Current Imbalance Trip**

**Factory Setting = 0 (Disabled)**

**Range = 5 - 30% or 0 (Disabled)**

Use to set the trip level for when current imbalance between any two phases exceeds this amount for the time specified **F041**.

#### **F041 = Current Imbalance Trip Delay**

**Factory Setting = 2 seconds**

**Range = 1 - 20 seconds**

Provides a time delay to prevent nuisance trips from short-duration transients. Using default settings, if the difference in output current between two phases exceeds 10% of FLA for more than 2 seconds, the starter will trip.

#### **F042 = Over Current Trip / Shear Pin Trip**

**Factory Setting = 0 (Disabled)**

**Range = 100 - 300%, 0 (Disabled)**

When a value other than 0 is entered for **F042**, the starter will trip when the output current of any phase exceeds the amount set and the time specified in **F043**. This is also referred to as a “Shear Pin Trip” and can be used to protect mechanical components from damage due to jammed loads.

#### **F043 = Over Current Trip Delay**

**Factory Setting = 1 second**

**Range = 1 - 20 seconds**

Provides a time delay to prevent nuisance trips from short-duration transients. For example using default settings, if the output current of any phase exceeds **F042** for more than 1 second, the starter will trip.

#### **F044 = Under Current Trip**

**Factory Setting = 0 (Disabled)**

**Range = 10 - 90%, or 0 (Disabled)**

When a value other than 0 is entered for **F044**, the starter will trip when the output current of any phase drops below the amount set, and the time specified by **F045**. This fault condition is often referred to as a “Load Loss Trip” and can be used to detect a broken shaft, V belt or other mechanical drive system component failure. In pumping applications, this can be used as a “Loss of Prime” trip.

#### **F045 = Under Current Trip Delay**

**Factory Setting = 2 seconds**

**Range = 1 - 60 seconds**

Provides a time delay to prevent nuisance trips from short-duration transients. Using the default setting, if the output current of any phase drops below **F044** for more than 2 seconds, the starter will trip.




Figure 5.6.8.a:  
Over Current Trip




Figure 5.6.8.b:  
Under Current Trip

▪ **5.6.8.a Ground Fault**

**F046 – F047** provides Ground Fault protection for equipment only (a.k.a. Arcing Ground Fault) using the Residual Current method. Trip settings are based on the CT ratio as shown in **F074** (see below). A delay time can be set by **F047** to help prevent nuisance trips. Ground current can always be viewed in the Status Display, shown with a “G” prefix (see section 5.3.1).



**WARNING!**

**THIS IS NOT INTENDED TO BE USED AS "PERSONNEL PROTECTION" GROUND FAULT!** This feature is only intended to provide a level of equipment protection against damaging ground currents. Ground faults are potentially dangerous conditions and must be corrected immediately for safety of operating personnel.

**F046 = Ground Fault Trip**

**Factory Setting = 0 (Disabled)**

**Range = 5 - 90% of CT value, or 0 (Disabled)**

When a value other than 0 is entered for **F046**, the starter will trip if current to ground exceeds this percentage of the unit CT value. The CT value is shown in **F074** (see section 5.6.12). This value is different from the Unit Rating or FLA setting. To calculate actual ground current, multiply the CT value of **F074** by the setting of **F046**.

**Example:**

210A starter, desired Ground Fault Trip level is 20A:

On this unit, the CT value reading from **F074** will be 250 (250:5)

$20 / 250 = 0.08$  (8%). Set **F046** to 8

**F047 = Ground Fault Trip Delay**

**Factory Setting = 2 seconds**

**Range = 1 - 60 seconds**

Provides a time delay to prevent nuisance trips from short-duration transients. Using default setting, if the Ground Fault current exceeds the level set in **F046** for more than 2 seconds, the starter will trip.



**CAUTION:**

This method of Ground Fault sensing may not provide adequate equipment protection in resistance-grounded systems. We recommend providing external GF protection using a core balanced Zero Sequence CT for those types of applications. Consult factory for additional assistance.

### 5.6.9 Lockouts, Reset and Internal Protection Features

**F048 – F050** provide lockout protection for motors and equipment that may have potentially damaging consequences from premature restart or with limited duty cycles. Time and count values for these lockouts can be viewed in **F055 – F058**. Time values are based on the Real Time Clock and *DONOT* reset when power is lost or disconnected. Emergency clearing of lockouts can be accomplished in **F071**.



▪ **Note:**

When **F048** through **F050** are used with 3 wire control systems, a Start command will not seal in during lockout time. When time has expired, a new Start command will be necessary.



**WARNING!**

When **F048** through **F050** are used with 2-wire control, the starter may re-start automatically when time has expired. Adequate warnings similar to those in Section 3.1.3.b should be observed.




Figure 5.6.9:  
Coast Down Lockout Timer

**F048 = Coast Down Lockout Timer (Back Spin Timer)**

**Factory Setting = 0 (Disabled)**

**Range = 1 - 60 minutes, or 0 (Disabled)**

**F048 = 1 - 60**, sets the number of minutes that the starter must be off before a restart can be attempted. This function is useful in applications such as pump motor backspin protection (where you need to prevent the pump motor from restarting if it is spinning backwards), 2 speed operations where speed changes require a minimum disconnect (spin-down timer), or reversing applications to prevent plugging (anti-plugging timer).

**F049 = Maximum Starts per Hour Lockout**

**Factory Setting = 0 (Disabled)**

**Range = 1 - 10 or 0 (Disabled)**

**F049= 1 - 10**, counts the number of start commands within a 1 hour period. If the setting (maximum starts per hour) is exceeded, starting is prohibited until sufficient time has expired. This timer initiates upon the first start in an hour. It resets after 1 hour from that start and waits until another subsequent start to initiate again. (Often used in conjunction with **F050**).



▪ **Notes:**

- Consult the motor manufacturer for a “Starts-per-Hour” or “Starting Duty Cycle” rating. Larger motors tend to have lower starts-per-hour ratings.
- When using the Decel function (**F025**) or an electronic braking option, count these cycles as additional “starts” when determining maximum starts-per-hour.

**F050 = Minimum Time Between Starts Lockout****Factory Setting = 0 (Disabled)****Range = 1 - 60 minutes, or 0 (Disabled)**

When F050 is set to 1 through 60, the motor cannot be restarted within the time specified after the first start. Time between starts is calculated from the time of the first start command to the next regardless of run time or off time.

**Example:**

If F050 = 15, motor will not be allowed to re-start within 15 minutes of the first start.

This function is useful as a "Short-Cycle Timer" to prevent excessive motor wear when automatic demand control may occasionally cycle on and off too quickly. e.g. compressors or sump pumps.

**5.6.9.a Internal Protection Features**

The **VMX Series** starter contains additional protection features that are built-into the hardware and are factory preset. **Function F051** is provided to alter these settings via numerical preset programming. For maximum protection, all of these features are turned ON as a factory default and should not be changed unless necessary for service purposes, testing or to accommodate non-standard applications. Factory default settings are as follows:

- **Phase Rotation:** Protection is ON. The expected rotation sequence is set for A-B-C.
- **Phase Current Loss (Running):** Protection is ON. The unit trips at <20% of unit Max amps after 3 seconds of acceleration and at full speed.
- **Shorted SCR:** Protection is ON. The unit will lock out if one SCR is shorted (no voltage drop across the SCR).
- **Shunt Trip:** Protection is ON. The unit trips if current flows in any phase while in the OFF mode.
- **PTC Trip:** Protection is ON. The unit will trip if the PTC Input resistance exceeds set value (or open).
- **Line Phase Loss (Stopped):** Protection is ON. The unit will trip if any phase voltage is not present while the unit is not accelerating or stopped.

**F051 = Internal Protection Features****Factory Setting = 255 (all enabled)****Range = 1 – 255: Decimal value representing bit locations**

F051 represents the decimal value for the binary setting of 8 bits (byte) of memory. Each of the 8 bits is set to a 1 or 0 and enables or disables the protection features depending on the setting. By adding (enable) or subtracting (disable) the decimal value associated with each of the protection features to the F051 total allows changes to be simply made by entering the new value via the keypad. The Factory Default value is

**F051 = 0255 (binary 11111111), which enables all features.**

The decimal values for each feature are as follows:

**Phase Rotation Protection:**

The **VMX Series** is set up to monitor an expected phase rotation and will trip if this changes. Control of this feature is divided into two categories: On-Off and Expected Sequence. The default setting is On, with an Expected Sequence of A-B-C.

The ability to turn this feature ON or OFF is useful in applications where the **VMX Series** starter is going to be used downstream from an existing reversing contactor / starter, or to avoid conflicts with other protection devices.

- **Rotation Trip On-Off Control Decimal value = 1 (b 00000001)**

If this feature is On (default setting) and you want to turn it Off, Subtract 1 from F051. If this feature is Off and you want to turn it On, add 1 to F051. When set to On, a trip will occur when the Expected Sequence (see below) is incorrect.

On large motors where large multiple cables are used, it may be easier to change the Expected Sequence in the **VMX Series** starter rather than to swap the cables.

- **Expected Phase Rotation Sequence Decimal Value = 2 (b 00000010)**

The A-B-C rotation is the default setting. To change to A-C-B, subtract 2 from F051. To change from A-C-B rotation to A-B-C, add 2 to F051. If the Rotation Trip is set to Off (see above), this setting is ignored.

**Phase Current Loss (Running) Protection:**

This feature will cause a Trip if the current in any phase (or all 3) is less than 12% of the CT value after 3 seconds from a Start Command. (Note that this is based on the Max Amp rating and not the programmed FLA). Turn it OFF if the motor no-load current is exceptionally low such as in high inertia machines, or **if you are testing a large starter with a small motor**.

- **Phase Loss (Running) Protection Decimal Value = 4 (b 00000100)**

This feature is On (default setting). To turn it Off, Subtract 4 from F051. If this feature is Off and you want to turn it On, add 4 to F051.

**Shorted SCR Lockout protection:**

This feature will cause a Lockout if at least one SCR is shorted, based on the expected voltage drop across the SCR assembly when the unit is OFF. (Note- A shorted SCR cannot be detected while the unit is running or in Bypass mode). If qualified personnel knowing the ramifications of having a shorted SCR issue requires an emergency restart, this feature can be turned to OFF. This is not the same as a Shunt Trip circuit (see below). This is a lockout of the NEXT start command.

- **Shorted SCR Lockout Decimal Value = 8 (b 00001000)**

This feature is On (default setting). To turn it Off, Subtract 8 from F051. If this feature is Off and you want to turn it On, add 8 to F051

**Shunt Trip:**

Shunt Trip is a feature that will cause an immediate Trip if the **VMX Series** detects current flowing through any phase (or all) while the VMX is in the Off state. The trip function is typically associated with the Aux. Relay setting 7 (see F060-63), wired to a Shunt Trip coil in an upstream circuit breaker or an in-line contactor. This function is to interrupt power flow to the motor windings in order to prevent damage. The usual cause is multiple shorted SCRs or a welded Bypass Contactor. The only time this function should be turned off is for troubleshooting by qualified service personnel.

- **Shunt Trip Decimal Value = 16 (b 00010000)**

This feature is On (default setting). To turn it Off, Subtract 16 from F051. To turn it On, add 16 to F051.

**PTC Trip:**

This feature controls the inclusion of the PTC Input (see Section 4.2.7). When it is ON (default setting), a jumper wire or other circuit must be installed on the PTC input if a PTC resistor is not included in the motor. Turn this feature to OFF for troubleshooting or if a jumper wire is not used.

- **PTC Trip Decimal Value = 32 (b 00100000)**

This feature is On (default setting). To turn it Off, Subtract 32 from F051. To turn it On, add 32 to F051.

**Line Phase Loss (Stopped) Trip:**

This feature will prevent the **VMX Series** starter from attempting to start if the voltage in one (or more) of the incoming phases is not present. This can be used to detect a blown fuse or power supply loss provided control power is still available. It differs from the Phase Loss (Running) Trip in that it is based upon line voltage and does not require that a Start Command be given. This trip function resets itself after determining that all 3 phases have voltage applied. The voltage level at which this feature activates is fixed at approximately 100VAC. It is not adjustable and should not be used as Under Voltage protection.

- **Line Phase Loss (Stopped) Trip Decimal Value = 64 (b 01000000)**

This feature is On (default setting). To turn it Off, Subtract 64 from F051. To turn it On, add 64 to F051.

- **Notes:**

1) When using an In-Line Isolation Contactor, it may be necessary to turn Off this protection (by subtracting a numeric value of 64 from F051) in order to avoid nuisance tripping whenever the In-Line Contactor opens.

2) This protection will automatically reset itself when line voltage is present on all 3 phases. When using 3-wire control, the **VMX Series** will not attempt to restart unless the Start Command is re-initiated.



- **Caution:**

**When using 2-wire control, the starter will restart when this feature resets itself after all 3 phases are present.**

### 5.6.9.a (continued) Function 51: Internal Protection Features

| Bit # | Fault Display Code | Protection Function     | Description                                                                                                                                                                                                                                  | Default Bit Setting | Decimal Value |
|-------|--------------------|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------|---------------|
| 0     | ROT*               | Phase Rotation Trip     | Phase Rotation protection. Phase rotation must match selection in Bit #2 below. Setting to Off (0) will make the VMX insensitive for use behind a reversing contactor                                                                        | 1 (On)              | 1             |
| 1     | ABC                | Expected Phase Sequence | 2 = A-B-C Phase Rotation Sequence Only<br>0 = A-C-B Phase Rotation Sequence Only                                                                                                                                                             | 1 (A-B-C Rotation)  | 2             |
| 2     | PLa or PLc*        | Phase Current Loss      | Phase Current Loss, any phase current reading that is less than 12% of the CT rating after 3 seconds from Start command.                                                                                                                     | 1 (On)              | 4             |
| 3     | SS*                | Shorted SCR             | At least one SCR is shorted; There is no voltage drop across the SCR phase assembly.                                                                                                                                                         | 1 (On)              | 8             |
| 4     | ST*                | Shunt Trip              | Shunt Trip of the main Circuit Breaker or Isolation Contactor (if provided and wired to an Aux. relay in F060-F061). Two or more SCRs have shorted in opposing phases so current is flowing to the motor while the VMX was in the Off state. | 1 (On)              | 16            |
| 5     | PTc*               | PTC Input Trip          | PTC Trip function. This can be disabled so that a jumper is not required across the PTC inputs.                                                                                                                                              | 1 (On)              | 32            |
| 6     | PLd or n3Ph        | Line Phase Loss Trip    | Protection against loss of input line voltage. Disable when using an In-Line Isolation Contactor or any other system that normally removes line power from the starter. Resets automatically when line voltage returns.                      | 1 (On)              | 64            |
| 7     | ---                | Reserved                | Reserved for factory use                                                                                                                                                                                                                     | 0 (Off)             | 128           |

\* = Operating Mode designation. See Fault Code List for description.

**Table 5.6.9.a: Function 51 table of Hardware Protection Features**



▪ **Note:**

To restore all settings back to the factory default, enter a value of 127. A value other than the default value of 127 indicates that one or more functions have been changed. To determine which of the protective functions have been changed/turned-off subtract the value displayed from 127 and compare the result against the „decimal value’ column shown in table 5.6.9.a.

**Example:** F051 reads a value of 109. Subtract 109 from 127 and a value of 18 remains. The value 18 does not represent a single bit value indicating that more than one function has been changed. Referring to Table 5.6.9.a, find the largest decimal value as shown in the „decimal value’ column smaller than 18. In this case a value of 16 (bit 4). This leaves a value of 2 (18 minus 16) which represents bit 1 (2). So in this example a value of 109 indicates that the Shunt Trip feature had been turned off (bit 4), and the Expected Phase Sequence had been changed to A-C-B (bit 1).

Instead of determining the previous selection add up all values in „decimal value’ column of the functions to be turned off and subtract this value from 127 and program the result into F051.

#### 5.6.9.b Auto-Reset Programming (F052 – F054)

The **VMX Series** can be programmed to automatically attempt a reset based on the selected „auto-reset’ faults (F52), provided a Start Command is present (see Section 4.2) and no fault condition is active. Function F52 selects the „Auto-Reset’ faults and function F53 sets the number of reset attempts. If F053 is set to 0 (default setting), the **VMX Series** auto-reset function is disabled.

#### Note:

When using 3 wire control:

For safety reasons the **VMX Series** will not attempt restarting unless the Start Command is reinitiated and maintained during a restart attempt.



#### F052 = Auto-Reset Selected Faults

**Factory Setting = 0 (Disabled)**

**Range = 1 - 12, or 0 (Disabled)**

If F052 = 1 through 12, the **VMX Series** will attempt to restart after the fault(s) coded in the following table. Only one selection can be entered.

| F052 Setting | Fault Condition Description   | Display Readout Reference |
|--------------|-------------------------------|---------------------------|
| 0            | Auto Reset Disabled           | ---                       |
| 1            | Over Temperature Trip         | OT                        |
| 2            | Over Current (Shear Pin) Trip | OC                        |
| 3            | Under Current Trip            | UC                        |
| 4            | Phase Loss Trip               | PLa or PLc                |
| 5            | Current Unbalance Trip        | UB                        |
| 6            | Ground Fault Trip             | GF                        |
| 7            | Short Circuit Trip            | SC                        |
| 8            | Faults 1, 2 or 3 above        | OT, OC or UC              |
| 9            | Faults 4, 5 or 6 above        | PL, UB or GF              |
| 10           | Any Fault except 7            | No SC                     |
| 11           | Any Fault except 6 & 7        | No GF and no SC           |
| 12           | Any Fault above, 1 - 7        | OT, OC, UC, PL, UB or GF  |

Note 1: UC, OC or UB require operation to resume before the fault can be detected.  
 Note 2: Cycling and / or restoration of control power will reset all of the above faults.  
 Note 3: Overload Trip reset function is programmed only in F005. See Section 3 for details  
 Note 4: Reset attempts with a fault condition present will cause a new fault. This will be logged into the the fault history (F085 – F093) and may overwrite previous fault records. Line Loss Trip (see F051) will automatically reset and is not included in this list.

**Table 5.6.9.b: Faults Selected for Auto-Restart**

#### F053 = Auto-Restart Attempts

**Factory Setting = 0 (Disabled)**

**Range = 1 - 10 Attempts, or 0 (Disabled)**

If F053 = 1 through 10, the **VMX Series** will attempt to restart if the Start Command is present for this number of times. If set to Zero, the starter will not attempt to reset automatically.

▪ **5.6.9.c Timer Value Readouts for Protection Features**

F054 – F059 provide display of timer or register values for information only. The user cannot alter them. Upon power loss and restoration, these values are updated for time elapsed.

**F054 = Restart Delay Time Readout**

**Factory Setting = Not Applicable**

**Range = 1 - 999 Seconds**

Remaining time value readout of F028, the Auto-Restart Delay Timer.

**F055 = Coast Down (Backspin) Timer Value**

**Factory Setting = Not Applicable**

**Range = 1 - 3600 Seconds**

Remaining time value readout of F048, the Coast Down Lockout Timer.

**F056 = Starts per Hour Timer Value**

**Factory Setting = Not Applicable**

**Range = 1 - 3600 Seconds**

Remaining time value readout of F049, the Starts-per-Hour Lockout Timer.

**F057 = Starts per Hour Counter Readout**

**Factory Setting = Not Applicable**

**Range = 1 - 10 Starts**

Incremental counter value readout of F050, the Starts-per-Hour Lockout.

**F058 = Time Value Between Starts Readout**

**Factory Setting = Not Applicable**

**Range = 1 - 3600 Seconds**

Remaining time value readout of F050, the Minimum Time Between Starts Timer.

**F059 = Thermal Capacity to Start Readout**

**Factory Setting = Not Applicable**

**Range = 0 - 100 % Thermal Capacity**

Readout only for the user's viewing of the motor Thermal Capacity percentage required to allow a Reset after an Overload Trip. Use this function in conjunction with the Remaining Thermal Capacity (in the Status Screen group) to be able to predict when a restart will be allowed. This value is automatically updated by the **VMX Series** CPU whenever a successful start sequence has been accomplished. The **VMX Series** essentially "learns" how much Thermal Capacity is needed in the motor in order to successfully restart, and stores the information at this Function. Upon power loss and restoration, this value is updated for elapsed time.

### 5.6.10 Output Relays

There are three programmable relays (rated 240VAC, 5A, 1200 VA) in the **VMX Series**. They can be programmed for change of state indication for any one of the 25 conditions identified in the following chart.

**F060 = Aux Relay 1: Form C (SPDT)**

**Factory Setting = 1 (Run / Stop)**

**Range = 1 - 27 (See list)**

Use to program the desired operation for Relay # 1.

**F061 = Aux Relay 2: Form C (SPDT)**

**Factory Setting = 2 (At Speed / Stop)**

**Range = 1 - 27 (See list)**

Use to program the desired operation for Relay # 2.

**F062 = Aux Relay 3: Form A (SPST, N.O.)**

**Factory Setting = 16 (Any Trip, 5 - 15)**

**Range = 1 - 27 (See list)**

Use to program the desired operation for Relay # 3.

**F063 = Aux Relay Delay Timer for Settings 23 – 26**

**Factory Setting = 0 (Disabled)**

**Range = 1 – 999 seconds, or 0 (Disabled)**

Use to program the desired On Delay for any Aux. Relay that has been programmed for Settings 23 through 26 from the chart below.

| Setting                                                         | Relay Operation Description                           |
|-----------------------------------------------------------------|-------------------------------------------------------|
| 1                                                               | Run / Stop (Changes on Start Command, resets on Stop) |
| 2                                                               | At Speed / Stop                                       |
| 3                                                               | At Speed / End of Decel                               |
| 4                                                               | Start / End of Decel                                  |
| 5                                                               | Short SCR Trip                                        |
| 6                                                               | Phase Loss Trip                                       |
| 7                                                               | Shunt Trip                                            |
| 8                                                               | OL (Motor Thermal Overload) Trip                      |
| 9                                                               | OT (Starter Thermal Over Temperature) Trip            |
| 10                                                              | Short Circuit Trip                                    |
| 11                                                              | Current Unbalance Trip                                |
| 12                                                              | Over Current (Shear-Pin) Trip                         |
| 13                                                              | Under Current Trip                                    |
| 14                                                              | Ground Fault Trip                                     |
| 15                                                              | Phase Rotation Trip                                   |
| 16                                                              | Any Trip (#5 - #15)                                   |
| 17                                                              | Any Trip, (#5-#15) <b>flashing output*</b>            |
| 18                                                              | Coast Down Time Lockout                               |
| 19                                                              | Starts Per Hour Lockout                               |
| 20                                                              | Time Between Starts Lockout                           |
| 21                                                              | Any Lockout (#18-#20)                                 |
| 22                                                              | Run Timer (F030) Engaged                              |
| 23                                                              | Run / Stop with On-delay from F063                    |
| 24                                                              | At Speed / Stop with On-delay from F063               |
| 25                                                              | At Speed / End of Decel with On-delay from F063       |
| 26                                                              | Start / End of Decel with On-delay from F063          |
| 27                                                              | Power Loss (nCP No Control Power) Trip                |
| <b>*Note: Flash rate for Setting #17 is ½ second On and Off</b> |                                                       |

Table 5.6.10: Output Relay Programming

**F064 = Reserved**

### 5.6.11 Communications

The **VMX Series** starter is shipped from the factory ready to accept RS-485 Serial Communications using Modbus RTU protocol. Additional detailed instructions on accomplishing communications are available in a **Serial Communication Supplement** to this manual. F065 – F067 are used to set the communications parameters in the starter for use by the adaptor module. F068 determines how the Start / Stop functions work through the comm. port.

#### F065 = Communications

**Factory Setting = 0 (Disabled)**

**Range = 0 – 2**

This enables serial communications with remote monitoring and control systems and sets the format for Modbus RTU protocol. Once Enabled, the local start / stop inputs are altered to avoid inadvertent starting. See F068 for details.

**F065 = 0**, communications are disabled.

**F065 = 1**, uses the std 11 bit Modbus format w/ parity bit.

**F065 = 2**, a non-standard 10-bit format without a parity bit is used to accommodate some systems using this method.

#### F066 = Baud Rate

**Factory Setting = 9.6 KB**

**Range = 4.8 to 19.2 KB**

Set value to either 4.8 KB, 9.6 KB or 19.2 KB and match the setting of the host device.

#### F067 = Modbus Address

**Factory Setting = 1**

**Range = 1 – 247**

Using Modbus communications protocol, up to 247 **VMX Series** starters can be networked using RS485 standard communication, each having a unique address. Two devices with the same address will result in a communications error.

#### F068 = Remote Starter Control

**Factory Setting = 0 (disabled)**

**Range = 0 – 3**

This determines how the **VMX Series** starter is to be controlled when using serial communications.

**When F068 = 0**, the starter can be monitored by the Comm port, but not controlled.

**When F068 = 1**, the starter will be controlled by the comm port. In addition, the Start / Stop inputs are altered as follows: The hard-wired Start command is put in “**AND**” logic with the Comm port; both Start commands must be on for the VMX to start. The Stop function is put in “**OR**” logic; either the Comm. port Stop command **OR** the hard-wired Stop will cause the VMX to stop.

**When F068 = 2**, the VMX starter is in full control of the Comm. port only. Local Start / Stop inputs become completely inactive. Use this function only when controlled shutdown is a priority.

**When F068 = 3**, the VMX starter will change the function of the **Jog / Remote Input** to cause a switch between the functions of setting 0 and setting 1 as listed above. When the input is open, the starter will respond to the Comm port as per setting F068=0 above. When the **Jog / Remote Input** is closed, the starter will respond as per setting F068=1 above. Use this function if it is necessary to have a return to local start/stop control should the communications system fail or become disconnected.

**Special Note when using Serial Comm:**  
When F068 = 3, the function of the Jog / Remote Input on TB-1 terminals 7 and 8 will change. Closing the Input will cause the Comm. port control to function as per setting F068=1. Leaving the input open will cause the Comm. port to function as per setting F068=0.

When F068 = 1, 2 or 3, the Jog function will cease to operate. Since Jogging is a local function, set F068 to 0 when using it.




Figure 5.6.11:  
Local - Remote Control Connections to TB-1  
Only when F068 = 3

**F069= Reserved**

### **5.6.12 System Settings**

The following functions set operator interface controls and unit programming. Also contained here are the Clock settings used for history functions. Change the Clock settings if accurate time values are important.

#### **F070 = Parameter Lock / User Password**

**Factory Setting = 0 (disabled)**

**Range = 0 – 999**

Use only when necessary to prevent unauthorized access.

Provides users with the ability to prevent unauthorized operators from making changes to the programmed functions. If you do NOT need to take advantage of this feature, do not enter anything into this function. The factory default is disabled, and no Password is necessary to make changes to the program.

**See Appendix 3 at the end of this manual for detailed instructions on using and altering the Parameter Lock / User Password feature.**

#### **F071 = Emergency Clear / Reset**

**Factory Setting = 0 (disabled)**

**Range = 0 – 2**

This Function serves two purposes. It can clear the memory values used for lockouts and overload protection, and it can reset all functions to the factory default settings. This is a “One-Shot” feature, so when another value is entered as shown below, this function automatically returns to the default state.

- **When F071 = 0**, the feature is disabled.
- **When F071 = 1**, the values stored in the Thermal Register and all of the Lockout Timers will be cleared. This will allow an **Emergency Restart** without having to wait for proper cool down time or lockout timers to expire.



#### **WARNING!**

**Clearing the Thermal Register to allow restarting without proper cool-down time after an Overload Trip can result in motor damage and fire. Use only where emergency restart is necessary with knowledge of these potential hazards.**



- **When F071 = 2**, the values of all functions will be reset to the factory default settings. Use this feature when setting conflicts have occurred or parameters have been tampered with. The Fault History is also cleared with this function.

#### **Note:**

This will not reset F070 = Parameter Lock / User Password. See Appendix 3 for resetting this feature.

**F072 = Reserved**

**F073 = Unit Frame Rating:**  
Read Only. Reserved for Factory Use

**F074 = CT Ratio:**  
Read Only. Primary value of the **VMX Series** internal Current Transformers (CTs) for use in determining the GF trip settings (F046). CTs cannot be used for external metering. Alteration is reserved for factory use only.

- **5.6.12.a Real Time Clock Settings**  
Functions F075 through F080 set the system real time clock. The time clock is used in the 24hr Time Clock Controller operation (F032 – F039) and for date/time stamping of the Fault History. The clock automatically adjusts for leap years and is backed up by a Lithium ion battery for long life.



- **Note:**  
The time clock does not automatically adjust for daylight savings time.

**F075= Year**  
**Factory Setting = Year of manufacture**  
**Range = 2000 to 2047**

**F076 = Month**  
**Factory Setting = Month of manufacture**  
**Range = 1 – 12**

**F077 = Day**  
**Factory Setting = Day of manufacture**  
**Range = 1 – 31**

**F078 = Hour**  
**Factory Setting = Actual (EST)**  
**Range = 0 - 23 (12:00 midnight is hour 0)**

**F079 = Minute**  
**Factory Setting = Actual (EST)**  
**Range = 0 – 59**

**F080 = Second**  
**Factory Setting = Actual (EST)**  
**Range = 0 – 59**

**F081 = Firmware revision number for Factory Use**

**F082 -F084 = Reserved**

### 5.6.13 Fault History and Statistical Data

F085 – F097 contain the Fault History and Statistical data for the Run Mode.

#### 5.6.13.a Fault History

Fault codes for each of the three latest events are stored with time and date stamps; see Chapter 7 for a complete list of fault codes and corresponding error displays.

Time stamps use the 24hr HH.MM format, so for example 3:19 PM would display as [15.19]

Date stamps use the MM.DD format, so for example September 3<sup>rd</sup> would display [09.03]

|                                | Fault #1<br>(Latest Fault) | Fault #2<br>(Previous Fault) | Fault #3<br>(Oldest Fault) |
|--------------------------------|----------------------------|------------------------------|----------------------------|
| Fault code:<br>(See Chapter 7) | F085                       | F088                         | F091                       |
| Time Stamp<br>(HH.mm)          | F086                       | F089                         | F092                       |
| Date Stamp<br>(MM.DD)          | F087                       | F090                         | F093                       |

Table 5.6.13.a: Fault History Configuration

**F085 = Latest Fault Code (Fault #1)**

**Factory Setting = 0 (No Fault)**

**Range = 0 – 27**

This Function displays the Fault Code of the latest fault event.

**F086 = Time Stamp of the Latest Fault**

**Factory Setting = 00.00 (No Fault)**

**Range = 00.00 – 23.59 (24hr time format)**

This Function displays the time of the latest fault event.

**F087 = Date Stamp of the Latest Fault**

**Factory Setting = 00.00 (No Fault)**

**Range = 01.01 – 12.31**

This Function displays the date of the latest fault event.

**F088 = Same as F085 except for the Previous Fault (Fault #2)**

**F089 = Same as F086 except for the Previous Fault.**

**F090 = Same as F087 except for the Previous Fault.**

**F091 = Same as F085 except for the Oldest Fault (Fault #3)**

**F092 = Same as F086 except for the Oldest Fault**

**F093 = Same as F087 except for the Oldest Fault**

▪ **5.6.13.b Statistical Data**

F094 - F097 display information from the Run Time / Elapsed Time meter and Run-Cycle counter.

**Run Time** includes Accel, Run, Decel, and Jog operations.

**Run Cycles** are counted only when the starter reaches At-Speed mode.

**F094 = Run Time, Hours**

**Factory Setting = 0000**

**Range = 000.9 - 999.9 hours**

Run times in excess of 999.9 are recorded in F095.

**F095 = Run Time, K Hours**

**Factory Setting = 0000**

**Range = 0000 - 9999 K hours**

0001 in readout means a run time of 1,000 hours.

**F096 = Run Counts**

**Factory Setting = 0000**

**Range = 0000 - 9999**

Run counts in excess of 9999 are recorded in F097.

**F097 = Run Counts, 10K Times**

**Factory Setting = 0000**

**Range = 0000 - 9999, 10 thousand times**

0001 in readout means a run count of 10,000 operations.

| Examples:                   | Overflow Value | Basic Value |
|-----------------------------|----------------|-------------|
| Run Time<br>23,047 Hours    | F095           | F094        |
|                             | 0002           | 3047        |
| Run Counts<br>18,702 Starts | F097           | F096        |
|                             | 0001           | 8702        |

Table 5.5.15: Statistical Data Examples

## Chapter 6 - Start-up

### 6.1 Basic Startup

Your new **VMX Series** Soft Starter is factory preset for a wide variety of applications and often can be used with minimal adjustment.

#### 6.1.1 Three Step Process

1. Connect L1, L2, and L3 to the input voltage source and T1, T2, and T3 to motor.
2. Connect control wires and control power.
3. Program motor FLA (F001).

#### 6.1.2 Start-up Parameters and Factory Defaults

In the initial start-up, test the performance of the starter with the initial factory presets, if required adjust or enable the more advanced features to meet your specific application requirements.

| Fn #        | Function Name                            | Factory Setting | Description / Factory Setting                             |
|-------------|------------------------------------------|-----------------|-----------------------------------------------------------|
| F001        | Motor Nameplate FLA.                     | 0               | FLA must be programmed for the starter to operate.        |
| F002        | Motor Nameplate Service Factor           | 1.0 SF          | Change only if necessary and for motors rated above 1.0SF |
| F003        | Overload Class During Start              | Class 10        | NEMA / UL Class 10                                        |
| F004        | Overload Class During Run                | Class 10        | NEMA / UL Class 10                                        |
| F005        | Overload Reset                           | 0 (Manual)      | 0 = Manual                                                |
| F010        | Ramp Profile                             | 1               | Ramp 1 and Ramp 2 = Voltage Ramp with Current Limit       |
| F011        | Initial Torque                           | 60              | 60% Initial Voltage                                       |
| F013        | Ramp Time                                | 10              | 10 Second Ramp (Ramp 1)                                   |
| F014        | Current Limit                            | 350             | 350% of programmed FLA                                    |
| F015 – F018 | Ramp 2 settings                          | ---             | Inactive unless Ramp 2 Input is closed                    |
| F019 – F052 | Software protection and control features | ---             | Inactive unless selected                                  |
| F053        | Internal hardware protection features    | 127             | All active                                                |
| F054 – F059 | Timer and counter value readouts         | ---             | Read only                                                 |
| F060        | Aux Relay #1                             | 1               | Run / Stop                                                |
| F061        | Aux Relay #2                             | 2               | At-Speed / Stop                                           |
| F062        | Aux Relay #3                             | 16              | Any Fault                                                 |
| F063        | Aux Relay Delay                          | 0               | No Delay                                                  |
| F065 – F068 | Communications                           | ----            | Not Used unless without optional Comm Adaptor.            |
| F070        | Parameter Lock                           | 0               | User password disabled                                    |
| F071        | Reset Function                           | 0               | Use to reset to default values                            |
| F073 – F080 | System settings and time clock           | ---             | User choice to adjust clock                               |
| F085 – F093 | Fault History                            | ---             | Read only                                                 |

**Table 6.1.2: Factory Presets**

## 6.2 Start-up Check List

- ☐ Supply voltage matches the rated supply voltage of the unit.
- ☐ Horsepower and current ratings of the motor and starter have the same rating or the starter has a higher rating.
- ☐ Initial ramp time and torque adjustments have been checked.
- ☐ Input voltage source are connected to the starters input terminals L1, L2 and L3.
- ☐ Motor leads are connected to the starter output terminals T1, T2, and T3.
- ☐ Appropriate control power is applied and/or control connections have been made.
- ☐ "Power On" light located on the front of the unit turns on when control power is applied.
- ☐ Four 7-segment LED readout is visible.
- ☐ The motor's FLA has been programmed in function F001.
- ☐ The thermal overload is properly set. (Use F003 and F004 to set OL Class.)
- ☐ The motor area and equipment are clear of personnel and parts before start-up.

## 6.3 Sequence of Operation

- Apply three-phase power to the unit. The motor should not run until the start command is applied.
- Apply control power and check that the "Power On" LED comes on.
- Status Display should read **[0000.]** showing no current in Phase A (minor flickering of the first digit is common).
- Apply the Run (Start) command. The motor should begin to accelerate. Status display will read Phase A Amps at an increasing rate.
- When the motor reaches full speed, the "At Speed" LED comes on. Status display should show a sharp decrease in Phase-A amps.
- If a Bypass Contactor is present (VMX...-BP model), the Bypass Contactor should pull in.
- If the motor does not fully accelerate, decelerates, or stops during the acceleration period, push the Stop button immediately and open the disconnect line.

### If Pump-Flex Decel is programmed in F025:

- Remove the Run Command (or push the Stop button). At-Speed LED will go out.
- If a Bypass Contactor is present (VMX...-BP model), the Bypass Contactor should drop out.
- Status display should read Phase-A amps increasing as motor begins to decelerate.
- Motor should begin to slow down. Status display should begin to show decreasing motor amps.
- When motor reaches Stop Level, starter should turn off. Status display will again show **[0000.]**

If the unit does not follow this operational sequence please refer to the Service and Troubleshooting Guide section.

#### 6.4 Testing with a smaller motor

- To test the **VMX Series** starter in combination with a motor that draws less than 20% of the starters Max Amp rating, the Phase Current Loss (Running) protection must be disabled as per instructions in section 5.6.9.a. If this feature is not disabled, the **VMX Series** will trip on a Phase Loss fault after running for 3 seconds at low current levels.

## Chapter 7 - Fault Conditions

Additional information on Fault Codes and possible causes can be found in the **Service and Troubleshooting Guide**.

### 7.1 Fault Codes and Numbers (in History)

A three-character fault code is displayed in the LED display at the time of the trip event. The first two digits indicate the trip condition (see Table 7.1). The third digit is a suffix showing the **VMX Series** operating mode when the trip occurred. Operating modes are as follows:

**Code suffix “A”:** Acceleration, meaning that the **VMX Series** was ramping up but had not yet achieved “At-Speed” status (see section 4.2.9.b for a brief description of At-Speed indication).

**Code suffix “c”:** Constant Speed (running), meaning that the **VMX Series** has reached the At-Speed condition and the motor was running when the trip occurred.

**Code suffix “d”:** Decel or Stop, meaning that **VMX Series** was either stopped (off, but power applied), or if the Pump-Flex Decel function was enabled, it was engaged in the Soft Stop routine set up by F024-27. ???



#### IMPORTANT NOTE:

**Fault code SSd may display if there is no output load (motor) connection when control power is applied!**

In addition to these fault display codes, each trip condition has a corresponding numeric code that is stored in the Fault History (see section 5.6.13.a). The numeric codes follow the display codes exactly. Table 7.1 shows the Fault Display Codes, Fault Number Codes and LED indicators for each fault condition. Additional details are available in the Service and Troubleshooting Guide.

**Example:** If Function F003 (starting overload protection) is set too low for the size of the load and causes a trip, the fault code “oLA” will be displayed. Its corresponding number will be entered into the fault history. In this case, the number 0010 will be shown on the display in function F085 (Fault History). The time the fault occurred is available in function F086 shown as “hh.mm.” Example: if the “oLA” fault occurred at 10:00 am, F086 would display “10.00.” The date the fault occurred is available in function F087. The date is shown as “mm.dd”. If the “oLA” fault occurred on March 1, F077 shows “03.01.” If no fault history is available F085 reads 0000.

| Fault Condition Description                   | Fault Display Code Readout | Fault Number Code used in History, F085, F088 and F091 | LED Indicator          |
|-----------------------------------------------|----------------------------|--------------------------------------------------------|------------------------|
| No Full Load Amps entered into F001           | <b>nFLA</b>                |                                                        |                        |
| Over Current during Acceleration              | <b>ocA</b>                 | 1                                                      | Over Current           |
| Over Current during Constant speed            | <b>occ</b>                 | 2                                                      |                        |
| Over Current during Deceleration              | <b>ocd</b>                 | 3                                                      |                        |
| Phase Loss during Acceleration                | <b>PLA</b>                 | 4                                                      | Phase Loss             |
| Phase Loss during Constant speed              | <b>PLc</b>                 | 5                                                      |                        |
| Phase Loss during Deceleration                | <b>PLd</b>                 | 6                                                      |                        |
| Line Voltage Loss (no 3 phase prior to start) | <b>n3Ph</b>                | 6                                                      |                        |
| Over Temperature during Acceleration          | <b>oTA</b>                 | 7                                                      | Over Temp              |
| Over Temperature during Constant speed        | <b>otc</b>                 | 8                                                      |                        |
| Over Temperature during Deceleration          | <b>otd</b>                 | 9                                                      |                        |
| Over Load during Acceleration                 | <b>oLA</b>                 | 10                                                     | Over Load              |
| Over Load during Constant speed               | <b>oLc</b>                 | 11                                                     |                        |
| Over Load during Deceleration                 | <b>oLd</b>                 | 12                                                     |                        |
| Shorted SCR during Acceleration               | <b>SSA</b>                 | 13                                                     | Shorted SCR or no load |
| Shorted SCR during Constant speed             | <b>SSc</b>                 | 14                                                     |                        |
| Shorted SCR during Deceleration or Stop       | <b>SSd</b>                 | 15                                                     |                        |
| Shunt Trip during Acceleration                | <b>st</b>                  | 16                                                     | Shunt Trip             |
| Shunt Trip during Constant speed              | <b>st</b>                  | 17                                                     |                        |
| Shunt Trip during Deceleration                | <b>st</b>                  | 18                                                     |                        |
| Current Imbalance during Acceleration         | <b>IBA</b>                 | 19                                                     | ---                    |
| Current Imbalance during Constant speed       | <b>IBc</b>                 | 20                                                     |                        |
| Current Imbalance during Deceleration         | <b>IBd</b>                 | 21                                                     |                        |
| Under Current during Acceleration             | <b>UcA</b>                 | 22                                                     | ---                    |
| Under Current during Constant speed           | <b>Ucc</b>                 | 23                                                     |                        |
| Under Current during Deceleration             | <b>Ucd</b>                 | 24                                                     |                        |
| Short Circuit during Acceleration             | <b>ScA</b>                 | 25                                                     | Over Current           |
| Short Circuit during Constant speed           | <b>ScC</b>                 | 26                                                     |                        |
| Short Circuit during Deceleration             | <b>Scd</b>                 | 27                                                     |                        |
| Ground Fault during Acceleration              | <b>GFA</b>                 | 28                                                     | ---                    |
| Ground Fault during Constant speed            | <b>GFc</b>                 | 29                                                     |                        |
| Ground Fault during Deceleration              | <b>GFd</b>                 | 30                                                     |                        |
| Bypass Discrepancy during Acceleration        | <b>BPA</b>                 | 31                                                     | ---                    |
| Bypass Discrepancy during Constant speed      | <b>BPc</b>                 | 32                                                     |                        |
| Bypass Discrepancy during Deceleration        | <b>BPd</b>                 | 33                                                     |                        |
| PTC Trip during Acceleration                  | <b>PtA</b>                 | 34                                                     | Over Load              |
| PTC Trip during Constant speed                | <b>Ptc</b>                 | 35                                                     |                        |
| PTC Trip during Deceleration                  | <b>Ptd</b>                 | 36                                                     |                        |
| Rotation Trip during Acceleration             | <b>rtA</b>                 | 37                                                     | ---                    |
| Rotation Trip during Constant speed           | <b>rtc</b>                 | 38                                                     |                        |
| Rotation Trip during Deceleration             | <b>rtd</b>                 | 39                                                     |                        |

Table 7.1: Fault code List

## Appendix 1 - Ramp Profile Details

The **VMX Series** offers four different types of starting ramp profiles. Simply select the one that best matches your motor / load requirements. In addition, **two separate ramps** are available that can be selected via contact closure (see section 4.2.5.a), and each one can be set up for any ramp type as shown in the table below.

| Ramp 1 Settings |                        |                   |                       | "Ramp Type Selection" from F010 | Ramp 2 Settings |                        |                   |                       |
|-----------------|------------------------|-------------------|-----------------------|---------------------------------|-----------------|------------------------|-------------------|-----------------------|
| Ramp Type       | Initial Torque from... | Ramp Time from... | Current Limit from... |                                 | Ramp Type       | Initial Torque from... | Ramp Time from... | Current Limit from... |
| Voltage         | F011                   | F013              | F014                  | 1                               | Voltage         | F015                   | F017              | F018                  |
| Current         | F012                   | F013              | F014                  | 2                               | Current         | F016                   | F017              | F018                  |
| Voltage         | F011                   | F013              | F014                  | 3                               | Current         | F016                   | F017              | F018                  |
| Current         | F012                   | F013              | F014                  | 4                               | Voltage         | F015                   | F017              | F018                  |

Table APP 1.1: Ramp Selection Choices and Settings




Figure APP 1.1:  
Voltage Ramp w/o Current Limit




Figure APP 1.2:  
Voltage Ramp with Current Limit

### Following are descriptions of the four types of Ramp Profiles

**1. Voltage Ramping** is the most reliable starting method, due to the fact that at some point the starter will reach an output voltage high enough to allow the motor to draw full current and develop full torque. This method is useful for applications where the load conditions change frequently and significantly enough to require different levels of starting torque. Examples where this is effective are:

- Material handling conveyers
- Positive displacement pumps
- Drum mixers, grinders etc.

Voltage is increased from a starting point (Initial Torque) to full voltage over an adjustable time period (Ramp Time). To achieve Voltage Ramping, set the Ramp Profile (F010) to 0001 or 0003 (Voltage Ramp), and the Maximum Current Limit setting (F014) to maximum (600%). Since this is essentially Locked Rotor Current on most motors, there will be little or no Current Limit effect on the Ramp profile. Initial Torque setting comes from the Initial Voltage function F011.

**2. Voltage Ramping with Current Limit** works similar to mode 1, except this mode adds an adjustable maximum current output. Voltage is increased gradually until the motor current reaches the Maximum Current Limit setting (F014). The motor current is held at this level until the motor accelerates to full speed. When the motor current drops below the limit setting the output voltage is automatically increased to maximize torque until the **VMX Series** is At-Speed. This may be necessary in applications where the electrical power is limited. Examples would be:

- Portable or emergency generator supplies
- Utility power near the end of a transmission line or other starting power demand restrictions.

Using Current Limit will override the Ramp Time setting if necessary, so use this feature when acceleration time is not critical. The Ramp Time setting however still determines the slope of the ramp up to the Current Limit setting to apply the softest possible acceleration. To achieve Voltage Ramping with Current Limit, set the Ramp Profile (F010) to 0001 or 0003 (Voltage Ramp), and the Maximum Current Limit setting (F014) to a desired lower setting, as determined by your application requirements.




Figure APP 1.3:  
Current / Torque Ramp

**3. Closed Loop Current (Torque) Ramping** provides smooth linear acceleration of output torque. Ramp Time becomes the time from Initial Torque and Current Limit settings. Output torque is constantly updated using an internal PID feedback loop to provide a linear ramp, therefore the available torque is maximized at any given speed. The best use of this feature is for applications where rapid changes in torque may result in load damage or equipment changes. Examples would be:

- Long overland conveyors where belt stretching may occur.
- Low pressure pumps where slight surges at the end-of-ramp may pose mechanical problems.
- Fans and mixers where blade warping is a problem.
- Material handling systems where stacked products may fall over or break.

This feature can be used with or without the Maximum Current Limit setting.

To achieve Torque Ramping with the **VMX Series**, set the Ramp Profile (F010) to 0002 or 0004 (Current Ramp), and the Maximum Current Limit setting (F014) to the desired level. Initial Torque setting comes from the Initial Current function F012.




Figure APP 1.4:  
Current Step Starting

**4. Current Limit Only (Current Step)** uses the Current Limit feature exclusively without the benefit of soft starting by ramping the voltage or current first (also known as **Pedestal Starting**). This will maximize the effective application of motor torque within the limits of the motor. In this mode, Initial Torque is set to maximum and Ramp Time is set to minimum, so that the output current jumps to the Current Limit setting immediately. Examples of when to use this mode are:

- Applications with a severely limited power supply
- When starting a difficult load such as a centrifuge or deep well pump
- When the motor capacity is barely adequate without stalling or overloading.
- It is a good choice when other starting modes fail.

Since ramp times are set to minimum, this mode functions in either Voltage Ramp or Current Ramp setting.

### Ramp Parameter Descriptions

Following are detailed descriptions of the individual settings that make up each ramp profile.

#### Initial Torque (Initial Voltage or Initial Current).

These functions set the initial start point of either the Voltage Ramp or Current Ramp as programmed in F010. Every load requires at least some amount of torque to start from a standstill. It is not efficient to begin ramping the motor from zero every time, since between zero and the (WK<sub>2</sub>) breakaway torque level, no useful work is being performed. The initial torque level should be set to provide just enough torque to make the motor shaft begin to rotate, enabling the softest possible start and preventing torque shock damage to the mechanical components. Setting this function too high will not damage the starter, but may reduce or eliminate the soft start advantages.

**Accel Ramp Time.** This Function sets the maximum allowable time for ramping from the Initial Torque setting to either of the following:

- 1) Current limit setting when the motor is still accelerating, or
- 2) Full output voltage if the Current Limit is set to maximum.

Increasing the Ramp Time softens the start process by lowering the slope of increase in voltage or current. This should be set to provide the softest possible start without stalling unless it is determined that the application has other considerations. Applications where this setting should be shorter include Centrifugal Pumps, because pump problems may occur as a result of insufficient torque during acceleration through the pump curve.



▪ **Note:**

Ramp Time is affected by the following conditions:

1. Current Limit will automatically override the Ramp Time if set to Voltage Ramp (F010=1) and if the motor does not reach full speed while in current limit mode.
2. An “Anti-Oscillation” circuit built-in to the **VMX Series** will shorten the Ramp Time if the motor reaches full speed before end of ramp.

**Current Limit.** This Function sets the maximum motor current that the starter allows during Ramping. It is active in both the Voltage Ramp and Current Ramp modes. As the motor begins to ramp, this feature will set a maximum at which the current draw will be held. Current Limit will remain in effect until one of the following two events occur:

1. The motor reaches full speed as detected by the At-Speed detection circuit.
2. The Overload Protection trips on Motor Thermal Overload (see Ch.3).

Once the motor has reached full speed, the Current Limit feature becomes inactive.

- **In the Voltage Ramp Profile**, the Voltage output is increased until the Current Limit is reached. The Ramp Time is the maximum time it will take for the voltage to increase until the Current Limit setting takes over. Under some load conditions, Current Limit may be reached before the Ramp Time has expired.
- **In the Current Ramp Profile**, output voltage varies to provide a linear increase in current up to the Current Limit setting, and Ramp Time is the time that it will take to get there. A closed loop feedback of motor current allows continuous updating of the output to maintain this ramp profile.


Because most AC induction motors will not start below 200% current, the current limit set point is adjustable down to only 200%.

**Caution:**

**While in the Start mode there is no maximum Current Limit time. Excessive start time may lead to motor stalling, causing an Overload Trip. If this happens, try raising the Current Limit setting to accommodate your load conditions. If the Current Limit setting cannot be increased, try using Current Limit without ramping features (“Current Limit Only” as described previously).**



## Appendix 2: Pump-Flex® Decel Mode Application Considerations




Pump-Flex® Deceleration (Soft Stop) is a unique feature of Motortronics Solid State Soft Starters. It provides a slow decrease in the output voltage, accomplishing a gentle decrease in motor torque during the stopping mode. This is the **OPPOSITE OF BRAKING** in that it will take **longer** to come to a stop than if the starter were just tuned off.

The primary use of this function is with centrifugal pumps as a means to reduce the sudden changes in pressure that are associated with “Water Hammer” and slamming of check valves. Decel control in pump applications is often referred to as **Pump Control**.

In a pump system, liquid is being pushed uphill. The force exerted by gravity on the column of liquid as it goes up hill is called the “Head Pressure” in the system. The pump is sized to provide enough Output Pressure to overcome the Head Pressure and move the fluid up the pipe. When the pump is turned off, the Output Pressure rapidly drops to zero and the Head Pressure takes over to send the fluid back down the hill. A “Check Valve” is used somewhere in the system to prevent this (if necessary) by only allowing the liquid to flow in one direction.

Kinetic energy in that moving fluid is suddenly trapped when the valve slams closed. Since fluids can’t compress, that energy is transformed into a “Shock Wave” that travels through the piping system looking for an outlet in which to dissipate. The sound of that shock wave is referred to as “Water Hammer”. The energy in that shock wave can be extremely damaging to pipes, fittings, flanges, seals and mounting systems.



### **SOLUTION:**

By using the Pump-Flex® Decel feature of the **VMX Series**, the pump output torque is gradually and gently reduced, which slowly reduces the pressure in the pipe. When the Pump Output Pressure is just slightly lower than the System Head Pressure, the flow slowly reverses and closes the Check Valve. By this time there is very little energy left in the moving fluid and the Shock Wave is avoided. When the output voltage to the motor is low enough to no longer be needed, the **VMX Series** will end the Pump-Flex® Decel cycle and turn itself off.

### **Caution!**

**Decel is THE OPPOSITE of braking. Enabling the Decel feature will make the motor take LONGER to stop than if it were simply turned off.**



### Setup and Use

Pump systems vary greatly. To accommodate this, the **Pump-Flex®** Decel control feature is designed to provide complete flexibility in how the deceleration process takes place by using the following settings.

Decel begins when a Stop command is given (or the Run command is removed). If there is a Bypass Contactor, it will open immediately, putting the power control back to the SCRs.




Figure APP2.2: Pump-Flex Decel Graph

**F024 = Deceleration Ramp**  
Factory Setting = 0 (Disabled)  
Range = 0 – 2

When **F024 = 0**, the deceleration feature is **disabled**.

When **F024 = 1**, the deceleration feature is **enabled** AND the overload protection feature (from F003 - F005) remains active. When a Stop command is given, the starter begins to apply Decel voltage. However, if an overload trip occurs, the starter ceases applying Decel voltage and the motor coasts to a stop to prevent additional motor heating and potential motor damage.

When **F024 = 2**, the deceleration feature is **enabled** and deceleration will **continue even when an overload condition trips**. This is to be used only when the risk of damage due to an uncontrolled shutdown is considered worse than the potential damage to the motor.

#### WARNING!



Setting **F025 = 2** presents significant risk of over-heating the motor beyond its design limits which could result in motor damage and fire hazard. Do this only in circumstances where the potential for mechanical damage outweighs the risk of motor damage and fire.



#### Note:

The PTC Input will act as an Overload trip (disable), however it ALWAYS shuts the starter down **WITHOUT** Decel (as in setting F025=1 above) even if F025 is set to 2.

**F025 = Begin Decel Level (BDL)****Factory Setting = 60%****Range = 0 - 100% of line voltage**

Used to drop voltage to a level where there is a noticeable effect on motor torque during Decel mode. Generally, systems with high head pressure need to start Decel near the top of the ramp (85-95%). Low head systems can drop to lower settings (50-60%). System conditions vary greatly by pump type, pipe size and system head. Some experimentation with settings may be necessary.

**F026 = Decel Shut Off Voltage****Factory Setting = 30%****Range = 0 to (BDL -1)%**

Sets the level where the starter is turned off, corresponding to where motor torque during Decel is no longer effective. Always set this function lower than the setting of F026, Begin Decel Level (this function is restricted from being less than F026 minus 1%). This function is used to shut the motor off once the check valve closes. Again, because systems vary greatly this setting may require adjustment several times. If you cannot hear or see the check valve close, observe fluid pressure or flow if available.

**F027 = Decel Ramp Time****Factory Setting = 10 seconds****Range = 1 - 60 seconds**

Sets the maximum time for the deceleration ramp to go from the Begin Decel Level setting (F026) to the Decel Shut Off Voltage (F027). This function is used to dampen the effect of reducing pump torque as much as possible. If the check valve still slams at the end of ramp, try extending this time function a little. Since motor heating increases as voltage is lowered, the setting should not exceed the time necessary to achieve the deceleration effect.

**▪ Note:**

When using the Decel function, count these cycles as additional "starts" when determining maximum starts-per-hour.

**Other Applications:**

Another common application for Decel control is on material handling conveyors as a means to prevent sudden stops that may cause products to shift, fall over or to bump into one another.

In overhead crane applications, Soft Stopping of the Bridge or Trolley can prevent loads from beginning to over swing on sudden stops.

## Appendix 3: Parameter Lock / User Password Instructions

Provides users with the ability to prevent unauthorized operators from making changes to the programmed functions. **If you do not need to take advantage of this feature, do not enter anything into this function.** The factory default is disabled, and no Password is necessary to make changes to the program.

When any value other than 0000 is entered into this Function, the Parameter Lock is enabled and that number becomes the User Password. From that point forward, it will be necessary to enter the User Password in this Function prior to making changes in any programmed function, including this one. When the Parameter Lock has been enabled, attempts to alter the program will result in the display reading **[Err ]** whenever the **[READ/ENTER]** key is pressed.

To alter the program after the Parameter Lock has been enabled, go to Function **F070** and enter the correct user Password. The display will read an encoded value representing the existing password. As soon as you press the first Arrow key, the display will change to **[0000]** and start showing the actual value of your password entry. When the **[READ/ENTER]** button is pressed, the display will read **[PASS]**, indicating that the User Password is correct and the system is unlocked. You will have 5 minutes in which to make a change in the program. This 5-minute window resets whenever any key is pressed, so it floats to give you 5 minutes after the last entry. After 5 minutes of no keypad activity, the Parameter Lock is reinstated with the current user Password. Subsequent changes will require re-entering the User Password.

To change the User Password or to disable the Parameter Lock function, enter the programmed User Password first, and then set Function F070 to 0, disabling the Parameter Lock. If you do not re-enter the Password or enter a new user password, the Parameter Lock feature will remain disabled. If you enter a different number into this Function, the new number becomes your new User Password. Existing passwords are encoded to "hide" them in the display.



**Caution:**

**DO NOT LOSE YOUR PASSWORD.**

If the password has been lost or forgotten, contact Motortronics for assistance.

### Example: Figure App 3 Enabling Password Protection / Parameter Lock

Starting from the Status Display Mode, no previous function number entered, no existing password...

#### Press the Fn key.

Displays F001 to indicate the beginning of the function list.

#### Press the LEFT arrow key

Selects the second digit (from the right). Note: do it in this order because F000 would not have been a valid number

#### Press the UP arrow key seven times (7X)

Changes the function code to F071.

#### Press the RIGHT arrow key

Selects the first digit (from the right).

#### Press the DOWN arrow key

Changes the function code to F070.

#### Press the Read Enter key

The default display will show **[3552]** as long as no password has been previously entered. This is the default code for "0000", meaning that there is no password. **As soon as you press the first Arrow key, the display will change to [0000]** and begin showing the actual value of your password entry. Any initial display other than **[3552]** signifies that a password already exists. This means that you will need to change, rather than enter a new one (see below).

#### Use the UP arrow and the LEFT arrow keys...

to display the password you desire (Valid range is 0000 to 0999). In this example, 0123 has been selected.

#### Press the Read Enter key

The display will flash **[End]** to confirm you have entered a password. Then it will return to displaying the Function #.

### Example: Setting a Password

#### Using Password 123

| Press Key... | Display Shows... | Means...                         |
|--------------|------------------|----------------------------------|
|              | 0000             | Phase A Current                  |
| Fn           | F070             | Select Function #70              |
| READ ENTER   | 3552             | Default Setting of Function #70  |
| ↑ x 3        | 0003             | New Value of First Digit         |
| ←            | 0003             | Cursor (flashing) Position Shift |
| ↑ x 2        | 0023             | New Value of Second Digit        |
| ←            | 0023             | Cursor (flashing) Position Shift |
| ↑            | 0123             | New Value of Second Digit        |
| READ ENTER   | End              | Value Accepted (flashes once)    |
|              | F070             | Return to Function # Display     |

Figure App 3:  
Entering a Password

### Changing passwords:

To change an existing password, the steps are essentially the same as outlined above, except you must first enter the existing password. At F070, press the **[READ/ENTER]** key to reveal the encoded password (you must know that password before it can be changed). Use the Arrow keys to enter the password. As soon as you press the first Arrow key, the display will change to **[0000]** and start showing the actual value of your entry. When you get to the existing password, press the **[READ/ENTER]** key again. The display will flash **[PASS]** to indicate that the password was accepted. If it flashes **[Err]**, you have entered the wrong password.

Resetting to Factory Defaults using F071 will NOT reset the password.

### Disabling Password Protection / Parameter Lockout

Changing function F070 to **[0000]** will disable the user password. If the initial display reads **[3552]**, the password is already set to **[0000]**.

## Appendix 4: Process Control Timer Functions

### F030 through F039; Overview of Process Timer Control and Time Clock Controller Features:

The following special functions allow your **VMX Series** starter to operate automatically from an internal Process Control Timer and Time Clock Controller (TCC) using a real time clock. The Process Control Timer (F030 and F031) can be used independently or together with the TCC feature (F032-39). The TCC requires using the Process Control Timer to provide for Start commands (depending on the selected mode). Time progression and clock values can be read in the Status Screen (see section 5.3.1).

A convenient chart at the end of this appendix shows all settings and interactions.

#### F030 = Process Control Timer Selection

**Factory Setting = 0 (Disabled)**

**Range = 0, 1, 2**

This function enables a **Process Control Timer**, which offers two operating modes (Minimum Batch Run Timer and Permissive Run Timer), selected by entering 1 or 2 here.

#### F030 = 1: Minimum Batch Run Timer

In this mode, the **Process Control Timer** ensures that the motor will run for a minimum amount of time, regardless of whether someone stops it intentionally, or power fails and returns. When selected, the Minimum Run Timer begins counting down after a Start command. The Time Value is set in **F031**. When the time value reaches **[0000]** the starter will turn off, even if the Start command is still closed and there is no Stop command.

To **Reset** the timer in this mode, initiate a Stop command after the timer has expired. If using the TCC (F032), reset is automatic when completed and no other Run command is present.

If a Stop Command, power failure or Fault trip occurs during timed operation, the **Process Control Timer** is suspended and maintains its value. When the starter is then restarted, the timer resumes counting down to ensure that the motor has run for the programmed amount of time (finishes the batch).

Use this function to ensure that a load operates for a minimum amount of time regardless of other circumstances. **Examples** would be:

- **Irrigation pumps** where a specific amount of pumping time is required even if the pump is shut down on a low level alarm and then resets, or power fails and returns.
- **Mixers** that need to agitate for a specific amount of time yet may be shut down when power fails or as product is added.
- **Aeration Blowers** that must be run for minimum amounts of time to ensure that proper aeration (contact time) has been provided to a tank.

#### ▪ **Note:**



In **2-wire control systems** where the Run command is maintained, the starter will automatically restart after a power failure or a Fault is reset. Use appropriate warnings as mentioned in section 3.1.3.b (see the following F032 description for an exception to this).

In **3-wire control systems**, a new Start command will be required to restart the starter.

**Example: Figure App 4.1  
Minimum Run (Batch) Timer**

An irrigation pump needs to come on when called for by a soil moisture control system, and run for ½ hour. If during that ½ hour the well level drops and shuts the pump down, the pump needs to restart when the well recovers and finish the ½ hour pump time.

**Set F030 to [0001] for Minimum Run Timer.**

This will ensure that when the well level recovers and resets the run command, the starter will finish the time sequence.

**Set F031 to [0030] (minutes)**

This is the Run Time that ensures the proper amount of irrigation getting to the crop.

**(Not Shown)**

**Ensure F032 is set to [0000] for One Shot**

This will allow the Start command provided by the external control system to engage the starter at any time it is required.

*(Another example of this function used with the Time Clock Controller is provided further on)*

| Example: Process Timer for Well Pump                           |                  |                                 |
|----------------------------------------------------------------|------------------|---------------------------------|
| Press Key...                                                   | Display Shows... | Means...                        |
|                                                                | F030             | Starting at Function #30        |
| READ ENTER                                                     | 0000             | Default Setting of Function #30 |
| ↑                                                              | 0001             | Set F030 = 1 Minimum Run Timer  |
| READ ENTER                                                     | End              | Value Accepted (flashes once)   |
| ↑                                                              | F031             | Change to F031                  |
| READ ENTER                                                     | 0000             | Default Setting of Function #31 |
| ← ↑ x 3                                                        | 0030             | Change Setting to 30 minutes    |
| READ ENTER                                                     | End              | Value Accepted (flashes once)   |
|                                                                | F031             | Return to Function # Display    |
| Cycle Control Power to Accept Changes                          |                  |                                 |
| Figure App 4.1:<br>Programming the Minimum Run Timer Functions |                  |                                 |

▪ **Notes on interactions with other functions:**

When used with F028 (Auto-Restart Delay), the Minimum Batch Timer will not resume counting down until F028 has expired and the starter has restarted. When used with **3 wire control**, it may be necessary to maintain a Start Command until after F028 has expired, or repeat if momentary.

When used with F049 – F050 (Lockout Protection features), the Minimum Batch Timer will not resume counting down until those settings have been satisfied and the **VMX Series** starter has restarted. When used with **3-wire control**, it may be necessary to maintain a Start Command until after they are satisfied, or repeat if momentary.

When used with the Pump Flex Decel feature, the Decel Time (F027) is counted as part of the Batch Run time for this feature.

### **F030 = 2: Permissive Run Timer.**

In this mode, the **Process Control Timer** engages differently according to the settings of the Time Clock Controller (TCC).

When the TCC is set to 0 (using “One Shot” operation), the Process Control Timer begins counting down after the first Start command. Subsequent stop and start commands have no further affect on the timer status and can be used to fully control the starter. When the timer finishes (F031 = [0000]), the starter will shut off. Upon the next Start command, the timer will reset and begin counting down again. In 2 wire control systems, the starter will shut off even if the Run command is still closed, and will only reset after the Run command has been cycled (opened and reclosed).

Use this function in *without* the Time Clock Controller (One-Shot mode) to ensure that a load only operates *for a maximum* of the programmed amount of time, beginning with the first Start command. **Examples** would be:

- **Pumps** where the failure of a stop float may lead to dry run conditions if allowed to operate too long, or when the pump only needs to run when someone is present, but operate automatically via float switched (pump-out for service).
- **Ventilation Blowers** where operation is controlled by a manual switch but may be inadvertently left on when someone leaves.

When the TCC is set for 1 through 8 (using Start Event Cycles), the timer begins counting down immediately **when a Start Event is activated**. Any Start / Stop Command that is given to the starter during this time will work normally. When the timer finishes (F031 = [0000]), the starter will shut off, and **Start / Stop commands will no longer function until the next Start Event Cycle (SEC)**. In 2 wire control systems, If a Run command is already present when the SEC occurs, it will make no difference and the starter will start.

**Reset** of the **Permissive Run Timer** will occur only when the next Start Event Cycle is activated by the Time Clock Controller, or when changes are made to programming (see note on programming changes (see “Important Note” on page 80). Loss of control power without program changes will NOT reset the time.

Use this function in conjunction with the Time Clock Controller to ensure that a load only operates during the programmed amount of time, beginning with the Start Event Cycle. **Examples** would be:

- **Air compressors** where leaking of air lines during normal downtime causes the compressor to run unnecessarily
- **Irrigation pumps** where operation during parts of the day is undesirable.
- **Energy Savings** to prevent operation when Time-of-Use (TOU) metering discounts are provided to promote conservation.

### Example: Figure App 4.2 Permissive Run Timer

An air compressor controlled by a pressure switch feeds a large air distribution system that has small normally insignificant leaks. If left on over night when the system is not in use, leaks drop the air pressure and the compressor cycles on and off even though the facility is unoccupied, wasting energy.

#### Set F030 to [0002] for Permissive Run Timer.

This will ensure that if not purposely turned off, the compressor will not run when the facility is shut down.

#### Set F031 to [0600] minutes (10 hours)


This is the longest Run Time after which the starter will automatically shut down. This ensures that it will not restart after the time expires and until a new Start Event occurs.

#### (Not Shown)

#### Ensure F032 is set to [0001] for Every Day, and F033 is set to correspond to work start time (or 5 minutes prior)

This will allow the Run command provided by the pressure switch to engage the starter any time it is required after the shift begins.

With this setting, the compressor will start whenever the pressure switch calls for it after the Start Event set by the Time Clock Controller, but if forgotten, it will shut itself off after 10 hours. If power is turned off or lost during those 10 hours, the timer is not cleared or reset, so even if it is turn back on 1 minute before the timer expires, it still shuts off at the end of that 10 hour period.



### Notes:



If the **Process Control Timer** (F030) is set for Minimum Batch Timer (value of 1), and the next Start Event Cycle passes without a Start command, the previous event will be ignored in favor of the new one.

If a **Process Control Timer** setting from F031 is so long that it overlaps a Start Event Cycle setting in F032-F039, the original timer value becomes invalid. The new Start Event Cycle reloads the value of F031 and begins counting down again from the beginning.

### F031 = Process Timer Value

**Factory Setting = 1**

**Range = 1 – 9999 minutes**

This function loads a value into the **Process Control Timer** above. When initialized, the value counts down towards 0. F030 sets the operating mode and reset functions for this timer.

The value of this timer can be read directly in the main Status Screen (see section 5.3.1). When the **Process Control Timer** has been enabled in F030, the Status Screen display for the value will flash once per second while timing. When completed, it will stop flashing and read [0000].



- **IMPORTANT NOTE:** When F030 or F031 is changed in program mode, the timer will not respond to the new settings until after control power has been cycled (off and back on again).

**F032 = Time Clock Controller (TCC)**

**Factory Setting = 0 (One Shot)**

**Range = 1 - 8 settings**

This function is used to select the operating mode of the 24hr / 7 Day **Time Clock Controller (TCC)**.

**F032 = 0** operates the SEC in a “One-Shot” mode (factory default setting). When set to 0, the Process Timer (F030) responds only to each **NEW** hard-wired START input command.

**Use this setting to allow the Process Control Timer to operate without the TCC.**

For safety purposes when using 2 wire control systems in this mode only, if power fails and the START/RUN command is present when power is restored, the starter will ignore this command until the input is cycled Off and back On (terminals TB1-1 and 3 are opened and reclosed).

**For automatic operations,** F032 can also set the number of days in which the TCC will repeat a **Start Event Cycle (SEC)**. Each Start Event Cycle consists of from 1 to 7 Start Events as programmed in F033 through F039 below. Start Events can be non-sequential (see Note below).

**F032 = 1** operates the SEC every day of the week.

**F032 = 2** operates the SEC every 2 days (every other day)

**F032 = 3** operates the SEC every 3<sup>rd</sup> day.

**F032 = 4** operates the SEC every 4<sup>th</sup> day.

**F032 = 5** operates the SEC every 5<sup>th</sup> day.

**F032 = 6** operates the SEC every 6<sup>th</sup> day

**F032 = 7** operates the SEC 1 day per week.

**F032 = 8** operates the SEC for a single 24HR event, non-repeating. Use this for testing or for “walk away” operations that need to run after you leave but not again.

Start Event Cycles allow the use of a Start Command (2-wire or 3-wire) **ONLY AFTER** the time of the Start Event has passed (logic state AND). In a 3-wire control system, this is similar to having an Enable switch in series with the Stop button. In a 2-wire control system, this is similar to having an Enable contacts in series with the Run contact. The Stop Button (or opening the Run contact) will always work to shut down the **VMX Series** starter. If F032 is set to anything other than 0, the normal Start – Stop functions will not longer work except as shown above.

Each Start Event is a timed operation based on the Process Timer settings in F030 above.



**Important:**

**If F030 = 0 (Disabled), the TCC will be ignored. So if F032 = 1-8 and F030 = 0, the starter will not operate!**

**Make sure that if F030 = 0, F032 = 0 as well.**

**F033 = Event #1 Start Time**

**Factory Setting = OFF**

**Range = 00:00 through 23:59, or OFF**

This function is used to select the start time for Event #1 in the TCC above. Once given a Start command after this event time, the starter will run the motor according to the selections entered into F030 and for the time entered into F031.

**F034 = Event #2 Start Time** Same as above, except for event #2

**F035 = Event #3 Start Time** Same as above, except for event #3

**F036 = Event #4 Start Time** Same as above, except for event #4

**F037 = Event #5 Start Time** Same as above, except for event #5

**F038 = Event #6 Start Time** Same as above, except for event #6

**F039 = Event #7 Start Time** Same as above, except for event #7

▪ **Note:**

Start Events are completely independent of one another, and can be programmed in any order. For instance, the Start Time in F037 can be earlier than the Start Time in F033. This allows easier alterations or additions of new Start Times after a unit is already installed.



| Fn#  | Function Type                          | Setting        | Function Description / Range                                                                                 | Timer Initiated By...                         | Motor Starts When... | Motor Stops When...                 | Timer Reset When...                  |
|------|----------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------|-----------------------------------------------|----------------------|-------------------------------------|--------------------------------------|
| F030 | Process Control Timer Mode             | 0              | No Process Control Timer operation (default setting from factory)                                            |                                               |                      |                                     |                                      |
|      |                                        | 1              | Minimum (Batch) Run Timer (works the same with or without TCC control)                                       | Start command and/or TCC                      | Start command        | Time Expires, Trip, or Stop Command | Time Expires + Stop command only     |
|      |                                        | 2              | Permissive Run Timer, without TCC (F032 = 0, "One Shot")<br>Permissive Run Timer, with TCC (F032 = 2 thru 8) | Start command<br>TCC Start Event only         | Start command        |                                     | Time Expires<br>Next SEC only        |
| F031 | Process Timer Value                    | Run Time Value | Timer value setting used by F030<br>Range: 1 – 9999 minutes (166.65 hours)                                   | ---                                           | ---                  |                                     | Per F030 setting                     |
| F032 | 24 hr / 7 day<br>Time Clock Controller | 0              | One-Shot, follows Start command only                                                                         | Start command                                 | Start command        | Per F030 setting                    | Per F030 setting                     |
|      |                                        | 1              | Loop the Start Even Cycle (SEC) daily                                                                        | 24hr Real Time Clock on day of program change |                      |                                     | Continuous unless program is changed |
|      |                                        | 2              | Loop the 24hr SEC every other day                                                                            |                                               |                      |                                     |                                      |
|      |                                        | 3              | Loop the 24hr SEC every 3 <sup>rd</sup> day                                                                  |                                               |                      |                                     |                                      |
|      |                                        | 4              | Loop the 24hr SEC every 4 <sup>th</sup> day                                                                  |                                               |                      |                                     |                                      |
|      |                                        | 5              | Loop the 24hr SEC every 5 <sup>th</sup> day                                                                  |                                               |                      |                                     |                                      |
|      |                                        | 6              | Loop the 24hr SEC every 6 <sup>th</sup> day                                                                  |                                               |                      |                                     |                                      |
|      |                                        | 7              | Loop the 24hr SEC one day per week                                                                           |                                               |                      |                                     |                                      |
|      |                                        | 8              | Single 24hr SEC, without repeating (until programmed again)                                                  |                                               |                      |                                     | Change of Program                    |
| F033 | Event #1                               | Start time     | 24hr TCC Start Time for Event #1                                                                             | F032 = 1-8                                    | Per F030 setting     | Per F030 setting                    | Continuous unless program is changed |
| F034 | Event #2                               | Start time     | 24hr TCC Start Time for Event #2                                                                             |                                               |                      |                                     |                                      |
| F035 | Event #3                               | Start time     | 24hr TCC Start Time for Event #3                                                                             |                                               |                      |                                     |                                      |
| F036 | Event #4                               | Start time     | 24hr TCC Start Time for Event #4                                                                             |                                               |                      |                                     |                                      |
| F037 | Event #5                               | Start time     | 24hr TCC Start Time for Event #5                                                                             |                                               |                      |                                     |                                      |
| F038 | Event #6                               | Start time     | 24hr TCC Start Time for Event #6                                                                             |                                               |                      |                                     |                                      |
| F039 | Event #7                               | Start time     | 24hr TCC Start Time for Event #7                                                                             |                                               |                      |                                     |                                      |

Chart APP 4.1 Process Timer and TCC Operations Logic Chart



- Note:**  
 These functions may interact with the Coast Down Lockout (F048), Stars-per-Hour Lockout (F049), Minimum Time Between Starts (F050), Auto-Reset (F052) and Restart Delay Time (F028) functions if enabled. Be sure to read and understand descriptions of those functions, then check settings before using the **Process Control Timer**.

**Example: Figure App 4.3**  
**Time Clock Controller with Minimum Run Timer**

An irrigation pump fed from a well with a single float level control needs to come on every other day at 5:30 PM, and run for ½ hour. If during that ½ hour the well level drops and shuts the pump down, the pump needs to restart when the well recovers and finish the ½ hour pump time.

**Set F030 to [0001] for Minimum Run Timer.**

This will ensure that when the well level recovers and resets the run command, the starter will finish the time sequence.

**Set F031 to [0030] (minutes)**

This is the Batch Time that ensures the proper amount of irrigation getting to the crop.

**Set F032 to [0002] for Every 2<sup>nd</sup> Day**

This will begin the Start Even Cycle on the day of programming and every other day from then on.

**Set F033 to [17.30]**

This is the 24HR time value representing 5:30 PM. At this time, every other day, the **VMX Series** starter will automatically start (provided the Stop float in the well is closed) and run for 30 minutes as programmed in F030.

If the pump needs to come on again at 7:00 PM, program F034 to **[19.00]**. If later on it is needed to come on at 6:00 AM as well, simply change any other unused start time, i.e. F038 to **[06.00]**. Even though this is Event #6 and the lower numbered events had later start times in the program, the starter will execute #6 on time in the next available cycle.

If the pump needs to come on every day, program F032 to **[0001]**.

**Example: Process Timer and TCC  
for Irrigation Pump**

| Press Key...          | Display Shows... | Means...                        |
|-----------------------|------------------|---------------------------------|
|                       | <b>F030</b>      | Starting at Function #30        |
| <b>READ ENTER</b>     | <b>0000</b>      | Default Setting of Function #30 |
| <b>↑</b>              | <b>0001</b>      | Set F030 = 1 Min. Batch Timer   |
| <b>READ ENTER</b>     | <b>End</b>       | Value Accepted (flashes once)   |
| <b>↑</b>              | <b>F031</b>      | Change to F031                  |
| <b>READ ENTER</b>     | <b>0000</b>      | Default Setting of Function #31 |
| <b>←</b> <b>↑</b> x 3 | <b>0030</b>      | Change Setting to 30 minutes    |
| <b>READ ENTER</b>     | <b>End</b>       | Value Accepted (flashes once)   |
| <b>↑</b>              | <b>F032</b>      | Change to F032                  |
| <b>READ ENTER</b>     | <b>0000</b>      | Default Setting of Function #32 |
| <b>↑</b> x 2          | <b>0002</b>      | Set to 2: Every 2nd Day         |
| <b>READ ENTER</b>     | <b>End</b>       | Value Accepted (flashes once)   |
| <b>↑</b>              | <b>F033</b>      | Change to F033                  |
| <b>←</b> <b>↑</b>     | <b>1730</b>      | Set to 17.30 (5:30 PM military) |
| <b>READ ENTER</b>     | <b>End</b>       | Value Accepted (flashes once)   |
|                       | <b>F033</b>      | Return to Function # Display    |

Cycle Control Power to Accept Changes

Figure App 4.3: Programming Timer Functions



- **Note:**  
If programming is entered AFTER the set time value, the TCC will wait until the next valid time before executing (i.e. if you entered the above example program changes at 5:35 PM, the pump would not come on automatically until 5:30 PM 2 days from now).

## Appendix 5 – External Over Load Relay Applications

Your **VMX Series** starter comes equipped with a very intelligent internal electronic overload protection system, and does not need an external Over Load Relay (OLR). There are instances however where external OLRs are needed or desired because of the application. These fall into three categories; Higher Level Protection systems, Redundant Backup applications and Special Motor applications.



▪ **Note:**

If the Decel Function is activated (F024), additional consideration must be put into determining how the starter is to operate in the event of an Over Load Trip. See Section 5.6.5 for issues regarding this application.

### **HIGHER LEVEL PROTECTION SYSTEMS**



Because of a desire for uniformity and/or operator familiarity in some facilities, Motor Protection Relays or other coordinated OEM protection systems may be used in lieu of the **VMX Series** protection (even though most of the features are the same or better). In these instances the **VMX Series** Over Load protection can simply be turned off, deferring protection to the external devices. Care should be taken however to ensure that the external device is properly wired into the starter control circuit to facilitate shutdown of the motor. The **VMX Series** provides a PTC input that can be wired to the NC aux contact of the external device so that a fault will still shut down the **VMX Series** and be annunciated on the display. See section 4.7.2.a for more details on using the PTC input.

### **REDUNDANT BYPASS STARTER APPLICATIONS:**

In some applications, it may be necessary to provide an independent means of starting and protecting the motor should the **VMX Series** starter become inoperable. If this were the case, the **Bypass Contactor** could be used for Across-the-Line (D.O.L) starting of the motor. The **VMX...BP** version with Integral Bypass Contactors is designed for that possibility, as long as the starter is properly selected when ordered. To do so, select the starter based upon the ATL (Across-the-Line) selection chart so that the contactor is rated for ATL duty instead of the normal Shunt Duty (see section 1.2.3 for Selection charts).

Under normal operations, the Bypass Contactor is controlled internally by the **VMX Series** PC board and an internal pilot relay. For redundant backup purposes however, terminals B1 and B2 of TB4 are provided for field connection of a dry contact closure in parallel to the pilot relay contact, allowing control even if the electronics are out of service. AC control power must still be applied to TB2 terminals A1 and A2, but no other electronics or power supplies need to be functioning. It is in this instance that an external OLR must be added to the motor power circuit and wired into that coil control circuit. TB4 is located in different areas of each frame size in the **VMX Series**. Refer to the following diagram for the location on your unit.


## VMX Bypass Control Terminal Location Diagrams



**Note:**

Use these terminals only when separate control of the Bypass Contactor is necessary

Bypass Control  
Terminals:  
210 – 550A with or  
without integral  
bypass



## Appendix 5 (cont.) External OL Relay Applications

### Across-the-Line (Direct-on-Line) Bypass

A suggested control schematic is shown below for using the **VMX ...-BP Series** rated for Across-the-Line Bypass with an External Overload:




Figure APP5.2: VMX Wiring for Across-the-Line Bypass Operation with External Overload Relay (Only the terminals necessary for this operation are shown)

#### In this example:

The Start / Run command (2-wire or 3-wire) energizes a control Relay "CR". If the selector Switch is in the "SS" (Soft Start) position, the contact of CR closes the 24VDC control signal to TB1, terminals 1 and 3 of the **VMX Series**, which begins ramping. When At-Speed status is reached, an internal Bypass Pilot Relay is used to close the Bypass Contactor. While in this mode, the **VMX Series** CPU provides full motor protection, even when the Bypass Contactor closes.

When the Selector Switch is placed in the "A-T-L" (Across-the-Line) position, a 2<sup>nd</sup> isolated contact of CR is used to close the circuit between B1 and B2 of TB4 which are internally connected in parallel to the Bypass Pilot Relay contact in the Bypass Contactor coil circuit. Since the **VMX Series** electronics may be out of service, an External Overload is added which only operates in this mode and protects the motor by dropping out the connection between B1 and B2.



#### Caution:

The circuit on TB-4 is at the same potential as the AC control voltage, but should not be directly connected to it. PC board damage may result.


## Appendix 5 (cont.) External OL Relay Applications

### SPECIAL MOTOR APPLICATIONS

#### Multiple Motors

When more than one motor is connected downstream from the **VMX Series** starter, the internal electronic overload protection cannot provide proper protection of the individual motors. Codes require the use of separate OLRs for each motor, which would need to be external devices.

In these instances the **VMX Series** Over Load protection should be turned off, deferring protection to the separate OLRs. Care should be taken to ensure that the External OLR is properly wired into the starter control circuit to facilitate shutdown of the motor. The **VMX Series** provides a PTC input that can be wired to the NC auxiliary contact of the external OLR so that a trip will still shut down the **VMX Series** and be annunciated on the display. Multiple OLRs would then be wired in series for the same effect. See **section 4.7.2.a** for details on using the PTC input.




## Appendix 5 (cont.) External OL Relay Applications

### SPECIAL MOTOR APPLICATIONS

#### 2S2W Motors

2 speed / 2 winding motor applications require a separate OLR sized for each set of windings. These would need to be external OLRs.



#### In this example:

The **VMX Series** is used ahead of an *existing* 2S2W starter, which already has separate OLRs for each speed. Dry Aux. contacts of the 2S2W starter are used to provide a Run command to the **VMX Series** so that all existing controls can be used. In addition, another dry Aux. of the Fast contactor is used to select Ramp 2. When started in Slow, Ramp 1 (default) is used. If started in Fast, different ramp settings are necessary so Ramp 2 is used. (See section 4.2.5.a for Dual Ramp info.)

**Either OLR will trip the VMX Series, which will display [ Ptc] and light the "Overload" LED.**

## Appendix 6 - Soft Starter Settings Record

The following chart may be used to record the changes made to the factory settings.

| Fn #   | Group                       | Function Description                                                                        | Adjustment / Display Range                                                                                        | Setting Increments | Factory Setting | Setting | Setting |
|--------|-----------------------------|---------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|--------------------|-----------------|---------|---------|
| F001   | Motor and Overload Info.    | Motor Nameplate FLA<br>FLA must be programmed for starter to function.                      | 50-100% of Max Amp Rating.<br>Upper limit of range automatically adjusts downward as Service factor is increased. | 1 amp              | 0               |         |         |
| F002   |                             | Motor Nameplate Service Factor                                                              | 1.00 - 1.30 SF                                                                                                    | 0.05               | 1.0 SF          |         |         |
| F003   |                             | Overload Class During Start                                                                 | NEMA / UL Class 5 - 20                                                                                            | 5                  | Class 10        |         |         |
| F004   |                             | Overload Class During Run                                                                   | NEMA / UL Class 5 - 30                                                                                            | 5                  | Class 10        |         |         |
| F005   |                             | Overload Reset                                                                              | 0 = Manual<br>1 = Auto<br>2 = Disabled Overload                                                                   | 1                  | 0<br>(Manual)   |         |         |
| F006-9 |                             | Reserved for factory use                                                                    |                                                                                                                   |                    |                 |         |         |
| F010   | Starting and Stopping Modes | Ramp Type Selection<br>VR = Voltage Ramp<br>CR = Current PID Ramp<br>1 = Ramp 1, 2 = Ramp 2 | Setting 1 = VR1 + VR2<br>Setting 2 = CR1 + CR2<br>Setting 3 = VR1 + CR2<br>Setting 4 = CR1 + VR2                  | 1                  | 1<br>VR1+VR2    |         |         |
| F011   |                             | Initial Torque (VR) of Ramp 1                                                               | 0-100% Line Voltage                                                                                               | 1%                 | 60%             |         |         |
| F012   |                             | Initial Torque (CR) of Ramp 1                                                               | 0-600% Motor Current                                                                                              | 1%                 | 200%            |         |         |
| F013   |                             | Accel Ramp Time of Ramp 1                                                                   | 1-120 seconds                                                                                                     | 1 second           | 10 seconds      |         |         |
| F014   |                             | Max Current Limit of Ramp 1                                                                 | 200 - 600% Motor Current                                                                                          | 1%                 | 350%            |         |         |
| F015   |                             | Initial Torque (VR) of Ramp 2                                                               | 0-100% Line Voltage                                                                                               | 1%                 | 60%             |         |         |
| F016   |                             | Initial Torque (CR) of Ramp 2                                                               | 0-600% Motor Current                                                                                              | 1%                 | 200%            |         |         |
| F017   |                             | Accel Ramp Time of Ramp 2                                                                   | 1-120 seconds                                                                                                     | 1 second           | 10 seconds      |         |         |
| F018   |                             | Max Current Limit of Ramp 2                                                                 | 200 - 600% Motor Current                                                                                          | 1%                 | 350%            |         |         |
| F019   | Jog Modes                   | Voltage Jog                                                                                 | 5 – 100% Line Voltage                                                                                             | 1%                 | 50%             |         |         |
| F020   |                             | Time of Voltage Jog                                                                         | 1 – 20 Seconds                                                                                                    | 1 second           | 10 seconds      |         |         |
| F021   |                             | Current Jog                                                                                 | 100 – 500% Motor Current                                                                                          | 1%                 | 150%            |         |         |
| F022   | Kick Mode                   | Kick Start Voltage                                                                          | 0 = Disabled, or<br>10 - 100% Line Voltage                                                                        | 1%                 | 0<br>Disabled   |         |         |
| F023   |                             | Kick Start Time                                                                             | 0.1 - 2 Seconds                                                                                                   | 0.1second          | 0.8 sec         |         |         |

**Appendix 6 (cont.) Soft Starter Settings Record**

| Fn # | Group                                            | Function Description                                                                                                                                                         | Adjustment / Display Range                                                                                                                                                                                                                                                                                                                                                                                                  | Setting Increments | Factory Setting | Setting | Setting |
|------|--------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|-----------------|---------|---------|
| F024 | <b>Pump Flex Decel Mode</b>                      | Pump Flex Control / Deceleration Ramp                                                                                                                                        | 0 = Disabled (coast to stop)<br>1 = Enabled, except after OL trip<br>2 = Enabled, continued Decel even if there is an OL trip                                                                                                                                                                                                                                                                                               | 1                  | 0<br>Disabled   |         |         |
| F025 |                                                  | Begin Decel Level (BDL), Immediate Drop Down Torque                                                                                                                          | 0 - 100 % of Output Voltage                                                                                                                                                                                                                                                                                                                                                                                                 | 1%                 | 60%             |         |         |
| F026 |                                                  | Decel Shut Off Voltage                                                                                                                                                       | 0 to (BDL minus 1)% Voltage                                                                                                                                                                                                                                                                                                                                                                                                 | 1%                 | 30%             |         |         |
| F027 |                                                  | Decel Ramp Time                                                                                                                                                              | 1 – 60 Seconds                                                                                                                                                                                                                                                                                                                                                                                                              | 1 second           | 10 seconds      |         |         |
| F028 | <b>Restart</b>                                   | Restart Delay Time (Sequential Start Delay)                                                                                                                                  | 0 = Disabled, or<br>1-999 seconds after a Power Loss (Status can be read in F054)                                                                                                                                                                                                                                                                                                                                           | 1 second           | 0<br>Disabled   |         |         |
| F029 |                                                  | Reserved for Factory Use                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                             |                    |                 |         |         |
| F030 | <b>Run Timer and Time Clock Controller Modes</b> | Process Control Timer Selection                                                                                                                                              | 0 = Disabled (No timer operation)<br>1 = Minimum Batch Run Timer<br>2 = Permissive Run Timer                                                                                                                                                                                                                                                                                                                                | 1                  | 0<br>Disabled   |         |         |
| F031 |                                                  | Run Timer Time for use in F030 above                                                                                                                                         | 1-9999 minutes after a Start Command or Start Event from TCC                                                                                                                                                                                                                                                                                                                                                                | 1                  | 1               |         |         |
| F032 |                                                  | 24hr Time Clock Controller (TCC) Start Event Mode.<br><br>Chose from "One Shot" or 1 to 7 "Start Events" in F033 – F039<br><br>Run time for this mode comes from F030 above. | Start Event Cycle (SEC) Settings<br>0 = One Shot: Start Event comes from Start command only<br>1 = Loop SEC every day<br>2 = Loop SEC every 2 <sup>nd</sup> day<br>3 = Loop SEC every 3 <sup>rd</sup> day<br>4 = Loop SEC. every 4 <sup>th</sup> day<br>5 = Loop SEC. every 5 <sup>th</sup> day<br>6 = Loop SEC. every 6 <sup>th</sup> day<br>7 = Loop SEC one day per week<br>8 = Single 24hr SEC (until programmed again) | 1                  | 0<br>One Shot   |         |         |
| F033 |                                                  | Start Event #1 Start Time                                                                                                                                                    | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                  | 1                  | OFF             |         |         |
| F034 |                                                  | Start Event #2 Start Time                                                                                                                                                    | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                  | 1                  | OFF             |         |         |
| F035 |                                                  | Start Event #3 Start Time                                                                                                                                                    | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                  | 1                  | OFF             |         |         |
| F036 |                                                  | Start Event #4 Start Time                                                                                                                                                    | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                  | 1                  | OFF             |         |         |
| F037 |                                                  | Start Event #5 Start Time                                                                                                                                                    | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                  | 1                  | OFF             |         |         |
| F038 |                                                  | Start Event #6 Start Time                                                                                                                                                    | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                  | 1                  | OFF             |         |         |
| F039 |                                                  | Start Event #7 Start Time                                                                                                                                                    | 00:00-23:59 (hh:mm) or OFF                                                                                                                                                                                                                                                                                                                                                                                                  | 1                  | OFF             |         |         |

| Fn # | Group                                   | Function Description                             | Adjustment / Display Range                                             | Setting Increments | Factory Setting          | Setting | Setting |
|------|-----------------------------------------|--------------------------------------------------|------------------------------------------------------------------------|--------------------|--------------------------|---------|---------|
| F040 | Current and Ground Fault Protection     | Current Imbalance Trip                           | 0 = Disabled, or<br>5 - 30% imbalance                                  | 1%                 | 0<br>Disabled            |         |         |
| F041 |                                         | Current Imbalance Trip Delay                     | 1 - 20 seconds                                                         | 1 second           | 2<br>seconds             |         |         |
| F042 |                                         | Over Current Trip                                | 0 = Disabled, or<br>100 - 300% of motor FLA                            | 1%                 | 0<br>Disabled            |         |         |
| F043 |                                         | Over Current Trip Delay                          | 1 - 20 seconds                                                         | 1 second           | 1 second                 |         |         |
| F044 |                                         | Under Current Trip                               | 0 = Disabled, or<br>10 - 90% of motor FLA                              | 1%                 | 0<br>Disabled            |         |         |
| F045 |                                         | Under Current Trip Delay                         | 1 - 60 seconds                                                         | 1 second           | 2<br>seconds             |         |         |
| F046 |                                         | Ground Fault Trip                                | 0 = Disabled, or<br>5 - 90% of CT ratio from Fn 74                     | 1%                 | 0<br>Disabled            |         |         |
| F047 |                                         | Ground Fault Trip Delay                          | 1 - 60 seconds                                                         | 1 second           | 2<br>seconds             |         |         |
| F048 | Lockouts, Reset and Internal Protection | Coast Down (Back Spin)<br>Lockout Timer          | 0 = Disabled, or 1 - 60 minutes                                        | 1 minute           | 0<br>Disabled            |         |         |
| F049 |                                         | Maximum Starts per Hour                          | 0 = Disabled, or 1 – 10 starts                                         | 1                  | 0<br>Disabled            |         |         |
| F050 |                                         | Minimum Time Between<br>Starts                   | 0 = Disabled, or 1 - 60 minutes                                        | 1 minute           | 0<br>Disabled            |         |         |
| F051 |                                         | Internal Protection Settings                     | 1 – 255<br>See 5.6.9.a                                                 | 1                  | 127<br>Enable all        |         |         |
| F052 |                                         | Auto Reset<br>on Selected Faults                 | Fault Preferences 1 – 12<br>See 5.6.9.b Fault Reset Selection<br>Table | 1                  | 4:<br>Phase<br>Loss only |         |         |
| F053 |                                         | Auto Reset Attempts                              | 0 = Disabled, or 1-10 attempts                                         | 1                  | 1                        |         |         |
| F054 |                                         | Restart Delay Time Value<br>Readout (for F028)   | 0-999 Minutes                                                          | 1                  | 0                        |         |         |
| F055 |                                         | Coast Down Timer Value<br>for F048               | 1-3600 Seconds                                                         | 1                  | 0                        |         |         |
| F056 |                                         | Starts Per Hour Timer Value<br>for F049          | 1-3600 Seconds                                                         | 1                  | 0                        |         |         |
| F057 |                                         | Starts Per Hour<br>For F049                      | 1-10 Starts                                                            | 1                  | 0                        |         |         |
| F058 |                                         | Time Value Between Starts<br>for F050            | 1-3600 Seconds                                                         | 1                  | 0                        |         |         |
| F059 |                                         | Thermal Capacity to Start<br>for F005            | 0-100 % Thermal Capacity                                               | 1                  | 0                        |         |         |
| F060 | Output Relays                           | Aux Relay 1 setting                              | Operation # 1 – 27: see<br>"Aux. Relay Settings Chart"                 | 1                  | 1                        |         |         |
| F061 |                                         | Aux Relay 2 setting                              | Operation # 1 – 27: see<br>"Aux. Relay Settings Chart"                 | 1                  | 2                        |         |         |
| F062 |                                         | Aux Relay 3 setting                              | Operation # 1 – 27: see<br>"Aux. Relay Settings Chart"                 | 1                  | 16                       |         |         |
| F063 |                                         | Aux. Relay Delay Timer<br>(for Operations 22-26) | 0 (Disabled), or 1-999 seconds                                         | 1 second           | 0<br>No Delay            |         |         |
| F064 |                                         | Reserved for factory use                         |                                                                        |                    |                          |         |         |

### Appendix 6 (cont.) Soft Starter Settings Record

| Fn #        | Group           | Function Description                | Adjustment / Display Range                                                                                       | Setting Increments | Factory Setting                | Setting | Setting |
|-------------|-----------------|-------------------------------------|------------------------------------------------------------------------------------------------------------------|--------------------|--------------------------------|---------|---------|
| F065        | Communications  | Communications                      | 0 = Disabled<br>1 = Enabled (11Bit)<br>2 = Enabled (10Bit)                                                       | 1                  | 0                              |         |         |
| F066        |                 | Baud Rate                           | 4.8, 9.6 and 19.2 KB                                                                                             | 3 rates            | 9.6 KB                         |         |         |
| F067        |                 | Modbus Address                      | 1 - 247                                                                                                          | 1                  | 1                              |         |         |
| F068        |                 | Remote Starter Control              | 0 = Disabled<br>1 = Enabled w/ Start button<br>2 = Enabled w/o Start button<br>3 = Enabled by Jog / Remote Input | 1                  | 0                              |         |         |
| F069        |                 | Reserved for factory use            |                                                                                                                  |                    |                                |         |         |
| F070        | System Settings | Parameter Lock<br>Customer Password | 0 – 999<br>0 = Disabled<br>Any Other Numbers = Password                                                          | 1                  | 0<br>(displays encrypted code) |         |         |
| F071        |                 | System Clear / Reset                | 0 = Disabled<br>1 = Clear THR and Lockout Timers<br>2 = Reset to Factory Default Settings                        | 1                  | 0                              |         |         |
| F072        |                 | Reserved for Factory Use            |                                                                                                                  |                    |                                |         |         |
| F073        |                 | Frame Rating                        | 18 - 550                                                                                                         | 1                  | By Model<br>(defaults to 48)   |         |         |
| F074        |                 | CT Value                            | 40-1200                                                                                                          | 5                  | By Model<br>(defaults to 40)   |         |         |
| F075        |                 | Year                                | 2000 - 2047                                                                                                      | 1 year             | 2000                           |         |         |
| F076        |                 | Month                               | 1 - 12                                                                                                           | 1 Month            | 1                              |         |         |
| F077        |                 | Day                                 | 1 - 31                                                                                                           | 1 Day              | 1                              |         |         |
| F078        |                 | Hour                                | 0 - 23                                                                                                           | 1 Hour             | 0                              |         |         |
| F079        |                 | Minute                              | 0 - 59                                                                                                           | 1 Minute           | 0                              |         |         |
| F080        |                 | Second                              | 0 - 59                                                                                                           | 1 Second           | 0                              |         |         |
| F081        |                 | Revision #                          | -                                                                                                                | -                  | Factory Setting                |         |         |
| F082 – F084 |                 | Reserved for factory use            |                                                                                                                  |                    |                                |         |         |

**Appendix 6 (cont.) Soft Starter Settings Record**

| Fn # | Group                      | Function Description                     | Adjustment / Display Range                                      | Setting Increments | Factory Setting | Setting | Setting |
|------|----------------------------|------------------------------------------|-----------------------------------------------------------------|--------------------|-----------------|---------|---------|
| F085 | Fault History and Run Data | Fault History #1, Latest Fault           | 0 = No fault history, or<br>Fault # 1 - 27: see Fault code list | 1                  | 0               |         |         |
| F086 |                            | Time Stamp, Fault #1<br>Based on F078-80 | 00.00-23.59 (hh.mm)<br>[hh = 00-23; mm = 00-59]                 | 00.01              | 00.00           |         |         |
| F087 |                            | Date Stamp, Fault #1<br>Based on F076-77 | 01.01 – 12.31 (MM.DD)<br>[MM = 01-12; DD = 01-31]               | 00.01              | 01.01           |         |         |
| F088 |                            | Fault History #2, Previous<br>Fault      | 0 = No fault history, or<br>Fault # 1 - 27: see Fault code list | 1                  | 0               |         |         |
| F089 |                            | Time Stamp, Fault #2                     | 00.00-23.59 (hh.mm)<br>[hh = 00-23; mm = 00-59]                 | 00.01              | 00.00           |         |         |
| F090 |                            | Date Stamp, Fault #2                     | 01.01 – 12.31 (MM.DD)<br>[MM = 01-12; DD = 01-31]               | 00.01              | 01.01           |         |         |
| F091 |                            | Fault History #3, Oldest Fault           | 0 = No fault history, or<br>Fault # 1 - 27: see Fault code list | 1                  | 0               |         |         |
| F092 |                            | Time Stamp, Fault #3                     | 00.00-23.59 (hh.mm)<br>[hh = 00-23; mm = 00-59]                 | 00.01              | 00.00           |         |         |
| F093 |                            | Date Stamp, Fault #3                     | 01.01 – 12.31 (MM.DD)<br>[MM = 01-12; DD = 01-31]               | 00.01              | 01.01           |         |         |
| F094 |                            | Run Time, Hours                          | 000.0 – 999.9 hours                                             | 0.1 hours          | 0               |         |         |
| F095 |                            | Run Time,<br>1000 Hour Overflow          | 0000 – 9999 thousand hours                                      | 1 k-hour           | 0               |         |         |
| F096 |                            | Run Cycle Counter                        | 0000 – 9999 times                                               | 1 times            | 0               |         |         |
| F097 |                            | Run Cycle Counter<br>10K overflow        | 0000 – 9999 10 thousand times                                   | 1 10k<br>times     | 0               |         |         |

## **Warranty information.**

**1 Year Warranty:** Phasetronics Inc., dba Motortronics, (hereinafter “Company”) warrants the **VMX Series** products to be free from defects in material and/or workmanship for a period of one (1) year from the date of sale, or a maximum of 18 months from the date of manufacture (if no sales records are available) as indicated by the unit’s date code. The Company reserves the right to repair or replace any malfunctioning units or sub assemblies under warranty at the Company’ sole option. Warranty repairs may be performed at the Company’s facility, in the field by a factory-authorized technician, or by the customer only with prior approval and at the specific direction of the Company’s Technical Services personnel. During the 1 year period, malfunctions of the control boards will be dealt with by replacement of the Modular Control Assembly (MCA), which contains the User Interface Panel, Digital Control Unit, Bypass control (if any) and Communications Interface. The MCA is designed to be replaced quickly without the need for tools (plug-in), and as such will constitute the majority of warranty replacements.

### **Warranty Service Procedure:**

In the event that warranty service becomes necessary, contact the distributor where the starter was purchased, or Motortronics Technical Services department directly at (727) 573-1819. Be prepared to provide the complete Model number, Serial Number, date and place of purchase. It is also helpful to know the date of initial commissioning. When Technical Services has determined the nature of the problem and that sending replacement parts or assemblies can repair it, they will require a purchase order for replacement parts and issue a Return Material Authorization (RMA) for the defective parts or assemblies. If any components or assemblies are received at the factory without the proper RMA documentation, the shipment(s) will be refused.

When the replacement parts are received and evaluated at the factory, any warranty determination will result in an offsetting credit being issued for the replacement parts already sent out. If the unit is not needed for immediate operation, an alternative is to have the Technical Services representative provide an RMA for the components, and they will be evaluated and repaired at the factory, and returned. In either circumstance, freight/shipping costs are the responsibility of the purchaser.

### **Responsibility:**

Company is not responsible for the misuse or misapplication of its products, intentional or otherwise. Improper application, installation, failure to provide safety devices or protective measures, or operation above its ratings, and failure to properly maintain or service products are all beyond the control and responsibility of the Company. Under no circumstances shall the Company be liable for loss of profits, indirect, incidental, special, consequential or other similar damages arising out of the misuse, misapplication or failure to maintain the Company’s products.

SCR power devices used in the **VMX Series** (and all other solid state motor control products) are covered under warranty only when it has been determined by the Company that a failure of another system within the MCA or firing board circuit has directly caused damage to the SCRs. Although every effort is provided to prevent SCR damage, it can still occur as a result of circumstances beyond the control of the Company. Improper starting conditions such as under sizing, rapid duty cycling and improper settings, or external power problems such as lightning strikes, capacitor switching, shorted motor windings or locked rotor currents can all cause damage to SCRs under the wrong circumstances. Failures under those conditions are not covered under warranty.