

☐

I'm not robot


reCAPTCHA

Continue

Belkin n600 extender setup guide

Belkin n600 setup. Belkin n600 firmware. Belkin setup router.



TABLE OF CONTENTS
HARDWARE INFORMATION
1. What is the Belkin N600 Dual-Band Plug-In Wi-Fi Router, F9K1121?
2. What is included in the Belkin F9K1121 package?
3. What is the warranty period of the Belkin F9K1121?
4. What are the parts of the Belkin F9K1121?
5. Which wireless connection standards and frequencies are supported by the Belkin F9K1121?
SETUP AND INSTALLATION
1. What are the requirements in setting up the Belkin F9K1121?
2. How do I set up the Belkin F9K1121?
CONNECTIVITY
1. What wireless security modes does the Belkin F9K1121 support?
2. How do I connect a wireless device to the wireless network of the Belkin F9K1121?
17872599708.pdf
ADVANCED CONFIGURATION
1. How do I update the firmware of the Belkin F9K1121?
2. Does the Belkin F9K1121 support the Guest Access feature?
pdf of fluid mechanics by rs khurmi
TROUBLESHOOTING
1. How do I restore the Belkin F9K1121 to its factory settings?
2. What should I do when I can't connect to the Internet wirelessly and my network name is not listed in Available Networks?
3. What should I do when my wireless network performance is slow, inconsistent, suffers from weak signal or is having difficulty maintaining a VPN connection?
One (1) Belkin F9K1121
One (1) Ethernet cable
One (1) Network Information Card (attached to router)
Quick Setup Guide (Setup CD)
Port - one (1) Ethernet port
Status LED
Wi-Fi Protected Setup (WPS™) - LED and button
Reset button
Antenna - two (2) built-in antennas
Bottom Plug - for power
A broadband Internet connection such as a cable or DSL modem with RJ45 (Ethernet) port
At least one (1) computer with an installed network interface adapter
TCP / IP networking protocol installed on each computer
RJ45 Ethernet networking cable
Web browser: Internet Explorer® 8 or higher, Firefox®, Chrome™, or Safari®
Minimum 1 GHz processor and 512 MB RAM or a device running iOS or Android™ operating systems
Operating System: Windows® XP SP3 or higher, Windows Vista®, or Windows® 7; or OS X® version 10.5 or above
Step 1: Go to your device settings or adapter settings if you are using a laptop and Enable the Wi-Fi setting.
Step 2: Scan the wireless networks in the area and select the wireless network name (SSID) of your router. The router will automatically check for a newer firmware version every time you log into the dashboard and alert you with a message at the top of the screen if there is an update available. You can choose to download the new version or ignore it. You will see a series of prompts notifying you that the firmware is about to be updated. IMPORTANT: Do not disconnect the power from the router during the update process as it could cause the system to fail. Updating the router's firmware via the web-based setup page
Follow the steps below on how to update your router's firmware using its web-based setup page.
Step 1: Locate and download the firmware file from the Belkin Support Site. For further instructions on how to download the firmware, click here.
NOTE: It is highly recommended to save your firmware in the Desktop to help you easily locate the file whenever you need it.
You may also rename the file for easier identification.
Step 2: Using a computer connected to your router's wireless network, open a web browser and enter " " or " " in the Address bar. Then press [Enter].
Step 3: Select Advanced Settings then click on Firmware Update.
Step 4: Click the Choose File button to search for the firmware you saved previously.
Step 5: Select the firmware file then click the Open. This will take you back into the router's web-based setup page.
Step 6: Click the Update button.
Step 7: A prompt asking, Are you sure you want to continue with upgrading? will appear. Click OK.
Step 8: A second prompt will open telling you the router will not respond during the upgrade and warning you not to remove the power supply from the router. Click OK again.
NOTE: Wait for the upgrade process to complete. Do NOT turn OFF or reboot the router during the upgrade process. Verify that your router is ON and the front panel light shows solid blue.
If you are far from the router, move closer to see if your device is out of the wireless network range.
Using a computer attached to the router via a network cable, open the router's web-based setup page by entering " " or " " and ensure that Broadcast SSID is ON. This setting is found on the Channel and SSID page.
Obstructions such as walls, fixtures, furniture and metal appliances
Wireless signal interference caused by other wireless networks using the same frequency such as baby monitors, microwave ovens, etc.
NOTE: Connection speed may decrease as you move farther from the router.
Troubleshooting Tips
In order to determine if wireless issues are related to distance, it is recommended to temporarily move the computer within 10 feet from the router if possible.
You may also change the wireless channel of your router. This will resolve issues of wireless interference to improve the performance and reliability of your network.
Was this support article useful?
Additional Support Questions? Search Again