



# ***Serpentine II & Serpentine VI Air Heaters***

**FOR SAFETY & LONG HEATER LIFE, CAREFULLY READ THIS MANUAL BEFORE USE.**



## **Safety**



### **SHOCK HAZARD!**

Only qualified individuals should install this heater and related controls.  
Follow all applicable electrical codes and use proper wiring.



### **BURN/FIRE/EXPLOSION HAZARD!**

Do not use in hazardous environments, and/or near explosive or reactive gases, or combustible materials. Avoid contact with the heater or exit accessories during or soon after operation. **DO NOT USE NEAR VOLATILE OR COMBUSTIBLE MATERIALS.**

## Description

Compact and efficient process air/inert gas heater, capable of producing exit temperatures up to 1400°F (760°C) with standard elements, and up to 1500°F (815°C) with the “2-Stage” elements. The heater unit consists of two parts - a replaceable serpentine-coil electric heater element, which fits into a stainless steel “triple-pass” exchanger housing. This special housing uses the incoming air to cool the outer shell prior to passing through the heater element. This not only minimizes radiant heat losses but provides a cool outer shell, to minimize burn injury for operators who accidentally contact the heater. Two heater sizes are available; the Serpentine II (wattages from 2000 to 3600W) and the Serpentine VI (wattages from 5000 to 8000W). If operated correctly, element life will be greater than 5000 hours.

## Limited Warranty

OSRAM SYLVANIA warrants that all products to be delivered hereunder will be free from defects in material and workmanship at the time of delivery. OSRAM SYLVANIA's obligation under this warranty shall be limited to (at its option) repairing, replacing, or granting a credit at the prices invoiced at the time of shipment for any of said products. This warranty shall not apply to any such products which shall have been repaired or altered, except by OSRAM SYLVANIA, or which shall have been subjected. OSRAM SYLVANIA shall be liable under this warranty only if (A) OSRAM SYLVANIA receives notice of the alleged defect within sixty (60) days after the date of shipment; (B) the adjustment procedure hereinafter provided is followed, and (C) such products are, to OSRAM SYLVANIA's satisfaction, determined to be defective.

THE WARRANTY SET FORTH IN THE PRECEDING PARAGRAPH IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR OF MERCHANTABILITY.

The information contained in this manual is based on data considered to be true and accurate. Reasonable precautions for accuracy has been taken in the preparation of this manual, however OSRAM SYLVANIA assumes no responsibility for any omissions or errors, nor assumes any liability for damages that may result from the use of the product in accordance with the information contained in this manual.

Please direct all warranty/repair requests or inquiries to the place of purchase, and provide the following information, in writing:

- (A) Order number under which products were shipped
- (B) Model/Serial Number of product
- (C) Reason for rejection

**PRODUCTS CAN NOT BE RETURNED TO OSRAM SYLVANIA WITHOUT AUTHORIZATION.**

Replacement, repair, or credit for products found to be defective will be made by the place of purchase. All products found to be not defective will be returned to the Buyer; transportation charges collect or stored at Buyers expense.

## Heater Models and Parts List

### Serpentine II Elements (used with Housing/Exchanger Part #F029763)

Part Number	Maximum Watts	Maximum Volts	Maximum Amps	Maximum Pressure (PSI)	Maximum Temperature
<b>F029765</b>	2000	240	8.3	25	1400°F / 760°C
<b>F029766</b>	2800	240	11.7	25	1400°F / 760°C
<b>F029767</b>	3600	240	15.0	25	1400°F / 760°C
<b>F060418</b>	3600 (2-Stage)	240	15.0	25	1500°F / 815°C

### Serpentine VI Elements (used with Housing/Exchanger Part #F057088)

Part Number	Maximum Watts	Maximum Volts	Maximum Amps	Maximum Pressure (PSI)	Maximum Temperature
<b>F040291</b>	5000	240	20.8	25	1300°F / 705°C
<b>F040292</b>	6000	240	25.0	25	1400°F / 760°C
<b>F061429</b>	6000 (2-Stage)	240	25.0	25	1500°F / 815°C
<b>F056548</b>	8000	240	33.3	25	1400°F / 760°C

## Specifications

Maximum Inlet Pressure	25 PSI (1.7 BAR)*
Maximum Inlet Air Temperature	200°F (93°C)
Maximum Exit Air Temperature	1400°F (760°C) Single Stage 1500°F (815°C) Two-Stage <i>(see page 8 for Performance Curves)</i>
Minimum Airflow	60 SCFH (28.3 SLPM) for Serpentine II models 120 SCFH (56.6 SLPM) for Serpentine VI models

## General Information

### **Environmental Conditions:**

Ambient Temperature	32°F to 104°F (0°C to 40°C)
Humidity	0% to 95% R.H.

### **Ventilation:**

Use in a well-ventilated area away from excess dust, dirt, and moisture.

### **Cleaning:**

With unit OFF and unplugged, exterior surfaces may be wiped clean using a dry, lint-free cloth.


### **Protective Earthing:**

Each heater comes with a convenient grounding stud and hardware located at the inlet of the heater for protective means of earthing.

## Dimensions/Mounting

**NOTE:** The inlet side of the heater is located where the leads/power feedthrus come out of the housing. Failure to install the heater in its proper orientation can result in heater damage and is not covered under the manufacturer's warranty.

### Heater Cartridge:




#### Serpentine II Elements

Part Number	A	B	C
<b>F029765</b> 2.0kW	7.69" (195mm)	7.69" (195mm)	0.63" (16mm)
<b>F029766</b> 2.8kW			
<b>F029767</b> 3.6kW			
<b>F060418</b> 3.6kW 2-Stage	8.13" (206mm)	8.13" (206mm)	0.63" (16mm)

#### Serpentine VI Elements

Part Number	A	B	C
<b>F040291</b> 5.0kW	10.25" (260mm)	10.88" (276mm)	1.25" (32mm)
<b>F040292</b> 6.0kW			
<b>F061429</b> 6.0kW 2-Stage			
<b>F056548</b> 8.0kW			

### Housing/Exchanger:



Part Number	A	B	C	D	E	Air Inlet FNPT
Serpentine II <b>F029763</b>	9.63" (245mm)	0.70"Ø (18mm)	1.50"Ø (38mm)	1.00" (25mm)	0.38" (9.5mm)	0.375" (9.5mm)
Serpentine VI <b>F057088</b>	12.38 (314mm)	1.38"Ø (35mm)	2.12"Ø (54mm)	1.00" (25mm)	0.50" (13mm)	0.750" (19mm)

## Precautions

1. Use filtered air. Avoid grease, oil, or oil vapors, corrosive or reactive gases which will damage heater.
2. Operate at safe voltages as shown on the Performance Curves (see page 8). Excess voltage will cause premature failure.
3. Always have sufficient airflow through the heater before applying power. Otherwise element will overheat very quickly, and burn out. NOTE: A thermocouple cannot detect temperatures if there is no flow – turn on flow before applying power, even when a controller with a thermocouple is being used.
4. Use phase angle fired power controllers. On-off controllers may shorten heater life (or burnout element).
5. For closed-loop control, use exposed junction type “K” thermocouple within one inch of the heater exit.
6. For closed-loop control, use a temperature controller with a fast sampling period (500ms) and minimal overshoot.


## Installation

**CAUTION: DO NOT Operate Heater Without Air**

- **WARNING:** THE INLET AIR/GAS SIDE OF THE HEATER IS LOCATED CLOSEST TO WHERE THE POWER FEED-THRU CONNECTIONS ARE MADE. INSTALLING THE HEATER IN THE WRONG ORIENTATION WILL DAMAGE THE HEATER AND CAN CREATE ADDITIONAL HAZARDS AS A RESULT.
1. Securely mount the heater
  2. Connect the ground wire to the green grounding nut on the housing assembly.
  3. Connect the air source to the heater.
  4. If a thermocouple is used, ensure that it is located within one inch from the heater exit. Osram-Sylvania recommends using an exposed junction type K thermocouple like Part # 039272. Contact Osram-Sylvania for specifications.



## Typical Wiring for 1Ø Heater with Closed Loop Control



## Operation (with Heater)

### START-UP

1. Reference the Performance Curves section (see page 8) for operational parameters before attempting to operate heater(s).
2. Turn on air and set pressure and/or flow to desired operating level.
3. If using a closed loop system, turn on power to the temperature and power controller, then set the desired temperature on the temperature controller. If using an open loop system, increase power to the heater through the power controller until the desired temperature is attained.

### SHUT-DOWN


1. Turn off Main Power circuit breaker, or disconnect MAIN POWER line.
2. Allow air to continue to flow for a minimum of 1 minute or until exit air temperature is 300°F (150°C) or less for safety. Continue airflow longer as necessary to prevent burn hazard to personnel.
3. Turn off air to the system.

## Performance Curves

The attached performance curves show exit air temperatures at different airflows and voltages. Pressure readings (longer dashed lines) are measured at the inlet to the heater with no entrance or exit restrictions. Solid lines indicate safe, normal-life operating conditions. The shorter dash lines indicate marginal, shorter-life operating conditions leading to premature burnout. With a known flow (or pressure) at the heater entrance, follow the flow (or pressure) line across until it meets the desired temperature curve. Drop a line straight down to intersect the x-axis. This point, along the "Heater volts – true RMS" axis, represents the voltage required to generate the desired exit air temperature at the chosen flow rate (inlet pressure).

### Serpentine II Elements

**Serpentine II Maximum Performance  
 with Baffled Housing (#F029763)**




Rev: 04/12







Serpentine II Performance Curve - 2.0kW  
with Baffled Housing (#F029763)



Serpentine II Performance Curve - 2.8kW  
with Baffled Housing (#F029763)




**Serpentine II Performance Curve - 3.6kW  
 with Baffled Housing (#F029763)**



Rev: 04/12



**Serpentine II Performance Curve - 3.6kW (2-Stage)  
 with Baffled Housing (#F029763)**




Rev: 04/12





Serpentine VI Elements

Serpentine VI Maximum Performance  
with Baffled Housing (#F057088)




Rev: 04/12







Serpentine VI Performance Curve - 5kW  
with Baffled Housing (#F057088)




Serpentine VI Performance Curve - 6kW  
with Baffled Housing (#F057088)



**Serpentine VI Performance Curve - 6kW (2-Stage)  
 with Baffled Housing (#F057088)**



**Serpentine VI Performance Curve - 8kW  
 with Baffled Housing (#F057088)**



## Troubleshooting and Replacing Heaters


1. Note that "TYPICAL" Element Life is APPROXIMATELY 5000 hours. This is based on heater element operating at or below temperatures shown on PERFORMANCE CURVE. In addition to normal end of life, elements can fail due to mechanical damage, or problems with the control system.
2. If an element has failed prematurely, it should be inspected to determine the cause of the element failure.
3. When replacing or troubleshooting heaters, turn off power to the system and be sure to follow lock-out/tag-out procedures.
  - a. For Troubleshooting Heater
    - i.) Use multi-meter to check continuity between:
      1. Power terminals H1-H2
      2. Thermocouples positive (+ yellow) to negative (- red)
    - ii.) If there is continuity on all above tests, check system wiring:
      1. Crossed thermocouple wires.
      2. Reversed thermocouple wire polarity – note RED is NEGATIVE.
      3. Verify inlet air temp is below set point on INLET TEMP controller.
    - iii.) If there is no continuity on any test, then contact your local SYLVANIA representative for assistance.
4. Remove entire heater assembly from system. Internal components are typically not replaceable.
5. Reconnect thermocouples, power and ground wires for new/replacement heater.
6. Attach any covers and operate heater as normal.



Element Life Curve

(This is published by the element wire manufacturer. It is considered typically and not a guaranteed life)

The life of a SYLVANIA heater is directly based on the temperature of the filament wire. The curve below shows that 5000 hours of life can be obtained by maintaining a filament temperature below 1900°F. Also note that the element does not fail until it reaches more than 2200°F!



***The technical data and specifications supplied in this operating manual are subject to change without prior notice. Contact OSRAM SYLVANIA for additional assistance.***