

FASTRAK®
USER'S MANUAL
Revision F

3SPACE®

OPM3609-002C
November 1993

NOTICE

Copyright ©1992-1993 by Polhemus Incorporated
Colchester, Vermont U.S.A.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, mechanical, photocopying, recording or otherwise, without the prior written permission of Polhemus Incorporated. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this book, Polhemus Incorporated assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from use of the information contained herein.

3SPACE® and FASTRAK® are registered trademarks of Polhemus Incorporated.

OPM3609-002C
November 1993

WARNING

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference in which case the user will be required to correct the interference at his own expense.

SOFTWARE COMMAND STRUCTURE COMPARISON FASTRAK vs TRACKER

For our customers who presently own one or more of our Tracker products and either have or are considering up-grading to a FASTRAK instrument, we are pleased to present a software command structure comparison between the Tracker and the new FASTRAK. This is not a detailed, bit by bit comparison - you will have to refer to the command data presented within the FASTRAK manual to obtain that level of detail. What we do show however, are all the commands by letter and title (old and new) in four major categories called "Same", "Modified", "Deleted" and "New". In the "Modified" category, where some of the commands themselves may not have been changed, modifications were made to their output structure.

1.0 Same

<u>Cmnd Ltr</u>	<u>Fastrak Title</u>	<u>Tracker Title</u>
A	Alignment Reference Frame	Define Alignment from Host
R	Reset Alignment Reference Frame	Reset Alignment
B	Boresight	Define Boresight
b	Unboresight	Reset Boresight
^K	Save Operational Configuration	Save System State
F	Enable ASCII Output Format	Set ASCII Data Format
^Y	Re-initialize System	System Reset
P	Single Record Transmission	Send Record
C	Continuous Print Output	Set Continuous Xmit Mode
c	Disable Continuous	Set Non-

	Printing	continuous Xmit Mode
U	Set Unit Inches	Set Inches Unit
u	Metric Conversion Units	Set Centimeter Units
^S	Suspend Data Xmission	Suspend Xmission (X/OFF)
^Q	Resume Data Xmission	Resume Xmission (X/ON)
v	Attitude Filter Parameters	Attitude Filter Parameters
x	Position Filter Parameters	Position Filter Parameters
V	Position Operation-al Envelope	Define Envelope

2.0 Modified

<u>Cmnd Ltr</u>	<u>Fastrak Title</u>	<u>Tracker Title</u>
e	Define Stylus Button Function	Run Digitizer Mode
f	Enable Binary Output Format	Set Binary Data Format
I	Define Increment	Define Increment
O	Output Data List	Define Output List
S	System Status	System Status
l	Active Station State	Station Acti vate/Deactivate
H	Hemisphere of Operation	Define Hemi-sphere from Host
N	Define Tip Offsets	Define Tip Offsets

3.0 Deleted

<u>Cmnd Ltr</u>	<u>Fastrak Title</u>	<u>Tracker Title</u>
a		Define Output
		List
k		Reset Output
		List
t		Extended Mode

4.0 New

<u>Cmnd Ltr</u>	<u>Fastrak Title</u>
G	Boresight Reference Angles
D	Enable Fixed Metal Compensation
d	Disable Fixed Metal Compensation
r	Transmitter Mounting Frame
y	Set Synchronization Mode
W	Reset System to Defaults
X	Configuration Control Data
Q	Angular Operational Envelope
o	Set Output Port
T	Built-In-Test Information

GETTING STARTED

There are two ways to get started with your FASTRAK instrument as with any new instrument. You could "wing it," which involves a great deal of assumptions based on either previous experience and/or visual inspection, and hope for the best. Or, you could sit down and read the whole manual, line-by-line, and then start. The former method inevitably leads to massive amounts of frustration and irritation and is bad for your blood pressure. The latter method, if followed exactly, will either lead to eventual success or completely cure your insomnia which in either case will be unacceptably time consuming.

The following is offered as an alternative approach. However, this approach does not preclude using the manual as a precise guide, reference and final arbiter.

NOTE: This approach assumes a single receiver, use of the RS-232 serial port at 9600 Baud communicating with a PC through Comm1, and use of the TERMINAL program located on the accompanying diskette.

1. Do visually and carefully inspect the instrument and the accompanying receiver(s) and transmitter. Note external switches and port numbering. If you have any questions concerning these items refer to Section 5 in the manual.

2. Set up the instrument close to your host computer and away from large metal objects like file cabinets, metal desks etc.

3. Identify the transmitter and insert the

transmitter connector into its appropriate port, being careful to firmly engage it. Using a small, flat bladed screw driver, lock the connector by seating the two retaining screws.

4. For getting started, use only one receiver. Identify the receiver and insert the receiver connector into Receiver Port #1. Firmly engage and lock the receiver connector into place in the same manner as the transmitter connector in Step 3 above.

5. Identify the "Receiver Inputs/Selector Switch". This switch is located on the front panel of the electronics unit between receiver ports #1 and #3.

Locate switch #1 and place it in the **DOWN** position. Ensure that all remaining (three) switches are in the **UP** position.

6. For testing purposes, it is convenient to mount both the transmitter and the receiver on a single block of wood (2X4 or equivalent) about 14 inches apart. Exact placement of the transmitter and receiver is not particularly important; just make sure the cable ends of both devices come off the small ends of the 2X4.

7. Identify the five pin "DIN" type power input connector on the back panel of the electronics unit. With the separate Power Supply ("brick") **UNPLUGGED** from the wall's convenience outlet, plug the "brick's" DIN connector into the power input connector on the rear panel of the electronics unit and firmly seat. Identify the power ON/OFF rocker switch located on the rear panel of the electronics unit. Ensure this switch is in the **OFF** position (logic "0" and DOWN) before inserting the "brick's" convenience plug into the 110/220 VAC outlet.

8. Identify the I/O Select Switch located on the rear panel of the electronics unit. Set the switches to the following positions:

<u>Switch</u>	<u>Position</u>
1	UP
2	UP
3	DOWN
4	DOWN
5	UP
6	DOWN
7	DOWN
8	UP

As set, these switches provide for RS-232 serial operation (Switch 8), 9600 baud (Switches 1, 2 & 3), 8 bit character width (Switch 5), no parity (Switches 6 & 7), and no hardware handshake (RTS, CTS) functionality (Switch 4).

9. **NOTE: THE FASTRAK INSTRUMENT THINKS IT IS A TRANSMITTER AND THEREFORE A NULL MODEM CABLE IS REQUIRED.** Obtain a NULL MODEM RS-232 serial interconnection cable with a 9 pin, female "D" connector on both ends. Plug one 9 pin, female "D" connector into the I/O connector located on the rear panel of the electronics unit. Engage and lock this connection in the same manner as the receiver and transmitter connections as indicated in Steps 3 & 4 above.

10. Most PC hosts have a 9 pin, male "D" type connector for Comm1. Therefore, because we are using Comm1, plug the remaining end of the cable into the Comm1 port of the host PC and engage and lock as before. If your host computer has a 25 pin "D" connector for the RS-232 port, you will need a 9 to 25 pin "D" connector adaptor with the proper genders.

Note that this adapter must not compromise the NULL MODEM sense of your cable.

11. Insert the Terminal Program diskette into the "A" drive, obtain the A drive prompt (A:\) and type "terminal" followed by a carriage return. When the Terminal program comes up, first refer to the READ.ME and TERMINAL.DOC files contained in this program so you will be familiar enough with the program to exercise the instrument.

12. At this point you may turn on the FASTRAK using the Power Switch located on the back panel of the S.E.U. Note the Power On Indicator located on the front panel of the electronics unit. It should flash for approximately 10 seconds indicating self-test and set-up. When these routines are completed (@10 seconds), the indicator will turn to a steady-on state thereby indicating that the instrument is ready to operate.

13. You may now use the Terminal Program to exercise the instrument. The six-degree-of-freedom output data you receive consists of seven columns of data as follows:

<u>Column</u>	<u>Function</u>
1	01
2	X position in inches
3	Y position in inches
4	Z position in inches
5	Azimuth attitude in degrees
6	Elevation attitude in degrees
7	Roll attitude in degrees

Because you have locked the receiver in one position relative to the transmitter (Step 6), the data output

will not change regardless of the number of data samples you take.

14. Loosen the receiver and move it approximately six inches toward the transmitter and take a data point. The value of the X position data will decrease by approximately six inches. The Y and Z values will remain roughly the same as the original data. If you left the attitude of the receiver approximately the same as it was when you started, then the attitude data will be approximately the same also.

15. Again, loosen the receiver and without moving its position, try twisting it in YAW (azimuth) approximately 45 degrees and lock it down with tape. Now take another data point. The first four columns will be approximately as they were in Step 13, but the Azimuth data in column 5 will have changed approximately 45 degrees.

16. Play with the instrument as shown in Step 14 to demonstrate that it measures the position and orientation (six-degrees-of-freedom) of the receiver with respect to the transmitter.

17. If the instrument fails to produce six-degree-of-freedom data, carefully go over the above procedure in a step-by-step fashion, checking connections and switch settings especially. When all else fails, call us.

FASTRAK USER'S MANUAL

1.0 INTRODUCTION

Welcome to the world of FASTRAK! We have streamlined our electromagnetic, six-degree-of-freedom tracking instrument to give you the latest and best tracking performance machine anywhere. Hopefully we have accomplished these attributes in our manual as well. The data presented here allows you to move into the FASTRAK lane with the speed you desire. You won't be hindered by excessive and formal verbiage. Only the pertinent facts are presented.

2.0 HARDWARE

The FASTRAK instrumentation consists of the following standard and optional items:

Standard Items

- | | |
|-------------------------------------|--------------|
| 1. System Electronics Unit (SEU) | 4A0316-01 |
| w/single carrier frequency | |
| capacitor board installed | |
| 2. Power Supply, Free Standing | 1C0034 |
| International Power Sources | |
| 3. Transmitter with 10' cable | 3A0369-02 |
| 4. Single Receiver with 10' Cable | 4A0314-01 |
| 5. FASTRAK Manual | OPM3609-002C |
| 6. FASTRAK Interface Diskette (FID) | |

Optional Items

1. RS-422 serial port in lieu of RS-232C port.
2. Up to three additional Receivers.
3. Any of three alternate Frequency Select Modules. (3A0363-01, 02, or 04)
4. Inter-Unit Synchronization Cables: Standard telephone extension cable (H1643-14.ND)
5. Video Sync Detector. (36-010)
6. Transmitter with 20' Cable. (3A0369-03)
7. Receiver with 20' Cable. (4A0314-02)
8. Transmitter with 1' break-away cable. (3A0369-04)
9. Receiver with 1' break-away cable. (4A0314-03)
10. Stylus with 10' or 20' Cable (4A0318-01 or 02)
11. 3BALL™ (receiver) with 10' cable (4A0314-05)

3.0 OVERVIEW

The FASTRAK tracking system uses electro-magnetic fields to determine the position and orientation of a remote object. The technology is based on generating near field, low frequency, magnetic field vectors from a single assembly of three colocated, stationary antennas called a transmitter (Xmtr), and detecting the field vectors with a single assembly of three colocated, remote sensing antennas called a receiver (Rcvr). The sensed signals are input to a mathematical algorithm that computes the receiver's position and orientation relative to the transmitter.

The FASTRAK consists of a System Electronics Unit (SEU), one to four receivers, a single transmitter, and a power supply. The system is

capable of operating at any of four discrete carrier frequencies. Different carrier frequencies allow operation of up to four FASTRAKs simultaneously and in close proximity to one another. The FASTRAK has two possible interfaces to your host computer: RS-232 and IEEE-488. Any single receiver may be operated at the fastest update rate (120 Hz); any two receivers at one half this rate; any three at one third this rate; or all four at one fourth the fastest rate. Mixed rates are not permitted meaning that all active receivers operate at the same update rate; one cannot be operated faster than another. Active receivers are selected by a combination of software configuration commands and receiver selector switch settings.

Additionally, the FASTRAK may be used with a stylus or a 3BALL device in lieu of a standard package receiver. Tip offsets are automatically calculated for the stylus and no special commands are required for this mode of operation. Switch functionality is provided with both the stylus or 3BALL device. The stylus and 3BALL may only be used in Receiver Port #1.

Operation of these devices is covered in Section 6.11.

4.0 SPECIFICATION

Position Coverage The instrument will provide the specified accuracy when the receivers are located within 30" (76 cm.) of the transmitter. Operation with separations up to 120" (305 cm.) is possible with reduced accuracy.

Angular Coverage The receivers are all-attitude.

Static Accuracy 0.03" (0.08 cm) RMS for the X,Y,or Z receiver position, and 0.15° RMS for receiver orientation.

Resolution 0.0002 inches/inch of range (0.0005 cms/cm of range), and .025°.

Latency 4.0 milliseconds from center of receiver measurement period to beginning of transfer from output port.

Output Software selectable including extended precision. Cartesian coordinates of position and Euler orientation angles are standard. Direction cosines and quaternions are selectable. English or metric units are also selectable.

Update Rate

One receiver: 120 updates/second/receiver
Two receivers: 60 updates/second/receiver
Three receivers: 40 updates/second/receiver
Four receivers: 30 updates/second/receiver

Carrier Frequency The FASTRAK may be configured with any one of four discrete carrier frequencies to allow simultaneous operation of up to four instruments in close proximity. Carrier frequencies are selected via color coded Frequency Select Modules (FSM). These frequencies are:

<u>Reference #</u>	<u>Frequency</u>	<u>Color Code</u>
1	8013 Hz	Black
2	10016 Hz	Red
3	12019 Hz (Standard)	Yellow
4	14022 Hz	Blue

The color dot can be found on the FSM, on the end closest to the connector.

Interfaces IEEE-488 parallel port at 100K Bytes/second maximum, and RS-232C serial port with software selectable baud rates of 300, 1200, 2400, 4800, 9600, 19200, 38400, 58600 and 115200; ASCII or Binary format. The factory standard for RS-232C is 9600 baud. An RS-422 port is available as an optional serial port in lieu of the RS-232 at the same baud rates.

Operating Environment Large metallic objects, such as desks or cabinets, located near the transmitter or receivers may adversely affect the performance of the instrument.

Operating Temperature 10°C to 40°C at a relative humidity of 10% to 95% non-condensing.

Physical Characteristics

SEU Width 11.38" (28.91 cm.), length 11.06" (28.90 cm.), height 3.63" (9.22 cm.), weight 5.0 lb. (2.26 Kg.).

Transmitter Width 2.1" (5.3 cm.), length 2.1" (5.3 cm.), height 2.3" (5.8 cm.), weight 0.6 lb. (0.27 Kg.) excluding attached cable. The Transmitter may be purchased with either 10' or 20' cables or with a 1' cable with break-away connector.

Receiver Width 1.1" (2.83 cm.), length 0.90" (2.29 cm.), height 0.60" (1.52 cm.), weight 0.6 oz. (17.0 gm.) excluding attached cable. Receivers may be purchased with either 10' or 20' cables, or with a one-foot cable with break-away connector.

Stylus Length 7.75" (19.7 cm.) including tip, maximum barrel diameter 0.75" (1.9 cm.), handle diameter 0.375" (0.95 cm.), tip length 1.00" (2.54 cm.), tip diameter 0.156" (0.4 cm.), weight 2.5 oz. (28.3 gm.) excluding attached cable. The stylus may be purchased with either 10' or 20' cables.

3BALL

A standard receiver mounted in an official #3 billiard

ball fitted with an integral switch. The 3BALL has a standard 10' cable.

Power Requirements

International Power Sources Supply: Input power is 85-264 VAC, 47-440 Hz, single phase at 25 watts.

5.0 COMPONENT DESCRIPTION

5.1 SEU

The SEU is a stand-alone unit that may be located anywhere that is convenient to the work area, AC power and the host computer. It contains the required input and output connectors and controls to support up to four receivers, a single transmitter and the RS-232 and IEEE 488 output ports. Receiver Input(s), Rcvr Select Switch, Transmitter Input, I/O Cables, I/O Select Switch, External Sync I/O, Video Sync Input, and Power Input connections are located on the SEU as shown in Figure 1 and Figure 2.

5.2 Receiver Inputs/Selector Switch

The four possible Receiver Input receptacles are 15 pin, female, "D" type designated 1, 2, 3, and 4 and are located on the SEU as shown in Figure 2, Front View. Any one or all four Receivers may be plugged in. Receiver selection is accomplished by the four position receiver Selector Switch located on the SEU as shown in Figure 2, Front View. To **select** a particular Receiver, the corresponding number selector switch must be **DOWN** and all others **UP**. Improper receiver switch selection or failure to select at least one receiver will result in a continuous output to the RS-232 port of "1" type output records (ACTIVE STATION STATE).

Figure 1. FASTRAK Instrument

Figure 2. FASTRAK SEU

5.3 Transmitter Output

The single Transmitter Output receptacle is a 15 pin, male "D" type located on the front of the SEU as shown in Figure 2.

5.4 Power Indicator

A green LED power on indicator is located on the front of the SEU as shown in Figure 2. Upon power up the indicator will blink for approximately 10 seconds while the instrument performs its initialization and self test routines. When these routines are complete the indicator changes from blink mode to steady-on and the instrument is ready for operation.

5.5 I/O Select Switch

The I/O Select Switch is an 8 position switch located on the rear panel of the SEU as shown in Figure 2, Rear View and is only read on power up. The purpose of this switch is to select the I/O to be used -- IEEE-488 parallel mode or RS-232 serial mode. Switch number 8 selects the desired mode and the remaining 7 switches have dual functionalities depending on the mode selected. The modes with switch positions and their corresponding functions are:

Parallel Mode -- IEEE-488

Note: **UP** position is a logic "1" and **DOWN** is a logic "0".

<u>Switch Position</u>	<u>Function</u>
----------------------------	-----------------

1	Bit 0 (LSB) IEEE-488 Address
2	Bit 1 IEEE-488 Address
3	Bit 2 IEEE-488 Address
4	Bit 3 IEEE-488 Address
5	Bit 4 (MSB) IEEE-488 Address
6	not used
7	not used
8	I/O Select -- DOWN for IEEE-488

Serial Mode -- RS-232

Note: **UP** position is a logic "1" and **DOWN** is a logic "0".

<u>Switch Position</u>	<u>Function</u>
1	Baud rate select
2	Baud rate select
3	Baud rate select
4	Hardware Handshake select
5	Character width: "0" = 7 bits "1" = 8 bits
6	Parity select
7	Parity select
8	I/O Select -- UP for RS-232

The Baud rate select logic for switches 1, 2 and 3 is as follows:

<u>Baud Rate</u>	<u>1</u>	<u>2</u>	<u>3</u>
1200	0	0	0
2400	1	0	0
4800	0	1	0
9600	1	1	0
19200	0	0	1
38400	1	0	1
57600	0	1	1
115200	1	1	1

The instrument reads the baud rate switches only on power up. Therefore, if you change the switches to obtain a different baud rate, you must restart the instrument either by using the ^Y command or by recycling the power. The "o" command may be used to override the switch settings during operation. However, even if you save the new baud rate with the ^K command, the next time you power up, the instrument will ignore the EEPROM baud rate setting and read the switch settings to operate at that baud rate.

The Hardware Handshake function, when evoked by Switch 4, enables the Request To Send (RTS) and Clear To Send (CTS) serial interface handshake functions for those host computers that would better operate utilizing them. The Hardware Handshake select logic for switch 4 is "0" = RTS/CTS Disabled
"1" = RTS/CTS Enabled.

The Parity select logic for switches 6 and 7 is as follows:

<u>Parity</u>	<u>6</u>	<u>7</u>
None	0	0
Odd	1	0
Even	0	1
not used	1	1

if selected - system defaults to Even parity.

5.6 External Sync I/O

The External Sync I/O module is located on the rear edge of the SEU as shown in Figure 2. The module contains two modular telephone plugs with the plug closest to the I/O Select Switch being "Sync In". All input and output signals must be differential TTL compatible signals with the following logic:

Input: START = Logic LOW to HIGH transition, 50 μsec. pulse, min.
Output: START = Logic HIGH, 50 μsec. pulse, min.

The Sync In and Sync Out signals use differential receivers and drivers which are compatible with RS-422 specifications.

The pin assignments for each plug are as follows and their numbering is shown in Figure 3:

"Sync In"	<u>Pin #</u>	<u>Function</u>
	4	SYNC IN POSITIVE
	3	SYNC IN NEGATIVE
	2	GROUND
	1	INTERNAL USE

"Sync Out"	<u>Pin #</u>	<u>Function</u>
	4	INTERNAL USE
	3	GROUND
	2	SYNC OUT NEGATIVE
	1	SYNC OUT POSITIVE

5.7 IEEE-488 I/O

The IEEE-488 I/O receptacle is a standard IEEE-488, 24 contact, female, "D" type located on the rear edge of the SEU as shown in Figure 2.

5.8 Frequency Select Module

The Frequency Select Module is used to select the operating carrier frequency of choice. It is located on the PCB directly behind the Transmitter input connector. The alternate carrier frequencies are produced by inserting the required capacitor module in the socket provided. The Frequency Select Modules are color coded for carrier frequency identification as described in Section 4.0 of this document. **AS WITH ANY HANDLING OF THE PCB, WHEN INSERTING OTHER MODULES TO EFFECT A DIFFERENT CARRIER FREQUENCY, STATIC PRECAUTIONS MUST BE OBSERVED. DO NOT REMOVE AND REPLACE FREQUENCY SELECT MODULE WITH POWER APPLIED TO THE PCB.**

5.9 RS-232 I/O

The RS-232 I/O connector is a standard, 9 pin, male, "D" connector located on the rear of the SEU as

Figure 3. FASTRAK Controls/Connections
(Front & Rear)

shown in Figure 2. The pinouts for this connector are as follows:

<u>Pin #</u>	<u>Function</u>
1	not used
2	RxD
3	TxD
4	not used
5	GND
6	not used
7	RTS*
8	CTS*

* Selected via Switch 4 of I/O Select Switch

FASTRAK optionally uses RTS and CTS which is enabled via the I/O Select Switch. Please refer to Appendix D to find the specific interconnection scheme for your host and the corresponding action that must be taken to obtain a reliable serial interface.

NOTE: If you do not find your particular host's RS-232 I/O interconnection scheme in Appendix D, call Polhemus and FAX a copy of your host's pinout scheme from its user's manual. Polhemus will respond with the appropriate action you must take to allow your FASTRAK and host to communicate. (Our FAX number can be found in Section 9.)

5.10 Optional RS-422 I/O

The optional RS-422 connector is identical to the RS-232 connector in form, fit, function, and location on the rear of the SEU. RS-422 is a differential transmit and receive I/O with a maximum speed of 10 Megabits/second with operation possible at a distance

of 1200 meters with a speed of 100Kbits/second. The RS-422 does not use Handshake functions for transmission and reception. The pinouts for this connector are as follow:

<u>Pin #</u>	<u>Function</u>
1	RxB; non-inverting receive input
2	not used
3	not used
4	TxB; non-inverting transmit output
5	not used
6	RxA; inverting receive input
7	not used
8	not used
9	TxA; inverting transmit output

5.11 Video Sync Input

The Video Sync Input is a subminiature telephone receptacle that mates with the video pickup coil assembly (Video Sync Detector). The Video Sync Input is located on the rear of the SEU as shown in Figure 2.

5.12 Power Input Receptacle

The Power Input is a 5 contact, female, shielded DIN type receptacle located on the rear of the SEU as shown in Figure 2. Pinouts for this receptacle are as follows:

<u>Pin #</u>	<u>Function</u>
1	COMMON

18

2	GROUND
3	+5 VDC
4	-15 VDC
5	+15 VDC

Note: Pin 1 is electrically shorted to Pin 2 on the PCB.

5.13 Cooling Fan

A small cooling fan is located on the rear panel of the SEU as shown in Figure 2. The fan is powered from the 5 VDC supply and will only operate when the instrument is powered up.

5.14 Transmitter

The Transmitter is dimensionally shown in Figure 4 including the position of the electrical center. There are 4, 1/4" - 20 NC tapped holes provided on the bottom surface for mounting. Nylon hardware (supplied) should be used when locating the Transmitter in a fixed position.

Figure 4. Transmitter

5.15 Receiver(s)

The Receiver is dimensionally shown in Figure 5 including the position of the electrical center. The Receiver package provides 2 mounting holes for #4 screws (supplied) in the event that Receiver mounting is required. In this case, the supplied nylon hardware is required.

5.16 Stylus

The stylus is dimensionally shown in Figure 6 and may only be used in Receiver port #1. The stylus functions as a receiver with the electrical center offset to the tip of the stylus via software and single or continuous output records may be obtained as a function of the integral switch. See Section 6.11 for operation with a stylus.

5.17 3BALL

The 3BALL is a receiver mounted in a #3 billiard ball which contains an integral switch. The 3BALL is shown in Figure 7 and may be used in the same manner as a mouse, in that single or continuous output records may be obtained as a function of the switch. The 3BALL may only be used in port #1. See Section 6.11 for operation with the 3BALL device.

Figure 5. Receiver

Figure 6. Stylus

Figure 7. 3BALL

5.18 Video Sync Detector

The Video Sync Detector consists of a pickup coil and a 3' cable terminated with a subminiature telephone plug. The Video Sync is used when the instrument's data exhibits objectionable noise when operating a receiver in close proximity to any CRT monitor. If this condition occurs, then Video Sync may be employed using the Video Sync Detector (see Section 5.9) and the software command "y2" (see Section 7.5 - Set Synchronization Mode). The pickup coil of the Video Sync Detector is attached to the CRT (Monitor) case and the connector inserted into the Video Sync Detector input. After issuing the "y2" command, the instrument checks for sufficient signal level from the video pickup coil. If the signal level from the pickup coil is below a preset threshold, a **"no video sync available"** message is displayed. If this condition exists, move the pickup coil to another part of the Monitor case. This procedure is repeated until the **"no video sync available"** message ceases to occur. The video synchronization mode may be exited at any time by selecting another type of synchronization mode using the "y" command.

5.19 Diskette

There is one diskette that accompanies this instrument called a FASTRAK Interface Diskette (FID).

The Terminal Program allows PC host/ instrument communication, testing and data collection without detailed knowledge of various system commands and contains the following program and files:

1. Terminal Emulator Program for instrument

- communication.
2. READ.ME file.
 3. TERMINAL.DOC file that describes functionality.
 4. Source Code for use by an experienced programmer.

6.0 INSTRUMENT OPERATION

6.1 I/O Considerations

Perhaps one of the most confusing and frustrating areas to deal with is interfacing the FASTRAK instrument to the host computer, because, if that isn't properly accomplished, then absolutely nothing happens. This section of the manual is an attempt to make that integration task as painless as possible.

As stated in Section 5, there are three possible interface ports; IEEE-488 parallel, RS-232C serial and an optional serial RS-422. Each port supports either Binary or ASCII formats. Only the two serial ports and their interconnections with the host computer are discussed here. Requirements for and use of the IEEE-488 parallel port are discussed in Appendix A.

RS-232C The RS-232 is the most commonly used port both in binary and ASCII formats because of its commonality and the fact that it supports high baud rates. The RS-232 port should be used where host to FASTRAK physical separation distances are no greater than 50 feet. There are two modes of operation with the RS-232; with Hardware Handshake (HH) and without HH. In Step 9 of the "Getting Started" section, we said that it is necessary to use a "null modem" cable because the instrument thinks it is a transmitter. If this is confusing to you here is a nearly universal approach to connecting the FASTRAK to your host computer via the RS-232 I/O Port.

For operation without Hardware Handshake, ensure that your RS-232 cable connects the **FASTRAK TRANSMIT DATA PIN (TxD)** to the **HOST'S RECEIVE DATA PIN** and that the **FASTRAK RECEIVE DATA PIN (RxD)** is connected to the

HOST'S TRANSMIT DATA PIN. Also ensure that the RS-232 cable connects the **FASTRAK GROUND PIN (GND)** to the **HOST'S GROUND PIN**. Note that the host's ground pin may be designated as "Signal Ground" or some other comparable phrase. Also, ensure that the I/O Select Switch switches are set exactly as shown in Item 8 of the "Getting Started" Section of this manual.

For operation with Hardware Handshake, the above connections must be made plus the following additional connections and change in switch settings. First, ensure that your RS-232 cable connects the **FASTRAK CTS (CLEAR-TO-SEND) PIN** to the **HOST'S DTR (DATA-TERMINAL-READY) PIN** and the **FASTRAK RTS (REQUEST- TO-SEND) PIN** is connected to the **HOST'S DSR (DATA-SET-READY) PIN**. Next, place switch #4 of the I/O Select Switch in the **UP** position. Please note however that your host may call the DTR and DSR functions by other similar names.

RS-422 The optional RS-422 port is used where large separation distances between the FASTRAK and the host are anticipated. The RS-422 does not use Hardware Handshaking and **failure to place switch #4 of the I/O Select Switch in the DOWN position will render the port inoperable.**

As with the RS-232 port, the RS-422 Transmit signals from the FASTRAK must be connected to the Host's Receive signals and the FASTRAK's Receive signals must be connected to the Host's Transmit signals. Signal polarity conventions must be strictly observed.

6.2 Setup

After assembling the instrument hardware and connecting the I/O cable to the host computer, the

TERMINAL.EXE program may be used to communicate with and operate the FASTRAK instrument. Please note: Once you have established the transmitter/receiver configuration and set the Selector Switch, the configuration is set until you change it. If at any time you decide to change the configuration or add additional or new receivers/transmitters, it must be accomplished with power OFF as receiver/transmitter characterization data is only read at power up. Failure to do this will result in erroneous data.

6.3 Power-Up

The FASTRAK has a power on switch. To power-up your instrument first ensure that the power supply is not plugged into the AC. Then connect the power cable from the Power Supply to the DIN power connector on the rear panel of the instrument. Plug the Power Supply into the AC outlet and turn the Power Switch to the ON position. On power up, the power indicator will blink for approximately 10 seconds to indicate the instrument's performance of an initialization and self test routine. During this time instrument operation is not possible. At the completion of this routine, the power indicator will change from a "blink" state to "steady-on" which indicates that the instrument is now operational.

6.4 Output Considerations

Operating the instrument consists of issuing commands over either I/O port from the host to control the instrument's performance characteristics and observing and/or utilizing the resulting outputs. The most important parameters describing the instrument's performance are latency, speed, accuracy and

resolution. Definitive treatment of these parameters is contained in two application notes found in Appendices B and C of this document. They are entitled: "ACCURACY AND RESOLUTION IN ELECTROMAGNETIC SIX-DEGREE-OF-FREEDOM MEASUREMENT SYSTEMS", and "Technical Note LATENCY - 3SPACE® FASTRAK."

From an operational point of view relative to the instrument output, latency must be considered with respect to baud rate, output record length and filtering. The combination of baud rate, record length and filtering collectively define the data transfer time. Depending on the baud rate, record length and filtering chosen, longer than specified latency, exclusive of data transfer time, will occur.

If the data transfer time is longer than the instrument's cycle time and data queuing is invoked in the output buffer, an output data record may be skipped. For example: if the instrument is operated in continuous print mode ("C" command) and the data transfer time is longer than the cycle time, the instrument will skip a data record or queue the data for output depending on the output buffer availability for the RS-232 port only. For the IEEE-488 port, however, output is immediate if the output buffer is available; if not, the data record is skipped. Additionally, if more than one receiver is in use, the receiver output sequence will not be compromised due to output buffer availability. If output data is requested with the "P" command (single record), regardless of the I/O port employed, and the time between requests is **less than** the instrument cycle time, no delays will result from queuing and no data record skipping will occur since only one full data record at a time will reside in the output buffer.

6.5 Synchronization and Multiple Systems

Synchronization

Synchronization defines and controls the precise time that a FASTRAK instrument measurement cycle will start and thereby controls the tracking output from an application system point of view. The FASTRAK instrument has three distinct synchronization modes that are controlled by the "y" commands and are defined as:

<u>MODE</u>	<u>COMMAND</u>
Internal Sync	y0
External Sync	y1
Video Sync	y2

- Internal Sync

In the Internal Sync mode (y0 command), each measurement cycle of the FASTRAK instrument starts immediately after the previous cycle ends. The instrument update rate is slightly greater than 120 Hz and cycle-to-cycle variations on the order of microseconds are possible in this mode. Only the "y0" command is required to initiate the Internal Sync mode and no input is required for the instrument's SYNC IN port.

- External Sync

The External Sync mode (y1 command), allows you to define when the FASTRAK instrument measurement cycle will start. This mode may be used to synchronize other peripheral instrumentation to the FASTRAK data collection cycle or to slow the FASTRAK to a known and desired rate. To initiate the External

Sync mode an external signal as detailed in Section 5.5 must be input to the SYNC IN port and the "y1" command issued.

WARNING

ONCE THE FASTRAK INSTRUMENT IS PLACED IN THE EXTERNAL SYNC MODE BY ISSUING THE "y1" COMMAND AND THE INSTRUMENT RECEIVES A SYNC PULSE, THE FASTRAK WILL IGNORE ANY SYNCHRONIZATION PULSES SENT DURING RESULTING MEASUREMENT CYCLES. WHEN THE MEASUREMENT CYCLE IS COMPLETE, THEN AND ONLY THEN WILL THE INSTRUMENT HONOR THE NEXT SYNC PULSE. IF YOU ARE CONTEMPLATING CHANGING SYNCHRONIZATION MODES DURING YOUR COURSE OF OPERATION WITH THE FASTRAK, WE RECOMMEND THAT YOU DO NOT BURN THE "y1" MODE INTO THE EEPROM. WHEN YOU WANT TO DISCONTINUE USING THE EXTERNAL SYNC MODE, YOU MUST SEND THE INSTRUMENT EITHER A "y2" OR "y0" COMMAND FOLLOWED BY ONE ADDITIONAL EXTERNAL SYNC PULSE. FAILURE TO DO THIS WILL CAUSE THE INSTRUMENT NOT TO RESPOND AND YOU WILL NOT BE ABLE TO EITHER SEND COMMANDS OR RECEIVE DATA.

- Video Sync

The Video Sync mode (y2 command) is employed as described in Section 5.14 entitled "Video Sync Detector." The FASTRAK measurement cycle starts as a function of signal quality and measurements will continue or stop as a function of the signal quality.

Multiple Systems

For optimum performance when employing multiple systems, each system should have a different carrier frequency (up to four available) to take advantage of

frequency multiplexing. The advantages include the fastest possible update rates from each machine for each receiver employed and the ability to operate all instruments in close proximity. Multiple instrument operation with the same carrier frequency for each instrument is not recommended as separation distances in excess of 23 feet are required between instruments to ensure non-interference. Similarly, multiple system operation with different carrier frequencies for each instrument requires a separation distance of 13.7 feet to ensure non-interference if the instruments are not synchronized. **Instrument separation distance is defined as the distance between the transmitter of one instrument and the receiver of another when both instruments are operating.** Multiple systems discussions assume that operation will be with frequency multiplexing and inter-instrument synchronization for up to four instruments.

Synchronizing multiple instruments, regardless of the mode chosen, involves interconnection of the SYNC IN/SYNC OUT ports of up to four instruments to be operated in close proximity and issuing the appropriate "y" commands. The interconnection is accomplished using a "daisy chain" configuration where one instrument is arbitrarily designated as the "Master" and the remaining designated as "Slaves." The SYNC OUT port of the "Master" is connected to the SYNC IN port of the first "Slave" and this "Slave's" SYNC OUT port is connected to the SYNC IN port of the next "Slave" and so on for a maximum total of four instruments (1 master and 3 slaves).

When synchronized, the instrument separation distance limitations for the receivers of any one instrument with respect to the transmitters of any of the other instruments are as follows: When four instruments are synchronized, this separation distance

limitation is 13 inches; i.e. the receivers of any one instrument must be no closer than 13.0 inches from the transmitters of any of the other remaining three instruments that are synchronized. If only three instruments are synchronized then this limitation is 11.5 inches and if only two instruments are synchronized then this limitation is reduced to 9.0 inches. Additionally, the minimum transmitter-to-transmitter lateral separation distance is 4.0 inches.

When synchronizing multiple instruments, the "Master" instrument may be synchronized in any mode desired or required (Internal, External or Video) using the appropriate "y" command corresponding to the chosen mode. However, each of the remaining "daisy chain" connected instruments (Slaves) must be configured in the External Sync mode utilizing the "y1" command. The above mentioned **WARNING** applies as well to each of the slave instruments in any multiple system synchronization scheme

6.6 System Commands and Outputs

There are two classes of system commands: one class for configuring the state of the instrument, and the other for controlling its performance characteristics. Not all system commands have intrinsic outputs, although verification may be made.

The commands are presented in functional, alphabetical order. Where applicable, a description of the detailed content of the data records output on the instrument's RS-232 or IEEE-488 ports are given for each command. All commands are input on the RS-232 serial port or the IEEE-488 parallel port and consist of ASCII characters. Additionally, format notations and conventions for both commands and outputs are presented first.

6.7 Command Format Notation and Convention

Use the following format notation to enter commands:

[] Items shown inside square brackets are optional.
To include optional items, type only the information inside the brackets. Do not type the brackets.

{ } Items shown inside braces are optional only when requesting a data record. These items must be specified when entering other parameters in the command. Do not type the braces.

<> Represents an ASCII carriage return. Whenever shown this value must be present to terminate the command sequence.

... An ellipsis indicates that you can repeat an item.

, A comma represents a delimiter in a list of optional parameters. The comma must be present for those parameters which are omitted except for the case of trailing commas. For example,

Qs,p1,,,p4<>

is the proper command format when omitting parameters p2 and p3. Commas following the parameter p4 are not required if parameters p5 and p6 are omitted.

| A vertical bar means either/or. Choose one of the separated items and type it as part of the

command. For example,

ON|OFF

indicates that you should enter either ON or OFF, but not both. Do not enter the vertical bar.

^ Denotes the Ctrl key on the keyboard. Command such as ^K, require the user to hold the Ctrl key and press the character following (ie. K).

NOTES:

- (1) For those commands involving an optional list of parameters, if some of the parameter values are omitted the current system retained value of that parameter is used in its place.
- (2) The "configuration" CLASS indicates that the current state of the command will be stored in EEPROM if a <ctrl K> command (save machine state) is executed. A "standard" CLASS means that the information is not stored in the EEPROM.
- (3) The RELATIVES field contains a list of those commands which provide related information to the system.(4) Throughout this document, the term "receiver" refers to each possible receiver in the FASTRAK (1 to 4).
- (4) The transmitter for the FASTRAK is numbered 1.
- (5) The term station is a transmitter-receiver pair. The four receivers paired with the one available transmitter are assigned station numbers one through four (1-4).

- (6) All commands and alphabetic parameters are case sensitive. They must be entered in upper or lower case as defined for particular command entries.
- (7) FASTRAKs are shipped configured in one of four (4) possible frequencies. The frequencies are referenced as follows:

<u>Ref. Number</u>	<u>Frequency</u>
1	8013 Hz
2	10016 Hz
3	12019 Hz (Standard)
4	14022 Hz

- (8) Where a numeric floating point value is required on input, the format may be specified in any possible format that provides the required accuracy. For example: 3.0 may be specified as:

3
3.
3.0 or
3.0 E+00

See each command's format for generally accepted accuracy range.

6.8 Output Record Format Notation and Conventions

The notation R(Sxx.xxxb) represents the ASCII output format for the specific data element, where:


R is the repeat count, and what follows in parenthesis is repeated R times
S is the sign byte, either +, -, or space (for +)

x is a decimal digit (0..9).
. is the decimal point
b is a Blank
H is a Hexadecimal digit (0..F).

Example: A format 3(Sx.xxxxb), would be output as:

-1.1111 2.2222 -3.3333

The notation SingleFP refers to the ANSI/IEEE Standard for Binary Floating-Point Arithmetic 754-1985 format of data. This is defined in the standard as:



The IEEE floating-point format uses sign magnitude notation for the mantissa, and an exponent offset by 127. In a 32-bit word representing a floating-point number, the first bit is the sign bit.

The next 8 bits the exponent, offset by 127 (ie. the actual exponent is e - 127). The last 23 bits are the absolute value of the mantissa with the most significant 1 implied. The decimal point is after the implied 1, or in other words the mantissa is actually expressed in 24 bits. In the normal case an IEEE value is expressed as:

$(-1)^S * (2^{(e-127)}) * (01.f)$ If $0 < e < 255$

In special cases:

```
(-1)S * 0.0                If e = 0 and f = 0
(-1)S * (2**(-126)) * (0.f) If e = 0 and f <> 0
                           (denormalized)
(-1)S * infinity           If e = 255 and f = 0
                           (infinity)
NaN (not a number)         If e = 255 and f <> 0
```

Note that the actual I/O byte sequence is system specific. For the greatest compatibility, Polhemus has adopted for output, the following Intel 80X86 byte ordering:

The lowest physical address for a byte is a0, a1 has address a0+1, etc. The least significant byte of data is b0, with b3 the most significant byte. For IEEE FP output from the Tracker/Digitizer the byte output sequence is b0, b1, b2, & b3.

<u>a0</u>	<u>a1</u>	<u>a2</u>	<u>a3</u>	
b0	b1	b2	b3	80X86
b2	b3	b0	b1	DEC PDP-11
b3	b2	b1	b0	Z8000 / M680XX

See the IEEE bit representation on the previous page for a more explicit breakdown.

The notation 16BIT is a special binary output format reserved for those users that need less accurate, but fast I/O. See the 16BIT BINARY output record for an explanation of this format.

The field "INITIATING COMMAND" in the description

of the output record represents the console port input command which will cause the output record to be generated. Note that record identifiers and initiating commands are case sensitive as shown on each record description.

All angles are represented in degrees. All X, Y, and Z units are in centimeters or inches, depending on the system configuration (see the Output Units commands "U" and "u").

6.9 Command/Output Listing

ALIGNMENT

Description: The alignment commands allow the user to define an origin from which the X, Y, Z measurements are referenced, and to define a measurement plane. For example, if there is a sloped surface to measure and it is necessary to have the X, Y, Z outputs measured with respect to the reference frame defined by this sloped surface, then the alignment commands allow you to do this.

Alignment data consists of the coordinates, in the transmitter reference frame, of three non-collinear points in space that are used to define the "alignment reference frame." The first point is the origin of the alignment reference frame. A line from the origin through the second point

defines the positive X-axis of the alignment reference frame. The plane defined by all three points defines the XY-plane of the alignment reference frame; the positive Y-direction being from the X-axis toward the third point.

The positive Z-axis is determined by the right hand rule convention for coordinate systems (see Figure 8).

The procedure for using the Alignment command, especially for those customers who have previously owned 3SPACE products such as the Digitizer with its handheld terminal, is a little different in the FASTRAK instrument. First, when defining the Origin, X-axis, and Y-axis, these points may be taken by issuing a "P" command with the FASTRAK in the normal transmitter reference frame. You must retain these points as their x, y, and z values are the inputs used when assembling the "A" command. If you are not using a terminal program when establishing the new alignment reference frame, then you must retrieve the x, y, and z coordinate values of the points taken with the "P" command from your host computer to assemble the "A" command. Obviously, if you are using a terminal program, these points would be available to you directly from your monitor screen. Another word of caution here -- when employing a receiver, the electrical center of the receiver is the point measured or designated for the Origin, X-axis, and Y-axis; when employing a stylus, the tip of the

stylus is the point measured or designated for the Origin, X-axis, and Y-axis. Lastly, after establishing your new desired reference frame, you must remember that the reference frame data is resident in FASTRAK RAM and you will lose this reference frame if you turn the machine OFF. Therefore, if you wish to retain the new reference frame, you should burn the data in the EEPROM by issuing a ^K command. In the event you wish to change or establish another new reference frame you may do so by first issuing an "R" command and follow the procedure listed above.

Having established your new reference frame, you may use the "Right Hand" rule to determine the Euler angle conventions for this new frame. Using your right hand, grasp the new, positive Z axis with your thumb pointing in the direction of positive "Z". Your fingers will then point in the direction of positive azimuthal angles. Using the right hand with the thumb pointing in the direction of positive "Y", your fingers will point in the direction of positive elevation angles. Using the right hand with the thumb pointing in the positive "X" direction, your fingers will

point in the direction of positive roll angles.

The units of the coordinates are interpreted according to the value of UNITS as set by the "U" and "u" command.

Figure 8. System Alignment

Commands: A, R ALIGNMENT REFERENCE FRAME

Syntax: Astation,[Ox],[Oy],[Oz],[Xx],[Xy],
 [Xz],[Yx],[Yy],[Yz]<>

Class: configuration

Purpose: The alignment command defines a reference
 frame to which all position and
 orientation output data is referred.
NOTE: This command operates
 incrementally. If the command is entered
 and the user then changes his/her mind,
 the 'R' command must be used to reset the
 alignment reference frame BEFORE the
 command is re-entered. This is ESPECIALLY
 IMPORTANT to remember if the user makes an
 error and wants to correct the erroneous
 input. The command is useful in this
 incremental mode ONLY TO THE MOST
 SOPHISTICATED user, and should not be
 attempted unless you have the expertise to
 understand and use the results. The
 command parameters are:

station = 1 to 4 which specifies the
 relevant transmitter/ receiver
 pair.

Ox,Oy,Oz the cartesian coordinates of the
 origin of the new reference
 frame.

Xx,Xy,Xz the coordinates of the point
 defining the positive direction
 of the X-axis of the new

reference frame.

Yx,Yy,Yz the coordinates of a third point
 that is in the positive Y
 direction from the X_axis.

If all of the optional parameters are
omitted the command returns the current
coordinate values to the host.

Relatives: R

Range: No Range Restriction Enforced

Default: The transmitter reference frame is the
 default alignment reference frame.
 (0,0,0,200,0,0,0,200,0) in centimeters

ALIGNMENT REFERENCE FRAME

SUB-RECORD IDENTIFIER A
INITIATING COMMAND A

byte(s)	Identification	Format
1	.. Record type, "2"	A1
2	.. Station Number	A1
3	.. Sub-record type "A"	A1
4-24	.. Origin coordinates	3(Sxxx.xx)
25-45	.. Positive X-axis coordinates	3(Sxxx.xx)
46-66	.. Positive Y-axis coordinates	3(Sxxx.xx)
67-68	.. Carriage return, line feed	

RESET ALIGNMENT REFERENCE FRAME

Syntax: Rstation<>

Class: standard

Purpose: This command resets the alignment reference frame for the specified station to the station reference frame. It provides an easy way to re-align the reference frame to the factory default values. The command parameter is defined as:

station the number of the station
 to be reset.

Relatives: A

BORESIGHT

Description: The boresight function allows one to designate any receiver orientation as the zero orientation point.

For example, the receiver may be mounted on a person's head to measure where it is pointing. When the user's head is looking at a given object, he may want the system angular outputs to be zero. The user can designate this receiver orientation as the zero orientation by giving the boresight command. This results in azimuth, elevation, and roll outputs of zero at this orientation. As the user's head moves away from the boresight point, the orientation angles are still measured in the designated reference frame, with the zero points shifted to the point where the boresight occurred.

Commands: B, G, b

Default: The zero orientation condition occurs when the receiver orientation corresponds to the transmitter orientation.

BORESIGHT

Syntax: Bstation<>

Class: configuration

Purpose: This command causes the system to redefine the specified station line of sight values as the new zero reference line of sight. This results in azimuth, elevation and roll outputs equal to the boresight reference values at the current orientation. The system default boresight matrix is the identity. The command parameter is defined as:

station the number of the station
to be boresighted.

Relatives: b, G

BORESIGHT REFERENCE ANGLES

Syntax: Gstation,[aref],[eref],[rref]<>

Class: configuration

Purpose: This command establishes the bore-sight reference angles for a particular station. When the system is subsequently boresighted with the "B" command the line-of-sight vector will assume these values. If all the optional parameters are omitted, the system returns the boresight reference angles for the specified station as an output record of type "G". The command parameters are defined as:

station the number of the station whose reference angles are to be fixed.

aref the azimuth reference angle.

eref the elevation reference angle.

rref the roll reference angle.

The system default boresight reference values are:

0, 0, 0

Relatives: B, b

BORESIGHT REFERENCE ANGLES

SUB-RECORD IDENTIFIER G

INITIATING COMMAND G

byte(s)	Identification	Format
1	...	Record type, "2"
2	...	Station Number
		A1
3	...	Sub-record type "G"
		A1
4-10	...	Azimuth reference angle
		Sxxx.xx
11-17	...	Elevation reference angle
		Sxxx.xx
18-24	...	Roll reference angle
		Sxxx.xx
25-26	...	Carriage return, line feed

UNBORESIGHT

Syntax: bstation<>

Class: standard

Purpose: The system boresight rotation matrix is
 reset to the identity matrix for the
 specified station. The command parameter
 is defined as:

 station the number of the station
 to be boresighted.

Relatives: B, G

COMPENSATION

Description: Compensation refers to the adjustments
 that are necessary to the system
 computations to compensate for metal in
 the magnetic field generated by the
 transmitter for accurate alignment of
 the coils inside the transmitter and
 receiver housings, and for dynamics of
 receiver movements (i.e., filter and
 gain control). The following commands
 provide a means to adjust parameters
 required for these compensations.

Commands: D, d, r, v, x, y

ENABLE FIXED METAL COMPENSATION

Syntax: D

Class: configuration

Purpose: Fixed metal compensation for all stations is enabled with this command. The compensation data must be present for this command to take effect. Compensation data resides in the characterization EPROMs if present. Default is disabled.

Relatives: d

DISABLE FIXED METAL COMPENSATION

Syntax: d

Class: configuration

Purpose: This command disables fixed metal compensation. Default value is compensation disabled.

Relatives: D

TRANSMITTER MOUNTING FRAME

Syntax: rstation,[A],[E],[R]<>

Class: configuration

Purpose: This command provides a means of modifying the mounting frame of the transmitter relative to a particular receiver. This command modifies the values of the transmitter mounting frame coordinates when it is used with an associated receiver. If the optional parameters are omitted, the system returns the current values of the transmitter mounting frame coordinates relative to the associated receiver as an output record of type "r".

The command parameters are:

station the station to be defined

A mounting frame azimuth angle

E mounting frame elevation angle

R mounting frame roll angle

Relatives: none

TRANSMITTER MOUNTING FRAME

RECORD IDENTIFIER r

INITIATING COMMAND r

byte(s)	Identification	Format
1 ...	Record type, "2"	A1
2 ...	Station Number	A1
3 ...	Sub-record type "r"	A1
4-11 ...	Azimuth mounting frame angle	Sxxx.xxx
12-19 ...	Elevation mounting frame angle	Sxxx.xxx
20-27 ...	Roll mounting frame angle	Sxxx.xxx
28-29 ...	Carriage return, line feed	

ATTITUDE FILTER PARAMETERS

Syntax: v[F],[FLOW],[FHIGH],[FACTOR]<>

Class: configuration

Purpose: This command establishes the sensitivity, boundary, and transition control parameters for the adaptive filter that operates on the attitude outputs of the tracking system. By means of this command, the user can adjust these parameters to fine-tune the overall dynamic response of any system that includes the tracker as a serial component. The four user-adjustable parameters are designated F, FLOW, FHIGH and FACTOR in the command syntax above.

The filter is a single-pole low-pass type with an adaptive pole location (i.e, a floating filter "parameter/ variable"). The pole location is constrained within the boundary values FLOW and FHIGH but is continuously self-adaptive between these limits as a function of the sensitivity parameter F and the sensed (ambient noise plus rotational rate) input conditions. For input "rate" conditions that fall within the adaptive range, the adaptive feature varies the pole location between the FLOW and FHIGH limits so as to maximize the output resolution for static inputs while minimizing the output lag for dynamic inputs. Whenever the input conditions cause the filter to make a transition to a narrower bandwidth (i.e.,

increased filtering), the transition rate of the pole location is constrained to a maximum allowable rate by the parameter FACTOR. The functions of the four adjustable parameters and their allowable value ranges are further detailed below. If all of the optional parameters are omitted the current value of each parameter is returned to the user as an output record of type "v".

F a scalar value that establishes the sensitivity of the filter to dynamic input conditions by specifying the proportion of new input data to recent average data that is to be used in updating the floating filter parameter/ variable.

Allowable range of values:
 $0 < F < 1$

FLOW a scalar value that specifies the maximum allowable filter-ing to be applied to the outputs during periods of relatively static input conditions. Setting this value to 1.0 disables the filter completely.

Allowable range of values: $0 < \text{FLOW} < \text{FHIGH}$

FHIGH a scalar value that specifies the minimum allowable filter-ing to be applied to the out-puts during periods of highly dynamic input conditions.

Allowable range of values: FLOW <
FHIGH < 1

FACTOR a scalar value that specifies the maximum allowable transition rate from minimum filtering (for highly dynamic input conditions) to maximum filtering (for relatively static input conditions) by proportionately limiting the decay to the low filter limit whenever the input conditions effect a transition to a narrower bandwidth.

Allowable range of values:
0 < FACTOR < 1

When the form of the command is v,1<> the attitude filter is disabled. This is the system default configuration.

Relatives: none

Note: The default mode for all filter parameters is OFF. Although these parameters are a function of the user's particular environment, the following settings may be used as a "jumping-off" point for determining optimum filtering in your particular environment.

F Set to 0.2
FLOW Set to 0.2
FHIGH Set to 0.8
FACTOR Set to 0.8

ATTITUDE FILTER PARAMETERS

RECORD IDENTIFIER v
INITIATING COMMAND v

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Blank	A1
3 Sub-record type "v"	A1
4-10 Filter sensitivity	bSx.xxx
11-17 Floating filter low value	bSx.xxx
18-24 Floating filter high value	bSx.xxx
25-31 Transition rate maximum	bSx.xxx
32-33 Carriage return, line feed	

POSITION FILTER PARAMETERS

Syntax: x[F],[FLOW],[FHIGH],[FACTOR]<>

Class: configuration

Purpose: This command establishes the sensitivity, boundary, and transition control parameters for the adaptive filter that operates on the position outputs of the tracking system. By means of this command, the user can adjust these parameters to fine-tune the overall dynamic response of any system that includes the tracker as a serial component. The four user-adjustable parameters are designated F, FLOW, FHIGH and FACTOR in the command syntax above.

The filter is a single-pole low-pass type with an adaptive pole location (i.e., a floating filter "parameter/ variable"). The pole location is constrained within the boundary values FLOW and FHIGH but is continuously self-adaptive between these limits as a function of the sensitivity parameter F and the sensed (ambient noise plus translational rate) input conditions.

For input "rate" conditions that fall within the adaptive range, the adaptive feature varies the pole location between the FLOW and FHIGH limits so as to minimize the output resolution for static inputs while minimizing the output lag for dynamic inputs. Whenever the input conditions cause the filter to make a transition to a narrower bandwidth (i.e.,

increased filtering), the transition rate of the pole location is constrained to a maximum allowable rate by the parameter FACTOR. The functions of the four adjustable parameters and their allowable value ranges are further detailed below. If all of the optional parameters are omitted, the current value of each parameter is returned to the caller as an output record of type "x".

F a scalar value that establishes the sensitivity of the filter to dynamic input conditions by specifying the proportion of new input data to recent average data that is to be used in updating the floating filter parameter/ variable

Allowable range of values:
 $0 < F < 1$

FLOW a scalar value that specifies the maximum allowable filtering to be applied to the outputs during periods of relatively static input conditions. Setting this value to 1.0 disables the filter completely.

Allowable range of values:
 $0 < \text{FLOW} < \text{FHIGH}$

FHIGH a scalar value that specifies the minimum allowable filtering to be applied to the outputs during periods of highly dynamic input conditions.

Allowable range of values: FLOW <
FHIGH < 1

FACTOR a scalar value that specifies the maximum allowable transition rate from minimum filtering (for highly dynamic input conditions) to maximum filtering (for relatively static input conditions) by proportionately limiting the decay to the low filter limit whenever the input conditions effect a transition to a narrower bandwidth.

Allowable range of values:
0 < FACTOR < 1

When the form of the command is x,1<> the position filter is disabled. This is the system default configuration.

Relatives: none

Note: The default mode for all filter parameters is OFF. Although these parameters are a function of the user's particular environment, the following settings may be used as a "jumping-off" point for determining optimum filtering in your particular environment.

F Set to 0.2

FLOW Set to 0.2

FHIGH Set to 0.8

FACTOR Set to 0.8

POSITION FILTER PARAMETERS

RECORD IDENTIFIER x
INITIATING COMMAND x

byte(s)	Identification	Format
1	... Record type, "2"	A1
2	... Blank	A1
3	... Sub-record type "x"	A1
4-10	... Filter sensitivity	bSx.xxx
11-17	... Floating filter low value	bSx.xxx
18-24	... Floating filter high value	bSx.xxx
25-31	... Transition rate maximum	bSx.xxx
32-33	... Carriage return, line feed	

SET SYNCHRONIZATION MODE

Syntax: y[smode]<>

Class: configuration

Purpose: This command allows the host to set the system synchronization mode. If the optional parameter is omitted the system returns the current value of the synchronization mode as an output record of type "y". The specific parameters are:

smode 0 signifies that the system is synced internally (8.3 milliseconds/cycle).

1 signifies that the system is externally synced to another Tracker system/external source.

2 signifies that the system is synced via a video frequency pickup coil.

Relatives: none.

SYNCHRONIZATION MODE

RECORD IDENTIFIER y

INITIATING COMMAND y

byte(s)	Identification	Format
1	Record type, "2"	A1
2	Blank	A1
3	Sub-record type "y"	A1
4	Synchronization mode	I1
	0 - none - free run	
	1 = External	
	2 = CRT	
5-6	Carriage return, line feed	

EEPROM

Description: EEPROM (Electrically Erasable Programmable Read Only Memory) is memory that can be altered by the system, but is not lost when the power is turned off. System variables are stored in the EEPROM. All of these variables are assigned user default values. The user default values are assigned to the variables at power-up and system reset. The values assigned to these variables at the factory are called the factory defaults, and these are the values initially assigned as the user defaults or can be re-assigned with appropriate use of the W command. In order to assign new user default values, the user must first set the desired variables to the new values, then execute the command SAVE MACHINE STATE (^K).

It is not necessary to execute the SAVE MACHINE STATE for each variable set. For example, if the user wishes to establish new default values for alignment and increment, all of the respective commands are executed first, followed by a single execution of the EEPROM BURN.

Commands: ^K, ^Y, W, X

Default: EEPROM is initially programmed with the factory default data.

SAVE OPERATIONAL CONFIGURATION

Syntax: ^K

Class: standard

Purpose: This command will cause the current state of the system configuration parameters to be saved in the EEPROM. This state is henceforth the power up state until another <ctrl K> is issued. **There may be a short pause of several seconds while the system executes this command.**

Relatives: ^Y, W, X

REINITIALIZE SYSTEM

Syntax: ^Y

Class: standard

Purpose: Reinitializes the entire system to the power up state. **The user should allow sufficient time for the system to run through its self test and initialization.**

Relatives: ^K, W, X

RESET SYSTEM TO DEFAULTS

Syntax: W

Class: configuration

Purpose: This command resets all of the system EEPROM variables to their factory default values. When invoked, the ^K command must be used to permanently set the EEPROM and the instrument reset using the ^Y command.

Relatives: ^K, ^Y, X

Note: This command should only be used after consultation with the factory.

CONFIGURATION CONTROL DATA

Syntax: X[string]<>

Class: configuration

Purpose: A maximum of 32 ASCII characters may be entered as configuration control data in EEPROM with this command. The <ctrl K> command must be used to save the EEPROM data. If the optional parameter is omitted the system returns the current value of the configuration control data. The specific parameters are:

string a maximum of 32 ASCII characters to identify the configuration for the user. This is output in both the "X" and "S" records

Relatives: ^K, ^Y, W

Note: Resetting the EEPROM with the "W" command alters the contents of this data area to "Factory Default CPG2030-003-01".

CONFIGURATION IDENTIFICATION

RECORD IDENTIFIER X

INITIATING COMMAND X

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Blank	A1
3 Sub-record type "X"	A1
4-35 Configuration identification	A32
36-37 Carriage return, line feed	

ENVELOPE

Description: Envelope refers to the X, Y, Z, azimuth, elevation, and roll limits in which the receiver is allowed to operate. Movement of the receiver outside these limits results in a software bit error in the output record. Refer to Section 6.10 for the definition of the software bit errors. All coordinates are given in the receiver reference frame. The units of the coordinates are interpreted according to the units flag as set by the "U" or "u" command. Refer to Figure 9.

Range: No range enforced.

Commands: Q, V

ANGULAR OPERATIONAL ENVELOPE

Syntax: Qs,[amax],[emax],[rmax],[amin],
[emin],[rmin]<>

Class: configuration

Purpose: The angular operational envelope is established with this command. This command may be used to impose software angular limits on the system outputs and may be used to avoid driving slaved gimbaled systems into the hard gimbal stops. If outputs are outside the limits defined by this command, the outputs are flagged with a "y" BIT error. If all of the optional parameters are omitted the system returns the current value of the parameters. The specific parameters are:

s the number of the station whose angular limits are to be returned or established.

amax the maximum azimuth value for the angular operational envelope.

emax the maximum elevation value for the angular operational envelope.

rmax the maximum roll value for the angular operational envelope.

amin the minimum azimuth value for the angular operational envelope.

emin the minimum elevation value for the

angular operational envelope.

rmin the minimum roll value for the angular operational envelope.

If any of the parameters are omitted the current value of that parameter is used. The system default values are:

180, 90, 180, -180, -90, -180

Relatives: V

ANGULAR OPERATIONAL ENVELOPE

RECORD IDENTIFIER Q
INITIATING COMMAND Q

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Station number	A1
3 Sub-record type "Q"	A1
4-12 Maximum azimuth value	Sxxx.xxxb
13-21 Maximum elevation value	Sxxx.xxxb
22-30 Maximum roll value	Sxxx.xxxb
31-39 Minimum azimuth value	Sxxx.xxxb
40-48 Minimum elevation value	Sxxx.xxxb
49-57 Minimum roll value	Sxxx.xxxb
58-59 Carriage return, line feed	

POSITION OPERATIONAL ENVELOPE

Syntax: Vs,[xmax],[ymax],[zmax],[xmin],
[ymin],[zmin]<>

Class: configuration

Purpose: The position operational envelope is established with this command. If outputs are outside the limits defined by this command, the outputs are flagged with a "x" BIT error. If all of the optional parameters are omitted the system returns the current value of the parameters. If some of the parameters are present the command fixes those limits. The specific parameters are:

- s the number of the station whose position limits are to be returned or established.
- xmax the maximum x-coordinate for the position operational envelope.
- ymax the maximum y-coordinate for the position operational envelope.
- zmax the maximum z-coordinate for the position operational envelope.
- xmin the minimum x-coordinate for the position operational envelope.
- ymin the minimum y-coordinate for the position operational envelope.

zmin the minimum z-coordinate for the
position operational envelope.

If any of the parameters are omitted the
current value of that parameter is used.
The system default values are:

200,200,200,-200,-200,-200 in centimeters

Relatives: Q

POSITION OPERATIONAL ENVELOPE

RECORD IDENTIFIER V
INITIATING COMMAND V

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Station number	A1
3 Sub-record type "V"	A1
4-11 Maximum x-coordinate value	Sxxx.xxx
12-19 Maximum y-coordinate value	Sxxx.xxx
20-27 Maximum z-coordinate value	Sxxx.xxx
28-35 Minimum x-coordinate value	Sxxx.xxx
36-43 Minimum y-coordinate value	Sxxx.xxx
44-51 Minimum z-coordinate value	Sxxx.xxx
52-53 Carriage return, line feed	

HEMISPHERE

Description: Because of the symmetry of the magnetic fields generated by the transmitter, there are two mathematical solutions to each set of receiver data processed. Therefore, only half of the total spatial sphere surrounding the transmitter is practically used at any one time without incurring an ambiguity in X, Y, Z measurements. This half sphere is referred to as the current hemisphere. The chosen hemisphere is defined by an LOS (line-of-sight) vector from the transmitter through a point at the zenith of the hemisphere, and is specified by the LOS direction cosines. Refer to Figure 10.

Range: -1 <= # <= +1

Commands: H

Default: The transmitter reference frame X-axis defines the default hemisphere.

Figure 10. System Hemisphere

HEMISPHERE OF OPERATION

Syntax: Hstation,[p1],[p2],[p3]<>

Class: configuration

Purpose: The operational hemisphere for a particular station is established with this command. The parameters are:

station the number of the station whose operational hemisphere is to be fixed.

p1 the x-component of a vector pointing in the direction of the operational hemisphere.

p2 the y-component of a vector pointing in the direction of the operational hemisphere.

p3 the z-component of a vector pointing in the direction of the operational hemisphere.

If all the optional parameters are omitted the system will return the vector components for the hemisphere of operation for the specified station as an output record of type "H".

The default value is:

1, 0, 0

Relatives: none

HEMISPHERE OF OPERATION

RECORD IDENTIFIER H
INITIATING COMMAND H

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Station number	A1
3 Sub-record type "H"	A1
4-10 Vector x-component	Sxx.xxx
11-17 Vector y-component	Sxx.xxx
18-24 Vector z-component	Sxx.xxx
25-26 Carriage return, line feed	

INCREMENT

Description: Increment refers to the minimum receiver movement necessary before a data record is transmitted.

Range: No limit enforced.

Commands: I

Default: 0.0 ; i.e., no movement necessary.

DEFINE INCREMENT

Syntax: Istation,[distance]<>

Class: configuration

Purpose: This command allows the host to define the increment. If the optional parameter is missing, the current increment value is retrieved for the specified station. Refer to Increment Definition for the format of the INCREMENT RECORD. The parameters are:

station the number of the station whose increment is to be changed.

distance the minimum distance a receiver must move before a data record is output to the host computer. If the optional parameter is omitted the system returns the current distance value. The units of distance must be consistent with the current system units - inches or centimeters. Default is 0.0 inches.

Relatives: none

INCREMENT DEFINITION

RECORD IDENTIFIER I

INITIATING COMMAND I

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Station number	A1
3 Sub-record type "I"	A1
4-10 Distance required to move	Sxxx.xx
11-12 Carriage return, line feed	

SYSTEM OUTPUT DEFINITION

Description: System output definition is accomplished by many commands. The following command sets affect the various output possibilities:

OUTPUT LIST,
OUTPUT FORMAT,
OUTPUT TRANSMIT MODE,
OUTPUT UNITS and,
OUTPUT START / STOP,
OUTPUT PORT SETTINGS.

With the various commands available from these command sets, a multitude of output possibilities may be tailored to each user's requirements. The output command sets follow. Note that outputs may also be affected by the previously mentioned "I" (Increment) command.

OUTPUT LIST

Description: The output list refers to the subset of data items to be included in a data record. Any combination of up to 32 data items that total less than or equal 125 bytes is permissible. See the "O" command for a list of data items.

Commands: O

OUTPUT DATA LIST

Syntax: Ostation,[p1],[p2],...,[pn]<>

Class: configuration

Purpose: This command allows the user to define the list of variables to be output to the host computer for the specified station. Any combination of up to 32 data items that total less than or equal 254 bytes is permissible. The allowable values of the parameters are:

- 0 ASCII space character
- 1 ASCII carriage return, line feed pair
- 2 x,y,z cartesian coordinates of position
- 3 relative movement, x,y,z cartesian coordinates of position; i.e., the difference in position from the last output. This item should only be selected if the specified station's Increment is = 0.0. See the "I" command.
- 4 az,el,roll Euler orientation angles
- 5 x direction cosines of the receiver's x,y,z axes - See Note 1.
- 6 y direction cosines of the receiver's x,y,z axes - See Note 1.
- 7 z direction cosines of the receiver's x,y,z axes - See Note 1.
- 8 x-receiver data (factory use only)
- 9 y-receiver data (factory use only)
- 10 z-receiver data (factory use only)
- 11 orientation quaternion

- 12 self calibration data (factory use only)
- 13 adjusted x-receiver data (factory use only)
- 14 adjusted y-receiver data (factory use only)
- 15 adjusted z-receiver data (factory use only)
- 16 stylus switch status
- 17 not used for Tracker
- 18 16-BIT binary x,y,z cartesian coordinates of position (see 16BIT notation)
- 19 16-BIT binary az,el,roll Euler orientation angles (see 16BIT notation)
- 20 16-BIT binary orientation quaternion (see 16BIT notation)
- 21-49 not used (reserved for future use)

Extended precision (50-66)

- 50 ASCII space character (same as 0)
- 51 ASCII carriage return, line feed pair (same as 1)
- 52 x,y,z cartesian coordinates of position
- 53 relative movement - x,y,z cartesian coordinates of position; i.e., the difference in position from the last output. This item should only be selected if the specified station's Increment is = 0.0. See the "I" command.
- 54 az,el,roll Euler orientation angles
- 55 x direction cosines of the

receiver's x, y, z axes - See Note
1.
56 y direction cosines of the
receiver's x, y, z axes - See Note
1.
57 z direction cosines of the
receiver's x, y, z axes - See Note
1.
58 x-receiver data (factory use only)
59 y-receiver data (factory use only)
60 z-receiver data (factory use only)
61 orientation quaternion
62 self calibration data
63 adjusted x-receiver data (factory
use only)
64 adjusted y-receiver data (factory
use only)
65 adjusted z-receiver data (factory
use only)
66 stylus switch status
67 not used for Tracker

68-98 not used (reserved for future use)
99 not used for Tracker

If all of the optional parameters are
omitted, the system returns the current
list of selected data items as an output
record of type "O".

Relatives: none

Default: 01,2,4,1<>; i.e., the three Cartesian
coordinates, the three orientation angles,
carriage return, and line feed for station
1.

NOTE 1 Items 5, 6, and 7 or 55, 56, and 57 may be obtained to construct the line-of-sight, line-of-hear, and line-of-plumb vectors as follows:

Three (3) values are obtained from each item above.

Item 5 or 55 = | 5a 5b 5c | | 55a 55b 55c |
Item 6 or 56 = | 6a 6b 6c | or | 56a 56b 56c |
Item 7 or 57 = | 7a 7b 7c | | 57a 57b 57c |

Then the a-column above is the line-of-sight vector,
the b-column above is the line-of-hear vector, and
the c-column above is the line-of-plumb vector.

OUTPUT ITEM LIST

RECORD IDENTIFIER 0
INITIATING COMMAND 0

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Station number	A1
3 Sub-record type "0"	A1
4-5 Data item 01 identification	I2
6-7 Data item 02 identification	I2
8-9 Data item 03 identification	I2
.	
.	
2*n+2 -		
2*n+3 Data item n identification	I2
2*n+4 -		
2*n+5 Carriage return, line feed	

SYSTEM DATA RECORD, ASCII FORMAT

RECORD IDENTIFIER none
INITIATING COMMANDS P or in continuous mode

Item	byte(s)	Identification	Format
1	..	Record type, "0"	A1
2	..	Station Number	A1
3	..	System Error Code (See note 2)	A1

Original Precision:

0 or 50	?* ..	ASCII space character	A1
1 or 51	?* ..	Carriage re- turn, line feed	
2	?* ..	x,y,z position cartesian coordinates	3(Sxxx.xx)
4	?* ..	az,el,roll Euler orienta- tion angles	3(Sxxx.xx)
5	?* ..	X-direction cosines of the receiver's x, y,z axes. See Note 3.	3(Sx.xxxx)
6	?* ..	Y-direction cosines of the receiver's x, y,z axes. See	3(Sx.xxxx)

7	?* ..	Note 3. Z-direction cosines of the receiver's x, y,z axes. See Note 3.	3(Sx.xxxx)jk
11	?* ..	Orientation Quaternion (Q0-Q3)	4(Sx.xxxx)
16	?* ..	Stylus Switch	bx where: x = 0 or 1

Extended precision:

52	?* ..	x,y,z position cartesian coordinates	3(Sx.xxxxxxESxxb)
54	?* ..	az,el,roll Euler orienta- tion angles	3(Sx.xxxxxxESxxb)
55	?* ..	X-direction cosines of the receiver's x, y,z axes. See Note 3.	3(Sx.xxxxxxESxxb)
56	?* ..	Y-direction cosines of the receiver's x, y,z axes. See Note 3.	3(Sx.xxxxxxESxxb)
57	?* ..	Z-direction cosines of the receiver's x, y,z axes. See Note 3.	3(Sx.xxxxxxESxxb)
61	?* ..	Orientation Quaternion (Q0-Q3)	4(Sx.xxxxxxESxxb)

66	?* ..	Stylus Switch	bx where: x = 0 or 1
----	-------	---------------	-------------------------

Factory use only:

8-10
12-49
58-60
62-65
67-69

* The system data record contents are specified by the user using the "O" command and may vary from configuration to configuration. Therefore, the specific location of a data item in the output record is not determined until the record contents are defined.

Note 1. Original precision is retained for compatibility with previous Polhemus 3SPACE systems. Also note that some item values are repeated as extended precision items, although no output difference is made (i.e., space, <cr lf>. Original and extended precision may be freely mixed in an output record, but it is recommended that extended precision be used if compatibility is not required, as the original precision may be deleted in future systems.

Note 2. This code will in general output the last error that the system BIT (Built In Test) routines found prior to the output of this system data record. If any BIT clearing has been commanded (see the "T" command), the system will search for an error that is currently set, starting at the largest numeric error code value, and then output the first error code found

in the search that is set. See the "T" command for specified definitions of each error code.

Note 3. Items 5, 6, and 7 or 55, 56, and 57 may be obtained to construct the line-of-sight, line-of-hear, and line-of-plumb vectors as follows:

Three (3) values are obtained from each item above.

Item 5 or 55 = | 5a 5b 5c | | 55a 55b 55c |
Item 6 or 56 = | 6a 6b 6c | or | 56a 56b 56c |
Item 7 or 57 = | 7a 7b 7c | | 57a 57b 57c |

Then the a-column above is the line-of-sight vector,
the b-column above is the line-of-hear vector, and
the c-column above is the line-of-plumb vector.

SYSTEM DATA RECORD, IEEE FLOATING-POINT FORMAT

RECORD IDENTIFIER none
INITIATING COMMANDS P or in continuous mode

byte(s)	Identification	Format
1	Record type, "0"	A1
2	Station Number	A1
3	System error code (See Note 2 on previous page.)	A1
?*	ASCII space character	A1
?*	Carriage return, line feed	
?*	x,y,z position cartesian coordinates	3(SingleFP)
?*	az,el,roll Euler orientation angles	3(SingleFP)
?*	X-direction cosines of the receiver's x,y,z axes. See Note 1.	3(SingleFP)
?*	Y-direction cosines of the receiver's x,y,z axes. See Note 1.	3(SingleFP)
?*	Z-direction cosines of the receiver's x,y,z axes. See Note 1.	3(SingleFP)
?*	X-receiver data	3(SingleFP)
?*	Y-receiver data	3(SingleFP)
?*	Z-receiver data	3(SingleFP)
?*	Orientation Quaternion 4(SingleFP) (Q0-Q3)	
?*	X-receiver corrected	3(SingleFP)

```

values
?* ..... Y-receiver corrected      3(SingleFP)
values
?* ..... Z-receiver corrected      3(SingleFP)
values
?* ..... Self Calibration Data     9(SingleFP)

*****

?*      The system data record contents are
        specified by the user using the "O" command
        and may vary from configuration to
        configuration. Therefore, the specific
        location of a data item in the output
        record is not determined until the record
        contents are defined.

```

NOTE 1 Items 5, 6, and 7 or 55, 56, and 57 may be obtained to construct the line-of-sight, line-of-hear, and line-of-plumb vectors as follows:

Three (3) values are obtained from each item above.

```

Item 5 or 55 = | 5a 5b 5c | | 55a 55b 55c |
Item 6 or 56 = | 6a 6b 6c | or | 56a 56b 56c |
Item 7 or 57 = | 7a 7b 7c | | 57a 57b 57c |

```

Then the a-column above is the line-of-sight vector,
the b-column above is the line-of-hear vector, and
the c-column above is the line-of-plumb vector.

```

SYSTEM DATA RECORD, 16-BIT BINARY FORMAT
*****

RECORD IDENTIFIER ..... none
INITIATING COMMANDS ..... P or in continuous mode

```

byte(s)	Identification	Format
1	Record type, "0"	A1
2	Station Number	A1
3	Error code	A1
?*	x,y,z position cartesian coordinates	3(16BIT)
?*	az,el,roll Euler orientation angles	3(16BIT)
?*	Orientation Quaternion Values	4(16BIT)
?*	Any format from an ASCII or IEEE format may also be included in this record. (See these formats on previous pages.) Care should be taken not to delete the usefulness of the sync bit discussed below.	

```

?*      The system data record contents are
        specified by the user using the "O" command
        and may vary from configuration to
        configuration. Therefore, the specific
        location of a data item in the output
        record is not determined until the record
        contents are defined.

```

The notation 16BIT is a special binary output format reserved for those users that need less accurate, but faster I/O. It contains only 14 bits of accuracy and is output in the following format without respect to the "F" (ASCII) or "f" (binary) command setting:

This format is limited to X,Y,Z position (item 18 in the "O" command) and AZ, EL, Roll Euler orientation angles (item 19 in the "O" command), and the unit-less four (4) values of the Orientation Quaternion (item 20 in the "O" command). Data format is 2's-complement. Each 8-bit byte of the 16 bit data will have its high-order bit set to zero, except for the lead-ing data byte, which is set to 1, as a "sync" bit, in the data that is output in this format.

Two things must be noted here: First, the "sync" bit is in the fourth byte of the data record and not a part of the three byte record header. Secondly, this "sync" bit is only valid if the output is limited (by specifying in the "O" command) to only those items that are guaranteed not to contain a high order bit set to 1. The data is output low-order byte first.

For positive values, position (X,Y,Z) full scale is +299.963 cm, which equates to +118.096 inches. For orientation angles, full scale is +179.978 degrees and the quaternion values of 0.999.

```

                Lo byte
            -----
            Hi byte
            -----
            | X | 1 | 1 | 1 | 1 | 1 | 1 | 1 |      | 0 | 0 | 1 | 1 |
            | 1 | 1 | 1 | 1 |      |      |      |      |
            ^
            ^-- sign bit
                |--- 0 or 1 for sync
    
```

This equates to xx011111 11111111 or full scale positive number of +299.963 cm, which equates to +118.096 inches. For orientation angles, full scale is +179.978 degrees.

For negative values, position (X,Y,Z) full scale is -300 cm, which equates to -118.110 inches. For orientation angles, full scale is -180 degrees. For the quaternion values, full scale is -1.

```

                Lo byte
            -----
            Hi byte
            -----
            | X | 0 | 0 | 0 | 0 | 0 | 0 | 0 |      | 0 | 1 | 0 | 0 |
            | 0 | 0 | 0 | 0 |      |      |      |      |
            ^
            ^-- sign bit
                |--- 0 or 1 for sync
    
```

This equates to xx100000 00000000 or full scale negative number of -300.000 cm, -118.110 inches, or -180.000 degrees, or a 1.000 quaternion value.

OUTPUT FORMAT

Description: Format refers to the method by which data is coded. ASCII format means that the data is generally human readable, while binary is generally computer readable. The data format controls only the output format. **All input to the system must be ASCII.** Binary format output is in accordance with the format specified by ANSI/IEEE Std 754-1985 Specification for Binary Floating Point Arithmetic. The current data format may be retrieved from the STATUS RECORD. Refer to the "S" (System Status) command.

Default: The default output data format is ASCII.

Commands: F, f

ENABLE ASCII OUTPUT FORMAT

Syntax: F

Class: configuration

Purpose: When this command is active all data transmitted through the system serial or parallel port will be in ASCII format. Default is active.

Relatives: f

ENABLE BINARY OUTPUT FORMAT

Syntax: f

Class: standard, configuration

Purpose: Sets the output data format to binary.
Subsequent data record items are output in
accordance with the format specified by
ANSI/IEEE Std 754-1985 Specification for
Binary Floating Point Arithmetic. Default
is ASCII formatted records.

Relatives: F

OUTPUT PORT SETTINGS

Description: The system RS-232 BAUD rate, parity, and
number of bits per character may be
established to specified values.

Default: Based on I/O switch settings.

Commands: o

SET OUTPUT PORT

Syntax: orate,parity,bits,HHS<>

Class: standard

Purpose: Sets the output BAUD rate for RS-232 port to a specified rate. The parameters are:

rate may be specified as follows:

3	=	300,
12	=	1200,
24	=	2400,
48	=	4800,
96	=	9600,
192	=	19200,
384	=	38400,
576	=	57600, or
1152	=	115200

parity N = none, O = Odd, E = even

bits 7 or 8

HHS Set to 1, enables use of hardware handshake (RTS, CTS)

Set to 0, disables use of hardware handshake

Note 1. The number of stop bits is always one (1).

Note 2. For seven (7) bits, parity may be NONE, ODD, or EVEN. For eight (8) bits there is never a parity bit; i.e., NONE.

Note 3. 8 data bits are required when using either the standard binary format or the 16 BIT format.

Default: Based on I/O switch settings.

Relatives: none

OUTPUT TRANSMIT MODE

Description: Transmit mode refers to whether the system automatically transmits a data record when it is ready (CONTINUOUS), or the host must request each data record by sending a "P" command to the system (NON-CONTINUOUS). The current transmit mode may be retrieved from the status record. Refer to Section 6.0 for the format of the STATUS RECORD.

Default: NON-CONTINUOUS.

Commands: C, P, c

CONTINUOUS PRINT OUTPUT

Syntax: C

Class: configuration

Purpose: This command enables the continuous print output mode for the system serial port. Default is non-continuous.

Relatives: c, P

SINGLE RECORD TRANSMISSION

Syntax: P

Class: standard

Purpose: When continuous print has been disabled,
request that a single data record be
transmitted to the host computer. If more
than one station is active, one record for
each of the active stations will be
transmitted.

Relatives: C, c

DISABLE CONTINUOUS PRINTING

Syntax: c

Class: configuration

Purpose: Disable continuous output to the host
computer. Default value is active.

Relatives: C, P

INPUT/OUTPUT UNITS

Description: Input/Output Units is a reference to the **distance** unit assumed by the system when interpreting input and generating output data. The current distance unit may be retrieved by the host from the status record. Refer to the S command in this section.

Default: Inches (absolute)

Commands: U, u

SET UNITS INCHES

Syntax: U

Class: standard, configuration

Purpose: Sets the **distance** unit to inches. Subsequent input and output lengths are interpreted as inches. System default is inches.

Relatives: u

METRIC CONVERSION UNITS

Syntax: u

Class: standard, configuration

Purpose: Sets the **distance** units to centimeters.
 Subsequent inputs and outputs are
 interpreted as centimeters. The system
 default is inches.

Relatives: U

OUTPUT START/STOP (XON/XOFF)

Description: Output start/stop is a pseudo
 implementation of the RS-232 XON/XOFF
 protocol. The commands start and stop
 the transmission of data from the RS-232
 device.

Default: XON (Enabled)

Commands: ^S, ^Q

SUSPEND DATA TRANSMISSION

Syntax: ^S

Class: standard

Purpose: Suspends data transmission to the host device until a subsequent ^Q is received. If a previous ^S command has been issued, without an intervening ^Q, this command will have no effect.

Relatives: ^Q

RESUME DATA TRANSMISSION

Syntax: ^Q

Class: standard

Purpose: Resumes data transmission to the host device following suspension of transmission by a ^S command. If a previous ^Q command has been issued, without an intervening ^S, this command will have no effect.

Relatives: ^S

STATIONS

Description: A station is a transmitter-receiver pair. The four receivers paired with the one available transmitter are assigned station numbers one through four (1-4). Stations may be activated or deactivated. If a station is active, data records are transmitted for that station; otherwise, no data records for that station are transmitted. At least one station must always be active.

Default: Rcvr Select Switch determines the available power-up active receivers.

Commands: 1

ACTIVE STATION STATE

Syntax: 1station,[state]<>

Class: standard

Purpose: Set the on/off station state. If the optional parameter is missing, the system returns the current state for the specified station as an output record of type "1". The parameters are:

Station FASTRAK
1 to 4 depending on
configuration.

state 0 = off
1 = on

Relatives: none

ACTIVE STATION STATE

RECORD IDENTIFIER 1
INITIATING COMMAND 1

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Station number	A1
3 Sub-record type "1"	A1
4 Station 1 = 1 if active, else 0	A1
5 Station 2 = 1 if active, else 0	A1
6 Station 3 = 1 if active, else 0	A1
7 Station 4 = 1 if active, else 0	A1
8-9 Carriage return, line feed	

STATUS

Description: Status refers to the capability to determine information about the system that is not available from other commands.

Commands: S, T

SYSTEM STATUS RECORD

Syntax: S

Class: standard

Purpose: Requests that a system status record be transmitted to the host computer.

Relatives: T

SYSTEM STATUS

RECORD IDENTIFIER S

INITIATING COMMAND S

byte(s)	Identification	Format
1 Record type, "2"	A1
2 Station number	A1
3 Sub-record type "S"	A1
4-6 System flags	H3
	LSBit	
0	... Output Format (0=ASCII, 1=Binary)	
1	... Units (0=Inches, 1=Centimeters)	
2	... Compensation (0=Off, 1=ON)	
3	... Transmit Mode (0=Non-Continuous, 1=Continuous)	
4	... Configuration (1=Tracker)	
5	... Always 1 (reserved for future use)	
6-9	... Reserved	
10-23	... Reserved for future use	
	MSBit	
7-9 BIT error	I3
10-15 Blank (Reserved for future use)	A6
16-21 Software Version ID	A6
22-53 System Identification (See "X")	A32
54-55 Carriage return, line feed	

INSTRUMENT CONFIGURATION STATUS - "S" Command

For those customers who are uninitiated in decoding bit information, the instrument's configuration status is contained as a hexadecimal number in the fourth, fifth, and sixth columns of the "S" command output. The following table lists the hexadecimal number and corresponding instrument configuration.

HEX #	<u>Instrument Configuration</u>			
	<u>Continuous</u>	<u>Compensation</u>	<u>Units</u>	<u>Output</u>
3FF	On	On	Cm.	Binary
3FE	On	On	Cm.	ASCII
3FD	On	On	In.	Binary
3FC	On	On	In.	ASCII
3FB	On	Off	Cm.	Binary
3FA	On	Off	Cm.	ASCII
3F9	On	Off	In.	Binary
3F8	On	Off	In.	ASCII
3F7	Off	On	Cm.	Binary
3F6	Off	On	Cm.	ASCII
3F5	Off	On	In.	Binary
3F4	Off	On	In.	ASCII
3F3	Off	Off	Cm.	Binary
3F2	Off	Off	Cm.	ASCII
3F1	Off	Off	In.	Binary
3F0	Off	Off	In.	ASCII

BUILT-IN-TEST INFORMATION

Syntax: TBITnbr[,0]<>

Class: standard

Purpose: This command allows the user to obtain additional information about a particular BIT and clear a bit error. This additional information is meaningful only to factory personnel. The "T" command is useful to attempt to clear a problem; however, if an error re-occurs, and after you have verified your setup configuration, consultation with the factory is recommended. The system returns the current BIT information for the specified BIT as an output record of type "T". The parameters are:

BITnbr The BIT number for which added information is requested (see below).

0 This parameter, if used, is specified as a 0 (zero). If present the BITnbr specified is reset/cleared.

Relatives: S

BITnbrs, associated output codes and their meanings are defined as follows:

BITnbr Code Transmitter & Receiver Error Codes

65	A	X Driver Linearity
66	B	Y Driver Linearity
67	C	Z Driver Linearity
68	D	x Gain Linearity
69	E	y Gain Linearity
70	F	z Gain Linearity
71	G	X Slope of Driver X Linearity Line
72	H	Y Slope of Driver Y Linearity Line
73	I	Z Slope of Driver Z Linearity Line
74	J	X Slope of Coil / Receiver X Linearity
75	K	Y Slope of Coil / Receiver Y Linearity
76	L	Z Slope of Coil / Receiver Z Linearity
77-83		Not Used (Reserved for future use)
84	T	Receiver PROM Error
85	U	Transmitter PROM Error
86	V	Receiver PROM Circuit Error
87	W	Transmitter PROM Circuit Error
88	X	Driver Characterization Validity
89	Y	Receiver Characterization Validity
90	Z	Receiver Coil Validity

BITnbr Code Self Calibration Error Codes

97	a	X Driver Limits Self-Calibration
98	b	Y Driver Limits Self-Calibration
99	c	Z Driver Limits Self-Calibration
100	d	x Gain Limits Self-Calibration
101	e	y Gain Limits Self-Calibration
102	f	z Gain Limits Self-Calibration
103	g	Coil Limits Self-Calibration
104	h	Not Used in FASTRAK

BITnbr Code Signal Matrix Error Codes

105	i	Not Used in FASTRAK
106	j	A Signal Saturation
107	k	A Low Signal
108	l	A Maximum Signal Element Zero

BITnbr Code EEPROM Error Codes

109	m	EEPROM Validity Checksum Error or Data Validity Discrepancy
110	n	Reserved for Future Use
111	o	Reserved for Future Use
112	p	Reserved for Future Use
113	q	Reserved for Future Use
114	r	Reserved for Future Use

BITnbr Code Soft Error Codes

115	s	Unit Normal Position Vector Reset (P/R- Norm)
-----	---	--

BITnbr Code Miscellaneous Error Codes

116	t	Compensation Structure Errors. Array Size Not In Specification Limits.
117	u	Compensation Point Not Within Mapped Bounds.
118	v	No CRT Sync Signal Available
119	w	Write Error on Configuration EEPROM.
120	x	Receiver Out of Motion Box.
121	y	Euler Angles Outside Allowed Angular Envelope.
122	z	Unused, Reserved.

BIT INFORMATION

RECORD IDENTIFIER T
INITIATING COMMAND T

byte(s)	Identification	Format
1	... Record type, "2"	A1
2	... Blank	A1
3	... Sub-record type "T"	A1
4-6	... BIT number	I3
7-??	... BIT information (Factory meaningful only)	A??
??-??	... Carriage return, line feed	

STYLUS

Description: Stylus refers to the tip definition and
button operation functions of the
Stylus.

Commands: N, e

DEFINE TIP OFFSETS

Syntax: Nstation,[xoff,yoff,zoff]<>

Class: Standard

Purpose: This command allows the user to override the factory defaults for the offsets of the receiver from the tip of a stylus. If the optional parameters are missing, the system returns the current tip offset for the specified station as an output record of type "N". The parameters are:

station = 1 for stylus

xoff x-direction tip offset

yoff y-direction tip offset

zoff z-direction tip offset

Default: This command can only override the factory default during the current operational session. Factory defaults are read on power-up.

Relatives: none

DEFINE STYLUS BUTTON FUNCTION

Syntax: e[station],fbutton<>

Class: Configuration

Purpose: This command allows the host to put a FASTRAK stylus into different output modes. The command parameters are defined as:

station the number of a station. Inclusion or omission of this parameter has NO effect on handling of this command. The parameter is retained for compatibility with other commands and products.

fbutton defines the function of the stylus button.

An entry of fbutton = 0 defines the output interaction as "mouse mode." The pushing of the stylus switch has no change on system output except that if the user has defined (by use of the "0" command) an output with item 16 (switch status), then the status of the switch is reported in the output record.

In this case a 1 is reported in the output record when the switch is pressed and a 0 when it is not pressed.

An entry of fbutton = 1 defines a pseudo "point" or "track" mode inter-action with the switch. In non-continuous mode of output, pressing the stylus switch has the same effect as sending a "P" command to the system (Point mode). In continuous output mode, pressing the stylus switch serves as a toggle for continuous output; i.e., the first time the switch is pressed, turns off output and the next pressing turns on continuous output (Track mode).

Default: System default is fbutton = 1 (point and track mode stylus interaction)

Relatives: None

6.10 Command Error

Command errors are defined as follows:

COMMAND ERROR

RECORD IDENTIFIER *

INITIATING COMMAND all invalid commands

byte(s)	Identification	Format
1	... Record Type, "2"	A1
2	... Blank	A1
3	... Sub-record type "E"	A1
4-10	... "*ERROR*"	
11-??	... Erroroneous command as it was input	
??-+11...	... "*ERROR* EC "	
??-??	... Error code from following list:	
	-1 Required field missing	
	-2 Required numeric is non-numeric	
	-3 Value is outside required range	
	-4 Specified frequency not hardware configured	
	-5 Internal buffer limits exceeded	
	-99 Undefined input - cannot identify command	
??-+3	... "*PS" (position)	
??-??	... Character position in the input record - note numbering starts 0,1,2...	
??-+3	... "*FL" (field)	

??-?? ... Field number causing the error - note
 numbering of the field is 0,1,2... and
 starts at '0' following the command
 identifier.
??-+3 ... "*ST" (station)
??-?? ... Number of the affected system station less
 1; i.e., this value ranges from 0-3,
 stations are numbered in commands as 1-4.

6.11 Default Operation with a Stylus or 3BALL

As noted in Section 5, the Stylus and 3BALL may only be operated in Port #1 as this port is the only one that will read a switch status. Operation of the switch on either the Stylus or 3BALL will cause the following actions as a function of the various FASTRAK commands and modes. No other actions are possible.

In NON-continuous output mode pressing the switch defines to the FASTRAK instrument a 'P' command, and all operations are as documented for issuing an RS-232 or IEEE-488 'P' command. Issuing a 'P' command via RS-232 or IEEE-488 still performs as documented.

When a 'C' command is entered via RS-232 or IEEE-488 to enable continuous mode, the instrument immediately responds with output as defined in the manual; however, when the Stylus/3BALL switch is pressed, output is interrupted (but this cycle is completed; i.e., all currently configured stations complete output for this cycle). The Stylus/3BALL switch then serves as a toggle for instrument output from then on until an RS-232 or IEEE-488 'c' command is issued. Each toggle will initiate or terminate a continuous stream of output that begins with station one (1) and terminates (by a subsequent switch pressing) with output for the last station in the cycle list.

Note that all output begins with the FIRST station (in the sequence 1, 2, 3, 4) that is configured ON and ends with the LAST station in the sequence list that is configured ON. Configured ON requires both a proper selection switch at power-on and NOT a current use of the "1" command, to change the receiver's state to OFF.

Increment functions as defined in this document. That is, if any receiver does NOT move, since its last cycle, by an amount equal to or greater than its defined increment, output is skipped for the receiver when the above actions cause an output.

A switch cycle takes 40 system cycles. At 8.33 msec per cycle, the switch is responsive at a speed of 333 msec or about 1/3 second. In other words, if the switch is held down while the system is in NON-continuous mode, an output cycle is generated as if a 'P' command is entered at the rate of 3/second. If the switch is pressed twice within the 333 msec window, the second pressing is ignored.

See the Define Stylus Button function ("e" Command) for other options and operational information.

7.0 LIMITED WARRANTY AND LIMITATION OF LIABILITY

7.1

PI warrants that the Systems shall be free from defects in material and workmanship for a period of one year from the date ownership of the System passed from PI to Buyer. PI shall, upon notification within the warranty period, correct such defects by repair or replacement with a like serviceable item at PI's option. This warranty shall be considered void if the System is operated other than in accordance with the instructions in PI's User Manual or is damaged by accident or mishandling. Parts or material which are clearly expendable or subject to normal wear beyond usefulness within the warranty period such as lamps, fuses, etc., are not covered by this warranty.

7.2

In the event any System or portion thereof is defective, Buyer shall, within the warranty period, notify PI in writing of the nature of the defect, remove the defective parts and, at the direction of PI, ship such parts to PI. Upon determination by PI that the parts or Systems are defective and covered by the warranty set forth above, PI, at its option shall repair or replace the same without cost to Buyer. Buyer shall pay all charges for transportation and delivery costs to PI's factory for defective parts where directed to be sent to PI, and PI shall pay for transportation costs to Buyer's facility only for warranty replacement parts and Systems. Removed parts covered by claims under this warranty shall become the property of PI.

7.3

In the event that allegedly defective parts are found not to be defective, or not covered by warranty, Buyer agrees that PI may invoice Buyer for all reasonable expenses incurred in inspect-ing, testing, repairing and returning the Systems and that Buyer will pay such costs on being invoiced therefor. Buyer shall bear the risk of loss or damage during transit in all cases.

7.4

Any repaired or replaced part or System shall be warranted for the remaining period of the original warranty or thirty (30) days, whichever is longer.

7.5

Warranties shall not apply to any Systems which have been:

- (a) repaired or altered other than by PI, except when so authorized in writing by PI.
- (b) used in an unauthorized or improper manner, or without following normal operating procedures; or
- (c) improperly maintained and where such activities in PI's sole judgement, have adversely affected the Systems. Neither shall warranties apply in the case of damage through accidents or acts of nature such as flood, earthquake, lightning, tornado, typhoon, power surge or failure, environmental extremes or other external causes.

7.6

PI DOES NOT WARRANT AND SPECIFICALLY DISCLAIMS THE

WARRANTY OF MERCHANTABILITY OF THE PRODUCTS OR THE WARRANTY OF FITNESS OF THE PRODUCTS FOR ANY PARTICULAR PURPOSE. PI MAKES NO WARRANTIES, EXPRESS OR IMPLIED, EXCEPT OF TITLE AND AGAINST PATENT INFRINGEMENT, OTHER THAN THOSE SPECIFICALLY SET FORTH HEREIN.

7.7

IN NO EVENT SHALL PI BE LIABLE UNDER ANY CIRCUMSTANCES FOR SPECIAL INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO LOSS OF PROFITS OR REVENUE. WITHOUT LIMITING THE FOREGOING PI'S MAXIMUM LIABILITY FOR DAMAGES FOR ANY CAUSE WHATSOEVER, EXCLUSIVE OF CLAIMS FOR PATENT INFRINGEMENT AND REGARDLESS OF THE FORM OF THE ACTION (INCLUDING BUT NOT LIMITED TO CONTRACT NEGLIGENCE OR STRICT LIABILITY) SHALL BE LIMITED TO BUYER'S ACTUAL DIRECT DAMAGES, NOT TO EXCEED THE PRICE OF THE GOODS UPON WHICH SUCH LIABILITY IS BASED.

8.0 INDEMNITY AGAINST PATENT INFRINGEMENT

PI shall have the right at its own expense, to defend or at its option to settle, any claim, suit or proceeding brought against Buyer on the issue of infringement of any United States patent by any product, or any part thereof, supplied by PI to Buyer under this Agreement. PI shall pay, subject to the limitations hereinafter set forth in this paragraph, any final judgment entered against Buyer on such issue in any such suit or proceeding defended by PI. PI at its sole option shall be relieved of the foregoing obligations unless Buyer notified PI promptly in writing of any such claim, suit or proceedings, and at PI's expense, gave PI proper and full information and assistance to settle and/or defend any such claim, suit or proceeding. If the product, or any part thereof, furnished by PI to Buyer becomes, or in the opinion of PI may become, the subject of any claim, suit or proceeding for infringement of any United States patent, or in the event of an adjudication that such product or part infringes any United States patent, or if the use, lease or sale of such product or part is enjoined, PI may, at its option and its expense: (a) procure for Buyer the right under such patent to use, lease or sell, as appropriate, such product or part, or (b) replace such product or part, or (c) modify such product, or part, or (d) remove such product or part and refund the aggregate payments and transportation costs paid therefore by the Buyer less a reasonable sum for use, damage and obsolescence. PI shall have no liability for any infringement arising from: (i) the combination of such product or part with any other product or part whether or not furnished to Buyer by PI, or (ii) the modification of such product or part unless such modification was made by PI, or (iii) the use of such product or part in practicing any process, or (iv) the

furnishing to Buyer of any information, data, service or application assistance. Buyer shall hold PI harmless against any expense, judgment or loss for infringement of any United States patents or trademarks which results from PI's compliance with Buyer's designs, specifications or instructions. PI shall not be liable for any costs or expense incurred without PI's written authorization and in no event shall PI's total liability to Buyer under, or as a result of compliance with, the provisions of this paragraph exceed the aggregate sum paid to PI by Buyer for the allegedly infringing product or part, exclusive of any refund under option (4) above. The foregoing states the entire liability of PI, and the exclusive remedy of Buyer, with respect to any actual or alleged patent infringement by such product or part.

9.0 CUSTOMER SERVICE

If you encounter any problems with your FASTRAK instrument, help is just a telephone call away. Call 802/655-3159 and ask for Customer Service. For the most part, our Customer Service engineers can handle your problems over the telephone and get you back into the fast lane right away. If the problem requires repair of your instrument, the Customer Service engineer will issue you a Return Merchandise Authorization (RMA) number. It is a good idea to keep the original shipping container for your FASTRAK instrument in the event that the instrument may require repair. Please do not return any instrument without an RMA number as it will not be accepted. If your instrument is still under warranty, Polhemus will repair it free of charge according to the provisions of the warranty as stated in Section 8 of this document. The proper return address is:

Polhemus Incorporated
1 Hercules Drive
P.O. Box 560
Colchester, Vermont 05446

Telephone (voice): (802) 655-3159
Telephone (FAX): (802) 655-1439

INDEX

Cmnd. Ltr	FASTRAK Title	Page
A	Alignment Reference Frame	46
B	Boresight	50
b	Unboresight	54
C	Continuous Print Output	118
c	Disable Continuous Printing	120
D	Enable Fixed Metal Compensation	56
d	Disable Fixed Metal Compensation	57
e	Define Stylus Button Function	141
F	Enable ASCII Output Format	112
f	Enable Binary Formatted Output	113
G	Boresight Reference Angles	52
H	Hemisphere of Operation	89
I	Define Increment	93
l	Active Station State	128
O	Output Data List	97
o	Set Output Port	115
N	Define Tip Offsets	140
P	Single Record Transmission	115
Q	Angular Operational Envelope	81
R	Reset Alignment Reference Frame	49
r	Transmitter Mounting Frame	58
S	System Status	131
T	Built-In-Test Information	134
U	Set Unit Inches	122
u	Metric Conversion Units	123
V	Position Operational Envelope	84
v	Attitude Filter Parameters	64
W	Reset System to Defaults	76
X	Configuration Control Data	77
x	Position Filter Parameters	65
y	Set Synchronization Mode	70

INDEX

Cmnd. Ltr	FASTRAK Title	Page
^K	Save Operational Configuration	74
^Q	Resume Data Transmission	126
^S	Suspend Data Transmission	125
^Y	Re-initialize System	75

GLOSSARY

Alignment Frame

The reference frame in which the position and orientation of the receiver is measured. The default alignment frame is the transmitter frame.

Attitude Matrix

A three-by-three matrix containing the direction cosines of the receiver's x axis in column one, the direction cosines of the receiver's y axis in column two, and the direction cosines of the receiver's z axis in column three. The order of the 3SPACE Euler angle rotation sequence is azimuth, elevation, and roll.

CA*CE	CA*SE*SR-SA*CR	CA*SE*CR+SA*SR
SA*CE	CA*CR+SA*SE*SR	SA*SE*CR-CA*SR
-SE	CE*SR	CE*CR
X direction cosines	Y direction cosines	Z direction cosines

where:

SA = Sin (azimuth), CA = Cos (azimuth)
SE = Sin (elevation), CE = Cos (elevation)
SR = Sin (roll), CR = Cos (roll)

Azimuth

(See Orientation Angles)

Boresight

Any procedure that rotates the receiver frame so as to precisely align the receiver to the designated reference frame.

In a 3SPACE system context, the term usually refers to the system software routine that, on command, performs a coordinate rotation which effectively aligns the receiver frame to a predefined boresight reference orientation.

Note that the boresight routine accomplishes the boresight orientation of the receiver regardless of the receiver's physical orientation at the instant of boresight initiation. So, for applications that require the orientation tracking of the body (or body member) to which the receiver is attached, a prerequisite to initiating the boresight function is a physical orientation of the body to be tracked to the boresight reference orientation.

Compensation Data

A set of invariable data that allows the 3SPACE to compensate for fixed distortions of the magnetic field due to the surrounding environment. The compensation data generally results from an application-specific distortion mapping procedure.

Direction Cosines

The cosines of the angles between the receiver's x, y, z axes and the X, Y, Z axes of the measurement reference (alignment) frame.

EEPROM

Electronically Erasable Programmable Read Only Memory. Memory that can be altered by the 3SPACE, but is not lost when the power is OFF. User default data is stored here, as well as the system identification data.

Elevation

(See Orientation Angles)

Factory Defaults

The values assigned to certain system variables by the factory. Stored in PROM, they are used to reinitialize the variables if EEPROM is lost.

Format

The interchange coding used to present data. The 3SPACE outputs either ASCII or BINARY data, but accepts only ASCII inputs from the host.

Hemisphere

Because of the inversion symmetry of the magnetic fields generated by the transmitter, there are two possible mathematical solutions for the X, Y, Z, position coordinates for each set of receiver data processed, and the 3SPACE is unable to determine which solution is the correct one without additional information. Therefore, only half of the total spatial sphere surrounding the transmitter can be utilized at any one time for unambiguous position measurement.

The selected hemisphere is referred to as the "current hemisphere." It is defined by an LOS (line-of-sight) vector from the transmitter through a point at the zenith of the hemisphere, and is specified by the direction cosines of the chosen LOS vector.

The orientation coordinates do not have a two-solution spherical ambiguity and are therefore valid throughout the operating sphere centered at the transmitter.

Host

Any device capable of supporting an RS-232C interface or the 3SPACE IEEE-488 parallel interface and capable of bi-directional data transmission. Devices may range from a dumb terminal to a mainframe computer.

Increment

The minimum movement necessary to cause the 3SPACE to transmit a record to the host.

Orientation Angles

The azimuth, elevation, and roll angles that define the current orientation of the receiver coordinate frame with respect to the designated reference frame.

The Euler angle coordinates that are output by the 3SPACE as one measure of receiver orientation are graphically defined in Figure 11.

In Figure 11, the x,y,z and X, Y, Z tri-axis arrays represent independent, three-dimensional orthogonal coordinate frames. The x,y,z triad represents the receiver frame in its current orientation state. The X,Y,Z triad represents the reference frame against which the relative orientation of the receiver frame is measured. By definition then, the X,Y,Z frame also represents the zero-orientation reference state of the receiver frame.

The 3SPACE Euler angles, azimuth, elevation and roll, are designated ϕ , θ , and ψ in Figure 11. These angles represent an azimuth-primary sequence of frame rotations that define the current orientation of the receiver with respect to its zero-orientation state. The defining rotation sequence is an azimuth rotation followed by an elevation rotation followed by a roll rotation.

The azimuth angle ϕ is defined in Figure 11 as a rotation of the X and Y reference axes about the Z reference axis. Note that the transition axes labelled X' and Y' represent the orientation of the X and Y axes after the azimuth rotation.

The elevation angle θ is defined as a rotation of the Z reference axis and the X' transition axis about the

Y' transition axis. Note that the transition axis labelled Z' represents the orientation of the Z reference axis after the elevation rotation. Note also that the current x axis of the current sensor frame represents the orientation of the X' transition axis after the elevation rotation.

Lastly, the roll angle \ddot{o} is defined as a rotation of the Y' and Z' transition axes about the x axis of the sensor frame. Note that the y and z axes of the current sensor frame represent the orientation of the Y' and Z' transition axes after the roll rotation.

Note also that in the example of Figure 11, the azimuth, elevation and roll rotations are positive, negative and positive respectively.

Output List

A list of the data items included in a data record.

X, Y, Z = Alignment (Reference) Frame
X, Y, Z = Rotated Stylus or Receiver
Coordinate Frame
 \emptyset = Azimuth
 \ddot{e} = Elevation
 \ddot{o} = Roll

Figure 11. The 3SPACE Euler Angles.

Quaternion

A four-parameter quantity representing a vector and a scalar. The quaternion $q = q_0 + i q_1 + j q_2 + k q_3$ can be used to represent the receiver's orientation without the need for trigonometric functions. The attitude matrix output from the 3SPACE can be equivalently represented by the following matrix using quaternions:

$$\begin{bmatrix} q_0^2 + q_1^2 - q_2^2 - q_3^2 & 2(q_1 q_2 - q_0 q_3) & 2(q_1 q_3 + q_0 q_2) \\ 2(q_3 q_0 + q_1 q_2) & q_0^2 - q_1^2 + q_2^2 - q_3^2 & 2(q_2 q_3 - q_0 q_1) \\ 2(q_1 q_3 - q_0 q_2) & 2(q_1 q_0 + q_3 q_2) & q_0^2 - q_1^2 - q_2^2 + q_3^2 \end{bmatrix}$$

X Directional
Cosines

Y Directional
Cosines

Z Directional
Cosines

Receiver

The receiver measures the low-frequency magnetic field generated by the transmitter. The receiver is used to track both the position and orientation of the object to which it is attached, relative to the measurement reference frame.

Roll

(See Orientation Angles)

Station

The transmitter-receiver pair. Up to four receivers are permitted, yielding a possible four stations.

Stylus

A pencil-shaped housing for the receiver with an integral switch and used by the operator to indicate and/or select points to be digitized.

System Identification Data (SID)

Thirty-two characters of data (hardware serial number, etc.) stored in EEPROM containing information identifying the system.

Transmitter

The transmitter generates the low-frequency magnetic field measured by the receiver. The transmitter's X, Y, and Z axes are the default measurement reference frame.

Units

The unit of assumed distance. The 3SPACE allows either inches or centimeters.

User Defaults

The values assigned to certain system variables by the user. Stored in EEPROM, the system receives these variable values at power-up.

APPENDIX A

IEEE-488

Not all host computers are equipped with IEEE-488 I/O capability. If you decide that using the 488 is required for your application and are in need of acquiring specific hardware, etc. to make your host compatible, the following list is presented. This listing is of known suppliers of IEEE-488 interface boards, code, cables, etc. No endorsement is implied by inclusion on this list; nor does the exclusion have any negative implications.

Black Box Corp.
P.O. Box 12800
Pittsburgh, PA 15241
412/746-5530 Sales

Capital Equipment Corp.
76 Blanchard Road
Burlington, MA 01803
617/273-1818

John Fluke Mfg. Co., Inc.
P.O. Box 9090
Everett, VA 98206
206/347-6100

Intelligent Interfaces, Inc.
P.O. Box 1486
Stone Mountain, GA 30086-1486
404/381-9891

IOtech Inc.

25971 Cannon Road
Cleveland, OH 44146
216/439-4091

National Instruments Corporate Office
6504 Bridge Point Parkway
Austin, TX 78730-5039
512/794-0100

Ziatech Corp.
3433 Roberto Court
San Luis Obispo, CA 93401
805/541-0488

DY4 Systems Inc.
7 Concord Street, Suite 2
Nashua, NH 03060-2328
603/595-2400

DY4 Systems Inc.
1475 S. Bascom Avenue, Suite 202
Campbell, CA 95008
408/377-9822

Bit 3
8120 Penn Avenue South
Minneapolis, MN 55431-1393
612/881-6955

Using the IEEE-488

The 488 should be selected by the dip switch along with the 488 address.

The general protocol for sending data to the FASTRAK system is to address the device to listen and send the data. It need not be terminated with an EOI because, as with the RS-232, commands are terminated with a carriage return or nothing at all, depending on the command.

When the FASTRAK outputs data, the SRQ line is set active. The controller should poll this line for activity, and then proceed with a serial poll after detecting activity. The poll will clear the SRQ. The system should be addressed to talk and the data is then transmitted. The last byte output from the system is transmitted with EOI active.

If operating in continuous mode, only one record of data is in the output buffer. If the system attempts to update the buffer and data measured during the last cycle is still present, the update will not occur. Therefore, to have the lowest latency, the data must be transferred in less than the cycle time of 8.3 milliseconds.

The system communicates at about 100 KB/ second maximum rate. The system can sustain this rate for 0.5 milliseconds after SRQ is activated with no slowing of the 8.3 milli-seconds system update rate. If transmission lasts longer and is at a rate higher than 50 KB/second, the system will only be servicing the 488 and the update rate of the system will suffer.

This allows for about a 50 byte output record before system update rate is affected.

If the 488 is operated at a rate slower than 50 KB/second, then the system update rate may also decrease depending upon the length of the data output record.

TABLE OF CONTENTS

SOFTWARE COMMAND STRUCTURE COMPARISON.....	vi
1.0 Same.....	vi
2.0 Modified.....	vii
3.0 Deleted.....	viii
4.0 New.....	viii
GETTING STARTED.....	ix
1.0 INTRODUCTION.....	1
2.0 HARDWARE.....	1
Standard Items.....	1
Optional Items.....	2
3.0 OVERVIEW.....	2
4.0 SPECIFICATION.....	4
Position Coverage.....	4
Angular Coverage.....	4
Static Accuracy.....	4
Resolution.....	4
Latency.....	4
Output.....	4
Carrier Frequency.....	5
Interfaces.....	5
Operating Environment.....	6
Operating Temperature.....	6
Physical Characteristics.....	6
3BALL.....	7
Power Requirements.....	7

5.0 COMPONENT DESCRIPTION.....	8
5.1 SEU.....	8
5.2 Receiver Inputs/Selector Switch.....	8
5.3 Transmitter Output.....	11
5.4 Power Indicator.....	11
5.5 I/O Select Switch.....	11
5.6 External Sync I/O.....	14
5.7 IEEE-488 I/O.....	16
5.8 Frequency Select Module.....	16
5.9 RS-232 I/O.....	17
5.10 Optional RS-422 I/O.....	18
5.11 Video Sync Input.....	18
5.12 Power Input Receptacle.....	19
5.13 Cooling Fan	19
5.14 Transmitter.....	19
5.15 Receiver(s).....	21
5.16 Stylus.....	21
5.17 3BALL.....	21
5.18 Video Sync Detector.....	25
5.19 Diskette.....	25
6.0 INSTRUMENT OPERATION.....	27
6.1 I/O Considerations.....	27
6.2 Setup.....	29
6.3 Power-Up.....	29
6.4 Output Considerations.....	30
6.5 Synchronization and Multiple Systems.....	31
6.6 System Commands and Outputs.....	35
6.7 Command Format Notation and Convention.....	36
6.8 Output Record Format Notation and Conventions	39
6.9 Command/Output Listing.....	42
ALIGNMENT.....	42
ALIGNMENT REFERENCE FRAME.....	47

RESET ALIGNMENT REFERENCE FRAME.....	50
BORESIGHT.....	51
BORESIGHT.....	52
BORESIGHT REFERENCE ANGLES.....	53
UNBORESIGHT.....	55
COMPENSATION.....	56
ENABLE FIXED METAL COMPENSATION.....	57
DISABLE FIXED METAL COMPENSATION....	58
TRANSMITTER MOUNTING FRAME.....	59
ATTITUDE FILTER PARAMETERS.....	61
POSITION FILTER PARAMETERS.....	66
SET SYNCHRONIZATION MODE.....	71
EEPROM.....	73
SAVE OPERATIONAL CONFIGURATION.....	75
REINITIALIZE SYSTEM.....	76
RESET SYSTEM TO DEFAULTS.....	77
CONFIGURATION CONTROL DATA.....	78
ENVELOPE.....	80
ANGULAR OPERATIONAL ENVELOPE.....	82
POSITION OPERATIONAL ENVELOPE.....	85
HEMISPHERE.....	88
HEMISPHERE OF OPERATION.....	90
INCREMENT.....	93
DEFINE INCREMENT.....	94
SYSTEM OUTPUT DEFINITION.....	96
OUTPUT LIST.....	97
OUTPUT DATA LIST.....	98
OUTPUT ITEM LIST.....	102
SYSTEM DATA RECORD, ASCII FORMAT....	103
SYSTEM DATA RECORD, IEEE FLOATING-POINT FORMAT.....	107
SYSTEM DATA RECORD, 16-BIT BINARY FORMAT.....	109
OUTPUT FORMAT.....	112
ENABLE ASCII OUTPUT FORMAT.....	113
ENABLE BINARY OUTPUT FORMAT.....	114
OUTPUT PORT SETTINGS.....	115
SET OUTPUT PORT.....	116

OUTPUT TRANSMIT MODE.....	118
CONTINUOUS PRINT OUTPUT.....	119
SINGLE RECORD TRANSMISSION.....	120
DISABLE CONTINUOUS PRINTING.....	121
INPUT/OUTPUT UNITS.....	122
SET UNITS INCHES.....	123
METRIC CONVERSION UNITS.....	124
OUTPUT START/STOP (XON/XOFF).....	125
SUSPEND DATA TRANSMISSION.....	126
RESUME DATA TRANSMISSION.....	127
STATIONS.....	128
ACTIVE STATION STATE.....	129
STATUS.....	131
SYSTEM STATUS RECORD.....	132
INSTRUMENT CONFIGURATION STATUS.....	134
BUILT-IN-TEST INFORMATION.....	135
STYLUS.....	140
DEFINE TIP OFFSETS.....	141
DEFINE STYLUS BUTTON FUNCTION.....	142
6.10 Command Error.....	144
6.11 Default Operation with a Stylus or 3BALL.....	146
7.0 LIMITED WARRANTY AND LIMITATION OF LIABILITY	148
8.0 INDEMNITY AGAINST PATENT INFRINGEMENT....	151
9.0 CUSTOMER SERVICE.....	153
INDEX.....	154
GLOSSARY.....	156

LIST OF FIGURES

Figure 1. FASTRAK.....	9
Figure 2. FASTRAK SEU.....	10
Figure 3. FASTRAK Controls/Connections (Front & Rear).....	15
Figure 4. Transmitter.....	20
Figure 5. Receiver.....	22
Figure 6. Stylus.....	23
Figure 7. 3BALL.....	24
Figure 8. System Alignment.....	45
Figure 9. System Envelope.....	81
Figure 10. System Hemisphere.....	89
Figure 11. The 3SPACE Euler Angles.....	162