



# OPERATOR'S MANUAL



**Original® | Composite® | CompositeXT® | HyCube® | ThermoTech®**

This manual contains important safety and operations information. Read this manual carefully and keep it with the trailer at all times.



# About this document

This document explains how to use various features of your trailer and provides essential maintenance information.

- Carefully read the safety information and follow the precautions for every trailer feature.
- This document covers optional specifications. It may include descriptions for features your trailer is not equipped with.
- Images of the trailer in this document may differ from the actual trailers.

## ❖ NOTE

Always keep this document with your trailer for future reference.

All information in this document is current at the time of publication. However, Hyundai Translead reserves the right to make changes at any time to carry out our policy of continual product improvement.

**This document applies to the Hyundai Translead dry van and reefer trailer models, and it includes descriptions and explanations of optional and standard equipment. As a result, you may find material in this manual that does not apply to your specific trailer.**

No part of this document may be reproduced, stored in any retrieval system, or transmitted in any form or by any means without the prior written permission of Hyundai Translead.

## About trailer models

### Dry van trailers

The dry van trailers includes the following models.

- **Original®**
  - Can be custom built to meet the specific needs of users.
  - Multiple side post spacing, strength and protection options are available.
  - Plywood is installed horizontally over the side posts with the full length of the trailer and over the front wall.
- **HyCube®**
  - Can be custom built to meet the specific needs of users.
  - Multiple side post spacing, strength and protection options are available.
  - Provides an interior width of 101" and up to 4,050 cubic feet of interior load capacity.
  - Multiple interior lining options (HDPE panels, G-bond, or galvanized steel) are available for custom interior width, strength, cargo protection and easy repair.
- **Composite®**
  - Provides composite panel side walls designed for quick and easy repair or replacement.
  - Provides patented sidewall configuration for improved assembly sturdiness and easier maintenance.
  - Smooth interior sidewalls are installed to reduce possible snag points.
  - Provides an integral scuff band on the bottom rail.
- **CompositeXT®**
  - Provides patented designs of the HT composite panel trailer for easy repair.
  - Provides an integral scuff band on the bottom rail, which has a centrally located external rib for increased sturdiness and scrape resistance.



## Reefer trailers

The reefer trailer includes the following model.

- **ThermoTech®**
  - Single-Temp design for the truckload carrier segment
  - Multi-Temp design for the grocery, dairy, and food distribution markets
  - Provides a lighter weight and stronger component construction.
  - Can be customized with multiple side doors.
  - Provides various liftgates and multi-temp configurations.

### ❖ NOTE

Pay attention to the security of the refrigeration unit mounted on the trailer and follow the manufacturer's service recommendations. To obtain its technical information and operating instruction document, contact your sales representative or an authorized dealer, or visit the manufacturer's website.

## Target users

The trailer should only be operated by users who possess the required skills, experience, and knowledge relevant to the trailer's operation and maintenance.

# Guide to genuine parts

## What are Hyundai Translead GENUINE PARTS™?

Hyundai Translead GENUINE PARTS™ are the same parts used by Hyundai Translead to manufacture trailers. They are designed and tested for the optimal safety, performance, and reliability for customers.



**GENUINE PARTS™**



**HYUNDAI  
TRANSLEAD**

**GENUINE  
PARTS™**


## Why Hyundai Translead GENUINE PARTS™?

Hyundai Translead GENUINE PARTS™ are engineered and built to meet rigid manufacturing requirements. Damage caused by using imitation, counterfeit, or used salvage parts is not covered under Hyundai Translead's limited warranty or any other warranty offered by Hyundai Translead.

Additionally, any damage to or failure of Hyundai Translead GENUINE PARTS™ caused by the installation or failure of imitation, counterfeit, or used salvage parts is not covered by any warranty offered by Hyundai Translead.

## How can you tell if you are purchasing Hyundai Translead GENUINE PARTS™?

Look for the Hyundai Translead GENUINE PARTS™ logo on the package. Hyundai Translead GENUINE PARTS™ are only sold through authorized Hyundai Translead dealers.



# Table of contents

## About this document.....3

### About trailer models..... 4

Dry van trailers ..... 4

Reefer trailers ..... 5

### Target users ..... 5

## Guide to genuine parts ...6

## Safety information ..... 11

### Symbols used in this document ..... 12

Safety symbols ..... 12

Tips and information ..... 12

### Safety and instructions labels on the trailer..... 13

Operation..... 13

Loading and weight distribution ..... 14

Inspection and maintenance 15

Component instructions..... 16

## About the trailer..... 17

### Vehicle Identification

Number (VIN)..... 18

### Overview of the trailers..... 19

Front ..... 19

Dry van trailers ..... 19

Reefer trailers ..... 20

Rear..... 21

Dry van trailers ..... 21

Reefer trailers ..... 22

### Essential parts..... 23

Landing gear..... 23

Operating the landing gear . 25

Changing the gear ..... 25

Raising or lowering the

landing gear ..... 25

Coupling components..... 26

Upper coupler and kingpin . 26

Fifth wheel (of a tractor) ..... 28

Running gear ..... 29

Suspension system ..... 29

Leaf spring suspension

(optional) ..... 30

Air spring suspension

(optional) ..... 31

Sliding suspension ..... 32

Wheels and tires..... 33

Brake system..... 35

Air system..... 35

Anti-lock Brake System

(ABS)..... 37

Brake system..... 39

Slack adjuster ..... 40

Brake chambers..... 40

Trailer body structure..... 41

Floor assembly ..... 42

Roof assembly..... 43

Door assembly ..... 44

Swing door assembly ..... 46

Roll-up door assembly ..... 48

Front and side walls ..... 50

Rear impact guard ..... 51

## Operating the trailer .... 55

### Coupling and uncoupling the trailer..... 56

Coupling ..... 57

Preparations before

coupling ..... 58

Inspecting the tractor's

fifth wheel and trailer's kingpin 58

Inspecting the area around the trailer and tractor...	58
Connecting the tractor to the trailer .....	59
Connecting the air and electrical lines.....	61
Supplying air to the trailer...	62
Raising the landing gear.....	62
Checking coupling connection (test lock) .....	63
Inspecting the coupling status.....	63
Uncoupling.....	64
Preparations before uncoupling .....	64
Lowering the landing gear ..	64
Disconnecting the air and electrical lines .....	65
Disconnecting the tractor from the trailer .....	66
Loading the trailer.....	67
Accessing the trailer .....	68
Load distribution .....	70
Distributing weight.....	71
Loading heavy concentrated loads.....	73
Sliding the trailer tandems..	75
Performing pre-trip inspection	79
Inspecting the tractor.....	81
Inside the tractor .....	81
Exterior of the tractor .....	82
Inspecting the trailer .....	82
Coupling parts of the trailer....	82
Side of the trailer.....	83
Under the trailer .....	83
Inside the trailer .....	84
Top of the trailer .....	84
Rear of the trailer .....	85

Inspecting the coupling status.....	85
--	----

## **Maintaining the trailer .. 87**

<b>Inspecting the trailer .....</b>	<b>88</b>
Trailer body structure.....	89
Floor assembly .....	89
Roof assembly.....	90
Door assembly .....	90
Swing door .....	91
Roll-up door .....	92
Sidewalls .....	93
Front wall .....	93
Upper coupler and kingpin....	94
Brake system.....	95
Air system.....	96
Draining the air tank .....	97
Anti-lock brake system (ABS).....	97
Lighting system.....	98
Suspension system .....	101
Air spring suspension (optional) .....	101
Leaf spring suspension (optional) .....	102
Landing gear.....	103
Wheels and tires.....	104
<b>Lubricating trailer parts ...</b>	<b>108</b>
Lubricating the fifth wheel (of a tractor).....	109
Lubricating the wheel-end assembly .....	110
Adding oil.....	112
Adding semi-fluid grease...	113
Lubricating the wheel nuts and studs .....	114

# Table of contents

Guidelines for proper wheel assembly .....	116
Lubricating the landing gear .....	118
Lubricating body parts .....	120
Lubricating the sliding suspension rail .....	120
Lubricating the door systems .....	121
Swing doors .....	121
Roll up door .....	122

## Appendix ..... 123

### Specifications ..... 124

Dry van trailers .....	124
Original® .....	124
General .....	124
Body Structure .....	124
HyCube® .....	126
General .....	126
Body structure .....	126
Composite® .....	128
General .....	128
Body Structure .....	129
CompositeXT® .....	130
General .....	130
Body Structure .....	131
Reefer trailers .....	132
ThermoTech® .....	132
General .....	132
Body Structure .....	132

### Parts list for repair and replacement ..... 134

General assembly .....	135
Landing gear assembly .....	136
Slider assembly .....	137
Brake system assembly .....	138
Running gear (top view) ...	138

Running gear (side view) ..	139
Wheel and hub assembly ...	140
Trailer body structure assembly .....	141
Floor assembly .....	141
Roof assembly .....	142
Rear frame assembly .....	143
Swing door assembly .....	144
Front wall assembly .....	145
Side wall assembly .....	146

### Electrical and lighting system diagrams ..... 147

Exterior lighting system .....	147
Lighting system wiring .....	147
Lighting units and harness .....	148
Interior lighting system .....	149
Dome lights wiring .....	149
Dome lights assembly .....	150

### FMCSA annual inspection checklist ..... 151

### Find a dealer near you ..... 152

### Product warranty ..... 153

# Safety information

<b>Symbols used in this document .....</b>	<b>12</b>
Safety symbols .....	12
Tips and information .....	12
<b>Safety and instructions labels on the trailer.....</b>	<b>13</b>
Operation.....	13
Loading and weight distribution .....	14
Inspection and maintenance.....	15
Component instructions.....	16

## Safety information

### Symbols used in this document

The following symbols are used in this document.

#### Safety symbols

Safety symbols are used to provide information about potential hazards and safety instructions to avoid them.



#### **WARNING**

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



#### **CAUTION**

Indicates a hazardous situation which, if not avoided, could result in minor injury or damage to or malfunction in the vehicle.

#### **NOTICE**

Indicates information considered important but not hazard-related.

### Tips and information

The following symbol is used in this manual to provide useful tips or additional information about your vehicle.



#### **NOTE**

Indicates helpful tips and additional information about your vehicle.



## Safety and instructions labels on the trailer



### CAUTION

Do not operate any equipment if you have not read and understood the safety labels attached to the trailer.

The safety and instructions labels attached to the trailer are intended to deliver safety alerts for safe trailer operation and maintenance. Be sure to read and understand all the safety labels and follow the instructions on the labels.

## Operation



Warning for user responsibility



Warning for towing capacity



Caution for slippery floor

## Safety information

**⚠ WARNING:** This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer, birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

**⚠ ADVERTENCIA:** Este producto puede exponerle a químicos incluyendo Plomo, que es conocido por el Estado de California como causante de cáncer, defectos de nacimiento u otros daños reproductivos. Para mayor información visite: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

**⚠ AVERTISSEMENT:** Ce produit peut vous exposer à des produits chimiques, y compris Plomb, identifiés par l'État de Californie comme pouvant causer le cancer et des malformations congénitales ou autres effets nocifs sur la reproduction. Pour de plus amples informations, prière de consulter: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

### Warning for chemical exposure

## Loading and weight distribution

**⚠ WARNING**

1. **DO NOT** concentrate the Load.
2. Uniformly Distributed Load Only.



### Warning for load distribution

**⚠ WARNING**



**OVERLOAD HAZARD**

Overloaded trailer may result in serious injury or death. Never exceed Gross Vehicle Weight Rating (GVWR). Before loading the trailer, verify the cargo capacity in VIN/Serial No. tag for maximum load.

### Warning for overload hazard

**⚠ WARNING**

DO NOT LOAD OR UNLOAD THE TRAILER UNLESS THE FRONT OF TRAILER IS SUPPORTED ON ONE OF THE FOLLOWING:

- a.) TRACTOR SUPPORT
- b.) CONVERTER DOLLY SUPPORT
- c.) ANTI-TIP LEG SUPPORT

FAILURE TO HAVE PROPER SUPPORT AT FRONT CAN RESULT IN TRAILER NOSE-DIVING WHICH CAN RESULT IN SERIOUS INJURY OR DEATH.

THIS TRAILER IS EQUIPPED WITH AN ANTI-TIP DEVICE ON FRONT WALL.



### Warning for load support

**ATTENTION ⚠**



Base rail, scuff band or side wall are **NOT INTENDED** as a CARGO GUIDE for pallets riding when the forklift is in motion. Driving pallets against wall may lead to trailer structural damage.

### Warning for forklift operation

## Inspection and maintenance



**Warning for wheel nuts inspection**



**Warning for trailer cleaner**



**Caution for trailer cleaning**

### FMCSA - PERIODIC INSPECTION CERTIFICATION

This vehicle has been inspected and repaired as necessary to comply with 49 C.F.R. 396.17 through 396.23 information on the contents of the inspection report can be obtained by contacting the owner/lessee.  
Hyundai Translead  
8850 Rio San Diego Dr., Suite 600  
San Diego, CA 92108

DATE OF INSPECTION:  
MONTH: 1 2 3 4 5 6 7 8 9 10 11 12  
YEAR: 2017 2018 2019 2020 2021

**Certification of inspection**

## Safety information

## Component instructions

**⚠ WARNING**

**PREVENT LOSS OF CONTROL**

DO NOT operate vehicle without all slider pins completely engaged through body rail holes. Unsecured slider suspension can cause loss of vehicle control and result property damage, server personal injury or death. Inspect carefully to ensure complete engagement of all four slider pins through body rail holes.

**TO POSITION THE SLIDING SUSPENSION:**

1. Set both tractor and trailer brakes.
2. If trailer is equipped with movable stop bar, move bar to desired location.
3. Retract slider positioning pins from body rails.
4. If any of the lock pins do not retract, gently rock the trailer back and forth with the trailer brakes applied. As soon as any binding between the pins and the body rail is relieved, the lock pins will retract.
5. Carefully drive forward or backward until the sliding suspension is at the desired location, then apply brakes again.
6. Return lock pins to locked position and visually check that each one completely engages the body rails holes.
7. If available, lock the locator bar in the body rails immediately behind the slider.
8. Inspect the slider at each stop to ensure that all lock pins are fully engaged in the body rails.

### Caution for slider operation

**LOCKING PIN OPERATION NOTICE**

Operating Process to Extend or Close the Chassis


1. Place both the tractor and chassis in position.
2. Connect the tractor's emergency air line to the Air Lock Gladhand only to supply air to the system to release the locking pins.
3. Drive slow and carefully the tractor, then pull forward to extend or push backwards to close chassis frame. Stop when the locking pins are close to the desired hole.
4. Cut off the air supply to the system, then move the front frame again until the locking pins from slider frame are fully engaged on both sides through the desired locking hole.
5. Gently move the chassis backwards and forward to ensure the locking pins are properly locked.
6. Disconnect the Air Lock Gladhand. Properly reconnect both emergency and service gladhands.

**WARNING: FAILURE TO LOCK THE FRONT FRAME CAN CAUSE A LOSS OF VEHICLE CONTROL, DEATH, SERIOUS BODILY INJURY, AND PROPERTY DAMAGE**

### Caution for locking pin operation

**⚠ WARNING**

Trailer is ABS equipped and requires a continuous electrical power to No. 7 (Blue) circuit. Towing vehicle must supply minimum of 10 amps at 12.5 volts on circuits No. 4 (Red) and No. 7 (Blue).



PIN	COLOR	CIRCUIT
1	White	Ground return to towing vehicle.
2	Black	Clearance, side marker, & identification lamps.
3	Yellow	Left turn signal and hazard lamps.
4	Red	Stop lamps & ABS (secondary power).
5	Green	Right turn signal and hazard lamps.
6	Brown	Tail, license, clearance and/or side marker lamps.
7	Blue	Continuous ABS primary power/auxiliary devices. (Aux. devices must switch off when trailer is in motion)

J560 Socket

Failure to follow this warning may result in property damage, serious injury or death.

### Warning for ABS socket connections


# About the trailer

<b>Vehicle Identification Number (VIN)</b> .....	<b>18</b>
<b>Overview of the trailers</b> .....	<b>19</b>
Front .....	19
Dry van trailers .....	19
Reefer trailers.....	20
Rear .....	21
Dry van trailers .....	21
Reefer trailers.....	22
<b>Essential parts</b> .....	<b>23</b>
Landing gear.....	23
Operating the landing gear.....	25
Changing the gear .....	25
Raising or lowering the landing gear .....	25
Coupling components.....	26
Upper coupler and kingpin .....	26
Fifth wheel (of a tractor) .....	28
Running gear .....	29
Suspension system .....	29
Leaf spring suspension (optional).....	30
Air spring suspension (optional) .....	31
Sliding suspension.....	32
Wheels and tires .....	33
Brake system.....	35
Air system .....	35
Anti-lock Brake System (ABS) .....	37
Brake system .....	39
Slack adjuster .....	40
Brake chambers.....	40
Trailer body structure.....	41
Floor assembly.....	42
Roof assembly .....	43
Door assembly .....	44
Swing door assembly.....	46
Roll-up door assembly .....	48
Front and side walls .....	50
Rear impact guard .....	51

## About the trailer

### Vehicle Identification Number (VIN)

To comply with the Federal Law regulations, each trailer must have its own Vehicle Identification Number (VIN). The VIN plate is located on the lower part of the trailer's front wall. The VIN plate includes the model designation, date of manufacture, the Gross Vehicle Weight Rating (GVWR), the Gross Axle Weight Rating (GAWR), and other specifications.



- 1 The date when the trailer was manufactured
- 2 Gross Vehicle Weight Rating (GVWR)
- 3 Gross Axle Weight Rating (GAWR) of all axles
- 4 Tire dimensions
- 5 The proper cold tire inflation pressure
- 6 The size of the rims
- 7 Vehicle Identification Number (VIN)
- 8 Material number
- 9 Trailer model number
- 10 Trailer type

#### NOTICE


- Do not remove or alter the Vehicle Identification Number (VIN) plate on the trailer. Doing so violates federal laws and regulations.
- Check each state's regulations for the maximum legal loads allowed.
- Any records for this trailer or any reference to this trailer in any correspondence must include the VIN.

## Overview of the trailers

View the location of exterior parts of the trailers.

### Front

#### *Dry van trailers*



❶ Front wall (p.50, 93)

❷ Roof (p.43, 90)

❸ Landing gear  
(p.23, 103, 118)

❹ Side wall (p.50, 93)

❺ Wheels & tires  
(p.33, 104, 110)

❻ Service air line connection  
(p.61, 96)


❼ Document holder

❽ Emergency air line  
connection (p.61, 96)

❾ Electrical 7-way connection  
(p.61, 147)

## About the trailer

### Reefer trailers




- |                                      |   |
|--------------------------------------|---|
| ① Refrigeration unit                 | ⑦ Landing gear<br>(p.23, 103, 118)            |
| ② Front wall (p.50, 93)              | ⑧ Service air line connection<br>(p.61, 96)   |
| ③ Roof (p.43, 90)                    | ⑨ Emergency air line<br>connection (p.61, 96) |
| ④ Fuel tank                          | ⑩ Electrical 7-way connection<br>(p.61, 147)  |
| ⑤ Side wall (p.50, 93)               |   |
| ⑥ Wheels & tires<br>(p.33, 104, 110) |   |



## Rear


### *Dry van trailers*



- |                               |                                     |
|-------------------------------|-------------------------------------|
| ① Rear door (p.44, 90, 121)   | ⑥ Mud flap                          |
| ② Door handle (p.44, 90, 121) | ⑦ Running gear assembly (p.29, 101) |
| ③ Kingpin (p.26, 59, 94)      | ⑧ Rear light (p.98, 148)            |
| ④ Mid-turn light (p.98, 148)  | ⑨ Rear impact guard (p.51)          |
| ⑤ Slider rail (p.32, 75)      |                                     |

## About the trailer

### Reefer trailers



❶ Rear door (p.44, 90, 121)

❷ Door handle  
(p.44, 90, 121)

❸ Kingpin (p.26, 59, 94)

❹ Mid-turn light (p.98, 148)

❺ Slider rail (p.32, 75)

❻ Mud flap

❼ Running gear assembly  
(p.29, 101)

❽ Rear light (p.98, 148)

❾ Rear impact guard (p.51)

## Essential parts


Carefully read the principles and instructions for the essential trailer parts. For safe trailer operation, regularly perform scheduled inspections and maintenance for each component of the trailer.

### Landing gear

The trailer landing gear assembly is located on the lower front of the trailer and is used to lower or raise the trailer in order to couple the trailer to the tractor. To ensure safe operation of the landing gear, inspect the components of the landing gear assembly regularly.

#### ❖ NOTE

Both internal and external gear boxes share the same crank direction. For more information on lubrication specifications, refer to "Lubricating the landing gear" on page 118.



- ❶ Crank shaft
- ❷ Landing gear bracket
- ❸ Crank handle

- ❹ K-brace
- ❺ Support leg
- ❻ Sand shoe

## About the trailer



### **WARNING**

To avoid potentially dangerous situations that could result in serious injury or death, follow the instructions below.


- Before operating the landing gear, visually inspect all braces at each attachment point, including the “hinge bolt,” which allows the handle to fold out of the way.
- Only uncouple trailers on level and solid surfaces.
- Before beginning the coupling or uncoupling process, ensure the trailer parking brakes are applied or that the wheels are well chocked.
- Do not uncouple the trailer from the truck without first fully extending the landing gear legs to make contact with the ground and support the trailer weight.
- Before moving the trailer, ensure the lower leg of the landing gear is fully retracted and the crank handle is properly placed in its keeper.
- Remove the crank handle from the keeper, engage in the operating position, and select low or high gear. Make sure the handle shank is fully engaged with the crank shaft. The “hinge bolt” is not adequate to use for cranking the landing gear.
- For safe use of the landing gear, stand facing the handle with two handed grip or one hand on the trailer and the other on the handle.
- Lubricate all moveable parts, bushings and bearing regularly in accordance with the landing gear leg manufacturer’s specifications.
- Always place the support legs on a plank for flotation to prevent them from sinking into soil or soft asphalt when a loaded trailer is uncoupled from a tractor.
- Do not force the landing gear beyond its normal raised or lowered positions.

## ***Operating the landing gear***

### **Changing the gear**


The landing gear provides two speeds.

- The low gear provides the power required to lift the trailer under load. To set the landing gear to the low gear, pull the crank handle.
- The high gear provides quick leg extension and retraction without a load. To set the landing gear to the high gear, push the crank handle.



### **Raising or lowering the landing gear**

To raise the support legs, turn the crank handle clockwise. To lower the support legs, turn the crank handle counterclockwise.



## About the trailer

### Coupling components



#### **WARNING**


Improper coupling between a tractor and a trailer may cause serious accidents, which may result in property loss, serious injury, and death. Ensure the following before each trip:

- The trailer has been properly coupled with the tractor.
- The tractor has the sufficient capacity and specifications to safely tow the trailer.

The principle of the coupling system is to connect the tractor to the trailer. The integral components of the coupling system are the trailer kingpin on the upper coupler and the tractor's fifth wheel.

#### *Upper coupler and kingpin*

The upper coupler is located on the front bottom side of the trailer, and it transfers the weight of the front of the trailer to the tractor's fifth wheel plate. This fabricated steel assembly incorporates the kingpin connected with the tractor fifth wheel to pull the tractor.



- ① Upper coupler
- ② Kingpin


**WARNING**

- Frequently inspect the coupling components of the tractor and trailer. Property loss, serious injury, or death may result if damaged coupling components fail during trailer operation.
- Damage to the upper coupler or kingpin and any fasteners to the adjacent trailer structure can compromise the structural integrity of the trailer. Therefore, you must inspect the upper coupler and kingpin for damage and immediately report any damage to your supervisor before operating the trailer.
- Do not operate the trailer if you have not visually inspected the upper coupler and kingpin to ensure proper coupling and locking by the fifth wheel jaws. This visual inspection is mandatory and required by law, as instances can occur when a pull test will not dislodge an improperly coupled trailer. Listening for the lock to close is insufficient as a test.
- When repairs are required, be sure a certified repair facility uses certified fasteners identical to ones used by the original equipment manufacturer, both in size and strength rating. Any structural repairs to the upper coupler or installation of a replacement kingpin must be done with extreme caution to replicate the original structure.

## About the trailer

### *Fifth wheel (of a tractor)*

The tractor fifth wheel is located in front of the rear axle of the tractor and is used to couple the trailer to the tractor. Before coupling the trailer to the tractor make sure the tractor fifth wheel is properly lubricated.



- ① Fifth wheel plate
- ② Fifth wheel jaw
- ③ Release lever



### **WARNING**

- Do not use any tractor fifth wheel that fails to operate properly. Always check the fifth wheel for proper lubrication and operation before coupling.
- Do not couple to a closed fifth wheel. Doing so may damage the tractor fifth wheel and trailer kingpin.



## Running gear

The running gear is composed of the moving parts of the trailer including a suspension system, hubs, wheels, drums, rims, bearings, brakes, axles, and tires.

### **NOTICE**

- If the tires or other components of the running gear have been replaced or altered since the trailer was manufactured, the GAWR value on the VIN plate must be changed.
- The upper running gear rail weld attachment to the trailer must be inspected for weld fatigue cracks in compliance with the annual FMCSA inspection requirements.

## *Suspension system*

The suspension system is composed of the air spring suspension or leaf spring suspension. It provides a cushioned, level platform, which allows the trailer to operate properly under all legal loads for which it was designed.


### **❖ NOTE**

For more information on the specifications for inspections, torque bolts, and the individual air suspension assembly, visit the manufacturer's website or visit the Hyundai Translead website at [www.hyundaitranslead.com](http://www.hyundaitranslead.com).

## About the trailer

### Leaf spring suspension (optional)

The leaf spring suspension assembly is an integral part of the trailer's suspension system, which supports the entire weight of the trailer.



- |                    |                         |
|--------------------|-------------------------|
| ① U-bolt           | ⑤ Adjustable torque arm |
| ② Front hanger     | ⑥ Bottom plate          |
| ③ Fixed torque arm | ⑦ Spring leaves         |
| ④ Seat riser       |                         |



#### **WARNING**

Before operating the trailer, always check if there are any missing or broken parts in the leaf spring suspension. Broken spring leaves, missing or loose U-bolts, or other defective conditions likely to cause axle shifts are hazardous and can cause accidents or breakdowns.




#### **CAUTION**

The spring leaves must always be securely clamped to the axle and spring seats to prevent any movement within the U-bolts. Even a slightly loose connection can cause misalignment of the axles, resulting in excessive tire wear and poor trailer tracking.

## Air spring suspension (optional)

The air spring suspension assembly helps to protect cargo, ensure driver comfort, and keep equipment operating at peak efficiency. The trailer is equipped with a spring brake priority to ensure the release of the spring brakes before air is directed to the air tank to inflate the air springs. The height control valve regulates the air pressure in the air spring suspension system to control the ride height of the trailer.



- ① Air tank
- ② Air spring

- ③ Shock absorber
- ④ Bogie frame



### CAUTION

Do not move the trailer until the tractor's air gauges indicate that the system is fully charged and stabilized. Doing so may damage the suspension system.

### NOTICE

In accordance with the Department of Transportation regulations, the following must be inspected before and after operation:

- Inspect each airbag for damage and sufficient inflation.
- Inspect all shock absorbers for damage or internal leakage.
- Inspect the height control valve for secure attachments and proper operation.


## About the trailer

### Sliding suspension

The sliding suspension assembly is used to adjust the position of the running gear beneath the trailer in order to affect the turning radius and/or adjust the amount of weight between the tractor drive axles and the trailer axles. The sliding suspension can be repositioned in 4" or 6" increments within the length of the upper running gear rail.

#### ❖ NOTE

- For more information on positioning the sliding suspension, refer to "Sliding the trailer tandems" on page 75.
- The both slider rails are perforated at equal intervals to accept the bullet-nosed locking pins from the upper running gear top rail.



- 1 Right slider rail
- 2 Left slider rail
- 3 Surelok

- 4 Slider frame
- 5 Rail clip



## WARNING


Always lock the sliding suspension. Failure to lock the sliding suspension when operating or parking the trailer can cause a loss of vehicle control, property damage, serious injury, or death.

## Wheels and tires

Refer to the following diagram for each component of the wheel assembly. Install the rims and wheels properly to ensure safe operation of the trailer and economical, trouble-free service. Also, use only the specified sizes of studs and nuts.

## NOTE

Every tire has its size, load limit, maximum air pressure, and date of manufacture molded into the sidewall of each tire. The Vehicle Identification Plate (VIN), located on the lower front of the trailer, states the Gross Axle Weight Rating (GAWR), the tire size, the load rating, and inflation pressure. For more information on the VIN plate, refer to "Vehicle Identification Number (VIN)" on page 18.



- |                              |                              |
|------------------------------|------------------------------|
| ① Hub assembly               | ④ Outer wheel (rim and tire) |
| ② Brake drum                 | ⑤ Lug nuts                   |
| ③ Inner wheel (rim and tire) | ⑥ Hub cap                    |

## About the trailer



### **WARNING**

- To avoid serious accidents that may result in death or serious injury, frequently inspect the tires for the following:
  - Wear and tear, cuts, and other damage
  - Nails and other sharp objects stuck in the rubber and stones and other objects lodged between the wheels
  - Any damaged valve stems
  - The rated air pressure for safe operation
  - Adequate tread conditions for safe operation
- Before each trip, inspect the wheel-end assembly for loose or missing wheel nuts (lug nuts) and lubricant leaks from wheel hubs to avoid serious wheel-end failures that may result in death or serious injury. For more information on lubricating the wheel-end assembly and tightening the wheel nuts, refer to “Lubricating the wheel-end assembly” on page 110.
- Servicing tires and wheel/rim is very dangerous and must only be performed by trained personnel using proper tools and procedures. To obtain more information on tire and wheel servicing, visit the websites of the US Department of Labor and NHTSA.
- Tires must only be inflated while in a restraining device/safety cage.
- Tires and wheels are very heavy. Be careful when carrying or handling them.
- Always check for any damage to the hubs and wheel ends, and check the oil level before moving the trailer. Cracked or damaged wheels, rims, rings, loose or missing lug nuts or studs can cause wheel loss and result in serious injury or death.
- Do not operate the trailer if the rims or rings are excessively damaged or corroded. Also, deflate the tires before removing the rims or wheels from the running gear.

## Brake system

The trailer's brake system consists of an air delivery system that includes plumbing, air tank, emergency valve, service valve, and the Anti-Lock Brake System (ABS). The brake system also includes foundation brakes made up of slack adjusters, S-cams, brake chambers, and brake shoes or pads.


### *Air system*

The trailer's air system is supplied by the tractor brake system and it consists of plumbing throughout the trailer, the gladhands for both the "Service (blue) and Emergency (red)" lines, the air tank, the suspension, and the brake valves. Refer to the following diagram for each component of the air system and its configuration.

#### ❖ NOTE

- The supply system from the tractor is connected to the red gladhand (emergency supply) and provides a constant air supply that releases the parking brakes and maintains consistent air pressure in the air tank.
- The service system from the tractor is connected to the blue gladhand (service supply) and provides a signal for trailer brake activation when the tractor brakes are applied.
- The supply system (emergency supply) allocates air for releasing the spring brakes before charging the air tank and supplying the suspension system.

## About the trailer



- |                      |                                       |
|----------------------|---------------------------------------|
| 1 Service supply     | 5 Electronic Control Unit (ECU) valve |
| 2 Emergency supply   | 6 Air tank                            |
| 3 Brake chambers     |                                       |
| 4 Spring brake valve |                                       |




### WARNING

- Do not operate the trailer if the brake system is defective or has not been adjusted adequately.
- Trailer brake systems must be inspected frequently by a qualified service technician for any issues, such as loose fittings or missing or damaged components. Missing or damaged components can result in accidents or breakdowns.
- Serious air loss is very dangerous and can result in accidents or breakdowns.
- After coupling the tractor and the trailer, follow the instructions below.
  - Wait until the air pressure is normal.
  - Turn off the tractor's engine and check for any air leaks on the trailer brake system.
  - Check the brake pressure gauge for signs of major air loss.
- Do not operate the trailer if the indications from the tractor's instruments show improper or insufficient air pressure for brakes, or if you hear any audible warning alarms.



## Anti-lock Brake System (ABS)

The Anti-lock Brake System (ABS) monitors the wheel rotation speed and controls braking during extreme braking applications. When a wheel loses traction with the road surface and locks in extreme braking situations, the sensors transmit this dynamic to the Electronic Control Unit (ECU) which regulates air pressure to that brake to release the brake for an instant to regain traction. Refer to the following diagram for each component of the ABS system for the trailer brake system.



- |   |  |
|---|--|
| ① 7-Way connector                         | ⑥ ECU valve                                  |
| ② White wire to white post (ground)       | ⑦ Power cable connector (of the ECU valve)   |
| ③ Blue wire to blue post (constant power) | ⑧ Sensor cable connectors (of the ECU valve) |
| ④ Red wire to red post (stop lamp)        | ⑨ Indicator light harness                    |
| ⑤ Main harness                            | ⑩ ABS indicator light                        |

## About the trailer




### **WARNING**

- The ABS indicator light located in the trailer's lower-left rear corner, or on near the bottom rail, turns on when electrical power is first applied to the ABS system. If the ABS indicator light does not turn on, the ABS system may be malfunctioning and needs to be serviced. If the light illuminates and stays lit while power is being supplied, the ABS system needs to be examined and repaired by a qualified service technician. Failure to do so can result in property damage, serious injury, or death.
- Avoid driving too fast for the conditions. Operate your vehicle within a safe speed range for the road conditions and payload weight to prevent death, personal injury, or property loss. While the ABS system can help you brake your vehicle under control and safely stop in severe braking situations, the ABS system cannot compensate for excessive speed, inattentive driving, or improper control of your vehicle.

## Brake system

The brake system consists of brake chambers, slack adjusters, S-cams, and shoes or pads. During service braking, the brake chambers convert air pressure to mechanical force through the slack adjusters and camshafts to apply the brakes using the brake shoes or pads.



- ① Upper brake shoe
- ② Lower brake shoe
- ③ S-cam

- ④ Slack adjuster
- ⑤ Brake chamber



### WARNING

- Do not disassemble or repair a brake chamber. Doing so may result in property damage, serious injury, or death due to the accidental sudden release of a high-energy spring.
- Before entering traffic, check the trailer brake operation to ensure they work properly. Also, operate the foot pedal, dash control valves, and hand valve to verify that the brakes are applied and released each time. Always be alert for air leaks during each type of brake application.

## About the trailer

- Service brakes and parking brakes must be inspected by the driver. Do not operate a trailer with defective brakes. Inspect the following before and after operation.
  - Check if the chamber plastic end cap is placed properly to prevent dirt and contaminants.
  - Check if any of the components of the brake system are defective, missing, damaged or corroded.
  - If a defect is suspected, place the vehicle out of service until a qualified service technician repairs it.

### Slack adjuster

The automatic slack adjusters installed on the trailer maintain a constant brake shoe to drum clearance that ensures constant brake shoe force.

### Brake chambers

All trailer brake chambers perform both service and parking brake functions. The service brake stops the trailer after receiving a signal from the tractor. The parking brake is applied when you apply the parking brake. The parking brake is also applied automatically when the air supply is unintentionally lost. To move the trailer before air pressure can be restored, such as during routine maintenance or in emergency situations, the mechanical spring brakes can be manually backed off and released using the cage bolt.

## Trailer body structure

The trailer's body structure is composed of a floor assembly, roof assembly, side walls, front wall, and doors (swing or roll-up door). For more information on the location of each component, refer to "Overview of the trailers" on page 19.



### WARNING

- Do not transport people in the trailer. Before closing the doors and operating the trailer, ensure there is no one in the trailer.
- Do not transport hazardous materials without proper permission and safeguards.
- When replacing components of the trailer's body structure, use materials with identical properties, thickness, and specifications.
- All repairs and adjustments of the components must be performed by trained service personnel.




### CAUTION

- Do not expose any part of the body structure to corrosive materials or solvents. Doing so may void the trailer warranty.
- Always keep the side or rear doors locked or closed when the trailer is moving.
- For safe trailer operation, regularly perform the scheduled inspections of the body structure.

## About the trailer

### *Floor assembly*

The floor assembly consists of floor boards and crossmembers. For the reefer trailer, the floor boards are made of extruded aluminum and include a sub floor and composite floor sills above the crossmembers. Refer to the following diagram for each component of the floor assembly.



- ① Floor boards
- ② Threshold plate
- ③ Crossmember



### **WARNING**


- Do not damage the integrity of the wood floor boards with excessive nailing in one area.
- To prevent a damage to the floor assembly during forklift entry into the trailer, use dock boards or leveling equipment.

## Roof assembly

The roof assembly includes the roof sheet, roof bows, and fastener connections to the top side rails. The roof sheet and roof bows are used to provide structural stability for the sidewalls. Refer to the following diagram for each component of the roof assembly.

### ❖ NOTE

The material for the standard roof sheet is used with full-length aluminum or optional fiberglass translucent material.



- ❶ Roof sheet
- ❷ Roof bows

## About the trailer



### **WARNING**

- If the roof is damaged, the upper side walls also may be damaged, which may result in buckling and a total collapse of the trailer.
- Do not allow any moisture or chemicals to enter the walls or roof through holes. Doing so may cause corrosion and add weight to the trailer.
- Ensure the proper clearance to prevent the trailer's roof from hitting other objects while operating the trailer.

## ***Door assembly***

There are two types of doors mounted on the trailer.

- Swing door
- Roll-up door



### **CAUTION**

- Read and follow all safety instructions and labels attached to or provided with the door.
- Regularly check the door assembly, including doors, hinges, panels, frame, lock rods, lock rod keepers, and door hold back securement devices for damage or distortions.
- Compression seals must be checked and repaired or replaced if necessary to ensure a weatherproof closure to protect cargo.
- Interior linings or insulated doors should be checked for damage or loose or missing fasteners and repaired as required.
- Safety equipment in the rear frame area, such as door hold backs, grab handles, steps, ramps, and slip-resistant materials must be inspected through the Trailer Preventive Maintenance (TPM) program. Repair or replace them if necessary.



- Check anti-rack rear door locks for damaged, distorted, or cracked tubes.
- Check operation and engagement of cams into keepers.
- Check bearing plates for loose or missing fasteners.
- Check tamperproof fasteners in gravity keepers and the top and bottom hinge.
- Check the operation and engagement of the third-point lock (if equipped).
- On insulated trailers, inspect the interior sealing surfaces (PVC wedging) to ensure that the thermal efficiency is maintained. Repair or replace any components if necessary.

#### ❖ NOTE

The frequency of the door maintenance may vary with climatic conditions and work applications.


## About the trailer

### Swing door assembly

The swing door assembly consists of the rear frame, two door panels with perimeter molding, gasket seals, hinges, door-locking hardware, lock rod, top and bottom keepers, and door hold backs. It is designed to provide full-width access to the trailer rear for loading/unloading and maximizing the net cargo area. Refer to the following diagram for each component of the swing door.

#### ❖ NOTE

When the door is properly closed, the rear door lock rods and the top and bottom keepers secure the door and hold the rear frame and trailer sides square during transit. It is most important that the lock rods and keepers temporarily unitize the doors and the rear frame for water and near airtight seals.



- ❶ Hinges
- ❷ Cam keeper (top)
- ❸ Locking rod

- ❹ Door panel
- ❺ Door handle
- ❻ Cam keeper (bottom)

**CAUTION**

- Follow the instructions below to avoid serious injuries when opening or closing the door panels.
  - Be careful when opening the swing doors. The cargo may shift against the doors during transit.
  - In windy conditions, secure the door panels to both sidewalls after opening the door panels.
  - Open swing doors a full 270° against the outside trailer sidewalls and securely engage the door hold back securement devices.
- Do not move the trailer with the doors open, except when backing into or pulling away from a loading dock.
- Do not stand within the swing radius of the swing doors if you have not checked the security of the door to the hold back security device.
- Before operating the swing doors, carefully inspect all hardware including hinges, lock rods and keepers, and door hold backs to ensure the components are not damaged.


## About the trailer

### Roll-up door assembly

The roll-up door assembly consists of horizontal door panels, door tracks, a door operating mechanism, and locking hardware. The roll-up door is operated (both up and down) by a pretensioned spring. The door should be properly adjusted and should stay in position when properly counterbalanced by the pretensioned spring.

#### ❖ NOTE

If the locking lever is released, the door should not descend before pulling it down or rise before providing lift.



- 1 Door panel
- 2 Locking lever

- 3 Grab handle
- 4 Pull down strap

**WARNING**

- If the springs on the door are highly tensioned or loose, the door may open or close too quickly or slowly while operating the door, resulting in serious injury or death. In this case, have the door adjusted or repaired by a qualified service technician.
- Do not stay in the opening or the doorway when the door is moving up or down.


**CAUTION**

- Before moving the trailer, check if the door is properly closed and locked.
- Operate the door only when it is properly adjusted, and stayed away from obstructions around the trailer.
- Do not use any part of the door, such as the strap or lift handle, as an aid when entering or leaving the trailer.
- Be careful when passing under the roll-up door with a forklift.
- Clear any obstruction from the door tracks and the base of the mounting angle where the door comes down to the floor.

## About the trailer

### *Front and side walls*

The front and side walls provide the structural integrity for the trailer design. Refer to the following diagram for each component of the front and side walls.



- 1 Front top rail
- 2 Side top rail
- 3 Side panel
- 4 Front panel

- 5 Front bottom rail
- 6 Front corner post
- 7 Side bottom rail


**WARNING**

If the sidewalls are damaged, the trailer may become deformed or collapsed, which can result in serious injury or death.

## Rear impact guard

The rear impact guard is used to reduce injuries and fatalities associated with lighter vehicles by preventing intrusions underneath the rear side of the trailer during impacts and absorbing some of the collision energy. It is mounted on the underside of the rear end of the trailer as an integral part of the trailer rear frame and understructure.

The rear impact guard consists of both vertical and horizontal structural components, forward bracing and numerous welds, hardware, and a certification label or a plate.



- ① Vertical bracket assembly
- ② Step guide assembly

## About the trailer



### **CAUTION**

- Inspect the rear impact guard before operating the trailer.
- Ensure that there are no cracks in the welds, all fasteners are properly secured and no structural members are bent or deformed. Replace or repair any component that does not comply with the dimensional requirements of the Federal Motor Vehicle Safety Standards (FMVSS).
- A damaged rear impact guard that does not satisfy the performance requirements mandated by the National Highway Traffic Safety Administration (NHTSA) and the Federal Motor Carrier Safety Administration (FMCSA) must be replaced or repaired.
- The integrity of rear impact guard must be maintained to meet NHTSA standards.
- Broken welds, bent components, missing or loose fasteners, excessive corrosion or other damage to the rear impact guard can affect its performance if a rear-end collision occurs.
- Detailed guard inspection, service, and repair records must be maintained on all guards for your protection.
- Repairs must be made in accordance with the guard's original design specifications.
- Replace the damaged rubber bumpers.
- The rear impact guard is subjected to impacts and stress during docking and loading operations. If these impacts and the stresses are excessive, the rear impact guard may be damaged.



**NOTICE**

- Federal Law requires the rear impact guard to meet the specifications listed in the Federal Motor Vehicle Safety Standards 49 CFR Sections 571.223 and 571.224. These federal standards include the requirements on strength and energy absorption, dimensional measurements as to width and road surface to lower horizontal member clearance, and certification of testing.
- At the time of manufacture a label or plate attesting to the certification is placed on the forward-facing surface of the lower horizontal member verifying it meets all standards. Do not remove or alter this label. Doing so is prohibited by law.
- You must take the photographs of any accident involving the rear impact guard to accurately show the condition of the trailer and structure and any vehicle or vehicles involved. These photographs should be taken at the time of the accident and before performing any repairs. The following views of the photographs should be taken.
  - Overall views of the trailer and impacting vehicle or vehicles from different angles showing the positions of all vehicles involved in relation to each other and to the roadway
  - Views of the relative condition of the trailer structure
  - Views of damaged areas
  - Close-up views of the damaged areas, including any surrounding structures

# MEMO

---

# Operating the trailer

<b>Coupling and uncoupling the trailer.....</b>	<b>56</b>
Coupling .....	57
Preparations before coupling .....	58
Inspecting the tractor's fifth wheel and trailer's kingpin .....	58
Inspecting the area around the trailer and tractor .....	58
Connecting the tractor to the trailer .....	59
Connecting the air and electrical lines .....	61
Supplying air to the trailer .....	62
Raising the landing gear .....	62
Checking coupling connection (test lock) .....	63
Inspecting the coupling status .....	63
Uncoupling .....	64
Preparations before uncoupling .....	64
Lowering the landing gear .....	64
Disconnecting the air and electrical lines .....	65
Disconnecting the tractor from the trailer .....	66
Loading the trailer .....	67
Accessing the trailer .....	68
Load distribution .....	70
Distributing weight .....	71
Loading heavy concentrated loads .....	73
Sliding the trailer tandems .....	75
Performing pre-trip inspection .....	79
Inspecting the tractor .....	81
Inside the tractor .....	81
Exterior of the tractor .....	82
Inspecting the trailer .....	82
Coupling parts of the trailer .....	82
Side of the trailer .....	83
Under the trailer .....	83
Inside the trailer .....	84
Top of the trailer .....	84
Rear of the trailer .....	85
Inspecting the coupling status .....	85
Operating the trailer .....	86
Aerodynamic side skirts .....	87
Tire pressure systems .....	87
California greenhouse gas phase 2 .....	88
Product warranty sample .....	89
Find a dealer near you .....	90

## Operating the trailer


### Coupling and uncoupling the trailer

Coupling and uncoupling properly can ensure safe operation of both the tractor and trailer, and it prevents potential risks during trailer operation.



#### **WARNING**

- Incorrect coupling and uncoupling may result in serious injury or death.
- Do not attempt to couple or uncouple the tractor and the trailer at an angle that may cause jackknifing. Doing so may damage the trailer's structure.



- To prevent serious injuries and damage to the trailer or nearby objects, use a spotter during coupling or uncoupling.

**CAUTION**

Use chock blocks or apply the trailer brakes when uncoupling or coupling the tractor and trailer on the road or in the terminal area. Also, use chock blocks for unusual conditions.

**NOTE**

- Additional lighting is required if coupling and uncoupling are performed in low-light conditions.
- Coupling and uncoupling procedures may vary based on the specific tractor's models.

## Coupling

**WARNING**

Improper coupling between a tractor and a trailer may cause serious accidents, which may result in property loss, serious injury, and death. Ensure the following before each trip:

- The trailer has been properly coupled with the tractor.
- The tractor has the sufficient capacity and specifications to safely tow the trailer.

## Operating the trailer

### ***Preparations before coupling***

Follow the instructions on inspecting the trailer and tractor below before coupling.

### **Inspecting the tractor's fifth wheel and trailer's kingpin**

Exit the tractor and inspect the fifth wheel and kingpin.

- Check for corroded, damaged, or missing parts (plate, release lever, jaw, and fasteners) on the fifth wheel.
- Check if mounting to the tractor is secure.
- Check if the fifth wheel plate is in the correct position for coupling.
  - The fifth wheel is tilted down at the rear.
  - The jaws are open.
  - The release lever is in the automatic lock position.
- Lock the fifth wheel in place if your fifth wheel is the sliding type.
- Check if there is enough lubricant on the plate.
- Check the kingpin for damage.


### **Inspecting the area around the trailer and tractor**

Inspect the area for proper coupling and exterior of the trailer.

- Check if the area is level and firm enough to support the landing gear.
- Check if the trailer parking brakes are applied.
- Check if the cargo is properly secured.


## ***Connecting the tractor to the trailer***

1. Enter the tractor and release the parking brake.
2. Back up the tractor slowly and approach the trailer with the tractor as straight as possible.
  - Ensure the tractor is aligned with the trailer. You should have the tractor roughly in a straight line with the trailer.



## Operating the trailer

3. Back up the tractor slowly until the fifth wheel connects to the kingpin.
  - You must listen for and feel the fifth wheel latching into its locked position.



4. Apply the parking brake, check the trailer coupler height and inspect the upper coupler and kingpin.
  - The trailer's height must be low enough that it can be raised slightly by the tractor when the tractor is connected to the trailer. If required, raise or lower the trailer adequately.



### **CAUTION**


Do not raise or lower the trailer excessively. Doing so may damage the nose of the trailer or the trailer may not be coupled with the tractor properly.

- Check if the upper coupler and kingpin are aligned.



### ***Connecting the air and electrical lines***

Connect the air lines (service and emergency) and 7-way connector from the tractor to the air and electrical system connections on the trailer's front wall.



### **CAUTION**

To prevent air leaks in the gladhands, check for leaks, damage or wear on the rubber seal of the gladhands. In addition, to supply air to the trailer brake system properly, check if the filter screens on the rubber seals are clean and not blocked by contaminants.

### **❖ NOTE**

- In case of any unexpected movement, wait for a few seconds after making the air connections.
- Ensure the air lines are safely supported so that they are not crushed or caught when the tractor is backing under the trailer.
- Ensure there is enough slack so that air supply lines and the 7-way connector are not disconnected.

## Operating the trailer

### *Supplying air to the trailer*

1. Enter the tractor, open the trailer supply valve to supply air to the trailer brake system, and wait until the air pressure gauges indicate a normal range for the pressure level.
2. Perform the following to check the brake system for crossed air lines.
  - Turn off the tractor's engine and check for air leaks in the brake system.
  - Apply the service brakes, check if the air pressure is within the normal range and listen for air leaks at the service gladhand.
3. If there are no air leaks, turn on the tractor's engine.

### *Raising the landing gear*

#### **NOTE**

For more information on each component of landing gear and instructions, refer to "Landing gear" on page 23.

1. Pull the crank handle of the landing gear to set it to the low gear.
2. Turn the crank handle clockwise until the landing gear is completely raised and then secure the crank handle.

### ***Checking coupling connection (test lock)***

Using the lowest forward gear and the engine idling, move the tractor forward to check if the fifth wheel is properly engaged and locked.

#### **❖ NOTE**

If the fifth wheel is not fully engaged and locked, it will release and the tractor will move forward. If this happens, properly engage and lock the fifth wheel again.

### ***Inspecting the coupling status***

Inspect the following for coupling status. If necessary, use a flashlight during inspection.

- Ensure there is no space between the upper coupler and fifth wheel.
- Ensure the fifth wheel's jaws lock around the kingpin shank.
- Ensure the fifth wheel's locking lever is in the "Locked" position.
- Ensure there is proper clearance among the air lines and 7-way connector cable.



#### **WARNING**

You must perform a visual inspection and verify a proper coupling. A visual inspection is required by law.

## Operating the trailer

### Uncoupling

#### *Preparations before uncoupling*

1. Select a location suitable and firm enough to support the weight of trailer and tractor.
2. Move the tractor in a straight line with the trailer.



#### **CAUTION**

Do not pull out the tractor at an angle. Doing so may damage the support legs of the landing gear and upper coupler.

3. Shut off the trailer air supply valve to lock the trailer brakes.
4. Back up the tractor slightly to ease the pressure on the fifth wheel locking jaws, which allows you to release the fifth wheel locking lever easily, and then apply the trailer parking brake while the tractor is pushing against the kingpin.

#### *Lowering the landing gear*

#### **❖ NOTE**

For more information on each component of landing gear and instructions, refer to “Landing gear” on page 23.


1. Push the crank handle of the landing gear to set it to the high gear.
2. Turn the crank handle counterclockwise until the landing gear touches the ground, and then secure the crank handle. (Do not raise the trailer from the fifth wheel.)

#### **❖ NOTE**

If necessary, place a proper supporting material under the landing gear to prevent the trailer from sinking into the ground.

## *Disconnecting the air and electrical lines*

1. Disconnect the air lines (service and emergency) and 7-way connector from the trailer.



2. Connect the air line gladhands and the 7-way connector to their receivers at the back of the tractor.




### **CAUTION**

Stow the air lines and the 7-way connector into their receivers properly to ensure they are not damaged while driving the tractor.

## Operating the trailer

### *Disconnecting the tractor from the trailer*

1. Raise the release lever of the fifth wheel, and then pull the release lever fully until it is in the “open” position.



#### **WARNING**

While handling with the release lever, keep your legs and feet away from the rear tractor wheels to prevent serious injuries in case the tractor suddenly moves.

2. Move the tractor forward until the fifth wheel is disconnected from the kingpin, and then stop the tractor when the fifth wheel is fully out from under the trailer. The tractor frame should be still under the front of the trailer.
3. Apply the tractor parking brake, shift to “N” (Neutral), and then turn off the tractor’s engine.
4. Exit the tractor and check the trailer and its landing gear for damage.

## Loading the trailer

To load the trailer properly, always use the access equipment safely and ensure the proper weight distribution.



### **WARNING**

To avoid serious injury or death, do not overload the trailer. Overloading the trailer beyond the rated GVWR creates potentially hazardous operating conditions, including fatal loss of vehicle control and premature failure of the trailer components.

For more information on the trailer's GVWR, refer to "Vehicle Identification Number (VIN)" on page 18.

### **NOTICE**

- Reefer trailers transport food and food products. The interior of the reefer trailer's body structure must be clean before loading. Refer to the FDA Food Safety Modernization Act (FSMA) regulations of 2011 to keep the trailer clean for food transportation.
- Follow the instructions below to maintain the products' cleanness and freshness for reefer trailers.
  - Do not load products that may contaminate food products.
  - Do not use cleaning agents that may contaminate food products when cleaning the inside of the reefer trailer's body structure.
  - Products being transported should be loaded at a temperature as cold as or colder than the required temperature of the products at the time of delivery.

## Operating the trailer

### *Accessing the trailer*

The access equipment, such as the steps and handholds, are used for safe entry and exit of the trailer body structure.

To access the trailer from the ground when the trailer is properly supported by extended landing gear, you must use a step ladder or other equipment designed for ascent and descent with suitable height to reach the bottom-most step safely. Also, maintain three points of contact (both hands and one foot or both feet and one hand) at all times to prevent falls.



#### **CAUTION**

- Do not climb onto or into a trailer unless it is properly secured on a solid, level surface, and steps are firmly attached to it.
- Always maintain three points of contact when ascending or descending trailer steps or ladder rungs.
- Check if the components, such as welds, fastener connections, latches, hold downs, etc. function properly, and repair them if necessary. These items must be kept clean, degreased, and free of materials that may cause them to become slippery.
- If the tractor does not provide proper steps, handholds, and a slip-resistant deck plate for the rear of the tractor, do not access to the trailer steps from the tractor.
- Do not climb on steps while holding anything in your hands. Your hands must be free.
- Always face the trailer while ascending and descending.
- Wear slip-resistant footwear to avoid slipping and falling.
- Do not step on the tires, fenders, tractor frames, or mud flap supports.
- Do not step on air and electrical lines that run between the tractor and the trailer, and disconnect and store them properly if they are not in use.
- Do not use the access equipment if it is wet, icy, or slippery.



- Do not use steps and handholds provided on the trailer's front corner to inspect, or maintain any heating or cooling unit.
- Do not remain on steps and handholds provided on the trailer's front corner while the trailer is being coupled with or uncoupled from the tractor.
- Do not jump from the trailer deck. Doing so may result in serious injury.
- Do not use any part of the trailer, such as the strap or lift handle, as an aid when entering or exiting the trailer.
- Walk carefully inside the trailer. The floor may be slippery.
- All interior lights must be turned off before closing the trailer door.
- Retractable steps must be returned and secured in their stowed position before moving the trailer.

***NOTICE***

Inspect the access equipment in accordance with the regular Trailer Preventive Maintenance (TPM) Program.

## Operating the trailer

### ***Load distribution***

The cargo must be properly loaded, blocked, and secured to avoid load shifting.



#### **CAUTION**

- Improper loading, load distribution or cargo securement may damage the components of the floor assembly.
- Do not use pallets with small sized footprints. Doing so may damage the floor assembly.
- The sliding suspension must be placed in the rear most position during loading.
- Ensure the trailer is on a firm and level ground during loading.
- To prevent the trailer from moving forward during loading, chock wheels, or use dock locking devices.

#### **NOTICE**

- Before operating the trailer, check the highway's legal load regulations. They may differ from the maximum load indicated on the VIN plate.
- For proper trailer load distribution, you must comply with the following sections of Title 49 of the Department of Transportation (DOT) Federal Motor Carriers Safety Regulations (FMCSR) at the FMCSA Official website ([www.fmcsa.dot.gov](http://www.fmcsa.dot.gov)).
  - Section 393.100 General rules for protection against shifting or falling cargo.
  - Section 393.102 Securement Systems
  - Section 393.104 Blocking and Bracing
  - Section 393.106 Front End Structure


## Distributing weight




### WARNING

Before each trip, ensure that the payload has been evenly distributed and securely fixed in the trailer's storage compartment. Uneven distribution of payload weight creates potentially hazardous operating conditions, which may result in fatal loss of vehicle control.

The cargo must be evenly distributed from the front to the rear. Refer to the following diagram for uniform load distribution.




**When coupled**




**When uncoupled**

## Operating the trailer

Also, refer to the following examples of proper weight distribution on the cargo. To distribute equal weight on all rear tires on the trailer, position the load equally between sides.



**Incorrect distribution position**



**Correct distribution position**



### **CAUTION**

To prevent unexpected movement of the cargo, secure the cargo against lateral load movement using securing straps.


## Loading heavy concentrated loads




### WARNING

Before each trip, ensure that the payload has been evenly distributed and securely fixed in the trailer's storage compartment. Uneven distribution of payload weight creates potentially hazardous operating conditions, which may result in fatal loss of vehicle control.

When loading heavy, concentrated loads, distribute the load over the full length of the floor or place the concentrated load in the center of the trailer. Also, to distribute weight front to rear, use a skid with the appropriate length and firm materials.




**Incorrect position of heavy loads (rear)**




**Incorrect position of heavy loads (front)**

## Operating the trailer



**Correct position of heavy loads (center)**



**Correct position of heavy loads (front and rear)**



### **CAUTION**

Do not load the trailer with the payload concentrated at front. Doing so may reduce the tire mileage and bend the tractor's axle system. Also, if you apply brakes suddenly, the trailer's brakes may lock, resulting in flat spots on your tires and dangerous skidding.

## ***Sliding the trailer tandems***

To change the weight distribution between the tractor's drive axles and the trailer tandems, slide the trailer tandems toward the front or back of the tractor. If you move the trailer tandems forward, you can put more weight on the trailer tandems and take weight off the tractor's drive axles. Or if you move the trailer tandems toward the rear of the trailer, you can take weight off the trailer tandems and put more weight onto the tractor's axles. The sliding suspension can be repositioned in 4" or 6" increments within the length of the upper running gear rail.



### **CAUTION**

Before beginning the procedure, read the following instructions and select an adequate area to avoid potential safety hazards.

- You can only slide the suspension slider when the trailer is on level ground and the tractor and trailer are in a straight line. Otherwise, the tractor may damage the trailer while backing up.
- Before beginning the procedure, check if the area provides enough clear space for the tractor to be moved.
- Do not perform this procedure on loose gravel. Doing so may allow the trailer wheels to slide.

### **NOTICE**


Several state governments in the United States have regulations that require the trailers to control the weight on each axle with the kingpin to rear axle (KPRA) restrictions and adjusting the tandem center. Make sure you have set the tandem wheel base to meet the appropriate KPRA to satisfy the specific state regulations and federal bridge law requirements.

### **❖ NOTE**

The operation of the slider lock pins and their instructions may differ depending on the suspension slider manufacturers. Follow the manufacturer's instructions before adjusting the suspension sliders.

## Operating the trailer


1. Straighten the tractor and trailer, and apply both the tractor and trailer parking brakes.
2. Exit the tractor and check the slider for any damage.
3. Place the manual stop bar on the slider rail hole (the front or rear of the slider) to reposition the slider.
  - To move the slider forward, place the bar in front of the slider. To move the slider rearward, place the bar behind the slider.



4. Unlock the slider lock pins located in front of the running gear.
5. Enter the tractor and release the tractor brake while keeping the trailer brake applied.



6. Move the rig forward or backwards depending on the required slider position and stop moving the tractor when the slider has come into contact with the manual stop bar.


**CAUTION**

When moving the rig forward or backwards, do not move the tractor with excessive force or slam the trailer.

7. Apply the tractor brake, exit the tractor.
8. Check if the slider is properly positioned on the selected location and lock the slider lock pins to engage the lock mechanism.

## Operating the trailer

9. Check if the slider lock pins are properly engaged through the holes of both slider rails.



10. Place the manual stop bar in the slider rail holes to the rear of the slider.

## Performing pre-trip inspection

For safe operation of the tractor and trailer, conduct a full pre-trip inspection before every departure. Before starting the inspection, make sure the tractor and trailer are parked safely away from traffic on a level and firm ground. If necessary, block the trailer wheels using chock blocks for safety during the inspection.



### WARNING

Inspect, connect, or repair the tractor or the trailer carefully. The tractor may move unexpectedly and cause serious injuries.



### CAUTION

- Complete a full pre-trip inspection of the tractor, and then properly couple it with the trailer. Inspect the trailer after the coupling.
- During the inspection, the parking brakes must be applied to prevent the vehicle from moving unexpectedly.
- Visually inspect electrical wiring, brake components (including brake hoses), and welds for any damage or distortion. If you find any defects, report to the registered owner before starting your trip.
- Always follow the vehicle manufacturer's manual when operating the sliding suspension or any other part of the trailer.
- Do not operate the vehicle in a condition or manner likely to cause an accident or breakdown.
- If any component is damaged or cannot function properly, do not operate the trailer.
- Conduct another inspection if you cannot guarantee the safety.

## Operating the trailer

### **NOTICE**

- Operate the trailer in accordance with federal, state, provincial, and local statutes, including temporary rules and regulations in construction or other warning zones.
- All operators must be properly licensed and perform all the U.S. Department of Transportation (DOT) required inspection, repair, and maintenance.
- Check for current registration, DOT Inspection, all necessary license plates and an accurate bill of lading.
- Follow the North American Standard Out-of-Service Criteria which can be obtained through the Commercial Vehicle Safety Alliance (CVSA) at [www.cvsastore@CVSA.org](http://www.cvsastore@CVSA.org).
- Maintain the document with identifying information, including company number, make, serial number, or VIN, year, and tire size during operation. Also, inspection, repair, maintenance records, and scheduled inspection type, and due date must be stated.
- If you find any defect that could cause injury or death, immediately inform the National Highway Traffic Safety Administration (NHTSA) and notify Hyundai Translead. If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, the NHTSA cannot become involved in individual problems between you, your dealer, or Hyundai Translead. To contact the NHTSA, you may call the Vehicle Safety Hot-line toll-free at 1-888-327-4236 (TTY: 1-800-424-9153), or visit [www.nhtsa.gov](http://www.nhtsa.gov), or write to Administrator, NHTSA, 1200 New Jersey Ave. S.E., Washington, DC 20590. You can also obtain other information about motor vehicle safety from [www.nhtsa.gov](http://www.nhtsa.gov).

### ***Inspecting the tractor***

Before beginning to inspect the tractor, apply the tractor parking brake and shift to "P" (Park) while the tractor's engine is turned on. After completing the inspection, ensure parking brakes are applied and turn off the tractor's engine.

### **Inside the tractor**

Inspect the following inside the tractor.

- Check the air pressure and brake response by applying the foot brake for one minute.
- Turn on all lights, including the emergency flashers and the low and high beam lights. Make sure they all work properly.
- Honk the horn and check the steering wheel for excessive free play.
- Check if the oil pressure is at its normal operating range and the gauge is working properly.
- Check if mirrors on both sides of the tractor are clean and aligned.
- Check if the washer-wipers works properly, and inspect the windshield for damage.
- Check if the heater-defroster blower is working properly.
- Check if a charged fire extinguisher and emergency equipment are mounted on the tractor.

## Operating the trailer

### Exterior of the tractor

Exit the tractor and inspect the following on the exterior of the tractor.

- Check for oil, water, or fuel leaks.
- Check if the fuel tank cap on the tractor is secured tightly.
- Check the front tires, wheels, and wheel nuts for damage.
- Check the headlamps, clearance lights, identification lights, flashers, and turn signals for damage.
- Check the rear tractor wheels and tires for loose or missing lug nuts and damaged rims, and check the tread depth and oil level in the wheel end hub cap. Ensure the tires are properly inflated.

### *Inspecting the trailer*

After inspecting the tractor, inspect the following sections of the trailer.

### Coupling parts of the trailer

Inspect the following on the coupling parts.

- Check if the fifth wheel jaws are engaged and locked securely around the kingpin.
- Check if the electrical cord from the tractor is fully inserted in the 7-way connector and retained by the spring-loaded connector closure. Also, ensure the cord is unobstructed, free of chafing, and not restricted.
- Check if the air delivery hoses from the tractor are unobstructed, free of chafing, and correctly and securely attached to the gladhands. Listen for air leaks.

## Side of the trailer

Inspect the following on the sidewalls and landing gear.

- Check the landing gear for damage.
- Check if the landing gear legs are fully raised and the crank handle is securely stowed in the crank handle holder.
- Check if the fuel tank cap on the reefer trailer is tightly secured without any leaks (ThermoTech® model only).
- Check the exterior sides of the trailer for tears or cuts on the surface skin.



### CAUTION

The side closure of the Composite® model must not have any tears or cuts.

- Check the side doors of the trailer for damage (if equipped).
- Check for proper placard and shipping papers (if equipped).
- Check and clean side marker lights and the conspicuity tape.

## Under the trailer

Inspect the following on the running gear assembly.

- Ensure that there are no permanent deformations, excessive rust, or missing or damaged rivets at the bottom of the trailer, including the cross members.
- Check the sliding suspension, ensure its position is correct for the load and the areas you will travel. All the locking pins must be completely engaged in the upper slide rail. There are 2-pin and 4-pin locking mechanisms on sliders. Ensure that all of the hold down brackets are firmly attached.

## Operating the trailer

---

- Check each air spring (air bag) for damage, ensure it is properly inflated and listen for air leaks.
- Check if the brakes, including the ABS system, are properly adjusted and can be operated properly.
- Check the trailer wheels and tires, and listen for air system leaks.
- Check if the mud flaps are securely attached to the brackets and if the brackets are properly secured to the trailer.

### **Inside the trailer**

Inspect the following on the floor assembly.

- Check the interior walls of the trailer for damage, particularly within two feet of the floor.
- Check the floor of the trailer for missing pieces, cracks, delamination, wavy appearance, and water stains. These may indicate a hazard to the safe operation.

### **Top of the trailer**

Check for roof damage. This indicates a mishandling of the loads when the trailer was loaded or unloaded.



## Rear of the trailer

Inspect the following on the exterior lights and door.

- Check if all lights are clean and working properly.
- Check if the doors are fully sealed and locked. If the doors are not secured with locks or seals, make sure no one is in the trailer.
- Check the door hinges for missing or damaged bolts/rivets.
- Check the rear impact guard for weld cracks, bent or broken bracing, and a straight lower horizontal member. Make sure the certification label or plate is in place.
- Check if the conspicuity tape is properly placed. Clean it if there is any dust or contaminants.

## *Inspecting the coupling status*

After completing the inspection of the tractor and the trailer, check for the proper coupling status and ensure the overall safety.

- While the trailer brakes are applied, release the tractor parking brakes and engage the clutch in first gear to test the tractor-trailer coupling.
- Ensure that there are no objects hanging from under the truck or the trailer.

## Operating the trailer

### California Greenhouse Gas Phase 2 Information

California Phase 2 trailer standards take effect for all trailer manufacturers in 2020. The standards are intended to make trailers more efficient and lower the greenhouse gas emissions associated with their use. Affected trailer types include box-type trailers, flat bed trailers, tank trailers, and container chassis. The trailer standards can be met through aerodynamic improvements, low rolling resistance tires, tire pressure systems (Tire Pressure Monitoring System/Automatic Tire Inflation System), and/or weight reduction.

Hyundai Translead emission-related warranty covers all aerodynamic devices, low rolling resistance tires, tire pressure systems, lightweight components, and other emission-related components that may be included: a warranty period of five years except for trailer tires, a warranty period of one year. For more information, please refer to the Warranty Statement.

If emission-related components are installed, the customer will receive a separate maintenance instruction for that specific device. If the maintenance instruction is missing, please contact Hyundai Translead Warranty Department.

## Aerodynamic Side Skirts

If emission-related components are installed, the customer will receive a separate maintenance instruction for that specific device. If the maintenance instruction is missing, please contact Hyundai Translead Warranty Department.

- Check the side skirt panels and supporting brackets for any damage or scratches
- Check the panels to see if they are loose
- Check the fasteners on the side skirt for any loose or missing bolts, and tighten if necessary

If any repairs need to be made for the side skirt, please refer to the manufacturer's manual for specific instructions.

## Tire Pressure Systems

Tire Pressure Monitoring System (TPMS) and Automatic Tire Inflation systems (ATIS) are used to monitor pressure of tires and/or direct air into tires to a preset pressure level to ensure that the tires do not remain underinflated. Periodic visual inspections are required for the proper operation of the tire inflation system.

- Check that the indicator light is working properly
- Check for any air leaks on all hoses, fittings, and wheel ends of the inflation system
- Check the control box for any damages
- Check tire pressure, as instructed in Page 31

If any repairs need to be made for the side skirt, please refer to the manufacturer's manual for specific instructions.

If the indicator light stays on for at least 10 minutes or a leak is present, please refer to the manufacturer's manual for troubleshooting instructions.


These maintenance steps are not necessary to keep the emission-related warranty valid.

## Operating the trailer

### California Greenhouse Gas Phase 2 Information

In order to retain the as-certified emission and fuel consumption performance of the trailer, the customer must install tires meeting or exceeding the rolling resistance performance of the original equipment tires. Hyundai Translead recommend to install the same tire. For a specific rolling resistance performance of the tire, please contact the tire supplier or Hyundai Translead.

The California Phase 2 Certified trailer will be installed a GHG plate next to the VIN plate shown below.

 <b>HYUNDAI Translead</b>	
VEHICLE EMISSION CONTROL INFORMATION	
FAMILY: [ FAMILY CODE ]	SUBCATEGORY: [ SUBCATEGORY ]
V.I.N.: [ 3H3 ]	MATERIAL No. [ 300XXXXX ]
DATE OF MANUFACTURE: [ DATE ]	
EMISSION CONTROL SYSTEM:	
<input type="checkbox"/> LRRA	<input type="checkbox"/> TARF
<input type="checkbox"/> TPMS	<input type="checkbox"/> WRTS
<input type="checkbox"/> WBLW	<input type="checkbox"/> DWLW
<input type="checkbox"/> TGRT	<input type="checkbox"/> TAUD
<input type="checkbox"/> WRTW	<input type="checkbox"/> WBSW
<input type="checkbox"/> DWSW	
<input type="checkbox"/> TATS	<input type="checkbox"/> ATI
<input type="checkbox"/> WRTC	<input type="checkbox"/> WBAW
<input type="checkbox"/> DWAU	
THIS VEHICLE COMPLIES WITH CALIFORNIA REGULATIONS FOR	
[ MY ] HEAVY-DUTY VEHICLES.	

You or a repair shop may maintain, replace or repair emission control devices and system as long as the emissions level meets or emits less than the original emissions level.

If you need more information on Greenhouse Gas standards and/or a specification of emission related components, please contact Hyundai Translead along with VIN or Material Number.

For more warranty information on GHG Phase 2, please contact Hyundai Translead Warranty Department at [warranty@hyundaitranslead.com](mailto:warranty@hyundaitranslead.com)

Identifier	The trailer is equipped with:
LRRA	Low Rolling Resistance Tire
TGRT	Gap Reducing Trailer Fairing
TATS	Trailer Aerodynamic Side Skirt
TARF	Trailer Aerodynamic Rear Fairing
TAUD	Trailer Aerodynamic Underbody Device
ATI	Automatic Tire Inflation System
TPMS	Tire Pressure Monitoring System
WRTW	Weight-reducing Trailer Wheels
WRTC	Weight-reducing trailer upper coupler plate
WRTS	Weight-reducing trailer axle sub-frames
WBSW	Wide-base single trailer tires with steel wheel
WBAW	Wide-base single trailer tires with aluminum wheel
WBLW	Wide-base single trailer tires with light-weight aluminum alloy wheel
DWSW	Dual-wide trailer tires with steel wheel
DWAW	Dual-wide trailer tires with aluminum wheel
DWLW	Dual-wide trailer tires with light-weight aluminum alloy wheel

# MEMO

---

# Maintaining the trailer

<b>Inspecting the trailer .....</b>	<b>88</b>
Trailer body structure .....	89
Floor assembly .....	89
Roof assembly .....	90
Door assembly .....	90
Swing door .....	91
Roll-up door .....	92
Sidewalls .....	93
Front wall .....	93
Upper coupler and kingpin .....	94
Brake system .....	95
Air system .....	96
Draining the air tank .....	97
Anti-lock brake system (ABS) .....	97
Lighting system .....	98
Suspension system .....	101
Air spring suspension (optional) .....	101
Leaf spring suspension (optional) .....	102
Landing gear .....	103
Wheels and tires .....	104
<b>Lubricating trailer parts .....</b>	<b>108</b>
Lubricating the fifth wheel (of a tractor) .....	109
Lubricating the wheel-end assembly .....	110
Adding oil .....	112
Adding semi-fluid grease .....	113
Lubricating the wheel nuts and studs .....	114
Guidelines for proper wheel assembly .....	116
Lubricating the landing gear .....	118
Lubricating body parts .....	120
Lubricating the sliding suspension rail .....	120
Lubricating the door systems .....	121
Swing doors .....	121
Roll up door .....	122

## Maintaining the trailer

### Inspecting the trailer

This section provides instructions for carrying out the required inspection of each part of the trailer. Follow the instructions in this section to inspect the trailer to ensure safe operation and optimal performance. For more information on the location of each component, refer to the “Overview of the trailers” on page 19.



#### **CAUTION**

Periodically check every part of the trailer for proper operation. If you find any damaged or worn parts during inspection, repair or replace them immediately.



#### **NOTE**

To perform the trailer preventive maintenance program, contact the Truck Trailer Manufacturers Assn. (TTMA) at 703-549-3010 or visit its website at [www.trucktrailer.org](http://www.trucktrailer.org) to obtain the “Trailer Maintenance Manual” document.



## Trailer body structure

Inspect the trailer body structure before every departure. Also, inspect the trailer body structure before loading or unloading the trailer.



### CAUTION

Do not expose any part of the body structure to corrosive materials or solvents. Doing so may void the trailer warranty.

### NOTICE

Safety equipment in the rear frame area, such as door hold backs, grab handles, steps, ramps, and slip-resistant materials, must be inspected frequently in connection with a Trailer Preventive Maintenance (TPM) program. Repair or replace them if necessary.

## Floor assembly


Part	Checkpoint	Tasks
<b>Floor</b>	Wooden boards (for dry van trailers)	Check for damage or delamination.
	Aluminum boards (for reefer trailers)	Check for damage, cracks, or deformation.
	Floor boards	Check for loose or missing fasteners.
	Scuff bands	
	Sub-floor (for reefer trailers)	Check for damage, cracks, deformation, or bends.

## Maintaining the trailer


### *Roof assembly*

Part	Checkpoint	Tasks
<b>Roof</b>	Whole assembly	Check for cracks, tears, or missing rivets.
	Sheet	Check for loss of bow bonding, looseness, or puncture damage.
	Bows	Check for damaged or missing parts.

### *Door assembly*

Part	Checkpoint	Tasks
<b>Door</b>	Panels	Check for damage or distortion.
	Hinges	
	Locking hardware	
	Hold back securements	
	Seals	Check for damage or wear.   <b>CAUTION</b> You must repair or replace damaged or worn door seals to ensure a weatherproof enclosure to protect cargo.

## Swing door

Part	Checkpoint	Tasks
<b>Swing door</b>	Anti-rack rear door locks	Check for damage, distortion, or cracks on tubes.
	Cams	Check for the operation and engagement into keepers.
	Bearing plates	Check for loose or missing fasteners.
	Gravity keepers	Check for tamperproof fasteners.
	Top and bottom hinges	
	Third-point lock (if equipped)	Check for the proper operation and engagement.
	PVC wedging interior sealing surfaces (insulated trailers only)	<p>Check for damage or wear.</p> <div>  <b>CAUTION</b>                      You must repair or replace damaged or worn interior sealing to maintain thermal efficiency.                 </div>

## Maintaining the trailer

### Roll-up door

Part	Checkpoint	Tasks
<b>Roll-up door</b>	Nuts and bolts	Check if they are tight and secure.
	Cables at attachment points	Check for frayed or damaged parts and replace them.
	Cable drums	Check for tightness against bearings.
	Rollers	Check for smooth operation and replace all sliding or damaged rollers.
	Door lock	Check if it is free and operating properly.
	Hinges	Check for broken or damaged parts and replace them.
	Tracks	Check for damage or obstruction through the full travel of the door and rollers.
	Door openings	
	Fasteners	Check for loose or damaged fasteners on the lift handle, lock, pull strap, hinges, and roller track, and tighten or replace them.
	Pull straps	Check for frayed, damaged, or severely worn parts and replace them.

## Sidewalls

Part	Checkpoint	Tasks
<b>Sidewalls</b>	Whole assembly	Check for loose, missing, or damaged rivets and fasteners.
	Sheets	Check for dents, dings, deep scrapes, delamination and holes.
	Bottom-side rails	Check for damage, such as bends, scrapes, and cracks.
	Top-side rails	
	Rear frame	



### CAUTION

- Have any damage on the side sheets inspected by a qualified trailer facility to determine if the sidewall's structural integrity has been compromised and requires immediate repair.
- If the rear frame, top-side rail, or bottom-side rail are damaged, have them repaired immediately by a qualified technician.

## Front wall

Part	Checkpoint	Tasks
<b>Front</b>	Whole assembly	Check for loose, missing, or damaged rivets and fasteners.
	Top front	Check for tree limb damage. <div> <b>CAUTION</b>              If the top front is damaged by tree limb, have it inspected by a qualified technician. It may cause moisture intrusion.           </div>
	Seams	Check for damage before each trip.

## Maintaining the trailer

### Upper coupler and kingpin

To ensure safe operation of the tractor and trailer, inspect the upper coupler and kingpin before and after every coupling. Regularly inspect the upper coupler and kingpin to ensure that they are properly lubricated and there is no excessive damage or wear.



#### **WARNING**

Frequently inspect the coupling components of the tractor and trailer. Property loss, serious injury, or death may result if damaged coupling components fail during trailer operation.



#### **CAUTION**

- Damaged kingpin, upper coupler structure, and connecting fasteners reduce the structural integrity and degrade the trailer's performance.
- Do not operate the trailer without inspecting the upper coupler and kingpin for damage. Immediately report any damage to your supervisor and repair it.
- Although the kingpin is made of hardened forged steel, it can be easily damaged, wear or broken with abuse.
- Before coupling, ensure that the fifth wheel is properly lubricated and the fifth wheel jaws are open to receive the kingpin. After coupling, ensure the following:
  - There is no space between the upper coupler and fifth wheel.
  - The fifth wheel jaws have closed around the kingpin shank.
  - The locking lever is in the locked position.

#### **NOTICE**

A visual inspection of the coupling is mandatory and required by law.

Part	Checkpoint	Tasks
<b>Upper coupler</b>	Surface	<ul style="list-style-type: none"> <li>• Check if it is properly lubricated.</li> <li>• Check for cracks and deformation of pick-up plate.</li> </ul>
	Fasteners	<ul style="list-style-type: none"> <li>• Check if they are in place and tightened properly.</li> <li>• Check for loose, missing, or damaged parts, and replace them.</li> </ul>
<b>Kingpin</b>	Surface	Check if it is properly lubricated.
	Bottom locking flange	Check for its proper condition.

### ❖ NOTE

If the fasteners of the upper coupler, side bottom rail, or rear frame wing plate are replaced with new ones, check if the replacement fasteners are the same diameter, design, and strength rating as the original equipment.

## Brake system

To ensure safe operation, inspect the brake system before every departure.



### CAUTION

Do not operate the vehicle if the brake system is defective or not properly adjusted. Have your vehicle repaired by a qualified technician.

### NOTICE

Inspect and adjust the brake system in accordance with the DOT requirements and a preventive maintenance program.

## Maintaining the trailer


### Air system

Part	Checkpoint	Tasks
<b>Air system</b>	Air hoses	Check for broken, missing, corroded, or damaged parts, and repair or replace them.
	Gladhands (on tractor and trailer)	<ul style="list-style-type: none"> <li>• Check for broken, missing, corroded, or damaged parts, and repair or replace them.</li> <li>• Check for leaks, damage or wear on the rubber seal.</li> <li>• Check if the filter screens on the rubber seals are clean and not blocked by contaminants.</li> </ul>
	Screens (on tractor and trailer)	Before connecting, make sure they are clean and not contaminated.
	Air dryer system	Check if it is equipped in the tractor.
	Air tank drain cocks	Daily open all of them to drain moisture from the system.
	Air gauges (on tractor)	Check for unusual air consumption to keep the air system tight.
	Service brake chamber plastic end cap	Check if it is in place to prevent dirt and contaminants.
	Service brake chamber clamping	Check if it is secure and not damaged.




## Draining the air tank

Daily drain moisture and contaminants from the air tank to keep the air system clean and in optimal condition. To drain the air tank, rotate the drain cock at the bottom of the air tank until it is fully opened, and then wait until the moisture has completely flown out from the air tank.



## Anti-lock brake system (ABS)

Part	Checkpoint	Tasks
<b>ABS system</b>	ABS indicator light	<p>Check if the ABS indicator light located at the trailer's rear-left corner turns on and off when electrical power is initially applied to the ABS.</p> <div>  <b>CAUTION</b> <p>If the ABS indicator light does not turn on or remains turned on while power is continuously applied, have it inspected and repaired or replaced by a qualified service facility.</p> </div>

## Maintaining the trailer

### Lighting system

Inspect the lighting system before every departure. Ensure that the lighting system operates properly and all lights and reflectors are clean enough to provide optimal visibility for safe operation.



#### **CAUTION**

- Do not operate the trailer if any light is damaged or cannot function properly.
- Turn off the lights while the trailer is positioned at a loading dock.
- Turn off all the interior lights before closing the trailer door.
- Use only original components for the lighting system.




#### **NOTE**

The Hyundai Translead's PC-rated front marker lights (visible over 180 degrees) prevent damage from the sides and comply with Federal Motor Vehicle Safety Standard 108 (FMVSS 108).

Part	Checkpoint	Tasks
Lighting system	Lights	<p>Check each light to make sure it is clean and operating properly while parking lights are activated.</p> <div> <p><b>❖ NOTE</b></p> <p>When replacing a pig tail marker light, leave 12 inches of extra length (slack) to allow the marker light could be changed from the outside of the trailer.</p> </div>
	4-way flashers	Check each flasher to make sure it is clean and operating properly while emergency flashers are activated.
	Reflectors	<ul style="list-style-type: none"> <li>• Check if the reflectors are clean and properly placed.</li> <li>• Check if the side reflectors are covering at least half of the trailer length. If you have replaced the reflectors with new ones, make sure the new reflectors comply with the same DOT regulations (C, C2, C3 or C4) and that they are same as the reflectors originally installed on the trailer.</li> </ul>

## Maintaining the trailer

Part	Checkpoint	Tasks
	Wiring and electrical system	<ul style="list-style-type: none"> <li>• Check for all wiring junctions and ground connections to ensure solid connections.</li> <li>• Check all wiring junctions and ground connections for poor connections and corrosion. If necessary, clean and grease them with dielectric grease.</li> <li>• Check the wiring harness for damage or unsupported wiring.</li> </ul> <div>  <b>CAUTION</b> <ul style="list-style-type: none"> <li>• Do not cut the wire or use a test probe (spike) to pierce insulation to prevent punctures to the wire jacket. If moisture is collected on the wire strands, the connections may be corroded.</li> <li>• For the dome lights, do not use any bulb with more than 21 candlepower. Stronger light may emit too much heat and ignite a fire in the cargo area. Load cargo away from the dome lights and turn off the dome lights before operating the trailer.</li> </ul> </div> <ul style="list-style-type: none"> <li>• Check if the trailer is connected to a tractor that supplies 12 volt DC current from the tractor's pigtail to the trailer's 7-way connector.</li> </ul>

## Suspension system

To ensure safe and proper trailer braking system during operating the trailer, inspect the suspension system before and after every operation.

### ❖ NOTE

For more information on the specifications for inspections, torque bolts, and the individual air suspension assembly, visit the manufacturer's website or visit the Hyundai Translead website at [www.hyundaitranslead.com](http://www.hyundaitranslead.com).

### *Air spring suspension (optional)*

Part	Checkpoint	Tasks
<b>Air spring suspension</b>	Air spring (air bag)	Check all air springs for damage and proper inflation. If necessary, Inflate each air spring equally to the proper level. Check all air springs for air leaks.
	Shock absorbers	Check for damage or internal leaks.
	Height control valve	Check for secure attachment and proper operation.

### NOTICE



In accordance with the U.S. Department of Transportation (DOT) regulations, inspect the air spring suspension systems before and after operation.

## Maintaining the trailer

### Leaf spring suspension (optional)

#### ❖ NOTE

For more information on the specifications for inspections, torque bolts, and the individual air suspension assembly, visit the manufacturer's website or visit the Hyundai Translead website at [www.hyundaitranslead.com](http://www.hyundaitranslead.com).

Part	Checkpoint	Tasks
<b>Leaf spring suspension</b>	Whole assembly	<ul style="list-style-type: none"> <li>• Check if there are any missing or broken parts in the leaf spring suspension.</li> </ul> <div>  <b>WARNING</b>  Broken spring leaves, missing or loose U-bolts, or other defective conditions likely to cause axle shifts are hazardous and can cause accidents or breakdowns. </div> <ul style="list-style-type: none"> <li>• Check if the leaf springs are securely clamped to the spring seats and axle to prevent any movement between U-bolts.</li> </ul> <div>  <b>CAUTION</b>  Even a slightly loose connection can cause misalignment of the axles, resulting in excessive tire wear and poor trailer tracking. </div>

## Landing gear

To ensure that the trailer is safely supported when it is uncoupled from the tractor, inspect the landing gear on a regular basis. For more information on lubricating the landing gear, refer to “Lubricating the landing gear” on page 118.



### WARNING

Perform regular inspection and maintenance of the landing gear components to avoid potentially hazardous situations which may cause serious injury or death.



### CAUTION

Do not force the support legs beyond their normal raised or lowered positions. Doing so may damage the landing gear.

Part	Checkpoint	Task
Landing gear	Attachment point	Check for broken, missing, corroded, or damaged parts on all braces at each attachment point, including the hinge bolt.
	Moveable parts	Check all moveable parts, including the bushings, bearings, and high and low gears for proper lubrication.
	Support legs	<ul style="list-style-type: none"> <li>• Before uncoupling the tractor from the trailer, check if they are fully extended and completely in contact with the ground to support the trailer weight.</li> <li>• Before moving the trailer, check if they are fully retracted and that the crank handle is properly positioned in its keeper.</li> </ul>

## Maintaining the trailer

### Wheels and tires

To ensure safe operation, inspect your wheels and tires before every departure. For more information on lubricating the wheel, refer to “Lubricating the wheel-end assembly” on page 110.



#### **WARNING**

- Cracked or damaged wheels, loose lug nuts, and missing studs are hazardous and can lead to wheel loss, resulting in serious injury or death.
- Tires and wheels are very heavy. Be careful when carrying or handling them.
- Servicing tires and wheels/rims is very dangerous and must only be performed by trained personnel using proper tools and procedures. To obtain more information on servicing wheels and tires, visit the websites of the US Department of Labor and NHTSA.
- Do not operate the trailer if the rims or rings are excessively damaged or corroded. Also, deflate the tires before removing the rims or wheels from the running gear.



#### **CAUTION**

- Do not operate the vehicle with tires that have low or no pressure.
- Tires must only be inflated while in a restraining device/safety cage.
- Do not inflate tires above the maximum inflation pressure molded on the tire by the tire manufacturer. Tires must be matched with compatible rims for safe operation.
- Tires next to each other need to be within a 4/32" thread depth of each other to avoid irregular wear.





- Do not overload the tires. The total load per tire must not exceed the tire manufacturer's specified load carrying capacity at the stated inflation pressures for both tires and rims.
- When replacing the tires or rims, replace them with the same size, type, and load rating as the original ones.
- Tires used for more than six or seven years from their date of manufacture may need to be replaced due to dry rot or cracking.
- To prevent wheel separation, periodically inspect the wheels during the 50 to 100 miles after the initial in-service date and at intervals that do not exceed 25,000 miles. Dismount and mount the wheel again. First, tighten the nuts with your fingers, then tighten them to 50 lb-ft, following the recommended cross over pattern, and then tighten to 496 lb-ft, following the cross over pattern. For more information on the tightening procedure, refer to "Guidelines for proper wheel assembly" on page 116.

## **NOTICE**

- Inspection, lubrication and maintenance of the wheel end system must comply with the Technology and Maintenance Council's (TMC) Recommended Practice No.631A.
- Tire and wheel/rim servicing can be extremely dangerous and must be done only by qualified technician using proper tools and procedures. Information about tire and wheel servicing can be obtained from the U.S. Department of Labor and NHTSA.
- For information on servicing wheels and rims, refer to OSHA 29 CFR 1910.177 and to the appropriate wheel and rim manufacturer's manuals. Also refer to Servicing Single-Piece and Multi-Piece Rim Wheels, the U.S. Department of Labor pamphlet, OSHA 3086, and the accompanying two chart set, available from OSHA regional offices.
- For information on detailed tire inspection, refer to the DOT tire regulations of Section 393.75.

## Maintaining the trailer

Part	Checkpoint	Task
<b>Wheels</b>	Hubs and ends	Check for damage.
	Rims	<ul style="list-style-type: none"> <li>• Check for damage.</li> <li>• Check for oil leaks.</li> </ul>
	Lug nuts	Check if they are loose or missing. <div> <b>❖ NOTE</b>            For more information on the tightening procedure, refer to “Guidelines for proper wheel assembly” on page 116.         </div>
	End hub cap	<ul style="list-style-type: none"> <li>• Check the oil level.</li> </ul> <div> <b>❖ NOTE</b>            For more information on the proper oil level, refer to “Adding oil” on page 112.         </div> <ul style="list-style-type: none"> <li>• Check for oil leaks.</li> </ul>
	Hub gaskets	Check the lubrication levels (if liquid lubrication is used) and check for leaks.
	Seals	

Part	Checkpoint	Task
Tires	Pressure	<p>Check if the pressure of all tires is within the normal range. The proper cold tire inflation pressure is stated on the VIN plate. For more information on the VIN plate, refer to the "Vehicle Identification Number (VIN)" on page 18.</p> <p> <b>NOTE</b> Measure the tire pressure before every departure during cold weather conditions.</p>
	Sidewall and tread	<ul style="list-style-type: none"> <li>• Check for abrasions, cuts, dry rot, or other damage.</li> <li>• Check if nails or other objects are embedded.</li> <li>• Check if stones and other objects are lodged between dual tires.</li> <li>• Check if the tread depth is sufficient.</li> </ul> <p> <b>CAUTION</b> If the fabric is exposed on the sidewall or on the tread, replace them immediately.</p>
	Valve stem	Check for damage.
	Valve caps	Check if they are damaged or missing.
	Axle end	Check if the dual tires on the end of the axles have the same diameter.

## Maintaining the trailer

### Lubricating trailer parts

Proper lubrication is essential for maintaining the mechanical performance required for safe operation of Hyundai Translead trailers and ensuring prolonged life of each trailer part.



#### **WARNING**

To avoid potential injury, death, or property loss, follow the instructions below while inspecting and maintaining the trailer.

- Find a safe place and stop the tractor and the trailer on level ground.
- Apply the parking brake and wheel chocks to ensure that the tractor and trailer do not move during the inspection or maintenance.
- Turn off the tractor unless it is required to keep the engine running to inspect part functions.

## Lubricating the fifth wheel (of a tractor)

For safe, trouble-free trailer operation, regularly inspect the fifth wheel of your tractor and lubricate it according to the fifth wheel manufacturer's guidelines.




### CAUTION

Closely inspect and lubricate the fifth wheel if you hear metallic screeching or a growling noise while coupling the tractor with a trailer.



### NOTE

The internal design and operation mechanism of the fifth wheel may differ depending on the manufacturer, and the required lubrication and lubrication intervals may also vary.



## Maintaining the trailer

### Lubricating the wheel-end assembly

Proper lubrication is required for the wheel-end assembly to maintain its design capacity.



#### **WARNING**

Strictly follow the guidelines listed below to avoid potentially hazardous wheel-end system failure, which may result in serious injury or death.

- Inspect the wheel hub lubricant level before each operation.
- Do not mix different types of lubricants in any wheel-end assembly.
- In any wheel-end assembly, only use the lubricant (oil or semi-fluid grease) specified by the manufacturer.
- In the absence of relevant information, contact the wheel-end system manufacturer or a qualified local lubricant supplier and ask for recommendations.

#### **NOTICE**

The Technology and Maintenance Council (TMC) Recommended Practice No. 631A provides recommendations for inspecting, lubricating, and maintaining wheel-end systems. This document recommends that semi-fluid grease levels be maintained at, but not above, the 3 and 9 o'clock positions (a 50% fill of the cavity).


Oil or semi-fluid grease are used to lubricate wheel bearings within the wheel hub assembly.



## WARNING

To avoid potential injury, death, or property loss due to premature wheel-end system failure:

- Only use the same lubricant previously used to fill the hub well. Do not mix different types or grades of lubricants.
- Do not mix oil and grease to lubricate the wheel-end assembly.
- Check for oil leaks and immediately replace the related parts, such as hubcap seals, if necessary. Oil leaks may cause premature failure of wheel-end assembly and can be indicated by oil stains and contamination around the hubcaps, rims, and tires.



## ❖ NOTE

- The internal design of the wheel-end assembly may differ depending on the manufacturer, and the approved lubricants and inspection intervals may also vary. For detailed information about the lubricants approved for your trailer's wheel-end assembly, including the lubricant type, grade, and viscosity, refer to the maintenance guidelines provided by the wheel-end assembly manufacturer.
- The lubricant information can also be found on the wheel end or on the bottom rail of the trailer body above the running gear.

## Maintaining the trailer

Visually inspect the oil or grease level through the inspection window, or open the hubcap to determine if additional lubrication is required.




### CAUTION

- Ensure that the trailer is parked on level ground before inspecting the lubricant level.
- Only use oil or grease with the grade and viscosity specified by the manufacturer.
- Do not overfill. Overfilling may cause leaks.
- Ensure that the air ventilation hole on the hubcap is not blocked with grease.

Add oil or semi-fluid grease in the hub well until the lubricant reaches the specified level. Only use oil or semi-fluid grease with the grade and viscosity specified on the wheel end or on the bottom rail of the trailer body above the running gear.

### Adding oil

Inspect the oil level through the inspection window and add oil to the "FULL" indicator if required.






## Adding semi-fluid grease

Add semi-fluid grease until it reaches the 3 and 9 o'clock level.



### CAUTION

- While filling the wheel hub well with semi-fluid grease, be careful not to block the air ventilation hole.
- Use a brush to lightly coat the adjusting nut and inside of the wheel cap with the semi-fluid grease.




### WARNING

Lubricant leaks from the wheel hubs may cause premature failure of wheel-end assembly, which may result in serious injury or death. Before each trip, carefully check the front and rear of all wheel hubs for any lubricant leaks. If a lubricant leak is discovered, immediately have the trailer inspected and repaired by a qualified technician.

## Maintaining the trailer

### *Lubricating the wheel nuts and studs*

Frequently inspect the wheel nut (lug nut) tightness and properly lubricate and tighten the wheel nuts as required.



### **WARNING**


Do not under-lubricate or over-lubricate the wheel studs and nuts.

- If the nuts and studs are not properly lubricated, the specified tightening torque may be reached before the nuts are properly tightened due to excessive friction, potentially causing the studs and nuts to loosen and fail.
- If nuts and studs are excessively lubricated, the required tightening torque may not be maintained during trailer operation, potentially causing the studs and nuts to loosen and fail.




## WARNING

Be extremely careful and keep the nut flange and drum surfaces free of any lubricant, dirt, or contamination. These surfaces are indicated by "X" marks in the following figure.



Improper lubrication may allow wheels and drums to move during trailer operation, potentially causing the studs and nuts to loosen and fail.

After removing the wheel nuts from the hub, apply two drops of common lubricating oil on each wheel stud and in the crevice between the wheel nuts and wheel nut flanges.



## Maintaining the trailer

### *Guidelines for proper wheel assembly*

After lubricating the wheel stud and wheel nuts (lug nuts), properly install the wheel to the wheel hub and tighten the wheel nuts to the specified tightening torque.



#### **WARNING**

To avoid potential injury, death, and property loss that may be caused by wheel separation due to loose wheel nuts:


- Frequently inspect the wheel nut tightness, especially up to 100 miles after the initial operation of the trailer, and at least once every 25,000 miles henceforth.
- When the inspection interval is reached, remove all wheels and reassemble them again according to the guidelines for proper wheel assembly.

1. Rotate the hub so one of the pilot pads is located at the top.
2. Evenly coat the pilot pads with a non-water based lubricant, making sure the drum is properly positioned on the raised step of the top pilot pad.


#### **❖ NOTE**

Ensure that the brakes have been properly adjusted before installing the wheels. Well-adjusted brakes facilitate keeping the drum in the desired position.

3. Ensure that the wheel is properly positioned on the pilot pads and that the mating surfaces are fully in contact with each other.




4. Pre-tighten the wheel nuts by turning them clockwise with your fingers and tighten them to 50 lb-ft according to the tightening order indicated in the following figure.



## Maintaining the trailer

5. Re-tighten the wheel nuts to the final torque of 496 lb-ft, to the tightening order indicated in the following figure.



## Lubricating the landing gear


The landing gear system is designed to safely support the weight (GVWR) of a fully loaded trailer, and proper lubrication is required to ensure effortless operation while coupling or uncoupling the trailer.

### ❖ NOTE

The internal design and operation mechanism of the landing gear may differ depending on the manufacturer and the required lubrication and lubrication intervals may also vary.

For detailed information and internal schematics, refer to the maintenance guidelines provided by the landing gear system manufacturer.

- As a general rule, it is recommended to lubricate your landing gear six months after initial operation, and then on a yearly basis.
- Frequently inspect the handle operation for fluid movement. Lubricate the handle joint with low-viscosity oil whenever it feels stiff.
- If lubrication does not alleviate the stiffness, if the handle feels loose, or if you feel excessive resistance or hear unusual noises while operating the landing gear, internal parts may have become worn out or damaged. Have the worn or damaged parts replaced as soon as possible.



## Maintaining the trailer

### Lubricating body parts

There are a few trailer body parts that require routine lubrication for optimal operation.


#### *Lubricating the sliding suspension rail*

The sliding suspension rail is used to adjust the position of the running gear assembly (bogie part) underneath the trailer body.

#### ❖ NOTE

Refer to the sliding suspension rail manufacturer's maintenance guidelines for the approved lubricants and the lubrication intervals, or contact a qualified local lubricant supplier and ask for recommendations.

Refer to the following figure to lubricate the sliding suspension rail and other related parts for smooth adjustment operation.






## ***Lubricating the door systems***

To prevent premature damage of the parts and ensure effortless operation, regularly inspect the door system and lubricate the moving parts.

### **Swing doors**

Use general lubricating oil to regularly lubricate the moving parts on the doors, including the hinges, latches, and handles.




## Maintaining the trailer

### Roll up door

Periodically lubricate the overhead rail that is used to stow the roll up door according to the maintenance guidelines provided by the roll up door manufacturer.

Also, use general lubricating oil to regularly lubricate the moving parts on either side of the door, including the hinges and latches.



# Appendix

<b>Specifications .....</b>	<b>124</b>
Dry van trailers .....	124
Original® .....	124
General .....	124
Body Structure .....	124
HyCube® .....	126
General .....	126
Body structure .....	126
Composite® .....	128
General .....	128
Body Structure .....	129
CompositeXT® .....	130
General .....	130
Body Structure .....	131
Reefer trailers .....	132
ThermoTech® .....	132
General .....	132
Body Structure .....	132
<b>Parts list for repair and replacement .....</b>	<b>134</b>
General assembly .....	135
Landing gear assembly .....	136
Slider assembly .....	137
Brake system assembly .....	138
Running gear (top view) .....	138
Running gear (side view) .....	139
Wheel and hub assembly .....	140
Trailer body structure assembly .....	141
Floor assembly .....	141
Roof assembly .....	142
Rear frame assembly .....	143
Swing door assembly .....	144
Front wall assembly .....	145
Side wall assembly .....	146
<b>Electrical and lighting system diagrams .....</b>	<b>147</b>
Exterior lighting system .....	147
Lighting system wiring .....	147
Lighting units and harness .....	148
Interior lighting system .....	149
Dome lights wiring .....	149
Dome lights assembly .....	150
<b>FMCSA annual inspection checklist .....</b>	<b>151</b>
<b>Find a dealer near you .....</b>	<b>152</b>
<b>Product warranty .....</b>	<b>153</b>

## Appendix

### Specifications

The following tables list the specifications and features of trailer body structure for each model of the trailers.

#### Dry van trailers

*Original*<sup>®</sup>

##### General

Item		Specifications
Length	Exterior	53' 0"
	Interior	52' 6"
Width	Exterior	102.36"
	Interior	99" (lining-to-lining)
Height	Exterior	13' 6"
	Interior	110"
Capacity		68,000 GVWR
Interior volume		3,970 cu. ft.
Tare weight		13,550 lbs
AIAG floor rating		18,000 lbs

##### Body Structure

Item	Specifications
Side sheets	Pre-painted white aluminum (.050" thick)
Side posts	<ul style="list-style-type: none"><li>Galvanized steel posts on 24" centers</li><li>1.13" deep x 5" wide, with posts on 12" centers over coupler and landing gear area</li></ul>

Item	Specifications
<b>Roof</b>	<ul style="list-style-type: none"> <li>• Full width aluminum sheet (0.04" thick)</li> <li>• Tension leveled prior to installation</li> </ul>
<b>Roof bows</b>	<ul style="list-style-type: none"> <li>• Galvanized steel anti-snag hat section on 24" centers</li> <li>• Pre-bonded to roof sheet</li> <li>• Roof bows installed using four solid rivets (two per end)</li> </ul>
<b>Front wall</b>	Four high-tensile, hat-shaped posts securely fastened with 6 heavy-duty fasteners covered with 0.05" aluminum front sheets
<b>Rear frame</b>	<ul style="list-style-type: none"> <li>• Hot-dip galvanized (0.19" thick), high-tensile steel construction with low-profile header, tube-shaped posts</li> <li>• Forged steel angle irons in the top corners for added rack resistance</li> <li>• Lights recessed in the rear sill with heavy-duty protection bars with welded reinforcing bar between tail lamps</li> </ul>
<b>Rear doors</b>	<ul style="list-style-type: none"> <li>• Composite swing door with a 0.5" composite panel</li> <li>• Dual durometer seals bonded to door</li> <li>• Four hinges and one anti-rack locking bar with nylon bushings per door</li> <li>• Lock handles fitted with rubber grips for operator comfort and safety</li> </ul>
<b>Interior lining</b>	<ul style="list-style-type: none"> <li>• Exterior grade plywood (0.25") installed horizontally over side posts</li> <li>• Exterior grade plywood (0.5") installed lower half of front wall and 0.25" over top height of front wall</li> </ul>

## Appendix

### HyCube®

#### General

Items		Specifications
<b>Length</b>	<b>Exterior</b>	53' 0"
	<b>Interior</b>	52' 6"
<b>Width</b>	<b>Exterior</b>	102.36"
	<b>Interior</b>	101" (lining-to-lining)
<b>Height</b>	<b>Exterior</b>	13' 6"
	<b>Interior</b>	110"
<b>Capacity</b>		68,000 GVWR
<b>Interior volume</b>		4,050 cu. ft.
<b>Tare weight</b>		13,900 lbs
<b>AIAG floor rating</b>		18,000 lbs

#### Body structure

Items	Specifications
<b>Side sheets</b>	Pre-painted white aluminum (0.50" thick)
<b>Side posts</b>	Slotted "A" logistic galvanized steel posts on 16" centers (0.45" deep x 6.57" wide) with posts on 12" centers over coupler and landing gear areas
<b>Roof</b>	<ul style="list-style-type: none"> <li>• Full width aluminum sheet (0.04" thick)</li> <li>• Tension leveled prior to installation.</li> </ul>
<b>Roof bows</b>	<ul style="list-style-type: none"> <li>• Galvanized steel anti-snag hat section on 24" centers</li> <li>• Pre-bonded to roof sheet</li> <li>• Roof bows installed using four solid rivets (two per end)</li> </ul>

Items	Specifications
<b>Front wall</b>	Four high-tensile, hat-shaped, posts securely fastened with 6 heavy-duty fasteners covered with aluminum front sheets (0.05").
<b>Rear frame</b>	<ul style="list-style-type: none"> <li>• Hot-dip galvanized (0.19" thick), high-tensile steel construction with low-profile header, tube shaped posts</li> <li>• Forged steel angle irons in the top corners for added rack resistance</li> <li>• Lights recessed in the rear sill with heavy-duty protection bars</li> </ul>
<b>Rear doors</b>	<ul style="list-style-type: none"> <li>• Composite construction of 0.5" composite panel covered by pre-painted white galvanized inner and outer skins (0.02")</li> <li>• Dual durometer seals bonded to door</li> <li>• Lock handles fitted with rubber grips for operator comfort and safety</li> </ul>
<b>Interior lining</b>	<ul style="list-style-type: none"> <li>• White HDPE lining (0.24" thick) installed fully height between uprights with no fasteners</li> <li>• Side lining hooks into place for easy replacement</li> <li>• Exterior grade plywood (0.5") installed on bottom and plywood (0.25") installed on top over front wall post</li> </ul>

## Appendix

### *Composite*<sup>®</sup>

#### General

Items		Specifications
Length	Exterior	53' 0"
	Interior	52' 6"
Width	Exterior	102.36"
	Interior	101.50" (at floor)
Height	Exterior	13' 6"
	Interior	110" (front to back)
Capacity		68,000 GVWR
Interior volume		4,095 cu. ft.
Door opening	Height	110"
	Width	99"
Tare weight		13,750 lbs
AIAA floor rating		18,000 lbs



## Body Structure

Items	Specifications
<b>Side sheets</b>	Composite panel (0.25") with pre-painted white, high-tensile galvanized steel inner and outer sheets
<b>Side stiffeners</b>	High-tensile galvanized steel (19GA) on 48" centers
<b>Roof</b>	<ul style="list-style-type: none"> <li>• Full width aluminum sheet (0.04" thick)</li> <li>• Tension leveled prior to installation</li> </ul>
<b>Roof bows</b>	Galvanized steel (16GA) anti-sag on 24" centers
<b>Front wall</b>	Four high-tensile, hat-shaped, posts securely fastened with 6 heavy-duty fasteners covered with aluminum front sheets (0.05")
<b>Rear frame</b>	<ul style="list-style-type: none"> <li>• Hot-dip galvanized (0.19" thick), high-tensile steel construction with low profile header and tube shaped posts</li> <li>• Forged steel angle irons in top corners for added rack resistance</li> <li>• Lights recessed in the rear sill with heavy-duty protection bars</li> </ul>
<b>Rear doors</b>	Swing door with a composite panel
<b>Interior front lining</b>	Exterior grade plywood (0.5") installed lower half of front wall and 0.25" over top height of front wall

## Appendix

### *CompositeXT<sup>®</sup>*

#### General

Items		Specifications
Length	Exterior	53' 0" (on one line)
	Interior	52' 6"
Width	Exterior	102.36"
	Interior	101.50" (above side scuff, wall to wall)
Height	Exterior	13' 6"
	Interior	110" (front to back)
Weight capacity		68,000 GVWR
Interior volume		4,095 cu. ft.
Door opening	Height	110"
	Width	99"
Tare weight		13,850 lbs
AIAG floor rating		18,000 lbs

## Body Structure

Items	Specifications
<b>Side sheets</b>	Composite panel (0.25") with pre-painted white, high-tensile galvanized steel inner and outer sheets
<b>Side stiffeners</b>	High-tensile galvanized steel (19GA) on 48" centers
<b>Roof</b>	<ul style="list-style-type: none"> <li>• Full width aluminum sheet (0.04" thick)</li> <li>• Tension leveled prior to installation</li> </ul>
<b>Roof bows</b>	Galvanized steel (16GA) anti-sag on 24" centers
<b>Front wall</b>	Four high-tensile, hat-shaped, posts securely fastened with 6 heavy-duty fasteners covered with aluminum front sheets (0.05")
<b>Rear frame</b>	<ul style="list-style-type: none"> <li>• Hot-dip galvanized (0.19" thick), high-tensile steel construction with low profile header and tube shaped posts</li> <li>• Forged steel angle irons in top corners for added rack resistance.</li> <li>• Lights recessed in the rear sill with heavy-duty protection bars</li> </ul>
<b>Rear doors</b>	Swing door with a composite panel
<b>Interior lining</b>	Exterior grade plywood (0.5") installed lower half of front wall and 0.25" over top height of front wall
<b>Side scuffband</b>	<ul style="list-style-type: none"> <li>• Exposed height extended scuff (16")</li> <li>• Exterior ribs for increased stiffness and scrape resistance</li> </ul>

## Appendix

### Reefer trailers

#### *ThermoTech*®

##### General

Items		Specifications
Length	Exterior	53' 0"
	Interior	52' 2"
Width	Exterior	102.36"
	Interior	97.4" (lining to lining)
Height	Exterior	13' 6"
	Interior	105.5"
Capacity		68,000 GVWR
Interior volume		3,722 cu. ft.
Lining		PolarX PP050
Tare weight		12,100 lbs
AIAG floor rating		18,000 lbs

##### Body Structure

Items	Specifications
Side sheets	Flat pre-painted white aluminum side sheet (0.04")
Side posts	Extruded aluminum "Z" side posts on 12" centers nose through support gear 24" centers support gear to rear of trailer

Items	Specifications
<b>Roof</b>	<ul style="list-style-type: none"> <li>• Full width aluminum sheet (0.03" thick)</li> <li>• Tension leveled prior to installation</li> <li>• Special corrugated roof sheet design allows roof to expand and contract without foam delamination or structural weakening of roof</li> </ul>
<b>Roof bows</b>	<ul style="list-style-type: none"> <li>• Extruded aluminum I-beam on 32" centers</li> <li>• Pre-bonded to roof sheet</li> </ul>
<b>Front wall</b>	<ul style="list-style-type: none"> <li>• Stainless steel front impact plate</li> <li>• Pre-painted white aluminum sheets (0.04") with 6" radius</li> <li>• Large opening refrigeration unit bracing</li> </ul>
<b>Rear frame</b>	<ul style="list-style-type: none"> <li>• Stainless steel rear frame including corner posts, hinge butts, door header, and rear sill</li> <li>• Stop/tail/turn signals are fully recessed in the rear sill.</li> <li>• Hot-dip galvanized high-tensile steel bolt-on under-ride protection</li> </ul>
<b>Rear doors</b>	<ul style="list-style-type: none"> <li>• Extruded aluminum frame type swing doors</li> <li>• Dual durometer seals</li> <li>• 0.04" pre-painted white aluminum outer sheets</li> <li>• One easy-operating anti-rack lock rod per door</li> <li>• Four heavy-duty extruded aluminum hinges per door</li> <li>• Lock rod handles are fitted with rubber grips for operator comfort and safety</li> </ul>
<b>Insulation</b>	Sides, floor and roofing (2"), rear door (3") and front wall 4" thick with Injection foamed urethane insulation
<b>Refrigeration</b>	Heavy-duty mounting frame and bracing provided for the large opening nose mounted unit

## Appendix


### Parts list for repair and replacement

The assembly diagrams provided in this section are intended to help you identify repair and replacement items for trailers manufactured by Hyundai Translead.

#### ❖ NOTE

The parts in the diagrams are mounted on the HyCube® model as a reference. For ordering parts to ensure proper selection and identification of the replacement items, contact your sales representative or an authorized dealer. Also, you can contact Hyundai Translead at 800-251-0871 or visit the website at [www.hyundaitranslead.com](http://www.hyundaitranslead.com).


## General assembly



- |   |   |
|---|---|
| ① Slider assembly mount                   | ⑨ Side wall assembly (left or driver's) |
| ② Landing gear mount sub-assembly         | ⑩ Roof assembly with dome lights        |
| ③ Floor assembly                          | ⑪ Rear frame assembly                   |
| ④ Upper coupler assembly                  | ⑫ Roll-up door assembly                 |
| ⑤ Landing gear assembly                   | ⑬ Rear bumper assembly                  |
| ⑥ Running gear assembly                   |   |
| ⑦ Front panel assembly                    |   |
| ⑧ Side wall assembly (right or passenger) |   |

## Appendix

### Landing gear assembly




- 1 Crank shaft
- 2 Landing gear bracket
- 3 Crank handle

- 4 K-brace
- 5 Support leg
- 6 Sand shoe



## Slider assembly




- |                               |                             |
|-------------------------------|-----------------------------|
| ① Front spring hanger         | ⑦ Top plate                 |
| ② Center rocker hanger        | ⑧ Medium duty 3-leaf spring |
| ③ Rear spring hanger          | ⑨ 5" Round spring seat      |
| ④ Radius rod (non-adjustable) | ⑩ 5" Round bottom plate     |
| ⑤ Radius rod (adjustable)     | ⑪ Pin pull handle           |
| ⑥ U-bolts                     | ⑫ Hold down clip            |

## Appendix

### Brake system assembly

#### Running gear (top view)




- 1 Spring brake valve
- 2 Quick release valve
- 3 ECU relay valve

- 4 Gladhand (emergency, red)
- 5 Gladhand (service, blue)

## Running gear (side view)

Running gear  
(side view)



① Air tank

② Axle

③ Spring brake chamber


④ Brake shoe kit

⑤ Automatic slack adjuster

⑥ S-Cam

## Appendix


### Wheel and hub assembly



- |                             |                         |
|-----------------------------|-------------------------|
| 1 Wheel seal                | 9 Hub cap               |
| 2 Wheel bearing             | 10 Steel rim            |
| 3 Wheel hub                 | 11 Air stem valve       |
| 4 Wheel stud                | 12 Flow thru valve cap  |
| 5 Wheel nut (cone lock nut) | 13 Tire                 |
| 6 Brake drum                | 14 Hub odometer bracket |
| 7 Spindle nut               | 15 Hub odometer         |
| 8 Hub cap gasket            |                         |

## Trailer body structure assembly


### *Floor assembly*



- ① Floor board
- ② Threshold plate

## Appendix

### *Roof assembly*




① Roof sheet

② Roof bow

③ Roof lining (if equipped)

④ Dome light bracket


## Rear frame assembly



- |   |                                      |
|---|--------------------------------------|
| ① Rear corner post (left or driver's)     | ⑤ Post bottom protector              |
| ② Rear corner post (right or passenger's) | ⑥ Lamp supporter angle               |
| ③ Door sill sub-assembly                  | ⑦ Quick change mud flap installation |
| ④ Door header sub-assembly                | ⑧ Mud flap bracket                   |
|   | ⑨ Mud flap                           |

## Appendix


### *Swing door assembly*



- |                    |                       |
|--------------------|-----------------------|
| ① Hinges           | ④ Door panel          |
| ② Cam keeper (top) | ⑤ Door handle         |
| ③ Locking rod      | ⑥ Cam keeper (bottom) |




## Front wall assembly



- |                                    |                          |
|------------------------------------|--------------------------|
| ① Front top rail                   | ⑥ Gladhand back plate    |
| ② Front corner radius              | ⑦ Front lining           |
| ③ Front corner cover (if equipped) | ⑧ Scuff band             |
| ④ Front panel                      | ⑨ VIN plate              |
| ⑤ Front post                       | ⑩ Document holder        |
|                                    | ⑪ Front corner protector |

## Appendix

### Side wall assembly




- |  |   |
|--|---|
| ① Main side panel                            | ⑤ Front-end side panel (right or passenger's) |
| ② Rear-end side panel (left or driver's)     | ⑥ Side post                                   |
| ③ Front-end side panel (left or driver's)    | ⑦ Top side rail                               |
| ④ Rear-end side panel (right or passenger's) | ⑧ Bottom side rail                            |
|  | ⑨ Side scuff band                             |

## Electrical and lighting system diagrams

Refer to the following diagrams for electrical wiring information for lighting systems and the location of the exterior and interior lights of the trailer.

### Exterior lighting system

#### *Lighting system wiring*




- ① Main wiring harness
- ② Rear wiring harness
- ③ Front marker light wiring harness
- ④ 7-Way electrical connector
- ⑤ Mid-turn signal mounting bracket

- ⑥ License plate lamp kit
- ⑦ Front clearance marker light
- ⑧ Mid-turn signal light
- ⑨ Tail light
- ⑩ Bottom side marker light
- ⑪ Top clearance lights

## Appendix

### Lighting units and harness




- |                                     |                                |
|-------------------------------------|--------------------------------|
| ① Main wiring harness               | ⑧ Front clearance marker light |
| ② Rear wiring harness               | ⑨ ABS indicator light          |
| ③ Front marker light wiring harness | ⑩ Mid-turn signal light        |
| ④ ABS Wiring Harness                | ⑪ Tail light                   |
| ⑤ 7-Way electrical connector        | ⑫ Bottom side marker light     |
| ⑥ Mid-turn signal mounting bracket  | ⑬ Top clearance light          |
| ⑦ License plate lamp kit            |                                |

#### ❖ NOTE

When replacing a pig tail marker light, leave 12 inches of extra length (slack) to allow the marker light could be changed from the outside of the trailer.

## Interior lighting system


### *Dome lights wiring*



- ① 7-Way electrical connector
- ② Switch and boot unit
- ③ Dome lights

## Appendix

### *Dome lights assembly*



- ① Red wire to white pin
- ② Red wire to brown pin
- ③ Switch and boot unit

- ④ Dome light
- ⑤ Dome light harness

# FMCSA annual inspection checklist



## FMCSA ANNUAL INSPECTION FORM

### HYUNDAI TRANSLEAD

Plant: La Encantada No. 7474 Parque Industrial "El Florido"

Tijuana B.C. México.

Corporate Office: 8880 Rio San Diego Drive, Ste # 600

San Diego, CA 92108

Inspection Facility: Hyundai Plant 1	Unit Number:	Hubodometer (if applicable):
City and State: Tijuana, Baja California, MX.	Customer:	S.A.P. Number:
Inspector Name:	VIN Number:	License Plate Number:
Inspection Date: <input type="checkbox"/> Pass <input type="checkbox"/> Fail	Repair Date:	Make: Hyundai Year / Model:

OK	NEEDS REPAIR	ITEMS INSPECTED	OK	NEEDS REPAIR	ITEMS INSPECTED
		<b>BRAKE SYSTEM</b>			<b>SAFE LOADING</b>
		Service Brakes			Part(s) of vehicle or condition of loading such as spare tire or any part of the load or dunnage can fall onto the roadway
		Parking Brake System			Protection against shifting cargo
		Brake Drums or Rotors			<b>STEERING MECHANISM</b>
		Brake Hose			For units with Steerable Rear Axle.
		Brake Tubing			<b>SUSPENSION</b>
		Audible Air Leaks			Any U Bolt(s), spring hanger(s) or other axle positioning part(s) cracked, broken, loose or missing resulting in shifting of an axle from it's normal position
		<b>COUPLING DEVICES</b>			Spring assembly
		Fifth Wheels / Upper Coupler			Torque, radius or tracking component
		Pintle Hooks			<b>FRAME</b>
		Drawbar / Towbar Eye			Frame members
		Drawbar / Towbar Tongue			Tire and Wheel Clearance
		Safety Devices			Adjustable Axle Assemblies (Sliding Sub-Frames).
		Saddle-Mounts			<b>TIRES</b>
		<b>EXHAUST SYSTEM / REFRIGERATED UNITS</b>			<b>WHEELS AND RIMS</b>
		No part of the exhaust system of any motor vehicle shall be located as would be likely to result in burning, charring or damaging the electrical wiring, the fuel supply, or any combustible part of the motor vehicle			Lock or Side Ring
		<b>FUEL SYSTEM / REFRIGERATED UNITS</b>			Fasteners
		Visible leak			Welds
		Fuel tank filler cap missing			<b>UNIT NUMBERS DISPLAYED</b>
		Fuel tank securely attached			<b>SPLASH GUARDS</b>
		<b>LIGHTING DEVICES</b>			Driver Side
		All lighting devices and reflectors required by Section 393 shall be operable.			Passenger Side

I have inspected the vehicle described above and certify that all entries are true and correct. I certify that this inspection meets the requirements of 49 CFR Part 396.17 and is in accordance with Appendix G to Subchapter B, Minimum Periodic Inspection Standards, and the vehicle has passed / failed as indicated above.

INSPECTOR'S NAME (Please Print): \_\_\_\_\_

INSPECTOR'S SIGNATURE: \_\_\_\_\_

QCD-F-600 EN

REV-03

QCD-F-600 EN

2022

## Appendix

---

### Find a dealer near you

To have the trailer maintained or repaired by a qualified technician, or to order replacement parts, visit the Hyundai Translead website at [www.hyundaitranslead.com/find-a-dealer/](http://www.hyundaitranslead.com/find-a-dealer/) and find an authorized Hyundai Translead dealer around you.



# Product warranty



**HYUNDAI  
TRANSLEAD**

## 5 Year LIMITED WARRANTY

Hyundai Translead ("Manufacturer") hereby warrants to the original purchaser ("Purchaser") of each new Hyundai Translead trailer, van, container, chassis, and converter dolly ("Product") that the Product will be free from defects in materials and workmanship for a period of five years, if properly maintained and used in normal service. "Normal service" means usage in the manner and for the purposes for which such Products are customarily utilized, and includes the loading, unloading and carriage of uniformly distributed legal loads of noncorrosive cargo, properly secured, in a manner that does not subject the Product to strains or impacts greater than those normally imposed during lawful use. Well-maintained public roads, with a gross vehicle weight that does not exceed the gross vehicle weight rating (GVWR) specified on the vehicle identification plate affixed to the vehicle by the Manufacturer prior to delivery.

Manufacturer's sole obligation under this limited warranty is to repair or replace, at its option, any part or component of the Product that was furnished and installed by Manufacturer and that proves defective in material and/or workmanship during the first sixty (60) months following the date of delivery to the Purchaser. Such repair or replacement will be performed by Manufacturer or, with Manufacturer's prior express authorization, at a repair facility designated or approved by Manufacturer. Manufacturer assumes no responsibility to reimburse Purchaser or pay for repairs made without Manufacturer's prior express authorization or at repair facilities not designated or approved by Manufacturer. As a precondition to Manufacturer's obligation under this limited warranty, Purchaser must notify Manufacturer of any product defect promptly upon discovery, and return Product to Manufacturer or, at Manufacturer's direction, to a repair facility designated by Manufacturer, within ten (10) days after Manufacturer requests its return for inspection and/or repair or replacement.

### WAIVERS AND DISCLAIMERS

**THE LIMITED WARRANTY PROVIDED HEREIN IS EXPRESSLY IN LIEU OF, AND PURCHASER HEREBY WAIVES, ANY AND ALL OTHER WARRANTIES, WHETHER WRITTEN OR ORAL, EXPRESS OR IMPLIED. MANUFACTURER EXPRESSLY DISCLAIMS AND PURCHASER HEREBY WAIVES ANY IMPLIED WARRANTY OF MERCHANTABILITY AND ANY WARRANTY THAT EXTENDS TO USES OF THE PRODUCT BEYOND NORMAL SERVICE AS DEFINED HEREIN.**

The limited warranty herein does not apply to, and Manufacturer makes no warranties, whether written or oral, expressed or implied, with respect to:

- 1) Parts, accessories, or other goods made or distributed by other manufacturers which are installed on the Product in accordance with Purchaser's specifications or requirements. Manufacturer will assign to Purchaser any warranties extended to Manufacturer by the makers or suppliers of such items.
- 2) Used goods delivered hereunder, regardless of their manufacturer, all of which are delivered "AS IS".
- 3) Components of any Product which, after delivery to the Purchaser, were repaired or altered by anyone other than Manufacturer or one of its authorized service representatives, unless, in Manufacturer's reasonable opinion, such repairs or alterations are in no way responsible for the condition complained of.
- 4) Parts, accessories or components supplied by Manufacturer which, due to ordinary wear and tear, need replacement during the warranty period, including, for example, but without limitation, light bulbs, brake linings and brake drums.
- 5) Normal deterioration of sheet metal, aluminum, paint, trim and appearance items resulting from use and exposure to the elements.
- 6) Tires and other components as to which a separate supplier's warranty applies.
- 7) Upon going into service, wheel end alignment claims are considered on a case by case basis. Factory alignments are covered upon delivery of all equipment.
- 8) Photos may be required to perform an evaluation for claims related to proprietary components.
- 9) As a customer courtesy, third party vendor parts are processed as a pass through with the component manufacturer for the first year of service only.

### LIMITATIONS OF MANUFACTURER'S LIABILITY

PURCHASER'S SOLE REMEDY FOR ANY DEFECT IN THE PRODUCT, OR ANY COMPONENT OR PART THEREOF, IS LIMITED TO THE REPAIR OR REPLACEMENT OF THE DEFECTIVE ITEM AT THE MANUFACTURER'S SOLE OPTION. MANUFACTURER SHALL HAVE NO LIABILITY FOR ANY CARGO LOSS, LOSS OF USE, LOST PROFITS, LOSS OF GOOD WILL, STORAGE, TOWING OR OTHER TRANSPORTATION COSTS, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER SUSTAINED BY PURCHASER OR BY PURCHASER'S CUSTOMERS, ARISING OUT OF ANY ALLEGED DEFECT, OR BREACH OR FAILURE OF WARRANTY.

### HYUNDAI TRANSLEAD

Serial Number(s):

Customer Name:

Date of Purchase:

