

# **Service Manual**

**Screw Compressor**

**M135 SIGMA CONTROL MOBIL**

No.: 9\_6975 00 E

Manufacturer:

**KAESER KOMPRESSOREN GmbH**

96410 Coburg • PO Box 2143 • GERMANY • Tel. +49-(0)9561-6400 • Fax +49-(0)9561-640130

<http://www.kaeser.com>

Original instructions  
/KKW/M135 1.00 en SBA-MOBILAIR

<b>1</b>	<b>Regarding this document</b>	
1.1	Using the Document .....	1
1.2	Further documents .....	1
1.3	Copyright .....	1
1.4	Symbols and markings .....	1
1.4.1	Warning notices .....	1
1.4.2	Other notices and symbols .....	2
<b>2</b>	<b>Technical Specification</b>	
2.1	Nameplate .....	3
2.2	List of Options .....	3
2.2.1	Compressed air treatment plant .....	4
2.2.2	Compressed air distributor .....	4
2.2.3	Check valve function .....	5
2.2.4	Low temperature equipment .....	5
2.2.5	Chassis .....	5
2.2.6	Lighting .....	5
2.2.7	Pedestrian protection .....	6
2.3	Machine (without options) .....	6
2.3.1	Sound emission .....	6
2.3.2	Torques .....	7
2.3.3	Ambient conditions .....	7
2.3.4	Additional specifications .....	7
2.4	Chassis .....	7
2.4.1	Weights .....	7
2.4.2	Tyres .....	8
2.4.3	Wheel nut/bolt tightening torque .....	8
2.4.4	Towbar tightening torque .....	8
2.5	Compressor .....	8
2.5.1	Working pressure and FAD .....	8
2.5.2	Compressed air outlet .....	9
2.5.3	Pressure relief valve .....	9
2.5.4	Temperature .....	9
2.5.5	Cooling oil recommendation .....	9
2.5.6	Cooling oil charge .....	10
2.6	Engine .....	10
2.6.1	Engine specification .....	10
2.6.2	Oil recommendation .....	11
2.6.3	Engine coolant recommendation .....	11
2.6.4	Fluid volumes .....	11
2.6.5	Batteries .....	11
2.7	Options .....	12
2.7.1	Low temperature equipment .....	12
2.7.2	Generator .....	13
<b>3</b>	<b>Safety and Responsibility</b>	
3.1	Basic Information .....	16
3.2	Specified use .....	16
3.3	Improper Use .....	16
3.4	User's Responsibilities .....	16
3.4.1	Observe statutory and universally accepted regulations .....	16
3.4.2	Defining personnel .....	17
3.4.3	Adherence to inspection schedules and accident prevention regulations .....	17
3.5	Dangers .....	18
3.5.1	Safely dealing with sources of danger .....	18

3.5.2	Safe machine operation .....	20
3.5.3	Organisational Measures .....	22
3.5.4	Danger areas .....	23
3.6	Safety Devices .....	23
3.7	Safety signs .....	23
3.8	Generator operation .....	25
3.8.1	Protection against dangerous electric current .....	25
3.8.2	Instructions for safe generator operation .....	25
3.8.3	Connection of extension cables .....	25
3.8.4	Maximum power supply loading .....	25
3.8.5	Regular generator inspections .....	26
3.9	Emergencies .....	26
3.9.1	Correct fire fighting .....	26
3.9.2	Contact with operating fluids/materials .....	26
3.10	Warranty .....	27
3.11	Environmental Protection .....	27
<b>4</b>	<b>Design and Function</b>	
4.1	Bodywork .....	28
4.2	Component identification .....	29
4.3	Machine function .....	29
4.4	Operating modes and control modes .....	31
4.4.1	Operating modes .....	31
4.4.2	MODULATING control mode .....	31
4.5	Safety devices .....	32
4.5.1	Monitoring functions with shutdown .....	32
4.5.2	Further safety devices .....	32
4.6	SIGMA CONTROL MOBIL keys and displays .....	33
4.7	SIGMA CONTROL MOBIL function .....	34
4.7.1	Display .....	34
4.7.2	SIGMA CONTROL MOBIL operating sequence .....	37
4.7.3	Menu structure of the SIGMA CONTROL MOBIL .....	38
4.8	List of menus .....	39
4.8.1	SIGMA CONTROL MOBIL main menu .....	41
4.8.2	SIGMA CONTROL MOBIL settings menu .....	42
4.8.3	SIGMA CONTROL MOBIL event memory .....	45
4.9	Air treatment options .....	48
4.9.1	Air cooler .....	49
4.9.2	Cyclone separator .....	49
4.9.3	Heat exchanger .....	49
4.9.4	Filter combination .....	49
4.9.5	Breathing air filter .....	50
4.10	Low temperature equipment option .....	50
4.11	Generator option .....	51
4.11.1	Operating modes .....	51
4.11.2	Operating controls .....	51
4.11.3	Note when operating the generator .....	52
4.12	Transport options .....	53
4.12.1	Chassis .....	53
4.12.2	Chassis .....	53
4.12.3	Chassis .....	53
4.12.4	Stationary frame .....	54
4.12.5	Stationary frame .....	54
4.13	Pedestrian protection option .....	54

<b>5 Installation and Operating Conditions</b>	
5.1 Safety .....	55
5.2 Positioning conditions .....	55
<b>6 Installation</b>	
6.1 Safety .....	57
6.2 Reporting Transport Damage .....	57
6.3 Fitting the towbar .....	57
6.4 Adjusting the chassis .....	58
6.4.1 Adjusting the towbar height .....	59
6.4.2 Changing the towing eye .....	59
<b>7 Initial Start-up</b>	
7.1 Safety .....	63
7.2 Instructions to be observed before commissioning or recommissioning .....	63
7.3 Checking installation and operating conditions .....	63
7.4 Setting the displayed units .....	64
7.5 Entering a password .....	65
7.6 Engine settings .....	66
7.7 Changing the parameters of the start/stop/automatic option .....	68
7.8 After storing the machine for a long period .....	70
7.9 Low-temperature operation (winter) .....	70
7.9.1 Starting assistance .....	70
7.9.2 Starting up low-temperature equipment .....	72
7.10 Putting the generator into operation .....	73
<b>8 Operation</b>	
8.1 Safety .....	75
8.2 Starting and stopping .....	75
8.2.1 Follow the brief instructions .....	75
8.2.2 Commissioning the machine .....	76
8.2.3 Starting the engine .....	77
8.2.4 Setting the output pressure .....	77
8.2.5 Shutting down the machine .....	79
8.2.6 Shutting down in an emergency .....	80
8.3 Setting parameters .....	80
8.4 Acknowledging alarm, warning and maintenance messages .....	80
8.5 Displaying machine operating data .....	81
8.6 Using the external fuel pump option .....	82
8.7 Using the low-temperature equipment .....	83
8.8 Generator operation .....	83
8.8.1 Switching in the generator .....	84
8.8.2 Switching off the generator .....	84
<b>9 Fault Recognition and Rectification</b>	
9.1 Basic instructions .....	85
9.2 SIGMA CONTROL MOBIL messages .....	85
9.2.1 Alarm messages on the controller (machine off) .....	85
9.2.2 Warning message on the controller .....	88
9.3 Engine faults and alarms .....	90
9.3.1 Engine refuses to start or does not turn over .....	90
9.3.2 Engine does not reach full speed .....	91
9.4 Compressor faults and alarms .....	91
9.4.1 Working pressure too high .....	91
9.4.2 Working pressure too low .....	92
9.4.3 Pressure relief valve blowing off .....	92

9.4.4	Machine overheating .....	93
9.4.5	Too much oil residue in the compressed air .....	93
9.4.6	Oil flows from the compressor air filter after shutdown .....	94
9.4.7	High moisture content in the compressed air .....	94
9.5	Generator faults and alarms .....	94
9.5.1	There is no voltage or too low a voltage from the generator .....	94
9.5.2	Generator voltage too high .....	95
<b>10</b>	<b>Maintenance</b>	
10.1	Safety .....	96
10.2	Maintenance message on the controller .....	96
10.3	Maintenance schedules .....	97
10.3.1	Logging maintenance work .....	97
10.3.2	Maintenance tasks after commissioning .....	97
10.3.3	Regular maintenance tasks .....	98
10.4	Engine .....	102
10.4.1	Radiator maintenance .....	103
10.4.2	Air filter maintenance .....	108
10.4.3	Fuel system maintenance .....	110
10.4.4	Checking the engine oil level .....	114
10.4.5	Engine oil filling and topping up .....	114
10.4.6	Changing the engine oil .....	115
10.4.7	Changing the oil filter .....	117
10.4.8	Checking the drive belts .....	118
10.4.9	Battery maintenance .....	120
10.5	Compressor .....	123
10.5.1	Checking cooling oil level .....	123
10.5.2	Cooling oil filling and topping up .....	124
10.5.3	Changing the cooling oil .....	124
10.5.4	Changing the oil filter .....	127
10.5.5	Oil separator tank dirt trap maintenance .....	129
10.5.6	Changing the oil separator cartridge .....	130
10.5.7	Air filter maintenance .....	131
10.5.8	Checking pressure relief valves .....	133
10.6	Cleaning the coolers and radiator .....	133
10.6.1	Cleaning the compressed air aftercooler .....	135
10.7	Rubber sealing strip maintenance .....	136
10.8	Chassis .....	136
10.8.1	Wheel checks .....	136
10.8.2	Towbar maintenance .....	136
10.8.3	Brake maintenance .....	138
10.9	Options .....	141
10.9.1	Cyclone separator maintenance .....	141
10.9.2	Combination filter maintenance .....	142
10.9.3	Breathing air filter maintenance .....	145
10.9.4	Generator drive belt maintenance .....	147
10.10	Document maintenance and service work .....	150
<b>11</b>	<b>Spares, Operating Materials, Service</b>	
11.1	Note the Nameplate .....	151
11.2	Ordering consumable parts and operating materials .....	151
11.3	KAESER AIR SERVICE .....	152
11.4	Service Addresses .....	152
<b>12</b>	<b>Decommissioning, Storage and Transport</b>	
12.1	De-commissioning .....	153

12.1.1	Temporary decommissioning .....	153
12.1.2	Long-term decommissioning .....	154
12.2	Transporting .....	155
12.2.1	Towing the compressor on the road .....	155
12.2.2	Parking the compressor .....	160
12.2.3	Transporting with a crane .....	162
12.2.4	Transporting with a forklift truck .....	162
12.2.5	Transporting as a load .....	163
12.3	Storage .....	164
12.4	Disposal .....	165
13	<b>Annex</b>	
13.1	Marking .....	166
13.2	Pipeline and instrument flow diagram (P+I diagram) .....	166
13.3	Dimensional drawing, chassis with height-adjustable tow bar .....	171
13.4	Dimensional drawing, chassis with fixed height tow bar .....	173
13.5	Dimensional drawing, chassis without parking brake .....	175
13.6	Dimensional drawings of stationary machine (skids) .....	177
13.7	Dimensional drawings of stationary machine (base frame) .....	179
13.8	Electrical Diagram .....	181
13.9	Lighting and signalling system connection .....	205
13.10	Lighting and signalling system connection .....	210
13.11	Generator electrical diagram, 400 V, 3-ph .....	213
13.12	Generator electrical diagram, 230 V, 3-ph .....	225
13.13	Fuel circulation diagram .....	235
13.14	SIGMA CONTROL MOBIL message codes .....	238
13.15	Operating instructions for compressed air filter (combination filter) .....	241
13.16	Operating instructions for compressed air filter (breathing air filter) .....	262



Fig. 1	Location of safety signs .....	23
Fig. 2	Bodywork .....	28
Fig. 3	Right-hand door opened .....	29
Fig. 4	Left-hand door opened .....	29
Fig. 5	General design .....	30
Fig. 6	Stepless regulation of FAD (standstill) .....	32
Fig. 7	Instrument panel keys and displays .....	33
Fig. 8	Opening page .....	34
Fig. 9	Engine preheating .....	35
Fig. 10	Display of operating mode (example) .....	35
Fig. 11	Menu structure of the SIGMA CONTROL MOBIL .....	39
Fig. 12	Machine data symbol .....	41
Fig. 13	Symbolic settings menu .....	44
Fig. 14	Event memory .....	45
Fig. 15	Event memory example: Alarm message .....	47
Fig. 16	Event memory example: Warning message .....	47
Fig. 17	Event memory example: Maintenance message .....	47
Fig. 18	Message code structure .....	48
Fig. 19	Air treatment options .....	49
Fig. 20	Coolant pre-heating .....	50
Fig. 21	Generator instrument panel - control box, 400 V, 3-phase .....	52
Fig. 22	Generator instrument panel - control box, 230 V, 3-phase .....	52
Fig. 23	Minimum distance from excavations/slopes and walls .....	55
Fig. 24	Fitting the towbar .....	58
Fig. 25	Fitting the towbar .....	58
Fig. 26	Towbar height adjustment .....	59
Fig. 27	Changing the towing eye (height-adjustable towbar) .....	60
Fig. 28	Changing the towing eye (fixed height towbar, GB chassis version) .....	61
Fig. 29	Changing the towing eye (fixed height towbar, USA chassis version) .....	61
Fig. 30	Temperature display setting .....	64
Fig. 31	Unit of pressure setting .....	65
Fig. 32	Waiting for password entry .....	65
Fig. 33	Password level 1 activated. ....	66
Fig. 34	Engine settings menu .....	67
Fig. 35	Settings in start/stop/automatic .....	69
Fig. 36	Jumper cable connection diagram .....	71
Fig. 37	Coolant pre-heating .....	73
Fig. 38	Insulation monitoring - 400 V, 3-phase generator .....	73
Fig. 39	Insulation monitoring - 230 V, 3-phase generator .....	74
Fig. 40	Starting instruments .....	75
Fig. 41	Brief instructions on starting and stopping .....	76
Fig. 42	«Battery isolating switch» .....	76
Fig. 43	Select menu option "set pressure in the oil separator tank" .....	78
Fig. 44	Setting the output pressure .....	78
Fig. 45	Operating data menu .....	82
Fig. 46	External fuel pump switch-on symbol .....	83
Fig. 47	Checking coolant level .....	104
Fig. 48	Draining the coolant from the radiator .....	106
Fig. 49	Radiator with centralised drainage .....	107
Fig. 50	Engine air filter maintenance .....	108
Fig. 51	Cleaning the filter element .....	109
Fig. 52	Fuel system maintenance .....	110
Fig. 53	Warning indication: Fuel filter water level .....	111
Fig. 54	Emptying the fuel prefilter water trap .....	112

Fig. 55	Changing the fuel prefilter cartridge .....	112
Fig. 56	Fuel filter maintenance .....	113
Fig. 57	Checking the engine oil level .....	114
Fig. 58	Draining the engine oil .....	116
Fig. 59	Draining the engine oil, central drain point .....	117
Fig. 60	Changing the oil filter .....	118
Fig. 61	Belt tension checking by hand .....	119
Fig. 62	Safety signs - warning stickers on the battery .....	120
Fig. 63	Checking cooling oil level .....	123
Fig. 64	Changing the cooling oil .....	125
Fig. 65	Central compressor oil drainage .....	126
Fig. 66	Changing the oil filter .....	128
Fig. 67	Cleaning the dirt trap .....	129
Fig. 68	Changing the oil separator cartridge .....	130
Fig. 69	Compressor air filter maintenance .....	132
Fig. 70	Cleaning the filter element .....	132
Fig. 71	Cooler/radiator cleaning .....	134
Fig. 72	Cleaning the compressed air aftercooler .....	135
Fig. 73	Overrun braking mechanism maintenance .....	137
Fig. 74	Ball coupling maintenance .....	138
Fig. 75	Ball coupling maintenance (USA version) .....	138
Fig. 76	Checking the brake lining thickness .....	139
Fig. 77	Brake adjustment .....	140
Fig. 78	Cleaning the dirt trap .....	141
Fig. 79	Combination filter maintenance .....	143
Fig. 80	Breathing air filter maintenance .....	145
Fig. 81	Generator belt tensioning .....	147
Fig. 82	Towing alignment .....	156
Fig. 83	Ball coupling (ALKO-EU) .....	157
Fig. 84	Ball coupling (ALKO-USA) .....	158
Fig. 85	Safety sign - secure the chocks .....	159
Fig. 86	Breakaway cable attachment .....	160
Fig. 87	Injury can occur if the towbar is unsupported and allowed to fall. ....	160
Fig. 88	Safety sign - secure the chocks .....	161
Fig. 89	Transporting using a forklift truck .....	163
Fig. 90	Load secured by strapping .....	164
Fig. 91	Marking .....	166

Tab. 1	The levels of danger and their meaning .....	2
Tab. 2	Nameplate .....	3
Tab. 3	Combined label for coupling load and options fitted .....	4
Tab. 4	Compressed air treatment plant .....	4
Tab. 5	Compressed air distributor .....	4
Tab. 6	Check valve function .....	5
Tab. 7	Low temperature equipment .....	5
Tab. 8	Chassis .....	5
Tab. 9	Lighting .....	5
Tab. 10	Pedestrian protection .....	6
Tab. 11	Guaranteed sound power level .....	6
Tab. 12	Emission sound pressure level .....	6
Tab. 13	Guaranteed sound pressure level .....	6
Tab. 14	Torques for hex-head screws .....	7
Tab. 15	Ambient conditions .....	7
Tab. 16	Machine weights .....	7
Tab. 17	Tyres .....	8
Tab. 18	Wheel nut/bolt tightening torque .....	8
Tab. 19	Towbar tightening torque .....	8
Tab. 20	Working pressure and FAD .....	8
Tab. 21	Compressed air distributor .....	9
Tab. 22	Relief valve activating pressure .....	9
Tab. 23	Machine temperatures .....	9
Tab. 24	Cooling oil recommendation .....	9
Tab. 25	Cooling oil charge .....	10
Tab. 26	Engine specification .....	10
Tab. 27	Engine oil recommendation .....	11
Tab. 28	Engine fluid volumes .....	11
Tab. 29	Batteries .....	11
Tab. 30	Ambient conditions .....	12
Tab. 31	Batteries .....	12
Tab. 32	Coolant pre-heater .....	12
Tab. 33	Generator data .....	13
Tab. 34	Delivery in generator mode .....	13
Tab. 35	Connection sockets .....	13
Tab. 36	Overload protection switch .....	14
Tab. 37	Generator operating limits .....	14
Tab. 38	Maximum three-phase mains loading .....	15
Tab. 39	Maximum single-phase mains loading .....	15
Tab. 40	Inspection intervals according to regulations .....	18
Tab. 41	Danger areas .....	23
Tab. 42	Safety signs .....	24
Tab. 43	Instrument panel keys and displays .....	33
Tab. 44	Display of messages prior to starting .....	35
Tab. 45	Operating mode display .....	35
Tab. 46	Display of operational state .....	36
Tab. 47	SIGMA CONTROL MOBIL operating sequence .....	37
Tab. 48	Menu structure of the SIGMA CONTROL MOBIL .....	38
Tab. 49	Settings menu .....	39
Tab. 50	Menu selection .....	39
Tab. 51	Menu option list .....	40
Tab. 52	Navigation (menu) .....	40
Tab. 53	Symbolic display of engine oil pressure .....	41
Tab. 54	Engine data display .....	41

Tab. 55	Display of compressor operating data .....	42
Tab. 56	Password level .....	42
Tab. 57	Menu guidance .....	43
Tab. 58	Event memory outline .....	46
Tab. 59	Message code structure .....	48
Tab. 60	Generator/compressor operation .....	51
Tab. 61	Generator operating modes .....	51
Tab. 62	Installation and operating conditions checklist .....	63
Tab. 63	Measures for re-commissioning the compressor after a long period of storage .....	70
Tab. 64	Test instructions for a generator with an insulation monitoring .....	74
Tab. 65	Fault messages and actions concerning the engine. ....	85
Tab. 66	Fault messages and actions concerning the compressor unit .....	87
Tab. 67	Fault messages and actions concerning the controller. ....	87
Tab. 68	General fault messages and measures .....	87
Tab. 69	Warning messages and measures relating to the engine. ....	89
Tab. 70	Warning messages and measures relating to the compressor .....	89
Tab. 71	General warning messages and measures .....	90
Tab. 72	Fault: engine refuses to start or comes to a stop. ....	90
Tab. 73	Fault: engine does not reach full speed. ....	91
Tab. 74	Fault: working pressure too high .....	91
Tab. 75	Fault: working pressure too low .....	92
Tab. 76	Fault: pressure relief valve blowing off .....	92
Tab. 77	Fault: machine overheating .....	93
Tab. 78	Fault: too much oil residue in the compressed air .....	93
Tab. 79	Fault: oil flows from the compressor air filter after shutdown .....	94
Tab. 80	Fault: high moisture content in the compressed air .....	94
Tab. 81	There is no voltage or too low a voltage from the generator .....	94
Tab. 82	Generator voltage too high .....	95
Tab. 83	Maintenance messages and measures connected with engine maintenance. ....	97
Tab. 84	Maintenance messages and measures connected with compressor maintenance. ....	97
Tab. 85	Maintenance tasks after commissioning .....	98
Tab. 86	Maintenance intervals and regular maintenance tasks .....	98
Tab. 87	Regular maintenance tasks .....	99
Tab. 88	Regular maintenance tasks for options .....	102
Tab. 89	KAESER coolant mixture table .....	105
Tab. 90	Logged maintenance tasks .....	150
Tab. 91	Compressor consumables .....	151
Tab. 92	Consumable engine parts .....	151
Tab. 93	"Temporarily decommissioned" information notice .....	153
Tab. 94	Long-term decommissioning checklist .....	154
Tab. 95	Text for the long-term decommissioned information notice .....	155
Tab. 96	Message code range 1100 – 1199: engine faults .....	238
Tab. 97	Message code range 1200 – 1299: compressor unit faults .....	239
Tab. 98	Message code range 1300 – 1399: controller faults .....	239
Tab. 99	Message code range 1400 – 1499: general faults .....	239
Tab. 100	Message code range 2100 – 2199: engine maintenance .....	240
Tab. 101	Message code range 2200 – 2299: compressor unit maintenance .....	240
Tab. 102	Message code range 3100 – 3199: engine warnings .....	240
Tab. 103	Message code range 3200 – 3299: compressor unit warnings .....	240
Tab. 104	Message code range 3400 – 3499: general warnings .....	240

# 1 Regarding this document

## 1.1 Using the Document

The service manual is part of the machine. It describes the machine as it was at the time of first delivery after manufacture.

- Keep the service manual in a safe place throughout the life of the machine.
- Pass the manual on to the next owner/user of the machine.
- Ensure that all amendments received are entered in the manual.
- Enter details from the machine nameplate and individual items of equipment in the table in chapter 2.

## 1.2 Further documents

Included with this service manual are additional documents intended to assist in the safe operation of the machine:

- Certificate of acceptance / operating instructions for the pressure vessel
- Manufacturer's declaration / declaration of conformity in accordance with applicable directives
- Engine documentation (compressors driven by internal combustion engine)

Missing documents can be requested from KAESER.

- Make sure all documents are complete and observe the instructions contained in them.
- Make sure you give the data from the nameplate when ordering documents.

## 1.3 Copyright

This service manual is copyright protected. Queries regarding use or duplication of the documentation should be referred to KAESER. Correct use of information will be fully supported.

## 1.4 Symbols and markings

### 1.4.1 Warning notices

Warning notices indicate three levels of danger signified by the signal word.

- DANGER
- WARNING
- CAUTION

**DANGER**

These show the kind of danger and its source.

The possible consequences of ignoring a warning are shown here.

The signal word "DANGER" indicates that death or severe injury can result from ignoring the warning.

- The measures required to protect yourself from danger are shown here.

## 1 Regarding this document

### 1.4 Symbols and markings

- Always read and comply with warning instructions.

Signal word	Meaning	Consequences of non-observance
DANGER	Warns of an imminent threat of danger	Death or serious injury may result
WARNING	Warns of possible danger	Death or serious injury are possible
CAUTION	Warns of a possibly dangerous situation	Light injuries or material damage are possible

Tab. 1 The levels of danger and their meaning

#### 1.4.2 Other notices and symbols



This symbol refers to particularly important information.

Material Here you will find details on special tools, operating materials or spare parts.

Precondition Here you will find conditional requirements necessary to carry out the task.  
Here conditions relevant to safety are named that will help you to avoid dangerous situations.

Option da ➤ This symbol is placed by lists of actions comprising one stage of a task.  
In lists of actions with several stages the sequence of actions is numbered.  
Information that refers to only one option is marked with a code (e.g.: "option da" means that this section is only valid for machines with the air treatment components "aftercooler and cyclone separator"). Option codes used in this service manual are explained in chapter 2.2.



Information referring to potential problems are identified by a question mark.

The cause is named in the help text ...

➤ ... and a remedy given.



This symbol refers to important information or measures concerning environmental protection.

Further information Here, your attention is drawn to further topics.

## 2 Technical Specification

### 2.1 Nameplate

The model designation and important technical information are given on the machine's nameplate.

The nameplate is located on the outside of the machine (see illustration in chapter 13.1)

► Enter the data from the nameplate here as a reference.

Characteristic	Value
Vehicle identity no.	
Permissible total weight	
Permissible axle load	
Permissible coupling load	
Compressor model	
Material number	
serial number	
Year of manufacture	
Total weight	
Lifting point load capacity	
Rated engine power	
Engine speed	
Maximum working pressure	

Tab. 2 Nameplate

### 2.2 List of Options

A list of the options fitted to your machine helps to relate the information in this service manual.  
A list of options fitted is given as code letters on the right side of the coupling load / options label.

The label is to be found

- on the outside of the machine
- on the front (see chapter 13.1)



The following table lists all possible options.  
Only the codes for those options fitted appear on the label.

- Take a list of fitted options from the combined coupling load / options label.

M121	MATNR	SERNR
		Options fitted
	Here is given the specified coupling load.	da db dc dd __
		__ __ __ __ __
		fa __ __ __ __
		__ __ hc hd __
		__ __ __ __ __
		ba bb __ __ __
		__ __ __ __ __
		ga __ __ __ __
		__ __ va __ __
		__ __ __ __ __
		__ __ __ __ __
		sa __ sc sd __
		ta tb tc __ te
		__ sg __ __ __
		02-M0277

Tab. 3 Combined label for coupling load and options fitted

### **2.2.1 Option da, db, dc, dd** **Compressed air treatment plant**

- Enter the fitted options as reference.

Option	Option code	Exists?
Aftercooler and cyclone separator	da	
Heat exchanger	db	
Breathing air filter	dc	
Filter combination	dd	

Tab. 4 Compressed air treatment plant

### **2.2.2 Option fa** **Compressed air distributor**

- Enter the fitted option as reference.

Option	Option code	Exists?
Non-separated compressed air distribution line	fa	

Tab. 5 Compressed air distributor

**2.2.3 Option hc, hd**  
**Check valve function**

- Enter the fitted option as reference.

Option	Option code	Exists?
Check valve	hc, hd	

Tab. 6 Check valve function

**2.2.4 Option ba, bb**  
**Low temperature equipment**

- Enter the fitted option as reference.

Option	Option code	Exists?
Low temperature equipment	ba	
Low temperature equipment + engine coolant pre-heating	bb	

Tab. 7 Low temperature equipment

**2.2.5 Option sa, sc, sd, sh, si**  
**Chassis**

- Enter the fitted option as reference.

Option	Permissible axle load [kg] (remarks)	Option code	Exists?
Height adjustable towbar	2700	sa	
Fixed height towbar	2700	sd	
Fixed height towbar without parking brake	2700	sh	
Stationary, on skids	–	sc	
Stationary, on a base frame	–	si	

Tab. 8 Chassis

**2.2.6 Option ta, tb, tc, te**  
**Lighting**

- Enter the fitted option as reference.

Option	Option code	Exists?
None (stationary)	ta	
Reflective warning triangle	tb	
EG - 12 V	tc	

Option	Option code	Exists?
USA 12 V (DOT conformity)	te	

Tab. 9 Lighting

### 2.2.7 Option sg Pedestrian protection

- Enter the fitted option as reference.

Option	Option code	Exists?
Pedestrian protection	sg	

Tab. 10 Pedestrian protection

## 2.3 Machine (without options)

### 2.3.1 Sound emission

#### 2.3.1.1 Sound emission

Model	M135
Guaranteed sound power level* [dB(A)]	99

\* To Directive 2000/14/EC

Tab. 11 Guaranteed sound power level

Model	M135
Emission sound pressure level* [dB(A)] According to EN ISO 11203: 1995 number 6.2.3.d.	80.5

Measurement distance: d = 1 m

Logarithmic surface ratio: Q2 = 18dB(A)

\* Calculated from the guaranteed sound power level (2000/14/EC Directive, Sound Emission Standard ISO 3744)

Tab. 12 Emission sound pressure level

#### 2.3.1.2 Sound pressure level

Model	M135
Sound pressure level* [dB(A)]	76

Measurement distance: 7 m

\* Sound pressure levels comply with the American EPA Standard.

Tab. 13 Guaranteed sound pressure level

### 2.3.2 Torques

Recommended values for hexagonal bolts of strength category 8.8

Hex-head screws							
Thread	M6	M8	M10	M12	M14	M16	M18
Torque [Nm]	9,5	23	46	80	127	195	280

Tab. 14 Torques for hex-head screws

### 2.3.3 Ambient conditions

Installation	Limit value
Maximum altitude AMSL* [m]	1000
Minimum ambient temperature [°C]	-10
Maximum ambient temperature [°C]	+50

\* Higher altitudes are permissible only after consultation with the manufacturer.

Tab. 15 Ambient conditions

### 2.3.4 Additional specifications

For specifications according to the machine's operating licence, such as:

- dimensions,
- track width,
- footprint,

see the dimensional drawing in chapters 13.3, 13.4, 13.5, 13.6 and 13.7.



The dimensional drawing also shows the position of the following inlets and outlets:

- Cooling air inlet
- Cooling air outlet
- Compressed air outlet
- Exhaust

## 2.4 Chassis

### 2.4.1 Weights



Maximum weights are shown. Actual weights of individual machines are dependent on equipment fitted (see machine nameplate).

Characteristic	Chassis		Stationary
Height adjustment	with	without	-
Actual total weight [kg]*			

\* Enter here for reference, the actual total weight taken from the nameplate.

Characteristic	Chassis		Stationary
Permissible axle load [kg]	2700	2700	–

\* Enter here for reference, the actual total weight taken from the nameplate.

Tab. 16 Machine weights

#### 2.4.2 Tyres

Characteristic/marking	Axle load up to 2700
Tyre size	215/75R 17.5
Maximum and recommended tyre pressure [bar]	5.75
Wheel bolts	M 18 x 1.5

Tab. 17 Tyres

Further information See tyre side wall for maximum pressure.

#### 2.4.3 Wheel nut/bolt tightening torque

Fixing medium	Thread	Wrench size	Torque [Nm]
Wheel bolt	M 18 x 1.5	34	325

Tab. 18 Wheel nut/bolt tightening torque

#### 2.4.4 Towbar tightening torque

Component	Thread	Strength category	Torque [Nm]
Ball coupling	M16	8.8	210
Towing eye	M16	8.8	210
Towbar	M20	10.9	540–560
	M24	8.8	670–690

Tab. 19 Towbar tightening torque

### 2.5 Compressor

#### 2.5.1 Working pressure and FAD

Maximum working pressure [bar]	10	12	14
SIGMA airend	29 G		
Free air delivery [ $m^3/min$ ]	13.0	12.0	10.5

Tab. 20 Working pressure and FAD

### 2.5.2 Compressed air outlet

Outlet valve ["]	Number
G 3/4	3
G 2	1

Tab. 21 Compressed air distributor

### 2.5.3 Pressure relief valve

Further information Maximum working pressure: see nameplate

Maximum working pressure [bar]	Activating pressure [bar]
7	—
8.6	—
10	13
12	15
14	16

Tab. 22 Relief valve activating pressure

### 2.5.4 Temperature

Machine temperatures	Values
Recommended airend discharge temperature for switching to load [°C]	30
Typical airend discharge temperature during operation [°C]	75 ..... 100
Maximum airend discharge temperature (automatic safety shut-down) [°C]	117

Tab. 23 Machine temperatures

### 2.5.5 Cooling oil recommendation

A sticker showing the type of oil used is located near the oil separator tank filler.

Information on ordering cooling oil is found in chapter 11.

Characteristic	SIGMA FLUID	
Oil grade	S-460	MOL
Classification	Silicone-free, synthetic oil	Mineral oil
Application	Standard oil for all applications except in connection with foodstuffs.  Particularly suitable for machines with a high duty cycle.	Standard oil for all applications except in connection with foodstuffs.  Particularly suitable for machines with a low duty cycle.

## 2 Technical Specification

### 2.6 Engine

Characteristic	SIGMA FLUID	
Oil grade	S-460	MOL
Approval	—	—
Viscosity at 40 °C	45 mm <sup>2</sup> /s (D 445; ASTM test)	44 mm <sup>2</sup> /s (DIN 51562-1)
Viscosity at 100 °C	7.2 mm <sup>2</sup> /s (D 445; ASTM test)	6.8 mm <sup>2</sup> /s (DIN 51562-1)
Flash point	238 °C (D 92; ASTM test)	220 °C (ISO 2592)
Density at 15 °C	864 kg/m <sup>3</sup> (ISO 12185)	—
Pour point	-46 °C (D 97; ASTM test)	-33 °C (ISO 3016)
Demulsibility at 54 °C	40/40/0/10 min (D 1401; ASTM test)	—

Tab. 24 Cooling oil recommendation

### 2.5.6 Cooling oil charge

Cooling oil	Fluid volume [l]
Machine	43
Compressor unit + heat exchanger (option db)	46

Tab. 25 Cooling oil charge

## 2.6 Engine

### 2.6.1 Engine specification

Characteristic	Specified
Make/Model	Deutz / TCD 2013 L04
Engine control	electronic
Fuel injection	Common rail system
Rated power [kW]	122
Speed under full load [rpm]	2000
Idling speed [rpm]	1300
Type of fuel	Diesel *
Fuel consumption under full load [l/h]	28.5
Oil consumption related to fuel consumption [%]	ca 0.5

\* Use only diesel fuel to EN 590, or ASTM D975. Consult the engine manufacturer on the use of other fuels.

Tab. 26 Engine specification

### 2.6.2 Oil recommendation

The engine oil must meet the following classification:

- ACEA, class E4, E7
- API, class CF, CI-4



The engine is filled initially with engine oil of viscosity class SAE 10 W / 40.

Ambient temperature [°C]	Viscosity class
-30 ..... 30	SAE 0 W / 30 SAE 5 W / 30
-30 ..... 50	SAE 0 W / 40 SAE 5 W / 40
-20 ..... 30	SAE 10 W / 30
-30 ..... 50	SAE 10 W / 40
-15 ..... 50	SAE 15 W / 40
-5 ..... 50	SAE 20 W / 50

Tab. 27 Engine oil recommendation

### 2.6.3 Engine coolant recommendation

Engine coolant must meet the requirements of specification ASTM D4985.



Do not use a coolant / antifreeze that meets only the requirements of ASTM D3306. Such coolants are intended only for light use in vehicles and could shorten the useful life of the engine.  
The engine service manual gives further information on coolant application.

### 2.6.4 Fluid volumes

Name	Fluid volume [l]
Engine oil	15.0
Fuel	200.0
Engine coolant	19.0

Tab. 28 Engine fluid volumes

### 2.6.5 Batteries

Characteristic	Value
Voltage [V]	24 (2 x 12)
Capacity [Ah]	2 x 100

Characteristic	Value
PTC testing current [A] (according to EN 50342)	850

Tab. 29 Batteries

Further information Depending on machine equipment, a higher capacity battery may be required. See chapter 2.7.1 for low temperature equipment.

## 2.7 Options

### 2.7.1 Option ba Low temperature equipment

#### 2.7.1.1 Ambient conditions

Positioning	Limit value
Maximum altitude AMSL* [m]	1000
Minimum ambient temperature [°C]	-25
Maximum ambient temperature [°C]	+50

\* Higher altitudes are permissible only after consultation with the manufacturer.

Tab. 30 Ambient conditions

#### 2.7.1.2 Batteries

Feature	Value
Voltage [V]	24 (2 x 12)
Capacity [Ah]	2 x 135
PTC testing current [A] (according to EN 50342)	1000

Tab. 31 Batteries

#### 2.7.1.3 Option bb Coolant pre-heating

Coolant pre-heater	Value
Voltage [V]	240
Power [W]	1000
Rated current [A]	6.0

Tab. 32 Coolant pre-heater

### 2.7.2 Option ga Generator

#### Generator specification

Characteristics	Generator 400 V/3~	Generator 230 V/3~
Rated power [kVA] 3-phase	15.0	15.0
Rated power [kVA] 1-phase	7.0	7.5
Voltage [V]	400/230	230/230
Voltage constant [%] balanced load		±5
Voltage constant [%] single-phase load		+6/-10
Rated current [A] 1-phase	21.7	32.6
Rated current [A] 3-phase	30.4	32.6
Rated current [A] short circuit (0.3 s/170 V)	300.0	330.0
Power factor (cos phi)	0.8 – 1	
Frequency [Hz]		50
Speed [rpm]		3000
Distortion factor [%]		<5
Type	Synchronous internal pole (electronically controlled)	
Enclosure protection	IP 54	

Tab. 33 Generator data

#### Reduced FAD

Maximum working pressure [bar]	10	12	14
SIGMA airend	29 G	29 G	29 G
Free air delivery [m³/min]	11.5	10.5	9.0

Tab. 34 Delivery in generator mode

#### Connections

Model	Generator 400 V/3~	Generator 230 V/3~
Power sockets	Number	Number
16 A; 230 V / 1~/N/PE	3	–
16 A; 400 V / 3~/N/PE	1	–

Model	Generator 400 V/3~	Generator 230 V/3~
Power sockets	Number	Number
16 A; 230 V / 2~ /PE	–	2
32 A; 230 V / 3~ /PE	–	1
16 A; 230 V / 3~ /PE	–	1

Tab. 35 Connection sockets

**Overload protection switch**

Model	Generator 400 V/3~	Generator 230 V/3~
Safety cut-out [A]	Number	Number
16	1	1
32	–	1

Tab. 36 Overload protection switch

**Operating limits**

(to EN 60034-22, page 10, table)

Characteristics	Value
Design category	G3
Voltage adjustment range [%]	±5
Static voltage deviation [%]	1
Maximum dynamic voltage drop [%]	-15
Maximum dynamic voltage rise [%]	20
Maximum voltage settling time [ms]	1500
Maximum voltage asymmetry [%]	1

Tab. 37 Generator operating limits

**Maximum power loading by consumers**

Resistive consumers include lamps and heaters, for example.

Electric motors and transformers are inductive consumers.

## Nominal rating conditions

- Ambient temperature: 25 °C
- Max. height above sea level at the place of use: 1000 m

**Three-phase power supply**

<b>Generator</b>		<b>400 V, 3-ph</b>	<b>230 V, 3-ph</b>
Rated power [kVA]		15.0	15.0
Resistive consumers [kVA]	–	11.0	12.7
Inductive consumers [kW]	Rated power	11.0	12.7

Tab. 38 Maximum three-phase mains loading

**Single phase**

<b>Generator</b>		<b>400 V, 3-ph</b>	<b>230 V, 3-ph</b>
Rated power [kVA]		15.0	15.0
Resistive consumers [kVA]	per phase	3.6	3.6
	Total	10.8	10.8
Inductive consumers [kW]	Rated power per phase	3.6	3.6
	Rated power total	10.8	10.8

Tab. 39 Maximum single-phase mains loading

## 3 Safety and Responsibility

### 3.1 Basic Information

The machine is manufactured to the latest engineering standards and acknowledged safety regulations. Nevertheless, dangers can arise through its operation:

- danger to life and limb of the operator or third parties,
- impairments to the machine and other material assets.

**DANGER**

Disregard of these instructions can result in serious injury.

- Read the service manual carefully and take note of the contents for safe machine operation.

- Use this machine only if it is in a technically perfect condition and only for the purpose for which it is intended; observe all safety measures and the instructions in the service manual.
- Immediately rectify (have rectified) any faults that could be detrimental to safety.

### 3.2 Specified use

The machine is intended solely for generating compressed air for industrial use. An optional electric generator is available to generate electric power for individual consumers.

Any other use is considered incorrect. The manufacturer is not liable for any damages that may result from incorrect use. The user alone is liable for any risks incurred.

- Keep to the specifications listed in this service manual.
- Operate the machine only within its performance limits and under the permitted ambient conditions.
- Do not use compressed air for breathing purposes unless it is specifically treated.
- Do not use compressed for any application that will bring it into direct contact with foodstuffs unless it is specifically treated.

### 3.3 Improper Use

- Never direct compressed air at persons or animals.
- Do not use untreated compressed air for breathing purposes.
- Do not allow the machine to breath in toxic, acidic, flammable or explosive gases or vapours.
- Do not operate the machine in areas in which specific requirements with regard to explosion protection are in force.

### 3.4 User's Responsibilities

#### 3.4.1 Observe statutory and universally accepted regulations.

These are, for example, nationally applied European directives and/or valid national legislation, safety and accident prevention regulations.

- Observe relevant statutory and accepted regulations during operation, transporting and maintenance of the machine.

### 3.4.2 Defining personnel

Suitable personnel are experts who, by virtue of their training, knowledge and experience as well as their knowledge of relevant regulations can assess the work to be done and recognize the possible dangers involved.

Authorised operators possess the following qualifications:

- are of legal age,
- are conversant with and adhere to the safety instructions and sections of the service manual relevant to operation,
- have received adequate training and authorisation to operate vehicles and electrical and compressed air devices.

Authorised maintenance personnel possess the following qualifications:

- are of legal age,
- have read, are conversant with and adhere to the safety instructions and sections of the service manual applicable to installation and maintenance,
- are fully conversant with the safety concepts and regulations of motor vehicle, electrical and compressed air engineering,
- are able to recognise the possible dangers of motor vehicle, electrical and compressed air devices and take appropriate measures to safeguard persons and property,
- have received adequate training in and authorization for the safe installation and maintenance of this machine.

Authorised transport personnel possess the following qualifications:

- are of legal age,
- are conversant with and adhere to the safety instructions and sections of the service manual relevant to transporting,
- are trained and authorised in safe vehicle transporting,
- are conversant with the safety regulations relating to handling motor vehicles and transport goods,
- are able to recognise the possible dangers of motor vehicles and take appropriate measures to safeguard persons and property.

**DANGER**

There is danger of fatal injury caused by contact with live components.

- Only qualified electricians may work on the installation, maintenance and repair of the machine's electrical assemblies. This includes work on current-carrying components.
- Ensure that personnel entrusted with operation, maintenance and transporting are qualified and authorized to carry out their tasks.

### 3.4.3 Adherence to inspection schedules and accident prevention regulations

The machine is subject to local inspection schedules.

**Examples of German operation**

- Have the pre-commissioning inspection carried out according to the Ordnance on Safety and Health, paragraph 14.

### 3 Safety and Responsibility

#### 3.5 Dangers

- Recurring inspections according to BGR 500, chapter 2.11:  
The user must ensure that the machine's safety devices are checked for function as required or at least annually.
- Carry out oil changes to BGR 500, chapter 2.11.  
The user must ensure that the cooling oil is changed as required or at least annually and the oil change must be documented. Intervals may be varied if an analysis proves that the oil is still usable.
- Keep to inspection intervals in accordance with the Ordinance on Industrial Safety and Health with maximum intervals as laid down in §15.

Inspection	Inspection interval	Inspecting authority
Equipment inspection	Before commissioning	Approved supervisory body
Internal inspection	Every 5 years after commissioning or the last inspection	Competent person (e. g. KAESER Service Technician)
Strength test	Every 10 years after commissioning or the last inspection	Competent person (e. g. KAESER Service Technician)

Tab. 40 Inspection intervals according to regulations

#### Checking the lifting eye

The user is responsible for ensuring that the machine's lifting eye and fixings are inspected according to national regulations for wear and damage.

- Have the lifting eye checked.  
If the lifting eye or fixings are not fully in order the machine may not be lifted in this way. Have the machine repaired immediately.

## 3.5 Dangers

### Basic Information

Information concerning the various forms of danger that can arise during machine operation are found here.

Basic safety instructions are found in this service manual at the beginning of each chapter in the section entitled 'Safety'.

Warning instructions are found before a potentially dangerous task.

### 3.5.1 Safely dealing with sources of danger

Information is found here concerning how to counter the various forms of danger that can arise during machine operation.

#### Exhaust fumes

Exhaust fumes from combustion engines contain carbon monoxide; this gas is odourless and can cause death.

- Use the machine only outdoors!
- Do not inhale exhaust fumes.
- Direct the exhaust fumes to the open air with a pipe of at least 100 mm dia.

**Fire and explosion**

Spontaneous ignition and combustion of fuel can result in serious injury or death.

- Allow no open flames or sparks at the place of use.
- Do not smoke while refuelling.
- Never refuel the machine when it is running.
- Do not allow fuel to overflow.
- Wipe up spilled fuel immediately.
- Keep fuel away from hot machine parts.
- Make sure that the ambient temperature at the machine's place of use is within permissible limits.

**Hot coolant**

The cooling system of a liquid-cooled engine at running temperature is under high pressure.

Coolant can spray out when the filler cap is opened causing severe burns.

- Let the machine cool down before opening the cooling system.
- Unscrew the filler cap carefully by a quarter to half a turn at first. Remove the filler cap only when pressure has escaped completely.

**Forces of compression**

Escaping compressed air can cause serious injury. The following information concerns work on components that could be under pressure.

- Wait until the machine has automatically vented (check that the pressure gauge indicates 0 bar).
- Then open an outlet valve carefully to ensure that the line between the minimum pressure / check valve and the compressed air outlet is vented.
- Do not carry out welding, heat treatment or mechanical modifications to pressurized components (e.g. pipes and vessels) as this influences the component's resistance to pressure.  
The safety of the machine is no longer ensured.

**Spring force**

Sudden release of spring force can cause serious energy.

Minimum pressure / check valves, pressure relief valves and inlet valves are powerfully spring-loaded.

- Do not open or dismantle any valves.

**Compressed air quality**

- Never directly inhale compressed air.
- Use appropriate systems for air treatment before using the compressed air from this machine as breathing air and/or for the processing of foodstuffs.
- Use foodstuff-compatible cooling oil whenever compressed air is to come into contact with foodstuffs.

**Rotating components**

Touching the fan wheel, the coupling or the belt drive while the machine is running can result in serious injury.

- Operate the machine only with closed safety guards, access doors and panels.
- Shut down the machine before opening a door or canopy.

### 3 Safety and Responsibility

#### 3.5 Dangers

- Wear close-fitting clothes and a hair net if necessary.
- Fit all safety devices and panels before starting the engine.

#### Electricity

- Allow only qualified and authorized electricians or trained personnel under the supervision of a qualified and authorized electrician to carry out work on electrical equipment according to electrical engineering regulations.
- Check regularly that all electrical connections are tight and in order.
- Only qualified and authorised electricians may carry out work on the generator or generator control box.
- Never carry out work on the generator or generator control box unless the machine is shut down.

#### Temperature

- Avoid contact with hot components. These include, for example, engine, compressor airend, oil and compressed air lines, coolers and oil separator tank.
- Wear protective clothing.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting fuel or oil vapours or parts of the machine.

#### Noise

- Operate the machine only with intact soundproofing.
- Wear hearing protection if necessary. The pressure relief valve blowing off, for example, can be particularly loud.

#### Operating fluids/materials

- Strictly forbid fire, open flame and smoking.
- Follow safety regulations when dealing with fuel, lubricants and chemical substances.
- Avoid contact with skin and eyes.
- Do not inhale fumes or aerosols from fuel or oil.
- Do not eat or drink while handling fuel, cooling and lubricating fluids.
- Keep suitable fire extinguishing agents ready for use.
- Use only KAESER approved operating materials.

#### Unsuitable spare parts

- Use only spare parts approved by the manufacturer for use in this machine. Unsuitable spare parts compromise the safety of the machine.
- Use only genuine KAESER pressure components.

#### Conversion or modification of the machine

- Do not permit conversion or modification of the machine as this can compromise function and safe working.

#### 3.5.2 Safe machine operation

Information on conduct that will help in handling the machine safely is given here.

**WARNING**

Danger of injury from hot, rotating and electrically live components!

Serious injury can be caused by touching such components.

- Operate the machine only with closed doors/canopy.
- Carry out maintenance and checks only with the machine shut down.

**Transporting**

- Shut down and fully disconnect the machine before transporting it.
- Allow transportation only by personnel trained in safely dealing with motor vehicles and the transporting of goods.
- Ensure that no persons are on the machine when transporting.
- Follow local traffic regulations when towing the compressor on public roads.
- Follow the ground rules for safe towing:
  - The maximum permissible load for the towing vehicle coupling and the maximum coupling load given for the machine must not be exceeded.
  - Avoid causing a shift in the centre of gravity by an excessive or incorrectly distributed load.
  - Do not tow in such a way as to impose excessive stress on the machine or chassis.
  - Adjust towing speed to accommodate ground conditions. This applies particularly on bends and corners.
- The towbar must be parallel with the ground otherwise towing instability can develop, resulting in damage to the machine and/or towing vehicle.
- Before moving the machine, make sure any security devices (e.g. anti-theft chain) are released.
- When the machine is lifted by a crane, the safety regulations relating to the crane and lifting slings must be observed.
  - Do not enter the danger zone while the machine is being lifted.
  - Never lift the machine over people or occupied buildings.
  - Secondary or attached loads may not:
    - cause excessive loading on the machine's lifting point (lifting eye),
    - adversely influence the machine's centre of gravity so that it hangs out of square.
  - Use only lifting slings that are suitable for the loads to which they will be subjected.
  - Use only hooks and shackles that comply with local safety regulations
  - Do not attach cables, chains or ropes directly to the machine's lifting eye.
  - Never tamper with the machine's lifting eye or its fixing.
  - Avoid jerking when lifting, as this may damage components.
  - Loads must be slowly lifted and carefully set down.
  - Never allow the load to hang from the crane longer than necessary.
- The following are forbidden:
  - transporting by slinging beneath a helicopter,
  - dropping by parachute.

**Positioning**

- Do not position the machine directly against a wall. A build up of heat from the exhaust can damage the machine.

### 3 Safety and Responsibility

#### 3.5 Dangers

- Do not operate in areas in which specific requirements regarding explosion protection are in force. For instance, the requirements of the ATEX directive 94/9/EC "Equipment and Protective Systems for use in Explosive Atmospheres".
- Ensure adequate ventilation.
- Ensure that required ambient conditions are maintained with regard to:
  - Ambient temperature
  - Clean inlet air with no damaging contaminants
  - Inlet air free of explosive or chemically unstable gases or vapours
  - Inlet air free of exhaust gasses from internal combustion engines
  - Inlet air free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulphide.
- Do not position the machine in warm cooling outlet air from other machines.
- Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.
- Chock the wheels to prevent unwanted movement.
- Do not place additional loads on the machine (e.g. excavator bucket as anti-theft measure).

#### Operation

- Keep the access doors closed for safety, quiet running and to ensure correct cooling air flow.
- Carry out regular inspections:
  - for visible damage and leakage,
  - of safety devices,
  - of components needing to be monitored.
- Never operate machines without an air filter when drawing in air from the surroundings.

#### Maintenance

- Make sure the machine is shut down, cooled down and pressure-free before commencing any maintenance work.
- Wear close-fitting, flame-resistant clothing. Wear protective clothing as necessary.
- Do not leave any loose components, tools or cleaning rags on or in the machine.
- Components removed from the machine may still be a source of danger.  
Do not open or destroy components removed from the machine as some, inlet valves, for instance, are powerfully spring-loaded.

#### De-commissioning, storage and disposal

- Drain out fluids and dispose of according to environmental regulations.  
These include, for example, fuel, engine oil and compressor cooling oil and engine coolant.
- Dispose of the machine in accordance with local environmental regulations.

#### 3.5.3 Organisational Measures

- Designate personnel and their responsibilities.
- Give clear instructions on reporting faults and damage to the machine.
- Give instructions on fire reporting and fire-fighting measures.

### 3.5.4 Danger areas

The table gives information on areas dangerous to personnel.

Only authorized personnel may enter these areas.

Task	Danger area	Authorized personnel
Transport	Within a 3 m radius of the machine.	Operating personnel to prepare for transport. No personnel during transport.
	Beneath the lifted machine.	No personnel!
Commissioning	Within the machine.	Maintenance personnel
	Within a 1 m radius of the machine.	
Operation	Within a 1 m radius of the machine.	Operating personnel
Maintenance	Within the machine.	Maintenance personnel
	Within a 1 m radius of the machine.	

Tab. 41 Danger areas

## 3.6 Safety Devices

Safety devices ensure safe working with the machine.

- Do not change, bypass or disable safety devices.
- Check safety devices for correct function regularly.
- Do not remove or obliterate labels and notices.
- Ensure that labels and notices are clearly legible.

Further information More information on safety devices is contained in chapter 4, section 4.5.

## 3.7 Safety signs

The diagram shows the positions of safety signs on the machine. The table lists the various safety signs used and their meanings.




Fig. 1 Location of safety signs

### 3 Safety and Responsibility

#### 3.7 Safety signs

Item	Sign	Meaning
310		It is forbidden to run the machine with open access doors or panels. Personal injury or machine damage can result from an open machine enclosure.
311		➢ Operate only with the enclosure fully closed. ➢ Transport only with the enclosure fully closed.
332		Hot surfaces and dangerous gas! Burning, from contact with hot components or gasses. ➢ Do not touch the surface. ➢ Wear long-sleeved garments (not synthetics such as polyester) and protective gloves. ➢ Do not inhale dangerous gases.
330		Hot surfaces!
331		Risk of burns caused by contact with hot components. ➢ Do not touch the surface. ➢ Wear long-sleeved garments (not synthetics such as polyester) and protective gloves.
620 621		Risk of serious lacerations or even severing of extremities (fingers) from rotating components. ➢ Operate the machine only with closed safety guards, access doors and panels. ➢ Shut down the machine before opening a door or canopy.
600*		Risk of fatal injury caused by dismantling valves (spring-loaded or under pressure) ➢ Do not open or dismantle valves. ➢ Call an authorized Service Technician if a fault occurs.
160*		Incorrect oil levels can cause damage to the machine or excessive oil content in the compressed air. ➢ Check the oil level regularly and correct as necessary.
320*		Loud noise and oil mist! Hearing damage and burning by relief valve blowoff. ➢ Wear hearing protectors and protective clothing. ➢ Close the canopy or doors. ➢ Work with caution.
850**		There is danger of fatal injury caused by contact with live components. ➢ Take protective measures.
510***		Malfunction due to deficient maintenance. Injury and machine damage possible. ➢ Maintain the chassis regularly. ➢ Note instructions in the service manual regarding the chassis.
1650*		Machine damage if switched while the engine is running! ➢ Use the «battery isolating switch» only with the engine stopped. ➢ Do not use the «battery isolating switch» as a main or emergency switch.

\* Location within the machine

\*\* Only machines with generator

\*\*\* Towable machines only

Tab. 42 Safety signs

## 3.8 Generator operation

### 3.8.1 Protection against dangerous electric current

Protection against dangerous electric current is regulated by IEC 60364-5-551 (DIN VDE 0100-551).

The measures concerning isolation, insulation monitoring and shut-down are applied. The generator is equipped with an automatic mains cut-out with overcurrent release and insulation monitoring in accordance with this protective measure.

- Observe and follow the regulations concerning protection against dangerous electric current when using the generator.

### 3.8.2 Instructions for safe generator operation

- Take note of the following for safe generator operation:

- Check correct function of the insulation monitoring device daily.
- Do not earth the neutral line (N) or connect it to the common protective earth/equipotential bonding (PE).
- Make sure the equipotential bonding to earth is properly carried through (mains and machine through cable to consumer).

If the generator feeds a network (TN network), let the network's protective measures remain effective or create another protective measure that is effective.

Adjust the protective measures accordingly if the generator feeds a different network.

Only a qualified electrician is allowed to carry out work on the generator or generator control box. The electrician is responsible for the effectiveness of the protective measures provided.

- Follow the regulations of the local electricity supply utility and obtain any necessary permits.
- When cleaning the inside of the machine do not direct water or steam jets directly at the generator or terminal box.
- Check regularly that all electrical connections are tight and in order.

### 3.8.3 Connection of extension cables

- Observe and adhere to the regulations regarding extension cables before operating the generator.
- In IT networks, the total length of power cables may not exceed 250 m ((DIN VDE 0100, Part 728 / IEC 60364-5-551).
- Use at least H07RN-F cables to DIN VDE 0282 Part 4 (IEC 60245-4 / HD 22.4) as non-fixed extension cables.

### 3.8.4 Maximum power supply loading

- Observe the following for maximum power supply loading of connected consumers:
- The power consumption values of simultaneous consumers are added.
- The maximum continuous power loading on the generator by the connected consumers is limited by the safety cut-out.

**3.8.5 Regular generator inspections**

- Adhere to the given inspection intervals for safe generator operation:
  - Daily check by authorised personnel:
    - Insulation monitor function check.
  - Annual inspection by trained and authorised electrician:
    - Visual check for mechanical damage to the generator and control box.
    - Visual check for damage to the insulation of connecting cables.
    - Earth conductor check.
    - Insulation resistance measurement.
    - Earth conductor current measurement.
    - Leakage current measurement.
    - Generator function check.
    - Check the generator fan and clean if necessary.
    - Check all screwed connections on the generator and control box and tighten if necessary.
    - Check that all warning and other labels are complete and undamaged.

**3.9 Emergencies****3.9.1 Correct fire fighting**

Suitable extinguishing agents:

- Foam
- Carbon dioxide
- Sand or earth

Unsuitable extinguishing agents:

- Strong jet of water
1. Keep calm.
  2. Give the alarm.
  3. Shut down the machine from the instrument panel if possible.
  4. To ensure safety:
    - warn persons in danger
    - help incapacitated persons
    - close the doors
  5. Try to extinguish the fire if you have the skill to do so.

**3.9.2 Contact with operating fluids/materials**

The following operating fluids/materials are in the machine:

- Fuel
- Engine coolant
- Battery electrolyte
- Lubricating oil
- Compressor cooling oil



If necessary, request a copy of the safety data sheet for KAESER SIGMA FLUID cooling oil.

- Eye contact:  
Rinse eyes thoroughly with lukewarm water and seek medical assistance.
- Skin contact:  
Wash off immediately.

## **3.10 Warranty**

This service manual contains no independent warranty commitment. Our general terms and conditions of business apply with regard to warranty.

A condition of our warranty is that the machine is used for the purpose for which it is intended under the conditions specified.

Due to the multitude applications for which the machine is suitable the obligation lies with the user to determine its suitability for his specific application.

In addition, we accept no warranty obligation for:

- the use of unsuitable parts or operating materials,
- unauthorised modifications,
- incorrect maintenance,
- incorrect repair.

Correct maintenance and repair includes the use of original spare parts and operating materials.

- Obtain confirmation from KAESER that your specific operating conditions are suitable.

## **3.11 Environmental Protection**

- Store and dispose of operating materials and replaced parts in accordance with local environmental protection regulations.
- Observe relevant national regulations.



This applies particularly to parts contaminated with fuel, oil, coolants and acids.



- Do not allow operating materials to escape to the environment or into the sewage system.

## 4 Design and Function

### 4.1 Bodywork

Bodywork is understood to be the exterior of the machine mounted on the chassis.




Fig. 2 Bodywork

- |   |                                 |   |                       |
|---|---------------------------------|---|-----------------------|
| ① | Right-hand wing door            | ⑤ | Lower body            |
| ② | Sound damping louver for cooler | ⑥ | Left-hand wing door   |
| ③ | Snap fastener                   | ⑦ | Cover for lifting eye |
| ④ | Handle                          |   |                       |

The bodywork has several functions when it is closed:


- Weather protection
- Sound insulation
- Guarding against touching
- Cooling air flow

The bodywork is not suitable for the following uses:

- Walking on, standing or sitting on.
- As resting place or storage of any kind of load.

Safe and reliable operation is only ensured when the bodywork is closed.


The gull doors are provided with handles for opening. Release the doors by the snap fasteners.

**4.2 Component identification**


04-M0011

**Fig. 3 Right-hand door opened**

- |                                     |                                 |
|-------------------------------------|---------------------------------|
| [1] Instrument panel (cover closed) | [6] Fuel filter                 |
| [2] Quick-stop pushbutton           | [7] Fuel filter with water trap |
| [3] Inlet valve                     | [8] Coolant expansion tank      |
| [4] Fuel tank                       | [9] Engine air filter           |
| [5] Engine                          | [10] Compressor air filter      |




04-M0012

**Fig. 4 Left-hand door opened**

- |                               |   |
|-------------------------------|---|
| [11] Fan                      | [15] Control valve with proportional controller |
| [12] Control cabinet          | [16] Minimum pressure/check valve               |
| [13] Battery isolating switch | [17] Lifting eye                                |
| [14] Oil separator tank       |   |

**4.3 Machine function**
**Machine function (without options)**

Item numbers correspond to the pipe and instrument flow diagram in chapter 13.2.


**Fig. 5 General design**

- |   |   |
|---|---|
| [1] Compressor air filter                     | [19] Combination valve (oil temperature thermostat) |
| [3] Inlet valve                               | [20] Oil cooler                                     |
| [4] Airend                                    | [21] oil filter                                     |
| [5] Oil separator tank                        | [23] Proportional controller                        |
| [7] Oil separator cartridge                   | [24] Engine air filter                              |
| [10] Compressed air distributor               | [27] Venting valve                                  |
| [13] Pressure relief valve                    | [28] Fan  |
| [14] Pressure gauge (on the instrument panel) | [37] Minimum pressure/check valve                   |
| [15] Engine                                   | [52] Control valve                                  |
| [16] Oil return line                          |   |

Ambient air is cleaned as it is drawn in through the filter [1].

The air is then compressed in the airend [4].

The airend is driven by an internal combustion engine [15].

Cooling oil is injected into the airend. It lubricates moving parts and forms a seal between the rotors themselves and between them and the airend casing. This direct cooling in the compression chamber ensures a very low airend discharge temperature.

Cooling oil recovered from the compressed air in the oil separator tank [5] gives up its heat in the oil cooler [20]. The oil then flows through the oil filter [21] and back to the point of injection. Pressure within the machine keeps the oil circulating. A separate pump is not necessary. A thermostatic valve [19] regulates the compressor's temperature.

Compressed air, freed of cooling oil in the oil separator tank [5], flows through the minimum pressure / check valve [37] into the air distributor [10]. The minimum pressure / check valve ensures that there is always a minimum internal pressure sufficient to maintain cooling oil circulation in the machine.

The cooling fan [28] ensures optimum cooling of all components within the enclosure.

## **4.4 Operating modes and control modes**

### **4.4.1 Operating modes**

The machine operates in the following modes:


- **LOAD**
  - The inlet valve is open.
  - The engine runs at maximum speed.
  - The airend delivers compressed air.
- **MODULATING**
  - With the help of a control valve (the proportional controller) the degree of opening of the inlet valve is steplessly varied in response to the air demand.
  - The load and fuel consumption of the engine rises and falls with the air demand.
  - The airend delivers compressed air.
- **IDLE**
  - The inlet valve is closed.
  - The control valve opens, allowing pressure in the oil separator tank to be applied to the inlet valve.
  - Compressed air then flows in a closed circuit through the airend, the oil separator tank and the control valve.
  - The pressure in the oil separator tank remains constant.
  - The engine runs at minimum speed.
- **STANDSTILL (shut down)**
  - The inlet valve closes.
  - The venting valve opens to depressurize the machine.
  - The engine stops.

### **4.4.2 MODULATING control mode**

The control system regulates the volume of air generated to match the actual demand. The machine keeps the working pressure constant by varying the volume of compressed air delivered, thereby matching the air demand.

With the help of an electrical control valve (the proportional controller), the opening and closing of the inlet valve is continuously varied in response to the actual air demand. The airend provides compressed air for connected consumers.

This stepless delivery regulation minimises fuel consumption of the engine. The load and fuel consumption of the engine rises and falls with the air demand.



04-M0007

Fig. 6 Stepless regulation of FAD (standstill)

③	Inlet valve	⑥③	Control valve (proportional valve)
④	Airend	⑤②	Control valve
⑤	Oil separator tank	②③	Proportional controller (electric)
④⑥	Nozzle	⑦	Venting valve

## 4.5 Safety devices

### 4.5.1 Monitoring functions with shutdown

The SIGMA CONTROL MOBIL monitors the important machine parameters. The machine is automatically shut down if an alarm occurs.

The SIGMA CONTROL MOBIL saves the alarm message.

Further information Further information on alarm messages is to be found in chapter 9.2.1.

### 4.5.2 Further safety devices

The following safety devices are provided and may not be modified in any way.

- Quick stop button
  - For immediate shutdown of the machine. The engine comes to a stop. The pressure system is vented.

- Pressure relief valves  
Pressure relief valves protect the system against unacceptable pressure rise. They are factory set.
- Enclosures and covers over moving parts and electrical connections:  
These protect against accidental contact.

## 4.6 SIGMA CONTROL MOBIL keys and displays




Fig. 7 Instrument panel keys and displays

Item	Sign	Name	Function	Background LED
1		«Acknowledge » key.	Acknowledgement key Acknowledges active and displayed messages.	Flashes when a message is active and waiting for acknowledgement.
2		«Information» key	Displays the event memory.	Flashes if a message is active.
3		«Menu» key	Displays the main menu.	-
4		«Horizontal arrows» change values «LEFT» and «RIGHT» keys	Change parameter values, cursor movement when entering a password.	-
5		«UP» and «DOWN» keys	Vertical movement in menus. Change values in password entry.	-

Item	Sign	Name	Function	Background LED
6		«esc» key	Returns to the menu, interrupts an entry.	–
7		«Enter» key	Selects a menu option, confirms an entry.	–
8		«Stop» key	Stops the machine.	Lights when an alarm occurs
9		«Start» key	Starts the machine	Flashes when ready to start. Illuminates when the engine is running.
10		«Load» key	Toggles between warm up and load.	Flashes when ready to switch to LOAD. Illuminates when the machine is operating under LOAD.
11	–	Indicator field or display	Graphic display	–

Tab. 43 Instrument panel keys and displays

## 4.7 SIGMA CONTROL MOBIL function

### 4.7.1 Display

Description of display field

- Graphic display
- Monochrome display
- 128 x 64 pixels

#### Opening page

The following is shown on this page while the controller is booting up:





Fig. 8 Opening page

#### Preheating

At temperatures below zero the engine is preheated, regulated by the engine control unit. The pre-heating period is influenced by an ambient temperature sensor.



04-M0346

Fig. 9 Engine preheating

#### Display of messages before the machine is ready to start

If there are messages in the event memory from the last machine operation, these will be displayed.

Message type	Function
Alarm	<ul style="list-style-type: none"> <li>➤ Displayed alarm rectified</li> <li>➤ Press the «Acknowledge»  key. The message is deleted and the engine can be started.</li> </ul>
Warning	<ul style="list-style-type: none"> <li>➤ Press the «Acknowledge»  key. The message is deleted and the engine can be started.</li> </ul>
Maintenance	<ul style="list-style-type: none"> <li>➤ Press the «Acknowledge»  key. The message is deleted and the engine can be started.</li> </ul>

Tab. 44 Display of messages prior to starting



See chapter 4.8.3 for explanation of messages.


#### Operating mode display

As soon as the machine is started, the display changes to show the operating mode.

The display changes automatically with each change in the machine's operating mode.

The display can be composed of symbols and alpha-numeric characters that together give a clear and logical meaning.

The display of operating mode is in two parts. The common display in the upper screen **always** shows the current airend discharge temperature. The lower half shows the machine's operating mode.



04-M0343

Fig. 10 Display of operating mode (example)

- [A] Airend discharge temperature (ADT)
- [B] Operational state

Meaning of the display	Explanation
Airend discharge temperature	The airend discharge temperature can be displayed in °C, °F or K as selected by the user.

Meaning of the display	Explanation
Operational state	See table for displays of operational states.

Tab. 45 Operating mode display

**Display of operational state**

The machine's current operational state is shown in the lower half of the display. The following states are available:

Item	Operational state	Meaning of the display	Explanation
B1		Ready to start	The machine can be started.
B2		IDLE	The machine is running in IDLE.
B3		Start-up	The engine is run up.
B4		LOAD	The machine is running under LOAD.
B5		Run-on phase	Cool-down function The timer setting is 60 seconds.
B6		Cool-down phase when machine overheated	Cool-down phase when the compressor and/or engine coolant overheated.
B7		Back pressure	The remaining pressure in the OST* is displayed and the machine cannot be started. The display is in bar or psi as selected by the user.
B8		Start inhibit	A start sequence is inhibited and the display shows the time remaining until the next start sequence is allowed. The timer setting is 20 seconds.

OST\* = oil separator tank

Tab. 46 Display of operational state

**4.7.2 SIGMA CONTROL MOBIL operating sequence**

Operating sequence	Key	Indication	Explanation
Ready to start			The «Start» key flashes.
Start ► Press the «Start» key.			The engine starts automatically. Maximum starting time 15 seconds. The starter disengages automatically when the engine picks up speed.
Engine running			The «Start» key illuminates.
Warm-up / IDLE phase			The machine runs in IDLE until the ADT* and ECT** reach 30 °C. While either of the temperatures is > 30 °C, the machine cannot be switched to LOAD. The machine may be switched to LOAD when the «Load» key flashes.
LOAD ► Press the «Load» key.			The machine switches over to LOAD. The «Load» key illuminates.
Set pressure:			The outlet pressure is set.
either Run-on phase ► Press the «Load» key.			The machine switches over to unloaded run-on. The engine runs at IDLE speed. The machine is vented. The «Load» key flashes.

\* ADT = airend discharge temperature

\*\* ECT = engine coolant temperature

\*\*\* OST = oil separator tank

Operating sequence	Key	Indication	Explanation
<i>or</i> <b>Stop</b> ➤ Press the «Stop» key and hold for more than a second.		60 s 7 bar 20 s	The machine switches over to unloaded run-on. The cool-down period is displayed The engine runs at IDLE speed. The machine is vented. The «Load» key flashes. Pressure in the OST** > 1 bar: back-pressure displayed. Pressure in the OST** ≤ 1 bar: display indicates "ready to start".
<b>Failed start, starting sequence interrupted</b>		20 s	The start inhibit function is activated if the machine fails to start or if the starting sequence is interrupted. The display shows the time remaining until the next starting sequence is allowed.

\* ADT = airend discharge temperature

\*\* ECT = engine coolant temperature

\*\*\* OST = oil separator tank

Tab. 47 SIGMA CONTROL MOBIL operating sequence

#### 4.7.3 Menu structure of the SIGMA CONTROL MOBIL

##### Menu structure

Main menu	Menu level 1	Menu level 2
Display of operating modes	Main menu	Operating data Compressor engine Settings menu Password input Engine test mode (ECU) Generator operating data
	Event memory	Alarm messages Warning messages Maintenance messages

Tab. 48 Menu structure of the SIGMA CONTROL MOBIL

#### Settings menu

Menu level 2	Menu level 3	Menu level 4
Settings menu	Setting indicator unit	-
	Controller functions (password-protected)	Compressor model Options Service functions
	Engine settings	-
	Options	"Start/stop/automatic" option "External fuel pump" option "GSM/GPS module" option

Tab. 49 Settings menu

## 4.8 List of menus

Pressing the «Menu» key (Fig. 7, item ③) opens the main menu.

By looking through the menu options, the engine and compressor unit data can be seen and adjustments made. The event memory can also be viewed.

#### Format




Fig. 11 Menu structure of the SIGMA CONTROL MOBIL

- |   |                        |   |                                       |
|---|------------------------|---|---------------------------------------|
| ① | Menu selection         | ④ | Navigation (menu)                     |
| ② | Display password level | Ⓐ | Display field size (white background) |
| ③ | Menu option list       | Ⓑ | Selection choice (grey background)    |

#### Menu selection

Selection	Menu	Sign	Description
1a	Main menu		Home page Display of machine data

## 4 Design and Function

### 4.8 List of menus

Selection	Menu	Sign	Description
1b	Settings menu		Parameter settings for machine data
1c	Controller menu		Not available to user. Password protected.
1d	Event memory		The following events (messages) are saved: <ul style="list-style-type: none"><li>■ Alarms,</li><li>■ warnings,</li><li>■ maintenance due.</li></ul>
1e	Fault memory		Display of alarms. An alarm shuts the machine down automatically.
1f	Maintenance memory		Display of maintenance due

Tab. 50 Menu selection

### Menu option list

Selection	Sign	Meaning
3a		Engine data
3b		Compressor unit data
3c		Parameter settings
3d		Messages
3e		Password
3f		Engine control unit (for Service personnel)
3g		Generator data (only machines with generators)

Tab. 51 Menu option list

### Navigation (menu)

Selection	Sign	Meaning	Key
4a		Menu option above	
4b		Menu option below	
4c		Key to confirm or change to the next menu option.	

Tab. 52 Navigation (menu)

### 4.8.1 SIGMA CONTROL MOBIL main menu

By selecting menu options from the main menu, the machine's current operating data can be viewed.

The data display consists of graphic symbols and parameter values (value + unit).

The graphic symbol can be made up of pictograms that together make up a logical meaning.  
Two machine parameters are shown on each display page.




Fig. 12 Machine data symbol

[M1]	Engine speed	[M7]	Battery
[M2]	Engine intake/turbo air	[V1]	Compressor (airend)
[M3]	Engine coolant	[A1]	Pressure
[M4]	Engine oil	[A2]	Temperature
[M5]	Fuel level	[A3]	Temperature high
[M6]	Operating hours counter	[A4]	Sensor

#### Example of a composed symbol

Indication	Symbol meaning	Parameter
4,6 bar	Engine oil + pressure = engine oil pressure	4.6 bar

Tab. 53 Symbolic display of engine oil pressure

#### Engine data

The engine operating data is presented on numerous display pages. With the aid of the arrow keys, one can page through the menu guide between the display pages.

The following data are shown:

Display page	Figure	Engine data
1. Page	4,6 bar 76 °C	Oil pressure Coolant temperature
2. Page	110,5 h 1000 U/min	Operating hours Speed
3. Page	65 % 25,5 V	Fuel level Battery voltage

Display page	Figure	Engine data
4. Page	 2,2 bar  23 °C	Turbo air pressure Turbo air temperature

Tab. 54 Engine data display

### Compressor data

The compressor unit operating data is presented on numerous display pages. With the aid of the arrow keys, one can page through the menu guide between the display pages.

The following data are shown:

Display page	Figure	Compressor unit data
1. Page	 88 °C  7,5 bar	Airend discharge temperature Pressure in the oil separator tank (OST)
2. Page	 7,5 bar 	Set pressure in the oil separator tank (OST)

Tab. 55 Display of compressor operating data

### 4.8.2 SIGMA CONTROL MOBIL settings menu

Selecting the hand symbol (table 50, item 1b) in the main menu will open the settings menu.

#### Password level

Entries and changes in the settings menu are only possible with the correct password.

The password level is reached by means of the "key" symbol in the individual menu views.



The password level is reset 3 minutes after the last key has been depressed. Temporary settings are not saved and are lost!

There are more than one password levels

Password level	Sign	Authorization
0		No password <ul style="list-style-type: none"> <li>■ Only user settings possible</li> </ul>
1		Renter password <ul style="list-style-type: none"> <li>■ Engine basic settings.</li> <li>■ Confirm maintenance carried out.</li> <li>■ Temporary pressure increase of 1.5 bar above working pressure.</li> </ul>

\* Maximum machine working pressure

Password level	Sign	Authorization
2	0→2	Customer service password <ul style="list-style-type: none"> <li>■ Engine basic settings.</li> <li>■ Confirm maintenance carried out.</li> <li>■ Release options.</li> <li>■ Temporary pressure increase of 1.5 bar above working pressure.</li> </ul>
3	0→3	Service password <ul style="list-style-type: none"> <li>■ All settings possible.</li> </ul>


\* Maximum machine working pressure

Tab. 56 Password level


Further information See chapter 7.5 for information on entering passwords.

### Operation

The following keys are used in the settings menu:

Sign	Key name	Location on the operating panel	Function
	«UP and DOWN» arrows	5	Navigation to parameters.
			
	«Horizontal arrows»	4	Change parameter value
	«Enter» key	7	Save settings.
	«esc» key	6	Interrupts an entry. Returns to menu.

Tab. 57 Menu guidance

**List of menus**

**Fig. 13 Symbolic settings menu**

- |            |   |           |  |
|------------|---|-----------|--|
| <b>E1b</b> | Settings menu   | <b>E5</b> | GSM/GPS module option (option illustrated as inactive, in preparation) |
| <b>E3</b>  | Navigation  | <b>E6</b> | Fuel pump option (illustrated as inactive)                             |
| <b>E1</b>  | Unit of temperature   | <b>E7</b> | Start-stop-automatic option (illustrated as inactive)                  |
| <b>E2</b>  | Unit of pressure  | <b>A</b>  | Display field size (white background)                                  |
| <b>E3</b>  | Controller settings (with key symbol, so long as the right password is not entered) | <b>B</b>  | Selection choice (grey background)                                     |
| <b>E4</b>  | Engine settings   |           |  |

**Unit of temperature**

The temperature unit is selected in the Temperature unit menu option **E1**.

Temperature can be displayed in the following units:

- °C
- °F
- K

**Unit of pressure**

The unit of pressure is selected in the pressure unit menu option **E2**.

Pressure can be displayed in the following units:

- bar
- psi

**Controller settings**

This menu option is not available to users. Changes in this menu option can only be made with the correct password.

**Engine settings**

Settings are made in the menu option "engine settings" **E4**.

This menu option is not available to users. Changes in this menu option can only be made with the correct password.

The following parameters can be set:

- Starter running time
- Cool-down run-on time of the engine (machine in IDLE).
- Engine speed LOAD speed.
- Engine speed IDLE speed.

#### Option ob "Start/stop/automatic" option

The symbol is stricken through if this option is not available on the machine. The menu option cannot be entered.

Changes to the parameter are made in the start/stop/automatic menu option [E8](#).

The following parameters can be changed:

- Run-on period under LOAD.
- Run-on period in IDLE.
- Manual or automatic operation (only in Service password level 3).

#### Option va "External fuel pump" option

The symbol is stricken through if this option is not available on the machine. The menu option cannot be entered.

By selecting the fuel pump menu option [E7](#) the fuel tank can be filled with an external pump.

### 4.8.3 SIGMA CONTROL MOBIL event memory

Selecting the **i** symbol (table 50, item [1d](#)) in the main menu will open the event menu menu option.




Fig. 14 Event memory

- |                      |                               |
|----------------------|-------------------------------|
| <a href="#">(1d)</a> | Event memory                  |
| <a href="#">(R1)</a> | Faults                        |
| <a href="#">(R2)</a> | Warnings                      |
| <a href="#">(R3)</a> | Maintenance                   |
| <a href="#">(R4)</a> | Machine data information page |

- |                      |                                       |
|----------------------|---------------------------------------|
| <a href="#">(R5)</a> | Fault memory                          |
| <a href="#">(3)</a>  | Navigation                            |
| <a href="#">(A)</a>  | Display field size (white background) |
| <a href="#">(B)</a>  | Selection choice (grey background)    |

The event memory is sub-divided into menu options:

Category	Short description	Sign	Note
Faults	R1		<p>The machine will be shut down.          The «Acknowledge »  key flashes.          The «Information» key  and «Stop» key  are illuminated.          If acknowledgement of the alarm by pressing the «Acknowledge »  key is possible, both lamps are extinguished.          The machine can only be restarted when the cause of the alarm is corrected.</p>
Warnings	R2		<p>The machine will not be shut down.          The «Acknowledge »  key flashes.          The «Information» key  illuminates.          These are extinguished by pressing the «Acknowledge »  key.          The «Information»  key remains illuminated, even after restarting, until the cause of the warning is rectified.</p>
Maintenance	R3		<p>The machine will not be shut down.          The «Acknowledge »  key flashes.          The «Information» key  illuminates.          These are extinguished by pressing the «Acknowledge »  key.          The «Information»  key remains illuminated, even after restarting, until the maintenance is carried out and the maintenance interval counter reset.</p>
Machine data information page	R4		<p>The following data are shown:</p> <ul style="list-style-type: none"> <li>■ Compressor model</li> <li>■ Pressure</li> <li>■ Speeds</li> <li>■ Equipment number</li> <li>■ Software version</li> </ul>
Fault memory	R5		<p>Display of the last 10 faults with</p> <ul style="list-style-type: none"> <li>■ fault code</li> <li>■ operating hours</li> </ul>

Tab. 58 Event memory outline



Selection keys are used to navigate through the event memory.

#### Make up of messages

The following illustrations show how typical examples of how individual message categories are produced.

#### Alarm message




Fig. 15 Event memory example: Alarm message

[R1] Event memory category: Alarm  
[R6] Message code

[R7] Operating hours since this occurred last time  
[R8] Symbolic fault location  
(example: coolant - temperature fault)

#### Warning messages




Fig. 16 Event memory example: Warning message

[R2] Message category: Warning  
[R6] Message code

[R7] Operating hours since this occurred last time  
[R8] Symbolic fault location  
(example: airend discharge temperature too high)

#### Maintenance message




Fig. 17 Event memory example: Maintenance message

[R3] Message category: Maintenance  
[R6] Message code

[R9] Time when maintenance is due.  
[RX] Maintenance interval

**Message code**

The key to the 4-character message code [R6] is as follows.




Fig. 18 Message code structure

- [a] Type of message
- [b] Location of occurrence
- [c] Key

The following table gives further information on message code structure.

Item	Position	Explanation
a	1. Position	Type of message <ul style="list-style-type: none"><li>■ 1 – Alarm</li><li>■ 2 – Maintenance</li><li>■ 3 – Warning</li></ul>
b	2. Position	Location of occurrence <ul style="list-style-type: none"><li>■ 1 – Engine</li><li>■ 2 – Compressor unit</li><li>■ 3 – Controller</li><li>■ 4 – General</li></ul>
c	3. and 4. positions	Key from 00 ... 99

Tab. 59 Message code structure

Further information See chapter 13.14 for a list of all SIGMA CONTROL MOBIL message codes.

## 4.9 Air treatment options

There follows a description of the possible air treatment options that may be fitted to the machine.




Fig. 19 Air treatment options

- |                                       |                                      |
|---------------------------------------|--------------------------------------|
| [1] Filter combination (option dd)    | [4] Heat exchanger (option db)       |
| [2] Cyclone separator (option da)     | [5] Breathing air filter (option dc) |
| [3] Compressed air cooler (option da) |                                      |

#### 4.9.1 Option da Air cooler

The aftercooler brings down the compressed air temperature to 5K to 10K above ambient. Most of the moisture carried in the compressed air is removed in this way.

#### 4.9.2 Option da Cyclone separator

Condensate accumulating during the air cooling process is separated, fed to the exhaust gas silencer and evaporated there.

#### 4.9.3 Option db Heat exchanger

The oil/air heat exchanger is fed with hot compressor cooling oil that warms the outgoing compressed air. This warm, dry compressed air is ideal for sand blasting, for example.

#### 4.9.4 Option dd Filter combination

The dried compressed air passes through a combination of prefilter and microfilter and emerges oil-free.

#### 4.9.5 Option dc Breathing air filter

Compressed air from an oil-injected compressor must not be used for breathing air. Dried compressed air must be filtered to remove all contaminants, such as fine dust and oil, as well as odours, before it can be used for breathing. To achieve this, the compressed air is passed through a combination of microfilter and activated carbon filter. The breathing air connector is specially marked; it is located separately on the compressed air distribution block.



#### DANGER

Danger of fatal injury from breathing arrest!

The filter does not remove CO/CO<sub>2</sub>, methane or other toxic gasses or vapours.

- Never use the machine in enclosed spaces, only in the open.
- Clean inlet air with no damaging contaminants.

#### 4.10 Option ba Low temperature equipment option

Special equipment is provided for operation in extremely low temperatures.

This equipment guarantees trouble-free operation in ambient temperatures from -25 °C to +50 °C. The electrical system starts the engine without problem at ambient temperatures down to -20 °C.

##### Option bb Coolant pre-heating

The engine coolant can be pre-heated to improve starting under cold conditions.

A separate mains power connection provides power to the coolant pre-heater. A flexible power cable joins the machine's power plug to the user's power socket.

The coolant pre-heater works according to the principle of self-circulation.

Option bb




Fig. 20 Coolant pre-heating

- ① Instrument panel  
② Connection for the coolant pre-heater

- ③ Engine block  
④ Coolant pre-heating

The ideal coolant pre-heating period is 2-3 hours before the machine is started. A pre-heating period of more than 3 hours is not necessary, as the maximum effect has already been achieved within this period (thermal balance).

## 4.11 Option ga Generator option

A generator is installed to provide a power supply to electrical consumers. The generator is driven from the engine by V-belts. A tensioning device automatically ensures optimum belt tension.

### 4.11.1 Operating modes

The compressor works with the normal air delivery regulation and generates electrical power at the same time.

The generator can work in two modes. These are selected by the mode switch:

- Automatic start
- Continuous load

Generator main switch	Mode selector switch	What is provided?
OFF	-	Compressed air
ON	Position 1 (automatic start)	Compressed air and electrical power
	Position 2 (continuous load)	Electrical power and compressed air

Tab. 60 Generator/compressor operation

Operating mode	Automatic start	Continuous load
Switch position	Position 1	Position 2
Engine speed	Electrical power takeoff > 100 VA automatic maximum speed	Permanent maximum speed (engine under full load)
	Power takeoff less than minimum: Engine run-on time of approximately 2 minutes at maximum speed	
Advantages	Fuel saving Constant oscillation between maximum and minimum speed avoided	Continuous generator power available without delay

Tab. 61 Generator operating modes

### 4.11.2 Operating controls

The switches, fuses and outlet sockets for electrical consumers are located on the generator control box. Individual consumers are connected only by these outlet sockets.




Fig. 21 Generator instrument panel - control box, 400 V, 3-phase

- |                              |   |
|------------------------------|---|
| ① «Mode selector switch»     | ④ Generator control box                       |
| ② Three-phase power sockets  | ⑤ «Generator main switch»                     |
| ③ Single-phase power sockets | ⑥ «Safety cut-out» (with overcurrent release) |




Fig. 22 Generator instrument panel - control box, 230 V, 3-phase

- |                               |   |
|-------------------------------|---|
| ① «Mode selector switch»      | ⑤ Generator control box                       |
| ② 3-phase power sockets, 32 A | ⑥ «Generator main switch»                     |
| ③ Single-phase power sockets  | ⑦ «Safety cut-out»                            |
| ④ 3-phase power sockets, 16 A | ⑧ «Safety cut-out» (with overcurrent release) |

#### 4.11.3 Note when operating the generator

##### Take note before switching in the generator:

When the network is fully loaded:

- The power consumption values of simultaneous consumers are added.
- The maximum continuous loading on the generator by connected consumers is limited by safety cut-outs.

**To be observed before connecting consumers****DANGER**

Devices start automatically without warning.

Serious injury and damage to property is possible.

- Make sure that electric consumers are switched off.

Pay particular attention to the following:

- Read the technical specification for the generator before connecting voltage-sensitive equipment.
- Check that electric consumers and their connecting cables are in perfect condition.
- Plug in and switch on consumers one-by-one.
- Consumers with unfavourable on/off characteristics (e.g. high starting current) should be started first.

Do not exceed the rated current for each outlet socket so as not to overload the generator.

**Take note before switching off the generator**

- Switch off electrical consumers and unplug them one-by-one.
- Switch off consumers drawing the highest current last.
- Check that the protective covers on the power sockets are correctly closed.
- Run the engine for a further 2 minutes after switching off the generator to allow the generator to cool down.

## **4.12 Option sa, sc, sd, sh, si Transport options**

### **4.12.1 Option sa Chassis**

The chassis has the following features:

- Single-axle
- Rubber-sprung axle
- Height-adjustable towbar

### **4.12.2 Option sd Chassis**

The chassis has the following features:

- Single-axle
- Rubber-sprung axle
- Fixed height towbar

### **4.12.3 Option sh Chassis**

The chassis has the following features:

- Single-axle

- Rubber-sprung axle
- Fixed height towbar
- without parking brake

**4.12.4 Option sc****Stationary frame**

The frame has the following features:

- Skids
- Use as stationary machine
- Mounted on truck/trailer platform

**4.12.5 Option si****Stationary frame**

The frame has the following features:

- Frame
- Use as stationary machine
- Mounted on truck/trailer platform

**4.13 Option sg****Pedestrian protection option**

The machine is provided with pedestrian protection that functions both as a deflector and against pedestrians being run-over.

## 5 Installation and Operating Conditions

### 5.1 Safety

- Strictly forbid fire, open flame and smoking.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting fuel or oil vapours or parts of the machine.
- The machine is not explosion-proof!  
Do not operate in areas in which specific requirements regarding explosion protection are in force. For instance, the requirements of ATEX directive 94/9/EC "Equipment and Protective Systems intended for use in Potentially Explosive Atmospheres".
- Ensure that required ambient conditions are maintained with regard to:
  - ambient temperature,
  - clean inlet air with no damaging contaminants,
  - inlet air free of explosive or chemically unstable gases or vapours,
  - inlet air free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulphide.
- Keep suitable fire extinguishing agents ready for use.

### 5.2 Positioning conditions

Precondition The ground at the machine's location must be level, firm and able to take the machine's weight (not more than 15° inclination in any direction).




Fig. 23 Minimum distance from excavations/slopes and walls

1. Keep sufficient distance (at least 1.5 m) from the edges of excavations and slopes.
2. Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.



#### CAUTION

Danger of burning from build up of heat and hot exhaust.

Insufficient distance from a wall may well cause heat build-up that could damage the machine.

- Do not position the machine directly against a wall.
- Ensure always sufficient ventilation space around the machine.

3. Position the machine as far as possible from any wall.
4. Ensure there is enough free space around and above the machine.
5. Keep air inlet and outlet openings free of obstructions so that the cooling air can flow freely through the machine.

6. Do not allow wind to blow into the cooling air outlet.
7. Do not allow exhaust gases and heated cooling air to be drawn into the compressor.
8. Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.

**CAUTION**

Ambient temperature too low!

Frozen condensate and highly viscous engine or compressor cooling oil can cause damage when starting the machine.

- Use winter grade engine oil.
- Use low viscosity compressor cooling oil.

9. At ambient temperatures below 0 °C, follow instructions in chapter 7.9.

## 6 Installation

### 6.1 Safety

Follow the instructions below for safe installation.

Warning instructions are located before a potentially dangerous task.

#### Basic safety instructions

1. Follow the instructions in chapter "Safety and Responsibility".
2. Installation work may only be carried out by authorized personnel.

Further information	Information on authorized personnel are found in chapter 3.4.2. Information on dangers and their avoidance are found in chapter 3.5.
---------------------	---

### 6.2 Reporting Transport Damage

1. Check the machine for visible and hidden transport damage.
2. Inform the carrier and the manufacturer in writing of any damage found.

### 6.3 Option sa Fitting the towbar

If the machine is shipped on a transport frame, it is necessary to dismantle the towbar to save space. The towbar must be re-assembled before removing the transport frame.

Material	Protective gloves Wrench Hard rubber hammer
Precondition	The machine is standing firm and level. The machine is switched off.



#### CAUTION

Danger of pinching!


Severe injury to fingers is possible if they become trapped in the adjusting mechanism.

- Always wear protective gloves.
- Work with caution.

## 6 Installation

### 6.4 Adjusting the chassis

Option sa




06-M0782

Fig. 24 Fitting the towbar

- |     |                           |     |                                 |
|-----|---------------------------|-----|---------------------------------|
| [1] | Overrun braking mechanism | [4] | Locking lever with securing pin |
| [2] | Handle                    | [5] | Parking brake lever             |
| [3] | Tie bar                   | [6] | Fixing bolt and nut             |

Option sa



06-M0785

Fig. 25 Fitting the towbar

1. Remove all transport securing items (duct tape, foam pads) from the towbar components.
2. Undo the self-locking nut and remove the tie bar fixing bolt.
3. Bring the overrun braking mechanism into the horizontal position.
4. Push the tie bar end between the cheeks of the overrun braking mechanism and align the fixing holes.
5. Push in the securing bolt, using light hammer blows if necessary.
6. Secure the bolt with the self-locking nut (see chapter 2.4.4 for tightening torque).
7. Take off the parking brake by pushing the lever down.
8. Pull out the securing pin and unscrew the locking lever to the stop.
9. Use the positioning handle to push the towbar to the required height.
10. Tighten the locking lever. Make sure the teeth in the adjustment joint mesh together.
11. Fully tighten the lever with a few hammer blows and insert the securing pin.
12. Pull on the parking brake again.


### 6.4 Adjusting the chassis

Material Pliers

Hard rubber hammer

Precondition The machine is shut down.

The machine is disconnected from the towing vehicle and safely parked.

**6.4.1 Option sa**
**Adjusting the towbar height**


06-M0016

Fig. 26 Towbar height adjustment

- ① Locking lever
- ② Securing pin
- ③ Handle

1. Pull out the securing pin and unscrew the locking lever to the stop.


**CAUTION**

Danger of pinching!

Severe injury to fingers is possible if they become trapped in the adjusting mechanism.

- Always wear protective gloves.
- Work with caution.

2. Adjust the towbar with the handle until it is horizontal with the coupling on the towing vehicle and parallel to the ground.

The centre-piece can be moved up to 50° upwards and 10° downwards for height adjustment.

The parallel tie bar ensures that the overrun braking mechanism stays horizontal (Fig. 26).

3. Tighten the locking lever again and secure by striking with a hard rubber hammer.

4. Replace the securing pin.

5. Check if:

- The teeth in the adjustment joint are fully engaged.
- The locking lever is tight.
- The securing pin is in place.

6. Tighten the locking lever again after 50 km.



The teeth in the adjustment joint will not disengage. The teeth are corroded together.

- Free the teeth by jerking the towbar horizontally and vertically.

**6.4.2 Changing the towing eye**

The towbar can be fitted with various towing eyes or couplings.

## 6 Installation

### 6.4 Adjusting the chassis

Material	Protective gloves Hexagon wrench Thin metal rod
Precondition	The machine is shut down. The machine is disconnected from the towing vehicle and safely parked.


**CAUTION**

Danger of pinching!

Severe injury to fingers is possible if they become trapped in the adjusting mechanism.


- Always wear protective gloves.
- Work with caution.

- Ascertain which towbar is fitted to the machine.

**6.4.2.1 Option sa**
**Changing the towing eye on a height-adjustable towbar**

The following alternative tasks must be carried out to change the towing eye or coupling.

Option sa



06-M0017

Fig. 27 Changing the towing eye (height-adjustable towbar)

- |                              |                       |
|------------------------------|-----------------------|
| [1] Self-locking hexagon nut | [4] Protective sleeve |
| [2] Hex-head bolt            | [5] Ball coupling     |
| [3] Towbar tube              | [6] Towing eye        |

Remove the ball coupling	Remove the towing eye.
1. Unscrew the nuts [1] and withdraw the fixing bolts [2]. 2. Remove the coupling [5] from the towbar tube [3].	1. Push back the protective sleeve [4]. 2. Unscrew the nuts [1] and withdraw the fixing bolts [2]. 3. Remove the towing eye [6] from the towbar tube [3].

## 6 Installation


### 6.4 Adjusting the chassis

Fitting the ball coupling	Fitting the towing eye
<ol style="list-style-type: none"> <li>Slide the coupling <b>5</b> onto the towbar tube.</li> <li>Position the various parts so that the bolts can be freely inserted.</li> <li>Insert the bolts <b>2</b> and secure with the self-locking nuts <b>1</b>.</li> </ol>	<ol style="list-style-type: none"> <li>Slide the towing eye <b>6</b> into or onto the towbar tube <b>3</b>.</li> <li>Position the various parts so that the bolts can be freely inserted.</li> <li>Insert the bolts <b>2</b> and secure with the self-locking nuts <b>1</b>.</li> <li>Draw the protective sleeve <b>4</b> over the fixings.</li> </ol>

#### 6.4.2.2 Option sd, sh

##### Changing the towing eye on a fixed height towbar


Option sd



06-M0018

Fig. 28 Changing the towing eye (fixed height towbar, GB chassis version)

Option sh



06-M0323

Fig. 29 Changing the towing eye (fixed height towbar, USA chassis version)

- |          |                           |          |                   |
|----------|---------------------------|----------|-------------------|
| <b>1</b> | Self-locking hexagon nut  | <b>5</b> | Towbar tube       |
| <b>2</b> | Hex-head bolt             | <b>6</b> | Protective sleeve |
| <b>3</b> | Shock absorber fixing eye | <b>7</b> | Ball coupling     |
| <b>4</b> | Shock absorber            | <b>8</b> | Towing eye        |

- Push back the protective sleeve **6**.

## 6 Installation

### 6.4 Adjusting the chassis

2. Unscrew the nuts **1** and withdraw the fixing bolts **2**.
3. Remove the ball coupling **7** or towing eye **8** from the towbar tube **5**.
4. Slide the new coupling **7** or towing eye **8** into or onto the towbar tube **5**.
5. Position the various parts so that the bolts can be freely inserted.
6. Push the bolts **2** through the front of the two holes in the eye **8** or coupling **7** and fix with the self-locking nuts **1**.



In order to insert the rear bolt, the delayed release of the compressed shock absorber is used. During the delayed return stroke, a suitable metal rod is pushed through the holes as they line up to hold them in place.

7. Push heavily against the towing eye **8** or coupling **7** to depress the overrun brake.
8. Pull the coupling and the towbar tube forward quickly and insert a suitable thin metal rod through the rear fixing hole **3** and the shock absorber's fixing eye **4**.
9. Insert the bolt **2** through the hole in the coupling/eye and the blocked fixing eye **3** of the shock absorber **4**. At the same time, pull out the metal rod again. Secure the bolt **2** with the self-locking nut **1**.
10. Tighten the nuts.
11. Draw the protective sleeve **6** over the fixings.

#### Checking the overrun braking mechanism

- Push the towbar tube in and out by hand.  
If resistance is felt, the shock absorber is properly connected.

## 7 Initial Start-up

### 7.1 Safety

Here you will find instructions for safe commissioning of the machine.  
Warning instructions are located before a potentially dangerous task.

#### Basic safety instructions

1. Follow the instructions in chapter "Safety and Responsibility".
2. Commissioning work may only be carried out by authorized operating and maintenance personnel.

Further information Information on authorized personnel are found in chapter 3.4.2.  
Information on dangers and their avoidance are found in chapter 3.5.

### 7.2 Instructions to be observed before commissioning or recommissioning



The initial start-up of every machine takes place at the factory. Every machine is also given a trial run and passes a careful check.

Incorrect or improper commissioning can cause injury to persons and damage to the machine.

- Commissioning may only be carried out by authorized installation and service personnel who have been trained on this machine.
- Remove all packing materials and tools on and in the machine.
- Observe the machine during the first few hours of operation to ensure that it is operating correctly.

### 7.3 Checking installation and operating conditions

- Check and confirm all the items in the checklist before starting the machine.

Function	See chapter	Confirmed?
➢ Are the operators fully conversant with safety regulations?	-	
➢ Have all the positioning conditions been fulfilled?	5	
➢ Is there sufficient cooling oil in the separator tank?	10.5.1	
➢ Is there sufficient oil in the engine?	10.4.4	
➢ Is the maintenance indicator on the air intake filters (engine and compressor) OK?	10.4.2, 10.5.7	
➢ Is there sufficient coolant in the coolant expansion tank?	10.4.1	
➢ Is there sufficient fuel in the fuel tank?	-	
➢ Fuel prefilter water trap emptied?	10.4.3	
➢ Are the access doors closed and all body panels in place?	-	
➢ Are the tyre pressures OK?	-	

Tab. 62 Installation and operating conditions checklist

## 7.4 Setting the displayed units

The following units can be changed:

- Unit of temperature
- Unit of pressure



The unit must only be set once and all displays are adjusted accordingly. The settings remain when the controller is switched off.

Precondition Controller switched on

Select <Main menu => settings => unit settings>.

### Setting the unit of temperature

The temperature unit is selected in the Temperature unit menu option [E1].




Fig. 30 Temperature display setting

- |                                       |   |
|---------------------------------------|---|
| [E1] Unit of temperature setting menu | [3] Navigation                            |
| [T1] Display unit °C (selected)       | [A] Display field size (white background) |
| [T2] Display unit °F                  | [B] Selection choice (grey background)    |
| [T3] Display unit K                   |   |



1. Use the «UP» and/or «DOWN» arrow keys to select the required unit.
  2. Press «Enter» .
- The setting is saved.
3. Press «esc» .

Result The display changes to show the operating mode.

### Setting the unit of pressure

The unit of pressure is selected in the pressure unit menu option [E2].




Fig. 31 Unit of pressure setting

- |                                    |   |
|------------------------------------|---|
| [E2] Unit of pressure setting menu | [3] Navigation                            |
| [D1] Display unit bar (selected)   | [A] Display field size (white background) |
| [D2] Display unit psi              | [B] Selection choice (grey background)    |

1. Use the «UP» and/or «DOWN» arrow keys to select the required unit.
2. Press «Enter» .
- The setting is saved.
3. Press «esc» .

Result The display changes to show the operating mode.

## 7.5 Entering a password

No password is set when the machine is delivered.

- - Password level 0

The following password is required to make entries and changes in the settings menu:

- — Password level 1 (renter password): **4512**

The following displays will require you to enter the password:




Fig. 32 Waiting for password entry

The cursor flashes at the position for the first letter of the password.

1. Keep on pressing the «DOWN» or «UP» key until the required character appears.
2. Use «RIGHT» to move the cursor to the position of the second letter.
- The cursor flashes in the position for the next letter of the password.
3. Set the remaining characters of the password until it is complete.
4. Confirm the password with «Enter» .

The activated password is displayed. (see example in figure 33).




Password is not activated - incorrect password.

- Re-enter the password.



The cursor can be moved «LEFT» or «RECHTS» to overwrite and incorrect entries.



07-M0867

Fig. 33 Password level 1 activated.

1. Correct the password.
2. Confirm the correct password with «Enter» .

The activated password is displayed.



The password level is reset 3 minutes after the last key has been depressed. Temporary settings are not saved and are lost!

Passwords for other levels are entered in the same way.

## 7.6 Engine settings

This menu option is not available to users. Changes in this menu option can only be made with the correct password.

The following parameters can be changed:

- Starter running time (renter, password level 1).
- Engine cool-down period in unloaded run-on (renter, password level 1).

The following parameters can only be set by Service Technicians.

- EngineLOAD speed (password level 3).
- EngineIDLE speed (password level 3).



LOAD and IDLE speeds can be temporarily changed for service purposes or necessary tests. These changes are not saved and are lost when the controller is switched off.

Precondition      Controller switched on  
*<main menu => settings => engine settings> selected.*




Fig. 34 Engine settings menu

- [E4] Engine settings menu
- [U1] Starter running time setting
- [U2] Cool-down period setting
- [U3] IDLE speed setting

- [U4] IDLE speed setting
- [3] Navigation (menu)
- [A] Display field size (white background)
- [B] Selection choice (grey background)

#### Starter running time setting

The starter running time can be set between 15 and 45 seconds.

1. Use the «UP» and/or «DOWN» arrow keys to select starter running time setting [U1].
2. Press «RIGHT» and/or «LEFT» keys to select the required time.
3. Press «Enter» .
4. The setting is saved.
4. Press «esc» .

**Result** The display changes to show the operating mode.

#### Cool-down period setting

When the «Stop» key is pressed, the machine switches to unloaded run-on and stops when the set period has expired.

The COOL-DOWN PERIOD can be set between 30 and 300 seconds.

1. Use the «UP» and/or «DOWN» arrow keys to select cool-down period setting [U2].
2. Press «RIGHT» and/or «LEFT» keys to select the required time.
3. Press «Enter» .
4. The setting is saved.
4. Press «esc» .

**Result** The display changes to show the operating mode.

#### Setting the engine LOAD speed.

1. Use the «UP» and/or «DOWN» keys to select LOAD speed setting [U3].
2. Press «RIGHT» and/or «LEFT» keys to select the required speed.

3. Press «Enter» .

The setting is saved.

4. Press «esc» .

The display changes to show the operating mode.



This setting is only temporary and is lost when the controller is switched off.

#### **Setting the engine IDLE speed.**

1. Use the «UP»  and/or «DOWN»  keys to select IDLE speed setting **U4**.

2. Press «RIGHT»  and/or «LEFT»  keys to select the required speed.

3. Press «Enter» .

The setting is saved.

4. Press «esc» .

The display changes to show the operating mode.



This setting is only temporary and is lost when the controller is switched off.

## **7.7 Option ob**

### **Changing the parameters of the start/stop/automatic option**

The following parameters can be changed:

- Run-on period under LOAD.
- Run-on period in IDLE.
- Manual or automatic operation (Service password level 3).




The length of the warm-up period, between starting and switching to LOAD, cannot be changed.

The controller switches the machine to LOAD as soon as the airend discharge temperature reaches 40 °C.

Precondition Controller switched on

*<Main menu => settings => options => start-stop-automatic > selected.*



07-M0356

Fig. 35 Settings in start/stop/automatic

- |  |   |
|--|---|
| [E7] Settings menu start/stop/automatic                        | [3] Navigation and settings               |
| [S1] Run-on under load   | [A] Display field size (white background) |
| [S2] Unloaded run-on   | [B] Selection choice (grey background)    |
| [S3] Manual or automatic operation (Service password level 3). |   |

#### Setting run-on under load

1. Use the «UP» and/or «DOWN» arrow keys to select run-on under load [S1].
  2. Press «RIGHT» and/or «LEFT» keys to select the required time.
  3. Press «Enter» .
- The setting is saved.
4. Press «esc» .
- The display changes to show the operating mode.

#### Unloaded run-on setting

1. Use the «UP» and/or «DOWN» arrow keys to select unloaded run-on [S2].
  2. Press «RIGHT» and/or «LEFT» keys to select the required time.
  3. Press «Enter» .
- The setting is saved.
4. Press «esc» .
- The display changes to show the operating mode.

## 7.8 After storing the machine for a long period

- Carry out the following before every re-commissioning after a long period of storage.

Storage period longer than	Remedy
5 months	<ul style="list-style-type: none"><li>➤ Remove the desiccant from the openings in the air intake filters of the engine and compressor.</li><li>➤ Check the air and oil filters.</li><li>➤ Drain the preserving oil from the separator tank.</li><li>➤ Fill with cooling oil.</li><li>➤ Drain the preserving oil from the engine.</li><li>➤ Fill with engine oil.</li><li>➤ Check the engine coolant</li><li>➤ Check the battery charge.</li><li>➤ Re-connect the battery (batteries).</li><li>➤ Check all fuel lines, engine oil lines and compressor cooling oil lines for leaks, loose connections, wear and damage.</li><li>➤ Clean the bodywork with a grease and dirt cleansing agent.</li><li>➤ Check the tyre pressures.</li></ul>
36 months	<ul style="list-style-type: none"><li>➤ Have the overall technical condition checked by an authorized KAESER Service Technician.</li></ul>

Tab. 63 Measures for re-commissioning the compressor after a long period of storage

## 7.9 Low-temperature operation (winter)

The machine's electrical equipment is designed for starting at ambient temperatures as low as  $-10^{\circ}\text{C}$ .

- At temperatures below  $0^{\circ}\text{C}$  use:
- winter-grade engine oil,
  - low viscosity cooling oil for the compressor,
  - winter-grade diesel fuel



Use air hoses that are as short as possible under extremely cold conditions.

### 7.9.1 Starting assistance

If the machine's starter batteries are discharged, it can be started with the batteries of another vehicle or engine-driven machine.

Material Jumper cables

Precondition The machine is disconnected from the towing vehicle and safely parked.


**DANGER**

Fire and explosion hazard.

High currents caused by short-circuited battery. Shorted batteries can catch fire or explode.

Battery casing may crack and allow acidic fluid to spray out.

- Observe the instructions provided with the battery jumper cables.
- Do not connect the battery jumper cables to the negative pole of the discharged battery or to the bodywork of the machine.
- Work with caution.



07-M0002

Fig. 36 Jumper cable connection diagram

[a]	Assisting vehicle batteries	[2]	Positive (+) terminal of the machine batteries
[b]	Machine batteries	[3]	Bare metal point on the engine block (earth)
[1]	Positive (+) terminal of the assisting vehicle	[4]	Negative (-) terminal of assisting vehicle batteries

- Follow the safety rules when dealing with batteries:
  - Connect batteries of the same voltage only.
  - The assisting vehicle and machine to be started must not touch.
  - Do not bend over the batteries when attaching jumper cables.
  - Only use battery jumper cables of sufficient cross-sectional area and with insulated terminal clamps.
  - Observe the instructions provided with the battery jumper cables.
  - Keep jumper cables away from rotating parts.
  - Do not attempt to start the machine if its batteries are frozen. Allow the batteries to thaw first.
  - Do not try to start the machine with a boost charger.

**Connecting the battery jumper cables**

1. Stop the engine of the assisting vehicle.
2. Switch off all power consumers.
3. Connect positive terminals [2] and [1].

**DANGER**

Explosion hazard!

A spark may ignite an explosive gas mixture.

- Do not, under any circumstances, connect the minus terminal of the assisting vehicle to the negative terminal of the battery in the machine to be started.  
This can cause sparks when connecting and disconnecting.
- Work with caution.

4. Connect the minus terminal of the assisting battery ④ to a bare metal point on the compressor engine to be started ③ as far away from the battery as possible.

**Starting the engine**

Precondition «Battery isolating switch» on.

1. Start the engine of the assisting vehicle and run at high speed.
2. Start the compressor engine.



Let the two engines run for approximately 3 minutes.

**Disconnecting the battery jumper cables**

1. Stop the engine of the assisting vehicle.
2. Disconnect the jumper cables in the reverse order, first negative (-) then positive (+).



If the compressor engine stops as soon as the cables are disconnected, it can mean serious damage to the alternator or battery and it should be handed over to a specialised workshop.


**7.9.2 Option ba****Starting up low-temperature equipment**

Option bb **Coolant pre-heating**

The engine coolant can be pre-heated to improve starting under cold conditions.

The connection for the mains supply is located on the machine's instrument panel.

Option bb



07-M0287

**Fig. 37 Coolant pre-heating**

- |  |   |
|--|---|
| <span style="border: 1px solid black; padding: 2px;">1</span> Instrument panel<br><span style="border: 1px solid black; padding: 2px;">2</span> Connection for the coolant pre-heater<br><span style="border: 1px solid black; padding: 2px;">3</span> Power cable | <span style="border: 1px solid black; padding: 2px;">4</span> Coolant pre-heating<br><span style="border: 1px solid black; padding: 2px;">5</span> Engine block |
|--|---|


**DANGER**

Danger of fatal injury from electric shock!

Serious injury or death can result from a short-circuit in the electric coolant pre-heater.


- The power cable for the coolant pre-heater may only be plugged into an electrical socket fitted with a protective earth.
- Connect the coolant pre-heater to the user's power socket with the power cable supplied.

## 7.10 Option ga

### Putting the generator into operation

The generator can be operated without an earth.

Test the insulation monitoring daily with the engine running before putting the generator into operation.



07-M0003

**Fig. 38 Insulation monitoring - 400 V, 3-phase generator**

## 7 Initial Start-up

### 7.10 Putting the generator into operation




Fig. 39 Insulation monitoring - 230 V, 3-phase generator

- |   |  |
|---|--|
| [1] «Main switch»   | [4] «Overload protection» switch functioning as safety cut-out with overcurrent release; «mains contactor» |
| [2] «Mode selector switch»  |  |
| [3] Test button with <i>earth-leak</i> warning lamp for «insulation monitoring» | [5] Three-phase power sockets  |
|   | [6] Single-phase power sockets   |

1. Put the machine into operation.



**DANGER**

There is danger of fatal injury caused by contact with live components.

- The generator may only be used if the overload protection switch tripped during the test.

2. Check the insulation monitor according to instructions.



Checking instructions are given on the label stuck on the generator control box.

**DANGER!**

**Electrical power.**

There is danger of fatal injury caused by contact with live components.

- Test the mains contactor each day while the machine is running.
- The generator may only be operated if the mains contactor is functioning correctly.

Checking the mains contactor

- «Mains contactor» [4] for generator switching.
- Press and hold the «test button» [3] for 3 seconds.

The «mains contactor» [4] trips out.

Problem: The «mains contactor» does not trip out?

- Shut down the generator and call KAESER Service.

Tab. 64 Test instructions for a generator with an insulation monitoring

## 8 Operation

### 8.1 Safety

Here are to be found instructions to ensure safe operation of the machine.

Warning instructions are located before a potentially dangerous task.

#### Basic safety instructions



##### WARNING

There is danger of injury from hot, rotating and electrically live components!  
Serious injury can be caused by touching such components.

- Operate the machine only with closed doors/canopy.
- Shut down the machine before opening any doors/canopy.
- Do not carry out any checks or settings while the machine is running.


Follow the instructions in chapter 'Safety and Responsibility'.

Details of authorized personnel are found in chapter 3.4.2.

Details of dangers and their avoidance are found in chapter 3.5.

### 8.2 Starting and stopping

Precondition No personnel are working on the machine.



08-M0363

Fig. 40 Starting instruments

- |     |  |      |                         |
|-----|--|------|-------------------------|
| [1] | Instrument panel cover<br>with sticker giving brief instructions | [6]  | «Quick-stop pushbutton» |
| [2] | Compressed air outlet pressure gauge                             | [7]  | «Stop» key              |
| [3] | Controller SIGMA CONTROL MOBIL                                   | [8]  | «Start» key             |
| [4] | «Controller on» switch   | [9]  | «Load» key              |
| [5] | Fuel gauge   | [10] | Display                 |

#### 8.2.1 Follow the brief instructions

Brief instructions containing symbolic information on starting and stopping is stuck to the inside of the instrument panel cover.




Fig. 41 Brief instructions on starting and stopping

- ① Starting sequence
- ② Shutdown sequence

➤ Open the instrument panel cover and follow the instructions stuck to the inside.



Each step explained in full.

#### 8.2.2 Commissioning the machine




Fig. 42 «Battery isolating switch»

- ① «Battery isolating switch»
- I – on
- 0 – off

1. Open the left-hand door.
2. Switch the «battery isolating switch» on.  
The battery is now connected to the machine's electrical system.
3. Close the access door.  
The machine can now be started.

### 8.2.3 Starting the engine



#### CAUTION

Serious damage to the engine from cold starting sprays!

Cold-start assists, such as ether or other sprays, can cause severe engine damage.

- Do not use cold start sprays.

1. Open the control panel cover.
2. Switch on the «Controller».
  - The controller boots up and the front page is displayed.
  - If the temperature is below zero, the engine control unit will switch on engine pre-heating.
  - If no existing message are displayed (see chapter 4.7, table 44) the display changes to operating data and shows ready to start.
  - The «Start» key ① flashes.
3. Press the «Start» key ①.
  - The engine starts and runs in IDLE until the following conditions are fulfilled:
    - The airend discharge temperature (ADT) reaches 30 °C.
    - The engine coolant temperature (ECT) reaches 30 °C.
  - When the ADT or ECT reaches 30 °C, the machine can be switched to LOAD.
  - The «Start» key ① illuminates and the «Load» key ② flashes.
4. Press the «Load» key ②.
  - The machine switches to LOAD and is ready to deliver compressed air.
  - The «Load» key ② illuminates.
    - If the «Load» key ② is pressed before the ADT or ECT reaches 30 °C the engine continues to run at IDLE speed. The controller switches automatically to LOAD when these temperature limits are reached.
    - If the starting sequence fails or is interrupted by pressing the «quick stop» key, the re-start inhibit is activated for 20 seconds. The display shows the remaining time before another start can be attempted.

Further information See chapter 4.7.2 for the operating sequence of the SIGMA CONTROL MOBIL.

### 8.2.4 Setting the output pressure

The output pressure is set from the instrument panel.

Setting is in increments of 0.1 bar and shown as a scale on the display.

The output setting menu option can be reached in two ways:

- Quick entry
- Entry via the menu structure

#### Quick entry

Precondition LOAD

<Main menu> (operating mode display) selected

## 8 Operation

### 8.2 Starting and stopping

- Press either «LEFT» or «RIGHT» .
- This immediately selects the output setting menu.

#### Entry via menu structure

Precondition

LOAD

<Main menu => engine operating data – compressor> selected.

Enter the output pressure in the sub-menu "set pressure in oil separator tank"




Fig. 43 Select menu option "set pressure in the oil separator tank"

- ①a Main menu
- ②b Compressor unit data
- ③ Navigation (menu)

1. Select the compressor data symbol and confirm with «Enter» .
  2. Select menu option "set pressure in the oil separator tank"
- This immediately selects the output setting menu.

#### Set pressure:



The pressure can only be set at lower than the nominal working pressure of the machine. A pressure setting 1.5 bar higher than nominal is possible with the appropriate password. This can only be temporary and falls back to nominal if no key is pressed for 3 minutes or if the controller is switched off.




Fig. 44 Setting the output pressure

- |   |  |
|---|--|
| ④ Select menu option "set pressure in the oil separator tank" | ⑦ Maximum working pressure (upper setting limit) |
| ⑤ Minimum working pressure (lower setting limit)              | ⑧ Current setting                                |
| ⑥ Setting scale with indicator bar                            |  |

- Use «RIGHT» and/or «LEFT» to select the output pressure and check on the instrument panel pressure gauge.



The set pressure is saved when leaving the setting menu option.

- Press «esc» .

The display changes to show the operating mode.

### 8.2.5 Shutting down the machine

**CAUTION**

Thermal overload of the turbo charger.

Abrupt stopping of the engine under load can cause a fault or damage to the turbo charger.

- Run the engine a few minutes in idle before shutting down to allow the turbo charger to cool.

#### Operating the machine in the cool-down phase

- Press and hold the «Stop» key for longer than one second.
  - The machine switches to unloaded run-on, i.e. the engine runs at IDLE speed and the oil separator tank is vented.
  - When the cool-down period has elapsed (engine setting "unloaded run-on") the machine has cooled enough so that the engine can stop automatically.



- The controller display shows *back pressure* if the pressure in the oil separator tank is still > 1 bar.
- When the machine is fully vented, the display changes to *ready to start*.
- When the OST is fully vented after shutdown, the re-start inhibitor is activated and is indicated by the timer counting down from 20 seconds.

#### Shutting down the machine



If the machine is not to be used again, the «battery isolating switch» should be switched off.

**CAUTION**

Danger of short circuit

Damage to the machine electrics is possible.

- Use the «battery isolating switch» only when the machine is at standstill.
- Do not use the «battery isolating switch» as a main or emergency switch.

1. Switch off the «controller».
2. Open the left-hand door.
3. Switch off the battery «battery isolating switch» when the instrument panel display is no longer illuminated.

The battery is disconnected from the machine's electrical system.
4. Close the «compressed air outlet valves» on the air distributor.
5. Close the operating panel cover and all doors. Lock if necessary.

### 8.2.6 Shutting down in an emergency

Stop the machine in case of danger by pressing the «Quick stop» button.



Use the «Quick stop» button to stop the machine only in emergencies.

#### Quick shutdown

- Press the «Quick-stop» button.
  - The engine stops immediately.
  - The «Quick stop» button remains latched in after being pressed.
  - The re-start inhibitor is activated (20 seconds).
  - The «Information» key and «Stop» key are illuminated.
  - The «Acknowledge» key flashes.

#### Put the machine back into operation

When the fault has been cleared, the machine must be reset.

Precondition The fault has been rectified.

- Unlatch the «Quick-stop» button.
- Confirm the message with the «Acknowledge» key.  
The «Information» key, «Stopp» key and «Acknowledge» key are illuminated.  
The machine can now be started again.

## 8.3 Setting parameters

Parameter setting and changing takes place in the controller settings menu.

- Select *<Main menu => setting>*.
- See chapter 4.8.2 for using the settings menu.
- Some menu options are password protected.

1. Use the «UP» and/or «DOWN» keys to navigate to the menu option containing the parameter to be set.
2. Use the «RIGHT» and/or «LEFT» key to set the required parameter value.
3. Confirm and save the setting with «Enter» .



Every action can be cancelled with the «escape» key .

## 8.4 Acknowledging alarm, warning and maintenance messages

Information from the controller is interpreted as displayed messages.

The message is stored in the event memory at the same time.



See chapter 4.8.3 for further information on the event memory.

#### Acknowledging alarm messages

An alarm message is displayed and:

- the machine is shut down and cannot be restarted,
- The «Information»  and «Stop»  keys are illuminated.
- The «Acknowledge»  key flashes.

Precondition Alarm rectified

- Confirm the message with the «Acknowledge»  key.

The «Information»  and «Stop»  and «Acknowledge»  keys are illuminated.

#### Acknowledging warning and maintenance messages

A fault warning message or notification of maintenance due is displayed, and:

- The «Information»  key illuminates,
- The «Acknowledge»  key flashes.

Precondition The cause of the warning is rectified

Maintenance is carried out

- Confirm the message with the «Acknowledge»  key.

The «Acknowledge»  key is extinguished but the «Information»  key is still illuminated.



The «Information» key  continues to be illuminated when the machine is restarted until the fault is rectified or maintenance carried out.

Maintenance acknowledgement is only possible with a password.

#### Resetting maintenance interval counters

Each maintenance interval counter must be separately reset. Only the counter currently displayed can be reset.

Precondition Maintenance is carried out

1. Enter the password for level 1 (renter level) or higher.
2. Simultaneously press and hold the «Acknowledge»  and «Enter»  keys for 2 seconds.

The displayed maintenance interval counter will be reset.

## 8.5 Displaying machine operating data

Precondition Controller switched on

<Main menu => engine operating data – compressor> selected.




Fig. 45 Operating data menu

- |      |                      |     |                                       |
|------|----------------------|-----|---------------------------------------|
| [1a] | Main menu            | [4] | Further menu options                  |
| [2a] | Engine data          | [A] | Display field size (white background) |
| [2b] | Compressor unit data | [B] | Selection choice (grey background)    |
| [3]  | Navigation (menu)    |     |                                       |

#### Display engine data

Engine data is shown in four display menus. With the aid of the arrow keys, one can page through the display.

1. Select the engine data symbol [2a] and confirm with «Enter» [J].
2. Call up the required display menu by pressing [T] and/or [F].

Further information See chapter 4.8.1 for information on engine data display menus.

#### Display compressor data

Engine data is shown in two different display menus. With the aid of the arrow keys, one can page through the display.

1. Select the compressor data symbol [2b] and confirm with «Enter» [J].
2. Call up the required display menu by pressing [T] and/or [F].

Further information See chapter 4.8.1 for information on compressor data display menus.

#### Menu exit

- Press «esc» [esc].
- The display changes to show the operating mode.

## 8.6 Option va Using the external fuel pump option

Precondition Controller switched on

*<main menu => settings => options => external fuel pump>*




Fig. 46 External fuel pump switch-on symbol

[E7] External fuel pump setting menu

⑦ External fuel pump on/off

Confirm with «Enter» [J]

**Switch the external fuel pump on**

- Press «Enter» [J].

The pump switches on and fills the machine's fuel tank.

**Switch the external fuel pump off**

- Press «Enter» [J].

The external fuel pump switches off.

**Menu exit**

- Press «esc» [esc].

**Result** The display changes to show the operating mode.

## **8.7 Option ba** **Using the low-temperature equipment**

- Heed the safety instructions in chapter 3.5.

**Option bb Coolant pre-heating**

- Start the coolant pre-heating as described in chapter 7.9.2.

## **8.8 Option ga** **Generator operation**

**DANGER**

There is danger of fatal injury caused by contact with live components.

- Check correct function of the insulation monitoring device daily (see chapter 7.10).
- Have the generator and control box checked annually by a qualified electrician (see chapter 3.8.5).

### 8.8.1 Switching in the generator

Precondition Full load mode

Read and follow the instructions on generator operation in chapter 4.11.3.

1. Turn the «generator main switch» to the "I" position.
2. «Set the safety cut-out(s)» to the "I" position.
3. Turn the mode selector switch to the required mode of operation

Further information See chapter 4.11.2 for generator controls.

See chapter 4.11.1 for generator operating modes.

### 8.8.2 Switching off the generator

Precondition Read and follow the instructions on switching off the generator in chapter 4.11.3.

**CAUTION**

Thermal overload of the turbo generator.

Stopping the machine abruptly after the generator has been in operation for some time can cause heat damage to the generator.

- Allow the engine to run for about 2 minutes in idle before shutting down to allow the generator to cool down.

1. «Set the safety cut-out(s)» to the "0" position.
2. Turn the «generator main switch» to the "0" position.
3. Press the «load» key.
  - The «load» key flashes.
  - The machine switches to unloaded run-on, i.e. the engine runs at IDLE speed and the oil separator tank is vented.
  - After running about 2 minutes in IDLE, the generator has cooled down enough so that the engine can be stopped.

## 9 Fault Recognition and Rectification

### 9.1 Basic instructions

1. Do not attempt fault rectification measures other than those given in this manual.
2. Inform KAESER Service if the fault cannot be removed by the action suggested.

Further information Observe the instructions in chapter "Safety" and prevailing local safety regulations when rectifying faults and malfunctions.

### 9.2 SIGMA CONTROL MOBIL messages

There are three types of message:

- Alarm messages, see chapter 9.2.1
- Warning messages, see chapter 9.2.2
- Maintenance messages, see chapter 10.2

The messages valid for your machine are dependent on the controller factory settings and individual equipment with which the machine is provided.

#### 9.2.1 Alarm messages on the controller (machine off)

Alarm with automatic machine shut-down function.

The «Acknowledge» key  flashes. The «Information» key  and «Stop» key  are illuminated.

##### Message code range 1100 – 1199 “engine faults”

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1100	Oil pressure fault.	Check the engine oil level.	10.4.4	–	–
		Have the engine oil pressure checked.	–	X	–
		Have the oil pressure switch checked.	–	X	X
1101	Oil pressure sensor defective.	Have the sensor changed.	–	X	X
1110	Coolant temperature high.	Check the coolant level.	10.4.1	–	–
		Clean the radiator.	10.6	–	–
		Check the cooling system.	–	X	X
1111	Coolant level too low.	Check the coolant level.	10.4.1	–	–
1112	Coolant temperature sensor defective.	Have the sensor changed.	–	X	X
1120	Turbo air pressure too high/low.	Have the turbo air pressure sensor checked.	–	X	X

## 9 Fault Recognition and Rectification

### 9.2 SIGMA CONTROL MOBIL messages

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1121	Turbo air temperature too high.	Check operating conditions.  Allow the machine to cool down.	5.2	-	-
		Clean the radiator.		10.6	-
1122	Turbo air temperature sensor defective.	Have the sensor changed.	-	X	X
1123	Turbo air temperature sensor defective.	Have the sensor changed.	-	X	X
1130	Fuel level low.	Refuel.	-	-	-
1131	Fuel temperature high.	Allow the machine to cool down.	-	-	-
1132	Fuel pressure low.	Have checked.	-	X	X
		Clean / replace the fuel filter.	10.4.3	-	-
1133	Fuel temperature sensor defective.	Have the sensor changed.	-	X	X
1134	Fuel pressure sensor defective.	Have the sensor changed.	-	X	X
1135	Fuel pump fault..	Have checked.	-	X	X
1140	Defective alternator.	Have checked.	-	X	X
1141	Battery voltage too high/low.	Battery maintenance.	10.4.9	-	-
		Check battery charging system.	-	X	X
1150	Engine electronics fault.	Have checked.	-	X	X
1151	Fault in the engine electronic communication - engine electronics side.	Have checked.	-	X	X
1152	Fault in the engine electronic communication - ECM side.	Have checked.	-	-	X
1160	Rail pressure sensor fault.	Have checked.	-	X	X
1161	Speed sensor fault.	Have checked.	-	X	X
1170	Starting fault (after 3 failed attempts).	Have checked.	-	-	X

Tab. 65 Fault messages and actions concerning the engine.

**Message code range 1200 – 1299 “compressor unit faults”**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1200	Compressor unit overheating.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.		–	–
		Check the cooling oil level.	10.5.2	–	–
1201	Compressor pressure too high.	Clean the cooler.	10.6	–	–
		Have checked.	–	–	X

Tab. 66 Fault messages and actions concerning the compressor unit

**Message code range 1300 – 1399 “controller faults”**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1300	Memory fault.	Have checked.	–	–	X
1301	Fault in bus communication with engine electronics.	Have checked.	–	–	X
1302	Fault in bus communication with display unit.	Have checked.	–	–	X
1303	Overheating.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.		–	–
1304	Power supply.	Have checked.	–	–	X

Tab. 67 Fault messages and actions concerning the controller.

**Message code range 1400 – 1499 “general faults”**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1400	Quick stop	Unblock.	8.2.6	–	–
		Have checked.		–	X
1410	Open circuit in the oil separator tank pressure sensor.	Have repaired.	–	–	X
1411	Short circuit in the oil separator tank pressure sensor.	Have repaired.	–	–	X

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
1412	Open circuit in the inlet valve pressure sensor.	Have repaired.	-	-	X
1413	Short circuit in the inlet valve pressure sensor.	Have repaired.	-	-	X
1414	Open circuit in the compressor unit temperature sensor.	Have repaired.	-	-	X
1415	Short circuit in the compressor unit temperature sensor.	Have repaired.	-	-	X
1416	Open circuit in fuel level sensor.	Have repaired.	-	-	X
1417	Short circuit in fuel level sensor.	Have repaired.	-	-	X
1420	Open circuit in the venting valve (p+e).	Have repaired.	-	-	X
1421	Short circuit in the venting valve (p+e).	Have repaired.	-	-	X
1422	Open circuit in the auxiliary venting valve (p)	Have repaired.	-	-	X
1423	Short circuit in the auxiliary venting valve (p)	Have repaired.	-	-	X
1424	Open circuit in the inlet valve control valve (e).	Have repaired.	-	-	X
1425	Short circuit in the inlet valve control valve (e).	Have repaired.	-	-	X
1426	Open circuit in the frost protector valve.	Have repaired.	-	-	X
1427	Short circuit in the frost protector valve.	Have repaired.	-	-	X
1430	Manual-stop automatic mode.	Unblock. Have checked.	8.2.6 -	-	- X
1450	Controller block, GSM/GPS monitoring.	Unblock GSM/GPS module.	-	-	X
1470	Automatic start fault.	Have checked.	-	-	X

Tab. 68 General fault messages and measures

### 9.2.2 Warning message on the controller

The machine is not shut down.

The «Acknowledge» key  flashes. The «Information» key  illuminates.



In the case of an overheating warning, the machine switches automatically to IDLE to cool down.

**Message code range 3100 – 3199 “engine warning”**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
3100	Engine oil level low.	Check the engine oil level.	10.4.4	–	–
		Have the engine oil pressure checked.	–	X	–
		Have the oil pressure sensor checked.	–	X	X
3110	Coolant temperature high.	Check the coolant level.	10.4.1	–	–
		Clean the radiator.	10.6	–	–
		Check the cooling system.	–	X	X
3121	Turbo air temperature high.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.			
		Clean the radiator.	10.6	–	–
		Have the turbo air pressure sensor checked.	–	X	X
3130	Fuel level low.	Refuel.	–	–	–
3133	Fuel filter water level.	Empty the fuel prefilter water trap.	10.4.3	–	–

Tab. 69 Warning messages and measures relating to the engine.

**Message code range 3200 – 3299 “compressor unit warnings”**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
3200	Compressor overheating.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.		–	–
		Check the cooling oil level.	10.5.2	–	–
3201	Compressor final pressure too high.	Clean the cooler.	10.6	–	–
		Have checked.	–	–	X

Tab. 70 Warning messages and measures relating to the compressor

**Message code range 3400 – 3499 “general warnings”**

Code	Meaning	Remedy	See chapter	Where can I get help?	
				Specialised workshop	KAESER Service
3400	Battery charging voltage.	Have checked.	–	X	X

Tab. 71 General warning messages and measures

## 9.3 Engine faults and alarms

Further information See also the engine service manual.

### 9.3.1 Engine refuses to start or does not turn over

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER Service	Engine service manual
«Quick-stop» button latched in.	Unlatch the «quick-stop» button, see chapter 8.2.6.	–	–	–
Defective starter.	Have changed.	X	–	–
Engine electrical fault	Have repaired/changed.	X	–	–
Fuel tank empty.	Fill up the fuel tank	–	–	–
Airlock in the fuel line between fuel tank and injector pump.	Bleed the fuel line (see chapter 10.4.3).	–	–	X
Fuel filter clogged.	Clean or replace, see chapter 10.4.3.	–	–	X
Fuel line broken.	Have changed.	X	–	–
Defective control fuse or relay.	Have repaired or replaced if necessary.	X	X	–
Airend discharge temperature too high.	Have adjusted.	–	X	–
SIGMA CONTROL MOBIL defective.	Have repaired/changed.	–	X	–
Electrical connections and/or cables loose or broken.	Tighten the connection or have the cable replaced.	X	–	–
Defective battery or low charge.	Maintain battery, see chapter 10.7.	–	–	–
Defective alternator.	Have changed.	X	–	–
Defective alternator regulator.	Have changed.	X	–	–

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER Service	Engine service manual
Oil pressure switch indicating insufficient oil pressure.	Check the engine oil level (see chapter 10.4.4).	–	–	X
	Have the engine repaired or exchanged.	X	–	–

Tab. 72 Fault: engine refuses to start or comes to a stop.

### 9.3.2 Engine does not reach full speed

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER Service	Engine service manual
Airlock in the fuel line between fuel tank and injector pump.	Bleed the fuel line (see chapter 10.4.3).	–	–	X
Fuel filter clogged.	Clean or replace, see chapter 10.4.3.	–	–	X
Fuel line broken.	Have changed.	X	–	–
Speed adjustment cylinder mal-adjusted or defective.	Repair or have replaced if necessary.	X	X	–
Engine electrical fault	Have repaired/changed.	X	–	–
SIGMA CONTROL MOBIL defective.	Have repaired/changed.	–	X	–

Tab. 73 Fault: engine does not reach full speed.

## 9.4 Compressor faults and alarms

### 9.4.1 Working pressure too high

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Proportional controller defective.	Have repaired or replaced if necessary.	–	X
Inlet valve not closing.	Check the controller, the control air line and the inlet valve and replace if necessary.	–	X
Pressure gauge giving false reading.	Have repaired or replaced if necessary.	–	X

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Venting valve does not blow off.	Check the connections and function and have repaired or replaced as necessary.	–	X

Tab. 74 Fault: working pressure too high

#### 9.4.2 Working pressure too low

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Proportional controller defective.	Have repaired or replaced if necessary.	–	X
Inlet valve not opening or only opening partially.	Repair or have replaced if necessary.	–	X
Pressure gauge giving false reading.	Have repaired or replaced if necessary.	–	X
Pressure relief valve maladjusted and/or leaking.	Have replaced if necessary.	–	X
Venting valve does not close.	Check the connections and function and have repaired or replaced as necessary.	–	X
Engine not running at full speed.	See chapter 9.3.	–	–
Engine air filter and/or compressor air filter clogged.	Clean or change, see chapters 10.4.2 and 10.5.7.	–	–
Oil separator cartridge heavily clogged.	Change, see chapter 10.5.6.	–	–

Tab. 75 Fault: working pressure too low

#### 9.4.3 Pressure relief valve blowing off

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Oil separator cartridge heavily clogged.	Change, see chapter 10.5.6.	–	–
Inlet valve not closing.	Check the controller, the control air line and the inlet valve and replace if necessary.	–	X
Pressure relief valve maladjusted and/or leaking.	Adjust or have replaced if necessary.	–	X

Tab. 76 Fault: pressure relief valve blowing off

#### 9.4.4 Machine overheating

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Defective cooling fan.	Have the blades or the complete fan wheel replaced.	–	X
Oil cooler clogged.	Clean surface, see chapter 10.6.	–	–
Defective working element in the combination valve.	Have repaired or replaced if necessary.	–	X
Oil separator cartridge heavily clogged.	Measure the pressure differential and change the cartridge if greater than 1 bar (see chapter 10.5.6).	–	X
Compressor oil filter clogged.	Change, see chapter 10.5.4.	–	–
Compressor cooling oil level too low.	Top up (see chapter 10.5.2).	–	–
Oil pipes leaking.	Seal leaks or have pipes changed.	X	X
Engine cooling system or cooling fan defective.	Have repaired.	X	X
Ambient temperature too high.	See installation conditions in chapter 5.2.	–	–

Tab. 77 Fault: machine overheating

#### 9.4.5 Too much oil residue in the compressed air

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Oil separator cartridge scavenge line clogged.	Clean the strainer in the separator cartridge dirt trap or have changed if necessary.	–	X
Fractured oil separator cartridge.	Change, see chapter 10.5.6.	–	–
Oil level in the oil separator tank too high.	Reduce to maximum level, see chapters 10.5.1 and 10.5.3.	–	–

Tab. 78 Fault: too much oil residue in the compressed air

**9.4.6 Oil flows from the compressor air filter after shutdown**

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Defective non-return function of the inlet valve.	Repair or have replaced if necessary.	–	X

Tab. 79 Fault: oil flows from the compressor air filter after shutdown

**9.4.7 Option da, db, dc, dd**
**High moisture content in the compressed air**

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER Service
Blocked condensate drain on the cyclone separator.	Clean the cyclone separator dirt trap or replace the strainer and nozzle if necessary. Replace (see chapter 10.9.1).	–	X

Tab. 80 Fault: high moisture content in the compressed air

**9.5 Option ga**
**Generator faults and alarms**
**9.5.1 There is no voltage or too low a voltage from the generator**

Possible cause	Action	Where can I get help?	
		Specialised workshop	KAESER Service
Defective drive belt.	Have changed.	X	X
Generator/regulator defective	Have repaired.	X	X
Overload protection switch triggered because of overload or defect.	Check the power requirement of the connected consumers and reduce if necessary; check the consumers for short circuits.	X	–
	Check the overload protection switch and have changed if necessary.	X	X
Engine speed too low.	Have reset to rated speed.	X	X
Generator not switched in.	Switch in the generator.	–	–
The compressor's working pressure is set too high, engine overloaded, speed drops off	Have the working pressure adjusted.	X	X

Possible cause	Action	Where can I get help?	
		Specialised workshop	KAESER Service
The engine power is reduced because of climatic or other effects.	Keep the generator and compressor load below the rated power	–	–

Tab. 81 There is no voltage or too low a voltage from the generator

### 9.5.2 Generator voltage too high

Possible cause	Action	Where can I get help?	
		Specialised workshop	KAESER Service
Generator/regulator defective	Have repaired.	X	X
Engine speed too high.	Have reset to rated speed.	X	X

Tab. 82 Generator voltage too high

# 10 Maintenance

## 10.1 Safety

Follow the instructions below to ensure safe machine maintenance.

Warning instructions are located before a potentially dangerous task.

### Basic safety instructions

**WARNING**

Danger of injury from hot, rotating and electrically live components!

Serious injury can be caused by touching such components.

- Shut down the machine before opening any doors/canopy.
- Do not carry out any checks or maintenance while the machine is running.

1. Follow the instructions in chapter 'Safety and Responsibility'.
2. Maintenance work may only be carried out by authorized personnel.
3. Before restarting the machine, make sure that:
  - No personnel are working on the machine,
  - all protective guards and cover panels are screwed back on,
  - all tools have been removed from the machine.

### Working on pressure system

1. Check that all air consumers are disconnected.
2. Wait until the machine is automatically vented (check that the pressure gauge indicates 0 bar).
3. Open outlet valves carefully to ensure that the line between the minimum pressure/check valve and the compressed air outlet is vented.
4. Do not open or dismantle any valves.

### Working on the drive system

- Before commencing work make sure that:
  - The «battery isolating switch» is off.
  - The machine has cooled down.

Further information Details of authorized personnel are found in chapter 3.4.2.

Details of dangers and their avoidance are found in chapter 3.5.

## 10.2 Maintenance message on the controller

The controller displays maintenance intervals. Display begins 25 hours before the interval will expire.

When the machine is switched on, the «Information» key illuminates. The «Acknowledge» key flashes.

Further information See chapter 8.4 for more information on acknowledging maintenance messages and resetting maintenance interval counters.

**Message code range 2100 – 2199 “engine maintenance”**

Code	Meaning	Remedy	See chapter
2100	Change engine oil and filter (500h).	Change the engine oil.	10.4.6
		Change the engine oil filter.	10.4.7
2101	Clean or change the engine air filter (500h).	Clean or change air filter.	10.4.2

Tab. 83 Maintenance messages and measures connected with engine maintenance.

**Message code range 2200 – 2299 “compressor unit maintenance”**

Code	Meaning	Remedy	See chapter
2200	Change the compressor cooling oil and filter (1000h).	Change the cooling oil.	10.5.3
		Change the oil filter.	10.5.4
2201	Clean or change the compressor air filter (250h).	Clean or change air filter.	10.5.7

Tab. 84 Maintenance messages and measures connected with compressor maintenance.

## 10.3 Maintenance schedules

The maintenance schedules provide an overview of the maintenance instructions for the machine.

- Read the relative section before undertaking maintenance.

### 10.3.1 Logging maintenance work



The maintenance intervals given are those recommended for average applications and operating conditions.

Maintenance schedules may be modified to take into account the application, the environment and the quality of maintenance.


**WARNING**

Wear and machine damage through unusual applications or operating conditions.

- Maintenance tasks must be carried out more frequently when operating conditions are unfavourable (e.g. dusty atmosphere) or when the equipment is in constant use.

- Adjust the maintenance intervals with regard to local installation and operating conditions.

- Keep a log of all properly carried out maintenance and service work.

This enables the frequency of individual maintenance tasks and deviations from our recommendations to be determined.

Further information A prepared list is provided in chapter 10.10.

### 10.3.2 Maintenance tasks after commissioning

The table below lists maintenance tasks required after commissioning (initial start-up).

- Carry out maintenance tasks according to the following schedule.

Component Task	After the first 10 h	After the first 50 h	See chapter	Note
<b>Engine</b>				
Check belt tension and re-tension if necessary.		X	10.4.8	Engine SM
Check coolant level.		X	10.4.1	Engine SM
<b>Compressor unit</b>				
Change the oil filter.		X	10.5.4	
<b>Chassis</b>				
Retighten the wheel nuts/bolts.		X		
<b>Option ga – generator</b>				
Check/adjust belt tension.	X		10.9.4	
h = operating hours; Engine SM = engine manufacturer's service manual				

Tab. 85 Maintenance tasks after commissioning

### 10.3.3 Regular maintenance tasks

The following table lists the various maintenance intervals.

Maintenance interval	Short description
Daily	–
Every 250 h, at least annually.	A250
Every 500 h, at least annually.	A500
Every 1000 h, at least annually.	A1000
Every 1500 h, at least annually.	A1500
Every 2000 h, at least annually.	A2000
Every 3000 operating hours	A3000
Every 6000 operating hours	A6000
Every 20000 operating hours	A20000
Every 36,000 operating hours but at least every 6 years	A36000

Tab. 86 Maintenance intervals and regular maintenance tasks

The table below lists regular maintenance tasks.

- Carry out maintenance tasks punctually taking ambient and operating conditions into consideration.

**10.3.3.1 Maintenance schedule**

- Carry out maintenance tasks according to the following schedule.

Component Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A6000	A36000	See chapter	Note
<b>Engine</b>											
Check inlet air filter maintenance indicator	X									10.4.2	
Check engine oil level.	X									10.4.4	Engine SM
Clean the engine air filter		X								10.4.2	
Change the engine oil		X								10.4.6	
Change the engine oil filter.		X								10.4.7	Engine SM
Check/adjust the drive belt tension.		X								10.4.8	Engine SM
Change engine air filter.			X							10.4.2	
Have intercooler maintained.	X										SW
Have the turbocharger checked.		X									SW
Have the crankcase venting valve checked.		X									SW
Check the engine mounts.		X									SW Engine SM
Have the valve clearance adjusted.			X								SW Engine SM
Replace the drive belt.				X						10.4.8	SW Engine SM
Have the multi-ribbed belt / jockey wheel checked/replaced.				X							Engine SM SW
Have the crankcase venting valve replaced.				X							SW
Check the engine coolant level.	X									10.4.1	Engine SM
Clean the radiator.		X								10.6	
Check coolant hoses and clamps.			X								

Engine SM = engine manufacturer's service manual; SW = specialized workshop.

Component Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A6000	A36000	See chapter	Note
Check antifreeze concentration.		X								10.4.1	Engine SM
Change the coolant.				X						10.4.1	Engine SM
Fill up the fuel tank.	X										
Empty the fuel prefilter water trap.	X									10.4.3	
Clean the fuel filter.			X							10.4.3	Engine SM
Have the fuel pump cleaned.				X							SW
Clean the tank fuel strainer.		X									
Clean the fuel tank.		X									
Check fuel lines and hose clamping bands, replace if necessary.				X							SW
Change the fuel prefilter.				X						10.4.3	Engine SM
Replace the fuel filter.				X						10.4.3	Engine SM
Check the fuel return line for leakage and firm fixing.			X								
Have the fuel injectors checked.					X						SW
Have the fuel injector pump checked.						X					SW
Check the battery electrolyte level and connections.			X							10.4.9	
Have an electronic test made on the injectors.							X				SW
<b>Compressor unit</b>											
Check inlet air filter maintenance indicator.	X									10.5.7	
Check the cooling oil level.	X									10.5.1	
Clean the compressor air filter.		X								10.5.7	
Clean the oil cooler.	X									10.6	
Have the pressure relief valve(s) checked.			X							10.5.8	
Check/clean the oil separator tank dirt trap.			X							10.5.5	
Change engine air filter.			X							10.5.7	

Engine SM = engine manufacturer's service manual; SW = specialized workshop.

Component Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A6000	A36000	See chapter	Note
Change the cooling oil.			X							10.5.3	
Change the compressor oil filter.			X							10.5.4	
Change the separator cartridge in the oil separator tank.						X				10.5.6	
<b>Chassis/bodywork</b>											
Check the tyre pressures.		X									
Check wheel fixings are tight.		X									
Carry out chassis maintenance.			X							10.8	
Grease the ball coupling, joints and towbar.			X							10.8.2	
Brake maintenance			X							10.8.3	
Check wear on the brake linings.			X							10.8.3.2	
Have the wheel brakes adjusted.		X									SW
Check all screw connections, hinges, locks, catches, handles and snap fasteners for wear and secure fixing.	X										
Grease the door hinges.			X								
Carry out rubber sealing strip maintenance.			X							10.7	
Have the lifting eye checked.			X								SW
<b>Other maintenance tasks</b>											
Check all accessible fittings, pipes and clamps for wear and tightness.			X								
Check hoses for leaks and wear.			X								
Have hose lines replaced.								X			SW
Check that all electrical connec- tions are tight.			X								

Engine SM = engine manufacturer's service manual; SW = specialized workshop.

Tab. 87 Regular maintenance tasks

**10.3.3.2 Maintenance schedule for options**

- Carry out maintenance tasks according to the following schedule.

Option Function	Daily	A250	A500	A1000	A2000	A20000	See chapter	Note
<b>Option da, db, dc, dd – cyclone separator</b>								
Clean and check the dirt trap.			X				10.9.1	
<b>Option da, db, dc, dd – compressed air aftercooler</b>								
Clean the cooler.		X					10.6.1	
<b>Option dd – filter combination</b>								
Drain condensate.	X						10.9.2	
Change the filter elements			X				10.9.2	
<b>Option dc – breathing air filter</b>								
Drain condensate.	X						10.9.3	
Change the filter elements			X				10.9.3	
<b>Option ga – generator</b>								
Check/adjust belt tension.		X					10.9.4	
Carry out visual check of drive belt.		X					10.9.4	
Have the generator and control box checked.			X					EL
Replace the drive belt.					X		10.9.4	
Have the generator bearings checked.				X				SW
Have the generator bearings changed.						X		SW
EL = qualified electrician; SW = specialist workshop								

Tab. 88 Regular maintenance tasks for options

**10.4 Engine**

- Carry out maintenance according to the schedule in chapter 10.3.3.1.

### 10.4.1 Radiator maintenance

Material	Coolant Coolant tester Receptacle Drain hose Funnel Cleaning cloths
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Machine cooled down. All compressed air consumers are disconnected and the air outlet valves are open.

**WARNING**

Danger of scalding by hot coolant!  
Serious injuries can be caused by hot coolant.  
► Allow the machine to cool down before opening the enclosure.

**CAUTION**

There is danger of injury from coolant containing antifreeze!  
► Avoid eye and skin contact with coolant. If the eyes are affected, rinse immediately with running water.  
► Wear protective glasses and gloves.

**CAUTION**

Insufficient coolant can damage the engine.  
Insufficient coolant will cause the engine to overheat. Overheating can cause serious damage to the engine.  
► Check the coolant level daily.  
► Top up the coolant as necessary.

#### 10.4.1.1 Checking coolant level

Check the coolant level of the engine daily before starting.

The level is checked on the coolant expansion tank.

- The tank is semi-transparent so the coolant level can be seen from outside.
- The level should be between the minimum and maximum markings with the engine cooled down.




Fig. 47 Checking coolant level

- |                            |                       |
|----------------------------|-----------------------|
| ① Filler neck with cap     | ⑤ Coolant level       |
| ② Overflow                 | Ⓐ Maximum mark (FULL) |
| ③ Coolant expansion tank   | Ⓑ Minimum mark (LOW)  |
| ④ Radiator connection hose |                       |

1. Open the right-hand access door.
2. Check the level of coolant in the expansion tank.  
Top up when the coolant level falls below the minimum level Ⓑ.
3. Close the access door.



Find out and rectify the reason for coolant loss.

#### 10.4.1.2 Check coolant

The coolant should be checked according to the maintenance schedule to ensure quality and operational life.

Coolant quality can be determined by the following parameters:

- Visual check
- Antifreeze concentration measurement

1. Open the right-hand access door.
2. Unscrew and remove the expansion tank filler cap ①.

##### Visual check

The coolant should be checked for its colour and any particles or sediments floating in it.

- Take a coolant sample and have analysed.  
The coolant should be changed if it is discoloured or has floating particles.

##### Antifreeze concentration measurement

An instrument (e.g. refractometer) is used to check antifreeze concentration.

Maximum frost protection is ensured with an antifreeze concentration of 55% by volume, as frost protection and heat transfer properties deteriorate beyond this point. Higher concentration also leads to higher operating temperature.

**CAUTION**

The engine can be damaged if the antifreeze concentration is insufficient.

Corrosion

Damage to the cooling system

Engine casing fracture

- Check coolant.
- Protect the coolant against frost.
- Top up as necessary.

1. Use the coolant tester as instructed by the manufacturer to test the coolant.  
Change the coolant when the concentration of antifreeze is too low.
1. Screw on the filler cap.
2. Close the access door.

**10.4.1.3 Mixing coolant**

Do not use water without coolant additive. Water alone is corrosive at engine operating temperature. Water also offers no protection from boiling or freezing.

The coolant is a mixture of clean, fresh water and antifreeze with corrosion inhibitor.

For reasons of corrosion protection and the need to raise the boiling point, the coolant must remain in the cooling system throughout the year.

The maximum permissible coolant life is 2 years.

- Follow coolant recommendations in chapter 2.6.3.

**Preparing coolant**

Precondition Coolant must meet the specification of ASTM D4985.

- The coolant should be mixed in the proportions given by the manufacturer.

KAESER coolant mixture table

Antifreeze	Water	Frost protection to [°C]
1 part	2 parts	-20
1 part	1.5 parts	-27
1 part	1 part	-37

Tab. 89 KAESER coolant mixture table



The concentration of antifreeze should not be less than 33% for ensured corrosion protection.

**10.4.1.4 Checking / topping up the coolant**

The proportion of antifreeze in the coolant should not fall below 33% to ensure frost and corrosion protection and prevent the build up of deposits in the cooling circuit. Topping up with water alone dilutes the antifreeze concentration and is forbidden.



Make sure that there is sufficient room for the coolant to expand when hot without overflowing.

Precondition The «battery isolating switch» is off.

1. Open the right-hand access door.
2. Remove the expansion tank filler cap.
3. Mix a quantity of coolant according to the table and top up to the mark.  
Top up until the coolant level is just below the maximum mark **A**
4. Screw on the filler cap.
5. Switch the «battery isolating switch» on.
6. Close the access door.
7. Start the engine and allow to IDLE for about 1 minute.
8. Stop the engine.
9. Open the right-hand access door.
10. Check the coolant level.  
Top up if the coolant level in the expansion tank has fallen.
11. Carry out a visual check for leaks.
12. Close the access door.

#### 10.4.1.5 Draining the coolant

The complete volume of coolant contained in the circuit can be drained from the radiator. This is done from a drain valve with the aid of a separate drain hose.

Precondition Machine cooled down.

The «battery isolating switch» is off.




Fig. 48 Draining the coolant from the radiator

- |          |                        |          |                              |
|----------|------------------------|----------|------------------------------|
| <b>①</b> | Filler cap             | <b>⑤</b> | Drain valve (ball)           |
| <b>②</b> | Coolant expansion tank | <b>⑥</b> | Quick-release coupling       |
| <b>③</b> | Radiator               | <b>⑦</b> | Drain hose with male fitting |
| <b>④</b> | Radiator drain         |          |                              |

1. Open both doors.
2. Unscrew and remove the expansion tank filler cap **①**.

3. Position a coolant receptacle beneath the radiator (hole in the floor panel).
4. Connect a suitable drain hose **7** to the radiator quick-release coupling **6**.
5. Lead the hose through the hole in the floor panel and into the receptacle, securing it in place.
6. Open the drain valve **5** and drain the coolant.
7. Close the drain valve and remove the drain hose.
8. Screw on the filler cap.
9. Close the doors.




► Dispose of used coolant in accordance with environmental protection regulations.

**Option sc, si Draining coolant (stationary compressors)**

Compressor cooling oil and engine coolant drain lines are led to a central point outside the machine on stationary machines. Coolant is drained via a hose screwed into the radiator drain point. The hose is provided with a shut-off valve and a plug.

Precondition Machine cooled down.

The «battery isolating switch» is off.



10-M0837

**Fig. 49 Radiator with centralised drainage**

- |          |                        |          |                    |
|----------|------------------------|----------|--------------------|
| <b>1</b> | Filler cap             | <b>5</b> | Screw plug         |
| <b>2</b> | Coolant expansion tank | <b>6</b> | Drain valve (ball) |
| <b>3</b> | Radiator               | <b>7</b> | Drain hose         |
| <b>4</b> | Radiator drain         |          |                    |

1. Open both doors.
2. Unscrew and remove the expansion tank filler cap **1**.
3. Place the coolant receptacle below the radiator drain point **4**.
4. Remove the plug **5**, open the shut-off valve **6** and collect the coolant.
5. Close the valve and replace the plug with sealing ring.
6. Close the doors.



► Dispose of used coolant in accordance with environmental protection regulations.

### 10.4.2 Air filter maintenance

Clean the filter according to the maintenance schedule or if the maintenance indicator shows this to be necessary.

Renew the air filter element after 2 years or after it has been cleaned 5 times.

- Material      Compressed air for blowing out  
                 Spare parts (as required)  
                 Cleaning cloths
- Precondition    The machine is shut down.  
                  The machine is fully vented, the pressure gauge reads 0 bar.  
                  Machine cooled down.  
                  All compressed air consumers are disconnected and the air outlet valves are open.

**WARNING**

Damaged air filter element

Wear in the engine from intake of contaminated air.

- Do not try to clean the filter element by striking it.
- Do not wash the filter element.




Fig. 50 Engine air filter maintenance

- |  |                  |
|--|------------------|
| ① Maintenance indicator                    | ⑤ Filter element |
| ② Red zone                                 | ⑥ Retaining clip |
| ③ Indicator piston                         | ⑦ Filter cap     |
| ④ Reset knob for the maintenance indicator |                  |




Fig. 51 Cleaning the filter element

- ① Compressed air gun with blast pipe bent to 90° at the end
- ② Filter element

➤ Open both doors.

#### Checking contamination of the air filter

Air filter maintenance is necessary when the yellow piston inside the maintenance indicator reaches the red zone.

- Check the air filter maintenance indicator.  
If the yellow piston reaches the red zone, clean or renew the filter element.

#### Cleaning the air filter

1. Release the retaining clip. Lift off the cap and extract the element.
2. Clean the inside of the housing, the cover and sealing faces carefully with a damp cloth.
3. Clean the filter element
  - Use dry compressed air ( $\leq 5$  bar) at an angle to blow dirt from the element from inside to outside.
  - The blast pipe must be long enough to reach right into the element.
  - The tip of the blast pipe should not be allowed to touch the element.
  - Clean sealing faces.
4. Inspect the element carefully for any damage.  
Renew a damaged element.
5. Insert the cleaned or new filter element into the filter housing. Make sure it is properly in place and sealed by its gasket.
6. Replace the cap and secure with the clip.

#### Resetting the maintenance indicator

- Press the reset knob on the maintenance indicator a number of times.  
The yellow piston within the indicator is reset and the maintenance indicator is ready for use again.
- Close the doors.


### 10.4.3 Fuel system maintenance

- Material    Spare parts  
               Receptacle  
               Cleaning cloths
- Precondition    The machine is shut down.  
                   The machine is standing level.  
                   The machine is fully vented, the pressure gauge reads 0 bar.  
                   Machine cooled down.  
                   All compressed air consumers are disconnected and the air outlet valves are open.  
                   The «battery isolating switch» is off.


**DANGER**

Danger of fire from spontaneous ignition of fuel!  
 Serious injury or death could result from the ignition and combustion of fuel.

- Allow no open flames or sparks at the place of use.
- Stop the engine.
- Wipe up escaped fuel.
- Keep fuel away from hot machine parts.
- Ensure that the maximum ambient temperature is not exceeded at the place of use.



10-M0366

Fig. 52 Fuel system maintenance

- |   |                  |   |                                       |
|---|------------------|---|---------------------------------------|
| ① | Fuel tank        | ③ | Fuel prefilter with water trap        |
| ② | Fuel fine filter | ④ | Manual fuel pump with bayonet fitting |

#### 10.4.3.1 Bleeding the fuel system

Air can enter the fuel system if the fuel tank is empty, after a fuel filter change or when carrying out work on the fuel lines.

Bleed the fuel system if the engine refuses to start despite the fact that the fuel tank is full.

1. Open the right-hand access door.
2. Unlatch the manual fuel pump bayonet lock by pressing and turning anti-clockwise.  
 The pump piston is pushed out by the spring.
3. Pump the piston until high resistance is felt.

4. Keep pumping until the return line is filled.
5. Switch the «battery isolating switch» on.
6. Close the access door.



Start the engine as soon as the fuel system has been bled and allow to run for at least 5 minutes in IDLE.

7. Open the right-hand access door.
8. Latch the manual fuel pump bayonet lock by pressing and turning clockwise.
9. Check the fuel prefilter for leaks.  
If a leak is found, tighten the filter element and fittings.
10. Close the access door.

#### 10.4.3.2 Fuel prefilter maintenance

- Open the right-hand access door.


##### Emptying the water trap

The fuel prefilter is equipped with a water trap. Contaminating water is trapped in the water receptacle. The water trap is connected by a sensor to the controller. If the water in the trap reaches a set level, the controller displays a warning.

- The display indicate water in the fuel filter.
- The «Information» key illuminates,
- The «Acknowledge» key flashes.



The water trap must be emptied when this warning is given.




10-M0413

Fig. 53 Warning indication: Fuel filter water level

Message category: warning

Message code

Fuel filter water level



10-M0414

Fig. 54 Emptying the fuel prefilter water trap

- ① Fuel prefilter with water trap
- ② Water receptacle
- ③ Dewatering tap

1. Place a receptacle beneath the fuel prefilter.
2. Open the dewatering tap and allow water and dirt to drain out into the receptacle.
3. Close the dewatering tap.
4. Switch the «battery isolating switch» on.
5. Close the access door.

Maintenance must be acknowledged after the water trap has been emptied.

**Precondition Draining the water trap**


- Confirm the maintenance with the «Acknowledge»  key.

The illuminated «Acknowledge»  and «Information»  keys are extinguished.



The mixture of fuel and water and any materials contaminated with fuel must be disposed of in accordance with environment protection regulations.

**Changing the filter cartridge**



10-M0855

Fig. 55 Changing the fuel prefilter cartridge

- |                    |  |
|--------------------|--|
| ① Filter head      | ④ Dewatering tap                           |
| ② Filter cartridge | ⑤ Connection for filter maintenance sensor |
| ③ Water receptacle |  |

1. Place a receptacle beneath the fuel prefilter.
2. Open the dewatering tap and allow water and dirt to drain out into the receptacle.
3. Disconnect the filter maintenance sensor.
4. Unscrew the filter cartridge and water trap anti-clockwise and remove.
5. Disconnect the water trap from the filter cartridge by unscrewing anti-clockwise.

6. Clean any fuel from the receptacle and clean the water trap.
7. Close the dewatering tap.
8. Screw the water trap onto the new filter cartridge.
9. Clean the sealing faces of the filter cartridge and filter head with a damp cloth.
10. Coat the sealing face of the new cartridge lightly with fuel and screw into the filter head.
11. Reconnect the filter maintenance sensor.
12. Switch the «battery isolating switch» on.
13. Close the access door.




The fuel system must be bled after the filter cartridge has been changed.



Dispose of fuel and any materials and components contaminated with it in accordance with environmental protection regulations.

Further information The engine service manual gives further information on fuel filter changing.

#### 10.4.3.3 Fuel filter maintenance



10-M0164

Fig. 56 Fuel filter maintenance

- ① Filter holder
- ② Filter cartridge
- ③ Turn in this direction to unscrew the filter cartridge.

1. Open the right-hand access door.
2. Place a container beneath the fuel filter.
3. Use a filter wrench to loosen then unscrew the filter cartridge. Catch fuel in the receptacle.
4. Carefully clean the filter holder sealing face using lint-free cloth.
5. Lightly coat the filter holder rubber gasket with fuel.
6. Lightly coat the new fuel filter cartridge with fuel and screw tight by hand.
7. Switch the «battery isolating switch» on.
8. Close the access door.



The fuel system must be bled after the filter cartridge has been changed.



Dispose of fuel and any materials and components contaminated with it in accordance with environmental protection regulations.

Further information The engine service manual gives further information on fuel filter changing.

#### 10.4.4 Checking the engine oil level

The engine oil is indicated by a dipstick in the oil sump. The oil level should ideally be between the two marks on the dipstick. The oil level should not be allowed to fall below the «minimum level».

- Material Cleaning cloths
- Precondition The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Engine cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.




Fig. 57 Checking the engine oil level

- |   |                       |   |                              |
|---|-----------------------|---|------------------------------|
| ① | Engine oil filler cap | A | Mark for «maximum oil level» |
| ② | Oil dipstick          | B | Mark for «minimum oil level» |

1. Open the right-hand access door.
2. Withdraw the dipstick, wipe with a lint-free cloth and replace fully.
3. Withdraw the dipstick once more and read off the oil level.  
The level should be between the maximum and minimum markings.  
Top up if the level has reached the «minimum level» mark.
4. Close the access door.

#### 10.4.5 Engine oil filling and topping up

- Material Engine oil  
Cleaning cloths  
Funnel
- Precondition The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.

**Filling with engine oil**

See chapter 2.6.4 for engine oil filling volume.  
The oil dipstick is marked with the «maximum oil level».

1. Open the right-hand access door.
2. Remove the filler cap and fill with fresh oil.
3. Wait 5 minutes then check the oil level.



It takes a few minutes for oil to reach the sump.

Top up if the level is too low.

4. Replace the filler cap.
5. Switch the «battery isolating switch» on.
6. Close the access door.

**Starting the machine and carrying out a trial run**

1. Start the machine and allow it to idle for at least 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Check the oil level after about 5 minutes.  
Top up if the level is too low.
5. Carry out a visual check for leaks.

**10.4.6 Changing the engine oil**

The engine oil should be changed:

- according to the maintenance schedule,
- according to the degree of contamination of the intake air,
- at least once a year.



See chapter 2.6.4 for engine oil filling volume.  
See engine service manual for oil change under dusty conditions.

Material	Engine oil Receptacle Cleaning cloths
----------	---

Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Engine at operating temperature. All compressed air consumers are disconnected and the air outlet valves are open. The «battery isolating switch» is off.
--------------	--

**CAUTION**

Danger of burns from hot components and escaping engine oil!

- Wear long-sleeved clothing and gloves.




Fig. 58 Draining the engine oil

- |   |                 |   |                             |
|---|-----------------|---|-----------------------------|
| ① | Floor pan       | ③ | Drain plug                  |
| ② | Engine oil sump | ④ | Drain hole in the floor pan |

**Draining the engine oil**

1. Open the right-hand access door.
2. Place the oil receptacle below the drain hole in the floor pan.
3. Unscrew the drain plug.  
Engine oil flows into the receptacle.
4. Clean the drain plug and screw in with a new gasket.
5. Close the access door.



Dispose of old oil and oil-soaked working materials according to environmental protection regulations.

**Further information**


See chapter 10.4.5 for oil filling.

The engine service manual gives instructions on oil changing.

**Option sc, si Draining the engine oil (stationary machine)**

Compressor oil and engine coolant drain lines are led to a central point outside the machine on stationary machines. Engine oil is drained via a hose connected to a drain point on the engine block. The hose is provided with a shut-off valve and a plug.

Option sc, si



10-M0838

Fig. 59 Draining the engine oil, central drain point

- [1] Engine oil drain
- [2] Screw plug
- [3] Drain valve (ball)

- [4] Drain hose
- [5] Engine oil sump

1. Place the oil receptacle below the drain point [1].
2. Remove the plug [2], open the shut-off valve [3] and collect the oil.
3. Close the valve and replace the plug with sealing ring.



Dispose of old oil and oil-soaked working materials according to environmental protection regulations.

Further information See chapter 10.4.5 for oil filling.  
The engine service manual gives instructions on oil changing.

#### 10.4.7 Changing the oil filter

Material Spares  
Chain pipe wrench (part no. 8.8095.0)  
Cleaning cloths  
Receptacle

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Engine cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.



##### CAUTION

Danger of burns from hot components and escaping engine oil!  
► Wear long-sleeved clothing and gloves.




Fig. 60 Changing the oil filter

- |                         |   |
|-------------------------|---|
| ① Fuel tank<br>② Engine | ③ Direction of rotation to unscrew the filter<br>④ Chain wrench |
|-------------------------|---|

1. Open the right-hand access door.
2. Prepare a receptacle.
3. Loosen the filter with the chain wrench and screw off. Catch any escaping oil.
4. Carefully clean sealing surfaces using lint-free cloth.
5. Lightly oil the new filter's gasket.
6. Turn the oil filter clockwise by hand to tighten.
7. Check the engine oil level.  
Top up if the level is too low.
8. Switch the «battery isolating switch» on.
9. Close the access door.

Further information The engine service manual gives further information on oil filter changing.



Dispose of old oil filters, old oil and materials contaminated with oil according to environmental protection regulations.

#### 10.4.8 Checking the drive belts

The life of the drive belts is influenced by belt tension.

- Slack belts can slip and become damaged.
- Over-tight belts stretch and fatigue quicker. Over-tight belts also place unnecessary stress on bearings and shorten their life.

Material V-belt tension measuring device  
Spares

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.


**WARNING**

Beware of rotating pulleys and moving belts.  
There is danger of serious injury from pinching.


- Never check the drive belts unless the engine is at standstill.
- Never run the machine without a belt guard.
  
- Open both doors.

**10.4.8.1 Visual check**

1. Remove the belt guard, if fitted.
2. Check the belts thoroughly for cracks, fraying or stretching.  
Replace damaged belts.

**10.4.8.2 Checking belt tension**

Check belt tension when they are warm, not hot, to avoid length variations through temperature.  
The engine manufacturer recommends a tension measuring device for belts. For operation see the engine service manual.  
The belt tension may also be checked by hand if no tension measuring device is available.



10-M0174

Fig. 61 Belt tension checking by hand

- [A] Permissible deflection of the belt
- [\*] Approximate pressure exerted: 10 kg  
Permissible movement: 10 – 15 mm

Checking belt tension with tension measuring device.	Belt tension checking by hand
<ol style="list-style-type: none"> <li>1. Check belt tension with the tension measuring device.</li> <li>2. Increase the tension on loose belts.</li> <li>3. Replace the belt guard.</li> </ol>	<p>Press the belts in with the thumb at the mid-point between pulleys.</p> <ol style="list-style-type: none"> <li>1. Check belt tension by hand (see Fig. 61).</li> <li>2. Increase the tension on loose belts.</li> <li>3. Replace the belt guard.</li> </ol>

1. Switch the «battery isolating switch» on.
2. Close the doors.

Further information The engine service manual gives information on removing, changing and tensioning drive belts.

### **10.4.9 Battery maintenance**

- Check the charging system if batteries discharge without reason.


#### **10.4.9.1 Safety**

**WARNING**

Danger of acid burns from escaping electrolyte!

- Wear appropriate protective clothing including acid-proof rubber gloves.
- Always wear eye and face protection.
- Do not tip the battery. Electrolyte may run out of the vent holes.
- Work with caution.

Observe the following points when working on the batteries:



10-M0167

Fig. 62 Safety signs - warning stickers on the battery.

- |   |   |   |  |
|---|---|---|--|
| ① | Fire, sparks, open flame and smoking are forbidden.     | ④ | Batteries are filled with caustic electrolyte.   |
| ② | Wear eye and face protection. Danger of acid burn.      | ⑤ | Observe the battery manufacturer's instructions. |
| ③ | Keep children well away from batteries and electrolyte. | ⑥ | Explosion hazard!                                |

- Take heed of any safety signs on the battery warning labels.

**Further instructions on working with batteries**

1. Do not remove battery terminal covers unnecessarily.
2. Do not lay tools on the battery. These can lead to short circuiting, overheating and battery bursting.
3. Take particular care when the battery has been in service for a long time or has just been charged as highly explosive gas is emitted.  
Ensure good ventilation.

#### 10.4.9.2 Battery checking and care

Even so-called 'maintenance-free' batteries need a degree of care to obtain their maximum operational life.

The outside of the battery and the terminals should be cleaned regularly with a soft cloth. This avoids current leaks and minimises the discharge rate.

Material Terminal grease

Distilled water

Cleaning cloths

Protective gloves

Eye protection

Precondition The machine is shut down.

The machine is standing level.

The machine is fully vented, the pressure gauge reads 0 bar.

Machine cooled down.

► Open the left-hand door.

1. Clean the casing and terminals.

2. Lightly grease the terminals to prevent corrosion.

3. Check that connections are tight and tighten if necessary.

#### Check the battery electrolyte level.

The fluid is generally sufficient for the life of the battery. Nevertheless, the fluid level should be checked annually. The level should be up to the mark, 1 cm above the plates.



Replace the battery immediately if the casing leaks.



#### WARNING

Battery destruction!

Topping up with pure acid will increase the electrolyte concentration and can destroy the battery.

► Top up only with distilled water.

► Check the electrolyte level



If the level does not reach the mark -

► top up with distilled water.

► Close the access door.

#### Winter operation

Batteries are particularly stressed in winter. Only a fraction of the normal starting energy is available at low temperatures.

**CAUTION**

Danger of batteries freezing!

Discharged batteries are subject to frost damage and can freeze at –10 °C.

- Check battery charge with a specific gravity tester.
- Recharge the battery
- Clean the battery terminals and wipe with grease.

1. Check the battery charge weekly.  
Recharge as necessary.
2. If the machine is to be unused for a number of weeks, remove the battery and store in a frost proof room.



In extreme cases, the use of heavy-duty cold-start batteries (to DIN 75311) and/or additional batteries is recommended.

**10.4.9.3 Battery removal and installation****Precondition**

The machine is shut down.

The machine is standing level.

The machine is fully vented, the pressure gauge reads 0 bar.

Machine cooled down.

The «battery isolating switch» is off.

**WARNING**

There is danger of batteries bursting!

If a battery is short circuited it will overheat and can burst.

Battery electrolyte will be sprayed out in such an event.

- Never short-circuit a battery (e.g. with a hand tool).
- Wear gloves and eye protection.

**CAUTION**

Excessive voltage produced by the alternator.

Voltage peaks can destroy the alternator regulator and diodes.

- The battery serves as a buffer and must not be disconnected while the engine is running.

1. Open the left-hand door.
2. Disconnect the negative cable first, then the positive cable.
3. Unscrew the battery fixing clamp.
4. Replace in the reverse order.
5. Switch the «battery isolating switch» on.
6. Close the doors.

**Replacing batteries:**

Replacement batteries must have the same capacity, current strength and form as the original batteries.

- Always replace a battery with one of the same type.



Old batteries are special waste and must be disposed of correctly in accordance with local environment protection regulations.

## 10.5 Compressor

- Carry out maintenance according to the schedule in chapter 10.3.3.1.

### 10.5.1 Checking cooling oil level

The oil level is checked at the oil separator tank filling port. Oil must be visible in the port when the filler plug is removed.

Material	Cleaning cloths
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. All compressed air consumers are disconnected and the air outlet valves are open.




Fig. 63 Checking cooling oil level

①	Oil separator tank	Ⓐ	Minimum level
②	Oil filler port	Ⓑ	Maximum level
③	Screw plug		

1. Open the left-hand door.
2. Slowly unscrew and withdraw the plug from the oil filler port.
3. Check that oil is visible.  
Top up if no oil is visible.
4. Replace the filler plug.
5. Close the access door.

**10.5.2 Cooling oil filling and topping up**

Material	Cooling oil Funnel Cleaning cloths Wrench
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Machine cooled down. All compressed air consumers are disconnected and the air outlet valves are open. The «battery isolating switch» is off.

**Filling with cooling oil**

A sticker on the oil separator tank specifies the type of oil used.

**CAUTION**

The machine could be damaged by unsuitable oil.

- Never mix incompatible types of oil.
- Never top up with a different type of oil to that already used in the machine.

1. Open the left-hand door.
2. Slowly unscrew and withdraw the plug from the oil filler port.
3. Top up the cooling oil to the maximum level **B** with the help of a funnel.
4. Check the oil level.
5. Check the filler plug gasket for damage.  
Change a damaged gasket immediately.
6. Replace the plug in the filler port.
7. Switch the «battery isolating switch» on.
8. Close the access door.

**Starting the machine and carrying out a trial run**

1. Start the machine and run in idle up to operating temperature.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
5. Open the outlet valves.
6. Check the oil level after about 5 minutes.  
Top up if necessary.
7. Carry out a visual check for leaks.

**10.5.3 Changing the cooling oil**

Drain all cooling-oil from:

- Oil separator tank
- Oil cooler
- Oil pipes

Material	Cooling oil Receptacle Drain hose New gasket for the drain plug Funnel Cleaning cloths
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. The machine is at operating temperature. All compressed air consumers are disconnected and the air outlet valves are open. The «battery isolating switch» is off.


**CAUTION**

There is risk of burns from hot components and escaping oil.

- Wear long-sleeved clothing and gloves.




Fig. 64 Changing the cooling oil

- |                                   |                                  |
|-----------------------------------|----------------------------------|
| [1] Oil separator tank            | [5] Quick-release coupling       |
| [2] Oil filler plug               | [6] Drain hose with male fitting |
| [3] Oil separator tank drain plug | [7] Oil cooler                   |
| [4] Drain valve (ball)            |                                  |

- Heed the safety instructions in chapter 3.5.

**10.5.3.1 Draining the cooling oil**

1. Open both doors.
2. Remove the plug [2] from the oil separator tank filling port.

### Draining the oil from the separator tank

The oil separator tank can be drained from a point accessible through a hole in the floor panel.

1. Position a receptacle below the separator tank drain plug ③.
2. Unscrew the drain plug ③ and allow the cooling oil to drain into the receptacle.
3. Fit a new gasket on the drain plug and screw it back in again.

### Draining the oil from the cooler

This is done from a drain valve on the oil cooler with the aid of a separate drain hose.

1. Position a receptacle beneath the oil cooler drain point (accessible through a hole in the floor panel).
2. Connect a suitable drain hose ⑥ to the oil cooler quick-release coupling ⑤.
3. Lead the hose through the hole in the floor panel and into the receptacle, securing it in place.
4. Open the drain valve ④ slowly and drain the cooling oil.
5. Close the drain valve and remove the drain hose.
1. Replace the plug ② in the oil separator tank filling port.
2. Close the doors.



Dispose of used oil and oil-contaminated working materials according to environmental protection regulations.

Further information See chapter 10.5.2 for oil filling.

#### 10.5.3.2 Option sc, si

##### Draining cooling oil (stationary compressors)

Compressor cooling oil and engine coolant drain lines are led to a central point outside the machine on stationary machines. Oil drainage is via hose lines screwed into the drain ports of the oil separator tank and the airend. Each hose line is provided with a shut-off valve and a plug.




Fig. 65 Central compressor oil drainage

- |   |                                     |   |                    |
|---|-------------------------------------|---|--------------------|
| ① | Oil filler plug                     | ④ | Screw plug         |
| ② | Oil separator tank drain connection | ⑤ | Drain valve (ball) |
| ③ | Oil cooler drain connection         | ⑥ | Drain hose         |

1. Open both doors.
2. Remove the plug ① from the oil separator tank filling port.

**Draining the oil from the separator tank**

1. Place the oil receptacle below the oil separator tank drain point ②.
2. Remove the plug, open the shut-off valve and collect the oil.
3. Close the valve and replace the plug with sealing ring.

**Draining the oil from the cooler**

1. Place the oil receptacle below the oil cooler drain point ③.
  2. Remove the plug, open the shut-off valve and collect the oil.
  3. Close the valve and replace the plug with sealing ring.
1. Replace the plug ① in the oil separator tank filling port.
  2. Close the doors.



Dispose of used oil and oil-contaminated working materials according to environmental protection regulations.

Further information See chapter 10.5.2 for oil filling.

**10.5.4 Changing the oil filter**

Material Spares

Receptacle

Cleaning cloths

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The «battery isolating switch» is off.

**CAUTION**

There is risk of burns from hot components and escaping oil.

➤ Wear long-sleeved clothing and gloves.




Fig. 66 Changing the oil filter

- ① oil filter
- ② Direction of rotation to unscrew the oil filter.
- ③ Combination valve

#### Changing the oil filter

1. Open the left-hand door.
2. Prepare a receptacle.
3. Loosen the filter by turning anticlockwise and catch any escaping oil.
4. Carefully clean sealing surfaces using lint-free cloth.
5. Lightly oil the new filter's gasket.
6. Turn the oil filter clockwise by hand to tighten.
7. Check the oil level in the oil separator tank.  
Top up if necessary.
8. Switch the «battery isolating switch» on.
9. Close the access door.




Dispose of old cooling oil and any materials or parts contaminated with oil according to environment protection regulations.

#### Starting the machine and carrying out a trial run

1. Start the machine and run in idle up to operating temperature.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
5. Open the outlet valves.
6. Check the oil level after about 5 minutes.  
Top up if necessary.
7. Carry out a visual check for leaks.

**10.5.5 Oil separator tank dirt trap maintenance**

- Material      Spare parts  
                 Cleaning cloths  
                 Cleaning fluid or spirit
- Precondition    The machine is shut down.  
                   The machine is fully vented, the pressure gauge reads 0 bar.  
                   Machine cooled down.  
                   All compressed air consumers are disconnected and the air outlet valves are open.


**Fig. 67** Cleaning the dirt trap

- |   |   |
|---|---|
| <span style="border: 1px solid black; padding: 2px;">1</span> Oil separator tank cover<br><span style="border: 1px solid black; padding: 2px;">2</span> Control valve<br><span style="border: 1px solid black; padding: 2px;">3</span> Union nut<br><span style="border: 1px solid black; padding: 2px;">4</span> Oil return line | <span style="border: 1px solid black; padding: 2px;">5</span> Sealing ring<br><span style="border: 1px solid black; padding: 2px;">6</span> Dirt trap<br><span style="border: 1px solid black; padding: 2px;">7</span> Strainer |
|---|---|

1. Open the left-hand door.
2. Undo the union nut and bend the oil return line to one side.
3. Unscrew the dirt trap.
4. Unscrew the strainer from the dirt trap.
5. Clean the housing, strainer and sealing ring with cleaning solvent or spirit.
6. Check the strainer and sealing ring for wear.  
    Change if heavily worn.
7. Reassemble the dirt trap.
8. Refit the oil scavenge line..
9. Close the access door.

**Starting the machine and carrying out a trial run**

1. Start the machine and run for approximately 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
    Pressure gauge reads 0 bar.
4. Open the outlet valves.
5. Open the right-hand access door.
6. Carry out a visual check for leaks.
7. Shut down the machine.
8. Close the access door.

### 10.5.6 Changing the oil separator cartridge

The oil separator cartridge cannot be cleaned.

The life of the oil separator cartridge is influenced by:

- Contamination in the air drawn into the compressor
- and adherence to the changing intervals for:
  - Cooling oil
  - oil filter
  - air filter

Material Spare parts

Cleaning cloths

Wrench

Precondition The machine is shut down.

The machine is fully vented, the pressure gauge reads 0 bar.

Machine cooled down.

All compressed air consumers are disconnected and the air outlet valves are open.

The «battery isolating switch» is off.




Fig. 68 Changing the oil separator cartridge

- |   |   |   |                          |
|---|---|---|--------------------------|
| ① | Control air line union nut  | ⑨ | Control valve            |
| ② | Oil scavenge pipe (screwed to the cover)                              | ⑩ | Solenoid valve           |
| ③ | Oil scavenge pipe union nut (lower fitting, screwed to the dirt trap) | ⑪ | Sealing ring             |
| ⑤ | Air pipe  | ⑬ | Oil separator cartridge  |
| ⑦ | Cover   | ⑭ | Pressure sensor          |
| ⑧ | Fixing screw  | ⑮ | Relief valve guard plate |

#### Changing the oil separator cartridge

1. Open the left-hand door.

2. Unscrew the union nuts **1** and **3** and place the components with connections carefully to one side.
3. Pull out the plug to the solenoid valve **10** and withdraw the cable.
4. Pull out the plug to the sensor **14** and withdraw the cable.
5. Remove the screws **8** securing the cover **7** to the tank.
6. Remove the protective guard **15** from the relief valve.
7. Carefully lift the cover and put to one side.



Take particular care with the following components:

- The oil scavenge line **2** screwed to the underside of the cover.
  - The pressure relief valve, covered by the guard plate **15**.
8. Take out the old cartridge **13** and sealing rings **11**.
  9. Clean all sealing surfaces, taking care that no foreign bodies (dirt particles) fall into the oil separator tank.
  10. Insert the new oil separator cartridge with sealing rings and screw down the cover.
  11. Unscrew the dirt trap at position **3**.
  12. Renew the strainer and sealing ring in the dirt trap.
  13. Screw the dirt trap back in.
  14. Replace the relief valve guard plate **15**.
  15. Replace and tighten all fittings.
  16. Check the oil level in the oil separator tank.  
Top up if necessary.
  17. Switch the «battery isolating switch» on.
  18. Close the access door.



Dispose of the old separator cartridge and sealing rings, along with any working materials contaminated with cooling oil, in accordance with environment protection regulations.

#### Starting the machine and carrying out a trial run

1. Start the machine and run in idle up to operating temperature.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
5. Open the outlet valves.
6. Check the oil level after about 5 minutes.  
Top up if necessary.
7. Carry out a visual check for leaks.

#### 10.5.7 Air filter maintenance

Clean the filter according to the maintenance schedule or if the maintenance indicator shows this to be necessary.

Renew the air filter element after 2 years or after it has been cleaned 5 times.

- Material      Compressed air for blowing out  
                 Spare parts (as required)  
                 Cleaning cloths
- Precondition    The machine is shut down.  
                   The machine is fully vented, the pressure gauge reads 0 bar.  
                   Machine cooled down.  
                   All compressed air consumers are disconnected and the air outlet valves are open.


**WARNING**

Damaged air filter element  
                  Wear in the engine from intake of contaminated air.  
       ➤ Do not try to clean the filter element by striking it.  
       ➤ Do not wash the filter element.




Fig. 69 Compressor air filter maintenance

- |   |  |   |                |
|---|--|---|----------------|
| ① | Maintenance indicator                    | ⑤ | Filter element |
| ② | Red zone                                 | ⑥ | Retaining clip |
| ③ | Indicator piston                         | ⑦ | Filter cap     |
| ④ | Reset knob for the maintenance indicator |   |                |




Fig. 70 Cleaning the filter element

- |   |   |
|---|---|
| ① | Compressed air gun with blast pipe bent to 90° at the end |
| ② | Filter element  |
- Open both doors.

## 10 Maintenance

### 10.6 Cleaning the coolers and radiator

#### Checking contamination of the air filter

Air filter maintenance is necessary when the yellow piston inside the maintenance indicator reaches the red zone.

- Check the air filter maintenance indicator.

If the yellow piston reaches the red zone, clean or renew the filter element.

#### Cleaning the air filter

1. Release the retaining clip. Lift off the cap and extract the element.
2. Clean the inside of the housing, the cover and sealing faces carefully with a damp cloth.
3. Clean the filter element
  - Use dry compressed air ( $\leq 5$  bar) at an angle to blow dirt from the element from inside to outside.
  - The blast pipe must be long enough to reach right into the element.
  - The tip of the blast pipe should not be allowed to touch the element.
  - Clean sealing faces.
4. Inspect the element carefully for any damage.  
Renew a damaged element.
5. Insert the cleaned or new filter element into the filter housing. Make sure it is properly in place and sealed by its gasket.
6. Replace the cap and secure with the clip.

#### Resetting the maintenance indicator

- Press the reset knob on the maintenance indicator a number of times.  
The yellow piston within the indicator is reset and the maintenance indicator is ready for use again.
- Close the doors.

#### 10.5.8 Checking pressure relief valves

- Have pressure relief valves checked by KAESER Service in accordance with the maintenance schedule.

## 10.6 Cleaning the coolers and radiator

The compressor oil cooler and engine coolant radiator are combined in a single cooler block.

The frequency of cleaning is mainly dependent on local operating conditions.

Heavy clogging of the cooler/radiator can cause oil overheating and overheating of the engine.

Check the cooler/radiator regularly for clogging.

Avoid creating dust eddies. Wear breathing protection if necessary.

Do not clean the cooler/radiator with a sharp instrument, otherwise it could be damaged.

A severely contaminated cooler/radiator should be cleaned by KAESER Service.


Material	Compressed air Water or steam jet blaster
Precondition	Machine placed over a washing point equipped with an oil separator. The machine is shut down. Machine cooled down. The machine is fully vented, the pressure gauge reads 0 bar. All compressed air consumers are disconnected and the air outlet valves are open. The «battery isolating switch» is off.


**CAUTION**

Damage to the machine can be caused by water or steam jets.

Direct water or steam jets can damage or destroy electrical components and indicating instruments.

- Cover up electrical components such as the control cubicle, alternator, starter and instruments.
- Do not direct water or steam jets at sensitive components such as alternator, starter or indicating instruments.



10-M0157

**Fig. 71** Cooler/radiator cleaning

- |   |   |   |            |
|---|---|---|------------|
| ① | Front end of compressor, sound insulation (radiator grill) removed  | ④ | Air cooler |
| ② | Direction of impacting water or steam jet (from outside to inside). | ⑤ | Radiator   |
| ③ | Oil cooler  |   |            |

1. Open both doors.
2. Seal off the air intakes of the engine and compressor air filters before starting cleaning.
3. Remove the sound damping louver in front of the cooler/radiator.
4. Clean the cooling fins with compressed air, water or steam jet in the opposite direction to the cooling air flow (from inside to outside).
5. Replace the sound damping louver.
6. Remove the protective coverings from the air filters.
7. Switch the «battery isolating switch» on again.
8. Close the doors.
9. Start the machine and run up to operating temperature so that excess water is evaporated.

## 10 Maintenance

### 10.6 Cleaning the coolers and radiator



Clean the cooler/radiator only in a washing area equipped with an oil separator.

#### 10.6.1 Option da, db, dc, dd

##### Cleaning the compressed air aftercooler

The compressed air aftercooler is located near the air treatment devices.

Material	Compressed air Water or steam jet blaster
Precondition	Machine placed over a washing point equipped with an oil separator. The machine is shut down. Machine cooled down. The machine is fully vented, the pressure gauge reads 0 bar. All compressed air consumers are disconnected and the air outlet valves are open. The «battery isolating switch» is off.




##### CAUTION

Damage to the machine can be caused by water or steam jets.

Direct water or steam jets can damage or destroy electrical components and indicating instruments.

- Cover up electrical components such as the control cabinet, alternator, starter and instruments.
- Do not direct water or steam jets at sensitive components such as operating and indicating instruments.

Option da, db, dc, dd



10-M0779

Fig. 72 Cleaning the compressed air aftercooler

- ① Compressed air aftercooler
- ② Direction of impacting water or steam jet (from inside to outside).

1. Open both doors.
2. Seal off the air intakes of the engine and compressor air filters before starting cleaning.
3. Clean the aftercooler with compressed air, water or steam jet in the opposite direction to the cooling air flow (from inside to outside).
4. Remove the protective coverings from the air filters.
5. Switch the «battery isolating switch» on again.
6. Close the doors.
7. Start the machine and run up to operating temperature so that excess water is evaporated.

## 10.7 Rubber sealing strip maintenance

The rubber sealing strips between the body panels the access doors serve both as a soundproofing measure and to prevent ingress of rain water.

Care of the rubber sealing strips is especially necessary during the winter months to prevent the strips from sticking and tearing when the access panels are opened.

- Lubricate the rubber sealing strips regularly with silicone oil or Vaseline.

## 10.8 Chassis

- Carry out maintenance according to the schedule in chapter 10.3.3.1.

### 10.8.1 Wheel checks

Check the wheels and tyres after the first 50 km and after every wheel change, but at least every six months for tightness, visible damage and tyre pressures.

Material      Torque wrench

                  Tyre pressure gauge

Precondition    The machine is switched off.

1. Check that the wheel fixings are tight.
2. Check the tyres for any defect.  
Replace any damaged or worn tyres.
3. Check the tyre pressures.

Further information    See chapter 2.4.3 for wheel fixing torques.

                      See chapter 2.4.2 for tyre pressures.

### 10.8.2 Towbar maintenance

Clean and lubricate all sliding and rotating bearings as necessary but at least every 6 months.



Material      Lithium enriched multi-purpose grease

                  Acid-free oil

                  Cleaning cloths

Precondition    The machine is shut down.

                      The machine is disconnected from the towing vehicle and safely parked.

**Option sa**


10-M0159

**Fig. 73 Overrun braking mechanism maintenance**

- 1 Handle  
2 Transfer cable

- 3 Oil points (option sa)  
4 Greasing points

#### 10.8.2.1 Check the towbar

1. Check the towbar for correct function and movement.
2. Clean and oil all sliding and rotating bearings.

**Option sa Check the height setting of the towbar**

- Check the towbar height setting.



The locking teeth on the towbar height adjustment joint are corroded and jammed and the towbar height cannot be adjusted.

- If necessary, free the teeth by jerking the towbar horizontally and vertically.
- Clean the toothed coupling and smear with water-repellent grease.

**Option sa, sd Maintaining the parking brake**

- Lightly lubricate the pins and adjustment joints.

#### 10.8.2.2 Overrun braking mechanism maintenance

##### Overrun braking mechanism greasing

- Pump fresh grease into the nipple until old grease is squeezed out.

**Further information** For greasing points see figure 73.

##### Checking the shock absorber


1. Loosen the transfer cable one side.
2. Press in the shock absorber against its damping force.

Have the shock absorber replaced by a specialist workshop if:

- there is little resistance to pushing in,
- air has entered the device,
- there is little resistance to pulling out,
- oil leaks out.

**10.8.2.3 Ball coupling maintenance**


Option sa, sd



10-M0551

Fig. 74 Ball coupling maintenance

Option sh



10-M0558

Fig. 75 Ball coupling maintenance (USA version)

- ① Lubricating points
- ② Greasing points

1. Check the ball coupling for correct function and movement.
2. Clean the ball coupling. Grease or oil the ball cup, joints and bearings.

**10.8.3 Brake maintenance**

The brake adjusting procedure ensures even wear on the brake linings.

The following points must be observed:

- Carry out the adjustment procedure on all wheel brakes, one after the other.
- During adjustment, turn the wheel in the 'forward' direction only.

Material Screwdriver

Torch

Lithium enriched multi-purpose grease

Precondition The machine is switched off.

1. Jack up the machine and lower it onto supports.
2. Release the parking brake and pull out the overrun braking mechanism fully.  
There is no braking effect applied.

### 10.8.3.1 Checking brake adjustment

1. Pull up the parking brake to first notch.
2. Turn the wheels in the forward direction.
3. Check that there is the same braking resistance on both wheels.  
If the resistance is not the same, the brakes must be adjusted.
4. Release the parking brake.

### 10.8.3.2 Checking brake lining wear




Fig. 76 Checking the brake lining thickness


- ① Inspection hole
- ② Brake linings

1. Remove the plug from the inspection hole.
2. With the aid of a torch, check the brake lining thickness.  
Have the brake linings replaced by a specialist workshop if they are less than 2 mm thick.
3. Replace the plug in the inspection hole.

### 10.8.3.3 Brake adjustment

There is an arrow pressed into the brake back plate near the adjustment hole.

- Turning in the direction of the arrow increases brake force.
- Turning in the opposite direction to the arrow releases brake force.


**Fig. 77 Brake adjustment**

- |          |                               |          |                          |
|----------|-------------------------------|----------|--------------------------|
| <b>①</b> | Wheel brakes                  | <b>④</b> | Equaliser                |
| <b>Ⓐ</b> | Brake adjustment              | <b>⑤</b> | Brake rod tensioning nut |
| <b>②</b> | Screwdriver as adjusting tool | <b>⑥</b> | Brake rod                |
| <b>③</b> | Adjusting wheel               | <b>⑦</b> | Cable tensioning nut     |
| <b>Ⓑ</b> | Brake rod adjustment          | <b>⑧</b> | Brake cable (Bowden)     |

1. Remove the plug from the adjustment hole.
2. Use a screwdriver to turn the adjusting wheel ③ until the wheels no longer turn in the forward direction.
3. Apply the parking brake a number of times to centralise the brake linings.
4. Use the screwdriver to turn the adjusting wheel back (3 to 5 notches) until there is no more braking resistance to the wheels turning forward.
5. Pull on the parking brake.
6. Check the position of the equaliser ④ on the brake rod ⑥.  
If the equaliser is perpendicular to the brake rod, the brake clearance is the same on each wheel.  
If the equaliser is not perpendicular, adjust the brakes again.
7. Pull the parking brake lightly on and compare the braking force on the wheels.  
If the braking force on the wheels is not equal, the brakes must be adjusted again.
8. Replace the plug in the adjustment hole.



A light rubbing sound when the wheels turn is permissible if it does not affect free turning.

#### Brake rod adjustment

1. To loosen the braking rod ⑥ undo the nut ⑤ on the equaliser ④.
  2. Grease the brake rod threads.
  3. Adjust the rod so there is no play or tension.  
The equaliser is perpendicular to the brake rod.
  4. Tighten the nut.
  5. Tighten all counter nuts.
- Test by applying the brake a number of times.

**10.8.3.4 Greasing the brake rods**

Grease the brake rods when necessary (stiff movement) but at least annually.

Material      Lithium enriched multi-purpose grease  
                   Cleaning cloths

Precondition    The machine is shut down.  
                   The machine is disconnected from the towing vehicle and safely parked.  
                   ➤ Clean and grease the brake rods sliding and adjustment joints.

**10.9 Options**


➤ Carry out maintenance according to the schedule in chapter 10.3.3.2.

**10.9.1 Option da, db, dc, dd**
**Cyclone separator maintenance**

Clean the cyclone separator dirt trap if the moisture content in the compressed air is too high.

Material      Cleaning cloths  
                   Dirt trap maintenance kit

Precondition    The machine is shut down.  
                   Machine cooled down.  
                   The machine is fully vented, the pressure gauge reads 0 bar.  
                   All compressed air consumers are disconnected and the air outlet valves are open.  
                   The «battery isolating switch» is off.



10-M0391

**Fig. 78 Cleaning the dirt trap**

- |     |                       |     |                                 |
|-----|-----------------------|-----|---------------------------------|
| [1] | Cyclone separator     | [5] | Sealing ring                    |
| [2] | Dirt trap             | [6] | Strainer                        |
| [3] | Condensate drain hose | [7] | Condensate drain hose union nut |
| [4] | Screw plug            | [8] | Nozzle                          |

**Cleaning the dirt trap**

1. Open the right-hand access door.
2. Unscrew the plug ④ and remove the strainer ⑥ from the dirt trap ②.
3. Loosen the union nut ⑦ and detach the condensate drain hose ③ from the dirt trap
4. Unscrew the nozzle ⑧ from the dirt trap housing and clean.
5. Check the nozzle for function and wear.  
Renew if non functional.
6. Clean the dirt trap housing, plug and sealing ring ⑤.
7. Clean the strainer.
8. Check the strainer and sealing ring for function and wear.  
Renew if non functional.
9. Replace the strainer in the dirt trap and screw in the plug.
10. Screw in the nozzle and re-attach the condensate drain hose.
11. Switch the «battery isolating switch» on.
12. Close the access door.

**Function and leakage check**

1. Start the machine and run for approximately 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Open the outlet valves.
5. Check the cyclone separator housing and hose line for leaks.

**10.9.2 Option dd  
Combination filter maintenance**


Precondition The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
All compressed air consumers are disconnected and the air outlet valves are open.

**WARNING**

Danger of injury from compressed air!

The combination filter is under pressure when operating; serious injury can result from loosening or opening components under pressure.

- Make sure there is no electrical power present on the machine. Check that the pressure gauge reads 0 bar.
- Depressurise the combination filter.

**Option dd**


10-M0168

**Fig. 79 Combination filter maintenance**

- |  |  |
|--|--|
| [1] Filter combination                         | [5] Pressure differential gauge (check fittings for Service personnel) |
| [a] Fine filter                                | [6] Filter head  |
| [b] Microfilter                                | [7] Casing gasket  |
| [2] Cyclone separator                          | [8] Filter element   |
| [3] Drain valve (ball) for condensate drainage | [9] Filter housing   |
| [4] Condensate drain hose fittings             |  |

- Open the right-hand access door.

#### 10.9.2.1 Draining condensate

Material Receptacle

Cleaning cloths

1. Place the receptacle under the combination filter hose lines.
2. Open the prefilter and microfilter condensate drain valves.
3. Close the access door.
4. Start up the compressor and run in idle.  
The condensate collecting in the filter housings is blown out.
5. Stop the compressor as soon as air escapes.
6. Open the right-hand access door.
7. Close the drain valve.
8. Close the access door.



Condensate must be stored in suitable containers and disposed of in accordance with local environmental regulations.

**10.9.2.2 Changing the filter elements**

Material    Spares  
              Filter wrench  
              Wrench  
              Cleaning cloths

Precondition    Machine cooled down.  
                  The «battery isolating switch» is off.

**Ensure that the combination filter is not under pressure.**

- Slowly open the prefilter and microfilter condensate drain valves.  
Remaining pressure escapes.

**Changing the filter elements**

Do not touch the filter element foam jacket with bare fingers!

1. Unscrew and remove the drain hoses from the filter housings.
2. Unscrew the filter housing anti-clockwise.
3. Draw the filter element down and out.
4. Clean the filter head, housing and sealing surface with a lint-free cloth.
5. Check the housing gasket.  
Change if damaged.
6. Insert a new filter element.
7. Screw on the filter housing clockwise.
8. Screw on the condensate drain hoses.
9. Close the drain valve.
10. Tighten the filter combination fittings.
11. Switch the «battery isolating switch» on.
12. Close the access door.

Further information    Further information on changing elements can be found in the filter instructions in chapter 13.15.


**Function and leakage check**

1. Start the machine and run for approximately 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Open the outlet valves.
5. Check the combination filter housing and hose lines for leaks.

**10.9.3 Option dc**
**Breathing air filter maintenance**

When working on the breathing air filter, follow the Operating instructions for compressed air filter (breathing air filter) given in chapter 13.16.

- Precondition
- The machine is shut down.
  - The machine is standing level.
  - The machine is fully vented, the pressure gauge reads 0 bar.
  - All compressed air consumers are disconnected and the air outlet valves are open.

**Option dd**

**Fig. 80 Breathing air filter maintenance**

- |     |  |     |  |
|-----|--|-----|--|
| [1] | Breathing air filter                         | [5] | Upper element (adsorption element)       |
| [2] | Lower housing                                | [6] | Upper housing                            |
| [3] | Lower filter element (high capacity element) | [7] | Condensate drain with manual opening tap |
| [4] | Body   |     |  |

- Open the right-hand access door.

**10.9.3.1 Draining condensate**

- Material

Receptacle

Cleaning cloths

1. Place the receptacle below the breathing air filter condensate drain point.
2. Open the breathing air filter drain tap.
3. Close the access door.
4. Start up the compressor and run in idle for about 2 minutes..  
The condensate collecting in the filter housings is blown out.
5. Shut down the machine.
6. Open the right-hand access door.
7. Close the drain tap.
8. Carefully remove the receptacle.
9. Close the access door.



Condensate must be stored in suitable containers and disposed of in accordance with local environmental regulations.

### 10.9.3.2 Changing the filter elements

The breathing air filter contains two different element and both must be changed as a pair. Note location.



Do not touch the filter element with bare fingers!

Material      Spares  
                  Filter wrench  
                  Cleaning cloths

Precondition      Machine cooled down.  
                      The «battery isolating switch» is off.

- Open the right-hand access door.
- 1. Open the breathing air filter drain tap to release any remaining pressure.
- 2. Change the lower filter element (high performance element)
  - Unscrew the lower housing anti-clockwise.
  - Draw the filter element down and out.
  - Clean the lower housing and sealing surface with a lint-free cloth.
  - Check the housing gasket.  
Change if damaged.
  - Insert a new lower filter element.
  - Screw on the lower housing clockwise.
- 3. Change the upper filter element (adsorption insert).
  - Unscrew the upper housing anti-clockwise.
  - Draw the filter element up and out.
  - Clean the lower housing and sealing surface with a lint-free cloth.
  - Check the housing gasket.  
Change if damaged.
  - Insert a new filter element.
  - Screw on the upper housing clockwise.
- 4. Close the drain tap.

Further information      Further information on changing elements can be found in the operating instructions in chapter 13.16.  
  
1. Switch the «battery isolating switch» on.  
2. Close the access door.

#### Function and leakage check

1. Start the machine and run for approximately 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Open the outlet valves.
5. Check the breathing air filter housing and hose line for leaks.

**10.9.4 Option ga**
**Generator drive belt maintenance**

Correct belt tension is extremely important for the function of the generator and the operational life of the belts themselves. The life of the drive belts is influenced by belt tension.

- Slack V-belts can cause belt slip and damage to the belts.
- Over-tight belts stretch and fatigue quicker. Over-tight belts also place unnecessary stress on bearings and shorten their life.

Material Spare parts (if required)


Precondition The machine is shut down.  
 The machine is fully vented, the pressure gauge reads 0 bar.  
 Machine cooled down.  
 All compressed air consumers are disconnected and the air outlet valves are open.  
 The «battery isolating switch» is off.


**WARNING**

Beware of rotating pulleys and moving belts.

Touching moving drive belt may result in severe bruising or even loss of limb or extremities.

- Check the belt only when the compressor is shut down.
- Never run the machine without a belt guard.



10-M0298

**Fig. 81 Generator belt tensioning**

- |                                    |                           |
|------------------------------------|---------------------------|
| [1] Support for belt tensioner     | [8] Generator swing frame |
| [2] Hexagon nut                    | [9] Belt adjustment       |
| [3] Spherical seat washer          | [10] Compression spring   |
| [4] Conical seat washer            | [11] Self-locking nut     |
| [5] Hexagon nut (locknut)          | [12] Generator            |
| [6] Drive belt (multi-ribbed belt) | [A] Tensioning dimension  |
| [7] Generator drive pulley         |                           |

- Open the left-hand door.

**10.9.4.1 Make a visual check for belt damage**

1. Remove the belt guard.
2. Check the drive belt for cracks, frays or stretching.  
Change the belt immediately if any damage is found.
3. Replace the belt guard.
4. Switch the «battery isolating switch» on.
5. Close the access door.

**10.9.4.2 Checking belt tension**

Check belt when it is warm, not hot, to avoid length variations through temperature.

The tensioning device uses spring force to apply correct tension to the belts over a certain range. The tensioning dimension **A** is checked when checking belt tension.

Tensioning dimension:

- **Separation:** 10 mm
- **Minimum separation:** 5 mm

1. Check the tensioning distance **A** on the belt adjustment **⑨**.  
Re-tension the belts if the tensioning dimension is below the minimum.
2. Switch the «battery isolating switch» on.
3. Close the access door.

**10.9.4.3 Belt tensioning**

1. Loosen the locking nut **②**.
2. Turn the tensioning nut **⑤** to tighten the belts **⑥** until the correct tensioning dimension **A** is reached.
3. Tighten the locknuts **②** and **⑤**.
4. Switch the «battery isolating switch» on.
5. Close the access door.

**10.9.4.4 Changing the belt**

1. Remove the belt guard.
2. Undo the nut **⑤** until the belt **⑥** can be slipped off the pulleys.
3. Take off the belt.
4. Check the pulleys for dirt and wear.  
Clean the pulleys.  
Change the pulley.
5. Place the new belt over the pulleys.
6. Turn the tensioning nut **⑤** to tighten the belts **⑥** until the correct tensioning dimension **A** is reached.
7. Tighten the locknuts **②** and **⑤**.
8. Replace the belt guard.
9. Switch the «battery isolating switch» on.

10. Close the access door.
11. Run the compressor under LOAD for 15–20 minutes.
12. Check the belt again and re-tension if necessary.



- Check the belt again after a further 2 operating hours.
- A belt that has been replaced may not be used again.



Old belts should be disposed of in accordance with local environment regulations.

## **10.10 Document maintenance and service work.**

Machine number:

- Enter maintenance and service work carried out in the list.

Tab. 90 Logged maintenance tasks

# 11 Spares, Operating Materials, Service

## 11.1 Note the Nameplate

The nameplate contains all information to identify your machine. This information is essential to us in order to provide you with optimal service.

- Please give the information from the nameplate with every enquiry and order for spares.

## 11.2 Ordering consumable parts and operating materials

KAESER consumable parts and operating materials are all genuine KAESER parts. They are selected for use in KAESER machines.



### WARNING

There is risk of personal injury or damage to the machine resulting from the use of unsuitable spare parts or operating materials.

Unsuitable or poor quality consumable parts and operating materials may damage the machine or impair its proper function.

In the event of damage, personal injury may result.

- Use only genuine KAESER spares and operating materials.
- Have an authorized KAESER Service Technician carry out regular maintenance.

### Compressor

Name	Quantity	Number
Air filter element	1	1260
Oil filter	1	1210
Oil separator cartridge set	1	1450
Cooling oil	1	1600

Tab. 91 Compressor consumables

### Deutz engine parts

Name	Quantity	Number
Air filter element	1	1280
Fuel prefilter insert	1	1915
Main fuel filter cartridge	1	1920
Oil filter	1	1905
Oil drain plug sealing ring	1	4496
Injector nozzle	1	4475
Injector sealing ring	1	4476
V-belt	1	4470
Engine oil	1	1925

Tab. 92 Consumable engine parts

## **11.3 KAESER AIR SERVICE**

KAESER AIR SERVICE offers:

- Authorized service technicians with KAESER factory training.
  - Increased operational reliability ensured by preventive maintenance.
  - Energy savings achieved by avoidance of pressure losses.
  - The security of genuine KAESER spare parts.
  - Increased legal certainty as all regulations are kept to.
- Why not sign a KAESER AIR SERVICE maintenance agreement.  
The advantages:  
Lower costs and higher compressed air availability.

## **11.4 Service Addresses**

Addresses of KAESER agents are given at the end of this manual.

## 12 Decommissioning, Storage and Transport

### 12.1 De-commissioning

De-commissioning is necessary, for example, under the following circumstances:

- The machine is temporarily not needed
- The machine will not be needed for a considerable time.
- The machine is to be scrapped.

Precondition The machine is shut down.

Machine dry and cool.

1. Carry out the following de-commissioning procedures.
2. Place a notice on the instrument panel describing the de-commissioning procedures carried out.

#### 12.1.1 Temporary decommissioning

Decommissioning for about 4 months.

Material Plastic foil

Moisture-resistant adhesive tape

1. Disconnect the battery (the minus terminal first and then the plus terminal).
2. Close off the following openings with plastic foil and moisture-resistant adhesive tape.
  - Engine air inlet
  - Compressor air inlet
  - Exhaust
3. Hang the following notice on the instrument panel informing of the decommissioning measurements taken.

#### Attention!

1. The machine is temporarily decommissioned.
  2. The following machine openings have been covered:
    - Engine air inlet
    - Compressor air inlet
    - Exhaust
  3. Recommission according to service manual.
- Date / signature

Tab. 93 "Temporarily decommissioned" information notice

#### Decommissioning of the compressor for several weeks during severe frost



#### CAUTION

Danger of batteries freezing.

Discharged batteries are subject to frost damage and can freeze at -10 °C.

- Store batteries in a frost-free place.
- Store batteries preferably fully charged.

1. Remove the battery (batteries) and store in a frost-free room.
2. Make sure batteries are fully charged.

### 12.1.2 Long-term decommissioning

Decommissioning the machine for 5 months or longer.

Material	Receptacle Preserving oil Preservative Desiccant Plastic sheeting Moisture-resistant adhesive tape
----------	---

- The following measures must be taken for long-term decommissioning.

Long-term decommissioning tasks	See chapter	Confirmed?
➤ Check engine coolant.	10.4.1	
➤ Drain the engine oil.	10.4.6	
➤ Drain the oil from the oil separator tank and the oil cooler.	10.5.3	
➤ Fill the separator tank and engine with preserving oil.	10.5.2	
	10.4.5	
➤ Run the machine for about 10 minutes to coat all parts with a protective oil film.	–	
➤ Disconnect the battery, the minus terminal first and then the plus terminal, and store in a frost-free room.	–	
➤ Check the battery fluid level.	10.7	
➤ Check the battery charge monthly and recharge if necessary to prevent the battery fluid freezing.	–	
➤ Clean the battery terminals and coat with acid-resistant grease.	–	
➤ Close the compressed air outlet valves.	–	
➤ Use plastic sheeting and moisture-resistant adhesive tape to seal off the following openings: – Engine air intake – Compressor air intake – Exhaust outlet	–	
➤ Clean the bodywork and treat with preservative.	–	
➤ Hang a notice on the instrument panel informing of the decommissioning measurements taken.	–	

Tab. 94 Long-term decommissioning checklist

- Hang the following notice on the instrument panel informing of the decommissioning measurements taken.

**Attention!**

1. The machine is decommissioned.
2. It is filled with preserving oil.
3. For recommissioning:
  - Take measures for recommissioning after a long period of storage.
  - Recommission according to service manual.

Date / signature

Tab. 95 Text for the long-term decommissioned information notice

- Store in a dry place with even temperature.

## **12.2 Transporting**

Precondition	Machine switched off and locked off («battery isolating switch» off) All connecting lines and hoses disconnected and removed. Any loose or movable parts that may fall when transporting, removed or secured. Allow transportation only by personnel trained in safely dealing with motor vehicles and the transporting of goods.
--------------	--

**WARNING**

There is danger of being run over or crushed by an overturning vehicle.  
Death or serious injury can result from being crushed or run-over by a machine under tow.  
➤ Riding on the machine while it is under tow is strictly forbidden.

- Make sure the danger area is clear of personnel.

### **12.2.1 Towing the compressor on the road**

This Mobilair compressor is approved for towing on public roads. The machine is designed for a maximum towing speed of 100 km/h. National and local regulations must be observed when towing the machine on public highways.

**Additional loading**

Do not exceed the permissible loading (overall weight, coupling load, axle load).  
Observe national traffic laws. If additional loading is not permitted, the load must go to the towing vehicle.

1. Check that loading the machine with tools or accessories during transport is permissible.
2. Place additional loads only in the spaces provided and secure carefully.

**Additional precautions for conditions of snow and ice**

Considerable snow or ice may build up on the machine under low temperature conditions.

**CAUTION**

There is danger of accidents caused by snow or ice falling off the machine.  
Snow or ice falling from the towed machine can endanger following vehicles.  
Problems with driving dynamics and damage to the machine could occur.  
The maximum permissible axle load could be exceeded.

- Do not tow the machine if it is coated in snow or ice.


- Remove any snow or ice before towing.

**Observe / carry out the following before towing:**

1. Make sure the towing hitch is compatible with the ball or eye coupling on the towed machine.
2. Check that the machine is shut down and secured against accidental restarting.
3. Detach all connecting lines and hoses.
4. Make sure there are no unsecured tools lying on or in the machine.
5. Close and lock the access doors.

**Option sa Adjust the towbar to suit the height of the towing vehicle hitch.**

When the machine is coupled up, the towbar must be parallel with the ground.



12-M0148

Fig. 82 Towing alignment

**WARNING**

Danger from problematic driving dynamics!  
The permissible loading range may be exceeded or undercut.  
Personal injury may result from towing.

Damage to the machine and/or towing vehicle is possible.

- Do not couple up the machine at an angle to the towing vehicle.
  - Ensure that the towbar is horizontal when coupled to the towing vehicle.
- 
- Adjust the towbar height to suit the height of the hitch on the towing vehicle.

Further information See chapter 6.4.1 for towbar height adjustment.

**Option sa, sd Coupling-up**

To couple up the machine, lower the open coupling onto the ball of the towing vehicle so that it clicks into place. The coupling is fully locked when the green locking indicator protrudes and is visible from the side.




Fig. 83 Ball coupling (ALKO-EU)

- |                     |                                    |
|---------------------|------------------------------------|
| [1] Coupling handle | [3] Towing vehicle ball hitch      |
| [2] Ball coupling   | [4] Locking indicator (protruding) |



#### CAUTION

There is considerable danger of injury caused by trapped fingers.  
They can be trapped in the spring-loaded closing mechanism.

- Never place your fingers inside an open ball coupling.
- Always wear protective gloves.

1. Pull up the coupling release lever.  
The coupling opens.



#### WARNING

Danger of accident from an incorrectly closed ball coupling.  
If the coupling is not fully closed the compressor can become uncoupled from the towing vehicle and cause an accident.

- Check correct coupling.

2. Place the open coupling over the towing vehicle ball hitch.  
The weight on the coupling will cause it to audibly close. The coupling locks automatically. Closing and locking is automatic.
3. Push the release lever down to be certain of locking.  
The coupling is fully locked when the release lever is fully down and can be pushed no further.
4. Check correct coupling.
  - Check that the coupling handle cannot be pushed further down.
  - Check that the locking indicator is protruding and visible.




The locking indicator is not visible.

- Lift the handle and uncouple.
- Set the coupling back on the towing vehicle ball hitch and push down.

#### Option sh Coupling-up

To couple up the compressor, lower the open coupling onto the ball hitch of the towing vehicle so that it clicks into place.

Option sh



12-M0331

Fig. 84 Ball coupling (ALKO-USA)

- |                               |                                      |
|-------------------------------|--------------------------------------|
| [1] Coupling handle           | [4] Security pin                     |
| [2] Ball coupling             | [5] Fixing hole for the security pin |
| [3] Towing vehicle ball hitch | [6] Ball coupling properly secured   |



#### CAUTION

There is considerable danger of injury caused by trapped fingers.  
They can be trapped in the spring-loaded closing mechanism.

- Never place your fingers inside an open ball coupling.
- Always wear protective gloves.

1. Check if the security pin is removed from the coupling and draw it out if not.
2. Pull up the coupling release lever.  
The coupling opens.



#### WARNING

Danger of accident from an incorrectly closed ball coupling.  
If the coupling is not fully closed the compressor can become uncoupled from the towing vehicle and cause an accident.

- Check correct coupling.
- Check correct location of the security pin.

3. Place the open coupling over the towing vehicle ball hitch.  
The weight on the coupling will cause it to audibly close. The coupling locks automatically. Closing and locking is automatic.
4. Push the release lever down to be certain of locking.  
The coupling is fully locked when the release lever is fully down and can be pushed no further.
5. Insert the security pin in the ball coupling fixing opening.

Option sa Carry out the following before starting to tow the vehicle:

1. Check that the towbar is adjusted to the correct height. See also chapter 6.4.1.  
Check that:
  - The teeth in the tow bar height adjusting joints are fully engaged
  - The locking levers are tightened
  - The security pin is fully inserted.
2. Wind the jockey wheel to its uppermost position.
3. Check that the wheels are securely fitted and the tyres are in good condition.


4. Check the tyre pressures.
5. Connect the cable for the lighting and indicator systems and carry out a function check.
6. Release the parking brake and remove the chocks from under the wheels.

**Option sd Carry out the following before starting to tow the vehicle:**

1. Wind the jockey wheel to its uppermost position.
2. Check that the wheels are securely fitted and the tyres are in good condition.
3. Check the tyre pressures.
4. Connect the cable for the lighting and indicator systems and carry out a function check.
5. Release the parking brake and remove the chocks from under the wheels.

**Option sh Carry out the following before starting to tow the vehicle:**

Option sh



12-M0393

Fig. 85 Safety sign - secure the chocks



**WARNING**

Missing chocks

Serious injury or death can result from an unchoked machine rolling away.

- Secure the chocks in the transport securing device before transporting the machine.
- Replace missing chocks immediately.

1. Wind the jockey wheel to its uppermost position.
2. Check that the wheels are securely fitted and the tyres are in good condition.
3. Check the tyre pressures.
4. Attach the lighting and indicator systems and carry out a function check.
5. Remove the chocks and secure them in the transport securing device.




Replacement chocks can be obtained from KAESER. A list is given at the end of this manual.  
The part number of the chock is 5.1325.0.

**Option sa, sd Emergency braking in the case of breakaway from the towing vehicle**

If the compressor breaks away from the towing vehicle, the cable tightens and pulls on the emergency brake (parking brake).

It is essential that the breakaway cable is threaded through its guides for correct emergency braking.



12-M0149

Fig. 86 Breakaway cable attachment

- ① Breakaway cable  
 ② Breakaway cable guide (eye)  
 ③ Connection (karabiner)

**CAUTION**

Unintentional brake application.

If the breakaway cable is too short it can apply the brakes when rounding a curve. This imposes high wear on the braking system.

- Make sure the breakaway cable is long enough.

1. Thread the breakaway cable through the guide welded on the side of the towbar.
2. Loop the end of the cable round the towing vehicle hitch and secure with the karabiner.


### 12.2.2 Parking the compressor

The parking brake is not a running brake and is used only to lock the wheels when the machine is positioned.

The machine is generally only moved by being coupled to a towing vehicle.

If the jockey wheel is wound too far out, the spindle can disengage and the towbar fall to the ground.

Precondition The machine is uncoupled from the towing vehicle.



12-M0265

Fig. 87 Injury can occur if the towbar is unsupported and allowed to fall.

**CAUTION**

Injury can occur if the towbar is unsupported and allowed to fall.

A falling towbar can cause injury, especially by crushing the feet.

- Do not wind the jockey wheel completely out when the machine is uncoupled from the towing vehicle.
- Do not wind up the jockey wheel to the stop.

**Option sa, sd Carry out the following when parking the compressor**

When parking on a slope, securely chock the machine before uncoupling.


1. Disconnect the lighting and signalling cable.
2. Pull on the parking brake.
3. Detach the breakaway cable.
4. Wind down the jockey wheel.
5. Place chocks under the wheels.
6. Pull up the parking brake to the stop.
7. Uncouple the compressor from the towing vehicle.
  - Lift up the safety lever and pull the coupling release lever forward.
  - Lift the coupling off the towing hitch ball. The coupling release lever remains in the 'open' position.



The gas spring automatically increases parking brake force if the machine rolls backwards or when parked on a slope.

**Option sh Carry out the following when parking the compressor**

When parking on a slope, securely chock the machine before uncoupling.



12-M0392

Fig. 88 Safety sign - secure the chocks

**WARNING**

Machine without parking brake.

Serious injury or death can result from an unchocked machine rolling away.

- Securely chock the machine before uncoupling.

1. Wind down the jockey wheel.
2. Place chocks under the wheels.
3. Dismantle the lighting and signalling system.

4. Uncouple the compressor from the towing vehicle.
  - Withdraw the security pin from the ball coupling.
  - Pull up the coupling release lever.
  - Lift the coupling off the towing hitch ball.
  - Insert the security pin in the ball coupling fixing opening.

### **12.2.3 Transporting with a crane**

#### **Additional precautions for conditions of snow and ice**

Considerable snow or ice may build up on the machine under low temperature conditions. This may adversely effect the machine's centre of gravity.

It is possible that the permissible loading on the crane or lifting eye is exceeded.

- Additional measures should be taken under conditions of snow or ice.
  - Remove any snow and ice from the machine before lifting by a crane.
  - Make sure the lifting eye cover plate is freely accessible and can be opened.

#### **Carry out the following tasks before transporting the machine**

A lifting eye is provided for transporting with a crane. The lifting eye is located beneath a lift-up cover in the centre of the canopy.

1. Unlock the cover from inside and lift up.
2. Position the crane hook vertically over the lifting eye.
3. Engage the hook in the eye.
4. Close and lock the access doors.
5. Lift the machine carefully.

#### **Take care when setting down the machine**



##### **CAUTION**

Incorrect setting down can damage the machine.

Machine components, particularly the chassis, can be damaged by incorrectly setting down.

- Set the machine down carefully.
  - Do not set down unevenly.
- 
- Set the machine down slowly and carefully.

### **12.2.4 Option sc**

#### **Transporting with a forklift truck**

Precondition

The machine is shut down.

All connecting lines and hoses disconnected and removed.




##### **CAUTION**

Damage to the machine by incorrect lifting with a fork truck.

The machine may fall or be damaged by the forks.

- Do not use a fork truck to lift towable machines.
- Only stationary machines with skids may be lifted with a fork truck.
- Pick up the machine only from the side with the forks through the lifting lugs.

Option sc



12-M0339

Fig. 89 Transporting using a forklift truck

- ① Skids
- ② Lifting lugs

1. Close and lock the access doors or canopy.
2. Position the fork truck to the side of the machine with the forks lined up with the lifting lugs.
3. Drive the forks fully through the lifting lugs as far as possible.  
The forks are fully under the machine.
4. Lift the machine carefully.

### 12.2.5 Transporting as a load

The means of transporting will determine the type of packing and load securing.

Packing and securing methods must be such that, assuming proper handling, the goods arrive in perfect condition at the destination.

Consult KAESER Service for advice concerning sea or air transport.

Material	Chocks Restraints or timber balks Straps
----------	--

#### Load securing devices




National directives and regulations for securing loads should be followed.

Load securing is taken to mean that by full braking or sudden turning the load will not slide, fall, roll or cause unnecessary noise. Accepted technical regulations should be observed (e.g. VDI directive 2700 ff in Germany).

Responsibility for properly secured loads falls on the driver, the vehicle keeper and the carrier.

Use chocks, restrainers or timber balks for securing the load.

If necessary, use straps across the chassis and the towbar.



12-M0856

Fig. 90 Load secured by strapping


**CAUTION**

Braces can damage the bodywork.

Movement during transportation can damage the bodywork.

- Do not use straps over the bodywork.
- Use straps only over the chassis.



Contact KAESER Service with any questions regarding transporting or load securing.

KAESER accepts no liability for damages arising through incorrect transport methods or insufficient or wrong securing of loads.

The transport restraints on rented, hired or exhibition machines should be re-used for the return journey.

**Before shipment as air freight**

The machine is designated as dangerous goods for air freight purposes; any disregard can result in a heavy fine.


**DANGER**

Danger of fire or explosion from operating fluids/materials.

The machine incorporates an internal combustion engine.

- Any dangerous fluids/materials contained within the machine must be removed before transport.

- Remove all dangerous fluids/materials.

These include:

- Residues of fuel or fuel vapours
- Lubricating and cooling oils in the engine and compressor unit
- Battery electrolyte

## 12.3 Storage

Moisture can lead to corrosion, particularly in the engine, airend and oil separator tank.

Frozen moisture can damage components, valve diaphragms and gaskets.



Advice can be obtained from KAESER on storage and commissioning.

**CAUTION**

Moisture and frost can damage the machine.

- Prevent ingress of moisture and formation of condensation.
- Maintain a storage temperature of >0 °C.
- Store the machine in a dry place, free from frost if possible.

## 12.4 Disposal

When disposing of a machine, drain out all liquids and remove old filters.

Precondition The machine is decommissioned.

1. Completely drain the fuel from the machine.
2. Completely drain the cooling oil and engine oil from the machine.
3. Remove used filters and the oil separator cartridge.
4. Drain the coolant from water-cooled engines and systems.
5. Hand the machine over to an authorized disposal expert.



- Parts contaminated with cooling oil or engine oil must be disposed of in accordance with local environment protection regulations.

# 13 Annex

## 13.1 Marking





Fig. 91 Marking


- |   |   |   |  |
|---|---|---|--|
| ① | Machine nameplate with serial number                          | ③ | Combined label for coupling loading and built-in options                       |
| ② | VIN *) (stamped in the bodywork)<br>* Vehicle identity number | ④ | Engine nameplate with serial number (on the cylinder head cover or crankcase). |

## 13.2 Pipeline and instrument flow diagram (P+I diagram)



1	Compressor - Air filter	24	Motor - Air filter
2	Filter maintenance indicator, Compressor -Air filter	25	Filter maintenance indicator, Motor - Air filter
3	Inlet valve	27	Venting valve
3.2	Pressure transducer - Control pressure	28	Fan
4	Airend	29	Exhaust silencer
5	Oil separator tank	30	Coupling
5.2	Screw plug	37	Minimum pressure check valve
5.13	Pressure transducer - Internal pressure	46	Nozzle (Secondary end Proportional controller)
6	Oil reserve	52	Control valve
7	Oil separator cartridge	56	Water cooler
11	Oil filter with screw plug	56.1	Cooling water expansion tank
12	Temperature gauge switch + Indication	56.2	Water filler with plug
13	Pressure relief valve	56.5	Cooling water sight glass
14	Pressure gauge Compressed air - Control panel	56.7	Shut-off valve with hose coupling - Water drain
15	Diesel engine	63	Control valve (Air circulation valve)
16	Oil return line	83.1	Engine air intake shut-off valve (automatic and manual shutoff)
17	Dirt trap	84	Spark arrestor
17.1	Nozzle	Option	
19	Combination valve - Oil temperature controller		
20	Oil cooler	hc	Minimum pressure check valve (without combination filter)
20.1	Shut-off valve with hose coupling - Oil drain	la	Spark arrestor
21	Oil filter	lb	Spark arrestor + Engine air intake shut-off valve (automatic and manual shutoff)
23	Electric proportional controller		

c	b	a	Change	Date	Author	Original	KAESER	KOMPRESSOREN	P&I Diagram legend	
							Mobilair	M 200		
							Ursprung:	FFMM1235T-01016.00	FFMM2005T-01015.00	Blatt 2 E




c		Datum	08.10.2008	P&I Diagram	<b>KAESER</b>
b		Bearb.	Holzauer	KOMPRESSOREN	Mobilair M 135/M 170/M 200
a		Gefr.	Plau		Compressed air outlet-options
	Änderung	Datum	Name	Ersatz für:	Ursprung: FMM120LA0-010101
			Norm	Ersatz durch:	
					FMM200DLA0-01016.00
					Blatt 1
					E

1	2	3	4	5	6	7	8
10	Compressed air distributor	37	Minimum pressure check valve	da	Aftercooler + Centrifugal separator		
32	Air cooler	39	Check valve	db	Heat exchanger		
33	Centrifugal separator	57	Shut-off valve - Venting line	dc	Breathing air filter		
33.1	Dirt trap			dd	Filter combination		
33.2	Nozzle	Option		fa	Direct air flow		
34	Heat exchanger			hd	Minimum pressure check valve (with combination filter)		
34.4	Screw plug - Oil drain						
35	Breathing air filter						
35.1	Hose coupling						
35.2	Nozzle						
36	Filter combination						
36.1	Shut-off valve for condensate drain						


**13.3 Option sa**

**Dimensional drawing, chassis with height-adjustable tow bar**




**13.4 Option sd**

**Dimensional drawing, chassis with fixed height tow bar**








**13.5 Option sh**

**Dimensional drawing, chassis without parking brake**



**13.6 Option sc**







**Dimensional drawings of stationary machine (skids)**



KAESER		KOMPRESSOREN	
2008	Ing	Name	
Gez	10/11	Gieseck Fösel	
Fahr			
Fräsig	18/11	Gieseck Fösel	
		EngGebau 120 DIN A2	Fräsig für
		T 11143 E	4.4.200
		1046975_00	

**13.7 Option si**

**Dimensional drawings of stationary machine (base frame)**


**EINZEILEIT A**
**View X**

**Engine exhaust**
**Control panel**
**Compressed air outlet**

**Detail view A2**

KAESER		KOMPRESSOREN	
T11142 E		Stationary compressor	
M 135 / M 170		M 135	
0946977_00	14.020	0946977_00	14.020

## 13.8 Electrical Diagram

1	2	3	4	5	6	7	8																																								
<b>Electrical diagrams</b>																																															
<b>MOBILAIR M123/M135/M170</b>																																															
<b>DEUTZ TCD Motor with EMR III</b>																																															
<b>and SIGMA CONTROL MOBIL</b>																																															
Manufacturer: KAESER Kompressoren GmbH Postfach 2143 96410 Coburg																																															
The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.																																															
<table border="1"><tr><td>c</td><td></td><td>Datum 01.01.2009</td><td>E</td><td>KAESER</td><td>Cover page</td><td>=</td><td></td></tr><tr><td>b</td><td></td><td>Bearb.</td><td>Weid</td><td>KOMPRESSOREN</td><td>MOBILAIR M123/M135/M170</td><td>+</td><td></td></tr><tr><td>a</td><td></td><td>Gegr.</td><td>Weid</td><td></td><td>Ursprung: af0123_01</td><td></td><td></td></tr><tr><td>A Änderung</td><td>Datum</td><td>Name</td><td>Norm</td><td>Ersatz durch:</td><td>Ersatz für:</td><td></td><td>DFA123.SCM-01230.02</td></tr><tr><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>Bl.</td></tr></table>								c		Datum 01.01.2009	E	KAESER	Cover page	=		b		Bearb.	Weid	KOMPRESSOREN	MOBILAIR M123/M135/M170	+		a		Gegr.	Weid		Ursprung: af0123_01			A Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:		DFA123.SCM-01230.02								Bl.
c		Datum 01.01.2009	E	KAESER	Cover page	=																																									
b		Bearb.	Weid	KOMPRESSOREN	MOBILAIR M123/M135/M170	+																																									
a		Gegr.	Weid		Ursprung: af0123_01																																										
A Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:		DFA123.SCM-01230.02																																								
							Bl.																																								
c		Datum 01.01.2009	E	KAESER	Cover page	=																																									
b		Bearb.	Weid	KOMPRESSOREN	MOBILAIR M123/M135/M170	+																																									
a		Gegr.	Weid		Ursprung: af0123_01																																										
A Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:		DFA123.SCM-01230.02																																								
							Bl.																																								

Lfd. Nr. No.	Benennung Name	Zeichnungsnr. Drawing No. (customer)	Zeichnungsnr. (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page		DFA123.SCM-01230.02	1	
2	List of contents		ZFA123.SCM-01230.02	1	
3	Block diagram	general instructions			
4	Block diagram	cabling	UFA123.SCM-01230.02	1	
5	Circuit diagram	Diesel motor	UFA123.SCM-01230.02	2	
6	Circuit diagram	ENR3 Motor connection	SFA123.SCM-01230.02	1	
7	Circuit diagram	ENR3	SFA123.SCM-01230.02	2	
8	Circuit diagram	Control panel	SFA123.SCM-01230.02	3	
9	Circuit diagram	SCM Power supply unit	SFA123.SCM-01230.02	4	
10	Circuit diagram	SCM sensors	SFA123.SCM-01230.02	5	
11	Circuit diagram	SCM inputs	SFA123.SCM-01230.02	6	
12	Circuit diagram	SCM inputs	SFA123.SCM-01230.02	7	
13	Circuit diagram	SCM outputs	SFA123.SCM-01230.02	8	
14	Circuit diagram	SCM outputs	SFA123.SCM-01230.02	9	
15	Circuit diagram	SCM outputs	SFA123.SCM-01230.02	10	
16	Circuit diagram	Volt-free contacts	SFA123.SCM-01230.02	11	
17	Electrical equipment identification		SFA123.SCM-01230.02	12	
18	Equipment parts list	control cabinet	GFA123.SCM-01230.02	20	
19	Terminal schedule	standard	KFA123.SCM-01230.02	1	
20	Terminal schedule	standard	KFA123.SCM-01230.02	1	
21	Terminal schedule	Automatic-start-stop	KFA123.SCM-01230.02	2	
22	Component layout	standard	KFA123.SCM-01230.02	3	
23	Component layout	Automatic-start-stop	AFA123.SCM-01230.02	1	
			AFA123.SCM-01230.02	2	

c	Datum	Bearb.	01.01.2009	KAESER	List of contents
b			Weid	KOMPRESSOREN	MOBILAIR SCM & EMR III
a			Weid	Ersatz durch:	Ursprung: af0123_01
				ZFA123.SCM-01230.02	Blatt 1 Bl.

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---

### general instructions

Control voltage: 24VDC

control cabinet wiring for non-designated conductors

 primary circuits: black  
 Control voltage DC: 1,5mm<sup>2</sup> H05V2-K/UL/CSA blue

 external voltage: 1,5mm<sup>2</sup> H07V2-K/UL/CSA orange

 measuring circuits: 1,0mm<sup>2</sup> H05V2-K/UL/CSA violet

earth conductor: green/yellow

wiring colors:

bl = blue

bn = brown

ge = yellow

gn = green

gng = green-yellow

gr = grey

or = orange

rs = pink

rt = red


sw = black


vi = violet


ws = white


 All control lines marked a) are 1,0 mm<sup>2</sup> H05V-K/UL blue


c	Datum	01.01.2009	Bearb.	Weid	=
b			Gegr.	Weid	+
a	Datum	Name	Ersatz durch:	Ersatz für:	Kaft 1
C Änderung	Datum	Norm		Ursprung:	Bl.







































## Service Manual Screw Compressor M135 SIGMA CONTROL MOBIL


No.: 9\_6975 00 E

## 1) model-dependent components









**13.9 Option tc  
Lighting and signalling system connection**


Electrical Dis-


MOBILAIR


**Lighting equipment connection 12V / 13-pole**

Manufacturer: Kaeser Kompressoren GmbH  
Postfach 2143  
96410 Coburg

The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.








**13.10 Option te  
Lighting and signalling system connection**

1	2	3	4	5	6	7	8
<b>Electrical diagrams</b> <b>MOBILAIR</b> <b>DOT-Lighting equipment</b>							
c		Datum	10.06.1999	E			=
b		Bearb.	Rauß				+
a		Gegr.	Schmidt				
d Änderung	Datum	Name	Nom	Ersatz durch:	Ersatz für:	Ursprung:	Blatt 1 Bl.

Cover page		
MOBILAIR	DOT-Lighting equipment	8.6514.0 DFAUSA.BEL-000909.00





**13.11 Option ga  
Generator electrical diagram, 400 V, 3-ph**


1		2		3		4		5		6		7		8
<b>Electrical diagrams</b>														
<b>Synchronous generator</b>														
<b>400V / 3~/50Hz, 15/23 kVA</b>														
<b>with Insulation monitoring</b>														
Manufacturer: KAESER Kompressoren GmbH Postfach 2143 96410 Coburg														
The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.														
c			Datum 05.01.2009	E										
b			Bearb.	Weid										
a			Gegr.	Weid										
A Änderung	Datum	Name	Norm		Ersatz durch:	Ersatz für:								
Kaeser Kompressoren														
Cover page KWG generator 230/400V														
Ursprung: AG0921.02														
Blatt 1														
DGENKWG.4.S4-00929.00														
Bl.														


Lfd. Nr. No.	Benennung Name	Zeichnungsnr. Drawing No. (customer)	Zeichnungsnr. (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page		DGENKKG 4S4-00929.00	1	
2	List of contents		ZGENKKG 4S4-00929.00	1	
3	Circuit diagram		SGENKKG 4S4-00929.00	1	
4	Circuit diagram	Insulation monitoring	SGENKKG 4S4-00929.00	2	
5	Circuit diagram	socket panel	SGENKKG 4S4-00929.00	3	
6	Circuit diagram	socket panel	SGENKKG 4S4-00929.00	4	
7	Electrical equipment identification		SGENKKG 4S4-00929.00	01	
8	Equipment parts list		EGENKKG 4S4-00929.00	1	
9	Terminal schedule	Terminal strip	KGENKKG 4S4-00929.00	1	
10	Component layout	front plate 16A 230/400V	AGENKKG 4S4-00929.00	1	
11	Component layout	front plate 32A 230/400V	AGENKKG 4S4-00929.00	2	

c		Datum 05.01.2009		=
b		Bearb. Weid		+
a		Gegr. Weid		
B Änderung	Datum	Name	Nom.	Ersatz durch:
				Ursprung: AGEN0921_02
				ZGENKKG 4S4-00929.00
				Blatt 1 Bl.









1	2	3	4	5	6	7	8
-A3	generator-Regulator						
-F01	Cut-out with overcurrent release						
-F03	Insulation monitoring						
-G3	generator						
-H03	Earth leak lamp						
-Q1	Main switch						
-S3	Test button, Insulation monitoring						
-S10	Selector switch						
-X4	Terminal strip socket panel						
-X5	Socket outlet 400V/3~/N/PE						
-X6,-X7	Socket outlet 230V/1~/N/PE						
<b>model-dependent components</b>							
-X8	Socket outlet 230V/1~/N/PE (generator 15kVA)						
-X8	Socket outlet 400V/3~/N/PE (generator 23kVA)						
c		Datum 05.01.2009					=
b		Bearb. Weid					+
a		Gepr. Weid					
E Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:	Ursprung: AG00921_02	Blatt 01 Bl.
						SGENKW/G.4.S4-00929.00	

13 Annex

### 13.11 Generator electrical diagram, 400 V, 3-ph

Bei der Nachbestellung von Geräten und Maschinen sind alle in den stark umrandeten Spalten B und C angegebenen Daten zu berücksichtigen. Da in den Spalten D bis G sind unter Kenntnis dieser Gefährlichkeits-Nummer die Anforderungen erfüllt werden müssen, sofern sie die Beantwortung technischer Rückfragen erleichtern. Für Ersatzbestellung ist zusätzlich die Angabe der Serialnummer erforderlich, falls diese auf dem Typenschild des Erzeugnisses genannt ist.


When reordering the equipment, all data enclosed by the heavy lines of columns B and C should be stated. In addition, the data in columns D to G should be given together with the No. of this list of equipment, insofar as they will be helpful in answering Technical enquiries. When ordering spare parts, also quote the serial No. of the product if stated on the rating plate.


\*) Versandanschrift - Kennzeichen

In case of enquiry, the serial No. or equipment number as given on the rating plate should be given together with the no. or name of the dealer from whom it was purchased.

The German version applies in cases of doubt.








**13.12 Option ga  
Generator electrical diagram, 230 V, 3-ph**


1		2		3		4		5		6		7		8
<b>Electrical diagrams</b>														
<b>Synchronous generator</b>														
<b>230V/3~/50Hz, 15 kVA</b>														
<b>with Insulation monitoring</b>														
Manufacturer: KAESER Kompressoren GmbH Postfach 2143 96410 Coburg														
The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.														
c			Datum 05.01.2009	E										
b			Bearb.	Weid										
a			Gegr.	Weid										
A Änderung	Datum	Name	Norm		Ersatz durch:	Ersatz für:								
=														
+														
Blatt 1														
Bl.														
DGENKWG.2S3-00930.00														


Lfd. Nr. No.	Benennung Name	Zeichnungsnr. Drawing No. (customer)	Zeichnungsnr. (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page		DGENKKWG.253-00930.00	1	
2	List of contents		ZGENKKWG.253-00930.00	1	
3	Circuit diagram		SGENKKWG.253-00930.00	1	
4	Circuit diagram	Insulation monitoring	SGENKKWG.253-00930.00	2	
5	Circuit diagram	socket panel	SGENKKWG.253-00930.00	3	
6	Electrical equipment identification		SGENKKWG.253-00930.00	01	
7	Equipment parts list		GGENKKWG.253-00930.00	1	
8	Terminal schedule	Terminal strip -X4	KGENKKWG.253-00930.00	1	
9	Component layout	front plate 32A 230V	AGENKKWG.253-00930.00	1	

c		Datum 05.01.2009		=
b		Bearb. Weid		+
a		Gepr. Weid		
B Änderung	Datum	Name	Nom.	Ersatz durch: Ursprung: A&E0929_00 Ersetzt für: Ursprung: A&E0930_00

ZGENKKWG.253-00930.00  
Blatt 1  
Bl.







Function:

Group of functions:	socket panel		socket panel	
c		Datum 05.01.2009 Bearb. Weid		Circuit diagram KWG generator 230V
b				=
a				+
d Änderung	Datum	Name	Ersatz durch: Ursprung: AEG0929_00	SGENKWG.2S3-00930.00 Blatt 3 Bl.

1	2	3	4	5	6	7	8
-A3	generator-Regulator						
-F01	Cut-out with overcurrent release						
-F02	Cut-out						
-F03	Insulation monitoring						
-G3	generator						
-H03	Earth leak lamp						
-Q1	Main switch						
-S3	Test button, Insulation monitoring						
-S10	Selector switch						
-X4	Terminal strip socket panel						
-X5,-X8	Socket outlet 230V/3~/N/PE						
-X6,-X7	Socket outlet 230V/1~/N/PE						

c		Datum 05.01.2009		=
b		Bearb. Weid		+
a		Gehr. Weid		
E Änderung	Datum	Name	Nom.	Ersatz durch: Ursprung: AGE0929_00 Blatt 01 Bl.

SGENKWG 2S3-00930.00
----------------------

Bei Nachbestellung von Geräten und Maschinen sind alle in den Spalten B und C angegebenen Daten zu übertragen. Die Daten in Spalte D bis G sind zusätzlich unter Bezeichnung einer Gepräzisierten Nummer auszufüllen. Diese Bezeichnung ist für die Erhaltungstechnik erforderlich. Für die Erstauslieferung ist zusätzlich die Angabe der Bestellnummer erforderlich, falls diese auf dem Typenschild des Erzeugnisses genannt ist.

When reordering the equipment all data enclosed by the heavy lines of columns B and C should be stated. In addition, the data in columns D to G should be given together with the No. of this list of equipment, insofar as they are helpful in answering technical enquiries. When ordering spare parts, also quote the serial No. of the product if stated on the parting plate.

1

55

The German version applies in cases of doubt.

gilt die deutsche Fassung


In Zweifelsfällen

- 7 -


Datum 05.01.2009

10

Cable identification		Destination		Terminal strip		KAESER KOMPRESSOREN		Terminal schedule	
Connection number	Component identification	Location	Wire link	Link	Terminal number	Connection number	Component identification	KWG generator 230V	Terminal strip -X4
-Q1	1	-G3	U	N	-G3	W	/22		
-Q1	3	-G3	V	N	-G3	W	/22		
-Q1	5	-G3	U	N	-G3	PE	/22		
-S10	13	-A3	X2:1	1	-A3	X2:2	/22		
-S10	14	-A3	X3:1	3	-A3	X3:2	/22		
-Q1	13	-A3	X3:4	7	-A3	X3:3	/22		
-Q1	14	-A3	X3:6	6	-A3	X3:5	/22		
-Q1	15	-A3	X3:7	7	-A3	X3:8	/22		
total 14 terminals		Terminal strip: -X4		1 2 3 4		5 6 1 2 3 4		Blatt 1	
-W3 Delflex 110 5x6mm <sup>2</sup>		-W3 Delflex 110 7x1mm <sup>2</sup>						Blatt 1	



### **13.13 Fuel circulation diagram**





## 13.14 SIGMA CONTROL MOBIL message codes

Further information See chapter 9.2 for measures to rectify the cause of message codes.

### Construction of message codes

The following is the key to 4-digit message codes.

- Position 1 - type of message:
  - 1 – Alarm
  - 2 – Maintenance
  - 3 – Warning
- Position 2 - location of the cause:
  - 1 – Engine
  - 2 - Compressor unit
  - 3 – Controller
  - 4 – General
- Positions 3 and 4 - numbers from 00 to 99

### Range 1100 - 1199: engine faults

Message code	Meaning
1100	Oil pressure fault.
1101	Oil pressure sensor defective.
1110	Coolant temperature high.
1111	Coolant level too low.
1112	Coolant temperature sensor defective.
1120	Turbo air pressure too high/low.
1121	Turbo air temperature too high.
1122	Turbo air temperature sensor defective.
1123	Turbo air temperature sensor defective.
1130	Fuel level low.
1131	Fuel temperature high.
1132	Fuel pressure low.
1133	Fuel temperature sensor defective.
1134	Fuel pressure sensor defective.
1135	Fuel pump fault..
1140	Defective alternator.
1141	Battery voltage too high/low.
1150	Engine electronics fault.
1151	Fault in the engine electronic communication - engine electronics side.
1152	Fault in the engine electronic communication - ECM side.
1160	Rail pressure sensor fault.
1161	Speed sensor fault.

## 13 Annex

### 13.14 SIGMA CONTROL MOBIL message codes

Message code	Meaning
1170	Starting fault (after 3 failed attempts).

Tab. 96 Message code range 1100 – 1199: engine faults

#### Range 1200 - 1299: compressor unit faults

Message code	Meaning
1200	Compressor unit overheating.
1201	Compressor pressure too high.

Tab. 97 Message code range 1200 – 1299: compressor unit faults

#### Range 1300 - 1399: controller faults

Message code	Meaning
1300	Memory fault.
1301	Fault in bus communication with engine electronics.
1302	Fault in bus communication with display unit.
1303	Overheating.
1304	Power supply.

Tab. 98 Message code range 1300 – 1399: controller faults

#### Message code range 1400 – 1499: general faults

Message code	Meaning
1400	Quick stop
1410	Open circuit in the oil separator tank pressure sensor.
1411	Short circuit in the oil separator tank pressure sensor.
1412	Open circuit in the inlet valve pressure sensor.
1413	Short circuit in the inlet valve pressure sensor.
1414	Open circuit in the compressor unit temperature sensor.
1415	Short circuit in the compressor unit temperature sensor.
1416	Open circuit in fuel level sensor.
1417	Short circuit in fuel level sensor.
1420	Open circuit in the venting valve (p+e).
1421	Short circuit in the venting valve (p+e).
1422	Open circuit in the auxiliary venting valve (p)
1423	Short circuit in the auxiliary venting valve (p)
1424	Open circuit in the inlet valve control valve (e).
1425	Short circuit in the inlet valve control valve (e).
1426	Open circuit in the frost protector valve.
1427	Short circuit in the frost protector valve.
1430	Manual-stop automatic mode.

## 13 Annex

### 13.14 SIGMA CONTROL MOBIL message codes

Message code	Meaning
1450	Controller block, GSM/GPS monitoring.
1470	Automatic start fault.

Tab. 99 Message code range 1400 – 1499: general faults

#### Range 2100 - 2199: engine maintenance

Message code	Meaning
2100	Change engine oil and filter (500h).
2101	Clean or change the engine air filter (500h).

Tab. 100 Message code range 2100 – 2199: engine maintenance

#### Range 2200 - 2299: compressor unit maintenance

Message code	Meaning
2200	Replace the compressor cooling oil and filter (1000h).
2201	Clean or change the compressor air filter (250h).

Tab. 101 Message code range 2200 – 2299: compressor unit maintenance

#### Range 3100 - 3199: engine warnings

Message code	Meaning
3100	Engine oil pressure too low.
3110	Coolant temperature high.
3121	Turbo air temperature high.
3130	Fuel level low.
3133	Fuel filter water level.

Tab. 102 Message code range 3100 – 3199: engine warnings

#### Range 3200 - 3299: compressor unit warnings

Message code	Meaning
3200	Compressor overheating.
3201	Compressor final pressure too high.

Tab. 103 Message code range 3200 – 3299: compressor unit warnings


#### Message code range 3400 – 3499: general warnings

Message code	Meaning
3400	Battery charging voltage.

Tab. 104 Message code range 3400 – 3499: general warnings

**13.15 Option dd**

**Operating instructions for compressed air filter (combination filter)**

**Bedienungsanleitung  
Instruction Manual****Hochleistungs - Druckluftfilter****Compressed-air filters****Serie / Series****FA (D), FB (D&E), FC (D&E), FD (E), FE (D&E), FF (D&E), FG**

Kaeser Kompressoren GmbH  
Postfach 2143  
96410 Coburg  
Tel.: 09561/640-0  
Fax: 09561/640130  
<http://www.kaeser.com>

**KAESER**

gültig ab 01.04.2007

D      GB

A	Kap. 9.2, 9.3 Wartungsintervalle	04.12.08	SK
Änd. Mittig.		Datum	Bearb.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Materialkennzeichnung**
**Sign of material**

Filter: Standard		Filter: D-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.
FA-6	9.4600.0	FA-6 D	9.4600.00110	E-A-6	9.4800.0
FA-10	9.4601.0	FA-10 D	9.4601.00110	E-A-10	9.4801.0
FA-18	9.4602.0	FA-18 D	9.4602.00110	E-A-18	9.4802.0
FA-28	9.4603.0	FA-28 D	9.4603.00110	E-A-28	9.4803.0
FA-48	9.4604.0	FA-48 D	9.4604.00010	E-A-48	9.4804.0
FA-71	9.4605.0	FA-71 D	9.4605.00010	E-A-71	9.4805.0
FA-107	9.4606.0	FA-107 D	9.4606.00010	E-A-107	9.4806.0
FA-138	9.4607.0	FA-138 D	9.4607.00010	E-A-138	9.4807.0
FA-177	9.4608.0	FA-177 D	9.4608.00010	E-A-177	9.4808.0
FA-221	9.4609.0	FA-221 D	9.4609.00010	E-A-221	9.4809.0
FA-185	9.4610.0	FA-185 D	9.4610.00010	E-A-185	9.4810.0
FA-283	9.4611.0	FA-283 D	9.4611.00010	E-A-283	9.4811.0
FA-354	9.4612.0	FA-354 D	9.4612.00010	E-A-185	9.4810.0
FA-526	9.4613.0	FA-526 D	9.4613.00010	E-A-185	9.4810.0
FA-708	9.4614.0	FA-708 D	9.4614.00010	E-A-185	9.4810.0
FA-885	9.4615.0	FA-885 D	9.4615.00010	E-A-185	9.4810.0
FA-1420	9.4616.0	FA-1420 D	9.4616.00010	E-A-185	9.4810.0
FA-1950	9.4617.0	FA-1950 D	9.4617.00010	E-A-185	9.4810.0
FA-2480	9.4618.0	FA-2480 D	9.4618.00010	E-A-185	9.4810.0

D-Pack: Filter mit ECO-DRAIN /

D-Pack: Filter with ECO-DRAIN

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Typ/Type	Typ/Type	Nr./No.
FB-6	9.4620.0	FB-6 B	9.4620.00110	FB-6 D	9.4620.00120	FB-6 E	E-B-6	9.4812.0	
FB-10	9.4621.0	FB-10 B	9.4621.00110	FB-10 D	9.4621.00120	FB-10 E	E-B-10	9.4813.0	
FB-18	9.4622.0	FB-18 B	9.4622.00110	FB-18 D	9.4622.00120	FB-18 E	E-B-18	9.4814.0	
FB-28	9.4623.0	FB-28 B	9.4623.00110	FB-28 D	9.4623.00120	FB-28 E	E-B-28	9.4815.0	
FB-48	9.4624.0	FB-48 B	9.4624.00110	FB-48 D	9.4624.00120	FB-48 E	E-B-48	9.4816.0	
FB-71	9.4625.0	FB-71 B	9.4625.00110	FB-71 D	9.4625.00120	FB-71 E	E-B-71	9.4817.0	
FB-107	9.4626.0	FB-107 B	9.4626.00110	FB-107 D	9.4626.00120	FB-107 E	E-B-107	9.4818.0	
FB-138	9.4627.0	FB-138 B	9.4627.00110	FB-138 D	9.4627.00120	FB-138 E	E-B-138	9.4819.0	
FB-177	9.4628.0	FB-177 B	9.4628.00110	FB-177 D	9.4628.00120	FB-177 E	E-B-177	9.4820.0	
FB-221	9.4629.0	FB-221 B	9.4629.00110	FB-221 D	9.4629.00120	FB-221 E	E-B-221	9.4821.0	
FB-185	9.4630.0	-	-	FB-185 D	9.4630.00120	FB-185 E	E-B-185	9.4822.0	
FB-283	9.4631.0	-	-	FB-283 D	9.4631.00120	FB-283 E	E-B-283	9.4823.0	
FB-354	9.4632.0	-	-	FB-354 D	9.4632.00120	FB-354 E	E-B-185	9.4822.0	
FB-526	9.4633.0	-	-	FB-526 D	9.4633.00120	FB-526 E	E-B-185	9.4822.0	
FB-708	9.4634.0	-	-	FB-708 D	9.4634.00120	FB-708 E	E-B-185	9.4822.0	
FB-885	9.4635.0	-	-	FB-885 D	9.4635.00120	FB-885 E	E-B-185	9.4822.0	
FB-1420	9.4636.0	-	-	FB-1420 D	9.4636.00020	FB-1420 E	E-B-185	9.4822.0	
FB-1950	9.4637.0	-	-	FB-1950 D	9.4637.00020	FB-1950 E	E-B-185	9.4822.0	
FB-2480	9.4638.0	-	-	FB-2480 D	9.4638.00020	FB-2480 E	E-B-185	9.4822.0	

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 2 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Materialkennzeichnung**
**Sign of material**

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type		Typ/Type	Nr./No.
FC-6	9.4640.0	FC-6 B	9.4640.00110	FC-6 D	9.4640.00120	FC-6 E		E-C-6	9.4824.0
FC-10	9.4641.0	FC-10 B	9.4641.00110	FC-10 D	9.4641.00120	FC-10 E		E-C-10	9.4825.0
FC-18	9.4642.0	FC-18 B	9.4642.00110	FC-18 D	9.4642.00120	FC-18 E		E-C-18	9.4826.0
FC-28	9.4643.0	FC-28 B	9.4643.00110	FC-28 D	9.4643.00120	FC-28 E		E-C-28	9.4827.0
FC-48	9.4644.0	FC-48 B	9.4644.00110	FC-48 D	9.4644.00120	FC-48 E		E-C-48	9.4828.0
FC-71	9.4645.0	FC-71 B	9.4645.00110	FC-71 D	9.4645.00120	FC-71 E		E-C-71	9.4829.0
FC-107	9.4646.0	FC-107 B	9.4646.00110	FC-107 D	9.4646.00120	FC-107 E		E-C-107	9.4830.0
FC-138	9.4647.0	FC-138 B	9.4647.00110	FC-138 D	9.4647.00120	FC-138 E		E-C-138	9.4831.0
FC-177	9.4648.0	FC-177 B	9.4648.00110	FC-177 D	9.4648.00120	FC-177 E		E-C-177	9.4832.0
FC-221	9.4649.0	FC-221 B	9.4649.00110	FC-221 D	9.4649.00120	FC-221 E		E-C-221	9.4833.0
FC-185	9.4650.0	-	-	FC-185 D	9.4650.00120	FC-185 E		E-C-185	9.4834.0
FC-283	9.4651.0	-	-	FC-283 D	9.4651.00120	FC-283 E		E-C-283	9.4835.0
FC-354	9.4652.0	-	-	FC-354 D	9.4652.00120	FC-354 E		E-C-185	9.4834.0
FC-526	9.4653.0	-	-	FC-526 D	9.4653.00120	FC-526 E		E-C-185	9.4834.0
FC-708	9.4654.0	-	-	FC-708 D	9.4654.00120	FC-708 E		E-C-185	9.4834.0
FC-885	9.4655.0	-	-	FC-885 D	9.4655.00120	FC-885 E		E-C-185	9.4834.0
FC-1420	9.4656.0	-	-	FC-1420 D	9.4656.00020	FC-1420 E		E-C-185	9.4834.0
FC-1950	9.4657.0	-	-	FC-1950 D	9.4657.00020	FC-1950 E		E-C-185	9.4834.0
FC-2480	9.4658.0	-	-	FC-2480 D	9.4658.00020	FC-2480 E		E-C-185	9.4834.0

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Filter: Standard		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type		Typ/Type	Nr./No.
FD-6	9.4660.0	FD-6 E	E-D-6	9.4836.0	
FD-10	9.4661.0	FD-10 E	E-D-10	9.4837.0	
FD-18	9.4662.0	FD-18 E	E-D-18	9.4838.0	
FD-28	9.4663.0	FD-28 E	E-D-28	9.4839.0	
FD-48	9.4664.0	FD-48 E	E-D-48	9.4840.0	
FD-71	9.4665.0	FD-71 E	E-D-71	9.4841.0	
FD-107	9.4666.0	FD-107 E	E-D-107	9.4842.0	
FD-138	9.4667.0	FD-138 E	E-D-138	9.4843.0	
FD-177	9.4668.0	FD-177 E	E-D-177	9.4844.0	
FD-221	9.4669.0	FD-221 E	E-D-221	9.4845.0	
FD-185	9.4670.0	FD-185 E	E-D-185	9.4846.0	
FD-283	9.4671.0	FD-283 E	E-D-283	9.4847.0	
FD-354	9.4672.0	FD-354 E	E-D-185	9.4846.0	
FD-526	9.4673.0	FD-526 E	E-D-185	9.4846.0	
FD-708	9.4674.0	FD-708 E	E-D-185	9.4846.0	
FD-885	9.4675.0	FD-885 E	E-D-185	9.4846.0	
FD-1420	9.4676.0	FD-1420 E	E-D-185	9.4846.0	
FD-1950	9.4677.0	FD-1950 E	E-D-185	9.4846.0	
FD-2480	9.4678.0	FD-2480 E	E-D-185	9.4846.0	

E-Pack: Filter mit Filtermonitor

E-Pack: Filter with filtermonitor

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 3 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Materialkennzeichnung**
**Sign of material**

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.
FE-6	9.4700.0	FE-6 B	9.4700.00110	FE-6 D	9.4700.00120	FE-6 E	E-E-6	9.4860.0	
FE-10	9.4701.0	FE-10 B	9.4701.00110	FE-10 D	9.4701.00120	FE-10 E	E-E-10	9.4861.0	
FE-18	9.4702.0	FE-18 B	9.4702.00110	FE-18 D	9.4702.00120	FE-18 E	E-E-18	9.4862.0	
FE-28	9.4703.0	FE-28 B	9.4703.00110	FE-28 D	9.4703.00120	FE-28 E	E-E-28	9.4863.0	
FE-48	9.4704.0	FE-48 B	9.4704.00110	FE-48 D	9.4704.00120	FE-48 E	E-E-48	9.4864.0	
FE-71	9.4705.0	FE-71 B	9.4705.00110	FE-71 D	9.4705.00120	FE-71 E	E-E-71	9.4865.0	
FE-107	9.4706.0	FE-107 B	9.4706.00110	FE-107 D	9.4706.00120	FE-107 E	E-E-107	9.4866.0	
FE-138	9.4707.0	FE-138 B	9.4707.00110	FE-138 D	9.4707.00120	FE-138 E	E-E-138	9.4867.0	
FE-177	9.4708.0	FE-177 B	9.4708.00110	FE-177 D	9.4708.00120	FE-177 E	E-E-177	9.4868.0	
FE-221	9.4709.0	FE-221 B	9.4709.00110	FE-221 D	9.4709.00120	FE-221 E	E-E-221	9.4869.0	
FE-185	9.4710.0	-	-	FE-185 D	9.4710.00120	FE-185 E	E-E-185	9.4870.0	
FE-283	9.4711.0	-	-	FE-283 D	9.4711.00120	FE-283 E	E-E-283	9.4871.0	
FE-354	9.4712.0	-	-	FE-354 D	9.4712.00120	FE-354 E	E-E-185	9.4870.0	
FE-526	9.4713.0	-	-	FE-526 D	9.4713.00120	FE-526 E	E-E-185	9.4870.0	
FE-708	9.4714.0	-	-	FE-708 D	9.4714.00120	FE-708 E	E-E-185	9.4870.0	
FE-885	9.4715.0	-	-	FE-885 D	9.4715.00120	FE-885 E	E-E-185	9.4870.0	
FE-1420	9.4716.0	-	-	FE-1420 D	9.4716.00020	FE-1420 E	E-E-185	9.4870.0	
FE-1950	9.4717.0	-	-	FE-1950 D	9.4717.00020	FE-1950 E	E-E-185	9.4870.0	
FE-2480	9.4718.0	-	-	FE-2480 D	9.4718.00020	FE-2480 E	E-E-185	9.4870.0	

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.
FF-6	9.4720.0	FF-6 B	9.4720.00110	FF-6 D	9.4720.00120	FF-6 E	E-F-6	9.4872.0	
FF-10	9.4721.0	FF-10 B	9.4721.00110	FF-10 D	9.4721.00120	FF-10 E	E-F-10	9.4873.0	
FF-18	9.4722.0	FF-18 B	9.4722.00110	FF-18 D	9.4722.00120	FF-18 E	E-F-18	9.4874.0	
FF-28	9.4723.0	FF-28 B	9.4723.00110	FF-28 D	9.4723.00120	FF-28 E	E-F-28	9.4875.0	
FF-48	9.4724.0	FF-48 B	9.4724.00110	FF-48 D	9.4724.00120	FF-48 E	E-F-48	9.4876.0	
FF-71	9.4725.0	FF-71 B	9.4725.00110	FF-71 D	9.4725.00120	FF-71 E	E-F-71	9.4877.0	
FF-107	9.4726.0	FF-107 B	9.4726.00110	FF-107 D	9.4726.00120	FF-107 E	E-F-107	9.4878.0	
FF-138	9.4727.0	FF-138 B	9.4727.00110	FF-138 D	9.4727.00120	FF-138 E	E-F-138	9.4879.0	
FF-177	9.4728.0	FF-177 B	9.4728.00110	FF-177 D	9.4728.00120	FF-177 E	E-F-177	9.4880.0	
FF-221	9.4729.0	FF-221 B	9.4729.00110	FF-221 D	9.4729.00120	FF-221 E	E-F-221	9.4881.0	
FF-185	9.4730.0	-	-	FF-185 D	9.4730.00120	FF-185 E	E-F-185	9.4882.0	
FF-283	9.4731.0	-	-	FF-283 D	9.4731.00120	FF-283 E	E-F-283	9.4883.0	
FF-354	9.4732.0	-	-	FF-354 D	9.4732.00120	FF-354 E	E-F-185	9.4882.0	
FF-526	9.4733.0	-	-	FF-526 D	9.4733.00120	FF-526 E	E-F-185	9.4882.0	
FF-708	9.4734.0	-	-	FF-708 D	9.4734.00120	FF-708 E	E-F-185	9.4882.0	
FF-885	9.4735.0	-	-	FF-885 D	9.4735.00120	FF-885 E	E-F-185	9.4882.0	
FF-1420	9.4736.0	-	-	FF-1420 D	9.4736.00020	FF-1420 E	E-F-185	9.4882.0	
FF-1950	9.4737.0	-	-	FF-1950 D	9.4737.00020	FF-1950 E	E-F-185	9.4882.0	
FF-2480	9.4738.0	-	-	FF-2480 D	9.4738.00020	FF-2480 E	E-F-185	9.4882.0	

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 4 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Materialkennzeichnung**
**Sign of material**

Filter: Standard		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.
FG-6	9.4740.0	E-G-6	9.4884.0
FG-10	9.4741.0	E-G-10	9.4885.0
FG-18	9.4742.0	E-G-18	9.4886.0
FG-28	9.4743.0	E-G-28	9.4887.0
FG-48	9.4744.0	E-G-48	9.4888.0
FG-71	9.4745.0	E-G-71	9.4889.0
FG-107	9.4746.0	E-G-107	9.4890.0
FG-138	9.4747.0	E-G-138	9.4891.0
FG-177	9.4748.0	E-G-177	9.4892.0
FG-221	9.4749.0	E-G-221	9.4893.0
FG-185	9.4750.0	E-G-185	9.4894.0
FG-283	9.4751.0	E-G-283	9.4895.0
FG-354	9.4752.0	E-G-185	9.4894.0
FG-526	9.4753.0	E-G-185	9.4894.0
FG-708	9.4754.0	E-G-185	9.4894.0
FG-885	9.4755.0	E-G-185	9.4894.0
FG-1420	9.4756.0	E-G-185	9.4894.0
FG-1950	9.4757.0	E-G-185	9.4894.0
FG-2480	9.4758.0	E-G-185	9.4894.0

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	
FFG-6	9.4760.0	FFG-6 B	9.4760.00110	FFG-6 D	9.4760.00120	FFG-6 E	
FFG-10	9.4761.0	FFG-10 B	9.4761.00110	FFG-10 D	9.4761.00120	FFG-10 E	
FFG-18	9.4762.0	FFG-18 B	9.4762.00110	FFG-18 D	9.4762.00120	FFG-18 E	
FFG-28	9.4763.0	FFG-28 B	9.4763.00110	FFG-28 D	9.4763.00120	FFG-28 E	
FFG-48	9.4764.0	FFG-48 B	9.4764.00110	FFG-48 D	9.4764.00120	FFG-48 E	
FFG-71	9.4765.0	FFG-71 B	9.4765.00110	FFG-71 D	9.4765.00120	FFG-71 E	
FFG-107	9.4766.0	FFG-107 B	9.4766.00110	FFG-107 D	9.4766.00120	FFG-107 E	
FFG-138	9.4767.0	FFG-138 B	9.4767.00110	FFG-138 D	9.4767.00120	FFG-138 E	
FFG-177	9.4768.0	FFG-177 B	9.4768.00110	FFG-177 D	9.4768.00120	FFG-177 E	
FFG-221	9.4769.0	FFG-221 B	9.4769.00110	FFG-221 D	9.4769.00120	FFG-221 E	
FFG-185	9.4770.0	-	-	FFG-185 D	9.4770.00120	FFG-185 E	
FFG-283	9.4771.0	-	-	FFG-283 D	9.4771.00120	FFG-283 E	
FFG-354	9.4772.0	-	-	FFG-354 D	9.4772.00120	FFG-354 E	
FFG-526	9.4773.0	-	-	FFG-526 D	9.4773.00120	FFG-526 E	
FFG-708	9.4774.0	-	-	FFG-708 D	9.4774.00120	FFG-708 E	
FFG-885	9.4775.0	-	-	FFG-885 D	9.4775.00120	FFG-885 E	
FFG-1420	9.4776.0	-	-	FFG-1420 D	9.4776.00020	FFG-1420 E	
FFG-1950	9.4777.0	-	-	FFG-1950 D	9.4777.00020	FFG-1950 E	
FFG-2480	9.4778.0	-	-	FFG-2480 D	9.4778.00020	FFG-2480 E	

Filterkombination bestehend aus Serie FF &amp; FG

Filter combination consist of series FF &amp; FG

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter Serie FF mit Filtermonitor und ECO-DRAIN

E-pack: Filter series FF with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 5 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FILTER-FA-FG\_06D E

**Inhaltsverzeichnis**
**Contents**

<b>1. Einleitung</b>	<b>1. Introduction</b>
<b>2. Sicherheitsregeln, Warnhinweise</b>	<b>2. Safety rules, warnings</b>
<b>3. Technische Daten</b>	<b>3. Technical data</b>
<b>4. Funktionsbeschreibung</b>	<b>4. Description of functions</b>
<b>5. Kondensatableiter</b>	<b>5. Condensate discharger</b>
<b>6. Transport, Wareneingangskontrolle</b>	<b>6. Transportation, checking of goods received</b>
<b>7. Montage</b>	<b>7. Assembly</b>
<b>8. Inbetriebnahme, Betrieb</b>	<b>8. Start up, operation</b>
<b>9. Wartung, Austausch der Filterelemente</b>	<b>9. Servicing, filter cartridge replacement</b>
<b>10. Garantiebedingungen</b>	<b>10. Guarantee conditions</b>
<b>11. Maßzeichnung</b>	<b>11. Dimensional drawing</b>
<b>12. Anhang (ECO-DRAIN)</b>	<b>12. Annex (ECO-DRAIN)</b>
<b>13. Einteilung nach Druckgeräterichtlinie</b>	<b>13. Grading of filters according to pressure equipment directive (PED)</b>

Wir haben den Inhalt der Bedienungsanleitung auf Übereinstimmung mit dem beschriebenen Gerät geprüft.  
Dennoch können Abweichungen nicht ausgeschlossen werden, so daß wir für die vollständige Übereinstimmung keine Gewähr übernehmen.

Technische Änderungen vorbehalten.

We have examined the content of the operating instructions for conformity with the appliance described.  
Inconsistencies cannot be ruled out, however, with the result that we do not guarantee complete conformity

We reserve the right to alter the specifications without prior notice

**1. Einleitung**
**1.1 Allgemeines**

Die in dieser Betriebsanleitung dokumentierten Druckluftfilter erfüllen alle Anforderungen, die an moderne Filtersysteme gestellt werden.  
Um Sie optimal nutzen zu können, benötigt der Anwender ausführliche Informationen.

In der vorliegenden Betriebsanleitung haben wir diese Informationen möglichst vollständig und in entsprechende Kapitel gegliedert zusammengestellt.

Lesen und beachten Sie diese Informationen.  
Sie helfen Ihnen auch Unfälle zu vermeiden.

**1. Introduction**
**1.1 General remarks**

The compressed air filters documented in these instruction manual has all requirements that can be expected from a modern filter/-system.  
In order to obtain maximum benefit from using the filters/ -system the user should have sufficient information.

These instruction manual gave the user this information which has been divided into separate sections for easy reference.

Please read carefully before installing and operating the filter/ -system.

**1.2 Erklärung der Symbole in der Bedienungsanleitung**

- Aufzählungen werden mit diesem Punkt oder Sternchen \* gekennzeichnet.

 Mit diesem Symbol werden Textstellen gekennzeichnet, die unbedingt zu beachten sind.

- Wichtige Sicherheitshinweise
- Wichtige Bedienungs-/Wartungshinweise
- Warnung vor möglichen Fehlbedienungen
- Warnung vor Gefahren

 Elektrisches Gefahrensymbol

 Ausführende Tätigkeit.  
Vom Bediener auszuführende Bedienschritte.

**1.2 Explanation to the symbols in the instruction manual**

- Technical data or instructions.  
\*

 Parts that require absolute attention

- Vital safety instructions
- Essential operation and maintenance instructions
- Warnings on handling or moving the dryer
- Danger areas

 Electrical danger symbol

 Changes sequence of operation

**1.3 Erklärung der Symbole am Gerät**

- |   |  |
|---|--|
|  | Automatischer Kondensatablauf / Automatic Condensate Drain |
|  | Elektroanschluß / Electrical Supply                        |

**1.3 Symbols used in the filter**

- |   |   |
|---|---|
|  | Drucklufeintritt / Compressed Air Inlet   |
|  | Druckluftaustritt / Compressed Air Outlet |

**2. Sicherheitsregeln,  
Warnhinweise**
**2.1 Bestimmungsgemäßer Gebrauch**
**⚠ Achtung!**

- Die Filter dürfen nur für die in dieser Bedienungsanleitung vorgesehenen Einsatzfälle zur Aufbereitung von Druckluft verwendet werden.
- Der einwandfreie und sichere Betrieb der Produkte erfordert sachgerechten Transport, Lagerung, Aufstellung und Montage, sowie sorgfältige Bedienung und Instandhaltung.

**2.2 Sicherheitsregeln**
**⚠ Warnung!**

- Die Filter dürfen nur von qualifiziertem Personal genutzt, bedient, gewartet oder instandgesetzt werden.
- Qualifiziertes Personal im Sinne der sicherheitsbezogenen Hinweise in dieser Dokumentation oder auf dem Produkt selbst, ist Personal das:
  - \* im Umgang mit Einrichtungen der Druckluft vertraut und unterwiesen sowie über die damit verbundenen Gefahren unterrichtet ist.
  - \* Den auf die Bedienung bezogenen Inhalt dieser Dokumentation kennt.
  - \* Es besitzt als solches eine zur Inbetriebnahme und Wartung derartiger Einrichtungen befähigende Ausbildung bzw. Berechtigung.

**2. Safety rules,  
warnings**
**2.1 Use of filter/-system**
**⚠ Achtung!**

- The filter must only be used for the purpose as designated in the instruction manual to upgrading the compressed air.
- To obtain maximum efficiency and operation of the filter/-system ensure all sections of the manual are read carefully.

**2.2 Safety rules**
**⚠ Warning!**

- The filter/-system must only be used, operated, inspected and repaired by trained personnel.
- Trained personnel are defined as follows:
  - \* Operating staff who are skilled in the field of compressed air engineering and who are familiar with the filter/-system and possible dangers in unauthorised operation or service.
  - \* Who can interpret and action the contents of this operation instruction manual.
  - \* Who have had the appropriate training and qualified as being competent in these fields.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**2. Sicherheitsregeln,  
Warnhinweise**
**2.3 Warnhinweise**
 **Warnung!**

Das (die) Filter beinhalten unter erhöhtem Druck stehende Systeme.  
Vor Servicearbeiten sind sie drucklos zu machen.

 **Warnung!**

Filtersysteme mit elektrisch gesteuerten Kondensatableitern enthalten unter elektrischer Spannung stehende Bauteile.  
Vor Servicearbeiten sind diese **alle** vom elektrischen Spannungsversorgungsnetz zu trennen.  
(Netzstecker ziehen, Hauptschalter ausschalten)

**ACHTUNG!**

**Alle Arbeiten am elektrischen System dürfen nur von elektrotechnisch geschultem Fachpersonal, oder unter Aufsicht von diesem, durch Unterwiesene ausgeführt werden.**

 **Hinweis!**

Die Filter sind **ausschließlich** zur Aufbereitung von Druckluft einzusetzen.

**ACHTUNG!**

**Die Verwendung in Verbindung mit brennbaren Gasen ist verboten!**

 **ACHTUNG!**

Filter/-systeme zur Aufbereitung von Atemluft dürfen nur nach Genehmigung des Herstellers der Filter/-systeme eingesetzt und betrieben werden.

**2. Safety rules,  
warnings**
**2.3 Security-warnings**
 **Warning!**

The filter/-system contains components under high pressure.  
Before starting any service work turn off compressed air supply to the dryer and depressurise the system.

 **Warning!**

The filter/-systems with electrical condensate discharger contains components that are electrically live and which can cause danger to life.  
Before starting any service work ensure all power is isolated from the filter/-system, mains isolator to be off, mains plug if fitted to be removed.

**ATTENTION!**

**Any electrical work on the dryer must only be carried out by skilled staff - qualified electricians, or persons under supervision of qualified staff.**

 **Remark!**

Use filter for compressed air applications **only**.

**Attention!**

**The use of combustible gases is prohibited.**

 **ATTENTION!**

Filter/-systems for breathing air applications must be approved from manufacturer.

**3. Technische Daten**
**3. Technical data**

MODEL DESIGNATION / FILTER- GRADE / GRADE	Volumenstrom / Capacity [m³/min]	Anschluß Connection [ ]	Betriebsdruck Working Pressure [max]	Abmessungen Dimensions [Höhe / Height [mm] Breite / Width [mm]]	Gewicht Weight [kg]	AUSTAUSCH-FILTERELEMENTE FILTER-REPLACEMENT CARTRIDGE	
						FILTER- GEHÄUSE / HOUSING	GRADE / GRADE
<b>MODUL-BAUWEISE / MODULAR SYSTEM</b>							
FA	-6	0.58	3/8"	16	105	-6	1
	-10	1.00	1/2"	16	105	-10	1
	-18	1.75	1/2"	16	105	-18	1
	-28	2.83	3/4"	16	133	-28	1
FB	-48	4.83	1"	16	133	-48	1
	-71	7.10	1-1/2"	16	164	-71	1
FC	-107	10.7	1-1/2"	16	164	-107	1
	-138	13.8	2	16	194	-138	1
FD	-177	17.7	2-1/2"	16	194	-177	1
	-221	22.1	2-1/2"	13	194	-221	1
<b>BEHÄLTER-BAUWEISE / PRESSURE VESSEL</b>							
FE	-185	18.5	DN80	16	1025	350	
FF	-283	28.3	DN80	16	1045	400	
	-354	35.4	DN80	16	1045	400	
FG	-526	52.6	DN100	16	1085	440	
	-708	70.8	DN100	16	1105	535	
	-885	88.5	DN100	16	1105	535	
	-1420	142	DN150	16	1215	600	
	-1950	195	DN150	16	1245	720	
	-2480	248	DN150	16	1245	750	

- Volumenstrom m³/h bezogen auf +20°C und 1 bar absolut, bei Betriebsüberdruck 7 bar / Air flow m³/h based on +20°C and 1 bar absolute, at working pressure 7 bar
- Größere Betriebsdrücke auf Anfrage / Contact factory for drivers with a higher working pressure
- Filtergehäuse F-185 – F-2480: Konstruktion der Behälter entspricht der EG-Richtlinie 87/404/EEC für einfache Druckbehälter und ist mit CE-Zichen versehen / Filter bowl F-185 – F-2480: Vessel construction complies with directive 87/404/EEC, simple pressure vessels, and is marked with the EC symbol

**Volumenstrom - Korrekturtabelle / Sizing**

Minimaler Betriebsdruck / Minimum working pressure bar	Korrekturfaktor / Correction factor	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0.38	0.52	0.63	0.75	0.88	1.00	1.13	1.26	1.38	1.52	1.65	1.76	1.87	2	2.14		

**Auslegung**

Bei Drucken abweichend von 7 bar berechnet sich der max. Volumenstrom wie folgt:  
den Korrekturfaktor des entsprechenden minimalen Betriebsdrückes mit dem gewählten Volumenstrom aus o.g. Tabelle multiplizieren.

**Based on**

To find the maximum flow at pressures other than 7 bar:  
multiply the flow (from table above) by the correction factor corresponding to the minimum working pressure of the filter.

**Betriebsbedingungen:**

Min. Betriebstemperatur: +1°C  
Max. Betriebstemperatur: 66°C  
Min. Betriebsdruck mit automatischem Kondensatablänger: 2,0 bar

FILTER-FA-FG\_06D E

**4. Funktionsbeschreibung**
**4. Description of operation**
**4.3 Serie FC**
**1-MIKRON-COALESING-FILTER**

- Zweistufige Tiefenfiltration bewirkt hervorragende Leistung und höhere Standzeiten des Filterelementes
- Entfernt 100% des Kondensats
- Entfernt Feststoffpartikel bis herunter zu 1 Mikron
- Restölgehalt < 1 ppm w/w
- Automatischer Kondensatableiter
- Differenzdruckanzeige am Filtergehäuse
- max. Flüssigkeitsbeladung: 2g/m<sup>3</sup>

**Anwendungen:**

- Allgemeine Filter für Werkstattluft
- Vorfilter für Hochleistungsfilter
- Nachfilter für Adsorptionstrockner
- Endstellenfiltration bei Einsatz von Nachkühlern oder Trocknern

**Funktion:**

Die Luft tritt von oben in das Filterelement FC ein und strömt radial durch den perforierten inneren Stützmantel zur 1. Filtrationsstufe. Diese Stufe besteht aus mehreren Lagen Glasfaser und einer stützenden Glasfasermatte. Gröbere Feststoffteilchen werden hier zurückgehalten. Die Luft gelangt nun in die 2. Filtrationsstufe, bestehend aus einer mehrlagigen Mischung von imprägnierten Glasfasern und Mikrofibern. In beiden Stufen werden Feststoffpartikel und Flüssigkeiten nach dem Prinzip der Tiefenfiltration sowie des Coalescings ausgefiltert. Die Luft tritt durch den perforierten äußeren Stützmantel aus.

**4.3 Series FC**
**1-MICRON-COALESING-FILTER**


- Two in-depth filter beds offer superior performance and extended cartridge life
- Removes 100% of liquid water
- Removes solid particles down to 1 micron
- Oil content < 1 ppm w/w
- Automatic condensate drain
- Differential pressure indicator at the filter housing
- max. liquid load: 2g/m<sup>3</sup>

**Application:**

- General filter for shop air
- Prefilter for high efficiency filters
- Afterfilter for pressure-swing desiccant dryers
- Point-of-use filter on systems utilising aftercoolers or dryers

**Operation:**

Air enters the inside of the cartridge FC and flows outwardly through two in-depth beds of glass fibres. Larger particles are collected in the first bed while all remaining particles one micron and larger are collected in the second bed. A combination of large void areas and stabilized media allows heavy particulate loading and low pressure drop resulting in a long service life for the cartridge. Throughout both stages, liquid aerosols are captured and coalesced. The coalesced liquids then drain to the bottom of the cartridge for removal.



F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**4. Funktionsbeschreibung**
**4. Description of operation**
**4.5 Serie FE**
**0,01-MIKRON-COALESING-FILTER  
(bei 0,01 ppm w/w max. Ölgehalt)**

DUO-System Abscheidung  
1. Stufe: flüssige Bestandteile  
2. Stufe: Ölbestandteile

- Entfernt mehr als 99,99% der Öl-Aerosole
- Entfernt Feststoffpartikel bis herunter zu 0,01 Mikron
- Restölgehalt < 0,01 ppm w/w
- Automatischer Kondensatableiter
- Differenzdruckanzeige am Filtergehäuse
- max. Flüssigkeitsbeladung: 1g/m<sup>3</sup>

**Anwendungen:**

- Vorfilter für Membrantrockner
- Vorfilter für Adsorptionstrockner
- Endstellenfiltration (falls **geringfügige** Feuchtigkeit vorhanden ist)

**Funktion:**

Die Luft tritt von oben in das Filterelement FE ein und strömt durch den inneren Stützmantel, radial durch verschiedenartige Lagen Fiberglas. Dann strömt die Luft durch ein weiteres Sieb. In dieser 1. Filtrationsstufe werden größere Partikel entfernt. In der zweiten Filtrationsstufe werden Aerosole und feste Bestandteile durch eine Mehrschicht-Membranwand aus epoxidharz verstärktem Fiberglas gefiltert, daß speziell für feinste Aerosole geeignet ist. Das Filtermedium ist ein Bett aus submikrofeinen Glasfasern und wirkt nach dem Prinzip des Coalescings sowie der Tiefenfiltration. Der innere Schaumstoffmantel gleicht Luftschwankungen und Aerosolkonzentrationen aus und gewährleistet eine gleichmäßige Verteilung. Im äußeren Schaumstoffmantel werden die Öltröpfchen gesammelt, fließen durch Schwerkraft in den unteren Teil des Filters und tropfen dann in den Filterbehälter ab.

**4.5 Series FE**
**0,01-MICRON-COALESING-FILTER  
(at 0,01 ppm w/w max. oil content)**

DUO-system separation  
1. Stage: liquid particles  
2. Stage: oil particles


- Removes more than 99,99% of oil aerosols
- Removes solid particles down to 0,01 microns
- Oil content < 0,01 ppm w/w
- Automatic condensate drain
- Differential pressure indicator at the filter housing
- max. liquid load: 1g/m<sup>3</sup>

**Application:**

- Prefilter for membrane dryers
- Prefilter for pressure-swing desiccant dryers
- Point-of-use filter (may be used if light liquid load is present)

**Operation:**

Air enters the inside of the cartridge FE and flows through an inner foam sleeve, radially outward through various layers of glass fibers. Then the air flows through another screen. In the first stage filter section the larger solid particles are trapped. In the second stage filter section aerosols and solid particles are trapped using a multi-layered membrane wall made of epoxy resin-reinforced glass fibres which was especially designed for the finest aerosols. The filter media is a bed of submicronic glass fibers and works to the principle of coalescing and in-depth filtration. The inner foam sleeve compensates air cycling and aerosol concentrations and maintains uniform distribution. The outer foam sleeve collects the coalesced oil droplets which then, due to gravity, travel downstream to the bottom of the sleeve and drain to the bottom of the filter bowl.



F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**7. Montage**
**7.1 Montageort**

Das Filter/-system sollte in einem trockenen, frostfreien Innenraum installiert werden.  
Zur Wartung ist genügend Freiraum vorzusehen.

**7.2 Montage**

Das Filter/-system ist senkrecht so zu montieren, daß der Druckluft-ein- und austritt waagerecht erfolgt.

Im Filtergehäuse eingebaute Filterelemente können sich während des Transportes lösen.  
Prüfen Sie den richtigen Sitz der Filterelemente vor der Inbetriebnahme.


**ACHTUNG!**

Achten Sie bei der Montage darauf, daß keine Zug- und Druckkräfte auf die Geräteanschlüsse übertragen werden.


**Hinweis!**

Bei den Standard-Filters FB, FC, FE und FF der Größe -185 & -283 ... -2480, den D-Pack-Basic-Filters FB, FC, FE und FF, sowie den E-Pack-Filters FA, FB, FC, FE und FF sind die Kondensatableiter beigelegt und müssen wie in Kapitel 11. „Maßzeichnung“ angebaut werden.

**7. Mounting**
**7.1 Location of mounting**

The filter/-system should be installed in a dry and frost-proof room indoors.  
Ample free, space should be allowed for the maintenance.

**7.2 Mounting**

Mount the filter/-system so that inlet and outlet connections are horizontal (filter bowl vertical).

Cartridges installed in the filter housing may become dislodged during transport.  
Make sure that the cartridge is correctly installed before use.


**ATTENTION!**

When installing the filter/-system ensure all connections are even and no pressure is placed on inlet and outlet connections.


**Remark!**

By the standard-filter FB, FC, FE and FF with the size -185 & -283 ... -2480, by the D-pack-basic-filter FB, FC, FE, FF and by the E-pack-filter FA, FB, FC, FE and FF the condensate drains are attached and must mount as shown in chapter 11. „Dimensional drawing“.

**7.3 Anschluß an das Druckluftnetz**

Die Druckluftein- und -austrittsleitung sollte für Servicezwecke mit einem Bypass versehen werden.  
Die Dimensionierung der Anschlüsse entnehmen Sie bitte dem Kapitel 3. „Technische Daten“.


**ACHTUNG!**

Durchflußrichtung beachten.  
Druckluftein- und austritt dürfen nicht vertauscht werden.

**7.3 Connection to the compressed air system**

The compressed air inlet and outlet line should be equipped with a by-pass system for the maintenance.  
For the sizing of the connections please see chapter 3. „Technical data“.


**ATTENTION!**

Pay attention to the flow direction.  
Do not exchange the compressed air inlet and outlet.

**7.4 Kondensatableitung**

Für die automatische Kondensatableitung ist bei den Filtern (FA, FB, FC, FE, FF) ein Anschluß vorhanden.  
Die Dimensionierung des Anschlusses entnehmen Sie bitte Kapitel 5. „Kondensatableiter“.


**HINWEIS!**

Bei der Entsorgung des Kondensats ist der Schmutzanteil zu berücksichtigen.  
Beachten Sie die jeweils geltenden gesetzlichen Vorschriften.

Bei den Filtern FD, FG entfällt der Kondensatableitungsanschluß.

**7.4 Condensate drain**

The filters (FA, FB, FC, FE, FF) are equipped with one connection for the automatically condensate drain.  
For the sizing of the connection please see chapter 5. „Condensate discharger“.



When fitting the drains please see to it, that the condensate separated is drained off into a system that does not create a back pressure.


**Instruction!**

When disposing of the condensate the amount of pollution has to be taken into consideration. Please act according to the prevailing regulations of law.

Condensate drain does not exist in filters FD, FG.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**8. Inbetriebnahme, Betrieb**
**8.1 Bereitschaft zur Inbetriebnahme**


Druckluftfilter/-systeme sind bereit zur Inbetriebnahme, wenn:

- Der auf dem Typenschild angegebene Druck dem maximalen Betriebsdruck entspricht.
- Sie entsprechend Kapitel 7. „Montage“ installiert wurden.
- Alle Zu- und Ableitungen sachgerecht angeschlossen sind.
- Die erforderlichen Energien (Druckluft) verfügbar sind.
- Absperrorgane (z.B. Ventil, Kugelhahn) in der Druckluftein- und austrittsleitung geschlossen sind.
- Kondensat durch die Kondensatableitung ungehindert abfließen kann.
- Der elektrisch gesteuerte Kondensatableiter an das elektrische Spannungsversorgungsnetz mit der richtigen Betriebsspannung angeschlossen ist. (Nur bei elektrisch gesteuerten Kondensatableitern)
- Das Filter/-system mit den richtigen Filterelementen ausgerüstet ist.

**8. Start-up, operation**
**8.1 Preconditions for starting the dryer**


The filter/-system is ready for starting when:

- Check unit serial number tag to verify working pressure.
- They have been installed in accordance with section 7. „Mounting“.
- All inlet and outlet lines have been correctly connected.
- The required forms of energy (compressed-air) are available.
- The shut-off devices (e.g. ball valve) in the compressed-air inlet and outlet lines are closed.
- The condensate is able to flow through the condensate discharger without obstruction.
- The electrical condensate drain has been connected to the electric power supply system with the correct operating voltage (only electrical condensate drains).
- The filter/-system is equipped with the right cartridges.

**8.2 Inbetriebnahme, Betrieb**


Vor der Inbetriebnahme ist sicherzustellen, daß alle Bedingungen des Abschnittes 8.1 „Bereitschaft zur Inbetriebnahme“ erfüllt sind.



Setzen Sie das Filter/-system durch langsame Öffnen der Druckluft eintritts- und austrittsleitung unter Druck.



Schließen Sie das Absperrorgan im Bypass (falls vorhanden).



Das Filter/-system ist nun in BETRIEB.

**8.2 Start up, operation**


Before starting the dryer, ensure that all the requirements specified in section 8.1 „Preconditions for starting the dryer“ have been fulfilled.



Place filter/-system under pressure gradually by slowly opening the compressed air inlet/outlet.




Close the shut-off device in the bypass (if installed).



The filter/-system is now OPERATIVE.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**8. Inbetriebnahme, Betrieb**
**8.3 Differenzdruckanzeige-Standard und  
D-Pack (OPTION)**


Die Differenzdruckanzeige informiert als Störanzeige über eine atypische Verschmutzung.

**⚠️ Unabhängig von der Differenzdruckanzeige müssen die Filterelemente gemäß der Wartungsintervalle gewechselt werden. (Siehe Kapitel 9)**

**⚠️ Das Filter FG benötigt keine Differenzdruckanzeige.**

**8. Start-up, operation**
**8.3 Differential pressure indicator-  
standard and D-Pack (OPTION)**

The differential pressure indicator indicates atypical contamination.

**⚠️ We recommend installing a new filter cartridge according to the maintenance periods. (See chapter 9)**

**⚠️ The FG filter does not require a differential pressure gauge.**

**9. Wartung  
Austausch der Filterelemente**
**9.1 Standzeit der Filterelemente**

Die Standzeit der Filterelemente ist abhängig von der Beladung. Mit steigender Beladung der Elemente erhöht sich der Differenzdruck über dem Filter.  
Die Filterelemente müssen gemäß unten stehender Tabelle gewechselt werden.

**9.2 Austausch der Filterelemente**
Filtergehäuse -6 bis -221

Anzahl der Filterelemente siehe Kapitel 4. „Technische Daten“.

**⚠️ WARNUNG!**

- Verwenden Sie keine Werkzeuge! (Filtergehäuse -6 bis -48)
- Öffnen und Schließen Sie das Filter nicht mit Gewalt.
- Das (die) Filter beinhaltet(n) unter erhöhtem Druck stehende Systeme.

Vor Servicearbeiten sind sie drucklos zu machen.

👉 Absperrvorrichtung im Drucklufttein- und -austritt schließen.

👉 Kondensatableitungsschlauch an (1) lösen.  
(Nur bei FB, FC, FE, FF).

👉 Rändelschraube (1) langsam im Uhrzeigersinn lösen.  
Das Filtergehäuse wird entlüftet.

**9. Servicing, filter cartridge replacement**
**9.1 Serviceable life of cartridge**

The cartridge's serviceable life depends upon the degree of contamination. As the cartridge becomes more contaminated, the differential pressure above the filter increases.  
The filterelements must be changed according to the table below.

**9.2 Replacing the cartridge**
Filter housing -6 to -221

Number of cartridges see chapter 4. „Technical data“.

**⚠️ CAUTION!**

- Do not use any tools (filter housings -6 to -48)
- Do not force the filter open or closed.
- The filter(s) contain(s) systems under high pressure.  
All pressure must be let off before servicing.

👉 Close the shut-off device in the compressed air inlet/outlet.

👉 Loosen condensate drain hose at (1) (only on FB, FC, FE, FF models).

👉 Slowly turn the knurled screw (1) clockwise. This will release the air from the housing.

**Wartungsintervalle / Maintenance-intervals**

Wartungsteil Part of maintenance	Type	Anwendung Application	Wartungs-Intervall Maintenance-Interval
Filter-Elemente / filter cartridges	FB, FC	Vorfilter Pre-filter	6.000 Bh, max. 1 Jahr / 6.000 Bh, max. 1 year
	FE, FF	Microfilter	3.000 Bh, max. 1 Jahr/ 3.000 Bh, max. 1 year
	FEG	Filterkombination Filter combination	3.000 Bh, max. 1 Jahr (Type FE) 3.000 Bh, max. 1 year Type (FE)
			1.000 Bh, max. 1 Jahr (Type FG) 1.000 Bh, max. 1 year Type (FG)
	FFG		1.000 Bh, max. 1 Jahr/ 1.000 Bh, max. 1 year
	FD	Nachfilter After-filter	6.000 Bh, max. 1 Jahr/ 6.000 Bh, max. 1 year
Kondensatableiter / condensate drain	FG	Aktivkohlefilter Act.carbon filter	1.000 Bh
	Service-unit	Vorfilter Pre-filter	6.000 Bh
	Service-unit	Microfilter	6.000 Bh
	Service-unit	Filterkombination Filter combination	6.000 Bh

Bh = Kompressor-Betriebsstunden / Working hours



F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**9. Wartung  
Austausch der Filterelemente**
 Filtergehäuse entfernen.

• **Filtergehäuse -6 bis -48 (Bayonet-Verschluß)**

- \* Das Filtergehäuse nach oben, gegen den Filterkopf drücken.
- \* Dann das Filtergehäuse im Uhrzeigersinn langsam gegen den Anschlag drehen (etwa 1/8 Drehung) und nach unten abziehen.

• **Filtergehäuse -71 bis -221 (Gewinde-Verschluß)**

- \* Schrauben Sie das Filtergehäuse gegen den Uhrzeigersinn (per Hand oder mit Hilfe eines Filterschlüssels) auf.

 Filterelement gemäß unten stehender Skizze abziehen, bzw. wechseln.

**Hinweis:** Die Schaumstoffummantelung der Filterelemente Serie FE, FF und FG dürfen nicht mit den Fingern angefaßt werden.

 Filtergehäuse in umgekehrter Reihenfolge zusammenbauen.

 Filter durch langsame Öffnen der Absperrvorrichtung wieder mit Druck beaufschlagen.

**9. Servicing, filter cartridge replacement**
 Remove housing.

• **Housing -6 to -48 (bayonet-style head)**

- \* Push housing upwards against the filter head.
- \* Then slowly turn the housing clockwise to the stop (about 1/8 of a turn) and remove by pulling downwards.


• **Housing -71 to -221 (threaded head)**

- \* Screw off the housing counter-clockwise (by hand or using a filter wrench).

 Remove and replace cartridge as shown below.

**Please note:** Do not touch the foam sleeves of the cartridges from the FE, FF and FG series with your fingers.

 Re-assemble the housing in the reverse order.

 Place filter under pressure again by slowly opening the shut-off device.

**Filtergehäuse -185 bis -2480**

Anzahl der Filterelemente siehe Kapitel 3. „Technische Daten“.

 **WARNING!**

- Das (die) Filter beinhaltet(n) unter erhöhtem Druck stehende Systeme.  
Vor Servicearbeiten sind sie drucklos zu machen.

**Housing -185 to -2480**

Number of cartridges see chapter 3. „Technical data“.

 **CAUTION!**

- The filter(s) contain(s) systems under high pressure.  
Alle pressure must be let off before servicing

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**9. Wartung  
Austausch der Filterelemente**

- ☞ Absperrvorrichtung im Druckluftein- und -austritt schließen.
- ☞ Kondensatableitungsschlauch an (1) lösen. (Nur bei FB, FC, FE, FF).
- ☞ Um das Filtergehäuse zu entlüften müssen Sie beim:
  - Kondensatabeleiter Nr. 30505 und Nr. 30506 die Entlüftungsschraube (3) entgegen dem Uhrzeigersinn lösen.
  - FG den Kugelhahn (5) öffnen.
- ☞ Schrauben der Flanschverbindung am Boden des Filtergehäuses vorsichtig lösen, da evtl. noch ein geringer Restdruck im System vorhanden ist.
- ☞ Schrauben bis auf eine entfernen und Flansch zur Seite schwenken.
- ☞ Filterelemente entgegen dem Uhrzeigersinn herausschrauben.
- ☞ Neue Filterelemente ohne Werkzeug „fingerfest“ einschrauben.
- Hinweis:** Die Schaumstoffummantelung der Filterelemente Serie FE, FF, FG dürfen nicht mit den Fingern angefaßt werden.
- ☞ Filtergehäuse in umgekehrter Reihenfolge schließen.
- ☞ Filter durch langes Öffnen der Absperrvorrichtungen wieder mit Druck beaufschlagen.


**9. Servicing, filter cartridge replacement**

- ☞ Close shut-off device in compressed air inlet/outlet.
- ☞ Loosen condensate drain hose at (1) (only on FB, FC, FE, FF models).
- ☞ Follow these steps to release the air from the housing:
  - for condensate drain no. 30505 and no. 30506, loosen the bleed screw (3) in counter-clockwise direction.
  - on FG models, open the ball valve (5).
- ☞ Gently loosen the screws at the bottom flange of the housing. Caution is necessary as the system may still be under slight residual pressure.
- ☞ Remove all screws except one and swing flange to the side.
- ☞ Screw out cartridge counter-clockwise.
- ☞ Screw in new cartridge by hand until „handtight“. Do not use a wrench.
- Please note:** Do not touch the foam sleeves of the cartridges from the FE, FF, FG series with your fingers.
- ☞ Close housing in reverse order.
- ☞ Place filter under pressure again by slowly opening the shut-off device.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**9. Wartung  
Austausch der Filterelemente**

**9.3 Austausch der**  
**Schwimmerableiter /**  
**ECO-DRAIN Service-unit /**  
**ECO-DRAIN Membransätze**

Die Kondensatableiter / Wartungspakete sind gemäß unten aufgeföhrter Tabelle regelmäßig zu wechseln.

**9. Servicing, filter cartridge  
replacement**

**9.3 Changing of**  
**Float drain /**  
**ECO-DRAIN Service-unit /**  
**ECO-DRAIN membrane set**

The condensate drains / service packages must be changed according to the table below.

Wartungsteil Part of maintenance	Wartungs-Intervall Maintenance-interval
Schwimmer-Kondensatableiter/ Float drain	3.000 Bh
Service-Unit (ECO DRAIN 30/31)	6.000 Bh
ECO DRAIN Verschleißteilsatz (ECO DRAIN 13/14) ECO DRAIN wearing part set (ECO DRAIN 13/14)	6.000 Bh

Nähtere Informationen finden Sie auch im Anhang ECO DRAIN.

For more details please see annex ECO DRAIN.

**10. Garantiebedingungen****10.1 Allgemeines**

Die Garantie erstreckt sich, im Rahmen unserer allgemeinen Lieferbedingungen, auf das gelieferte Filter/-system.

**10.2 Garantieausschluß**

**Garantieansprüche bestehen nicht,**

- wenn das Filter/-system durch Einfluß höherer Gewalt oder durch Umwelteinflüsse beschädigt oder zerstört wird.
- bei Schäden, die durch unsachgemäße Behandlung, insbesondere Nichtbeachtung der Betriebs- und Wartungsanleitung aufgetreten sind (regelmäßige Kontrolle des Kondensatableiters / regelmäßiger Wechsel der Filterelemente).
- falls das Filter/-system nicht seinen Bestimmungen entsprechend eingesetzt war (siehe Kapitel 3. „Technische Daten“).
- falls das Filter/-system durch nicht hierfür autorisierte Werkstätten oder andere Personen unsachgemäß geöffnet oder repariert wurde und/oder mechanische Beschädigungen irgendwelcher Art aufweist.

**10. Guarantee conditions****10.1 General**

The guarantee covers the delivered device with regard to our general terms of delivery.


**10.2 Exclusion from guarantee coverage**

**No guarantee claims shall be assertible,**

- if the filter/-system is damaged or destroyed due to force majeurs or environmental effects.
- for damage resulting from incorrect handling, in particular failure to comply with the operating and maintenance instructions (regular inspection of the condensate discharger, regular change of the filter cartridges).
- if the filter/-system has not been used in accordance with its specifications (see section 3. „Technical data“).
- if the filter/-system has been opened or repaired by workshops or other persons unauthorised for this purpose and/or reveals any type of mechanical damage.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**13.16 Option dc****Operating instructions for compressed air filter (breathing air filter)**



**AC010 - AC030**

**OIL-X  
EVOLUTION**

Original Language EN **OIL VAPOUR & ODOUR REMOVAL FILTERS**

(NL) OLIEDAMP & GEUR VERWIJDERINGSFILTERS	(DE) FILTER ZUM ENTFERNNEN VON ÖLNEBEL UND GERÜCHEN
(FR) FILTRES D'ÉLIMINATION DES ODEURS ET DES VAPEURS D'HUILE	(FI) ÖLJYHÖYRYN JA HAJUN POISTOSUODATTIMET
(SV) FILTER FÖR AVLÄGSNING AV OLJEÅNGOR OCH LUKT	(NO) OLJEDAMP- OG OLJELUKTFJERNINGSFILTRE
(DA) FILTER FÖR AVLÄGSNING AV OLJEÅNGOR OCH LUKT	(EL) ΦΙΛΤΡΑ ΑΦΑΙΡΕΣΗΣ ΑΤΜΩΝ & ΟΣΜΩΝ ΛΑΔΙΟΥ
(ES) FILTROS DE ELIMINACIÓN DE OLORES Y VAPORES DE ACEITE	(PT) VAPOR DO ÓLEO E FILTROS DE REMOÇÃO DOS CHEIROS
(IT) FILTRI PER L'ELIMINAZIONE DEGLI ODORI E DEI VAPORI D'OLIO	(PL) FILTRY DO USUWANIA OPARÓW I ZAPACHU OLEJU
(SK) FILTRE NA ODSTRAŇOVANIE OLEJOVÝCH VÝPAROV A ZÁPACHU	(CS) OLEJOVÉ A PROTIPACHOVÉ FILTRY
(ET) ŌLISUDU JA -HAISU EEMALDUSFILTRID	(HU) OLAJGÖZ- ÉS SZAGELTÁVOLÍTÓ SZÜRŐK
(LV) EĻĻAS TVAIKU UN AROMĀTA NOVĒRŠANAS FILTRI	(LT) ALYVOS GARŪ IR KVAPO ŠALINIMO FILTRAI
(RU) ФИЛЬТРЫ ДЛЯ УСТРАНЕНИЯ ЗАПАХА И ПАРОВ МАСЛА	(SL) FILTRI ZA ODSTRANJEVANJE OLJNIH HLAPOV IN VONJAV
(TR) YAĞ BUHARI VE KOKUSU GİDERİCİ FİLTRELER	(MT) FILTRI LI JNEHHU L-FWAR TAŽ-ŽJUT U L-IRWEJJAH




**Warning**

- Highlights actions or procedures, which if not performed correctly, may lead to personal injury or death.
- Benadrukt de acties of procedures die, indien niet juist uitgevoerd, lichamelijk letsel of de dood kunnen veroorzaken.
- Weist auf Aktionen oder Verfahren hin, die bei fehlerhafter Durchführung zu Verletzungen und tödlichen Unfällen führen können.
- Met en relief les actions ou procédures qui, si elles ne sont pas exécutées correctement, peuvent entraîner des dommages corporels ou la mort.
- Osoittaa toimenpiteitä tai menettelytapoja, jotka väärin suoritettuna saattavat aiheuttaa henkilövahingon tai kuoleman.
- Anger åtgärder och metoder som kan orsaka personskador eller dödsfall om de inte utförs korrekt.
- Fremhevær handlinger eller prosedyrer som kan føre til personskafe eller dødsfall hvis de ikke utføres på korrekt måte.
- Επισημαίνεται τις ενέργειες ή τις διαδικασίες, οι οποίες αν δεν πραγματοποιηθούν σωστά, μπορεί να οδηγήσουν σε τραυματισμό προσωπικού ή σε θάνατο.
- Destaca acciones o procedimientos que, de no realizarse correctamente, pueden ocasionar daños personales o la muerte.
- Realça as acções ou procedimentos que, se não forem executados correctamente, poderão provocar danos pessoais ou morte.
- Segnala azioni o procedure che, se non eseguite correttamente, comportano il rischio di infortuni o morte.
- Wskazuje działania i procedury, które w razie niewłaściwego wykonania mogą prowadzić do obrażenia ciała lub śmierci.
- Zvýrazňuje činnosti alebo postupy, ktoré môžu v prípade nesprávneho vykonania viesť k zraneniu alebo usmrteniu.
- Upozornění na činnosti nebo postupy, jejichž nesprávné provádění může vést ke zranění nebo usmrcení osob.
- Tóstab esile toiminguud vői protsedurid, mis väärä teostamise korral vöhjastada kehavigastus vői surma.
- Olyan műveleteket vagy eljárásokat jelöl, amelyek nem megfelelő módon történő végrehajtása súlyos vagy végzetes személyi sérlést okozhat.
- Uzsver darbības vai procedūras, kuru rezultātā, ja tās neveic pareizi, var izraisīt ievainojumus vai nāvi.
- Žymi veiksmus ar procedūras, kuriuos atlikus neteisingai, galima susizēstī ar mīri.
- Указывает на действия, ненадлежащее выполнение которых может привести к нанесению вреда здоровью или смерти
- Označuje dejanja ali postopke, ki lahko ob nepravilnem izvajjanju poškodujejo človeka ali povzročijo smrt.
- Doğru bir şekilde yerine getirilmemiği takdirde bu ürüne hasar verebilecek işlem ve süreçleri vurgular.
- Tissottolinea l-azzjonijiet jew il-proceduri, li jekk ma jsirux kif suppost, jista' jkun hemm korrientej jew mewt


**Caution**

- Highlights actions or procedures, which if not performed correctly, may lead to damage to this product.
- Benadrukt de acties of procedures die, indien niet juist uitgevoerd, schade kunnen berokkenen aan dit product.
- Weist auf Aktionen oder Verfahren hin, die bei fehlerhafter Durchführung zu Schäden am Gerät führen können.
- Met en relief les actions ou procédures qui, si elles ne sont pas exécutées correctement, peuvent endommager ce produit.
- Osoittaa toimenpiteitä tai menettelytapoja, jotka väärin suoritettuna saattavat vaurioittaa tätä laitetta.
- Anger åtgärder och metoder som kan orsaka skador på den här produkten om de inte utförs korrekt.
- Fremhevær handlinger eller prosedyrer som kan føre til skade på produktet hvis de ikke utføres på korrekt måte.
- Επισημαίνεται τις ενέργειες ή τις διαδικασίες, οι οποίες αν δεν πραγματοποιηθούν σωστά, μπορεί να προκαλέσουν ζημιά στο πρώτο αυτό
- Destaca acciones o procedimientos que, de no realizarse correctamente, pueden ocasionar el deterioro del producto.
- Realça as acções ou procedimentos que, se não forem executados correctamente, poderão danificar este produto.
- Segnala azioni o procedure che, se non eseguite correttamente, comportano il rischio di danneggiare il prodotto.
- Wskazuje działania i procedury, które w razie niewłaściwego wykonania mogą powodować uszkodzenie produktu.
- Zvýrazňuje činnosti alebo postupy, ktoré v prípade nesprávneho vykonania mohú viesť k poškodeniu tohto výrobku.
- Upozornění na činnosti nebo postupy, jejichž nesprávné provádění může vést k poškození tohoto výrobku.
- Tóstab esile toiminguud vői protsedurid, mis väärä teostamise korral vöhjastavat toodet kahjustada.
- Olyan műveleteket vagy eljárásokat jelöl, amelyek nem megfelelő módon történő végrehajtása a termék károsodásához vezethet.
- Uzsver darbības vai procedūras, kuru rezultātā, ja tās neveic pareizi, var sabojāt šā izstrādājumu.
- Žymi veiksmus ar procedūras, kuriuos atlikus neteisingai, galima sugadinti šī gaminī.
- Указывает на действия, ненадлежащее выполнение которых может привести к повреждениям данного изделия
- Označuje dejanja ali postopke, ki lahko ob nepravilnem izvajjanju poškodujejo izdelek.
- Doğru bir şekilde yerine getirilmemiği takdirde yaralanma ya da ólume yol açabilecek işlem ve süreçleri vurgular
- Tissottolinea l-azzjonijiet jew il-proceduri, li jekk ma jsirux kif suppost, tista' ssir hsara lil dan il prodott



- Suitable gloves must be worn.
- Geeignete Schutzhandschuhe tragen.
- Käytettävä asianmukaisia käsineitä.
- Bruk egnede hansker.
- Απαιτείται να φοράτε κατάλληλα γάντια.
- Devem ser utilizadas luvas adequadas.
- Należy zakładać odpowiednie rękawice
- Kohustuslik kanda sobivaid kaitsekindaid
- Jävalkä piemēroti cimdi.
- Работы должны проводиться в соответствующих перчатках
- Uygun eldiven giyilmelidir
- Altijd geschikte handschoenen dragen.
- Le port de gants adaptés est obligatoire.
- Använd lämpliga handskar.
- Der skal anvendes egnede handsker.
- Se deben llevar puestos guantes apropiados.
- Indossare guanti di protezione.
- Je nutné použiť vhodné rukavice.
- Visleni megfelelő védőkesztyűt.
- Reikia művétől tinkamas pirésinges.
- Uporabit je treba ustrerene rokavice.
- Għandhom jintibbu ingħanti adatti



- Highlights the requirements for disposing of used parts and waste.
- Benadrukt de vereisten voor het weggoeden van gebruikte onderdelen en afval.
- Weist auf die Anforderungen zur Entsorgung gebrauchter Teile und Abfall hin.
- Met en relief les consignes de mise au rebut des pièces usagées et des déchets.
- Osoittaa käytettyjen osien ja jätteen hävitättämistä koskevia vaatimuksia.
- Anger de krav som ställs på bortskaffande av gamla delar och avfall.
- Fremhevær kravene for avhending av brukte dele og affald.
- Επισημαίνεται τις απαιτήσεις απόρριψης των χρησιμοποιημένων εξαρτημάτων και των απορριμάτων
- Destaca los requisitos para desechar las piezas usadas y los residuos.
- Realça os requisitos para eliminar as peças utilizadas e os desperdícios.
- Segnala i criteri per lo smaltimento di componenti usati e rifiuti.
- Wskazuje wymagania dotyczące usuwania zużytych części i odpadów.
- Zvýrazňuje požiadavky pre zneškodnenie použitých dielov a odpadu.
- Upozornění na požadavky týkající se likvidace použitych dílů a odpadu.
- Tóstab esile kasutatud osade ja jáakide utiliserimisele esitatavad nõuded
- A használt alkatrészek és a hulladék megfelelő módon történő elhelyezésére hívja fel a figyelmet.
- Uzsver prasbas tam, ka atrbīvoties no lietotajām detalām un atkritumiem.
- Žymi panaudotu dalīju ar atlieku išmetimo reikalavimus.
- Указывает на требования по уничтожению использованных деталей и отходов
- Označuje zahteve za odlaganje rabljenih delov in odpadkov.
- Kullanılmış parçaların ve atıkların atılmasıyla ilişkili gereklilikleri vurgular
- Tissottolinea l-kundizzonijiet biex wieħed jarmi l-partijiet użati u l-iskart

	<ul style="list-style-type: none"> <li>Pressure.</li> <li>Paine.</li> <li>Πίεση</li> <li>Ciśnienie</li> <li>Nyomás alatt.</li> <li>Tlak</li> </ul>	<ul style="list-style-type: none"> <li>Druk.</li> <li>Tryck</li> <li>Presión.</li> <li>Tlak..</li> <li>Spiediens.</li> <li>Basinç</li> </ul>	<ul style="list-style-type: none"> <li>Druck.</li> <li>Trykk</li> <li>Pressão.</li> <li>Tlak.</li> <li>Slégis.</li> <li>Pressjoni</li> </ul>	<ul style="list-style-type: none"> <li>Pression.</li> <li>Tryk</li> <li>Pressione.</li> <li>Surve.</li> <li>Давление</li> </ul>
	<ul style="list-style-type: none"> <li>Release Pressure.</li> <li>Evacuation de pression.</li> <li>Avlst trykk</li> <li>Despresurizar.</li> <li>Ciśnienia spustowe</li> <li>Surve väljalase</li> <li>Ísléiskite slégi.</li> <li>Basinci Kaldırın</li> </ul>	<ul style="list-style-type: none"> <li>Druk aflaten.</li> <li>Vapauta paine.</li> <li>Aflast tryk</li> <li>Liberta Pressão.</li> <li>Uvořníte tlak.</li> <li>Engedje ki a nyomást.</li> <li>Справить давление</li> <li>Nehhi I-pressjoni</li> </ul>	<ul style="list-style-type: none"> <li>Druck ablassen.</li> <li>Tryckutsläpp.</li> <li>Εκτόνωση πίεσης</li> <li>Scaricare la pressione.</li> <li>Uvolnění tlaku.</li> <li>Pazeminiel spiedienu.</li> <li>Sprostitev tlaka.</li> </ul>	<ul style="list-style-type: none"> <li>Druck ablassen.</li> <li>Tryckutsläpp.</li> <li>Εκτόνωση πίεσης</li> <li>Scaricare la pressione.</li> <li>Uvolnění tlaku.</li> <li>Pazeminiel spiedienu.</li> <li>Sprostitev tlaka.</li> </ul>
	<ul style="list-style-type: none"> <li>Replace every year</li> <li>Remplacer tous les ans.</li> <li>Skift ut hvert år</li> <li>Sustituir anualmente</li> <li>Naleží wymieniać raz w roku</li> <li>Asendage igal aastal</li> <li>Keiskite karta per metus</li> <li>Her yil değiştirin</li> </ul>	<ul style="list-style-type: none"> <li>Elk jaar vervangen</li> <li>Vaihda vuosittain.</li> <li>Udskift en gang om året</li> <li>Substituir todos os anos</li> <li>Každý rok vymieňajte</li> <li>Évente cserélje</li> <li>Заменять каждый год.</li> <li>Ibdel kull sena</li> </ul>	<ul style="list-style-type: none"> <li>Jährlich austauschen</li> <li>Byt varje år</li> <li>Αντικατασταθεί κάθε χρόνο</li> <li>Sostituire ogni anno</li> <li>Nutná výměna každý rok.</li> <li>Nomainiet reizi gadā</li> <li>Zamenjajte vsako leto.</li> </ul>	<ul style="list-style-type: none"> <li>Jährlich austauschen</li> <li>Byt varje år</li> <li>Αντικατασταθεί κάθε χρόνο</li> <li>Sostituire ogni anno</li> <li>Nutná výměna každý rok.</li> <li>Nomainiet reizi gadā</li> <li>Zamenjajte vsako leto.</li> </ul>
	<ul style="list-style-type: none"> <li>Filter housing / Model</li> <li>Logement du filtre/modèle.</li> <li>Filterhus-/modell</li> <li>Caja de filtro/modelo.</li> <li>Obudowa filtra / model.</li> <li>Filti korpus/mudel</li> <li>Filtro korpusas / modelis</li> <li>Filtre muhafazası / Model</li> </ul>	<ul style="list-style-type: none"> <li>Filterhuis / Model</li> <li>Suodatinotelö-/malli</li> <li>Filterhus/modell</li> <li>Caixa / Modelo do filtro</li> <li>Kryt filtra / Model</li> <li>Szűrőház / típus</li> <li>Korpusc filtra / model</li> <li>Kontenitū tal-filtri - Mudell</li> </ul>	<ul style="list-style-type: none"> <li>Filtergehäuse / Modell</li> <li>Filterhus/modell</li> <li>Υποδοχή/μοντέλο φίλτρου</li> <li>Corpo del filtro / Modello</li> <li>Kryt filtru / Model</li> <li>Filtra korpuiss / modelis</li> <li>Ohišje filtra / Model</li> </ul>	<ul style="list-style-type: none"> <li>Filtergehäuse / Modell</li> <li>Filterhus/modell</li> <li>Υποδοχή/μοντέλο φίλτρου</li> <li>Corpo del filtro / Modello</li> <li>Kryt filtru / Model</li> <li>Filtra korpuiss / modelis</li> <li>Ohišje filtra / Model</li> </ul>
	<ul style="list-style-type: none"> <li>High efficiency filter element</li> <li>Hochleistungsfilterelement</li> <li>Tehokas suodatinelementti</li> <li>Høyeffektiv filterelement</li> <li>Φίλτρο υψηλής απόδοσης</li> <li>Elemento do filtro de elevado rendimento</li> <li>Wysokowydajny wkład filtra</li> <li>Výsoce účinný filtrační prvek</li> <li>Nagy hatékony szűrélem</li> <li>Labai efektívus filtravimo elementas</li> <li>Visoko učinkovit filtrirni element</li> <li>Element tal-filtri b'efficjenza kbira</li> </ul>	<ul style="list-style-type: none"> <li>• Zeer efficiënt filterelement</li> <li>• Cartouche filtrante haute efficacité.</li> <li>• Högeffektiv filterelement</li> <li>• Högeffektiv filterelement</li> <li>• Elemento filtrante de gran eficiencia.</li> <li>• Elemento filtrante ad alta efficienza</li> <li>• Vysoko účinný filtračný článok</li> <li>• Körktöltik filterelement</li> <li>• Augstas produktivitātes filtra elements</li> <li>• Высокоэффективный фильтрующий элемент</li> <li>• Yüksek etkinlikli filtre öğesi</li> </ul>	<ul style="list-style-type: none"> <li>• Zeer efficiënt filterelement</li> <li>• Cartouche filtrante haute efficacité.</li> <li>• Högeffektiv filterelement</li> <li>• Högeffektiv filterelement</li> <li>• Elemento filtrante de gran eficiencia.</li> <li>• Elemento filtrante ad alta efficienza</li> <li>• Vysoko účinný filtračný článok</li> <li>• Körktöltik filterelement</li> <li>• Augstas produktivitātes filtra elements</li> <li>• Высокоэффективный фильтрующий элемент</li> <li>• Yüksek etkinlikli filtre öğesi</li> </ul>	<ul style="list-style-type: none"> <li>• Zeer efficiënt filterelement</li> <li>• Cartouche filtrante haute efficacité.</li> <li>• Högeffektiv filterelement</li> <li>• Högeffektiv filterelement</li> <li>• Elemento filtrante de gran eficiencia.</li> <li>• Elemento filtrante ad alta efficienza</li> <li>• Vysoko účinný filtračný článok</li> <li>• Körktöltik filterelement</li> <li>• Augstas produktivitātes filtra elements</li> <li>• Высокоэффективный фильтрующий элемент</li> <li>• Yüksek etkinlikli filtre öğesi</li> </ul>
	<ul style="list-style-type: none"> <li>Adsorption filter cartridge - Granular carbon</li> <li>Adsorptionsfiltereinsatz - Granulatkohle</li> <li>Adsorptionsuodateinelementti - rakeinen hiili</li> <li>Adsorpsjonsfilterpatron - Karbon i konform</li> <li>Φυσιγύο φίλτρου προσρόφησης - Κοκκώδης άνθρακας</li> <li>Cartucho do filtro de adsorcão - Carvão granular</li> <li>Adsorpçyni wkład filtrujący z węglem ziarnistego</li> <li>Adsorpçni filtrační prvek – granulovaný uhlík</li> <li>Adsorpcíos szűróbetét – granulált szén</li> <li>Adsorbcinio filtro kasetė – anglies granulés</li> <li>Kaseta adsorpcjskega filtra – zrnasti ogljik</li> <li>Kaxxa assorbenti tal-filtri – Karbonju mrammel</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter cartridge - korrelvormige actieve kool</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone</li> <li>Adsorpčná filtračná kazeta – Granulovaný uhlík</li> <li>Adsorpcionsfilter kassett – teraline súsi</li> <li>Absorbējoša filtra kasetne – graudains oglekis</li> <li>Adsorbcionny filtry kasetne – гранулированный уголь</li> <li>Adsorpsiyon filtersi kartusu – Taneli karbon</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter cartridge - korrelvormige actieve kool</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone</li> <li>Adsorpčná filtračná kazeta – Granulovaný uhlík</li> <li>Adsorpcionsfilter kassett – teraline súsi</li> <li>Absorbējoša filtra kasetne – graudains oglekis</li> <li>Adsorbcionny filtry kasetne – гранулированный уголь</li> <li>Adsorpsiyon filtersi kartusu – Taneli karbon</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter cartridge - korrelvormige actieve kool</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone</li> <li>Adsorpčná filtračná kazeta – Granulovaný uhlík</li> <li>Adsorpcionsfilter kassett – teraline súsi</li> <li>Absorbējoša filtra kasetne – graudains oglekis</li> <li>Adsorbcionny filtry kasetne – гранулированный уголь</li> <li>Adsorpsiyon filtersi kartusu – Taneli karbon</li> </ul>
	<ul style="list-style-type: none"> <li>Adsorption filter element - Wrapped carbon cloth</li> <li>Adsorpçie filterelement - gewikkeld koolstofdoek</li> <li>Adsorptionsfilterelement - eingewickeltes Filtertuch aus Kohlenstoff</li> <li>Cartouche filtrante d'adsorption - Charbon entouré de tissu.</li> <li>Adsorptionsuodateinelementti - kääritty hiilikangas</li> <li>Adsorptionsfilterelement - Veckad kolfiberduk</li> <li>Adsorpsjonsfilterelement – Innipakket karbonstoff</li> <li>Adsorptionsfilterelement - Veckad kolfiberduk</li> <li>Φίλτρο προσρόφησης - Τυλιγμένο ύφασμα άνθρακα</li> <li>Elemento filtrante de adsorción, capas de tejido de carbón.</li> <li>Elemento do filtro de adsorcão - Pano revestido de carvão</li> <li>Elemento filtrante ad adsorbimento - tessuto al carbone con struttura ad avvolgimento</li> <li>Wkład adsorpçyni filtra ze zwijanej tkaniny z włókną węglowego</li> <li>Adsorpçni filtrační článok - Zabalená uhlíková tkanina</li> <li>Adsorpçni filtrační prvek - zabalena uhlíková tkanina</li> <li>Adsorpcionsfilter element - isoleeritud süsinikriie</li> <li>Adsorpcios szűróelem - göngölyt szénszövet</li> <li>Absorbējošs filtra elements – satīta oglekla drānīna</li> <li>Adsorbcinis filtravimo elementas – susuktas anglies audinys</li> <li>Адсорбционный фильтрующий элемент – ткань из углеродистого волокна</li> <li>Adsorpcjiski filtrimi element - navita ogljkova krpa</li> <li>Adsorpsiyon filtersi ögesi - Sarılı karbon kumaş</li> <li>Element tal-filtri li jassorbixxi - Xoqqa tal-karbonju mgeżwra</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter element -Wrapped carbon cloth</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone</li> <li>Adsorpčná filtračná kazeta – Granulovaný uhlík</li> <li>Adsorpcionsfilter kassett – teraline súsi</li> <li>Absorbējoša filtra kasetne – graudains oglekis</li> <li>Adsorbcionny filtry kasetne – гранулированный уголь</li> <li>Adsorpsiyon filtersi kartusu – Taneli karbon</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter element -Wrapped carbon cloth</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone</li> <li>Adsorpčná filtračná kazeta – Granulovaný uhlík</li> <li>Adsorpcionsfilter kassett – teraline súsi</li> <li>Absorbējoša filtra kasetne – graudains oglekis</li> <li>Adsorbcionny filtry kasetne – гранулированный уголь</li> <li>Adsorpsiyon filtersi kartusu – Taneli karbon</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter element -Wrapped carbon cloth</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone</li> <li>Adsorpčná filtračná kazeta – Granulovaný uhlík</li> <li>Adsorpcionsfilter kassett – teraline súsi</li> <li>Absorbējoša filtra kasetne – graudains oglekis</li> <li>Adsorbcionny filtry kasetne – гранулированный уголь</li> <li>Adsorpsiyon filtersi kartusu – Taneli karbon</li> </ul>
	<ul style="list-style-type: none"> <li>Ensure correct tool is used</li> <li>Zorg dat het juiste gereedschap wordt gebruikt</li> <li>Vérifier que les outils adéquats sont utilisés.</li> <li>Se till att rätt verktyg används.</li> <li>Sørg for at benytte korrekt værkøj</li> <li>Asegúrese de que se utiliza la herramienta adecuada</li> <li>Assicurarsi di utilizzare l'utensile corretto</li> <li>Uistite sa, že používate správny nástroj</li> <li>Tagago òige tööriista kasutamine</li> <li>Izmantojiet tikai atbilstošus darbarīkus</li> <li>Убедитесь, что используется правильный инструмент</li> <li>Doğru alet kullanılmamasını sağlayın</li> </ul>	<ul style="list-style-type: none"> <li>Stellen Sie sicher, dass Sie das richtige Werkzeug verwenden.</li> <li>• Käytetään oikeaa työkalua</li> <li>• Pass på att korrekt verktyg brukas</li> <li>• Βεβαιωθείτε ότι χρησιμοποιείται το σωστό εργαλείο</li> <li>• Certifique-se de que é utilizada a ferramenta correcta</li> <li>• Należy używać odpowiedniego narzędzia.</li> <li>• Zkontrolujte použití správného nástroje</li> <li>• Mindig a célnak megfelelő szerszámot használja</li> <li>• Ізтікінкіте, кад наудожамас reikiamas ірекісі</li> <li>• Poskrbite, da boste uporabili ustrezno orodje</li> <li>• Kun žgur li tintuża l-ghoddha t-tajba</li> </ul>	<ul style="list-style-type: none"> <li>Stellen Sie sicher, dass Sie das richtige Werkzeug verwenden.</li> <li>• Käytetään oikeaa työkalua</li> <li>• Pass på att korrekt verktyg brukas</li> <li>• Βεβαιωθείτε ότι χρησιμοποιείται το σωστό εργαλείο</li> <li>• Certifique-se de que é utilizada a ferramenta correcta</li> <li>• Należy używać odpowiedniego narzędzia.</li> <li>• Zkontrolujte použití správného nástroje</li> <li>• Mindig a célnak megfelelő szerszámot használja</li> <li>• Ізтікінкіте, кад наудожамас reikiamas ірекісі</li> <li>• Poskrbite, da boste uporabili ustrezno orodje</li> <li>• Kun žgur li tintuża l-ghoddha t-tajba</li> </ul>	<ul style="list-style-type: none"> <li>Stellen Sie sicher, dass Sie das richtige Werkzeug verwenden.</li> <li>• Käytetään oikeaa työkalua</li> <li>• Pass på att korrekt verktyg brukas</li> <li>• Βεβαιωθείτε ότι χρησιμοποιείται το σωστό εργαλείο</li> <li>• Certifique-se de que é utilizada a ferramenta correcta</li> <li>• Należy używać odpowiedniego narzędzia.</li> <li>• Zkontrolujte použití správného nástroje</li> <li>• Mindig a célnak megfelelő szerszámot használja</li> <li>• Ізтікінкіте, кад наудожамас reikiamas ірекісі</li> <li>• Poskrbite, da boste uporabili ustrezno orodje</li> <li>• Kun žgur li tintuża l-ghoddha t-tajba</li> </ul>

**Warning!**

This product must be installed and maintained by competent and authorised personnel only, under strict observance of these operating instructions, any relevant standards and legal requirements where appropriate.

**Retain this user guide for future reference**

**Waarschuwing!**

Dit product mag alleen geïnstalleerd en onderhouden worden door deskundig en bevoegd personeel met strikte inachtneming van deze bedieningsinstructies en de betreffende normen en wettelijke vereisten indien van toepassing.

**Bewaar deze handleiding als naslag.**

**Warnung!**

Das Produkt darf ausschließlich von autorisiertem Fachpersonal unter strikter Befolgung dieser Betriebsanleitung, ggf. relevanter Normen sowie gesetzlicher Vorschriften installiert und gewartet werden.

**Bewahren Sie die Bedienungsanleitung zu Referenzzwecken auf.**

**Attention !**

Ce produit doit être installé et entretenu exclusivement par un personnel compétent et autorisé, dans le respect le plus strict de ce mode d'emploi et des normes applicables et exigences légales éventuelles.

**Conserver ce guide de l'utilisateur à titre de référence future**

**Varoitus!**

Tämän tuotteen saa asentaa ja huoltaa vain pätevä ja valtuutettu henkilöstö, noudattaen tarkasti näitä käyttöohjeita, kaikkia asiaankuuluvia normeja ja tarpeen vaatiessa lain asettamia vaatimuksia.

**Säilytä tämä käyttöohje tulevaa tarvetta varten.**

**Varning!**

Produkten får endast installeras och underhållas av utbildad och behörig personal, som följer denna bruksanvisning och eventuella tillämpliga normer och lagföreskrifter noga i förekommande fall.

**Behåll denna användarhandbok som referens**

**Advarsel!**

Dette produktet må bare installeres og vedlikeholdes av kompetent og autorisert personale, i streng overholdelse av disse betjeningsanvisningene, alle relevante standarder og rettslige krav der det passer.

**Ta vare på denne brukerveiledningen for senere bruk**

**Advarsel!**

Dette produktet må kun installeres og vedlikeholdes af autoriseret personale, under nøje overholdelse af disse driftsinstruktioner, relevante standarder og lovgivningsmæssige krav, hvor dette er aktuelt.

**Gem denne vejledning til senere reference.**

**Προειδοποίηση!**

H εγκατάσταση και συντήρηση αυτού του προϊόντος πρέπει να γίνεται μόνο από κατάλληλα εκπαιδευμένο και εξουσιοδοτημένο προσωπικό, με αυστηρή τήρηση των οδηγιών χειρισμού, των εφαρμοζόμενων προτύπων και των νομικών απαιτήσεων όπου απαιτείται.

**Φυλάξτε αυτό το εγχειρίδιο χρήσης για μελλοντική αναφορά**

**Advertencia**

La instalación y mantenimiento de este producto debe ser efectuada únicamente por personal competente y autorizado, respetándose de forma estricta estas instrucciones de funcionamiento, así como cualquier norma y requerimiento legal que sean aplicables.

**Conserve esta guía del usuario para poder consultarla en el futuro.**

**Advertência!**

A instalação e a manutenção deste produto só deve ser realizada por pessoal autorizado e competente, sob estrita observância destas instruções de utilização e de quaisquer normas e requisitos legais relevantes, quando adequado.

**Conserve este guia do utilizador para referência futura**


**Rakkomandazzjonijiet ghall-Installazzjoni**

Nirrakkomandaw li l-arja kompressata tiġi trattata qabel ma tidhol fis-sistema ta' distribuzzjoni kif ukoll fil-punti ċi l-applikazzjonijiet kritici ta' l-użu.

L-installazzjoni ta' tagħmir li jnixxef l-arja kumpressata fuq sistema li kienet inxarrba jista' jirriżulta f'aktar tagħbjia ta' hmiegħ għall-filtri li jintużaw f-punt wieħed, għall-perjodu sakemm is-sistema ta' distribuzzjoni tinxxf. L-elementi tal-filtri jista' jkollhom bżonn li jinbidlu aktar spiss matul dan il-perjodu.

Għal installazzjonijiet fejn jintużaw kumpressuri mingħajr jejt, xorta jkun hemm preżenti ajrusols u partijet ta' l-ilma, għalhekk xorta għandhom jintużaw grad bi skop generali u b'efficċjenza kbira.

Filtu għal skopijiet generali għandu dejjem jiġi installat biex jipprotegi l-filtri ta' efficċjenza kbira mill-volum kbir ta' ajrusols likwid u partijet solidi.

Installa tagħmir ta' purifikazzjoni fl-aktar temperatura baxxa possibbi imma b'mod li ma jkunx hemm iffrizziar, preferibilment aktar 'l-isfel mill-aftercoolers u mir-riċevituri ta' l-arja.

Tagħmir tal-purifikazzjoni fil-punt ta' l-użu għandu jiġi installat kemm jista' jkun qrib tal-post fejn għandu jaapplika.

It-tagħmir ta' purifikazzjoni m'għandux jiġi installat aktar 'l-isfel mill-valvs li jifthu malajr u għandu jkun protett minn possibilità ta' fluss b'lura jew kundizzjonijiet oħra stressanti.

Naddaf il-pajps kollha li jwasslu għaż-żejt tagħmir ta' purifikazzjoni qabel tinstalla u l-pajps kollha wara li tinstalla t-taghħmir ta' purifikazzjoni u qabel ma tqabbar ma' l-applikazzjoni finali.


Jekk tififtija linji ta' by-pass madwar it-taghħmir ta' purifikazzjoni, kun żgur li hemm biżżejjed filtrazzjoni ffifttata mal-linjal ta-by-pass biex ma thallix li jkun hemm kontaminazzjoni tas-sistema aktar 'l-isfel.



Ipprovi facilità biex tiddrejnejna l-likwidli li jingħabru mit-taghħmir tal-purifikazzjoni. Il-likwidli li jingħabru għandhom jiġu trattati u mormija b'mod risponsabli.

Iż-żmien kemm idumu jservu l-elementi tal-filtri li jneħħi l-fwar taż-żjut huwa affettwat mill-konċentrazzjoni taż-żejt tad-dħul, l-umdità relativa u t-temperatura tas-sistema ta' l-arja kumpressata. L-elementi li jneħħu l-fwar taż-żjut ikollhom bżonn jinbidlu aktar ta' sikkut mill-element shiħi ekwivalenti.

Mudelli AC010□□□ - AC030□□□ huma ffifttati b'indikatur tal-volum taż-żejt. Kemm l-elementi tal-filtri kif ukoll l-indikatur għandhom jinbidlu jekk l-indikatur isir ta' kultur blu.

**Jekk Joghġbok Innota - Dan hu indikatur tal-volum taż-żejt u ma jindikax iż-żmien li jdum iservi l-element tal-filtri.**





**5. Spare Parts (Service Kits)**

Reserve-onderdelen (servicekits) • Ersatzteile (Service-Kits) • Pièces de rechange (nécessaires d'entretien) • Varaosat (Huoltopakkaukset)


• Reservdelar (servicesatser) • Reservedeler (service-sett) • Reservedelele (Servicekit) • Ανταλλακτικά (Πακέτα τεχνικής υποστήριξης)

• Piezas de repuesto (kits de mantenimiento) • Peças Sobressalentes (Kit de Reparação) • Ricambi (kit per l'assistenza)



• Części zamiennne (zestawy serwisowe) • Náhradné diely (Servisná súprava) • Náhradní díly (Sady pro údržbu) • Varuosad (hoolekomplektid)


• Pótalkatrészek (szervizkészletek) • Rezerves daļas (apkopes komplekti) • Atsarginės dalys (priežiuros detalių komplektai)

• Запасные части (ЗИП) • Nadomestni deli (servisni komplet) • Yedek parça (Servis kitleri) • Partijiet Għat-Tibdil (Kitts tas-Servizz)

 EF1	<ul style="list-style-type: none"> <li>• AUTOMATIC DRAIN</li> <li>• AUTOMATISCHER ABLAUF</li> <li>• VIDANGE AUTOMATIQUE</li> <li>• AUTOMISCHAFTAPPEN</li> <li>• DRENAJE AUTOMATICO</li> <li>• SCARIO AUTOMATICO</li> <li>• AUTOMATISK AFLØB</li> <li>• DRENO AUTOMÁTICO</li> <li>• AYTOMATH ΑΠΟΣΤΡΑΓΓΙΣΗ</li> <li>• AUTOMATDRÄNERING</li> <li>• AUTOMAATTINEN</li> <li>• TYHJENNYSKAPPALE</li> <li>• DREN AUTOMATYCZNY</li> <li>• AUTOMATICKE VYSUŠENIE</li> <li>• AUTOMATICKE VYPOUŠTĚNÍ</li> <li>• AUTOMAATNE VÄLJALASE</li> <li>• AUTOMATIKUS LEERESZTÉS</li> <li>• AUTOMÁTISKA IZTECINĀŠANA</li> <li>• AUTOMATINIS IŠLEIDIMAS</li> <li>• АВТОМАТИЧЕСКИЙ ДРЕНАЖ</li> <li>• SAMODEJNI ODTOK</li> <li>• OTOMATİK SÜZDÜRÜCÜ</li> <li>• DREJN AWATOMATIKU</li> </ul>	 EM1	<ul style="list-style-type: none"> <li>• MANUAL DRAIN</li> <li>• MANUELLE ABLAUF</li> <li>• VIDANGE MANUELLE</li> <li>• MANUEEL AFTAPPEN</li> <li>• DRENAJE MANUAL</li> <li>• SCARIO MANUALE</li> <li>• MANUELT AFLØB</li> <li>• DRENO MANUAL</li> <li>• ΧΕΙΡΟΚΙΝΗΤΗ ΑΠΟΣΤΡΑΓΓΙΣΗ</li> <li>• MANUELL DRÄNERING</li> <li>• KÄSIKÄYTTÖINEN</li> <li>• TYHJENNYSKAPPALE</li> <li>• DREN RĘCZNY</li> <li>• RUČNÉ VYSUŠENIE</li> <li>• RUČNÍ VYPOUŠTĚNÍ</li> <li>• KÄSITSI VÄLJALASE</li> <li>• KÉZI LEERESZTÉS</li> <li>• MANUĀLA IZTECINĀŠANA</li> <li>• RANKINIS IŠLEIDIMAS</li> <li>• ДРЕНАЖ ВРУЧНУЮ</li> <li>• ROČNÍ ODTOK</li> <li>• ELLE KULLANILACAK SÜZDÜRÜCÜ</li> <li>• DREJN MANWALI</li> </ul>
--	---	--	---


 010 A
 010 B
 010 C
 015 B
 015 C
 020 C
 020 D
 020 E
 025 D
 025 E
 030 E
 030 F
 030 G

 AA	 AC	 AC
 010AA	 010AC	 015AC
 015AA		
 020AA	 020AC	 025DAC
 025AA		
 025EAC		
 030AA	 030AC	 030AC



**AC010 - AC030**
**6. Maintenance**

Onderhoud • Wartung • Entretien • Kunnossapito • Underhåll • Vedlikehold • Vedligeholdelse • Συντήρηση • Mantenimiento • Manutenção • Manutenzione • Konserwacja • Údržba • Údržba • Hooldus • Karbantartás • Tehnická apkope • Techninė priežiūra • Обслуживание • Vzdrževanja • Bakım • Manutenzjoni



Models AC010□□□I - AC030□□□I are fitted with a bulk oil indicator. Both filter elements and indicator should be changed if indicator is blue in colour.

**Please Note - This is a bulk oil indicator, it does not indicate filter element life.**

Modellen AC010□□□I - AC030□□□I zijn uitgerust met een bulk olie indicator. Zowel de filterelementen als de indicator moeten vervangen worden als de indicator blauw van kleur is.

**N.B. - Dit is een bulk olie indicator, het is geen indicator voor de levensduur van het filterelement.**

Die Modelle AC010□□□I - AC030□□□I sind mit einer Ölanzeige ausgestattet. Sowohl die Filterelemente also auch die Anzeige sollte ausgetauscht werden, wenn sich die Anzeige blau färbt.

**Bitte beachten - Es handelt sich hier um eine Ölzanzeige. Diese gibt keinen Hinweis auf die Lebensdauer des Filterelements.**

Les modèles AC010□□□I - AC030□□□I sont fournis avec un indicateur de présence massive d'huile. Lorsque l'indicateur est bleu, il est nécessaire de remplacer les cartouches et l'indicateur.

**Remarque : Il s'agit d'un indicateur de présence massive d'huile, et non pas de la durée de vie des cartouches.**

Malleissa AC010□□□I - AC030□□□I on öljynilmäisin. Sekä suodatinelementit että ilmäisin on vaihdettava, jos ilmäisin on sininen.

**Huomautus – Tämä on öljynilmäisin. Se ei ilmaise suodatinelementin ikää.**

Modell AC010□□□I - AC030□□□I har en indikator för större mängder olja. Både filterelement och indikator ska bytas om indikatorn har blå färg.

**Observera — indikatorn visar oljeförekomst, den indikerar inte filterelementets livslängd.**

Modell AC010□□□I - AC030□□□I er montert med bulkvolum oljeindikator. Både filterelementer og indikator skal skiftes når indikatoren er blå.

**Merk – Dette er en bulkvolum oljeindikator, den indikerer ikke filterelementets levetid.**

Modell AC010□□□I - AC030□□□I har en indikator för större mängder olja. Både filterelement och indikator ska bytas om indikatorn har blå färg.

**Observera — indikatorn visar oljeförekomst, den indikerar inte filterelementets livslängd.**

Τα μοντέλα AC010□□□I - AC030□□□I διαθέτουν ένα δείκτη παρουσίας λαδιού. Όταν ο δείκτης είναι μπλε πρέπει να αλλάζονται τόσο τα φίλτρα όσο και οι δείκτες.

**Παρακαλούμε σημειώστε ότι - Αυτός είναι ένας δείκτης παρουσίας λαδιού, δεν υποδεικνύει τη διάρκεια ζωής του φίλτρου.**

Los modelos AC010□□□I - AC030□□□I disponen de un indicador de presencia de aceite. Si el indicador se vuelve azul deben cambiarse tanto los elementos filtrantes como el indicador.


**Nota importante: se trata de un indicador de presencia de aceite. No indica la vida del elemento filtrante.**

Modelos AC010□□□I - AC030□□□I são instalados com um indicador do óleo em bruto. Ambos os elementos do filtro e o indicador deverão ser mudados se o indicador estiver azul.


**Nota - Este é um indicador do óleo em bruto, não indica a vida útil do elemento do filtro.**

I modelli AC010□□□I - AC030□□□I sono provvisti di un indicatore degli oli misti. Sostituire gli elementi filtranti e l'indicatore quando il secondo assume una colorazione blu.


**Nota - L'indicatore segnala la presenza di oli misti, ma non la durata dell'elemento filtrante.**




**7**




**8**




**9**




**10**




**11**




**12**




13



14



15



<b>Declaration of Conformity</b>		<b>Verklaring van Conformiteit</b>		<b>Konformitätsserklärung</b>		<b>DE</b>	
Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ, UK <b>AC010, 015, 020 025, 030</b>	domnick hunter	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ, GB <b>AC010, 015, 020 025, 030</b>	domnick hunter	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ GROSSBRITANNIEN <b>AC010, 015, 020 025, 030</b>	domnick hunter	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ GROSSBRITANNIEN <b>AC010, 015, 020 025, 030</b>	domnick hunter
<b>Directives</b>	97/23/EC.	<b>Richtlijnen</b>	97/23/EC.	<b>Richtlinien</b>	97/23/EC.	<b>Angewandte Normen</b>	Allgemein in Übereinstimmung mit ASME/VIII Div : 2004.
<b>Standards used</b>	Generally in accordance with ASME/VIII Div 1 : 2004.	<b>Gehanteerde normen</b>	Gewoonlijk volgens ASME/VIII Div 1 : 2004.	<b>Beurteilungsroute der Druckgeräterichtlinie:</b>	Artikel 3.3 (AC010, 015, 020, 025) Modul A (AC030)	<b>Benannte Stelle für die Druckgeräterichtlinie:</b>	Modul A (AC030)
<b>PEI Assessment Route :</b>	Article 3.3 (AC 010, 015, 020, 025) Module A (AC 030)	<b>Aangemelde instantie voor PED:</b>	N/A	<b>EG-Baumusterprüfungsberechtigung:</b>	N/A	<b>Bevolmächtigter Vertreter</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd
<b>Notified body for PED:</b>	N/A	<b>EC Type onderzoeks certificaat:</b>	N/A	<b>Bevoegde vertegenwoordiger</b>	Barry Wade Manager Bedrijfssysteemverbetering domnick hunter ltd	<b>Erklärung</b>	Hiermit erkläre ich als bevollmächtigter Vertreter die Konformität der oben aufgeführten Informationen in Bezug auf die Lieferung Herstellung dieses Produkts mit den Normen und anderen zugehörigen Dokumenten gemäß den Bestimmungen der oben genannten Richtlinien.
<b>EC Type-examination Certificate:</b>	N/A	<b>Verklaring</b>	Als bevoegde vertegenwoordiger verklaar ik dat bovenstaande informatie met betrekking tot de levering / verkoop van dit product overeenstemt met de normen en andere bijbehorende documentatie volgens de bepalingen van bovengenoemde richtlijnen.	<b>Handtekening:</b>	<i>Domnick</i>	<b>Datum:</b>	28 / 09 / 05
<b>Authorised Representative</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd	<b>Verklaringnummer:</b>	0001/280905	<b>Unterschrift:</b>	<i>Domnick</i>	<b>Datum:</b>	28 / 09 / 05
<b>Declaration</b>	I declare that as the authorised representative, the above information in relation to the supply / manufacture of this product, is in conformity with the standards and other related documents following the provisions of the above Directives.						Nummer der Erklärung: 0001/280905
<b>Signature:</b>	<i>Domnick</i>	<b>Date:</b>	28 / 09 / 05	<b>Vaatimustenmukaisusvakuutus</b>	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ ISO-BRITANNIA <b>AC010, 015, 020 025, 030</b>	<b>Förskräkten om överensstämmelse</b>	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ, Storbritannien <b>AC010, 015, 020 025, 030</b>
<b>Declaration Number:</b>	0001/280905	<b>Directive:</b>	97/23/EC.	<b>Direktiv</b>	97/23/EC.	<b>Använda standarder</b>	Generell i enlighet med ASME/VIII Div 1 : 2004.
<b>Directives</b>	97/23/EC.	<b>Käytetty standard</b>	Yleensä seuraavan standardin mukaisesti: ASME/VIII Div 1 : 2004.	<b>PED-användningsmetyl:</b>	Artikel 3.3 (AC010, 015, 020, 025, 030) Modul A (AC030)	<b>Fastställningsavg för PED:</b>	Artikel 3.3 (AC010, 015, 020, 025, 030) Modul A (AC030)
<b>Norms utilisées</b>	Généralement conforme à ASME/VIII Div 1 : 2004.	<b>Organisme de notification pour la directive d'équipement de pression :</b>	N/A	<b>Amält organ för PED:</b>	N/A	<b>EG-intyg om typrovnings:</b>	N/A
<b>Méthode d'évaluation de la directive d'équipements de pression :</b>	Article 3.3 (AC010, 015, 020, 025, 030) Module A (AC030)	<b>Certificat d'examen de type CE :</b>	N/A	<b>Auktoriserad representant</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd	<b>Vakuutus</b>	Jag försäkrar i egenskap av auktorisera representant, att ovannämnda information avseende leverans/leverering av detta produkt överensstämmer med standarder och övriga relevanta dokument enligt vilket en överensställe direktiv.
<b>Représentant agréé</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd	<b>Allekiratkaisu:</b>	<i>Domnick</i>	<b>Päivitys:</b>	28 / 09 / 05	<b>Förskräkten:</b>	Domnick Förskräkten nummer: 0001/280905
<b>Declaration</b>	Je déclare à titre de représentant agréé que les informations ci-dessus liées à la fourniture/fabrication de ce produit sont en conformité avec les normes et autres documents lis déclarés selon les dispositions des directives susmentionnées.						N° de déclaration : 0001/280905
<b>Signature :</b>	<i>Domnick</i>	<b>Date :</b>	28 / 09 / 05	<b>FR</b>	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ GB <b>AC010, 015, 020 025, 030</b>	<b>FI</b>	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ ISO-BRITANNIA <b>AC010, 015, 020 025, 030</b>
<b>Directives</b>	97/23/EC.	<b>Käytetty standard</b>	Yleensä seuraavan standardin mukaisesti: ASME/VIII Div 1 : 2004.	<b>Direktiv</b>	97/23/EC.	<b>Använda standarder</b>	Generell i enlighet med ASME/VIII Div 1 : 2004.
<b>Norms utilisées</b>	Généralement conforme à ASME/VIII Div 1 : 2004.	<b>PED-användningsmetyl:</b>	Artikel 3.3 (AC010, 015, 020, 025, 030) Modul A (AC030)	<b>Fastställningsavg för PED:</b>	Artikel 3.3 (AC010, 015, 020, 025, 030) Modul A (AC030)	<b>Amält organ för PED:</b>	N/A
<b>Méthode d'évaluation de la directive d'équipements de pression :</b>	Article 3.3 (AC010, 015, 020, 025, 030) Module A (AC030)	<b>Organisme de notification pour la directive d'équipement sous pression :</b>	N/A	<b>EG-intyg om typrovnings:</b>	N/A	<b>Vakuutus</b>	Jag försäkrar i egenskap av auktorisera representant, att ovannämnda information avseende leverans/leverering av detta produkt överensstämmer med standarder och övriga relevanta dokument enligt vilket en överensställe direktiv.
<b>Représentant agréé</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd	<b>Certificat d'examen de type CE :</b>	N/A	<b>Auktoriserad representant</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd	<b>Förskräkten:</b>	Domnick Förskräkten nummer: 0001/280905
<b>Declaration</b>	Je déclare à titre de représentant agréé que les informations ci-dessus liées à la fourniture/fabrication de ce produit sont en conformité avec les normes et autres documents lis déclarés selon les dispositions des directives susmentionnées.						N° de déclaration : 0001/280905
<b>Signature :</b>	<i>Domnick</i>	<b>Date :</b>	28 / 09 / 05	<b>SV</b>	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ, Storbritannien <b>AC010, 015, 020 025, 030</b>	<b>Förskräkten om överensstämmelse</b>	Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ GROSSBRITANNIEN <b>AC010, 015, 020 025, 030</b>
<b>Directives</b>	97/23/EC.	<b>Direktivet</b>	97/23/EC.	<b>Direktiv</b>	97/23/EC.	<b>Använda standarder</b>	Generell i enlighet med ASME/VIII Div 1 : 2004.
<b>Norms utilisées</b>	Généralement conforme à ASME/VIII Div 1 : 2004.	<b>Käytetty standard</b>	Yleensä seuraavan standardin mukaisesti: ASME/VIII Div 1 : 2004.	<b>PED-användningsmetyl:</b>	Artikel 3.3 (AC010, 015, 020, 025, 030) Modul A (AC030)	<b>Fastställningsavg för PED:</b>	Artikel 3.3 (AC010, 015, 020, 025, 030) Modul A (AC030)
<b>Méthode d'évaluation de la directive d'équipements de pression :</b>	Article 3.3 (AC010, 015, 020, 025, 030) Module A (AC030)	<b>Organisme de notification pour la directive d'équipement sous pression :</b>	N/A	<b>Amält organ för PED:</b>	N/A	<b>EG-intyg om typrovnings:</b>	N/A
<b>Représentant agréé</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd	<b>Certificat d'examen de type CE :</b>	N/A	<b>Auktoriserad representant</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd	<b>Vakuutus</b>	Jag försäkrar i egenskap av auktorisera representant, att ovannämnda information avseende leverans/leverering av detta produkt överensstämmer med standarder och övriga relevanta dokument enligt vilket en överensställe direktiv.
<b>Declaration</b>	Je déclare à titre de représentant agréé que les informations ci-dessus liées à la fourniture/fabrication de ce produit sont en conformité avec les normes et autres documents lis déclarés selon les dispositions des directives susmentionnées.						N° de déclaration : 0001/280905
<b>Signature :</b>	<i>Domnick</i>	<b>Date :</b>	28 / 09 / 05	<b>Förskräkten:</b>	<i>Domnick</i>	<b>Förskräkten:</b>	Domnick Förskräkten nummer: 0001/280905

