

JUMO LOGOSCREEN 601

Paperless Recorder with Touchscreen



Operating Manual



70652100T90Z001K000

V3.00/EN/00710333/2021-06-28

1	Introduction	9
1.1	Safety information	9
1.2	Intended use	10
1.3	Qualification of personnel	10
1.4	Acceptance of goods, storage, and transport	10
1.4.1	Checking the delivery	10
1.4.2	Important information about storage and transport	10
1.4.3	Returning goods	10
1.4.4	Disposal	11
1.5	Identifying the device version	12
1.5.1	Nameplate	12
1.5.2	Order details	13
1.5.3	Scope of delivery	14
1.5.4	Accessories	14
1.6	Content of the technical documentation	15
1.6.1	Device documentation in printed form	15
1.6.2	Device documentation in the form of PDF files	15
1.6.3	Documentation for optional software	16
1.7	Device version	16
2	Description	17
2.1	Brief description	17
2.2	Block diagram	17
2.3	Display and control elements	18
2.4	Connection elements	18
3	Mounting	19
3.1	General information on mounting	19
3.2	Dimensions	20
3.3	Panel mounting	21
3.4	Handling the front of the device	21
3.5	Terminal cover (accessories)	22
3.6	Universal carrying case, compact (extra code 970)	23
4	Electrical connection	25
4.1	Installation notes	25
4.2	Galvanic isolation	26
4.3	Connection elements	27
4.4	Connection diagram	29
4.4.1	Analog inputs	29
4.4.2	Digital inputs	31
4.4.3	Analog outputs	32

Contents

4.4.4	Digital inputs/outputs	33
4.4.5	Relays	34
4.4.6	RS232/RS485 interface	35
4.4.7	Ethernet/PROFINET	35
4.4.8	Voltage supply	35
5	Operation	37
5.1	Operating concept	37
5.1.1	Touchscreen	37
5.1.2	LED displays	39
5.2	Main menu	40
5.2.1	Logon	40
5.2.2	Configuration	41
5.2.3	Parameterization	41
5.2.4	Device information	41
5.2.5	Audit trail list	41
5.2.6	Service	42
5.2.7	Calibrating the touchscreen	42
5.3	Alarm and event menu	42
5.3.1	Alarm list	43
5.3.2	Event list	44
5.4	Visualization menu (display)	46
5.4.1	Curve diagram	47
5.4.2	Digital diagram	50
5.4.3	Bar graph	51
5.4.4	Text image	52
5.4.5	Report	55
5.4.6	Current batch	57
5.4.7	Completed batch	58
5.4.8	Process screen	60
5.4.9	Counter/integrator	60
5.4.10	Comment text	61
5.5	Text input dialog	62
5.6	Flash manager	65
5.7	Web server	68
5.8	Electronic signature	69
6	Setup program	75
6.1	Installation	75
6.1.1	Hardware and software requirements	75
6.1.2	Installing and starting the program	75
6.1.3	Logon and rights	76
6.2	User interface	78
6.3	Menu bar functions	81

6.3.1	File	81
6.3.2	Edit	82
6.3.3	Data transfer	83
6.3.4	Extras	84
6.3.5	View	85
6.3.6	Window	85
6.3.7	Info	86
6.4	Setup file	87
6.4.1	Views and functions	87
6.4.2	Create file info	89
6.4.3	Create configuration	89
6.4.4	Transfer setup file	90
7	Configuration	91
7.1	Selectors	93
7.1.1	Analog selector	93
7.1.2	Digital selector	94
7.2	Basic device (setup only)	97
7.3	Device	98
7.4	Display	100
7.4.1	Start image and watermark (setup only)	100
7.4.2	Screen	101
7.4.3	Colors	102
7.4.4	General Information	103
7.5	Analog inputs	105
7.5.1	Limit value monitoring	109
7.6	Analog outputs	112
7.7	Digital inputs	115
7.7.1	Signal monitoring	115
7.8	Digital inputs/outputs	118
7.8.1	Signal monitoring	118
7.9	Relays	121
7.10	External analog inputs	122
7.10.1	Limit value monitoring	123
7.11	External digital inputs	126
7.11.1	Signal monitoring	127
7.12	External text variables	129
7.13	Limit value monitoring functions	130
7.13.1	Alarm	131
7.14	Counters/integrators	133
7.14.1	General settings	133
7.14.2	Specific settings	135
7.15	Flow	143
7.15.1	Limit value monitoring	145
7.16	Math	148

Contents

7.16.1	Limit value monitoring	151
7.17	Logic	154
7.17.1	Signal monitoring	155
7.18	Groups	158
7.18.1	Parameter	158
7.18.2	Analog channels	159
7.18.3	Digital channels	162
7.18.4	Diagram view	162
7.18.5	Standard operation	164
7.18.6	Event operation	166
7.18.7	Time operation	167
7.18.8	Counters/integrators	168
7.18.9	Event texts	169
7.18.10	Alarm signals	170
7.19	Report	171
7.20	Batches	174
7.20.1	General Information	174
7.20.2	Batch lines	176
7.21	Ethernet	179
7.22	Serial interface	182
7.22.1	Modbus slave	184
7.22.2	Modbus master	185
7.22.3	NMEA 0183	185
7.23	Modbus-TCP	187
7.23.1	Modbus slave	187
7.23.2	Modbus master	188
7.24	Time settings	190
7.25	Time server (SNTP)	191
7.26	Undocumented parameters	192
8	Parameterization	193
8.1	Fine adjustment	193
8.2	Counters/integrators	195
8.3	Limit value monitoring functions	196
8.4	Date and time	197
8.5	Batches	199
8.6	System data	200
9	Configuration – in setup program only	201
9.1	Country settings	201
9.2	User list	204
9.2.1	Default user settings	206
9.2.2	Password rules	206
9.2.3	Character table	207

9.2.4	Public rights	208
9.2.5	User rights	209
9.2.6	Overview of rights	210
9.2.7	Behavior after power on	212
9.2.8	Expertise protection	212
9.3	Text list	213
9.4	Email	214
9.4.1	Email server	215
9.5	Web server	217
9.6	Electronic signature	220
9.7	Modbus frames for reading	222
9.8	Modbus frames for writing	223
9.9	PROFINET	224
9.10	ST code	225
9.11	Customized linearization	228
9.11.1	Formula	230
9.11.2	Grid values	231
9.12	Process screens	233
9.12.1	Process screen editor	233
9.12.2	Background	234
9.12.3	Object types	236
9.12.4	General object features	237
9.12.5	Pictogram	239
9.12.6	Analog signal	240
9.12.7	Digital signal	241
9.12.8	Text	242
9.12.9	Frame	243
9.12.10	Rectangle	244
9.12.11	Bar graph	245
9.12.12	Universal display	246
9.12.13	Float value entry	247
9.12.14	Text entry	248
9.12.15	Digital value entry	249
9.12.16	Text selection from list	251
9.12.17	Text selection by value	252
9.12.18	Preview	253
10	Online parameter (setup only)	255
10.1	Ethernet	255
10.2	Date and time	256
10.3	Screenshot	257
10.4	Delete recording data	258
10.5	Reset user list	258
10.6	Additional process values for online data	259
10.7	Approval of extra codes	260

Contents

10.8	Creation of a device certificate	261
10.9	Calibrate/test	262
10.9.1	Hardware/Software	262
10.9.2	Calibration constants	262
10.9.3	Analog inputs	263
10.9.4	Analog outputs	263
10.9.5	Digital inputs	264
10.9.6	Digital inputs/outputs	264
10.9.7	Touch	265
10.9.8	Display and relay	266
10.9.9	Battery	266
11	Annex	267
11.1	Technical data	267
11.1.1	Analog inputs	267
11.1.2	Digital inputs	270
11.1.3	Analog outputs	270
11.1.4	Digital inputs/outputs	271
11.1.5	Relays	271
11.1.6	Interfaces	272
11.1.7	Screen	273
11.1.8	Electrical data	273
11.1.9	Environmental influences	274
11.1.10	Case	274
11.1.11	Approvals and approval marks	274
11.2	Buffer battery replacement	275
11.3	China RoHS	275
11.4	Barcode	276
11.4.1	Batch control	276
11.4.2	Texts and process values	278

1.1 Safety information

General

This manual contains information that must be observed in the interest of your own safety and to avoid material damage. This information is supported by symbols which are used in this manual as indicated.

Please read this manual before starting up the device. Store this manual in a place that is accessible to all users at all times.

If difficulties occur during startup, please do not intervene in any way that could jeopardize your warranty rights!

Warning symbols



WARNING!

This symbol in connection with the signal word indicates that **personal injury** may occur if the respective precautionary measures are not carried out.



CAUTION!

This symbol in connection with the signal word indicates that **material damage or data loss** will occur if the respective precautionary measures are not taken.



CAUTION!

This symbol indicates that **components could be destroyed** by electrostatic discharge (ESD = Electro Static Discharge) if the respective cautionary measures are not taken.

Only use the ESD packages intended for this purpose to return device inserts, assembly groups, or assembly components.



READ THE DOCUMENTATION!

This symbol, which is attached to the device, indicates that the associated **documentation for the device** must be **observed**. This is necessary to identify the nature of the potential hazard, and to take measures to prevent it.

Note symbols



NOTE!

This symbol refers to **important information** about the product, its handling, or additional benefits.



REFERENCE!

This symbol refers to **additional information** in other sections, chapters, or other manuals.



FURTHER INFORMATION!

This symbol is used in tables and indicates that **further information** is provided after the table.



DISPOSAL!

At the end of its service life, the device and any batteries present do not belong in the trash! Please ensure that they are **disposed of** properly and in an **environmentally friendly** manner.

1 Introduction

1.2 Intended use

The device is designed for use in an industrial environment as specified in the technical data. Other uses beyond those defined are not viewed as intended uses.

The device has been manufactured in compliance with applicable standards and directives as well as the applicable safety regulations. Nevertheless, improper use may lead to personal injury or material damage.

To avoid danger, only use the device:

- For the intended use
- When in good order and condition
- When taking the technical documentation provided into account

Risks resulting from the application may arise, e.g. as the result of missing safety provisions or wrong settings, even when the device is used properly and as intended.

1.3 Qualification of personnel

This document contains the necessary information for the intended use of the device to which it relates.

It is intended for staff with technical qualifications who have been specially trained and have the appropriate knowledge in the field of automation technology.

The appropriate level of knowledge and the technically fault-free implementation of the safety information and warnings contained in the technical documentation provided are prerequisites for risk-free mounting, installation, and startup as well as for ensuring safety when operating the described modules. Only qualified personnel have the required specialist knowledge to correctly interpret and implement the safety information and warnings contained in this document in specific situations.

1.4 Acceptance of goods, storage, and transport

1.4.1 Checking the delivery

- Ensure that the packaging and its contents are undamaged
- Check the delivery for completeness against the packing slip and order details
- Inform the supplier immediately if there is any damage
- Store damaged parts until clarification is received from the supplier

1.4.2 Important information about storage and transport

- Store the device in a dry, clean environment. Observe the admissible ambient conditions (see "Technical data")
- Protect the device from shock during transport
- The original packaging provides optimum protection for storage and transport

1.4.3 Returning goods

If repairs are needed, return the complete device in clean condition.

Use the original packaging to return goods.

Accompanying letter for repair

Please include the completed accompanying letter for repair when returning goods.

Do not forget to state the following:

- Description of the application and
- Description of the error that has occurred

The accompanying letter for repair (supplementary sheet for product returns) can be downloaded online from the manufacturer's website:

<http://productreturn.jumo.info>

Protection against electrostatic discharge (ESD)

(ESD = electrostatic discharge)

To prevent damage due to ESD, electronic modules or components must be handled, packaged, and stored in an ESD-protected environment. Measures that protect against electrostatic discharge and electric fields are described in DIN EN 61340-5-1 and DIN EN 61340-5-2 "Protection of electronic devices from electrostatic phenomena".

When sending back electronic modules or components, please note the following:

- Pack sensitive components only in an environment providing protection against ESD. Workspaces such as this divert electrostatic charges to ground in a controlled manner and prevent static charges due to friction.
- Use only packaging intended specifically for ESD-sensitive modules/components. These must consist of conductive plastics.

No liability can be assumed for damage caused by ESD.



CAUTION!

Electrostatic charges occur in non-ESD-protected environments.

Electrostatic discharges can damage modules or components.

- For transport purposes, use only the ESD packaging provided.

1.4.4 Disposal

Disposing of the device



DISPOSAL!

Devices and/or replaced parts should not be placed in the refuse bin at the end of their service life as they consist of materials that can be recycled by specialist recycling plants.

Dispose of the device and the packaging material in a proper and environmentally friendly manner.

For this purpose, observe the country-specific laws and regulations for waste treatment and disposal.

Disposing of the packaging material

The entire packaging material (cardboard packaging, inserts, plastic film, and plastic bags) is fully recyclable.

1 Introduction

1.5 Identifying the device version

1.5.1 Nameplate

The nameplate is affixed to the housing.

Contents

The nameplate contains important information. This includes:

Description	Designation on the nameplate	Example
Device type	Typ	706521/18-114-25/260
Part no.	TN	00123456
Fabrication number	F-Nr.	0070033801219110006
Voltage supply	-	AC/DC 20 to 30 V, 48 to 63 Hz

Device type (Typ)

Compare the specifications on the nameplate with the order.

Identify the supplied device version using the order details (order code).

Part no. (TN)

The part no. uniquely identifies an article in the catalog. It is important for communication between the customer and the sales department.

Fabrication number (F-Nr.)

The fabrication number indicates, among other things, the date of manufacture (year/week).

Example: F-Nr = 00700338012**1911**0006

The characters in question are digits 12, 13, 14, and 15 (from the left).

The device was therefore produced in the 11th week of 2019.

1.5.2 Order details

(1) Basic type	
706521	Paperless recorder with the following interfaces: 1x Ethernet, 2x USB (1x host, 1x device), 1x RS232/485 interface, as well as a relay (changeover contact)
(2) Basic type extension	
0	Without software package
1	With software package (setup program incl. USB cable, PC Evaluation Software PCA3000, PCA Communication Software PCC; in conjunction with extra code "888" as well with PC Security Manager PCS and PC Audit Trail Manager PCAT software)
(3) Language	
8	Default setting (German/English)
9	Set according to customer specifications
(4) Option 1 (slot 1)^a	
0	Not used
1	Analog/digital: 3 analog and 6 digital inputs, 1 analog output
(5) Option 2 (slot 2)^a	
0	Not used
1	Analog/digital: 3 analog and 6 digital inputs, 1 analog output
(6) Option 3 (slot 3)^a	
0	Not used
4	Digital: 12 digital inputs/outputs (individually switchable)
(7) Voltage supply	
23	AC 110 to 240 V +10/-15 %, 48 to 63 Hz
25	AC/DC 20 to 30 V, 48 to 63 Hz
(8) Extra code 1	
.	Not used
260	Math and logic module (6 channels each)
221	Structured text (ST code)
(9) Extra code 2	
.	Not used
887	Manipulation detection with digital certificate
888	FDA 21 CFR Part 11 with digital certificate
(10) Extra code 3	
.	Not used
163	PROFINET IO device interface (incl. Ethernet)
879	AMS2750/CQI-9 ^b
(11) Extra code, housing	
.	Not used
970	Universal carrying case, compact ^c

^a Subsequent expansion is only possible in JUMO Central Services.

^b For the calibration certificate it is necessary to state the channels along with the thermocouple type and the desired measuring points. The device is to be used as a permanently installed field device. Use as a mobile field test device for SAT and TUS testing is not permitted.

^c The extra code is only available in conjunction with voltage supply AC 110 to 240 V. The UL approval does not apply. Use only for personnel with technical qualifications who have been specially trained, and have the relevant knowledge in the field of automation technology! Specifications for ambient temperature and for protection type are to be observed (see technical data)!

1 Introduction

Order code (1) (2) (3) (4) (5) (6) (7) (8)^a (9) (10)^a (11)
 / - - / , , ,

Order example 706521 / 1 8 - 1 1 4 - 23 / 260 , 887 , 163 , 970

^a Multiple selection at positions 8 and 10 is possible. Specify extra codes one after the other, and separate them with commas.

1.5.3 Scope of delivery

1 paperless recorder in the ordered version
1 quick start guide (brief instructions)
4 mounting elements

1.5.4 Accessories

Description	Part no.
Setup program	00645110
USB cable, A connector to Micro-B connector, length 3 m	00616250
PC Evaluation Software PCA3000	00431882
PCA communication software PCC	00431879
PC software package consisting of: setup program, PC Evaluation Software PCA3000, PCA Communication Software PCC, PC Security Manager PCS, PC Audit Trail Manager PCAT. Please specify all version numbers when placing follow-up orders.	00666817
USB flash drive, 2 GB ^a	00505592
Activation for math and logic module (setup program required)	00716354
Activation for structured text (ST code; setup program required)	00716357
Activation, automatic printout (PCA3000)	00505548
TP-Link TL-WR710N (Wi-Fi router)	00658592
Sealable terminal cover	00712239
Relay (N/O contact) AC 230 V / 3 A for DIN rail	00515872

^a The indicated USB flash drive has been tested and is designed for industrial applications. Other brands with larger storage capacity can also be used, but no liability is assumed for this.

1.6 Content of the technical documentation

The documentation for this device is addressed to plant manufacturers and users with appropriate technical expertise; it consists of the following documents.

1.6.1 Device documentation in printed form

70652100T97...

Quick start guide (brief instructions)

A hard copy of the quick start guide is part of the scope of delivery of the device.

The quick start guide describes the steps to take for mounting and electrical connection, as well as the operation of the device. It also contains the order details and a list of technical data.

The quick start guide is an excerpt from the operating manual.

1.6.2 Device documentation in the form of PDF files

The following documents are available for download from the manufacturer's website. They also form part of the scope of delivery of the optional software package.

70652100T10...

Data sheet

The data sheet contains general information about the device, the order details, and the technical data. It forms the basis for selecting the device and making a purchasing decision.

70652100T90...

Operating manual

The operating manual contains full details on mounting, the electrical connection, operation, parameterization, and the configuration of the device. In addition, it contains the order details and a list of technical data.

In the case of the present device, the operating manual also describes the use of the setup program (PC program) with which the device can also be configured.

70653000T92...

Modbus interface description

The interface description provides information on communication with other devices or superordinate systems using the Modbus protocol (Modbus-RTU, Modbus-TCP).

In the case of the present device, the interface description also contains specifications on communication via Ethernet.

70653007T92...

PROFINET interface description

This document explains the use of the PROFINET interface, which can be used to integrate the device into a PROFINET network as an IO device. A GSD file (GSDML) is available for the programming system of the IO controller and describes the features of the device.

70653000T96...

ST editor manual

This document describes the application of the ST editor with which users can create their own applications in the PLC programming language "structured text" (ST) for the device. The document is intended for users with relevant programming knowledge.

The ST editor is a component of the setup program.

1 Introduction

70652100T97...

Quick start guide (brief instructions)

The quick start guide is also available as a PDF file and has the same scope as the printed document.

1.6.3 Documentation for optional software

The following manuals in the form of PDF files are available for download from the manufacturer's website. They also form part of the scope of delivery of the respective software.

B 709701.0 or 70970100T90...

PC evaluation software PCA3000

The operating manual describes the operating principle and the features of the PC evaluation software. The PC evaluation software helps to visualize and evaluate the captured recording data (measurement data, batch data, messages, etc.).

B 709702.0 or 70970200T90...

PCA communication software PCC

The operating manual describes the operating principle and the features of the PCA communication software. The PCA communication software is responsible for the data transfer from a device or system to a PC or to a network.

B 709703.0 or 70970300T90...

PC Security Manager software PCS

The operating manual describes the operating principle and the features of the PC Security Manager software. PCS ensures that only authorized persons can gain access to the system components (device, PC software) and sign electronic signatures in electronic documents. Only system administrators are able to configure the Security Manager.

PCS is only available for devices with extra code 888.

B 709704.0 or 70970400T90...

PC Audit Trail Manager software PCAT

The operating manual describes the operating principle and the features of the PC Audit Trail Manager software. PCAT documents actions performed in the PC software components which lead to modifications of files, user lists (rights files), device lists, etc. The different message types are: "Information", "Warnings", and "Errors". Audit trail recordings cannot be modified.

Device audit trail data is not shown in PCAT, only in PCA3000.

PCAT is only available for devices with extra code 888.

1.7 Device version

The device version of the paperless recorder can be determined through the software version (SW version) of the device. The software version is displayed in the "Device info" menu (Main menu > Device info > Versions > Basic device: SW version).

Structure of the software version number (SW version): 323.xx.yy

323 = basic version, xx = device version, yy = current version


2.1 Brief description

The JUMO LOGOSCREEN 601 paperless recorder is characterized by an intuitive, icon-based operation and visualization concept that makes it easy to operate.

Different versions of the JUMO LOGOSCREEN 601 are available for process data recording. The scalability allows for flexible adaptation to various customer requirements: from the device version without measurement input (24 process values via interface) through to different device versions with up to 6 measurement inputs (universal analog inputs), 2 analog outputs, 12 digital inputs, 12 individually switchable digital inputs/outputs. A relay output is available as standard. The version with FDA-compliant data recording fulfills all requirements according to 21 CFR Part 11.


In order to display the recorded data, the JUMO LOGOSCREEN 601 features various visualizations. In addition, the user can use the setup program to create up to 6 separate process screens – with up to 100 objects per process screen – according to his individual requirements. For batch-based processes, a special batch recording is available which enables the storage of additional, batch-related information. The extra code "structured text" allows for the creation of individual measurement and recording applications.

2.2 Block diagram



2 Description

2.3 Display and control elements



- (1) Touchscreen (TFT color screen)

Technical data:

⇒ chapter 11.1.7 "Screen", Page 273

The screen appearance is described in the "Operation" chapter:

⇒ chapter 5.1.1 "Touchscreen", Page 37

- (2) Alarm LED

The LED is lit while an alarm is present.

- (3) Power LED

The LED flashes after switching on the device until the startup process is completed. It is then permanently lit.

- (4) USB host interface with cover

To remove the cover, take hold of the lug and pull it out.



CAUTION!

Protection type IP66 (front-side) only with closed USB host interface.

Protection type IP66 is only guaranteed with the available default cover of the USB host interface.

- Only remove the cover to use the interface; then remount the cover immediately (the cover must be flush with the front of the device).

2.4 Connection elements

The connecting elements on the rear of the device and the front-side USB host interface are described in the "Electrical connection" chapter.

⇒ chapter 4.3 "Connection elements", Page 27

3.1 General information on mounting



WARNING!

The device is not designed for use in potentially explosive areas.

Explosion hazard.

- Only deploy the device outside of potentially explosive areas.
-

Mounting site

The device is designed for installation in a panel cut-out. The front of the device and housing have different protection types (see technical data).

Climatic conditions

The ambient temperature and the relative humidity at the mounting site must correspond to the technical data. Aggressive gases and vapors have a negative effect on the operating life of the device. The mounting site must be free from dust, powder, and other suspended solids.

Installation position

Any installation position may be chosen, however the screen view angle must be taken into consideration (see technical data).


Technical data

- ⇒ chapter 11.1 "Technical data", Page 267


3 Mounting

3.2 Dimensions

Device




Panel cut-out




Close mounting

Distance between panel cut-outs	Horizontal	Vertical
Minimum clearance	20 mm	20 mm
Recommended distance (easier mounting of mounting elements)	50 mm	50 mm

Device with terminal cover (accessories)



3.3 Panel mounting



Step	Action
1	Insert the device into the panel cut-out from the front until the seal is flush with the panel.
2	Insert the mounting elements into the recesses of the housing (one element on each corner, see figure) and use a screwdriver to evenly clamp them against the rear side of the panel with a torque of 1.0 Nm.



CAUTION!

The front of the device and housing have different protection types!

The protection type IP66 (front-side) is only guaranteed if the seal is flush and even.

- The four supplied mounting elements must all be used and must be distributed evenly as shown in the figure.

3.4 Handling the front of the device

Cleaning

The front of the device (front foil) can be cleaned with standard detergents, rinsing and cleaning agents.



CAUTION!

The front of the device is not resistant to aggressive acids and lyes, scouring agents, and cleaning with a pressure cleaner.

Use of these media can cause damage.

- Only clean the front of the device with suitable agents.

Operation

The screen (resistive touchscreen) can be operated by finger pressure or with a commercially available touchscreen stylus.

3 Mounting




CAUTION!

Sharp or hard objects are not suitable for operating the screen.

They can cause scratches and damage the front foil.

- Only operate the screen with your finger or with a suitable stylus.

3.5 Terminal cover (accessories)




Step	Action
1	Screw the spacer bolt (A) into the rear wall of the device.
2	Attach the terminal cover (B) to the rear wall of the device.
3	Screw the capstan screw (D) with locking washer (C) through the lug of the terminal cover and into the spacer bolt.
4	If necessary attach the seal (not shown here).




NOTE!

Observe the specifications on the maximum admissible conductor cross section when using the terminal cover (see chapter 11.1.8 "Electrical data", Page 273).

3.6 Universal carrying case, compact (extra code 970)



Dimensions



Intended use

The paperless recorder in the carrying case is intended only for use by personnel with technical qualifications who have been specially trained, and have the relevant knowledge in the field of automation technology.

Cleaning

The specifications for cleaning the carrying case are the same as those for cleaning the front of the device.

⇒ chapter 3.4 "Handling the front of the device", Page 21

Device fuse

The carrying case is equipped with a replaceable device fuse (micro fuse 5.0 A / 250 V delayed-action, according to DIN EN 60127-2; part no. 65018001). Any faulty fuses must be replaced with the same type of fuse. Disconnect all poles of the carrying case from the mains voltage beforehand (remove the mains plug)!

Mains cable

The removable mains cable (H05VV-F 3G1; 2.5 m long; part no. 00052953) must not be replaced with an insufficiently dimensioned cable.

Differing technical data

Observe the specifications regarding the ambient temperature and protection type of the housing!

⇒ chapter 11.1.9 "Environmental influences", Page 274

3 Mounting

⇒ chapter 11.1.10 "Case", Page 274

4.1 Installation notes

Requirements for personnel

- Work on the device must only be carried out to the extent described and, like the electrical connection, only by qualified personnel.
- Before plugging and unplugging connecting cables, it must be ensured that the acting person is electrostatically discharged (by touching grounded metallic parts, for example).

Cables, shielding, and grounding

- When selecting the electrical wiring material as well as when installing and connecting the device electrically, comply with the requirements of DIN VDE 0100 "Low-voltage electrical installations" and the applicable country-specific regulations (for example, based on IEC 60364).
- Route input, output, and supply lines separately and not parallel to one another.
- Only use shielded and twisted probe and interface cables. Do not route the lines close to current-carrying components or cables.
- For temperature probes, ground the shielding on one side in the control cabinet.
- Do not perform loophroughs on the grounding cables, but instead route the cables individually to a shared grounding point in the control cabinet; in doing so, ensure that the cables are as short as possible.

Ensure that the potential equalization is correct.

Electrical safety

- The device is intended to be installed in control cabinets or plants. Ensure that the customer's fuse protection does not exceed 20 A. Disconnect the device from the mains voltage on all poles prior to starting service or repair work.
- The relay's load circuit can be operated with a hazardous electrical voltage (e.g. 230 V). De-energize the load circuit during mounting/dismounting and electrical connection.
- To prevent the relay contacts being destroyed in the case of an external short-circuit in the load circuit, the latter must be fuse-protected as per the maximum admissible relay current (see technical data).
- The device is not suitable for installation in potentially explosive areas.
- In addition to a faulty installation, incorrectly set values on the device can also impair the correct function of the downstream process. Therefore, ensure that safety devices independent of the device, e.g., overpressure valves or temperature limiters/monitors, are present and that it is only possible for qualified personnel to define settings. Please observe the corresponding safety regulations in this context.

References to other information


- The electromagnetic compatibility conforms to the standards and regulations cited in the technical data.
- In general, please observe the specifications regarding galvanic isolation.

Technical data

- ⇒ chapter 11.1 "Technical data", Page 267

4 Electrical connection

4.2 Galvanic isolation




- (1) The voltage specifications correspond to the test voltages (alternating voltage, rms values) according to EN 61010-1:2011-07 for the type test.
- (2) Functional galvanic isolation for connection of SELV or PELV electrical circuits.


4 Electrical connection

4.3 Connection elements

Front USB host interface (without cover)



Back connection elements



Connection element and assignment

1.	USB device interface
2.1	Ethernet interface (as a standard feature) or
2.1, 2.2	PROFINET interface (including Ethernet; extra code): 2.1 = port 2, 2.2 = port 1
3.	RS232/RS485 interface

Connection element and assignment

4.	Relay 1 (changeover contact)
5.	Voltage supply
6. - 15.	Option inputs and outputs (Slot 1 to Slot 3)

4 Electrical connection



NOTE!

The front-side USB host interface is intended only for connecting a USB flash drive. Any other use is not admissible.



NOTE!

The quality of the USB cable and the USB flash drive affects whether or not the device functions correctly. It is recommended to use the components (accessories) supplied by the manufacturer.



CAUTION!

The device is not suitable for connection to a PoE port (power over Ethernet).

There is the risk of damage to the device.

- Connect the device to an Ethernet port without PoE.
-



NOTE!

Observe the specifications on the maximum admissible conductor cross section when using the terminal cover (accessories) (see chapter 11.1.8 "Electrical data", Page 273).



CAUTION!

In unfavorable conditions, the temperature may exceed 60 °C at the terminals.







As a result, the insulation of the cables connected at the terminals may be damaged.


- The affected cables must be heat-resistant up to at least 75 °C.
-

4 Electrical connection

4.4 Connection diagram

4.4.1 Analog inputs




Measuring probe	Terminals and connection symbol	Connection element.terminal / assignment
Thermocouple		Analog/digital option (order code 1): 7.1-5 / Analog input 1 8.1-5 / Analog input 2 9.1-5 / Analog input 3
RTD temperature probe Two-wire circuit		11.1-5 / Analog input 4 12.1-5 / Analog input 5 13.1-5 / Analog input 6
RTD temperature probe Three-wire circuit		
RTD temperature probe Four-wire circuit		
Resistance transmitter		
Resistance/potentiometer Two-wire circuit		



4 Electrical connection


Measuring probe	Terminals and connection symbol	Connection element.terminal / assignment
Resistance/potentiometer Three-wire circuit		
Resistance/potentiometer Four-wire circuit		
Voltage DC -10(0) to +10 V		
Voltage DC -1(0) to +1 V		
Voltage DC 0 to 70 mV		
Current DC 0(4) to 20 mA		

4.4.2 Digital inputs




Version	Terminals and connection symbol	Connection element.terminal / assignment
Digital input DC 0/24 V, auxiliary voltage supply DC 24 V	 Example: potential-free contact on digital input 1 and +24 V (auxiliary voltage)  Example: external voltage on digital input 1 and GND	Analog/digital option (order code 1):: 6.1 / Digital input 1 6.2 / Digital input 2 6.3 / Digital input 3 6.4 / Digital input 4 6.5 / Digital input 5 6.6 / Digital input 6 6.7 / +24 V 6.8 / GND 10.1 / Digital input 7 10.2 / Digital input 8 10.3 / Digital input 9 10.4 / Digital input 10 10.5 / Digital input 11 10.6 / Digital input 12 10.7 / +24 V 10.8 / GND 


4 Electrical connection

4.4.3 Analog outputs

Version	Terminals and connection symbol	Connection element.terminal / assignment
Analog output DC 0 to 10 V or DC 0(4) to 20 mA (configurable)	12345678910 ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ U_x , I_x + -	Analog/digital option (order code 1): 6.9 / Analog output 1 + 6.10 / Analog output 1 - 10.9 / Analog output 2 + 10.10 / Analog output 2 - 


4.4.4 Digital inputs/outputs

Version	Terminals and connection symbol	Connection element.terminal / assignment
Digital input DC 0/24 V or digital output DC 0/24 V (individually switchable), auxiliary voltage supply DC 24 V Note regarding the digital option: Auxiliary voltage supply and digital outputs together deliver max. 100 mA (at 24 V).	 Example: potential-free contact on digital input/output 1 (as input) and +24 V (auxiliary voltage)  Example: external voltage on digital input/output 1 (as input) and GND  Example: external relay on digital input/output 1 (as output) and GND (max. 40 mA per output, max. 100 mA in total, see note in the "Version" column)	Digital option (order code 4): 14.1 / Digital input/output 1 14.2 / Digital input/output 2 14.3 / Digital input/output 3 14.4 / Digital input/output 4 14.5 / Digital input/output 5 14.6 / Digital input/output 6 14.7 / +24 V 14.8 / GND 15.1 / Digital input/output 7 15.2 / Digital input/output 8 15.3 / Digital input/output 9 15.4 / Digital input/output 10 15.5 / Digital input/output 11 15.6 / Digital input/output 12 15.7 / +24 V 15.8 / GND




4 Electrical connection

4.4.5 Relays

Version	Terminals and connection symbol	Connection element.terminal / assignment
Relay (changeover contact) (max. 3 A at AC 230 V, resistive load)		Relay 1: 4.1 / Normally open contact (NO) 4.2 / Common contact (C) 4.3 / Normally closed contact (NC)

4 Electrical connection

4.4.6 RS232/RS485 interface


Version	Connection element.pin / assignment	Connection element
RS232 9-pin SUB-D socket (switchable to RS485)	3.2 / RxD (received data) 3.3 / TxD (transmission data) 3.5 / GND (ground)	
RS485 9-pin SUB-D socket (switchable to RS232)	3.3 / TxD+/RxD+ (transmission/received data +) 3.5 / GND (ground) 3.8 / TxD-/RxD- (transmission/received data -)	




NOTE!

To connect a GPS receiver (RS422, transmission data only), use the RS485 interface (the paperless recorder is in receive mode). Pin assignment: 3 = TxD+, 8 = TxD-, 5 = GND.

4.4.7 Ethernet/PROFINET

Version	Connection element.pin / assignment	Connection element
Ethernet 1 x RJ45 (as a standard feature)	2.1.1 / TX+ (transmission data +) 2.1.2 / TX- (transmission data -) 2.1.3 / RX+ (received data +) 2.1.6 / RX- (received data -)	
PROFINET IO device (incl. Ethernet) 2 x RJ45, integrated switch (as extra code)	Port 2: 2.1.1 / TX+ (transmission data +) 2.1.2 / TX- (transmission data -) 2.1.3 / RX+ (received data +) 2.1.6 / RX- (received data -) Port 1: 2.2.1 / TX+ (transmission data +) 2.2.2 / TX- (transmission data -) 2.2.3 / RX+ (received data +) 2.2.6 / RX- (received data -)	

4.4.8 Voltage supply

Version	Connection element.terminal / assignment	Terminals and connection symbol
AC 110 to 240 V +10/-15 %, 48 to 63 Hz or AC/DC 20 to 30 V, 48 to 63 Hz Observe order details!	5.L1 / Line conductor (for DC: positive terminal L+) 5.N / Neutral conductor (for DC: negative terminal L-) 5.PE / Protection conductor	

4 Electrical connection

5.1 Operating concept

The device is equipped with a resistive touchscreen; the operation is menu-driven. User management protects the device against unauthorized access. The different users can be assigned different privileges so that they can only access specific functions.

In addition to the visualizations available per default, the setup program can be used to create individual process screens for presenting process data.


Thanks to the integrated web server, certain visualizations can also be rendered in a web browser.

5.1.1 Touchscreen

The visualization screen shown after switching on the device depends on the configuration (device: Main menu > Configuration > Display > Generally > Image after reset; also see the "Configuration" chapter in the operating manual).

The example shown here is the curve diagram (vertical, with digital traces).

View



- | | |
|--|--|
| (1) Status bar | (2) Screen (here: curve diagram with digital traces) |
| (3) Channel information (display depends on the configuration) | (4) Navigation bar |

Status bar



The status bar consists of three areas which are delimited by vertical lines. Each area is an active button which can be used to display (☒) and hide (☐) further information.

The **area on the left** shows you the diagram type and group number. Tapping the button displays the alarm list.

The **area in the center** is used to display the status of the recording operating mode and communication types based on icons. The button displays details of the group operating mode (depending on the screen), the batch recording status, and the status of the data transfer via the PCC software as a text display.

Icons used:

5 Operation

Position	Meaning	Symbol
Left	Data transfer via PCC software	
	- Transfer active	
	- Transfer not active	No icon
Center	Batch recording	
	- Recording active	
	- Recording not active (or batch not configured)	No icon
Right	Operating mode	
	- Standard operation	
	- Event operation	
	- Time operation	

The **area on the right** shows the logon status as an icon and the time. The button additionally shows the weekday, date, user name, and memory usage.

Icons used:

Position	Meaning	Symbol
Left	Logon status	
	- User not logged on	
	- User logged on	

The status bar is also used as an **alarm display**. In the event of an alarm, the alarm text (red background) and the normal text (blue background) are alternately displayed.

Screen

The screen area displays the current visualization, a menu (e.g., main menu) with its menu items, or a list (e.g., event list).

Channel information

 R1	AI01 18.218 °C	 R2	AI02 101.33 °C	 R3	AI03 257.95 °C
--	-------------------	--	-------------------	--	-------------------

The channel information display in the curve diagram can be switched on and off (configuration). The designation (pointer) of the analog signal (e.g., A1) is displayed along with the abbreviation of the analog signal (e.g., AI01 for analog input 1) and the analog value.

Instead of the abbreviation, the designation (description) can also be displayed (configuration).

Navigation bar



The navigation bar consists of three areas which are delimited by vertical lines.

The **area on the left** contains the buttons (icons) for calling up

- the main menu (left),
- the alarm and event menu (center), and
- the visualization menu (right).

The **area in the center** contains buttons (icons) whose function depends on the screen currently being displayed.

The **area on the right** contains buttons (icons) for screen navigation:
The "Home" button takes the user directly to a specific screen (configurable).
Pressing the "Next" button (right arrow) selects the next screen on a specific level (e.g., toggle to the next active group).

5.1.2 LED displays

The device is equipped with two LEDs on its front side that display the device status.

Green LED

The green LED (power LED) flashes after switching on the device until the startup process is completed. It is then permanently lit.

Red LED

The red LED (alarm LED) is permanently lit while an alarm is present.
Acknowledging the collective alarm in the alarm list does not reset the alarm display.


5 Operation

5.2 Main menu



The main menu contains functions for configuring, parameterizing, and operating the device.

View



- (1) Menu items
- (2) Quit main menu

- (3) Scroll up
- (4) Scroll box (current position within the menu); movable
- (5) Scroll down

5.2.1 Logon



This is the menu in which users log on and off, and change their passwords.

The following IDs, names, and passwords are set by default:

Users	ID	Name	Password
User 1	Master	System Master	9200
User 2	User 1	Data Management	1
User 3	User 2	Data Management	2
User 4	User 3	Data Management	3
User 5	Service	Service	9200

Further information: see the operating manual, chapter "Configuration - only in setup program" > "User list" > "Default user settings".

Logoff with signature

With extra code 888 (FDA) and with the corresponding configuration in the PCS software, an electronic signature is required when logging off. The signature applies to the entire time period for which the user was logged on.

Configuration of the electronic signature: see operating manual, chapter "Configuration - only in setup program" > "Electronic signature".

Example of an electronic signature:

⇒ chapter 5.8 "Electronic signature", Page 69

5.2.2 Configuration



This menu contains functions for configuring the device. The functions are available both on the device and in the setup program (see the "Configuration" chapter in the operating manual).

In addition to this, there are functions that can only be configured with the setup program (see the operating manual, chapter "Configuration - only in setup program" and "Online parameters").



CAUTION!

Changing the configuration closes the current capturing of recording data and means the new data is recorded such that it is chronologically separated from the old data (new configuration = new archive section). As a basic principle, the device only stores the recording data that has been captured during the last 20 configurations. However, irrespective of this, the oldest data is automatically overwritten with new data when the internal memory is full (ring buffer principle).

The data before and after the reconfiguration cannot be displayed as a whole in PCA3000. Data which is older than the last 20 configurations can no longer be extracted from the device.

- Before making any changes to the configuration, always create a backup of the data. It is also necessary to select suitable retrieval cycles for the data to prevent data loss. The setup program (configuration of the groups) provides a guideline value for the maximum data capture time.

5.2.3 Parameterization



This menu contains the functions for parameterizing the device (see the "Parameterization" chapter in the operating manual).

5.2.4 Device information



This menu contains information about the device (name, versions), the current process values (inputs, outputs, internal functions), the Ethernet interface, and the PROFINET interface (optional extra).

The device version is indicated through the "Version" parameter in the submenu "Versions" > "Basic device":

Standard = device in standard version

21 CFR Part 11 = device in FDA compliant version

With extra code 887 (digital certificate) or 888 (FDA) information about the digital certificate is also displayed in this menu.

5.2.5 Audit trail list



This menu lists the audit trail messages generated by the device.

All user intervention with the device is automatically recorded and stored in the audit trail list of the device. The audit trail list is managed independently of the event list.

The audit trail list is designed as a ring buffer which can contain a maximum of 150 entries. When the list is full, each new entry causes the oldest entry to be deleted from the list.

5 Operation

5.2.6 Service



This menu contains various service functions.

Default configuration

You can store the current device configuration with this function.
Similarly, a previously stored configuration can be loaded as the current configuration.

5.2.7 Calibrating the touchscreen




This menu enables you to calibrate the touchscreen (position calibration). To do so, you need to tap the center of the crosshairs shown in the corners of the screen one after another.

5.3 Alarm and event menu



The alarm and event menu enables you to call up the alarm list and event list.

View



- (1) Menu items
- (2) Quit the alarm and event menu

Alarm and event lists of the batches

A separate alarm list and event list exists for each active batch (in addition to the overall list). These separate lists contain batch-related entries based on the group assignment (events and alarms of the channels and counters/integrators).

5.3.1 Alarm list




The alarm list shows all alarms that are present in their order of occurrence. If an alarm is no longer present, its entry is automatically removed from the alarm list. The alarm list is rebuilt after power on.

Each alarm represents an event. For this reason, the time at which an alarm occurs and disappears again is recorded in the event list.

An alarm that is present is additionally shown in the status bar and by the red LED.

View



Collective alarm

The following collective signals are created and are available in the digital selector:

- **Collective alarm**
The signal is active while an alarm is present (the alarm list is not empty).
- **Collective alarm acknowledged**
This signal is activated when an alarm occurs; it remains active until acknowledged even if the alarm disappears in the meantime.

5 Operation

5.3.2 Event list



The event list contains event entries in chronological order. A maximum of 150 entries are stored and displayed. When new entries are added, the oldest entries are deleted. The event list is kept after power off.

As with process data, events are transferred to the PC Evaluation Software PCA3000 for evaluation.

The events include:

- System messages (e.g., power on, configuration change, time sync)
- Device alarms (malfunctions; e.g., battery discharged, data loss, input not calibrated)
- Configured alarms
- Configured events
- Counter messages (counter status and counter reset)
- Batch messages (start and end of batch recording)
- General messages (e.g., comments, error messages from the interfaces, USB flash drive plugged in/removed, collective alarm acknowledged)
- GPS data

View

Event list10:39:55

(1)

08/24/2015 10:38:13 Upper tol. alarm Grp. 1 Chan. 2 on

08/24/2015 10:38:12 New configuration

(2)

(3)


(1) Event (here: alarm) with time and event text (configurable)

(2) Quit event list

(3) Update event list

Event list in memory view

If the alarm and event menu is called up from the memory view (history) (or from the curve presentation of a completed batch), the event list is opened directly. An additional button is available here which lets you mark the time of a specific event in the memory view with the cursor position.



- (1) Selected event
The event is selected by tapping.

- (2) Call up memory view
In the memory view, the cursor is moved to the position (time) at which the event occurred.
If the respective point in time is no longer in the history, the cursor is moved to the start of the memory view (oldest point in time).

5 Operation

5.4 Visualization menu (display)



View

In the visualization menu, the display type and group that should currently be displayed on the device are selected. Up to 6 analog channels and 6 digital channels of a group can be shown on one screen.

Display

(1) Curve diagram

Digital diagram

Bargraph

2.15 Text image

Actual batch

Completed batch

(2)

10:49:23

(3)

(4)

(5)

(1) Menu items

(2) Quit visualization menu

(3) Scroll up

(4) Scroll box (current position within the menu); movable

(5) Scroll down


5.4.1 Curve diagram



In the curve diagram, the analog and digital signals configured for the relevant group are displayed as analog curves or digital traces. Digital traces and channel information can be hidden in the group configuration.

The diagram type (horizontal, vertical) is selected individually for each group in the configuration. The following view shows the vertical diagram. Accordingly, the description also applies to the horizontal diagram (see the example later on).

Group view



- | | |
|--|---|
| (1) Designation (pointer) of the analog curve | (4) Designation (pointer) of the digital trace |
| (2) Analog curve (color change in the event of an alarm) | (5) Digital trace |
| (3) Auxiliary line (configurable) | (6) Event off |
| (4) Channel information: designation (pointer), signal abbreviation (configurable), and current value of analog signal (color change in the event of an alarm) | (7) Alarm off |
| Touch the button to display the channel individually (incl. scaling and limit values). | (8) Event on |
| | (9) Power on, alarm on |
| | (10) Signal description (instead of abbreviation) |
| | (11) Navigation bar |


Navigation bar



- | | |
|-----------------------------------|-----------------------------------|
| (1) Hide/show digital traces | (4) Call up memory view (history) |
| (2) Hide/show channel information | (5) Go to next active group |
| (3) Hide/show analog values | |

5 Operation

Memory view (history)



- | | |
|---|---|
| (1) Move time for memory values forward (later memory values) | (5) Time of memory values (cursor position) |
| (2) Cursor (time of numeric memory values) | (6) Zoom factor |
| (3) Move time for memory values back (earlier memory values) | (7) Navigation bar |
| (4) Analog value at selected time | |

Navigation bar



- | | |
|---------------------------|---|
| (1) Quit memory view | (4) Change zoom factor |
| (2) Access event list | (5) Find memory values (enter time) |
| (3) Hide/show cursor keys | (6) Curve selection (activate/deactivate view) |
| | (7) Render electronic signature or display information about rendered signature |

Electronic signature

With extra code 888 (FDA) and with the corresponding configuration in the PCS software, a certain time period can be provided with an electronic signature. The signature applies to the time period that is displayed in the diagram at the time of the signature. The displayed period may have to be expanded prior to signing. During signing the time period can only be reduced; it can then no longer be expanded.

Any user who has the corresponding authorization can sign the signature ("Confirm batches, electronic signature" right). This can be a different user to the one who is currently logged on.

Configuration of the electronic signature: see operating manual, chapter "Configuration - only in setup program" > "Electronic signature".


Example of an electronic signature:

⇒ chapter 5.8 "Electronic signature", Page 69

Horizontal diagram

In the horizontal diagram, the analog curves and digital traces run from right to left. The channel information is shown on the right edge of the screen; the icons for event and alarm at the top edge of the screen.

Digital traces and channel information can be hidden in the group configuration, as in the vertical view.




5 Operation

5.4.2 Digital diagram



In the digital diagram, the digital signals configured for the relevant group are displayed as digital traces. The diagram type (horizontal, vertical) is selected individually for each group in the configuration. The following view shows the vertical diagram. Accordingly, the description also applies to the horizontal diagram.

Group view



- (1) Designation (pointer) of the digital trace
Displays the logical state:
Colored area = HIGH (B1, B3)
Colored frame = LOW (B2)

- (2) Digital trace

- (3) Signal designation of digital signal (configurable)

- (4) Navigation bar

Navigation bar



- (1) Call up memory view (history)

- (2) Go to next active group

Memory view

See memory view in the curve diagram.

⇒ chapter 5.4.1 "Curve diagram", Page 47


5.4.3 Bar graph



In the bar graph view, the analog signals configured for the relevant group are shown as bar graphs, and the digital signals – depending on their logical state – as colored areas or frames.

The diagram type selected for the group (horizontal, vertical) is irrelevant for the bar graph view. The view is always as a column diagram (vertical) and not as a bar diagram (horizontal).

Group view



- | | |
|---|--|
| <p>(1) Signal abbreviation (configurable) of analog signal
Call up individual view of analog signal (numerical view and bar graph); see text image - individual view.</p> <p>(2) Bar graph of the analog signal (color change in the event of an alarm)</p> <p>(3) Digital signal with signal abbreviation (configurable) and designation (pointer)
Displays the logical state:
Colored area = HIGH (B1, B3)
Colored frame = LOW (B2)</p> | <p>(4) Current analog value (color change in the event of an alarm)</p> <p>(5) End value of scaling (display range, configurable)</p> <p>(6) Limit value for max. alarm (configurable)</p> <p>(7) Limit value for min. alarm (configurable)</p> <p>(8) Start value of scaling (display range, configurable)</p> <p>(9) Go to next active group</p> |
|---|--|


5 Operation

5.4.4 Text image




The text image shows the current values for the analog signals configured for the relevant group as numbers. The digital signals – depending on their logical state – are shown as colored areas or frames.

Group view



- | | |
|---|---|
| (1) Designation (pointer) and signal abbreviation (configurable) of the analog signal | (4) Digital signal with signal abbreviation (configurable) and designation (pointer)
Displays the logical state:
Colored area = HIGH (B1, B3)
Colored frame = LOW (B2) |
| (2) Current value of analog signal | |
| (3) Call up individual view of analog signal (numerical view and bar graph)
In the individual view, all digital signals of the group are also displayed. | (5) Go to next active group |


Individual view



- | | | | |
|-----|---|-----|---|
| (1) | Designation (pointer), signal abbreviation (configurable), and signal designation (configurable) of the analog signal | (4) | Bar graph (column diagram) of the analog signal |
| (2) | Current value of analog signal | (5) | Digital signal with signal abbreviation (configurable) and designation (pointer) |
| (3) | Back to group view | | Displays the logical state:
Colored area = HIGH (B1, B3)
Colored frame = LOW (B2) |

5 Operation

Individual view with alarms



- | | |
|--|---|
| (1) Last alarm to have occurred (here: from analog input 03) | (4) Limit value for max. alarm (configurable) |
| (2) Current value of analog signal with color change (alarm) | (5) Bar graph (column diagram) of analog signal with color change (alarm) |
| (3) Alarm text of analog input | (6) Limit value for min. alarm (configurable) |

5.4.5 Report



A report shows the statistical information for the relevant group. A report contains the maximum, minimum, and average values of the analog signals during the recording time (the recording period is configurable). A distinction is made between the current (ongoing) report and the completed report.

To create a report, it must be activated in the configuration for the relevant group.

View

Report - Group 01

	Maximum value °C	Minimum value °C	Average value °C
AI01			
External	297.25	53.689	175.49

Navigation icons: Menu, Alarm, Data, Next

- | | | | |
|-----|--|-----|---|
| (1) | Designation (pointer) and signal abbreviation (configurable) of the analog signal | (4) | Go to the next analog signal within the group |
| (2) | Values of analog signal in the current (not completed) report | (5) | Go to the report for the next group |
| | <p>The type (configurable; here: external) decides when the report is stored and thus completed.</p> | | |
| (3) | Call up detailed view of analog signal | | |

5 Operation

Detailed view

Report - Group 01			13:38:33
External	Current	Completed	(4)
(1) AI01	°C	°C	(5)
Maximum value	200.76	292.60	
(2) Time	08/24/2015 13:38:22	08/24/2015 13:37:51	
Minimum value	84.126	80.773	
Time	08/24/2015 13:38:18	08/24/2015 13:37:40	
Average value	114.45	174.49	
(3) Timestamp start	08/24/2015 13:38:13	08/24/2015 13:37:23	
Timestamp end	08/24/2015 13:38:34	08/24/2015 13:38:10	
			(6)

(1) Designation (pointer) and signal abbreviation (configurable) of analog signal; report type (configurable; here: external)

(2) Time at which the max. value (or min. value) occurred

(3) Time stamp for current report: beginning of recording and current time

Time stamp for completed report: beginning and end of reporting period

(4) Completed report

(5) Current (ongoing) report

(6) Back to previous view

5.4.6 Current batch



This function opens the report for the current batch recording. Batch recording can be started and stopped (depending on the configuration).

The report layout is defined in the batch configuration. This is where the individual lines of the report are defined, and the text for the left column, and content of the right column, are specified (device: main menu > Configuration > Batch > Batch line x; see also the "Configuration" chapter in the operating manual).

View

Actual batch - Batch 1

Program name	Text 1
Customer info	Text 3
Batch name	Text 5
Batch number	000000020Text 7
Batch start	08/24/2015 13:43:08
Batch end	08/24/2015 13:43:32
Batch duration	00:25

- (1) Left column

(2) Right column
- (3) Editable text (depending on the configuration)

(4) Batch number and non-editable text (depending on the configuration)

(5) Stop/start batch recording (only for configured "Batch start via touchscreen")

5 Operation

5.4.7 Completed batch



This function displays the report for the completed batch recording. Recorded data can be shown as a report and as a curve diagram.

If necessary, the report can also display the data from current batch recording.

View

Completed batch - Batch 1		09:48:55
Program name	Text 1	
Customer info	Text 3	
Batch name	Text 5	
Batch number	000000012Text 7	
Batch start	07/27/2016 09:48:15	
Batch end	07/27/2016 09:48:23	
Batch duration	00:09	

(1)

(2)

(3)

(1) Open report (statistical information for the completed batch recording, and, if necessary, the current batch recording)

(2) Open curve presentation (analog curves and digital traces of the completed batch recording)

(3) Render electronic signature or display information about rendered signature

Electronic signature

With extra code 888 (FDA) and with the corresponding configuration in the PCS software, the completed batch can be provided with an electronic signature. The signature can only be provided once per completed batch; it cannot be revoked. If a signature was provided already then this state is displayed through the following symbol (3):

Any user who has the corresponding authorization can sign the signature ("Confirm batches, electronic signature" right). This can be a different user to the one who is currently logged on.

Configuration of the electronic signature: see operating manual, chapter "Configuration - only in setup program" > "Electronic signature".

Example of an electronic signature:

⇒ chapter 5.8 "Electronic signature", Page 69

Report for batch

Report - Group 01

(1)

Batch

R1

AI01

Current

°C

Completed

°C

Maximum value

200.99

200.92

Time

08/24/2015 | 13:46:54

08/24/2015 | 13:44:46

Minimum value

200.93

200.76

Time

08/24/2015 | 13:46:46

08/24/2015 | 13:43:07

Average value

200.98

200.85

Timestamp start

08/24/2015 | 13:46:44

08/24/2015 | 13:43:07

Timestamp end

08/24/2015 | 13:47:12

08/24/2015 | 13:44:48

(2)

(3)


(6)

- (1) Designation (pointer) and signal abbreviation (configurable) of the analog signal
- (2) Go to the next analog signal within the group
- (3) Back to the batch report view

- (4) Data (statistical information) for the completed batch recording
- (5) Data (statistical information) for the current (ongoing) batch recording
- (6) Go to next group

⇒ chapter 5.4.5 "Report", Page 55

Curve presentation for the batch



The functions are identical to those of the memory view in the "Curve diagram" visualization.

⇒ chapter 5.4.1 "Curve diagram", Page 47

When opening the curve presentation, the zoom factor is computed so as to display the data of the entire batch recording on the screen.

5 Operation

5.4.8 Process screen



This visualization shows the individual process screens. You can use the arrow keys in the navigation bar to change to the next process screen.


Process screens can be created with the setup program and transferred to the device. For a process screen to be displayed, it must be activated (configuration parameters in the setup program; see operating manual, chapter "Configuration - only in setup program" > "Process screens").

5.4.9 Counter/integrator




This visualization shows all activated counters/integrators.

View



- | | | | |
|-----|---|-----|--|
| (1) | Abbreviation (configurable) of the counter/integrator | (3) | Current status of the counter/integrator (unit configurable) |
| (2) | Open detailed view of the counter/integrator | | |

Detailed view



- | | |
|--|--|
| (1) Designation (configurable) of the counter/integrator | (4) Limit value for max. alarm (configurable) |
| (2) Specifications on current counter/integrator
The type (configurable; here: external) decides when the status is stored and the counter/integrator thus completed. | (5) Bar graph view of the current counter/integrator
Start and end of the display range are configurable. |
| (3) Specifications on the completed counter/integrator | (6) Back to view of all activated counters/integrators |
| | (7) Display of the last 7 completed counter/integrator statuses |

5.4.10 Comment text



This function can be used to enter a text (max. 160 characters) that is entered in the event list after completing the entry.

⇒ chapter 5.5 "Text input dialog", Page 62

The comment text is assigned either only to the group in question or to all groups. The assignment depends on the visualization that the device is in when the function is called up.

In the case of the following visualizations, the comment text is assigned to all groups: current batch, completed batch, process screen, counter/integrator

In the case of the following visualizations, the comment text is only assigned to the group in question: curve diagram, digital diagram, bar graph, text image, report

The assignment to a certain group applies when only the event list of a certain group is displayed (memory view, curve presentation of the completed batch). In addition, the PCA3000 PC evaluation software can filter the events according to groups.

Comment with authentication

Depending on the "Comment with authentication" parameter, the user ID and password are required to enter a comment text (see operating manual, chapter "Configuration - only in the setup program" > "User list" > "Password rules").

5 Operation

In the case of a device that has extra code 888 (FDA), the setting in question is performed using the PCS software.

The approach when entering a comment with authentication basically corresponds to the one when rendering an electronic signature for a completed batch (only steps 2 to 4).

Example of an electronic signature:

⇒ chapter 5.8 "Electronic signature", Page 69

5.5 Text input dialog

The text input dialog is used for all functions in which the user can enter or edit text.

Example: Configuration of an analog input

Analog input 1


14:02:06

Channel designation	AI01	(1)
Channel description	Analog input 01	(2)
Sensor	Inactive	(3)
Temperature input		
Unit		
Linearization		
Resistance measuring range		
Measuring range-Start		
Measuring range-End		

- (1) Editable text (max. 5 characters)

(3) Drop-down menu (text not editable)
- (2) Editable text (max. 21 characters)
- Tap the text field to edit the text.

Text input dialog




- | | |
|--|--|
| <p>(1) Parameter (designation of the configuration parameter from the previous dialog)</p> <p>(2) Open text list (history of last 20 text entries)
The text from the list replaces the text in the input box.</p> <p>(3) Shift key (toggle to the second level of the current keyboard layout, e.g., upper-case)
To hold, you need to press the key for longer. To reset, (briefly) press the key again.</p> <p>(4) Cancel text entry (input is not applied)</p> | <p>(5) Input box with current text
After changing to the text input dialog, the current text is fully selected. Tapping on the input box displays a cursor. Tapping and dragging the cursor lets you select multiple characters.</p> <p>(6) Backspace key
The character to the left of the cursor is deleted. If multiple characters are selected, they are deleted.</p> <p>(7) Cursor keys (move cursor left or right)</p> <p>(8) Complete text entry (input is applied)</p> <p>(9) Toggle keyboard layout (for example letters, digits, non-standard characters)</p> |
|--|--|

5 Operation

Keyboard mappings

Each of the 30 keys in the default keyboard layout can be mapped with up to 10 characters. The Shift key toggles between the first two characters. To select more characters, you need to hold down the relevant key for longer. This displays a selection window in which you can select the desired character by tapping.



- (1) Multiple assignment of the "a" key
To leave the selection window without selecting a character, tap on the screen outside of the selection window.

More examples of multiple assignments of individual keys:

q Q @
s S ß
< > | '

Keyboard layout

The "Keyboard layout" key enables you to switch between the various keyboard layouts (keyboard assignments) (e.g., letters, digits, non-standard characters).


In the default keyboard layout (e.g., letters), each key can be assigned up to 10 characters. In the other keyboard layouts, only one character per key is possible.

The keyboard can be assigned individually for each language with the setup program (max. 6 layouts).

5.6 Flash manager

The Flash Manager menu automatically opens when the device is in basic status and a USB flash drive (FAT16/FAT32 file system) is plugged into the front USB port. If the device is in a menu (main menu, alarm and event list, display), the Flash Manager is opened only after exiting the menu.

Device dialog box



(1) Flash manager functions

(2) "Apply" button

The selected function is grayed out.

The Flash Manager provides functions for transferring specific data between the device and a USB flash drive. The available functions depend on the logged-on user's rights, or on the public rights. The selected function is performed by pressing the "Apply" button (check mark).



CAUTION!

Do not remove the USB flash drive without ejecting it.

There is a risk of losing data.

- ▶ Before removing the USB flash drive, always run the "Eject USB flash drive" function. Do not remove the USB flash drive until you see the "Safe to remove hardware" message.

Flash manager functions

- **Ejecting USB flash drive:**
Function for safely removing the USB flash drive to avoid data loss
- **Writing recording data to USB flash drive:**
Any recording data not yet backed up is written to the USB flash drive (retrieving the data). When this function is called up again, only the newly added recording data since the last run is transferred to the USB flash drive
- **Saving all recording data on the USB flash drive (backup):**
All recording data available on the device (including previously backed-up data) is transferred to the USB flash drive (data backup). It can take up to 30 minutes to execute this function!
The user can choose a time period from which the recording data is saved. The "Total" time period corresponds to the previous function. For the other time periods (1 day, 1 week, 4 weeks) the determined starting time is displayed and updated (see example further down). Here, the user can also

5 Operation

choose any starting time in the past. Using the additional parameter "Save counters/reports" it is possible to save the current readings of the counters and integrators as well as the statistics (report) – even if they have not yet been completed – along with the recording data.

- **Writing current counter/statistics and recording data to the USB flash drive:**
The current counter and integrator statuses, as well as the statistics (report) are read out, and written to the USB flash drive along with the newly added recording data.
- **Reading configuration from USB flash drive:**
The configuration data (except the user list) is transferred from the USB flash drive to the device. This reconfigures the device and data recording is restarted.
- **Writing configuration to USB flash drive:**
The configuration data (incl. the user list) is transferred from the device to the USB flash drive.
- **Writing service data to USB flash drive:**
Internal service data is transferred to the USB flash drive and can be sent to the device manufacturer for diagnosis.
- **Software update:**
Function for updating the device software; the USB flash drive must contain specific files provided by the device manufacturer.
- **Reading user list from USB flash drive:**
The user list is transferred from the USB flash drive to the device and activated.



CAUTION!


Data loss due to software update.

A software update deletes all recording data stored on the device (incl. counters/integrators and statistics).

- Before updating the software, save (back up) the recording data on a USB flash drive.
-

Saving the recording data of a certain time period

In the following example the recording data of a week should be saved.



The screenshot shows a 'Flash-Manager' dialog box with a title bar. Inside, there's a section titled 'Flash-Manager' containing three fields: 'Time period' with a dropdown menu showing '1 week' (labeled (1)), 'Start time' with a text box showing '08/04/2016 15:00:00' (labeled (2)), and 'Save counters/reports' with a dropdown menu showing 'No'. At the bottom of the dialog are two buttons: a blue button with a white 'X' (cancel) and a blue button with a white checkmark (confirm).

(1) Select time period

(2) Determined starting time (editable)

The starting time is automatically determined by the device depending on the current date (here: August 04, 2016), the current time (here: 15:00:00), and the selected time period. This time can be changed by the user.



NOTE!


The recording data that is saved in the device is organized into data blocks of 20 kB each. This may mean that even data that was recorded prior to the starting time is saved.

5 Operation

5.7 Web server

The device includes a built-in web server which supports online visualization with the help of a web browser. The user can access the process values, various visualizations, and the device's alarm and event list.

For access, you need to enter the device's IP address in the address line of the web browser. If needed, you can also use the DNS device name.



The start page, index.htm, exists by default; more HTML pages can be transferred to the device using the setup program. To prevent unauthorized access, you can activate a logon procedure with user name and password.

The web server is configured with the setup program (see the operating manual chapter "Configuration - only in setup program" > "Web server").

The web server is also activated with the setup program (see the operating manual chapter "Configuration" > "Device": Version of online visualization):



NOTE!

Online visualization in version 336.xx.xx (old variant):

The Microsoft Silverlight¹ plug-in is required for this function. If the plug-in is not present, the web browser displays a note and offers to install it.

Supported web browser: Microsoft Internet Explorer¹

¹ Microsoft, Silverlight, and Internet Explorer are registered trademarks of the Microsoft Corporation.

5.8 Electronic signature

With the extra code 888 (FDA), the user has the option to provide a completed batch or the recording data of a certain time period with their electronic signature. A logged-on user can also provide their signature during logoff – it applies to the entire time period for which the user was logged on.



The prerequisites for the electronic signature are the device-dependent settings in the PCS software as well as the related user right.


Completed batch

The following example shows the electronic signature of a completed batch.

Step	Action																
1	In the report of the completed batch recording, press the button (1) for the electronic signature: <table border="1"> <thead> <tr> <th colspan="2">Completed batch - Batch 1</th> </tr> </thead> <tbody> <tr> <td>Program name</td> <td>Text 1</td> </tr> <tr> <td>Customer info</td> <td>Text 3</td> </tr> <tr> <td>Batch name</td> <td>Text 5</td> </tr> <tr> <td>Batch number</td> <td>000000012Text 7</td> </tr> <tr> <td>Batch start</td> <td>07/27/2016 09:48:15</td> </tr> <tr> <td>Batch end</td> <td>07/27/2016 09:48:23</td> </tr> <tr> <td>Batch duration</td> <td>00:09</td> </tr> </tbody> </table>	Completed batch - Batch 1		Program name	Text 1	Customer info	Text 3	Batch name	Text 5	Batch number	000000012Text 7	Batch start	07/27/2016 09:48:15	Batch end	07/27/2016 09:48:23	Batch duration	00:09
Completed batch - Batch 1																	
Program name	Text 1																
Customer info	Text 3																
Batch name	Text 5																
Batch number	000000012Text 7																
Batch start	07/27/2016 09:48:15																
Batch end	07/27/2016 09:48:23																
Batch duration	00:09																

5 Operation

Step	Action
2	Select your user ID (in this case: master)  The user has to select his/her ID. This step is required because someone other than the currently logged-on user can provide this signature.
3	Enter text that describes the meaning of the signature (evaluation text) using the keyboard. Alternatively, select text from the text list (1) and, if required, edit it: (1)  The possibilities of entering a text depend on the configuration (no text available, enter text via keyboard, select text from text list, select text from text list and edit).

Step	Action
4	Enter password: 
5	Confirm process:  The process can still be aborted here.

5 Operation

Step	Action
6	In the report of the completed batch recording, press the button (1) to display the signature that was provided: Completed batch - Batch 1 Program name Text 1 Customer info Text 3 Batch name Text 5 Batch number 000000012Text 7 Batch start 07/27/2016 09:48:15 Batch end 07/27/2016 09:48:23 Batch duration 00:09 (1) The signature (here: master) and the meaning of the signature (here: batch o.k.) are displayed: Completed batch - Batch 1 15:43:19 Electronic signature Signature Master Significance Batch o. k.

Time period

The electronic signature for a time period essentially differs from the signature for the completed batch by requiring the time period in question to be selected.

The signature applies to the time period that is displayed in the diagram at the time of the signature. The displayed period may have to be expanded prior to signing. During signing the time period can only be reduced; it can then no longer be expanded.

Significance	
Signature	Master -
Significance	
Time period	
from	08/09/2016 15:44:14
to	08/09/2016 15:44:50

Logoff

The electronic signature during logoff requires no entry of the user ID as this function is only available for the user who is currently logged on. The further steps, including entry of the password, correspond to those of the signature for the completed batch from step 3 (enter text for meaning) to step 5 (confirm process). The signature can only be evaluated with the PCA3000 software.

The signature applies to the entire time period for which the user was logged on.

5 Operation

The setup program is a PC software tool for convenient configuration of the paperless recorder; it offers the following functions:

- User-friendly program operation
- Support for multiple languages, both in the setup program and in the device (operating language)
- Activation of optional device features (extra code)
- Editor for creating process screens for the device
- Communication between the setup program and the device via Ethernet or USB device interface for transferring setup data and process data
- Display of process data for selected signals (online data)

6.1 Installation

6.1.1 Hardware and software requirements

To install and operate the setup program, you need a PC with a CD/DVD drive, a USB host interface, and an Ethernet interface.

Use of interfaces:

⇒ chapter 6.4.4 "Transfer setup file", Page 90

Specifications on the supported operating system (Microsoft Windows¹), required hard disk drives, and memory can be found under information about the setup program on the manufacturer's website (search for 706530; in the search results click the link to the product, go to software, and look for further information about the setup program).



NOTE!

The setup program is delivered on a CD; alternatively, it can be downloaded from the manufacturer's website.

6.1.2 Installing and starting the program

Installing the program



CAUTION!

Installing the setup program can interfere with running programs.

This can cause loss of data.

► Quit all programs before starting the setup program installation.

Step	Action
1	Insert the CD into the drive and close the drive.
2	After inserting the CD, the installation program automatically starts. If this does not happen, run the "Launch.exe" file in the main directory of the CD.
3	The installation program guides you through the rest of installation with on-screen prompts.
4	Read and accept the terms of the license agreement. Accepting the license agreement is a prerequisite to installing the setup program.

¹ Microsoft and Windows are registered trademarks of the Microsoft Corporation.

6 Setup program

Step	Action
5	Enter the license number for the setup program (see CD sleeve; you may also need to enter license numbers for additional functions after installation). If the "30-day test version" option is set during installation, the setup program is fully functional for 30 days (full user rights). After 30 days, the program automatically switches to a "demo version" in which some functions, e.g., data transmission, data storage, and printing are blocked. The software can be licensed at a later date. ⇒ chapter 6.1.3 "Logon and rights", Page 76
6	Specify a program folder in the Windows start menu into which the icons for starting the software should be copied. The directory for the program files is determined automatically.
7	Press the "Install" button to start the actual installation.

Starting the program

After completing the installation, the setup program can be started from the Windows Start menu.

6.1.3 Logon and rights


Logging onto the setup program

The user name and password are not requested following initial installation of the setup program. The user is logged on initially as "Specialist" with a blank password. In the "**Extras**" menu, the "**Renew logon/Change password**" function can be used to activate this request when the program starts.

⇒ chapter 6.3.4 "Extras", Page 84

A distinction can be made between the "Specialist" and "Maintenance" users when the log-in function is activated. The two users have different rights to functions of the setup program.

If the prompt is active, the user must log on:

Step	Action
1	Log onto the program.  A screenshot of a 'User log-in' dialog box. It has a title bar with a close button (X). On the left is a lock icon. To the right of the lock are two input fields: 'User ID:' with a dropdown menu showing 'Admin' and a small downward arrow, and 'Password:' with a text box. Below these fields are three buttons: 'OK', 'Cancel', and a button with a downward arrow.



NOTE!

The user is now logged onto the setup program but not the device. To log onto the device, the user again needs a user ID (e.g., Master) and the device password. This data must be entered in the device's connection list when setting up the connection to a device.

Rights in the setup program

Depending on the installation and logon, individual users have different rights in the setup program. The differences are summarized in the following table.


Right	Demo installation	Maintenance	Specialist
Write interface texts	-	X	X
New	X	X	X
Open	X	X	X
Save, Save As, Delete	-	X	X
Configure undocumented parameters	-	-	X

6 Setup program

Right	Demo installation	Maintenance	Specialist
Export data to external mass storage (USB flash drive)	-	x	x
Import data from external mass storage (USB flash drive)	-	x	x
Print	-	x	x
Activation of program options	x	-	x
Activate extra codes	-	-	x
Edit interface settings	-	x	x
Edit device settings	x	x	x
Delete device	-	-	x
Create new device	x	-	x
x = Right exists, - = Right does not exist			

6 Setup program

6.2 User interface



- | | |
|------------------------------------|-----------------------------------|
| (1) Menu bar | (2) Toolbar |
| (3) Working area – navigation tree | (4) Working area – display window |
| (5) Connection status | (6) Online data |

Menu bar

The individual functions of the setup program are launched from the menu bar.

⇒ chapter 6.3 "Menu bar functions", Page 81


Toolbar

The toolbar contains selected functions from the menu bar. These can be launched by left-clicking on them. Hovering the mouse pointer over one of the icons displays the name of the function after a few seconds.



Moving the toolbar

The user can change the position of the toolbar:

Step	Action
1	Position the mouse pointer between two groups of symbols. 
2	Press the left mouse button.
3	While holding down the left mouse button, drag the toolbar to the desired location.
4	Release the left mouse button. 

Possible positions of the toolbar:

- Along the left or right window border (vertical alignment)
- Below the menu bar (horizontal alignment),
- Along the lower edge above the user information (horizontal alignment)
- Any position (its own window - any alignment by changing the window size)

Closing the toolbar

Once the toolbar has been moved, it can be closed by clicking the  button. To display the toolbar again, it must be activated in the **File > Default settings** menu under **User interface** (select checkbox). The toolbar then appears at the location to which it was previously moved. Double-clicking on the free space above the symbols (or between two groups of symbols) moves the toolbar back to its original position underneath the menu bar.

Working area

The working area comprises the navigation tree (left) and the display window (right); it shows the current settings of a configuration file (setup file).

⇒ chapter 6.4 "Setup file", Page 87

The way the working area is divided can be changed by moving the border between the navigation tree and display window sideways with the aid of the left mouse button.


6 Setup program

Connection status

The "Connection status" line indicates whether a connection to a device exists. In addition, some interface data is displayed, e.g., the IP address.


The line can be shown and hidden using the **Window > Connection status** function.

Example: No connection



no device connected

Example: Connection to a device



Connected with 706520 - Name , HTTP , 10.11.101.4:80 , Recorder 1 , logged in with ID: Master

The height of the line can be changed by moving the border of the online data window with the aid of the left mouse button.

Online data

The "Online data" function displays current process data in the setup program.

The online data window can be shown and hidden using the **Window > Online data** function.

The height of the window can be changed by moving the border of the working area or the "Connection status" line with the aid of the left mouse button.

Documentation (operating manual)

The operating manual of the device is available as a PDF document in the setup program when you press F1 for the Help function.

The document is opened with the program (PDF viewer) assigned to files with the "PDF" extension on the PC in question.

The language of the document depends on the language of the setup program (menu **File > Default settings... > National language of program**). The document is not available in all languages.

6.3 Menu bar functions

This chapter describes the menu bar functions. The order of the subchapters corresponds to the location of the menus in the menu bar (from left to right).

Functions that can also be called up via the toolbar are marked with the matching icon here.

6.3.1 File

Overview of menu items:

New	Ctrl+N
Open ...	Ctrl+O
Save	Ctrl+S
Save as...	
Close	
Export as RTF text	
Print ...	Ctrl+P
Print preview...	
Printer setup...	
Default settings ...	
Last files ...	
Exit	

New



Creates a new setup file in the working area.

The user can select from the following options:

- Manual (user-defined setting)
- Data import from external mass storage
- Via interface: Automatic detection of the connected device
- Via interface: Automatic detection and reading out of the configuration

Open ...



Opens an existing setup file and displays the content in the working area.

Save



Saves the settings shown in the working area in a setup file. The file name only needs to be entered once. If the file is saved again, no prompt for the file name is shown.

Save as ...

Saves the settings shown in the working area in a setup file. In contrast to the **Save** function, a prompt for the file name always appears in this case.

To use a setup file of a paperless recorder type 706520 for a type 706521 or 706530, it must be converted. To do this, the appropriate file type must be selected when saving.

6 Setup program

Close

Removes the settings shown in the working area from the working area and closes the Setup window. The user has the opportunity to save changes that have not yet been saved.

Export as RTF text

Saves the current setting as an RTF file on the PC.

Print ...



Prints the setup settings. The menus to be printed can be selected beforehand.

Print preview ...



The print results are displayed on screen. Several pages can be displayed and the view can be scaled.

Printer setup ...

Allows the printer settings to be changed. When a program starts, the Windows default printer is always used as the active printer.

Standard Settings ...

Allows the default settings of the setup program to be changed. Some changes are not applied until you restart the setup program.

Last Files ...

Displays the file names of the setup files last saved.


Clicking once on the file name opens the setup file or displays an already opened setup file as the active window.

Exit

Quits the setup program. The user has the opportunity to save changes that have not yet been saved.

6.3.2 Edit

Overview of menu items:

A screenshot of a menu list with five items: 'File-Info-Header', 'File-Info-Text', 'Configuration level', 'Online parameters', and 'Setup only'. The last three items have a right-pointing arrow next to them.

File-Info-Header	
File-Info-Text	
Configuration level	>
Online parameters	>
Setup only	>

The menu items and their sub-menus match the navigation tree in the working area.

6.3.3 Data transfer

Overview of menu items:

Establish connection...	F2
Break connection...	Alt-F2
Data transfer to the device...	F5
Data transfer from the device...	Alt-F5
Data export to ext. mass storage	
Data import from ext. mass storage	
Transferring data...	

Establish Connection ...



Opens the device connections list.

The device connections list contains all devices to which a connection can be established via the setup program. Devices can be added to or removed from the list.

The interface parameters for the connection are also configured in the device connections list.

Break connection ...



Terminates the connections of the active setup file.

Data transfer to the device ...



Sends the setup data to the device.

A connection to the relevant device is required. If there is no connection, the device connections list is opened automatically.

Data transfer from the device ...



Reads out the setup data from the device.

A connection to the relevant device is required. If there is no connection, the device connections list is opened automatically.

Data export to ext. mass storage



Transfers the setup file to an external mass storage (USB flash drive).

Data import from ext. mass storage



Reads out a setup file from external mass storage (USB flash drive).

The setup settings are displayed in the working area.


Apply data ...

This function is not supported by the paperless recorder.

6 Setup program

6.3.4 Extras

Overview of menu items:



Activation of program options

Activates optional functions of the setup program (entry of additional license numbers).

Using this function, the setup program can also be registered with a valid license number at a later date (30-day test version or full version) if a valid license number was not entered during the installation (demo mode).

Renewing log-in/altering password

Opens a window to activate user login.

After the setup program has been installed, prompts for the user name and password do not appear when the program starts until user logon has been activated. The user is logged on initially as "Specialist" with a blank password.

This function activates the user name and password prompts when the program starts and changes the current password.

Comment in audit trail

Creates a comment in the audit trail data of the setup program.

In devices with enhanced security requirements, audit trail data documents operator actions in the individual PC programs.

Online parameters

Allows access to the device's online parameters. An active connection to the device is required for this.

The online parameters are also available in the navigation tree.

Text library...

Opens a window for editing the text library.

The text library is used to manage the various control languages for the device (incl. online visualization).

⇒ chapter 9.1 "Country settings", Page 201

In various sub-menus, the "Language >" button allows editing of the respective language.


Version library...

Shows the content of the version library.

The list contains the default versions of the device software (incl. the web server) and the compatible hardware versions provided by the device manufacturer together with the setup program. Additional software versions that were imported subsequently (e.g., customer-specific versions) are also included.

6.3.5 View

Overview of menu items:



Open elements

Expands all elements in the working area so that the sub-items and the settings can be viewed.

Close elements

Collapses all elements in the working area.

Full view

The working area contains all functions of the setup program.

User list


The working area contains only the "User list" function.

Only the user table (user ID and name, password, group assignment) is transferred to the device. For this to function correctly, the user groups in the device and in the setup file must match.

Devices with extra code 888 (FDA) do not have this function.

6.3.6 Window

Overview of menu items:



Cascade



Arranges all open setup windows in an overlapping arrangement.

Left-clicking on a window brings it to the foreground.

Tile vertically



Arranges all open setup windows in a tiled arrangement.

Left-clicking on a window makes it the active window.

Arrange icons

Arranges the symbols for all minimized setup windows in the lower region of the user interface.

This function has an effect only if a symbol was previously moved out of the lower region.

6 Setup program

Online data

Alternately shows/hides the online data window.

A checkmark preceding the menu item indicates that the window is shown.

Connection status

Alternately shows/hides the line for displaying the connection status.

A checkmark preceding the menu item indicates that the line is shown.

Opened window (here: Setup 1)


Displays the names of all opened setup files as a list.

Clicking on the name in the list makes the associated window the active window. A checkmark preceding the name indicates the active window.

In the example shown here, only one setup file is open; it is named "Setup 1".

6.3.7 Info

Overview of menu items:



Info on setup
Registered license numbers ...
Program folder ...

Info on setup

Displays information about the setup program, incl. the version number.

The version number is important, for instance, when contacting the service hotline.

Registered license numbers ...

Shows all registered license numbers and any active options.

The license numbers and the information about active options are important, for instance, when contacting the service hotline.

Information about obtaining a fee-based license number can be found on the manufacturer's website (see software download of setup program).

Program folder ...


Shows the various folders (directories) that are being used on the hard disk drive or in the network by the setup program.

To display the contents of the folder, click the button (on the right next to folder path).

6.4 Setup file

The setup file contains full details of the device's hardware and software, as well as its configuration. The function **File > New** or **File > Open** creates a new setup file, or opens an existing file.

6.4.1 Views and functions



- (1) Navigation tree
Shows the areas and the sub-items
- (3) Active setup window

- (2) Display window
Shows the sub-items and their settings
- (4) Inactive setup window

6 Setup program

Navigation tree

Clicking on the  ("-") icon zooms out of the view; clicking on the  ("+") icon zooms back in.

Double clicking an entry (e.g., "Analog inputs") starts the change dialog. Alternatively, you can initiate changes via the menu bar (**Edit** > **Configuration level** > **Analog inputs**).

Display window

Double clicking an entry in the display window starts the change dialog. Clicking on the  icon ("right arrow") in front of an entry lists the current settings in the display window; clicking on the  icon ("down arrow") hides these settings again.

Setup window

If several setup windows are open simultaneously, clicking once on the name at the lower edge of the inactive window (here: "Setup 2...") makes it the active window.




Right mouse button functions

If you press the right mouse button in the navigation tree or in the display window, you have access to various context-dependent functions. The functions relate to the entry to which the mouse pointer is pointing when pressing the right button.

Example:

You press the right mouse button on the "Analog inputs" entry.



Analog inputs > **Edit**

The function starts the change dialog for configuring the analog inputs.

The change dialog can also be started by double clicking with the left mouse button.

Analog inputs > **Maximize**

This function shows you the current configuration of the analog inputs.

Alternatively, you can view the current configuration by left clicking the  icon ("right arrow").

Copy data to clipboard > **Analog inputs**

The function copies the current configuration of the analog inputs to the Windows clipboard (RTF format). The clipboard content can be used in an editor or text processing program, for example.

Copy data to clipboard > **All data**

The function copies the entire current configuration – not just that of the analog inputs – to the Windows clipboard (RTF format). The clipboard content can be used in an editor or text processing program, for example.

Print


The function enables the current settings to be printed. You can choose which parameter groups to print and which not to print. Alternatively, printing is also possible via the **File** menu.

6.4.2 Create file info

The file info consists of the **file info header** and the **file info text**; and is used to describe the setup file. The information is only stored in the setup file and not transferred to the device.

The file info header and file info text can be directly called up via the corresponding menu entry in the navigation tree or display window.

Setup dialog box



Parameter

Parameter	Selection/settings	Description
File info header		
Short info	Enter text	Description of the setup file in short form
Programmer	Enter text	Name of programmer
Order code	Enter text	Order code
Order	Enter text	Order number
Extra info	Enter text	Additional information
File info text		
File info text	Enter text	Exhaustive description of the setup file

6.4.3 Create configuration

The device configuration is divided into three areas in the setup program:

- Configuration level
- Only setup
- Online parameters

The individual parameters and their settings are described in the relevant chapters of this operating manual.

Configuration level

⇒ chapter 7 "Configuration", Page 91

6 Setup program

Only setup

⇒ chapter 9 "Configuration – in setup program only", Page 201

Online parameters

⇒ chapter 10 "Online parameter (setup only)", Page 255

6.4.4 Transfer setup file

To transfer the setup file, you first need to open a connection between the setup program (PC) and the device.

A connection is possible via:

- Ethernet interface (TCP/IP)
- USB device interface

To use the Ethernet interface, the device must have an IP address.

If DHCP is supported on the network and enabled on the device, the IP address is assigned automatically by the network.

The assignment of the IP address and other required settings in this context can also be performed manually.

⇒ chapter 7.21 "Ethernet", Page 179

The USB device interface is needed if there is no network, or no IP address was assigned.



NOTE!

The USB device interface is not intended for a permanent connection, since unintentional removal of the USB connector cannot be prevented due to the lack of a captive connection.

Establish connection

Function in the menu bar: **Data transfer > Establish connection**

If you wish to establish a connection (or start data transfer without an existing connection), the setup program opens the device connection list. The device connection list contains all the devices for which a connection has been configured. Users can add connections to new devices, change the features of existing connections (interface parameters) as well as remove connections.

The "Use connection settings assistant" function assists the user with creating a new entry, i.e. a new connection, and with editing existing entries.

To create a connection, select the desired device in the device connection list and then press the  button.

This chapter describes the paperless recorder configuration based on the menu items and parameters of the device: **Main menu > Configuration**

The description also applies for the configuration with the setup program.



NOTE!

The configuration on the device is only available if a user is logged on, and the user has the required rights.

Parameters within a menu item that only exist on the device or in the setup program are marked as "(device only)" or "(setup only)".

Beyond this, there are functions that can only be configured with the setup program. These functions are described in separate chapters:

⇒ chapter 9 "Configuration – in setup program only", Page 201

⇒ chapter 10 "Online parameter (setup only)", Page 255

Default settings are shown in **bold** in the parameter tables.

Copy configuration

Certain confirmation menus offer the option of copying the configuration of one instance to another instance. In such cases the navigation bar contains the following button:



This enables the configuration of an analog input to be applied for other analog inputs, for example.

Edit texts during configuration

Certain texts, such as the channel designations, can be modified directly during the configuration.

In the setup program, the user can enter or change text in one, several, or different languages after pressing the (1) "Language" button. All languages that exist in the country settings are available for selection.



(1) Language

In the device, the text can only be changed in the currently selected language.

7 Configuration

Overview of inputs and outputs and internal functions

The following table provides an overview of all inputs and outputs, as well as the internal functions with digital or analog output signals. The number of optional inputs and outputs depends on the device version (see order details, options 1 to 3).

Inputs/outputs/functions	Notes
Analog inputs 1 to 6	Optional extra
Analog outputs 1 to 2	Optional extra
Digital inputs 1 to 12	Optional extra
Digital inputs/outputs 1 to 12	Optional extra, can be switched individually
Relay outputs (changeover contact) 1	As a standard feature
External analog inputs 1 to 24	As a standard feature, via interface
External digital inputs 1 to 24	As a standard feature, via interface
External text variables 1 to 10	As a standard feature, via interface
External event texts 1 to 4	As a standard feature, via interface; 1 text per group
Limit value monitoring functions 1 to 24	As a standard feature
Counters/integrators 1 to 6	As a standard feature; incl. 2 high-speed counters (via digital inputs/outputs 1, 2)
Flow measurements 1 to 2	As a standard feature; high-speed inputs are required for the "Digital" signal type
Math functions 1 to 6	Optional extra (extra code 260)
Logic functions 1 to 6	Optional extra (extra code 260)
ST code - ST analog outputs 1 to 40 - ST digital outputs 1 to 40 - ST alarm outputs 1 to 32 - ST fault output	Optional extra (extra code 221); see chapter 9.10 "ST code", Page 225

7.1 Selectors

The selectors contain signals that are available for configuration on the device or in the setup program. These are device signals (e.g., analog and digital inputs or internal signals), and signals that are transferred to the device via an interface (external analog and digital inputs; can also be written using barcodes).

7.1.1 Analog selector

Category	Signal	Description
No selection		No signal selected
Analog inputs	Analog input 1 to 6	Analog input signal
External analog inputs	Ext. analog input 1 to 24	Signal of external analog input (via interface)
Flow	Flow 1 to 8	Current flowmeter reading
Counter statuses (current)	Counters (cur.) 1 to 2	Current value of counter or integrator
Math results (analog)	Math (analog) 1 to 6	Results of math formula
ST code analog outputs	ST analog output 1 to 40	Signal of the analog output from the PLC module (application created with ST code)
Batches	Text comparison 1 to 10 for batch 1	Result of the text comparison for the batch line concerned (text length or index)
Time	Time (hours)	Hours, minutes, or seconds of the current time
	Time (minutes)	
	Time (seconds)	

7 Configuration

7.1.2 Digital selector

Category	Signal	Description
No selection		No signal selected
Digital inputs	Digital input 1 to 12	Signal of digital input
Digital inputs/ outputs	Digital input/output 1 to 12	Signal of digital input
External digital inputs	Ext. digital input 1 to 24	Signal of external digital input (via interface)
Math results (digital)	Math (digital) 1 to 6	0 = Math result is valid 1 = Math result is invalid (computation error, also for substitute value output)
Logic results	Logic 1 to 6	Results of logic formula
Signals of limit value monitor.	Status of limit value monit. 1 to 24	Status signal of limit value monitoring function
Alarms of digital inputs	Alarm digital input 1 to 12	Alarm signal of the digital input
Alarms of digital inputs/outputs	Alarm digital inputs/outputs 1 to 12	Alarm signal of the digital input
Alarms of analog inputs	Alarm 1 analog inp. 1 to 6	Alarm signal from alarm 1 of the analog input
	Alarm 2 analog inp. 1 to 6	Alarm signal from alarm 2 of the analog input
Alarms of ext. digital inputs	Alarm ext. digital input 1 to 24	Alarm signal of external digital input
Alarms of ext. analog inputs	Alarm 1 ext. analog input 1 to 24	Alarm signal from alarm 1 of the external analog input
	Alarm 2 ext. analog input 1 to 24	Alarm signal from alarm 2 of the external analog input
Alarms of logic	Alarm logic 1 to 6	Alarm signal of logic formula
Alarms of math	Alarm 1 math 1 to 6	Alarm signal from alarm 1 of math formula
	Alarm 2 math 1 to 6	Alarm signal from alarm 2 of math formula
Alarms of limit value monitor.	Alarm limit value monit. 1 to 24	Alarm signal of limit value monitoring function
Alarms of flow	Alarm 1 flow 1 to 2	Alarm signal from alarm 1 of flow measurement
	Alarm 2 flow 1 to 2	Alarm signal from alarm 2 of flow measurement
Alarms of counters/integrators	Alarm 1 counter/integr. 1 to 6	Alarm signal from alarm 1 of counter or integrator
	Alarm 2 counter/integr. 1 to 6	Alarm signal from alarm 2 of counter or integrator
Alarms of groups	Upper tol. alarm gr. 1 to 4	Upper tolerance band alarm signal of group
	Lower tol. alarm gr. 1 to 4	Lower tolerance band alarm signal of group
	Alarm group 1 to 4	Collective alarm of group

7 Configuration

Category	Signal	Description
System alarms	Collective alarm	Collective alarm of device The signal is active if the alarm list contains at least one entry (an entry is removed as soon as the alarm disappears).
	Collective alarm with acknowledgment	Collective alarm of device; active until acknowledged The signal is activated for each new entry in the alarm list; it remains active until acknowledged (even if the entry has disappeared from the alarm list).
	Memory alarm	The signal is active if the data was not read out in time and the free internal memory drops below the memory alarm limit value (Configuration > Device).
	Battery empty	Battery alarm (buffer battery is discharged and must be replaced) Notify service department! Caution: RAM memory content may be lost!
	Battery weak	Battery pre-warning (buffer battery can be replaced within 4 weeks without data loss) Notify service department!
	User logged on	Signal is active when a user is logged on.
	USB flash drive active	This signal is active if a USB flash drive is plugged in and active.
	Temp. unit °F device	This signal is active if the temperature unit of the device is configured as "Degrees Fahrenheit" (Configuration > Device).
	Temp. unit °F interface	This signal is active if the temperature unit of the interface is configured as "Degrees Fahrenheit" (Configuration > Device).
	The following "Slave timeout ..." signals are active if the device is acting as a Modbus slave, timeout monitoring is enabled, and no request is received from the Modbus master within the configured period (Configuration > Serial interface; Configuration > Modbus/TCP).	
	Slave timeout Com1	(for Modbus via serial interface)
	Slave timeout Com1 inv	(as above, inverted signal)
	Slave timeout TCP1	(for Modbus-TCP, master 1)
	Slave timeout TCP1 inv	(as above, inverted signal)
	Slave timeout TCP2	(for Modbus-TCP, master 2)
	Slave timeout TCP2 inv	(as above, inverted signal)
	Timeout PROFINET	Timeout signal of the PROFINET interface
	Timeout GPS	Timeout signal of the GPS function
Batches	Batch 1 active	Signal active when batch reporting is active
	Alarm batch 1	Alarm signal of batch reporting
ST code digital outputs	ST digital output 1 to 40	Signal of the digital output from the PLC module (application created with ST code)
ST code alarm outputs	ST alarm output 1 to 32	Alarm signal from the PLC module (application created with ST code)

7 Configuration


Category	Signal	Description
ST code error	ST error	Error signal from the PLC module (application created with ST code)

7.2 Basic device (setup only)

This menu item is used to change device hardware (optional plug-in boards) and optional functions (extra code, e.g., math/logic) in the current setup project. The following options are available for this purpose:

- User-defined creation: Device hardware and optional functions are selected by the user in the setup program.
- Automatic detection: Device hardware and optional functions are read out from the connected device and transferred to the setup program.
- Automatic detection with read out of setup file: The configuration is additionally read out from the device here and transferred to the setup program.

Setup dialog box



7 Configuration

7.3 Device

The general device data is configured in this menu.

Device dialog box

Device		🔔 10:05:38
Device name	Name	
Language	English ⬇	
Temperature unit device	Degrees Celsius ⬇	
Temperature unit interface	Degrees Celsius ⬇	
Memory alarm limit value	20 %	
		

Parameter

Parameter	Selection/settings	Description
Device name	Name (example) (max. 20 characters)	The device name is used in the setup program, Web server, and the PCC and PCA3000 PC programs.
Language	Language 1: English (example) Select language (drop-down menu).	Language of display texts (max. 15 languages) All texts for a language can be changed using the setup program. This is also where the language order is defined. The first 15 languages are available on the device.
Country settings after power on (setup only)	Yes (☒) , No (☐)	If "Yes," is selected, the user can configure settings immediately after switching on the device the next time. The parameter is then automatically reset to "No" in the device so that no settings occur after switching back on again. The parameter is not automatically reset in the setup file. This parameter can also be set in the parameterization: ⇒ chapter 8.6 "System data", Page 200 The country settings are also configured after switching on the device for the first time as part of the startup.

Parameter	Selection/settings	Description
Temperature unit device	Unit in which the temperature values are entered and displayed. When the unit is changed, all the relevant values are converted and the display is adjusted.	
	Deg. Celsius Deg. Fahrenheit	Unit = °C Unit = °F
Temperature unit interface	Unit of the temperature values transferred via the interface (external analog inputs). However, the "Temperature unit device" parameter is authoritative for displaying the values. The values transferred via the interface are converted if needed.	
	Deg. Celsius Deg. Fahrenheit	Unit = °C Unit = °F
Memory alarm limit value 	0 to 20 to 100 %	If the free memory of the measurement-data memory drops below the limit value, a memory alarm is triggered.
Version Online Vis. (setup only)	Version of the web server function for displaying process data with a web browser via the HTTP protocol (visualizations at operating level)	
	No online visualization Standard online visualization 336.xx.xx 461.xx.xx	Web server inactive Default version Old variant of online visualization New variant of online visualization Other versions may be available here.
Display protection (setup only)	Password to prevent displaying configuration data in the setup program. Without a password (default setting), the configuration is always displayed. If a password is set, and input incorrectly, the configuration is not displayed; however, it can be transferred from the setup program to the device and also read out from the device.	
	***** (enter password)	Password (max. 16 characters; case sensitive)
Setup quick info (setup only)	Enter text (max. 20 characters)	Brief description of the setup project The text is transferred to the device, stored there and displayed below "Device info".
Setup info (setup only)	Enter text (max. 500 characters)	Exhaustive description of the setup project The text is transferred to the device, stored there and displayed below "Device info".

Memory alarm limit value



CAUTION!

If the data are not read by the user in time:

There is a risk of data loss once the memory alarm has been triggered.

- Data is to be read out immediately.

7 Configuration


7.4 Display

This menu is used to implement the following settings:

- Screen settings
- Colors of the individual items of information in the visualizations
- General settings for the various visualizations

7.4.1 Start image and watermark (setup only)

Setup dialog box



Parameter

Parameter	Selection/settings	Description
Start image active	Yes (☒) , No (☐) Users can press the "..." button to import and export a start image.	The start image is active if "Yes" is selected. The image is displayed after power on during the initialization phase. Fixed size: 640 × 480 pixels
Watermark in diagram	Yes (☒) , No (☐) Users can press the "..." button to import and export a watermark.	If "Yes" is selected, a watermark that runs through the background is shown in the curve diagram. Maximum size: 100 × 200 pixels
Watermark history	Yes (☒) , No (☐) Users can press the "..." button to import and export a watermark.	If "Yes" is selected, a watermark that runs through the background is shown in the curve diagram of the history. Maximum size: 100 × 200 pixels

7.4.2 Screen

Device dialog box

Screen

10:02:30

Brightness	100
Screen switch-off	Inactive
Time	
Control signal	


Parameter

Parameter	Selection/settings	Description
Brightness	0 to 100 %	Screen brightness
Screen switch-off	The screen can be switched off (darkened) to save energy.	
	Inactive	The switch-off is not active.
	Time	If the screen is not touched for a period from 10 to 32767 seconds, the switch-off is activated and the screen turns dark.
	By control signal	The switch-off is activated by one of the digital signals (digital selector). A digital signal can be a digital input, a relay status, or a batch activation, for example.
Time	10 to 300 to 32767	Time in seconds for the screen switch-off
Control signal	No selection	No screen switch-off
	Digital selector	Signal (high active) for the screen switch-off when selecting the control signal

7 Configuration

7.4.3 Colors

Device dialog (excerpt)



Parameter

Parameter	Selection/settings	Description
Analog channel 1 to analog channel 6	Color ...	Color used to display the corresponding analog channel (graphically, numerically, and in text form).
Digital channel 1 to digital channel 6	Color ...	Color used to display the corresponding digital channel (graphically and in text form).
Analog curves background	Color ...	Background color for displaying the analog curves
Digital trace background	Color ...	Background color for displaying the digital traces
Alarm refer. curve	Color ...	Color used to display an analog channel when it leaves a tolerance band.
Alarm 1, Alarm 2	Color ...	Color used to mark the alarm in question.
Time stamp in diagram	Color ...	Color used to display the time information.
Grid lines in diagram	Color ...	Color in which the grid in the curve diagram is displayed.

7.4.4 General Information

Device dialog (excerpt)

Generally

10:08:52

Image after reset

Image after Home-Button

Display curve diagram

Yes

Display digital diagram

Yes

Display bargraph

Yes

Display text image

Yes

Display process screen

Yes

Display report

Yes

Display counter information

Yes

Parameter

Parameter	Selection/settings	Description
Image after reset:		
Last image before reset	Yes , No	If "Yes" is selected, the last active image before the reset (by rebooting or changing the configuration) is also displayed after the reset.
Image selection 	Curve diagram Select visualization.	Visualization after reset, if "Last image before reset" is not active. ⇒ chapter 5.4 "Visualization menu (display)", Page 46
Group selection	1 Select group.	Group whose channels are displayed in the selected visualization.
Image after Home-Button:		
Home button active	Yes , No	If "Yes" is selected, the device changes to a specific visualization after pressing the Home button.
Image selection 	Curve diagram Select visualization.	Visualization after pressing the Home button ⇒ chapter 5.4 "Visualization menu (display)", Page 46
Group selection	1 Select group.	Group whose channels are displayed in the selected visualization.
General information:		
Display curve diagram	Yes , No	"Yes" releases the "Curve diagram" visualization for selection by the user.
Display digital diagram	Yes , No	"Yes" releases the "Digital diagram" visualization for selection by the user.

7 Configuration

Parameter	Selection/settings	Description
Show bar graph	Yes , No	"Yes" releases the "Bar graph" visualization for selection by the user.
Show text image	Yes , No	"Yes" releases the "Text image" visualization for selection by the user.
Show process screen	Yes , No	"Yes" releases the "Process screen" visualization for selection by the user.
Show reports	Yes , No	"Yes" releases the "Reports" visualization for selection by the user.
Display counters/integrators	Yes , No	"Yes" releases the "Counters/Integrators" visualization for selection by the user.
Display batch	Yes , No	"Yes" releases the "Current batch" and "Completed batch" visualizations for selection by the user.
Input simulation 	Yes, No	If "Yes" is selected, all inputs and outputs of the device are ignored and pseudo data is displayed on the screen.
Show alarms	Yes , No	"No" suppresses displaying fault and alarm messages in the status and title bars.
Barcode -> Batch mask	Yes, No	If "Yes" is selected, the "Current batch" visualization is automatically shown when the corresponding barcode is scanned.
Thousand separator	Yes, No	If "Yes" is selected, a stroke will be used in certain visualizations as an identification marking for numbers above and including 1000. Example: 215'892,9
Lock touchscreen	Lock the touchscreen to prevent use. This does not switch off the screen.	
	No selection Digital selector	Not locked Signal (high active) with which the touchscreen (screen) is locked while the signal is active.
Width of auxiliary line	1 to 3	Width of the auxiliary lines in the curve diagram

Image after reset, Image after Home-Button:

Additional settings may be required for a visualization to be displayed by the device. For example, batches can only be displayed if they are appropriately configured by the user.

Input simulation



NOTE!

The inputs and outputs adopt an undefined status. This parameter should only be activated for test purposes and also only if no digital outputs are connected.

7.5 Analog inputs

The analog inputs (optional extra) are universal analog inputs for connecting various measuring probes. For example, the analog inputs are pooled into groups together with other analog signals via the "Groups" configuration and are available for further use via these groups.

Device dialog (excerpt)

Analog input 1		10:15:22
Channel designation	AI01	↑
Channel description	Analog input 01	
Sensor	Resistance-Thermometer 2L	≡
Temperature input		
Unit	°C	
Linearization	Pt100	↓
Resistance measuring range		
Measuring range-Start	-200.00 °C	
Measuring range-End	+850.00 °C	↓

✕
📄
✓

Parameter

Parameter	Selection/settings	Description
Channel designation	AI ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Analog input ... Use default text or enter other text.	Description (designation) with max. 21 characters (e.g. for curve diagram)
Sensor	Selection of measuring probe for the relevant analog input	
	Inactive	No sensor selected Deviating default setting for analog input 1 to 3 (see below)
	RTD temp. probe 2-w	RTD temperature probe in two-wire circuit
	RTD temp. probe 3-w	RTD temperature probe in three-wire circuit
	RTD temp. probe 4-w	RTD temperature probe in four-wire circuit
	Resistance/potentiometer 2-w	Resistor/potentiometer in two-wire circuit
	Resistance/potentiometer 3-w	Resistor/potentiometer in three-wire circuit
	Resistance/potentiometer 4-w	Resistor/potentiometer in four-wire circuit
	Resistance transmitter	Resistance transmitter
	Thermocouple	Thermocouple
	Voltage 0 to 70 mV	Voltage signal

7 Configuration

Parameter	Selection/settings	Description
	Voltage 0 to 1 V	Voltage signal
	Voltage -1 to +1 V	Voltage signal
	Voltage 0 to 10 V	Voltage signal
	Voltage -10 to +10 V	Voltage signal
	Current 0 to 20 mA	Current signal
	Current 4 to 20 mA	Default setting for analog input 1 to 3 Current signal
Temperature input	In the case of a voltage/current signal, resistance/potentiometer, or resistance transmitter, the measured value must be defined as a temperature to convert automatically when changing the temperature unit.	
	No	Measured value is not a temperature.
	Yes	Measured value is a temperature.
Unit	Measured value unit for voltage/current signal, resistance/potentiometer or resistance transmitter	
	% (Max. 5 characters)	The unit is displayed if the measured value is displayed in numerical form
Linearization 	Available options and default settings depend on the measuring sensor selected.	
	Linear	
	Pt50	IEC 751: 2008
	Pt100	IEC 751: 2008
	Pt500	IEC 751: 2008
	Pt1000	IEC 751: 2008
	Pt100 JIS	JIS 1604
	Pt50 GOST	GOST 6651-2009 A.2
	Pt100 GOST	GOST 6651-2009 A.2
	Cu50 GOST	GOST 6651-2009 A.3
	Cu100 GOST	GOST 6651-2009 A.3
	Ni100	DIN 43760:1987-09
	Ni100 GOST	GOST 6651-2009 A.5
	Fe-CuNi L	DIN 43710:1985-12
	Fe-CuNi J	DIN EN 60584-1:2014
	Cu_CuNi U	DIN 43710:1985-12
	Cu-CuNi T	DIN EN 60584-1:2014
	NiCr-Ni K	DIN EN 60584-1:2014
	NiCr-CuNi E	DIN EN 60584-1:2014
	NiCrSi-NiSi N	DIN EN 60584-1:2014
	Pt10Rh-Pt S	DIN EN 60584-1:2014
	Pt13Rh-Pt R	DIN EN 60584-1:2014
	Pt30Rh-Pt6Rh B	DIN EN 60584-1:2014
	W5Re-W26Re C	ASTM E230M-11
	W3Re-W25Re D	ASTM E1751M-09
	W5Re-W20Re A1	GOST R 8.585-2001
	Chromel®-Copel® L	GOST R 8.585-2001
	Chromel®-Alumel®	GOST R 8.585-2001
	Platinel II	

7 Configuration

Parameter	Selection/settings	Description
	Customer-specific 1 to 4	Customer-specific linearization using grid points (pairs of values) or 4th order polynomial
Resistance measuring range	Measuring range for resistance/potentiometer and for customer-specific linearization with RTD temperature probe 0 to 4000 Ω 0 to 400 Ω	
Measuring range start 	-99999 to +99999 (Default setting depends on sensor and linearization.)	Lower limit of measuring range (for voltage/current signal, resistance/potentiometer, or resistance transmitter) If the measured value is below the lower limit, "<<<<<" (out of range) is shown for a numerical display.
Measuring range end 	-99999 to +99999 (Default setting depends on sensor and linearization.)	Upper limit of measuring range (for voltage/current signal, resistor/potentiometer, or resistance transmitter) If the measured value is above the upper limit, ">>>>>" (out of range) is shown for a numerical display.
Scaling start 	-99999 to +99999 (Default setting depends on sensor and linearization.)	Lower limit of measuring range or display range (depending on sensor and linearization)
Scale end 	-99999 to +99999 (Default setting depends on sensor and linearization.)	Upper limit of measuring range or display range (depending on sensor and linearization)
Decimal places	Number of pre-decimal and decimal places for the numerical display of the measured value Even if the number of decimal places is fixed, the format is automatically changed if needed in order to display all digits before the decimal point.	
	Auto XXXXXp XXXXpX XXXpXX XXpXXX XpXXXX	Automatic No decimal place One decimal place Two decimal places Three decimal places Four decimal places
Offset 	-99999 to 0 to +99999	Correction value
Filter time constant 	0 s to 1 s to 100 s	Time constant for adjusting the digital input filter (0 s = filter off)
Compensation	Selection of cold junction (for thermocouple)	
	Internal Pt100 External constant	Internal Pt100 temperature probe Constant cold junction temperature
Ext. reference temperature	-30 to 0 to +85	Cold junction temperature (for thermocouple and constant cold junction temperature)

7 Configuration

Parameter	Selection/settings	Description
Resistance Ra or Ro 	0 Ω to 4000 Ω	For Resistance transmitter: Resistance Ra between sliding contact (S) and start (A), if the sliding contact is positioned at the start. For Resistance/potentiometer: Offset resistance Ro
Resistance Rs or Rx 	0 Ω to 1000 Ω to 4000 Ω	For Resistance transmitter: Resistance range Rs of sliding contact For Resistance/potentiometer: Shifting resistance range Rx
Resistance Re 	0 Ω to 4000 Ω	For Resistance transmitter: Resistance Re between sliding contact (S) and end (E), if the sliding contact is positioned at the end.
Probe break detection	For a "Thermocouple" type sensor, probe break detection can be disabled.	
	Yes	Detection is active.
	No	Detection is inactive.

Linearization

Linearization must be selected to match the sensor (measuring probe).

The predefined linearizations can be supplemented with **customer-specific linearization**.

⇒ chapter 9.11 "Customized linearization", Page 228

Measuring range

For customer-specific linearization, the values are identical to the settings at that point for the "Measuring range start" and "Measuring range end;" they cannot be changed here.

Scaling

In typical linearizations for **RTD temperature probes and thermocouples**, this parameter delimits the measuring range.

Example: Pt100, scaling 0 to 200 °C

The physical measuring range of the hardware from -200 to +850 °C is delimited. Only measured values in the range 0 to 200 °C are processed. The diagram and bar graph have a plottable range of 0 to 200 °C. The values are covered by automatic °C/°F conversion.

For **voltage and current signals** the measured value is scaled, taking the measuring range into account.

Example: Input 0 to 20 mA; measuring range start 5 mA; measuring range end 18 mA; scaling: -500 to +1000

From the measuring range 0 to 20 mA, only values in the range 5 to 18 mA are taken into account. The value range 5 to 18 mA is scaled to the range -500 to +1000. 5 mA corresponds to -500, and 18 mA corresponds to +1000. The range -500 to +1000 is used for the diagram, bar graph, and all further processing. The values are covered by the automatic °C/°F conversion if the measured value has been defined as a temperature ("Temperature input" parameter).

For **customer-specific linearization** the values initially reflect the local settings for "Measuring range start" and "Measuring range end;" the scaling range can be further delimited here.

Offset


To offset plant-specific deviations, the measured value can be corrected (offset) for each analog input (following linearization). A positive or negative form of the correction value is added to the measured value (entering a negative correction value reduces the measured value). Typical applications include compensating for the line resistance of a RTD temperature probe in a two-wire circuit.

Filter time constant

The filter time constant is used to adjust the digital input filter (2nd order filter). If the input signal changes suddenly, approx. 26 % of the change is recorded following a period that corresponds to the filter time constant (2 × filter time constants: approx. 59 %; 5 × filter time constants: approx. 96 %). A large filter time constant means: high attenuation of interference signals, slow reaction to the actual measured value display, low limit frequency (low-pass filter).

Resistance Ra or Ro, Rs or Rx, Re

The overall resistance $R_a + R_s + R_e$ (or $R_o + R_x$) must not exceed 4000 Ω .



7.5.1 Limit value monitoring

Limit value monitoring with one or two limit values (alarm 1, alarm 2) can be activated for each analog input. In out-of-limit cases, an alarm signal is activated. Depending on the configuration, an entry is made in the event list or additionally in the alarm list. In the latter case, the alarm/event text is displayed in the status bar (until another alarm occurs); the collective alarm is enabled, and the plotter trace may be displayed in a different color.

This limit value monitoring function is independent of the general limit value monitoring values (Configuration > Limit value monitoring) and available in addition to them.

7 Configuration

Device dialog box

Analog input 1
🔔 10:21:11

Alarm 1

Activation/Type
Maximum alarm

Alarm/Event list
Alarm/Event

Alarm-/Event list
Alarm 1 Analog input 01

Limit value
+0.0000 °C

Switching differential
+0.0000 °C

Alarm suppression
No selection

Alarm delay
0 s

Alarm 2

✕


📄

✓

Parameter

Parameter	Selection/settings	Description
Activation/Type 	Inactive Min. alarm Max. alarm	Limit value monitoring is inactive. Alarm signal is active if the value drops below the limit value. Alarm signal is active if the limit value is exceeded.
Alarm/Event list 	Inactive (signal only) Event Alarm/event	In out-of-limit cases, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Limit value 	-99999 to 0 to +99999	If the limit value is exceeded (max. alarm case) or the value drops below the limit (min. alarm case), an out-of-limit case exists.
Switching differential 	0 to 99999	The switching differential is used to suppress constant switching of the alarm signal in the event of fluctuations of the input signal around the limit value.
Alarm suppression 	No selection Digital selector	The selected digital signal (high-active) prevents the alarm signal being activated.
Alarm delay 	0 s to 32767 s	Delay time for alarm signal activation

Activation/type, limit value, switching differential



- | | | | |
|-----|----------------------------|---|------------------|
| (1) | Limit value for min. alarm | 1 | Alarm signal on |
| (2) | Limit value for max. alarm | 0 | Alarm signal off |
| (3) | Switching differential | | |

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

Alarm suppression, alarm delay

Alarm suppression and alarm delay prevent or delay entries being added to the event list and alarm list, activation of the collective alarm, the display in the status bar, and the color change (analog value, plotter trace).

Alarm delay

During an out-of-limit case, the alarm signal is only activated after the delay time has expired. If the limit value infringement no longer exists at that point, the time for the next limit value infringement restarts from zero.

Response in case of a fault

If the input signal returns an error value, the alarm signal is activated as long as limit value monitoring is enabled. For this to happen, a min. or max. alarm must be configured (the limit value is unimportant here). Alarm suppression is also taken into consideration in this case, but not the alarm delay.

7 Configuration

7.6 Analog outputs

The analog outputs (optional extra) can each be configured as current or voltage outputs (current signal, voltage signal) and are freely scalable.

Device dialog box

Analog output 1		🕒 10:24:35
Channel designation	AA01	
Channel description	Analog output 01	
Signal source	Analog input 1 ▾	
Output signal	Voltage 0-10 V ▾	
Scale start	+0.0000 °C	
Scale end	+100.00 °C	
Behaviour in the event of fault	Replacement value ▾	
Replacement value	+0.0000 V	



Parameter

Parameter	Selection/settings	Description
Channel designation	AO ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Analog output ... Use default text or enter other text.	Description (designation) with max. 21 characters
Signal source	Analog selector No selection	Analog signal that is issued via the analog output. In the event of "No selection" a voltage of 0 V is output.
Output signal	Physical output signal Voltage 0 to 10 V Current 0 to 20 mA Current 4 to 20 mA Voltage 10 to 0 V Current 20 to 0 mA Current 20 to 4 mA	Voltage signal Current signal Current signal Voltage signal, inverse Current signal, inverse Current signal, inverse
Scaling start 	-99999 to 0 to +99999	Start value of value range
Scale end 	-99999 to 100 to +99999	End value of value range

Parameter	Selection/settings	Description
Response in case of a fault 	Value of the output signal after deviation above or below the measuring range (out of range = o-o-r) The selection options "Defined low value" and "Defined high value" are only available for the output signals 4 to 20 mA and 20 to 4 mA.	
	Replacement value	Configurable value (parameter "Replacement value")
	Defined low value	Value for deviation below measured value/short-circuit according to NAMUR recommendation
	Defined high value	Value for deviation above measured value/probe break according to NAMUR recommendation
Replacement value	0 to 22 mA or 0 to 10 V (depending on output signal)	Value of the output signal in the event of deviation above or below the measuring range

Scaling start, scaling end

A value range is assigned to the physical output signal by specifying the zero point and end value (scaling). The default setting corresponds to a value range of 0 to 100%.

If, for example, a temperature with a value range from 150 °C to 500 °C is to be issued via an analog output with signal type 0 to 20 mA, the start value must be set to 150 (corresponding to 0 mA) and the end value to 500 (corresponding to 20 mA).

Response in case of a fault

Output value in the event of fault:

Signal type (parameter "Output signal")	Output value
Voltage 0 to 10 V	Replacement value (configurable)
Current 0 to 20 mA	Replacement value (configurable)
Current 4 to 20 mA	Replacement value (configurable) or Defined low value (1 mA) or Defined high value (22 mA)
Voltage 10 to 0 V	Replacement value (configurable)
Current 20 to 0 mA	Replacement value (configurable)
Current 20 to 4 mA	Replacement value (configurable) or Defined low value (1 mA) or Defined high value (22 mA)

This behavior also applies for probe/wire break or probe/conductor short-circuit. Error detection depends on the type of measuring probe (see technical data, measuring circuit monitoring).

⇒ chapter 11.1.1 "Analog inputs", Page 267

Limits according to NAMUR recommendation NE 43 for signal type 4 to 20 mA:

Measurement information M	3.8 to 20.5 mA
Failure information A for deviation below measured value/short-circuit ("NAMUR Low")	≤ 3.6 mA
Failure information A for deviation above measured value/probe break ("NAMUR High")	≥ 21 mA

7 Configuration

Behavior after power on


During the initialization phase of the device, the output signal assumes a value of 0 V or 0 mA depending on the configuration of the relevant analog output.

7.7 Digital inputs

The digital inputs (optional extra) are actuated with an external voltage DC 0/24 V or via a potential-free contact (auxiliary voltage in place).

The digital inputs are pooled into groups along with other digital signals in the "Groups" configuration and are then available for further use via these groups.

Device dialog box



Parameter

Parameter	Selection/settings	Description
Channel designation	DI ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Digital input ... Use default text or enter other text.	Description (designation) with max. 21 characters
Signal inversion	Inversion of the input signal	
	No Yes	The signal is not inverted. The signal is inverted.

7.7.1 Signal monitoring

Signal monitoring (alarm) can be activated for each digital input.

In alarm cases, an alarm signal is activated. Depending on the configuration, an entry is made in the event list or additionally in the alarm list. In the latter case, the alarm/event text is displayed in the status bar (until another alarm occurs); the collective alarm is enabled, and the plotter trace may be displayed in a different color.

7 Configuration

Device dialog box

Digital input 1

10:29:36

Channel designation	DI01	↑
Channel description	Digital input 01	
Signal inversion	No	↓
Alarm		
Activation	Active	↓
Alarm/Event list	Inactive (Signal only)	↓
Alarm at level	High(1)	↓
Alarm/Event text	Alarm Digital input 01	
Alarm delay	0 s	↓

✕

📄

✓

Parameter

Parameter	Selection/settings	Description
Activation	Inactive Active	Signal monitoring is inactive. Signal monitoring is active.
Alarm/Event list 📖	Inactive (signal only) Event Alarm/event	In the event of an alarm, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm active at	High (1) Low (0)	Alarm at high level (1) Alarm at low level (0)
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Alarm delay 📖	0 s to 32767 s	Delay time for alarm signal activation
Alarm suppression 📖	Digital selector No selection	The selected digital signal (high-active) prevents the alarm signal being activated.

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

Alarm delay

In the event of an alarm (parameter "Alarm active at"), the alarm signal is not activated until the delay time has expired. If the alarm case is left in the meantime, the timer restarts when a new alarm case occurs.

Alarm delay, alarm suppression

Alarm delay and alarm suppression delay or prevent entries being added to the event list and alarm list, activation of the collective alarm, and display in the status bar.

7 Configuration

7.8 Digital inputs/outputs

The digital inputs/outputs (optional extra) can be individually switched between input and output. The inputs are actuated with an external voltage DC 0/24 V or via a potential-free contact (auxiliary voltage in place). The outputs provide an output signal of DC 0/24 V.

As digital inputs, they are pooled into groups along with other digital signals in the "Groups" configuration and are then available for further use via these groups.

Device dialog box

Digital input/output 1

10:31:48

Function	Input
Channel designation	DIO01
Channel description	Digital inp./outp. 01
Signal source	
Signal inversion	No
Alarm	

Parameter

Parameter	Selection/settings	Description
Function	Input Output	Digital input Digital output
Channel designation	DIO ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Digital input/output ... Use default text or enter other text.	Description (designation) with max. 21 characters
Signal source (for output only)	Digital selector No selection	Digital signal output via the digital output. "No selection": the output signal corresponds to the "Low" state (0 V for non-inverted signals, 24 V for inverted signals).
Signal inversion	Inversion of the input or output signal No Yes	The signal is not inverted. The signal is inverted.

Behavior after power on

During the device's initialization phase, all connections are actuated as digital inputs, even if they were previously configured as digital outputs.

7.8.1 Signal monitoring

Signal monitoring (alarm) can be activated for each digital input/output.

Device dialog box

Digital input/output 1

10:32:59

Signal source	
Signal inversion	No
Alarm	
Activation	Active
Alarm/Event list	Inactive (Signal only)
Alarm at level	High(1)
Alarm/Event text	Alarm Digital input/output 01
Alarm delay	0 s
Alarm suppression	No selection

✕

📄

✓

Parameter

Parameter	Selection/settings	Description
Activation	Inactive Active	Signal monitoring is inactive. Signal monitoring is active.
Alarm/Event list 📖	Inactive (signal only) Event Alarm/event	In the event of an alarm, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm active at	High (1) Low (0)	Alarm at high level (1) Alarm at low level (0)
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Alarm delay 📖	0 s to 32767 s	Delay time for alarm signal activation
Alarm suppression 📖	Digital selector No selection	The selected digital signal (high-active) prevents the alarm signal being activated.

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

7 Configuration

Alarm delay

In the event of an alarm (parameter "Alarm active at"), the alarm signal is not activated until the delay time has expired. If the alarm case is left in the meantime, the timer restarts when a new alarm case occurs.

Alarm delay, alarm suppression

Alarm delay and alarm suppression delay or prevent entries being added to the event list and alarm list, activation of the collective alarm, and display in the status bar.

7.9 Relays

The device is equipped with a relay output (changeover contact).

Device dialog

Relay

10:49:58

Signal source	Digital input 1
Channel designation	REL01
Channel description	Relay output 01
Signal inversion	No




Parameter

Parameter	Selection/settings	Description
Signal source	Digital selector No selection	Digital signal for controlling the relay "No selection" means that the relay is in idle state.
Channel designation	REL 01 Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Relay output 01 Use default text or enter other text.	Description (designation) with max. 21 characters
Signal inversion	Inversion of the digital signal for controlling the relay	
	No	The signal is not inverted.
	Yes	The signal is inverted.

Behavior after power on

During the initialization phase of the device, the relay is in idle state.


7 Configuration

7.10 External analog inputs

The external analog inputs are analog signals that are transferred to the device via an interface from external systems. The external analog inputs can also be written by a barcode scanner (see chapter 11.4.2 "Texts and process values", Page 278).

The external analog inputs are pooled into groups along with other analog signals via the "Groups" configuration and are then available for further use via these groups.

Device dialog (excerpt)



Parameter

Parameter	Selection/settings	Description
Channel designation	eAI ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Ext. analog input ... Use default text or enter other text.	Description (designation) with max. 21 characters (e.g. for curve diagram)
Temperature	The parameter determines whether the transferred value (measured value) is evaluated as a temperature value, a temperature difference, or not as a temperature. The distinction between temperature value and temperature difference is significant for conversion from °C to °F.	
	None	The value is not a temperature.
	Temperature difference	The value is a temperature difference.
	Temperature value	The value is a temperature value.
Unit	% (Max. 5 characters)	The unit is displayed if the measured value is displayed in numerical form.

Parameter	Selection/settings	Description
Decimal places	Number of pre-decimal and decimal places for the numerical display of the input value Even if the number of decimal places is fixed, the format is automatically changed if needed in order to display all digits before the decimal point. Auto XXXXXp XXXXpX XXXpXX XXpXXX XpXXXX	Automatic No decimal place One decimal place Two decimal places Three decimal places Four decimal places
Start of display range	-99999 to 0 to +99999	Lower limit of display range
End of display range	-99999 to 100 to +99999	Upper limit of display range
Reset signal 	Digital selector No selection	The reset signal (high active) sets the analog input to a status of "no input signal".
Save using power off	No Yes	If "Yes", the current value is saved upon switch-off (power off) and is available again upon switch-on (power on).
Offset	-99999 to 0 to +99999	Correction value (correction of the display value by addition or subtraction)
Factor 	-999999999 to 1 to +999999999	Factor for evaluating the measured value

Reset signal

The device can monitor the connection to the Modbus master as a Modbus slave. If the connection is down (timeout from the master), a digital signal is activated (slave timeout ...). This signal can be used as a reset signal to set the input to a defined value.

Using the device (slave) to monitor the Modbus connection only makes sense if the external master writes to the input. If the external master only has read access to the input, this function has no meaning.

Factor

Using a factor makes it possible, for example, to reduce the measured value before further processing so that the displayed (and registered) value lies within the display range.

Since the display range ends at 99999, a measured value of 100000, for example, can be multiplied by a factor of 0.001 so that a value of 100 is displayed. The unit must be changed accordingly (e.g.: 100000 kWh = 100 MWh).

The value that was modified by the factor can also be corrected by an offset (correction value).

7.10.1 Limit value monitoring

Limit value monitoring with one or two limit values (alarm 1, alarm 2) can be activated for each external analog input. In out-of-limit cases, an alarm signal is activated. Depending on the configuration, an entry is made in the event list or additionally in the alarm list. In the latter case, the alarm/event text is displayed in the status bar (until another alarm occurs); the collective alarm is enabled, and the plotter trace may be displayed in a different color.

This limit value monitoring function is independent of the general limit value monitoring values (Configuration > Limit value monitoring) and available in addition to them.

7 Configuration

Device dialog box

External analog input 1

10:52:56

Alarm 1

Activation/Type

Maximum alarm

Alarm/Event list

Inactive (Signal only)

Alarm/Event text

Alarm1 ext. analog input 01

Limit value

+0.0000 %

Switching differential

+0.0000 %

Alarm suppression

No selection

Alarm delay


0 s

Alarm 2

Parameter

Parameter	Selection/settings	Description
Activation/Type 	Inactive Min. alarm Max. alarm	Limit value monitoring is inactive. Alarm signal is active if the value drops below the limit value. Alarm signal is active if the limit value is exceeded.
Alarm/Event list 	Inactive (signal only) Event Alarm/event	In out-of-limit cases, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Limit value 	-99999 to 0 to +99999	If the limit value is exceeded (max. alarm case) or the value drops below the limit (min. alarm case), an out-of-limit case exists.
Switching differential 	0 to 99999	The switching differential is used to suppress constant switching of the alarm signal in the event of fluctuations of the input signal around the limit value.
Alarm suppression 	Digital selector No selection	The selected digital signal (high-active) prevents the alarm signal being activated.
Alarm delay 	0 s to 32767 s	Delay time for alarm signal activation

Activation/type, limit value, switching differential



(1)	Limit value for min. alarm	1	Alarm signal on
(2)	Limit value for max. alarm	0	Alarm signal off
(3)	Switching differential		

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

Alarm suppression, alarm delay

Alarm suppression and alarm delay prevent or delay entries being added to the event list and alarm list, activation of the collective alarm, the display in the status bar, and the color change (analog value, plotter trace).

Alarm delay

During an out-of-limit case, the alarm signal is only activated after the delay time has expired. If the limit value infringement no longer exists at that point, the time for the next limit value infringement restarts from zero.

Response in case of a fault

If the input signal returns an error value, the alarm signal is activated as long as limit value monitoring is enabled. For this to happen, a min. or max. alarm must be configured (the limit value is unimportant here). Alarm suppression is also taken into consideration in this case, but not the alarm delay.

7 Configuration

7.11 External digital inputs

The external digital inputs are digital signals that are transferred to the device via an interface from external systems. The external digital inputs can also be written by a barcode scanner (see chapter 11.4.2 "Texts and process values", Page 278).

The external digital inputs are pooled into groups along with other digital signals in the "Groups" configuration and are then available for further use via these groups.

Device dialog box

External digital input 1

11:21:04

Channel designation	eDI01
Channel description	Ext. digital input 01
Signal inversion	No
Reset signal	No selection
Save during power off	No

Alarm

Parameter

Parameter	Selection/settings	Description
Channel designation	eDI ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Ext. digital input ... Use default text or enter other text.	Description (designation) with max. 21 characters (for PCA3000)
Signal inversion	Inversion of the input signal No Yes	The signal is not inverted. The signal is inverted.
Reset signal 	Digital selector No selection	The reset signal (high active) sets the digital input to a binary value of 0.
Save using power off	No Yes	If "Yes", the current value is saved upon switch-off (power off) and is available again upon switch-on (power on).

Reset signal

The device can monitor the connection to the Modbus master as a Modbus slave. If the connection is down (timeout from the master), a digital signal is activated (slave timeout ...). This signal can be used as a reset signal to set the input to a defined value.

Using the device (slave) to monitor the Modbus connection only makes sense if the external master writes to the input. If the external master only has read access to the input, this function has no meaning.

7.11.1 Signal monitoring

Signal monitoring (alarm) can be activated for each external digital input.

Device dialog box

External digital input 1

10:55:42

Reset signal	No selection	
Saving	No	
Alarm		
Activation	Active	
Alarm/Event list	Inactive (Signal only)	
Alarm at level	High (1)	
Alarm/Event text	Alarm ext. digital input 01	
Alarm delay	0 s	
Alarm suppression	No selection	

Parameter

Parameter	Selection/settings	Description
Activation	Inactive Active	Signal monitoring is inactive. Signal monitoring is active.
Alarm/Event list	Inactive (signal only) Event Alarm/event	In the event of an alarm, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm active at	High (1) Low (0)	Alarm at high level (1) Alarm at low level (0)
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Alarm delay	0 s to 32767 s	Delay time for alarm signal activation
Alarm suppression	Digital selector No selection	The selected digital signal (high-active) prevents the alarm signal being activated.

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

7 Configuration

Alarm delay

In the event of an alarm (parameter "Alarm active at"), the alarm signal is not activated until the delay time has expired. If the alarm case is left in the meantime, the timer restarts when a new alarm case occurs.

Alarm delay, alarm suppression


Alarm delay and alarm suppression delay or prevent entries being added to the event list and alarm list, activation of the collective alarm, and display in the status bar.

7.12 External text variables

The device can receive external texts (text variables) via an interface; the texts are used for batch reporting. The external text variables can also be written by a barcode scanner (see chapter 11.4.2 "Texts and process values", Page 278).

As of device version 04, these texts can also be used as event text for a group.

Device dialog box



External text variable 1		11:22:05
Save during power off	Yes	
Reset signal	No selection	
Event text for group	0	

Parameter

Parameter	Selection/settings	Description
Save using power off	No Yes	If "Yes", the current text is saved upon switch-off (power off) and is available again upon switch-on (power on).
Reset signal 	Digital selector No selection	The reset signal (high active) is used to delete the text in the text variables (blank text).
Event text for group	0 to ...	Number of the group The text is entered into the event list of the relevant group (for each text change). 0: The function is not active.

Reset signal

With the reset signal it is possible, for example, to delete texts displayed in a batch mask within a process screen. Please note as a general rule that the text must not be deleted until batch recording is complete, otherwise it will not be transferred to the batch report.



NOTE!

Separate Modbus addresses are available for external text variables and external event texts, which can be transferred as short texts or long texts.

If both Modbus addresses of a variable are used, the value of the variable is overwritten in each case. The user has to make sure that a variable is not overwritten unintentionally.

7 Configuration

7.13 Limit value monitoring functions

The general limit value monitoring functions can be used for different analog signals. Each limit value monitoring function delivers a status signal and an alarm signal:

- The status signal is active (1), if a max. alarm or a min. alarm was enabled and the limit value is exceeded or the value drops below the minimum (limit value infringement).
- The alarm signal depends on the status signal and the "Alarm for status" parameter.

Depending on the configuration, an entry is made in the event list or additionally in the alarm list. In the latter case, the alarm/event text is displayed in the status bar (until another alarm occurs); the collective alarm is enabled, and the plotter trace may be displayed in a different color.

General limit value monitoring is independent of limit value monitoring of the analog inputs and external analog inputs.

Device dialog box

Limit value monitoring 1

11:47:37

Channel designation	LM 01
Channel description	Lim. val. monitor. 01
Signal source	No selection
Behaviour in the event of fault	Signal active
Alarm at status	High(1)

Alarm

Parameter

Parameter	Selection/settings	Description
Channel designation	LM ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Limit value monitor. ... Use default text or enter other text.	Description (designation) with max. 21 characters
Alarm for status	This setting decides whether the alarm signal is active for active or inactive limit value infringement.	
	High (1)	Alarm signal is active for a high level of the status signal (limit value infringement).
	Low (0)	Alarm signal is active for a low level of the status signal (no limit value infringement).
Signal source	Analog selector No selection	Input signal of limit value monitoring (signal to be monitored).

Parameter	Selection/settings	Description
Response in case of a fault	Behavior of the status signal if the input signal delivers an error value.	
	Signal inactive	Status signal is inactive.
	Signal active	Status signal is active.
	Signal unchanged	Status signal keeps the state it had before the fault.

7.13.1 Alarm

Device dialog box

Limit value monitoring 1
11:48:53

Alarm at status	High(1)	↑
Alarm		
Activation/Type	Maximum alarm	↓
Alarm/Event list	Inactive (Signal only)	↓
Alarm/Event text	Alarm limit value monitoring 01	
Limit value	+0.0000	≡
Switching differential	+0.0000	
Alarm suppression	No selection	↓
Alarm delay	0 s	↓

✕
📄
✓


Parameter

Parameter	Selection/settings	Description
Activation/Type 	Inactive Min. alarm Max. alarm	Limit value monitoring is inactive. Status signal is active if the value drops below the limit value. Status signal is active if the limit value is exceeded.
Alarm/Event list 	Inactive (signal only) Event Alarm/event	In out-of-limit cases, only the status signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Limit value 	-99999 to 0 to +99999	If the limit value is exceeded (max. alarm case) or the value drops below the limit (min. alarm case), an out-of-limit case exists.

7 Configuration

Parameter	Selection/settings	Description
Switching differential 	0 to 99999	The switching differential is used to suppress constant switching of the status signal in the event of fluctuations of the input signal around the limit value.
Alarm suppression 	Digital selector No selection	The selected digital signal (high-active) prevents the status signal being activated.
Alarm delay 	0 s to 32767 s	Delay time for status signal activation

Activation/type, limit value, switching differential



(1)	Limit value for min. alarm	1	Status signal on
(2)	Limit value for max. alarm	0	Status signal off
(3)	Switching differential		

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

Alarm suppression, alarm delay

Alarm delay and alarm suppression delay or prevent entries being added to the event list and alarm list, activation of the collective alarm, and display in the status bar.

Alarm delay

During an out-of-limit case, the status signal is only activated after the delay time has expired. If the limit value infringement no longer exists at that point, the time for the next limit value infringement restarts from zero.

7.14 Counters/integrators

The counters/integrators can be configured as counters, integrators, operating time counters, high-speed counters, or for determining the total flow (volume):

- Counters are used to count digital signals.
- Integrators are used to integrate analog inputs.
- Operating time counters are used to measure the length of time that digital signals have been active.
- A high-speed counter can be used to record counter pulses up to 12.5 kHz (via certain optional inputs; see technical data).
- The total flow is determined by integrating the volume flow (see chapter 7.15 "Flow", Page 143).

Stored counter and integrator statuses can be evaluated with the PCA3000 evaluation software on the PC.

7.14.1 General settings

Device dialog box

General settings		11:51:33
Synchronization time	00:00:00	
Start daily	00:00:00	
End daily	00:00:00	
Period	3 min	
Weekday	Monday	
Reset signal	Digital input 7	
Integrator behaviour on fault	Stop calculation	

Parameter

Parameter	Selection/settings	Description
Synchronization time 	00:00:00 to 23:59:59	Synchronization time for completion and restart of counters or integrators for which the "Type" parameter is configured as "Periodical", "Daily", or "Weekly".
Daily start	00:00:00 to 23:59:59	Start time of counters or integrators whose "Type" parameters are configured as "Daily from/to".
Daily end	00:00:00 to 23:59:59	End time of counters or integrators whose "Type" parameters are configured as "Daily from/to".
Period	1 min, 2 min, 3 min , 4 min, 5 min, 10 min, 15 min, 30 min, 1 h, 2 h, 3 h, 4 h, 6 h, 8 h, 12 h	Pulse period of counters or integrators for which the "Type" parameter is configured as "Periodical".

7 Configuration

Parameter	Selection/settings	Description
Day of the week	Sunday, Monday , Tuesday, Wednesday, Thursday, Friday, Saturday	Day of the week on which the counters and integrators for which the "Type" parameter is configured as "Weekly", are saved at the synchronization time and restarted with the start value 0.
Reset signal 	Digital selector No selection	The reset signal is used to set the counter and integrator statuses to 0 (independent of other parameters).
Integr. behavior in the event of fault	Behavior in the event of fault when integrating a measured value or determining the total flow	
	Interrupt calculation	Calculation is interrupted while the fault exists.
	Discard calculation	The calculation results are discarded.

Synchronization time

The synchronization time is used for completion and restart for daily, weekly, and periodical counters and integrators. When the synchronization time is reached, all statuses are saved and the function is restarted with the start value 0. With the weekly type, the "Day of the week" parameter also plays a role.

The synchronization time will be explained in more detail below, using the example of a periodical counter. The completion and restart is performed at the next point in time occurring in the time grid – depending on the synchronization time and period.

Example:

Period = 2 hours

Synchronization time = 11:30:00

Power on = 09:11:00 1st period from 09:11 to 09:30 = 19 minutes

2nd period from 09:30 to 11:30 = 2 hours

3rd period from 11:30 to 13:30 = 2 hours

etc.

Reset signal

The current statuses are not saved when the counters and integrator statuses are reset. This function can be used when setting up a plant (test run) or as a so-called "Clear switch", for example.



NOTE!

For each counter/integrator, the general reset signal can be overwritten by an individual reset signal (see the following chapter "Specific settings").

Individual settings



NOTE!

Instead of the general settings for the synchronization time, daily start, daily end, period, and day of the week, it is also possible to use individual settings for each counter/integrator (see the following chapter "Specific settings").

7.14.2 Specific settings

Device dialog (excerpt) – counter/integrator 1 ...

Counter/Integrator 1		11:53:21
Function	Counter	▲
Save (for analysis)	Yes	▼
Type	Daily	▼
External control signal		≡
Additional saving	Inactive	▼
Signal source	No selection	▼
Factor	+1000.0	
Time base		
Threshold		▼





Parameter

Parameter	Selection/settings	Description
Function	Operating mode of the counter/integrator	
	Inactive	Counter/integrator is switched off.
	Counter	Counter for the pulses of a digital signal
	Integrator	Integration of an analog signal
	Flow ... (total)	Integration of volume flow (determining the total flow)
	Operating time	Determination of the length of time that a digital signal is active.
Save (for evaluation)	High-speed counter ...	Counting of the pulses of a digital signal up to 12.5 kHz; only available if the necessary digital input/output is in place.
	The result (status of the counter/integrator) can be saved in order to evaluate it with the PCA3000 evaluation software.	
	No	Event is not saved.
	Yes	Event is saved.

7 Configuration

Parameter	Selection/settings	Description
Type 	This setting decides when the current status of the counter/integrator is saved. Depending on the specific setting (Yes - No), the parameters from the previous chapter "General settings" must also be taken into consideration.	
	Periodically	Completion and restart will be determined by the "Period" and "Synch. time" parameters.
	External	Completion and restart will be determined by an external control signal. The counter/integrator functions when the signal is set (High).
	Daily	The counter/integrator is counted/integrated for a day (24 hours). Completion and restart will be determined by the "Synch. time" parameter.
	Weekly	The counter/integrator is counted/integrated for a week. Completion and restart will be determined by the "Day of the week" and "Synch. time" parameters.
	Monthly	The counter/integrator is counted/integrated for a month. Completion and restart are performed on the first day of the month at 00:00.
	Annual	The counter/integrator is counted/integrated for a year. Completion and restart are performed on the first day of the year at 00:00.
	Total	The counter/integrator is counted/integrated for the entire duration of the current configuration.
Ext. control signal	Daily from/to	The counter/integrator is counted/integrated for a period within one day. Restart and completion are determined by the "Daily start" and "Daily end" parameters.
	Digital selector No selection	External control signal (high active) for completion and restart of the counter/integrator (for the "External" type). The counter/integrator functions when the signal is active.

Parameter	Selection/settings	Description
Additional storage 	The parameter decides whether the current statuses are to be saved additionally (in addition to the save operation resulting from the "Type" parameter). The current statuses are saved but not reset. Depending on the specific setting (Yes - No), the parameters from the previous chapter "General settings" must also be taken into consideration. The parameter is only active for "Save (for evaluation)" = Yes.	
	Inactive Periodically Daily Weekly Monthly Annual	No additional storage Completion and restart will be determined by the "Period" and "Synch. time" parameters. The counter/integrator is counted/integrated for a day (24 hours). Completion and restart will be determined by the "Synch. time" parameter. The counter/integrator is counted/integrated for a week. Completion and restart will be determined by the "Day of the week" and "Synch. time" parameters. The counter/integrator is counted/integrated for a month. Completion and restart are performed on the first day of the month at 00:00. The counter/integrator is counted/integrated for a year. Completion and restart are performed on the first day of the year at 00:00.
Signal source	Analog selector and digital selector No selection	Input signal to be counted (digital signal) or integrated (analog signal). For the "Flow (total)" function, the flow process value is used as the signal source. For the "High-speed counter" function, digital input/output 1 is used as the signal source.
Factor	"Counter" and "High-speed counter" function: The counter status is incremented by the factor value for each digital signal pulse. A negative value can be used to form a backwards counter. "Integrator" function: The current measured value of the analog or integer signal is multiplied by the factor and added to the result.	
	-99999 to 1 to +99999	Value or factor

7 Configuration

Parameter	Selection/settings	Description
Time base	"Integrator" function: The current measured value is integrated corresponding to the selected time base, taking the factor into consideration:	
	Second	The measured value is divided by 1 and added up every second.
	Minute	The measured value is divided by 60 and added up every second.
	Hour	The measured value is divided by 3600 and added up every second.
	Day	The measured value is divided by 86400 and added up every second.
	"Operating time" function: The time base specifies the unit in which the operation time is displayed:	
Threshold value	Second	Display in seconds
	Minute	Display in minutes
	Hour	Display in hours
	Day	Display in days
	"Integrator" function: Integration only takes place if the current measured value is greater than the threshold value. The time base and factor are not included in the threshold comparison.	
Reset signal	-999999999 to 0 to +999999999	Threshold value
	The reset signal is used to set the counter and integrator statuses to 0 (independently of other parameters). The current status is not saved in the process. This reset signal is available in addition to the reset signal described in the previous chapter "General settings".	
	Digital selector	The signal (high active) can be selected from the list of digital signals.
Individual settings	No selection	No signal selected.
	Instead of the general settings for the synchronization time, daily start, daily end, period, and day of the week, it is also possible to use individual settings for each counter/integrator.	
	Not activated (no checkmark) Activated (checkmark)	The general settings are used. The individual settings are used (for "Parameter" and "Selection/settings": see the previous chapter "General settings").

Type; Additional storage

Selection "annual" or "total": the counter/integrator status is temporarily stored at the end of each month, but not reset to 0. This means that the current status is always available for evaluation with the PCA3000 evaluation software at this point in time.

Device dialog – counter/integrator 1 ... – display

Counter/Integrator 1
11:56:11

Display

Channel designation	C/I01
Channel description	Counter/Integrator 01
Volume unit	
Volume factor	
Unit	hh
Decimal place	XXXXpX
Start display range	+0.000000000 l
End display range	+100000000.0 l

X
[]
✓

Parameter

Parameter	Selection/settings	Description
Channel designation	C/I ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Counter/integrator ... Use default text or enter other text.	Description (designation) with max. 21 characters (e.g. for curve diagram)
Volume unit	Unit in which the total flow is shown. The unit is displayed wherever the status is displayed in numerical form.	
	l m ³ gal hl By the volume factor	Liters Cubic meters Gallons Hectoliters The total flow (in liters) is multiplied by the volume factor and is displayed in the freely selectable unit.
Volume factor	Conversion factor for evaluating the total flow (for the volume unit "Volume factor") -99999 to 1 to 99999	
		Factor
Unit	5 characters ()	Unit in which the counter or integrator status is displayed. This is also used if "By the volume factor" is configured as the volume unit. The unit is displayed wherever the status is displayed in numerical form.

7 Configuration

Parameter	Selection/settings	Description
Decimal places	Pre-decimal and decimal places for the numerical display of the counter or integrator status Even if the number of decimal places is fixed, the format is automatically changed if needed in order to display all digits before the decimal point.	
	Auto XXXXXp XXXXpX XXXpXX XXpXXX XpXXXX	Automatic No decimal place One decimal place Two decimal places Three decimal places Four decimal places
Start of display range	-999999999 to 0 to 999999999	Lower limit of the bar graph display
End of display range	-999999999 to 100000000 to 999999999	Upper limit of the bar graph display The counter or integrator status is displayed using a maximum of 9 digits. If this is exceeded, the status restarts from 0.

Device dialog – counter/integrator 1 ... – limit value monitoring function (alarm 1, alarm 2)

Limit value monitoring with one or two limit values (alarm 1, alarm 2) can be activated for each counter/integrator. In out-of-limit cases, an alarm signal is activated. Depending on the configuration, an entry is made in the event list or additionally in the alarm list. In the latter case, the alarm/event text is displayed in the status bar (until another alarm occurs); the collective alarm is enabled, and the plotter trace may be displayed in a different color.

Counter/Integrator 1

11:58:17

Alarm 1

Activation/Type

Maximum alarm

Alarm/Event list

Inactive (Signal only)

Alarm/Event text

Alarm 1 Counter/Integrator 1

Limit value

+0.000000000 hh

Switching differential

+0.000000000 hh

Alarm suppression

No selection

Alarm delay

0 s

Alarm 2

✕

📄

✓

Parameter

Parameter	Selection/settings	Description
Activation/Type 	Inactive Min. alarm Max. alarm	Limit value monitoring is inactive. Alarm signal is active if the value drops below the limit value. Alarm signal is active if the limit value is exceeded.
Alarm/Event list 	Inactive (signal only) Event Alarm/event	In out-of-limit cases, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Limit value 	-999999999 to 0 to +999999999	If the limit value is exceeded (max. alarm case) or the value drops below the limit (min. alarm case), an out-of-limit case exists.
Switching differential 	-999999999 to 0 to +999999999	The switching differential is used to suppress constant switching of the alarm signal in the event of fluctuations of the current counter status or integrator value around the limit value.

7 Configuration

Parameter	Selection/settings	Description
Alarm suppression 	No selection Digital selector	The selected digital signal (high-active) prevents the alarm signal being activated.
Alarm delay 	0 s to 32767 s	Delay time for alarm signal activation

7.15 Flow

Two methods are available for flow measurement (volume flow, volume per unit of time): computation based on a digital signal (signal type "Digital", e.g., rotary pulses of a paddlewheel) and the evaluation of an analog signal (signal type "Analog signal").



NOTE!

For the "Digital" signal type, the signal must be fed in at a high-speed input (optional extra, see technical data). The minimum frequency is 1 Hz, the maximum frequency is 12.5 kHz. If the frequency is < 1 Hz, the flow value is set to 0.

Device dialog (excerpt) – flow 1 ...

Flow 1		11:32:29
Signal type	Digital (Input/Output 01)	^
Channel designation	Flo01	≡
Channel description	Flow 01	
Analog signal		
Unit		
Conversion -/K-factor	+1.0000 1/l	
⚙ Flow output		
Unit	l/sec	↓
Factor for customer-specif unit		

Parameter

Parameter	Selection/settings	Description
Signal type 	Inactive	Flow measurement is inactive.
	Digital (...)	Evaluation of rotary pulses from a paddlewheel sensor
	Analog signal	Evaluation of an analog input signal
Channel designation	FI ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Flow ... Use default text or enter other text.	Description (designation) with max. 21 characters (e.g. for curve diagram)
Analog signal	Analog selector No selection	Analog signal for determining the flow (only for signal type "Analog signal")

7 Configuration

Parameter	Selection/settings	Description
Unit 	Conversion factor for evaluating the measured value (only for the signal type "Analog signal") The units stated in brackets are used in the device info.	
	l/s (l/s) l/min (l/m) l/h (l/h) m ³ /min (m ³ /m) m ³ /h (m ³ /h) US.gal/s (U.g/s) US.gal/min (U.g/m) US.gal/h (U.g/h) Customer-specific Imp.gal/s (l.g/s) Imp.gal/min (l.g/m) Imp.gal/h (l.g/h)	Unit (conversion factor): Liters per second (1) Liters per minute (60) Liters per hour (3600) Cubic meters per minute (0.06) Cubic meters per hour (3.6) US gallon (US liquid gallon): Gallons per second (1/3.7854 = 0.264173) Gallons per minute (15.8504) Gallons per hour (951.0223) Imperial (British) gallon: Gallons per second (1/4.5461 = 0.219969) Gallons per minute (13.1982) Gallons per hour (791.8876)
Conversion/K-factor	-99999 to 1 to +99999	Factor (pulses per liter) for evaluating the measured value (only for signal type "Digital ...")
Output		
Unit	Selector (see above) l/s	Unit in which the flow value is displayed.
Customer-specific factor	-99999 to 1 to +99999	Factor for evaluating the measured value (only for "customer-specific" unit)
Customer-specific unit	l/h Use default text or enter other text.	Flow value unit (only for "customer-specific" unit)
Decimal places	Number of pre-decimal and decimal places for the numerical display of the measured value Even if the number of decimal places is fixed, the format is automatically changed if needed in order to display all digits before the decimal point.	
	Auto XXXXXp XXXXpX XXXpXX XXpXXX XpXXXX	Automatic No decimal place One decimal place Two decimal places Three decimal places Four decimal places
Start of display range	-99999 to 0 to +99999	Lower limit of display range
End of display range	-99999 to +100 to +99999	Upper limit of display range

Parameter	Selection/settings	Description
Low flow suppression	-99999 to 0 to +99999	Limit value for suppressing low flow values (any prefix sign) A flow value that is below this limit value is no longer acquired.

Signal type, unit

In addition to standardization at the analog input, for the "Analog signal" signal type rescaling can occur by selecting the unit and using the associated conversion factor. If rescaling is not needed, the unit must be set to l/s (1 liter per second) (default setting).

For example: The analog input is used to measure the flow velocity in meters per second (m/s). By selecting the unit, the cross section is taken into account and the time unit is adapted if required. The unit l/s (factor = 1) means that a flow velocity of 1 m/s corresponds to a flow of 1 l/s.



NOTE!

Signal type "Digital": The input signal is not monitored. In the event of a fault, if the input signal does not deliver any pulses, a value of 0 is determined as the flow. If monitoring is required, a min. alarm with a suitable limit value needs to be configured.

Signal type "Analog signal": In the event of a fault (sensor error or no input signal), the flow value is set to 0. If monitoring is required, a min. alarm with a suitable limit value needs to be configured.

7.15.1 Limit value monitoring

Limit value monitoring with one or two limit values (alarm 1, alarm 2) can be activated for flow measurement.

In out-of-limit cases, an alarm signal is activated. Depending on the configuration, an entry is made in the event list or additionally in the alarm list. In the latter case, the alarm/event text is displayed in the status bar (until another alarm occurs); the collective alarm is enabled, and the plotter trace may be displayed in a different color.

This limit value monitoring function is independent of the general limit value monitoring values (Configuration > Limit value monitoring) and available in addition to them.

Device dialog box

Flow

13:16:28

Alarm 1

Activation/Type

Maximum alarm

Alarm/Event list

Inactive (Signal only)

Alarm/Event text

Alarm 1 flow

Limit value

+0.0000 l/sec

Switching differential

+0.0000 l/sec

Alarm suppression

No selection

Alarm delay

0 s

Alarm 2

✕


✓

7 Configuration

Parameter

Parameter	Selection/settings	Description
Activation/Type 	Inactive Min. alarm Max. alarm	Limit value monitoring is inactive. Alarm signal is active if the value drops below the limit value. Alarm signal is active if the limit value is exceeded.
Alarm/Event list 	Inactive (signal only) Event Alarm/event	In out-of-limit cases, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Limit value 	-99999 to 0 to +99999 l/s	If the limit value is exceeded (max. alarm case) or the value drops below the limit (min. alarm case), an out-of-limit case exists.
Switching differential 	0 to 99999 l/s	The switching differential is used to suppress constant switching of the alarm signal in the event of fluctuations of the input signal around the limit value.
Alarm suppression 	Digital selector No selection	The selected digital signal (high-active) prevents the alarm signal being activated.
Alarm delay 	0 s to 32767 s	Delay time for alarm signal activation

Activation/type, limit value, switching differential



(1)	Limit value for min. alarm	1	Alarm signal on
(2)	Limit value for max. alarm	0	Alarm signal off
(3)	Switching differential		

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

Alarm suppression, alarm delay

Alarm suppression and alarm delay prevent or delay entries being added to the event list and alarm list, activation of the collective alarm, the display in the status bar, and the color change (analog value, plotter trace).

Alarm delay

During an out-of-limit case, the alarm signal is only activated after the delay time has expired. If the limit value infringement no longer exists at that point, the time for the next limit value infringement restarts from zero.

Response in case of a fault

If the input signal returns an error value, the alarm signal is activated as long as limit value monitoring is enabled. For this to happen, a min. or max. alarm must be configured (the limit value is unimportant here). Alarm suppression is also taken into consideration in this case, but not the alarm delay.

7 Configuration

7.16 Math

The optional math function (extra code 260 "Math/Logic") supports formulas which can be freely used for mathematical calculations (analog values).

In addition, functions for calculating the differential, ratio, and relative humidity are also provided. In this case, two analog values (variables a and b), for example, the measured values of analog input 1 and 2 are linked to each other. The dry-bulb temperature and the wet-bulb temperature are required for calculating the relative humidity and should be determined with a psychrometric humidity sensor.

There is also a function for calculating a floating average.

The results are available in the analog selector. If the function is not active, the math value = 0.

A digital signal (0/1) is also derived from the results in each case. This is 0 when the result is a valid value.

Activating the function

On the device, the math function is only available when activated. To do so, the extra code "Math/Logic" must first be activated in the setup program using an activation code (Setup program: Online parameters > Enabling of extra codes).

The math function is available in the setup program after enabling the "Math/Logic" option (Configuration: Basic device > Math/Logic).

Device dialog (excerpt)

Mathematics 1		09:55:59
Function	Formula	^
Channel name	Mat01	
Channel description	Mathematics 01	
Temperature	None	≡
Unit	%	
Start display range	+0.0000 %	
End display range	+100.00 %	
Comma format	XXXXpX	+
Behaviour in the event of fault	Output error value	+



Parameter

Parameter	Selection/settings	Description
Function 	Without function Formula Differential (a-b) Ratio (a/b) Humidity (a;b) Floating average (a;t)	Function is switched off. Mathematical links with freely selectable variables and operators Differential of variable a and variable b Ratio of variable a to variable b Calculation of relative humidity Variable a: Dry-bulb temperature Variable b: Wet-bulb temperature Floating average of variable a (sampling interval 1 s)
Channel designation	Mat ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Math ... Use default text or enter other text.	Description (designation) with max. 21 characters (e.g. for curve diagram)
Temperature	None Temperature difference Temperature value	The math result is displayed in the entered unit The math result is a temperature difference and is shown in °C or °F (depending on the device settings). The math result is a temperature value and is shown in °C or °F (depending on the device settings).
Unit	5 characters (%)	Unit in which the math result (analog value) is displayed.
Start of display range	-99999 to 0 to +99999	Lower limit of display range for graphical display
End of display range	-99999 to 100 to +99999	Upper limit of display range for graphical display
Decimal places	Number of pre-decimal and decimal places for the numerical display of the math result Even if the number of decimal places is fixed, the format is automatically changed if needed in order to display all digits before the decimal point. Auto XXXXXp XXXXpX XXXpXX XXpXXX XpXXXX	Automatic No decimal place One decimal place Two decimal places Three decimal places Four decimal places
Response in case of a fault	Behavior if the math function does not produce a valid result due to an invalid input value. Output error value Output replacement value	 The math error value 5.0E+37 is output. The replacement value is output.
Replacement value	-99999 to 0 to +99999	Replacement value for output in the event of a fault.
Time const. for average value (min)	1 to 9999	Time constant in minutes for calculating the floating average

7 Configuration

Parameter	Selection/settings	Description
Variable a	Analog selector	Analog signal a (for calculating the differential, ratio, and humidity, and determining the floating average)
Variable b	Analog selector	Analog signal b (for calculating the differential, ratio, and humidity)
Save using power off	No Yes	Only if function = formula: If "Yes", the current value is saved upon switch-off (power off) and is available again upon switch-on (power on).

Function

The formula is created with the setup program. The differential, ratio, humidity, and floating average functions are also available; they can be used individually in the formula.

If the "Formula" function is selected although no formula has been stored, an error value is output (display "---").

Setup dialog box

Parameter

Parameter	Selection/settings	Description
Formula as text 		View with the formula created using the Formula Editor The formula can also be edited in this field.

All other parameters and their settings are identical to the configuration on the device.

Formula as text, Formula Editor

Pressing the "Formula Editor" button opens an editor that can be used to create formulas by selecting variables and operators (max. 600 ASCII characters). Formulas can be entered freely in line with standard mathematical rules. Any number of spaces may be used within the formula symbol string. Spaces are not admissible in function designations, names of variables, or constants.



NOTE!

The trigonometric functions (SIN, COS, and TAN operators) use degrees (360).

Error handling

The following circumstances may arise:

Process value of math function	Configuration "Behavior in the event of fault"	Initial value of math function	Binary value of math function
None (math function inactive)	Any	3.0E+37	0 (FALSE)
No error value	Any	Value of math function	0 (FALSE)
Error value	Output error value	5.0E+37	1 (FALSE)
Error value	Output replacement value	Replacement value	1 (FALSE)

Status after change of configuration

Modified parameters are incorporated immediately.

Behavior after power on

If the "Save using power off" function is not active, all math values are set to 3.0E+37 and the calculation is restarted.

7.16.1 Limit value monitoring

Limit value monitoring with one or two limit values (alarm 1, alarm 2) can be activated for the results. In out-of-limit cases, an alarm signal is activated. Depending on the configuration, an entry is made in the event list or additionally in the alarm list. In the latter case, the alarm/event text is displayed in the status bar (until another alarm occurs); the collective alarm is enabled, and the plotter trace may be displayed in a different color.

This limit value monitoring function is independent of the general limit value monitoring values (Configuration > Limit value monitoring) and available in addition to them.

7 Configuration

Device dialog box

Mathematics 1

13:34:43

Alarm 1

Activation/Type

Maximum alarm

Alarm/Event list

Inactive (Signal only)

Alarm/Event text

Alarm 1 Mathematics 1

Limit value

+0.0000 %

Switching differential

+0.0000 %

Alarm suppression

No selection

Alarm delay


0 s

Alarm 2

Parameter

Parameter	Selection/settings	Description
Activation/Type 	Inactive Min. alarm Max. alarm	Limit value monitoring is inactive. Alarm signal is active if the value drops below the limit value. Alarm signal is active if the limit value is exceeded.
Alarm/Event list 	Inactive (signal only) Event Alarm/event	In out-of-limit cases, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Limit value 	-99999 to 0 to +99999	If the limit value is exceeded (max. alarm case) or the value drops below the limit (min. alarm case), an out-of-limit case exists.
Switching differential 	0 to 99999	The switching differential is used to suppress constant switching of the alarm signal in the event of fluctuations of the input signal around the limit value.
Alarm suppression 	No selection Digital selector	The selected digital signal (high-active) prevents the alarm signal being activated.
Alarm delay 	0 s to 32767 s	Delay time for alarm signal activation

Activation/type, limit value, switching differential



(1)	Limit value for min. alarm	1	Alarm signal on
(2)	Limit value for max. alarm	0	Alarm signal off
(3)	Switching differential		

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

Alarm suppression, alarm delay

Alarm suppression and alarm delay prevent or delay entries being added to the event list and alarm list, activation of the collective alarm, the display in the status bar, and the color change (analog value, plotter trace).

Alarm delay

During an out-of-limit case, the alarm signal is only activated after the delay time has expired. If the limit value infringement no longer exists at that point, the time for the next limit value infringement restarts from zero.

Response in case of a fault

If the input signal returns an error value, the alarm signal is activated as long as limit value monitoring is enabled. For this to happen, a min. or max. alarm must be configured (the limit value is unimportant here). Alarm suppression is also taken into consideration in this case, but not the alarm delay.

7 Configuration

7.17 Logic

The optional logic function (extra code 260 "Math/Logic") supports formulas which can be freely used for logical operations (binary values).


The results are available in the digital selector. If the function is not active, the logical value = 0.

Activating the function

On the device, the Logic function is only available when activated. To do so, the extra code "Math/Logic" must first be activated in the setup program using an activation code (Setup program: Online parameters > Enabling of extra codes).

The Logic function is available in the setup program after enabling the "Math/Logic" option (Configuration: Basic device > Math/Logic).


Device dialog box



Parameter

Parameter	Selection/settings	Description
Function 	Without function Formula	Function is switched off. Logical links with freely selectable variables and operators The formula is created with the setup program.
Channel designation	Log ... Use default text or enter other text.	Name (abbreviation) with max. 5 characters that is used in the visualizations.
Channel description	Logic ... Use default text or enter other text.	Description (designation) with max. 21 characters
Save using power off	No Yes	If "Yes", the current value is saved upon switch-off (power off) and is available again upon switch-on (power on).

Setup dialog box



Parameter

Parameter	Selection/settings	Description
Formula as text 		View of the formula created with the Formula Editor (max. 600 ASCII characters) The formula can also be edited in this field.

All other parameters and their settings are identical to the configuration on the device.

Formula as text, Formula Editor

Pressing the "Formula Editor" button opens an editor that can be used to create formulas by selecting variables and operators (max. 600 ASCII characters). Formulas can be entered freely in line with standard Boolean rules. Any number of spaces may be used within the formula symbol string. Spaces are not admissible in function designations, names of variables, or constants.

Status after change of configuration

Modified parameters are incorporated immediately.

Behavior after power on

If the "Save using power off" function is not active, all logic values are set to 0 and the calculation is re-started.

7.17.1 Signal monitoring

Signal monitoring (alarm) can be activated for the results.

7 Configuration

In alarm cases, an alarm signal is activated. Depending on the configuration, an entry is made in the event list or additionally in the alarm list. In the latter case, the alarm/event text is displayed in the status bar (until another alarm occurs); the collective alarm is enabled, and the plotter trace may be displayed in a different color.

Device dialog box

Logic 1 🕒 15:14:41	
Channel designation	Log01
Channel description	Logic 01
Alarm	
Activation	Active
Alarm/Event list	Inactive (Signal only)
Alarm at level	High (1)
Alarm/Event text	Alarm Logic 01
Alarm delay	0 s
Alarm suppression	No selection

Parameter

Parameter	Selection/settings	Description
Activation	Inactive Active	Signal monitoring is inactive. Signal monitoring is active.
Alarm/Event list 	Inactive (signal only) Event Alarm/event	In the event of an alarm, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.
Alarm active at	High (1) Low (0)	Alarm at high level (1) Alarm at low level (0)
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Alarm delay 	0 s to 32767 s	Delay time for alarm signal activation
Alarm suppression 	Digital selector No selection	The selected digital signal (high-active) prevents the alarm signal being activated.

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

Alarm delay

In the event of an alarm (parameter "Alarm active at"), the alarm signal is not activated until the delay time has expired. If the alarm case is left in the meantime, the timer restarts when a new alarm case occurs.

Alarm delay, alarm suppression

Alarm delay and alarm suppression delay or prevent entries being added to the event list and alarm list, activation of the collective alarm, and display in the status bar.

7 Configuration

7.18 Groups

The user can configure up to four groups each with a maximum of six analog channels and six digital channels. During the configuration, the user specifies whether the channels in a group can only be viewed, or also stored, and how data recording occurs (memory cycle, storage method).

Grouping channels offers the ability, for example,

- To configure a separate group for each plant,
- To create one group each for different memory cycles (e.g., record pressure values every 125 ms, temperature values every 2 s) or
- To record special plant statuses in a separate group (e.g., record certain channels with a faster memory cycle if limit values are exceeded).



NOTE!

To use batch reporting at least one group must be active.

7.18.1 Parameter

Device dialog box

Parameter

Parameter	Selection/settings	Description
Status	General settings of the group	
	Inactive (default setting as from group 2)	The group data are neither displayed nor saved.
	Display only	The group data are displayed on the screen.
	Display/Save (default setting for group 1)	The group data are displayed on the screen and saved. The group data can only be evaluated using a PC if they have been saved.
Name	Use default text or enter other text.	Description of the group, with a max. length of 15 characters. The description is shown in the individual visualizations.

7.18.2 Analog channels

A group can consist of up to six analog channels (Channel 1 to Channel 6).

Device dialog box

Parameter

Parameter	Selection/settings	Description
Input signal 	Analog selector No selection	Signal source for the channel Default setting for group 1: Channel 1: analog input 1 Channel 2: analog input 2 Channel 3: analog input 3
Line width	Determines the width of the graphic measured value display. Thin Thick	Thin line width (1 pixel) Thick line width (2 pixels)
Tol. band active	Available as from channel 2 of a group. No, Yes	If "Yes", the channel is compared with channel 1 of the group. It must be ensured that channel 1 of the group is active (Input signal <> No selection).
Upper tolerance band limit	Only available for channel 1 of a group. 0 to 10 to 100	The "Upper tolerance band limit" and the current measured value of channel 1 form the upper limit of the tolerance band.
Lower tolerance band limit	Only available for channel 1 of a group. -100 to -10 to 0	The "Lower tolerance band limit" and the current measured value of channel 1 form the lower limit of the tolerance band.

7 Configuration

Parameter	Selection/settings	Description
Upper switching differential	Only available for channel 1 of a group. -100 to -2 to 0	If there is a positive tolerance violation, the current measured value from channel 2 to 6 must first drop below the current measured value of channel 1, plus the upper tolerance band limit and upper switching differential, in order for the alarm to be canceled.
Lower switching differential	Only available for channel 1 of a group. 0 to 2 to 100	If there is a negative tolerance violation, the current measured values from channel 2 to 6 must first exceed the current measured value of channel 1, plus the lower tolerance band limit and lower switching differential, in order for the alarm to be canceled.
Alarm text upper limit	Available as from channel 2 of a group. Use default text or enter other text.	The text entered (max. 31 characters) is displayed and entered in the alarm and event list if the selected channel exits the tolerance in positive direction.
Alarm text lower limit	Available as from channel 2 of a group. Use default text or enter other text.	The text entered (max. 31 characters) is displayed and entered in the alarm and event list if the selected channel exits the tolerance in negative direction.
Show auxiliary line 1, 2	Two auxiliary lines (level lines) can be shown for each channel. No , Yes	If "Yes" is selected, the auxiliary line is shown in the vertical and horizontal curve diagram if this has been activated generally in the configuration of the diagram view.
Auxiliary line value 1, 2	The two auxiliary lines can be used, for example, to define a lower and upper limit. As a result, the user can see in the diagram whether the current value is within the defined range. 0 to 100	Auxiliary line value
Auxiliary line color 1, 2	The default setting for the auxiliary line color corresponds to the color of the analog channel concerned (Configuration > Display > Colors). Use default color or select another color.	Auxiliary line color

Input signal

Channel 1 has a special task; it is used as the reference curve for the other channels in the group. All other channels in the group can be compared with channel 1 independently of one another. If the configured tolerance band is exited, an alarm occurs, and an alarm text is displayed in the "status and title line" and entered in the alarm list and event list.




NOTE!

The tolerance band comparison is only possible within the scaling limits. If a channel drops below or exceeds the range, this will result in both a min. and a max. alarm as with all other functions (in this case, pos. tolerance and neg. tolerance).

Example of tolerance band monitoring

The principle of the alarm follows the alarm configuration of the individual analog channels.



(1)	Lower alarm	1	Alarm on
(2)	Upper alarm	0	Alarm off
(3)	Switching differential		

Channel 1: Measured value = 21 °C (reference value)

Upper tolerance band limit = 10 °C

Upper switching differential = -2 °C

Channel 2: Tolerance band is active.

The alarm is generated if the current measured value from channel 2 is above 31 °C.

The alarm is canceled again if the current measured value drops below 29 °C.

Channel 1: Measured value = 21 °C (reference value)

Lower tolerance band limit = -10 °C

Lower switching differential = 2 °C

Channel 2: Tolerance band is active.

The alarm is generated if the current measured value from channel 2 is below 11 °C.

The alarm is deleted again if the current measured value exceeds 13 °C.



NOTE!

In the example shown, channel 1 is constant and channel 2 changes its measured value. This does not have to be the case. It could just as easily be channel 1 that changes, or even both channels.

7 Configuration

7.18.3 Digital channels

A group can consist of up to six digital channels (Channel 1 to Channel 6).

Device dialog box

Digital channels

15:22:05

Channel 1

Input signal

Digital input 1

Channel 2

Channel 3

Channel 4

Channel 5

Channel 6

Parameter

Parameter	Selection/settings	Description
Input signal	Digital selector No selection	Signal source for the channel

7.18.4 Diagram view

Device dialog box

Diagram-View

13:52:03

Display channel information

Yes

Measuring value display

Min.

Display envelope diagram

No

Display digital track

Yes

Diagram type

Vertically

Display channel description

No

Display auxiliary lines

Yes

Parameter

Parameter	Selection/settings	Description
Display channel information	This parameter is used to switch on and switch off the channel information display in the curve diagram: channel designation (e.g., A1) along with the abbreviation of the analog or digital signal (e.g., AI01 for analog input 1) and numerical display of the analog value.	
	No Yes	Display disabled Display enabled
Measured value display	The parameter determines which value is shown in the diagram header (only for curve presentation and when min./max. value recording is activated; see the parameter "Memory values").	
	Min. Max.	The min. value is displayed. The max. value is displayed.
Show envel. diagram	The parameter determines whether the measured values are shown as an envelope diagram or a line in the curve presentation (only when min./max. value storage is activated; see the parameter "Memory values"). If the data is not stored as min./max. values, the parameter has no effect.	
	No Yes	The min./max. values are displayed as a line. The min./max. values are displayed as an envelope diagram.
Show digital traces	The parameter determines whether the digital traces (digital signals) are shown in the curve presentation along with the analog signals.	
	No Yes	The digital signals are not displayed. Digital and analog signals are displayed.
Diagram type	The diagram can be displayed vertically or horizontally.	
	Vertical Horizontal	Diagram runs from the top down. Diagram runs from the right to left.
Display channel description	The parameter determines whether the channel description (e.g. analog input 01), rather than the abbreviation (e.g. AI01), is displayed in the channel information of the curve diagram.	
	No Yes	The abbreviation is displayed. The channel description is displayed.
Display auxiliary lines	The parameter determines whether the auxiliary lines (level lines) are shown in the curve diagram.	
	No Yes	The display of auxiliary lines is deactivated. Auxiliary lines are displayed if this has been activated in the configuration of the analog channels for the respective auxiliary line.

7 Configuration

7.18.5 Standard operation

When standard operation is activated, the measurement data is recorded at the configured memory cycle unless one of the following operating modes is active:

- Event operation
- Time operation

Standard operation has the lowest priority compared with time and event operation.

Device dialog box

Standard operation 15:28:57	
Memory status	On
Memory values	Average value
Memory cycle	5 s

Parameter

Parameter	Selection/settings	Description
Memory status 	On	The data is saved if this operating mode is active.
	Off	The data is not saved if this operating mode is active.
Memory values 	Average value	The average value across the configured memory cycle is calculated and saved.
	Current value	The current value at the end of the memory cycle is stored.
	Min. value	If the signal returns an error value during the memory cycle, even if this is only for a short time, the value is stored.
	Max. value	The minimum value within the configured memory cycle is stored.
	Min./Max. value	The maximum value within the configured memory cycle is stored.
		The minimum and maximum values within the configured memory cycle are stored.

Parameter	Selection/settings	Description
Memory cycle	0 s ... 5 s ... 32000 s	The memory cycle is configured here. Depending on the configuration of the "Memory values" parameter, the measurement data is saved when the configured time has elapsed. The smaller the memory cycle, the more data needs to be saved. If "0 s" is configured, the device uses the fastest possible cycle; in other words, it stores the measured values every 125 ms (high-speed mode; possible for up to four groups).

Memory status

The operating mode "Standard operation" is only available if memory status is switched on.



NOTE!

If the memory status is switched off and neither event operation nor time operation is active, only events will be recorded but measurement data will not be saved.

Memory values

For a digital signal the following values are stored depending on the "Memory values" parameter:

"Memory values" parameter	Stored value
Average value	High (1), if the digital signal assumes this value once during the memory cycle, otherwise Low (0)
Current value	Current value at the time of storing
Min. value	Low (0), if the digital signal assumes this value once during the memory cycle, otherwise High (1)
Max. value	High (1), if the digital signal assumes this value once during the memory cycle, otherwise Low (0)
Min./Max. value	High (1), if the digital signal assumes this value once during the memory cycle, otherwise Low (0)

7 Configuration

7.18.6 Event operation

Event operation is enabled by a control signal; it can be used, for example, to shorten a memory cycle during an alarm.

Event operation has the highest priority of all three operating modes.

Device dialog box

Event operation 15:29:47

Control signal	No selection
Memory values	Average value
Memory cycle	1 s

Parameter

Parameter	Selection/settings	Description
Control signal	Digital selector No selection	Signal that starts (high active) and stops event operation.
Memory values	See "Standard operation".	See "Standard operation".
Memory cycle	0 s ... 1 s ... 32000 s	See "Standard operation".

7.18.7 Time operation

A time frame is defined for time operation (max. 24 hours); during this period, a specific memory value and a specific memory cycle are active.

Time operation has higher priority compared with standard operation, but lower priority than event operation.

Device dialog box

Time operation

15:31:51

Begin	00:00:00
End	00:00:00
Memory values	Average value
Memory cycle	1 s

Parameter

Parameter	Selection/settings	Description
Start	00:00:00	Time at which to start time operation. Start = End: Time operation is inactive.
End	00:00:00	Time at which to end time operation again. Start = End: Time operation is inactive.
Memory values	See "Standard operation".	See "Standard operation".
Memory cycle	0 s ... 1 s ... 32000 s	See "Standard operation".

7 Configuration

7.18.8 Counters/integrators

Up to 6 counters/integrators can be assigned to each group. Alarms of these counters/integrators then cause an entry to be made in the event list and alarm list of the batch concerned (depending on the configuration).

Device dialog box

Counter/Integrators

🔒 13:53:34

Counter/Integrator 1	No selection	⬇
Counter/Integrator 2	No selection	⬇
Counter/Integrator 3	No selection	⬇
Counter/Integrator 4	No selection	⬇
Counter/Integrator 5	No selection	⬇
Counter/Integrator 6	No selection	⬇

✕

✓

Parameter

Parameter	Selection/settings	Description
Counter/integrator 1 to counter/integrator 6	Selector of all counters/integrators No selection	Counter/integrator whose alarm is entered in the event list and alarm list of the batch concerned. The settings of the respective alarm source are decisive for the entry.

7.18.9 Event texts

Each group can be assigned additional event texts selected from the text list. The selection is controlled by up to 5 digital signals or one analog signal which determine the text number in the text list. Each time the text number is changed, the corresponding text is copied from the text list into the event list.

The text is entered as a comment in the event list of the batch concerned. If there is no text at the selected point in the text list (or if the value is outside the value range), no entry is made in the event list.

Device dialog box

Event texts

13:54:47

First text	1
Digital signal 1	No selection
Digital signal 2	No selection
Digital signal 3	No selection
Digital signal 4	No selection
Digital signal 5	No selection
Text number	No selection

Parameter

Parameter	Selection/settings	Description
First text	1 to 500	First selectable text (text number) in the text list (text offset; only if selected through binary number)
Digital signal 1 (bit 0) to Digital signal 5 (bit 4)	Digital selector No selection	Bit 0 (LSB) to bit 4 (MSB) form a binary number which defines the text, taking the text offset into account.
Text number	Analog selector No selection	Analog signal whose value is used as the text number for selecting the text from the text list. If there are decimal places, the system rounds up or down to the nearest integer.

Digital signal ...

32 texts from the text list are available for selection by digital signals; the first selectable text is determined by the "First text" parameter.

First text + binary number = text number

Digital signal 1 has a priority of 2^0 , digital signal 2 a priority of 2^1 , etc.:

7 Configuration

Digital signal 5 (bit 4)	Digital signal 4 (bit 3)	Digital signal 3 (bit 2)	Digital signal 2 (bit 1)	Digital signal 1 (bit 0)	Decimal value
0	0	0	0	0	0
0	0	0	0	1	1
0	0	0	1	0	2
0	0	0	1	1	3
.	.	.	.	.	.
1	1	1	1	1	31

0 = "No selection" in the digital selector or signal is inactive.
1 = Signal selected and signal is active (high active).

Examples:

First text = 1; text selection bits: 00000 (= 0); text number = 1 + 0 = 1

First text = 1; text selection bits: 11111 (= 31); text number = 1 + 31 = 32

First text = 97; text selection bits: 11111 (= 31); text number = 97 + 31 = 128

7.18.10 Alarm signals

Up to 12 alarm signals can be assigned to each group. These alarms then cause an entry to be made in the event list and alarm list of the batch concerned (depending on the configuration).

Device dialog box

Parameter

Parameter	Selection/settings	Description
Alarm signal 1 to alarm signal 12	Selector of all alarm signals No selection	The selected alarm is entered in the event list and alarm list of the batch concerned. The settings of the respective alarm source are decisive for the entry.

7.19 Report

A report can be generated for each of the groups. The maximum value, the minimum value, and the average value of each analog channel referring to the selected reporting period are saved in a report.



NOTE!

Processing any changes to the configuration:

All reports are completed, saved, and restarted. The values of the completed reports in the device are set to empty, "----". In this case, the results of the completed reports can only be viewed with the PCA3000 software.



NOTE!

Automatic intermediate results of the "Total" and "Yearly" reports:

The "Total" and "Yearly" reports are saved once a month at the turn of the month, independently of other reports. They are not completed, but continue to run.

Device dialog (excerpt)

Report	Status
Daily	Off
Weekly	Off
Weekday	
Monthly	Off
Annually	Off
Total	Off
Periodically	Off
Period	
Report by control signal	Off

Parameter

Parameter	Selection/settings	Description
Daily	Specifies whether a report runs for a day (24 hours). Completion and restart are determined by the synchronization time parameter.	
	Off, On	If "On", the daily report runs.
Weekly	Specifies whether a report runs for a week. Completion and restart are determined by the day of the week and synchronization time parameters.	
	Off, On	If "On", the weekly report runs.
Day of the week	Sunday to Saturday	For the weekly report, the day of the week is used in combination with the synchronization time parameter as the report end and restart.
Monthly	Specifies whether a report runs for a month. Completion and restart occur at 00:00 on the first day of the month.	
	Off, On	If "On", the monthly report runs.

7 Configuration

Parameter	Selection/settings	Description
Annual	Specifies whether a report runs for a whole year. Completion and restart occur at 00:00 on the first day of the year	
	Off, On	If "On", the yearly report will be run.
Total	Total specifies whether a report is to be run for the total duration of the current configuration of the device.	
	Off, On	If "On", the total report will be run.
Periodically	Specifies whether a periodic report runs. Completion and restart are determined by the period and synchronization time parameters.	
	Off, On	If "On", the periodical report runs.
Period	1 min to 12 h	Period is used as the report end and restart for the periodical report.
Report by control signal 	Specifies whether an external report runs while the control signal is active.	
	Off, On	If "On", the external report will be run.
Control signal	Digital selector No selection	Control signal (high active) for the external report
Synchronization time 	Synchronizat. time is used as the report end and restart for the daily, weekly, and periodical report.	
	00:00:00	Time of synchronization
Out of range 	This parameter decides what happens if an analog channel is outside of the valid measuring range (scaling).	
	Stop report Delete report	The reports for this channel are stopped. If the measured values are within the measuring range limits, these will be restarted. The reports are set to invalid ("----") and only restarted following the configured report end.

Report by control signal



NOTE!

Within 5 seconds, only one external report is started in a group, i.e., any new external starts prior to the 5 seconds elapsing are ignored. If the start signal is still on after 5 seconds, the external report is started immediately. If the start signal is no longer on, the report is not restarted.

Synchronization time

The synchronization time parameter will be explained in more detail below, using the example of a periodical report. The stop and restart are performed at the next point in time occurring in the time grid – depending on the synchronization time and period.

Example:

Period = 2 hours

Synchronizat. time = 11:30:00

Power on = 09:11:00

1st period from 09:11 to 09:30 = 19 minutes

2nd period from 09:30 to 11:30 = 2 hours

3rd period from 11:30 to 13:30 = 2 hours

etc.



NOTE!

The principle is the same for all reports relating to the synchronization time (daily, weekly, and periodical report). For a daily report, the first report will usually not run for 24 hours and the first weekly report will usually not run for 7 days.

7 Configuration

7.20 Batches

The device supports reporting of one batch. The batch data is recorded along with the channels for the groups and displayed in batch visualizations.



NOTE!

To use batch reporting at least one group must be active.

7.20.1 General Information

Device dialog box

Parameter

Parameter	Selection/settings	Description
Batch active	Yes, No	The selected batch can only be configured if "Yes".
Batch name	Batch ...	Designation with a maximum length of 15 characters that is used in visualizations.
Group assignment	Select groups in drop-down menu (set checkmark). Batch 1: group 1	Assigned groups are shown with 1 (in this case: group 1).
Batch start	Barcode Inactive Control signal Touchscreen	Start and stop of batch reporting are controlled by a barcode scanner. Batch is not recorded. Start and stop of batch reporting are controlled by a digital signal. Start and stop of batch reporting are controlled by a button on the screen.
Control signal	Digital selector No selection	Signal that is used to start (high active) and stop batch reporting. The parameter is only available for batch start with "Control signal".

Parameter	Selection/settings	Description
Recipe header 	Recipe Use default text or enter other text.	For a completed batch, the recipe header is displayed as a title above a comment text (e.g., Recipe).
Text selection bit 0 to Text selection bit 5 	Digital selector No selection	Bit 0 (LSB) to bit 5 (MSB) form a binary number which defines a text from the text list (batch texts), taking the text offset into account.

Recipe header

The comment text can contain up to 400 characters (20 lines with 20 characters each); it is used to describe the batch. It is only transferred via an interface to the device (Modbus or barcode) and can only be displayed with the PCA3000 PC evaluation software.



NOTE!

Before ending batch reporting, a comment text must exist on the device for it be added to the batch report. After completing batch reporting, the comment text is deleted again. If it is to be used multiple times, the user must resend it to the device for each instance of batch reporting.

Text selection bit ...

64 texts from the text list (batch texts) are available for selection by digital signals; the first selectable text is determined by the "First text" parameter of the batch line.

First text + binary number = text number

Text selection bit 0 has a priority of 2^0 , text selection bit 1 a priority of 2^1 , etc.:

Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Decimal value
0	0	0	0	0	0	0
0	0	0	0	0	1	1
0	0	0	0	1	0	2
0	0	0	0	1	1	3
.	.	.	.	.	.	.
1	1	1	1	1	1	63

0 = "No selection" in the digital selector or signal is inactive.

1 = Signal selected and signal is active (high active).

Examples:

First text = 1; text selection bits: 000000 (= 0); text number = 1 + 0 = 1 (text 1)

First text = 1; text selection bits: 111111 (= 63); text number = 1 + 63 = 64 (text 64)

First text = 65; text selection bits: 111111 (= 63); text number = 65 + 63 = 128 (text 128)

If there is no text at the selected point in the text list (or if the value is outside the value range), no entry is made in the batch line (existing text is deleted).

7 Configuration

7.20.2 Batch lines

Device dialog box

Batch line 1		🔒 13:59:02
Text left column	Program name	⬆
Content right column	Selection from text list	⬇
Default text	Text 1	
Delete line	Yes	⬇
First text	1	
Number of texts	50	
Editable	Yes	⬇
Text number		
Text comparison	Inactive	⬇

✕
✓

Parameter

Parameter	Selection/settings	Description
Text left column	Program name (in line 1) Use default text or enter other text.	This parameter specifies the text in the left column for the selected line of the batch report.
Contents of right column	This defines how to compose the texts in the right column of a batch report.	
	No entry	The field remains empty.
	Default text	A set text – defined by the "Default text" parameter – is used.
	Selection from the text list	The user can select the text from the text list (batch texts). After reconfiguration, the default text is initially displayed; the user must select the desired text from the list in the "Current batch" visualization. The texts can be defined in the setup program.
	Selection by digital signal	A text from the text list (batch texts) is used. The selection is performed using a maximum of 6 digital signals (text selection bits). The texts can be defined in the setup program.
	Batch name	The batch name is displayed.
	Batch number ...	The batch number is used along with a text (default text). The batch number is incremented at the end of batch reporting. It can be pre-assigned using the device in the parameterization menu.
	Batch start	Start (date and time) of batch reporting

Parameter	Selection/settings	Description
	Batch end Batch duration Barcode User name External text variable ... Text number	End (date and time) of batch reporting Time difference between batch start and batch end The text in the selected line will be filled by a barcode scanner. Name of logged-on user Text that can be sent to the device via the interface (see interface description). The external text variables can also be written by a barcode scanner (see chapter 11.4.2 "Texts and process values", Page 278). The text is selected from the text list (batch texts). The text number is defined by an analog variable (analog selector).
Default text	Text x	The text (max. 160 characters) is used in the current batch report if the text in the right column is composed of "Default text" or "Batch number". For "Selection from the text list" or "Barcode," the text is used as a default.
Delete line	The parameter decides whether or not an edited text (in the right column) is reset after a batch is completed.	
	Yes, No	If "Yes", the text in the right column is replaced with its original content at the batch end (default text).
First text	1 ...	The parameter is available if the text in the right column is composed of the internal text list (batch texts) ("Selection from the text list" or "Select through digital signals"). It is the first text from the list which the user can select. In the setup program, the selectable texts are shown in a separate window during the configuration.
Number of texts	1 ... 50	The parameter is available if the text in the right column is composed of the internal text list (batch texts) (for "Selection from the text list"). In the setup program, the selectable texts are shown in a separate window during the configuration.

7 Configuration

Parameter	Selection/settings	Description
Editable	This parameter enables editing of the text within the current batch report.	
	Yes, No	If "No," the text in the right column can only be edited by modifying the "Default text". If "Yes", the text in the right column – for the current batch report – can be changed. Depending on the "Delete line" parameter, the configured text can be re-activated automatically after the batch report is completed.
Text number	Analog selector	The parameter is available if the text in the right column is composed of the internal text list (batch texts) (for selection by "Text number"). The text number is defined by the value of the analog signal. If there are decimal places, the system rounds up or down to the nearest integer. If there is no text at the selected point in the text list (or if the value is outside the value range), no entry is made in the batch line (existing text is deleted).
	No selection	
Text comparison	The length of the text in the right column (except batch start, batch end, and batch duration) can be checked, or the text can be compared with text from a definable area of the text list (first text; number of texts). The result is available in the analog selector.	
	Inactive Text length Text list	The function is inactive (result = 0). The result corresponds to the text length. If the text matches a text from the defined area of the text list, its index (position in the list area, beginning with 0) is output as the result. Otherwise the value -1 is output.
First text	1 ...	First text from the text list which is used for the text comparison.
Number of texts	1 ... 50	Number of texts in the text list for the text comparison (as from the first text).

7.21 Ethernet

The device may be integrated into a company network via the Ethernet interface.

The following functions are available via Ethernet:

- Communication with PC software such as the setup program, PCC, PCA3000
- Web server for using a web browser
- Communication with SNTP server and email server (SMTP)
- Communication with a Modbus master or slave via Modbus-TCP

Device dialog box

Ethernet 16:14:16	
IP address assignment	Automatically (DHCP)
IP address	
Subnet-Mask	
Standard-Gateway	
DNS device name	MAC000cd8094ecd-TYP7065...
DNS-Server IP automatically	Yes
DNS-Server	

Parameter

Parameter	Selection/settings	Description
IP address as- signment 	Automatic (DHCP) Manual	The device takes its IP address from the DHCP server. The IP address for the device must be assigned manually.
IP address 	0.0.0.0 ... 223.223.223.1 ... 255.255.255.255	Manual allocation of the IP address for the device (active if DHCP = Off) The IP address may need to be requested from the administrator in question.
Subnet mask 	0.0.0.0 ... 255.255.255.0 ... 255.255.255.255	Manual setting of the subnet mask (active if DHCP = OFF) The structure of the subnet mask may need to be requested from the responsible administrator.
Standard gateway 	0.0.0.0 ... 255.255.255.255	Manual setting of the IP address of the standard gateway (router) (active if DHCP = OFF) The IP address may need to be requested from the administrator in question.

7 Configuration

Parameter	Selection/settings	Description
DNS device name 	MAC000cd8094ecd-TYP7065... Admissible characters: a ... z, A ... Z, -, 0 ... 9 (max. 63 characters); Name must start with a letter and must not end with "-" (hyphen).	Example of a unique DNS device name (assigned by default) If necessary, the name can also be assigned individually, but it must be unique.
DNS server IP autom.	Yes No	The IP address of the DNS server is automatically assigned. The IP address of the DNS server must be entered manually.
DNS server 	0.0.0.0 ... 255.255.255.255	IP address of the DNS server (for manual input) The IP address may need to be requested from the administrator in question.



NOTE!

Transfer rate (10 Mbit/s or 100 Mbit/s) and duplex mode (half duplex or full duplex) are determined automatically.



NOTE!

The Ethernet parameters are shown in the device info (Main menu > Device info > Ethernet). In the event of connection problems, check the current settings.

IP address assignment



NOTE!

If applicable, deactivate the DHCP to ensure that the device uses a fixed IP address.

Subnet mask

The subnet mask determines which part of the IP address designates the network and which part is available for addressing a device within a network. The length of the mask is 32 bits (IPv4), which is the same length as an IP address.

Example: In a network with a mask of 255.255.255.0, the first 24 bits (from the left) are used for the network address; these are set to "1" in the mask. The remaining 8 bits are set to "0" in the mask and can be used for device addresses. There are therefore 254 device addresses available (256 - 2 because the address 0 is assigned for the network itself and the address 256 is used for the broadcast).

Standard gateway

All network requests to addresses that do not belong to the relevant network are routed through the standard gateway.

DNS device name

The DNS device name is a symbolic name that can be used for addressing instead of an IP address.

If a DNS device name has been entered, it is communicated to the DHCP server so that the device can be addressed with the name entered if the function is supported in the relevant network. If no DNS device name has been entered, the device can only be addressed using the assigned IP address.

**NOTE!**

If DHCP is active, a DNS device name should always be used so that the device can also be addressed if the IP address is changed.

DNS server

The DNS server responds to requests from the network to resolve a DNS device name into an IP address.

This IP address must be known if the device uses a representative name to address a different device or a server, for example when sending an email.

7 Configuration

7.22 Serial interface

The device is equipped with a serial interface which is configurable as an RS232 or RS485 interface. The interface supports the Modbus protocol (Modbus RTU) as a master or slave. Alternatively, a barcode scanner may be connected.

As of device version 04, the connection of a GPS receiver is supported (NMEA 0183).

For more information on using the serial interface with the Modbus protocol, see:

⇒ chapter 9.7 "Modbus frames for reading", Page 222

⇒ chapter 9.8 "Modbus frames for writing", Page 223

If you use the serial interface with a barcode scanner, please refer to the technical documentation for the barcode scanner for the required settings.

Communication via Modbus is described in detail in the separate interface description.

Device dialog box

Serial interface 16:17:44	
Type	RS 232
Protocol	Modbus-Slave
Baudrate	9600
Data format	8 - 1 - no parity
Minimum response time	40 ms
Modbus-Slave Modbus-Master NMEA 0183	
X ✓	

Parameter

Parameter	Selection/settings	Description
Type	RS232 RS485	RS232 interface RS485 interface
Protocol	Modbus slave Modbus master Barcode NMEA 0183	The device acts as a Modbus slave (Modbus-RTU). The device acts as a Modbus master (Modbus-RTU). A barcode scanner should be operated on the interface. Receiving GPS data (NMEA 0183 data records)

7 Configuration

Parameter	Selection/settings	Description
Baud rate	Baud rate with which the interface is operated.	
	4800	4800 baud
	9600	9600 baud
	19200	19200 baud
	38400	38400 baud
	115200	115200 baud
Data format	Data format with which the interface is operated.	
	8 - 1 - no parity	8 data bits, 1 stop bit, no parity
	8 - 1 - odd parity	8 data bits, 1 stop bit, odd parity
	8 - 1 - even parity	8 data bits, 1 stop bit, even parity
Min response time	0 to 40 to 500 ms	The minimum response time is adhered to by the Modbus slave before a response is sent following a data request. After receiving a response, the Modbus master waits during this period before sending a new request.
Line break character (setup only)	\$ Blank space . ; : -	This character triggers a line break when scanning batch texts (only for protocol = barcode).



NOTE!

Changes to the interface parameters only become active after the device has been restarted (power on).

7 Configuration

7.22.1 Modbus slave

The device acts as a Modbus slave.

Device dialog box

Serial interface	
Baudrate	9600
Data format	8 - 1 - no parity
Minimum response time	40 ms
Modbus-Slave	
Device address	1
Timeout monitoring	No
Alarm-/Event list	Slave-Time-out COM01
Timeout	2000 ms
Modbus-Master	

Parameter

Parameter	Selection/settings	Description
Device address 	1 to 254	Modbus device address
Timeout monitoring 	No Yes	Monitoring is not active. Monitoring is active.
Alarm/Event text	Use default text or enter other text.	Text that is displayed in the event of an alarm and entered in the alarm and event list.
Timeout 	250 to 2000 to 99999 ms	Time period for timeout monitoring. After this time, a failure of the Modbus master is identified.

Device address

For the interface type RS485, the device address of the Modbus may only occur once within a connection (multiple devices connected to a bus). It is less significant for interface type RS232, as only one device may be connected to the serial interface.

Timeout monitoring, timeout

This function monitors the communication between the Modbus master and Modbus slave from the perspective of the Modbus slave. After enabling timeout monitoring, a timer starts when the first request is received (the timer time is the time set as the "Timeout"). The timer starts to run again after each new request. If the request does not appear, an internal digital signal is activated after the timer has elapsed and an entry is made in the alarm and event list. The signal is reset with the next request.

7.22.2 Modbus master

The device acts as a Modbus master.

Device dialog box

Serial interface
16:20:02

Type	RS 232
Protocol	Modbus-Master
Baudrate	9600
Data format	8 - 1 - no parity
Minimum response time	40 ms
Modbus-Slave Modbus-Master	
Timeout	200 ms
Scanning cycle	500 ms

Parameter

Parameter	Selection/settings	Description
Timeout	60 to 200 to 10000 ms	A request sent by the master is defined as faulty if no answer is received within this time.
Scanning cycle	60 to 500 to 99999 ms	The Modbus master requests data from the Modbus slave at these intervals.

7.22.3 NMEA 0183

The received GPS data records (NMEA 0183) are filtered and entered in the event list of the relevant group if they match the filter conditions.

In addition, the data records can be transferred via Modbus to another device (Modbus slave). The external text variables (long) are used for this purpose.

7 Configuration

Device dialog

Serial interface
07:38:39

Modbus-Slave
Modbus-Master
NMEA 0183

Cycle
60
Group
1
Data record 1
GPZDA
Data record 2
GPGLL
Data record 3
External text variable (long)
0

X
✓

Parameter

Parameter	Selection/settings	Description
Cycle	60 to 9999 s	Interval at which the records are entered into the event list of the relevant group.
Group	1 to ...	Group to which the event entry is assigned.
Data record 1	Enter device ID and data record identifier (max. 5 characters). GPZDA	The first characters (without "\$") of a received data record are compared with this string. Only if there is a match, the data record will be entered into the event list. Up to three strings can be specified for the comparison (data record 1 to data record 3).
Data record 2	Enter device ID and data record identifier (max. 5 characters). GPGLL	
Data record 3	Enter device ID and data record identifier (max. 5 characters).	
External text variable (long)	0 to ... Example: 4 Data record 1 > text variable 4 Data record 2 > text variable 5 Data record 3 > text variable 6	Number of the first text variable for the transmission of the data records via the Modbus interface. 0: No text variable selected.

Timeout monitoring

If there is no new signal from the GPS receiver after a period of time corresponding to 3 times the cycle time, the "Timeout GPS" signal is activated (see digital selector).



NOTE!

The GPS data records are stored in the device in the text variable "External event text (long) - group x". This text variable may then not be written via Modbus or PROFINET.

7.23 Modbus-TCP

This menu is used to implement settings for the Modbus-TCP operating mode.

If the device is a Modbus slave, two external devices (Master 1 and Master 2) can access the device at the same time. If it is a Modbus master, it can communicate with up to four external devices (Device 1 to Device 4).

For use of the Modbus protocol, see also:

⇒ chapter 9.7 "Modbus frames for reading", Page 222

⇒ chapter 9.8 "Modbus frames for writing", Page 223

Communication via Modbus is described in detail in the separate interface description.



NOTE!

To ensure that fixed IP addresses are used, the DHCP must be deactivated in the devices involved, if applicable.



NOTE!

The transfer times in an Ethernet network depend in part on the network architecture and the capacity utilization. This may result in delays during updates of process values.

7.23.1 Modbus slave

The device acts as a Modbus slave.

Device dialog box

Modbus-Slave

07:38:50

Port

502

Master 1

Timeout monitoring

Yes

IP address

0.0.0.0

Timeout

2000 ms

Alarm-/Event list

Slave-Time-out TCP01

Master 2

✕

✓

Parameter

Parameter	Selection/settings	Description
Port	0 ... 502 ... 1024	TCP port for Modbus-TCP Changes to the port are not applied until after the system has been restarted.

7 Configuration

Parameter	Selection/settings	Description
Master 1, Master 2		
Timeout monitoring 	No Yes	Monitoring is not active. Monitoring is active.
IP address	0.0.0.0	IP address of the Modbus master for timeout monitoring The address must be set.
Timeout 	250 to 2000 to 99999 ms	Time period for timeout monitoring After this time, a failure of the Modbus master is identified.
Alarm/Event text	Use default text or enter other text.	Text that is displayed in the event of an alarm and entered in the alarm and event list.

Timeout monitoring, timeout

This function monitors the communication between the Modbus master and Modbus slave from the perspective of the Modbus slave. After enabling timeout monitoring, a timer starts when the first request is received (the timer time is the time set as the "Timeout"). The timer starts to run again after each new request. If the request does not appear, an internal digital signal is activated after the timer has elapsed and an entry is made in the alarm and event list. The signal is reset with the next request.

7.23.2 Modbus master

The device acts as a Modbus master.

Device dialog box

Modbus-Master

08:00:13

Timeout

2000 ms

Scanning cycle

500 ms

▲ Device 1

IP address

0.0.0.0

Port

502

▼ Device 2

▼ Device 3

▼ Device 4

✕

✓

Parameter

Parameter	Selection/settings	Description
Timeout	60 ... 2000 ... 10000 ms	A request sent by the master is defined as faulty if no answer is received within this time.

7 Configuration

Parameter	Selection/settings	Description
Scanning cycle	60 ... 500 ... 99999 ms	The Modbus master requests data from the Modbus slave at these intervals.
Device 1 to Device 4		
IP address	0.0.0.0	IP address of Modbus slave The address must be set.
Port	0 ... 502 ... 1024	TCP port of Modbus slave (for Modbus-TCP)

7 Configuration

7.24 Time settings

The settings in this dialog are used to synchronize multiple devices by means of a control signal.



NOTE!

The date and time are set in the device parameterization or setup program (online parameters). The PC's date and time are used for the settings in the setup program. The date and time can also be set using a time server.

Device dialog box

Parameter

Parameter	Selection/settings	Description
Control signal for time sync 	Digital selector No selection	Control signal for synchronizing the time (with low-high edge)
Sync during batch	No, Yes	If "Yes", the time can also be synchronized while batch reporting is in progress.

Control signal for time sync

The signal is used to synchronize multiple devices. The time is synchronized when transferring from Low to High (min. pulse duration = 125 ms). The seconds are crucial to changing the time. The time is put forward or back by a maximum of ± 30 seconds. Example:

12:55:29 -> 12:55:00, 12:55:30 -> 12:56:00



NOTE!

In the setup program, the time zone and daylight saving time are also set during the configuration; in the device, they are set in the parameterization (Parameterization > Date and time).

7.25 Time server (SNTP)

The time and date of the paperless recorder can be synchronized with a time server using the SNTP protocol (Simple Network Time Protocol).

Device dialog box

Time server (SNTP) 08:03:14

Synchronizing with server

Yes

SNTP-Server 1

SNTP-Server 2

SNTP-Server 3

Period

1 h

Parameter

Parameter	Selection/settings	Description
Synchronize with server	No	Time/date of device are not synchronized.
	Yes	Time/date of device are periodically synchronized with a time server.
SNTP server 	The device supports up to three time servers (SNTP). Specify the DNS name if possible and not the IP address.	
1	Enter server address	First time server
2	Enter server address	Second time server
3	Enter server address	Third time server
Period	1 h	Synchronization every hour
	12 h	Synchronization every 12 hours
	24 h	Synchronization every 24 hours

SNTP server

The server list is processed top down, in other words, the next time server on the list is only queried if the previous server is unreachable. If no time server can be reached at the envisaged sync time, synchronization is retried later (the repeat time starts at 1 minute and varies). After five unsuccessful attempts, a "Time server error" message is added to the event list. After a wait, another attempt is made to synchronize the time.

Time zone and daylight saving time

The SNTP server always provides the UTC time so that both the time zone and the time for switching to daylight saving time are only defined by the device configuration (Configuration > Date and time).

7 Configuration

Deviation tolerance

Time and date synchronization depends on the deviation tolerance (30 s).

If the deviation of the time/date between the server and the device is less than or equal to the deviation tolerance, the time on the device is slowly modified (the internal clock runs slightly faster or slower) without needing reconfiguration. This also applies in the special cases stated below. If the deviation of the time/date between the server and the device is greater than the deviation tolerance, a new configuration is automatically generated, and the time/date on the device are immediately set to the new value from the server (time jump). However, this does not apply in the following special cases:

- Batch reporting is active
- Setup transmission is active
- Transmission of measurement data by the PCC program is active
- Control windows are open on the device (e.g., configuration)
- Memory manager is active (e.g., writing data to the USB flash drive)

In the stated special cases, time synchronization is canceled and another attempt is made after 1 minute. In the event of further unsuccessful attempts, the repetition interval is varied slightly to avoid the time query occurring at the same interval as the other event preventing time synchronization (e.g., PCC transmission).

7.26 Undocumented parameters



CAUTION!

Incorrect configuration of the "Undocumented parameters".

The device does not react as it should.

- Undocumented parameters must only be changed if the user is requested to do so by a service technician from the manufacturer.
-

This chapter describes the parameterization of the paperless recorder; this is only possible on the device: **Main menu > Parameterization**

A parameter that is also configurable in the setup program or via an interface will be pointed out.



NOTE!

The parameterization on the device is only available if a user is logged on, and the user has the required rights.

Default settings are shown in **bold** in the parameter tables.

8.1 Fine adjustment

You can use customer-specific fine adjustment to correct the measured values of an analog input. In contrast to offsetting, which is used to specify a constant correction value for the entire characteristic line, fine adjustment can also be used to change the slope of the characteristic line.

Device dialog box

Analog input 1
🔒 21:25:39

Active	Yes
Actual start value	+0.0000
Actual end value	+1.0000
Target start value	+0.0000
Target end value	+1.0000

✕
📄
✓

Parameter

Parameter	Selection/settings	Description
Active	Yes	The function for performing fine adjustment is active.
	No	Function is inactive.
Actual start value	-99999 ... 0 ... +99999	Lower display value
Actual end value	-99999 ... 1 ... +99999	Upper display value
Target start value	-99999 ... 0 ... +99999	Lower reference value
Target end value	-99999 ... 1 ... +99999	Upper reference value

Example

The temperature inside a furnace is measured with an RTD temperature probe and displayed. Due to the temperature drift of the sensor, the true temperature (reference measurement) deviates from the displayed value. The amount of deviation is different at the upper and lower measuring points, meaning that measured value offset is not suitable.


Actual start value: 15 °C (displayed value)

8 Parameterization

Target start value: 20 °C (reference measurement)

Actual end value: 70 °C (displayed value)

Target end value: 80 °C (reference measurement)




(1)	Display values	(2)	Reference values
(3)	Furnace	(4)	Sensor in RTD temperature probe

Performing fine adjustment

- 1) Determine the lower value (as low and constant as possible) with the reference measuring device.
Example: Set furnace temperature to 20 °C.
- 2) Enter the display value as the actual start value and the reference value as the target start value.
Example: Enter 15 and 20.
- 3) Determine the upper value (as high and constant as possible) with the reference measuring device.
Example: Increase furnace temperature to 80 °C.
- 4) Enter the display value as the actual end value and the reference value as the target end value.
Example: Enter 70 and 80.

Characteristic line

The following diagram shows the changes in the characteristic line caused by the fine adjustment (point of intersection with the x axis as well as the slope).



y	Display value	(1)	Characteristic line before fine adjustment
x	Reference value	(2)	Characteristic line after fine adjustment

Resetting the fine adjustment

The following settings must be made to reverse the fine adjustment:

Actual start value = target start value

Actual end value = target end value

8.2 Counters/integrators

This function is used to change the current counter/integrator status (e.g., to 0 or any other value). The counter/integrator continues to run with this new value, but the period for adding the total is not restarted. The change is logged in the event list specifying the old and new values and is only effective once. The old value is not stored.

Device dialog box

Counter/Integrator 1
13:28:31

Current value	+0.000000000
Start value	+0.000000000




Parameter

Parameter	Selection/settings	Description
Current value	(Display only)	Displays the current counter/integrator status
Start value	-999999999 to 0 to +999999999	New start value for the counter/integrator

8 Parameterization

8.3 Limit value monitoring functions

The limit value and switching differential in the general limit value monitoring functions are also adjustable in the parameterization. The prerequisite for this is that limit value monitoring has been previously configured.

chapter 7.13 "Limit value monitoring functions", Page 130

Limit value and switching differential can be configured in the configuration as well as via an interface.

Device dialog box

Limit value monitoring 1		🔒 16:07:34
Channel designation	LM 01	
Channel description	Lim. val. monitor. 01	
Signal source	Analog input 1	
🔔 Alarm		
Limit value	+0.0000 °C	
Switching differential	+0.0000 °C	
 		

Parameter

Parameter	Selection/settings	Description
Channel designation	None	Name (abbreviation), as configured.
Channel description	None	Description (designation), as configured.
Signal source	None	Input signal of limit value monitoring (signal to be monitored), as configured.
Limit value	-99999 to 0 to +99999	If the limit value is exceeded (max. alarm case) or the value drops below the limit (min. alarm case), an out-of-limit case exists.
Switching differential	0 to 99999	The switching differential is used to suppress constant switching of the status signal in the event of fluctuations of the input signal around the limit value.

8.4 Date and time

This function is used to set the current date and the current time on the device and to select the time zone. Additionally, settings for the start and end of daylight saving time are configured here.

The device date and time can also be set with the setup program using the PC's date and time:

chapter 10.2 "Date and time", Page 256

The date and time can also be set using a time server:

chapter 7.25 "Time server (SNTP)", Page 191

Device dialog box

Date and time		13:29:52
Current Date-Time	08/26/2015 13:29:20	▲
Daylight saving time changeover	Automatically	▼
Time zone	UTC+1h (CET)	▼
▲ Start daylight saving time		≡
Month	March	▼
Weekday/Day	Sunday	▼
Day in month	Last	▼
Time	02:00:00	
▲ Daylight saving end		▼
✕ ✓		

Parameter

Parameter	Selection/settings	Description
Current date/time	Enter the date and time	The date and time are only applied after quitting the "Date and time" dialog by pressing the checkmark (✓).
Daylight saving time changeover	Inactive Automatic	No automatic toggling Automatic toggling according to the settings for the start and end of daylight saving time Changing this setting can cause the time to change.
Time zone	UTC+1h (CET) (Drop-down menu)	Time zone regardless of daylight saving time Changing the time zone causes the time to change.
Start of daylight saving time	January to March to December First, second, third, fourth, last Sunday to Saturday, 1 to 31 00:00 to 02:00 to 24:00	Month Day of the week in month Day of the week/day Time

8 Parameterization

Parameter	Selection/settings	Description
End of daylight saving time	January to October to December First, second, third, fourth, last Sunday to Saturday, 1 to 31 00:00 to 03:00 to 24:00	Month Day of the week in month Day of the week/day Time



NOTE!

In the setup program, the time zone and daylight saving time are set during the configuration (Configuration level > Time settings).



NOTE!

Any change in the date and time will lead to a new configuration.

8.5 Batches

This function specifies a start number for the batch number of the respective batch.

The batch number is used in the batch report. At the end of batch reporting, the value is incremented by one.

Device dialog box

Batches 15:50:27	
Batch number 1	0
Batch number 2	0
Batch number 3	0
Batch number 4	0
Batch number 5	0

Parameter

Parameter	Selection/settings	Description
Batch number 1 to batch number 5	0 to 999999999	Start number for the batch number of the affected batch (batch 1 to batch 5)

8 Parameterization

8.6 System data

The "Country settings after power on" parameter determines whether the language and other country-specific settings (temperature unit, time zone, daylight saving time) can be selected when the device is next powered on.

This parameter can also be set in the configuration, but only with the setup program:

chapter 7.3 "Device", Page 98

The "Transmit user separately" parameter enables the user table to be transferred to the device separately from the configuration data.

Device dialog box

System data 08:36:46	
Country settings after power on	No
Transfer users separately	No

Parameter

Parameter	Selection/settings	Description
Country settings after power on	Yes, No	If "Yes," is selected, the user can configure settings immediately after switching on the device the next time. The parameter is then automatically reset to "No" so that no settings occur after switching back on again. The country settings are also configured after switching on the device for the first time as part of the startup.
Transmit user separately	Yes, No	Only for a device without extra code 888 (FDA): If choosing "Yes" the user table (table with user ID and name, password, group assignment) will not be transferred along with the configuration and the user groups to the device. In that case the user table can only be transferred separately. chapter 6.3.5 "View", Page 85

9 Configuration – in setup program only



NOTE!

The functions described in this chapter can only be configured with the setup program.

Default settings are shown in **bold** in the parameter tables.

9.1 Country settings

Text library

The text library is used to manage the various language and country-specific settings, such as the date format and decimal point, independently of the project.

Function in the menu bar: **Tools > Text library**

This function is only available if a license number that includes text library editing has been registered.

Country settings

The country settings (language and country-specific settings such as the date format and decimal point) are taken from the text library by the setup program when creating a setup file. The first two languages (Language 1 and Language 2) are applied. The user can add more languages.

A country setting can be moved to another position in the list ("Sort language"). The first 15 country settings in the list are sent to the device and are available there for changing the language.



NOTE!

Language can be edited both in the text library and in the country settings. As a general rule, all country- or customer-specific changes should be made in the text library while project-specific modifications are made in the country settings.

Setup dialog box

Parameter


Parameter	Selection/settings	Description
ID	(No input box)	Internal ID (only for service purposes to identify the language)
Language	Use default text or enter other text.	Designation of the language

9 Configuration – in setup program only

Parameter	Selection/settings	Description
Date format	DDMMYYYY MMDDYYYY YYYYMMDD	Example: 31.12.2010 Example: 12-31-2010 Example: 2010-12-31
Separating point (time)	Use the default character or enter another character.	Example of separating point ":" (colon): 23:59:59
Separating point (date)	Use the default character or enter another character.	Example of separating character "/" (slash): 31/12/2010
Decimal point	Use the default character or enter another character.	Example of decimal point "." (point): 100.5
Character input (standard keyboard layout), Non-standard character 1 to Non-standard character 5	Keyboard layout of virtual keyboard on the device (letters, digits, and non-standard characters) In the default keyboard layout each key can be assigned up to 10 characters. In the other keyboard layouts (Non-standard character 1 to 5), only one character per key is possible. Left click the virtual key in the keyboard field. If needed, change the key assignments in the text field (below the keyboard box).	The appropriate key is selected and the characters that are assigned to the key appear in the text field. The first character from the left corresponds to the character on the key.

Language

After pressing the "Language" button, the user has various editing options:



For example, the user can edit a language or create a new language based on an existing language.

Language editing functions

Selection	Submenu	Function
New language ...	Create	A new language is created based on the selected language.
New language ...	From setup file	The new language is created from an existing setup file. To do this, the user needs to select the setup file from a directory (file with a suffix of ".323"). If the setup file contains multiple languages, these languages are shown for selection.
New language ...	From current library	The new language is created from the text library of the current setup program. If the text library contains multiple languages, the user needs to select the desired language.

9 Configuration – in setup program only

Selection	Submenu	Function
New language ...	From another library	The new language is created from another text library. To do this, the user needs to select the text library from a directory (file with the suffix ".dat"). If the setup file contains multiple languages, these languages are shown for selection.
Edit		Opens the "Device texts" window in which the (target) language can be edited.
Delete		Deletes the selected language.
Copy		Copies the selected language.

9 Configuration – in setup program only

9.2 User list

The user IDs, names, and passwords for various users are assigned in the user list, and the user rights are managed. The system supports up to five users with varying rights.

These settings are crucial for logging onto the device. They are not authoritative for logging into the setup program.

Additionally, public rights are defined here. These rights are used if there is no user logged on to the device.



NOTE!

In a device without extra code 888 (FDA), the "Transmit user separately" parameter decides whether the user table (user ID and name, password, group assignment) is transferred separately from the configuration and the user groups to the device.

See chapter "Parameterization" > "System data".



NOTE!

A device with extra code 888 (FDA) does not have this function available in the setup program because the user list can only be created with the PC Security Manager software PCS. Up to 50 users can be administered like that; the "Manage users" right is required here.

See operating manual for PC Security Manager software PCS (B 709703.0 or 70970300T96...).

Setup dialog box

Parameter

Parameter	Selection/settings	Description
Password rules	Press button	⇒ chapter 9.2.2 "Password rules", Page 206
Character table	Press button	⇒ chapter 9.2.3 "Character table", Page 207

9 Configuration – in setup program only

Parameter	Selection/settings	Description
Group 1 ... Group 15, Public rights 	Select relevant user group from the drop-down list.	The following parameters "Group designation" and "Rights" refer to the selected user group. The rights for users that are not logged on are defined by selecting "Public rights".
Group designation	Use the default designation or enter a different designation.	Use a text for the designation that describes the function (rights) of the user group.
Rights	Press button	Rights of the user group ⇒ chapter 9.2.5 "User rights", Page 209
User 1 ... User 5 	Select relevant user from the drop-down list.	The default settings for the relevant user are displayed and can be changed by the operator. ⇒ chapter 9.2.1 "Default user settings", Page 206
ID	Use default ID or enter other ID.	The ID (user ID) is displayed in the user list for logon.
Name	Use default name or enter other name.	Use a text for the name that describes the function (rights) of the user. The name is not displayed or prompted for at logon time.
Password	Use the default password or enter a different password.	The password is requested for logon.
Group assignment	Select one or several user groups (select checkbox).	The relevant user gets the rights of the selected user group.

Group 1Group 15, Public rights

Up to 15 groups are provided for assigning user rights; specific rights are assigned to these groups. An individual name can be assigned to each group in order to make it easier to distinguish the groups (e.g. "Master", "Users", "Service"). The rights assigned to the group "Public rights" are valid for users who are not logged on.

User 1 ... User 5

Up to 5 users can be managed; each user can be assigned to one or multiple groups. As a result, the user receives the rights of the relevant group.

9 Configuration – in setup program only

9.2.1 Default user settings

User 1 (Master) is assigned all rights by default. Users 2 to 4 (User 1 to User 3) and User 5 (Service) have limited rights.

User 5 is designed for performing service functions. It differs from User 1 in that the user cannot manage any other users or delete recording data. Users 2 to 4 have identical rights.

Users 1 to 5 are designed both for logging on directly to the device and for logging on indirectly to the device via the setup program.

The individual rights of each user can be configured individually with the setup program.

The following IDs, names, and passwords are set by default:

Users	ID	Name	Password
User 1	Master	System Master	9200
User 2	User 1	Data Management	1
User 3	User 2	Data Management	2
User 4	User 3	Data Management	3
User 5	Service	Service	9200


9.2.2 Password rules

Re-authentication guarantees that a user has to log on to the device again after a specified time has elapsed during which no operation is performed. The device can be protected against unauthorized users in this way.

The user is not logged out immediately after the time elapses, and only when the next operation is performed. A message then appears prompting the user to log on again. After confirming this message by pressing "OK," the user can log back on.

If the device is in a condition in which operation is not possible (e.g., during a configuration), the timer is stopped.

Setup dialog box



Parameter

Parameter	Selection/settings	Description
Re-authentication	0 to 65535	Time after which it is necessary to log on again. 0 = Function is disabled
Comment with authentication 	Yes (☒) , No (☐)	By choosing "Yes" the user has to select a user ID and enter the password to enter a comment text. The comment text is entered into the event list along with the user ID.

Comment with authentication

A comment with authentication can be performed by any user who has the appropriate authorization ("View recording data and evaluate history" right). This can be a different user to the one who is currently logged on.

9 Configuration – in setup program only


9.2.3 Character table

The character table is used to define the characters available for assigning passwords.

The characters are displayed on the device in the form of a virtual keyboard, which is organized in levels.

If the setup program is used to assign or change a password, only the characters specified in the setup program are admissible. Subdivision into levels is irrelevant in this case.

Setup dialog box



Parameter


Parameter	Selection/settings	Description
Character 1 ... Character 16 (Character level)	Select level from the drop-down list. The default levels 1 to 4 cannot be edited. Other levels can be added in a user-specific way.	Virtual keyboard level for assigning the password on the device The virtual keyboard can consist of up to 16 levels, each with up to 32 characters.
Heading	Use the default text or enter a different text.	Short designation for the level of the device's virtual keyboard (not currently used).
Category	Select relevant category from the drop-down list (if necessary).	The category enables you to distinguish levels according to the type of characters defined there.
Input box (bottom)	Enter or edit characters	The characters are displayed in the keyboard field in the order of entry (from left to right and top down). The view basically reflects the virtual keyboard of the device.

9 Configuration – in setup program only

9.2.4 Public rights

Public rights apply to users who are not logged on to the system.

Setup dialog box



Assign rights

The rights are listed as a tree structure. A click on "+" expands the view: The relevant sub-items (single rights) become visible. A click on "-" collapses the view: only the major item (group) is visible.


The rights are activated by a click on the corresponding checkbox.

9 Configuration – in setup program only

9.2.5 User rights

User rights apply to a user logged onto the device.

Setup dialog box



Assign rights

The rights are listed as a tree structure. A click on "+" expands the view: The relevant sub-items (single rights) become visible. A click on "-" collapses the view: only the major item (group) is visible.

The rights are activated by a click on the corresponding checkbox.

9 Configuration – in setup program only

9.2.6 Overview of rights

The following rights can be assigned as public rights and user rights.

Category	Individual right
Setup	Write configuration
	Time setting
	Fine adjustment (on the device)
	Read configuration
Recording data	Read out recording data, incl. clear memory alarm
	Only read out recording data (memory alarm is kept)
	View recording data
	View recording data and evaluate history
	Delete recording data
	Create device certificate
General information	Enter batch texts
	View device info screen
Security	Manage users
	View event list
	Reset user list
Mixed	View audit trail
	Set counter
	Alarms acknowledgement
	Service
	Logon only via setup program
Extra codes	Activate extra codes
Process screen	Process screen operation
Parameterization	Write parameterization
	Read parameterization
Batches (in PCS only)	Confirm batches, electronic signature (on the device)

9 Configuration – in setup program only

Effects of rights (on the device)

Individual right	Effect
Write configuration	The configuration can be written (edited) and read (only writing is possible in the setup program). The affected menu items or functions are available in the individual menus (Main menu: Configuration; Sub-menu "Service": Load default configuration; Flash Manager: Read configuration from USB flash drive, software update).
Time setting	In the main menu, "Parameterization" sub-menu, the menu item "Date and time" (for setting the date, time, time zone, and daylight saving time) is available. The date and time can also be set with the setup program (online parameters; use of PC's date and time).
Fine adjustment (on the device)	The "Fine adjustment" (fine adjustment of analog inputs) menu item is available in the main menu, "Parameterization" sub-menu.
Read configuration	The configuration can be read. The affected menu items or functions are available in the individual menus (Main menu: Configuration; Sub-menu "Service": Save default configuration; Flash Manager: Write configuration to USB flash drive).
Read out recording data, incl. clear memory alarm	The following functions are available in the Flash Manager: Writing recording data to USB flash drive; Write current counters/statistics and recording data to USB flash drive.
Only read out recording data (memory alarm is kept)	The following function is available in the Flash Manager: Saving all recording data on USB flash drive (Backup). – The memory alarm is cleared. If the recording data is read out with the PCA communication software PCC, the following applies: If the user logged onto PCC only has this right, but not the right "Read out recording data, incl. clear memory alarm", the user can only extract the data, but not clear the memory alarm. To also clear the memory alarm, the appropriate option must be active in PCC (Do not clear memory alarm on device: No).
View recording data	All views are available in the Visualization menu (View) (incl. batch report).
View recording data and evaluate history	All views are available in the Visualization menu (View) (incl. batch report). In the curve diagram and the digital diagram, the memory display (history) can be called up. It is possible to enter a comment text. The curve presentation can be opened in the report for the completed batch.
Delete recording data	All recording data can be deleted (function in setup program, online parameters).
Create device certificate	A device certificate can be created (function in setup program, online parameters).
Enter batch texts	All views are available in the Visualization menu (View) (incl. batch report). The batch texts can be edited in the current batch report.
View device info screen	The Device info menu is available in the main menu (it contains information about the device, the current process values, and the Ethernet interface).
Manage users	The Flash Manager has the following function available: read user list from USB flash drive.
View event list	The event list is also available in the alarm and event menu.
Reset user list	The user list can be reset (function in setup program, online parameters).
View audit trail	The "Audit Trail list" menu item is available in the main menu (the list contains all audit trail messages).

9 Configuration – in setup program only

Individual right	Effect
Set counter	The menu items "Counters/Integrators" (set initial value) and "Batch" (enter batch number) are available in the main menu, "Parameterization" sub-menu.
Alarms acknowledgment	The collective alarm can be acknowledged in the alarm list.
Service	The "Service" menu item is available in the main menu. The "Writing service data to USB flash drive" function is available in the Flash Manager.
Logon only via setup program	The user can only log onto the device through the setup program; the user cannot be selected in the device itself.
Activate extra codes	Extra codes can be activated (function in setup program, online parameters).
Process screen operation	In the process screen, in case of an input object a value or text can be entered (in as far as the object is editable).
Write parameterization	The "Parameterization" menu item is available in the main menu; the sub-menu parameters can be edited.
Read parameterization	The "Parameterization" menu item is available in the main menu; the system data can be read.
Confirm batches, electronic signature (on the device)	The user can provide the electronic signature for a completed batch, for the recording data of a certain time period, or when logging off (in as far as the PCS is configured appropriately).

9.2.7 Behavior after power on

The user needs to log on whenever the device is powered on.

Changes to the user list are stored on powering off.

9.2.8 Expertise protection

The device configuration typically contains the user's specific expertise, which needs to be protected against unauthorized access.

The device provides multiple rights which are configurable depending on the requirements and which provide protection of expertise:


- The right "Read configuration" along with the right "Write configuration" (both rights deactivated) prevents the configuration being visible on the device.
- The right "Read configuration" (right disabled) prevents copying to a USB flash drive and reading out data with the setup program.
- The "Manage users" right (right disabled) lets you prevent expertise protection being disabled.
- The right "Reset user list" (right disabled) prevents working around expertise protection.
- The "Logon via setup program only" right (enabled) gives the plant manufacturer the ability, in combination with the rights "Write configuration" and "Read configuration," to ensure that the end user on the device cannot view the configuration.

9 Configuration – in setup program only

9.3 Text list

These texts are available for all functions that allow text to be selected from the text list.
In this menu, the texts can be edited individually for each of the device languages.

Setup dialog box



Parameter

Parameter	Selection/settings	Description
Text number: 1 to ...	Select the relevant device language (tab) and edit the text to be changed in the "Text" column (max. 160 characters).	The text can be used as a batch text, event text, in the ST code, and in the process screen.

9 Configuration – in setup program only

9.4 Email

An email alarm can be sent to up to three address simultaneously via a mail server. Up to 5 alarm texts can be configured; sending is controlled using a digital signal.

Setup dialog box

Parameter

Parameter	Selection/settings	Description
Email 1 ... Email 5 (Email settings for the 5 alarm texts)		
Email addresses	The email is sent to up to 3 email addresses (each with max. 64 characters) at the same time.	
	1	Enter first email address
	2	Enter second email address
	3	Enter third email address
Alarm signal	Signal that triggers sending of an email.	
	No selection Digital signal	No alarm message Alarm message is triggered by a signal (high active), which must be selected from the list of digital signals (digital selector).
Subject	Text (max. 120 characters) for the subject line of the email	
	Mail Subject 01 (For email 1)	Enter text (or use default text)
Contents	Text (max. 120 characters) for the text field of the email	
	Mail Text 01 (For email 1)	Enter text (or use default text)

9 Configuration – in setup program only



NOTE!

Email transmission should be tested in the scope of startup. If there is an error, this leads to an entry with an error code in the device's event list.

The interface description contains a list of all error codes ("Error codes as integer return values").

9.4.1 Email server



NOTE!

The following settings may only be performed by qualified personnel.

Setup dialog box

The dialog box titled "E-Mail-Server" contains the following fields and options:

- Authentication: None (dropdown)
- User name: Your user name (text field)
- Password: Your password (text field)
- SMTP-Server: smtp.example.net (text field)
- Encryption: None (dropdown)
- SMTP port number: 25 (text field)
- Sender (E-Mail-Address): device@example.net (text field)

Caution:
Characters other than A..Z, a..z, 0..9, -, _, @, ., may cause problems!

Buttons: OK, Cancel

Parameter

Parameter	Selection/settings	Description
Authentication	Authentication at logon to email server	
	None SMTP-Auth	No authentication Authentication with user name and password on SMTP server
User name	User name (max. 64 characters) for logging onto the email server	
	Your user name (Example)	Enter name (also applies if Authentication = no).
Password	Password (max. 64 characters) for logging on to the email server	
	Your password (Example)	Enter password (only for SMTP Auth).
SMTP server	Address (URL, max. 64 characters) of the email server for SMTP	
	smtp.example.net (Example)	Enter server address.
Encryption	Type of encryption between email client and email server (depending on the email provider)	
	None	Unencrypted
	TLS	Transport Layer Security (formerly: SSL)
	StartTLS	TLS where the connection is unencrypted to begin with (encryption takes place while the connection is being established)

9 Configuration – in setup program only

Parameter	Selection/settings	Description
SMTP port number	Port number of the email server for SMTP	
	25 (normally: TLS = 465, StartTLS = 587)	Change the port number if applicable (depending on the email provider and type of encryption).
Sender (email address)	Email address (max. 64 characters) as sender address	
	device@example.net (Example)	Enter address.

9 Configuration – in setup program only

9.5 Web server

The integrated web server provides the user with convenient access to process values, various visualizations, and the device's alarm and event list from a web browser. Access can be password protected.

The device has a maximum of 2 MB memory for HTML pages. The start page, index.htm, is available by default; access with the web browser is performed by entering the device's IP address. If needed, you can also use the DNS device name.




NOTE!

Online visualization in version 336.xx.xx (old variant):

The Microsoft Silverlight¹ plug-in is required for this function. If the plug-in is not present, the web browser displays a note and offers to install it.

Supported web browser: Microsoft Internet Explorer¹

Setup dialog box



Online visualization

The online visualization is configurable as a standard version or user version.

In the **Standard version** a distinction is made between a standard device and an FDA device (extra code 888):

- Standard device (version: standard): all functions are available.
- FDA device (version: 21 CFR Part 11): the "Import" and "Delete" functions are locked; the FDA compliant web application that is created by the manufacturer is always transferred to the device. Only data is displayed in the web browser; entering comments is not possible.

The **User version** does not include a default web application. Creation and use of the web application are the customer's responsibility. All functions are available.

¹ Microsoft, Silverlight, and Internet Explorer are registered trademarks of the Microsoft Corporation.


9 Configuration – in setup program only

Function of buttons

Button	Designation	Description
	Import Web	Select the folder that contains the files required for the Web application (incl. HTML files).
	Export Web	Select the folder to which the files used for the Web application should be exported.
	Delete Web	After answering the confirmation prompt, all files (except index.htm) are removed from the setup file.
	HTML tags 	HTML tags are used to convert names of variables into addresses for Web server programming.
	Security 	The user name and password for logging on and the time until the next automatic logoff are defined here.

HTML tags


To open this window, use the "HTML tags" button:



Select the required variable names from the relevant selectors.

Security

To open this window, use the "Security" button:



9 Configuration – in setup program only

Parameter

Parameter	Selection/settings	Description
Password active	Yes (☒) , No (☐)	If "Yes," the user needs to log on with their user name and password to be able to access the website. No logon is required for "No".
User name	Master (ASCII; max. 31 characters)	User name for logon to the Web server
Password	9200 (ASCII; max. 31 characters)	Password for logging onto the web server
Timeout	0 ... 65535 min	Time until automatic logout if no user activity is detected. 0 min = No automatic logout

9 Configuration – in setup program only

9.6 Electronic signature

This menu item is included if extra code 888 (FDA) is available.

These settings are significant for the appearance and text entry during an electronic signature. If an electronic signature can even be provided – or whether it must be provided – depends on the configuration in the PC Security Manager software PCS.

See operating manual for PC Security Manager software PCS.

Setup dialog box

Parameter

Parameter	Selection/settings	Description
Designation of the parameters		
Meaning	Enter text (or use default text).	Designation of the parameter in the device The text that is entered here is used as a heading or row designation in the respective device dialog box. During the electronic signature an evaluation text that describes the meaning of the signature (for what is being signed) can be entered.
Signature	Enter text (or use default text).	Designation of the parameter in the device The text that is entered here is used as a heading or row designation in the respective device dialog box.
Settings for text selection		
The following parameters decide whether an evaluation text that describes the meaning of the signature (e.g. "Batch o.k.") can be used for an electronic signature.		
The parameters need to be set separately for the following applications:		
- Batches: signature for completed batches - Logoff: signature when logging off - PCA3000: subsequent signature for a completed batch in the PC evaluation software PCA3000 - Time period: signature for a certain time period		

9 Configuration – in setup program only

Parameter	Selection/settings	Description
Display text list	Yes (☒) , No (☐)	By selecting "Yes" the evaluation text (meaning) can be selected from the text list.
First text	1 to ...	First selectable text (text number) in the text list
Number of texts	1 to 50	Number of selectable texts (as of the first text)
Editable	Yes (☒) , No (☐)	By selecting "Yes" any text can be entered or – when displaying text list = "Yes" – the text can be edited in the text list. By selecting "No" and displaying text list = "No" the result is the signature without evaluation text.

9 Configuration – in setup program only

9.7 Modbus frames for reading

This function is used to compile up to 32 Modbus frames for reading process values from external devices (via interface) individually for each opposite end. The process values (analog and digital values; texts) are written to the selected variables (external inputs and texts) from the received Modbus telegram and are available for use in the paperless recorder.

Each frame can be used to configure up to 24 frame entries with a process value each, which are then grouped and transmitted in a Modbus telegram.

Setup dialog box

No.	External input	Modb.add...	Modb.add...	Data type	Bit posi...	Factor
1	Process values\No selection	0x0000	0x8000	None	-	-
2	Process values\No selection	0x0000	0x8000	None	-	-
3	Process values\No selection	0x0000	0x8000	None	-	-
4	Process values\No selection	0x0000	0x8000	None	-	-
5	Process values\No selection	0x0000	0x8000	None	-	-
6	Process values\No selection	0x0000	0x8000	None	-	-
7	Process values\No selection	0x0000	0x8000	None	-	-
8	Process values\No selection	0x0000	0x8000	None	-	-
9	Process values\No selection	0x0000	0x8000	None	-	-
10	Process values\No selection	0x0000	0x8000	None	-	-
11	Process values\No selection	0x0000	0x8000	None	-	-
12	Process values\No selection	0x0000	0x8000	None	-	-
13	Process values\No selection	0x0000	0x8000	None	-	-
14	Process values\No selection	0x0000	0x8000	None	-	-



CAUTION!

A variable can be used in multiple frames.

This means that different process values are written to the same variable.

- The user has to make sure that a variable is not overwritten unintentionally.

Configuration and use of the Modbus frames for reading are described in the interface description.

⇒ chapter 1.6.2 "Device documentation in the form of PDF files", Page 15

9 Configuration – in setup program only

9.8 Modbus frames for writing

This function can be used to compile up to 32 Modbus frames for writing the paperless recorder's process values to external devices (via interface) individually for each opposite end. The paperless recorder writes the process values (analog and digital values; texts) to the frames, where they are available for external devices.

Each frame can be used to configure up to 24 frame entries with a process value each, which are then grouped and transmitted in a Modbus telegram.

Setup dialog box

Modbus-Frames for writing

Frame 1Frame 2Frame 3Frame 4Frame 5Frame 6Frame 7Frame 8Frame 9Frame 10Frame 11Frame 12Frame 13

Comment:

Frame 01

Interface:

Modbus-Slave

Device address:

1

Modbus start address:

0x0000

0x9000

Master: Zu schreibende Adresse

Slave address for ext. master

No.	Process value	Modb.add...	Modb.add...	Data type	Bit posi...	Factor
1	Process values\No selection	0x0000	0x9000	None	-	-
2	Process values\No selection	0x0000	0x9000	None	-	-
3	Process values\No selection	0x0000	0x9000	None	-	-
4	Process values\No selection	0x0000	0x9000	None	-	-
5	Process values\No selection	0x0000	0x9000	None	-	-
6	Process values\No selection	0x0000	0x9000	None	-	-
7	Process values\No selection	0x0000	0x9000	None	-	-
8	Process values\No selection	0x0000	0x9000	None	-	-
9	Process values\No selection	0x0000	0x9000	None	-	-
10	Process values\No selection	0x0000	0x9000	None	-	-
11	Process values\No selection	0x0000	0x9000	None	-	-
12	Process values\No selection	0x0000	0x9000	None	-	-
13	Process values\No selection	0x0000	0x9000	None	-	-
14	Process values\No selection	0x0000	0x9000	None	-	-

Frame lenght:

0

Error value: ☐

3e+37

Copy

Edit

OK

Cancel

Copy

Import

Configuration and use of the Modbus frames for writing are described in the interface description.

⇒ chapter 1.6.2 "Device documentation in the form of PDF files", Page 15

9 Configuration – in setup program only

9.9 PROFINET

The paperless recorder can also be equipped with a PROFINET interface and integrated into a PROFINET network as an IO device as an optional extra. The interface also supports simultaneous use of Ethernet standard services; thus Ethernet interfaces as a standard feature are omitted.

A GSD file (GSDML) is available for the programming system of the IO controller and describes the features of the paperless recorder.

Setup dialog box

Off...	Slot ID	Data type	ID table	Remark
00.0	Value 1	Bit field 8 bits	Collective alarm\Collective alarm device	
00.1	Value 2	Bit field 8 bits	Collective alarm\Collective alarm acknowledged	
00.2	Value 3	Bit field 8 bits	Collective alarm\Collective alarm (internal)	
00.3	Value 4	Bit field 8 bits	Collective alarm\Log -On	
00.4	Value 5	Bit field 8 bits	Collective alarm\Malfunction	
00.5	Value 6	Bit field 8 bits	Collective alarm>Error PROFIBUS	
00.6	Value 7	Bit field 8 bits	Collective alarm\Battery empty pre-warning	
00.7	Value 8	Bit field 8 bits	Collective alarm\Battery empty	
01.0	Value 9	Bit field 8 bits	Collective alarm\External USB 1 plugged in	
01.1	Value 10	Bit field 8 bits	Collective alarm\Temp. in Fahrenheit (Operation)	
01.2	Value 11	Bit field 8 bits	Relay\Relay 1\Relay	
01.3	Value 12	Bit field 8 bits	Current batch\Batch 1\Batch active	
01.4	Value 13	Bit field 8 bits	ID disabled\Null Digital	

Configuration and use of the PROFINET interface are described in the PROFINET-IO interface description.

⇒ chapter 1.6.2 "Device documentation in the form of PDF files", Page 15

9 Configuration – in setup program only

9.10 ST code

The user has the option to create his/her own application using the "structured text" option (extra code). The application is created with the ST editor, which is part of the setup program, in the PLC programming language "structured text". The finished application is transmitted to the device and continuously processed there. There is a debugger function available for testing and troubleshooting.



NOTE!

This function is available in the setup program if the "ST code" extra code has been activated (Basic device > Additional module: ST code). To access this function in the device, it must be enabled with the setup program (online parameters > Enabling of extra codes).

Setup dialog box

Variables bool_in01 to bool_in40

Parameter	Selection/text/value	Description
Digital signal	Digital selector No selection	Source of the Boolean input variables
Description	<Enter text> Use default text or enter other text.	Description or abbreviation of variables

Variables real_in01 to real_in40

Parameter	Selection/text/value	Description
Analog signal	Analog selector No selection	Source of the real input variables
Description	<Enter text> Use default text or enter other text.	Description or abbreviation of variables

9 Configuration – in setup program only

Variables bool_out01 to bool_out40

Parameter	Selection/text/value	Description
Description	<Enter text> Use default text or enter other text.	Description of the Boolean output variables
Designation	<Enter text> Use default text or enter other text.	Abbreviation of variables

Variables real_out01 to real_out40

Parameter	Selection/text/value	Description
Description	<Enter text> Use default text or enter other text.	Description of the real output variables
Designation	<Enter text> Use default text or enter other text.	Abbreviation of variables
Temperature		This selection is important for the automatic conversion in case of a change in temperature unit (°C/°F) (see system data).
	None	The value is not a temperature.
	Relative	The value is a temperature difference.
	Absolute	The value is a temperature value.
Unit	<Enter text> %	Value unit (if it is not a temperature)
Scaling start	-99999 to 99999 (0)	Minimum admissible value
Scaling end	-99999 to 99999 (100)	Maximum admissible value
Decimal places		Number of pre-decimal and decimal places for displaying the value
	Auto	Automatic
	XXXX.	No decimal place
	XXX.X	One decimal place
	XX.XX	Two decimal places
	X.XXX	Three decimal places

Variables alarm01 to alarm08

Parameter	Selection/settings	Description
Activation	Off On	Alarm (signal monitoring) is inactive. Alarm (signal monitoring) is active.
Alarm/Event list 	Off Event Alarm	In the event of an alarm, only the alarm signal is activated. The alarm/event text is entered in the event list. The alarm/event text is entered in the alarm list and the event list. The collective alarm is activated and the text of the last alarm to occur is displayed in the status bar.

9 Configuration – in setup program only

Parameter	Selection/settings	Description
Alarm active at	High (1) Low (0)	Alarm at high level (1) Alarm at low level (0)
Alarm/Event text	Use default text or enter other text.	Text entered in the alarm and event list and displayed in the status bar.
Alarm delay 	0 s to 999 s	Delay time for activation of the alarm signal
Alarm suppression 	Digital selector No selection	The selected digital signal (high-active) prevents the alarm signal being activated.

Alarm/Event list

All events and their time of occurrence are added to the event list. If the event is an alarm, newly occurring alarms and their time of occurrence are additionally added to the alarm list. If an alarm is made inactive, it is removed from the alarm list and the time of removal is added to the event list.

Alarm delay

In the event of an alarm (parameter "Alarm active at"), the alarm signal is not activated until the delay time has expired. If the alarm case is left in the meantime, the timer restarts when a new alarm case occurs.

Alarm delay, alarm suppression

Alarm delay and alarm suppression delay or prevent entries being added to the event list and alarm list, activation of the collective alarm, and display in the status bar.

ST editor

Press the corresponding button to start the ST editor.

There is a separate manual for the ST editor available with further information.

⇒ chapter 1.6.2 "Device documentation in the form of PDF files", Page 15

9 Configuration – in setup program only

9.11 Customized linearization

You can use the customer-specific linearization to create a customized linearization characteristic line for analog inputs. This characteristic line is used for all analog inputs for which the corresponding linearization has been selected in the configuration.

Customer-specific linearization can only be programmed with the setup program. Two procedures are available for this (type of linearization): formulas or grid values (value pairs).

In the case of RTD temperature probes, linearization can additionally be performed using the alpha, beta, and gamma value in combination with the basic value (R0) and the measuring range start/end.


Up to four linearization tables can be created and used simultaneously for different analog inputs.



NOTE!

It is possible to create different characteristic lines with grid values and formulas. The characteristic line that matches the formula is authoritative for use in the module, however. If the grid values and formula are not compatible when you press "OK" to exit the dialog, a warning is output. You can then delete the grid points or recalculate the formula on the basis of the grid values.

Signal flow



- | | |
|--|--|
| (1) Measured value | (4) Offset (normalized) |
| (2) Monitoring of measured values for standard signals (limits as per NAMUR) | (5) Monitoring of linearized values with regard to scaling (configuration parameter: Scaling start, Scaling end) |
| (3) Linearization (grid points/formula) | (6) Linearized value |
- Grid points: Monitoring of the definition range (measured values)
Formula: Monitoring of the value range (linearized values) with regard to the measuring range (configuration parameter: Measuring range start, Measuring range end)

9 Configuration – in setup program only

Measured value

The following table shows the admissible measured value range of the analog inputs as a function of the selected sensor. These values represent the minimum and maximum input values of customer-specific linearization.

Sensor	Lower limit	Upper limit	Comment
RTD temperature probe	0 Ω	400 Ω or 4000 Ω	Upper limit depending on configuration
Thermocouple	0 mV	100 mV	
Resistance transmitter	0 %	100 %	Loop generation as a percentage of the total resistance (max. 4000 Ω)
Resistance/potentiometer	0 Ω	400 Ω or 4000 Ω	Upper limit depending on configuration
Current 0 ... 20 mA	0 mA	20.625 mA	Underrange is not detected.
Current 4 ... 20 mA	3.8 mA	20.5 mA	
Voltage 0 ... 70 mV	-0.875 mV	72.1875 mV	
Voltage 0 ... 1 V	-0.0125 V	1.03125 V	
Voltage -1 ... +1 V	-1.025 V	1.0625 V	
Voltage 0 ... +10 V	-0.125 V	10.3125 V	
Voltage -10 ... +10 V	-10.25 V	10.625 V	



NOTE!

The measured value is monitored for current and voltage signals. The current and voltage values stated in the table are limits based on the NAMUR recommendation NE 43 (exception: lower limit for current 0 ... 20 mA). A measured value outside of these limits results in a deviation above or below the measuring range (out of range).

Linearization

Depending on the selected linearization type, the definition range or value range of the linearization is monitored.

⇒ chapter 9.11.1 "Formula", Page 230

⇒ chapter 9.11.2 "Grid values", Page 231

Linearized value

The linearized value is monitored with regard to the scaling range (start, end). The range of the linearized values (possibly incl. offset) is thus delimited as follows:

Lower limit = Minimum (start, end) - |end - start| × 0.0125

Upper limit = Maximum (start, end) + |end - start| × 0.03125



NOTE!

A linearized value outside of these limits results in a deviation above or below the measuring range (out of range).



NOTE!

A linearized value that represents a temperature value must be given only in °C.

9 Configuration – in setup program only

9.11.1 Formula

Customer-specific linearization is specified using a 4th order polynomial. The polynomial is calculated for the entire linearization range.

Polynomial formula: $y = X4 \cdot x^4 + X3 \cdot x^3 + X2 \cdot x^2 + X1 \cdot x + X0$

Setup dialog box

Parameter

Parameter	Selection/settings	Description
Measuring range start (Ymin)	-99999 ... 0 ... +99999	Start value of the y axis Always give a temperature value in °C.
Measuring range end (Ymax)	-99999 ... 100 ... +99999	End value of the y axis Always give a temperature value in °C.
X0	-99999 ... 0 ... +99999	Absolute component of the polynomial (point of intersection with the y axis)
X1	-99999 ... 1 ... +99999	Coefficient of the linear component (x)
X2	-99999 ... 0 ... +99999	Coefficient of the quadratic component (x ²)
X3	-99999 ... 0 ... +99999	Coefficient of the cubic component (x ³)
X4	-99999 ... 0 ... +99999	Coefficient of the quartic component (x ⁴)

The value range for the linearization (linearized values, y axis) is monitored in the module and limited as follows:

Lower limit of the value range = $Ymin - 0.0125 \times (Ymax - Ymin)$

Upper limit of the value range = $Ymax + 0.03125 \times (Ymax - Ymin)$



NOTE!

A linearized value that lies outside of the value range results in a deviation above or below the measuring range (out of range).

9 Configuration – in setup program only

Displaying linearization on a graphic ("Display graphic" button)

Use this button to create a graphic of the linearization.

The graphic includes the characteristic lines for both types of linearization where applicable, namely the formula and the grid points (table).

The display range for the graphic is initially determined by the "measuring range start" and "measuring range end" values (y values); it can be temporarily changed in the display by entering different x values.

9.11.2 Grid values

Customer-specific linearization is specified by entering up to 40 grid points (pairs of values X/Y). The value of X stands for the physical measured value (e.g., voltage in mV, current in mA, or resistance in ohm; depending on the sensor type) and the value of Y stands for the linearized value (e.g., temperature in °C).

Setup dialog box

Customer-specific linearization

Table 1 Table 2 Table 3 Table 4

Name: Cust1

Description: Customer-specific 01

Type of linearization: Supporting values

Measuring range-Start: 0

Measuring range-End: 100

Basic values

	Measurement value (X)	Linearized value (Y)
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		

Formula

y = 0 · x⁴ + 0 · x³ + 0 · x² + 1 · x + 0

Display graphic Update graphic OK Cancel

Parameter

Parameter	Selection/settings	Description
Measured value (X)	-99999 ... 0 ... +99999	Value of the relevant grid point on the x axis
Linearized value (Y)	-99999 ... 0 ... +99999	Value of the relevant grid point on the y axis Always give a temperature value in °C.

The definition range of linearization (measured values, x axis) is monitored in the module and delimited as follows:

Lower limit of the definition range = $X_{min} - 0.0125 \times (X_{max} - X_{min})$

Upper limit of the definition range = $X_{max} + 0.03125 \times (X_{max} - X_{min})$

9 Configuration – in setup program only



NOTE!

A measured value outside of the definition range results in a deviation above or below the measuring range (out of range).

Displaying linearization on a graphic ("Display graphic" button)

Use this button to create a graphic of the linearization.

The graphic includes the characteristic lines for both types of linearization where applicable, namely the grid points (table) and the formula.

The display range for the graphic is initially determined by the smallest and largest grid points; it can be temporarily changed in the display by entering different x values.

Calculating the polynomial using the grid points ("fx" button)

After entering the value pairs, use this button to calculate a polynomial that describes the progression of the linearization characteristic line.

The calculated coefficients are incorporated into the formula. The characteristic lines for both types of linearization then correspond to each other.

If the x values do not increase in a straight line, the linearization is not applied. In this case, it is impossible to display the graphic or calculate the polynomial.

9 Configuration – in setup program only


9.12 Process screens

Process screens are used for visualizing process data. The setup program can be used to create individual process screens that are transferred to the device and are available there in the "View" menu.

The size of a process screen (background) is 640 pixels (width) by 379 pixels (height).

9.12.1 Process screen editor

Setup dialog box



(1)	Object list	(2)	Object used
(3)	Selected process screen	(4)	Activate process screen
(5)	Select background image	(6)	Name of the process screen
(7)	Select background color	(8)	Navigation and processing functions
(9)	Exit process screen editor; settings are not adopted	(10)	Exit process screen editor; settings are adopted
(11)	Preview of the process screen (preview screen is opened in the setup program)		

Navigation and processing functions

Button	Function
	Cut object from the object list

9 Configuration – in setup program only

Button	Function
	Copy object to another object (only within the same process screen)
	Paste cut object into the object list
	Add new object to the object list
	Remove object from the object list
	Move object up in object list
	Move object down in object list
	Edit object

Create process screen

A process screen is created in the following way:

1. Select the process screen to be created (tab) by left-clicking on it.
2. Select the object (Objects 1 to 100) in the object list by left-clicking on it.
3. Start editing the object features by using the left mouse button to double-click on the selected object or by clicking the () symbol.
4. Edit features and close the dialog with OK.
5. Inspect the object in the preview screen. Change the features of the object if required.
6. Select and edit additional objects.
7. Change the default name of the process screen (if required).
8. Configure the background image ("Background") and the background color, if required (the background color can only be seen if the background image does not cover the entire process screen area or if the "Transparent" option was selected when importing the image).
9. Activate the process screen (only activated process screens are transferred to the device).
10. OK transfers the process screen to the setup file.
11. Transfer the setup file to the device.
12. On the device, select the "Process screen" visualization (view).


9.12.2 Background

In addition to the background color, a background image can also be used for the background of the process screen. The background image is selected from the list of available screens in the setup program. If the background color is to be visible, the background image must not cover the entire area of the process screen or it must be transparent (option when replacing a screen).

The list can contain up to 100 images that are used as the background image or pictogram. 10 MB storage space is available on the device for all images. The required storage space is determined in the setup program; it may thus be impossible to add more images to the list.

9 Configuration – in setup program only


Setup dialog box



Parameter

Parameter	Selection/settings	Description
Image name	Selection from list of images	Background image for the process screen
X position	0 ... 639	X coordinate of the upper left corner of the background image in the process screen
Y position	0 ... 378	Y coordinate of the upper left corner of the background image in the process screen
Visible	Yes (☒) , No (☐)	"Yes" releases the display of the background image in the process screen.
Centered	Yes (☒) , No (☐)	"Yes" horizontally and vertically centers the background image in the process screen (X and Y position are then unimportant).

The "..." button is used to open the list of the available images in the setup program:



"Replace" button: The selected image is replaced by a different image, which must be selected from a file directory as a graphic in BMP or PNG format (max. 640 × 379 pixels; 16-bit color depth). During this process, the name (title) under which the image appears in the list can be changed so that it is different from the file name. If the "Transparency: Color pixel top left" option is active (checked), all pixels or areas that use the same color as the pixel top left are transparent in the process screen.



NOTE!

For an image to be displayed correctly in the online visualization, it should always be imported as a PNG format graphic. Transparent areas must be created with a graphics program up front. The "Transparency: Color pixel top left" option cannot be used for this.

9 Configuration – in setup program only



NOTE!

If you import an image with a higher resolution, the process screen editor scales the image to the maximum admissible size. The aspect of the original image is kept. Similarly the color depth of the image is reduced to 16-bit if the image file you are importing uses more colors.

"Export" button: the selected pictogram is saved in a file directory as a graphic in BMP format.

9.12.3 Object types

The following object types are available when editing object features:

Type	Description
Pictogram	The status of a digital signal is graphically depicted using two pictograms (icons or images).
Analog signal	The value of an analog signal is displayed in numerical form (e.g. 123.45).
Digital signal	The status of a digital signal is displayed within a frame via a text (e.g. Low, High).
Text	Text that is displayed in the process screen. This is a fixed text that is entered when editing the object.
Frame	Frame for grouping or highlighting objects The area within the frame is transparent and is automatically placed in the background. An object (e.g., text or image) located within this frame is made visible as a result.
Rectangle	Rectangle for grouping or highlighting objects Unlike the frame, the rectangle is not transparent (separate color can be set). As a result, objects can be arranged against a background with a color that differs from that of the general background color.
Bar graph	The value of an analog signal is displayed as a bar graph (vertical or horizontal).
Universal display	Field for displaying the features of an analog signal (e.g., channel designation, scaling, unit, limit value)
Float value entry	Field for entering a float value The value is assigned to an analog variable (selection from a selector).
Text entry	Field for entering a text The text is assigned to a text variable (selection from a selector).
Digital value entry	Field for selecting a binary value (low, high) The value is assigned to a digital variable (selection from a selector).
Text selection from list	Field for selecting a text from the text list The text can be selected from a defined area of the text list. Depending on the configuration, the text is written to a text variable. The number of the selected text can be written to an analog variable.
Text selection by value	Text that is displayed in the process screen. This concerns a text from the text list. The text selection is controlled via an analog signal that determines the text number.

9 Configuration – in setup program only

9.12.4 General object features

The description of the general object features applies for all object types for which the parameters in question are available.

The specific object features are described in the following chapters under the corresponding object type.

Setup dialog box

The screenshot shows the 'Objects' dialog box with the following settings: Type is set to a dropdown menu; Object name is empty; X-Position is 10; Y-Position is 20; Width is 50; Height is 20; Visual is checked; Editable is checked; Background colour is set to a color picker; Transparent is unchecked; Frame shape is Thin; Foreground colour is set to a color picker; Font size is 15 Pixel; Orientation is Left-aligned; and another Orientation is Horizontally. The OK and Cancel buttons are at the bottom right.

Parameter

Parameter	Selection/settings	Description
Type	Selection from list of object types	Object type for the process screen
Object name	Enter text (max. 24 characters) Blank (no object name)	In the ST editor, the object ID can be accessed via the object name. If an object name is assigned, it must be unique within the process screen.
X position	0 ... 10 ... 639	X coordinate of the upper left corner of the object in the process screen
Y position	0 ... 20 ... 378	Y coordinate of the upper left corner of the object in the process screen
Width	1 ... 50 ... 640	Width of the object
Height	1 ... 20 ... 379	Height of the object
Visible	Yes (☒) , No (☐)	"Yes" releases the display of the object in the process screen.
Editable	Yes (☒) , No (☐)	"Yes" enables the option for entry in the process screen (only for input objects).
Background color	Select color (drop-down menu).	Background color of the object
Transparent	Yes (☒) , No (☐)	If "Yes", the background color of the object is not active. Instead, the font will be displayed in front of the background color of the process screen.
Frame form	Select form (drop-down menu).	The object can be provided with a frame.

9 Configuration – in setup program only

Parameter	Selection/settings	Description
Foreground color 	Select color (drop-down menu).	Font color within the object
Font size	Select font size (drop-down menu).	Font size within the object
Alignment	Select alignment (drop-down menu).	Alignment of the font within the object (left-aligned, right-aligned, centered)
Orientation	Select orientation (drop-down menu).	Orientation of the object in the process screen (horizontal, vertical; not for input objects).

Foreground color

In order for the font to be visible, the foreground and background color must be different from each other. If the "Transparent" setting is selected (☒) , this applies with regard to the background color of the process screen.

Preview

If the dialog is exited using the "OK" button, the preview screen opens in the setup program.

⇒ chapter 9.12.18 "Preview", Page 253

9 Configuration – in setup program only

9.12.5 Pictogram

Setup dialog box

Objects

Type:

Pictogram

Object name:

☒ Visual

☒ Editable

X-Position:

Y-Position:

Signal source:

No selection

Image digital signal = TRUE

Kein Bild

...

No image

Image digital signal = FALSE

Kein Bild

...

No image

OK

Cancel

Parameter

Parameter	Selection/settings	Description
Signal source	Digital signal whose status is displayed via the corresponding pictogram.	
	No selection	No signal selected. (Pictogram for FALSE (0) will be displayed.)
	Select signal.	Digital selector
Image digital signal = TRUE	Select the "..." button and select the image from the list (or select "No image").	Pictogram for displaying the status TRUE (1).
Image digital signal = FALSE	Select the "..." button and select the image from the list (or select "No image").	Pictogram for displaying the status FALSE (0).

9 Configuration – in setup program only

9.12.6 Analog signal

Setup dialog box

Objects

Type: Analog signal

Object name:

Visual

Editable

X-Position: 10

Y-Position: 20

Width: 50

Height: 20

Signal source:

Comma format: Auto

No selection

Background colour:

Transparent:

Frame shape: Thin

Foreground colour:

Font size: 15 Pixel

Orientation: Left-aligned

Orientation: Horizontally

Warning

In this font, only a limited ANSI character set (255 characters) is available in the device!

OK

Cancel

Parameter

Parameter	Selection/settings	Description
Signal source	Analog signal whose value within the object is displayed numerically.	
	No selection	No signal selected. (Display: -----)
	Select signal.	Analog selector
Decimal places	Select format (drop-down menu).	Number of decimal places of the displayed value

240

9 Configuration – in setup program only

9.12.7 Digital signal

Setup dialog box

Objects

Type: Digital signal

Object name:

☒ Visual

☒ Editable

X-Position: 10

Y-Position: 20

Width: 50

Height: 20

Signal source:

No selection

Background colour:

Transparent:

Frame shape: Thin

Colour for low:

Colour for high:

Font size: 15 Pixel

Orientation: Left-aligned

Orientation: Horizontally

Text Low: Low

Text High: High

Warning

In this font, only a limited ANSI character set (255 characters) is available in the device!

OK

Cancel

Parameter

Parameter	Selection/settings	Description
Signal source	Digital signal whose status within the object is displayed via a text.	
	No selection	No signal selected. (Text for low condition will be displayed.)
	Select signal.	Digital selector
Color for low	Select color (drop-down menu).	Font color (Text Low) within the object (foreground color)
Color for high	Select color (drop-down menu).	Font color (text high) within the object (foreground color)
Text Low	Enter text (or use default text).	Text for low condition
Text High	Enter text (or use default text).	Text for high condition

9 Configuration – in setup program only

9.12.8 Text

Setup dialog box

Objects

Type:

Text

Object name:

☒ Visual

☒ Editable

X-Position:

Y-Position:

Width:

Height:

Text source:

Process values

No selection

Background colour:

Transparent: ☐

Frame shape:

Thin

Foreground colour:

Font size:

15 Pixel

Orientation:

Left-aligned

Orientation:

Horizontally

Text:

Warning

In this font, only a limited ANSI character set (255 characters) is available in the device!

OK

Cancel

Parameter

Parameter	Selection/settings	Description
Text source	Text source whose text is displayed within the object.	
	No selection Select signal.	No text source selected. The selection must be of the "Text" data type.
Text	Enter text	Text that is displayed within the object. This text is used if no text source was selected, or if the text source does not return any text.

9 Configuration – in setup program only

9.12.10 Rectangle

Setup dialog box

Objects

Type: Rectangle

Object name:

☒ Visual

X-Position: 10

Width: 50

☒ Editable

Y-Position: 20

Height: 20

Foreground colour:

Frame shape:

Thin

OK

Cancel

Parameter

Parameter	Selection/settings	Description
Color	Select color (drop-down menu).	Color of the rectangle surface Unlike the frame, the rectangle is not transparent, although it is automatically in the background. As a result, objects can be arranged against a background with a color that differs from that of the general background color.
Frame form	Select form (drop-down menu).	The rectangle can also be provided with a (black) frame.

9 Configuration – in setup program only

9.12.11 Bar graph

Setup dialog box

The screenshot shows the 'Objects' dialog box with the 'Type' set to 'Bargraph'. The 'Object name' field is empty. The 'Visual' and 'Editable' checkboxes are checked. The 'X-Position' is 10, 'Y-Position' is 20, 'Width' is 50, and 'Height' is 20. The 'Signal source' dropdown is set to 'No selection'. The 'Foreground colour' is black. The 'Transparent' checkbox is unchecked. The 'Frame shape' is 'Thin'. The 'Colour for Off' and 'Colour for On' are both black. The 'Orientation' is 'Horizontally'. The 'Display details' checkbox is unchecked. The 'OK' and 'Cancel' buttons are at the bottom right.

Parameter

Parameter	Selection/settings	Description
Signal source	Analog signal whose value is displayed as a bar graph.	
	No selection	No signal selected. (Display: Bar at "0")
	Select signal.	Analog selector
Foreground color	Select color (drop-down menu).	Color for displaying details
Color for off	Select color (drop-down menu).	Color of the bar background within the object (background color)
Color for on	Select color (drop-down menu).	Color of the bar within the object (foreground color)
Show details	Yes (☒) , No (☐)	If "Yes," alarms (Alarm 1 left, Alarm 2 right) and range limits (upper and lower) are displayed (only in the case of a vertical view).

9 Configuration – in setup program only

9.12.12 Universal display

Setup dialog box

The screenshot shows the 'Objects' dialog box with the 'Type' set to 'Universal display'. The 'Object name' field is empty. The 'Visual' and 'Editable' checkboxes are checked. The 'X-Position' is 10, 'Y-Position' is 20, 'Width' is 50, and 'Height' is 20. The 'Signal source' dropdown is set to 'No selection'. The 'Background colour' is a light blue, 'Transparent' is unchecked, 'Frame shape' is 'Thin', and 'Foreground colour' is black. The 'Font size' is 15 Pixel, 'Orientation' is 'Left-aligned', and 'Orientation' is 'Horizontally'. The 'Display type' dropdown is set to 'Channel designation'. A warning box states: 'In this font, only a limited ANSI character set (255 characters) is available in the device!'. The 'OK' and 'Cancel' buttons are at the bottom right.

Parameter

Parameter	Selection/settings	Description
Signal source	Analog signal whose feature is displayed.	
	No selection	No signal selected (the process screen shows an empty field with the background color).
	Select signal.	Analog selector
Display type	Select the display type (drop-down menu).	The display type (analog signal feature) is displayed in the process screen.

Display type

The following display types are available:

- Channel designation, channel description
- Scaling start, scaling end
- Unit
- Limit value Alarm 1, limit value Alarm 2
- Hysteresis (switching differential) alarm 1, hysteresis alarm 2

9 Configuration – in setup program only

9.12.13 Float value entry

Setup dialog box

Objects

Type:

Input float value

Object name:

☒ Visual

☒ Editable

X-Position:

10

Y-Position:

20

Width:

50

Height:

20

Destination:

Comma format:

Auto

Background colour:

Transparent: ☐

Frame shape:

Without

Foreground colour:

Minimum value:

0

Maximum value:

100

Font size:

15 Pixel

Orientation:

Left-aligned

OK

Cancel

Parameter

Parameter	Selection/settings	Description
Destination	Variable in which the entered value is written.	
	No selection Select variable.	No variable selected. Analog selector (external analog input 1 to ...; limit value monitoring 1 to ...: limit value and switching differential)
Decimal places	Select format (drop-down menu).	Number of decimal places of the displayed value
Minimum value	-99999 to 99999 (0)	Lower limit of the admissible input range
Maximum value	-99999 to 99999 (100)	Upper limit of the admissible input range

9 Configuration – in setup program only

9.12.14 Text entry

Setup dialog box

Objects

Type:

Text input

Object name:

☒ Visual

☒ Editable

X-Position:

Y-Position:

Width:

Height:

Destination:

Process values

No selection

Number of characters:

Background colour:

Transparent: ☐

Frame shape:

Thin

Foreground colour:

Font size:

15 Pixel

Orientation:

Left-aligned

Warning

In this font, only a limited ANSI character set (255 characters) is available in the device!

OK

Cancel

Parameter

Parameter	Selection/settings	Description
Destination	Variable in which the entered text is written.	
	No selection Select variable.	No variable selected. Text selector (external text (long) 1 to ...; external event text (long) 1 to ...)
Number of char- acters	1 to 160 (100)	Maximum number of characters that can be entered.

9 Configuration – in setup program only

9.12.15 Digital value entry

Setup dialog box

The 'Objects' dialog box is used to configure a digital value entry object. It includes the following settings:

- Type:** Input digital value (selected in the dropdown)
- Object name:** (empty text field)
- Visual:** ☒ (checked)
- Editable:** ☒ (checked)
- X-Position:** 10
- Y-Position:** 20
- Width:** 50
- Height:** 20
- Destination:** (empty dropdown)
- Display mode:** Text (selected in the dropdown)
- Toggle function:** ☐ (unchecked)
- Background colour:** (empty dropdown)
- Transparent:** ☐ (unchecked)
- Frame shape:** Thin (selected in the dropdown)
- Color for Low:** (black color selection)
- Color for High:** (black color selection)
- Text Low:** Low (selected in the dropdown)
- Text High:** High (selected in the dropdown)
- Image digital signal = TRUE:** Kein Bild (button)
- Image digital signal = FALSE:** Kein Bild (button)
- Font size:** 15 Pixel (selected in the dropdown)
- Orientation:** Left-aligned (selected in the dropdown)
- Warning:** In this font, only a limited ANSI character set (255 characters) is available in the device!
- Buttons:** OK, Cancel

Parameter

Parameter	Selection/settings	Description
Destination	Variable to which the value is written. No selection Select variable.	No variable selected. Digital selector (external digital input 1 to ...)
Display mode 	Text Screen	Entry by selecting the corresponding text from a drop-down list or using the toggle function Entry by selecting the corresponding pictogram (with the toggle function)
Toggle function	Yes (☒) , No (☐)	By selecting "Yes" the value (low, high) changes with each click of the button in the process screen (in the case of display mode = text).
Color for low 	Select color (drop-down menu).	Font color (Text Low) within the object
Color for high 	Select color (drop-down menu).	Font color (Text High) within the object
Text Low	Enter text (or use default text).	Text for low condition
Text High	Enter text (or use default text).	Text for high condition
Image for low 	Select image (button "...").	Image (pictogram) for low condition
Image for high 	Select image (button "...").	Image (pictogram) for high condition

9 Configuration – in setup program only

Display mode

Text: The value (Low, High) is determined by the selection of the corresponding text (Text Low, Text High) from a drop-down list. Alternatively, a toggle function can be activated.

Image: The value is determined by selecting the image (pictogram) (integrated toggle function).

Color for low, color for high (foreground color)

In order for the font to be visible, the foreground and background color must be different from each other. If the "Transparent" setting is selected () , this applies with regard to the background color of the process screen.

Image for low, image for high

The "No image" setting means that the condition concerned is shown without an image in the process screen. In other words, an image is only shown for the other condition.

Example: High (on) = green pictogram; Low (off) = no image

9 Configuration – in setup program only

9.12.16 Text selection from list

Setup dialog box

The screenshot shows the 'Objects' dialog box with the 'Type' set to 'Text selection from list'. The 'Object name' field is empty. The 'Visual' and 'Editable' checkboxes are both checked. The 'X-Position' is 10, 'Y-Position' is 20, 'Width' is 50, and 'Height' is 20. The 'Text destination' dropdown is set to 'Process values' with 'No selection' below it. The 'Index destination' dropdown is also set to 'Process values' with 'No selection' below it. The 'Background colour' dropdown is set to a dark grey color. The 'Transparent' checkbox is unchecked. The 'Frame shape' dropdown is set to 'Thin'. The 'Foreground colour' dropdown is set to a black color. The 'Font size' dropdown is set to '15 Pixel'. The 'Orientation' dropdown is set to 'Left-aligned'. The 'First text' field is 1, 'Number of texts' is 10, and 'Number of characters' is 100. The 'Text editable' checkbox is unchecked. The 'OK' and 'Cancel' buttons are at the bottom right.

Parameter

Parameter	Selection/settings	Description
Text destination	Text variable into which the text selected in the process screen is written.	
	No selection Select variable.	No variable selected. Selector
Index destination	Analog variable into which the index (position in the list area, beginning with 0) of the selected text is written.	
	No selection Select variable.	No variable selected. Selector
First text	1 to ...	First selectable text (text number) in the text list
Number of texts	1 to 50 (10)	Number of selectable texts in the text list (as of the first selectable text)
Number of characters	1 to 160 (100)	Maximum number of characters in the event of a modifiable text
Text editable	Yes (☒) , No (☐)	If "Yes" is selected, the selected text can be edited (index destination is then disabled).

9 Configuration – in setup program only

9.12.17 Text selection by value

Setup dialog box

The screenshot shows a dialog box titled 'Objects' with a close button (X) in the top right corner. The 'Type' is set to 'Text selection by value'. The 'Object name' field is empty. The 'Visual' checkbox is checked, and the 'Editable' checkbox is also checked. The 'X-Position' is 10, 'Y-Position' is 20, 'Width' is 50, and 'Height' is 20. The 'Signal source (text number)' dropdown is set to 'No selection'. The 'Background colour' dropdown is set to a light grey color. The 'Transparent' checkbox is unchecked. The 'Frame shape' dropdown is set to 'Thin'. The 'Foreground colour' dropdown is set to black. The 'Font size' dropdown is set to '15 Pixel'. The 'Orientation' dropdown is set to 'Left-aligned'. There are several empty input fields on the right side of the dialog. At the bottom right, there are 'OK' and 'Cancel' buttons.

Parameter

Parameter	Selection/settings	Description
Signal source (text number)		Analog signal whose value is used as the text number for selecting the text from the text list. The text is displayed in the process screen.
		If there is no text at the selected point in the text list (or if the value is outside the value range), no text is shown (existing text is deleted).
	No selection Select variable.	No variable selected. Analog selector

9 Configuration – in setup program only


9.12.18 Preview

A process screen that has been created can be checked and modified in the preview screen using the setup program before transferring to the device.

The preview screen is opened by pressing the "Preview" button:

The preview screen also opens if the dialog for creating an object is exited using the "OK" button.

Preview screen



Processing functions

Button	Function
	Select foreground color (for example, font color) within the object (drop-down menu).
	Select background color of the object (drop-down menu).
	Change the frame form of the object (none, thin, thick, raised, recessed).
	Change font size.
	Change alignment of the font within the object (left-aligned, centered, right-aligned).
	Change orientation of the object in the process screen (horizontal, vertical).
	Move the object in the process screen forward with each click. The object is simultaneously moved down in the object list (higher number).
	Move the object in the process screen back with each click. The object is simultaneously moved up in the object list (smaller number).
	Move object in process screen horizontally or vertically. Clicking on this button opens an additional window. This contains different arrows (buttons) for moving the object in preset steps.

9 Configuration – in setup program only

Button	Function
	Align object in the process screen (left, right, top, bottom). Select the first object by clicking, keep the Shift key pressed, and click on another object (or more) with the left mouse button. When you click on the appropriate button, the other objects are aligned on the first object.
	
Language	Select language (drop-down menu) The object text is displayed in the selected language, provided it has already been entered in this language when creating the object.

Processing object features

Changes can be made directly to the object features in question using the processing functions described above. It is also possible to open the object by double-clicking (in the preview screen or in the object list) in order to process the object features.

Moving objects

The user has the following options to move an object horizontally or vertically in the preview screen:

- Double-clicking the object to open it and changing the X/Y position.
- Left-clicking and holding the object and moving it directly in the preview screen.
- Moving the object using the arrows.

10 Online parameter (setup only)




NOTE!

The functions described in this chapter are configured in the setup program. An active connection between the setup program and the device is required for this.

Default settings are shown in **bold** in the parameter tables.

10.1 Ethernet

Setup dialog box



The image shows a screenshot of the 'Ethernet' setup dialog box. It contains the following fields and settings:

- IP address assignment: Automatically (DHCP) (dropdown menu)
- IP address: 223 . 223 . 223 . 1
- Subnet-Mask: 255 . 255 . 255 . 0
- Standard-Gateway: 0 . 0 . 0 . 0
- DNS-Server IP automatically: Yes (dropdown menu)
- DNS device name: MAC000cd80a4218-TYP7065
- DNS-Server: 0 . 0 . 0 . 0
- Buttons: OK, Cancel

The parameters and their settings are identical to the configuration in the device.

⇒ chapter 7.21 "Ethernet", Page 179

10 Online parameter (setup only)

10.2 Date and time

The device's date and time are configured in this dialog by transferring them from the PC on which the setup program is running.


In contrast to this, the settings for the time zone and daylight saving time are configured in the device's parameter level. You can also set the date and time manually there:

⇒ chapter 8.4 "Date and time", Page 197

The date and time can also be set using a time server:

⇒ chapter 7.25 "Time server (SNTP)", Page 191

Setup dialog box



Parameter


Parameter	Selection/settings	Description
Date/time of the device	Select "Read out permanently" button	The current date and time are cyclically read out from the device. To newly set the date and time, first cancel cyclical reading ("Stop" button).
New setting	Use date/time from PC (Enter date/time (UTC))	The PC's date and time settings are used for setting the device. (This function is not supported.)
Set	Press button	The date and time are set.
Synchronize	Press button	The time is synchronized. If the difference between the current time in the device and the new time is greater than 30 seconds, the function is not executed.

10 Online parameter (setup only)

10.3 Screenshot

The user can use this function to create a screenshot of the device's screen content.

Setup dialog box



Parameter

Parameter	Selection/settings	Description
Create	Press button	Create screenshot
Save	Press button	Stores the screenshot as a graphic The file name and storage location are freely selectable. The file is stored as a pixel image; the most common image formats are available for selection (e.g., bmp, jpg, tif).
Print	Press button	Print screenshot All printers installed on the PC are available for printing.

10 Online parameter (setup only)

10.4 Delete recording data


This function deletes all the data recorded in the device's internal recording data memory up to this time.



NOTE!

This function should only be used after startup of the device or after setting up a new plant.


Setup dialog box



10.5 Reset user list

This function resets the user list on the device to the default settings.

Setup dialog box



NOTE!


A device with extra code 888 (FDA) does not have this function available in the setup program. The user list can only be reset with the PC Security Manager software PCS.
See operating manual for PC Security Manager software PCS.

10 Online parameter (setup only)


10.6 Additional process values for online data

Additional process values to be displayed as online data are selected in this dialog ("Additional process values" tab).

Setup dialog box



After pressing the "Edit" button (or double clicking on the relevant line), the following dialog appears; you can then select the process value:



Parameter


Parameter	Selection/settings	Description
Process value	Select the process value from the selector (drop-down menu) No selection	Analog signal, digital signal, or text The selection you make is displayed in the online data "Selector" column along with the complete path from the selector. The value of the process value is shown in the "Value" column.
Additional identifier	Enter text (max. 30 characters)	Individual designation of the process value The text is shown in the online data "Identifier" column.
Unit	Enter text (max. 6 characters)	Process value unit The text is shown in the online data "Unit" column.

10 Online parameter (setup only)

10.7 Approval of extra codes

You can use this function to activate additional functions (extra codes) for the device via the setup program.

Setup dialog box



Parameter


Parameter	Selection/settings	Description
Generate code number	To generate a code number, click the function to select it and then click the "Next" button. Follow the other instructions.	This function is used to generate a code number to activate an extra code. The code number is required to obtain an activation code from a sales partner.
Enter activation code	To enter an activation code, click the function to select it and then click the "Next" button. Follow the other instructions.	This function is used to activate an extra code. This requires the activation code received from the sales partner.
Reset extra codes	To reset extra codes, click the function to select it and then click the "Next" button. Follow the other instructions.	This function can be used to lock an extra code that has been activated. Locked extra codes can only be activated by re-enabling. This procedure is subject to charge.

10 Online parameter (setup only)

10.8 Creation of a device certificate

Extra code 887 or 888 gives the device reliable manipulation detection. The digital device certificate verifies that the recording data has not been tampered with either in the device or during transfer to the data archive.

Setup dialog box



Parameter

Parameter	Selection/settings	Description
Generate certificate request	To generate a certificate request, click the function to select it and then click the "Next" button. Follow the other instructions.	This function creates a file that includes the certificate request. The file is required to request a certificate response from the sales partner.
Apply certificate response	To apply the certificate response, click the function to select it and then click the "Next" button. Follow the other instructions.	This function transfers the certificate response to the device. For this purpose the file sent by the sales partner is required.


10 Online parameter (setup only)

10.9 Calibrate/test

10.9.1 Hardware/Software

This window shows the device version numbers (basic device and I/O cards), information on calibration, and various IDs.


Setup dialog box



10.9.2 Calibration constants

This window displays the calibration constants for the analog inputs and outputs.

Setup dialog box



10 Online parameter (setup only)

10.9.3 Analog inputs

This function tests the analog inputs. To allow this to happen, the appropriate signal or resistance must be in place at the relevant analog input.

Setup dialog box

The screenshot shows the 'Calibrate / test' dialog box with the 'Analog inputs' tab selected. On the left, a list of test measurements is displayed, with the last value being 287.128662. On the right, the 'Analog input' is set to 'Analog input 1' and the 'Signal analog input' is set to 'Pt100 2-Wire'. The 'Actual' field shows the value 287.128662 Ohm. A 'Test' button is located below the 'Actual' field. At the bottom right, there are 'OK' and 'Cancel' buttons.

After pressing the "Test" button, the value at the analog input is continuously measured and displayed in the "Act. value" (last value) field as well as in the display field (left; all measured values). The continuous measurement is terminated by pressing "Stop":

10.9.4 Analog outputs

This function tests the analog outputs. The signal at the relevant analog output must be measured for this purpose.

Setup dialog box

The screenshot shows the 'Calibrate / test' dialog box with the 'Analog outputs' tab selected. On the left, there is a large empty display area. On the right, the 'Analog output' is set to 'Analog output 1' and the 'Signal analog output' is set to '0 ... 10 V'. The 'Setpoint' field is set to 0.0 V. A 'Test' button is located below the 'Setpoint' field. At the bottom right, there are 'OK' and 'Cancel' buttons.


After selecting the signal type (0 to 10 V or 0 to 20 mA) and entering the setpoint value, the corresponding value is output at the relevant analog output by pressing the "Test" button. The output value must be measured and compared with the setpoint value.

10 Online parameter (setup only)

10.9.5 Digital inputs

This function tests the digital inputs.

Setup dialog box




If the level at an input is "High," this is indicated with a check mark in the checkbox.

10.9.6 Digital inputs/outputs

This function tests the digital inputs/outputs. You can toggle between input and output in each case.

Setup dialog box



If the level at a digital input is "High," this is indicated with a check mark in the checkbox.

To toggle between digital input and digital output (and back), click on the line and then press the corresponding button.

A digital output is set to "High" by checking the relevant checkbox.

10 Online parameter (setup only)

10.9.7 Touch

This function is used to calibrate the screen's touch function.

Setup dialog box

	Top LH	Bottom LH	Top RH	Bottom RH
Minimum value X:	0	0	3600	3600
Constant X:	295	261	3881	3878
Maximum value X:	600	600	4095	4095
Minimum value Y:	0	3300	0	3300
Constant Y:	406	3829	414	3777
Maximum value Y:	700	4095	700	4095

Start touch calibration

OK Cancel

The current values of the parameters are read out from the device when opening the dialog. They are for information purposes only and cannot be changed by the user.

Parameter	Description
Minimum value X	Left limit of the respective centering field (top left, bottom left, top right, bottom right)
Constant X	X coordinate of the center point of the respective centering field
Maximum value X	Right limit of the respective centering field
Minimum value Y	Lower limit of the respective centering field
Constant Y	Y coordinate of the center point of the respective centering field
Maximum value Y	Upper limit of the respective centering field


The calibration is started and the user must tap the centering fields that are consecutively displayed on the device screen (touch the center point of the box). The screen color briefly changes if the centering field is not touched. Following successful calibration, a corresponding message is displayed in the setup program.

10 Online parameter (setup only)

10.9.8 Display and relay

This function tests the screen's color rendering and the function of the LEDs and the relay.

Setup dialog box



To test the color rendering, click to select the color or the color gradient. The screen then displays the relevant color pattern.

The LEDs and the relay are also enabled or disabled by clicking (checking).




NOTE!

The screen remains in this test mode until the "Calibrate/test" dialog is exited by touching the "OK" button (or until touch calibration is started).

10.9.9 Battery

This function is used to display the status of the buffer battery (OK, low, empty).

Setup dialog box



11.1 Technical data

11.1.1 Analog inputs

General

Number	Max. 6 (see connection diagram)
A/D converter	24 bit delta-sigma
Sampling rate	Up to 6 channels: 125 ms
Input filter	Digital filter, 2nd order; filter constant can be set from 0 to 100.0 s
Galvanic isolation	See "Galvanic isolation"

Thermocouples

Designation	Type	Standard	ITS	Measuring range	Accuracy ^a
Fe-CuNi	"L"	DIN 43710 (1985)	IPTS-68	-200 to +900 °C	≤ 0.1 %
Fe-CuNi	"J"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	-210 to +1200 °C	≤ 0.1 % from -100 °C
Cu-CuNi	"U"	DIN 43710 (1985)	IPTS-68	-200 to +600 °C	≤ 0.1 % from -100 °C
Cu-CuNi	"T"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	-270 to +400 °C	≤ 0.1 % from -150 °C
NiCr-Ni	"K"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	-270 to +1300 °C	≤ 0.1 % from -80 °C
NiCr-CuNi	"E"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	-270 to +1000 °C	≤ 0.1 % from -80 °C
NiCrSi-NiSi	"N"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	-270 to +1300 °C	≤ 0.1 % from -80 °C
Pt10Rh-Pt	"S"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	-50 to +1768 °C	≤ 0.15 % from 100 °C
Pt13Rh-Pt	"R"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	-50 to +1768 °C	≤ 0.15 % from 100 °C
Pt30Rh-Pt6Rh	"B"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	0 to 1820 °C	≤ 0.15 % from 600 °C
W5Re-W26Re	"C"	DIN EN 60584-1:2014 IEC 60584-1:2013	ITS-90	0 to 2315 °C	≤ 0.1 % from 500 °C
W3Re-W25Re	"D"	ASTM E1751M-15	ITS-90	0 to 2315 °C	≤ 0.1 % from 500 °C
W5Re-W20Re	"A1"	GOST R 8.585-2001	ITS-90	0 to 2500 °C	≤ 0.1 % from 500 °C
Chromel®-Copel	"L"	GOST R 8.585-2001	ITS-90	-200 to +800 °C	≤ 0.1 % from -80 °C
Chromel®-Alumel®	"K"	GOST R 8.585-2001	ITS-90	-270 to +1372 °C	≤ 0.1 % from -80 °C
PLII (Platinel® II)		ASTM E1751M-15	ITS-90	0 to 1395 °C	≤ 0.1 %
Ambient temperature influence	≤ 100 ppm/K				
Cold junction	Internal (Pt100) or external (constant)				
Cold junction accuracy (internal)	± 1 K				
Cold junction temperature (external)	-30 to +85 °C (adjustable)				
Base measuring range	-20 to +70 mV				

^a Accuracy refers to the measuring range

11 Annex

RTD temperature probe

Designation	Standard	ITS	Measuring range	Accuracy ^a	Measuring current
Pt50	DIN EN 60751:2009 IEC 60751:2008	ITS-90	-200 to +850 °C	≤ 0.1 %	500 µA
Pt100	DIN EN 60751:2009 IEC 60751:2008	ITS-90	-200 to +850 °C	≤ 0.1 %	500 µA
Pt500	DIN EN 60751:2009 IEC 60751:2008	ITS-90	-200 to +850 °C	≤ 0.1 %	50 µA
Pt1000	DIN EN 60751:2009 IEC 60751:2008	ITS-90	-200 to +850 °C	≤ 0.1 %	50 µA
Pt100	JIS C 1604:1981	IPTS-68	-200 to +649 °C	≤ 0.1 %	500 µA
Pt50	GOST 6651-2009 A.2	ITS-90	-200 to +850 °C	≤ 0.1 %	500 µA
Pt100	GOST 6651-2009 A.2	ITS-90	-200 to +850 °C	≤ 0.1 %	500 µA
Cu50	GOST 6651-2009 A.3	ITS-90	-180 to +200 °C	≤ 0.4 %	500 µA
Cu100	GOST 6651-2009 A.3	ITS-90	-180 to +200 °C	≤ 0.4 %	500 µA
Ni100	DIN 43760 (1987)	IPTS-68	-60 to +250 °C	≤ 0.2 %	500 µA
Ni100	GOST 6651-2009 A.5	ITS-90	-60 to +180 °C	≤ 0.2 %	500 µA
Connection type		2/3/4-wire			
Ambient temperature influence		≤ 50 ppm/K			
Sensor line resistance		Max. 10 Ω per cable for two-wire circuit Max. 30 Ω per cable for three/four-wire circuit			

^a Accuracy refers to the measuring range.

Resistance transmitter and resistance/potentiometer

Designation	Measuring range	Accuracy ^a	Measuring current
Resistance transmitter	0 to 4000 Ω	≤ 0.1 %	50 µA
Resistance/potentiometer	0 to 400 Ω	≤ 0.1 %	500 µA
	0 to 4000 Ω	≤ 0.1 %	50 µA
Ambient temperature influence	≤ 100 ppm/K		
Connection type			
Resistance transmitter	Three-wire circuit		
Resistance/potentiometer	Two/three/four-wire circuit		
Smallest measuring span	60 Ω		
Sensor line resistance	Max. 10 Ω per cable for two-wire and three-wire circuits		
Resistance values	Freely programmable within the limits, in increments of 0.1 Ω		

^a Accuracy refers to the maximum measuring range. Small measuring spans lead to reduced linearization accuracy.

Voltage, current (standard signals)

Designation	Measuring range	Accuracy ^a	Input resistance or burden voltage
Voltage	0 to 70 mV	≤ 0.1 %	> 500 kΩ
	0 to 10 V	≤ 0.05 %	> 500 kΩ
	-10 to +10 V	≤ 0.05 %	> 500 kΩ
	-1 to +1 V	≤ 0.08 %	> 500 kΩ
	0 to 1 V	≤ 0.08 %	> 500 kΩ
Current	4 to 20 mA	≤ 0.1 %	< 2 V
	0 to 20 mA	≤ 0.1 %	< 2 V
Ambient temperature influence	≤ 100 ppm/K		
Smallest measuring span			
Voltage	5 mV		
Current	0.5 mA		
Measuring range start/end			
Voltage	Freely programmable within the limits, in increments of 0.01 mV		
Current	Freely programmable within the limits, in increments of 0.01 mA		
Deviation below/above the measur. range	According to NAMUR recommendation NE 43 (only current input 4 to 20 mA)		

^a Accuracy refers to the maximum measuring range. Small measuring spans lead to reduced linearization accuracy.

Measuring circuit monitoring

The device behavior in the event of a malfunction is configurable.

Measuring probe	Probe break	Short-circuit	Polarity
Thermocouple	Is detected	Is not detected	Is detected in certain conditions ^a
RTD temperature probe	Is detected	Is detected	Is not detected
Resistance transmitter	Is detected	Is not detected	Is not detected
Resistance/potentiometer	Is detected	Is not detected	Is not detected
Voltage 0 to 70 mV	Is detected	Is not detected	Is detected
Voltage 0 to 10 V	Is not detected	Is not detected	Is detected
Voltage -10 to +10 V	Is not detected	Is not detected	Is not detected
Voltage 0 to 1 V	Is detected	Is not detected	Is detected
Voltage -1 to +1 V	Is detected	Is not detected	Is not detected
Current 0 to 20 mA	Is not detected	Is not detected	Is not detected
Current 4 to 20 mA	Is detected	Is detected	Is detected

^a Dependent on the set characteristic line

11 Annex

11.1.2 Digital inputs

Number	Max. 12 (see connection diagram)
Input	
Level	Logic level 0: < 3.5 V; logic level 1: > 10 V
Sampling rate	125 ms (max. counting frequency: 4 Hz)
Potential-free contact	R _{ON} : < 1 kΩ; R _{OFF} : > 50 kΩ (use of auxiliary voltage 24 V)
Auxiliary voltage supply	
Voltage	DC 24 V +10/-15 %
Current	Max. 50 mA per slot

11.1.3 Analog outputs

Number	Max. 2 (see connection diagram)
Voltage	
Output signal	DC 0 to 10 V
Load resistance	> 500 Ω
Current	
Output signal	DC 0(4) to 20 mA
Load resistance	< 450 Ω
Accuracy	0.5 %
Ambient temperature influence	150 ppm/K

11.1.4 Digital inputs/outputs

Number	Max. 12 (see connection diagram)
Input or output	Individually configurable as input or output
Input	
Level	Logic level 0: < 3.5 V; logic level 1: > 10 V
Sampling rate	125 ms (max. counting frequency: 4 Hz)
Potential-free contact	R _{ON} : < 1 kΩ; R _{OFF} : > 50 kΩ (use of auxiliary voltage 24 V)
High-speed input	
Usable inputs	1, 2 (see connection diagram)
Function	Counts each positive edge of the input signal
Max. counting frequency	12.5 kHz
Mark-to-space ratio	30 to 70 % (high-pulse ≥ 30 μs, low-pulse ≥ 30 μs)
Accuracy for flow measurement	0.5 % of measured value; ambient temperature influence: 50 ppm/K
Output	
Output signal	DC 0/24 V +10/-15 %; galvanically isolated
Current	Max. 40 mA per output, max. 100 mA in total (including auxiliary voltage supply current)
Auxiliary voltage supply	
Voltage	DC 24 V +10/-15 %
Current	Max. 100 mA (including digital outputs current)

11.1.5 Relays

Number	1 (see connection diagram)
Relay (changeover contact)	
Switching capacity	3 A at AC 230 V or DC 30 V, resistive load
Contact life	30,000 switching operations at rated load

11 Annex

11.1.6 Interfaces

RS232/RS485	
Number	1 (can be switched between RS232 and RS485)
Connector type	SUB-D 9-pin (socket)
Baud rate	4800, 9600, 19200, 38400, 115200
Data format	8/1n, 8/1e, 8/1o
Protocol	Modbus RTU as master or slave, barcode scanner, NMEA 0183
Application	Communication with Modbus master/slave, connection of a barcode scanner or a GPS receiver
External inputs	Via Modbus master/slave functionality: 24 analog and 24 digital inputs, 10 batch texts, 4 event texts
Ethernet	
Number	1 (alternative to PROFINET interface)
Connector type	RJ45 (socket)
Transfer rate	10 Mbit/s, 100 Mbit/s
Protocol	IPv4; TCP, UDP; DHCP, DNS, HTTP, SMTP, SNTP, Modbus-TCP
Application	Communication with PC (setup program, data archiving, web server), email server, SNTP server, and Modbus master/slave
External inputs	Via Modbus master/slave functionality: 24 analog and 24 digital inputs, 10 batch texts, 4 event texts
Max. cable length	100 m
PROFINET IO device	
Number	1 (alternative to Ethernet interface)
Connector type	2 x RJ45 (socket), integrated switch
Transfer rate	100 Mbit/s
Conformity class	B (CC-B)
Netload class	III (Netload Class III)
Protocol	DCP, LLDP, VLAN Priority, PTCP
Application	Communication with PROFINET IO controller; Ethernet standard services are also supported
Max. cable length	100 m
USB host	
Number	1 (on front with cover)
Connector type	A (socket)
Standard	USB 2.0 (high speed)
Application	Exclusively for connecting a USB flash drive (FAT16/FAT32; see accessories)
Max. load current	100 mA
USB device	
Number	1 (on the back)
Connector type	Micro-B (socket)
Standard	USB 2.0 (high speed)
Application	To connect to a PC (setup program, PCC/PCA3000)
Max. cable length	5 m

11.1.7 Screen

Type	TFT color screen/TFT-touchscreen (resistive) ^a
Size	14.5 cm (5.7")
Resolution	640 × 480 pixels (VGA)
Number of colors	65536
Frame rate	60 Hz (type)
Brightness setting	Adjustable on the device
Screensaver (switch-off)	After waiting period or due to control signal

^a TFT color screens may have pixel errors due to technological and/or production-related reasons. Up to four pixel errors are deemed admissible for this paperless recorder; they do not provide the ground for warranty claims.

11.1.8 Electrical data

Voltage supply	AC 110 to 240 V +10/-15 %, 48 to 63 Hz or AC/DC 20 to 30 V, 48 to 63 Hz (not in conjunction with extra code 970)
Electrical safety	According to DIN EN 61010-1 Overvoltage category II to 300 V mains voltage, pollution degree 2
Protection rating	I with internal isolation from SELV
Power consumption AC 110 to 240 V AC/DC 20 to 30 V	< 45 VA < 30 VA
Data backup	Internal flash memory
Data buffering	Battery (operating life > 7 years); additionally, storage capacitor for buffering during battery change (buffer time approx. 2 minutes)
Time	Battery-buffered real-time clock
Electrical connection	On the back via push-in spring-cage terminals
Conductor cross section on terminal 5 Wire or stranded wire without ferrule Stranded wire with ferrule 2 × stranded wire with twin ferrule with plastic collar Stripping length	Min. 0.2 mm ² , max. 2.5 mm ² Min. 0.2 mm ² , max. 2.5 mm ² Min. 0.5 mm ² , max. 1.5 mm ² (both stranded wires with identical cross section) 10 mm
Conductor cross section on terminals 4, 14, and 15 Wire or stranded wire without ferrule Stranded wire with ferrule Stripping length	Min. 0.2 mm ² , max. 2.5 mm ² (with terminal cover: max. 1.5 mm ²) Min. 0.25 mm ² , max. 2.5 mm ² (with terminal cover: max. 1.5 mm ²) 10 mm
Conductor cross section on terminals 6 to 13 Wire or stranded wire without ferrule Stranded wire with ferrule Stripping length	Min. 0.14 mm ² , max. 1.5 mm ² (with terminal cover: max. 0.5 mm ²) Without plastic collar: min. 0.25 mm ² , max. 1.5 mm ² (with terminal cover: max. 0.5 mm ²) With plastic collar: min. 0.25 mm ² , max. 0.5 mm ² 9 mm

11 Annex

11.1.9 Environmental influences

Ambient temperature range	
Storage	-20 to +60 °C
Operation	-20 to +50 °C ^a ; in conjunction with extra code 970: 0 to 40 °C
Site altitude	Max. 2000 m above sea level
Climatic environmental influences	According to DIN EN 60721-3 with extended temperature range
Resistance to climatic conditions	≤ 85 % rel. humidity without condensation
Storage	According to class 1K2
Operation	According to class 3K3
Mechanical environmental influences	According to DIN EN 60721-3
Storage	According to class 1M2
Transport	According to class 2M2
Operation	According to class 3M3
Electromagnetic compatibility (EMC)	According to DIN EN 61326-1
Interference emission	Class A – only for industrial use –
Interference immunity	Industrial requirements

^a At temperatures below 0 °C, the build-up of screen contents slows down.

11.1.10 Case

Case type	Flush-mounted housing according to DIN IEC 61554 made of zinc-plated steel sheet (indoor use)
Case front	Made of die-cast zinc with decor foil
Front frame dimensions	144 mm x 144 mm (front frame depth approx. 8 mm including seal)
Mounting depth	120.9 mm (incl. spring-cage terminals)
Panel cut-out	138 ^{+1.0} mm x 138 ^{+1.0} mm
Panel thickness	2 to 8 mm
Case fastening	In panel using the four supplied mounting elements
Operating position	Any, with due consideration for the viewing angle of the screen, horizontal ±50°, vertical ±30°
Protection type	According to DIN EN 60529, front IP66, back IP20; in conjunction with extra code 970: IP20 with open carrying case, IP20D with closed carrying case
Weight	Max. 1.65 kg (without terminal cover)

11.1.11 Approvals and approval marks

Approval mark	Testing facility	Certificate/certification number	Inspection basis	Valid for
c UL us	Underwriters Laboratories	E201387	UL 61010-1 (3. Ed.), CAN/CSA-22.2 No. 61010-1 (3rd Ed.)	All versions of the built-in device; not in conjunction with extra code 970

The device is approved if the approval mark is shown on the device.

11.2 Buffer battery replacement



CAUTION!

The device contains a buffer battery that is used for data buffering when the device is in switched off mode or if the power fails. The operating life of the battery is at least 7 years. A low battery is indicated by the battery pre-alarm ("Battery low"). An empty battery is indicated by the battery alarm ("Battery empty").

If the battery is not changed in time, data may be lost!

- The battery must be replaced within 4 weeks after the battery pre-alarm has been triggered. The battery change must be carried out exclusively by the manufacturer's service department. For this purpose the device must be sent to the manufacturer.

11.3 China RoHS

						
产品组别 Product group: 706521	产品中有害物质的名称及含量 China EEP Hazardous Substances Information					
部件名称 Component Name						
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
外壳 Housing (Gehäuse)	○	○	○	○	○	○
过程连接 Process connection (Prozessanschluss)	○	○	○	○	○	○
螺母 Nuts (Mutter)	○	○	○	○	○	○
螺栓 Screw (Schraube)	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
This table is prepared in accordance with the provisions SJ/T 11364.
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
Indicate the hazardous substances in all homogeneous materials' for the part is below the limit of the GB/T 26572.

×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。
Indicate the hazardous substances in at least one homogeneous materials' of the part is exceeded the limit of the GB/T 26572.

11 Annex

11.4 Barcode

Initializing the barcode scanner

The barcode scanner must be initialized once prior to use. Example:

Step	Action
1	Scan the "Factory Default Settings" barcode.
2	Scan the "Select RS-232 Standard" barcode.

The relevant information and barcodes can be found in the manual for the barcode scanner being used.

The paperless recorder supports the barcodes code 39 (standard variant) and code 128 (A and B, without control characters) as well as the QR code (without control characters). The following examples were drawn up using code 39.

11.4.1 Batch control



NOTE!

In order to control batches using the barcode scanner, the paperless recorder must have been configured accordingly. The "Enter batch texts" right is required.

Showing the batch report

This function requires the corresponding display configuration (Configuration > Display > General: Barcode -> Batch mask = Yes).

Step	Action
1	Scan the BATCH1 barcode.



The batch report is displayed.

Enter batch texts

Step	Action
1	Scan the barcodes for the batch text of the individual lines one after the other (starting with the first line).

All batch lines configured for the barcode input are populated with the scanned text one after the other (max. 160 characters). The last line is overwritten in the case of further entries.

If there is a dollar character (default setting, configurable) within the scanned text, this causes the text following the dollar character to be entered in the next line. In this way one scan operation can populate up to 10 lines. Several dollar characters stringed together cause the corresponding number of line breaks.

A maximum of 480 characters (incl. the characters for the line break) can be entered with one scan operation (e.g. 3 lines of 159 characters each or 10 lines of 47 characters each).



NOTE!

The batch control codes (BATCH..., START, STOP, RESET) cannot be loaded as batch texts.

Reset texts

Step	Action
1	Scan the RESET barcode.



RESET

The entered batch texts are reset. The standard texts (default texts) are displayed and the first line is prepared for text entry again.

The standard text is specified in the configuration of the batch line (Configuration > Batch > Batch line: Default text).

Start batch reporting

Step	Action
1	Scan the START barcode.



START

Batch reporting is started.

Stop batch reporting

Step	Action
1	Scan the STOP barcode.



STOP

Batch reporting is stopped.

In the current batch report, and depending on the configuration of the batch line, texts loaded via barcode are either reset to the standard text (default text) (Configuration > Batch > Batch line: Delete line = Yes) or retained (Delete line = No).

The texts are saved in the completed batch report.

11 Annex

11.4.2 Texts and process values

Specific control characters can be used to load event texts, process values (external text variables, analog and digital variables), or comment texts (batch recipes).

Once the respective text has been scanned using the control character, the system automatically switches back to barcode input for batch control.

Enter text into event list

%En% = entry into the event list of group n (n = number of group; n = 0 for all groups)

Example: %E1%ABC



The text "ABC" is entered into the event list of group 1.

Example: %E0%DEF

The text "DEF" is entered into the event lists of all groups.

Enter text into external text variable

%Tn% = enter as text into the external text variable n (n = number of variable)

Example: %T1%ABC



The text "ABC" is entered into external text variable 1.

The entered text is available in the text selector.

Control characters and the following text can also be scanned one after another. To do so, only the control character must be used for the first scan process.

Example for the first scan process: %T1%

The next scanned text is interpreted as text for external text variable 1.

Example for the second scan process: ABC

The text "ABC" is entered into external text variable 1.

Enter float value in external analog variable

%Fn% = enter as float value into external analog variable n (n = number of variable)

Example: %F1%447.6



The float value 447.6 is entered into external analog variable 1.

The entered value is available in the analog selector.

Enter binary value in external digital variable:

%Bn% = enter as binary value into external digital variable n (n = number of variable)

Example: %B1%1



%B 1 %1

The binary value 1 is entered into external digital variable 1.

The entered value is available in the digital selector.

A scan process allows several values in consecutive variables to be entered.

Example: %B2%101

The binary values 1, 0, 1 are entered as from variable 2 (variable 2 = 1, variable 3 = 0, variable 4 = 1).

Enter text (recipe) in batch report

%Rn% = enter as comment text (e.g. recipe) into the batch report of batch n (n = number of batch)

Example: %R1%ABC



%R 1 %A B C

The text "ABC" is entered as comment text into the batch report of batch 1.

The comment text can contain up to 400 characters (20 lines with 20 characters each); it is used to describe the batch. It can only be displayed using the PC evaluation software PCA3000.



JUMO GmbH & Co. KG

Street address:
Moritz-Juchheim-Straße 1
36039 Fulda, Germany

Delivery address:
Mackenrodtstraße 14
36039 Fulda, Germany

Postal address:
36035 Fulda, Germany

Phone: +49 661 6003-0
Fax: +49 661 6003-607
Email: mail@jumo.net
Internet: www.jumo.net

JUMO Instrument Co. Ltd.

JUMO House
Temple Bank, Riverway
Harlow, Essex, CM20 2DY, UK

Phone: +44 1279 63 55 33
Fax: +44 1279 62 50 29
Email: sales@jumo.co.uk
Internet: www.jumo.co.uk

JUMO Process Control, Inc.

6733 Myers Road
East Syracuse, NY 13057, USA

Phone: +1 315 437 5866
Fax: +1 315 437 5860
Email: info.us@jumo.net
Internet: www.jumousa.com

