

## **TN70E-B8026**

# Service Engineer's Manual



## Copyright

This publication, including all photographs, illustrations, and software, is protected under international copyright laws, with all rights reserved.

Neither this manual, nor any material contained herein, may be reproduced without written consent of manufacturer.

Copyright 2018 MITAC COMPUTING TECHNOLOGY CORPORATION. All rights reserved. TYAN<sup>®</sup> is a registered trademark of MITAC COMPUTING TECHNOLOGY CORPORATION.

Version 1.0

## Disclaimer

Information contained in this document is furnished by MITAC COMPUTING TECHNOLOGY CORPORATION and has been reviewed for accuracy and reliability prior to printing. MITAC assumes no liability whatsoever, and disclaims any express or implied warranty, relating to sale and/or use of TYAN<sup>®</sup> products including liability or warranties relating to fitness for a particular purpose or merchantability. MITAC retains the right to make changes to produce descriptions and/or specifications at any time, without notice. In no event will MITAC be held liable for any direct or indirect, incidental or consequential damage, loss of use, loss of data or other malady resulting from errors or inaccuracies of information contained in this document.

## **Trademark Recognition**

All registered and unregistered trademarks and company names contained in this manual are property of their respective owners including, but not limited to the following.

TYAN<sup>®</sup> is a trademark of MITAC COMPUTING TECHNOLOGY CORPORATION. AMD<sup>®</sup> is a trademark of AMD<sup>®</sup> Corporation. AMI<sup>®</sup>, AMIBIOS<sup>®</sup> and combinations thereof are trademarks of AMI Technologies. Microsoft<sup>®</sup>, Windows<sup>®</sup> are trademarks of Microsoft Corporation. IBM<sup>®</sup>, PC<sup>®</sup>, AT<sup>®</sup> and PS/2<sup>®</sup> are trademarks of IBM Corporation. Winbond<sup>®</sup> is a trademark of Winbond Electronics Corporation.

## FCC Declaration



#### Notice for the USA

Compliance Information Statement (Declaration of Conformity Procedure) DoC FCC Part 15: This device complies with part 15 of the FCC Rules.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

This device may not cause harmful interference.

• This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### Notice for Canada

This Class A digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la Classe A est conforme à la norme NMB-003 du Canada.

## • Notice for Europe (CE Mark)

# CE

This product is in conformity with the Council Directive 2014/30/EU and 2014/35/EU.

#### Warning

This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.

#### CAUTION

Lithium battery included with this board. Do not puncture, mutilate, or dispose of battery in fire. There will be danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by manufacturer. Dispose of used battery according to manufacturer instructions and in accordance with your local regulations.

## • VCCI-A

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨 害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要 求されることがあります。

## • Safety: IEC/EN 60950-1

This equipment is compliant with CB/LVD of Safety: IEC/EN 60950-1.

## About this Manual

This manual is intended for trained service technician/personnel with hardware knowledge of computers. Components inside the compartments should be serviced only by a trained service technician/personnel. This manual is aimed to provide you with instructions on installing your TYAN TN70E-B8026.

## How this guide is organized

This guide contains the following parts:

#### **Chapter 1: Overview**

This chapter provides an introduction to the TYAN TN70E-B8026 barebones and standard parts list, describes the external components, gives an overview of the product from different angles.

#### **Chapter 2: Setting Up**

This chapter covers procedures on installing the memory modules, hard drivers and other optional parts.

#### **Chapter 3: Replacing the Pre-installed Components**

This chapter covers the removal and replacement procedures for pre-installed components.

#### Appendix:

This chapter provides the cable connection table, how to install IO plate for OCP Card, the FRU parts list for reference of system setup, and technical support in case a problem arises with your system.

## Safety and Compliance Information

Before installing and using TYAN TN70E-B8026, take note of the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Do not block the slots and opening on the unit, which are provided for ventilation.
- Only use the power source indicated on the marking label. If you are not sure, contact the power company.
- The unit uses a three-wire ground cable, which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
- Do not place anything on the power cord. Place the power cord where it will not be in the way of foot traffic.
- Follow all warnings and cautions in this manual and on the unit case.
- Do not push objects in the ventilation slots as they may touch high voltage components and result in shock and damage to the components.
- When replacing parts, ensure that you use parts specified by the manufacturer.
- When service or repairs have been done, perform routine safety checks to verify that the system is operating correctly.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- Cover the unit when not in use.

## Safety Information

Retain and follow all product safety and operating instructions provided with your equipment. In the event of a conflict between the instructions in this guide and the instructions in equipment documentation, follow the guidelines in the equipment documentation.

Observe all warnings on the product and in the operating instructions. To reduce the risk of bodily injury, electric shock, fire and damage to the equipment, observe all precautions included in this guide.

You must become familiar with the safety information in this guide before you install, operate, or service TYAN products.

	<b>Caution</b> . This symbol indicates a potential hazard. The potential for injury exists if cautions are not observed. Consult equipment documentation for specific details.
R	<b>Caution.</b> Slide-mounted equipment is not to be used as a shelf or a work space.
<u>J</u>	<b>Warning.</b> This symbol indicates the presence of hazardous energy circuits or electric shock hazards. Refer all servicing to qualified personnel.
<u>sss</u>	Warning. This symbol indicates the presence of a hot surface or hot component. If this surface is contacted, the potential for injury exists. To reduce risk of injury from a hot component, allow the surface to cool before touching.

## Symbols on Equipment

## **General Precautions**

• Follow all caution and warning instructions marked on the equipment and explained in the accompanying equipment documentation.

## Machine Room Environment

• This device is for use only in a machine room or IT room.

• Make sure that the area in which you install the system is properly ventilated and climate-controlled.

• Ensure that the voltage and frequency of your power source match the voltage and frequency inscribed on the electrical rating label of the equipment.

• Do not install the system in or near a plenum, air duct, radiator, or heat register.

• Never use the product in a wet location.

#### **Equipment Chassis**

- Do not block or cover the openings to the system.
- Never push objects of any kind through openings in the equipment. Dangerous voltages might be present.
- Conductive foreign objects can produce a short circuit and cause fire, electric shock, or damage to your equipment.
- Lift equipment using both hands and with your knees bent.

#### **Equipment Racks**

To avoid injury or damage to the equipment:

• Observe local occupational health and safety requirements and guidelines for manual materials handling.

• Do not attempt to move a rack by yourself; a minimum of two people are needed to move a rack.

• Do not attempt to move a fully loaded rack. Remove equipment from the rack before moving it.

• Do not attempt to move a rack on an incline that is greater than 10 degrees from the horizontal.

• Make sure the rack is properly secured to the floor or ceiling.

• Make sure the stabilizing feet are attached to the rack if it is a single-rack installation.

- Make sure racks are coupled together if it is a multiple-rack installation.
- Make sure the rack is level and stable before installing an appliance in the

rack.

- Make sure the leveling jacks are extended to the floor.
- Make sure the full weight of the rack rests on the leveling jacks.

• Always load the rack from the bottom up. Load the heaviest component in the rack first.

• Make sure the rack is level and stable before pulling a component out of the rack.

• Make sure only one component is extended at a time. A rack might become unstable if more than one component is extended.

#### To avoid damage to the equipment:

• The rack width and depth must allow for proper serviceability and cable management.

• Ensure that there is adequate airflow in the rack. Improper installation or restricted airflow can damage the equipment.

• The rack cannot have solid or restricted airflow doors. You must use a mesh door on the front and back of the rack or remove the doors to ensure adequate air flow to the system.

• If you install the Model in a rack, do not place equipment on top of the unit. It will cause restricted airflow and might cause damage to the equipment.

• Make sure the product is properly matted with the rails. Products that are improperly matted with the rails might be unstable.

• Verify that the AC power supply branch circuit that provides power to the rack is not overloaded. This will reduce the risk of personal injury, fire, or damage to the equipment. The total rack load should not exceed 80 percent of the branch circuit rating. Consult the electrical authority having jurisdiction over your facility wiring and installation requirements.

#### **Equipment Power Cords**

• Use only the power cords and power supply units provided with your system. The system might have one or more power cords.

• Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.

• In all European electrical environments, you must ground the Green/Yellow tab on the power cord. If you do not ground the Green/Yellow tab, it can cause an electrical shock due to high leakage currents.

• Do not place objects on AC power cords or cables. Arrange them so that no one might accidentally step on or trip over them.

• Do not pull on a cord or cable. When unplugging from the electrical outlet, grasp the cord by the plug.

• To reduce the risk of electrical shock, disconnect all power cords before servicing the appliance.

#### **Equipment Batteries**

• The system battery contains lithium manganese dioxide. If the battery pack is not handled properly, there is risk of fire and burns.

• Do not disassemble, crush, puncture, short external contacts, or dispose of the battery in fire or water.

• Do not expose the battery to temperatures higher than 60°C (140°F).

• The system battery is not replaceable. If the battery is replaced by an incorrect type, there is danger of explosion. Replace the battery only with a spare designated for your product.

• Do not attempt to recharge the battery.

• Dispose of used batteries according to the instructions of the manufacturer. Do not dispose of batteries with the general household waste. To forward them to recycling or proper disposal, use the public collection system or return them to TYAN, your authorized TYAN partner, or their agents.

#### **Equipment Modifications**

• Do not make mechanical modifications to the system. TYAN is not responsible for the regulatory compliance of TYAN equipment that has been modified.

## **Equipment Repairs and Servicing**

• The installation of internal options and routine maintenance and service of this product should be performed by trained service technicians/personnel who are knowledgeable about the procedures, precautions, and hazards associated with equipment containing hazardous energy levels.

• Do not exceed the level of repair specified in the procedures in the product documentation. Improper repairs can create a safety hazard.

• Allow the product to cool before removing covers and touching internal components.

• Remove all watches, rings, or loose jewelry when working before removing covers and touching internal components.

• Do not use conductive tools that could bridge live parts.

• Use gloves when you remove or replace system components; they can become hot to the touch.

• If the product sustains damage requiring service, disconnect the product from the AC electrical outlet and refer servicing to an authorized service provider. Examples of damage requiring service include:

- The power cord, extension cord, or plug has been damaged.

- Liquid has been spilled on the product or an object has fallen into the product.

- The product has been exposed to rain or water.

- The product has been dropped or damaged.

- The product does not operate normally when you follow the operating instructions.

## **Table of Contents**

Chapter 1:	Overview	15
1.1 At	bout the TYAN TN70E-B8026	15
1.2 Pr	oduct Model	15
1.3 Fe	eatures	16
1.4 St	andard Parts List	20
1.4.1	Box Contents	20
1.4.2	Accessories	20
1.5 Ab	bout the Product	21
1.5.1	System Front View	21
1.5.2	System Rear View	23
1.5.3	System Top View	25
Chapter 2:	Setting Up	27
2.0.1	Before you Begin	27
2.0.2	Work Area	27
2.0.3	Tools	27
2.0.4	Precautions	28
2.1 In:	stalling Motherboard Components	29
2.1.1	Removing the Chassis Cover	29
2.1.2	Removing the Air Duct	30
2.1.3	Installing the CPU and Heatsink	31
2.1.4	Installing the PCI-E Card	34
2.1.5	Installing the Memory	37
2.1.6	Installing Hard Drives	39
2.2 Ra	ack Mounting	46
2.2.1	Installing the Server in a Rack	46
Chapter 3:	Replacing Pre-Installed Components	51
3.1 Int	troduction	51
3.2 Di	sassembly Flowchart	51
3.3 Re	emoving the Cover	52
3.4 Re	eplacing Motherboard Components	52
3.4.1	Replacing the Riser Card	52
3.4.2	PCI-E Riser Cards Specification	54
3.4.3	Connector Pin Definition (M7106-L24-3F)	54
3.4.4	Connector Pin Definition (M7106-R24-3F)	55
3.5 Re	eplacing the Front Panel Board	56
3.5.1	Front Panel Board Specifications	58
3.5.2	FPB LED and Connector Pin Definition	59
3.6 Re	eplacing the USB Board	60

3.6.1	USB Board Specifications	
3.6.2	USB Board Connector Pin Definition	
3.7 Re	placing the System Fan	63
3.8 Re	placing the Fan Backplane Board	
3.8.1	Fan BP Board Specifications	
3.8.2	Fan BP Board LED Definitions	
3.8.3	Connector Pin Definitions	
3.9 Re	eplacing the HDD Backplane Board	70
3.9.1	HDD Backplane Board Features	72
3.9.2	Connector Definition	73
3.10 R	eplacing the Power Distribution Board	74
3.11 R	eplacing the Rear HDD Backplane Board	75
3.11.1	HDD Backplane Features	
3.11.2	Connector Definition	77
3.12 R	eplacing the Power Supply	79
3.13	Disconnecting All Motherboard Cables	80
3.13.1	Removing the Motherboard	
Appendix I:	Installing IO Plate for OCP Card	83
Appendix II:	Cable Connection Tables	87
Appendix III	: Fan and Temp Sensors	89
Appendix IV	: FRU Parts Table	93
Appendix V	: Technical Support	95

## NOTE

## **Chapter 1: Overview**

## 1.1 About the TYAN TN70E-B8026

Congratulations on your purchase of the TYAN<sup>®</sup> TN70E-B8026, a highly optimized rack-mountable barebone system. The TN70E-B8026 is designed to AMD<sup>®</sup> Zen<sup>®</sup> Naples series Processor, and Up to 1,024GB RDIMM/LRDIMM/NVDIMM DDR4 2667 MHz memory. Leveraging advanced technology from AMD<sup>®</sup>, TN70E-B8026 server system is capable of offering scalable 32 and 64-bit computing, high bandwidth memory design, providing a rich feature set and incredible performance, and lightning-fast PCI-E bus implementation. The TN70E-B8026 not only empowers your company in nowadays IT demand but also offers a smooth path for future application usage.

TYAN<sup>®</sup> also offers the TN70E-B8026 in a version that can support up to twelve hot-swap 2.5"/3.5" SATA HDD/SSD or NVMe SSD and two hot-swap 2.5" SSD. The TN70E-B8026 uses TYAN<sup>®</sup>'s latest chassis, featuring a robust structure and a solid mechanical enclosure. All of this provides TN70E-B8026 the power and flexibility to meet the needs of nowadays server application.



## 1.2 Product Model

The system boards within the Tyan barebone systems contain different features and chipsets, which are defined by the following models:

• **B8026T70EV10E4HR**: Intel-based platform, support (8) 3.5"/2.5" Hot-Swap HDD/SSD + (4) NVMe, (2) hot-swap 2.5" HDD/SSD

## 1.3 Features

## B8026T70EV10E4HR Specifications

	Net weight	19 kg (42 lbs)
	Form Factor	2U Rackmount
	Chassis Model	TN70E
System	Dimension (D x W x H)	27.56" x 17.72" x 3.43" (700 x 450 x 87mm)
	Motherboard	S8026GM2NRE
	Gross Weight	30 kg (66 lbs)
	Buttons	(1) RST, (1) PWR w/ LED, (1) ID
Front Panel	LEDs	(1) ID, (1) BMC event
	I/O Ports	(2) USB 2.0 ports
	Type / Q'ty	3.5"/2.5" Hot-Swap SSD/HDD + NVMe/ (8) + (4)
External Drive Bay	HDD Backplane Support	SAS 12Gb/s, SATA 6Gb/s, NVMe
	Supported HDD Interface	(8) SATA 6Gb/s + (4) NVMe
	Type / Q'ty	(2) 2.5" Hot-swap HDD/SSDs
Internal Drive Bay	Supported HDD Interface	(2) SATA 6Gb/s
System Cooling Configuration	FAN	(8) 6cm fans
	Туре	RPSU
	Input Range	AC 100-127V/10A, AC 200-240V/5A
Power Supply	Frequency	50-60 Hz
	Output Watts	770 Watts
	Efficiency	80 plus Platinum
	Redundancy	1+1
	Socket Type / Q'ty	AMD Socket SP3/ (1)
Processor	Average CPU Power (ACP) wattage	Max up to 180W
	Supported CPU Series	(1) AMD EPYC™ 7000 Series Processor

	Supported DIMM Qty		(16) DIMM slots	
	DIMM Type /		DDR4 ECC	;
Memory	Speed		RDIMM/LRI	DIMM/NVDIMM 2667
	Capacity		Up to 1,024	GB RDIMM/LRDIMM
	Memory channel		8 Channels	
	Memory vol	tage	1.2V	
Expansion Slots	PCI-E		(2) PCI-E Gen3 x8 slots, (2) PCI-E Gen3 x8 slots (w/ x0 link or x8 link), (2) PCI-E Gen3 x16 slot (w/ x16 link or x8 link), *Without using OCP 2.0 Mezz card, please contact with Tyan technical support for details.	
	Pre-install T Riser Card	<b>FYAN</b>	M7106-L24-3F, M7106-R24-3F	
	Others:		(1) PCI-E G (conn.A+co	Gen3 x16 OCP 2.0 slots onn.B)
	Port Q'ty		(2) GbE ports, (1) PHY dedicated for IPMI	
LAN	Controller		Broadcom I	BCM5720
	PHY		Realtek RT	L8211E
		Connector	(2) SF ports	FF-8612 for (16) SATA
	SATA	Controller	Direct	t from AMD CPU
		Speed	6.0 G	b/s
Storage		RAID	N/A	
	NIVMo	Connector (M.2)	(2) 22 (by P	2110/2280/2260/2242 CI-E & SATA interface)
	NVINE	Connector (OCuLink)	(4) SF ports	F-8612 for (8) NVMe
	Connector	type	D-Sub 15-p	pin
Graphic	Resolution		Up to 1920x1200	
	Chipset		Aspeed AST2500	
	USB		(3) USB3.0 TYPE-A)/ (2 front)	ports (2 at rear, 1 2) USB2.0 ports (2 at
I/O POILS	СОМ		(1) DB-9 port (COM1) + (1) header (COM2)	
	VGA		(1) D-Sub 1	5-pin port

17 http://www.tyan.com

	RJ-45	(2) GbE ports, (1) GbE dedicated for IPMI
	Chipset	Aspeed AST2500
	Temperature	Monitors temperature for CPU & memory & system environment
System Monitoring	Voltage	Monitors voltage for CPU, memory, chipset & power supply
	LED	Over temperature warning indicator, Fan & PSU fail LED indicator
	Others	Watchdog timer support
Server Management	AST2500 iKVM Feature	IPMI 2.0 compliant baseboard management controller (BMC), Supports storage over IP and remote platform-flash, USB 2.0 virtual hub
, i i i i i i i i i i i i i i i i i i i	AST2500 IPMI Feature	24-bit high quality video compression, 10/100/1000 Mb/s MAC interface
	Onboard Chipset	Onboard Aspeed AST2500
	Brand / ROM size	AMI, 32MB
BIOS	Feature	Hardware Monitor, Boot from USB device/PXE via LAN/Storage, User Configurable FAN PWM Duty Cycle, Console Redirection, ACPI 6.1, SMBIOS 3.1/PnP/Wake on LAN, ACPI sleeping states S5
Operating System	OS supported list	Please refer to our AVL support lists.
	CB/LVD	Yes
	RCM	Class A
Regulation	FCC (DoC)	Class A
	CE (DoC)	Class A
	VCCI	Class A
	Operating Temp.	10° C ~ 35° C (50° F~ 95° F)
Operating Environment	Non-operating Temp.	- 40° C ~ 70° C (-40° F ~ 158° F)
	In/Non-operating Humidity	90%, non-condensing at 35° C
RoHS	<b>RoHS 6/6 Compliant</b>	Yes

Package Contains	Manual	(1) Quick Installation Guide
	Installation CD	(1) TYAN Device Driver CD
	Barebone	(1) TN70A-B8026 Barebone

#### NOTE:

- The specifications are subject to change without prior notice.
  Please visit our website for the latest specifications.

## 1.4 Standard Parts List

This section describes TN70E-B8026 package contents and accessories. Open the box carefully and ensure that all components are present and undamaged. The product should arrive with packaged as illustrated below.

#### 1.4.1 Box Contents

If any items are missing or appear damaged, contact your retailer or browse to TYAN's website for service: <u>http://www.tyan.com</u>

- (1) 2U chassis
- (2) DELTA, DPS 770GB C 770W Power Supply (pre-installed)
- (8) 60x38mm Fan (pre-installed)
- (1) S8026GM2NRE MB
- (1) M1701T70-FPB Front Panel Board
- (1) M1702T70-USB USB Board
- (1) M1806G70-FB Fan Board
- (1) M1601T70E-D-PDB Power Distribution Board
- (1) M7106-R24-3F riser card#1
- (1) M7106-L24-3F riser card#2
- (1) M1290T70E-BP12E-12-1 HDD Backplane
- (1) M1287G88-BP12-2 HDD Backplane

## 1.4.2 Accessories

If any items are missing or appear damaged, contact your retailer or browse to TYAN's website for service: <u>http://www.tyan.com</u>

- (1) Rail kit
- (2) CPU Heatsink
- (2) CPU Clip
- (2) US power cord
- (2) EU power cord
- (1) IO PLATE LAN Kit (with gasket)
- (1) IO PLATE SFP Kit
- (1) 2.5" HDD screw pack
- (1) TYAN Quick Installation Guide
- (1) TYAN Driver CD
- (1) M.2 Screw

## 1.5 About the Product

The following views show you the product.

## 1.5.1 System Front View



HDD/NVMe Sequence	NVMe2/HDD2	SSD/HDD5	SSD/HDD8	SSD/HDD11
	NVMe1/HDD1	SSD/HDD4	SSD/HDD7	SSD/HDD10
	NVMe0/HDD0	NVMe3/HDD3	SSD/HDD6	SSD/HDD9

M1701T70-FPB Front Panel Board				
1	Power Button with green LED	5	ID Button	
2	IPMI LED	6	USB 2.0 Port	
3	ID LED	7	USB 2.0 Port	
4	RESET Button	8	3.5" /2.5" SSD/ HDD bays	

## Front Panel LED Definitions (M1701T70-FPB)

LED	State	Color	Description
	On	Green	System is turned on
Power On/Off LED	Blinking	Green	System is under S1 or S3 state
	Off	Off	Power off
Warning (IPMI) LED	On	Amber	Fan fail / Over temperature / Over Voltage / PSU fail
	On	Green	No failure
ID LED	On	Blue	System identified remotely on the server, by clicking the Chassis Locate LED key.*
	Off	Off	System not identified

#### HDD LED



LED	Color	State	Description
	Red	ON	NVME/SATA/SAS HDD fail
HDD fall LED		OFF	No failure found
	Green	ON	NVME/SATA/SAS HDD ready
		Blinking	NVME/SATA/SAS HDD access acivity
Access LED		OFF	Power disconnected

## 1.5.2 System Rear View



1	(2)770GB C 770W Power Supply	7	ID LED (Blue)
2	(2)USB3.0 Ports	8	(2)2.5" Hot-swap HDD/SSD bays
3	Serial Port	9	RJ45(LAN3) dedicate to BMC
4	RJ45(LAN1)&RJ45(LAN2)	10	VGA Port
5	Mezz Card I/O (reserved for OCP2.0 Mezz card)	11	Expansion Slots(Gen3 x16 via 2 riser cards)
6	ID Button		

#### ID LED

LED	State	Color	Description
ID LED	On	Blue	System identified
	Off	Off	System not identified

**NOTE:** Press the ID button when the system AC (Alternating Current) is on, then the ID LED will light blue if the system is identified. Users from remote sites can also activate the ID LED by entering a few commands in IPMI. For detailed software support, please visit <u>http://www.tyan.com</u> for the latest AST2500 user guide.

#### Rear I/O: Onboard LAN LED Color Definition

The **three (3)** onboard Ethernet ports have green and amber LEDs to indicate LAN status. The chart below illustrates the different LED states.

10/100/1000 Mbps LAN Link/Activity LED Scheme				
		Left LED	Right LED	
10 Mbps	Link	Green	Off	
	Active	Blinking Green	Off	
100 Mbps	Link	Green	Green	
	Active	Blinking Green	Green	
1000 Mbps	Link	Green	Amber	
	Active	Blinking Green	Amber	
No Link		Off	Off	

## 1.5.3 System Top View



1	(12) Hot-swap 3.5'/2.5' HDD trays			
2	M1290T70E-BP12E-12-1 HDD Backplane Board			
3	(8) System fans			
4	M1601T70E-D-PDB Power Distribution Board			
5	DELTA, DPS 770GB C 770W Power Supply			
6	(2) Hot-swap 2.5" SSD trays			
7	Riser Card Bracket (M7106-L24-3F, M7106-R24-3F pre-installed)			
8	Memory Slots			
9	CPU Sockets			
10	PCIE3.0 SLOT x24			
11	OCP A Slot (OCP1_A)			
12	OCP B Slot (OCP1_B)			

## Chapter 2: Setting Up

## 2.0.1 Before you Begin

This chapter explains how to install the CPUs, CPU heatsinks, memory modules, and hard drives. Instructions on inserting add on cards are also given.

#### 2.0.2 Work Area

Make sure you have a stable, clean working environment. Dust and dirt can get into components and cause malfunctions. Use containers to keep small components separated. Putting all small components in separate containers prevents them from becoming lost. Adequate lighting and proper tools can prevent you from accidentally damaging the internal components.

#### 2.0.3 Tools

The following procedures require only a few tools, including the following:

- A cross head (Phillips) screwdriver
- A grounding strap or an anti-static pad
- A T20 Security Torx screwdriver

Most of the electrical and mechanical connections can be disconnected with your hands. It is recommended that you do not use pliers to remove connectors as it may damage the soft metal or plastic parts of the connectors.



#### 2.0.4 Precautions

Components and electronic circuit boards can be damaged by discharges of static electricity. Working on a system that is connected to a power supply can be extremely dangerous. Follow the guidelines below to avoid damage to TN70E-B8026 or injury to yourself.

- Ground yourself properly before removing the top cover of the system. Unplug the power from the power supply and then touch a safely grounded object to release static charge (i.e. power supply case). If available, wear a grounded wrist strap. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Avoid touching motherboard components, IC chips, connectors, memory modules, and leads.
- The motherboard is pre-installed in the system. When removing the motherboard, always place it on a grounded anti-static surface until you are ready to reinstall it.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Do not flex or stress circuit boards.
- Leave all components inside the static-proof packaging that they ship with until they are ready for installation.
- After replacing optional devices, make sure all screws, springs, or other small parts are in place and are not left loose inside the case. Metallic parts or metal flakes can cause electrical shorts.

**NOTE:** All connectors are keyed to only attach one way. All use the correct screw size as indicated in the procedures.

## 2.1 Installing Motherboard Components

This section describes how to install components on to the mainboard, including CPUs, memory modules and add on cards.

#### 2.1.1 Removing the Chassis Cover

Follow these instructions to remove TN70E-B8026 chassis cover.

1. Remove the screw on the left side, and unscrew the rear top cover on the back side.



2. Slide to lift the rear top cover up.



29 http://www.tyan.com

## 2.1.2 Removing the Air Duct

1. Remove the air duct from the chassis.



#### 2.1.3 Installing the CPU and Heatsink

Follow the steps below on installing CPUs and CPU heat sinks.

1. Use a T20 Torx screwdriver to loosen the screws securing the force frame in a sequential order (3->2->1).

Note: The force frame will automatically eject after the captive screws are being released.



2. By placing your both index fingers on the sides on the metal handle, pull to release the rail frame. Then lift the rail frame to its fully open position.





3. Remove the external cap from the rail frame.



31 http://www.tyan.com

4. Using your thumbs and forefinger, remove the PnP cap by lifting it up vertically.



5. Align and install the carrier frame with package into the slot on the rail frame. Note: During installation, observe the following:





NOTE:

During installation, observe the following:1. Make sure to push the carrier frame with package towards the end of the rail frame until it clicks into place.2. Do not drop the carrier frame or touch the package pad to avoid component damage.

6. Carefully close the rail frame with the installed package. Then push both edges of the rail frame firmly until it locks in place.



7. Close the force frame. Then use a T20 Torx screwdriver to tighten the screws to secure the force frame in a sequential order (1 ->2->3).



8. To secure the heatsink, use a T30 Security Torx to tighten the screws. Tighten the four screws in a diagonal sequence to secure the heat sink.



33 http://www.tyan.com

## 2.1.4 Installing the PCI-E Card

Follow these instructions to install the PCI-E card.

1. Unscrew the riser card bracket.



2. Remove the riser card bracket from the chassis.



http://www.tyan.com

3. Unscrew to remove the dummy brackets.



**4.** Insert the PCI-E card into the riser card bracket and screw it firmly. Follow the same procedures to insert the card to the other side of the riser card bracket if necessary.



5. The same procedure to install the PCIE card to the second riser card.



6. Reposition and screw the riser card bracket into the chassis.


### 2.1.5 Installing the Memory

Follow these instructions to install the memory modules onto the motherboard.

1. Press the memory slot locking levers in the direction of the arrows as shown in the following illustration.



2. Align the memory module with the slot. When inserted properly, the memory slot locking levers lock automatically onto the indentations at the ends of the module. Follow the recommended memory population table to install the other memory modules.



37 http://www.tyan.com

#### Memory Population table



#### 2.1.6 Installing Hard Drives

The TN70E-B8026 supports twelve 3.5"/2.5" hot-swap HDD/SSDs and two 2.5" hot-swap SSDs.

#### Installing 3.5" Hot-Swap Hard Drives

Follow these instructions to install a 3.5" HDD.

Warning!!! Always install the hard disk drive to the chassis after the chassis has been secured on the rack.

1. Press the locking lever latch and pull the locking lever open.



2. Slide the HDD tray out.



3. Place the 3.5" hard disk drive into the HDD tray and secure the HDD to the HDD tray using 4 screws.



4. Reinsert the HDD tray into the chassis. Push to secure the locking lever until it clicks into place.



#### Installing 2.5" Hot-Swap Hard Drives

Follow these instructions to install a 2.5" HDD/SSD.

Warning!!! Always install the hard disk drive to the chassis after the chassis has been secured on the rack.

1. Press the locking lever latch and pull the locking lever open.



2. Slide the HDD tray out.



3. Place the 2.5" HDD/SSD into the HDD tray and align the 2.5" HDD/SSD with its guide pins.



4. Turn over the HDD tray and secure the HDD/SSD to the tray using 4 screws.



5. Reinsert the HDD tray into the chassis. Push to secure the locking lever until it clicks into place.



#### Installing 2.5" Hot-Swap Hard Drives

Follow these instructions to install a 2.5" SSD.

Warning!!! Always install the hard disk drive to the chassis after the chassis has been secured on the rack.

1. Press the locking lever latch and pull the locking lever open.



2. Remove the 4 screws to detach HDD tray bracket.



3. Secure one side HDD screws.



4. Secure the other side HDD screws.



5. Reinsert the HDD tray into the chassis. Push to secure the locking lever until it clicks into place.





# 2.2 Rack Mounting

After installing the necessary components, the TYAN TN70E-B8026 can be mounted in a rack using the supplied rack mounting kit.

#### **Sliding Rail Kit**

- Sliding Rails x 2
- Rail screw Pack x 1



#### **Mounting Ear Kit**

- Mounting Ears x 2
- Mounting Ears screw Pack x 1

## 2.2.1 Installing the Server in a Rack

Follow these instructions to mount the TYAN TN70E-B8026 into an industry standard 19" rack.

**NOTE**: Before mounting the TYAN TN70E-B8026 in a rack, ensure that all internal components have been installed and that the unit has been fully tested. However, to make the installation easier, we suggest that you remove all HDD trays before you insert the chassis into the rack.

#### Installing the Inner Rails to the Chassis

1. Draw out the inner rail from the rail assembly. When the rail comes to a stop pull the tab to release the latch and completely draw the inner rail out.



2. Align the inner sliding rail on the side of the server, and pull towards the arrow to secure the hooks



3. Repeat steps 2 to 4 to secure the sliding rail to the other side of the server.



#### Installing the Outer Rails to the Unit

Secure the outer rails to the rack using four M5 screws and four washers (A) on each side.



#### **Rack Mounting the Server**

1. Draw out the middle rail to the latch position.



2. When the inner rails come to a stop, pull the tab to release the latch and push the whole system in.



3. Secure the mounting ears of the unit to the rack using two M5 x 20L screws (C).



# NOTE

# **Chapter 3: Replacing Pre-Installed Components**

# 3.1 Introduction

This chapter explains how to replace the pre-installed components, including the Motherboard, M1701T70-FP Front Panel Board, M1702T70-USB Board, M1290T70E-BP12E-12-1 HDD Backplane, M1287G88-BP12-2 HDD Backplane, M1601T70-D-PDB Power Distribution board, M7106-L24-3F and M7106-R24-3F Riser cards, System fan and Power supply unit etc.

# 3.2 Disassembly Flowchart

The following flowchart outlines the disassembly procedure.



51 http://www.tyan.com

# 3.3 Removing the Cover

Before replacing any parts you must remove the chassis cover first. Follow **Chapter 2.1.1** to remove the cover of the TN70E-B8026.

# 3.4 Replacing Motherboard Components

Follow these instructions to replace motherboard components, including the motherboard.

# 3.4.1 Replacing the Riser Card

Follow these instructions to replace the M7106-L24-3F and M7106-R24-3F Riser cards.

1. Unscrew the riser card bracket.



2. Remove the riser card bracket from the chassis.





3. Unscrew the M7016-L24-3F riser card to replace with a new one.



4. Unscrew the M7016-R24-3F riser card to replace with a new one.



5. Follow the steps described earlier in reverse to reinstall the riser card bracket.

# 3.4.2 PCI-E Riser Cards Specification

#### M7106-L24-3F Riser Card



# 3.4.3 Connector Pin Definition (M7106-L24-3F)

Location	Definition
J1	PCIe X16 SLOT
J2	4P Power Connector
J3	PCIe X8 SLOT
J4	PCIe X8 SLOT

#### M7106-R24-3F Riser Card



### 3.4.4 Connector Pin Definition (M7106-R24-3F)

Location	Definition
J1	PCIe X8 SLOT
J2	4Pin Power Connector
J3	PCIe X16 SLOT
J4	PCIe X8 SLOT

	Pin	Signal	Pin	Signal
J2 (PWR1)	1	+12V	2	GND
	3	GND	4	+5V

# 3.5 Replacing the Front Panel Board

Follow these instructions to replace the M1701T70-FP Front Panel Board.

1 Unscrew to release the Front Panel Board cover.





2 Remove the Front Panel Board cover.



3 Unscrew the Front Panel Board to replace a new one.



4 Disconnect the Front Panel Board to replace a new one.



5 Follow the steps described earlier in reverse to reinstall the Front Panel Board.

# 3.5.1 Front Panel Board Specifications



Form Factor	A	18.5MMx44.2MM, 4-layer PCB		
Connectors		One 2x15 pin header for front panel connector of		
		motherboard and HDD backplane board		
	A	Power On/Off LED Color: Green (after power on)		
I EDe	$\triangleright$	ID LED Color: Blue		
	$\triangleright$	Warning (IPMI) LED Dual Color:		
		Amber (Warning) / Green (Normal)		
	$\triangleright$	RESET button		
Push buttons		ID button		
		Power On/Off button with Power On/Off LED		

### 3.5.2 FPB LED and Connector Pin Definition

LED	State	Color	Description
Dowor	On	Green	System is turned on
Power On/Off LED	Blinking	Green	System is under S1 or S3 state
	Off	Off	Power off
Warning	On	Amber	Fan fail / Over temperature / Over Voltage / PSU fail
(IPMI) LED	On	Green	No failure
ID LED	On	Blue	System identified remotely on the server, by clicking the Chassis Locate LED key.*
	Off	Off	System not identified

### J1: FPIO connector

Definition	Pin	Pin	Definition
PW_LED+	1	2	+5VSB
Кеу	3	4	ID_LED+
PW_LED-	5	6	ID_LED-
HD_LED+	7	8	LED_FAULT1-
HD_LED-	9	10	LED_FAULT2-
PWR_SW+	11	12	LAN_ACT
PWR_SW-	13	14	LAN_LINK#
RESET+	15	16	SMB_DAT
RESET-	17	18	SMB_CLK
ID_SW-	19	20	NC
Temp_sensor	21	22	NC
NC	23	24	NC
SMB_ALR	25	26	FPB_HDD_ACTIVITY_G-
SMB_CLK	27	28	FPB_HDD_FAULT_R-
SMB_DAT	29	30	GND

# 3.6 Replacing the USB Board

Follow these instructions to replace the M1702T70-USB Board.

1 Unscrew to release the USB front cover.





2 Remove the USB front cover.



3 Unscrew the USB Board.



4 Disconnect the USB Board to replace a new one.



5 Follow the steps described earlier in reverse to reinstall the USB Board.

## 3.6.1 USB Board Specifications



Form Factor	$\triangleright$	35 mmx17 mm, 4-layer PCB				
	$\checkmark$	One 2x5 pin header for front panel connector of				
Connectors		motherboard				
	$\succ$	2 USB ports				

## 3.6.2 USB Board Connector Pin Definition

#### J2: 2x5-pin Connector for FP Connector of Motherboard

Pin	Definition	Description	Pin	Definition	Description
1	VCC_USB	USB power	2	VCC_USB	USB power
3	USB_P0_N	Port1(J1) USB-	4	USB_P1_N	Port2(J3) USB-
5	USB_P0_P	Port1(J1) USB+	6	USB_P1_P	Port2(J3) USB+
7	GND1	Ground	8	GND2	Ground
9	NP		10	NC	No connect

# 3.7 Replacing the System Fan

Follow these instructions to replace the fan.

1. Disconnect the power cable.



2. Press the button to take out the fan from the chassis.



63 http://www.tyan.com

3. Release the rubber screws from the fan.



4. Loose the screws on both sides.



5. Push the latch in the direction as the arrow shown to release the fan from the iron holder.



6. Remove the iron holder to replace a new fan.



7. After replacing a new one, put the fan unit back into the cage.

# 3.8 Replacing the Fan Backplane Board

Follow these instructions to replace the M1806G70-FB Fan Board in your system.

1. Disconnect all the fan power cable.



2. Use a screw driver to unscrew the fan cage.



66 http://www.tyan.com

3. And lift it up from the chassis.



4. Release the 14 screws on the Fan Backplane Board to replace a new one.



5. Follow the steps described in reverse order to reinstall the fan cage.

### 3.8.1 Fan BP Board Specifications



Here shows the M1806G70-FB Fan Backplane Board in details.

Form Factor	254 mm x 82 mm, 4-layer PCB
Integrated I/O	<ul> <li>(2) 1x4pin R/A Power Connector</li> <li>(8) 2x2pin Fan Connectors</li> <li>(1) 2x10pin Barebone Fan Connector</li> <li>(1) 2x2pin Connector for S7086</li> </ul>

# 3.8.2 Fan BP Board LED Definitions

FAN Status	FAN Status	Green LED(Right)	Red LED(Left)
Left Right Green	With Fan	On	Off
10 A	Without Fan	Off	On

## 3.8.3 Connector Pin Definitions

#### Power Connector (PWR1/PWR2)

Definition	Pin	Pin	Definition
+12V	1	2	GND
GND	3	4	+5V

#### **Barebone Fan Connector (J8)**

Definition	Pin	Pin	Definition
FANIN1	1	2	FANIN6
FANIN2	3	4	FANIN7
FANIN3	5	6	FANIN8
FANIN4	7	8	SIO_FANIN1
FANIN5	9	10	SIO_ FANIN2
GND	11	12	Key
MB_PWM2	13	14	MB_PWM1
SIO_ FANIN3	15	16	SMBUS_3V3_DATA
SIO_ FANIN4	17	18	SMBUS_3V3_CLK
VDD_3.3_AUX	19	20	MB_PWM3

# 3.9 Replacing the HDD Backplane Board

**NOTE:** Before detach the HDD backplane, please remove all the HDD trays with HDDs, otherwise the HDD backplane will be damage when strains at the disassembly.

1. Disconnect all cables connected to the M1290T70E-BP12E-12-1 HDD Backplane. Remove the fan cage.





1. Unscrew the HDD BP Board.



70 http://www.tyan.com

2. Lift up the HDD Backplane bracket.



3. The HDD BP Board bracket is as shown below.



4. Unscrew the backplane and replace with a new HDD backplane board.



5. Follow the procedures described earlier to reinstall the HDD backplane board bracket into the chassis.

### 3.9.1 HDD Backplane Board Features



#### **Front View**

OCU Link0

#### **Rear View**



Form Factor	Dimension: 422.4*29.8mm
(2) Specifications (3)	(2) OCU Link Connector Input
	(3) Mini SAS HD Connector Input
Overview	(4) SGPIO Header
	(12) SATA HDD or (8) SATA HDD + (4) NVMe Output
## 3.9.2 Connector Definition

Location	Definition	
HDD0	SATA + NVMe Connector	
HDD1	SATA + NVMe Connector	
HDD2	SATA + NVMe Connector	
HDD3	SATA + NVMe Connector	
HDD4	SATA Connector	
HDD5	SATA Connector	
HDD6	SATA Connector	
HDD7	SATA Connector	
HDD8	SATA Connector	
HDD9	SATA Connector	
HDD10	SATA Connector	
HDD11	SATA Connector	
SATA0_3	Mini SAS HD Connector	
SATA4_7	Mini SAS HD Connector	
SATA8_11	Mini SAS HD Connector	
NVME01	OCULink Connector	
NVME23	OCULink Connector	
PW1	Power Connector	

# 3.10 Replacing the Power Distribution Board

Follow these instructions to replace the M1601T70E-D-PDB Power Distribution Board in your system.

1. Disconnect all cables connected to the power distribution board.



2. Unscrew to take off the power distribution board and replace with a new one.



3. Insert the PDB into the chassis following the above procedures in reverse.

# 3.11 Replacing the Rear HDD Backplane Board

Follow the instructions to replace the M1287G88-BP12-2 HDD backplane Board

1. Disconnect all cables and unscrew the power distribution board.



## 3.11.1 HDD Backplane Features

### **Front View**



## **Rear View**



PCB Dimensions:	93*36*2mm	
Layer:	4 layers	
	(2) SATA Connectors	
	(1) JTAG Jumper(J1)	
Integrated I/O	(1) SGPIO Connector(J2)	
	(2) 7-pin SATA connector	
	(1) 4 Pin Power connector	

## 3.11.2 Connector Definition

### HDD0: HDD Connector

Definition	Pin	Pin	Definition
SAS_TX0+	S2	S3	SAS_TX0-
GND	<b>S</b> 4	S5	SAS_RXBN0
SAS_RXBP0	<b>S</b> 6	S7	GND
SAS0_PRESENT_L	<b>S</b> 8	S9	NC
NC	S10	S11	GND
NC	S12	S13	NC
GND	S14	P1	NC
NC	P2	P3	NC
GND	P4	P5	GND
GND	P6	<b>P</b> 7	HD0_V5
VDD_5_RUN	<b>P</b> 8	P9	VDD_5_RUN
HD0_PRS_L	P10	P11	SAS0_LED
GND	P12	P13	HD0_V12HD
VDD_5_RUN	P14	P15	VDD_5_RUN
GND	S1	GND1	GND
GND	GND2		

### HDD1: HDD Connector

Definition	Pin	Pin	Definition
SAS_TX1+	S2	S3	SAS_TX1-
GND	S4	S5	SAS_RXBN1
SAS_RXBP1	S6	S7	GND
SAS0_PRESENT_L	S8	S9	NC
NC	S10	S11	GND
NC	S12	S13	NC
GND	S14	P1	NC
NC	P2	P3	NC
GND	P4	P5	GND
GND	P6	P7	HD1_V5
VDD_5_RUN	P8	P9	VDD_5_RUN
HD1_PRS_L	P10	P11	SAS1_LED
GND	P12	P13	HD1_V12HD
VDD_5_RUN	P14	P15	VDD_5_RUN
GND	S1	GND1	GND
GND	GND2		

## SATA0: SATA Connector

Definition	Pin	Pin	Definition
GND	1	2	SAS_TX0+
SAS_TX0-	3	4	GND
SAS_RXBN0	5	6	SAS_RXBP0
GND	7		

## SATA1: SATA Connector

Definition	Pin	Pin	Definition
GND	1	2	SAS_TX1+
SAS_TX1-	3	4	GND
SAS_RXBN1	5	6	SAS_RXBP1
GND	7		

### J1: JTAG Connector

Definition	Pin	Pin	Definition
CPLD_JTAG_TCK	1	2	GND
CPLD_JTAG_TDO	3	4	VDD_3P3_RUN
CPLD_JTAG_TMS	5	6	NC
NC	7	8	NC
CPLD_JTAG_TDI	9	10	GND

## J2: SGPIO Connector

Definition	Pin	Pin	Definition
SMBUS_3V3_CLK	1	2	SAS_SIO_DIN_A
SMBUS_3V3_DATA	3	4	SAS_SIO_DOUT_A
GND	5	6	SAS_SIO_END_A
NC	7	8	SAS_SIO_CLK_A
VCC3_AUX	9	10	NC

## PW1: Power Connector

Definition	Pin	Pin	Definition
VDD_12_RUN	1	2	GND
GND	3	4	VDD_5_RUN

# 3.12 Replacing the Power Supply

Follow these instructions to replace the power supply module in your system.

1. Press the latch to pull the power supply out.



2. After replacing a new power supply, press and hold the latch to push the power supply back into the chassis.



## 3.13 Disconnecting All Motherboard Cables

1. Disconnect all cables connected to the motherboard.





## 3.13.1 Removing the Motherboard

After removing all of the aforementioned cables, follow the instructions below to remove the motherboard from the chassis.

- 1. Remove the air duct, processor and heatsink if installed.
- 2. Remove nine screws securing the motherboard to the chassis.



3. Carefully lift the motherboard from the chassis.

# NOTE

# Appendix I: Installing IO Plate for OCP Card

Follow these instructions to install the IO Plate for OCP Card. Here shows how to install the IO Plate for the dual-port LAN card M7062-I599-2T.

1. Unscrew the riser card bracket.



2. Remove the riser card bracket from the chassis.



83 http://www.tyan.com 3. Use a screwdriver to break the semi-shearing for the OCP card slot. Discharge the metal slug.



4. Take out the IO plate for LAN card. Use a screwdriver to break the LAN port's semi shearing. Break one semi-shearing if a single-port LAN card is installed. Break both for a dual-port LAN card.



84 http://www.tyan.com

5. Insert the IO Plate to the OCP card LAN port.



6. Screw the IO Plate to the chassis





7. Insert the LAN card into the OCP slot



8. Secure the LAN card to the chassis



# **Appendix II: Cable Connection Tables**

#### 1. Mini-SAS HD Cable

#### B8026T70EV10E4HR SKU

M1290T70E-BP12E-12 Backplane (BP) Board to S8026MB					
Cable	HDD BP M1290T70E-BP12E-12	Connect to	S8026MB		
OCuLink	NVME 01	$\rightarrow$	OCUL5		
OCuLink	NVME 23	$\rightarrow$	OCUL6		
Mini-SAS HD	SATA 0-3	$\rightarrow$	OCUL1		
Mini-SAS HD	SATA 4-7	$\rightarrow$	OCUL1		
Mini-SAS HD	SATA 8-11	→	OCUL2		

#### 2. System FAN Ctrl cable

FAN M1806G70-FB	Connect to	S8026 MB
J8	$\rightarrow$	FAN_HD1

#### 3. Front Panel Control Cable

Front Panel M1701T70-FPB	Connect to	S8026 MB
J1	$\rightarrow$	FPIO_2

#### 4. Front Panel USB Cable

Front Panel M1702T70-USB	Connect to	S8026 MB
J2	$\rightarrow$	USB3_FPIO1

#### 5. Power Supply Cables

M1601T70-D-PDB	Connect to	S8026 MB
PW1 (MB)	$\rightarrow$	PW1
PATX1 (MB1)	$\rightarrow$	PW2
PATX2 (MB2)	$\rightarrow$	PW3
J7 (PSMI)	$\rightarrow$	PSMI_HD1

#### 6. Power Supply Cables

M1601T70-D-PDB	Connect to	M1806G70-FB
PW4(FAN BD1)	$\rightarrow$	PW1
PW5(FAN BD2)	$\rightarrow$	PW2

### 7. Power Supply Cables

M1601T70-D-PDB	Connect to	M1290T70E-BP12E-12 HDD BP
PATX6,7 (HDD BP1,2)	$\rightarrow$	HDD BP1 PW1

#### 8. Power Supply Cables

M1601T70-D-PDB	Connect to	M1287G88-BP12-2-1 Rear HDD BP
J3(DVD)	$\rightarrow$	PW1

#### 9. SATA HDD Cable

S8026 MB	Connect to	M1287G88-BP12-2-1 Rear HDD BP
SSATADOM1	$\rightarrow$	SSATA0
SSATADOM2	$\rightarrow$	SSATA1

#### 10. SGPIO Cable

S8026 MB	Connect to	M1290T70E-BP12E-12-1 HDD BP
SGPIO0		SGPI00
SGPIO1	$\rightarrow$	SGPIO2

#### 11. Control Internal cable

S8026 MB	Connect to	Chassis
J122	$\rightarrow$	Chassis

# **Appendix III: Fan and Temp Sensors**

This section aims to help readers identify the locations of some specific FAN and Temp Sensors on the motherboard. A table of BIOS Temp sensor name explanation is also included for readers' reference.



NOTE: The red dot indicates the sensor.

### Fan and Temp Sensor Location:

- 1. Fan Sensor: It is located in the third pin of the fan connector, which detects the fan speed (rpm)
- 2. Temp Sensor: SYS\_Air\_Outlet ,and MB\_Air\_Inlet etc. They detect the system temperature around.

**NOTE:** The system temperature is measured in a scale defined by **AMD**, not in Fahrenheit or Celsius.

## **BIOS Temp Sensor Name Explanation:**

Aptio S Advanced	etup Utility	– Copyright (	C) 2017 American Megatrends, Inc.
PC Health Status ID# NAME	READING	UNIT STATUS	
01 CPU_TC11_Value 07 MB_Air_Inlet 08 SVS_Air_Inlet 09 SVS_Air_Inlet 00 CPU_SOC_MOSFET 00 CPU_SOC_MOSFET 00 CPU_SOC_MOSFET_1 00 CPU_SOC_MOSFET_1 00 DIUMMOSFET_1 00 DIUMC1_CH_B 12 PO_D0_UMC1_CH_B 12 PO_D0_UMC1_CH_B 13 PO_D0_UMC1_CH_E 15 PO_D0_UMC1_CH_F 16 PO_D2_UMC1_CH_F 16 PO_D2_UMC1_CH_F 16 PO_D2_UMC1_CH_G 17 PO_D2_UMC0_CH_H 15 PVPDDCR_CPU 15 PVPP_ABCD 16 PVPD_EFGH 16 PVDDID_EFGH 16 PVDDID_EFGH 17 PVDDID_EFGH 17 PVDDID_SOC	: 40 : 24 : 24 : 24 : 46 : 39 : 27 : 26 : N/A :	*C OK *C OK	++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Versio	n 2.18.1264.	Copyright (C)	2017 American Megatrends, Inc.

Aptio Se Advanced	tup Utility – (	Copyright (C) 2017 American	Megatrends, Inc.
Aptio Se Advanced	tup Utility - ( : 0.8360 : 0.9064 : 1.8018 : 1.8018 : 12.090 : 5.088 : 3.3170 : 3.3170 : N/A F : N/A F : 11300 F : 11300 F : 11300 F : 11200 F : N/A F : N/A F	Copyright (C) 2017 American V OK  A V OK  V OK V OK V OK V OK V OK V OK V OK V OK V OK RPM OK	<pre>Megatrends, Inc.  **: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save &amp; Exit E5C: Exit</pre>
6B SYS_FAN_10 6C SYS_FAN_11 6D SYS_FAN_12 90 PSU_Status	: N/A F : N/A F : N/A F : 1	RPM OK RPM OK RPM OK OK ▼	F4: Save & Exit ESC: Exit

Version 2.18.1264. Copyright (C) 2017 American Megatrends, Inc.

CPU_Tct1_Value	Temperature of the CPU_Tct1
MB_Air_Inlet	Temperature of the MB_Air_Inlet Area
SAS_Air_Outlet	Temperature of the SAS_Air_Outlet Area
SAS_Air_Inlet	Temperature of the SAS_Air_Inlet Area
CPU_CORE_MOSFET	Temperature of the CPU_ CORE_MOSFET
CPU_SOC_MOSFET	Temperature of the CPU_SOC_MOSFET
DIMM_MOSFET_1	Temperature of the DIMM MOSFET_1
DIMM_MOSFET_2	Temperature of the DIMM MOSFET_2
P0_D1_UMC0_CH_A	The highest temperature of CPU0 D1UMC0 channel A slot
P0_D1_UMC1_CH_B	The highest temperature of CPU0 D1 UMC1 channel B slot
P0_D0_UMC1_CH_C	The highest temperature of CPU0 D0 UMC1 channel C slot
P0_D0_UMC0_CH_D	The highest temperature of CPU0 D0 UMC0 channel D slot
P0_D3_UMC0_CH_E	The highest temperature of CPU0 D3 UMC0 channel E slot
P0_D3_UMC1_CH_F	The highest temperature of CPU0 D3 UMC1 channel F slot
P0_D2_UMC1_CH_G	The highest temperature of CPU0 D2 UMC1 channel G slot
P0_D2_UMC0_CH_H	The highest temperature of CPU0 D2 UMC0 channel H slot
BIOS FAN Sensor	Name Explanation
CPU0_FAN	Fan speed of CPU0_FAN
SYS_FAN_1	Fan speed of SYS_FAN_1
SYS FAN 2	Fan speed of SYS_FAN_2

SYS_FAN_3	Fan speed of SYS_FAN_3
SYS_FAN_4	Fan speed of SYS_FAN_4
SYS_FAN_5	Fan speed of SYS_FAN_5
SYS_FAN_6	Fan speed of SYS_FAN_6
SYS_FAN_7	Fan speed of SYS_FAN_7
SYS_FAN_8	Fan speed of SYS_FAN_8
SYS_FAN_9	Fan speed of SYS_FAN_9
SYS_FAN_10	Fan speed of SYS_FAN_10
SYS_FAN_11	Fan speed of SYS_FAN_11
SYS_FAN_12	Fan speed of SYS_FAN_12

# **Appendix IV: FRU Parts Table**

TN70E-B8026 FRU Parts							
Item	Model Number	Part Number	Picture	Description			
Power Supply	FRU-PS-0100	471100000247	4	TF-POWER SUPPLY;SBU,770 W,DELTA,DPS-770GB C,(S0F),1U MODULE,REV.S0F			
FAN	FRU-TS-0080	336252012309	0	TF-FAN;SBU,12V,PFC0612DE-7N51,2BALL ,1.68A,12000RPM,61.5dBA,60*60*38M M,4PIN			
Heatsink	FRU-TH-0200	343T58100002	the second se	TF-HEATSINK;SBU,AL/CU,SOLDERLING+PI PE,SP3-PASSIVE-1U-HEATSINK,SF4A9100 01-1,78.9X119.3X25.0MM, SCREW,TN70A-B8026			
PCIE Riser Card	FRU-C-0490	411T56400041	■ Control of the	TF-PWA;SBU,TN70E-B7106,M7106-L24-3 F,R02,For BB,TYAN			
	FRU-RC-0500	411T56400046		TF-PWA;SBU,TN70E-B7106,M7106-R24-3 F,R02,For BB,TYAN			
HDD BP	FRU-RC-0700	411T56400129		TF-PWA;SBU,TN70E-B7106,M1290T70E-B P12E-12-1,R02,FOR BB,TYAN			
Rack Mounting	CRAL-0170	340786900010		TF-SLIDE RAIL MIC ASSY;SBU,YELLOW RIVER DP,B7018Y190X2			
Cable	FRU-CS-0330	332810000514		TF-POWER CORD;SBU,US,125 V,16 AWG(1.31mm²),1800mm,AC PWR CORD			
	CCBL-0300	332810000281		TF-PWR CORD;EU,250V,H05VV-FX3C,10A,0.75M M,1830MM			
	FRU-CS-0270	422T53400006		MINI-SAS HD CABLE			
	FRU-CS-0781	422T57100005	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	TF-CABLE ASSY;SAS INTERNAL,SBU,32 AWG,600 mm,OCuLink 8X to OCuLink 8X CABLE,OCuLink 8X 80P/OCuLink 8X 80P,Normal Signal,No Reserved pin,TN70A-B8026			
	FRU-CS-0800	422T57200001	-0-	TF-CABLE ASSY;SAS INTERNAL,SBU,34 AWG,750 mm,OCuLink 8X CABLE, OCuLink 8X 80P/OCuLink 8X 80P, GT62F-B5630			
	FRU-CS-0780	422T57100001	-07	TF-CABLE ASSY;SAS INTERNAL,SBU,34 AWG,600 mm,OCuLink 8X CABLE, OCuLink 8X 80P/OCuLink 8X 80P,TN70A-B8026			

	FRU-CS-0581	422T56400007	-0-	TF-CABLE ASSY;SAS INTERNAL,SBU,32 AWG,700 mm,OCuLink 8X to Mini-SAS HD CABLE,OCuLink 8X 80P/SHORT MINI-SAS HD 36P*2,TN70E-B7106
	FRU-CS-0580	422T56400002	~~~	TF-CABLE ASSY;SAS INTERNAL,SBU,34 AWG,700 mm,OCuLink 8X CABLE, OCuLink 8X 80P/SHORT MINI-SAS HD 36P*2,TN70E-B7106
	FRU-CS-0890	332820000010	-0-	TF-AC/DC POWER CABLE;SBU,18 AWG,200mm,2*4P PWR Y CABLE,2*4P(M),P4.2/2*4P(M),P4.2+2*4P (M),P4.2,TN70-B7016
	FRU-CS-0900	422T56700003	-0-	TF-AC/DC POWER CABLE;SBU,24 AWG,350MM,S4P PWR CABLE,1*4P(M),P2.54/1*4P(M),P2.54,GA 88-B5631
Air Duct	FRU-TA-0070	344T57100002		TF-AIRDUCT;SBU,PC+ABS, TN70A-B8026
I/O PLATE LAN KIT	FRU-SO-0160	452T57200005		TF-I/O PLATE LAN KIT;SBU,SGCC+SCREW +GASKET,GT62F-B5630
I/O PLATE SFP KIT	FRU-SO-0150	452T57200006		TF-I/O PLATE SFP KIT;SBU, SGCC+SCREW,GT62F-B5630

# **Appendix V: Technical Support**

If a problem arises with your system, you should first turn to your dealer for direct support. Your system has most likely been configured or designed by them and they should have the best idea of what hardware and software your system contains. Hence, they should be of the most assistance for you. Furthermore, if you purchased your system from a dealer near you, take the system to them directly to have it serviced instead of attempting to do so yourself (which can have expensive consequence).

If these options are not available for you then MITAC COMPUTING TECHNOLOGY CORPORATION can help. Besides designing innovative and quality products for over a decade, MITAC has continuously offered customers service beyond their expectations. TYAN's website (http://www.tyan.com) provides easy-to-access resources such as in-depth Linux Online Support sections with downloadable Linux drivers and comprehensive compatibility reports for chassis, memory and much more. With all these convenient resources just a few keystrokes away, users can easily find their latest software and operating system components to keep their systems running as powerful and productive as possible. MITAC also ranks high for its commitment to fast and friendly customer support through email. By offering plenty of options for users, MITAC serves multiple market segments with the industry's most competitive services to support them.

TYAN's tech support is some of the most impressive we've seen, with great response time and exceptional organization in general." — Anandtech.com

Please feel free to contact us directly for this service at tech-support@tyan.com

#### Help Resources:

- 1. See the TYAN's website for FAQ's, bulletins, driver updates, and other information: <u>http://www.tyan.com</u>
- 2. Contact your dealer for help before calling TYAN.
- 3. Check the TYAN user group: alt.comp.periphs.mainboard.TYAN

#### **Returning Merchandise for Service**

During the warranty period, contact your distributor or system vendor FIRST for any product problems. This warranty only covers normal customer use and does not cover damages incurred during shipping or failure due to the alteration, misuse, abuse, or improper maintenance of products.

#### Note:

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service can be rendered. You may obtain service by calling the manufacturer for a Return Merchandise Authorization (RMA) number. The RMA number should be prominently displayed on the outside of the shipping carton and the package should be mailed prepaid. TYAN will pay to have the board shipped back to you.

TYAN<sup>®</sup> TN70E-B8026 Service Engineer's Manual V1.0

Document No.: D2425 - 100