



# **STARTING GUIDE**

# FRENIC-Eco · FRN-F1

Frequency inverter for HVAC applications

3-phase 400V 0.75 - 560kW

Last update: 281020087 SG\_Eco\_EN\_2.1.0

Version	Changes applied	Date	Written	Checked	Approved
2.0.0	Second edition	26/06/2007	D. Bedford		
2.1.0	ROM 1900 functions added Small corrections	28/10/2008	J.Rasmussen	D. Bedford	



# FRENIC-ECO

CONTE Chapter	NTS	Page
1.	SAFETY INFORMATION AND CONFORMITY TO STANDARDS	1
1.1	Safety information	1
1.2	Conformity to European Standards	3
2.	MECHANICAL INSTALLATION	4
2.1	Installing the inverter	4
2.2	Removing and mounting the inverter covers	4
3.	ELECTRICAL INSTALLATION	5
3.1	Power terminals	5
3.2	Control terminals	5
3.3	Wiring diagram	6
3.4	Digital inputs (X1, X2, X3, X4, X5, FWD and REV)	7
3.5	Digital outputs (Y1, Y2, Y3, Y5A/C and 30A/B/C)	8
3.6	Setting up the slide switches	9
4.	OPERATION USING THE KEYPAD	10
5.	QUICK START COMMISSIONING	11
5.1	Inspection and preparation prior to powering on	11
5.2	Setting the function codes	11
5.3	Quick start commissioning (auto tuning)	12
5.4	Operation	12
6.	FUNCTION CODES AND APPLICATION EXAMPLES	13
6.1	Function codes tables and basic description	13
6.2	Application examples	25
6.2.1	Line-Inverter changeover	25
6.2.2	Select Multistep Frequencies (7 different set point frequencies)	28
6.2.3	PID Controller	28
7.	TROUBLESHOOTING	31
8.	SPECIFICATIONS AND EXTERNAL DIMENSIONS	32
8.1	IP20/IP00 specifications	32
8.2	IP54 specifications	33
8.3	External dimensions	34
8.3.1	IP20/IP00 dimensions	34
8.3.2	IP54 dimensions	36
8.3.3	Keypad dimensions TP – E1	37
8.3.4	Keypad dimensions TP – G1	37
8.3.5	Dimensions DC Reactors	38
8.3.6	Dimensions EMC input filters	40
9.	OPTIONS	43
9.1	Options table	43
9.2	EMC input filter	44
9.3	DC Reactors	44







# Preface

Thank you for purchasing our FRENIC-Eco series of inverters.

This product is designed to drive a three-phase induction motor for fan and pump applications.

Read through this starting guide and become familiar with proper handling and operation of this product. Please note that this starting guide should enable you to get familiar with the main functions and should help you to install the inverter. Not all functions are described here. For more detailed information please refer absolutely to the attached CD-ROM which contains the user's manual (MEH456).

Improper handling might result in incorrect operation, a short life, or even a failure of this product as well as the motor. Have this manual delivered to the end user of this product. Keep this starting guide and CD-ROM in a safe place until this product is discarded.

Listed below are the other materials related to the use of the FRENIC-Eco. Read them in conjunction with this starting guide as necessary.

FRENIC-ECO User's Manual	(MEH456)
<ul> <li>RS485 Communication User's Manual</li> </ul>	(MEH448b)
Catalogue	(MEH442c)
RS485 Communications Card "OPC-F1-RS" Installation Manual	(INR-SI47-0872)
<ul> <li>Relay Output Card "OPC-F1-RY" Instruction Manual</li> </ul>	(INR-SI47-0873)
Mounting Adapter for External Cooling "PB-F1" Installation Manual	(INR-SI47-0880)
Panel-mount Adapter "MA-F1" Installation Manual	(INR-SI47-0881)
<ul> <li>Multi-function Keypad "TP-G1" Instruction Manual</li> </ul>	(INR-SI47-0890-E)
FRENIC Loader Instruction Manual	(INR-SI47-1185-E)
Pump Control Instruction Manual	(INR-SI47-1107-E)
Profibus DP Interface Card "OPC-F1-PDP" Instruction Manual	(INR-SI47-1144-JE)
<ul> <li>Device Net Interface Card "OPC-F1-DEV" Instruction Manual</li> </ul>	(INR-SI47-0904)
<ul> <li>LonWorks Interface Card "OPC-F1-LNW" Instruction Manual</li> </ul>	(INR-SI47-1071a)

The materials are subject to change without notice. Be sure to get the latest editions for use.



# 1. SAFETY INFORMATION AND CONFORMITY TO STANDARDS

## 1.1 Safety information

Read this manual thoroughly before proceeding with installation, connections (wiring), operation, or maintenance and inspection. Ensure you have enough knowledge of the device and familiarize yourself with all safety information and precautions before proceeding to operate the inverter. Safety precautions are classified into the following two categories in this manual.

RENIC-

Not considering the information indicated by this symbol may lead to dangerous conditions, possibly resulting in death or serious bodily injuries.	
Not considering the information indicated by this symbol may lead to dangerous conditions, possibly resulting in minor or light bodily injuries and/or substantial property damage.	

Not considering the information contained under the CAUTION title can also result in serious consequences. These safety precautions are of utmost importance and must be observed at all times.

#### Application

# 

- FRENIC-Eco is designed to drive a three-phase induction motor. Do not use it for single-phase motors or for other purposes. Fire or an accident could occur.
- FRENIC-Eco may not be used for a life-support system or other purposes directly related to human safety.
- Though FRENIC-Eco is manufactured under strict quality control, install safety devices for applications where serious accidents or material losses are foreseen in relation to the failure of it. An accident could occur.

#### Installation

# 

- Install the inverter on a nonflammable material such as metal. Otherwise fire could occur.
- Do not place flammable matter nearby. Doing so could cause fire.

# 

- Do not support the inverter by its terminal block cover during transportation. Doing so could cause the inverter to drop and injuries.
- Prevent lint, paper fibers, sawdust, dust, metallic chips, or other foreign materials from getting into the inverter or from accumulating on the heat sink. Otherwise, a fire or an accident might result.
- Do not install or operate an inverter that is damaged or lacking parts. Doing so could cause fire, an accident or injuries.
- Do not get on a shipping box.
- Do not stack shipping boxes higher than the indicated information printed on those boxes. Doing so could cause injuries.

#### Maintenance, inspection, and parts replacement

# **WARNING**

- Turn the power OFF and wait for at least five minutes for models of 30 kW or below, or ten minutes for models of 37 kW or above, before starting inspection. Further, check that the LED monitor is unlit, and check the DC link bus voltage between the P (+) and N (-) terminals to be lower than 25 VDC. **Otherwise, electric shock could occur.**
- Maintenance, inspection, and parts replacement should be made only by qualified persons.
- Take off the watch, rings and other metallic matter before starting work.
- Use insulated tools. Otherwise, electric shock or injuries could occur.

#### Disposal

# 

• Handle the inverter as an industrial waste when disposing of it. Otherwise injuries could occur.

#### Others

# 

• Never attempt to modify the inverter. Doing so could cause electric shock or injuries.



1



# FRENIC-ECO

#### Wiring

# 

- When wiring the inverter to the power source, insert a recommended moulded case circuit breaker (MCCB) or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) with overcurrent protection in the path of power lines. Use the devices within the recommended current range.
- Use wires in the specified size. Otherwise, fire could occur.
- Do not use one multicore cable in order to connect several inverters with motors.
- Do not connect a surge killer to the inverter's output (secondary) circuit. Doing so could cause fire.
- Ground the inverter following national/local electric code, depending on the input (primary) voltage of the inverter. Otherwise, electric shock could occur.
- Qualified electricians should carry out wiring.
- Be sure to perform wiring after turning the power OFF. Otherwise, electric shock could occur.
- Be sure to perform wiring after installing the inverter body. Otherwise, electric shock or injuries could occur.
- Ensure that the number of input phases and the rated voltage of the product match the number of phases and the voltage of the AC power supply to which the product is to be connected. **Otherwise fire or an accident could occur.**
- Do not connect the power source wires to output terminals (U, V, and W). Doing so could cause fire or an accident.
- Generally, control signal wires do not have reinforced insulation. If they accidentally touch any live parts in the main circuit, their insulation coat may break for any reasons. In such a case, an extremely high voltage may be applied to the signal lines. Protect the signal line from contacting any high voltage lines. **Otherwise, an accident or electric shock could occur.**

# 

- Wire the three-phase motor to terminals U, V, and W of the inverter. Otherwise injuries could occur.
- The inverter, motor and wiring generate electric noise. Take care of malfunction of the nearby sensors and devices. To prevent the motor from malfunctioning, implement noise control measures. Otherwise an accident could occur.

#### Setting control switches

# 

 Before setting up any internal control switches, turn OFF the power, wait more than five minutes for models of 30 kW or below, or ten minutes for models of 37 kW or above, and make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P (+) and N (-) has dropped below a safe voltage (+25 VDC). Otherwise electric shock could occur.

#### Operation

# 

- Be sure to install the terminal block cover and the front cover before turning the power ON. Do not remove the covers while power is applied. Otherwise electric shock could occur.
- Do not operate switches with wet hands. Doing so could cause electric shock.
- If the retry function has been selected, the inverter may automatically restart and drive the motor depending on the cause of tripping.
- (Design the machinery or equipment so that human safety is ensured after restarting.)
- If the stall prevention function (current limiter), automatic deceleration, and overload prevention control have been selected, the inverter may operate at an acceleration/deceleration time or frequency different from the commanded ones. Design the machine so that safety is ensured even in such cases. Otherwise an accident could occur.
- The STOP key is only effective when function setting (Function code F02) has been established to enable the STOP key. Prepare an emergency stop switch separately. If you disable the STOP key priority function and enable operation by external commands, you cannot emergency-stop the inverter using the STOP key on the keypad.
- If an alarm reset is made with the Run command signal turned ON, a sudden start will occur. Ensure that the Run command signal is turned OFF in advance. Otherwise an accident could occur.
- If you enable the "restart mode after momentary power failure" (Function code F14 = 3, 4, or 5), then the inverter automatically restarts running the motor when the power is recovered. Design the machinery or equipment so that human safety is ensured after restarting.
- If you set the function codes incorrectly or without completely understanding this instruction manual and the FRENIC-Eco User's Manual (MEH456), the motor may rotate with a torque or at a speed not permitted for the machine. An accident or injuries could occur.
- Do not touch the inverter terminals while the power is applied to the inverter even if the inverter stops. Doing so could cause electric shock.

# 

- Do not turn the main circuit power (circuit breaker) ON or OFF in order to start or stop inverter operation. Doing so could cause failure.
- Do not touch the heat sink because it becomes very hot. Doing so could cause burns.
- Setting the inverter to high speeds is easy. Before changing the frequency (speed) setting, check the specifications of the motor and machinery.
- The brake function of the inverter does not provide mechanical holding means. Injuries could occur.

## **GENERAL PRECAUTIONS**

Drawings in this manual may be illustrated without covers or safety shields for explanation of detail parts. Restore the covers and shields in the original state and observe the description in the manual before starting operation.







# 1.2 Conformity to European standards

The CE marking on Fuji products indicates that they comply with the essential requirements of the Electromagnetic Compatibility (EMC) Directive 89/336/EEC issued by the Council of the European Communities and the Low Voltage Directive 73/23/EEC.

EMC-filter built-in inverters that bear a CE Marking are in conformity with EMC Directives. Inverters having no EMC filter can be in conformity with EMC Directives if an optional EMC-compliant filter is connected to them.

General-purpose inverters are subject to the regulations set forth by the Low Voltage Directive in the EU. Fuji Electric declares the inverters bearing a CE marking are compliant with the Low Voltage Directive.

The FRENIC-Eco series of inverters conforms to the following standards: Low Voltage Directive EN50178:1997

EMC Directives EN61800-3:2004

For further information please check the FRENIC-Eco user's manual.

Considerations when using FRENIC-Eco as a product with conformity to Low Voltage Directive If you wish to use a FRENIC-Eco series inverter as a product with conformity to the Low Voltage Directive, refer to the related guidelines.





# 2. MECHANICAL INSTALLATION

(nut

## 2.1 Installing the inverter



#### Mounting base

The inverter should be mounted on a base made of material that can withstand heat sink temperature, which can rise up to 90°C approx. during inverter operation.

#### Clearances

Ensure that the minimum clearances indicated are maintained at all times. When installing the inverter in the enclosure of your system, take extra care with ventilation inside the enclosure as the temperature around the inverter will tend to increase. Do not install the inverter in a small enclosure with poor ventilation.

\* For 400V class 90kW or above a 50 mm clearance is needed instead of 10 mm (left and right sides).

As long as the ambient temperature is 40°C or lower, 5.5 kW or lower inverters may be mounted side-by-side without any gap between them. For others inverters, please follow the clearances needed.

#### 2.2 Removing and mounting the inverter covers (for inverters 37kW or above, please refer to user's manual for details)

For mounting the covers, please follow removing instructions in the opposite way.

- ① To remove the terminal block cover, loose the screw, hold the cover using the labelled "PULL" indication, pull it up towards you.
- ② To remove the front cover (keypad cover), hold it with both hands, slide it downwards, disengage the latch, tilt the front cover towards you and pull it upwards.









# 3. ELECTRICAL INSTALLATION

# 3.1. Power terminals

Symbol Name		Description	
L1/R, L2/S, L3/T	Main power inputs	Connect the 3-phase input power lines Input voltage for F1S-4: 380-460V AC 50/60Hz Input voltage for F1S-2: 200-230V AC 50/60Hz	
U, V, W	Inverter outputs	Connect a 3-phase motor	
R0, T0 Auxiliary power input		For a backup of the control circuit power supply, connect AC power lines same as that of the main power input	
P1, P(+) DC reactor connection		Connect a DC reactor (DCRE) for improving power factor (an option for the inverter whose capacity is 55 kW or below)	
P(+), N(-) DC link bus		An optional PWM regenerative converter may be connected to these terminals	
R1, T1	Auxiliary power input for the fans	Auxiliary power input for the fans for 55KW or above inverters (400V AC series) or 45KW or above inverters (200V AC series)	
<b>⊜</b> G x 2	Ground terminals	Grounding terminals for the inverter's chassis (or case) and motor. Earth one of the terminals and connect the grounding terminal of the motor. Inverters provide a pair of grounding terminals that function equivalently	

# 3.2. Control terminals

The FRENIC-Eco has 7 digital inputs, 3 transistor outputs, 2 relay outputs and 2 analog outputs. All of them are programmable.

Symbol	Name	Programmable	Example of use	Description
PLC	Internal power supply			24V DC max. current 50mA
СМ	Digital common			Common terminal (0V)
FWD	Digital input	YES	RUN command	External run command (forward) Set the required function in E98
REV	Digital input	YES	RUN command	External run command (reverse) Set the required function in E99
X1, X2, X3, X4 and X5	Digital inputs	YES	Speed selection, coast to stop,	Programmable digital inputs Set the required function in E01 to E05
Y5 A/C	Digital relay output	YES	MC control signal, inverter ready,	Programmable digital outputs (relay outputs)
30 A,B,C	Digital relay output	YES	To indicate if inverter is under error (alarm)	Set the required function in E24 and E27
Y1, Y2 and Y3	Digital transistor outputs	YES	Same as relay output Y5A/C and 30A/B/C	Programmable digital outputs (transistor outputs) Set the required function in E20 to E22
СМҮ	Transistor output common			Common terminal for digital transistor outputs (Y1 to Y3)
13	Potentiometer power supply			Potentiometer 1 - 5 K $\Omega$ 10V DC 10 mA max.
12	Analog input (0 - 10 V DC)		Pressure command	Max. input voltage +15 V DC Input impedance 22 K $\Omega$
C1	Analog input (4 - 20 mA DC)		Feedback	Max. current +30 mA DC Input impedance 250 $\Omega$
V2	Analog input (0 - 10 V DC)		Pressure command	Max. input voltage +15 V DC Input impedance 22 KΩ
11	Common terminal for analog inputs and outputs			Common terminal for analog input and output terminals
FMA	Analog output	YES	Motor output (kW), output current,	<ul> <li>0 - 10 V DC or 4 - 20 mA DC selectable Input impedance of external device:</li> <li>0 - 10 V DC: 5 KΩ; 4 - 20 mA DC: 500 Ω</li> </ul>
FMI	Analog output	YES	Motor output (kW), Output current,	4 - 20 mA DC no selectable Input impedance of external device: 500 $\Omega$







# 3.3. Wiring diagram

Following there is a basic wiring diagram.









# 3.4. Digital inputs (X1, X2, X3, X4, X5, FWD and REV)

The digital inputs can be operated in PNP logic (ON level by means of +24V DC) or NPN logic (ON level by means of 0V). The logic is selectable by using the switch SW1 located on the inverter control board (please refer to chapter 3.6).

## Example connection: PNP logic (SOURCE)

#### (a) Using external power supply



24 VDC power supply

## (b) Using inverter power supply



# Example connection: NPN logic (SINK)

#### (a) Using external power supply



24 VDC power supply

<u>Electrical specification for digital inputs:</u> (X1 to X5, FWD and REV)

	Item	Min	Max
SIMK	ON level	0 V DC	2V DC
SINK	OFF level	22 V DC	27V DC
SOUDCE	ON level	22 V DC	27V DC
SUURCE	OFF level	0 V DC	2V DC

Item	Min	Max
Max. operation current at ON	2.5 mA	5 mA
Allowable leakage current at OFF	-	0.5 mA



#### (b) Using inverter power supply







# 3.5. Digital outputs (Y1, Y2, Y3, Y5A/C and 30A/B/C)

Transistor digital outputs can be operated both in PNP (SOURCE) or NPN (SINK) logic. The logic is selectable depending on the connection is made. Connecting the "PLC" terminal to the transistor common "CMY" terminal you get PNP logic. Connecting the "CM" terminal to the transistor common "CMY" terminal you get NPN logic.

#### Connection example: output "PNP" logic

a) Using external power supply



Connection example: output "NPN" logic

a) Using external power supply



24 VDC power supply

<u>Electrical specifications for transistor digital outputs:</u> (Y1, Y2 and Y3)

	Мах	
Operation	ON level	3V DC
voltage	OFF level	27V DC
Maximum oper	50 mA	
Leakage	0,1 mA	





(b) Using inverter power supply



<u>Electrical specifications for relay digital outputs:</u> (Y5A/C and 30A/B/C)

48V DC, 0.5 A	
250V AC, 0.3A, $\cos \phi = 0.3$	







## 3.6 Setting up the slide switches

Switching the slide switches located on the PCB allows you to customize the operation mode of the analog output terminals, digital I/O terminals, and communication ports. The locations of those switches are shown in Figure 3.1. To switch the slide switches, remove the front and terminal block covers, so that you can see the control PCB that contains the

switches. Furthermore, for models of 37 kW or above, open the keypad enclosure. Table 3.1 lists function of each slide switch.

Table 3.1. Function of Each Slide Switch

Switch	Function						
1 SW1	<ul> <li>Switches service mode of the digital input terminals for SINK or SOURCE.</li> <li>To make the digital input terminal [X1] to [X5], [FWD] or [REV] serve as a current sink, switch SW1 to SINK.</li> <li>To make them serve as a current source, switch SW1 to SOURCE.</li> </ul>						
2 SW3	<ul> <li>Switches on/off the terminating resistor of RS485 communications port of the inverter.</li> <li>To connect a keypad to the inverter switch SW3 to OFF (factory default).</li> <li>If the inverter is connected to the RS485 communications network as a termination device, switch it to ON.</li> </ul>						
3 SW4	Switches output mode of the analog output terminal FMA to voltage or current.         When switching this switch, change also data of the function code F29.         Switch SW4 to:       Set data of F29 to:         Voltage output (Factory default)       VO       0         Current output       IO       1						
۵ SW5	Switches property of the analog input terminal V2 for voltage input or PTC.         When switching this switch, change also data of the function code H26         Switch SW5 to:       Set data of H26 to:         Analog frequency command source in voltage input       V2         (Factory default)       PTC         PTC thermistor input       PTC						

## Figure 3.1. Location of the slide switches





SW3









# 4. OPERATION USING THE KEYPAD

The keypad consists of a 4 digit LED monitor, 5 LED indicators, and 6 keys, as shown in the figure.

The keypad allows you to start and stop the motor, monitor running status and switch to the menu mode. In the menu mode you may set the function code data, monitor I/O signal states and check the maintenance information as well as the alarm information.



The keypad has 3 operation modes: programming mode, running mode and alarm mode.

Operation mode		Programming mode		Running mode			
Monit	Monitor, keys		STOP	RUN	STOP	RUN	Alarm mode
		Function	Displays the function code or data		Displays the output frequency, set frequency, loader motor speed, required power, output current and output voltage		Displays the alarm description and alarm history
	8.8.8.8	Display	ON		Blinking	ON	Blinking/ON
		Function	The program mode is indic	ated	Displays the unit of frequency, outp and line speed.	ut current, required power, speed	None
Monitor	PRG.MODE	Display	PRG M Hz r/min_jt	ODE A ∎ kW nVmin ON	Frequency indication PRG MODE   Hz   A   KW I r/min   m/min   ON Current indication PRG MODE   Hz   A   KW I r/min   m/min   ON	Speed indication PRG_MODE Hz A KW r/min m/min ON Capacity of current indication PRG_MODE Hz A KW r/min m/min Blink or lit	OFF
	KEYPAD Function		Operation selection (keypad operation/terminal operation) is displayed				
	CONTROL	Display			Lit in keypad operation mode (F0	2 = 0, 2 or 3)	
		Function	Absence of operation command is displayed	Presence of operation command is displayed	Absence of operation command is displayed	Presence of operation command is displayed	Stop state due to trip is displayed
		Display	RUN	RUN	RUN	RUN	If an alarm occurs during operation, unlit during keypad operation or lit during terminal block operation

Keys	PRG RESET	Function	Switches to running mode		Switches to programming mode	Releases the trip and switches to stop mode or running mode	
			Digit shift (cursor movemen	nt) in data setting			
	FUNC	Function	Determines the function code, stores and updates data		Switches the LED monitor display		Displays the operation information
	$\bigcirc$	Function	Increases/decreases the function code and data		Increases/decreases the frequency, motor speed and other settings		Displays the alarm history
	RUN	Function	Invalid		Starts running (switches to running mode (RUN))	Invalid	Invalid
	STOP	Function	Invalid	Deceleration stop (switches to programming mode STOP)	Invalid	Deceleration stop (switches to running mode STOP)	Invalid

- If F02 = 1, the RUN key will not be enabled (RUN command by digital input terminals).

- If F02 = 1, the STOP key will not be enabled (RUN/STOP command by digital input terminals).

- If H96 = 1 or 3, STOP key located on the keypad will stop the motor with priority, even if other RUN/STOP commands are enabled.





# 5. QUICK START COMMISSIONING

## 5.1 Inspection and preparation prior to powering on

(1) Please check if the power wires are correctly connected to the inverter input terminals L1/R, L2/S and L3/T, if the motor is connected to the inverter terminals U, V and W and if the grounding wires are connected to the ground terminals correctly.

# A WARNING

- Do not connect power supply wires to the inverter output terminals U, V, and W. Otherwise, the inverter may be damaged if you turn the power on.
- Be sure to connect the grounding wires of the inverter and the motor to the inverter ground terminals.

Otherwise an electric shock may occur

- (2) Check for short circuits between terminals and exposed live parts and ground faults.
- (3) Check for loose terminals, connectors and screws.
- (4) Check if the motor is separated from mechanical equipment.
- (5) Turn the switches off so that the inverter does not start or operate erroneously at power-on.
- (6) Check if safety measures are taken against runaway of the system, e.g., a defense to protect people from unexpectedly approaching your power system.





#### 5.2 Setting the function codes

Set next function codes data according to motor ratings and application values. For the motor, check the rated values printed on the nameplate of the motor.

Code	Name	Description
F 03	Maximum frequency	
F 04	Base frequency	Motor characteristics
F 05	Rated voltage	
F 07	Acceleration time 1	Application values
F 08	Deceleration time 1	Application values
P 02	Motor rated capacity	Motor characteristics
P 03	Motor rated current	







## 5.3 Quick start commissioning (auto tuning)

Even if it is not extremely necessary, the auto tuning procedure should be performed before running the motor for the first time. There are two auto tuning modes: auto tuning mode 1 (static) and auto tuning mode 2 (dynamic).

Auto tuning mode 1 (P04 = 1): P07 and P08 function code values are measured.

Auto tuning mode 2 (P04 = 2): The no load current (P06 function code) is measured as well as P07 and P08. When choosing this option, please remove the mechanical load from the motor.

# **WARNING**

The motor will start moving if Auto tuning mode 2 is chosen

#### Auto tuning procedure

- 1. Power on the inverter.
- 2. Switch the operation mode from remote to local (by means of F02 = 2 or 3).

3. If there are any kind of contactors between the motor and the inverter, please close them manually.

4. Set P04 to 1 (Auto tuning mode 1) or P04 to 2 (auto tuning mode 2), press FUNC/DATA and press RUN (the current flow going through the motor winding will generate a sound). The auto tuning takes a few seconds until is finished itself. P06 will be measured as well as P07 and P08 if auto tuning mode 2 has been selected.

The auto tuning procedure has been finished.

## LOCAL MODE TEST

- (1) Set F02 = 2 or F02 = 3 to select the local mode (RUN command given by the keypad).
- (2) Switch the inverter on and check the LED keypad is displaying and blinking 0.00 Hz.
- (3) Set a low frequency using the arrow keys  $\bigcirc$  /  $\bigcirc$  (check if the new frequency is already blinking in the LED keypad). Press PRG/RESET during one second to move the cursor across the LED keypad.
- (4) Press FUNC/DATA to store the new selected frequency.
- (5) Press RUN key to start driving the motor.
- (6) Press STOP key to stop the motor.

#### 5.4 Operation

After confirming the inverter can drive the motor, connect the motor to the machine and adjust the necessary function codes. Depending on the application conditions, further adjustments may be required: such as adjustments of torque boost (F09), acceleration time (F07), and deceleration time (F08). Make sure to set relevant function codes properly.





# 6. FUNCTION CODES AND APPLICATION EXAMPLES

#### 6.1 Function codes tables and basic description

Function codes enable the FRENIC-Eco series of inverters to be set up to match your system requirements. The function codes are classified into eight groups: <u>Fundamental Functions (F codes)</u>, <u>Extension Terminal Functions (E codes)</u>, <u>Control Functions of Frequency (C codes)</u>, <u>Motor Parameters (P codes)</u>, <u>High Performance Functions (H codes)</u>, <u>Application Functions (J codes)</u>, <u>Link Function (y codes)</u> and <u>Option Functions (o codes)</u>. For Option function (o codes), refer to the instruction manual for the option.

For further information about the FRENIC-Eco function codes please refer to FRENIC-Eco user's manual. For further information about pump control please refer to the pump control instruction manual.

#### F codes: Fundamental functions

Code	Name		Setting range	Default setting	Actual setting
F00	Data protection		0: Disable data protection (function code can be edited)	0	
F01	Frequency command 1		1: Enable arrow keys on the keypad 1: Enable voltage input to terminal [12] (0 to 10V DC) 2: Enable current input to terminal [C1] (4 to 20 mA) 3: Enable sum of voltage and current inputs terminals [12] and [C1] 5: Enable voltage input to terminal [V2] (0 to 10V DC) 7: Enable terminal command (UP) / (DOWN) control	0	
F02	RUN command		0: Enable RUN / STOP keys on the keypad (Motor rotational direction from digital input signals FWD/REV) 1: Enable terminal command FWD or REV 2: Enable RUN / STOP keys on keypad (forward) 3: Enable RUN / STOP keys on keypad (reverse)	2	
F03	Maximum frequency		25.0 to 120.0 Hz	50.0 Hz	
F04	Base frequency		25.0 to 120.0 Hz	50.0 Hz	
F05	Rated voltage at base frequency		0: Output a voltage in proportion to input voltage 80 to 240V: Output a voltage AVR-controlled (200V AC series) 160 to 500V: Output a voltage AVR-controlled (400V AC series)	400 V	
F07	Acceleration time 1		0.00 to 3600 s (Entering 0.00 cancels the acceleration time, requiring external soft-start)	20.0 s	
F08	Deceleration time 1		0.00 to 3600 s (Entering 0.00 cancels the deceleration time, requiring external soft-start)	20.0 s	
F09	Torque boost		0.0 to 20.0 % (percentage of the rated voltage at base frequency (F05)). This setting is effective when F37 = 0,1,3 or 4	Depend on the inverter power capacity	
F10	Electronic thermal overload protection for motor	Selection motor charact.	1: For general-purpose motors with built-in-self-cooling fan 2: For separately excited motor fan	1	
F11		Overload detection level	0.0: Disable 1 to 135% of the rated current (allowable continuous drive current) of the motor	100 % of the motor rated current	
F12		Thermal time constant	0.5 to 75.0 min	5.0 min (22kW or below) 10.0 min (30kW or above)	
F14	Restart mode after momentary power failure (Mode selection)	1	<ul> <li>0: Disable restart (trip immediately)</li> <li>1: Disable restart (trip after a recovery from power failure)</li> <li>3: Enable restart (continue to run, for heavy inertia or general loads)</li> <li>4: Enable restart (restart at the frequency at which the power failure occurred, for general loads)</li> <li>5: Enable restart (restart at the starting frequency, for low-inertia load)</li> </ul>	0	
F15	Frequency limiter	High	0 to 120.0 Hz	70.0 Hz	
F16		Low	0 to 120.0 Hz	0.0 Hz	
F18	Bias (frequency command 1)		-100.00 to 100.00 %	0.00 %	
F20	DC braking	Start freq.	0.0 to 60.0 Hz	0.0 Hz	
F21		Braking level	0 to 60 % (100% is interpreted as rated output current of the inverter)	0 %	
F22		Braking time	0.00: Disable 0.01 to 30.00 s	0.00 s	
F23	Starting frequency		0.1 to 60.0 Hz	0.5 Hz	
F25	Stop frequency		0.1 to 60.0 Hz	0.2 Hz	









Code	Name		Setting range	Default setting	Actual setting
F26	Motor sound	Carrier frequency	0.75 to 15 kHz (22kW or below) 0.75 to 10 kHz (30kW to 75kW) 0.75 to 6 kHz (90kW or above)	15/10/6 kHz	
F27		Sound tone	0: Level 0 (Inactive) 1: Level 1 2: Level 2 3: Level 3	0	
F29	Analog ouptut (FMA)	Mode selection	0: Output in voltage (0 to 10V DC) 1: Output in current (4 to 20mA DC)	0	
F30		Output adjust.	0 to 200 %	100 %	
F31		Function	Select a function to be monitored from the following 0: Output frequency 2: Output current 3: Output voltage 4: Output torque 5: Load factor 6: Input power 7: PID feedback value (PV) 9: DC link bus voltage 10: Universal AO 13: Motor output 14: Calibration analog output (+10V DC / 20 mA DC) 15: PID process command (SV) 16: PID process output (MV)	0	
F34	Analog output (FMI)	Duty	0 to 200 %: Voltage output adjustment	100 %	
F35		Function	Select a function to be monitored from the following: 0: Output frequency 2: Output current 3: Output voltage 4: Output torque 5: Load factor 6: Input power 7: PID feedback value (PV) 9: DC link bus voltage 10: Universal AO 13: Motor output 14: Calibration analog output (20 mA DC) 15: PID process command (SV) 16: PID process output (MV)	0	
F37	Load selection/ Auto torque boost/ Auto energy saving operation		0: Variable torque load increasing in proportion to square of speed 1: Variable torque load increasing in proportion to square of speed (Higher startup torque required) 2: Auto-torque boost 3: Auto-energy saving operation (Variable torque load increasing in proportion to square of speed) 4: Auto-energy saving operation (Variable torque load increasing in proportion to square of speed; higher startup torque required) Note: Apply this setting to a load with short acceleration time. 5: Auto-energy saving operation (Auto-torque boost) Note: Apply this setting to a load with long acceleration time.	1	
F43	Current limiter	Mode selection	0: Disable (No current limiter works) 1: Enable at constant speed (Disabled during acceleration and deceleration) 2: Enable during acceleration and at constant speed	0	
F44		Level	20 to 120 % (100% is interpreted as rated output current of the inverter)	110 %	

The shaded function codes are applicable to the quick setup menu





# E codes: Extension terminal functions

Code	Name	Data setting range	Default setting	Actual setting
E01	Command assignment to: [X1]	Selecting function code data assigns the corresponding function to terminals [X1] to [X5] as listed below. Setting the value of 1000s in parentheses () shown below	6	
E02	[X2] [X3]	assigns a negative logic input to a terminal.	7	
E03	[X4] [X5]	and 30 are for negative logic, respectively.	8	
E04		0 (4000), 0 - 1 - + (5 - +	11	
E05		1 (1001): Select multistep frequency (SS1) 2 (2001): Select multistep frequency (SS2)	35	
		3 (1002): Select multistep frequency (SS4) 3 (1003): Select multistep frequency (SS8)		
		6 (1006): Enable 3-wire operation (HLD)		
		7 (1007): Coast to stop (BX)		
		8 (1008): Reset alarm (RST)		
		9 (1009): Enable external alarm trip (THR)		
		11 (1011): Switch frequency command 2/1 (Hz2/Hz1)		
		13: Enable DC brake (DCBRK)		
		15: Switch to commercial power (50 Hz) (SW50)		
		16: Switch to commercial power (60 Hz) (SW60)		
		17 (1017): UP (Increase output frequency) (UP)		
		10 (1010): DOWN (Decrease output frequency) (DOWN) 10 (1010): Enchla write from kovnod (Data changeable) (WE KD)		
		20 (1020): Cancel RID control (Hz/RID)		
		21 (1020): Calicel FID collutor 21 (1021): Switch normal/inverse operation (IVS)		
		22 (1022): Interlock (II)		
		24 (1024): Enable communications link via RS485 or field bus (LE)		
		(0ption) 25 (1025): Universal DI		
		26 (1026): Select starting characteristics (STM)		
		30 (1030): Force to stop (STOP)		
		33 (1033): Reset PID integral and differential components (PID-RST)		
		34 (1034): Hold PID integral component (PID-HI D)		
		35 (1035): Select local (keypad) operation (LOC)		
		38 (1038): Enable to run (RE)		
		39: Protect motor from dew condensation (DWP)		
		40: Enable integrated sequence to switch to commercial power (ISW50) (50 Hz)		
		41: Enable integrated sequence to switch to commercial power (ISW60) (60 Hz)		
		50 (1050): Clear periodic switching time (MCLR)		
		51 (1051): Enable pump drive (motor 1) (MEN1)		
		52 (1052): Enable pump drive (motor 2) (MEN2)		
		53 (1053): Enable pump drive (motor 3) (MEN3)		
		54 (1054): Enable pump drive (motor 4) (MEN4)		
		87 (1087): Switch RUN command 2/1 (FR2/FR1)		
		88: RUN forward 2 (FWD2)		
		89: RUN reverse 2 (REV2)		
E14	Acceleration Time (Multistep Frequency + UP/DOWN)			
E15	Deceleration Time (Multistep Frequency +	0.00 to 3600 s	20.00	
	UF/DOWN)			

FRENIC-ECO





Code	Name		Data setting range		Default setting	Actual setting
E20	Command assignment to: [Y1]		Selecting function code data assigns the corresponding function to ter to [Y3], [Y5A/C], and [30A/B/C] as listed below. Setting the value of 10	minals [Y1] 00s in	0	
E21	[Y2]		parentheses () shown below assigns a negative logic input to a termin	al.	1	
E22	[Y5A/C] [30A/B/C]				2	
E24			0 (1000): Inverter running	(RUN)	10	
E27	-		2 (1002): Frequency arrival signal	(FAR) (FDT)	99	
	-		3 (1003): Undervoltage detected (inverter stopped) 5 (1005): Inverter output limiting	(LU) (IOL)		
			6 (1006): Auto-restarting after momentary power failure	(IPF)		
			10 (1007): Motor overload early warning 10 (1010): Inverter ready to run	(OL) (RDY)		
			11: Switch motor drive source between commercial power and	(SW88)		
			inverter output (For MC on commercial line) 12: Switch motor drive source between commercial power and	(SW52-2)		
			inverter output (For primary side)	(\$\\\\\52.1)		
			inverter output (For secondary side)	(30032-1)		
			15 (1015): Select AX terminal function (For MC on primary side)	(AX)		
			25 (1025): Cooling fan in operation 26 (1026): Auto-resetting	(FAN) (TRY)		
			27 (1027): Universal DO	(U-DO)		
			28 (1028): Heat sink overheat early warning 30 (1030): Service life alarm	(OH)		
			33 (1033): Command loss detected	(REF OFF)		
			35 (1035): Inverter output on	(RUN2)		
			37 (1036): Overload prevention control 37 (1037): Current detected	(OLP) (ID)		
			42 (1042): PID alarm	(PID-ALM)		
			43 (1043): Under PID control 44 (1044): Motor stopping due to slow flowrate under PID control	(PID-CTL) (PID-STP)		
			45 (1045): Low output torque detected	(U-TL)		
			54 (1054): Inverter in remote operation	(RMT)		
			56 (1056): Motor overheat detected (PTC)	(THM)		
			59 (1059): C1 disconnection detected	(CIOFF)		
			61 (1060): Sequenced start motor 1, inverter-driven 61 (1061): Sequenced start motor 1, commercial-power driven	(M1_I) (M1_L)		
			62 (1062): Sequenced start motor 2, inverter-driven	(M2_I)		
			63 (1063): Sequenced start motor 2, commercial-power driven	(M2_L) (M3_I)		
			65 (1065): Sequenced start motor 3, commercial-power driven	(M3_L)		
			67 (1067): Sequenced start motor 4, commercial-power driven	(M4_L)		
			69 (1069): Pump control limit signal	(MLIM)		
			87 (1087): (FAR AND FDT) signal	(FARFDT)		
E31	Frequency detection	Detection level	99 (1099): Alarm output (for any alarm) 0.0 to 120.0 Hz	(ALM)	50 0 Hz	
E32	(FDT)	Hysteresis	0.0 to 120.0 Hz		10 Hz	
E34	Overload early warning/	Level	0: Disable		100% of the motor	
E35	Current detection	Timer	Current value of 1% to 150% of the inverter rated current		rated current	
E00		TITIO			10.00 s	
E40	PID display coefficient A		-333 (0 0.00 (0 333		100	
E41	PID display coefficient B		- 393 to 0.00 to 999		0.00	
E43	LED monitor	Item selection	0: Speed monitor (Select by E48) 3: Output current			
			4: Output voltage			
			8: Calculated torque			
			10: PID process command (Final)		0	
			12: PID feedback value			
			14: PID Output 15: Load factor			
			16: Motor output			
F45	LCD monitor	Item selection	17: Analog input 0: Running status, rotational direction and operation guide			
E40	(only with multi-functional keypad TP-G1)	Nem Selection	1: Bar charts for output frequency, current and calculated torque		0	
E46	Keypad TP-G1) Lan	guage selection	0: Japanese 1: English			
			2: German		1	
			3: French 4: Spanish			
			5: Italian			
E47	Contrast control 0 (L	ow) to 10 (High)	5			





# FRENIC-ECO

Name		Setting range	Default setting	Actual setting
D monitor	Speed item	0: Output frequency 3: Motor speed in r/min 4: Load shaft in r/min 7: Display speed in %	0	
Coefficient for speed indication		0.01 to 200.00	30.00	
splay coefficient for input		0.000: (Cancel / reset) 0.001 to 9999	0.010	
watt-hour data Keypad (menu display mode)		0: Function code data editing mode (Menus #0, #1 and #7) 1: Function code data check mode (Menus #2 and #7) 2: Full-menu mode (Menus #0 through #7)	0	
Analog input for [12] (Extension function selection) [C1]		Selecting function code data assigns the corresponding function to terminals [12], [C1] and [V2] as listed below	0	
		0: None	0	
-	[V2]	1: Auxiliary frequency command 1 2: Auxiliary frequency command 2 3: PID process command 1 5: PID feedback value 20: Analog input monitor	0	
aving digital reference free	quency	0: Auto saving (at the time of main power turned off) 1: Saving by pressing FUNC/DATA key	0	
ommand loss detection	Level	0: Decelerate to stop 20 to 120 % 999: Disable	999	
etect low torque	Detection level	0 to 150 %	20 %	
-	Timer	0.01 to 600.00 s	20.00 s	
ommand assignment to: WD]		Selecting function code data assigns the corresponding function to terminals [FWD] and [REV] as listed below. Setting the value of 1000s in parentheses ()	98	
EV]		shown below assigns a negative logic input to a terminal. In the case of (THR) and (STOP), data 1009 and 1030 are for normal logic and 9 and 30 are for negative logic, respectively. (1000): Select multistep frequency (SS1) (1001): Select multistep frequency (SS2) (1002): Select multistep frequency (SS3) 6 (1006): Enable 3-wire operation (HLD) 7 (1007): Coast to stop (BX) 8 (1008): Reset alarm (RST) 9 (1009): Enable external alarm trip (THR) 11 (1011): Switch frequency command 2/1 (Hz2/Hz1) 13: Enable DC brake (DCBRK) 15: Switch to commercial power (50 Hz) (SW50) 16: Switch to commercial power (50 Hz) (SW50) 17 (1017): UP (Increase output frequency) (UP) 18 (1018): DCWN (Decrease output frequency) (UP) 18 (1018): DCWN (Decrease output frequency) (UP) 19 (1019): Enable write from keypad (Data changeable) (WE-KP) 20 (1020): Cancel PID control 12 (1022): Interlock (LL) 24 (1024): Enable communications link via RS485 or field bus (LE) 26 (1025): Universal DI (U-DI) 26 (1025): Universal DI 26 (1026): Select starting characteristics 31 (1033): Reset PID integral and differential components 41 (1034): Hold PID integral component 41 (1034): Hold PID integral component 41 (1034): Hold PID integral component 41 (1035): Select tocal (keypad) operation (LOC) 38 (1038): Enable to run 39. Protect motor from dew condensation (DWP) 40: Enable integrated sequence to switch to commercial power (ISW50) (50 Hz) 41: Enable integrated sequence to switch to commercial power (ISW50) (50 Hz) 50 (1050): Clear periodic switching time (MCLR) 51 (1051): Enable pump drive (motor 1) (MEN3) 54 (1054): Enable pump drive (motor 2) (MEN3) 54 (1054): Enable pump drive (motor 3) 44 (1054): Enable pump drive (motor 3) 44 (1054): Enable pump drive (motor 3) 44 (1054): Enable pump drive (motor 4) (MEN4) 57 (1057): Switch run command 2/1 (FR2/FR1) 58 (RVD reverse 2 (REV2)	99	
	Name         D monitor         efficient for speed indical         play coefficient for input         thour data         ypad (menu display mod         alog input for         tension function         ection)         ving digital reference free         mmand loss detection         tect low torque         mmand assignment to:         VD]         EV]	Name         D monitor       Speed item         efficient for speed indication	Name         Setting range           D monitor         Speed item         0. Output drop speed in frain 7. Disglay speed in frain 7. Disglay speed in %           efficient for speed indication         0.01 to 200.00           page coefficient for input throur data         0.000: (Cancel / reset)           0.001 (cancel / reset)         0.001 to 200.00           page (menu display mode)         0. Function code data deding mode (Menus #0, #1 and #7)           1: Function code data deding mode (Menus #0, #1 and #7)         1: Function code data settings the corresponding function to terminals [12].           forming function code data settings the corresponding function to terminals in 12].         1: Audian frequency command 1           is running function code data settings the corresponding function to terminals [12].         1: Audian frequency command 1           is ND process command 1         2: Audiany frequency command 1           2: Audiany frequency command 1         3: PID process command 1           3: PID process command 1         5: PID process command 1           3: PID process command 1         5: PID process command 1           3: PID process command 1         5: PID process command 1           4: Dow lange transport provide the terminals         1: Dow lange transport provide the terminals           intra terminal coss detection         1: Dow lange transport provide the terminals           1: Dow lange transport	Name         Setting range         Default enting           D monitor         Speed item         C. Output fingurery         0           efficient for speed indication         0.010 (Cancel / reset)         0.010           play coefficient for input         0.000 (Cancel / reset)         0.010           play coefficient for input         0.000 (Cancel / reset)         0.010           play coefficient for input         0.000 (Cancel / reset)         0.010           play coefficient for input         0.010 (Cancel / reset)         0.010           play coefficient for input         0.010 (Cancel / reset)         0.010           play coefficient for input         0.010 (Cancel / reset)         0.010           play for them digital product input mode (Manus #D input pot play fir)         0         0           play for the digital product input pot pot product input pot pot product input pot pot product input pot pot pot product input pot pot pot pot pot pot pot pot pot po

The shaded function codes are applicable to the quick setup menu







# C codes: Control functions of frequency

Code	!	Name	Data setting range	Default setting	Actual setting
C01	Jump frequency	1	0.0 to 120.0 Hz	0.0 Hz	
C02		2		0.0 Hz	
C03		3		0.0 Hz	
C04		Band	0.0 to 30.0 Hz	3.0 Hz	
C05	Multistep frequency	1	0.00 to 120.00 Hz	0.00 Hz	
C06		2		0.00 Hz	
C07		3		0.00 Hz	
C08		4	_	0.00 Hz	
C09		5	_	0.00 Hz	
C10		6	_	0.00 Hz	
011				0.00 Hz	
012		0	-	0.00 HZ	
C13			-	0.00 HZ	
C14		11	-	0.00 Hz	
C16		12	-	0.00 Hz	
C17		13	-	0.00 Hz	
C18		14	-	0.00 Hz	
C19		15		0.00 Hz	
			Enable voltage input to terminal [12] (0 to 10V DC)     Enable current input to terminal [C1] (4 to 20 mA)     S: Enable sum of voltage and current inputs to terminals [12]     and [C1]     S: Enable voltage input to terminal [V2] (0 to 10V DC)     7: Enable terminal command (UP) / (DOWN) control	2	
Code	1	Name	Data setting range	Default setting	Actual setting
C32	Analog input adjustment for [12]	Gain for terminal input [12]	0.00 to 200.00 %	100.0 %	
C33		Filter time constant	0.00 to 5.00 s	0.05 s	
C34		Gain reference point	0.00 to 100.00 %	100.0 %	
C37	Analog input adjustment for [C1]	Gain for terminal input [C1]	0.00 to 200.00 %	100.0 %	
C38		Filter time constant	0.00 to 5.00 s	0.05 s	
C39		Gain reference point	0.00 to 100.00 %	100.0 %	
C42	Analog input adjustment for [V2]	Gain for terminal input [V2]	0.00 to 200.00 %	100.0 %	
C43		Filter time constant	0.00 to 5.00 s	0.05 s	
C44		Gain reference point	0.00 to 100.00 %	100.0 %	
C50	Bias reference point (Frequer	ncy command 1)	0.00 to 100.0 %	0.00 %	
C51	Bias for PID command 1	Bias value	-100.0 to 100.00 %	0.00 %	
C52		Bias reference point	0.00 to 100.00 %	0.00 %	
C53	Selection of normal/inverse o (Frequency command 1)	peration	0: Normal operation 1: Inverse operation	0	







# P codes: Motor parameters

Code		Name	Data setting range	Default setting	Actual setting
P01	Motor	No. of poles	2 to 22	4	
P02		Rated capacity	0.01 to 1000 kW (If P99 is 0, 3 or 4) 0.01 to 1000 HP (If P99 is 1)	Rated capacity of the motor	
P03		Rated current	0.00 to 2000 A	Rated current of Fuji standard motor	
P04		Autotuning	0: Disable 1: Enable (Tune %R1 and %X while the motor is stopped) 2: Enable (Tune %R1 and %X while the motor is stopped and no-load current while running)	0	
P06		No-load current	0.00 to 2000 A	Rated value of Fuji standard motor	
P07		%R1	0.00 to 50.00 %	Rated value of Fuji standard motor	
P08		%X	0.00 to 50.00 %	Rated value of Fuji standard motor	
P99		Motor selection	0: Characteristics of motor 0 (Fuji standard motors, 8-series) 1: Characteristics of motor 1 (HP-rated motors) 3: Characteristics of motor 3 (Fuji standard motors, 6-series) 4: Other motors	0	

The shaded function codes are applicable to the quick setup menu





# FRENIC-ECO

# H codes: High performance functions

·					T	
Code	Na	ame	Data setti	ng range	Default setting	Actual setting
H03	Data initialization		0: Disable initialization 1: Initialize all function code data 2: Initialize motor parameters	to the factory defaults	0	
H04	Auto-resetting	Times	0: Disable 1 to 10 times		0 times	
H05		Reset interval	0.5 to 20.0 s		5.0 s	
H06	Cooling fan ON/OFF control		0: Disable (Always in operation)		0	
H07	Acceleration/Deceleration pat	ttern	0: Linear 1: S-curve (Weak) 2: S-curve (Strong)		0	
H09	Select starting characteristics (Auto search for idling motor's speed)		0: Disable 3: Enable (Follow RUN command 4: Enable (Follow RUN command 5: Enable (Follow RUN command reverse)	Curvilinear     O: Disable     S: Enable (Follow RUN command, either forward or reverse)     4: Enable (Follow RUN command, both forward and reverse)     5: Enable (Follow RUN command, inversely both forward and		
H11	Deceleration mode		0: Normal deceleration 1: Coast-to-stop		0	
H12	Instantaneous overcurrent limiting		0: Disable 1: Enable		1	
H13	Restart mode after	Restart time	0.1 to 10.0 s		Depending on the	
H14		Frequency fall rate	0.00: Set deceleration time 0.01 to 100.0 Hz/s	mand	999	
H15	-	Continuous running level	200V series: 200 to 300VDC	nanu	235 V DC	
H16	-	Allowable momentary power	0.0 to 30.0 s	lly datermined by the invertor	999	
H17	Select starting characteristics	Frequency for idling motor's	999: The longest time automatically determined by the inverter		999	
H26	PTC thermistor input	Mode selection	0: Disable 1: Enable (Upon detection of PTC and stops with OH4 displayed) 2: Enable (Upon detection of PTC	2, the inverter immediately trips 2, the inverter continues	0	
H27	-	Level	running while outputting alarm sig 0.00 to 5.00 V DC	gnal (THM))	1.60 V DC	
H30	Communication link function	(Mode selection)	Frequency command	RUN command	1.00 ¥ DO	
			0: F01/C30 1: RS485 link 2: F01/C30 3: RS485 link (option) 5: RS485 link (option) 6: F01/C30 7: RS485 link	F02 F02 RS485 link RS485 link F02 RS485 link (option) RS485 link (option)	Set at factory	0
H42	Capacitance of DC link bus c	apacitor	8: RS485 link (option) Indication for replacing DC link	bus capacitor (0000 to FFFF:		
H43	Cumulative run time of coolin	g fan	Indication of cumulative run time	of cooling fan for replacement	-	
H47	Initial capacitance of DC link	bus capacitor	Indication for replacing DC link	bus capacitor (0000 to FFFF:	-	
H48	Cumulative run time of capac	itors on the printed circuit	Indication for replacing capacito (0000 to EEEE: Hexadecimal) Re	rs on the printed circuit board	-	
H49	Select starting	0.0 to 10.0 s	0.0 s		1	1
H50	characteristics (Auto search time for idling motor's speed) Non-linear V/f pattern	Frequency	0.0: Cancel 0.1 to 120.0 Hz		0.0 Hz (22kW or below)	5.0 Hz (30kW or above)
H51 H56	Deceleration time for forced s	stop	Voltage 0.00 to 3600 s		0 to 240V: Output a voltage AVR- controlled (for 200V AC series) 0 to 500V: Output a voltage AVR- controlled (for 400V AC series)	0 (22kW or below) 20 (30kW or above, 200V ser.) 40 (30kW or above, 400V ser.)
H61	LIP/DOWN Control		1 or 3. Display data on the keypa	d´s LED monitor in decimal	20.0 s	
			format (in each bit, "0" for disable Bit 0: Last UP/DOWN command v command (Prefixed to "1") Bit 1: Multistep Frequency + UP/I	d, "1" for enabled) value on releasing run	1 (Bit 0 = 1)	





Code	Name	Data setting range	Default setting	Actual setting
H63	Low limiter Mode selection	0: Limit by F16 (Frequency Limiter: Low) and continue to run 1: If the output frequency lowers less than the one limited by F16 (Frequency limiter: Low), decelerates to stop the motor	0	
H64	Lower limiting frequency	0.0: Depends on F16 (Frequency limiter: Low) 0.1 to 60.0 Hz	2.0 Hz	
H69	Automatic deceleration	0: Disable 3: Enable (Control DC link bus voltage at a constant)	0	
H70	Overload prevention control	0.00: Follow deceleration time specified by F08 0.01 to 100.00 Hz/s 999: Disable	999	
H71	Deceleration characteristics	0: Disable 1: Enable	0	
H80	Gain for suppression of output current fluctuation for motor	0.00 to 0.40	0.10 for 45 kW or above (200V series) and for 55 kW or above (400V series) 0.20 for 37 kW or below (200V series) and for 45 kW or below (400V series)	
H86	Reserved *1	0 to 2	2 for 45 kW or above (200V series) and for 55 kW or above (400V series) 0 for 37 kW or below (200V series) and for 45 kW or below (400V series)	
H87	Reserved *1	25.0 to 120.0 Hz	25.0 Hz	
H88	Reserved *1	0 to 3 999	0	
H89	Reserved *1	0, 1	0	
H90	Reserved *1	0, 1	0	
H91	C1 signal disconnection detection	0.0 s: Wire disconnection protection disabled 0.1-60.0 s: Wire disconnection detection time	0.0 s	
H92	Continue to run P component: gain	0.000 to 10.000 times 999	999	
H93	I component: time	0.010 to 10.000 s999	999	
H94	Cumulative run time of motor	Change or reset the cumulative data	-	
H95	DC braking (braking response mode)	0: Slow 1: Quick	1	
H96	STOP key priority/start check function	STOP key priority     Start check function       0: Disable     Disable       1: Enable     Disable       2: Disable     Enable       3: Enable     Enable	0	
H97	Clear alarm data	Setting H97 data to "1" clears alarm data and then returns to zero	0	
H98	Protection/maintenance function	0 to 63: Display data on the keypad's LED monitor in decimal format (In each bit, "0" for disabled, "1" for enabled)Bit 0: Lower the carrier frequency automatically Bit 1: Detect input phase loss Bit 2: Detect output phase loss Bit 3: Select life judgement criteria of DC link bus capacitor Bit 4: Judge the life of DC link bus capacitor Bit 5: Detect DC fan lock	19 (decimal) (Bits 4,1,0 = 1 bits 5,3,2, = 0)	

\*1 The H86 through H90 are displayed, but they are reserved for particular manufacturers. Unless otherwise specified, do not access these function codes.







# J codes: Application functions

Code		Name	Data setting range	Default setting	Actual setting
J01	PID control Mode se	election	0: Disable 1: Enable (normal operation) 2: Enable (inverse operation)	0	
J02	Remote	process command	0: Enable arrow keys on keypad 1: PID process command 1 3: Enable terminal command UP/DOWN control 4: Command via communications link	0	
J03	P (gain)		0.000 to 30.000	0.100 times	
J04	l (integra	al time)	0.0 to 3600.0 s	0.0 s	
J05	D (differe	ential time)	0.00 to 600.00 s	0.00 s	
J06	Feedbac	ck filter	0.0 to 900.0 s	0.5 s	
J10	Anti rese	et windup	0 to 200 %	200 %	
J11	Select al	larm output	(Refer to FRENIC-Eco user's manual)	0	
J12	Upper lir	mit alarm (AH)	0 to 100 %	100 %	
J13	Lower lir	mit alarm (AL)	0 to 100 %	0 %	
J15	Stop free	quency for slow flowrate	0: Disable 1 to 120 Hz	0	
J16	Slow flow	wrate level stop latency	1 to 60 s	30 s	
J17	Starting	frequency	0: Disable 1 to 120 Hz	0	
J18	Upper lir	mit of PID process output	1 to 120 Hz 900: Depends on setting of E15	999	
J19	Lower lir	mit of PID process output	1 to 120 Hz	999	
J21	Dew condensation prevent	ion (Duty)	1 to 50 %	1 %	
J22	Commercial power switchin	ng sequence	0: Keep inverter operation (Stop due to alarm)	0	
J23	Starting from the Slow Flow	vrate Stop	0 to 100 %	0 %	
J24	Starting from the Slow Flow	vrate Stop	0 to 60 s	0	
J25	Pump control	Mode selection	0: Disable 1: Enable (Fixed inverter-driven motor) 2: Enable (Floating inverter-driven motor)	0	
J26	Motor 1 mode		0: Disable (Always OFF) 1: Enable	0	
J27	Motor 2 mode		2: Force to run by commercial power	0	
J28	Motor 3 mode		-	0	
J29	Motor 4 mode		-	0	
J30	Motor switching order		0: Fixed 1: Automatically (Constant run time)	0	
J31	Motor stop mode		0: Stop all motors (inverter-driven and commercial power-driven) 1: Stop inverter-driven motor only (excl. alarm state) 2: Stop inverter-driven motor only (incl. alarm state)	0	
J32	Periodic switching time for	motor drive	0.0: Disable switching 0.1 to 720.0 h: Switching time range 999: Fix to 3 min	0.0 h	
J33	Periodic switching signaling	g period	0.00 to 600.00 s	0.10 s	
J34	Sequenced start of comme driven motor	rcial power- Frequency	0 to 120 Hz 999: Depends on setting of J18 (This code is used to judge whether or not to start a commercial power-driven motor by checking the output frequency of the inverter-driven motor)	999	
J35	]	Duration	0.00 to 3600 s	0.00 s	
J36	Sequenced stop of comme driven motor	rcial power- Frequency	0 to 120 Hz 999: Depends on setting of J19 (This code is used to judge whether or not to stop a commercial power-driven motor by checking the output frequency of the inverter-driven motor)	999	
J37		Duration	0.00 to 3600 s	0.00 s	
J38	Contactor delay time		0.01 to 2.00 s	0.10 s	
J39	Switching time for motor se time)	equenced start (Deceleration	0.00: Depends on the setting of F08 0.01 to 3600 s	0.00 s	
<b>F</b> <del>O</del> e	-Front runners	<u>Charles</u> Cr			22





Code	Name		Data setting range		Default setting	Actual setting
J40	Switching time for motor sequenced sto	p (Acceleration time)	0.00: Depends on the setting of F07 0.01 to 3600 s		0.00 s	
J41	Motor Unmount Switching Level		0 to 100 %		0 %	
J42	Switching motor sequenced start/seque band)	nced stop (Dead	0.0: Disable 0.1 to 50.0 %		0.0 %	
J43	PID control startup frequency		0: Disable 1 to 120Hz 999: Depends on the setting of J36		999	
J44	Motor Mount Switching Level		0: Depends on the setting of J41 1 to 100 %		0 %	
J45	Signal assignment to: (for relay output card)	[Y1 A/B/C]	Selecting function code data assigns the corresponding to terminals [Y1A/B/C]. [Y2A/B/C] and [Y3A/B/C]	function	100	
J46		[Y2 A/B/C]			100	
J47		[Y3 A/B/C]			100	
			100: Depends on the setting of E20 to E22 60 (1060): Sequenced start motor 1, inverter- driven 61 (1061): Sequenced start motor 1, commercial power-driven 62 (1062): Sequenced start motor 2, inverter- driven 63 (1063): Sequenced start motor 3, inverter- driven 64 (1064): Sequenced start motor 3, inverter- driven 65 (1065): Sequenced start motor 3, commercial power-driven 67 (1067): Sequenced start motor 4, commercial power-driven 68 (1068): Periodic switching early warning 69 (1069): Pump control limit signal	(M1_l) (M1_L) (M2_l) (M2_L) (M3_l) (M3_L) (M4_L) (MCHG) (MLIM)		
J48	Cumulative run time of motor	Motor 0	Indication of cumulative run time of motor for replacement	ent		
J49	7	Motor 1				
J50		Motor 2				
J51		Motor 3				
J52	1	Motor 4				
J53	Maximum cumulative number of relay ON times	Y1 A/B/C to Y3 A/B/C	Indication of maximum number of ON times of relay cor the relay output card or those built in inverter.	ntacts on		
J54		[Y1], [Y2], [Y3]	Display of 1.000 means 1.000 times			
J55		[Y5A/C], [30A/B/C]	For relay output card For built-in mechanical contacts			
J93	PID Start Frequency (Mount)	•	0: Depends on the setting of J36 1 to 120 Hz		0 Hz	
J94	PID Start Frequency (Unmount)		0: Depends on the setting of J34 1 to 120 Hz		0 Hz	







# y codes: Link functions

Code	Ν	lame	Data setting range	Default setting	Actual setting
y01	RS485 communication (standard)	Station address	1 to 255	1	
y02		Communications error processing	0: Immediately trip with alarm Er8 1: Trip with alarm Er8 after running for the period specified by timer y03 2: Retry during the period specified by timer y03. If retry fails, trip and alarm Er8. If it succeeds, continue to run 3: Continue to run	0	
y03		Error processing timer	0.0 to 60.0 s	2.0 s	
y04	-	Transmission speed	0: 2400 bps 1: 4800 bps 2: 9600 bps 3: 19200 bps 4: 38400 bps	3	
y05		Data length	0: 8 bits 1: 7 bits	0	
y06		Parity check	0: None 1: Even parity 2: Odd parity	0	
y07		Stop bits	0: 2 bits 1: 1 bit	0	
y08		No-response error detection time	0 (No detection) 1 to 60 s	0	
y09	-	Response latency time	0.00 to 1.00 s	0.01 s	
y10		Protocol selection	0: Modbus RTU protocol 1: FRENIC Loader protocol (SX protocol) 2: Fuji general-purpose inverter protocol 3: Metasys-N2	1	
y11	RS485 communication (option)	Station address	1 to 255	1	
y12		Communications error processing	<ol> <li>Immediately trip with alarm ErP</li> <li>Trip with alarm ErP after running for the period specified by timer y13</li> <li>Retry during the period specified by timer y13. If retry fails, trip and alarm ErP. If it succeeds, continue to run</li> <li>Continue to run</li> </ol>	0	
y13		Error processing timer	0.0 to 60.0 s	2.0 s	
y14		Transmission speed	0: 2400 bps 1: 4800 bps 2: 9600 bps 3: 19200 bps 4: 38400 bps	3	
y15		Data length	0: 8 bits 1: 7 bits	0	
y16		Parity check	0: None 1: Even parity 2: Odd parity	0	
y17		Stop bits	0: 2 bits 1: 1 bit	0	
y18		No-response error detection time	0 (No detection) 1 to 60 s	0	
y19		Response latency time	0.00 to 1.00 s	0.01 s	
y20		Protocol selection	0: Modbus RTU protocol 2: Fuji general-purpose inverter protocol 3: Metasys-N2	0	
y98	Bus link function (Mode selection)	Frequency command 0: Follow H30 data 1: Via field bus option 2: Follow H30 data 3: Via field bus option	RUN command Follow H30 data Follow H30 data Via field bus option Via field bus option	0	
y99	Loader link function (Mode selection)	Frequency command 0: Follow H30 and Y98 data 1: Via RS485 link (Loader) 2: Follow H30 and Y98 data 3: Via RS485 link (Loader)	RUN command Follow H30 and Y98 data Follow H30 and Y98 data Via RS485 link (Loader) Via RS485 link (Loader)	0	







### 6.2 Application examples

#### 6.2.1 Line-Inverter changeover

Following there is an example describing how to switch a motor from commercial-power operation to inverter-operation (and vice versa) using an internal automatic switch sequence called ISW50 function.

Components needed to develop this application:

- Motor (pump or fan motor)
- 3 relays (the relays will be connected to 3 contactors)
- 1 thermal relay (optional)
- FRENIC-Eco inverter (FRN-F1)

# 

When the primary contactor SW52-1 is opened the inverter will not be powered on. Therefore, and in order to keep the inverter control circuit alive, an auxiliary input voltage is needed from R0/T0 auxiliary input terminals.

Circuit diagram and configuration:



#### Configuration of control circuit:

To switch the motor from inverter operation to commercial-power operation or vice versa the inverter ISW50 function will be used.

#### 1. DIGITAL INPUTS (in this case FWD, X1 and are used)

- FWD: digital input set as FWD function (RUN command).
- X1: digital input set as mutistep frequency SS1 function (speed).
- X2: digital input set as ISW50 function (to switch the motor).





# 2. DIGITAL OUTPUTS (in this case Y1, Y2 and Y3 are used)

- Y1: digital output set as SW52-1 function (this digital output will be connected to relay 1. Relay 1 will open or close the primary contactor SW52-1).

- Y2: digital output set as SW52-2 function (this digital output will be connected to relay 2. Relay 2 will open or close the secondary contactor SW52-2).

- Y3: digital output set as SW88 function (this digital output will be connected to relay 3. Relay 3 will open or close the commercial power contactor SW88)



#### Switching sequence:

#### 1. INVERTER OPERATION -----> COMMERCIAL POWER OPERATION

If the digital input set as ISW50 function is changed from ON to OFF.....

(1) The inverter output is shut off immediately (IGBT off).

(2) The inverter primary contactor (SW52-1) and the inverter secondary contactor (SW52-2) are opened immediately.
(3) If the RUN command is kept during t1 time (H13 + 0.2 seconds), the commercial power contactor SW88 is closed and the motor is switched to commercial power operation.

#### 2. COMMERCIAL POWER OPERATION -----> INVERTER OPERATION

If the digital input set as ISW50 function is changed from OFF to ON.....

(1) The primary contactor SW52-1 is closed immediately giving voltage to the inverter (inverter is powered).

(2) The commercial power contactor SW88 is opened immediately (disconnecting the motor from the line).

(3) After t2 time (time required for the inverter main circuit to get ready + 0.2 s) the inverter secondary contactor SW52-2 is immediately closed.

(4) After t3 time (H13 + 0.2 s), the inverter starts driving and the motor is inverter controlled up to the desired frequency.







## Timing scheme:



#### The function codes which have been modified are:

Code	Data	Description
F02	1	RUN command using terminals (digital inputs)
F03	motor data	Maximum frequency
F04	motor data	Base frequency
F05	motor data	Rated voltage
F07	15 s (for instance)	Acceleration time
F08	15 s (for instance)	Deceleration time
E01	0	SS1 multistep frequency function assigned to X1 terminal (digital input)
E02	40	Switching sequence command ISW50 assigned to X2 terminal (digital input)
E20	12	SW52-1 function assigned to Y1 terminal (digital output)
E21	13	SW52-2 function assigned to Y2 terminal (digital output)
E22	11	SW88 function assigned to Y3 terminal (digital output)
E46	1	Language selection (English language selected)
C05	10 Hz (for instance)	If X1 terminal is ON, C05 speed will be selected
P01	motor data	Number of motor poles
P02	motor data	Motor capacity
P03	motor data	Motor rated current
P06	motor data	Motor no load current (for instance 50% of P03). If autotuning mode 2 is done, P06 is auto calculated.
H13	2 seconds	Restart time
	2 seconds	Restart ume







# 6.2.2 Select Multistep Frequencies (7 different set point frequencies)

To use Multistep Frequencies you have to program E01 to E05 to SS1 (0), SS2 (1) or SS4 (2) functions. Switching digital input signals (programmed to SS1, SS2 and SS4 functions) ON/OFF will switch the frequency command to those defined by function codes C05 through C11 (multistep frequencies). With this, the inverter may drive the motor at 8 different set point frequencies.

The table below lists the frequencies that can be obtained by the combination of switching (SS1), (SS2), and (SS4). In the "Selected frequency" column, "Other than multistep frequency" represents the set frequencies defined by frequency command 1 (F01), frequency command 2 (C30), or others.

(SS4)	(SS2)	(SS1)	Selected frequency
OFF	OFF	OFF	Other than multistep frequency
OFF	OFF	ON	C05 (multistep frequency 1)
OFF	ON	OFF	C06 (multistep frequency 2)
OFF	ON	ON	C07 (multistep frequency 3)
ON	OFF	OFF	C08 (multistep frequency 4)
ON	OFF	ON	C09 (multistep frequency 5)
ON	ON	OFF	C10 (multistep frequency 6)
ON	ON	ON	C11 (multistep frequency 7)

#### 6.2.3 PID Controller

In order to set up the PID controller the following parameters have to be set:

J01. PID control (mode select).

This function is used to setup the operation mode of the PID controller. The alternatives are:

- 0 PID inactive
- 1 PID active, forward operation
- 2 PID active, reverse operation



J02. Remote process command.

This parameter is used to set the source of the Set Value for the PID Controller.

- 0 Enable set by Keypad
- 1 PID process command 1
- 3 Enable terminal command (up)/(down) control
- 4 Command via communication link





When setting J02 to 1, you have to specify the source of this command. In order to do so you have to program one of the following functions to 3 (PID process command 1):

ENIC-EC

E61 to 3 when using terminal 12 (0 to 10V DC) E62 to 3 when using terminal C1 (4 to 20mA) E63 to 3 when using terminal V2 (0 to 10 V DC)

The second signal that we have to set is the source of the PID Feedback. This also will be done using the functions mentioned above, depending on the kind of feedback signal that the inverter receives from the sensor:

E61 to 5 when using terminal 12 (0 to 10V DC) E62 to 5 when using terminal C1 (4 to 20 mA) E63 to 5 when using terminal V2 (0 to 10V DC)

Note: if these functions are set up with the same data, the operation priority is given in the following order E61 > E62 > E63.

#### J03. PID control (P-gain).

This parameter is used to set the proportional (P) gain of the PID controller. This parameter has to be tuned on site; the value depends on the application.

#### J04. PID control (I-time).

This function is used to set the integral (I) time of the PID controller. This function has to be tuned on site; the value depends on the application.

#### J05. PID control (D-time).

This function is used to set the derivative (D) time of the PID controller.

This function has to be tuned on site; the value depends on the application.

J06. PID control (Feedback filter).

This function is used to set the time constant of the filter for PID control feedback signal, in seconds.

This function has to be tuned on site; the value depends on the application.

The following 3 functions are especially designed for pump applications.

These function codes specify the data for the slow flowrate stop in pump control, a feature that stops the inverter when there is no water consumption.

#### Slow flowrate stop function

When the discharge pressure has increased, decreasing the reference frequency (output of the PID processor) below the stop frequency for slow flowrate level (J15) for more than the elapsed stopping time on slow flowrate level stop latency (J16), the inverter decelerates to stop, while PID control itself continues to operate. When the discharge pressure decreases, increasing the reference frequency (output of the PID processor) above the starting frequency (J17), the inverter resumes operation. If we need to have a signal indicating the state in which the inverter is stopped due to the slow flowrate stop feature, we have to assign PID-STP function (Inverter stopping due to slow flowrate under PID control ) to one of the general-purpose output terminal (function code data = 44).

J15. PID Control (Stop frequency for slow flowrate).

Specifies the frequency which triggers a slow flowrate stop of the inverter.

#### J16. PID Control (Slow flowrate level stop latency).

Specifies the elapsed time from when the inverter stops operation due to slow flowrate level condition.

#### J17. PID Control (Starting frequency).

Specifies the starting frequency. Select a frequency higher than the slow flowrate level stop frequency. If the specified starting frequency is lower than the slow flowrate level stop frequency, the later stop frequency is ignored; the slow flowrate level stop is triggered when the output of the PID processor drops below the specified starting frequency.





For Example: Set-point set by keypad and feedback from a transducer (transmitter) connected in current input C1 (figure 2), forward operation.

RENIC-ECO

F02=0 (Start-Stop: keypad, FWD/REV button) F07=1.0 (Acceleration time 1) F08=1.0 (Deceleration time 1)

E40=7.00 (7 bar max) E41=0.00 (0 bar min) E43=10 (PID set-point value)

PID parameters:

J01=1 (PID active, forward operation) J02=0 (PID set value from keypad) E62=5 (PID feedback value by current input C1)

J03 (PID control P-gain) J04 (PID control I-gain) J05 (PID control D-gain) J06 (PID control Feedback filter)







# FRENIC-ECO

# 7. TROUBLESHOOTING

Alarm code	Alarm Name	Alarm contents
OC1	Overcurrent during acceleration	The inverter output current has exceeded the overcurrent level.
OC2	Overcurrent during deceleration	Possible causes: short-circuit in the output phase, F09 too large, ground faults, EMC noise, acceleration/deceleration times are too short or motor load is too
OC3	Overcurrent at constant speed	heavy.
EF	Ground fault (90kW or above)	A ground fault current flowed from the inverter output to the ground.
OU1	Overvoltage during acceleration	The internal DC-Voltage has exceeded the overvoltage level.
OU2	Overvoltage during deceleration	Possible causes: the input voltage is too high, the braking load is too high or the deceleration time is too short
OU3	Overvoltage at constant speed	
LU	Undervoltage	The DC voltage is below the undervoltage level.
Lin	Input phase loss	The unbalance between the input phases is too big.
OPL	Output phase loss	One output phase is not connected or has no load.
OH1	Heat sink overheat	The temperature of the heat sink has exceeded the alarm level.
OH2	Alarm issued by an external device	THR external failure. Check the external device which is connected to the inverter.
ОН3	Inside of the inverter overheat	The temperature inside the inverter has exceeded the alarm level.
ОН4	Motor protection (PTC thermistor)	PTC failure. Probably the motor temperature is too high.
FUS	Fuse blown (90kW or above)	The fuse inside the inverter is blown.
PbF	Charger circuit fault (55kW or above)	The magnetic contactor (MC) failed. This MC is inside the inverter and short- circuits the charging resistor.
OL1	Electronic thermal overload relay	Inverter detects an overload of the connected motor (related function codes F10 to F12).
OLU	Inverter overload	The temperature inside the inverter is too high or the load is too heavy.
Er1	Memory error	An error occurred while writing data to inverter memory.
Er2	Keypad communications error	Communication error between the remote keypad and the inverter.
Er3	CPU error	The CPU is not working properly.
Er4	Option board communications error	Communication error between the option board and the inverter. Refer to the option manual.
Er5	Option board error	An error has been detected by the option board. Refer to the option manual.
Er6	Incorrect operation error	Check setting of H96.
Er7	Autotuning error	Auto-tuning failed (check motor connections, motor parameters, check if main contactors are being closed properly and check if there is a BX or BBX functions assigned to a ON level digital input).
Er8	RS485 communications error	A communication error occurred during RS485 communication.
ErF	Data saving error during undervoltage	The inverter was not able to save the frequency command and PID process command set by the keypad when the power was cut off.
ErP	RS485 communications error (option board)	A communication error occurred during RS485 communication through the RS485 option board.
ErH	Power PCB error (55kW or above)	Failure caused by an internal inverter board.

For further information about alarm codes please refer to the FRENIC-Eco user's manual.







### 8.1 IP20 / IP00 specifications

		Ite	em		Specifications													
Туре	(FRNF	1S-4E)			0.75	1.5	2.2	4.0	5.5	7.5	11	15	18.5	22	30	37	45	55
Nom	inal applied r	notor (k)	N)	*1	0.75	1.5	2.2	4.0	5.5	7.5	11	15	18.5	22	30	37	45	55
	Rated capa	city (kVA	N)	*2	1,9	2,8	4,1	6,8	9,5	12	17	22	28	33	44	54	64	80
tings	Rated voltag	ge (V)		*3	Three	-phase,	380, 400	V/50 Hz	, 380, 40	0, 440,	460 V/60	) Hz (with	n AVR fu	nction)				
ut rai	Rated curre	nt (A)		•4	2.5	3.7	5.5	9.0	12.5	16.5	23	30	37	44	59	72	85	105
Dutpi	Overload ca	pability			120 %	of rated	current	for 1min										
	Rated frequ	ency			50, 60	Hz												
		Main p	ower supply		Three	-phase, 3	380 to 48	80V, 50/6	60Hz						Three-p 380 to 4 Three-p 380 to 4	ohase, 140 V/50 H ohase, 180 V/60 H	iz iz	
tings	Phases, voltage, frequency	Auxilia power	ry control input	6	Single	-phase,	380 to 4	80V, 50/	60Hz						Single- 380 to 4 Single- 380 to 4	ohase, 440 V/50 H ohase, 480 V/60 H	iz iz	
nput ra		Auxilia power	ry fan input	*5	None													*10
-	Voltage/freq	luency a	llowance	ļ	Voltag	je: +10 t	o -15% (	Voltage u	unbaland	e: 2% or	r less) *9	, Freque	ncy: +5	to -5%				
	Rated	0.022	(with DCR)		1.6	3.0	4.5	7.5	10.6	14.4	21.1	28.8	35.5	42.2	57.0	68.5	83.2	102
	current (A)	*6	(without DCR)		3.1	5.9	8.2	13.0	17.3	23.2	33.0	43.8	52.3	60.6	77.9	94.3	114	140
	Required po supply capa	ower icity (kV/	A)	•7	1.2	2.2	3.1	5.3	7.4	10	15	20	25	30	40	48	58	71
ding	Torque (%)			*8						20						10	to 15	
Brak					Starting frequency: 0.0 to 60.0 Hz. Braking time: 0.0 to 20.0 a. Braking Javal: 0 to 60%													
	DC braking				Startin	ng freque	ency: 0.0	to 60.0 I	Hz, Brak	ing time:	0.0 to 3	0.0 s, Br	aking lev	el: 0 to 6	50%			
DC r	DC braking eactor (DCR)	)			Startin	ng freque	ency: 0.0	to 60.0 I	Hz, Brak	ing time:	0.0 to 3	0.0 s, Br	aking lev	el: 0 to 6	50%			_
DC r Appl	DC braking eactor (DCR)	) standar	ds		Startin Option UL508	ng freque n BC, C22.	ency: 0.0 2 No. 14	to 60.0 l	Hz, Brak 78 :1997	ing time: (Applyir	0.0 to 3	0.0 s, Br	aking lev	vel: 0 to 6	50%			
DC r Appl Encl	DC braking eactor (DCR) icable safety osure (IEC60	) standar (529)	ds		Startin Option UL508 IP20,	ng freque n BC, C22. UL open	ency: 0.0 2 No. 14 type	to 60.0 I	Hz, Brak 78 :1997	(Applyir	0.0 to 3	0.0 s, Br	aking lev	vel: 0 to 6	50%	UL open	type	
DC r Appl Encl Cool	DC braking eactor (DCR) icable safety osure (IEC60 ing method	) standar 529)	ds		Startin Option UL508 IP20, Natural cooling	ng freque n BC, C22. UL open	2 No. 14 type Fan coo	to 60.0 I	Hz, Brak 78 :1997	ing time: (Applyir	0.0 to 3	0.0 s, Br	aking lev	vel: 0 to 6	1P00, 1	UL open	type	

		ltem								Spe	cifications				2.55		
Туре	(FRNF1S	4A)		75	90	110	132	160	200	220	280	315	355	400	450	500	560
Nomi	nal applied moto	or (kW)	•1	75	90	110	132	160	200	220	280	315	355	400	450	500	560
	Rated capacity	/ (kVA)	*2	105	128	154	182	221	274	316	396	445	495	563	640	731	792
s6u	Rated voltage	(V)	*3	Three-	phase, 38	) to 480V	(with AVR	function)									
t rati	Rated current	(A)	*4	139	168	203	240	290	360	415	520	585	650	740	840	960	1040
outpu	Overload capa	bility		120 %	of rated cu	urrent for 1	min										
0	Rated frequen	cy		50, 60	Hz												
		Main power su	pply	Three-	phase, 38	0 to 440V,	50Hz or T	hree-phas	ie, 380 to	480V, 60H	z						
	Phases,	Auxiliary contro power Input	ol .	Single-	phase, 38	0 bis 480V	/, 50/60Hz										
atings	frequency	Auxiliary fan power Input	*9	Single- Single	phase, 38 pahse, 38	0 to 440V/ 0 to 480V/	50Hz 60Hz										
puti	Voltage/freque	ncy variations		Voltage	e: +10 to -	15% (Volta	age unbala	ance: 2% d	or less) *7,	Frequenc	y: +5 to -5	%			24		
5	Rated current	(A) *8	(with DCR)	138	164	201	238	286	357	390	500	559	628	705	789	881	990
	runed content	((1))	(without DCR)	-	-		-	-	-	-			-		-	-	-
	Required power	er supply capacit	y(kVA) *5	96	114	140	165	199	248	271	347	388	435	489	547	611	686
бu	Torque (%)		*6			-0				. 1	) to 15			1-11-1 -		1900 a	
Brak	DC Injection b	raking		Starting	g frequenc	y: 0.0 to 6	0.0Hz, Bra	aking time	0.0 to 30.	.0s, Brakin	g level: 0	0 60%					
DC re	eactor (DCR)	6)s		Option								_					
Appli	cable safety star	ndards		UL508	C, C22.2 M	lo. 14, EN	50178 :19	97 (Apply	ing)								
Enclo	sure (IEC60529	))		IP20, U	JL open ty	ре											
Cooli	ng method			Fan co	oling												
Mass	(kg)			34	42	45	63	67	96	98	162	165	282	286	355	360	360

 Fuji 4-pole standard motor
 Rated capacty is calculated by assuming the output rated voltage as 440V for three-phase 400 V series.
 Output voltage cannot exceed the power supply voltage.
 An excessively low setting of the carrier frequency may result in the higher motor temperature or tripping of the inverter by its overcurrent limiter setting. Lower the continuous load or maximum load instead. (When setting the carrier frequency (F26) to 1kHz, reduce the load to https://doi.org/10.1016/j.j.com/j.c maximum load instead, (when seeing the currer requency (r20 80% of first rating.) \*5 Obtained when a DC reactor (DCR) is used. \*6 Average braking torque (Varies with the efficiency of the motor.)

\*7 Voltage unbalance (%) = Max. voltage (V) - Min. voltage (V) Three-phase average voltage (V) x 67 (IEC61800-3)

- If this value is 2 to 3%, use an AC reactor (ACR option).
  If this value is 2 to 3%, use an AC reactor (ACR option).
  Trial calculation done on assumption that the power capacity is 500kVA (or 10 times the inverter capacity if the inverter capacity is larger than 50 kVA) and the Inverter is connected to the power supply of %X=5%.
  Use [R1, T1] terminals for driving AC cooling fans of an Inverter powered by the DC link bus, such as by a high power factor PVM converter. (In ordinary operation, the terminals are not used.)
  To Bingle-phase, 380 to 440V/50Hz or Bingle-phase, 380 to 440V/50Hz or Bingle-phase.







## 8.2 IP54 specifications

	Item								Specifi	cations							
	Type (FRNF1L-4E)	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90
Non	ninal applied motor [kW] *1)	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90
	Rated capacity [kVA] <sup>*2)</sup>	1.9	2.8	4.1	6.8	9.5	12	17	22	28	33	44	54	64	77	105	128
gs nt	Rated voltage [V] *3)				Three	-phase 3	80V,400	V/50Hz,	380V,400	)V,440V,	460V/60	Hz (With	AVR fur	nction)			
atinç	Rated current [A] *4)	2.5	3.7	5.5	9.0	12.5	16.5	23	30	37	44	59	72	85	105	139	168
02	Overload capability							120%	of rated of	current fo	or 1min						
	Rated frequency								50, 6	50Hz			1				
	Main power supply				Thre	ee-phase	,380 to 4	80V,50/6	50Hz					380 380	[hree-ph ) to 440\ ) to 480\	ase, 1/50Hz 1/60Hz	
ings	Auxiliary control power input				Sing	le-phase	e,380 to 4	80V,50/	50Hz					380 380 380	Single-ph ) to 440\ ) to 480\	ase, //50Hz //60Hz	
Input rat	Auxiliary power input for the fans "9)						-							380 380 380	Single-ph ) to 440\ ) to 480\	ase, 1/50Hz 1/60Hz	
	Voltage/frequency variations		Voltage: +10 to -15% (Voltage unbalance: 2% or less <sup>(8)</sup> ), Frequency: +5 to -5%														
	Rated current [A] *5)	1.6	3.0	4.5	7.5	10.6	14.4	21.1	28.8	35.5	42.2	57.0	68.5	83.2	102	138	164
	Required power supply capacity [kVA] <sup>*6)</sup>	1.2	2.2	3.1	5.3	7.4	10	15	20	25	30	40	48	58	71	96	114
бu	Torque *7) [%]					2	0							10	to 15		
Braki	DC injection braking				Starting	g frequer	icy: 0.0 to	) 60.0Hz	, Braking	time: 0.0	) to 30.0s	s, Brakin	g level: C	) to 60%			
	EMC filter				S	tandard (	conforma Er	nce: Imn nission: (	nunity: 2ª Class A (	<sup>d</sup> Env. (E Group 1 (	N61800- EN5501	3: 1996- 1: 1998+	+A11:200 A1: 1999	)0) )+A2: 20	02)		
[	DC REACTOR (DCRE)					Inpu	power fa	actor : 86	% or mo	re at 100	% load(C	Dutput R	ating)				
	KEY PAD							Multifun	ctional K	eypad (T	P-G1W)						
Ap	plicable safety standards	EN50178:1997															
	Enclosure							P54(IEC	50529) / I	JL TYPE	12(UL50	D)					
	Cooling method	Natural	cooling			-				Fan c	ooling						
	Weight / Mass [kg]	12.5	12.5	13	14	14	22	22	24	34	35	40	54	56	74	76	86

\*1) Fuji's 4-pole standard motor.

\*2) Rated capacity is calculated by regarding the output rated voltage as440V for three-phase 400V series.

\*3) Output voltage cannot exceed the power supply voltage.

\*4) Motor temperature gets higher or current limit function of the inverter is easy to operate if carrier frequency is set to low. Continuous or peak load shall be reduced to avoid high motor temperature or current limit operation. When setting the carrier frequency (F26) to 1 kHz or below, reduce the load to 80% of rated load or below for use.

\*5) Calculated under Fuji-specified conditions.

\*6) Obtained when a DC reactor (DCRE) is used.

\*7) Average braking torque without optional braking resistor (varies with the efficiency of the motor).

\*8) Voltage unbalance =  $\frac{\text{Max.voltage}[V] \quad \text{Min.voltage}[V]}{\text{Three - phase average voltage}[V]} \times 67\%$  (IEC61800 3(5.2.3))

If this value is 2 to 3%, use an AC reactor (ACR).

\*9) Normally no need to be connected. Use these terminals when the inverter is used with a power regenerative PWM converter (e.g. RHC series).







# 8.3 External dimensions

# 8.3.1 IP20 / IP00 external dimensions

## FRN0.75F1S-4 to FRN5.5F1S-4

Units expressed in mm



#### FRN7.5F1S-4 to FRN30F1S-4





# 

Units expressed in mm



Power							D	imensio	ns [mm]						
supply voltage	Туре	W	W1	W2	W3	W4	Н	H1	D	D1	D2	D3	D4	ØA	ØB
	FRN7.5F1S-4E														
	FRN11F1S-4E	220	196	63,5	46,5	46,5	260	238		118,5	96,5	141,7	16	27	34
	FRN15F1S-4E											136,7	21		
Three-	FRN18.5F1S-4E								215					34	42
phase	FRN22F1S-4E	250	226	67	58	58	400	378		85	130	166,2	2		
1001	FRN30F1S-4E	]		-								-	-	-	







# FRN37F1S-4 to FRN560F1S-4

Units expressed in mm





Power supply	_							Dime	ensions	[mm]						
voitage	Гуре	W	W1	W2	W3	W4	W5	Н	H1	H2	D	D1	D2	D3	D4	ØA
	FRN37F1S-4E															
	FRN45F1S-4E	320	240	304	310,2			550	530		255		140			
	FRN55F1S-4E							330	330			115			4,5	
	FRN75F1S-4E					8	10	615	595	12	270					10
	FRN90F1S-4E	355	275	339	345,2								155			
	FRN110F1S-4E								720		300	145	100	4		
	FRN132F1S-4E							740			315	135				
	FRN160F1S-4E							740	710							
	FRN200F1S-4E	530	430	503	509,2						360	180				
Three-	FRN220F1S-4E										300	100				
nhase	FRN280F1S-4E							1000	970						6	
400 V	FRN315F1S-4E					13,5	15	1000	770	15,5	380	200	180			15
100 V	FRN355F1S-4E	680	580	653	659											
	FRN400F1S-4E													6,4		
	FRN450F1S-4E							1/00	1270							
	FRN500F1S-4E	880	780	853	859			1400	1370		440	160				
	FRN560F1S-4E	]														







# 8.3.2 IP54 dimensions

Units expressed in mm



Power supply voltage	Inverter type	W	Н	D
i onoi suppry voltago	FRN0.75F1L-2E			
	FRN1.5 F1L-2E			
	FRN2.2 F1L-2E	210	500	225
	FRN3.7 F1L-2E	210	000	220
Inree phase 200V	FRN5.5 F1L-2E			
	FRN7.5F1L-2E			
	FRN11F1L-2E	300	600	280
	FRN15F1L-2E			
	FRN18.5F1L-2E			
	FRN22F1L-2E	350	800	220
	FRN30F1L-2E			320
	FRN37F1L-2E	400	1100	
	FRN45F1L-2E	450	1280	360
	FRN0.75F1L-4E			
	FRN1.5F1L-4E			
	FRN2.2F1L-4E	210	500	225
	FRN3.7F1L-4E			
	FRN5.5F1L-4E			
	FRN7.5F1L-4E			
Three phase	FRN11F1L-4E	300	600	280
400V	FRN15F1L-4E			
	FRN18.5F1L-4E			
	FRN22F1L-4E	350	800	
	FRN30F1L-4E			320
	FRN37F1L-4E	100		
	FRN45F1L-4E	400	1100	
	FRN55F1L-4E			
	FRN75F1L-4E	450	1170	350
	FRN90F1L-4E	450	1280	360







## 8.3.3 Keypad dimensions TP-E1

Units expressed in mm



# 8.3.4 Keypad dimensions TP-G1

Units expressed in mm









# 8.3.5 Dimensions DC Reactors

DC Reactors	Induc- tivity	Rated- current	Connection	Protection class	Loss	Weight	Isolation-	в	т	T1	н	L1	L3	d1	d2	d2	Drawing
	, 		type	ю		oo ka	ologo								mm2		Nr
DCRE4-0.4	50	<b>А</b> 1.5	Clamp	IP00	<b>6</b> .6	0.5	T50/B	60	64	50	65	44	36	3.6x7	2.5	11111	1
DCRE4-0.75	30	2.5	Clamp	IP00	8	0.7	T50/B	66	76	56	70	50	40	4.8x9	2.5		1
DCRE4-1.5	16	4	Clamp	IP00	11,4	1,2	T50/B	66	87	66	70	50	51	4,8x9	2,5		1
DCRE4-2.2	12	5,5	Clamp	IP00	13	1,4	T50/B	78	72	60	80	56	44	4,8x9	2,5		1
DCRE4-4.0	7	9	Clamp	IP00	16	2,1	T50/B	84	96	73.5	86	64	62	4,8x9	2,5		1
DCRE4-5.5	4	13	Clamp	IP00	14,7	2,1	T50/B	84	96	73.5	86	64	62	4,8x9	2,5		1
DCRE4-7.5	3,5	18	Clamp	IP00	25,5	4,5	T50/B	96	110	99.7	95	84	83	5,8X11	2,5		1
DCRE4-11	2,2	25	Clamp	IP00	23	4,5	T50/B	96	110	99.7	95	84	83	5,8X11	4		1
DCRE4-15	1,8	34	Clamp	IP00	27	6	T50/B	120	125	98	115	90	81	5,8X11	10		1
DCRE4-18.5 KL	1,4	41	Clamp	IP00	31	6	T50/B	120	150	98	134	90	81	5,8X11	10		1
DCRE4-18.5 KS	1,4	41	Lug	IP00	31	6	T50/B	120	150	98	105	90	81	5,8X11		5,5	2
DCRE4-22A KL	1,2	49	Clamp	IP00	33	8,4	T50/B	120	170	118	134	90	91	5,8X11	10		1
DCRE4-22A KS	1,2	49	Lug	IP00	33	8,4	T50/B	120	170	118	105	90	91	5,8X11		5,5	2
DCRE4-30B KL	0,86	80	Clamp	IP00	85	10,2	T50/B	150	185	126	200	122	103	7x13	35		3
DCRE4-30B KS	0,86	80	Lug	IP00	85	10,2	T50/B	150	185	126	135	122	103	7x13		10	2
DCRE4-37B KL	0,7	100	Clamp	IP00	100	13,6	T50/B	150	220	132	210	122	131	7x13	50		3
DCRE4-37B KS	0,7	100	Lug	IP00	100	13,6	T50/B	150	255	132	135	122	131	7x13		10	2
DCRE4-45B KL	0,58	120	Clamp	IP00	90	13,6	T50/F	150	225	152	210	122	131	7x13	50		3
DCRE4-45B KS	0,58	120	Lug	IP00	90	13,6	T50/F	150	225	152	135	122	131	7x13		10	2
DCRE4-55B KL	0,47	146	Clamp	IP00	109	17	T50/F	174	215	130	235	155	130	7x13	50		3
DCRE4-55B KS	0,47	146	Lug	IP00	109	17	T50/F	174	215	130	155	155	130	7x13		12	2

# Drawing 1





Drawing 3













FRENIC-Eco



DC Reactors type	W	W1	D	D1	D2	D3	Н	Mounting hole	Terminal hole	Mass KG	Drawing
DCR4-75C	255±10	225	106±2	88±1	125	53±1	145	6	M10	12.4	4
DCR4-90C	258±10	225	116±2	98±1	130	58±1	145	6	M12	14.7	4
DCR4-110C	308±10	265	118± 4	90±2	140	58±2	155	8	M12	18.4	4
DCR4-132C	308±10	265	126± 4	100±2	150	63±2	180	8	M12	22	4
DCR4-160C	357±10	310	131±4	103±2	160	65.5±2	190	10	M12	25.5	4
DCR4-200C	357±10	310	141±4	113±2	165	70.5±2	190	10	M12	29.5	4
DCR4-220C	357±10	310	146± 4	118±2	185	73±2	190	10	M12	32.5	4
DCR4-280C	350±10	310	161±4	133	210	80.5±2	190	M10	M16	38	4
DCR4-315C	400±10	345	146± 4	118	200	73±2	225	M10	M16	40	4
DCR4-355C	400±10	345	156± 4	128±2	200	78±2	225	M10	-	47	5
DCR4-400C	445±10	385	145± 4	117	213	72.5±2	245	M10	-	52	5
DCR4-450C	440±10	385	150± 4	122±2	215	75±2	245	M10	-	60	5
DCR4-500C	445±10	390	165± 4	137±2	220	82.5±2	245	M10	-	70	5
DCR4-560C	270	145	208	170	200	-	480	Ø14 LONG HOLE	Ø15	70	6

# Drawing 4



# Drawing 5



## Drawing 6









## 8.3.6 Dimensions EMC input filters

# FS5536 – 12 – 07

Units expressed in mm

# 



FS21312 - 18 - 07



FS5536 - 35 - 07

FS21312 - 44 - 07









FS5536 - 50 - 07



FS21312 – 78 – 07







FS5536 - 180 - 40

150















FN3359







Dimensions [mm]	FN3359 – 600 – 99	FN3359 – 800 – 99	FN3359 - 1000 - 99
A	300	350	350
В	260	280	280
С	135	170	170
D	210	230	230
E	120	145	145
F	235	255	255
G	Ø12	Ø12	Ø12
Н	2	3	3
	43	53	53
J	M12	M12	M12
К	20	25	25
L	20	25	25
М	440	510	510
Ν	221	241	241
0	142	177	177
U	60	60	60
W	25	40	40
Х	15	20	20
Y	40	50	50
Z	Ø10.5	Ø14	Ø14







# 9. OPTIONS

## 9.1 Options table

Option name		Function and application					
	DC reactor (DCRE)	The DC reactor is used to reduce harmonic components on the input current (mains supply) of the inverter. Note: DO NOT FORGET to remove the DC bar between P1 and P(+) before installing this option.					
ain options	Output filter(OFLE)	Install an output filter between the inverter and the motor to: 1) Suppress the voltage fluctuation at the motor input terminals. 2) Reduce leakage current from the motor power cable (motor supply), due to harmonic components. 3) Reduce emission and induction noise generated from the motor power cable. Note: When using an OFLE, set the switching frequency of the inverter (function code F26) within the allowable range specified by the filter manufacturer, otherwise the filter will overheat.					
Z	Ferrite ring reactors (ACL)	The ferrite ring reactors are used to reduce radiated emissions from the inverter.					
	EMC input filter	The EMC input filter is used to make the inverter to conform to European EMC directives.					
	AC reactor	The AC reactor is connected to the inverter input (mains supply) when the inter-phase voltage unbalance of the AC mains is between 2% and 3%.					
	(ACRE)	Inter - phase voltage unbalance = $\frac{\text{Max. voltage (V)} - \text{Min. voltage (V)}}{3 \text{ phase average voltage (V)}} \times 67$					
IS	Multi-function keypad (TP-G1)	Allows the user to monitor the status of the inverter (voltage, output current, input power,), as well as to set parameters values in a conversational mode (6 languages available). It is able to store three complete inverter function sets. It includes a Liquid Crystal Display.					
ion opti	Extension cable for keypad (CBS)	The extension cable allows to connect the keypad to the inverter remotely. Three lengths are available: 5 m (CB-5S), 3 m (CB-3S) y 1 m (CB-1S).					
nunicat	RS485 Communications card (OPC-F1-RS)	This card adds an additional communications port to the inverter that allows to connect a PLC or PC.					
nd comr	DeviceNet interface card (OPC-F1-DEV)	This card is used to communicate the inverter to a DeviceNet master unit.					
ation ar	ProfiBus DP interface card (OPC-F1-PDP)	This card is used to communicate the inverter to a ProfiBus DP master unit.					
Opera	LonWorks interface card (OPC-F1-LNW)	This card is used to communicate the inverter to a LonWorks master unit					
	Relay output card (OPC-F1-RY)	This card is used to add three relay outputs to the inverter.					
	Loader software	PC software, Windows GUI (Graphics user interface) based that allows to set inverter function values more easily. Also allows to upload/download all the function values to/from a file.					
	Attachment for external cooling (PB-F1)	With this adapter you can install the inverter in the panel in such a way that the heatsink is outside of the cabinet. Available for inverters for capacities of 30 kW or below.					
	Panel-Mount adapter (MA-F1)	Use this adapter when installing the FRENIC-Eco by using the mounting holes of the already installed inverter (FRENIC5000P11S, 5.5 to 37KW).					





#### 9.2 EMC input filter

The following table describes the EMC input filter and the EMC compliance level for each inverter capacity.

	Inverter model	EMC input filter	Compliance level				
	FRN0,75F1S-4E	FS5536-12-07	· ·				
	FRN1,5F1S-4E	FS5536-12-07					
	FRN2,2F1S-4E	FS5536-12-07					
	FRN4,0F1S-4E	FS5536-12-07	C1 conducted (20m 1Ek/1z), C1 redicted (2Em 1Ek/1z)				
	FRN5,5F1S-4E	FS21312-18-07	CT CONducted (ZOIII, TSKHZ); CT Tadiated (ZSIII, TSKHZ)				
	FRN7,5F1S-4E	FS5536-35-07					
	FRN11F1S-4E	FS5536-35-07					
	FRN15F1S-4E	FS21312-44-07					
	FRN18,5F1S-4E	FS5536-50-07					
	FRN22F1S-4E	FS21312-78-07	C1 conducted (20m, 15kHz); C2 radiated (25m, 15kHz)				
	FRN30F1S-4E	FS21312-78-07					
	FRN37F1S-4E FS5536-100-35						
ise ply	FRN45F1S-4E	FS5536-180-40					
gha	FRN55F1S-4E	FS5536-180-40					
< e	FRN75F1S-4E	FS5536-180-40					
40C	FRN90F1S-4E	FS5536-180-40	$C_{2}$ conducted (10m, 10k/ kz), C_{2} radiated (10m, 10k/ kz)				
	FRN110F1S-4E	FS5536-250-99	CZ CONDUCIEU (TOITI, TOKHZ); CZ TAUIAIEU (TOITI, TOKHZ)				
	FRN132F1S-4E	FS5536-250-99					
	FRN160F1S-4E	FS5536-400-99-1					
	FRN200F1S-4E	FS5536-400-99-1					
	FRN220F1S-4E	FS5536-400-99-1					
	FRN280F1S-4E	FN3359-600-99					
	FRN315F1S-4E	FN3359-600-99					
	FRN355F1S-4E	FN3359-800-99					
	FRN400F1S-4E	FN3359-800-99	C3 conducted (100m, 6kHz); C2 radiated (100m, 6kHz)				
1	FRN450F1S-4E	FN3359-800-99					
1	FRN500F1S-4E	FN3359-1000-99	1				
	FRN560F1S-4E FN3359-1000-99						

#### 9.3 DC reactor

The following table describes the recommended standard DC reactors for each inverter model.

	Inverter model	Standard DC reactors				
	FRN0,75F1S-4E	DCRE4-0,75				
	FRN1,5F1S-4E	DCRE4-1,5				
	FRN2,2F1S-4E	DCRE4-2,2				
	FRN4,0F1S-4E	DCRE4-4,0				
	FRN5,5F1S-4E	DCRE4-5,5				
nse ply	FRN7,5F1S-4E	DCRE4-7,5				
pha	FRN11F1S-4E	DCRE4-11				
ee >	FRN15F1S-4E	DCRE4-15				
40C	FRN18,5F1S-4E	DCRE4-18,5				
	FRN22F1S-4E	DCRE4-22A				
	FRN30F1S-4E	DCRE4-30B				
	FRN37F1S-4E	DCRE4-37B				
	FRN45F1S-4E	DCRE4-45B				
	FRN55F1S-4E	DCRE4-55B				







# CONTACT INFORMATION

# Headquarters Europe

### Fuji Electric FA Europe GmbH

Goethering 58 63067 Offenbach/Main Germany Tel.: +49 (0)69 669029 0 Fax: +49 (0)69 669029 58 info\_inverter@fujielectric.de www.fujielectric.de

#### Germany

Fuji Electric FA Europe GmbH Sales area South Drosselweg 3 72666 Neckartailfingen Tel.: +49 (0)7127 9228 00 Fax: +49 (0)7127 9228 01 hgneiting@fujielectric.de

#### Switzerland

Fuji Electric FA Schweiz ParkAltenrhein 9423 Altenrhein Tel.: +41 71 85829 49 Fax.: +41 71 85829 40 info@fujielectric.ch www.fujielectric.ch

## Headquarters Japan

#### Fuji Electric Systems Co., Ltd..

Gate City Ohsaki East Tower, 11-2 Osaki 1-chome, Shinagawa-ku, Tokyo 141-0032 Japan Tel.: +81-3-5435-7280 Fax: +81-3-5435-7425 www.fesys.co.jp

## Fuji Electric FA Europe GmbH

Sales area North Friedrich-Ebert-Str. 19 35325 Mücke Tel.: +49 (0)6400 9518 14 Fax: +49 (0)6400 9518 22 mrost@fujielectric.de

#### Spain

Fuji Electric FA España Ronda Can Fatjó 5, Edifici D, Local B Parc Tecnològic del Vallès 08290 Cerdanyola (Barcelona) Tel.: +34 93 5824333/5 Fax: +34 93 5824344 infospain@fujielectric.de

