



FEASYCOM

FSC-BT80X

Sink Programming User Guide

Version 3.4

深圳市飞思通科技有限公司
FEASYCOM

Revision History

Version	Data	Notes	Author
1.0	2015/10/10	First Release	Tony
2.0	2016/05/20	Add commands	Navy
3.0	2017/11/13	Add A2DP Source profiles	Navy
3.1	2018/01/25	Add commands	Navy
3.2	2018/08/31	Update Commands	Navy
3.3	2018/12/21	Add commands	Navy
3.4	2019/04/26	Update A2DP Source profiles Commands	Carfei

Contact Us:

Shenzhen Feasycom Technology Co., Ltd

Web: www.feasycom.com

Email: support@feasycom.com

Tel: +86-755-27924639, +86-755-23062695

Address: Room 2004-2005, 20th Floor, Huichao Technology Building,
Jinhai Road, Xixiang, Baoan District, Shenzhen, 518100, China.

Contents

1. Introduction.....	6
1.1 Terms.....	6
1.2 Hardware Interface.....	6
1.3 Supported Bluetooth Profile	6
1.4 Command Format.....	6
1.5 Indication Format.....	7
1.6 Module Default Settings	7
2.Command Table	8
2.1 General Commands	8
2.1.1 AT Command Test.....	8
2.1.2 Read Firmware Version	8
2.1.3 Read BR/EDR MAC Address.....	8
2.1.4 Read BLE MAC Address	9
2.1.5 Read/Write BR/EDR Local Name	9
2.1.6 Read/Write BLE Local Name	10
2.1.7 Read/Write BLE Random Addr Configuration	10
2.1.8 Read/Write UART Baudrate.....	10
2.1.9 Read/Write UART Configuration <need reboot>	10
2.1.10 Read/Write Pin Code	11
2.1.11 Turn On/Off Secure Simple Pairing <need reboot>	11
2.1.12 Read/Write Class Of Device <need reboot>	11
2.1.13 Read/Clear Paired Record	12
2.1.14 Turn On/Off Throughput Mode <need reboot>	12
2.1.15 Read Module States.....	13
2.1.16 Turn On/Off Power On Auto Reconnect <need reboot>	13
2.1.17 Scan Nearby Devices	14
2.1.18 Auto Scan Enable.....	14
2.1.19 Speaker Volume Setting.....	14
2.1.20 I2S/PCM Format Configuration <need reboot>	15
2.1.21 SPDIF Format Configuration <need reboot>	15
2.1.22 Release All Connections.....	16
2.1.23 Soft Reboot.....	16
2.1.24 Restore Factory Settings.....	16
2.1.25 Close AT Air Command Mode.....	16
2.1.26 Enable Module.....	16
2.1.27 Enter Pairing Mode	17
2.2 HFP Commands	17
2.2.1 Read HFP State.....	17
2.2.2 Establish HFP Connection	17
2.2.3 Release HFP Connection.....	18
2.2.4 Dial/Redial Phone Number	18
2.2.5 Send DTMF code	18

2.2.6 Pick Up Incoming Call.....	19
2.2.7 Reject/Hung up Call	19
2.2.8 Transfer Voice Audio	19
2.2.9 Mute Mic	19
2.3 A2DP/AVRCP Commands.....	20
2.3.1 Read A2DP State.....	20
2.3.2 Read/Write A2DP Role	20
2.3.3 Establish A2DP Connection	20
2.3.4 Release A2DP Connection	21
2.3.5 Read A2DP Decoder	21
2.3.6 Read/Write AVRCP Configuration	21
2.3.7 Track Play/Pause.....	22
2.3.8 Track Play.....	22
2.3.9 Track Pause.....	22
2.3.10 Track Stop.....	22
2.3.11 Track Forward.....	23
2.3.12 Track Backward.....	23
2.4 Phonebook Access Commands	23
2.4.1 Download Phonebook	23
2.5 Bluetooth Serial Commands (BR/EDR SPP).....	23
2.5.1 Read SPP State	23
2.5.2 Establish SPP Connection	24
2.5.3 Release SPP Connection	24
2.5.4 Send Data Via SPP.....	24
2.6 Bluetooth Serial Commands (LE GATT)	25
2.6.1 Read GATT State.....	25
2.6.2 Release GATT Connection.....	25
2.6.3 Send Data Via GATT.....	25
3. Indication Table	26
3.1 General Indications	26
3.1.1 Device State	26
3.1.2 Scan Result.....	26
3.1.3 Paired Success.....	27
3.2 HFP Indications	27
3.2.1 HFP State	27
3.2.2 HFP Device Information.....	27
3.2.3 Incoming/Outgoing Call Number	27
3.2.4 Incoming/Outgoing Call Name.....	28
3.2.5 HFP Voice Audio State	28
3.2.6 HFP Device Network Signal Strength.....	28
3.2.7 HFP Device Network Operator Selection	28
3.2.8 HFP Device Roaming State.....	29
3.2.9 HFP Device Battery Level.....	29
3.3 A2DP/AVRCP Indications.....	29

3.3.1 A2DP State	29
3.3.2 A2DP Device Information	29
3.3.3 AVRCP State.....	29
3.3.4 Media Player State.....	30
3.3.5 Media Player Play Progress.....	30
3.3.6 Media Track Information	30
3.4 Phonebook Access Indications.....	31
3.4.1 PB Entries Of Remote Devices	31
3.4.2 Received Phonebook Data	31
3.5 Bluetooth Serial Indications.....	32
3.5.1 SPP State	32
3.5.2 GATT State.....	32
3.5.3 SPP Device Information	32
3.5.4 GATT Device Information	32
3.5.5 SPP Received Data	33
3.5.6 GATT Received Data	33
3.6 GPIO Indications	33
3.6.1 LED Pin	33
3.6.2 State Pin	33

1. Introduction

This specification presents design guidelines for software engineers that use FSC-BT80X series modules for Bluetooth requirements.

1.1 Terms

Throughout this specification:

- {} : Content between {...} is optional
- << : Content behind << represents a *COMMAND* sent from Host to Module
- >> : Content behind >> represents a *RESPONSE* sent from Module to Host

1.2 Hardware Interface

- GPIO
- PWM
- UART
- I2C Master/Slave
- I2S Master/Slave
- Analog Input/Output

1.3 Supported Bluetooth Profile

- SPP (Serial Port Profile)
- GATT Server (Generic Attribute Profile)
- GATT Client (Generic Attribute Profile)
- HFP Sink (Hands-Free Profile)
- A2DP Sink (Advanced Audio Distribution Profile)
- A2DP Source (Advanced Audio Distribution Profile)
- AVRCP Controller (Audio/Video remote controller Profile)
- AVRCP Target (Audio/Video remote controller Profile)
- HID Keyboard (Human Interface Profile)
- PBAP Server (Phonebook Access Profile)

1.4 Command Format

AT+ Command {=Param1{, Param2{, Param3...}}} <CR><LF>

- All commands start with “AT”, end with <CR><LF>

- <CR> stands for "carriage return", corresponding hex is 0x0D
- <LF> stands for "line feed", corresponding hex is 0x0A
- If command has parameter, parameter keep behind "="
- If command has multiple parameters, parameter must be separated by ","
- If command has response, response start with <CR><LF>, end with <CR><LF>
- Module will always report command's execution result using "OK" for success or "ERROR" for failure

e.g.

1. Read module's BR/EDR local name


```
<< AT+NAME
>> +NAME=Feasycom
>> OK
```
2. Pick up an incoming call when no call incoming actually


```
<< AT+HFPANSW
>> ERROR
```

1.5 Indication Format

<CR><LF>+ Indication {=Param1{, Param2{, Param3...}}} <CR><LF>

- All indications start with <CR><LF>, end with <CR><LF>
- If indication has parameter, parameter keep behind "="
- If indication has multiple parameters, parameter must be separated by ","
- Hex value <FF> will be used instead of "," in some special indications

e.g.

1. Received "1234567890" from mobile phone via SPP profile


```
>> +SPPDATA=10,1234567890
```
2. Call number "10086" use a mobile phone when HFP connected


```
>> +HFPSTAT=4
      +HFPCID=10086
      +HFPCIE=China Mobile
      +HFPAUDIO=1
      +HFPSTAT=6
```

1.6 Module Default Settings

Local Name (BR/EDR)	FSC-BT80X
Local Name (LE)	FSC-BT80X-LE
Pin Code	0000
Secure Simple Pairing Mode	On
Physical UART Baudrate	115200bps/8/N/1

2.Command Table

2.1 General Commands

2.1.1 AT Command Test

Format: AT
Response: OK
Description: Test the communication between HOST and Module after power on, UART baudrate changed and etc.
Example: AT command test << AT >> OK

2.1.2 Read Firmware Version

Format: AT+VER
Response: +VER=Param Param: Firmware version (24 Bytes ASCII)
Example: Read module's firmware version << AT+VER >> +VER=FSC-BT80X,V1.0.0,20160120 >> OK

2.1.3 Read BR/EDR MAC Address

Format: AT+ADDR
Response: +ADDR=Param Param: Module's BR/EDR MAC address (12 Bytes ASCII)

Example: Read Module's BR/EDR MAC address

```
<< AT+ADDR
>> +ADDR=DC0D30123456
>> OK
```

2.1.4 Read BLE MAC Address

Format: AT+LEADDR

Response: +LEADDR=Param
Param: Module's LE MAC address (12 Bytes ASCII)

2.1.5 Read/Write BR/EDR Local Name

Format: AT+NAME {=Param1{, Param2}}

Param1: BR/EDR local name (1~31 Bytes ASCII, default: FSC-BT80X)

Param2: MAC address suffix (0/1, default:0)

(0) Disable suffix

(1) Enable suffix "-XXXX" (lower 4 bytes of MAC address) after local name

Response: +NAME=Param

Description: Write local name if parameter existence, otherwise read current local name

Example: Read current BR/EDR local name

```
<< AT+NAME
>> +NAME=Feasycom
>> OK
```

Example: Change module's BR/EDR local name to "ABC"

```
<< AT+NAME=ABC
>> OK
```

Example: Change module's BR/EDR local name to "ABC" and enable suffix

```
<< AT+NAME=ABC,1
>> OK
```

2.1.6 Read/Write BLE Local Name

Format: AT+LENAM {=Param1{, Param2}} Param1: BLE local name (1~25 Bytes ASCII, default: FSC-BT80X-LE) Param2: MAC address suffix (0/1, default:0) (0) Disable suffix (1) Enable suffix "-XXXX" (lower 4 bytes of MAC address) after local name
Response: +LENAM=Param

2.1.7 Read/Write BLE Random Addr Configuration

Format: AT+LECFG {=Param} Param1: BLE Random addr enable(0/1, default:1) (0) Disable (1) Enable
Response: +LECFG=Param

2.1.8 Read/Write UART Baudrate

Format: AT+BAUD{=Param} Param: Baudrate (9600/19200/38400/57600/115200/230400/460800/921600, default:115200)
Response: +BAUD=Param
Description: Module's baudrate will be changed immediately after received this command

2.1.9 Read/Write UART Configuration <need reboot>

Format: AT+UARTCFG{=Param} Param: Uart Configuration(0/1, default:0) (0) Disable CTS/RTS (1) Enable CTS/RTS

Response: +UARTCFG= Param

2.1.10 Read/Write Pin Code

Format: AT+PIN{=Param}

Param: Pin code (4~15 Bytes ASCII, default:0000)

Response: +PIN=Param

Example: Read module's pin code

<< AT+PIN

>> +PIN=0000

>> OK

Example: Change module's pin code to "12345678"

<< AT+PIN=12345678

>> OK

2.1.11 Turn On/Off Secure Simple Pairing <need reboot>

Format: AT+SSP{=Param}

Param: Simple pairing (0/1, default:1)

(0) Turn off

(1) Turn on

Response: +SSP=Param

Description: Pin code input will be bypassed if simple pairing is on in pairing procedure

2.1.12 Read/Write Class Of Device <need reboot>

Format: AT+COD{=Param}

Param: Class of device (6 bytes ASCII, default:240404 Handsfree device)

Response: +COD=Param

Description: Filter nearby BR/EDR devices using COD when in scan state in A2DP master mode. Configure type of device in A2DP slave mode.

2.1.13 Read/Clear Paired Record

Format: AT+PLIST{=Param}

Param:(0/(1~8)/12 Bytes MAC address)

(0) Clear all paired record

(1~8) Clear specific paired record with index

(MAC) Clear specific paired record with MAC address

Response1: +PLIST=Param1, Param2{, Param3}

Param1: (1~8) Paired device's index

Param2: (MAC) Paired device's MAC address

Param3: (UTF8) Paired device's name

Response2: +PLIST=E: End of the paired record

Example: Read module's paired record

```
<< AT+PLIST
```

```
>> +PLIST=1,1C5CF226D773, iPhone
```

```
+PLIST=2,A0BC30075421, Samsung S8
```

```
+PLIST=E
```

```
>> OK
```

Example: Clear module's paired record

```
<< AT+PLIST=0
```

```
>> OK
```

2.1.14 Turn On/Off Throughput Mode<need reboot>

Format: AT+TPMODE{=Param}

Param: Throughput mode (0/1, default:0)

(0) Turn Off

(1) Turn On

Response: +TPMODE=Param

Description: When SPP/GATT profile connected and throughput mode is on, the AT command will be de-active, every byte received via physical UART will be sent to air, vice

visa
Example: Read current throughput mode <pre><< AT+TPMODE >> +TPMODE=1 >> OK</pre> Example: Turn off throughput mode <pre><< AT+TPMODE=0 >> OK</pre>

2.1.15 Read Module States

Format: AT+STAT
Response: +STAT=Param1, Param2, Param3, Param4, Param5, Param6, Param7, Param8 Param1: DEVSTAT Param2: SPPSTAT Param3: GATTSTAT Param4: HFPSTAT Param5: A2DPSTAT Param6: AVRCPSTAT Param7: HIDSTAT Param8: PBSTAT
Description: Refer to chapter 3 for state description, state may have different meanings according to profile selection

2.1.16 Turn On/Off Power On Auto Reconnect <need reboot>

Format: AT+AUTOCONN{=Param} Param: Option (0~15, default:3) (0) Turn Off (1-15) Turn on and reconnect times
Response: +AUTOCONN=Param
Description: Module will attempt to connect last device after power on if set

2.1.17 Scan Nearby Devices

Format: AT+SCAN {=Param} Param1:(0~1) (0) Stop scan (1) Scan nearby BR/EDR devices
Description: Refer to Chapter 3 for format description of scan result when in A2DP Slave mode. Scan and connect nearby BR/EDR devices when in A2DP master mode.

2.1.18 Auto Scan Enable

Format: AT+INQCFG {=Param} Param: (0/1, default:1) (0) Disable (1) Enable
Response: +INQCFG=Param
Description: Auto Scan and connect nearby BR/EDR devices when in A2DP master mode

2.1.19 Speaker Volume Setting

Format: AT+SPKVOL{=Param} Param: ('+'/'-')
Response: +SPKVOL =Param
Example: Read current speaker volume << AT+SPKVOL >> +SPKVOL=14 Example: Increase audio speaker volume << AT+SPKVOL=+ >> OK

2.1.20 I2S/PCM Format Configuration <need reboot>

Format: +I2SCFG{=Param}

Param: A base-10 representation of a bit field, default:0, for each bit:

BIT[0] 0: Disable I2S/PCM for audio input/output

1: Enable I2S/PCM for audio input/output

BIT[1] 0: I2S/PCM master role

1: I2S/PCM slave role

BIT[2] 0: 48000Hz sample rate

1: 44100Hz sample rate

BIT[3-4] 00: I2S Philips standard format

BIT[5-6] 00: 16-bit resolution

01: 24-bit resolution

10: 32-bit resolution

Example: Read current I2S/PCM configuration

```
<< AT+I2SCFG
```

```
>> +I2SCFG=0
```

Example: Set I2S/PCM configuration to: I2S master, 32-bit resolution, 48kHz.

I2S LRCLK: 48000Hz

I2S BCLK: 3.072MHz (48000Hz * 32bit * 2Stereo)

```
<< AT+I2SCFG=65
```

```
>> OK
```

2.1.21 SPDIF Format Configuration <need reboot>

Format: +SPDIFCFG{=Param}

Param: A base-10 representation of a bit field, default:0, for each bit:

BIT[0] 0: Disable SPDIF for audio output

1: Enable SPDIF for audio output

Example: Read current SPDIF configuration

```
<< AT+SPDIFCFG
```

```
>> +SPDIFCFG=0
```

2.1.22 Release All Connections

Format: AT+DSCA
Description: Module release all Bluetooth connections with remote device

2.1.23 Soft Reboot

Format: AT+REBOOT
Description: Module release all Bluetooth connections with remote device then reboot

2.1.24 Restore Factory Settings

Format: AT+RESTORE
Description: Module restore all factory settings then reboot

2.1.25 Close AT Air Command Mode

Format: AT+CLOSEAT
Description: Close AT Air Command Mode

2.1.26 Enable Module

Format: AT+BTEN {=Param} Param: (0~1) (0) Enter Pairing Mode (1) Quit Pairing Mode
Description: Disconnect all device connected and put module enter unconnectable and undiscoverable state .Always effective even reboot.

2.1.27 Enter Pairing Mode

Format: AT+PAIR{=Param} Param: (0~1) (0) Enter Pairing Mode (1) Quit Pairing Mode
Description: put module enter or quit connectable and discoverable state.

2.2 HFP Commands

2.2.1 Read HFP State

Format: AT+HFPSTAT
Response: +HFPSTAT=Param Param:(0~6) (0) Unsupported (1) Standby (2) Connecting (3) Connected (4) Outgoing call (5) Incoming call (6) Active call

2.2.2 Establish HFP Connection

Format: AT+HFPCONN{=Param} Param: MAC address of target device (12 Bytes ASCII)
Description: Module will reconnect to last HFP device if parameter not exist

Example: Connect to last HFP device

<< AT+HFPCONN

>> OK

Example2: Connect to specific HFP device with MAC address

<< AT+HFPCONN=1C5CF226D773

>> OK

2.2.3 Release HFP Connection

Format: AT+HFPDISC

Description: Release current HFP connection with remote device

2.2.4 Dial/Redial Phone Number

Format: AT+HFPDIAL{=Param}

Param: Phone number (1~25 Bytes ASCII)

Description: Dial specific number if parameter existence, otherwise redial

Example: Redial

<< AT+HFPDIAL

>> OK

Example: Dial number "075527924639"

<< AT+HFPDIAL=075527924639

>> OK

2.2.5 Send DTMF code

Format: AT+HFPDTMF=Param

Param: DTMF code (0~9/#/*)

Example: Send DTMF code "#" while talking

<< AT+HFPDTMF=#

>> OK

2.2.6 Pick Up Incoming Call

Format: AT+HFPANSW
Description: Pick up an incoming call

2.2.7 Reject/Hung up Call

Format: AT+HFPCHUP
Description: Reject incoming call or hung up outgoing/active call

2.2.8 Transfer Voice Audio

Format: AT+HFPADTS{=Param} Param: Transfer direction (0/1) (0) Transfer voice audio from module to remote device (1) Transfer voice audio from remote device to module
Description: Transfer voice audio between module and remote device by default if no parameter existence

2.2.9 Mute Mic

Format: AT+MUTEMIC{=Param} Param: mute mic(0/1) (0) unmute (1) mute
Description: mute mic when call active

2.3 A2DP/AVRCP Commands

2.3.1 Read A2DP State

Format: AT+A2DPSTAT
Response: +A2DPSTAT=Param Param:(0~4) (0) Unsupported (1) Standby (2) Connecting (3) Connected (4) Streaming

2.3.2 Read/Write A2DP Role

Format: AT+A2DPROLE{=Param} Param: (0/1 default:0) (0) Slave (1) Master
Description: Receive audio sink from remote device in slave role. Launch audio source to remote device in master role. Master mode default settings: 1. Enable auto scan(+INQCFG=1) Auto clear paired device list and reboot after role changed.

2.3.3 Establish A2DP Connection

Format: AT+A2DPCONN{=Param} Param: MAC address of target device (12 Bytes ASCII)
Description: Module will reconnect to last A2DP device if no parameter exist

Example: Connect to last A2DP device

<< AT+A2DPCONN

>> OK

Example2: Connect to specific A2DP device with MAC address

<< AT+A2DPCONN=1C5CF226D773

>> OK

2.3.4 Release A2DP Connection

Format: AT+A2DPDISC

Description: Release current A2DP connection with remote device

2.3.5 Read A2DP Decoder

Format: AT+A2DPDEC

Response: +A2DPDEC=Param

Param:(0~7)

(0) INVALID

(1) SBC_(decoder/encoder configurable)

(2) MP3_(decoder configurable)

(3) AAC_(decoder configurable)

(4) FASTSTREAM_(decoder/encoder configurable)

(5) APTX_(decoder/encoder configurable)

(6) APTX-LL_(decoder/encoder configurable)

(7) APTX-HD_(decoder/encoder configurable)

Description: Default support (1)SBC (5)APTX (7)APTX-HD

2.3.6 Read/Write AVRCP Configuration

Format: AT+AVRCPCFG{=Param}

Param: A base-10 representation of a bit field, default:9, for each bit:

BIT[0] Auto get track ID3 information (title, artist, album) on track changed.default:1

BIT[1-3] Auto get track state (play progress) if value > 0. default:5(second)

Example: Read AVRCP configuration

```
<<  AT+ AVRCPCFG
>>  + AVRCPCFG =9
      OK
```

Example: Get track play progress every 1 second

```
<<  AT+ AVRCPCFG =3
>>  OK
```

Description: Refer to Chapter 3 for indication format of track information and track state

2.3.7 Track Play/Pause

Format: AT+PLAYPAUSE

Description: Send play or pause command to remote media player according to current play status

2.3.8 Track Play

Format: AT+PLAY

Description: Send play command to remote media player

2.3.9 Track Pause

Format: AT+PAUSE

Description: Send pause command to remote media player

2.3.10 Track Stop

Format: AT+STOP

Description: Send stop command to remote media player

2.3.11 Track Forward

Format: AT+FORWARD
Description: Send forward command to remote media player

2.3.12 Track Backward

Format: AT+BACKWARD
Description: Send backward command to remote media player

2.4 Phonebook Access Commands

2.4.1 Download Phonebook

Format: AT+PBDOWN=Param1{, Param2} Param1: Phonebook type (0~5) (0) Phonebook (SIM Storage) (1) Phonebook (Phone Storage) (2) Received call log (3) Dialed call log (4) Missed call log (5) All call log Param2: Max items (1~65535, default:3000 for phonebook; 50 for call log)
Response: +PBDDATA=Param1<FF>Param2<FF>Param3 {<FF>Param4} Param: Refer to Chapter 3 for format description of received phonebook data

2.5 Bluetooth Serial Commands (BR/EDR SPP)

2.5.1 Read SPP State

Format: AT+SPPSTAT

Response: +SPPSTAT=Param
Param: Refer to Chapter 3 for state description

2.5.2 Establish SPP Connection

Format: AT+SPPCONN=Param
Param: MAC address of target device (12 Bytes ASCII)

Description: If target device is mobile phone, mobile phone must have initialized a RFCOMM service before this

2.5.3 Release SPP Connection

Format: AT+SPPDISC

Description: Release current SPP connection with remote device

2.5.4 Send Data Via SPP

Format: AT+SPPSEND=Param1, Param2
Param1: Payload length (1~236)
Param2: Payload (1~236Bytes UTF8)

Description: If throughput mode is on, this command is de-active

Example: Send data "1234567890" to remote device via SPP

<< AT+SPPSEND=10,1234567890

>> OK

2.6 Bluetooth Serial Commands (LE GATT)

2.6.1 Read GATT State

Format: AT+GATTSTAT
Response: +GATTSTAT=Param Param: Refer to Chapter 3 for state description

2.6.2 Release GATT Connection

Format: AT+GATTDISC
Description: Release current GATT connection with remote device

2.6.3 Send Data Via GATT

Format: AT+GATTSEND=Param1, Param2 Param1: Payload length (1~100) Param2: Payload (1~100 Bytes UTF8)
Description: If throughput mode is on, this command is de-active
Example: Send data "1234567890" to remote device via GATT << AT+GATTSEND=10,1234567890 >> OK

3. Indication Table

3.1 General Indications

3.1.1 Device State

Format: +DEVSTAT=Param

Param: A base-10 representation of a bit field, for each bit:

BIT[0] 0: Power Off; 1: Power On

BIT[1] 0: BR/EDR Non Discoverable; 1: BR/EDR Discoverable

BIT[2] 0: BLE Non Advertising; 1: BLE Advertising

BIT[3] 0: BR/EDR Non Scanning; 1: BR/EDR Scanning

BIT[4] 0: BLE Non Scanning; 1: BLE Scanning

Example: Module is power on, discoverable and advertising

>> +DEVSTAT=7

3.1.2 Scan Result

Format: +SCAN =Param1, Param2, Param3, Param4, Param5, Param6

Param1: Index (1~8)

Param2: Device address type (0~2)

(0)LE public address

(1)LE random address

(2)BR/EDR address

Param3: MAC address (12 Bytes ASCII)

Param4: RSSI (-255 ~ 0)

Param5: Size of Param6 if exist

Param6: Device Name for BR/EDR devices or advertising data for LE devices

Description: Param5/Param6 may not exist if remote device out of distance

Example: Scan BR/EDR nearby devices in 6.4s

<< AT+SCAN=1,5

>> OK

+SCAN=1,2, DC0D30000003, -32,8, Feasycom

+SCAN=2,2, DC0D30000044, -64,8, Feasycom_1234

+SCAN=3,2, DC0D30000097, -47,8, TESTHID

3.1.3 Paired Success

Format: +PAIRED=Param

Param: MAC address (12 Bytes ASCII) of current paired device

3.2 HFP Indications

3.2.1 HFP State

Format: +HFPSTAT=Param

Param:(0~6)

- (0) Unsupported
- (1) Standby
- (2) Connecting
- (3) Connected
- (4) Outgoing call
- (5) Incoming call
- (6) Active call

3.2.2 HFP Device Information

Format: +HFPDEV=Param1,Param2

Param1: (12 Bytes ASCII), Remote device's MAC address of current HFP connection

Param2: (UTF8), Remote device's name of current HFP connection

Example: HFP connect success with device

>> *+HFPDEV=1C5CF226D774,iPhone*

3.2.3 Incoming/Outgoing Call Number

Format: +HFPCID=Param

Param:(1~25 Bytes ASCII), Call number

Example: Dial number 10086

<< AT+HFPDIAL=10086

>> +HFPSTAT=4

+HFPCID=10086

+HFPCIE=China Mobile

+HFPAUDIO=1

Example: Incoming call with number 13265463800

>> +HFPSTAT=5

+HFPCID=13265463800

+HFPCIE=Jerry

+HFPAUDIO=1

3.2.4 Incoming/Outgoing Call Name

Format: +HFPCIE=Param

Param:(UTF8), Call name

Description: Not every mobile phone support this indication

3.2.5 HFP Voice Audio State

Format: +HFPAUDIO=Param

Param:(0/1)

(0) HFP voice audio disconnected, audio input/output routed to remote device

(1) HFP voice audio connected, audio input/output routed to module

3.2.6 HFP Device Network Signal Strength

Format: +HFPSIG=Param

Param:(0~5) Network signal strength of remote device

3.2.7 HFP Device Network Operator Selection

Format: +HFPNET=Param

Param:(UTF8) Network operator selection of remote device

3.2.8 HFP Device Roaming State

Format: +HFPROAM=Param
Param:(0/1) Roaming state of remote device

3.2.9 HFP Device Battery Level

Format: +HFPBATT=Param
Param:(0~5) Battery level of remote device

3.3 A2DP/AVRCP Indications

3.3.1 A2DP State

Format: +A2DPSTAT=Param
Param:(0~4)
(0) Unsupported
(1) Standby
(2) Connecting
(3) Connected
(4) Streaming

3.3.2 A2DP Device Information

Format: +A2DPDEV=Param
Param: (12 Bytes ASCII), Remote device's MAC address of current A2DP connection

3.3.3 AVRCP State

Format: +AVRCPSTAT=Param
Param:(0~3)
(0) Unsupported
(1) Standby
(2) Connecting

(3) Connected

3.3.4 Media Player State

Format: +PLAYSTAT=Param

Param:(0~4)

(0) Stopped

(1) Playing

(2) Paused

(3) Fast Forwarding

(4) Fast Rewinding

3.3.5 Media Player Play Progress

Format: +TRACKSTAT=Param1, Param2, Param3

Param1:(0~4), Media Player State

Param2:(Decimal ASCII), Elapsed time of current track in second

Param3:(Decimal ASCII), Total time of current track in second

Example: Read media player play progress every 3s

<< AT+AVRCPCFG=7

>> +TRACKSTAT=1,142000,248000

+TRACKSTAT=1,145000,248000

+TRACKSTAT=1,148000,248000

3.3.6 Media Track Information

Format: +TRACKINFO=Param1 <FF> Param2 <FF> Param3

Param1: title

Param2: artist

Param3: ablum

Example: Phone playing song "Creep-Radio Head"

>> +TRACKINFO=Creep <FF> Radiohead <FF> Pablo Honey

3.4 Phonebook Access Indications

3.4.1 PB Entries Of Remote Devices

Format: +PBCNT=Param
Param: Phonebook entries of remote device

3.4.2 Received Phonebook Data

Format1: +PBDATA=Param1 <FF> Param2 xFF \xParam3 {xFF Param4}

Param1: Type

- (0) Phonebook (SIM Storage)
- (1) Phonebook (Phone Storage)
- (2) Received call log
- (3) Dialed call log
- (4) Missed call log

Param2: (UTF8), Name

Param3: (ASCII), Number

Param4: (15 Bytes ASCII), Call time

Format:

Year(4Bytes)Month(2Bytes)Day(2Bytes) T(1Byte)Hour(2Bytes).
Minute(2Bytes)Second(2Bytes). e.g. 20161012T152826 represents
2016/10/12/15/28/26

Format2: +PBDATA=E: Download complete

Description: Call time may not exist for some mobile phones

Example: Download all phonebook

```
<< AT+PBDOWN=1
>> +PBCNT=234
    +PBDATA=1 <FF> Jack <FF> 18219146201
    +PBDATA=1 <FF> kenan <FF> 8613771972680
    .....
    +PBDATA=E
```

Example: Download 10 dialed call log

```
<< AT+PBDOWN=3,10
>> +PBDATA=3 <FF> China Mobile <FF> 10086 <FF> 20171013T103516
    +PBDATA=3 <FF> Jerry <FF> 18688967507 <FF> 20171012T152826
```

.....
+PBDATA=E

3.5 Bluetooth Serial Indications

3.5.1 SPP State

Format: +SPPSTAT=Param

Param:(0~3)

- (0) Unsupported
- (1) Standby
- (2) Connecting
- (3) Connected

3.5.2 GATT State

Format: +GATTSTAT=Param

Param:(0~3)

- (0) Unsupported
- (1) Standby
- (2) Connecting
- (3) Connected

3.5.3 SPP Device Information

Format: +SPPDEV=Param

Param: (12 Bytes ASCII), Remote device's MAC address of current SPP connection

3.5.4 GATT Device Information

Format: +GATTDEV=Param

Param: (12 Bytes ASCII), Remote device's MAC address of current GATT connection

3.5.5 SPP Received Data

Format: +SPPDATA=Param1, Param2 Param1: Payload length Param2: Payload
Description: If throughput mode is on, only Param2 will be present
Example: Received data "1234567890" from remote device via SPP << +SPPDATA=10,1234567890

3.5.6 GATT Received Data

Format: +GATTDATA=Param1, Param2 Param1: Payload length Param2: Payload
Description: If throughput mode is on, only Param2 will be present
Example: Received data "1234567890" from remote device via GATT << +GATTDATA=10,1234567890

3.6 GPIO Indications

3.6.1 LED Pin

LED0(Output)	
Low Level	Initializing
Blink in 1Hz	Ready to connecting
High Level	Connected

3.6.2 State Pin

LED1(Output)	
Low Level	SPP/GATT Disconnected

High Level

SPP/GATT Connected

深圳市飞易通科技有限公司
FEASYCOM®