




Assembly and Operating Manual

Roof fan with constant pressure control

E-RUP 190 CP
E-RUP 220 CP
E-RUP 250 CP
E-RUP 280 CP
E-RUP 355 CP
E-RUP 400 CP
E-RUP 450 CP
E-RUP 500 CP
E-RUP 560 CP
E-RUP 630 CP

English

The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.

This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Ventilair Group. It may not be reproduced or given to third parties without its consent.

The picture on the cover shows an example configuration. The product supplied may therefore differ from the illustration.

The original manual has been produced in the German language.

Information updated: print 14.07.2016
We reserve the right to make changes

Assembly and Operating Manual

Contents

1. Important information	4
1.1. Rules and regulations	4
1.2. Guarantee and liability	4
2. General safety instructions	4
2.1. Intended use	4
2.2. Improper use	4
2.3. Personnel qualifications	4
2.4. Safety instructions in this manual	5
2.5. Adhere to the following instructions	5
2.5.1. General instructions	5
2.5.2. During installation	5
2.5.3. During commissioning	5
2.5.4. During operation	6
2.5.5. During maintenance and repair	6
2.5.6. Disposal	6
3. Delivery contents	6
4. Product and Performance description	6
4.1. Device description	6
5. Transport and storage	7
6. Assembly	7
7. Electrical connection	8
8. Commissioning	9
9. Operation	9
10. Maintenance and repair	9
10.1. Important notes	9
10.2. Cleaning and care	10
11. Expansion and reconfiguration	10
12. Dismantling and disposal	10
12.1. Disposal	10
13. Troubleshooting	10
13.1. Possible operating faults.	11
14. Technical data	11
15. Wiring diagrams	13



1. Important information

This manual contains important information on the safe and appropriate assembly, transport, commissioning, operation, maintenance, disassembly and simple troubleshooting of the product.

The product has been manufactured according to the accepted rules of current technology.

There is, however, still a danger of personal injury or damage to equipment if the following general safety instructions and the warnings before the steps contained in these instructions are not complied with.

- **Read these instructions completely and thoroughly before working with the product.**
- **Keep these instructions in a location where they are accessible to all users at all times.**
- **Always include the operating instructions when you pass the product on to third parties.**

1.1. Rules and regulations

Also observe the generally applicable, legal or otherwise binding regulations of the European or national legislation and the rules for the prevention of accidents and for environmental protection applicable in your country.

1.2. Guarantee and liability

Ventilair Group products are made to the highest technical standards in accordance with the generally recognized rules of the profession. They are subject to constant quality control and meet the relevant requirements when delivered. Because the products are being constantly developed, we reserve the right to make changes to the products at any time and without prior announcement. We do not accept any liability for the correctness or completeness of this installation and operating manual. The warranty only applies to the delivered configuration. The warranty will not apply if the product is incorrectly assembled or handled or not used as intended.



2. General safety instructions

Planners, plant engineers and operators are responsible for ensuring that the product is installed and operated correctly.

- Exclusively use **Ventilair Group** Ventilatoren in good technical order and condition.
- Check the product for visible defects, for example cracks in the housing or missing rivet, screws and covers.
- Only use the product within the performance range provided in the technical data.
- Protection against contact and being sucked in and safety distances should be provided in accordance with DIN EN 13857.
- Generally prescribed electrical and mechanical protection devices are to be provided by the client.
- Safety components must not be bypassed or put out of operation.
- The product may be operated by personnel with limited physical, sensory or mental capacities only if they are supervised or have been instructed by responsible personnel.
- Children must be kept away from the product.

2.1. Intended use

The **Ventilair Group** roof fan is designed and built with consideration of the EU Low Voltage Directive 2006/95/EC. The roof fan may only be operated in compliance with the relevant conditions mentioned in the EU Low Voltage Directive.

The device may only be taken into operation when it is correctly connected.

Observe the operating conditions and performance limits specified in the technical data.

Intended use includes having read and understood these instructions, especially chapter 2 "General safety instructions".

2.2. Improper use

Any use of the product other than described in chapter "Intended use" is considered as improper.

Also note the following points, which are improper and dangerous:

- Operation in a potentially explosive atmosphere.

2.3. Personnel qualifications

Assembly, commissioning and operation, disassembly and service (including maintenance and repair) require basic mechanical and electrical knowledge, as well as knowledge of the appropriate technical terms. In order to ensure operating safety, these activities may therefore only be carried out by qualified technical personnel or a person under the direction and supervision of qualified personnel. Qualified personnel are those who can recognize possible hazards and institute the appropriate safety measures due to their professional training, knowledge, and experience, as well as their understanding of the relevant conditions pertaining to the work to be done. Qualified personnel must observe the rules relevant to the subject area.





2.4. Safety instructions in this manual

In this manual, there are safety instructions before the steps whenever there is a danger of personal injury or damage to the equipment. The measures described to avoid these hazards must be observed.

Safety instructions are set out as follows:

- | | |
|---------------------------------------|---|
| Safety sign (warning triangle) | - Draws attention to the risk |
| • Type of risk | - Identifies the type or source of the hazard. |
| » Consequences | - Describes what occurs when the safety instructions are not complied with. |
| → Precautions | - States how the hazard can be avoided. |

Safety sign (warning triangle)



Denotation

General warning!

Indicates possible hazardous situations. Failure to observe the warnings may result in personal injury and / or damage to property.



Electricity warning (hazardous voltage)!

Indicates possible hazards due to electricity. Failure to observe the warnings may result in death, injury and/or damage to property.



Important instructions follow!

Instructions for safe, optimum use of the product.



2.5. Adhere to the following instructions

2.5.1. General instructions

- Observe the provisions for accident prevention and environmental protection for the country where the product is used and at the workplace.
- Persons who assemble, operate, disassemble or maintain **Ventilair Group** products must not consume any alcohol, drugs or pharmaceuticals that may affect their ability to respond.
- Responsibilities for the operation, maintenance and regulation of the product should be clearly determined and observed so that there can be no unclear areas of responsibility with regard to safety.
- Never overload the product. Do not place anything on it.
- The warranty only applies to the delivered configuration.
- The warranty will not apply if the product is incorrectly assembled or handled or not used as intended.

2.5.2. During installation

- Disconnect all of the product's poles from the mains before installing the product or connecting or removing plugs. Make sure that the product cannot be switched back on again.
- Lay cables and lines so that they cannot be damaged and no one can trip over them.
- Before commissioning, make sure that all gaskets and seals in the plug-in connections are correctly fitted and undamaged in order to prevent fluids and foreign matter getting into the product.
- Information signs must not be changed or removed.

2.5.3. During commissioning

- Make sure that all electrical connections are either used or covered. Commission the product only if it is installed completely.

2.5.4. During operation

- In an emergency, or if there is a fault, or other irregularities, switch the equipment off and make sure it cannot be switched back on again.
- The technical data given on the rating plate must not be exceeded.

2.5.5. During maintenance and repair

- If operated correctly, **Ventilair Group** products only require a minimum amount of maintenance. Please follow all of the instructions given in section 10 in this respect.
- Make sure that no connections or components are loosened unless the device is disconnected from the mains. Make sure that the equipment cannot be switched back on again.
- Individual components must not be interchanged. For example, the components intended for one product may not be used for other products.
- After removing fastening screws (6) (see Section 1), the housing of the air handling unit can be opened for cleaning and maintenance.

2.5.6. Disposal

- Dispose the product in accordance with the currently applicable national regulations in your country.

3. Delivery contents

Included in delivery depending on model type:


- 1 x roof fan with constant pressure control
- 1 x installation and operating manual

4. Product and Performance description

The roof fan with constant pressure control is used in ventilation systems to maintain a constant set pressure level.

The constant pressure control is integrated in the air handling unit housing. It controls the fan speed to reach and keep the set-point of the differential pressure constant.

4.1. Device description



Legend

1. Cover
2. Fan housing
3. Mounting plate
4. Connection cable
5. Mounting screws

Fig. 1:
Roof fan



5. Transport and storage

Transport and storage should only be performed by specialist personnel in accordance with the installation and operating manual and regulations in force.

The following points should be noted and followed:

- Check the delivery according to the delivery note to ensure it is complete and correct and check for any damage. Any missing quantities or damage incurred during transport should be confirmed by the carrier. No liability is accepted if this is not observed.
- Avoid damage or deformation of the housing.
- The product must be stored in a dry area and protected from the weather in the original packaging. Even weatherproof modules should be covered because their weather resistance is only guaranteed after complete installation.
- Storage temperature between $-20\text{ }^{\circ}\text{C}$ and $+40\text{ }^{\circ}\text{C}$. Avoid severe temperature fluctuations.



6. Assembly

Assembly work may only be performed by specialist personnel in accordance with the installation and operating manual and the regulations and standards in force.

The following points should be noted and followed:

- Installation accessories should be provided by the client.
- Only suitable installation aids, in accordance with regulations, should be used.
- The installation should be easily accessible for maintenance and cleaning and should be easy to dismantle.
- The unit should only be installed with authorized and suitable fastening materials at all fastening points.
- Do not distort the unit when installing.
- No holes should be made in the housing, or any screws screwed into it.

- The pressure measurement hose is placed in the duct to be controlled (vacuum side). Check leak tightness while installing.

Legend

1. Cover
2. Constant pressure control
3. Mounting screws
4. Roof fan
5. Connection cable
6. Pressure measurement hose
7. Control cable
8. Roof socket (Accessories)




Fig. 2:
Assembly size E-RUP ...CP



7. Electrical connection



- **Electricity warning (hazardous voltage)!**
- » **Failure to observe the hazard may result in death, injury or damage to property.**
- **Before performing any work on conductive parts, always disconnect the unit completely from the electricity supply and make sure that it cannot be switched back on again.**

Electrical installation may only be performed by qualified electricians in accordance with the installation and operating manual and the national regulations, standards and guidelines in force:

- EN, DIN and VDE specifications, including all safety requirements.
- Technical connection conditions
- Safety at work and accident prevention requirements.

This list does not claim to be complete.

Requirements should be applied under one's own personal responsibility.

The following points should be noted and followed:

- The electrical connections must be made as shown in the corresponding wiring diagrams and terminal diagrams.
- The type of cable, size of cable and method of laying should be determined by an authorized electrician.
- Low and extra-low voltage cables should be laid separately.
- An all-pole mains disconnection device with at least 3 mm contact gap must be provided in the supply line.
- Any cable inlets that are not used must be sealed so that it is airtight.
- All cable inlets must have strain relief.
- Check all protective measures after the electrical connection work (earthing resistance, etc.).




Fig. 3:
Connection terminals in the regulator

- | | | |
|-----------|-------------------------|--|
| 6. | X3, X4 | Open: day-time operation BN / BU
Closed: night-time operation |
| 7. | X5, X6 | Open: regulator OFF BK / GY
Closed: regulator ON |
| 8. | Set-point: day | 10-990 Pa |
| 9. | Set-point: night | 10-990 Pa |

**Only potential-free contacts may be connected at terminals X3 and X4, and X5 and X6. Applying an external voltage can seriously damage the regulator.
The regulations for safety extra-low voltages must be observed.**

**The maximum pressure in a ventilation plant must not exceed 5000 Pa.
This would result in severe damage to the regulator.**



8. Commissioning

- **Electricity warning (hazardous voltage)!**
 - » **Failure to observe the hazard may result in death, injury or damage to property.**
- **Before performing any work on conductive parts, always disconnect the unit completely from the electricity supply and make sure that it cannot be switched back on again.**

Commissioning by trained technical personnel may only be performed when any risk has been ruled out. The following checks should be performed in accordance with the installation and operating manual and the regulations in force:

- Check all mechanical and electrical protection measures (e.g. earthing).
- Voltage, frequency and type of current must correspond with the rating plate.
- Check all electrical connections and wiring.
- Check any electrical, switching, safety and control devices connected.
- The pressure measuring tube will be laid in the duct.
- Setting of the desired differential pressure see 9. Operation
- After checking and connecting to the electrical grid, put the switch (2) (see Fig. 1) in position „I“. The fan is starting.

9. Operation

CAUTION! Isolate electrical installation! (see 8. Commissioning!)

Switching the regulator on and off (Control wire BK / GY)

By bridging the terminals X5 and X6 (control wire BK, GY) constant pressure control CON P1000 is switched on, by removing the bridge, it is switched off.

Turning the night mode ON and OFF (Control wire BN / BU)

By bridging the terminals X3 and X4 (control wire BN, BU) the night mode is switched on, by removing the bridge, it is switched off.

Changing day-time set-point

Adjust set-point Day with the decade switches (8).

e.g. $\begin{matrix} 3 & 2 \\ 8 & 8 \end{matrix} = 32 \times 10 = 320 \text{ Pa}$

Adjusting the night-time set-point

Adjust set-point Night with the decade switches (9).

e.g. $\begin{matrix} 4 & 1 \\ 9 & 9 \end{matrix} = 41 \times 10 = 410 \text{ Pa}$





Fig. 4: Setting of differential pressure at the decade switches

10. Maintenance and repair

10.1. Important notes

- **Electricity warning (hazardous voltage)!**
 - » **Failure to observe the hazard may result in death, injury or damage to property.**
- **Before performing any work on conductive parts, always disconnect the unit completely from the electricity supply and make sure that it cannot be switched back on again.**



Maintenance and repairs may only be performed by specialist personnel in accordance with this installation and operating manual and the regulations in force.

Do not repair defective or damaged units yourself, but report the damage or faults to the manufacturer in writing.



- **Unauthorized repairs may cause personal injury and / or damage to property, in which case the manufacturer's guarantee or warranty will not apply.**

10.2. Cleaning and care

Servicing, troubleshooting and cleaning may only be performed by specialist personnel in accordance with this installation and operating manual and the regulations in force.

If operated correctly, **Ventilair Group** products only require a small amount of maintenance.

The following work should be performed at regular intervals, in accordance with health and safety regulations:

- Check the operation of the control system and safety devices.
- Check electrical connections and wiring for damage.
- Pressure fittings and hoses should be checked regularly for impurities and, if necessary, they should be cleaned, respectively the pressure hoses should be replaced.

Before putting back into service after care and maintenance work, carry out a safety check as described in Sections 7 + 8!



11. Expansion and reconfiguration

The unit must not be reconfigured.

Ventilair Group Ventilatoren's warranty only applies for the configuration delivered. The warranty will cease to apply after any reconfiguration or expansion.

12. Dismantling and disposal



- **Risk of injury if dismantled under hazardous voltage!**
- » **If you do not switch off the voltage before starting to dismantle the unit you may injure yourself and damage the product or parts of the installation.**
- **Make sure that the relevant parts of the installation have been disconnected from the voltage supply.**

12.1. Disposal

Careless disposal of the unit may cause pollution.

Please therefore dispose of the unit in accordance with the national requirements that apply in your country.



13. Troubleshooting

Please note the following instructions:

- Proceed systematically and purposefully when troubleshooting, even when under the pressure of time. In the worst case, randomly and indiscriminately dismantling and changing settings may result in it no longer being possible to determine the original cause of the fault.
- Get an overview of the unit's operation in conjunction with the overall installation.
- Try to clarify whether the unit provided the required function in the overall installation before the fault occurred.
- Try to find any changes to the overall installation in which the unit is installed:
 - » Have the unit's operating conditions or operating range been changed?
 - » Have any changes (e.g. reconfigurations) or repairs been performed on the overall system (installation, electrics, control) or to the unit? If yes: what?
 - » Has the unit been operated correctly?
 - » How does the fault appear?
- Form a clear idea of the cause of the fault. If necessary, question the immediate operator or the installation operator.

If you have not been able to remove the fault, please contact the manufacturer. The contact address can be found at www.ventilairgroup.com or on the back cover of this operating and installation manual.

13.1. Possible operating faults.

Further faults may occur before and during operation of the unit which are not indicated by an error message on the display.

Fault	Possible causes	Fault correction
Fan does not run.	- Unit is not connected. - Unit is not in position „I“. - No electricity supply - Supply lead not connected.	- Connect unit. - Start unit. - Check fuse / power supply. - Have electrical power supply connected by an authorised electrician.
No regulation!	- Set-point value differential pressure is set to 0 Pa. - Pressure measured in the wrong place	- Adjust set-point value differential pressure. - Connect the longer pressure measurement hose to a suitable point in the ventilation duct

14. Technical data

Technical data												
Units / Model			E-RUP 190 CP	E-RUP 220 CP	E-RUP 250 CP	E-RUP 280 CP	E-RUP 355 CP	E-RUP 400 CP	E-RUP 450 CP	E-RUP 500 CP	E-RUP 560 CP	E-RUP 630 CP
Length	L	mm	337	337	337	437	598	598	670	670	931	931
Width	B	mm	388	388	388	541	745	745	860	860	1165	1165
Height	H	mm	225	225	242	249	333	333	418	418	521	521
Operating voltage U	V		230V ~	230V ~	230V ~	230V ~	230V ~	230V ~	230V ~	400V 3~	400V 3~	400V 3~
Frequency f	Hz		50	50	50	50	50	50	50	50	50	50
Power consumption P	W		99	113	179	268	165	503	509	1331	2263	2627
Current I	A		0,8	0,9	1,4	1,8	1,3	2,2	2,2	2	3,3	3,8
Max. current consumption I _{max}	A		0,8	0,9	1,5	1,9	1,4	2,3	2,3	2,1	3,5	4,0
Max. ambient temp. t _A	°C		60	60	70	55	60	50	50	50	60	55
Max. ambient temp. t _M	°C		60	60	70	55	60	50	50	50	60	55
Wiring diagrams No.			133375	133375	133375	133375	133375	133375	133375	133381	133381	133381






Fig. 5:
Dimensions of the supply air unit

Data in accordance with ErP Directive 327/2011 of the European Parliament											
Units / Model		E-RUP 190 CP	E-RUP 220 CP	E-RUP 250 CP	E-RUP 280 CP	E-RUP 355 CP	E-RUP 400 CP	E-RUP 450 CP	E-RUP 500 CP	E-RUP 560 CP	E-RUP 630 CP
ID-number		134712	134714	134716	134718	132971	132977	132983	132990	132998	133005
ErP-conformity		2015 **	2015 **	2015	2015	2015	2015	2015	2015	2015	2015
Overall efficiency	$\eta_{es} [\%]$			57,2	58,8	63,4	65,1	65,7	65,6	66,9	65,3
Measurement category				A	A	A	A	A	A	A	A
Efficiency category				statisch static	statisch static	statisch static	statisch static	statisch static	statisch static	statisch static	statisch static
Efficiency grade at optimum energy efficiency point	N			74,9	75,3	82,1	78,6	79,3	74,9	73,6	71,2
Variable speed drive				integriert integrated	integriert integrated	integriert integrated	integriert integrated	integriert integrated	integriert integrated	integriert integrated	integriert integrated
Year of manufacture		see nameplate									
Commercial registration number		K.V.K. 17110442									
Site of manufacturer		Ventilair Group, Kerver 16, 5521 DB Eersel - The Netherlands									
Nominal motor power input at optimum energy efficiency point	$P_e [kW]$			0,206	0,273	0,164	0,508	0,507	1,324	2,302	2,737
Volumetric flow at optimum energy efficiency point	$q_v [m^3/h]$			913	1208	1778	3223	3718	5886	8443	10703
Static pressure at optimum energy efficiency point	$p_{st} [Pa]$			428	443	197	360	311	519	655	604
Rotations per minute at the optimum energy efficiency point	$n [1/min]$			2828	2563	1233	1472	1225	1333	1527	1303
The specific ratio		The specific ratio is close to 1 and significantly below 1.11.									
Information on dismantling, recycling and disposal		Observe the user manual of this product.									
Optimal life		Observe the user manual of this product.									
Description of additional items used when determining the fan energy efficiency, such as ducts, that are not described in the measurement category and not supplied with the fan.		No special items have been used for determining the fan energy efficiency, except the required connection components according to the measurement category.									

* Not ErP compliant, can be sold only as a spare part for identical fans defined by the regulation (EC) 327/2011 or outside the E.C..

** Compliant to the ErP-regulation (EC) 327/2011, the power consumption at optimum efficiency is < 125W.

*** Compliant to the ErP-regulation (EC) 327/2011, the maximum power consumption of the kitchen hood is < 280W.

15. Wiring diagrams

Ventilair Group Belgium

Pieter Verhaeghestraat 8
8520 Kuurne
Tel. +32 56 36 21 20
be@ventilairgroup.com

Ventilair Group The Netherlands

Kerver 16
5521 DB Eersel
Tel. +31 497 36 00 31
nl@ventilairgroup.com

Ventilair Group France

Boulevard de la liberté 130
59000 Lille
Tel. +33 3 20 12 06 49
fr@ventilairgroup.com

The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information.

The information given does not release the user from the obligation of own judgment and verification.
It must be remembered that our products are subject to a natural process of wear and aging.

This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Ventilair Group.
It may not be reproduced or given to third parties without its consent.

Information updated:
print 14.07.2016
mdr_pb_02e_k14288

We reserve the right to make changes

Language:
English