


Mobile Lubrication Library

Volvo Excavator Centralized Lubrication System Installation



Instructions for installing a Graco automatic lubrication system on the Volvo Excavator Models EC140 to EC480



Maximum System Working Pressure: 3000 psi (20.68 MPa, 206.8 bar)



Important Safety Information

Before beginning any installation, read all warnings and instructions in all related Graco component manuals (page 25) and all related Original Equipment Manufacturer (OEM) manuals, including the vehicle's Operation and Maintenance Manual (OMM). Save all instructions.

The lubrication system design described in this manual is based upon representative equipment models. Models may vary slightly depending on series and year. Additional hoses, fittings, and valve outlet doubling plugs are supplied with the kits to modify the system based on your model's specific configuration.

 WARNING			
			
FLUID INJECTION HAZARD Fluid leaks from incorrectly installed or ruptured components, and/or failure to verify the components are properly installed and tested, can result in serious injury such as fluid spraying in the eyes or on skin and fluid injection, or equipment damage.			

NOTICE
Welding can damage electronics and the equipment's structure. To help prevent equipment damage caused by welding: <ul style="list-style-type: none"> • Disconnect the vehicle battery before welding. • Follow all welding guidelines in the OEM manuals, including the OEM service manuals. • Only weld in locations specifically approved by the OEM. Consult OEM dealership for information and recommendations. • Perform all welding in accordance with American Welding Standard (AWS) standards.

The installation instructions contained in this manual are only a recommendation for an automatic lubrication system. They are not intended to replace any instructions provided in the OEM manuals. Always refer to the OEM's manuals for details on lubrication intervals.

Table of Contents

Recommended Tools and Supplies	3
Installation	4
Zerks and Grease Point Fittings	4
System Layout and Lubrication Points	5
Volvo 21 Point Excavator	
Models EC140 to EC480	5
Volvo 21 Point Excavator	
Models EC140 to EC480 with Primary Valve	6
G3 Pump Mounting Bracket and Pressure Relief	
Valve Assembly	7
Assemble CSP Valves	7
Assemble Hose Fittings	9
Install Power Cable	11
Assemble Bracket and Install the GLC2200	
Controller (if equipped)	12
Hose Routing Guidelines	13
Wiring Guidelines	18
G3 SP Pumps with Internal Controller, Feedback and Manual Run Button Wiring Schematic	18
G3 Pro Pumps with Internal Controller and Manual Run Button Wiring Schematic	18
G3 Standard Pumps with GLC2200 External Controller, With and Without Feedback Wiring Schematic	19
Programming	20
Fill Pump, Valves, and Hoses with Grease to Purge Air	21
Fill Valves and Hoses with Grease to Purge Air	21
Test the System	22
Train the Operator	22
Check List	22
Troubleshooting	23
Valve Kits	24
Pump Kits	25
Related Manuals	25
Graco Information	26

Recommended Tools and Supplies


Tool	Size/Description	
	US	Metric
Combination wrench*	1/4 in. - 3/4 in.	6 mm - 20 mm
Socket, standard and deep well with ratchet*	3/8 in. - 3/4 in.	9.5 mm - 20 mm
Screwdrivers: standard and Phillips	1 short; 1 long	
Adjustable wrench	1 small; 1 medium	
High speed drill (corded or cordless)		
Drill bit - steel, high quality	5/16 in., 11/16 in.	
Center punch	fine point	
Pipe taper tap	1/8 in. NPT	
Hammer		
Angle grinder		
Grinding disc	Heavy grade grinding disc	
Flap disc	60 - 80 grit	
Cutoff disc	High quality disc	
Cutting blade / knife	Razor blade cutting tool	
Standard pliers	Rubber handle	
Needle nose pliers	Rubber handle	
Side cut pliers (diagonal cutters)	Rubber handle	
Slip joint pliers	Rubber handle	
Locking pliers	Small or medium	
Wire stripper / crimper	General duty wire stripper / crimper	
Soldering iron	30 watt minimum	
Electrical solder		
Soldering flux		
Shrink tubing	Various sizes	
Electrical tape	Black, small roll	
Thread sealant	Liquid thread sealant such as Loctite® 656	
Multimeter / voltmeter	Must test DC/AC/Ohms	
Electrical connectors	Ring connectors (14 -18 gauge)	
Tape measure	Standard / metric	
Primer and paint	Color should match the equipment	
Documentation / writing implements	Small note pad, pen, pencil, marker	

*Both US and Metric sizes of these tools are recommended.

Loctite® is a registered trademark of the Henkel Corporation.

All trademarks and registered trademarks used in this manual are for identification purposes only. All trademarks and registered trademarks are the property of their respective owners.

NOTE: When any of the following images are shown in the instructions it means that these components should be used during the installation to secure or protect parts.



Installation

Disconnect battery before installing the lubrication system. Inspect the machine and verify that the system design includes all lubrication points and meets the manufacturer's requirements.

Zerks and Grease Point Fittings

1. Grease all zerk fittings (FIG. 1).




FIG. 1

2. Remove all grease zerks (FIG. 2).




FIG. 2

3. The kit includes a variety of extenders, elbows, straight compression fittings, and elbow compression fittings (FIG. 3). Mix and match fittings and components supplied in the kit to replace the zerks.
4. Apply pipe sealant to fittings. To avoid contamination do not use PTFE tape on the fitting threads. If you must use PTFE tape, always ensure the first thread on the fitting is not taped and the tape is applied precisely.




FIG. 3

System Layout and Lubrication Points

Volvo 21 Point Excavator Models EC140 to EC480






FIG. 4

Lube Point	Description
A	Swing Gear
B	Boom Foot Pin
C	Boom Cylinder Foot Pin
D	Boom Cylinder Rod Pin
E	Stick Cylinder Foot Pin
F	Boom/Stick Pin
G	Stick Cylinder Rod Pin
H	Bucket Cylinder Foot Pin
I	Bucket Link Pin
J	Bucket Pin
K	H Link




Volvo 21 Point Excavator Models EC140 to EC480 with Primary Valve



ti33005a

FIG. 5

Lube Point	Description
A	Swing Gear
B	Boom Foot Pin
C	Boom Cylinder Foot Pin
D	Boom Cylinder Rod Pin
E	Stick Cylinder Foot Pin
F	Boom/Stick Pin
G	Stick Cylinder Rod Pin
H	Bucket Cylinder Foot Pin
I	Bucket Link Pin
J	Bucket Pin
K	H Link



ti33922a

G3 Pump Mounting Bracket and Pressure Relief Valve Assembly

Assemble and install pressure relief valve and pump mounting bracket on the pump (FIG. 6). See the Graco G3 pump instruction manual for additional instructions. A complete list of related Graco instruction manuals is provided on page 25.




FIG. 6

Assemble CSP Valves

The CSP primary valve assembly shown in FIG. 7 is provided as a guide. Assemble the parts as needed to best accommodate your installation. See the Graco CSP Valve instruction manual for instructions. A complete list of related Graco instruction manuals is provided on page 25.




FIG. 7


Install CSP Valves

Use supplied weld block and bolts to install the CSP valves on the equipment. Refer to FIG. 8 and FIG. 10 for recommended installation locations for the valves.

NOTE: If using a proximity switch to monitor the system:

- Route the proximity cable to the G3 SP pump mounting location.
- Route the proximity cable under the cab of the Excavator when using a GLC2200 Controller.


Recommended Installation Components



ti33001a

FIG. 8


Recommended Installation Components



ti33002a

FIG. 10


Recommended Installation Components



ti33962a

FIG. 9: Optional valve mounting if using primary valve

Recommended Installation Components



ti33963a

FIG. 11: Optional valve mounting

Assemble Hose Fittings

The hoses included in the kit require assembly prior to installation. The two piece connection fittings must be installed to the end of the hose. For detailed instructions see manual 3A3159.




FIG. 12

NOTE: Steps 1-7 refer to FIG. 12.

1. Wrap or slide the hose wrap over the end of the cut-to-length hose until the entire length of the hose is encased in the hose wrap.
2. Trim the hose wrap, leaving approximately 1 inch of the hose end unwrapped.
3. Remove the stud and sleeve from their package and disassemble the two pieces.
4. Lubricate the sleeve threads and hose inside diameter.
5. Install the sleeve onto the end of the hose by rotating it counter-clockwise until its seated.
6. Back off 1/4 turn. This will allow enough space for the stud to be connected.
7. Thread the stud clockwise into the sleeve until the sleeve nearly bottoms out against the stud shoulder.

NOTICE

Do not over-tighten the fittings during the final assembly. After the two fittings are securely connected, stop tightening. Over-tightening can damage the fittings and a new hose assembly will need to be made.

The sleeve should be firm when tightening but not difficult to install. If the sleeve is difficult to install, check the hose for proper lubrication. Reapply lubricant as needed. Installation without proper lubrication can cause damage to the core tube.

8. Repeat Steps 1-7 for all hose assemblies.

Install G3 Pump

NOTICE

Never install pump directly to the cab. Do not drill holes or weld on any part of the cab. Drilling or welding on the cab will likely void the cab certification for Roll Over Protective Structures (ROPS) and Falling Object Protective Structures (FOPS).


Install the pump in a protected area near the cab. The installation location should have ample space around the pump to allow for the hoses, cables and a relief valve.

- The deck plate that surrounds the cab is the preferred installation location (FIG. 13). The deck plate is a non-critical component and therefore drilling through the deck plate is generally acceptable by most manufacturers. However, if this location is not acceptable due to durability or space constraints, identify an alternate location around the cab such as below the ladder, in the engine compartment or on the frame.
- A custom pump mounting bracket may be required if the preferred or alternative locations (referenced above) are not acceptable for mounting the pump.

Recommended Installation Components



Option 1



Option 2




FIG. 13

Install Power Cable

1. Route the power cable from the pump through the body of the machine and under the cab to protect it from the environment and to aid in wiring into the cab. For installations utilizing a proximity switch and a GLC2200 controller, route the prox cable along the same path as the power cable (FIG. 14).

NOTE: If using a G3 SP pump, route the prox cable directly to the pump and connect it to the supplied M12 connector.

2. Route the power cable into the cab through the rubber grommet located under the floor mat (FIG. 14).

NOTE:

- If your pump uses a remote manual run button with a 5-wire CPC cable, route the cable to the manual run button. See Wiring Guidelines, page 18.
- If your pump uses a GLC2200 Controller, route the pump power cable into the cab, toward the fuse panel (FIG. 15). See Wiring Guidelines, page 18.




FIG. 14

Recommended Installation Components




FIG. 15

Recommended Installation Components



Assemble Bracket and Install the GLC2200 Controller (if equipped)

NOTE: All parts included in the mounting bracket kit may not be required for your installation. The bracket assembly shown in FIG. 16 is provided as a guide. The bracket is designed to be assembled in several configurations. Assemble the parts as needed to best accommodate your installation.




FIG. 16

1. Assemble the GLC2200 mounting bracket.

NOTE: FIG. 16 is only provided as a guide. Parts can be rotated to best suit your installation location and to provide optimal orientation for operator access inside the cab.

2. Attach the controller to the bracket using the hardware provided in the kit.
3. Install the bracket inside the cab using existing holes in the cab using the hardware provided in the kit (FIG. 17).




FIG. 17

NOTICE

Never install controller directly to the cab. Do not drill holes or weld on any part of the cab. Drilling or welding on the cab will likely void the cab certification for Roll Over Protective Structures (ROPS) and Falling Object Protective Structures (FOPS).

Hose Routing Guidelines

NOTICE

Never install valves directly to the cab. Do not drill holes or weld on any part of the cab. Drilling or welding on the cab will likely void the cab certification for Roll Over Protective Structures (ROPS) and Falling Object Protective Structures (FOPS).

- Identify the internal and external pivot points to ensure proper hose lengths are used. If hoses are too short they will bind and eventually break. If hoses are too long, they can easily get snagged on external debris or pinched in the machine.
- Follow the existing hydraulic and electrical routing. This will ensure the lines are protected and routing is consistent with the OEM's existing hydraulic hose routing.
- Utilize existing grommets, supports or cut outs in the equipment's frame for access points. Routing hoses through these areas keeps the hoses inside the machine and provides protection. It also provides a cleaner and more professional looking installation.
- Install hoses to ensure they move with the machine. Consider pivot, oscillation, extension, and pinch point areas on the equipment. Before cutting and securing hoses, have a qualified technician move the various parts of the machine to ensure proper routing is achieved.
- Connect hoses to divider valves.
- Use weld studs and p-clamps to secure hoses to the equipment. Use zip ties to the secure hoses together and to the equipment's existing hydraulic hoses.
- If possible, fill hoses with grease prior to installing on the equipment.
- See FIG. 18 through FIG. 25 for hose routing examples.




FIG. 18




FIG. 19






FIG. 20



ti33851a

FIG. 21




FIG. 22





FIG. 23





FIG. 24: Top View




FIG. 25: Bottom View

Wiring Guidelines

G3 SP Pumps with Internal Controller, Feedback and Manual Run Button Wiring Schematic (FIG. 26)




FIG. 26

G3 Pro Pumps with Internal Controller and Manual Run Button Wiring Schematic (FIG. 27)




FIG. 27

G3 Standard Pumps with GLC2200 External Controller, With and Without Feedback Wiring Schematic (FIG. 28)




FIG. 28

Programming (FIG. 30, FIG. 29, FIG. 31)

G3 SP

Example Settings:

Cycles: CY:20
Off Time: 01:00





FIG. 29

G3 Pro

Example Settings:

On Time: 04:00 Min
Off Time: 01:00 Min
Prelube: Off
or
Prelube: On - 10:00





FIG. 30

GLC2200

Example Settings:

On: Cy
Cycles: CY:20
On Time: 12:00 Min
Off Time: 01:00 Hour
Low Level: LL:02





FIG. 31

Fill Pump, Valves, and Hoses with Grease to Purge Air

NOTE: Take care to ensure dirt and/or debris do not get on the grease fitting or introduced into the system.

Fill Pump Reservoir

- Fill the pump with grease through the grease zerk using a grease gun (FIG. 32).




FIG. 32

- Do not overfill the reservoir. See fill level on the front of the pump reservoir. Grease will flow out of the reservoir overflow located on the back of the pump if the reservoir is overfilled.

Fill Valves and Hoses with Grease to Purge Air

An automatic lubrication system must be free of air in order to generate enough pressure to cycle grease through the valves.

- Connect a grease gun to the grease zerk on the CSP valves to fill them with grease (FIG. 33).




FIG. 33

- Use a waste container to capture excess grease from the grease hoses.
- Identify when hoses are filled and air is purged from the hose.

NOTE: It is helpful to have a colleague assist with this step. While one person is filling the hoses with grease the second person can monitor the grease hoses and bearing points and verify they are receiving grease and filled.

- Tighten hoses to the pump and bearing points securely.

Test the System

Before testing the system:

- Verify the pump reservoir is filled with grease.
- Verify valve and grease hoses are filled with grease and air is purged.
- Verify all supply hoses are connected securely.
- Connect power to battery. Turn key to ACC.
- Verify the G3 pump and (when used) the GLC2200 Controller have power.
- Press the Manual Run button on the G3 pump or GLC2200 Controller to run the lube system through several lube events and to ensure all lube points are receiving grease.
- While the pump is running, walk around the equipment and inspect all pump, valves, hose fittings, and bearing point connections to verify there are no leaks in the system.
- Articulate all working sections of the equipment to ensure there is sufficient hose length supplied to all lubrication points.
- Inspect the valve hose fittings and bearing point connections again, to verify there are no leaks, the hoses are secure, and that all points are receiving grease.
- Adjust fittings or connections that are leaking.
- If possible, put equipment into service and inspect the movement of the machine to verify there are no pinch points and that the equipment is functioning properly.
- After all of the testing is completed, park the equipment in a safe and secure place, disconnect the battery switch, and ensure proper parking procedures are observed.
- Complete any final housekeeping activities such as cleaning the work area, ensuring that any potential grease spills have been cleaned up, and that all waste containers are disposed of properly.
- Perform a final walk around on the machine. Take photographs as needed for documentation or reference.

Train the Operator

Train the operator on the features and day-to-day operation of the lubrication system.

Check List

- How to know when the reservoir is empty.
- What to do when the reservoir is empty.
- How to know if the lube points are getting grease.
- Lubrication system inspection.
- Clearing faults on the pump or controller.

Troubleshooting

Review the Troubleshooting Table below. For additional service, refer to the Graco Website, www.Graco.com and/or contact your Graco Distributor.

Problem	Solution
Pump does not power on.	Verify the equipment battery is connected and the key is in the ACC position. Check wiring to the G3 pump and GLC2200 Controller is correct. See Wiring, page 18.
GLC2200 Controller or G3 pump is in alarm mode. System does not operate.	Hold down the fault clear button on the GLC2200 or G3 pump for 3 seconds to clear the fault and begin the OFF Time countdown.
GLC2200 Controller is in fault mode and display shows ER:LL or G3 Pump is in fault mode and the LED next to the Low Level Fault is lit.	G3 Pump reservoir is empty and requires refilling. After reservoir is filled, press and hold the reset button on the GLC2200 or G3 pump for 3 seconds.
GLC2200 alarm sounding during machine operation.	To silence the alarm until service can be rendered, press the reset button for 1 second; then release the button. This will silence the alarm but maintain the lube system in alarm mode until serviced.
GLC2200 Controller or G3 pump in fault mode. ER:Cy displays.	The lubrication system failed to complete a lube event in the time allowed to run. Verify controller is programmed correctly. In colder temperatures, it may be necessary to increase standard run time to complete the lube cycle.
	If the first solution does not correct the problem, run a manual cycle and check the pump relief valve for discharged grease. The grease pressure is at 4000 psi (27.58 MPa, 275.8 bar) when the relief valve discharges. If grease has discharged from the relief valve, a bearing may have stopped taking grease, a hose may be compromised, or the CSP valve may be clogged.
	Inspect CSP divider valve hoses for damage and/or leaks. Replace hoses if needed. If hoses are not compromised, use a manual grease gun to verify the valves are accepting grease.
	If the CSP valve fails to accept grease; the valve may be clogged and need to be replaced or the bearing point is refusing to accept grease. Repeat steps for remaining CSP valves until the blockage is found.
The CSP valves refuse to accept grease.	Verify that the CSP valves have not been over-torqued to their required specification. If they have been over-torqued, valve performance can be compromised. Adjust the valve assembly.
Bearings are not receiving enough grease.	Reduce the OFF Time on the controller. This will increase the frequency of the lube events and increase the amount of grease the bearings receive throughout the day. Alternative setting = 45 minutes = 30% increase, 40 minutes = 50% increase, 30 minutes = 100% increase.
GLC2200 Controller or G3 pump will not run programmed time.	Verify you are programming the hours, minutes, and second correctly. Refer to the GLC2200 or G3 pump instruction manual.
There is a broken hose in the lubrication system.	Replace broken hose. See Assemble Hose Fittings instructions on page 7. The original kit included extra hose and fittings. If you do not have spare hose and fittings to assemble a replacement hose, contact your Graco Distributor for assistance with ordering new parts.

Valve Kits

Description	Models/Quantity	
	26C125	26C128
8.6 mm hose, 100 meters	1	1
9 mm hose wrap, 10 meters	5	5
Hose stud sleeve	50	56
Hose stud straight	30	36
Hose stud 90-degree	20	20
1/8 BSPT x 6 mm compression fitting, straight	25	30
1/8 BSPT x 6 mm compression fitting, 90-degree	25	25
1/8 NPT x 6 mm compression fitting, straight	4	4
1/8 NPT x 6 mm compression fitting, 90-degree	4	4
1/8 BSPT x 1/8 90-degree elbow	15	15
1/8 BSPT x 1/8 extension	15	15
1/4 NPT compression	NA	1
1/4 NPT short street elbow	NA	1
CSP8 with indicator	NA	1
CSP12 w/indicator	1	1
CSP14 w/indicator	1	1
CSP outlet 8.6 mm compression fitting	26	30
CSP doubling plug	20	20
CSP mounting kit	3	3
P-clamp weld studs	10	10
P-clamps, small	10	10
P-clamps, large	5	5
1/4-20 nuts	15	15
Zip ties, 100 count	1	1
Coupling, Anchor STR 1/8	2	2
CSP inlet tee	2	3
Grease zerk	2	3
Grease zerk cover	2	3
Anchor bracket	1	1
4000 psi relief valve	1	NA
1/4 NPT x 1/8 NPT relief valve bushing	1	NA
Relief valve fitting	1	NA
Pump element	1	NA

Pump Kits

G3 Standard: 26C130, 26C131, 26C132;

G3 Pro: 26C133, 26C134, 26C135;

G3 SP: 26C136, 26C137, 26C138

Description	Models/Quantity		
	G3 Standard	G3 Pro	G3SP
G3 Pump, 24VDC/CPC5/LL	1	1	1
GLC2200 controller	1	NA	NA
GLC2200 10 ft. cable	1	NA	NA
GLC2200 mounting bracket	1	NA	NA
Manual run button	NA	1	1
Add-a-fuse ATC	1	1	1
5-Amp fuse ATC	1	1	1
Add-a-fuse ATM	1	1	1
5-Amp fuse ATM	1	1	1
Branch tee outlet fitting, 1/8	1	1	1
Reducer bushing 1/4 x 1/8	1	1	1
4000 psi relief valve	1	1	1
Pump mounting bracket	1	1	1
CSP proximity switch	1	NA	1
Wiring harness, M12 (f) to bare wire	1	NA	1
Eurofast connector, 4-pin	NA	NA	1
Large ground ring connector	2	2	2
Small ground ring connector	2	2	2
Pump mounting bolts	4	4	4
Pump mounting nuts	4	4	4
Pump mounting washers	4	4	4
17V033 - 10 feet extra wire (power/ground)	NA	1	1

Related Manuals

Manual No.	Title
332291	G3 Standard Pump
332298	G3 Pro Pump
3A4676	G3 SP Pump
3A5028	G3 Illuminated Remote Run Button
3A2960	GLC2200 Controller
3A3159	Instructions for Installing a Field Attachable/Reusable Hose Fitting
3A3995	CSP Valve

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

For patent information, see www.graco.com/patents.

Original information. This manual contains English. MM 333546

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2018, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com

April 2019