SECTION 501-00: Body System — General Information SPECIFICATIONS

General Specifications

ltem	Specification
Sealers	
HB Fuller E709	ESD-M4G162-A
3M Strip-Caulk-Black 051135-08578	ESB-M4G32-A
Silicone Gasket and Sealant F7AZ-19554-EA	WSK-M2G343-A4
Adhesives	
Weather Strip Adhesive E8AZ-19552-A	ESB-M2G14-A
3M Scotch CA Tape F67B-78311A40-AA	
Lubricants	
Silicone Lubricant COAZ-19553-AA	ESR-M13P4-A

SECTION 501-00: Body System — General Information DESCRIPTION AND OPERATION 2000 Explorer/Mountaineer Workshop Manual

Body

The body is constructed of a lightweight all-steel welded material. The body is bolted to a full frame.

Insulation is installed:

- Under the hood.
- Above and below the instrument panel.
- At the cowl side panels.
- Over the front and rear tunnel.
- Over the front and rear floor pans.
- Inside the B, C, and D pillars.

Body Sealer Types and Applications

HB Fuller E709

HB Fuller E709:

- Does not run.
- Is fast drying.
- Remains semi-elastic.
- Can be used for seam sealing in such areas as the floorpan, wheelhouse, bulkhead, door openings, and drip rails.
- Can be used to seal outside moulding clip holes.
- Meets Ford Specification ESD-M4G162-A.

3M Strip-Caulk-Black 051135-08578

3M Strip-Caulk-Black 051135-08578:

- Has a plastic base with a filler.
- Is heavy-bodied.
- Is used on spot-weld holes, around mounting clips, and between surfaces not sealed by a gasket.
- Meets Ford Specification ESB-M4G32-A.

Weatherstrip Adhesive

Weatherstrip Adhesive E8AZ-19552-A or equivalent meeting Ford specification ESB-M2G14-A is designed to hold weatherstripping to the body.

Silicone Lubricant

Silicone Lubricant COAZ-19553-AA meeting Ford specification ESR-M13P4-A :

- Is used on the door and window weatherstrips.
- Should be applied at regular lubrication intervals.
- Makes doors easier to close.
- Reduces weatherstrip squeaks.
- Reduces weatherstrip wear.
- Helps retain door-window alignment by reducing friction between the glass and the rubber weatherstrips.

Body System

Inspection and Verification

Leaks

NOTE: Trim will reveal the location of most leaks.

- 1. Remove any trim or carpet in the general area of the leak.
- 2. Road test or water test the vehicle.
- 3. Inspect for a dust pattern around the area in question.
- 4. Inspect for water paths near and above the area in question.
- 5. Some leaks can be located by placing bright light under the vehicle, removing any necessary trim or carpet, and inspecting the interior of the body at joints and weld lines.

Noise

Wind noise, rattles, and their sources are detected by driving the vehicle at highway speeds. The vehicle should be driven in four different directions, with all the windows closed, the radio off, the blower motor off, and all the ventilation ducts open.

Most wind noise leaks will occur at the door and window seals or at the sheet metal joints in the door or the door opening.

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action
 Dust/Water Leaks 	 Body sealer missing. Opening in weldings or body joints. Components not fully installed. Components missing. Components damaged. 	• REMOVE trim. CHECK for leaks and SEAL with appropriate sealer. ROAD TEST or WATER TEST for leaks. RECHECK trim for leaks; USE light under vehicle with trim removed. CHECK interior of body at joints and weld lines.
 Dust Leak at Right Rear Quarter Panel 	 Tape under trim panel is loose. 	 REPAIR and/or REPLACE tape as necessary. TEST the system for normal operation.
Dust/Water	Missing or damaged	CHECK plugs for proper

Leaks at Floor Pan and Grommets	plugs and/or grommets.	installation. REPLACE if necessary. TEST the system for normal operation.
 Door Drain Holes Collecting Water 	 Holes clogged with mud or road tar. 	 CLEAN drain holes of dirt and foreign material with a punch or screwdriver. CHECK drain holes regularly. TEST the system for normal operation.
 Wind Noise 	 Leaks at door and window seals or sheet metal joints in dorrs or door openings. 	 SEAL leaks with Silicone Gasket and Sealant F7AZ-19554-EA or equivalent meeting Ford Specification WSK-M2G343-A4.
	 Loose/misaligned weatherstrip. 	 Reattach weatherstrip. Replace any damaged pin-type retainers. Use weatherstrip adjesive E8AZ- 19552-A or equivalent meeting Ford Specification ESB-M2G14-A as necessary.
	Poor Door Fit.	 Adjust the striker or hinges as necessary. For additional information on the hinge adjustment, refer to <u>Section 501-</u> 03. Check for acceptable door efforts after repair.
Rattles	 Loose objects in door wells, pillars, and quarter panels. 	 CHECK doors by carefully STRIKING underside of door with a rubber mallet. LISTEN for loose objects in door. REPAIR. TIGHTEN body bolts and screws.
	 Misalignment (if tightening bolts does not eliminate rattle). 	• REFER to <u>Section 501-03</u> .
	 Weatherstripping and anti-squeak material. 	 APPLY additional sealer; INSTALL in proper location to eliminate rattle. TEST the system for normal operation.

Torque Specifications

Description	Nm	lb-ft	lb-in
Cowl Top Vent Panel to Cowl Screw	2.5-2.9	—	22.3-25.9
Fender to Front Fender Radiator Support Brace Bolt	10-14	8-10	
Fender to Radiator Grille Opening Panel Nut	6-8	—	54-70
Front Fender to Front Fender Apron Screws	10-14	8-10	
Fender to Rocker Panel Bolts	10-14	8-10	
Radiator Grille Opening Panel to Fender Bolt	6-8	—	54-70
Radiator Grille Opening Panel to Hood Latch Support Bolt	6-8	—	54-70
Radiator Grille Opening Panel Support Bracket Bolts		—	54-70
Speed Control Servo Bracket Bolt		7-9	
Top Fender to Inner Fender Bolts		8-10	_

SECTION 501-02: Front End Body Panels DESCRIPTION AND OPERATION

Front End Body Panels

The front end body panel components consist of:

- the hood
- the hood hinges
- the cowl top vent panels
- the front fenders
- the front fender apron (16054)
- the radiator grille opening panel reinforcement
- the radiator opening cover
- the hood latch support
- the radiator air deflector
- the front bumper
- the radiator grille
- the radiator upper sight shield

2000 Explorer/Mountaineer Workshop Manual

Panel — Cowl Top Vent

Removal

- 1. Disconnect the LH windshield washer hose from inside the engine compartment.
- 2. Remove the wiper arms.
 - 1. Slide the clip to clear the wiper arm drive mechanism.
 - 2. Pull the wiper arm from the wiper arm drive mechanism.



3. Remove the cowl top vent panel-to-cowl screw.



4. Remove the LH cowl top vent panel by pulling up on the LH cowl top vent panel to disengage the clips.



5. Remove the RH cowl top vent panel by pulling up on the RH cowl top vent panel to disengage the clips and disconnect the right washer hose.



Installation

1. To install, reverse the removal procedure.



Fender — Front

Removal

- 1. Remove the grille opening panel reinforcement. For additional information, refer to <u>Grille Opening</u> <u>Panel Reinforcement</u>.
- 2. Remove the front bumper (17757). For additional information, refer to Section 501-19.
- 3. Remove the front panel of the rocker panel trim or, if equipped, the running board(s).
- 4. Remove the front wheel and tire assembly. For additional information, refer to Section 204-04.
- 5. Remove the front fender apron (16054).
 - 1. Remove the screws.
 - 2. Remove the bolts.



6. Remove the lower fender to rocker panel bolts and spacers.



7. **NOTE:** The front door must be open to gain access to the fender bolt.

Remove the fender bolt.



8. Remove the fender to front fender radiator support brace bolt.



- 9. If removing the RH front fender, position the speed control servo (9C735) aside.
 - 1. Remove the bolt.
 - 2. Position the speed control servo aside.



- 10. If removing the RH front fender, remove the antenna. For additional information, refer to <u>Section 415-02</u>.
- 11. Remove the front fender (16005).
 - 1. Remove the top fender to inner fender bolts.
 - 2. Remove the front fender.



Installation

- 1. Install the front fender.
 - 1. Install the front fender.
 - 2. Install the top fender to inner fender bolts.



- 2. If installing the RH front fender, install the antenna. For additional information, refer to <u>Section 415-</u><u>02</u>.
- 3. If installing the RH front fender, install the speed control servo bracket.
 - 1. Position the servo bracket.
 - 2. Install the bolt.



4. Install the fender to front fender radiator support brace bolt.



5. **NOTE:** The front door must be open to gain access to the bolt.

Install the top fender to inner fender bolt.



6. Install the fender to rocker panel bolts and spacers.



- 7. Install the front fender apron.
 - 1. Install the front fender to front fender apron screws.
 - 2. Install the top fender to inner fender bolts.



- 8. Install the front wheel and tire assembly. For additional information, refer to Section 204-04.
- 9. Install the front panel of the rocker panel trim or, if equipped, the running board(s).
- 10. Install the front bumper. For additional information, refer to <u>Section 501-19</u>.
- 11. Install the grille opening panel reinforcement. For additional information, refer to <u>Grille Opening Panel</u> <u>Reinforcement</u>.

Grille Opening Panel Reinforcement

Removal

NOTE: Mountaineer shown, Explorer similar.

- 1. Remove the radiator grille (8200). For additional information, refer to Section 501-08.
- 2. Remove the radiator opening cover (8C299).
 - Remove the seven pin-type retainers.



- 3. Position the two radiator grille splash shields aside.
 - Remove the two pin-type retainers.



4. Disconnect the two headlamp electrical connectors.



5. Remove the fender to radiator grille opening panel nut.



6. Remove the four radiator grille opening panel support bracket bolts.



7. Remove the radiator grille opening panel to hood latch support bolt.



8. NOTE: If necessary, transfer parts to the new component.

- Remove the radiator grille opening panel.1. Remove the radiator grille opening panel to fender bolts.2. Remove the grille opening panel.



Installation

1. To install, reverse the removal procedure.







General Specifications

Item	Specification
Door clearance; front and rear edge	3.0-7.0 mm (0.118-0.275in) parallel top to bottom within 1.0 mm (0.04 in)
Door clearance; top of door to roof	3.0-7.0 mm (0.118-0.275in) parallel top to bottom within 2.0 mm (0.08 in)
Door flushness; front door to front fender, rear door to front door	-1.0-0.00mm (-0.04-0.00in)

Torque Specifications

Description	Nm	lb-ft	lb-in
Battery cable bolts	7-10		62-89
Chassis wire harness to front door bolt	2.7-3.7		24-33
Door hinge to body bolts/nuts	30	22	—
Hinge to door bolts	30	22	—
Liftgate hinge to liftgate bolts	17-27	13-20	_
Liftgate hinge to body bolt and nut	26-34	19-24	_

Body Closures

Body Closures



Page 2 of 2

ltem	Part Number	Description
1	20124	Front Door
2	20708	Front Door Opening Weatherstrip
3	22800	Front Door Upper Hinge
4	22810	Front Door Lower Hinge
5	24630	Rear Door
6	—	Rear Door Upper Hinge
7	26802	Rear Door Lower Hinge
8	—	Rear Door Opening Weatherstrip
9	40010	Liftgate
10	42900	Liftgate Hinge
11	404A06	Liftgate Weatherstrip

Hinge Adjustment — Front Door, Horizontal and Verticle

- 1. Mark the position of the front door hinges to use as a reference point.
- 2. Loosen the front door hinge to front door bolts just enough to permit movement of the door .



3. Adjust the front door alignment to specification.



4. Tighten the front door hinge to front door bolts.



Hinge Adjustment — Front Door, Fore and Aft

NOTE: Check the rear door hinge adjustment before adjusting the front door hinge.

- 1. Remove the cowl side trim panel. For additional information, refer to <u>Section 501-05</u>.
- 2. Position the electrical connector mounting bracket aside.
 - 1. Remove the pin-type retainer.
 - 2. Position the electrical connector mounting bracket aside.



- 3. Mark the position of the front door hinges to use as a reference point.
- 4. **NOTE:** Position the front door to gain access to the bolts.

Loosen the two front door hinge to body bolts and nuts just enough to permit movement of the door.



5. Adjust the front door alignment to specification.



6. Tighten the front door hinge to body bolts.



- Position the electrical connector mounting bracket.
 Position the electrical connector mounting bracket.
 - 2. Install the pin-type retainer.



8. Install the cowl side trim panel. For additional information, refer to Section 501-05.

Hinge Adjustment — Door, Rear

- 1. Remove the front seat safety belt retractor. For additional information, refer to Section 501-20A.
- 2. Mark the position of the rear door hinges to use as a reference point.
- 3. Loosen the rear door hinge to body nuts just enough to permit movement of the door.



4. Adjust the rear door alignment to specification.



- 5. Tighten the rear door hinge to body nuts.
- 6. Check the front door hinge adjustment. For additional information, refer to <u>Hinge Adjustment—Front</u> <u>Door, Fore and Aft</u> or <u>Hinge Adjustment—Front Door, Horizontal and Verticle</u>.
- 7. Install the front seat safety belt retractor. For additional information, refer to Section 501-20A.

Hinge Adjustment —Rear Door, Horizontal and Vertical

- 1. Mark the position of the rear door hinge to use as a reference.
- 2. Loosen the rear door hinge to rear door bolts just enough to permit movement of the door.



3. Adjust the rear door alignment to specification and flush to adjacent panels.



4. Tighten the rear door hinge to rear door bolts.

SECTION 501-05: Interior Trim and Ornamentation SPECIFICATIONS

2000 Explorer/Mountaineer Workshop Manual

Torque Specifications

Description	Nm	lb-ft	lb-in
Battery ground cable	7-10	5-7	—
Coat hook screw	1.4-2.0		12-18
Door trim panel screws	1.4-2.0		12-18
Liftgate handle screws 1			9-11
Liftgate trim panel screw 2.3-3.3			20-29
Quarter trim panel screws 1.0-1.5 —			9-13
Quarter window latch screws 9 -			80
Safety belt guide bolt	34-46	25.1-33.9	_
Safety belt anchor bolts	30-40	23-29	—
Safety belt anchor nuts	34-46	24.9-33.8	_

SECTION 501-05: Interior Trim and Ornamentation DESCRIPTION AND OPERATION

Interior Trim

Interior Trim Components



Page 2 of 2

Item	Part Number	Description
1	03598	Windshield Side Garnish Moulding
2	<u> </u>	B-Pillar Trim Panel
3	51968	Roof Trim Panel
4	13000	Floor Carpet
5	—	Carpet Assembly, Rear Floor
6	31012	Quarter Trim Panel
7	13144	Liftgate Scuff Plate
8	46404	Liftgate Door Trim Panel
9	27406	Rear Door Trim Panel
10	13208	Front Door Scuff Plate
11	23942	Front Door Trim Panel
12	02345	Cowl Side Trim Panel, RH and LH
SECTION 501-05: Interior Trim and Ornamentation REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Trim Panel — B-Pillar

Special Tool(s)

5TT181-A	Safety Belt Bolt Bit 501-010 (T77L-2100-A)
ST1490-A	Windshield and Molding/Trim Removal Kit or equivalent 107-R0401

Removal

1. Remove the windshield side garnish moulding (03598).



- 2. Remove the front door scuff plate (13208).
 - 1. Starting at one end and working along the front door scuff plate, use Windshield and Molding/Trim Removal Kit to remove the front door scuff plate.
 - 2. Remove the front door scuff plate from the B-pillar.



3. Remove the (A) screw and the (B) coat hook.



4. Open the front safety belt guide bolt cover.



5. Using special tool, remove the front safety belt guide bolt.



6. Use Safety Belt Bolt Bit to remove the front safety belt anchor bolt.



- Remove the B-pillar trim panel.
 Remove the pin-type retainer.
 Feed the safety belt webbing through the opening.
 Remove the B-pillar trim panel.



1. To install, reverse the removal procedure.







SECTION 501-05: Interior Trim and Ornamentation REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Trim Panel —Cowl Side

Special Tool(s)



Removal

NOTE: 4-door shown, 2-door similar.

- 1. Remove the front door scuff plate (13208).
 - 1. Starting at one end and working along the front door scuff plate, use Windshield and Molding/Trim Removal Kit to remove the front door scuff plate.
 - 2. Remove the front door scuff plate from the B-pillar.



2. Remove the cowl side trim panel (02345) by pulling outward to disengage the pin-type retainers.



Installation

1. To install, reverse the removal procedure.

SECTION 501-05: Interior Trim and Ornamentation REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Trim Panel — Front Door

Removal

NOTE: High series shown, low series similar.

NOTE: The window must be completely down to remove the front door trim panel.

- 1. On high series front door trim panel, disconnect the battery ground cable (14301).
- 2. Remove the screws.



3. Remove the inside door handle cup (22634).



- 4. On low series front door trim panel, remove the screw and the window regulator handle.
- 5. Start in a lower corner and work around the panel and separate the front door trim panel (23942) from the front door (20124) to disengage the pin-type retainers.



6. Lift the front door trim panel to disengage the top lip from the weatherstrip.



- 7. Position the front door trim panel aside.
- 8. Separate the power window switch finish panel from the door trim panel.
 - Release the locking tabs.



9. If equipped, remove the courtesy lamp bulb from the lens and remove the front door trim panel.



1. **NOTE:** When the battery (10653) is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 mi) or more to relearn the strategy.

To install, reverse the removal procedure.

SECTION 501-05: Interior Trim and Ornamentation REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Trim Panel —Liftgate Door

Special Tool(s)



Windshield and Molding/Trim Removal Kit or equivalent 107-R0401

Removal

1. Remove the (A) liftgate handle to liftgate screws and the (B) liftgate handle.



2. Remove the liftgate trim panel screw access plug.



3. Remove the screw.



- 4. Remove the liftgate door trim panel.
 - 1. Use Windshield and Molding/Trim Removal Kit to remove the liftgate door trim panel from the liftgate window opening.
 - 2. Push the liftgate door trim panel toward the top of the liftgate and remove the liftgate trim panel.



1. To install, reverse the removal procedure.







Trim Panel —Quarter, Four Door

Special Tool(s)

5T1181-A	Safety Belt Bolt Bit 501-010 (T77L-2100-A)
ST1490-A	Windshield and Molding/Trim Removal Kit or equivalent 107-R0401

Removal

1. If equipped, remove the retractable cargo cover.



- 2. Remove the liftgate scuff plate (13144).
 - 1. Starting at either end and working along the liftgate scuff plate, use Windshield and Molding/Trim Removal Kit to remove the scuff plate.
 - 2. Remove the liftgate scuff plate.



- 3. If equipped, remove the rear power lock switch assembly.
 - Disconnect the electrical connector.



- 4. Remove the B-pillar trim panel. For additional information, refer to Trim Panel-B-Pillar.
- 5. Remove the three rear quarter trim panel screws.
 - Position the carpet aside to gain access to the screws.



6. Remove the rear safety belt anchor nut.



7. Open the rear safety belt guide bolt cover.



8. Using the special tool, remove the rear safety belt guide bolt.



- Remove the quarter trim panel (31012).
 1. Remove the pin-type retainers.

 - Feed the safety belt webbing through the opening in the quarter trim panel.
 Remove the quarter trim panel.



- 1. Install the quarter trim panel.
 - Feed the safety belt webbing through the opening in the quarter trim panel.
 Position the quarter trim panel.

 - 3. Install the pin-type retainers.



2. Using the special tool, install the rear safety belt guide bolt.



3. Close the rear safety belt guide bolt cover



4. Install the rear safety belt anchor nut.



5. Install the three rear quarter trim panel screws.



- 6. Install the B-pillar trim panel. For additional information, refer to Trim Panel—B-Pillar.
- 7. Install the liftgate scuff plate.
 - 1. Position the liftgate scuff plate.
 - 2. Start at either end and work along the liftgate scuff plate, pushing it into the floor panel.



8. If equipped, install the retractable cargo cover.



Trim Panel —Rear Door

Removal

NOTE: High series shown, low series similar.

NOTE: The window glass must be completely down to remove the rear door trim panel.

1. Remove the screws.



2. Remove the inside door handle cup.



- 3. On low series rear door trim panel, remove the window regulator handle.
 - Remove the screw.
- 4. Start in a lower corner and work around the panel and separate the rear door trim panel from the rear door to disengage the pin-type retainers.



5. Remove the rear door trim panel by lifting to disengage the top lip from the weatherstrip.



6. Turn the rear door trim panel over.



- Disconnect the power window switch electrical connector.
 Remove the screws.

 - 2. Disconnect the electrical connector.



1. To install, reverse the removal procedure.

Trim Panel —Quarter, Two Door

Special Tool(s)

STI181-A	Safety Belt Bolt Bit 501-010 (T77L-2100-A)
STI 490-A	Windshield and Molding/Trim Removal Kit or equivalent 107-R0401

Removal

1. Remove the windshield side garnish moulding (03598).



- 2. Remove the front door scuff plate.
- 3. Remove the front safety belt guide bolt cover.



4. Using the special tool, remove the front safety belt guide bolt.



5. Using the special tool, remove the front safety belt anchor bolt.



6. If equipped, remove the retractable cargo cover.



- 7. Remove the liftgate scuff plate (13144).
 - 1. Starting at either end and working along the liftgate scuff plate, use Windshield and Molding/Trim Removal Kit to remove the scuff plate.
 - 2. Remove the liftgate scuff plate.



- 8. Fold the rear seat into the load floor position.
- 9. Using the special tool, remove the rear safety belt guide bolt.
 - Position the rear safety belt guide cover aside.



10. Using the special tool, remove the rear safety belt anchor bolt.



11. Remove the two rear quarter window latch screws.



- 12. Remove the coat hook.
 - 1. Remove the screw.
 - 2. Remove the coat hook.



- 13. Remove the quarter trim panel front screw.
 - Position the carpet aside to gain access to the screw.



- 14. Remove the three quarter trim panel rear screws.
 - Position the carpet aside to gain access to the screws.



- 15. If equipped, remove the rear power lock switch assembly.
 - Disconnect the electrical connector.



- 16. Remove the quarter trim panel.1. Remove the eight pin-type retainers.
 - 2. Feed the safety belt webbing through the opening in the quarter trim panel.
 - 3. Remove the quarter trim panel.



1. To install, reverse the removal procedure.







SECTION 501-05: Interior Trim and Ornamentation REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Headliner

Removal

- 1. Disconnect the battery ground cable (14301).
- 2. Remove the quarter trim panel (31012) . For additional information, refer to <u>Trim Panel—Quarter,</u> <u>Four Door</u> or <u>Trim Panel—Quarter, Two Door</u>.
- 3. If equipped, remove the overhead console. For additional information, refer to Section 501-12.
- 4. Remove the interior lamps. For additional information, refer to Section 417-02.
- 5. Remove the sun visors.
 - 1. Remove the six screws.
 - 2. Remove the sun visors.
 - If equipped, disconnect the electrical connectors.



- 6. Remove the sun visor brackets.
 - 1. Remove the two screws.
 - 2. Remove the sun visor brackets.



7. Remove the assist handle bolt covers.



- 8. Remove the assist handles.
 - 1. Remove the bolts.
 - 2. Remove the assist handles.



9. Remove the headliner pin-type retainers.



- 10. Remove the six remaining pin-type retainers.
- 11. Remove the headliner.

Installation

1. **NOTE:** When the battery (10653) is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 mi) or more to relearn the strategy.

To install, reverse the removal procedure.

SECTION 501-08: Exterior Trim and Ornamentation SPECIFICATIONS

2000 Explorer/Mountaineer Workshop Manual

Torque Specifications

Description	Nm	lb-in
Radiator Grille Screws	1.6-2.2	14-20
Front Upper Sight Shield Bolts	6-8	54-70
Running Board Bolts	9-13	81-115
Running Board Nuts	2.5-3.5	23-30
Running Board Screws	0.9-1.3	8-11

SECTION 501-08: Exterior Trim and Ornamentation DESCRIPTION AND OPERATION

Exterior Trim and Ornamentation

The exterior trim components for the Explorer consist of the following:

- luggage rack
- side moulding
- side trim moulding
- running boards
- rear emblem
- rear liftgate trim moulding
- radiator grille
- trim level emblem
- optional step bar

The exterior trim components for the Mountaineer consist of the following:

- luggage rack
- side moulding
- side trim moulding
- trim level emblem
- rear emblem
- radiator grille
- running boards
- rear liftgate trim moulding

Radiator Grille

REMOVAL AND INSTALLATION

Removal

NOTE: Explorer shown; Mountaineer similar.

- 1. Raise and support the hood (16612).
- 2. Remove the front upper radiator upper sight shield (8C291).
 - 1. Remove the bolts.
 - 2. Remove the pin type retainers.
 - 3. Remove the radiator upper sight shield.



- 3. Remove the parking lamps; for additional information refer to Section 417-01.
- 4. Remove the radiator grille (8200).
 - 1. Remove the screws.
 - 2. Release the clips.
 - 3. Remove the radiator grille.



Installation

NOTE: Explorer shown; Mountaineer similar.

1. **NOTE:** Insert the locating tabs before installing the radiator grille screws.

To install, reverse the removal procedure.



SECTION 501-09: Rear View Mirrors SPECIFICATIONS

2000 Explorer/Mountaineer Workshop Manual

Torque Specifications

Description	Nm	lb-in
Battery Ground Cable Screw	7-10	62-89
Outside Rear View Mirror Nuts	6-8	54-71
Rear View Mirrors

Rear View Mirror Components



Outside Rear View Mirrors

Both LH and RH outside rear view mirrors are controlled and adjusted from the outside rear view mirror switch. The outside rear view mirrors can also be folded in or manually adjusted. The outside rear view mirrors can also house the optional ground illumination lamps. The mirrors can have the optional heated function when the heated back window glass is actuated.

The heated power mirror contains a grid that is provided power by the rear window defrost relay.

Pressing the rear window defrost switch begins the ten-minute cycle and activates the rear window defrost relay.

Pressing the rear window defrost switch at anytime during the timing cycle will deactivate the function and deactivate the rear window defrost relay. If the switch is NOT pressed during the ten-minute cycle, power remains applied to the rear window defrost relay until the timer interval has expired.

Inside Rear View Mirror — Electrochromic

The electrochromic inside rear view mirror has three features:

- Automatic dimming.
- Autolamp delay; refer to Section 417-01.
- Automatic lock-in normal view state, when vehicle is placed in REVERSE (R).

The automatic dimming feature darkens the inside rear view mirror whenever the front ambient light sensor detects low outside light and glare reaches the light sensor (photocell), located inside the mirror. The electrochromic inside rear view mirror starts to return to the normal view once glare goes away.

SECTION 501-09: Rear View Mirrors DIAGNOSIS AND TESTING 2000 Explorer/Mountaineer Workshop Manual

Rear View Mirrors

Refer to Wiring Diagrams Cell <u>124</u>, Power Mirrors for schematic and connector information.

Refer to Wiring Diagrams Cell <u>125</u>, Automatic Day/Night Mirrors for schematic and connector information.

Refer to Wiring Diagrams Cell <u>56</u>, Rear Window Defrost/Mirror Defrost for schematic and connector information.

Special Tool(s)



Inspection and Verification

- 1. Verify the customer concern by operating the outside/inside rear view mirrors.
- 2. Visually inspect for the following obvious signs of mechanical and electrical damage.

Visual Inspection Chart

Mechanical	Electrical
MirrorSwitch	Fuse(s)Wiring harnessLoose or corroded connections

3. If the concern is not visually evident, determine the symptom and proceed to Symptom Chart.

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action	
 The Mirrors Are Inoperative 	 Fuse. Circuitry. Outside rear view mirror switch. 	• GO to <u>Pinpoint Test</u> <u>A</u> .	

A Single Mirror Is Inoperative	 Circuitry. Outside rear view mirror motor. 	• GO to <u>Pinpoint Test</u> <u>B</u> .
 A Single Mirror Does Not Function With Switch Logic 	 Outside rear view mirror control. Outside rear view mirror motor. Circuitry. 	GO to <u>Pinpoint Test</u> <u>C</u> .
 The Auto Dimming Mirror Does Not Operate Properly 	 Fuse. Inside rear view mirror. Circuitry. 	GO to <u>Pinpoint Test</u> <u>D</u> .
 The Heated Outside Mirror Does Not Defrost — Both Power/Heated Mirrors 	 Fuse. Power/heated mirror. Circuitry. 	GO to <u>Pinpoint Test</u> <u>E</u> .
The Heated Outside Mirror Does Not Defrost — Left Power/Heated Mirror	 Left power heated mirror. Circuitry. 	• GO to <u>Pinpoint Test</u> <u>F</u> .
 The Heated Outside Mirror Does Not Defrost — Right Power/Heated Mirror 	 Right power/heated mirror. Circuitry. 	• GO to <u>Pinpoint Test</u> <u>G</u> .

Pinpoint Tests

PINPOINT TEST A: THE MIRRORS ARE INOPERATIVE

CONDITIONS	DETAILS/RESULTS/ACTIONS
A1 CHECK FUSE JUNCTION PANEL FUSE 1 (7	5A)
2 Fuse 1 (7.5A)	
	• Is the fuse OK?
	→ Yes GO to <u>A2</u> .
	→ No REPLACE the fuse. TEST the system for normal operation. If the fuse fails again,



normal operation.

PINPOINT TEST B: SINGLE MIRROR INOPERATIVE

CONDITIONS	DETAILS/RESULTS/ACTIONS				
B1 CHECK THE OUTSIDE REAR VIEW MIRROR CONTROL					
Dutside Rear View Mirror Switch C507	 2 Use the table to check for continuity between the given terminals of the outside rear view mirror switch for the side that is not operating correctly. 				
	Direction		lirror	RHM	lirror
	Up	1 and 7	5 and 6	1 and 8	5 and 6
	Down	1 and 6	5 and 7	1 and 6	5 and 8
	Left	1 and 4	5 and 6	1 and 3	5 and 6
	Right	1 and 6	4 and 5	1 and 6	3 and 5
	 Is the resisterminals I given sets direction? → Yes GO to B2. → No 	stance b less tha of term	oetween n 5 ohn iinals in	n given ns only each	for the
	REPLACE the outside rear view mirror switch. TEST the system for normal operation.				
B2 CHECK CIRCUIT 542 (Y) FOR OPEN	r				
Inoperative Outside Rear View Mirror C509 or C606 (C505 or					
C605 two door)	2 Measure the	resistan	ce betwe	een outs	ide rear

		view m inc ch	irror switch, circuit 542 operative outside rear v art below:	(Y), and iew mirror	using the
			LH Mirror	RH Mirror	
			2 DOOR	C505-1	C605-1
			4 DOOR	C509-5	C606-6
			OUTSIDE REAR VIEW MIRROR SWITCH	C507-6	C507-6
		• Is the resistance less than 5 ohms?			
		→ Yes REF TES	CACE the inoperative The system for norm	rear view al operatio	mirror. n.
		→ No REF norr	PAIR circuit 542 (Y). TE nal operation.	ST the sy	stem for

PINPOINT TEST C: A SINGLE MIRROR DOES NOT FUNCTION WITH SWITCH LOGIC

CONDITIONS	DETAILS/RESULTS/ACTIONS			
C1 CHECK THE MIRROR MOVEMENT (LEFT/RIGHT)				
	 Operate the LH and RH outside rear view mirrors in the left and right direction. 			
	 Do the outside rear view mirrors move left and right? 			
	\rightarrow Yes GO to <u>C2</u> .			
	\rightarrow No GO to <u>C3</u> .			
C2 CHECK MIRROR MOVEMENT (UP/DOWN)				
	1 Operate the LH and RH outside rear view mirrors in the up and down direction.			
	 Do the outside rear view mirrors move up and down? 			
	→ Yes System is OK.			







PINPOINT TEST D: THE AUTO DIMMING MIRROR DOES NOT OPERATE PROPERLY

CONDITIONS	DITIONS DETAILS/RESULTS/ACTIONS		
NOTE: If the transmission range sensor is malfunctioning so that the backup lamps are on, the electrochromic inside rear view mirror will not darken.			
D1 CHECK INSIDE REAR VIEW MIRROR OPERATION			
2	 Perform the Inside Rear View Mirror — Self Test. Refer to Component Tests. 		







PINPOINT TEST E: THE HEATED OUTSIDE MIRROR DOES NOT DEFROST — BOTH POWER/HEATED MIRRORS

CONDITIONS	DETAILS/RESULTS/ACTIONS		
E1 CHECK THE HEATED REAR WINDOW SWITCH OPERATION			
	Place the heated rear window switch in the ON position.		
	 Does the heated rear window switch illuminate? 		
	→ Yes REFER to <u>Section 501-11</u> .		
	$\rightarrow No$ GO to <u>E2</u> .		
E2 CHECK FUSE JUNCTION PANEL FUSE 32 (7.5A)		
Fuse 32 (7.5A)			



PINPOINT TEST F: THE HEATED OUTSIDE MIRROR DOES NOT DEFROST — LEFT POWER/HEATED MIRROR

CONDITIONS	DETAILS/RESULTS/ACTIONS
F1 CHECK CIRCUIT 59 (DG/P) FOR VOLTAGE	



PINPOINT TEST G: THE HEATED OUTSIDE MIRROR DOES NOT DEFROST — RIGHT POWER/HEATED MIRROR INOPERATIVE





Component Tests

Inside Rear View Mirror — Self Test

NOTE: This diagnostic test is applicable to late build models equipped with electrochromic inside rear view mirrors.

- 1. Place the ignition switch in the OFF position.
- 2. Place the autolamp in the OFF (slide control at the far left [detent]) position.
- 3. Using a ball-point pen or paper clip, press and hold the mode switch located at the bottom of the mirror. After three seconds, the headlamps and parking lights will illuminate. If the headlamps do not illuminate, check inside rear view mirror C341-2, circuit 218 (W/P), for an open or a short, or check for a defective parklamp relay. The autolamp status LED will illuminate.
- 4. Release the mode switch. If the headlamp or status LED does not illuminate then check inside rear view mirror C341-5, circuit 54 (LG/Y), and inside rear view mirror C341-4, circuit 57 (BK), for a short or an open.
- 5. Place the ignition switch in the ON position. The headlamps and parking lights will extinguish. The inside rear view mirror will dim. The autolamp status indicator and headlamps will extinguish and the inside rear view mirror will darken. If the autolamps remain ON and/or the inside rear view mirror does not darken, check inside rear view mirror C341-6, circuit 640 (R/Y), for an open; or check inside rear view mirror C341-3, circuit 140 (BK/PK), for battery voltage.
- 6. **NOTE:** This procedure must be started within ten seconds or the mirror will default to the power-up state.

The mirror will reset to the power-on state (mirror bright, lamps off). Once the inside rear view mirror is dark, place the gear shift lever in the REVERSE position. If the mirror does not return to full bright,

check inside rear view mirror C341-3, circuit 140 (BK/PK), for an open.

- 7. Place the gear shift lever in the PARK position.
- 8. Place the ignition switch in the OFF position.

Mirror —Inside Rear View, Electrochromic

Removal

CAUTION: Do not use tools or other objects to pry the mount or mirror away from the windshield. Use of tools may damage the mirror mount.

1. Disconnect the inside rear view mirror electrical connector.



2. Turn the inside rear view mirror to the vertical position.



- 3. Remove the inside rear view mirror.
 - Twist the mirror horizontally until the tube assembly bottoms out and the spring releases off the mounting button.

Installation

- 1. Position the inside rear view mirror onto the mounting button.
- 2. NOTE: Make sure the inside rear view mirror remains parallel to the windshield glass.

Slide the inside rear view mirror onto the mounting button while applying holding force against the button until a click is heard.

3. Connect the inside rear view mirror electrical connector.



4. **NOTE:** The mirror mount is designed to detach from the button during air bag deployment. Excessive force or adjustment can cause the mirror to detach from the windshield.

Check the inside rear view mirror for normal operation.

Mirror —Outside Rear View

Removal

- 1. Disconnect the battery ground cable (14301).
- 2. Remove the front door trim panel; refer to <u>Section 501-05</u>.
- 3. Remove the speaker.
 - 1. Remove the screws.
 - 2. Disconnect the electrical connector.
 - 3. Remove the speaker.



- 4. Remove the outside rear view mirror (17682).
 - 1. Disconnect the power mirror wiring clips.
 - 2. Remove the outside rear view mirror nuts.
 - 3. Remove the outside rear view mirror.
 - Feed the power mirror wiring through the opening in the front door (20124).



Installation

1. **NOTE:** When the battery (10655) is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 mi) or more to relearn the strategy.

To install, reverse the removal procedure.



Torque Specifications

Description	Nm	lb-ft	lb-in
Adjuster latch/pivot cover screw	1.6-2.2	—	15-19
Battery ground cable bolt	7-10	_	62-89
Center occupant safety belt bolt	30-40	22-30	—
Driver seat module screws	12	9	—
Front/rear seat backrest latch bolts	47-63	34-46	—
Front seat back pad adjusting pump bolt	11-14	8-10	—
Front seat cushion side cover screws	1.6-2.2	_	15-19
Front seat inboard pivot bolt	19-26	14-19	
Front seat track to floor bolts	21-28	15-21	—
Inboard safety belt bracket bolt	38-44	28-32	—
Latch handle screws	1.6-2.2	_	15-19
Link arm nut	30-40	22-30	
Rear outboard bolt	30-40	22-30	—
Rear outboard nut	30-40	22-30	
Rear seat back inboard/outboard pivot bolts	38-44	28-32	
Rear seat riser to floor nuts	30-40	22-30	
Rear seat riser pivot bolts	38-44	28-32	—
Rear seat link bolt	30-40	22-30	
Rear seat to floor bolts	30-40	22-30	
Safety belt buckle bracket to floor nuts	34-46	25-34	_
Seat cushion to adjuster latch bolts, rear seat	38-44	28-32	
Seat track to seat cushion bolts	17-23	13-17	
Side air bag nuts	8	_	71
Slide bar to floor bolt	40	30	
Slide bar to seat track bolt	7.5-10.5	_	66.4-92.9
Slide bar to seat track nut	7.5-10.5	_	66.4-92.9
40% seat inboard pivot bolts	23-32	17-24	—
50% seat cushion to seat hinge bolts	7-11	_	62-97
50/50 seat back latch bolt	30-46	22-33	
60% front seat armrest bolt	30-35	22-26	
60% seat cushion outboard side bolster screw	1.6-2.2	_	15-19
60% seat inboard pivot cover bolt	1.6-2.2	_	15-19

SECTION 501-10: Seating DESCRIPTION AND OPERATION

Seats

The seat options consist of:

- Captain's Chair (cloth)
- Eddie Bauer Sport Bucket (leather, standard power driver, optional power passenger, optional heated, optional side air bag)
- Limited Seat (leather, optional heated, optional side air bag)
- Sport Bucket (cloth, optional side air bag)
- Sport Bucket (driver, cloth, optional power, optional side air bag)
- Sport Bucket (leather, optional power, optional side air bag)
- Vinyl Bucket
- 60/40 Front Bench (vinyl, cloth)
- 50/50 Rear Seat (vinyl, cloth, leather)
- 60/40 Rear Seat (vinyl, cloth, leather)

Programmable Seat, Explorer Limited

Programmable Seat Switch



This system allows automatic positioning of the driver seat to three programmable positions.

- To program position one, move the driver seat to the desired position using the seat regulator control switch. Depress the set button. Within five seconds, depress button one.
- To program position two, repeat the previous procedure using button two.
- To program position three, repeat the previous procedure but depress buttons one and two simultaneously
- To recall position one, depress button one. To recall position two, depress button two. To recall position three, depress button one and two simultaneously.

A position can only be recalled when the transmission selector is in PARK or NEUTRAL. A position may be programmed at any time.

Heated Seat

This system allows the electrical heating of the front seats on passenger demand.

The components of the system are:

- The seat heating elements located in the seat cushion and backrest.
- The heated seat module located on the seat cushion frame.
- The heated seat control switch, located on the seat side trim panel.
- Temperature sensors located in the seat heating elements.

Side Air Bag

Driver and passenger side air bags are attached to the seat backrest frame. For diagnostic information or if the side air bag has been deployed, refer to <u>Section 501-20B</u>.

Front seat backrest trim covers installed on seats with side air bags cannot be repaired. The front seat backrest trim covers are to be installed new. Cleaning is permissible.

If a side air bag deployment took place the seat back pad, trim cover and side air bag module must be replaced. Replace the seat back frame if necessary.

Seats

Refer to Wiring Diagrams Cell <u>120</u>, Power Seats for schematic and connector information.

Refer to Wiring Diagrams Cell <u>122</u>, Power Lumbar Seats for schematic and connector information.

Refer to Wiring Diagrams Cell <u>123</u>, Memory Seats for schematic and connector information.

Special Tool(s)

[1]. [2]	73III Automotive Meter or equivalent 105-R0057	
ST1137-A		
	Passenger Car Pressure Tester or equivalent 014-R1052	
ST1253-B		
ST2332-A	Worldwide Diagnostic System (WDS) 418-F224, New Generation STAR (NGS) Tester 418-F052, or equivalent scan tool	
ST2506-A	Air Bag Simulator (Restraints System Diagnostic Tool) 418-F088 (105-R0012) or equivalent	

Restraint System Diagnostic Tool Warning

WARNING: This tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Inspection and Verification

1. Verify the customer concern by operating the power seat(s).

2. Visually inspect for obvious signs of mechanical and electrical damage.

Visual Inspection Chart

Mechanical	Electrical
 Switch(s) Seat tracks obstructed or damaged Hose(s) Pad adjuster 	 Fuse(s) Wiring harness Loose or corroded connections Motor(s) Adjusting pump

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 3. If the concern remains after the inspection connect the scan tool to the data link connector (DLC) located beneath the instrument panel and select the vehicle to be tested from the scan tool menu. If the scan tool does not communicate with the vehicle:
 - check that the program card is correctly installed.
 - check the connections to the vehicle.
 - check the ignition switch position.
- 4. If the scan tool still does not communicate with the vehicle, refer to the scan tool manual.
- 5. Perform the DATA LINK DIAGNOSTIC TEST. If the scan tool responds with:
 - CKT914, CKT915 or CKT70 = ALL ECUS NO RESP/NOT EQUIP, refer to Section 418-00.
 - NO RESP/NOT EQUIP for DSM, <u>Go To Pinpoint Test K</u>.
 - SYSTEM PASSED, retrieve and record the continuous diagnostic trouble codes (DTCs), erase the continuous DTCs and perform self test diagnostics for the driver seat module (DSM).
- 6. If the DTCs retrieved are related to the concern, go to DSM Diagnostic Trouble Code (DTC) Index to continue diagnostics.

7. If no DTCs related to the concern are retrieved, proceed to Symptom Chart to continue diagnostics.

DSM Diagnostic Trouble Code (DTC) Index

DSM Diagnostic Trouble Code (DTC) Index

DTO	Beendedter	DTC Caused	
DIC	Description	Ву	Action
B1342	ECU is Defective	DSM	INSTALL a new DSM. REFER to <u>Seat</u> <u>Module—Driver, 6-Way Power</u> . TEST the system for normal operation.
B1529	Memory SET Switch Circuit Short to Power	DSM	Go To Pinpoint Test H.
B1533	Memory 1 Switch Circuit Short to Power	DSM	Go To Pinpoint Test H.
B1537	Memory 2 Switch Circuit Short to Power	DSM	Go To Pinpoint Test H.
B1663	Seat Driver Front Up/Down Motor Stalled	DSM	REFER to Symptom Chart for customer concern, then <u>Go To Pinpoint</u> <u>Test G</u> or <u>Go To Pinpoint Test H</u> .
B1664	Seat Driver Rear Up/Down Motor Stalled	DSM	REFER to Symptom Chart for customer concern, then <u>Go To Pinpoint</u> <u>Test G</u> or <u>Go To Pinpoint Test H</u> .
B1665	Seat Driver Forward/Backward Motor Stalled	DSM	REFER to Symptom Chart for customer concern, then <u>Go To Pinpoint</u> <u>Test G</u> or <u>Go To Pinpoint Test H</u> .
B1676	Battery Power Out of Range	DSM	REFER to Section 414-00.
B1711	Seat Driver Front Up Switch Circuit Short to Power	DSM	<u>Go To Pinpoint Test G</u> .
B1715	Seat Driver Down Switch Circuit Short to Power	DSM	<u>Go To Pinpoint Test G</u> .
B1719	Seat Driver Forward Switch Circuit Short to Power	DSM	<u>Go To Pinpoint Test G</u> .
B1723	Seat Driver Rearward Switch Circuit Short to Power	DSM	<u>Go To Pinpoint Test G</u> .
B1727	Seat Driver Rear Up Switch Circuit Short to Power	DSM	<u>Go To Pinpoint Test G</u> .
B1731	Seat Driver Rear Down Switch Circuit Short to Power	DSM	<u>Go To Pinpoint Test G</u> .
B1950	Seat Rear Up/Down Potentiometer Feedback Circuit Failure (Possible Open or Short to Ground Condition)	DSM	<u>Go To Pinpoint Test H</u> .
B1952	Seat Rear Up/Down Potentiometer Feedback Circuit Short to Power	DSM	<u>Go To Pinpoint Test H</u> .
B1954	Seat Front Up/Down Potentiometer Feedback Circuit Failure (Possible Open or Short to Ground Condition)	DSM	<u>Go To Pinpoint Test H</u> .
B1956	Seat Front Up/Down Potentiometer Feedback Circuit Short to Power	DSM	Go To Pinpoint Test H.
J I	I	I	I

B1962	Seat Horizontal Fwd/Rwd Potentiometer Feedback Circuit Failure (Possible Open or Short to Ground Condition)	DSM	<u>Go To Pinpoint Test H</u> .
B1964	Seat Horizontal Fwd/Rwd Potentiometer Feedback Circuit Short to Power	DSM	<u>Go To Pinpoint Test H</u> .

DSM Parameter Identification (PID) Index

DSM Parameter Identification (PID) Index

PID	Description	Expected Values
CCNT_DS	Number of Continuous DTCs in Module	One Count Per Bit
P/N SW	Park/Neutral Switch	P/N, not P/N
SFWD_MT	Driver Seat Forward/Rearward Motor	SENSED, NOTSEN
SREARMT	Driver Seat Rear Motor	SENSED, NOTSEN
SFNT_MT	Driver Seat Front Motor	SENSED, NOTSEN
MEM2_SW	Memory Recall Switch 2	OFF, ON
MEM1_SW	Memory Recall Switch 1	OFF, ON
MEMS_SW	Memory SET Switch	OFF, ON
SFNT_SW	Power Seat Switch — Front	SHORT, UP, DOWN, OFF
SREARSW	Power Seat Switch — Rear	SHORT, UP, DOWN, OFF
SFWD_SW	Power Seat Switch — Forward/Rearward	SHORT, RWD, FWD, OFF
SFWD_P	Driver Seat Position % Forward	% of Full Forward
SFNT_P	Driver Seat Front Position % Up	% of Full Up
SREAR_P	Driver Seat Rear Position % Up	% of Full Up
VBATVDM	Battery Voltage	Volts
PMIR_H	Passenger Side Mirror Horizontal Motor	SENSED, notSEN
PMIR_V	Passenger Side Mirror Vertical Motor	SENSED, notSEN
DMIR_H	Driver Side Mirror Horizontal Motor	SENSED, notSEN
DMIR_V	Driver Side Mirror Vertical Motor	SENSED, notSEN
MIR_SEL	Power Mirror Select Switch	PSSNGR, DRIVER
MIRV_SW	Power Mirror Position Switch — Vertical	SHORT, DOWN, UP, OFF
MIRH_SW	Power Mirror Position Switch — Horizontal	SHORT, RIGHT, LEFT, OFF
DMIR_R	Driver Mirror Position % Right	% of Full Right
DMIR_UP	Driver Mirror Position % Up	% of Full Up
PMIR_R	Passenger Mirror Position % Right	% of Full Right
PMIR_UP	Passenger Mirror Position % Up	% of Full Up

DSM Active Command Index

DSM Active Command Index

Active Command	Display	Action
PID LATCH	PID LATCH	ON, OFF
MEMORY SET LED CONTROL	LED STATE	ON, OFF
SEAT CONTROL	FRONT UP	ON, OFF
	FRONT DWN	ON, OFF
	REAR UP	ON, OFF
	REAR DWN	ON, OFF
	HORZ FWD	ON, OFF
	HORZ RWD	ON, OFF

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action
 The power seat is inoperative 	 Fuse. Circuitry. Front seat regulator control switch (14A701). 	 <u>Go To Pinpoint Test</u> <u>A</u>. If equipped with memory seat, <u>Go</u> <u>To Pinpoint Test G</u>.
 The power seat moves but is noisy 	Seat track.	• <u>Go To Pinpoint Test</u> <u>B</u> .
 The power seat moves but is loose 	Fastening hardware.Seat track.	<u>Go To Pinpoint Test</u> <u>C</u> .
 The power seat does not make full travel 	Track obstructed.Seat track.	<u>Go To Pinpoint Test</u> <u>D</u> .
 The power seat does not move horizontally/vertically 	 Front seat regulator motors (14547). Circuitry. Front seat regulator control switch. 	 <u>Go To Pinpoint Test</u> <u>E</u>. If equipped with memory seat, <u>Go</u> <u>To Pinpoint Test G</u>.
The power lumbar is inoperative	 Circuitry. Fuse. Seat control switch (14C715). Front seatback pad adjusting pump (65530). Front seatback pad adjusting hose (65528). Front seatback pad adjuster (65500). 	• <u>Go To Pinpoint Test</u> <u>F</u> .

L

 The memory seat is inoperative 	Seat regulator control switch.Circuitry.DSM.	 <u>Go To Pinpoint Test</u> <u>G</u>.
 The memory seat does not operate correctly — does not operate using the memory SET switch 	 Memory SET switch. DSM. Circuitry. 	 <u>Go To Pinpoint Test</u> <u>H</u>.
 The memory seat does not operate correctly — the seat moves in one second intervals 	DSM.Circuitry.	 <u>Go To Pinpoint Test</u> <u>H</u>.
 The memory seat does not operate correctly — the seat does not move to the correct memory position 	 DSM. Circuitry. Memory SET switch. Memory seat. 	 <u>Go To Pinpoint Test</u> <u>H</u>.
 The memory seat does not operate correctly — does not operate using the remote transmitter 	 Circuitry. Keyless entry transmitter. RAP module. DSM. 	 <u>Go To Pinpoint Test</u> <u>J</u>.
 No communication with the module — unable to perform on- demand self-test with the driver seat module 	DSM.Circuitry.	 <u>Go To Pinpoint Test</u> <u>K</u>.
 The heated seat is inoperative 	 Fuse. Circuitry. Heated seat switch. Heated seat module. Seat heater and temperature sensor. 	 <u>Go To Pinpoint Test</u> <u>L</u>.
 The heated seat is inoperative— seat does heat but the heated seat switch illuminates when pressed. 	 Circuitry. Heated seat module. Seat heater and temperature sensor. 	• <u>Go To Pinpoint Test</u> <u>M</u> .
The heated seat is inoperative— seat does heat but the heated seat switch does not illuminate when pressed.	 Circuitry. Heated seat module. Heated seat switch. 	• <u>Go To Pinpoint Test</u> <u>N</u> .

Pinpoint Tests

Г

PINPOINT TEST A: THE POWER SEAT IS INOPERATIVE

Τ

Į

CONDITIONS	DETAILS/RESULTS/ACTIONS		
A1 CHECK FUSE JUNCTION PANEL FUSE 18 (2	25A)		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.			
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.			
NOTE: Airbag simulators (restraint system diagnost side airbag to floor connector.	ic tools) MUST be installed under the seats in the		
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.			
NOTE: Diagnostics may be performed on seat systeclimate controlled, heated, power seat track) with the restraint system diagnostic tool is installed under the	ems other than the side airbag system (lumbar, e seat installed in the vehicle as long as the e seat in the side airbag to floor connector.		
NOTE: After diagnosing/repairing a seat system the before operating the vehicle.	restraint system diagnostic tool must be removed		
NOTE: Before disconnecting the battery, raise the s seat to its most forward position.	eat to its highest position, then move and tilt the		
Image: Second system Image: Second system	 Deactivate the supplemental restraint system. Refer to <u>Section 501-20B</u>. Is the fuse OK? → Yes GO to A2. → No INSTALL a new Fuse 18 (25A). TEST the system for normal operation. If the fuse fails again, CHECK for a short to ground. REPAIR as necessary. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u>. LATOR CONTROL SWITCH — CIRCUIT 171 		
(BK/W)			

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible



Limited or Switch—6-Way Power Seat, Sport Bucket. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to Section 501-20B.
→ No REPAIR Circuit 57 (BK). TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .

PINPOINT TEST B: THE POWER SEAT MOVES BUT IS NOISY

CONDITIONS DETAILS/RESULTS/ACTIONS **B1** CHECK THE TRACK ALIGNMENT WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. **NOTE:** If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in Section 501-20B of the appropriate car/truck service manual. NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector. NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle. NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector. **NOTE:** After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle. **NOTE:** Before disconnecting the battery, raise the seat to its highest position, then move and tilt the seat to its most forward position. Deactivate the supplemental restraint system. Refer to <u>Section 501-20B</u>. 2 Check the alignment of the track to the floor and the track to the seat. Is the track out of alignment? ightarrow Yes ALIGN the track to the seat and the floor. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to Section 501-20B. No INSTALL a new seat track assembly. REFER to Seat-Track, Limited and 6-Way Power. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to Section 501-20B.
PINPOINT TEST C: THE POWER SEAT MOVES BUT IS LOOSE

CONDITIONS	DETAILS/RESULTS/ACTIONS	
C1 CHECK THE FASTENING HARDWARE		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.		
NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.		
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.		
NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.		
NOTE: After diag before operating	pnosing/repairing a seat system the restraint system diagnostic tool must be removed the vehicle.	
NOTE: Before di seat to its most fe	sconnecting the battery, raise the seat to the highest position, then move and tilt the prward position.	
	1 Deactivate the supplemental restraint system. Refer to <u>Section 501-20B</u> .	
	2 Check the hardware fastening the seat.	
	Is the fastening hardware loose?	
	→ Yes TIGHTEN all the fastening hardware to specifications. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .	
	→ No INSTALL a new seat track assembly. REFER to <u>Seat—Track, Limited and 6-Way</u> <u>Power</u> . TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .	

PINPOINT TEST D: THE POWER SEAT DOES NOT MAKE FULL TRAVEL

CONDITIONS	DETAILS/RESULTS/ACTIONS	
D1 CHECK THE SEAT TRACK FOR OBSTRUCTIONS		
WARNING Remove from ve violation of veh	: The restraint system diagnostic tool is for restraint system service only. whicle prior to road use. Failure to remove could result in injury and possible icle safety standards.	

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate

car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.

\square Deactivate the supplemental restraint system. Refer to <u>Section 501-20B</u> .
2 Remove the driver seat. Refer to <u>Seat—Front Bucket</u> .
Are there any obstructions in the seat track?
→ Yes REMOVE the obstruction(s) and grease the track(s). TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section</u> <u>501-20B</u> .
→ No INSTALL a new seat track assembly. REFER to <u>Seat—Track, Limited and 6-Way</u> <u>Power</u> . TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .

PINPOINT TEST E: THE POWER SEAT DOES NOT MOVE HORIZONTALLY/VERTICALLY

CONDITIONS	DETAILS/RESULTS/ACTIONS	
E1 DETERMINE WHICH DIRECTION HAS FAILED		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.		
NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.		
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the		

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.

2	 Deactivate the supplemental restraint system. Refer to <u>Section 501-20B</u>. Push the driver or passenger seat regulator control switch to the front and rear.
	 Does the power seat move to the front and rear?
	\rightarrow Yes GO to E2.
	\rightarrow No GO to E9.
E2 DETERMINE POWER SEAT TILTING FAILUR	RE
WARNING: The restraint system diagnosti Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	c tool is for restraint system service only. to remove could result in injury and possible
	1 Verify the power seat tilting feature.
	 Can the power seat be tilted forward and backward?
	Yes If only the forward tilting operates, GO to <u>E3</u> .
	If only the rearward tilting operates, GO to <u>E6</u> . → No INSTALL a new seat regulator control switch. REFER to <u>Switch—6-Way Power Seat</u> , <u>Limited</u> or <u>Switch—6-Way Power Seat</u> , <u>Sport Bucket</u> . TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
E3 CHECK THE VOLTAGE TO THE REAR HEIG	HT MOTOR
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
1	

















PINPOINT TEST F: THE POWER LUMBAR IS INOPERATIVE

CONDITIONS	DETAILS/RESULTS/ACTIONS	
F1 CHECK FRONT SEATBACK ADJUSTING PUMP		
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible	

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system

must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.

· · · · · · · · · · · · · · · · · · ·	r
2	1 Deactivate the supplemental restraint system. Refer to <u>Section 501-20B</u> .
	Press and hold the driver or passenger lumbar seat control switch (+) button.
	 Does the driver or passenger front seatback pad adjusting pump run?
	→ Yes GO to <u>F7</u> .
	→ No GO to <u>F2</u> .
F2 CHECK OPERATION OF POWER SEAT(S)	
NOTE: Do not press the front lumbar seat control sw	/itch.
	1 Verify the operation of the power seat(s).
	 Does the driver or passenger power seat(s) operate?
	→ Yes GO to <u>F3</u> .
	→ No If the power lumbar in question is part of the driver memory seat, GO to <u>Pinpoint Test G</u> .
	If equipped with power seat(s), GO to <u>Pinpoint Test A</u> .
F3 CHECK THE VOLTAGE TO THE LUMBAR SEA	AT CONTROL SWITCH





	normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
F6 CHECK CIRCUIT 57 (BK) FOR OPEN	
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible
	1 Measure the resistance between front seatback pad adjusting pump C347-2 (driver) or C354-2 (passenger), Circuit 57 (BK), and ground.
GR1394-A	
	Is the resistance less than 5 ohms?
	→ Yes INSTALL a new driver or passenger front seatback pad adjusting pump. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
	→ No REPAIR Circuit 57 (BK). TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
F7 CHECK FRONT SEATBACK PAD ADJUSTING	SYSTEM
	 Press and hold the driver or passenger lumbar seat control switch (+) button. Observe the driver or passenger front
	 seatback pad adjuster . Does the driver or passenger front seatback pad adjuster inflate?
	→ Yes GO to <u>F13</u> .
	→ No GO to <u>F8</u> .
F8 CHECK FRONT SEATBACK PAD ADJUSTER	

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	Gain access to the driver or passenger front seatback pad adjuster .
	Inspect the driver or passenger front seatback pad adjuster.
	 Is there any visible damage to the driver or passenger front seatback pad adjuster ?
	→ Yes REPAIR or INSTALL a new driver or passenger front seatback pad adjuster. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to Section 501-20B.
	$ \stackrel{\rightarrow}{\underset{\text{GO to } \underline{\text{F9}}.}{}} No$
F9 CHECK AIR FLOW AT FRONT SEAT	BACK PAD ADJUSTING PUMP
WARNING: The restraint system di Remove from vehicle prior to road use. I violation of vehicle safety standards.	iagnostic tool is for restraint system service only. Failure to remove could result in injury and possible I Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting pump .
WARNING: The restraint system di Remove from vehicle prior to road use. violation of vehicle safety standards.	 iagnostic tool is for restraint system service only. Failure to remove could result in injury and possible Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting pump . Press and hold the driver or passenger lumbar seat control switch (+) button.
WARNING: The restraint system di Remove from vehicle prior to road use. violation of vehicle safety standards.	 iagnostic tool is for restraint system service only. Failure to remove could result in injury and possible Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting pump . Press and hold the driver or passenger lumbar seat control switch (+) button. Check the driver or passenger front seatback pad adjusting pump opening for air flow.
WARNING: The restraint system di Remove from vehicle prior to road use. violation of vehicle safety standards.	 iagnostic tool is for restraint system service only. Failure to remove could result in injury and possible Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting pump . Press and hold the driver or passenger lumbar seat control switch (+) button. Check the driver or passenger front seatback pad adjusting pump opening for air flow. Was air felt coming from the front seatback pad adjusting pump opening?
WARNING: The restraint system di Remove from vehicle prior to road use. violation of vehicle safety standards.	 iagnostic tool is for restraint system service only. Failure to remove could result in injury and possible 1 Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting pump . 2 Press and hold the driver or passenger lumbar seat control switch (+) button. 3 Check the driver or passenger front seatback pad adjusting pump opening for air flow. Was air felt coming from the front seatback pad adjusting pump opening? → Yes GO to F10.
WARNING: The restraint system di Remove from vehicle prior to road use. violation of vehicle safety standards.	 iagnostic tool is for restraint system service only. Failure to remove could result in injury and possible 1 Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting pump . 2 Press and hold the driver or passenger lumbar seat control switch (+) button. 3 Check the driver or passenger front seatback pad adjusting pump opening for air flow. Was air felt coming from the front seatback pad adjusting pump opening? → Yes GO to F10. → No INSTALL a new driver or passenger front seatback pad adjusting pump. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to Section 501-20B.

 Reconnect the driver or passenger front seatback pad adjusting hose at the drive passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting hose opening for fibe driver or passenger front seatback pad adjusting hose opening for flow. Press and hold the driver or passenger front seatback pad adjusting hose opening for flow. Check the driver or passenger front seatback pad adjusting hose opening for flow. Was air felt coming from the driver or passenger front seatback pad adjusting hose opening? → Yes GO to E11. → No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hose opening? → Yes GO to E11. → No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hose opening? → Yes GO to E11. → No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hose opening? → Wes system for normal operation. REACTIVATE the supplemental restraint system REFER to Section 501-20B. F11 CHECK AIR FLOW COMING FROM THE SEAT CONTROL SWITCH Marking: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster or passenger front seatback pad adjuster hor or passenger front seatback pad adjuster from seatback pad adjuster from seatback pad adjuster front seatback pad adjuster front seatback pad adjuster hor or p	WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible
 Cherrore the driver or passenger front seatback paradiusting hose coming from the driver or passenger front seatback paradiusting hose coming from the driver or passenger front seatback paradiusting hose opening for flow. Press and hold the driver or passenger front seatback paradiusting hose opening for flow. Check the driver or passenger front seatback paradiusting hose opening? Yes GO to E11 Yes GO to E11 Yes GO to E11 No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hose opening? It CHECK AIR FLOW COMING FROM THE SEAT CONTROL SWITCH WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting hose opening? 		 Reconnect the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting pump. Remove the driver or passenger front
 Press and hold the driver or passenger lumbar seat control switch (+) button. Check the driver or passenger front seatback pad adjusting hose opening for flow. Was air felt coming from the driver or passenger front seatback pad adjusting hose opening? → Yes GO to E11. → No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hose opening. F11 CHECK AIR FLOW COMING FROM THE SEAT CONTROL SWITCH WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose oping front seatback pad adjusting hose oping front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjusting hose oping for the driver or passenger front seatback pad adjuster at the driver or passenger front seatback pad adjuster at the driver or passenger front seatback pad adjuster at the driver or passenger front seatback pad adjuster at the driver or passenger front seatback pad adjuster at the driver or passenger front seatback pad adjuster at the d		Remove the driver or passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting pump at the driver or passenger lumbar seat control switch.
 I Check the driver or passenger front seatback pad adjusting hose opening for flow. Was air felt coming from the driver or passenger front seatback pad adjusting hose opening? → Yes GO to E11. → No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hose opening? F11 CHECK AIR FLOW COMING FROM THE SEAT CONTROL SWITCH MARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose opening? Remove the driver or passenger front seatback pad adjusting hose opening? 		Press and hold the driver or passenger lumbar seat control switch (+) button.
 Was air felt coming from the driver of passenger front seatback pad adjusting hose opening? → Yes GO to E11. → No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hor TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to Section 501-20B. F11 CHECK AIR FLOW COMING FROM THE SEAT CONTROL SWITCH MARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster at the driver or passenger lumbar seat control switch. 		4 Check the driver or passenger front seatback pad adjusting hose opening for air flow.
 → Yes GO to F11. → No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hor TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to Section 501-20B. F11 CHECK AIR FLOW COMING FROM THE SEAT CONTROL SWITCH MARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose coming fror the driver or passenger front seatback pa adjusting pump at the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster at the driver or passenger lumba seat control switch. 		 Was air felt coming from the driver or passenger front seatback pad adjusting hose opening?
 No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hu TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u>. F11 CHECK AIR FLOW COMING FROM THE SEAT CONTROL SWITCH WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose coming fron the driver or passenger front seatback pa adjusting pump at the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster at the driver or passenger lumbar seat control switch. 		$ \xrightarrow{\rightarrow} \mathbf{Yes} $ GO to <u>F11</u> .
 F11 CHECK AIR FLOW COMING FROM THE SEAT CONTROL SWITCH WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose coming fror the driver or passenger front seatback pad adjusting pump at the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster at the driver or passenger lumbar seat control switch. 		→ No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hose. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
 WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Reconnect the driver or passenger front seatback pad adjusting hose coming fror the driver or passenger front seatback pad adjusting pump at the driver or passenger lumbar seat control switch. Remove the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster at the driver or passenger lumbar seat control switch. 	F11 CHECK AIR FLOW COMING FROM THE SEA	AT CONTROL SWITCH
 Reconnect the driver or passenger front seatback pad adjusting hose coming fror the driver or passenger front seatback pa adjusting pump at the driver or passenger lumbar seat control switch. Remove the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster at the driver or passenger lumbar seat control switch. 	WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. The remove could result in injury and possible
Remove the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster at the driver or passenger lumba seat control switch.		1 Reconnect the driver or passenger front seatback pad adjusting hose coming from the driver or passenger front seatback pad adjusting pump at the driver or passenger lumbar seat control switch.
		2 Remove the driver or passenger front seatback pad adjusting hose going to the driver or passenger front seatback pad adjuster at the driver or passenger lumbar seat control switch.
Press and hold the driver or passenger lumbar seat control switch (+) button.		Press and hold the driver or passenger lumbar seat control switch (+) button.
4 Check the driver or passenger lumbar se control switch opening for air flow.		4 Check the driver or passenger lumbar seat control switch opening for air flow.

	 Was air felt coming from the driver or passenger lumbar seat control switch opening? → Yes GO to F12. → No INSTALL a new driver or passenger lumbar seat control switch. TEST the system for normal operation. REACTIVATE the 	
	supplemental restraint system. REFER to <u>Section 501-20B</u> .	
F12 CHECK AIR FLOW AT FRONT SEATBACK P	AD ADJUSTER	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	Reconnect the driver or passenger front seatback pad adjusting hose at the driver or passenger lumbar seat control switch.	
	2 Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjuster.	
	Press and hold the driver or passenger lumbar seat control switch (+) button.	
	4 Check the driver or passenger front seatback pad adjusting hose opening for air flow.	
	 Was air felt coming from the driver or passenger front seatback pad adjusting hose opening? 	
	→ Yes GO to <u>F13</u> .	
	→ No REPAIR or INSTALL a new driver or passenger front seatback pad adjusting hose. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .	
F13 CHECK THE SYSTEM FOR LEAKS		
	 Reconnect the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjuster . Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting 	

3	pump . Insert a hand pump into the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjusting pump .
	 Press and hold the driver or passenger lumbar seat control switch (+) button while inflating the driver or passenger front seatback pad adjuster to 34.47 kPa (5 psi). Check the system pressure after three hours. After three hours, is the reading 32.41 kPa (4 7 psi) or more?
	 → Yes System OK. → No GO to F14.
F14 CHECK FRONT SEATBACK PAD ADJUSTER	FOR LEAKS
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible
	 Remove the in-line pressure. Remove the driver or passenger front seatback pad adjusting hose at the driver or passenger front seatback pad adjuster .
3 GR0434-A	 Insert a hand pump into the driver or passenger front seatback pad adjuster.
	pad adjuster to 34.47 kPa (5 psi).

Check the system pressure after three hours.
 After three hours, is the reading 32.41 kPa (4.7 psi) or more?
→ Yes INSTALL a new driver or passenger lumbar seat control switch and/or driver or passenger front seatback pad adjusting hose. TEST the system for normal operation.
→ No INSTALL a new driver or passenger front seatback pad adjuster. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .

PINPOINT TEST G: THE MEMORY SEAT IS INOPERATIVE

CONDITIONS	DETAILS/RESULTS/ACTIONS	
G1 RETRIEVE THE DTCS		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.		
NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.		
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.		
NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.		
NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.		
NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.		
2 PRND	Deactivate the supplemental restraint system. Refer to <u>Section 501-20B</u> .	



	If DTC B1719, GO to <u>G3</u> .
	If DTC B1723, GO to <u>G3</u> .
	If DTC B1727, GO to <u>G3</u> .
	If DTC B1731, GO to <u>G3</u> .
	If DTC B1952, GO to Pinpoint Test J.
	If DTC B1954, GO to Pinpoint Test J.
	If DTC B1956, GO to <u>Pinpoint Test J</u> .
	If DTC B1962, GO to <u>Pinpoint Test J</u> .
	If DTC B1964, GO to Pinpoint Test J.
	If DTC B1342, REPLACE the DSM. REFER to
	Seat Module—Driver, 6-Way Power. TEST the system for normal operation.
	REACTIVATE the supplemental restraint
	system. REFER to <u>Section 501-20B</u> .
	\rightarrow No
	GO to <u>G2</u> .
G2 CHECK THE DSM FOR CORRECT SEAT REC MONITOR THE DSM PIDS SFNT SW, SREARSW	GULATOR CONTROL SWITCH INPUTS — AND SFWS_SW
	 Monitor the DSM PIDs SFNT_SW, SREARSW and SFWS_SW while activating the seat switch.
	 Do the PID values agree with the switch positions?
	\rightarrow Yes GO to <u>G9</u> .
	→ No If fuse junction panel Fuse 18 (25A) fails while toggling the seat regulator control switch, GO to G7.
	 → No If fuse junction panel Fuse 18 (25A) fails while toggling the seat regulator control switch, GO to G7. If fuse junction panel Fuse 18 (25A) is OK, GO to G7.
G3 CHECK THE SEAT REGULATOR CONTROL	 → No If fuse junction panel Fuse 18 (25A) fails while toggling the seat regulator control switch, GO to G7. If fuse junction panel Fuse 18 (25A) is OK, GO to G7. SWITCH SWITCH Output Output Description: SWITCH Output Description: Switch Description: Descrite: Description: <
G3 CHECK THE SEAT REGULATOR CONTROL WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	 → No If fuse junction panel Fuse 18 (25A) fails while toggling the seat regulator control switch, GO to G7. If fuse junction panel Fuse 18 (25A) is OK, GO to G7. SWITCH SWITCH tool is for restraint system service only. to remove could result in injury and possible
G3 CHECK THE SEAT REGULATOR CONTROL WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	 → No If fuse junction panel Fuse 18 (25A) fails while toggling the seat regulator control switch, GO to G7. If fuse junction panel Fuse 18 (25A) is OK, GO to G7. SWITCH SWITCH tool is for restraint system service only. to remove could result in injury and possible Solution Solution<!--</td-->
G3 CHECK THE SEAT REGULATOR CONTROL WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	 → No If fuse junction panel Fuse 18 (25A) fails while toggling the seat regulator control switch, GO to G7. If fuse junction panel Fuse 18 (25A) is OK, GO to G7. SWITCH SWITCH tool is for restraint system service only. o remove could result in injury and possible Output Output








































PINPOINT TEST H: THE MEMORY SEAT DOES NOT OPERATE CORRECTLY — DOES NOT OPERATE USING THE MEMORY SET SWITCH

CONDITIONS	DETAILS/RESULTS/ACTIONS
H1 RETRIEVE THE DTCS	

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the

restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.













WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.



Measure the resistance between the following memory set switch C511 pins and DSM C337 pins.

Memory Set Switch	Circuit	DSM
C511-4	267 (BR/LG)	C337- 16
C511-3	268 (BK/O)	C337- 15
C511-1	270 (BR/O)	C337-3
C511-8	272 (W/O)	C337- 13

• Are the resistances less than 5 ohms?

 \rightarrow Yes

INSTALL a new DSM. REFER to <u>Seat</u> <u>Module—Driver, 6-Way Power</u>. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u>.

	→ No REPAIR the circuit(s) in question. TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
H9 CHECK THE DSM FOR CORRECT OUTPUTS — MONITOR THE DSM PIDS SFWD_P, SFNT_P, AND SREAR_P	
WARNING: The restraint system diagnost Remove from vehicle prior to road use. Failure violation of vehicle safety standards.	c tool is for restraint system service only. to remove could result in injury and possible
	 Place the seat in a central position using the seat regulator control switch.
	2 Monitor the DSM PID SFWD_P while operating the seat regulator control switch forward/rearward switch.
	3 Monitor the DSM PID SFNT_P while operating the seat regulator control switch front up/down switch.
	4 Monitor the DSM PID SREAR_P while operating the seat regulator control switch rear up/down switch.
	 Does the PID (position % of travel) values increase with forward/down movement and decrease with rearward/up movement throughout entire travel?
	→ Yes INSTALL a new DSM. REFER to <u>Seat</u> <u>Module—Driver, 6-Way Power</u> . TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
	→ No If the DSM PID SFWD_P values do not increase or decrease, GO to <u>H16</u> .
	If the DSM PID SFNT_P values do not increase or decrease, GO to <u>H10</u> .
	If the DSM PID SREAR_P values do not increase or decrease, GO to <u>H13</u> .
H10 CHECK CIRCUITS 443 (LG/R), 447 (O/R) A	ND 446 (O/W) FOR SHORT TO POWER















PINPOINT TEST J: THE MEMORY SEAT DOES NOT OPERATE CORRECTLY — DOES NOT OPERATE USING THE REMOTE TRANSMITTER

CONDITIONS	DETAILS/RESULTS/ACTIONS
J1 RETRIEVE THE DIAGNOSTIC TROUBLE CODES (DTCS)	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
NOTE: If a seat equipped with a seat mounted side must be deactivated per the deactivation procedure car/truck service manual.	airbag system is being serviced the airbag system contained in <u>Section 501-20B</u> of the appropriate
NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.	
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.	
NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.	
NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.	
NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.	

	Deactivate the supplemental restraint system. Refer to Section 501-20B.
2	
PRND	
3	
4	
Scan Tool	
Retrieve Continuous DTCs	
	Document any continuous DTCs.
Clear Continuous DTCs	
	 Are any DTCs retrieved?
	→ Yes REFER to DSM Diagnostic Trouble Code (DTC) Index.
	\rightarrow No GO to <u>J2</u> .
J2 CHECK CIRCUITS 267 (BR/LG) AND 268 (BK/	O) FOR OPEN
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
1	1 Measure the resistance between memory set



PINPOINT TEST K: NO COMMUNICATION WITH THE MODULE — UNABLE TO PERFORM ON-DEMAND SELF-TEST WITH THE DRIVER SEAT MODULE

CONDITIONS	DETAILS/RESULTS/ACTIONS
K1 CHECK VEHICLE FOR MEMORY SEAT/MIRROR OPTION	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.	
NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.	
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.	
NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.	
NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.	
NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.	
	Deactivate the supplemental restraint system. Refer to <u>Section 501-20B</u> .









	Is the resistance less than 5 ohms?
	→ Yes REFER to <u>Section 418-00</u> .
	→ No REPAIR Circuit 570 (BK/W). TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
K8 CHECK DSM FOR TRANSMISSION RANGE SI P/N_SW	ENSOR INPUT — MONITOR THE DSM PID
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible
	1 Monitor the DSM PID P/N_SW while moving the transmission gear shift lever through entire range.
	 Does the PID value agree with the gear shift lever positions?
	→ Yes INSTALL a new DSM. REFER to <u>Seat</u> <u>Module—Driver, 6-Way Power</u> . TEST the system for normal operation. REACTIVATE the supplemental restraint system. REFER to <u>Section 501-20B</u> .
	→ No GO to <u>K9</u> .
K9 CHECK CIRCUIT 1000 (R/BK) FOR OPEN	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
1	1 Measure the resistance between DSM C337-20, Circuit 1000 (R/BK), and fuse



PINPOINT TEST L: THE HEATED SEAT IS INOPERATIVE

CONDITIONS	DETAILS/RESULTS/ACTIONS
L1 CHECK FOR VOLTAGE TO THE HEATED SEAT MODULES — CIRCUIT 1048 (LB/WH)	
WARNING: The restraint system diagnosti Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	c tool is for restraint system service only. to remove could result in injury and possible
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.	
NOTE: Airbag simulators (restraint system diagnos side airbag to floor connector.	tic tools) MUST be installed under the seats in the

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.



L2 CHECK FOR VOLTAGE TO THE HEATED SEAT SWITCHES AND MODULES — CIRCUIT 1003 (GY/YE) WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. 1 2 2 Disconnect inoperative heated seat switch C371 (driver) or C343 (passenger). 3 4 4 Measure the voltage between heated seat switch C371 (driver) or C343 (passenger), circuit 1003 (GY/YE), and ground; and ____ between heated seat module C370-6 (driver) or C340-6 (passenger), circuit 1003 (GY/YE), and ground. GR3569-A • Are the voltages greater than 10 volts? [→] Yes GO to L3. \rightarrow No REPAIR circuit 1003 (GY/YE). TEST the system for normal operation. Vehicles equipped with side air bags, REACTIVATE the seat supplemental restraint system. For additional information, refer to Section 501-20B. L3 CHECK PASSENGER HEATED SEAT MODULE(S) GROUND — CIRCUIT 57 (BK) WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. 1 1 Measure the resistance between heated seat module C370 (driver) or C340 (passenger),
















REACTIVATE the seat supplemental restraint system. For additional information, refer to Section 501-20B.
→ No REPAIR circuit 1061 (BR/LB). TEST the system for normal operation. Vehicles equipped with side air bags, REACTIVATE the seat supplemental restraint system. For additional information, refer to <u>Section 501-</u> <u>20B</u> .

PINPOINT TEST M: THE HEATED SEAT IS INOPERATIVE — SEAT DOES NOT HEAT BUT THE HEATED SEAT SWITCH ILLUMINATES WHEN PRESSED

CONDITIONS	DETAILS/RESULTS/ACTIONS		
M1 CHECK THE HEATED SEAT CIRCUITRY FO	M1 CHECK THE HEATED SEAT CIRCUITRY FOR OPEN AND SHORT TO GROUND		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.			
NOTE: If a seat equipped with a seat mounted side must be deactivated per the deactivation procedure car/truck service manual.	airbag system is being serviced the airbag system contained in <u>Section 501-20B</u> of the appropriate		
NOTE: Airbag simulators (restraint system diagnost side airbag to floor connector.	tic tools) MUST be installed under the seats in the		
NOTE: Diagnostics or repairs are not to be perform vehicle. Prior to attempting to diagnose/repair the si the vehicle and the restraint system diagnostic tool floor connector. The restraint system diagnostic too	ed on a side airbag system with the seat in the ide airbag system the seat must be removed from must be installed in side airbag connector at the I must be removed prior to operating the vehicle.		
NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.			
NOTE: After diagnosing/repairing a seat system the before operating the vehicle.	estraint system diagnostic tool must be removed		
	1 NOTE: Before disconnecting the battery, raise the seat to its highest position, then move and tilt the seat to its most forward position.		
	Vehicles equipped with side air bags, prepare the vehicle for seating diagnostics.		
	 Deactivate the air bag system. For additional information, refer to <u>Section 501-20B</u>. 		
	 With the air bag system deactivated, position the seats in the vehicle. Connect the seat system electrical connectors. 		
2			











PINPOINT TEST N: THE HEATED SEAT IS INOPERATIVE — SEAT DOES HEAT BUT THE HEATED SEAT SWITCH DOES NOT ILLUMINATE WHEN PRESSED

CONDITIONS	DETAILS/RESULTS/ACTIONS	
N1 CHECK FOR VOLTAGE TO THE HEATED SEAT MODULE — CIRCUIT 461 (OG)		

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.







Component Test

Switch — Seat Regulator Control

Seat Regulator Control Switch



Remove the seat regulator control switch. Measure the resistance between the following indicated terminals while pressing the requested switches.

Switch	Terminals	
Front Tilt Up	5 and 4	7 and 2
Front Tilt Down	7 and 4	5 and 2
Rear Tilt Up	6 and 4	1 and 2
Rear Tilt Down	1 and 4	6 and 2
Seat Up	5, 6 and 4	1, 7 and 2
Seat Down	1, 7 and 4	5, 6 and 2
Seat Forward	3 and 4	8 and 2
Seat Rearward	8 and 4	3 and 2

The resistance should be less than 5 ohms for each direction.

If the resistance is not less than 5 ohms for each switch, replace the switch; otherwise, return to the calling pinpoint test.

Switch — Memory Set

Memory Set Switch



Remove the memory set switch.

Measure the resistance between the following indicated terminals while pressing the requested switches.

Switch	Terminals
Memory Switch 1	6 and 4
Memory Switch 2	6 and 3
Memory Set Switch	6 and 1

The resistance should be less than 5 ohms for each switch position.

If the resistance is not less than 5 ohms for each switch, replace the switch; otherwise, return to the calling Pinpoint Test.

Switch	Terminals
Memory Switch LED	8 and 9

NOTE: Refer to Multimeter User's Manual for testing diodes.

To check the memory set switch LED, connect the positive meter lead to terminal 8 and the negative lead to terminal 9. The meter should indicate greater than 0.3 volts. Reversing the leads, the meter should read OL.

If the meter readings are not as indicated above, replace the switch; otherwise, return to the calling Pinpoint Test.

SECTION 501-10: Seating REMOVAL AND INSTALLATION

Switch —6-Way Power Seat, Sport Bucket

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 1. Deactivate the supplemental restraint system. For additional information, refer to <u>Section 501-20B</u>.
- 2. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Front Bucket</u>, Removal and Installation.

Remove the front seat. For additional information, refer to <u>Seat—Front Bucket</u>.

3. Remove the lumbar support knob.



4. Remove the rear side shield screw.



5. CAUTION: To prevent damage to the side shield, the clips must be depressed in order to release the side shield from the cushion pan.

Release the side shield clips.



6. Unhook the side shield from the seat latch.



7. If equipped, disconnect the heated seat switch electrical connector.



- 8. Remove the side shield.
 - Disconnect the electrical connector.
 Remove the side shield.



- 9. Remove the 6-way power seat switch.
 - 1. Remove the screws.
 - 2. Remove the 6-way power seat switch.



Installation

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

- 1. To install, reverse the removal procedure.
- 2. Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 3. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 4. Check the restraint system for proper operation.

SECTION 501-10: Seating REMOVAL AND INSTALLATION

Switch —6-Way Power Seat, Limited

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 1. Deactivate the supplemental restraint system. For additional information, refer to <u>Section 501-20B</u>.
- 2. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Front Bucket</u>, Removal and Installation.

Remove the front seat. For additional information, refer to <u>Seat—Front Bucket</u>.

3. Disconnect the power seat switch electrical connector.



4. Remove the front seat cushion side shield rear screw.



5. Remove the front seat cushion side shield screws.



6. CAUTION: Use care when disconnecting the seat cushion side shield from the seat cushion frame so the tabs on the seat cushion side shield are not damaged.

Disconnect the front seat cushion side shield.



7. Disconnect the lumbar support control switch electrical connector.



8. Disconnect the lumbar support adjusting hoses (65528) from the adjusting switch.



9. If equipped, disconnect the heated seat switch electrical connector.



10. Remove the front seat cushion side shield.



- 11. Remove the 6-way power seat switch.
 - 1. Remove the screws.
 - 2. Remove the 6-way power seat switch.



Installation

1. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

To install, reverse the removal procedure.

- 2. Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 3. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 4. Check the restraint system for proper operation.

SECTION 501-10: Seating REMOVAL AND INSTALLATION

Switch —Heated Seat, Sport Bucket

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 1. Deactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 2. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Front Bucket</u>, Removal and Installation.

Remove the front seat. For additional information, refer to <u>Seat—Front Bucket</u>.

3. Remove the lumbar support knob.



4. Remove the rear side shield screw.



5. Release the side shield clips.



6. Disconnect the heated seat switch electrical connector.



7. Remove the heated seat switch.



Installation

1. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

To install, reverse the removal procedure.

- 2. Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 3. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 4. Check the restraint system for proper operation.

SECTION 501-10: Seating REMOVAL AND INSTALLATION

Switch —Heated Seat, Limited

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 1. Deactivate the supplemental restraint system. For additional information, refer to <u>Section 501-20B</u>.
- 2. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Front Bucket</u>, Removal and Installation.

Remove the front seat. For additional information, refer to <u>Seat—Front Bucket</u>.

3. Disconnect the power seat switch electrical connector.



4. Remove the front seat cushion side shield rear screw.



5. Remove the front seat cushion side shield screws.



6. CAUTION: Use care when disconnecting the seat cushion side shield from the seat cushion frame so the tabs on the seat cushion side shield are not damaged.

Disconnect the front seat cushion side shield.



7. Disconnect the lumbar support control switch electrical connector.



8. Disconnect the lumbar support adjusting hoses (65528) from the adjusting switch.



9. Disconnect the heated seat switch electrical connector.



10. Remove the front seat cushion side shield.



11. Remove the heated seat switch.



Installation

1. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

To install, reverse the removal procedure.

- 2. Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 3. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 4. Check the restraint system for proper operation.

Seat — Front Bucket

Special Tool(s)



Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live side air bag module down on the cover tear seam. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking

components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

NOTE: A repair is made by replacement only. If a part is replaced and the new part does not correct the condition, install the original part and carry out the diagnostic procedure again.

NOTE: If a side air bag deployment took place the seatback pad, trim cover, and side air bag module must be replaced. The seatback frame should be replaced if necessary.

- 1. Deactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 2. On 6-way power seat equipped vehicles, position the seat in the full up position.
- 3. Disconnect the battery ground cable (14301) and wait at least one minute.
- 4. Remove the front seat track rear bolt covers.



GR0786-A

5. Remove the bolts.



6. Remove the slide bar bolt cover plug.



7. Using the Safety Belt Bolt Bit, remove the bolt.



8. Remove the front seat track to floor front bolts.



- 9. Disconnect the safety belt warning indicator electrical connector.
- 10. If equipped, disconnect the side air bag electrical connector.
- 11. On 6-way power seat equipped vehicles, lean the seat back and disconnect the electrical connectors.



12. CAUTION: Use care when handling the seat and track assembly. Dropping the assembly or sitting on a seat not secured in the vehicle may result in damaged components.

Remove the front seat.

Installation

- 1. Position the front seat.
 - On 6-way power seat equipped vehicles, connect the electrical connectors.



2. If equipped, connect the side air bag electrical connector.

- 3. Connect the safety belt warning indicator electrical connector.
- 4. Install the front seat track to floor bolts.



5. Using the special tool, install the slide bar bolt.



6. Install the slide bar bolt cover plug.



7. Install the rear front seat track bolts.


8. Install the rear front seat track bolt covers.



9. **NOTE:** When the battery (10655) is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 mi) or more to relearn the strategy.

On 6-way power seat equipped vehicles, connect the battery ground cable.

10. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 11. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 12. Check the restraint system for proper operation.

Seat — Rear, 40% Portion of 60/40 Split Bench

Removal and Installation

For additional information, refer to Seat-Rear, 60% Portion of 60/40 Split Bench in this section.

Seat — Rear, 50/50 Split Bench

Special Tool(s)



Removal

- 1. Fold the rear seat cushion assembly forward.
- 2. Remove the retaining nut from the end of the link arm and slide the link arm off the stud on the seat cushion frame.



- 3. Return the seat back assembly to the upright position.
- 4. Remove the retaining nuts from the front floor attachment.



- 5. Remove the seat cushion assembly from the vehicle.
- 6. Use Safety Belt Bolt Bit to remove the safety belt bolt.



7. Remove the rear outboard nut.



8. Slide the seat back assembly off the center pivot bracket and remove the seat back assembly from the vehicle.



Installation

- 1. Install the seat back (with link arm) onto the pin on the center pivot bracket and position the seat onto the floor pan.
- 2. Install the rear outboard nut.



3. Use Safety Belt Bolt Bit to install the rear outboard bolt.



- 4. Install the seat cushion.
 - Install the nuts.



5. Install the link arm nut.





Seat — Rear, 60% Portion of 60/40 Split Bench

Removal

NOTE: 60 percent rear seat shown; 40 percent rear seat similar.

1. Remove the rear outboard nut and bolt.



2. **NOTE:** Remove the plastic caps from the studs.

Remove the rear seat riser to floor nuts.



- 3. Fold the rear seat down.
- 4. Remove the rear seat.
 - Pivot the seat to unhook the tab from the safety belt buckle bracket.



Installation

1. To install, reverse the removal procedure.



SECTION 501-10: Seating REMOVAL AND INSTALLATION

Seat — Track, Front Manual

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

CAUTION: Use care when handling the seat and track assembly. Dropping the assembly or sitting on a seat not secured in the vehicle may result in damaged components.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 1. Deactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 2. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Front Bucket</u>, Removal and Installation.

Remove the front seat. For additional information, refer to Seat-Front Bucket.

3. Place the front seat (60012) upside-down on a clean workbench.

- 4. Remove the safety belt buckle slide bar.
 - 1. Remove the nut.
 - 2. Remove the bolt.
 - 3. Remove the safety belt buckle slide bar.



5. Remove the seat track to seat cushion front bolts.



- 6. Remove the front seat track (61705).
 - 1. Remove the seat track to seat cushion rear bolts.
 - 2. Remove the front seat track.



Installation

- 1. Install the front seat track front bolts.
 - 1. Position the front seat track.
 - 2. Install the inboard bolt.
 - 3. Install the outboard bolt.



- 2. Install the front seat track rear bolts.
 - 1. Install the inboard bolt.
 - 2. Install the outboard bolt.



- 3. Install the safety belt buckle slide bar.
 - 1. Position the safety belt buckle slide bar.
 - 2. Install the nut.
 - 3. Install the bolt.



4. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Front Bucket</u>, Removal and Installation.

Install the front seat. For additional information, refer to Seat—Front Bucket.

5. A WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 6. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 7. Check the restraint system for proper operation.

SECTION 501-10: Seating REMOVAL AND INSTALLATION

Seat — Track, Limited and 6-Way Power

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

CAUTION: Use care when handling the seat and track assembly. Dropping the assembly or sitting on a seat not secured in the vehicle may result in damaged components.

NOTE: LHD seats shown, RHD seat similar.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 1. Deactivate the supplemental restraint system. For additional information, refer to <u>Section 501-20B</u>.
- 2. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Front Bucket</u>, Removal and Installation.

Remove the front seat. For additional information, refer to <u>Seat—Front Bucket</u>.

- 3. Place the seat on a clean workbench.
- 4. Remove the safety belt buckle slide bar.
 - 1. Remove the nut.
 - 2. Remove the bolt.
 - 3. Remove the safety belt buckle slide bar.



- 5. Disconnect the seat track wiring harness electrical connectors.
 - If equipped, disconnect the memory seat module electrical connectors.
 - Disconnect the seat track motor electrical connectors.



- 6. Remove the seat track.
 - 1. Remove the bolts.
 - 2. Remove the seat track.



Installation

1. **NOTE:** When installing the power seat track, start at the corner with the round hole and work around the seat base in a horseshoe pattern.

To install, reverse the removal procedure.



2. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 3. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 4. Check the restraint system for proper operation.



SECTION 501-10: Seating REMOVAL AND INSTALLATION

Seat Module —Heated Seat

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage may result.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 1. Deactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 2. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Track, Limited and 6-Way</u> <u>Power</u>, Removal and Installation.

Remove the power front seat track. For additional information refer to <u>Seat—Track, Limited and 6-</u> <u>Way Power</u>.

3. Disconnect the heated seat module electrical connector.



- 4. Remove the heated seat module.
 - 1. Release the clip.
 - 2. Remove the heated seat module.



Installation

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage may result.

1. Install the heated seat module.



2. Connect the heated seat module electrical connector.



3. **NOTE:** Be sure to read and follow all air bag warnings contained in <u>Seat—Track, Limited and 6-Way</u> <u>Power</u>, Removal and Installation.

Install the power front seat track. For additional information, refer to <u>Seat—Track, Limited and 6-Way</u> <u>Power</u>.

4. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 5. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 6. Check the restraint system for proper operation.

SECTION 501-10: Seating REMOVAL AND INSTALLATION

Side Air Bag Wiring Harness

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live side air bag module down on the cover tear seam. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: A side air bag repair is made by installing a new component only. If a part is replaced and the new part does not correct the condition, install the original part and carry out the diagnostic procedure again.

All Seats

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

- 1. Deactivate the supplemental restraint system. For additional information, refer to Section 501-20B.
- 2. **NOTE:** Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, 6-Way Power, Except</u> <u>Limited</u>, <u>Seat—Front Bucket</u>, <u>Limited</u>, or <u>Seat—Front Bucket</u>, <u>Manual</u>, Disassembly and Assembly.

Disassemble the seat. For additional information, refer to <u>Seat—Front Bucket, 6-Way Power, Except</u> <u>Limited</u>, <u>Seat—Front Bucket</u>, <u>Limited</u> or <u>Seat—Front Bucket</u>, <u>Manual</u>.

3. **WARNING:** Front seat back trim covers installed on seats equipped with side air bags cannot be repaired. They are to be replaced (cleaning is permissible).

Unhook the trim cover J-clip.



- 4. Remove the seat backrest trim cover swing rods.
 - 1. Remove and discard the hog rings.
 - 2. Remove the seat backrest trim cover cushion swing rods.



5. CAUTION: Use care when separating the seat cushion trim cover from the hook and loop strip, or the hook and loop strip can be torn from the seat cushion foam.

Roll the seatback trim cover in an inside out fashion to the side air bag deployment chute.



Limited Seat

- 6. Roll the seat backrest trim cover to the first row of hog rings.
- 7. Remove and discard the hog rings.
- 8. Roll the seat backrest trim cover to the second row of hog rings.



9. Remove and discard the hog rings.



10. Roll the seat backrest trim cover to the side air bag deployment chute.

All Seats

11. Unzip the side air bag deployment chute.



Sport Bucket

12. Roll the seat backrest cover and side air bag deployment chute to completely expose the side air bag bracket and side air bag module.



Limited Seat

13. Roll the seat backrest trim cover to the third row of hog rings.



14. Remove and discard the hog rings.



All Seats

15. Remove the side air bag wiring harness wire tie.



16. **NOTE:** If installing a new side air bag module, use new retaining nuts. If the same side air bag module is to be reused, then reuse the side air bag module retaining nuts.

Through the seat backrest cushion opening, position the side air bag module aside.

• Remove the retaining nuts.



- 17. Remove the side air bag module.
 - 1. Release the side air bag module electrical connector clip.
 - 2. Release the connector tabs by pushing in on them, then disconnect the side air bag module electrical connector.
 - 3. Remove the side air bag module.



18. NOTE: Sport bucket seat shown; Limited seat similar.

NOTE: The seat backrest components other than the seat backrest frame and side air bag wiring harness have been omitted for clarity.

Remove the side air bag wiring harness.

• Disconnect the pin-type retainers from the seat backrest frame.



Installation

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Check the side air bag deployment chute and zipper for damage. The deployment chute and zipper must not be repaired. If there is any damage to the deployment chute or zipper, the seat back trim cover and deployment chute must be installed new as a unit. Failure to do so may result in personal injury.

WARNING: The deployment seam cannot be repaired or resewn. A trim cover requiring replacement of the bolster or side facing must be replaced as a unit.

WARNING: If the air bag deployment chute is not properly positioned and completely zipped, the side air bag may not deploy properly. Failure to follow these instructions may result in personal injury.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

All Seats

1. **NOTE:** The seat backrest components other than the seat backrest frame and side air bag wiring harness have been omitted for clarity.

NOTE: Sport bucket seat shown; Limited seat similar.

Install the side air bag wiring harness.

• Connect the pin-type retainer to the seat backrest frame.



- 2. Connect the side air bag module electrical connector.
 - 1. Install the connector to the side air bag module.
 - 2. Slide the side air bag module electrical connector locking clip to secure the connector to the side air bag module.



- 3. Make sure the electrical connector is securely fastened to the side air bag module.
- 4. WARNING: Inspect the mounting surfaces of the side air bag module and the seat back frame mounting bracket for any foreign objects before installing the side air bag module. If any foreign objects are found, remove them. Failure to do so may result in personal injury, in the event of an air bag deployment.

WARNING: Inspect the side air bag deployment chute and the side air bag cavity in the seat back pad for any foreign objects. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury, in the event of an air bag deployment.

WARNING: If the air bag cover has separated or the air bag material has been exposed, install a new side air bag module. Do not attempt to repair the air bag module. Failure to do so may result in personal injury in the event of an air bag deployment.

CAUTION: The retaining nuts of the side air bag module must be tightened in the sequence described.

CAUTION: Be sure the side air bag wiring harness is not pinched between the side air bag module and mounting bracket.

Install the side air bag module onto the front seat back frame mounting bracket.

- 1. Position the side air bag module onto the front seat back mounting bracket being sure the side air bag wiring harness is located behind the seat backrest frame.
- 2. Install the side air bag module retaining nut.
- 3. Install the side air bag module retaining nut.
- 4. Install the side air bag module retaining nut.



5. Tie-strap the side air bag module wire harness to the seat back frame.



Limited Seats

6. Unroll the seat backrest trim cover to the third row of hog rings.



7. Install the hog rings.



All Seats

8. Roll the seat back trim cover to position the deployment chute around the side air bag module.



9. WARNING: Check the side air bag deployment chute and zipper for damage. The deployment chute and zipper must not be repaired. If there is any damage to the deployment chute or zipper the seat back trim cover and deployment chute must be installed new as a unit.

WARNING: If the air bag deployment chute is not properly positioned and completely zipped, the side air bag may not deploy properly.

Position the air bag deployment chute.

- 1. Insert the outboard side of the air bag deployment chute between the seat back pad and the side air bag module, pulling it around the outboard side of the seat back frame.
- 2. Insert the inboard side of the air bag deployment chute between the seat back pad and the

side air bag module from the inboard side of the seat back.



10. NOTE: Sport bucket seat shown; Limited seat similar.

NOTE: Be sure the side air bag deployment chute is properly positioned, before proceeding to the next step.

Zip the air bag deployment chute completely closed, then position the zipper tails at the top and bottom of the deployment chute, into the seat back opening.

- The side air bag deployment chute must encircle the side air bag module, going completely around the side air bag module and the side of the seat back frame.
- Align the side air bag deployment chute to the side air bag module, making sure it covers the length of the side air bag module.



Limited Seat

11. Unroll the seat backrest trim cover to the second row of hog rings.



12. Install the hog rings.



- 13. Unroll the seat backrest trim cover to the bottom row of hog rings.
- 14. Install the hog rings.

Sport Bucket Seat

15. **NOTE:** Make sure that the top of the swing rod is positioned beneath the listing wire near the middle row of hog rings.

If equipped, install the seat backrest trim cover swing rods.

- 1. Position the seat backrest trim cover and install the swing rods through the sleeves.
- 2. Install the hog rings.



- 16. Connect the hook and loop fastener to the seat backrest trim cover.
 - 1. Pull the seat backrest trim cover completely down.
 - 2. Reach up inside the seat backrest and grab the plastic above the hook and loop. Remove enough plastic to expose the hook and loop.



All Seats

17. **NOTE:** If equipped, make sure that the seat backrest heating element wire is aligned with and off-set from the lower seat backrest trim cover J-clip.

Hook the trim cover clip.



18. **NOTE:** Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, 6-Way Power, Except</u> <u>Limited</u> and <u>Seat—Front Bucket, Limited</u>, Disassembly and Assembly.

Assemble the seat. For additional information, refer to <u>Seat—Front Bucket, 6-Way Power, Except</u> <u>Limited</u> and <u>Seat—Front Bucket, Limited</u>.

19. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 20. Prove out the air bag system. For additional information, refer to Section 501-20B.
- 21. Check the restraint system for proper operation.

Seat —40% Portion of Front 60/40 Split Bench

Disassembly

1. The disassembly of the 40% portion of the front 60/40 split bench is similar to the manual front bucket seat. For additional information, refer to <u>Seat—Front Bucket, Limited</u>.

Assembly

1. The assembly of the 40% portion of the front 60/40 split bench is similar to the manual front bucket seat. For additional information, refer to <u>Seat—Front Bucket, Manual</u>.
Seat —60% Portion of Front 60/40 Split Bench

Disassembly

- 1. Remove the seat track. For additional information, refer to <u>Seat—Track, Front Manual</u>.
- 2. Remove the seat backrest latch cover.
 - 1. Remove the screw.
 - 2. Remove the seat backrest latch cover.



3. Remove the front seat backrest latch to seat cushion bolts.



4. Remove the inboard pivot bolt and separate the seat cushion from the seat backrest.



- 1. To assemble, reverse the disassembly procedure.
 - Check the restraint system for proper operation.



Seat — Back, 40% Portion of Front 60/40 Split Bench

Disassembly

1. For the disassembly of the 40 percent front seat backrest, refer to <u>Seat—Back, Front Bucket,</u> <u>Manual</u>.

Assembly

1. For the assembly of the 40 percent front seat backrest, refer to Seat-Back, Front Bucket, Manual.

Seat — Back, 40% Portion of Rear 60/40 Split Bench

Disassembly

- 1. Disassemble the rear 40 percent seat. For additional information, refer to <u>Seat—Rear, 40% Portion of</u> <u>60/40 Split Bench</u>.
- 2. Unhook the seat backrest trim cover J-clip.



3. CAUTION: Use care when separating the seat backrest trim cover from the hook and loop strip or the hook and loop strip may be torn from the seat backrest foam.

Disengage the hook and loop strip and remove the seat backrest trim cover.



4. Remove the seat backrest frame from the seat backrest foam.



GR0726-B

- 5. Remove the rear seat backrest latch.
 - 1. Remove the bolt.
 - 2. Remove the rear seat backrest latch.



Assembly

- 1. Install the rear seat backrest latch.
 - 1. Position the rear seat backrest latch.
 - 2. Install the bolt.



2. Install the seat backrest frame into the seat backrest foam.



- 3. Install the seat backrest trim cover.
 - Connect the hook and loop strip to the seat backrest trim cover.



4. Hook the seat backrest trim cover J-clip.



5. Assemble the rear 40 percent seat. For additional information, refer to <u>Seat—Rear, 40% Portion of 60/40 Split Bench</u>.

Seat — Back, 60% Portion of Front 60/40 Split Bench

Disassembly

- 1. Disassemble the seat. For additional information, refer to <u>Seat—60% Portion of Front 60/40 Split</u> <u>Bench</u>.
- 2. Remove the armrest bolt cover.



- 3. Remove the armrest.
 - 1. Remove the bolt.
 - 2. Remove the armrest.



4. Disassemble the seat backrest. For additional information, refer to <u>Seat—Back, Front Bucket,</u> <u>Manual</u>.

Assembly

1. To assemble, reverse the disassembly procedure.



Seat — Back, 60% Portion of Rear 60/40 Split Bench

Disassembly

- 1. Disassemble the rear 60 percent seat. For additional information, refer to <u>Seat—Rear, 60% Portion of 60/40 Split Bench</u>.
- 2. Unhook the J-clips.
- 3. CAUTION: Use care when separating the seat backrest trim cover from the hook and loop strip or the hook and loop strip may be torn from the seat backrest foam.

Disengage the hook and loop strips and remove the seat backrest trim cover.



4. Remove the seat backrest padding.



Assembly

1. Install the seat backrest foam.



2. Install the seat backrest trim cover and connect the hook and loop strips.



- 3. Connect the seat backrest trim cover J-clip.
- 4. Assemble the rear 60 percent seat. For additional information, refer to <u>Seat—Rear, 60% Portion of 60/40 Split Bench</u>.

Seat —Back, Front Bucket, 6-Way Power, Except Limited

Disassembly

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live side air bag module down on the cover tear seam. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: A side air bag repair is made by installing a new component only. If a part is replaced and the new part does not correct the condition, install the original part and carry out the diagnostic procedure again.

NOTE: If a side air bag deployment took place the seat back pad, trim cover, and side air bag module must be replaced. The seatback frame should be replaced if necessary.

NOTE: Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, 6-Way Power, Except</u> <u>Limited</u>, Disassembly and Assembly.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

1. **NOTE:** Before disconnecting the battery, raise the seat to its hightest position, then move and tilt the seat to its most forward position.

Deactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

2. Disassemble the 6-way power front bucket seat. For additional information, refer to <u>Seat—Front</u> <u>Bucket, 6-Way Power, Except Limited</u>.

3. **WARNING:** Front seat back trim covers installed on seats equipped with side air bag cannot be repaired. They are to be replaced (cleaning is permissible).

Unhook the trim cover J-clip.



- 4. Remove the seat backrest trim cover swing rods.
 - 1. Remove and discard the hog rings.
 - 2. Remove the seat backrest trim cover cushion swing rods.



5. CAUTION: Use care when separating the seat cushion trim cover from the hook and loop strip, or the hook and loop can be torn from the seat cushion foam.

If equipped, roll the seatback trim cover in an inside out fashion to the side air bag deployment chute.



6. If equipped, unzip the side air bag deployment chute.



7. Roll the seat backrest trim cover up to expose the lower row of hog rings.



8. If equipped, remove the side air bag wiring harness wire tie.



9. **NOTE:** If installing a new side air bag module use new retaining nuts. If the same side air bag module is to be used, then reuse the side air bag module retaining nuts.

If equipped, through the seat backrest cushion opening, position the side air bag module aside.

• Remove the retaining nuts.



- 10. If equipped, remove the side air bag module.

 - Slide the side air bag module electrical connector clip.
 Release the connector tabs by pushing in on them, then disconnect the side air bag module electrical connector.
 - 3. Remove the side air bag module.



11. Remove and discard the lower row hog rings.



- 12. On leather seats, pull the seat backrest trim cover up to expose the upper row of hog rings.
- 13. On leather seats, remove and discard the upper row hog rings.



- 14. Remove the seat backrest trim cover.
- 15. Remove the plastic bag.



- 16. Remove the seat backrest frame from the seat backrest foam.
 - 1. Remove the J-clip.
 - 2. NOTE: The seat backrest foam may be glued to the seat backrest frame.

Remove the seat backrest frame from the seat backrest foam.



- 17. Remove the front seat backrest latch.
 - 1. Remove the bolts.
 - 2. Remove the front seat backrest latch.



18. Remove the plastic bag from the top of the seat backrest frame.



- 19. Remove the lumbar support adjuster.
 - Release the clips.



20. CAUTION: Any time the seat backrest heating element is removed from the seat backrest foam, the foam must be replaced.

If equipped, remove the seat backrest heating element from the seat backrest foam.



- 21. If equipped, remove the side air bag wiring harness.
 - Disconnect the pin-type retainers from the seat backrest frame.



Assembly

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Check the side air bag deployment chute and zipper for damage. The deployment chute and zipper must not be repaired. If there is any damage to the deployment chute or zipper, the seat back trim cover and deployment chute must be installed new as a unit. Failure to do so may result in personal injury.

WARNING: The deployment seam cannot be repaired or resewn. A trim cover requiring replacement of the bolster or side facing must be replaced as a unit.

WARNING: If the air bag deployment chute is not properly positioned and completely zipped, the side air bag may not deploy properly. Failure to follow these instructions may result in personal injury.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

- 1. If equipped, install the side air bag wiring harness.
 - Connect the pin-type retainer to the seat backrest frame.



2. If equipped, install the seat backrest heating element.



- 3. Install the lumbar support adjuster.
 - Clip the ends to the seat backrest frame.



4. Install the plastic bag on the top of the seat backrest frame.



- 5. Install the front seat backrest latch (62648).
 - 1. Position the front seat backrest latch.
 - 2. Install the bolts.



- 6. Install the seat backrest frame into the seat backrest foam.
 - 1. Install the seat backrest frame into the seat backrest foam.
 - 2. Install the J-clip.



7. Install the plastic bag over the seat backrest.



- 8. Pull the seat backrest trim cover to the upper cutout in the seat backrest.
- 9. On leather seat, install the upper row of hog rings.



- 10. Pull the seat backrest trim cover to the lower cutout in the seat backrest.
- 11. Install the lower row of hog rings.



- 12. If equipped, connect the side air bag module electrical connector.
 - 1. Plug the electrical connector into the side air bag module.
 - 2. Slide the locking clip into position.



- 13. If equipped, make sure the side air bag module electrical connector is securely fastened to the side air bag module.
- 14. WARNING: Inspect the mounting surfaces of the side air bag module and the seat back frame mounting bracket for any foreign objects before installing the side air bag module. If any foreign objects are found, remove them. Failure to do so may result in personal injury, in the event of an air bag deployment.

WARNING: Inspect the side air bag deployment chute and the side air bag cavity in the seat back pad for any foreign objects. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury, in the event of an air bag deployment.

WARNING: If the air bag cover has separated or the air bag material has been exposed, install a new side air bag module. Do not attempt to repair the air bag module. Failure to do so may result in personal injury in the event of an air bag deployment.

CAUTION: The retaining nuts of the side air bag module must be tightened in the sequence described.

CAUTION: Be sure the side air bag wiring harness is not pinched between the side air bag module and the mounting bracket.

If equipped, install the side air bag module onto the front seat back frame mounting bracket.

- 1. Position the side air bag module onto the front seat back mounting bracket being sure the side air bag wiring harness is located behind the seat backrest frame.
- 2. Install the side air bag module retaining nut.
- 3. Install the side air bag module retaining nut.
- 4. Install the side air bag module retaining nut.



15. If equipped, install the side air bag wiring harness wire tie.



16. If equipped, roll the seat backrest trim cover to position the deployment chute around the side air bag module.



17. WARNING: Check the side air bag deployment chute and zipper for damage. The

deployment chute and zipper must not be repaired. If there is any damage to the deployment chute or zipper the seat back trim cover and deployment chute must be installed new as a unit.

WARNING: If the air bag deployment chute is not properly positioned and completely zipped, the side air bag may not deploy properly.

If equipped, position the side air bag deployment chute.

- 1. Insert the outboard side of the air bag deployment chute between the seat back pad and the side air bag module, pulling it around the outboard side of the seat back frame.
- 2. Insert the inboard side of the air bag deployment chute between the seat back pad and the side air bag module from the inboard side of the seat back.



18. **NOTE:** Be sure the side air bag deployment chute is properly positioned, before proceeding to Step 19.

If equipped, zip the air bag deployment chute completely closed, then position the zipper tails at the top and bottom of the deployment chute, into the seat back opening.

- The side air bag deployment chute must encircle the side air bag module, going completely around the side air bag module and the side of the seat back frame.
- Align the side air bag deployment chute to the side air bag module, making sure it covers the length of the side air bag module.



19. **NOTE:** Make sure that the top of the swing rod is positioned beneath the listing wire near the lower row of hog rings.

Install the seat backrest trim cover swing rods.

- 1. Position the seat backrest trim cover and install the swing rods through the sleeves.
- 2. Install the hog rings.



- 20. Connect the hook and loop fastener to the seat backrest trim cover.
 - 1. Pull the seat backrest trim cover completely down.
 - 2. Reach up inside the seat backrest and grab the plastic above the hook and loop. Remove enough plastic to expose the hook and loop.



21. **NOTE:** If equipped, make sure that the seat backrest heating element wire is aligned with and off-set from the lower seat backrest trim cover J-clip.

NOTE: Check that the lumbar strap is secure to the wire paddle before closing the trim cover.

NOTE: If equipped with a side air bag module, check the positioning of the air bag deployment chute before closing the trim cover.

Hook the trim cover clips.



22. **NOTE:** Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, 6-Way Power, Except</u> <u>Limited</u>, Disassembly and Assembly.

Assemble the 6-way power front bucket seat. For additional information, refer to <u>Seat—Front Bucket</u>, <u>6-Way Power, Except Limited</u>.

23. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 24. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 25. Check the restraint system for proper operation.

SECTION 501-10: Seating DISASSEMBLY AND ASSEMBLY

Seat — Back, Front Bucket, Limited

Disassembly

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live side air bag module down on the cover tear seam. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: A side air bag repair is made by installing a new component only. If a part is replaced and the new part does not correct the condition, install the original part and carry out the diagnostic procedure again.

NOTE: If a side air bag deployment took place the seat back pad, trim cover, and side air bag module must be replaced. The seat back frame should be replaced as necessary.

NOTE: Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, Limited</u>, Disassembly and Assembly.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

1. **NOTE:** Before disconnecting the battery, raise the seat to its highest position, then move and tilt the seat to its most forward position.

Deactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 2. Disassemble the seat. For additional information, refer to Seat-Front Bucket, Limited.
- 3. Remove the head restraint.
 - 1. Press the head restraint release button.
 - 2. Remove the head restraint.



4. WARNING: Front seat back trim covers installed on seats equipped with side air bags cannot be repaired. They are to be replaced (cleaning is permissible).

Unhook the seat backrest trim cover J-clip.



- 5. Roll the seat backrest trim cover to the first row of hog rings.
- 6. Remove and discard the hog rings.
- 7. Roll the seat backrest trim cover to the second row of hog rings.



8. Remove and discard the hog rings.



- 9. If equipped, roll the seat backrest trim cover to the side air bag deployment chute.
- 10. **NOTE:** Sport bucket seat shown; Limited seat similar.

If equipped, unzip the side air bag deployment chute.



11. Roll the seat backrest trim cover to the top row of hog rings.



12. Remove and discard the hog rings.



13. If equipped, remove the side air bag wiring harness wire tie.



14. NOTE: If installing a new side air bag module use new retaining nuts. If the same side air bag module

is to be used, then reuse the side air bag module retaining nuts.

If equipped, through the seat backrest cushion opening, position the side air bag module aside.Remove the retaining nuts.



- 15. If equipped, remove the side air bag module.
 - 1. Slide the side air bag module electrical connector clip.
 - 2. Release the connector tabs by pushing in on them, then disconnect the side air bag module electrical connector.
 - 3. Remove the side air bag module.



- 16. Finish inverting the seat backrest trim cover.
- 17. Unhook the seat backrest foam J-clip.



18. NOTE: Removing the head restraint guide sleeves will also remove the seat backrest trim cover and the seat backrest foam.

Remove the head restraint guide sleeves.

- Position the seat backrest cushion to gain access to the head restraint guide sleeves.
 Press the head restraint guide sleeve tabs.
- 3. Remove the head restraint guide sleeve.
- Remove the head restraint guide sleeves from the seat backrest trim cover and inspect them for damage.



19. Remove the wire tie.



- 20. Remove the lumbar support adjuster.
 - 1. Open the tabs enough to remove the tension on the listing wires.
 - 2. Remove the listing wires.
 - 3. Remove the lumbar support adjuster.



21. CAUTION: Any time the seat backrest heating element is removed from the seat backrest foam, the foam must be replaced.

NOTE: Sport bucket seat shown; Limited seat similar.

If equipped, and if necessary, remove the seat backrest heating element from the seat backrest foam.



22. NOTE: Sport bucket seat shown; Limited seat similar.

If equipped, remove the side air bag wiring harness.

• Disconnect the pin-type retainers from the seat backrest frame.



Assembly

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Check the side air bag deployment chute and zipper for damage. The deployment chute and zipper must not be repaired. If there is any damage to the deployment chute or zipper, the seat back trim cover and deployment chute must be installed new as a unit. Failure to do so may result in personal injury.

WARNING: The deployment seam cannot be repaired or resewn. A trim cover requiring replacement of the bolster or side facing must be replaced as a unit.

WARNING: If the air bag deployment chute is not properly positioned and completely zipped, the side air bag may not deploy properly. Failure to follow these instructions may result in personal injury.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

1. NOTE: Sport bucket seat shown; Limited seat similar.

If equipped, install the side air bag wiring harness.

• Connect the pin-type retainers to the seat backrest frame.



2. NOTE: Sport bucket seat shown; Limited seat similar.

If equipped, and if necessary, install the seat backrest heating element.



- 3. Install the lumbar support adjuster.
 - 1. Position the lumbar support adjuster.
 - 2. Install the listing wires.
 - 3. Close the tabs enough to place tension on the listing wires without bending them.



4. Install the wire tie.



- 5. Position the seat backrest foam on the seat backrest frame.
- 6. **NOTE:** The head restraint guide sleeves are keyed; make sure they are aligned with the seat backrest frame and the head restraint guide bars before installing them in the seat backrest trim cover.

Install the head restraint guide sleeves.


7. Hook the seat backrest foam J-clip.



- 8. If equipped, connect the side air bag module electrical connector.
 - 1. Plug the electrical connector into the side air bag module.
 - 2. Slide the locking clip into position.



- 9. If equipped, make sure the side air bag module electrical connector is securely fastened to the side air bag module.
- 10. WARNING: Inspect the mounting surfaces of the side air bag module and the seat back frame mounting bracket for any foreign objects before installing the side air bag module. If any foreign objects are found, remove them. Failure to do so may result in personal injury, in the event of an air bag deployment.

WARNING: Inspect the side air bag deployment chute and the side air bag cavity in the seat back pad for any foreign objects. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury, in the event of an air bag deployment.

WARNING: If the air bag cover has separated or the air bag material has been exposed, install a new side air bag module. Do not attempt to repair the air bag module. Failure to do so may result in personal injury in the event of an air bag deployment.

CAUTION: The retaining nuts of the side air bag module must be tightened in the sequence described.

CAUTION: Be sure the side air bag wiring harness is not pinched between the side air bag module and the mounting bracket.

If equipped, install the side air bag module onto the front seat back frame mounting bracket, being sure the side air bag wiring harness is located behind the seat backrest frame.

- 1. Position the side air bag module onto the front seat back mounting bracket.
- 2. Install the side air bag module retaining nut.
- 3. Install the side air bag module retaining nut.
- 4. Install the side air bag module retaining nut.



11. If equipped, install the side air bag wiring harness wire tie.



12. Unroll the seat backrest trim cover to the top row of hog rings.



13. Install the hog rings.



- 14. If equipped, roll the seat back trim cover to position the deployment chute around the side air bag module.
- 15. WARNING: Check the side air bag deployment chute and zipper for damage. The deployment chute and zipper must not be repaired. If there is any damage to the deployment chute or zipper the seat back trim cover and deployment chute must be installed new as a unit.

WARNING: If the air bag deployment chute is not properly positioned and completely zipped, the side air bag may not deploy properly.

If equipped, position the air bag deployment chute.

1. Insert the outboard side of the air bag deployment chute between the seat back pad and the side air bag module, pulling it around the outboard side of the seat back frame.

2. Insert the inboard side of the air bag deployment chute between the seat back pad and the side air bag module from the inboard side of the seat back.



16. **NOTE:** Sport bucket seat shown; Limited seat similar.

NOTE: Be sure the side air bag deployment chute is properly positioned, before proceeding to Step 17.

Zip the air bag deployment chute completely closed, then position the zipper tails at the top and bottom of the deployment chute, into the seat back opening.

- The side air bag deployment chute must encircle the side air bag module, going completely around the side air bag module and the side of the seat back frame.
- Align the side air bag deployment chute to the side air bag module, making sure it covers the length of the side air bag module.



17. Unroll the seat backrest trim cover to the second row of hog rings.



18. Install the hog rings.



- 19. Unroll the seat backrest trim cover to the bottom row of hog rings.
- 20. Install the hog rings.
- 21. **NOTE:** If equipped, make sure that the seat backrest heating element wire is aligned with and off-set from the lower seat backrest trim cover J-clip.

Hook the seat backrest trim cover J-clip.



- 22. Install the head restraint.
 - 1. Press the head restraint release button.
 - 2. Install the head restraint.



23. **NOTE:** Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, Limited</u>, Disassembly and Assembly.

Assemble the seat. For additional information, refer to Seat—Front Bucket, Limited.

24. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Deactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 25. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 26. Check the restraint system for proper operation.

Seat —Back, Front Bucket, Manual

Disassembly

- 1. Disassemble the manual front bucket seat. For additional information, refer to <u>Seat—Front Bucket</u>, <u>Manual</u>.
- 2. Unhook the seat backrest trim cover J-clip.



3. CAUTION: Use care when separating the seat backrest trim cover from the hook and loop strip or the hook and loop strip may be torn from the seat backrest foam.

Disengage the hook and loop strips and remove the seat backrest trim cover.



- 4. Remove the seat back padding from the seat back frame.
 - 1. Remove the J-hook.
 - 2. Remove the seat back padding from the seat back frame.



- Remove the front seat backrest latch (62648).
 Remove the bolts.
 - 2. Remove the front seat backrest latch.



Assembly

- 1. Install the front seat backrest latch.
 - 1. Position the front seat backrest latch.
 - 2. Install the bolts.



- 2. Install the seat back padding into the seat back frame.
 - 1. Install the seat back frame into the seat back padding.
 - 2. Install the J-hook.



- 3. Install the seat backrest trim cover.
 - Connect the hook and loop strips to the seat backrest trim cover.



4. Hook the seat backrest trim cover J-clips.



5. Assemble the manual front bucket seat. For additional information, refer to <u>Seat—Front Bucket,</u> <u>Manual</u>.

Seat — Back, Rear 50/50 Split Bench

Disassembly

- 1. Remove the rear seat link from the seat backrest.
 - 1. Remove the bolt.
 - 2. Remove the rear seat link.



- 2. Remove the seat backrest adjuster handle.
 - 1. Remove the screw.
 - 2. Remove the seat backrest adjuster handle.



3. Disconnect the seat backrest trim cover.



4. Roll back the seat backrest trim cover.

- 1. Disconnect the pin-type retainers.
- 2. Roll back the seat backrest trim cover.



- 5. Remove the staples.
- 6. Roll back the seat backrest trim cover.
 - 1. Disconnect the pin-type retainers.
 - 2. Roll back the seat backrest trim cover.



- 7. Remove the staples.
- 8. Roll the seat backrest trim cover up completely.



9. Remove the two head restraint lock springs.



- 10. Remove the head restraint.
- 11. Remove the seat backrest foam.
- 12. Remove the head restraint guide sleeves.
 - Depress the tangs to release.



- 13. Remove the rear seat backrest latch assembly from the seat backrest.
 - 1. Remove the bolt.
 - 2. Remove the rear seat backrest latch assembly.



Assembly

1. To assemble, reverse the disassembly procedure.







Seat — Cushion, 40% Portion of Front 60/40 Split Bench

Disassembly

1. For the disassembly of the 40 percent front seat cushion, refer to <u>Seat—Cushion, Front Bucket,</u> <u>Manual</u>.

Assembly

1. For the assembly of the 40 percent front seat cushion, refer to <u>Seat—Cushion, Front Bucket, Manual</u>.

Seat — Cushion, 40% Portion of Rear 60/40 Split Bench

Disassembly

- 1. Disassemble the rear 40 percent seat. For additional information, refer to <u>Seat—Rear, 60% Portion of</u> <u>60/40 Split Bench</u>.
- 2. Remove the rear seat legs.
 - 1. Remove the pivot bolts.
 - 2. Remove the rear seat legs.



3. Unhook the seat cushion trim cover J-clips.



4. CAUTION: Use care when separating the seat cushion trim cover from the hook and loop strip or the hook and loop strip may be torn from the seat cushion foam.

Remove the seat cushion trim cover.

• Separate the seat cushion trim cover from the hook and loop strip.



5. **NOTE:** Use the brackets on the seat cushion frame to obtain the necessary leverage to unhook the rear flex mat J-clip.

Remove the seat cushion flex mat.

- 1. Unhook the rear flex mat J-clip.
- 2. Unhook the front flex mat J-clip.
- 3. Remove the seat cushion flex mat.



Assembly

1. CAUTION: The flex mat J-clips must be installed with the openings facing down or the seat cushion will be damaged.

NOTE: Use the brackets on the seat cushion frame to obtain the necessary leverage to hook the rear flex mat J-clip.

Install the seat cushion flex mat.

- 1. Position the seat cushion flex mat.
- 2. Hook the front flex mat J-clip.
- 3. Hook the rear flex mat J-clip.



2. Position the seat cushion trim cover on the seat cushion hook and loop strips.



3. Hook the seat cushion trim cover J-clips.



- 4. Install the rear seat riser pivot bolts.1. Position the rear seat legs.2. Install the rear seat riser pivot bolts.



5. Assemble the rear 40 percent seat. For additional information, refer to <u>Seat—Rear, 60% Portion of 60/40 Split Bench</u>.

Seat — Cushion, 60% Portion of Front 60/40 Split Bench

Disassembly

- 1. Disassemble the seat. For additional information, refer to <u>Seat—60% Portion of Front 60/40 Split</u> <u>Bench</u>.
- 2. Unhook the seat cushion trim cover J-clips.



3. Remove the seat cushion frame from the seat cushion foam.



- 4. Invert the seat cushion trim cover.
- 5. CAUTION: Use care when separating the seat cushion trim cover from the hook and loop strip or the hook and loop strip may be torn from the seat cushion foam.

Remove the seat cushion trim cover.

• Separate the seat cushion trim cover from the hook and loop strip.



Assembly

1. To assemble, reverse the disassembly procedure.

Seat — Cushion, 60% Portion of Rear 60/40 Split Bench

Disassembly

- 1. Disassemble the 60 percent rear seat. For additional information, refer to <u>Seat—Rear, 60% Portion of</u> <u>60/40 Split Bench</u>.
- 2. Remove the seat cushion legs.
 - 1. Remove the pivot bolts.
 - 2. Remove the seat cushion legs.



- 3. Remove the seat cushion frame from the seat cushion foam.
 - 1. Unhook the seat cushion trim cover J-clips.
 - 2. Remove the seat cushion frame from the seat cushion foam.



- 4. Invert the seat cushion trim cover.
- 5. CAUTION: Use care when separating the seat cushion trim cover from the hook and loop strip or the hook and loop strip may be torn from the seat cushion foam.

Remove the seat cushion trim cover.

• Separate the seat cushion trim cover from the hook and loop strip.



6. **NOTE:** Use the brackets on the seat cushion frame to obtain the necessary leverage to unhook the rear flex mat J-clip.

Remove the seat cushion flex mats.

- 1. Unhook the rear flex mat J-clips.
- 2. Unhook the front flex mat J-clips.
- 3. Remove the seat cushion flex mats.



Assembly

1. CAUTION: The flex mat J-clips must be installed with the openings facing down or the seat cushion foam will be damaged.

NOTE: Use the brackets on the seat cushion frame to obtain the necessary leverage to hook the rear flex mat clip.

Install the seat cushion flex mats.

- 1. Position the seat cushion flex mats.
- 2. Hook the front flex mat J-clips.
- 3. Hook the rear flex mat J-clips.



2. Position the seat cushion trim cover on the seat cushion hook and loop strips.



- 3. Install the seat cushion frame into the seat cushion foam.
 - 1. Position the seat cushion frame.
 - 2. Hook the seat cushion trim cover J-clips.



- 4. Install the seat cushion legs.
 - 1. Position the seat cushion legs.
 - 2. Install the rear seat riser pivot bolts.



5. Assemble the 60 percent rear seat. For additional information, refer to <u>Seat—Rear, 60% Portion of 60/40 Split Bench</u>.

Seat — Cushion, Front Bucket, 6-Way Power, Except Limited

Disassembly

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.

- 1. Deactivate the supplemental restraint system. For additional information, refer to <u>Section 501-20B</u>.
- 2. **NOTE:** Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, 6-Way Power, Except</u> <u>Limited</u>, Disassembly and Assembly.

Disassemble the 6-way power front bucket seat. For additional information, refer to <u>Seat—Front</u> <u>Bucket, 6-Way Power, Except Limited</u>.

3. Disconnect the seat cushion trim cover J-clips.



4. If equipped, disconnect the seat cushion heating element electrical connector.



5. Remove the seat cushion frame from the seat cushion foam.



- 6. Invert the seat cushion trim cover.
- Remove the swing rods.
 Remove and discard the hog rings.
 Remove the swing rods.



8. CAUTION: Use care when separating the seat cushion trim cover from the hook and loop strip or the hook and loop strip may be torn from the seat cushion foam.

Remove the seat cushion trim cover.



9. CAUTION: Any time the seat cushion heating element is removed from the seat cushion foam, the foam must be replaced.

If equipped, and if necessary, remove the seat cushion heating element from the seat cushion foam.



10. Remove the wire harness from the seat cushion frame.



Assembly

1. Install the wire harness.



2. If equipped, and if necessary, install the seat cushion heating element.



3. **NOTE:** When installing a new seat cushion trim cover, it may be necessary to cut a hole for the front seat back pad adjusting cable, backrest heating element electrical lead, and the side air bag wiring harness. Use the old seat cushion trim cover as a guide for the location of the hole.

Position the seat cushion trim cover.



- 4. Install the seat cushion swing rods.
 - 1. **NOTE:** Make sure the ends of the swing rods are positioned beneath the listing wires at the rear of the seat cushion foam.

Position the swing rods.

2. Install the hog rings.



- 5. Invert the seat cushion trim cover.
- 6. Connect the seat cushion trim cover J-clips.



7. **NOTE:** Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, 6-Way Power, Except Limited</u>, Disassembly and Assembly.

Assemble the 6-way power front bucket seat. For additional information, refer to <u>Seat—Front Bucket</u>, <u>6-Way Power, Except Limited</u>.

8. **WARNING:** The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and

possible violation of vehicle safety standards.

Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 9. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 10. Check the restraint system for proper operation.

SECTION 501-10: Seating DISASSEMBLY AND ASSEMBLY

Seat — Cushion, Front Bucket, Limited

Disassembly

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterward.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

NOTE: Before disconnecting the battery, raise the seat to the highest position, then move and tilt the seat to its most forward position.

- 1. Deactivate the supplemental restraint system. For additional information, refer to <u>Section 501-20B</u>.
- 2. **NOTE:** Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, Limited</u>, Disassembly and Assembly.

Disassemble the seat. For additional information, refer to Seat—Front Bucket, Limited.

- 3. Disconnect the seat backrest recliner actuator.
 - 1. Remove the screws.
 - 2. Disconnect the seat backrest recliner actuator.



- 4. If equipped, disconnect the seat cushion heating element electrical connector.
- 5. Remove the seat cushion frame from the seat cushion foam.
 - 1. Unhook the seat cushion trim cover J-clips.
 - 2. Remove the seat cushion frame from the seat cushion foam.



6. Invert the seat cushion trim cover.



7. **NOTE:** The hog rings along the front of the seat are shown, the hog rings along either side are similar.

Remove and discard the hog rings.

- 1. Fold back the seat cushion trim cover to expose the hog rings.
- 2. Remove and discard the hog rings.



8. CAUTION: Any time the seat cushion heating element is removed from the seat cushion foam, the foam must be replaced.

NOTE: Sport bucket seat shown; Limited seat similar.

If equipped, and if necessary, remove the seat cushion heating element from the seat cushion foam.



9. Disconnect the heated seat module electrical connector.



- 10. Remove the heated seat module.
 - 1. Release the clip.
 - 2. Remove the heated seat module.



- 11. Remove the driver seat module (DSM).
 - 1. Remove the screws.
 - 2. Disconnect the electrical connectors.
 - 3. Remove the DSM.



12. Disconnect the lumbar support adjusting pump electrical connector.



- 13. Remove the power seat wiring harness.1. Disconnect the pin-type retainers.

 - 2. Remove the power seat wiring harness.


- 14. Remove the flexilator.
 - 1. Remove the flexilator springs.
 - 2. Remove the flexilator.



- 15. Remove the lumbar support adjusting pump.
 - 1. Remove the bolt.
 - 2. Remove the lumbar support adjusting pump.



16. Remove the seat backrest recliner roll pins and remove the seat backrest recliners.



- 17. Disconnect the seat backrest recliners from the seat backrest recliner actuator.
 - 1. Disconnect the seat backrest recliner actuator cable housings from the seat backrest recliners.
 - 2. Unhook the seat backrest recliner actuator cables from the seat backrest recliners.



Assembly

- 1. Connect the seat backrest recliners to the seat backrest recliner actuator.
 - 1. Hook the seat backrest recliner actuator cables to the seat backrest recliners.
 - 2. Connect the seat backrest recliner actuator cable housings to the seat backrest recliners.



2. Install the seat backrest recliner roll pins.



- Install the lumbar support adjusting pump.
 Position the lumbar support adjusting pump.
 - 2. Install the bolt.



- 4. Install the flexilator.
 - 1. Position the flexilator.
 - 2. Install the flexilator springs.



- 5. Install the power seat wiring harness.1. Position the power seat wiring harness.2. Install the pin-type retainers.



6. Connect the lumbar support adjusting pump electrical connector.



- 7. Install the DSM.
 - 1. Connect the electrical connectors.
 - 2. Position the DSM.
 - 3. Install the screws.



8. **NOTE:** The hog rings along the front of the seat are shown; the hog rings along either side are similar.

Install the hog rings.

- 1. Fold back the seat cushion trim cover to the hog ring installation position.
- 2. Install the hog rings.





9. Invert the seat cushion trim cover.



- 10. Install the seat cushion frame.
 - 1. Position the seat cushion frame.
 - 2. Hook the seat cushion trim cover J-clips.



- 11. If equipped, connect the seat cushion heating element electrical connector.
- 12. Connect the seat backrest recliner actuator.
 - 1. Connect the seat backrest recliner actuator.
 - 2. Install the screws.
 - Tighten until the screws are fully seated.



13. **NOTE:** Be sure to read and follow all air bag warnings in <u>Seat—Front Bucket, Limited</u>, Disassembly and Assembly.

Assemble the seat. For additional information, refer to <u>Seat—Front Bucket, Limited</u>.

14. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from the vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Reactivate the supplemental restraint system. For additional information, refer to Section 501-20B.

- 15. Prove out the air bag system. For additional information, refer to <u>Section 501-20B</u>.
- 16. Check the restraint system for proper operation.

Seat — Cushion, Front Bucket, Manual

Disassembly

- 1. Disassemble the manual front bucket seat. For additional information, refer to <u>Seat—Front Bucket,</u> <u>Manual</u>.
- 2. Disconnect the seat cushion trim cover J-clips.



3. CAUTION: Use care when separating the seat cushion trim cover from the hook and loop strip or the hook and loop strip may be torn from the seat cushion foam.

Remove the seat cushion trim cover.

• Disconnect the seat trim cover from the hook and loop strips.



- 4. Remove the seat cushion.
 - Disconnect the front and rear J-clips.



- 5. Remove the flexilator.
 - 1. Remove the flexilator to frame springs.

 - Disengage the spring clip.
 Disengage the flexilator hooks from the seat frame.
 - 4. Remove the flexilator.



Assembly

- 1. Install the flexilator.
 - 1. Position the flexilator.
 - 2. Install the flexilator hooks to the seat frame.
 - 3. Hook the spring clip.
 - 4. Install the flexilator to frame springs.



2. Position the seat cushion trim cover on the seat cushion hook and loop strips.



3. Connect the seat cushion trim cover J-clips.



4. Assemble the manual front bucket seat. For additional information, refer to <u>Seat—Front Bucket,</u> <u>Manual</u>.

Seat — Rear, 40% Portion of 60/40 Split Bench

Disassembly

- 1. Remove the rear seat. For additional information, refer to <u>Seat—Rear, 40% Portion of 60/40 Split</u> <u>Bench</u>.
- 2. Place the rear seat on a clean workbench.
- 3. Remove the seat backrest latch handle.
 - 1. Remove the screws.
 - 2. Remove the seat backrest latch handle.



4. Remove the inboard pivot cover.



- 5. Remove the outboard pivot cover.
 - 1. Remove the screw.
 - 2. Remove the outboard pivot cover.



6. Remove the inboard pivot bolt.



7. Remove the outboard pivot bolt.



8. Remove the seat cushion.

Assembly

- 1. Position the seat cushion.
- 2. **NOTE:** Be sure to install the seat pivot washer between the seat cushion and the seat backrest to allow for smooth operation of the seat backrest.

Install the seat inboard pivot bolt.



3. Install the outboard pivot bolt.



4. Install the inboard pivot cover.



- 5. Install the outboard pivot cover.
 - 1. Position the outboard pivot cover.
 - 2. Install the screw.



- 6. Install the seat backrest latch handle.
 - 1. Position the seat backrest latch handle.
 - 2. Install the screws.



7. Install the rear seat. For additional information, refer to <u>Seat—Rear, 40% Portion of 60/40 Split</u> <u>Bench</u>.

Seat — Rear, 40% Portion of 60/40 Split Bench

Disassembly

- 1. Remove the rear seat. For additional information, refer to <u>Seat—Rear, 40% Portion of 60/40 Split</u> <u>Bench</u>.
- 2. Place the rear seat on a clean workbench.
- 3. Remove the seat backrest latch handle.
 - 1. Remove the screws.
 - 2. Remove the seat backrest latch handle.



4. Remove the inboard pivot cover.



- 5. Remove the outboard pivot cover.
 - 1. Remove the screw.
 - 2. Remove the outboard pivot cover.



6. Remove the inboard pivot bolt.



7. Remove the outboard pivot bolt.



8. Remove the seat cushion.

Assembly

- 1. Position the seat cushion.
- 2. **NOTE:** Be sure to install the seat pivot washer between the seat cushion and the seat backrest to allow for smooth operation of the seat backrest.

Install the seat inboard pivot bolt.



3. Install the outboard pivot bolt.



4. Install the inboard pivot cover.



- 5. Install the outboard pivot cover.
 - 1. Position the outboard pivot cover.
 - 2. Install the screw.



- 6. Install the seat backrest latch handle.
 - 1. Position the seat backrest latch handle.
 - 2. Install the screws.



7. Install the rear seat. For additional information, refer to <u>Seat—Rear, 40% Portion of 60/40 Split</u> <u>Bench</u>. SECTION 501-11: Glass, Frames and Mechanisms SPECIFICATIONS

General Specifications

ltem	Specification
Foam Butyl	WSB-M2G234-C
Urethane Glass Prep Essex U-401	WSB-M2G314-B
Urethane Glass Primer Essex U-402	WSB-M5B280-C
Urethane Metal Primer Essex U-413	WSB-M2G234-C
Urethane Sealant Essex U-216	WSB-M2G316-B
Urethane Sealant Essex 400-HV	WSB-M2G316-B

Torque Specifications

Description	Nm	lb-in
Battery ground cable bolt	7-10	62-89
Door trim panel screws	1.4-2.0	13-17
Equalizer bracket nuts	9-14	80-123
Inside door handle screw	7.5-10.5	67-93
Liftgate window glass-to-window glass hinge nuts	2-3	18-26
Movable quarter window hinge nuts	11-13	99-115
Power window motor nuts	5.6-9.1	50-81
Quarter window glass nuts	3-4	27-35
Rear window glass regulator nut	10-14	90-124
Rear window regulator switch plate screws	1.4-2.0	13-17
Window regulator switch plate harness assembly	2-3	18-26

Glass, Frames and Mechanisms —Glass

Windshield Glass



The windshield glass (03100) :

- Is standard plastic and glass laminate safety glass.
- Is bonded to the window opening flange with urethane sealant.

Liftgate Glass



The liftgate window glass:

- Is standard plastic and glass laminate safety glass.
- Houses the rear defogger grid.

Front Door Glass



The front door window glass:

- Is standard plastic and glass laminate safety glass.
- May be raised and lowered by use of the window regulator handle (standard).
- May be raised and lowered by use of the window regulator control switch (14529) (optional).

Rear Door Glass



The rear door window glass:

- Is standard plastic and glass laminate safety glass.
- May be raised and lowered by use of the window regulator handle (standard).
- May be raised and lowered by use of the window regulator control switch (optional).

Quarter Window Glass



The quarter window glass:

• Is standard plastic and glass laminate safety glass.

Glass, Frames and Mechanisms —Window Regulator Control

The window regulator control switch:

- Is located on each door trim panel.
- May be used to raise or lower both LH side and RH side windows from the master control on the driver door.
- Includes a window lock feature that is controlled through the master control.
- Can manually lower the driver side window when the master control is depressed longer than 0.4 seconds.
- The driver side window can be completely lowered when the master control is depressed between 0.04 and 0.4 seconds and then released.

SECTION 501-11: Glass, Frames and Mechanisms DESCRIPTION AND OPERATION

Glass, Frames and Mechanisms — Module

Features and Operation:

The generic electronic module (GEM) controls the opening of the LH driver side power window (window down motion) by activating the one touch down (OTD) window relay.

• The driver side window has two downward motions, manual mode and auto mode. The down window mode is selected by pressing the LH window regulator control switch (master control). When the GEM detects that the master control switch has been depressed for a time greater than 0.4 seconds, it enters the manual mode. If the GEM detects that the master control switch was depressed between 0.04 and 0.4 seconds, it enters the auto mode.

The power window system will operate only if:

- The ignition switch is in the RUN or ACC position (or)
- The delayed accessory feature is in the active mode.

Modes of Operation

There are two modes of operation for the power window system:

Manual Mode:

When the LH window regulator control switch is pressed to the down position, the window will move down when the LH window regulator control switch is depressed longer than 0.4 seconds.

Feature Input:

• NOTE: Delayed accessory feature must be active.

LH window regulator control switch, first down position.

Feature Output:

• OTD relay coil output (grounded when activated, open circuit when deactivated).

Auto Mode:

Auto mode provides the OTD feature. The OTD feature is activated when the LH window regulator control switch, for the LH window, is pressed between 0.04 and 0.4 seconds, and then released.

Auto mode will be terminated when any of the follow conditions are met:

- The LH window regulator control switch is pushed to the up position or down position.
- Seven seconds have elapsed since auto mode was initiated.
- A window regulator electric drive stall condition is detected on the OTD sense line inputs.

Feature Inputs:

• LH window regulator control switch inputs; refer to the LH Front Window Regulator Control Switch

Inputs Table.

- OTD sense lines, high and low (voltage difference corresponds to window current).
- NOTE: Delayed accessory feature must be active.

Door open warning lamp switches (grounded when door is ajar, open circuit when door is closed).

Feature Output:

• Down window relay coil output (grounded when activated, open circuit when deactivated).

One Touch Down Relay

The GEM controls manual down and OTD window movement with the OTD relay.

The relay is activated by applying ground directly to one side of the down window relay coil, and is deactivated by removing the ground signal.

LH Front Window Regulator Control Switch Inputs Table

	Input State		
Switch Position	UP C4-3	DOWN C4-4	OTD C4-4
OFF	GND	GND	OPEN
UP	12V	GND	OPEN
DOWN	GND	12V	OPEN

Delayed Accessory

Features and Operation:

The delayed accessory feature of the GEM provides power for the power window system. The following components are under the control of the delayed accessory relay:

- LH window regulator electric drives.
- RH window regulator electric drives.

The delayed accessory feature is active when:

- The ignition is in the RUN position or ACC position, (or)
- The ignition switch makes a transition from RUN or ACC to OFF, and all doors are closed.

NOTE: Delayed accessory is suspended (off) while the ignition is in the START position. The delayed accessory feature is re-activated when the ignition makes the transition from START to RUN. The delayed accessory feature becomes deactivated if:

- Any passenger door becomes ajar when the ignition switch is in the OFF or KEY OUT positions.
- Ten minutes have elapsed since the ignition made a transition from RUN or ACC to OFF.

Feature Inputs:

• Ignition switch RUN position: 12V on both RUN and RUN/ACC inputs.

- Ignition switch ACC position: 12V on RUN/ACC input only.
- Door open warning lamp switches (grounded when door is ajar, open when door is closed).

Feature Outputs:

Delayed accessory relay coil output (grounded when active, open circuit when inactive).

Heated Backlite and Mirror Timer

When the rear window defrost switch is pressed, a 10-minute timer is started and the GEM energizes a relay that provides battery voltage to the heated backlite and outside rearview mirror (if equipped). The rear window defrost heats up to defog the rear window or melt accumulated snow or ice.

GEM Controlled Functions

The GEM is equipped on four-wheel drive vehicles with power windows. The central timer modules (CTMs) are equipped only on two-wheel drive vehicles without power windows.

NOTE: GEM diagnostics are compatible with scan tool, while CTM diagnostics are not.

The GEM incorporates the functions of several different modules into one, and offers diagnostics to easily locate and repair concerns affecting the subsystems that it controls.

The GEM constantly monitors the systems under its control and reports a concern in the form of a diagnostic trouble code (DTC). A DTC can be retrieved with scan tool through the communications link.

The scan tool is a menu-driven tester that allows the user to run specific diagnostic tests. Scan tool can isolate faults in the GEM subsystems through a symptom-driven diagnostic procedure. Connecting the tester to the GEM communications link will not alert the GEM. If the GEM is "asleep" when then diagnostic connector is plugged in, the GEM must be "awakened." If the communication link cannot be established, it is advised to turn the ignition to RUN.

The GEM has a sleep function to minimize battery consumption. During the sleep mode, the GEM turns off all outputs and monitors the following:

- Door ajar (Both front and rear doors, and liftgate).
- Key in ignition.
- Key in RUN or ACC.
- Door handles (driver or passenger).
- Two-step unlock switch (disarm switch).
- Neutral safety switch.
- Illuminated entry request RAP module.

If a change of status occurs at one of these inputs while the GEM is asleep, the GEM will "wake up." When the GEM awakens, it performs an internal self test, and begins normal operation of its functions.

The GEM will go into the sleep mode immediately after both of the following conditions have been met:

- Key in OFF or key not in ignition.
- After 45 minutes have elapsed with no change to any wake-up input.

The GEM control system has two modes of operation, the normal operating mode and tester-dependent diagnostics mode.

The normal operation of the GEM can detect errors. An integral part of the normal GEM operation is the continued diagnostic capability. Continuous diagnostics detects errors, and changes the GEM control strategy. There is no warning lamp for the GEM; therefore, a DTC concern will direct you to the GEM. Examples of faults that may be detected during normal operation include:

- GEM continuous self test (RAM, ROM, EEPROM, A/D checking).
- Output driver monitoring (open circuit/short to GND, short to battery).
- Illogical combinations of input signals.

The GEM can only detect open circuit/short to GND faults when the GEM is not energizing a load, and short to battery faults when the GEM is attempting to energize a load.

Delayed Accessory

The GEM controls the delayed accessory feature and the power supply to the power windows through the delayed accessory relay.

The relay is activated by applying ground directly to one side of the delayed accessory relay coil, and is deactivated by removing the ground signal.

Battery Saver

The following components are under the control of the battery saver relay:

- Delayed accessory relay.
- Overhead interior lamp with map lamps.
- Overhead interior lamp switch.
- Interior lamp relay coil.

The battery saver relay becomes active (relay coil is energized) when the GEM is in the awake mode, and is deactivated (relay coil is de-energized) when the GEM is in the sleep mode.

The battery saver will remain active until the ignition state is not ACC or RUN and 45 minutes have passed since the last active input. At that time, the relay will be deactivated and power to the above circuits will terminate.

Five minutes after the battery saver relay has become deactivated, the GEM will go into a lower power state known as sleep mode. In the sleep mode, the GEM will deactivate all outputs and will monitor only select inputs.

Logical characteristics of the GEM battery saver mode are as follows:

Feature Input:

• Sleep/awake mode status.

Feature Output:

• Battery saver relay control (open circuit in sleep mode, grounded when awake).

SECTION 501-11: Glass, Frames and Mechanisms DIAGNOSIS AND TESTING

2000 Explorer/Mountaineer Workshop Manual

Glass, Frames and Mechanisms

Refer to Wiring Diagrams Cell <u>56</u>, Rear Window Defrost/Mirror Defrost for schematic and connector information.

Refer to Wiring Diagrams Cell <u>59</u>, Generic Electronic Module (GEM) for schematic and connector information.

Refer to Wiring Diagrams Cell 100, Windows for schematic and connector information.

Special Tool(s)

5T1137.4	73III Automotive Meter or equivalent 105-R0057
	Worldwide Diagnostic System (WDS) 418-F224,
ST2332-A	New Generation STAR (NGS) Tester 418-F052, or equivalent scan tool

Inspection and Verification

1. **NOTE:** The generic electronic module (GEM)/central timer module (CTM) must be reconfigured upon replacement. Refer to the scan tool help screen on the configuration card to program the Tire Size, Axle Ratio.

The power windows system and rear window defroster system are (GEM) controlled systems.

- 2. Verify the customer concern by operating the power windows system or rear window defroster system.
- 3. Visually inspect for obvious signs of mechanical and electrical damage.

Visual Inspection Chart

Mechanical	Electrical
 Window regulator electric drive Window glass Heated back window grid 	 Fuse(s) Damaged wiring harness Loose or corroded connector(s) Circuitry

- 4. If the concern remains after the inspection, connect the scan tool to the data link connector (DLC) located beneath the instrument panel and select the vehicle to be tested from the scan tool menu. If the scan tool does not communicate with the vehicle:
 - check that the program card is properly installed.
 - check the connections to the vehicle.
 - check the ignition switch position.
- 5. If the scan tool still does not communicate with the vehicle, refer to the scan tool manual.
- 6. Perform the DATA LINK DIAGNOSTIC TEST. If the scan tool responds with:
 - CKT914, CKT915 or CKT70 = ALL ECUS NO RESP/NOT EQUIP, refer to Section 418-00.
 - NO RESP/NOT EQUIP for GEM module, go to Pinpoint Test L.
 - SYSTEM PASSED, retrieve and record the continuous diagnostic trouble codes (DTCs), erase the continuous DTCs and perform self-test diagnostics for the GEM.
- 7. If the DTCs retrieved are related to the concern, go to the GEM/CTM Diagnostic Trouble Code (DTC) Index to continue diagnostics.
- 8. If no DTCs related to the concern are retrieved, proceed to Symptom Chart to continue diagnostics.

GEM/CTM Diagnostic Trouble Code (DTC) Index

DTC DTC Description Caused By Action P0500 Vehicle Speed Signal Circuit REFER to Section 308-07A. GEM Failure B1302 Accessory Delay Relay Coil GEM GO to Pinpoint Test A. Circuit Failure B1304 Accessory Delay Relay Coil GEM GO to Pinpoint Test A. Circuit Open or Short to Battery B1313 Battery Saver Relay Coil — GEM/CTM GO to Pinpoint Test A. Circuit Failure B1315 Battery Saver Relay Coil GO to Pinpoint Test A. GEM/CTM Circuit Short to Battery B1317 Battery Voltage HIGH GEM/CTM REFER to Section 414-00. B1318 Battery Voltage LOW GEM/CTM REFER to Section 414-00. B1322 Door Ajar Driver Circuit Short GEM/CTM REFER to Section 417-02. to Ground B1323 Door Ajar Lamp Circuit Failure GEM/CTM REFER to Section 413-01. B1325 Door Ajar Lamp Circuit Short GEM/CTM REFER to Section 413-01. to Battery B1330 Door Ajar Passenger Circuit GEM/CTM REFER to Section 417-02. Short to Ground B1334 Decklid Ajar Rear Door Circuit GEM/CTM REFER to Section 417-02.

GEM/CTM Diagnostic Trouble Code (DTC) Index

	Short to Ground		
B1338	RR Door Open Warning Lamp Switch Circuit Short to Ground	GEM/CTM	REFER to <u>Section 417-02</u> .
B1340	Chime Input Request Circuit Short to Ground	GEM/CTM	REFER to <u>Section 413-09</u> .
B1342	GEM/CTM is Defective	GEM/CTM	CLEAR the DTCs. RETRIEVE the DTCs. If DTC B1342 is retrieved, REPLACE the GEM/CTM; REFER to <u>Section 419-10</u> . TEST the system for normal operation.
B1345	Heated Backlite Input Circuit Short to Ground	GEM	GO to <u>Pinpoint Test K</u> .
B1347	Heated Backlite Relay Circuit Failure	GEM	GO to Symptom Chart.
B1349	Heated Backlite Relay Circuit Short to Battery	GEM	GO to <u>Pinpoint Test K</u> .
B1352	Ignition Key-In Circuit Failure	GEM/CTM	REFER to Section 413-09.
B1355	Ignition RUN Circuit Failure	GEM/CTM	REFER to Section 211-05, Symptom Chart.
B1359	Ignition RUN/ACC Circuit Failure	GEM/CTM	REFER to Section 211-05, Symptom Chart.
B1371	Illuminated Entry Relay Circuit Failure	GEM/CTM	REFER to <u>Section 417-02</u> .
B1398	Power Window Driver One- Touch Window Relay Circuit Failure	GEM	GO to Symptom Chart.
B1400	Power Window Driver One- Touch Window Relay Coil Circuit Short to Battery	GEM	GO to Symptom Chart.
B1404	Power Window Driver Down Circuit Open	GEM	GO to Symptom Chart.
B1405	Power Window Driver Down Circuit to Battery	GEM	GO to Symptom Chart.
B1410	Power Window Driver Motor Circuit Failure	GEM	GO to Symptom Chart.
B1426	Seat Belt Lamp Circuit Short to Battery	GEM/CTM	REFER to <u>Section 413-01</u> .
B1428	Seat Belt Lamp Circuit Failure	GEM/CTM	REFER to Section 413-01.
B1431	Wiper Brake/Run Relay — Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1432	Wiper Brake/Run Relay Short to Battery	GEM/CTM	REFER to <u>Section 501-16</u> .
B1434	Wiper Hi/Lo Speed Relay — Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1436	Wiper Hi/Lo Speed Relay Circuit Short to Battery	GEM/CTM	REFER to <u>Section 501-16</u> .
B1438	Wiper Mode Select Switch Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1441	Wiper Mode Select Switch	GEM/CTM	REFER to Section 501-16.

	Input Short to Ground		
B1446	Wiper Park Sense Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1450	Wiper/Wash Interval Delay Switch Input Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1453	Wiper/Wash Interval Delay Switch Input Short to Ground	GEM/CTM	REFER to <u>Section 501-16</u> .
B1458	Wiper/Washer Pump Motor Relay Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1460	Wiper/Washer Pump Motor Relay Coil Short to Battery	GEM/CTM	REFER to <u>Section 501-16</u> .
B1462	Seat Belt Switch Circuit Failure	GEM/CTM	REFER to Section 413-09.
B1466	Wiper Hi/Lo Speed Not Switching	GEM/CTM	REFER to <u>Section 501-16</u> .
B1467	Wiper Hi/Low Speed Circuit Motor Short to Battery	GEM/CTM	REFER to <u>Section 501-16</u> .
B1473	Wiper Low Speed Circuit Motor Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1475	Accessory Delay Relay Contacts Short to Battery	GEM/CTM	GO to Symptom Chart.
B1476	Wiper High Speed Circuit Motor Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1483	Brake Pedal Input Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
B1485	Brake Pedal Input Short Circuit to Battery	GEM	REFER to <u>Section 308-07A</u> .
B1571	LR Door Ajar — Circuit Failure	GEM/CTM	REFER to Section 417-02.
B1574	LR Door Ajar Circuit Short to Ground	GEM/CTM	REFER to <u>Section 417-02</u> .
B1577	Lamp Park Input Short Circuit to Battery	GEM/CTM	REFER to <u>Section 413-09</u> .
B1610	Illuminated Entry Input (From RAP Module) Circuit Short to Ground	GEM	REFER to <u>Section 417-02</u> .
B1611	Wiper Rear Mode Select Switch Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B1614	Wiper Rear Mode Select Switch Circuit Short to Ground	GEM	REFER to <u>Section 501-16</u> .
B1814	Wiper Rear Motor Down Relay Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B1816	Wiper Rear Motor Down Relay Coil Circuit Short to Battery	GEM	REFER to <u>Section 501-16</u> .
B1818	Wiper Rear Motor Up Relay Coil Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B1820	Rear Wiper Motor Up Relay Circuit Short to Battery	GEM	REFER to <u>Section 501-16</u> .

B1833	Door Unlock Switch Circuit Short to Ground	GEM	REFER to <u>Section 501-14B</u> .
B1834	Door Unlock Disarm Output Circuit Failure	GEM	REFER to <u>Section 501-14B</u> .
B1836	Door Unlock Disarm Output Circuit Short to Battery	GEM	REFER to <u>Section 501-14B</u> .
B1839	Rear Wiper Rear Motor Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B1840	Wiper Front Power Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B2105	Throttle Position Input (TPI) Signal Out of Range Low	GEM	REFER to <u>Section 308-07A</u> .
B2106	Throttle Position Input (TPI) Signal Out of Range High	GEM	REFER to <u>Section 308-07A</u> .
B2141	NVM Configuration Failure	GEM/CTM	REFER to Section 418-01.
P1763	Transmission Neutral In Tow Indicator Circuit Short to Battery	GEM	REFER to <u>Section 413-09</u> .
P1764	Transmission Neutral In Tow Indicator Circuit Fault	GEM	REFER to <u>Section 413-09</u> .
B1894	Rear Wiper Motor Speed Sense Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
P1804	4WD High Indicator Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1806	4WD High Indicator Short Circuit to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1808	4WD Low Indicator Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1810	4WD Low Indicator Short Circuit to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1812	4WD Mode Select Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1815	4WD Mode Select Short Circuit to Ground	GEM	REFER to <u>Section 308-07A</u> .
P1820	Transfer Case CW Shift Relay Coil	GEM	REFER to <u>Section 308-07A</u> .
P1822	Transfer Case CW Shift Relay Coil Short to Power	GEM	REFER to <u>Section 308-07A</u> .
P1824	4WD Electric Clutch Relay Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1826	4WD Low Clutch Relay Short to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1828	Transfer Case CCW Shift Relay Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1830	Transfer Case HI to LO Shift Relay Coil Short to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1836	Transfer Case Front Shaft	GEM	REFER to Section 308-07A.

	Speed Sensor Circuit Failure		
P1837	Transfer Case Rear Shaft Speed Sensor Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1838	Transfer Case Shift Motor Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1846	Transfer Case CONTACT PLATE "A" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1850	Transfer Case CONTACT PLATE "B" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1854	Transfer Case CONTACT PLATE "C" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1858	Transfer Case CONTACT PLATE "D" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1866	Transfer Case System Concern	GEM	REFER to <u>Section 308-07A</u> .
P1867	Transfer Case Contact Plate General Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1874	Automatic Hall Effect Sensor Power Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1875	Automatic Hall Effect Sensor Power Circuit Short to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1891	Transfer Case Contact Plate Ground Return Open Circuit	GEM	REFER to <u>Section 308-07A</u> .

GEM/CTM Parameter Identification (PID) Index

GEM/CTM Parameter Identification (PID) Index

PID	Description	Expected Values
VSS_GEM	Vehicle Speed Input	0 - 255 KPH
PARK_SW	External Access Ajar Switch Status	OFF, ON
D_DR_SW	Driver Door Ajar Switch Status	CLOSED, AJAR
DR_DSRM	Door Disarm Switch Status	L_DOOR, R_DOOR, LIFT_G, OFF
DR_UNLK	All Doors Unlock Output State	ON, OFF, ON-B-, OFFO-G
P_DR_SW	Passenger Door Ajar Switch Status	CLOSED, AJAR
IGN_KEY	Key-In-Ignition Status	IN, OUT
IGN_GEM	Ignition Switch Status	START, RUN, OFF, ACCY
BATSAV	Battery Saver Relay Circuit	ON, OFF, ON-B-, OFFO-G
VBATGEM	Battery Voltage	0.0 VDC - 14.3 VDC
LGATESW	Liftgate Ajar Switch Status	CLOSED - AJAR
LRDR_SW	Left Rear Door Ajar Switch Status	CLOSED - AJAR
RRDR_SW	Right Rear Door Ajar Switch Status	CLOSED - AJAR
INTLMP	Illuminated Entry Relay Circuit	ON, OFF, ON-B-, OFFO-G

CLTCHSW	Transmission Clutch Interlock Switch (GEM Only)	ENGAGED, NOT ENGAGED
NTRL_SW	Neutral Safety Switch Input (GEM Only)	NTRL, not NTRL
MTR_CCW	Transmission Transfer CCW Motor Output (GEM Only)	ON, OFF, OFFO-G, ON-B-
MTR_CW	CW Shift Relay Coil Status (GEM Only)	OFF, ON, ON-B-, OFFO-G
4WD_SW	4WD Switch Status (GEM Only)	AUTO, 4WDLOW, 4WDHIGH
4WDELCL	4WD Electric Clutch	ON, OFF, ON-B-, OFFO-G
TRANSGR	Transmission Gear Status	REV, notREV
4WDCLCH	4WD Electronic Clutch Output Status (GEM Only)	ON, OFF, OFFO-G, ON-B-
4WDLOW	4WD Low Indicator Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
4WDHIGH	4WD High Indicator Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
PLATE_A	Transfer Case Contact Plate Switch A (GEM Only)	OPEN, CLOSED
PLATE_B	Transfer Case Contact Plate Switch B (GEM Only)	OPEN, CLOSED
PLATE_C	Transfer Case Contact Plate Switch C (GEM Only)	OPEN, CLOSED
PLATE_D	Transfer Case Contact Plate Switch D (GEM Only)	OPEN, CLOSED
BOO_GEM	Brake Pedal Position (BPP) Switch Input (GEM Only)	ON, OFF
HALLPWR	Hall Effect Speed Sensor Power (GEM Only)	ON, OFF, ON-B-, OFFO-G
4WDCLST	4WD Clutch PWM Output Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
TRA_RSP	Rear Shaft Speed (GEM Only)	0-255 mph
TRA_FSP	Front Shaft Speed (GEM Only)	0-225 mph
PLATEPW	Contact Plate Ground Output (GEM Only)	ON, OFF, ON-B-, OFFO-G
PWR_RLY	ABS Active Input	ON, OFF
NTF	Neutral Tow Function (GEM Only)	ON, OFF
NTF_LMP	Neutral Tow Light (GEM Only)	ON, OFF
D_SBELT	Driver Seat Belt Status	OUT, IN
IPCHIME	External Chime Request	ON, OFF
SBLTMP	Seat Belt Indicator Status	OFF, ON, OFFO-G, ON-B-
DRAJR_L	Door Ajar Warning Lamp Circuit	OFF, ON
D_PWRLY	One Touch Down Relay Coil Circuit Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
D_ PWAMP	Driver Power Window Regulator Electric Drive Current (GEM Only)	0.25 amp increments
D_PWPK	Driver Power Window Regulator Electric Drive Peak Current (GEM Only)	0.25 amp increments
ACCDLY	Accessory Delay Relay Coil Circuit (GEM Only)	ON, OFF, ON-B-, OFFO-G
RDEF_ SW	Rear Defrost Control Switch Status	ON, OFF
RDEFRLY	Rear Window Defrost Relay Coil Circuit	ON, OFF, ON-B-, OFFO-G
WASHRLY	Washer Relay Status	ON, OFF, ON-B-, OFFO-G
WPPK_PK	Wiper Park-to-Park Time	0 - 65 Seconds
-	-	-
WPMODE	Wiper Control Mode Status	WASH, OPEN, INVLD, OFF, INTVL 1- 7, LOW, HIGH
---------	---	--
WPPRKSW	Wiper Motor Status	PARKED, notPRK
WPRUN	Wiper Mode Run Relay	ON, OFF, ON-B-, OFFO-G
WPHISP	Windshield Wiper HI/LO Relay Status	ON, OFF, ON-B-, OFFO-G
WASH_SW	Washer Pump Relay Switch Status	OFF, ON, ON-B-, OFFO-G
R_WP_UP	Rear Wiper Up Relay Status (GEM Only)	ON, OFF, OFFO-G, ON-B-
R_WP_DN	Rear Wiper Down Relay Status (GEM Only)	ON, OFF, OFFO-G, ON-B-
R_WP_SW	Rear Wiper Input Switch Status (GEM Only)	WPLOW, OFF, WPHIGH
R_WP_MD	Rear Wiper Mode Switch Status (GEM Only)	OFF, INTVL 1-2, LOW WASH
R_WP_PK	Rear Wiper Park Status (GEM Only)	PARKED, notPRK

GEM/CTM Active Command Index

GEM/CTM Active Command Index

Active Command	Display	Action
PID LATCH	PID LATCH	ON, OFF
FRONT WIPER	WIPER RLY	ON, OFF
FRONT WIPER	SPEED RLY	ON, OFF
FRONT WIPER	WASH RLY	ON, OFF
WARNING LAMPS AND CHIME	SBLT LAMP	ON, OFF
WARNING LAMPS AND CHIME	CHIME	ON, OFF
WARNING LAMPS AND CHIME	AJAR LAMP	ON, OFF
BATTERY SAVER	BATT SAVR	ON, OFF
INTERIOR COURTESY LAMPS	INT LAMPS	ON, OFF
ONE TOUCH DOWN AND ACCY DELAY (GEM only)	ACCY RLY	ON, OFF
ONE TOUCH DOWN AND ACCY DELAY (GEM only)	ONE TOUCH	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM only)	CW/CCW	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM only)	HIGH LAMP	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM only)	LOW LAMP	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM only)	PLATE PWR	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM only)	SHFT CLCH	ON, OFF
SHIFT CLUTCH CONTROL	CLUTCH SOL	ANALOG %
NEUTRAL IN TOW LAMP	NTFLAMP	ON, OFF
REAR WIPER (GEM only)	UP RELAY	ON, OFF
REAR WIPER (GEM only)	DWN RELAY	ON, OFF
HEATED BACKLIGHT	RLY CNTRL	ON, OFF
DOOR LOCK CONTROL	DD UNLOCK	ON, OFF

GEM/CTM Wiggle Test Diagnostic Trouble Code (DTC) Index

GEM/CTM Wiggle Test Diagnostic Trouble Code (DTC) Index

DTC	Description	DTC Caused By
B1317	Battery Voltage HIGH	GEM/CTM
B1318	Battery Voltage LOW	GEM/CTM
B1322	Door Ajar Driver Circuit Short to Ground	GEM/CTM
B1330	Door Ajar Passenger Circuit Short to Ground	GEM/CTM
B1352	Ignition Key-In Circuit Failure	GEM/CTM
B1410	Power Window Driver Motor Circuit Failure	GEM
B1438	Wiper Mode Select Switch Circuit Failure	GEM/CTM
B1441	Wiper Mode Select Switch Input Short to Ground	GEM/CTM
B1446	Wiper Park Sense Circuit Failure	GEM/CTM
B1450	Wiper/Wash Interval Delay Switch Input Circuit Failure	GEM/CTM
B1453	Wiper/Wash Interval Delay Switch Input Short to Ground	GEM/CTM
B1462	Seat Belt Switch Circuit Failure	GEM/CTM
B1577	Lamp Park Input Short Circuit to Battery	GEM/CTM
B1610	Illuminated Entry Input (From RAP Module) Circuit Short to Ground	GEM
B1833	Door Unlock Disarm Switch Circuit Short to Ground	GEM

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action
 All Power Windows Are Inoperative — (2 Door and 4 Door) 	 Fuse(s). Circuitry. GEM. Battery saver relay. Accessory delay relay. Driver window regulator control switch (14529). DTC B1302. DTC B1304. DTC B1313. DTC B1315. DTC B1342. 	GO to <u>Pinpoint Test A</u> .
Single Power Window Is Inoperative — Driver Power Window	GEM.One touch down relay.	 GO to <u>Pinpoint Test B</u>.

(4 Door)	 Circuitry. Driver window regulator control switch . Driver window regulator electric drive (23394) . DTC B1398. DTC B1400. DTC B1400. DTC B1405. DTC B1410. DTC B1342. 	
 Single Power Window Is Inoperative — Driver Power Window (2 Door) 	 Circuitry. Driver power window regulator control switch. Driver power window motor. DTC B1398. DTC B1400. DTC B1404. DTC B1405. DTC B1410. DTC B1342. 	GO to <u>Pinpoint Test C</u> .
 Single Power Window Is Inoperative — Passenger Power Window (4 Door) 	 Circuitry. Master window/door lock control switch. Passenger window regulator control switch. Passenger window regulator electric drive . 	GO to <u>Pinpoint Test D</u> .
 Single Power Window Is Inoperative — Passenger Power Window (2 Door) 	 Circuitry. Passenger power window regulator control switch. Passenger power window motor. Driver power window regulator control switch. 	GO to Pinpoint Test E
Single Power Window Is Inoperative — LR Power Window	 Circuitry. Master window/door lock control switch. LR window regulator control switch . LR window regulator electric 	GO to Pinpoint Test F

	drive .	
 Single Power Window Is Inoperative — RR Power Window 	 Circuitry. Master window/door lock control switch. RR window regulator control switch . RR window regulator electric drive . 	GO to <u>Pinpoint Test G</u> .
 The One Touch Down Feature Is Inoperative 	 GEM. Driver window regulator control switch (2 door). Master window/door lock control switch (4 door). Circuitry. DTC B1398. DTC B1342. 	 GO to <u>Pinpoint Test H</u>.
 All Windows Operate With the Ignition in the OFF Position 	 Circuitry. Accessory delay relay. 	 CHECK the accessory delay relay; REFER to Component Test. If OK, REPAIR circuit 400 (LB/BK). If not OK, REPLACE the accessory delay relay. TEST the system for normal operation.
 The Back Window Will Not Defrost 	 GEM. Circuitry. Heated back window relay. Heated backlite. Heated back window grid. DTC B1347. DTC B1349. DTC B1342. 	GO to <u>Pinpoint Test J</u> .
The Back Window Defroster Will Not Shut Off Automatically	 Heated back window relay. Circuitry. GEM. Heated backlite. Heated back window grid. DTC B1345. DTC B1347. DTC B1342. 	GO to <u>Pinpoint Test K</u> .
 No Communication With the Module — Generic Electronic Module 	Fuse.Circuitry.GEM.	 GO to <u>Pinpoint Test L</u>.

Pinpoint Test

CAUTION: Electronic modules are sensitive to electrostatic discharges. If exposed to these charges, damage may result.

CAUTION: Disconnect the battery before removing and installing the generic electronic module (GEM) or its connectors. Failure to follow this caution will result in the GEM storing many erroneous DTCs and possibly exhibiting erratic operation after installation.

CAUTION: Be careful when probing the I/P fuse panel, power distribution box or any connectors. Damage will result to the connector receptacle if the probe or terminal being used is too large.

NOTE: If continuous diagnostic trouble codes (DTCs) are recorded and the symptom is not present when performing the pinpoint tests, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.

NOTE: Complete the entire pinpoint test related to the symptom before replacing the GEM.

CONDITIONS	DETAILS/RESULTS/ACTIONS
A1 CHECK THE IGNITION STATES — MONITOR THE GEM PID IGN_GEM	
Scan Tool	3 Monitor the GEM PID IGN_GEM while turning the ignition switch (11572) through the START, RUN, OFF, and ACC positions.
	 Do the PID values agree with the ignition switch positions?
	REFER to Section 417-02

PINPOINT TEST A: ALL POWER WINDOWS ARE INOPERATIVE - (2 DOOR AND 4 DOOR)

A2 RETRIEVE THE DIAGNOSTIC TROUBLE CODES (DTCS)			
	1 Retrieve and document continuous DTCs.		
Clear Continuous DTCs			
3 GEM On-Demand Self-Test			
	• Are any DTCs recorded?		
	→ Yes If DTC B1302, GO to <u>A4</u> .		
	If DTC B1304, GO to <u>A4</u> .		
	If DTC B1313, GO to <u>A3</u> .		
	If DTC B1315, GO to <u>A3</u> .		
	If DTC B1342, REPLACE the GEM; REFER to <u>Section 419-10</u> . CLEAR the DTCs. TEST the system for normal operation.		
	\rightarrow No GO to <u>A3</u> .		
A3 CHECK THE BATTERY SAVER RELAY COIL	. CIRCUIT — MONITOR THE GEM PID BATSAV		
	Monitor the GEM PID BATSAV while triggering the GEM active command BATT SAVR ON and OFF.		
	 Does the GEM PID BATSAV value agree with the command mode? 		
	→ Yes GO to <u>A4</u> .		













PINPOINT TEST B: SINGLE POWER WINDOW IS INOPERATIVE — DRIVER POWER WINDOW (4 DOOR)

CONDITIONS	DETAILS/RESULTS/ACTIONS
B1 CHECK THE IGNITION STATES — MONITOR THE GEM PID IGN_GEM	
1	





















Front Door. CLEAR the DTCs. TEST the system for normal operation.
No REPAIR circuit 992 (W/BK). CLEAR the DTCs. TEST the system for normal operation.

PINPOINT TEST C: SINGLE POWER WINDOW IS INOPERATIVE — DRIVER POWER WINDOW (2 DOOR)

CONDITIONS	DETAILS/RESULTS/ACTIONS	
C1 CHECK THE IGNITION STATES — MONITOR THE GEM PID IGN _GEM		
Scan Tool	Monitor the GEM PID IGN_GEM while turning the ignition switch through the START, RUN, OFF and ACC positions.	
	 Do the PID values agree with the ignition switch positions? 	
	[→] Yes GO to <u>C2</u> .	
	→ No REFER to <u>Section 417-02</u> .	
C2 RETRIEVE THE DIAGNOSTIC TROUBLE CC	DES (DTCS)	
	1 Retrieve and document continuous DTCs.	
Clear Continuous DTCs		





















PINPOINT TEST D: SINGLE POWER WINDOW IS INOPERATIVE — PASSENGER POWER WINDOW (4 DOOR)

CONDITIONS	DETAILS/RESULTS/ACTIONS	
D1 CHECK THE VOLTAGE TO THE PASSENGER WINDOW REGULATOR CONTROL SWITCH — CIRCUIT 170 (R/LB)		
1 Solution Passenger Window Regulator Control Switch C615 3	3 Depress the right side of the window lock switch.	














PINPOINT TEST E: SINGLE POWER WINDOW IS INOPERATIVE — PASSENGER WINDOW REGULATOR CONTROL (2 DOOR)













PINPOINT TEST F: SINGLE POWER WINDOW IS INOPERATIVE - LR POWER WINDOW

CONDITIONS	DETAILS/RESULTS/ACTIONS
F1 CHECK THE VOLTAGE TO THE LR WINDOW REGULATOR CONTROL SWITCH — CIRCUIT 170 (R/LB)	











	Control, Rear Door. CLEAR the DTCs. TEST the system for normal operation.	
	If the LR power window did operate with the LR window regulator control switch but not with the master window/door lock control switch, REPLACE the master window/door lock window control switch; REFER to <u>Switch—</u> <u>Window Regulator Control, Driver Door</u> . CLEAR the DTCs. TEST the system for normal operation.	
	→ No Remove the jumper wires; GO to F8.	
F8 CHECK CIRCUIT 884 (Y/BK) FOR OPEN		
LR Power Window Motor C701		
	Measure the resistance between LR window regulator control switch C702-5, circuit 884 (Y/BK), and LR power window motor C701, circuit 884 (Y/BK).	
	Is the resistance less than 5 ohms?	
	→ Yes GO to <u>F9</u> .	
	\rightarrow No REPAIR circuit 884 (Y/BK). CLEAR the DTCs. TEST the system for normal operation.	
F9 CHECK CIRCUIT 334 (Y/LB) FOR OPEN		
	Measure the resistance between LR window regulator control switch C702-2, circuit 885 (Y/LB), and LR power window motor C701, circuit 885 (Y/LB).	



PINPOINT TEST G: SINGLE POWER WINDOW IS INOPERATIVE - RR POWER WINDOW















PINPOINT TEST H: THE ONE TOUCH DOWN FEATURE IS INOPERATIVE

CONDITIONS	DETAILS/RESULTS/ACTIONS
H1 CHECK THE IGNITION STATES — MONITOR THE GEM PID IGN_GEM	
1	















PINPOINT TEST J: THE BACK WINDOW DEFROSTER WILL NOT DEFROST

CONDITIONS	DETAILS/RESULTS/ACTIONS
J1 CHECK THE IGNITION STATES - MONITOR	₹ THE GEM PID IGN_GEM
Scan Tool	Monitor the GEM PID IGN_GEM while turning the ignition switch through the START, RUN, OFF, and ACC positions.

	 Do the PID values agree with the ignition switch positions?
	\rightarrow Yes GO to <u>J2</u> . → No
12 RETRIEVE THE DIAGNOSTIC TROUBLE CO	
	Retrieve and document continuous DTCs.
[2]	
Clear Continuous DTCs	
<u>e</u>	
GEM On-Demand Self-Test	
	Are any DTCs recorded?
	\rightarrow Ves
	If DTC B1343, GO to <u>J13</u> .
	If DTC B1347, GO to <u>J3</u> .
	If DTC B1349, GO to <u>J3</u> .
	If DTC B1342, REPLACE the GEM; REFER to <u>Section 419-10</u> . CLEAR the DTCs. TEST the system for normal operation.
	$ \xrightarrow{\rightarrow} \mathbf{No} $ GO to <u>J3</u> .
	If the rear window defroster does not operate properly in some places, GO to <u>J19</u> .
	If the rear window defrost switch does not illuminate but the rear window defrost operates properly, GO to <u>J20</u> .
J3 CHECK THE REAR WINDOW DEFROST RELAY COIL CIRCUIT — MONITOR THE GEM PID RDEFRLY	
1	1 Monitor the GEM PID RDEFRLY while triggering the GEM active command RLY











	normal operation. If the fuse fails again, CHECK for a short to ground. REPAIR as necessary.
	If the fuse is OK, REPAIR circuit 185 (BK). CLEAR the DTCs. TEST the system for normal operation.
J12 CHECK THE REAR WINDOW DEFROST RE	LAY
	Check the rear window defrost relay; refer to Component Test.
	Is the rear window defrost relay OK?
	→ Yes REPAIR circuit 186 (BR/LB). CLEAR the DTCs. TEST the system for normal operation.
	→ No REPLACE the rear window defrost relay. CLEAR the DTCs. TEST the system for normal operation.
J13 CHECK THE HEATED BACKLITE SWITCH I	NPUT — MONITOR THE GEM PID RDEF_SW
	 Monitor the GEM PID RDEF_SW while pressing the heated backlite switch ON and OFF.
	 Does the GEM PID RDEF_SW agree with the switch position?
	\rightarrow Yes GO to <u>J17</u> .
	\rightarrow No GO to <u>J14</u> .
J14 CHECK THE GROUND TO THE HEATED B/	ACKLITE SWITCH — CIRCUIT 57 (BK)
Heated Backlite Switch C248	3 Measure the resistance between heated backlite switch C248-4, circuit 57 (BK), and ground.












PINPOINT TEST K: THE BACK WINDOW DEFROSTER WILL NOT SHUT OFF AUTOMATICALLY

CONDITIONS	DETAILS/RESULTS/ACTIONS
K1 RETRIEVE THE DIAGNOSTIC TROUBLE CO	DDES (DTCS)
1	











PINPOINT TEST L: NO COMMUNICATION WITH THE MODULE — GENERIC ELECTRONIC MODULE

CONDITIONS	DETAILS/RESULTS/ACTIONS
L1 CHECK POWER DISTRIBUTION BOX MAXI-FUSE 1 (50A)	
1 Maxi-Fuse 1 (50A)	
	Is the fuse OK?
	→ Yes GO to <u>L2</u> .
	→ No REPLACE the fuse. CLEAR the DTCs. TEST the system for normal operation. If the fuse fails again, CHECK circuit 1052 (T/BK) for a short to ground. REPAIR as necessary.
L2 CHECK FUSE JUNCTION PANEL FUSE 25 (7.5A)	





Component Tests

Relay — Heated Back Window

Use 73III Automotive Meter to check for the continuity between terminal 85 and all other terminals. If resistance is 5 ohms or less between terminal 2 and any other terminal, replace the relay. If resistance is greater than 5 ohms, continue with the test. Use two jumper wires to connect relay terminals 86 and 30 directly to the positive battery terminal. Use 73III Automotive Meter set in the volts position to check for voltage at terminal 87A. If battery voltage is not indicated, replace the relay. If battery voltage is indicated, connect a third jumper wire to terminal 85, and ground the jumper wire to a known good ground. Check for voltage at terminal 87. If battery voltage is not indicated, replace the relay.



Relay — Mini ISO

Use 73III Automotive Meter to check for the continuity between terminal 85 and all other terminals. If resistance is 5 ohms or less between terminal 85 and any other terminal, replace the relay. If resistance is greater than 5 ohms, continue with the test. Use two jumper wires to connect relay terminals 86 and 30 directly to the positive battery terminal. Use 73III Automotive Meter set in the volts position to check for voltage at terminal 87A. If battery voltage is not indicated, replace the relay. If battery voltage is indicated, connect a third jumper wire to terminal 85 and ground the jumper wire to a known good ground. Check for voltage at terminal 87. If battery voltage is not indicated, replace the relay.



Relay — Micro ISO

Use 73III Automotive Meter to check for the continuity between terminal 2 and all other terminals. If resistance is 5 ohms or less between terminal 2 and any other terminal, replace the relay. If resistance is greater than 5 ohms, continue with the test. Use two jumper wires to connect relay terminals 1 and 3 directly to the positive battery terminal. Use 73III Automotive Meter set in the volts position to check for voltage at terminal 4. If battery voltage is not indicated, replace the relay. If battery voltage is indicated, connect a third jumper wire to terminal 2 and ground the jumper wire to a known good ground. Check for voltage at terminal 5. If battery voltage is not indicated, replace the relay.



Heated Window Grid Wire Repair

Special Tool(s)



NOTE: Any breaks longer than 25 mm (1 inch) in one grid cannot be repaired. The back window glass must be replaced. Breaks equal to or shorter than 25 mm (1 inch) the heated back window grid wire can be successfully repaired by using the following procedure.

- 1. Obtain the following repair kit:
 - Repair Kit Order Number 50-25-0584-0029.
- 2. The vehicle should be allowed to reach $16^{\circ}C$ ($60^{\circ}F$) or above.
- 3. Clean the repair area with denatured alcohol.
- 4. Place the grid line mask over the break aligning the cut-out slots on either side of the repair area.



- 5. Apply the epoxy to the repair area.
- 6. Remove the mask without disturbing the epoxy.
- Use the special tool to heat the repair area for 1 to 2 minutes at a distance of about 25-50 mm (1-2 inches). This procedure should heat the repair area to approximately 149° C (300° F).
- 8. The heated back window may be energized immediately after the repair. Optimum hardness and adhesion will occur after 24 hours. Do not disturb the repair area until that time.

SECTION 501-11: Glass, Frames and Mechanisms GENERAL PROCEDURES

2000 Explorer/Mountaineer Workshop Manual

Lead Terminal Repair

- 1. Obtain the following repair kit:
 - Repair Kit Order Number 50-25-0584-0029.
- 2. The vehicle should be allowed to reach 16°C (60°F) or above.
- 3. Clean the area with denatured alcohol.
- 4. Apply the epoxy to the repair area.
- 5. Hold the terminal in place on the bus bar with an appropriate tool.



6. Apply epoxy to the repair area.

Switch —Window Regulator Control, Driver Door

Removal

1. Disconnect the battery ground cable (14301).



- 2. Remove the front door trim panel; refer to Section 501-05.
- 3. Remove the window regulator switch plate harness assembly.
 - 1. Remove the screws.
 - 2. Remove the harness assembly.



- 4. Remove the window regulator control switch (14529).
 - 1. Pry the release tabs.
 - 2. Remove the window regulator control switch.



1. **NOTE:** When the battery is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 mi) or more to relearn the strategy.

To install, reverse the removal procedure.



Switch —Window Regulator Control, Rear Door

Removal

- 1. Remove the rear window regulator switch plate.
 - 1. Remove the screws.
 - 2. Remove the rear window regulator switch plate.



- 2. Remove the window regulator switch plate harness assembly.
 - 1. Remove the screws.
 - 2. Remove the harness assembly.



- 3. Remove the window regulator control switch (14529).
 - 1. Pry the release tabs.
 - 2. Remove the window regulator control switch.



1. **NOTE:** When the battery is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 mi) or more to relearn the strategy.

To install, reverse the removal procedure.



Window Glass —Liftgate

Removal

- 1. Open the liftgate glass.
- 2. Disconnect the two rear window defogger electrical connectors (one on each side).



3. Disconnect the two liftgate cylinders (one on each side).



4. Release the upper liftgate trim panel clips to gain access to liftgate window glass access plugs.



5. Remove the liftgate glass hinge access plugs.



- 6. Remove the liftgate window glass.1. Remove the two liftgate window glass to window hinge nuts.2. Remove the liftgate window glass.



1. To install, reverse the removal procedure.



Window Glass — Front Door

Special Tool(s)

C.S.	Heavy Duty Riveter or equivalent 501-D011 (D80L-23200-A)
ST1132-A	

Removal

- 1. Remove the front door trim panel; refer to <u>Section 501-05</u>.
- 2. Remove the inside glass weatherstrip.



3. **NOTE:** Lower the window glass to access the two rivets.

Drill out the window regulator arm to window glass rivets.



4. NOTE: Slide the glass through the outboard side of the front door (20124) .

Remove the front door window glass (21410).



1. NOTE: Slide the glass through the outboard side of the front door .

Position the front door window glass.



2. Use Heavy Duty Riveter to install the window regulator arm to window glass rivets.



3. Install the inside glass weatherstrip.



4. Install the front door trim panel; refer to <u>Section 501-05</u>.

2000 Explorer/Mountaineer Workshop Manual

Window Glass —Rear Door

Special Tool(s)



Removal

- 1. Remove the rear door trim panel; refer to <u>Section 501-05</u>.
- 2. Remove the inside glass weatherstrip.



3. Drill out the window regulator arm to window glass rivets.



4. NOTE: Slide the glass through the outboard side of the rear door (24630) .

Remove the rear door window glass (25712).



1. **NOTE:** Slide the glass through the outboard side of the rear door .

Position the rear door window glass.



2. Use Heavy Duty Riveter to install the window regulator arm to window glass rivets.



3. Install the inside glass weatherstrip.



4. Install the rear door trim panel; refer to <u>Section 501-05</u>.

Window Glass — Movable Quarter

Removal

- 1. Remove the quarter trim panel; refer to <u>Section 501-05</u>.
- 2. Remove the quarter window glass.
 - 1. Remove the nuts.
 - 2. Remove the quarter window glass.



Installation

1. **NOTE:** If the seal requires adjustment, disconnect the quarter trim panel. Rotate the quarter window latch clockwise to increase seal pressure or counterclockwise to reduce seal pressure. Reconnect the quarter window latch.

To install, reverse the removal procedure.



Window Glass —Quarter

Removal

- 1. Remove the quarter trim panel (31012) ; refer to Section 501-05.
- 2. Remove the rear quarter window glass.
 - 1. Remove the ten nuts.
 - 2. Carefully push the rear quarter window glass outward to release the butyl seal.



3. Remove the excess foam butyl from the window opening.



Installation

1. **NOTE:** When applying foam butyl, leave a slight overlap at the bottom to allow for drainage.

Apply 6 mm (0.23 in) foam butyl or equivalent meeting Ford specification WSB-M2G234-C to the rear quarter window glass frame.

- Start at the bottom middle and work around the frame.
- 2. Install the rear quarter window glass.
 - 1. Position the rear quarter window glass.
 - 2. **NOTE:** Loosely install the ten nuts before tightening.

Tighten the ten nuts to specification.



3. Install the quarter trim panel ; refer to <u>Section 501-05</u>.

Motor —Rear Door

Removal

- 1. Raise and support the rear door window glass to the full up position.
- 2. Disconnect the battery ground cable.
- 3. Remove the rear door trim panel. For additional information, refer to Section 501-05.
- 4. Remove the speaker.
 - 1. Remove the screws.
 - 2. Disconnect the electrical connector.
 - 3. Remove the speaker.



5. Remove the watershield.



- 6. Remove the power window motor.
 - 1. Remove the bolts.
 - 2. Disconnect the electrical connector.
 - 3. Remove the power window motor.


Installation

1. **NOTE:** When the battery is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 miles) or more to relearn the strategy.

To install, reverse the removal procedure.

• Cycle the door glass to ensure engagement of the drive mechanism.



Motor and Window Regulator — Front Door

Special Tool(s)

	Heavy Duty Riveter or equivalent 501-D011 (D80L-23200-A)
0	
ST1132-A	

Removal

- 1. Remove the front door trim panel. For additional information, refer to Section 501-05.
- 2. Disconnect the inside front door handle from the front door (20124).
 - 1. Remove the screws.
 - 2. Disconnect the inside front door handle.



3. Disconnect the rod from the inside front door handle.



- 4. Remove the water shield.
- 5. Position the front door window glass to access the track rivets through the door openings.

6. Support the front door window glass.



- 7. Disconnect the battery ground cable (14301).
- 8. Remove the regulator to window rivets.
- 9. If equipped, disconnect the power window motor electrical connector.



10. If equipped, remove the equalizer bracket to front door inner panel nuts.



- 11. Remove the window regulator/motor assembly.
 - 1. Drill out the rivets.
 - 2. Remove the nut.



12. WARNING: Prior to power window removal, make sure the regulator arms are in a fixed position to prevent counterbalance spring unwind. failure to place the regulator arms in a fixed position can cause the spring to suddenly release resulting in personal injury.

If equipped, remove the power window motor.

- Remove the bolts.
 Remove the power window motor.



Installation

1. **NOTE:** When the battery is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 mi) or more to relearn the strategy.

To install, reverse the removal procedure.

- Use Heavy Duty Riveter to install the new rivets.
- Cycle the door glass to ensure engagement of the drive mechanism.









Windshield Glass

Special Tool(s)

	Interior Auto Glass Cut-Out Knife Kit 164-R2450 or equivalent
ST1320-A	
	Pneumatic Knife with Offset Blade
Ç Î	107-R1511 or equivalent
ST1109-A	
PUMIPKE	The Pumper 164-R2459 or equivalent
ST2085-A	

Removal

WARNING: To prevent glass splinters from entering the eyes or cutting hands, wear safety glasses and heavy gloves when cutting the glass from the vehicle.

1. Remove the windshield side garnish moldings.



- 2. Remove the interior rear view mirror. For additional information, refer to <u>Section 501-09</u>.
- 3. If equipped, remove the overhead console.
- 4. Remove the sun visors.

- 1. Remove the sun visor screws.
- 2. Remove the sun visors.
- If equipped, disconnect the electrical connector.



- 5. Remove the sun visor clips.
 - 1. Remove the sun visor clip screws.
 - 2. Remove the sun visor clips.



- 6. Lower the front portion of the headliner.
- 7. Remove the cowl grille. For additional information, refer to <u>Section 501-02</u>.
- 8. Remove the upper windshield weatherstrip.



9. Remove the LH and RH windshield mouldings.



- 10. Using a soft brush or vacuum, remove any dirt or foreign material from the pinch weld.
- 11. **NOTE:** Lubricate the urethane sealant with water to aid the special tool when cutting.

Using the special tool, cut the urethane sealant from the windshield glass starting at the top center and work toward the bottom corners.



12. Using the special tool, distance the windshield from the body.



13. Using the special tool, cut the remaining urethane sealant and remove the windshield glass.



14. Using a soft brush or vacuum, remove any foreign material or dirt from the pinch weld.

Installation

CAUTION: After installing the urethane installed glass, the vehicle should not be driven until the urethane has cured. The curing times at temperatures above 13°C (55°F) and relative humidity above 50% is 12-24 hours (decreasing at higher temperatures and lower humidities). Inadequate curing of the urethane may adversely affect the strength of the urethane bond.

- 1. Dry fit the windshield. Make alignment marks with tape or non-staining grease pencil.
- 2. CAUTION: Do not scratch the pinch weld area.

Trim the remaining urethane sealant on the pinch weld to within the specification.

• The existing urethane sealant surface should be smooth and free of cuts and contamination.



- 3. Use a wool applicator to apply Urethane Metal Primer Essex U-413 meeting Ford specification WSB-M2G234-C to any exposed metal on the pinch weld. Allow six to ten minutes to dry.
- 4. Apply (A) Foam Butyl meeting Ford specification WSB-M2G234-C to the (B) pinch weld.



- 5. If reinstalling original windshield, remove the excess urethane sealant from the windshield glass.
- 6. Clean the inside of the glass surface with an alcohol-free cleaner making sure the ceramic coated area is clean .
- 7. NOTE: Wipe off the Glass Prep immediately after each application because it flash dries.

Apply Urethane Glass Prep Essex U-401 meeting Ford specification WSB-M2G314-B twice around the glass surface to be urethaned.

- 8. Apply Glass Primer Essex U-402 meeting Ford specification WSB-M5B280-C to the same area that was prepped in the pervious step. Allow five minutes to dry.
- 9. Cut the urethane applicator tip to specification.



10. CAUTION: If the vehicle is to be driven within 24 hours of urethane application, urethane sealant Essex U-216 must be used due to its one hour cure time.

Apply a bead of urethane sealant Essex 400-HV or Essex U-216, which meets Ford specification WSB-M2G316-B to the pinch weld just outside the foam dam.



11. Install the windshield glass aligning it to the marks previously made.



- 12. After the windshield glass is set , check for water leaks and add urethane sealant where needed.
- 13. Install the upper windshield weatherstrip.



- 14. If necessary, remove excess urethane from the outside surface of the windshield glass.
- 15. Install the LH and RH windshield mouldings.



- 16. Install the cowl grille. For additional information, refer to Section 501-02.
- 17. If equipped, install the overhead console.
- 18. Install the sun visor clips.
 - 1. Install the sun visor clips.
 - 2. Install the screws.



- 19. Install the sun visors.
 - 1. Install the sun visors.
 - If equipped, connect the electrical connector.
 - 3. Install the screws.



- 20. Install the front portion of the headliner.
- 21. Install the interior rear view mirror. For additional information, refer to Section 501-09.
- 22. Install the windshield side garnish mouldings.



SECTION 501-12: Instrument Panel and Console SPECIFICATIONS

Torque Specifications

Description	Nm	lb-ft	lb-in
Battery Cable Clamp Bolts	7-10	—	62-89
Instrument Panel Cowl Side Bolts	25.5-34.5	19-25	
Bulkhead Wiring Harness Connector Bolts	4.0-5.5	—	36-49
Upper Series Floor Console Bolts	9	—	80
Upper Series Floor Console Electrical Connector Bolt	4.0-5.5	—	36-49
Upper Series Front Floor Console Bolts	3.4-4.6	—	30-41
Base Series Floor Console Front Screws	3-4	—	26-35
Base Series Floor Console Rear Screw	2-3		18-26
Instrument Panel Cowl Side Bolts	25.5-34.5	19-25	—
Ground Wire Screws	2-3	—	18-26
Instrument Panel Cowl Top Bolts (Inner)	2-3	—	18-26
Instrument Panel Cowl Top Bolts (Outer)	25.5- 34.5	19-25	_
Instrument Panel to Body Harness Bolt	4.0-5.5	—	36-49
Instrument Panel Brace Bolt	7.2-10.8	—	64-96

SECTION 501-12: Instrument Panel and Console DESCRIPTION AND OPERATION

2000 Explorer/Mountaineer Workshop Manual

Instrument Panel

Instrument Panel Components



Item	Part Number	Description
1	043B13	Driver Side Air Bag Module
2	10849	Instrument Cluster
3	18806	Radio Chassis
4	—	Rear Windshield Wiper/Washer Switch
5	044A74	Passenger Side Air Bag Module
6	06024	Glove Compartment Door
7	—	Climate Control Head
8	—	Power Point
9	15052	Cigar Lighter Knob and Element

SECTION 501-12: Instrument Panel and Console DESCRIPTION AND OPERATION

2000 Explorer/Mountaineer Workshop Manual

Console — Overhead

Overhead Console

5 4 1 6 6 7 7 7 7 7 7 7 7 7 7 7 7 7		
ltem	Part Number	Description
1	—	Map Lamp Switch
2	—	Compass/Thermometer Display
3		Mode Switch
4	—	Garage Door Remote Button
5	_	Garage Door Remote Holder Release Button

SECTION 501-12: Instrument Panel and Console REMOVAL AND INSTALLATION

Instrument Panel

Removal

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage may result.

- 1. Remove the steering column; refer to <u>Section 211-04</u>.
- 2. Disconnect the brake pedal position (BPP) switch electrical connector.



3. If equipped, disconnect the clutch pedal position (CPP) switch electrical connector.



- 4. Remove the LH and RH cowl side trim panels. For additional information, refer to Section 501-05.
- 5. Disconnect the electrical connectors and the ground wires on the RH cowl panel.



6. Disconnect the power distribution box from the bracket and position aside.



- 7. Disconnect the bulkhead wiring harness connectors from inside the engine compartment.
 - 1. Loosen the bolts.
 - 2. Disconnect the electrical connectors.



8. Remove the bulkhead connector insulator.



9. Unclip the bulkhead electrical connectors from the dash panel.



- 10. Remove the passenger side air bag module (044A74) ; refer to <u>Section 501-20B</u>.
- 11. Disconnect the blend door actuator electrical connector.



12. Disconnect the climate control vacuum harness connector.



13. Disconnect the radio antenna cable in-line connector.



- 14. Raise the glove compartment.
 - Press the glove compartment release tabs inward while raising the glove compartment.



15. Remove the instrument panel defroster opening grille.



16. Remove the instrument panel cowl top bolts.



- 17. If equipped, remove the upper series floor console; refer to Console—Floor, Upper Series.
- 18. Remove the instrument panel brace bolt from under the steering column opening.



19. Remove the windshield side garnish mouldings.



20. Remove the RH instrument panel cowl side bolt.



21. Remove the instrument panel fuse panel door.



22. Remove the LH instrument panel cowl side bolts.



- 23. Position the instrument panel away from the dash panel.
- 24. Disconnect the instrument panel to body harness.1. Loosen the bolt.

 - 2. Disconnect the harness.



25. **NOTE:** Two technicians are required to carry out this step.

Remove the instrument panel.

• If necessary, transfer components to the new instrument panel.

Installation

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage may result.

1. NOTE: Two technicians are required to carry out this step.

Position the instrument panel.

- 2. Connect the instrument panel to body harness.
 - 1. Connect the harness.
 - 2. Tighten the bolt.



- 3. Align and install the instrument panel.
- 4. Install the LH instrument panel cowl side bolts.



5. Install the RH instrument panel cowl side bolt.



6. Install the instrument panel cowl top bolts.



7. Install the instrument panel defroster opening grille.



8. Install the instrument panel fuse panel door.



9. Install the instrument panel brace bolt from under the steering column opening.



- 10. If equipped, install the floor console; refer to <u>Console—Floor, Upper Series</u>.
- 11. Install the windshield side garnish mouldings.



- 12. Lower the glove compartment.
 - Press the glove compartment release tabs inward while pulling downward on the glove compartment.



13. Connect the radio antenna cable in-line connector.



14. Connect the climate control vacuum harness connector.



15. Connect the blend door actuator electrical connector.



- 16. Install the passenger side air bag module ; refer to <u>Section 501-20B</u>.
- 17. Connect the electrical connectors and the ground wires on the RH cowl panel.



18. Position the bulkhead electrical connector handle.



19. Install the bulkhead connector insulator.



- 20. Install the bulkhead wiring harness connectors.
 - 1. Connect the electrical connectors.
 - 2. Tighten the bolts.



21. Install the power distribution box onto the power distribution box bracket.



- 22. Install the LH and RH cowl side trim panels. For additional information, refer to Section 501-05.
- 23. If equipped, connect the CPP switch electrical connector.



24. Connect the BPP switch electrical connector.



25. Install the steering column; refer to $\underline{\text{Section 211-04}}$.

Console — Floor, Upper Series

Removal

- 1. Disconnect the battery ground cable.
- 2. Remove the front floor console tray.
 - If equipped with message center, disconnect the three connectors.



- 3. Disconnect the floor console electrical connector.
 - 1. Remove the bolt.
 - 2. Disconnect the electrical connector.



4. Remove the front floor console bolts.



5. Remove the center cupholder panel.



6. Remove the center floor console bolts.



7. NOTE: The console must be moved rearward to disengage the rear mounting bracket.

Remove the floor console.



Installation

1. To install, reverse the removal procedure.



\/∕¢®)) GR0591-A
Console — Floor, Base Series Explorer

Removal

NOTE: The base floor console is shown; floor console with removable storage bin is similar.

- 1. Remove the front seat center armrest.
 - 1. Remove the two covers.
 - 2. Remove the four bolts.
 - 3. Remove the armrest.



2. Remove the utility tray beverage holder.



- 3. Remove the floor console.
 - 1. Remove the screws.
 - 2. Remove the floor console.



Installation

1. To install, reverse the removal procedure.





2000 Explorer/Mountaineer Workshop Manual

Console — Overhead

Removal

- 1. Disconnect the battery ground cable.
- 2. If equipped, open the garage door remote cover.



3. If equipped, remove the screws.



4. Remove the overhead console.



5. Disconnect the two electrical connectors (three connectors on moonroof equipped vehicles).



Installation

1. To install, reverse the removal procedure.

SECTION 501-14A: Handles, Locks, Latches and Mechanisms 2000 Explorer/Mountaineer Workshop Manual SPECIFICATIONS

General Specifications

ltem	Specification
Liftgate glass flushness mm (in)	-1.50 (06)

Lock Repair/Replacement Specifications

Part Number	Lock Repair Package Name	
F85Z-11582-AA	Ignition Cylinder Lock Kit	
F87Z-7821990-BA	Door Lock Kit	
F87Z-7843432-CA	Liftgate Lock Kit	

Torque Specifications

Description	Nm	lb-ft	lb-in
Battery ground cable	7-10	_	62-89
Door latch screws	4-8	_	36-70
Hood auxiliary catch hook bolts	11-13	_	91-123
Hood assist spring bolt	24-31	18-23	—
Hood latch bolts	10.5-13.5	8-9	—
Hood latch control handle screws	2-4	_	16-41
Inside door handle screws	7.5-10.5	_	67-93
License plate lamp shield screws	3	_	27
Liftgate latch bolt	9-14	7-10	—
Liftgate latch remote control	11-13	_	91-123
Liftgate lock actuator nuts	11-13	_	91-123
Liftgate lock cylinder nuts	6-7	_	54-62
Liftgate window latch nuts	12	9	_
Radiator grille sight shield bolts	6-8	_	54-70
Door latch striker	40	30	_

Handles, Locks, Latches and Mechanisms

Hood

Hood Latch Components



ltem	Part Number	Description
1	16892	Hood auxiliary catch hook
2	16C644	Hood assist spring
3	—	Hood latch control handle and Cable

4	16700	Hood latch
---	-------	------------

Door

Door Latch Components



Liftgate

Liftgate Latch Components

		ELUS
Item Part Number	Description	GN2116-A
1 —	Liftgate glass latch	1
2 —	Lock cylinder	1
3 —	Liftgate handle]
4 —	Liftgate latch]
5 —	Liftgate lock actuator]

SECTION 501-14A: Handles, Locks, Latches and Mechanisms 2000 Explorer/Mountaineer Workshop Manual DIAGNOSIS AND TESTING

Locks, Latches and Mechanisms

Refer to Wiring Diagrams Cell <u>110</u>, Power Door Locks for schematic and connector information.

Special Tool(s)

নিয়ায়ন	73 Digital Multimeter or equivalent
Ø.	105-R0051
Ē	
ST1137-A	

Inspection and Verification

- 1. Verify the customer concern by operating the handles, locks, latches and mechanisms.
- 2. **NOTE:** Be sure the battery (10655) is fully charged. Refer to <u>Section 414-00</u>. Before starting electrical diagnosis, check for mechanical binds by manually operating the door lock. Then operate the lock system several times from each switch, while observing the operation of all door locks.

Visually inspect for obvious signs of mechanical and electrical damage using the following chart.

Visual Inspection Chart

Mechanical	Electrical
 Binding latches Door lock cylinder Misaligned door Lock actuator 	 Fuse Relays Switch Wiring harness Loose or corroded connections

3. If the concern is not visually evident, determine the symptom and proceed to Symptom Chart.

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action
 The door lock is inoperative 	 Circuitry. Power door lock actuator (218A42). 	GO to <u>Pinpoint Test A</u> .
 The door locks are inoperative 	Fuse.Circuitry.Door lock switch.	GO to <u>Pinpoint Test B</u> .

	 All lock and unlock relay(s). 	
 All the locks operate from one switch only 	Circuitry.Door lock switch.	GO to <u>Pinpoint Test C</u> .
 The door locks are inoperative — door locks operate one way only 	 Circuitry. Door lock switch. All lock or unlock relay(s). 	GO to <u>Pinpoint Test D</u> .
 The door locks only operate with the engine running 	 Battery discharged. 	 CHECK the battery voltage; REFER to <u>Section 414-00</u>.

Pinpoint Tests

PINPOINT TEST A: THE DOOR LOCK IS INOPERATIVE

CONDITIONS	DETAILS/RESULTS/ACTIONS		
A1 CHECK THE OPERATION OF THE SUSPECT DOOR LOCK			
	 Check for binding or stuck conditions by manually operating the inoperative door lock. 		
	Is the lock stuck or binding?		
	→ Yes REPAIR or REPLACE the binding components. TEST the system for normal operation.		
	$\rightarrow \mathbf{No}$ GO to <u>A2</u> .		
A2 CHECK THE POWER DOOR LOCK ACTUAT (PK/BK)	A2 CHECK THE POWER DOOR LOCK ACTUATOR FOR LOCK OPERATION — CIRCUIT 117 (PK/BK)		
Inoperative Power Door Lock Actuator	Measure the voltage at the inoperative power door lock actuator connector Pin 1, Circuit 117 (PK/BK), and ground while operating the door lock switch to the LOCK position.		



PINPOINT TEST B: ALL THE DOOR LOCKS ARE INOPERATIVE

CONDITIONS	DETAILS/RESULTS/ACTIONS
B1 CHECK FUSE JUNCTION PANEL FUSE 18 (25A)
1	



Is the voltage greater than 10 volts?
→ Yes REPAIR Circuit 57 (BK). TEST the system for normal operation.
→ No REPAIR Circuit 171 (BK/W). TEST the system for normal operation.

PINPOINT TEST C: ALL THE LOCKS OPERATE FROM ONE SWITCH ONLY

CONDITIONS	DETAILS/RESULTS/ACTIONS	
C1 CHECK THE INOPERATIVE DOOR LOCK SWITCH		
	Check the inoperative door lock switch. Refer to Wiring Diagrams, Cell 149, Component Testing	
	Is the switch OK?	
	→ Yes GO to <u>C2</u> . → No	
	System for normal operation.	
C2 CHECK THE GROUND TO THE INOPERATIVE DOOR LOCK SWITCH — CIRCUIT 57 (BK)		
1	1 Measure the resistance between the inoperative door lock switch Circuit 57 (BK), and ground; refer to the following chart:	
	Switch Connector/Pin	
	Liftgate C404-3	
	Passenger C614-4	
	Driver (2 door) C514-4	
	Driver (4 door) C501-4	





PINPOINT TEST D: THE DOOR LOCKS ARE INOPERATIVE — DOOR LOCKS OPERATE ONE WAY ONLY

CONDITIONS	DETAILS/RESULTS/ACTIONS
D1 CHECK LOCK OPERATION	
	Actuate the door lock switch to the LOCK position.
	Do the doors lock?
	\rightarrow Yes GO to <u>D2</u> .
	$ \xrightarrow{\rightarrow} \mathbf{No} $ GO to <u>D6</u> .
D2 CHECK THE VOLTAGE TO THE ALL UNLOCK RELAY — CIRCUIT 171 (BK/W)	









Latch —Hood

Removal

- 1. Raise and support the hood (16612).
- 2. Remove the radiator grille sight shield (8C031).
 - 1. Remove the bolts.
 - 2. Remove the rivets.
 - 3. Remove the radiator grille sight shield.



3. **NOTE:** Mark the hood latch position prior to removal of the bolts.

Remove the hood latch (16700)

- 1. Remove the bolts.
- 2. Disconnect the hood latch cable from the hood latch.
- 3. Remove the hood latch.



Installation

- 1. To install, reverse the removal procedure.
 - Adjust the hood latch; refer to Latch—Hood, Adjustment.



Latch — Hood, Adjustment

- 1. Verify the hood alignment.
- 2. Remove the radiator grille sight shield (8C031).
 - 1. Remove the bolts.
 - 2. Remove the rivets.
 - 3. Remove the radiator grille sight shield.



- 3. Align the hood latch.
 - 1. Loosen the hood latch bolts enough to allow for movement of the hood latch.
 - 2. Align the hood latch with the hood latch striker.



4. Tighten the hood latch bolts.



- 5. Verify the hood latch striker is fully engaging the hood latch.
 - Repeat the procedure as necessary.

Latch —Door

Special Tool(s)



Removal and Installation

NOTE: Front door shown, rear door similar.

Front door

- 1. Remove the door lock cylinder; refer to Lock Cylinder—Door.
- 2. If equipped, remove the power door lock actuator.
 - 1. Disconnect the electrical connector.
 - 2. Drill out the rivet.
 - 3. Disconnect the actuator rod.
 - 4. Remove the actuator.



Rear door

3. If equipped, remove the power door lock actuator. For additional information, refer to <u>Actuator—Door</u>, <u>Rear</u> in this section.

All doors

- 4. Remove the door latch remote control.
 - 1. Remove the screws.
 - 2. Disconnect the door latch remote control link from the door latch remote control.
 - 3. Remove the door latch remote control.



5. Disconnect the door latch actuating rod from the door latch.



- 6. Remove the rear glass run channel.
 - 1. Remove the bolt.
 - 2. Remove the rear glass run channel.



7. Remove the screws and the door latch.



8. Disconnect the door latch push button rod from the door latch.



9. **NOTE:** Connect the remote control rod, door latch push button rod and lock cylinder rod to the front door latch (21812) before installing the new latch.

NOTE: When the battery is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 16 km (10 mi) or more to relearn the strategy.

To install, reverse the removal procedure.

• Use the special tool to install the new rivet.

Latch —Liftgate Window

Removal

- 1. Open the liftgate window glass.
- 2. Remove the liftgate trim panel. For additional informatioin, refer to Section 501-05.
- 3. Remove the vent panel.
 - 1. Remove the pin-type retainers.
 - 2. Remove the vent panel.



4. Remove the liftgate watershield.



- 5. Disconnect the liftgate window latch actuating rod.
 - 1. Open the clip.
 - 2. Disconnect the liftgate window latch actuating rod.



6. **NOTE:** Mark the position of the liftgate window latch prior to removing the nuts.

Disconnect the electrical connector and remove the nuts.



7. Remove the liftgate window latch.



Installation

1. **NOTE:** Manually close the liftgate window latch to set the latch control rod length.

To install, reverse the removal procedure.

• Before installing the liftgate trim panel, adjust the liftgate window latch; refer to <u>Latch—Liftgate</u> <u>Window, Adjustment</u>.



Latch — Liftgate Window, Adjustment

- 1. Remove the liftgate trim panel. For additional informatioin, refer to <u>Section 501-05</u>.
- 2. Remove the liftgate watershield.



- 3. Close the liftgate window glass.
- 4. Disconnect the liftgate window latch actuating rod.
 - 1. Open the clip.
 - 2. Disconnect the liftgate window latch actuating rod.



5. Loosen the liftgate window latch nuts.



6. Adjust the liftgate window latch.

• Set the liftgate window glass flushness to 1.5mm (0.06 in) under flush.



7. Tighten the liftgate window latch nuts.



- Connect the liftgate window latch activating rod.
 Connect the liftgate window latch actuating rod.
 - 2. Lock the clip.



- 9. Verify the liftgate window glass flushness.
- 10. Install the liftgate watershield.


11. Install, the liftgate trim panel. For additional information, refer to <u>Section 501-05</u>.

Latch —Liftgate

Removal

- 1. Remove the liftgate trim panel. For additional information, refer to Section 501-05.
- 2. Remove the liftgate watershield.



- 3. Disconnect the liftgate latch release rod from the liftgate latch remote control.
 - 1. Open the clip.
 - 2. Disconnect the liftgate latch release rod.



- 4. Remove the liftgate latch.
 - 1. Remove the bolts.
 - 2. Disconnect the electrical connector.
 - 3. Remove the liftgate latch and the liftgate release rod.



Installation

1. **NOTE:** If replacement of the liftgate latch release rods necessary, be sure to match the color coded rods for proper installation.

NOTE: Make sure the liftgate latch release rod is not preloading the latch. It should be clipped in a relaxed state with no slack.

NOTE: Position the liftgate latch release rod by pushing outboard to remove the slack.

To install, reverse the removal procedure.



Handle — Hood Latch Release

Removal

NOTE: The hood latch control handle and cable are replaced as an assembly.

- 1. Remove the hood latch. For additional information, refer to Latch-Hood.
- 2. Unclip the hood latch control handle and cable retainer from the inner fender splash shield.



- 3. Position the hood latch control handle and cable aside.
 - 1. Remove the two screws.
 - 2. Position the hood latch control handle and cable aside.



- 4. Remove the hood latch control handle and cable.
 - 1. Remove the hood latch control and cable grommet from the dash panel.
 - 2. Remove the hood latch control handle and cable.



Installation

1. To install, reverse the removal procedure.



Handle — Door, Outside

Special Tool(s)



Removal

NOTE: Front door shown, rear door similar.

- 1. Remove the door trim panel. For additional information, refer to <u>Section 501-05</u>.
- 2. Remove the watershield.
- 3. NOTE: The front door window glass must be completely up.

Remove the outside door handle.

- 1. Disconnect the front door latch to door handle rod.
- 2. Drill out the two rivets and remove the outside door handle.



Installation

1. NOTE: Front door shown, rear door similar.

To install, reverse the removal procedure.

• Use Heavy-Duty Riveter to install the rivets.

Handle — Door, Inside

Removal

NOTE: Front door shown, rear door similar.

- 1. Remove the door trim panel. For additional information, refer to <u>Section 501-05</u>.
- 2. Disconnect the inside door handle (22600) from the door.
 - 1. Remove the screws.
 - 2. Disconnect the inside door handle.



3. Disconnect the rod from the inside door handle.



Installation

1. NOTE: Front door shown, rear door similar.

To install, reverse the removal procedure.



Handle —Liftgate

Special Tool(s)



Removal

- 1. Remove the liftgate trim panel For additional information, refer to <u>Section 501-05</u>.
- 2. Remove the liftgate watershield.



- 3. Remove the vent panel.
 - 1. Remove the pin-type retainers.
 - 2. Remove the vent panel.



- 4. Disconnect the outside liftgate handle actuating rod.
 - 1. Open the clip.
 - 2. Disconnect the outside liftgate handle actuating rod.



- 5. Remove the license plate lamp shield.
 - 1. Remove the screws.
 - 2. Remove the license plate lamp shield.



- 6. Remove the outside liftgate handle.
 - 1. Drill out the rivets.
 - 2. Remove the outside liftgate handle.



Installation

- 1. To install, reverse the removal procedure.
 - Use Heavy-Duty Riveter to install the rivets.



Lock Cylinder — Door

Removal and Installation

NOTE: When a lock cylinder is replaced, both door lock cylinders, liftgate lock cylinders and ignition lock cylinder should be replaced as a set. This will eliminate carrying an extra key which will fit only one lock. If a key is to be replaced, the new key code number is stamped on a metal tag attached to the key.

NOTE: Individual lock cylinders are repaired by discarding the inoperative cylinder and building a new lock cylinder using the appropriate lock repair package. The lock repair package includes a detailed instruction sheet to build the new lock cylinder to the current key code of the vehicle.

- 1. Remove the front door trim panel (23942). For additional information, refer to Section 501-05.
- 2. If equipped with power windows, connect the battery ground cable. For additional information, refer to <u>Section 414-01</u>.
- 3. Raise the window to the closed position.
- 4. Position the watershield aside.
- 5. Disconnect the front door latch control cylinder rod from the door lock cylinder lever.



6. Slide the (A) door lock cylinder retainer away from the (B) lock cylinder and remove the cylinder.



7. To install, reverse the removal procedure.

Lock Cylinder —Liftgate

Removal

NOTE: Individual lock cylinders are repaired by discarding the inoperative cylinder and building a new lock cylinder using the appropriate lock repair package. The lock repair package includes a detailed instruction sheet to build the new lock cylinder to the current key code of the vehicle.

- 1. If equipped, remove the liftgate lock actuator. For additional information, refer to <u>Actuator—Liftgate</u> <u>Lock</u>.
- 2. Remove the liftgate latch remote control. For additional information, refer to <u>Latch Remote Control</u>_<u>Liftgate</u>.
- 3. Remove the liftgate lock cylinder.
 - 1. Remove the nuts.
 - 2. Remove the liftgate lock cylinder.
 - If equipped, disconnect the electrical connector.



Installation

1. **NOTE:** Manually close the liftgate window latch to set the latch control rod length.

NOTE: Make sure the liftgate window latch actuating rod is not preloading the liftgate window latch. It should be clipped in a relaxed state with no slack.

To install, reverse the removal procedure.



Latch Remote Control —Liftgate

Removal

NOTE: If equipped with power locks, perform steps one and eight.

- 1. Remove the liftgate lock actuator. For additional information, refer to <u>Actuator—Liftgate Lock</u>.
- 2. Remove the liftgate window latch. For additional information, refer to Latch-Liftgate Window.
- 3. Remove the vent panel.
 - 1. Remove the pin-type retainers.
 - 2. Remove the vent panel.



- 4. Disconnect the liftgate latch release rods.
 - 1. Open the clips.
 - 2. Disconnect the liftgate latch release rods.



- 5. Disconnect the liftgate handle rod.
 - 1. Open the clip.
 - 2. Disconnect the liftgate handle rod.



- 6. Disconnect the lock cylinder rod.
 - 1. Open the clip.
 - 2. Disconnect the lock cylinder rod.



7. Remove the liftgate latch remote control bolt.



8. Remove the liftgate latch remote control from the liftgate.

Installation

NOTE: If equipped with power locks, perform steps one and two.

- 1. Install the latch remote control and (if equipped) the push button rod into the liftgate.
- 2. Install the liftgate lock actuator. For additional information, refer to <u>Actuator—Liftgate Lock</u>.
- 3. Loosely install the liftgate latch remote control bolt.



4. **NOTE:** Manually close the liftgate window latch to set the latch control rod length.

Install the liftgate window latch.

- 1. Position the liftgate window latch.
- 2. Install the nuts.
- 3. Connect the electrical connector.



- 5. Connect the liftgate window latch actuating rod.
 - 1. Position the liftgate window latch actuating rod.
 - 2. Close the clip.



6. Tighten the liftgate latch remote control bolt.



- 7. Connect the lock cylinder rod.
 - 1. Position the lock cylinder rod.
 - 2. Close the clip.



8. **NOTE:** Make sure the liftgate handle rod is not preloading the liftgate latch remote control. It should be clipped in a relaxed state with no slack.

Connect the liftgate handle rod.

- 1. Position the liftgate handle rod.
- 2. Close the clip.



9. **NOTE:** Make sure the latch release rods are not preloading the liftgate latch remote control. They should be clipped in a relaxed state with no slack.

Connect the liftgate latch release rods.

- 1. Position the liftgate latch release rods by pushing outboard to remove the slack.
- 2. Close the clips.



- 10. Install the vent panel.
 - 1. Position the vent panel.
 - 2. Install the pin-type retainers.



- 11. Adjust the liftgate window latch. For additional information, refer to <u>Latch—Liftgate Window,</u> <u>Adjustment</u>.
- 12. Install the liftgate watershield.



13. Install the liftgate trim panel. For additional information, refer to Section 501-05.

Actuator — Door, Front

Special Tool(s)



Removal

- 1. Remove the front door trim panel (23942). For additional information, refer to <u>Section 501-05</u>.
- 2. Remove the watershield.
- 3. Remove the power door lock actuator.
 - 1. Disconnect the electrical connector.
 - 2. Drill out the rivet.
 - 3. Disconnect the actuator rod.
 - 4. Remove the actuator.



Installation

- 1. To install, reverse the removal procedure.
 - Use Heavy-Duty Riveter to install the actuator rivet.

Actuator — Door, Rear

Special Tool(s)



Removal

- 1. Remove the rear door trim panel. For additional information, refer to Section 501-05.
- 2. Remove the rear door watershield.



- 3. Remove the power door lock actuator.
 - 1. Disconnect the electrical connector.
 - 2. Drill out the rivet.
 - 3. Disconnect the actuator rod.
 - 4. Remove the actuator.



Installation

• Use Heavy-Duty Riveter to install the actuator rivet.

Actuator —Liftgate Lock

Removal

- 1. Disconnect the battery ground cable (14301).
- 2. Remove the liftgate window latch. For additional information, refer to Latch-Liftgate Window.
- 3. Remove the vent panel.
 - 1. Remove the pin-type retainers.
 - 2. Remove the vent panel.



- 4. Disconnect the liftgate latch release rods.
 - 1. Open the clips.
 - 2. Disconnect the liftgate latch release rods.



- 5. Disconnect the liftgate handle rod.
 - 1. Open the clip.
 - 2. Disconnect the liftgate handle rod.



- 6. Disconnect the lock cylinder rod.
 - 1. Open the clip.
 - 2. Disconnect the lock cylinder rod.



7. Remove the liftgate latch remote control bolt.



8. Disconnect the liftgate lock actuator electrical connector.



9. Remove the liftgate lock actuator nuts.



10. Move the liftgate latch remote control to the LH opening and remove the liftgate lock actuator.

Installation

- 1. Connect and position the liftgate lock actuator.
- 2. Install the liftgate lock actuator nuts.



3. Connect the liftgate lock actuator electrical connector.



- 4. Position the liftgate latch remote control.
- 5. Loosely install the liftgate latch remote control bolt.



6. **NOTE:** Manually close the liftgate window latch to set the latch control rod length.

Install the liftgate window latch.

- 1. Position the liftgate window latch.
- 2. Install the nuts.
- 3. Connect the electrical connector.



- 7. Connect the liftgate window latch actuating rod.
 - 1. Position the liftgate window latch actuating rod.
 - 2. Close the clip.



8. Tighten the liftgate latch remote control bolt.



9. **NOTE:** Be sure the bell crank of the liftgate latch remote control is in the unlocked position (upward) for proper lock cylinder rod length.

Connect the lock cylinder rod.

- 1. Position the lock cylinder rod.
- 2. Close the clip.



10. **NOTE:** Make sure the liftgate handle rod is not preloading the liftgate latch remote control. It should be clipped in a relaxed state with no slack.

Connect the liftgate handle rod.

- 1. Position the liftgate handle rod.
- 2. Close the clip.



11. **NOTE:** Make sure the latch release rods are not preloading the liftgate latch. They should be clipped in a relaxed state with no slack.

Connect the liftgate latch release rods.

- 1. Position the liftgate latch release rods by pushing outboard to remove the slack.
- 2. Close the clips.



- 12. Adjust the liftgate window latch. For additional information, refer to <u>Latch—Liftgate Window</u>, <u>Adjustment</u>.
- 13. Install the liftgate watershield.



- 14. Install the vent panel.
 - 1. Position the vent panel.
 - 2. Install the pin-type retainers.



- 15. Install the liftgate trim panel. For additional information, refer to <u>Section 501-05</u>.
- 16. Connect the battery ground cable.

Switch — Door Open Warning

Removal

- 1. Remove the door trim panel. For additional information, refer to Section 501-05.
- 2. Remove the door latch. For additional information, refer to Latch-Door.
- 3. Remove the door opening warning lamp switch.
 - 1. Lift the locking tab.
 - 2. Rotate the door opening warning lamp switch counterclockwise.
 - 3. Remove the door opening warning lamp switch.



Installation

1. To install, reverse the removal procedure.
SECTION 501-14B: Keyless Entry/Computer Operated Locks SPECIFICATIONS

2000 Explorer/Mountaineer Workshop Manual

Torque Specifications

Description	Nm	lb-in
Battery ground cable	10	89

SECTION 501-14B: Keyless Entry/Computer Operated Locks DESCRIPTION AND OPERATION 2000 Explorer/Mountaineer Workshop Manual

Keyless Entry

The keyless entry system components consist of the following:

- keyless entry remote transmitter (15K601)
- remote anti-theft personality (RAP) module (15K602)
- driver unlock relay (if equipped with two step unlocking)
- all unlock relay
- all lock relay
- keyless entry keypad (14A626)

The electronic door lock system has three main components: the remote anti-theft personality (RAP) module, attached to the rear left hand quarter panel, the three-button (hand held) keyless entry remote transmitter (15K601), and the keyless entry keypad (14A626) on the driver side door.

The door locks are controlled by the RAP module through three external relays: the driver unlock relay (if equipped with two step unlocking), the all unlock relay, and the all lock relay. These relays are located in the relay box on the LH rear quarter panel.

The keyless entry remote transmitter initiates the following electronic door lock system functions:

- Unlocks the driver door (if equipped with two step unlocking).
- Unlocks all doors.
- Locks all doors.
- Enables the panic alarm.
- Issues the interior lamps on (when unlocking) and off (when locking) commands to the generic electronic module (GEM).
- Sounds the horn (13832) once when LOCK on keyless entry remote transmitter is pressed twice, and doors are closed.
- Sounds the horn twice when LOCK on the keyless entry remote transmitter is pressed twice, and any door or the liftgate window is ajar.
- Allows up to four keyless entry remote transmitters to be programmed.
- The order that the transmitters are programmed into the module will set the memory seat to the corresponding position when the driver door is unlocked with the transmitter.

NOTE: The remote entry features will not function when the ignition switch (11572) is in the RUN or ACC position.

The keyless entry remote transmitters are reprogrammable and must be set at the same time.

To confirm that the doors have been locked and that the anti-theft system has armed, press the LOCK button again, within five seconds of the first press. The horn will sound once if the doors have locked and all doors are closed.

To activate the panic alarm:

• Press the red PANIC button on the keyless entry remote transmitter. The horn will sound and the headlamps (13008) and exterior lamps will flash for a maximum of two minutes and 45 seconds.

To deactivate the panic alarm:

- Press the red PANIC button again on the keyless entry remote transmitter.
- Turn the ignition switch to RUN/ACC.

The keyless entry keypad can be used to unlock the driver door (if equipped with two step unlocking) or lock and unlock all the doors and the liftgate. It also lights the keypad lamp, allows one user code to be programmed and issues illuminated entry on/off requests to the GEM when locking and unlocking.

The system (permanent) entry code is located on the owner's wallet card in the glove box; it is also electronically accessible by asking for the RAP KEYCODE PID on the scan tool and on the receiver assembly housing.

The receiver assembly is programmed at the factory with a five-digit entry code. A replacement receiver assembly includes a new owner's code card.

To turn on the interior lamps and light all illuminated components, press any button on the keyless entry keypad.

To program a temporary access code:

- Enter the permanent code on the keyless entry keypad.
- Press the 1/2 button within 5 seconds of last digit of permanent code. (This alerts system to accept temporary code.)
- Enter alternate 5-digit code. Do not exceed 5 seconds between entering digits or between pressing the 1/2 button and entering the first digit.

If equipped with two step unlocking:

To unlock the driver door, enter the permanent factory code or enter the owner's alternate code. To unlock the passenger door(s) and liftgate, press the 3/4 button within five seconds of unlocking the driver door.

If not equipped with two step unlocking:

To unlock all the doors and the liftgate, enter the permanent factory code or enter the owner's alternate code.

To lock all doors, press the 7/8 and 9/0 buttons at the same time. (It is not necessary to enter the key code first.) This will turn off courtesy lamps.

NOTE: The doors will not lock if the vehicle is started in neutral and passed into any forward gear.

If the autolock feature is enabled, the autolock feature will activate when the ignition switch is in the RUN/ACC position, the shift control selector is passed into or through the reverse (R) position and all doors, liftgate and liftgate window are closed when the driver releases the brake pedal (2455).

After the initial lock, all doors will automatically relock when any door is opened and then closed followed by the release of the brake pedal. However, the doors will not relock if the ignition switch is in the OFF position.

NOTE: The door ajar state will be monitored continuously for 500 ms after locking has occurred. If a door is opened again within 500 ms, the driver door will unlock.

The door may not automatically lock if the vehicle is shifted quickly into gear after starting the engine (6007).

Autolock Enable/Disable — Using the Keypad

A manual enable/disable mode allows the autolock and memory seat features to be turned off and on; there are PIDs in RAP (autolock and memory seat) which reflect if the feature is ON or OFF. The RAP module configuration can be used to turn the "autolock" on/off and turn the "move mem. seat w/ key fob" on/off. These PIDs (AUTOLOCK and MEMSEAT) are only available on the Ford Service Function (FSF) Card. RAP module configuration will not be available at the beginning of the 1998 model year.

To enable or disable autolock using the keyless entry keypad:

- 1. Enter the five-digit permanent entry code into the keyless entry keypad.
- 2. Within five seconds of entering the code, press and hold the 7/8 button on the keypad.
- 3. Within five seconds of Step 2, and while holding the 7/8 button, press the 3/4 button on the keypad and release it.
- 4. Within five seconds of Step 3, release the 7/8 button on the keypad.

If the autolock sound is disabled, the horn will chirp once. If the autolock feature is enabled, the horn will chirp once shortly and then sound a second time with a longer sound of the horn once the above sequence is completed.

Autolock Enable/Disable — Using the Ignition Switch

Another way to turn the autolock off/on is by following this series of steps:

- 1. Close all doors.
- 2. Confirm that the ignition switch is in the OFF position.
- 3. **NOTE:** Steps 4 through 8 must be performed within 30 seconds.

Turn the ignition switch from OFF to RUN.

- 4. Press the driver interior power door lock UNLOCK button three times.
- 5. Turn the ignition switch from RUN to OFF.
- 6. Press the driver interior power door lock UNLOCK button three times.
- 7. Turn the ignition switch from OFF to RUN.
- 8. Verify that the RAP module chirps the horn. This indicates that the RAP module is now in the enable/disable mode and ready to accept program changes.
- 9. Press the driver interior power door lock UNLOCK button one time to command the RAP module to toggle the autolock/relock feature OFF.
- 10. Press the driver interior power door lock LOCK button once to enter the command.
- 11. Verify that the horn chirps one time to signal the RAP module confirmation of the command. There should only be one chirp indicating that autolock/relock feature has been disabled. If one chirp is heard, followed by a longer sound of the horn, the autolock/relock feature has just been enabled.

Return to step 10.

- 12. Turn the ignition switch to the OFF position to exit the enable/disable mode.
- 13. Exit the vehicle and verify that the RAP module chirps the horn once to indicate that a feature has been changed and that autolock/relock has been disabled.

SECTION 501-14B: Keyless Entry/Computer Operated Locks DIAGNOSIS AND TESTING 2000 Explorer/Mountaineer Workshop Manual

Keyless Entry

Refer to Wiring Diagrams Cell <u>117</u>, Remote Control Alarm and Lock System for schematic and connector information.

Special Tool(s)

TENE	73 Digital Multimeter or equivalent
Ø	105-R0051
ST1137-A	
The second secon	Worldwide Diagnostic System (WDS)
	418-F224,
	New Generation STAR Tester
STOOD A	418-F052, or equivalent

Inspection and Verification

- 1. Verify the customer concern by operating the electronic door lock control system.
- 2. Visually inspect for obvious signs of mechanical and electrical damage; refer to the following chart:

Visual Inspection Chart

Mechanical	Electrical
 Binding latches 	 Fuse(s) 20 (7.5A), 9 (20A), 18 (10A), 1 (60A), and 25 (7.5A) Relays Wiring harness Loose or corroded connections Keyless entry keypad Remote transmitter Door open warning lamp switch

- 3. If the concern remains after the inspection, connect the scan tool to the data link connector (DLC) located beneath the instrument panel and select the vehicle to be tested from the scan tool menu. If scan tool does not communicate with the vehicle:
 - check that the program card is properly installed.
 - check the connections to the vehicle.
 - check the ignition switch position.
- 4. If scan tool still does not communicate with the vehicle, refer to the scan tool manual.
- 5. Perform the DATA LINK DIAGNOSTIC TEST. If the scan tool responds with:

- CKT914, CKT915 or CKT70 = ALL ECUS NO RESP/NOT EQUIP, refer to Section 418-00.
- NO RESP/NOT EQUIP for RAP, go to Pinpoint Test A.
- NO RESP/NOT EQUIP for GEM/CTM, go to Pinpoint Test G.
- SYSTEM PASSED, retrieve and record the continuous diagnostic trouble codes (DTCs), erase the continuous DTCs and perform self-test diagnostics for the RAP.
- 6. If the DTCs retrieved are related to the concern, go to RAP Diagnostic Trouble Code (DTC) Index or GEM/CTM Diagnostic Trouble Code (DTC) Index to continue diagnostics.
- 7. If no DTCs related to the concern are retrieved, proceed to Symptom Chart to continue diagnostics.

RAP Module Diagnostic Trouble Code (DTC) Index

RAP Module Diagnostic Trouble Code (DTC) Index

DTC	Description	DTC Caused By	Action
B1309	Power Door Lock Circuit Short to Ground	RAP	GO to Pinpoint Test C.
B1341	Power Door Unlock Circuit Short to Ground	RAP	GO to Pinpoint Test C.
B1485	Brake Pedal Input Circuit Short to Battery	RAP	GO to Pinpoint Test D.
B1526	Keyless Entry Keypad Switch Circuit Short to Ground	RAP	GO to <u>Pinpoint Test B</u> .
B1629	PRNDL Reverse Input Short to Battery	RAP	GO to <u>Pinpoint Test E</u> .
B1845	Ignition Tamper Circuit Failure	RAP	Invalid DTC. Ignore this DTC.
B2425	Keyless Entry Out of Synchronization	RAP	GO to Pinpoint Test C.
B1334	Decklid Ajar Rear Door Circuit Short to Ground	RAP	REFER to Section 417-02.

RAP Module Parameter Identification (PID) Index

RAP Module Parameter Identification (PID) Index

PID	Description	Expected Value
AL_EVT#	Last 8 Alarm Events	DROPEN, HOODTR, IGNTAM, PANIC, T_AJAR, NOEVNT
BOO	Brake Switch Input	OFF, ON
D_DOOR	Left Front Door Ajar Switch	CLOSED, AJAR
DECKLID	Decklid / Hatch Ajar	CLOSED, AJAR
DR_LOCK	Driver Door Lock Output State	NO, YES
DR_UNLK	All Doors Unlock Output State	NO, YES
DRLKCYL	Door Lock Cylinder	notACT, ACTIVE
HOOD_SW	Decklid/Hatch Or Hood Punchout	notPUN, PUNCHD
IGN_A	Ignition Switch -ACCY Position	NO, YES
IGN_R	Ignition Switch -RUN Position	NO, YES

IGN_RES	Ignition Tamper Sensor	HIGH
KEY_PAD	Keypad	1/2, 3/4, 5/6, 7/8, 9/0
KEYCODE	Factory Keyless Entry Code	5 Digit #, INVLD
TRANSGR	Transmission Gear	notREV, REV

RAP Active Command Index

RAP Active Command Index

Active Command	Display	Action
THEFT LED	ALARM	ON, OFF
ILLUMINATED ENTRY	INT LAMPS	ON, OFF
HEAD/PARKING LAMPS	PARKLAMPS	ON, OFF
HEAD/PARKING LAMPS	HEADLAMPS	ON, OFF
DOOR LOCK CONTROL	LOCK	ON, OFF
DOOR LOCK CONTROL	UNLOCK	ON, OFF
DOOR LOCK CONTROL	DD UNLOCK	ON, OFF
HORN CONTROL	HORN	ON, OFF
STARTER INTERRUPT CONTROL	STARTER	ON, OFF
KEYPAD BACKLIGHTING	LIGHT	ON, OFF
SEAT MEMORY SELECT CONTROL	MEMORY 1	ON, OFF
SEAT MEMORY SELECT CONTROL	MEMORY 2	ON, OFF

GEM/CTM Diagnostic Trouble Code (DTC) Index

GEM/CTM Diagnostic Trouble Code (DTC) Index

DTC	Description	DTC Caused By	Action
P0500	Vehicle Speed Signal Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
B1302	Accessory Delay Relay Coil Circuit Failure	GEM	REFER to <u>Section 501-11</u> .
B1304	Accessory Delay Relay Coil Circuit Short to Battery	GEM	REFER to <u>Section 501-11</u> .
B1313	Battery Saver Relay Coil Circuit Failure	GEM/CTM	REFER to <u>Section 417-02</u> .
B1315	Battery Saver Relay Coil Circuit Short to Battery	GEM/CTM	REFER to <u>Section 417-02</u> .
B1317	Battery Voltage HIGH	GEM/CTM	REFER to Section 414-00.
B1318	Battery Voltage LOW	GEM/CTM	REFER to Section 414-00.

Page	4 of	66
------	------	----

B1322	Door Ajar LF Circuit Short to Ground	GEM/CTM	REFER to <u>Section 417-02</u> .
B1323	Door Ajar Lamp Circuit Failure	GEM/CTM	REFER to Section 413-01.
B1325	Door Ajar Lamp Circuit Short to Battery	GEM/CTM	REFER to <u>Section 413-01</u> .
B1330	Door Ajar RF Circuit Short to Ground	GEM/CTM	REFER to Section 417-02.
B1334	Decklid Ajar Rear Door Circuit Short to Ground	GEM/CTM	REFER to <u>Section 417-02</u> .
B1338	RR Door Ajar Circuit Short to Ground	GEM/CTM	REFER to <u>Section 417-02</u> .
B1340	Chime Input Request Circuit Short to Ground	GEM/CTM	REFER to <u>Section 413-09</u> .
B1342	GEM/CTM is Defective	GEM/CTM	CLEAR the DTCs. RETRIEVE the DTCs. If DTC B1342 is retrieved, REPLACE the GEM/CTM; REFER to <u>Section 419-</u> <u>10</u> . TEST the system for normal operation.
B1345	Heated Backlite Input Circuit Short to Ground	GEM	REFER to <u>Section 501-11</u> .
B1347	Heated Backlite Relay Circuit Failure	GEM	REFER to <u>Section 501-11</u> .
B1349	Heated Backlite Relay Circuit Short to Battery	GEM	REFER to <u>Section 501-11</u> .
B1352	Ignition Key-In Circuit Failure	GEM/CTM	REFER to <u>Section 413-09</u> .
B1355	Ignition RUN Circuit Failure	GEM/CTM	REFER to Section 211-05, Symptom Chart.
B1359	Ignition RUN/ACC Circuit Failure	GEM/CTM	REFER to Section 211-05, Symptom Chart.
B1371	Illuminated Entry Relay Circuit Failure	GEM/CTM	REFER to <u>Section 417-02</u> .
B1373	Interior Lamp Relay Coil Circuit Short to Battery	GEM/CTM	REFER to <u>Section 417-02</u> .
B1398	Power Window Driver One-Touch Window Relay Circuit Failure	GEM	REFER to <u>Section 501-11</u> .
B1400	Power Window Driver One-Touch Window Relay Coil Circuit Short to Battery	GEM	REFER to <u>Section 501-11</u> .
B1404	Power Window Driver Down Circuit Open	GEM	REFER to <u>Section 501-11</u> .
B1405	Driver Power Window Down Circuit to Battery	GEM	REFER to <u>Section 501-11</u> .
B1410	Power Window Driver Motor Circuit Failure	GEM	REFER to <u>Section 501-11</u> .
B1426	Seat Belt Lamp Circuit	GEM/CTM	REFER to Section 413-01.

	Short to Battery		
B1428	Seat Belt Lamp Circuit Failure	GEM/CTM	REFER to <u>Section 413-01</u> .
B1431	Wiper Brake/Run Relay — Circuit Failure	GEM/CTM	REFER to Section 501-16.
B1432	Wiper Brake/Run Relay Short to Battery	GEM/CTM	REFER to <u>Section 501-16</u> .
B1434	Wiper Hi/Lo Speed Relay — Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1436	Wiper Hi/Lo Speed Relay Circuit Short to Battery	GEM/CTM	REFER to <u>Section 501-16</u> .
B1438	Wiper Mode Select Switch Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1441	Wiper Mode Select Switch Input Short to Ground	GEM/CTM	REFER to <u>Section 501-16</u> .
B1446	Wiper Park Sense Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1450	Wiper/Wash Interval Delay Switch Input Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1453	Wiper/Wash Interval Delay Switch Input Short to Ground	GEM/CTM	REFER to <u>Section 501-16</u> .
B1458	Wiper/Washer Pump Motor Relay Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1460	Wiper/Washer Pump Motor Relay Coil Short to Battery	GEM/CTM	REFER to Section 501-16.
B1462	Seat Belt Switch Circuit Failure	GEM/CTM	REFER to Section 413-09.
B1466	Wiper Hi/Lo Speed Not Switching	GEM/CTM	REFER to <u>Section 501-16</u> .
B1467	Wiper Hi/Lo Speed Circuit Motor Short to Battery	GEM/CTM	REFER to <u>Section 501-16</u> .
B1473	Wiper Low Speed Circuit Motor Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1475	Accessory Delay Relay Contacts Short to Battery	GEM/CTM	REFER to <u>Section 501-11</u> .
B1476	Wiper High Speed Circuit Motor Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1483	Brake Pedal Input Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
B1485	Brake Pedal Input	GEM	REFER to <u>Section 308-07A</u> .

	Short Circuit to Battery		
B1574	LR Door Ajar Circuit Short to Ground	GEM/CTM	REFER to <u>Section 417-02</u> .
B1577	Lamp Park Input Short Circuit to Battery	GEM/CTM	REFER to <u>Section 413-09</u> .
B1610	Illuminated Entry Input (From RAP Module) Circuit Short to Ground	GEM	REFER to <u>Section 417-02</u> .
B1611	Wiper Rear Mode Select Switch Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B1614	Wiper Rear Mode Select Switch Circuit Short to Ground	GEM	REFER to <u>Section 501-16</u> .
B1814	Wiper Rear Motor Down Relay Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B1816	Wiper Rear Motor Down Relay Coil Circuit Short to Battery	GEM	REFER to <u>Section 501-16</u> .
B1818	Wiper Rear Motor Up Relay Coil Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B1820	Rear Wiper Motor Up Relay Circuit Short to Battery	GEM	REFER to <u>Section 501-16</u> .
B1833	Door Unlock Switch Circuit Short to Ground	GEM	GO to <u>Pinpoint Test F</u> .
B1834	Door Unlock Disarm Output Circuit Failure	GEM	GO to <u>Pinpoint Test F</u> .
B1836	Door Unlock Disarm Output Circuit Short to Battery	GEM	GO to <u>Pinpoint Test F</u> .
B1839	Wiper Rear Rear Motor Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B1840	Wiper Front Power Circuit Failure	GEM/CTM	REFER to <u>Section 501-16</u> .
B1894	Wiper Rear Motor Speed Sense Circuit Failure	GEM	REFER to <u>Section 501-16</u> .
B2105	Throttle Position Input (TPI) Signal Out of Range Low	GEM	REFER to <u>Section 308-07A</u> .
B2106	Throttle Position Input (TPI) Signal Out of Range High	GEM	REFER to <u>Section 308-07A</u> .
B2141	NVM Configuration Failure	GEM/CTM	Vehicle speed calibration data is not programmed into the GEM/CTM. REFER to the scan tool help screen on the configuration card to program the tire size and axle ratio.

			TEST the system for normal operation. If DTC B2141 is still present, REPLACE the GEM/CTM. REFER to <u>Section 419-10</u> . TEST the system for normal operation.			
P1763	Transmission Neutral "In Tow" Indicator Circuit Short to Battery	GEM	REFER to <u>Section 413-09</u> .			
P1764	Transmission Neutral "In Tow" Indicator Circuit Fault	GEM	REFER to <u>Section 413-09</u> .			
P1804	4WD High Indicator Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1806	4WD High Indicator Short Circuit to Battery	GEM	REFER to <u>Section 308-07A</u> .			
P1808	4WD Low Indicator Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1810	4WD Low Indicator Short Circuit to Battery	GEM	REFER to <u>Section 308-07A</u> .			
P1812	4WD Mode Select Switch Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1815	4WD Mode Select Short Circuit to Ground	GEM	REFER to <u>Section 308-07A</u> .			
P1820	Transfer Case CW Shift Relay Coil Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1822	Transfer Case CW Shift Relay Coil Short to Power	GEM	REFER to <u>Section 308-07A</u> .			
P1824	4WD Electric Clutch Relay Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1826	4WD LOW Clutch Relay Short to Battery	GEM	REFER to <u>Section 308-07A</u> .			
P1828	Transfer Case CCW Shift Relay Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1830	Transfer Case CCW Shift Relay Coil Short to Battery	GEM	REFER to <u>Section 308-07A</u> .			
P1836	Transfer Case Front Shaft Speed Sensor Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1837	Transfer Case Rear Shaft Speed Sensor Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1838	Transfer Case Shift Motor Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1846	Transfer Case CONTACT PLATE "A" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .			
P1850	Transfer Case	GEM	REFER to Section 308-07A.			

	CONTACT PLATE "B" Circuit Failure		
P1854	Transfer Case CONTACT PLATE "C" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1858	Transfer Case CONTACT PLATE "D" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1866	Transfer Case System Concern	GEM	REFER to Section 308-07A.
P1867	Transfer Case Contact Plate General Circuit Failure	GEM	REFER to Section 308-07A.
P1874	Automatic Hall Effect Sensor Power Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1875	Automatic Hall Effect Sensor Power Circuit Short to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1891	Transfer Case Contact Plate Ground Return Open Circuit	GEM	REFER to <u>Section 308-07A</u> .

GEM/CTM Parameter Identification (PID) Index

GEM/CTM Parameter Identification (PID) Index

PID	Description	Expected Values	
VSS_GEM	Vehicle Speed Input	0 - 255 KPH	
PARK_SW	External Access Ajar Switch Status	OFF, ON	
D_DR_SW	Driver Door Ajar Switch Status	CLOSED, AJAR	
DR_DSRM	Door Disarm Switch Status	L_DOOR, R_DOOR, LIFT_G, OFF	
DR_UNLK	All Doors Unlock Output State	ON, OFF, ON-B-, OFFO-G	
P_DR_SW	Passenger Door Ajar Switch Status	CLOSED, AJAR	
IGN_KEY	Key-In-Ignition Status	IN, OUT	
IGN_GEM	Ignition Switch Status	START, RUN, OFF, ACCY	
BATSAV	Battery Saver Relay Circuit	ON, OFF, ON-B-, OFFO-G	
VBATGEM	Battery Voltage	0.0 VDC - 14.3 VDC	
LGATESW	Liftgate Ajar Switch Status	CLOSED - AJAR	
LRDR_SW	Left Rear Door Ajar Switch Status	CLOSED - AJAR	
RRDR_SW	Right Rear Door Ajar Switch Status	CLOSED - AJAR	
INTLMP	Illuminated Entry Relay Circuit	ON, OFF, ON-B-, OFFO-G	
CLTCHSW	Transmission Clutch Interlock Switch (GEM Only)	ENGAGED, NOT ENGAGED	
NTRL_SW	Neutral Safety Switch Input (GEM Only)	NTRL, not NTRL	
MTR_CCW	Transmission Transfer CCW Motor Output (GEM	ON, OFF, ON-B, OFFO-G	

	Only)	
MTR_CW	CW Shift Relay Coil Status (GEM Only)	OFF, ON, ON-B-, OFFO-G
4WD_SW	4WD Switch Status (GEM Only)	AUTO, 4WDLOW, 4WDHIGH
4WDELCL	4WD Electric Clutch	ON, OFF, ON-B-, OFFO-G
TRANSGR	Transmission Gear Status	REV, notREV
4WDCLCH	4WD Electronic Clutch Output Status (GEM Only)	ON, OFF, OFFO-G, ON-B-
4WDLOW	4WD Low Indicator Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
4WDHIGH	4WD High Indicator Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
PLATE_A	Transfer Case Contact Plate Switch A (GEM Only)	OPEN, CLOSED
PLATE_B	Transfer Case Contact Plate Switch B (GEM Only)	OPEN, CLOSED
PLATE_C	Transfer Case Contact Plate Switch C (GEM Only)	OPEN, CLOSED
PLATE_D	Transfer Case Contact Plate Switch D (GEM Only)	OPEN, CLOSED
BOO_GEM	Brake Pedal Position (BPP) Switch Input (GEM Only)	ON, OFF
HALLPWR	Hall Effect Speed Sensor Power (GEM Only)	ON, OFF, ON-B-, OFFO-G
4WDCLST	4WD Clutch PWM Output Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
TRA_RSP	Rear Shaft Speed (GEM Only)	0-255 mph
TRA_FSP	Front Shaft Speed (GEM Only)	0-225 mph
PLATEPW	Contact Plate Ground Output (GEM Only)	ON, OFF, ON-B-, OFFO-G
PWR_RLY	ABS Active Input	ON, OFF
NTF	Neutral Tow Function (GEM Only)	ON, OFF
NTF_LMP	Neutral Tow Light (GEM Only)	ON, OFF
D_SBELT	Driver Seat Belt Status	OUT, IN
IPCHIME	External Chime Request	ON, OFF
SBLTMP	Seat Belt Indicator Status	OFF, ON, OFFO-G, ON-B-
DRAJR_L	Door Ajar Warning Lamp Circuit	OFF, ON
D_PWRLY	One Touch Down Relay Coil Circuit Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
D_ PWAMP	Driver Power Window Regulator Electric Drive Current (GEM Only)	0.25 amp increments
D_PWPK	Driver Power Window Regulator Electric Drive Peak Current (GEM Only)	0.25 amp increments
ACCDLY	Accessory Delay Relay Coil Circuit (GEM Only)	ON, OFF, ON-B-, OFFO-G
RDEF_ SW	Rear Defrost Control Switch Status	ON, OFF
RDEFRLY	Rear Window Defrost Relay Coil Circuit	ON, OFF, ON-B-, OFFO-G
WASHRLY	Washer Relay Status	ON, OFF, ON-B-, OFFO-G
WPPK_PK	Wiper Park-to-Park Time	0 - 65 Seconds
WPMODE	Wiper Control Mode Status	WASH, OPEN, INVLD, OFF, INTVL 1- 7, LOW, HIGH
WPPRKSW	Wiper Motor Status	PARKED, notPRK
		Ú

WPRUN	Wiper Mode Run Relay	ON, OFF, ON-B-, OFFO-G	
WPHISP	Windshield Wiper HI/LO Relay Status	ON, OFF, ON-B-, OFFO-G	
WASH_SW	Washer Pump Relay Switch Status	OFF, ON, ON-B-, OFFO-G	
R_WP_UP	Rear Wiper Up Relay Status (GEM Only)	ON, OFF, ON-B-, OFFO-G	
R_WP_DN	Rear Wiper Down Relay Status (GEM Only)	ON, OFF, ON-B-, OFFO-G	
R_WP_SW	Rear Wiper Input Switch Status (GEM Only)	WPLOW, OFF, WPHIGH	
R_WP_MD	Rear Wiper Mode Switch Status (GEM Only)	OFF, INTVL 1-2, LOW WASH	
R_WP_PK	Rear Wiper Park Status (GEM Only)	PARKED, notPRK	

GEM/CTM Active Command Index

GEM/CTM Active Command Index

Active Command	Display	Action
PID LATCH	PID LATCH	ON, OFF
FRONT WIPER	WIPER RLY	ON, OFF
FRONT WIPER	SPEED RLY	ON, OFF
FRONT WIPER	WASH RLY	ON, OFF
WARNING LAMPS AND CHIME	SBLT LAMP	ON, OFF
WARNING LAMPS AND CHIME	CHIME	ON, OFF
WARNING LAMPS AND CHIME	AJAR LAMP	ON, OFF
BATTERY SAVER	BATT SAVR	ON, OFF
INTERIOR COURTESY LAMPS	INT LAMPS	ON, OFF
ONE TOUCH DOWN AND ACCY DELAY (GEM Only)	ACCY RLY	ON, OFF
ONE TOUCH DOWN AND ACCY DELAY (GEM Only)	ONE TOUCH	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	CW/CCW	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	HIGH LAMP	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	LOW LAMP	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	PLATE PWR	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	SHFT CLCH	ON, OFF
SHIFT CLUTCH CONTROL	CLUTCH SOL	ANALOG %
NEUTRAL IN TOW LAMP	NTFLAMP	ON, OFF
REAR WIPER (GEM Only)	UP RELAY	ON, OFF
REAR WIPER (GEM Only)	DWN RELAY	ON, OFF
HEATED BACKLIGHT	RLY CNTRL	ON, OFF
DOOR LOCK CONTROL	DD UNLOCK	ON, OFF

GEM/CTM Wiggle Test Diagnostic Trouble Code (DTC) Index

GEM/CTM Wiggle Test Diagnostic Trouble Code (DTC) Index

DTC	Description	DTC Caused By
		1 1

B1317	Battery Voltage HIGH	GEM/CTM
B1318	Battery Voltage LOW	GEM/CTM
B1322	Door Ajar LF Circuit Short to Ground	GEM/CTM
B1330	Passenger Door Ajar Circuit Short to Ground	GEM/CTM
B1352	Ignition Key-In Circuit Failure	GEM/CTM
B1410	Driver Power Window Motor Circuit Failure	GEM
B1438	Wiper Mode Select Switch Circuit Failure	GEM/CTM
B1441	Wiper Mode Select Switch Input Short to Ground	GEM/CTM
B1446	Wiper Park Sense Circuit Failure	GEM/CTM
B1450	Wiper/Wash Interval Delay Switch Input Circuit Failure	GEM/CTM
B1453	Wiper/Wash Interval Delay Switch Input Short to Ground	GEM/CTM
B1462	Seat Belt Switch Circuit Failure	GEM/CTM
B1577	Lamp Park Input Short Circuit to Battery	GEM/CTM
B1610	Illuminated Entry Input (From RAP Module) Circuit Short to Ground	GEM
B1833	Door Unlock Disarm Switch Circuit Short to Ground	GEM

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action		
 No Communication With the Module — Remote Anti-Theft Personality (RAP) 	 Fuse(s) 20 (7.5A) and 9 (20A). Circuitry. RAP module. 	 GO to <u>Pinpoint Test A</u>. 		
 The Doors Do Not Lock/Unlock Using the Keyless Entry Keypad 	 Keyless entry keypad. Circuitry. RAP module. 	 GO to <u>Pinpoint Test B</u>. 		
 The Doors Do Not Lock/Unlock Using the Remote Transmitter — If Equipped With Two Step Unlocking 	 Keyless entry remote transmitter. Antenna. Keyless entry remote transmitter program. Radio/TV tower. 	GO to <u>Pinpoint Test C</u> .		
The Illuminated Entry Does Not Operate From Remote Transmitter	GEM.Circuitry.RAP module.	 REFER to <u>Section 417-02</u>. 		
The Auto-lock Does Not Operate Properly	Circuitry.Door open	GO to <u>Pinpoint Test D</u> .		

	 warning lamp switch. Brake Pedal Position (BPP) switch. Digital TR sensor. 	
 The Memory Seat Does Not Operate Properly Using the Remote Transmitter 	 Circuitry. RAP module. Seat module (DSM). 	 GO to <u>Pinpoint Test E</u>.
 All Door Locks Are Inoperative — Two Step Unlock Does Not Operate Properly (If Equipped) 	 Switches. Circuitry. Door unlock relay. GEM. DTC B1833. DTC B1834. DTC B1836. Fuse 18 (10A). 	GO to <u>Pinpoint Test F</u> .
 No Communication With The Module — Generic Electronic Module/Central Timer Module 	 Circuitry. Fuse(s) 1 (60A) and 25	GO to <u>Pinpoint Test G</u> .
The Panic Button Does Not Operate Using the Remote Transmitter (Unlock and Lock Operate Properly)	 Keyless entry remote transmitter. RAP module. 	 CHECK both transmitters for panic operation. If only one transmitter does not operate, REPLACE the batteries. TEST the transmitter panic operation. If the transmitter still does not operate, REPLACE the transmitter. If both transmitters do not operate, REPLACE the RAP module; REFER to <u>Section 419-10</u>. TEST the system for normal operation.

Pinpoint Tests

CAUTION: Be careful when probing the fuse junction panel, battery junction box or any connectors. Damage will result to the connector receptacle if the probe or terminal being used is too large.

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage may result.

NOTE: If continuous DTCs are recorded and the symptom is not present when performing the pinpoint tests, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.

PINPOINT TEST A: NO COMMUNICATION WITH THE MODULE — REMOTE ANTI-THEFT PERSONALITY (RAP)







PINPOINT TEST B: THE DOORS DO NOT LOCK/UNLOCK USING THE KEYLESS ENTRY KEYPAD

CONDITIONS	DETAILS/RESULTS/ACTIONS			
B1 CONFIRM NORMAL KEYLESS ENTRY KEYF	PAD OPERATION			
	1 Unlock the driver door with keypad code.			
	Confirm keyless entry keypad back lighting and interior lamp illumination after first keypad button pressed.			
	Press the 3/4 button within five seconds of unlocking driver door with keypad code to unlock all doors.			
	 Press 7/8 and 9/0 buttons to lock all doors. Keypad back lighting and interior lamp illumination should turn off. 			
	 Do all functions operate as expected? 			
	→ Yes VERIFY the concern. RETURN to the Symptom Chart.			
	→ No If keyless entry keypad code does not operate (or has been lost), GO to <u>B2</u> .			
	If the doors unlock, but the keyless entry keypad back lighting does not operate, GO to <u>B7</u> .			













		RAP Module	Circuit	
		C336-5	78 (LB/Y)	
		C336-6	79 (LG/R)	
		C336-19	121 (Y/BK)	
Ω		C336-7	122 (Y)	
		C336-8	123 (R)	
GN2207-B	→ Yess REI Key TES → No REI DTO	Are the resista ohms? PLACE the key pad—Keyless ST the system f PAIR the circui Cs. TEST the s	ances greate dess entry ke <u>Entry</u> . CLEA for normal op t(s) in questio ystem for no	er than 10,000 eypad; REFER to AR the DTCs. beration. on. CLEAR the rmal operation.

PINPOINT TEST C: THE DOORS DO NOT LOCK/UNLOCK USING THE REMOTE TRANSMITTER — IF EQUIPPED WITH TWO STEP UNLOCKING

CONDITIONS	DETAILS/RESULTS/ACTIONS
C1 CHECK DOOR LOCK/UNLOCK OPERATION USING THE REMOTE TRANSMITTER	
	 NOTE: Verify that the doors are locked. Press the keyless entry remote transmitter UNLOCK button. The driver door should unlock. Press the keyless entry remote transmitter UNLOCK button again within 5 seconds. The rest of the doors should unlock. NOTE: Verify that all the doors are unlocked. Press the keyless entry remote transmitter LOCK button. All doors should lock. Do the power locks operate as described?
	 Press the keyless entry remote transmitter LOCK button. All doors should lock. Do the power locks operate as described?




















	2 Monitor the RAP PID DD_LOCK.
	Press the lock button on the keyless entry remote transmitter.
	 Does the RAP PID DD_LOCK change from OFF to LOCK to OFF?
	$\xrightarrow{\rightarrow}$ Yes GO to <u>C20</u> .
	$ \xrightarrow{\rightarrow} \mathbf{No} $ GO to <u>C21</u> .
C20 CHECK TRANSMITTER UNLOCK INPUT -	MONITOR THE RAP PID DD_LOCK
	 Monitor the RAP PID DD_LOCK Press the unlock button on the keyless entry
	 Does the RAP PID DD_LOCK change
	from OFF to UNLOCK to OFF?
	→ Yes REPLACE the RAP module; REFER to <u>Section</u> <u>419-10</u> . CLEAR the DTCs. TEST the system for normal operation.
	\rightarrow No GO to <u>C21</u> .
C21 CHECK TRANSMITTER OPERATION	
	1 NOTE: If the vehicle is within 0.8 km (1/2 mi) of radio or TV towers, the operating distance of the remote transmitter may be reduced.
	Press each button on the keyless entry remote transmitter while standing 3 m (10 ft) away from the vehicle and confirm that operation is as described in Description and Operation.
	 Is there an appropriate response for

	each button pressed?
	→ Yes System is OK.
	→ No GO to <u>C22</u> .
C22 CHECK FOR ANY RESPONSE FROM TRA	NSMITTER NO. 1
	1 Stand next to or sit inside the vehicle.
	Press each button on the keyless entry remote transmitter.
	 Does the system respond to any button pressed from transmitter No. 1?
	→ Yes GO to <u>C24</u> .
	\rightarrow No GO to C23.
C23 CHECK FOR ANY RESPONSE FROM TRANSMITTER NO. 2	
	1 Stand next to or sit inside the vehicle.
	Press each button on the keyless entry remote transmitter.
	 Does the system respond to any button pressed from transmitter No. 2?
	→ Yes GO to <u>C24</u> .
	\rightarrow No GO to C30.
C24 CHECK TRANSMITTER TIC/DATA	
NOTE: When TRANSMITTER TIC/DATA screen first appears, different eight digit letter/number codes should appear next to the TIC 1: and TIC 2: symbols. These are the stored transmitter identification codes (TICs) for the No. 1 and No. 2 transmitters.	
	1 Enter RAP, FUNCTION TESTS, TRANSMITTER TIC/DATA through the scan tool menus.
	 Is there at least one transmitter stored and displayed next to TIC 1?
	$\xrightarrow{\rightarrow}$ Yes GO to <u>C25</u> .
	ightarrow No

	PROGRAM all of the keyless entry remote transmitters. REFER to <u>Programming</u> . CLEAR the DTCs. TEST the system for normal operation.
C25 CHECK LAST TIC RECEIVED	
1 TIC/DATA	1 NOTE: It is normal for LAST TIC RECEIVED and LAST DATA RECEIVED to flash different information momentarily when the button is pressed. Information will lock in on the correct values. The tester is seeing the computer update its memory.
	NOTE: Pressing CLEAR will clear the last transmission received, but will not clear stored TICs in memory.
	Press and release the UNLOCK button of a keyless entry remote transmitter. The transmission received contains TICs for the keyless entry remote transmitter being operated and DATA for which the button has been pressed.
	 Does an eight digit letter/number code appear under LAST TIC RECEIVED: and the word UNLOCK appear under LAST DATA RECEIVED:?
	→ Yes GO to <u>C28</u> .
	\rightarrow No GO to <u>C26</u> .
C26 CHECK TRANSMITTER TIC/DATA—SECO	ND TRANSMITTER
	1 Repeat step C25 for the second keyless entry remote transmitter.
	 Does an eight digit letter/number code appear under LAST TIC RECEIVED: and the word UNLOCK appear under LAST DATA RECEIVED:?
	$\xrightarrow{\rightarrow}$ Yes GO to <u>C27</u> .
	\rightarrow No GO to <u>C29</u> .
C27 TEST KEYLESS ENTRY REMOTE TRANSM	AITTER BATTERIES
	 Switch batteries from the No. 2 to the No. 1 keyless entry remote transmitter.
	2 Repeat step C25 for the No. 1 keyless entry

	remote transmitter.
	 Does an eight digit letter/number code appear under LAST TIC RECEIVED: and the word UNLOCK appear under LAST DATA RECEIVED:?
	→ Yes RETURN original batteries to both keyless entry remote transmitters; REPLACE batteries in the No. 1 keyless entry remote transmitter. CLEAR the DTCs. TEST the system for normal operation.
	→ No REPLACE the No. 1 keyless entry remote transmitter. CLEAR the DTCs. TEST the system for normal operation.
C28 CHECK TIC/DATA FOR TIC MATCH	
TIC/DATA	
	Does the TIC under LAST TIC RECEIVED: match TIC 1 or TIC 2?
	→ Yes GO to <u>C29</u> .
	→ No PROGRAM all of the keyless entry remote transmitters to be used with this system (at least two). REFER to <u>Programming</u> . REPEAT C21.
C29 CHECK TIC/DATA FOR DATA MATCH	
TIC/DATA	
	 Do all buttons pressed for each transmitter create expected LAST DATA RECEIVED response?
	→ Yes REPLACE the RAP module; REFER to <u>Section</u> <u>419-10</u> . CLEAR the DTCs. TEST the system for normal operation.



C31 RESYNCHRONIZE KEYLESS ENTRY REM	OTE TRANSMITTER
	1 Press any button on the inoperative keyless entry remote transmitter four times consecutively.
	 Does the keyless entry remote transmitter operate properly?
	→ Yes CLEAR the DTCs. TEST the system for normal operation.
	→ No GO to <u>C32</u> .
C32 CHECK FOR SECOND KEYLESS ENTRY R	EMOTE TRANSMITTER
	 Check for another keyless entry remote transmitter that works with the vehicle.
	 Is there another keyless entry remote transmitter that works with the vehicle?
	→ Yes GO to <u>C33</u> .
	\rightarrow No GO to <u>C34</u> .
C33 RESYNCHRONIZE THE INOPERATIVE KEYLESS ENTRY REMOTE TRANSMITTER USING THE SECOND KEYLESS ENTRY REMOTE TRANSMITTER	
	1 Press any button on the operational keyless entry remote transmitter.
	2 Within 30 seconds press a button on the inoperative keyless entry remote transmitter.
	Check the inoperative keyless entry remote for proper operation.
	 Does the keyless entry remote transmitter in question operate properly?
	→ Yes CLEAR the DTCs. TEST the system for normal operation.
	\rightarrow No GO to <u>C34</u> .
C34 REPROGRAM THE INOPERATIVE KEYLES	S ENTRY REMOTE TRANSMITTER
	1 Reprogram all keyless entry remote transmitters; refer to <u>Programming</u> .

 Does the keyless entry remote transmitter operate properly?
→ Yes CLEAR the DTC. INFORM the customer that any additional keyless entry remote transmitters not present during the programming mode will not operate with the vehicle. All keyless entry remote transmitters must be programmed at the same time. TEST the system for normal operation.
\rightarrow No GO to <u>C17</u> .

PINPOINT TEST D: THE AUTO-LOCK DOES NOT OPERATE PROPERLY

CONDITIONS	DETAILS/RESULTS/ACTIONS
D1 ATTEMPT NORMAL AUTOLOCK/RELOCK C	PERATION
	1 NOTE: Understand the conditions required for autolock to function; refer to Description and Operation.
	Perform the autolock and relock sequences.
	 Do the autolock and relock features work?
	→ Yes Autolock/relock functions are OK. CLARIFY with owner and RETURN to Symptom Chart.
	$\rightarrow \text{No}$ GO to <u>D2</u> .
D2 CONFIRM AUTOLOCK IS ENABLED	
	1 Perform enable/disable sequence for autolock/relock feature. Refer to Description and Operation.
	 As this sequence is performed for the first time, does the horn chirp once followed by a longer honk?
	→ Yes GO to D1 (a feature became enabled which was previously disabled).
	$\stackrel{ ightarrow}{ ightarrow}$ No lf one horn chirp sounded, but no longer horn



















PINPOINT TEST E: THE MEMORY SEAT DOES NOT OPERATE PROPERLY USING THE REMOTE

TRANSMITTER

CONDITIONS	DETAILS/RESULTS/ACTIONS
E1 DETERMINE TRANSMITTER ONE AND TWO)
Scan Tool	
	 With the ignition off, press any button on the remote transmitter. NOTE: Transmitter with TIC1, TIC2, or TIC3 will cause the memory seat to move to corresponding locations 1, 2, or 3 as set by the memory seat control switches. A transmitter under TIC4 does not cause any seat movement.
	 Select TRANSMITTER TIC/DATA from the scan tool RAP FUNCTION TEST list. Compare the LAST TIC RECEIVED with the data stored in TIC1, TIC2, TIC3, TIC4, to determine transmitter 1 (TIC1), transmitter 2 (TIC2), transmitter 3 (TIC3), and transmitter 4 (TIC4). Repeat step 5 for the second remote transmitter.
	 Are remote transmitters one and two identified? → Yes GO to E2. → No
E2 CHECK REMOTE TRANSMITTER ONE FOR	If remote transmitters do not match any stored TICs, REPROGRAM all transmitters; REFER to <u>Programming</u> . MEMORY SEAT OPERATION
	1 Press the UNLOCK button on remote









PINPOINT TEST F: ALL DOOR LOCKS ARE INOPERATIVE — TWO STEP UNLOCK DOES NOT OPERATE PROPERLY (IF EQUIPPED)















	→ Yes REPLACE the GEM; REFER to Section 419- <u>10</u> . CLEAR the DTCs. TEST the system for normal operation.
	→ No REPLACE the door unlock relay. CLEAR the DTCs. TEST the system for normal operation.
F13 CHECK THE DOOR DISARM INPUT CIRCU	IT — MONITOR THE GEM PID DR_DSRM
	 Monitor the GEM PID DR_DSRM while unlocking the LF door, RF door and liftgate with the key.
	 Does the PID indicate L_Door when in the unlock position and OFF when in the unlock position for each door?
	→ Yes REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.
	→ No If the GEM PID DR_DSRM indicates L_Door only, GO to F14.
	If the GEM PID DR_DSRM indicates R_Door only, GO to F15.
	If the GEM PID DR_DSRM indicates LIFT_G only, GO to F16.
	If the GEM PID DR_DSRM indicates L_Door for all locks, GO to F <u>17</u> .
F14 CHECK THE DRIVER DOOR DISARM SWIT	CH CIRCUIT 25 (DG/P) AND CIRCUIT 57 (BK)
Driver Door Disarm Switch C510	
GEM C280	





	 Are the resistances less than 5 ohms? → Yes REPLACE the liftgate disarm switch. CLEAR the DTCs. TEST the system for normal operation. → No REPAIR circuit 25 (DG/P) or circuit 57 (BK). CLEAR the DTCs. TEST the system for normal operation.
F17 CHECK CIRCUIT 25 (DG/P) FOR SHORT TO GROUND — MONITOR THE GEM PID DR_DSRM	
	1 Monitor the GEM PID DR_DSRM while disconnecting each disarm switch.
	 Does PID indicate OFF when any of the disarm switches is disconnected?
	→ Yes REPLACE the disarm switch that changed PID value when disconnected. CLEAR the DTCs. TEST the system for normal operation.
	→ No REPAIR circuit 25 (DG/P). CLEAR the DTCs. TEST the system for normal operation.

PINPOINT TEST G: NO COMMUNICATION WITH THE MODULE — GENERIC ELECTRONIC MODULE/CENTRAL TIMER MODULE

CONDITIONS	DETAILS/RESULTS/ACTIONS
G1 CHECK BATTERY JUNCTION BOX MAXI-FU	JSE 1 (50A)
Maxi-Fuse 1 (60A)	
	• Is the fuse OK?
	→ Yes GO to <u>G2</u> .
	$\xrightarrow{\rightarrow}$ No REPLACE the fuse. CLEAR the DTCs. TEST





TEST the system for normal operation.

SECTION 501-14B: Keyless Entry/Computer Operated Locks GENERAL PROCEDURES 2000 Explorer/Mountaineer Workshop Manual

Programming

NOTE: All keyless entry remote transmitters (15K601) are programmable and must be set at the same time.

NOTE: To program (or reprogram) the keyless entry remote transmitters into the RAP module, perform the following steps:

- 1. Make sure that the anti-theft system is not armed or triggered.
- 2. Turn the ignition switch (11572) from OFF to RUN eight times within ten seconds, ending in RUN. If the RAP module has successfully entered program mode, it will lock and then unlock all doors.
- 3. Press any button on a keyless entry remote transmitter, and the doors will lock and then unlock to confirm that each keyless entry remote transmitter has been programmed.
- 4. If the door locks do not respond for any keyless entry remote transmitter, wait several seconds and press the button again. If the door locks still fail to respond, refer to Diagnosis and Testing.
- 5. Turn the ignition switch to the OFF position, or wait up to 20 seconds after step 2, to exit program mode. If a keyless entry remote transmitter has been programmed (or reprogrammed), the RAP module will lock and unlock all doors one last time to confirm.
SECTION 501-14B: Keyless Entry/Computer Operated Locks REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Keypad —Keyless Entry

Removal

- 1. Disconnect the battery ground cable.
- 2. CAUTION: Do not operate the radio chassis with a radio speaker disconnected.

Remove the front door trim panel. For additional information, refer to Section 501-05.

3. Remove the screws and lift the radio speaker out to gain access to the electrical connector.



4. Disconnect the speaker wiring connector.



- 5. Disconnect the electrical connector.
 - Release harness pin-type retainers.



- 6. Remove the keyless entry keypad and harness.
 - 1. Remove the clip.
 - 2. Remove the keyless entry keypad and harness.



Installation

1. **NOTE:** When the is disconnected and reconnected, some abnormal drive symptoms may occur while the vehicle relearns its adaptive strategy. The vehicle may need to be driven 10 miles (16 km) or more to relearn the strategy.

To install, reverse the removal procedure.

SECTION 501-14B: Keyless Entry/Computer Operated Locks REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Module — Remote Anti-Theft Personality (RAP)

Removal and Installation

For additional information, refer to <u>Section 419-10</u>.

SECTION 501-16: Wipers and Washers SPECIFICATIONS

Torque Specifications

Description	Nm	lb-ft	lb-in
Instrument Panel Finish Panel Screws	2-3	—	18-26
Ground Strap Nut	7-9	—	61-82
Windshield Wiper Washer Switch	2-3	—	18-26
Windshield Wiper Pivot Shaft Nut	10-13	—	89-115
Windshield Wiper Motor Bolts	7.0-9.0	—	61-82
Windshield Wiper/Washer Reservoir Screw and Nut	5-6	—	44-53
Pivot Arm — Rear Nut	13-17	—	113-154
Rear Wiper Motor Bolts	9-12	_	79-108

Wipers and Washers

Wiper and Washer Systems



6	17664	Windshield Washer Pump
7	17618	Windshield Washer Reservoir
8	17B649	Windshield Washer Reservoir Fluid Level Sensor (If Equipped)

Rear Wiper and Washer System



Rear Washer Hose Location and Routing

Item Part Numb	GK6606-A	cription
1 —	Rear Washer Ho	se

Wipers and Washers —Front

The wiper system has four different operating modes: off mode, low speed mode, high speed mode, and interval mode.

In the off mode, there is no windshield wiper motor activity, and the windshield wiper motor is in the PARK position.

In the low speed mode, the windshield wiper motor is set to a low speed setting. The windshield wiper hi/lo relay is deactivated, while the windshield wiper run/park relay is activated.

In the high speed mode, the windshield wiper motor is set to a high speed setting. The windshield wiper hi/lo relay and the windshield wiper run/park relay are both activated.

In the interval mode, the windshield wiper motor is set to a low speed setting with the windshield wiper hi/lo relay deactivated. The windshield wiper run/park relay is activated at the beginning of each wipe and deactivated when the windshield wiper motor park switch reaches the RUN position.

The permanent magnet three-brush windshield wiper motor allows selection of either low or high speed, when selected the steering column mounted multi-function switch (13K359). When the multi-function switch is in the LOW position, the common brush and low speed brush are used. When the multi-function switch is in the HIGH position, current bypasses part of the armature winding to the high speed brush. When the multi-function switch is moved to the off position, the windshield wiper motor will continue to run at low speed until the windshield wipers (17500) park.

When the multi-function switch is in the interval (INT) position, the windshield wipers will make a single sweep followed by a pause. The control knob on the end of the multi-function switch adjusts the pause from approximately 1-20 seconds.

Vehicles equipped with a generic electronic module (GEM) are available with the speed-dependant interval wiper feature. During the interval mode, the delay between successive wipes will decrease with higher vehicle speed to compensate for increased water on the windshield glass. This feature will relieve the operator from constantly switching between interval settings.

	Dwell Interval	
Delay/Wash Switch State	0-10 MPH	65 MPH and Above
1 (Long)	18	18
2	16	5
3	13	4
4	10	3
5	7	2
6	4	1
7 (Short)	1	0

Dwell Intervals for Each Switch State

If the washer switch is pressed between 100 ms and 300 ms, with the mode switch in the OFF position, the wiper system will provide one low speed wipe with no wash.

To engage the windshield washer, push the knob of the multi-function switch toward the steering column (3C529). When the multi-function switch is in the OFF or INT position, the windshield wipers will run as long as the knob is depressed up to 10 seconds. When the knob is released, the washer will stop immediately, but the windshield wipers will continue to run for two to three sweeps, then return to their previous set operation. Washer engagement does not affect windshield wiper operation when the multi-function switch is in the LOW or HIGH position, but the washer will be deactivated if the knob is held greater than 10 seconds.

Feature inputs:

- Ignition switch RUN position: (battery potential on both RUN and RUN/ACC inputs).
- Ignition switch ACC position: (battery potential on RUN/ACC input only).
- Wiper switch position: (different resistance for each mode; see Wiper Switch Resistance Values table).
- Interval Delay/Wash switch position: (different resistance for each mode; See Interval Delay/Wash Switch Resistance Values table).
- Windshield wiper motor park switch: (ground for PARK position and battery potential for RUN position).

Feature outputs:

- Windshield wiper hi/lo relay control: (ground to activate and open circuit to deactivate.)
- Windshield wiper run/park relay control: (ground to activate and open circuit to deactivate.)
- Washer pump relay control: (ground to activate and open circuit to deactivate.)

SECTION 501-16: Wipers and Washers DESCRIPTION AND OPERATION

Wipers and Washers —Rear

The generic electronic module (GEM) allows operation of the rear wiper functions when the ignition switch is in the RUN or ACC position only. When the liftgate or liftgate glass is ajar (ground potential is present at the liftgate and/or liftgate glass ajar switch), the rear wiper is moved to the PARK position (if not in this position) and deactivated. The GEM controls the cycling of the rear wiper motor through two external relays (rear wiper up relay and rear wiper down relay).

There are four modes of operation: off mode, interval mode, low mode and wash mode.

In the off mode, there is no liftgate wiper motor activity and the liftgate wiper motor will be in the PARK position.

In the interval mode, there are two interval wiper settings to provide the following rear wiper dwell times:

Setting	Dwell
Interval 1	12 seconds
Interval 2	6 seconds

When the rear wiper mode/wash switch is placed in one of the intervals in the table, the GEM will activate one rear wipe cycle of the rear wiper motor. Once the wiper cycle has reached the LO position, after the initial wipe, the GEM will start a cyclical timing function with the dwell times specified in the table.

In the low mode, the liftgate wiper motor will cycle the rear motor continuously at a low speed setting.

In the wash mode, when the rear wiper wash switch is pressed and held for a time greater than 100 ms, the GEM will cycle the rear wiper motor three times.

NOTE: The GEM does not control the rear washer, only the wiper.

In the mist mode, the washer switch is pressed between 100 ms and 300 ms with the mode switch in the OFF position, the wiper system will provide one low speed wipe with no wash.

SECTION 501-16: Wipers and Washers DESCRIPTION AND OPERATION

Wipers and Washers —Rear Washer Hose

Fluid for the rear washer is supplied by a two-way washer pump located in the windshield washer fluid reservoir in the engine compartment.

The rear washer hose contains a check valve, which is located in the hose that passes through the liftgate in the rear of the vehicle. This check valve holds the entire line full of washer fluid between washer operation. There is also a stand pipe located along the right hand D-pillar of the vehicle. This stand pipe prevents the unintentional release of washer fluid from the rear washer nozzle. If the hose is cut or disconnected after the line was initially primed with fluid, and the washer system is turned on, the stand pipe may fill with fluid. To resolve this, once the hose is repaired, temporarily disconnect the check valve to allow fluid in stand pipe to drain to lowest point in the hose; then reinstall the check valve.

2000 Explorer/Mountaineer Workshop Manual

Wipers and Washers

Refer to Wiring Diagrams Cell <u>59</u>, Generic Electronic Module for schematic and connector information.

Refer to Wiring Diagrams Cell 81, Interval Wiper/Washer for schematic and connector information.

Refer to Wiring Diagrams Cell 82, Liftgate Wiper/Washer for schematic and connector information.

Special Tool(s)

	73 Digital Multimeter or equivalent 105-R0051
ST1137-A	
ST2332-A	Worldwide Diagnostic System (WDS) 418-F224, New Generation STAR (NGS) Tester 418-F052, or equivalent scan tool
5T1453-A	Alternator, Regulator, Battery and Starter Tester (ARBST) or equivalent 010-00725

Inspection and Verification

1. **NOTE:** The CTM must be reconfigured upon replacement. Refer to the scan tool help screen on the configuration card to program the tire size and axle ratio.

The wiper washer system is a generic electronic module (GEM)/central timer module (CTM) controlled system.

- 2. Verify the customer concern by operating the system in question.
- 3. Visually inspect for the following obvious signs of mechanical and electrical damage.

Visual Inspection Chart

Mechanical	Electrical

 Switch(es) Wiper arms Wiper mechanism 	 BJB Fuses: 1 (60A) 8 (15A) CJB Fuses: 12 (7.5A) 16 (30A) 25 (7.5A) Damaged wiring harness Loose or corroded connections Lamps Circuitry
---	---

- 4. If the concern remains after the inspection, connect scan tool to the data link connector (DLC) located beneath the instrument panel and select the vehicle to be tested from the scan tool menu. If the scan tool does not communicate with the vehicle:
 - check that the program card is properly installed.
 - check the connections to the vehicle.
 - check the ignition switch position.
- 5. If the scan tool still does not communicate with the vehicle, refer to the scan tool manual.
- 6. Perform the DATA LINK DIAGNOSTIC TEST. If the scan tool responds with:
 - CKT914, CKT915 or CKT70 = ALL ECUS NO RESP/NOT EQUIP, refer to Section 418-00.
 - NO RESPONSE/NOT EQUIPPED for GEM/CTM, go to Pinpoint Test M.
 - SYSTEM PASSED, retrieve and record the continuous diagnostic trouble codes (DTCs), erase the continuous DTCs and perform front and rear wiper self-test diagnostics for the GEM/CTM.
- 7. If the DTCs retrieved are related to the concern, go to GEM/CTM Diagnostic Trouble Code (DTC) Reference Chart to continue diagnostics.
- 8. If no DTCs related to the concern are retrieved, proceed to Symptom Chart to continue diagnostics.

GEM/CTM Diagnostic Trouble Code (DTC) Index

GEM/CTM Diagnostic Trouble Code (DTC) Index

DTC	Description	DTC Caused By	Action
P0500	Vehicle Speed Signal Circuit Failure	GEM	GO to <u>Pinpoint Test F</u> .
B1302	Accessory Delay Relay Coil Circuit Failure	GEM	REFER to <u>Section 501-11</u> .
B1304	Accessory Delay Relay Coil Circuit Short to Battery	GEM	REFER to <u>Section 501-11</u> .
B1313	Battery Saver Relay Coil Circuit Failure	GEM/CTM	REFER to <u>Section 417-02</u> .
B1315	Battery Saver Relay Coil Circuit Short to Battery	GEM/CTM	REFER to <u>Section 417-02</u> .

B1317	Battery Voltage HIGH	GEM/CTM	REFER to Section 414-00.
B1318	Battery Voltage LOW	GEM/CTM	REFER to Section 414-00.
B1322	Door Ajar Driver Circuit Short to Ground	GEM/CTM	REFER to <u>Section 417-02</u> .
B1323	Door Ajar Lamp Circuit Failure	GEM/CTM	REFER to Section 413-01.
B1325	Door Ajar Lamp Circuit Short to Battery	GEM/CTM	REFER to Section 413-01.
B1330	Door Ajar RF Circuit Short to Ground	GEM/CTM	REFER to Section 417-02.
B1334	Decklid Ajar Rear Door Circuit Short to Ground	GEM/CTM	REFER to Section 417-02.
B1338	RR Door Ajar Circuit Short to Ground	GEM/CTM	REFER to Section 417-02.
B1340	Chime Input Request Circuit Short to Ground	GEM/CTM	REFER to <u>Section 413-09</u> .
B1342	GEM/CTM is Defective	GEM/CTM	CLEAR the DTCs. RETRIEVE the DTCs. If DTC B1342 is retrieved, REPLACE the GEM/CTM; REFER to Section 419- 10. TEST the system for normal operation.
B1345	Heated Backlite Input Circuit Short to Ground	GEM	REFER to <u>Section 501-11</u> .
B1347	Heated Backlite Relay Circuit Failure	GEM	REFER to <u>Section 501-11</u> .
B1349	Heated Backlite Relay Circuit Short to Battery	GEM	REFER to Section 501-11.
B1352	Ignition Key-In Circuit Failure	GEM/CTM	REFER to <u>Section 413-09</u> .
B1355	Ignition RUN Circuit Failure	GEM/CTM	REFER to Section 211-05, Symptom Chart.
B1359	Ignition RUN/ACC Circuit Failure	GEM/CTM	REFER to Section 211-05, Symptom Chart.
B1371	Illuminated Entry Relay Circuit Failure	GEM/CTM	REFER to Section 417-02.
B1373	Interior Lamp Relay Coil Circuit Short to Battery	GEM/CTM	REFER to <u>Section 417-02</u> .
B1398	Power Window Driver One-Touch Window Relay Circuit Failure	GEM	REFER to <u>Section 501-11</u> .
B1400	Power Window Driver One-Touch Window Relay Coil Circuit Short to Battery	GEM	REFER to <u>Section 501-11</u> .
B1404	Power Window Driver Down Circuit Open	GEM	REFER to Section 501-11.
B1405	Driver Power Window Down Circuit to Battery	GEM	REFER to <u>Section 501-11</u> .

B1410	Power Window Driver Motor Circuit Failure	GEM	REFER to Section 501-11.
B1426	Seat Belt Lamp Circuit Short to Battery	GEM/CTM	REFER to Section 413-01.
B1428	Seat Belt Lamp Circuit Failure	GEM/CTM	REFER to <u>Section 413-01</u> .
B1431	Wiper Brake/Run Relay — Circuit Failure	GEM/CTM	GO to Symptom Chart.
B1432	Wiper Brake/Run Relay Short to Battery	GEM/CTM	GO to <u>Pinpoint Test A</u> .
B1434	Wiper Hi/Lo Speed Relay — Circuit Failure	GEM/CTM	GO to Symptom Chart.
B1436	Wiper Hi/Lo Speed Relay Circuit Short to Battery	GEM/CTM	GO to <u>Pinpoint Test C</u> .
B1438	Wiper Mode Select Switch Circuit Failure	GEM/CTM	GO to Symptom Chart.
B1441	Wiper Mode Select Switch Input Short to Ground	GEM/CTM	GO to Symptom Chart.
B1446	Wiper Park Sense Circuit Failure	GEM/CTM	GO to <u>Pinpoint Test D</u> .
B1450	Wiper/Washer Interval Delay Switch Input Circuit Failure	GEM/CTM	GO to Symptom Chart.
B1453	Wiper/Washer Interval Delay Switch Input Short to Ground	GEM/CTM	GO to Symptom Chart.
B1458	Wiper/Washer Pump Motor Relay Circuit Failure	GEM/CTM	GO to <u>Pinpoint Test E</u> .
B1460	Wiper/Washer Pump Motor Relay Coil Short to Battery	GEM/CTM	GO to <u>Pinpoint Test E</u> .
B1462	Seat Belt Switch Circuit Failure	GEM/CTM	REFER to Section 413-09.
B1466	Wiper Hi/Lo Speed Not Switching	GEM/CTM	GO to Symptom Chart.
B1467	Wiper Hi/Lo Speed Circuit Motor Short to Battery	GEM/CTM	GO to Symptom Chart.
B1473	Wiper Low Speed Circuit Motor Failure	GEM/CTM	GO to Symptom Chart.
B1475	Accessory Delayed Relay Contacts Short to Battery	GEM/CTM	REFER to <u>Section 501-11</u> .
B1476	Wiper High Speed Circuit Motor Failure	GEM/CTM	GO to Symptom Chart.

B1483	Brake Pedal Input Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
B1485	Brake Pedal Input Short Circuit to Battery	GEM	REFER to Section 308-07A.
B1574	LR Door Ajar Circuit Short to Ground	GEM/CTM	REFER to <u>Section 417-02</u> .
B1577	Lamp Park Input Short Circuit to Battery	GEM/CTM	REFER to Section 413-09.
B1610	Illuminated Entry Input (From RAP Module) Circuit Short to Ground	GEM	REFER to <u>Section 417-02</u> .
B1611	Wiper Rear Mode Select Switch Circuit Failure	GEM	GO to Symptom Chart.
B1614	Wiper Rear Mode Select Switch Circuit Short to Ground	GEM	GO to Symptom Chart.
B1814	Wiper Rear Motor Down Relay Circuit Failure	GEM	GO to <u>Pinpoint Test K</u> .
B1816	Wiper Rear Motor Down Relay Coil Circuit Short to Battery	GEM	GO to <u>Pinpoint Test K</u> .
B1818	Wiper Rear Motor Up Relay Coil Circuit Failure	GEM	GO to Symptom Chart.
B1820	Rear Wiper Motor Up Relay Circuit Short to Battery	GEM	GO to <u>Pinpoint Test K</u> .
B1833	Door Unlock Switch Circuit Short to Ground	GEM	REFER to <u>Section 501-14B</u> .
B1834	Door Unlock Disarm Output Circuit Failure	GEM	REFER to <u>Section 501-14B</u> .
B1836	Door Unlock Disarm Output Circuit Short to Battery	GEM	REFER to <u>Section 501-14B</u> .
B1839	Wiper Rear Motor Circuit Failure	GEM	GO to <u>Pinpoint Test K</u> .
B1840	Wiper Front Power Circuit Failure	GEM/CTM	GO to Pinpoint Test A.
B1894	Wiper Rear Motor Speed Sense Circuit Failure	GEM	GO to <u>Pinpoint Test K</u> .
B2105	Throttle Position Input (TPI) Signal Out of Range Low	GEM	REFER to <u>Section 308-07A</u> .
B2106	Throttle Position Input (TPI) Signal Out of Range High	GEM	REFER to <u>Section 308-07A</u> .

B2141	NVM Configuration Failure	GEM/CTM	Vehicle speed calibration data is not programmed into the GEM/CTM. REFER to the scan tool help screen on the configuration card to program the tire size ratio. TEST the system for normal operation. If DTC B2141 is still present, REPLACE the GEM/CTM. REFER to <u>Section 419-10</u> . TEST the system for normal operation.
P1763	Transmission Neutral InTow Indicator Circuit Short to Battery	GEM	REFER to <u>Section 413-09</u> .
P1764	Transmission Neutral InTow Indicator Circuit Fault	GEM	REFER to <u>Section 413-09</u> .
P1804	4WD High Indicator Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1806	4WD High Indicator Short Circuit to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1808	4WD Low Indicator Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1810	4WD Low Indicator Short Circuit to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1812	4WD Mode Select Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1815	4WD Mode Select Short Circuit to Ground	GEM	REFER to <u>Section 308-07A</u> .
P1820	Transfer Case CW Shift Relay Coil Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1822	Transfer Case CW Shift Relay Coil Short to Power	GEM	REFER to <u>Section 308-07A</u> .
P1824	4WD Electric Clutch Relay Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1826	4WD LOW Clutch Relay Short to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1828	Transfer Case CW Shift Relay Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1830	Transfer Case CCW Shift Relay Coil Short to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1836	Transfer Case Front Shaft Speed Sensor Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1837	Transfer Case Rear Shaft Speed Sensor Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1838	Transfer Case Shift Motor Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1846	Transfer Case CONTACT PLATE "A"	GEM	REFER to <u>Section 308-07A</u> .

	Circuit Failure		
P1850	Transfer Case CONTACT PLATE "B" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1854	Transfer Case CONTACT PLATE "C" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1858	Transfer Case CONTACT PLATE "D" Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1866	Transfer Case System Concern	GEM	REFER to <u>Section 308-07A</u> .
P1867	Transfer Case Contact Plate General Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1874	Automatic Hall Effect Sensor Power Circuit Failure	GEM	REFER to <u>Section 308-07A</u> .
P1875	Automatic Hall Effect Sensor Power Circuit Short to Battery	GEM	REFER to <u>Section 308-07A</u> .
P1891	Transfer Case Contact Plate Ground Return Open Circuit	GEM	REFER to <u>Section 308-07A</u> .

GEM/CTM Parameter Identification (PID) Index

GEM/CTM Parameter Identification (PID) Index

PID	Description	Expected Values
VSS_GEM	Vehicle Speed Input	0 - 255 KPH
PARK_SW	External Access Ajar Switch Status	OFF, ON
D_DR_SW	Driver Door Ajar Switch Status	CLOSED, AJAR
DR_DSRM	Door Disarm Switch Status	L_Door, R_Door, LIFT_G, OFF
DR_UNLK	All Doors Unlock Output State	ON, OFF, ON-B-, OFFO-G
P_DR_SW	Passenger Door Ajar Switch Status	CLOSED, AJAR
IGN_KEY	Key-In-Ignition Status	IN, OUT
IGN_GEM	Ignition Switch Status	START, RUN, OFF, ACCY
BATSAV	Battery Saver Relay Circuit	ON, OFF, ON-B-, OFFO-G
VBATGEM	Battery Voltage	0.0 VDC - 14.3 VDC
LGATESW	Liftgate Ajar Switch Status	CLOSED - AJAR
LRDR_SW	Left Rear Door Ajar Switch Status	CLOSED - AJAR
RRDR_SW	Right Rear Door Ajar Switch Status	CLOSED - AJAR
INTLMP	Illuminated Entry Relay Circuit	ON, OFF, ON-B-, OFFO-G

CLTCHSW	Transmission Clutch Interlock Switch (GEM Only)	ENGAGED, NOT ENGAGED
NTRL_SW	Neutral Safety Switch Input (GEM Only)	NTRL, not NTRL
MTR_CCW	Transmission Transfer CCW Motor Output (GEM Only)	ON, OFF, OFFO-G, ON-B-
MTR_CW	CW Shift Relay Coil Status (GEM Only)	OFF, ON, OFFO-G, ON-B-
4WD_SW	4WD Switch Status (GEM Only)	AUTO, 4WDLOW, 4WDHIGH
4WDELCL	4WD Electric Clutch	ON, OFF, ON-B-, OFFO-G
TRANSGR	Transmission Gear Status	REV, notREV
4WDCLCH	4WD Electronic Clutch Output Status (GEM Only)	ON, OFF, OFFO-G, ON-B-
4WDLOW	4WD Low Indicator Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
4WDHIGH	4WD High Indicator Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
PLATE_A	Transfer Case Contact Plate Switch A (GEM Only)	OPEN, CLOSED
PLATE_B	Transfer Case Contact Plate Switch B (GEM Only)	OPEN, CLOSED
PLATE_C	Transfer Case Contact Plate Switch C (GEM Only)	OPEN, CLOSED
PLATE_D	Transfer Case Contact Plate Switch D (GEM Only)	OPEN, CLOSED
BOO_GEM	Brake Pedal Position (BPP) Switch Input (GEM Only)	ON, OFF
HALLPWR	Hall Effect Speed Sensor Power (GEM Only)	ON, OFF, ON-B-, OFFO-G
4WDCLST	4WD Clutch PWM Output Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
TRA_RSP	Rear Shaft Speed (GEM Only)	0-255 mph
TRA_FSP	Front Shaft Speed (GEM Only)	0-225 mph
PLATEPW	Contact Plate Ground Output (GEM Only)	ON, OFF, ON-B-, OFFO-G
PWR_RLY	ABS Active Input	ON, OFF
NTF	Neutral Tow Function (GEM Only)	ON, OFF
NTF_LMP	Neutral Tow Light (GEM Only)	ON, OFF
D_SBELT	Driver Seat Belt Status	OUT, IN
IPCHIME	External Chime Request	ON, OFF
SBLTMP	Seat Belt Indicator Status	OFF, ON, OFFO-G, ON-B-
DRAJR_L	Door Ajar Warning Lamp Circuit	OFF, ON
D_PWRLY	One Touch Down Relay Coil Circuit Status (GEM Only)	ON, OFF, ON-B-, OFFO-G
D_ PWAMP	Driver Power Window Regulator Electric Drive Current (GEM Only)	0.25 amp increments
D_PWPK	Driver Power Window Regulator Electric Drive Peak Current (GEM Only)	0.25 amp increments
ACCDLY	Accessory Delay Relay Coil Circuit (GEM Only)	ON, OFF, ON-B-, OFFO-G
RDEF_ SW	Rear Defrost Control Switch Status	ON, OFF
RDEFRLY	Rear Window Defrost Relay Coil Circuit	ON, OFF, ON-B-, OFFO-G
WASHRLY	Washer Relay Status	ON, OFF, ON-B-, OFFO-G
WPPK_PK	Wiper Park-to-Park Time	0 - 65 Seconds
		Y

WPMODE	Wiper Control Mode Status	WASH, OPEN, INVLD, OFF, INTVL 1- 7, LOW, HIGH
WPPRKSW	Wiper Motor Status	PARKED, notPRK
WPRUN	Wiper Mode Run Relay	ON, OFF, ON-B-, OFFO-G
WPHISP	Windshield Wiper HI/LO Relay Status	ON, OFF, ON-B-, OFFO-G
WASH_SW	Washer Pump Relay Switch Status	OFF, ON, ON-B-, OFFO-G
R_WP_UP	Rear Wiper Up Relay Status (GEM Only)	ON, OFF, OFFO-G, ON-B-
R_WP_DN	Rear Wiper Down Relay Status (GEM Only)	ON, OFF, OFFO-G, ON-B-
R_WP_SW	Rear Wiper Input Switch Status (GEM Only)	WPLOW, OFF, WPHIGH
R_WP_MD	Rear Wiper Mode Switch Status (GEM Only)	OFF, INTVL 1-2, LOW WASH
R_WP_PK	Rear Wiper Park Status (GEM Only)	PARKED, notPRK

GEM/CTM Active Command Index

GEM/CTM Active Command Index

Active Command	Display	Action
PID LATCH	PID LATCH	ON, OFF
FRONT WIPER	WIPER RLY	ON, OFF
FRONT WIPER	SPEED RLY	ON, OFF
FRONT WIPER	WASH RLY	ON, OFF
WARNING LAMPS AND CHIME	SBLT LAMP	ON, OFF
WARNING LAMPS AND CHIME	CHIME	ON, OFF
WARNING LAMPS AND CHIME	AJAR LAMP	ON, OFF
BATTERY SAVER	BATT SAVR	ON, OFF
INTERIOR COURTESY LAMPS	INT LAMPS	ON, OFF
ONE TOUCH DOWN AND ACCY DELAY (GEM Only)	ACCY RLY	ON, OFF
ONE TOUCH DOWN AND ACCY DELAY (GEM Only)	ONE TOUCH	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	CW/CCW	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	HIGH LAMP	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	LOW LAMP	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	PLATE PWR	ON, OFF
4-WHEEL ELECTRONIC SHIFT (GEM Only)	SHFT CLCH	ON, OFF
SHIFT CLUTCH CONTROL	CLUTCH SOL	ANALOG %
NEUTRAL IN TOW LAMP	NTFLAMP	ON, OFF
REAR WIPER (GEM Only)	UP RELAY	ON, OFF
REAR WIPER (GEM Only)	DWN RELAY	ON, OFF
HEATED BACKLIGHT	RLY CNTRL	ON, OFF
DOOR LOCK CONTROL	DD UNLOCK	ON, OFF

GEM/CTM Wiggle Test Diagnostic Trouble Code (DTC) Index

GEM/CTM Wiggle Test Diagnostic Trouble Code (DTC) Index

DTC	Description	DTC Caused By
B1317	Battery Voltage HIGH	GEM/CTM
B1318	Battery Voltage Low	GEM/CTM
B1322	Driver Door Ajar Circuit Short to Ground	GEM/CTM
B1330	Passenger Door Ajar Short to Ground	GEM/CTM
B1352	Ignition Key-In Circuit Failure	GEM/CTM
B1410	Driver Power Window Motor Circuit Failure	GEM
B1438	Wiper Mode Select Switch Circuit Failure	GEM/CTM
B1441	Wiper Mode Select Switch Short to Ground	GEM/CTM
B1446	Wiper Park Sense Circuit Failure	GEM/CTM
B1450	Wiper/Wash Interval Delay Switch Input Circuit Failure	GEM/CTM
B1453	Wiper/Wash Interval Delay Switch Input Short to Ground	GEM/CTM
B1462	Seat Belt Switch Circuit Failure	GEM/CTM
B1577	Park Lamp Input Circuit Short to Battery	GEM/CTM
B1610	Illuminated Entry Input (From RAP Module) Circuit Short to Ground	GEM/CTM

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action
The Wipers Are Inoperative	 CJB Fuse 16 (30A). Circuitry. GEM/CTM. Multi-function switch (13K359). Wiper run/park relay. Wiper HI/LO relay. Wiper motor. DTC B1431. DTC B1432. DTC B1438. DTC B1450. DTC B1840. 	• GO to <u>Pinpoint</u> <u>Test A</u> .
 The Wipers Stay On Continuously 	Circuitry.GEM/CTM.Multi-function	• GO to <u>Pinpoint</u> <u>Test B</u> .

	 switch. Wiper run/park relay. Wiper HI/LO relay. Wiper motor. DTC B1431. DTC B1441. DTC B1453. DTC B1473. DTC B1476. 	
 The High/Low Wiper Speeds Do Not Operate Properly 	 Circuitry. GEM/CTM. Multi-function switch. Wiper HI/LO relay. Wiper motor. DTC B1434. DTC B1436. DTC B1438. DTC B1441. DTC B1450. DTC B1466. DTC B1473. DTC B1476. 	• GO to <u>Pinpoint</u> <u>Test C</u> .
 The Intermittent Wiper Mode Does Not Operate Properly 	 Circuitry. GEM/CTM. Multi-function switch. Wiper motor. DTC B1438. DTC B1446. DTC B1450. DTC B1453. 	• GO to <u>Pinpoint</u> <u>Test D</u> .
The Windshield Washer Pump Is Inoperative	 Circuitry. GEM/CTM. Multi-function switch. Washer pump relay. Washer pump. DTC B1450. DTC B1453. DTC B1458. DTC B1460. 	• GO to <u>Pinpoint</u> <u>Test E</u> .
 The Speed Dependent Interval Mode Does Not Operate Properly 	 Circuitry. GEM. 4WABS control module. DTC P0500. 	 GO to <u>Pinpoint</u> <u>Test F</u>.
The Wipers Do Not Operate Properly — High Speed Wipers Only Operate	 Circuitry. Multi-function switch. Wiper HI/LO relay. 	GO to <u>Pinpoint</u> <u>Test G</u> .

	 Wiper motor. GEM/CTM. DTC B1473. DTC B1434. DTC B1436. DTC B1466. DTC B1467. 	
 The Wipers Stay On Continuously — Rear Wiper 	 Circuitry. GEM. Rear wiper/washer switch. DTC B1614. 	• GO to <u>Pinpoint</u> <u>Test H</u> .
 The Washer Pump Is Inoperative — Rear Washer Pump 	 Circuitry. GEM. Rear wiper/washer switch. Washer pump. 	• GO to <u>Pinpoint</u> <u>Test J</u> .
 The Wipers Are Inoperative — Rear Wiper 	 Circuitry. GEM. Rear wiper down relay. Rear wiper up relay. Rear wiper motor. Liftgate door ajar switch(es). Liftgate wiper disable switch. DTC B1334. DTC B1611. DTC B1814. DTC B1816. DTC B1820. DTC B1839. DTC B1894. 	• GO to <u>Pinpoint</u> <u>Test K</u> .
The Wipers Do Not Operate Properly — Rear Wiper	 Circuitry. GEM. Rear wiper/washer switch. DTC B1611. DTC B1614. 	• GO to <u>Pinpoint</u> <u>Test L</u> .
No Communication With the Module — GENERIC ELECTRONIC MODULE/CENTRAL TIMER MODULE	 BJB Fuse 1 (50A) CJB Fuse 25 (7.5A) Circuitry. GEM/CTM. 	• GO to <u>Pinpoint</u> <u>Test M</u> .

Pinpoint Tests

CAUTION: Before removing and installing the GEM/CTM or its connectors, disconnect the

battery. Failure to follow this caution will result in GEM/CTM storing many erroneous DTCs and it may exhibit erratic operation after installation.

CAUTION: Be careful when probing the battery junction box (BJB), central junction box (CJB) or any connectors. Damage will result to the connector receptacle if the probe or terminal being used is too large.

CAUTION: Electronic modules are sensitive to electrical charges. If exposed to these charges, damage may result.

NOTE: If continuous DTCs are recorded and the symptom is not present when performing the pinpoint tests, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.

NOTE: Complete the entire pinpoint test related to the symptom before replacing the GEM/CTM.

CONDITIONS DETAILS/RESULTS/ACTIONS A1 CHECK THE IGNITION STATES - MONITOR THE GEM/CTM PID IGN_GEM 1 2 Scan Tool 3 3 **NOTE:** If the vehicle is equipped with a manual transmission, depress the clutch while turning the ignition switch to start. Monitor the GEM/CTM PID IGN GEM while turning the ignition switch through the START, RUN, OFF and ACC positions. • Do the PID values agree with the ignition switch positions? → Yes GO to A2. \rightarrow No REFER to Section 417-02. A2 RETRIEVE THE DIAGNOSTIC TROUBLE CODES (DTCs) 1 1 Retrieve and document continuous DTCs.

PINPOINT TEST A: THE WIPERS ARE INOPERATIVE



A4 CHECK THE WIPER RUN RELAY COIL CIRC	→ No REPLACE the fuse. CLEAR the DTCs. TEST the system for normal operation. If the fuse fails again, CHECK for a short to ground. REPAIR as necessary.
1	
	2 Monitor the GEM/CTM PID WPRUN while
Ĩ	Does the GEM/CTM PID WPRUN value
	agree with the command mode?
	→ Yes If the GEM/CTM PID WPRUN displays ON and OFF, GO to <u>A11</u> .
	→ No If the GEM/CTM PID WPRUN displays OFFO- G, GO to <u>A7</u> .
	If the GEM/CTM PID WPRUN displays ON-B-, GO to <u>A5</u> .
A5 CHECK THE WIPER RUN RELAY	
1	
	Check the wiper run relay; refer to Wiring Diagrams cell 149.
	Is the wiper run relay OK?
	→ Yes GO to <u>A6</u> .
	→ No REPLACE the wiper run relay. CLEAR the DTCs. TEST the system for normal operation.
A6 CHECK CIRCUIT 646 (Y/W) FOR SHORT TO	POWER
1	
















REPAIR the wiper mechanism. CLEAR the
DTCs. TEST the system for normal operation.

PINPOINT TEST B: THE WIPERS STAY ON CONTINUOUSLY















REPLACE the wiper motor; REFER to <u>Motor</u> <u>Windshield Wiper</u>. CLEAR the DTCs. TEST the system for normal operation.

PINPOINT TEST C: THE HIGH/LOW WIPER SPEEDS DO NOT OPERATE PROPERLY

CONDITIONS	DETAILS/RESULTS/ACTIONS	
C1 CHECK THE IGNITION STATES — MONITOR THE GEM/CTM PID IGN_GEM		
Scan Tool	 NOTE: If the vehicle is equipped with a manual transmission, depress the clutch while turning the ignition switch to start. Monitor the GEM/CTM PID IGN_GEM while turning the ignition switch through the START, RUN, OFF and ACC positions. Do the PID values agree with the ignition switch positions? Yes GO to C2. → No 	
C2 RETRIEVE THE DIAGNOSTIC TROUBLE CODES (DTCS)		
	1 Retrieve and document continuous DTCs.	
3		





















PINPOINT TEST D: THE INTERMITTENT WIPER SPEED DOES NOT OPERATE PROPERLY

CONDITIONS	DETAILS/RESULTS/ACTIONS	
D1 CHECK THE IGNITION STATES — MONITOR THE GEM/CTM PID IGN_GEM		



















PINPOINT TEST E: THE WASHER PUMP IS INOPERATIVE









	TEST the system for normal operation.
E8 CHECK CIRCUIT 680 (LB/O) FOR OPEN	
1	 Measure the resistance between multi- function switch C210-590, circuit 680 (LB/O), and GEM/CTM C280-13, circuit 680 (LB/O).
	Is the resistance less than 5 ohms?
	→ Yes REPLACE the GEM/CTM; REFER to Section 419-10. CLEAR the DTCs. TEST the system for normal operation.
	$\xrightarrow{\rightarrow}$ No REPAIR circuit 680 (LB/O). CLEAR the DTCs. TEST the system for normal operation.
E9 CHECK THE FRONT WASHER PUMP RELAY PID WASHRLY	COIL CIRCUIT — MONITOR THE GEM/CTM
	1 Monitor the GEM/CTM PID WASHRLY while triggering the active command WASH RLY ON and OFF.
	• Does the GEM/CTM PID WASHRLY agree with the active command WASH RLY?
	→ Yes If the GEM/CTM PID WASHRLY displays ON - and OFF, GO to E17.
	→ No If the GEM/CTM PID WASHRLY displays OFFO-G, GO to E10.
	If the GEM/CTM PID WASHRLY displays ON- B-, GO to $E15$.
E10 CHECK CJB FUSE 12 (7.5A)	














PINPOINT TEST F: THE SPEED DEPENDENT INTERVAL MODE DOES NOT OPERATE PROPERLY







PINPOINT TEST G: THE WIPERS DO NOT OPERATE PROPERLY — HIGH SPEED WIPERS ONLY OPERATE

CONDITIONS	DETAILS/RESULTS/ACTIONS	
G1 CHECK THE IGNITION STATES — MONITOR THE GEM/CTM PID IGN_GEM		
1		













	→ Yes REPAIR circuit 647 (GY/LB). CLEAR the DTCs. TEST the system for normal operation.
	$\rightarrow \text{No}$ GO to <u>G13</u> .
G13 CHECK THE WIPER HI/LO RELAY	
	Check the wiper HI/LO relay; refer to Wiring Diagrams cell 149.
	Is the wiper HI/LO relay OK?
	→ Yes REPLACE the GEM/CTM; REFER to <u>Section</u> <u>419-10</u> . CLEAR the DTCs. TEST the system for normal operation.
	→ No REPLACE the wiper HI/LO relay. CLEAR the DTCs. TEST the system for normal operation.
G14 CHECK CIRCUIT 63 (R) FOR VOLTAGE	
Wiper HI/LO Relay	
4	4 Measure the voltage between wiper HI/LO relay connector pin 2, circuit 63 (R), and ground.







CHECK the wiper motor; REFER to Component Test. REPLACE the wiper motor if it does not pass the test; REFER to <u>Motor—</u> <u>Windshield Wiper</u> . CLEAR the DTC. TEST the system for normal operation.
→ No REPAIR circuit 58 (W). CLEAR the DTCs. TEST the system for normal operation.

PINPOINT TEST H: THE WIPERS STAY ON CONTINUOUSLY — REAR WIPER

CONDITIONS	DETAILS/RESULTS/ACTIONS
H1 CHECK THE IGNITION STATES — MONITOR THE GEM/CTM PID_GEM	
Scan Tool	 NOTE: If the vehicle is equipped with a manual transmission, depress the clutch while turning the ignition switch to start. Monitor the GEM/CTM PID IGN_GEM while turning the ignition switch through the START, RUN, OFF and ACC positions. Do the PID values agree with the ignition switch positions? Yes GO to H2. → No REFER to Section 417-02.
H2 RETRIEVE THE DIAGNOSTIC TROUBLE CO	DES (DTCS)
1	I Retrieve and document continuous DTCs.





PINPOINT TEST J: THE WASHER PUMP IS INOPERATIVE — REAR WASHER PUMP

CONDITIONS	DETAILS/RESULTS/ACTIONS
J1 CHECK THE FRONT WASHER OPERATION	
I	 Verify the front washer operates properly by pressing the front washer switch. Does the front washer operate properly?











PINPOINT TEST K: THE WIPERS ARE INOPERATIVE — REAR WIPER







	REPLACE the liftgate wiper disable switch. CLEAR the DTCs. TEST the system for normal operation.
K5 CHECK THE RH LIFTGATE AJAR SWITCH -	– MONITOR THE GEM PID LGATESW
RH Liftgate Ajar Switch C439	
4	I Close the liftgate and liftgate glass.
<u>ک</u>	5 Monitor the GEM PID LGATESW.
	 Does the GEM PID LGATESW indicate AJAR?
	→ Yes GO to <u>K6</u> .
	→ No REPLACE the RH liftgate ajar switch. CLEAR the DTCs. TEST the system for normal operation.
K6 CHECK THE LH LIFTGATE AJAR SWITCH -	- MONITOR THE GEM PID LGATESW
1	
LH Liftgate Ajar Switch C438	I Close the liftgate and liftgate glass.
































CONDITIONS		DETAILS/RESULTS/ACTIONS		
L1 RETRIEVE THE DIAGNOSTIC TROUBLE CODES (DTCs)				
3	Scan Tool	I Retrieve and document continuous DTCs.		
4 ••••••••••••••••••••••••••••••••••••				
	Clear Continuous DTCs			
GE	M Wiper/Washer Self Test			
		• Are any DTCs recorded?		
		→ Yes If DTC B1611, GO to <u>L2</u> .		
		If DTC B1614, GO to L2.		
		If DTC B1839, GO to <u>L6</u> .		
		If DTC B1894, GO to <u>L6</u> .		
		If DTC B1342, REPLACE the GEM; REFER to <u>Section 419-10</u> . CLEAR the DTCs. TEST the system for normal operation.		

PINPOINT TEST L: THE REAR WIPERS DO NOT OPERATE PROPERLY - REAR WIPER





	→ No REPAIR circuit 359 (GY/R). CLEAR the DTCs. TEST the system for normal operation.	
	MONITOR THE GEM PID R_WP_PK	
	 Move the rear wiper arm to the center of the glass by triggering the GEM active commands REAR WIPER UP RELAY and REAR WIPER DOWN RELAY ON and OFF. Does the GEM PID R_WP_PK indicate PARKED when the rear wiper is parked and notPRK when the rear wiper is in the center of the glass? 	
	→ Yes GO to <u>L12</u> . → No GO to <u>L7</u> .	
L7 CHECK CIRCUIT 587 (P/Y) FOR OPEN		
Rear Wiper Motor C417		
GEM C281	 Measure the resistance between GEM C281- 4, circuit 587 (P/Y), and rear wiper motor C417-3, circuit 587 (P/Y). 	





GK6120-A				
	 Is the resistance greater than 10,000 ohms? 			
	→ Yes REPLACE the GEM; REFER to <u>Section 419-</u> <u>10</u> . CLEAR the DTCs. TEST the system for normal operation.			
	→ No REPLACE the rear wiper motor; REFER to <u>Motor—Rear Wiper</u> . CLEAR the DTCs. TEST the system for normal operation.			
L12 CHECK THE WIPER MECHANISM				
	1 Remove the linkage from the wiper motor.			
	Are the wipers free?			
	→ Yes CHECK the wiper motor by performing the Wiper Motor Current Draw Test; REFER to Component Testing. If the wiper motor does not pass the test, REPLACE the rear wiper motor; REFER to <u>Motor—Rear Wiper</u> . CLEAR the DTCs. TEST the system for normal operation.			
	→ No REPAIR the wiper mechanism. CLEAR the DTCs. TEST the system for normal operation.			

PINPOINT TEST M: NO COMMUNICATION WITH THE MODULE — GENERIC ELECTRONIC MODULE/CENTRAL TIMER MODULE

CONDITIONS	DETAILS/RESULTS/ACTIONS
M1 CHECK BJB FUSE 1 (60A)	
1	







Component Test

Relay — Micro ISO

Use the multimeter to check for the continuity between terminal 2 and all other terminals. If the resistance is 5 ohms or less between terminal 2 and any other terminal, replace the relay. If resistance is greater than 5 ohms, continue with the test. Use two jumper wires to connect relay terminals 1 and 3 directly to the positive battery terminal. Use the multimeter set in the volts position to check for voltage at terminal 4. If battery voltage is not indicated, replace the relay. If battery voltage is indicated, connect a third jumper wire to terminal 2 and ground the jumper wire to a known good ground. Check for voltage at terminal 5. If battery voltage is not indicated, replace the relay.



Windshield Wiper Motor

CAUTION: Do not handle the wiper motor abusively when diagnosing the wiper operations. Failure to follow this caution may result in damage to the motor magnets and will make the wiper motor inoperative. Rough handling of new replacement wiper motors may also damage the motor

magnets.

Use Alternator, Regulator, Battery and Starter Tester (ARBST) to test the wiper motor on the vehicle.



To test the wiper motor, disconnect the windshield wiper mounting arm and pivot shaft from the windshield wiper motor; refer to <u>Pivot Arm—Front</u> or refer to <u>Pivot Arm—Rear</u>.

Disconnect the wiper motor. Connect the (1) green lead from (2) Alternator, Regulator, Battery and Starter Tester (ARBST) to the battery negative (-) post. Connect the (3) red lead from ARBST to the wiper motor (4) common brush terminal (terminal 3).

Test the low speed mode by connecting a (5) cable from the battery positive (+) post to the (6) low speed brush terminal (terminal 4) and measure the current draw. If the current draw is greater than 3.5 amperes, replace the windshield wiper motor.

Test the high speed mode by connecting a cable from the battery positive (+) post to the (7) high speed brush terminal (terminal 5) and measure the current draw. If the current draw is greater than 5.5 amperes, replace the wiper motor.

Windshield Wiper Blade and Pivot Arm Adjustment

- 1. Cycle and park the windshield wipers.
- 2. Verify the distance between the center of the (1) RH windshield wiper blade and the (3) bottom of the windshield glass is within specification.



3. Verify the distance between the center of the (2) LH windshield wiper blade and the (3) bottom of the windshield glass is within specification.



4. If the distance is not within specification, remove the windshield wiper pivot arm and reposition to specification. For additional information, refer to <u>Pivot Arm—Front</u>.

Pivot Arm — Front

Removal

1. NOTE: The windshield wiper pivot arms are replaced as an assembly.

Remove the pivot arm.

- 1. Pull up on the pivot arm.
- 2. Pull out on the retainer tab and remove the pivot arm.



Installation

1. **NOTE:** The wiper motor must be cycled to make sure that it is in the park position. If necessary, adjust the wiper pivot arms. For additional information, refer to Windshield Wiper Blade and Pivot Arm Adjustment in this section.

To install, reverse the removal procedure.

Pivot Arm —Rear

Removal

CAUTION: Use a shop towel or similar device to protect the vehicle finish when performing the procedure.

1. Disconnect the rear washer hose.



- 2. Remove rear pivot arm.
 - 1. Lift the pivot arm nut cover.
 - 2. Remove the nut.
 - 3. Remove the pivot arm.



Installation

1. Turn the rear wiper switch on and allow the motor to operate for at least one cycle.



2. **NOTE:** This step ensures that the wiper motor is in the park position.

Turn the rear wiper switch OFF.



3. Position the wiper blade outside the wiper arm stop.



- 4. Install the wiper pivot arm onto the wiper motor.
 - Tighten retaining nut.



5. Connect the washer hose.



6. Cycle the wiper motor one time to allow the wiper arm to park on the wiper arm stop.



Mounting Arm and Pivot Shaft

Removal

1. Cycle the windshield wiper blades (17528) to the verticle position.



- 2. Remove the cowl top vent panels; refer to Section 501-02.
- 3. Unsnap the wiper motor clip from the RH mounting arm and pivot shaft.



4. Disconnect the RH windshield wiper mounting arm and pivot shaft (17566) from the LH windshield wiper mounting arm and pivot shaft (17567) and move both away from the windshield wiper motor (17504).



5. Remove the RH and LH mounting arm and pivot shafts.

- 1. Remove the two nuts.
- 2. Remove the mounting arm and pivot shafts.



Installation

- 1. Install the RH and LH mounting arms and pivot shafts.
 - 1. Position the mounting arm and pivot shafts into place.
 - 2. Install the two nuts.



2. CAUTION: To avoid possible damage to the windshield wiper adapter and connecting arm clip (17531), be sure the clip is fully seated before installing the adapter and connecting arm clip on the windshield wiper motor crank pin.



Install the clip onto the RH mounting arm and pivot shaft.

3. Install the LH windshield wiper mounting arm and pivot shaft onto the windshield wiper motor crank pin, and install the RH windshield wiper mounting arm and pivot shaft onto the wiper motor crank pin.



4. Install the cowl top vent panels; refer to <u>Section 501-02</u>.

SECTION 501-16: Wipers and Washers REMOVAL AND INSTALLATION 2000 Explorer/Mountaineer Workshop Manual

Motor —Windshield Wiper

Removal

CAUTION: The internal permanent magnets used in the windshield wiper motor (17504) are made of a glass-like material. To avoid damaging the magnets, do not strike the motor with a hammer or any other object.

NOTE: The windshield wiper motor is not a repairable item. If worn or damaged, the motor must be replaced.

- 1. Remove the LH pivot arm.
 - 1. Pull up on the pivot arm.
 - 2. Pull out on the retainer tab and remove the pivot arm.



2. Remove the LH cowl top vent panel screw.



3. Disconnect the washer hose from the LH washer jet nozzle.



- 4. Remove the LH cowl top vent panel.
 - Release the seven spring retainers.



5. Unsnap the wiper motor clip from the RH mounting arm and pivot shaft.



6. Disconnect the RH windshield wiper mounting arm and pivot shaft (17566) from the LH windshield wiper mounting arm and pivot shaft (17567) and move both away from the windshield wiper motor.



7. Disconnect the electrical connector.



8. Remove the ground strap nut and position the strap aside.



- 9. Remove the windshield wiper motor.
 - Remove the stud bolts.
 - Remove the bolts.



Installation

1. CAUTION: To avoid possible damage to the mounting arm and pivot shaft retainer clip, be sure the clip is fully seated before installing on the motor crank pin.

NOTE: Install the LH mounting arm and pivot shaft to the motor before installing the RH mounting arm and pivot shaft.

NOTE: Install the retainer clip on the RH mounting arm and pivot shaft prior to installing the motor.

To install, reverse the removal procedure.







SECTION 501-16: Wipers and Washers REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Module — Generic Electronic Module (GEM)

For additional information, refer to <u>Section 419-10</u>.

Switch —Rear Wiper/Washer

Removal

- 1. Remove the instrument panel finish panel.
 - 1. Remove the two screws.
 - 2. Remove the center instrument panel finish panel.
 - Disconnect the electrical connectors.



- 2. Remove the rear wiper/washer switch.
 - 1. Remove the screws.
 - 2. Remove the mounting bezel.
 - 3. Release the two tabs and remove the rear wiper/washer switch.



Installation

1. To install, reverse the removal procedure.


Motor —Rear Wiper

Removal

- 1. Remove the rear pivot arm; refer to Pivot Arm-Rear.
- 2. Remove the liftgate door trim panel; refer to <u>Section 501-05</u>.
- 3. Position the watershield aside to gain access to the rear wiper motor.
- 4. Remove rear wiper motor.
 - Disconnect electrical connector.
 - Remove three retaining bolts.
 - Remove rear wiper motor.



Installation

1. To install, reverse the removal procedure.



Washer Pump and Reservoir — Front

Removal

1. **NOTE:** To prevent spilling windshield washer fluid, drain the windshield washer reservoir (17618) before removal.

Disconnect the windshield washer hose from the windshield washer pump.

- 2. Disconnect the coolant overflow hose from the engine coolant overflow reservoir and plug the outlet of the reservoir.
- 3. Disconnect the windshield washer reservoir pump electrical connector and low level washer fluid electronic sensor connector, if equipped.



- 4. Remove the engine air cleaner; refer to <u>Section 303-12</u>.
- 5. Remove the two screws and two nuts and remove the windshield washer reservoir.



6. NOTE: Make sure not to tear the rubber grommet during disassembly.

Remove the windshield washer pump.



Installation

1. **NOTE:** The windshield washer reservoir, windshield washer pump (17664) and the windshield washer reservoir fluid level sensor (17B649) are replaced separately.

To install, reverse the removal procedure.



Washer Pump and Reservoir —Washer Hose Repair

- 1. Locate and verify the leaking washer hose.
- 2. Cut the hose cleanly and remove the damaged portion of the washer hose.



- 3. Install a windshield washer hose adapter (17A612) between the cut ends of the hose.
- 4. **NOTE:** In difficult cases, clamping may be required.

Install a segment of 6.4 mm (0.25 in) i.d. black rubber hose N809610-S or equivalent over th e ends of the washer hose, and clamp both ends of the rubber hose using spring clamps 389252-S101 or equivalent.

SECTION 501-17: Roof Opening Panel SPECIFICATIONS

General Specifications

Item	Specification
Roof Opening Panel	
Rear edge of roof panel to roof opening panel	0 - 1.5 mm (0.059)
Front edge of roof panel to roof opening panel	0 - 1.5 mm (0.059)

Torque Specifications

Description	Nm	lb-in
Roof opening panel assembly screws	10	89
Roof opening panel lifter arm bolts	4	35
Roof opening panel motor bolts	5	50

Roof Opening Panel

The roof opening panel consists of the following:

- air deflector
- overhead console
- roof opening panel motor
- roof opening panel module located above the headliner
- roof opening panel
- roof opening panel shield
- roof opening panel switch
- roof opening panel drain hose

The roof opening panel is an electronically operated panel that can be opened or closed by depressing a switch located inside the vehicle on the overhead console. It also has a one-touch open feature.

When the roof opening panel switch is rocked rearward, the roof opening panel moves back into the storage space between the headliner and the roof panel (50202).

The roof opening panel can be moved to the fully closed position by rocking the switch forward and holding it until the roof opening panel is fully closed.

When the roof opening panel is in the fully closed position, the rear portion can be raised to the vent position to provide ventilation by rocking the switch forward. The roof opening panel can be closed by rocking the switch rearward.

Roof Opening Panel

Special Tool(s)

	73III Automotive Meter 105-R0057 or equivalent
ST1137-A	

Inspection and Verification

- 1. Verify the customer concern by operating the roof opening panel.
- 2. Visually inspect for obvious signs of mechanical and electrical damage.

Visual Inspection Chart

Mechanical	Electrical
 Roof opening panel Opening shield Roof panel frame Opening shield guide feet 	 Central junction box Fuse 26 (10A) Battery junction box Fuse 4 (30A) maxi-fuse Relays Roof opening panel switch Wiring harness Roof opening panel motor

3. If the concern is not visually evident, determine the symptom and proceed to the Symptom Chart.

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action
 The roof opening panel has excessive wind noise 	 Incorrect adjustment. Roof opening panel seals. 	 GO to <u>Pinpoint</u> <u>Test A</u>.
 The roof opening panel leaks 	 Improper adjustment. Roof opening panel frame drain hose. Roof opening panel seals. Roof opening panel frame. 	 GO to <u>Pinpoint</u> <u>Test B</u>.
The roof opening panel rattles	 Roof opening panel. 	GO to <u>Pinpoint</u>

	 Roof opening panel rail or guide. Rear lifter assemblies. Front guides. Roof opening panel headlining. 	<u>Test C</u> .
 The roof opening panel is noisy during operation 	 Sliding roof outer glass panel. Roof opening panel rail and guide or troughs. Rear guide pin. Rear lifter assemblies. Roof opening panel motor. 	 GO to <u>Pinpoint</u> <u>Test D</u>.
 The roof opening panel does not open or close 	 Central junction box Fuse 26 (10A). Battery junction box Fuse 4 (30A). Circuitry. Switch. Roof opening panel motor. 	• GO to <u>Pinpoint</u> <u>Test E</u> .
 The roof opening panel does not seat in flush position from any position 	 Incorrect adjustment. 	 REFER to General Procedures.

Pinpoint Tests

PINPOINT TEST A: THE ROOF OPENING PANEL HAS EXCESSIVE WIND NOISE



 Open and close the roof opening panel. Check the adjustment when the roof opening panel closes.
 Is the adjustment OK?
→ Yes Check for correct installation of the roof opening panel motor. Refer to Motor—Roof Opening Panel. TEST the system for normal operation.
→ No ADJUST the roof opening panel. REFER to <u>Roof Opening Panel Alignment</u> or <u>Roof</u> <u>Opening Panel Horizontal Adjustment</u> . TEST the system for normal operation.

PINPOINT TEST B: THE ROOF OPENING PANEL LEAKS

CONDITIONS	DETAILS/RESULTS/ACTIONS
B1 CHECK T	HE ADJUSTMENT OF THE ROOF OPENING PANEL
	1 NOTE: Make sure the roof opening panel seals are not cracked or loose.
	Check the roof opening panel seals.
	 Does the roof opening panel seal correctly?
	→ Yes GO to <u>B2</u> .
	→ No ADJUST the roof opening panel. REFER to <u>Roof Opening Panel Alignment</u> or <u>Roof</u> <u>Opening Panel Horizontal Adjustment</u> . TEST the system for normal operation.
B2 CHECK T	HE DRAIN HOSES
	1 NOTE: Make sure the drain hoses are not cracked, slit, pinched, or obstructed.
	Check the four drain hoses for correct operation.
	Are the drain hoses OK?
	\rightarrow Yes GO to <u>B3</u> .
	→ No REPAIR or INSTALL a new drain hose(s). Refer to <u>Roof Opening Panel Drain</u> <u>Hose</u> . TEST the system for normal operation.
B3 CHECK THE DRAIN HOSE ATTACHMENT POINTS	
	1 NOTE: Make sure the drain hose attachment points are not damaged or obstructed.
	Check the drainage points for proper attachment.

	 Are the attachment points OK? → Yes
	 GO to <u>B4</u>. → No REPAIR the roof opening panel as necessary. TEST the system for normal operation.
B4 CHECK T	HE WATER TROUGH CONDITION
	1 Check the water trough for damage.
	 Is the water trough OK?
	\rightarrow Yes GO to <u>B5</u> .
	$\xrightarrow{\rightarrow}$ No REPAIR the water trough. TEST the system for normal operation.
B5 CHECK T	HE CONDITION OF THE ROOF OPENING PANEL
	1 Check the roof opening panel frame for damage that may cause the roof opening panel seal to seat incorrectly.
	Is the roof opening panel frame OK?
	→ Yes INSTALL a new roof opening panel; REFER to <u>Roof Opening Panel</u> . TEST the system for normal operation.
	→ No REPAIR roof opening panel frame as necessary. TEST the system for normal operation.

PINPOINT TEST C: THE ROOF OPENING PANEL RATTLES

C1 CHECK THE ROOF OPENING PANEL OPERATION ① Check the roof opening panel during operation. • Is the roof opening panel loose? → Yes ADJUST the roof opening panel. REFER to Roof Opening Panel Alignment or Roof Opening Panel Horizontal Adjustment. TEST the system for normal operation. → No	CONDITIONS	DETAILS/RESULTS/ACTIONS
 1 Check the roof opening panel during operation. Is the roof opening panel loose? → Yes ADJUST the roof opening panel. REFER to <u>Roof Opening Panel Alignment</u> or <u>Roof Opening Panel Horizontal Adjustment</u>. TEST the system for normal operation. → No 	C1 CHECK T	HE ROOF OPENING PANEL OPERATION
 Is the roof opening panel loose? → Yes ADJUST the roof opening panel. REFER to Roof Opening Panel Alignment or Roof Opening Panel Horizontal Adjustment. TEST the system for normal operation. → No 		① Check the roof opening panel during operation.
 → Yes ADJUST the roof opening panel. REFER to <u>Roof Opening Panel Alignment</u> or <u>Roof Opening Panel Horizontal Adjustment</u>. TEST the system for normal operation. → No 		Is the roof opening panel loose?
\rightarrow No		→ Yes ADJUST the roof opening panel. REFER to <u>Roof Opening Panel Alignment</u> or <u>Roof</u> <u>Opening Panel Horizontal Adjustment</u> . TEST the system for normal operation.
GO to <u>C2</u> .		\rightarrow No GO to <u>C2</u> .

C2 CHECK THE ROOF OPENING PANEL TRACKS $\begin{bmatrix} 1 \end{bmatrix}$ Open the roof opening panel. 2 Check the tracks for obstructions and damage. • Are the tracks OK? [→] Yes GO to C3. → No REMOVE all the track obstructions and REPAIR the roof opening panel tracks. TEST the system for normal operation. C3 CHECK THE WATER TROUGH AND TROUGH GUIDES 1 Check the water trough and trough guides for any loose fasteners or obstructions. • Are the trough and trough guides installed securely and free from foreign material? [→] Yes GO to C4. → No REMOVE all foreign material from the trough and install securely. SECURE the trough guides or REPAIR as necessary. TEST the system for normal operation. **C4** CHECK THE OPENING SHIELD 1 Check the opening shield for correct installation. • Is the opening shield installed correctly? \rightarrow Yes GO to C5. → No INSTALL the opening shield correctly. Refer to Roof Opening Panel Shield . TEST the system for normal operation. **C5** CHECK THE AIR DEFLECTOR ASSEMBLY L Check the air deflector for obstructions and damage. Is the air deflector OK? \rightarrow Yes GO to C6. \rightarrow No REMOVE all obstructions and REPAIR or INSTALL a new the air deflector assembly. REFER to <u>Air Deflector</u>. TEST the system for normal operation. **C6** CHECK ROOF OPENING PANEL

 Verify the roof opening panel is free from obstruction, damage, and is securely fastened.
Is the roof opening panel OK?
→ Yes INSTALL a new roof opening panel frame. REFER to <u>Roof Opening Panel Frame</u> .
→ No REPAIR the roof opening panel as necessary. REFER to <u>Roof Opening Panel</u> . TEST the system for normal operation.

PINPOINT TEST D: THE ROOF OPENING PANEL IS NOISY DURING OPERATION

CONDITIONS	DETAILS/RESULTS/ACTIONS	
D1 CHECK T	HE ROOF OPENING PANEL FOR OBSTRUCTIONS OR DAMAGE	
	1 Check the roof opening panel for any obstructions and damage.	
	 Are there any obstructions and damage? 	
	$\xrightarrow{\rightarrow}$ Yes REMOVE all obstructions. REPAIR the roof opening panel as necessary. TEST the system for normal operation.	
	\rightarrow No GO to <u>D2</u> .	
D2 CHECK T	HE ROOF OPENING PANEL OPERATION	
	1 Check the roof opening panel during operation.	
	 Is the roof opening panel loose or not correctly adjusted? 	
	→ Yes ADJUST the roof opening panel. REFER to <u>Roof Opening Panel Alignment</u> or <u>Roof</u> <u>Opening Panel Horizontal Adjustment</u> . It may be necessary to adjust the roof opening panel forward. TEST the system for normal operation.	
	\rightarrow No GO to D3.	
D3 CHECK T	HE ROOF OPENING PANEL TRACKS	
	1 Open the roof.	
	2 Check the tracks for obstructions and damage.	
	Are the tracks OK?	
	→ Yes GO to <u>D4</u> .	

	→ No REMOVE all obstructions and REPAIR any damage. TEST the system for normal operation.	
D4 CHECK THE OPENING SHIELD		
	1 Check the opening shield for proper movement.	
	Is the opening shield moving correctly?	
	→ Yes GO to <u>D5</u> .	
	→ No REMOVE and REINSTALL the opening shield. REFER to <u>Roof Opening Panel</u> <u>Shield</u> . TEST the system for normal operation.	
D5 CHECK THE LIFTER ARMS		
	1 Check the lifter arms for obstructions and damage.	
	Are the lifter assemblies OK?	
	→ Yes GO to <u>D6</u> .	
	→ No REMOVE all obstructions and REPAIR any damage. TEST the system for normal operation.	
D6 CHECK THE ROOF OPENING PANEL MOTOR		
	1 Gain access to the roof opening panel motor.	
	2 Open the roof opening panel.	
	Does the motor make excessive noise?	
	→ Yes INSTALL a new roof opening panel motor. REFER to Motor—Roof Opening Panel. TEST the system for normal operation.	
	→ No ADJUST the roof opening panel. REFER to <u>Roof Opening Panel Alignment</u> or <u>Roof</u> <u>Opening Panel Horizontal Adjustment</u> . TEST the system for normal operation.	

PINPOINT TEST E: THE ROOF OPENING PANEL DOES NOT OPEN OR CLOSE

CONDITIONS	DETAILS/RESULTS/ACTIONS
E1 CHECK THE POWER DOOR LOCKS	
	1 Verify the power door locks operate.









→ No REPAIR the circuit. TEST the system for normal operation.

SECTION 501-17: Roof Opening Panel GENERAL PROCEDURES 2000 Explorer/Mountaineer Workshop Manual

Manual Operation

- 1. Remove the overhead console. For additional information, refer to Section 501-12.
- 2. Insert a flat head screwdriver in the center of the manual drive slot to depress the release pin. Rotate the screwdriver clockwise until the roof opening panel is closed.



Roof Opening Panel Alignment

1. Loosen the four roof opening panel bolts.



- 2. Close the roof opening panel.
- 3. **NOTE:** The correct position of the roof opening panel to the roof panel should be 0 to 1.5 mm (0.059 in) above the roof panel at the rear edge and 0 to 1.5 mm (0.059 in) below the roof panel at the front edge of the panel.

Adjust the roof opening panel.



4. Tighten the roof opening panel bolts.



Roof Opening Panel Horizontal Adjustment

1. Open the roof opening panel to the vent position.



- 2. Loosen the roof opening panel.
 - Loosen the four lifter arm bolts.



- Adjust the roof opening panel.
 Reposition the roof opening panel.
 - 2. Tighten the four lifter arm bolts.



Roof Opening Panel

Removal and Installation

1. Open the roof opening panel to the vent position.



2. Remove the four lifter arm bolts.



3. From outside the vehicle, remove the roof opening panel.



- 4. To install, reverse the removal procedure.
 - Check for correct alignment of the panel. For additional information, refer to <u>Roof Opening</u> <u>Panel Alignment</u> and <u>Roof Opening Panel Horizontal Adjustment</u> in this section.

Roof Opening Panel Shield

Removal and Installation

- 1. Remove the roof opening panel. For additional information, refer to <u>Roof Opening Panel</u> in this section.
- 2. Remove the water channel.
 - 1. Remove the screws.
 - 2. Remove the water channel.



3. Slide the roof opening panel shield forward halfway.



- 4. Disengage the roof opening panel shield spring-loaded guide feet.
 - 1. Push the roof opening panel shield toward one side of the vehicle.
 - 2. Lift the front portion of the roof opening panel shield upward to disengage the spring-loaded guide feet.



5. Slide the roof opening panel shield forward and release the rear guide feet.



6. **NOTE:** When installing the water channel, make sure that the water channel is seated on the locking clips. The LH water channel screw must be installed first.

To install, reverse the removal procedure.

Motor — Roof Opening Panel

Removal

- 1. Remove the overhead console.
 - Disengage the retaining clips and partially remove the overhead console.



2. Disconnect the electrical connectors.



3. NOTE: Make sure that the roof opening panel motor is in the closed position before removal.

Remove the motor.

- 1. Remove the bolts.
- 2. Disconnect the electrical connector.

Installation

1. NOTE: The roof opening panel should be in the closed position.

Connect the roof opening panel motor electrical connector.

- 2. Position the overhead console and connect the electrical connectors.
- 3. With the motor still removed, bump the switch one time only towards the close or vent open position.
- 4. Position the roof opening panel motor and install the bolts.



5. Install the overhead console.

Roof Opening Panel Drain Hose

Removal and Installation

- 1. Remove the headliner. For additional information, refer to <u>Section 501-05</u>.
- 2. From underneath the vehicle, securely attach a new drain hose to the lower end of the old drain hose.



3. Disconnect the drain hose from the roof opening panel assembly.



4. **NOTE:** Make sure that the hoses are not kinked.

Pull the old drain hose through the body of the vehicle and connect the new hose to the roof opening panel.



5. Install the headliner. For additional information, refer to <u>Section 501-05</u>.

Air Deflector

Removal and Installation

- 1. Open the roof opening panel to the fully retracted position.
- 2. Release the two air deflector arms.



- 3. Remove the air deflector.
 - 1. Detach the two air deflector retainer clips from the U-frame.
 - 2. Remove the air deflector.



4. To install, reverse the removal procedure.
Roof Opening Panel Frame

Removal and Installation

- 1. Remove the headliner. For additional information, refer to <u>Section 501-05</u>.
- 2. Disconnect the roof opening panel motor electrical connector.



- 3. Remove the roof opening panel frame.
 - 1. Disconnect the four drain hoses.
 - 2. Remove the fourteen screws.
 - 3. Remove the roof opening panel frame.



Torque Specifications

Description		lb-ft
Front bumper cover strut bolts (Mountaineer)	12	9
Front bumper nuts	70	52
Front bumper fog lamp bracket bolts (Explorer)	30	22
Front bumper fog lamp bracket bolts (Mountaineer)	12	9
Rear bumper isolator and bracket bolts	98-132	72-97
Rear bumper to frame nuts	98-132	72-97

SECTION 501-19: Bumpers DESCRIPTION AND OPERATION

Bumpers

The bumper system consists of the following components:

- air deflector
- fog lamps
- front license plate mounting bracket
- front bumper reinforcement
- front bumper cover
- front bumper cover corner mouldings (Explorer)
- rear bumper spacers
- rear bumper stone deflector
- rear bumper

Bumper Cover — Explorer

Removal

- 1. Remove the front bumper. For additional information, refer to <u>Bumper—Front</u> in this section.
- 2. Remove the bumper cover pin-type retainers.



3. Remove the six fasteners, one pin-type retainer and the air deflector.



- 4. Remove the bumper cover.
 - 1. Remove the 12 screws.
 - 2. Remove the bumper cover.



Installation

Bumper Cover — Corner Molding, Explorer

Removal

- 1. Remove the front bumper cover. For additional information, refer to <u>Bumper Cover—Explorer</u> in this section.
- 2. Remove the bumper cover corner moulding.
 - 1. Remove the clips.
 - 2. Remove the screws.
 - 3. Remove the bumper cover corner moulding.



Installation

Bumper Cover — Mountaineer

Removal

- 1. Remove the front bumper. For additional information, refer to <u>Bumper—Front</u> in this section.
- 2. Remove the two bumper cover struts.
 - 1. Remove the two bolts.
 - 2. Remove the two screws.
 - 3. Remove the two bumper cover struts.



- 3. Remove the two fog lamp assemblies.
 - 1. Remove the four bolts.
 - 2. Remove the two fog lamp assemblies.



- 4. Remove the bumper cover.
 - 1. Remove the rivet.
 - 2. Remove the eight screws.
 - 3. Remove the bumper cover.



5. Remove the two bumper insulators.



Installation





Bumper — Front

Removal

NOTE: Explorer shown, Mountaineer similar.

1. If equipped, disconnect the fog lamp electrical connector.



2. WARNING: To avoid possible injury, support the front bumper before removing the nuts.

Remove the front bumper.

- 1. Remove the four nuts (two each side).
- 2. Remove the front bumper.



Installation



Bumper —Rear

Removal

- 1. If equipped, disconnect the parking aid wiring harness electrical connector.
- 2. WARNING: To avoid possible injury, support the rear bumper before removing the nuts.

NOTE: The rear bumper spacer is required for repair only.

Remove the rear bumper (17906).

- 1. Support the bumper and remove the four nuts (two each side).
- 2. If equipped, remove the spacer.
- 3. Remove the rear bumper.



Installation



Bumper Bracket — Rear

Removal

- 1. Remove the rear bumper (17906); refer to <u>Bumper—Rear</u> in this section.
- 2. Remove the rear bumper isolator and bracket (17787).
 - 1. Remove the nuts and bolts.
 - 2. Remove the isolators and brackets.



Installation



SECTION 501-19: Bumpers REMOVAL AND INSTALLATION 2000 Explorer/Mountaineer Workshop Manual

Parking Aid Sensor

Removal and Installation

For additional information, refer to <u>Section 413-13</u>.

SECTION 501-20A: Occupant Restraints - Active SPECIFICATIONS

General Specifications

ltem	Specification	
Ford Threadlock 262	WSK-M2G351-A6	
(E2FZ-19554-B)		

Torque Specifications

Description	Nm	lb-ft	lb-in
Driver seat safety belt buckle nut	40	30	
Front seat safety belt buckle bolts	40	30	
Rear seat center occupant safety belt and retractor bolt	40	30	
Rear seat safety belt buckle front nuts	40	30	
Rear seat safety belt buckle assembly rear nuts	48	35	
Safety belt anchor bolts	40	30	
Safety belt guide to floor bolt	40	30	I
Safety belt guide to seat track bolt	9	—	80
Safety belt guide to seat track nut	9	—	80
Safety belt retractor bolts	40	30	
Shoulder safety belt height adjuster bolts	40	30	

SECTION 501-20A: Occupant Restraints - Active DESCRIPTION AND OPERATION

2000 Explorer/Mountaineer Workshop Manual

Occupant Restraint System

WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds that the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

When replacing safety belt buckle or retractor assemblies, use only the replacement parts specified in the Ford Customer Service Division Master Parts Catalog.

4 2 3 Ø 5 GR4220-A Part Number Item Description 1 Passenger side rear safety belt buckle 2 Center rear safety belt buckle 3 Driver side rear buckle 4 Driver side safety belt buckle (bucket seat) 5 Passenger side safety belt buckle (bucket seat)

Occupant Restraint System Component Locations — Buckles, Four-Door

Occupant Restraint System Component Locations — Buckles, Two-Door



Occupant Restraint System Component Locations — Retractors and Tongues, Four-Door

Item	Part Number	Description	
1	_	Passenger side front safety belt retractor assembly	
2	—	Center passenger rear safety belt retractor and rear passenger buckle assembly	
3	—	Driver side rear retractor assembly (passenger side similar)	1
4	—	Driver shoulder safety belt height adjuster (passenger side similar)	

Occupant Restraint System Component Locations — Retractors and Tongues, Two-Door

	Part		
Item	Number	Description	
1	_	Passenger side front safety belt retractor assembly	
2		Rear driver side retractor assembly	
3	_	Driver shoulder safety belt height adjuster (passenger side similar)	

The outboard safety belt for the front and rear seats is a continuous-loop three-point system. The combination lap and shoulder belt (continuous-loop) uses a common sliding tongue and retractor.

The shoulder harness retractor is designed to let the webbing move freely in or out at all times, except during vehicle hard braking, hard cornering or an impact of 8 km/h (5 mph) or more, when it is automatically locked by a mechanically actuated inertia sensor.

Dual Locking Mode Retractors

NOTE: When replacing a dual locking mode retractor, the retractor should be checked to make sure it is not

in the automatic locking retractor (ALR) mode after installation in the stowed position.

All outboard continuous-loop, three-point retractor systems, except the driver position, are equipped with the dual locking mode system.

The emergency locking retractor (ELR) mode will allow the occupant freedom of movement, locking tight only on hard braking, hard cornering, or an impact of approximately 8 km/h (5 mph). The ELR mode helps to reduce the forward movement of the driver and passengers. The ELR mode is continuously in operation at all seating positions.

The ALR portion of this system does not allow the occupant freedom of movement. The ALR mode is used when locking a child seat in an outboard seating position or when a tight belt fit is desired. The ALR mode is disengaged when the webbing is free to move in or out of the retractor. The ALR mode is automatically engaged when the webbing is fully extracted from the retractor and then allowed to retract. As the webbing is retracted back onto the spool, an audible clicking sound is made, indicating that the retractor is in ALR mode. The ALR mode is automatically disengaged when most of the webbing is retracted back onto the spool.

WARNING: After any vehicle collision, the safety belt system at all outboard seating positions (except driver, which has no "automatic locking retractor" feature) must be checked by a qualified technician to verify that the "automatic locking retractor" feature for child seats is still functioning properly, in addition to other checks for proper safety belt system function. A belt and retractor assembly must be replaced if the safety belt assembly's "automatic locking retractor" feature or any other safety belt function is not operating properly when checked according to the procedures in the workshop manual. Failure to replace the Belt and Retractor assembly could increase the risk of injury in collisions.

This vehicle has a safety belt system with an energy management feature at the front seating positions to help further reduce the risk of injury in the event of a head-on collision.

This safety belt system has a retractor assembly that is designed to pay out webbing in a controlled manner. This feature is designed to help reduce the belt force acting on occupant's chest.

Safety Belt Extension Assembly

In certain cases, the safety belt may be too short even when it is fully extended. About 20 cm (8 in) can be added to the belt length by using a safety belt extension (611C22). Safety belt extensions are available at no cost from any Ford or Lincoln-Mercury dealer parts department at no cost. Safety belt extensions are only available with black webbing.

There are two extension assemblies available, one for the front seating positions and one for the rear seating positions and they are not interchangeable.

Use only extensions manufactured by the same supplier as the safety belt. Manufacturer identification is located at the end of the webbing on the label. Also, use the safety belt extension only if safety belt is too short for you when fully extended. Do not use extension to change the fit of the shoulder belt across the torso.

Attaching Safety Seats With Tether Straps

Some manufacturers make child safety seats that include a tether strap that goes over the back of the vehicle seat and attaches to an anchoring point. Other manufacturers offer the tether strap as an accessory. Contact the manufacturer of the child safety seat for information about ordering a tether strap.

Attach a tether strap anchor bracket to the rear floor by using a tether anchor kit, available at no charge from

any Ford or Lincoln-Mercury dealership.

Carefully read and follow the instructions provided with the kit for installation of the child tether strap anchor.

Occupant Restraint System — Indicator Lights and Chimes

Safety Belt Warning Indicator and Chime

The warning indicator and chime are reminders to fasten the safety belt. The following conditions will take place:

- If the safety belt is not buckled before the ignition is turned to the ON position, the chime will turn on for four to eight seconds and the indicator will come on for one to two minutes.
- If the safety belt is buckled while the indicator is on and the chime is sounding, both the indicator and chime will turn off.
- If the safety belt is buckled before the ignition is turned to the ON position, neither the indicator nor the chime will turn on.

Belt Minder (if equipped)

The Belt Minder feature is a supplemental warning to the safety belt warning function. This feature provides additional reminders to the driver that the driver's safety belt is unbuckled by intermittently sounding a chime and illuminating the safety belt warning lamp in the instrument cluster.

lf	Then
The driver's safety belt is not buckled before the vehicle has reached at least 5 km/h (3 mph) and 1-2 minutes have elapsed since the ignition switch has been turned to ON	The Belt Minder feature is activated - the safety belt warning light illuminates and the warning chime sounds for 6 seconds every 30 seconds, repeating for approximately 5 minutes or until safety belt is buckled.
The driver's safety belt is buckled while the safety belt indicator light is illuminated and the safety belt warning chime is sounding	The Belt Minder feature will not activate.
The driver's safety belt is buckled before the ignition switch is turned to the ON position	The Belt Minder feature will not activate.

Occupant Restraint System

Inspection and Verification

- 1. Verify the customer concern by operating the safety belts.
- 2. Visually inspect for obvious signs of mechanical and electrical damage. For additional information, refer to the following chart:

Visual Inspection Chart

Mechanical	
Loose webbingSafety belt retractor and tongue assem	ıbly

3. If the concern is not visually evident, determine the symptom. GO to Symptom Chart.

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action
 Normal mode — occupant restraint system inoperative 	Broken tooth on retractor sensor gear.Loose webbing.	 REFER to Component Test.
 Automatic locking retraction (ALR) system inoperative 	Broken tooth on retractor sensor gear.Loose webbing.	 REFER to Component Test.
 The safety belt warning chime is inoperative 	 Circuitry. Safety belt warning switch. Generic electronic module (GEM). 	 REFER to <u>Section</u> <u>413-09</u>.
 The safety belt warning indicator is inoperative 	 Circuitry. Safety belt warning switch. Instrument cluster. Bulb. GEM. 	 REFER to <u>Section</u> <u>413-01</u>.

Component Test

Functional Test

- 1. The driver should buckle up and proceed to a safe test area. If the RH front or a rear passenger safety belt must be tested, a passenger should be buckled into the RH front or rear seat. The RH front belt may be tested using a driver only, providing driver has the ability to grasp the RH front shoulder belt and extend it approximately 66 cm (25.9 in) with no compromise to safe driving. This method applies to 8 km/h (5 mph) test only.
- 2. After reaching a safe area to carry out sudden stops, the driver will attain a speed of approximately 8 km/h (5 mph). The driver should inform the passenger (if applicable) that he is preparing to make a severe brake application. At this time, both the driver and passenger should grasp their respective shoulder harnesses and prepare to lean slightly forward at the moment the brake application is made.

3. **WARNING:** The driver and passenger must be prepared to brace themselves in the event the retractor does not lock.

The driver will make a maximum brake application without tire skid. The maximum brake application should be on dry concrete or equivalent hard road surface; never on a wet or gravel road.

- 4. The driver and passenger should lean forward slightly into shoulder harness. At this instant, belts should lock up without webbing pay out.
- 5. If there is a lockup of both shoulder straps, safety belt assemblies are functioning correctly.
- 6. **NOTE:** If the retractor of a new safety belt assembly has been bolted into a damaged or distorted mounting area, the new retractor could be warped and may not function. If this is the case, reshape the sheet metal and install another new complete safety belt assembly.

Should either or both retractors fail to lock up at the 8 km/h (5 mph) speed, repeat the test at a constant 24 km/h (15 mph). This test must be carried out with RH front or rear passenger if RH front or rear belts are to be tested.

 If either or both shoulder safety belts do not lock up at 24 km/h (15 mph) test, return vehicle for repair of malfunctioning safety belts. Remove retractor and rework sheet metal in retractor's mounting surface. Install retractor assembly and retest safety belt assembly(s). SECTION 501-20A: Occupant Restraints - Active GENERAL PROCEDURES

2000 Explorer/Mountaineer Workshop Manual

Safety Belt Cleaning

1. WARNING: Do not bleach or re-dye the webbing, as the webbing may weaken.

Clean the safety belt webbing only with a mild soap solution recommended for cleaning upholstery or carpets. Follow the instructions provided with the soap.

Safety Belt With Anchor Plate Thread Damage

- 1. Remove the broken or stripped bolt and discard.
- 2. Drill out the internal threads in the safety belt anchor plate with a 10.7 mm (27/64 in) drill.
- 3. Rethread the anchor plate with a 1/2-13 tap (seat belt).
- 4. Clean out the chips.
- 5. Install the attachment parts. Original parts are to be replaced with the repair parts indicated in the Safety Belt Parts Replacement Guidelines.
- 6. When repairing a multiple belt and attachment, install the nut to the bolt in the tunnel area from the underside of the floorpan.

SECTION 501-20A: Occupant Restraints - Active GENERAL PROCEDURES

Replacement of the Weld Nut and Reinforcement

- 1. Remove the interior trim panel to expose the suspect anchor point. For additional information, refer to <u>Section 501-00</u>.
- Determine if the weld nut only or the weld nut and reinforcement and weld nut are missing. If the B- or C- or D-pillar safety belt anchor nuts or reinforcements are stripped or missing, a new nut or reinforcement should be installed. To install a missing weld nut only, proceed to Step 3.
- 3. Obtain the correct M12 weld nut and a standard washer to perform the procedure.
- 4. Drill out two 8 mm (5/16 in) diameter holes adjacent to the clearance hole.
- 5. Obtain a length of copper welding wire and feed through clearance hole in door frame opening until it becomes visible at the access hole.
- 6. Pull the wire through so that it may be secured to the weld nut and washer.
- 7. Pull the wire back up to the weld nut clearance hole.
- 8. Hold the weld nut securely in place. Use the MIG Wire Feed Welder 106-00053 to plug weld the nut in place at the two 8 mm (5/16 in) diameter holes previously drilled.
- 9. Metal finish as required.
- 10. Verify the nut is securely in place.

Safety Belt Shoulder Height Adjuster With Stripped Weld Nuts

Special Tool(s)



- 1. Remove the B-pillar trim panel. For additional information, refer to <u>Section 501-05</u>.
- 2. Use the half-inch drill with integral stop provided in D-Ring Installation Kit to drill out the damaged threads in the upper pillar structure.



3. **NOTE:** After each rotation, back off tap slightly to remove new cuttings and be sure to blow out any chips before proceeding.

Apply a suitable lubricant to the M14 x 1.5 tap with integral stop provided in D-Ring Installation Kit and tap new threads.



4. Use a threaded insert (N807170-S190) provided in the D-Ring Installation Kit and screw it into the retapped hole until it is slightly below the surface.



5. **NOTE:** If the two bolts on the height adjuster are not stripped, install the height adjuster. For additional information, refer to the appropriate height adjuster procedure in this section.

Use a hammer to lightly tap the installation tool provided in the D-Ring Installation Kit several times to seat the insert keys.


SECTION 501-20A: Occupant Restraints - Active GENERAL PROCEDURES

Safety Belt Procedure After a Collision

1. WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters, if so equipped, child safety seat tether attachments, and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate correctly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

NOTE: Safety belt assemblies should be periodically inspected to make sure they have not become damaged and that they remain in correct operating condition, particularly if they have been subjected to severe stress.

Before installing the new safety belt assembly, the safety belt attaching areas must be inspected for damage and distortion. If the attaching points are damaged and distorted, the sheet metal must be reworked back to its original shape and structural integrity.

Install the new safety belt(s) using the appropriate instructions. Perform the Functional Test.

Safety Belt Tongue Rotated on Belt

1. Fold the safety belt as indicated.



2. Pull the safety belt tongue over the fold in the safety belt.



SECTION 501-20A: Occupant Restraints - Active GENERAL PROCEDURES

Automatic Locking Retractor — Evaluation of Lockability and Release

WARNING: After any vehicle collision, the safety belt system at all outboard seating positions (except driver, which has no "automatic locking retractor" feature) must be checked by a qualified technician to verify that the "automatic locking retractor" feature for child seats is still functioning properly, in addition to other checks for proper safety belt system function. A belt and retractor assembly must be replaced if the safety belt assembly's "automatic locking retractor" feature, or any other safety belt function, is not operating properly when checked according to the procedures in the workshop manual. Failure to replace the belt and retractor assembly could increase the risk of injury in collisions.

- 1. Extend the safety belt to latch the tongue into the buckle across an empty seat without slack in the safety belt, with the seat in the full down and rearmost position, seat back in an upright position, and if applicable, the D-ring adjusted in the full down position.
- 2. Pull the shoulder belt to full extension to engage the retractor's automatic locking retractor (ALR) feature. Then allow the belt to retract freely in the ALR mode, and the retractor force set the correct belt tightness.
- 3. Pull on the shoulder belt to check that the belt has remained in the ALR mode. If the belt is not locked, install a new belt and retractor assembly. The safety belt should remain locked in the ALR mode across an empty seat.
- 4. To verify that the safety belt still automatically disengages from the ALR mode correctly, with the Dring adjusted to the full up position, if applicable, unlatch the safety belt tongue from the buckle and allow the safety belt to retract to its stowed position. Pull on the shoulder belt to verify that the retractor assembly has converted automatically out of the ALR mode. If the belt remains locked in the stowed position, a new belt and retractor assembly must be installed. The safety belt should extract freely.

Retractor — B-Pillar, Two-Door

Special Tool(s)



Material

ltem	Specification	
Ford Threadlock 262 (E2F2-19554-B) or equivalent	WSK-M2G351-A6	

Removal

WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Remove the quarter trim panel. For additional information, refer to Section 501-05.
- 2. Remove the front safety belt retractor.
 - 1. Use Safety Belt Bolt Bit to remove the bolt.
 - 2. Remove the front safety belt retractor.



Installation

NOTE: Apply Ford Threadlock 262 (E2FZ-19554-B) or equivalent to fasteners when installing safety belt buckle or retractor assemblies.

1. Use Safety Belt Bolt Bit to install the front safety belt retractor.



- 2. Install the quarter trim panel. For additional information, refer to <u>Section 501-05</u>.
- 3. Check the restraint system for proper operation.

Retractor — Driver Side and Outside Passenger, B-Pillar, Four-Door

Special Tool(s)



Material

ltem	Specification	
Ford Threadlock 262 (E2F2-19554-B) or equivalent	WSK-M2G351-A6	

Removal

WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Remove the B-pillar trim panel. For additional information, refer to <u>Section 501-05</u>.
- 2. Remove the front safety belt retractor.
 - 1. Use Safety Belt Bolt Bit to remove the bolts.
 - 2. Remove the front safety belt retractor.



Installation

NOTE: Apply Ford Threadlock 262 (E2FZ-19554-B) or equivalent to fasteners when installing safety belt buckle or retractor assemblies.

1. Use Safety Belt Bolt Bit to install the front safety belt retractor.



- 2. Install the B-pillar trim panel. For additional information, refer to Section 501-05.
- 3. Check the restraint system for proper operation.

Retractor — Driver Side and Outside Passenger, B-Pillar, Four-Door

Special Tool(s)



Material

ltem	Specification	
Ford Threadlock 262 (E2F2-19554-B) or equivalent	WSK-M2G351-A6	

Removal

WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Remove the B-pillar trim panel. For additional information, refer to <u>Section 501-05</u>.
- 2. Remove the front safety belt retractor.
 - 1. Use Safety Belt Bolt Bit to remove the bolts.
 - 2. Remove the front safety belt retractor.



Installation

NOTE: Apply Ford Threadlock 262 (E2FZ-19554-B) or equivalent to fasteners when installing safety belt buckle or retractor assemblies.

1. Use Safety Belt Bolt Bit to install the front safety belt retractor.



- 2. Install the B-pillar trim panel. For additional information, refer to Section 501-05.
- 3. Check the restraint system for proper operation.

Retractor --- C-Pillar, Four-Door

Special Tool(s)



Material

ltem	Specification	
Ford Threadlock 262 (E2F2-19554-B) or equivalent	WSK-M2G351-A6	

Removal



WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Remove the guarter trim panel; refer to Section 501-05.
- 2. Remove the safety belt retractor.
 - 1. Use Safety Belt Bolt Bit to remove the bolt.
 - 2. Remove the safety belt retractor.



Installation

NOTE: Apply Ford Threadlock 262 (E2FZ-19554-B) or equivalent to fasteners when installing safety belt buckle or retractor assemblies.

1. Use Safety Belt Bolt Bit to install the safety belt retractor.



- 2. Install the quarter trim panel. For additional information, refer to <u>Section 501-05</u>.
- 3. Check the restraint system for proper operation.

Retractor — C-Pillar, Two-Door

Special Tool(s)



Material

ltem	Specification	
Ford Threadlock 262 (E2F2-19554-B) or equivalent	WSK-M2G351-A6	

Removal

WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Remove the quarter trim panel. For additional information, refer to Section 501-05.
- 2. Remove the safety belt retractor.
 - 1. Use Safety Belt Bolt Bit to remove the bolts.
 - 2. Remove the safety belt retractor.



Installation

NOTE: Apply Ford Threadlock 262 (E2FZ-19554-B) or equivalent to fasteners when installing safety belt buckle or retractor assemblies.

1. Use Safety Belt Bolt Bit to install the safety belt retractor.



- 2. Install the quarter trim panel. For additional information, refer to <u>Section 501-05</u>.
- 3. Check the restraint system for proper operation.

Retractor — Rear Seat, Retractor and Buckle Assembly, Four-Door

Special Tool(s)



Material

ltem	Specification	
Ford Threadlock 262 (E2F2-19554-B) or equivalent	WSK-M2G351-A6	

Removal



WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Fold the rear seat down to load floor position.
- 2. Remove the rear safety belt buckle and retractor assembly.
 - 1. Use Safety Belt Bolt Bit to remove the bolt.
 - 2. Remove the rear safety belt buckle and retractor assembly.



Installation

NOTE: Apply Ford Threadlock 262 (E2FZ-19554-B) or equivalent to fasteners when installing safety belt buckle or retractor assemblies.

1. **NOTE:** Make sure the safety belt webbing is not twisted prior to installation.

To install, reverse the removal procedure.

• Check the restraint system for proper operation.



Height Adjuster

Special Tool(s)



Material

ltem	Specification	
Ford Threadlock 262 (E2F2-19554-B) or equivalent	WSK-M2G351-A6	

Removal

- 1. On four-door models, remove the B-pillar trim panel. For additional information, refer to <u>Section 501-</u> <u>05</u>.
- 2. On two-door models, remove the quarter trim panel. For additional information, refer to <u>Section 501-</u>05.
- 3. Remove the height adjuster cover (602B90).



- 4. Remove the shoulder safety belt height adjuster (602B82).
 - 1. Use Safety Belt Bolt Bit to remove the two bolts.
 - 2. Remove the shoulder safety belt height adjuster.



Installation

NOTE: Apply Ford Threadlock 262 (E2FZ-19554-B) or equivalent to fasteners when installing safety belt buckle or retractor assemblies.

1. Use Safety Belt Bolt Bit and install the shoulder safety belt height adjuster.



2. Install the height adjuster cover.



- 3. On two door models, install the quarter trim panel. For additional information, refer to Section 501-05.
- 4. On four door models, install the B-pillar trim panel. For additional information, refer to <u>Section 501-</u><u>05</u>.
- 5. Check the restraint system for proper operation.

Safety Belt Buckle — Bucket Seats

Special Tool(s)



Material

ltem	Specification	
Ford Threadlock 262 (E2F2-19554-B) or equivalent	WSK-M2G351-A6	

Removal

WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Remove the floor console. For additional information, refer to <u>Section 501-12</u>.
- 2. Move the seat forward and use Safety Belt Bolt Bit to remove the slide bar bolt.



- 3. Remove the front seat. For additional information, refer to Section 501-10.
- 4. Remove the safety belt slide bar.
 - 1. Disconnect the electrical connector (LH only).
 - 2. Remove the nut.
 - 3. Remove the bolt.

4. Remove the slide bar.



5. **NOTE:** Clamp the slide bar collar in a vise along the break line only.

Remove the safety belt buckle.

- 1. Clamp the slide bar in a suitable vise.
- 2. Use Safety Belt Bolt Bit to remove the bolt.
- 3. Remove the buckle.



Installation

NOTE: Apply Ford Threadlock 262 (E2FZ-19554-B) or equivalent to fasteners when installing safety belt buckle or retractor assemblies.

1. To install, reverse the removal procedure.





Safety Belt Buckle — Rear Seat, Four-Door

Removal

WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Remove the rear seats. For additional information, refer to <u>Section 501-10</u>.
- 2. Remove the rear safety belt buckle assembly.
 - 1. Remove the nuts.
 - 2. Remove the rear safety belt buckle assembly.



Installation

- 1. To install, reverse the removal procedure.
 - Check the restraint system for correct operation.



Safety Belt Buckle —Rear Seat, Two-Door

Removal

WARNING: All safety belt assemblies including retractors, buckles, front seat belt buckle support assemblies (slide bar), shoulder belt height adjusters (if so equipped) child safety seat tether attachments and attaching hardware should be inspected after any collision. All belt assemblies should be replaced unless a qualified technician finds the assemblies show no damage and operate properly. Belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.

- 1. Remove the rear seats. For additional information, refer to <u>Section 501-10</u>.
- 2. Remove the rear safety belt buckles.
 - 1. Remove the nuts.
 - 2. Remove the rear safety belt buckles.



Installation

- 1. To install, reverse the removal procedure.
 - Check the restraint system for correct operation.



SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explorer/Mountaineer Workshop Air Bag System Manual SPECIFICATIONS

General Specifications

Item	Specification
Connector Identification	
Butt connector E6FZ-14488-A	Gauge 18-22, Red, Class C
Butt connector E6FZ-14488-B	Gauge, 14-16, Blue, Class C
Butt connector E6FZ-14488-C	Gauge 10-12, Yellow, Class C

Torque Specifications

Description	Nm	lb-ft	lb-in
Side crash sensor	12	9	—
Restraints control module bracket	12	9	—
Driver air bag module	9	_	80
Passenger air bag module	7.6-10.4	_	67-92
Side air bag module	8	_	71
Seat back pivot bolt	29	21	—
Seat back recliner bolts	52	38	—
Track to cushion frame	20	15	—
Steering column fore and aft nuts	15	11	_
Lower steering column opening finish panel reinforcement	12	9	—
Front crash sensor	10.2-13.8	_	90-122
Weld nut repair screw (8 mm) (N802455-S190)	12	9	_
Grounding screw (6 mm) (N806327-S190)	12	9	—

SECTION 501-20B: Occupant Restraints — Passive — Supplemental Air Bag System DESCRIPTION AND OPERATION

2000 Explorer/Mountaineer Workshop Manual

Air Bag Supplemental Restraint System (SRS)

The air bag supplemental restraint system (SRS) is designed to provide increased collision protection for front seat occupants in addition to that provided by the three-point safety belt system. Safety belt use is necessary to obtain the best occupant protection and to receive the full advantage of the SRS.

The air bag supplemental restraint system (SRS) components are shown in the following illustration.

Air Bag Supplemental Restraint System (SRS) Components



ltem	Part Number	Description
1	14B321	Restraints control module (RCM)

Page	2	of	5	
I ugo	_	O1	\mathcal{I}	

2	14B345	Side crash sensor (RH)
3	98611D10	Passenger side air bag module
4	044A74	Passenger air bag module
5	78611D11	Driver side air bag module
6	14B345	Side crash sensor (LH)
7	043B13	Driver air bag module
8	14A664	Air bag sliding contact
9	14B005	Air bag sensor and bracket (LH)
10	14B005	Air bag sensor and bracket (RH)

Air Bag Module — Driver

NOTE: References to the driver air bag module must not be confused with the seat-mounted air bag components of the supplemental restraint system (SRS).

The driver air bag module:

- is installed new as an assembly.
- is mounted in the center of the steering wheel.

Driver Air Bag Module



Air Bag Sliding Contact

The air bag sliding contact:

- is mounted on the steering column, behind the steering wheel.
- continuously transfers electrical signals from the driver air bag module to the restraints control module (RCM).

Air Bag Module — Driver Side

NOTE: References to side air bag modules refer to the seat-mounted and not to the steering wheel or

instrument panel mounted air bag components of the supplemental restraint system (SRS).

The driver side air bag module:

- is installed new as an assembly.
- is mounted in the driver seat back.

Air Bag Module — Passenger Side

NOTE: References to side air bag modules refer to the seat-mounted and not to the steering wheel or instrument panel mounted air bag components of the supplemental restraint system (SRS).

The passenger side air bag module:

- is installed new as an assembly.
- is mounted in the passenger seat back.

Air Bag Module — Passenger

NOTE: References to the passenger air bag module must not be confused with the seat-mounted air bag components of the supplemental restraint system (SRS).

The passenger air bag module:

- is installed new as an assembly.
- is mounted in the RH side of the instrument panel.

Passenger Air Bag Module

DR1402-A		2	
ltem	Part Number		Description
1	—	Deployment door (part of 044A74)	
2	044A74	Passenger air bag module	

Restraints Control Module (RCM)

The restraints control module (RCM) carries out the following functions:

- signals the inflators to deploy the air bags in the event of a deployable crash.
- monitors the air bag supplemental restraint system (SRS) for faults.

- illuminates the air bag indicator if a fault is detected.
- flashes the air bag indicator to indicate the lamp fault code (LFC) detected.
- communicates through the data link connector (DLC) the current or historical Diagnostic Trouble Codes (DTCs).
- signals the generic electronic module (GEM) to activate a chime if the air bag indicator is not available and another SRS fault exists.

NOTE: The safety sensor is internal to the RCM and is not serviced separately.

The RCM monitors the SRS for possible faults. If a fault is detected while the ignition switch is in the RUN position, the RCM will illuminate the air bag indicator located in the instrument cluster.

When the ignition is cycled (turned off and then on), the air bag indicator will prove out by lighting for six seconds and then off for two seconds. After the prove out, the air bag indicator will then flash the two-digit LFC. If an SRS fault exists, the air bag indicator will flash the LFC five times, then it will remain illuminated for the rest of the key cycle. The RCM will also communicate the current and historical DTCs through the DLC, to the scan tool. If the air bag indicator does not function, and the system detects a fault condition, the RCM will signal the GEM to activate an audible chime. The chime is a series of five sets of five tone bursts. If the chime is heard, the SRS and the air bag indicator require repair.

LFCs are prioritized. If two or more faults occur at the same time, the fault having the highest priority will be displayed. After that fault has been corrected, the next highest priority fault will be displayed.

The RCM includes a backup power supply. This feature provides sufficient backup power to deploy the air bags in the event that the ignition circuit is damaged in a collision before the safing and air bag sensors determine that a deployment is required. The backup power supply will deplete its stored energy approximately one minute after the battery ground cable is disconnected.

Electrical System

The electrical system that supports the air bag supplemental restraint system (SRS):

- is powered from the battery through the ignition circuit.
- provides the electrical path from the restraints control module (RCM) to the air bag modules.
- provides the electrical path from the RCM to the air bag indicator.
- provides the electrical path from the RCM to the data link connector (DLC).
- provides the electrical path from the RCM to the generic electronic module (GEM).

Sensor

WARNING: The restraints control module (RCM) orientation is critical for correct system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) has been involved in a collision in which the right cowl A-pillar area has been damaged, inspect the mounting and bracket for deformation. If damaged, the RCM must be replaced whether or not the air bags have deployed. In addition, make sure the area of the RCM mounting is restored to its original condition.

The SRS contains two sensors which are integral to the RCM. The RCM is mounted on the RH A-pillar.

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explorer/Mountaineer Workshop Air Bag System Manual DIAGNOSIS AND TESTING

Air Bag Supplemental Restraint System (SRS)

Refer to Wiring Diagrams Cell <u>46</u>, Air Bag for schematic and connector information.

Special Tool(s)

ST2506-A	Front Air Bag Simulator (Restraint System Diagnostic Tool) 105-R0012 or Equivalent
ST2507-A	Side Air Bag Simulator (Restraint System Diagnostic Tool) 418-133 or Equivalent

Restraint System Diagnostic Tool Warning

WARNING: This tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Diagnosing Customer Concerns Without Hard Diagnostic Trouble Codes (DTCs)

If a lamp fault code (LFC) is reported by the customer but is not present when the vehicle comes in for repair, follow the Diagnostic Instructions procedure in this section to identify the intermittent DTC.

Once the DTC is known, read the Normal Operation section for the code involved.

- Follow the deactivation procedure in this section.
- Determine the location of components involved in creating that code.
- Carry out a thorough visual inspection of:
 - components.
 - connectors.
 - splices and wiring harnesses.
 - pinched wires.
 - worn insulation on conductors.
 - opens, shorts or loosely mounted sensors.

Refer to Possible Causes, which lists the common concerns that relate to a particular code. Concerns are listed according to priority.

Diagnosing Customer Concerns with Hard Diagnostic Trouble Codes (DTCs)

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

Most air bag supplemental restraint system (SRS) diagnostic procedures will require the use of the deactivation and reactivation procedures in this section.

The deactivation procedure requires the removal of the driver air bag and the disconnection of the passenger air bag. Restraint system diagnostic tools are attached to the vehicle harness at the air bag sliding contact and at the electrical connectors for the passenger air bag and the two side air bags. This procedure removes the risk of air bag deployment while diagnostics are carried out.

Restraint system diagnostic tools are required to carry out diagnosis and testing of the SRS. The restraint system diagnostic tool is a 2-ohm resistor used to simulate air bag module connections to the system. It is not acceptable to short-circuit the air bag module connections with a zero-ohm jumper wire. If a zero-ohm jumper wire is used to short-circuit the air bag module connections, a lamp fault code (LFC) will be displayed.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

The reactivation procedure requires the removal of any restraint system diagnostic tools installed and the reinstallation and reconnection of any air bag modules removed or disconnected.

Deactivation Procedure

1. **WARNING:** To avoid accidental deployment and possible personal injury, the backup
power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

Remove the front seats from the vehicle. For additional information, refer to Section 501-10.

2. WARNING: Carry a live air bag module with the air bag and trim cover pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live air bag module down with the trim cover face down. This will reduce the risk of injury in the event of an accidental deployment.

Remove the driver air bag module from the vehicle. Refer to Module—Driver Air Bag in this section.

3. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

Connect a front restraint system diagnostic tool to the vehicle harness at the top of the steering column.

4. WARNING: Carry a live air bag module with the air bag and deployment door pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live air bag module down with the deployment door face down. This will reduce the risk of injury in the event of an accidental deployment.

Disconnect the passenger air bag module electrical connector.

- 5. Connect a front restraint system diagnostic tool to the vehicle harness.
- 6. Connect a side restraint system diagnostic tool to the vehicle harness used for the driver side air bag.
- 7. Connect a side restraint system diagnostic tool to the vehicle harness used for the passenger side air bag.
- 8. Reconnect the battery ground cable. For additional information, refer to Section 414-01.

Reactivation Procedure

1. WARNING: The air bag simulators must be removed and the air bag modules reconnected when the system is reactivated to avoid non-deployment in a collision, resulting in possible personal injury.

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Disconnect the battery ground cable. For additional information, refer to Section 414-01.

- 2. Wait at least one minute for the backup power supply in the restraints control module (RCM) to deplete its stored energy.
- 3. Remove the restraint system diagnostic tool from the vehicle harness connector at the top of the steering column.
- 4. WARNING: Carry a live air bag module with the air bag and trim cover pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

Install the driver air bag module. Refer to Module—Driver Air Bag in this section.

- 5. Remove the restraint system diagnostic tool from the vehicle harness connector at the passenger air bag module.
- 6. WARNING: Carry a live air bag module with the air bag and deployment door pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

Connect the passenger air bag module electrical connector.

7. Remove the restraint system diagnostic tool from the vehicle harness used for the passenger side air bag.

- 8. Remove the restraint system diagnostic tool from the vehicle harness used for the driver side air bag.
- 9. Install the front seats. For additional information, refer to <u>Section 501-10</u>.
- 10. Reconnect the battery ground cable. For additional information, refer to Section 414-01.
- 11. Prove out the system.

Glossary

Restraint System Diagnostic Tools

Restraint system diagnostic tools are used to simulate air bag module connections to the system.

Disconnect the Component

Disconnect the component means disconnect the component vehicle harness connector. It does not mean remove the component. Do not reconnect a disconnected component unless instructed to do so.

Deactivate the System

Deactivate the system means to carry out the deactivation procedure. Refer to Deactivation Procedure in this section.

Prove Out the System

Prove out the system means to turn the ignition switch from the OFF to the RUN position and visually monitor the air bag indicator with the air bag modules installed. The air bag indicator will light continuously for approximately six seconds and then turn off. If an air bag supplemental restraint system (SRS) fault is present, the air bag indicator will either:

- fail to light.
- remain lit continuously.
- flash.

The flashing might not occur until approximately 30 seconds after the ignition switch has been turned from the OFF to the RUN position. This is the time required for the restraints control module (RCM) to complete the testing of the SRS. If the air bag indicator is inoperative and an SRS fault exists, a chime will sound in a pattern of five sets of five beeps. If this occurs, the air bag indicator will need to be repaired before diagnosis can continue.

Reactivate the System

Reactivate the system means to carry out the reactivation procedure. Refer to Reactivation Procedure in this section.

Reconnect the System

Reconnect the system means to reconnect all system components. Refer to Air Bag Reconnect Checklist in this section.

Install a New Component

Install a new component means to remove the existing component and install a new authorized part obtained from Ford Customer Service Division.

Verify the System

Verify the system means to prove out the system with restraint system diagnostic tools for the air bag modules in place of the components.

Air Bag Reconnect Checklist

The checklist below should be completed following diagnosis or repair of any air bag system concern:

- 1. Is the three-way connector at the base of the steering column connected?
- 2. Are the air bag modules connected?
- 3. Is the restraints control module (RCM) connected?
- 4. Is the vehicle battery connected?

Manual

Diagnostic Instructions — Air Bag Supplemental Restraint System (SRS)

Special Tool(s)

	Worldwide Diagnostic System (WDS) 418-F224,
ST2332-A	New Generation STAR (NGS) Tester 418-F052, or equivalent scan tool

The symptom chart can be used to help locate the air bag supplemental restraint system (SRS) concerns if no diagnostic trouble codes (DTCs) are retrieved and the listed symptoms are observed. Whether or not the listed symptoms are observed, always carry out the following:

- 1. Retrieve all DTCs stored in the restraints control module (RCM) memory. Refer to Retrieve/Clear Continuous DTCs in this section.
- 2. Run the On-Demand Self Test to determine what DTCs are currently being sensed by the RCM; refer to On-Demand Self Test in this section.
- 3. If the stored DTCs are different than the current DTCs, always repair the current DTCs first.
- 4. If memory displays different continuous DTCs than the On-Demand Self Test, perform in the following order:
- On-Demand Self Test.
- Memory (Retrieve/Clear Continuous DTCs).

A DTC can indicate several concerns. The DTCs are to assist in system diagnosis and are not to be considered definitive. Always refer to the pinpoint test corresponding to the DTC to determine where the concern lies and to repair the concern correctly.

The SRS diagnostics can be divided into three sections:

- diagnostic test modes.
- PID/data monitor and record.
- active command modes.

Diagnostic Test Modes

Two menu options are available under the diagnostic test modes:

• Retrieve/Clear Continuous DTCs.

• On-Demand Self Test.

Retrieve/Clear Continuous DTCs

During vehicle operation the restraints control module (RCM) will detect and store both intermittent and hard fault DTCs in nonvolatile memory. The DTC strategy employed by the RCM incorporates a time-out scheme for determining when a concern exists in the system. This requires a concern to exist for up to one minute in the system before the RCM will detect it. For the RCM to determine that a concern no longer exists, the concern must be absent for up to one minute. The actual detection time-outs vary with each DTC. The DTCs can be retrieved with the scan tool. Any DTCs stored in the RCM will be displayed on the scan tool along with a brief description of the DTC. If no DTCs are present, the scan tool will display a SYSTEM PASSED message. The scan tool can also be used to clear DTCs from the RCM memory, as long as the concern no longer exists. Once 254 key cycles have been recorded since the concern was last detected, the DTC will automatically be removed from memory.

To retrieve or clear DTCs, connect the scan tool to the data link connector (DLC). Follow the instructions for the scan tool being used. All continuous DTCs will be displayed on the screen. Before proceeding with the clearing operation, make note of the DTCs displayed, because once cleared, they cannot be retrieved. Hard DTCs will be redisplayed after clearing DTCs since they cannot be cleared from the RCM.

On-Demand Self Test

The On-Demand Self Test option is used to verify that no electrical concerns exist with the air bag supplemental restraint system (SRS). Upon entering the self test, the restraint control module (RCM) will make an electrical check of each electrical component in the system. If a concern is detected, a DTC is displayed on the scan tool with a brief description of the DTC. Concerns detected during the self test are not stored in memory, unless the same concern was also detected during normal vehicle operation. The self test should always be run after any repair to verify that the repair was successful.

To run the On-Demand Self Test, connect the scan tool to the data link connector (DLC). Follow the instructions for the scan tool being used. The RCM will run the On-Demand Self Test and display on-demand DTCs (reflecting hard system concerns) on the screen.

PID/Data Monitor and Record

The PID/Data Monitor and Record option allows the scan tool operator to read the state of several parameter IDs (PIDs) to aid in diagnosing the system. PIDs are real time measurements of parameters such as voltages, resistances, etc., calculated by the restraints control module (RCM) and sent to the scan tool for display. Many of the PIDs supported by the RCM are calculated periodically and are, therefore, not true real time readings.

To retrieve PIDs, connect the scan tool to the data link connector (DLC). Follow the instructions for the scan tool being used. PIDs are updated continuously on the display.

Active Commands

This command allows the technician to verify operation of the air bag indicator and chime. When the air bag

output command is executed, the indicator and the chime are activated simultaneously for approximately four seconds. Both devices are deactivated automatically.

DTC ^a	LFC b	LFC Priority	Description	Action To Take
_	_	1	RCM Disconnected, Inoperative, or Lost/Low Ignition Feed	GO to Pinpoint Test A.
B1318	_	_	Ignition Voltage Below 9 Volts	CHECK battery voltage. REFER to Section 414-01.
B1342	24	2	RCM is Faulted	GO to Pinpoint Test B.
B1231	19	3	RCM Crash Data Memory Full	GO to Pinpoint Test C.
B1921	21	4	RCM Bracket Ground Resistance High	GO to Pinpoint Test D.
C1414	29	5	Incorrect Vehicle Identification Code	GO to Pinpoint Test E.
B1887	15	6	Driver Air Bag Circuit Shorted to Ground	GO to Pinpoint Test F.
B1916	15	7	Driver Air Bag Circuit Shorted to Battery or Ignition	GO to Pinpoint Test G.
B1888	16	8	Passenger Air Bag Circuit Shorted to Ground	GO to Pinpoint Test H.
B1925	16	9	Passenger Air Bag Circuit Shorted to Battery or Ignition	GO to Pinpoint Test I.
B1932	32	10	Driver Air Bag Circuit Resistance High	GO to Pinpoint Test J.
B1933	33	11	Passenger Air Bag Circuit Resistance High	GO to Pinpoint Test K.
B1934	34	12	Driver Air Bag Circuit Resistance Low	GO to Pinpoint Test L.
B1935	35	13	Passenger Air Bag Circuit Resistance Low	GO to Pinpoint Test M.
B1901	14	14	Front External Crash Sensor Shorted to Ground	GO to Pinpoint Test N.
B1941	41	15	Front External Crash Sensor Open Circuit or Short to Battery	GO to Pinpoint Test O.
B2444	48	16	Driver Side Crash Sensor is Faulted	GO to Pinpoint Test P.
B2445	49	17	Passenger Side Crash Sensor is Faulted	GO to Pinpoint Test Q.
B2441	42	18	Driver Side Crash Sensor Mounting Fault	GO to Pinpoint Test R.
B2440	43	19	Passenger Side Crash Sensor Mounting Fault	GO to Pinpoint Test S.
U2017	44	20	Driver Side Crash Sensor Communication Fault	GO to <u>Pinpoint Test T</u> .
U2018	45	21	Passenger Side Crash Sensor Communication Fault	GO to Pinpoint Test U.
B1993	36	22	Driver Side Air Bag Circuit Shorted to Ground	GO to Pinpoint Test V.
B1992	36	24	Driver Side Air Bag Circuit Shorted to Battery or Ignition	GO to Pinpoint Test W.
B1994	36	26	Driver Side Air Bag Circuit Resistance High	GO to Pinpoint Test X.

Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table

B1995	36	28	Driver Side Air Bag Circuit Resistance Low	GO to Pinpoint Test Y.
B1997	37	23	Passenger Side Air Bag Circuit Shorted to Ground	GO to <u>Pinpoint Test Z</u> .
B1996	37	25	Passenger Side Air Bag Circuit Shorted to Battery or Ignition	GO to <u>Pinpoint Test AA</u> .
B1998	37	27	Passenger Side Air Bag Circuit Resistance High	GO to <u>Pinpoint Test AB</u> .
B1999	37	29	Passenger Side Air Bag Circuit Resistance Low	GO to <u>Pinpoint Test AC</u> .
B1892	—	30	Air Bag Tone Warning Indicator Circuit Shorted to Ground or Open	GO to <u>Pinpoint Test AD</u> .
B1891	_	31	Air Bag Tone Warning Indicator Circuit Shorted to Battery or Ignition	GO to <u>Pinpoint Test AE</u> .
B1869	Tone c	32	Air Bag Indicator Inoperative	GO to <u>Pinpoint Test AF</u> .
B1870	Tone c	33	Air Bag Indicator Shorted to Battery	GO to <u>Pinpoint Test AG</u> .
—		—	No Communication With the Restraints Control Module (RCM)	GO to Pinpoint Test AH.

^a DTC: Diagnostic trouble code, retrieved using scan tool.

^b LFC: Lamp fault code, flashed on air bag indicator.

^c Tone will sound only if additional DTCs are present.

Inspection and Verification

- 1. Verify the customer concern by checking the air bag indicator in the instrument cluster. Refer to Prove Out the System in this section.
- 2. Visually inspect for obvious signs of mechanical and electrical damage using the following chart.

Visual Inspection Chart

Mechanical	Electrical
 Damaged restraints control module (RCM) bracket Damaged front external crash sensor bracket 	 Open fuse(s) Damaged wiring harness Loose or corroded connectors Circuitry open/shorted Damaged shorting bars

3. If the concern is not visually evident, use the scan tool to retrieve diagnostic trouble codes (DTCs) and carry out the on-demand self test.

4. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag

system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

If the on-demand self test is passed and no DTCs are retrieved, proceed to the symptom chart.

5. If DTCs are retrieved, refer to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table.

Symptom Chart

Symptom Chart

Condition	Possible Sources	Action
 Air bag warning indicator is illuminated continuously 	 Ignition circuits. Ground circuits. RCM. Connector shorting bar. RCM camming beam. RCM disconnected. Other circuitry. Instrument cluster. 	• GO to <u>Pinpoint</u> <u>Test A</u> .
 Air bag indicator flashing 	 Air bag SRS system fault. 	 REFER to DTC Priority Table.
 Audible tone — DTCs retrieved 	 Air bag SRS system fault. 	 GO to <u>Pinpoint</u> <u>Test AF</u>. GO to <u>Pinpoint</u> <u>Test AG</u>.
 No communication with the restraints control module (RCM) 	 Scan Tool. Data Link Connector (DLC). RCM. Circuitry. 	• GO to <u>Pinpoint</u> <u>Test AH</u> .

Pinpoint Tests — Air Bag Supplemental Restraint System (SRS)

Special Tool(s)

[ia:100]	73 Digital Multimeter 105-R0051 or Equivalent
ST1137-A	
ST2506-A	Front Air Bag Simulator (Restraint System Diagnostic Tool) 105-R0012 or Equivalent
ST2507-A	Side Air Bag Simulator (Restraint System Diagnostic Tool) 418-133 or Equivalent
5T2332-A	Worldwide Diagnostic System 418-F224, New Generation STAR (NGS) Tester 418-F048, or equivalent scan tool

Restraint System Diagnostic Tool Warning

WARNING: This tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Pinpoint Test A: Air Bag Warning Indicator Is Illuminated Continuously — RCM Disconnected, Inoperative or Lost/Low Ignition Feed

Normal Operation

NOTE: During normal operation the air bag indicator will be lit continuously for 6 seconds after the ignition switch is placed in the RUN position and after five cycles of a lamp fault code (LFC) if a fault exists. Be sure to cycle the ignition switch and look for a 6 second indicator prove-out without LFCs.

The restraints control module (RCM) will communicate diagnostic trouble codes (DTCs) to the scan tool through the data link connector (DLC). If the scan tool displays NO COMMUNICATION when retrieving continuous DTCs, use Pinpoint Test AH to troubleshoot the system.

Possible Causes

An air bag indicator that is illuminated continuously can be caused by one of the following:

- the ignition circuit damaged.
- the RCM disconnected from the vehicle harness.
- a loss of RCM ground.
- the RCM inoperative.
- other circuitry.
- worn or damaged shorting bar or camming beam.

PINPOINT TEST A: AIR BAG WARNING INDICATOR IS ILLUMINATED CONTINUOUSLY — RCM DISCONNECTED, INOPERATIVE OR LOST/LOW IGNITION FEED





	Inspect C232 harness side for worn, damaged, or dislodged shorting bar at pins 20 and 21. Inspect for foreign material.
DR1541-A	
	Were any connector concerns found?
	$\xrightarrow{\rightarrow}$ Yes CORRECT connector concerns. GO to <u>A7</u> .
	\rightarrow No GO to <u>A4</u> .
A4 CHECK THE IGNITION CIRCUIT 364 (BK/LG)	FOR AN OPEN
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible
NOTE: If a seat equipped with a seat mounted side a must be deactivated per the deactivation procedure car/truck service manual.	airbag system is being serviced the airbag system contained in <u>Section 501-20B</u> of the appropriate
NOTE: Airbag simulators (restraint system diagnostic side airbag to floor connector.	c tools) MUST be installed under the seats in the
NOTE: Diagnostics or repairs are not to be performe vehicle. Prior to attempting to diagnose/repair the sic the vehicle and the restraint system diagnostic tool n floor connector. The restraint system diagnostic tool	d on a side airbag system with the seat in the le airbag system the seat must be removed from nust be installed in side airbag connector at the must be removed prior to operating the vehicle.
NOTE: Diagnostics may be performed on seat syste climate controlled, heated, power seat track) with the restraint system diagnostic tool is installed under the	ms other than the side airbag system (lumbar, e seat installed in the vehicle as long as the seat in the side airbag to floor connector.
NOTE: After diagnosing/repairing a seat system the before operating the vehicle.	restraint system diagnostic tool must be removed
	1 Deactivate the system.
2	
3	Measure the voltage between RCM C232 pin 2, circuit 364 (BK/LG), harness side and ground.



2 RCM C232 3	Measure the resistance to ground at instrument cluster C288 pin 4, circuit 608 (BK/YE), harness side.
	 Is the resistance less than 10,000 ohms?
	Yes REPAIR the circuit. GO to <u>A7</u> .
	\rightarrow No INSTALL a new RCM. GO to <u>A7</u> .
A7 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible
	1 Refer to the continuous DTCs recorded during Step A1.
	 Were any continuous DTCs retrieved during Step A1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test B: LFC 24/DTC B1342 — RCM Is Faulted

Normal Operation

The restraints control module (RCM) monitors the backup power supply, accelerometer operation and memory. If the RCM detects a fault in any of these components, it will store a diagnostic trouble code (DTC) B1342 in memory and flash a lamp fault code (LFC) 24 on the air bag indicator.

Possible Causes

An RCM fault can be caused by:

- the backup power supply not operating correctly.
- an internal module circuit fault detected.
- a microcontroller RAM/ROM/EEPROM fault.

PINPOINT TEST B: LFC 24/DTC B1342 — RCM IS FAULTED



	cleared until it is corrected and the DTC is no longer retrieved during the on- demand self test. INSTALL a new RCM. GO to <u>B2</u> .
	→ No This is an intermittent fault. The fault condition is not present at this time. INSTALL a new RCM. GO to <u>B2</u> .
B2 CHECK FOR	ADDITIONAL DTCs
	1 Refer to the continuous DTCs recorded during Step B1.
	 Were any continuous DTCs retrieved during Step B1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No CLEAR all DTCs.

Pinpoint Test C: LFC 19/DTC B1231 — RCM Crash Data Memory Full

Normal Operation

WARNING: The restraints control module (RCM) orientation is critical for correct system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) has been involved in a collision in which the right cowl A-pillar area has been damaged, inspect the mounting and bracket for deformation. If damaged, the RCM must be replaced whether or not the air bags have deployed. In addition, make sure the area of the RCM mounting is restored to its original condition.

WARNING: A new RCM must be installed if the air bag modules have deployed.

WARNING: Clearing DTC B1231 will potentially remove all record of the crash event.

When the air bags are deployed during a collision, the restraints control module (RCM) will flash a lamp fault code (LFC) 19 on the air bag indicator and store a diagnostic trouble code (DTC) B1231 in memory. The LFC 19 and DTC B1231 indicate that a crash has been recorded by the RCM.

Possible Causes

Crash data memory full is caused by a crash event that deployed the air bags.

PINPOINT TEST C: LFC 19/DTC B1231 — RCM CRASH DATA MEMORY FULL

CONDITIONS	DETAILS/RESULTS/ACTIONS	
C1 CHECK FOR	A HARD OR INTERMITTENT DTC	
1		



C3 CHECK FOR ADDITIONAL DTCs	
	1 Refer to the continuous DTCs recorded during Step C1.
	 Were any continuous DTCs retrieved during Step C1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	\rightarrow No CLEAR all DTCs.

Pinpoint Test D: LFC 21/DTC B1921 — RCM Bracket Ground Resistance High

Normal Operation

WARNING: The tightening torque of the restraints control module (RCM) retaining bolts is critical for correct air bag supplemental restraint system (SRS) operation. Refer to <u>Module</u> <u>Restraints Control</u> in this section for correct torque values.

The restraints control module (RCM) monitors the resistance between the ground connections at its housing and the reference ground at pin 21. If the RCM detects a resistance greater than 100 ohms, it will store a diagnostic trouble code (DTC) B1921 in memory and flash a lamp fault code (LFC) 21 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

High resistance between the RCM housing ground and pin ground can be caused by:

- incorrect seating of the RCM retaining bolts.
- incorrect tightening torque of the RCM retaining bolts.
- high resistance on RCM logic ground circuit 649 (BK/OG).

PINPOINT TEST D: LFC 21/DTC B1921 — RCM BRACKET GROUND RESISTANCE HIGH

D1 CHECK FOR A HARD OR INTERMITTENT DTC	CONDITIONS	DETAILS/RESULTS/ACTIONS
	D1 CHECK FOR A HARD OR INTERMITTENT D	тс

Scan Tool	
4	A Retrieve and record any continuous DTCs for use later in this pinpoint test.
Retrieve/Clear Continuous DTCs	
On-Demand Self Test	
	 Was DTC B1921 retrieved during the on- demand self test?
	→ Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>D2</u> .
	→ No This is an intermittent fault. The fault condition is not present at this time. GO to <u>D6</u> .
D2 INSPECT THE RCM MOUNTING, MOUNTING	G BRACKET AND MOUNTING SURFACE
	1 Remove the RCM. Refer to <u>Module—</u> <u>Restraints Control</u> in this section.
	2 Visually inspect the RCM, mounting bracket and mounting surface for damage, corrosion or dirt.
	3 Inspect the RCM mounting and make sure that the retaining bolts are fully seated and tightened correctly. Refer to <u>Module—</u> <u>Restraints Control</u> in this section for correct tightening torque.
	• Was a significant amount of corrosion or dirt found, the RCM mounting bracket attached to the mounting surface incorrectly or the three RCM retaining bolts not fully seated and tightened correctly?
	→ Yes MAKE SURE the RCM, mounting bracket and

	mounting surface are free of damage, corrosion or dirt, and the three retaining bolts are fully seated and correctly tightened. REATTACH the RCM and mounting bracket to the mounting surface. GO to <u>D7</u> .
	\rightarrow No GO to D3.
D3 CHECK THE RCM HARNESS CONNECTION	
	 Inspect the RCM harness pins and check the RCM harness connection.
	 Are the RCM harness pins OK and are the RCM harness connectors connected to the RCM correctly with the red locking clips engaged?
	→ Yes GO to <u>D4</u> .
	→ No ATTACH the RCM harness connectors correctly. GO to <u>D7</u> .
D4 CHECK THE VEHICLE CHASSIS GROUND	
	1 Measure the resistance between a known good chassis ground and the mounting surface of the RCM.
	Is the resistance greater than 100 ohms?
	$\xrightarrow{\rightarrow}$ Yes REPAIR the chassis grounding system. GO to <u>D7</u> .
	$\rightarrow $ No GO to <u>D5</u> .
D5 CHECK THE GROUND CIRCUIT 649 (BK/OG) FOR AN OPEN
RCM C232	
3	3 Measure the resistance between RCM C232 pin 21, circuit 649 (BK/OG), harness side and a sheet metal ground near the RCM.

DR0995-A =	
	Is the resistance greater than 100 ohms?
	$\xrightarrow{\rightarrow}$ Yes REPAIR the circuit. GO to <u>D7</u> .
	\rightarrow No GO to <u>D7</u> .
D6 CHECK FOR AN INTERMITTENT FAULT	
	1 Refer to the continuous DTCs recorded during Step D1.
	 Was the continuous DTC retrieved during Step D1 an intermittent fault?
	→ Yes CHECK for causes of intermittent high resistance on circuit 649 (BK/OG). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to D7.
	$\rightarrow \text{No}$ GO to D7.
D7 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	1 Refer to the continuous DTCs recorded during Step D1.
	 Were any continuous DTCs retrieved during Step D1
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC)

Priority Table in this section for pinpoint test direction.
→ No RECONNECT the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test E: LFC 29/DTC C1414 — Incorrect Vehicle Identification Code

Normal Operation

The restraints control module (RCM) monitors the voltage at pins 10, 13 and 14 to determine if it is installed on the correct vehicle. If the RCM detects an unexpected condition at any of these pins, it will store a diagnostic trouble code (DTC) C1414 in memory and flash a lamp fault code (LFC) 29 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

An incorrect vehicle identification code can be caused by:

- an RCM installed on the wrong vehicle.
- an incorrectly programmed RCM.
- a wiring concern at RCM C2 pins 10, 13 or 14.

PINPOINT TEST E: LFC 29/DTC C1414 — INCORRECT VEHICLE IDENTIFICATION CODE

CONDITIONS	DETAILS/RESULTS/ACTIONS
E1 CHECK FOR A HARD OR INTERMITTENT D	тс
1	
Scan Tool	
	4 Retrieve and record any continuous DTCs for use later in this pinpoint test.
Retrieve/Clear Continuous DTCs	





	 Was the continuous DTC retrieved during Step E1 an intermittent fault?
	→ Yes CHECK for causes of an intermittent open on circuit 364 (BK/LG). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>E6</u> .
	\rightarrow No GO to <u>E6</u> .
E6 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	1 Refer to the continuous DTCs recorded during Step E1.
	 Were any continuous DTCs retrieved during Step E1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test F: LFC 15/DTC B1887 — Driver Air Bag Circuit Shorted to Ground

Normal Operation

The restraints control module (RCM) checks for driver air bag circuit shorts to ground by monitoring the voltage of circuits 614 (GY/OG) and 615 (GY/WH) at pins 3 and 4. If the RCM detects a short to ground on either of these pins, it will store a diagnostic trouble code (DTC) B1887 in memory and flash a lamp fault code (LFC) 15 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

A driver air bag circuit short to ground can be caused by:

- a short to ground on circuit 614 (GY/OG).
- a short to ground on circuit 615 (GY/WH).
- a short to ground on the air bag sliding contact (14A664) .
- a short to ground on the driver air bag module.

CONDITIONS	DETAILS/RESULTS/ACTIONS
F1 CHECK FOR A HARD OR INTERMITTENT D	rc
Scan Tool	
4 Detrious (Clear Continuous DTCo	4 Retrieve and record any continuous DTCs for use later in this pinpoint test.
On-Demand Self Test	
	 Was DTC B1887 retrieved during the on- demand self test?
	 → Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to F2. → No This is an intermittent fault. The fault condition is not present at this time. GO to F5.
F2 CHECK THE DRIVER AIR BAG MODULE	
WARNING: The restraint system diagnosti	c tool is for restraint system service only

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system

must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.





	 Was the continuous DTC retrieved during Step F1 an intermittent fault? → Yes CHECK for causes of intermittent short to ground on circuit 614 (GY/OG), circuit 615 (GY/WH), and the air bag sliding contact assembly. ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to F6.
	→ No GO to <u>F6</u> .
F6 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	1 Refer to the continuous DTCs recorded during Step F1.
	 Were any continuous DTCs retrieved during Step F1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test G: LFC 15/DTC B1916 — Driver Air Bag Circuit Shorted to Battery or Ignition

Normal Operation

The restraints control module (RCM) checks for driver air bag circuit shorts to battery or ignition by monitoring the voltage of circuit 614 (GY/OG) and 615 (GY/WH) at pins 3 and 4. If the RCM detects a short to battery or ignition on either of these pins, it will store a diagnostic trouble code (DTC) B1916 in memory and flash a lamp fault code (LFC) 15 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

A driver air bag circuit short to battery or ignition can be caused by:

- a short to battery or ignition on circuit 614 (GY/OG).
- a short to battery or ignition on circuit 615 (GY/WH).

- a short to battery or ignition on the air bag sliding contact.
- a short to battery or ignition on the driver air bag module.

PINPOINT TEST G: LFC 15/DTC B1916 — DRIVER AIR BAG CIRCUIT SHORTED TO BATTERY OR IGNITION

CONDITIONS	DETAILS/RESULTS/ACTIONS
G1 CHECK FOR A HARD OR INTERMITTENT D	тс
Scan Tool	
	A Retrieve and record any continuous DTCs for use later in this pinpoint test.
On-Demand Self Test	
	 Was DTC B1916 retrieved during the on- demand self test?
	 → Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to G2. → No This is an intermittent fault. The fault condition is not prepent at this time. CO to C5
	is not present at this time. GO to Go.
GZ CHECK THE DRIVER AIR BAG MODULE	
1	

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.





	 the air bag sliding contact connector C271. Check for pinched wires and damaged connector pin terminals. Was any damage found?
	\rightarrow Yes REPAIR as necessary. GO to <u>G6</u> .
	\rightarrow No GO to <u>G6</u> .
G5 CHECK FOR AN INTERMITTENT FAULT	
	1 Refer to the continuous DTCs recorded during Step G1.
	 Was the continuous DTC retrieved during Step G1 an intermittent fault?
	→ Yes CHECK for causes of intermittent short to battery or ignition on circuit 614 (GY/OG), circuit 615 (GY/WH), and the air bag sliding contact assembly. ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>G6</u> .
	\rightarrow No GO to <u>G6</u> .
G6 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	1 Refer to the continuous DTCs recorded during Step G1.
	 Were any continuous DTCs retrieved during Step G1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test H: LFC 16/DTC B1888 — Passenger Air Bag Circuit Shorted to Ground

Normal Operation

The restraints control module (RCM) checks for passenger air bag circuit shorts to ground by monitoring the voltage of circuits 607 (LB/OG) and 616 (PK/BK) at pins 6 and 7. If the RCM detects a short to ground on either of these pins, it will store a diagnostic trouble code (DTC) B1888 in memory and flash a lamp fault code (LFC) 16 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

A passenger air bag circuit short to ground can be caused by:

- a short to ground on circuit 607 (LB/OG).
- a short to ground on circuit 616 (PK/BK).
- a short to ground on the passenger air bag module.
- an RCM internal concern.



PINPOINT TEST H: LFC 16/DTC B1888 — PASSENGER AIR BAG CIRCUIT SHORTED TO GROUND




	→ Yes REPAIR as necessary. GO to <u>H6</u> .	
	→ No GO to <u>H6</u> .	
H5 CHECK FOR AN INTERMITTENT FAULT		
	 Refer to the continuous DTCs recorded during Step H1. 	
	 Was the DTC retrieved during Step H1 an intermittent fault? 	
	→ Yes CHECK for causes of intermittent short to ground on circuit 607 (LB/OG) and circuit 616 (PK/BK). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>H6</u> .	
	→ No GO to <u>H6</u> .	
H6 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	Refer to the continuous DTCs recorded during Step H1.	
	 Were any continuous DTCs retrieved during Step H1? 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.	

Pinpoint Test I: LFC 16/DTC B1925 — Passenger Air Bag Circuit Shorted to Battery or Ignition

Normal Operation

The restraints control module (RCM) checks for passenger air bag circuit shorts to battery or ignition by monitoring the voltage of circuits 607 (LB/OG) and 616 (PK/BK) at pins 6 and 7. If the RCM detects a short

to battery or ignition on either of these pins, it will store a diagnostic trouble code (DTC) B1925 in memory and flash a lamp fault code (LFC) 16 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

A passenger air bag circuit short to battery or ignition can be caused by:

- a short to battery or ignition on circuit 607 (LB/OG).
- a short to battery or ignition on circuit 616 (PK/BK).
- a short to battery or ignition on the passenger air bag module.
- an RCM internal concern.

PINPOINT TEST I: LFC 16/DTC B1925 — PASSENGER AIR BAG CIRCUIT SHORTED TO BATTERY OR IGNITION

CONDITIONS	DETAILS/RESULTS/ACTIONS
I1 CHECK FOR A HARD OR INTERMITTENT DT	c
Scan Tool	
	Retrieve and record any continuous DTCs for use later in this pinpoint test.
Retrieve/Clear Continuous DTCs	
On-Demand Self Test	
	 Was DTC B1925 retrieved during the on- demand self test?
	Yes This is a hard fault. The fault condition is still

present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>12</u>.

 \rightarrow No

This is an intermittent fault. The fault condition is not present at this time. GO to <u>15</u>.

12 CHECK THE PASSENGER AIR BAG MODULE

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.





	RCM pin 6, circuit 616 (PK/BK) feeding pin 7. Check for pinched wires and damaged connector pin terminals.	
	• Was any damage found?	
	→ Yes REPAIR as necessary. GO to <u>I6</u> .	
	$ \stackrel{\rightarrow}{\underset{\text{GO to } \underline{I6}}{\longrightarrow} } No $	
I5 CHECK FOR AN INTERMITTENT FAULT		
	1 Refer to the continuous DTCs recorded during Step I1.	
	 Was the DTC retrieved during Step I1 an intermittent fault? 	
	→ Yes CHECK for causes of intermittent short to battery or ignition on circuit 607 (LB/OG) and circuit 616 (PK/BK). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>16</u> .	
	→ No GO to <u>I6</u> .	
I6 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	 Refer to the continuous DTCs recorded during Step I1. 	
	 Were any continuous DTCs retrieved during Step I1? 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.	

Pinpoint Test J: LFC 32/DTC B1932 — Driver Air Bag Circuit Resistance High

Normal Operation

The restraints control module (RCM) monitors the resistance for the driver air bag ignitor by measuring the resistance between pins 3 and 4. If the RCM detects high resistance between these pins, it will store a diagnostic trouble code (DTC) B1932 in memory and flash a lamp fault code (LFC) 32 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

Driver air bag high resistance can be caused by:

- a poor connection or corrosion in the driver air bag module circuits or the air bag sliding contact.
- an open circuit or high resistance in the air bag sliding contact windings.
- an open circuit or high resistance in the wiring harness.
- an open circuit or high resistance in the driver air bag module.
- an RCM internal concern.

PINPOINT TEST J: LFC 32/DTC B1932 — DRIVER AIR BAG CIRCUIT RESISTANCE HIGH







	 NOTE: By disconnecting the air bag sliding contact connector, the connector pins are shorted together with a shorting bar. Do not remove the shorting bar. NOTE: Zero the multimeter prior to taking the measurement 	
DR0292-В	Measure the resistance between air bag sliding contact C271, circuit 614 (GY/OG), harness side and air bag sliding contact C271, circuit 615 (GY/WH), harness side.	
	Is the resistance greater than 0.5 ohm?	
	$\xrightarrow{\rightarrow}$ Yes INSTALL a new air bag sliding contact. GO to <u>J6</u> .	
	\rightarrow No REPAIR the circuit(s) as necessary. GO to <u>J6</u> .	
J5 CHECK FOR AN INTERMITTENT FAULT		
	1 Refer to the continuous DTCs recorded during Step J1.	
	 Was the continuous DTC retrieved during Step J1 an intermittent fault? 	
	→ Yes CHECK for causes of intermittent high resistance on circuit 614 (GY/OG), circuit 615 (GY/WH), and the air bag sliding contact assembly. ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>J6</u> .	
	→ No GO to <u>J6</u> .	
J6 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	1 Refer to the continuous DTCs recorded during Step J1.	
	 Were any continuous DTCs retrieved during Step J1? 	
	ightarrow Yes	

Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test K: LFC 33/DTC B1933 — Passenger Air Bag Circuit Resistance High

Normal Operation

The restraints control module (RCM) monitors the resistance of the passenger air bag ignitor by measuring the resistance between pins 6 and 7. If the RCM detects high resistance between these pins, it will store a diagnostic trouble code (DTC) B1933 in memory and flash a lamp fault code (LFC) 33 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

A passenger air bag high resistance can be caused by:

- a poor connection or corrosion in the passenger air bag module circuits.
- an open circuit or high resistance in the wiring harness.
- an open circuit or high resistance in the passenger air bag module.
- an RCM internal concern.

PINPOINT TEST K: LFC 33/DTC B1933 — PASSENGER AIR BAG CIRCUIT RESISTANCE HIGH

CONDITIONS	DETAILS/RESULTS/ACTIONS
K1 CHECK FOR A HARD OR INTERMITTENT DT	C
Scan Tool	
4	A Retrieve and record any continuous DTCs for

	use later in this pinpoint test.	
Retrieve/Clear Continuous DTCs		
On-Demand Self Test		
	 Was DTC B1933 retrieved during the on- demand self test? 	
	→ Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>K2</u> .	
	→ No This is an intermittent fault. The fault condition is not present at this time. GO to <u>K4</u> .	
K2 CHECK THE PASSENGER AIR BAG MODULI	Ξ	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in Section 501-208 of the appropriate		
car/truck service manual. NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.		
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.		
NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.		
NOTE: After diagnosing/repairing a seat system the before operating the vehicle.	restraint system diagnostic tool must be removed	
	2 Deactivate the system.	
3		



	→ Yes REPAIR the circuit(s) as necessary. GO to <u>K5</u> .	
	→ No INSTALL a new RCM. GO to <u>K5</u> .	
K4 CHECK FOR AN INTERMITTENT FAULT		
	 Refer to the continuous DTCs recorded during Step K1. 	
	 Was the continuous DTC retrieved during Step K1 an intermittent fault? 	
	→ Yes CHECK for causes of intermittent high resistance on circuit 607 (LB/OG) and circuit 616 (PK/BK). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>K5</u> .	
	\rightarrow No GO to <u>K5</u> .	
K5 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	 Refer to the continuous DTCs recorded during Step K1. 	
	 Were any continuous DTCs retrieved during Step K1? 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.	

Pinpoint Test L: LFC 34/DTC B1934 — Driver Air Bag Circuit Resistance Low

Normal Operation

The restraints control module (RCM) monitors the resistance of the driver air bag ignitor by measuring the resistance between pins 3 and 4. If the RCM detects low resistance between these pins, it will store a

diagnostic trouble code (DTC) B1934 in memory and flash a lamp fault code (LFC) 34 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

Driver air bag low resistance can be caused by:

- a short in the air bag sliding contact windings.
- a short in the wiring harness.
- a low resistance in the driver air bag module.
- an RCM internal concern.
- a worn or damaged connector shorting bar (harness side).
- a worn or damaged connector camming beam (component side).

PINPOINT TEST L: LFC 34/DTC B1934 — DRIVER AIR BAG CIRCUIT RESISTANCE LOW

CONDITIONS	DETAILS/RESULTS/ACTIONS
L1 CHECK FOR A HARD OR INTERMITTENT DT	TC
Scan Tool	
	A Retrieve and record any continuous DTCs for use later in this pinpoint test.
S	
On-Demand Self Test	 Was DTC B1934 retrieved during the on- demand self test?





DR0292-B	
	 Is the resistance greater than 10,000 ohms?
	Yes INSTALL a new air bag sliding contact. GO to <u>L6</u> .
	No REPAIR the circuit(s) as necessary. GO to <u>L6</u> .
L5 CHECK FOR AN INTERMITTENT FAULT	
	1 Refer to the continuous DTCs recorded during Step L1.
	 Was the DTC retrieved during Step L1 an intermittent fault?
	→ Yes CHECK for causes of intermittent low resistance on circuit 614 (GY/OG), circuit 615 (GY/WH), and the air bag sliding contact assembly. ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>L6</u> .
	\rightarrow No GO to <u>L6</u> .
L6 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	1 Refer to the continuous DTCs recorded during Step L1.
	 Were any continuous DTCs retrieved during Step L1?
	ightarrow Yes

Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test M: LFC 35/DTC B1935 — Passenger Air Bag Circuit Resistance Low

Normal Operation

The restraints control module (RCM) monitors the resistance of the passenger air bag ignitor by measuring the resistance between pins 6 and 7. If the RCM detects low resistance between these pins, it will store a diagnostic trouble code (DTC) B1935 in memory and flash a lamp fault code (LFC) 35 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

Passenger air bag low resistance can be caused by:

- a short in the wiring harness.
- a low resistance in the passenger air bag module.
- an RCM internal concern.
- a worn or damaged shorting bar.
- a worn or damaged connector camming beam (component side).

PINPOINT TEST M: LFC 35/DTC B1935 — PASSENGER AIR BAG CIRCUIT RESISTANCE LOW

CONDITIONS	DETAILS/RESULTS/ACTIONS
M1 CHECK FOR A HARD OR INTERMITTENT D	ſĊ
Scan Tool	

A Retrieve/Clear Continuous DTCs S On-Demand Self Test	4 Retrieve and record any continuous DTCs for use later in this pinpoint test.
	 Was DTC B1935 retrieved during the on-demand self test?
	→ Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>M2</u> .
	→ No This is an intermittent fault. The fault condition is not present at this time. GO to <u>M4</u> .
M2 CHECK THE PASSENGER AIR BAG MODUL	E
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards. NOTE: If a seat equipped with a seat mounted side	tool is for restraint system service only. o remove could result in injury and possible airbag system is being serviced the airbag system
must be deactivated per the deactivation procedure car/truck service manual.	contained in Section 501-20B of the appropriate
NOTE: Airbag simulators (restraint system diagnost side airbag to floor connector.	ic tools) MUST be installed under the seats in the
NOTE: Diagnostics or repairs are not to be performed vehicle. Prior to attempting to diagnose/repair the si the vehicle and the restraint system diagnostic tool r floor connector. The restraint system diagnostic tool	ed on a side airbag system with the seat in the de airbag system the seat must be removed from must be installed in side airbag connector at the must be removed prior to operating the vehicle.
NOTE: Diagnostics may be performed on seat systeclimate controlled, heated, power seat track) with the restraint system diagnostic tool is installed under the	ems other than the side airbag system (lumbar, e seat installed in the vehicle as long as the e seat in the side airbag to floor connector.
NOTE: After diagnosing/repairing a seat system the before operating the vehicle.	restraint system diagnostic tool must be removed
1	2 Deactivate the system.



M4 CHECK FOR AN INTERMITTENT FAULT	
	1 Refer to the continuous DTCs recorded during Step M1.
	 Was the DTC retrieved during Step M1 an intermittent fault?
	→ Yes CHECK for causes of intermittent low resistance on circuit 607 (LB/OG) and circuit 616 (PK/BK). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>M5</u> .
	→ No GO to <u>M5</u> .
M5 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	 Refer to the continuous DTCs recorded during Step M1.
	 Were any continuous DTCs retrieved during Step M1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test N: LFC 14/DTC B1901 — Front External Crash Sensor Shorted To Ground

Normal Operation

The front external crash sensors monitor the severity of a crash event. If the crash event is severe enough, the sensor(s) will close and signal the restraints control module (RCM) to deploy the air bags. Each front external crash sensor contains a 1580 ohm resistor. The two crash sensors are connected in parallel at the splice in circuit 619 (PK/WH). Because of the parallel connection, the RCM normally measures about 790 ohms to ground on circuit 619 (PK/WH).

The RCM measures this resistance to verify that the crash sensors are correctly mounted and connected. If there is a short to ground on circuit 619 (PK/WH), the RCM will store diagnostic trouble code (DTC) B1901

in memory. The RCM will also flash lamp fault code (LFC) 14 (or higher priority code if one exists) on the air bag indicator.

Possible Causes

A front external crash sensor shorted to ground fault can be caused by:

- a short to ground on circuit 619 (PK/WH).
- a damaged or inoperative front external crash sensor.
- an RCM internal concern.

PINPOINT TEST N: LFC 14/DTC B1901 — FRONT EXTERNAL CRASH SENSOR SHORTED TO GROUND



corrected and the DTC is no longer retrieved during the on-demand self test. GO to N2. \rightarrow No This is an intermittent fault. The fault condition is not present at this time. GO to N5. N2 CHECK CIRCUIT 619 (PK/WH) WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. **NOTE:** If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in Section 501-20B of the appropriate car/truck service manual. NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector. NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle. NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector. **NOTE:** After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle. 1 Deactivate the system. 3 **RCM C232** 4 4 Measure the resistance between RCM C232 pin 25, circuit 619 (PK/WH), harness side and RCM C232 pin 21, circuit 649 (BK/OG), harness side. DR1001-A Is the resistance between 690 and 890 ohms?



DROB03-A	
	 Is the resistance between 1530 and 1630 ohms?
	→ Yes REPAIR circuit 619 (PK/WH). GO to <u>N6</u> .
	→ No INSTALL a new LH front external crash sensor. GO to <u>N6</u> .
N5 CHECK FOR AN INTERMITTENT FAULT	
	 Refer to the continuous DTCs recorded during Step N1 .
	 Was the continuous DTC retrieved during Step N1 an intermittent fault?
	→ Yes CHECK for causes of intermittent short to ground on circuit 619 (PK/WH). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>N6</u> .
	→ No GO to <u>N6</u> .
N6 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible
	1 Refer to the continuous DTCs recorded during Step N1.
	 Were any continuous DTCs retrieved during Step N1?
	→ Yes Do not clear any DTCs until all DTCs have

been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test O: LFC 41/DTC B1941 — Front External Crash Sensor Open Circuit or Short to Battery

Normal Operation

The front external crash sensors monitor the severity of a crash event. If the crash event is severe enough, the sensor(s) will close and signal the restraints control module (RCM) to deploy the air bags. Each front external crash sensor contains a 1590 ohm resistor. Since the two crash sensors are connected in parallel through the splice in circuit 619 (PK/WH), the RCM normally measures about 790 ohms.

The RCM measures this resistance to verify that the crash sensors are correctly mounted and connected. If there is a short to battery or an open on circuit 619 (PK/WH), the RCM will store a diagnostic trouble code (DTC) B1941 in memory and flash a lamp fault code (LFC) 41 (or higher priority code is one exists) on the air bag indicator.

Possible Causes

A front external crash sensor open circuit or short to battery fault can be caused by:

- damaged wiring on circuit 619 (PK/WH).
- damaged front external crash sensor.
- a short to battery on circuit 619 (PK/WH).
- an RCM internal concern.

PINPOINT TEST O: LFC 41/DTC B1941 — FRONT EXTERNAL CRASH SENSOR OPEN CIRCUIT OR SHORT TO BATTERY

CONDITIONS	DETAILS/RESULTS/ACTIONS
01 CHECK FOR A HARD OR INTERMITTENT DT	C
1	
Scan Tool	
3	

A Retrieve/Clear Continuous DTCs	4 Retrieve and record any continuous DTCs for use later in this pinpoint test.
On-Demand Self Test	
	 Was DTC B1941 retrieved during the on-demand self test?
	→ Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>O2</u> .
	\rightarrow No This is an intermittent fault. The fault condition is not present at this time. GO to O6.
O2 CHECK FOR BATTERY ON CIRCUIT 619 (PK	/WH)
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. remove could result in injury and possible
NOTE: If a seat equipped with a seat mounted side must be deactivated per the deactivation procedure car/truck service manual.	airbag system is being serviced the airbag system contained in <u>Section 501-20B</u> of the appropriate
NOTE: Airbag simulators (restraint system diagnost side airbag to floor connector.	ic tools) MUST be installed under the seats in the
NOTE: Diagnostics or repairs are not to be performed vehicle. Prior to attempting to diagnose/repair the sit the vehicle and the restraint system diagnostic tool r floor connector. The restraint system diagnostic tool	ed on a side airbag system with the seat in the de airbag system the seat must be removed from must be installed in side airbag connector at the must be removed prior to operating the vehicle.
NOTE: Diagnostics may be performed on seat systeclimate controlled, heated, power seat track) with the restraint system diagnostic tool is installed under the	ems other than the side airbag system (lumbar, e seat installed in the vehicle as long as the e seat in the side airbag to floor connector.
NOTE: After diagnosing/repairing a seat system the before operating the vehicle.	restraint system diagnostic tool must be removed
2	Deactivate the system.





Front External Crash Sensor C132	Measure the resistance between LH front external crash sensor C132, circuit 619 (PK/WH) component side and the rivet on the side of the LH front external crash sensor case.
	 Is the resistance between 1530 and 1630 ohms?
	→ Yes REPAIR circuit 619 (PK/WH). GO to <u>O6</u> .
	→ No INSTALL a new LH front external crash sensor. GO to <u>07</u> .
O6 CHECK FOR AN INTERMITTENT FAULT	
	1 Refer to the continuous DTCs recorded during Step O1.
	 Was the continuous DTC retrieved during Step O1 an intermittent fault?
	→ Yes CHECK for causes of intermittent high resistance or short to battery on circuit 619 (PK/WH). ATTEMPT to recreate the hard fault by flexing the wire harness an cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>O6</u> .
	\rightarrow No GO to <u>O7</u> .
07 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	1 Refer to the continuous DTCs recorded during Step O1.
	•

 Were any continuous DTCs retrieved during Step O1?
→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test P: LFC 48/DTC B2444 — Driver Side Crash Sensor Is Faulted

Normal Operation

The driver side crash sensor monitors the severity of a crash event. If the crash event is severe enough, the sensor will signal the restraints control module (RCM) to deploy the driver side air bag.

The RCM monitors the two-wire current loop to the driver side crash sensor for a signal that is out of the expected range. If the RCM detects a signal from the driver side crash sensor, indicating a fault, it will store diagnostic trouble code (DTC) B2444 and flash a lamp fault code (LFC) 48 (or a higher priority code if one exists) on the air bag indicator.

Possible Causes

A driver side crash sensor fault can be caused by:

• damaged driver side crash sensor.

PINPOINT TEST P: LFC 48/DTC B2444 — DRIVER SIDE CRASH SENSOR IS FAULTED





Pinpoint Test Q: LFC 49/DTC B2445 — Passenger Side Crash Sensor Is Faulted

Normal Operation

The passenger side crash sensor monitors the severity of a crash event. If the crash event is severe enough, the sensor will signal the restraints control module (RCM) to deploy the passenger side air bag.

The RCM monitors the two-wire current loop to the passenger side crash sensor for a signal that is out of the expected range. If the RCM detects a signal from the passenger side crash sensor, indicating a fault, it will store diagnostic trouble code (DTC) B2445 and flash a lamp fault code (LFC) 49 (or a higher priority

code if one exists) on the air bag indicator.

Possible Causes

A passenger side crash sensor fault can be caused by:

• damaged passenger side crash sensor.

PINPOINT TEST Q: LFC 49/DTC B2445 — PASSENGER SIDE CRASH SENSOR IS FAULTED



	→ No This is an intermittent fault. The fault condition is not present at this time. INSTALL a new passenger side crash sensor. GO to Q2.
Q2 CHECK FOR	ADDITIONAL DTCs
	I Refer to the continuous DTCs recorded during Step Q1.
	 Were any continuous DTCs retrieved during Step Q1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	\rightarrow No CLEAR all DTCs.

Pinpoint Test R: LFC 42/DTC B2441 — Driver Side Crash Sensor Mounting Fault

Normal Operation

The driver side crash sensor monitors the severity of a crash event. If the crash event is severe enough, the sensor will signal the restraints control module (RCM) to deploy the driver side air bag.

The RCM monitors the two-wire current loop to the driver side crash sensor for a signal that is out of the expected range. If the RCM detects a signal from the driver side crash sensor, indicating a sensor mounting fault, it will store diagnostic trouble code (DTC) B2441 and flash a lamp fault code (LFC) 42 (or a higher priority code if one exists) on the air bag indicator.

Possible Causes

A driver side crash sensor mounting fault can be caused by:

- damaged driver side crash sensor.
- corrosion or damage at the sensor mounting surface.

PINPOINT TEST R: LFC 42/DTC B2441 — DRIVER SIDE CRASH SENSOR MOUNTING FAULT




	Remove the driver side crash sensor. For additional information, refer to <u>Sensor—Side Crash</u> in this section.	
	Visually inspect the driver side crash sensor, mounting bracket and mounting surface for damage, corrosion or dirt.	
	Inspect the driver side crash sensor mounting and make sure that the retaining bolts are fully seated and tightened correctly. For additional information, refer to <u>Sensor—Side Crash</u> in this section for correct tightening torque.	
	 Was a significant amount of corrosion or dirt found, the driver side crash sensor mounting bracket attached to the mounting surface incorrectly, or the two driver side crash sensor retaining bolts not fully seated and tightened correctly? 	
	→ Yes MAKE SURE the driver side crash sensor, mounting bracket and mounting surface are free of damage, corrosion or dirt and the two retaining bolts are fully seated and correctly tightened. REATTACH the driver side crash sensor and mounting bracket to the mounting surface. GO to <u>R6</u> .	
	\rightarrow No GO to R3.	
R3 CHECK THE DRIVER SIDE CRASH SENSOR HARNESS CONNECTION		
	1 Check the driver side crash sensor harness.	
	 Is the driver side crash sensor harness connector connected to the driver side crash sensor correctly? 	
	\rightarrow Yes GO to <u>R4</u> .	
	\rightarrow No ATTACH the driver side crash sensor harness connector correctly. GO to <u>R6</u> .	
R4 CHECK THE	VEHICLE CHASSIS GROUND	
	Measure the resistance between a known good chassis ground and the mounting surface of the driver side crash sensor.	
	Is the resistance greater than 100 ohms?	
	$\xrightarrow{\rightarrow}$ Yes REPAIR the chassis grounding system. GO to <u>R6</u> .	
	\rightarrow No INSTALL a new driver side crash sensor. GO to <u>R6</u> .	
R5 CHECK FOR	AN INTERMITTENT FAULT	
<u>^</u>		
	The notice is the sector of the sector for a sector is the	

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system

must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

	1 Deactivate the system.	
	2 Refer to the continuous DTCs recorded during Step R1.	
	Was a continuous DTC retrieved during Step R1 an intermittent fault?	
	→ Yes CHECK for causes of an intermittent mounting fault. ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>R6</u> .	
	\rightarrow No GO to <u>R6</u> .	
R6 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	1 Refer to the continuous DTCs recorded during Step R1.	
	 Were any continuous DTCs retrieved during Step R1? 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	$\xrightarrow{\rightarrow}$ No RECONNECT the system. PROVE OUT the system. CLEAR all DTCs.	

Pinpoint Test S: LFC 43/DTC B2440 — Passenger Side Crash Sensor Mounting Fault

Normal Operation

The passenger side crash sensor monitors the severity of a crash event. If the crash event is severe enough, the sensor will signal the restraints control module (RCM) to deploy the passenger side air bag.

The RCM monitors the two-wire current loop to the passenger side crash sensor for a signal that is out of

the expected range. If the RCM detects a signal from the passenger side crash sensor, indicating a sensor mounting fault, it will store diagnostic trouble code (DTC) B2440 and flash a lamp fault code (LFC) 43 (or a higher priority code if one exists) on the air bag indicator.

Possible Causes

A passenger side crash sensor mounting fault can be caused by:

- damaged passenger side crash sensor.
- corrosion or damage at the sensor mounting surface.

PINPOINT TEST S: LFC 43/DTC B2440 — PASSENGER SIDE CRASH SENSOR MOUNTING FAULT



	demand self test. GO to <u>S2</u> .		
	No This is an intermittent fault. The fault condition is not present at this time. GO to <u>S5</u> .		
S2 CHECK THE	S2 CHECK THE MOUNTING OF THE PASSENGER SIDE CRASH SENSOR		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.			
NOTE: If a seat ed must be deactivate car/truck service n	IOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system nust be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate ar/truck service manual.		
NOTE: Airbag sim side airbag to floo	nulators (restraint system diagnostic tools) MUST be installed under the seats in the r connector.		
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.			
NOTE: Diagnostic climate controlled, restraint system d	NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.		
NOTE: After diagr before operating the	nosing/repairing a seat system the restraint system diagnostic tool must be removed he vehicle.		
	1 Deactivate the system.		
	Remove the passenger side crash sensor. For additional information, refer to <u>Sensor—Side Crash</u> in this section.		
	Image: Second		
	Inspect the passenger side crash sensor mounting and make sure that the retaining bolts are fully seated and tightened correctly. For additional information, refer to <u>Sensor—Side Crash</u> in this section for correct tightening torque.		
	• Was a significant amount of corrosion or dirt found, the passenger side crash sensor mounting bracket attached to the mounting surface correctly, or the two passenger side crash sensor retaining bolts not fully seated and tightened correctly?		
	 → Yes MAKE SURE the passenger side crash sensor, mounting bracket and mounting surface are free of damage, corrosion or dirt and the two retaining bolts are fully seated and properly tightened. REATTACH the passenger side crash sensor and mounting bracket to the mounting surface. GO to <u>S6</u>. → No 		
	GO to <u>S3</u> .		
S3 CHECK THE	PASSENGER SIDE CRASH SENSOR HARNESS CONNECTION		
	L Check the passenger side crash sensor harness connection.		

	 Is the passenger side crash sensor harness connector connected to the passenger side crash sensor correctly? 		
	$\xrightarrow{\rightarrow}$ Yes GO to <u>S4</u> .		
	\rightarrow No ATTACH the passenger side crash sensor harness connector correctly. GO to <u>S6</u> .		
S4 CHECK THE	VEHICLE CHASSIS GROUND		
	1 Measure the resistance between a known good chassis ground and the mounting surface of the passenger side crash sensor.		
	Is the resistance greater than 100 ohms?		
	\rightarrow Yes REPAIR the chassis grounding system. GO to <u>S6</u> .		
	$\xrightarrow{\rightarrow}$ No INSTALL a new passenger side crash sensor. GO to <u>S6</u> .		
S5 CHECK FOR	R AN INTERMITTENT FAULT		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.			
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.			
NOTE: Airbag sin side airbag to floc	NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.		
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.			
NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.			
NOTE: After diag before operating t	nosing/repairing a seat system the restraint system diagnostic tool must be removed the vehicle.		
	1 Deactivate the system.		
	2 Refer to the continuous DTCs recorded during Step S1.		
	 Was a continuous DTC retrieved during Step S1 an intermittent fault? 		
	→ Yes CHECK for causes of an intermittent mounting fault. ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>S6</u> .		

	\rightarrow No GO to <u>S6</u> .
S6 CHECK FOR	ADDITIONAL DTCs
WARNING: Remove from vel violation of vehic	The restraint system diagnostic tool is for restraint system service only. hicle prior to road use. Failure to remove could result in injury and possible cle safety standards.
	1 Refer to the continuous DTCs recorded during Step S1.
	 Were any continuous DTCs retrieved during Step S1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	No RECONNECT the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test T: LFC 44/DTC U2017 — Driver Side Crash Sensor Communication Fault

Normal Operation

The driver side crash sensor monitors the severity of a crash event. If the crash event is severe enough, the sensor will signal the restraints control module (RCM) to deploy the driver side air bag.

The RCM monitors the two-wire current loop to the driver side crash sensor for a signal that is out of the expected range. If the RCM detects an out-of-range signal from the driver side crash sensor, indicating a sensor communication fault, it will store diagnostic trouble code (DTC) U2017 and flash a lamp fault code (LFC) 44 (or a higher priority code if one exists) on the air bag indicator.

Possible Causes

A driver side crash sensor communication fault condition can be caused by:

- damaged wiring on circuit 1261 (WH/LG).
- damaged wiring on circuit 1262 (BN/LG).
- damaged driver side crash sensor.

PINPOINT TEST T: LFC 44/DTC U2017 — DRIVER SIDE CRASH SENSOR COMMUNICATION FAULT

CONDITIONS	DETAILS/RESULTS/ACTIONS	
T1 CHECK FOR CONTINUOUS OR ON-DEMAND SELF TEST DTCs		



WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the before operating the vehicle.	restraint system diagnostic tool must be removed
	1 Deactivate the system.
	2 Make sure the driver side crash sensor harness connector is fully connected to the driver side crash sensor.
	 Is the driver side crash sensor connected correctly?
	→ Yes GO to <u>T3</u> .
	→ No CONNECT the driver side crash sensor connector correctly. GO to $\underline{T10}$.
T3 CHECK THE CIRCUIT 1261 (WH/LG) FOR AN	OPEN
RCM C233	
Driver Side Crash Sensor C310	4 Measure the resistance between RCM C233 pin 8, circuit 1261 (WH/LG), harness side and driver side crash sensor C310, circuit
	1261 (WH/LG), harness side.
DR1002-A	
	Is the resistance greater than 1 ohm?
	→ Yes REPAIR the circuit. GO to <u>T10</u> .











NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

	 Deactivate the system. Refer to the continuous DTCs recorded during Step T1. Was the continuous DTC retrieved during Step T1 an intermittent fault? 	
	→ Yes CHECK for causes of a communication fault. ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>T10</u> .	
	GO to <u>T10</u> .	
T10 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	1 Refer to the continuous DTCs recorded during Step T1.	
	 Were any continuous DTCs retrieved during Step T1? 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	→ No RECONNECT the system. PROVE OUT the system. CLEAR all DTCs.	

Pinpoint Test U: LFC 45/DTC U2018 — Passenger Side Crash Sensor Communication Fault

Normal Operation

The passenger side crash sensor monitors the severity of a crash event. If the crash event is severe enough, the sensor will signal the restraints control module (RCM) to deploy the passenger side air bag.

The RCM monitors the two-wire current loop to the passenger side crash sensor for a signal that is out of the expected range. If the RCM detects an out-of-range signal from the passenger side crash sensor, indicating a sensor communication fault, it will store diagnostic trouble code (DTC) U2018 and flash a lamp fault code (LFC) 45 (or a higher priority code if one exists) on the air bag indicator.

Possible Causes

A passenger side crash sensor communication fault condition can be caused by:

- damaged wiring on circuit 1263 (WH).
- damaged wiring on circuit 1264 (BN).
- damaged passenger side crash sensor.

PINPOINT TEST U: LFC 45/DTC U2018 — PASSENGER SIDE CRASH SENSOR COMMUNICATION FAULT

	CONDITIONS	DETAILS/RESULTS/ACTIONS
U1	CHECK FOR CONTINUOUS OR ON-DEMAND	SELF TEST DTCs
1		
3	Scan Tool	
4	Retrieve/Clear Continuous DTCs	4 Retrieve and record any continuous DTCs for use later in this pinpoint test.
5	On-Demand Self Test	
		 Was DTC U2018 retrieved during the on-demand self test?
		 → Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to U2. → No This is an intermittent fault. The fault

	condition is not present at this time. GO to $\underline{U9}$.	
U2 CHECK THE PASSENGER SIDE CRASH SEN	SOR HARNESS CONNECTOR	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system nust be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.		
NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.		
NOTE: Diagnostics or repairs are not to be performe vehicle. Prior to attempting to diagnose/repair the sid the vehicle and the restraint system diagnostic tool n floor connector. The restraint system diagnostic tool	ed on a side airbag system with the seat in the de airbag system the seat must be removed from nust be installed in side airbag connector at the must be removed prior to operating the vehicle.	
NOTE: Diagnostics may be performed on seat syste climate controlled, heated, power seat track) with the restraint system diagnostic tool is installed under the	ms other than the side airbag system (lumbar, e seat installed in the vehicle as long as the e seat in the side airbag to floor connector.	
NOTE: After diagnosing/repairing a seat system the before operating the vehicle.	restraint system diagnostic tool must be removed	
	1 Deactivate the system.	
	2 Make sure the passenger side crash sensor harness connector is fully connected to the passenger side crash sensor.	
	 Is the passenger side crash sensor connected correctly? 	
	$ \xrightarrow{\rightarrow} Yes $ GO to <u>U3</u> .	
	→ No CONNECT the passenger side crash sensor connector correctly. GO to <u>U10</u> .	
U3 CHECK CIRCUIT 1263 (WH) FOR AN OPEN		
RCM C233		











WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

during Step U1.
 Were any continuous DTCs retrieved during Step U1?
→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
→ No RECONNECT the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test V: LFC 36/DTC B1993 — Driver Side Air Bag Circuit Shorted to Ground

Normal Operation

The restraints control module (RCM) monitors the resistance to ground at RCM C1 pins 2 and 3. If the resistance is less than 1000 ohms at either pin, the RCM will interpret that as a ground short, store diagnostic trouble code (DTC) B1993 and flash lamp fault code (LFC) 36.

Possible Causes

A driver side air bag circuit short to ground can be caused by:

- grounded wiring on circuit 1257 (WH/LB).
- damaged wiring on circuit 1258 (BN/LB).
- ground short in the driver side air bag module.
- an RCM internal concern.

PINPOINT TEST V: LFC 36/DTC B1993 — DRIVER SIDE AIR BAG CIRCUIT SHORTED TO GROUND

CONDITIONS	DETAILS/RESULTS/ACTIONS
V1 CHECK FOR A HARD OR INTERMITTENT DTC	
1	









	→ No INSTALL a new RCM. GO to <u>V8</u> .
V7 CHECK FOR AN INTERMITTENT FAULT	
	 Refer to the continuous DTCs recorded during Step V1.
	 Was the continuous DTC retrieved during Step V1 an intermittent fault?
	→ Yes CHECK for causes of intermittent short to ground on circuit 1257 (WH/LB) and circuit 1258 (BN/LB). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>V8</u> .
	\rightarrow No GO to <u>V8</u> .
V8 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	Refer to the continuous DTCs recorded during Step V1.
	 Were any continuous DTCs retrieved during Step V1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test W: LFC 36/DTC B1992 — Driver Side Air Bag Circuit Shorted to Battery or Ignition

Normal Operation

The restraints control module (RCM) monitors the driver side air bag circuits at RCM C1 pins 2 and 3 for a short to battery or ignition. If battery or ignition voltage is detected, the RCM will store diagnostic trouble code (DTC) B1992 and flash lamp fault code (LFC) 36.

Possible Causes

A driver side air bag circuit short to battery or ignition can be caused by:

- battery or ignition voltage on circuit 1257 (WH/LB).
- battery or ignition voltage on circuit 1258 (BN/LB).
- battery or ignition voltage short in the driver side air bag.
- an RCM internal concern.

PINPOINT TEST W: LFC 36/DTC B1992 — DRIVER SIDE AIR BAG CIRCUIT SHORTED TO BATTERY OR IGNITION











	\rightarrow No INSTALL a new RCM. GO to <u>W8</u> .
W7 CHECK FOR AN INTERMITTENT FAULT	
	1 Refer to the continuous DTCs recorded during Step W1.
	 Was the continuous DTC retrieved during Step W1 an intermittent fault?
	→ Yes CHECK for causes of intermittent short to battery or ignition on circuit 1257 (WH/LB) and circuit 1258 (BN/LB). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>W8</u> .
	→ No GO to <u>W8</u> .
W8 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	I Refer to the continuous DTCs recorded during Step W1.
	 Were any continuous DTCs retrieved during Step W1?
	→ Yes Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTC.

Pinpoint Test X: LFC 36/DTC B1994 — Driver Side Air Bag Circuit Resistance High

Normal Operation

The restraints control module (RCM) monitors the resistance of the driver side air bag circuit loop and the air bag module igniter at RCM C1 pins 2 and 3. If the resistance is greater than 3.6 ohms, the RCM will store diagnostic trouble code (DTC) B1994 and flash lamp fault code (LFC) 36.

Possible Causes

A high resistance on the driver side air bag circuit can be caused by:

- damaged wiring on circuit 1257 (WH/LB).
- damaged wiring on circuit 1258 (BN/LB).
- damaged driver side air bag module.
- damaged RCM.

PINPOINT TEST X: LFC 36/DTC B1994 — DRIVER SIDE AIR BAG CIRCUIT RESISTANCE HIGH

CONDITIONS	DETAILS/RESULTS/ACTIONS	
X1 CHECK FOR A HARD OR INTERMITTENT D	rc	
Scan Tool		
4 Retrieve/Clear Continuous DTCs	4 Retrieve and record any continuous DTCs for use later in this pinpoint test.	
	 Was DTC B1994 retrieved during the on- demand self test? 	
	→ Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to X2.	
	→ No This is an intermittent fault. The fault condition is not present at this time. GO to $\underline{X7}$.	
X2 CHECK THE DRIVER SIDE AIR BAG MODULE		
A		

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible

violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.






	→ No INSTALL a new RCM. GO to <u>X8</u> .	
X7 CHECK FOR AN INTERMITTENT FAULT		
	Refer to the continuous DTCs recorded during Step X1.	
	 Was the continuous DTC retrieved during Step X1 an intermittent fault? 	
	→ Yes CHECK for causes of intermittent high resistance on circuit 1257 (WH/LB) and circuit 1258 (BN/LB). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to X8.	
	$ \stackrel{\rightarrow}{\underset{\text{GO to }\underline{X8}}{\longrightarrow}} No $	
X8 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	Refer to the continuous DTCs recorded during Step X1.	
	 Were any continuous DTCs retrieved during Step X1. 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.	

Pinpoint Test Y: LFC 36/DTC B1995 — Driver Side Air Bag Circuit Resistance Low

Normal Operation

The restraints control module (RCM) monitors the resistance of the driver side air bag circuit loop and the air bag module igniter at RCM C1 pin 2 and 3. If the resistance is less than 1.4 ohms, the RCM will store diagnostic trouble code (DTC) B1995 and flash lamp fault code (LFC) 36.

Possible Causes

A low resistance on the driver side air bag circuit can be caused by:

- damaged wiring on circuit 1257 (WH/LB).
- damaged wiring on circuit 1258 (BN/LB).
- damaged driver side air bag module.
- damaged RCM.
- worn or damaged shorting bar or camming beam in C233 or C313.

PINPOINT TEST Y: LFC 36/DTC B1995 — DRIVER SIDE AIR BAG CIRCUIT RESISTANCE LOW









	during Step Y1.	
	 Was the continuous DTC retrieved during Step Y1 an intermittent fault? 	
	→ Yes CHECK for causes of intermittent low resistance on circuit 1257 (WH/LB) and circuit 1258 (BN/LB). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>Y7</u> .	
	\rightarrow No GO to <u>Y7</u> .	
Y7 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	1 Refer to the continuous DTCs recorded during Step Y1.	
	 Was the continuous DTC retrieved during Step Y1? 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	→ No RECONNECT the system. REACTIVATE the	

Pinpoint Test Z: LFC 37/DTC B1997 — Passenger Side Air Bag Circuit Shorted to Ground

Normal Operation

The restraints control module (RCM) monitors the resistance to ground at RCM C1 pins 5 and 6. If the resistance is less than 1000 ohms at either pin, the RCM will interpret that as a ground short, store diagnostic trouble code (DTC) B1997 and flash lamp fault code (LFC) 37.

Possible Causes

A passenger side air bag circuit short to ground can be caused by:

- grounded wiring on circuit 1259 (WH/YE).
- damaged wiring on circuit 1260 (BN/YE).

- ground short in the passenger side air bag module.
- an RCM internal concern.

PINPOINT TEST Z: LFC 37/DTC B1997 — PASSENGER SIDE AIR BAG CIRCUIT SHORTED TO GROUND

CONDITIONS	DETAILS/RESULTS/ACTIONS
Z1 CHECK FOR A HARD OR INTERMITTENT D	C
Scan Tool	
A Petripuo/Closer Continuous DTCs	4 Retrieve and record any continuous DTCs for use later in this pinpoint test.
On-Demand Self Test	
	 Was DTC B1997 retrieved during the on- demand self test?
	→ Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>Z2</u> .
	→ No This is an intermittent fault. The fault condition is not present at this time. GO to $\underline{Z7}$.
Z2 CHECK THE PASSENGER SIDE AIR BAG MO)DULE

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.







Passenger Side Air Bag Module C314	2 Inspect all crimps, terminals, wires and connectors in circuit 1259 (WH/YE) between the seat harness C308 and RCM C233 pin 5 and circuit 1260 (BN/YE) between the seat harness C308 and RCM C233 pin 6. Check for pinched wires and damaged connector pin terminals.
	• Was any damage found?
	\rightarrow Yes REPAIR as necessary. GO to <u>Z8</u> .
	→ No INSTALL a new RCM GO to <u>Z8</u> .
Z7 CHECK FOR AN INTERMITTENT FAULT	
	 Refer to the continuous DTCs recorded during Step Z1.
	 Was the continuous DTC retrieved during Step Z1 an intermittent fault?
	→ Yes CHECK for causes of intermittent short to ground on circuit 1259 (WH/YE) and circuit 1260 (BN/YE). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>Z8</u> .
	\rightarrow No GO to Z8.
Z8 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
	 Refer to the continuous DTCs recorded during Step Z1.
	 Were any continuous DTCs retrieved during Step Z1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control

Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test AA: LFC 37/DTC B1996 — Passenger Side Air Bag Circuit Shorted to Battery or Ignition

Normal Operation

The restraints control module (RCM) monitors the passenger side air bag circuits at RCM C1 pins 5 and 6 for a short to battery or ignition. If battery or ignition voltage is detected, the RCM will store diagnostic trouble code (DTC) B1996 and flash lamp fault code (LFC) 37.

Possible Causes

A passenger side air bag circuit short to battery or ignition can be caused by:

- battery or ignition voltage on circuit 1259 (WH/YE).
- battery or ignition voltage on circuit 1260 (BN/YE).
- battery or ignition voltage short in the passenger side air bag module.
- an RCM internal concern.

PINPOINT TEST AA: LFC 37/DTC B1996 — PASSENGER SIDE AIR BAG CIRCUIT SHORTED TO BATTERY OR IGNITION

CONDITIONS	DETAILS/RESULTS/ACTIONS
AA1 CHECK FOR A HARD OR INTERMITTENT I	DTC
2 Scan Tool	
3	
4	Retrieve and record any continuous DTCs for use later in this pinpoint test.

Retrieve/Clear Continuous DTCs		
On-Demand Self Test		
	 Was DTC B1996 retrieved during the on- demand self test? 	
	→ Yes This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>AA2</u> .	
	→ No This is an intermittent fault. The fault condition is not present at this time. GO to <u>AA7</u> .	
AA2 CHECK THE PASSENGER SIDE AIR BAG N	NODULE	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate		
NOTE: Airbag simulators (restraint system diagnostic tools) MUST be installed under the seats in the side airbag to floor connector.		
NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.		
NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.		
NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.		
	2 Deactivate the system.	
3		







	• Was any damage found?
	→ Yes REPAIR as necessary. GO to <u>AA8</u> .
	No INSTALL a new RCM. GO to <u>AA8</u> .
AA7 CHECK FOR AN INTERMITTENT FAULT	
	1 Refer to the continuous DTCs recorded during Step AA1.
	 Was the continuous DTC retrieved during Step AA1 an intermittent fault?
	→ Yes CHECK for causes of intermittent short to battery or ignition on circuit 1259 (WH/YE) and circuit 1260 (BN/YE). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>AA8</u> .
	\rightarrow No GO to <u>AA8</u> .
AA8 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	c tool is for restraint system service only. o remove could result in injury and possible
	1 Refer to the continuous DTCs recorded during Step AA1.
	 Were any continuous DTCs retrieved during Step AA1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test AB LFC 37/DTC B1998 — Passenger Side Air Bag Circuit Resistance High

Normal Operation

The restraints control module (RCM) monitors the resistance of the passenger side air bag circuit loop and the air bag module igniter at RCM C1 pins 5 and 6. If the resistance is greater than 3.6 ohms, the RCM will store diagnostic trouble code (DTC) B1998 and flash lamp fault code (LFC) 37.

Possible Causes

A high resistance on the passenger side air bag circuit can be caused by:

- damaged wiring on circuit 1259 (WH/YE).
- damaged wiring on circuit 1260 (BN/YE).
- damaged passenger side air bag module.
- damaged RCM.

PINPOINT TEST AB: LFC 37/DTC B1998 — PASSENGER SIDE AIR BAG CIRCUIT RESISTANCE HIGH

CONDITIONS	DETAILS/RESULTS/ACTIONS
AB1 CHECK FOR A HARD OR INTERMITTENT	DTC
Scan Tool	
	4 Retrieve and record any continuous DTCs for use later in this pinpoint test.
S	
On-Demand Self Test	
	 Was DTC B1998 retrieved during the on- demand self test?
	Yes This is a hard fault. The fault condition is still

present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>AB2</u>.

 \rightarrow No

This is an intermittent fault. The fault condition is not present at this time. GO to <u>AB7</u>.

AB2 CHECK THE PASSENGER SIDE AIR BAG MODULE

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.



AB3 CHECK THE PASSENGER SIDE AIR BAG MODULE SEAT HARNESS CIRCUIT 1259





	 connectors in circuit 1259 (WH/YE) between the seat harness C308 and RCM C233 pin 5 and circuit 1260 (BN/YE) between the seat harness C308 and RCM C233 pin 6. Check for pinched wires and damaged connector pin terminals. Was any damage found? → Yes REPAIR as necessary. GO to AB8. → No 	
AB7 CHECK FOR AN INTERMITTENT FAULT		
	Refer to the continuous DTCs recorded during Step AB1.	
	 Was the continuous DTC retrieved during Step AB1 an intermittent fault? 	
	 → Yes CHECK for causes of intermittent high resistance on circuit 1259 (WH/YE) and circuit 1260 (BN/YE). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>AB8</u>. → No GO to AB8 	
AB8 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	1 Refer to the continuous DTCs recorded during Step AB1.	
	 Were any continuous DTCs retrieved during Step AB1? 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all	

DTCs.

Pinpoint Test AC: LFC 37/DTC B1999 — Passenger Side Air Bag Circuit Resistance Low

Normal Operation

The restraints control module (RCM) monitors the resistance of the passenger side air bag circuit loop and the air bag module igniter at RCM C1 pins 5 and 6. If the resistance is less than 1.4 ohms, the RCM will store diagnostic trouble code (DTC) B1999 and flash lamp fault code (LFC) 37.

Possible Causes

A low resistance on the passenger side air bag circuit can be caused by:

- damaged wiring on circuit 1259 (WH/YE).
- damaged wiring on circuit 1260 (BN/YE).
- damaged passenger side air bag module.
- damaged RCM.
- damaged shorting bar or camming beam in C233 or C314.

PINPOINT TEST AC: LFC 37/DTC B1999 — PASSENGER SIDE AIR BAG CIRCUIT RESISTANCE LOW

CONDITIONS	DETAILS/RESULTS/ACTIONS
AC1 CHECK FOR A HARD OR INTERMITTENT	этс
Scan Tool	
4 Retrieve/Clear Continuous DTCs	Retrieve and record any continuous DTCs for use later in this pinpoint test.







	 → Yes INSTALL a new passenger side air bag. GO to AC7. → No PEPAIP the circuit(s) between the passenger 	
	side air bag connector C314 and the under- seat connector C308. GO to <u>AC7</u> .	
AC6 CHECK FOR AN INTERMITTENT FAULT		
	1 Refer to the continuous DTCs recorded during Step AC1.	
	 Was the continuous DTC retrieved during Step AC1 an intermittent fault? 	
	→ Yes CHECK for causes of intermittent low resistance on circuit 1259 (WH/YE) and circuit 1260 (BN/YE). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>AC7</u> .	
	\rightarrow No GO to <u>AC7</u> .	
AC7 CHECK FOR ADDITIONAL DTCs		
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.		
	1 Refer to the continuous DTCs recorded during Step AC1.	
	 Were any continuous DTCs retrieved during Step AC1? 	
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.	
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.	

Pinpoint Test AD: B1892 — Air Bag Tone Warning Indicator Circuit Shorted to Ground or Open

Normal Operation

The restraints control module (RCM) monitors its connection to the generic electronic module (GEM) at C280 pin 20. This connection is used to signal a chime if the air bag indicator is inoperative and another SRS fault exists. If the RCM detects a short to ground or open on the connection to the GEM, it will store a diagnostic trouble code (DTC) B1892 in memory.

Possible Causes

An air bag tone warning indicator circuit short to ground or open can be caused by:

- a short to ground or open on circuit 1083 (LB/BK).
- a damaged or inoperative GEM.
- a damaged RCM.

PINPOINT TEST AD: DTC B1892 — AIR BAG TONE WARNING INDICATOR CIRCUIT SHORTED TO GROUND OR OPEN

CONDITIONS	DETAILS/RESULTS/ACTIONS	
AD1 CHECK FOR A HARD OR INTERMITTENT DTC		
Scan Tool		
	Retrieve and record any continuous DTCs for use later in this pinpoint test.	
S		
On-Demand Self Test		
	 Was DTC B1892 retrieved during the on-demand self test? 	
	ightarrow Yes	

This is a hard fault. The fault condition is still present. This fault cannot be cleared until it is corrected and the DTC is no longer retrieved during the on-demand self test. GO to <u>AD2</u>.

 \rightarrow No

This is an intermittent fault. The fault condition is not present at this time. GO to <u>AD5</u>.

AD2 CHECK THE AIR BAG TONE WARNING INDICATOR CIRCUIT

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.

		2 Deactivate the system.
	RCM C232	
	0.514	
5	GEM	5 Measure the resistance between RCM C232 pin 26, circuit 1083 (LB/BK), harness side and RCM C232 pin 21, circuit 649 (BK/OG), harness side.





WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

1 Refer to the continuous DTCs recorded during Step AD1.
 Were any continuous DTCs retrieved during Step AD1?
→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test AE: DTC B1891 — Air Bag Tone Warning Indicator Circuit Shorted to Battery or Ignition

Normal Operation

The restraints control module (RCM) monitors its connection to the generic electronic module (GEM) at pin 20. This connection is used to signal a chime if the air bag indicator is inoperative and another SRS fault exists. If the RCM detects a short to battery or ignition on the connection to the GEM, it will store a diagnostic trouble code (DTC) B1891 in memory.

Possible Causes

An air bag tone warning indicator circuit short to battery or ignition can be caused by:

- a short to battery or ignition on circuit 1083 (LB/BK).
- a damaged or inoperative GEM.
- a damaged RCM.

PINPOINT TEST AE: DTC B1891 — AIR BAG TONE WARNING INDICATOR CIRCUIT SHORTED TO BATTERY OR IGNITION

CONDITIONS	DETAILS/RESULTS/ACTIONS	
AE1 CHECK FOR A HARD OR INTERMITTENT DTC		



WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.




	the wire harness and cycling the ignition key frequently. REPAIR any intermittent concerns found. GO to <u>AE5</u> .
	GO to <u>AE5</u> .
AE5 CHECK FOR ADDITIONAL DTCs	
WARNING: The restraint system diagnostic Remove from vehicle prior to road use. Failure to violation of vehicle safety standards.	tool is for restraint system service only. o remove could result in injury and possible
	1 Refer to the continuous DTCs recorded during Step AE1.
	 Were any continuous DTCs retrieved during Step AE1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test AF: DTC B1869 — Air Bag Indicator Inoperative

Normal Operation

The air bag indicator is designed to illuminate for 6 (+/-2) seconds when the ignition switch is turned to the RUN position. This initial 6 seconds of illumination is considered normal operation and is called prove out of the air bag indicator. The air bag indicator is then used to warn the driver if there is a fault in the air bag supplemental restraint system (SRS).

The restraints control module (RCM) monitors the air bag indicator for open and short to ground conditions. If the RCM detects an open or short to ground condition on the air bag indicator circuit, it will store a diagnostic trouble code (DTC) B1869 in memory.

If the RCM detects an air bag indicator failure in addition to another SRS failure, the RCM will send a signal to the generic electronic module (GEM) to produce five sets of five tone bursts.

Possible Causes

An air bag indicator inoperative condition can be caused by:

- damaged wiring on circuit 608 (BK/YE).
- a damaged or burned out air bag indicator.
- an instrument cluster malfunction.

• a damaged RCM.

PINPOINT TEST AF: DTC B1869 — AIR BAG INDICATOR INOPERATIVE



WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible

violation of vehicle safety standards.

NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.





DR1400-A	
	Is the resistance greater than 10 ohms?
	→ Yes REPAIR the circuit. GO to <u>AF6</u> . → No
AES CHECK FOR AN INTERMITTENT FALLET	REPAIR the instrument cluster. GO to <u>AF6</u> .
	 I Refer to the continuous DTCs recorded during Step AF1. Was the continuous DTC retrieved during Step AF1 an intermittent fault? → Yes CHECK for causes of intermittent short to ground or open on circuit 608 (BK/YE). ATTEMPT to recreate the hard fault by flexing the wire harness and cycling the ignition key
	frequently. REPAIR any intermittent concerns found. GO to <u>AF6</u> . → No
AF6 CHECK FOR ADDITIONAL DTCs	
A	

WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible

violation of vehicle safety standards.	
	1 Refer to the continuous DTCs recorded during Step AF1.
	 Were any continuous DTCs retrieved during Step AF1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test AG: DTC B1870 — Air Bag Indicator Shorted to Battery

Normal Operation

The air bag indicator is designed to illuminate for 6 (+/-2) seconds when the ignition switch is turned to the RUN position. This initial 6 seconds of illumination is considered normal operation and is called prove out of the air bag indicator. The air bag indicator is then used to warn the driver that there is a fault in the air bag supplemental restraint system (SRS).

While the air bag indicator is activated, the restraints control module (RCM) monitors the air bag indicator for short to battery conditions. If the RCM detects a short to battery condition on the air bag indicator circuit, it will store a diagnostic trouble code (DTC) B1870 in memory.

If the RCM detects an air bag indicator failure in addition to another SRS failure, the RCM will send a signal to the generic electronic module (GEM) to produce five sets of five tone bursts.

Possible Causes

An air bag indicator short to battery condition can be caused by:

- a short to battery on circuit 608 (BK/YE).
- a damaged or inoperative instrument cluster.
- an RCM internal concern.

PINPOINT TEST AG: DTC B1870 - AIR BAG INDICATOR SHORTED TO BATTERY

CONDITIONS	DETAILS/RESULTS/ACTIONS
AG1 CHECK FOR A HARD OR INTERMITTENT DTC	
1	



NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.

NOTE: Airbag simulators (restraint system diagnostic tools) **MUST** be installed under the seats in the side airbag to floor connector.

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.





WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible

violation of vehicle safety standards.	
	 Refer to the continuous DTCs recorded during Step AG1.
	 Were any continuous DTCs retrieved during Step AG1?
	→ Yes Do not clear any DTCs until all DTCs have been resolved. GO to the Restraints Control Module (RCM) Diagnostic Trouble Code (DTC) Priority Table in this section for pinpoint test direction.
	→ No RECONNECT the system. REACTIVATE the system. PROVE OUT the system. CLEAR all DTCs.

Pinpoint Test AH: No Communication with the Restraints Control Module (RCM)

Normal Operation

The RCM communicates with the scan tool using ISO 9141 communication mode through the data link connector (DLC).

Possible Causes

Γ

A no communication condition can be caused by:

- damage to circuit 70 (LB/WH).
- a damaged DLC.
- a damaged scan too.
- an RCM internal concern.

PINPOINT TEST AH: NO COMMUNICATION WITH THE RESTRAINTS CONTROL MODULE (RCM)

CONDITIONS	DETAILS/RESULTS/ACTIONS
AH1 CHECK THE RCM CONNECTOR C232 AND CONNECTOR PIN 5 FOR DAMAGE	
WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.	
NOTE: If a seat equipped with a seat mounted side airbag system is being serviced the airbag system must be deactivated per the deactivation procedure contained in <u>Section 501-20B</u> of the appropriate car/truck service manual.	
NOTE: Airbag simulators (restraint system diagnostic side airbag to floor connector.	tools) MUST be installed under the seats in the

NOTE: Diagnostics or repairs are not to be performed on a side airbag system with the seat in the vehicle. Prior to attempting to diagnose/repair the side airbag system the seat must be removed from the vehicle and the restraint system diagnostic tool must be installed in side airbag connector at the floor connector. The restraint system diagnostic tool must be removed prior to operating the vehicle.

NOTE: Diagnostics may be performed on seat systems other than the side airbag system (lumbar, climate controlled, heated, power seat track) with the seat installed in the vehicle as long as the restraint system diagnostic tool is installed under the seat in the side airbag to floor connector.

NOTE: After diagnosing/repairing a seat system the restraint system diagnostic tool must be removed before operating the vehicle.







2000 Explorer/Mountaineer Workshop Manual

Air Bag Disposal — Deployed Air Bag

1. WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

Dispose of the deployed air bag modules and safety belt pretensioners in the same manner as any other part to be scrapped.

2000 Explorer/Mountaineer Workshop Manual

Air Bag Disposal — Undeployed, Inoperative

WARNING: Carry a live air bag module with the air bag and trim cover or deployment door pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

NOTE: All inoperative air bag modules and safety belt pretensioners have been placed on the Mandatory Return List. All discolored or damaged air bag modules must be treated the same as any inoperative live air bag being returned.

1. Remove the inoperative component from the vehicle. For additional information, refer to the appropriate air bag procedure in this section or to <u>Section 501-20A</u> for the retractor/pretensioner assembly.

AIR BAG MODULE VERIFICATION		
VEHICLE SERIAL NO. This 17 digit number can be found (1) on your vehicle registration (2) on the dash panel at left side close to lower edge of windshield.		
ATTENTION INSTALLER Please complete and mail this postcard with your New Air Bag Module Serial Number (see sample below) and the Vehicle Identification Number (VIN) of the vehicle in which you are installing this module.		
LOOK FOR YOUR REPLACEMENT AIR BAG MODULE SERIAL NUMBER (SN) AT THE LOCATION SHOWN IN THIS SAMPLE AND ENTER IT IN THE SPACE PROVIDED BELOW		
MODULE SERIAL NO.		
A0005406		

 NOTE: When installing a new air bag module, a prepaid return postcard is provided with the replacement air bag module. The serial number for the new part and the vehicle identification number (VIN) must be recorded and sent to Ford Motor Company.

If installing a new air bag module:

• Record the necessary information and return the inoperative air bag module to Ford Motor Company.

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explorer/Mountaineer Workshop Air Bag System Manual GENERAL PROCEDURES

Air Bag Disposal — Driver, Undeployed, Scrapped Vehicle

Remote Deployment

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module or safety belt retractor/pretensioner assembly. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live air bag module with the air bag and trim cover or deployment door pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Remote deployment is to be performed outdoors with all personnel at least 6.1 meters (20 feet) away to ensure personal safety. Due to the loud report which occurs when the air bag is deployed, hearing protection is required.

WARNING: Do not place the driver or passenger air bag module with the trim cover or deployment door facing down, as the forces of the deploying air bag can cause it to ricochet and cause personal injury.

- 1. Remove the driver air bag from the vehicle. Refer to Module—Driver Air Bag in this section.
- 2. Cut and strip the wires near the electrical connector.



3. Obtain two wires (20 gauge minimum) at least 6.1 meters (20 feet) long and attach one end of each wire to the stripped ends of the air bag module wires.



- 4. Place the air bag module on a flat surface in an open outdoor area with the trim cover facing upward.
- 5. Remain at least 6.1 meters (20 feet) away from the air bag module.
- 6. Deploy the air bag module by touching the other ends of the two wires to the terminals of a 12–volt battery.



- 7. To allow for cooling, wait at least ten minutes before approaching the deployed air bag.
- 8. Dispose of the deployed air bag module in the same manner as any other part to be scrapped.

Manual

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explorer/Mountaineer Workshop Air Bag System GENERAL PROCEDURES

Air Bag Disposal — Passenger, Undeployed, Scrapped Vehicle

Remote Deployment

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live air bag module with the air bag and trim cover or deployment door pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Remote deployment is to be performed outdoors with all personnel at least 6.1 meters (20 feet) away to ensure personal safety. Due to the loud report which occurs when the air bag is deployed, hearing protection is required.

WARNING: Do not place the driver or passenger air bag module with the trim cover or deployment door facing down, as the forces of the deploying air bag can cause it to ricochet and cause personal injury.

- 1. Remove the passenger air bag from the vehicle. Refer to Module—Passenger Air Bag in this section.
- 2. Cut and strip the wires near the electrical connector.



3. Obtain two wires (20 gauge minimum) at least 6.1 meters (20 feet) long and attach one end of each wire to the stripped wires on the air bag module.



- 4. Place the air bag module on a flat surface in an open outdoor area with the deflector can facing downward.
- 5. Remain at least 6.1 meters (20 feet) away from the air bag module.
- 6. Deploy the air bag module by touching the other ends of the two wires to the terminals of a 12–volt battery.



- 7. To allow for cooling, wait at least ten minutes before approaching the deployed air bag.
- 8. Dispose of the deployed air bag module in the same manner as any other part to be scrapped.

Air Bag Disposal — Side, Undeployed, Scrapped Vehicle

Remote Deployment

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module or safety belt retractor/pretensioner assembly. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live air bag module with the air bag and trim cover or deployment door pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Remote deployment is to be performed outdoors with all personnel at least 6.1 meters (20 feet) away to ensure personal safety. Due to the loud report which occurs when the air bag is deployed, hearing protection is required.

WARNING: Do not place the side air bag module with the tear seam facing down or the attaching studs facing upward, as the forces of the deploying air bag can cause it to ricochet and cause personal injury.

- 1. Remove the side air bag from the vehicle. For additional information, refer to <u>Module—Side Air Bag</u> in this section.
- 2. Obtain two wires (20 gauge minimum) at least 6.1 meters (20 feet) long and attach one end of each wire to the connector pins on the air bag module.



- 3. Place the air bag module on a flat surface in an open outdoor area with the tear seam facing upward and the attaching studs facing downward.
- 4. Remain at least 6.1 meters (20 feet) away from the air bag module.
- 5. Deploy the side air bag module by touching the other ends of the two wires to the terminals of a 12– volt battery.



- 6. To allow for cooling, wait at least ten minutes before approaching the deployed air bag.
- 7. Dispose of the deployed side air bag module in the same manner as any other part to be scrapped.

2000 Explorer/Mountaineer Workshop Manual

Wiring Repair

- 1. Inspect the supplemental restraint system (SRS) wiring and the wiring harness for any damage that may have occurred as a result of the accident. Inspect and repair or install new, as required, any damaged:
 - insulation.
 - terminal.
 - connectors.
 - splices.
- 2. Splice damaged wires using the specified butt-splice connector or equivalent.
 - For splices required in adjacent wiring, stagger the splices 51 mm (2.04 in) apart from each other.
 - Use waterproof butt-splice type connectors.
 - Use the correct size heat shrink nylon tube to prevent water, salt, condensation, and heat from affecting the wiring repair. Make sure the tube extends 25 mm (1 in) each side of the repair.
 - Use a splice connector that is lined with a sealer that melts when heated with a heat gun and flows from the tubing, sealing the splice.
 - Use the correct gauge connector for the wire being repaired.
 - Use connectors that are transparent to allow inspection of the finished splice.

Weld Nut Repair —"J" Nut, Restraints Control Module (RCM), Front External Crash and Side Crash Sensor

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: There are two procedures to repair a vehicle having missing air bag crash sensor attaching weld nut (s). Read both procedures before proceeding with the repair.

NOTE: If two or more weld nuts are missing, do not install the "J" nuts as outlined in this procedure. Weld nuts must be installed as outlined in Weld Nut Repair — Missing Weld Nut, Restraints Control Module (RCM), Front External Crash and Side Crash Sensor.

NOTE: The following procedure applies to vehicles that have a rectangular hole in the sheet metal that is in close proximity to the missing weld nut.

- 1. Obtain a "J" nut (part number N623332-S301) or any of the following optional "J" nuts (part numbers: N623342-S101, N800854-S100, N800925-S100).
- 2. Obtain a 6 mm (0.24 in) grounding screw (part number N806327-S190) or equivalent.
- 3. Install the "J" nut through the rectangular hole in the sheet metal.
- 4. **NOTE:** Be sure the threaded portion of the "J" nut is aligned with the clearance hole in the sheet metal.

Install the crash sensor.

5. Tighten the attaching screws to specification. Refer to Torque Specifications in this section.

Weld Nut Repair — Missing Weld Nut, Restraints Control Module (RCM), Front External Crash and Side Crash Sensor

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: There are two procedures to repair a vehicle having missing air bag crash sensor attaching weld nut (s). Read both procedures before proceeding with the repair.

NOTE: If two or more weld nuts are missing, do not install the "J" nuts as outlined in Weld Nut Repair — "J" Nut, Restraints Control Module (RCM), Front External Crash and Side Crash Sensor. Weld nuts must be installed as outlined in this procedure.

NOTE: Radiator support repair shown, others are similar.

- 1. Obtain a 6 mm (0.24 in) weld nut (part number N806285-S190).
- 2. Obtain a 6 mm (0.24 in) grounding screw (part number N806327-S190).
- 3. Route a sufficient length of copper welding wire through the weld nut clearance hole and back out an adjacent access hole.



4. Feed the copper welding wire through the weld nut, then through a standard flatwasher.



- 5. Secure the flatwasher so that it cannot be pulled off the end of the copper welding wire.
- 6. Pull the copper welding wire back through the clearance hole, allowing the weld nut and flatwasher to follow the copper welding wire through.
- 7. Position the weld nut to the weld nut clearance hole, firmly pulling on the copper welding wire allowing the secured flatwasher to hold the weld nut in position.
- 8. Holding the weld nut securely in place and using a MIG welder, weld in four places around the edge of the weld nut.
- 9. Metal finish as required.
- 10. Verify the nut is securely in place.
- 11. Install the crash sensor.
- 12. Tighten the attaching screws to specification. Refer to Torque Specifications in this section.

Weld Nut Repair —Stripped Weld Nut, Restraints Control Module (RCM), Front External Crash and Side Crash Sensor

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

- 1. Obtain an 8 mm (0.32 in) grounding screw (part number N802455-S190).
- 2. Drill out the internal threads of the stripped-out weld nut to 7.37 mm (0.29 in) using a letter "L" size drill bit.
- 3. Position the crash sensor to the vehicle.
- 4. Install the 8 mm (0.32 in) grounding screw into the drilled-out weld nut.
- 5. Install the remaining attaching screws.
- 6. Tighten the attaching screws to specification. Refer to Torque Specifications in this section.

Manual

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explorer/Mountaineer Workshop Air Bag System REMOVAL AND INSTALLATION

Sensor — Front External Crash

Removal

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: A repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

- 1. Disconnect the battery ground cable (14301) and wait at least one minute. For additional information, refer to Section 414-01.
- 2. Remove the radiator grill and radiator opening cover. For additional information, refer to Section 501-02.
- 3. Remove the air bag sensor.
 - 1. Disconnect the air bag sensor electrical connector.
 - 2. Remove the three screws.
 - 3. Remove the air bag sensor.



Installation

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage can result.

NOTE: A repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

1. Follow the removal procedure in reverse order.



2. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Prove out the air bag system.
Manual

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explorer/Mountaineer Workshop Air Bag System REMOVAL AND INSTALLATION

Sensor —Side Crash

Removal

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

NOTE: Right side is shown, left side is similar.

- 1. Disconnect the battery ground cable (14301) and wait at least one minute. For additional information, refer to Section 414-01.
- 2. NOTE: Four door is shown, two door is similar.

NOTE: The front seat has been removed for clarity.

Remove the B-pillar lower trim panel with scuff plates.



- 3. Remove the side crash sensor.
 - 1. Disconnect the side crash sensor electrical connector.
 - 2. Remove the two retaining bolts.
 - 3. Remove the side crash sensor with bracket.



Installation

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: The tightening torque of the air bag side crash sensor retaining bolts is critical for proper system operation.

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage can result.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

1. Follow the removal procedure in reverse order.



2. **WARNING:** The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards. Prove out the air bag system.

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explorer/Mountaineer Workshop Air Bag System Manual REMOVAL AND INSTALLATION

Module — Restraints Control

Removal

WARNING: The restraints control module (RCM) orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) has been involved in a collision in which the right cowl A-pillar area has been damaged, inspect the mounting and bracket for deformation. If damaged, the RCM must be replaced whether or not the air bags have deployed. In addition, make sure the area of the RCM mounting is restored to its original condition.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage can result.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

- 1. Disconnect the battery ground cable (14301) and wait at least one minute. For additional information, refer to <u>Section 414-01</u>.
- 2. Remove the right hand cowl side trim panel (02345). For additional information, refer to <u>Section 501-</u><u>05</u>.



- 3. Disconnect the restraints control module (RCM).

 - Slide the two RCM electrical connector locking clips down to disengage them.
 While squeezing the locking clip area to pivot the latch, disconnect the two RCM electrical connectors.



- 4. Remove the RCM with bracket.
 - 1. Remove the three RCM bracket retaining bolts.

2. Remove the RCM with bracket.



Installation

1. WARNING: The tightening torque of the restraints control module (RCM) retaining bolts is critical for proper system operation.

CAUTION: Electronic modules are sensitive to static electrical charges. If exposed to these charges, damage can result.

NOTE: A repair is made by installing a new part only. If the part does not correct the condition, install the original part and perform the diagnostic procedure again.

Follow the removal procedure in reverse order.



2. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Prove out the air bag system.

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explo Air Bag System REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Module — Driver Air Bag

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live air bag module with the air bag and trim cover pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live air bag module down with the trim cover face down. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterwards.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Air bag modules with discolored or damaged trim covers must be installed new, not repainted.

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

- 1. Disconnect the battery ground cable (14301) and wait at least one minute. For additional information, refer to <u>Section 414-01</u>.
- 2. Remove the two steering wheel back cover plugs.



3. Remove the two driver side air bag module retaining bolts.



- 4. Remove the driver air bag module.
 - 1. Disconnect the driver air bag module electrical connector.
 - 2. Remove the driver air bag module.



Installation

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the

event of an accidental deployment.

WARNING: Carry a live air bag module with the air bag and trim cover pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

NOTE: Make sure to tighten the retaining bolts to specification.

1. Follow the removal procedure in reverse order.



2. **WARNING:** The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Prove out the air bag system.

Manual

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explorer/Mountaineer Workshop Air Bag System REMOVAL AND INSTALLATION

Module — Passenger Air Bag

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

KARNING: Do not set a live air bag module down with the deployment door face down. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterwards.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Air bag modules with discolored or damaged deployment doors must be installed new, not repainted.

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: A repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

- 1. Disconnect the battery ground cable (14301) and wait at least one minute. For additional information, refer to <u>Section 414-01</u>.
- 2. Open the glove compartment door to access the mounting screws.



3. Remove the two screws.



4. CAUTION: Do not handle the passenger air bag module by grabbing the edges of the deployment door.

Reaching one hand into the glove box opening, push out on the passenger air bag module and separate it from the instrument panel.



5. Disconnect the electrical connector and remove the passenger air bag module.



Installation

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

NOTE: A repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

1. Follow the removal procedure in reverse order.



2. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Prove out the air bag system.

SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Explor Air Bag System REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Module — Side Air Bag

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live side air bag module down on cover tear seam. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterwards.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: When replacing the side air bag after deployment, refer to <u>Section 501-10</u> for additional information concerning the installation of a new side air bag.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

NOTE: Front driver seat is shown, passenger seat is similar.

- 1. Disconnect the battery ground cable (14301) and wait at least one minute. For additional information, refer to <u>Section 414-01</u>.
- 2. Remove the seat from the vehicle. For additional information, refer to Section 501-10.

WARNING: Front seat back trim covers installed on seats equipped with side air bags cannot be repaired; they are to be replaced (cleaning is permissible).

3. Disconnect the seat motor electrical connector.



4. Remove the four bolts (two shown) and the seat track from the seat bottom.



5. Disconnect the power seat switch electrical connector.



6. **NOTE:** Release all tension from the manual lumbar support cable.

Pull and remove the manual lumbar support adjustment handle and remove the lower seat trim panel retaining screw.



7. Press the tabs in on the two retaining clips (one shown) and separate the lower seat trim panel from the seat bottom frame.



- 8. Remove the lower seat trim panel.
 - 1. Disconnect the heated seat switch (if equipped).
 - 2. Remove the lower seat trim panel.



9. Remove the push pin holder from the seat bottom frame for the lumbar support cable.



- Separate the lumbar support cable assembly.
 Separate the lumbar support case assembly by sliding apart.
 Remove the cable end ball from the cable end retainer and separate.



11. Remove the push pin retaining the heated seat back electrical connector to the seat bottom frame.



12. Disconnect the heated seat back electrical connector.



13. Remove the side air bag electrical connector and wire harness push pins from the seat bottom frame.



14. Remove the push pin from the side air bag electrical connector.



15. Remove the two retaining bolts.



16. CAUTION: When positioning the seat or separating the seat bottom from the back, be careful not to damage the seat back pivot and any of the wires or cables from the seat back to

the seat bottom. This can cause damage to one of the seat components.

Laying the seat on its other side, remove the retaining bolt for the seat pivot, being careful not to damage the seat pivot, cable or any of the wires.



- 17. Remove the seat back from the seat bottom.
 - 1. Pull the heated seat wire harness through the seat bottom.
 - 2. Pull the lumbar support cable through the seat bottom.
 - 3. Pull the side air bag module wire harness through the seat bottom.
 - 4. Remove the seat back from the seat bottom.



18. Separate the seat back trim cover lower J-clip.



19. Remove and discard the hog rings from the two swing rods (one shown).



20. Slide the swing rods out of the seat back trim cover.



21. CAUTION: Use care when separating the seat cushion trim cover from the hook and loop strip. The hook and loop strip can be torn from the seat cushion foam.

Roll the seat back trim cover, in an inside out fashion, to the side air bag deployment chute.



22. Unzip the side air bag deployment chute.



23. Roll the seat back cover and side air bag deployment chute to completely expose the side air bag module and mounting bracket.



24. Remove the side air bag wire harness tie strap retainer.



25. **NOTE:** If installing a new side air bag module, use new retaining nuts. If the same side air bag module is to be reused, then reuse the side air bag module retaining nuts.

Position the side air bag module aside, through the seat back cushion opening.

• Remove the retaining nuts.



- 26. Remove the side air bag module.
 - 1. Slide the side air bag module electrical connector locking clip to disengage it.
 - 2. Release the connector tabs by pushing in on them, then disconnect the side air bag module electrical connector.
 - 3. Remove the side air bag module.



Installation

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live side air bag module with the air bag and tear seam pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag

deployment, which can result in personal injury.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

- 1. Connect the side air bag module electrical connector.
 - 1. Install the connector to the side air bag module.
 - 2. Slide the side air bag module electrical connector locking clip to secure the connector to the side air bag module.



2. Make sure the electrical connector is securely fastened to the side air bag module.

WARNING: Inspect the mounting surfaces of the side air bag module and the seat back frame mounting bracket for any foreign objects before installing the side air bag module. If any foreign objects are found, remove them. Failure to do so may result in personal injury, in the event of an air bag deployment.

WARNING: Inspect the side air bag deployment chute and the side air bag cavity in the seat back pad for any foreign objects. If any foreign objects are found, remove them. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Before installing the side air bag module, check it for damage and foreign objects. If the air bag module is damaged, replace it. If any foreign objects are found, remove them. Failure to do so may result in personal injury, in the event of an air bag deployment.

WARNING: If the air bag cover has separated or the air bag material has been exposed, install a new side air bag module. Do not attempt to repair the air bag module. Failure to do so may result in personal injury in the event of an air bag deployment.

WARNING: Check the side air bag deployment chute and zipper for damage. The deployment chute and zipper must not be repaired. If there is any damage to the deployment chute or zipper, the seat back trim cover and deployment chute must be replaced as a unit. Failure to do so may result in personal injury.

3. CAUTION: The retaining nuts of the side air bag module must be tightened in the sequence described.

CAUTION: Make sure the side air bag wiring harness is not pinched between the side air

bag module and the mounting bracket.

Install the side air bag module onto the front seat back frame mounting bracket, making sure the side air bag wiring harness is located behind the seat backrest frame and side air bag module mounting bracket.

- 1. Position the side air bag module onto the front seat back mounting bracket.
- 2. Install the side air bag module retaining nut.
- 3. Install the side air bag module retaining nut.
- 4. Install the side air bag module retaining nut.



4. Tie-strap the side air bag module wire harness to the seat back frame.



5. Unroll the seat back trim cover, to position the deployment chute around the side air bag module.



6. WARNING: Check the side air bag deployment chute and zipper for damage. The deployment chute and zipper must not be repaired. If there is any damage to the deployment chute or zipper the seat back trim cover and deployment chute must be installed new as a unit.

WARNING: If the air bag deployment chute is not properly positioned and completely zipped, the side air bag may not deploy properly.

Position the air bag deployment chute.

- 1. Insert the outboard side of the air bag deployment chute between the seat back pad and the side air bag module, pulling it around the outboard side of the seat back frame.
- 2. Insert the inboard side of the air bag deployment chute between the seat back pad and the side air bag module from the inboard side of the seat back.



7. **NOTE:** Be sure the side air bag deployment chute is properly positioned, before proceeding.

Zip the air bag deployment chute completely closed, then position the zipper tail at the top and bottom

of the deployment chute, into the seat back opening.

- The side air bag deployment chute must encircle the side air bag module, going completely around the side air bag module and the side of the seat back frame.
- Align the side air bag deployment chute to the side air bag module, making sure it covers the length of the side air bag module.



- 8. Unroll the seat back trim cover to the bottom row of hog rings.
- 9. Install the swing rods back into the seat back trim cover sleeves.



10. NOTE: The seat back trim cover has been inverted for clarity.

Reaching between the seat back trim cover and the seat back pad, at the middle row of hog rings, position the top of the swing rods under the listing wire in the seat back pad.



11. Install new hog rings onto the swing rods (one shown).



- 12. Pull the seat back rest trim cover completely down and connect the hook and loop fastener to the seat back cushion.
- 13. Route the seat back heating element wire harness (if equipped).



14. Reattach the seat back trim cover lower J-clips.



- 15. Position the seat back to the seat bottom and route the wires and cables.
 - 1. Pull the side air bag module wire harness through the seat bottom.
 - 2. Pull the lumbar support cable through the seat bottom.
 - 3. Pull the heated seat wire harness through the seat bottom.



16. CAUTION: When positioning the seat or installing the bottom to the seat back, be careful not to damage the seat back pivot and any of the wires or cables from the seat back to the seat bottom. This can cause damage to one of the seat components.

Align the seat back to the seat bottom. Install the bolt and tighten to specification.



17. Install the two bolts and tighten to specification.



18. Install the push pin onto the side air bag electrical connector.



19. Route the side air bag module electrical connector and wire harness, then install the push pins.



20. Connect the heated seat wire connector.



21. Route the heated seat wire harness and install the push pin.



- 22. Connect the lumbar support cable assembly.
 - 1. Install the cable end ball to the cable end retainer.
 - 2. Insert the lumbar cable sleeve into the adjustment cable sleeve slot.



23. Install the push pin holder to the seat bottom frame for the lumbar support cable.



24. Install the seat bottom lower side shield into the seat bottom frame.

- 1. Connect the heated seat switch (if equipped).
- 2. Insert the lower side shield clips into the seat bottom frame.



25. Install the seat bottom lower side shield retaining screw and the lumbar support handle.



26. Connect the power seat switch electrical connector.



27. Position the seat track to the seat bottom frame. Install the four bolts (two shown) and tighten to specification.



28. Connect the seat motor electrical connector.



- 29. Install the seat into the vehicle. For additional information, refer to <u>Section 501-10</u>.
- 30. Connect the battery ground cable (14301). For additional information, refer to Section 414-01.
- 31. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Prove out the air bag system.
SECTION 501-20B: Occupant Restraints — Passive — Supplemental 2000 Exp Air Bag System REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Air Bag Sliding Contact

Removal

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live air bag module with the air bag and trim cover pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Do not set a live air bag module down with the trim cover face down. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: After deployment, the air bag surface can contain deposits of sodium hydroxide, a product of the gas generant combustion that is irritating to the skin. Wash your hands with soap and water afterwards.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

WARNING: Air bag modules with discolored or damaged trim covers must be replaced, not repainted.

WARNING: Vehicle sensor orientation is critical for proper system operation. If a vehicle equipped with an air bag supplemental restraint system (SRS) is involved in a collision, inspect the sensor mounting bracket and wiring pigtail for deformation. Replace and properly position the sensor or any other damaged supplemental restraint system (SRS) components whether or not the air bag is deployed.

WARNING: To avoid accidental deployment and possible personal injury, the backup power supply must be depleted before repairing or replacing any front or side air bag supplemental restraint system (SRS) components and before servicing, replacing, adjusting or striking components near the front or side air bag sensors, such as doors, instrument panel, console, door latches, strikers, seats and hood latches.

Please refer to the appropriate vehicle shop manual to determine location of the front air bag sensors.

The side air bag sensors are located at or near the base of the B-pillar.

To deplete the backup power supply energy, disconnect the battery ground cable and wait at least one minute. Be sure to disconnect auxiliary batteries and power supplies (if equipped).

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

- 1. Disconnect the battery ground cable (14301) and wait at least one minute. For additional information, refer to <u>Section 414-01</u>.
- 2. Remove the driver air bag module. For additional information, refer to <u>Module—Driver Air Bag</u> in this section.
- 3. NOTE: Make sure the wheels (1007) are in the straight-ahead position.

Remove the steering wheel (3600). For additional information, refer to Section 211-04.

4. Apply two strips of masking tape across the air bag sliding contact (14A664) to prevent accidental rotation when the air bag sliding contact is removed.



- 5. Remove the lower steering column opening finish panel.
 - 1. Remove the retaining screws and position the hood release handle out of the way.
 - 2. Remove the two retaining screws from the lower steering column opening finish panel.
 - 3. Pull out to release the retaining clips and remove the lower steering column opening finish panel.



6. Remove the four retaining bolts and remove the lower steering column opening finish panel reinforcement.



7. Loosen , but do not remove, the four steering column to instrument panel retaining bolts enough to remove the upper steering column shroud (two shown).



- 8. Remove the lower steering column shroud (3530).
 - 1. If equipped, remove the tilt wheel handle and shank (3F609).
 - 2. Remove the three screws.
 - 3. Remove the lower steering column shroud.



- 9. Remove the ignition switch lock cylinder (11582).
 - 1. Position the ignition switch lock cylinder to the RUN position.
 - 2. Using the suitable tool, push upward on the cylinder release tab while pulling the ignition switch lock cylinder outward.



10. Remove the upper steering column shroud.



- 11. Remove the passive anti-theft system (PATS) transmitter.
 - 1. Remove the PATS transmitter retaining screw.
 - 2. Position the PATS transmitter out of the way.



12. Remove the key-in-ignition warning indicator switch.



13. Remove the two air bag sliding contact wire connectors from the wire connector bracket and disconnect them.



14. Remove the wire harness from the two holders (one shown).



15. Release the lower air bag sliding contact retaining clip.



- 16. Remove the air bag sliding contact.
 - 1. Release the remaining two air bag sliding contact retaining clips.
 - 2. Remove the air bag sliding contact.



Installation

WARNING: Always wear safety glasses when repairing an air bag supplemental restraint system (SRS) vehicle and when handling an air bag module. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Carry a live air bag module with the air bag and trim cover pointed away from your body. This will reduce the risk of injury in the event of an accidental deployment.

WARNING: Never probe the connectors on the air bag module. Doing so can result in air bag deployment, which can result in personal injury.

NOTE: Repair is made by installing a new part only. If the new part does not correct the condition, install the original part and perform the diagnostic procedure again.

1. Follow the removal procedure in reverse order.





2. WARNING: The restraint system diagnostic tool is for restraint system service only. Remove from vehicle prior to road use. Failure to remove could result in injury and possible violation of vehicle safety standards.

Prove out the air bag system.

SECTION 502-02: Full Frame and Body Mounting SPECIFICATIONS

General Specifications

ltem	Specification
Drill Bit For Rivet Replacement	3.17 mm (1/8 in)
Drill Bit For Rivet Replacement	8.73 mm (11/32 in)

Torque Specifications

Description	Nm	lb-ft
Radiator Insulator Bolts	68-92	50-68
Radiator Insulator Nuts	46-64	34-47
Transmission Support Insulator Nuts	98-132	73-97
Transmission Crossmember to Frame Bolts	70	52
Transmission Crossmember Bolts and Nuts	127	94

SECTION 502-02: Full Frame and Body Mounting DESCRIPTION AND OPERATION

2000 Explorer/Mountaineer Workshop Manual

Frame and Body Mounting

The frame (5005) consists of two steel channel rails, a rear crossmember, four additional support crossmembers and a front crossmember.

The rails and crossmembers are not replaced separately.

Frame and Body Mounting

	4 6 6 7 6 8 7 6 8 7 8	
Item	Part Number	Description
1	N802289	Spacer
2	1000145	Split Shim
3	1000192	Upper Insulator Assembly
4	1000193	Lower Insulator Assembly
5	N800442-S428	Bolt
6	—	Frame Rail (Part of 5005)
7	8A297	Radiator Support
8	N621946-S2	Nut and Washer
0	11021940-32	

Item Part Number Description		
ltem	Part Number	Description
1	N802289-S2	Spacer/Washer
2	1000192	Upper Insulator Assembly
3	1000193	Lower Insulator Assembly
4	—	Frame Rail (Part of 5005)
5	11135	Front Floor Panel
6	N808698-S100	Bolt

Item Part Number Description			
Item	Part Number	Description	
1	N808698-5100	Spacer/Washer	
2	1000192	Upper Insulator Assembly	
3	1000193	Lower Insulator Assembly	
4		Frame Rail (Part of 5005)	
5	11135	Front Floor Panel	

))) (N0333-A
Item	Part Number	Description
1	N808698-S100	BOIL
2	N802289-S2	Spacer/Washer
3	1000192	Upper Insulator Assembly
4	1000193	Lower Insulator Assembly
5		Frame Rail (Part of 5005)
6	11215	Rear Floor Panel

1 4		
ltem	Part Number	Description
1	11215	Rear Floor Panel
2	1000192	Upper Insulator Assembly
3	1000193	Lower Insulator Assembly
0		,
4	_	Frame Rail (Part of 5005)

Frame Maintenance — Rivet Removal

CAUTION: Do not drill outside the rivet into the frame as that will weaken the frame.

NOTE: Rivets that are removed will be replaced with the next larger size bolts.

1. Drill a 3.17 mm (1/8 in) pilot hole through the rivet.



2. Drill a 8.73 mm (11/32 in) hole through the rivet.



3. Remove the rivet head.



4. Drive out the rivet with a punch.



5. Remove the support.

Frame Maintenance — Rivet Replacement

NOTE: Rivets that are removed will be replaced with the next larger size bolts.

1. CAUTION: Drill only where a rivet was removed.

Drill a bolt hole in the support and the frame.

- Line drill a hole the size of the bolt through the old rivet hole (that is, for 11.1 mm [7/16 in] diameter rivets, use a 12.7 mm [1/2 in] drill).
- 2. Position the support.
- 3. Insert the bolts, nuts and washers (Property Class 9.8 metric [Grade 8]) in the drilled holes.
- 4. Tighten the bolts.

2000 Explorer/Mountaineer Workshop Manual

Frame Maintenance — Drilling Precautions

- 1. If a hole must be drilled in the frame, make sure the hole meets the following requirements:
 - The hole is at least the specified distance from the edge of the nearest hole.
 - The edge of the drilled hole is at least the specified distance from the edge of the flange.
 - The hole is at least the specified distance above the frame centerline.
 - The drilled hole is at least the specified distance from any other existing bracket or component of the frame.



2000 Explorer/Mountaineer Workshop Manual

Frame Maintenance —Welding Precautions

- 1. If welding must be done on a frame, make sure the following requirements are met:
 - If the frame is attached to the vehicle, the battery ground cable (14301) must be disconnected before using any electrical welding equipment. For additional information, refer to 414-01.
 - Do not use gas welding equipment; arc welding is the only approved method.
 - Use a temperature-indicating crayon to make sure that the temperature does not exceed 750° C (1,400°F).
 - Install new spot-welded components by spot welding where possible. If spot welding is not possible, use puddle welding.

Frame Maintenance — Frame Straightening

1. **WARNING:** Straightening of front frame rail convolute is prohibited. Failure to follow these instructions may result in personal injury.

When straightening the frame, make sure the following requirements are met:

• CAUTION: Reposition and/or shield any fuel lines, brake lines, or wiring harness or component in the heated area.

If heat is needed to straighten a frame member, keep the temperature below 650° C (1,200° F) (a dull red glow). A temperature sensitive thermal melt crayon should be used to monitor heat buildup.

- Heat should be kept to a minimum area so that the hardness of the metal will not be affected.
- Straightening should only be attempted on frames that fail to meet specifications of the diagonal checking method or where damage is apparent.
- Straightening should be limited to parts which are not severely bent.
- Reposition and/or shield any fuel lines, brake lines, or wiring harnesses or components in heated area.

2000 Explorer/Mountaineer Workshop Manual

Frame Maintenance — Frame Reinforcing

NOTE: The frame must be straightened before any reinforcing can be started.

 After a bent frame member has been straightened, inspect the frame member closely for cracks. If any cracks show, the frame member should be reinforced or replaced. Reinforcements should be made from angle or flat stock of the same material and thickness as the frame member being reinforced, and should extend to either side of the crack. Ideally, the reinforcement should be cut from the corresponding area of a similar frame.



Underbody Misalignment Check

Two Door Frame Dimensions



Four Door Frame Dimensions



3	—	4529.7 mm (178.3 in)
4	—	792.96 mm (31.2 in)

1. CAUTION: Do not correct serious misalignment with one jacking operation. Align each section proportionately until the proper dimensions are obtained.

NOTE: To ensure accurate measurements, remove all trim from the reference points to expose bare metal.

To align or square a body, take two opposite diagonal measurements between pillars. Take measurements between reference points such as crease lines or weld joints which are diagonally opposite each other on the two pillars being measured.

- 2. When repairing a vehicle with damage on both sides, take horizontal and vertical measurements from an intact Explorer or Mountaineer vehicle and transfer the dimensions to the damaged vehicle. Alignment can be made by diagonal measurements taken from points on two pillars.
- 3. The dimensions of the underbody must be restored in repairing major body damage to provide correct front and rear wheel geometry. Once the frame and suspension members are aligned, other repair operations can be performed.

SECTION 502-02: Full Frame and Body Mounting REMOVAL AND INSTALLATION

2000 Explorer/Mountaineer Workshop Manual

Support

Removal and Installation

For additional information, refer to Frame Maintenance—Rivet Replacement in this section.