



MARK ROBERTS MOTION CONTROL

# BOLT X



## QUICK START GUIDE

QSG Product Code: MRMC-2253-00

Products Covered: MRMC-2023-00, MRMC-2080-00

---

# Bolt X Quick Start Guide

QSG Product Code: MRMC-2253-00

Products Covered: MRMC-2023-00, MRMC-2080-00

Document version: BOLT-X-QSG-20012022

© 2022 Mark Roberts Motion Control Ltd. All rights reserved.

No part of this publication may be reproduced, transmitted, or translated by any means — graphical, electronic, or mechanical — including photocopying, recording, taping, or storage in an information retrieval system, without the express written permission of Mark Roberts Motion Control.

Although every care has been taken to ensure that the information in this document is accurate and up to date, Mark Roberts Motion Control continuously strives to improve their products and may make changes to the hardware, firmware, and software described in this document. Mark Roberts Motion Control therefore cannot be held responsible for any error or omission in this document.

All product names mentioned herein are the trademarks or registered trademarks of their respective owners.

| Contact information                     |                                                                                        |
|-----------------------------------------|----------------------------------------------------------------------------------------|
| <b>Mark Roberts Motion Control Ltd.</b> |                                                                                        |
| Unit 3, South East Studios              |                                                                                        |
| Blindley Heath                          |                                                                                        |
| Surrey                                  |                                                                                        |
| RH7 6JP                                 |                                                                                        |
| United Kingdom                          |                                                                                        |
| Telephone:                              | +44 (0) 1342 838000                                                                    |
| E-mail:                                 | info@mrmoco.com (sales and general enquiries)<br>support@mrmoco.com (customer support) |
| Web:                                    | www.mrmoco.com<br>www.mrmocorentals.com                                                |

# Contents

|                   |                                                                                    |           |
|-------------------|------------------------------------------------------------------------------------|-----------|
| <b>Chapter 1</b>  | <b>Quick Start.....</b>                                                            | <b>1</b>  |
|                   | Overview .....                                                                     | 1         |
|                   | Safety procedures for using industrial robots,<br>including high speed track.....  | 2         |
|                   | Assessing a site .....                                                             | 3         |
|                   | Installation safety .....                                                          | 4         |
|                   | Software setup .....                                                               | 6         |
|                   | Operational safety .....                                                           | 6         |
|                   | Mounting the Yaskawa arm .....                                                     | 8         |
|                   | Mounting the weight wings .....                                                    | 9         |
|                   | Anchoring Bolt X On Pedestal to the floor .....                                    | 10        |
|                   | Attaching the track motor pinch wheel to Bolt<br>(Family of Robots) On Track ..... | 14        |
|                   | Connecting the cables — Bolt X On Pedestal .....                                   | 16        |
|                   | Connecting the cables — Bolt X On Track.....                                       | 18        |
|                   | Bolt X arm connectors for Ulti-box and camera .....                                | 21        |
|                   | Starting up the Bolt X system .....                                                | 22        |
|                   | Bolt X start-up summary .....                                                      | 24        |
|                   | Shutting down the Bolt X system.....                                               | 25        |
| <b>Appendix 1</b> | <b>Using Weight Plates with Bolt X on Track .....</b>                              | <b>27</b> |
|                   | Number of plates.....                                                              | 27        |
|                   | Using Bolt X without Track (with Weight Plates).....                               | 29        |
| <b>Appendix 2</b> | <b>Troubleshooting.....</b>                                                        | <b>32</b> |
|                   | Typical symptoms, causes, and actions .....                                        | 32        |
|                   | Checking when YRC1000 is ready.....                                                | 33        |
|                   | Switching Bolt X to Manual Mode.....                                               | 34        |
|                   | Moving the Robot in Manual Mode .....                                              | 35        |
|                   | Setting Bolt X Back to Remote Mode .....                                           | 36        |
|                   | Bolt X Recalibration.....                                                          | 36        |
|                   | Changing User Profile .....                                                        | 40        |
|                   | Second Home Position Check and Reset .....                                         | 41        |
|                   | Setting Joint Limits .....                                                         | 43        |
|                   | Moving the Bolt X Arm by Hand (Using Brake<br>Release Function).....               | 44        |
|                   | Checking if Yaskawa YRC1000 Output File is set to<br>Flair .....                   | 49        |

|                   |                                                          |           |
|-------------------|----------------------------------------------------------|-----------|
| <b>Appendix 3</b> | <b>Bolt X panels.....</b>                                | <b>50</b> |
|                   | Bolt X On Track base panel connector summary.....        | 50        |
|                   | Bolt X arm panels connector summary .....                | 52        |
|                   | 12VDC connector.....                                     | 54        |
|                   | 48VDC connector.....                                     | 54        |
|                   | Ulti-box connector summary.....                          | 55        |
|                   | Ulti-box connector pin-out information .....             | 58        |
|                   | Servo motor connector .....                              | 58        |
|                   | Program serial connector .....                           | 58        |
|                   | Power connector .....                                    | 59        |
|                   | Camera Accessory connector.....                          | 59        |
|                   | Data In connector .....                                  | 60        |
|                   | Brake 24V connector.....                                 | 60        |
|                   | Brake 24V connector.....                                 | 61        |
|                   | CAN connector .....                                      | 61        |
| <b>Appendix 4</b> | <b>Specifications.....</b>                               | <b>63</b> |
|                   | Physical Specification.....                              | 63        |
|                   | Range of Travel.....                                     | 64        |
|                   | Power requirements.....                                  | 64        |
|                   | Cable Colours .....                                      | 65        |
|                   | General Electric Data .....                              | 65        |
|                   | Earth.....                                               | 65        |
|                   | Earth Leakage Protection .....                           | 65        |
|                   | Power for Flair and PC (500W) .....                      | 65        |
|                   | Power Data by Country - United States of<br>America..... | 66        |
| <b>Appendix 5</b> | <b>Cleaning and Maintenance.....</b>                     | <b>67</b> |
|                   | General Care .....                                       | 67        |
|                   | Cleaning .....                                           | 67        |
|                   | Main Body and Arm .....                                  | 67        |
|                   | Cables .....                                             | 67        |
|                   | Pinchwheel.....                                          | 67        |
|                   | Track Gearbox.....                                       | 68        |
|                   | Track and Track Bearings .....                           | 68        |
|                   | Replacing the Pinch Wheel.....                           | 69        |
|                   | Replacing the Track Pinion.....                          | 71        |

## Chapter 1 Quick Start

### Overview

Thank you for using the Bolt X High-speed Cine-bot from Mark Roberts Motion Control (MRMC). Bolt X is designed for reliable day-in, day-out use in professional studio and Outside Broadcast environments. There are two versions of Bolt X:



**Bolt X On Pedestal** has a stationary base which you either hold down with weights or, for more permanent installations, attach to the floor.



**Bolt X On Track** has a base designed for moving along Precision Track. It has removable trolley wheels for moving between sets, and can also be held down with weights at temporary locations.

## Safety procedures for using industrial robots, including high speed track

Note that the words **Robot** and **Rig** are completely interchangeable and identical in meaning, for the purposes of this document.

Motion Control rigs are potentially dangerous. It is important that you and everyone else on the set understand the safety notes on the following pages in order to stay safe.

You should use this document in addition to the normal Safety Manual instructions that are applicable to all motion control rigs, such as Milos. This section emphasises the safety concerns that are especially important around high-speed, high-acceleration, industrial-grade robots which can cause severe injuries, such as Bolt X.

- Unlike traditional motion control equipment, Bolt X can get to maximum speed in the blink of an eye - too fast for someone to be able to quickly move out of the way.
- ⇔ If you are using Bolt X On Track then you need to take extra steps during installation and use due to the additional risks involved in using track. See the separate *Precision Track Quick Start Guide* for information on laying the track, securing it to the floor, and mounting Bolt X onto it. The notes given below for track users are marked with this symbol: ⇔.
- It is ultimately the **operator** of the rig who is responsible for the safe use of the equipment so never bypass any of the safety points listed here.
- No one other than a highly trained operator should use the robot, no matter how simple it looks or is.
- This document is for the use of robots for carrying cameras or props, not people. Additional safety steps should be taken prior to using a rig to carry people.

## Assessing a site

Before setting up Bolt X you need to **assess the site**, paying particular attention to the following points:

- Is the ground or floor firm enough and level enough? You might have to use boards or bricks to create a level surface. The surface needs to be strong enough to take the weight of Bolt X itself (630 kg for Bolt X On Pedestal, 830 for Bolt X On Track) plus the weight of the track (95 kg per section). The track must either be secured to the ground or to the weight plates supplied (2 plates per section=2x80 kg). If you are using Bolt X On Pedestal for high-speed moves then 400 kg of anchor weights on each corner are recommended.
- Does the site have access? You need to make sure you can either push Bolt X into position on its wheels or carry it there using a pallet truck or forklift.
- Does the site have a power source with sufficient capacity for the robot and the correct mains voltage?
  - Bolt X On Pedestal gets its power from the YRC1000 robot controller unit which runs **415 Volt, 32A, 50/60Hz, three-phase power supply (five-wire including Neutral and Ground)**.
  - Bolt X On Track requires one **415 Volt, three-phase power supply (five-wire including Neutral and Ground)** connections. It cannot be configured to run on less without significant loss of track speed performance.
  - The RTL/Flair computer that controls Bolt X (that is, the desktop computer and the power supply brick for the RT-14 interface box are auto-switching and can run on 120-240 Volts AC.
- Does the site have unusual environmental attributes that require specialised protection from extreme temperatures, humidity, rain, or dust?

## Installation safety

- Due to the large mass of the rigs and the accelerations they achieve it is important that they are securely mounted, with the recommended plates and bolts to a secure and concrete floor.
- ⇔ When using track, ensure that it is properly bolted to the floor. No amount of counterweight will stop the track from moving and twisting if the track isn't secured, especially with short lengths of track.
- ⇔ Make sure there is plenty of clearance around the length of the track for the trailing cables of the rig to slide along the floor. Ensure that they are not mounted in such a way so that they can catch on the track or robot as it moves along the full length.
- Ensure the floor can support the load and the stresses (see above).
- Ensure the power supply is properly earthed (grounded) and of the correct voltage (see above).
- If the rig is mounted to something other than the floor then the mount should be heavy and strong enough to take the forces and not move or fall over during sudden starts and stops. Use the recommended minimum thickness steel plates. Check with MRMC if you are unsure of the exact requirements for your robot.
- Check that all cables are securely fixed and are not going to catch during motion.
- Ensure the camera, lens, focus motor, accessories, power supplies/batteries, etc. are all very securely mounted and will not come off during sudden motions, to become lethal missiles.
- Ensure all safety accessories are securely attached and in working order, including emergency stops, safety sensors, etc.
- Clearly mark the area around the robot in which no persons are allowed to enter. As a bare minimum, use brightly marked tape on the floor, outside the reach of the robot, to indicate the "No Go Zone". Ideally, use physical safety barriers, and light guards/curtains.

- Keep stands, lights and accessories out of the No Go Zone, if possible. If not possible then try to take as much care with their positioning and the motion of the rig, as if they were a person. Remember a light, accidentally hit at high speed by the robot, can be just as dangerous to someone standing outside the No Go Zone as the robot is to someone standing in the zone.
  - Where physical safety barriers are impractical, light guards should be used or similar alternatives such as laser scanners, to stop anyone entering the No Go Zone during motion.
  - Ideally have the robot surrounded on all four sides by a safety barrier, but where that is not practical, ensure that the maximum number of sides feasible are closed off, and that any person having to stand within reach of the robot is located as far away as possible for the shot.
- ⇔ Never let anyone cross the robot's track when the track motor is powered up. In fact, it is a good idea to get into the routine of walking around the track instead of over it so that you don't cross the track out of habit when the track motor is powered up.

**WARNING!**

For Bolt X on Track on location, a generator capable of at least 50KW along with other high power equipment connected to the same generator is recommended.

This is due to the regenerative circuit in the Yaskawa YRC1000 controller. If the generator is not capable to absorb the excess energy produced by robot hard decelerations, especially on track, some component in the controller may be damaged and would need to be replaced. This kind of damage is not covered by either Yaskawa or MRMC warranty.



## Software setup

- Always ensure you have the right configuration for the robot you are using, such as maximum axis speeds and accelerations.
- Also check the Cartesian speed and acceleration limits are set to reasonable values.

## Operational safety

- Do not use around flammable gas. All electrical equipment can generate sparks that can ignite flammable gas.
- Keep the equipment dry. The system has **not** been made weatherproof. Do not use with wet hands.
- Always run moves only when standing within easy reach of the emergency stop.
- Always tell the production company and the crew to keep away from the robot and not approach it when any of its red lights are on which indicates it is powered up. Have them sign the appropriate safety documents and disclaimers to ensure they understand this and are indemnifying MRMC if anything happens.
- Always loudly and clearly indicate to others when the rig is about to move. Shout “Rig Moving!” if no other means exists.
- ⇔ When using track motion always have someone keep an eye on the trailing rig cables to ensure they don’t get caught on anything or anyone.
- Always ensure the rig is disabled when someone has to enter the No Go Zone.
- Always run any move or adjusted move slowly at first to check the motion. Even if you have checked the move previously, if you make a minor change to it then you need to recheck it.



- Keep the software in “slow mode” unless the move has been tested and is now specifically doing a high speed pass.
- In the event that a person or Actor has to be within the no-go zone during a move (hand model etc.) ensure that they fully briefed on the safety requirements and that they know not to change their position or do anything other than the rehearsed moves without fully warning the operator. Any such person is to have a clear escape route to allow them to move safely away from the robot.
- During use, repeatedly check the rig mounting points, cables, camera mount, accessories etc. to ensure nothing has, or is, working its way loose.
- Never bypass any safety hardware or software.

## Mounting the Yaskawa arm

1. Remove all packaging from the Bolt X arm and the pedestal. If not already added, attach the two mounting plates on the arm using 4 x M12 screws on each side. Ensure that each plate is mounted on the correct side.
2. Securely attach shackles on each of the four corners of the lifting plates.
3. Use the shackles to tie a lifting sling around the arm and insert the hook from the gantry hoist on to it.



4. Wheel the Bolt X base under the gantry hoist.

5. Use the gantry hoist to gently lift the arm and lower it in position on the Bolt X base aligning the screw slots.



6. Tighten the 8xM20 screws to secure the arm on the Bolt X base.
7. Remove the gantry hook and the straps from the arm. Also, remove the yellow lifting plates from the arm.

## Mounting the weight wings

If you want to use Bolt X in a stationary position that is temporary (or if you don't want to damage the floor by installing anchors in it), you must weigh down the Bolt X base to keep it stable during high-speed moves. To do this you install wings on the base, which lie flat on the floor, and then put weights on the wings to securely hold down the rig.

1. Use a pallet truck for Bolt X On Pedestal to lift Bolt high enough to go over the wings (about 10 cm).
2. Lay one of the wings beside the Bolt X base and push the edge of the wing over the edge of Bolt X, lining up the four holes.

3. Lower the base close to the wing but not quite resting on it, close enough for the five retaining bolts to reach the wings through the base.
4. Insert the four retaining bolts (two on each corner of the base) and tighten. Note that some versions have locknuts.
5. Repeat steps 1 to 4 to mount the other wing.
6. Lower the base completely so it is resting on both wings.
7. Put the weights onto the wings. Bolt requires 800kg of weights on both sides.

Bolt X On  
Pedestal with  
wings and  
weights



### Hint

You can move Bolt X using a pallet jack without removing the wings if you want, as long as you take the weight plates off first.


## Anchoring Bolt X On Pedestal to the floor

If you are setting up Bolt X On Pedestal in a permanent (or semi-permanent) location, it is recommended that you anchor the pedestal to the floor. If this is not possible, as an alternative you can hold


it down with weights. The following procedure tells you how to anchor the pedestal to a concrete floor.



× 4 corners



× 4 corners



× 4 corners

1. Temporarily put the Bolt X On Pedestal into place where you want.
2. At one corner of the pedestal, use one of the two holes to draw a circle on the concrete with a pencil, to mark the position of the hole. You can use either hole.

Repeat for the other three corners of the pedestal.

3. Temporarily remove Bolt X On Pedestal and at one of the four circles that you have drawn, draw a cross centred on the circle, to help you precisely locate the drill bit.



Repeat for the other three corners.

4. On the 20mm diameter drill bit, put tape around the bit 5 cm from the tip. This will help you gauge the depth of the hole in the next step.
5. At one of the corner circles, drill a hole 5 cm deep into the concrete, centred on the cross. When the tape on the drill bit reaches the floor, drilling is complete.

Repeat for the other three corners.


6. Clean the four holes.

7. At one of the holes insert the drop-in anchor insert, threads upward, all the way to the bottom.
8. Insert the anchor spreader tool into the drop-in anchor insert.
9. Hit the top of the anchor spreader tool with a hammer until the anchor is fully spread in the concrete.
10. Remove the anchor spreader tool.
11. Repeat steps 7 to 10 for the other three corners.
12. Put Bolt X On Pedestal in place over the holes.
13. Insert the four retaining bolts (M16) through the corners of the base and into the drop-in anchor inserts, and tighten.




Notes

## Attaching the track motor pinch wheel to Bolt (Family of Robots) On Track




1. On the separately supplied pinch wheel assembly, remove the brass retaining pin by pulling on the ring.
2. Mount the pinch wheel assembly onto the track motor on the rig underside, by sliding the track motor gear against the rack and putting the pinch wheel Socket onto the track motor Mounting bar.
3. Replace the retaining pin in the pinch wheel assembly by pushing on the ring (not the sleeve), to hold the assembly in place on the track motor.
4. Ensure that the track motor gear is held firmly against toothed side of the rack. If it is not, then push the pinch wheel assembly slightly towards the rack so that the rubber wheel presses firmly against the smooth side of the rack. Check that the space between the black plastic block behind the rubber wheel and racking after mounting the pinch wheel assembly is less than 1mm.


5. Insert the small side of an allen key in the cavity on the block of the pinch wheel assembly and using the allen key pull the block towards the racking.




6. Plug the pinch wheel cable to the socket on the rig underside, and use cable ties to hold it securely up away from the track, if required.


# Connecting the cables — Bolt X On Pedestal





# Connecting the cables — Bolt X On Track






**Important**

The Jumper\* in the Safety PLC applies when using this robot as a single robot operation. For more information on using the Universal Robot system with multiple robots, refer to the Universal E-stop System Quick Start Guide.

The desk top E-stop box can also be daisy-chained to multiple E-stop buttons. For more information, refer to Universal E-stop System Quick Start Guide.

# Bolt X arm connectors for Ulti-box and camera

The connections that go through the Bolt X arm are shown below. These are for the Ulti-box mounted on the arm, and for the camera that you mount in the cage at the end of the arm.



## Starting up the Bolt X system

Once you have attached all the cables, you power up the Bolt X rig by switching on the components in the order described below.

1. Make sure you have secured the area around Bolt X. Put up guard rails around Bolt X (and the track) as necessary, and tell others on the set that you are now powering up the rig.



2. Release the E-stop that is plugged into the **YRC1000 teach pendant** (twist and pull) and also the E-stop that is on the **Bolt X base** (if using Bolt X On Track) by turning the red button clockwise until the button pops up. **Do not release the other E-stop by the computer stack yet.**



3. Ensure that the bypass jumper is plugged in the Bolt X base side panel. The panel can be accessed by undoing 4 x screws and removing the cover.



Bypass jumper

4. If the teach pendant is plugged in the side panel instead of the bypass jumper, ensure that the key in the YRC1000 teach pendant is pointing to **REMOTE** and not to **TEACH** label. (It is recommended that when moving the robot under normal circumstances, the teach pendant is replaced with the bypass jumper.)



5. Power up Bolt X itself as follows:

For Bolt X on Pedestal,  
power on the YRC1000  
controller unit



The pendant shows the boot up  
sequence which normally takes about  
1 minute. For more, refer to *Checking  
when YRC1000 is ready* on page 33.

For Bolt X On Track, turn  
on the power switch on the  
side of the Bolt X Base.



6. Power up the Ulti box. Both input and output switches on the power supply need to be switched on.
7. Power up other connected devices, if applicable, such as the Motionbase or the XL Turntable. Note that there is no particular order in which these need to be powered up.
8. Power up the Flair PC and all of its components.
9. Check INtime is running on the Flair PC.
10. Launch Flair. After software boot up is complete, ensure that the green network and node lights are illuminated in Flair. Reload if necessary.
11. Release the E-stop that is plugged into the computer stack, by turning the button clockwise until the red button pops up and then pressing the Enable button. Also make sure the key on the PLC box is in the vertical position (RED led must be off). Green LED on the E-stop box should come on.
  - 11.1 The Green LED on the safety box should also come on.
  - 11.2 (pedestal only) The Yellow LED on the YRC cabinet should also come on.



Reset  
button

The robot is now ready to be enabled in the software.

## Bolt X start-up summary

1. Secure the area
2. Release the E-stop on the rig
5. Switch on all the equipment on the system
5. Switch on the Flair PC
6. Start Flair
7. Release the E-stop on the computer stack

In Flair:

8. **Engage Robot**
9. Send the arm to Home position, carefully
10. Zero the track (if applicable) and Lens Control Motor axes.
11. Set the soft limits

The rig is now ready to use.

## Shutting down the Bolt X system

1. Move Bolt X to its Home position, for both the arm and the track (if using Bolt X On Track).

or...

If you are going to transport Bolt X to a new location, put the Bolt X arm into its transport position. You can do this either by using Flair (although you might have to reset the soft limits to reach the transport position).

2. In the Flair software, click on the **Disengage Robot** button.
3. In the Flair software, disengage the track by toggling off the **Track** button.
4. Press down all E-stop buttons:
  - On the computer stack
  - On the **YRC1000 controller unit** (if using Bolt X On Pedestal) or on the **Bolt X base** (if using Bolt X On Track)
5. Close the Flair software.
6. Shut down Windows on the Flair PC.
7. Turn off any peripherals. Turn off Bolt X as follows:

Turn off the power switch on YRC1000.



For Bolt X On Track, turn off the power switch on the side of the Bolt X Base.



To remove Bolt X On Track from the track see *Mounting Bolt (family of robots) on the track* in the separate *Precision Track Quick Start Guide* and follow the instructions there in reverse order, to attach the trolley wheels, detach the pinch motor wheels and remove the rig from the track bearings.



## Appendix 1 Using Weight Plates with Bolt X on Track

If you are using a fast robot with a long arm, such as Bolt X on Track, it is recommended that you hold the track down by bolting it to the ground as above. If that is not feasible, use the weight plates to lay under and then bolt the track on to the weight plates.

They are not a full substitute for a rigid fixing to a ground anchor and will not provide the same stability. Caution should therefore be exercised when using weight plates alone to stabilise a system.

MRMC have empirically tested the Bolt X to a **maximum speed of 180deg/s** on Joint 1 of the rig. A 6-plate system will provide the required safety at this speed.

Note that this speed is highly unlikely to be practical in normal operation of the rig with weight plates only due to the movement which will occur, making it unsuitable for filming.


To avoid any significant gaps in the weight plate system for longer runs greater than 6 lengths an additional 1 plate per length of rail is required. For more detail on how to lay the track and weight plates, refer to *Precision Track Quick Start Guide*.

### Number of plates


- Two plates for each 3m section of precision rail up to 3 sections.
- For systems with more than 3 sections of 3m rail 6 plates should be used up to a maximum of six sections, spaced evenly.
- For more than 6 sections 1 additional plate per section is required.
- For systems with less than 3 rail sections additional stabilising weights must be used, equivalent to 6 plates.

| Rail Sections | Plates Required        |
|---------------|------------------------|
| Upto 3        | Equivalent of 6 plates |


| Rail Sections | Plates Required                           |
|---------------|-------------------------------------------|
| 3 to 6        | 6                                         |
| More than 6   | One plate per rail section, spaced evenly |




1 section = 6 plates or equivalent



3 sections = 6 plates



5 sections = 6 plates




8 sections = 8 plates




## Using Bolt X without Track (with Weight Plates)

1. Ensure that the Bolt X is not on track and can be wheeled on its jacking castors.
2. Lay the first weight plate on the floor, in a position that will be the rear of the Bolt X turret, across the “facing front” direction.



3. Lay the second weight plate on the floor in front of this and carefully position it so the threaded holes along the long centre axis of the plate are 800mm apart between the two plates. Do not use the floating retainers as they are inexact and are used only for fitting rail.
4. Add the supplied 4 x ramps to the first weight plate the Bolt X will be wheeled on to.
5. While carefully aligning and keeping the wheels straight, wheel the Bolt X over the first plate.
6. Once the first pair of wheels has rolled over the first weight plate, remove the 2 x ramps from the inner edge of the weight plate and add them to the inner edge of the next weight plate.

7. Still keeping the wheels straight, wheel the Bolt X so it climbs the second weight plate using the ramps.




Screw cavities on the Bolt X base should align with those in the weight plates underneath

8. Drop the screws in the Bolt X base screw cavities and, if required, adjust the weight plates below so that the screws line up. You will need to raise the jacking castors so the Bolt X Base rests on the weight plates. Once the screws have lined up, secure them.



9. Stack 4 x weight plates perpendicular to the weight plates, already positional under the robot, as additional weights making a total of 6 x weight plates.



10. Remove the casters and align the holes in the side of the added two weight plates each side with the holes in the original plates and screw them together.

## Appendix 2 Troubleshooting

### Typical symptoms, causes, and actions

**Note**

The YRC1000 teach pendant should only be used for troubleshooting purposes and should not be used for normal operation of the rig. The teach pendant is not related to Flair/RTL in any way and is not an interlace to MRMC Bolt system.

| Symptoms                                                                          | Cause and/or action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flair fails to establish a network connection to the Bolt X controller (YRC1000). | <p>Try a different cable. The Ethernet cable between the Flair PC and YRC1000 (for Bolt X On Pedestal) and in the umbilical between the Flair PC and Track Base (for Bolt X on Track) needs to be a high quality, fault-free, straight-through (that is, not cross-over) Ethernet cable.</p> <p>Check that all cables are connected correctly (page 16 and page 18) and that all devices, including the Ethernet hubs, have power.</p> <p>Make sure you have allowed enough time for the Bolt X/YRC1000 unit to completely power up.</p> <p>When you touch the Teach pendant, the screen should turn on. Check the panel of the pendant to see that the robot is not in booting sequence. (See <i>Checking when YRC1000 is ready</i> on page 33.)</p> <p>Check that INTime is running.</p> <p>Check that the network socket where the hub is connected to the PC is under INTime.</p> |

| Symptoms                                                                             | Cause and/or action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Bolt X axes won't move<br><br>Cabled properly but there seems no power in the robot. | <p>Make sure you have enabled Bolt in Flair/RTL (click on the <b>Engage Robot</b> button).</p> <p>Ensure that the Orange LED on YRC1000 is on.</p> <p>Switch the key in the teach pendant to <b>TEACH</b> position. Try to move the arm using the Teach Pendant:</p> <ol style="list-style-type: none"> <li>1. On the Teach pendant, press the Servo On Ready button. The Servo On LED will start blinking.</li> <li>2. Press the Deadman's handle half way. This will turn the motor on the robot on.</li> <li>3. Press + or - for individual joints.</li> </ol> <p>Remember to replace the Teach Pendant key to <b>REMOTE</b> position after you have fixed the issue.</p> |
| Robot is engaged but the axes remain grey and do not move.                           | <p>Check the Second Home Position and reset. See <i>Second Home Position Check and Reset</i> on page 41.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

## Checking when YRC1000 is ready

The robot teach pendant is housed inside the Bolt X on Track base. To access it, undo screwsx11 and remove the cover. Remember to replace the pendant and the cover after you have used it.



After switching on YRC1000, on the pendant, in the Job menu, make sure no error message is displayed at the bottom of the screen. (Function buttons should be blank.)



## Switching Bolt X to Manual Mode

You can run the Bolt X in manual mode without using Flair.

1. Ensure that YRC1000 is powered up and booted.
2. Switch the key on the pendant to 'Teach' position.
3. If the E-stop cable as well as the rest of the system are still connected, switch the key on the safety PLC to horizontal position to bypass Flair (red LED will come on).
4. Alternatively, if the safety PLC is not available, you can use Bypass Estop box [20529] and connect it directly to the umbilical.



5. Ensure that the E-stop on the pendant is released and there are no error messages on the pendant.
6. Release the desk E-stop, or the Bypass Estop, by twisting the big red button engage the robot by pressing the small reset button.

## Moving the Robot in Manual Mode

1. Press the **Servo On Ready** button on the pendant. The **Servo ON** light should start blinking.
2. Press the Dead Man's Handle at the rear of the pendant half way to turn the robot on..

### Note

If you release the deadman's handle, the robot will power off. Press the **Servo On Ready** button on the pendant and the deadman's handle half way again to power up the robot.

3. Use the axes buttons X to Z, shown, to move the joints on Bolt X.



### Note

When moving an axis using the pendant, be careful, as the direction might be reversed with respect to Flair.

To move the Bolt X base or to switch from moving Rotate to Track, press the **Ex Axis** button. To switch to moving Rotate axis, press the **Robot** button.

4. Use the Slow and Fast button to change the speed of the axes movement.

## Setting Bolt X Back to Remote Mode

1. Switch the key in Safety PLC back to vertical position.
2. Switch the key in the teach pendant back to “Network” position.
3. If you are using the Bypass Estop box [20529] instead of Safety PLC, replace it with Safety PLC.
4. If you still cannot engage and move the robot in Flair, restart Flair.

## Bolt X Recalibration

The robot should never lose calibration. However, the following are the examples of situations that the robot might lose calibration:

- After a hardware crash.
- The batteries inside the encoder keep the encoder position saved at all times even when the power to the robot is off. If the batteries run out then the encoder position will be lost.



Battery housing

- If any of the encoder cables is unplugged then the encoder position will be lost.



Encoder cable


- If you try to change the encoder batteries when the power to the robot is off then also the encoder position will be lost.
- When you connect the base to a different arm or vice versa.

Use the pendant to check if the axes zero properly (the Current Position of all axes should be less than 1000 pulse indicating they are close to zero.) To do this:

1. Align the arrows on the arm by eye to bring it to zero position as accurately as possible (this can be done either with the software or the pendant in Manual Mode).
2. Go to **MAIN MENU** → **ROBOT** → **CURRENT POSITION**. Check that the value is close to zero.
3. If one axis is not zero, change the User Profile to **Safety Mode**. Refer to *Changing User Profile* on page 40 for more information.




6. A message appears when you press **Select**. Select **Yes**.



The values in the ABSOLUTE DATA column will not change as they are absolute values. It is the current position values that will change.

7. Select **MAIN MENU** → **ROBOT** → **CURRENT POSITION**. The axis is changed to 0.



## Changing User Profile

1. Select **MAIN MENU** → **SYSTEM INFO** → **SECURITY**.



2. You will be presented with a list of user profiles. Select the desired user profile.



3. Enter the password for the user:
  - Management Mode Password: 999999999
  - Safety Mode Password: 555555555
4. Press the **Enter** key on the keypad.

## Second Home Position Check and Reset

When the robot is turned off, it stores the current position as the 'second home position'. An example scenario can be after a transport move the motors can move slightly and therefore the current axis position can change in the Second Home Position page. This might generate an error due to a mismatch between the memorised position and actual position. For example, when Flair is started and the robot is engaged, the robot will engage successfully but all axes would become 'grey' in Flair again and you might not be able to move them. To resolve this issue:

1. Switch to **Manual Mode**.
  - 1.1 Ensure that YRC1000 is powered up and booted.
  - 1.2 Switch the key on the pendant to 'Teach' position.
  - 1.3 If the E-stop cable as well as the rest of the system are still connected, switch the key on the safety PLC to horizontal position to bypass Flair (red LED will come on).
  - 1.4 Alternatively, if the safety PLC is not available, you can use Bypass Estop box [20529] and connect it directly to the umbilical.



- 1.5 Ensure that the E-stop on the pendant is released and there are no error messages on the pendant.
  - 1.6 Release the desk E-stop, or the Bypass Estop, by twisting the big red button engage the robot by pressing the small reset button.

2. Press the Dead Man's Handle at the rear of the pendant half way to turn the robot on. and release to turn it off.

**Note**

If you release the deadman's handle, the robot will power off. Press the **Servo On Ready** button on the pendant and the deadman's handle half way again to power up the robot.

3. Select **Main Menu** → **Robot** → **Second Home Position**.
4. Move all axes to the SPECIFIED POSITION so that the values in the DIFFERENCE column are zero or close to zero. To do this enable the robot and press and hold **FWD**. Use the Fast/Slow buttons to alter the robot speed during this movement. The axes will all move to stored second home position so that the values in the Current position column are the same as those in the Specified position column and the Difference will be 0. Sometimes, you might need to move each axis individually.



If you want to move the Base, move from ROBOT to EX. AXIS.



5. Press **DATA**.
6. Click on Confirm Position. You might need to do this twice.  
The error should now clear.
7. Switch the key back to 'Remote' and engage Flair in the usual way.


## Setting Joint Limits

1. Switch user profile to Safety Mode.
2. Select **MAIN MENU** → **ROBOT** → **SOFT LIMIT SETTING**.



3. Select the limit setting and enter a new setting. (Values are in pulses)

Joint T (Roll) is 100000, which is approximately 180°.



## Moving the Bolt X Arm by Hand (Using Brake Release Function)

In certain situations, it might be pertinent to move the robot arm by hand. This can be in a situation, for example, when momentum or a programming error moves the arm against its internal hard limits or if the camera platform gets stuck against another part of the arm, the motors might not be able to move from this position without tripping out. To move the Bolt X arm by hand:



### WARNING!

Brake release mode can lead to unforeseeable arm movements.

1. Ensure that YRC1000 is powered up and booted.
2. Switch the key on the pendant to 'Teach' position.
3. If the E-stop cable as well as the rest of the system are still connected, switch the key on the safety PLC to horizontal position to bypass Flair (red LED will come on).

4. Alternatively, if the safety PLC is not available, you can use Bypass Estop box [20529] and connect it directly to the umbilical.



5. Ensure that the E-stop on the pendant is released and there are no error messages on the pendant.
6. Release the desk E-stop by twisting the big red button engage the robot by pressing the small reset button.
7. Select **MAIN MENU** → **SYSTEM INFO** → **SECURITY**.



8. You will be presented with a list of user profiles. Scroll to **Safety Mode** and press **Enter**.



9. Enter the password for the Safety Mode user: 555555555
10. Press the **Enter** key on the keypad.
11. Navigate to **Robot** → **Manual Brake Release**. Scroll to find the option, if required. Select **Yes** for confirmation.




12. Scroll down to the axis for which the brake needs to be released.



**WARNING!**

It is important that the desired axis is highlighted and people are prohibited in the isolation area around the robot. Brake release mode can lead to unforeseeable arm movements.



13. Simultaneously press deadman's handle to half position and **Interlock** + **Select** buttons. The brake releases on the highlighted axis and is ready to be moved by hand.



**WARNING!**

Exercise extreme caution when using Brake Release function as unexpected movement of the robot can cause damage to both personnel and equipment.




## Checking if Yaskawa YRC1000 Output File is set to Flair

The Yaskawa YRC1000 is set to communicate with Flair in the factory. If for some reason, this has changed then the robot will fail to communicate with Flair. The file names used for Flair is Flair2Motoman.out. To check this setting:

1. Turn on the robot (YRC1000).
2. In the Pendant, select **MAIN MENU** → **JOBS** → **JOB**.
3. The Job name should be FLAIR. If the Job name is RTOS then the system needs to be configured for Flair. Contact MRMC if this is the case.

## Appendix 3 Bolt X panels


### Bolt X On Track base panel connector summary



1. **240V AC** output, for general use by additional devices that you want to mount on the base.
2. **VIDEO 1 IN** input connector for the video 1 signal from the camera. This has a straight-through internal connection to the **VIDEO 1 OUT** connector (6).
3. **VIDEO 2 IN** connector for the video 2 signal from the camera. This has a straight-through connection to the **VIDEO 2 OUT** connector (7).
- 4 and 9. **ULTI ETHERNET IN** and **ULTI ETHERNET OUT** connectors for communications between Ulti box on the arm and Ethernet hub via the umbilical cable.
5. **48V DC** power connector. You usually use this to power the Ulti-box (and its attachments) on the Bolt arm, by attaching a cable from this connector to the 48V connector on the arm.
6. **VIDEO 1 OUT** connector for the video 1 signal from the camera. This has a straight-through connection to the **VIDEO 1 IN** connector (2).
7. **VIDEO 2 OUT** connector for the video 2 signal from the camera. This has a straight-through connection to the **VIDEO 2 IN** connector (3).

8. **ROBOT** connector. You use this to connect the robot Controller YRC1000 inside the Bolt X base, via the umbilical cable, to the hub in where the Flair PC is connected
10. **E-STOP** connector. You connect this to the PLC via the umbilical cable.

## Bolt X arm panels connector summary



1. **Camera** connector is an Ethernet connector or communications between the camera and the rest of the system. The connection between these two connectors is a straight-through internal connection through arm.
2. **Ulti** connector is an Ethernet connector or communications between the Ulti box on the robot arm and the rest of the system. You ordinarily attach this to the Ethernet connector in Bolt X base (for Bolt X On Track).
3. **VID 1** output connector for the video 1 signal from the camera. This can be connected to the **VIDEO 1 IN** connector on the Bolt X base.
4. **VID 2** output connector for the video 1 signal from the camera. This can be connected to the **VIDEO 2 IN** connector on the Bolt X base.
5. **12 V DC** input power connector. You can use this to power the camera or other devices mounted on the camera platform.
6. **48V DC** input power connector supplies 48 Volts DC output to the Ulti box on the Bolt X arm. This has a straight-through internal connection to the **Ulti-box input** connector.


7. **YRC1000 power and controller** connector. This is for the encoder and power cable that runs between the Bolt X arm and the YRC1000 controller unit, which supplies control to the arm.

## Bolt X arm connector pinout information

### 12VDC connector

This type of connector is used to power the camera through the robot arm.


1. GND
2. +12-24V
3. Not used



### 48VDC connector

This type of connector is used to power the camera through the robot arm.

1. GND
2. Not used
3. +48V



# Ulti-box connector summary

The Ulti-box that is mounted on the Bolt X arm is a multi-purpose interface box that is used to control servo motors on many MRMC heads and Lens Control Motor (LCM) units. The Ulti-box offers versatile connections for many camera and lens configurations although some of the axes connectors such as **PAN**, **TILT**, and **DATA** are not ordinarily used in the context of Bolt X, as Bolt X itself provides these features.



1. **PAN** connector for the Pan servo motor on a head. For pin-out information see *Servo motor connector* on page 58.
  2. **PROG** serial connector for connection to a controller using a Serial RS232 connection (as an alternative to an Ethernet or DataLink connection), and for updating the firmware in the Ulti-box. For pin-out information see *Program serial connector* on page 58.
  3. **POWER** DC input for the Ulti-box and its attached devices. The standard unit uses a power input of 24-36 Volts. The high-power variant (marked **HV**, for **High Voltage**) uses 24-48 Volts. For pin-out information see *Power connector* on page 59.
  4. **CAM ACC** Camera Accessory input/output connector. It has pins for three stepper motors, two serial lens controls, two trigger in controls, and two trigger out controls. For pin-out information see *Camera Accessory connector* on page 59.
  5. **ETHERNET** RJ45 connector for controlling the Ulti-box and its connected devices from a Flair PC. This Ethernet port is rated at 100 Mbits/sec but can operate at lower speeds of 10 Mbits/sec or less.
  6. **DATA** DataLink In (Up Link) connector for controlling the Ulti-box and its attached devices using a DataLink connection, as an alternative to an Ethernet or Serial RS232 connection. You connect this to a device that is further up the DataLink daisy-chain, such as one of the following:
    - The **DATA OUT** (or **DOWN LINK**) connector on a controller such as the MSA-20 Handwheels or Large Format Panel (LFP).
    - The **RIG/HEAD** connector on an RT-12 or RT-14 interface box which is in turn connected to a PC running Flair Motion Control Software.
- Note that because there is no DataLink Out connector on the Ulti-box, the Ulti-box must be connected at the end of the DataLink daisy-chain rather than the middle. For pin-out information see *Data In connector* on page 60.
7. **BRAKE 24V** connector to connect the 24V brake power supply.
  8. **E\_STOP** connector can be used as an input for E-Stop. To enable the motors, Pins of this connector needs to be shorted, else all drivers are disabled and enable signal from Flair is ignored. It can be

connected to the external E-Stop box, but if no external E-Stop is needed, a bypass jumper may be used.


9. **CAN** connector is used to communicate with external CAN capable motor drives.
- 10,11. **ZOOM, FOCUS** connectors for external servo Lens Control Motors (LCMs) mounted on the camera platform. For pin-out information see *Servo motor connector* on page 58.
12. **TILT** connector for a Tilt servo motor on a head. For pin-out information see *Servo motor connector* on page 58.
- 13,14. **AUX-1, AUX-2** connectors for control of auxiliary servo motors. For pin-out information see *Servo motor connector* on page 58.

## Ulti-box connector pin-out information

### Servo motor connector

This type of connector is used for six servo motor connectors on the Ulti-box:  
Pan, Zoom, Focus, Tilt, Aux-1, Aux-2.


1. DATUM
2. A+
3. B+
4. Z+
5. Brake/Enable output
6. MOTOR\_B
7. MOTOR\_A
8. LIMIT
9. +5V
10. GND



### Program serial connector

Serial connector for connection to a controller using a **Serial RS232** connection, and for updating the firmware in the Ulti-box.

1. SerialTxA
2. SerialRxA
3. +5V
4. FGPIO
5. DSP\_TRSTN
6. TCK
7. TMS
8. DSP\_TDI
9. DSP\_TDO
10. DSP\_EMU0
11. DSP\_EMU1
12. FPGA\_TDI
13. FPGA\_TDO
14. BOOT\_SEL
15. +3.3V
16. GND



## Power connector

The power input connector for the Ulti-box. For usage see page 56.


1. GND
2. GND
3. +35V
4. +35V



## Camera Accessory connector

This is a multi-purpose camera accessory connector with connections for three stepper motors, two serial lens controls, two trigger in controls, and two trigger out controls.


1. Step1
2. Gp2In (Trigger In 2)
3. Step2
4. SerialTxB serial lens control
5. Step3
6. SerialRxB serial lens control
7. Dir3
8. GND
9. +5V
10. Gp1In (Trigger In 1)
11. Dir1
12. Dir2
13. Gp2Out (Trigger Out 2)
14. Gp1Out (Trigger Out 1)



## Data In connector

This is a DataLink In connector for connection to a controller using a DataLink connection. DataLink In (Up Link) connector for connection to a DataLink device higher up in the DataLink daisy-chain. For usage see page 60.

1. Watchdog-
2. Link1Out-
3. Link1Out+
4. Link1In-
5. Link1In+
6. Watchdog+



## Brake 24V connector

This is a Lemo Size 0 2-way connector and is sourced from external PSU.


1. GND
2. +24V



## Brake 24V connector

This is a Lemo Size 1 2-way connector; external circuitry should keep the pins closed.


1. E-STOP-
2. E-STOP+



## CAN connector

This is a Lemo Size 0 3-way connector; is used to communicate with external CAN capable motor drives.

1. CAN Hi
2. CAN Lo
3. GND



Notes

## Appendix 4 Specifications

### Physical Specification

| Dimensions                                          | Bolt X On Pedestal | Bolt X On Track                            |
|-----------------------------------------------------|--------------------|--------------------------------------------|
| Weight - Arm [kg]                                   | 560                | 560                                        |
| Weight - Base [kg]                                  | 200                | 430                                        |
| Weight - YRC1000 controller unit [kg]               | 85                 | 85<br>(included in the weight of the base) |
| Weight - anchor weights and wings [kg]              | 1600               | 1600 (if taken off the track)              |
| Weight - floor plates (2 per section of track) [kg] | NA                 | 80 x 2                                     |
| Maximum payload [kg]                                | 20                 | 20                                         |
| Height - maximum lens height [mm]                   | 4300               | 4300                                       |
| Lowest position [mm]                                | -1300              | -1300                                      |
| Maximum mechanical vertical clearance needed [mm]   | 4800               | 4800                                       |
| Maximum lens reach from rotate centre [mm]          | 3212               | 3212                                       |
| Maximum horizontal clearance needed [mm]            | 3800               | 3800                                       |
| Height - arm in transport position [mm]             | 1719               | 1860                                       |
| Length - arm in transport position [mm]             | 1991               | 1112                                       |
| Width - without wheels [mm]                         | NA                 |                                            |
| Width - with wheels [mm]                            | NA                 | 1234                                       |
| Width - with weights [mm]                           | 2255               | NA                                         |
| Width - without weights [mm]                        | 950                | NA                                         |

Temperature range: 0-45 °C (32-113 °F)

Humidity tolerance: 0% to 85% relative humidity, non-condensing

## Range of Travel

Track: Unlimited range of travel @ 4 m/s

Rotate: +/- 180° range of travel @ 180°/s

Lift: + 135° to - 90° range of travel @ 180°/s

Arm: + 206° to - 80° range of travel @ 180°/s


Pan: +/- 200° range of travel @ 400°/s

Tilt: +/- 150° range of travel @ 430°/s

Roll: +/- 455° range of travel @ 630°/s

## Power requirements

**Bolt X on Track** requires three-phase power line with Neutral in Wye connection plus Earth (Ground), 50-60 Hz.



Phase to phase voltage must be 380V at least, any lower voltage would reduce maximum track speed. Maximum applied voltage is 480V.

**Bolt X On Pedestal** requires three phase but NO NEUTRAL. The power cable is wired directly to the robot's controller (YRC1000).

Allowed three phase input voltages:

3-Phase, 380-480VAC (+10%, -15%), 50/60 Hz (±2%)

## Cable Colours

|              |         |
|--------------|---------|
| Brown        | Phase 1 |
| Black        | Phase 2 |
| Grey         | Phase 3 |
| Green/Yellow | Ground  |

Note: No NEUTRAL is used

## General Electric Data

### Earth

Earth must have good connection (less than 10 ohm) to the closest grounding point of the location.

### Earth Leakage Protection

In industrial situations, where you are running large machinery, the earth leakage breaker (RCD/GFI) must be at least 100mA, preferably 300mA. Otherwise the machine will not power up and will sometimes trip when running.

## Power for Flair and PC (500W)

The PC running FLAIR and associated components are delivered mounted in a flight case. The power requirement is 110/240VAC single phase 50/60Hz and consumes no more than 500 Watts. All PSUs adjust automatically to the supply voltage.

### WARNING!

For Bolt X on Track on location, a generator capable of at least 50KW along with other high power equipment connected to the same generator is recommended.

This is due to the regenerative circuit in the Yaskawa YRC1000 controller. If the generator is not capable to absorb the excess energy produced by robot hard decelerations, especially on track, some component in the controller may be damaged and would need to be replaced. This kind of damage is not covered by either Yaskawa or MRMC warranty.



## Power Data by Country - United States of America

| ASSUMED    | VOLTAGE<br>VAC | CURRENT<br>AMPS | POLES | WIRING<br>CONFIG | CONNECTOR ON<br>WALL | NOTE         |
|------------|----------------|-----------------|-------|------------------|----------------------|--------------|
| SUPPLY (7) | 208            | 20              | 3+N+E | DELTA            | L21-20R              | N see note 1 |
| SUPPLY (8) | 208            | 30              | 3+N+E | DELTA            | L21-30R              | N see note 1 |

| MRMC RIGS – MAX POWER<br>REQUIREMENTS (Voltage) | POWER<br>KVA | SUPPLY<br>VOLTAGE | CURRENT<br>AMPS | RIG<br>CONFIG | WIRING<br>CONFIG | SUPPLIED<br>CONNECTOR | TRANS<br>FORMER | GFI   | NOTE |
|-------------------------------------------------|--------------|-------------------|-----------------|---------------|------------------|-----------------------|-----------------|-------|------|
| BOLT on PEDESTAL<br>(208/400/480)               | 3            | 208               | 8               | 3+E           |                  | L21-20P               | -               | 300mA | 2    |
| BOLT on TRACK (415)                             | 10           | 208               | 29              | 3+N+E         | WYE              | L21-30P               | 12KVA           | 300mA | 3    |
| BOLT X on PEDESTAL (380-<br>440)                | 3.5          | 208               | 10              | 3+E           |                  | L21-20P               | 4KVA            | 300mA | 2    |
| BOLT X on TRACK (380-440)                       | 10.5         | 208               | 30              | 3+N+E         | WYE              | L21-30P               | 12KVA           | 300mA | 3    |

### Notes

1. The Neutral in a US three phase Delta configuration is NOT the same as the Neutral in a WYE configuration and is never used by MRMC rigs.
2. The Neutral on the supply side is NOT used by MRMC rigs. Only the three hot wires and the earth are connected from the rig to the X,Y,Z and E. W is not connected.
3. The transformer recommended here is 11KVA 208VAC three phase Delta input to three phase 415 WYE output. The earth connection must be included. The transformer therefore is required to transform the three phase voltage and transform 3+E (Delta) to 3+N+E (WYE) as required by the Bolt X on Track.

## Appendix 5 Cleaning and Maintenance

### General Care

After transport, the machine may exhibit an error on its Teach pendant that prevents enabling of the axes; this is due to slight shifting of the arms in transport, creating an out of position error. This can be corrected by going through the Second Home Position reset as explained in the *Second Home Position Check and Reset* on page 41.

Inspect carefully the cableways along the arms for damage or stretching of cables, and ensure any cable clamps and flexing corners are adjusted to suit.

Take great care with the large multi way connectors on the base, arm and umbilical. If they are unplugged for transport ensure they are wrapped or covered so the tiny pins cannot get damaged. Do not spray cleaning fluids into these plugs and sockets.

### Cleaning

The Bolt X on tracks should be turned off and unplugged for cleaning.

### Main Body and Arm

The Bolt X on Track requires little maintenance, but should be cleaned frequently depending upon where it is used. Clean the main body of the rig and arm with a proprietary cleaning liquid on a soft cloth, then go over the machine with a cloth with WD40, or similar. Gaffer Tape smears can be removed with sticky stuff remover. Fans in the body of the machine should be sucked with a vacuum cleaner.

### Cables

Cables should be also cleaned in the same way, but avoid spraying liquids into any open sockets.

### Pinchwheel

The Pinch wheel should be checked occasionally. Any signs of damage to the red rubber wheel should have it replaced. Limit sensors on the pinch wheel pivot should be replaced whenever they become broken or their cables damaged.

## **Track Gearbox**

After approximately five years of use the track gearbox oil will need changing, this is just a gear oil available from motor factors, grade EP90.

## **Track and Track Bearings**

The Track Bearings should be frequently greased using a good quality grease gun, again from a motor factor; the grease is Brown Low Melting grade. This should be done at least once per month if the machine is busy and especially in sandy or gritty environments. The bearings should be pumped with grease into one end grease nipple with the bearing on the rail moving slowly along; until the dirty grease stops coming out around the sides onto the rail.

Running with dry bearings will be noisy and produce loose shaky shoots, and will considerably shorten the life of the bearings and the bearing rail. As soon as any track bearing becomes slightly loose on the rail or noisy, or has been damaged or has any balls missing from its four raceways, it should be replaced.


## Replacing the Pinch Wheel

The worn out pinch wheel can be replaced in the pinch wheel assembly using the following procedure:

1. Unscrew the small screw on the pinch wheel on the underside of the pinch wheel assembly. The pinch wheel is not completely detached yet.




2. Using the same allen key push in the screw cavity to release the pin securing the pinch wheel.



3. Notice a washer above the pinch wheel; keep it aside. Discard the worn out pinch wheel.




4. Replace the washer on the new pinch wheel carefully and inserting it lined with the screw cavities in the centre shaft of the pinch wheel assembly. Ensure that the washer is inserted towards the underside of the shaft and not on the top.
5. When the pinch wheel is centred on the cavities insert the pin. (Refer to step 2 for alignment and pin position). Push the pin enough so it is flush with shaft and is not protruding.
6. Replace the screw and washer to secure the pinch wheel to the assembly.



## Replacing the Track Pinion

This procedure can be performed either while the robot is on track or while the robot is on jacking wheels.

1. If the robot is mounted on the track, remove the pinchwheel assembly from the track motor and move the track motor away from the rail racking. Using bare fingers, observe the underside of the pinion to perceive the position of the pinion on the shaft.
2. Remove the grub screw from the track pinion.



3. You should now be able to release without applying pressure. If it is not released easily, use Flair to run the track motor at a slow speed, eg 20rpm. While the track pinion is rotating, use a heat gun to heat the pinion to allow it to expand.

### Caution

- Take care when heating the pinion with the heat gun to only direct the gun downwards onto the sides and central when underneath. If the heat gun is directed at the gearbox seal above the pinion it can cause damage and create leaks.
- Do not hit the pinion or gearbox with any tools to detach it from the gearbox. Hammering can cause permanent damage to the pinion and gearbox.



4. Once the pinion is sufficiently expanded, using heat-proof gloves, try removing the pinion; again without using much pressure.
5. Replace the new track pinion by inserting it onto the shaft. If it doesn't fit easily, heat it using the heat gun and then slide it on to the track motor shaft. The position of the pinion should be the same as you had observed before removing the worn out pinion; approximately only 1-2mm of shaft projecting from the pinion centre.
6. Replace the grub screw to secure the pinion.

Notes

Notes

Notes



**Mark Roberts Motion Control Ltd.**

Unit 3, South East Studios, Blindley Heath, Surrey RH7 6JP

United Kingdom

Telephone: +44 (0) 1342 838000

[info@mrsmoco.com](mailto:info@mrsmoco.com)

[www.mrmoco.com](http://www.mrmoco.com)

