



Spatial FOG Dual

Reference Manual








Table of Contents

1	Revision History.....	8
2	Firmware Changelog.....	9
3	Hardware Changelog.....	11
4	Introduction.....	12
5	Foundation Knowledge.....	13
5.1	GNSS.....	13
5.2	INS.....	13
5.3	GNSS/INS.....	13
5.4	AHRS.....	13
5.5	RTK GNSS.....	13
5.6	The Sensor Co-ordinate Frame.....	14
5.7	Roll, Pitch and Heading.....	14
5.7.1	Second Right Hand Rule.....	14
5.7.2	Rotation Order.....	15
5.8	Geodetic Co-ordinate System.....	15
5.8.1	Longitude and Latitude.....	15
5.8.2	Height.....	16
5.9	NED Co-ordinate Frame.....	18
5.10	ECEF Co-ordinate Frame.....	19
6	Evaluation Kit.....	20
6.1	Kit Contents.....	20
6.2	Quick Start.....	20
6.3	Antenna Survey Mount Assembly.....	21
7	Part Numbers and Ordering Options.....	22
7.1	Evaluation Kit.....	22
7.2	Standalone Unit.....	22
7.3	Internal GNSS Receiver License Upgrades.....	22
7.4	Accessories.....	23
8	Specifications.....	24
8.1	Mechanical Drawings.....	24
8.2	Centre of Gravity Drawings.....	25
8.3	Navigation Specifications.....	26
8.4	Heading Accuracy.....	26
8.5	Sensor Specifications.....	27
8.6	GNSS Specifications.....	27
8.7	Communication Specifications.....	28
8.8	Hardware Specifications.....	28
8.9	Electrical Specifications.....	29
8.10	Power Consumption.....	30
8.11	Connector Pin-out.....	30
8.12	Spatial FOG Dual Evaluation Cable Harness.....	31
8.13	Serial Number.....	33
9	Installation.....	34
9.1	Installation Checklist.....	34
9.2	Position and Alignment.....	34
9.2.1	Alignment.....	35
9.3	Mounting Plate.....	35
9.4	Power Supply.....	36
9.5	GNSS Antennas.....	37




9.6	GNSS Antenna Cables.....	39
9.7	Static Port.....	39
9.8	Odometer.....	39
9.8.1	Factory VSS Signal.....	39
9.8.2	OBDII Odometer Interface.....	40
9.8.3	Aftermarket Wheel Speed Sensor.....	40
9.8.4	Radar Speed Sensor.....	40
9.9	Vibration.....	41
10	Operation.....	42
10.1	Filter.....	42
10.2	Initialisation.....	42
10.2.1	Orientation Initialisation.....	42
10.2.2	Navigation Initialisation.....	43
10.2.3	Heading Initialisation.....	43
10.2.4	Time Initialisation.....	43
10.3	Hot Start.....	43
10.4	Time.....	44
10.5	Heading Source.....	44
10.5.1	Dual Antenna Heading.....	44
10.5.2	North Seeking Gyrocompass Heading.....	44
10.5.3	Velocity Heading.....	45
10.5.4	External Heading.....	45
10.6	Magnetics.....	45
10.7	Data Anti Aliasing.....	46
10.8	Vehicle Profiles.....	46
10.9	Odometer Pulse Length.....	46
10.9.1	Odometer Automatic Pulse Length Calibration Procedure.....	46
10.10	Reversing Detection.....	46
10.11	Motion Analysis.....	47
10.12	RAIM.....	47
10.13	RTK.....	47
10.13.1	Cellular RTK corrections.....	47
10.13.2	Base station radio modem RTK corrections.....	48
10.14	Heave.....	48
10.15	Environmental Exposure.....	48
10.15.1	Temperature.....	49
10.15.2	Water.....	49
10.15.3	Salt.....	49
10.15.4	Dirt and Dust.....	49
10.15.5	PH Level.....	49
10.15.6	Shocks.....	49
11	Spatial FOG Manager.....	50
11.1	Software Changelog.....	51
11.2	System Requirements.....	51
11.3	Installation.....	52
11.4	Troubleshooting.....	52
11.4.1	All Platforms.....	52
11.4.2	Windows.....	52
11.4.3	Linux.....	53
11.5	Main View.....	54




11.5.1	Serial Port.....	54
11.5.2	Attitude Indicator.....	54
11.5.3	Status Indicator.....	54
11.5.3.1	Spatial Status Indicator.....	55
11.5.3.2	Fix Indicator.....	55
11.5.3.3	Satellites Table.....	55
11.5.4	3D Map.....	55
11.5.5	3D Map Controls.....	55
11.5.5.1	Reset View.....	55
11.5.5.2	Clear History.....	55
11.6	Logging.....	55
11.7	Views.....	56
11.7.1	Device Information.....	56
11.7.2	Status.....	57
11.7.3	Satellites.....	58
11.7.4	Raw Sensors.....	59
11.7.5	Orientation.....	60
11.7.6	Position.....	61
11.7.7	Velocity and Acceleration.....	62
11.7.8	3D Model.....	63
11.7.9	Communications Statistics.....	63
11.7.10	GNSS Receiver Information.....	64
11.7.11	Heave.....	64
11.7.12	North Seeking Status.....	65
11.8	Configuration.....	66
11.8.1	Configuration Export.....	67
11.8.2	Filter Options.....	68
11.8.3	Packet Rates.....	69
11.8.4	Alignment Configuration.....	70
11.8.4.1	Alignment Offset.....	70
11.8.4.2	GNSS Antenna Offset.....	70
11.8.4.3	Odometer Offset.....	71
11.8.4.4	External Data Offset.....	71
11.8.5	Baud Rates.....	71
11.8.6	GPIO Configuration.....	72
11.8.7	Odometer.....	72
11.8.8	Reset.....	73
11.8.9	Heave Offset.....	73
11.8.10	GPIO Output.....	74
11.8.11	Manual Initialisation.....	75
11.8.12	Dual Antenna.....	76
11.9	Tools.....	77
11.9.1	Terminal.....	77
11.9.2	Firmware Update.....	77
11.9.3	Log Converter.....	78
11.9.4	NTRIP Client.....	78
11.9.5	Network Connect.....	78
12	Interfacing.....	79
12.1	Communication.....	79
12.1.1	Baud Rate.....	79



12.2 External Data.....	79
12.3 GPIO Pins and Auxiliary RS232.....	79
12.3.1 GPIO Pins Voltage Level.....	80
12.3.2 GNSS RS232.....	80
12.4 Dynamic Pin Functions.....	80
12.4.1 1PPS Output.....	82
12.4.2 GNSS Fix Output.....	82
12.4.3 Odometer Input.....	82
12.4.4 Zero Velocity Input.....	82
12.4.5 Pitot Tube Input.....	82
12.4.6 NMEA Input.....	83
12.4.7 NMEA Output.....	83
12.4.8 Novatel GNSS Input.....	83
12.4.9 Topcon GNSS Input.....	84
12.4.10 ANPP Input.....	84
12.4.11 ANPP Output.....	84
12.4.12 Disable GNSS.....	84
12.4.13 Disable Pressure.....	84
12.4.14 Set Zero Orientation Alignment.....	84
12.4.15 System State Packet Trigger.....	84
12.4.16 Raw Sensors Packet Trigger.....	84
12.4.17 Pressure Depth Transducer.....	84
12.4.18 RTCM Differential GNSS Corrections Input.....	85
12.4.19 Trimble GNSS Input.....	85
12.4.20 u-blox GNSS Input.....	85
12.4.21 Hemisphere GNSS Input.....	85
12.4.22 Teledyne DVL Input.....	85
12.4.23 Trittech USBL Input.....	85
12.4.24 Linkquest DVL Input.....	85
12.4.25 Linkquest USBL Input.....	85
12.4.26 Nortek DVL Input.....	85
12.4.27 Left Wheel Speed Sensor.....	86
12.4.28 Right Wheel Speed Sensor.....	86
12.4.29 1PPS Input.....	86
12.4.30 Wheel Speed Sensor.....	86
12.4.31 Wheel Encoder Phase A.....	86
12.4.32 Wheel Encoder Phase B.....	86
12.4.33 Event 1 Input.....	86
12.4.34 Event 2 Input.....	86
12.4.35 TSS1 Output.....	87
12.4.36 Simrad 1000 Output.....	87
12.4.37 Simrad 3000 Output.....	87
12.4.38 Serial Port Passthrough.....	87
12.4.39 GNSS Receiver Passthrough.....	87
12.4.40 Gimbal Encoder Phase A.....	87
12.4.41 Gimbal Encoder Phase B.....	87
12.4.42 Odometer Direction, Forward Low.....	87
12.4.43 Odometer Direction, Forward High.....	87
12.4.44 Reverse Alignment, Forward Low.....	88
12.4.45 Reverse Alignment, Forward High.....	88




12.4.46 Zero Angular Velocity Input.....	88
13 Advanced Navigation Packet Protocol.....	89
13.1 Data Types.....	89
13.2 Packet Structure.....	89
13.2.1 Header LRC.....	90
13.2.2 Packet ID.....	90
13.2.3 Packet Length.....	90
13.2.4 CRC.....	90
13.3 Packet Requests.....	90
13.4 Packet Acknowledgement.....	90
13.5 Packet Rates.....	91
13.6 Packet Timing.....	91
13.7 Packet Summary.....	91
13.8 System Packets.....	94
13.8.1 Acknowledge Packet.....	94
13.8.1.1 Acknowledge Result.....	94
13.8.2 Request Packet.....	94
13.8.3 Boot Mode Packet.....	95
13.8.3.1 Boot Mode Types.....	95
13.8.4 Device Information Packet.....	95
13.8.4.1 Device ID.....	96
13.8.5 Restore Factory Settings Packet.....	96
13.8.6 Reset Packet.....	96
13.8.6.1 Verification Sequence Values.....	97
13.8.7 Serial Port Pass-through Packet.....	97
13.8.7.1 Pass-through Routes.....	97
13.9 State Packets.....	98
13.9.1 System State Packet.....	98
13.9.1.1 System Status.....	99
13.9.1.2 Filter Status.....	100
13.9.1.3 GNSS Fix Status.....	100
13.9.1.4 Unix Time Seconds.....	100
13.9.1.5 Microseconds.....	101
13.9.2 Unix Time Packet.....	101
13.9.3 Formatted Time Packet.....	101
13.9.4 Status Packet.....	102
13.9.5 Position Standard Deviation Packet.....	102
13.9.6 Velocity Standard Deviation Packet.....	102
13.9.7 Euler Orientation Standard Deviation Packet.....	103
13.9.8 Quaternion Orientation Standard Deviation Packet.....	103
13.9.9 Raw Sensors Packet.....	104
13.9.10 Raw GNSS Packet.....	104
13.9.10.1 Raw GNSS Status.....	105
13.9.11 Satellites Packet.....	106
13.9.12 Detailed Satellites Packet.....	106
13.9.12.1 Satellite Systems.....	107
13.9.12.2 Satellite Frequencies.....	107
13.9.13 Geodetic Position Packet.....	107
13.9.14 ECEF Position Packet.....	108
13.9.15 UTM Position Packet.....	108



13.9.16	NED Velocity Packet.....	108
13.9.17	Body Velocity Packet.....	109
13.9.18	Acceleration Packet.....	109
13.9.19	Body Acceleration Packet.....	109
13.9.20	Euler Orientation Packet.....	110
13.9.21	Quaternion Orientation Packet.....	110
13.9.22	DCM Orientation Packet.....	110
13.9.23	Angular Velocity Packet.....	111
13.9.24	Angular Acceleration Packet.....	111
13.9.25	External Position & Velocity Packet.....	111
13.9.26	External Position Packet.....	112
13.9.27	External Velocity Packet.....	113
13.9.28	External Body Velocity Packet.....	113
13.9.29	External Heading Packet.....	113
13.9.30	Running Time Packet.....	114
13.9.31	Local Magnetic Field Packet.....	114
13.9.32	Odometer State Packet.....	114
13.9.33	External Time Packet.....	115
13.9.34	External Depth Packet.....	115
13.9.35	Geoid Height Packet.....	115
13.9.36	RTCM Corrections Packet.....	116
13.9.37	External Pitot Pressure Packet.....	116
13.9.38	Wind Packet.....	116
13.9.39	Heave Packet.....	117
13.9.40	Post Processing Packet.....	117
13.9.41	Raw Satellite Data Packet.....	118
13.9.41.1	Satellite Frequencies.....	119
13.9.41.2	Tracking Status.....	119
13.9.42	Raw Satellite Ephemeris Packet.....	119
13.9.43	External Odometer Packet.....	119
13.9.43.1	Odometer flags.....	120
13.9.44	External Air Data Packet.....	120
13.9.44.1	External Air Data Flags.....	120
13.9.44.2	Notes.....	120
13.9.45	GNSS Receiver Information Packet.....	121
13.9.45.1	GNSS Manufacturer IDs.....	121
13.9.45.2	GNSS Receiver Models.....	121
13.9.46	North Seeking Initialisation Status Packet.....	121
13.9.46.1	North Seeking Initialisation Status Flags.....	122
13.9.46.2	North Seeking Initialisation Current Rotation Angle.....	122
13.9.47	Gimbal State Packet.....	123
13.9.48	Automotive Packet.....	123
13.10	Configuration Packets.....	124
13.10.1	Packet Timer Period Packet.....	124
13.10.1.1	UTC Synchronisation.....	124
13.10.1.2	Packet Timer Period.....	124
13.10.2	Packets Period Packet.....	125
13.10.2.1	Clear Existing Packets.....	125
13.10.2.2	Packet Period.....	125
13.10.3	Baud Rates Packet.....	126



13.10.4	Installation Alignment Packet.....	127
13.10.4.1	Alignment DCM.....	127
13.10.5	Filter Options Packet.....	128
13.10.5.1	Vehicle Types.....	128
13.10.6	Advanced Filter Parameters Packet.....	129
13.10.7	GPIO Configuration Packet.....	129
13.10.7.1	GPIO1 Functions.....	129
13.10.7.2	GPIO2 Functions.....	130
13.10.7.3	Auxiliary RS232 Transmit Functions.....	132
13.10.7.4	Auxiliary RS232 Receive Functions.....	132
13.10.8	Odometer Configuration Packet.....	133
13.10.9	Set Zero Orientation Alignment Packet.....	133
13.10.10	Reference Point Offsets Packet.....	134
13.10.11	GPIO Output Configuration Packet.....	135
13.10.11.1	NMEA Fix Behaviour.....	135
13.10.11.2	GPIO Output Rates.....	135
13.10.11.3	GPIO Output Rates Index.....	136
13.10.12	Dual Antenna Configuration Packet.....	136
13.10.12.1	Offset Types.....	137
13.10.12.2	Automatic Offset Orientations.....	137
13.10.13	User Data Packet.....	137
13.10.14	GPIO Input Configuration Packet.....	137



1 Revision History

Version	Date	Changes
1.4	08/03/2022	Updated firmware changelog, section 2 Updated accessory part numbers, section 7.4 Updated specifications, sections 8.3 & 8.5 Added centre of gravity diagram, section 8.2 Added Device ID table, section 13.8.4.1 Updated software changelog, section 11.1 Updated Log Converter Tool image and description, section 11.9.3 Added logging command line information, section 11.6 Clarified geoid, ellipsoid and orthometric heights, section 5.8
1.3	04/06/2019	Updated firmware changelog, section 2 Updated external body velocity packet size and definition 13.9.28 Added wheel speed sensor specifications, section 12.4.30 Added note about external data packet acknowledgement, section 13.4 Clarified geoid height packet description, section 13.9.35 Updated NMEA output rate, section 12.4.7 Corrected units for velocity in Packet 29, section 13.9.10 Added 1PPS voltage levels, section 12.4.1 Changed read status of packet 67, section 13.7 Clarified height referenced to mean sea level, section 13.9.35 Added the size of the DC power socket to Illustration 16 Updated advice on heat dissipation. section 9.2 Updated dynamic pin functions table, section 12.4 Updated GPIO configuration packet, section 13.10.7 Added pressure depth transducer deprecated input function 12.4.17 Added Teledyne DVL input function 12.4.22 Added Tritech USBL input function 12.4.23 Added Linkquest DVL input function 12.4.24 Added Linkquest USBL input functionality 12.4.25 Removed external pitot pressure packet, section 13.9.37 Added reverse alignment input functions 12.4.44 Added zero angular velocity input function 12.4.46 Clarified port baud rates in sections 8.7, 12.1, 12.3 and 13.10.3 Updated packet summary section 13.7
1.2	18/05/2018	Updated firmware changelog, section 2 Updated hardware changelog, section 3
1.1	30/04/2018	Updated firmware changelog, section 2
1.0	26/06/2015	Initial release

Table 1: Revision history

2 Firmware Changelog

Version	Date	Changes
1.6	23/12/2019	Improvements to odometer automatic scaling results in improved dead reckoning with odometer Improvements to heading integrity monitoring results in better rejection of erroneous heading Support for Novatel HEADING2 message Support for Trimble RTX
1.5	31/05/2019	Fixed regression with integrity monitoring introduced in version 1.4
1.4	07/05/2019	Improvements to INS performance in urban canyons Improvements to odometer aided navigation Added support for u-blox Z9P protocol changes World magnetic model updated to WMM2015v2 Added zero angular velocity GPIO input Improvements to water height estimation algorithm Online odometer scaling now adjusts for up to 5% scaling error
1.3	18/04/2018	Addition of extra BeiDou and Galileo frequencies to raw satellite data output. Hemisphere binary input now supports Bin1 and GPHDT messages. Receiver default functionality is changed to preferentially track L2P over L2C Hot start performance improvements Fix for SBAS and QZSS satellite numbering Added Nortek DVL support Added support for new NMEA messages PFEC,Gpatt, PFEC,Gphve, PSIMSSB and GPVHW. Significantly improved integrity monitoring algorithms allow the system to more effectively filter out bad data from GNSS receivers, odometers and external sources. NMEA PASHR message updated to include standard deviation. Improved motion analysis (ZUPT). IMU1750 temperature reporting changed to 2 decimal places.
1.21	01/07/2016	Added fix for GNSS receiver time issue that could cause time to jump forward by 5 years in rare circumstances. Fixed issue where automatic dual antenna offset would not converge if antennas changed separation and a hot start reset performed Fixed bug where SBAS GNSS fix would be incorrectly shown as differential GNSS fix
1.1	05/04/2016	Filter improvements result in increased performance in urban canyons and high dynamic environments. Added support for NMEA messages GPROT and GPHEV Added support for raw GNSS packet input


Version	Date	Changes
		Bug fix for NMEA mode character indicating incorrectly Bug fix for raw satellite data packet update rate not saving correctly
1.0	08/04/2015	Initial release

Table 2: Firmware changelog

3 Hardware Changelog

Version	Date	Changes
2.4	01/06/2016	Slightly reduced power consumption and heat generation Minor internal improvements
2.2	03/08/2015	Internal solid state hot start battery changed resulting in longer hot start capability Other minor internal improvements
1.0	14/01/2015	Initial release

Table 3: Hardware changelog




4 Introduction

Spatial FOG Dual is a ruggedised GPS aided inertial navigation system and AHRS that provides accurate position, velocity, acceleration and orientation under the most demanding conditions. It combines ultra high accuracy fibre optic gyroscopes, accelerometers, magnetometers and a pressure sensor with a dual antenna RTK GNSS receiver. These are coupled in a sophisticated fusion algorithm to deliver accurate and reliable navigation and orientation.

Spatial FOG Dual can provide amazing results but it does need to be set up properly and operated with an awareness of its limitations. Please read through this manual carefully to ensure success within your application.

The Spatial FOG Manager software is downloadable from the software section. It allows Spatial FOG Dual to be easily configured and tested. It is referenced throughout this manual.

If you have any questions please contact support@advancednavigation.com.au.



5 Foundation Knowledge

This chapter is a learning reference that briefly covers knowledge essential to understanding Spatial FOG Dual and the following chapters. It explains the concepts in simple terms so that people unfamiliar with the technology may understand it.

5.1 GNSS

GNSS stands for global navigation satellite system. A GNSS consists of a number of satellites in space that broadcast navigation signals. These navigation signals can be picked up by a GNSS receiver on the earth to determine that receiver's position and velocity. For a long time the only operational GNSS was the United States GPS. However the Russian GLONASS is now fully operational with similar performance to GPS. The Chinese BeiDou is in the process of becoming operational and the European Union's GALILEO should be operational within ten years.

GNSS is excellent for navigational purposes and provides fairly accurate position (2.5 metres) and velocity (0.03 metres/second). The main drawback of GNSS is that the receiver must have a clear signal from at least 4 satellites to function. GNSS satellite signals are very weak and struggle to penetrate through buildings and other objects obstructing view of the sky. GNSS can also occasionally drop out due to disturbances in the upper atmosphere.

5.2 INS

INS stands for inertial navigation system. An inertial navigation system can provide position and velocity similar to GNSS but with some big differences. The principle of inertial navigation is the measurement of acceleration. This acceleration is then integrated into velocity. The velocity is then integrated into position. Due to noise in the measurement and the compounding of that noise through the integration, inertial navigation has an error that increases exponentially over time. Inertial navigation systems have a very low relative error over short time periods but over long time periods the error can increase dramatically.

5.3 GNSS/INS

By combining GNSS and INS together in a mathematical algorithm, it is possible to take advantage of the benefits of GNSS long-term accuracy and INS short-term accuracy. This provides an overall enhanced position and velocity solution that can withstand short GNSS drop outs.

5.4 AHRS

AHRS stands for attitude and heading reference system. An AHRS uses accelerometers, gyroscopes and magnetometers combined in a mathematical algorithm to provide orientation. Orientation consists of the three body angles roll, pitch and heading.

5.5 RTK GNSS

RTK stands for real time kinematic. RTK is a technology used to significantly enhance the accuracy of GNSS. With standard GNSS the accuracy achievable is approximately 2.5 metres, with RTK GNSS the accuracy achievable is 0.01 metres. RTK works by estimating the phase of the carrier wave of the GNSS signal. By using the phase of the carrier wave, rather than the data content, RTK is able to measure the signal 1000 times more precisely.

RTK GNSS requires continuous correction data from a base station to function. These corrections are typically received either over a radio modem or through a cellular network.

5.6 The Sensor Co-ordinate Frame

Inertial sensors have 3 different axes: X, Y and Z and these determine the directions around which angles and accelerations are measured. It is very important to align the axes correctly in installation otherwise the system won't work correctly. These axes are marked on the top of the device as shown in Illustration 1 below with the X axis pointing in the direction of the connector, the Z axis pointing down through the base of the unit and the Y axis pointing out of the starboard side.




Illustration 1: Spatial FOG Dual axes




Illustration 2: First right hand rule

When installed in an application the X axis should be aligned such that it points forwards and the Z axis aligned so that it points down when level. A good way to remember the sensor axes is the right hand rule, which is visualised in Illustration 2. You take your right hand and extend your thumb, index and middle. Your thumb then denotes the X axis, your index denotes the Y axis and your middle denotes the Z axis.


5.7 Roll, Pitch and Heading

Orientation can be described by the three angles roll, pitch and heading, these are known as the Euler angles. The rotation axes of roll, pitch and heading are shown visually in Illustration 1. The arrow indicates the positive rotation direction.

Roll is the angle around the X axis and is zero when the unit is level. Pitch is the angle around the Y axis and is zero when the unit is level. Heading is the angle around the Z axis and is zero when the positive X axis is pointing to true north.

5.7.1 Second Right Hand Rule

The two right hand rules are often the best way to memorise the sensor axes and directions of positive rotation. The first right hand rule gives the positive axis directions and is described in section 5.6. The second right hand rule shown in Illustration 3 provides the direction of positive



rotation. To use it, point your thumb in the positive direction of that axis, then the direction that your fingers curl over is the positive rotation on that axis.




Illustration 3: Second right hand rule

5.7.2 Rotation Order

When multiple axes are rotated, to imagine the final orientation the three rotations must be performed in the order heading first, then pitch and then roll. To deduce the final orientation the unit should first be considered level with the X axis pointing north and the Z axis pointing down. Heading is applied first, then pitch is applied and finally roll is applied to give the final orientation. This can be hard for some people to grasp at first and is often best learned experimentally by rotating Spatial FOG Dual with your hand whilst watching the orientation plot in real time on the computer.

5.8 Geodetic Co-ordinate System

The geodetic co-ordinate system is the most popular way of describing an absolute position on the Earth. It is made up of the angles latitude and longitude combined with a height relative to the ellipsoid.

5.8.1 Longitude and Latitude

Latitude is the angle that specifies the north to south position of a point on the Earth's surface, reported as $\pm 90^\circ$. Longitude is the angle that specifies the east to west position of a point on the Earth's surface, reported as $\pm 180^\circ$. The line of zero latitude is the equator and the line of zero longitude is the prime meridian. Illustration 4 shows how latitude and longitude angles are used to describe a position on the surface of the Earth.




Illustration 4: Latitude and longitude represented visually to describe a position

Illustration 5 shows latitude and longitude on a map of the world, represented with a standard Mercator projection.





Illustration 5: World map showing latitudes and longitudes

Latitude and longitude give the 2D point on the surface of the Earth. These are combined with height to give the 3D position on the Earth.

5.8.2 Height

Any height data output by Advanced Navigation devices is the height referenced the WGS84 reference ellipsoid. The WGS84 reference ellipsoid is a smooth mathematical model that approximates the form of the surface of the earth. The ellipsoid height (as used by GNSS) is not referenced to mean sea level; the height from the EGM96 geoid (orthometric height) approximates the height above mean sea level (MSL).

See Illustration 6 below for a visual representation of geoid height, ellipsoid height and orthometric height (height above mean sea level).

Note:

- Ellipsoid height refers to the height of a point of interest referenced to the WGS84 reference ellipsoid
- Geoid height refers to the height of the EGM96 geoid referenced to the WGS84 reference ellipsoid at a point of interest
- Orthometric height is the height at a point of interest referenced to the EGM96 geoid.

All heights can be either positive or negative dependant upon direction from the reference surface.



$$H = h - N$$




Illustration 6: Orthometric, ellipsoid and geoid height diagram

The value required to convert the WGS84 ellipsoid height to orthometric height can be found in the geoid height packet, see section 13.9.35.

5.9 NED Co-ordinate Frame

The NED (North East Down) co-ordinate frame is used to express velocities and relative positions. The origin of the co-ordinate frame can be considered the current position. From that origin, the north axis points true north and parallel to the line of longitude at that point. The east axis points perpendicular to the north axis and parallel to the line of latitude at that point. The down axis points directly down towards the centre of the Earth. See Illustration 7 for a graphical representation of the NED co-ordinate frame at a position on the Earth.




Illustration 7: Graphic showing geodetic, NED and ECEF co-ordinates

5.10 ECEF Co-ordinate Frame

The ECEF (Earth-centred earth-fixed) co-ordinate frame is a Cartesian co-ordinate frame used to represent absolute positions on the Earth. It's origin is at the centre of the Earth. ECEF is an alternative to the geodetic co-ordinate frame. It is represented by the three axes X, Y and Z which are presented graphically in Illustration 7. ECEF positions can be retrieved from Advanced Navigation products however the geodetic system is used as the default.

6 Evaluation Kit

Spatial FOG Dual is supplied in an evaluation kit that contains everything required to get started operating the system right away. The evaluation kit is supplied in a rugged transport case to protect the equipment during shipping.



Illustration 8: Spatial FOG Dual Evaluation Kit rugged transport case




Illustration 9: Spatial FOG Dual Evaluation Kit contents

6.1 Kit Contents

1. Spatial FOG Dual GNSS/INS, RS422
2. Interface cable harness, see section 8.12
3. 2 x Antcom G5Ant-53A4T1 L1/L2/L5 GNSS antennas with 5/8"-11 survey mounts
4. 2 x RG-58/U 4 metre antenna cable
5. 1 metre FTDI USB to RS232 / RS422 (switchable) adaptor cable
6. 100-240 V AC to 24 V DC power supply
7. Transport Case

6.2 Quick Start

1. Position the two GNSS antennas in a level orientation with a clear view of the sky. The primary antenna should be positioned directly forwards of the secondary antenna with separation of at least 0.5 metres.
2. Connect the coaxial cables between the antennas and Spatial FOG Dual.
3. Attach the interface cable harness to the Spatial FOG Dual unit and screw up finger tight.
4. Plug the power supply into the cable harness and then into the wall socket
5. Plug the USB to RS422/RS232 cable into the cable harness primary RS422 socket and your computer
6. Download the Spatial FOG Manager software from the Advanced Navigation website. Java



is required to run the software. Java is available from <http://www.java.com> if not already installed.

7. Click the connect button in Spatial FOG Manager.
8. The various windows in Spatial FOG Manager can be used to view the real time data.
9. If dual antenna heading will take a short time to initialise. The progress can be monitored in the status view.
10. To view the data logs, click disconnect in Spatial FOG Manager. In the tools menu, select log converter and press convert. The *.anpp binary log file will be converted to CSV files that can be opened with popular data processing programs such as Matlab or Microsoft Excel. The log files can be found in the same folder as the Spatial FOG Manager software.

6.3 Antenna Survey Mount Assembly

The Antcom G5Ant-53A4T1 antennas included in the evaluation kit can either be mounted to a panel or mounted to a standard 5/8"-11 survey mount thread with the optional survey mount kit included in the evaluation kit. Please see Illustration 10 below for assembly of antenna with the survey mount kit.




Illustration 10: Antenna survey mount exploded view

7 Part Numbers and Ordering Options

7.1 Evaluation Kit

Part Number	Description	Notes
SPATIAL-FOG-DUAL-EK	Spatial FOG Dual Evaluation Kit	Spatial FOG Dual evaluation kit Includes items listed in section 6.1 L1 GPS, GLONASS and SBAS DGNSS supported Raw satellite data output supported License required for RTK, L2, BeiDou and Galileo RS422 communication

Table 4: Evaluation kit part numbers

7.2 Standalone Unit

The standard Spatial FOG Dual is shipped with RS422, RS232 is available upon request.

Part Number	Description	Notes
SPATIAL-FOG-DUAL	Spatial FOG Dual Unit	Spatial FOG Dual unit L1 GPS, GLONASS and SBAS DGNSS supported Raw satellite data output supported License required for RTK, L2, BeiDou and Galileo No cables included RS422 communication

Table 5: Standalone unit part numbers

7.3 Internal GNSS Receiver License Upgrades

These license upgrades can either be ordered with the unit or purchased later and installed in the field using Spatial FOG Manager.

Part Number	Description	Notes
SFD-LIC-8MM	RTK, L2, BeiDou and Galileo License Upgrade	GNSS receiver software license upgrade that enables 8mm RTK, L2, BeiDou and Galileo
SFD-LIC-LBAND		

Table 6: Internal GNSS receiver license upgrade part numbers

7.4 Accessories

Part Number	Description	Notes
8071-4336-78	Unterminated Interface Cable	Spatial FOG Dual connector with 2 metres of unterminated cable See section 8.11
SF-CABLE-KIT	Spatial FOG Dual Evaluation Cable Harness	Spatial FOG Dual connector with 2 metres of cable to industry standard connectors See section 8.12
CABLE-FTDI	USB to RS232 / RS422 cable 1 m	FTDI USB to RS232 / RS422 (selectable) 1 metre cable
SUPPLY-24V	24V DC Power Supply	100-240V AC Mains to 24V DC Power Supply (DC jack) Includes 2-pin plug types A/C/G/I
CAR12VPWR	Car auxiliary power outlet supply	Car auxiliary power supply to DC jack power supply
BF046WS180427-03	SMA to TNC 4m Cable	SMA to TNC connector 4 metre antenna cable
G5ANT-53A4T1	Antcom GNSS Antenna	Antcom G5 L1/L2/L5 GNSS antenna with survey mount
VSP6337L	VeroStar GNSS Antenna	VeroStar GNSS Antenna - L1/L2/L5 plus L-band, pole mount, TNC Female Connector
OBDII-ODOMETEU+0052	OBDII Odometer	OBDII Odometer Interface See section 9.8.2
Various Air Data Units	Air Data Unit	Air data unit provides pitot and static air data aiding for Spatial FOG Dual in fixed wing aircraft
MOUNT-SUCT	Suction Cup Antenna Mount	Suction cup 5/8" GNSS antenna survey mount for easy installation of GNSS antenna on vehicles

Table 7: Accessories part numbers



8 Specifications

8.1 Mechanical Drawings





Illustration 11: Mechanical drawings of Spatial FOG Dual



8.2 Centre of Gravity Drawings




Illustration 12: Centre of Gravity mechanical drawing of Spatial FOG Dual

8.3 Navigation Specifications

Parameter	Value
Horizontal Position Accuracy	0.8 m
Vertical Position Accuracy	1.5 m
Horizontal Position Accuracy (RTK or Kinematica Post Processing)	0.008 m
Vertical Position Accuracy (RTK or Kinematica Post Processing)	0.015 m
Velocity Accuracy	0.005 m/s
Roll & Pitch Accuracy	0.01 °
Heading Accuracy	0.01 °
Heading Accuracy (north seeking only)	0.25 ° secant latitude
Roll & Pitch Accuracy (Kinematica Post Processing)	0.005 °
Heading Accuracy (Kinematica Post Processing)	0.007 °
Orientation Range	Unlimited
Hot Start Time	2 s
Internal Filter Rate	1000 Hz
Output Data Rate	Up to 1000 Hz

Table 8: Navigation specifications

8.4 Heading Accuracy

Antenna Separation	Accuracy
0.5 m	0.03 °
1 m	0.01 °
2 m	0.007 °
5 m	0.005 °
10 m	0.002 °

Table 9: Heading accuracy

8.5 Sensor Specifications

Parameter	Accelerometers	Gyroscopes	Magnetometers	Pressure
Range	±10 g	±490 °/s	±8 G	10 to 120 KPa
Noise Density (Random Walk)	120 ug/√Hz (0.07 m/s/√hr)	0.7 °/hr/√Hz (0.012 °/√hr)	210 uG/√Hz	0.56 Pa/√Hz
Bias Instability	15 ug	0.1 °/hr	-	10 Pa
Initial Bias	< 1 mg	< 2 °/hr	-	< 100 Pa
Non-linearity	< 0.03 %	< 0.005 %	< 0.08 %	-
Scale Factor Stability	< 0.04 %	< 0.02 %	< 0.09 %	-
Cross-axis Alignment Error	< 0.04 °	< 0.02 °	< 0.05 °	-
Bandwidth	200 Hz	440 Hz	110 Hz	50 Hz

Table 10: Sensor specifications

8.6 GNSS Specifications

Parameter	Value
Model	Trimble MB-Two
Supported Navigation Systems	GPS L1, L2 GLONASS L1, L2 GALILEO E1, E5b BeiDou B1, B2
Supported SBAS Systems	WAAS EGNOS MSAS GAGAN QZSS Trimble RTX
Update Rate	20 Hz
Hot Start First Fix	3 s
Cold Start First Fix	30 s
Horizontal Position Accuracy	1.2 m
Horizontal Position Accuracy (with SBAS)	0.5 m
Horizontal Position Accuracy (with RTK)	0.008 m
Velocity Accuracy	0.005 m/s
Timing Accuracy	20 ns
Acceleration Limit	11 g

Table 11: GNSS Specifications

8.7 Communication Specifications


Parameter	Value
Interface	RS422 (RS232 optional)
Primary Port Speed	2400 to 10 M baud
Auxiliary Port Speed	2400 to 2 M baud
GPIO Port Speed	2400 to 250 K baud
Protocol	AN Packet Protocol
Peripheral Interface	2x GPIO 1x Auxiliary RS232 1x GNSS corrections RS232
GPIO Level	5 V or RS232

Table 12: Communication specifications

8.8 Hardware Specifications

Parameter	Value
Operating Voltage	9 to 36 V
Input Protection	-40 to 100 V
Power Consumption	510 mA @ 12 V (typical)
Backup Battery Capacity	> 48 hrs
Backup Battery Charge Time	30 mins
Backup Battery Endurance	> 10 years
Operating Temperature	-40 °C to 75 °C
Environmental Sealing	IP68 MIL-STD-810G
MTBF	> 36,000 hours
Shock Limit	40 g 11 ms
Dimensions	94 x 94 x 95 mm
Weight	740 grams

Table 13: Hardware specifications



8.9 Electrical Specifications

Parameter	Minimum	Typical	Maximum
Power Supply			
Input Supply Voltage	9 V		36 V
Input Protection Range	-40 V		100 V
RS232			
Tx Voltage Low		-5.4 V	-5 V
Tx Voltage High	5 V	5.4 V	
Tx Short Circuit Current			±60 mA
Rx Threshold Low	0.6 V	1.2 V	
Rx Threshold High		1.5 V	2.0 V
RS422			
Tx Differential Output	1.5 V		
Tx Short Circuit Current			±250 mA
Rx Differential Threshold	-0.2 V		-0.05 V
GPIO			
Output Voltage Low	0 V		0.3 V
Output Voltage High	4.8 V		5 V
Output Current			5 mA
Input Voltage	-20 V		20 V
Input Threshold Low			1.5 V
Input Threshold High	3.5 V		
GNSS Antenna			
Active Antenna Supply Voltage	4.8 V		5 V
Antenna Supply Current			150 mA

Table 14: Electrical specifications

8.10 Power Consumption




Illustration 13: Maximum and typical current consumption across operating voltage

8.11 Connector Pin-out

Power supply and signal connections are made through a 13 pin Glenair mighty mouse series 801 connector. The Glenair part number is 801-007-16M8-13SA. The connector provides a reliable and rugged connection to Spatial FOG Dual under demanding conditions and is rated to IP68 in the mated condition. Connection to Spatial FOG Dual may be made with the Spatial FOG Dual evaluation cable harness, which provides a pre-terminated 2 metre cable assembly with all signals broken out to industry standard connectors, see section 8.12. Advanced Navigation also supplies connectors with 2 metres of unterminated cable, see Illustration 14. Custom lengths are available on request.




Illustration 14: Spatial FOG Dual connector with 2 metres of unterminated cable





Illustration 15: Spatial FOG Dual mated connector clearance

Pin	Colour	Function
1	Black	GPIO 1
2	Brown	GPIO 2
3	Red	Signal Ground
4	Orange	Power Ground
5	Yellow	Power Supply
6	Green	Primary RS422 Rx(+) / RS232 Rx
7	Blue	Primary RS422 Rx(-)
8	Violet	Primary RS422 Tx(+) / RS232 Tx
9	Grey	Primary RS422 Tx(-)
10	White	Auxiliary RS232 Tx
11	White/Black	Auxiliary RS232 Rx
12	White/Brown	GNSS RS232 Rx
13	White/Red	GNSS RS232 Tx

Table 15: Pin allocation table for Spatial FOG Dual connector

8.12 Spatial FOG Dual Evaluation Cable Harness

Advanced Navigation offers a pre-terminated evaluation cable harness for quick connection to Spatial FOG Dual. All external signal and power connections are provided with 2 metres of cable. For quick testing in applications, the interface cable is provided with industry standard 9 pin DSUB connectors on the communication channels with industry standard pinouts. The evaluation cable harness is supplied as part of the Spatial FOG Dual Evaluation Kit, see section 6.





Illustration 16: Spatial FOG Dual evaluation cable harness diagram

Colour	Function	Primary	Auxiliary	GNSS	GPIO	Power
Black	GPIO 1				2	
Brown	GPIO 2				3	
Red	Signal Ground	5	5	5	5	
Orange	Power Ground					Ring
Yellow	Power Supply					Tip
Green	Primary RS422 Rx(+)	3				
Blue	Primary RS422 Rx(-)	7				
Violet	Primary RS422 Tx(+)	2				
Grey	Primary RS422 Tx(-)	8				
White	Auxiliary RS232 Tx		2			
White/Black	Auxiliary RS232 Rx		3			
White/Brown	GNSS RS232 Rx			3		
White/Red	GNSS RS232 Tx			2		

Table 16: Spatial FOG Dual evaluation cable harness connector pin-out

8.13 Serial Number

The serial number can be inspected by using the device information dialogue in the Spatial FOG Manager software, see section 11.7.1. The primary serial number label is located inside the enclosure and is accessible only by Advanced Navigation technicians. The secondary serial number label is located on the outside rear of the enclosure with the serial number encoded in a 2D data matrix bar code to assist customers in tracking their units. The external label also contains the hardware version and build date. Applications are available for most smart-phones that can scan the 2D data matrix bar code to display the serial number.



Illustration 17: Spatial FOG Dual external serial number label

9 Installation


9.1 Installation Checklist

1. Securely mount the unit to the vehicle following the guidelines in section 9.2.
2. Mount the two GNSS antennas following the guidelines in section 9.5 and then connect the antenna cables between the antennas and the Spatial FOG Dual unit. If the two antennas are not installed in the standard configuration of primary front and secondary rear, the offset will need to be entered into the Dual Antenna dialogue in Spatial FOG Manager.
3. Connect the connector cable to Spatial FOG Dual and then connect a suitable power supply as specified in section 9.4. A suitable power supply is included in the evaluation kit.
4. Connect the USB converter cable to the primary port and a computer, open the Spatial FOG Manager software and click connect.
5. If the unit is mounted in an alignment other than the standard alignment of X pointing forward and Z pointing down, this alignment offset will need to be entered into the Alignment Configuration dialogue in Spatial FOG Manager. Please see section 9.2.1 for more details.
6. Accurately measure the GNSS antenna offset from the centre of the Spatial FOG Dual unit to the central base of the antenna in the body co-ordinate frame (X positive forward and Z positive down) and enter these values into the Alignment Configuration dialogue in Spatial FOG Manager. Please see section 9.5 for more details. Please note that the body axes are always X positive forward and Z positive down irrespective of any alignment offset entered in the previous step.
7. Enter the vehicle type in the Filter Options dialogue in Spatial FOG Manager.
8. The system is now ready for use.

9.2 Position and Alignment

When installing Spatial FOG Dual into a vehicle, correct positioning and alignment are essential to achieve good performance. There are a number of goals in selecting a mounting site in your application, these are:

1. Spatial FOG Dual should be mounted in an area that is not going to exceed its temperature range and mounted in a manner that will properly dissipate heat; please contact support@advancednavigation.com for advice specific to your application.
2. Spatial FOG Dual should be mounted away from vibration where possible.
3. Spatial FOG Dual should be mounted within several metres of the GNSS antenna where possible.
4. If atmospheric altitude is going to be used, the two vents on the sides of Spatial FOG Dual should not be obstructed.
5. Spatial FOG Dual should be mounted close to the centre of gravity of the vehicle where possible.
6. As FOG technology is subject to minor bias variations under strong magnetic fields, Spatial FOG Dual should be mounted at least 0.25 metres away from sources of dynamic magnetic



interference such as high current wiring, large motors and rotating or reciprocating machinery.

9.2.1 Alignment

The easiest way to align Spatial FOG Dual is by installing it with the sensor axes aligned with the vehicle axes. This means that the X axis points forward towards the front of the vehicle and the Z axis points down towards the ground.

If aligning Spatial FOG Dual with the vehicle axes is not possible or not optimal, it may be mounted in a different alignment and the alignment offset should be configured using the alignment configuration dialogue in Spatial FOG Manager, see section 11.8.4. For easy alignment, the set zero orientation button in the Spatial FOG Manager alignment dialogue can be used to set the current orientation as the zero orientation alignment, see section 11.8.4. Please note that this will only correct for roll and pitch offsets. Any heading offset will need to be entered manually and saved before using this function.

9.3 Mounting Plate

Spatial FOG Dual's mounting plate and hole guide is shown below in Illustration 18. The holes are designed for M4 bolts. The alignment holes can be used to ensure precise alignment of Spatial FOG Dual through the use of alignment pins.




Illustration 18: Spatial FOG Dual mounting plate

9.4 Power Supply

A high level of power supply filtering has been built into Spatial FOG Dual to allow for reliable operation in demanding environments. Spatial FOG Dual contains a fully isolated power supply and has separate grounds for power and signal to ensure that power supply noise does not corrupt communications or cause ground loops with other equipment. When wiring the system, the signal ground should be routed with the primary RS232, auxiliary RS232, GNSS RS232 and GPIO pins. The power ground should be routed with the power supply to the power source.

A power supply should be selected that can provide at least the maximum current calculated from the graph in Illustration 13.

Spatial FOG Dual contains an active protection circuit on the power supply input that protects the unit from under-voltage, over-voltage and reverse polarity events. The protection circuit shuts off power and automatically recovers the unit to full operation once the fault is removed. Take care when running the unit close to its under-voltage lockout of 9 V because small voltage drops can engage the under-voltage shutdown and potentially oscillate between the on and off state. It is recommended that the unit is always run at 10 V or more to avoid issues associated with this.



9.5 GNSS Antennas

The GNSS antennas should be installed level with a clear unobstructed view of the sky and close to the Spatial FOG Dual unit where possible. The antennas should be mounted away from any RF emitters. It is important to have a ground plane (flat conductive surface such as a piece of plate aluminium) under the antenna with a minimum radius of 60mm. Correct antenna positioning is very important for Spatial FOG Dual's heading to function correctly.

The primary antenna position offset should be configured in the Spatial FOG Dual unit by using the alignment configuration dialogue in Spatial FOG Manager, see section 11.8.4. The antenna offset is measured from the centre of the Spatial FOG Dual unit to the central base (ARP) of the antenna in the body frame. It is very important to set the antenna offset accurately as Spatial FOG Dual corrects for lever arm velocities. Incorrect GNSS antenna offset will lead to performance degradation under turning and angular rotations.

An example installation with axes marked is shown below in Illustration 19 and Illustration 20. In this installation there would be a positive X antenna offset value, a negative Y antenna offset value and a negative Z offset value.




Illustration 19: Spatial FOG Dual antenna offset isometric view






Illustration 20: Spatial FOG Dual antenna offset front view

The secondary antenna should be mounted directly behind the primary antenna with as much separation as possible. The higher the separation the better the orientation accuracy. See Illustration 21 for example mounting on a car. If it is impractical to mount the secondary antenna directly behind the primary antenna, it can be mounted in another position. In this case the secondary antenna offset must be accurately measured and entered using the dual antenna configuration dialogue in Spatial FOG Manager, see section 11.8.12.



*Illustration 21: Spatial
FOG Dual example
antenna placement*


The standard antenna supplied in the Spatial FOG Dual evaluation kit is the Antcom G5Ant-53A4T1. It is an L1/L2/L5 RTK antenna that supports GPS, GLONASS, BeiDou, Galileo, Omnistar and SBAS. It is environmentally sealed to the IP68 standard.

If you are supplying your own antenna it is important to ensure that the antenna is able to receive all constellations and not just GPS, otherwise you will not achieve full performance. It is also important to select an IP67 antenna with an IP67 SMA connector, otherwise the system will not be environmentally sealed.

It is recommended to use an antenna with the following characteristics:

- The antenna should be capable of receiving GPS, GLONASS, BeiDou and Galileo.
- The antenna needs to have an accurate phase centre. This is required for the dual antenna heading to function correctly. Low performance (low cost) antennas are typically not able to achieve good heading performance.
- If the unit is being used for RTK, the antenna needs to be capable of receiving both L1 and L2. It should also have an accurate phase centre.
- The antenna should have a minimum LNA gain of 29dB and a maximum gain of 50dB.
- The antenna should be environmentally sealed, including connectors.

If you are sourcing your own antenna cables it is important to ensure that the antenna has enough gain to support the loss over the cable. Spatial FOG Dual requires a minimum of 25dB of gain at the connector. With the standard 4 metre RG-58/U antenna cables supplied by Advanced Navigation, the minimum antenna gain is 27dB.



9.6 GNSS Antenna Cables

The antenna cables should be routed away from powerful RF emitters, high current wiring, high temperatures and any rotating or reciprocating machinery. It is very important not to bend the antenna cable beyond its maximum bend radius. It is recommended to use wide cable ties and be careful not to do them up too tight. Advanced Navigation recommends using either RG58 low loss or LMR240 coaxial cable combined with high quality connectors. LMR300 and LMR400 can also be used to minimise loss for very long antenna cables.

Cable Type	Minimum Bend Radius	Signal Loss
RG-58/U Low Loss	20 mm	~0.92 dB/m
LMR240	20 mm	~0.33 dB/m
LMR300	22.2 mm	~0.26 dB/m
LMR400	25.4 mm	~0.17 dB/m

Table 17: GNSS antenna co-axial cable properties

9.7 Static Port

Spatial FOG Dual uses atmospheric pressure to stabilise its vertical velocity. The static port vents can be found on the sides of the Spatial FOG Dual enclosure at the top. These are special vents that do not allow water to enter the enclosure.

9.8 Odometer

On ground vehicles, the use of an odometer input can greatly improve Spatial FOG Dual's navigation and orientation solution during GNSS dropouts. With a high resolution wheel encoder Spatial FOG Dual can be used to navigate indoors with GNSS disabled altogether.

There are several different options for odometer installation which are listed below.

9.8.1 Factory VSS Signal


Most road cars since 1980 contain a VSS (vehicle speed sensor) signal that can be wired directly into one of Spatial FOG Dual's GPIO pins. The vehicle should be taken to an automotive electrician to perform the work.

To setup the odometer, the appropriate GPIO pin should be set to the odometer input function using Spatial FOG Manager, see section 11.8.6. The odometer pulse length must then be set either manually or automatically, please see section 10.9 for more information.

For more information on the GPIO signals and their requirements please see section 12.4.3.

9.8.2 OBDII Odometer Interface

For applications where it is undesirable to modify the vehicle or the system needs to be used with multiple vehicles, the OBDII odometer interface may be a better solution. OBDII is a vehicle diagnostic port standard and most vehicles from the mid 1990s onwards contain an OBDII port in the drivers side foot well. Advanced Navigation produces an OBDII odometer interface that plugs into this OBDII port and feeds Spatial FOG Dual with odometer data over the Auxiliary RS232 port, please see Illustration 22. These units are priced at approximately AUD 500. Please contact



Advanced Navigation sales for more information.



Illustration 22: Advanced Navigation OBDII Odometer

9.8.3 Aftermarket Wheel Speed Sensor

Applications requiring very high performance are recommended to use a high precision aftermarket wheel speed sensor. Advanced Navigation recommends aftermarket wheel speed sensors from Pegasem or GMH Engineering.



*Illustration 23:
Aftermarket wheel speed
sensor*

9.8.4 Radar Speed Sensor

For applications requiring high performance in harsh conditions where aftermarket wheel speed sensors are not feasible, a radar speed sensor is recommended. Advanced Navigation recommends radar speed sensors from Stalker or GMH Engineering.



Illustration 24: Radar speed sensor


9.9 Vibration

Spatial FOG Dual is able to tolerate a high level of vibration compared to other inertial systems. There is however a limit to the amount of vibration that Spatial FOG Dual can tolerate and large levels of vibration will cause Spatial FOG Dual's accuracy to degrade.

When mounting Spatial FOG Dual to a platform with vibration there are several options. It is recommended to first try mounting Spatial FOG Dual and see whether it can tolerate the vibrations. The raw sensor view in the Spatial FOG Manager software can give you a good idea of how bad the vibrations are. If the vibrations are causing the sensors to go over range you will need to take preventative steps against the vibration.

If Spatial FOG Dual is unable to tolerate the vibrations there are several options:

1. Try to find a mounting point with less vibration.
2. Spatial FOG Dual can be mounted on top of a small flat piece of rubber. Please note that this may cause small changing orientation errors due to flexing of the rubber.
3. Spatial FOG Dual can be mounted to a plate which is then mounted to the platform through vibration isolation mounts.



10 Operation

10.1 Filter

Spatial FOG Dual contains a sophisticated filter which it uses to fuse all its sensors into a state estimation. The filter is a set of custom algorithms that have similar principles to a kalman filter, but operate differently. Spatial FOG Dual's custom filter makes decisions based upon context and history which greatly improves performance and makes it more resilient to error sources than a typical kalman filter.

Under rare conditions, when there are large errors present that Spatial FOG Dual's filter cannot compensate for, it can become unstable. If Spatial FOG Dual's filter does become unstable a monitoring process will immediately reset the filter to the last known good state. The filter initialised flag will remain reset until the filter stabilises again. In real time control applications it is very important to monitor Spatial FOG Dual's filter status, so that data can be ignored if a situation occurs causing the filter to reset.

10.2 Initialisation

There are four different levels of initialisation on Spatial FOG Dual. These are orientation, navigation, heading and time. The initialisation can be monitored by inspecting the status view in Spatial FOG Manager, see section 11.7.2.





Illustration 25: The four initialisation levels

After all four levels of initialisation, Spatial FOG Dual's filter takes several minutes to achieve its full accuracy. It is recommended to wait two minutes after initialisation for applications requiring high accuracy.

10.2.1 Orientation Initialisation

Orientation initialisation occurs automatically upon power on and typically completes within several seconds. Once orientation initialisation is complete, the roll, pitch and angular velocity values will be valid.

When Spatial FOG Dual starts up, it assumes that it can be in any orientation. To determine its orientation it uses the accelerometers to detect the gravity vector. Whilst this is occurring, if there are random accelerations present, these can cause an incorrect orientation to be detected. To prevent this, Spatial FOG Dual monitors the accelerometers and gyroscopes and restarts the orientation detection if there are sudden movements. It is however still possible under some



circumstances for it to miss minor movements and start with a small orientation error. In this scenario Spatial FOG Dual will progressively correct the orientation error over a period of several seconds.

10.2.2 Navigation Initialisation

Navigation initialisation completes once the system has determined a starting position. The most common method of navigation initialisation is for the system to get a 3D GNSS fix. If the system is hot starting it will remember it's position from when it was switched off and use this as the starting position. The other possibility for navigation initialisation is an external position source, see section 12.2 for more information. In a situation where a GNSS fix is not available to initialise navigation, it can be initialised manually by entering a position into the position dialogue in Spatial FOG Manager, see section 11.8.11.

Once navigation initialisation is complete, the position, velocity and acceleration values will be valid.

10.2.3 Heading Initialisation

Heading initialisation completes once the system has determined a heading. The conditions required to determine a heading depend upon the heading source being used, see section 10.5. The default heading source is dual antenna heading and this will initialise the heading within several minutes of power on assuming both antennas are connected with a clear unobstructed view of the sky. The system can be stationary or moving during this initialisation. If the system is hot starting it will remember it's heading from when it was switched off and use this as the starting heading until another source becomes available.

Until the heading has been initialised, the system will not be able to navigate without a GNSS fix and the roll and pitch values will not be able to reach full accuracy.

10.2.4 Time Initialisation


Time initialisation completes once the system has determined time accurately. This occurs as soon as the GNSS receiver obtains it's first fix. It is also possible to provide an external source of time, see section 12.2 for more information on external time sources.

Until the time has initialised the values of unix time and formatted time that Spatial FOG Dual outputs will not be valid and may change.

10.3 Hot Start

Spatial FOG Dual is the first GNSS/INS on the market with hot start functionality. This allows Spatial FOG Dual to start inertial navigation within 2 seconds and obtain a GNSS fix in as little as 3 seconds. Spatial FOG Dual's hot start is always on and fully automatic.

A next generation backup battery system within Spatial FOG Dual provides the hot start ability for more than 24 hours without power. When Spatial FOG Dual hot starts it assumes that it is in the same state it was when it lost power and begins navigating from that position. The hot start also provides ephemeris, almanac and time information to the GNSS receiver which allows it to achieve a fix far more quickly than it otherwise would. When the GNSS achieves it's first fix, if this position deviates from the hot start position, Spatial FOG Dual will jump to the new position without causing any side effects to the filter.



Whilst Spatial FOG Dual is without power it keeps track of the time accurately to within 1 second so that the time is immediately valid on a hot start.

Spatial FOG Dual's hot start is of particular benefit to vehicle tracking and robotics applications. The primary benefits are immunity and fast recovery from power failure as well as fast startup time.

10.4 Time

Spatial FOG Dual was designed to provide a highly accurate time reference. When a GNSS fix is available Spatial FOG Dual's time is accurate to within 50 nanoseconds. When a GNSS fix is lost, Spatial FOG Dual's time accuracy typically remains within 10 microseconds over extended time periods. When Spatial FOG Dual hot starts the time accuracy is typically within 1 second immediately on startup and corrected to within 50 nanoseconds as soon as a GNSS fix is achieved. To synchronise with Spatial FOG Dual's high accuracy time, both the packet protocol and a 1PPS line must be used.

10.5 Heading Source

There are four different heading sources available for Spatial FOG Dual. By default Spatial FOG Dual uses dual antenna heading. This can be complemented with velocity heading for forward driving vehicles such as cars. In applications where GNSS is not available, north seeking gyrocompass heading can be used. It is possible to use multiple heading sources and this will often provide performance benefits.

10.5.1 Dual Antenna Heading

Dual antenna heading is the default heading source and provides very accurate heading while GNSS is available. Dual antenna heading works under both stationary and moving conditions and does not require any specific initialisation procedure. Dual antenna heading only works when there is a good GNSS fix available. It requires a clear view of the sky with minimal nearby sources of interference or multipath.


10.5.2 North Seeking Gyrocompass Heading

Spatial FOG Dual's high accuracy gyroscopes allow it to detect the rotation of the earth and seek north with a high degree of accuracy. When used as the sole heading source, initialisation of the north seeking takes 15 minutes and requires that the unit remain stationary in between three rotations. With the assistance of another heading source, the gyrocompass heading can take as little as 60 seconds to initialise and will not require any rotations or stationary time.

For example once the system has initialised with either dual antenna heading or velocity heading, the north seeking algorithm will automatically initialise during the first 60 seconds of operation without any intervention required.

When used as the sole heading source, the north seeking initialisation procedure is:

1. Turn on Spatial FOG Dual and leave stationary for 5 minutes.
2. Rotate Spatial FOG Dual approximately +90 degrees about the Z axis and leave stationary for 3 minutes.
3. Rotate Spatial FOG Dual approximately +90 degrees about the Z axis and leave stationary for 3 minutes.



4. Rotate Spatial FOG Dual approximately +90 degrees about the Z axis and leave stationary for 3 minutes.

To assist users in getting accustomed to the north seeking procedure there is a north seeking status dialogue in Spatial FOG Manager that provides feedback and guides the user through the initialisation process, see section 11.7.12.

Spatial FOG Dual's gyrocompass heading is fully automatic and always on. For all applications, the gyrocompass heading requires approximate position. For moving applications, the gyrocompass heading function requires continuous velocity updates to provide accurate heading. This data is typically provided by the internal GNSS receiver, however it can also be provided by an odometer or other type of speed sensor.

Applications where north seeking should not be used as the sole heading source include

- Environments with high vibration.
- Environments with rapid temperature fluctuations.
- Environments with strong changing magnetic fields close to the FOG unit (the fibre optic gyroscopes bias is affected by strong magnetic fields).
- Applications where it is impractical to perform the initialisation procedure.
- Applications where the system is moving at speeds of over 1 metre/second and no velocity aiding information is available.

In these scenarios an alternative heading source should be considered. Please see the alternative options of Dual Antenna Heading, Velocity Heading and External Heading. If in doubt, please contact Advanced Navigation support for assistance in selecting the correct heading source for your application.

10.5.3 Velocity Heading


Velocity heading works by deriving heading from the direction of velocity and acceleration. Velocity heading works well with cars, boats, fixed wing aircraft and other vehicles that don't move sideways. Velocity heading does not work with helicopters and other 3D vehicles. The downside of velocity heading is that heading can not be measured until the vehicle moves at a horizontal speed of over 1.15 metres/second with a GNSS fix. Velocity heading is very useful for getting accurate heading quickly on moving vehicles without requiring any specific initialisation procedure.

10.5.4 External Heading

External heading can be used if there is some other way to derive heading that is external to Spatial FOG Dual. Examples include reference markers and SLAM systems. The heading must be fed into Spatial FOG Dual using the External Heading Packet or through NMEA into a GPIO pin.

10.6 Magnetism

Spatial FOG Dual uses magnetometers to detect changes in heading which allows the north seeking algorithm to initialise faster if another heading source is not available. If strong dynamic magnetic disturbances are present this will not effect the accuracy of the heading but may cause the north seeking initialisation to take longer when GNSS is not available.



10.7 Data Anti Aliasing

Internally Spatial FOG Dual's filters update at 1000 Hz. When Spatial FOG Dual outputs data, most applications require the data at a much lower rate (typically < 100 Hz). This causes a problem for time based data such as velocities and accelerations where aliasing will occur at the lower rate. To prevent this problem, if the output rate is lower than 1000 Hz, Spatial FOG Dual will low pass filter the values of the time dependent data between packets to prevent aliasing. This is only the case when a packet is set up to output at a certain rate. If the packet is simply requested no anti aliasing will occur. Additionally there is no anti aliasing for non time dependent fields such as position.

10.8 Vehicle Profiles

Spatial FOG Dual supports a number of different vehicle profiles. These vehicle profiles impose constraints upon the filter that can increase performance. If your application matches one of the available vehicle profiles, it is recommended to select it for use in the filter options dialogue in Spatial FOG Manager, see section 11.8.2. For a list of the different vehicle profiles please see section 13.10.5.1. Please note that if the wrong vehicle profile is selected it can cause a significant decrease in performance.

10.9 Odometer Pulse Length


For Spatial FOG Dual to use a wheel speed sensor or odometer input, it must know the pulse length of the signal. The pulse length is the distance in metres between low to high transitions of the signal. The odometer pulse length can either be entered manually or automatically calibrated by Spatial FOG Dual. To enter the pulse length manually, please use the odometer configuration dialogue in Spatial FOG Manager, see section 11.8.7. To automatically calibrate the odometer pulse length please use the procedure listed below in section 10.9.1. By default the odometer will automatically calibrate itself.

10.9.1 Odometer Automatic Pulse Length Calibration Procedure

1. Ensure that the signal is connected correctly and that the GPIO pin is configured as an odometer input using the GPIO configuration dialogue in Spatial FOG Manager, see section 11.8.6.
2. Open Spatial FOG Manager, connect to Spatial FOG Dual and open the odometer configuration dialogue. In the odometer configuration dialogue tick the automatic pulse length calibration check box and press the write button, see section 11.8.7.
3. Wait until Spatial FOG Dual has a continuous GNSS fix and then drive 1000 metres over flat terrain with as little turning as possible.
4. If Spatial FOG Dual loses a GNSS fix for any extended period of time during the calibration, the distance travelled will be reset. The distance travelled can be checked in the odometer configuration dialogue to ensure that it has passed 1000 metres.
5. Once 1000 metres has been driven, press the read button and check that the automatic pulse length check box becomes un-ticked and the pulse length value is read.

10.10 Reversing Detection

Reversing detection is an algorithm that can detect when the vehicle is travelling in reverse. Knowledge of reverse motion is important when using velocity heading or odometer input to



provide correct results. If Spatial FOG Dual is fitted to a vehicle that does not reverse or doesn't use velocity heading or odometer, this function should be disabled. Reversing detection is enabled by default and it can be disabled using the filter configuration dialogue in Spatial FOG Manager, see section 11.8.2.

10.11 Motion Analysis

Motion analysis is an artificial intelligence algorithm that associates patterns in high frequency inertial data with the speed of the vehicle. After power on it takes some time to match patterns with speed before it will become active. Motion analysis only activates when dead reckoning and is most effective when the vehicle is near stationary. Motion analysis does not work in all situations and it's primary benefit is in ground vehicles. When active it can be recognised by 2Hz steps in velocity data. Motion analysis is disabled by default and can be enabled using the filter configuration window in Spatial FOG Manager, see section 11.8.2.

10.12 RAIM

RAIM stands for receiver autonomous integrity monitoring. It allows a GNSS receiver to detect and exclude both faulty and fraudulent satellite signals. Spatial FOG Dual's internal GNSS is equipped with RAIM and it is enabled by default.

10.13 RTK

Spatial FOG Dual's internal GNSS receiver supports RTK GNSS which uses correction data from a base station to provide significantly higher positional accuracy than standard GNSS. RTK requires additional infrastructure equipment to receive corrections and is not practical for all applications. There are two different options for receiving RTK corrections. For applications that are within good cellular coverage we recommend cellular RTK corrections, see section 10.13.1. For applications that have poor or no cellular coverage we recommend base station radio modem RTK corrections, see section 10.13.2.

10.13.1 Cellular RTK corrections



Illustration 26: ARWest JLink GSM cellular corrections receiver

For cellular RTK corrections, Advanced Navigation recommends the ARWest JLink GSM cellular

corrections receiver. This unit can be plugged directly into Spatial FOG Dual's GNSS RS232 port to receive cellular RTK corrections. Please contact ARWest for more information and pricing.

10.13.2 Base station radio modem RTK corrections



Illustration 27: Trimble R4 base station



Illustration 28: Trimble TDL 450L radio modem

Base station radio modem RTK corrections require two additional pieces of hardware, these are the base station and the radio modem receiver. The base station is setup at a fixed location and transmits corrections to the radio modem receiver that is connected to the mobile Spatial FOG Dual unit. The radio modem receiver and Spatial FOG Dual unit must remain within range of the base station to receive these corrections, typically this range is approximately 20km. Advanced Navigation recommends the Trimble R4 base station combined with the Trimble TDL 450L radio modem. Please contact your local Trimble dealer for more information and pricing.

10.14 Heave


Spatial FOG Dual can provide vertical heave position at four different points on a ship. Spatial FOG Dual's heave filter is always on and fully automatic. After power on, Spatial FOG Dual requires approximately 5 minutes for it's heave filter to converge upon an accurate solution. Heave works without a GNSS fix, however best heave performance is achieved when Spatial FOG Dual has a GNSS fix.

By default Spatial FOG Dual provides heave from the point at which the Spatial FOG Dual unit is mounted, however it can provide heave at four different offset points on the ship. To set the heave offsets, either use the heave configuration dialogue in Spatial FOG Manager, see section 11.8.9.

10.15 Environmental Exposure

Whilst Spatial FOG Dual is environmentally protected, there are clearly defined limits to this protection that must be adhered to for reliable operation.

Spatial FOG Dual is only protected when it's connector is mated and two IP67 SMA GNSS antennas are attached. When any of these connections are not made the unit offers no environmental protection.



Spanners or tools should never be used to tighten the connectors. They should only ever be finger tight.

10.15.1 Temperature

Spatial FOG Dual should not be subjected to temperature's outside of it's operating range. Subjecting Spatial FOG Dual to temperature's outside of the storage range can cause failure of the system.

10.15.2 Water

Spatial FOG Dual is water-proof to the IP68 standard which means that it can be submersed in water to a depth of up to 2 metres only. Submersion to depths beyond 2 metres can cause water entry and destruction of the internal electronics.

10.15.3 Salt

Spatial FOG Dual is made from marine grade aluminium which gives it reasonably good salt water corrosion resistance. However Spatial FOG Dual cannot tolerate extended periods of time in salt water environments. After any contact with salt water environments, Spatial FOG Dual should be thoroughly rinsed with fresh water.

10.15.4 Dirt and Dust

Spatial FOG Dual is completely sealed against dirt and dust entry. It is important to note that this is only the case when the connectors are mated. When un-mating the connectors if the Spatial FOG Dual unit is dirty or dusty, the dirt should be rinsed off with fresh water first and then dried off. This is to prevent dirt or dust entering the connectors which can cause them to fail.

10.15.5 PH Level

Environments with a high or low PH level can cause the Spatial FOG Dual enclosure to corrode. If Spatial FOG Dual comes into contact with these environments it should be rinsed in fresh water as soon as possible. It is not recommended to operate Spatial FOG Dual in non neutral PH environments.

10.15.6 Shocks

Spatial FOG Dual can tolerate shocks to 25g, however continuous shocks of this severity are likely to cause premature failure. Shocks above 25g can effect the factory sensor calibration and degrade performance. Normally shocks to Spatial FOG Dual when mounted in a vehicle are fine. Even a high speed car crash is likely to reach a peak of only 50g. Shocks directly to Spatial FOG Dual's enclosure can more easily go over the limit however so care should be taken when handling the unit prior to mounting.



11 Spatial FOG Manager

Spatial FOG Manager is a software tool provided by Advanced Navigation for logging, testing, display and configuration of Spatial FOG Dual. It is designed to be simple and easy to use.






Illustration 29: Screenshot of Spatial FOG Manager



11.1 Software Changelog

Version	Date	Changes
6.1	18/02/2022	Device information updated automatically after a firmware update GNSS receiver information is updated after applying a receiver option Improve display of Trimble receiver options Add ability to control log file location Included software version number in title Improved NTRIP mountpoint selection. Added handling of non-standard NTRIP server responses Improved NTRIP server reconnection Improved Log files saved by default in the directory from where the application is launched Improve export configuration reliability Updated source of map tiles Force the device to exit bootloader mode if a firmware update is not in progress
5.6	09/09/2020	Updated raw sensors dialogue to include all temperatures Updated network connection functionality to improve usability More information on the GNSS Receiver Information page Fixed bug with communications statistics dialogue cutting off numbers Added zero angular velocity update GPIO function Added Mavlink output GPIO function Added GNSS Receiver Update dialogue
4.6	18/09/2017	Added new GPIO functions to GPIO configuration Added new NMEA messages to GPIO output configuration Update to 3D mapping fixes issues with map data not loading
4.5	17/03/2017	Fix for incorrect leap second in RINEX files since 01/01/2017 More signals output in RINEX files
4.4	12/04/2016	Extended NTRIP support for older versions Log converter now outputs a KML file for Google Earth with detailed information as well as the GPX file Added serial port passthrough tool Secondary antenna raw satellite data is now converted to RINEX as well as the primary antenna
4.3	17/08/2015	Spatial Manager now requests all configuration upon connection Spatial Manager converts any configuration packets found in ANPP log files into text Bug fix for NTRIP invalid connection
4.2	02/04/2015	Initial Release



11.2 System Requirements

The software includes a 3D mapping display which requires a modern 3D graphics card and up to date drivers to run. If your machine does not meet the graphics requirements the mapping view will only show space without a globe.

When Spatial FOG Dual is running at very high output rates e.g. 1000 Hz, Spatial FOG Manager can consume significant system resources handling the large quantity of data.

11.3 Installation

Spatial FOG Manager does not need to be installed and can be run from any directory by double clicking on it. Spatial FOG Manager requires a recent version of Java, available at <http://www.java.com>. To open the program on some systems it may be necessary to right click and select open with → Java Runtime Environment.

The Spatial FOG Dual evaluation kit makes use of an FTDI USB to RS422 device. The drivers are normally installed automatically, if not they are available from <http://www.ftdichip.com/Drivers/VCP.htm>.

11.4 Troubleshooting

Please contact support@advancednavigation.com.au if you are having issues.

11.4.1 All Platforms

If the globe does not appear in the 3D map area, this indicates that either your graphics card is not powerful enough or your graphics card driver is out of date.

11.4.2 Windows

There is a well known problem with USB serial devices under Windows known as “crazy mouse”. The problem occurs when the system mistakenly installs the USB serial device as a mouse. Unfortunately Microsoft has not fixed this problem in over 15 years, so it probably won't be fixed. If you experience this problem, often a restart will resolve it. Otherwise there is a tool available at <http://www.stentec.com/anonftp/pub/wingps/pnpblockerssetup.exe> that can fix the issue.

If the serial port does not show up when you plug in your Spatial FOG Dual USB device, you may need to install the drivers from <http://www.ftdichip.com/Drivers/VCP.htm>.

If you experience a blue screen of death whilst using Spatial FOG Manager, this is typically a problem associated with older FTDI drivers. To resolve the problem, install the latest drivers from <http://www.ftdichip.com/Drivers/VCP.htm>.

When operating Spatial FOG Dual at a very high data rate, data can be lost due to the latency of the FTDI driver. To resolve this problem the latency of the driver should be reduced by going to control panel → system → device manager → ports and right click on the USB serial port, then click properties. In the properties window click the port settings tab and then the advanced button. You then need to change the latency timer setting to 1ms. Please see the screenshot in Illustration 30.




Illustration 30: Screenshot of latency timer setting

11.4.3 Linux

If serial ports do not show up, the typical cause is permissions. The user should add themselves to the dialout group with the command `sudo adduser username dialout`.

Compiz causes issues with the 3D mapping. If you are experiencing problems it is recommended to turn off compiz.

Modemmanager can also sometimes cause problems on Linux installations. If you are not using a modem, it is recommended to remove modemmanager with the command `sudo apt-get remove modemmanager`.

Spatial FOG Manager is able to run on the OpenJDK JRE but it uses significantly more system resources than when it is running on the Oracle JRE.

11.5 Main View




Illustration 31: Screenshot of Spatial FOG Manager main view

11.5.1 Serial Port


The serial port dialogue is used to connect to Spatial FOG Dual. You should select a serial port and baud rate and click connect. The default baud rate of Spatial FOG Dual is 115200. The connection indicator displays whether there is communication with a Spatial FOG Dual unit.

11.5.2 Attitude Indicator

The aircraft style attitude indicator shows roll and pitch through a virtual horizon. Around the sides heading, speed and height are shown. All units are SI (metric) and degrees.

11.5.3 Status Indicator

The status indicator section contains a Spatial FOG Dual status indicator, a fix indicator and a satellites table.



11.5.3.1 Spatial Status Indicator

This indicator shows any problems with Spatial FOG Dual. Before a GNSS fix is achieved it will show the status "Filter not initialised". Once the filter has initialised it should show "Healthy". Clicking on the indicator will show the detailed status flags.

11.5.3.2 Fix Indicator

This shows the status of the GNSS fix. Under normal operating conditions it should show either "3D Fix" or "SBAS Fix". When satellite visibility is poor it may show either "2D Fix" or "No Fix".

11.5.3.3 Satellites Table

The satellites table shows the number of active satellites being used in the current GNSS solution. More detailed information can be found in the satellites view.

11.5.4 3D Map

The 3D map shows Spatial FOG Dual's position on the Earth as well as a red trail of position history. When the filter initialises the map will automatically reset the view to Spatial FOG Dual's location. To move the camera click and drag on the map. To zoom in and out use the scroll wheel. To change the camera view right click and drag or shift click and drag.

11.5.5 3D Map Controls

11.5.5.1 Reset View

This resets the map view to Spatial FOG Dual's current position.

11.5.5.2 Clear History

This clears the current position history, this is the red trail shown on the map.

11.6 Logging

Spatial FOG Manager features a fully automatic logging system. Every time the serial port connect button is clicked Spatial FOG Manager starts a new log file in either the current directory or the user's home directory. The log file is given the file name SpatialLog_date_time.anpp and contains all of the raw data received from Spatial FOG Dual in the AN packet protocol. The log files are closed when the serial port is disconnected.

Logging can be disabled via command line `-n,--logdisable`, and log file location can be set via command line `-l,--logpath <Path of output logfile>`.

To convert these log files into easily accessible formats, the log converter dialogue in the tools menu can be used, see section 11.9.3. The log converter dialogue creates a folder and generates files in the CSV (comma separated values) format that can be easily opened with Microsoft Excel, Matlab, libreoffice and most other data analysis programs. It also creates a GPX file of position that is designed to be opened with Google Earth.

▼	Folder	SpatialLog_13-02-11_11-30-52	Today 1:02 PM	--	Folder
		EulerOrientation.csv	Today 1:02 PM	40 KB	comm...values
		EulerStandardDeviation.csv	Today 1:02 PM	39 KB	comm...values
		GoogleEarth.kml	Today 1:02 PM	78 KB	Googl...ument
		RawSensors.csv	Today 1:02 PM	101 KB	comm...values
		Satellites.csv	Today 1:02 PM	8 KB	comm...values
		State.csv	Today 1:02 PM	753 KB	comm...values
		Status.csv	Today 1:02 PM	57 KB	comm...values
		SpatialLog_13-02-11_11-30-52.anpp	Today 11:32 AM	264 KB	Document

Illustration 32: Screenshot showing log file and log conversion folder

11.7 Views

The views menu contains a number of different options for viewing data from Spatial FOG Dual.




Illustration 33: Screenshot of Spatial FOG Manager views menu

11.7.1 Device Information





Illustration 34: Screenshot of Spatial FOG Manager device information dialogue

11.7.2 Status

Status shows Spatial FOG Dual's complete status as contained in the system state packet detailed in section 13.9.1.1.






Illustration 35: Screenshot of Spatial FOG Manager status dialogue



11.7.3 Satellites

Satellites shows detailed information on the satellites that Spatial FOG Dual's GNSS receiver is tracking. Elevation and azimuth are in units of degrees.



System	PRN	Frequency	Elevation	Azimuth	SNR
GLONASS	1	L1C/A L1P L2P	50	187	43
GPS	22	L1C/A	16	63	28
GPS	23	L1C/A	17	275	41
GLONASS	8	L1C/A L1P L2P	38	104	43
GLONASS	11	L1C/A L1P L2P	63	52	43
GLONASS	17	L1C/A L1P L2P	15	231	38
GLONASS	10	L1C/A L1P L2P	35	140	39
GLONASS	24	L1C/A L1P L2P	18	286	36
GPS	31	L1C/A L2P	68	98	44
GPS	20	L1C/A L2P	28	228	42
GPS	1	L1C/A L2P	50	259	45
GPS	11	L1C/A L2P	37	293	45
GPS	32	L1C/A L2P	65	199	44
GPS	14	L1C/A	20	123	34
	14	L1C/A	49	347	38

Illustration 36: Screenshot of Spatial FOG Manager satellites dialogue



11.7.4 Raw Sensors

Raw sensors shows the temperature calibrated raw sensor values.




Illustration 37: Screenshot of Spatial FOG Manager raw sensors dialogue



11.7.5 Orientation

Orientation shows Spatial FOG Dual's orientation, angular velocity and orientation error.





Illustration 38: Screenshot of Spatial FOG Manager orientation dialogue



11.7.6 Position

Position shows Spatial FOG Dual's position and position error. Latitude and longitude are converted to North and East metres from a reference point that can be reset.




Illustration 39: Screenshot of Spatial FOG Manager position dialogue




11.7.7 Velocity and Acceleration

Velocity and Acceleration shows Spatial FOG Dual's velocity, acceleration and g-force.



Illustration 40: Screenshot of Spatial FOG Manager velocity and acceleration dialogue



11.7.8 3D Model

This dialogue shows a real-time 3D model of Spatial FOG Dual's orientation.




Illustration 41: Screenshot of Spatial FOG Manager 3D model dialogue

11.7.9 Communications Statistics

This dialogue shows statistics on the data packets received from Spatial FOG Dual and can be useful in diagnosing signal integrity problems.

Communications Statistics	
Packets Decoded:	7796
Bytes Decoded:	649627
Bytes Discarded:	0
LRC Errors:	0
CRC Errors:	0

Illustration 42: Screenshot of Spatial FOG Manager communications statistics dialogue



11.7.10 GNSS Receiver Information

This dialogue shows information on the internal GNSS receiver contained inside of Spatial FOG Dual.




Illustration 43: Screenshot of Spatial FOG Manager GNSS receive information dialogue

11.7.11 Heave

For the heave dialogue to function the heave packet (ID 58) must be set to output periodically using the Packet Rates dialogue.





Illustration 44: Screenshot of Spatial FOG Manager heave dialogue

11.7.12 North Seeking Status

The north seeking status view guides the user through the north seeking initialisation procedure and provides feedback on the progress. It is not necessary to use this dialogue to perform the north seeking initialisation, however it can be very helpful for users getting accustomed to the process. The error value provided gives an approximation of the bias convergence accuracy. A good initialisation should yield an error of less than 10%. Each quadrant represents a 90 degree segment about the Z axis in which data must be collected and the unit starts at zero degrees in



quadrant 1 when powered on, see Illustration 46.




Illustration 45: Screenshot of Spatial FOG Manager north seeking status dialogue




Illustration 46: North seeking quadrants around Z axis

11.8 Configuration

The configuration menu contains a number of dialogues for the configuration of Spatial FOG Dual.




Illustration 47: Screenshot of Spatial FOG Manager configuration menu

11.8.1 Configuration Export

The configuration export dialogue can be used to export all Spatial FOG Dual settings to a file. This file can be imported at a later date or on other units. This is useful to restore a unit to preset configuration at a later date or for batch configuration of multiple units.





Illustration 48: Screenshot of Spatial Manager configuration export dialogue



11.8.2 Filter Options

For most applications the default filter options should be used and only the vehicle profile set. If in doubt please contact support@advancednavigation.com.au.





Illustration 49: Screenshot of Spatial FOG Manager filter options dialogue




11.8.3 Packet Rates

The packet rates dialogue allows the user to specify which packets output on a periodic basis and at what rate. The default packets enabled are the System State Packet (ID 20) and the Raw Sensors Packet (ID 28) at 20Hz and these typically provide all the data that a user will require. These two packets need to be enabled for the data graphs to update in Spatial FOG Manager. Other state packets can be enabled as required. Please see the Packet Summary table in section 13.7 for a list of all packets.

Packet ID	Period	Output Rate
20	50	20.0 Hz
28	200	5.0 Hz

Illustration 50: Screenshot of Spatial FOG Manager packet rates dialogue



11.8.4 Alignment Configuration

The alignment configuration dialogue is used to set the alignment offsets of the system installation. It is important to set the values in this dialogue correctly for accurate results. For most applications only the GNSS antenna offset values need to be entered and the rest of the values can be left at their factory defaults of zero.

Alignment Offset		Odometer Offset	
Roll Offset:	0.000 Degrees	X Offset:	0.000 Metres
Pitch Offset:	-0.000 Degrees	Y Offset:	0.000 Metres
Heading Offset:	0.000 Degrees	Z Offset:	0.000 Metres

Zero Current Orientation

GNSS Antenna Offset		External Data Offset	
X Offset:	1.800 Metres	X Offset:	0.000 Metres
Y Offset:	0.000 Metres	Y Offset:	0.000 Metres
Z Offset:	-0.800 Metres	Z Offset:	0.000 Metres

Save

Illustration 51: Screenshot of Spatial FOG Manager alignment configuration dialogue

11.8.4.1 Alignment Offset

If Spatial FOG Dual is installed into the vehicle with the X axis pointing forwards and the Z axis pointing down, then no alignment offset is required and the roll, pitch and heading offset values can remain at the factory defaults of zero.

If the unit is installed in a different orientation then the roll, pitch and heading offset must be entered. For example if the unit is installed on its side with the X axis pointing up and the Z axis pointing forwards and no change to the Y axis, then this would result in a pitch offset of +90 degrees with roll and heading remaining zero.

If there is a small misalignment due to mechanical mounting error this can be compensated for by setting the vehicle stationary on a level surface and pressing the zero current orientation button. Please note that this will only correct for roll and pitch offsets, the heading offset must be entered manually and saved before using this function.

All the other offsets will be measured in the realigned body co-ordinate frame (X positive forward, Z positive down) after being corrected for any alignment offset entered.

11.8.4.2 GNSS Antenna Offset

The GNSS antenna offset is measured from the centre of the Spatial FOG Dual unit to the centre of the antenna in the body co-ordinate frame (X positive forward, Z positive down).

11.8.4.3 Odometer Offset

The odometer offset is measured from the centre of the Spatial FOG Dual unit to the point at which the vehicle's tyre makes contact with the road in the body co-ordinate frame (X positive forward, Z positive down).

11.8.4.4 External Data Offset

These values are only required for speciality applications operating with external sources of data. Please contact support@advancednavigation.com.au for assistance with these values.

11.8.5 Baud Rates

When changing baud rates, some Microsoft Windows machines are unable to function at the higher baud rates. It is recommended to test the baud rate first with the permanent box unticked. This way, if it is not possible to communicate at the higher baud rate, a power cycle can be used to revert to the previous baud rate.





Illustration 52: Screenshot of Spatial FOG Manager baud rates dialogue



11.8.6 GPIO Configuration

This dialogue allows the user to select the function of the GPIO pins and Auxiliary RS232. These functions change dynamically and are effective immediately upon pressing save. Please note that GPIO pins function at RS232 levels for data functions and 0 to 5 volt levels for all other functions. The internal hardware automatically reconfigures based upon the selected function.




Illustration 53: Screenshot of Spatial FOG Manager GPIO configuration dialogue

11.8.7 Odometer

The odometer dialogue allows the user to configure the odometer pulse length and view the real time odometer data to verify correct operation.




Illustration 54: Screenshot of Spatial FOG Manager odometer configuration dialogue

11.8.8 Reset

The reset button causes the system to perform a power cycle as if the unit had the power removed and reapplied. The factory restore button causes the system to erase all settings and restore factory defaults. It also erases the hot start data so that the system is forced to perform a cold start.




Illustration 55: Screenshot of Spatial FOG Manager reset dialogue

11.8.9 Heave Offset

The heave offset dialogue allows the user to move the heave measurement points to different positions on the vessel. When the values are zero the measurement point is the centre of the Spatial FOG Dual unit. This can be offset to a different position on the ship by entering the offset value from the centre of the Spatial FOG Dual unit to the desired position in the body co-ordinate frame (X positive forwards, Z positive down). Please note that these values only apply to the Heave Packet. NMEA, TSS and Simrad heave is not affected by the values in this dialogue which are always measured at the centre of the Spatial FOG Dual unit.




Illustration 56: Screenshot of Spatial FOG Manager heave offset dialogue



11.8.10 GPIO Output

The GPIO output configuration dialogue allows the user to configure the output rates for the GPIO and Auxiliary RS232 data functions NMEA, TSS and PASHR.


NMEA		
Fix Mode:	Normal	
	GPIO1 Rate	Auxiliary Tx Rate
GPZDA Rate:	Disabled	Disabled
GPGGA Rate:	Disabled	Disabled
GPVTG Rate:	Disabled	Disabled
GPRMC Rate:	1 Hz	1 Hz
GPHTD Rate:	Disabled	Disabled
GPGLL Rate:	Disabled	Disabled
PASHR Rate:	Disabled	Disabled

TSS		
	GPIO1 Rate	Auxiliary Tx Rate
	1 Hz	1 Hz

Simrad		
	GPIO1 Rate	Auxiliary Tx Rate
	1 Hz	1 Hz

Save

Illustration 57: Screenshot of Spatial FOG Manager GPIO output configuration dialogue



11.8.11 Manual Initialisation

The manual initialisation dialogue can be used to set the position of Spatial FOG Dual when the unit is supplied without a GNSS receiver or when a GNSS fix is not available. Setting this value will initialise navigation. The heading value can also be set manually in the absence of a heading source, this will initialise the heading filter.





Illustration 58: Screenshot of Spatial FOG Manager Manual Initialisation configuration dialogue



11.8.12 Dual Antenna

The dual antenna configuration dialogue is only used when Spatial FOG Dual is being operated with the optional dual antenna upgrade kit.

The recommended installation is with the primary antenna to the front and the secondary antenna directly to the rear along the same axis, in which case the values in this dialogue can be left at their factory defaults.

If it is not practical to mount the antennas in the recommended alignment, the alternate alignment must be entered into this dialogue. It is recommended to try and use one of the automatic offsets where possible where the antennas must be installed in one of four different automatic offset orientations aligned on an axis.

If it is not possible to use one of the automatic offsets, the antennas can be installed in any configuration and a manual offset should be entered. The manual offset is measured from the central base of the secondary antenna to the central base of the primary antenna in the body co-ordinate frame (X positive forward, Z positive down). If using a manual offset, please be careful to measure the offset accurately, as even small offset errors can result in relatively large heading errors e.g. 2 cm error = 1.15 degrees heading error with a 1 metre separation.

When using an automatic offset, the manual offset values are ignored and when using a manual offset, the automatic offset selection is ignored.

Dual Antenna Configuration

Automatic Offset

Automatic Offset

Primary Front and Secondary Rear

Manual Offset

Offset from secondary antenna to primary antenna

X: 0.0 Metres

Y: 0.0 Metres

Z: 0.0 Metres

Save

Illustration 59: Screenshot of Spatial FOG Manager dual antenna configuration dialogue

11.9 Tools

The tools menu contains tools for performing procedures with Spatial FOG Dual.




Illustration 60: Screenshot of Spatial FOG Manager tools menu

11.9.1 Terminal

The terminal is only used during specialised technical support with Advanced Navigation engineers.

11.9.2 Firmware Update

The firmware update dialogue is used to update Spatial FOG Dual's firmware. Advanced Navigation firmware files have the extension .anfw. The dialogue shows the version number of the firmware file along with the date and time it was generated by engineering.





Illustration 61: Screenshot of Spatial FOG Manager firmware update dialogue



11.9.3 Log Converter

This tool allows the user to convert Spatial FOG Dual log files into various standard formats that are readable by many programs, as well as set a user configurable log path. The position offset values can be used to project the exported position to a point other than the centre of the Spatial FOG Dual unit. For most users these values should be left at zero.




Illustration 62: Screenshot of Spatial FOG Manager log converter dialogue

11.9.4 NTRIP Client

The NTRIP client can be used to connect to a network DGPS or RTK service to stream correction data to Spatial FOG for DGPS or RTK. The NTRIP client requires an internet connection to function. Please contact support@advancednavigation.com.au for guidance on getting set up with network DGPS or RTK.




Illustration 63: Screenshot of Spatial FOG Manager NTRIP client dialogue

11.9.5 Network Connect

The network connect dialogue allows Spatial FOG Manager to make a connection to Spatial FOG over a TCP/IP network rather than the default serial port connection. This allows Spatial FOG to be used with ethernet to serial converters. Advanced Navigation recommends Lantronix ethernet to serial converters.

12 Interfacing

12.1 Communication

Communication with Spatial FOG Dual is over the primary RS422 or RS232 interface in the Advanced Navigation Packet Protocol (ANPP). The RS422 or RS232 format is fixed at 1 start bit, 8 data bits, 1 stop bit and no parity. See section 13 for details on the protocol.

12.1.1 Baud Rate

The default baud rate of Spatial FOG Dual is 115,200. The primary port RS422 baud rate can be set anywhere from 2400 to 10,000,000 baud and can be modified using the Spatial FOG Manager software or the baud rate packet, see section 13.10.3. It is important to select a baud rate that is capable of carrying the amount of data that Spatial FOG Dual is set to send. See packet rates in section 13.5 for more details on data output calculation. The data rate in bytes per second can be calculated by dividing the baud rate by 10. For example if the baud rate is 115,200, then the data rate is 11,520 bytes per second.

12.2 External Data

External sources of position, velocity and/or heading can be integrated into Spatial FOG Dual's filter solution. The data can be sent to Spatial FOG Dual in the ANPP format over the primary port or through one of the GPIO pins in a number of different formats. If using the ANPP, please use Table 18 below to find the relevant section. If using the GPIOs, please see section 12.3.

Packet	Section
External Position and Velocity	13.9.25
External Position	13.9.26
External Velocity	13.9.27
External Body Velocity	13.9.28
External Heading	13.9.29
External Time	13.9.33
External Depth	13.9.34
External Odometer	13.9.43
External Air Data	13.9.44

Table 18: ANPP external data reference

12.3 GPIO Pins and Auxiliary RS232

Spatial FOG Dual contains two general purpose input output pins and one auxiliary RS232 port on the main connector. These pins are multi function and can be used to extend Spatial FOG Dual with additional peripherals, sensors and data formats. The GPIO pins have digital input, digital output, frequency input and frequency output functionality. Additionally GPIO1 can function as an RS232 serial transmit line and GPIO2 can function as an RS232 serial receive line. The GPIO serial baud rate can be configured anywhere from 2400 to 250 K baud. The auxiliary serial baud

rate can be configured anywhere from 2400 to 2 M baud. Changes to these baud rates can be made by using the Baud Rates dialog box in Spatial FOG Manager (see section 11.8.5) or the Baud Rates Packet (see section 13.10.3).

The available GPIO pin functions and auxiliary RS232 functions are listed below in section 12.4. The function of a GPIO pin or auxiliary RS232 can be changed at any time using the GPIO Configuration dialogue in Spatial FOG Manager (see section 11.8.6) or the GPIO Configuration Packet (see section 13.10.7). The receive and transmit functions of the auxiliary RS232 port can be configured independently with different functionality.

12.3.1 GPIO Pins Voltage Level

GPIO1 and GPIO2 are dual voltage level pins that can function at either 0 to 5 volt levels or RS232 levels. When these pins are used for digital input, digital output, frequency input or frequency output the pins operate at standard 0 to 5 volt levels (-20 to 20 volt tolerant). When the pins are used for serial receive or serial transmit, the pins automatically switch to RS232 voltage levels.

12.3.2 GNSS RS232


The GNSS RS232 is a fixed function RS232 port that is directly connected to the internal Trimble MB-Two GNSS receiver. This allows for configuration and upgrades of the internal GNSS receiver and can also be used for sending differential or RTK corrections.

12.4 Dynamic Pin Functions

Function	Type	GPIOs	Auxiliary RS232
Inactive	Tristate	All	All
1PPS Output	Digital Output	All	Transmit
GNSS Fix Output	Digital Output	All	Transmit
Odometer Input	Frequency Input	All	Receive
Zero Velocity Input	Digital Input	All	Receive
Pitot Tube Input	Frequency Input	All	Receive
NMEA Input	Serial Receive	2	Receive
NMEA Output	Serial Transmit	1	Transmit
Novatel GNSS Input	Serial Receive	2	Receive
Topcon GNSS Input	Serial Receive	2	Receive
ANPP Input	Serial Receive	2	Receive
ANPP Output	Serial Transmit	1	Transmit
Disable GNSS	Digital Input	All	Receive
Disable Pressure	Digital Input	All	Receive
Set Zero Orientation Alignment	Digital Input	All	Receive
System State Packet Trigger	Digital Input	All	Receive

Function	Type	GPIOs	Auxiliary RS232
Raw Sensors Packet Trigger	Digital Input	All	Receive
Pressure Depth Transducer	Frequency Input	All	Receive
RTCM Differential GNSS Corrections Input	Serial Receive	2	Receive
Trimble GNSS Input	Serial Receive	2	Receive
u-blox GNSS Input	Serial Receive	2	Receive
Hemisphere GNSS Input	Serial Receive	2	Receive
Teledyne DVL Input	Serial Receive	2	Receive
Tritech USBL Input	Serial Receive	2	Receive
Linkquest DVL Input	Serial Receive	2	Receive
Linkquest USBL Input	Serial Receive	2	Receive
Nortek DVL Input	Serial Receive	2	Receive
Left Wheel Speed Sensor	Frequency Input	All	Receive
Right Wheel Speed Sensor	Frequency Input	All	Receive
1PPS Input	Digital Input	All	Receive
Wheel Speed Sensor	Frequency Input	All	Receive
Wheel Encoder Phase A	Frequency Input	All	
Wheel Encoder Phase B	Frequency Input	All	
Event 1 Input	Digital Input	All	Receive
Event 2 Input	Digital Input	All	Receive
TSS1 Output	Serial Transmit	1	Transmit
Simrad 1000 Output	Serial Transmit	1	Transmit
Simrad 3000 Output	Serial Transmit	1	Transmit
Serial Port Passthrough	Serial	All	All
GNSS Receiver Passthrough	Serial	All	All
Gimbal Encoder Phase A	Frequency Input	All	
Gimbal Encoder Phase B	Frequency Input	All	
Odometer Direction, Forward Low	Digital Input	All	Receive
Odometer Direction, Forward High	Digital Input	All	Receive
Reverse Alignment, Forward Low	Digital Input	All	Receive
Reverse Alignment, Forward High	Digital Input	All	Receive
Zero Angular Velocity Input	Digital Input	All	Receive

Table 19: GPIO pin functions



12.4.1 1PPS Output

In this function, the pin pulses for 50 milliseconds to signal the precise second. The 1PPS line starts pulsing approximately 100 milliseconds after power up and always fires irrespective of whether Spatial FOG Dual has accurate time or not. It is important to note that when Spatial FOG Dual acquires time corrections from its GNSS receiver, the 1PPS signal may fire at an interval of less than 1 second. This typically only occurs the first time the GNSS receiver obtains a fix after startup. The time initialised status flag can be used to determine whether the time and 1PPS line is accurate or not.

1PPS Source	Voltage Level	Trigger
Auxiliary	-5v to 5v	Falling Edge
GPIO	0 to 5v	Rising Edge

Table 20: 1PPS Specifications

12.4.2 GNSS Fix Output

In this function, the pin is low when there is no GNSS fix or a 2D fix and high when there is a 3D, SBAS, Differential or RTK GNSS fix.

12.4.3 Odometer Input

This function is designed for low resolution vehicle speed sensors and odometers. It expects a normally low input with a high state for the trigger. If the pulse length is more than 0.1 metres this odometer input function should be used, if it is less than 0.1 metres the wheel speed sensor function should be used. Please contact Advanced Navigation support for help integrating with your speed sensor.

Parameter	Value
Trigger	Low → High
Maximum Frequency	600Khz
Maximum Pulse Rate	4294967 pulses/metre

Table 21: Odometer Specifications

12.4.4 Zero Velocity Input

When using this function, a high state indicates to Spatial FOG Dual that it is stationary. The low state indicates that the vehicle is not stationary. Use of this function can significantly improve drift performance when a GNSS signal is not available.

12.4.5 Pitot Tube Input

This function is designed for fixed wing aircraft to enhance navigation through the use of a pitot tube to measure airspeed. It requires a differential pressure sensor that has a frequency output such as the Kavlico P992 (frequency output option) or the Paroscientific series 5300. Please contact Advanced Navigation support for help integrating with a pitot tube.

12.4.6 NMEA Input

This function accepts external data in the NMEA format. Advanced Navigation recommends against using NMEA where possible due to the inefficiency, inaccuracy and poor error checking of the format. All NMEA messages received must have a valid checksum. Supported messages are listed below. The recommended combination of messages are GPGGA, GPVTG and GPZDA with optional messages GPGSV and GPGSA.

Message ID	Description
GPGGA GNGGA	3D position
GPGLL GNGLL	2D position
GPRMC GNRMC	2D position, 2D velocity and coarse time
GPVTG GNVTG	2D velocity
GPHDT GNHDT HEHDT	Heading
GPGSV GNGSV	Satellites
GPGSA GNGSA	Dilution of Position
GPZDA GNZDA	Time

Table 22: Supported NMEA messages


12.4.7 NMEA Output

This function outputs a configurable combination of the NMEA messages GPZDA, GPGGA, GPVTG, GPRMC, GPHDT and PASHR at up to 50 Hz. The messages output and the output rate can be configured using the NMEA output configuration dialogue in Spatial FOG Manager. Advanced Navigation recommends against using NMEA where possible due to the inefficiency, inaccuracy and poor error checking of the format. An example output is shown below.

```
$GPZDA,031644.460,07,05,2013,00,00*52
$GPGGA,031644.460,3352.3501851,S,15112.2355488,E,6,00,1.4,150.0,M,0.0,M,,*7E
$GPVTG,089.19,T,089.19,M,000.00,N,000.00,K,E*27
$GPRMC,031644.460,A,3352.3501851,S,15112.2355488,E,0.0,89.2,070513,12.5,W,E*02
$GPHDT,89.2,T*06
$PASHR,031644.460,089.19,T,-00.01,-00.47,-00.00,,,,0,0*2E
```

12.4.8 Novatel GNSS Input

This function is designed for interfacing Spatial FOG Dual with a Novatel GNSS receiver. It accepts



data in the Novatel binary format and requires messages BESTPOSB and BESTVELB at rates higher than 1 Hz (20Hz recommended). The message BESTSATSB is optional to display detailed satellite information. The message HEADING is also supported for ALIGN capable receivers.

12.4.9 Topcon GNSS Input

This function is designed for interfacing Spatial FOG Dual with a Topcon GNSS receiver. It accepts data in the GRIL TPS binary format and expects messages PG and VG at rates higher than 1 Hz.

12.4.10 ANPP Input

This function accepts data in the ANPP format as specified in section 13.

12.4.11 ANPP Output

This function outputs data in the ANPP format as specified in section 13. For packets to be sent out they must be requested through another GPIO functioning as ANPP input.

12.4.12 Disable GNSS

This function accepts a digital input with a low state enabling the GNSS and a high state disabling the GNSS.

12.4.13 Disable Pressure

This function accepts a digital input with a low state enabling the atmospheric pressure sensor and a high state disabling the atmospheric pressure sensor.

12.4.14 Set Zero Orientation Alignment

This function accepts a digital input. The input is normally low and a transition from low to high causes Spatial FOG Dual to set its alignment so that the current orientation is zero. Due to the risk of exhausting the flash cycles, the change is not permanent and will disappear on reset. To make it permanent the Installation Alignment Packet must be read and then sent back to Spatial FOG Dual with the permanent flag set. This function requires de-bouncing if attached to a switch.

12.4.15 System State Packet Trigger


This function accepts a digital input. The input is normally low and a transition from low to high causes Spatial FOG Dual to send the system state packet. This function requires de-bouncing if attached to a switch.

12.4.16 Raw Sensors Packet Trigger

This function accepts a digital input. The input is normally low and a transition from low to high causes Spatial FOG Dual to send the raw sensors packet. This function requires de-bouncing if attached to a switch.

12.4.17 Pressure Depth Transducer

This function is designed for interfacing with a legacy pressure depth transducer. These are no



longer available and the function is now deprecated.

12.4.18 RTCM Differential GNSS Corrections Input

This function accepts RTCM differential GPS corrections. This allows for Differential GNSS or RTK with Spatial FOG Dual's internal GNSS receiver.

12.4.19 Trimble GNSS Input

This function is designed for interfacing Spatial FOG Dual with an external Trimble GNSS receiver. It accepts data in the Trimble binary format GSOF and expects packet 0x40 with records 1, 2, 8, and 12 at rates higher than 1Hz (20Hz recommended) and optional records 9 and 34 at 1 to 2Hz.

12.4.20 u-blox GNSS Input

This function is designed for interfacing Spatial FOG Dual with a u-blox GNSS receiver. It accepts data in the u-blox binary format and expects message NAV-PVT or NAV-SOL at rates higher than 1Hz.

12.4.21 Hemisphere GNSS Input

This function is designed for interfacing Spatial FOG Dual with a Hemisphere GNSS receiver. It accepts data in the Hemisphere binary format and expects message Bin1 at rates higher than 1Hz. For Hemisphere receivers that provide heading using two antennas, NMEA should be used instead as the binary format does not allow for transmission of heading information.

12.4.22 Teledyne DVL Input

This function accepts DVL data from a Teledyne DVL. For assistance with configuration please contact support@advancednavigation.com.au.

12.4.23 Trittech USBL Input

This function accepts USBL data from a Trittech USBL. For assistance with configuration please contact support@advancednavigation.com.au.

12.4.24 Linkquest DVL Input

This function accepts DVL data from a Linkquest DVL. For assistance with configuration please contact support@advancednavigation.com.au.

12.4.25 Linkquest USBL Input

This function accepts USBL data from a Linkquest USBL. For assistance with configuration please contact support@advancednavigation.com.au.

12.4.26 Nortek DVL Input

This function accepts DVL data in the Nortek DVL binary format. It accepts the packets 0x1B (DVL Bottom Track) and 0x1D (DVL Water Track). The recommended update rate is 8Hz.

12.4.27 Left Wheel Speed Sensor

This function is designed for the left wheel of a vehicle with dual wheel speed sensors.

12.4.28 Right Wheel Speed Sensor

This function is designed for the right wheel of a vehicle with dual wheel speed sensors.

12.4.29 1PPS Input

This function is designed to allow external GNSS receivers to synchronise time with Spatial FOG Dual. It triggers on a transition from low to high.

12.4.30 Wheel Speed Sensor

This function is designed for high resolution vehicle speed sensors and wheel speed sensors. It expects a normally low input with a high state for the trigger. If the pulse length is more than 0.1 metres the odometer input function should be used, if it is less than 0.1 metres this wheel speed sensor function should be used. Please contact Advanced Navigation support for help integrating with your speed sensor.

Parameter	Value
Trigger	Low → High
Maximum Frequency	40 MHz
Maximum Pulse Rate	4,294,967,295 pulses/metre

Table 23: Wheel Speed Sensor Specifications

12.4.31 Wheel Encoder Phase A

This function is designed for interfacing with a rotary incremental quadrature encoder that is measuring the wheel speed of a ground vehicle such as a car. It should be used in combination with Wheel Encoder Phase B.

12.4.32 Wheel Encoder Phase B


This function is designed for interfacing with a rotary incremental quadrature encoder that is measuring the wheel speed of a ground vehicle such as a car. It should be used in combination with Wheel Encoder Phase A.

12.4.33 Event 1 Input

This function is designed to allow external events to be recorded inside Spatial FOG Dual's output. The event is recorded in the filter status, see section 13.9.1.2, and resets after the next packet is output. The event triggers on a transition from low to high.

12.4.34 Event 2 Input

This function is designed to allow external events to be recorded inside Spatial FOG Dual's output. The event is recorded in the filter status, see section 13.9.1.2, and resets after the next packet is output. The event triggers on a transition from low to high.



12.4.35 TSS1 Output

This function outputs the TSS1 format at a user configurable rate up to 50 Hz. The output rate can be configured using the GPIO output configuration dialogue in Spatial FOG Manager, see section 11.8.10.

12.4.36 Simrad 1000 Output

This function outputs the Simrad 1000 format at a user configurable rate up to 50 Hz. The output rate can be configured using the GPIO output configuration dialogue in Spatial FOG Manager, see section 11.8.10.

12.4.37 Simrad 3000 Output

This function outputs the Simrad 3000 format at a user configurable rate up to 50 Hz. The output rate can be configured using the GPIO output configuration dialogue in Spatial FOG Manager, see section 11.8.10.

12.4.38 Serial Port Passthrough

This function allows passthrough communication through either GPIO 1 and 2 or the Auxiliary RS232. To transmit data use the Serial Port Pass-through Packet. When data is received it will be sent back using the same Serial Port Pass-through Packet.

12.4.39 GNSS Receiver Passthrough

This function allows for pass through connection to the internal GNSS receiver. This is useful for firmware updates of the internal GNSS receiver.

12.4.40 Gimbal Encoder Phase A

This function is designed for interfacing with a rotary incremental quadrature encoder to measure the azimuth angle of a gimbal that Spatial FOG Dual is installed in. It should be used in combination with Gimbal Encoder Phase B.

12.4.41 Gimbal Encoder Phase B

This function is designed for interfacing with a rotary incremental quadrature encoder to measure the azimuth angle of a gimbal that Spatial FOG Dual is installed in. It should be used in combination with Gimbal Encoder Phase A.

12.4.42 Odometer Direction, Forward Low

This function is designed to take a reversing indication input for direction with an odometer or wheel encoder. It should be used in combination with Odometer Input or Wheel Speed Sensor.

12.4.43 Odometer Direction, Forward High

This function is designed to take a reversing indication input for direction with an odometer or wheel encoder. It should be used in combination with Odometer Input or Wheel Speed Sensor.



12.4.44 Reverse Alignment, Forward Low

This function is designed to reverse the alignment settings for vehicles that can have two vehicle forward directions, such as locomotives.

12.4.45 Reverse Alignment, Forward High

This function is designed to reverse the alignment settings for vehicles that can have two vehicle forward directions, such as locomotives.

12.4.46 Zero Angular Velocity Input

In this function, a high state indicates to Spatial FOG Dual that the vehicle is not rotating. The low state indicates that the vehicle could be rotating. Use of this function can significantly improve heading drift performance when a GNSS signal is not available.

13 Advanced Navigation Packet Protocol

The Advanced Navigation Packet Protocol (ANPP) is a binary protocol designed with high error checking, high efficiency and safe design practices. It has a well defined specification and is very flexible. It is used across all existing and future Advanced Navigation products.

13.1 Data Types

The following data types are used in the packet protocol. All data types in the protocol are little endian byte ordering.

Abbreviation	Bytes	Also known as
u8	1	unsigned char, unsigned byte, uint8_t
s8	1	char, byte, int8_t
u16	2	unsigned short, uint16_t
s16	2	short, int16_t
u32	4	unsigned int, unsigned long, uint32_t
s32	4	int, long, int32_t
u64	8	unsigned long long, uint64_t
s64	8	long long, int64_t
fp32	4	float
fp64	8	double


Table 24: Data type abbreviations used in the ANPP

13.2 Packet Structure

The ANPP packet structure is shown in Table 25 and the header format is shown in Table 26. Example code can be downloaded from the software section.

Header				
Header LRC	Packet ID	Packet Length	CRC16	Packet Data

Table 25: ANPP Packet Structure



ANPP Header Format				
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Header LRC, see section 13.2.1
2	1	u8	1	Packet ID, see section 13.2.2
3	2	u8	1	Packet Length, see section 13.2.3
4	3	u16	2	CRC16, see section 13.2.4

Table 26: ANPP header format

13.2.1 Header LRC

The header LRC (Longitudinal Redundancy Check) provides error checking on the packet header. It also allows the decoder to find the start of a packet by scanning for a valid LRC. The LRC can be found using the following:

$$\text{LRC} = ((\text{packet_id} + \text{packet_length} + \text{crc}[0] + \text{crc}[1]) \wedge 0xFF) + 1$$

13.2.2 Packet ID

The packet ID is used to distinguish the contents of the packet. Packet IDs range from 0 to 255.

Within this range there are three different sub-ranges, these are system packets, state packets and configuration packets.

System packets have packet IDs in the range 0 to 19. These packets are implemented the same by every device using ANPP.

State packets are packets that contain data that changes with time, i.e. temperature. State packets can be set to output at a certain rate. State packets are packet IDs in the range 20 to 179.

Configuration packets are used for reading and writing device configuration. Configuration packets are packet IDs in the range 180 to 255.

13.2.3 Packet Length

The packet length denotes the length of the packet data, i.e. from byte index 5 onwards inclusive. Packet length has a range of 0 – 255.

13.2.4 CRC

The CRC is a CRC16-CCITT. The starting value is 0xFFFF. The CRC covers only the packet data.

13.3 Packet Requests

Any packet can be requested at any time using the request packet. See section 13.8.2.

13.4 Packet Acknowledgement

When configuration packets are sent to Spatial FOG Dual, it will reply with an acknowledgement

packet that indicates whether the configuration change was successful or not. For details on the acknowledgement packet, see section 13.8.1.

External data packets will also generate negative acknowledgement packets if there is a problem with the packet. Positive acknowledgements will not be sent.

13.5 Packet Rates

The packet rates can be configured either using Spatial Manager or through the Packets Period Packet. By default Spatial FOG Dual is configured to output the System State Packet at 50Hz. When configuring packet rates it is essential to ensure the baud rate is capable of handling the data throughput. This can be calculated using the rate and packet size. The packet size is the packet length add five to account for the packet overhead. For example to output the system state packet at 50Hz the calculation would be:

Data throughput = (100 (packet length) + 5 (fixed packet overhead)) * 50 (rate)

Data throughput = 5250 bytes per second

Minimum baud rate = data throughput x 11 = 57750 Baud

Closest standard baud rate = 115200 Baud


When multiple packets are set to output at the same rate, the order the packets output is from lowest ID to highest ID.

13.6 Packet Timing


Packets are output in order of packet ID from lowest ID to highest ID and all packets that are output in one sequence have their data matched to the same time of validity. The time of validity can be found in either the System State Packet, the Unix Time Packet or the Formatted Time Packet. For example if the Unix Time Packet, Status Packet and NED Velocity Packet packet were all set to output at 10 Hz, at each 0.1 second period the three packets would output consecutively by order of packet ID with all data synchronised between them and the Unix Time Packet providing the time of validity for the other two packets.

13.7 Packet Summary

Packet ID	Length	R/W	Name
System Packets			
0	4	R	Acknowledge Packet
1	-	W	Request Packet
2	1	R/W	Boot Mode Packet
3	24	R	Device Information Packet
4	4	W	Restore Factory Settings Packet
5	4	W	Reset Packet
10	-	R/W	Serial Port Pass-through Packet
State Packets			



Packet ID	Length	R/W	Name
20	100	R	System State Packet
21	8	R	Unix Time Packet
22	14	R	Formatted Time Packet
23	4	R	Status Packet
24	12	R	Position Standard Deviation Packet
25	12	R	Velocity Standard Deviation Packet
26	12	R	Euler Orientation Standard Deviation Packet
27	16	R	Quaternion Orientation Standard Deviation Packet
28	48	R	Raw Sensors Packet
29	74	R	Raw GNSS Packet
30	13	R	Satellites Packet
31	-	R	Detailed Satellites Packet
32	24	R	Geodetic Position Packet
33	24	R	ECEF Position Packet
34	25	R	UTM Position Packet
35	12	R	NED Velocity Packet
36	12	R	Body Velocity Packet
37	12	R	Acceleration Packet
38	16	R	Body Acceleration Packet
39	12	R	Euler Orientation Packet
40	16	R	Quaternion Orientation Packet
41	36	R	DCM Orientation Packet
42	12	R	Angular Velocity Packet
43	12	R	Angular Acceleration Packet
44	60	R/W	External Position & Velocity Packet
45	36	R/W	External Position Packet
46	24	R/W	External Velocity Packet
47	16 or 24	R/W	External Body Velocity Packet
48	8	R/W	External Heading Packet
49	8	R	Running Time Packet
50	12	R	Local Magnetic Field Packet
51	20	R	Odometer State Packet
52	8	R/W	External Time Packet
53	8	R/W	External Depth Packet



Packet ID	Length	R/W	Name
54	4	R	Geoid Height Packet
55	-	W	RTCM Corrections Packet
56	8	-	External Pitot Pressure Packet
57	12	R/W	Wind Packet
58	16	R	Heave Packet
59	-	R	Post Processing Packet
60	-	R	Raw Satellite Data Packet
61	-	R	Raw Satellite Ephemeris Packet
67	13	R/W	External Odometer Packet
68	25	R/W	External Air Data Packet
69	48	R/W	GNSS Receiver Information Packet
71	28	R	North Seeking Initialisation Status Packet
72	8	R/W	Gimbal State Packet
73	24	R	Automotive Packet
Configuration Packets			
180	4	R/W	Packet Timer Period Packet
181	-	R/W	Packets Period Packet
182	17	R/W	Baud Rates Packet
185	73	R/W	Installation Alignment Packet
186	17	R/W	Filter Options Packet
187	-	R/W	Advanced Filter Parameters Packet
188	13	R/W	GPIO Configuration Packet
192	8	R/W	Odometer Configuration Packet
193	5	W	Set Zero Orientation Alignment Packet
194	49	R/W	Reference Point Offsets Packet
195	33	R/W	GPIO Output Configuration Packet
196	17	R/W	Dual Antenna Configuration Packet
198	64	R/W	User Data Packet
199	65	R/W	GPIO Input Configuration Packet

Table 27: Packet summary

13.8 System Packets

13.8.1 Acknowledge Packet

Acknowledgement Packet				
Packet ID			0	
Length			4	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Packet ID being acknowledged
2	1	u16	2	CRC of packet being acknowledged
3	3	u8	1	Acknowledge Result, see section 13.8.1.1

Table 28: Acknowledge packet

13.8.1.1 Acknowledge Result


Value	Description
0	Acknowledge success
1	Acknowledge failure, CRC error
2	Acknowledge failure, packet size incorrect
3	Acknowledge failure, values outside of valid ranges
4	Acknowledge failure, system flash memory failure
5	Acknowledge failure, system not ready
6	Acknowledge failure, unknown packet

Table 29: Acknowledge result

13.8.2 Request Packet

Request Packet				
Packet ID			1	
Length			1 x number of packets requested	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Packet ID requested
+				Field 1 repeats for additional packet requests

Table 30: Request packet



13.8.3 Boot Mode Packet

Boot Mode Packet				
Packet ID			2	
Length			1	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Boot mode, see section 13.8.3.1

Table 31: Boot mode packet

13.8.3.1 Boot Mode Types

Value	Description
0	Bootloader
1	Main Program

Table 32: Boot mode types

13.8.4 Device Information Packet

Device Information Packet				
Packet ID			3	
Length			24	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Software version
2	4	u32	4	Device ID, see section 13.8.4.1
3	8	u32	4	Hardware revision
4	12	u32	4	Serial number part 1
5	16	u32	4	Serial number part 2
6	20	u32	4	Serial number part 3

Table 33: Device information packet

13.8.4.1 Device ID

Bit	Description
1	Spatial
4	Spatial FOG
5	Spatial Dual
11	Orientus >v3
13	Air Data Unit
14	Subsonus
16	Spatial FOG Dual
17	Motus
19	GNSS Compass
21	Subsonus Tag
22	Poseidon
26	Certus
27	Aries
28	Boreas D90

Table 34: Device ID

13.8.5 Restore Factory Settings Packet

Restore Factory Settings Packet				
Packet ID			4	
Length			4	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Verification Sequence (set to 0x85429E1C)

Table 35: Restore factory settings packet

13.8.6 Reset Packet

Reset Packet				
Packet ID			5	
Length			4	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Verification sequence, see section 13.8.6.1

Table 36: Reset packet

13.8.6.1 Verification Sequence Values

Value	Description
0x21057A7E	Standard hot start reset
0x9A5D38B7	Cold start reset

Table 37: Verification sequence values

13.8.7 Serial Port Pass-through Packet

Serial Port Pass-through Packet				
Packet ID			10	
Length			Variable, up to 255 bytes	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Pass-through route, see section 13.8.7.1
2	1			Pass-through data

Table 38: Serial port pass-through packet

13.8.7.1 Pass-through Routes

Value	Description
1	GPIO 1 and 2
2	Auxiliary RS232

Table 39: Pass-through routes

13.9 State Packets

Spatial FOG Dual supports a large number of packets providing extensive functionality. However for the majority of users the easiest approach is to configure Spatial FOG Dual using the Spatial Manager software and then support only the single system state packet shown below in section 13.9.1. Advanced functionality can be added as required through the other packets.

13.9.1 System State Packet

System State Packet				
Packet ID				20
Length				100
Field #	Bytes Offset	Data Type	Size	Description
1	0	u16	2	System status, see section 13.9.1.1
2	2	u16	2	Filter status, see section 13.9.1.2
3	4	u32	4	Unix time seconds, see section 13.9.1.4
4	8	u32	4	Microseconds, see section 13.9.1.5
5	12	fp64	8	Latitude (rad)
6	20	fp64	8	Longitude (rad)
7	28	fp64	8	Height (m)
8	36	fp32	4	Velocity north (m/s)
9	40	fp32	4	Velocity east (m/s)
10	44	fp32	4	Velocity down (m/s)
11	48	fp32	4	Body acceleration X (m/s/s)
12	52	fp32	4	Body acceleration Y (m/s/s)
13	56	fp32	4	Body acceleration Z (m/s/s)
14	60	fp32	4	G force (g)
15	64	fp32	4	Roll (radians)
16	68	fp32	4	Pitch (radians)
17	72	fp32	4	Heading (radians)
18	76	fp32	4	Angular velocity X (rad/s)
19	80	fp32	4	Angular velocity Y (rad/s)
20	84	fp32	4	Angular velocity Z (rad/s)
21	88	fp32	4	Latitude standard deviation (m)
22	92	fp32	4	Longitude standard deviation (m)
23	96	fp32	4	Height standard deviation (m)

Table 40: System state packet

13.9.1.1 System Status

This field contains 16 bits that indicate problems with the system. These are boolean fields with a zero indicating false and one indicating true.

Bit	Description
0	System Failure
1	Accelerometer Sensor Failure
2	Gyroscope Sensor Failure
3	Magnetometer Sensor Failure
4	Pressure Sensor Failure
5	GNSS Failure
6	Accelerometer Over Range
7	Gyroscope Over Range
8	Magnetometer Over Range
9	Pressure Over Range
10	Minimum Temperature Alarm
11	Maximum Temperature Alarm
12	Low Voltage Alarm
13	High Voltage Alarm
14	GNSS Antenna Disconnected or Short Circuit
15	Data Output Overflow Alarm

Table 41: System status

13.9.1.2 Filter Status

This field contains 16 bits that indicate the status of the filters. These are boolean fields with a zero indicating false and one indicating true.

Bit	Description
0	Orientation Filter Initialised
1	Navigation Filter Initialised
2	Heading Initialised
3	UTC Time Initialised
4	GNSS Fix Status, see section 13.9.1.3
5	
6	
7	Event 1 Occurred
8	Event 2 Occurred
9	Internal GNSS Enabled
10	Dual Antenna Heading Active
11	Velocity Heading Enabled
12	Atmospheric Altitude Enabled
13	External Position Active
14	External Velocity Active
15	External Heading Active

Table 42: Filter status


13.9.1.3 GNSS Fix Status

Value	Bit 6	Bit 5	Bit 4	Description
0	0	0	0	No GNSS fix
1	0	0	1	2D GNSS fix
2	0	1	0	3D GNSS fix
3	0	1	1	SBAS GNSS fix
4	1	0	0	Differential GNSS fix
5	1	0	1	Omnistar/Starfire GNSS fix
6	1	1	0	RTK Float GNSS fix
7	1	1	1	RTK Fixed GNSS fix

Table 43: GNSS fix status

13.9.1.4 Unix Time Seconds

This field provides UTC time in seconds since January 1, 1970 including leap seconds.



13.9.1.5 Microseconds

This field provides the sub-second component of time. It is represented as microseconds since the last second. Minimum value is 0 and maximum value is 999999.

13.9.2 Unix Time Packet

Unix Time Packet				
Packet ID				21
Length				8
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Unix time seconds, see section 13.9.1.4
2	4	u32	4	Microseconds, see section 13.9.1.5

Table 44: Unix time packet

13.9.3 Formatted Time Packet

Formatted Time Packet				
Packet ID				22
Length				14
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Microseconds
2	4	u16	2	Year
3	6	u16	2	Year day, 0 - 365
4	8	u8	1	Month, 0 - 11
5	9	u8	1	Month Day, 1 - 31
6	10	u8	1	Week Day, 0 - 6
7	11	u8	1	Hour, 0 - 23
8	12	u8	1	Minute, 0 - 59
9	13	u8	1	Second, 0 - 59

Table 45: Formatted time packet

13.9.4 Status Packet

Status Packet				
Packet ID			23	
Length			4	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u16	2	System status, see section 13.9.1.1
2	2	u16	2	Filter status, see section 13.9.1.2

Table 46: Status packet

13.9.5 Position Standard Deviation Packet

Position Standard Deviation Packet				
Packet ID			24	
Length			12	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Latitude standard deviation (m)
2	4	fp32	4	Longitude standard deviation (m)
3	8	fp32	4	Height standard deviation (m)

Table 47: Position standard deviation packet

13.9.6 Velocity Standard Deviation Packet

Velocity Standard Deviation Packet				
Packet ID			25	
Length			12	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Velocity north standard deviation (m/s)
2	4	fp32	4	Velocity east standard deviation (m/s)
3	8	fp32	4	Velocity down standard deviation (m/s)

Table 48: Velocity standard deviation packet

13.9.7 Euler Orientation Standard Deviation Packet

Euler Orientation Standard Deviation Packet				
Packet ID			26	
Length			12	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Roll standard deviation (rad)
2	4	fp32	4	Pitch standard deviation(rad)
3	8	fp32	4	Heading standard deviation(rad)

Table 49: Euler orientation standard deviation packet

13.9.8 Quaternion Orientation Standard Deviation Packet

Quaternion Orientation Standard Deviation Packet				
Packet ID			27	
Length			16	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	QS standard deviation
2	4	fp32	4	QX standard deviation
3	8	fp32	4	QY standard deviation
4	12	fp32	4	QZ standard deviation

Table 50: Quaternion orientation standard deviation packet

13.9.9 Raw Sensors Packet


Raw Sensors Packet				
Packet ID			28	
Length			48	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Accelerometer X (m/s/s)
2	4	fp32	4	Accelerometer Y (m/s/s)
3	8	fp32	4	Accelerometer Z (m/s/s)
4	12	fp32	4	Gyroscope X (rad/s)
5	16	fp32	4	Gyroscope Y (rad/s)
6	20	fp32	4	Gyroscope Z (rad/s)
7	24	fp32	4	Magnetometer X (mG)
8	28	fp32	4	Magnetometer Y (mG)
9	32	fp32	4	Magnetometer Z (mG)
10	36	fp32	4	IMU Temperature (deg C)
11	40	fp32	4	Pressure (Pascals)
12	44	fp32	4	Pressure Temperature (deg C)

Table 51: Raw sensors packet

13.9.10 Raw GNSS Packet

This packet represents the raw data as it is received from the GNSS receiver. The position is not corrected for antenna position offset and the velocity is not compensated for the antenna lever arm offset. The INS position and velocity that are in the other packets are corrected for antenna position offset and lever arm.

Please note that the tilt and heading fields will only be valid when operating with the optional dual antenna upgrade kit or the add on SAASM GPS heading unit.




Raw GNSS Packet				
Packet ID			29	
Length			74	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Unix time stamp (seconds)
2	4	u32	4	Microseconds
3	8	fp64	8	Latitude (rad)
4	16	fp64	8	Longitude (rad)
5	24	fp64	8	Height (m)
6	32	fp32	4	Velocity north (m/s)
7	36	fp32	4	Velocity east (m/s)
8	40	fp32	4	Velocity down (m/s)
9	44	fp32	4	Latitude standard deviation (m)
10	48	fp32	4	Longitude standard deviation (m)
11	52	fp32	4	Height standard deviation (m)
12	56	fp32	4	Tilt (rad)
13	60	fp32	4	Heading (rad)
14	64	fp32	4	Tilt standard deviation (rad)
15	68	fp32	4	Heading standard deviation (rad)
16	72	u16	2	Status, see section 13.9.10.1

Table 52: Raw GNSS packet

13.9.10.1 Raw GNSS Status

Bit	Description
0	GNSS Fix Status, see section 13.9.1.3
1	
2	
3	Doppler velocity valid
4	Time valid
5	External GNSS
6	Tilt valid
7	Heading valid
8	Floating ambiguity heading
9-15	Reserved (set to zero)

Table 53: Raw GNSS status

**13.9.11 Satellites Packet**

Satellites Packet				
Packet ID				30
Length				13
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	HDOP
2	4	fp32	4	VDOP
3	8	u8	1	GPS satellites
4	9	u8	1	GLONASS satellites
5	10	u8	1	BeiDou satellites
6	11	u8	1	GALILEO satellites
7	12	u8	1	SBAS satellites

Table 54: Satellites packet

13.9.12 Detailed Satellites Packet

Detailed Satellites Packet				
Packet ID				31
Length				7 x number of satellites
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Satellite system, see section 13.9.12.1
2	1	u8	1	Satellite number (PRN)
3	2	s8	1	Satellite frequencies, see section 13.9.12.2
4	3	u8	1	Elevation (deg)
5	4	u16	2	Azimuth (deg)
6	6	u8	1	SNR
+				Fields 1-6 repeat for additional satellites

Table 55: Detailed satellites packet

13.9.12.1 Satellite Systems

Value	System
0	Unknown
1	GPS
2	GLONASS
3	BeiDou
4	GALILEO
5	SBAS
6	QZSS
7	Starfire
8	Omnistar

Table 56: Satellite systems

13.9.12.2 Satellite Frequencies

Bit	Description
0	L1 C/A
1	L1 C
2	L1 P
3	L1 M
4	L2 C
5	L2 P
6	L2 M
7	L5

Table 57: Satellite frequencies

13.9.13 Geodetic Position Packet

Geodetic Position Packet				
Packet ID			32	
Length			24	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp64	8	Latitude (rad)
2	8	fp64	8	Longitude (rad)
3	16	fp64	8	Height (m)

Table 58: Geodetic position packet

13.9.14 ECEF Position Packet

ECEF Position Packet				
Packet ID			33	
Length			24	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp64	8	ECEF X (m)
2	8	fp64	8	ECEF Y (m)
3	16	fp64	8	ECEF Z (m)

Table 59: ECEF position packet

13.9.15 UTM Position Packet


UTM Position Packet				
Packet ID			34	
Length			26	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp64	8	Northing (m)
2	8	fp64	8	Easting (m)
3	16	fp64	8	Height (m)
4	24	u8	1	Zone number
5	25	s8	1	Zone character

Table 60: UTM position packet

13.9.16 NED Velocity Packet

NED Velocity Packet				
Packet ID			35	
Length			12	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Velocity north (m/s)
2	4	fp32	4	Velocity east (m/s)
3	8	fp32	4	Velocity down (m/s)

Table 61: NED velocity packet

**13.9.17 Body Velocity Packet**

Body Velocity Packet				
Packet ID		36		
Length		12		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Velocity X (m/s)
2	4	fp32	4	Velocity Y (m/s)
3	8	fp32	4	Velocity Z (m/s)

Table 62: Body velocity packet

13.9.18 Acceleration Packet

This packet includes the acceleration due to gravity.

Acceleration Packet				
Packet ID		37		
Length		12		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Acceleration X (m/s/s)
2	4	fp32	4	Acceleration Y (m/s/s)
3	8	fp32	4	Acceleration Z (m/s/s)


Table 63: Acceleration packet

13.9.19 Body Acceleration Packet

This packet does not include the acceleration due to gravity.

Body Acceleration Packet				
Packet ID		38		
Length		16		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Body acceleration X (m/s/s)
2	4	fp32	4	Body acceleration Y (m/s/s)
3	8	fp32	4	Body acceleration Z (m/s/s)
4	12	fp32	4	G force (g)

Table 64: Body acceleration packet



13.9.20 Euler Orientation Packet

Euler Orientation Packet				
Packet ID			39	
Length			12	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Roll (rad)
2	4	fp32	4	Pitch (rad)
3	8	fp32	4	Heading (rad)

Table 65: Euler orientation packet

13.9.21 Quaternion Orientation Packet

Quaternion Orientation Packet				
Packet ID			40	
Length			16	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	QS
2	4	fp32	4	QX
3	8	fp32	4	QY
4	12	fp32	4	QZ

Table 66: Quaternion orientation packet

13.9.22 DCM Orientation Packet

DCM Orientation Packet				
Packet ID			41	
Length			36	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	DCM[0][0]
2	4	fp32	4	DCM[0][1]
3	8	fp32	4	DCM[0][2]
4	12	fp32	4	DCM[1][0]
5	16	fp32	4	DCM[1][1]
6	20	fp32	4	DCM[1][2]
7	24	fp32	4	DCM[2][0]

8	28	fp32	4	DCM[2][1]
9	32	fp32	4	DCM[2][2]

Table 67: DCM orientation packet

13.9.23 Angular Velocity Packet

Angular Velocity Packet				
Packet ID		42		
Length		12		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Angular velocity X (rad/s)
2	4	fp32	4	Angular velocity Y (rad/s)
3	8	fp32	4	Angular velocity Z (rad/s)

Table 68: Angular velocity packet


13.9.24 Angular Acceleration Packet

Angular Acceleration Packet				
Packet ID		43		
Length		12		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Angular acceleration X (rad/s/s)
2	4	fp32	4	Angular acceleration Y (rad/s/s)
3	8	fp32	4	Angular acceleration Z (rad/s/s)

Table 69: Angular acceleration packet

13.9.25 External Position & Velocity Packet

External Position & Velocity Packet				
Packet ID		44		
Length		60		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp64	8	Latitude (rad)
2	8	fp64	8	Longitude (rad)
3	16	fp64	8	Height (m)
4	24	fp32	4	Velocity north (m/s)



5	28	fp32	4	Velocity east (m/s)
6	32	fp32	4	Velocity down (m/s)
7	36	fp32	4	Latitude standard deviation (m)
8	40	fp32	4	Longitude standard deviation (m)
9	44	fp32	4	Height standard deviation (m)
10	48	fp32	4	Velocity north standard deviation (m/s)
11	52	fp32	4	Velocity east standard deviation (m/s)
12	56	fp32	4	Velocity down standard deviation (m/s)

Table 70: External position & velocity packet

13.9.26 External Position Packet

External Position Packet				
Packet ID				45
Length				36
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp64	8	Latitude (rad)
2	8	fp64	8	Longitude (rad)
3	16	fp64	8	Height (m)
4	24	fp32	4	Latitude standard deviation (m)
5	28	fp32	4	Longitude standard deviation (m)
6	32	fp32	4	Height standard deviation (m)

Table 71: External position packet

13.9.27 External Velocity Packet

External Velocity Packet				
Packet ID			46	
Length			24	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Velocity north (m/s)
2	4	fp32	4	Velocity east (m/s)
3	8	fp32	4	Velocity down (m/s)
4	12	fp32	4	Velocity north standard deviation (m/s)
5	16	fp32	4	Velocity east standard deviation (m/s)
6	20	fp32	4	Velocity down standard deviation (m/s)

Table 72: External velocity packet

13.9.28 External Body Velocity Packet


This packet has been defined to support a single velocity standard deviation for all three axes, or, different values for all three axes. Please ensure you modify the packet length in the packet header accordingly, depending on which format you are using.

External Body Velocity Packet				
Packet ID			47	
Length			16 or 24	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Velocity X (m/s)
2	4	fp32	4	Velocity Y (m/s)
3	8	fp32	4	Velocity Z (m/s)
4	12	fp32	4	Velocity X standard deviation (m/s)
5	12	fp32	4	OPTIONAL: Velocity standard deviation Y (m/s)
6	12	fp32	4	OPTIONAL: Velocity standard deviation Z (m/s)

Table 73: External body velocity packet

13.9.29 External Heading Packet

External Heading Packet				
Packet ID			48	
Length			8	
Field #	Bytes	Data	Size	Description



	Offset	Type		
1	0	fp32	4	Heading (rad)
2	4	fp32	4	Heading standard deviation (rad)

Table 74: External heading packet

13.9.30 Running Time Packet

Running Time Packet				
Packet ID			49	
Length			8	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Running time (seconds)
2	4	u32	4	Microseconds

Table 75: Running time packet

13.9.31 Local Magnetic Field Packet

Local Magnetic Field Packet				
Packet ID			50	
Length			12	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Local magnetic field X (mG)
2	4	fp32	4	Local magnetic field Y (mG)
3	8	fp32	4	Local magnetic field Z (mG)

Table 76: Local magnetic field packet

13.9.32 Odometer State Packet

Odometer State Packet				
Packet ID			51	
Length			20	
Field #	Bytes Offset	Data Type	Size	Description
1	0	s32	4	Odometer pulse count
2	4	fp32	4	Odometer distance (m)
3	8	fp32	4	Odometer speed (m/s)
4	12	fp32	4	Odometer scaling error

5	16	u8	1	Odometer active
6	17		3	Reserved

Table 77: Odometer state packet

13.9.33 External Time Packet

External Time Packet				
Packet ID			52	
Length			8	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Unix time (seconds), see section 13.9.1.4
2	4	u32	4	Microseconds, see section 13.9.1.5

Table 78: External time packet

13.9.34 External Depth Packet

External Depth Packet				
Packet ID			53	
Length			8	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Depth (m)
2	4	fp32	4	Depth standard deviation (m)

Table 79: External depth packet


13.9.35 Geoid Height Packet

This packet provides the offset at the current location between the WGS84 ellipsoid and the EGM96 geoid model. This can be used to determine the current height above mean sea level and also depth through the following equations:

Height Above Mean Sea Level = WGS84 Height – Geoid Height

Depth = Geoid Height – WGS84 Height

WGS84 Height is the height at the current location in the System State packet.



Geoid Height Packet				
Packet ID		54		
Length		4		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Geoid Height (m)

Table 80: Geoid height packet

13.9.36 RTCM Corrections Packet

This packet is used to encapsulate RTCM differential or RTK correction data to be sent to Spatial FOG Dual's internal GNSS receiver for differential or RTK GNSS functionality.

RTCM Corrections Packet				
Packet ID		55		
Length		Variable, up to 255 bytes		
Field #	Bytes Offset	Data Type	Size	Description
1	0			RTCM corrections data

Table 81: RTCM corrections packet

13.9.37 External Pitot Pressure Packet

This packet is no longer supported. The External Air Data packet #68 should be used.

13.9.38 Wind Packet

This packet provides Spatial FOG Dual's current 2D wind velocity. These values are only valid when external air data is provided to Spatial FOG Dual. This can be either through the External Pitot Pressure Packet, the External Air Data Packet or when a pitot tube is interfaced to one of the GPIO pins. When this packet is written to the device, it disables the wind estimation filter and the wind values provided are used statically.

Wind Packet				
Packet ID		57		
Length		12		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Wind velocity north (m/s)
2	4	fp32	4	Wind velocity east (m/s)
3	8	fp32	4	Wind velocity standard deviation (m/s)

Table 82: Wind packet




13.9.39 Heave Packet

Heave Packet				
Packet ID			58	
Length			16	
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Heave point 1 (m)
2	4	fp32	4	Heave point 2 (m)
3	8	fp32	4	Heave point 3 (m)
4	12	fp32	4	Heave point 4 (m)

Table 83: Heave packet

13.9.40 Post Processing Packet

No longer supported. If you need an IMR file please contact Advanced Navigation support for required settings.



13.9.41 Raw Satellite Data Packet

Spatial Manager will automatically convert this packet to RINEX 3.02 format.

Raw Satellite Data Packet				
Packet ID			60	
Length			16 + Satellites * (6 + Frequencies * 26)	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u32	4	Unix time (seconds)
2	4	u32	4	Nanoseconds
3	8	s32	4	Receiver clock offset (nanoseconds)
2	12	u8	1	Receiver number
3	13	u8	1	Packet number
4	14	u8	1	Total packets
5	15	u8	1	Number of satellites
For each satellite				
7	16	u8	1	Satellite system, see section 13.9.12.1
8	17	u8	1	PRN or satellite number
9	18	u8	1	Elevation (degrees)
10	19	u16	2	Azimuth (degrees)
11	21	u8	1	Number of frequencies
For each frequency of each satellite				
12	22	u8	1	Satellite frequency, see section 13.9.41.1
13	23	u8	1	Tracking status, see 13.9.41.2
13	24	fp64	8	Carrier phase
14	32	fp64	8	Pseudo range (m)
15	40	fp32	4	Doppler frequency (Hz)
16	44	fp32	4	Signal to noise ratio (dB-Hz)

Table 84: Raw satellite data packet

13.9.41.1 Satellite Frequencies

Value	Frequency
0	Unknown
1	L1 C/A
2	L1 C
3	L1 P
4	L1 M
5	L2 C
6	L2 P
7	L2 M
8	L5

Table 85: Satellite frequencies

13.9.41.2 Tracking Status

Bit	Description
0	Carrier phase valid
1	Carrier phase cycle slip detected
2	Carrier phase half-cycle ambiguity
3	Pseudo range valid
4	Doppler valid
5	SNR valid
6	Reserved
7	Reserved


Table 86: Tracking status

13.9.42 Raw Satellite Ephemeris Packet

Spatial Manager will automatically convert this packet to RINEX 3.02 format. This packet has been left out of the reference manual due to it's length. If you need the format of this packet, please contact Advanced Navigation support.

13.9.43 External Odometer Packet

External Odometer Packet				
Packet ID			67	
Length			13	
Field #	Bytes Offset	Data Type	Size	Description



1	0	fp32	4	Estimated delay (s)
2	4	fp32	4	Speed (m/s)
3	8	fp32	4	Reserved (set to zero)
3	12	u8	1	Odometer flags, see section 13.9.43.1

Table 87: External odometer packet

13.9.43.1 Odometer flags

Bit	Description
0	Reversing detection supported
1-7	Reserved (set to zero)

Table 88: Odometer flags

13.9.44 External Air Data Packet

External Air Data Packet				
Packet ID				68
Length				25
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Barometric altitude delay (s)
2	4	fp32	4	Airspeed delay (s)
2	8	fp32	4	Barometric altitude (m)
3	12	fp32	4	Airspeed (m/s)
4	16	fp32	4	Barometric altitude standard deviation (m)
5	20	fp32	4	Airspeed standard deviation (m/s)
6	24	u8	1	Flags, see section 13.9.44.1

Table 89: External air data packet

13.9.44.1 External Air Data Flags

Bit	Description
0	Barometric altitude set and valid
1	Airspeed set and valid
2	Barometric altitude reference reset

Table 90: External air data flags

13.9.44.2 Notes

Barometric altitude does not need to be referenced to any co-ordinate frame or QNH. If the

barometric altitude reference is changed during operation, the barometric altitude reference reset flag should be set for the next packet.

13.9.45 GNSS Receiver Information Packet

GNSS Receiver Information Packet				
Packet ID			69	
Length			48	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	GNSS manufacturer ID, see section 13.9.45.1
2	1	u8	1	GNSS receiver model, see section 13.9.45.2
3	2	s8[10]	10	GNSS serial number in ASCII character string
4	12	u32	4	Firmware version
5	16	u32[3]	12	Software license code
10	28		20	Reserved (set to zero)

Table 91: GNSS receiver information packet

13.9.45.1 GNSS Manufacturer IDs

For Spatial FOG Dual the GNSS Manufacturer ID will always be 1 (Trimble).

Value	Description
0	GNSS Manufacturer Unknown
1	Trimble

Table 92: GNSS manufacturer IDs

13.9.45.2 GNSS Receiver Models


For Spatial FOG Dual the GNSS receiver model will always be 4.

Value	Description
0	GNSS Receiver Model Unknown
1	Trimble BD920
2	Trimble BD930
3	Trimble BD982
4	Trimble MB-Two

Table 93: GNSS receiver models

13.9.46 North Seeking Initialisation Status Packet

North Seeking Initialisation Status Packet
--



Packet ID				71
Length				28
Field #	Bytes Offset	Data Type	Size	Description
1	0	u16	2	Flags, see section 13.9.46.1
2	2		2	Reserved (set to zero)
3	4	u8	1	Quadrant 1 data collection progress (%)
4	5	u8	1	Quadrant 2 data collection progress (%)
5	6	u8	1	Quadrant 3 data collection progress (%)
6	7	u8	1	Quadrant 4 data collection progress (%)
7	8	fp32	4	Current rotation angle (rad), see section 13.9.46.2
8	12	fp32	4	Current gyroscope bias solution X (rad/s)
9	16	fp32	4	Current gyroscope bias solution Y (rad/s)
10	20	fp32	4	Current gyroscope bias solution Z (rad/s)
11	24	fp32	4	Current gyroscope bias solution error (%)

Table 94: North seeking initialisation status packet

13.9.46.1 North Seeking Initialisation Status Flags


Bit	Description
0	North seeking initialisation complete
1	North seeking initialisation cannot start because the position is unknown
2	North seeking initialisation paused due to excessive rolling
3	North seeking initialisation paused due to excessive pitching
4	North seeking initialisation paused due to excessive movement
5-16	Reserved (set to zero)

Table 95: North seeking initialisation status flags

13.9.46.2 North Seeking Initialisation Current Rotation Angle

Range	Quadrant
$-\pi/4$ to $\pi/4$	Quadrant 1
$\pi/4$ to $3\pi/4$	Quadrant 2
$-3\pi/4$ to $3\pi/4$	Quadrant 3
$-3\pi/4$ to $-\pi/4$	Quadrant 4

Table 96: North seeking initialisation current rotation angle


**13.9.47 Gimbal State Packet**

Gimbal State Packet				
Packet ID		72		
Length		8		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Current angle (rad)
2	4		4	Reserved (set to zero)

*Table 97: Gimbal state packet***13.9.48 Automotive Packet**

Automotive Packet				
Packet ID		73		
Length		24		
Field #	Bytes Offset	Data Type	Size	Description
1	0	fp32	4	Virtual odometer distance (m)
2	4	fp32	4	Slip Angle (rad)
3	8	fp32	4	Velocity X (m/s)
4	12	fp32	4	Velocity Y (m/s)
5	16	fp32	4	Distance standard deviation (m)
6	20		4	Reserved (set to zero)

Table 98: Automotive packet



13.10 Configuration Packets

Configuration packets can be both read from and written to the device. On many of the configuration packets the first byte is a permanent flag. A zero in this field indicates that the settings will be lost on reset, a one indicates that they will be permanent.

13.10.1 Packet Timer Period Packet

Packet Timer Period Packet				
Packet ID			180	
Length			4	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u8	1	UTC synchronisation, see section 13.10.1.1
3	2	u16	2	Packet timer period, see section 13.10.1.2

Table 99: Packet timer period packet

13.10.1.1 UTC Synchronisation

This is a boolean value that determines whether or not the packet timer is synchronised with UTC time, with zero for disabled and one for enabled. For UTC Synchronisation to be enabled the packet timer period must multiply into 1000000 evenly. For example if the packet timer period is 10000 (10 ms), $1000000/10000 = 100$ which is valid for UTC synchronisation. If the packet timer period is 15000 (15 ms), $1000000/15000 = 66.6666$ which is not valid for UTC synchronisation. To get the rate use the following.

Packet Timer Rate = $1000000/(\text{Packet Timer Period})$ Hz

13.10.1.2 Packet Timer Period

This is a value in microseconds that sets the master packet timer period. The minimum value is 1000 (1 ms) or 1000 Hz and the maximum value is 65535 (65.535 ms) or 15.30 Hz.

13.10.2 Packets Period Packet

Packets Period Packet				
Packet ID				181
Length				2 + (5 x number of packet periods)
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u8	1	Clear existing packet periods, see section 13.10.2.1
3	2	u8	1	Packet ID
4	3	u32	4	Packet period, see section 13.10.2.2
+				Fields 3-4 repeat for additional packet periods

Table 100: Packets period packet

13.10.2.1 Clear Existing Packets

This is a boolean field, when set to one it deletes any existing packet rates. When set to zero existing packet rates remain. Only one packet rate can exist per packet ID, so new packet rates will overwrite existing packet rates for the same packet ID.

13.10.2.2 Packet Period


This indicates the period in units of the packet timer period. The packet rate can be calculated as follows.

$$\text{Packet Rate} = 1000000 / (\text{Packet Period} \times \text{Packet Timer Period}) \text{ Hz}$$

For example if the packet timer period is set to 1000 (1 ms). Setting packet ID 20 with a packet period of 50 will give the following.

$$\text{Packet 20 Rate} = 1000000 / (50 \times 1000)$$

$$\text{Packet 20 Rate} = 20 \text{ Hz}$$



13.10.3 Baud Rates Packet

Baud Rates Packet				
Packet ID			182	
Length			17	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u32	4	Primary RS422 port baud rate (2400 to 10,000,000)
3	5	u32	4	GPIO 1 & 2 baud rate (2400 to 250000)
4	9	u32	4	Auxiliary RS232 baud rate (2400 to 2000000)
5	13		4	Reserved (set to zero)

Table 101: Baud rates packet

13.10.4 Installation Alignment Packet

Installation Alignment Packet				
Packet ID			185	
Length			73	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	fp32	4	Alignment DCM[0][0]
3	5	fp32	4	Alignment DCM[0][1]
4	9	fp32	4	Alignment DCM[0][2]
5	13	fp32	4	Alignment DCM[1][0]
6	17	fp32	4	Alignment DCM[1][1]
7	21	fp32	4	Alignment DCM[1][2]
8	25	fp32	4	Alignment DCM[2][0]
9	29	fp32	4	Alignment DCM[2][1]
10	33	fp32	4	Alignment DCM[2][2]
11	37	fp32	4	GNSS antenna offset X (m)
12	41	fp32	4	GNSS antenna offset Y (m)
13	45	fp32	4	GNSS antenna offset Z (m)
14	49	fp32	4	Odometer offset X (m)
15	53	fp32	4	Odometer offset Y (m)
16	57	fp32	4	Odometer offset Z (m)
17	61	fp32	4	External data offset X (m)
18	65	fp32	4	External data offset Y (m)
19	69	fp32	4	External data offset Z (m)

Table 102: Installation alignment packet

13.10.4.1 Alignment DCM

The alignment DCM (direction cosine matrix) is used to represent an alignment offset of Spatial FOG Dual from it's standard alignment. A DCM is used rather than euler angles for accuracy reasons. To convert euler angles to DCM please use the formula below with angles in radians.


$$\text{DCM}[0][0] = \cos(\text{heading}) * \cos(\text{pitch})$$

$$\text{DCM}[0][1] = \sin(\text{heading}) * \cos(\text{pitch})$$

$$\text{DCM}[0][2] = -\sin(\text{pitch})$$

$$\text{DCM}[1][0] = -\sin(\text{heading}) * \cos(\text{roll}) + \cos(\text{heading}) * \sin(\text{pitch}) * \sin(\text{roll})$$

$$\text{DCM}[1][1] = \cos(\text{heading}) * \cos(\text{roll}) + \sin(\text{heading}) * \sin(\text{pitch}) * \sin(\text{roll})$$



$$DCM[1][2] = \cos(\text{pitch}) * \sin(\text{roll})$$

$$DCM[2][0] = \sin(\text{heading}) * \sin(\text{roll}) + \cos(\text{heading}) * \sin(\text{pitch}) * \cos(\text{roll})$$

$$DCM[2][1] = -\cos(\text{heading}) * \sin(\text{roll}) + \sin(\text{heading}) * \sin(\text{pitch}) * \cos(\text{roll})$$

$$DCM[2][2] = \cos(\text{pitch}) * \cos(\text{roll})$$

13.10.5 Filter Options Packet

Filter Options Packet				
Packet ID			186	
Length			17	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u8	1	Vehicle type, see section 13.10.5.1
3	2	u8	1	Internal GNSS enabled (boolean)
4	3	u8	1	Reserved (set to zero)
5	4	u8	1	Atmospheric altitude enabled (boolean)
6	5	u8	1	Velocity heading enabled (boolean)
7	6	u8	1	Reversing detection enabled (boolean)
8	7	u8	1	Motion analysis enabled (boolean)
9	8	u8	9	Reserved (set to zero)

Table 103: Filter options packet

13.10.5.1 Vehicle Types

Value	Description
0	Unconstrained
1	Bicycle or Motorcycle
2	Car
3	Hovercraft
4	Submarine
5	3D Underwater Vehicle
6	Fixed Wing Plane
7	3D Aircraft
8	Human
9	Boat
10	Large Ship

11	Stationary
12	Stunt Plane
13	Race Car

Table 104: Vehicle types

13.10.6 Advanced Filter Parameters Packet

Please contact Advanced Navigation support.


13.10.7 GPIO Configuration Packet

GPIO Configuration Packet				
Packet ID				188
Length				13
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u8	1	GPIO1 function, see section 13.10.7.1
3	2	u8	1	GPIO2 function, see section 13.10.7.2
4	3	u8	1	Auxiliary RS232 transmit function, section 13.10.7.3
5	4	u8	1	Auxiliary RS232 receive function, section 13.10.7.4
8	5	u8	8	Reserved (set to zero)

Table 105: GPIO configuration packet

13.10.7.1 GPIO1 Functions

Value	Description
0	Inactive
1	1PPS Output
2	GNSS Fix Output
3	Odometer Input
4	Zero Velocity Input
5	Pitot Tube Input
7	NMEA Output
12	ANPP Output
14	Disable GNSS
15	Disable Pressure
16	Set Zero Orientation Alignment




17	System State Packet Trigger
18	Raw Sensors Packet Trigger
26	Pressure Depth Transducer
27	Left Wheel Speed Sensor
28	Right Wheel Speed Sensor
29	1PPS Input
30	Wheel Speed Sensor
31	Wheel Encoder Phase A
32	Wheel Encoder Phase B
33	Event 1 Input
34	Event 2 Input
38	GNSS Receiver Passthrough
39	TSS1 Output
40	Simrad 1000 Output
41	Simrad 3000 Output
42	Serial Port Passthrough
43	Gimbal Encoder Phase A
44	Gimbal Encoder Phase B
45	Odometer Direction, Forward Low
46	Odometer Direction, Forward High
53	Reverse Alignment, Forward Low
54	Reverse Alignment, Forward High
55	Zero Angular Velocity Input

Table 106: GPIO1 functions


13.10.7.2 GPIO2 Functions

Value	Description
0	Inactive
1	1PPS Output
2	GNSS Fix Output
3	Odometer Input
4	Zero Velocity Input
5	Pitot Tube Input
6	NMEA Input
8	Novatel GNSS Input



9	Topcon GNSS Input
11	ANPP Input
14	Disable GNSS
15	Disable Pressure
16	Set Zero Orientation Alignment
17	System State Packet Trigger
18	Raw Sensors Packet Trigger
19	RTCM Differential GNSS Corrections Input
20	Trimble GNSS Input
21	u-blox GNSS Input
22	Hemisphere GNSS Input
23	Teledyne DVL Input
24	Tritech USBL Input
25	Linkquest DVL Input
26	Pressure Depth Transducer
27	Left Wheel Speed Sensor
28	Right Wheel Speed Sensor
29	1PPS Input
30	Wheel Speed Sensor
31	Wheel Encoder Phase A
32	Wheel Encoder Phase B
33	Event 1 Input
34	Event 2 Input
35	Linkquest USBL Input
38	GNSS Receiver Passthrough
42	Serial Port Passthrough
43	Gimbal Encoder Phase A
44	Gimbal Encoder Phase B
45	Odometer Direction, Forward Low
46	Odometer Direction, Forward High
51	Nortek DVL Input
53	Reverse Alignment, Forward Low
54	Reverse Alignment, Forward High
55	Zero Angular Velocity Input


Table 107: GPIO2 functions

**13.10.7.3 Auxiliary RS232 Transmit Functions**

Value	Description
0	Inactive
1	1PPS Output
2	GNSS Fix Output
7	NMEA Output
12	ANPP Output
38	GNSS Receiver Passthrough
39	TSS1 Output
40	Simrad 1000 Output
41	Simrad 3000 Output
42	Serial Port Passthrough

*Table 108: Auxiliary RS232 transmit functions***13.10.7.4 Auxiliary RS232 Receive Functions**

Value	Description
0	Inactive
3	Odometer Input
4	Zero Velocity Input
5	Pitot Tube Input
6	NMEA Input
8	Novatel GNSS Input
9	Topcon GNSS Input
11	ANPP Input
14	Disable GNSS
15	Disable Pressure
16	Set Zero Orientation Alignment
17	System State Packet Trigger
18	Raw Sensors Packet Trigger
19	RTCM Differential GNSS Corrections Input
20	Trimble GNSS Input
21	u-blox GNSS Input
22	Hemisphere GNSS Input
23	Teledyne DVL Input
24	Tritech USBL Input



25	Linkquest DVL Input
26	Pressure Depth Transducer
27	Left Wheel Speed Sensor
28	Right Wheel Speed Sensor
29	1PPS Input
30	Wheel Speed Sensor
33	Event 1 Input
34	Event 2 Input
35	Linkquest USBL Input
38	GNSS Receiver Passthrough
42	Serial Port Passthrough
45	Odometer Direction, Forward Low
46	Odometer Direction, Forward High
51	Nortek DVL Input
53	Reverse Alignment, Forward Low
54	Reverse Alignment, Forward High
55	Zero Angular Velocity Input

Table 109: Auxiliary RS232 receive functions


13.10.8 Odometer Configuration Packet

Odometer Configuration Packet				
Packet ID			192	
Length			8	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u8	1	Automatic pulse measurement active
3	2	u8	2	Reserved (set to zero)
4	4	fp32	4	Pulse length (m)

Table 110: Odometer configuration packet

13.10.9 Set Zero Orientation Alignment Packet

This packet was modified as of firmware version 2.0 for code safety certification. Previously it was 1 byte long with no verification sequence.



Set Zero Orientation Alignment Packet				
Packet ID			193	
Length			5	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u32	4	Verification sequence (set to 0x9A4E8055)

Table 111: Set zero orientation alignment packet

13.10.10 Reference Point Offsets Packet

The reference point offsets packet can be used to adjust the measurement point that all data is referenced to. By default all the values of this packet are zero and the measurement point that all data is referenced to is the centre of the Spatial FOG Dual unit. The primary reference point offset can be used to adjust the measurement point to a different location on the vehicle. The primary reference point offset applies to all data output including NMEA etc as well as heave point 1. The other heave point offsets apply only to heave points 2-4 in the Heave Packet.

Reference Points Offset Packet				
Packet ID			194	
Length			49	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	fp32	4	Primary reference point offset X (m)
3	5	fp32	4	Primary reference point offset Y (m)
4	9	fp32	4	Primary reference point offset Z (m)
5	13	fp32	4	Heave point 2 offset X (m)
6	17	fp32	4	Heave point 2 offset Y (m)
7	21	fp32	4	Heave point 2 offset Z (m)
8	25	fp32	4	Heave point 3 offset X (m)
9	29	fp32	4	Heave point 3 offset Y (m)
10	33	fp32	4	Heave point 3 offset Z (m)
11	37	fp32	4	Heave point 4 offset X (m)
12	41	fp32	4	Heave point 4 offset Y (m)
13	45	fp32	4	Heave point 4 offset Z (m)

Table 112: Reference point offsets packet

13.10.11 GPIO Output Configuration Packet

GPIO Output Configuration Packet				
Packet ID			195	
Length			33	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u8	1	NMEA fix behaviour, see section 13.10.11.1
3	2	u16	2	GPZDA Rates, see section 13.10.11.2
4	4	u16	2	GPGGA Rates, see section 13.10.11.2
5	6	u16	2	GPVTG Rates, see section 13.10.11.2
6	8	u16	2	GPRMC Rates, see section 13.10.11.2
7	10	u16	2	GPHDT Rates, see section 13.10.11.2
8	12	u16	2	GPGLL Rates, see section 13.10.11.2
9	14	u16	2	PASHR Rates, see section 13.10.11.2
10	16	u16	2	TSS1 Rates, see section 13.10.11.2
11	18	u16	2	Simrad Rates, see section 13.10.11.2
12	20		12	Reserved (set to zero)

Table 113: GPIO output configuration packet

13.10.11.1 NMEA Fix Behaviour

Value	Description
0	Normal
1	Always indicate 3D fix when the navigation filter is initialised

Table 114: NMEA fix behaviour

13.10.11.2 GPIO Output Rates

Bit	Description
0-3	GPIO 1 rate, see 13.10.11.3
4-7	Auxiliary RS232 Tx rate, see 13.10.11.3
8-15	Reserved (set to zero)

Table 115: GPIO output rates

13.10.11.3 GPIO Output Rates Index

Value	Bit 3	Bit 2	Bit 1	Bit 0	Description
0	0	0	0	0	Disabled
1	0	0	0	1	0.1 Hz
2	0	0	1	0	0.2 Hz
3	0	0	1	1	0.5 Hz
4	0	1	0	0	1 Hz
5	0	1	0	1	2 Hz
6	0	1	1	0	5 Hz
7	0	1	1	1	10 Hz
8	1	0	0	0	25 Hz
9	1	0	0	1	50 Hz

Table 116: GPIO output rates index

13.10.12 Dual Antenna Configuration Packet

By default the system uses automatic offset with primary front and secondary rear. If entering a manual offset, the automatic offset orientation type is ignored and can be set to zero. Likewise when using an automatic offset, the manual offset values are ignored and can be set to zero. When operating with an automatic offset the manual offset values will be populated with the automatically calculated offset values.

Dual Antenna Configuration Packet				
Packet ID			196	
Length			17	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	u16	2	Offset type, see section 13.10.12.1
3	3	u8	1	Automatic offset orientation, see section 13.10.12.2
4	4	u8	1	Reserved (set to zero)
5	5	fp32	4	Manual offset X (m)
6	9	fp32	4	Manual offset Y (m)
7	13	fp32	4	Manual offset Z (m)

Table 117: Dual antenna configuration packet

13.10.12.1 Offset Types

Value	Description
0	Manual offset
1	Automatic offset

Table 118: Offset types

13.10.12.2 Automatic Offset Orientations

Value	Description
0	Primary front and secondary rear
1	Primary rear and secondary front
2	Primary right and secondary left
3	Primary left and secondary right

Table 119: Automatic offset orientations

13.10.13 User Data Packet

This packet is for storage of users data. The data itself is not used by Spatial FOG Dual.

User Data Packet				
Packet ID			198	
Length			64	
Field #	Bytes Offset	Data Type	Size	Description
1	0		64	User Data

Table 120: User data packet

13.10.14 GPIO Input Configuration Packet

GPIO Input Configuration Packet				
Packet ID			199	
Length			65	
Field #	Bytes Offset	Data Type	Size	Description
1	0	u8	1	Permanent
2	1	fp32	4	Gimbal radians per encoder tick
3	2		60	Reserved (set to zero)

Table 121: GPIO input configuration packet



Information in this document is provided solely in connection with Advanced Navigation products. Advanced Navigation reserves the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All Advanced Navigation products are sold pursuant to Advanced Navigation's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the Advanced Navigation products and services described herein, and Advanced Navigation assumes no liability whatsoever relating to the choice, selection or use of the Advanced Navigation products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by Advanced Navigation for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ADVANCED NAVIGATION'S TERMS AND CONDITIONS OF SALE ADVANCED NAVIGATION DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ADVANCED NAVIGATION PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY TWO AUTHORIZED ADVANCED NAVIGATION REPRESENTATIVES, ADVANCED NAVIGATION PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE.

ADVANCED NAVIGATION PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of Advanced Navigation products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by Advanced Navigation for the Advanced Navigation product or service described herein and shall not create or extend in any manner whatsoever, any liability of Advanced Navigation.

Information in this document supersedes and replaces all information previously supplied.

© 2022 Advanced Navigation - All rights reserved