

Dell PowerEdge Command Line Reference Guide for the M I/O Aggregator 9.8(0.0)



Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your computer.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Contents

1 About this Guide.....	15
Objectives.....	15
Audience.....	15
Conventions.....	15
Information Icons.....	16
2 Before You Start.....	17
Operational Modes.....	17
Default Settings.....	17
Other Auto-Configured Settings.....	18
DCB Support.....	18
FCoE Connectivity.....	18
iSCSI Operation.....	18
Link Aggregation.....	19
Link Tracking.....	19
VLANs.....	19
Where to Go From Here.....	20
3 CLI Basics.....	21
Accessing the Command Line.....	21
Multiple Configuration Users.....	21
Navigating the CLI.....	22
Obtaining Help.....	22
Using the Keyword no Command.....	24
Filtering show Commands.....	24
Command Modes.....	25
4 File Management.....	27
boot system gateway.....	27
boot system stack-unit.....	27
cd.....	28
copy.....	28
copy running-config startup-config.....	30
delete.....	30
dir.....	31
format flash.....	31
HTTP Copy via CLI.....	32
logging coredump stack-unit.....	33
pwd.....	33
rename.....	33
restore factory-defaults.....	34
show boot system.....	35



show file.....	36
show file-systems.....	37
show os-version.....	38
show running-config.....	38
show version.....	40
upgrade boot.....	41
upgrade system.....	42

5 Control and Monitoring..... 44

asset-tag.....	44
clear alarms.....	44
clear command history.....	45
configure.....	45
debug cpu-traffic-stats.....	46
debug ifm trace-flags.....	46
disable.....	47
enable.....	47
end.....	48
exit.....	48
ftp-server enable.....	48
ftp-server topdir.....	49
ftp-server username.....	50
hostname.....	50
ip telnet server enable.....	51
ip telnet source-interface.....	51
line.....	52
ping.....	52
reload.....	54
service timestamps.....	54
show alarms.....	55
show command-history.....	56
show configuration lock.....	57
show cpu-traffic-stats.....	57
show debugging.....	58
show diag.....	59
show environment.....	59
show inventory.....	60
show memory.....	61
show processes cpu.....	62
show processes ipc flow-control.....	65
show processes memory.....	66
show revision.....	68
show server-interfaces.....	69
show system.....	70
show tech-support.....	71
show uplink brief.....	74

show util-threshold cpu.....	75
show util-threshold memory.....	75
ssh-peer-stack-unit.....	75
telnet.....	76
telnet-peer-stack-unit.....	77
terminal length.....	77
terminal monitor.....	77
terminal xml.....	78
trace route.....	78
undebg all.....	79
write.....	80

6 u-Boot..... 81

boot change.....	81
boot selection.....	81
boot show net config retries.....	82
boot write net config retries.....	82
boot zero.....	82
default gateway.....	83
enable.....	83
help.....	83
ignore enable password.....	84
ignore startup-config.....	84
interface management ethernet ip address.....	85
no default gateway.....	85
no interface management ethernet ip address.....	85
reload.....	86
show boot blc.....	86
show boot selection.....	86
show bootflash.....	87
show bootvar.....	87
show default gateway.....	88
show interface management ethernet.....	89
show interface management port config.....	89
syntax help.....	89

7 Data Center Bridging (DCB)..... 91

Fibre Channel over Ethernet for FC Flex IO Modules.....	91
advertise dcbx-appln-tlv.....	92
advertise dcbx-tlv.....	92
bandwidth-percentage.....	93
clear dcbx counters.....	94
clear ets counters.....	94
clear pfc counters.....	94
dcb-enable.....	95
dcb enable pfc-queues.....	95



dcb enable auto-detect on-next-reload.....	96
dcb-map stack-unit all stack-ports all.....	99
dcbx-port role.....	99
dcbx version.....	100
debug dcbx.....	101
fc-map.....	101
fcoe-map.....	102
fcoe priority-bits.....	103
iscsi priority-bits.....	104
keepalive.....	104
interface vlan (NPIV proxy gateway).....	105
pfc mode on.....	105
pfc no-drop queues.....	106
pfc priority.....	107
priority-group.....	108
priority-group bandwidth pfc.....	108
priority-pgid.....	110
qos-policy-output ets.....	111
scheduler.....	111
show dcb.....	112
show interface dcbx detail.....	113
show interface ets.....	115
show interface pfc.....	118
show interface pfc statistics.....	121
show qos dcb-map.....	121
show stack-unit stack-ports ets details.....	122
show stack-unit stack-ports pfc details.....	123

8 Dynamic Host Configuration Protocol..... 125

clear ip dhcp client statistics.....	125
debug ip dhcp client events.....	126
debug ip dhcp client packets.....	126
ip address dhcp.....	127
release dhcp interface.....	127
renew dhcp interface.....	128
show ip dhcp client statistics.....	129
show ip dhcp lease.....	129

9 FC Flex IO Modules..... 130

Fibre Channel over Ethernet for FC Flex IO Modules.....	130
NPIV Proxy Gateway for FC Flex IO Modules.....	130
description (for FCoE maps).....	130
fabric.....	131
fabric-id vlan.....	132
fcf-priority.....	133
fc-map.....	133

fcoe-map.....	134
fka-adv-period.....	135
interface vlan (NPIV proxy gateway).....	136
keepalive.....	137
show fc switch.....	137
show fcoe-map.....	138
show npiv devices.....	140
show running-config fcoe-map.....	142

10 FC FLEXIO FPORT..... 143

active-zoneset	143
fabric.....	143
fc alias.....	144
fc zone.....	145
fc zoneset.....	145
fcoe-map.....	146
feature fc.....	147
show fc alias.....	147
show fc ns.....	148
show fc switch.....	149
show fc zone.....	150
show fc zoneset.....	151
show fcoe-map.....	152

11 FIP Snooping..... 153

clear fip-snooping database interface vlan.....	153
clear fip-snooping statistics.....	153
feature fip-snooping.....	154
fip-snooping enable.....	154
fip-snooping fc-map.....	155
fip-snooping port-mode fcf.....	155
show fip-snooping statistics.....	156
debug fip-snooping.....	158
show fip-snooping config.....	159
show fip-snooping enode.....	159
show fip-snooping fcf.....	160
show fip-snooping sessions.....	161
show fip-snooping statistics.....	162
show fip-snooping system.....	165
show fip-snooping vlan.....	165

12 Internet Group Management Protocol (IGMP)..... 166

IGMP Commands.....	166
IGMP Snooping Commands.....	167
clear ip igmp groups.....	167
debug ip igmp.....	167



ip igmp group-join-limit.....	168
ip igmp querier-timeout.....	168
ip igmp query-interval.....	169
ip igmp query-max-resp-time.....	169
ip igmp snooping enable.....	170
ip igmp snooping fast-leave.....	170
ip igmp snooping flood.....	171
ip igmp snooping last-member-query-interval.....	171
ip igmp snooping mrouter.....	172
ip igmp snooping querier.....	172
ip igmp version.....	173
show ip igmp groups.....	173
show ip igmp interface.....	174
show ip igmp snooping mrouter.....	175

13 Interfaces..... 177

Port Interface Commands.....	177
Port Channel Commands.....	177
Time Domain Reflectometer (TDR) Commands.....	178
Virtual LAN (VLAN) Commands.....	178
auto vlan.....	178
channel-member.....	179
clear counters.....	180
clear mac-address-table dynamic.....	181
default vlan-id.....	181
description.....	182
feature fc.....	182
flowcontrol.....	183
interface.....	185
interface ManagementEthernet.....	185
interface port-channel.....	186
interface range.....	187
interface vlan.....	189
intf-type cr4 autoneg.....	189
keepalive.....	190
minimum-links.....	190
monitor interface.....	191
mtu.....	193
name.....	194
negotiation auto.....	195
remote-fault-signaling rx.....	197
show config (INTERFACE mode).....	197
show config (from INTERFACE RANGE mode).....	198
show config (from INTERFACE VLAN mode).....	198
show config (from PROTOCOL LLDP mode).....	199
show interfaces.....	199

show interfaces configured.....	202
show interfaces description.....	203
show interfaces port-channel.....	204
show interfaces stack-unit.....	207
show interfaces status.....	208
show interfaces switchport.....	209
show tdr.....	210
show vlan.....	211
shutdown.....	212
source (port monitoring for 40-Gigabit Ethernet).....	213
speed (for 1000/10000 interfaces).....	214
stack-unit portmode.....	215
tdr-cable-test.....	215
vlan tagged (CMC).....	216
vlan untagged (CMC).....	217
14 IPv4 Routing.....	219
clear tcp statistics.....	219
debug ip dhcp.....	219
debug ip icmp.....	220
ip route.....	221
management route.....	222
show arp.....	223
show ip interface.....	225
show ip management-route.....	226
show ip multicast-cam stack-unit.....	227
show ip route.....	228
show tcp statistics.....	230
15 iSCSI Optimization.....	233
advertise dcbx-app-tlv.....	233
iscsi aging time.....	233
iscsi cos.....	234
iscsi enable.....	235
iscsi priority-bits.....	235
iscsi profile-compellent.....	236
iscsi target port.....	236
show iscsi.....	237
show iscsi sessions.....	237
show iscsi sessions detailed.....	238
16 Isolated Networks.....	240
io-aggregator isolated-network vlan.....	240
show io-aggregator isolated-networks	240
17 Link Aggregation Control Protocol (LACP).....	242



auto-lag enable.....	242
clear lacp counters.....	242
debug lacp.....	243
delay-restore abort-threshold.....	243
io-aggregator auto-lag enable.....	244
lacp link-fallback member.....	244
lacp long-timeout.....	245
lacp port-priority.....	245
port-channel mode.....	246
port-channel-protocol lacp.....	247
show interfaces port-channel.....	247
show io-aggregator auto-lag status.....	250
show lacp.....	250
show link-bundle-distribution port-channel.....	251
show port-channel-flow.....	252

18 Layer 2.....254

MAC Addressing Commands.....	254
Virtual LAN (VLAN) Commands.....	254
clear mac-address-table dynamic.....	254
description.....	255
mac-address-table aging-time.....	255
mac-address-table static.....	256
mac-address-table station-move refresh-arp.....	256
show cam mac stack-unit.....	257
show mac-address-table.....	258

19 Link Layer Discovery Protocol (LLDP).....261

advertise dot3-tlv.....	261
advertise management-tlv.....	262
clear lldp counters.....	262
clear lldp neighbors.....	263
debug lldp interface.....	263
disable.....	264
hello.....	264
multiplier.....	265
protocol lldp (Configuration).....	265
protocol lldp (Interface).....	266
show lldp neighbors.....	266
show lldp statistics.....	267

20 Port Monitoring.....268

description.....	268
monitor session.....	269
show config.....	270
show monitor session.....	270

show running-config monitor session.....	271
source (port monitoring).....	271

21 Quality of Service (QoS)..... 273

Per-Port QoS Commands.....	273
Policy-Based QoS Commands.....	273
bandwidth-percentage.....	273
description.....	274
dot1p-priority.....	274
policy-aggregate.....	275
policy-map-output.....	276
qos-policy-output.....	276
rate-shape.....	277
service-class bandwidth-percentage.....	278
service-class dot1p-mapping.....	278
service-class dynamic dot1p.....	279
service-policy output.....	280
service-queue.....	281
show qos dcb-map.....	281
show qos dot1p-queue-mapping.....	282
show qos qos-policy-output.....	283

22 Security..... 284

AAA Accounting Commands.....	284
aaa accounting.....	284
aaa accounting suppress.....	285
aaa authorization commands.....	286
aaa authorization config-commands.....	286
aaa authorization exec.....	287
accounting.....	287
show accounting.....	288
Authentication and Password Commands.....	289
aaa authentication enable.....	289
aaa authentication login.....	290
banner exec.....	291
banner login.....	292
banner motd.....	293
debug radius.....	294
debug tacacs+.....	294
exec-banner.....	294
ip radius source-interface.....	295
ip tacacs source-interface.....	295
login authentication.....	296
RADIUS Commands.....	297
radius-server deadtime.....	297
radius-server host.....	297



radius-server key.....	298
radius-server retransmit.....	299
radius-server timeout.....	299
show privilege.....	300
Suppressing AAA Accounting for Null Username Sessions.....	300
TACACS+ Commands.....	300
TACACS+ Accounting.....	301
tacacs-server host.....	302
tacacs-server key.....	303
timeout login response.....	303
SSH Server and SCP Commands.....	304
enable password.....	304
enable restricted.....	305
service password-encryption.....	305
show ip ssh.....	306
show ip ssh client-pub-keys.....	306
show ip ssh rsa-authentication.....	307
show users.....	307
ssh.....	308
username.....	309

23 Stacking Commands.....311

power-cycle stack-unit.....	311
reset stack-unit.....	312
show system stack-ports.....	313
show system stack-unit fanout.....	314
show system stack-unit iom-mode.....	315
show system stack-unit iom-uplink-speed.....	315
show system stack-unit stack-group.....	316
stack-unit iom-mode.....	316
stack-unit iom-mode uplink-speed.....	317
stack-unit priority.....	318
stack-unit renumber.....	319

24 Storm Control..... 320

io-aggregator broadcast storm-control.....	320
show io-aggregator broadcast storm-control status.....	321
show storm-control unknown-unicast.....	321
storm-control broadcast (Interface).....	322
storm-control multicast (Interface).....	322
storm-control unknown-unicast (Interface).....	323

25 System Time..... 324

calendar set.....	324
clock read-calendar.....	325
clock set.....	325

clock summer-time date.....	326
clock summer-time recurring.....	327
clock timezone.....	328
clock update-calendar.....	329
ntp server.....	329
show calendar.....	330
show clock.....	331

26 Uplink Failure Detection (UFD).....332

clear ufd-disable.....	332
debug uplink-state-group.....	333
defer-timer.....	333
description.....	334
downstream.....	334
downstream auto-recover.....	335
downstream disable links.....	336
enable.....	336
show running-config uplink-state-group.....	337
show uplink-state-group.....	337
uplink-state-group.....	339
upstream.....	339

27 Virtual Link Trunking (VLT).....341

back-up destination.....	341
clear vlt statistics.....	342
lacp ungroup member-independent.....	342
peer-link port-channel.....	343
show vlt backup-link.....	344
show vlt brief.....	344
show vlt detail.....	345
show vlt mismatch.....	345
show vlt role.....	346
show vlt statistics.....	346
stack-unit iom-mode.....	348
system-mac.....	348
unit-id.....	349
vlt domain.....	349
vlt-peer-lag port-channel.....	350

28 Debugging and Diagnostics.....351

Offline Diagnostic Commands.....	351
Hardware Commands.....	351
clear hardware stack-unit.....	352
diag stack-unit.....	352
hardware watchdog.....	353
offline stack-unit.....	354



show diag.....	355
show hardware stack-unit.....	357
show hardware counters interface.....	365
show hardware buffer interface.....	367
show hardware system-flow.....	368
show hardware buffer-stats-snapshot.....	370
show hardware stack-unit buffer-stats-snapshot (Total Buffer Information).....	373
show hardware drops.....	375
A Internet Control Message Protocol (ICMP) Message Types.....	377

About this Guide

This book provides information about the Dell Networking OS command line interface (CLI) on the Dell PowerEdge M I/O Aggregator.

This book also includes information about the protocols and features found in the Dell Networking OS and on the Dell Networking systems supported by the Dell Networking OS.

References

For more information about your system, refer to the following documents:

- *Dell PowerEdge M I/O Aggregator Configuration Guide*
- *Dell PowerEdge M I/O Aggregator Getting Started Guide*
- *Release Notes for the Dell PowerEdge M I/O Aggregator*

Objectives

This book is intended as a reference guide for the Aggregator CLI commands, with detailed syntax statements, along with usage information and sample output.

This guide contains an Appendix with a list of the request for comment (RFCs) and management information base files (MIBs) supported.



NOTE: For more information about when to use the CLI commands, refer to the *Dell PowerEdge M I/O Aggregator Configuration Guide* for your system.

Audience

This book is intended for system administrators who are responsible for configuring or maintaining networks. This guide assumes that you are knowledgeable in Layer 2 and Layer 3 networking technologies.

Conventions

This book uses the following conventions to describe command syntax.

Keyword	Keywords are in Courier font and must be entered in the CLI as listed.
<i>parameter</i>	Parameters are in italics and require a number or word to be entered in the CLI.
{X}	Keywords and parameters within braces must be entered in the CLI.



[X]	Keywords and parameters within brackets are optional.
x y	Keywords and parameters separated by a bar require you to choose one option.
x y	Keywords and parameters separated by a double bar allows you to choose any or all of the options.

Information Icons

This book uses the following information symbols:



NOTE: The Note icon signals important operational information.



CAUTION: The Caution icon signals information about situations that could result in equipment damage or loss of data.



WARNING: The Warning icon signals information about hardware handling that could result in injury.

Before You Start

By following the instructions in the *Dell PowerEdge M I/O Aggregator Getting Started Guide* that is shipped with the product, you install the Aggregator in a Dell PowerEdge M1000e Enclosure.

The Aggregator installs with zero-touch configuration. After you power it on, an Aggregator boots up with default settings and auto-configures with software features enabled. This chapter describes the default settings and software features that are automatically configured at startup. Use the tasks described in the other chapters to reconfigure the Aggregator for customized network operation.

Operational Modes

The I/O Aggregator supports four operational modes. Select the operational mode that meets your deployment needs. To enable a new operational mode, reload the switch.

- Standalone mode — stack-unit unit iom-mode standalone. This is the default mode for IOA. It is fully automated zero-touch mode that allows you to configure VLAN memberships. (Supported in CMC)
- Programmable MUX mode (PMUX) — stack-unit unit iom-mode programmable-mux. Select this mode to configure PMUX mode CLI commands.
- Stacking mode — stack-unit unit iom-mode stacking. Select this mode to stack up to 6 IOA stack units as a single logical switch. The stack units can be in the same or on different chassis. This is a low-touch mode where all configuration except VLAN membership is automated. To enable VLAN, you must configure it. In this operational mode, base module links are dedicated to stacking.
- Virtual Link Trunking mode (VLT) — stack-unit unit iom-mode vlt. Select this mode to multi-home server interfaces to different IOA modules. This is a low-touch mode where all configuration except VLAN membership is automated. To enable VLAN, you must configure it. In this mode, base module links are dedicated to VLT interconnect.

For more information, refer to the *Dell PowerEdge M I/O Aggregator Configuration Guide*.

Default Settings

The I/O Aggregator provides zero-touch configuration with the following default configuration settings:

- Default user name (**root**)
- Password (**calvin**)
- VLAN (**vlan1**) and IP address for in-band management (**DHCP-assigned**)
- IP address for out-of-band (OOB) management (**DHCP-assigned**)
- Read-only SNMP community name (**public**)
- Broadcast storm control (**enabled**)
- Unregistered Multicast Packets flooding (**enabled**)
- IGMP snooping in all VLANs except the default VLAN (**enabled**)
- VLAN configuration (**all ports belong to all VLANs**)

You can change any of these default settings using the CLI. Refer to the appropriate chapter for details.





NOTE: You can also change many of the default settings using the chassis management controller (CMC) interface. For information about how to access the CMC to configure an Aggregator, refer to the *Dell PowerEdge M1000e Enclosure Hardware Owner's Manual* or *Dell Chassis Management Controller (CMC) User's Guide* on the Dell Support website at <http://support.dell.com/support/edocs/systems/pem/en/index.htm>.

Other Auto-Configured Settings

After the Aggregator powers on, it auto-configures and is operational with software features enabled, including:

- VLANs: All ports are configured as members of all (4094) VLANs. All VLANs are up and can send or receive layer 2 traffic. For more information, refer to [VLANs](#).
- Data Center Bridging Capability Exchange Protocol (DCBX)
- Fibre Channel over Ethernet (FCoE) connectivity
- FCoE Initiation Protocol (FIP) snooping
- Hybrid ports: Ports are administratively up and auto-configured to operate as hybrid ports to transmit tagged and untagged VLAN traffic.
- iSCSI optimization
- IGMP snooping
- Jumbo frames: Ports are set to a maximum MTU of 12,000 bytes by default.
- Link aggregation: All uplink ports are configured in a single LAG (LAG 128).
- Link Layer Discovery Protocol (LLDP): Enabled on all ports.
- Link tracking: Enables server-facing links to be brought up only if the uplink port-channel (LAG 128) is up.
- Stacking: Stacking is supported only on the 40GbE ports on the base module. A single stack is limited to six Aggregators in the same chassis. Up to three stacks are supported in an M1000e chassis. To configure a switch stack, you must use the CLI. For more information, refer to Stacking Commands.

DCB Support

DCB enhancements for data center networks are supported to eliminate packet loss and provision links with required bandwidth. The Aggregator provides zero-touch configuration for DCB. The Aggregator auto-configures DCBX port roles to match the DCBX configuration in the ToR switches to which it connects through its uplink ports.

The Aggregator supports DCB only in standalone mode and not in the stacking mode.

FCoE Connectivity

Many data centers use Fibre Channel (FC) in storage area networks (SANs). Fibre Channel over Ethernet (FCoE) encapsulates Fibre Channel frames over Ethernet networks.

On an Aggregator, the internal ports support FCoE connectivity and connect to the converged network adapter (CNA) in blade servers. FCoE allows Fibre Channel to use 10-Gigabit Ethernet networks while preserving the Fibre Channel protocol.

The Aggregator also provides zero-touch configuration for FCoE configuration. The Aggregator auto-configures to match the FCoE settings used in the ToR switches to which it connects through its uplink ports.

iSCSI Operation

Support for iSCSI traffic is turned on by default when the Aggregator powers up. No configuration is required.

When the Aggregator powers up, it monitors known TCP ports for iSCSI storage devices on all interfaces. When a session is detected, an entry is created and monitored as long as the session is active.



The Aggregator also detects iSCSI storage devices on all interfaces and auto-configures to optimize performance. Performance optimization operations, such as Jumbo frame size support, and disabling storm control on interfaces connected to an iSCSI equallogic (EQL) storage device, are applied automatically.

CLI configuration is necessary only when the configuration includes iSCSI storage devices that cannot be automatically detected and when non-default QoS handling is required.

Link Aggregation

In Standalone, VLT, and Stacking modes, all uplink ports are configured in a single LAG (LAG 128). There can be multiple uplink LAGs in programmable-mux mode. Server-facing ports are auto-configured as part of link aggregation groups if the corresponding server is configured for LACP-based NIC teaming. Static LAGs are supported in PUX mode.

 **NOTE: The recommended LACP timeout is Long-Timeout mode.**

Link Tracking

By default, all server-facing ports are tracked by the operational status of the uplink LAG. If the uplink LAG goes down, the Aggregator loses its connectivity and is no longer operational; all server-facing ports are brought down.

 **NOTE: If installed servers do not have connectivity to a ToR switch, check the Link Status LED of uplink ports on the Aggregator. If all LEDs are ON, check the LACP configuration on the ToR switch that is connected to the Aggregator to ensure the LACP is correctly configured.**

VLANs

By default, all Aggregator ports belong to all 4094 VLANs and are members of untagged VLAN 1. You can use the CLI or CMC interface to configure only the required VLANs on a port.

When you configure VLANs on server-facing interfaces (ports 1 to 32), you can assign VLANs to a port or a range of ports by entering the `vlan tagged` or `vlan untagged` commands in interface configuration mode; for example:

```
Dell(conf)# interface tengigabitethernet 0/2 - 4
Dell(conf-if-range-te-0/2-4)# vlan tagged 5,7,10-12
Dell(conf-if-range-te-0/2-4)# vlan untagged 3
```

 **NOTE: You can also use the CMC interface to configure VLANs.**

Uplink LAG

The tagged VLAN membership of the uplink LAG is automatically configured based on the tagged and untagged VLAN configuration of all server-facing ports (ports 1 to 32).

The untagged VLAN used for the uplink LAG is always the default VLAN.

Server-Facing LAGs

The tagged VLAN membership of a server-facing LAG is automatically configured based on the server-facing ports that are members of the LAG.

The untagged VLAN of a server-facing LAG is configured based on the untagged VLAN to which the lowest numbered server-facing port in the LAG belongs.

 **NOTE: Dell Networking recommends that you configure the same VLAN membership on all LAG member ports.**

Stacking Mode



When you configure an Aggregator to operate in stacking mode (See “Configuring and Bringing Up a Stack” in the Dell Networking Configuration Guide for the M I/O Aggregator), VLANs are reconfigured as follows:

If an Aggregator port belonged to all 4094 VLANs in standalone mode (default), all VLAN membership is removed and the port is assigned only to default VLAN 1. You must configure additional VLAN membership as necessary.

If you had manually configured an Aggregator port to belong to one or more VLANs (non-default) in standalone mode, the VLAN configuration is retained in stacking mode only on the master switch

When you reconfigure an Aggregator from stacking to standalone mode:

Aggregator ports that you manually configured for VLAN membership in stacking mode retain their VLAN configuration in standalone mode.

To restore the default auto-VLAN mode of operation (in which all ports are members of all 4094 VLANs) on a port, enter the `auto vlan` command; for example:

```
Dell(conf)# interface tengigabitethernet 0/2
Dell(conf-if-te-0/2)# auto vlan
```

To get the default standalone mode configurations:

1. Delete the **startup-config** file and reboot the system.
2. Restore to factory default settings.
3. Configure **auto vlan** command on all the server ports.

Where to Go From Here

You can customize the Aggregator for use in your data center network as necessary. To perform additional switch configuration, do one of the following:

- For remote out-of-band management, enter the OOB management interface IP address into a Telnet or SSH client and log in to the switch using the user ID and password to access the CLI.
- For local management using the CLI, use the attached console connection.
- For remote in-band management from a network management station, enter the VLAN IP address of the management port and log in to the switch to access the CLI.

If you installed the Aggregator in a stack, you can configure additional settings for switch stacking

In case of a Dell Networking OS upgrade, you can check to see that an Aggregator is running the latest Dell Networking OS version by entering the [show version](#) command. To download a Dell Networking OS version, go to <http://support.dell.com>.

Refer to the appropriate chapter for detailed information on how to configure specific software settings.



CLI Basics

This chapter describes the command line interface (CLI) structure and command modes. The Dell operating system commands are in a text-based interface that allows you to use the launch commands, change command modes, and configure interfaces and protocols.

Accessing the Command Line

When the system boots successfully, you are positioned on the command line in EXEC mode and not prompted to log in. You can access the commands through a serial console port or a Telnet session. When you Telnet into the switch, you are prompted to enter a login name and password.

Example

```
telnet 172.31.1.53
Trying 172.31.1.53...
Connected to 172.31.1.53.
Escape character is '^]'.
Login: username
Password:
Dell>
```

After you log in to the switch, the prompt provides you with the current command-level information. For example:

Prompt	CLI Command Mode
Dell>	EXEC
Dell#	EXEC Privilege
Dell (conf) #	CONFIGURATION

 **NOTE:** For a list of all the command mode prompts, refer to the [Command Modes](#) section.

Multiple Configuration Users

When a user enters CONFIGURATION mode and another user is already in CONFIGURATION mode, the Dell operating system generates an alert warning message similar to the following:

```
Dell#conf

% Warning: The following users are currently configuring the system:

User "" on line console0
User "admin" on line vty0 ( 123.12.1.123 )
User "admin" on line vty1 ( 123.12.1.123 )
User "Irene" on line vty3 ( 123.12.1.321 )
Dell#conf
```

When another user enters CONFIGURATION mode, the Dell Networking OS sends a message similar to the following:

```
% Warning: User "admin" on line vty2 "172.16.1.210" is in configuration
```



In this case, the user is “admin” on vty2.

Navigating the CLI

The Dell Networking OS displays a CLI prompt comprised of the host name and CLI mode.

- Host name is the initial part of the prompt and is “Dell” by default. You can change the host name with the `hostname` command.
- CLI mode is the second part of the prompt and reflects the current CLI mode. For a list of the Dell Networking OS command modes, refer to the command mode list in the [Accessing the Command Line](#) section.

The CLI prompt changes as you move up and down the levels of the command structure. Starting with CONFIGURATION mode, the command prompt adds modifiers to further identify the mode. For more information about command modes, refer to the [Command Modes](#) section.

Prompt	CLI Command Mode
Dell>	EXEC
Dell#	EXEC Privilege
Dell(conf)#	CONFIGURATION
Dell(conf-if-te-0/0)#	INTERFACE
Dell(conf-if-vl-1)#	
Dell(conf-if-ma-0/0)#	
Dell(conf-if-range)#	
Dell(conf-line-console)#	LINE
Dell(conf-line-vty)#	
Dell(conf-mon-sess)#	MONITOR SESSION

Obtaining Help

As soon as you are in a command mode there are several ways to access help.

To obtain a list of keywords at any command mode: Type a `?` at the prompt or after a keyword. There must always be a space before the `?`.

To obtain a list of keywords with a brief functional description: Type `help` at the prompt.

To obtain a list of available options: Type a keyword and then type a space and a `?`.

To obtain a list of partial keywords using a partial keyword: Type a partial keyword and then type a `?`.



Example

The following is an example of typing `ip ?` at the prompt:

```
Dell (conf) #ip ?
igmp      Internet Group Management Protocol
route     Establish static routes
telnet    Specify telnet options
```

When entering commands, you can take advantage of the following timesaving features:

- The commands are not case-sensitive.
- You can enter partial (truncated) command keywords. For example, you can enter `int tengig int` for the `interface tengigabitethernet interface` command.
- To complete keywords in commands, use the TAB key.
- To display the last enabled command, use the up Arrow key.
- To erase the previous character, use either the Backspace key or Delete key.
- To navigate left or right in the Dell Networking OS command line, use the left and right Arrow keys.

The shortcut key combinations at the Dell Networking OS command line are as follows:

Key Combination Action

CNTL-A	Moves the cursor to the beginning of the command line.
CNTL-B	Moves the cursor back one character.
CNTL-D	Deletes the character at the cursor.
CNTL-E	Moves the cursor to the end of the line.
CNTL-F	Moves the cursor forward one character.
CNTL-I	Completes a keyword.
CNTL-K	Deletes all the characters from the cursor to the end of the command line.
CNTL-L	Re-enters the previous command.
CNTL-N	Returns to the more recent commands in the history buffer after recalling commands with Ctrl-P or the up Arrow key.
CNTL-P	Recalls commands, beginning with the last command.
CNTL-U	Deletes the line.
CNTL-W	Deletes the previous word.
CNTL-X	Deletes the line.
CNTL-Z	Comes back to EXEC mode from any CONFIGURATION mode.
Esc B	Moves the cursor back one word.
Esc F	Moves the cursor forward one word.
Esc D	Deletes all the characters from the cursor to the end of the word.



Using the Keyword no Command

To disable, delete or return to default values, use the `no` form of the commands.

For most commands, if you type the keyword `no` in front of the command, you disable that command or delete it from the running configuration. In this guide, the `no` form of the command is described in the Syntax portion of the command description. For example:

Syntax	<code>no {boot default enable ftp-server hardware hostname ip line logging monitor service io-aggregator broadcast storm-control snmp-server username}</code>	
Defaults	None	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Filtering show Commands

To find specific information, display certain information only or begin the command output at the first instance of a regular expression or phrase, you can filter the display output of a `show` command.

When you execute a `show` command, and then enter a pipe (`|`), one of the following parameters, and a regular expression, the resulting output either excludes or includes those parameters.

 **NOTE: The Dell Networking OS accepts a space before or after the pipe, no space before or after the pipe, or any combination. For example: `Dell#command | grep TenGig|except regular-expression | find regular-expression`.**

except	displays only the text that does not match the pattern (or regular expression)
find	searches for the first occurrence of a pattern
grep	displays text that matches a pattern.
no-more	does not paginate the display output
save	copies the output to a file for future use

The `grep` command option has an `ignore-case` sub-option that makes the search case-insensitive. For example, the commands:

- `show run | grep Ethernet` returns a search result with instances containing a capitalized “Ethernet,” such as interface `TenGigabitEthernet 0/1`.
- `show run | grep ethernet` does not return the search result above because it only searches for instances containing a non-capitalized “ethernet”.
- `show run | grep Ethernet ignore-case` returns instances containing both “Ethernet” and “ethernet”.

Displaying All Output

To display the output all at once (not one screen at a time), use the `no-more` option after the pipe. This operation is similar to the `terminal length screen-length` command except that the `no-more` option affects the output of just the specified command. For example:

```
Dell#show running-config|no-more
```

Filtering the Command Output Multiple Times

You can filter a single command output multiple times. To filter a command output multiple times, place the `save` option as the last filter. For example:

```
Dell# command | grep regular-expression | except regular-expression | grep other-regular-expression | find regular-expression | no-more | save
```

Command Modes

To navigate and launch various CLI modes, use specific commands. Navigation to these modes is described in the following sections.

EXEC Mode

When you initially log in to the switch, by default, you are logged in to EXEC mode. This mode allows you to view settings and enter EXEC Privilege mode, which is used to configure the device.

When you are in EXEC mode, the `>` prompt is displayed following the host name prompt, which is “Dell” by default. You can change the host name prompt using the `hostname` command.

 **NOTE: Each mode prompt is preceded by the host name.**

EXEC Privilege Mode

The `enable` command accesses EXEC Privilege mode. If an administrator has configured an “Enable” password, you are prompted to enter it.

EXEC Privilege mode allows you to access all the commands accessible in EXEC mode, plus other commands, such as to clear address resolution protocol (ARP) entries and IP addresses. In addition, you can access CONFIGURATION mode to configure interfaces, routes and protocols on the switch. While you are logged in to EXEC Privilege mode, the `#` prompt displays.

CONFIGURATION Mode

In EXEC Privilege mode, use the `configure` command to enter CONFIGURATION mode and configure routing protocols and access interfaces.

To enter CONFIGURATION mode:

1. Verify that you are logged in to EXEC Privilege mode.
2. Enter the `configure` command. The prompt changes to include (conf).

From this mode, you can enter INTERFACE mode by using the `interface` command.

INTERFACE Mode

To configure interfaces or IP services on those interfaces, use INTERFACE mode. An interface can be physical (for example, a TenGigabit Ethernet port) or virtual (for example, the VLAN interface).



To enter INTERFACE mode:

1. Verify that you are logged in to CONFIGURATION mode.
2. Enter the `interface` command and then enter an interface type and interface number that is available on the switch.

The prompt changes to include the designated interface and slot/port number. For example:

Prompt	Interface Type
Dell (conf-if-te-0/1) #	Ten-Gigabit Ethernet interface then slot/port information
Dell (conf-if-vl-1) #	VLAN Interface then VLAN number (range 1–4094)
Dell (conf-if-ma-0/1) #	Management Ethernet interface then slot/port information
Dell (conf-if-range) #	Designated interface range (used for bulk configuration)

LINE Mode

To configure the console or virtual terminal parameters, use LINE mode.

To enter LINE mode:

1. Verify that you are logged in to CONFIGURATION mode.
2. Enter the `line` command. Include the keywords `console` or `vty` and their line number available on the switch. The prompt changes to include `(config-line-console)` or `(config-line-vty)`.

You can exit this mode by using the `exit` command.

MONITOR SESSION Mode

In CONFIGURATION mode, use the `monitor session` command to enter MONITOR SESSION mode and configure port monitoring.

To enter MONITOR SESSION mode:

1. Verify that you are logged in to CONFIGURATION mode.
2. Use the `monitor session` command. Include the monitor session ID. The prompt changes to include `(conf-mon-sess)`.

You can return to CONFIGURATION mode by using the `exit` command.

PROTOCOL LLDP Mode

In CONFIGURATION mode, use the `protocol lldp` command to enter PROTOCOL LLDP mode and configure the LLDP protocol.

To enter PROTOCOL LLDP mode:

1. Verify that you are logged in to CONFIGURATION mode.
2. Enter the `protocol lldp` command. The prompt changes to include `Dell (config-lldp)`.

You can return to CONFIGURATION mode by using the `exit` command.



File Management

This chapter contains commands needed to manage the configuration files and includes other file management commands. The commands in this chapter are supported by the Dell Networking OS.

boot system gateway

Specify the IP address of the default next-hop gateway for the management subnet.

Syntax `boot system gateway ip-address`

Parameters `ip-address` Enter an IP address in dotted decimal format.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Saving the address to the startup configuration file preserves the address in NVRAM in case the startup configuration file is deleted.

boot system stack-unit

Specify the location of the Dell Networking OS image to be used to boot the system.

Syntax `boot system stack-unit <0-5 | all> {default | primary | secondary}`

Parameters	0-5	Enter the stack member unit identifier of the stack member.
	all	Enter the keyword <code>all</code> to set the primary, secondary, and default images for the system.
	default	Enter the keyword <code>default</code> to set the default image path for the system.
	primary	Enter the keyword <code>primary</code> to set the primary image path for the system.
	secondary	Enter the keyword <code>secondary</code> to set the secondary image path for the system.



Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.
	9.4(0.0)	Supported on the FN I/O aggregator.
Usage Information	The system first attempts to load the image from the primary path. If it fails to boot, the system tries to load the image from the secondary path and if that also fails, the system loads the default image.	

cd

Change to a different working directory.

Syntax `cd directory`

Parameters

directory (OPTIONAL) Enter one of the following:

- `flash`: (internal Flash) or any sub-directory
- `usbflash`: (external Flash) or any sub-directory

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

copy

Copy one file to another location. The Dell Networking OS supports IPv4 addressing for FTP, TFTP, and SCP (in the *hostip* field).

Syntax `copy source-file-url destination-file-url`

Parameters

file-url Enter the following location keywords and information:

- To copy a file from the internal FLASH, enter `flash://` then the filename.
- To copy the running configuration, enter the keywords `running-config`.
- To copy the startup configuration, enter the keywords `startup-config`.
- To copy a file on the external FLASH, enter `usbflash://` then the filename.

Command Modes EXEC Privilege



Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	The Dell Networking OS supports a maximum of 100 files, at the root directory level, on both the internal and external Flash.	

The `usbflash` commands are supported. For a list of approved USB vendors, refer to the *Dell Networking OS Release Notes*.

When copying a file to a remote location (for example, using Secure Copy [SCP]), enter only the keywords and Dell Networking OS prompts you for the rest of the information.

 **NOTE: Dell Networking OS imposes a length limit on the password you create for performing the secure copy operation. Your password can be no longer than 32 characters.**

For example, when using SCP, you can enter the `copy running-config scp:` command. The running-config is the source and the target is specified in the ensuing prompts. Dell Networking OS prompts you to enter any required information, as needed for the named destination — remote destination, destination filename, user ID and password, and so forth.

When you use the `copy running-config startup-config` command to copy the running configuration (the startup configuration file amended by any configuration changes made because the system was started) to the startup configuration file, Dell Networking OS creates a backup file on the internal flash of the startup configuration.

The Dell Networking OS supports copying the running-configuration to a TFTP server or to an FTP server:

- `copy running-config tftp:`
- `copy running-config ftp:`

 **NOTE: Dell Networking OS imposes a length limit on the password you create for accessing the FTP server. Your password can be no longer than 32 characters.**

In the `copy scp: flash:` example, specifying SCP in the first position indicates that the target to specify in the ensuing prompts. Entering `flash:` in the second position means that the target is the internal Flash. In this example, the source is on a secure server running SSH, so you are prompted for the UDP port of the SSH server on the remote host.

Example (running-config scp:)

```
Dell#copy running-config scp:
Address or name of remote host []: 10.10.10.1
Port number of the server [22]: 99
Destination file name [startup-config]: old_running
User name to login remote host: sburgess
Password to login remote host:

Password to login remote host? dilling
```

Example (copy scp:)

```
Dell#copy scp: flash:
Address or name of remote host []: 10.11.199.134
Port number of the server [22]: 99
Source file name []: test.cfg
User name to login remote host: admin
```



Password to login remote host:
Destination file name [test.cfg]: test1.cfg

Related Commands [cd](#) — Changes the working directory.

copy running-config startup-config

Copy running configuration to the startup configuration.

Syntax `copy running-config startup-config {duplicate}`

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information This command is useful for quickly making a change configuration on one chassis available on external flash to move it to another chassis.

delete

Delete a file from the flash. After deletion, files cannot be restored.

Syntax `delete flash: ([flash://]filepath) usbflash ([usbflash://]filepath)`

Parameters

flash-url	Enter the following location and keywords: • For a file or directory on the internal Flash, enter <code>flash://</code> then the filename or directory name. • For a file or directory on an external USB drive, enter <code>usbflash://</code> then the filename or directory name.
------------------	--

no-confirm	(OPTIONAL) Enter the keywords <code>no-confirm</code> to specify that the Dell Networking OS does not require user input for each file prior to deletion.
-------------------	---

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator



dir

Displays the files in a file system. The default is the current directory.

Syntax `dir [filename | directory name:]`

Parameters

- filename | directory name:** (OPTIONAL) Enter one of the following:
- For a file or directory on the internal Flash, enter `flash://` then the filename or directory name.
 - For a file or directory on an external USB drive, enter `usbflash://` then the filename or directory name.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#dir
Directory of flash:

 1  drwx  4096      Jan 01 1980 00:00:00 +00:00 .
 2  drwx  2048      Mar 06 2010 00:36:21 +00:00 ..
 3  drwx  4096      Feb 25 2010 23:32:50 +00:00 TRACE_LOG_DIR
 4  drwx  4096      Feb 25 2010 23:32:50 +00:00 CORE_DUMP_DIR
 5  d---  4096      Feb 25 2010 23:32:50 +00:00 ADMIN_DIR
 6  -rwx 720969768  Mar 05 2010 03:25:40 +00:00 6gb
 7  -rwx  4260      Mar 03 2010 22:04:50 +00:00 prem-23-5-12
 8  -rwx 31969685   Mar 05 2010 17:56:26 +00:00
DellS-XL-8-3-16-148.bin
 9  -rwx  3951      Mar 06 2010 00:36:18 +00:00 startup-config

flash: 2143281152 bytes total (1389801472 bytes free)
Dell#
```

Related Commands [cd](#) — Changes the working directory.

format flash

Erase all existing files and reformat the filesystem in the internal flash memory. After the filesystem is formatted, files cannot be restored.

Syntax `format {flash: | usbflash:}`

Defaults **flash memory**

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.



Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information You must include the colon (:) when entering this command.

 **CAUTION: This command deletes all files, including the startup configuration file. So, after executing this command, consider saving the running config as the startup config (use the `write memory` command or `copy run start` command).**

Related Commands

- [copy](#) – copies the current configuration to either the startup-configuration file or the terminal.
- [show file](#) – displays the contents of a text file in the local filesystem.
- [show file-systems](#) – displays information about the file systems on the system.

HTTP Copy via CLI

Copy one file to another location. Dell Networking OS supports IPv4 and IPv6 addressing for FTP, TFTP, and SCP (in the *hostip* field).

Syntax

```
copy http://10.16.206.77/sample_file flash://sample_filecopy flash://sample_file http://10.16.206.77/sample_file
```

You can copy from the server to the switch and vice-versa.

Parameters

copy http:	Address or name of remote host []: 10.16.206.77
flash:	Port number of the server [80]:
	Source file name []: sample_file
	User name to login remote host: x
	Password to login remote host:
	Destination file name [sample_file]:

Defaults None.

Command Modes EXEC

Supported Modes All Modes

Command History

Version	Description
---------	-------------

9.4(0.0)	Introduced on the FN I/O Aggregator.
----------	--------------------------------------

9.3(0.1)	Introduced on the M I/O Aggregator.
----------	-------------------------------------

Example

```
copy http://admin:admin123@10.16.206.77/sample_file flash://sample_file
```

Related Commands `copy ftp:flash`

Copy files from FTP server to switch

logging coredump stack-unit

Enable the coredump.

Syntax `logging coredump stack-unit all`

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The Kernel core dump can be large and may take up to five to 30 minutes to upload. The Dell Networking OS does not overwrite application core dumps so delete them as necessary to conserve space on the flash; if the flash is out of memory, the coredump is aborted. The Dell Networking OS completes the coredump process and waits until the upload is complete before rebooting the system.

pwd

Display the current working directory.

Syntax `pwd`

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example
Dell#pwd
flash:
Dell#

Related Commands [cd](#) – changes the directory.

rename

Rename a file in the local file system.

Syntax `rename url url`



Parameters	<i>url</i>	Enter the following keywords and a filename:
		- For a file on the internal Flash, enter <code>flash://</code> then the filename. - For a file on an external USB drive, enter <code>usbflash://</code> then the filename.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

restore factory-defaults

Restore factory defaults.

Syntax `restore factory-defaults stack-unit id {clear-all | nvram}`

Parameters	factory-defaults	Return the system to its factory default mode.
	<i>id</i>	Enter the stack member unit identifier to restore the mentioned stack-unit. The range is from 0 to 6. Enter the keyword <code>all</code> to restore all units in the stack.
	clear-all	Enter the keywords <code>clear-all</code> to reset the NvRAM and the system startup configuration.
	nvram	Enter the keyword <code>nvram</code> to reset the NvRAM only.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Restoring factory defaults deletes the existing startup configuration and all persistent settings (stacking, fanout, and so forth).

When restoring all units in a stack, all the units in the stack are placed into stand-alone mode.

When restoring a single unit in a stack, that unit placed in stand-alone mode. No other units in the stack are affected.

When restoring units in stand-alone mode, the units remain in stand-alone mode after the restoration. After the restore is complete, the units power cycle immediately.

 **CAUTION: There is no undo for this command.**

Example

```
Dell#restore factory-defaults stack-unit 0 clear-all
*****
* Warning - Restoring factory defaults will delete the existing *
* startup-config and all persistent settings (stacking, fanout, etc.)*
* After restoration the unit(s) will be powercycled immediately. *
* Proceed with caution ! *
*****
Proceed with factory settings? Confirm [yes/no]:yes
-- Restore status --
Unit Nvram      Config
-----
0      Success  Success
Power-cycling the unit(s).
Dell#
```

Example (NvRAM, all)

```
Dell#restore factory-defaults stack-unit all nvram
*****
* Warning - Restoring factory defaults will delete the existing *
* persistent settings (stacking, fanout, etc.) *
* All the units in the stack will be split into standalone units. *
* After restoration the unit(s) will be powercycled immediately. *
* Proceed with caution ! *
*****
Proceed with factory settings? Confirm [yes/no]:yes
-- Restore status --
Unit Nvram      Config
-----
0      Success
1      Success
2      Success
3      Not present
4      Not present
5      Not present
Power-cycling the unit(s).
Dell#
```

Example (NvRAM, single unit)

```
Dell#restore factory-defaults stack-unit 1 nvram
*****
* Warning - Restoring factory defaults will delete the existing *
* persistent settings (stacking, fanout, etc.) *
* After restoration the unit(s) will be powercycled immediately. *
* Proceed with caution ! *
*****
Proceed with factory settings? Confirm [yes/no]:yes
-- Restore status --
Unit Nvram      Config
-----
1      Success
Power-cycling the unit(s).
Dell#
```

show boot system

Displays information about boot images currently configured on the system.

Syntax show boot system stack-unit {0-5 | all}

Parameters

0-5	Enter this information to display the boot image information of only the entered stack-unit.
------------	--



all Enter the keyword `all` to display the boot image information of all the stack-units in the stack.

Defaults none

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show boot system stack-unit all
Current system image information in the system:
=====
Type      Boot Type      A      B
-----
Stack-unit 0 is not present.
Stack-unit 1 DOWNLOAD BOOT 9-1-0-218      9-1-0-202
Stack-unit 2 is not present.
Stack-unit 3 is not present.
Stack-unit 4 is not present.
Stack-unit 5 is not present.
```

show file

Displays contents of a text file in the local filesystem.

Syntax `show file url`

Parameters

url Enter one of the following:

- For a file on the internal Flash, enter `flash://` then the filename.
- For a file on the external Flash, enter `usbflash://` then the filename.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show file flash://startup-config
! Version E8-3-17-38
boot system stack-unit 1 primary tftp://10.11.9.21/dv-m1000e-2-b2
boot system stack-unit 1 default system: A:
boot system gateway 10.11.209.62
!
```



```
hostname FTOS
--More--
Dell#
```

Related Commands [format flash](#) — erases all the existing files and reformats the filesystem in the internal flash memory.

[show file-systems](#) — displays information about the file systems on the system.

show file-systems

Displays information about the file systems on the system.

Syntax `show file-systems`

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show file-systems
Size(b)      Free(b)      Feature  Type      Flags  Prefixes
2143281152   836874240   FAT32    USERFLASH rw      flash:
-            -            -        network  rw      ftp:
-            -            -        network  rw      tftp:
-            -            -        network  rw      scp:
Dell#
```

Command Fields

Field	Description
size(b)	Lists the size in bytes of the storage location. If the location is remote, no size is listed.
Free(b)	Lists the available size in bytes of the storage location. If the location is remote, no size is listed.
Feature	Displays the formatted DOS version of the device.
Type	Displays the type of storage. If the location is remote, the word <code>network</code> is listed.
Flags	Displays the access available to the storage location. The following letters indicate the level of access: • <code>r</code> = read access • <code>w</code> = write access
Prefixes	Displays the name of the storage location.

Related Commands [format flash](#) — erases all the existing files and reformats the filesystem in the internal flash memory.

[show file](#) — displays the contents of a text file in the local filesystem.



show os-version

Displays the release and software image version information of the image file specified.

Syntax `show os-version [file-url]`

Parameters

file-url (OPTIONAL) Enter the following location keywords and information:

- For a file on the internal Flash, enter `flash://` then the filename.
- For a file on an FTP server, enter `ftp://user:password@hostip/filepath`.
- For a file on a TFTP server, enter `tftp://hostip/filepath`.
- For a file on the external Flash, enter `usbflash://filepath` then the filename.

Defaults none

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information  **NOTE: A filepath that contains a dot (.) is not supported.**

Example

```
Dell#show os-version

RELEASE IMAGE INFORMATION :
-----
Platform      Version      Size      ReleaseTime
IOM-Series: XL  8-3-17-38   31603078   Jul 19 2012 06:02:28

TARGET IMAGE INFORMATION :
-----
Type      Version      Target      checksum
runtime   8-3-17-38     Control Processor  passed

CPLD IMAGE INFORMATION :
-----
Card      CPLD Name      Version
Stack-unit 1  IOM SYSTEM CPLD      6
Dell#
```

show running-config

Displays the current configuration and display changes from the default values.

Syntax `show running-config [entity] [configured] [status]`

Parameters

entity (OPTIONAL) To display that entity's current (non-default) configuration, enter one of the following keywords:



NOTE: If you did not configure anything for that entity, nothing displays and the prompt returns.

boot	for the current boot configuration
ftp	for the current FTP configuration
igmp	for the current IGMP configuration
interface	for the current interface configuration
line	for the current line configuration
lldp	for the current lldp configuration
logging	for the current logging configuration
management- route	for the current Management port forwarding configuration
monitor	for the current Monitor configuration
snmp	for the current SNMP configuration
uplink-state- group	for the uplink state group configuration
users	for the current users configuration

configured (OPTIONAL) Enter the keyword `configured` to display line card interfaces with non-default configurations only.

status (OPTIONAL) Enter the keyword `status` to display the checksum for the running configuration and the start-up configuration.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show running-config
Current Configuration ...
! Version 9-4(0-180)
!
boot system stack-unit 0 primary tftp://10.11.8.12/dv-ci-stomp-tc-1-a1
!
redundancy auto-synchronize full
!
hostname Dell
...
```

Example

```
Dell#show running-config status

running-config bytes 5063, checksum 0xF6F801AC
startup-config bytes 4835, checksum 0x764D3787
Dell#
```



Usage Information The `status` option allows you to display the size and checksum of the running configuration and the startup configuration.

show version

Displays the current Dell Networking OS version information on the system.

Syntax `show version`

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show version
Dell Force10 Real Time Operating System Software
Dell Force10 Operating System Version: 1.0
Dell Force10 Application Software Version: E8-3-17-38
Copyright (c) 1999-2012 by Dell Inc. All Rights Reserved.
Build Time: Thu Jul 19 05:59:59 PDT 2012
Build Path: /sites/sjc/work/swsystems01-2/ravisubramani/ravis-8317/SW/SRC/
Cp_src/Tacacs
FTOS uptime is 4 day(s), 4 hour(s), 3 minute(s)
System image file is "dv-m1000e-2-b2" System Type: I/O-Aggregator
Control Processor: MIPS RMI XLP with 2147483648 bytes of memory.

256M bytes of boot flash memory.

1 34-port GE/TE (XL)
56 Ten GigabitEthernet/IEEE 802.3 interface(s)
```

Command Fields	Lines Beginning With	Description
	Dell Force10 Network...	Name of the operating system
	Dell Force10 Operating...	OS version number
	Dell Force10 Application...	Software version
	Copyright (c)...	Copyright information
	Build Time...	Software build's date stamp
	Build Path...	Location of the software build files loaded on the system
	Dell Force10 uptime is...	Amount of time the system has been up
	System image...	Image file name
	Chassis Type:	System type (M I/O Aggregator)



Lines Beginning With	Description
Control Processor:...	Control processor information and amount of memory on processor
256M bytes...	Amount of boot flash memory on the system
134 Port	Hardware configuration of the system, including the number and type of physical interfaces available

upgrade boot

Upgrade the bootflash image or bootselector image.

Syntax upgrade boot {all | bootflash-image | bootselector-image} stack-unit {0-5 | all} {booted | flash: | ftp: | tftp: | usbflash:} (A: | B:)

Parameters	all	Enter the keyword <code>all</code> to change both the bootflash and bootselector images.
	bootflash-image	Enter the keywords <code>bootflash-image</code> to change the bootflash image.
	bootselector-image	Enter the keywords <code>bootselector-image</code> to change the bootselector image.
	0-5	Enter the keyword <code>0-5</code> to upgrade only the mentioned stack-unit.
	all	Enter the keyword <code>all</code> to upgrade all the member stack-units.
	booted	Enter the keyword <code>booted</code> to upgrade from the current image in the M I/O Aggregator.
	ftp:	After entering the keyword <code>ftp:</code> , you can either follow it with the location of the source file in this form: <code>//userid:password@hostip/filepath</code> or press Enter to launch a prompt sequence.
	tftp:	After entering the keyword <code>tftp:</code> , you can either follow it with the location of the source file in this form: <code>//hostlocation/filepath</code> or press Enter to launch a prompt sequence.
	flash:	After entering the keyword <code>flash:</code> , you can either follow it with the location of the source file in this form: <code>//filepath</code> or press Enter to launch a prompt sequence.
	usbflash:	After entering the keyword <code>usbflash:</code> , you can either follow it with the location of the source file in this form: <code>//filepath</code> or press Enter to launch a prompt sequence.
	A:	Enter this keyword to upgrade the bootflash partition A.
	B:	Enter this keyword to upgrade the bootflash partition B.

Defaults	none
Command Modes	EXEC Privilege
Supported Modes	All Modes



Command History	<table><thead><tr><th>Version</th><th>Description</th></tr></thead><tbody><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>8.3.17.0</td><td>Supported on the M I/O Aggregator.</td></tr></tbody></table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	8.3.17.0	Supported on the M I/O Aggregator.
Version	Description						
9.4(0.0)	Supported on the FN I/O Aggregator.						
8.3.17.0	Supported on the M I/O Aggregator.						
Usage Information	You must reload the Dell Networking OS after executing this command.						
Example	<pre>Dell#upgrade boot ? all Upgrade both boot flash image and selector image bootflash-image Upgrade boot flash image bootselector-image Upgrade boot selector image Dell#</pre>						

upgrade system

Upgrade the bootflash image or system image.

Syntax	upgrade system {flash: ftp: scp: tftp: usbflash: stack-unit {0-5 all} {A: B:}}																		
Parameters	<table><tbody><tr><td>0-5</td><td>Enter the keyword 0-5 to upgrade only the mentioned stack-unit.</td></tr><tr><td>all</td><td>Enter the keyword all to upgrade all the member units of the stack.</td></tr><tr><td>ftp</td><td>After entering the keyword ftp you can either follow it with the location of the source file in this form://userid:password@hostip/filepath, or press Enter to launch a prompt sequence.</td></tr><tr><td>scp</td><td>After entering the keyword scp you can either follow it with the location of the source file in this form://userid:password@hostip/filepath, or press Enter to launch a prompt sequence.</td></tr><tr><td>tftp</td><td>After entering the keyword tftp you can either follow it with the location of the source file in this form://hostlocation/filepath, or press Enter to launch a prompt sequence.</td></tr><tr><td>flash</td><td>After entering the keyword flash you can either follow it with the location of the source file in this form://filepath, or press Enter to launch a prompt sequence.</td></tr><tr><td>usbflash</td><td>After entering the keyword usbflash you can either follow it with the location of the source file in this form://filepath, or press Enter to launch a prompt sequence.</td></tr><tr><td>A:</td><td>Enter this keyword to upgrade the bootflash partition A.</td></tr><tr><td>B:</td><td>Enter this keyword to upgrade the bootflash partition B.</td></tr></tbody></table>	0-5	Enter the keyword 0-5 to upgrade only the mentioned stack-unit.	all	Enter the keyword all to upgrade all the member units of the stack.	ftp	After entering the keyword ftp you can either follow it with the location of the source file in this form://userid:password@hostip/filepath, or press Enter to launch a prompt sequence.	scp	After entering the keyword scp you can either follow it with the location of the source file in this form://userid:password@hostip/filepath, or press Enter to launch a prompt sequence.	tftp	After entering the keyword tftp you can either follow it with the location of the source file in this form://hostlocation/filepath, or press Enter to launch a prompt sequence.	flash	After entering the keyword flash you can either follow it with the location of the source file in this form://filepath, or press Enter to launch a prompt sequence.	usbflash	After entering the keyword usbflash you can either follow it with the location of the source file in this form://filepath, or press Enter to launch a prompt sequence.	A:	Enter this keyword to upgrade the bootflash partition A.	B:	Enter this keyword to upgrade the bootflash partition B.
0-5	Enter the keyword 0-5 to upgrade only the mentioned stack-unit.																		
all	Enter the keyword all to upgrade all the member units of the stack.																		
ftp	After entering the keyword ftp you can either follow it with the location of the source file in this form://userid:password@hostip/filepath, or press Enter to launch a prompt sequence.																		
scp	After entering the keyword scp you can either follow it with the location of the source file in this form://userid:password@hostip/filepath, or press Enter to launch a prompt sequence.																		
tftp	After entering the keyword tftp you can either follow it with the location of the source file in this form://hostlocation/filepath, or press Enter to launch a prompt sequence.																		
flash	After entering the keyword flash you can either follow it with the location of the source file in this form://filepath, or press Enter to launch a prompt sequence.																		
usbflash	After entering the keyword usbflash you can either follow it with the location of the source file in this form://filepath, or press Enter to launch a prompt sequence.																		
A:	Enter this keyword to upgrade the bootflash partition A.																		
B:	Enter this keyword to upgrade the bootflash partition B.																		
Defaults	none																		
Command Modes	EXEC Privilege																		
Supported Modes	All Modes																		



Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

You must reload Dell Networking OS after executing this command. Use the command `upgrade system stack-unit` to copy Dell Networking OS from the management unit to one or more stack members.

Example

```
Dell#upgrade system ?
flash:          Copy from flash file system (flash://filepath)
ftp:            Copy from remote file system, IPv4 or IPv6, (ftp:/
/userid:password@hostip/filepath)
scp:            Copy from remote file system, IPv4 or IPv6, (scp:/
/userid:password@hostip/filepath)
stack-unit Sync image to the stack-unit
tftp:           Copy from remote file system, IPv4 or IPv6, (tftp:/
/hostip/filepath)
usbflash:       Copy from usbflash file system (usbflash://
filepath)
Dell#
```



Control and Monitoring

This chapter describes control and monitoring for the I/O Aggregator.

asset-tag

Assign and store a unique asset-tag to the stack member.

Syntax	<code>asset-tag stack-unit unit id Asset-tag ID</code>	
	To remove the asset tag, use the <code>no stack-unit unit-id Asset-tag ID</code> command.	
Parameters	stack-unit unit-id	Enter the keywords <code>stack-unit</code> then the <code>unit-id</code> to assign a tag to the specific member. The range is from 0 to 5.
	Asset-tag ID	Enter a unique asset-tag ID to assign to the stack member. This option accepts a maximum of 10 characters, including all special characters except double quotes. To include a space in the asset-tag, enter a space within double quotes.
Defaults	No asset-tag is assigned.	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
Related Commands	show system — Displays the current status of all stack members or a specific member.	

clear alarms

Clear the alarms on the system.

Syntax	<code>clear alarms</code>	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information This command clears alarms that are no longer active. If an alarm situation is still active, it is seen in the system output.

clear command history

Clear the command history log.

Syntax `clear command history`

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Related Commands [show command-history](#)— displays a buffered log of all the commands all users enter along with a time stamp.

configure

Enter CONFIGURATION mode from EXEC Privilege mode.

Syntax `configure [terminal]`

Parameters

terminal	(OPTIONAL) Enter the keyword <code>terminal</code> to specify that you are configuring from the terminal.
-----------------	---

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#configure
Dell (conf) #
```



debug cpu-traffic-stats

Enable the collection of computer processor unit (CPU) traffic statistics.

Syntax `debug cpu-traffic-stats`

Defaults Disabled

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information This command enables (and disables) the collection of CPU traffic statistics from the time this command is executed (not from system boot). However, excessive traffic a CPU receives automatically triggers (turn on) the collection of CPU traffic statics.

To view the traffic statistics, use the `show cpu-traffic-stats` command.

If the CPU receives excessive traffic, traffic is rate controlled.

 **NOTE:** You must enable this command before the `show cpu-traffic-stats` command displays traffic statistics. Dell Networking recommends disabling debugging (`no debug cpu-traffic-stats`) after troubleshooting is complete.

Related Commands [show cpu-traffic-stats](#)— displays the cpu traffic statistics.

debug ifm trace-flags

Turn on the IFM internal trace-flags.

Syntax `debug ifm trace-flags trace-flags`
To disable this command, use the `no debug ifm trace-flags` command.

Parameters

<i>trace-flags</i>	Enter a hexadecimal number representing the trace-flag.
---------------------------	---

Defaults None

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

 **NOTE:** Use this command only when you are working directly with a technical support representative to troubleshoot a problem. Do not use this command unless a technical support representative instructs you to do so.

disable

Return to EXEC mode.

Syntax `disable [level]`

Parameters *level* (OPTIONAL) Enter a number for a privilege level of the Dell Networking OS. The range is from 0 to 15. The default is **1**.

Defaults **1**

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

enable

Enter EXEC Privilege mode or any other privilege level configured. After entering this command, you may need to enter a password.

Syntax `enable [level]`

Parameters *level* (OPTIONAL) Enter a number for a privilege level of the Dell Networking OS. The range is from 0 to 15. The default is **15**.

Defaults **15**

Command Modes EXEC

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Users entering EXEC Privilege mode or any other configured privilege level can access configuration commands. To protect against unauthorized access, use the `enable password` command to configure a password for the `enable` command at a specific privilege level. If no privilege level is specified, the default is privilege level **15**.

Related Commands [enable password](#)— configures a password for the `enable` command and to access a privilege level.



end

Return to EXEC Privilege mode from other command modes (for example, CONFIGURATION mode).

Syntax `end`

Command Modes

- CONFIGURATION
- LINE
- INTERFACE
- MONITOR SESSION
- PROTOCOL LLDP

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Related Commands [exit](#)— returns to the lower command mode.

exit

Return to the lower command mode.

Syntax `exit`

Command Modes

- EXEC Privilege
- CONFIGURATION
- LINE
- INTERFACE
- PROTOCOL LLDP

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Related Commands [end](#) — returns to EXEC Privilege mode.

ftp-server enable

Enable FTP server functions on the system.

Syntax `ftp-server enable`



Defaults	Disabled	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
morpheus% ftp 10.31.1.111
Connected to 10.31.1.111.
220 FTOS (1.0) FTP server ready
Name (10.31.1.111:dch): dch
331 Password required
Password:
230 User logged in
ftp> pwd
257 Current directory is "flash:"
ftp> dir
200 Port set okay
150 Opening ASCII mode data connection
size  date          time name
-----
 512  Jul-20-2004   18:15:00 tgting
 512  Jul-20-2004   18:15:00 diagnostic
 512  Jul-20-2004   18:15:00 other
 512  Jul-20-2004   18:15:00 tgt
226 Transfer complete
329 bytes received in 0.018 seconds (17.95 Kbytes/s)
ftp>
```

Related Commands

[ftp-server topdir](#)— sets the directory to be used for incoming FTP connections.

[ftp-server username](#)— sets a username and password for incoming FTP connections.

ftp-server topdir

Specify the top-level directory to be accessed when an incoming FTP connection request is made.

Syntax	<code>ftp-server topdir <i>directory</i></code>	
Parameters	<i>directory</i>	Enter the directory path.
Defaults	The internal flash is the default directory.	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.



Usage Information	After you enable FTP server functions with the <code>ftp-server enable</code> command, Dell Networking recommends specifying a top-level directory path. Without a top-level directory path specified, the Dell Networking OS directs users to the flash directory when logging in to the FTP server.
Related Commands	ftp-server enable — enables FTP server functions on the M I/O Aggregator. ftp-server username — sets a username and password for incoming FTP connections to the M I/O Aggregator.

ftp-server username

Create a user name and associated password for incoming FTP server sessions.

Syntax	<code>ftp-server username <i>username</i> password [<i>encryption-type</i>] <i>password</i></code>	
Parameters	<i>username</i>	Enter a text string up to 40 characters long as the user name.
	<i>password password</i>	Enter the keyword <code>password</code> then a string up to 40 characters long as the password. Without specifying an encryption type, the password is unencrypted.
	<i>encryption-type</i>	(OPTIONAL) After the keyword <code>password</code> , enter one of the following numbers: 0 (zero) for an unencrypted (clear text) password 7 (seven) for a hidden text password
Defaults	Not enabled.	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

hostname

Set the host name of the system.

Syntax	<code>hostname <i>name</i></code>	
Parameters	<i>name</i>	Enter a text string, up to 32 characters long.
Defaults	Dell Networking Operating System (OS)	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	The hostname is used in the prompt.	

ip telnet server enable

Enable the Telnet server on the switch.

Syntax	<code>ip telnet server enable</code>
	To disable the Telnet server, use the <code>no ip telnet server enable</code> command.

Defaults	Enabled
Command Modes	CONFIGURATION
Supported Modes	All Modes
Command History	

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

ip telnet source-interface

Set an interface's IP address as the source address in outgoing packets for Telnet sessions.

Syntax	<code>ip telnet source-interface <i>interface</i></code>
--------	--

Parameters	<i>interface</i>	Enter the following keyword and slot/port or number information:
		- For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information. - For VLAN interface, enter the keyword <code>vlan</code> then a number from 1 to 4094.

Defaults	The IP address on the system that is closest to the Telnet address is used in the outgoing packets.	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History		

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.



Related Commands [telnet](#) — telnets to another device.

line

Enable and configure console and virtual terminal lines to the system. This command accesses LINE mode, where you can set the access conditions for the designated line.

Syntax `line {console 0 | vty number [end-number]}`

Parameters

console 0	Enter the keyword <code>console 0</code> to configure the console port. The console option is <0-0>.
vtty number	Enter the keyword <code>vtty</code> followed by a number from 0 to 9 to configure a virtual terminal line for Telnet sessions. The system supports 10 Telnet sessions.
end-number	(OPTIONAL) Enter a number from 1 to 9 as the last virtual terminal line to configure. You can configure multiple lines at one time.

Defaults Not configured

Command Modes CONFIGURATION

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information You cannot delete a terminal connection.

Related Commands [show memory](#) — View current memory usage on the M I/O Aggregator.

ping

Test connectivity between the system and another device by sending echo requests and waiting for replies.

Syntax `ping [host | ip-address] [count {number | continuous}] [datagram-size]
[timeout] [source (ip src-ipv4-address) | interface] [tos] [df-bit (y|n)]
[validate-reply(y|n)] [pattern pattern] [sweep-min-size] [sweep-max-size]
[sweep-interval] [ointerface (ip src-ipv4-address) | interface]`

Parameters

host	(OPTIONAL) Enter the host name of the devices to which you are testing connectivity.
-------------	--



<i>ip-address</i>	(OPTIONAL) Enter the IPv4 address of the device to which you are testing connectivity. The address must be in the dotted decimal format.
<i>count</i>	Enter the number of echo packets to be sent. The default is 5 . - number: from 1 to 2147483647 - continuous: transmit echo request continuously
<i>datagram size</i>	Enter the ICMP datagram size. The range is from 36 to 15360 bytes. The default is 100 .
<i>timeout</i>	Enter the interval to wait for an echo reply before timing out. The range is from 0 to 3600 seconds. The default is 2 seconds .
<i>source</i>	Enter the IPv4 source ip address or the source interface. Enter the IP address in A.B.C.D format. - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. - For a VLAN interface, enter the keyword <code>vlan</code> then a number from 1 to 4094.
<i>tos</i>	Enter the type of service required. The range is from 0 to 255. The default is 0 .
<i>df-bit</i>	Enter Y or N for the "don't fragment" bit in IPv4 header. - N: Do not set the "don't fragment" bit. - Y: Do set "don't fragment" bit The default is No.
<i>validate-reply</i>	Enter Y or N for reply validation. - N: Do not validate reply data. - Y: Do validate reply data. The default is No.
<i>pattern pattern</i>	Enter the IPv4 data pattern. The range is from 0 to FFFF. The default is 0xABCD .
<i>sweep-min-size</i>	Enter the minimum size of datagram in sweep range. The range is from 52 to 15359 bytes.
<i>sweep-max-size</i>	Enter the maximum size of datagram in sweep range. The range is from 53 to 15359 bytes.
<i>sweep-interval</i>	Enter the incremental value for sweep size. The range is from 1 to 15308 seconds.
<i>ointerface</i>	Enter the outgoing interface for multicast packets. Enter the IP address in A.B.C.D format. - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. - For a VLAN interface, enter the keyword <code>vlan</code> then a number from 1 to 4094.

Defaults

See parameters above.

Command Modes

- EXEC
- EXEC Privilege



Supported Modes	All Modes	
Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	When you enter the <code>ping</code> command without specifying an IP address (Extended Ping), you are prompted for a target IP address, a repeat count, a datagram size (up to 1500 bytes), a timeout (in seconds), and for Extended Commands. For information on the ICMP message codes that return from a <code>ping</code> command, refer to Internet Control Message Protocol (ICMP) Message Types .	
Example (IPv4)	<pre> Dell#ping 172.31.1.255 Type Ctrl-C to abort. Sending 5, 100-byte ICMP Echos to 172.31.1.255, timeout is 2 seconds: Reply to request 1 from 172.31.1.208 0 ms Reply to request 1 from 172.31.1.216 0 ms Reply to request 1 from 172.31.1.205 16 ms :: Reply to request 5 from 172.31.1.209 0 ms Reply to request 5 from 172.31.1.66 0 ms Reply to request 5 from 172.31.1.87 0 ms Dell# </pre>	

reload

Reboot the Dell Networking OS.

Syntax	<code>reload</code>	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	If there is a change in the configuration, the Dell Networking OS prompts you to save the new configuration. Or you can save your running configuration with the <code>copy running-config</code> command.	
Related Commands	reset stack-unit — resets any designated stack member except the management unit.	

service timestamps

Add time stamps to debug and log messages. This command adds either the uptime or the current time and date.

Syntax	<code>service timestamps [debug log] [datetime [localtime] [msec] [show-timezone] uptime]</code>	
Parameters	<code>debug</code>	(OPTIONAL) Enter the keyword <code>debug</code> to add timestamps to debug messages.



log	(OPTIONAL) Enter the keyword <code>log</code> to add timestamps to log messages with severity from 0 to 6.
datetime	(OPTIONAL) Enter the keyword <code>datetime</code> to have the current time and date added to the message.
localtime	(OPTIONAL) Enter the keyword <code>localtime</code> to include the localtime in the timestamp.
msec	(OPTIONAL) Enter the keyword <code>msec</code> to include milliseconds in the timestamp.
show-timezone	(OPTIONAL) Enter the keyword <code>show-timezone</code> to include the time zone information in the timestamp.
uptime	(OPTIONAL) Enter the keyword <code>uptime</code> to have the timestamp based on time elapsed since system reboot.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information If you do not specify parameters and enter `service timestamps`, it appears as `service timestamps debug uptime` in the running-configuration.

To view the current options set for the `service timestamps` command, use the `show running-config` command.

show alarms

Display the active major and minor alarms on the system.

Syntax `show alarms`

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell# show alarms

-- Minor Alarms --
Alarm Type                Duration
-----
No minor alarms
```



```
-- Major Alarms --
Alarm Type          Duration
-----
No major alarms

Dell#
```

show command-history

Display a buffered log of all commands all users enter along with a time stamp.

Syntax show command-history

Defaults None

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	<table border="0"> <tr> <th style="text-align: left;">Version</th> <th style="text-align: left;">Description</th> </tr> <tr> <td>9.4(0.0)</td> <td>Supported on the FN I/O Aggregator.</td> </tr> <tr> <td>8.3.17.0</td> <td>Supported on the M I/O Aggregator.</td> </tr> </table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	8.3.17.0	Supported on the M I/O Aggregator.
Version	Description						
9.4(0.0)	Supported on the FN I/O Aggregator.						
8.3.17.0	Supported on the M I/O Aggregator.						

Usage Information One trace log message is generated for each command. No password information is saved to this file.

Example

```
Dell#show command-history
[4/20 10:27:23]: CMD-(CLI):[enable]by default from console
[4/20 10:27:23]: CMD-(CLI):[configure terminal]by default from console
- Repeated 1 time.
[4/20 10:27:23]: CMD-(CLI):[snmp-server community public ro]by default from console
[4/20 10:27:23]: CMD-(CLI):[logging 172.16.1.162]by default from console
[4/20 10:27:23]: CMD-(CLI):[logging 10.10.10.4]by default from console
[4/20 10:27:24]: CMD-(CLI):[logging 10.1.2.4]by default from console
[4/20 10:27:24]: CMD-(CLI):[logging 172.31.1.4]by default from console
[4/20 10:27:24]: CMD-(CLI):[logging 133.33.33.4]by default from console
[4/20 10:27:24]: CMD-(CLI):[management route 172.16.1.0 /24 10.11.209.4]by default from console
[4/20 10:27:24]: CMD-(CLI):[service timestamps log datetime]by default from console
[4/20 10:27:24]: CMD-(CLI):[line console 0]by default from console
[4/20 10:27:24]: CMD-(CLI):[exec-timeout 0]by default from console
[4/20 10:27:24]: CMD-(CLI):[exit]by default from console
[4/20 10:27:29]: CMD-(CLI):[show version]by default from console
[4/20 10:27:56]: CMD-(CLI):[show interfaces tengigabitethernet 0/3]by default from console
[4/20 10:55:8]: CMD-(CLI):[show lldp neighbors]by default from console
[4/20 15:17:6]: CMD-(CLI):[show cam-acl]by default from console
[4/20 16:34:59]: CMD-(CLI):[show running-config interface tengigabitethernet 0/55]by default from console
[4/20 16:38:14]: CMD-(CLI):[show vlan]by default from console
[5/4 9:11:52]: CMD-(TEL0):[show version]by admin from vty0 (10.11.68.14)
[5/4 9:12:9]: CMD-(TEL0):[show hosts]by admin from vty0 (10.11.68.14)
[5/4 9:14:38]: CMD-(TEL0):[show arp]by admin from vty0 (10.11.68.14)
[5/4 9:19:29]: CMD-(TEL0):[enable]by admin from vty0 (10.11.68.14)
```



```
[5/4 9:19:35]: CMD-(TEL0):[configure]by admin from vty0 (10.11.68.14)
- Repeated 1 time.
[5/4 9:19:50]: CMD-(TEL0):[interface tengigabitethernet 0/16]by admin from
vtty0
(10.11.68.14)
[5/4 9:20:11]: CMD-(TEL0):[exit]by admin from vty0 (10.11.68.14)
Dell#
```

Related Commands [clear command history](#) — clears the command history log.

show configuration lock

Display the configuration lock status.

Syntax `show configuration lock`

Defaults None

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The type may be auto, manual, or rollback. When set to auto, Dell Networking OS automatically denies access to CONFIGURATION mode to all other users every time the user on the listed VTY line enters CONFIGURATION mode. When set to manual, the user on the listed VTY line must explicitly set the lock each time before entering CONFIGURATION mode. Rollback indicates that Dell Networking OS is in a rollback process. The line number shown in the output can be used to send the messages to that session or release a lock on a VTY line.

Example

```
Dell#show configuration lock
Configure exclusively locked by the following line:
Line           : vty 0
Line number    : 2
User           : admin
Type           : AUTO
State          : LOCKED
Ip address     : 10.11.9.97
Dell#
```

show cpu-traffic-stats

Display the CPU traffic statistics.

Syntax `show cpu-traffic-stats [port number | all]`

Parameters

<i>port number</i>	(OPTIONAL) Enter the port number to display traffic statistics on that port only. The range is from 1 to 1568.
--------------------	--



all (OPTIONAL) Enter the keyword **all** to display traffic statistics on all the interfaces receiving traffic, sorted based on the traffic.

Defaults **all**

Command Modes EXEC

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Traffic statistics are sorted on a per-interface basis; the interface receiving the most traffic is displayed first. All CPU and port information is displayed unless a specific port or CPU is specified. Traffic information is displayed for router ports only; not for management interfaces. The traffic statistics are collected only after the `debug cpu-traffic-stats` command is executed; not from the system bootup.

 **NOTE: After debugging is complete, use the `no debug cpu-traffic-stats` command to shut off traffic statistics collection.**

Example

```
Dell#show cpu-traffic-stats
Processor : CP
-----
Received 100% traffic on TenGigabitEthernet 8/2 Total packets:100
  LLC:0, SNAP:0, IP:100, ARP:0, other:0
  Unicast:100, Multicast:0, Broadcast:0
Dell#
```

Related Commands [debug cpu-traffic-stats](#) — enables CPU traffic statistics for debugging.

show debugging

View a list of all enabled debugging processes.

Syntax `show debugging`

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show debug
Generic IP: (Access List: test)
  IP packet debugging is on for (Access List: test)
    TenGigabitEthernet 0/16
  ICMP packet debugging is on for
    TenGigabitEthernet 0/16
OSPF:1
  OSPF packet debugging is on
DHCP:
```

```
DHCP debugging is on
Dell#
```

show diag

Display the diagnostics information.

Syntax `show diag {information | stack-unit number [detail | summary]] | testcase}`

Parameters

information	Enter the keyword <code>information</code> to view current diagnostics information in the system.
stack-unit <i>unit-id</i>	(OPTIONAL) Enter the keywords <code>stack-unit</code> then the <i>unit-id</i> to display information on a specific stack member. The range is from 0 to 5.
detail	(OPTIONAL) Enter the keyword <code>detail</code> to view detailed diagnostics information.
summary	(OPTIONAL) Enter the keyword <code>summary</code> to view a summary of the diagnostics information.
testcase	Enter the keyword <code>testcase</code> to view current diagnostics testcases available in the system.

Defaults Summary

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

show environment

Displays the system component status (for example, temperature or voltage).

Syntax `show environment [all | stack-unit unit-id]`

Parameters

all	Enter the keyword <code>all</code> to view all components.
stack-unit <i>unit-id</i>	Enter the keywords <code>stack-unit</code> then the <i>unit-id</i> to display information on a specific stack member. The range is from 0 to 5.
thermal sensor	Enter the keywords <code>thermal-sensor</code> to view all components.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes



Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example (all)

```
Dell#show environment all

-- Unit Environment Status --
Unit  Status  Temp  Voltage  TempStatus
-----
* 1  online   66C   ok       2
* Management Unit
-- Thermal Sensor Readings (deg C) --
Unit Sensor0 Sensor1 Sensor2 Sensor3 Sensor4 Sensor5 Sensor6 Sensor7
Sensor8 Sensor9
-----
1      51      51      63      61      61      61      67      61
64     66
Dell#
```

Example (stack-unit)

```
Dell#show environment stack-unit

-- Unit Environment Status --
Unit  Status      Temp  Voltage      TempStatus
-----
* 1  online        66C   ok           2
* Management Unit
Dell#
```

Example (thermal-sensor)

```
Dell#show environment thermal-sensor

-- Thermal Sensor Readings (deg C) --
Unit Sensor0 Sensor1 Sensor2 Sensor3 Sensor4 Sensor5 Sensor6 Sensor7
Sensor8 Sensor9
-----
1      51      51      64      61      61      61      67      61
64     66
Dell#
```

show inventory

Displays the switch type, components (including media), and Dell Networking OS version including hardware identification numbers and configured protocols.

Syntax `show inventory [media slot] [[optional-module]]`

Parameters

media slot	(OPTIONAL) Enter the keyword <code>media</code> then the stack ID of the stack member you want to display.
optional-module	(OPTIONAL) Enter the keyword <code>optional-module</code> to display optional module information.

Defaults `none`

Command Modes `EXEC`



Supported Modes All Modes

Command History

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information If there are no fiber ports in the unit, just the header under `show inventory media` displays. If there are fiber ports b
"Media not present or accessible".

Example

```
Dell#show inventory
System Type           : PE-FN-410S-IOA
System Mode           : 1.0
Software Version      : 1-0(0-1859)

Unit Type              Serial Number  Part Number  Rev  Piece Part ID
-----
* 0  PowerEdge-FN-410S-IOA  TW000000000020  07NVPVX01    X01  TW-07NVPV-00000-000-

* - Management Unit

Software Protocol Configured
-----
DCBX
FIP Snooping
IGMP
iSCSI
LLDP
SNMP
Dell#
```

Example (media)

```
Dell#show inventory media ?
<0-5>          Slot number
|              Pipe through a command

Dell#show inventory media
Slot  Port    Type    Media              Serial Number      F10Qualified
-----
0      9      SFP+    10GBASE-CU1M      APF11380028XGQ     Yes
0      10     SFP+    10GBASE-CU2M      APF12090032HDL     Yes
0      11     SFP+    10GBASE-CU2M      APF12090032HFB     Yes
0      12     SFP+    10GBASE-CU0.5M    APF12490013FP2     Yes
Dell#
```

Example (optional-module)

```
Dell#show inventory optional-module
Unit  Slot  Expected  Inserted  Next Boot  Status/Power (On/Off)
-----
1     0      SFP+      SFP+      AUTO      Good/On
1     1      QSFP+     QSFP+      AUTO      Good/On
* - Mismatch
Dell#
```

Related Commands [show config \(from INTERFACE VLAN mode\)](#) — displays information on a specific physical interface or virtual interface.

show memory

Display current memory usage on the M I/O Aggregator.

Syntax `show memory [stack-unit 0-5]`



Parameters	stack-unit 0–5	(OPTIONAL) Enter the keywords <code>stack-unit</code> then the stack unit ID of the stack member to display memory information on the designated stack member.
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	The output for <code>show memory</code> command displays the memory usage of LP part (sysdlp) of the system. The sysdlp is an aggregate task that handles all the tasks running on the CPU.	
Example	<pre>Dell#show memory Statistics On Unit 0 Processor ===== Total (b) Used (b) Free (b) Lowest (b) Largest (b) 268435456 4010354 264425102 264375410 264425102</pre>	

show processes cpu

Display CPU usage information based on processes running.

Syntax	<code>show processes cpu [management-unit 1-99 [details] stack-unit 0-5 summary ipc memory [stack-unit 0-5]]</code>	
Parameters	management-unit 1-99 [details]	(OPTIONAL) Display processes running in the control processor. The 1–99 variable sets the number of tasks to display in order of the highest CPU usage in the past five (5) seconds. Add the keyword <code>details</code> to display all running processes (except sysdlp). Refer to Example (management-unit).
	stack-unit 0–5	(OPTIONAL) Enter the keywords <code>stack-unit</code> then the stack member ID. The range is from 0 to 5. As an option of the <code>show processes cpu</code> command, this option displays CPU usage for the designated stack member. Or, as an option of <code>memory</code> , this option limits the output of memory statistics to the designated stack member. Refer to Example (stack-unit).
	summary	(OPTIONAL) Enter the keyword <code>summary</code> to view a summary view CPU utilization of processes related to line card processing. Refer to Example (summary).
	ipc	(OPTIONAL) Enter the keyword <code>ipc</code> to display interprocess communication statistics.
	memory	(OPTIONAL) Enter the keyword <code>memory</code> to display memory statistics. Refer to Example (memory).



Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Example (summary) Dell#show processes cpu summary

CPU utilization	5Sec	1Min	5Min
UNIT1	4%	3%	2%

Example (management-unit) Dell#show processes cpu management-unit 5

CPU utilization for five seconds: 4%/0%; one minute: 4%; five minutes: 4%

PID	Runtime(ms)	Invoked	uSecs	5Sec	1Min	5Min	TTY	Process
0x00000000	2120	212	10000	3.77%	3.77%	3.77%	0	system
0x00000112	2472940	247294	10000	0.79%	0.61%	0.65%	0	sysdlp
0x000000e4	495560	49556	10000	0.20%	0.25%	0.24%	0	sysd
0x0000013d	34310	3431	10000	0.00%	0.02%	0.00%	0	lacp
0x00000121	4190	419	10000	0.00%	0.02%	0.00%	0	iscsiOpt

PID Runtime(ms) Invoked uSecs 5Sec 1Min 5Min TTY Process

Dell#

Example (stack-unit) Dell#show process cpu stack-unit 1

CPU utilization for five seconds: 4%/0%; one minute: 3%; five minutes: 2%

PID	Runtime(ms)	Invoked	uSecs	5Sec	1Min	5Min	TTY	Process
0x763a3000	17981680	1798168	10000	3.00%	2.67%	2.67%	0	KP
0x762ba000	0	0	0	0.00%	0.00%	0.00%	0	debugagt
0x762d9000	0	0	0	0.00%	0.00%	0.00%	0	F10StkMgr
0x762f8000	214590	21459	10000	0.00%	0.00%	0.00%	0	lcMgr
0x76319000	7890	789	10000	0.00%	0.00%	0.00%	0	dla
0x76344000	155770	15577	10000	0.00%	0.00%	0.02%	0	sysAdmTsk
0x76363000	583230	58323	10000	0.00%	0.00%	0.02%	0	timerMgr
0x76381000	658850	65885	10000	0.00%	0.17%	0.08%	0	PM
0x76299000	80110	8011	10000	0.00%	0.00%	0.00%	0	diagagt
0x763c3000	0	0	0	0.00%	0.00%	0.00%	0	evagt

--More--

Example (memory) Dell#show processes memory

Memory Statistics Of Stack Unit 1 (bytes)

=====

Total: 2147483648, MaxUsed: 499019776, CurrentUsed: 499019776,

CurrentFree:

1648463872

TaskName	TotalAllocated	TotalFreed	MaxHeld	CurrentHolding
f10appioserv	225280	0	0	192512
fcoectrl	270336	0	0	9277440
f10appioserv	225280	0	0	192512
iscsiOpt	114688	0	0	7380992
dhclient	552960	0	0	1626112
f10appioserv	225280	0	0	192512



```

ndpm          618496          0          0          0          7389184
f10appioserv  225280          0          0          0          192512
vrrp          335872          0          0          0          7712768
f10appioserv  225280          0          0          0          192512
frrp          180224          0          0          0          7192576
f10appioserv  225280          0          0          0          192512
xstp          2740224         0          0          0          9445376
f10appioserv  225280          0          0          0          192512
pim           1007616         0          0          0          7585792
f10appioserv  225280          0          0          0          192512
igmp          417792          0          0          0          14774272
f10appioserv  225280          0          0          0          192512
mrtm          5496832         0          0          0          12636160
f10appioserv  225280          0          0          0          192512
l2mgr         1040384         0          0          0          42471424
f10appioserv  225280          0          0          0          192512
l2pm          176128          0          0          0          24166400
f10appioserv  225280          0          0          0          192512
arpm          192512          0          0          0          6955008
f10appioserv  225280          0          0          0          192512
otm           184320          0          0          0          7127040

--More--
Dell#

```

Example (stack-unit) Dell#show process memory stack-unit 1
Total: 2147483648, MaxUsed: 499040256, CurrentUsed: 499040256,
CurrentFree:
1648443392

TaskName	TotalAllocated	TotalFreed	MaxHeld	CurrentHolding
f10appioserv	225280	0	0	192512
fcoectrl	270336	0	0	9277440
f10appioserv	225280	0	0	192512
iscsiOpt	114688	0	0	7380992
dhclient	552960	0	0	1626112
f10appioserv	225280	0	0	192512
ndpm	618496	0	0	7389184
f10appioserv	225280	0	0	192512
vrrp	335872	0	0	7712768
f10appioserv	225280	0	0	192512
frrp	180224	0	0	7192576
f10appioserv	225280	0	0	192512
xstp	2740224	0	0	9445376
f10appioserv	225280	0	0	192512
pim	1007616	0	0	7585792
f10appioserv	225280	0	0	192512
igmp	417792	0	0	14774272
f10appioserv	225280	0	0	192512
mrtm	5496832	0	0	12636160

--More--
Dell#

Related Commands

- [show diag](#)— displays the data plane or management plane input and output statistics of the designated component of the designated stack member.
- [show hardware system-flow](#)— displays Layer 3 ACL or QoS data for the selected stack member and stack member port-pipe.
- [show interfaces stack-unit](#)— displays information on all interfaces on a specific stack member.
- [show processes memory](#)— displays CPU usage information based on running processes.



show processes ipc flow-control

Display the single window protocol queue (SWPQ) statistics.

Syntax `show processes ipc flow-control [cp]`

Parameters

cp	(OPTIONAL) Enter the keyword <code>cp</code> to view the control processor's SWPQ statistics.
-----------	---

Defaults none

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

Field	Description
Source QID /Tx Process	Source Service Identifier
Destination QID/Rx Process	Destination Service Identifier
Cur Len	Current number of messages enqueued
High Mark	Highest number of packets in the queue at any time
#of to / Timeout	Timeout count
#of Retr /Retries	Number of retransmissions
#msg Sent/Msg Sent/	Number of messages sent
#msg Ackd/Ack Rcvd	Number of messages acknowledged
Retr /Available Retra	Number of retries left
Total/ Max Retra	Number of retries allowed

Important Points:

- The SWP provides flow control-based reliable communication between the sending and receiving software tasks.
- A sending task enqueues messages into the SWP queue³ for a receiving task and waits for an acknowledgement.
- If no response is received within a defined period of time, the SWP timeout mechanism resubmits the message at the head of the FIFO queue.
- After retrying a defined number of times, the `SWP-2-NOMORETIMEOUT` timeout message is generated.



- In the example, a retry (Retries) value of zero indicates that the SWP mechanism reached the maximum number of retransmissions without an acknowledgement.

Example

```
Dell#show processes ipc flow-control
```

```
Q Statistics on CP Processor
TxProcess   RxProcess   Cur      High  Time  Retr      Msg      Ack
Aval  Max
Len      Mark  Out   ies      Sent      Rcvd  Retra  Retra
ACLO      RTM0      0        0        0        0        0        0    10
10
ACLO      DIFFSERV0  0        0        0        0        0        0    10
10
ACLO      IGMP0      0        0        0        0        0        0    10
10
ACLO      PIM0      0        0        0        0        0        0    10
10
LACP0     IFMGR0     0        24        0        0        34        34    25
25
STP0      L2PM0     0        0        0        0        0        0    25
25
L2PM0     STP0      0        1        0        0        2        2    25
25
FRRP0     L2PM0     0        0        0        0        0        0    25
25
DHCP0     ACL0      0        0        0        0        0        0    25
25
DHCP0     IPMGR0     0        0        0        0        0        0    25
25
DHCP0     IFMGR0     0        0        0        0        0        0    25
25
SMUX0     IFMGR0     0        38        0        0        47        47    60
60
SMUX0     LACP0     0        1        0        0        3        3    60
60
--More--

Dell#
```

show processes memory

Display memory usage information based on processes running in the system.

Syntax `show processes memory {management-unit | stack unit {0-5 | all | summary}}`

Parameters

management-unit	Enter the keywords <code>management-unit</code> for CPU memory usage of the stack management unit.
stack unit 0-5	Enter the keywords <code>stack unit</code> then a stack unit ID of the member unit for which to display memory usage on the forwarding processor.
all	Enter the keyword <code>all</code> for detailed memory usage on all stack members.
summary	Enter the keyword <code>summary</code> for a brief summary of memory availability and usage on all stack members.

Command Modes

- EXEC
- EXEC Privilege



Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information `show processes memory output`

Field	Description
Total:	Total system memory available
MaxUsed:	Total maximum memory used ever (history indicated with time stamp)
CurrentUsed:	Total memory currently in use
CurrentFree:	Total system memory available
SharedUsed:	Total used shared memory
SharedFree:	Total free shared memory
PID	Process ID
Process	Process Name
ResSize	Actual resident size of the process in memory
Size	Process test, stack, and data size
Allocs	Total dynamic memory allocated
Frees	Total dynamic memory freed
Max	Maximum dynamic memory allocated
Current	Current dynamic memory in use

The output for the `show process memory` command displays the memory usage statistics running on CP part (sysd) of the system. The sysd is an aggregate task that handles all the tasks running on the M I/O Aggregator's CP.

The output of the `show memory` command and this command differ based on which the Dell Networking OS processes are counted.

- In the `show memory` output, the memory size is equal to the size of the application processes.
- In the output of this command, the memory size is equal to the size of the application processes plus the size of the system processes.

Example

```
Dell#show processes memory stack-unit 1
Total: 2147483648, MaxUsed: 499040256, CurrentUsed: 499040256,
CurrentFree:
1648443392
TaskName      TotalAllocated      TotalFreed      MaxHeld
CurrentHolding
f10appioserv      225280              0              0              192512
fcoectrl          270336              0              0              9277440
f10appioserv      225280              0              0              192512
iscsiOpt          114688              0              0              7380992
dhclient          552960              0              0              1626112
f10appioserv      225280              0              0              192512
ndpm              618496              0              0              7389184
f10appioserv      225280              0              0              192512
vrrp              335872              0              0              7712768
f10appioserv      225280              0              0              192512
```



```

frrp          180224          0          0          7192576
f10appioserv  225280          0          0          192512
xstp          2740224          0          0          9445376
f10appioserv  225280          0          0          192512
pim           1007616          0          0          7585792
f10appioserv  225280          0          0          192512
igmp          417792          0          0          14774272
f10appioserv  225280          0          0          192512
mrtm          5496832          0          0          12636160

```

--More--

Example

(management-unit)

```

Dell#show processes memory management-unit
Total      : 2147483648, MaxUsed      : 499093504 [07/23/2012 17:42:16]
CurrentUsed: 499093504, CurrentFree: 1648390144
SharedUsed : 18470440, SharedFree : 2501104

```

PID	Process	ResSize	Size	Allocs	Frees	Max
Current						
633	fcoecntrl	9277440	270336	1380528	132512	1281144
1248016						
289	iscsiOpt	7380992	114688	23262	16564	23262
6698						
476	dhclient	1626112	552960	0	0	0
0						
521	ndpm	7389184	618496	4848	0	4848
4848						
160	vrp	7712768	335872	880	0	880
880						
318	frrp	7192576	180224	71086	66256	21394
4830						
218	xstp	9445376	2740224	21858	0	21858
21858						
277	pim	7585792	1007616	62168	0	62168
62168						

--More--

show revision

Displays the revision numbers of all stack-units.

Syntax

```
show revision
```

Command Modes

• EXEC Privilege

Supported Modes

All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

(Command)

```

Dell#show revision
-- Stack unit 1 --
IOM SYSTEM CPLD : 1
Dell#

```



show server-interfaces

Displays server port information.

Syntax `show server-interfaces{brief|detail}`

Command Modes

- EXEC Privilege

Supported Modes All Modes

Command History

Version 9.4(0.0)	Supported on the FN I/O Aggregator.
Version 8.3.17.0	Supported on the M I/O Aggregator .

Example (brief Command)

```
Dell#show server-interfaces brief

----- show server ports brief -----
Interface                               OK  Status  Protocol  Description
TenGigabitEthernet 0/1                 YES up      up
TenGigabitEthernet 0/2                 YES up      up
TenGigabitEthernet 0/3                 YES up      up
TenGigabitEthernet 0/4                 NO  up      down
TenGigabitEthernet 0/5                 YES up      up
TenGigabitEthernet 0/6                 NO  up      down
TenGigabitEthernet 0/7                 YES up      up
TenGigabitEthernet 0/8                 NO  up      down

----- show lacp -----
Interface                               OK  Status  Protocol  Description
Port-channel 1                         YES up      up
Dell#
```

Example (detail Command)

```
Dell#show server-interfaces detail

----- show server ports detail -----

TenGigabitEthernet 0/1 is up, line protocol is up
Hardware is DellEth, address is 00:1e:c9:de:03:79
Current address is 00:1e:c9:de:03:79
Server Port AdminState is N/A
Pluggable media not present
Interface index is 33886978
Internet address is not set
Mode of IPv4 Address Assignment : NONE
DHCP Client-ID :001ec9de0379
MTU 12000 bytes, IP MTU 11982 bytes
LineSpeed 10000 Mbit
Flowcontrol rx off tx off
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 2d16h24m
Queueing strategy: fifo
Input Statistics:
  10701 packets, 1123557 bytes
  0 64-byte pkts, 10701 over 64-byte pkts, 0 over 127-byte pkts
  0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
  10701 Multicasts, 0 Broadcasts
  0 runts, 0 giants, 0 throttles
  0 CRC, 0 overrun, 0 discarded
Output Statistics:
  442113 packets, 46047526 bytes, 0 underruns
  870 64-byte pkts, 362829 over 64-byte pkts, 55411 over 127-byte pkts
--More--
```



show system

Displays the current status of all stack members or a specific stack member.

Syntax `show system [brief | stack-unit unit-id]`

Parameters

brief	(OPTIONAL) Enter the keyword <code>brief</code> to view an abbreviated list of system information.
stack unit unit-id	(OPTIONAL) Enter the keywords <code>stack unit</code> then the stack member ID for information on the stack member. The range is from 0 to 5.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example (show system brief command)

```
Dell#show system brief
Stack MAC : 00:01:e8:00:ab:03
-- Stack Info --
Unit UnitType Status ReqTyp CurTyp Version Ports
-----
0 Member not present
1 Management online I/O-Aggregator I/O-Aggregator 8-3-17-38 56
2 Member not present
3 Member not present
4 Member not present
5 Member not present
Dell#
```

Example (stack-unit command)

```
Dell#show system stack-unit 1
-- Unit 1 --
Unit Type : Management Unit
Status : online
Next Boot : online
Required Type : I/O-Aggregator - 34-port GE/TE (XL)
Current Type : I/O-Aggregator - 34-port GE/TE (XL)
Master priority : 0
Hardware Rev : 01
Num Ports : 56
Up Time : 4 day, 7 hr, 9 min
FTOS Version : 8-3-17-38
Jumbo Capable : yes
POE Capable : no
Boot Flash : A: 4.0.1.0bt [booted] B: 4.0.1.0bt1
Boot Selector : 4.0.0.0bt
Memory Size : 2147483648 bytes
Temperature : 67C
Voltage : ok
Switch Power : GOOD
Product Name : I/O Aggregator
Mfg By : DELL
Mfg Date :
Serial Number : 0000000000000000
Part Number : NVH81X01
Piece Part ID : 00-NVH81X-00000-000-0000
```



```

PPID Revision : 01
Service Tag : N/A
Expr Svc Code : N/A
Chassis Svce Tag: RTWB200
Fabric Id : C2
Asset tag : test
PSOC FW Rev : 0xb
ICT Test Date : 0-0-0
ICT Test Info : 0x0
Max Power Req : 31488
Fabric Type : 0x3
Fabric Maj Ver : 0x1
Fabric Min Ver : 0x0
SW Manageability: 0x4
HW Manageability: 0x1
Max Boot Time : 3 minutes
Link Tuning : unsupported
Auto Reboot : enabled
Burned In MAC : 00:01:e8:00:ab:03
No Of MACs : 3
Dell#

```

Related Commands [asset-tag](#)—Assign and store unique asset-tag to the stack member.

[show version](#)— Displays the Dell version.

[show processes memory](#)—Displays the memory usage based on the running processes.

[show system stack-ports](#)— Displays information about the stack ports on all switches in the stack.

[show diag](#)— Displays the data plane and management plane input and output statistics of a particular stack member.

show tech-support

Displays a collection of data from other show commands, necessary for Dell Networking technical support to perform troubleshooting on Aggregators.

Syntax `show tech-support [stack-unit unit-id | page]`

Parameters

stack-unit	(OPTIONAL) Enter the keyword <code>stack-unit</code> to view CPU memory usage for the stack member designated by <i>unit-id</i> . The range is 0 to 5.
page	(OPTIONAL) Enter the keyword <code>page</code> to view 24 lines of text at a time. Press the SPACE BAR to view the next 24 lines. Press the ENTER key to view the next line of text. When using the pipe command (<code> </code>), enter one of these keywords to filter command output. Refer to CLI Basics for details on filtering commands.
save	Enter the keyword <code>save</code> to save the command output. flash: Save to local flash drive (<code>flash://filename</code> (max 20 chars))

Command Modes

- EXEC Privilege



Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

Without the `page` or `stack-unit` option, the command output is continuous, use Ctrl-z to interrupt the command output.

The `save` option works with other filtering commands. This allows you to save specific information of a `show` command. The `save` entry must always be the last option.

For example: `Dell#show tech-support |grep regular-expression |except regular-expression | find regular-expression | save flash://result`

This display output is an accumulation of the same information that is displayed when you execute one of the following `show` commands:

- `show cam`
- `show clock`
- `show environment`
- `show file`
- `show interfaces`
- `show inventory`
- `show processes cpu`
- `show processes memory`
- `show running-conf`
- `show version`

Example (save)

```
Dell#show tech-support ?
page          Page through output
stack-unit    Unit Number
|            Pipe through a command
<cr>
Dell#show tech-support stack-unit 1 ?
page          Page through output
|            Pipe through a command
<cr>
Dell#show tech-support stack-unit 1 | ?
except S      how only text that does not match a pattern
find          Search for the first occurrence of a pattern
grep          Show only text that matches a pattern
no-more       Don't paginate output
save          Save output to a file
Dell#show tech-support stack-unit 1 | save ?
flash:        Save to local file system (flash://filename (max 20 chars) )
usbflash:     Save to local file system (usbflash://filename (max 20
chars) )
Dell#show tech-support stack-unit 1 | save flash://LauraSave
Start saving show command report .....
Dell#
Dell#dir
Directory of flash:
Directory of flash:
1 drwx 4096 Jan 01 1980 01:00:00 +01:00 .
2 drwx 2048 May 16 2012 10:49:01 +01:00 ..
3 drwx 4096 Jan 24 2012 19:38:32 +01:00 TRACE_LOG_DIR
```



```

4 drwx 4096 Jan 24 2012 19:38:32 +01:00 CORE_DUMP_DIR
5 d--- 4096 Jan 24 2012 19:38:34 +01:00 ADMIN_DIR
6 -rwx 10303 Mar 15 2012 18:37:20 +01:00 startup-config.bak
7 -rwx 7366 Apr 20 2012 10:57:02 +01:00 startup-config
8 -rwx 4 Feb 19 2012 07:05:02 +01:00 dhcpBindConflict
9 -rwx 12829 Feb 18 2012 02:24:14 +01:00 startup-config.backup
10 drwx 4096 Mar 08 2012 22:58:54 +01:00 WJ_running-config
11 -rwx 7689 Feb 21 2012 04:45:40 +01:00 stbkup
flash: 2143281152 bytes total (2131476480 bytes free)
Dell

```

Example (support)

```

Dell#show tech-support stack-unit 1
----- show version
-----
Dell Networking Real Time Operating System Software
Dell Networking Operating System Version: 1.0
Dell Networking Application Software Version: E8-3-17-38
Copyright (c) 1999-2012 by Dell Inc. All Rights Reserved.
Build Time: Thu Jul 19 05:59:59 PDT 2012
Build Path: /sites/sjc/work/swsystems01-2/ravisubramani/ravis-8317/SW/SRC/
Cp_src/
Tacacs
FTOS uptime is 4 day(s), 7 hour(s), 14 minute(s)
System image file is "dv-m1000e-2-b2"
System Type: I/O-Aggregator
Control Processor: MIPS RMI XLP with 2147483648 bytes of memory.
256M bytes of boot flash memory.
1 34-port GE/TE (XL)
56 Ten GigabitEthernet/IEEE 802.3 interface(s)
----- show clock
-----
17:49:37.2 UTC Mon Jul 23 2012
----- show running-config
-----
Current Configuration ...
! Version E8-3-17-38
! Last configuration change at Mon Jul 23 17:10:18 2012 by default
!
boot system stack-unit 1 primary tftp://10.11.9.21/dv-m1000e-2-b2
boot system stack-unit 1 default system: A:
boot system gateway 10.11.209.62
!
redundancy auto-synchronize full
!
service timestamps log datetime
!
hostname FTOS
----- show ip management route
-----
Destination Gateway State
-----
1
--More--
Dell#

```

Related Commands

[show version](#) — displays the Dell Networking OS version.

[show system](#) — displays the current switch status..

[show environment](#) — displays system component status.

[show processes memory](#) — displays memory usage based on the running processes.



show uplink brief

Displays the uplink port information.

Syntax show uplink {brief|detail}

Parameters

brief	Enter the keyword <code>brief</code> to display a brief summary of the uplink port information.
detail	Enter the keyword <code>detail</code> to display uplink port information with description.

Command Modes

- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example (brief)

```
Dell#show uplink brief
----- show uplink brief -----
Interface          OK Status   Protocol Description
TenGigabitEthernet 0/41 NO up      down
TenGigabitEthernet 0/43 NO up      down
TenGigabitEthernet 0/44 NO up      down
TenGigabitEthernet 0/45 NO up      down
TenGigabitEthernet 0/46 NO up      down
TenGigabitEthernet 0/47 NO up      down
TenGigabitEthernet 0/48 NO up      down
TenGigabitEthernet 0/49 NO up      down
TenGigabitEthernet 0/50 NO up      down
TenGigabitEthernet 0/51 NO up      down
TenGigabitEthernet 0/52 NO up      down
TenGigabitEthernet 0/53 NO up      down
TenGigabitEthernet 0/54 NO up      down
TenGigabitEthernet 0/55 NO up      down
TenGigabitEthernet 0/56 NO up      down
TenGigabitEthernet 1/41 NO up      down
TenGigabitEthernet 1/42 NO up      down
TenGigabitEthernet 1/43 NO up      down
--More--
4 www.force10networks.com (10.11.84.18) 000.000 ms 000.000 ms 000.000 ms
Dell#
```

Example (detail)

```
Dell#show uplink detail
----- show uplink detail -----
TenGigabitEthernet 0/41 is up, line protocol is down
Hardware is DellForce10Eth, address is 00:1e:c9:f1:00:99
Current address is 00:1e:c9:f1:00:99
Port is not present
Pluggable media not present
Interface index is 44634881
Internet address is not set
Mode of IP Address Assignment : NONE
DHCP Client-ID :tenG170001ec9f10099
MTU 12000 bytes, IP MTU 11982 bytes
LineSpeed auto
Flowcontrol rx on tx off
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 2d19h53m
Queueing strategy: fifo
Input Statistics:
```



```

0 packets, 0 bytes
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 0 Broadcasts
--More--

```

show util-threshold cpu

Displays the set CPU utilization threshold values.

Syntax `show util-threshold cpu`

Command Modes

- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information This command displays all CPU utilization thresholds of the management, standby, and stack-units.

show util-threshold memory

Displays the set memory utilization threshold values.

Syntax `show util-threshold memory`

Command Modes

- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information This command displays all memory utilization thresholds of the management, standby, and stack-units.

ssh-peer-stack-unit

Open an SSH connection to the peer stack-unit.

Syntax `ssh-peer-stack-unit [-l username]`



Parameters	- username	(OPTIONAL) Enter the keyword - followed by your username. Default: The username associated with the terminal.
-------------------	--------------------	---

Defaults	Not configured.
-----------------	-----------------

Command Modes	• EXEC Privilege
----------------------	--

Supported Modes	All Modes
------------------------	-----------

Command History	<table border="0"> <tr> <th style="text-align: left;">Version</th> <th style="text-align: left;">Description</th> </tr> <tr> <td>9.6(0.0)</td> <td>Supported on the FN I/O Aggregator.</td> </tr> <tr> <td>8.3.17.0</td> <td>Supported on the M I/O Aggregator.</td> </tr> </table>	Version	Description	9.6(0.0)	Supported on the FN I/O Aggregator.	8.3.17.0	Supported on the M I/O Aggregator.
Version	Description						
9.6(0.0)	Supported on the FN I/O Aggregator.						
8.3.17.0	Supported on the M I/O Aggregator.						

telnet

Connect through Telnet to a server. The Telnet client and server in Dell Networking OS support IPv4 connections. You can establish a Telnet session directly to the router or a connection can be initiated from the router.

Syntax	<code>telnet {host ip-address [/source-interface]}</code>
---------------	---

Parameters	<table border="0"> <tr> <td style="vertical-align: top;">host</td> <td>Enter the name of a server.</td> </tr> <tr> <td style="vertical-align: top;">ip-address</td> <td>Enter the IPv4 address in dotted decimal format of the server.</td> </tr> <tr> <td style="vertical-align: top;">source-interface</td> <td> (OPTIONAL) Enter the keywords /source-interface then the interface information to include the source interface. Enter the following keywords and slot/port or number information: • For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet then the slot/port information. • For a VLAN interface, enter the keyword <code>vlan</code> then a number from 1 to 4094. </td> </tr> </table>	host	Enter the name of a server.	ip-address	Enter the IPv4 address in dotted decimal format of the server.	source-interface	(OPTIONAL) Enter the keywords /source-interface then the interface information to include the source interface. Enter the following keywords and slot/port or number information: • For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet then the slot/port information. • For a VLAN interface, enter the keyword <code>vlan</code> then a number from 1 to 4094.
host	Enter the name of a server.						
ip-address	Enter the IPv4 address in dotted decimal format of the server.						
source-interface	(OPTIONAL) Enter the keywords /source-interface then the interface information to include the source interface. Enter the following keywords and slot/port or number information: • For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet then the slot/port information. • For a VLAN interface, enter the keyword <code>vlan</code> then a number from 1 to 4094.						

Defaults	Not configured.
-----------------	-----------------

Command Modes	• EXEC • EXEC Privilege
----------------------	--

Supported Modes	All Modes
------------------------	-----------

Command History	<table border="0"> <tr> <th style="text-align: left;">Version</th> <th style="text-align: left;">Description</th> </tr> <tr> <td>9.4(0.0)</td> <td>Supported on the FN I/O Aggregator.</td> </tr> <tr> <td>8.3.17.0</td> <td>Supported on the M I/O Aggregator.</td> </tr> </table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	8.3.17.0	Supported on the M I/O Aggregator.
Version	Description						
9.4(0.0)	Supported on the FN I/O Aggregator.						
8.3.17.0	Supported on the M I/O Aggregator.						

Usage Information	Telnet to link-local addresses is not supported.
--------------------------	--



telnet-peer-stack-unit

Open a telnet connection to the peer stack-unit.

Syntax `telnet-peer-stack-unit`

Defaults Not configured.

Command Modes

- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.6(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

terminal length

Configure the number of lines displayed on the terminal screen.

Syntax `terminal length screen-length`
To return to the default values, use the `no terminal length` command.

Parameters

<i>screen-length</i>	Enter a number of lines. Entering zero will cause the terminal to display without pausing. The range is from 0 to 512.
	Default: 24 lines

Defaults 24 lines

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

terminal monitor

Configure the Dell Networking OS to display messages on the monitor/terminal.

Syntax `terminal monitor`



To return to default settings, use the `no terminal monitor` command.

Defaults	Disabled	
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

terminal xml

Enable XML mode in Telnet and SSH client sessions.

Syntax	<code>terminal xml</code> To exit the XML mode, use the <code>no terminal monitor</code> command.	
Defaults	Disabled	
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	This command enables XML input mode where you can either cut and paste XML requests or enter the XML requests line-by-line.	

trace route

View the packet path to a specific device.

Syntax	<code>traceroute {host ip-address}</code>	
Parameters	host	Enter the name of device.
	ip-address	Enter the IP address of the device in dotted decimal format.



Defaults	Timeout = 5 seconds; Probe count = 3; 30 hops max; 40 byte packet size; UDP port = 33434	
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	94(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	When you enter the traceroute command without specifying an IP address (Extended Traceroute), you are prompted for a target and source IP address, timeout in seconds (default is 5), a probe count (default is 3), minimum TTL (default is 1), maximum TTL (default is 30), and port number (default is 33434). To keep the default setting for those parameters, press the ENTER key.	
Example (IPv4)	<pre> Dell#traceroute www.force10networks.com Translating "www.force10networks.com"...domain server (10.11.0.1) [OK] Type Ctrl-C to abort. ----- Tracing the route to www.force10networks.com (10.11.84.18), 30 hops max, 40 byte packets ----- TTL Hostname Probe1 Probe2 Probe3 1 10.11.199.190 001.000 ms 001.000 ms 002.000 ms 2 gwegress-sjc-02.force10networks.com (10.11.30.126) 005.000 ms 001.000 ms 001.000 ms 3 fw-sjc-01.force10networks.com (10.11.127.254) 000.000 ms 000.000 ms 000.000 ms 4 www.force10networks.com (10.11.84.18) 000.000 ms 000.000 ms 000.000 ms Dell# </pre>	
Related Commands	ping — Tests the connectivity to a device.	

undebg all

Disable all debug operations on the system.

Syntax	undebg all	
Defaults	none	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	94(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.



write

Copy the current configuration to either the startup-configuration file or the terminal.

Syntax `write {memory | terminal}`

Parameters

memory	Enter the keyword <code>memory</code> to copy the current running configuration to the startup configuration file. This command is similar to the <code>copy running-config startup-config</code> command.
terminal	Enter the keyword <code>terminal</code> to copy the current running configuration to the terminal. This command is similar to the <code>show running-config</code> command.

Command Modes

- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The `write memory` command saves the running-configuration to the file labeled startup-configuration. When using a LOCAL CONFIG FILE other than the startup-config not named "startup-configuration", the running-config is not saved to that file; use the `copy` command to save any running-configuration changes to that local file.



u-Boot

All commands in this chapter are in u-Boot mode. These commands are supported on the Dell Networking Aggregator only. To access this mode, hit **Esc** key when the following line appears on the console during a system boot: Hit Esc key to interrupt autoboot:

You enter u-Boot immediately, as indicated by the `BOOT_USER#` prompt.

 **NOTE: Only the most frequently used commands available in uBoot mode are described in this chapter.**
In uBoot mode, you cannot use the Tab key for command completion.

boot change

Change the operating system boot parameters.

Syntax	boot change [primary secondary default]	
Command Modes	uBoot	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

boot selection

Change the ROM bootstrap bootflash partition.

Syntax	boot selection[a b]	
Command Modes	· uBoot	
Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.



boot show net config retries

Show the number of retries for network boot configuration failure.

Syntax `boot show net config retries`

Command Modes `uBoot`

Supported Modes `All Modes`

Command History	Version	Description
	94(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
BOOT_USER# boot show net config retries
Number of Network Boot Config Retries is : 0
BOOT_USER #
```

boot write net config retries

Set the number of retries for network boot configuration failure.

Syntax `boot write net config retries <int>`

Command Modes `uBoot`

Supported Modes `All Modes`

Command History	Version	Description
	94(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
BOOT_USER # boot write net config retries 2
Updated number of Network Boot Config retries to 2.
BOOT_USER #
```

boot zero

Clears the primary, secondary, or default boot parameters.

Syntax `boot zero [primary| secondary| default]`

Command Modes `uBoot`

Supported Modes `All Modes`

Command History	Version	Description
	94(0.0)	Supported on the FN I/O Aggregator.



Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

default gateway

Set the default gateway IP address.

Syntax	default-gateway <ip-address>	
Command Modes	uBoot	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

enable

Change the access privilege level.

Syntax	enable [user admin]	
Command Modes	uBoot	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

help

Displays the help menu.

Syntax	help	
Command Modes	uBoot	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.



Example

```
BOOT_USER # help
***** Dell Force10 Boot Interface Help Information *****
Current access level: USER LEVEL
Use "syntax help" for more information on syntax.
Available command list (22 commands total):
boot change [primary|secondary|default]
    change operating system boot parameters
boot selection [a|b]
    change the rom bootstrap bootflash partition
boot show net config retries
    show number of retries for network boot config failure
boot write net config retries <int>
    write number of retries for network boot config failure
boot zero [primary|secondary|default]
    zero operating system boot parameters
default-gateway <ip-address>
    default-gateway - set the default gateway ip address
enable [user|admin]
    change access privilege level
help
    display help menu
-(36%)-Use <CR> to continue, q to stop:
BOOT_USER #
```

ignore enable password

Ignore the enabled password.

Syntax ignore enable-password

Command Modes uBoot

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

ignore startup-config

Ignore the system startup configuration.

Syntax ignore startup-config

Command Modes uBoot

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.



interface management ethernet ip address

Set the management port IP address and mask.

Syntax `interface management ethernet ip address <ip/mask>`

Command Modes uBoot

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

no default gateway

Clear the default gateway IP address.

Syntax `no default-gateway`

Command Modes uBoot

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

no interface management ethernet ip address

Clear the management port IP address and mask.

Syntax `no interface management ethernet ip address`

Command Modes uBoot

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.



reload

Reload the Aggregator.

Syntax reload

Command Modes uBoot

Supported Modes All Modes

Command History

Version

Description

94(0.0)

Supported on the FN I/O Aggregator.

8.3.17.0

Supported on the M I/O Aggregator.

show boot blc

Show the boot loop counter value.

Syntax show boot blc

Command Modes uBoot

Supported Modes All Modes

Command History

Version

Description

94(0.0)

Supported on the FN I/O Aggregator.

8.3.17.0

Supported on the M I/O Aggregator.

Example

```
BOOT_USER # show boot blc ?
Total 1 possible command found.
Possible command list:
show boot blc
    show the boot loop counter value
BOOT_USER # show boot blc
Boot Loop Counter : 10

BOOT_USER #
```

show boot selection

Displays the ROM bootstrap bootflash partition.

Syntax show boot selection

Command Modes uBoot

Supported Modes All Modes

Command History

Version

Description

94(0.0)

Supported on the FN I/O Aggregator.



Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Example

```

BOOT_USER # show boot blc ?
Total 1 possible command found.
Possible command list:
show boot blc
    show the boot loop counter value
BOOT_USER # show boot blc
Boot Loop Counter : 10

BOOT_USER #

```

show bootflash

Show the summary of boot flash information.

Syntax	show bootflash
Command Modes	uBoot
Supported Modes	All Modes
Command History	

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```

BOOT_USER # show bootflash

GENERAL BOOTFLASH INFO
=====
Bootflash Partition A:
    Dell Force10 Networks System Boot
    Official IOM_LP_IMG_BOOT_LOADER, BSP Release 4.0.1.0bt1
    Created Tue May 1 10:56:16 2012 by build on login-sjc-01

Bootflash Partition B:
    Dell Force10 Networks System Boot
    Official IOM_LP_IMG_BOOT_LOADER, BSP Release 4.0.1.0bt1
    Created Tue May 1 10:56:16 2012 by build on login-sjc-01

Boot Selector Partition:
    Dell Force10 Networks System Boot
    Official IOM_XLOAD_LP_IMG_BOOT_SELECTOR, BSP Release 4.0.0.0bt1
    Created Tue May 1 10:56:34 2012 by build on login-sjc-01

BOOT_USER #

```

show bootvar

Show the summary of operating system boot parameters.

Syntax	show bootvar
--------	--------------



Command Modes	uBoot						
Supported Modes	All Modes						
Command History	<table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>94(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr> <tr> <td>8.3.17.0</td><td>Supported on the M I/O Aggregator.</td></tr> </table>	Version	Description	94(0.0)	Supported on the FN I/O Aggregator.	8.3.17.0	Supported on the M I/O Aggregator.
Version	Description						
94(0.0)	Supported on the FN I/O Aggregator.						
8.3.17.0	Supported on the M I/O Aggregator.						

Example

```

BOOT_USER # show bootvar

PRIMARY OPERATING SYSTEM BOOT PARAMETERS:
=====
boot device           : tftp
file name             : premnath
Management Ethernet IP address : 10.16.130.134/16
Server IP address    : 10.16.127.35
Default Gateway IP address : 15.0.0.1
Management Ethernet MAC address : 00:01:E8:43:DE:DF

SECONDARY OPERATING SYSTEM BOOT PARAMETERS:
=====
No Operating System boot parameters specified!

DEFAULT OPERATING SYSTEM BOOT PARAMETERS:
=====
boot device           : tftp
file name             : FTOS-XL-8-3-16-99.bin
Management Ethernet IP address : 10.16.130.134/16
Server IP address    : 10.16.127.53
Default Gateway IP address : 15.0.0.1
Management Ethernet MAC address : 00:01:E8:43:DE:DF

BOOT_USER #

```

show default gateway

Displays the default gateway IP address.

Syntax	show default-gateway						
Command Modes	uBoot						
Supported Modes	All Modes						
Command History	<table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>94(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr> <tr> <td>8.3.17.0</td><td>Supported on the M I/O Aggregator.</td></tr> </table>	Version	Description	94(0.0)	Supported on the FN I/O Aggregator.	8.3.17.0	Supported on the M I/O Aggregator.
Version	Description						
94(0.0)	Supported on the FN I/O Aggregator.						
8.3.17.0	Supported on the M I/O Aggregator.						

Example

```

BOOT_USER # show default-gateway
Gateway IP address: 15.0.0.1
BOOT_USER #

```



show interface management ethernet

Show the management port IP address and mask.

Syntax `show interface management ethernet`

Command Modes uBoot

Supported Modes All Modes

Command History	Version	Description
	94(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
BOOT_USER # show interface management ethernet
Management ethernet IP address: 10.16.130.134/16
BOOT_USER #
```

show interface management port config

Show the management port boot characteristics.

Syntax `show interface management port config`

Command Modes uBoot

Supported Modes All Modes

Command History	Version	Description
	94(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
BOOT_USER # show interface management port config
Management ethernet Port Configuration: no Auto Negotiate
Management ethernet Port Configuration: 100M
Management ethernet Port Configuration: full duplex
BOOT_USER #
```

syntax help

Show the syntax information.

Syntax `help`

Command Modes uBoot

Supported Modes All Modes

Command History	Version	Description
	94(0.0)	Supported on the FN I/O Aggregator.



Version	Description
8.3.17.0	Supported on the M I/O Aggregator.



Data Center Bridging (DCB)

Data center bridging (DCB) refers to a set of IEEE Ethernet enhancements that provide data centers with a single, robust, converged network to support multiple traffic types, including local area network (LAN), server, and storage traffic. DCB features are auto-configured in standalone mode.

The Dell Networking OS commands for DCB features include 802.1Qbb priority-based flow control (PFC), 802.1Qaz enhanced transmission selection (ETS), and the data center bridging exchange (DCBX) protocol.

CLI commands for individual DCB features are as follows:

DCB command

- [dcb enable auto-detect on-next-reload](#)
- [show qos dcb-map](#)

PFC Commands

- [clear pfc counters](#)
- [show interface pfc](#)
- [show interface pfc statistics](#)

ETS Commands

- [clear ets counters](#)
- [show interface ets](#)

DCBX Commands

- [dcbx version](#)
- [clear dcbx counters](#)
- [show dcb](#)
- [show interface dcbx detail](#)

Fibre Channel over Ethernet for FC Flex IO Modules

FCoE provides a converged Ethernet network that allows the combination of storage-area network (SAN) and LAN traffic on a Layer 2 link by encapsulating Fibre Channel data into Ethernet frames.

The Aggregator, installed with the FC Flex IO module, functions as a top-of-rack edge switch that supports converged enhanced Ethernet (CEE) traffic — Fibre channel over Ethernet (FCoE) for storage, Interprocess Communication (IPC) for servers, and Ethernet local area network (LAN) (IP cloud) for data — as well as FC links to one or more storage area network (SAN) fabrics.

FCoE works with the Ethernet enhancements provided in Data Center Bridging (DCB) to support lossless (no-drop) SAN and LAN traffic. In addition, DCB provides flexible bandwidth sharing for different traffic types, such as LAN and SAN, according to 802.1p priority classes of service. DCBX should be enabled on the system before the FIP snooping feature is enabled.



All of the commands that are supported for FCoE on the I/O Aggregator apply to the FC Flex IO modules. Similarly, all of the configuration procedures and the settings that are applicable for FCoE on the I/O Aggregator are valid for the FC Flex IO modules.

advertise dcbx-appln-tlv

On a DCBX port with a manual role, configure the application priority TLVs advertised on the interface to DCBX peers.

Syntax `advertise dcbx-appln-tlv {fcoe | iscsi}`
To remove the application priority TLVs, use the `no advertise dcbx-appln-tlv {fcoe | iscsi}` command.

Parameters `{fcoe | iscsi}` Enter the application priority TLVs, where:

- `fcoe`: enables the advertisement of FCoE in application priority TLVs.
- `iscsi`: enables the advertisement of iSCSI in application priority TLVs.

Defaults Application priority TLVs are enabled to advertise FCoE and iSCSI.

Command Modes PROTOCOL LLDP

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information To disable TLV transmission, use the `no` form of the command; for example, `no advertise dcbx-appln-tlv iscsi`.

advertise dcbx-tlv

On a DCBX port with a manual role, configure the PFC and ETS TLVs advertised to DCBX peers.

Syntax `advertise dcbx-tlv {ets-conf | ets-reco | pfc} [ets-conf | ets-reco | pfc]`
`[ets-conf | ets-reco | pfc]`
To remove the advertised ETS TLVs, use the `no advertise dcbx-tlv` command.

Parameters `{ets-conf | ets-reco | pfc}` Enter the PFC and ETS TLVs advertised, where:

- `ets-conf`: enables the advertisement of ETS configuration TLVs.
- `ets-reco`: enables the advertisement of ETS recommend TLVs.
- `pfc`: enables the advertisement of PFC TLVs.

Defaults All PFC and ETS TLVs are advertised.



Command Modes	PROTOCOL LLDP								
Supported Modes	Programmable-Mux (PMUX)								
Command History	<table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr> <tr> <td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr> <tr> <td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr> </table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Version	Description								
9.4(0.0)	Supported on the FN I/O Aggregator.								
9.2(0.0)	Introduced on the M I/O Aggregator.								
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.								
Usage Information	You can configure the transmission of more than one TLV type at a time; for example: <code>advertise dcbx-tlv ets-conf ets-reco</code>. You can enable ETS recommend TLVs (<code>ets-reco</code>) only if you enable ETS configuration TLVs (<code>ets-conf</code>). To disable TLV transmission, use the <code>no</code> form of the command; for example, <code>no advertise dcbx-tlv pfc ets-reco</code>. DCBX requires that you enable LLDP to advertise DCBX TLVs to peers. Configure DCBX operation at the INTERFACE level on a switch or globally on the switch. To verify the DCBX configuration on a port, use the <code>show interface dcbx detail</code> command.								

bandwidth-percentage

Assign a percentage of weight to the class/queue.

Syntax	<code>bandwidth-percentage percentage</code> To remove the bandwidth percentage, use the <code>no bandwidth-percentage</code> command.								
Parameters	<i>percentage</i> Enter the percentage assignment of weight to the class/queue. The range is from 1 to 100% (granularity 1%).								
Defaults	none								
Command Modes	CONFIGURATION (conf-qos-policy-out)								
Supported Modes	Programmable-Mux (PMUX)								
Command History	<table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr> <tr> <td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr> <tr> <td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr> </table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Version	Description								
9.4(0.0)	Supported on the FN I/O Aggregator.								
9.2(0.0)	Introduced on the M I/O Aggregator.								
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.								
Usage Information	The unit of bandwidth percentage is 1%. A bandwidth percentage of 0 is allowed and disables the scheduling of that class. If the sum of the bandwidth percentages given to all eight classes exceeds 100%, the bandwidth percentage automatically scales down to 100%.								
Related Commands	qos-policy-output — creates a QoS output policy.								



clear dcbx counters

Clear all DCBx TLV counters on an interface.

Syntax	<code>clear dcbx counters tengigabitethernet slot/port</code>	
Defaults	none	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

clear ets counters

Clear ETS TLV counters.

Syntax	<code>clear ets counters [tengigabitethernet slot/port]</code>	
Parameters	slot/port	Enter the slot/port number.
Command Modes	· EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

clear pfc counters

Clear the PFC TLV counters and PFC statistics on an interface or stack unit.

Syntax	<code>clear pfc counters [port-type slot/port [statistics]] [stack-unit {unit-number all} stack-ports all]</code>	
Parameters	port-type	Enter the keywords <code>port-type</code> then the slot/port information.
	stack-unit <i>unit number</i>	Enter the keywords <code>stack-unit</code> then the stack-unit number to clear. The range is from 0 to 5.
	all stack-ports all	Enter the keywords <code>all stack-ports all</code> to clear the counters on all interfaces.



	statistics	Enter the keyword <code>statistics</code> to clear only the hardware PFC counters.
Defaults	None	
Command Modes	• EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
Usage information	If you do not use the <code>statistics</code> parameter, both hardware and DCBx counters clear.	

dcb-enable

Enable data center bridging.

Syntax	<code>dcb enable</code> To disable DCB, use the <code>no dcb enable</code> command.	
Defaults	none	
Command Modes	CONFIGURATION	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
Usage Information	DCB is not supported if you enable <code>link-level flow control</code> on one or more interfaces.	

dcb enable pfc-queues

Configure the number of PFC queues.

Syntax	<code>dcb enable pfc-queues value</code>	
Parameters	value	Enter the number of PFC queues. The range is from 1 to 4. The number of ports supported based on lossless queues configured will depend on the buffer.
Default	2	
Command Modes	CONFIGURATION mode	
Supported Modes	Programmable-Mux (PMUX)	



Command History	Version	Description
	9.6(0.0)	Supported on the FN 2210S Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.
	9.3(0.0)	Supported on the MXL 10/40GbE Switch IO Module platform.
Usage Information	You can configure up to a maximum of four lossless (PFC) queues. By configuring four lossless queues, you can configure four different priorities and assign a particular priority to each application that your network is used to process. For example, you can assign a higher priority for time-sensitive applications and a lower priority for other services, such as file transfers. You can configure the amount of buffer space to be allocated for each priority and the pause or resume thresholds for the buffer. This method of configuration enables you to effectively manage and administer the behavior of lossless queues.	
Example	Dell(conf)#dcb pfc-queues 4	

dcb enable auto-detect on-next-reload

Enables or disables global DCB on a subsequent reload. This command also internally configures PFC buffers based on DCB enable/disable. Save and reload is mandatory for the configurations to take effect. Auto-detect keyword can be used to re-enable IOA with port wise DCB auto detect feature.

Syntax	dcb enable [auto-detect on-next-reload] To disable global DCB on a subsequent reload, use the no dcb enable on-next-reload command.	
Parameters	auto-detect	Enter the keywords auto-detect to re-enable the Aggregator with port wise DCB auto detect feature.
	on-next-reload	Enter the keywords on-next-reload to apply DCB configurations on subsequent reload.
Defaults	DCB is globally enabled with auto-detect feature.	
Command Modes	· CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.3	Added auto-detect parameter on the M I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example (Disable)

Dell#show dcb stack-unit 0 port-set 0
stack-unit 0 port-set 0
DCB Status: Enabled, PFC Queue Count: 4

stack-unit Total Buffer PFC Total Buffer PFC Shared Buffer PFC Available Buffer
PP (KB) (KB) (KB) (KB)

0 0 3822 1912 832 450
Dell(conf)#
Dell#



```

Dell#
Dell#conf
Dell(conf)#no dcb enable on-next-reload
Dell(conf)#end
Dell#
Dell#write memory
!
Mar 18 00:21:49: %STKUNIT0-M:CP %FILEMGR-5-FILESAVED: Copied running-config to
startup-config in flash by default

```

```
Dell#reload
```

```

Proceed with reload [confirm yes/no]: y
syncing disks... done
unmounting file systems...
unmounting /f10/flash (/dev/ld0e)...
unmounting /usr (mfs:35)...
unmounting /lib (mfs:24)...
unmounting /f10 (mfs:21)...
unmounting /tmp (mfs:15)...
unmounting /kern (kernfs)...
unmounting / (/dev/md0a)... done
rebooting...

```

```

Dell#show dcb stack-unit 0 port-set 0
stack-unit 0 port-set 0
DCB Status: Enabled, PFC Queue Count: 4

```

	stack-unit	Total	Buffer	PFC	Total	Buffer	PFC	Shared	Buffer	PFC	Available	Buffer
	PP		(KB)			(KB)			(KB)			(KB)
0	0	3822		1912		832			450			

```

Dell(conf)#
Dell#

```

Example (Enable)

```

Dell#show dcb stack-unit 0 port-set 0
stack-unit 0 port-set 0
DCB Status: Enabled, PFC Queue Count: 4

```

	stack-unit	Total	Buffer	PFC	Total	Buffer	PFC	Shared	Buffer	PFC	Available	Buffer
	PP		(KB)			(KB)			(KB)			(KB)
0	0	3822		1912		832			450			

```

Dell(conf)#
Dell#
Dell#
Dell#
Dell#conf
Dell(conf)#dcb enable on-next-reload
Dell(conf)#end
Dell#Mar 18 00:26:07: %STKUNIT0-M:CP %SYS-5-CONFIG_I: Configured from console
Dell#write memory
!
Mar 18 00:26:11: %STKUNIT0-M:CP %FILEMGR-5-FILESAVED: Copied running-config to
startup-config in flash by default

```

```

Dell#
Dell#reload

```

```

Proceed with reload [confirm yes/no]: y
syncing disks... done
unmounting file systems...
unmounting /f10/flash (/dev/ld0e)...
unmounting /usr (mfs:35)...

```



```

unmounting /lib (mfs:24)...
unmounting /f10 (mfs:21)...
unmounting /tmp (mfs:15)...
unmounting /kern (kernfs)...
unmounting / (/dev/md0a)... done
rebooting...
Dell#show dcb stack-unit 0 port-set 0
stack-unit 0 port-set 0
DCB Status: Enabled, PFC Queue Count: 4

```

	stack-unit	Total	Buffer	PFC	Total	Buffer	PFC	Shared	Buffer	PFC	Available	Buffer
	PP		(KB)			(KB)			(KB)			(KB)
0	0	3822		1912		832			450			

Dell(conf)#

Example (Enable DCB with Auto-Detect)

```

Dell#show dcb
stack-unit 0 port-set 0
DCB Status : Disabled
PFC Queue Count : 2
Total Buffer[lossy + lossless] (in KB) : 3822
PFC Total Buffer (in KB) : 1912
PFC Shared Buffer (in KB) : 832
PFC Available Buffer (in KB) : 1080
Dell#
Dell#
Dell#con
Dell(conf)#dcb enable auto-detect on-next-reload
Dell(conf)#end
Dell#Mar 18 00:35:19: %STKUNIT0-M:CP %SYS-5-CONFIG_I: Configured from console

```

```

Dell#write memory
!
Mar 18 00:35:24: %STKUNIT0-M:CP %FILEMGR-5-FILESAVED: Copied running-config to
startup-config in flash by default

```

```

Dell#
Dell#reload

```

```

Proceed with reload [confirm yes/no]: y
syncing disks... done
unmounting file systems...
unmounting /f10/flash (/dev/ld0e)...
unmounting /usr (mfs:35)...
unmounting /lib (mfs:24)...
unmounting /f10 (mfs:21)...
unmounting /tmp (mfs:15)...
unmounting /kern (kernfs)...
unmounting / (/dev/md0a)... done
rebooting...
Dell#show dcb stack-unit 0 port-set 0
stack-unit 0 port-set 0
DCB Status: Enabled, PFC Queue Count: 4

```

	stack-unit	Total	Buffer	PFC	Total	Buffer	PFC	Shared	Buffer	PFC	Available	Buffer
	PP		(KB)			(KB)			(KB)			(KB)
0	0	3822		1912		832			450			

Dell(conf)#



dcb-map stack-unit all stack-ports all

Apply the specified DCB map on all ports of the switch stack.

Syntax	<code>dcb-map stack-unit all stack-ports all <i>dcb-map-name</i></code> To remove the PFC and ETS settings in a DCB map from all stack units, use the <code>no dcb-map stack-unit all stack-ports all</code> command.	
Parameters	<i>dcb-map-name</i>	Enter the name of the DCB map.
Defaults	None	
Command Modes	CONFIGURATION	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Introduced on the FC Flex IO Modules with I/O Aggregator.
Usage Information	The <code>dcb-map stack-unit all stack-ports all</code> command overwrites any previous DCB maps applied to stack ports.	

dcbx-port role

Configure the DCBX port role the interface uses to exchange DCB information.

Syntax	<code>dcbx port-role {config-source auto-downstream auto-upstream manual}</code> To remove DCBX port role, use the <code>no dcbx port-role {config-source auto-downstream auto-upstream manual}</code> command.	
Parameters	config-source auto-downstream auto-upstream manual	Enter the DCBX port role, where: • <code>config-source</code>: configures the port to serve as the configuration source on the switch. • <code>auto-upstream</code>: configures the port to receive a peer configuration. The configuration source is elected from auto-upstream ports. • <code>auto-downstream</code>: configures the port to accept the internally propagated DCB configuration from a configuration source. • <code>manual</code>: configures the port to operate only on administer-configured DCB parameters. The port does not accept a DCB configuration received from a peer or a local configuration source.
Defaults	Manual	
Command Modes	INTERFACE PROTOCOL LLDP	
Supported Modes	Programmable-Mux (PMUX)	



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Introduced on the FC Flex IO module installed in the M I/O Aggregator.
Usage Information	DCBX requires that you enable LLDP to advertise DCBX TLVs to peers.	
	Configure DCBX operation at the INTERFACE level on a switch or globally on the switch. To verify the DCBX configuration on a port, use the <code>show interface dcbx detail</code> command.	

dcbx version

Configure the DCBX version used on the interface.

Syntax	<code>dcbx version {auto cee cin ieee-v2.5}</code>
	To remove the DCBX version, use the <code>no dcbx version {auto cee cin ieee-v2.5}</code> command.

Parameters	auto cee cin ieee-v2.5	Enter the DCBX version type used on the interface, where:
		• <code>auto</code>: configures the port to operate using the DCBX version received from a peer. • <code>cee</code>: configures the port to use CEE (Intel 1.01). • <code>cin</code>: configures the port to use Cisco-Intel-Nuova (DCBX 1.0). • <code>ieee-v2.5</code>: configures the port to use IEEE 802.1az (Draft 2.5).

Defaults	Auto
Command Modes	INTERFACE PROTOCOL LLDP
Supported Modes	All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Introduced on the FC Flex IO module installed in the M I/O Aggregator.

Usage Information	DCBX requires that you enable LLDP to advertise DCBX TLVs to peers.	
	Configure DCBX operation at the INTERFACE level on a switch or globally on the switch. To verify the DCBX configuration on a port, use the <code>show interface dcbx detail</code> command.	



debug dcbx

Enable DCBX debugging.

Syntax `debug dcbx {all | auto-detect-timer | config-exchng | fail | mgmt | resource | sem | tlv}`

To disable DCBX debugging, use the `no debug dcbx` command.

Parameters

`{all | auto-detect-timer | config-exchng | fail | mgmt | resource | sem | tlv}`

Enter the type of debugging, where:

- `all`: enables all DCBX debugging operations.
- `auto-detect-timer`: enables traces for DCBX auto-detect timers.
- `config-exchng`: enables traces for DCBX configuration exchanges.
- `fail`: enables traces for DCBX failures.
- `mgmt`: enables traces for DCBX management frames.
- `resource`: enables traces for DCBX system resource frames.
- `sem`: enables traces for the DCBX state machine.
- `tlv`: enables traces for DCBX TLVs.

Defaults `none`

Command Modes EXEC Privilege

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.3(0.0)	Introduced on the FC Flex IO module installed in the M I/O Aggregator.

fc-map

In an FCoE map, configure the FCoE mapped address prefix (FC-MAP) value which is used to identify FCoE traffic transmitted on the FCoE VLAN for the specified fabric.

Syntax `fc-map fc-map-value`

Parameters

fc-map-value

Enter the unique MAC address prefix used by a SAN fabric.
The range of FC-MAP values is from 0EFC00 to 0EFCFF.

Defaults `None`

Command Modes FCoE MAP

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.6(0.0)	Supported on the FN 2210S Aggregator.



Version	Description
9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.

Usage Information	The FC-MAP value you enter must match the FC-MAP value used by an FC switch or FCoE forwarder (FCF) in the fabric. An FCF switch accepts only FCoE traffic that uses the correct FC-MAP value. The FC-MAP value is used to generate the fabric-provided MAC address (FP-MAC). The FPMA is used by servers to transmit FCoE traffic to the fabric. An FC-MAP can be associated with only one FCoE VLAN and vice versa. In an FCoE map, the FC-MAP value, fabric ID, and FCoE VLAN parameters must be unique. To remove a configured FC-MAP value from an FCoE map, enter the <code>no fcoe-map</code> command.
Related Commands	fcoe-map — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.

fcoe-map

Create an FCoE map which contains the parameters used to configure the links between server CNAs and a SAN fabric. Apply the FCoE map on a server-facing Ethernet port.

Syntax	<code>fcoe-map map-name</code>	
Parameters	map-name	Maximum: 32 alphanumeric characters.
Defaults	On the FN2210S Aggregator with PMUX modules, the following parameters are applied on all the PMUX module interfaces: • Description: SAN_FABRIC • Fabric-id: 1002 • Fcoe-vlan: 1002 • Fc-map: 0x0efc00 • Fcf-priority: 128 • Fka-adv-period: 8000mSec • Keepalive: enable • Vlan priority: 3	
Command Modes	CONFIGURATION INTERFACE	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.6(0.0)	Supported on the FN2210S Aggregator.



Version	Description
9.3(0.0)	Introduced on the M I/O Aggregator.

Usage Information	An FCoE map is a template used to map FCoE and FC parameters in a converged fabric. An FCoE map is used to virtualize upstream FC ports on an FN2210S Aggregator with the PMUX module NPIV proxy gateway so that they appear to downstream server CNA ports as FCoE forwarder (FCF) ports on an FCoE network. When applied to FC and Ethernet ports on an NPIV proxy gateway, an FCoE map allows the switch to operate as an FCoE-FC bridge between an FC SAN and an FCoE network by providing FCoE-enabled servers and switches with the necessary parameters to log in to a SAN fabric. On an FN2210S Aggregator a with the PMUX module NPIV proxy gateway, you cannot apply an FCoE map applied on fabric-facing FC ports and server-facing 10-Gigabit Ethernet ports. An FCoE map consists of the following parameters: the dedicated FCoE VLAN used for storage traffic, the destination SAN fabric (FC-MAP value), FCF priority used by a server, and the FIP keepalive (FKA) advertisement timeout. In each FCoE map, the fabric ID, FC-MAP value, and FCoE VLAN parameters must be unique. Use one FCoE map to access one SAN fabric. You cannot use the same FCoE map to access different fabrics. To remove an FCoE map from an Ethernet interface, enter the <code>no fcoe-map map-name</code> command in Interface configuration mode.
--------------------------	---

fcoe priority-bits

Configure the FCoE priority advertised for the FCoE protocol in application priority TLVs.

Syntax	<code>fcoe priority-bits priority-bitmap</code> To remove the configured FCoE priority, use the <code>no fcoe priority-bits</code> command.
---------------	--

Parameters	<i>priority-bitmap</i> Enter the priority-bitmap range. The range is from 1 to FF.
-------------------	---

Defaults 0x8

Command Modes PROTOCOL LLDP

Supported Modes Programmable-Mux (PMUX)

Command History	<table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr> <tr> <td>9.3(0.0)</td><td>Introduced on the FC Flex IO module installed in the M I/O Aggregator.</td></tr> </table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.3(0.0)	Introduced on the FC Flex IO module installed in the M I/O Aggregator.
Version	Description						
9.4(0.0)	Supported on the FN I/O Aggregator.						
9.3(0.0)	Introduced on the FC Flex IO module installed in the M I/O Aggregator.						

Usage Information	This command is available at the global level only.
--------------------------	---



iscsi priority-bits

Configure the iSCSI priority advertised for the iSCSI protocol in application priority TLVs.

Syntax `iscsi priority-bits priority-bitmap`
To remove the configured iSCSI priority, use the `no iscsi priority-bits` command.

Parameters `priority-bitmap` Enter the priority-bitmap range. The range is from 1 to FF.

Defaults 0x10

Command Modes PROTOCOL LLDP

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Introduced on the FC Flex IO module installed in the M I/O Aggregator.

Usage Information This command is available at the global level only.

keepalive

Send keepalive packets periodically to keep an interface alive when it is not transmitting data.

Syntax `keepalive [seconds]`
To stop sending keepalive packets, use the `no keepalive` command.

Parameters `seconds` (OPTIONAL) For interfaces with PPP encapsulation enabled, enter the number of seconds between keepalive packets. The range is from 0 to 23767. The default is **10 seconds**.

Defaults Enabled.

Command Modes INTERFACE

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Introduced on the M I/O Aggregator.

Usage Information When you configure `keepalive`, the system sends a self-addressed packet out of the configured interface to verify that the far end of a WAN link is up. When you configure `no keepalive`, the system does not send keepalive packets and so the local end of a WAN link remains up even if the remote end is down.



interface vlan (NPIV proxy gateway)

Create a dedicated VLAN to be used to send and receive Fibre Channel traffic over FCoE links between servers and a fabric over an Aggregator with the PMUX module of NPIV proxy gateway.

Syntax `interface vlan vlan-id`

Parameters `vlan-id` Enter a number as the VLAN Identifier. The range is 1 to 4094.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Introduced on the FN I/O Aggregator.
	9.3(0.0)	Introduced on the M I/O Aggregator.

Usage Information FCoE storage traffic received from servers on an M I/O Aggregator with the PMUX module NPIV proxy gateway is de-capsulated into Fibre Channel packets and forwarded over FC links to SAN switches in a specified fabric. You must configure a separate FCoE VLAN for each fabric to which FCoE traffic is forwarded. Any non-FCoE traffic sent on a dedicated FCoE VLAN will be dropped.

You configure the association between a dedicated VLAN, which carries FCoE traffic from server CNAs over the NPIV proxy gateway to a SAN fabric in which destination storage arrays are installed, in an FCoE map by using the `fabric id vlan` command.

When you apply an FCoE map to a server-facing Ethernet port, the port is automatically configured as a tagged member of the FCoE VLAN.

For more information about VLANs and the commands to configure them, refer to the [Virtual LAN \(VLAN\) Commands](#) section.

Example (Single Range)

```
Dell(conf)#interface vlan 10
Dell(conf-if-v1-3)#
```

Related Commands [fcoe-map](#) — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.

pfc mode on

Enable the PFC configuration on the port so that the priorities are included in DCBX negotiation with peer PFC devices.

Syntax `pfc mode on`
To disable the PFC configuration, use the `no pfc mode on` command.

Defaults PFC mode is on.

Command Modes DCB MAP



Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Introduced on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
Usage Information	By applying a DCB input policy with PFC enabled, you enable PFC operation on ingress port traffic. To achieve complete lossless handling of traffic, also enable PFC on all DCB egress ports or configure the dot1p priority-queue assignment of PFC priorities to lossless queues (refer to <code>pfc no-drop queues</code>). To disable PFC operation on an interface, enter the <code>no pfc mode on</code> command in DCB Input Policy Configuration mode. PFC is enabled and disabled as global DCB operation is enabled (<code>dcb-enable</code>) or disabled (<code>no dcb-enable</code>). You cannot enable PFC and link-level flow control at the same time on an interface.	

pfc no-drop queues

Configure the port queues that still function as no-drop queues for lossless traffic.

Syntax	pfc no-drop queues <i>queue-range</i> To remove the no-drop port queues, use the <code>no pfc no-drop queues</code> command.									
Parameters	<i>queue-range</i>	Enter the queue range. Separate the queue values with a comma; specify a priority range with a dash; for example, <code>pfc no-drop queues 1,3</code> or <code>pfc no-drop queues 2-3</code>. The range is from 0 to 3.								
Defaults	No lossless queues are configured.									
Command Modes	INTERFACE									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.	
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									
Usage Information	The maximum number of lossless queues globally supported on the switch is two. The following lists the dot1p priority-queue assignments. <table><tr><th>dot1p Value in the Incoming Frame</th><th>Description heading</th></tr><tr><td>0</td><td>0</td></tr></table>		dot1p Value in the Incoming Frame	Description heading	0	0				
dot1p Value in the Incoming Frame	Description heading									
0	0									



dot1p Value in the Incoming Frame	Description heading
1	0
2	0
3	1
4	2
5	3
6	3
7	3

pfc priority

Configure the CoS traffic to be stopped for the specified delay.

Syntax `pfc priority priority-range`
To delete the pfc priority configuration, use the `no pfc priority` command.

Parameters *priority-range* Enter the 802.1p values of the frames to be paused. Separate the priority values with a comma; specify a priority range with a dash; for example, `pfc priority 1,3,5-7`. The range is from 0 to 7.

Defaults none

Command Modes Interface

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information You can enable any number of 802.1p priorities for PFC. Queues to which PFC priority traffic is mapped are lossless by default. Traffic may be interrupted due to an interface flap (going down and coming up) when you reconfigure the lossless queues for no-drop priorities in a PFC input policy and reapply the policy to an interface.

The maximum number of lossless queues supported on the I/O Aggregator switch is four.

A PFC peer must support the configured priority traffic (as DCBX detects) to apply PFC.



priority-group

To use with an ETS output policy, create an ETS priority group.

Syntax `priority-group group-name`

To remove the priority group, use the `no priority-group` command.

Parameters `group-name` Enter the name of the ETS priority group. The maximum is 32 characters.

Defaults none

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information A priority group consists of 802.1p priority values that are grouped for similar bandwidth allocation and scheduling, and that share latency and loss requirements. All 802.1p priorities mapped to the same queue must be in the same priority group.

You must configure 802.1p priorities in priority groups associated with an ETS output policy. You can assign each dot1p priority to only one priority group.

The maximum number of priority groups supported in ETS output policies on an interface is equal to the number of data queues (4) on the port. The 802.1p priorities in a priority group can map to multiple queues.

If you configure more than one priority queue as strict priority or more than one priority group as strict priority, the higher numbered priority queue is given preference when scheduling data traffic.

priority-group bandwidth pfc

Configure the ETS bandwidth allocation and PFC mode used to manage port traffic in an 802.1p priority group.

Syntax `priority-group group-num {bandwidth percentage| strict-priority} pfc {on | off}`

Parameters <code>priority-group group-num</code>	Enter the keyword <code>priority-group</code> followed by the number of an 802.1p priority group. Use the <code>priority-pgid</code> command to create the priority groups in a DCB map.
<code>bandwidth percentage</code>	Enter the keyword <code>bandwidth</code> followed by a bandwidth percentage allocated to the priority group. The range of valid values is 1 to 100. The sum of all allocated bandwidth percentages in priority groups in a DCB map must be 100%.



strict-priority	Configure the priority-group traffic to be handled with strict priority scheduling. Strict-priority traffic is serviced first, before bandwidth allocated to other priority groups is made available.
pfc {on off}	Configure whether priority-based flow control is enabled (on) or disabled (off) for port traffic in the priority group.

Defaults None

Command Modes DCB MAP

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.3(0.0)	Introduced on the FC Flex IO module installed in the M I/O Aggregator.

Usage Information

Use the `dcb-map` command to configure priority groups with PFC and/or ETS settings and apply them to Ethernet interfaces.

Use the `priority-pgid` command to map 802.1p priorities to a priority group. You can assign each 802.1p priority to only one priority group. A priority group consists of 802.1p priority values that are grouped together for similar bandwidth allocation and scheduling, and that share latency and loss requirements. All 802.1p priorities mapped to the same queue must be in the same priority group.

Repeat the `priority-group bandwidth pfc` command to configure PFC and ETS traffic handling for each priority group in a DCB map.

You can enable PFC on a maximum of two priority queues.

If you configure more than one priority group as strict priority, the higher numbered priority queue is given preference when scheduling data traffic.

If a priority group does not use its allocated bandwidth, the unused bandwidth is made available to other priority groups.

To remove a priority-group configuration in a DCB map, enter the `no priority-group bandwidth pfc` command.

By default, equal bandwidth is assigned to each dot1p priority in a priority group. Use the `bandwidth` parameter to configure the bandwidth percentage assigned to a priority group. The sum of the bandwidth allocated to all priority groups in a DCB map must be 100% of the bandwidth on the link. You must allocate at least 1% of the total port bandwidth to each priority group.

Related Commands

[priority-pgid](#) – Configures the 802.1p priority traffic in a priority group for a DCB map.



priority-pgid

Assign 802.1p priority traffic to a priority group in a DCB map.

Syntax `priority-pgid dot1p0_group-num dot1p1_group-num dot1p2_group-num dot1p3_group-num dot1p4_group-num dot1p5_group-num dot1p6_group-num dot1p7_group-num`

Parameters

`dot1p0_group-num` Enter the priority group number for each 802.1p class of traffic in a DCB map.

`dot1p1_group-num`

`dot1p2_group-num`

`dot1p3_group-num`

`dot1p4_group-num`

`dot1p5_group-num`

`dot1p6_group-num`

`dot1p7_group-num`

Defaults None

Command Modes DCB MAP

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Introduced on the FC Flex IO module installed in the M I/O Aggregator.

Usage Information PFC and ETS settings are not pre-configured on Ethernet ports. You must use the `dcb-map` command to configure different groups of 802.1p priorities with PFC and ETS settings.

Using the `priority-pgid` command, you assign each 802.1p priority to one priority group. A priority group consists of 802.1p priority values that are grouped together for similar bandwidth allocation and scheduling, and that share latency and loss requirements. All 802.1p priorities mapped to the same queue must be in the same priority group. For example, the `priority-pgid 0 0 0 1 2 4 4 4` command creates the following groups of 802.1p priority traffic:

- Priority group 0 contains traffic with dot1p priorities 0, 1, and 2.
- Priority group 1 contains traffic with dot1p priority 3.
- Priority group 2 contains traffic with dot1p priority 4.
- Priority group 4 contains traffic with dot1p priority 5, 6, and 7.

To remove a `priority-pgid` configuration from a DCB map, enter the `no priority-pgid` command.

Related Commands [priority-group bandwidth pfc](#)— Configures the ETS bandwidth allocation and the PFC setting used to manage the port traffic in an 802.1p priority group.



qos-policy-output ets

To configure the ETS bandwidth allocation and scheduling for priority traffic, create a QoS output policy.

Syntax `qos-policy-output policy-name ets`
To remove the QoS output policy, use the `no qos-policy-output ets` command.

Parameters *policy-name* Enter the policy name. The maximum is 32 characters.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information If an error occurs in an ETS output-policy configuration, the configuration is ignored and the scheduler and bandwidth allocation settings are reset to the ETS default values (all priorities are in the same ETS priority group and bandwidth is allocated equally to each priority).

If an error occurs when a port receives a peer's ETS configuration, the port's configuration is reset to the previously configured ETS output policy. If no ETS output policy was previously applied, the port is reset to the default ETS parameters.

Related Commands

- [scheduler](#) — schedules the priority traffic in port queues.
- [bandwidth-percentage](#) — bandwidth percentage allocated to the priority traffic in port queues.

scheduler

Configure the method used to schedule priority traffic in port queues.

Syntax `scheduler value`
To remove the configured priority schedule, use the `no scheduler` command.

Parameters *value* Enter schedule priority value. The valid values are:

- `strict`: strict-priority traffic is serviced before any other queued traffic.
- `werr`: weighted elastic round robin (werr) provides low-latency scheduling for priority traffic on port queues.

Defaults Weighted elastic round robin (WERR) scheduling is used to queue priority traffic.

Command Modes POLICY-MAP-OUT-ETS

Supported Modes Programmable-Mux (PMUX)



Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information

dot1p priority traffic on the switch is scheduled to the current queue mapping. dot1p priorities within the same queue must have the same traffic properties and scheduling method.

ETS-assigned scheduling applies only to data queues, not to control queues.

The configuration of bandwidth allocation and strict-queue scheduling is not supported at the same time for a priority group. If you configure both, the configured bandwidth allocation is ignored for priority-group traffic when you apply the output policy on an interface.

Related Commands

- [bandwidth-percentage](#) — bandwidth percentage allocated to priority traffic in port queues.

show dcb

Displays the data center bridging status, the number of PFC-enabled ports, and the number of PFC-enabled queues.

Syntax `show dcb [stack-unit unit-number]`

Parameters
unit number Enter the DCB unit number. The range is from 0 to 5.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information Specify a stack-unit number on the Master switch in a stack.

Example

```
Dell#show dcb
stack-unit 0 port-set 0
DCB Status                               : Enabled
PFC Queue Count                          :      2
Total Buffer[lossy + lossless] (in KB)   :    3822
PFC Total Buffer (in KB)                  :    1912
PFC Shared Buffer (in KB)                  :     832
PFC Available Buffer (in KB)               :   1080
```



show interface dcbx detail

Displays the DCBX configuration on an interface.

Syntax `show interface port-type slot/port dcbx detail`

Parameters

<i>port-type</i>	Enter the port type.
<i>slot/port</i>	Enter the slot/port number.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information To clear DCBX frame counters, use the `clear dcbx counters interface stack-unit/port` command.

The following describes the `show interface dcbx detail` command shown in the following example.

Field	Description
Interface	Interface type with chassis slot and port number.
Port-Role	Configured the DCBX port role: auto-upstream, auto-downstream, config-source, or manual.
DCBX Operational Status	Operational status (enabled or disabled) used to elect a configuration source and internally propagate a DCB configuration. The DCBX operational status is the combination of PFC and ETS operational status.
Configuration Source	Specifies whether the port serves as the DCBX configuration source on the switch: true (yes) or false (no).
Local DCBX Compatibility mode	DCBX version accepted in a DCB configuration as compatible. In auto-upstream mode, a port can only receive a DCBX version supported on the remote peer.
Local DCBX Configured mode	DCBX version configured on the port: CEE, CIN, IEEE v2.5, or Auto (port auto-configures to use the DCBX version received from a peer).
Peer Operating version	DCBX version that the peer uses to exchange DCB parameters.
Local DCBX TLVs Transmitted	Transmission status (enabled or disabled) of advertised DCB TLVs (see TLV code at the top of the show command output).
Local DCBX Status: DCBX Operational Version	DCBX version advertised in Control TLVs.
Local DCBX Status: DCBX Max Version Supported	Highest DCBX version supported in Control TLVs.



Field	Description
Local DCBX Status: Sequence Number	Sequence number transmitted in Control TLVs.
Local DCBX Status: Acknowledgment Number	Acknowledgement number transmitted in Control TLVs.
Local DCBX Status: Protocol State	Current operational state of the DCBX protocol: ACK or IN-SYNC.
Peer DCBX Status: DCBX Operational Version	DCBX version advertised in Control TLVs received from the peer device.
Peer DCBX Status: DCBX Max Version Supported	Highest DCBX version supported in Control TLVs received from the peer device.
Peer DCBX Status: Sequence Number	Sequence number transmitted in Control TLVs received from the peer device.
Peer DCBX Status: Acknowledgment Number	Acknowledgement number transmitted in Control TLVs received from the peer device.
Total DCBX Frames transmitted	Number of DCBX frames sent from the local port.
Total DCBX Frames received	Number of DCBX frames received from the remote peer port.
Total DCBX Frame errors	Number of DCBX frames with errors received.
Total DCBX Frames unrecognized	Number of unrecognizable DCBX frames received.

Example

```
Dell(conf)# show interface tengigabitethernet 0/49 dcbx detail
Dell#show interface te 0/49 dcbx detail

E-ETS Configuration TLV enabled
  e-ETS Configuration TLV disabled
R-ETS Recommendation TLV enabled
  r-ETS Recommendation TLV disabled
P-PFC Configuration TLV enabled
  p-PFC Configuration TLV disabled
F-Application priority for FCOE enabled
  f-Application Priority for FCOE disabled
I-Application priority for iSCSI enabled
  i-Application Priority for iSCSI disabled
-----

Interface TenGigabitEthernet 0/49
  Remote Mac Address 00:00:00:00:00:11
  Port Role is Auto-Upstream
  DCBX Operational Status is Enabled
  Is Configuration Source? TRUE

Local DCBX Compatibility mode is CEE
  Local DCBX Configured mode is CEE
  Peer Operating version is CEE
  Local DCBX TLVs Transmitted: ErPfi
```



```

Local DCBX Status
-----
DCBX Operational Version is 0
DCBX Max Version Supported is 0
Sequence Number: 2
Acknowledgment Number: 2
Protocol State: In-Sync

Peer DCBX Status:
-----
DCBX Operational Version is 0
DCBX Max Version Supported is 255
Sequence Number: 2
Acknowledgment Number: 2
Total DCBX Frames transmitted 27
Total DCBX Frames received 6
Total DCBX Frame errors 0
Total DCBX Frames unrecognized 0

```

show interface ets

Displays the ETS configuration applied to egress traffic on an interface, including priority groups with priorities and bandwidth allocation.

Syntax `show interface port-type slot/port ets {summary | detail}`

Parameters

<i>port-type slot/port</i>	Enter the port-type slot and port ETS information.
ets	
{summary detail}	Enter the keyword <code>summary</code> for a summary list of results or enter the keyword <code>detail</code> for a full list of results.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	
Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information To clear ETS TLV counters, use the `clear ets counters interface port-type slot/port` command.

The following describes the `show interface summary` command shown in the following example.

Field	Description
Interface	Interface type with stack-unit and port number.
Max Supported TC Group	Maximum number of priority groups supported.
Number of Traffic Classes	Number of 802.1p priorities currently configured.



Field	Description
Admin mode	ETS mode: on or off. When on, the scheduling and bandwidth allocation configured in an ETS output policy or received in a DCBX TLV from a peer can take effect on an interface.
Admin Parameters	ETS configuration on local port, including priority groups, assigned dot1p priorities, and bandwidth allocation.
Remote Parameters	ETS configuration on remote peer port, including admin mode (enabled if a valid TLV was received or disabled), priority groups, assigned dot1p priorities, and bandwidth allocation. If ETS admin mode is enabled on the remote port for DCBX exchange, the Willing bit received in ETS TLVs from the remote peer is included.
Local Parameters	ETS configuration on local port, including admin mode (enabled when a valid TLV is received from a peer), priority groups, assigned dot1p priorities, and bandwidth allocation.
Operational status (local port)	Port state for current operational ETS configuration: • <code>Init</code>: Local ETS configuration parameters were exchanged with the peer. • <code>Recommend</code>: Remote ETS configuration parameters were received from the peer. • <code>Internally propagated</code>: ETS configuration parameters were received from the configuration source.
ETS DCBX Oper status	Operational status of the ETS configuration on the local port: match or mismatch.
Reason	Reason displayed when the DCBx operational status for ETS on a port is down.
State Machine Type	Type of state machine used for DCBX exchanges of ETS parameters: Feature — for legacy DCBX versions; Asymmetric — for an IEEE version.
Conf TLV Tx Status	Status of ETS Configuration TLV advertisements: enabled or disabled.
ETS TLV Statistic: Input Conf TLV pkts	Number of ETS Configuration TLVs received.
ETS TLV Statistic: Output Conf TLV pkts	Number of ETS Configuration TLVs transmitted.
ETS TLV Statistic: Error Conf TLV pkts	Number of ETS Error Configuration TLVs received.

Example (Summary)

```

Dell(conf)# show interfaces te 0/1 ets summary
Interface TenGigabitEthernet 0/1
Max Supported TC Groups is 4
Number of Traffic Classes is 8
Admin mode is on
Admin Parameters:
-----
Admin is enabled
TC-grp Priority#      Bandwidth TSA
0      0,1,2,3,4,5,6,7 100%    ETS
1              0%      ETS
2              0%      ETS
3              0%      ETS
4              0%      ETS
5              0%      ETS
6              0%      ETS
7              0%      ETS

```



```

Priority#           Bandwidth  TSA
0                   13%        ETS
1                   13%        ETS
2                   13%        ETS
3                   13%        ETS
4                   12%        ETS
5                   12%        ETS
6                   12%        ETS
7                   12%        ETS
Remote Parameters:
-----
Remote is disabled
Local Parameters:
-----
Local is enabled
TC-grp Priority#     Bandwidth  TSA
0           0,1,2,3,4,5,6,7 100%      ETS
1           0%              ETS
2           0%              ETS
3           0%              ETS
4           0%              ETS
5           0%              ETS
6           0%              ETS
7           0%              ETS
Priority#           Bandwidth  TSA
0                   13%        ETS
1                   13%        ETS
2                   13%        ETS
3                   13%        ETS
4                   12%        ETS
5                   12%        ETS
6                   12%        ETS
7                   12%        ETS
Oper status is init
Conf TLV Tx Status is disabled
Traffic Class TLV Tx Status is disabled

```

Example (Detail)

```

Dell(conf)# show interfaces tengigabitethernet 0/1 ets detail
Interface TenGigabitEthernet 0/1
Max Supported TC Groups is 4
Number of Traffic Classes is 8
Admin mode is on
Admin Parameters :
-----
Admin is enabled
TC-grp Priority#     Bandwidth  TSA
0           0,1,2,3,4,5,6,7 100%      ETS
1           0%              ETS
2           0%              ETS
3           0%              ETS
4           0%              ETS
5           0%              ETS
6           0%              ETS
7           0%              ETS

Priority#           Bandwidth  TSA
0                   13%        ETS
1                   13%        ETS
2                   13%        ETS
3                   13%        ETS
4                   12%        ETS
5                   12%        ETS
6                   12%        ETS
7                   12%        ETS
Remote Parameters:
-----
Remote is disabled

```



```

Local Parameters :
-----
Local is enabled
TC-grp Priority#      Bandwidth TSA
0      0,1,2,3,4,5,6,7 100%    ETS
1      0%              ETS
2      0%              ETS
3      0%              ETS
4      0%              ETS
5      0%              ETS
6      0%              ETS
7      0%              ETS

Priority#             Bandwidth TSA
0      13%            ETS
1      13%            ETS
2      13%            ETS
3      13%            ETS
4      12%            ETS
5      12%            ETS
6      12%            ETS
7      12%            ETS

Oper status is init
ETS DCBX Oper status is Down
Reason: Port Shutdown
State Machine Type is Asymmetric
Conf TLV Tx Status is enabled
Reco TLV Tx Status is enabled
0 Input Conf TLV Pkts, 0 Output Conf TLV Pkts, 0 Error Conf TLV Pkts
0 Input Traffic Class TLV Pkts, 0 Output Traffic Class TLV Pkts, 0 Error
Traffic Class
TLV Pkts

```

show interface pfc

Displays the PFC configuration applied to ingress traffic on an interface, including priorities and link delay.

Syntax `show interface port-type slot/port pfc {summary | detail}`

Parameters

<i>port-type slot/ port</i>	Enter the port-type slot and port PFC information.
<i>pfc</i>	
{summary detail}	Enter the keyword <code>summary</code> for a summary list of results or enter the keyword <code>detail</code> for a full list of results.

Command Modes INTERFACE

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information To clear the PFC TLV counters, use the `clear pfc counters interface port-type slot/port` command.



The following describes the `show interface pfc summary` command shown in the following example.

Field	Description
Interface	Interface type with stack-unit and port number.
Admin mode is on Admin is enabled	PFC admin mode is on or off with a list of the configured PFC priorities. When the PFC admin mode is on, PFC advertisements are enabled to be sent and received from peers; received PFC configuration take effect. The admin operational status for a DCBX exchange of PFC configuration is enabled or disabled.
Remote is enabled, Priority list Remote Willing Status is enabled	Operational status (enabled or disabled) of peer device for DCBX exchange of PFC configuration with a list of the configured PFC priorities. Willing status of peer device for DCBX exchange (Willing bit received in PFC TLV): enabled or disable.
Local is enabled	DCBX operational status (enabled or disabled) with a list of the configured PFC priorities.
Operational status (local port)	Port state for current operational PFC configuration: • <code>Init</code>: Local PFC configuration parameters were exchanged with the peer. • <code>Recommend</code>: Remote PFC configuration parameters were received from the peer. • <code>Internally propagated</code>: PFC configuration parameters were received from the configuration source.
PFC DCBX Oper status	Operational status for the exchange of the PFC configuration on the local port: match (up) or mismatch (down).
Reason	Reason displayed when the DCBx operational status for PFC on a port is down.
State Machine Type	Type of state machine used for DCBX exchanges of the PFC parameters: Feature — for legacy DCBX versions; Symmetric — for an IEEE version.
TLV Tx Status	Status of the PFC TLV advertisements: enabled or disabled.
PFC Link Delay	Link delay (in quanta) used to pause specified priority traffic.
Application Priority TLV: FCOE TLV Tx Status	Status of FCoE advertisements in application priority TLVs from the local DCBX port: enabled or disabled.
Application Priority TLV: SCSI TLV Tx Status	Status of iSCSI advertisements in application priority TLVs from the local DCBX port: enabled or disabled.
Application Priority TLV: Local FCOE Priority Map	Priority bitmap the local DCBX port uses in FCoE advertisements in application priority TLVs.
Application Priority TLV: Local iSCSI Priority Map	Priority bitmap the local DCBX port uses in iSCSI advertisements in application priority TLVs.
Application Priority TLV: Remote FCOE Priority Map	Status of FCoE advertisements in application priority TLVs from the remote peer port: enabled or disabled.
Application Priority TLV: Remote iSCSI Priority Map	Status of iSCSI advertisements in application priority TLVs from the remote peer port: enabled or disabled.



Field	Description
PFC TLV Statistics: Input TLV pkts	Number of PFC TLVs received.
PFC TLV Statistics: Output TLV pkts	Number of PFC TLVs transmitted.
PFC TLV Statistics: Error pkts	Number of PFC error packets received.
PFC TLV Statistics: Pause Tx pkts	Number of PFC pause frames transmitted.
PFC TLV Statistics: Pause Rx pkts	Number of PFC pause frames received.

Example (Summary)

```

Dell# show interfaces tengigabitethernet 0/4 pfc summary
Interface TenGigabitEthernet 0/4
  Admin mode is on
  Admin is enabled
  Remote is enabled, Priority list is 4
  Remote Willing Status is enabled
  Local is enabled
  Oper status is Recommended
  PFC DCBX Oper status is Up
  State Machine Type is Feature
  TLV Tx Status is enabled
  PFC Link Delay 45556 pause quantams
  Application Priority TLV Parameters :
  -----
  FCOE TLV Tx Status is disabled
  ISCSI TLV Tx Status is disabled
  Local FCOE PriorityMap is 0x8
  Local ISCSI PriorityMap is 0x10
  Remote FCOE PriorityMap is 0x8
  Remote ISCSI PriorityMap is 0x8

Dell# show interfaces tengigabitethernet 0/4 pfc detail
Interface TenGigabitEthernet 0/4
  Admin mode is on
  Admin is enabled
  Remote is enabled
  Remote Willing Status is enabled
  Local is enabled
  Oper status is recommended
  PFC DCBX Oper status is Up
  State Machine Type is Feature
  TLV Tx Status is enabled
  PFC Link Delay 45556 pause quanta
  Application Priority TLV Parameters :
  -----
  FCOE TLV Tx Status is disabled
  ISCSI TLV Tx Status is disabled
  Local FCOE PriorityMap is 0x8
  Local ISCSI PriorityMap is 0x10
  Remote FCOE PriorityMap is 0x8
  Remote ISCSI PriorityMap is 0x8
  0 Input TLV pkts, 1 Output TLV pkts, 0 Error pkts,
  0 Pause Tx pkts, 0 Pause Rx pkts

```



show interface pfc statistics

Displays counters for the PFC frames received and transmitted (by dot1p priority class) on an interface.

Syntax `show interface port-type slot/port pfc statistics`

Parameters

<i>port-type</i>	Enter the port type.
<i>slot/port</i>	Enter the slot/port number.

Command Modes INTERFACE

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O aggregator. This command is supported in Programmable-Mux (PMUX) mode only.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Example (Summary) Dell#show interfaces te 0/3 pfc statistics
Interface TenGigabitEthernet 0/3

Priority	Rx XOFF	Frames Rx	Total Frames	Tx	Total Frames
0	0	0	0	0	0
1	0	0	0	0	0
2	0	0	0	0	0
3	0	0	0	0	0
4	0	0	0	0	0
5	0	0	0	0	0
6	0	0	0	0	0
7	0	0	0	0	0

show qos dcb-map

Display the DCB parameters configured in a specified DCB map.

Syntax `show qos dcb-map map-name`

Parameters

<i>map-name</i>	Displays the PFC and ETS parameters configured in the specified map.
-----------------	--

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.6(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.



Usage Information Use the `show qos dcb-map` command to display the enhanced transmission selection (ETS) and priority-based flow control (PFC) parameters used to configure server-facing Ethernet ports.

The following table describes the `show qos dcb-map` output shown in the example below.

Field	Description
State	Complete: All mandatory DCB parameters are correctly configured. In progress: The DCB map configuration is not complete. Some mandatory parameters are not configured.
PFC Mode	PFC configuration in DCB map: On (enabled) or Off.
PG	Priority group configured in the DCB map.
TSA	Transmission scheduling algorithm used by the priority group: Enhanced Transmission Selection (ETS).
BW	Percentage of bandwidth allocated to the priority group.
PFC	PFC setting for the priority group: On (enabled) or Off.
Priorities	802.1p priorities configured in the priority group.

Example

```
Dell# show qos dcb-map dcbmap2

State      :Complete
PfcMode:ON
-----
PG:0 TSA:ETS BW:50 PFC:OFF
Priorities:0 1 2 4 5 6 7

PG:1 TSA:ETS BW:50 PFC:ON
Priorities:3
```

show stack-unit stack-ports ets details

Displays the ETS configuration applied to egress traffic on stacked ports, including ETS Operational mode on each unit and the configured priority groups with dot1p priorities, bandwidth allocation, and scheduler type.

Syntax `show stack-unit {all | stack-unit} stack-ports {all | port-number} ets details`

Parameters

<i>stack-unit</i>	Enter the stack unit identification.
<i>port-number</i>	Enter the port number.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History

Version	Description
---------	-------------

9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.



Version	Description
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Example

```
Dell(conf)# show stack-unit all stack-ports all ets details
```

```
Stack unit 0 stack port all
Max Supported TC Groups is 4
Number of Traffic Classes is 1
Admin mode is on
```

```
Admin Parameters:
```

```
-----
```

Admin is enabled			
TC-grp	Priority#	Bandwidth	TSA

0	0,1,2,3,4,5,6,7	100%	ETS
1		-	-
2		-	-
3		-	-
4		-	-
5		-	-
6		-	-
7		-	-
8		-	-

```
Stack unit 1 stack port all
Max Supported TC Groups is 4
Number of Traffic Classes is 1
Admin mode is on
Admin Parameters:
```

```
-----
```

Admin is enabled			
TC-grp	Priority#	Bandwidth	TSA

0	0,1,2,3,4,5,6,7	100%	ETS
1		-	-
2		-	-
3		-	-
4		-	-
5		-	-
6		-	-
7		-	-
8		-	-

show stack-unit stack-ports pfc details

Displays the PFC configuration applied to ingress traffic on stacked ports, including PFC Operational mode on each unit with the configured priorities, link delay, and number of pause packets sent and received.

Syntax `show stack-unit {all | stack-unit} stack-ports {all | port-number} pfc details`

Parameters

<i>stack-unit</i>	Enter the stack unit.
<i>port-number</i>	Enter the port number.

Command Modes CONFIGURATION

Supported Modes All Modes



Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Example

```
Dell(conf)# show stack-unit all stack-ports all pfc details

stack unit 0 stack-port all
  Admin mode is On
  Admin is enabled, Priority list is 4-5
  Local is enabled, Priority list is 4-5
  Link Delay 45556 pause quantum
  0 Pause Tx pkts, 0 Pause Rx pkts

stack unit 1 stack-port all
  Admin mode is On
  Admin is enabled, Priority list is 4-5
  Local is enabled, Priority list is 4-5
  Link Delay 45556 pause quantum
  0 Pause Tx pkts, 0 Pause Rx pkts
```



Dynamic Host Configuration Protocol

Dynamic host configuration protocol (DHCP) is an application layer protocol that dynamically assigns IP addresses and other configuration parameters to network end-stations (hosts) based on configuration policies determined by network administrators.

An Aggregator can operate as a DHCP client. As a DHCP client, the Aggregator requests an IP address from a DHCP server.

The following types of DHCP commands are described in this chapter:

- DHCP Client Commands
- Other Commands supported by DHCP Client

DHCP Client Commands

- [clear ip dhcp client statistics](#)
- [ip address dhcp](#)
- [release dhcp interface](#)
- [renew dhcp interface](#)
- [show ip dhcp client statistics](#)
- [show ip dhcp lease](#)

Other Commands supported by DHCP Client

- [debug ip dhcp client events](#)
- [debug ip dhcp client packets](#)

clear ip dhcp client statistics

Displays DHCP client statistics, including the number of DHCP messages sent and received on an interface.

Syntax `clear ip dhcp client statistics interface type slot/port`

Parameters

interface <i>type slot/port</i>	Clear DHCP client statistics on the specified interface. • For the management interface on the stack-unit, enter the keyword <code>managementethernet</code> followed by slot/port information. The slot and port range is 0. • For a VLAN, enter the keyword <code>vlan</code> followed by a number from 1 to 4094.
--	--

Command Modes EXEC Privilege

Supported Modes All Modes

Default None



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

debug ip dhcp client events

Enable the display of log messages for the following events on DHCP client interfaces:

- IP address acquisition
- IP address release
- Renewal of IP address and lease time
- Release of an IP address

Syntax `debug ip dhcp client events [interface type slot/port]`

Parameters

interface type slot/port	Display log messages for DHCP packets sent and received on the specified interface.
---------------------------------	---

- For the management interface on the stack-unit, enter the keyword `managementethernet` followed by slot/port information. The slot and port range is 0
- For a VLAN, enter the keyword `vlan` followed by a number from 1 to 4094.

Command Modes EXEC Privilege

Supported Modes All Modes

Default None

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

debug ip dhcp client packets

Enable the display of log messages for all DHCP packets sent and received on DHCP client interfaces.

Syntax `debug ip dhcp client packets [interface type slot/port]`

Parameters

interface type slot/port	Display log messages for DHCP packets sent and received on the specified interface.
---------------------------------	---

- For the management interface on the stack-unit, enter the keyword `managementethernet` followed by slot/port information. The slot and port range is 0



- For a VLAN, enter the keyword `vlan` followed by a number from 1 to 4094.

Command Modes EXEC Privilege

Supported Modes All Modes

Default None

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

ip address dhcp

Acquire an IP address dynamically on an interface from the DHCP server.

Syntax `ip address dhcp [relay | vendor-class-identifier]`
To disable DHCP Client on an interface, use the `no ip address dhcp` command.

Command Modes INTERFACE

Supported Modes All Modes

Default Enabled

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information In the I/O Aggregator, the DHCP client is enabled only on the default VLAN and management interface 0/0. Use the `ip address` command to assign a static IP address that overwrites the dynamically assigned IP address.

release dhcp interface

Release the dynamically-acquired IP address on an Ethernet interface while retaining the DHCP client configuration on the interface.

Syntax `release dhcp interface type slot/port`

Parameters

**interface type slot/
port**

- For the management interface on the stack-unit, enter the keyword `management ethernet` followed by slot/port information. The slot and port range is 0.
- For a VLAN, enter the keyword `vlan` followed by a number from 1 to 4094.

Command Modes EXEC Privilege



Supported Modes	All Modes	
Default	None	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.
Usage Information	When you enter the <code>release dhcp</code> command, although the IP address that was dynamically-acquired from a DHCP server is released from an interface, the ability to acquire a new DHCP server-assigned address remains in the running configuration for the interface. To acquire a new IP address, enter either the <code>renew dhcp</code> command at the EXEC privilege level or the <code>ip address dhcp</code> command at the interface configuration level.	

renew dhcp interface

Re-acquire a dynamic IP address on an Ethernet interface enabled as a DHCP client.

Syntax	<code>renew dhcp interface type slot/port</code>	
Parameters	interface type slot/port	Enter any of the following keywords and slot/port or number to clear counters from a specified interface: - For the management interface on the stack-unit, enter the keyword <code>managementethernet</code> followed by slot/port information. The slot and port range is 0. - For a VLAN, enter the keyword <code>vlan</code> followed by a number from 1 to 4094.
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Default	None.	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage information	The <code>renew dhcp</code> command is used to renew the lease of IP address obtained through dhcp. To display the currently configure dynamic IP address and lease time, enter the <code>show ip dhcp lease</code> command.	



show ip dhcp client statistics

Displays DHCP client statistics, including the number of DHCP messages sent and received on an interface.

Syntax `show ip dhcp client statistics interface type slot/port`

Parameters

interface type slot/port	Display DHCP client statistics on the specified interface.
	- For the management interface on the stack-unit, enter the keyword <code>managementethernet</code> followed by slot/port information. The slot and port range is 0. - For a VLAN, enter the keyword <code>vlan</code> followed by a number from 1 to 4094.

Command Modes EXEC Privilege

Supported Modes All Modes

Default None.

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

show ip dhcp lease

Displays lease information about the dynamic IP address currently assigned to a DHCP client-enabled interface.

Syntax `show ip dhcp lease[interface type slot/port]`

Parameters

interface type slot/port	Display DHCP client statistics on the specified interface.
	- For the management interface on the stack-unit, enter the keyword <code>managementethernet</code> followed by slot/port information. The slot and port range is 0. - For a VLAN, enter the keyword <code>vlan</code> followed by a number from 1 to 4094.

Command Modes EXEC Privilege

Supported Modes All Modes

Default Display DHCP lease information on all DHCP client-enabled interfaces on the switch.

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.



FC Flex IO Modules

This chapter provides a generic, broad-level description of the operations, capabilities, and configuration commands of the Fiber Channel (FC) Flex IO module.

Fibre Channel over Ethernet for FC Flex IO Modules

FCoE provides a converged Ethernet network that allows the combination of storage-area network (SAN) and LAN traffic on a Layer 2 link by encapsulating Fibre Channel data into Ethernet frames.

The Aggregator, installed with the FC Flex IO module, functions as a top-of-rack edge switch that supports converged enhanced Ethernet (CEE) traffic — Fibre channel over Ethernet (FCoE) for storage, Interprocess Communication (IPC) for servers, and Ethernet local area network (LAN) (IP cloud) for data — as well as FC links to one or more storage area network (SAN) fabrics.

FCoE works with the Ethernet enhancements provided in Data Center Bridging (DCB) to support lossless (no-drop) SAN and LAN traffic. In addition, DCB provides flexible bandwidth sharing for different traffic types, such as LAN and SAN, according to 802.1p priority classes of service. DCBx should be enabled on the system before the FIP snooping feature is enabled.

All of the commands that are supported for FCoE on the I/O Aggregator apply to the FC Flex IO modules. Similarly, all of the configuration procedures and the settings that are applicable for FCoE on the I/O Aggregator are valid for the FC Flex IO modules.

NPIV Proxy Gateway for FC Flex IO Modules

The N-port identifier virtualization (NPIV) Proxy Gateway (NPG) feature provides FCoE-FC bridging capability on the M I/O Aggregator with the FC Flex IO module switch, allowing server CNAs to communicate with SAN fabrics over the M I/O Aggregator with the FC Flex IO module.

To configure the M I/O Aggregator with the FC Flex IO module to operate as an NPIV proxy gateway, use the following commands:

description (for FCoE maps)

In an FCoE map, add a text description of the FCoE and FC parameters used to transmit storage traffic over an M I/O Aggregator with the FC Flex IO module NPIV proxy gateway in a converged fabric.

M I/O Aggregator with the FC Flex IO module

Syntax	<code>description text</code>	
Parameters	text	Enter a maximum of 32 characters.
Defaults	None	
Command Modes	FCOE MAP	

Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.
Usage Information	The text description is displayed in <code>show fcoe-map</code> command output.	
Related Commands	fcoe-map — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.	
	show fcoe-map — displays the Fibre Channel and FCoE configuration parameters in FCoE maps.	

fabric

Apply an FCoE map on a fabric-facing Fibre Channel (FC) port.

M I/O Aggregator with the FC Flex IO module

Syntax	<code>fabric map-name</code>	
Parameters	<i>map-name</i>	Maximum: 32 alphanumeric characters.
Defaults	None	
Command Modes	INTERFACE FIBRE_CHANNEL	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.

Usage Information

An FCoE map is a template used to map FCoE and FC parameters in a converged fabric. An FCoE map is used to virtualize upstream FC ports on an M I/O Aggregator with the FC Flex IO module NPIV proxy gateway so that they appear to downstream server CNA ports as FCoE forwarder (FCF) ports on an FCoE network. When applied to FC and Ethernet ports on an NPIV proxy gateway, an FCoE map allows the switch to operate as an FCoE-FC bridge between an FC SAN and an FCoE network by providing FCoE-enabled servers and switches with the necessary parameters to log in to a SAN fabric. Use the `fcoe-map` command to create an FCoE map.

On an M I/O Aggregator with the FC Flex IO module NPIV proxy gateway, you cannot apply an FCoE map on fabric-facing FC ports and server-facing Ethernet ports.

After you apply an FCoE map on an FC interface, when the port is enabled (`no shutdown`), the NPIV proxy gateway starts sending FIP multicast advertisements on behalf of the FC port to downstream servers in order to advertise the availability of a new FCF port on the FCoE VLAN.



To remove an FCoE map from an FC interface, enter the `no fabric map-name` command in Interface configuration mode.

Related Commands [fcoe-map](#) — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.

[show fcoe-map](#) — displays the Fibre Channel and FCoE configuration parameters in FCoE maps.

fabric-id vlan

In an FCoE map, configure the association between the dedicated VLAN used to carry FCoE traffic between servers and a SAN, and the fabric where the desired storage arrays are installed.

M I/O Aggregator with the FC Flex IO module

Syntax `fabric-id fabric-num vlan vlan-id`

Parameters

fabric-id fabric-num	Enter a fabric ID number that is the same as the ID number of the dedicated VLAN used to carry FCoE storage traffic to the fabric specified in the FCoE map. You can enter a fabric ID in the range 1–4094.
vlanvlan-id	Enter the ID number of the dedicated VLAN used to carry FCoE storage traffic between servers and a SAN fabric and specified with the <code>vlan</code> command in the FCoE map.

Defaults None

Command Modes FCOE MAP

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.

Usage Information In the `fabric-id vlan` command, the fabric and VLAN ID numbers must be the same.

In each FCoE map, the fabric ID, FC-MAP value, and FCoE VLAN parameters must be unique.

To remove a fabric-VLAN association from an FCoE map, enter the `no fabric-id vlan` command.

You must first create a VLAN and then specify the configured VLAN ID in the `fabric-id vlan` command. Otherwise, the following error message is displayed.

```
FTOS(conf-fcoe-f)#fabric-id 10 vlan 10 % Error: Vlan 10 does not exist
```

Related Commands [fcoe-map](#) — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.

[show fcoe-map](#) — displays the Fibre Channel and FCoE configuration parameters in FCoE maps.



fcf-priority

In an FCoE map, configure the priority used by a server CNA to select an upstream FCoE forwarder (FCF).

M I/O Aggregator with the FC Flex IO module

Syntax	<code>fcf-priority priority</code>	
Parameters	<i>priority</i>	Enter the priority assigned to the M I/O Aggregator with the FC Flex IO module NPIV proxy gateway, which appears to a downstream server CNA as an FCF. The range of FCF priority values is from 1 to 255.
Defaults	128	
Command Modes	FCOE MAP	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.
Usage Information	The FCF priority you assign to an M I/O Aggregator with the FC Flex IO module is used by server CNAs to select an upstream FCF to use for a fabric login (FLOGI). To remove a configured FCF priority from an FCoE map, enter the <code>no fcf-priority</code> command.	
Related Commands	fcoe-map — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric. show fcoe-map — displays the Fibre Channel and FCoE configuration parameters in FCoE maps.	

fc-map

In an FCoE map, configure the FCoE mapped address prefix (FC-MAP) value which is used to identify FCoE traffic transmitted on the FCoE VLAN for the specified fabric.

M I/O Aggregator with the FC Flex IO module

Syntax	<code>fc-map fc-map-value</code>	
Parameters	<i>fc-map-value</i>	Enter the unique MAC address prefix used by a SAN fabric. The range of FC-MAP values is from 0EFC00 to 0EFCFF.
Defaults	None	
Command Modes	FCOE MAP	
Supported Modes	Programmable-Mux (PMUX)	



Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.
Usage Information	The FC-MAP value you enter must match the FC-MAP value used by an FC switch or FCoE forwarder (FCF) in the fabric. An FCF switch accepts only FCoE traffic that uses the correct FC-MAP value.	
	The FC-MAP value is used to generate the fabric-provided MAC address (FP-MAC). The FPMA is used by servers to transmit FCoE traffic to the fabric. An FC-MAP can be associated with only one FCoE VLAN and vice versa.	
	In an FCoE map, the FC-MAP value, fabric ID, and FCoE VLAN parameters must be unique.	
	To remove a configured FC-MAP value from an FCoE map, enter the <code>no fcoe-map</code> command.	
Related Commands	fcoe-map — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.	

fcoe-map

Create an FCoE map which contains the parameters used to configure the links between server CNAs and a SAN fabric. Apply the FCoE map on a server-facing Ethernet port.

M I/O Aggregator with the FC Flex IO module

Syntax	<code>fcoe-map map-name</code>	
Parameters	<i>map-name</i>	Maximum: 32 alphanumeric characters.
Defaults	On the I/O Aggregator with PMUX modules, the following parameters are applied on all the PMUX module interfaces: • Description: SAN_FABRIC • Fabric-id: 1002 • Fcoe-vlan: 1002 • Fc-map: 0x0efc00 • Fcf-priority: 128 • Fka-adv-period: 8000mSec • Keepalive: enable • Vlan priority: 3	
Command Modes	CONFIGURATION INTERFACE	
Supported Modes	Programmable-Mux (PMUX)	



Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.
Usage Information	An FCoE map is a template used to map FCoE and FC parameters in a converged fabric. An FCoE map is used to virtualize upstream FC ports on an M I/O Aggregator with the PMUX module NPIV proxy gateway so that they appear to downstream server CNA ports as FCoE forwarder (FCF) ports on an FCoE network. When applied to FC and Ethernet ports on an NPIV proxy gateway, an FCoE map allows the switch to operate as an FCoE-FC bridge between an FC SAN and an FCoE network by providing FCoE-enabled servers and switches with the necessary parameters to log in to a SAN fabric.	
	On an M I/O Aggregator with the PMUX module NPIV proxy gateway, you cannot apply an FCoE map is applied on fabric-facing FC ports and server-facing 10–Gigabit Ethernet ports.	
	An FCoE map consists of the following parameters: the dedicated FCoE VLAN used for storage traffic, the destination SAN fabric (FC-MAP value), FCF priority used by a server, and the FIP keepalive (FKA) advertisement timeout.	
	In each FCoE map, the fabric ID, FC-MAP value, and FCoE VLAN parameters must be unique. Use one FCoE map to access one SAN fabric. You cannot use the same FCoE map to access different fabrics.	
	To remove an FCoE map from an Ethernet interface, enter the <code>no fcoe-map map-name</code> command in Interface configuration mode.	
Related Commands	show fcoe-map — displays the Fibre Channel and FCoE configuration parameters in FCoE maps.	

fka-adv-period

In an FCoE map, configure the time interval used to transmit FIP keepalive (FKA) advertisements.

M I/O Aggregator with the FC Flex IO module

Syntax	<code>fka-adv-period seconds</code>	
Parameters	seconds	Enter the time period (in seconds) used to send FIP keepalive messages to peer devices. The range is from 8 to 90 seconds.
Defaults	8 seconds	
Command Modes	FCOE MAP	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.
Usage Information	To delete the FIP keepalive time period from an FCoE map, enter the <code>no fka-adv-erpiod</code> command.	



Related Commands [fcoe-map](#) — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.

interface vlan (NPIV proxy gateway)

Create a dedicated VLAN to be used to send and receive Fibre Channel traffic over FCoE links between servers and a fabric over an M I/O Aggregator with the PMUX module NPIV proxy gateway.

M I/O Aggregator with the FC Flex IO module

Syntax `interface vlan vlan-id`

Parameters *vlan-id* Enter a number as the VLAN Identifier. The range is 1 to 4094.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module configured as an NPIV proxy gateway.

Usage Information FCoE storage traffic received from servers on an M I/O Aggregator with the PMUX module NPIV proxy gateway is de-capsulated into Fibre Channel packets and forwarded over FC links to SAN switches in a specified fabric. You must configure a separate FCoE VLAN for each fabric to which FCoE traffic is forwarded. Any non-FCoE traffic sent on a dedicated FCoE VLAN will be dropped.

You configure the association between a dedicated VLAN, which carries FCoE traffic from server CNAs over the NPIV proxy gateway to a SAN fabric in which destination storage arrays are installed, in an FCoE map by using the `fabric id vlan` command.

When you apply an FCoE map to a server-facing Ethernet port, the port is automatically configured as a tagged member of the FCoE VLAN.

For more information about VLANs and the commands to configure them, refer to the [Virtual LAN \(VLAN\) Commands](#) section.

Example (Single Range) `Dell(conf)#interface vlan 10`
 `Dell(conf-if-vl-3)#`

Related Commands [fcoe-map](#) — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.



keepalive

In an FCoE map, enable the monitoring of FIP keepalive messages (if it is disabled).

M I/O Aggregator with the FC Flex IO module

Syntax	keepalive					
Parameters	None					
Defaults	FIP keepalive monitoring is enabled on Ethernet and Fibre Channel interfaces.					
Command Modes	FCOE MAP					
Supported Modes	Programmable-Mux (PMUX)					
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.3(0.0)</td><td>Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.</td></tr></table>		Version	Description	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.
Version	Description					
9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.					
Usage Information	FIP keepalive (FKA) messaging is used to detect if other FCoE devices are reachable. To remove FIP keepalive monitoring from an FCoE map, enter the <code>no keepalive</code> command.					
Related Commands	fcoe-map — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.					

show fc switch

Display the switch configuration for Fibre Channel capability.

M I/O Aggregator with the FC Flex IO module

Syntax	show fc switch					
Parameters	None					
Command Modes	- EXEC - EXEC Privilege					
Supported Modes	All Modes					
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.7(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr></table>		Version	Description	9.7(0.0)	Introduced on the M I/O Aggregator.
Version	Description					
9.7(0.0)	Introduced on the M I/O Aggregator.					
Usage Information	The following table describes the show fc switch output shown in the following example.					
	<table><tr><td>Switch Mode</td><td>Fibre Channel mode of operation of an Aggregator.</td></tr></table>		Switch Mode	Fibre Channel mode of operation of an Aggregator.		
Switch Mode	Fibre Channel mode of operation of an Aggregator.					



Switch WWN	Factory-assigned worldwide node (WWN) name of the Aggregator. The M I/O Aggregator WWN name is not user-configurable.
-------------------	---

Example

```
Dell(conf)#do show fc switch
Switch Mode : NPG
Switch WWN   : 10:00:aa:00:00:00:00:ac
Dell(conf)#
```

show fcoe-map

Display the Fibre Channel and FCoE configuration parameters in FCoE maps.

M I/O Aggregator with the FC Flex IO module

Syntax `show fcoe-map [brief | map-name]`

Parameters	brief	Displays an overview of currently configured FCoE maps.
	map-name	Displays the FC and FCoE configuration parameters in a specified FCoE map. The FCoE map is applied on Ethernet (FCoE) and FC ports to transmit FC storage traffic to a specified fabric.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.

Usage Information Use the `show fcoe-map` command to display the FC and FCoE parameters used to configure server-facing Ethernet (FCoE) and fabric-facing FC ports in all FCoE maps on an M I/O Aggregator with the FC Flex IO module NPIV proxy gateway.

In each FCoE map, the values for the fabric ID and FC-MAP that identify the SAN fabric to which FC storage traffic is sent, and the FCoE VLAN to be used must be unique.

An FCoE map is used to identify the SAN fabric to which FCoE storage traffic is sent and to virtualize M I/O Aggregator with the FC Flex IO module FC ports so that they appear to downstream server CNA ports as FCoE Forwarder (FCF) ports on an FCoE network.

The following table describes the `show fcoe-map brief` output shown in the example below.

Field	Description
Fabric-Name	Name of a SAN fabric.
Fabric ID	The ID number of the SAN fabric to which FC traffic is forwarded.



Field	Description
VLAN ID	The dedicated FCoE VLAN used to transport FCoE storage traffic between servers and a fabric over the NPIV proxy gateway. The configured VLAN ID must be the same as the fabric ID.
FC-MAP	FCoE MAC address-prefix value - The unique 24-bit MAC address prefix that identifies a fabric.
FCF Priority	The priority used by a server to select an upstream FCoE forwarder.
Config-State	Indicates whether the configured FCoE and FC parameters in the FCoE map are valid: Active (all mandatory FCoE and FC parameters are correctly configured) or Incomplete (either the FC-MAP value, fabric ID, or VLAN ID are not correctly configured).
Oper-State	Operational status of link to the fabric: Up (link is up and transmitting FC traffic), Down (link is down and not transmitting FC traffic), Link-wait (link is up and waiting for FLOGI to complete on peer FC port), or Removed (port has been shut down).

The following table describes the `show fcoe-map map-name` output shown in the example below.

Field	Description
Fabric-Name	Name of a SAN fabric.
Fabric ID	The ID number of the SAN fabric to which FC traffic is forwarded.
VLAN ID	The dedicated FCoE VLAN used to transport FCoE storage traffic between servers and a fabric over the NPIV proxy gateway. The configured VLAN ID must be the same as the fabric ID.
VLAN priority	FCoE traffic uses VLAN priority 3. (This setting is not user-configurable.)
FC-MAP	FCoE MAC address-prefix value - The unique 24-bit MAC address prefix that identifies a fabric.
FKA-ADV-period	Time interval (in seconds) used to transmit FIP keepalive advertisements.
FCF Priority	The priority used by a server to select an upstream FCoE forwarder.
Config-State	Indicates whether the configured FCoE and FC parameters in the FCoE map are valid: Active (all mandatory FCoE and FC parameters are correctly configured) or Incomplete (either the FC-MAP value, fabric ID, or VLAN ID are not correctly configured).
Oper-State	Operational status of link to the fabric: Up (link is up and transmitting FC traffic), Down (link is down and not transmitting FC traffic), Link-wait (link is up and waiting for FLOGI to complete on peer FC port), or Removed (port has been shut down).
Members	M I/O Aggregator with the FC Flex IO module Ethernet and FC ports that are members of the dedicated FCoE VLAN that carries storage traffic to the specified fabric.

Example

```
Dell#show fcoe-map brief
Fabric-Name Fabric-Id Vlan-Id FC-MAP FCF-Priority Config-State Oper-
State
test 16 16 0efc02 128 ACTIVE UP
cnatest 1003 1003 0efc03 128 ACTIVE UP
sitest 1004 1004 0efc04 128 ACTIVE DOWN

Dell#show fcoe-map si
```



Fabric Name	si
Fabric Id	1004
Vlan Id	1004
Vlan priority	3
FC-MAP	0efc04
FKA-ADV-Period	8
Fcf Priority	128
Config-State	ACTIVE
Oper-State	DOWN
Members	

Related Commands [fcoe-map](#) — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.

show npiv devices

Display the FCoE and FC devices currently logged into an M I/O Aggregator with the FC Flex IO module NPIV proxy gateway.

M I/O Aggregator with the FC Flex IO module

Syntax `show npiv devices [brief]`

Parameters

brief	Displays an overview of current server CNA-fabric connections over an M I/O Aggregator with the FC Flex IO module NPIV proxy gateway.
--------------	---

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.

Usage Information Use the `show npiv devices` command to display information on the server CNA, server-facing Ethernet and fabric-facing ports, and the SAN fabric in each server-fabric connection over an M I/O Aggregator with the FC Flex IO module that operates as an NPIV proxy gateway.

The following table describes the `show npiv devices brief` output shown in the example below.

Field	Description
ENode-Intf	M I/O Aggregator with the FC Flex IO module Ethernet interface (<i>slot/port</i>) to which a server CNA is connected.
ENode-WWPN	Worldwide port name (WWPN) of a server CNA port.
FCoE-Vlan	VLAN ID of the dedicated VLAN used to transmit FCoE traffic to and from the fabric.
Fabric-Intf	Fabric-facing Fibre Channel port (<i>slot/port</i>) on which FC traffic is transmitted to the specified fabric.

Field	Description
Fabric-Map	Name of the FCoE map containing the FCoE/FC configuration parameters for the server CNA-fabric connection.
LoginMethod	Method used by the server CNA to log in to the fabric; for example: FLOGI - ENode logged in using a fabric login (FLOGI). FDISC - ENode logged in using a fabric discovery (FDISC).
Status	Operational status of the link between a server CNA port and a SAN fabric: Logged In - Server has logged in to the fabric and is able to transmit FCoE traffic.

Example

```
Dell# show npiv devices brief
```

```
Total NPIV Devices = 2
```

ENode-Intf	ENode-WWPN	FCoE-Vlan	Fabric-Intf	Fabric-Map	LoginMethod
Te 0/12 LOGGED_IN	20:01:00:10:18:f1:94:20	1003	Fc 0/5	fid_1003	FLOGI
Te 0/13 LOGGED_IN	10:00:00:00:c9:d9:9c:cb	1003	Fc 0/0	fid_1003	FDISC

Usage Information

The following table describes the `show npiv devices` output shown in the example below.

Field	Description
ENode [number]	A server CNA that has successfully logged in to a fabric over an M I/O Aggregator with the FC Flex IO module Ethernet port in ENode mode.
Enode MAC	MAC address of a server CNA port.
Enode Intf	Port number of a server-facing Ethernet port operating in ENode mode.
FCF MAC	Fibre Channel forwarder MAC: MAC address of M I/O Aggregator with the FC Flex IO module FCF interface.
Fabric Intf	Fabric-facing Fibre Channel port (<i>slot/port</i>) on which FCoE traffic is transmitted to the specified fabric.
FCoE VLAN	ID of the dedicated VLAN used to transmit FCoE traffic from a server CNA to a fabric and configured on both the server-facing M I/O Aggregator with the FC Flex IO module port and server CNA port.
Fabric Map	Name of the FCoE map containing the FCoE/FC configuration parameters for the server CNA-fabric connection.
Enode WWPN	Worldwide port name of the server CNA port.
Enode WWNN	Worldwide node name of the server CNA.
FCoE MAC	Fabric-provided MAC address (FPMA). The FPMA consists of the FC-MAP value in the FCoE map and the FC-ID provided by the fabric after a successful FLOGI. In the FPMA, the most significant byte is the FC-MAP; the least significant bytes are the FC-ID.
FC-ID	FC port ID provided by the fabric.
LoginMethod	Method used by the server CNA to log in to the fabric; for example, FLOGI or FDISC.
Secs	Number of seconds that the fabric connection is up.
State	Status of the fabric connection: logged in.



Example

```
ENode[0]:
ENode MAC      : 00:10:18:f1:94:21
ENode Intf     : Te 0/12
FCF MAC        : 5c:f9:dd:ef:10:c8
Fabric Intf    : Fc 0/5
FCoE Vlan      : 1003
Fabric Map     : fid 1003
ENode WWPNN    : 20:01:00:10:18:f1:94:20
ENode WNNN     : 20:00:00:10:18:f1:94:21
FCoE MAC       : 0e:fc:03:01:02:01
FC-ID          : 01:02:01
LoginMethod    : FLOGI
Secs           : 5593
Status         : LOGGED_IN

ENode[1]:
ENode MAC      : 00:10:18:f1:94:22
ENode Intf     : Te 0/13
FCF MAC        : 5c:f9:dd:ef:10:c9
Fabric Intf    : Fc 0/0
FCoE Vlan      : 1003
Fabric Map     : fid 1003
ENode WWPNN    : 10:00:00:00:c9:d9:9c:cb
ENode WNNN     : 10:00:00:00:c9:d9:9c:cd
FCoE MAC       : 0e:fc:03:01:02:02
FC-ID          : 01:02:01
LoginMethod    : FDISC
Secs           : 5593
Status         : LOGGED_IN
```

Related Commands [fcoe-map](#) — creates an FCoE map which contains the parameters used in the communication between servers and a SAN switch.

show running-config fcoe-map

Displays the current fcoe-map configurations.

M I/O Aggregator with the FC Flex IO module

Syntax `show running-config fcoe-map`

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.6(0.0)	Supported on the FN2210S Aggregator.
	9.3(0.0)	Introduced on the M I/O Aggregator and MXL 10/40GbE Switch with the FC Flex IO module.

Example

```
Dell(conf)#do show running-config fcoe-map
!
fcoe-map map
fc-map 0efc00
fabric-id 100 vlan 100
```



FC FLEXIO FPORT

The switch is a Trident+ based switch which is plugged into the Dell M1000 Blade server chassis. The blade module contains two slots for pluggable flexible module. The goal is to provide support for direct connectivity to FC equipments through Fibre channel ports by FC Flex IO optional module. The FC Flex IO utilizes Broadcom Montreal (BCM84757) FC/FCOE mapper to provide FCOE to FC functionality.

active-zoneset

Activate the zoneset.

Syntax `active-zoneset zoneset_name`
To change to the default zone behavior, use the `no active-zoneset zoneset_name` command.

Parameters `zoneset_name` Enter the zoneset name.

Command Modes FC FABRIC CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.7(0.0)	Introduced on the M I/O Aggregator.

Example

```
Dell(conf)# fcoe-map default_full_fabric
Dell(conf-fcoe-default_full_fabric)# fc-fabric
Dell(conf-fmap-default_full_fabric-fcfabric)# active-zoneset zsl
```

Related Commands [show fc zoneset](#) — displays the configured and active zoneset.

fabric

Apply an FCoE map on a fabric-facing Fibre Channel (FC) port.

Syntax `fabric map-name`

Parameters `map-name` Maximum: 32 alphanumeric characters.

Defaults None

Command Modes INTERFACE FIBRE_CHANNEL

Supported Modes All Modes



Command History	Version	Description
	9.7(0.0)	Introduced on the M I/O Aggregator.
Usage Information	An FCoE map is a template used to map FCoE and FC parameters in a converged fabric. An FCoE map virtualizes the upstream FC ports on an M I/O Aggregator NPIV proxy gateway to appear to downstream server CNA ports as FCoE forwarder (FCF) ports on an FCoE network. When applied to FC and Ethernet ports on an NPIV proxy gateway, an FCoE map allows the switch to operate as an FCoE-FC bridge between an FC SAN and an FCoE network. It provides necessary parameters to FCoE-enabled servers and switches to log in to a SAN fabric. Use the <code>fcoe-map</code> command to create an FCoE map. On an M I/O Aggregator NPIV proxy gateway, an FCoE map is applied on fabric-facing FC ports and server-facing Ethernet ports. Use the <code>fabric</code> command to apply an FCoE map on an FC port. Use the <code>fcoe-map</code> command to apply an FCoE map on an Ethernet port. After you apply an FCoE map on an FC interface, when the port is enabled (<code>no shutdown</code>), the NPIV proxy gateway starts sending FIP multicast advertisements on behalf of the FC port to downstream servers to advertise the availability of a new FCF port on the FCoE VLAN. To remove an FCoE map from an FC interface, enter the <code>no fabric map-name</code> command in Interface configuration mode.	
	Related Commands fcoe-map — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric. show fcoe-map — displays the Fibre Channel and FCoE configuration parameters in FCoE maps.	

fc alias

Create a zone alias name.

Syntax	<code>fc alias ZoneAliasName member name</code>
	To delete a zone alias name, use the <code>no fc zone ZoneAliasName</code> command.

Parameters	ZoneAliasName	Enter the zone alias name.
	member name	Enter the WWPN, port ID, or domain/port.

Command Modes	CONFIGURATION
---------------	---------------

Supported Modes	All Modes
-----------------	-----------

Command History	Version	Description
	9.7(0.0)	Introduced on the M I/O Aggregator.

Example	Syntax:	
	<pre>Dell(conf)#fc alias test12 Dell(conf-fc-alias-test12)#? end exit</pre>	<pre>Exit from configuration mode Exit from Alias config mode</pre>



member	Add Alias member
no	Negate a command or set its defaults
show	Show alias profile configuration
Dell (conf-fc-alias-test12) #member ?	
WORD	WWN(00:00:00:00:00:00:00:00), or portID(123000)

Related Commands [show fc alias](#) — displays the configured alias.

fc zone

Create a zone.

Syntax `fc zone zonename member`
 To delete a zone, use the `no fc zone zonename member` command.

Parameters

<i>zonename</i>	Enter the zone name.
<i>member</i>	Enter the WWPN, port ID, or domain/port.

Command Modes ALIAS CONFIGURATION

Supported Modes All Modes

Command History

Version	Description
9.7(0.0)	Introduced on the M I/O Aggregator.

Example without member

```
Dell(conf)# fc zone z1
Dell(conf-fc-zone-z1)#
```

Example with member

```
Dell(conf)#fc zone test
Dell(conf-fc-zone-test)#member ?
WORD                               WWN(00:00:00:00:00:00:00:00), or
Alias name(word)
Dell(conf-fc-zone-test)#member
```

Related Commands [show fc zone](#) — displays the configured zone.
 [show fcoe-map](#) — displays the fabric parameters.

fc zoneset

Create a zoneset.

Syntax `fc zoneset zoneset_name [member]`
 To delete a zoneset, use the `no fc zoneset zoneset_name [member]` command.



Parameters	zoneset_name	Enter the zoneset name.
	member	Enter the WWPN, FC-ID, or Alias name.
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	
	9.7(0.0)	Introduced on the M I/O Aggregator.
Example	<pre>Dell(config)#fc zoneset test1 Dell(config-fc-zoneset-test1)#member ? WORD Zone Name Dell(config-fc-zoneset-test1)#member</pre>	
Related Commands	show fc zoneset — displays the configured and active zoneset.	
	show fcoe-map — displays the fabric parameters.	

fcoe-map

Create an FCoE map which contains the parameters used to configure the links between server CNAs and a SAN fabric. Apply the FCoE map on a server-facing Ethernet port.

Syntax	<code>fcoe-map map-name</code>	
Parameters	map-name	Maximum: 32 alphanumeric characters.
Defaults	None	
Command Modes	CONFIGURATION	
	INTERFACE	
Supported Modes	All Modes	
Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator.
Usage Information	An FCoE map is a template to map FCoE and FC parameters in a converged fabric. An FCoE map virtualizes upstream FC ports on an M I/O Aggregator NPIV proxy gateway to appear to downstream server CNA ports as FCoE forwarder (FCF) ports on an FCoE network. When applied to FC and Ethernet ports on an NPIV proxy gateway, an FCoE map allows the switch to operate as an FCoE-FC bridge between an FC SAN and an FCoE network. It provides necessary parameters to FCoE-enabled servers and switches to log in to a SAN fabric.	



On an M I/O Aggregator NPIV proxy gateway, an FCoE map is applied on fabric-facing FC ports and server-facing Ethernet ports. Use the `fcoe-map` command to apply an FCoE map on an Ethernet port. Use the `fabric` command to apply an FCoE map on an FC port.

An FCoE map consists of the following parameters: the dedicated FCoE VLAN for storage traffic, the destination SAN fabric (FC-MAP value), FCF priority, and the FIP keepalive (FKA) advertisement timeout.

To remove an FCoE map from an Ethernet interface, enter the `no fcoe-map map-name` command in Interface configuration mode.

 **NOTE: You cannot create fcoe-map in IOA mode. It can only be created in PMUX mode.**

 **NOTE: In FCF F mode, you can create only one FCoE map. It doesn't get created automatically. If you try to create more than one map, an error message is displayed.**

Related Commands [show fcoe-map](#)— displays the Fibre Channel and FCoE configuration parameters in FCoE maps.

feature fc

Enable feature fc with FPort functionality.

Syntax `feature fc fport domain-id range`

Parameters

<i>Range</i>	Enter the range from 1 to 239.
--------------	--------------------------------

Command Modes CONFIGURATION

Supported Modes All Modes

Command History

Version	Description
9.7(0.0)	Introduced on the M I/O Aggregator.

Usage Information Enable `remote-fault-signaling rx off` command in FCF FPort mode on interfaces connected to the Compellent and MDF storage devices.

Example `Dell(conf)#feature fc fport domain-id`

show fc alias

Display the configured alias.

Syntax `show fc alias [ZoneAliasName ]`

Parameters

<i>ZoneAliasName</i>	Enter the zone alias name to display the details.
----------------------	---

Command Modes

- EXEC
- EXEC Privilege



Supported Modes	All Modes	
Command History	Version	Description
	9.7(0.0)	Introduced on the M I/O Aggregator.
Example	Dell#show fc alias	
	Zone Alias Name	all
	0x030303	
	Dell#	
Related Commands	fc alias — creates a zone alias name.	

show fc ns

Display the devices in the name server database.

Syntax	show fc ns { switch } [brief]	
Parameters	switch	Enter the keyword switch to display all the devices in the name server database of the switch.
	brief	Enter the keyword brief to display in brief devices in the name server database.
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.7(0.0)	Introduced on the M I/O Aggregator.
Example	<pre>Dell#show fc ns switch Total number of devices = 1 Switch Name 10:00:5c:f9:dd:ef:0a:00 Domain Id 1 Switch Port 53 Port Id 01:35:00 Port Name 10:00:8c:7c:ff:17:f8:01 Node Name 20:00:8c:7c:ff:17:f8:01 Class of Service 8 IP Address Symbolic Port Name Brocade-1860 3.0.3.0 DV-SP-SERVER2 Symbolic Node Name (NULL) Port Type Node port Registered with NameServer Yes Registered for SCN Yes Display of local name server entries - brief version Dell#</pre>	
	<pre>Dell#show fc ns switch brief Total number of devices = 1 Intf# Domain FC-ID Enode-WWPN Enode-WWNN</pre>	



```

53      1      01:35:00      10:00:8c:7c:ff:17:f8:01 20:00:8c:7c:ff:
17:f8:01
Dell#

Dell#show fc ns fabric
Total number of devices =      3
Switch Name      10:00:5c:f9:dd:ef:0a:80
Domain Id      2
Switch Port      9
Port Id      02:09:00
Port Name      32:11:0e:fc:00:00:00:88
Node Name      22:11:0e:fc:00:00:00:88
Class of Service      8
IP Address
Symbolic Port Name      (NULL)
Symbolic Node Name      (NULL)
Port Type      Node port
Registered with NameServer      No
Registered for SCN      No
Switch Name      10:00:5c:f9:dd:ef:0a:80
Domain Id      2
Switch Port      11
Port Id      02:0b:00
Port Name      31:11:0e:fc:00:00:00:77
Node Name      21:11:0e:fc:00:00:00:77
Class of Service      8
IP Address
Symbolic Port Name      (NULL)
Symbolic Node Name      (NULL)
Port Type      Node port
Registered with NameServer      No
Registered for SCN      No
Switch Name      10:00:5c:f9:dd:ef:0a:00
Domain Id      1
Switch Port      53
Port Id      01:35:00
Port Name      10:00:8c:7c:ff:17:f8:01
Node Name      20:00:8c:7c:ff:17:f8:01
Class of Service      8
IP Address
Symbolic Port Name      Brocade-1860 | 3.0.3.0 | DV-SP-SERVER2 | |
Symbolic Node Name      (NULL)
Port Type      Node port
Registered with NameServer      Yes
Registered for SCN      Yes
Dell#

Dell#show fc ns fabric brief
Total number of devices =      2
Intf#      Domain      FC-ID      Enode-WWPN      Enode-WWNN
9      2      02:09:00      32:11:0e:fc:00:00:00:88 22:11:0e:fc:
00:00:00:88
11      2      02:0b:00      31:11:0e:fc:00:00:00:77 21:11:0e:fc:
00:00:00:77
Dell#

```

show fc switch

Display the switch configuration for Fibre Channel capability.

Syntax show fc switch



Parameters	None					
Command Modes	- EXEC - EXEC Privilege					
Supported Modes	All Modes					
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.7(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr></table>	Version	Description	9.7(0.0)	Introduced on the M I/O Aggregator.	
Version	Description					
9.7(0.0)	Introduced on the M I/O Aggregator.					
Usage Information	The following table describes the <code>show fc switch</code> output shown in the following example.					
	<table><tr><td>Switch Mode</td><td>Fibre Channel mode of operation of an MXL switch.</td></tr><tr><td>Switch WWN</td><td>Factory-assigned worldwide node (WWN) name of the MXL. The MXL WWN name is not user-configurable.</td></tr></table>	Switch Mode	Fibre Channel mode of operation of an MXL switch.	Switch WWN	Factory-assigned worldwide node (WWN) name of the MXL. The MXL WWN name is not user-configurable.	
Switch Mode	Fibre Channel mode of operation of an MXL switch.					
Switch WWN	Factory-assigned worldwide node (WWN) name of the MXL. The MXL WWN name is not user-configurable.					
Example	<pre>Dell(conf)#do show fc switch Switch Mode : FPORT Switch WWN : 10:00:aa:00:00:00:ac Dell(conf)#</pre>					

show fc zone

Display the configured zone.

Syntax	show fc zone [zonename]	
Parameters	zonename	Enter the zone name to display the details.
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.7(0.0)	Introduced on the M I/O Aggregator.
Example	<pre>Dell#show fc zone ZoneName ZoneMember ===== brcd_sanb brcd_cna1_wwpn1 sanb_p2tgt1_wwpn Dell#</pre>	
Related Commands	fc zone — creates a zone.	



show fc zoneset

Display the configured and active zoneset.

Syntax `show fc zoneset [ zoneset_name | active ]`

Parameters

zoneset_name	Enter the zoneset name to display the zoneset name
active	Enter the keyword <code>active</code> to display the active zonesets.
merged	Enter the keyword <code>merged</code> to display the merge active zones.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.7(0.0)	Introduced on the M I/O Aggregator.

Example

```
Dell#show fc zoneset

ZoneSetName                ZoneName                ZoneMember
=====
fcoe_srv_fc_tgt
                        brcd_sanb
                                brcd_cna1_wwpn1
                                sanb_p2tgt1_wwpn

Active Zoneset: fcoe_srv_fc_tgt

ZoneName                ZoneMember
=====
brcd_sanb
                        10:00:8c:7c:ff:21:5f:8d
                        20:02:00:11:0d:03:00:00

Dell#

Dell#show fc zoneset active

Active Zoneset: fcoe_srv_fc_tgt

ZoneName                ZoneMember
=====
brcd_sanb
                        10:00:8c:7c:ff:21:5f:8d
                        20:02:00:11:0d:03:00:00

Dell#
```

Related Commands

- [fc zone](#) — creates a zone.
- [fc zoneset](#) — creates a zoneset.
- [active-zoneset](#) — activates the zoneset.



show fcoe-map

Display the Fibre Channel and FCoE configuration parameters in FCoE maps.

Syntax `show fcoe-map`

Parameters None

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.3(0.0)	Introduced on the M I/O Aggregator.

Usage Information

Use the `show fcoe-map` command to display the FC and FCoE parameters used to configure server-facing Ethernet (FCoE) and fabric-facing FC ports in all FCoE maps on an M I/O Aggregator Switch.

In each FCoE map, the values for the fabric ID and FC-MAP that identify the SAN fabric to which FC storage traffic is sent, and the FCoE VLAN to be used must be unique.

An FCoE map is used to identify the SAN fabric to which FCoE storage traffic is sent. It also virtualizes M I/O Aggregator Switch with the FC Flex IO module FC ports so that they appear to downstream server CNA ports as FCoE Forwarder (FCF) ports on an FCoE network.

Example

```
Dell(conf)#do show fcoe-map

Fabric Name          SAN_FABRIC

Fabric Type          npiv
Fabric Id             1002
Vlan Id              1002
Vlan priority         3
FC-MAP               0efc00
FKA-ADV-Period        8
Fcf Priority          128
Config-State          ACTIVE
Oper-State            UP
=====
Members
Fc 0/41 Fc 0/42 Fc 0/43 Fc 0/44 Fc 0/49 Fc 0/50 Fc 0/51 Fc 0/52
Te 0/4 Te 0/9 Te 0/16
=====
=====
Dell(conf)#
```

Related Commands [fcoe-map](#) — creates an FCoE map which contains the parameters used in the communication between servers and a SAN fabric.



FIP Snooping

In a converged Ethernet network, an Aggregator can operate as an intermediate Ethernet bridge to snoop on Fibre Channel over Ethernet Initialization Protocol (FIP) packets during the login process on Fibre Channel over Ethernet (FCoE) forwarders (FCFs). Acting as a transit FIP snooping bridge, the switch uses dynamically-created ACLs to permit only authorized FCoE traffic to be transmitted between an FCoE end-device and an FCF.

This chapter describes the FIP snooping commands.

clear fip-snooping database interface vlan

Clear FIP snooping information on a VLAN for a specified FCoE MAC address, ENode MAC address, or FCF MAC address, and remove the corresponding ACLs FIP snooping generates.

Syntax `clear fip-snooping database interface vlan vlan-id {fcoe-mac-address | enode-mac-address | fcf-mac-address}`

Parameters

<i>fcoe-mac-address</i>	Enter the FCoE MAC address to be cleared of FIP snooping information.
<i>enode-mac-address</i>	Enter the ENode MAC address to be cleared of FIP snooping information.
<i>fcf-mac-address</i>	Enter the FCF MAC address to be cleared of FIP snooping information.

Command Modes EXEC Privilege

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

clear fip-snooping statistics

Clear the statistics on the FIP packets snooped on all VLANs, a specified VLAN, or a specified port interface.

Syntax `clear fip-snooping statistics [interface vlanVlan-id| interface port-type port/slot|interface port-channel port-channel-number]`

Parameters

<i>vlan-id</i>	Enter the VLAN ID of the FIP packet statistics to be cleared.
<i>port type port/slot</i>	Enter the port-type and slot number of the FIP packet statistics to be cleared.



port-channel-number

Enter the port channel number of the FIP packet statistics to be cleared.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

feature fip-snooping

Enable FCoE transit and FIP snooping on a switch.

Syntax `feature fip-snooping`
To disable the FCoE transit feature, use the `no feature fip-snooping` command.

Defaults Disabled

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

fip-snooping enable

Enable FIP snooping on all VLANs or on a specified VLAN.

Syntax `fip-snooping enable`
To disable the FIP snooping feature on all or a specified VLAN, use the `no fip-snooping enable` command.

Defaults FIP snooping is disabled on all VLANs.

Command Modes

- CONFIGURATION
- VLAN INTERFACE

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.



Version	Description
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information The maximum number of FCFs supported per FIP snooping-enabled VLAN is four. The maximum number of FIP snooping sessions supported per ENode server is 16.

fip-snooping fc-map

Configure the FC-MAP value FIP snooping uses on all VLANs.

Syntax	<code>fip-snooping fc-map <i>fc-map-value</i></code> To return the configured FM-MAP value to the default value, use the <code>no fip-snooping fc-map</code> command.									
Parameters	<i>fc-map-value</i>	Enter the FC-MAP value FIP snooping uses. The range is from 0EFC00 to 0EFCFF.								
Defaults	0x0EFC00									
Command Modes	· CONFIGURATION · VLAN INTERFACE									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>		Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									

fip-snooping port-mode fcf

Configure the port for bridge-to-FCF links.

Syntax	<code>fip-snooping port-mode fcf</code> To disable the bridge-to-FCF link on a port, use the <code>no fip-snooping port-mode fcf</code> command.									
Command Modes	INTERFACE									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>		Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									
Usage Information	The maximum number of FCFs supported per FIP snooping-enabled VLAN is four.									



show fip-snooping statistics

Displays statistics on the FIP packets snooped on all interfaces, including VLANs, physical ports, and port channels..

Syntax `show fip-snooping statistics [interface vlan vlan-id | interface port-type port/slot | interface port-channel port-channel-number]`

Parameters

<i>vlan-id</i>	Enter the VLAN ID of the FIP packet statistics to be displayed.
<i>port-type port/slot</i>	Enter the port-type and slot number of the FIP packet statistics to be displayed.
<i>port-channel-number</i>	Enter the port channel number of the FIP packet statistics to be displayed.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following table describes the `show fip-snooping statistics` command.

Field	Description
Number of Vlan Requests	Number of FIP-snooped VLAN request frames received on the interface.
Number of VLAN Notifications	Number of FIP-snooped VLAN notification frames received on the interface
Number of Multicast Discovery Solicits	Number of FIP-snooped multicast discovery solicit frames received on the interface.
Number of Unicast Discovery	Number of FIP-snooped unicast discovery solicit frames received on the interface.
Number of FLOGI	Number of FIP-snooped FLOGI request frames received on the interface.
Number of FDISC	Number of FIP-snooped FDISC request frames received on the interface
Number of FLOGO	Number of FIP-snooped FLOGO frames received on the interface
Number of ENode Keep Alives	Number of FIP-snooped ENode keep-alive frames received on the interface
Number of VN Port Keep Alives	Number of FIP-snooped VN port keep-alive frames received on the interface



Field	Description
Number of Multicast Discovery Advertisements	Number of FIP-snooped multicast discovery advertisements received on the interface
Number of Unicast Discovery Advertisements	Number of FIP-snooped unicast discovery advertisements received on the interface
Number of FLOGI Accepts	Number of FIP FLOGI accept frames received on the interface
Number of FLOGI Rejects	Number of FIP FLOGI reject frames received on the interface
Number of FDISC Accepts	Number of FIP FDISC accept frames received on the interface
Number of FDISC Rejects	Number of FIP FDISC reject frames received on the interface
Number of FLOGO Accepts	Number of FIP FLOGO accept frames received on the interface
Number of FLOGO Rejects	Number of FIP FLOGO reject frames received on the interface
Number of CVLs	Number of FIP clear virtual link frames received on the interface
Number of FCF Discovery	Number of FCF discovery timeouts that occurred on the interface
Number of VN Port Session	Number of VN port session timeouts that occurred on the interface
Number of Session failures due to Hardware Config	Number of session failures due to hardware configuration that occurred on the interface

Example

```

Dell# show fip-snooping statistics interface vlan 100
Number of Vlan Requests                               :0
Number of Vlan Notifications                           :0
Number of Multicast Discovery Solicits                  :2
Number of Unicast Discovery Solicits                    :0
Number of FLOGI                                         :2
Number of FDISC                                         :16
Number of FLOGO                                         :0
Number of Enode Keep Alive                             :9021
Number of VN Port Keep Alive                           :3349
Number of Multicast Discovery Advertisement             :4437
Number of Unicast Discovery Advertisement              :2
Number of FLOGI Accepts                                :2
Number of FLOGI Rejects                                :0
Number of FDISC Accepts                                :16
Number of FDISC Rejects                                :0
Number of FLOGO Accepts                                :0
Number of FLOGO Rejects                                :0
Number of CVL                                           :0
Number of FCF Discovery Timeouts                       :0
Number of VN Port Session Timeouts                     :0
Number of Session failures due to Hardware Config      :0
Dell(conf) #

```



```

Dell# show fip-snooping statistics int tengigabitethernet 0/11
Number of Vlan Requests                               :1
Number of Vlan Notifications                           :0
Number of Multicast Discovery Solicits                  :1
Number of Unicast Discovery Solicits                   :0
Number of FLOGI                                         :1
Number of FDISC                                         :16
Number of FLOGO                                         :0
Number of Enode Keep Alive                             :4416
Number of VN Port Keep Alive                           :3136
Number of Multicast Discovery Advertisement             :0
Number of Unicast Discovery Advertisement              :0
Number of FLOGI Accepts                                :0
Number of FLOGI Rejects                                :0
Number of FDISC Accepts                                :0
Number of FDISC Rejects                                :0
Number of FLOGO Accepts                                :0
Number of FLOGO Rejects                                :0
Number of CVL                                           :0
Number of FCF Discovery Timeouts                       :0
Number of VN Port Session Timeouts                     :0
Number of Session failures due to Hardware Config       :0

```

Example (port channel)

```

Dell# show fip-snooping statistics interface port-channel 22
Number of Vlan Requests                               :0
Number of Vlan Notifications                           :2
Number of Multicast Discovery Solicits                  :0
Number of Unicast Discovery Solicits                   :0
Number of FLOGI                                         :0
Number of FDISC                                         :0
Number of FLOGO                                         :0
Number of Enode Keep Alive                             :0
Number of VN Port Keep Alive                           :0
Number of Multicast Discovery Advertisement             :4451
Number of Unicast Discovery Advertisement              :2
Number of FLOGI Accepts                                :2
Number of FLOGI Rejects                                :0
Number of FDISC Accepts                                :16
Number of FDISC Rejects                                :0
Number of FLOGO Accepts                                :0
Number of FLOGO Rejects                                :0
Number of CVL                                           :0
Number of FCF Discovery Timeouts                       :0
Number of VN Port Session Timeouts                     :0
Number of Session failures due to Hardware Config       :0

```

debug fip-snooping

Enable the debug FIP protocol specific messages.

Syntax debug fip-snooping [all|acl|error|ifm|info|ipc|rx]

Parameters

all	Enable all the debug options.
acl	Enable for ACL specific debugs
error	Enable for Error specific debugs
ifm	Enable for IFM specific debugs
info	Enable for Information specific debugs



	ipc	Enable for IPC specific debugs
	rx	Enable for packet receive specific debugs
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History		
	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

show fip-snooping config

Displays the FIP snooping status and configured FC-MAP values.

Syntax	<code>show fip-snooping config</code>	
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History		
	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Example	<pre>Dell#show fip-snooping config FIP Snooping Feature enabled Status: Enabled FIP Snooping Global enabled Status: Enabled Global FC-MAP Value: 0X0EFC00 Dell#</pre>	

show fip-snooping enode

Displays information on the ENodes in FIP-snooped sessions, including the ENode interface and MAC address, FCF MAC address, VLAN ID, and FC-ID.

Syntax	<code>show fip-snooping enode [enode-mac-address]</code>	
Parameters	<i>enode-mac-address</i>	Enter the MAC address of the ENodes to be displayed.
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	



Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

The following table describes the `show fip-snooping enode` command.

Field	Description
ENode MAC	MAC address of the ENode
ENode Interface	Slot/ port number of the interface connected to the ENode.
FCF MAC	MAC address of the FCF
VLAN	VLAN ID number used by the session
FC-ID	Fibre Channel session ID assigned by the FCF.

Example

```
Dell# show fip-snooping enode
Enode MAC          Enode Interface      FCF MAC
VLAN              FC-ID
-----
-----
54:7f:ee:37:34:40  100          d4:ae:52:1b:e3:cd    Te 0/11
                  62:00:11
```

show fip-snooping fcf

Displays information on the FCFs in FIP-snooped sessions, including the FCF interface and MAC address, FCF interface, VLAN ID, FC-MAP value, FKA advertisement period, and number of ENodes connected.

Syntax `show fip-snooping fcf[fcf-mac-address]`

Parameters

<i>fcf-mac-address</i>	Enter the MAC address of the FCF to be displayed.
------------------------	---

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

The following table describes the `show fip-snooping fcf` command.

Field	Description
FCF MAC	MAC address of the FCF
FCF Interface	Slot/ port number of the interface to which the FCF is connected.



Field	Description
VLAN	VLAN ID number used by the session
FC-MAP	FC-MAP value advertised by the FCF.
FKA_ADV_PERIOD	Period of time (in milliseconds) during which FIP keep-alive advertisements are transmitted.
No of ENodes	Number of ENodes connected to the FCF

Example

```

Dell# show fip-snooping fcf
FCF MAC          FCF Interface  VLAN    FC-MAP    FKA_ADV_PERIOD  No.
of ENodes
-----
54:7f:ee:37:34:40 Po 128        100     0e:fc:00
4000              1

```

show fip-snooping sessions

Displays information on FIP-snooped sessions on all VLANs or a specified VLAN, including the ENode interface and MAC address, the FCF interface and MAC address, VLAN ID, FCoE MAC address and FCoE session ID number (FC-ID), worldwide node name (WWNN) and the worldwide port name (WWPN).

Syntax `show fip-snooping sessions[interface vlan vlan-id]`

Parameters

vlan-id Enter the vlan-id of the specified VLAN to be displayed.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following table describes the `show fip-snooping sessions` command.

Field	Description
ENode MAC	MAC address of the ENode.
ENode Interface	Slot/ port number of the interface connected to the ENode.
FCF MAC	MAC address of the FCF.
FC Interface	Slot/ port number of the interface to which the FCF is connected.
VLAN	VLAN ID number used by the session.
FCoE MAC	MAC address of the FCoE session assigned by the FCF.
FC-ID	Fibre Channel ID assigned by the FCF.



Field	Description
Port WWPN	Worldwide port name of the CNA port.
Port WWNN	Worldwide node name of the CNA port.

Example

```
Dell#show fip-snooping sessions
Enode MAC          Enode Intf          FCF MAC          FCF Intf VLAN FCoE MAC
FC-ID
00:0e:1e:0c:54:a6 Te 0/14 00:05:73:f2:4f:ae Pol28 100 0e:fc:00:9a:00:27 9a:
00:27 20:01:00:0e:1e:0c:54:a6
00:0e:1e:06:01:5e Te 0/16 00:05:73:f2:4f:af Pol28 100 0e:fc:00:9a:01:18 9a:
01:18 20:01:00:0e:1e:06:01:5
Port WWNN
20:00:00:0e:1e:0c:54:a6
20:00:00:0e:1e:0c:54:a6
```

show fip-snooping statistics

Displays statistics on the FIP packets snooped on all interfaces, including VLANs, physical ports, and port channels..

Syntax `show fip-snooping statistics [interface vlan vlan-id | interface port-type port/slot | interface port-channel port-channel-number]`

Parameters

<i>vlan-id</i>	Enter the VLAN ID of the FIP packet statistics to be displayed.
<i>port-type port/slot</i>	Enter the port-type and slot number of the FIP packet statistics to be displayed.
<i>port-channel-number</i>	Enter the port channel number of the FIP packet statistics to be displayed.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

The following table describes the `show fip-snooping statistics` command.

Field	Description
Number of Vlan Requests	Number of FIP-snooped VLAN request frames received on the interface.
Number of VLAN Notifications	Number of FIP-snooped VLAN notification frames received on the interface
Number of Multicast Discovery Solicits	Number of FIP-snooped multicast discovery solicit frames received on the interface.



Field	Description
Number of Unicast Discovery	Number of FIP-snooped unicast discovery solicit frames received on the interface.
Number of FLOGI	Number of FIP-snooped FLOGI request frames received on the interface.
Number of FDISC	Number of FIP-snooped FDISC request frames received on the interface
Number of FLOGO	Number of FIP-snooped FLOGO frames received on the interface
Number of ENode Keep Alives	Number of FIP-snooped ENode keep-alive frames received on the interface
Number of VN Port Keep Alives	Number of FIP-snooped VN port keep-alive frames received on the interface
Number of Multicast Discovery Advertisements	Number of FIP-snooped multicast discovery advertisements received on the interface
Number of Unicast Discovery Advertisements	Number of FIP-snooped unicast discovery advertisements received on the interface
Number of FLOGI Accepts	Number of FIP FLOGI accept frames received on the interface
Number of FLOGI Rejects	Number of FIP FLOGI reject frames received on the interface
Number of FDISC Accepts	Number of FIP FDISC accept frames received on the interface
Number of FDISC Rejects	Number of FIP FDISC reject frames received on the interface
Number of FLOGO Accepts	Number of FIP FLOGO accept frames received on the interface
Number of FLOGO Rejects	Number of FIP FLOGO reject frames received on the interface
Number of CVLs	Number of FIP clear virtual link frames received on the interface
Number of FCF Discovery	Number of FCF discovery timeouts that occurred on the interface
Number of VN Port Session	Number of VN port session timeouts that occurred on the interface
Number of Session failures due to Hardware Config	Number of session failures due to hardware configuration that occurred on the interface

Example

```

Dell# show fip-snooping statistics interface vlan 100
Number of Vlan Requests                               :0
Number of Vlan Notifications                           :0
Number of Multicast Discovery Solicits                  :2
Number of Unicast Discovery Solicits                   :0

```



```

Number of FLOGI :2
Number of FDISC :16
Number of FLOGO :0
Number of Enode Keep Alive :9021
Number of VN Port Keep Alive :3349
Number of Multicast Discovery Advertisement :4437
Number of Unicast Discovery Advertisement :2
Number of FLOGI Accepts :2
Number of FLOGI Rejects :0
Number of FDISC Accepts :16
Number of FDISC Rejects :0
Number of FLOGO Accepts :0
Number of FLOGO Rejects :0
Number of CVL :0
Number of FCF Discovery Timeouts :0
Number of VN Port Session Timeouts :0
Number of Session failures due to Hardware Config :0
Dell(conf) #

```

```

Dell# show fip-snooping statistics int tengigabitethernet 0/11
Number of Vlan Requests :1
Number of Vlan Notifications :0
Number of Multicast Discovery Solicits :1
Number of Unicast Discovery Solicits :0
Number of FLOGI :1
Number of FDISC :16
Number of FLOGO :0
Number of Enode Keep Alive :4416
Number of VN Port Keep Alive :3136
Number of Multicast Discovery Advertisement :0
Number of Unicast Discovery Advertisement :0
Number of FLOGI Accepts :0
Number of FLOGI Rejects :0
Number of FDISC Accepts :0
Number of FDISC Rejects :0
Number of FLOGO Accepts :0
Number of FLOGO Rejects :0
Number of CVL :0
Number of FCF Discovery Timeouts :0
Number of VN Port Session Timeouts :0
Number of Session failures due to Hardware Config :0

```

Example (port channel)

```

Dell# show fip-snooping statistics interface port-channel 22
Number of Vlan Requests :0
Number of Vlan Notifications :2
Number of Multicast Discovery Solicits :0
Number of Unicast Discovery Solicits :0
Number of FLOGI :0
Number of FDISC :0
Number of FLOGO :0
Number of Enode Keep Alive :0
Number of VN Port Keep Alive :0
Number of Multicast Discovery Advertisement :4451
Number of Unicast Discovery Advertisement :2
Number of FLOGI Accepts :2
Number of FLOGI Rejects :0
Number of FDISC Accepts :16
Number of FDISC Rejects :0
Number of FLOGO Accepts :0
Number of FLOGO Rejects :0
Number of CVL :0
Number of FCF Discovery Timeouts :0
Number of VN Port Session Timeouts :0
Number of Session failures due to Hardware Config :0

```



show fip-snooping system

Displays information on the status of FIP snooping on the switch (enabled or disabled), including the number of FCoE VLANs, FCFs, ENodes, and currently active sessions.

Syntax `show fip-snooping system`

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell# show fip-snooping system
Global Mode                : Enabled
FCOE VLAN List (Operational) : 1, 100
FCFs                       : 1
Enodes                     : 2
Sessions                   : 17
```

show fip-snooping vlan

Display information on the FIP snooping operational VLANs.

Syntax `show fip-snooping vlan`

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Introduced on the M I/O Aggregator.

Example

```
Dell# show fip-snooping vlan
* = Default VLAN
```

VLAN	FC-MAP	FCFs	Enodes	Sessions
----	-----	----	-----	-----
*1	-	-	-	-
1002	0X0EFC00	1	1	1



Internet Group Management Protocol (IGMP)

The Dell Networking OS supports IGMP snooping version 2 and 3 on all Dell Networking systems.

IGMP Commands

The Dell Networking OS supports the following IGMP commands:

- [clear ip igmp groups](#)
- [debug ip igmp](#)
- [ip igmp group-join-limit](#)
- [ip igmp querier-timeout](#)
- [ip igmp query-interval](#)
- [ip igmp query-max-resp-time](#)
- [ip igmp snooping enable](#)
- [ip igmp snooping fast-leave](#)
- [ip igmp snooping flood](#)
- [ip igmp snooping last-member-query-interval](#)
- [ip igmp snooping mrouter](#)
- [ip igmp snooping querier](#)
- [ip igmp version](#)
- [show ip igmp groups](#)
- [show ip igmp interface](#)
- [show ip igmp snooping mrouter](#)

Important Points to Remember

- Dell Networking OS supports version 1, version 2, and version 3 hosts.
- Dell Networking OS IGMP snooping implementation is based on IP multicast address (not based on Layer 2 multicast mac-address) and the IGMP snooping entries are in Layer 3 flow table not in Layer 2 forwarding information base (FIB).
- Dell Networking OS IGMP snooping implementation is based on draft-ietf-magma-snoop-10.
- IGMP snooping is supported on all M I/O Aggregator stack members.
- IGMP snooping is enabled by default on the switch.
- A maximum of 8k groups and 4k virtual local area networks (VLAN) are supported.
- IGMP snooping is not supported on default VLAN interface.
- Flooding of unregistered multicast traffic is enabled by default.
- Queries are not accepted from the server side ports and are only accepted from the uplink LAG.
- Reports and Leaves are flooded by default to the uplink LAG irrespective of whether it is an mrouter port or not.

IGMP Snooping Commands

Dell Networking OS supports IGMP Snooping version 2 and 3 on all Dell Networking systems.

Important Points to Remember for IGMP Snooping

- Dell Networking OS supports version 1, version 2, and version 3 hosts.
- Dell Networking OS IGMP snooping implementation is based on IP multicast address (not based on Layer 2 multicast mac address) and the IGMP snooping entries are in Layer 3 flow table not in Layer 2 forwarding information base (FIB).
- Dell Networking OS IGMP snooping implementation is based on draft-ietf-magma-snoop-10.
- Dell Networking OS supports IGMP snooping on JUMBO-enabled cards.
- IGMP snooping is not enabled by default on the switch.
- A maximum of 1800 groups and 600 VLAN are supported.
- IGMP snooping is not supported on a default VLAN interface.
- IGMP snooping is not supported over VLAN-Stack-enabled VLAN interfaces (you must disable IGMP snooping on a VLAN interface before configuring VLAN-Stack-related commands).

clear ip igmp groups

Clear entries from the group cache table.

Syntax	<code>clear ip igmp groups [group-address interface]</code>	
Parameters	group-address	(OPTIONAL) Enter the IP multicast group address in dotted decimal format.
	interface	(OPTIONAL) Enter the interface type and slot/port information: For a VLAN interface enter the keyword <code>vlan</code> followed by a number from 1 to 4094.
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

debug ip igmp

Enable debugging of IGMP packets.

Syntax	<code>debug ip igmp [group address interface]</code>	
	To disable IGMP debugging, enter the <code>no ip igmp</code> command. To disable all debugging, enter the <code>undebug all</code> command.	
Defaults	Disabled	
Parameters	group-address	(OPTIONAL) Enter the IP multicast group address in dotted decimal format.



interface (OPTIONAL) Enter the interface type and slot/port information:
For a VLAN interface enter the keyword `vlan` followed by a number from 1 to 4094.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

ip igmp group-join-limit

To limit the number of IGMP groups that can be joined in a second, use this feature.

Syntax `ip igmp group-join-limit number`

Parameters

<i>number</i>	Enter the number of IGMP groups permitted to join in a second. The range is from 1 to 10000.
---------------	--

Defaults none

Command Modes CONFIGURATION (*conf-if-interface-slot/port*)

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

ip igmp querier-timeout

Change the interval that must pass before a multicast router decides that there is no longer another multicast router that should be the querier.

Syntax `ip igmp querier-timeout seconds`
To return to the default value, use the `no ip igmp querier-timeout` command.

Parameters

<i>seconds</i>	Enter the number of seconds the router must wait to become the new querier. The range is from 60 to 300. The default is 125 seconds .
----------------	--

Defaults **125 seconds**

Command Modes INTERFACE

Supported Modes Programmable-Mux (PMUX)



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

ip igmp query-interval

Change the transmission frequency of IGMP general queries the Querier sends.

Syntax `ip igmp query-interval seconds`
 To return to the default values, use the `no ip igmp query-interval` command.

Parameters

seconds	Enter the number of seconds between queries sent out. The range is from 1 to 18000. The default is 60 seconds .
----------------	--

Defaults **60 seconds**

Command Modes INTERFACE

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

ip igmp query-max-resp-time

Set the maximum query response time advertised in general queries.

Syntax `ip igmp query-max-resp-time seconds`
 To return to the default values, use the `no ip igmp query-max-resp-time` command.

Parameters

seconds	Enter the number of seconds for the maximum response time. The range is from 1 to 25. The default is 10 seconds .
----------------	--

Defaults **10 seconds**

Command Modes INTERFACE

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.



ip igmp snooping enable

Enable IGMP snooping on all or a single VLAN. This command is the master on/off switch to enable IGMP snooping.

Syntax `ip igmp snooping enable`

To disable IGMP snooping, use the `no ip igmp snooping enable` command.

Defaults Disabled.

Command Modes

- CONFIGURATION
- INTERFACE VLAN

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

Usage Information To enable IGMP snooping, enter this command. When you enable this command from CONFIGURATION mode, IGMP snooping enables on all VLAN interfaces (except the default VLAN).



NOTE: Execute the `no shutdown` command on the VLAN interface for IGMP Snooping to function.

ip igmp snooping fast-leave

Enable IGMP snooping fast-leave for this VLAN.

Syntax `ip igmp snooping fast-leave`

To disable IGMP snooping fast leave, use the `no igmp snooping fast-leave` command.

Defaults Not configured.

Command Modes INTERFACE VLAN — (conf-if-vl-*n*)

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

Usage Information Queriers normally send some queries when a leave message is received prior to deleting a group from the membership database. There may be situations when you require a fast deletion of a group. When you enable IGMP fast leave processing, the switch removes an interface from the multicast group as soon as it detects an IGMP version 2 leave message on the interface.

ip igmp snooping flood

This command controls the flooding behavior of unregistered multicast data packets. When flooding is disabled, unregistered multicast data traffic is forwarded to *only* multicast router ports in a VLAN. If there is no multicast router port in a VLAN, unregistered multicast data traffic is dropped.

Syntax `ip igmp snooping flood`
To disable the flooding, use the `no ip igmp snooping flood` command.

Parameters Enabled

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

ip igmp snooping last-member-query-interval

The last member query interval is the maximum response time inserted into Group-Specific queries sent in response to Group-Leave messages.

Syntax `ip igmp snooping last-member-query-interval milliseconds`
To return to the default value, use the `no ip igmp snooping last-member-query-interval` command.

Parameters *milliseconds* Enter the interval in milliseconds. The range is from 100 to 65535. The default is **1000 milliseconds**.

Defaults **1000 milliseconds**

Command Modes INTERFACE VLAN

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

Usage Information This last-member-query-interval is also the interval between successive Group-Specific Query messages. To change the last-member-query interval, use this command.



ip igmp snooping mrouter

Statically configure a VLAN member port as a multicast router interface.

Syntax `ip igmp snooping mrouter interface interface`
To delete a specific multicast router interface, use the `no ip igmp snooping mrouter interface interface` command.

Parameters `interface interface` Enter the following keywords and slot/port or number information:

- For a 100/1000 Ethernet interface, enter the keyword `gigabitethernet` followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword `gigabitethernet` followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` then the slot/port information.
- For a 40-Gigabit Ethernet interface, enter the keyword `fortyGigE` then the slot/port information.
- For a Port Channel interface, enter the keywords `port-channel` then a number.

Defaults Not configured.

Command Modes INTERFACE VLAN — (conf-if-vl-*n*)

Supported Modes Programmable-Mux (PMUX)

Command History This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following is a list of the Dell Networking OS version history for this command.

Version	Description
9.2(0.0)	Introduced on the M I/O Aggregator.

Usage Information Dell Networking OS provides the capability of statically configuring the interface to which a multicast router is attached. To configure a static connection to the multicast router, enter the `ip igmp snooping mrouter interface` command in the VLAN context. The interface to the router must be a part of the VLAN where you are entering the command.

ip igmp snooping querier

Enable IGMP querier processing for the VLAN interface.

Syntax `ip igmp snooping querier`
To disable IGMP querier processing for the VLAN interface, use the `no ip igmp snooping querier` command.

Defaults Not configured.

Command Modes INTERFACE VLAN — (conf-if-vl-*n*)



Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
Usage Information	This command enables the IGMP switch to send General Queries periodically. This behavior is useful when there is no multicast router present in the VLAN because the multicast traffic is not routed. Assign an IP address to the VLAN interface for the switch to act as a querier for this VLAN.	

ip igmp version

Manually set the version of the router to IGMPv2 or IGMPv3.

Syntax	<code>ip igmp version {2 3}</code>	
Parameters	2	Enter the number 2 to set the IGMP version number to IGMPv2.
	3	Enter the number 3 to set the IGMP version number to IGMPv3.
Defaults	2 (that is, IGMPv2)	
Command Modes	INTERFACE	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

show ip igmp groups

View the IGMP groups.

Syntax	<code>show ip igmp groups [group-address [detail] detail interface [group-address [detail]]]</code>	
Parameters	group-address	(OPTIONAL) Enter the group address in dotted decimal format to view information on that group only.
	interface	(OPTIONAL) Enter the interface type and slot/port information: For a VLAN interface enter the keyword <code>vlan</code> followed by a number from 1 to 4094.
	detail	(OPTIONAL) Enter the keyword <code>detail</code> to display the IGMPv3 source information.
Command Modes	· EXEC	



- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show ip igmp groups
Total Number of Groups: 5
IGMP Connected Group Membership
Group Address Interface Mode Uptime
Expires Last Reporter
225.0.0.0 Vlan 100 IGMPv2 00:00:05
00:02:04 3.0.0.51
Member Ports: Po 2
225.0.0.2 Vlan 100 IGMPv2 00:00:05
00:02:04 3.0.0.51
Member Ports: Po 2
225.0.0.3 Vlan 100 IGMPv2 00:00:05
00:02:04 3.0.0.51
Member Ports: Po 2
225.0.0.4 Vlan 100 IGMPv2 00:00:05
00:02:04 3.0.0.51
Member Ports: Po 2
```

Field

Group Address

Interface

Mode

Uptime

Expires

Last Reporter

Member Ports

Description

Lists the multicast address for the IGMP group.

Lists the interface type, slot and port number.

Displays the IGMP version used.

Displays the amount of time the group has been operational.

Displays the amount of time until the entry expires.

Displays the IP address of the last host to be a member of the IGMP group.

Indicates the member ports of the port channel. If the port channel is VLT, an asterisk (*) after the port channel number indicates the port channel is locally down and that a remote VLT port is up.

show ip igmp interface

View information on the interfaces participating in IGMP.

Syntax `show ip igmp interface [interface]`

Parameters

interface (OPTIONAL) Enter any of the following keywords and slot/port or number to clear counters from a specified interface:



- For a Port Channel interface, enter the keyword port-channel followed by a number. Range: 1-128
- For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
- For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show ip igmp interface
Vlan 2 is up, line protocol is down
Inbound IGMP access group is not set
Interface IGMP group join rate limit is not set
IGMP snooping is enabled on interface
IGMP Snooping query interval is 60 seconds
IGMP Snooping querier timeout is 125 seconds
IGMP Snooping last member query response interval is 1000 ms
IGMP snooping fast-leave is disabled on this interface
IGMP snooping querier is disabled on this interface
Vlan 3 is up, line protocol is down
Inbound IGMP access group is not set
Interface IGMP group join rate limit is not set
IGMP snooping is enabled on interface
IGMP Snooping query interval is 60 seconds
IGMP Snooping querier timeout is 125 seconds
IGMP Snooping last member query response interval is 1000 ms
IGMP snooping fast-leave is disabled on this interface
IGMP snooping querier is disabled on this interface
--More--
```

show ip igmp snooping mrouter

Displays multicast router interfaces.

Syntax `show ip igmp snooping mrouter [vlan number]`

Parameters

vlan number	Enter the keyword vlan followed by the vlan number. Range: 1 to 4094
--------------------	--

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes



Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show ip igmp snooping mrouter vlan 2
Interface Router Ports
Vlan 2 Po 128
Dell#
```

Related Commands [show ip igmp groups](#) — Use this IGMP command to view groups.



Interfaces

This chapter defines the interface commands on the Aggregator switch.

Port Interface Commands

The following commands are for physical, loopback, and null interfaces:

- [clear counters](#)
- [clear mac-address-table dynamic](#)
- [interface range](#)
- [interface vlan](#)
- [keepalive](#)
- [monitor interface](#)
- [name](#)
- [show config \(INTERFACE mode\)](#)
- [show config \(from INTERFACE RANGE mode\)](#)
- [show config \(from INTERFACE VLAN mode\)](#)
- [show interfaces configured](#)
- [show interfaces description](#)
- [show interfaces stack-unit](#)
- [show interfaces port-channel](#)
- [show interfaces status](#)
- [show interfaces switchport](#)
- [show vlan](#)
- [shutdown](#)
- [speed \(for 1000/10000 interfaces\)](#)

Port Channel Commands

A Link Aggregation Group (LAG) is a group of links that appear to a MAC client as if they were a single link according to IEEE 802.3ad. In Dell Networking OS, a LAG is referred to as a Port Channel.

- For the Aggregator, the maximum port channel ID is 128 and the maximum members per port channel is 16.

Because each port can be assigned to only one Port Channel, and each Port Channel must have at least one port, some of those nominally available Port Channels might have no function because they could have no members if there are not enough ports installed. In the Aggregator, stack members can provide those ports.

The commands in this section are specific to Port Channel interfaces:

- [auto vlan](#)



- [monitor interface](#)
- [show config \(from INTERFACE RANGE mode\)](#)
- [show interfaces port-channel](#)

 **NOTE:** The Dell Networking OS implementation of LAG or Port Channel requires that you configure a LAG on both switches manually. For information about Dell Networking OS link aggregation control protocol (LACP) for dynamic LAGs, refer to the [Link Aggregation Control Protocol \(LACP\)](#) chapter. For more information about configuring and using Port Channels, refer to the *Dell PowerEdge M I/O Aggregator Configuration Guide*

Time Domain Reflectometer (TDR) Commands

TDR is useful for troubleshooting an interface that is not establishing a link; either it is flapping or not coming up at all. TDR detects open or short conditions of copper cables on 100/1000/10G Base-T modules.

- [tdr-cable-test](#)
- [show tdr](#)

Important Points to Remember

- The interface and port must be enabled (configured—see the `interface` command) before running TDR. An error message is generated if you have not enabled the interface.
- The interface on the far-end device must be shut down before running TDR.
- Because TDR is an intrusive test on an interface that is not establishing a link, do not run TDR on an interface that is passing traffic.
- When testing between two devices, do not run the test on both ends of the cable.

Virtual LAN (VLAN) Commands

The following commands configure and monitor virtual local area networks (VLANs). VLANs are a virtual interface and use many of the same commands as physical interfaces.

You can configure an IP address only on the default VLAN. FTP, TFTP, ACLs, and SNMP are not supported on a VLAN.

Occasionally, while sending broadcast traffic over multiple VLANs, state of a VLAN interface may continually switch between Master and Backup.

- [auto vlan](#)
- [default vlan-id](#)
- [name](#)
- [show config \(from INTERFACE VLAN mode\)](#)
- [show vlan](#)
- [vlan tagged](#)
- [vlan untagged](#)

auto vlan

Change the port to auto or admin vlan mode (enable or disable all auto VLANs).

Syntax `auto vlan`

To remove membership from 4K VLAN, use the `no auto vlan` command.

Defaults	none	
Parameters	description	Enter a text string description to identify the VLAN (80 characters maximum).
Command Modes	INTERFACE	
Supported Modes	Standalone Mode	
Usage Information	The <code>auto vlan</code> command adds the port as untagged to default vlan and tagged to all other 4094 VLAN.	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

channel-member

Add an interface to the Port Channel, while in INTERFACE PORTCHANNEL mode.

Syntax	<code>channel-member interface</code>
	To delete an interface from a Port Channel, use the <code>no channel-member interface</code> command.

Parameters	interface	(OPTIONAL) Enter any of the following keywords and slot/port or number information: • For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. • For a 40-Gigabit Ethernet interface, enter the keyword <code>fortyGigE</code> then the slot/port information.
------------	------------------	--

Defaults	Not configured.	
Command Modes	INTERFACE PORTCHANNEL	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information	Use the <code>interface port-channel</code> command to access this command.	
	You cannot add an interface to a Port Channel if the interface contains an IP address in its configuration.	
	Link MTU and IP MTU considerations for Port Channels are: • All members must have the same link MTU value and the same IP MTU value. • The Port Channel link MTU and IP MTU must be less than or equal to the link MTU and IP MTU values configured on the channel members. For example, if the members have a link MTU of 2100 and an IP	



MTU 2000, the Port Channel's MTU values cannot be higher than 2100 for link MTU or 2000 bytes for IP MTU.

When an interface is removed from a Port Channel with the `no channel-member` command, the interface reverts to its configuration prior to joining the Port Channel.

An interface can belong to only one Port Channel.

You can add up to 16 interfaces to a Port Channel on the MXL switch. The interfaces can be located on different line cards but must be the same physical type and speed (for example, all 10-Gigabit Ethernet interfaces). However, you can combine 100/1000 interfaces and GE interfaces in the same Port Channel.

If the Port Channel contains a mix of interfaces with 100 Mb/s speed and 1000 Mb/s speed, the software disables those interfaces whose speed does not match the speed of the first interface configured and enabled in the Port Channel. If that first interface goes down, the Port Channel does not change its designated speed; disable and re-enable the Port Channel or change the order of the channel members configuration to change the designated speed. If the Port Channel contains a mix of interfaces with 100 Mb/s speed and 1000 Mb/s speed, the software disables those interfaces whose speed does not match the speed of the first interface configured and enabled in the Port Channel. If that first interface goes down, the Port Channel does not change its designated speed; disable and re-enable the Port Channel or change the order of the channel members configuration to change the designated speed. For more information about Port Channels, refer to the *Dell Networking OS Configuration Guide*.

Related Commands [interface port-channel](#) — creates a Port Channel interface.

clear counters

Clear the counters used in the `show interfaces` commands for VLANs, and physical interfaces, or selected ones.

Syntax `clear counters interface`

Defaults Without a specific interface specified, the command clears all interface counters.

Parameters

interface	(OPTIONAL) Enter any of the following keywords and slot/port or number to clear counters from a specified interface:
	• For the management interface on the stack-unit, enter the keyword <code>managementethernet</code> followed by slot/port information. The slot and port range is 0. • For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information. • For a Port Channel interface, enter the keyword <code>port-channel</code> followed by a number. Range: 1-128

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.



Example Dell#clear counters
Clear counters on all interfaces [confirm]

clear mac-address-table dynamic

Clear the MAC address table of all MAC addresses learned dynamically.

Syntax clear mac-address-table dynamic {interface tengigabitethernet *slot/port-id*}

Parameters

interface	Enter the keyword <code>interface range</code> and one of the interfaces — slot/port, port-channel or VLAN number. Select the range of interfaces for bulk configuration. You can enter up to six comma separated ranges-spaces are not required between the commas. Comma-separated ranges can include VLANs, port-channels and physical interfaces. Slot/Port information must contain a space before and after the dash. For example, interface range tengigabitethernet 0/1 - 5 is valid; interface range tengigabitethernet 0/1-5 is not valid. • For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information.
------------------	--

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

default vlan-id

Set the default VLAN ID.

Syntax default vlan-id <vlan-id>
To reset the default VLAN ID, use the `no default vlan-id` command.

Defaults none

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.



Related commands [show vlan](#) — Displays VLAN configuration.

description

Assign a descriptive text string to the interface.

Syntax `description desc_text`
To delete a description, enter `no description` command.

Parameters ***desc_text*** Enter a text string up to 240 characters long.

Defaults No description is defined.

Command Modes INTERFACE

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

- Usage Information**
- Spaces between characters are not preserved after entering this command unless you enclose the entire description in quotation marks ("desc_text").
 - Entering a text string after the default `vlan-id` command overwrites any previous text string configured as the description.
 - The `show tdr` and default `vlan-id` commands are the only commands that you can configure on an interface that is a member of a port-channel.
 - Use the `show interfaces description` command to display descriptions configured for each interface.

Related commands [show interfaces description](#) — Displays the description field of interfaces.

feature fc

Enables the Fibre channel communication via the NPG functionality.

Syntax `feature fc`

Command Modes CONFIGURATION

Default Enabled

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.6(0.0)	Supported on the FN 2210S Aggregator and M I/O Aggregator.



flowcontrol

Control how the system responds to and generates 802.3x pause frames on 10G and 40Gig stack units.

Syntax `flowcontrol rx {off | on} tx {off | on} threshold`

Parameters	rx on	Enter the keywords <code>rx on</code> to process the received flow control frames on this port. This is the default value for the receive side.
	rx off	Enter the keywords <code>rx off</code> to ignore the received flow control frames on this port.
	tx on	Enter the keywords <code>tx on</code> to send control frames from this port to the connected device when a higher rate of traffic is received. This is the default value on the send side.
	tx off	Enter the keywords <code>tx off</code> so that flow control frames are not sent from this port to the connected device when a higher rate of traffic is received.

Defaults

- `rx off`
- `tx off`

Command Modes INTERFACE

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information The globally assigned 48-bit Multicast address 01-80-C2-00-00-01 is used to send and receive pause frames. To allow full duplex flow control, stations implementing the pause operation instruct the MAC to enable the reception of frames with a destination address equal to this multicast address.

The pause:


- Starts when *either* the packet pointer or the buffer threshold is met (whichever is met first). When the discard threshold is met, packets are dropped.
- Ends when *both* the packet pointer and the buffer threshold fall below 50% of the threshold settings.

The *discard threshold* defines when the interface starts dropping the packet on the interface. This may be necessary when the connected device does not honor the flow control frame sent by the switch. The discard threshold should be larger than the *buffer threshold* so that the buffer holds at least hold at least three packets.

Important Points to Remember

- Do not enable `tx pause` when buffer carving is enabled. For information and assistance, consult Dell Networking TAC.
- Asymmetric flow control (`rx on tx off`, or `rx off tx on`) setting for the interface port less than 100 Mb/s speed is not permitted. The following error is returned:
`Can't configure Asymmetric flowcontrol when speed <1G, config ignored`
- The only configuration applicable to half duplex ports is `rx off tx off`. The following error is returned:
`Cannot configure Asymmetric flowcontrol when speed <1G, config ignored>`
- You cannot configure half duplex when the flow control configuration is on (default is `rx on tx on`). The following error is returned: `Cannot configure half duplex when flowcontrol is on, config ignored`





```

Dell(conf-if-tengig-0/1)#show config
!
interface TenGigabitEthernet 0/1
no ip address
switchport
no negotiation auto
flowcontrol rx off tx on
no shutdown
...

```

This Example shows how the Dell Networking OS negotiates the flow control values between two Dell Networking chassis connected back-to-back using 1G copper ports.

Configured			
LocRxConf	LocTxConf	RemoteRxConf	RemoteTxConf
off	off	off	off
		off	on
		on	off
		on	on
off	on	off	off
		off	on
		on	off
		on	on
on	off	off	off
		off	on
		on	off
		on	on
on	on	off	off
		off	on
		on	off
		on	on
LocNegRx	LocNegTx	RemNegRx	RemNegTx
off	off	off	off
off	off	off	off
off	off	off	off
off	off	off	off
off	off	off	off
off	off	off	off
off	off	off	off
off	on	on	off
off	off	off	off
off	off	off	off
on	off	off	on
on	on	on	on
on	on	on	on
off	off	off	off
off	off	off	off
on	on	on	on
on	on	on	on

[show running-config](#) — displays the flow configuration parameters (non-default values only).

`show interfaces` — displays the negotiated flow control parameters.

interface

Configure a physical interface on the switch.

Syntax `interface interface`

Parameters *interface* Enter one of the following keywords and slot/port or number information:

- For a 10-Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` then the slot/port information.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information You cannot delete a physical interface.

By default, physical interfaces are disabled (`shutdown`) and are in Layer 3 mode. To place an interface in mode, ensure that the interface's configuration does not contain an IP address and enter the `Port Channel Commands` command.

The tunnel interface operates as an ECMP (equal cost multi path) only when the next hop to the tunnel destination is over a physical interface. If you select any other interface as the next hop to the tunnel destination, the tunnel interface does not operate as an ECMP.

Example

```
Dell(conf)#interface tengig 0/1
Dell(conf-if-te-0/1)#exit#
```

Related Commands [interface port-channel](#) — configures a port channel.

[interface vlan](#) — configures a VLAN.

[show interfaces](#) — displays the interface configuration.

interface ManagementEthernet

Configure the Management port on the system.

Syntax `interface ManagementEthernet slot/port`

Parameters *slot/port* Enter the keyword `ManagementEthernet`, then the slot number (0) and port number zero (0).

Defaults Not configured.



Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	94.(0.0)	Supported on the FN I/O Aggregator and M I/O Aggregator.
Usage Information	You cannot delete a Management port.	
	The Management port is enabled by default (<code>no shutdown</code>). To assign an IP address to the Management port, use the <code>ip address</code> command.	
Example	<pre>Dell(conf)#interface managementethernet 0/0 Dell(conf-if-ma-0/0)#</pre>	

interface port-channel

Create a Port Channel interface, which is a link aggregation group (LAG) containing physical interfaces on the Aggregator.

Syntax	<code>interface port-channel <i>channel-number</i></code>	
	To delete a Port Channel, use the <code>no interface port-channel <i>channel-number</i></code> command.	
Parameters	<i>channel-number</i>	For a Port Channel interface, enter the keywords <code>port-channel</code> then a number. The range is from 1 to 128.
Defaults	Not configured.	
Command Modes	CONFIGURATION	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	94.(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Usage Information	Port Channel interfaces are logical interfaces and can be either in Layer 2 mode (by using the <code>switchport</code> command) or Layer 3 mode (by configuring an IP address). You can add a Port Channel in Layer 2 mode to a VLAN.	
	A Port Channel can contain both 100/1000 interfaces and GE interfaces. Based on the first interface configured in the Port Channel and enabled, the Dell Networking OS determines if the Port Channel uses 100 Mb/s or 1000 Mb/s as the common speed. For more information, refer to channel-member .	
	If the line card is in a Jumbo mode chassis, you can also configure the <code>mtu</code> and <code>ip mtu</code> commands. The Link MTU and IP MTU values configured on the channel members must be greater than the Link MTU and IP MTU values configured on the Port Channel interface.	





NOTE: In a Jumbo-enabled system, you must configure all members of a Port Channel with the same link MTU values and the same IP MTU values.

Example

```
Dell(conf)#int port-channel 2
Dell(conf-if-po-2)#
```

Related Commands [channel-member](#) — adds a physical interface to the LAG.

[interface](#) — configures a physical interface.

[interface vlan](#) — configures a VLAN.

interface range

This command permits configuration of a range of interfaces to which subsequent commands are applied (bulk configuration). Using the interface range command, you can enter identical commands for a range of interface.

Syntax

```
interface range interface, interface,...
```

To delete a description, enter `no description` command.

Parameters

**interface,
interface,...**

Enter the keyword interface range and one of the interfaces — slot/port, port-channel or VLAN number. Select the range of interfaces for bulk configuration. You can enter up to six comma separated ranges—spaces are not required between the commas. Comma-separated ranges can include VLANs, port-channels and physical interfaces.

Slot/Port information must contain a space before and after the dash. For example, `interface range tengigabitethernet 0/1 - 5` is valid; `interface range tengigabitethernet 0/1-5` is not valid.

- For a 10-Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` followed by the slot/port information.
- For a VLAN, enter the keyword `vlan` followed by a number from 1 to 4094.

Defaults none

Command Modes CONFIGURATION

Supported Modes All Modes

Command History

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information When creating an interface range, interfaces appear in the order they are entered; they are not sorted. The command verifies that interfaces are present (physical) or configured (logical). Important things to remember:

- Bulk configuration is created if at least one interface is valid.
- Non-existing interfaces are excluded from the bulk configuration with a warning message.



- The interface range prompt includes interface types with slot/port information for valid interfaces. The prompt allows for a maximum of 32 characters. If the bulk configuration exceeds 32 characters, it is represented by an ellipsis (...).
- When the interface range prompt has multiple port ranges, the smaller port range is excluded from the prompt.
- If overlapping port ranges are specified, the port range is extended to the smallest start port and the biggest end port.

Example-Bulk Configuration Warning Message

```
Dell(conf)#interface range tengig 2/0 - 1 , tengig 10/0 , tengig 3/0
, fa 0/0
% Warning: Non-existing ports (not configured) are ignored by
interface-range
```

Example-Interface Range prompt with Multiple Ports

```
Dell(conf)#interface range tengig 2/0 - 23 , tengig 2/1 - 10
Dell(conf-if-range-tengig-2/0-23#
```

Example-Interface Range prompt Overlapping Port Ranges

```
Dell(conf)#interface range tengig 2/1 - 11 , tengig 2/1 - 23
Dell(conf-if-range-tengig-2/1-23#
```

Only VLAN and port-channel interfaces created using the `interface vlan` and `vlan tagged` commands can be used in the `interface range` command.

Use the `show running-config` command to display the VLAN and port-channel interfaces. VLAN or port-channel interfaces that are not displayed in the `show running-config` command cannot be used with the bulk configuration feature of the `interface range` command. You cannot create virtual interfaces (VLAN, Port-channel) using the `interface range` command.



NOTE: If a range has VLAN, physical, and port-channel interfaces, only commands related to physical interfaces can be bulk configured. To configure commands specific to VLAN or port-channel, only those respective interfaces should be configured in a particular range.

Example-Single Range Bulk Configuration

```
Dell(conf)# interface range tengigabitethernet 5/1 - 23
Dell(conf-if-range)# no shutdown
Dell(conf-if-range)#
```

Example-Multiple Range Bulk Configuration Gigabit Ethernet and Ten Gigabit Ethernet

The following example shows how to use commas to add different interface types to the range enabling all TenGigabit Ethernet interfaces in the range 5/1 to 5/23 and both Ten Gigabit Ethernet interfaces 1/1 and 1/2.

```
Dell(conf-if)# interface range tengigabitethernet 5/1 - 23,
tengigabitethernet 1/1 - 2
Dell(conf-if-range)# no shutdown
Dell(conf-if-range)#
```

Example-Multiple Range Bulk Configuration with VLAN and port channel

The following example shows how to use commas to add VLAN and port-channel interfaces to the range.

```
Dell(conf-if)# interface range tengigabitethernet 5/1 - 23,
tengigabitethernet 1/1 - 2,
Vlan 2 - 100 , Port 1 - 25
Dell(conf-if-range)# no shutdown
Dell(conf-if-range)#
```

Related commands

[show config \(from INTERFACE RANGE mode\)](#) — Shows the bulk configuration interfaces.
[show interfaces status](#) — Displays a summary of interface information.

interface vlan

Configure a VLAN. Configure the default VLAN to enable Static or DHCP IP configuration. You can configure up to 4094 VLANs.

Syntax	<code>interface vlan <i>vlan-id</i></code>	
	To delete a VLAN, use the <code>no interface vlan <i>vlan-id</i></code> command.	
Parameters	<i>vlan-id</i>	Enter 1 for the default VLAN. Enter a number as the VLAN identifier. The range is from 1 to 4096.
Defaults	Not configured, except for the default VLAN, which is configured as VLAN 1.	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	For more information about VLANs and the commands to configure them, refer to Virtual LAN (VLAN) Commands . FTP, TFTP, and SNMP operations are not supported on a VLAN. MAC/IP ACLs are not supported.	
Examples	<pre>Dell(conf)#int vlan 1 Dell(conf-if-vl-1)# Dell(conf)#int vlan 3 Dell(conf-if-vl-3)#</pre>	
Related commands	show vlan — Displays the current VLAN configuration on the switch. vlan tagged — Adds a Layer 2 interface to a VLAN as a tagged interface. vlan untagged — Adds a Layer 2 interface to a VLAN as an untagged interface.	

intf-type cr4 autoneg

Set the interface type as CR4 with auto-negotiation enabled.

Syntax	<code>intf-type cr4 autoneg</code>	
	If you configure <code>intf-type cr4 autoneg</code> , use the <code>no intf-type cr4 autoneg</code> command to set the interface type as cr4 with autonegotiation disabled.	
Defaults	Not configured	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	If you configure <code>interface type</code> as CR4 with auto-negotiation enabled, also configure CR4 with auto-negotiation. Many DAC cable link issues are resolved by setting the interface type as CR4.	
Related Commands	interface — configures a physical interface.	
	interface port-channel — configures a port channel group.	

keepalive

Send keepalive packets periodically to keep an interface alive when it is not transmitting data.

Syntax	<code>keepalive [seconds]</code>	
	To stop sending keepalive packets, use the <code>no keepalive</code> command.	
Parameters	seconds	(OPTIONAL) For interfaces with PPP encapsulation enabled, enter the number of seconds between keepalive packets. The range is from 0 to 23767. The default is 10 seconds .
Defaults	Enabled.	
Command Modes	INTERFACE	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Usage Information	When you configure <code>keepalive</code> , the system sends a self-addressed packet out of the configured interface to verify that the far end of a WAN link is up. When you configure <code>no keepalive</code> , the system does not send keepalive packets and so the local end of a WAN link remains up even if the remote end is down.	

minimum-links

Configure the minimum number of links in a LAG (Port Channel) that must be in “oper up” status for the LAG to be also in “oper up” status.

Syntax	<code>minimum-links number</code>
--------	-----------------------------------



Parameters	<i>number</i>	Enter the number of links in a LAG that must be in “oper up” status. The range is from 1 to 16. The default is 1 .								
Defaults	1									
Command Modes	INTERFACE									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.	
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									
Usage Information	If you use this command to configure the minimum number of links in a LAG that must be in “oper up” status, the LAG must have at least that number of “oper up” links before it can be declared as up. For example, if the required minimum is four, and only three are up, the LAG is considered down.									

monitor interface

Monitor counters on a single interface or all interfaces on a stack unit. The screen is refreshed every five seconds and the CLI prompt disappears.

Syntax `monitor interface [interface]`
 To disable monitoring and return to the CLI prompt, press the `q` key.

Parameters *interface* (OPTIONAL) Enter the following keywords and slot/port or number information:

- For the management port, enter the keyword `managementethernet` followed by the slot (0 or 1) and the port (0).
- For a 10-Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` followed by the slot/port information.
- For a Port Channel interface, enter the keyword `port-channel` followed by a number. The range is from 1 to 4094.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
8.3.17.0	Supported on M I/O Aggregator.

Usage Information The delta column displays changes since the last screen refresh.
 The following are the `monitor` command menu options.



Key	Description
systest-3	Displays the host name assigned to the system.
monitor time	Displays the amount of time since the <code>monitor</code> interface command was entered.
time	Displays the amount of time the chassis is up (since last reboot).
m	Change the view from a single interface to all interfaces on the stack unit or visa-versa.
c	Refresh the view.
b	Change the counters displayed from Packets on the interface to Bytes.
r	Change the [delta] column from change in the number of packets/bytes in the last interval to rate per second.
l	Change the view to the next interface on the stack unit, or if in the stack unit mode, the next stack unit in the chassis.
a	Change the view to the previous interface on the stack unit, or if in line stack unit mode, the previous stack unit in the chassis.
T	Increase the screen refresh rate.
t	Decrease the screen refresh rate.
q	Return to the CLI prompt.

Example (Single Interface)

```
systest-3 Monitor time: 00:00:06 Refresh Intvl.: 2s Time: 03:26:26
Interface: tengig 0/3, Enabled, Link is Up, Linespeed is 1000 Mbit

Traffic statistics:      Current      Rate      Delta
  Input bytes:      9069828  43 Bps    86
  Output bytes:    606915800  43 Bps    86
  Input packets:      54001    0 pps     1
  Output packets:   9401589    0 pps     1
    64B packets:        67    0 pps     0
  Over 64B packets:   49166    0 pps     1
  Over 127B packets:    350    0 pps     0
  Over 255B packets:   1351    0 pps     0
  Over 511B packets:    286    0 pps     0
  Over 1023B packets:  2781    0 pps     0
Error statistics:
  Input underruns:      0    0 pps     0
  Input giants:        0    0 pps     0
  Input throttles:     0    0 pps     0
    Input CRC:         0    0 pps     0
  Input IP checksum:   0    0 pps     0
  Input overrun:       0    0 pps     0
  Output underruns:    0    0 pps     0
  Output throttles:    0    0 pps     0

m - Change mode          c - Clear screen
l - Page up              a - Page down
T - Increase refresh interval  t - Decrease refresh interval
q - Quit
```

Example (All Interfaces)

```
systest-3 Monitor time: 00:01:31 Refresh Intvl.: 2s Time: 03:54:14
Interface  Link    In Packets  [delta] Out Packets
[delta]
  Gi 0/0   Down        0         0         0         0
  Gi 0/1   Down        0         0         0         0
```



```

Gi 0/2 Up 61512 52 66160 42
Gi 0/3 Up 63086 20 9405888 24
Gi 0/4 Up 14697471418 2661481 13392989657
2661385
Gi 0/5 Up 3759 3 161959604 832816
Gi 0/6 Up 4070 3 8680346 5
Gi 0/7 Up 61934 34 138734357 72
Gi 0/8 Up 61427 1 59960 1
Gi 0/9 Up 62039 53 104239232 3
Gi 0/10 Up 17740044091 372 7373849244 79
Gi 0/11 Up 18182889225 44 7184747584 138
Gi 0/12 Up 18182682056 0 3682 1
Gi 0/13 Up 18182681434 43 6592378911 144
Gi 0/14 Up 61349 55 86281941 15
Gi 0/15 Up 59808 58 62060 27
Gi 0/16 Up 59889 1 61616 1
Gi 0/17 Up 0 0 14950126 81293
Gi 0/18 Up 0 0 0 0
Gi 0/19 Down 0 0 0 0
Gi 0/20 Up 62734 54 62766 18
Gi 0/21 Up 60198 9 200899 9
Gi 0/22 Up 17304741100 3157554 10102508511
1114221
Gi 0/23 Up 17304769659 3139507 7133354895
523329
m - Change mode c - Clear screen
b - Display bytes r - Display pkts/bytes per sec
l - Page up a - Page down

```

mtu

Set the link maximum transmission unit (MTU) (frame size) for an Ethernet interface.

Syntax

`mtu value`

To return to the default MTU value, use the `no mtu` command.

Parameters

value Enter a maximum frame size in bytes. The range is from 594 to 9252. MXL Switch Range is from 594 to 12000. The default is **1554**.

Defaults

1554

Command Modes

INTERFACE

Supported Modes

Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information

If the packet includes a Layer 2 header, the difference between the link MTU and IP MTU (`ip mtu` command) must be enough bytes to include the Layer 2 header.

- The IP MTU is adjusted automatically when you configure the Layer 2 MTU with the `mtu` command.



When you enter the `no mtu` command, The Dell Networking OS reduces the IP MTU value to 1536 bytes.

Link MTU and IP MTU considerations for port channels and VLANs are as follows.

port channels:

- All members must have the same link MTU value and the same IP MTU value.
- The port channel link MTU and IP MTU must be less than or equal to the link MTU and IP MTU values configured on the channel members. For example, if the members have a link MTU of 2100 and an IP MTU 2000, the port channel's MTU values cannot be higher than 2100 for link MTU or 2000 bytes for IP MTU.

VLANs:

- All members of a VLAN must have same IP MTU value.
- Members can have different Link MTU values. Tagged members must have a link MTU 4 bytes higher than untagged members to account for the packet tag.
- The VLAN link MTU and IP MTU must be less than or equal to the link MTU and IP MTU values configured on the VLAN members. For example, the VLAN contains tagged members with Link MTU of 1522 and IP MTU of 1500 and untagged members with Link MTU of 1518 and IP MTU of 1500. The VLAN's Link MTU cannot be higher than 1518 bytes and its IP MTU cannot be higher than 1500 bytes.

The following shows the difference between Link MTU and IP MTU.

Layer 2 Overhead	Link MTU and IP MTU Delta
Ethernet (untagged)	18 bytes
VLAN Tag	22 bytes
Untagged Packet with VLAN-Stack Header	22 bytes
Tagged Packet with VLAN-Stack Header	26 bytes

name

Assign a name to the Default VLAN.

Syntax `name vlan-name`

To remove the name from the VLAN, use the `no name` command.

Parameters `vlan-name` Enter up to 32 characters as the name of the VLAN.

Defaults Not configured.

Command Modes INTERFACE VLAN

Supported Modes All Modes



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	This CLI applies only to the Default VLAN. To display information about a named VLAN, enter the <code>show vlan</code> command with the name parameter or the <code>show interfaces description</code> command.	
Related commands	default vlan-id — Assigns a descriptive text string to the interface. interface vlan — Configures a VLAN. show vlan — Displays the current VLAN configurations on the switch.	

negotiation auto

Enable auto-negotiation on an interface.

Syntax	<pre>negotiation auto</pre> To disable auto-negotiation, enter <code>no negotiation auto</code> command.	
Defaults	Enabled.	
Command Modes	INTERFACE	
Supported Modes	All Modes	
Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator
Usage Information	The <code>no negotiation auto</code> command is only available if you first manually set the speed of a port to 10Mbits or 100Mbits. The <code>negotiation auto</code> command provides a mode option for configuring an individual port to forced-master/forced slave once auto-negotiation is enabled. If the mode option is not used, the default setting is slave. If you do not configure forced-master or forced slave on a port, the port negotiates to either a master or a slave state. Port status is one of the following: • Forced-master • Force-slave • Master • Slave • Auto-neg Error—typically indicates that both ends of the node are configured with forced-master or forced-slave	



 **CAUTION: Ensure that one end of your node is configured as forced-master and one is configured as forced-slave. If both are configured the same (that is forced-master or forced-slave), the show interfaces command will flap between an auto-neg-error and forced-master/slave states.**

You can display master/slave settings with the `show interfaces` command.

Example (Master/Slave)

```
Dell(conf)# interface tengig 0/0
Dell(conf-if)#neg auto
Dell(conf-if-autoneg)# ?

end          Exit from configuration mode
exit         Exit from autoneg configuration mode
mode         Specify autoneg mode
no           Negate a command or set its defaults
show         Show autoneg configuration information
Dell(conf-if-autoneg)#mode ?
forced-master Force port to master mode
forced-slave  Force port to slave mode
Dell(conf-if-autoneg)#
```

Example (Configured)

```
Dell#show interfaces configured
TenGigabitEthernet 13/18 is up, line protocol is up
Hardware is Dell Eth, address is 00:01:e8:05:f7:fc
Current address is 00:01:e8:05:f7:fc
Interface index is 474791997
Internet address is 1.1.1.1/24
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 1000 Mbit, Mode full duplex, Master
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interfaces" counters 00:12:42
Queueing strategy: fifo
Input Statistics:
...
```

User Information

Both sides of the link must have auto-negotiation enabled or disabled for the link to come up.

The following details the possible speed and auto-negotiation combinations for a line between two 10/100/1000 Base-T Ethernet interfaces.

Port 0

- auto-negotiation enabled* speed 1000 or auto
- auto-negotiation enabled speed 100
- auto-negotiation disabled speed 100
- auto-negotiation disabled speed 100
- auto-negotiation enabled* speed 1000 or auto

Port 1

- auto-negotiation enabled* speed 1000 or auto
- auto-negotiation enabled speed 100
- auto-negotiation disabled speed 100
- auto-negotiation enabled speed 100
- auto-negotiation disabled speed 100

Link Status Between Port 1 and Port 2

- Up at 1000 Mb/s
- Up at 100 Mb/s

- Up at 100 Mb/s
- Down
- Down

* You cannot disable auto-negotiation when the speed is set to 1000 or auto.

Related Commands [speed \(for 1000/10000 interfaces\)](#) — sets the link speed to 1000, 10000, or auto-negotiate the speed.

remote-fault-signaling rx

Brings the interface up or down when a Remote Fault Indication (RFI) error is detected.

Syntax `remote-fault-signaling rx {on | off}`

Parameters

on	Brings the interface up when an RFI error is detected.
off	Brings the interface down when an RFI error is detected.

Defaults ON.

Command Modes INTERFACE CONFIGURATION

Command History

Version 9.7(0.0)	Introduced on the M I/O Aggregator.
-------------------------	-------------------------------------

Usage Information By default, the M I/O Aggregator processes RFI errors transmitted by remote peers and brings down the interface when an RFI error is detected.

Example

```
Dell(conf-if-te-1/3)#remote-fault-signaling rx ?
on Enable
off Disable
```

show config (INTERFACE mode)

Displays the interface configuration.

Syntax `show config`

Command Modes INTERFACE

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell(conf-if)#show conf
!
interface TenGigabitEthernet 1/7
no ip address
switchport
```



```
no shutdown
Dell(conf-if)#
```

show config (from INTERFACE RANGE mode)

Display the bulk configured interfaces (group).

Syntax `show config`

Command Modes CONFIGURATION INTERFACE (conf-if-range)

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell(conf)#interface range tengigabitethernet 1/1 - 2
Dell(conf-if-range-tengig-1/1-2)#show config
!
interface TenGigabitEthernet 1/1
  no ip address
  switchport
  no shutdown
!
interface TenGigabitEthernet 1/2
  no ip address
  switchport
  no shutdown
Dell(conf-if-range-tengig-1/1-2)#
```

show config (from INTERFACE VLAN mode)

Displays the current configuration of the Default VLAN.

Syntax `show config`

Command Modes INTERFACE VLAN

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell(conf-if-vl-1)#show config
!
interface Vlan 1
  description a
  no ip address
  mtu 2500
```



```
shutdown
Dell(conf-if-vl-1) #
```

show config (from PROTOCOL LLDP mode)

Displays the LLDP configuration.

Syntax `show config`

Command Modes PROTOCOL LLDP

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell(conf-lldp)#show conf
!
protocol lldp
Dell(conf-lldp) #
```

show interfaces

Displays information on a specific physical interface or virtual interface.

Syntax `show interfaces interface`

Parameters

<i>interface</i>	Enter one of the following keywords and slot/port or number information:
	- For the management interface on the stack-unit, enter the keyword <code>managementethernet</code> followed by slot/port information. The slot and port range is 0. - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. - For a VLAN interface, enter the keyword <code>vlan</code> followed by a number from 1 to 4094. - For a Port Channel interface, enter the keyword <code>port-channel</code> followed by a number. The range is from 1 to 128.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.6(0.0)	Added support for Auto-LAG on the M I/O Aggregator.



Version	Description
8.3.17.0	Supported on the M I/O Aggregator

Usage Information

Use this `show interfaces` command for details on a specific interface. Use the `show interfaces stack-unit` command for details on all interfaces on the designated stack unit.

On the M I/O Aggregator, the show interface output displays incorrect rate information details over time for link monitoring when the rate-interval is configured for 5 seconds. Dell Networking recommends using higher rate-intervals such as 15 to 299 seconds to minimize the errors seen.

 **NOTE: In the CLI output, the power value will be rounded to a 3-digit value. For receive/transmit power that is less than 0.000, an snmp query will return the corresponding dbm value even though the CLI displays as 0.000.**

 **NOTE: After the counters are cleared, the line-rate continues to increase until it reaches the maximum line rate. When the maximum line rate is reached, there will be no change in the line-rate.**

User Information

The following describes the `show interfaces` command shown in the 10G example below.

Line	Description
TenGigabitEthernet 2/0...	Displays the interface's type, slot/port, and administrative and line protocol status.
Hardware is...	Displays the interface's hardware information and its assigned MAC address.
Interface index...	Displays the interface index number used by SNMP to identify the interface.
Internet address...	States whether an IP address is assigned to the interface. If an IP address is assigned, that address is displayed.
MTU 1554...	Displays link and IP MTU information. If the chassis is in Jumbo mode, this number can range from 576 to 12000.
LineSpeed	Displays the interface's line speed.
ARP type:...	Displays the ARP type and the ARP timeout value for the interface.
Last clearing...	Displays the time when the <code>show interfaces</code> counters were cleared.
Queuing strategy...	States the packet queuing strategy. FIFO means first in first out.
Input Statistics:	Displays all the input statistics including: • Number of packets and bytes into the interface • Number of packets with IP headers and VLAN tagged headers.  NOTE: The sum of the number of packets may not be as expected since a VLAN tagged IP packet counts as both a VLAN packet and an IP packet. • Packet size and the number of those packets inbound to the interface • Number of symbol errors, runts, giants, and throttles packets: – symbol errors = number packets containing bad data. That is, the port MAC detected a physical coding error in the packet. – runts = number of packets that are less than 64B – giants = packets that are greater than the MTU size – throttles = packets containing PAUSE frames • Number of CRC, IP Checksum, overrun, and discarded packets:

Line	Description
	– CRC = packets with CRC/FCS errors – IP Checksum = packets with IP Checksum errors – overrun = number of packets discarded due to FIFO overrun conditions – discarded = the sum of runts, giants, CRC, IP Checksum, and overrun packets discarded without any processing
Output Statistics:	Displays output statistics sent out of the interface including: • Number of packets, bytes, and underruns out of the interface – packets = total number of packets – bytes = total number of bytes – underruns = number of packets with FIFO underrun conditions • Number of Multicast, Broadcast, and Unicast packets: – Multicasts = number of MAC multicast packets – Broadcasts = number of MAC broadcast packets – Unicasts = number of MAC unicast packets • Number of throttles and discards packets:: – throttles = packets containing PAUSE frames – discarded = number of packets discarded without any processing
Rate information...	Estimate of the input and output traffic rate over a designated interval (30 to 299 seconds). Traffic rate is displayed in bits, packets per second, and percent of line rate.
Time since...	Elapsed time since the last interface status change (hh:mm:ss format).

Usage Information The interface counter “over 1023-byte pkts” does not increment for packets in the range $9216 > x < 1023$.

The Management port is enabled by default (no shutdown). If necessary, use the `ip address` command to assign an IP address to the Management port.

Example 10G Port

```

Dell-IOA-A1(conf-if-te-0/1)#do show int te 0/1
TenGigabitEthernet 0/1 is up, line protocol is down(error-disabled[UFD])
Hardware is DellEth, address is f8:b1:56:07:1d:8e
    Current address is f8:b1:56:07:1d:8e
Server Port AdminState is Up
Pluggable media not present
Interface index is 15274753
Internet address is not set
Mode of IPv4 Address Assignment : NONE
DHCP Client-ID :f8b156071d8e
MTU 12000 bytes, IP MTU 11982 bytes
LineSpeed auto
Auto-lag is disabled
Flowcontrol rx on tx off
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 00:12:53
Queueing strategy: fifo
Input Statistics:
    0 packets, 0 bytes
    0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
    0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
    0 Multicasts, 0 Broadcasts
    0 runts, 0 giants, 0 throttles
    0 CRC, 0 overrun, 0 discarded

```



```

Output Statistics:
  0 packets, 0 bytes, 0 underruns
  0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
  0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
  0 Multicasts, 0 Broadcasts, 0 Unicasts
  0 throttles, 0 discarded, 0 collisions, 0 wredrops
Rate info (interval 299 seconds):
  Input 00.00 Mbits/sec,          0 packets/sec, 0.00% of line-rate
  Output 00.00 Mbits/sec,         0 packets/sec, 0.00% of line-rate
Time since last interface status change: 00:11:36

```

Example

(ManagementEthernet)

```

Dell#show interface managementethernet ?
O/O Management Ethernet interface number
Dell#show interface managementethernet 0/0
ManagementEthernet 0/0 is up, line protocol is up
Hardware is DellForce10Eth, address is 00:1e:c9:f1:00:05
Current address is 00:1e:c9:f1:00:05
Pluggable media not present
Interface index is 235159752
Internet address is 10.11.209.87/16
Mode of IP Address Assignment : MANUAL
DHCP Client-ID: mgmt001ec9f10005
Virtual-IP is not set
Virtual-IP IPv6 address is not set
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 100 Mbit, Mode full duplex
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 5d4h57m
Queueing strategy: fifo
Input 3448753 packets, 950008323 bytes, 3442163 multicast
Received 0 errors, 0 discarded
Output 4627 packets, 814226 bytes, 0 multicast
Output 0 errors, 0 invalid protocol

```

Related Commands

[show interfaces configured](#)—Displays any interface with a non-default configuration.

[show interfaces port-channel](#)— Displays information on all interfaces on a specific stack unit.

[show interfaces switchport](#)— Displays Layer 2 information about the interfaces.

[show inventory](#)— Displays the M I/O Aggregator type, components (including media), Dell Networking OS version including hardware identification numbers and configured protocols.

[show ip interface](#)— Displays Layer 3 information about the interfaces.

[show memory](#)— Displays the stack unit(s) status.

[show interfaces status](#)— Displays all interfaces configured using the interface range command.

show interfaces configured

Displays any interface with a non-default configuration.

Syntax `show interfaces configured`

Command Modes

- EXEC
- EXEC Privilege



Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

(ManagementEthernet)

```
Dell#show interfaces configured
TenGigabitEthernet 1/1 is up, line protocol is down(error-disabled[UFD])
Hardware is DellForce10Eth, address is 00:01:e8:00:ab:01
Current address is 00:01:e8:00:ab:01
Server Port AdminState is Down
Pluggable media not present
Interface index is 67703553
Internet address is not set
Mode of IP Address Assignment : NONE
DHCP Client-ID :tenG2580001e800ab01
MTU 12000 bytes, IP MTU 11982 bytes
LineSpeed auto
Flowcontrol rx off tx off
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 05:15:07
Queueing strategy: fifo
Input Statistics:
 0 packets, 0 bytes
 0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
 0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
 0 Multicasts, 0 Broadcasts
 0 runts, 0 giants, 0 throttles
 0 CRC, 0 overrun, 0 discarded
Output Statistics:
 0 packets, 0 bytes, 0 underruns
 0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
 0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
 0 Multicasts, 0 Broadcasts, 0 Unicasts
 0 throttles, 0 discarded, 0 collisions, 0 wredrops
Rate info (interval 299 seconds):
Input 00.00 Mbits/sec, 0 packets/sec, 0.00% of line-rate
Output 00.00 Mbits/sec, 0 packets/sec, 0.00% of line-rate
Time since last interface status change: 05:14:12
TenGigabitEthernet 1/2 is up, line protocol is down(error-disabled[UFD])
Dell#
```

show interfaces description

Display the descriptions configured on the interface.

Syntax `show interfaces [interface] description`

Parameters

interface

Enter one of the following keywords and slot/port or number information:

- For the management interface on the stack unit enter the keyword `ManagementEthernet` followed by the slot/port information. The slot range is 0-0 and the port range is 0.
- For a 10-Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` followed by the slot/port information.



- For VLAN interfaces, enter the keyword `vlan` followed by a number from 1 to 4094.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes

All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

The following describes the `show interfaces description` command shown in the Example below.

Field	Description
Interface	Displays the type of interface and associated slot and port number.
OK?	Indicates if the hardware is functioning properly.
Status	States whether the interface is enabled (up) or disabled (administratively down).
Protocol	States whether IP is enabled (up) or disabled (down) on the interface.
Description	Displays the description (if any) manually configured for the interface.

Example

```
Dell#show interface description
Interface          OK  Status      Protocol  Description
TenGigabitEthernet 0/1 NO  admin down  down
TenGigabitEthernet 0/2 NO  admin up    down
TenGigabitEthernet 0/3 NO  admin up    down
TenGigabitEthernet 0/4 NO  admin up    down
TenGigabitEthernet 0/5 NO  admin up    down
TenGigabitEthernet 0/6 NO  admin up    down
TenGigabitEthernet 0/7 NO  up down
TenGigabitEthernet 0/8 YES  up up
```

show interfaces port-channel

Display information on configured Port Channel groups.

Syntax

```
show interfaces port-channel [channel-number] [brief| description]
```

Parameters

<i>channel-number</i>	For a Port Channel interface, enter the keyword <code>port-channel</code> followed by a number. The range is from 1 to 128.
<i>brief</i>	(OPTIONAL) Enter the keyword <code>brief</code> to display only the port channel number, the state of the port channel, and the number of interfaces in the port channel.
<i>description</i>	(OPTIONAL) Enter the keyword <code>description</code> to display interface information with description.

Command Modes

- EXEC



- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.7(0.0)	Introduced on the M I/O Aggregator.
9.4(0.0)	Supported on the FN I/O Aggregator.

Usage Information The following describes the `show interfaces port-channel` command shown in the following example.

Field	Description
Port-Channel 1...	Displays the status of LAG. In the Example, the status of the LAG, LAG fate-sharing group ("Failover-group") is listed.
Hardware is...	Displays the interface's hardware information and its assigned MAC address.
Port-channel is part...	Indicates whether the LAG is part of a LAG fate-sharing group ("Failover-group").
Internet address...	States whether an IP address is assigned to the interface. If an IP address is assigned, that address is displayed.
MTU 1554...	Displays link and IP MTU.
LineSpeed	Displays the interface's line speed. For a port channel interface, it is the line speed of the interfaces in the port channel.
Members in this...	Displays the interfaces belonging to this port channel.
ARP type:...	Displays the ARP type and the ARP timeout value for the interface.
Last clearing...	Displays the time when the <code>show interfaces</code> counters were cleared.
Queueing strategy.	States the packet queuing strategy. FIFO means first in first out.
packets input...	Displays the number of packets and bytes into the interface.
Input 0 IP packets...	Displays the number of packets with IP headers, VLAN tagged headers, and MPLS headers. The number of packets may not add correctly because a VLAN tagged IP packet counts as both a VLAN packet and an IP packet.
0 64-byte...	Displays the size of packets and the number of those packets entering that interface. This information is displayed over two lines.
Received 0...	Displays the type and number of errors or other specific packets received. This information is displayed over three lines.
Output 0...	Displays the type and number of packets sent out the interface. This information is displayed over three lines.
Rate information...	Displays the traffic rate information into and out of the interface. Traffic rate is displayed in bits and packets per second.
Time since...	Displays the time since the last change in the configuration of this interface.

**Example
(EtherScale)**

```
Dell#show interfaces port-channel
Port-channel 1 is down, line protocol is down
Hardware address is 00:1e:c9:f1:00:05, Current address is 00:1e:c9:f1:00:05
Interface index is 1107755009
Minimum number of links to bring Port-channel up is 1
Internet address is not set
```



```

Mode of IP Address Assignment : NONE
DHCP Client-ID :lag1001ec9f10005
MTU 12000 bytes, IP MTU 1500 bytes
LineSpeed auto
Members in this channel:
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 03:28:00
Queueing strategy: fifo
Input Statistics:
0 packets, 0 bytes
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 0 Broadcasts
0 runs, 0 giants, 0 throttles
0 CRC, 0 overrun, 0 discarded
Output Statistics:
0 packets, 0 bytes, 0 underruns
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 0 Broadcasts, 0 Unicasts
0 throttles, 0 discarded, 0 collisions

```

User Information

The following describes the `show interfaces port-channel brief` command shown in the following example.

Field	Description
LAG	Lists the port channel number.
Mode	Lists the mode: · L3 — for Layer 3 · L2 — for Layer 2
Status	Displays the status of the port channel. · down — if the port channel is disabled (shutdown) · up — if the port channel is enabled (no shutdown)
Uptime	Displays the age of the port channel in hours:minutes:seconds.
Ports	Lists the interfaces assigned to this port channel.
(untitled)	Displays the status of the physical interfaces (up or down). · In Layer 2 port channels, an * (asterisk) indicates which interface is the primary port of the port channel. The primary port sends out interface PDU. · In Layer 3 port channels, the primary port is not indicated.

Example

```

Dell#show int po bri
Codes: L - LACP Port-channel
       O - OpenFlow Controller Port-channel
       A - Auto Port-channel
       I - Internally Lagged
LAG Mode Status Uptime Ports
L   128 L3 down 00:00:00
Dell#

```

To indicate the LACP fallback, Internally lagged is added to the list. When the LAG auto-configures itself, the LAG status describes as 'I'.



Related Commands [show lacp](#) — displays the LACP matrix.

show interfaces stack-unit

Display information on all interfaces on a specific Aggregator stack member.

Syntax `show interfaces stack-unit unit-number`

Parameters

<i>unit-number</i>	Enter the stack member number (0 to 5).
--------------------	---

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show interfaces stack-unit 0
TenGigabitEthernet 0/1 is down, line protocol is down
Hardware is DellForce10Eth, address is 00:1e:c9:f1:00:05
Current address is 00:1e:c9:f1:00:05
Server Port AdminState is Down
Pluggable media not present
Interface index is 34148609
Internet address is not set
Mode of IP Address Assignment : NONE
DHCP Client-ID :tenG130001ec9f10005
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed auto
Flowcontrol rx off tx off
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 5d5h24m
Queueing strategy: fifo
Input Statistics:
0 packets, 0 bytes
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 0 Broadcasts
0 runs, 0 giants, 0 throttles
0 CRC, 0 overrun, 0 discarded
Output Statistics:
0 packets, 0 bytes, 0 underruns
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 0 Broadcasts, 0 Unicasts
0 throttles, 0 discarded, 0 collisions
Rate info (interval 299 seconds):
Input 00.00 Mbits/sec, 0 packets/sec, 0.00% of line-rate
Output 00.00 Mbits/sec, 0 packets/sec, 0.00% of line-rate
Time since last interface status change: 5d5h23m
!-----output truncated -----!
```



Related Commands [show diag](#) — Displays data plane and management plane input/output statistics.

show interfaces status

Displays a summary of interface information or specify a stack unit and interface to display status information for that specific interface only.

Syntax `show interfaces [interface | stack-unit unit-number] status`

Parameters

<i>interface</i>	(OPTIONAL) Enter one of the following keywords and slot/port or number information: For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information.
<i>linecard slot-number</i>	(OPTIONAL) Enter the keyword <code>linecard</code> then the slot number.

Defaults none

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show interface status
Port      Description      Status    Speed    Duplex    Vlan
Te 0/1      Down             Down      Auto     Auto      --
Te 0/2      Down             Down      Auto     Auto      --
Te 0/3      Down             Down      Auto     Auto      --
Te 0/4      Down             Down      Auto     Auto      --
Te 0/5      Down             Down      Auto     Auto      --
Te 0/6      Down             Down      Auto     Auto      --
Te 0/7      Down             Down      Auto     Auto      --
Te 0/8      Up 1             Up 1      0000 Mbit Full  --
Te 0/9      Down             Down      Auto     Auto      --
Te 0/10     Down             Down      Auto     Auto      --
Te 0/11     Down             Down      Auto     Auto      --
Te 0/12     Down             Down      Auto     Auto      --
Te 0/13     Down             Down      Auto     Auto      --
Te 0/14     Down             Down      Auto     Auto      --
Te 0/15     Down             Down      Auto     Auto      --
Te 0/16     Up               Up        10000 Mbit Full  --
```



show interfaces switchport

Display only virtual and physical interfaces in Layer 2 mode. This command displays the Layer 2 mode interfaces' IEEE 802.1Q tag status and VLAN membership.

Syntax `show interfaces switchport [interface | stack-unit unit-id ]`

Parameters

interface	(OPTIONAL) Enter one of the following keywords and slot/port or number information: - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information. - Enter the keyword <code>backup</code> to view the backup interface for this interface.
stack-unit unit-id	(OPTIONAL) Enter the keywords <code>stack-unit</code> followed by the stack member number. The range is from 0 to 5.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following describes the `show interfaces switchport` command for the following example.

Items	Description
Name	Displays the interface's type, slot, and port number.
802.1QTagged	Displays whether if the VLAN tagged ("True"), untagged ("False"), or hybrid ("Hybrid"), which supports both untagged and tagged VLANs by port 13/0.
Vlan membership	Lists the VLANs to which the interface is a member. Starting with Dell Networking OS version 7.6.1, this field can display native VLAN membership by port 13/0.

Example

```
Dell#show interfaces switchport
Codes: U - Untagged, T - Tagged
x - Dot1x untagged, X - Dot1x tagged
G - GVRP tagged, M - Trunk, H - VSN tagged
i - Internal untagged, I - Internal tagged, v - VLT untagged, V - VLT
tagged
Name: TenGigabitEthernet 1/1
802.1QTagged: Hybrid
IO-AGG port mode: Auto VLANs enabled
Vlan membership:
Q Vlans
U 1
T 2-4094
Native VlanId: 1.
Name: TenGigabitEthernet 1/2
802.1QTagged: Hybrid
IO-AGG port mode: Auto VLANs enabled
Vlan membership:
Q Vlans
U 1
```



```
T 2-4094
Native VlanId: 1.
--More--
```

Related Commands [show ip interface](#) — displays Layer 3 information about the interfaces.

show tdr

Displays the TDR test results.

Syntax `show tdr interface`

Parameters *interface* Enter the keyword `TenGigabitEthernet` followed by the slot/port information for the 100/1000/10 GbaseT Ethernet interface.

Defaults none

Command Modes EXEC

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information If the TDR test has not been run, an error message is generated:
`%Error: Please run the TDR test first`

The following describes the TDR test status.

Status	Definition
<i>OK Status:</i> <i>Terminated</i>	TDR test is complete, no fault is detected on the cable, and the test is terminated.
<i>Length: 92 (+/- 1) meters, Status:</i> <i>Shorted</i>	A short is detected on the cable. The location, in this Example is 92 meters. The short is accurate to plus or minus one meter.
<i>Length: 93 (+/- 1) meters, Status:</i> <i>Open</i>	An opening is detected on the cable. The location, in this Example is 93 meters. The open is accurate to plus or minus one meter.
<i>Status: Impedance Mismatch</i>	There is an impedance mismatch in the cables.

Example

```
Dell#show tdr tengigabitethernet 1/1
Time since last test: 00:00:02
Pair A, Length: OK Status: Terminated
Pair B, Length: 92 (+/- 1) meters, Status: Short
Pair C, Length: 93 (+/- 1) meters, Status: Open
Pair D, Length: 0 (+/- 1) meters, Status: Impedance Mismatch
```

Related Commands [tdr-cable-test](#) — Runs the TDR test.



show vlan

Displays the current VLAN configurations on the switch.

Syntax `show vlan [brief |id vlan-id | name vlan-name]`

Parameters

brief	(OPTIONAL) Enter the keyword <code>brief</code> to display the following information: • VLAN ID • VLAN name (left blank if none is configured.) • Spanning Tree Group ID • MAC address aging time • IP address
id <i>vlan-id</i>	(OPTIONAL) Enter the keyword <code>id</code> followed by a number from 1 to 4094. Only information on the VLAN specified is displayed
name <i>vlan-name</i>	(OPTIONAL) Enter the keyword <code>name</code> followed by the name configured for the VLAN. Only information on the VLAN named is displayed.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following describes the `show vlan` command information given in the following example

Column Heading	Description
(Column 1 — no heading)	• asterisk symbol (*) = Default VLAN • G = GVRP VLAN • P = primary VLAN • C = community VLAN • I = isolated VLAN
NUM	Displays existing VLAN IDs.
Status	Displays the word Inactive for inactive VLANs and the word Active for active VLANs.
Q	Displays G for GVRP tagged, M for member of a VLAN-Stack VLAN, T for tagged interface, U (for untagged interface), x (uncapitalized x) for Dot1x untagged, or X (capitalized X) for Dot1x tagged.
Ports	Displays the type, slot, and port information. For the type, Po = port channel, Fo= fortygigabit ethernet, and Te = ten gigabit ethernet.



Example

```

Dell# show vlan id 40
Codes: * - Default VLAN, G - GVRP VLANs, R - Remote Port Mirroring
VLANs, P - Primary, C - Community, I - Isolated
Q: U - Untagged, T - Tagged
x - Dot1x untagged, X - Dot1x tagged
G - GVRP tagged, M - Vlan-stack, H - VSN tagged
i - Internal untagged, I - Internal tagged, v - VLT untagged, V
- VLT tagged
NUM Status Description Q Ports
1 Inactive a
Dell#

```

Example (Brief)

```

Dell#show vlan brief
VLAN Name                               STG MAC Aging      IP Address
-----
1                               0      0      unassigned
2                               0      0      unassigned
20                              0      0      unassigned
1002                           0      0      unassigned
Dell#

```

Example (Using a VLAN Name)

```

Dellconf)#interface vlan 222
Dell(conf-if-vl-222)#name test
Dell(conf-if-vl-222)#do show vlan name test
Codes: * - Default VLAN, G - GVRP VLANs
Q: U - Untagged, T - Tagged
x - Dot1x untagged, X - Dot1x tagged
G - GVRP tagged, M - Vlan-stack
NUM Status Description Q Ports
222 Inactive U TenGig 1/22
Dell(conf-if-vl-222)#
Dell#

```

Related Commands [interface vlan](#) — Configures a VLAN.

shutdown

Disable an interface.

Syntax shutdown

To activate an interface, use the `no shutdown` command.

Defaults The interface is disabled.

Command Modes INTERFACE

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The `shutdown` command marks a physical interface as unavailable for traffic. To discover if an interface is disabled, use the `show ip interface` command. Disabled interfaces are listed as down.



Disabling a VLAN or a port channel causes different behavior. When a VLAN is disabled, the Layer 3 functions within that VLAN are disabled. Layer 2 traffic continues to flow. Entering the `shutdown` command on a port channel disables all traffic on the port channel and the individual interfaces within the port channel. To enable a port channel, you must enter `no shutdown` on the port channel interface and at least one interface within that port channel.

The `shutdown` and `description` commands are the only commands that you can configure on an interface that is a member of a port channel.

Related Commands

- [vlan tagged](#) — Test the condition of copper cables on 100/1000/10G Base-T modules.
- [interface vlan](#) — Creates a VLAN.
- [show ip interface](#) — Displays the interface routing status. Add the keyword `brief` to display a table of interfaces and their status.

source (port monitoring for 40-Gigabit Ethernet)

Configure a port monitor source and destination. Starting with Dell Networking OS Release 9.3(0.0), you can also configure a 40-Gigabit Ethernet interface as the destination interface or port to which the monitored traffic is sent .

Syntax

```
source interface destination interface direction {rx | tx | both}
```

To disable a monitor source, use the `no source interface destination interface direction {rx | tx | both}` command.

Parameters

interface	Enter the one of the following keywords and slot/port information: • For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. • For a 40-Gigabit Ethernet interface, enter the keyword <code>fortyGigE</code> then the slot/port information.
destination	Enter the keyword <code>destination</code> to indicate the interface destination.
direction {rx tx both}	Enter the keyword <code>direction</code> then one of the packet directional indicators. • <code>rx</code>: to monitor receiving packets only. • <code>tx</code>: to monitor transmitting packets only. • <code>both</code>: to monitor both transmitting and receiving packets.

Defaults none

Command Modes MONITOR SESSION (`conf-mon-sess-session-ID`)

Supported Modes All Modes

Command History	<table border="0"> <tr> <th>Version</th> <th>Description</th> </tr> <tr> <td>9.3(0.0)</td> <td>Added support for the <code>fortyGigE</code> keyword on M I/O Aggregator.</td> </tr> <tr> <td>8.3.17.0</td> <td>Supported on M I/O Aggregator.</td> </tr> </table>	Version	Description	9.3(0.0)	Added support for the <code>fortyGigE</code> keyword on M I/O Aggregator.	8.3.17.0	Supported on M I/O Aggregator.
Version	Description						
9.3(0.0)	Added support for the <code>fortyGigE</code> keyword on M I/O Aggregator.						
8.3.17.0	Supported on M I/O Aggregator.						



Example

```
Dell(conf-mon-sess-1)# source tengigabitethernet 0/1 destination
tengigabitethernet 0/45 direction rx
Dell(conf-mon-sess-1)#
Dell(conf-mon-sess-1)#do show monitor session
  SessID  Source          Destination          Dir  Mode  Source IP
Dest IP
-----  -
1      Te 0/1              Te 0/45              rx   Port   N/A
N/A
Dell(conf-mon-sess-1)#
```

speed (for 1000/10000 interfaces)

Set the speed for 1000/10000 Base-T Ethernet interfaces. Both sides of a link must be set to the same speed (1000/10000) or to auto or the link may not come up.

Syntax

```
speed {1000 | 10000 | auto}
```

To return to the default setting, use the `no speed {1000 | 10000 | auto}` command.

Parameters

1000	Enter the keyword <code>1000</code> to set the interface's speed to 1000 Mb/s.
10000	Enter the keyword <code>10000</code> to set the interface's speed to 10000 Mb/s. Auto-negotiation is enabled. For more information, refer to name
auto	Enter the keyword <code>auto</code> to set the interface to auto-negotiate its speed. Auto-negotiation is enabled. For more information, refer to name .

Defaults

auto

Command Modes

INTERFACE

Supported Modes

All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

This command is found on the 1000/10000 Base-T Ethernet interfaces.

When you enable `auto`, the system performs an automatic discovery to determine the optics installed and configure the appropriate speed.

When you configure a speed for the 1000/10000 interface, confirm the `negotiation auto` command setting. Both sides of the link must have auto-negotiation either enabled or disabled. For speed settings of 1000 or auto, the software sets the link to auto-negotiation and you cannot change that setting.

Related Commands

[negotiation auto](#) — enables or disables auto-negotiation on an interface.



stack-unit portmode

Split a single 40G port into 4x10G ports on the MXL switch.

Syntax `stack-unit stack-unit port number portmode quad`

Parameters

<i>stack-unit</i>	Enter the stack member unit identifier of the stack member to reset. The range is 0 to 5.
-------------------	---



NOTE: The MXL switch commands accept Unit ID numbers from 0 to 5, though the MXL switch supports stacking up to three units only with the Dell Networking OS version 8.3.71.

<i>number</i>	Enter the port number of the 40G port to be split. Enter one of the following port numbers for the MXL switch: 48, 52, 56, or 60.
---------------	---

Defaults Disabled.

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information Splitting a 40G port into 4x10G port is supported on standalone and stacked units.

- You cannot use split ports as stack-link to stack an MXL Switch.
- The split ports MXL switch unit cannot be a part of any stacked system.
- The unit number with the split ports must be the default (stack-unit 0).
- This set up can be verified using `show system brief` command. If the unit ID is different than 0, it must be renumbered to 0 before ports are split by using the `stackunit id renumber 0` command in EXEC mode.

The quad port must be in a default configuration before it can be split into 4x10G ports. The 40G port is lost in the config when the port is split, so be sure that the port is also removed from other L2/L3 feature configurations.

The system must be reloaded after issuing the CLI for the change to take effect.

tdr-cable-test

Test the condition of copper cables on 100/1000/10GBase-T modules.

Syntax `tdr-cable-test interface`

Parameters

<i>interface</i>	Enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information for the 100/1000/10GBase-T Ethernet interface.
------------------	--

Defaults none



Command Modes	EXEC						
Supported Modes	All Modes						
Command History	<table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr> <tr> <td>8.3.17.0</td><td>Supported on the M I/O Aggregator.</td></tr> </table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	8.3.17.0	Supported on the M I/O Aggregator.
Version	Description						
9.4(0.0)	Supported on the FN I/O Aggregator.						
8.3.17.0	Supported on the M I/O Aggregator.						
Usage Information	The interface must be enabled to run the test or an error message is generated: <pre>Dell#tdr-cable-test tengigabitethernet 5/2</pre> <pre>%Error: Interface is disabled TenGIG 5/2</pre>						
Related Commands	show tdr — Displays the results of the TDR test.						

vlan tagged (CMC)

Add a Layer 2 interface to a VLAN as a tagged interface.

Syntax	<pre>vlan tagged [vlan-id]</pre> To remove a tagged interface from a VLAN, use the <code>no vlan tagged vlan-id</code> command.
--------	--

Parameters	<table> <tr> <td><i>vlan-id</i></td><td>Enter the VLAN ID. The range is from 1 to 4094.</td></tr> </table>	<i>vlan-id</i>	Enter the VLAN ID. The range is from 1 to 4094.
<i>vlan-id</i>	Enter the VLAN ID. The range is from 1 to 4094.		

Defaults	All interfaces in Layer 2 mode are untagged.
----------	---

Command Modes	INTERFACE
---------------	-----------

Supported Modes	All Modes
-----------------	-----------

Command History	<table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr> <tr> <td>8.3.17.0</td><td>Supported on the M I/O Aggregator.</td></tr> </table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	8.3.17.0	Supported on the M I/O Aggregator.
Version	Description						
9.4(0.0)	Supported on the FN I/O Aggregator.						
8.3.17.0	Supported on the M I/O Aggregator.						

Usage Information	If the interface belongs to several VLANs, you must remove it from all VLANs to change it to an untagged interface. Tagged interfaces can belong to multiple VLANs, while untagged interfaces can only belong to one VLAN at a time. When two or more ports configured for VLANs form a LAG, the resulting LAG is a tagged member of all the configured VLANs and an untagged member of the VLAN to which the port with the lowest port ID belongs. For example, if port 0/1-32 is an untagged member of VLAN 2 and port 0/41 is an untagged member of VLAN 3, the resulting LAG consisting of the two ports is an untagged member of VLAN 2 and a tagged member of VLAN3.
-------------------	--

Example	<pre>Dell(conf-if-te-0/2)#vlan tagged ?</pre> VLAN-RANGE Comma/Hyphen separated VLAN ID set
---------	---



```

Dell(conf-if-te-0/2)#vlan tagged 2,3-4
Dell(conf-if-te-0/2)#show config
!
interface TenGigabitEthernet 0/2
mtu 12000
vlan tagged 2-4
!
port-channel-protocol LACP
port-channel 1 mode active
!
protocol lldp
advertise management-tlv system-name
dcbx port-role auto-downstream
no shutdown
Dell(conf-if-te-0/2)#

```

Related Commands [interface vlan](#) — Configures a VLAN.

[vlan untagged](#) — Specifies which interfaces in a VLAN are untagged.

vlan untagged (CMC)

Add a Layer 2 interface to a VLAN as an untagged interface.

Syntax `vlan untagged [vlan-id]`
 To remove a untagged interface from a VLAN, use the `no vlan untagged [vlan-id]` command.

Parameters

<i>vlan-id</i>	Enter the VLAN ID. The range is from 1 to 4094.
----------------	---

Defaults All interfaces in Layer 2 mode are untagged.

Command Modes INTERFACE

Supported Modes All Modes

Command History	
Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Untagged interfaces can only belong to one VLAN.

In the default VLAN, you cannot use the `no untagged interface` command. To remove an untagged interface from all VLANs, including the default VLAN, enter INTERFACE mode and use the `no vlan tagged` command.

Tagged interfaces can belong to multiple VLANs, while untagged interfaces can only belong to one VLAN at a time.

When two or more ports configured for VLANs form a LAG, the resulting LAG is a tagged member of all the configured VLANs and an untagged member of the VLAN to which the port with the lowest port ID belongs.



For example, if port 0/33 is an untagged member of VLAN 2 and port 0/41 is an untagged member of VLAN 3, the resulting LAG consisting of the two ports is an untagged member of VLAN 2 and a tagged member of VLANs 2 and 3.

Example

```
Dell(conf-if-te-0/2)#vlan untagged ?
<1-4094> Untagged VLAN id
Dell(conf-if-te-0/2)#
Dell(conf-if-te-0/2)#vlan untagged 4094
Dell(conf-if-te-0/2)#show config
!
interface TenGigabitEthernet 0/2
mtu 12000
vlan untagged 4094
!
port-channel-protocol LACP
port-channel 1 mode active
!
protocol lldp
advertise management-tlv system-name
dcbx port-role auto-downstream
no shutdown
Dell(conf-if-te-0/2)#
```

Related Commands [interface vlan](#) — Configures a VLAN.

[vlan tagged](#) — Specifies which interfaces in a VLAN are tagged.



IPv4 Routing

The aggregator supports both IPv4 and IPv6 routing and these are used only for the management purpose. This chapter describes the IPv4 related commands. They are:

- [clear tcp statistics](#)
- [debug ip dhcp](#)
- [debug ip icmp](#)
- [ip route](#)
- [management route](#)
- [show arp](#)
- [show ip management-route](#)
- [show ip multicast-cam stack-unit](#)
- [show ip interface](#)
- [show ip route](#)
- [show tcp statistics](#)

clear tcp statistics

Clear the TCP counters.

Syntax	<code>clear tcp statistics</code>	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

debug ip dhcp

Enable debug information for DHCP relay transactions and display the information on the console.

Syntax	<code>debug ip dhcp</code>	
Parameters	<i>debug ip dhcp</i>	To disable debug, use the no debug ip dhcp command.
Defaults	Debug disabled	



Command Mode EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
94(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
FTOS#debug ip dhcp
00:12:21 : %RELAY-I-PACKET: BOOTP REQUEST (Unicast) received at interface
113.3.3.17 BOOTP
Request, hops = 0, XID = 0xbf05140f, secs = 0, hwaddr = 00:60:CF:20:7B:8C,
giaddr = 0.0.0.0
00:12:21 : %RELAY-I-BOOTREQUEST: Forwarded BOOTREQUEST for 00:60:CF:20:7B:
8C to 14.4.4.2
00:12:26 : %RELAY-I-PACKET: BOOTP REQUEST (Unicast) received at interface
113.3.3.17 BOOTP
Request, hops = 0, XID = 0xbf05140f, secs = 5, hwaddr = 00:60:CF:20:7B:8C,
giaddr = 0.0.0.0
00:12:26 : %RELAY-I-BOOTREQUEST: Forwarded BOOTREQUEST for 00:60:CF:20:7B:
8C to 14.4.4.2
00:12:40 : %RELAY-I-PACKET: BOOTP REQUEST (Unicast) received at interface
113.3.3.17 BOOTP
Request, hops = 0, XID = 0xda4f9503, secs = 0, hwaddr = 00:60:CF:20:7B:8C,
giaddr = 0.0.0.0
00:12:40 : %RELAY-I-BOOTREQUEST: Forwarded BOOTREQUEST for 00:60:CF:20:7B:
8C to 14.4.4.2
00:12:42 : %RELAY-I-PACKET: BOOTP REPLY (Unicast) received at interface
14.4.4.1 BOOTP Reply,
hops = 0, XID = 0xda4f9503, secs = 0, hwaddr = 00:60:CF:20:7B:8C, giaddr =
113.3.3.17
00:12:42 : %RELAY-I-BOOTREPLY: Forwarded BOOTREPLY for 00:60:CF:20:7B:8C
to 113.3.3.254
00:12:42 : %RELAY-I-PACKET: BOOTP REQUEST (Unicast) received at interface
113.3.3.17 BOOTP
Request, hops = 0, XID = 0xda4f9503, secs = 0, hwaddr = 00:60:CF:20:7B:8C,
giaddr = 0.0.0.0
00:12:42 : %RELAY-I-BOOTREQUEST: Forwarded BOOTREQUEST for 00:60:CF:20:7B:
8C to 14.4.4.2
00:12:42 : %RELAY-I-PACKET: BOOTP REPLY (Unicast) received at interface
14.4.4.1 BOOTP Reply,
hops = 0, XID = 0xda4f9503, secs = 0, hwaddr = 00:60:CF:20:7B:8C, giaddr =
113.3.3.17
00:12:42 : %RELAY-I-BOOTREPLY: Forwarded BOOTREPLY for 00:60:CF:20:7B:8C
to 113.3.3.254
FTOS#
```

debug ip icmp

View information on the internal control message protocol (ICMP).

Syntax debug ip icmp [*interface*] [*count value*]
To disable debugging, use the no debug ip icmp command.

Parameters

interface (OPTIONAL) Enter the following keywords and slot/port or number information:

- For the management interface, enter the keyword ManagementEthernet then the slot/port information. The slot range is 0 and the port range is 0.

- For a 10 Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` then the slot/port information.
- For VLAN, enter the keyword `vlan` then by a number from 1 to 4094.

count value (OPTIONAL) Enter the keywords `count` then the count value. The ranges from 1 to 65534. The default is **Infinity**.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information To stop packets from flooding the user terminal when debugging is turned on, use the `count` option.

Example

```
ICMP: echo request rcvd from src 40.40.40.40
ICMP: src 40.40.40.40, dst 40.40.40.40, echo reply
ICMP: src 40.40.40.40, dst 40.40.40.40, echo reply
ICMP: echo request sent to dst 40.40.40.40
ICMP: echo request rcvd from src 40.40.40.40
ICMP: src 40.40.40.40, dst 40.40.40.40, echo reply
ICMP: src 40.40.40.40, dst 40.40.40.40, echo reply
ICMP: echo request sent to dst 40.40.40.40:
```

ip route

Assign a static route to the switch.

Syntax `ip route destination mask {ip-address | interface [ip-address]}[distance] [permanent] [tag tag-value]`

To delete a specific static route, use the `no ip route destination mask {address | interface [ip-address]}` command.

To delete all routes matching a certain route, use the `no ip route destination mask` command.

Parameters

destination	Enter the IP address in dotted decimal format of the destination device.
mask	Enter the mask in the slash prefix format (/x) of the destination device's IP address.
ip-address	Enter the IP address in dotted decimal format of the forwarding router.
interface	Enter the following keywords and slot/port or number information: • For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information. • For a VLAN, enter the keyword <code>vlan</code> followed by a number from 1 to 4094.



<i>distance</i>	(OPTIONAL) Enter a number as the distance metric assigned to the route. The range is from 1 to 255.
<i>permanent</i>	(OPTIONAL) Enter the keyword <i>permanent</i> to specify the route is not removed, even if the interface assigned to that route goes down. The route must be up initially to install it in the routing table. If you disable the interface with an IP address associated with the keyword <i>permanent</i> , the route disappears from the routing table.
<i>tag tag-value</i>	(OPTIONAL) Enter the keyword <i>tag</i> followed by a number to assign to the route. The range is from 1 to 4294967295.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Using the following example of a static route: `ip route 33.33.33.0 /24 tengigabitethernet 0/0 172.31.5.43`

- The software installs a next hop that is not on the directly connected subnet but which recursively resolves to a next hop on the interface's configured subnet. In the example, if `gig 0/0` has an ip address on subnet 2.2.2.0 and if 172.31.5.43 recursively resolves to 2.2.2.0, Dell Networking OS installs the static route.
- When the interface goes down, Dell Networking OS withdraws the route.
- When the interface comes up, Dell Networking OS re-installs the route.
- When recursive resolution is "broken," Dell Networking OS withdraws the route.
- When recursive resolution is satisfied, Dell Networking OS re-installs the route.

Related Commands [show ip route](#)— views the switch routing table.

management route

Configure a static route that points to the Management interface or a forwarding router.

Syntax `management route {ipv4-address}/mask{forwarding-router-address | managementethernet}`

Parameters

<i>{ipv4-address}/mask</i>	Enter an IPv4 address (A.B.C.D) followed by the prefix-length for the IP address of the management interface.
<i>forwarding-router-address</i>	Enter an IPv4 address of a forwarding router.
<i>managementethernet</i>	Enter the keyword <i>managementethernet</i> for the Management interface.

Defaults Not configured.

Command Modes CONFIGURATION



Supported Modes	All Modes	
Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	When a static route (or a protocol route) overlaps with Management static route, the static route (or a protocol route) is preferred over the Management Static route. Also, Management static routes and the Management Connected prefix are not reflected in the hardware routing tables. Separate routing tables are maintained for IPv4 management routes. This command manages both tables.	

show arp

Displays the ARP table.

Syntax `show arp [interface interface | ip ip-address [mask] | macaddress mac-address [mac-address mask]] [static | dynamic] [summary]`

Parameters	interface <i>interface</i>	(OPTIONAL) Enter the following keywords and slot/port or number information: - For the Management interface, enter the keyword <code>managementethernet</code> followed by the slot/port information. - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information. - For a VLAN, enter the keyword <code>vlan</code> followed by a number from 1 to 4094.
	ip <i>ip-address mask</i>	(OPTIONAL) Enter the keyword <code>ip</code> followed by an IP address in the dotted decimal format. Enter the optional IP address mask in the slash prefix format (<code>/ x</code>).
	macaddress <i>mac-address mask</i>	(OPTIONAL) Enter the keyword <code>macaddress</code> followed by a MAC address in <code>nn:nn:nn:nn:nn:nn</code> format. Enter the optional MAC address mask in <code>nn:nn:nn:nn:nn</code> format also.
	static	(OPTIONAL) Enter the keyword <code>static</code> to view entries entered manually.
	retries	(OPTIONAL) Enter the keyword <code>retries</code> to view the number of ARP retries before a 20-second back off.
	dynamic	(OPTIONAL) Enter the keyword <code>dynamic</code> to view dynamic entries.
	summary	(OPTIONAL) Enter the keyword <code>summary</code> to view a summary of ARP entries.
	inspection	(OPTIONAL) Enter the keyword <code>inspection</code> to view dynamic ARP Inspection details.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following describes the `show arp` command shown in the following example.



Row Heading	Description
Protocol	Displays the protocol type.
Address	Displays the IP address of the ARP entry.
Age(min)	Displays the age (in minutes) of the ARP entry.
Hardware Address	Displays the MAC address associated with the ARP entry.
Interface	Displays the first two letters of the interfaces type and the slot/port associated with the ARP entry.
VLAN	Displays the VLAN ID, if any, associated with the ARP entry.
CPU	Lists which CPU the entries are stored on.

Example

```
Dell#show arp
```

Protocol	Address	Age (min)	Hardware Address	Interface	VLAN	
CPU						
Internet	10.11.8.6	167	00:01:e9:45:00:03	Ma 0/0	-	CP
Internet	10.11.68.14	124	00:01:e9:45:00:03	Ma 0/0	-	CP
Internet	10.11.209.254	0	00:01:e9:45:00:03	Ma 0/0	-	CP

Example (Private VLAN)



NOTE: In this example, Line 1 shows community VLAN 200 (in primary VLAN 10) in a PVLAN. Line 2 shows primary VLAN 10.

```
Dell#show arp
```

Protocol	Address	Age (min)	Hardware Address	Interface	VLAN	
CPU						
Internet	5.5.5.1	-	00:01:e8:43:96:5e	-	Vl 10 pv 200	CP
Internet	5.5.5.10	-	00:01:e8:44:99:55	-	Vl 10	CP
Internet	10.1.2.4	1	00:01:e8:d5:9e:e2	Ma 0/0	-	CP
Internet	10.10.10.4	1	00:01:e8:d5:9e:e2	Ma 0/0	-	CP
Internet	10.16.127.53	1	00:01:e8:d5:9e:e2	Ma 0/0	-	CP
Internet	10.16.134.254	20	00:01:e8:d5:9e:e2	Ma 0/0	-	CP
Internet	133.33.33.4	1	00:01:e8:d5:9e:e2	Ma 0/0	-	CP

Usage Information

The following describes the `show arp summary` command shown in the following example.

Row Heading	Description
Total Entries	Lists the total number of ARP entries in the ARP table.
Static Entries	Lists the total number of configured or static ARP entries.
Dynamic Entries	Lists the total number of learned or dynamic ARP entries.
CPU	Lists which CPU the entries are stored on.

Example (Summary)

```
Dell#show arp summary
```

TotalEntries	Static Entries	Dynamic Entries	CPU
3	0	3	CP

```
Dell#
```

show ip interface

View IP-related information on all interfaces.

Syntax `show ip interface [interface | brief] [configuration]`

Parameters	interface	(OPTIONAL) Enter the following keywords and slot/port or number information: • For the Management interface, enter the keyword <code>ManagementEthernet</code> followed by zero (0). • For a Port Channel interface, enter the keywords <code>port-channel</code> followed by a number. The range is from 1 to 128. • For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information. • For a VLAN, enter the keyword <code>vlan</code> followed by a number from 1 to 4094.
	brief	(OPTIONAL) Enter the keyword <code>brief</code> to view a brief summary of the interfaces and whether an IP address is assigned.
	configuration	(OPTIONAL) Enter the keyword <code>configuration</code> to display the physical interfaces with non-default configurations only.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following describes the `show ip interface` command shown in the following example.

Lines	Description
TenGigabitEthernet 0/0...	Displays the interface's type, slot/port and physical and line protocol
Internet address...	States whether an IP address is assigned to the interface. If one is, that address is displayed.
IP MTU is...	Displays IP MTU value.
Inbound access...	Displays the name of the any configured incoming access list. If none is configured, the phrase "not set" is displayed.
Proxy ARP...	States whether proxy ARP is enabled on the interface.
Split horizon...	States whether split horizon for RIP is enabled on the interface.
Poison Reverse...	States whether poison for RIP is enabled on the interface
ICMP redirects...	States if ICMP redirects are sent.
ICMP unreachable...	States if ICMP unreachable messages are sent.



Example

```
Dell#show ip int te 0/0
TenGigabitEthernet 0/0 is down, line protocol is down
Internet address is not set
IP MTU is 1500 bytes
Inbound access list is not set
Proxy ARP is enabled
Split Horizon is enabled
Poison Reverse is disabled
ICMP redirects are not sent
ICMP unreachable are not sent
Dell#
```

Usage Information

The following describes the `show ip interface brief` command shown in the following example.

Fields	Description
Interface	Displays type of interface and the associated slot and port number.
IP-Address	Displays the IP address for the interface, if configured.
Ok?	Indicates if the hardware is functioning properly.
Method	Displays "Manual" if the configuration is read from the saved configuration.
Status	States whether the interface is enabled (up) or disabled (administratively down).
Protocol	States whether IP is enabled (up) or disabled (down) on the interface.

Example (Brief)

```
Dell#show ip int brief
Interface                IP-Address  OK? Method Status Protocol
TenGigabitEthernet 0/1 unassigned NO   None   up    down
TenGigabitEthernet 0/2 unassigned YES  None   up    up
TenGigabitEthernet 0/3 unassigned YES  None   up    up
TenGigabitEthernet 0/4 unassigned NO   None   up    down
TenGigabitEthernet 0/5 unassigned NO   None   up    down
TenGigabitEthernet 0/6 unassigned NO   None   up    down
TenGigabitEthernet 0/7 unassigned NO   None   up    down
TenGigabitEthernet 0/8 unassigned NO   None   up    down
TenGigabitEthernet 0/9 unassigned NO   None   up    down
```

show ip management-route

View the IP addresses assigned to the Management interface.

Syntax

```
show ip management-route [all | connected | summary | static]
```

Parameters

all	(OPTIONAL) Enter the keyword <code>all</code> to view all IP addresses assigned to all Management interfaces on the switch.
connected	(OPTIONAL) Enter the keyword <code>connected</code> to view only routes directly connected to the Management interface.
summary	(OPTIONAL) Enter the keyword <code>summary</code> to view a table listing the number of active and non-active routes and their sources.
static	(OPTIONAL) Enter the keyword <code>static</code> to view non-active routes also.

Command Modes

· EXEC



- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show ip management-route
Destination      Gateway          State
-----
10.1.2.0/24      ManagementEthernet 0/0    Connected
172.16.1.0/24    10.1.2.4        Active
Dell#
```

show ip multicast-cam stack-unit

Displays content-addressable memory (CAM) entries.

Syntax `show ip multicast-cam stack-unit 0-5 port-set pipe-number [ip-address mask [longer-prefixes] | detail | member-info | summary]`

Parameters

<i>0-5</i>	Enter the stack-unit ID, from 0 to 5.
<i>pipe-number</i>	Enter the number of the Port-Pipe number. The range is from 0 to 0.
<i>ip-address mask</i> [<i>longer-prefix</i>]	(OPTIONAL) Enter the IP address and mask of a route to CAM entries for that route only. Enter the keyword <i>longer-prefixes</i> to view routes with a common prefix.
detail	Enter the keyword <i>detail</i> to display the group index ID used by the ecmp routes in the CAM.
member-info	Enter the keyword <i>member-info</i> to display the group index used by the ecmp, the number of egress ports (members) for the ecmp, and the port details of each member. The detail information under <i>member-info</i> will give the MAC address, VLAN ID and gateway of every member port of the ecmp.
summary	(OPTIONAL) Enter the keyword <i>summary</i> to view a table listing route prefixes and the total number routes which can be entered in to CAM.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

9.4(0.0)	Supported on the FN I/O Aggregator.
----------	-------------------------------------



8.3.17.0 Supported on the M I/O Aggregator.

Usage Information The following describes the `show ip fib stack-unit` command shown in the following example.

Field	Description
Destination	Displays the destination route of the index.
CG	Displays 0.
V	Displays a 1 if the entry is valid and a 0 otherwise.
C	Displays the CPU bit. 1 indicates that a packet hitting this entry is forwarded to the control processor, depending on Egress port.
V Id	Displays the VLAN ID. If the entry is 0, the entry is not part of a VLAN.
Mac Addr	Displays the next-hop router's MAC address.
Port	Displays the egress interface. Use the second half of the entry to determine the interface. For example, in the entry 17cl CP, the CP is the pertinent portion. • CP = control processor • Fo= 40 Gigabit Ethernet interface • Te = 10 Gigabit Ethernet interface

Example

```
Dell#show ip multicast-cam stack-unit 0 port-set 0 10.10.10.10/32
longer-prefixes
Destination      EC      CG      V      C      VId      Mac-Addr      Port
-----
10.10.10.10      0       0       1       1       0 00:00:00:00:00:00      3f01 CP
Dell#
```

show ip route

View information, including how they were learned, about the IP routes on the switch.

Syntax `show ip route [hostname | ip-address [mask] [longer-prefixes] | list
prefix-list [process-id] | connected | static | summary]`

Parameters	ip-address	(OPTIONAL) Specify a name of a device or the IP address of the device to view more detailed information about the route.
	mask	(OPTIONAL) Specify the network mask of the route. Use this parameter with the IP address parameter.
	longer-prefixes	(OPTIONAL) Enter the keywords <code>longer-prefixes</code> to view all routes with a common prefix.
	list prefix-list	(OPTIONAL) Enter the keyword <code>list</code> and the name of a configured prefix list.
	process-id	(OPTIONAL) Specify that only OSPF routes with a certain process ID must be displayed.



connected	(OPTIONAL) Enter the keyword <code>connected</code> to view only the directly connected routes.
static	(OPTIONAL) Enter the keyword <code>static</code> to view only routes configured by the <code>ip route</code> command.
summary	(OPTIONAL) Enter the keyword <code>summary</code> .

Command Modes

- EXEC
- EXEC Privilege

Supported Modes

All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

The following describes the `show ip route all` command in the following example.

Field	Description
(undefined)	Identifies the type of route: • C = connected • S = static • R = RIP • B = BGP • IN = internal BGP • EX = external BGP • LO = Locally Originated • O = OSPF • IA = OSPF inter area • N1 = OSPF NSSA external type 1 • N2 = OSPF NSSA external type 2 • E1 = OSPF external type 1 • E2 = OSPF external type 2 • i = IS-IS • L1 = IS-IS level-1 • L2 = IS-IS level-2 • IA = IS-IS inter-area • * = candidate default • > = non-active route • + = summary routes
Destination	Identifies the route's destination IP address.
Gateway	Identifies whether the route is directly connected and on which interface the route is configured.
Dist/Metric	Identifies if the route has a specified distance or metric.



Field	Description
Last Change	Identifies when the route was last changed or configured.

Example

Example (Summary)

```

Dell#show ip route summary
Route Source      Active Routes      Non-active Routes
connected         2                   0
static            1                   0
Total             3                   0
Total 3 active route(s) using 612 bytes
Dell#show ip route static ?
|                Pipe through a command
<cr>
Dell#show ip route static
          Destination      Gateway              Dist/Metric  Last Change
          -----
*S      0.0.0.0/0          via 10.10.91.9, Te 1/2      1/0         3d2h
Dell#

```

show tcp statistics

View information on TCP traffic through the switch.

Syntax `show tcp statistics`

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following describes the `show tcp statistics cp` command shown in the following example.

Field	Description
Rcvd:	Displays the number and types of TCP packets received by the switch. - Total = total packets received - no port = number of packets received with no designated port
0 checksum error...	Displays the number of packets received with the following: - checksum errors - bad offset to data - too short
329 packets...	Displays the number of packets and bytes received in sequence.
17 dup...	Displays the number of duplicate packets and bytes received.
0 partially...	Displays the number of partially duplicated packets and bytes received.
7 out-of-order...	Displays the number of packets and bytes received out of order.



Field	Description
0 packets with data after window	Displays the number of packets and bytes received that exceed the switch's window size.
0 packets after close	Displays the number of packet received after the TCP connection was closed.
0 window probe packets...	Displays the number of window probe and update packets received.
41 dup ack...	Displays the number of duplicate acknowledgement packets and acknowledgement packets with data received.
10184 ack...	Displays the number of acknowledgement packets and bytes received.
Sent:	Displays the total number of TCP packets sent and the number of urgent packets sent.
25 control packets...	Displays the number of control packets sent and the number retransmitted.
11603 data packets...	Displays the number of data packets sent.
24 data packets retransmitted	Displays the number of data packets resent.
355 ack..	Displays the number of acknowledgement packets sent and the number of packet delayed.
0 window probe...	Displays the number of window probe and update packets sent.
7 Connections initiated...	Displays the number of TCP connections initiated, accepted, and established.
14 Connections closed...	Displays the number of TCP connections closed, dropped.
20 Total rxmt...	Displays the number of times the switch tried to re-send data and the number of connections dropped during the TCP retransmit timeout period.
0 Keepalive....	Lists the number of keepalive packets in timeout, the number keepalive probes and the number of TCP connections dropped during keepalive.

Example

```
Dell#show tcp statistics

Rcvd: 9849 Total, 0 no port
0 checksum error, 0 bad offset, 0 too short
5735 packets (7919 bytes) in sequence
20 dup packets (2 bytes)
0 partially dup packets (0 bytes)
1 out-of-order packets (0 bytes)
0 packets ( 0 bytes) with data after window
0 packets after close
0 window probe packets, 0 window update packets
0 dup ack packets, 0 ack packets with unsend data
6671 ack packets (152813 bytes)
Sent: 6778 Total, 0 urgent packets
7 control packets
6674 data packets (152822 bytes)
12 data packets (1222 bytes) retransmitted
85 ack only packets (5677 delayed)
0 window probe packets, 0 window update packets
0 Connections initiated, 7 connections accepted, 7 connections established
8 Connections closed (including 4 dropped, 0 embryonic dropped)
```



```
12 Total rxmt timeout, 1 connections dropped in rxmt timeout
26 Keepalive timeout, 25 keepalive probe, 1 Connections dropped in
keepalive
Dell#
```



iSCSI Optimization

Internet small computer system interface (iSCSI) optimization enables quality-of-service (QoS) treatment for iSCSI storage traffic on an Aggregator.

 **NOTE:** When iSCSI storage devices are detected on the server-ports, storm-control is disabled on those ports. When the iSCSI devices are off the ports, storm-control is enabled again.

advertise dcbx-app-tlv

Configure DCBX to send iSCSI TLV advertisements.

Syntax	<code>advertise dcbx-app-tlv iscsi</code> To disable DCBX iSCSI TLV advertisements, use the <code>no advertise dcbx-app-tlv iscsi</code> command.	
Defaults	Disabled.	
Command Modes	PROTOCOL LLDP	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Usage Information	You can configure iSCSI TLVs to send either globally or on a specified interface. The interface configuration takes priority over global configuration.	

iscsi aging time

Set the aging time for iSCSI sessions.

Syntax	<code>iscsi aging time time</code> To remove the iSCSI session aging time, use the <code>no iscsi aging time</code> command.	
Parameters	<i>time</i>	Enter the aging time for the iSCSI session. The range is from 5 to 43,200 minutes.
Defaults	10 minutes	
Command Modes	CONFIGURATION	



Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

iscsi cos

Set the QoS policy that is applied to the iSCSI flows.

Syntax `iscsi cos {enable | disable | dot1p vlan-priority-value [remark] | dscp dscp-value [remark]}`
To disable the QoS policy, use the `no iscsi cos dscp` command.

Parameters

enable	Enter the keyword <code>enable</code> to allow the application of preferential QoS treatment to iSCSI traffic so that the iSCSI packets are scheduled in the switch with a dot1p priority 4 regardless of the VLAN priority tag in the packet. The default is: the iSCSI packets are handled with dotp1 priority 4 without remark.
disable	Enter the keyword <code>disable</code> to disable the application of preferential QoS treatment to iSCSI frames.
dot1p vlan-priority-value	Enter the dot1p value of the VLAN priority tag assigned to the incoming packets in an iSCSI session. The range is from 0 to 7. The default is the dot1p value in ingress iSCSI frames is not changed and is the same priority is used in iSCSI TLV advertisements if you did not enter the <code>iscsi priority-bits</code> command.
dscp dscp-value	Enter the DSCP value assigned to the incoming packets in an iSCSI session. The valid range is from 0 to 63. The default is: the DSCP value in ingress packets is not changed.
remark	Marks the incoming iSCSI packets with the configured dot1p or DSCP value when they egress to the switch. The default is: the dot1and DSCP values in egress packets are not changed.

Defaults The default dot1p VLAN priority value is 4 without the `remark` option.

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.



iscsi enable

Globally enable iSCSI optimization.

Syntax `iscsi enable`

To disable iSCSI optimization, use the `no iscsi enable` command.

Parameters `enable` Enter the keyword `enable` to enable the iSCSI optimization feature.

Defaults Disabled.

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information When you enable the iSCSI feature using the `iscsi enable` command, flow control settings are set to `rx on tx off` on all interfaces.

iscsi priority-bits

Configure the iSCSI priority advertised for the iSCSI protocol in application priority TLVs.

Syntax `iscsi priority-bits priority-bitmap`

To remove the configured iSCSI priority, use the `no iscsi priority-bits` command.

Parameters `priority-bitmap` Enter the priority-bitmap range. The range is from 1 to FF.

Defaults 0x10

Command Modes PROTOCOL LLDP

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information This command is available at the global level only.



iscsi profile-compellent

Configure the auto-detection of Dell Compellent arrays on a port.

Syntax `iscsi profile-compellent`

Defaults Dell Compellent disk arrays are not detected.

Command Modes INTERFACE

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

iscsi target port

Configure the iSCSI target ports and optionally, the IP addresses on which iSCSI communication is monitored.

Syntax `iscsi target port [tcp-port-2...tcp-port-16] ip-address [ip-address]`
To remove the configured iSCSI target ports or IP addresses, use the `no iscsi target port` command.

Parameters

<i>tcp-port-2...tcpport- 16</i>	Enter the tcp-port number of the iSCSI target ports. The <code>tcp-port-n</code> is the TCP port number or a list of TCP port numbers on which the iSCSI target listens to requests. Separate port numbers with a comma. The default is 860, 3260 .
<i>ip-address</i>	(Optional) Enter the ip-address that the iSCSI monitors. The ip-address specifies the IP address of the iSCSI target.

Defaults **860, 3260**

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module

Usage Information You can configure up to 16 target TCP ports on the switch in one command or multiple commands.

When you use the `no iscsi target port` command and the TCP port you wish to delete is one bound to a specific IP address, the IP address value must be included in the command.



show iscsi

Display the currently configured iSCSI settings.

Syntax `show iscsi`

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show iscsi
iSCSI is enabled
iSCSI session monitoring is enabled
iSCSI COS : dot1p is 4 no-remark
Session aging time: 10
Maximum number of connections is 256
-----
iSCSI Targets and TCP Ports:
-----
TCP Port      Target IP Address
3260
860
Dell#
```

Related Commands

- [show iscsi sessions](#) — displays information on active iSCSI sessions on the switch that have been established since the last reload.
- [show iscsi sessions detailed](#) — displays detailed information on active iSCSI sessions on the switch.

show iscsi sessions

Display information on active iSCSI sessions on the switch that have been established since the last reload.

Syntax `show iscsi sessions`

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell# show iscsi sessions
Session 0:
```



```
Target: iqn.2001-05.com.equallogic:0-8a0906-0e70c2002-10a0018426a48c94-
iom010
Initiator: iqn.1991-05.com.microsoft:win-x918v27yajg
ISID: 400001370000
```

Session 1:

```
Target: iqn.2001-05.com.equallogic:0-8a0906-0f60c2002-0360018428d48c94-
iom011
Initiator: iqn.1991-05.com.microsoft:win-x918v27yajg
ISID: 400001370000.
```

Related Commands

- [show iscsi](#) — displays the currently configured iSCSI settings.
- [show iscsi sessions detailed](#) — displays detailed information on active iSCSI sessions on the switch.

show iscsi sessions detailed

Displays detailed information on active iSCSI sessions on the switch.

Syntax `show iscsi sessions detailed [session isid]`

Parameters

<i>isid</i>	Enter the session's iSCSI ID to display detailed information on specified iSCSI session.
-------------	--

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
---------	-------------

9.4(0.0)	Supported on the FN I/O Aggregator.
----------	-------------------------------------

8.3.17.0	Supported on the M I/O Aggregator.
----------	------------------------------------

Example

```
Dell# show iscsi sessions detailed
Session 0 :
```

```
-----
Target:iqn.2010-11.com.ixia:ixload:iscsi-TG1
Initiator:iqn.2010-11.com.ixia.ixload:initiator-iscsi-2c
Up Time:00:00:01:28 (DD:HH:MM:SS)
Time for aging out:00:00:09:34 (DD:HH:MM:SS)
ISID:806978696102
Initiator      Initiator      Target      Target      Connection
IP Address     TCP Port      IP Address  TCPPort      ID
10.10.0.44      33345         .10.0.101   3260         0
Session 1 :
```

```
-----
Target:iqn.2010-11.com.ixia:ixload:iscsi-TG1
Initiator:iqn.2010-11.com.ixia.ixload:initiator-iscsi-35
Up Time:00:00:01:22 (DD:HH:MM:SS)
Time for aging out:00:00:09:31 (DD:HH:MM:SS)
ISID:806978696102
Initiator      Initiator      Target      Target      Connection
IP Address     TCP Port      IP Address  TCPPort      ID
10.10.0.53     33432         10.10.0.101 3260         0
```



Related Commands

- [show iscsi](#) — displays the currently configured iSCSI settings.
- [show iscsi sessions](#) — displays information on active iSCSI sessions on the switch that have been established since the last reload.



Isolated Networks

This chapter describes the isolated networks commands in the Dell Networking OS.

io-aggregator isolated-network vlan

Enable the isolated-network functionality for a particular VLAN or a set of VLANs.

Syntax	<code>[no] io-aggregator isolated-network vlan <i>vlan-range</i></code>	
Parameters	isolated-network	Specify an isolated network to be configured
	vlan <i>vlan-range</i>	Enter the keyword <code>vlan</code> followed by the member VLANs using VLAN IDs (separated by commas), a range of VLAN IDs (separated by a hyphen), a single VLAN ID, or a combination. For example: VLAN IDs (comma-separated): 3, 4, 6. Range (hyphen-separated): 5-10. Combination: 3, 4, 5-10, 8.
Defaults	Not configured.	
Command Modes	CONFIGURATION	
Usage Information	To add more VLANs into an isolated network, you can enter this same command at any later point. The VLANs specified are appended to the existing set of VLANs. To remove a VLAN or a set of VLANs from an isolated network, use the <code>no</code> form of command.	
Supported Modes	All Modes	
Command History	Version	Description
	9.5(0.0)	Supported on the FN I/O Aggregator.
	9.5(0.0)	Supported on the M I/O Aggregator.
Example	<code>Dell(conf)#io-aggregator isolated-network vlan 5-10</code>	

show io-aggregator isolated-networks

Display the VLANs that are configured to be part of an isolated network on an Aggregator.

Syntax	<code>show io-aggregator isolated-networks</code>	
Parameters	isolated-networks	Specify an isolated network to be configured



vlan vlan-range Enter the keyword vlan followed by the member VLANs using VLAN IDs (separated by commas), a range of VLAN IDs (separated by a hyphen), a single VLAN ID, or a combination. For example: VLAN IDs (comma-separated): 3, 4, 6. Range (hyphen-separated): 5-10. Combination: 3, 4, 5-10, 8.

Defaults None

Command Modes EXEC Privilege

Usage Information This command is used to show the isolated-network feature status and the VLANs configured for this feature. Show running-config will save this command under io-aggregator.

Supported Modes All Modes

Command History	
Version	Description
9.5(0.0)	Supported on the FN I/O Aggregator.
9.5(0.0)	Supported on the M I/O Aggregator.

Example Dell#show io-aggregator isolated-networks
Isolated Network Enabled VLANs : 5-10



Link Aggregation Control Protocol (LACP)

This chapter contains commands for Dell Networking's implementation of the link aggregation control protocol (LACP) for the creation of dynamic link aggregation groups (LAGs — called *port-channels* in Dell Networking OS parlance).

auto-lag enable

Enable auto-lag on a server facing port.

Syntax `auto-lag enable`

To disable the auto-lag use the `no auto-lag enable` command.

When disabled, the server port associated in a LAG is removed and the LAG itself gets removed. Any LACPDUs received on the server port are discarded.

Defaults	Enabled	
Command Modes	INTERFACE	
Supported Modes	Standalone, Stacking, VLT	
Command History	Version	Description
	9.6(0.0)	Supported on the FN I/O Aggregator
	9.6(0.0)	Supported on the M I/O Aggregator.

clear lacp counters

Clear Port Channel counters.

Syntax	<code>clear lacp port-channel-number counters</code>	
Parameters	<i>port-channel-number</i>	Enter a port-channel number:
		The range is from 1 to 128.
Command Modes	EXEC	
	EXEC Privilege	
Supported Modes	All Modes	



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Related Commands [show lacp](#) — displays the LACP configuration.

debug lacp

Debug LACP (events).

Syntax `debug lacp [events | pdu interface [in | out]]`
 To disable LACP debugging, use the `no debug lacp [events | pdu interface [in | out]]` command.

Parameters	events	(OPTIONAL) Enter the keyword <code>events</code> to debug the LACP event information.
	pdu in out	(OPTIONAL) Enter the keyword <code>pdu</code> to debug the LACP Protocol Data Unit information. Optionally, enter an <code>in</code> or <code>out</code> parameter to: - Receive enterin - Transmit enterout
	interface in out	Enter the following keywords and slot/port or number information: For a Ten-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information.

Defaults none

Command Modes EXEC
 EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

delay-restore abort-threshold

Increase the Boot Up timer to some value (>60 seconds).

Syntax `delay-restore abort-threshold <interval>`
 To remove use the `no delay-restore abort-threshold` command.



Defaults	60 seconds						
Command Modes	VLT DOMAIN						
Command History	This guide is platform-specific. For command information about other platforms, refer to the relevant <i>Dell Networking OS Command Line Reference Guide</i> . The following is a list of the Dell Networking OS version history for this command. <table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>9.8(0.0)</td><td>Introduced on the S3048-ON and S4048-ON.</td></tr> <tr> <td>9.7(0.0)</td><td>Introduced on the S4820T, S4810, S6000, S5000, Z9000, S6000-ON and Z9500.</td></tr> </table>	Version	Description	9.8(0.0)	Introduced on the S3048-ON and S4048-ON.	9.7(0.0)	Introduced on the S4820T, S4810, S6000, S5000, Z9000, S6000-ON and Z9500.
Version	Description						
9.8(0.0)	Introduced on the S3048-ON and S4048-ON.						
9.7(0.0)	Introduced on the S4820T, S4810, S6000, S5000, Z9000, S6000-ON and Z9500.						
Parameter	Enter the value (in seconds) to specify the time interval for delay restore timer to abort. This timer is applicable only during reload/boot-up and not in other scenarios (example, ICL flap). The range is from 1 to 1800 seconds.						
Usage Information	To abort VLT delay restore timer as the maximum threshold, the maximum time interval is applied to hold down ICL peer-up in the start-up configurations during the reload.						

io-aggregator auto-lag enable

Enable auto-lag globally on the server facing ports

Syntax	<code>io-aggregator auto-lag enable</code> To disable the auto-lag, use the <code>no io-aggregator auto-lag enable</code> command. When disabled, all the server ports associated in a LAG are removed and the LAG itself gets removed. Any LACPDUs received on the server ports are discarded.							
Defaults	Enabled							
Command Modes	CONFIGURATION							
Supported Modes	Standalone, Stacking, VLT							
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.6(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.6(0.0)</td><td>Supported on the M I/O Aggregator.</td></tr></table>		Version	Description	9.6(0.0)	Supported on the FN I/O Aggregator.	9.6(0.0)	Supported on the M I/O Aggregator.
Version	Description							
9.6(0.0)	Supported on the FN I/O Aggregator.							
9.6(0.0)	Supported on the M I/O Aggregator.							
Related Commands	show io-aggregator auto-lag status —displays global information on the auto-lag status.							

lACP link-fallback member

Enable the LACP link fallback member feature.

Syntax	<code>lACP link-fallback member-independent port-channel 128</code>
--------	---



To disable the LACP link fallback member, use the `no lacp link-fallback member-independent port-channel 128` command.

Command Modes INTERFACE

Supported Modes Standalone, Stacking

Command History This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Reference Guide*.

The following is a list of the Dell Networking OS version history for this command.

Version	Description
9.7(0.0)	Introduced on the M I/O Aggregator and FN I/O Aggregator.

lacp long-timeout

Configure a long timeout period (30 seconds) for an LACP session.

Syntax `lacp long-timeout`
To reset the timeout period to a short timeout (1 second), use the `no lacp long-timeout` command.

Defaults **1 second**

Command Modes INTERFACE (conf-if-po-number)

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information This command applies to dynamic port-channel interfaces only. When applied on a static port-channel, this command has no effect.

lacp port-priority

To influence which ports will be put in Standby mode when there is a hardware limitation that prevents all compatible ports from aggregating, configure the port priority.

Syntax `lacp port-priority priority-value`
To return to the default setting, use the `no lacp port-priority priority-value` command.

Parameters *priority-value* Enter the port-priority value. The higher the value number, the lower the priority. The range is from 1 to 65535. The default is **32768**.



Defaults	32768	
Command Modes	INTERFACE	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

port-channel mode

Configure the LACP port channel mode.

Syntax `port-channel number mode [active] [passive] [off]`

Parameters	number	Enter the keywords <code>number</code> then a number.
	active	Enter the keyword <code>active</code> to set the mode to the active state.  NOTE: LACP modes are defined in <i>Usage Information</i>.
	passive	Enter the keyword <code>passive</code> to set the mode to the passive state.  NOTE: LACP modes are defined in <i>Usage Information</i>.
	off	Enter the keyword <code>off</code> to set the mode to the off state.  NOTE: LACP modes are defined in <i>Usage Information</i>.

Defaults	off	
Command Modes	INTERFACE	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information	LACP Modes	
	Mode	Function
	active	An interface is in an active negotiating state in this mode. LACP runs on any link configured in the active state and also automatically initiates negotiation with other ports by initiating LACP packets.
	passive	An interface is not in an active negotiating state in this mode. LACP runs on any link configured in the passive state. Ports in a passive state respond to negotiation

Mode	Function
	requests from other ports that are in active states. Ports in a passive state respond to LACP packets
off	An interface cannot be part of a dynamic port channel in off mode. LACP does not run on a port configured in off mode.

port-channel-protocol lacp

Enable LACP on any LAN port.

Syntax `port-channel-protocol lacp`
To disable LACP on a LAN port, use the `no port-channel-protocol lacp` command.

Command Modes INTERFACE

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Example

```
Dell(conf)#interface TenGigabitEthernet 3/15
Dell(conf-if-tengig-3/15)#no shutdown
Dell(conf-if-tengig-3/15)#port-channel-protocol lacp
Dell(conf-if-tengig-3/15-lacp)#port-channel 32 mode active
...
Dell(conf)#interface TenGigabitEthernet 3/16
Dell(conf-if-tengig-3/16)#no shutdown
Dell(conf-if-tengig-3/16)#port-channel-protocol lacp
Dell(conf-if-tengig-3/16-lacp)#port-channel 32 mode active
```

show interfaces port-channel

Display information on configured Port Channel groups.

Syntax `show interfaces port-channel [channel-number] [brief|description]`

Parameters	channel-number	For a Port Channel interface, enter the keyword <code>port-channel</code> followed by a number. The range is from 1 to 128.
	brief	(OPTIONAL) Enter the keyword <code>brief</code> to display only the port channel number, the state of the port channel, and the number of interfaces in the port channel.
	description	(OPTIONAL) Enter the keyword <code>description</code> to display interface information with description.

Command Modes

- EXEC



- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.7(0.0)	Introduced on the M I/O Aggregator.
9.4(0.0)	Supported on the FN I/O Aggregator.

Usage Information The following describes the `show interfaces port-channel` command shown in the following example.

Field	Description
Port-Channel 1...	Displays the status of LAG. In the Example, the status of the LAG, LAG fate-sharing group ("Failover-group") is listed.
Hardware is...	Displays the interface's hardware information and its assigned MAC address.
Port-channel is part...	Indicates whether the LAG is part of a LAG fate-sharing group ("Failover-group").
Internet address...	States whether an IP address is assigned to the interface. If an IP address is assigned, that address is displayed.
MTU 1554...	Displays link and IP MTU.
LineSpeed	Displays the interface's line speed. For a port channel interface, it is the line speed of the interfaces in the port channel.
Members in this...	Displays the interfaces belonging to this port channel.
ARP type:...	Displays the ARP type and the ARP timeout value for the interface.
Last clearing...	Displays the time when the <code>show interfaces</code> counters were cleared.
Queueing strategy.	States the packet queuing strategy. FIFO means first in first out.
packets input...	Displays the number of packets and bytes into the interface.
Input 0 IP packets...	Displays the number of packets with IP headers, VLAN tagged headers, and MPLS headers. The number of packets may not add correctly because a VLAN tagged IP packet counts as both a VLAN packet and an IP packet.
0 64-byte...	Displays the size of packets and the number of those packets entering that interface. This information is displayed over two lines.
Received 0...	Displays the type and number of errors or other specific packets received. This information is displayed over three lines.
Output 0...	Displays the type and number of packets sent out the interface. This information is displayed over three lines.
Rate information...	Displays the traffic rate information into and out of the interface. Traffic rate is displayed in bits and packets per second.
Time since...	Displays the time since the last change in the configuration of this interface.

**Example
(EtherScale)**

```
Dell#show interfaces port-channel
Port-channel 1 is down, line protocol is down
Hardware address is 00:1e:c9:f1:00:05, Current address is 00:1e:c9:f1:00:05
Interface index is 1107755009
Minimum number of links to bring Port-channel up is 1
Internet address is not set
```



```

Mode of IP Address Assignment : NONE
DHCP Client-ID :lag1001ec9f10005
MTU 12000 bytes, IP MTU 1500 bytes
LineSpeed auto
Members in this channel:
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 03:28:00
Queueing strategy: fifo
Input Statistics:
0 packets, 0 bytes
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 0 Broadcasts
0 runs, 0 giants, 0 throttles
0 CRC, 0 overrun, 0 discarded
Output Statistics:
0 packets, 0 bytes, 0 underruns
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 0 Broadcasts, 0 Unicasts
0 throttles, 0 discarded, 0 collisions

```

User Information

The following describes the `show interfaces port-channel brief` command shown in the following example.

Field	Description
LAG	Lists the port channel number.
Mode	Lists the mode: · L3 — for Layer 3 · L2 — for Layer 2
Status	Displays the status of the port channel. · down — if the port channel is disabled (shutdown) · up — if the port channel is enabled (no shutdown)
Uptime	Displays the age of the port channel in hours:minutes:seconds.
Ports	Lists the interfaces assigned to this port channel.
(untitled)	Displays the status of the physical interfaces (up or down). · In Layer 2 port channels, an * (asterisk) indicates which interface is the primary port of the port channel. The primary port sends out interface PDU. · In Layer 3 port channels, the primary port is not indicated.

Example

```

Dell#show int po bri
Codes: L - LACP Port-channel
       O - OpenFlow Controller Port-channel
       A - Auto Port-channel
       I - Internally Lagged
LAG Mode Status Uptime Ports
L   128 L3 down 00:00:00
Dell#

```

To indicate the LACP fallback, Internally lagged is added to the list. When the LAG auto-configures itself, the LAG status describes as 'I'.



Related Commands [show lacp](#) — displays the LACP matrix.

show io-aggregator auto-lag status

Displays global information on the auto-lag status.

Syntax `show io-aggregator auto-lag status`

Command Modes EXEC

Supported Modes Standalone, Stacking, VLT

Command History	Version	Description
	9.6(0.0)	Supported on the FN I/O Aggregator.
	9.6(0.0)	Supported on the M I/O Aggregator.

Example Dell-ct-mx1-1-b1(conf)#do show io-aggregator auto-lag status
Auto LAG creation on server port(s) is disabled

show lacp

Displays the LACP matrix.

Syntax `show lacp port-channel-number [sys-id | counters]`

Parameters	<i>port-channel-number</i>	Enter a port-channel number: The range is from 1 to 128.
	<i>sys-id</i>	(OPTIONAL) Enter the keywords <code>sys-id</code> and the value that identifies a system.
	<i>counters</i>	(OPTIONAL) Enter the keyword <code>counters</code> to display the LACP counters.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example (Port-Channel-Number) Dell#show lacp 128
Port-channel 1 admin up, oper up, mode lacp
Actor System ID:Priority 32768, Address 0001.e800.a12b
Partner System ID:Priority 32768, Address 0001.e801.45a5
 Actor Admin Key 1, Oper Key 1, Partner Oper Key 1



LACP LAG 1 is an aggregatable link

A-Active LACP, B-Passive LACP, C-Short Timeout, D-Long Timeout
E-Aggregatable Link, F-Individual Link, G-IN_SYNC, H-OUT_OF_SYNC
I-Collection enabled, J-Collection disabled, K-Distribution enabled L-
Distribution disabled,
M-Partner Defaulted, N-Partner Non-defaulted, O-Receiver is in expired
state,
P-Receiver is not in expired state

Port Te 0/1 is enabled, LACP is enabled and mode is lacp
Actor Admin: State ACEHJLMP Key 1 Priority 128
Oper: State ACEGIKNP Key 1 Priority 128
Partner Admin: State BDFHJLMP Key 0 Priority 0
Oper: State BCEGIKNP Key 1 Priority 128
Dell#

Example (Sys-id)

Dell#show lacp 1 sys-id
Actor System ID: Priority 32768, Address 0001.e800.a12b
Partner System ID: Priority 32768, Address 0001.e801.45a5
Dell#

Example (Counter)

Dell#show lacp 1 counters

Port LACP PDU Marker PDU Unknown Illegal
Xmit Recv Xmit Recv Pkts Rx Pkts Rx

TenGig 0/1 200 200 0 0 0 0
Dell#

Related Commands

[clear lacp counters](#) — Clears the LACP counters.

[show interfaces port-channel](#) — Displays the information on configured Port Channel groups.

show link-bundle-distribution port-channel

Display the traffic-handling and utilization of the member interfaces of the port channel.

Syntax show link-bundle-distribution port-channel

Command Modes EXEC

EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.3.0.0	Introduced on the M I/O Aggregator

Usage Information The following table describes the output fields of this show command:



Field	Description
Link-bundle trigger threshold	Threshold value that is the checkpoint, exceeding which the link bundle is marked as being overutilized and alarm is generated
LAG bundle number	Number of the LAG bundle
Utilization (In Percent)	Traffic usage in percentage of the packets processed by the port channel
Alarm State	Indicates whether an alarm is generated if overutilization of the port channel occurred. Possible values are Active and Inactive
Interface	Slot and port number, and the type of the member interface of the port channel
Line Protocol	Indicates whether the interface is administratively up or down
Utilization (In Percent)	Traffic usage in percentage of the packets processed by the particular member interface

Example

```
Dell#show link-bundle-distribution port-channel
Link-bundle trigger threshold - 60

LAG bundle - 1          Utilization[In Percent] - 0          Alarm State - Inactive

Interface              Line Protocol  Utilization[In Percent]
Te 0/5                 Up            0
Te 0/13                Up            0
```

show port-channel-flow

Display an egress port in a given port-channel flow.

Syntax

```
show port-channel-flow port-channel number incoming-interface interface
{ src-mac address dest-mac address {vlan vlanid | ether-type }} [ src-ip
address dest-ip address ] [ src-port number dest-port number ]
```

Parameters

port-channel <i>number</i>	Enter the keywords <code>port-channel</code> then the number of the port channel to display flow information. The range is from 1 to 128.
incoming-interface <i>interface</i>	Enter the keywords <code>incoming-interface</code> then the interface type and slot/port or number information: For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information.
src-mac <i>address</i>	Enter the keywords <code>src-mac</code> then the MAC source address in the <code>nn:nn:nn:nn:nn:nn</code> format.
dest-mac <i>address</i>	Enter the keywords <code>dest-mac</code> then the MAC destination address in the <code>nn:nn:nn:nn:nn:nn</code> format.
vlan <i>vlan-id</i>	Enter the keyword <code>vlan</code> then the VLAN ID. The range is from 1 to 4094.



ether-type	Enter the keywords <code>ether-type</code> then the ether-value in the XX:XX format.
src-ip address	Enter the keywords <code>src-ip</code> then the IP source address in IP address format.
dest-ip address	Enter the keywords <code>dest-ip</code> then the IP destination address in IP address format.
src-port number	Enter the keywords <code>src-port</code> then the source port number. The range is from 1 to 65536. The default is None .
dest-port number	Enter the keywords <code>dest-port</code> then the destination port number. The range is from 1 to 65536. The default is None .

Command Modes EXEC

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information

Because this command calculates based on a Layer 2 hash algorithm, use this command to display flows for switched Layer 2 packets, not for routed packets (use the `show ip flow` command to display routed packets).

The `show port-channel-flow` command returns the egress port identification in a given port-channel if a valid flow is entered. A mismatched flow error occurs if MAC-based hashing is configured for a Layer 2 interface and you are trying to display a Layer 3 flow.

The output displays three entries:

- Egress port for unfragmented packets.
- In the event of fragmented packets, the egress port of the first fragment.
- In the event of fragmented packets, the egress port of the subsequent fragments.



NOTE: In the `show port-channel-flow` command output, the egress port for an unknown unicast, multicast, or broadcast traffic is not displayed.

Layer 2

This chapter describes commands to configure Layer 2 features.

This chapter contains the following sections:

- [MAC Addressing Commands](#)
- [Virtual LAN \(VLAN\) Commands](#)

MAC Addressing Commands

The following commands are related to configuring, managing, and viewing MAC addresses:

- [clear mac-address-table dynamic](#)
- [mac-address-table aging-time](#)
- [mac-address-table static](#)
- [mac-address-table station-move refresh-arp](#)
- [show cam mac stack-unit](#)
- [show mac-address-table](#)

Virtual LAN (VLAN) Commands

The following commands configure and monitor virtual local area networks (VLANs). VLANs are a virtual interface and use many of the same commands as physical interfaces.

You can configure an IP address and Layer 3 protocols on a VLAN called Inter-VLAN routing. FTP, TFTP, ACLs and SNMP are not supported on a VLAN.

clear mac-address-table dynamic

Clear the MAC address table of all MAC addresses learned dynamically.

Syntax `clear mac-address-table dynamic {address mac-address | all | interface interface | vlan vlan-id}`

Parameters	address <i>mac-address</i>	Enter the keyword <code>address</code> followed by a MAC address in nn:nn:nn:nn:nn:nn format.
	all	Enter the keyword <code>all</code> to delete all MAC address entries in the MAC address table.
	interface <i>interface</i>	Enter the following keywords and slot/port or number information:



- For a 10-Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` followed by the slot/port information.

vlan *vlan-id* Enter the keyword `vlan` followed by a VLAN ID number from 1 to 4094.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

description

Add a description about the selected VLAN.

Syntax `description description`
To remove the description from the VLAN, use the `no description` command.

Parameters *description* Enter a text string description to identify the VLAN (80 characters maximum).

Defaults none

Command Modes INTERFACE VLAN

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Related Commands [show vlan](#) – displays the VLAN configuration.

mac-address-table aging-time

Specify an aging time for MAC addresses to remove from the MAC address table.

Syntax `mac-address-table aging-time seconds`
To delete the configured aging time, use the `no mac-address-table aging-time seconds` command.

Parameters

seconds Enter either zero (0) or a number as the number of seconds before MAC addresses are relearned. To disable aging of the MAC address table, enter 0. The range is from 10 to 1000000. The default is **1800 seconds**.



Defaults	1800 seconds	
Command Modes	CONFIGURATION	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.

mac-address-table static

Associate specific MAC or hardware addresses to an interface and virtual local area networks (VLANs).

Syntax `mac-address-table static mac-address output interface vlan vlan-id`
 To remove a MAC address, use the `no mac-address-table static mac-address output interface vlan vlan-id` command.

Parameters	mac-address	Enter the 48-bit hexadecimal address in nn:nn:nn:nn:nn:nn format.
	output interface	Enter the keyword <code>output</code> then one of the following interfaces for which traffic is forwarded: - For a Port Channel interface, enter the keywords <code>port-channel</code> then a number. The range is from 1 to 128. - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. - For a 40-Gigabit Ethernet interface, enter the keyword <code>fortyGigE</code> then the slot/port information.
	vlan vlan-id	Enter the keyword <code>vlan</code> then a VLAN ID number from 1 to 4094.

Defaults	Not configured.	
Command Modes	CONFIGURATION	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

mac-address-table station-move refresh-arp

Ensure that address resolution protocol (ARP) refreshes the egress interface when a station move occurs due to a topology change.

Syntax `[no] mac-address-table station-move refresh-arp`

Defaults	none								
Command Modes	CONFIGURATION								
Supported Modes	Programmable-Mux (PMUX)								
Command History	<table> <thead> <tr> <th>Version</th><th>Description</th></tr> </thead> <tbody> <tr> <td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr> <tr> <td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr> <tr> <td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr> </tbody> </table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Version	Description								
9.4(0.0)	Supported on the FN I/O Aggregator.								
9.2(0.0)	Introduced on the M I/O Aggregator.								
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.								
Usage Information	For details about using this command, refer to the “NIC Teaming” section of the Layer 2 chapter in the <i>Dell Networking OS Configuration Guide</i> .								

show cam mac stack-unit

Display the content addressable memory (CAM) size and the portions allocated for MAC addresses and for MAC ACLs.

Syntax `show cam mac stack-unit unit_number port-set port-pipe count [vlan vlan-id] [interface interface]`

Parameters

stack-unit <i>unit_number</i>	(REQUIRED) Enter the keyword <code>stack-unit</code> followed by a stack member number to select the stack unit for which to gather information. The range is 0 to 5.
port-set <i>port-pipe</i>	(REQUIRED) Enter the keywords <code>port-set</code> followed by a Port-Pipe number to select the Port-Pipe for which to gather information. The range is 0.
address <i>mac-addr</i>	(OPTIONAL) Enter the keyword <code>address</code> followed by a MAC address in the nn:nn:nn:nn:nn:nn format to display information on that MAC address.
dynamic	(OPTIONAL) Enter the keyword <code>dynamic</code> to display only those MAC addresses learned dynamically by the switch.
static	(OPTIONAL) Enter the keyword <code>static</code> to display only those MAC address specifically configured on the switch.
interface <i>interface</i>	(OPTIONAL) Enter the keyword <code>interface</code> followed by the interface type, slot and port information: For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> followed by the slot/port information.
vlan <i>vlan-id</i>	(OPTIONAL) Enter the keyword <code>vlan</code> followed by the VLAN ID to display the MAC address assigned to the VLAN. The range is from 1 to 4094.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

show mac-address-table

Display the MAC address table.

Syntax `show mac-address-table [dynamic | static] [address mac-address | interface interface | vlan vlan-id] [count [vlan vlan-id] [interface interface-type [slot [/port]]]]`

Parameters	dynamic	(OPTIONAL) Enter the keyword <code>dynamic</code> to display only those MAC addresses the switch dynamically learns. Optionally, you can also add one of these combinations: <code>address/mac-address</code> , <code>interface/interface</code> , or <code>vlan vlan-id</code> .
	static	(OPTIONAL) Enter the keyword <code>static</code> to display only those MAC addresses specifically configured on the switch. Optionally, you can also add one of these combinations: <code>address/mac-address</code> , <code>interface/interface</code> , or <code>vlan vlan-id</code> .
	address <i>mac-address</i>	(OPTIONAL) Enter the keyword <code>address</code> then a MAC address in the <code>nn:nn:nn:nn:nn:nn</code> format to display information on that MAC address.
	interface <i>interface</i>	(OPTIONAL) Enter the keyword <code>interface</code> then the interface type, slot and port information: - For a Port Channel interface, enter the keywords <code>port-channel</code> then a number. The range is from 1 to 128. - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information.
	interface <i>interface-type</i>	(OPTIONAL) Instead of entering the keyword <code>interface</code> then the interface type, slot and port information, as above, you can enter the interface type, then just a slot number.
	vlan <i>vlan-id</i>	(OPTIONAL) Enter the keyword <code>vlan</code> then the VLAN ID to display the MAC address assigned to the VLAN. The range is 1 to 4094.
	count	(OPTIONAL) Enter the keyword <code>count</code> , then optionally, by an interface or VLAN ID, to display total or interface-specific static addresses, dynamic addresses, and MAC addresses in use.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes Programmable-Mux (PMUX)



Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.

Usage Information

The following describes the `show mac-address-table` command shown in the following example.

Column Heading	Description
VlanId	Displays the VLAN ID number.
Mac Address	Displays the MAC address in nn:nn:nn:nn:nn:nn format.
Type	Lists whether the MAC address was manually configured (Static), learned dynamically (Dynamic), or associated with a specific port (Sticky).
Interface	Displays the interface type and slot/port information. The following abbreviations describe the interface types: • gi — Gigabit Ethernet then a slot/port. • po — Port Channel then a number. The range is from 1 to 255 for TeraScale. • so — SONET then a slot/port. • te — 10 Gigabit Ethernet then a slot/port.
State	Lists if the MAC address is in use (Active) or not in use (Inactive).

Example

```
Dell#show mac-address-table
VlanId Mac Address      Type      Interface  State
20      00:00:c9:ad:f6:12  Dynamic   Te 0/3     Active
Dell#
```

Usage Information

The following describes the `show mac-address-table` command shown in the following example.

Column Heading	Description
VlanId	Displays the VLAN ID number.
Mac Address	Displays the MAC address in nn:nn:nn:nn:nn:nn format.
Type	Lists whether the MAC address was manually configured (Static), learned (Dynamic), or associated with a specific port (Sticky). An (N) indicates that the specified MAC address has been learnt by a neighbor and is synced to the node.
Interface	Displays the interface type and slot/port information. The following abbreviations describe the interface types: • gi — Gigabit Ethernet then a slot/port • po — Port Channel then a number. The range is from 1 to 255. \ • so — SONET then a slot/port. • te — 10-Gigabit Ethernet then a slot/port.
State	Lists if the MAC address is in use (Active) or not in use (Inactive).

The following describes the `show mac-address-table count` command shown in the following example.



Line Beginning With	Description
MAC Entries...	Displays the number of MAC entries learned per VLAN.
Dynamic Address...	Lists the number of dynamically learned MAC addresses.
Static Address...	Lists the number of user-defined MAC addresses.
Total MAC...	Lists the total number of MAC addresses the switch uses.

Example (Count)

```
Dell#show mac-address-table count
MAC Entries for all vlans :
Dynamic Address Count :      5
Static Address (User-defined) Count :  0
Total MAC Addresses in Use:      5
Dell#
```



Link Layer Discovery Protocol (LLDP)

The link layer discovery protocol (LLDP) advertises connectivity and management from the local station to the adjacent stations on an IEEE 802 LAN. LLDP facilitates multi-vendor interoperability by using standard management tools to discover and make available a physical topology for network management. The Dell Networking OS implementation of LLDP is based on IEEE standard 801.1ab. This chapter describes the LLDP commands.

The starting point for using LLDP is invoking LLDP with the `protocol lldp` command in either CONFIGURATION or INTERFACE mode.

The information LLDP distributes is stored by its recipients in a standard management information base (MIB). You can access the information by a network management system through a management protocol such as simple network management protocol (SNMP).

For details about implementing LLDP/LLDP-MED, refer to the Link Layer Discovery Protocol chapter of the *Dell PowerEdge FN I/O Aggregator Configuration Guide*.

advertise dot3-tlv

Advertise dot3 TLVs (Type, Length, Value).

Syntax	<code>advertise dot3-tlv {max-frame-size}</code>	
	To remove advertised dot3-tlv, use the <code>no advertise dot3-tlv {max-frame-size}</code> command.	
Parameters	max-frame-size	Enter the keywords <code>max-frame-size</code> to advertise the dot3 maximum frame size.
Defaults	none	
Command Modes	CONFIGURATION (<code>conf-lldp</code>) and INTERFACE (<code>conf-if-interface-lldp</code>)	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.



advertise management-tlv

Advertise management TLVs (Type, Length, Value).

Syntax	<pre>advertise management-tlv {system-capabilities system-description system-name}</pre> To remove advertised management TLVs, use the <code>no advertise management-tlv {system-capabilities system-description system-name}</code> command.	
Parameters	system-capabilities	Enter the keywords <code>system-capabilities</code> to advertise the system capabilities TLVs to the LLDP peer.
	system-description	Enter the keywords <code>system-description</code> to advertise the system description TLVs to the LLDP peer.
	system-name	Enter the keywords <code>system-name</code> to advertise the system name TLVs to the LLDP peer.
Defaults	none	
Command Modes	CONFIGURATION (conf-lldp)	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.16.1	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Usage Information	The command options <code>system-capabilities</code> , <code>system-description</code> , and <code>system-name</code> can be invoked individually or together, in any sequence.	

clear lldp counters

Clear LLDP transmitting and receiving counters for all physical interfaces or a specific physical interface.

Syntax	<pre>clear lldp counters interface</pre>	
Parameters	interface	Enter the following keywords and slot/port or number information: For a 10-Gigabit Ethernet interface, enter the keyword <code>tenGigabitEthernet</code> followed by the slot/port information.
Defaults	none	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	



Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

clear lldp neighbors

Clear LLDP neighbor information for all interfaces or a specific interface.

Syntax `clear lldp neighbors {interface}`

Parameters

<i>interface</i>	Enter the following keywords and slot/port or number information:
	- For a 10-Gigabit Ethernet interface, enter the keyword <code>tenGigabitEthernet</code> then the slot/port information. - For a 40-Gigabit Ethernet interface, enter the keyword <code>fortyGigE</code> then the slot/port information.

Defaults none

Command Modes EXEC Privilege

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

debug lldp interface

Enable LLDP debugging to display timer events, neighbor additions or deletions, and other information about incoming and outgoing packets.

Syntax `debug lldp interface {interface | all}{events | packet {brief | detail} {tx | rx | both}}`

To disable debugging, use the `no debug lldp interface {interface | all}{events} {packet {brief | detail} {tx | rx | both}}` command.

Parameters

<i>interface</i>	Enter the following keywords and slot/port or number information:
	For a 10-Gigabit Ethernet interface, enter the keyword <code>tenGigabitEthernet</code> followed by the slot/port information.
all	(OPTIONAL) Enter the keyword <code>all</code> to display information on all interfaces.
events	(OPTIONAL) Enter the keyword <code>events</code> to display major events such as timer events.



packet	(OPTIONAL) Enter the keyword <code>packet</code> to display information regarding packets coming in or going out.
brief	(OPTIONAL) Enter the keyword <code>brief</code> to display brief packet information.
detail	(OPTIONAL) Enter the keyword <code>detail</code> to display detailed packet information.
tx	(OPTIONAL) Enter the keyword <code>tx</code> to display transmit-only packet information.
rx	(OPTIONAL) Enter the keyword <code>rx</code> to display receive-only packet information.
both	(OPTIONAL) Enter the keyword <code>both</code> to display both receive and transmit packet information.

Defaults	none
Command Modes	EXEC Privilege
Supported Modes	All Modes
Command History	

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

disable

Enable or disable LLDP.

Syntax	<code>disable</code> To enable LLDP, use the <code>no disable</code> command.
--------	--

Defaults	Enabled, that is <code>no disable</code> .
Command Modes	CONFIGURATION (<code>conf-lldp</code>) and INTERFACE (<code>conf-if-interface-lldp</code>)
Supported Modes	Programmable-Mux (PMUX)
Command History	

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Related Commands	debug lldp interface — debugs LLDP.
------------------	---

hello

Configure the rate at which the LLDP control packets are sent to its peer.

Syntax	<code>hello seconds</code>
--------	----------------------------



To revert to the default, use the `no hello seconds` command.

Parameters	<i>seconds</i>	Enter the rate, in seconds, at which the control packets are sent to its peer. The rate is from 5 to 180 seconds. The default is 30 seconds .								
Defaults	30 seconds									
Command Modes	CONFIGURATION (conf-lldp) and INTERFACE (conf-if-interface-lldp)									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.	
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									

multiplier

Set the number of consecutive misses before LLDP declares the interface dead.

Syntax `multiplier integer`
To return to the default, use the `no multiplier integer` command.

Parameters	<i>integer</i>	Enter the number of consecutive misses before the LLDP declares the interface dead. The range is from 2 to 10.								
Defaults	4 x hello									
Command Modes	CONFIGURATION (conf-lldp) and INTERFACE (conf-if- <i>interface</i> -lldp)									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.	
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									

protocol lldp (Configuration)

Enable LLDP globally on the switch.

Syntax `protocol lldp`
To disable LLDP globally on the chassis, use the `no protocol lldp` command.



Defaults	Enabled.	
Command Modes	CONFIGURATION (conf-lldp)	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

protocol lldp (Interface)

Enter the LLDP protocol in the INTERFACE mode.

Syntax	[no] protocol lldp
	To return to the global LLDP configuration mode, use the <code>no protocol lldp</code> command from Interface mode.

Defaults	Enabled	
Command Modes	INTERFACE (conf-if-interface-lldp)	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information	This command is available only in PMUX mode.	
	By default, protocol lldp is enabled, To disable, use the <code>no protocol lldp</code> command.	
	When you enter the LLDP protocol in the Interface context, it overrides global configurations. When you execute the <code>no protocol lldp</code> from INTERFACE mode, interfaces begin to inherit the configuration from global LLDP CONFIGURATION mode.	

show lldp neighbors

Display LLDP neighbor information for all interfaces or a specified interface.

Syntax	show lldp neighbors [<i>interface</i>] [detail]	
Parameters	<i>interface</i>	(OPTIONAL) Enter the following keywords and slot/port or number information:
		For a 10-Gigabit Ethernet interface, enter the keyword <code>tenGigabitEthernet</code> then the slot/port information.



detail (OPTIONAL) Enter the keyword **detail** to display all the TLV information, timers, and LLDP tx and rx counters.

Defaults none

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Omitting the keyword **detail** displays only the remote chassis ID, Port ID, and Dead Interval.

Example

```
Dell (conf-if-te-1/31)#do show lldp neighbors
Loc PortID      Rem Host Name  Rem Port Id      Rem Chassis Id
-----
Te 1/37         FTOS          TenGigabitEthernet 0/37  00:01:e8:05:40:46
Te 1/38         FTOS          TenGigabitEthernet 0/38  00:01:e8:05:40:46
Te 1/39         FTOS          TenGigabitEthernet 0/39  00:01:e8:05:40:46
Te 1/40         FTOS          TenGigabitEthernet 0/40  00:01:e8:05:40:46
Dell (conf-if-te-1/31)#
```

show lldp statistics

Displays the LLDP statistical information.

Syntax show lldp statistics

Defaults none

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show lldp statistics
----- LLDP GLOBAL STATISTICS ON CHASSIS -----
Total number of neighbors: 4
Last table change time: 00:01:17, In ticks: 3859
Total number of Table Inserts: 7
Total number of Table Deletes: 3
Total number of Table Drops: 0
Total number of Table Age Outs: 0
Dell#
```



Port Monitoring

The port monitoring feature allows you to monitor network traffic by forwarding a copy of each incoming or outgoing packet from one port to another port.

Important Points to Remember

- Port monitoring is supported on physical ports only. Port-channel interfaces and virtual local area networks (VLANs), are not supported.
- The monitoring (destination, “MG”) and monitored (source, “MD”) ports must be on the same switch.
- The monitored (source) interface must be a server-facing interface in the format slot/port, where valid slot numbers are 0-1 and server-facing port numbers are from 1 to 32. The monitoring interface must be an uplink port in the chassis.
- Dell Networking OS permits a limited set of commands for monitoring ports. To display these commands, use the ? command.
- Only one MG and one MD may be in a single port-pipe.
- A monitoring port may not be a member of a VLAN.
- There may only be one destination port in a monitoring session.
- A source port (MD) can only be monitored by one destination port (MG). If you try to assign a monitored port to more than one monitoring port, the following error is displayed as shown in example.

Example

```
Dell(conf)#mon ses 1
Dell(conf-mon-sess-1)#source tengig 0/0 destination tengig 0/60 direction
both
Dell(conf-mon-sess-1)#do show mon ses
SessionID Source      Destination  Direction  Mode  Type
-----
1      TenGig 0/0   TenGig 0/60  both           interface
Port-based
Dell(conf-mon-sess-1)#mon ses 2
Dell(conf-mon-sess-2)#source tengig 0/0 destination tengig 0/61 direction
both
% Error: MD port is already being monitored.
```

 **NOTE:** There is no limit to the number of monitoring sessions per system, provided that there are only four destination ports per port-pipe. If each monitoring session has a unique destination port, the maximum number of session is four per port-pipe.

description

Enter a description of this monitoring session.

Syntax

```
description {description}
```

To remove the description, use the `no description {description}` command.

Parameters	description	Enter a description regarding this session (80 characters maximum).
Defaults	none	
Command Modes	MONITOR SESSION (conf-mon-sess-session-ID)	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Related Commands	monitor session — enables a monitoring session.	

monitor session

Create a session for monitoring traffic with port monitoring.

Syntax	<code>monitor session session-ID</code>
	To delete a session, use the <code>no monitor session session-ID</code> command.
	To delete all monitor sessions, use the <code>no monitor session all</code> command.

Parameters	session-ID	Enter a session identification number. The range is from 0 to 65535.
Defaults	none	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	The <code>monitor</code> command is saved in the running configuration at Monitor Session mode level and can be restored after a chassis reload.	
Example	<pre>Dell(conf)# monitor session 60 Dell(conf-mon-sess-60)</pre>	
Related Command	show monitor session — Displays the monitor session. show running-config monitor session — Displays the running configuration of a monitor session.	



show config

Display the current monitor session configuration.

Syntax `show config`

Defaults none

Command Modes MONITOR SESSION (conf-mon-sess-session-ID)

Supported Modes All Modes

Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell(conf-mon-sess-1)#show config
!
monitor session 1
source TenGigabitEthernet 0/1 destination Port-channel 1 direction rx
```

show monitor session

Display the monitor information of a particular session or all sessions.

Syntax `show monitor session {session-ID}`
To display monitoring information for all sessions, use the `show monitor session` command.

Parameters

<i>session-ID</i>	(OPTIONAL) Enter a session identification number. The range is from 0 to 65535.
-------------------	---

Defaults none

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show monitor session
  SessID  Source      Destination      Dir  Mode  Source IP
Dest IP
-----
-----
      1  Vl 10      Te 0/8         rx   Flow   N/A
N/A
```

Related Commands [monitor session](#) — creates a session for monitoring.



show running-config monitor session

Displays the running configuration of all monitor sessions or a specific session.

Syntax	<code>show running-config monitor session {<i>session-ID</i>}</code> To display the running configuration for all monitor sessions, use the <code>show running-config monitor session</code> command.	
Parameters	<i>session-ID</i>	(OPTIONAL) Enter a session identification number. The range is from 0 to 65535.
Defaults	none	
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	The <code>monitoring</code> command is saved in the running configuration at the Monitor Session mode level and can be restored after a chassis reload.	
Example	<pre>Dell# show running-config monitor session ! monitor session 1 source TenGigabitEthernet 0/1 destination TenGigabitEthernet 0/2 direction rx</pre>	
Related Commands	monitor session — creates a session for monitoring. show monitor session — displays a monitor session.	

source (port monitoring)

Configure a port monitor source.

Syntax	<code>source <i>interface</i> destination <i>interface</i> direction {rx tx both}</code> To disable a monitor source, use the <code>no source <i>interface</i> destination <i>interface</i> direction {rx tx both}</code> command.	
Parameters	<i>interface</i>	Enter the one of the following keywords and slot/port information: For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information.
	<i>destination</i>	Enter the keyword <code>destination</code> to indicate the interface destination.



direction {rx | tx | both} Enter the keyword `direction` followed by one of the packet directional indicators.

- `rx`: to monitor receiving packets only.
- `tx`: to monitor transmitting packets only.
- `both`: to monitor both transmitting and receiving packets.

Defaults none

Command Modes MONITOR SESSION (*conf-mon-sess-session-ID*)

Supported Modes All Modes

Command History

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell(conf-mon-sess-11)#source tengig 10/0 destination tengig 10/47
direction
rx
Dell(conf-mon-sess-11)#
```

Usage Information The monitored (source) interface must be a server-facing interface in the format slot/port, where valid slot numbers are 0-1 and server-facing port numbers are from 1 to 32.



Quality of Service (QoS)

The Dell Networking operating software commands for quality of service (QoS) include traffic conditioning and congestion control. QoS commands are not universally supported on all Dell Networking Products.

Per-Port QoS Commands

Per-port QoS (port-based QoS) allows you to define the QoS configuration on a per-physical-port basis.

Policy-Based QoS Commands

Policy-based traffic classification is handled with class maps. These maps classify unicast traffic into one of four classes. The system allows you to match multiple class maps and specify multiple match criteria. Policy-based QoS is not supported on logical interfaces, such as port-channels, VLANs, or Loopbacks.

bandwidth-percentage

Assign a percentage of weight to the class/queue.

Syntax	<code>bandwidth-percentage <i>percentage</i></code> To remove the bandwidth percentage, use the <code>no bandwidth-percentage</code> command.	
Parameters	<i>percentage</i>	Enter the percentage assignment of weight to the class/queue. The range is from 1 to 100% (granularity 1%).
Defaults	none	
Command Modes	CONFIGURATION (conf-qos-policy-out)	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Usage Information	The unit of bandwidth percentage is 1%. A bandwidth percentage of 0 is allowed and disables the scheduling of that class. If the sum of the bandwidth percentages given to all eight classes exceeds 100%, the bandwidth percentage automatically scales down to 100%.	



Related Commands [qos-policy-output](#) — creates a QoS output policy.

description

Add a description to the selected policy map or QoS policy.

Syntax `description {description}`
To remove the description, use the `no description {description}` command.

Parameters *description* Enter a description to identify the policies (80 characters maximum).

Defaults none

Command Modes CONFIGURATION (policy-map-input and policy-map-output; conf-qos-policy-in and conf-qos-policy-out; wred)

Supported Modes Programmable-Mux (PMUX)

Command History	
Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Related Commands [policy-map-output](#) — creates an output policy map.
[qos-policy-output](#) — creates an output QoS-policy on the router.

dot1p-priority

Assign a value to the IEEE 802.1p bits on the traffic this interface receives.

Syntax `dot1p-priority priority-value`
To delete the IEEE 802.1p configuration on the interface, use the `no dot1p-priority` command.

Parameters *priority-value* Enter a value from 0 to 7.

dot1p	Queue Number
0	2
1	0
2	1
3	3
4	4
5	5



dot1p	Queue Number
6	6
7	7

Defaults none

Command Modes INTERFACE

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information The `dot1p-priority` command changes the priority of incoming traffic on the interface. The system places traffic marked with a priority in the correct queue and processes that traffic according to its queue.

When you set the priority for a port channel, the physical interfaces assigned to the port channel are configured with the same value. You cannot assign the `dot1p-priority` command to individual interfaces in a port channel.

policy-aggregate

Allow an aggregate method of configuring per-port QoS via policy maps. An aggregate QoS policy is part of the policy map (input/output) applied on an interface.

Syntax `policy-aggregate qos-policy-name`
To remove a policy aggregate configuration, use the `no policy-aggregate qos-policy-name` command.

Parameters ***qos-policy-name*** Enter the name of the policy map in character format (32 characters maximum).

Defaults none

Command Modes CONFIGURATION (policy-map-input and policy-map-output)

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.



Usage Information	Aggregate input/output QoS policy applies to all the port ingoing/outgoing traffic. Aggregate input/output QoS policy can coexist with per queue input/output QoS policies. 1. If only aggregate input QoS policy exists, input traffic conditioning configurations (rate-police) apply. Any marking configurations in aggregate input QoS policy are ignored. 2. If aggregate input QoS policy and per class input QoS policy coexist, aggregate input QoS policy preempts per class input QoS policy on input traffic conditioning (rate-police). In other words, if rate police configuration exists in the aggregate QoS policy, the rate police configurations in per class QoS are ignored. Marking configurations in per class input QoS policy still apply to each queue.
Related Commands	policy-map-output — creates an output policy map.

policy-map-output

Create an output policy map.

Syntax	<code>policy-map-output <i>policy-map-name</i></code> To remove a policy map, use the <code>no policy-map-output <i>policy-map-name</i></code> command.									
Parameters	<i>policy-map-name</i>	Enter the name for the policy map in character format (32 characters maximum).								
Defaults	none									
Command Modes	CONFIGURATION									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.	
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									
Usage Information	To assign traffic to different flows using QoS policy, use the Output Policy map. This command enables Policy-Map-Output Configuration mode (conf-policy-map-out).									
Related Commands	service-queue — assigns a class map and QoS policy to different queues. policy-aggregate — allows an aggregate method of configuring per-port QoS using policy maps. service-policy output — applies an output policy map to the selected interface.									

qos-policy-output

Create a QoS output policy.

Syntax	<code>qos-policy-output <i>qos-policy-name</i></code>
---------------	---

To remove an existing output QoS policy, use the `no qos-policy-output qos-policy-name` command.

Parameters	<i>qos-policy-name</i>	Enter your output QoS policy name in character format (32 characters maximum).								
Defaults	none									
Command Modes	CONFIGURATION									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.	
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									
Usage Information	To specify the name of the output QoS policy, use this command. After the output policy is specified, rate-limit, bandwidth-percentage, and WRED can be defined. This command enables Qos-Policy-Output Configuration mode — (conf-qos-policy-out).									
Related Commands	bandwidth-percentage — assigns weight to the class/queue percentage.									

rate-shape

Shape the traffic output on the selected interface.

Syntax	rate shape [kbps] rate [burst-KB]	
Parameters	kbps	Enter the keyword kbps to specify the rate limit in Kilobits per second (Kbps). Make the following value a multiple of 64. The range is from 0 to 40000000. The default granularity is Megabits per second (Mbps).
	rate	Enter the outgoing rate in multiples of 10 Mbps. The range is from 10 to 10000.
	burst-KB	(OPTIONAL) Enter the burst size in KB. The range is from 0 to 10000. The default is 50 .
Defaults	Granularity for rate is Mbps unless you use the kbps option.	
Command Modes	QOS-POLICY-OUT	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.



Usage Information When you apply `rate-shape` in QoS policy both on the Queue Level and in Aggregate mode, the queue-based shaping occurs first then aggregate rate shaping.

service-class bandwidth-percentage

Specify a minimum bandwidth for queues.

Syntax `service-class bandwidth-percentage queue0 number queue1 number queue2 number queue3 number`

Parameters **number** Enter the bandwidth-weight, as a percentage. The range is from 1 to 100.

Defaults none

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information Guarantee a minimum bandwidth to different queues globally using the `service-class bandwidth-percentage` command from CONFIGURATION mode. The command is applied in the same way as the `bandwidth-percentage` command in an output QoS policy. The `bandwidth-percentage` command in QOS-POLICY-OUT mode supersedes the `service-class bandwidth-percentage` command.

When you enable ETS, the egress QoS features in the output QoS policy-map (such as `service-class bandwidth-percentage` and `bandwidth-percentage`), the default bandwidth allocation ratio for egress queues are superseded by ETS configurations. This is to provide compatibility with DCBX. Therefore, Dell Networking OS recommends disabling ETS when you wish to apply these features exclusively. After you disable ETS on an interface, the configured parameters are applied.

service-class dot1p-mapping

Configure a service-class criterion based on a dot1p value.

Syntax `service-class dot1p-mapping {dot1p0 value | dot1p1 value | dot1p2 queue | dot1p3 value | dot1p4 value | dot1p5 value | dot1p6 value | dot1p7 value}`

Parameters **value** Enter a dot1p list number and value. The list number range is from 0 to 7. The range is from 0 to 3.

Defaults For each dot1p Priority, the default CoS queue value is:

- dot1p CoS Queue



0 0-7
1 0-7
2 0-7
3 0-7
4 0-7
5 0-7
6 0-7
7 0-7

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information To apply dot1p-queue-mapping, use the `service-class dynamic dot1p` command.

service-class dynamic dot1p

Honor all 802.1p markings on incoming switched traffic on an interface (from INTERFACE mode) or on all interfaces (from CONFIGURATION mode). A CONFIGURATION mode entry supersedes an INTERFACE mode entry.

Syntax `service-class dynamic dot1p`
To return to the default setting, use the `no service-class dynamic dot1p` command.

Defaults All dot1p traffic is mapped to Queue 0 unless you enable the `service-class dynamic dot1p` command. The default mapping is as follows:

dot1p	Queue ID
0	0
1	0
2	0
3	1
4	2
5	3
6	3
7	3



Command Modes	· INTERFACE · CONFIGURATION									
Supported Modes	Programmable-Mux (PMUX)									
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr><tr><td>8.3.16.1</td><td>Introduced on the MXL 10/40GbE Switch IO Module.</td></tr></table>	Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Introduced on the M I/O Aggregator.	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.	
Version	Description									
9.4(0.0)	Supported on the FN I/O Aggregator.									
9.2(0.0)	Introduced on the M I/O Aggregator.									
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.									
Usage Information	To honor all incoming 802.1p markings on incoming switched traffic on the interface, enter this command. By default, this facility is not enabled (that is, the 802.1p markings on incoming traffic are not honored). You can apply this command on both physical interfaces and port channels. When you set the <code>service-class dynamic</code> for a port channel, the physical interfaces assigned to the port channel are automatically configured; you cannot assign the <code>service-class dynamic</code> command to individual interfaces in a port channel. · All dot1p traffic is mapped to Queue 0 unless you enable the <code>service-class dynamic dot1p</code> command on an interface or globally. · Layer 2 or Layer 3 service policies supersede dot1p service classes.									

service-policy output

Apply an output policy map to the selected interface.

Syntax	<code>service-policy output <i>policy-map-name</i></code> To remove the output policy map from the interface, use the <code>no service-policy output <i>policy-map-name</i></code> command.	
Parameters	<i>policy-map-name</i>	Enter the name for the policy map in character format (16 characters maximum). You can identify an existing policy map or name one that does not yet exist.
Defaults	none	
Command Modes	INTERFACE	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.
Usage Information	A single policy-map can be attached to one or more interfaces to specify the service-policy for those interfaces. A policy map attached to an interface can be modified.	



Related Commands [policy-map-output](#) — creates an output policy map.

service-queue

Assign a class map and QoS policy to different queues.

Syntax `service-queue queue-id [class-map class-map-name] [qos-policy qos-policy-name]`

To remove the queue assignment, use the `no service-queue queue-id [class-map class-map-name] [qos-policy qos-policy-name]` command.

Parameters

queue-id	Enter the value used to identify a queue. The range is from 0 to 3 (four queues per interface; four queues are reserved for control traffic).
class-map class-map-name	(OPTIONAL) Enter the keyword <code>class-map</code> then the class map name assigned to the queue in character format (32 character maximum).
	 NOTE: This option is available under policy-map-input only.
qos-policy qos-policy-name	(OPTIONAL) Enter the keywords <code>qos-policy</code> then the QoS policy name assigned to the queue in text format (32 characters maximum). This specifies the input QoS policy assigned to the queue under <code>policy-map-input</code> and output QoS policy under <code>policy-map-output</code> context.

Defaults none

Command Modes CONFIGURATION (conf-policy-map-in and conf-policy-map-out)

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.
8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Usage Information This command assigns a class map or QoS policy to different queues.

Related Commands [service-policy output](#) — applies an output policy map to the selected interface.

show qos dcb-map

Display the DCB parameters configured in a specified DCB map.

Syntax `show qos dcb-map map-name`

Parameters **map-name** Displays the PFC and ETS parameters configured in the specified map.



Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.6(0.0)	Supported on the FN I/O Aggregator and M I/O Aggregator.

Usage Information

Use the `show qos dcb-map` command to display the enhanced transmission selection (ETS) and priority-based flow control (PFC) parameters used to configure server-facing Ethernet ports.

The following table describes the `show qos dcb-map` output shown in the example below.

Field	Description
State	Complete: All mandatory DCB parameters are correctly configured. In progress: The DCB map configuration is not complete. Some mandatory parameters are not configured.
PFC Mode	PFC configuration in DCB map: On (enabled) or Off.
PG	Priority group configured in the DCB map.
TSA	Transmission scheduling algorithm used by the priority group: Enhanced Transmission Selection (ETS).
BW	Percentage of bandwidth allocated to the priority group.
PFC	PFC setting for the priority group: On (enabled) or Off.
Priorities	802.1p priorities configured in the priority group.

Example

```
Dell# show qos dcb-map dcbmap2

State      :Complete
PfcMode:ON
-----
PG:0 TSA:ETS BW:50 PFC:OFF
Priorities:0 1 2 4 5 6 7

PG:1 TSA:ETS BW:50 PFC:ON
Priorities:3
```

show qos dot1p-queue-mapping

View dot1p to queue mapping.

Syntax `show qos dot1p-queue-mapping`

Defaults none

Command Modes

- EXEC



- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show qos dot1p-queue-mapping
Dot1p Priority : 0 1 2 3 4 5 6 7
               Queue : 0 0 0 1 2 3 3 3
Dell#
```

show qos qos-policy-output

View the output QoS policy details.

Syntax `show qos qos-policy-output [qos-policy-name]`

Parameters

qos-policy-name Enter the QoS policy name.

Defaults none

Command Modes

- EXEC
- EXEC Privilege

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
	8.3.16.1	Introduced on the MXL 10/40GbE Switch IO Module.

Example

```
Dell#show qos qos-policy-output

Qos-policy-output qmap_out
Bandwidth-percentage 10
Qos-policy-output qmap_wg
Rate-shape 100 50
Wred yellow wy
Wred green wg
Dell#
```



Security

This chapter describes various types of security commands in the Dell Networking OS, in the following sections:

The commands are listed in the following sections:

- [AAA Accounting Commands](#)
- [Authentication and Password Commands](#)
- [RADIUS Commands](#)
- [TACACS+ Commands](#)
- [SSH Server and SCP Commands](#)

 **NOTE:** Starting with the Dell Networking OS version 7.2.1.0, LEAP with MSCHAP v2 supplicant is implemented.

AAA Accounting Commands

AAA Accounting enables tracking of services that users are accessing and the amount of network resources being consumed by those services. When you enable AAA Accounting, the network server reports user activity to the TACACS+ security server in the form of accounting records. Each accounting record is comprised of accounting AV pairs and is stored on the access control server. As with authentication and authorization, you must configure AAA Accounting by defining a named list of accounting methods, and then applying that list to various interfaces.

aaa accounting

Enable AAA Accounting and create a record for monitoring the accounting function.

Syntax

```
aaa accounting {system | exec | commands level} {name | default}{start-stop
| wait-start | stop-only} {tacacs+}
```

To disable AAA Accounting, use the `no aaa accounting {system | exec | command level} {name | default}{start-stop | wait-start | stop-only} {tacacs+}` command.

Parameters

system	Enter the keyword <code>system</code> to send accounting information of any other AAA configuration.
exec	Enter the keyword <code>exec</code> to send accounting information when a user has logged in to EXEC mode.
commands level	Enter the keyword <code>command</code> then a privilege level for accounting of commands executed at that privilege level.
name default	Enter one of the following: • For <code>name</code>, enter a user-defined name of a list of accounting methods. • For <code>default</code>, the default accounting methods used.

start-stop	Enter the keywords <code>start-stop</code> to send a “start accounting” notice at the beginning of the requested event and a “stop accounting” notice at the end of the event.
wait-start	Enter the keywords <code>wait-start</code> to ensure that the TACACS+ security server acknowledges the start notice before granting the user’s process request.
stop-only	Enter the keywords <code>stop-only</code> to instruct the TACACS+ security server to send a “stop record accounting” notice at the end of the requested user process.
tacacs+	Enter the keyword <code>tacacs+</code> to use TACACS+ data for accounting. Dell Networking OS currently only supports TACACS+ accounting.

Defaults	none
Command Modes	CONFIGURATION
Supported Modes	All Modes
Command History	

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator and M I/O Aggregator.

Usage Information	In the example above, TACACS+ accounting is used to track all usage of EXEC command and commands on privilege level 15. Privilege level 15 is the default. If you want to track usage at privilege level 1 for example, use the <code>aaa accounting command 1 command</code> .
-------------------	--

Example	<pre>Dell(conf)# aaa accounting exec default start-stop tacacs+ Dell(conf)# aaa accounting command 15 default start-stop tacacs+ Dell(config)#</pre>
---------	--

Related Commands	enable password — changes the password for the <code>enable</code> command.
------------------	---

aaa accounting suppress

Prevent the generation of accounting records of users with the user name value of NULL.

Syntax	<code>aaa accounting suppress null-username</code> To permit accounting records to users with user name value of NULL, use the <code>no aaa accounting suppress null-username</code> command.
--------	--

Defaults	Accounting records are recorded for all users.
----------	--

Command Modes	CONFIGURATION
---------------	---------------

Supported Modes	All Modes
-----------------	-----------

Command History	
Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator and M I/O Aggregator.

Usage Information	Dell Networking OS issues accounting records for all users on the system, including users whose username string, due to protocol translation, is NULL. For example, a user who comes on line with the <code>aaa</code>
-------------------	--



authentication login *method-list* none command is applied. To prevent the accounting records from being generated for sessions that do not have user names associated to them, use the `aaa accounting suppress` command.

aaa authorization commands

Set parameters that restrict (or permit) a user's access to EXEC and CONFIGURATION level commands.

Syntax `aaa authorization commands {level | role role-name}{name|default} {local | tacacs+ | none}`
Undo a configuration with the `no aaa authorization commands {level | role role-name} {name|default} {local | tacacs+ | none}` command.

Parameters	commands level	Enter the keyword <code>commands</code> then the command privilege level for command level authorization.
	role role-name	Enter the keyword <code>role</code> then the role name.
	name	Define a name for the list of authorization methods.
	default	Define the default list of authorization methods.
	local	Use the authorization parameters on the system to perform authorization.
	tacacs+	Use the TACACS+ protocol to perform authorization.
	none	Enter the keyword <code>none</code> to apply no authorization.

Defaults none

Command Modes CONFIGURATION

Supported Modes All Modes

Command History This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following is a list of the Dell Networking OS version history for this command.

Version	Description
9.6(0.0)	Supported on the M I/O Aggregator

aaa authorization config-commands

Set parameters that restrict (or permit) a user's access to EXEC level commands.

Syntax `aaa authorization config-commands`
Disable authorization checking for CONFIGURATION level commands using the `no aaa authorization config-commands` command.

Defaults Enabled when you configure `aaa authorization commands` command.

Command Modes CONFIGURATION

Supported Modes All Modes



Command History This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following table lists the Dell Networking OS version history for this command.

Version	Description
9.6.(0.0)	Supported on the FN I/O Aggregator and M I/O Aggregator.

Usage Information By default, the `aaa authorization commands` command configures the system to check both EXEC level and CONFIGURATION level commands. Use the command `no aaa authorization config-commands` to enable only EXEC-level command checking.

aaa authorization exec

Set parameters that restrict (or permit) a user's access to EXEC-level commands.

Syntax `aaa authorization exec {name | default} {local || tacacs+ || if-authenticated || none}`
To disable authorization checking for EXEC level commands, use the `no aaa authorization exec` command.

Parameters	name	Define a name for the list of authorization methods.
	default	Define the default list of authorization methods.
	local	Use the authorization parameters on the system to perform authorization.
	tacacs+	Use the TACACS+ protocol to perform authorization.
	none	Enter the keyword <code>none</code> to apply no authorization.

Defaults none

Command Modes CONFIGURATION

Supported Modes All Modes

Command History This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following table lists the Dell Networking OS version history for this command.

Version	Description
9.6.(0.0)	Supported on the FN I/O Aggregator and M I/O Aggregator.

accounting

Apply an accounting method list to terminal lines.

Syntax `accounting {exec | commands level} method-list`

Parameters	exec	Enter the keyword <code>exec</code> to apply an EXEC level accounting method list.
	commands level	Enter the keywords <code>commands level</code> to apply an EXEC and CONFIGURATION level accounting method list.



method-list

Enter a method list that you defined using the `aaa accounting exec` or `aaa accounting` commands.

Defaults none

Command Modes LINE

Supported Modes All Modes

Command History

Version

Description

9.4(0.0)

Supported on the FN I/O Aggregator and M I/O Aggregator.

Related Commands [aaa accounting](#) — enables AAA Accounting and creates a record for monitoring the accounting function.

show accounting

Display the active accounting sessions for each online user.

Syntax `show accounting`

Defaults none

Command Modes EXEC

Supported Modes All Modes

Command History This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following table lists the Dell Networking OS version history for this command.

Version

Description

9.4(0.0)

Introduced on the M I/O Aggregator.

Usage Information This command steps through all active sessions and then displays the accounting records for the active account functions.

Example

```
Dell#show accounting
Active accounted actions on tty2, User admin Priv 1 Role <none>
  Task ID 2, EXEC Accounting record, 00:02:03 Elapsed, service=shell
Active accounted actions on tty3, User ad Priv 15 Role <none>
  Task ID 7, EXEC Accounting record, 00:01:22 Elapsed, service=shell
Active accounted actions on tty4, User ad Priv 15 Role <none>
  Task ID 11, EXEC Accounting record, 00:00:35 Elapsed, service=shell
Active accounted actions on tty5, User ad1 Priv1 Role sysadmin
  Task ID 16, EXEC Accounting record, 00:00:04 Elapsed, service=shell
Dell#
```

Related Commands [aaa accounting](#) — enables AAA Accounting and creates a record for monitoring the accounting function.



Authentication and Password Commands

This section contains the commands that control the management access to the system.

aaa authentication enable

Configure AAA Authentication method lists for user access to EXEC privilege mode (the “Enable” access).

Syntax `aaa authentication enable {default | method-list-name} method [... method2]`
To return to the default setting, use the `no aaa authentication enable {default | method-list-name} method [... method2]` command.

Parameters	default	Enter the keyword <code>default</code> then the authentication methods to use as the default sequence of methods for the Enable login. The default is <code>default enable</code> .
	<i>method-list-name</i>	Enter a text string (up to 16 characters long) to name the list of enabled authentication methods activated at login.
	<i>method</i>	Enter one of the following methods: • <code>enable</code>: use the password the <code>enable password</code> command defines in CONFIGURATION mode. • <code>line</code>: use the password the <code>password</code> command defines in LINE mode. • <code>none</code>: no authentication. • <code>radius</code>: use the RADIUS servers configured with the <code>radius-server host</code> command. • <code>tacacs+</code>: use the TACACS+ server(s) configured with the <code>tacacs-server host</code> command.
	<i>... method2</i>	(OPTIONAL) In the event of a “no response” from the first method, Dell Networking Operating System (OS) applies the next configured method.

Defaults Use the `enable password`.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information By default, the `Enable password` is used. If you configure `aaa authentication enable default`, Dell Networking Operating System (OS) uses the methods defined for `Enable access` instead.

Methods configured with the `aaa authentication enable` command are evaluated in the order they are configured. If authentication fails using the primary method, Dell Networking Operating System (OS) employs the second method (or third method, if necessary) automatically. For example, if the TACACS+ server is reachable, but the server key is invalid, Dell Networking OS proceeds to the next authentication method. The TACACS+ is incorrect, but the user is still authenticated by the secondary method.



Related Commands [enable password](#) — changes the password for the `enable` command.

[login authentication](#) — enables AAA login authentication on the terminal lines.

[radius-server host](#) — specifies a RADIUS server host.

[tacacs-server host](#) — specifies a TACACS+ server host.

aaa authentication login

Configure AAA Authentication method lists for user access to EXEC mode (`Enable log-in`).

Syntax `aaa authentication login {method-list-name | default} method [... method4]`
 To return to the default setting, use the `no aaa authentication login {method-list-name | default}` command.

Parameters	<i>method-list-name</i>	Enter a text string (up to 16 characters long) as the name of a user-configured method list that can be applied to different lines.
	<i>default</i>	Enter the keyword <code>default</code> to specify that the method list specified is the default method for all terminal lines.
	<i>method</i>	Enter one of the following methods: • <code>enable</code>: use the password the <code>enable password</code> command defines in CONFIGURATION mode. • <code>line</code>: use the password the <code>password</code> command defines in LINE mode. • <code>none</code>: no authentication. • <code>radius</code>: use the RADIUS servers configured with the <code>radius-server host</code> command. • <code>tacacs+</code>: use the TACACS+ servers configured with the <code>tacacs-server host</code> command.
	<i>... method4</i>	(OPTIONAL) Enter up to four additional methods. In the event of a “no response” from the first method, Dell Networking Operating System (OS) applies the next configured method (up to four configured methods).

Defaults Not configured (that is, no authentication is performed).

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information By default, the locally configured username password is used. If you configure `aaa authentication login default`, Dell Networking Operating System (OS) uses the methods this command defines for login instead.



Methods configured with the `aaa authentication login` command are evaluated in the order they are configured. If users encounter an error with the first method listed, Dell Networking Operating System (OS) applies the next method configured. If users fail the first method listed, no other methods are applied. The only exception is the local method. If the user's name is not listed in the local database, the next method is applied. If the correct user name/password combination is not entered, the user is not allowed access to the switch.

 **NOTE: If authentication fails using the primary method, Dell Networking Operating System (OS) employs the second method (or third method, if necessary) automatically. For example, if the TACACS+ server is reachable, but the server key is invalid, Dell Networking Operating System (OS) proceeds to the next authentication method. The TACACS+ is incorrect, but the user is still authenticated by the secondary method.**

After configuring the `aaa authentication login` command, configure the `login authentication` command to enable the authentication scheme on terminal lines.

Connections to the SSH server work with the following login mechanisms: local, radius, and tacacs.

Related Commands [login authentication](#) — enables AAA login authentication on the terminal lines.

[radius-server host](#) — specifies a RADIUS server host.

[tacacs-server host](#) — specifies a TACACS+ server host.

banner exec

Configure a message that is displayed when your enter EXEC mode.

Syntax `banner exec c line c`
To delete a banner, use the `no banner exec` command.

Parameters

<i>c</i>	Enter the keywords <code>banner exec</code> , then enter a character delineator, represented here by the letter <i>c</i> . Press ENTER .
<i>line</i>	Enter a text string for your banner message ending the message with your delineator. In the following example, the delineator is a percent character (%); the banner message is "testing, testing".

Defaults No banner is displayed.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information After entering the banner login command, type one or more spaces and a delineator character. Enter the banner text then the second delineator character. When the user is connected to the router, if a message of the day banner is configured, it displays first. If no message of the day banner is configured, the login banner and prompt appear. After the user has logged in, the EXEC banner (if configured) displays.



Example

```
Dell(conf)#banner exec ?
LINE c banner-text c, where 'c' is a delimiting character
Dell(conf)#banner exec %
Enter TEXT message. End with the character '%'.
This is the banner%
Dell(conf)#end
Dell#exit
4d21h5m: %RPM0-P:CP %SEC-5-LOGOUT: Exec session is terminated for user on
line
console

This is the banner

Dell con0 now available

Press RETURN to get started.
4d21h6m: %RPM0-P:CP %SEC-5-LOGIN_SUCCESS: Login successful for user on line
console
This is the banner
Dell>
```

Related Commands

[banner login](#) — sets a banner for login connections to the system.

[exec-banner](#) — enables the display of a text string when you enter EXEC mode.

[line](#) — enables and configures the console and virtual terminal lines to the system.

banner login

Set a banner to display when logging on to the system.

Syntax

```
banner login {keyboard-interactive | no keyboard-interactive} [c line c]
```

Parameters

keyboard-interactive	Enter the keyword <code>keyboard-interactive</code> to require a carriage return (CR) to get the message banner prompt.
<i>c</i>	Enter a delineator character to specify the limits of the text banner. The delineator is a percent character (%).
<i>line</i>	Enter a text string for your text banner message ending the message with your delineator. The delineator is a percent character (%). Range: maximum of 50 lines, up to 255 characters per line

Defaults

No banner is configured and the CR is required when creating a banner.

Command Modes

CONFIGURATION

Supported Modes

All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information

After entering the banner login command, type one or more spaces and a delineator character. Enter the banner text then the second delineator character. When the user is connected to the router, if a message of the day banner is configured, it displays first. If no message of the day banner is configured, the login banner and prompt appear. After the user has logged in, the EXEC banner (if configured) displays.



Example

```
Dell(conf)#banner login ?
keyboard-interactive Press enter key to get prompt
LINE c banner-text c, where 'c' is a delimiting character
Dell(conf)#no banner login ?
keyboard-interactive Prompt will be displayed by default
<cr>
Dell(conf)#banner login keyboard-interactive

Enter TEXT message. End with the character '%'.
This is the banner%
Dell(conf)#end
Dell#exit

13d21h9m: %RPM0-P:CP %SEC-5-LOGOUT: Exec session is terminated for user on
line console

This is the banner

Dell con0 now available

Press RETURN to get started.
13d21h10m: %RPM0-P:CP %SEC-5-LOGIN_SUCCESS: Login successful for user on
line console
This is the banner
Dell>
```

Related Commands [exec-banner](#) — enables the display of a text string when you enter EXEC mode.

banner motd

Set a message of the day (MOTD) banner.

Syntax `banner motd c line c`

Parameters

c	Enter a delineator character to specify the limits of the text banner. The delineator is a percent character (%).
line	Enter a text string for your MOTD banner the message with your delineator. The delineator is a percent character (%).

Defaults No banner is configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information After entering the banner login command, type one or more spaces and a delineator character. Enter the banner text then the second delineator character. When the user is connected to the router, if a message of the day banner is configured, it displays first. If no message of the day banner is configured, the login banner and prompt appear. After the user has logged in, the EXEC banner (if configured) displays.

Related Commands [banner exec](#) — enables the display of a text string when you enter EXEC mode.

[banner login](#) — sets a banner to display after successful login to the system.



debug radius

View RADIUS transactions to assist with troubleshooting.

Syntax `debug radius`
To disable debugging of RADIUS, use the `no debug radius` command.

Defaults Disabled.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

debug tacacs+

To assist with troubleshooting, view TACACS+ transactions.

Syntax `debug tacacs+`
To disable debugging of TACACS+, use the `no debug tacacs+` command.

Defaults Disabled.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

exec-banner

Enable the display of a text string when the user enters EXEC mode.

Syntax `exec-banner`
To disable the banner on terminal lines, use the `no exec-banner` command.

Defaults **Enabled on all lines** (if configured, the banner appears).

Command Modes LINE

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.



Usage Information	Optionally, use the <code>banner exec</code> command to create a text string that is displayed when you access EXEC mode. This command toggles that display.
Related Commands	banner exec — configures a banner to display when entering EXEC mode. line — enables and configures console and virtual terminal lines to the system.

ip radius source-interface

Specify an interface's IP address as the source IP address for RADIUS connections.

Syntax	<code>ip radius source-interface interface</code> To delete a source interface, use the <code>no ip radius source-interface</code> command.
---------------	--

Parameters	interface	Enter the following keywords and slot/port or number information: - For a 100/1000 Ethernet interface, enter the keyword <code>GigabitEthernet</code> then the slot/port information. - For a Gigabit Ethernet interface, enter the keyword <code>GigabitEthernet</code> then the slot/port information. - For Loopback interfaces, enter the keyword <code>loopback</code> then a number from zero (0) to 16838. - For the Null interface, enter the keywords <code>null 0</code>. - For a Port Channel interface, enter the keywords <code>port-channel</code> then a number. The range is from 1 to 128. - For a ten-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. - For a 40-Gigabit Ethernet interface, enter the keyword <code>fortyGigE</code> then the slot/port information. - For VLAN interface, enter the keyword <code>vlan</code> then a number from 1 to 4094.
-------------------	------------------	--

Defaults	Not configured.
Command Modes	CONFIGURATION
Supported Modes	All Modes
Command History	

Version	Description
9.3.(0.0)	Supported on the M I/O Aggregator.

ip tacacs source-interface

Specify an interface's IP address as the source IP address for TACACS+ connections.

Syntax	<code>ip tacacs source-interface interface</code> To delete a source interface, use the <code>no ip tacacs source-interface</code> command.
---------------	--

Parameters	interface	Enter the following keywords and slot/port or number information: For a 100/1000 Ethernet interface, enter the keyword <code>GigabitEthernet</code> then the slot/port information.
-------------------	------------------	---



- For a Gigabit Ethernet interface, enter the keyword `GigabitEthernet` then the slot/port information.
- For Loopback interfaces, enter the keyword `loopback` then a number from zero (0) to 16838.
- For the Null interface, enter the keywords `null 0`.
- For a Port Channel interface, enter the keywords `port-channel` then a number. The range is from 1 to 128.
- For a ten-Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` then the slot/port information.
- For a 40-Gigabit Ethernet interface, enter the keyword `fortyGigE` then the slot/port information.
- For VLAN interface, enter the keyword `vlan` then a number from 1 to 4094.

Defaults	Not configured.
Command Modes	CONFIGURATION
Supported Modes	All Modes
Command History	

Version	Description
9.3(0.0)	Supported on the M I/O Aggregator.

login authentication

To designate the terminal lines, apply an authentication method list.

Syntax	<code>login authentication {method-list-name default}</code> To use the local user/password database for login authentication, use the <code>no login authentication</code> command.
--------	---

Parameters	
<i>method-list-name</i>	Enter the keywords <code>method-list-name</code> to specify that method list, created in the <code>aaa authentication login</code> command, to be applied to the designated terminal line.
<i>default</i>	Enter the keyword <code>default</code> to specify that the default method list, created in the <code>aaa authentication login</code> command, is applied to the terminal line.

Defaults	No authentication is performed on the console lines. Local authentication is performed on the virtual terminal and auxiliary lines.
Command Modes	LINE
Supported Modes	All Modes
Command History	

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information	If you configure the <code>aaa authentication login default</code> command, the <code>login authentication default</code> command automatically is applied to all terminal lines.
-------------------	---

Related Commands	aaa authentication login — selects the login authentication methods.
------------------	--



RADIUS Commands

The following RADIUS commands are supported by Dell Networking Operating System (OS).

radius-server deadtime

Configure a time interval during which non-responsive RADIUS servers to authentication requests are skipped.

Syntax	<code>radius-server deadtime seconds</code>	
	To disable this function or return to the default value, use the <code>no radius-server deadtime</code> command.	
Parameters	seconds	Enter a number of seconds during which non-responsive RADIUS servers are skipped. The range is from 0 to 2147483647 seconds. The default is 0 seconds .
Defaults	0 seconds	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

radius-server host

Configure a RADIUS server host.

Syntax	<code>radius-server host {hostname ipv4-address ipv6-address} [auth-port port-number] [retransmit retries] [timeout seconds] [key [encryption-type] key]</code>	
Parameters	hostname	Enter the name of the RADIUS server host.
	ipv4-address ipv6-address	Enter the IPv4 address (A.B.C.D) or IPv6 address (X:X:X:X:X) of the RADIUS server host.
	auth-port port-number	(OPTIONAL) Enter the keywords <code>auth-port</code> then a number as the port number. The range is from zero (0) to 65535. The default port-number is 1812 .
	retransmit retries	(OPTIONAL) Enter the keyword <code>retransmit</code> then a number as the number of attempts. This parameter overwrites the <code>radius-server retransmit</code> command. The range is from zero (0) to 100. The default is 3 attempts .
	timeout seconds	(OPTIONAL) Enter the keyword <code>timeout</code> then the seconds the time interval the switch waits for a reply from the RADIUS server. This parameter overwrites the <code>radius-server timeout</code> command. The range is from 0 to 1000. The default is 5 seconds .
	key [encryption-type] key	(OPTIONAL) Enter the keyword <code>key</code> then an optional encryption-type and a string up to 42 characters long as the authentication key. The RADIUS host server uses this authentication key and the RADIUS daemon operating on this switch.



For the encryption-type, enter either zero (0) or 7 as the encryption type for the key entered. The options are:

- 0 is the default and means the password is not encrypted and stored as clear text.
- 7 means that the password is encrypted and hidden.

Configure this parameter last because leading spaces are ignored.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information To configure any number of RADIUS server hosts for each server host that is configured, use this command. Dell Networking Operating System (OS) searches for the RADIUS hosts in the order they are configured in the software.

The global default values for the `timeout`, `retransmit`, and `key` optional parameters are applied, unless those values are specified in the `radius-server host` or other commands. To return to the global default values, if you configure the `timeout`, `retransmit`, or `key` values, include those keywords when using the `no radius-server host` command syntax.

Related Commands [login authentication](#) — sets the database to be checked when a user logs in.

[radius-server retransmit](#) — sets the number of times the RADIUS server attempts to send information.

[radius-server timeout](#) — sets the time interval before the RADIUS server times out.

radius-server key

Configure a key for all RADIUS communications between the switch and the RADIUS host server.

Syntax `radius-server key [encryption-type] key`
To delete a password, use the `no radius-server key` command.

Parameters	encryption-type	(OPTIONAL) Enter either zero (0) or 7 as the encryption type for the key entered. The options are: • 0 is the default and means the key is not encrypted and stored as clear text. • 7 means that the key is encrypted and hidden.
	key	Enter a string that is the key to be exchanged between the switch and RADIUS servers. It can be up to 42 characters long.

Defaults Not configured.



Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.
Usage Information	The key configured on the switch must match the key configured on the RADIUS server daemon.	
	If you configure the <code>key</code> parameter in the <code>radius-server host</code> command, the key configured with the <code>radius-server key</code> command is the default key for all RADIUS communications.	
Related Commands	radius-server host — configures a RADIUS host.	

radius-server retransmit

Configure the number of times the switch attempts to connect with the configured RADIUS host server before declaring the RADIUS host server unreachable.

Syntax	<code>radius-server retransmit <i>retries</i></code>	
	To configure zero retransmit attempts, use the <code>no radius-server retransmit</code> command.	
	To return to the default setting, use the <code>radius-server retransmit 3</code> command.	
Parameters	<i>retries</i>	Enter a number of attempts that Dell Networking Operating System (OS) tries to locate a RADIUS server. The range is from zero (0) to 100. The default is 3 retries .
Defaults	3 retries	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

Related Commands [radius-server host](#) — configures a RADIUS host.

radius-server timeout

To reply to a request, configure the amount of time the RADIUS client (the switch) waits for a RADIUS host server .

Syntax	<code>radius-server timeout <i>seconds</i></code>	
	To return to the default value, use the <code>no radius-server timeout</code> command.	
Parameters	<i>seconds</i>	Enter the number of seconds between an unsuccessful attempt and the radius-server timeout times out. The range is from zero (0) to 1000 seconds. The default is 5 seconds .



Defaults	5 seconds	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.
Related Commands	radius-server host — configures a RADIUS host.	

show privilege

View your access level.

Syntax	<code>show privilege</code>	
Command Modes	- EXEC - EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.
Example	<pre>Dell#show privilege Current privilege level is 15 Dell#</pre>	

Suppressing AAA Accounting for Null Username Sessions

When you activate AAA accounting, the Dell Networking OS software issues accounting records for all users on the system, including users whose username string, because of protocol translation, is NULL.

An example of this is a user who comes in on a line where the AAA authentication `login method-list none` command is applied. To prevent accounting records from being generated for sessions that do not have usernames associated with them, use the following command.

- Prevent accounting records from being generated for users whose username string is NULL.
- CONFIGURATION mode

```
aaa accounting suppress null-username
```

TACACS+ Commands

Dell Networking OS supports TACACS+ as an alternate method for login authentication.



TACACS+ Accounting

Enable AAA Accounting and create a record for monitoring the accounting function.

Syntax `aaa accounting {system | exec | commands level} {name | default}{start-stop | wait-start | stop-only} {tacacs+}`

To disable AAA Accounting, use the

```
no aaa accounting {system | exec | command level} {name | default}{start-stop | wait-start | stop-only} {tacacs+}
```

command

Defaults.

Parameters

system	Enter the keyword system to send accounting information of any other AAA configuration.
exec	Enter the keyword exec to send accounting information when a user has logged in to EXEC mode.
commands level	Enter the keyword command then a privilege level for accounting of commands executed at that privilege level.
name / default	Enter one of the following: • For name, enter a user-defined name of a list of accounting methods. • For default, the default accounting methods used.
start-stop	Enter the keywords start-stop to send a “start accounting” notice at the beginning of the requested event and a “stop accounting” notice at the end of the event.
wait-start	Enter the keywords wait-start to ensure that the TACACS+ security server acknowledges the start notice before granting the user’s process request.
stop-only	Enter the keywords stop-only to instruct the TACACS+ security server to send a “stop record accounting” notice at the end of the requested user process.
tacacs+	Enter the keyword tacacs+ to use TACACS+ data for accounting.

Dell Networking OS currently only supports TACACS+ accounting.

Defaults None

Command Modes CONFIGURATION

Usage Information In the example above, TACACS+ accounting is used to track all usage of EXEC command and commands on privilege level 15. Privilege level 15 is the default. If you want to track usage at privilege level 1 for example, use the `aaa accounting command 1` command.

Supported Modes All Modes

Command History

Version	Description
9.5(0.0)	Supported on the FN I/O Agregator and M I/O Aggregator.



Example

```
Dell(config)# aaa accounting exec default start-stop tacacs+
Dell(config)# aaa accounting command 15 default start-stop tacacs+
Dell(config)#
```

Related Commands	enable password	changes the password for the enable command.
	login authentication	enables AAA login authentication on the terminal lines.
	password	creates a password.
	tacacs-server host	specifies a TACACS+ server host.

tacacs-server host

Specify a TACACS+ host.

Syntax

```
tacacs-server host {hostname | ipv4-address | ipv6-address} [port number]
[timeout seconds] [key key]
```

Parameters	hostname	Enter the name of the TACACS+ server host.
	ipv4-address ipv6-address	Enter the IPv4 address (A.B.C.D) or IPv6 address (X:X:X:X) of the TACACS+ server host.
	port number	(OPTIONAL) Enter the keyword <code>port</code> then a number as the port to be used by the TACACS+ server. The range is from zero (0) to 65535. The default is 49 .
	timeout seconds	(OPTIONAL) Enter the keyword <code>timeout</code> then the number of seconds the switch waits for a reply from the TACACS+ server. The range is from 0 to 1000. The default is 10 seconds .
	key key	(OPTIONAL) Enter the keyword <code>key</code> then a string up to 42 characters long as the authentication key. This authentication key must match the key specified in the <code>tacacs-server key</code> for the TACACS+ daemon.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information

To list multiple TACACS+ servers to be used by the `aaa authentication login` command, configure this command multiple times.

If you are not configuring the switch as a TACACS+ server, you do not need to configure the `port`, `timeout` and `key` optional parameters. If you do not configure a key, the key assigned in the `tacacs-server key` command is used.

Related Commands [aaa authentication login](#) — specifies the login authentication method.



[tacacs-server key](#) — configures a TACACS+ key for the TACACS server.

tacacs-server key

Configure a key for communication between a TACACS+ server and a client.

Syntax	<code>tacacs-server key [encryption-type] key</code>	
	To delete a key, use the <code>no tacacs-server key key</code> command.	
Parameters	encryption-type	(OPTIONAL) Enter either zero (0) or 7 as the encryption type for the key entered. The options are: • 0 is the default and means the key is not encrypted and stored as clear text. • 7 means that the key is encrypted and hidden.
	key	Enter a text string, up to 42 characters long, as the clear text password. Leading spaces are ignored.
Defaults	Not configured.	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.
Usage Information	The key configured with this command must match the key configured on the TACACS+ daemon.	

timeout login response

Specify how long the software waits for the login input (for example, the user name and password) before timing out.

Syntax	<code>timeout login response seconds</code>	
	To return to the default values, use the <code>no timeout login response</code> command.	
Parameters	seconds	Enter a number of seconds the software waits before logging you out. The range is: • VTY: the range is from 1 to 30 seconds, the default is 30 seconds. • Console: the range is from 1 to 300 seconds, the default is 0 seconds (no timeout). • AUX: the range is from 1 to 300 seconds, the default is 0 seconds (no timeout).
Defaults	See the defaults settings shown in <i>Parameters</i> .	
Command Modes	LINE	
Supported Modes	All Modes	



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.
Usage Information	The software measures the period of inactivity defined in this command as the period between consecutive keystrokes. For example, if your password is "password" you can enter "p" and wait 29 seconds to enter the next letter.	

SSH Server and SCP Commands

The Dell Networking OS supports secure shell (SSH) protocol versions 1.5 and 2.0. SSH is a protocol for secure remote login over an insecure network. SSH sessions are encrypted and use authentication.

enable password

Change the password for the `enable` command.

Syntax	<pre>enable password [level level] [encryption-type] password</pre> To delete a password, use the <code>no enable password [encryption-type] password [level level]</code> command.
--------	--

Parameters	level level	(OPTIONAL) Enter the keyword <code>level</code> followed by a number as the level of access. The range is from 1 to 15.
	encryption-type	(OPTIONAL) Enter the number 7 or 0 as the encryption type. Enter a 7 followed by a text string as the hidden password. The text string must be a password that was already encrypted by a Dell Networking router. Use this parameter only with a password that you copied from the <code>show running-config</code> file of another Dell Networking router.
	password	Enter a text string, up to 32 characters long, as the clear text password.

Defaults No password is configured. *level* = **15**.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Use this command to define a password for a level.

Passwords must meet the following criteria:

- Start with a letter, not a number.



- Passwords can have a regular expression as the password. To create a password with a regular expression in it, use CNTL + v prior to entering regular expression. For example, to create the password abcd]e, you type “abcd CNTL v]e”. When the password is created, you do not use the CNTL + v key combination and enter “abcd]e”.



NOTE: The question mark (?) and the tilde (~) are not supported characters.

Related Commands [show running-config](#) — views the current configuration.

enable restricted

Allows Dell Networking technical support to access restricted commands.

Syntax	enable restricted [<i>encryption-type</i>] password To disallow access to restricted commands, use the no enable restricted command.	
Parameters	<i>encryption-type</i>	(OPTIONAL) Enter the number 7 as the encryption type. Enter 7 followed a text string as the hidden password. The text string must be a password that was already encrypted by a Dell Networking router. Use this parameter only with a password that you copied from the show running-config file of another Dell Networking router.
	<i>password</i>	Enter a text string, up to 32 characters long, as the clear text password.
Command Modes	Not configured.	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	Only Dell Networking Technical Support staff use this command.	

service password-encryption

Encrypt all passwords configured in Dell Networking OS.

Syntax	service password-encryption To store new passwords as clear text, use the no service password-encryption command.	
Defaults	Enabled.	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.



Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information



CAUTION: Encrypting passwords with this command does not provide a high level of security. When the passwords are encrypted, you cannot return them to plain text unless you re-configure them. To remove an encrypted password, use the `no password password` command.

To keep unauthorized people from viewing passwords in the switch configuration file, use the `service password-encryption` command. This command encrypts the clear-text passwords created for user name passwords, authentication key passwords, the privileged command password, and console and virtual terminal line access passwords.

To view passwords, use the `show running-config` command.

show ip ssh

Display information about established SSH sessions.

Syntax	<code>show ip ssh</code>
Command Modes	- EXEC - EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show ip ssh
SSH server                : disabled.
SSH server version        : v1 and v2.
Password Authentication    : enabled.
Hostbased Authentication  : disabled.
RSA Authentication        : disabled.
Dell#
```

Related Commands [show ip ssh client-pub-keys](#) — displays the client-public keys.

show ip ssh client-pub-keys

Displays the client public keys used in host-based authentication

Syntax	<code>show ip ssh client-pub-keys</code>
Defaults	none
Command Modes	EXEC
Supported Modes	All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information This command displays the contents of the `flash://ADMIN_DIRssh/knownhosts` file.

Example

```
Dell#show ip ssh client-pub-keys

poclab4,123.12.1.123 ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAIEAox/
QQp8xYhzOxn07yh4VGPAoUfgKoieTHO9G4sNV+ui
+DWEc3cgYAcU5LailMU2ODrzhCwyDNp05tKBu3tReG1
o8AxLi6+S4hyEMqHzkzBFNVqHzpQc
+Rs4p2urzV0F4pRKnaXdHf3Lk4D460HZRhhVrxqeNxDpEnWIMPJi0
ds= ashwani@poclab4

Dell#
```

show ip ssh rsa-authentication

Displays the authorized-keys for the RSA authentication.

Syntax `show ip ssh rsa-authentication {my-authorized-keys}`

Parameters

my-authorized-keys Display the RSA authorized keys.

Defaults none

Command Modes EXEC

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information This command displays the contents of the `flash:/ADMIN_DIR/ssh/authorized-keys.username` file.

Example

```
Dell#show ip ssh rsa-authentication my-authorized-keys
ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAIEAyB17l4gFp4r2DRHIvMc1VZd0Sg5GQxRV1y1X1JOMeO6Nd0WuYyzrQMM
4qJAoBwtneOXfLBcHF3V2hcMIqaZN+CRcnw/
zCmInCf0+qVTdloofsea5r09kS0xTp0CNfHXZ3NuGCq9Ov33m9+U9tMwhS8vy8AVxdH4x4km3c3t5Jvc=
freedom@poclab4
Dell#
```

show users

Allows you to view information on all users logged in to the switch.

Syntax `show users [all]`

Parameters

all (OPTIONAL) Enter the keyword `all` to view all terminal lines in the switch.

Command Modes EXEC Privilege



Supported Modes All Modes

Command History

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following describes the `show user` command shown in the following example.

Field	Description
(untitled)	Indicates with an asterisk (*) which terminal line you are using.
Line	Displays the terminal lines currently in use.
User	Displays the user name of all users logged in.
Host(s)	Displays the terminal line status.
Location	Displays the IP address of the user.

Example

```
Dell# show users
Authorization Mode:  role or privilege
Line               User           Role           Priv Host(s)
Location
*  0  console 0
   2  vty 0      admin          unassigned     1  idle
10.16.127.35
   3  vty 1      ad             unassigned     15 idle
10.16.127.145
   4  vty 2      ad1            sysadmin       1  idle
10.16.127.141
   5  vty 3      ad1            sysadmin       1  idle
10.16.127.145
   6  vty 4      admin          unassigned     1  idle
10.16.127.141
   7  vty 5      ad             unassigned     15 idle
10.16.127.141
Dell#
```

Related Commands [ssh](#)— enables a user.

ssh

Open an SSH connection specifying the host name, username, port number and version of the SSH client.

Dell Networking OS supports both inbound and outbound SSH sessions using IPv4 addressing. Inbound SSH supports accessing the system through the management interface as well as through a physical Layer 3 interface.

Syntax `ssh {hostname | ipv4 address} [-l username | -p port-number|-v {1|2}]`

Parameters

hostname	(OPTIONAL) Enter the IP address or the host name of the remote device.
ipv4 address	(OPTIONAL) Enter the IP address in dotted decimal format A.B.C.D.
-l username	(OPTIONAL) Enter the keyword <code>-l</code> followed by the user name used in this SSH session. The default is the user name of the user associated with the terminal.
-p port-number	(OPTIONAL) Enter the keyword <code>-p</code> followed by the port number. The range is from 1 to 65536. The default is 22 .
-v {1 2}	(OPTIONAL) Enter the keyword <code>-v</code> then the SSH version 1 or 2. The default is the version from the protocol negotiation.



Defaults	As shown in the <i>Parameters</i> section.					
Command Modes	EXEC Privilege					
Supported Modes	All Modes					
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>8.3.17.0</td><td>Supported on the M I/O Aggregator.</td></tr></table>	Version	Description	8.3.17.0	Supported on the M I/O Aggregator.	
Version	Description					
8.3.17.0	Supported on the M I/O Aggregator.					

Example

```
Dell#ssh 10.16.151.48 -l anvltest

Trying 10.16.151.48...
01:18:16: %STKUNIT0-M:CP %SEC-5-SSH_USAGE: Initiated SSH Client v2 (FIPS
Disabled) to anvltest@10.16.151.48 by default from console
anvltest@10.16.151.48's password:
Last login: Thu Jan  5 00:17:47 2012 from login-maa-101
[anvltest@dt-maa-linux-1 ~]# exit
logout
Dell#
```

username

Establish an authentication system based on user names.

Syntax

```
username name access-list-name [nopassword | {password | secret}
[encryption-type] password] [privilege level]
```

If you do not want a specific user to enter a password, use the `nopassword` option.

To delete authentication for a user, use the `no username name` command.

Parameters

<i>name</i>	Enter a text string for the name of the user up to 63 characters.
<i>access-list-name</i>	Enter the name of a configured access control list (either an IP access control list or MAC access control list).
<i>nopassword</i>	Enter the keyword <code>nopassword</code> to specify that the user should not enter a password.
<i>password</i>	Enter the keyword <code>password</code> followed by the <i>encryption-type</i> or the password.
<i>secret</i>	Enter the keyword <code>secret</code> followed by the <i>encryption-type</i> or the password.
<i>encryption-type</i>	Enter an encryption type for the password that you enter. 0 directs Dell Networking OS to store the password as clear text. It is the default encryption type when using the <code>password</code> option. 7 to indicate that a password encrypted using a DES hashing algorithm follows. This encryption type is available with the <code>password</code> option only. 5 to indicate that a password encrypted using an MD5 hashing algorithm follow. This encryption type is available with the <code>secret</code> option only, and is the default encryption type for this option.
<i>password</i>	Enter a string up to 32 characters long.
<i>privilege level</i>	Enter the keyword <code>privilege</code> then a number from zero (0) to 15.
<i>secret</i>	Enter the keyword <code>secret</code> then the encryption type.



Defaults	The default encryption type for the <code>password</code> option is 0 . The default encryption type for the <code>secret</code> option is 0 .					
Command Modes	CONFIGURATION					
Supported Modes	All Modes					
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>8.3.17.0</td><td>Supported on the M I/O Aggregator.</td></tr></table>	Version	Description	8.3.17.0	Supported on the M I/O Aggregator.	
Version	Description					
8.3.17.0	Supported on the M I/O Aggregator.					
Usage Information	To view the defined user names, use the <code>show running-config user</code> command.					
Related Commands	service password-encryption — specifies a password for users on terminal lines. show running-config — views the current configuration.					



Stacking Commands

Stacking is supported on an Aggregator only on the 40GbE ports on the base module. Stacking is limited to two Aggregators in the same chassis in a single stack. Up to three stacks are supported in an M1000e chassis.

Stacking provides a single point of management and NIC teaming for high availability and higher throughput. To configure an Aggregator stack, you must use the CLI.

The stacking commands are always available and operational, whether or not an Aggregator has a stacking module inserted. You can use the commands to pre-configure an Aggregator, so that the configuration settings are invoked when the Aggregator is attached to other Aggregator blades.

For more information about using the Aggregator stacking feature, refer to the *Stacking Aggregators* chapter in the Dell Networking OS Configuration Guide for the M I/O Aggregator.

You can use the following commands to manage a stack of Aggregator I/O modules:

- [power-cycle stack-unit](#)
- [reset stack-unit](#)
- [show system stack-ports](#)
- [show system stack-unit iom-mode](#)
- [show system stack-unit stack-group](#)
- [stack-unit iom-mode](#)

power-cycle stack-unit

To hard reset any stack unit including master unit.

Syntax	<code>power-cycle stack-unit <i>unit-number</i></code>	
Parameter	Unit number	The unit number ranges from 0 to 5.
Defaults	None	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.6.(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	This command is supported on the M I/O, FN410S, and FN410T Aggregators.	



This command is used to reset the stack-unit. The master unit can also be power cycled using this command.

reset stack-unit

Reset any designated stack member except the management unit (master unit).

Syntax `reset stack-unit 0-5 hard`

Parameters

0-5	Enter the stack member unit identifier of the stack member to reset.
hard	Reset the stack unit if the unit is in a problem state.

Defaults none

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.6.(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information This command is supported on the M I/O, FN410S, and FN410T Aggregators

Resetting the management unit is not allowed and an error message displays if you try to do so. Resetting is a soft reboot, including flushing the forwarding tables.

You can run this command directly on the stack standby unit (Standby Master) to reset the standby. You cannot reset any other unit from the standby unit

Example

```
Dell#show system brief
Stack MAC : 00:1e:c9:f1:00:9b
-- Stack Info --
Unit      UnitType      Status      ReqTyp      CurTyp      Version      Ports
-----
0         Management    online      I/O-Aggregator I/O-Aggregator 8-3-17-46    56
1         Standby       online      I/O-Aggregator I/O-Aggregator 8-3-17-46    56
2         Member       not present
3         Member       not present
4         Member       not present
5         Member       not present
Dell#
Dell#reset stack-unit 0 >>>Resetting master not allowed
% Error: Reset of master unit is not allowed.
Dell#
Dell#reset stack-unit 1
Dell#01:02:00: %STKUNIT0-M:CP %CHMGR-5-STACKUNIT_RESET: Stack unit 1 being reset
01:02:00: %STKUNIT0-M:CP %IFMGR-1-DEL_PORT: Removed port: Te 1/1-32,41-56
01:02:00: %STKUNIT0-M:CP %CHMGR-2-STACKUNIT_DOWN: Stack unit 1 down - reset
01:02:00: %STKUNIT1-S:CP %IFMGR-1-DEL_PORT: Removed port: Te 1/1-32,41-56
01:02:05: %I/O-Aggregator:0 %IFAGT-5-STACK_PORT_LINK_DOWN: Changed stack port
state to down: 0/10
01:02:11: %STKUNIT0-M:CP %POLLMGR-2-ALT_STACK_UNIT_STATE: Alternate Stack-unit is
not present
```



```
Dell#01:02:12: %STKUNIT0-M:CP %CHMGR-2-STACKUNIT_DOWN: Stack unit 1 down - card removed
```

Related Commands [reload](#)—reboots the system.

show system stack-ports

Display information about the stacking ports on all switches in the M I/O Aggregator switch stack..

Syntax `show system stack-ports [status | topology]`

Parameters

status	(OPTIONAL) Enter the keyword <code>status</code> to display the command output without the Connection field.
topology	(OPTIONAL) Enter the keyword <code>topology</code> to limit the table to just the Interface and Connection fields.

Defaults none

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information The following describes the `show interfaces` command shown in the following example.

Field	Description
Topology	Lists the topology of stack ports connected: Ring, Daisy chain, or Standalone.
Interface	The unit/port ID of the connected stack port on this unit.
Link Speed	Link Speed of the stack port (10 or 40) in Gb/s.
Admin Status	The only currently listed status is Up.
Connection	The stack port ID to which this unit's stack port is connected.

Example

```
Dell# show system stack-ports
Topology: Ring
```

Interface	Connection	Link Speed (Gb/s)	Admin Status	Link Status	Trunk Group
0/33		40	up	down	
0/37	1/37	40	up	up	
1/33		40	up	down	
1/37	0/37	40	up	up	

```
Dell#
```

Example (Status)

```
Dell# show system stack-ports status
Topology: Daisy chain
Interface Link Speed Admin Link Trunk
```



	(Gb/s)	Status	Status	Group
0/33	40	up	down	
0/37	40	up	up	
1/33	40	up	down	
1/37	40	up	up	

Example (Topology) Dell# show system stack-ports topology
Topology: Daisy chain

Interface	Connection	Trunk	Group
-----------	------------	-------	-------

0/33			
0/37	1/37		
1/33			
1/37	0/37		
Dell	#		

Related Commands [power-cycle stack-unit](#)—resets the designated stack member.

[show diag](#)— displays the data plane or management plane input and output statistics of the designated component of the designated stack member.

[show system](#)—displays the current status of all stack members or a specific member.

show system stack-unit fanout

Displays the current 40GbE ports configured in fanout mode.

Syntax show system stack-unit <unit-number> fanout[configured]

Parameters *unit-number* <0–5> Enter the number of the member stack unit. The range is from 0 to 5.

Defaults none

Command Modes . EXEC Privilege

Supported Modes All Modes

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show system stack-unit 0 fanout ?
configured Configured fan out ports
Dell#show system stack-unit 0 fanout configured ?
| Pipe through a command
<cr>
Dell#show system stack-unit 0 fanout configured
Configured fan out ports in stack-unit 0
Configured Next Boot
33          33
37          37
41          41
45          45
Dell#
```



show system stack-unit iom-mode

Displays the current iom-mode (stack/standalone) and the mode configured after next reboot.

Syntax `show system stack-unit unit-number iom-mode`

Parameters `unit number <0-5>` Enter the number of the member stack unit. The range is from 0 to 5.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.6(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage information This command is supported on the M I/O, FN410S, and FN410T Aggregators

Example

```
Dell#show system stack-unit all iom-mode ?
|                               Pipe through a command
<cr>
Dell#show system stack-unit all iom-mode
Unit      Boot-Mode      Next-Boot
-----
0          stack           stack
1          stack           stack
2          stack           stack
3          stack           stack
4          Not Present
5          Not Present
Dell#
```

show system stack-unit iom-uplink-speed

Display the uplink speed of the LAG bundles configured on the Flex IO modules installed on the Aggregator.

Syntax `show system stack-unit unit-number iom-uplink-speed`

Parameters `unit number <0-5>` Enter the number of the member stack unit. The range is from 0 to 5.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History


Version	Description
9.3(0.0)	Introduced on the M I/O Aggregator

Usage Information The value under the Boot-speed field in the output of the show command indicates the uplink speed that is currently effective on the LAG bundles, whereas the value under the Next-Boot field indicates the uplink speed that is applicable for the LAG bundle after the next reboot of the switch.

Example

```
Dell# show system stack-unit 0 iom-uplink-speed
Unit      Boot-speed      Next-Boot
```





show system stack-unit stack-group

Displays the stack-groups present/configured for a M I/O Aggregator stack unit.

Syntax	show system stack-unit <i>unit-number</i> stack-group [configured]	
Parameters	<i>unit number <0-5></i>	Enter the number of the member stack unit. The range is from 0 to 5.
Defaults	none	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show system stack-unit 0 stack-group ?
configured          Configured stack groups
|                   Pipe through a command
<cr>
Dell#show system stack-unit 0 stack-group configured
Configured stack groups in stack-unit 0
Dell#show system stack-unit 0 stack-group
Stack group Ports
-----
0                0/33
1                0/37
2                0/41
3                0/45
Dell#
```

Related Commands [reload](#)— reboots the system.

[show system](#)— displays the current status of all stack members or a specific member.

stack-unit iom-mode

Toggle the Aggregator operating mode between programmable multiplex, standalone, stack, and VLT modes.

Syntax	stack-unit < <i>unit-number</i> > iom-mode [programmable-mux stack standalone vlt]	
Parameters	<i>unit number <0-5></i>	Enter the number of the member stack unit. The range is from 0 to 5.
	<i>programmable-mux</i>	Enable programmable multiplex mode.
	<i>stack</i>	Enable stack mode.
	<i>standalone</i>	Enable stand-alone mode.



	vlt	Enable virtual link trunking mode.
Defaults	standalone	
Command Modes	· CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.6.(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	This command is supported on the M I/O, FN410S, and FN410T Aggregators.	
Example	<pre>Dell(conf)#stack-unit 0 iom-mode stack % You are about to stack your IOA module, please reload the IOA and then plug in the stacking cable for the changes to take effect. Dell(conf)# Dell#</pre>	
Related Commands	reload — Reboots the operating system. show system — displays the current status of all stack members or a specific member.	

stack-unit iom-mode uplink-speed

Specify the uplink speed of the member interfaces in a LAG bundle for the Aggregator that operates in standalone, stacking, or VLT mode to be 40 GbE. By default, the uplink speed of the LAG bundle is set as 10 GbE.

Syntax `stack-unit unit-number iom-mode {stack | standalone | vlt} uplink-speed 40G`
To restore the default uplink speed of the LAG bundle, which is 10 GbE, use the `stack-unit unit-number iom-mode {stack | standalone | vlt}` command.

Parameters	<i>unit number <0-5></i>	Enter the number of the member stack unit. The range is from 0 to 5.
	<i>iom-mode</i>	Denotes the operating mode of the I/O Aggregator.
	stack	Specify that the uplink speed of the member interfaces in a LAG bundle applies for the Aggregator in stacking mode
	standalone	Specify that the uplink speed of the member interfaces in a LAG bundle applies for the Aggregator in standalone mode
	vlt	Specify that the uplink speed of the member interfaces in a LAG bundle applies for the Aggregator in VLT mode
	uplink-speed 40G	Set the uplink speed of the member or child interfaces of the LAG bundle to function at 40 Gigabit Ethernet per second

Command Modes CONFIGURATION

Supported Modes All Modes



Command History	Version	Description
	9.3(0.0)	Supported on the M I/O Aggregator
Usage Information	This functionality to set the uplink speed is available from the CMC interface when the I/O Aggregator functions as a simple MUX or a VLT node with all of the uplink interfaces configured to be member links in the same LAG bundle. You cannot configure the uplink speed to be set as 40 GbE by default if the Aggregator functions in programmable MUX mode with multiple uplink LAG interfaces or in stacking mode because CMC is not involved with configuration of parameters when the Aggregator operates in either of these modes with uplink interfaces being part of different LAG bundles. When you configure the native mode to be 40 GbE, the CMC sends a notification to the IOA to set the default internal working of all of the ports to be 40 GbE after the reload of the switch is performed. After you configure the native mode that denotes the uplink speed of the module ports to be 40 GbE, you must enter the <code>reboot</code> command (not pressing the Reset button, which causes the factory default settings to be applied when the device comes up online) from the CMC to cause the configuration of the uplink speed to be effective.	

stack-unit priority

Configure the ability of a switch to become the management unit of a stack.

Syntax	<code>stack-unit stack-number priority 1-14</code>	
Parameters	<i>stack-number</i>	Enter the stack member unit identifier.
	<i>1-14</i>	This preference parameter allows you to specify the management priority of one backup switch over another, with 0 the lowest priority and 14 the highest. The switch with the highest priority value is chosen to become the management unit if the active management unit fails or on the next reload.
Defaults	0	
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.6.(0.0)	Supported on the FN I/O Aggregator.
	9.3(0.0)	Supported on the M I/O Aggregator.
Usage Information	This command is supported on the M I/O, FN410S, and FN410T Aggregators.	
Related Commands	• reload – reboots Dell Networking Operating System (OS). • show system – displays the status of all stack members or a specific member.	



stack-unit renumber

Change the stack member ID of any stack member or a stand-alone unit.

Syntax `stack-unit 0-5 renumber 0-5`

Parameters

0-5	The first instance of this value is the stack member unit identifier, from 0 to 5, of the switch that you want add to the stack. The range is from 0 to 5. The second instance of this value is the desired new unit identifier number.
------------	---

Defaults none

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.6(0.0)	Supported on the FN I/O Aggregator.
9.3(0.0)	Supported on the M I/O Aggregator.

Usage Information

This command is supported on the FN410S and the FN410T Aggregators.

You can renumber any switch, including the management unit or a stand-alone unit.

You cannot renumber a unit to a number of an active member in the stack.

When executing this command on the master, the stack reloads. When the members are renumbered, only that specific unit is reset and comes up with the new unit number.

Example

```
Dell#stack-unit 5 renumber 4
```

Renumbering will reset the unit.
Warning: Interface configuration for current unit will be lost!
Proceed to renumber [confirm yes/no]:

Related Commands

- [reload](#) – reboots Dell Networking Operating System (OS).
- [reset stack-unit](#) – resets the designated stack member.
- [show system](#) – displays the current status of all stack members or a specific member.



Storm Control

The Dell Networking operating software storm control feature allows you to limit or suppress traffic during a traffic storm.

Important Points to Remember

- Interface commands can only be applied on physical interfaces (virtual local area networks [VLANs] and link aggregation group [LAG] interfaces are not supported).
- An INTERFACE-level command only supports storm control configuration on ingress.
- An INTERFACE-level command overrides any CONFIGURATION-level ingress command for that physical interface, if both are configured.
- You can apply the CONFIGURATION-level storm control commands at ingress or egress and are supported on all physical interfaces.
- When storm control is applied on an interface, the percentage of storm control applied is calculated based on the advertised rate of the line card. It is not based on the speed setting for the line card.
- Do not apply per-VLAN quality of service (QoS) on an interface that has storm control enabled (either on an interface or globally).
- When you enable broadcast storm control on an interface or globally on ingress, and DSCP marking for a DSCP value 1 is configured for the data traffic, the traffic goes to queue 1 instead of queue 0.
- Similarly, if you enable unicast storm control on an interface or globally on ingress, and DSCP marking for a DSCP value 2 is configured for the data traffic, the traffic goes to queue 2 instead of queue 0.

 **NOTE: Bi-directional traffic (unknown unicast and broadcast) along with egress storm control causes the configured traffic rates split between the involved ports. The percentage of traffic that each port receives after the split is not predictable. These ports can be in the same/different port pipes or the same/different line cards.**

 **NOTE: The policy discard drop counters are common across storm-control drops, ACL drops and QoS drops. Therefore, if your configuration includes ACL and QoS, those drops are also computed and displayed in the policy discard drops counter field along with storm-control drops. The packets dropped by the storm control feature can be monitored by viewing the value of the Policy Discard Drops field of the output of the `show hardware stack-unit 0 drops` command.**

io-aggregator broadcast storm-control

Rate-limit the traffic storm to 1 Gbps.

Syntax	<pre>io-aggregator broadcast storm-control</pre> To disable storm control, use the <code>no io-aggregator broadcast storm-control</code> command.
Defaults	Enabled
Command Modes	• CONFIGURATION

Supported Modes	Standalone-Mux (SMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.
Usage Information	This command is not available in PMUX mode.	

show io-aggregator broadcast storm-control status

Shows if storm control is enabled or disabled. If enabled, displays information on the rate limit value.

Syntax	<code>show io-aggregator broadcast storm-control status</code>	
Command Modes	EXEC Privilege	
Supported Modes	Standalone-Mux (SMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Example	<pre>Dell#show io-aggregator broadcast storm-control status Storm-Control Enabled Broadcast Traffic limited to 1000 Mbps Dell#</pre>	

show storm-control unknown-unicast

Display the storm control unknown-unicast configuration.

Syntax	<code>show storm-control unknown-unicast [<i>interface</i>]</code>	
Parameters	<i>interface</i>	(OPTIONAL) Enter one of the following interfaces to display the interface specific storm control configuration: - For a 1-Gigabit Ethernet interface, enter the keyword <code>GigabitEthernet</code> then y the slot/port information. - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. - For a 40-Gigabit Ethernet interface, enter the keyword <code>fortyGigE</code> then the slot/ port information.
Defaults	none	
Command Modes	EXEC	



- EXEC Privilege

Supported Modes Programmable-Mux (PMUX)

Command History This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following is a list of the Dell Networking OS version history for this command.

Version	Description
9.2(0.0)	Introduced on the M I/O Aggregator.

storm-control broadcast (Interface)

Configure the percentage of broadcast traffic allowed on an interface.

Syntax `storm-control broadcast [packets_per_second in]`
 To disable broadcast storm control on the interface, use the `no storm-control broadcast [packets_per_second in]` command.

Parameters

<code>packets_per_second</code>	Enter the packets per second of broadcast traffic allowed into the network. The range is from 0 to 33554368.
---------------------------------	--

Command Modes INTERFACE (conf-if-interface-slot/port)

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Introduced on the M I/O Aggregator.

storm-control multicast (Interface)

Configure the percentage of multicast traffic allowed on the interface.

Syntax `storm-control multicast packets_per_second in`
 To disable multicast storm control on the interface, use the `no storm-control multicast packets_per_second in` command.

Parameters

<code>packets_per_second</code>	Enter the packets per second of broadcast traffic allowed into the network. The range is from 0 to 33554368.
---------------------------------	--

Command Modes INTERFACE (conf-if-interface-slot/port)

Supported Modes Programmable-Mux (PMUX)



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.

storm-control unknown-unicast (Interface)

Configure percentage of unknown-unicast traffic allowed on the interface.

Syntax `storm-control unknown-unicast [packets_per_second in]`
 To disable unknown-unicast storm control on the interface, use the `no storm-control unknown-unicast [packets_per_second in]` command.

Parameters

<i>packets_per_second</i>	Enter the packets per second of broadcast traffic allowed into the network. The range is from 0 to 33554431.
---------------------------	--

Command Modes INTERFACE (conf-if-interface-slot/port)

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Introduced on the M I/O Aggregator.



System Time

The commands in this chapter configure time values on the system, either using the Dell Networking OS, the hardware, or using the network time protocol (NTP). With NTP, the switch can act only as a client to an NTP clock host.

For more information, refer to the **Network Time Protocol** section of the *Management* chapter in the *Dell PowerEdge M I/O Aggregator Configuration Guide*.

The NTP commands are:

- [calendar set](#)
- [ntp server](#)
- [show calendar](#)
- [show clock](#)
- [clock read-calendar](#)
- [clock set](#)
- [clock summer-time date](#)
- [clock summer-time recurring](#)
- [clock timezone](#)
- [clock update-calendar](#)

calendar set

Set the time and date for the switch hardware clock.

Syntax	calendar set <i>time month day year</i>	
Parameters	<i>time</i>	Enter the time in hours:minutes:seconds. For the hour variable, use the 24-hour format; for example, 17:15:00 is 5:15 pm.
	<i>month</i>	Enter the name of one of the 12 months in English. You can enter the name of a day to change the order of the display to time day month year.
	<i>day</i>	Enter the number of the day. The range is from 1 to 31. You can enter the name of a month to change the order of the display to <i>time day month year</i> .
	<i>year</i>	Enter a four-digit number as the year. The range is from 1993 to 2035.
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.



Usage Information	You can change the order of the month and day parameters to enter the time and date as time day month year. In the switch, the hardware clock is separate from the software and is called the calendar. This hardware clock runs continuously. After the hardware clock (the calendar) is set, the operating system automatically updates the software clock after system bootup. You cannot delete the hardware clock (calendar). To manually update the software with the hardware clock, use the <code>clock read-calendar</code> command.
Example	<pre>Dell#calendar set 08:55:00 june 18 2006 Dell#</pre>
Related Commands	clock read-calendar — sets the software clock based on the hardware clock. clock set — sets the software clock. clock update-calendar — sets the hardware clock based on the software clock. show clock — displays the clock settings.

clock read-calendar

Set the software clock on the switch from the information set in hardware clock (calendar).

Syntax	<code>clock read-calendar</code>	
Defaults	Not configured.	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Usage Information	In the switch, the hardware clock is separate from the software and is called the calendar. This hardware clock runs continuously. After the hardware clock (the calendar) is set, the operating system automatically updates the software clock after system bootup. You cannot delete this command (there is not a <code>no</code> version of this command).
--------------------------	--

clock set

Set the software clock in the switch.

Syntax	<code>clock set time month day year</code>
---------------	--



Parameters	<i>time</i>	Enter the time in hours:minutes:seconds. For the hour variable, use the 24-hour format; example, 17:15:00 is 5:15 pm.
	<i>month</i>	Enter the name of one of the 12 months, in English. You can enter the number of a day and change the order of the display to <i>time day month year</i> .
	<i>day</i>	Enter the number of the day. The range is from 1 to 31. You can enter the name of a month to change the order of the display to <i>time month day year</i> .
	<i>year</i>	Enter a four-digit number as the year. The range is from 1993 to 2035.
Defaults	Not configured.	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	You can change the order of the <i>month</i> and <i>day</i> parameters to enter the time and date as <i>time day month year</i> . You cannot delete the software clock.	
	The software clock runs only when the software is up. The clock restarts, based on the hardware clock, when the switch reboots.	
	Dell Networking recommends using an outside time source, such as NTP, to ensure accurate time on the switch.	
Example	<pre>Dell#clock set 12:11:00 21 may 2012 Dell#</pre>	

clock summer-time date

Set a date (and time zone) on which to convert the switch to daylight saving time on a one-time basis.

Syntax	<pre>clock summer-time <i>time-zone</i> date <i>start-month</i> <i>start-day</i> <i>start-year</i> <i>start-time</i> <i>end-month</i> <i>end-day</i> <i>end-year</i> <i>end-time</i> [<i>offset</i>]</pre> To delete a daylight saving time zone configuration, use the <code>no clock summer-time</code> command.
--------	---

Parameters	<i>time-zone</i>	Enter the three-letter name for the time zone. This name is displayed in the show clock output.
	<i>start-month</i>	Enter the name of one of the 12 months in English. You can enter the name of a day to change the order of the display to <i>time day month year</i> .
	<i>start-day</i>	Enter the number of the day. The range is from 1 to 31. You can enter the name of a month to change the order of the display to <i>time day month year</i> .
	<i>start-year</i>	Enter a four-digit number as the year. The range is from 1993 to 2035.



<i>start-time</i>	Enter the time in hours:minutes. For the hour variable, use the 24-hour format; example, 17:15 is 5:15 pm.
<i>end-day</i>	Enter the number of the day. The range is from 1 to 31. You can enter the name of a month to change the order of the display to time day month year.
<i>end-month</i>	Enter the name of one of the 12 months in English. You can enter the name of a day to change the order of the display to time day month year.
<i>end-time</i>	Enter the time in hours:minutes. For the hour variable, use the 24-hour format; example, 17:15 is 5:15 pm.
<i>end-year</i>	Enter a four-digit number as the year. The range is from 1993 to 2035.
<i>offset</i>	(OPTIONAL) Enter the number of minutes to add during the summer-time period. The range is from 1 to 1440. The default is 60 minutes .

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Related Commands [clock summer-time recurring](#) — sets a date (and time zone) on which to convert the switch to daylight saving time each year.

[show clock](#) — displays the current clock settings.

clock summer-time recurring

Set the software clock to convert to daylight saving time on a specific day each year.

Syntax `clock summer-time time-zone recurring [start-week start-day start-month start-time end-week end-day end-month end-time [offset]]`

To delete a daylight saving time zone configuration, use the `no clock summer-time` command.

Parameters

<i>time-zone</i>	Enter the three-letter name for the time zone. This name is displayed in the <code>show clock</code> output. You can enter up to eight characters.
<i>start-week</i>	(OPTIONAL) Enter one of the following as the week that daylight saving begins and then enter values for start-day through end-time: <code>week-number</code>: Enter a number from 1 to 4 as the number of the week in the month to start daylight saving time. <code>first</code>: Enter this keyword to start daylight saving time in the first week of the month. <code>last</code>: Enter this keyword to start daylight saving time in the last week of the month.



<i>start-day</i>	Enter the name of the day that you want daylight saving time to begin. Use English three letter abbreviations; for example, Sun, Sat, Mon, and so on. The range is from Sun to Sat.
<i>start-month</i>	Enter the name of one of the 12 months in English.
<i>start-time</i>	Enter the time in hours:minutes. For the hour variable, use the 24-hour format; example, 17:15 is 5:15 pm.
<i>end-week</i>	Enter the one of the following as the week that daylight saving ends: <code>week-number</code>: enter a number from 1 to 4 as the number of the week to end daylight saving time. <code>first</code>: enter the keyword <code>first</code> to end daylight saving time in the first week of the month. <code>last</code>: enter the keyword <code>last</code> to end daylight saving time in the last week of the month.
<i>end-day</i>	Enter the weekday name that you want daylight saving time to end. Enter the weekdays using the three letter abbreviations; for example Sun, Sat, Mon, and so on. The range is from Sun to Sat.
<i>end-month</i>	Enter the name of one of the 12 months in English.
<i>end-time</i>	Enter the time in hours:minutes:seconds. For the hour variable, use the 24-hour format; example, 17:15:00 is 5:15 pm.
<i>offset</i>	(OPTIONAL) Enter the number of minutes to add during the summer-time period. The range is from 1 to 1440. The default is 60 minutes .

Defaults	Not configured.
Command Modes	CONFIGURATION
Supported Modes	All Modes
Command History	

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Related Commands	clock summer-time date — sets a date (and time zone) on which to convert the switch to daylight saving time on a one-time basis. show clock — displays the current clock settings.
------------------	---

clock timezone

Configure a timezone for the switch.

Syntax	<pre>clock timezone <i>timezone-name</i> <i>offset</i></pre> To delete a timezone configuration, use the <code>no clock timezone</code> command.
--------	---

Parameters	<i>timezone-name</i> Enter the name of the timezone. You cannot use spaces.
------------	--



offset

Enter one of the following:

- a number from 1 to 23 as the number of hours in addition to universal time coordinated (UTC) for the timezone.
- a minus sign (-) then a number from 1 to 23 as the number of hours.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Coordinated universal time (UTC) is the time standard based on the International Atomic Time standard, commonly known as Greenwich Mean time. When determining system time, include the differentiator between UTC and your local timezone. For example, San Jose, CA is the Pacific Timezone with a UTC offset of -8.

clock update-calendar

Set the switch hardware clock based on the software clock.

Syntax `clock update-calendar`

Defaults Not configured.

Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

Usage Information Use this command only if you are sure that the hardware clock is inaccurate and the software clock is correct. You cannot delete this command (there is not a `no` form of this command).

Related Commands [calendar set](#)— sets the hardware clock.

ntp server

Configure an NTP time-serving host.

Syntax `ntp server {hostname | ipv4-address} [key keyid] [prefer] [version number]`

Parameters
ipv4-address Enter an IPv4 address (A.B.C.D).



hostname	Enter the hostname of the server.
key keyid	(OPTIONAL) Enter the keyword <code>key</code> and a number as the NTP peer key. The range is from 1 to 4294967295.
prefer	(OPTIONAL) Enter the keyword <code>prefer</code> to indicate that this peer has priority over other servers.
version number	(OPTIONAL) Enter the keyword <code>version</code> and a number to correspond to the NTP version used on the server. The range is from 1 to 3.

Defaults Not configured.

Command Modes CONFIGURATION

Supported Modes All Modes

Command History	Version	Description
	9.2(0.0)	Supported on the M I/O Aggregator.

Usage Information You can configure multiple time-serving hosts (up to 250). From these time-serving hosts, the operating system chooses one NTP host with which to synchronize.

Because many polls to NTP hosts can impact network performance, Dell Networking recommends limiting the number of hosts configured.

show calendar

Display the current date and time based on the switch hardware clock.

Syntax `show calendar`

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show calendar
12:29:34 pacific Tue May 22 2012
Dell#
```

Related Commands [show clock](#)— displays the time and date from the switch software clock.



show clock

Displays the current clock settings.

Syntax `show clock [detail]`

Parameters **detail** (OPTIONAL) Enter the keyword `detail` to view the source information of the clock.

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show clock
12:30:04.402 pacific Tue May 22 2012
Dell#
```

Example (Detail)

```
Dell#show clock detail
12:30:26.892 pacific Tue May 22 2012
Time source is RTC hardware
Summer time starts 00:00:00 UTC Wed Mar 14 2012
Summer time ends 00:00:00 pacific Wed Nov 7 2012
Dell#
```

Related Commands [clock summer-time recurring](#) — sets the software clock to convert to daylight saving time on a specific day each year.

[ntp server](#) — configures an NTP time-serving host.



Uplink Failure Detection (UFD)

Uplink failure detection (UFD) provides detection of the loss of upstream connectivity and, if you use this with network interface controller (NIC) teaming, automatic recovery from a failed link.

 **NOTE:** In Standalone, VLT, and Stacking modes, the UFD group number is 1 by default and cannot be changed.

clear ufd-disable

Re-enable one or more downstream interfaces on the switch/router that are in a UFD-Disabled Error state so that an interface can send and receive traffic.

Syntax	<code>clear ufd-disable {interface <i>interface</i> uplink-state-group <i>group-id</i>}</code>	
Parameters	interface <i>interface</i>	Specify one or more downstream interfaces. For <i>interface</i> , enter one of the following interface types: • 10 Gigabit Ethernet: <code>tengigabitethernet {<i>slot/port</i> <i>slot/port-range</i>}</code> • Port channel: <code>port-channel {<i>1-512</i> <i>port-channel-range</i>}</code> Where <i>port-range</i> and <i>port-channel-range</i> specify a range of ports separated by a dash (-) and/or individual ports/port channels in any order; for example: <code>tengigabitethernet 1/1-2,5,9,11-12 port-channel 1-3,5</code>. A comma is required to separate each port and port-range entry.
	uplink-state-group <i>group-id</i>	Re-enables all UFD-disabled downstream interfaces in the group. The valid <i>group-id</i> values are from 1 to 16.
Defaults	A downstream interface in a UFD-disabled uplink-state group is also disabled and is in a UFD-Disabled Error state.	
Command Modes	CONFIGURATION	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.
Related Commands	• downstream — assigns a port or port-channel to the uplink-state group as a downstream interface. • uplink-state-group — creates an uplink-state group and enables the tracking of upstream links.	

debug uplink-state-group

Enable debug messages for events related to a specified uplink-state group or all groups.

Syntax `debug uplink-state-group [group-id]`
To turn off debugging event messages, enter the `no debug uplink-state-group [group-id]` command.

Parameters

group-id	Enables debugging on the specified uplink-state group. The valid group-id values are from 1 to 16.
-----------------	--

Defaults none

Command Modes EXEC Privilege

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Related Commands [clear ufd-disable](#) — re-enables downstream interfaces that are in a UFD-Disabled Error state.

defer-timer

Configure a timer that prevents unwanted flapping of downstream ports when the uplink port channel goes down and comes up.

Syntax `defer-timerseconds`

Defaults 10 (Standalone mode)

Parameters

seconds	Specify the time (in seconds) to wait for the upstream port channel (LAG 128) to come back up before server ports are brought down. The range is from 1 to 120.
----------------	---

Command Modes UPLINK-STATE-GROUP

Supported Modes Standalone, Stacking, VLT

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Usage Information This command is not supported in Programmable-Mux mode.



description

Enter a text description of an uplink-state group.

Syntax `description text`

Parameters **text** Text description of the uplink-state group. The maximum length is 80 alphanumeric characters.

Defaults none

Command Modes UPLINK-STATE-GROUP

Supported Modes Programmable-Mux (PMUX)

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Example

```
Dell(conf-uplink-state-group-16)# description test
Dell(conf-uplink-state-group-16)#
```

Related Commands [uplink-state-group](#) — creates an uplink-state group and enables the tracking of upstream links.

downstream

Assign a port or port-channel to the uplink-state group as a downstream interface.

Syntax `downstream interface`

To delete an uplink-state group, enter the `no downstream interface` command.

Parameters **interface** Enter one of the following interface types:

- Fast Ethernet: `fastethernet {slot/port | slot/port-range}`
- 1 Gigabit Ethernet: `gigabitethernet {slot/port | slot/port-range}`
- 10 Gigabit Ethernet: `tengigabitethernet {slot/port | slot/port-range}`
- Port channel: `port-channel {1-512 | port-channel-range}`

Where `port-range` and `port-channel-range` specify a range of ports separated by a dash (-) and/or individual ports/port channels in any order; for example: `gigabitethernet 1/1-2,5,9,11-12 port-channel 1-3,5`. A comma is required to separate each port and port-range entry.

Defaults none

Command Modes UPLINK-STATE-GROUP

Supported Modes Programmable-Mux (PMUX)

Command History This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following is a list of the Dell Networking OS version history for this command.

Version	Description
9.2(0.0)	Introduced on the M I/O Aggregator.

Usage Information You can assign physical port or port-channel interfaces to an uplink-state group.

You can assign an interface to only one uplink-state group. Configure each interface assigned to an uplink-state group as either an upstream or downstream interface, but not both.

You can assign individual member ports of a port channel to the group. An uplink-state group can contain either the member ports of a port channel or the port channel itself, but not both.

Related Commands

- [upstream](#) — assigns a port or port-channel to the uplink-state group as an upstream interface.

downstream auto-recover

Enable auto-recovery so that UFD-disabled downstream ports in an uplink-state group automatically come up when a disabled upstream port in the group comes back up.

Syntax `downstream auto-recover`

To disable auto-recovery on downstream links, use the `no downstream auto-recover` command.

Defaults The auto-recovery of UFD-disabled downstream ports is enabled.

Command Modes UPLINK-STATE-GROUP

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Related Commands

- [downstream](#) — assigns a port or port-channel to the uplink-state group as a downstream interface.
- [uplink-state-group](#) — creates an uplink-state group and enables the tracking of upstream links.



downstream disable links

Configure the number of downstream links in the uplink-state group that are disabled if one upstream link in an uplink-state group goes down.

Syntax `downstream disable links {number | all}`

To revert to the default setting, use the `no downstream disable links` command.

Parameters

<i>number</i>	Enter the number of downstream links to be brought down by UFD. The range is from 1 to 1024.
all	Brings down all downstream links in the group.

Defaults

No downstream links are disabled when an upstream link in an uplink-state group goes down.

Command Modes UPLINK-STATE-GROUP

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Usage Information

A user-configurable number of downstream interfaces in an uplink-state group are put into a link-down state with an UFD-Disabled error message when one upstream interface in an uplink-state group goes down.

If all upstream interfaces in an uplink-state group go down, all downstream interfaces in the same uplink-state group are put into a link-down state.

Related Commands

- [downstream](#) — assigns a port or port-channel to the uplink-state group as a downstream interface.
- [uplink-state-group](#) — creates an uplink-state group and enables the tracking of upstream links.

enable

Re-enable upstream-link tracking for an uplink-state group after it has been disabled.

Syntax `enable`

To disable upstream-link tracking without deleting the uplink-state group, use the `no enable` command.

group-id Enables debugging on the specified uplink-state group. Valid *group-id* values are 1 to 16.

Defaults Upstream-link tracking is automatically enabled in an uplink-state group.

Command Modes UPLINK-STATE-GROUP

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.



Version	Description
9.2(0.0)	Supported on the M I/O Aggregator.

show running-config uplink-state-group

Display the current configuration of one or more uplink-state groups.

Syntax	show running-config uplink-state-group [<i>group-id</i>]							
Parameters	<i>group-id</i>	Displays the current configuration of all uplink-state groups or a specified group. The valid group-id values are from 1 to 16.						
Defaults	none							
Command Modes	- EXEC - EXEC Privilege							
Supported Modes	Programmable-Mux (PMUX)							
Command History	<table><tr><th>Version</th><th>Description</th></tr><tr><td>9.4(0.0)</td><td>Supported on the FN I/O Aggregator.</td></tr><tr><td>9.2(0.0)</td><td>Supported on the M I/O Aggregator.</td></tr></table>		Version	Description	9.4(0.0)	Supported on the FN I/O Aggregator.	9.2(0.0)	Supported on the M I/O Aggregator.
Version	Description							
9.4(0.0)	Supported on the FN I/O Aggregator.							
9.2(0.0)	Supported on the M I/O Aggregator.							
Example	<pre>Dell#show running-config uplink-state-group ! no enable uplink state track 1 downstream TengigabitEthernet 0/2,4,6,11 upstream TengigabitEthernet 0/8, 12 upstream PortChannel 1 ! uplink state track 2 downstream TengigabitEthernet 0/1,3,5 upstream TengigabitEthernet 0/9,10</pre>							
Related Commands	show uplink-state-group — displays the status information on a specified uplink-state group or all groups. uplink-state-group — creates an uplink-state group and enables the tracking of upstream links.							

show uplink-state-group

Display status information on a specified uplink-state group or all groups.

Syntax	show uplink-state-group [<i>group-id</i>] [detail]	
Parameters	<i>group-id</i>	Displays status information on a specified uplink-state group or all groups. The valid group-id values are from 1 to 16.



detail	Displays additional status information on the upstream and downstream interfaces in each group
---------------	--

Defaults	none
-----------------	------

Command Modes	- EXEC - EXEC Privilege
----------------------	--

Supported Modes	Programmable-Mux (PMUX)
------------------------	-------------------------

Command History	This guide is platform-specific. For command information about other platforms, refer to the relevant <i>Dell Networking OS Command Line Reference Guide</i> .
------------------------	--

The following is a list of the Dell Networking OS version history for this command.

Version	Description
9.2(0.0)	Introduced on the M I/O Aggregator.

Example	<pre> Dell# show uplink-state-group Uplink State Group: 1 Status: Enabled, Up Uplink State Group: 3 Status: Enabled, Up Uplink State Group: 5 Status: Enabled, Down Uplink State Group: 6 Status: Enabled, Up Uplink State Group: 7 Status: Enabled, Up Uplink State Group: 16 Status: Disabled, Up Dell# show uplink-state-group 16 Uplink State Group: 16 Status: Disabled, Up Dell#show uplink-state-group detail (Up): Interface up (Dwn): Interface down (Dis): Interface disabled Uplink State Group : 1 Status: Enabled, Up Upstream Interfaces : Downstream Interfaces : Uplink State Group : 3 Status: Enabled, Up Upstream Interfaces : Gi 0/46(Up) Gi 0/47(Up) Downstream Interfaces : Te 13/0(Up) Te 13/1(Up) Te 13/3(Up) Te 13/5(Up) Te 13/6(Up) Uplink State Group : 5 Status: Enabled, Down Upstream Interfaces : Gi 0/0(Dwn) Gi 0/3(Dwn) Gi 0/5(Dwn) Downstream Interfaces : Te 13/2(Dis) Te 13/4(Dis) Te 13/11(Dis) Te 13/12(Dis) Te 13/13(Dis) Te 13/14(Dis) Te 13/15(Dis) Uplink State Group : 6 Status: Enabled, Up Upstream Interfaces : Downstream Interfaces : Uplink State Group : 7 Status: Enabled, Up Upstream Interfaces : Downstream Interfaces : Uplink State Group : 16 Status: Disabled, Up Upstream Interfaces : Gi 0/41(Dwn) Po 8(Dwn) Downstream Interfaces : Gi 0/40(Dwn) </pre>
----------------	---



uplink-state-group

Create an uplink-state group and enable the tracking of upstream links on a switch/ router.

Syntax `uplink-state-group group-id`
To delete an uplink-state group, enter the `no uplink-state-group group-id` command.

Parameters `group-id` Enter the ID number of an uplink-state group. The range is from 1 to 16.

Defaults none

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Usage Information After you enter the command, to assign upstream and downstream interfaces to the group, enter Uplink-State-Group Configuration mode.

An uplink-state group is considered to be operationally up if at least one upstream interface in the group is in the Link-Up state.

An uplink-state group is considered to be operationally down if no upstream interfaces in the group are in the Link-Up state. No uplink-state tracking is performed when a group is disabled or in an operationally down state.

To disable upstream-link tracking without deleting the uplink-state group, use the `no enable` command in uplink-state-group configuration mode.

Example

```
Dell(conf)#uplink-state-group 16
Dell(conf)#
02:23:17: %RPM0-P:CP %IFMGR-5-ASTATE_UP: Changed uplink state group Admin
state to up: Group 16
```

Related Commands

- [show running-config uplink-state-group](#) — displays the current configuration of one or more uplink-state groups.
- [show uplink-state-group](#) — displays the status information on a specified uplink-state group or all groups.

upstream

Assign a port or port-channel to the uplink-state group as an upstream interface.

Syntax `upstream interface`
To delete an uplink-state group, use the `no upstream interface` command.



Parameters	interface Enter one of the following interface types: • Fast Ethernet: <code>fastethernet {slot/port slot/port-range}</code> • 1 Gigabit Ethernet: <code>gigabitethernet {slot/port slot/port-range}</code> • 10 Gigabit Ethernet: <code>tengigabitethernet {slot/port slot/port-range}</code> • 40 Gigabit Ethernet: <code>fortyGigE {slot/port slot/port-range}</code> • Port channel: <code>port-channel {1-512 port-channel-range}</code> Where <code>port-range</code> and <code>port-channel-range</code> specify a range of ports separated by a dash (-) and/or individual ports/port channels in any order; for example: <code>gigabitethernet 1/1-2,5,9,11-12 port-channel 1-3,5</code>. A comma is required to separate each port and port-range entry.				
Defaults	none				
Command Modes	UPLINK-STATE-GROUP				
Supported Modes	Programmable-Mux (PMUX)				
Command History	This guide is platform-specific. For command information about other platforms, refer to the relevant <i>Dell Networking OS Command Line Reference Guide</i>. The following is a list of the Dell Networking OS version history for this command. <table> <tr> <th>Version</th><th>Description</th></tr> <tr> <td>9.2(0.0)</td><td>Introduced on the M I/O Aggregator.</td></tr> </table>	Version	Description	9.2(0.0)	Introduced on the M I/O Aggregator.
Version	Description				
9.2(0.0)	Introduced on the M I/O Aggregator.				
Usage Information	You can assign physical port or port-channel interfaces to an uplink-state group. You can assign an interface to only one uplink-state group. Configure each interface assigned to an uplink-state group as either an upstream or downstream interface, but not both. You can assign individual member ports of a port channel to the group. An uplink-state group can contain either the member ports of a port channel or the port channel itself, but not both.				
Example	<pre>Dell(conf-uplink-state-group-16)# upstream gigabitethernet 1/10-15 Dell(conf-uplink-state-group-16)#</pre>				
Related Commands	• downstream — assigns a port or port-channel to the uplink-state group as a downstream interface.				



Virtual Link Trunking (VLT)

VLT allows physical links between two chassis to appear as a single virtual link to the network core. VLT eliminates the requirement for Spanning Tree protocols by allowing link aggregation group (LAG) terminations on two separate distribution or core switches, and by supporting a loop-free topology. VLT provides Layer 2 multipathing, creating redundancy through increased bandwidth and enabling multiple parallel paths between nodes and load-balancing traffic where alternative paths exist.

 **NOTE:** When you launch the VLT link, the VLT peer-ship is not established if any of the following is TRUE:

- The VLT System-MAC configured on both the VLT peers do not match.
- The VLT Unit-Id configured on both the VLT peers are identical.
- The VLT System-MAC or Unit-Id is configured only on one of the VLT peers.
- The VLT domain ID is not the same on both peers.

If the VLT peer-ship is already established, changing the System-MAC or Unit-Id does not cause VLT peer-ship to go down.

Also, if the VLT peer-ship is already established and the VLT Unit-Id or System-MAC are configured on both peers, then changing the CLI configurations on the VLT Unit-Id or System-MAC is rejected if any of the following become **TRUE**:

- After making the CLI configuration change, the VLT Unit-Id becomes identical on both peers.
- After making the CLI configuration change, the VLT System-MAC do not match on both peers.

When the VLT peer-ship is already established, you can remove the VLT Unit-Id or System-MAC configuration from either or both peers. However, removing configuration settings can cause the VLT ports to go down if you configure the Unit-Id or System-MAC on only one of the VLT peers.

back-up destination

Configure the IPv4 or IPv6 address of the management interface on the remote VLT peer to be used as the endpoint of the VLT backup link for sending out-of-band hello messages.

Syntax `back-up destination {[ipv4-address] | [ipv6 ipv6-address] [interval seconds]}`

Parameters	ipv4-address	Enter the IPv4 address of the backup destination.
	ipv6	Enter the keyword <code>ipv6</code> then an IPv6 address in the X:X:X:X::X format.
	interval seconds	Enter the keyword <code>interval</code> to specify the time interval to send hello messages. The range is from 1 to 5 seconds. The default is 1 second.

Defaults **1 second**

Command Modes VLT DOMAIN

Supported Modes Programmable-Mux (PMUX)



Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.

clear vlt statistics

Clear the statistics on VLT operations.

Syntax `clear vlt statistics [arp | domain | igmp-snoop | mac | multicast | ndp]`

Parameters	domain	Clear the VLT statistics for the domain.
	multicast	Clear the VLT statistics for multicast.
	mac	Clear the VLT statistics for the MAC address.
	arp	Clear the VLT statistics for ARP.
	igmp-snoop	Clear the VLT statistics for IGMP snooping.
	ndp	Clear the VLT statistics for NDP.

Command Modes EXEC

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.

Example

```
VLT ARP Statistics
-----
ARP Tunnel Pkts sent:0
ARP Tunnel Pkts Rcvd:0
ARP-sync Pkts Sent:0
ARP-sync Pkts Rcvd:0
ARP Reg Request sent:19
ARP Reg Request rcvd:10
```

lACP ungroup member-independent

Prevent possible loop during the bootup of a VLT peer switch or a device that accesses the VLT domain.

Syntax `lACP ungroup member-independent {vlt | port-channel}`

Parameters	port-channel	Force all LACP port-channel members to become switchports.
	vlt	Force all VLT LACP members to become switchports.

Defaults Not configured.



Command Modes	CONFIGURATION	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.
Usage Information	LACP on the VLT ports (on a VLT switch or access device), which are members of the virtual link trunk, is not brought up until the VLT domain is recognized on the access device.	
	To ungroup the VLT and port-channel configurations, use the no lacp ungroup member independent command on a VLT port channel, depending on whether the port channel is VLT or non-VLT.	
Example	<pre> Dell(conf)#lacp ungroup member-independent ? port-channel LACP port-channel members become switchports vlt All VLT LACP members become switchports </pre>	

peer-link port-channel

Configure the specified port channel as the chassis interconnect trunk between VLT peers in the domain.

Syntax	<code>peer-link port-channel <i>port-channel-number</i> {peer-down-vlan <i>vlan id</i>}</code>	
Parameters	<i>port-channel-number</i>	Enter the port-channel number that acts as the interconnect trunk.
	<i>peer-down-vlan vlan id</i>	Enter the keyword <code>peer-down-vlan</code> then a VLAN ID to configure the VLAN that the VLT peer link uses when the VLT peer is down.
Defaults	Not configured.	
Command Modes	VLT DOMAIN	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.
Usage Information	To configure the VLAN from where the VLT peer forwards packets received over the VLTi from an adjacent VLT peer that is down, use the peer-down-vlan parameter. To ensure that the DHCP discover packets are forwarded to the VLAN that has the DHCP server, use this configuration.	



show vlt backup-link

Displays information on the backup link operation.

Syntax show vlt backup-link

Default Not configured.

Command Modes EXEC

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.

Example

```
Dell# show vlt backup-link
VLT Backup Link
-----
Destination:                169.254.31.23
Peer HeartBeat status:      Up
HeartBeat Timer Interval:   1
HeartBeat Timeout:          3
UDP Port:                   34998
HeartBeat Messages Sent:    24
HeartBeat Messages Received: 25
```

show vlt brief

Display brief status information about VLT domains currently configured on the switch.

Syntax show vlt brief

Default Not configured.

Command Modes EXEC

Supported Modes All Modes

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.

Example (Brief)

```
Dell#show vlt br
VLT Domain Brief
-----
Domain ID                      : 1
Role                           : Secondary
Role Priority                   : 32768
ICL Link Status                 : Up
HeartBeat Status                : Up
VLT Peer Status                 : Up
Version                        : 6(3)
Local System MAC address       : 00:01:e8:8a:e9:91
Remote System MAC address      : 00:01:e8:8a:e9:76
Remote system version           : 6(3)
Delay-Restore timer             : 90 seconds
```



```

Delay-Restore Abort Threshold          : 60 seconds
Peer-Routing                          : Disabled
Peer-Routing-Timeout timer           : 0 seconds
Multicast peer-routing timeout       : 150 seconds
Dell#

```

show vlt detail

Displays detailed status information about VLT domains currently configured on the switch.

Syntax `show vlt detail`

Default Not configured.

Command Modes EXEC

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Example

```

Dell# show vlt detail
Local LAG Id Peer LAG Id Local Status Peer Status Active VLANs
-----
128      128      UP      UP      1000
Dell#

```

show vlt mismatch

Display mismatches in VLT parameters.

Syntax `show vlt mismatch`

Command Modes EXEC

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Example

```

Dell#show vlt mismatch
Domain
-----
Parameters      Local      Peer
-----
Unit-ID         0          15

Vlan-config
-----
Vlan-ID         Local Mode  Peer Mode

```



```

-----
          100          --          L3
Vlan IPv4 Multicast Status
-----
Vlan-ID          Local Status          Peer Status
-----
          4094          Active          Inactive
Dell#

```

show vlt role

Display the VLT peer status, role of the local VLT switch, VLT system MAC address and system priority, and the MAC address and priority of the locally-attached VLT device.

Syntax `show vlt role`

Default Not configured.

Command Modes EXEC

Supported Modes All Modes

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Example

```

Dell#show vlt role
VLT Role
-----
VLT Role:          Primary
System MAC address: 00:01:05:08:02:05
Primary Role Priority: 32768
Local System MAC address: 00:01:e8:00:ab:03
Local System Role Priority: 32768
Local Unit Id:      0
Dell#

```

show vlt statistics

Displays statistics on VLT operations.

Syntax `show vlt statistics`

Default Not configured.

Command Modes EXEC

Supported Modes All Modes



Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Example

```
Dell#show vlt statistics
VLT Domain Statistics
-----
HeartBeat Messages Sent:      449
HeartBeat Messages Received: 448
ICL Hello's Sent:            154
ICL Hello's Received:        154
Domain Mismatch Errors:      0
Version Mismatch Errors:     0
Config Mismatch Errors:      0

VLT MAC Statistics
-----
L2 Info Pkts sent:16, L2 Mac-sync Pkts Sent:25
L2 Info Pkts Rcvd:15, L2 Mac-sync Pkts Rcvd:24
L2 Reg Request sent:2
L2 Reg Request rcvd:1
L2 Reg Response sent:1
L2 Reg Response rcvd:1

VLT Igmp-Snooping Statistics
-----
IGMP Info Pkts sent:      9
IGMP Info Pkts Rcvd:     10
IGMP Reg Request sent:    2
IGMP Reg Request rcvd:    2
IGMP Reg Response sent:   2
IGMP Reg Response rcvd:   1
IGMP PDU Tunnel Pkt sent: 0
IGMP PDU Tunnel Pkt rcvd: 0
IGMP Tunnel PDUs sent:    0
IGMP Tunnel PDUs rcvd:    0

VLT ARP Statistics
-----
ARP Tunnel Pkts sent:0
ARP Tunnel Pkts Rcvd:0
ARP Tunnel Pkts sent Non Vlt:0
ARP Tunnel Pkts Rcvd Non Vlt:0
ARP-sync Pkts Sent:0
ARP-sync Pkts Rcvd:0
ARP Reg Request sent:2
ARP Reg Request rcvd:1
VLT IOA Statistics
-----
IOA Info Pkts sent:      5
IOA Info Pkts Rcvd:      7
IOA Reg Request sent:    2
IOA Reg Request rcvd:    2
IOA Reg Response sent:   2
IOA Reg Response rcvd:   1
VLT NDP Statistics
-----
NDP NA VLT Tunnel Pkts sent:0
NDP NA VLT Tunnel Pkts Rcvd:0
NDP NA Non-VLT Tunnel Pkts sent:0
NDP NA Non-VLT Tunnel Pkts Rcvd:0
Ndp-sync Pkts Sent:0
Ndp-sync Pkts Rcvd:0
Ndp Reg Request sent:2
```



```
Ndp Reg Request rcvd:1
VLT multicast not enabled
```

stack-unit iom-mode

Set the Aggregator operating mode to VLT mode.

Syntax	<code>stack-unit <unit-number> iom-mode vlt</code>	
Parameters	unit number <0-5>	Enter the number of the member stack unit. The range is from 0 to 5. The default is 0.
	vlt	Enable virtual link trunking mode.
Command Modes	CONFIGURATION	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.
Usage Information	This command resets the operating mode to VLT. You must reboot the Aggregator after using this command.	

system-mac

Reconfigure the default MAC address for the domain.

Syntax	<code>system-mac mac-address</code>	
Parameters	mac-address	Enter the system MAC address for the VLT domain.
Defaults	Not configured.	
Command Modes	VLT DOMAIN	
Supported Modes	Programmable-Mux (PMUX)	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.
Usage Information	When you create a VLT domain on a switch, Dell Networking OS automatically creates a VLT-system MAC address used for internal system operations.	
	To reconfigure the default MAC address for the domain by entering a new MAC address in the format nn:nn:nn:nn:nn:nn, use the <code>system-mac</code> command.	



You must also reconfigure the same MAC address on the VLT peer switch.

unit-id

Explicitly configure the default unit ID of a VLT peer switch.

Syntax `unit-id [0 | 1]`

Parameters

0 1	Configure the default unit ID of a VLT peer switch. Enter 0 for the first peer or enter 1 for the second peer.
--------------	--

Defaults Automatically assigned based on the MAC address of each VLT peer. The peer with the lower MAC address is assigned unit 0; the peer with the higher MAC address is assigned unit 1.

Command Modes VLT DOMAIN

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.

Usage Information When you create a VLT domain on a switch, Dell Networking OS automatically assigns a unique unit ID (0 or 1) to each peer switch. The unit IDs are used for internal system operations. Use the `unit-id` command to explicitly configure the unit ID of a VLT peer. Configure a different unit ID (0 or 1) on each peer switch.

To minimize the time required for the VLT system to determine the unit ID assigned to each peer switch when one peer reboots, use this command.

vlt domain

Enable VLT on a switch, configure a VLT domain, and enter VLT-domain configuration mode.

Syntax `vlt domain domain-id`

Parameters

domain-id	Enter the Domain ID number. Configure the same domain ID on the peer switch. The range of domain IDs is from 1 to 1000.
------------------	---

Command Modes CONFIGURATION

Supported Modes Programmable-Mux (PMUX)

Command History

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
9.2(0.0)	Supported on the M I/O Aggregator.



Usage Information The VLT domain ID must be the same between the two VLT devices. If the domain ID is not the same, a syslog message is generated and VLT does not launch.

vlt-peer-lag port-channel

Associate the port channel to the corresponding port channel in the VLT peer for the VLT connection to an attached device.

Syntax `vlt-peer-lag port-channel id-number`

Parameters *id-number* Enter the respective vlt port-channel number of the peer device.

Defaults Not configured.

Command Modes INTERFACE PORT-CHANNEL

Supported Modes Programmable-Mux (PMUX)

Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	9.2(0.0)	Supported on the M I/O Aggregator.



Debugging and Diagnostics

This chapter contains the following sections:

- [Offline Diagnostic Commands](#)
- [Hardware Commands](#)

Offline Diagnostic Commands

The offline diagnostics test suite is useful for isolating faults and debugging hardware. While tests are running, the Dell Networking OS results are saved as a text file (TestReport-SU-X.txt) in the flash directory. The `show file` command is available only on Master and Standby.

Important Points to Remember

- Offline diagnostics can only be run when the unit is offline.
- Offline diagnostics cannot be run in Stacking mode.
- You can only run offline diagnostics on a unit to which you are connected via the console. In other words, you cannot run diagnostics on a unit to which you are connected via a stacking link.
- Diagnostic results are stored in a file (TestReport-SU-X.txt) in the flash directory. To review the results, use the `show file` command, which prints the results to the screen.
- Diagnostics only test connectivity, not the entire data path.

The offline diagnostics commands are:

- [diag stack-unit](#)
- [offline stack-unit](#)
- [show diag](#)

Hardware Commands

These commands display information from a hardware sub-component or ASIC.

The hardware commands are:

- [clear hardware stack-unit](#)
- [show diag](#)
- [show hardware stack-unit](#)
- [show hardware system-flow](#)



clear hardware stack-unit

Clear statistics from selected hardware components.

Syntax	<pre>clear hardware stack-unit 0-5 {counters unit 0-1 counters cpu data-plane statistics cpu party-bus statistics stack-port 0-52}</pre>	
Parameters	stack-unit 0-5	Enter the keywords <code>stack-unit</code> then 0 to 5 to select a particular stack member and then enter one of the following command options to clear a specific collection of data.
	counters	Enter the keyword <code>counters</code> to clear the counters on the selected stack member.
	unit 0-0 counters	Enter the keyword <code>unit</code> along with a port-pipe number, from 0 to 1, then the keyword <code>counters</code> to clear the counters on the selected port-pipe.
	cpu data-plane statistics	Enter the keywords <code>cpu data-plane statistics</code> to clear the data plane statistics.
	cpu party-bus statistics	Enter the keywords <code>cpu party-bus statistics</code> to clear the management statistics.
	stack-port 33-56	Enter the keywords <code>stack-port</code> then the port number of the stacking port to clear the statistics of the particular stacking port. The range is from 33 to 56.
 NOTE: You can identify stack port numbers by physical inspection of the rear modules. The numbering is the same as for the 10G ports. You can also inspect the output of the <code>show system stack-ports</code> command.		
Defaults	none	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.
Related Commands	show diag — displays the data plane or management plane input and output statistics of the designated component of the designated stack member.	

diag stack-unit

Run offline diagnostics on a stack unit.

Syntax	<pre>diag stack-unit number {alllevels level0 level1 level2 [verbose no-reboot] terminate interactive test <id>}</pre>	
Parameters	number	Enter the stack-unit number. The range is from 0 to 5.
	alllevels	Enter the keyword <code>alllevels</code> to run the complete set of offline diagnostic tests.
	level0	Enter the keyword <code>level0</code> to run Level 0 diagnostics. Level 0 diagnostics check for the presence of various components and perform essential path verifications. In addition, they verify the identification registers of the components on the board.

level1	Enter the keyword <code>level1</code> to run Level 1 diagnostics. Level 1 diagnostics is a smaller set of diagnostic tests with support for automatic partitioning. They perform status/self test for all the components on the board and test their registers for appropriate values. In addition, they perform extensive tests on memory devices (for example, SDRAM, flash, NVRAM, EEPROM, and CPLD) wherever possible. There are no tests on 10G links. At this level, stack ports are shut down automatically.
level2	Enter the keyword <code>level2</code> to run Level 2 diagnostics. Level 2 diagnostics are a full set of diagnostic tests with no support for automatic partitioning. Level 2 diagnostics are used primarily for on-board loopback tests and more extensive component diagnostics. Various components on the board are put into Loopback mode and test packets are transmitted through those components. These diagnostics also perform snake tests using VLAN configurations. To test 10G links, physically remove the unit from the stack.
verbose	Enter the keyword <code>verbose</code> to run the diagnostic in Verbose mode. Verbose mode gives more information in the output than Standard mode.
no-reboot	Enter the keyword <code>no-reboot</code> to avoid automatic rebooting of the chassis after completion of diagnostic execution. Generally, this option is never used because if you run the diagnostic once again without rebooting the chassis, it may cause an issue with the diagnostic results..
terminate	Enter the keyword <code>terminate</code> to stop the execution of the level diag that is already started using the <code>diag stack-unit</code> command. Once this CLI is issued, syslogs indicating the termination of the diag test is displayed. The diag results for the executed tests are stored in the flash directory (<code>TestReport-SU-X.txt</code>).
interactive	Enter the keyword <code>interactive</code> to run some individual diag tests such as <code>POWERLEDTST</code> , <code>STATUSLEDTST</code> and so on. The help option under the interactive command displays the list of tests that can be run.

Defaults	none
Command Modes	EXEC Privilege
Supported Modes	All Modes
Command History	

Version	Description
9.4(0.0)	Supported on the FN I/O Aggregator.
8.3.17.0	Supported on the M I/O Aggregator.

hardware watchdog

Set the watchdog timer to trigger a reboot and restart the system.

Syntax	<code>hardware watchdog</code>
Defaults	Enabled
Command Modes	· CONFIGURATION



Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	This command enables a hardware watchdog mechanism that automatically reboots an Dell Networking OS switch/router with a single unresponsive unit. This is a last resort mechanism intended to prevent a manual power cycle.	

offline stack-unit

Place a stack unit in the offline state.

Syntax	<code>offline stack-unit <i>number</i></code>	
Parameters	<i>number</i>	Enter the stack-unit number. The range is from 0 to 5.
Defaults	none	
Command Modes	EXEC Privilege	
Supported Modes	All Modes	
Command History	Version	Description
	9.4(0.0)	Supported on the FN I/O Aggregator.
	8.3.17.0	Supported on the M I/O Aggregator.
Usage Information	While executing the offline stack unit CLI, the following warning message is displayed: <pre> Dell#offline stack-unit 0 Warning - offline of unit will bring down all the protocols and the unit will be operationally down, except for running Diagnostics. Please make sure that stacking/fanout not configured for Diagnostics execution. Also reboot/online command is necessary for normal operation after the offline command is issued. Proceed with Offline [confirm yes/no]:no Dell# </pre> Make sure that stacking is not configured for Diagnostics execution. Also, reboot/online command is necessary for normal operation after the offline command is issued.	



show diag

View diagnostics information.

Syntax `show diag {information | stack-unit number [detail | periodic | summary] | testcase}`

Parameters	information	Enter the keyword <code>information</code> to view current diagnostics information in the system.
	stack-unit <i>unit-id</i>	Enter the keyword <code>stack-unit</code> followed by the <i>unit-id</i> to display information on a specific stack member. The range is from 0 to 5.
	detail	(OPTIONAL) Enter the keyword <code>detail</code> to view detailed diagnostics information.
	summary	(OPTIONAL) Enter the keyword <code>summary</code> to view a summary of the diagnostics information. By default, the summary is displayed.
	testcase	Enter the keyword <code>testcase</code> to view the list of all the diag tests available.

Defaults Summary

Command Modes EXEC Privilege

Supported Modes All Modes

Command History	Version	Description
	8.3.17.0	Supported on the M I/O Aggregator.

Example 1 (show diag information Command)

```
Dell#show diag information
Diag information:
Diag software image version:
8-3-17-36
-----
Stack-unit Member 0: Unit diags are terminated (Stackunit Offline).
Stack-unit Member 1: Not present.
Stack-unit Member 2: Not present.
Stack-unit Member 3: Not present.
Stack-unit Member 4: Not present.
Stack-unit Member 5: Not present.
-----
```

Example 2 (show diag stack-unit Command)

```
Dell#show diag stackunit 0
Diag status of Stackunit member 0:
-----
Stackunit is currently offline.
Stackunit level0 diag issued at Tue May 15, 2012 11:11:47 AM.
Current diag status:      Unit diags are terminated.
Total number of diags:      17
Number of diags performed:   1
Number of diags passed:      1
Number of diags failed:      0
Number of diags pending:     16
Last Test executed:         POWERRAILSTATUSTEST
Last notification received at: Tue May 15, 2012 11:12:24 AM
-----
```

Example 3 (show diag testcase stack-unit Command)

```
Dell#show diag testcase stack-unit 0
***** Navasota Diagnostics Test *****
Test ID Test Description                               Test Level
-----
```



```

1  POWERRAILSTATUSTEST                      Level0
2  OPTMODSLOTPOWERSTATUSTEST                Level0
3  TSENSORACCESSTEST                        Level0
4  RTCPRESENCETEST                          Level0
5  CPUSDRAMPRESENCETEST                     Level0
6  CPUSDRAMSIZEEST                          Level0
7  USBACCESSTEST                            Level0
8  USBHOSTCONTROLLERACCESSTEST              Level0
9  SDFLASHACCESSTEST                         Level0
10 QSFPPPLUSPOWERMODETEST                   Level0
11 CPLDPRESENCETEST                         Level0
12 FLASHACCESSTEST                          Level0
13 BOARDREVTEST                             Level0
14 MGMTPHYPRESENCETEST                      Level0
15 OPTMODTYPEPESTEST                         Level0
16 QSFPPPLUSPRESENCETEST                     Level0
17 CPUTYPEDETECTTEST                         Level0
101 RTCFUNCTIONTEST                         Level1
102 RTCROLLOVERTEST                         Level1
103 GPIOACCESSTEST                           Level1
104 PSOCACCESSTEST                           Level1
105 PCIEBCM56846ACCESSTEST                   Level1
106 CPUSDRAMACCESSTEST                       Level1
107 CPUSDRAMDATA LINETEST                     Level1
108 CPUSDRAMADDRESS LINETEST                 Level1
109 USBFILECOPYTEST                          Level1
110 FLASHRWTEST                              Level1
111 I2CSTRESSTEST                            Level1
112 AVSPowerCntrlACCESSTEST                  Level1
113 SERVERPORTPHYACCESSTEST                  Level1
114 SERVERPORTPHYRWTEST                      Level1
115 QSFPPPLUSPHYACCESSTEST                   Level1
116 QSFPPPLUSPHYRWTEST                       Level1
117 QSFPPPLUSPHYEXTLINKTEST                  Level1
118 QSFPPPLUSEEPROMTEST                      Level1
119 OPTMODPHYACCESSTEST                      Level1
120 OPTMODPHYRWTEST                          Level1
121 OPTMODPHYEXTLINKTEST                     Level1
122 OPTMODMODULEEEPROMTEST                   Level1
123 MGMTPHYACCESSTEST                        Level1
124 SDFLASHFILECOPYSTRESSTEST                Level1
201 QSFPPPLUSPHYLNKSPEEDTEST                 Level2
202 OPTMODPHYLNKSPEEDTEST                     Level2
203 MGMTPHYLOOPBACKTEST                       Level2
204 MGMTMACLOOPBACKTEST                       Level2
205 CPUSNAKESERVERPORTPHYLPBKTEST             Level2
206 CPUSNAKESERVERPORTMACLPBKTEST             Level2
207 CPUSNAKEQSFPPPHYLPBKTEST                  Level2
208 CPUSNAKEQSFPPMACLPBKTEST                   Level2
209 CPUSNAKEOPTMODPHYLPBKTEST                 Level2
210 CPUSNAKEOPTMODMACLPBKTEST                 Level2
Total Diagnostic Testcases in All Levels: 51
***** END
*****

```

**Example 4 (show
diag testcase stack-
unit interactive
Command)**

```

Dell#show diag testcase stack-unit 0 interactive
***** Navasota Diagnostics Test *****
Test ID Test Description      Test Level
-----
401 POWERLEDTEST              Interactive
402 DEBUGLEDTEST              Interactive
403 STATUSLEDTEST              Interactive
404 OPTMODLEDCONTROLTEST       Interactive
405 FIXEDLEDCONTROLTEST        Interactive
406 RTCBATTERYTEST             Interactive
407 CPLDRESETTEST              Interactive
408 I2CDEVICESCANTEST          Interactive

```



```

409 SERVERPORTPHYEXTLINKTEST   Interactive
410 CPUSNAKEQSFPPEXTLPBKTEST   Interactive
411 CPUSNAKEOPTMODEXTLPBKTEST   Interactive
Total Diagnostic Testcases in Interactive: 11
***** END
*****

```

show hardware stack-unit

Display the data plane or management plane input and output statistics of the designated component of the designated stack member.

Syntax

```

show hardware stack-unit 0-5 {buffer [ unit 0 ] total buffer | buffer unit
0 interface all queue [(0-14) | all] buffer-info} {phy-firmware-version}
{cpu data-plane statistics [stack-port 0-52] | cpu party-bus statistics |
cpu private-mgmt statistics | drops [unit 0-1 ] | stack-port 33-56 | unit
0-0 {counters | details | port-stats [detail] | register}}

```

Parameters

stack-unit 0-5 {command-option}	Enter the keywords <code>stack-unit</code> then 0 to 5 to select a particular stack member and then enter one of the following command options to display a collection of data based on the option entered.
buffer	Enter the keyword <code>buffer</code> . To display buffer statistics for a all interface, enter the keyword <code>interface</code> followed by the keyword <code>all</code> . To display the forwarding plane statistics containing the packet buffer usage per port per stack unit, enter the keyword <code>unit</code> then 0 for port-pipe 0, then <code>port</code> and the port number (42-53, and then <code>buffer-info</code> .
fpga	Enter the keyword <code>fpga</code> , to display fpga details.
fru	Enter the keyword <code>fru</code> , to display fru details.
phy-firmware-version	Each member of the stack is updated automatically with the latest firmware while booting as well as during OIR. To dump the physical firmware version for stack units, enter the keywords <code>phy-firmware-version</code> .
cpu data-plane statistics	Enter the keywords <code>cpu data-plane statistics</code> , optionally followed by the keywords <code>stack port</code> and its number from 0 to 52 to display the data plane statistics, which shows the High Gig (Higig) port raw input/output counter statistics to which the stacking module is connected.
cpu party-bus statistics	Enter the keywords <code>cpu party-bus statistics</code> , to display the Management plane input/output counter statistics of the Private Management interface.
cpu private-mgmt statistics	Enter the keywords <code>cpu private-mgmt statistics</code> , to display the Management plane input/output counter statistics of the Private Management interface.
drops interface interface	Enter the keyword <code>drops</code> to display internal drops on the selected stack member.
stack-port 33-56	Enter the keywords <code>stack-port</code> and a stacking port number to select a stacking port for which to display statistics. Identify the stack port number as you would to identify a 10G port that was in the same place in one of the rear modules.





NOTE: You can identify stack port numbers by physical inspection of the rear modules. The numbering is the same as for the 10G ports. You can also inspect the output of the `show system stack-ports` command.

`unit 0-0 {counters | details | port-stats [detail] | register}`

Enter the keyword `unit` then 0 for port-pipe 0, and then enter one of the following keywords to troubleshoot errors on the selected port-pipe and to give status on why a port is not coming up to register level: `counters`, `details`, `port-stats [detail]`, or `register`.

Defaults none

Command Modes

- EXEC
- EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
---------	-------------

9.8(0.0)	Replaced the keyword <code>port</code> with <code>interface</code> .
8.3.17.0	Supported on the M I/O Aggregator.

Example (show hardware stack-unit phy-firmware-version Command)

```
Dell#show hardware stack-unit 1 phy-firmware-version
PortNumber      Status          Programmed Version      SW Version
=====
41               Present         01.05                   01.05
42               Present         01.05                   01.05
43               Present         01.05                   01.05
44               Present         01.05                   01.05
45               Not Present     N/A                     N/A
46               Not Present     N/A                     N/A
47               Not Present     N/A                     N/A
48               Not Present     N/A                     N/A
49               Present         01.06                   01.06
50               Present         01.06                   01.06
51               Present         01.06                   01.06
52               Present         01.06                   01.06
53               Present         01.06                   01.06
54               Present         01.06                   01.06
55               Present         01.06                   01.06
56               Present         01.06                   01.06
Dell#
```

In the above example, the *Status* field represents presence of OPTM ports, *Programmed version* field represents loaded firmware version, and *SW version* represents the SDK version.

Example (data-plane)

```
Dell#show hardware stack-unit 1 cpu data-plane statistics
bc pci driver statistics for device:
rxHandle         :7392
noMhdr           :0
noMbuf           :0
noClus           :0
recvd            :7392
dropped          :0
recvToNet        :7392
rxError          :0
rxDatapathErr    :0
rxPkt(COS0)      :0
rxPkt(COS1)      :0
rxPkt(COS2)      :10
```



```

rxPkt(COS3)      :0
rxPkt(COS4)      :0
rxPkt(COS5)      :338
rxPkt(COS6)      :0
rxPkt(COS7)      :7044
rxPkt(UNIT0)     :7392
transmitted      :29899
txRequested      :29899
noTxDesc         : 0
txError          :0
txReqTooLarge    :0
txInternalError  :0
txDatapathErr    :0
txPkt(COS0)      :0
txPkt(COS1)      :0
txPkt(COS2)      :0
txPkt(COS3)      :0
txPkt(COS4)      :0
txPkt(COS5)      :0
txPkt(COS6)      :0
txPkt(COS7)      :0
txPkt(UNIT0)     :0
Dell#

```

Example

```

Dell#show hardware stack-unit 1 cpu party-bus statistics
Input Statistics:
8189 packets, 8076608 bytes
0 dropped, 0 errors
Output Statistics:
366 packets, 133100 bytes
0 errors
Dell#

```

Example (drops)

```

Dell#show hard stack-unit 1 drops
UNIT No: 0

Total Ingress Drops : 7448
Total IngMac Drops : 0
Total Mmu Drops : 0
Total EgMac Drops : 0
Total Egress Drops : 16
Dell#

```

Example (drop summary)

```

Dell#show hardware stack-unit 1 drops unit 0
UserPort PortNumber      Ingress Drops      IngMac Drops      Total Mmu
Drops      EgMac
Drops      Egress Drops
1          1              0              0
0          0
0          0
2          2              0              0
0          0
0          0
3          3              0              0
0          0
0          0
4          4              0              0
0          0
0          0
5          5              728             0
0          0
5          0
6          6              0              0
0          0
0          0
7          7              0              0
0          0
0          0

```



```

0
8      8      0      0
0
0
9      9      0      0
0
0
10     10     0      0
0
0
--More--
Dell#

```

Example (drop counters)

```

Dell#show hardware stack-unit 1 unit 0 counters
unit: 0 port: 1 (interface Te 1/1)
Description                                     Value
RX - IPv4 L3 Unicast Frame Counter              0
RX - IPv4 L3 Routed Multicast Packets           0
RX - IPv6 L3 Unicast Frame Counter              0
RX - IPv6 L3 Routed Multicast Packets           0
RX - Unicast Packet Counter                     0
RX - 64 Byte Frame Counter                      336186
RX - 65 to 127 Byte Frame Counter               0
RX - 128 to 255 Byte Frame Counter              0
RX - 256 to 511 Byte Frame Counter              0
RX - 512 to 1023 Byte Frame Counter             0
RX - 1024 to 1518 Byte Frame Counter            0
RX - 1519 to 1522 Byte Good VLAN Frame Counter 0
RX - 1519 to 2047 Byte Frame Counter            0
RX - 2048 to 4095 Byte Frame Counter            0
RX - 4096 to 9216 Byte Frame Counter            0
RX - Good Packet Counter                       336186
RX - Packet/Frame Counter                      336186
RX - Unicast Frame Counter                     0
RX - Multicast Frame Counter                   336186
RX - Broadcast Frame Counter                   0
RX - Byte Counter                             21515904
RX - Control Frame Counter                     0
RX - Pause Control Frame Counter               0
RX - Oversized Frame Counter                   0
RX - Jabber Frame Counter                      0
RX - VLAN Tag Frame Counter                    0
RX - Double VLAN Tag Frame Counter             0
RX - RUNT Frame Counter                       0
RX - Fragment Counter                          0
RX - VLAN Tagged Packets                       0
RX - Ingress Dropped Packet                    0
RX - MTU Check Error Frame Counter             0
RX - PFC Frame Priority 0                      0
RX - PFC Frame Priority 1                      0
RX - PFC Frame Priority 2                      0
RX - PFC Frame Priority 3                      0
RX - PFC Frame Priority 4                      0
RX - PFC Frame Priority 5                      0
RX - PFC Frame Priority 6                      0
RX - PFC Frame Priority 7                      0
RX - Debug Counter 0                          336186
RX - Debug Counter 1                          336186
RX - Debug Counter 2                          0
RX - Debug Counter 3                          0
RX - Debug Counter 4                          0
RX - Debug Counter 5                          336186
RX - Debug Counter 6                          0
RX - Debug Counter 7                          0
RX - Debug Counter 8                          0
TX - 64 Byte Frame Counter                     166
TX - 65 to 127 Byte Frame Counter              112

```



TX - 128 to 255 Byte Frame Counter	0
TX - 256 to 511 Byte Frame Counter	0
TX - 512 to 1023 Byte Frame Counter	0
TX - 1024 to 1518 Byte Frame Counter	0
TX - 1519 to 1522 Byte Good VLAN Frame Counter	0
TX - 1519 to 2047 Byte Frame Counter	0
TX - 2048 to 4095 Byte Frame Counter	0
TX - 4096 to 9216 Byte Frame Counter	0
TX - Good Packet Counter	278
TX - Packet/Frame Counter	278
TX - Unicast Frame Counter	0
TX - Multicast Frame Counter	278
TX - Broadcast Frame Counter	0
TX - Byte Counter	18688
TX - Control Frame Counter	0
TX - Pause Control Frame Counter	0
TX - Oversized Frame Counter	0
TX - Jabber Counter	0
TX - VLAN Tag Frame Counter	0
TX - Double VLAN Tag Frame Counter	0
TX - RUNT Frame Counter	0
TX - Fragment Counter	0
TX - PFC Frame Priority 0	0
TX - PFC Frame Priority 1	0
TX - PFC Frame Priority 2	0
TX - PFC Frame Priority 3	0
TX - PFC Frame Priority 4	0
TX - PFC Frame Priority 5	0
TX - PFC Frame Priority 6	0
TX - PFC Frame Priority 7	0
TX - Debug Counter 0	0
TX - Debug Counter 1	0
TX - Debug Counter 2	0
TX - Debug Counter 3	0
TX - Debug Counter 4	0
TX - Debug Counter 5	0
TX - Debug Counter 6	0
TX - Debug Counter 7	0
TX - Debug Counter 8	0
TX - Debug Counter 9	0
TX - Debug Counter 10	0
TX - Debug Counter 11	0

unit: 0 port: 61 (interface Fo 1/60)

Description	Value
RX - IPV4 L3 Unicast Frame Counter	0
RX - IPV4 L3 Routed Multicast Packets	0
RX - IPV6 L3 Unicast Frame Counter	0
RX - IPV6 L3 Routed Multicast Packets	0
RX - Unicast Packet Counter	0
RX - 64 Byte Frame Counter	0
RX - 65 to 127 Byte Frame Counter	0
RX - 128 to 255 Byte Frame Counter	0
RX - 256 to 511 Byte Frame Counter	0
RX - 512 to 1023 Byte Frame Counter	0
RX - 1024 to 1518 Byte Frame Counter	0
RX - 1519 to 1522 Byte Good VLAN Frame Counter	0
RX - 1519 to 2047 Byte Frame Counter	0
RX - 2048 to 4095 Byte Frame Counter	0
RX - 4096 to 9216 Byte Frame Counter	0
RX - Good Packet Counter	0
RX - Packet/Frame Counter	0
RX - Unicast Frame Counter	0



RX - Multicast Frame Counter	0
RX - Broadcast Frame Counter	0
RX - Byte Counter	0
RX - Control Frame Counter	0
RX - Pause Control Frame Counter	0
RX - Oversized Frame Counter	0
RX - Jabber Frame Counter	0
RX - VLAN Tag Frame Counter	0
RX - Double VLAN Tag Frame Counter	0
RX - RUNT Frame Counter	0
RX - Fragment Counter	0
RX - VLAN Tagged Packets	0
RX - Ingress Dropped Packet	0
RX - MTU Check Error Frame Counter	0
RX - PFC Frame Priority 0	0
RX - PFC Frame Priority 1	0
RX - PFC Frame Priority 2	0
RX - PFC Frame Priority 3	0
RX - PFC Frame Priority 4	0
RX - PFC Frame Priority 5	0
RX - PFC Frame Priority 6	0
RX - PFC Frame Priority 7	0
RX - Debug Counter 0	0
RX - Debug Counter 1	0
RX - Debug Counter 2	0
RX - Debug Counter 3	0
RX - Debug Counter 4	0
RX - Debug Counter 5	0
RX - Debug Counter 6	0
RX - Debug Counter 7	0
RX - Debug Counter 8	0
TX - 64 Byte Frame Counter	0
TX - 65 to 127 Byte Frame Counter	0
TX - 128 to 255 Byte Frame Counter	0
TX - 256 to 511 Byte Frame Counter	0
TX - 512 to 1023 Byte Frame Counter	0
TX - 1024 to 1518 Byte Frame Counter	0
TX - 1519 to 1522 Byte Good VLAN Frame Counter	0
TX - 1519 to 2047 Byte Frame Counter	0
TX - 2048 to 4095 Byte Frame Counter	0
TX - 4096 to 9216 Byte Frame Counter	0
TX - Good Packet Counter	0
TX - Packet/Frame Counter	0
TX - Unicast Frame Counter	0
TX - Multicast Frame Counter	0
TX - Broadcast Frame Counter	0
TX - Byte Counter	0
TX - Control Frame Counter	0
TX - Pause Control Frame Counter	0
TX - Oversized Frame Counter	0
TX - Jabber Counter	0
TX - VLAN Tag Frame Counter	0
TX - Double VLAN Tag Frame Counter	0
TX - RUNT Frame Counter	0
TX - Fragment Counter	0
TX - PFC Frame Priority 0	0
TX - PFC Frame Priority 1	0
TX - PFC Frame Priority 2	0
TX - PFC Frame Priority 3	0
TX - PFC Frame Priority 4	0
TX - PFC Frame Priority 5	0
TX - PFC Frame Priority 6	0
TX - PFC Frame Priority 7	0
TX - Debug Counter 0	0
TX - Debug Counter 1	0
TX - Debug Counter 2	0
TX - Debug Counter 3	0
TX - Debug Counter 4	0
TX - Debug Counter 5	0



```
TX - Debug Counter 6 0
TX - Debug Counter 7 0
TX - Debug Counter 8 0
TX - Debug Counter 9 0
TX - Debug Counter 10 0
TX - Debug Counter 11 0
```

Example (port-statistics)

```
Dell#show hardware stack-unit 1 unit 0 port-stats
      ena/ speed/ link auto STP      lrn inter  max  loop
port link duplex scan neg?  state  pause  discrd ops face frame back
xe0 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xe1 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1554
xe2 up   1G FD      SW Yes Forward      None   FA  GMII 11996
xe3 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xe4 down 10G FD     SW Yes Block        None   FA  KR 8996
xe5 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xe6 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xe7 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xe8 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xe9 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xel0 down 10G FD    SW Yes Forward      Tag    F  KR 1550
xel1 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xel2 !ena 1G FD      SW Yes Block        None   FA  GMII 11996
xel3 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xel4 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xel5 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xel6 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xel7 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xel8 down 1G FD     SW Yes Forward      Tag    F  GMII 1550
xel9 !ena 1G FD      SW Yes Forward      Tag    F  GMII 1550
xe20 down 1G FD     SW Yes Forward      Tag    F  GMII 1550
--More--
Dell#
```

Example (register)

```
Dell#show hardware stack-unit 0 unit 0 register
0x0f180d34 ALTERNATE_EMIRROR_BITMAP_PARITY_CONTROL.ipipe0 = 0x00000001
0x0f180d35 ALTERNATE_EMIRROR_BITMAP_PARITY_STATUS_INTR.ipipe0 = 0x00000000
0x0f180d36 ALTERNATE_EMIRROR_BITMAP_PARITY_STATUS_NACK.ipipe0 = 0x00000000
0x0018070c ARB_EOP_DEBUG.ipipe0 = 0x00000000
0x00180312 ARB_RAM_DBGCTRL.ipipe0 = 0x00000000
0x03300000 ASF_PORT_SPEED.cpu0 = 0x00000000
0x03322000 ASF_PORT_SPEED.xe0 = 0x00000000
0x03326000 ASF_PORT_SPEED.xe1 = 0x00000000
0x0332a000 ASF_PORT_SPEED.xe2 = 0x00000007
0x0332e000 ASF_PORT_SPEED.xe3 = 0x00000000
0x03323000 ASF_PORT_SPEED.xe4 = 0x00000000
0x03327000 ASF_PORT_SPEED.xe5 = 0x00000000
0x0332b000 ASF_PORT_SPEED.xe6 = 0x00000000
0x0332f000 ASF_PORT_SPEED.xe7 = 0x00000000
0x03324000 ASF_PORT_SPEED.xe8 = 0x00000000
0x03328000 ASF_PORT_SPEED.xe9 = 0x00000000
0x0332c000 ASF_PORT_SPEED.xe10 = 0x00000000
0x03330000 ASF_PORT_SPEED.xe11 = 0x00000000
0x03325000 ASF_PORT_SPEED.xe12 = 0x00000000
0x03329000 ASF_PORT_SPEED.xe13 = 0x00000000
0x0332d000 ASF_PORT_SPEED.xe14 = 0x00000000
0x03331000 ASF_PORT_SPEED.xe15 = 0x00000000
0x03332000 ASF_PORT_SPEED.xe16 = 0x00000000
0x03336000 ASF_PORT_SPEED.xe17 = 0x00000000
0x0333a000 ASF_PORT_SPEED.xe18 = 0x00000000
0x0333e000 ASF_PORT_SPEED.xe19 = 0x00000000
0x03333000 ASF_PORT_SPEED.xe20 = 0x00000000
0x03337000 ASF_PORT_SPEED.xe21 = 0x00000000
0x0333b000 ASF_PORT_SPEED.xe22 = 0x00000000
0x0333f000 ASF_PORT_SPEED.xe23 = 0x00000000
0x03334000 ASF_PORT_SPEED.xe24 = 0x00000000
0x03338000 ASF_PORT_SPEED.xe25 = 0x00000000
0x0333c000 ASF_PORT_SPEED.xe26 = 0x00000000
```



```

0x03340000 ASF_PORT_SPEED.xe27 = 0x00000000
0x03335000 ASF_PORT_SPEED.xe28 = 0x00000000
0x03339000 ASF_PORT_SPEED.xe29 = 0x00000000
!----- output truncated -----!

```

Example (unit details)

```

Dell#show hardware stack-unit 0 unit 0 details
*****
The total no of FP & CSF Devices in the Card is 1
The total no of FP Devices in the Card is 1
The total no of CSF Devices in the Card is 0
The number of ports in device 0 is - 49
The number of Hg ports in devices 0 is - 1
The CPU Port of the device is 0
The staring unit no the SWF in the device is 0
*****
bcmLinkMonStatusShow: The Current Link Status Is
Front End Link Status 0x20000000000000000000000000000000
Front End Port Present Status 0x00000000000000000000000000000000
Back Plane Link Status 0x00000000
*****
Link Status of all the ports in the Device - 0
The linkStatus of Front End Port 1 is FALSE
The linkStatus of Front End Port 2 is FALSE
The linkStatus of Front End Port 3 is TRUE
The linkStatus of Front End Port 4 is FALSE
The linkStatus of Front End Port 5 is FALSE
The linkStatus of Front End Port 6 is FALSE
The linkStatus of Front End Port 7 is FALSE
The linkStatus of Front End Port 8 is FALSE
The linkStatus of Front End Port 9 is FALSE
The linkStatus of Front End Port 10 is FALSE
The linkStatus of Front End Port 11 is FALSE
The linkStatus of Front End Port 12 is FALSE
The linkStatus of Front End Port 13 is FALSE
The linkStatus of Front End Port 14 is FALSE
The linkStatus of Front End Port 15 is FALSE
The linkStatus of Front End Port 16 is FALSE
The linkStatus of Front End Port 17 is FALSE
The linkStatus of Front End Port 18 is FALSE
The linkStatus of Front End Port 19 is FALSE
The linkStatus of Front End Port 20 is FALSE
The linkStatus of Front End Port 21 is FALSE
The linkStatus of Front End Port 22 is FALSE
The linkStatus of Front End Port 23 is FALSE
The linkStatus of Front End Port 24 is FALSE
The linkStatus of Front End Port 25 is FALSE
The linkStatus of Front End Port 26 is FALSE
The linkStatus of Front End Port 27 is FALSE
The linkStatus of Front End Port 28 is FALSE
The linkStatus of Front End Port 29 is FALSE
The linkStatus of Front End Port 30 is FALSE
The linkStatus of Front End Port 31 is FALSE
The linkStatus of Front End Port 32 is FALSE
The linkStatus of Front End Port 37 is FALSE
!----- output truncated -----!

```

Example (buffer)

```

Dell#show hardware stack-unit 0 buffer total-buffer
Dell#sh hardware stack-unit 0 buffer total-buffer
Total Buffers allocated per Stack-Unit 46080

```

Example (Queue2/Buffer-Info)

```

Dell#show hardware stack-unit 1 buffer unit 0 interface all queue 6 buffer-
info
      Buffer Stats for Front End Ports
      =====
----- Buffer Stats for Interface Te 1/1 Queue 6 -----
Maximum Shared Limit: 7667
Default Packet Buffer allocate for the Queue: 8

```



```

Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/2 Queue 6 -----
Maximum Shared Limit: 7667
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/3 Queue 6 -----
Maximum Shared Limit: 7667
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/4 Queue 6 -----
Maximum Shared Limit: 7667
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/5 Queue 6 -----
Maximum Shared Limit: 7667
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/6 Queue 6 -----
Maximum Shared Limit: 7667
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
<output truncated for brevity>

```

Example (queue buffer)

```

Dell(conf)#show hardware stack-unit 0 buffer unit 0 port 1 queue 2 buffer-
info
----- Buffer Stats for Unit 0 Port 1 Queue 2 -----
Maximum Shared Limit: 30720
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0

```

Related Commands

[show interfaces stack-unit](#) — displays information on all interfaces on a specific stack member.

[show processes cpu](#) — displays CPU usage information based on running processes.

[show system stack-ports](#) — displays information about the stacking ports on all switches in the stack.

[show system](#) — displays the current status of all stack members or a specific member.

show hardware counters interface

Display the counter information for a specific interface.

Syntax

```
show hardware counters interface interface
```

Parameters

counters

Enter the keywords `counters` to display counter value for the specified stack-member the port-pipe.

interface *interface*

Enter any of the following keywords and slot/port or number information:

- For a 10-Gigabit Ethernet interface, enter the keyword `TenGigabitEthernet` then the slot/port information.
- For a 40-Gigabit Ethernet interface, enter the keyword `fortyGigE` then the slot/port information.

Defaults

none



Command Modes

- EXEC
- EXEC Privilege

Command History

This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following is a list of the Dell Networking OS version history for this command.

Version	Description
9.8(0.0)	Introduced on the M I/O Aggregator.

Example

```
Dell#show hardware counters interfac tengigabitethernet 5/1
unit: 0 port: 2 (interface Te 5/1)
Description                                     Value
RX - IPv4 L3 Unicast Frame Counter                0
RX - IPv4 L3 Routed Multicast Packets              0
RX - IPv6 L3 Unicast Frame Counter                0
RX - IPv6 L3 Routed Multicast Packets              0
RX - Unicast Packet Counter                       0
RX - 64 Byte Frame Counter                        0
RX - 65 to 127 Byte Frame Counter                  0
RX - 128 to 255 Byte Frame Counter                  0
RX - 256 to 511 Byte Frame Counter                  0
RX - 512 to 1023 Byte Frame Counter                 0
RX - 1024 to 1518 Byte Frame Counter                 0
RX - 1519 to 1522 Byte Good VLAN Frame Counter     0
RX - 1519 to 2047 Byte Frame Counter                 0
RX - 2048 to 4095 Byte Frame Counter                 0
RX - 4096 to 9216 Byte Frame Counter                 0
RX - Good Packet Counter                          0
RX - Packet/Frame Counter                         0
RX - Unicast Frame Counter                         0
RX - Multicast Frame Counter                       0
RX - Broadcast Frame Counter                       0
RX - Byte Counter                                 0
RX - Control Frame Counter                         0
RX - Pause Control Frame Counter                   0
RX - Oversized Frame Counter                       0
RX - Jabber Frame Counter                          0
RX - VLAN Tag Frame Counter                        0
RX - Double VLAN Tag Frame Counter                  0
RX - RUNT Frame Counter                           0
RX - Fragment Counter                              0
RX - VLAN Tagged Packets                           0
RX - Ingress Dropped Packet                        0
RX - MTU Check Error Frame Counter                  0
RX - PFC Frame Priority 0                           0
RX - PFC Frame Priority 1                           0
RX - PFC Frame Priority 2                           0
RX - PFC Frame Priority 3                           0
RX - PFC Frame Priority 4                           0
RX - PFC Frame Priority 5                           0
RX - PFC Frame Priority 6                           0
RX - PFC Frame Priority 7                           0
RX - Debug Counter 0                               0
RX - Debug Counter 1                               0
RX - Debug Counter 2                               0
<output truncated for brevity>
```



show hardware buffer interface

Display buffer statistics for a specific interface.

Syntax `show hardware buffer interface interface{priority-group { id | all } | queue { id | all} ] buffer-info`

Parameters

interface <i>interface</i>	Enter any of the following keywords and slot/port or number information: - For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. - For a 40-Gigabit Ethernet interface, enter the keyword <code>fortyGigE</code> then the slot/port information.
priority-group	Identifier of the priority group in the range of 0 to 7.
queue	Enter the keyword <code>queue</code> followed by <i>id</i> for specific queue or keyword <code>all</code> .
buffer-info	To display total buffer information for the interface, enter the keywords <code>buffer-info</code> .

Command Modes

EXEC

EXEC Privilege

Command History

Version	Description
9.8(0.0)	Introduced on the M I/O Aggregator and FN I/O Aggregator.

Example displaying total-buffer information for the interface

```
Dell# show hardware buffer interface tengigabitethernet 1/1 buffer-info
----- Buffer Stats for Interface Te 1/1 -----
Maximum Shared Limit for the Interface: 38336
Default Packet Buffer allocate for the Interface: 120
Used Packet Buffer for the Interface: 0
```

Example displaying priority-group range

```
Dell#show hardware buffer interface tengigabitethernet 1/1 priority-group
0 buffer-info
----- Buffer stats for unit: 0 port: 1 (interface Te 1/1) -----
-----
PG# PRIORITIES          MIN      SHARED  MODE   HDRM   MIN      SHARED  HDRM
-----
0   -                61440    0      STATIC  174    0        0        0

Dell#
```

Example displaying queue range

```
Dell#show hardware buffer interface tengigabitethernet 1/1 queue all
buffer-info
----- Buffer Stats for Interface Te 1/1 Queue 0 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 1 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 2 -----
```



```

Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 3 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 4 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 5 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 6 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 7 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 8 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 9 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 10 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8
Used Packet Buffer: 0
----- Buffer Stats for Interface Te 1/1 Queue 11 -----
Maximum Shared Limit: 29514
Default Packet Buffer allocate for the Queue: 8

```

<output truncated for brevity>

show hardware system-flow

Display Layer 2 ACL or QoS data for the selected stack member and stack member port-pipe.

Syntax `show hardware system-flow layer2 stack-unit 0-5 port-set 0-0 [counters]`

Parameters

acl qos	For the selected stack member and stack member port-pipe, display which system flow entry the packet hits and what queue the packet takes as it dumps the raw system flow tables.
stack-unit 0-5	Enter the keywords <code>stack-unit</code> then 0 to 5 to select a stack member ID.
port-set 0-0	Enter the keywords <code>port-set</code> with a port-pipe number—0.
[counters]	(OPTIONAL) Enter the keyword <code>counters</code> to display hit counters for the selected ACL or QoS option.

Defaults none



Command Modes EXEC Privilege

Supported Modes All Modes

Command History

Version	Description
8.3.17.0	Supported on the M I/O Aggregator.

Example

```
Dell#show hardware system-flow layer2 stack-unit 0 port-set 0 counters
```

EntryId	Description	#HITS
2048	STP BPDU Redirects	0
2047	LLDP BPDU Redirects	164904
2045	LACP traffic Redirects	0
2044	GVRP traffic Redirects	0
2043	ARP Reply Redirects	0
2042	802.1x frames Redirects	0
2041	VRRP frames Redirects	0
2040	IPv6VRRP frames Redirects	0
2039	GRAT ARP	0
2036	IPv6 Mcast Control Traffic	128840
2000	VLT ARP SYNC Frames	0
1999	ICL Hellos	0
1998	ICL MAC SYNC Frames	0
1997	VLT Tunneled STP Frames	0
1995	DROP Cases	43207
1917	L3 Term Traffic ClassID 1 to Q6	0
1916	L3 CPU Bound Traffic ClassId 2 to Q5	0
1915	Unknown MCAST Packets	0
1792	BGP with TTL1, L4 SRC port Redirects	0
1791	BGP with TTL1, L4 DST Port Redirects	0
25		

```
Dell#
```

Example (non-counters)

```
Dell#show hardware system-flow layer2 stack-unit 0 port-set 0
```

```
##### FP Entry for redirecting STP BPDU to CPU Port
#####
EID 2048: gid=1,
        slice=15, slice_idx=0x00, prio=0x800, flags=0x82, Installed
        tcam: color_indep=0, higig=0, higig_mask=0,
        KEY=0x00000000 00000000 00000000 0180c200 00000000 00000000
00000000
, FPF4=0x00
        MASK=0x00000000 00000000 00000000 ffffffff ffff0000 00000000
00000000
,      0x00
        action={act=Drop, param0=0(0x00), param1=0(0x00)},
        action={act=CosQCpuNew, param0=7(0x07), param1=0(0x00)},
        action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)},
        action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
        meter=NULL,
        counter={idx=0, mode=0x01, entries=1}

##### FP Entry for redirecting LLDP BPDU to RSM #####
EID 2047: gid=1,
        slice=15, slice_idx=0x01, prio=0x7ff, flags=0x82, Installed
        tcam: color_indep=0, higig=0, higig_mask=0,
        KEY=0x00000000 00000000 00000000 0180c200 000e0000 00000000
00000000
, FPF4=0x00
        MASK=0x00000000 00000000 00000000 ffffffff ffff0000 00000000
00000000
,      0x00
        action={act=Drop, param0=0(0x00), param1=0(0x00)},
        action={act=CosQCpuNew, param0=7(0x07), param1=0(0x00)},
```



```

        action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)},
        action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
        meter=NULL,
        counter={idx=1, mode=0x01, entries=1}

##### FP Entry for redirecting LACP traffic to CPU Port
#####
EID 2045: gid=1,
        slice=15, slice_idx=0x02, prio=0x7fd, flags=0x82, Installed
        tcam: color_indep=0, higig=0, higig_mask=0,
        KEY=0x00000000 00000000 00000000 0180c200 00020000 00000000
00000000
, FPF4=0x00
        MASK=0x00000000 00000000 00000000 ffffffff ffff0000 00000000
00000000
, 0x00
        action={act=Drop, param0=0(0x00), param1=0(0x00)},
        action={act=CosQCpuNew, param0=7(0x07), param1=0(0x00)},
        action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)},
        action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
        meter=NULL,
        counter={idx=2, mode=0x01, entries=1}

##### FP Entry for redirecting GVRP traffic to RSM #####
EID 2044: gid=1,
        slice=15, slice_idx=0x03, prio=0x7fc, flags=0x82, Installed
        tcam: color_indep=0, higig=0, higig_mask=0,
        KEY=0x00000000 00000000 00000000 0180c200 00210000 00000000
00000000
, FPF4=0x00
        MASK=0x00000000 00000000 00000000 ffffffff ffff0000 00000000
00000000
, 0x00
        action={act=Drop, param0=0(0x00), param1=0(0x00)},
        action={act=CosQCpuNew, param0=7(0x07), param1=0(0x00)},
        action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)},
        action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
        meter=NULL,
        counter={idx=3, mode=0x01, entries=1}

##### FP Entry for redirecting ARP Replies to RSM #####
EID 2043: gid=1,
        slice=15, slice_idx=0x04, prio=0x7fb, flags=0x82, Installed
        tcam: color_indep=0, higig=0, higig_mask=0,
        KEY=0x00000000 00000000 00000000 00000000 00000000 00000806
00001600
, FPF4=0x00
        MASK=0x00000000 00000000 00000000 00000000 00000000 0000ffff
00001600
, 0x00
        action={act=Drop, param0=0(0x00), param1=0(0x00)},
        action={act=CosQCpuNew, param0=6(0x06), param1=0(0x00)},
        action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)},
        action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
!----- output truncated -----!

```

show hardware buffer-stats-snapshot

Displays buffer statistics tracking resource information for a specific interface.

Syntax Dell#show hardware stack-unit <id> buffer-stats-snapshot unit <id> resource x



Parameters

buffer-info

buffer-info Displays total buffer information for a group, where x can be one of the following:

- All - Displays ingress and egress device, port, and queue snapshots
- Interface all queue {all} - egress queue-level snapshot for both unicast and multicast packets
- Interface all queue ucast {id | all} - egress queue-level snapshot for unicast packets only
- Interface all queue mcast {id | all} - egress queue-level snapshot for multicast packets only
- Interface all prio-group {id | all} - ingress priority-group level snapshot

buffer-stats-snapshot unit number

Display the historical snapshot of buffer statistical values unit Enter the keyword unit along with a port-pipe number. The range is from 0 to 0.

Command Modes

EXEC

EXEC Privilege

Command History

Version

Description

9.8(0.0)

Introduced on the M I/O Aggregator and the FN I/O Aggregator.

Usage Information

<Interface><slot/port>-Queue ucast/mcast — Displays the total unicast/multicast buffer usage on per-port per-queue basis. For CPU port, counters for queues 0 to11 displays and there is no differentiation between unicast and multicast queues.

Example displaying egress queue-level snapshot for both unicast and multicast packets for the specific interface

```
Dell# show hardware buffer-stats-snapshot resource interface fortyGigE 1/1
queue all
Unit 1 unit: 0 port: 1 (interface Fo 1/1)
```

Q#	TYPE	Q#	TOTAL BUFFERED CELLS
UCAST		0	0
UCAST		1	0
UCAST		2	0
UCAST		3	0
UCAST		4	0
UCAST		5	0
UCAST		6	0
UCAST		7	0
UCAST		8	0
UCAST		9	0
UCAST		10	0
UCAST		11	0
MCAST		0	0
MCAST		1	0
MCAST		2	0
MCAST		3	0
MCAST		4	0
MCAST		5	0
MCAST		6	0
MCAST		7	0
MCAST		8	0



Example displaying
egress queue-level
snapshot for unicast
packets for the
specific interface

```

Dell#show hardware buffer-stats-snapshot resource interface fortyGigE 0/0
queue ucast 10
Unit 0 unit: 0 port: 1 (interface Fo 0/0)
-----
Q#  TYPE      Q#      TOTAL BUFFERED CELLS
-----
UCAST          10          0

Dell#show hardware buffer-stats-snapshot resource interface fortyGigE 0/0
queue ucast all
Unit 0 unit: 0 port: 1 (interface Fo 0/0)
-----
Q#  TYPE      Q#      TOTAL BUFFERED CELLS
-----
UCAST          0          0
UCAST          1          0
UCAST          2          0
UCAST          3          0
UCAST          4          0
UCAST          5          0
UCAST          6          0
UCAST          7          0
UCAST          8          0
UCAST          9          0
UCAST         10          0
UCAST         11          0

```

Example displaying
egress queue-level
snapshot for
multicast packets for
the specific interface

```

Dell#show hardware buffer-stats-snapshot resource interface fortyGigE 0/0
queue mcast 3
Unit 1 unit: 0 port: 1 (interface Fo 0/0)
-----
Q#  TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST          3          0

Dell#show hardware buffer-stats-snapshot resource interface fortyGigE 0/0
queue mcast all
Unit 0 unit: 0 port: 1 (interface Fo 0/0)
-----
Q#  TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST          0          0
MCAST          1          0
MCAST          2          0
MCAST          3          0
MCAST          4          0
MCAST          5          0
MCAST          6          0
MCAST          7          0
MCAST          8          0

```

Example displaying
ingress priority-
group level snapshot
for the specific
interface

```

Dell#show hardware buffer-stats-snapshot resource interface fortyGigE 1/1
priority-group 7
Unit 1 unit: 0 port: 1 (interface Fo 1/1)
-----
PG#      SHARED CELLS      HEADROOM CELLS
-----
7         0                0

Dell#show hardware buffer-stats-snapshot resource interface fortyGigE 1/1
priority-group all
Unit 1 unit: 0 port: 1 (interface Fo 1/1)
-----

```

PG#	SHARED CELLS	HEADROOM CELLS
0	0	0
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0

```
Dell#show hardware buffer-stats-snapshot resource interface fortyGigE 0/0
priority-group 7
```

```
Unit 0 unit: 0 port: 1 (interface Fo 0/0)
```

PG#	SHARED CELLS	HEADROOM CELLS
7	0	0

```
Dell#show hardware buffer-stats-snapshot resource interface fortyGigE 0/0
priority-group all
```

```
Unit 0 unit: 0 port: 1 (interface Fo 0/0)
```

PG#	SHARED CELLS	HEADROOM CELLS
0	0	0
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0

show hardware stack-unit buffer-stats-snapshot (Total Buffer Information)

View the buffer statistics tracking resource information depending on the type of buffer information, such as device-level details, port-level counters, queue-based snapshots, or priority group-level snapshot in the egress and ingress direction of traffic.

Syntax

```
show hardware stack-unit {id} buffer-stats-snapshot unit {id} resource
interface all {priority-group { id | all } | queue { ucast{id | all}{ mcast
{id | all} | all}}
```

Parameters

stack-unit *stack-unit-number*

Unique ID of the stack unit to select a particular stack member and then enter one of the following command options to display a collection of data based on the option entered. The range is from 0 to 11.

buffer-stats-snapshot unit *number*

Display the historical snapshot of buffer statistical values unit Enter the keyword unit along with a port-pipe number. The range is from 0 to 0.

buffer-info

buffer-info Displays total buffer information for a group, where x can be one of the following:

- All - Displays ingress and egress device, port, and queue snapshots



- Interface all queue {all} - egress queue-level snapshot for both unicast and multicast packets
- Interface all queue ucast {id | all} - egress queue-level snapshot for unicast packets only
- Interface all queue mcast {id | all} - egress queue-level snapshot for multicast packets only
- Interface all prio-group {id | all} - ingress priority-group level snapshot

Command Modes EXEC

EXEC Privilege

Command History

Version	Description
9.8(0.0)	Introduced on the MI/O Aggregator, and FN I/O Aggregator.

Usage Information

The following information is displayed based on the buffer-info type, such as device-level details, queue-based snapshots, or priority group-level snapshot in the egress and ingress direction of traffic:

- Device-ingress – Displays total buffer accounting usage for the unit.
- Device-egress – Display total buffer usage for the unit, total multicast buffer usage for the unit and also on per-service-pool basis. Counters will be displayed for the 2 service-pools – one for normal traffic and other for DCB traffic.

When the buffer-stats-snapshot is disabled, the following informational message is displayed when you run the show command: %Info: Buffer-stats-snapshot feature is disabled.

Example

```
Dell#show hardware stack-unit 1 buffer-stats-snapshot unit 3 resource
interface all queue mcast 3
Unit 1 unit: 3 port: 1 (interface Fo 1/144)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0

Unit 1 unit: 3 port: 5 (interface Fo 1/148)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0

Unit 1 unit: 3 port: 9 (interface Fo 1/152)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0

Unit 1 unit: 3 port: 13 (interface Fo 1/156)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0

Unit 1 unit: 3 port: 17 (interface Fo 1/160)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0
```



```

Unit 1 unit: 3 port: 21 (interface Fo 1/164)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0

Unit 1 unit: 3 port: 25 (interface Fo 1/168)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0

Unit 1 unit: 3 port: 29 (interface Fo 1/172)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0

Unit 1 unit: 3 port: 33 (interface Fo 1/176)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----
MCAST        3        0

Unit 1 unit: 3 port: 37 (interface Fo 1/180)
-----
Q# TYPE      Q#      TOTAL BUFFERED CELLS
-----

```

show hardware drops

Displays internal drops on the specified interface or for a range of interface.

Syntax `show hardware drops interface interface`

Parameters

interface	Enter any of the following keywords and slot/port or slot/port-range or number information:
	- For a 10-Gigabit Ethernet interface, enter the keyword <code>TenGigabitEthernet</code> then the slot/port information. - For a 40-Gigabit Ethernet interface, enter the keyword <code>fortyGigE</code> then the slot/port information.
drops	Enter the keyword <code>drops</code> to display internal drops.

Command Modes

EXEC
EXEC Privilege

Command History

This guide is platform-specific. For command information about other platforms, refer to the relevant *Dell Networking OS Command Line Reference Guide*.

The following is a list of the Dell Networking OS version history for this command.



Version	Description
9.8(0.0)	Introduced on the M I/O Aggregator and the FN I/O Aggregator.

Example displaying internal drops for the specific interface Dell#show hardware drops interface tengigabitethernet 2/1

```

Drops in Interface Te 2/1:
--- Ingress Drops ---
Ingress Drops : 0
IBP CBP Full Drops : 0
PortSTPnotFwd Drops : 0
IPv4 L3 Discards : 0
Policy Discards : 0
Packets dropped by FP : 0
(L2+L3) Drops : 0
Port bitmap zero Drops : 0
Rx VLAN Drops : 0
--- Ingress MAC counters---
Ingress FCSDrops : 0
Ingress MTUExceeds : 0
--- MMU Drops ---
Ingress MMU Drops : 0
HOL DROPS (TOTAL) : 0
HOL DROPS on COS0 : 0
HOL DROPS on COS1 : 0
HOL DROPS on COS2 : 0
HOL DROPS on COS3 : 0
HOL DROPS on COS4 : 0
HOL DROPS on COS5 : 0
HOL DROPS on COS6 : 0
HOL DROPS on COS7 : 0
HOL DROPS on COS8 : 0
HOL DROPS on COS9 : 0
HOL DROPS on COS10 : 0
HOL DROPS on COS11 : 0
HOL DROPS on COS12 : 0
HOL DROPS on COS13 : 0
HOL DROPS on COS14 : 0
HOL DROPS on COS15 : 0
HOL DROPS on COS16 : 0
HOL DROPS on COS17 : 0
TxPurge CellErr : 0
Aged Drops : 0
--- Egress MAC counters---
Egress FCS Drops : 0
--- Egress FORWARD PROCESSOR Drops ---
IPv4 L3UC Aged & Drops : 0
TTL Threshold Drops : 0
INVALID VLAN CNTR Drops : 0
L2MC Drops : 0
PKT Drops of ANY Conditions : 0
Hg MacUnderflow : 0
TX Err PKT Counter : 0
--- Error counters---
Internal Mac Transmit Errors : 0
Unknown Opcodes : 0
Internal Mac Receive Errors : 0

```



Internet Control Message Protocol (ICMP) Message Types

This chapter lists and describes the possible ICMP message type resulting from a ping. The first three columns list the possible symbol or type/code. For example, you would receive a ! or 03 as an echo reply from your ping.

Table 1. ICMP Messages and Their Definitions

Symbol	Type	Code	Description	Query	Error
.			Timeout (no reply)		
!	0	3	echo reply	.	
U	3		destination unreachable:		
		0	network unreachable		.
		1	host unreachable		.
		2	protocol unreachable		.
		3	port unreachable		.
		4	fragmentation needed but don't fragment bit set		.
		5	source route failed		.
		6	destination network unknown		.
		7	destination host unknown		.
		8	source host isolated (obsolete)		.
		9	destination network administratively prohibited		.
		10	destination host administratively prohibited		.
		11	network unreachable for TOS		.
		12	host unreachable for TOS		.
		13	communication administratively prohibited by filtering		.
		14	host precedence violation		.
		15	precedence cutoff in effect		.
C	4	0	source quench		.
	5		redirect		.
		0	redirect for network		.
		1	redirect for host		.
		2	redirect for type-of-service and network		.
		3	redirect for type-of-service and host		.

Symbol	Type	Code	Description	Query	Error
&	8	0	echo request	.	
	9	0	router advertisement	.	
	10	0	router solicitation	.	
	11		time exceeded:		
		0	time-to-live equals 0 during transit		.
		1	time-to-live equals 0 during reassembly		.
	12		parameter problem:		
		1	IP header bad (catchall error)		.
		2	required option missing		.
	13	0	timestamp request	.	
	14	0	timestamp reply	.	
	15	0	information request (obsolete)	.	
	16	0	information reply (obsolete)	.	
	17	0	address mask request	.	
	18	0	address mask reply	.	

