

## **Operating Instructions**

Digital Cordless Phone Model No. KX-TG5511CX KX-TG6511CX KX-TG6512CX



Model shown is KX-TG5511. Model shown is KX-TG6511.



#### Thank you for purchasing a Panasonic product.

Please read these operating instructions before using the unit and save them for future reference.

This unit is compatible with Caller ID. You must subscribe to the appropriate service offered by your service provider/telephone company.

TG5511-6511-6512CX(e-e).book Page 2 Tuesday, May 11, 2010 11:46 AM

Index



#### Important Information Important safety instructions . . . . . . 6 For best performance ..... 6 Specifications .....7 Getting Started Setting up ..... 8 Note when setting up. . . . . . . . . . . . . . . . 9 Turning the power on/off . . . . . . . . 13 Making/Answering Calls Useful features during a call . . . . . . 16 Phonebook Copying phonebook entries. . . . . . 19 Programming Special programming .....24 **Caller ID Service Voice Mail Service** Intercom/Locator Transferring calls, conference calls. . 30 **Useful Information** 2

Table of Contents



TG5511-6511-6512CX(e-e).book Page 3 Tuesday, May 11, 2010 11:46 AM



#### **Model composition**

Series	Model No.	Base unit	Handset		
Series	woder No.	Part No.	Part No.	Quantity	
KX-TG5511 series	KX-TG5511 <sup>*1</sup>	KX-TG5511	KX-TGA550	1	
KX-TG6511	KX-TG6511 <sup>*1</sup>	KX-TG6511	KX-TGA650	1	
series	KX-TG6512	KX-TG6511	KX-TGA650	2	

\*1 Feature differences: Intercom calls can be made between the handsets by purchasing and registering one or more optional handsets (page 4).

• The suffix (CX) in the following model numbers will be omitted in these instructions: KX-TG5511CX/KX-TG6511CX/KX-TG6512CX

### Accessory information

#### Supplied accessories

		Quantity			
No.	Accessory item/Part number	KX-TG5511 KX-TG6511	KX-TG6512		
1	AC adaptor/PQLV219BX	1	2		
2	Telephone line cord	1	1		
3	Rechargeable batteries <sup>*1</sup> / HHR-55AAAB or N4DHYYY00001	2	4		
4	Handset cover <sup>*2</sup>	1	2		
5	Charger	—	1		

\*1 See page 4 for replacement battery information.

\*2 The handset cover comes attached to the handset.







TG5511-6511-6512CX(e-e).book Page 4 Tuesday, May 11, 2010 11:46 AM



#### Introduction

#### Additional/replacement accessories

Please contact your nearest Panasonic dealer for sales information.

Accessory item	Model number
Rechargeable	HHR-4DPA or HHR-4MRT <sup>*1</sup>
batteries	Battery type:
	<ul> <li>Nickel metal hydride (Ni-MH)</li> </ul>
	<ul> <li>2 x AAA (R03) size for each handset</li> </ul>
DECT repeater	KX-A272

\*1 Replacement batteries may have a different capacity from that of the supplied batteries.

#### Expanding your phone system

You can expand your phone system by registering optional handsets (6 max.) to a single base unit.

• Optional handsets may be a different colour from that of the supplied handsets.

#### ■ KX-TG5511

#### KX-TG6511/KX-TG6512

Handset (optional): KX-TGA551CX Handset (optional): KX-TGA651CX







\_\_\_\_\_

TG5511-6512CX(e-e).book Page 5 Tuesday, May 11, 2010 11:46 AM

#### For your safety

To prevent severe injury and loss of life/property, read this section carefully before using the product to ensure proper and safe operation of your product.

#### WARNING

#### Power connection

- Use only the power source marked on the product.
- Do not overload power outlets and extension cords. This can result in the risk of fire or electric shock.
- Completely insert the AC adaptor/power plug into the power outlet. Failure to do so may cause electric shock and/or excessive heat resulting in a fire.
- Regularly remove any dust, etc. from the AC adaptor/power plug by pulling it from the power outlet, then wiping with a dry cloth. Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire.
- Unplug the product from power outlets if it emits smoke, an abnormal smell, or makes an unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped emitting and contact an authorised service centre.
- Unplug from power outlets and never touch the inside of the product if its casing has been broken open.
- Never touch the plug with wet hands. Danger of electric shock exists.

#### Installation

- To prevent the risk of fire or electrical shock, do not expose the product to rain or any type of moisture.
- Do not place or use this product near automatically controlled devices such as automatic doors and fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.
- Do not allow the AC adaptor or telephone line cord to be excessively pulled, bent or placed under heavy objects.

#### Important Information

#### **Operating safeguards**

- Unplug the product from power outlets before cleaning. Do not use liquid or aerosol cleaners.
- Do not disassemble the product.
- Do not spill liquids (detergents, cleansers, etc.) onto the telephone line cord plug, or allow it to become wet at all. This may cause a fire. If the telephone line cord plug becomes wet, immediately pull it from the telephone wall jack, and do not use.

#### Medical

- Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids, to determine if they are adequately shielded from external RF (radio frequency) energy. (The product operates in the frequency range of 1.88 GHz to 1.90 GHz, and the RF transmission power is 250 mW (max.).)
- Do not use the product in health care facilities if any regulations posted in the area instruct you not to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

#### CAUTION

#### Installation and location

- Never install telephone wiring during an electrical storm.
- Never install telephone line jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.
- The AC adaptor is used as the main disconnect device. Ensure that the AC outlet is installed near the product and is easily accessible.
- This product is unable to make calls when:
   the handset batteries need recharging or have failed.

5

- there is a power failure.
- the key lock feature is turned on.

#### TG5511-6512CX(e-e).book Page 6 Tuesday, May 11, 2010 11:46 AM

#### Important Information

#### Battery

- We recommend using the batteries noted on page 4. USE ONLY rechargeable Ni-MH batteries AAA (R03) size.
- Do not mix old and new batteries.
- Do not open or mutilate the batteries. Released electrolyte from the batteries is corrosive and may cause burns or injury to the eyes or skin. The electrolyte is toxic and may be harmful if swallowed.
- Exercise care when handling the batteries. Do not allow conductive materials such as rings, bracelets, or keys to touch the batteries, otherwise a short circuit may cause the batteries and/or the conductive material to overheat and cause burns.
- Charge the batteries provided with or identified for use with this product only, in accordance with the instructions and limitations specified in this manual.
- Only use a compatible base unit (or charger) to charge the batteries. Do not tamper with the base unit (or charger).
   Failure to follow these instructions may cause the batteries to swell or explode.

## Important safety instructions

When using your product, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following: 1. Do not use this product near water for

- Do not use this product near water for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement or near a swimming pool.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- 3. Do not use the telephone to report a gas leak in the vicinity of the leak.
- Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

SAVE THESE INSTRUCTIONS

6

#### For best performance

#### Base unit location/avoiding noise

The base unit and other compatible Panasonic units use radio waves to communicate with each other.

- For maximum coverage and noise-free communications, place your base unit:
  - at a convenient, high, and central location with no obstructions between the handset and base unit in an indoor environment.
  - away from electronic appliances such as TVs, radios, personal computers, wireless devices, or other phones.
- facing away from radio frequency transmitters, such as external antennas of mobile phone cell stations. (Avoid putting the base unit on a bay window or near a window.)
- Coverage and voice quality depends on the local environmental conditions.
- If the reception for a base unit location is not satisfactory, move the base unit to another location for better reception.

#### Environment

- Keep the product away from electrical noise generating devices, such as fluorescent lamps and motors.
- The product should be kept free from excessive smoke, dust, high temperature, and vibration.
- The product should not be exposed to direct sunlight.
- Do not place heavy objects on top of the product.
- When you leave the product unused for a long period of time, unplug the product from the power outlet.
- The product should be kept away from heat sources such as radiators, cookers, etc. It should not be placed in rooms where the temperature is less than 0 °C or greater than 40 °C. Damp basements should also be avoided.
- The maximum calling distance may be shortened when the product is used in the following places: Near obstacles such as hills, tunnels, underground, near metal objects such as wire fences, etc.

#### TG5511-6511-6512CX(e-e).book Page 7 Tuesday, May 11, 2010 11:46 AM



7

• Operating the product near electrical appliances may cause interference. Move away from the electrical appliances.

#### Routine care

- Wipe the outer surface of the product with a soft moist cloth.
- Do not use benzine, thinner, or any abrasive powder.

#### Other information

### Notice for product disposal, transfer, or return

 This product can store your private/ confidential information. To protect your privacy/confidentiality, we recommend that you erase information such as phonebook or caller list entries from the memory before you dispose of, transfer, or return the product.

### Information on Disposal in other Countries outside the European Union



These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

#### Specifications

- Standard:
  - DECT (Digital Enhanced Cordless Telecommunications), GAP (Generic Access Profile)
- Frequency range: 1.88 GHz to 1.90 GHz
- RF transmission power: Approx. 10 mW (average power per channel)

#### Important Information

- Power source: 100–240 V AC, 50/60 Hz
   Power consumption: Base unit: Standby: Approx. 0.45 W Maximum: Approx. 3.8 W Charger: Standby: Approx. 0.2 W Maximum: Approx. 3.0 W
- Operating conditions: 0 °C - 40 °C, 20 % - 80 % relative air humidity (dry)

#### Note:

- Design and specifications are subject to change without notice.
- The illustrations in these instructions may vary slightly from the actual product.





#### TG5511-6511-6512CX(e-e).book Page 9 Tuesday, May 11, 2010 11:46 AM

# Getting Started

#### **Battery installation**

- USE ONLY Ni-MH batteries AAA (R03) size.
- Do NOT use Alkaline/Manganese/ Ni-Cd batteries.
- Confirm correct polarities  $(\bigoplus, \bigcirc)$ .



Rechargeable Ni-MH ONLY

• When the language selection is displayed, see page 13.

#### **Battery charge**

Charge for about 7 hours.

• When the batteries are fully charged, the charge indicator goes off and "Fully charged" is displayed.



#### Note when setting up

#### Note for connections

- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- The AC adaptor should be connected to a vertically oriented or floormounted AC outlet. Do not connect the AC adaptor to a ceiling-mounted AC outlet, as the weight of the adaptor may cause it to become disconnected.

#### During a power failure

The unit will not work during a power failure. We recommend connecting a corded-type telephone (without AC adaptor) to the same telephone line or to the same telephone line jack using a Tadaptor.

#### Note for battery installation

- Use the supplied rechargeable batteries. For replacement, we recommend using the Panasonic rechargeable batteries noted on page 4, 6.
- Wipe the battery ends (⊕, ⊝) with a dry cloth.
- Avoid touching the battery ends
   (⊕, ⊖) or the unit contacts.

#### Note for battery charge

- It is normal for the handset to feel warm during charging.
- Clean the charge contacts of the handset, base unit, and charger with a soft and dry cloth once a month. Clean more often if the unit is exposed to grease, dust, or high humidity.

9



TG5511-6511-6512CX(e-e).book Page 10 Tuesday, May 11, 2010 11:46 AM

#### Getting Started

#### **Battery level**

lcon	Battery level				
	High				
	Medium				
	Low				
<u>)</u>	Needs charging.				

## Panasonic Ni-MH battery performance (supplied batteries)

Operation	Operating time
In continuous use	18 hours max.
Not in use (standby)	170 hours max.

#### Note:

10

- It is normal for batteries not to reach full capacity at the initial charge.
   Maximum battery performance is reached after a few complete cycles of charge/discharge (use).
- Actual battery performance depends on usage and ambient environment.
- Even after the handset is fully charged, the handset can be left on the base unit or charger without any ill effect on the batteries.
- The battery level may not be displayed correctly after you replace the batteries. In this case, place the handset on the base unit or charger and let it charge for at least 7 hours.

#### Controls

#### Handset

#### ■ KX-TG5511



- Ringer indicator
- Ø Speaker
- 3 [ ] (Talk)
- ④ [♣] (Speakerphone)
- Dial keypad
- 6 Receiver
- ⑦ Display
  ③ [☆⊕] (Off/Power)
- **(**ECO/R)
  - ECO: Eco mode shortcut key R: Recall/Flash





TG5511-6511-6512CX(e-e).book Page 12 Tuesday, May 11, 2010 11:46 AM

Item



## Base unit • KX-TG5511 • Charge contacts @ [-w]] (Locator) • KX-TG6511/KX-TG6512 • Charge contacts

Getting Started

Charge contacts
 [••))] (Locator)

Display

Item

Ψ

Handset display items

Meaning

Within base unit range

啩	Speakerphone is on. (page 15)				
ſ	<ul> <li>The line is in use.</li> <li>When flashing slowly: The call is put on hold.</li> <li>When flashing rapidly: An incoming call is now being received.</li> </ul>				
<b>*)</b>	Missed call <sup>*1</sup> (page 27)				
ECO	The base unit transmission power is set to "Low". (page 14)				
*	The LCD and key backlight is off. (page 22)				
	Battery level				
Ð	Alarm is on. (page 24)				
X	Privacy mode is on. (page 22)				
æ	Ringer volume is off. (page 22)				
Mew voice mail message received.*2 (page 29)       Line     Someone is using the line.					
				*** ~ ** **	

Meaning

\*1 Caller ID subscribers only

\*2 Voice mail subscribers only

#### Soft key icons

lcon	Action
1	Returns to the previous screen or outside call.
	Displays the menu.
ОК	Accepts the current selection.
	Displays a previously dialled phone number.



#### TG5511-6511-6512CX(e-e).book Page 13 Tuesday, May 11, 2010 11:46 AM



#### Action Icon Makes a call. (page 15) Ø Temporarily turns off the ringer for incoming calls. (page 16) 12/24 Sets 24-hour or 12-hour clock format. (page 14) <u>,</u> Places a call on hold. (page 30) $\mathbf{i}$ Opens the phonebook. Allows you to edit phone numbers. (page 28) Adds new entry. (page 18) Ø Displays the character entry mode for phonebook search. (page 18) Turns the key lock feature **F**0 off. (page 17) 1/A/? Selects a character entry mode. Ľ Stores phone numbers. (page 28) Р Inserts a dialling pause. Erases the selected item or X returns to the outside call. •))) Allows you to make an intercom call. (page 30) $\forall$ Establishes a conference call. (page 30) С Erases a number/character. Ø Puts the call on mute.

#### Getting Started

## Turning the power on/off

#### Power on

Press [ \* • ] for about 1 second.

#### Power off

Press [ \* ()] for about 2 seconds.

#### **Initial settings**

Symbol meaning: Example: [v]/[]: "Off" Press [v] or [] to select the words in quotations.

#### **Display language**

#### Important:

• When the language selection is displayed after installing the batteries for the first time, perform step 2.

[#][1][1][0]
 [▼]/[▲]: Select your desired language. → OK → [☆Φ]

#### **Dialling mode**

If you cannot make calls, change this setting according to your telephone line service. The default setting is "Tone". "Tone": For tone dial service. "Pulse": For rotary/pulse dial service.

#### 1 $\square \rightarrow [\#][1][2][0]$

2  $[\mathbf{v}]/[\mathbf{A}]$ : Select the desired setting.  $\rightarrow \mathbf{OK} \rightarrow [\mathbf{A} \bigcirc]$ 





#### TG5511-6511-6512CX(e-e).book Page 14 Tuesday, May 11, 2010 11:46 AM



#### Getting Started

#### Date and time

- 1  $\square \rightarrow [\#][1][0][1]$
- 2 Enter the current date, month, and year. → OK Example: 15 July, 2010
  - [1][5] [0][7] [1][0]
- 3 Enter the current hour and minute. Example: 9:30 [0][9] [3][0]
  - You can select 24-hour or 12-hour clock format ("AM" or "PM") by pressing [2/24].

#### 4 OK $\rightarrow$ [ $\checkmark \oplus$ ]

#### Note:

14

- To correct a digit, press [ ◄] or [ ►] to move the cursor to the digit, then make the correction.
- The date and time may be incorrect after a power failure. In this case, set the date and time again.

#### One touch eco mode

The **[ECO/R]** button on the handset enables you to activate the eco function with one touch.

By activating eco mode, your unit can reduce the base unit transmission power by up to 90% in standby mode.

You can turn on/off one touch eco mode by just pressing **[ECO/R]**. The default setting is "Normal".

- When the one touch eco mode is on:
   "Low" is temporarily displayed and
   ECO is shown on the handset display instead of ♥.
- When the one touch eco mode is off:
   "Normal" is temporarily displayed and Eco goes off from the handset display.

#### Note:

- When there is another cordless phone nearby and it is in use, the base unit transmission power may not be reduced.
- Activating one touch eco mode reduces the range of the base unit in standby mode.
- If you set the repeater mode to "on" (page 26):
  - One touch eco mode is cancelled.
  - "Eco Setup" is not shown in the display menu (page 20).

#### TG5511-6511-6512CX(e-e).book Page 15 Tuesday, May 11, 2010 11:46 AM



#### Making calls

1 Lift the handset and dial the phone number.

• To correct a digit, press **C**.

- 2 Press [ ~ ] or .
- When you finish talking, press
   (べ) or place the handset on the base unit or charger.

#### Using the speakerphone

- 1 Dial the phone number and press [땨].
  - Speak alternately with the other party.
- 2 When you finish talking, press 【べひ】.

#### Note:

- For best performance, use the
- speakerphone in a quiet environment.To switch back to the receiver, press

## Adjusting the receiver or speaker volume

Press (▲) or (▼) repeatedly while talking.

#### Making a call using the redial list

The last 10 phone numbers dialled are stored in the redial list (each 24 digits max.).

- 1 (◯ or (►) (◯)
- 2 **[v]**/**[**▲**]**: Select the desired phone number.
- 3 [~]

#### Erasing a number in the redial list

- **1 (○)** or **(**►**)** (○)
- 2 [▼]/[▲]: Select the desired phone number. → X

#### Making/Answering Calls

## $\frac{3 \quad [v]/[A]: "Yes" \rightarrow OX \rightarrow [\% 0]}{Pause (for PBX/long distance service}$

**users)** A pause is sometimes required when making calls using a PBX or long distance service. When storing a calling card access number and/or PIN in the phonebook, a pause is also needed (page 19).

**Example:** If you need to dial the line access number "0" when making outside calls with a PBX:

#### $1 \quad [0] \rightarrow \mathbb{P}$

2 Dial the phone number.  $\rightarrow$  [ $\frown$ ] Note:

 A 3 second pause is inserted each time P is pressed. Repeat as needed to create longer pauses.

#### Answering calls

When a call is being received, the ringer indicator flashes rapidly.

- 1 Lift the handset and press [ ⌒ ] or [☞] when the unit rings.
  - You can also answer the call by pressing any dial key from [0] to [9], [\*], or [#]. (Any key answer feature)
- 2 When you finish talking, press 【べひ】 or place the handset on the base unit or charger.

#### Auto talk

You can answer calls simply by lifting the handset off the base unit or charger. You do not need to press [ ]. To turn this feature on, see page 22.





TG5511-6511-6512CX(e-e).book Page 16 Tuesday, May 11, 2010 11:46 AM



#### Making/Answering Calls

Adjusting the handset ringer volume Press [ ] or [ ] repeatedly to select the desired volume while the handset is ringing for an incoming call.

Note:

• You can also program the handset ringer volume beforehand (page 21).

#### Temporary handset ringer off

While the handset is ringing for a call, you can turn the ringer off temporarily by pressing a.

## Useful features during a call

#### Hold

This feature allows you to put an outside call on hold.

1 Press 🗐 during an outside call.

2 [v]/[A]: "Hold"  $\rightarrow$  OK

- **3** To release hold, press [ . ].
  - Another handset user can take the call by pressing [ ].

#### Note:

- If a call is kept on hold for more than 9 minutes, an alarm tone starts to sound and the ringer indicator flashes rapidly. After 1 additional minute on hold, the call is disconnected.
- If another phone is connected to the same line (page 9), you can also take the call by lifting its handset.

#### Mute

16

While mute is turned on, you can hear the other party, but the other party cannot hear you.

Press X during conversation.
I flashes.

2 To return to the conversation, press again.

#### **Recall/flash**

**[ECO/R]** allows you to use the special features of your host PBX such as transferring an extension call, or accessing optional telephone services.

#### Note:

 To change the recall/flash time, see page 22.

## For call waiting or Call Waiting Caller ID service users

To use call waiting, you must first subscribe to call waiting from your service provider/telephone company. This feature allows you to receive calls while you are already talking on the phone. If you receive a call while on the phone, you will hear a call waiting tone. If you subscribe to both Caller ID and Call Waiting with Caller ID services, the 2nd caller's information is displayed after you hear the call waiting tone on the handset.

- 1 Press [ECO/R] to answer the 2nd call.
- 2 To switch between calls, press [ECO/R].

#### Note:

 Please contact your service provider/telephone company for details and availability of this service in your area.

## Temporary tone dialling (for rotary/pulse service users)

You can temporarily switch the dialling mode to tone when you need to access touch-tone services (for example, telephone banking services).

**1** Make a call.

•

TG5511-6511-6512CX(e-e).book Page 17 Tuesday, May 11, 2010 11:46 AM



2 Press [\*] when prompted to enter your code or PIN, then press the appropriate dial keys.

#### Note:

• The dialling mode will return to pulse when you hang up.

#### Call share

You can join an existing outside call. To join the conversation, press [ ~ ] when the other handset is on an outside call.

Note:

 To prevent other users from joining your conversations with outside callers, turn the privacy mode on (page 22).

#### Key lock

The handset can be locked so that no calls or settings can be made. Incoming calls can be answered, but all other functions are disabled while key lock is on.

To turn key lock on, press 🗐 for about 3 seconds.

- **FO** is displayed.
- To turn key lock off, press of for about 3 seconds.

#### Note:

• Calls to emergency numbers cannot be made until key lock is turned off.





TG5511-6511-6512CX(e-e).book Page 18 Tuesday, May 11, 2010 11:46 AM



#### Phonebook

#### Handset phonebook

The phonebook allows you to make calls without having to dial manually. You can add 100 names and phone numbers.

#### **Adding entries**

- 1  $\mathbb{M} \to \mathbb{M}$
- 2 Enter the party's name (16 characters max.).  $\rightarrow$  **OK** 
  - You can change the character entry mode by pressing **TAV2** (page 31).
- 3 Enter the party's phone number (24 digits max.). → OK 2 times
  - To add other entries, repeat from step 2.
- 4 【沐心】

## Finding and calling a phonebook entry

#### Scrolling through all entries

- 1 🖾
- 2 [▼]/[▲]: Select the desired entry.
   You can scroll through the phonebook entry by pressing and holding [▼] or [▲].
- 3 [~]

#### Searching by first character

1 🖾

18

- character entry mode. → OK 2 Press the dial key ([0] to [9], or [#])
- which contains the character you are searching for (page 31).

- Press the same dial key repeatedly to display the first entry corresponding to each character located on that dial key.
- If there is no entry corresponding to the character you selected, the next entry is displayed.
- **3 [▼]/[▲]**: Scroll through the phonebook if necessary.

#### 4 [ ]

#### **Editing entries**

- 1 Find the desired entry (page 18).  $\rightarrow \blacksquare$
- 2 [▼]/[▲]: "Edit" → OK
  3 Edit the name if necessary (16)
- characters max.; page 31).  $\rightarrow \bigcirc$  **K** Edit the phone number if necessary
- (24 digits max.). → OK 2 times → [☆ひ]

#### **Erasing entries**

#### Erasing an entry

- 1 Find the desired entry (page 18).
- 2  $[X] \rightarrow [V]/[A]$ : "Yes"  $\rightarrow OK$  $\rightarrow [\% 0]$

#### Erasing all entries

- $1 \boxtimes \to \blacksquare$
- 2 [v]/[A]: "Erase All"  $\rightarrow$  OK
- 3 [v]/[A]: "Yes"  $\rightarrow$  OK
- 4  $[\mathbf{v}]/[\mathbf{A}]$ : "Yes"  $\rightarrow$   $\mathbf{OK} \rightarrow [\mathbf{T} \oplus]$

\_\_\_\_\_

TG5511-6511-6512CX(e-e).book Page 19 Tuesday, May 11, 2010 11:46 AM



#### Chain dial

This feature allows you to dial phone numbers in the phonebook while you are on a call. This feature can be used, for example, to dial a calling card access number or bank account PIN that you have stored in the phonebook, without having to dial manually.

- 1 During an outside call, press 🔲.
- 2 [v]/[A]: "Phonebook"  $\rightarrow$  OK
- 3  $[\mathbf{v}]/[\mathbf{A}]$ : Select the desired entry.
- 4 Press **T** to dial the number.

#### Note:

- When storing a calling card access number and your PIN in the phonebook as one phonebook entry, press P to add pauses after the number and PIN as necessary (page 15).
- If you have rotary/pulse service, you need to press [\*] before pressing
   in step 1 to change the dialling mode temporarily to tone. When adding entries to the phonebook, we recommend adding [\*] to the beginning of phone numbers you wish to chain dial (page 18).

## Copying phonebook entries

You can copy phonebook entries between 2 handsets.<sup>\*1</sup> \*1 Panasonic compatible handset

#### Copying an entry

- 1 Find the desired entry (page 18).  $\rightarrow \blacksquare$
- 2 [v]/[A]: "Copy"  $\rightarrow$  OK

#### Phonebook

19

- $[\mathbf{v}]/[\mathbf{A}]$ : Select the handset you want to send the phonebook entry to.  $\rightarrow$  **OX**
- When an entry has been copied, "Completed" is displayed.
- To continue copying another entry: [▼]/[▲]: "Yes" → OK → Find the desired entry. →

3

4 [木①]

#### **Copying all entries**

- $1 \boxtimes \to \blacksquare$
- 2  $[\mathbf{v}]/[\mathbf{A}]$ : "Copy All"  $\rightarrow$  OK
- **3 [▼]/[▲**]: Select the handset you
  - want to send the phonebook entry to.  $\rightarrow$  **OK**
  - When all entries have been copied, "Completed" is displayed.
- 4 [木①]



TG5511-6511-6512CX(e-e).book Page 20 Tuesday, May 11, 2010 11:46 AM



#### Programming

#### **Programmable settings**

You can customise the unit by programming the following features using the handset. To access the features, there are 2 methods:

- scrolling through the display menus (page 20)
- using the direct commands (page 21)
- Direct command is the main method used in these operating instructions.

#### Programming by scrolling through the display menus

#### 1 🔳

- 2 Press  $[\mathbf{v}]$  or  $[\mathbf{A}]$  to select the desired main menu.  $\rightarrow$  **OK**
- Press [▼] or [▲] to select the desired item in sub-menu 1. → OK
   In some cases, you may need to select from sub-menu 2. → OK
- 4 Press [v] or [A] to select the desired setting.  $\rightarrow$  **OK** 
  - This step may vary depending on the feature being programmed.
  - To exit the operation, press [メウ].

#### Note:

• See page 21 for the default settings.

Main menu	Sub-menu 1	Sub-menu 2	Page
Caller List ♪)	_	_	27
Time Settings	Set Date/Time <sup>*1</sup>	_	14
<b>e</b>	Alarm	-	24
	Time Adjustment <sup>*1</sup>	_	-
Ringer Setup	Ringer Volume (Handset)	-	-
	Ringtone	-	-
Intercom •))	_	_	30
Initial Setup	Ringer Setup	Ringer Volume	-
<b>3-</b> C		Ringtone	-
	Time Settings	Set Date/Time <sup>*1</sup>	14
		Alarm	24
		Time Adjustment <sup>*1</sup>	-
	Handset Name	_	24
	Eco Setup	Transmission Power <sup>*1</sup>	14



TG5511-6511-6512CX(e-e).book Page 21 Tuesday, May 11, 2010 11:46 AM



21

		Progra	mming
Main menu	Sub-menu 1	Sub-menu 2	Page
Initial Setup Display Setup		LCD & Key Backlight	-
		Contrast	-
	Keytones	-	-
	Area Code <sup>*1</sup>	-	24
	Auto Talk	-	15
	Line Setup	Dial Mode <sup>*1</sup>	13
		Recall/Flash <sup>*1</sup>	16
	Privacy Mode <sup>*1</sup>	-	-
	Base Unit PIN <sup>*1</sup>	-	25
	Repeater Mode <sup>*1</sup>	-	26
	Register	Register H.set	25
	Language	Display	13

\*1 If you program these settings using one of the handsets, you do not need to program the same item using another handset.

#### Programming using the direct commands

#### $1 \quad \blacksquare \rightarrow [\#]$

- 2 Enter the desired code.
- 3 Select the desired setting.  $\rightarrow$  OK
  - This step may vary depending on the feature being programmed.
  - To exit the operation, press [ $\checkmark$  $\bigcirc$ ].

#### Note:

• In the following table, < > indicates the default settings.

Feature	Code	Setting	System <sup>*1</sup>	Page
Caller List [2][1][		-	-	27
Set Date/Time	[1][0][1]	-	•	14
Alarm	[7][2][0]	<pre>[1]: Once [2]: Daily [0]: <off></off></pre>	-	24
Time Adjustment <sup>*2</sup>	[2][2][6]	<pre>[1]:Caller ID [0]: <manual></manual></pre>	•	-
Ringer Volume <sup>*3</sup> (Handset)	[1][6][0]	[1]-[6]: Level 1-6 <6> [0]: Off	-	-
Ringtone <sup>*4, *5</sup> [1][6][1 (Handset)		<ringtone 1=""></ringtone>	-	-
Intercom	[2][7][4]	_	_	30
Handset Name [1][0][4]		-	-	24

TG5511-6511-6512CX(e-e).book Page 22 Tuesday, May 11, 2010 11:46 AM

Programmino



Programming							
Feature	Code	Setting	System <sup>*1</sup>	Page			
Transmission Power	[7][2][5]	[1]: <normal> [2]: Low</normal>	•	14			
LCD & Key Backlight	[2][7][6]	[1]: <on> [0]: Off</on>	-	-			
Contrast (Display contrast)	[1][4][5]	[1]-[6]: Level 1-6 <3>	-	-			
Keytones <sup>*6</sup>	[1][6][5]	[1]: <on> [0]: Off</on>	-	-			
Area Code	[2][5][5]	-	•	24			
Auto Talk <sup>*7</sup>	[2][0][0]	[1]: On [0]: <off></off>	-	15			
Dial Mode	[1][2][0]	[1]: Pulse [2]: <tone></tone>	•	13			
Recall/Flash <sup>*8</sup>	[1][2][1]	<pre>[0]: 900 msec. [1]: 700 msec. [2]: &lt;600 msec.&gt; [3]: 400 msec. [4]: 300 msec. [5]: 250 msec. [5]: 250 msec. [#]: 160 msec. [#]: 160 msec. [6]: 110 msec. [7]: 100 msec. [8]: 90 msec. [9]: 80 msec.</pre>	•	16			
Privacy Mode <sup>*9</sup>	[1][9][4]	[1]: On [0]: <off></off>	•	-			
Base Unit PIN	[1][3][2]	<0000>	•	25			
Repeater Mode	[1][3][8]	[1]: On [0]: <off></off>	•	26			
Register H.set	[1][3][0]	-	-	25			
Cancel Register	[1][3][1]	_	-	25			
Display (Change language)	[1][1][0]	<english></english>	-	13			

\*1 If "System" column is checked, you do not need to program the same item using another handset.

\*2 This feature allows the unit to automatically adjust the date and time each time caller information including date and time is received.

To turn this feature on, select "Caller ID". To turn this feature off, select "Manual". (Caller ID subscribers only)

To use this feature, set the date and time first (page 14).

22

However even when the ringer volume is set to off, the handset still rings for alarm (page 24), intercom calls (page 30), and paging (page 30).

TG5511-6511-6512CX(e-e).book Page 23 Tuesday, May 11, 2010 11:46 AM

•



- \*4 If you select one of the melody ringer tones, the ringer tone continues to play for several seconds even if the caller has already hung up. You may either hear a dial tone or no one on the line when you answer the call.
- \*5 The preset melodies in this product are used with permission of © 2007 Copyrights Vision Inc.
- \*6 Turn this feature off if you prefer not to hear key tones while you are dialling or pressing any keys, including confirmation tones and error tones.
- \*7 If you subscribe to a Caller D service and want to view the caller's information after lifting up the handset to answer a call, turn off this feature.
- \*8 The recall/flash time depends on your telephone exchange or host PBX. Contact your PBX supplier if necessary.
- \*9 To prevent other users from joining your conversations with outside callers, turn this feature on.





TG5511-6511-6512CX(e-e).book Page 24 Tuesday, May 11, 2010 11:46 AM



#### Programming

#### Special programming

#### Alarm

An alarm sounds at the set time for 3 minutes once or daily. Alarm can be set for each handset.

#### Important:

- Set the date and time beforehand (page 14).
- 1  $\blacksquare \to [\#][7][2][0]$
- 2 [v]/[▲]: Select the desired alarm option. → OK

#### "off"

Turns alarm off. Go to step 6.

"Once" An alarm sounds once at the set time.

"Daily"

An alarm sounds daily at the set time. Go to step 4.

- 3 Enter the desired date and month.  $\rightarrow$  **OK**
- 4 Set the desired time.  $\rightarrow$  **OK**
- 5  $[\mathbf{v}]/[\mathbf{A}]$ : Select the desired alarm tone.  $\rightarrow$  **OK** 
  - We recommend selecting a different ringer tone from the one used for outside calls.
- 6 OX → (木☉)
   When the alarm is set, 𝔅 is displayed.

#### Note:

- To stop the alarm, press any dial key or place the handset on the base unit or charger.
- When the handset is in use, the alarm will not sound until the handset is in standby mode.

#### Changing the handset name

Each handset can be given a customised name ("Bob", "Kitchen", etc.). This is useful when you make intercom calls between handsets. You can also select whether or not the handset name is displayed in standby mode. The default setting is "off". If you select "On" without entering any handset name, "Handset 1" to "Handset 6" is displayed.

#### 1 $\square \rightarrow [\#][1][0][4]$

2 Enter the desired name (max. 10 characters; page 31).

• If not required, go to step 3.

#### 3 ок

4  $[\mathbf{v}]/[\mathbf{A}]$ : Select the desired setting.  $\rightarrow$  **OK** 2 times

5 [六①]

## Storing an area code to be deleted automatically

In some situations, phone numbers stored automatically in the caller list (page 27) will include area codes. If you do not want to dial the area code when making calls from the caller list, you can store the area code which you want the unit to delete automatically.

**Example:** You have stored the area code "123". If you make a call from the caller list to the phone number "123-456-7890", the unit dials "456-7890".

#### $1 \quad \blacksquare \rightarrow [\#][2][5][5]$

2 Enter an area code (5 digits max.).  $\rightarrow \square \rightarrow \square \rightarrow [\neg \square$ 



TG5511-6511-6512CX(e-e).book Page 25 Tuesday, May 11, 2010 11:46 AM

#### Changing the base unit PIN (Personal Identification Number)

#### Important:

- If you change the PIN, please make note of your new PIN. The unit will not reveal the PIN to you. If you forget your PIN, contact an authorised service centre.
- 1  $\square \rightarrow [\#][1][3][2]$
- 2 Enter the current 4-digit base unit PIN (default: "0000").
- 3 Enter the new 4-digit base unit PIN.  $\rightarrow \text{OK} \rightarrow [\checkmark \circlearrowright]$

#### Registering a unit

#### **Operating additional units**

#### Additional handsets

Up to 6 handsets can be registered to the base unit.

#### Important:

• The additional handset model recommended for use with this unit is noted on page 4. If another handset model is used, certain operations (handset settings, base unit settings, etc.) may not be available.

## Registering a handset to the base unit

The supplied handset and base unit are pre-registered. If for some reason the handset is not registered to the base unit (for example,  $\forall$  is displayed even when the handset is near the base unit), re-register the handset.

#### Programming

## Handset: $\square \rightarrow [\#][1][3][0]$

#### 2 Base unit:

1

Press and hold (•)) for about 5 seconds. (No registration tone)

- If all registered handsets start ringing, press the same button to stop. Then repeat this step.
- The next step must be completed within 90 seconds.

#### 3 Handset:

Wait until "Base PIN" is displayed.  $\rightarrow$  Enter the base unit PIN (default: "0000").  $\rightarrow$  **DK** 

- If you forget your PIN, contact an authorised service centre.
- When the handset has been registered successfully, **Y** is displayed.

#### Note:

3

- While registering, "Base in registering" is displayed on all registered handsets.
- When you purchase an additional handset, refer to the additional handset's installation manual for registration.

#### Deregistering a handset

A handset can cancel its own registration (or the registration of another handset) that is stored to the base unit. This allows the handset to end its wireless connection with the system.

- I □ → [#][1][3][1]
   All handsets registered to the base unit are displayed.
- 2  $[\mathbf{v}]/[\mathbf{A}]$ : Select the handset you want to cancel.  $\rightarrow$  **OK** 
  - [v]/[a]: "Yes" ightarrow OK
  - A confirmation tone sounds.
  - The handset does not beep when cancelling its own registration.



25

\_\_\_\_ \_\_\_\_ \_\_\_

TG5511-6511-6512CX(e-e).book Page 26 Tuesday, May 11, 2010 11:46 AM



#### Programming

4 【六①】

## Increasing the range of the base unit

You can increase the signal range of the base unit by using a DECT repeater. Please use only the Panasonic DECT repeater noted on page 4. Contact your Panasonic dealer for details.

#### Important:

- Before registering the repeater to this base unit, you must turn the repeater mode on.
- Do not use more than one repeater at a time.

#### Setting the repeater mode

- 1  $\square \rightarrow [\#](1](3](8)$
- 2 [v]/[▲]: Select the desired setting. → OK → [ $\checkmark$   $\circlearrowright$ ]

#### Note:

 After turning the repeater mode on or off, ♥ is displayed on the handset momentarily. This is normal and the handset can be used once ♥ is displayed.



TG5511-6511-6512CX(e-e).book Page 27 Tuesday, May 11, 2010 11:46 AM



#### Using Caller ID service

#### Important:

• This unit is Caller ID compatible. To use Caller ID features, you must subscribe to a Caller ID service. Contact your service provider/ telephone company for details.

#### **Caller ID features**

When an outside call is being received, the caller's phone number is displayed. Caller information for the last 50 callers is logged in the caller list from the most recent call to the oldest.

- If the unit cannot receive caller information, the following is displayed:
  - "Out of Area": The caller dials from an area which does not provide a Caller ID service.
  - "Private Caller": The caller requests not to send caller information.
- If the unit is connected to a PBX system, caller information may not be properly received. Contact your PBX supplier.

#### Missed calls

If a call is not answered, the unit treats it as a missed call and >) is displayed. This lets you know if you should view the caller list to see who called while you were away.

Even if only one missed call in the caller list is viewed (page 27), \*) disappears from the display. When you receive another new call, \*) is displayed again. **Note:** 

 Even when there are unviewed missed calls, disappears from the standby display if the following operation is performed by one of the registered handsets:

#### Caller ID Service

- Being replaced on the base unit or charger.
- Pressing 【★❹】.

#### Phonebook name display

When caller information is received and it matches a phone number stored in the phonebook, the stored name in the phonebook is displayed and logged in the caller list.

#### Caller list

#### Important:

- Only 1 person can access the caller list at a time.
- Make sure the unit's date and time setting is correct (page 14).

## Viewing the caller list and calling back

#### 1 【◄】(→))

- 2 Press [▼] to search from the most recent call, or press [▲] to search from the oldest call.
  - If ▶ is displayed, not all of the information is shown. To see the remaining information, press [▶].
     To return to the previous screen, press [◄].
- 3 To call back, press [♪]. To exit, press [★心].

#### Note:

- If you do not want to dial the area code when making calls from the caller list, you can store the area code which you want the unit to delete automatically (page 24).

27



 $(\mathbf{\Phi})$ 

TG5511-6511-6512CX(e-e).book Page 28 Tuesday, May 11, 2010 11:46 AM



#### Caller ID Service

## Editing a caller's phone number before calling back

- 1 [◄](→))
- 2  $[\mathbf{v}]/[\mathbf{A}]$ : Select the desired entry.
  - If ▶ is displayed, not all of the information is shown. To see the remaining information, press [▶]. To return to the previous screen, press [◄].
- 4 [ ]

## Erasing selected caller information

- 1 【◄】(≯)
- 2  $[\mathbf{v}]/[\mathbf{A}]$ : Select the desired entry.
- $\begin{array}{ccc} 3 & \bigstar \to [v]/[\Lambda]: "Yes" \to OK \\ & \to [ \bigstar \circlearrowright ] \end{array}$

#### Erasing all caller information

- 1 [◄](→)
- $\begin{array}{ccc} 2 & \bigstar \to [v]/[A]: "Yes" \to OK \\ & \to [ \not \sim 0 ] \end{array}$

## Storing caller information to the phonebook

- 1 [◄](>)
- $\begin{array}{c} \textbf{2} \quad [\texttt{v}]/[\texttt{A}]: \text{ Select the desired entry.} \\ \quad \rightarrow \textbf{E} \end{array}$
- 3 [v]/[A]: "Phonebook"  $\rightarrow OK$
- 4 To store the name, continue from step 2, "Adding entries", page 18.



|-\_\_\_\_\_

<del>(</del>•)

TG5511-6511-6512CX(e-e).book Page 29 Tuesday, May 11, 2010 11:46 AM



#### Voice mail service

Voice mail is an automatic answering service offered by your service provider/ telephone company. After you subscribe to this service, your service provider/ telephone company's voice mail system answers calls for you when you are unavailable to answer the phone or when your line is busy. Messages are recorded by your service provider/ telephone company, not your telephone. When you have new messages,  $\underline{\aleph}$  is displayed on the handset if message indication service is available. Please contact your service provider/telephone company for details of this service. Important:

 If still remains on the display even after you have listened to new messages, turn it off by pressing and holding **(#)** for 2 seconds.



TG5511-6511-6512CX(e-e).book Page 30 Tuesday, May 11, 2010 11:46 AM



#### Intercom/Locator

#### Intercom

Intercom calls can be made between handsets.

#### Note:

- If you receive an outside call while talking on the intercom, you hear 2 tones. To answer the call, press
   (\*), then press (\*).
- When paging the handset, the paged handset beeps for 1 minute.

#### Making an intercom call

- $1 \quad \blacksquare \rightarrow \blacksquare$
- 2  $[\mathbf{v}]/[\mathbf{A}]$ : Select the desired unit.  $\rightarrow$  OK
  - To stop paging, press (★.).
- 3 When you finish talking, press [☆心].

#### Answering an intercom call

- **1** Press **[** ] to answer the page.
- 2 When you finish talking, press [\*ひ].

#### Handset locator

All registered handsets beep for 1 minute.

To stop paging, press it again or  $[\bigstar 0]$  on the handset.

## Transferring calls, conference calls

Outside calls can be transferred or a conference call with an outside party can be made between 2 handsets.

- 1 During an outside call, press ()) to put the call on hold.
- 2 [v]/[A]: Select the desired unit.  $\rightarrow$  OK
- Wait for the paged party to answer.If the paged party does not
  - answer, press **5** to return to the outside call.
- 4 To complete the transfer: Press [べの].
  - The outside call is being routed to the destination unit.

## To establish a conference call: Press

- To leave the conference, press
   (\*O). The other 2 parties can continue the conversation.
- To put the outside call on hold, press . To resume the conference, press .

#### Note:

 If you want to return to the outside call after the paged party answers, press

#### Answering a transferred call

Press [ ~ ] to answer the page.



TG5511-6511-6512CX(e-e).book Page 31 Tuesday, May 11, 2010 11:46 AM



#### **Character entry**

The dial keys are used to enter characters and numbers. Each dial key has multiple characters assigned to it. The characters that can be entered depend on the character entry mode (page 31).

- Press [ ◄] or [►] to move the cursor left or right.
- Press dial keys to enter characters and numbers.
- Press C to erase the character or number highlighted by the cursor. Press and hold C to erase all characters or numbers.
- Press  $[ \star ]$  (A $\rightarrow$ a) to switch between uppercase and lowercase.
- To enter another character located on the same dial key, press [>] to move the cursor to the next space, then press the appropriate dial key.
- If you do not press any dial key within 5 seconds after entering a character, the character is fixed and the cursor moves to the next space.

#### **Character entry modes**

The available character entry modes are Alphabet (ABC), Numeric (0-9), Greek (ABC), Extended 1 (AÄÅ), Extended 2 (SŚŠ), and Cyrillic (ABB). When in these entry modes except Numeric, you can select which character is entered by pressing a dial key repeatedly.



When the unit displays the character entry screen:

 $1/\sqrt{2} \rightarrow [\mathbf{v}]/[\mathbf{A}]$ : Select a character entry mode.  $\rightarrow \mathbf{OK}$ 



Note:

 $\bullet\_$  in the following tables represents a single space.

#### Alphabet character table (ABC)

0_	1 *'()	(2ABC)	3 DEF	(4ан)	(5jkl)	6mno	(7PQRS)	8τυν	<b>G</b> WXYZ	#
0	л %,	АВС	DEF	GHI	JKL	ΜΝΟ	PQR	ТUV	WΧΥ	#
	()*,	2	3	4	5	6	S 7	8	Z 9	
	/ 1	abc	def	ghi	jkl	mno	pqrs	tuv	wху	
		2	3	4	5	6	7	8	z 9	

Numeric entry table (0-9)

	0_	1 *()	(2ABC)	3 DEF	(4 ани	(5jkl	6mmo	PQRS	8τυν	<b>G</b> WXYZ	#
0	C	1	2	3	4	5	6	7	8	9	#

#### Greek character table (ABF)

0_	( <b>1</b> *')	(2ABC)	3 DEF		(5jkl	6mno	(7PQRS)	8τυν	<b>G</b> WXYZ	#
_ 0	<u> </u>	АВГ	ΔEΖ	ΗΘΙ	КΛΜ	ΝΞΟ	ΠΡΣ	ТΥΦ	ΧΨΩ	#
	()*,	2	3	4	5	6	7	8	9	
	/ 1									



31





#### **Useful Information**

Extended 1 character table (AÄÅ)

0_	1*()	(2ABC)	3 DEF	(4 сні	(5jkl	<u>6mno</u>	(7PQRS)	8τυν	<b>G</b> WXYZ	#
_ 0	□ & ' () <b>米</b> , - . / 1	AÀÁ ÂÃÄ ÅÆB CÇ2	ÉÊË	l) í î	JKL 5	M N Ñ O Ò Ó Ô Õ Ö Ø 6	SŞβ	ÚÛÜ	W Ŵ X Y ŷ Z 9	#
		aàá âãä åæb cç2	d e è é ê ë ẽ f 3	gğh iìíî ïĩıĭ 4	j k I 5		pqrs șß7		wŴx yŷz 9	

 $\bullet$  The following are used for both uppercase and lowercase:  $\ ^{\mbox{$\sigma$}}\,\hat{W}\,\hat{y}$ 



Extended 2 character table (SŚŠ)

• The following are used for both uppercase and lowercase:



ĄĆČĘŁĹĽŃŔŚŠůỳŹŻŽ Cyrillic character table (A6B)

0_	1 *()	(2ABC)	3 DEF	(4 дні)	(5jkl)	6mno	PQRS	(8TUV)	9wxyz	#
_ 0 ľ	L & '	АБВ	ДЕЖ	ИЙК	мно	РСТ	ΦХЦ	ШЩ	ьэю	#
ΕΙΪ	()*,	Г	3	Л	п	У	Ч	ЪЫ	я	
У	/ 1	2	3	4	5	6	7	8	9	





TG5511-6511-6512CX(e-e).book Page 33 Tuesday, May 11, 2010 11:46 AM



Useful Information

#### **Error messages**

If the unit detects a problem, one of the following messages is shown on the display.

Display message	Cause/solution
Base no power Or No link. Reconnect AC adaptor.	<ul> <li>The handset has lost communication with the base unit. Move closer to the base unit and try again.</li> <li>Unplug the base unit's AC adaptor to reset the unit. Reconnect the adaptor and try again.</li> <li>The handset's registration may have been cancelled. Re-register the handset (page 25).</li> </ul>
Check Phone Line	<ul> <li>The supplied telephone line cord has not been connected yet or not connected properly. Check the connections (page 8).</li> </ul>
Failed	<ul> <li>Phonebook copy failed (page 19). Confirm the other handset (the receiver) is in standby mode and try again.</li> </ul>
Incomplete	<ul> <li>The receiver's phonebook memory is full. Erase the unwanted phonebook entries from the other handset (the receiver) and try again.</li> </ul>
Memory Full	<ul> <li>The phonebook memory is full. Erase unwanted entries (page 18).</li> </ul>
Use rechargeable battery.	<ul> <li>A wrong type of battery such as Alkaline or Manganese was inserted. Use only the rechargeable Ni-MH batteries noted on page 4, 6.</li> </ul>
You must first subscribe to Caller ID.	<ul> <li>You must subscribe to a Caller ID service. Once you receive caller information after subscribing to a Caller ID service, this message will not be displayed.</li> </ul>





TG5511-6511-6512CX(e-e).book Page 34 Tuesday, May 11, 2010 11:46 AM



#### Useful Information

### Troubleshooting

If you still have difficulties after following the instructions in this section, disconnect the base unit's AC adaptor and turn off the handset, then reconnect the base unit's AC adaptor and turn on the handset.

#### General use

Problem	Cause/solution
The handset does not turn on even after installing charged batteries.	<ul> <li>Place the handset on the base unit or charger to turn on the handset.</li> </ul>
The unit does not work.	<ul> <li>Make sure the batteries are installed correctly (page 9).</li> <li>Fully charge the batteries (page 9).</li> <li>Check the connections (page 8).</li> <li>Unplug the base unit's AC adaptor to reset the unit and turn off the handset. Reconnect the adaptor, turn on the handset and try again.</li> <li>The handset has not been registered to the base unit. Register the handset (page 25).</li> </ul>
I cannot hear a dial tone.	<ul> <li>Make sure that you are using the supplied telephone line cord. Your old telephone line cord may have a different wiring configuration.</li> <li>The base unit's AC adaptor or telephone line cord is not connected. Check the connections.</li> <li>Disconnect the base unit from the telephone line and connect the line to a known working telephone. If the working telephone operates properly, contact our service personnel to have the unit repaired. If the working telephone does not operate properly, contact your service provider/telephone company.</li> </ul>

#### Programmable settings

Problem	Cause/solution
The display is in a language I cannot read.	<ul> <li>Change the display language (page 13).</li> </ul>
I cannot activate the eco mode.	• You cannot set eco mode when you set the repeater mode "on". If required, set the repeater mode to "off" (page 26).



TG5511-6511-6512CX(e-e).book Page 35 Tuesday, May 11, 2010 11:46 AM



	Useful Information
Problem	Cause/solution
I cannot register a handset to a base unit.	<ul> <li>The maximum number of handsets (6) is already registered to the base unit. Cancel unused handset registrations from the base unit (page 25).</li> <li>You entered the wrong PIN. If you forget your PIN, contact an authorised service centre.</li> </ul>

#### Battery recharge

Problem	Cause/solution
The handset beeps and/or 🖨 flashes.	<ul> <li>Battery charge is low. Fully charge the batteries (page 9).</li> </ul>
<ul> <li>I fully charged the batteries, but</li> <li>is still flashes or</li> <li>the operating time seems to be shorter.</li> </ul>	<ul> <li>Clean the battery ends (⊕, ⊖) and the charge contacts with a dry cloth and charge again.</li> <li>It is time to replace the batteries (page 9).</li> </ul>
The handset display is blank.	<ul> <li>The handset is not turned on. Turn the power on (page 13).</li> </ul>

#### Making/answering calls, intercom

Problem	Cause/solution				
¥ is displayed.	<ul> <li>The handset is too far from the base unit. Move closer.</li> </ul>				
	<ul> <li>The base unit's AC adaptor is not properly connected. Reconnect AC adaptor to the base unit.</li> </ul>				
	<ul> <li>The handset is not registered to the base unit. Register it (page 25).</li> </ul>				
	<ul> <li>Activating one touch eco mode reduces the range of the base unit in standby mode. If required, turn eco mode off (page 14).</li> </ul>				



TG5511-6511-6512CX(e-e).book Page 36 Tuesday, May 11, 2010 11:46 AM

$\bullet$	
	•

### Useful Information

Problem	Cause/solution
Noise is heard, sound cuts in and out.	<ul> <li>You are using the handset or base unit in an area with high electrical interference. Reposition the base unit and use the handset away from sources of interference.</li> <li>Move closer to the base unit.</li> <li>If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.</li> <li>Unplug the base unit's AC adaptor to reset the unit and turn off the handset. Reconnect the</li> </ul>
	adaptor, turn on the handset and try again.
Sound quality seems to be getting worse.	<ul> <li>You have registered a handset that is not recommended (page 4). The clearest sound quality is only possible by registering the recommended handset.</li> </ul>
The handset does not ring.	<ul> <li>The ringer volume is turned off. Adjust ringer volume (page 21).</li> </ul>
I cannot make a call.	<ul> <li>The dialling mode may be set incorrectly. Change the setting (page 13).</li> <li>The handset is too far from the base unit. Move closer and try again.</li> <li>Another unit is in use. Wait and try again later.</li> <li>The key lock feature is turned on. Turn it off (page 17).</li> </ul>



 $(\mathbf{\Phi})$ 

#### TG5511-6512CX(e-e).book Page 37 Tuesday, May 11, 2010 11:46 AM



37

#### Caller ID

Problem	Cause/solution
Caller information is not displayed.	<ul> <li>You must subscribe to a Caller ID service. Contact your service provider/telephone company for details.</li> <li>If your unit is connected to any additional telephone equipment, remove and plug the unit directly into the wall jack.</li> <li>If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.</li> <li>Other telephone equipment may be interfering with this unit. Disconnect the other equipment and try again.</li> </ul>
Caller information is slow to display.	<ul> <li>Depending on your service provider/ telephone company, the unit may display the caller's information at the 2nd ring or later.</li> <li>Move closer to the base unit.</li> </ul>
Time on the unit has shifted.	<ul> <li>Incorrect time information from incoming Caller ID changes the time. Set the time adjustment to "Manual" (off) (page 21).</li> </ul>
The name stored in the phonebook is not fully displayed while an outside call is being received.	<ul> <li>Edit the phonebook entry name to fit in 1 line of text (page 18).</li> </ul>

#### Liquid damage

Problem	Cause/solution
Liquid or other form of moisture has entered the handset/base unit.	Disconnect the AC adaptor and telephone line cord from the base unit. Remove the batteries from the handset and leave to dry for at least 3 days. After the handset/base unit are completely dry, reconnect the AC adaptor and telephone line cord. Insert the batteries and charge fully before use. If the unit does not work properly, contact an authorised service centre.

#### Caution:

• To avoid permanent damage, do not use a microwave oven to speed up the drying process.



TG5511-6511-6512CX(e-e).book Page 38 Tuesday, May 11, 2010 11:46 AM



#### Useful Information

#### Wall mounting

#### Note:

• Make sure that the wall is strong enough to support the weight of the unit.







Privacy mode: 22 **R** Recall/flash: 16

> Redialling: 15 Repeater: 26

Ringer tone: 21

S Speakerphone: 15

V Voice mail: 29

Volume

Temporary tone dialling: 16

Ringer (Handset): 16, 21

Time adjustment: 21

Transferring calls: 30

Troubleshooting: 34

Receiver: 15

Speaker: 15

W Wall mounting: 38

т



#### Index

- A Additional handsets: 25 Alarm: 24 Answering calls: 15 Area code: 24 Auto talk: 15
- B Battery: 9
- C Caller ID service: 27 Caller list: 27 Caller list edit: 28 Call share: 17 Call waiting: 16 Call Waiting Caller ID: 16 Chain dial: 19 Character entry: 31 Conference calls: 30 Control type: 11
- D Date and time: 14 Dialling mode: 13 Direct command: 21 Display Contrast: 22 Language: 13
- E Eco mode: 14 Error messages: 33
- H Handset Deregistration: 25 Locator: 30
  - Name: 24 Registration: 25 Hold: 16
- I Intercom: 30
- K Key lock: 17 Keytones: 22
- M Making calls: 15 Missed calls: 27 Mute: 16
- P Pause: 15 Phonebook: 18 PIN: 25 Power failure: 9 Power on/off: 13

39



We recommend keeping a record of the following information to assist with any repair under warranty.

Serial No.	Date of purchase
(found on the bottom of the base unit)	
Name and address of dealer	

Attach your purchase receipt here.

Panasonic System Networks Co., Ltd. 1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

#### Copyright:

I

This material is copyrighted by Panasonic System Networks Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic System Networks Co., Ltd.

© Panasonic System Networks Co., Ltd. 2010



L

