



EC Motors with LinMot Drives

**Documentation of how to control EC Motors with
LinMot Drives**



**EC Motors with
B1100 / C1100 / C1200 / E1100 / E1200
Series Drives**

© 2014 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying,

recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG. Reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Document version 1.10.2, VC/Ro, September 2014

Table of Content


1 INTRODUCTION.....	4
2 CONFIGURATION	4
3 MOTORS WITH ADF-FILE	5
3.1 NTI SERVO MOTORS	5
3.2 APM SERVO MOTORS (E.G. FROM ELMO MOTION CONTROL)	5
3.3 BERGER LAHR RECM.....	6
3.4 FAULHABER EC MOTORS	7
3.5 SIBONI MOTORS	8
4 SENSOR AND DIFFERENTIAL HALL SWITCHES WIRING.....	9
5 HALL SWITCHES VS. COMMUTATION ANGLE.....	10
6 CONTACT ADDRESSES	11

1 Introduction


3 phases rotary EC motors control support	
Drives series	Supported since firmware release
E1100	3.4
B1100	3.7
E1200	3.11, 5.0, 6.0
C1100, C1200	6.0

2 Configuration

The rotary EC motors are configured by using the LinMot-Talk software. For a couple of motor types LinMot provides actuator definition files (*.adf). With such an ADF-file the motor configuration can be done by using the *Motor Wizard* tool of the LinMot-Talk software.



You will find the EC motor ADF-files in the subdirectory \Motors\Other Motors\ of your LinMot-Talk installation.



After selecting an EC motor ADF-file, the *Motor Wizard* will guide through the configuration step by step.

3 Motors with ADF-File

3.1 NTI Servo Motors

Supported Types:	EC01-40/100
Feedback:	Hall switches & ABZ encoder
Commutation:	- Based on hall switches until first Z pulse from encoder - Based on encoder signals afterwards (sine commutation)
Position Control:	- Based on feedback from ABZ encoder

Wiring:

	B1100	C1100 C1200	E1100	E1200
Motor Phases U,V,W and Ground	X2 or X3	X2	X2 or X3	X2
Hall Switches U, V, W	X13	X13	X10 U → A V → B W → Z	X13
RS422 ABZ Encoder Signals	X13	X13	X12	X13
Sensor supply (5V) from	X13	X13	X12	X13

See also chapter 4 "Sensor and differential Hall Switches Wiring".

3.2 APM Servo Motors (e.g. from Elmo Motion Control)

Supported Types:	APM SA01ACx-9 APM SB02ADx-9 APM SB03ADx-9
Feedback:	Hall switches & ABZ encoder
Commutation:	- Based on hall switches until first Z pulse from encoder - Based on encoder signals afterwards (sine commutation)
Position Control:	- Based on feedback from ABZ encoder

Wiring:

	B1100	C1100 C1200	E1100	E1200
Motor Phases U,V,W and Ground	X2 or X3	X2	X2 or X3	X2
Hall Switches U, V, W	X13	X13	X10 U → A V → B W → Z	X13
RS422 ABZ Encoder Signals	X13	X13	X12	X13
Sensor supply (5V) from	X13	X13	X12	X13

See also chapter 4 "Sensor and differential Hall Switches Wiring".

3.3 Berger Lahr RECM

Supported Types: RECM 372/4 DC048 xl
 RECM 374/4 DC048 xl
 RECM 375/4 DC060 xl
 RECM 377/4 DC060 xl

Feedback: Hall switches & ABZ encoder

Commutation: - Based on hall switches until first Z pulse from encoder
 - Based on encoder signals afterwards (sine commutation)

Position Control: - Based on feedback from ABZ encoder

Wiring:

	B1100	C1100 C1200	E1100	E1200
Motor Phases U,V,W and PE Earth	X2 or X3	X2	X2 or X3	X2
Hall Switches U, V, W	X13	X13	X10 U → A V → B W → Z	X13
RS422 ABZ Encoder Signals	X13	X13	X12	X13
Sensor supply (5V) from	X13	X13	X12	X13

See also chapter 4 "Sensor and differential Hall Switches Wiring".

3.4 Faulhaber EC Motors

Supported Types:

- 1628 T 024 B K1155
- 2036 U 024 B K1155
- 2036 U 036 B K1155
- 2444 S 024 B K1155
- 2444 S 048 B K1155
- 3056 K 024 B K1155
- 3056 K 036 B K1155
- 3242 G 024 BX4 3692
- 3268 G 024 BX4 3692
- 3274 G 024 BP4 3692
- 3564 K 024 B K1155
- 3564 K 036 B K1155
- 3564 K 048 B K1155
- 4490 H 024 B K1155
- 4490 H 048 B K1155

3268 G 024 BX4 IE3 – 1024 L

LM 1247 – 020 - 01
LM 1247 – 080 - 01
LM 1247 – 120 - 01

LM 2070 – 040 - 01
LM 2070 – 080 - 01
LM 2070 – 120 - 01

Feedback: Analog hall sensors & optional encoder

Commutation: - Based on hall sensor signals

Position Control: - Based on hall sensor signals or optional encoder

Wiring:

	B1100	C1100 C1200	E1100	E1200
Motor Phases A,B,C A → U B → V C → W	X2 or X3	X2	X2 or X3	X2
Hall Sensors A,B,C A → X3.4 B → X3.9 C → do not connect!	X3	X3	X3	X3
Optional Encoder	X13	X13	X12	X13

3.5 Siboni Motors

Supported Types:	B60L 585 B60C 596 S0402B 454
Feedback:	Hall Switches & ABZ Encoder
Commutation:	- Based on hall switches until first Z pulse from encoder - Based on encoder signals afterwards (sine commutation)
Position Control:	- Based on feedback from ABZ encoder
Thermal protection:	- PTC

Wiring:

	B1100	C1100 C1200	E1100	E1200
Motor Phases U, V, W and Earth U → W V → V W → U	X2 or X3	X2	X2 or X3	X2
Hall Switches U, V, W	X13	X13	X10 U → A V → B W → Z	X13
RS422 ABZ Encoder Signals Supply +5V red GND black SHIELD SHIELD CH A blue CH /A blue/black CH B green CH /B green/black CH Z yellow CH /Z yellow/black Hall U brown Hall /U brown/black Hall V grey Hall /V grey/black Hall W white Hall /W white/black	X13	X13	X12	X13
Sensor supply (5V) from	X13	X13	X12	X13
PTC			X4.10/X4.11	X4.10/X4.11

See also chapter 4 "Sensor and differential Hall Switches Wiring".

4 Sensor and differential Hall Switches Wiring

Signal	B1100, C1100, C1200 & E1200	E1100	
		X12 - Pin	X10 - Pin
	X13 - Pin		
+5V	1	1	
/A	2	2	
/B	3	3	
/Z	4	4	
GND	5	5	
/U	6		2
/V	7		6
/W	8		5
A	9	6	
B	10	7	
Z	11	8	
Enc. Alarm	12	9	
U	13		1
V	14		3
W	15		4
Shield	case	case	case

Figure 1: B1100, C1100, C1200, E1100 and E1200 sensor and differential hall switches wiring

5 Hall Switches vs. Commutation Angle




Figure 2: Hall switches vs. commutation angle situation 1




Figure 3: Hall switches vs. commutation angle situation 2 with changed direction

6 Contact Addresses

SWITZERLAND

NTI AG

Haerdlistr. 15
CH-8957 Spreitenbach

Sales and Administration: +41-(0)56-419 91 91
office@linmot.com

Tech. Support: +41-(0)56-544 71 00
support@linmot.com

Tech. Support (Skype) : [skype:support.linmot](https://www.skype.com/user/linmot)

Fax: +41-(0)56-419 91 92
Web: <http://www.linmot.com/>

USA

LinMot, Inc.

204 E Morrissey Dr.
Elkhorn, WI 53121

Sales and Administration: 877-546-3270
262-743-2555

Tech. Support: 877-804-0718
262-743-1284

Fax: 800-463-8708
262-723-6688

E-Mail: us-sales@linmot.com
Web: <http://www.linmot-usa.com/>

Please visit <http://www.linmot.com/> to find the distribution near you.

Smart solutions are...