BALDOR MN406 RPM AC Inverter Duty Motors Operating manual

http://www.manuallib.com/baldor/mn406-rpm-ac-inverter-duty-motors-operating-manual.html

This manual contains general procedures that apply to BaldorReliance Motor products. Be sure to read and understand the Safety Notice statements in this manual. For your protection, do not install, operate or attempt to perform maintenance procedures until you understand the Warning and Caution statements.

ManualLib.com collects and classifies the global product instrunction manuals to help users access anytime and anywhere, helping users make better use of products.

http://www.manuallib.com

BALDOR · RELIANCE

RPM AC Inverter Duty Motors NEMA Frames FL180 – L440 Family IEC Frames FDL112 – DL280 Family

(Specifically designed for operation with Adjustable Speed Controls)

Installation & Operating Manual

3/09

MN406

Any trademarks used in this manual are the property of their respective owners.

Table of Contents

Section 1	
General Information	1–1
Overview	1–1
Limited Warranty	1–1
Safety Notice	1–1
Receiving	1–3
Handling	1–3
Storage	1–3
Removal From Storage	1–4
Section 2	
Installation & Operation	2–1
Overview	2–1
Mechanical Installation	2–1
Stub Shaft Installation	2–2
Stub Shaft Removal	2–2
Mounting Location	2–2
Alignment	2–3
Doweling & Bolting	2–3
Guarding	2–4
Electrical Installation	2–4
Thermostat Leads Connection	2–5
Blower Motor Connection	2–5
Grounding	2–5
Shipping Blocks	2–6
Encoder Connections	2–6
Drain Plugs	2-6
Drive	<u> </u>
Shaft Loads – Avial and Badial	2_7
Ontional Accessories	2_8
First Time Start I In	2_0
	2-9
	2-3
Maximum Safa Speed	2-10
	2-10
Section 2	2-10
Maintenance & Troubleshooting	3–1
General Inspection	3_1
Belubrication & Bearings	3_1
Lubrication Procedure	3_1
Type of Grease	3_2
	3_2 3_2
Suggested bearing and winding BTD setting guidelines for Non-Hazardous Locations ONLY	0-0 2 1
Suggested bearing and winding TID setting guidelines for NON-Dazardous Locations ONLY	3-4

MN406

Table of Contents i

ii Table of Contents

Section 1 General Information

<u>Overview</u>	This manual contains general procedures that apply to Baldor•Reliance Motor products. Be sure to read and understand the Safety Notice statements in this manual. For your protection, do not install, operate or attempt to perform maintenance procedures until you understand the Warning and Caution statements. A Warning statement indicates a possible unsafe condition that can cause harm to personnel. A Caution statement indicates a condition that can cause damage to equipment.					
Important:	This instruction manual is not intended to include a comprehensive listing of all details for all procedures required for installation, operation and maintenance. This manual describes general guidelines that apply to most of the motor products shipped by Baldor. If you have a question about a procedure or are uncertain about any detail, Do Not Proceed. Please contact your Baldor District office for more information or clarification. Before you install, operate or perform maintenance, become familiar with the following if applicable to					
	 vour area: NEMA Publication MG-2, Safety Standard for Construction and guide for Selection, Installation and Use of Electric Motors and Generators. IEC 34–1 Electrical and IEC72–1 Mechanical specifications 					
	ANSI C51.5, the National Electrical Code (NEC) and local codes and practices.					
	www.baldor.com/support/warranty standard.as					
<u>Safety Notice</u>	: This equipment contains high voltage! Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt installation, operation and maintenance of electrical equipment. Be sure that you are completely familiar with NEMA publication MG-2, safety standards for construction and					
	guide for selection, installation and use of electric motors and generators, the National Electrical Code and local codes and practices. Unsafe installation or use can cause conditions that lead to serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.					
WARNING:	Do not touch electrical connections before you first ensure that power has been disconnected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.					
WARNING:	Disconnect all electrical power from the motor windings and accessory devices before disassembly of the motor. Electrical shock can cause serious or fatal injury.					
WARNING:	The Adjustable Speed Controller may apply hazardous voltages to the motor leads after power to the controller has been turned off. Verify that the controller is incapable of delivering hazardous voltages and that the voltage at the motor leads is zero before proceeding. Failure to observe this precaution may result in severe bodily injury or death.					
WARNING:	Be sure the system is properly grounded before applying power. Do not apply AC power before you ensure that all grounding instructions have been followed. Electrical shock can cause serious or fatal injury. National Electrical Code and Local codes must be carefully followed.					
WARNING:	Avoid extended exposure to machinery with high noise levels. Be sure to wear ear protective devices to reduce harmful effects to your hearing.					
WARNING:	Surface temperatures of motor enclosures may reach temperatures which can cause discomfort or injury to personnel accidentally coming into contact with hot surfaces. When installing, protection should be provided by the user to protect against accidental contact with hot surfaces. Failure to observe this precaution could result in bodily injury.					
WARNING:	This equipment may be connected to other machinery that has rotating parts or parts that are driven by this equipment. Improper use can cause serious or fatal injury. Only qualified personnel should attempt to install operate or maintain this equipment					
WARNING:	Do not by-pass or disable protective devices or safety guards. Safety features are designed to prevent damage to personnel or equipment. These devices can only provide protection if they remain operative.					
WARNING:	Avoid the use of automatic reset devices if the automatic restarting of equipment can be hazardous to personnel or equipment.					
WARNING:	Be sure the load is properly coupled to the motor shaft before applying power. The shaft key must be fully captive by the load device. Improper coupling can cause harm to personnel or equipment if the load decouples from the shaft during operation.					
WARNING:	Use proper care and procedures that are safe during handling, lifting, installing, operating and maintaining operations. Improper methods may cause muscle strain or other harm.					
WARNING:	Incorrect motor rotation direction can cause serious or fatal injury or equipment damage. Be sure to verify motor rotation direction before coupling the load to the motor shaft.					
WARNING:	Motors that are to be used in flammable and/or explosive atmospheres must display the CSA listed logo. Specific service conditions for these motors are defined in NFPA 70 (NEC) Article 500.					

MN406

General Information 1-1

Safety Notice	Continued
WARNING:	Pacemaker danger – Magnetic and electromagnetic fields in the vicinity of current carrying carrying conductors and permanent magnet motors can result result in a serious health hazard to persons with cardiac pacemakers, metal implants, and hearing aids. To avoid risk, stay way from the area surrounding a permanent magnet motor.
WARNING:	RPM AC permanent magnet motors can induce voltage and current in the motor leads by rotating the motor shaft. Electrical shock can cause serious or fatal injury. Therefore, do not couple the load to the motor shaft until all motor connections have been made. During any maintenance inspections, be sure the motor shaft will not rotate.
WARNING:	Before performing any motor maintenance procedure, be sure that the equipment connected to the motor shaft cannot cause shaft rotation. If the load can cause shaft rotation, disconnect the load from the motor shaft before maintenance is performed. Unexpected mechanical rotation of the motor parts can cause injury or motor damage.
WARNING:	Do not use non UL/CSA listed explosion proof motors in the presence of flammable or combustible vapors or dust. These motors are not designed for atmospheric conditions that require explosion proof operation.
WARNING:	UL Listed motors must only be serviced by UL Approved Authorized Baldor Service Centers if these motors are to be returned to a hazardous and/or explosive atmosphere.
WARNING:	Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions, should be permanently guarded to prevent accidental contact by personnel. Accidental contact with body parts or clothing can cause serious or fatal injury.
WARNING:	C-Face motor is intended for mounting auxiliary equipment such as pumps and gears. When mounted horizontally Frames FL, RL and L280C thru L360C, (FDL, RDL and DL180Y-DL220Y) and frames L400D thru L4461D, DL250Y – DL280Y must be supported by the feet and not by the C-Face on D-Flange alone. C-Face motors should be supported by the feet and not by the C-Face. Installations requiring a horizontally mounted motor in frames L280C – L440D, FDL, DL180Y-DL280Y must be supported by the feet as well as C-Face, D-Flange or IEC Flange. Failure to observe these precautions can result in bodily injury and equipment damage.
Caution:	Use only a shielded motor power cable with a complete circumferential braided or copper film/tape ground jacket around the power leads. This ground should be secured to the motor frame from within the motor terminal box and must return without interruption to the drive ground. In addition, if the motor and coupled equipment are not on a single common metal base plate, it is important to equalize the equipment ground potentials by bonding the motor frame to the coupled equipment using a high frequency conductor such as a braided strap.
Caution:	Do not over-lubricate motor as this may cause premature bearing failure.
Caution:	Do not lift the motor and its driven load by the motor lifting hardware. The motor lifting hardware is adequate for lifting only the motor. Disconnect the load (gears, pumps, compressors, or other driven equipment) from the motor shaft before lifting the motor.
Caution:	If eye bolts are used for lifting a motor, be sure they are securely tightened. The lifting direction should not exceed a 20° angle from the shank of the eye bolt or lifting lug. Excessive lifting angles can cause damage.
Caution:	To prevent equipment damage, be sure that the electrical service is not capable of delivering more than the maximum motor rated amps listed on the rating plate.
Caution:	If a HI POT test (High Potential Insulation test) must be performed, follow the precautions and procedure in NEMA MG1 and MG2 standards to avoid equipment damage.
Caution:	Do not use an induction oven to heat noise tested bearings. Arcing between the balls and races may damage the bearing. Failure to observe this precaution may result in equipment damage.
Caution:	Do not operate motors with a roller bearing unless a radial load is applied so that damage to the roller bearing does not occur.
Caution:	RPM AC permanent magnet motors with an open enclosure, such as DP–FV, should not be used where ferrous dust or particles may may be present . Totally enclosed permanent magnet motors are recommended for these applications.
	If you have any questions or are uncertain about any statement or procedure, or if you require additional information please contact your Baldor District office or an Authorized Baldor Service Center.

1-2 General Information

<u>Receiving</u>	Each Baldor•Reliance motor is thoroughly tested at the factory and carefully packaged for shipment. When you receive your motor, there are several things you should do immediately. 1. Observe the condition of the shipping container and report any damage immediately to the					
	commercial carrier that delivered your motor.2. Verify that the part number of the motor you received is the same as the part number listed on your purchase order.					
Handling	The motor should be lifted using the lifting lugs or eve bolts provided					
g	 Use the lugs or eye bolts provided to lift the motor. Never attempt to lift the motor and additional equipment connected to the motor by this method. The lugs or eye bolts provided are designed to lift only the motor. Never lift the motor by the motor shaft or the hood of a WPII motor. If eye bolts are used for lifting a motor, be sure they are securely tightened. The lifting direction should not exceed a 20° angle from the shank of the eye bolt. Excessive lifting angles can cause motor damage. To avoid condensation inside the motor, do not unpack until the motor has reached room temperature. 					
	(Room temperature is the temperature of the room in which it will be installed). The packing provides insulation from temperature changes during transportation.					
	 When lifting a WPII (Weather Proof Type 2) motor, do not lift the motor by inserting lifting lugs into holes on top of the cooling hood. These lugs are to be used for hood removal only. A spreader bar should be used to lift the motor by the cast lifting lugs located on the motor frame. 					
	4. If the motor must be mounted to a plate with the driven equipment such as pump, compressor etc., it may not be possible to lift the motor alone. For this case, the assembly should be lifted by a sling around the mounting base. The entire assembly can be lifted as an assembly for installation. Do not lift the assembly using the motor lugs or eye bolts provided. Lugs or eye bolts are designed to lift motor only. If the load is unbalanced (as with couplings or additional attachments) additional slings or other means must be used to prevent tipping. In any event, the load must be secure before lifting.					
<u>Storage</u>	Storage requirements for motors and generators that will not be placed in service for at least six months from date of shipment. Improper motor storage will result in seriously reduced reliability and failure. An electric motor that does not experience regular usage while being exposed to normally humid atmospheric conditions is likely to develop rust in the bearings or rust particles from surrounding surfaces may contaminate the bearings. The electrical insulation may absorb an excessive amount of moisture leading to the motor winding failure.					
	A wooden crate "shell" should be constructed to secure the motor during storage. This is similar to an export box but the sides & top must be secured to the wooden base with lag bolts (not nailed as export boxes are) to allow opening and reclosing many times without damage to the "shell".					
	 Minimum resistance of motor winding insulation is 5 Meg ohms or the calculated minimum, which ever is greater. Minimum resistance is calculated as follows: Rm = kV + 1 where: (Rm is minimum resistance to ground in Meg–Ohms and kV is rated nameplate voltage defined as Kilo–Volts.) Example: For a 480VAC rated motor Rm =1.48 meg–ohms (use 5 MΩ). For a 4160VAC rated motor Rm = 5.16 meg–ohms. 					
Preparatior	i for Storage					
	 Some motors have a shipping brace attached to the shaft to prevent damage during transportation. The shipping brace, if provided, must be removed and stored for future use. The brace must be reinstalled to hold the shaft firmly in place against the bearing before the motor is moved. 					
	 Store in a clean, dry, protected warehouse where control is maintained as follows: a. Shock or vibration must not exceed 2 mils maximum at 60 hertz, to prevent the bearings from brinelling. If shock or vibration exceeds this limit vibration isolation pads must be used. 					
	b. Storage temperatures of 10°C (50°F) to 49°C (120°F) must be maintained.					
	 c. Relative humidity must not exceed 60%. d. Motor space beaters (when present) are to be connected and operaized whenever there is a 					
	possibility that the storage ambient conditions will reach the dew point. Space heaters are optional.					
	Note: Remove motor from containers when heaters are energized, reprotect if necessary.					
	3. Measure and record the resistance of the winding insulation (dielectric withstand) every 30 days of					
	a. If motor insulation resistance decreases below the minimum resistance, contact your Baldor District office.					
	b. Place new desiccant inside the vapor bag and re-seal by taping it closed.					

MN406

General Information 1-3

- c. If a zipper-closing type bag is used instead of the heat-sealed type bag, zip the bag closed instead of taping it. Be sure to place new desiccant inside bag after each monthly inspection.
 d. Place the shell over the motor and secure with lag bolts.
- d. Place the shell over the motor and secure with lag bolts.
- 4. Where motors are mounted to machinery, the mounting must be such that the drains and breathers are fully operable and are at the lowest point of the motor. Vertical motors must be stored in the vertical position. Storage environment must be maintained as stated in step 2.
- 5. Motors with anti-friction bearings are to be greased at the time of going into extended storage with periodic service as follows:
 - a. Motors marked "Do Not Lubricate" on the nameplate do not need to be greased before or during storage.
 - b. Ball and roller bearing (anti-friction) motor shafts are to be rotated manually every six months and greased in accordance with the Maintenance section of this manual.
 - c. Sleeve bearing (oil lube) motors are drained of oil prior to shipment. The oil reservoirs must be refilled to the indicated level with the specified lubricant, (see Maintenance). The shaft should be rotated monthly by hand at least 10 to 15 revolutions to distribute oil to bearing surfaces.
 - d. "Provisions for oil mist lubrication" These motors are packed with grease; rotate motor shaft every six months and grease in accordance with the Maintenance section of this manual.
 - e. "Oil Mist Lubricated" These bearings are protected for temporary storage by a corrosion inhibitor. If stored for greater than 3 months or outdoor storage is anticipated, connected to the oil mist system while in storage. If this is not possible, add the amount of grease indicated under "Standard Condition" in Section 3, then rotate the shaft 15 times by hand.
- 6. All breather drains are to be fully operable while in storage (drain plugs removed). The motors must be stored so that the drain is at the lowest point. All breathers and automatic "T" drains must be operable to allow breathing and draining at points other than through the bearings around the shaft. Vertical motors should be stored in a safe stable vertical position.
- 7. Coat all external machined surfaces with a rust preventing material. An acceptable product for this purpose is Exxon Rust Ban # 392.
- 8. Carbon brushes should be lifted and held in place in the holders, above the commutator, by the brush holder fingers. The commutator should be wrapped with a suitable material such as cardboard paper as a mechanical protection against damage.

Non-Regreaseable Motors

Non-regreasable motors with "Do Not Lubricate" on the nameplate should have the motor shaft rotated 15 times to redistribute the grease within the bearing every 3 months or more often.

All Other Motor Types

Before storage, the following procedure must be performed.

- 1. Remove the grease drain plug, if supplied, (opposite the grease fitting) on the bottom of each bracket prior to lubricating the motor.
- 2. The motor with regreasable bearing must be greased as instructed in Section 3 of this manual.
- 3. Standard RPM AC Motors in frames FL180, FL210, and FL 250 (IEC frames FDL 112, FDL132 and FDL160) use double shielded bearings with oversized grease reservoirs that provide lifetime lubrication with no maintenance.
- 4. Replace the grease drain plug after greasing.
- 5. The motor shaft must be rotated a minimum of 15 times after greasing.
- 6. Motor Shafts are to be rotated at least 15 revolutions manually every 3 months and additional grease added every nine months (see Section 3) to each bearing.
- 7. Bearings are to be greased at the time of removal from storage.

Removal From Storage

- 1. Remove all packing material.
- 2. Measure and record the electrical resistance of the winding insulation resistance meter at the time of removal from storage. The insulation resistance must not be less than 50% from the initial reading recorded when the motor was placed into storage. A decrease in resistance indicates moisture in the windings and necessitates electrical or mechanical drying before the motor can be placed into service. If resistance is low, contact your Baldor District office.
- 3. Regrease the bearings as instructed in Section 3 of this manual.
- 4. Reinstall the original shipping brace if motor is to be moved. This will hold the shaft firmly against the bearing and prevent damage during movement.

1–4 General Information

Section 2 Installation & Operation

Overview Installation should conform to the National Electrical Code as well as local codes and practices. When other devices are coupled to the motor shaft, be sure to install protective devices to prevent future accidents. Some protective devices include, coupling, belt guard, chain guard, shaft covers etc. These protect against accidental contact with moving parts. Machinery that is accessible to personnel should provide further protection in the form of guard rails, screening, warning signs etc.

RPM AC[™] motors are high performance motors specifically designed for use with adjustable frequency controllers. The basic design includes Class H insulation, 1.0 service factor, 40°C ambient, continuous duty. Standard enclosures are totally enclosed blower cooled, totally enclosed fan–cooled, totally enclosed nonventilated, totally enclosed air over piggy back and drip–proof force ventilated. Many modifications, and accessories are available. Motors are available as both induction and permanent magnet construction. RPM AC motors are equipped with metric hardware.

It is important that motors be installed in locations that are compatible with motor enclosure and ambient conditions. Improper selection of the motor enclosure and ambient conditions can lead to reduced operating life of the motor.

Proper ventilation for the motor must be provided. Obstructed airflow can lead to reduction of motor life.

- 1. **Open Drip-Proof/WPI** motors are intended for use indoors where atmosphere is relatively clean, dry, well ventilated and non-corrosive.
- 2. Totally Enclosed and WPII motors may be installed where dirt, moisture or dust are present and in outdoor locations.
- 3. FDL112 to DL280 are designed and built in accordance to IEC34-1 and IEC72-1 specifications.
- Note: Motors located in a damp, moist environment must have space heaters to protect against condensation when motor is not operating.

Mechanical Installation

C-Face motor is intended for mounting auxiliary equipment such as pumps and gears. When mounted horizontally Frames FL, RL and L280C thru L360C, (FDL, RDL and DL180Y-DL220Y) and frames L400D thru L4461D, DL250Y – DL280Y must be supported by the feet and not by the C-Face on D-Flange alone. C-Face motors should be supported by the feet and not by the C-Face. Installations requiring a horizontally mounted motor in frames L280C – L440D, FDL, DL180Y-DL280Y must be supported by the feet as well as C-Face, D-Flange or IEC Flange. Failure to observe these precautions can result in bodily injury and equipment damage.
Do not lift the motor and its driven load by the motor lifting hardware. The motor lifting hardware is adequate for lifting only the motor. Disconnect the load (gears, pumps, compressors, or other driven equipment) from the motor shaft before lifting the motor.
If eye bolts are used for lifting a motor, be sure they are securely tightened. The lifting direction should not exceed a 20° angle from the shank of the eye bolt or lifting lug. Excessive lifting angles can cause damage.
RPM AC permanent magnet motors with an open enclosure, such as DP–FV (IP23/IC06), should not be used where ferrous dust or particles may may be present. Totally enclosed permanent magnet motors are recommended for these applications.

After storage or after unpacking and inspection to see that all parts are in good condition, do the following:

- 1. Rotate the motor shaft by hand to be sure there are no obstructions to free rotation.
- 2. A motor that has been in storage for some time should be tested for moisture (dielectric withstand insulation test) and relubricated (regreaseable type) prior to being put into service.
- 3. A motor with roller bearings is shipped with a shaft block. After removing the shaft block, be sure to replace any bolts used to hold the shaft block in place during shipment that are required in service.

Installation & Operation 2-1

NEMA Erama	Hole Dia.	Hole Dia.	ole Dia. Bolt Size for Bolt Grade Hol	Hole Dia.	Bolt Size	Torque NM for Bolt Grade			
	(Inch)	& Thread	SAE 5	SAE 8		(mm)	& Thread	SAE 8.8	SAE 12.9
FL180	0.44	³ / ₈ –16	33–37	47–53	FDL112	12	M10-1.5	50	72
RL210, FL210	0.44	³ / ₈ –16	33–37	47–53	FDL/RDL132	12	M10-1.5	50	72
RL250, FL250	0.56	¹ / ₂ –13	83–93	117–132	FDL/RDL160	15	M12-1.75	126	158
L280, FL280, RL280	0.56	¹ / ₂ –13	83–93	117–132	FDL/RDL180	15	M12-1.75	126	158
L320	0.69	⁵ / ₈ –11	155–176	200–249	DL200	19	M16-2.5	238	337
L360	0.81	³ / ₄ –10	274–310	389–440	DL220	19	M20-2.5	420	596
L400 & L440	1.06	⁷ / ₈ –9	434–486	616–689	DL250	24	M22-2.5	658	934
					DL280	24	M22-2.5	658	934

Table 2–1 Tightening Torque

Stub Shaft Installation

- 1. Turn off and lock out power to the motor.
- 2. Remove in-line blower motor and cover assembly by removing the Hex head cap screws on cover (if enclosure is TEAO-Blower cooled or IC416).

NOTE: An extended blower cover maybe required when a feedback device is installed. Contact your local Baldor District Office for assistance with an in-line blower.

- 3. Check the motor shaft center hole for chips, dirt, or other residue and clean as required.
- 4. Apply an even coat of Loctite 271 (red thread lock) to stub shaft thread.
- 5. Place stub shaft in motor shaft threaded hole and hand tighten.

6. Use a spanner wrench on motor shaft drive end (or alternate means of locking motor shaft), tighten the stub shaft to 20 lb-ft (27NM) for L180 – L440 frames; or 2 lb-ft (2.8NM) for D132–D280 frames).

- 7. Use a dial indicator with .0005" (1.01mm) graduations, indicate the stub shaft to within .002" (.05mm) T.I.R., except for Inland tachometers.
- Inland tachometer stub shafts must indicate to within .001" (.025mm) T.I.R.
- 8. Mount feedback device per manufacturer's instructions.

Stub Shaft Removal

- 1. Turn off and lock out power to the motor.
- 2. Remove in-line blower motor and cover assembly by removing the Hex head cap screws on cover (if enclosure is TEAO-Blower cooled or IC416).
- 3. After removal of blower assembly, motor shaft will need to be locked from turning. The use of a spanner wrench on motor drive shaft or alternate means can be used. Place an open-end wrench on stub shaft flats and turn counter clockwise (right-hand) threads).
- 4. Replace blower motor and cover assembly (if TEAO blower cooled or IC416) with the correct extended blower cover, using the hex head cap screws previously removed.

Mounting Location

All RPM AC motors are designed to be mounted by the "Mounting Feet". Use appropriate hardware (not furnished).

The motor should be installed in a location compatible with the motor enclosure and specific ambient. Allow adequate air flow clearance between the motor and any obstruction. Locate the machine where the ambient temperature does not exceed 104°F (40°C) unless otherwise marked on the nameplate and where clean air has free access to ventilating intake and outlet openings. Except for machines with a suitable protective enclosure (IC06), the location should be clean and dry.

Note: The cooling system on (Non–Finned) frame RPM AC drip proof guarded force ventilated and totally enclosed, blower cooled motors (IC416) requires clean air to be forced through ducts which are integral to the frame. It is important that these air passages be kept clean and that sufficient clearance be provided on the blower motor air inlets and outlets for unrestricted flow of air. For Drip–Proof Force Ventilated Enclosures (IC06) sufficient clearance must be provided on all inlet and outlet openings to provide for unrestricted flow of air. Separately ventilated motors with exhaust to ambient (pipe–in only) must have at least 6 inches of clearance between the opening and adjacent walls or floor.

2-2 Installation & Operation

The motor must be securely installed to a rigid foundation or mounting surface to minimize vibration and maintain alignment between the motor and shaft load. Failure to provide a proper mounting surface may cause vibration, misalignment and bearing damage. All hold down bolts must be the correct grade for the type of mounting and must be torqued to their recommended value.

Foundation caps and sole plates are designed to act as spacers for the equipment they support. If these devices are used, be sure that they are evenly supported by the foundation or mounting surface.

When installation is complete and accurate alignment of the motor and load is accomplished, the base should be grouted to the foundation to maintain this alignment.

The standard motor base is designed for horizontal or vertical mounting. Adjustable or sliding rails are designed for horizontal mounting only. Consult your Baldor District Office for further information.

Belted Drive

Motor slide bases or rails, when used, must be securely anchored to the foundation with the proper bolts. Note: The motor shaft and the load shaft must be parallel and the sheaves aligned.

Coupled Drive

Standard RPM AC Motors will operate successfully mounted on the floor, wall or ceiling, and with the shaft at any angle from horizontal to vertical. Special mountings may have duty or thrust demands that may require a different bearing system.

Alignment Accurate alignment of the motor with the driven equipment is extremely important.

1. Direct Coupling

For direct drive, use flexible couplings if possible. Consult the drive or equipment manufacturer for more information. Mechanical vibration and roughness during operation may indicate poor alignment. Use dial indicators to check alignment. The space between coupling hubs should be maintained as recommended by the coupling manufacturer.

Note: Roller bearing motors are not suitable for coupled duty applications.

2. End-Play Adjustment

The axial position of the motor frame with respect to its load is also extremely important. The motor bearings are not designed for excessive external axial thrust loads. Improper adjustment will cause failure.

3. Pulley Ratio

The pulley ratio should not exceed 8:1.

Caution: Do not over tension belts. Over tension of the V–Belts may result in damage to the motor or driven equipment. Unless otherwise indicated, V–belt load must not exceed values given in Table 2–2.

4. Belt Drive

Align sheaves carefully to minimize belt wear and axial bearing loads (see End-Play Adjustment). Belt tension should be sufficient to prevent belt slippage at rated speed and load. However, belt slippage may occur during starting.

Doweling & Bolting After proper alignment is verified, dowel pins should be inserted through the motor feet into the foundation. This will maintain the correct motor position should motor removal be required.

(Baldor•Reliance motors are designed for doweling.)

- 1. Drill dowel holes in diagonally opposite motor feet in the locations provided.
- 2. Drill corresponding holes in the foundation.
- 3. Ream all holes.
- 4. Install proper fitting dowels.
- 5. Mounting bolts must be carefully tightened to prevent changes in alignment. Use a flat washer and lock washer under each nut or bolt head to hold the motor feet secure. Flanged nuts or bolts may be used as an alternative to washers.

Guarding

WARNING: Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions, should be permanently guarded to prevent accidental contact by personnel. Accidental contact with body parts or clothing can cause serious or fatal injury.

Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions. This is particularly important where the parts have surface irregularities such as keys, key ways or set screws. Some satisfactory methods of guarding are:

- 1. Covering the machine and associated rotating parts with structural or decorative parts of the driven equipment.
- 2. Providing covers for the rotating parts. Covers should be sufficiently rigid to maintain adequate guarding during normal service.

Electrical Installation

Bypass Mode

All RPM AC motors are inverter duty motors using optimum pole design. They are not intended to be used in bypass mode (across the line). Consult your Baldor District Office to determine suitability of motor for specific applications in bypass mode. Permanent magnet motors cannot be run in bypass mode.

- WARNING: Do not touch electrical connections before you first ensure that power has been disconnected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.
- WARNING: The Adjustable Speed Controller may apply hazardous voltages to the motor leads after power to the controller has been turned off. Verify that the controller is incapable of delivering hazardous voltages and that the voltage at the motor leads is zero before proceeding. Failure to observe this precaution may result in severe bodily injury or death.
- Caution: Use only a shielded motor power cable with a complete circumferential braided or copper film/tape ground jacket around the power leads. This ground should be secured to the motor frame from within the motor terminal box and must return without interruption to the drive ground. In addition, if the motor and coupled equipment are not on a single common metal base plate, it is important to equalize the equipment ground potentials by bonding the motor frame to the coupled equipment using a high frequency conductor such as a braided strap.

Note: Main power leads for CE Marked Motors may be marked U,V,W – for standard configurations, please consult connection diagrams.

1. Single Voltage/Three Lead Motors Connect leads marked U/T1_V/T2 and W/T3 to the appropriate control

Connect leads marked U/T1, V/T2 and W/T3 to the appropriate control output terminals (refer to the Controller Instruction Manual). See Figure 2-1.

Figure 2-1 Connection Diagram

Connection Diagram 422927-1



2-4 Installation & Operation

2. Dual Voltage Motors

Be sure the motor leads are connected properly for "Low" or "High" voltage connection, see Figure 2-1. Connect leads marked U/T1, V/T2 and W/T3 to the appropriate control output terminals (refer to the Controller Instruction Manual).

Leads P1 & P2 are thermostat leads. They are to be connected in series with the holding coil of the motor controller, which uses a manual momentary start switch.

Thermostat Leads Connection

* GND is ground lead normally connects

As a standard feature, RPM AC motors have three (3) normally closed thermostats (one per phase) connected in series, with leads P1 and P2 terminated in the main conduit box. To protect against motor overheating, thermostats must be connected to the appropriate controller circuit (function loss). Failure to connect the thermostats will void the motor warranty. Follow the controller instruction manual for correct thermostat lead connections.

Blower Motor Connection Three phase blower motors.

RPM AC motors which are blower cooled incorporate an independently powered three phase AC blower motor to assure continuous cooling air flow regardless of RPM AC motor speed.

The specific RPM AC blower motor depends on frame size and enclosure, see Figures 2-1 and 2-2.

	•				
U1=	Black	(Delta)	(Star)	(Delta)	(Star)
U2=	Green	T6 T4 T5	T6 T4 T5	W2 U2 V2	W2 U2 V2
V1=	Blue				
V2=	White	j i j i 2 j i 3	• ¹¹ • ¹² • ¹³		
W1=	Brown		èL1 èL2èL3	l ↓ L1 ↓ L2 ↓ L3	
W2=	Yellow	Low Volts	High Volts	Low Volts	High Volts
	A A C H			(

Figure 2-2 Blower Motor Connections

to ground lug in blower terminal box. GND= Green/Yellow*

- 1. Connect the blower leads as shown in the connection diagram supplied with the blower motor, see Figure 2-2
- 2. Connect for low or high voltage as shown in Figure 2-1.

Grounding In Europe, the customer is responsible to ensure ground method conforms to IEC and applicable local codes.

In the USA consult the National Electrical Code (NEC), Article 430 for information on grounding of motors and generators, and Article 250 for general information on grounding. In making the ground connection, the installer should make certain that there is a solid and permanent metallic connection between the ground point, the motor or generator terminal housing, and the motor or generator frame.

Motors with resilient cushion rings usually must be provided with a bonding conductor across the resilient member. Some motors are supplied with the bonding conductor on the concealed side of the cushion ring to protect the bond from damage. Motors with bonded cushion rings should usually be grounded at the time of installation in accordance with the above recommendations for making ground connections. When motors with bonded cushion rings are used in multimotor installations employing group fusing or group protection, the bonding of the cushion ring should be checked to determine that it is adequate for the rating of the branch circuit over current protective device being used.

There are applications where grounding the exterior parts of a motor or generator may result in greater hazard by increasing the possibility of a person in the area simultaneously contacting ground and some other nearby live electrical parts of other ungrounded electrical equipment. In portable equipment it is difficult to be sure that a positive ground connection is maintained as the equipment is moved, and providing a grounding conductor may lead to a false sense of security.

Select a motor starter and over current protection suitable for this motor and its application. Consult motor starter application data as well as the National Electric Code and/or other applicable local codes.

Caution: Use only a shielded motor power cable with a complete circumferential braided or copper film/tape ground jacket around the power leads. This ground should be secured to the motor frame from within the motor terminal box and must return without interruption to the drive ground. In addition, if the motor and coupled equipment are not on a single common metal base plate, it is important to equalize the equipment ground potentials by bonding the motor frame to the coupled equipment using a high frequency conductor such as a braided strap.

Due to the high switching frequencies of inverter controls, the ground connection/path must be low impedance, not only low resistance. The NEC grounding instructions are intended to protect from low frequency, high current considerations and are not adequate for grounding of high frequency circuits.

MN406

Installation & Operation 2-5

RPM AC induction motors are designed to operate with a high frequency adjustable speed drive. To avoid damage to the motor and driven equipment due to bearing currents, the motor must be grounded and bonded properly. A low impedance ground conductor should be used to ground all RPM AC motors. Failure to ground the motor properly for high frequency transients (1MHz to 10MHz) may result in electric discharge damage to the motor bearings and/or the driven equipment.

The drive manufacturer should specify a shielded motor power cable that includes a complete circumferential braided or copper film/tape ground. This ground should be secured to the motor frame from within the motor terminal box and must return without interruption to the drive ground. In addition, if the motor and coupled equipment are not on a single common metal base plate, it is important to equalize the equipment ground potentials by bonding the motor frame to the coupled equipment using a high frequency conductor such as a braided strap.

Shipping Blocks

Motors supplied with roller bearings at the drive end are shipped with wooden blocking to prevent axial movement of the shaft during shipment. Remove the blocking and bolts securing it and discard. Make sure motor shafts turn freely. If motor is to be reshipped, blocking of bearing is required.

Encoder Connections

Due to the wide variety of brands and types of feedback devices provided for RPM AC motors, please consult the encoder installation and instruction diagrams provided with the device.

Drain Plugs

If motor is totally enclosed (IP44, IP54, IP55) it is recommended that condensation drain plugs be removed. These are located in the lower portion of the end-shields or bottom of frame on each end for FL180 (FDL112) frame.

Totally enclosed "XT" motors have automatic drains which should be left in place as received.

Drive RPM AC motors FL180 thru FL/RL250 and FDL112 thru FDL160 are supplied with a shaft suitable for a belt or coupled drive.

Belt loads should be verified with maximum allowable radial loads, see "Shaft Loads".

Proper alignment is critical for long life of bearings, shafts and belts, and minimum downtime. Misalignment can cause excessive vibration and damaging forces on shaft and bearings. For direct coupled drives, flexible couplings facilitate alignment. For belt drives, the sheave must be placed as close as possible to the motor bracket.

Minimum V-Belt Sheave Diameters

Application of Pulleys, Sheaves, Sprockets and Gears on Motor Shafts. To avoid excessive bearing loads and shaft stresses, belts should not be tightened more than necessary to transmit the rated torque. The pretension of the V-belt drive should be based on the total tightening force required to transmit the horsepower divided by the number of belts. This procedure avoids the excessive load caused by tightening individual belts to a prescribed level recommended by belt manufacturers. Mounting

In general, the closer pulleys, sheaves, sprockets or gears are mounted to the bearing on the motor shaft, the less will be the load on the bearing. This will give greater assurance of trouble-free service. The center point of the belt, or system of V-belts, must not be beyond the end of the motor shaft. The inner edge of the sheave or pulley rim should not be closer to the bearing than the shoulder on the shaft but should be as close to this point as possible. The outer edge of a chain sprocket or gear must not extend beyond the end of the standard motor shaft.

2-6 Installation & Operation

Shaft Loads – Axial and Radial

RPM AC motors are suitable for limited shaft loads as shown in Tables 2–2 and 2–3. Recommended maximum thrust loads depend on the mounting position, either horizontal or vertical. For recommendations for loads in excess of those shown, for higher speeds and special shaft extensions contact your local Baldor District office.

Caution: Use of these radial load capacities requires the accurate calculation of the radial load. Radial loads for gears, sprockets, and flywheel are usually accurately determined but the radial loads due to V-belt drives are subject to miscalculations because they do not include all of the pre-tension load (belt tightening). The calculations of the radial load for a V-belt drive must include the pre-tension for transmitting the horsepower, pretension for centrifugal force on the belts, pre-tension for high start torques, rapid acceleration or deceleration, pre-tension for drives with short act-of-contact between the V-belt and sheave, and low coefficient of friction between belt and sheave caused by moisture, oil or dust. Over tension of the V-Belts may result in damage to the motor or driven equipment. Unless otherwise indicated, V-belt load must not exceed values given in Table 2-2.

Fromo	Radial Load Capacities at the End of the Shaft in Ib(N)						
Frame	2500 RPM	1750 RPM	1150 RPM	850 RPM			
FL180 / FDL112	445 (1980)	445 (1980)	445 (1980)	445 (1980)			
FL/RL210 / FDL/RDL132	875 (3890)	875 (3890)	875 (3890)	875 (3890)			
FL/RL250 / FDL/RDL160	1375 (6100)	1525 (6765)	1525 (6765)	1525 (6765)			
L280 / FDL/RDL180	1000 (4450)	1175 (5235)	1175 (5235)	1175 (5235)			
UL/UFL/URL280 / UDL180	2400 (10690)	2500 (11140)	2500 (11140)	2500 (11140)			
L320 / DL200	1300 (5785)	1475 (6570)	1475 (6570)	1475 (6570)			
UL320 / UDL200	2850 (12700)	2850 (12700)	2850 (12700)	2850 (12700)			
L360 / DL220	1800 (8020)	2050 (9140)	2300 (10250)	2550 (10250)			
UL360 / UDL220	4550 (20280)	4550 (20280)	4550 (20280)	4550 (20280)			
L400 / DL250	1700 (7580)	1950 (8690)	2250 (10020)	2500 (11140)			
UL400 / UDL250	3625 (16160)	4090 (18230)	4700 (20950)	5190 (23130)			
L440 / DL280	2100 (9350)	2400 (10700)	2800 (12475)	3150 (14030)			
UL440 / UDL280	4650 (20270)	4650 (20270)	4650 (20270)	4650 (20270)			

Table 2–2 Radial Load Capacity– No Axial Load

Data for motors with roller bearings at the drive end (back end).

Motors with ball bearings at the drive end are for coupled duty only.

MN406

								-				
Frame	Horizontal Mounting			Vertical Mounting Thrust Down			Vertical Mounting Thrust Up					
	2500RPM	1750RPM	1150RPM	850RPM	2500RPM	1750RPM	1150RPM	850RPM	2500RPM	1750RPM	1150RPM	850RPM
FL180 /	430	480	480	480	385	455	555	630	445	470	570	645
FDL112	(1910)	(2135)	(2135)	(2135)	(1710)	(2020)	(2470)	(2800)	(1980)	(2090)	(2535)	(2870)
FL/RL210 /	775	880	1015	1125	705	805	905	1005	870	970	1070	1170
FDL/RDL132	(3445)	(3915)	(4515)	(5005)	(3135)	(3580)	(4025)	(4470)	(3870)	(4315)	(4760)	(5205)
FL/RL250 /	1160	1310	1520	1680	1050	1205	1410	1580	1310	1465	1670	1840
FDL/RDL160	(5160)	(5825)	(6760)	(7470)	(4670)	(5360)	(6270)	(7030)	(5825)	(6515)	(7425)	(8185)
L/FL/RL280 / RDL/ FDL/ DL180	590 (2625)	700 (3110)	850 (3780)	975 (4335)	405 (1800)	515 (2290)	665 (2960)	795 (3535)	830 (3690)	940 (4180)	1090 (4845)	1225 (5450)
L320 / DL200	705	835	1020	1170	405	540	730	885	1010	1145	1335	1490
	(3135)	(3715)	(4535)	(5205)	(1800)	(2400)	(3245)	(3935)	(4490)	(5090)	(5935)	(6625)
L360 / DL220	875	1075	1350	1525	380	570	850	1025	1180	1370	1650	1825
	(3890)	(4780)	(6005)	(6780)	(1690)	(2535)	(3780)	(4560)	(5250)	(6095)	(7340)	(8115)
L400 / DL250	1350	1630	2000	2250	760	1110	1500	1765	1955	2305	2695	2960
	(6005)	(7250)	(8895)	(10005)	(3380)	(4935)	(6670)	(7850)	(8695)	(10250)	(11985)	(13165)
L440 / DL280	1300 (5780)	1550 (6895)	1800 (8005)	20 <u>5</u> 0 (9115)	110 (490)	345 (1535)	610 (2710)	825 (3670)	2410 (10720)	2645 (11765)	2910 (12945)	3125 (13900)

Figure 2-3 Accessory Connections

Table 2–3 Axial Thrust Capacity in Ib (N) – for Minimum L–10 Bearing Life of 10,000 Hrs. With No External Overhung Load

Optional Accessories

<u>HEATERS</u>

H1 — WW H2

H1 — VVV— H2

One heater is installed in each end of motor. Leads for each heater are labeled H1 & H2. (Like numbers should be tied together).

RED

Three thermistors are installed in windings.

Leads are labeled TD1-TD6 for shutdown and TD7-TD12 for warning.



BEARING RTD RED WHITE

* One bearing RTD is installed in Drive endplate (PUEP), leads are labeled RTDDE.

* One bearing RTD is installed in Opposite Drive endplate (FREP), leads labeled RTDODE.

* Note RTD may have 2-Red/1-White leads; or 2-White/1-Red Lead.

2-8 Installation & Operation

WARNING: Incorrect motor rotation direction can cause serious or fatal injury or equipment damage. Be sure to verify motor rotation direction before coupling the load to the motor shaft.

WARNING: Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions, should be permanently guarded to prevent accidental contact by personnel. Accidental contact with body parts or clothing can cause serious or fatal injury.

Caution: Do not operate motors with a roller bearing unless a radial load is applied so that damage to the roller bearing does not occur.

First Time Start Up

- 1. Be sure that all power to motor and accessories is off.
- 2. Be sure the motor shaft is disconnected from the load and will not cause mechanical rotation of the motor shaft.
- 3. Remove all unused shaft keys and loose rotating parts to prevent them from flying off.
- 4. Verify the mechanical installation is secure. All bolts and nuts are tightened etc., covers and protective devices are securely in their places.
- 5. If motor has been in storage or idle for some time, check winding insulation integrity.
- 6. Inspect all electrical connections for proper termination, clearance, mechanical strength and electrical continuity.
- 7. Be sure all shipping materials and braces (if used) are removed from motor shaft.
- 8. Manually rotate the motor shaft to ensure that it rotates freely.
- 9. Replace all panels and covers that were removed during installation.
- 10. Momentarily apply power and check the direction of rotation of the motor shaft. If motor rotation is wrong be sure power is off and change the motor lead connections as follows:. RPM AC motors are designed to be capable of bi-directional shaft rotation. When voltages in an A-B-C phase sequence are applied to leads U/T1, V/T2, W/T3 clockwise shaft rotation facing the opposite drive end will result. If shaft rotation is incorrect, change the direction of rotation as follows:
 - a. Turn off and lockout all power to the motor and verify that the voltage at the motor leads is zero.
 - b. Reverse any two of three motor power leads.
 - c. Restore power.
- 11. Start the motor and ensure rotation is correct and operation is smooth without excessive vibration or noise. If so, run the motor for 1 hour with no load connected.
- 12. Momentarily apply power and check the direction of air flow is in agreement with the "direction of air flow" arrows mounted on the motor. If directional flow is incorrect be sure power is off and interchange power leads to T1 and T2 or U1 and V1, Figure 2-2.
- 13. After 1 hour of operation, disconnect power and connect the load to the motor shaft. Verify all coupling guards and protective devices are installed. Ensure motor is properly ventilated.
- 14. If motor is totally enclosed fan-cooled or non-ventilated it is recommended that condensation drain plugs, if present, be removed. These are located in the lower portion of the end-shields. Totally enclosed fan-cooled "XT" motors are normally equipped with automatic drains which may be left in place as received.

While operating the motor, observe the performance. It should run smoothly with little noise. The bearings should not overheat and should reach a leveling off temperature. Any undue noise, overheating, or erratic performance should be investigated and necessary corrective action taken immediately to prevent serious dam age. Please contact your Baldor District office.

All RPM AC motors are lubricated before shipment and will operate for a long period before regreasing is required. The period will vary depending on environmental and service conditions. Refer to Maintenance section.

Air Flow Volume

Separately ventilated motors DPSV, TESV (IP23 IC17 and IP44-IC37) must have the following volume of air to adequately cool the motor unless the nameplate specifies a different value. Cooling air temperature must not exceed the maximum ambient temperature indicated on the nameplate (standard is 40°C). This data applies to all base speeds for frame sizes in Table 2–4.

MN406

Table	2–4	Air	Flow
IUNIC	~ -	~	1 10 11

Froma Siza	DPSV OR TESV Data			
Frame Size	Air Volume M ³ /sec	Static Pressure psi (mm of water)		
FL180 / FDL112	175 (0.083)	2 (50.8)		
RL210 / RDL132	225 (0.106)	3 (76.2)		
RL250 / RDL160	400 (0.189)	3.5 (88.9)		
L280 / DL/RDL280	500 (0.236)	3.75 (95.3)		
L320 / DL200	650 (0.307)	4.5 (114.3)		
L360 / DL225	800 (0.377)	5.25 (133.3)		
L400 / DL250	1100 (0.519)	6.5 (165.1)		
L440 / DL280	1500 (0.707)	7.2 (182.8)		

- WARNING: Do not touch electrical connections before you first ensure that power has been disconnected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.
- WARNING: Surface temperatures of motor enclosures may reach temperatures which can cause discomfort or injury to personnel accidentally coming into contact with hot surfaces. When installing, protection should be provided by the user to protect against accidental contact with hot surfaces. Failure to observe this precaution could result in bodily injury.
- WARNING: Incorrect motor rotation direction can cause serious or fatal injury or equipment damage. Be sure to verify motor rotation direction before coupling the load to the motor shaft.
- WARNING: Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions, should be permanently guarded to prevent accidental contact by personnel. Accidental contact with body parts or clothing can cause serious or fatal injury.
- Caution: Do not operate motors with a roller bearing unless a radial load is applied so that damage to the roller bearing does not occur.
- Caution: RPM AC permanent magnet motors with an open enclosure, such as DP–FV (IP23/IC06), should not be used where ferrous dust or particles may may be present. Totally enclosed permanent magnet motors are recommended for these applications.
- **Operation** During operation observe the motors' performance. It should run smoothly with little noise. The bearings should not overheat and should reach a normal operating temperature. Any undue noise, overheating, or erratic performance should be investigated and corrective action taken immediately to prevent serious damage.

All RPM AC motors are lubricated before shipment and will operate for a long period before regreasing is required. The period will vary depending on environmental and service conditions. Refer to Maintenance section of this manual.

Maximum Safe Speed

The maximum safe operating speed of the motor is listed on the motor nameplate. Do not exceed this speed. When the maximum speed of the motor control can exceed the maximum safe motor speed (motor nameplate value), the speed characteristics of the control must be set so the speed is limited to this maximum.

Balance Motors are dynamically balanced to meet the dynamic balance limits of NEMA MG1 Part 7 second for peak value of the unfiltered velocity in inches per second unless ordered differently. Balance is done with a full length 1/2 height shaft key. A full shaft key is shipped with motor. Sheave or coupling should be balanced with a 1/2 height shaft key. Std. Dynamic Balance Limits.

RPM	NEMA	IEC			
	VelocityPeak (in/sec)	Velocity (mm/sec RMS)			
0-1200	0.15	2.7			
1201-1800	0.15	2.7			
1801-3600	0.15	2.7			
3601-5000	0.2	3.6			
5001-8000	0.2	3.6			

Table 2–5 Dynamic Balance

2-10 Installation & Operation

Section 3 Maintenance & Troubleshooting

WARNING:	UL Listed motors must only be serviced by UL Approved Authorized Baldor Service Centers if these motors are to be returned to a hazardous and/or explosive atmosphere.
WARNING:	Pacemaker danger – Magnetic and electromagnetic fields in the vicinity of current carrying carrying conductors and permanent magnet motors can result result in a serious health hazard to persons with cardiac pacemakers, metal implants, and hearing aids. To avoid risk, stay way from the area surrounding a permanent magnet motor.
WARNING:	RPM AC permanent magnet motors can induce voltage and current in the motor leads by rotating the motor shaft. Electrical shock can cause serious or fatal injury. Therefore, do not couple the load to the motor shaft until all motor connections have been made. During any maintenance inspections, be sure the motor shaft will not rotate.
WARNING:	Do not touch electrical connections before you first ensure that power has been disconnected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.
WARNING:	The Adjustable Speed Controller may apply hazardous voltages to the motor leads after power to the controller has been turned off. Verify that the controller is incapable of delivering hazardous voltages and that the voltage at the motor leads is zero before proceeding. Failure to observe this precaution may result in severe bodily injury or death.
WARNING:	Surface temperatures of motor enclosures may reach temperatures which can cause discomfort or injury to personnel accidentally coming into contact with hot surfaces. When installing, protection should be provided by the user to protect against accidental contact with hot surfaces. Failure to observe this precaution could result in bodily injury.
WARNING:	Guards must be installed for rotating parts such as couplings, pulleys, external fans, and unused shaft extensions, should be permanently guarded to prevent accidental contact by personnel. Accidental contact with body parts or clothing can cause serious or fatal injury.
General Inspec	tion Inspect the motor at regular intervals, approximately every 500 hours of operation or every 3
	months, whichever occurs first. Keep the motor clean and the ventilation openings clear. The following steps should be performed at each inspection:
	 Check that the motor is clean. Check that the interior and exterior of the motor is free of dirt, oil, grease, water, etc. Oily vapor, paper pulp, textile lint, etc. can accumulate and block motor ventilation. If the motor is not properly ventilated, overheating can occur and cause early motor failure.
	 Perform a dielectric with stand test periodically to ensure that the integrity of the winding insulation has been maintained. Record the readings. Immediately investigate any significant decrease in insulation resistance.
	3. Check all electrical connectors to be sure that they are tight.
Relubrication	Bearings Bearing grease will lose its lubricating ability over time, not suddenly.
	The lubricating ability of a grease (over time) depends primarily on the type of grease, the size of the bearing, the speed at which the bearing operates and the severity of the operating conditions. Good results can be obtained if the following recommendations are used in your maintenance program. Relubrication with the shaft stationary and a warm motor is recommended.
Lubrication	Procedure
WARNING:	Disconnect all electrical power from the motor windings and accessory devices before disassembly of the motor. Electrical shock can cause serious or fatal injury.
	1. Relubrication with the shaft stationary and a warm motor is recommended. If lubrication must be done with motor running, stay clear of rotating parts and electrical circuits.
	Wipe all dirt from the outside of the grease fills and drains.
	 Locate the grease inlet at the top of the bearing hub, clean the area and replace the 1/8-inch pipe plug with a grease fitting if the motor is not equipped with grease fitting.
	4. Remove grease drain plug located opposite the grease inlet.
	5. Using a manual grease gun, pump in the recommended grease in the amount shown. This amount of grease will provide an ample supply of lubricant between lubrication periods for the service condition listed in Table 3-6, Table 3-7 and Table 3-8. Use only clean, fresh grease from clean containers and handle so as to keep it clean. In general, mixing of greases is not recommended. If an incompatible grease is used, the lube system must be repacked completely with the new
	grease.

Wipe away any excess grease at the grease drain or relief and replace drain plugs.

MN406

Maintenance & Troubleshooting 3-1

Type of Grease

See the motor nameplate for replacement grease or oil recommendation. Use Mobil Polyrex EM or equivalent grease unless motor nameplate specifies special grease. Amount of grease to be added to RPM AC motors. See Table 3-8 for relubrication interval.

Table 3-6 Relubrication Amount

Frame Size	Vol. in Cubic in ³ (cm ³)	Weight oz (gram)
L, RL, FL280, DL180, RDL,FDL180	1.0 (16)	0.5 (14)
L320 thru L360, DL200 thru DL225	1.5 (24)	0.75 (21)
L400 thru L440, DL250 thru DL280	2.5 (40)	1.25 (35)

Note: NEMA frames FL/RL180, FL/RL210 and FL/RL250 (IEC frames FDL112, FDL/RDL132–160) have maintenance free non regreasable double shielded ball bearings as standard. The 280–440 frames have open ball bearings, with inner caps as part of PLS System.

Determine service condition on the basis of the most severe operating parameter; that is temperature, bearing load, atmosphere, or operating hours per day.

Table 3-7 Service Condition

Service Condition	Ambient	Use/Day	Atmosphere	Bearing Load
Standard	–18°C to 40°C (0°F to 104°F)	8	Clean	Steady
Severe	–30°C to 50°C (−22°F to 122°F)	8 to 24	Medium Dirt, Abrasives,Corrosion	Medium Shock, Vibration (less than .2 in/sec.)
Extreme	–54°C to 65°C (−65°F to 149°F)	8 to 24	Heavy Dirt, Abrasives, Corrosion	Heavy Shock, Vibration (more than .44 in/sec)

 — Motors must be specially designed for operation in ambient in this range. Special grease is required.

 Table 3-8 Relubrication Periods For RPM AC Motors

Maximum Normal	F rom a	Relubrication Interval in Months 2			
Operating Speed RPM 1	Frame	Standard Service	Severe Service	Extreme Service	
3450 and higher	All	9	4	1	
2400 thru 3449	DL180 thru DL280 L, RL/FL280 thru L440	9	3	1	
	FDL180 thru DL200 L, RL/FL280 thru L320	36	12	3	
1700 thru 2399	DL225 thru DL280 L360 thru L440	18	6	2	
	UDL225 thru UDL280 UL360 thru UL440	9	3	1	
	FDL180 thru DL200 L, FL/RL280 thru L320	36	24	8	
800 thru 1699	DL225 thru DL280 L360 thru L440	36	12	3	
	UDL225 thru UDL280 UL360 thru UL440	9	6	1	
	FDL180 thru DL200 L, FL/RL280 thru L320	48	36	12	
500 thru 799	DL225 thru DL280 L360 thru L440	36	24	8	
	UDL225 thru UDL280 UL360 thru UL440	18	12	4	
400 and lower	FDL180 thru DL200 UDL225 thru UDL280	48 24	36 18	12 6	
455 and lower	L, FL/RL280 thru L440 UL360 thru UL440	48 24	36 18	12 6	

Maximum speed occurs more than 30% of operating time.

2 - For Tandem drives increase frequency of lubrication by multiplying values by 0.8

3-2 Maintenance & Troubleshooting

Table 3-9 Troubleshooting Chart

Symptom	Possible Causes	Possible Solutions		
Motor will not start	Usually caused by line trouble, such	heck source of power. Check overloads, fuses,		
	as, single phasing at the starter.	controls, etc.		
Excessive humming	High Voltage.	Check input line connections.		
	Eccentric air gap.	Have motor serviced at local Baldor service center.		
Motor Over Heating	Overload. Compare actual amps	Locate and remove source of excessive friction in		
	(measured) with nameplate rating.	motor or load.		
		Reduce load or replace with motor of greater capacity.		
	Single Phasing.	Check current at all phases (should be approximately		
		equal) to isolate and correct the problem.		
	Improper ventilation.	Check external cooling fan to be sure air is moving		
		properly across cooling fins.		
		Excessive dirt build-up on motor. Clean motor.		
	Unbalanced voltage.	Check voltage at all phases (should be approximately		
	Deter withing on states	equal) to isolate and correct the problem.		
	Rotor rubbing on stator.	Check air gap clearance and bearings.		
		Ingriteri Triru Boits .		
	Over voltage or under voltage.	Check input voltage at each phase to motor.		
	Open stator winding.	Check stator resistance at all three phases for		
		balance.		
	Grounded winding.	Perform dielectric test and repair as required.		
	Improper connections.	Inspect all electrical connections for proper		
		electrical continuity. Refer to motor lead connection		
		diagram		
Rearing Over Heating	Misalignment	Check and align motor and driven equipment		
Dealing Over meaning	Excessive belt tension	Beduce belt tension to proper point for load		
	Excessive and thrust	Beduce the end thrust from driven machine		
	Excessive grease in hearing	Remove grease until cavity is approximately 3/, filled		
	Licessive grease in bearing.	Add groase until eavity is approximately 3/ filled		
	Dirt in boaring	Clean bearing equity and bearing. Benack with corre		
	Dirt in bearing.	grease until cavity is approximately 3/, filled		
Vibration	Misalianment	Check and align motor and driven equipment		
VIDIATION	Rubbing botwoon rotating parts and	Isolato and oliminato causo of rubbing		
	stationary parts	Isolate and eliminate cause of rubbing.		
	Botor out of balance	Have rotor balance checked are repaired at your		
		Baldor Service Center.		
	Resonance	Tune system or contact your Baldor Service Center		
		for assistance.		
Noise	Foreign material in air gap or	Remove rotor and foreign material. Reinstall rotor.		
	ventilation openings.	Check insulation integrity. Clean ventilation openings.		
Growling or whining	Bad bearing.	Replace bearing. Clean all grease from cavity and		
		new bearing. Repack with correct grease until cavity		
		is approximately 3/4 filled.		

Suggested bearing and winding RTD setting guidelines for Non-Hazardous Locations ONLY

Most large frame AC Baldor•Reliance motors with a 1.15 service factor are designed to operate below a Class B (80°C) temperature rise at rated load and are built with a Class H winding insulation system. Based on this low temperature rise, RTD (Resistance Temperature Detectors) settings for Class B rise should be used as a starting point. Some motors with 1.0 service factor have Class F temperature rise.

The following tables show the suggested alarm and trip settings for RTDs. Proper bearing and winding RTD alarm and trip settings should be selected based on these tables unless otherwise specified for specific applications.

If the driven load is found to operate well below the initial temperature settings under normal conditions, the alarm and trip settings may be reduced so that an abnormal machine load will be identified.

The temperature limits are based on the installation of the winding RTDs imbedded in the winding as specified by NEMA. Bearing RTDs should be installed so they are in contact with the outer race on ball or roller bearings or in direct contact with the sleeve bearing shell.

Motor Load	Class B Tem _l (Typical	Class B Temp Rise ≤ 80°C (Typical Design)		Class F Temp Rise ≤ 105°C		Class H Temp Rise ≤ 125°C	
-	Alarm	Trip	Alarm	Trip	Alarm	Trip	
≤ Rated Load	130	140	155	165	175	185	
Rated Load to 1.15 S.F.	140	150	160	165	180	185	

Winding RTDs – Temperature Limit In °C (40°C Maximum Ambient)

Note: • Winding RTDs are factory production installed, not from Mod-Express.

• When Class H temperatures are used, consider bearing temperatures and relubrication requirements.

Bearing RTDs – Temperature Limit In °C (40°C Maximum Ambient)

Bearing Type Grease	Anti-Friction		
	Alarm	Trip	
Standard	100	110	

Axial Float

RPM AC motors have a wave spring washer between the drive end bracket and bearing. The opposite drive end bearing is positioned axially by a float restricting inner cap. Axial float (including bearing internal clearance) should be within the following limits:

	Maximum		Minimu	ım
Frame Size	In.	mm.	In.	mm.
FL180 thru L440 (FDL112 thru DL280)	.051	1.29	.013	.33

Axial Float -In./Min.

The L440 (DL280) frame wavy spring is located on the opposite drive end.

MASSACHUSETTS BOSTON 6 PULLMAN STREET WORCESTER, MA 01606 PHONE: 508-854-0708 FAX: 508-854-0291 MICHIGAN 5993 ProgressDrive STERLING HEIGHTS, MI 48312 PHONE: 586-978-9800 FAX: 586-978-9969 MINNESOTA MINNEAPOLIS 21080 134TH AVE. NORTH ROGERS, MN 55374 PHONE: 763-428-3633 FAX: 763-428-4551 MISSOURI ST LOUIS 422 INDUSTRIAL DRIVE MARYLAND HEIGHTS, MO 63043 PHONE: 314-298-1800 FAX: 314-298-7660 KANSAS CITY 1501 BEDFORD AVENUE NORTH KANSAS CITY, MO 64116 PHONE: 816-587-0272 FAX: 816-587-3735 NEW YORK AUBURN ONE FLUS DRIVE 65 SOUTH TURNPIKE ROAD WALLINGFORD, CT 06492 AUBURN, NY 13021 PHONE: 315-255-3403 FAX: 315-253-9923 NORTH CAROLINA GREENSBORO 1220 ROTHERWOOD ROAD GREENSBORO, NC 27406 PHONE: 336-272-6104 FAX: 336-273-6628 OHIO CINCINNATI 2929 CRESCENTVILLE ROAD WEST CHESTER, OH 45069 PHONE: 513-771-2600 FROME: 513-771-2000 FAX: 513-772-2219 CLEVELAND 8929 FREEWAY DRIVE MACEDONIA, OH 44056 PHONE: 330-468-4777 FAX: 330-468-4778 OKLAHOMA TULSA 7170 S. Braden, Suite140 Tulsa, OK 74136 PHONE: 918-366-9320 5525 W. MINNESOTA STREET FAX: 918-366-9338 OREGON REGON PORTLAND 20393 SW AVERY COURT TUALATIN, OR 97062 PHONE: 503-691-9010 FAX: 503-691-9012 1800 DIXON STREET, SUITE C DES MOINES, IA 50316 PHONE: 515-263-6929 PENNSYLVANIA PHILADELPHIA 1035 THOMAS BUSCH MEMORIAL HIGHWAY PENNSAUKEN, NJ 08110 PHONE: 856-661-1442 FAX: 856-663-6363

UNITED STATES ARIZONA PHOENIX

4211 S 43RD PLACE PHOENIX, AZ 85040

PHONE: 602-470-0407

PHONE: 602-470-0407 FAX: 602-470-0464 **ARKANSAS CLARKSVILLE** 1001 COLLEGE AVE. CLARKSVILLE, AR 72830 PHONE: 479-754-9108

CHAINE 479-754-9108 FAX: 479-754-9205 CALIFORNIA LOS ANGELES 6480 FLOTILLA COMMERCE, CA 90040 PHONE: 323-724-6771 FAX: 323-724-6859 HAYWARD, CA 94545 PHONE: 510-785-9900 FAX: 510-785-9910

FAX: 510-785-9910 COLORADO

DENVER 3855 ForestStreet Denver, CO 80207 PHONE: 303-623-0127 FAX: 303-595-3772 CONNECTICUT

WALLINGFORD

FAX: 203-269-5485

PHONE: 203-269-1354

TAMPA/PUERTO RICO/

TAMPA, FL 33605 PHONE: 813-248-5078 FAX: 813-247-2984

ATLANTA 62 TECHNOLOGY DR.

FAX: 770-772-7200

CHICAGO 4 SAMMONS COURT

FAX: 630-226-9420 INDIANA INDIANAPOLIS

IOWA DES MOINES

BOLINGBROOK, IL 60440 PHONE: 630-296-1400

INDIANAPOLIS, IN 46241 PHONE: 317-246-5100 FAX: 317-246-5110

FAX: 515-263-6515 MARYI AND

ELKRIDGE, MD 21075 PHONE: 410-579-2135

FAX: 410-579-2677

BALTIMORE 6660 SANTA BARBARA RD. SUITE 22-24

ALPHARETTA, GA 30005 PHONE: 770-772-7000

GEORGIA

ILL INOIS

VIRGIN ISLANDS 3906 EAST 11TH AVENUE

DENVER

PITTSBURGH 159 PROMINENCE DRIVE NEW KENSINGTON, PA 15068 PHONE: 724-889-0092 FAX: 724-889-0094 TENNESSEE MEMPHIS 4000 WINCHESTER ROAD MEMPHIS, TN 38118 PHONE: 901-365-2020 FAX: 901-365-3914 TEXAS DALLAS 3040 QUEBEC DALLAS, TX 75247 PHONE: 214-634-7271 FAX: 214-634-8874 HOUSTON 10355 W. LittleYorkRd. Suite300 Suite300 Houston, TX 77041 PHONE: (281) 977-6500 FAX: (281) 977-6510 UTAH SALT LAKE CITY 2230 SOUTH MAIN STREET SALT LAKE CITY, UT 84115 PHONE: 801-832-0127 FAX: 801-832-8911 WISCONSIN 2725 SOUTH 163RD STREET NEW BERLIN, WI 53151 PHONE: 262-784-5940 FAX: 262-784-1215 INTERNATIONAL SALES FORT SMITH, AR P.O. BOX 2400 FORT SMITH, AR 72902 PHONE: 479-646-4711 FAX: 479-648-5895 CANADA

PHONE: 780-434-4900 FAX: 780-438-2600 TORONTO OAKVILLE, ONTARIO 2750 COVENTRY ROAD OAKVILLE, ONTARIO L6H 6R1 PHONE: 905-829-3301 FAX: 905-829-3302 MONTREAL, QUEBEC 5155, J.A. Bombardier St-Hubert(Québec) Canada J3Z 1G4 PHONE: 514-933-2711 FAX: 514-933-8639 VANCOUVER, BRITISH COLUMBIA 1538 KEBET WAY PORT COQUITLAM FOR LCOQUILLAM, BRITISH COLUMBIA V3C 5M5 PHONE 604-421-2822 FAX: 604-421-3113 WINNIPEG, MANITOBA 54 PRINCESS STREET WINNIPEG, MANITOBA R3B 1K2 PHONE: 704.404 575 PHONE: 204-942-5205 FAX: 204-956-4251

AUSTRALIA UNIT 3, 6 STANTON ROAD SEVEN HILLS, NSW 2147, AUSTRALIA PHONE: (61) (2) 9674 5455 FAX: (61) (2) 9674 2495 UNIT 8, 5 KELLETTS ROAD ROWVILLE, VICTORIA, 3178 ALISTRALIA PHONE: (61) (3) 9753 4355 FAX: (61) (3) 9753 4366

ELSALVADOR RESIDENCIAL PINARES DE SUIZA POL. 15 #44, NVA. SAN SALVADOR, EL SALVADOR PHONE: +503 2288-1519 FAX: +503 2288-1518

CHILE LuisThayerOjeda166, of402 - Providencia Santiago, Chile Phone: +56 2 816 9900

CHINA 160 SongSHENG road SongjiangINDUSTRY ZONE Shanghai201613, China PHONE: +86 21 5760 5335 Fax: +86 21 5760 5336

GERMANY DIESELSTRASSE 22 D-85551 KIRCHHEIM MUNICH, GERMANY PHONE: +49 89 90 5080 FAX: +49 89 90 50 8492

INDIA 14, COMMERCE AVENUE MAHAGANESH COLONY PAUD ROAD PUNE - 411038 MAHARASHTRA, INDIA PHONE: +91 20 25 45 27 17 / 18 FAX: +91 20 25 45 27 19

ITALY BaldorASR AG SUCCURSALE DI Mendrisio ViaBorromini, 20A CH-6850 Mendrisio Switzerland PHONE: 0041 91 640 99 50 FAX: 0041 91 630 26 33

JAPAN DIA BLDG 802. 2-21-1 TSURUYA-CHO, KANAGAWA-KU YOKOHAMA, 221-0835, JAPAN PHONE: 81-45-412-4506 FAX: 81-45-412-4507

MEXICO LEON, guanajuato KM. 2.0 BLVD. AEROPUERTO LEÓN 37545, GUANAJUATO, MÉXICO PHONE: +52 477 761 2030 FAX: +52 477 761 2010

MIDDLE EAST & NORTH AFRICA VSE INTERNATIONAL CORP. P. O. BOX 5618

BUFFALO GROVE, IL 60089-5618 PHONE: 847 590 5547 FAX: 847 590 5587

PANAMA AVE. RICARDO J. ALFARO EDIFICIO SUN TOWERS MALL PISO 2, LOCAL 55 CiudaddePanamá, Panamá PHONE: +507 236-5155 Fax: +507 236-0591

SINGAPORE 18 KAKI BUKIT ROAD 3, #03-09 ENTREPRENEUR BUSINESS CENTRE SINGAPORE 415978 PHONE: (65) 6744 2572 FAX: (65) 6747 1708

SWITZERLAND POSTFACH 73 SCHUTZENSTRASSE 59 CH-8245 FEUERTHALEN SWITZERLAND PHONE: +41 52 647 4700 FAX: +41 52 659 2394

TAIWAN 1F. No126 Wenshan3rdStreet. NantunDistrict, TaichungCity408 TaiwanR 0 C PHONE: (886) 4 238 04235 FAX: (886) 4 238 04463

UNITED KINGDOM 6 BRISTOL DISTRIBUTION PARK HAWKLEY DRIVE BRISTOL BS32 0BF U.K. PHONE: +44 1454 850000 FAX: +44 1454 859001

VENEZUELA Av. Roma. QtaelMilagro. Urb. CaliforniaNorte Caracas 1070 Venezuela Phone/fax: +58 212 272 7343 mobile: +58 414 114 8623

EDMONTON, ALBERTA 4053-92 STREET EDMONTON, ALBERTA T6E 6R8





A MEMBER OF THE ABB GROUP BALDOR ELECTRIC COMPANY P.O. Box 2400 Fort Smith, AR 72901–2400 (479) 646–4711 Fax (479) 648–5792 www.baldor.com

© 2008 Baldor Electric Company MN406

All rights reserved. Printed in USA 3/09