Nikon

DIGITAL CAMERA

COOLPIX L105

User's Manual





Trademark Information

- Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Macintosh, Mac OS, and QuickTime are trademarks of Apple Inc., registered in the U.S. and other countries.
- Adobe and Acrobat are registered trademarks of Adobe Systems Inc.
- SD and SDHC Logos are trademarks of SD-3C, LLC.
- PictBridge is a trademark.
- All other trade names mentioned in this manual or the other documentation provided with your Nikon product are trademarks or registered trademarks of their respective holders.

AVC Patent Portfolio License

This product is licensed under the AVC Patent Portfolio License for the personal and non-commercial use of a consumer to (i) encode video in compliance with the AVC standard ("AVC video") and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, L.L.C. See http://www.mpegla.com.

Introduction	
First Steps	
Basic Photography and Playback: 🗖 Easy Auto Mode	
More on Shooting	
More on Playback	
Editing Image	
Movie Recording and Playback	
Connecting to Televisions, Computers and Printers	
Basic Camera Setup	
Notes on Camera Care and General Usage	
Technical Notes	

For Your Safety

To prevent damage to your Nikon product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them. The consequences that could result from failure to observe the precautions listed in this section are indicated by the following symbol:



This icon marks warnings, information that should be read before using this Nikon product, to prevent possible injury.

WARNINGS



★ Turn off in the event of malfunction

Should you notice smoke or an unusual smell coming from the camera or AC adapter, unplug the AC adapter and remove the battery immediately, taking care to avoid burns. Continued operation could result in injury. After removing or disconnecting the power source, take the equipment to a Nikonauthorized service representative for inspection.



♠ Do not disassemble

Touching the internal parts of the camera or AC adapter could result in injury. Repairs should be performed only by qualified technicians. Should the camera or AC adapter break open as the result of a fall or other accident. take the product to a Nikon-authorized service representative for inspection, after unplugging the product and/or removing the battery.

♠ Do not use the camera or AC adapter in the presence of flammable gas

Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.

Mandle the camera strap with care

Never place the strap around the neck of an infant or child



★ Keep out of reach of children

Particular care should be taken to prevent infants from putting the battery or other small parts into their mouths



♠ Do not remain in contact with the camera, battery charger, or AC adapter for extended periods while the devices are on or in use

Parts of the devices become hot. Leaving the devices in direct contact with the skin for extended periods may result in low-temperature burns.

⚠ Observe caution when handling the battery

The battery may leak or explode if improperly handled. Observe the following precautions when handling the battery for use in this product:

- Before replacing the battery, turn the product off. If you are using the AC adapter, be sure it is unplugged.
- Use only the batteries approved for use in this product (14). Do not combine old and new batteries or batteries of different makes or types.
- When charging Nikon EN-MH2 rechargeable Ni-MH batteries, use only the specified charger and charge the batteries four at a time. When replacing the batteries with FN-MH2-B2 batteries (available separately), purchase two sets (total of four batteries).
- The EN-MH2 rechargeable batteries are for use with Nikon digital cameras only, and are compatible with COOLPIX I 105.
- Insert batteries in the correct orientation.
- Do not short or disassemble the battery or attempt to remove or break the battery insulation or casing.
- Do not expose the battery to flame or to excessive heat.
- Do not immerse in or expose to water
- Do not transport or store with metal objects such as necklaces or hairpins.
- Batteries are prone to leakage when fully discharged. To avoid damage to the product, be sure to remove the battery when no charge remains.

- Discontinue use immediately should you notice any change in the battery, such as discoloration or deformation.
- If liquid from the damaged battery comes in contact with clothing or skin, rinse immediately with plenty of water.

⚠ Observe the following precautions when handling the **Battery Chargers (available** separately)

- Keep Dry. Failure to observe this precaution could result in fire or electric shock.
- Dust on or near the metal parts of the plug should be removed with a dry cloth. Continued use could result in fire.
- Do not handle the power cable or go near the battery charger during lightning storms. Failure to observe this precaution could result in electric shock
- Do not damage, modify, forcibly tug or bend the power cable, place it under heavy objects, or expose it to heat or flame Should the insulation be damaged and the wires become exposed, take it to a Nikon-authorized service representative for inspection. Failure to observe these precautions could result in fire or electric shock.
- Do not handle the plug or battery charger with wet hands. Failure to observe this precaution could result in electric shock.
- Do not use with travel converters or adapters designed to convert from one voltage to another or with DC-to-AC inverters. Failure to observe this precaution could damage the product or result in overheating or fire.

Use appropriate cables

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose, to maintain compliance with product regulations.



Mandle moving parts with care

Be careful that your fingers or other objects are not pinched by the lens cover or other moving parts.



The CD-ROMs supplied with this device should not be played back on audio CD equipment. Playing CD-ROMs on an audio CD player could cause hearing loss or damage the equipment.



♠ Observe caution when using the flash

Using the flash close to your subject's eyes could cause temporary visual impairment. Particular care should be observed if photographing infants, when the flash should be no less than 1 m (3 ft 4 in.) from the subject.



♠ Do not operate the flash with the flash window touching a person or object

Failure to observe this precaution could result in burns or fire.

Avoid contact with liquid crystal

Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent liquid crystal from the monitor touching the skin or entering the eyes or mouth.



★ Turn the power off when using inside an airplane or the hospital

Turn the power off while inside the airplane during take off or landing. Follow the instructions of the hospital when using while in a hospital. The electromagnetic waves given out by this camera may disrupt the electronic systems of the airplane or the instruments of the hospital.

Notices

Notice for Customers in the U.S.A.

Federal Communications Commission (FCC) Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.



CAUTIONS

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

Interface Cables

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC rules.

Notice for customers in the State of California

WARNING

Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm.

Wash hands after handling.

Nikon Inc.,

1300 Walt Whitman Road Melville, New York 11747-3064 USA

Tel: 631-547-4200

Notice for customers in Canada

CAUTION

This Class B digital apparatus complies with Canadian ICFS-003.

ATTENTION

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

Symbol for Separate Collection in European Countries

This symbol indicates that this product is to be collected separately.



The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

This symbol on the battery indicates that the battery is to be collected separately.



The following apply only to users in European countries:

- All batteries, whether marked with this symbol or not, are designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

Table of Contents

For Your Safety	!!
WARNINGS	ii
Notices	
Introduction	
About This Manual	1
Information and Precautions	
Parts of the Camera	4
The Camera Body	4
Raising and Lowering the Built-in Flash	
Attaching the Camera Strap and Lens Cap	7
The Monitor	8
Basic Operations	10
(shooting mode) button	10
▶ (playback) button	10
(movie-record) button	10
The Multi Selector	11
MENU button	12
Switching Between Tabs	12
Help Displays	13
About the Shutter-release Button	
First Steps	
Inserting the Batteries	14
Applicable Batteries	14
Turning On and Off the Camera	14
Setting Display Language, Date and Time	
Inserting Memory Cards	18
Removing Memory Cards	19

Table of Contents

Basic Photography and Playback: 🗳 Easy Auto Mode			
Step 1 Turn the Camera On and Select ݣ (Easy Auto) Mode	20		
Indicators Displayed in 🏅 (Easy auto) Mode			
Step 2 Frame a Picture	22		
Using the Zoom	23		
Step 3 Focus and Shoot	24		
Step 4 Viewing and Deleting Images	26		
Viewing Images (Playback Mode)	26		
Deleting Images	26		
Easy Auto Mode	28		
Using the Flash	29		
Taking Pictures with the Self-timer	32		
Adjusting the Brightness: Exposure Compensation	33		
More on Shooting	34		
Selecting Shooting Mode	34		
Shooting Suited for the Scene (Scene Mode)			
Selecting a Scene Mode	35		
Features	36		
Taking Pictures for a Panorama	42		
Capturing Smiling Faces Automatically (Smart Portrait Mode)	44		
Shooting Continuously at High Speed (Sport Continuous)	46		
Sport Continuous Menu	47		
Auto Mode	48		
Macro Mode	49		
Shooting Menu (Auto Mode)	50		
Displaying the Shooting Menu	50		
♠ Image Mode (Image Quality/Image Size)	51		
WB White Balance (Adjusting hue)	53		
Continuous	55		
ISO ISO Sensitivity	56		
Color Options	57		
Camera Settings that Cannot Be Set at the Same Time	58		

More on Playback		
Full-frame Operation	59	
Viewing Multiple Images: Thumbnail Playback		
Calendar Display		
Taking a Closer Look: Playback Zoom		
Playback Menu		
■ Slide Show	66	
T Delete		
Editing Image		
Image Editing Function	69	
Editing Images	70	
D-Lighting: Enhancing Brightness and Contrast	70	
Small Picture: Resizing Images	71	
🗶 Crop: Creating a Cropped Copy	72	
Movie Recording and Playback	73	
Recording Movies	73	
Movie Menu	75	
堺 Movie Options	77	
Autofocus Mode	78	
Movie Playback	79	
Deleting Movies	79	
Connecting to Televisions, Computers and Printers	80	
Connecting to a TV	80	
Connecting to a Computer	81	
Before Connecting the Camera	81	
Transferring Images from a Camera to a Computer	82	
Connecting to a Printer	86	
Connecting the Camera and Printer	87	
Printing Images One at a Time	88	
Printing Multiple Images	89	

Table of Contents

Basic Camera Setup			
Setup Menu			
Menus			
₩ Welcome Screen	96		
Date	97		
Monitor Settings	100		
ME Date Imprint	102		
(Vibration Reduction	103		
🔊 Motion Detection	104		
Sound Settings	105		
② Auto Off	106		
🖪 Format Memory/🗋 Format Card	107		
▶ Language	108		
TV Settings	108		
🗷 Blink Warning	109		
Reset All	110		
🖁 Battery Type			
On Protect			
🗗 Rotate Image	113		
Copy: Copying Between Memory Card and Internal Memory	114		
Yet Firmware Version	115		
Notes on Camera Care and General Usage	116		
Caring for the Camera	116		
Cleaning			
Storage			
Technical Notes	120		
Optional Accessories	120		
Approved Memory Cards	120		
Image File and Folder Names	121		
Error Messages			
Troubleshooting	126		
Specifications	131		
Supported Standards	134		
Index	135		

About This Manual

Thank you for purchasing a Nikon COOLPIX L105 digital camera. This manual was written to help you enjoy taking pictures with your Nikon digital camera. Read this manual thoroughly before use, and keep it where all those who use the product will read it.

Symbols and Conventions

To make it easier to find the information you need, the following symbols and conventions are used:



This icon marks cautions information that should be read before use, to prevent damage to the camera.



This icon marks tips, additional information that may be helpful when using the camera.



This icon marks notes, information that should be read before using the camera.



This icon indicates that more information is available elsewhere in this manual or in the Ouick Start Guide

Notations

- A Secure Digital (SD) memory card is referred to as a "memory card".
- The setting at the time of purchase is referred to as the "default setting".
- The names of menu items displayed in the camera monitor, and the names of buttons or messages displayed in the computer monitor appear in bold.

Screen Samples

In this manual, images are sometimes omitted from monitor display samples so that monitor indicators can be more clearly shown.

Illustrations and Screen Display

Illustrations and text displays shown in this manual may differ from actual display.



Memory Cards

Images taken with this camera can be saved in the camera's internal memory or on removable memory cards. If a memory card is inserted, all new images will be saved on the memory card and delete, playback and format operations will apply only to the images on the memory card. The memory card must be removed before the internal memory can be formatted or used to save, delete or view images.

Information and Precautions

Life-Long Learning

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually updated information is available online at the following sites:

- For users in the U.S.A.: http://www.nikonusa.com/
- For users in Europe and Africa: http://www.europe-nikon.com/support/
- For users in Asia, Oceania, and the Middle East: http://www.nikon-asia.com/

Visit these sites to keep up-to-date with the latest product information, tips, answers to frequently asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. See the URL below for contact information:

http://imaging.nikon.com/

Use Only Nikon Brand Electronic Accessories

Nikon COOLPIX cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including battery chargers, batteries and AC adapters) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry.

The use of non-Nikon electronic accessories could damage the camera and may void your Nikon warranty.

For more information about Nikon brand accessories, contact a local authorized Nikon dealer.

Before Taking Important Pictures

Before taking pictures on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning correctly. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

About the Manuals

- No part of the manuals included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission.
- Nikon reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- Nikon will not be held liable for any damages resulting from the use of this product.
- While every effort was made to ensure that the information in these manuals is accurate and complete, we would appreciate it were you to bring any errors or omissions to the attention of the Nikon representative in your area (address provided separately).

Notice Concerning Prohibition of Copying or Reproduction

Note that simply being in possession of material that was digitally copied or reproduced by means of a scanner, digital camera or other device may be punishable by law.

· Items prohibited by law from being copied or reproduced

Do not copy or reproduce paper money, coins, securities, government bonds or local government bonds, even if such copies or reproductions are stamped "Sample". The copying or reproduction of paper money, coins, or securities that are circulated in a foreign country is prohibited. Unless the prior permission of the government was obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited. The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

· Cautions on certain copies and reproductions

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards and tickets, such as passes and meal coupons.

· Comply with copyright notices

The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcut prints, maps, drawings, movies and photographs is governed by national and international copyright laws. Do not use this product for the purpose of making illegal copies or to infringe copyright laws.


Disposing of Data Storage Devices

Please note that deleting images or formatting data storage devices such as memory cards or builtin camera memory does not completely erase the original image data. Deleted files can sometimes be recovered from discarded storage devices using commercially available software, potentially resulting in the malicious use of personal image data. Ensuring the privacy of such data is the user's responsibility.

Before discarding a data storage device or transferring ownership to another person, erase all data using commercial deletion software, or format the device and then completely refill it with images containing no private information (for example, pictures of empty sky). Be sure to also replace any pictures selected for the welcome screen (96). Care should be taken to avoid injury or damage to property when physically destroying data storage devices.


Parts of the Camera


The Camera Body



		Zoom control	23
ı		W : wide	23
	1	T : tele	23
		: thumbnail playback	60
		👇 : playback zoom	62
		? : help	13
	2	Shutter-release button24	
	3	Self-timer lamp32	
4		Power switch/Power-on lamp	
		2	0, 106
	5	Speaker79	

6	Built-in microphone73
7	Eyelet for camera strap7
8	Built-in flash6, 29
9	USB connector and audio/video output80, 82, 87
10	Pin cover80, 82, 87
11	Lens118, 131
12	DC input connector (for AC adapter available separately from Nikon) 15, 120
13	DC input connector cover15





1	Monitor
2	Multi selector1
3	(shooting mode) button10
4	● (movie-record) button10
5	Flash lamp29
6	(apply selection) button1
7	▶ (playback) button10, 26
8	Eyelet for camera strap

9	Battery-chamber/ memory card slot cover14, 18
10	(delete) button26, 79
11	MENU button
12	Tripod socket
13	Battery-chamber14
14	Memory card slot18

Raising and Lowering the Built-in Flash

Raising the built-in flash

See "Using the Flash" (\square 29) for more information about flash settings.



Lowering the Built-in Flash.


Push the built-in flash down gently to lower the built-in flash when not in use.



Attaching the Camera Strap and Lens Cap

Attach the lens cap to the camera strap, and then attach the strap to the camera (at two places).







Lens Cap


- Remove the lens cap before you shoot a picture.
- At times when you will not be shooting pictures such as when the power is off or while you are carrying the camera, attach the lens cap to the camera to protect the lens.

The Monitor

The following indicators may be displayed in the monitor during shooting and playback (actual display varies with current camera settings).


The indicators and photo info displayed during shooting and playback will turn off after a few seconds (100).

Shooting



^{*} Differs according to the current shooting mode. Refer to the sections on each mode for details.

Playback




1	Date of recording16	i
2	Time of recording16	,
3	Volume79	1
4	Battery level indicator20	1
5	Movie options [*] 77	1
6	Image mode [*] 51	1
7	a Current frame number/ total number of frames	1

8	Internal memory indicator26
9	Movie playback indicator79
10	Print-order icon64
11	Small picture71
12	D-Lighting icon70
13	Protect icon112
14	File number and type121

^{*} The icon displayed varies with the setting that was set at the time of shooting.


Basic Operations

(shooting mode) button



- Press in playback mode to enter shooting mode.

▶ (playback) button



- During shooting mode, the camera enters the playback mode when **\bigsize** is pressed.
- If the camera is turned off, hold down ▶ to turn the camera on in playback mode.

(movie-record) button




- Press the (movie-record) button in playback mode to enter shooting mode.

The Multi Selector

This section describes standard uses of the multi-selector to select modes, select menu options and to apply selection. Operate the multi selector by pressing it up. down, left, right, or by pressing **®**.

For Shooting






Display (macro mode) menu (49)/select the item below.



For Playback






For the Menu Screen



screen.



Apply selection (Go to the next screen). Select the item to the right/ go to the next screen (apply selection).



Notes on the Multi Selector

MENU button

Press **MENU** to display the menu for the selected mode.

- Use the multi selector to apply settings (\(\simeg 11\)).
- Select a tab on the left side of the monitor to display the corresponding menu.
- To exit the menu display, press **MENU** again.



Menus available for the current mode are displayed. Display the movie menu (during shooting). Display the setup menu.



Displayed when there are more previous menu items.

Displayed when there are one or more menu items to follow.

Displayed when the menu contains two or more pages.



Select an item and press (R) or the multi selector ▶ to proceed to the next set of options.



Press (R) or the multi selector to apply selection.

Switching Between Tabs



Press the multi selector ◀ to highlight the tab.

Press the multi selector ▲▼ to select a tab and press (6) or .


The selected menu will be displayed.

To display the tabs, press the multi selector ◀ while the menu is displayed in the following modes.

• Easy auto mode, scene mode and smart portrait mode

Help Displays

Rotate the zoom control to $\mathbf{T}(\mathbf{Q})$ when \mathbf{P}/\mathbf{Q} is displayed at the lower right of the menu screen to view a description of the currently selected menu option. To return to the original menu, rotate the zoom control to $\mathbf{T}(\mathbf{Q})$ again.





About the Shutter-release Button

The camera features a two-stage shutter-release button. To set focus and exposure, press the shutter-release button halfway, stopping when you feel resistance. Focus and exposure lock while the shutter-release button is held in this position. To release the shutter and take a picture, press the shutter-release button the rest of the way down. Do not use force when pressing the shutter-release button, as this may result in camera shake and blurred images.







Press the shutterrelease button halfway to set focus and exposure.



V

Press the shutterrelease button the rest of the way down to take picture.


Inserting the Batteries

- Open the battery-chamber/memory card slot cover.
 - Before opening the battery-chamber/memory card slot cover, hold the camera upside down to prevent the batteries from falling out.



2 Insert the Batteries

 Confirm that the positive (+) and negative (-) terminals are oriented correctly as described on the label at the entrance of the battery chamber, and insert the batteries.



3 Close the battery-chamber/memory card slot cover.




Applicable Batteries

- Four LR6/L40 (AA-size) alkaline batteries (batteries supplied)
- Four FR6/L91 (AA-size) lithium batteries
- Four EN-MH2 rechargeable Ni-MH (nickel metal hydride) batteries

Turning On and Off the Camera

After removing the lens cap, press the power switch to turn on the camera. The power-on lamp (green) lights for a moment, then the monitor turns on. Press the power switch again to turn the camera off. When the camera turns off, both the power-on lamp and monitor turn off. If the camera is turned off, hold down ightharpoonup to turn the camera on in playback mode (ightharpoonup 26).




Removing the Batteries

Before opening the battery-chamber/memory card slot cover, turn the camera off and confirm that the power-on lamp and the monitor are off.

Additional Precautions Regarding Batteries

- Read and follow the warnings and cautions (iii, 117).
- Be sure to read and follow the warnings for the battery on page iii and the section, "The Battery" (117), before using the battery.
- Do not combine old and new batteries or batteries of different makes or types.
- · Batteries with the following defects cannot be used:







negative terminal

Notes on the EN-MH2 rechargeable Ni-MH batteries

When using EN-MH2 batteries with the COOLPIX L105, charge the batteries four at a time using Battery Charger MH-73 (112, 120).

Battery Type

To improve battery performance, set the Battery type setting (112) in the setup menu (92) to match the type of batteries inserted into the camera.

The default setting is the type of battery supplied with purchase. When any other type of battery is used, turn the camera on and change the setting.

Alkaline Batteries

Performance of alkaline batteries may vary greatly depending on the manufacturer. Choose a reliable brand.

Alternative Power Sources

To power the camera continuously for extended periods, use an AC Adapter EH-67 (available separately) (🕮 120). Do not, under any circumstances, use another make or model of AC adapter. Failure to observe this precaution could result in overheating or in damage to the camera.

Auto Off (Standby Mode)

If no operations are performed for a specified amount of time, the monitor turns off, the power-on lamp flashes, and the camera enters standby mode. After an additional three minutes, the auto power off feature turns the camera off.

- During shooting or playback, the camera enters standby mode if no operations are performed for 30 seconds (default setting).
- During standby mode, the monitor is off and the power-on lamp flashes; you can turn the monitor on by pressing any of the following buttons: power switch, shutter-release button, 🗖 button, 📘 button, or the (movie-record) button
- The amount of time that passes before the camera enters standby mode is determined by the Auto off setting (\square 106) in the setup menu (\square 92).

Lens Frror

If Lens Error is displayed, make sure that the lens cap has been removed, then turn the camera on again.


Setting Display Language, Date and Time

A language-selection and date setting screen for the internal clock is displayed the first time the camera is turned on.

1 Press the power switch to turn on the camera.

The power-on lamp (green) lights for a moment and the monitor turns on.

Remove the lens cap.



2 Use the multi selector to choose the desired language and press **®**.

For information on using the multi selector, see "The Multi Selector" (\square 11).





3 Choose **Yes** and press **®**.

If **No** is selected, the date and time are not set.



4 Press ◀ or ▶ to select your home time zone (city name) (☐ 99) and press ๋.



Daylight Saving Time

To use the camera in an area where daylight saving time is in effect, press \triangle on the home time zone in Step 4 to set the daylight saving time to on.

When the daylight saving time setting is selected, the \P mark appears at the top of the monitor. To release the daylight saving time setting, press \blacktriangledown .



5 Change the date and time.

- Press ▲ or ▼ to edit the highlighted item.
- Press ➤ to move the cursor in the following order.
 D -> M -> Y -> Hour -> Minute -> D M Y



6 Choose the order in which the day, month and year are displayed and press **®** or **▶**.

• The settings are applied.



7 Make sure that the lens cap has been removed, then press .

• The shooting-mode selection menu is displayed.



8 When **Easy auto mode** is displayed, press **®**.

- The camera enters shooting mode and you can take pictures in Easy auto mode (\$\square\$ 20).
- Press the multi selector ▲ or ▼ before ♠, to switch to another shooting mode (□ 34).



Changing the Date and Time, Date Imprint

- To change the date and time, select **Date** from **Date** (\square 97) in the setup menu (\square 92) and follow the instructions starting from the above step 5.
- To change the time zone and the daylight saving settings, select **Time zone** from **Date** in the setup menu (QQ 97, 98).
- To imprint the shooting date into images when taking pictures, make sure the date and time are set, then set **Date imprint** (102) in the setup menu.

Inserting Memory Cards

Images are saved in the camera's internal memory (approximately 102 MB) or on removable Secure Digital (SD) memory cards (available separately) (120).

If a memory card is inserted into the camera, images are automatically saved on the memory card and images saved to the memory card can be played back, deleted or transferred. Remove the memory card to save images in the internal memory, or play back, delete or transfer images from the internal memory.

1 Confirm the power-on lamp and the monitor are off and open the battery-chamber/ memory card slot cover.

Be sure to turn off the camera before opening the battery-chamber/memory card slot cover.

Before opening the battery-chamber/memory card slot cover, hold the camera upside down to prevent the batteries from falling out.



2 Insert the memory card.


Slide the memory card in correctly until it clicks into place.

Close the battery-chamber/memory card slot cover.



Inserting Memory Cards

Inserting the memory card upside down or backwards could damage the camera or the memory card. Make sure that the memory card is correctly oriented.




Removing Memory Cards

Before opening the battery-chamber/memory card slot cover, *turn the camera off* and confirm that the power-on lamp and the monitor are off. Open the battery-chamber/memory card slot cover and press the card in (①) to partially eject the card. Remove the card (②), being careful not to bend it.

Formatting Memory Cards

If the message at right is displayed, the memory card must be formatted before use (107). **Note that formatting permanently deletes all images and other data on the memory card.** Be sure to make copies of any images you wish to keep before formatting the memory card.





• The first time you insert the memory cards used in other devices into the camera, be sure to format them using this camera (\(\superaction\) 107).


The Write Protect Switch

SD memory cards are equipped with a write protect switch. Images cannot be saved or deleted and the memory card cannot be formatted when this switch is in the "lock" position. Unlock by sliding the switch to the "write" position.

Memory Cards

- · Use only Secure Digital memory cards.
- Do not perform the following during formatting, while data
 is being written to or deleted from the memory card, or during data transfer to a computer. Failure
 to observe this precaution could result in the loss of data or in damage to the camera or memory
 card:
 - Insert or remove the card
 - Remove the batteries
 - Turn off the camera
 - Disconnect the AC adapter
- Do not format the memory card using a computer.
- Do not disassemble or modify.
- Do not drop, bend, or expose to water or strong physical shocks.
- Do not touch the metal terminals with your fingers or metal objects.
- Do not affix labels or stickers to the memory card.
- Do not leave in direct sunlight, closed vehicles or areas exposed to high temperatures.
- Do not expose to humidity, dust, or to corrosive gases.






Step 1 Turn the Camera On and Select 🕍 (Easy Auto) Mode

In (easy auto) mode, the camera automatically determines an appropriate shooting mode when you frame a picture, allowing you to easily take pictures using a shooting mode that suits the scene (\square 28).

- 1 Remove the lens cap and press the power switch to turn on the camera.
 - The power-on lamp (green) lights for a moment and the monitor turns on. The lens extends at this time.
 - Raise the built-in flash (6).



Press to display the shootingmode selection menu.




- 3 Press the multi selector ▲▼ to choose and press ®.
 - The camera enters 🗳 (easy auto) mode.



4 Check the battery level and number of exposures remaining.

Battery level indicator

Monitor	Description	
NO INDICATOR	The battery level is high.	
©	Batteries low. Prepare to replace batteries.	
1 Battery exhausted.	Cannot take pictures. Replace with new batteries.	



Number of exposures remaining

Number of Exposures Remaining

The number of images that can be saved depends on the capacity of the internal memory or memory card and image mode setting $(\square 52)$.

Indicators Displayed in 🚨 (Easy auto) Mode

Motion detection icon
Reduce the blurring caused by subject
movement or camera shake

Internal memory indicator Images will be saved to internal memory (approximately 102 MB). When a memory card is inserted, \(\bigcit \) is not displayed and images will be saved to memory card.

Vibration reduction icon
Reduce the effects of
camera shake.

Movie options
Displays the movie setting
used when recording
movies (☐ 77).
Press the ● (movierecord) button to record
movies (☐ 73).

Image mode

1

Display image size and quality (compression) set in the image mode menu. The default setting is **2 4000×3000**.

- When the camera is pointed at a person's face, the camera automatically detects the face and focuses on it (
 _ 24, 28).
- The self-timer (32) and exposure compensation (33) are available.
- The macro mode button (\(\sime\) 11, 49) on the multi selector is not available. Changes to macro mode when the camera selects close-up scene mode.
- Image mode (51) can be changed by pressing MENU.

Note on the Flash

When the built-in flash is lowered, the flash setting is fixed at off and s is displayed at the top of the monitor. In situations where flash is needed, such as in dark locations or when the subject is backlit, be sure to raise the built-in flash by hand $(\Box 6, 29)$.


Notes on Vibration Reduction and Motion Detection

- See **Vibration reduction** (103) or **Motion detection** (104) in the setup menu (92) for more information.
- Set Vibration reduction to Off when using a tripod.

Step 2 Frame a Picture

1 Ready the camera.

 Hold the camera steadily in both hands, keeping your fingers and other objects away from the lens, flash, and microphone.



2 Frame the picture.

- When the camera determines a scene mode, the shooting mode icon changes (\(\simega\) 28).
- When the camera detects a human face, that face is framed by a yellow double border. Up to 12 faces can be detected. When the camera detects more than one face, the face closest to the camera is framed by a double border and the others by single borders.

Shooting mode icon



 When shooting non-human subjects or when no faces are detected, the camera will focus on the center of the monitor. Position the main subject near the center of the focus area.

Easy auto mode

- The desired scene mode may not be selected in certain conditions. In this case, select another shooting mode.
- ullet When digital zoom is in effect, the shooting mode is lacktriangle.


Using the Zoom

Use the zoom control to activate optical zoom.

Rotate the zoom control toward **T** to zoom in, increasing the size of the subject.

Rotate the zoom control toward ${\bf W}$ to zoom out, increasing the area visible in the frame.

A zoom indicator is displayed at the top of the monitor when the zoom control is rotated.



Digital Zoom

When the camera is zoomed in to the maximum optical zoom magnification, rotating and holding the zoom control at \mathbf{T} triggers digital zoom. Digital zoom can magnify the subject up to about 4× beyond the magnification of the optical zoom.

When digital zoom is used, the focus area is not displayed and the camera focuses at the center of the frame.



Digital Zoom and Interpolation

Unlike optical zoom, digital zoom uses a digital imaging process known as interpolation to magnify images, resulting in slight deterioration of image quality.

Interpolation is applied when shooting still images at zoom positions beyond ...

When zoom is increased beyond the \triangle position, interpolation is initiated and the zoom indicator turns yellow to indicate that interpolation is being applied.

The position of Δ moves to the right as image size decreases, allowing you to confirm the zoom positions at which still images can be captured without interpolation using the current image mode setting.



Step 3 Focus and Shoot

1 Press the shutter-release button halfway.


• Press halfway (13) to focus. When the subject is in focus, the focus area glows green.








When a face is detected:



When shooting nonhuman subjects or when no faces are detected:



· When digital zoom is used, the focus area is not displayed and the camera focuses at the center of the frame. When the subject is in focus, the focus indicator glows green.



- The shutter speed and aperture are displayed when the shutter-release button is pressed halfway.
- Focus and exposure remain locked while the shutter release button is pressed halfway.
- When the camera is unable to focus, the focus area, or focus indicator, blinks red. Change the composition and press the shutter-release button halfway again.

2 Press the shutter-release button the rest of the way down.

• The image is saved to the memory card or internal memory.



During Saving

While images are being saved, the number of exposures remaining display will blink. Do not open the battery-chamber/memory card slot cover.

Removing the memory card or the battery during saving may result in loss of data or in damage to the saved data, camera or card.

Autofocus

Autofocus may not perform as expected in the following situations. In some rare cases, the subject may not be in focus despite the fact that the focus area or the focus indicator glows green:

- · Subject is very dark
- Objects of sharply differing brightness are included in the scene (e.g. the sun is behind the subject and the subject is in deep shadow)
- No contrast between the subject and surroundings (e.g. when the subject is wearing a white shirt and is standing in front of a white wall)
- Several objects are at different distances from the camera (e.g. the subject is inside a cage)
- · Subject is moving rapidly

In these situations, try pressing the shutter-release button halfway again to refocus, several times if necessary. If the subject is still not in focus, select auto mode and use focus lock (48) to take the picture by first focusing on an object that is the same distance from the camera as the desired subject.

Notes on Face Detection

See "Notes on Face Detection" (QQ 28) for more information.

The Did someone blink? Screen

When ☑ **Blink warning** is set to **On**, the **Did someone blink?** screen (☐ 109) is displayed after taking a picture if the camera detects a face with closed eyes.

Flash

If the subject is poorly lit, the flash (\square 29) may fire by pressing the shutter-release button all the way down.

Step 4 Viewing and Deleting Images

Viewing Images (Playback Mode)

Press ►.

- The last image taken is displayed in full-frame playback mode.
- Use the multi selector ▲, ▼, ◀ or ▶ to view additional images.Hold down the multi selector ▲, ▼, ◀ or ▶ to quickly scan through images.
- Pictures may be displayed briefly at low resolution while being read from the memory card or internal memory.
- Press
 or the
 (movie-record) button to switch to shooting mode. You can also press the shutter-release button.
- When \(\bigcap \) is displayed, images saved in the internal memory are displayed. When a memory card is inserted, \(\bigcap \) is not displayed and images saved on the memory card are displayed.




The Multi Selector



Internal memory indicator

Deleting Images

1 Press to delete the image currently displayed in the monitor.



- **2** Use the multi selector to select **Yes** and press **®**.
 - Deleted pictures cannot be recovered.
 - To exit without deleting the image, choose No and press (N).



Playback Mode

See "More on Playback" (59) and "Editing Image" (69) for more information.

Power ON by Pressing 🕨

When the camera is off, hold down **\to** to turn on the camera in playback mode. The lens will not extend.

Viewing Image

- While the monitor is off during standby mode, it will turn on again when the power switch, shutter-release button, or ▶ button is pressed (□ 106).

Ø Deleting the Last Image Taken While in Shooting Mode

In shooting mode, press to delete the last images taken.



Selecting Multiple Pictures for Deletion

When **Delete** (\square 67) is selected from the playback menu (\square 63), multiple images can be deleted.

Easy Auto Mode

Automatic Scene Selection

The camera automatically selects one of the following scenes when you point the camera at a subject.

- Auto mode (general use)
- **Z** Portrait (**Q** 36)
- **L**andscape (**□** 36)
- PY Night portrait (37)
- Might landscape (39)
- Close-up (◯ 39)
- Backlight (QQ 41)

Notes on Face Detection

- The camera's ability to detect faces depends on a variety of factors, including
 whether or not the subject is facing the camera. The camera may be unable to
 detect faces in the following situations:
 - When faces are partially hidden by sunglasses or other obstructions
 - When faces take up too much or too little of the frame
- When there are multiple people in the frame, the face on which the camera focuses depends on a variety of shooting conditions, such as whether or not the subject is facing the camera.

Using the Flash

In dark locations or when the subject is backlit, you can shoot pictures with flash by raising the built-in flash.

- The flash has a range of about 0.5 to 5.5 m (1 ft 8 in. to 18 ft) when the camera is zoomed out all the way, and about 1.5 to 3.5 m (5 ft to 11 ft) when the camera is zoomed in all the way.
- If the built-in flash is raised when using easy auto mode (\$\sum_2\$ 20), the camera
 automatically sets a flash mode according to the determined scene mode.
 When the built-in flash is lowered, the flash setting changes to off and \$\mathbf{9}\$ is
 displayed at the top of the monitor.

Selecting a Flash Mode

When using Auto mode (\square 48), certain scene modes (\square 35), or smart portrait mode (\square 44), the following flash modes are available.

\$AUTO Auto

Flash fires automatically when lighting is poor.

‡⊚ Auto with red-eye reduction

Reduces "red-eye" in portraits (\square 31).

Off

Flash will not fire even when lighting is poor.

Fill flash

Flash fires when a picture is taken. Use to "fill-in" (illuminate) shadows and back-lit subjects.

\$ Slow sync

Auto flash mode is combined with slow shutter speed.

Flash illuminates main subject; Slow shutter speeds are used to capture background at night or under dim light.

1 Raise the built-in flash (\square 6).

• When the built-in flash is lowered, it is fixed to **(soft)**.



2 Press **\$** (flash mode) on the multi selector.

• The flash menu is displayed.



3 Press the multi selector **△** or **▼** to select a mode, and press **®**.

- The icon for the selected flash mode is displayed at the top of the monitor.
- When \$\frac{\text{AITO}}{\text{into}}\$ (auto) is applied, \$\frac{\text{AITO}}{\text{disappears}}\$ disappears after a few seconds regardless of the monitor settings (\(\sigma\) 100).
- If a setting is not applied by pressing
 within a few seconds, the selection is cancelled.





✓ Lowering the Built-in Flash

Push the built-in flash down gently to lower the built-in flash when not in use (\square 6).

Shooting When Lighting Is Poor and the Flash Is Disabled (③)

- Use of a tripod is recommended to stabilize the camera during shooting and avoid the effects of camera shake. Set Vibration reduction (103) to Off when using a tripod.
- The ISO is displayed when the camera automatically increases sensitivity to minimize blur caused by slow shutter speed. Images taken when ISO is displayed may be slightly mottled.

Note on Using the Flash


When using the flash, reflections from dust particles in the air may appear as bright spots in images. To reduce these reflections, set the flash to **③** (off).

The Flash Lamp

The flash lamp indicates flash status when the shutter-release button is pressed halfway.

- On: Flash will fire when picture is taken.
- Blinks: Flash charging. Wait a few seconds and try again.
- Off: Flash will not fire when picture is taken.

If the remaining battery level is low, the monitor will turn off until the flash has finished charging.



The Flash Mode Setting

The default setting of flash mode depends on the shooting mode.

- 🚨 (easy auto) mode: 🚻 Auto
- Scene mode: The default setting depends on the scene menu (35).
- (smart portrait) mode: \$AUTO Auto
- 💐 (sport continuous) mode: 🏵 Off (locked)
- 🗖 (auto) mode: 🕬 Auto

Flash cannot be used simultaneously with certain features. \rightarrow Camera Settings that Cannot Be Set at the Same Time (\square 58)

When the shooting mode is **(auto)** mode (((1) 48), the changed flash setting is saved even if the camera is turned off.

Red-eye Reduction

This camera is equipped with an **advanced red-eye reduction** system.

Pre-flashes are fired several times at low intensity before the main flash to reduce the effects of redeve.

If the camera detects "red-eye" when a picture is taken, Nikon's own In-Camera Red-Eye Fix processes the image before it is saved.

Note the following when using red-eye reduction:

- Because pre-flashes are fired before the picture is taken, there is a slight lag between when the shutter-release button is pressed and when the picture is shot.
- The time required to save images increases slightly.
- Red-eye reduction may not always produce the desired results.
- In some rare cases, other portions of images may be affected. Use flash modes other than auto with red-eye reduction in the above cases.

Taking Pictures with the Self-timer

When using the self-timer, pictures are taken 10 seconds after the shutter-release button is pressed. When using the self-timer, use of a tripod is recommended. Set **Vibration reduction** (103) in the setup menu (92) to **Off** when using a tripod.

1 Press 🖒 (self-timer) on the multi selector.

The self-timer menu is displayed.



Press the multi selector ▲ or ▼ to select ON, and press ⑥.

The self-timer icon (**S**) 10) is displayed.

If a setting is not applied by pressing within a few seconds, the selection is cancelled.



3 Frame the picture and press the shutter-release button halfway.

Focus and exposure are set.





4 Press the shutter-release button the rest of the way down.

The self-timer starts and the number of seconds remaining until the shutter is released is displayed in the monitor. The self-timer lamp blinks. The lamp stops blinking one second before the picture is taken and remains lit until the shutter is released.

When the shutter is released, the self-timer is set to **OFF**

To stop the timer before a picture is taken, press the shutter-release button again.







Adjusting the Brightness: Exposure Compensation

Exposure compensation is used to alter exposure from the value suggested by the camera to make images brighter or darker.

1 Press (exposure compensation) on the multi selector.

• The exposure compensation guide is displayed.



2 Press the multi selector ▲ or ▼ to adjust the exposure, and press **®**.

- To make the subject brighter, adjust the exposure compensation to the "+" side.
- To make the subject darker, adjust the exposure compensation to the "-" side.
- Exposure compensation can be set to values between -2.0 and +2.0 EV.
- If a setting is not applied by pressing within a few seconds, the selection is cancelled

3 Press the shutter-release button to shoot.

 To turn off exposure compensation, repeat from step 1 and set the value to 0.0, then press ⁽⁸⁾



Exposure compensation

Exposure Compensation Value

When shooting mode is **\textit{\textit{\textit{\textit{\textit{0}}}}}** (auto) mode (\(\implies\) 48), the exposure compensation setting is saved even if the camera is turned off.

Using Exposure Compensation

- The camera tends to reduce exposure when the frame is dominated by brightly lit objects and to
 increase exposure when the frame is mostly dark. Positive compensation may therefore be
 required to capture the brilliancy of very bright objects that fill the frame (for example, sunlit
 expanses of water, sand, or snow) or when the background is much brighter than the main
 subject.
- Negative compensation may be called for when large areas of the frame contain very dark objects (for example, a swath of dark green leaves) or when the background is much darker than the main subject.

Selecting Shooting Mode

Select the shooting mode from a easy auto mode, seene mode, smart portrait, sport continuous mode, or auto mode.

1 Press in shooting mode.

• The shooting-mode selection menu is displayed.



2 Use the multi selector ▲ or ▼ to select a shooting mode and press ๋.

- The camera enters the selected shooting mode.



To return to the current shooting mode without switching shooting modes, press or the shutter-release button.

1 **E**asy auto mode

20

By simply framing a picture, the camera automatically selects the optimum scene mode for simpler shooting.

2 **%** Scene

35

Camera settings are automatically optimized for the selected scene type.

3 Smart portrait

The camera detects a smiling face to shoot the face automatically.

4 Sport continuous

□ 46

Allows rapid, continuous shooting while you press and hold the shutter-release button fully.

5 Auto mode

48

You can change the flash mode, use macro mode (for close-ups), etc., and take pictures. You can also select to shoot bursts of pictures continuously.

Shooting Suited for the Scene (Scene Mode)

Camera settings are automatically optimized for the selected scene type. The following scene modes are available.

2 Portrait	Beach/snow	🗱 Close-up	🖺 Backlight
■ Landscape	ä Sunset	TI Food	🛱 Panorama assist
Night portrait	≟ Dusk/dawn	<u>■</u> Museum	
X Party/indoor	■ Night landscape	□ Сору	

Selecting a Scene Mode

- Press in shooting mode to display the shooting-mode selection menu and use the multi selector and to select scene mode.
 - The icon of the last scene mode used is displayed. <u>2</u> (Portrait) is the default setting.





- 2 Press ▶, press the multi selector ▲, ▼, ◀, or ▶ to select a scene, and press ເເ
 - The shooting mode screen for the selected scene is displayed.
 - Features → (□ 36)



- **3** Frame the subject and shoot.
 - For scene modes that use the flash, be sure to raise the built-in flash before shooting.





Image Mode

When using scene mode, you can set **Image mode** (\square 51) by pressing **MENU**. If the image mode setting is changed, the new image mode setting is also applied to other shooting modes (except sport continuous).

Features

The following icons are used for descriptions in this section: **♦**: flash mode when the built-in flash is raised (\(\sime\) 29); \(\sime\): self-timer (\(\sime\) 32); \(\sime\): macro mode (\(\sime\) 49); \(\sime\): exposure compensation (\(\sime\) 33).

Portrait

Use this mode for taking portraits in which the main subject stands out clearly.

- If the camera detects a face, it focuses on the face. See "Face Detection" (24) for more information.
- If more than one face is detected, the camera focuses on the face closest to the camera.
- If no faces are detected, the camera will focus on the center of the screen.
- Digital zoom is not available.



* Other settings can be selected.

■ Landscape

Use this mode for vivid landscapes and cityscapes.

 Camera focuses at infinity. The focus area or focus indicator (\(\infty\) 8) always glows green when the shutter-release button is pressed halfway. Note, however, that objects in the foreground may not always be in focus.





^{*} Other settings can be selected.

■ Night portrait

NR ⊼

Use this mode to achieve a natural balance between the main subject and background lighting in portraits taken at night.

- Shoot pictures with the built-in flash raised.
- If the camera detects a face, it focuses on the face. See "Face Detection" (24) for more information.
- If more than one face is detected, the camera focuses on the face closest to the camera.
- If no faces are detected, the camera will focus on the center of the screen.
- Digital zoom is not available.



^{*1} Flash mode is set to fill flash with slow sync and red-eye reduction, and cannot be changed.
*2 Other settings can be selected.

XX Party/indoor

Captures the effects of candlelight and other indoor background lighting.

- The camera focuses on the subject in the center of the frame
- As pictures are easily affected by camera shake, hold the camera steadily. In a dark place, the use of a tripod is recommended. Set Vibration reduction (103) to Off when using a tripod.





^{*1} The flash may change to slow sync with red-eye reduction. Other settings can be selected.

- ★: For those scene modes with ★, use of a tripod is recommended. Set Vibration reduction (□ 103) to Off when using a tripod.
- Indicates images shot in this scene mode are processed automatically to reduce noise, and therefore may take more time to save.

^{*2} Other settings can be selected.

Shooting Suited for the Scene (Scene Mode)

Beach/snow

Captures the brightness of such subjects as snowfields, beaches, or sunlit expanses of water.

• The camera focuses on the subject in the center of the frame.

Off*



4AUTO* * Other settings can be selected.



Preserves the deep hues seen in sunsets and sunrises.

(%)

· The camera focuses on the subject in the center of the frame.



Off* . (3)* (1) Off \mathbf{z} 0.0*

¥

Other settings can be selected.

Dusk/dawn

NR 🗼

Off

[]

Preserves the colors seen in the weak natural light before sunrise or after sunset.

 Camera focuses at infinity. The focus area or focus indicator (QQ 8) always glows green when the shutter-release button is pressed halfway. Note, however, that objects in the foreground may not always be in focus.





^{*} Other settings can be selected.

- (3): For those scene modes with (4), use of a tripod is recommended. Set **Vibration reduction** (103) to **Off** when using a tripod.
- Indicates images shot in this scene mode are processed automatically to reduce noise, and therefore may take more time to save.

NR [⊼]

Slow shutter speeds are used to produce stunning night landscapes.

 Camera focuses at infinity. The focus area or focus indicator (\$\sum 8\$) always glows green when the shutter-release button is pressed halfway. Note, however, that objects in the foreground may not always be in focus.





^{*} Other settings can be selected.

🗱 Close-up

Photograph flowers, insects and other small objects at close range.

- Macro mode (49) will turn ON and the zoom will automatically move to the closest possible shooting position.
- The closest distance at which the camera can focus varies depending on the zoom position. The camera can focus at distances as close as 1 cm (0.4 in.) from the lens when ♣ and the zoom indicator glow green (zoom indicator is positioned near △).
- The camera focuses continuously until the shutter-release button is pressed halfway to lock the focus.
- As pictures are easily affected by camera shake, check the Vibration reduction (\(\sum_{103}\)) setting and hold the camera steadily.



^{*} Other settings can be selected. Note that the flash may be unable to light the entire subject at distances of less than 50 cm (1 ft 8 in.).

- ★: For those scene modes with ★, use of a tripod is recommended. Set Vibration reduction
 (□ 103) to Off when using a tripod.
- Indicates images shot in this scene mode are processed automatically to reduce noise, and therefore may take more time to save.

TI Food

Use this mode when taking pictures of food.

 Macro mode (49) will turn ON and the zoom will automatically move to the closest possible shooting position.

The closest distance at which the camera can focus varies depending on the zoom position. The camera can focus at distances as close as 1 cm (0.4 in.) from the lens when \Im and the zoom indicator glow green (zoom indicator is positioned near \triangle).

- You can adjust the hue using the slider displayed on the left side of the monitor. Press the multi selector ▲ to increase the amount of red, or ▼ to increase the amount of blue. The hue setting is saved even when the camera is turned off.
- The camera focuses on the subject in the center of the frame. Use focus lock to frame the picture on an object not in the center of the frame (48).
- The camera focuses continuously until the shutter-release button is pressed halfway to lock the focus.



^{*} Other settings can be selected.

m Museum

Use indoors where flash photography is prohibited (for example, in museums and art galleries) or in other settings in which you do not want to use the flash.

- The camera focuses on the subject in the center of the frame.
- BSS (best shot selector) can be used to shoot (55).
- As pictures are easily affected by camera shake, check the Vibration reduction (\(\subseteq\) 103) setting and hold the camera steadily.



^{*} Other settings can be selected.



[]

[2 14]

TI 673



□ Сору

Provides clear pictures of text or drawings on a white board or in print.

- The camera focuses on the subject in the center of the
- Use macro mode (49) to focus at short ranges.
- Colored text and drawings may not show up well.



^{*} Other settings can be selected.

Backlight

Use when light is coming from behind your subject, throwing features or details into shadow. The flash fires automatically to "fill in" (illuminate) shadows.

- Shoot pictures with the built-in flash raised.
- The camera focuses on the subject in the center of the frame.



نوسون الله الأولى ا

क्षेत्र का जासकार क्यां में मिर्ग संस्थानकार

kite in securit in the first securities of the securities of the security s



Use when taking a series of pictures that will later be joined to form a single panorama image using the supplied Panorama Maker 5 software. See Taking Pictures for a Panorama (\$\sum_4\$2) for details.

4	③ *	(3)	Off*	 Off*	7	0.0*

^{*} Other settings can be selected.

 <sup>★
 ★</sup> Off*
 W
 Off
 ☑
 0.0*

^{*} Other settings can be selected.

Taking Pictures for a Panorama

The camera focuses on the subject in the center of the frame. Use a tripod for best results. Set **Vibration reduction** (\square 103) to **Off** when using a tripod.

Press in shooting mode to display the shooting-mode selection menu and use the multi selector to select Panorama assist (35).





The panorama direction icon (()) is displayed to show the direction in which pictures are joined.

2 Use the multi selector to choose the direction and press **®**.

Select how pictures are joined together in the completed panorama; right (\D) , left (\D) , up (\D) or down (\D) .

The yellow panorama direction icon (DD) is displayed to the direction pressed and the direction is fixed when \mathfrak{B} is pressed. The white fixed direction D is displayed.



Apply flash mode (\square 29), self-timer (\square 32), macro mode (\square 49) and exposure compensation (\square 33) settings with this step, if necessary. Press \bigcirc to reselect the direction.

3 Shoot the first picture.

The first picture is superimposed in the first third of the monitor





4 Shoot the second picture.

Frame the next picture so that one third of the frame overlaps the first picture, and press the shutter-release button.

Repeat until you have taken the necessary number of pictures to complete the panorama.





5 Press ® when shooting is completed.

• The camera returns to step 2.



Panorama Assist

- Set flash mode, self-timer, macro mode and exposure compensation before taking the first picture.
 They cannot be changed after the first picture is taken. Images cannot be deleted, nor can zoom or Image mode setting (\$\sigma\$ 51) be adjusted after the first picture is taken.

Note on AE/AF-L

All pictures taken in a panorama series have the same white balance, exposure, and focus settings.

When the first picture is shot, AE/AF-L is displayed to indicate that exposure, white balance, and focus are locked.



Panorama Maker 5

Install Panorama Maker 5 from the supplied ViewNX 2 CD-ROM.

Transfer images to a computer (82) and use Panorama Maker 5 (85) to join them in a single panorama.

More Information

See "Image File and Folder Names" (121) for more information.

Capturing Smiling Faces Automatically (Smart Portrait Mode)

The camera detects a smiling face to shoot the face automatically.


Press in shooting mode to display the shooting-mode selection menu and use the multi selector or ▼ to select and press .



The camera enters smart portrait mode.

2 Frame the picture.

- Raise the built-in flash when using the flash.
- Point the camera at the subject.
- If the camera detects a person's face, the face is framed by a double yellow border in the focus area, and when the face comes into focus, the double border turns green for a moment and the focus is locked.



• Up to three faces can be detected. When the camera detects more than one face, the face nearest the center of the screen is framed by a double border in the focus area and the other faces are framed by a single border.

3 The shutter is automatically released.

- If the camera detects the smiling face of the person framed by a double border, the shutter is automatically released.
- Pictures can also be taken by pressing the shutter-release button. If the camera does not detect any faces, the camera focuses on the subject in the center of the frame.

4 Exit smart portrait mode by pressing .

Change to another shooting mode.



Face Detection and Smiling Face Detection features

- In some shooting conditions, face detection does not work and faces cannot be detected.
- Notes on Face Detection → □ 28

Auto Off (Standby Mode) When Using Smart Portrait Mode

When using smart portrait mode, Auto off $(\square 106)$ will turn the camera off if no operations are performed in the following situations:

- The camera does not detect any faces.
- The camera detected the face but cannot detect a smiling face.

Functions Available in Smart Portrait Mode

- Digital zoom is not available.
- Flash mode (29) changes automatically to **\$400** (auto), but can be changed.
- The exposure compensation (33) is available.
- The self-timer and macro mode are not available.
- Image mode (51) can be changed by pressing **MENU**. If the image mode setting is changed, the new image mode setting is also applied to other shooting modes (except sport continuous).

More Information

See, "Autofocus" (25) for more information.

Shooting Continuously at High Speed (Sport Continuous)

Sport continuous mode allows rapid, continuous shooting while you press and hold the shutter-release button fully. With continuous shooting, instantaneous movements in moving subjects can be captured.

- With the default setting of **Continuous H**, the camera shoots up to 20 pictures at a rate of up to about 11.1 frames per second (fps).
- ISO sensitivity is set high.
- Image mode can be set to **3. 2048×1536** or smaller.
- The focus, exposure, and white balance settings are fixed at the values for the first picture in each series.
- Press in shooting mode to display the shooting-mode selection menu and use the multi selector in very to select and press w.



The camera enters sport continuous mode.

- **2** Press MENU, then confirm or set the items in the sport continuous menu.
 - sport continuous menu → □ 47
 - Press MENU after setting the items to return to shooting mode.



3 Frame the subject and shoot.

- The camera focuses on the subject in the center of the frame. Pressing the shutter-release button halfway sets the focus and exposure.
- Continuous shooting continues as long while the shutter-release button is held all the way down, and stops when the number of shot frames reaches the maximum available number (\$\sum\$ 47).



Functions Available with Sport Continuous

- The exposure compensation (33) is available.
- The flash is disabled.
- The self-timer and macro mode are not available.

Notes on Sport Continuous Shooting

- It may take some time to save the images after shooting. The time it takes to save the images
 depends on the number of shots taken, the image mode, the memory card's write speed, etc.
- Because the ISO sensitivity is set to 640 or higher, images may appear rough as a result. Proper exposure may not be obtained in clear weather (images may be overexposed).
- Smear (\(\sumeq\) 119) visible in the monitor when shooting with sport continuous will be visible in the saved image data. To reduce smear effects, avoid bright objects such as the sun, reflections of the sun, and electric lights when shooting.
- When shooting under lights that have a high flicker rate, such as fluorescent or mercury lights, exposure and white balance may differ from image to image.
- The shutter speed is set automatically within the range of 1/8000 s to 1/15 s.
- The speed of continuous shooting may be slower depending on shutter speed settings and the write speed of the memory card.
- When using sport continuous mode, the camera focuses continuously until the shutter-release button is pressed halfway to lock the focus. A sound will be heard while the camera focuses.

More Information

See, "Autofocus" (25) for more information.

Sport Continuous Menu

The following items can be set in the sport continuous menu. In sport continuous mode, press **MENU** (\square 12) to display the sport continuous menu, then use the multi-selector (\square 11) to modify and apply settings.

Sport continuous

Select the sport continuous mode type to determine the maximum continuous shooting speed and maximum number of frames to be shot.

- **Uniform Continuous H** (default setting): Approx. 11.1 frames per second (20 frames max.)
- **Continuous M**: Approx. 7.3 frames per second (20 frames max.)
- **U** Continuous L: Approx. 4.4 frames per second (20 frames max.)

Image mode

Image mode (51) can be set.

- In sport continuous mode, the following image mode settings are available:
 2048×1536 (default setting), 1024×768, 640×480, 1920×1080.
- The image mode setting in the sport continuous menu is saved separately from the image mode setting in other shooting modes and is not applied to the other modes.

Auto Mode

In (auto) mode, macro mode (49) and exposure compensation (33) can be applied and pictures can be taken using flash mode (\square 29) and self-timer (\square 32). Pressing **MENU** in **a** (auto) mode allows you to specify settings for all shooting menu items (\$\sum_{\text{50}}\$) depending upon the shooting situations.

- 1 Press to display the shootingmode selection menu.
 - The shooting-mode selection menu is displayed.



- Press the multi selector \blacktriangle or \blacktriangledown to choose \blacksquare and press (%).
 - The camera enters (auto) mode.
 - Raise the built-in flash when using the flash.
 - Set the flash mode (QQ 29), self-timer (QQ 32), exposure compensation (33), and macro mode (49) to match the shooting conditions.
 - Press MENU to display the shooting menu, and set the items in the shooting menu to match the shooting conditions (\square 50).



3 Frame the subject and shoot.

· The camera focuses on the subject in the center of the frame





Focus Lock

When the camera focuses on an object in the center of the frame, you can use focus lock to focus on an off-center subject.

- Be sure that the distance between the camera and the subject does not change while focus is locked.
- When the shutter-release button is pressed halfway, exposure is locked.



in the center of the shutter frame.



release button halfway.



Position the subject Press the Confirm that the focus area is green.



Continue holding down the shutterrelease button halfway and recompose the picture.



Press the shutterrelease button the rest of the way down.

Macro Mode

Macro mode is used for taking pictures of objects as close as 1 cm (0.4 in.). Note that the flash may be unable to light the entire subject at distances of less than 50 cm (1 ft 8 in.).

When using **(auto)** mode, follow the procedure below. Macro mode can also be used with some scene modes ((1) 39, 40, 41).

- 1 Press (macro mode) on the multi selector.
 - The macro menu is displayed.



2 Press the multi selector **△** or **▼** to select **ON**, and press **®**.

The macro mode icon (S) is displayed.

If a setting is not applied by pressing within a few seconds, the selection is cancelled.



3 Use the zoom control and frame the picture.

The camera can focus at distances as close as 1 cm (0.4 in.) from the lens when 3 and the zoom indicator glow green (zoom indicator is positioned near \triangle).



Autofocus

When shooting still images using macro mode, the camera focuses continuously until the shutterrelease button is pressed halfway to lock the focus. A sound will be heard while the camera focuses.

The Macro Mode Setting

- diagnostic (easy auto) mode: Changes to macro mode when the camera selects . The macro mode button on the multi selector cannot be used.
- Scene mode: The default setting depends on the scene menu (35). Macro mode is turned on when Close-up or Food are selected in scene mode.
- ☑ (smart portrait) mode, 🏖 (sport continuous) mode: Macro mode cannot be used.
- When shooting mode is **a** (auto) mode, the macro mode setting is saved even if the camera is turned off.

Shooting Menu (Auto Mode)

While shooting in \triangle (auto) mode (\square 48), the shooting menu contains the following options.

4 :	Image mode	 51
	Choose image size and quality (compression). Also available when using other shooting modes.	
MB	White balance	5 3
	Match white balance to the light source.	
	Continuous	1 55
	Change settings to Continuous or BSS (best shot selector).	
ISO	ISO sensitivity	 56
	Control the camera's sensitivity to light.	
Ø	Color options	 57
	Make colors more vivid or save images in monochrome.	

Displaying the Shooting Menu

Press lacktriangle in shooting mode to display the shooting-mode selection menu and set the shooting mode to lacktriangle (auto) mode (\Box 48).

Press **MENU** to display the shooting menu.



- Use the multi selector to choose and apply settings (\square 11).
- To exit the shooting menu, press MENU.

♦ Image Mode (Image Quality/Image Size)

Set to \bigcirc (auto) mode (\bigcirc 48) \rightarrow MENU (Shooting menu) \rightarrow \clubsuit Image mode

Choose image size and quality (compression). The size of the files, and with it the number of images that can be saved, depends on the size and quality (compression) of the images. Before shooting, choose an image mode according to how you plan to use the image.

Setting	Size (pixels)	Description
2 4000×3000★	4000×3000	Highest quality, suitable for enlargements or high-quality prints. The compression ratio is approximately 1:4.
4000×3000 (default setting)	4000×3000	Best choice in most situations. The compression
8 _M 3264×2448	3264×2448	ratio is approximately 1:8.
5 2592×1944	2592×1944	
3 _M 2048×1536	2048×1536	Smaller size allows more images to be saved. The compression ratio is approximately 1:8.
PC 1024×768	1024×768	Suited to display on a computer monitor. The compression ratio is approximately 1:8.
MA 640×480	640×480	Suited to distribution by e-mail or full-screen display on a television with a 4:3 aspect ratio.
₩ 3968×2232	3968×2232	Images with an aspect ratio of 16:9 can be taken. The compression ratio is approximately 1:8.

The icon for the current setting is displayed in the monitor in shooting and playback modes (\square 8, 9).

Note on Image Mode

- If the image mode setting is changed, the new image mode setting is also applied to other shooting modes (except sport continuous).
- This feature cannot be used simultaneously with certain features. → "Camera Settings that Cannot Be Set at the Same Time" (□ 58)

Image Mode for Sport Continuous Mode

- In sport continuous mode (□ 46), the following image mode settings are available: 2048×1536, □ 1024×768, □ 640×480, □ 1920×1080 (image size 1920 × 1080, compression ratio 1/8).
- The image mode setting in the sport continuous menu (\square 46) is saved separately from the image mode setting in other shooting modes and is not applied to the other modes.

Number of Exposures Remaining

The following table lists the approximate number of images that can be saved in internal memory and on a 4 GB memory card. Note that the number of images that can be saved will differ depending on the composition of the image (due to JPEG compression). In addition, this number may differ depending on the make of memory card, even if the capacity for the memory card is the same.

Image mode	Internal memory (Approx. 102 MB)	Memory card *1 (4 GB)	Print size (printed at 300 dpi; cm/in.)*2
№ 4000×3000 ★	17	650	34×25/13.4×9.8
2 4000×3000	35	1280	34×25/13.4×9.8
8 _M 3264×2448	52	1910	28×21/11×8.3
5 _M 2592×1944	81	2940	22×16/8.7×6.2
3 _M 2048×1536	126	4640	17×13/6.7×5.1
PC 1024×768	411	15000	9×7/3.5×2.8
₩ 640×480	731	24100	5×4/2×1.6
3968×2232	47	1720	34×19/13.4×7.5
🖺 1920×1080	182	6700	16×9/6.5×3.5

 $^{^{*1}}$ If the number of exposures remaining is 10,000 or more, the number of exposures remaining display shows 9999.

^{*2} Print sizes are calculated by dividing the number of pixels by printer resolution (dpi) and multiplying by 2.54 cm (1 in.). However, at the same image size, images printed at higher resolutions will print smaller than the size indicated, and those printed at lower resolutions will print larger than the size indicated.

WB White Balance (Adjusting hue)

Set to (auto) mode ((1) 48) → MENU (Shooting menu) → WB White balance

The color of light reflected from an object varies with the color of the light source. The human brain is able to adapt to changes in the color of the light source, with the result that white objects appear white whether seen in the shade, direct sunlight, or under incandescent lighting. Digital cameras can mimic this adjustment by processing images according to the color of the light source. This is known as "white balance".

Although the default setting, **Auto** can be used under most types of lighting, you can apply the white balance setting suited to a particular light source to achieve more accurate results.

AUTO Auto (default setting)

White balance automatically adjusted to suit lighting conditions. Best choice in most situations

PRE Preset manual

Neutral-colored object used as reference to set white balance under unusual lighting conditions. Please refer to "Preset Manual" for more information(\$\square\$) 54).

Daylight

White balance adjusted for direct sunlight.

Incandescent

Use under incandescent lighting.

Fluorescent

Use under most types of fluorescent lighting.

Cloudy

Use when taking pictures under overcast skies.

多 Flash

Use with flash mode.

The icon for the current setting is displayed in the monitor (\square 8). However, when **Auto** is selected, no icon is displayed.

White Balance

- This feature cannot be used simultaneously with certain features. → "Camera Settings that Cannot Be Set at the Same Time" (□ 58)
- At white-balance settings other than **Auto** or **Flash**, turn the flash off (**③**) (\square 29).

Preset Manual

Preset manual is used with mixed lighting or to compensate for light sources with a strong color cast (for example, to make pictures taken under a lamp with a red shade look as though they had been taken under white light).

- Place a white or gray reference object under the lighting that is used during shooting.
- 2 Display the shooting menu (34), use the multi selector to select **PRE Preset manual** in the **White balance** menu, and press **8**.

The camera zooms in.




3 Select Measure.

To apply the most recently measured value for preset manual, choose **Cancel** and press **®**. The most recently measured value is applied for white balance.



4 Frame the reference object.



Reference object frame

5 Press **®**.

The shutter is released (no image is captured) and the new white-balance value is set.

Note on Preset Manual

The camera cannot measure a white balance value for when the flash fires. When shooting with the flash, set **White balance** to **Auto** or **Flash**.

□ Continuous

Set to lacktriangle (auto) mode (\Box 48) \Rightarrow MENU (Shooting menu) \Rightarrow \Box Continuous

Change settings to Continuous or BSS (best shot selector).

Flash will be switched off for **Continuous**, **BSS** or **Multi-shot 16**, and focus, exposure and white balance are fixed at the values for the first picture in each series.

Single (default setting)

One shot is taken each time shutter-release button is pressed.

Continuous

While the shutter-release button is held all the way down, up to 4 pictures are taken at a rate of about 1.0 frames per second (fps) when image mode is set to **2.4000×3000**.

BSS BSS (Best Shot Selector)

The "best shot selector" is recommended when shooting with the flash off or the camera zoomed in, or in other situations in which inadvertent motion can result in blurred images.

When BSS is on, the camera takes up to 10 pictures while the shutter-release button is held all the way down. The sharpest image in the series is automatically selected and saved

Multi-shot 16

Each time the shutter-release button is pressed all the way down, the camera takes 16 shots at a rate of about 7.4 frames per second (fps), then arranges them in a single image. Images are captured with the image mode locked at 22560×1920.



The icon for the current setting is displayed in the monitor during shooting (\square 8). When set to **Single**, no icon is displayed.

Note on Continuous Shooting

Digital zoom cannot be used.

- The frame rate with continuous shooting may vary, depending upon the current image mode setting, the memory card used, and the shooting environment.
- This feature cannot be used simultaneously with certain features. → "Camera Settings that Cannot Be Set at the Same Time" (□ 58)

Note on BSS

BSS is best suited to shooting subjects that are not moving. When shooting moving subjects or when the composition of the picture changes while shooting, the desired results may not be achieved.

Note on Multi-shot 16

Smear (\square 119) visible in the monitor when shooting with Multi-shot 16 will be visible in the saved image data. To reduce smear effects, avoid bright objects such as the sun, reflections of the sun, and electric lights when shooting.

ISO Sensitivity

Set to (auto) mode (48) → MENU (Shooting menu) → ISO ISO sensitivity

Sensitivity is a measure of how quickly the camera reacts to light. The higher the sensitivity, the less light needed to make an exposure. Although a high ISO rating is suited for taking pictures of subjects in action or in poor lighting, high sensitivity is often associated with "noise" - randomly spaced, brightly colored pixels concentrated in dark parts of the image.

Auto (default setting)

Sensitivity is ISO 80 under normal conditions; when lighting is poor and the flash is off, the camera compensates by raising sensitivity to a maximum of ISO 800.

80, 100, 200, 400, 800, 1600, 3200, 6400

Sensitivity will be locked at the specified value.

• When ISO sensitivity is locked, **Motion detection** (104) does not function.

The icon for the current setting is displayed in the monitor (\square 8). When **Auto** is selected, the **Sol** icon is not displayed at ISO 80, but is displayed if the ISO sensitivity automatically increases to more than 80 (\square 30).

Notes on ISO Sensitivity

This feature cannot be used simultaneously with certain features. \rightarrow "Camera Settings that Cannot Be Set at the Same Time" (\square 58)

ISO 3200 and ISO 6400

When ISO sensitivity is set to 3200 or 6400, the available Image mode settings are limited to ₹ 2048×1536, ₹ 1024×768, and ₹ 640×480. The image mode of the shooting mode is shown in red and ₱ is displayed next to the ISO sensitivity in the lower left of the monitor.

E03200

Color Options

Set to **△** (auto) mode (**△** 48) **→ MENU** (Shooting menu) **→ ②** Color options

Make colors more vivid or save images in monochrome.

Standard color (default setting)

Use for images exhibiting natural color.

🕅 Vivid color

Use to achieve a vivid, "photoprint" effect.

டு Black-and-white

Save images in black-and-white.

Sepia Sepia

Save images in sepia tones.

C Cyanotype

Save images in cyan-blue monochrome.

The effects of the selected option can be previewed in the monitor (\square 8). At settings other than **Standard color**, the icon for the current setting is displayed in the monitor.

Camera Settings that Cannot Be Set at the Same Time

Certain settings in the shooting menu cannot be used with other functions.

Restricted Functions	Setting	Description
Flash mode	Continuous (🕮 55)	If set to Continuous , BSS , or Multi-shot 16 , the flash cannot be used.
Digital zoom	Continuous (CC 55)	Digital zoom cannot be used when shooting with Multi-shot 16 .
	Continuous (🕮 55)	When using Multi-shot 16, Image mode is fixed at 5. 2560×1920.
lmage mode	ISO sensitivity (CQ 56)	When the ISO sensitivity is set to 3200 or 6400, the available Image modes are restricted to ₹ 2048×1536, 1024×768, and 10 640×480. For all other image mode settings, if ISO sensitivity is set to 3200 or 6400, the image mode setting changes to ₹ 2048×1536.
White balance	Color options (CC) 57)	When using Black-and-white , Sepia , or Cyanotype , the White balance setting is fixed at Auto .
Continuous	Self-timer (CCC 32)	When using the self-timer, the setting is fixed at Single .
ISO sensitivity	Continuous (🔲 55)	When using Multi-shot 16, ISO sensitivity is set automatically according to the brightness.
Date imprint	Continuous (🕮 55)	The shooting date and time cannot be imprinted in images captured when using Continuous or BSS .
Motion detection	Continuous (🕮 55)	Motion detection does not function when shooting with Multi-shot 16 .
	ISO sensitivity (56)	Motion detection does not function when ISO sensitivity is set to any setting other than Auto.

Full-frame Operation

Press \blacktriangleright button during shooting to switch to playback mode and view images (\square 26).

The following operations can be performed while viewing images in full-frame.



То	Use	Description	
Choose images	() () () () () ()	Press ▲▼◀▶ to view the previous or next image. Hold down the multi selector ▲, ▼, ◀ or ▶ to quickly scan through images.	26
View thumbnails/ calendar	W (E	Display 4, 9, or 16 image thumbnails. While displaying 16 image thumbnails, rotate the zoom control to W (►) to display the calendar.	60, 61
Playback zoom	T (Q)	The image can be enlarged up to about 10×. Press ® to return to full-frame playback.	62
Movie Playback	⊚ K	Play the selected movie.	79
Deleting Images	Ó	Delete the selected image.	26
Menu Display	MENU	Display the playback menu.	63
Switch to shooting mode	•	Press or the (movie-record) button. You can also press the shutter- release button to return to shooting mode.	10

Viewing Images

Viewing Multiple Images: Thumbnail Playback


Rotate the zoom control to **W** () in full-frame playback mode () to display images in "contact sheets" of thumbnail images. The following operations can be performed while thumbnails are displayed.



M THE CA				
То	Use	Description		
Choose images	(S)	Press the multi selector \triangle , \bigvee , \triangleleft or \triangleright .	11	
Increase the number of images displayed/apply the calendar display	W (►)	Rotate the zoom control to \mathbf{W} ($\mathbf{\square}$) to increase the number of picture thumbnails displayed: $4 \to 9 \to 16$. Rotate the zoom control to \mathbf{W} ($\mathbf{\square}$) in the 16-picture thumbnail display to apply the calendar display ($\mathbf{\square}$ 61), and images can be found by the date on which they were captured. Rotate the zoom control to \mathbf{T} (\mathbf{Q}) to return to thumbnail display mode. Rotate the zoom control to \mathbf{T} (\mathbf{Q}) to reduce the number of frames displayed from $16 \to 9 \to 4$. While 4 frames are displayed, rotate the zoom control to \mathbf{T} (\mathbf{Q}) again to return to full-	-	
		frame display mode.		
Switch to full-frame playback	®	Press ® .	26	
	۵			
Switch to shooting mode	•	Press □ or the ● (movie-record) button. You		
	↓	can also press the shutter-release button to return to shooting mode.	10	

Thumbnail Playback Mode Display

While images selected for **Print Set** (\square 64) and **Protect** (\square 112) are chosen, the icons shown on the right are displayed with them. Movies are displayed as film frames.



Calendar Display

When displaying 16 thumbnail frames in playback mode (\square 60), switch to calendar display by rotating the zoom control to **W** (\blacksquare).

You can select images to view based on the day they were taken. Days containing images have a yellow line under them.



То	Use	Description	
Choose date	089 0	Press the multi selector \triangle , \bigvee , \triangleleft or \triangleright .	11
Switch to full-frame playback	⊗	The first image for that date will be displayed full-frame.	26
Switch to thumbnail display	T (Q)	Rotate the zoom control to ${\bf T}$ (${\bf Q}$).	-

Calendar display

- Images taken when the camera's date is not set are treated as images taken on January 1, 2011.
- $\overleftarrow{\text{m}}$ and **MENU** are not available during calendar display.

Taking a Closer Look: Playback Zoom

Rotating the zoom control to $\mathbf{T}(\mathbf{Q})$ during full-frame playback mode (\square 26) zooms the current image, with the center of the image displayed in the monitor.

 The guide displayed in the right bottom in the monitor will show which part of the image is currently displayed.




The following operations can be performed while images are zoomed in.

То	Use	Description	
Zoom in	T (Q)	Zoom increases each time the zoom control is rotated to $\mathbf{T}(\mathbf{Q})$, up to about 10x.	-
Zoom out	W (53)	Zoom decreases each time the zoom control is rotated to W (). When the magnification ratio reaches 1×, the display returns to full-frame playback mode.	-
View other areas of image	(1) (8) (8)	Press the multi selector \blacktriangle , \blacktriangledown , \blacktriangleleft or \blacktriangleright to scroll to areas of the image not visible in the monitor.	11
Switch to full-frame playback	Ø8	Press 👀.	26
Crop image MENU		Press MENU to crop current image to contain only the portion visible in the monitor.	72
Switch to shooting mode	•	Press or the (movie-record) button. You can also press the shutter-release button to return to shooting mode.	10

Images taken using Face Detection

When the zoom control is rotated to $\mathbf{T}(\mathbf{Q})$ during full-frame playback mode for images taken using Face Detection (\square 24), the image will be enlarged with the face detected with shooting at the center of the monitor.



 Rotate the zoom control toward T (Q) again or toward W (►) to zoom in or out as normal.

Playback Menu

The following options are available in playback mode.

	D-Lighting	1 70
	Enhances brightness and contrast in dark portions of images.	
4	Print set	1 64
	Select images to print and the number of copies for each.	
	Slide show	1 66
	View images saved in the internal memory or on a memory card in an autoslide show.	omatic
ú	Delete	1 67
	Delete selected images or all images. Multiple images can be deleted with operation.	one
	Small picture	 71

Create a small copy of the current image.

Displaying the Playback Menu

Press **•** to enter playback mode.

Display the playback menu by pressing MENU.



- Use the multi selector to choose and apply settings (QQ 11).
- To exit the playback menu, press **MENU**.

Protecting Images From Accidental Deletion, Rotating Images

- You can rotate images by using **Rotate image** (113) in the setup menu (92).

Copying Files Between the Internal Memory and Memory Card

You can copy files between the internal memory and memory card by using **Copy** (\square 114) in the setup menu (\square 92).

Print Set

Press the ▶ button (Playback mode) → MENU (Playback menu) → 🗗 Print set

When printing images using one of the following methods, you can select which images will be printed and the number of copies of each image will be printed, and save this electronic "print order" information on the memory card.

- Printing by inserting the camera's memory card into the card slot of a DPOF-compatible printer (134)
- Printing by taking the camera's memory card to a photo lab
- **1** Press **MENU** in playback mode.

The playback menu is displayed.



2 Use the multi selector to choose **Print set** and press **®**.



3 Choose **Select images** and press **®**.



4 Choose the images (up to 99) and number of copies (up to nine) of each.

Press the multi selector ◀ or ▶ to choose the desired images. Press ▲ or ▼ to set the number of copies for each. Images selected for printing can be identified by the check mark (❤) and the numeral indicating the number of copies to be printed. Images for which no copies have been specified will not be printed.



Rotate the zoom control to $\mathbf{T}(\mathbf{Q})$ to display full-frame playback, and \mathbf{W} ($\mathbf{\Xi}$) to switch back to 12 thumbnails. Press $\mathbf{\Theta}$ when setting is complete.

5 Choose whether or not to also print shooting date and photo information.

Choose ${\bf Date}$ and press ${\bf W}$ to print date of recording on all images in the print order.

Choose **Info** and press **®** to print photo information (shutter speed and aperture) on all images in the print order.

Choose **Done** and press **®** to complete the print order and exit.

Images selected for printing are indicated by the a icon displayed during playback.





Notes on Printing Shooting Date and Photo Information

When the **Date** and **Info** options are enabled in the print set menu, shooting date and photo information are printed on images when a DPOF-compatible printer (134) which supports printing of shooting date and photo information is used.

- Photo information cannot be printed when the camera is connected directly to a printer, via the supplied USB cable, for DPOF printing (90).
- Date and Info are reset each time the Print set menu is displayed.
- The date and time printed on images with DPOF printing when
 Date in the Print set menu is enabled, are those saved with the
 image when it was taken. Date and time printed using this option
 are not affected when the camera's date and time setting are
 changed from the setup menu after images are saved.



Deleting All Print Orders

Select **Delete print set** in step 3 of the print set procedure (\square 64) and press \otimes to delete print orders for all images.

Date Imprint

The shooting date and time can be imprinted in images at the time of shooting by using **Date imprint** (\square 102) in the setup menu. Dates can be printed from printers that do not support date imprinting (\square 65). Only the Date imprint date and time on images will be printed, even if **Print set** is enabled with date selected in the print set screen.

□ Slide Show

Press the ▶ button (Playback mode) → MENU (Playback menu) → ➡ Slide show

View images saved in the internal memory or on a memory card in an automatic slide show.

1 Use the multi selector to choose **Start** and press **®**.

To repeat the slide show automatically, enable **Loop** and press **®** before selecting **Start**. The check mark (**>**) is added to the loop option when enabled.



2 The slide show begins.


While the slide show is in progress, the following operations can be performed:

- Use the multi selector to switch images. Hold ▶ or ◀
 down to fast forward or rewind
- Press (K) to pause the slide show.



3 Choose Fnd or Restart

When the slide show ends or is paused, select **End** and press **®** to return to the playback menu, or choose **Restart** to play the slide show again.



Notes on Slide Show

- Only the first frame of movies (79) included in slide shows is displayed.
- Even if **Loop** is selected, the monitor can continuously display the Slide Show for up to 30 minutes (\(\simp\) 106).

₩ Delete

Press the ▶ button (Playback mode) → MENU (Playback menu) → 🖆 Delete

Delete selected images or all images.

Erase selected images

Delete selected images. → Selecting Multiple Images (□ 68)

Erase all images

Delete all images.



- Once deleted, images cannot be recovered. Transfer important images to a computer before deletion.
- Images marked with the $\mathfrak{G}_{\overline{a}}$ icon are protected and cannot be deleted (\mathfrak{Q} 112).

Selecting Multiple Images

The screen shown on the right will be displayed in the menus (shown below) when choosing images.

Playback menu: Print set: **Select images** (QQ 64),

Delete: Erase selected images (QQ 67)

Setup menu: Welcome screen: **Select an image** (QQ 96),

Protect (112), Rotate image (113),

Copy: Selected images (114)

Follow the procedure described below to choose the images.



1 Press the multi selector

or

to choose the desired image.

Only one image can be selected for **Welcome screen** and **Rotate image**. Proceed to step 3.

Rotate the zoom control to $\mathbf{T}(\mathbf{Q})$ to display full-frame playback, and $\mathbf{W}(\mathbf{\Xi})$ to switch back to 12 thumbnails.



2 Press ▲ or ▼ to select **ON** or **OFF** (or the number of copies).

When **ON** is selected, a check mark (\checkmark) is displayed in the top left corner of the current image. Repeat steps 1 and 2 to select additional images.



3 To fix the selection of images, press **®**.

A confirmation dialog is displayed for certain screens, such as **Erase selected images**. In this case follow the on-screen directions.

Image Editing Function

Use the camera to edit images in-camera and save them as separate files. The editing features described below are available (\square 121).

Editing function	Description
D-Lighting (70)	Create a copy of the current image with enhanced brightness and contrast, brightening dark portions of the image.
Small picture (71)	Create a small copy of images suitable for use on web pages or as e-mail attachments.
Crop (QQ 72)	Enlarge the image or refine the composition and create a copy containing only the portion visible in the monitor.

Notes on Image Editing

- Images taken at an Image mode setting (□ 51) of 3968×2232 or 1920×1080 cannot be edited.
- Only images taken with the COOLPIX L105 can be edited with this camera.
- When using a different model of digital camera, images edited with this camera may not be displayed properly and may not be able to be transferred to a computer.
- Editing functions are not available when there is not enough free space in the internal memory or on the memory card.

Restrictions on Image Editing

The following limitations apply when editing images that were created by editing.

Copies Created By:	Can Be Edited By:
D-Lighting	Small picture and crop can be used.
Small picture Crop	Additional editing is not possible.

- Images cannot be edited twice with the same editing function.
- To use D-Lighting together with small picture or crop, use D-Lighting first, and use small picture or crop as the last edit function performed on that image.

Original Images and Edited Copies

- Copies created with editing functions are not deleted if the original images are deleted. The
 original images are not deleted if copies created with editing functions are deleted.
- Edited copies are saved with the same shooting date and time as the original.
- Edited copies do not retain the **Print set** (\square 64) and **Protect** (\square 112) settings of the original.

Editing Images

D-Lighting: Enhancing Brightness and Contrast

Create a copy of the current image with enhanced brightness and contrast, brightening dark portions of the image. Enhanced copies are saved as separate files

- Select the desired image from full-frame (26) or thumbnail (60) playback mode and press MENU.
 - The playback menu is displayed.



- 2 Use the multi selector to choose 🖪 **D-Lighting** and press **®**.
 - The original version is displayed on the left and the edited version is displayed on the right.



- 3 Choose **OK** and press **®**.
 - A new image with enhanced brightness and contrast is created.
 - To cancel, select Cancel and press (%).
 - Images created with D-Lighting can be identified by the 🔁 icon displayed during playback.





Small Picture: Resizing Images

Create a small copy of the current image. Suitable for uploading to web sites or sending by e-mail. The following sizes are available: 440×480, 320×240, and 160×120. Small copies are saved as JPEG files with a compression ratio of 1.16

- 1 Select the desired image from full-frame (26) or thumbnail (60) playback mode and press MENU.
 - The playback menu is displayed.



2 Use the multi selector to choose **Small** picture and press (%).



3 Choose the desired copy size and press **®**.



- 4 Choose **Yes** and press **®**.
 - A new, smaller copy is created.
 - To cancel, select **No** and press **(N)**.
 - The copy is displayed with a gray frame.




★ Crop: Creating a Cropped Copy

Create a copy containing only the portion visible in the monitor when MENU 8 & is displayed with playback zoom (ac) enabled. Cropped copies are saved as separate files.

- 1 Rotate the zoom control to **T** (Q) in full-frame playback mode to zoom in on the image.
 - To crop an image displayed in "tall" (portrait) orientation, zoom in on picture until the black bars displayed on the both sides of the monitor disappear. The cropped image is displayed in landscape orientation. To crop the image in its current "tall" (portrait) orientation, first, use the Rotate image.





Rotate the zoom control to $\mathbf{T}(Q)$ or $\mathbf{W}(\mathbf{\Xi})$ to adjust the zoom ratio.

Press the multi selector \triangle , ∇ , \triangleleft or \triangleright to scroll the image until only the portion you want to copy is visible in the monitor.



3 Press MENU.



4 Use the multi selector to select **Yes** and press **®**.

A new image, containing only the portion visible in the monitor, is created.

To exit without cropping the image, choose \mathbf{No} and press $\mathbf{@}$.



About the size of the original image

The smaller the cropped area of the image, the smaller of the cropped image size (number of pixels). When the image is cropped and the size of the cropped copy is 320×240 or 160×120 , the image is displayed with a gray border on the playback screen, and the small picture icon \square or \square is displayed on the left of the playback screen.

More Information

Recording Movies

You can use the camera to record movies with sound.

The maximum file size for a single movie is 4 GB and the maximum movie length for a single movie is 29 minutes, even when there is sufficient free space on the memory card for longer recording (\square 77).

1 Turn the camera on and display the shooting mode screen.

- Movies can be recorded in any shooting mode $(\Box \Box 34).$
- The current movie options setting is displayed. The default setting is **HD720p** (1280×720) (ДД 77).



Movie options


2 Lower the built-in flash (\square 6)


Recording movies while the built-in flash is raised may cause the audio to be muffled.

3 Press the **●** (movie-record) button to start recording.

- · Recording begins after the monitor turns off briefly.
- The camera focuses on the subject in the center of the frame. The focus area is not displayed while recording movies.









Press the (movie-record) button to stop recording.



Recording Movies

- When recording movies, we recommend using a memory card with a Class 6 or higher speed class rating (\(\superactin \superactin 120\)). When using a memory card with a low speed class, recording may stop unexpectedly.
- When recording movies, the angle of view (field of view) is smaller than when shooting still images.
- Digital zoom cannot be used while recording movies.
- Operation sounds from the time of recording (the zoom control being rotated, the lens zooming, the autofocus, etc.) may be heard when playing back movies.
- Smear (
 — 119) visible in the monitor when recording will be visible in the saved image data. To
 reduce smear effects, avoid bright objects such as the sun, reflections of the sun, and electric lights
 when recording movie.

Autofocus

- When **Autofocus mode** in the movie menu is set to **& Single AF** (default setting), focus is locked when the **●** (movie-record) button is pressed and recording starts (□ 78).
- - 1. Before recording, set **Autofocus mode** to **Single AF** (default setting) in the movie menu.

While the Camera Is Saving Movies

When movie recording stops, the movie is not completely saved until the shooting screen is displayed. Do not open the battery-chamber / memory card slot cover if the movie has not yet been completely saved. Removing the memory card or the battery while a movie is being saved may result in loss of the movie data or damage to the camera or the memory card.

Functions Available in Movie Mode

- When the shooting mode is set to **a** (auto) mode (□ 48), the current settings for white balance (□ 53) and color options (□ 57) are used when recording movies.
- When the shooting mode is set to any mode other than (auto) mode, White balance is set to
 Auto and Color options is set to Standard color when recording movies. Movies are recorded
 in color even when scene mode is set to Copy.

- Flash will not fire even when lighting is poor.
- When recording movies, electronic vibration reduction is used automatically to reduce the effects of camera shake.

Movie Menu

The movie menu contains the following options.

 Movie options
 □ 77

 The movie menu offers the options shown below.

 Note and the common of the comm

Displaying the Movie Menu

- 1 Display the shooting mode screen and press MENU.
 - The menu is displayed.





When using easy auto mode, scene mode, or smart
portrait mode, press the multi selector (☐ 11)
 to
display the tabs.



2 Press the multi selector **◄**.

You can now select a tab



3 Press **△** or **▼** to select the **ા** tab.



Recording Movies

4 Press **▶** or **®**.

You can now select an item from the movie menu.

Use the multi selector to choose and apply settings (\square 11).

To exit the movie menu, press \P and select another tab.



帰 Movie Options

Display the shooting mode screen → Press the MENU button → \P (Movie menu) (\square 75) → \P Movie options

The movie menu offers the options shown below. Increasing the image size and bitrate will increase the image quality, but file size will also increase.

Option	Description	
HD 720p (1280 × 720) (default setting)	Movies with an aspect ratio of 16:9 are recorded. • Movie bitrate: 9.0 Mbps	
VGA VGA (640 × 480)	Movies with an aspect ratio of 4:3 are recorded. • Movie bitrate: 3.0 Mbps	
OVGA (320 × 240)	Movies with an aspect ratio of 4:3 are recorded. • Movie bitrate: 640 kbps	

- The movie bitrate is the volume of movie data recorded per second. As a variable bitrate (VBR) system has been adopted, the movie recording rate varies automatically according to the subject so that more data is recorded per second for movies containing frequently moving subjects, thus increasing movie file size.
- The frame rate is approximately 30 frames per second in any options.

Movie Options and Maximum Movie Length

Option	Internal memory (Approx. 102 MB)	Memory card (4 GB)*
HD 720p (1280×720) (default setting)	1 min 24 s	50 min
VGA VGA (640×480)	3 min 54 s	2 h 5 min
QVGA (320×240)	10 min 57 s	4 h 45 min

All figures are approximate. The maximum recording time varies depending on the type of memory card used, the bit rate of recorded movies, etc.

More Information

^{*} The maximum file size for a single movie is 4 GB and the maximum movie length for a single movie is 29 minutes, even when there is sufficient free space on the memory card for longer recording.

ᢂ Autofocus Mode

Display the shooting mode screen \Rightarrow Press the MENU button \Rightarrow $\mbox{$\!\!\!/\!\!\!|}$ (Movie menu) ($\mbox{$\square$}$ 75) \Rightarrow $\mbox{$\square$}$ Autofocus mode

Choose how the camera focuses in movie mode.

Setting	Description
Single AF (default setting)	Focus is locked when the (movie-record) button is pressed to start recording. Select this option when the distance between the camera and the subject will remain fairly consistent.
Full-time AF	Camera focuses continuously. Select this option when the distance between the camera and subject will change significantly during recording. Use of Single AF is recommended to prevent the sound of the camera focusing from interfering with recording.


Movie Playback

In full-frame playback mode (26), movies can be identified by the Movie options icon (77). To play a movie, display it in full-frame playback mode and press .

15/11/2011 15:30 0010.MOV

Use the zoom control $\mathbf{T}(Q)/\mathbf{W}(\mathbf{\Xi})$ during playback to adjust the volume.

Playback controls are displayed at the top of the monitor. Press the multi selector \blacktriangleleft or \blacktriangleright to choose a control, then press $\textcircled{\textbf{W}}$ to perform the selected operation. The following operations are available.



То	Use	Description		
Rewind	4	Rewin	Rewind movie. Playback resumes when 6 is released.	
Advance	•	Advar	Advance movie. Playback resumes when 🔞 is released.	
	II		playback. The following operations can be performed playback is paused.	
Pause		4	Rewind movie by one frame. Rewind continues while ® is pressed.	
		₽	Advance movie by one frame. Advance continues while is pressed.	
		Þ	Resume playback.	
End	•	End playback and return to full-frame playback.		

Deleting Movies

Press $\widehat{\textbf{m}}$ when displayed in full-frame playback mode $(\square 26)$, or when selected in thumbnail $(\square 60)$ playback mode. A confirmation dialog is displayed. Choose **Yes** and press $\textcircled{\textbf{N}}$ to delete the movie, or choose **No** and press $\textcircled{\textbf{N}}$ to return to the normal playback display without deleting the movie.






Connecting to a TV


Connect the camera to a television using an optional audio/video cable (120) to play back images on a television.

1 Turn off the camera.




2 Connect the camera to the TV.

Connect the yellow plug of the audio/video cable to the video-in jack on the TV, and the white plug to the audio-in jack.



- **3** Tune the television to the video channel.
 - See the documentation provided with your television for details.
- **4** Hold down **▶** to turn on the camera.
 - The camera enters playback mode, and the images taken are displayed on the television.
 - While connected to the TV, the camera monitor remains off



Connecting the Audio/Video Cable

When connecting the AV cable, be sure that the camera connector is oriented correctly. Do not use force when connecting the AV cable to the camera. When disconnecting the AV cable, do not pull the connector at an angle.

Video Mode

Be sure that the camera's video mode setting conforms to the standard used by your television. The video mode setting is an option set in the **Set up** menu $(\square 92) \rightarrow TV$ settings $(\square 108)$.

Connecting to a Computer

Use the supplied USB cable to connect the camera to a computer and copy (transfer) images to the computer.

Before Connecting the Camera

Install the Software

Use the supplied ViewNX 2 CD and install the following software on the computer. For more information on installing the software, refer to the *Quick Start Guide*.

- ViewNX 2: Use the image transfer feature "Nikon Transfer 2" to save images that
 were captured with the camera on the computer. Saved images can be viewed
 and printed. Image and movie editing features are also supported.
- Panorama Maker 5: This software can join a series of images to create a single panorama image.

Compatible Operating Systems

Windows

Windows 7 Home Basic/Home Premium/Professional/Enterprise/Ultimate, Windows Vista Home Basic/Home Premium/Business/Enterprise/Ultimate (Service Pack 2), or Windows XP Home Edition/Professional (Service Pack 3)

Macintosh

Mac OS X (version 10.4.11, 10.5.8, 10.6.7)

For information about the requirements for playing back movies recorded when Movie options is set to \square HD 720p, refer to "System Requirements" in the ViewNX 2 help information (\square 85).

Refer to the Nikon website for the latest information on operating system compatibility.


Notes on Power Source

- When connecting the camera to a computer, use batteries with a sufficient amount of charge remaining to prevent the camera from turning off unexpectedly.
- To power the camera continuously for extended periods, use an AC Adapter EH-67 (available separately) (120). Do not, under any circumstances, use another make or model of AC adapter.
 Failure to observe this precaution could result in overheating or in damage to the camera.

Transferring Images from a Camera to a Computer

- 1 Start the computer to which ViewNX 2 was installed.
- **2** Be sure that the camera is off.
- **3** Connect the camera to the computer using the supplied USB cable.

Be sure that connectors are properly oriented. Do not attempt to insert connectors at an angle, and do not use force when connecting or disconnecting the USB cable.



4 Turn on the camera.

The power-on lamp will light. The camera monitor will remain off.



5 Start the ViewNX 2 image transfer feature "Nikon Transfer 2" installed on the computer.

Windows 7

When the **Devices and Printers** L105 screen is displayed, click **Change program** under **Import pictures and videos**. Select **Import File using Nikon Transfer 2** in the **Change program** dialog and click **OK**.

Double-click **Import File** on the **Devices and Printers** L105 screen.

Windows Vista

When the AutoPlay dialog is displayed, click Import File using Nikon Transfer 2.

Windows XP

When the action selection dialog is displayed, select **Nikon Transfer 2 Import File**, and click **OK**.

Mac OS X

Nikon Transfer 2 will start automatically when the camera is connected to the computer if **Yes** was selected in the **Auto-Launch setting** dialog when ViewNX 2 was first installed.

- See "Starting Nikon Transfer 2 Manually" (\$\sigma\$ 85) for more information.
- If there are a large number of images on the memory card, it may take some time for Nikon Transfer 2 to start.
- **6** Confirm that the source device is displayed in the transfer options **Source** panel and click **Start Transfer**.



Any images that have not been transferred to the computer will be transferred (default setting of ViewNX 2).

Connecting to a Computer

When transfer is complete, the ViewNX 2 screen is displayed (ViewNX 2 default setting) and transferred images are displayed.



For more information on using ViewNX 2, refer to the ViewNX 2 help information $(\square 35)$.

Disconnecting the Camera

Do not turn off the camera or disconnect the camera from the computer during transfer.

When transfer is complete, turn off the camera and disconnect the USB cable.



Transferring Images Using a Computer's Card Slot or a Commerciallyavailable Card Reader

When the memory card is inserted into a computer's card slot or into a commercially-available card reader, the images can be transferred using "Nikon Transfer 2", the image transfer feature of ViewNX 2.

- Make sure that the memory card being used is supported by the card reader or other card reading device.
- To transfer images, insert the memory card into the card reader or card slot and follow the procedure from step 5 (83).
- To transfer images saved in the camera's internal memory, the images must first be copied to a memory card using the camera (\square 114).



Starting ViewNX 2 Manually

Windows

Choose Start menu > All Programs > ViewNX 2 > ViewNX 2.

Double-clicking the **ViewNX 2** shortcut icon on the desktop will also start ViewNX 2.

Mac OS X

Open the Applications folder, open the Nikon Software > ViewNX 2 folders in that order, and then double-click the ViewNX 2 icon. Clicking the ViewNX 2 icon on the Dock will also start ViewNX 2.



Starting Nikon Transfer 2 Manually

To start Nikon Transfer 2, first start ViewNX 2, and then click the **Transfer** icon at the top of the screen or select Launch Transfer from the File menu.



For More Information on Using ViewNX 2 and Nikon Transfer 2

For more information on ViewNX 2 or Nikon Transfer 2, start ViewNX 2 or Nikon Transfer 2 and select ViewNX 2 Help from the Help menu.

Panorama Creation with Panorama Maker 5

- Use a series of images captured in **Panorama assist** scene mode (42) to create a single panorama photo with Panorama Maker 5.
- Panorama Maker 5 can be installed on a computer using the supplied ViewNX 2 CD.
- After installation is complete, follow the procedure described below to start Panorama Maker 5.

Windows

Choose Start menu>All Programs>ArcSoft Panorama Maker 5>Panorama Maker 5.

Mac OS X

Open Applications and double-click the Panorama Maker 5 icon.

• For more information on using Panorama Maker 5, refer to the on-screen instructions and help information contained in Panorama Maker 5.




Image File Names and Folder Names

See "Image File and Folder Names" (121) for more information.

Connecting to a Printer

Users of PictBridge-compatible (\square 134) printers can connect the camera directly to the printer and print images without using a computer.



Note on Power Source

- When connecting the camera to a printer, use batteries with adequate charge remaining to power the camera to prevent the camera from turning off unexpectedly.
- To power the camera continuously for extended periods, use an AC Adapter EH-67 (available separately) (120). Do not, under any circumstances, use another make or model of AC adapter.
 Failure to observe this precaution could result in overheating or in damage to the camera.

Printing Images


In addition to printing images transferred to a computer from your personal printer and printing over a direct camera-to-printer connection, the following options are also available for printing images:

- · Insert a memory card into a DPOF-compatible printer's card slot
- Take a memory card to a digital photo lab


For printing using these methods, you can specify the images and the number of prints each using **Print set** in the playback menu $(\square 64)$.

Connecting the Camera and Printer


1 Turn off the camera.



- **2** Turn on the printer.
 - Check printer settings.
- **3** Connect the camera to the printer using the supplied USB cable.



- 4 Turn on the camera.
 - When connected correctly, the PictBridge startup screen (1) is displayed in the camera monitor. Then the **Print selection** screen is displayed (2).





Connecting the USB Cable

When connecting the USB cable, be sure that the connectors are oriented correctly. Do not use force when connecting the USB cable. When disconnecting the USB cable, do not pull the connector at an angle.

Printing Images One at a Time

After connecting the camera to the printer correctly (\square 87), print images by following the procedure below.

- 1 Use the multi selector to choose the desired image and press

 .
 - Rotate the zoom control to W (■) to display 12 thumbnails, and T (Q) to switch back to full-frame playback.



2 Choose **Copies** and press **®**.



3 Choose the number of copies (up to nine) and press **6**.



4 Choose **Paper size** and press **®**.



- **5** Choose the desired paper size and press **®**.
 - To specify paper size using printer settings, choose **Default** in the paper size menu.




6 Choose Start print and press ®.



7 Printing starts.

Monitor display returns to that shown in step 1 when printing is complete.

To cancel before all copies have been printed, press **®**.



Current print/ total number of prints

Printing Multiple Images

After connecting the camera to the printer correctly (\square 87), print images by following the procedure below.

When the Print selection screen is displayed, press MENU.

The **Print menu** is displayed.



2 Use the multi selector to choose **Paper size** and press **®**.

Press **MENU** to exit the print menu.



3 Choose the desired paper size and press **®**.

To specify paper size using printer settings, choose **Default** in the paper size menu.



4 Choose Print selection, Print all images or DPOF printing and press (8).



Print selection

Choose the images (up to 99) and number of copies (up to nine) of each.

- Press the multi selector

 or

 to select images, and press

 or

 to set the number of copies for each.
- Images selected for printing can be identified by the check mark (♥) and the numeral indicating the number of copies to be printed. Images for which no copies have been specified will not be printed.
- Rotate the zoom control to T (Q) to display full-frame playback, and W (►) to switch back to 12 thumbnails
- Press **(N)** when setting is complete.
- The menu shown on the right is displayed. To print, select **Start print** and press **3** Choose **Cancel** and press **4** to return to the print menu.



Print all images

All images saved in the internal memory, or on the memory card, are printed one at a time.

 The menu shown on the right is displayed. To print, select Start print and press
 Oncose Cancel and press to return to the print menu.



DPOF printing

Print images for which a print order was created in **Print set** (\square 64).


- The menu shown on the right is displayed. To print, select **Start print** and press **3**. Choose **Cancel** and press **3** to return to the print menu.





5 Printing starts.

- Monitor display returns to the print menu (step 2) when printing is complete.
- To cancel before all copies have been printed, press **®**.



Current print/ total number of prints

Paper Size

The camera supports the following paper sizes: **Default** (the default paper size for the current printer), 3.5×5 in., 5×7 in., 100×150 mm, 4×6 in., 8×10 in., Letter, A3, and A4. Only sizes supported by the current printer will be displayed.

Setup Menu

The setup menu contains the following options.

MEHÚ	Menus	1 95
	Select how menus are displayed.	
Ü	Welcome screen	1 96
	Specify the welcome screen displayed when the camera is turned on.	
(4)	Date	1 97
	Set camera clock and choose home and destination time zones.	
	Monitor settings	1 00
	Adjust photo info, image review, and brightness settings.	
DATE	Date imprint	1 02
	Imprint date on images.	
(4)	Vibration reduction	1 03
	Specify the vibration reduction setting for shooting still images.	
وم	Motion detection	1 04
	Specify whether or not motion detection is used to reduce the effects subject movement and camera shake when taking still images.	of
4 >>	Sound settings	1 05
	Specify sound settings.	
9	Auto off	1 06
	Set time before camera enters standby mode to save power.	
	Format memory/Format card	1 07
	Format internal memory or memory card.	
×	Language	108
	Choose the language used for camera monitor display.	
=	TV settings	108
	Adjust settings for connection to a television.	
i≘	Blink warning	1 09
	Set whether or not to detect human subjects with eyes closed when spictures using face detection.	hooting
C	Reset all	110
	Restore camera settings to default values.	
8	Battery type	112
	Select the type of batteries used.	
Оп	Protect	112
	Protect selected images from accidental deletion.	

4	Rotate image	113
	Change the orientation of an image.	
Œ	Сору	III 114
	Copy files between memory card and internal memory.	
Ver.	Firmware version	1 15
	Display camera firmware version	

Displaying the Setup Menu

1 Press MENU.

The menu is displayed.

 When using easy auto mode, scene mode, or smart portrait mode, press the multi selector (☐ 11) ◀ to display the tabs.





- **2** Press the multi selector **◄**.
 - You can now select a tab.



3 Press \triangle or ∇ to select the Υ tab.



4 Press **▶** or **®**.

- You can now select an item from the setup menu.
- Use the multi selector to choose and apply settings (\(\supersetting\) 11).
- To exit the setup menu, press MENU or press

 and select another tab.



Menus

Press the MENU button $\rightarrow \Upsilon$ (Setup menu) (\square 93) $\rightarrow \overline{\mathbb{M}}$ Menus

Select how menus are displayed.

■ Text (default setting)

Menus are displayed in list format.



Icons

All menu items can be displayed in a single page.



I□ Welcome Screen

Press the MENU button → Y (Setup menu) (□ 93) → □ Welcome screen

Specify the welcome screen displayed when the camera is turned on.

None (default setting)

The welcome screen is not displayed when the camera is turned on; the shooting mode or playback mode screen is displayed.

COOLPIX

The welcome screen is displayed when the camera is turned on, then the shooting mode or playback mode screen is displayed.

Select an image

An image captured with this camera is used as the welcome screen. When the image selection screen is displayed (\square 68), select the desired image and press \otimes to register the image as the welcome screen.

- As the selected image is saved in the camera, the image is displayed in the welcome screen even if the original image is deleted.
- Images captured with an Image mode (□ 51) setting of 3968×2232 or 1920×1080, and image copies created using small picture (□ 71) or crop (□ 72) that are 320×240 or smaller, cannot be selected.

① Date

Press the MENU button → Y (Setup menu) (□ 93) → ② Date

Set the camera clock.

Date

Set camera clock to current date and time.

Use the multi selector to set the date and time.

- Edit the highlighted item: Press ▲ or ▼.
- Finish setting: After selecting the order in which the day, month, and year are displayed, press (11).

Time zone

Set the home ($\stackrel{\bullet}{\mathbf{n}}$) time zone (district) or daylight saving time. When the destination ($\stackrel{\bullet}{\mathbf{n}}$) time zone is selected, the time difference ($\stackrel{\bullet}{\Box}$) 99) is automatically calculated and the date and time in the selected region are saved. This can be useful when travelling.

Setting Travel Destination Time Zone

1 Use the multi selector to choose **Time zone** and press **®**.

The Time zone menu is displayed.



2 Choose **→ Travel destination** and press **®**.

The date and time displayed in the monitor changes according to the region currently selected.



3 Press ▶.

The new city time zone menu is displayed.



4 Press **◄** or **▶** to select the travel destination time zone (city name).

To use the camera in an area where daylight saving time is in effect, press ▲ to display the ♣ mark at the top of the monitor and set the daylight saving time. When the daylight saving time goes into effect, the clock is automatically advanced one ▶ hour. To turn off the daylight saving time setting, press ▼.



Press (to enter the travel destination.

While the travel destination time zone is selected, the \$ icon will be displayed in the monitor when the camera is in shooting mode.

The Clock Battery

The camera's clock is powered by a clock battery that is independent of the batteries that powers the camera. The clock battery charges when the main batteries are installed or an AC adapter is connected, and can provide several days of backup power after about 10 hours of charging.

(Home Time Zone)

- To switch to the home time zone, choose **\(\frac{1}{4} \) Home** in step 2 and press **(N)**.
- To change the home time zone, choose Home in step 2 and perform steps 3 and 4, to set the
 home time zone.

Daylight Saving Time

When the summer saving time begins or ends, turn the daylight saving time option on or off using the home time zone display in Step 4.

Imprinting the date on pictures

After setting the date and time, set the **Date imprint** setting (\square 102) in the setup menu. Once **Date imprint** is set, the shooting date and time can be imprinted on the image data when taking pictures.

Time Zones

The camera supports the time zones listed below.

For time zones not listed below, set the camera's clock manually to local time using **Date** in the setup menu.

UTC +/-	Time zone	UTC +/-	Time zone
-11	Midway, Samoa	+1	Madrid, Paris, Berlin
-10	Hawaii, Tahiti	+2	Athens, Helsinki, Ankara
-9	Alaska, Anchorage	+3	Moscow, Nairobi, Riyadh, Kuwait, Manama
-8	PST (PDT): Los Angeles, Seattle, Vancouver	+4	Abu Dhabi, Dubai
-7	MST (MDT): Denver, Phoenix, La Paz	+5	Islamabad, Karachi
-6	CST (CDT): Chicago, Houston, Mexico City	+5.5	New Delhi
-5	EST (EDT): New York, Toronto, Lima	+6	Colombo, Dhaka
-4.5	Caracas	+7	Bangkok, Jakarta
-4	Manaus	+8	Beijing, Hong Kong, Singapore
-3	Buenos Aires, Sao Paulo	+9	Tokyo, Seoul
-2	Fernando de Noronha	+10	Sydney, Guam
-1	Azores	+11	New Caledonia
±0	London, Casablanca	+12	Auckland, Fiji

□ Monitor Settings

Press the MENU button $\Rightarrow \Upsilon$ (Setup menu) (\square 93) $\Rightarrow \square$ Monitor settings

The following settings are available.

Photo info

Choose information displayed in the monitor during shooting and playback mode. (101)

Image review

- **On** (default setting): Images are automatically displayed briefly immediately after shooting.
- Off: Images are not displayed after shooting.

Brightness

Choose from five settings for monitor brightness. The default setting is 3.

Photo Info

Select whether or not photo info is displayed.

See "The Monitor" (\square 8, 9) for information on indicators in the monitor.

	Shooting mode	Playback mode	
Show info	© 2°D	15/11/2011 12:00 0004.JPG	
Auto info (default setting)	The same information as in Show info is displayed. If no operations are performed after a few seconds, the display will be the same as Hide info . The information is displayed again when an operation is performed.		
Hide info			
Framing grid	In the following shooting modes, a framing grid is displayed to help frame pictures, in addition to the information displayed in Auto info. • ② (Easy auto) • ② (Auto) In other shooting modes, the same information as in Auto info is displayed.	The same information as in Auto info is displayed.	

Date Imprint

Press the MENU button → Y (Setup menu) (☐ 93) → III Date imprint

The shooting date and time can be imprinted in images at the time of shooting. This information can be printed even from printers that do not support printing of date and time (\square 65).



Off (default setting)

Date and time are not imprinted on images.

DATE Date

The shooting date is imprinted in images.

Date and time

The shooting date and time is imprinted in images.

At settings other than **Off**, the icon for the current setting is displayed in the monitor $(\square 3)$.

Date imprint

- Imprinted dates form a permanent part of image data and cannot be deleted.
- Date imprint is disabled in the following situations.
- When using the **Museum** or **Panorama assist** scene modes.
 - When using sport continuous mode.
 - When Continuous (55) is set to Continuous or BSS.
 - When recording movies.
- Dates imprinted at an Image mode setting (□ 51) of 640×480 may be difficult to read.
 Select 1024×768 or larger when using date imprint.
- The date is saved using the format selected in the setup menu's **Date** item (16, 97).

Date Imprint and Print Set

When images are printed from DPOF-compatible printers that can print date and photo information, you can use **Print Set** (\square 64) and print the shooting date and photo information on the images. In such a case, it is unnecessary to imprint date and time on images beforehand using **Date Imprint**.

(Vibration Reduction

Press the MENU button → Y (Setup menu) (□ 93) → (■) Vibration reduction

Specify the vibration reduction setting for shooting still images. Vibration reduction effectively corrects blur that commonly occurs when shooting with zooming or at slow shutter speeds. Set vibration reduction to **Off** when using a tripod to stabilize the camera during shooting.

(M) On (hybrid)

Image-sensor shift vibration reduction reduces the effects of camera shake. Additionally, electronic vibration reduction is used to process images and remove the effects of camera shake in the following situations.

- · When the flash does not fire
- When a shutter speed slower than 1/60 seconds is used
- When **Self-timer** is disabled
- When Continuous is set to Single
- · When ISO sensitivity is set to 200 or less

(On (default setting)

Image-sensor shift vibration reduction reduces the effects of camera shake.

Off

Vibration reduction is not used

The vibration reduction setting can be confirmed in the monitor during shooting (\square 8, 21) (When it is set to **Off**, no icon is displayed).

Notes on Vibration reduction

- Vibration reduction may take a few seconds to activate after the power is turned on, or the camera enters shooting mode from playback mode. Wait until the display stabilizes before shooting.
- Due to characteristics of the vibration reduction function, images displayed on the camera's monitor immediately after shooting may appear blurry.
- Vibration reduction may be unable to completely eliminate the effects of camera shaking in some situations.
- When set to **On (hybrid)**, electronic vibration reduction may not reduce the effects of camera shake if the amount of vibration is very small or very large.
- When set to **On (hybrid)**, electronic vibration reduction does not function if shutter speed is fast or very slow.
- When set to **On (hybrid)**, the camera automatically releases the shutter two times for each shot
 and processes the image, therefore it takes more time to save captured images. The **Shutter**sound (\(\sigma\) 105) will be heard only once. Only one image is saved.

Using Vibration Reduction with Movies

When recording movies, electronic vibration reduction is used automatically to reduce the effects of camera shake.

Motion Detection

Press the MENU button → Y (Setup menu) (□ 93) → Motion detection

Specify whether or not motion detection is used to reduce the effects of subject movement and camera shake when taking still pictures.

Auto (default setting)

When the camera detects subject movement or camera shake, the ISO sensitivity and shutter speed are automatically increased to reduce blurring. Note that motion detection is not active in the following situations:

- When the flash is set to \$ (fill flash)
- When the ISO sensitivity option (□ 56) is set fixed at a particular value in
 (auto) mode
- When using Multi-shot 16 (55)
- In the following scene modes: Night portrait (37), Dusk/dawn (38), Night landscape (39), Museum (40), Backlight (41)
- When using Sport Continuous mode (46)

Off

Motion detection is not enabled

The motion detection setting can be confirmed in the monitor during shooting (\square 21).

When the camera detects shaking and increases shutter speed, the motion detection indicator turns green. When set to **Off**, no icon is displayed.

Notes on Motion detection

- Blurring caused by camera shake or subject movement may not be eliminated depending on shooting conditions.
- Motion detection may not function if the subject exhibits significant movement or is too dark.
- The images taken may become somewhat grainy.

Sound Settings

Press the MENU button → ¥ (Setup menu) (□ 93) → ♦ Sound settings

Specify sound settings.

Button sound

Turn the button sound **On** or **Off**. When **On** (default setting) is selected, a beep will sound once when operations are completed successfully, twice when the focus has been locked, and three times when an error is detected, and Start-up sound will also play when the camera is turned on.

Shutter sound

Choose shutter sound from **On** (default setting) or **Off**. Note that even when set to **On**, the shutter sound will not be heard in the following situations.

- When Continuous is set to Continuous, BSS, or Multi-shot 16
- When scene mode is set to **Museum**
- · When using sport continuous

(ii) Auto Off

Press the MENU button → Y (Setup menu) (☐ 93) → ② Auto off

When the camera is on and a period of time passes without any operations, the camera will enter standby mode (\square 15) to save power.

Once the camera has entered standby mode, the power-on lamp will blink. If no operations are performed for another three minutes, the camera will turn off. Use this option to set time before camera enters standby mode.

Auto off

Choose the time allowed to elapse before the camera enters standby mode if no operations are performed from **30 s** (default setting), **1 min**, **5 min**, and **30 min**.

Sleep mode

If **On** (default setting) is selected, the camera will enter standby mode when there is no change in the brightness of the subject, even before the time selected in the auto off menu has elapsed. The camera will enter sleep mode after 30 seconds when **Auto off** is set to **1 min** or less, or after 1 minute when **Auto off** is set to **5 min** or more.

Notes on Auto Off

The time allowed to elapse before the camera enters standby mode is fixed in the following cases:

- While menus are displayed: 3 minutes
- While slide show is in progress: Up to 30 minutes

Exiting Standby Mode

Press one of the following buttons to exit standby mode.

- · Power switch
- Shutter-release button
- 🗖 button
- ▶ button
 - (movie-record) button

I Format Memory/ ☐ Format Card

Press the MENU button → Y (Setup menu) (□ 93) → In Format memory/ Format card

Use this option to format the internal memory or a memory card.

Formatting internal memory

To format the internal memory, remove the memory card from the camera

The **Format memory** option is displayed in the setup menu.

Format memory be deleted! OK?

Formatting a Memory Card

When the memory card is inserted into the camera, the **Format card** option is displayed in the setup menu.



Formatting Internal Memory and Memory Cards

- Formatting the internal memory or memory cards **permanently deletes all data**. Be sure to transfer important images to a computer before formatting.
- Do not turn the camera off or open the battery-chamber/memory card slot cover during formatting.
- The first time you insert the memory cards used in other devices into this camera, be sure to format them using this camera.

▶ Language

Press the MENU button → Y (Setup menu) (☐ 93) → ► Language

Select one of 24 languages for display of camera menus and messages.

Čeština	Czech
Dansk	Danish
Deutsch	German
English	(default setting)
Español	Spanish
Ελληνικά	Greek
Français	French
Indonesia	Indonesian
Italiano	Italian
Magyar	Hungarian
Nederlands	Dutch
Norsk	Norwegian

Polski	Polish
Português	Portuguese
Русский	Russian
Suomi	Finnish
Svenska	Swedish
Türkçe	Turkish
عسربي	Arabic
简体中文	Simplified Chinese
繁體中文	Traditional Chinese
日本語	Japanese
한글	Korean
ภาษาไทย	Thai

TV Settings

Press the MENU button → Y (Setup menu) (☐ 93) → ■ TV settings

Adjust settings for connection to a television.

Set **Video mode** to **NTSC** or **PAL** depending on the specification of the connected television

Blink Warning

Press the MENU button → Y (Setup menu) (□ 93) → ☑ Blink warning

Set whether or not to detect human subjects with eyes closed when shooting pictures using face detection $(\square 24)$ in the following situations.

- 🏅 (Easy auto) mode
- Portrait (36) or Night portrait (37) scene modes

On

When the camera detects that one or more human subjects have closed their eyes shortly after detecting the faces and shooting them, the **Did someone blink?** screen will be displayed in the monitor. The face of the human subject that may have closed his/her eyes is framed by a yellow border. In such a case, you can check the shot picture and determine if you take the picture again.

→ "Operating the Did someone blink? Screen"

Off (default setting)

Blink warning does not take effect.

Operating the Did someone blink? Screen

The following operations are available when the **Did someone blink?** screen is displayed.

If no operations are performed for a few seconds, the screen automatically returns to the shooting mode screen.



То	Use	Description
Enlarge and display the face of the person who blinked	T (Q)	Rotate the zoom control to $\mathbf{T}(\mathbf{Q})$.
Switch to full-frame playback	W (53)	Rotate the zoom control to W (🔁).
Select the face to be displayed	0 0 0	If the camera detects more than one human subjects with their eyes closed, press ▲▼◀ ▶ during the enlarged display to switch over the face displayed.
Delete the shot image	Ú	Press to.
Return to shooting mode	₩	Press 🔞 or the shutter-release button.

Reset All

Press the MENU button → Y (Setup menu) (☐ 93) → ■ Reset all

When **Reset** is selected, the camera's settings will be restored to their default values.

Pop-up Menu

Option	Default value
Flash mode (QQ 29)	Auto
Self-timer (◯ 32)	Off
Macro mode (49)	Off
Exposure compensation (33)	0.0

Scene Mode

Option	Default value
Scene mode (QQ 35)	Portrait
Hue adjustment in food mode (40)	Center

Sport Continuous Menu

Option	Default value
Sport continuous (QQ 46)	Continuous H
Image mode (CQ 51)	3 2048×1536

Shooting Menu

Option	Default value
Image mode (51)	2 4000×3000
White balance (53)	Auto
Continuous (CC 55)	Single
ISO sensitivity (QQ 56)	Auto
Color options (QQ 57)	Standard color

Movie Menu

Option	Default value
Movie options (77)	HD 720p (1280×720)
Autofocus mode (QQ 78)	Single AF

Setup Menu

Option	Default value
Menus (QQ 95)	Text
Welcome screen (96)	None
Photo info (100)	Auto info
Image review (100)	On
Brightness (100)	3
Date imprint (102)	Off
Vibration reduction (103)	On
Motion detection (104)	Auto
Button sound (QQ 105)	On
Shutter sound (105)	On
Auto off (QQ 106)	30 s
Sleep mode (106)	On
Blink warning (109)	Off

Others

Option	Default value
Paper size (QQ 88, 89)	Default

- Choosing Reset all also clears the current file number (
 121) from the memory. Numbering will continue from the lowest number available. To reset file numbering to "0001", delete all images (
 67) before selecting Reset all.
- The following settings in the menus will remain unaffected even if Reset all is performed.

Shooting menu:

Preset manual in the **White balance** menu (54)

Setup menu:

Settings for image registered for **Welcome screen** (96), **Date** (97), **Language** (108), **TV settings** (108), and **Battery type** (112)

出 Battery Type

Press the MENU button → Y (Setup menu) (□ 93) → H Battery type

To ensure that the camera shows the correct battery level (\square 20), choose the type that matches the batteries currently in use.

Alkaline (default setting)	LR6/L40 (AA-size) alkaline batteries
COOLPIX (Ni-MH)	Nikon EN-MH2 rechargeable Ni-MH (nickel metal hydride) batteries
Lithium	FR6/L91 (AA-size) lithium batteries

On Protect

Press the MENU button \Rightarrow Y (Setup menu) (\square 93) \Rightarrow On Protect

Protect selected images from accidental deletion. Use the image selection screen to turn protection on and off for selected images (see "Selecting Multiple Images" (\square 68) for more information).

Note, however, that formatting the camera's internal memory or the memory card will permanently erase protected files (\square 107).

Protected images can be identified by the 🔊 icon (🛄 9, 60) in playback mode.

⚠ Rotate Image

Press the MENU button → ¥ (Setup menu) (□ 93) → 🗗 Rotate image

Set the image orientation (vertical or horizontal frame) displayed on the camera monitor after the pictures are taken.

Images can be rotated 90° clockwise or counterclockwise.

Images that were saved in the portrait (vertical) orientation can be rotated up to 180° in either direction.

Select images on the image selection screen (\square 68) to display the image rotation screen. Press the multi selector \blacktriangleleft or \blacktriangleright to rotate the image 90°.



Rotate 90° counterclockwise

Rotate 90° clockwise

Press M to select the displayed direction and the vertical / horizontal position data will be saved on the image.

☐ Copy: Copying Between Memory Card and Internal Memory

Press the MENU button → Y (Setup menu) (□ 93) → 日 Copy

Copy images between the internal memory and a memory card.

1 Select an option from the copy screen using the multi selector and press **®**.

▶ : Copy images from internal memory to memory card

☐ → ■: Copy images from memory card to internal memory.

© → CS

Сору

2 Choose the copy option and press **®**.

Selected images: Copy images selected from the image

selection screen (QQ 68).

All images: Copy all images.



Notes on Copy

- JPEG- and MOV-format files can be copied. Files saved in any other format cannot be copied.
- Images taken with another make of camera or that have been modified on a computer cannot be copied.
- When copying images for which Print set (\(\superscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\sinscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscript{\subscri

More Information

Ver Firmware Version

Press the MENU button → Y (Setup menu) (□ 93) → Ver. Firmware version

View the current camera firmware version.



Caring for the Camera

To ensure continued enjoyment of this Nikon product, observe the following precautions when using or storing the device:

Keep dry

The device will be damaged if immersed in water or subjected to high humidity.

▼ Do not drop

The product may malfunction if subjected to strong shock or vibration.

Handle the lens and all moving parts with care

Do not apply force to the lens, monitor, memory card slot or battery chamber. These parts are easily damaged. Applying force to the lens cover could result in camera malfunction or damage to the lens. Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent the liquid crystal from the display touching the skin or entering the eyes or mouth.

Do not point the lens at strong light sources for extended periods

Avoid pointing the lens at the sun or other strong light sources for extended periods when using or storing the camera. Intense light may cause deterioration of the image sensor, producing a white blur effect in photographs.

Keep away from strong magnetic fields

Do not use or save this device in the vicinity of equipment that generates strong electromagnetic radiation or magnetic fields. Strong static charges or the magnetic fields produced by equipment such as radio transmitters could interfere with the monitor, damage data saved on the memory card, or affect the product's internal circuitry.

Avoid sudden changes in temperature

Sudden changes in temperature, such as when entering or leaving a heated building on a cold day, can cause condensation to form inside the device. To prevent condensation, place the device in a carrying case or a plastic bag before exposing it to sudden changes in temperature.

Turn the product off before removing or disconnecting the power source

Do not remove the battery while the product is on, or while images are being saved or deleted. Forcibly cutting power in these circumstances could result in loss of data or in damage to product memory or internal circuitry.

The Battery

- After purchasing replacement rechargeable batteries, charge them before use. They are not fully charged at the time of purchase.
 - Be sure to read and follow the information found in "Optional Accessories" (\(\sum \) 120) and in the documentation included with the Battery Charger MH-73 (available separately).
- Battery capacity tends to decrease on cold days. Be sure that the batteries are fresh before heading
 outside to take pictures in cold weather. Keep spare batteries in a warm place and exchange as
 necessary. Once warmed, a cold battery may recover some of its charge.
- Dirt on the battery terminals can prevent the camera from functioning.
- Used batteries are a valuable resource. Please recycle used batteries in accordance with local regulations.

Cleaning

Lens	Avoid touching glass parts with your fingers. Remove dust or lint with a blower (typically a small device with a rubber bulb attached to one end that is pumped to produce a stream of air out the other end). To remove fingerprints or other stains that cannot be removed with a blower, wipe the lens with a soft cloth, using a spiral motion that starts at the center of the lens and working toward the edges. If this fails, clean the lens using a cloth lightly dampened with commercial lens cleaner.
Monitor	Remove dust or lint with a blower. To remove fingerprints and other stains, clean the monitor with a soft, dry cloth, being careful not to apply pressure.
Body	Use a blower to remove dust, dirt or sand, then wipe gently with a soft, dry cloth. After using the camera at the beach or seaside, wipe off any sand or salt with a dry cloth lightly dampened with fresh water, then dry thoroughly. Note that foreign matter inside the camera could cause damage not covered by the warranty.

Do not use alcohol, thinner, or other volatile chemicals.

Storage

Turn the camera off when not in use. Check that the power-on lamp is off before putting the camera away. Remove the battery if the camera will not be used for an extended period. Do not store the camera with naphtha or camphor moth balls, or in any of the following locations:

- Next to equipment that produces strong electromagnetic fields, such as televisions or radios
- Exposed to temperatures below −10 °C (14 °F) or above 50 °C (122 °F)
- Poorly ventilated or subject to humidities of over 60%

To prevent mold or mildew, take the camera out of storage at least once a month. Turn the camera on and release the shutter a few times before putting the camera away again.

Notes on the Monitor

- The monitor may contain a few pixels that are always lit or that do not light. This is a characteristic common to all TFT LCD displays, and does not indicate a malfunction. Images saved using the product will not be affected.
- When framing bright subjects, vertical comet-like streaks that whiten toward either end may
 appear in the display. This phenomenon, known as "smear", does not indicate a malfunction.
 In shooting modes other than Sport continuous mode, Multi-shot 16 and movie mode, smear has
 no effect on the images that are saved.
- Images in the monitor may be difficult to see under bright lighting.
- The monitor is lit by an LED backlight. Should the monitor begin to dim or flicker, contact your Nikon-authorized service representative.

Notes on Smear

White or colored streaks may be visible when bright subjects are framed in the monitor. This phenomenon, known as "smear," occurs when extremely bright light strikes the image sensor; it is characteristic of image sensors and does not indicate a malfunction. Smear may also take the form of partial discoloration in the monitor during shooting. It does not appear in images recorded with the camera except in the cases of movies and of images recorded with **Multi-shot 16** selected for **Continuous**. When shooting in these modes, we recommend that you avoid bright subjects such as the sun, reflected sunlight, and electric lights.

Optional Accessories

Battery charger/ Rechargeable batteries*	Battery Charger MH-73 (includes four EN-MH2 rechargeable Ni-MH batteries) Replacement rechargeable batteries: Rechargeable Ni-MH batteries EN-MH2-B4 (set of four EN-MH2 batteries)
AC adapter	AC Adapter EH-67
USB cable	USB Cable UC-E6
Audio/video cable	Audio Video Cable EG-CP14
Lens cap	Lens Cap LC-CP20

^{*} When using with the COOLPIX L105, charge the four EN-MH2 rechargeable Ni-MH batteries at a time using Battery Charger MH-73. Also, do not mix batteries that have a different amount of charge remaining (117). EN-MH1 rechargeable Ni-MH batteries cannot be used.

Approved Memory Cards

The following Secure Digital (SD) memory cards have been tested and approved for use in this camera.

 Memory cards with an SD Speed Class rating of 6 or faster are recommended for recording movies. Movie recording may stop unexpectedly when memory cards with a lower Speed Class rating are used.

	SD memory card	SDHC memory card ²
SanDisk	2 GB ¹	4 GB, 8 GB, 16 GB, 32 GB
TOSHIBA	2 GB ¹	4 GB, 8 GB, 16 GB, 32 GB
Panasonic	2 GB ¹	4 GB, 8 GB, 12 GB, 16 GB, 32 GB
Lexar	-	4 GB, 8 GB, 16 GB, 32 GB

If the memory card will be used with a card reader or similar device, make sure that the device supports 2 GB cards.

² SDHC compliant.


If the memory card will be used with a card reader or similar device, make sure that the device supports SDHC.



Contact the manufacturer for details on the above cards. We cannot guarantee camera
performance when using memory cards made by other manufacturers.

Image File and Folder Names

Images and movies are assigned file names as follows.



ascending order, starting with "0001")

- Files are saved in folders named with a folder number followed by a fivecharacter identifier: "P_" plus a three-digit sequence number for images taken using panorama assist (e.g. "101P_001"; QQ 42) and "NIKON" for all other images (e.g. "100NIKON"). When the number of files within a folder reaches 9999, a new folder will be created. File numbers will be assigned automatically starting with "0001"
- Files copied using **Copy** > **Selected images** are copied to the current folder, where they are assigned new file numbers in ascending order starting from the largest file number in memory. Copy > All images copies all folders from the source medium: file names do not change but new folder numbers are assigned in ascending order, starting from the largest folder number on the destination medium (\square 114).
- Folders can hold up to 200 images; if an image is taken when the current folder. contains 200 images, a new folder will be created by adding one to the current folder number. If an image is taken when the current folder is numbered 999 and contains 200 images or an image numbered 9999, no further images can be taken until the medium is formatted (\square 107) or a new memory card inserted.

Error Messages

The following table lists the error messages and other warnings displayed in the monitor, as well as the solutions for dealing with them.

Display	Problem	Solution	Щ
(blinks)	Clock not set.	Set clock.	97
	Battery running low.	Prepare to replace batteries.	14, 112
1 Battery exhausted.	Battery exhausted.	Replace batteries.	
● Battery temperature high	Battery temperature is high.	Turn off camera, and allow battery to cool down before resuming use. After 5 seconds, this message will disappear, the monitor will turn off, and the power-on lamp and flash lamp will blink rapidly. After the lamps blink for three minutes, the camera will turn off automatically. Pressing the power switch also turns off the camera.	14
AF ● (blinks red)	Camera cannot focus.	Refocus. Use focus lock.	24, 25, 48
Please wait for the camera to finish recording.	Camera cannot perform other operations until saving is complete.	Wait until message clears from display automatically when saving is complete.	25
• Memory card is write protected.	Write-protect switch is in "lock" position.	Slide write-protect switch to "write" position.	19
This card cannot be used.	Error accessing memory card.	Use approved card.Check that connectors are clean.	120 18
① This card cannot be read.		Confirm that memory card is correctly inserted.	18

Display	Problem	Solution	Image: section of the content of the
Card is not formatted. Format card? Yes No	Memory card has not been formatted for use in COOLPIX L105.	All data saved on the memory card will be deleted. If there is any data on the card that you want to keep, select No , and backup the data to a computer before formatting the memory card. To format the memory card, select Yes and press W .	19
Out of memory.	Memory card is full.	Choose smaller image mode. Delete images. Insert new memory card. Remove memory card and use internal memory.	51 26,67, 79 18 19
	Error occurred while saving image.	Format internal memory or memory card.	107
saved.	Camera has run out of file numbers.	Insert new memory card. Format internal memory or memory card.	18 107
	Image cannot be used for welcome screen.	The following cannot be registered as the welcome screen. Images reduced to 320 × 240 or smaller when edited using crop or small picture Images captured at an Image mode setting of 3968×2232 or 1920×1080.	51, 71, 72
	There is not enough memory to copy the image.	Delete images from destination.	67
mage cannot be modified.	You are trying to edit an image that cannot be edited.	Confirm the editing features that can be used. These options cannot be used with movies.	69 -
Cannot record movie.	Time out error while recording movie.	Choose memory card with faster write speed.	18

Error Messages

Display	Problem	Solution	Ф
Memory contains no images.	No images in the internal memory or memory card.	Remove memory card to play back images from internal memory.	114
File contains no image data.	File not created with COOLPIX L105.	File cannot be viewed on this camera. View file using the computer or any other	-
This file cannot be played back.		devices which was used to create or edit this file.	
1 All images are hidden.	The image cannot be played back in a slide show.	-	66
This image cannot be deleted.	Image is protected.	Disable protection.	112
Travel destination is in the current time zone.	Destination in same time zone as home.	-	97
Raise the flash.	The built-in flash is lowered.	Raise the built-in flash when changing the flash mode. Raise the built-in flash when shooting using the Night portrait and Backlight scene modes.	6, 29 37, 41
Lower the flash.	The flash is raised when recording a movie.	May hamper sound recording. Quietly lower the flash. The sound of the flash being lowered may be recorded.	73
Lens error. (If the lens cap is attached, turn the camera off, remove the lens cap, and turn the camera on.)	Lens error.	Remove the lens cap if still attached, and turn camera off and then on again. If error persists, contact retailer or Nikon-authorized service representative.	20
O Communications error	USB cable disconnected during printing.	Turn camera off, reconnect USB cable.	87

Display	Problem	Solution	Image: control of the
System error	Error has occurred in camera's internal circuitry.	Turn camera off, remove and reinsert battery, and turn camera on. If error persists, contact retailer or Nikon-authorized service representative.	14, 20
Printer error: check printer status.	Running out of ink or printer error.	Check printer. After solving the problem, select Resume and press ® to resume printing.*	-
Off Printer error: check paper	Specified size of paper is not loaded in printer.	Load the specified paper, select Resume and press of to resume printing.*	-
Off Printer error: paper jam	Paper has jammed in the printer.	Eject the jammed paper, select Resume and press to resume printing.*	-
Off Printer error: out of paper	No paper is loaded in printer.	Load the specified paper, select Resume and press of to resume printing.*	-
Off Printer error: check ink	Ink error.	Check ink, select Resume and press (M) to resume printing.	-
Off Printer error: out of ink	Ink cartridge is empty.	Replace ink, select Resume and press * to resume printing.	-
Printer error: file corrupt	An error caused by the image file has occurred.	Select Cancel and press ® to cancel printing.	-

^{*} See the documentation provided with your printer for further guidance and information.

Troubleshooting

If the camera fails to function as expected, check the list of common problems below before consulting your retailer or Nikon-authorized service representative. Refer to the page numbers in the right-most column for more information.

Display, Settings and Power Supply

Problem	Cause/Solution	
Monitor is blank	Camera is off. Battery exhausted. Standby mode for saving power: press the shutter-release button halfway. When flash lamp blinks red, wait until flash has charged. Camera and computer are connected via USB cable. Camera	20 20 15, 24 30 82 80
Monitor is hard to read	Adjust monitor brightness. Monitor is dirty. Clean monitor.	100 118
Camera turns off without warning	Battery exhausted. Camera has turned off automatically to save power. Battery is cold.	20 106 117
Date and time of recording are not correct	Images taken while the clock is not set will have a time stamp of "00/00/0000 00:00"; movies will be dated "01/ 01/2011 00:00". Set the correct date and time using Date in the setup menu. Check camera clock regularly against more accurate timepieces and reset as required.	16 97
No indicators displayed in monitor	Hide info is selected for Photo info . Select Show info .	100
Date imprint not available	Camera clock has not been set.	16, 97
Date not being displayed on images even when Date imprint is enabled	Date imprint cannot be used with the current shooting mode. A feature that cannot be used with date imprint is selected. Date imprint cannot be used when recording movies.	102
Camera settings reset	The clock battery is exhausted; all settings were restored to their default values.	98

Problem	Cause/Solution	
Monitor turns off, and the power-on lamp blinks rapidly.	Battery temperature is high. Turn off camera and allow battery to cool down before resuming use. After the lamps blink for three minutes, the camera will turn off automatically. Pressing the power switch also turns off the camera.	14

Electronically Controlled Cameras

In extremely rare instances, unusual characters may appear in the monitor and the camera may stop functioning. In most cases, this phenomenon is caused by a strong external static charge. Turn the camera off, remove and replace the battery, then turn the camera on again. In the event of continued malfunction, contact your retailer or Nikon-authorized service representative. Note that disconnecting the power source as described above may result in the loss of any data not saved to internal memory or the memory card at the time the problem occurred. Data already saved will not be affected.

Shooting

Problem	Cause/Solution	
No picture taken when shutter- release button is pressed.	 When camera is in playback mode, press . When menus are displayed, press MENU. Battery exhausted. When flash lamp blinks, flash is charging. 	10 12 20 30
Cannot use shooting mode.	Disconnect the USB cable.	82, 87
Camera cannot focus.	The intended subject is one with which autofocus does not perform well. Focus error. Turn camera off and then on again.	25 20
Images are blurred.	 Use flash. Raise the ISO sensitivity. Use vibration reduction and motion detection. Use BSS (Best Shot Selector). Use tripod and self-timer. 	29 56 103, 104 55 5, 32
Comet-like streaks that whiten toward either end appear in the monitor.	Smear may occur when the camera is aimed at a bright subject. When using multi-16, sport continuous, or when recording movies, avoid bright objects such as the sun, reflections of the sun, and electric lights.	55, 119
Bright specks appear in images taken with flash.	Flash is reflecting off particles in air. Lower the built-in flash or set flash mode to ③ (Off).	6, 29

Troubleshooting

Problem	Cause/Solution	Ш
Flash does not fire.	 The built-in flash is lowered, or flash mode is set to (Off). Some scene modes that cannot turn on flash are selected. Sport continuous mode is selected. A feature that cannot be used with the flash is selected. 	6, 29 35 46 58
Digital zoom cannot be used.	Digital zoom cannot be used in the following situations. When Portrait or Night portrait is selected for Scene mode. When smart portrait mode is selected. When Multi-shot 16 is selected for Continuous.	36, 37 44 55
Image mode not available.	A feature that cannot be used with image mode is selected. Available image modes differ according to the current shooting mode.	58 51
No sound when shutter is released.	Off is selected for Sound settings > Shutter sound in setup menu. Do not block the speaker.	105 4
Images appear smeared.	Lens is dirty. Clean lens.	118
Hues are unnatural.	White balance does not match light source.	53
Randomly spaced bright pixels ("noise") appear in image.	The subject is dark, so shutter speed is too slow or ISO sensitivity is too high. Noise can be reduced by using flash. Select a lower ISO sensitivity.	29 56
Images are too dark (underexposed).	The built-in flash is lowered, or flash mode is set to ⑤ (Off). Flash window is blocked. Subject is beyond flash range. Adjust exposure compensation. Raise the ISO sensitivity. Subject is backlit. Select the Backlight scene mode, or set the flash mode to ⑤ (fill flash).	6, 29 22 29 33 56 29, 41
Images are too bright (overexposed).	Adjust exposure compensation.	33

Problem	Cause/Solution	
Unexpected results when flash set to \$ (auto with red-eye reduction).	When taking pictures with \$\circ\ (auto with redeye reduction), or when taking pictures with Night portrait (either in easy auto mode or the Night portrait scene mode) and the fill flash with slow sync and red-eye reduction is used, red-eye reduction may be applied, in rare cases, to areas not affected by red-eye. Use auto mode or any scene mode other than Night portrait , and change the flash mode to any setting other than \$\circ\ (auto with red-eye reduction) and try shooting again.	28, 29, 37

Playback

Problem	Cause/Solution	Щ
File cannot be played back.	File was overwritten or renamed by computer or other make of camera. Only movies recorded with COOLPIX L105 can be played back.	- 79
Cannot zoom in on images.	Playback zoom cannot be used with movies, small pictures, or images that have been cropped to 320 × 240 or smaller.	-
Cannot use D-Lighting, crop, or small picture options.	These options cannot be used with movies. Images taken at an Image mode setting of \$\mathbb{3968x2232}\$ or \$\mathbb{1920x1080}\$ cannot be edited.	79 51
	Select image that supports D-Lighting, crop, or small picture. Camera is unable to edit images taken with other cameras.	69 69
Images not displayed on television.	Select the correct Video mode (Setup menu > TV settings). Memory card contains no images. Replace memory card. Remove memory card to play back images from internal memory.	108 18
Nikon Transfer 2 does not start when camera is connected.	 Camera is off. Battery exhausted. USB cable is not correctly connected. Camera is not recognized by the computer. Confirm system requirements. Computer is not set to launch Nikon Transfer 2 automatically. For more information about Nikon Transfer 2, refer to help information contained in Nikon Transfer 2. 	20 20 82 - 81

Troubleshooting

Problem	Cause/Solution	
Images to be printed are not displayed.	Memory card contains no images. Replace memory card. Remove memory card to print images from internal memory.	18
Cannot select paper size with camera.	Even when using a PictBridge compatible printer, paper size cannot be selected from the camera in the following situations. Use the printer to select paper size. The printer does not support the paper sizes used by the camera. The printer automatically selects the paper size.	88, 89

Specifications

Nikon COOLPIX L105 Digital Camera

Type		Compact digital camera		
Effective pixels		12.1 million		
Image sensor		1/2.3-in. type CCD; 12.39 million total pixels		
Lens		15× optical zoom, NIKKOR lens		
Focal length		5.0-75.0mm (angle of view equivalent to that of 28-420 mm lens in 35mm [135] format)		
f/-nun	mber	f/3.5-5.4		
Const	ruction	12 elements in 8 groups		
Digital zoom		Up to 4x (angle of view equivalent to that of approx. 1680 mm lens in 35mm [135] format		
Vibration reduction		Combination of image-sensor shift and electronic VR (for still pictures) Electronic VR (movies)		
Autofoci	us (AF)	Contrast-detect AF		
Focus lens)	range (from	Approx. 50 cm (1 ft 8 in.) to ∞ (W); approx. 1.5 m (5 ft) to ∞ (T) Macro mode: 1 cm (0.4 in.) (middle zoom position) to ∞		
Focus-area selection		Center, face detection		
Monitor		7.5 cm (3-in.), approx. 230k-dot, TFT LCD with 5-level brightness adjustment		
	e coverage ting mode)	Approx. 97% horizontal and 97% vertical (Compared to actual picture)		
	e coverage back mode)	Approx. 100% horizontal and 100% vertical (Compared to actual picture)		
Storage				
Media	1	Internal memory (Approx. 102 MB), Secure Digital (SD) memory cards		
File sy	rstem .	DCF, Exif 2.2, and DPOF compliant		
File fo	ormats	Still pictures: JPEG Movies: MOV (Video: MPEG-4 AVC/H.264, Audio: AAC, monaural)		
Image size (pixels)		12M (High) [4000×3000★] 12M [4000×3000] 8M [3264×2448] 5M [2592×1944] 3M [2048×1536] PC [1024×768] VGA [640×480] 16:9 [3968×2232] 16:9 [1920×1080]		
ISO sensitivity (Standard output sensitivity)		ISO 80, 100, 200, 400, 800, 1600, 3200, 6400, Auto (ISO 80-800), Sport continuous mode (ISO 640-3200)		

Exposure	
Metering	256-segment matrix, center-weighted (when using up to $2\times$ digital zoom), spot (digital zoom $2\times$ or more)
Exposure control	Programmed auto exposure with motion detection and exposure compensation (-2.0 to +2.0 EV in steps of 1/3 EV)
Shutter	Mechanical and charge-coupled electronic shutter
Speed	1/1000 - 2 s, 1/8000 - 1/15 s (Sport continuous mode)
Aperture	Electronically-controlled ND filter (-2 AV) selection
Range	2 steps (f/3.5 and f/7 [W])
Self-timer	Approx. 10 seconds
Built-in flash	
Range (approx.)	[W]: 0.5 to 5.5 m (1 ft 8 in. to 18 ft)
(ISO sensitivity: Auto)	[T]: 1.5 to 3.5 m (5 ft to 11 ft)
Flash control	TTL auto flash with monitor preflashes
Interface	Hi-Speed USB
Data transfer protocol	MTP, PTP
Video output	Can be selected from NTSC and PAL
I/O terminal	Audio video output/digital I/O (USB), DC input connector
Supported languages	Arabic, Chinese (Simplified and Traditional), Czech, Danish, Dutch, English, Finnish, French, Greek, German, Hungarian, Indonesian, Italian, Japanese, Korean, Polish, Portuguese, Norwegian, Russian, Spanish, Swedish, Thai, Turkish
Power sources	 Four LR6/L40 (AA-size) alkaline batteries Four FR6/L91 (AA-size) lithium batteries Four EN-MH2 rechargeable Ni-MH batteries (available separately) AC Adapter EH-67 (available separately)
Battery life	Still pictures*: • Approx. 320 shots when using alkaline batteries • Approx. 950 shots when using lithium batteries • Approx. 540 shots when using EN-MH2 batteries Movies: • Approx. 2 h 55 min when using alkaline batteries (HD 720p) • Approx. 7 h 40 min when using lithium batteries (HD 720p) • Approx. 4 h 20 min when using EN-MH2 batteries (HD 720p)
Tripod socket	1/4 (ISO 1222)
Dimensions (W \times H \times D)	Approx. $108.9 \times 74.3 \times 78.1$ mm (Approx. $4.3 \times 3.0 \times 3.1$ in.) (excluding projections)
Weight	Approx. 432 g (15.3 oz) (including batteries and SD memory card)

0	perating environment	
	Operating temperature	0 to 40°C (32 to 104°F)
	Humidity	Less than 85% (no condensation)

- Unless otherwise stated, all figures are basically for a camera with fully-charged LR6/L40
 (AA-size) alkaline batteries operated at an ambient temperature of 25 °C (77 °F). Data for
 lithium batteries apply when using four commercially available FR6/L91 (AA-size)
 Energizer(R) Ultimate Lithium batteries.
- * Based on Camera and Imaging Products Association (CIPA) standards for measuring the life of camera batteries. Measured at 23 (±2) °C (69 to 77°F); zoom adjusted with each shot, flash fired with every other shot, image mode set to № 4000×3000. Battery life may vary depending on shooting interval and length of time menus and images are displayed. Supplied batteries are for trial use only.



Supported Standards

- **DCF**: Design Rule for Camera File System is a standard widely used in the digital camera industry to ensure compatibility among different makes of camera.
- **DPOF**: Digital Print Order Format is an industry-wide standard that allows images to be printed from print orders saved on the memory card.
- Exif version 2.2: This camera supports Exif (Exchangeable Image File Format for Digital Still Cameras) version 2.2, a standard that allows information saved with photographs to be used for optimal color reproduction when images are output from Exif-compliant printers.
- **PictBridge**: A standard developed cooperatively by the digital camera and printer industries, allowing photographs to be output directly to a printer without connecting the camera to a computer.

Index

Symbols

(apply selection) button 5, 11

• (movie-record) button 5, 10

Playback) button 5, 10

(shooting mode) button 5, 10

Auto mode 48

Toelete button 5, 26, 27, 79

陷 D-Lighting 70

Easy auto mode 20, 28

Exposure compensation 33

Flash mode 30

Macro mode 49

▶ Playback mode 26

Scene mode 35

Self-timer 32

Smart portrait mode 44

🕏 Sport continuous mode 46

AE/AF-L 43

W button 4, 23, 59, 60, 61, 62

button 4, 23, 59, 60, 61, 62 T button 4, 13, 23, 59, 60, 61, 62

Q button 4, 23, 59, 60, 61, 62

2 button 4, 13

MENU button 5, 12

<u>A</u>

AC adapter 15, 120

Alkaline batteries 14, 15

Aperture 24

Audio/video cable 80

Audio-in/Video-in jack 80

Auto flash 29

Auto off 15, 106

Autofocus 24, 49, 78

Autofocus mode 78

В

Backlight 2 41

Batteries 14, 98

Battery level 20

Battery type 15, 112

Battery-chamber 5

Battery-chamber/memory card slot cover

5, 14, 18

Beach/snow 📆 38

Best Shot Selector 55 Black-and-white 57

Blink warning 109

Brightness 100

brightness

BSS 55

Built-in flash 4, 29

Built-in microphone 4

Button sound 105

C

Calendar display 61

Close-up 🗱 39

Cloudy 53

Color options 57

Compression ratio 51

Computer 81

Continuous 55

Copy 114

Copy 🖬 41

Crop 72

Cyanotype 57

<u>D</u>

Date 16, 97

Date imprint 102

Daylight 53

Daylight saving time 16, 98

DC input connector 4

DC input connector cover 4

Delete 26, 27, 67, 79

Digital zoom 23

Direct print 86

D-Lighting 69, 70

DPOF 134

DPOF printing 91

DSCN 121

Dusk/dawn 📸 38

Ε J JPG 121 Easy auto mode 20, 28 EH-67 15, 120 EN-MH2 14, 112, 117, 120 Landscape 4 36 Exposure compensation 33 Language 108 Extension 121 Lens 4, 131 Eyelet for camera strap 4 Lithium batteries 14 F M File names 121 Macro mode 49 Fill flash 29 Memory capacity 20 Firmware version 115 Memory card 18, 120 Flash 29, 30 Memory card slot 5, 18 Flash lamp 5, 30 Menus 95 Fluorescent 53 Monitor 5, 8, 118 Focus 13, 24, 78 Monitor settings 100 Focus lock 25, 48 Motion detection 104 Folder names 121 MOV 121 Food ***!** 40 Movie menu 73, 75 Format 19, 107 Movie playback 79 Format memory card 19, 107 Movie settings 77 Formatting internal memory 107 Multi selector 5, 11 **ESCN 121** Multi-shot 16 55 Full-frame playback mode 27 Museum **1** 40 Full-time AF 78 Ν Н Nickel metal hydride batteries 14 Halfway 13 Night landscape 439 Help 13 Night Portrait P 37 Nikon Transfer 2 81, 82, 85 Identifier 121 Number of Exposures Remaining 20, 52 Image mode 21, 35, 51 0 Image review 100 Off 29 Image size 51 Optical zoom 23 Incandescent 53 Optional Accessories 120 Indicator lamp 5 Internal memory 18 Ρ ISO sensitivity 30, 46, 56 Panorama assist # 41, 42

Panorama Maker 5 81, 85 Paper size 88, 89 Party/indoor 37 Photo info 100 PictBridge 86, 134 Playback 26, 27, 59, 60, 62, 79 Playback button 5, 10 Playback menu 63 Playback zoom 62 Portrait **2** 36 Power 14, 16, 20 Power switch 4, 14, 20 Power-on lamp 4, 14, 20 Preset manual 54 Print 64, 88, 89 Print set 64 Print Set (Date) 65 Printer 86 Protect 112 R Recording movies button 5, 10 Red-eye reduction 29, 31 Replay mode 26 Reset all 110 Rotate image 113 **RSCN 121** S Scene mode 35, 36 Self-timer 32 Self-timer lamp 4, 32 Sepia 57 Setup menu 92 Shooting 20, 22, 24 Shooting mode button 5, 10 Shutter sound 105 Shutter speed 24 Shutter-release button 4, 24 Single 55 Single AF 78 Sleep Mode 106

Slide show 66

Slow Sync 29
Small picture 71
Smart portrait 44
Sound settings 105
Speaker 4
Sport continuous mode 46
SSCN 121
Standard color 57
Strap 7
Sunset

38

Τ

Tabs 12 Thumbnail playback 60 Time zone 16, 97, 99 Tripod socket 5 TV 80 TV settings 108

U

USB cable 82 USB connector and audio/video output 4, 80, 87 USB/audio/video output connector 81, 82

<u>V</u>

Vibration reduction 103 ViewNX 2 81, 85 Vivid color 57 Volume 79

W

Welcome screen 96 White balance 53

Ζ

Zoom control 4, 23, 79



No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

