

Nokia C6-00 User Guide

Issue 1

Contents**Safety 5**

About your device	5
Office applications	6
Network services	6
Shared memory	6
Magnets and magnetic fields	7

Find help 8

Support	8
In-device help	8
Do more with your device	8
Update device software	8
Settings	9
Access codes	9
Remote lock	10
Prolong battery life	10
Increase available memory	11

Get started 12

Keys and parts (front)	12
Keys and parts (top)	12
Keys and parts (sides)	12
Keys and parts (bottom)	12
Keys and parts (back)	12
Insert the SIM card and battery	13
Memory card	13
Antenna locations	14
Switch the device on or off	15
Charge the battery	15
Touch screen actions	15
Write text	17
Lock the keys and touch screen	20
Headset	20
Attach a wrist strap	20
Nokia Switch	20

Your device 22

Home screen	22
Display indicators	23

Shortcuts	25
Search	25
Volume and loudspeaker control	26
Offline profile	26
Fast downloading	26
Ovi (network service)	27
Ovi Contacts	27

Make calls 33

Touch screen during calls	33
Make a voice call	33
During a call	33
Answer or reject a call	34
Contact search	34
Speed dial a phone number	34
Voice dialling	35
Call waiting	35
Make a conference call	35
Voice and video mailboxes	36
Make a video call	36
During a video call	37
Answer or reject a video call	37
Video sharing	38
Internet calls	40
Log	41

Contacts (phonebook) 42

Save and edit names and numbers	42
Contacts toolbar	42
Manage names and numbers	43
Assign default numbers and addresses	43
Contact cards	43
Set contacts as favourites	44
Ringing tones, images, and call text for contacts	44
Copy contacts	44
SIM services	44
Contact groups	45

E-mail 46

About e-mail	46
--------------	----

Add a mailbox	46	Positioning (GPS)	68
Read e-mail	47	About GPS	68
Send an e-mail	47	About assisted GPS (A-GPS)	69
Mail for Exchange	48	Hold your device correctly	69
Messaging	49	Tips on creating a GPS connection	69
Messaging main view	49	Position requests	70
Write and send messages	49	Landmarks	70
Messaging inbox	50	GPS data	71
View messages on a SIM card	51	Positioning settings	71
Cell broadcast messages	51	Maps	72
Service commands	51	Maps overview	72
Messaging settings	51	View your location and the map	73
Nokia Messaging	53	Navigation view	73
About Nokia Messaging	53	Map view	73
Connectivity	54	Plan a route	74
Data connections and access points	54	Get traffic and safety information	74
Network settings	54	Drive to your destination	75
Wireless LAN	55	Walk to your destination	75
Access points	56	Share location	76
View your active data connections	58	Save places and routes	76
Synchronisation	59	Send places to your friends	77
Bluetooth connectivity	59	Change the look of the map	77
Transfer data using a USB cable	62	Camera	77
PC connections	62	Image capture	77
Administrative settings	63	Video recording	81
Internet	64	Camera settings	82
Browse the web	64	Photos	83
Browser toolbar	64	About Photos	83
Navigate pages	65	View images and video clips	83
Web feeds and blogs	65	View and edit file details	84
Content search	65	Organise images and video clips	84
Bookmarks	66	Photos toolbar	85
Empty the cache	66	Albums	85
End the connection	66	Tags	85
Connection security	66	Slide show	86
Web settings	67	Edit images	86
		Edit videos	87
		Image print	87
		Share online	87

Music	88
Play a song or podcast	88
Playlists	89
Podcasts	89
Transfer music from a computer	89
Ovi Music	90
Nokia Podcasting	90
FM radio	93

Videos	94
Download and play a video clip	94
Video feeds	95
My videos	95
Transfer video clips from your PC	96
Videos & TV settings	96

Personalise your device	97
Change the look of your device	97
Profiles	97
3-D tones	97
Modify the home screen	97
Modify the main menu	98

Applications	98
Calendar	98
Clock	99
RealPlayer	100
Recorder	101
Notes	101
Office	102

Settings	106
Phone settings	106
Application manager	111
Calling settings	113

Troubleshooting	115
------------------------	------------

Green tips	117
Save energy	117
Recycle	117
Save paper	117

Learn more	118
------------	-----

Product and safety information	118
---------------------------------------	------------

Index	124
--------------	------------

Safety

Read these simple guidelines. Not following them may be dangerous or illegal. Read the complete user guide for further information.

SWITCH ON SAFELY



Do not switch the device on when wireless phone use is prohibited or when it may cause interference or danger.

INTERFERENCE



All wireless devices may be susceptible to interference, which could affect performance.

SWITCH OFF IN RESTRICTED AREAS



Follow any restrictions. Switch the device off in aircraft, near medical equipment, fuel, chemicals, or blasting areas.

ROAD SAFETY COMES FIRST



Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

QUALIFIED SERVICE



Only qualified personnel may install or repair this product.

ACCESSORIES AND BATTERIES



Use only approved accessories and batteries. Do not connect incompatible products.

WATER-RESISTANCE



Your device is not water-resistant. Keep it dry.

About your device

The wireless device described in this guide is approved for use on the (E)GSM 850, 900, 1800, 1900, and UMTS 900, 1900, 2100 networks. Contact your service provider for more information about networks.

When using the features in this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights.

Copyright protection may prevent some images, music, and other content from being copied, modified, or transferred.

Your device supports several methods of connectivity. Like computers, your device may be exposed to viruses and other harmful content. Exercise caution with messages, connectivity requests, browsing, and downloads. Only install and use services and other software from trustworthy sources that offer adequate security and protection against harmful software, such as applications that are Symbian Signed or have passed the Java Verified™ testing. Consider installing antivirus and other security software on your device and any connected computer.

Important: Your device can only support one antivirus application. Having more than one application with antivirus functionality could affect performance and operation or cause the device to stop functioning.

Your device may have preinstalled bookmarks and links for third-party

internet sites. You may also access other third-party sites through your device. Third-party sites are not affiliated with Nokia, and Nokia does not endorse or assume liability for them. If you choose to access such sites, you should take precautions for security or content.

Warning:

To use any features in this device, other than the alarm clock, the device must be switched on. Do not switch the device on when wireless device use may cause interference or danger.

The office applications support common features of Microsoft Word, PowerPoint, and Excel (Microsoft Office 2000, XP, and 2003). Not all file formats can be viewed or modified.

Remember to make back-up copies or keep a written record of all important information stored in your device.

When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.

The images in this guide may differ from your device display.

Office applications

The office applications support common features of Microsoft Word, PowerPoint, and Excel (Microsoft Office 2000, XP, and 2003). Not all file formats are supported.

Network services

To use the device you must have service from a wireless service provider. Some features are not available on all networks; other features may require that you make

specific arrangements with your service provider to use them. Network services involve transmission of data. Check with your service provider for details about fees in your home network and when roaming on other networks. Your service provider can explain what charges will apply. Some networks may have limitations that affect how you can use some features of this device requiring network support such as support for specific technologies like WAP 2.0 protocols (HTTP and SSL) that run on TCP/IP protocols and language-dependent characters.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, these features will not appear on your device menu. Your device may also have customized items such as menu names, menu order, and icons.

Shared memory

The following features in this device may share memory: multimedia messaging (MMS), e-mail application, instant messaging. Use of one or more of these features may reduce the memory available for the remaining features. If your device displays a message that the memory is full, delete some of the information stored in the shared memory.

During extended operation such as an active video call and high speed data connection, the device may feel warm. In most cases, this condition is normal. If you suspect the device is not working properly, take it to the nearest authorised service facility.

Magnets and magnetic fields

Keep your device away from magnets or magnetic fields.

Find help

Support

When you want to learn more about how to use your product or you are unsure how your device should function, see the support pages at www.nokia.com/support or your local Nokia website, www.nokia.mobi/support (with a mobile device), the Help application in the device, or the user guide.

If this does not resolve your issue, do one of the following:

- Restart the device: switch off the device, and remove the battery. After about a minute, replace the battery, and switch on the device.
- Restore the original factory settings as explained in the user guide. Your documents and files will be deleted in the reset, so back up your data first.
- Update your device software regularly for optimum performance and possible new features, as explained in the user guide.

If your issue remains unsolved, contact Nokia for repair options. See www.nokia.com/repair. Before sending your device for repair, always back up the data in your device.

In-device help

Your device contains instructions to help to use the applications in your device.

To open help texts from the main menu, select **Menu > Applications > Help** and the application for which you want to read instructions.

When an application is open, to access the help text for the current view, select **Options > Help**.

When you are reading the instructions, to change the size of the help text, select **Options > Decrease font size** or **Increase font size**.

You may find links to related topics at the end of the help text.

If you select an underlined word, a short explanation is displayed.

Help texts use the following indicators:



Link to a related help topic.



Link to the application being discussed.

When you are reading the instructions, to switch between help texts and the application that is open in the background, select **Options > Show open apps**, and the desired application.

Do more with your device

There are various applications provided by Nokia and third party software developers, that help you do more with your device. To find and download applications, visit the Ovi Store at store.ovi.com. These applications are explained in the guides that are available on the product support pages at www.nokia.com/support or your local Nokia website.

Update device software About software updates

Software updates may include new features and enhanced functions that were not available at the time of purchase

of your device. Updating the software may also improve the device performance.

To get a notification when new software is available for your device, register with My Nokia, and subscribe to notifications for text or e-mail messages. For more information, go to www.nokia.com/mynokia.

Warning:

If you install a software update, you cannot use the device, even to make emergency calls, until the installation is completed and the device is restarted. Be sure to back up data before accepting installation of an update.

Downloading software updates may involve the transmission of large amounts of data (network service).

Make sure that the device battery has enough power, or connect the charger before starting the update.

After updating your device software or applications, the instructions related to the updated applications in the user guide or helps may no longer be up to date.

Update software using your PC

Nokia Software Updater is a PC application that enables you to update your device software. To update your device software, you need a compatible PC, broadband internet access, and a compatible USB data cable to connect your device to the PC.

To get more information and to download the Nokia Software Updater application, go to www.nokia.com/softwareupdate.

Settings

Your device normally has MMS, GPRS, streaming, and mobile internet settings automatically configured, based on your network service provider information. You may have settings from your service providers already installed in your device, or you may receive or request the settings from the network service providers as a special message.

You can change the general settings in your device, such as language, standby mode, display, and keypad lock settings.

Access codes

If you forget any of the access codes, contact your service provider.

Personal identification number (PIN) code — This code protects your SIM card against unauthorised use. The PIN code (4 - 8 digits) is usually supplied with the SIM card. After three consecutive incorrect PIN code entries, the code is blocked, and you need the PUK code to unblock it.

UPIN code — This code may be supplied with the USIM card. The USIM card is an enhanced version of the SIM card and is supported by 3G mobile phones.

PIN2 code — This code (4 - 8 digits) is supplied with some SIM cards, and is required to access some functions in your device.

Lock code (also known as security code) — The lock code helps you to protect your device against unauthorised use. The preset code is 12345. You can create and change the code, and set the device to request the code. Keep the new code secret and in a safe place separate from your device. If you forget the code and your device is locked, your device will

require service. Additional charges may apply, and all the personal data in your device may be deleted. For more information, contact a Nokia Care point or your device dealer.

Personal Unblocking Key (PUK) code and PUK2 code — These codes (8 digits) are required to change a blocked PIN code or PIN2 code, respectively. If the codes are not supplied with the SIM card, contact the network service provider whose SIM card is in your device.

UPUK code — This code (8 digits) is required to change a blocked UPIN code. If the code is not supplied with the USIM card, contact the network service provider whose USIM card is in your device.

International Mobile Equipment Identity (IMEI) number — This number (15 or 17 digits) is used to identify valid devices on the GSM network. Devices that are, for example, stolen, can be blocked from accessing the network. The IMEI number for your device can be found under the battery.

Remote lock

You can lock your device remotely using a predefined text message. You can also lock the memory card remotely.

Enable remote locking

- 1 Select **Menu > Settings and Phone > Phone mgmt. > Security settings > Phone and SIM card > Remote phone locking > Enabled.**
- 2 Enter the text message content (5-20 characters), verify it, and enter the lock code.

Lock your device remotely

Write the predefined text message, and send it to your device. To unlock your device, you need the lock code.

Prolong battery life

Many features in your device increase the demand on battery power and reduce the battery lifetime. To save battery power, note the following:

- Features that use Bluetooth technology, or allowing such features to run in the background while using other features, increase the demand on battery power. Deactivate Bluetooth connectivity when you do not need it.
- Features that use wireless LAN (WLAN), or allowing such features to run in the background while using other features, increase the demand on battery power. WLAN on your Nokia device deactivates when you are not trying to connect, not connected to an access point, or not scanning for available networks. To further reduce battery consumption, you can specify that your device does not scan, or scans less often, for available networks in the background.
- If you have selected **Packet data connection > When available** in the connection settings, and there is no packet data coverage (GPRS), the device periodically tries to establish a packet data connection. To prolong the operating time of your device, select **Packet data connection > When needed.**
- The Maps application downloads new map information when you scroll to

new areas on the map, which increases the demand on battery power. You can prevent the automatic download of new maps.

- If the signal strength of the cellular network varies much in your area, your device must scan for the available network repeatedly. This increases the demand on battery power.

If the network mode is set to dual mode in the network settings, the device searches for the 3G network. You can set the device to use only the GSM network. To use only the GSM network, select **Menu > Settings and Connectivity > Network > Network mode > GSM**.

- The backlight of the display increases the demand on battery power. In the display settings, you can change the length of the time-out period after which the backlight is switched off. Select **Menu > Settings and Phone > Display > Light time-out**. To adjust the light sensor that observes lighting conditions and adjusts the display brightness, in the display settings, select **Light sensor**.
- Leaving applications running in the background may increase the demand on battery power. To close the applications you are not using, if they are not responding, select **Options > Show open apps.**, and go to the application using the menu key. Press and hold the menu key to open the application, and select **Options > Exit**.

Increase available memory

Do you need more available device memory for new applications and content?

View how much space is available for different data types

Select **Menu > Applications > Office > File mgr.**

Many features of the device use memory to store data. The device notifies you if the memory in different memory locations is low.

Increase available memory


Transfer data to a compatible memory card (if available) or to a compatible computer.

To remove data you no longer need, use File manager or open the respective application. You can remove the following:


- Messages in the folders in Messaging and retrieved e-mail messages in the mailbox
- Saved web pages
- Contact information
- Calendar notes
- Applications shown in Application manager that you do not need
- Installation files (.sis or .sisx) of applications you have installed. Transfer the installation files to a compatible computer.
- Images and video clips in Photos. Back up the files to a compatible computer.

Get started

Keys and parts (front)




- 1 Proximity sensor
- 2 Earpiece
- 3 Touch screen
- 4 Call key
- 5 Menu key
- 6 Light sensor
- 7 Secondary camera
- 8 End/Power key




Do not cover the area above the touch screen, for example, with protective film or tape.

Keys and parts (top)



- 1 Nokia AV connector (3.5 mm) for compatible headsets and headphones
- 2 USB connector

Keys and parts (sides)




- 1 Memory card slot cover
- 2 Volume up/Zoom in key
- 3 Volume down/Zoom out key
- 4 Lock switch
- 5 Capture key

Keys and parts (bottom)



- 1 Charger connector
- 2 Microphone
- 3 Wrist strap eyelet

Keys and parts (back)



- 1 Camera flash
- 2 Camera lens
- 3 Loudspeaker


Note: The surface of this device does not contain nickel in the platings. The surface of this device contains stainless steel.

Insert the SIM card and battery


Follow the instructions carefully, to avoid damaging the back cover.

Always switch the device off and disconnect the charger before removing the battery.


- 1 Unlock the back cover release latch, and lift the back cover.




- 2 If the battery is inserted, lift the battery in the direction of the arrow to remove it.




- 3 Insert the SIM card. Ensure the contact area on the card is facing the connectors on the device and that the bevelled corner is facing the top of the device.



- 4 Align the contacts of the battery with the corresponding connectors on the battery compartment, and insert the battery in the direction of the arrow.



- 5 To replace the back cover, direct the top locking catches toward their slots, and press down until the cover locks into place.



Memory card




Use only compatible microSD cards approved by Nokia for use with this device. Nokia uses approved industry standards for memory cards, but some brands may not be fully compatible with

this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.

Insert the memory card

A memory card may be already inserted in the device. If not, do the following:

- 1 Open the memory card slot cover.
- 2 Insert a compatible memory card in the slot. Ensure that the contact area on the card is facing down and towards the slot.



- 3 Push the card in. You hear a click when the card locks into place.
- 4 Close the memory card slot cover.

Remove the memory card


Important: Do not remove the memory card during an operation when the card is being accessed. Doing so may damage the memory card and the device, and corrupt data stored on the card.

- 1 Before you remove the card, press the power key, and select **Remove memory card**. All applications are closed.

- 2 When **Removing memory card will close all open applications. Remove anyway?** is displayed, select **Yes**.
- 3 When **Remove memory card and press 'OK'** is displayed, open the memory card slot cover.
- 4 To release the memory card from the slot, push it in slightly.
- 5 Pull out the memory card. If the device is switched on, select **OK**.
- 6 Close the memory card slot cover.

Antenna locations


Your device may have internal and external antennas. Avoid touching the antenna area unnecessarily while the antenna is transmitting or receiving. Contact with antennas affects the communication quality and may cause a higher power level during operation and may reduce the battery life.



Switch the device on or off

Switch the device on

- 1 Press and hold the power key.




- 2 If prompted, enter a PIN code (provided by your network service provider, for example, 1234) or lock code, and select OK. The preset lock code is 12345. If you forget the code and your device is locked, your device will require service and additional charges may apply. For more information, contact a Nokia Care point or your device dealer.

Switch the device off

Press and hold the power key.

Charge the battery

Your battery has been partially charged at the factory. If the device indicates a low charge, do the following:



- 1 Connect the charger to a wall outlet.

- 2 Connect the charger to the device. When the battery is charging, the charging indicator light around the charger connector is lit.
- 3 When the device indicates a full charge, disconnect the charger from the device, then from the wall outlet.

You do not need to charge the battery for a specific length of time, and you can use the device while it is charging. If the battery is completely discharged, it may take several minutes before the charging indicator appears on the display or before any calls can be made.

Tip: Disconnect the charger from the wall outlet when the charger is not in use. A charger that is connected to the outlet consumes power even when it is not connected to the device.

During extended operation such as an active video call and high speed data connection, the device may feel warm. In most cases, this condition is normal. If you suspect the device is not working properly, take it to the nearest authorised service facility.

Touch screen actions

Use the touch screen with your finger or with a stylus (if available).

Important: Use only a stylus approved by Nokia for use with this device. Using any other stylus may invalidate any warranty applying to the device and may damage the touch screen. Avoid scratching the touch screen. Never use an actual pen or pencil or other sharp objects to write on the touch screen.

Tap and double-tap

To open an application or other element on the touch screen, you normally tap it with your finger. However, to open the following items, you must tap them twice.

- List items in an application, such as the Drafts folder in the Messaging application.
- Files in a file list, for example, an image in the Captured folder in the Photos application.

Tip: When you open a list view, the first item is already highlighted. To open the highlighted item, tap it once.

If you tap a file or similar item once, it is not opened, it becomes highlighted. To see the options available for the item, select **Options** or, if available, select an icon from a toolbar.


Select

In this user documentation, to open applications or items by tapping them once or twice, you "select" them.

Example: To select **Options** > **Help**, tap **Options**, and then tap **Help**.

Drag


To drag, place your finger on the screen, and slide it across the screen.



Example: To scroll up or down on a web page, drag the page with your finger.


Swipe

To swipe, slide your finger quickly left or right on the screen.



Flick

To flick, place your finger on the screen, slide it quickly across the screen, then quickly lift your finger. The content of the screen will continue scrolling with the speed and direction it had at the moment of release. To select an item from a scrolling list and to stop the movement, tap the item.



Scroll

To scroll up or down in lists that have a scroll bar, drag the slider of the scroll bar.

In some list views, you can place your finger on a list item and drag up or down.

Tip: To view a brief description of an icon, place your finger on the icon. Descriptions are not available for all icons.


Touch screen backlight

To turn the screen backlight on, unlock the screen and keys, if necessary, and press the menu key.

Write text

You can enter text in different modes. The full keyboard works as a traditional keyboard, and the on-screen alphanumeric keypad mode allow you to tap characters. The handwriting recognition modes allow you to write characters directly on the screen.


To activate text input mode, tap any text input field.

In the text input view, to switch between the available text input modes, tap  and select the desired input mode.


The input methods and languages supported by the handwriting recognition vary by region.

Keyboard input

Keyboard



Your device has a full keyboard. To open the keyboard, slide the touch screen up. In all applications, the screen rotates automatically from portrait to landscape when you open the keyboard.



- 1 **Function key.** To insert special characters printed at the top of keys, press the function key, and then press the desired key. To enter several special characters in a row, press the function key twice quickly. To return to normal mode, press the function key.
- 2 **Shift key.** To switch between upper and lower case modes, press the shift key twice. To enter a single upper case character in lower case mode, or vice versa, press the shift key, and then the desired alphabet key.
- 3 **Sym key.** To insert special characters not shown on the keyboard, press the sym key, and select the desired character.
- 4 **Ctrl key.** Some shortcuts require the ctrl key.
- 5 **Space key**
- 6 **Shift key**
- 7 **Enter key**
- 8 **Navi™ key (scroll key).** Press the scroll key to make a selection. Press the edges of the scroll key to scroll left, right, up, or down on the display. Press and hold the edge of the scroll key to accelerate scrolling.
- 9 **Backspace key.** To delete a character, press the backspace key. To delete several characters, press and hold the backspace key.

Insert characters not shown on the keyboard

It is possible to insert variations of characters, for example, characters with accents. To insert á, press and hold the sym key, and then press **A** repeatedly, until the desired character is displayed. The order and availability of letters

depends on the selected writing language.


Touch input Handwriting


The input methods and languages supported by the handwriting recognition vary by region and may not be available for all languages.


To activate handwriting mode, select  > **Handwriting**.

Write legible, upright characters on the text input area, and leave a space between each character.

To teach the device your handwriting style, select  > **Handwriting training**.

To enter letters and numbers (default mode), write words as you would normally. To select number mode, select . To enter non-Latin characters, select the corresponding icon, if available.



To enter special characters, write them as you would normally, or select  and the desired character.

To delete characters or move the cursor back, swipe backwards (see Figure 1).

To insert a space, swipe forwards (see Figure 2).



Touch input settings

Select **Menu > Settings and Phone > Touch input**.

To configure text input settings for the touch screen, select from the following:

Handwriting training — Open the handwriting training application. Train the device to recognise your handwriting better. This option is not available in all languages.

Writing language — Define which language-specific characters in your handwriting are recognised and how your on-screen keyboard is laid out.

Writing speed — Adjust the speed at which handwriting is recognised.

Guiding line — Show or hide the guiding line in the writing area. The guiding line helps you write in a straight line, and it also helps the device recognise your writing. This option may not be available in all languages.


Pen trail width — Change the thickness of the text.

Writing colour — Change the colour of the text.

Adaptive search — Filter the contents of a list in an application according to the characters entered in the search field.

Icons and functions

Use the on-screen keypad (**Alphanumeric keypad**) to enter characters like you would with a traditional phone keypad with numbers on the keys. For an explanation of each icon and its function, see the following figure.



- 1 Close - Closes on-screen keypad (**Alphanumeric keypad**).
- 2 Input menu - Opens the touch input menu, which includes commands such as **Activate predictive text** and **Writing language**.
- 3 Text input indicator - Opens a pop-up window, in which you can turn predictive text input modes on or off, change the character case, and switch between letter and number mode.
- 4 Input mode - Opens a pop-up window, in which you can select from the available input modes. When you tap an item, the current input method view closes, and the selected one opens.
- 5 Arrow keys - Moves the cursor left or right.
- 6 Backspace - Deletes the previously entered character.
- 7 Number keys - Enters the desired numbers or characters according to the current case and input mode.
- 8 Star - Opens a special characters table.

- 9 Shift - Changes the character case, turns predictive text input modes on or off, and switches between the alphabet and number modes.

Lock the keys and touch screen

To lock or unlock the touch screen and the keys, slide the lock switch on the side of the device.

When the touch screen and keys are locked, the touch screen is switched off and the keys are inactive.

To change settings for automatic screen and key locking, select **Menu > Settings and Phone > Phone mgmt. > Auto. keyguard.**

Headset

You can connect a compatible headset or compatible headphones to your device. You may need to select the cable mode.




Warning:

When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety.

Do not connect products that create an output signal as this may cause damage to the device. Do not connect any voltage source to the Nokia AV Connector.

When connecting any external device or any headset, other than those approved by Nokia for use with this device, to the Nokia AV Connector, pay special attention to volume levels.

Attach a wrist strap



Thread the wrist strap, and tighten it.

Nokia Switch Transfer content

You can use the Switch application to copy content such as phone numbers, addresses, calendar items, and images from your previous Nokia device to your device.

The type of content that can be transferred depends on the model of the device from which you want to transfer content. If that device supports synchronisation, you can also synchronise data between the devices. Your device notifies you if the other device is not compatible.

If the other device cannot be switched on without a SIM card, you can insert your SIM card in it. When your device is switched on without a SIM card, the Offline profile is

automatically activated, and transfer can be done.

Transfer content for the first time

- 1 To retrieve data from the other device for the first time, on your device, select **Menu > Applications > Tools > Phone setup > Phone switch**.
- 2 Select the connection type you want to use to transfer the data. Both devices must support the selected connection type.
- 3 If you select Bluetooth connectivity as the connection type, connect the two devices. To have your device search for devices with Bluetooth connectivity, select **Continue**. Select the device from which you want to transfer content. You are asked to enter a code on your device. Enter a code (1-16 digits), and select **OK**. Enter the same code on the other device, and select **OK**. The devices are now paired.

Some earlier Nokia devices may not have the Switch application. In this case, the Switch application is sent to the other device as a message. To install the Switch application on the other device, open the message, and follow the instructions on the display.

- 4 On your device, select the content you want to transfer from the other device.

When the transfer has started, you can cancel it and continue later.

Content is transferred from the memory of the other device to the corresponding location in your device. The transfer time depends on the amount of data to be transferred.

Synchronise, retrieve, or send content

After the first data transfer, you can start new transfers or create shortcuts to repeat the same type of transfer later.

Select Menu > Applications > Tools > Phone setup > Phone switch.

Select from the following to start a new transfer, depending on the model:



Synchronise content between your device and the other device, if the other device supports synchronisation. The synchronisation is two-way. If an item is deleted in one device, it is deleted in both. You cannot restore deleted items with synchronisation.



Retrieve content from the other device to your device. With retrieval, content is transferred from the other device to your device. You may be asked to keep or delete the original content in the other device, depending on the device model.



Send content from your device to the other device.

If you cannot send an item, depending on the type of the other device, you can add the item to the Nokia folder, or to **C:\Nokia** or **E:\Nokia** in your device. When you select the folder to transfer, the items are synchronised in the corresponding folder in the other device, and vice versa.

After a data transfer, you are asked if you want to save a shortcut with the transfer settings to the main view, so you can repeat the same transfer later.

Edit a shortcut

Select **Options > Shortcut settings**. You can create or change the name of the shortcut, for example.

View the transfer log

Select a shortcut in the main view and **Options > View log**.

If an item to be transferred has been edited in both devices, the device attempts to merge the changes automatically. If this is not possible, there is a transfer conflict.

Solve transfer conflicts

Select **Check one by one**, **Priority to this phone**, or **Priority to other phone**.

Your device

Home screen

About the home screen

In the home screen, you can quickly access your most frequently used applications, control applications, such as the music player, view your favourite contacts, and view at a glance if you have missed calls or new messages.




Interactive home screen elements

To open the clock application, tap the clock (1).

To open the calendar or change profiles in the home screen, tap the date or the profile name (2).

To view or modify connectivity settings (⇌), to see the available wireless LANs if WLAN scanning is enabled, or to view the missed events, tap the top right corner (3).

To open the dialler to make a phone call, select  (4).

To hide and show content, swipe the home screen with your finger.

Add items to the home screen

Select and hold an empty area in the home screen, and from the pop-up menu, select **Add content** and the item.

Using widgets may involve the transmission of large amounts of data (network service).

Move an item in the home screen

Select **Options** > **Edit content** and the desired item, and drag and drop it to a new location.

Remove an item from the home screen

Select and hold the item to remove, and from the pop-up menu, select **Remove**.

Music player in the home screen

You can use Music player from the home screen.

Activate Music player controls

In the home screen, select **Options** > **Edit content** > **Options** > **Add content** > **Music player**.

Open Music player

Select **Go to Music** and the items you want to listen to.


Music player control keys, and, if available, the title of the song, artist, and album art are displayed when a song is played.

Favourite contacts in the home screen

You can add several contacts directly to the home screen, and quickly make calls or send messages to the contacts, view the contacts' web feeds, or access the contact information and settings.

Add your favourite contacts to the home screen

- 1 In the home screen, select **Options** > **Edit content** > **Options** > **Add content** > **Favourite contacts**.

A row of  icons is displayed in the home screen.

- 2 Select an icon () and a contact.

Add your Share online feed to the home screen

By adding the Share online widget to your home screen, you can quickly access your Share online feed.





In the home screen, select **Options** > **Edit content** > **Options** > **Add content** > **Share online**.

You need to register to the service before you can receive a feed.


The widget displays thumbnail images from the feed. The latest images are displayed first.



Display indicators

General indicators




	The touch screen and keys are locked.
	The device alerts silently for incoming calls or messages.
	You have set a clock alarm.
	You are using a timed profile.

Call indicators








	Someone has tried to call you.
---	--------------------------------










2	You are using your second phone line (network service).
	You have set your device to divert incoming calls to another number (network service). If you have two phone lines, a number indicates the active line.
	Your device is ready for an internet call.
D	You have an ongoing data call (network service).

Messaging indicators








	You have unread messages. If the indicator is blinking, the SIM card memory for messages may be full.
	You have received new mail.
	You have messages waiting to be sent in the Outbox folder.

Network indicators

	Your device is connected to a GSM network (network service).
3G	Your device is connected to a 3G network (network service).
	You have a GPRS packet data connection (network service).  indicates that the connection is on hold and  that a connection is being established.
	You have an EGPRS packet data connection (network service).  indicates that the connection is on hold and  that a connection is being established.

	You have a 3G packet data connection (network service).  indicates that the connection is suspended and  that a connection is being established.
	You have a high-speed downlink packet access (HSDPA) connection (network service).  indicates that the connection is suspended and  that a connection is being established.
	A WLAN connection is available (network service).  indicates that the connection is encrypted and  that the connection is not encrypted.

Connectivity indicators

	Bluetooth is active.  indicates that your device is sending data. If the indicator is blinking, your device is trying to connect to another device.
	You have connected a USB cable to your device.
	GPS is active.
	The device is synchronising.
	You have connected a compatible headset to the device.
	You have connected a compatible text phone to the device.

Shortcuts

To switch between open applications, press and hold the menu key.

Leaving applications running in the background increases the demand on battery power and reduces the battery life.


To open the browser application, in the dialler, tap and hold **0**.

To change the profile, press the power key, and select a profile.

To call your voice mailbox (network service), in the dialler, tap and hold **1**.

To open a list of last dialled numbers, in the home screen, press the call key.

To use voice commands, in the home screen, press and hold the call key.

When writing, to change the writing language, press  and the sym key.

Search

About Search

Select **Menu > Applications > Search**.

Search enables you to use various internet-based search services to find, for example, websites, and images. The content and availability of the services may vary.

Start a search

Select **Menu > Applications > Search**.

To search the contents of your mobile device, enter search terms in the search field, or browse the content categories.

While you enter the search terms, the results are organised into categories. The most recently accessed results appear at the top of the result list, if they match your search terms.

To search for web pages on the internet, select **Search the Internet** and a search provider, and enter your search terms in the search field. The search provider you selected is set as your default internet search provider.

If a default search provider is already set, select it to start a search, or select **More search services** to use another search provider.

To change the default search provider, select **Options > Settings > Search services**.

To change the country or region setting to find more search providers, select **Options > Settings > Country or region**.

Search settings

Select **Menu > Applications > Search**.

To change the Search application settings, select **Options > Settings** and from the following:

Country or region — Select the country or region you want to search from.

Connection — Select the access point, and allow or deny network connections.

Search services — Select whether service providers and search categories are shown.

General — Enable or disable tooltips, and clear the search history.

Volume and loudspeaker control

Adjust the volume of a phone call or sound clip

Use the volume keys.



The built-in loudspeaker allows you to speak and listen from a short distance without having to hold the device to your ear.

Use the loudspeaker during a call

Select **Loudspeaker**.

Turn off the loudspeaker

Select **Activate handset**.

Warning:

Continuous exposure to high volume may damage your hearing. Listen to music at a moderate level, and do not hold the device near your ear when the loudspeaker is in use.

Offline profile

The offline profile lets you use the device without connecting to the wireless cellular network. When the offline profile is active, you can use your device without a SIM card.

Activate the offline profile

Press the power key briefly, and select **Offline**.

When you activate the offline profile, the connection to the cellular network is closed. All radio frequency signals to and from the device to the cellular network are prevented. If you try to send messages using the cellular network, they are placed in the Outbox folder to be sent later.

Important: In the Offline profile you cannot make or receive any calls, or use other features that require cellular network coverage. Calls may still be possible to the official emergency number programmed into your device. To make calls, you must first activate the phone function by changing profiles. If the device has been locked, enter the lock code.

When you have activated the offline profile, you can still use a wireless LAN (WLAN), for example, to read your e-mail or browse on the internet. You can also use Bluetooth connectivity while in the offline profile. Remember to comply with any applicable safety requirements when establishing and using WLAN or Bluetooth connections.

Fast downloading

High-speed downlink packet access (HSDPA, also called 3.5G, indicated by **3.5G**) is a network service in UMTS networks and provides high-speed data downloads. When HSDPA support in the device is activated and the device is connected to a UMTS network that supports HSDPA, downloading data such as messages, e-mail, and browser pages through the cellular network may be faster. An active HSDPA connection is indicated by ^{3.5G}.


You can activate or deactivate support for HSDPA in packet data settings.

For availability and subscription to data connection services, contact your service provider.

HSDPA only affects the download speed; sending data to the network, such as messages and e-mail, is not affected.

Ovi (network service)


Visit Ovi

 Ovi contains services provided by Nokia. With Ovi, you can create a mail account, share your images and video clips with friends and family, plan trips and view locations on a map, download games, applications, video clips, and tones to your device, and purchase music. The available services may vary by region, and not all languages are supported.

To access Ovi services, go to www.ovi.com, and register your own Nokia account.

For more information on how to use the services, see the support pages of each service.

About Ovi Store

 In Ovi Store, you can download mobile games, applications, videos, images, themes, and ringing tones to your device. Some items are free of charge; others you need to pay for with your credit card or in your phone bill. The availability of payment methods depends on your country of residence and your network service provider. Ovi Store offers content that is compatible with your mobile device and relevant to your tastes and location.

Ovi Contacts

About Ovi Contacts

With Ovi Contacts, you can stay connected to the people who matter most. Search for contacts, and discover friends in the Ovi community. Keep in touch with your friends - chat, share your location and presence, and easily follow what your friends are up to and where they are. You can even chat with friends who use Google Talk™.

You can also sync your contacts, calendar, and other content between your Nokia device and Ovi.com. Your important information is stored and kept up-to-date both in your device and on the web. With Ovi Contacts, you can make your contacts list dynamic and be confident that your contacts are stored on Ovi.com.

You must have a Nokia Account to use the service. Create an account on your mobile device, or visit www.ovi.com on your PC.

Using Ovi Contacts may involve the transmission of large amounts of data through your service provider's network. Contact your network service provider for information about data transmission charges.

Start using Ovi Contacts

Select **Contacts**, and open the Ovi tab.

The Ovi Contacts service is part of Ovi, and uses the same account information.

If you are new to Ovi and its services, to start using the Ovi Contacts application, you must register to Ovi by creating a Nokia account.

Create a Nokia account

- 1 Select **Ovi Chat**, and when prompted, connect to the internet.
- 2 Enter the required information.
- 3 In the **My profile** view, enter your profile information. Your first and last name are mandatory details.
- 4 Select **Done**.

If you have already registered to Ovi using your PC or mobile device, you can start using Ovi Contacts with the same account details.

Sign in to Ovi Contacts and activate the service

Select **Ovi Chat**, and enter your user name and password.

If you have not yet provided your profile information for Ovi Contacts, do so, and select **Done**. Your first and last name are mandatory details.

Connect to the service

Connect to Ovi Contacts

Select **Go online** and the connection method. Use a wireless LAN (WLAN) connection where available.

Cancel the connection

Select **Options** > **Cancel connecting**.

A packet data connection may generate additional data transmission charges. For pricing details, contact your network service provider.

Select **Go online** > **Options** and from the following:

Select — Select the item.

Go online — Connect to the service if you are offline.

My profile — Edit your profile information.

Recommend to friend — Invite a contact to join Ovi Contacts. The invitation is sent as a text message.

Settings — Modify the Ovi Contacts settings.

The available options may vary.

Create and edit your profile

Edit your profile information

Select **My profile**.

View the profiles of your Ovi Contacts friends

Select a friend and **Options** > **Profile**.

Your profile information is visible to your Ovi Contacts friends. Only the following profile details are displayed to other Ovi Contacts users, for example during a search: first name and last name. To change your privacy settings, access Ovi on your PC, and sign in to your Nokia account.

Change your profile image

Select the profile image, **Select existing image**, and the new image. You can also edit or remove the current profile image or capture a new one.

Change your availability

By default, your availability is set to **Available**. To change your availability, select the icon.

Tell your friends what you are doing at the moment

Select **What are you doing?**, and enter text in the field.

Show your friends what music you are currently listening to

Select **Now playing**. To do this, you must allow your now playing information to be shared in the presence settings.

Edit your contact information

Select a field, and enter text.

In the My profile view, select **Options** and from the following:

Edit text — Cut, copy, or paste text.

Change — Change your status (when the status field is selected).

Activate — Start broadcasting your location or your now playing information to your friends (when either field is selected).

Undo changes — Undo the changes you made in the profile view.

Edit shared locations — Select the landmarks you want to broadcast to your friends (when the My location field is selected).

Stop sharing — Stop broadcasting your location to your friends (when the My location field is selected).

The available options may vary.

Find and add friends

Select **Options** > **Invite friend**.

Search for a friend

Enter the name of the friend in the Search friends field, and select the search icon.

You cannot search for friends based on their mobile number or e-mail address.

Start a new search

Select **New search**.

If the friends you searched for could not be found, they are not registered Ovi members, or they have chosen to be invisible in searches. When prompted, send a text message to your friends to invite them to join Ovi Contacts.

Send an invitation to join Ovi Contacts

Select **Select service**: and the service you know your friend uses. Enter your friend's user name, and select the send icon.

Select **Options** and from the following:

Select — Select an item.

Open — Open an item.

Invite as friend — Send an invitation to the contact.

Show profile — View the profile of the contact.

Renew invitation — Resend an invitation to join Ovi Contacts to a pending friend.

Search — Search for the contact whose name or other related keyword you entered in the Search friends field.

Edit text — Cut, copy, or paste text.

The available options may vary.

Chat with your friends

Start a chat with a friend

Select the friend.

Send a chat message

Enter the text in the message field, and select the send icon.

In the chat view, select **Options** and from the following:

Send — Send the message.

Add smiley — Insert a smiley.

Send my location — Send your location details to your chat partner (if supported by both devices).

Profile — View the details of a friend.

My profile — Select your presence status or profile image, personalise your message, or change your details.

Edit text — Copy or paste text.

End chat — End the active chat.

Exit — End all active chats, and close the application.

The available options may vary.

To receive location information from your friend, you must have the Maps application. To send and receive location information, both the Maps and Positioning applications are needed.

View the location of your friend

Select **Show on map**.

Return to the Ovi Contacts main view without ending the chat

Select **Back**.

Add, call, or copy phone numbers from a chat

Go to a phone number in a chat, and select **Options** and the appropriate option.

Ovi Sync

To sync your device with Ovi, you must have a Nokia account and activate the Ovi Contacts service on your device.

Sync your device with Ovi

- 1 If you sync your device with Ovi for the first time, use the Sync wizard to select what content you want to sync, and the sync interval.
- 2 Select **Synchronise**. If your device is in the Offline profile, connect to the internet when prompted.

Select **Options** and from the following:

Start — Sync your device with Ovi.

Cancel — Cancel an ongoing sync.

Synchronisation settings — Modify your sync settings.

The available options may vary.

Share your location

Open the Contacts application and the Ovi tab.

To share your location, select **Options** > **Settings** > **Presence** > **Share my location** and from the following:

Sharing allowed — Allow your friends to see your location.

My shared landmarks — Select the landmarks from where your location is broadcast to your friends.

Refresh interval — Select how often you broadcast your current location.

Add and select landmarks:

To add a location to the landmarks list, select **Share my location** > **My shared**

landmarks > Options > New landmark.

To add your current location as a landmark, select **Current position**.

To browse for a location on a map, select **Select from map**.

To add a landmark manually, select **Enter manually**.

To select the locations you want to share with your friends, select **Share my location > My shared landmarks**, and select the landmarks from the list. Select **Options** to edit, mark, and unmark items on the list.

Whenever you are online with the Contacts on Ovi service, and in one of the selected locations, your friends can see your location.

Ovi Contacts settings

Select **Options > Settings**.

Select from the following:

Account — Access your account details, and define your visibility to others in a search.

Presence — Show information about your location to your friends, and allow them to see when you are making a phone call (call status).

Personalisation — Modify the settings related to the startup and tones of the Ovi Contacts application, and automatically accept friend invitations.

Connection — Select the network connection to use, and activate roaming warnings.

Using a packet data connection may involve the transmission of large amounts of data through your service provider's network. For information about data transmission charges, contact your network service provider.

Exit — End all active chats, and close the application.

Nokia account settings

Select **Options > Settings > Account**.

Edit your account details

Select **My account**.

Define your visibility in searches

Select **My account > Visibility in search**. You must be online to change your visibility.

Presence settings

Select **Options > Settings > Presence**.

Modify presence settings

Select from the following:

Share my location — Allow your friends to see your location.

Share now playing — Allow your friends to see what music you are currently listening to on your mobile device.

Share call status — Allow your friends to see your call status.

Share your location

Select **Share my location** and from the following:

Sharing allowed — Allow your friends to see your location in selected landmarks.

My shared landmarks — Select the landmarks from where your location is broadcast to your friends.

Refresh interval — Select how often you broadcast your current location.

Add a location to the landmarks list

Select **Share my location** > **My shared landmarks** > **Options** > **New landmark**.

Add your current location as a landmark

Select **Current position**.

Browse for a location on a map

Select **Select from map**.

Add a landmark manually

Select **Enter manually**.

Select locations you want to share with your friends

- 1 Select **Share my location** > **My shared landmarks**.
- 2 Select the landmarks from the list.
- 3 Select **Options** to edit, mark, and unmark items on the list. Depending on your settings, your friends can see your location when you are in one of the selected locations.

Personalisation settings

Select **Options** > **Settings** > **Personalisation**.

Select from the following:

Login on start-up — Sign in automatically to Ovi Contacts when you switch on your mobile device.

Auto-accept friend invit. — Accept friend requests automatically without notification.

Auto-accept voice msgs. — Allow voice message to be accepted automatically.

Message tone — Select a tone for new messages.

Friend online tone — Select the tone that sounds when a friend comes online.

Icon on Home screen — Add the Ovi Contacts shortcut icon to your device home screen.

Connection settings

Select **Options** > **Settings** > **Connection**.

Modify connection settings

Select **Network connection** and the desired connection. To use the default connection defined in your device connection settings, select **Default connection**.


Set the device to notify you when your home network is not available

To receive a warning when your device is trying to connect to another network, select **Roaming warning** > **On**.

Make calls

Touch screen during calls

Your device has a proximity sensor. To extend battery life and prevent accidental selections, the touch screen is disabled automatically during calls, when you place the device next to your ear.



Do not cover the proximity sensor, for example, with protective film or tape.

Make a voice call

- 1 In the home screen, select to open the dialler, and enter the phone number, including the area code. To remove a number, select **C**.
For international calls, select * twice for the + character (which replaces the international access code), and enter the country code, area code (omit the leading zero if necessary), and phone number.
- 2 To make the call, press the call key.
- 3 To end the call (or to cancel the call attempt), press the end key.
Pressing the end key always ends a call, even if another application is active.

Call a contact

- 1 Select **Menu** > **Contacts**.
- 2 Go to the desired name. Or, enter the first letters or characters of the name in the search field, and go to the name.
- 3 To call the contact, press the call key. If you have saved several numbers for

a contact, select the desired number from the list, and press the call key.

End a call

Press the end key.

During a call

To mute or unmute the microphone, select or .

To put the call on hold or unhold it, select or .

To activate the loudspeaker, select . If you have attached a compatible headset with Bluetooth connectivity, to route the sound to the headset, select **Options** > **Activate BT handsfree**.

To switch back to the handset, select).

To end the call, select .

To switch between the active and held calls, select .

Tip: When you have only one active voice call, to put the call on hold, press the call key. To unhold the call, press the call key again.

- 1 To send DTMF tone strings (for example, a password), select **Options** > **Send DTMF**.
- 2 Enter the DTMF string, or search for it in the contacts list.
- 3 To enter a wait character (w) or a pause character (p), press * repeatedly.

- 4 To send the tone, select **OK**. You can add DTMF tones to the phone number or DTMF field in contact details.

To end an active call and replace it by answering the waiting call, select **Options > Replace**.

Many of the options that you can use during a voice call are network services.

Answer or reject a call

To answer a call, press the call key or swipe **Swipe to answer** from left to right. Swipe is in use only when the touch screen is locked.

To unlock the touch screen without answering a call, swipe **Swipe to unlock** from right to left, and then answer or reject the call, or send a reject call text message. The ringing tone is muted automatically.

If you do not want to answer a call, to reject the call, press the end key. If the call divert feature (network service) is activated, rejecting an incoming call also diverts the call.


To mute the ringing tone of an incoming call, select **Silence**.

To send a reject call text message without actually rejecting the call, informing the caller that you cannot answer the call, select **Silence > Send msg.**, edit the message text, and press the call key.

To activate the reject call text message feature, select **Menu > Settings and Calling > Call > Reject call with**

message. To write your standard message, select **Message text**.

Contact search

- 1 To open the dialler, in the home screen, select .
- 2 To activate contact search, select **Options > Search for contacts**.
- 3 To search for contacts, start entering the contact's name.

To search for contacts using the full keyboard, in the home screen, start entering the contact's name or phone number. Select the desired contact from the list of proposed matches.

To call the found contact, press the call key.

Speed dial a phone number

With the speed dial feature, you can quickly call your friends and family with the press and hold of a key.

Select **Menu > Settings and Calling**.


Activate speed dialling

Select **Call > Speed dialling > On**.

Assign a phone number to a number key

- 1 Select **Speed dialling**.
- 2 Go to the key to which you want to assign the phone number, and select **Options > Assign**.
1 and 2 are reserved for the voice and video mailboxes.

Make a call

In the home screen, select  to open the dialler, and select and hold the assigned key number.

Voice dialling

Your device automatically creates a voice tag for contacts.

Listen to a voice tag for a contact

- 1 Select a contact and **Options** > **Voice tag details**.
- 2 Go to a contact detail, and select **Options** > **Play voice tag**.

Make a call with a voice tag

Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely solely upon voice dialling in all circumstances.

When you use voice dialling, the loudspeaker is in use. Hold the device at a short distance away when you say the voice tag.

- 1 To start voice dialling, in the home screen, press and hold the call key. If a compatible headset with the headset key is attached, press and hold the headset key to start voice dialling.
- 2 A short tone sounds, and **Speak now** is displayed. Say clearly the name that is saved for the contact.
- 3 The device plays a synthesised voice tag for the recognised contact in the selected device language, and displays the name and number. To cancel the voice dialling, select **Quit**.

If several numbers are saved for a name, you can say also the name and the number type, such as mobile or telephone.

Call waiting

With call waiting (network service), you can answer a call when you have another call in progress.

Activate call waiting

Select **Menu** > **Settings and Calling** > **Call** > **Call waiting**.

Answer a waiting call

Press the call key. The first call is put on hold.

Swap between an active call and a call on hold

Select **Options** > **Swap**.

Connect the call on hold to the active call

Select **Options** > **Transfer**. You disconnect yourself from the calls.

End an active call


Press the end key.

End both calls

Select **Options** > **End all calls**.

Make a conference call

Your device supports conference calls between a maximum of six participants, including yourself.


- 1 Make a call to the first participant.
- 2 To make a call to another participant, select **Options** > **New call**. The first call is put on hold.
- 3 When the new call is answered, to add the first participant to the conference call, select .

Add a new participant to a conference call

Make a call to another participant, and add the new call to the conference call.

Have a private conversation with a conference call participant


Select .

Go to the participant, and select . The conference call is put on hold on your device. The other participants continue the conference call.

To return to the conference call, select



Drop a participant from a conference call

Select , go to the participant, and select



End an active conference call

Press the end key.

Voice and video mailboxes

With voice or video mailbox (network services, video mailbox available only in 3G networks) you can listen to the voice or video call messages you have received.

Call your voice or video mailbox

In the home screen, select  to open the dialler, select and hold **1**, and select **Voice mailbox** or **Video mailbox**.

Change the phone number of your voice or video mailbox

- 1 Select **Menu** > **Settings** and **Calling** > **Call mailbox**, a mailbox, and **Options** > **Change number**.

- 2 Enter the number (obtained from your network service provider), and select **OK**.

Make a video call

When you make a video call (network service), you can see a real-time, two-way video between you and the recipient of the call. The live video captured by the camera is displayed to the video call recipient.

To be able to make a video call, you must have a USIM card and be in the coverage of a 3G network. For availability, pricing and subscription to video call services, contact your network service provider.

A video call can only be made between two parties. The video call can be made to a compatible mobile device or an ISDN client. Video calls cannot be made while another voice, video, or data call is active.

Indicators




You are not receiving video (the recipient is not sending video or the network is not transmitting it).



You have denied video sending from your device. To send an image instead, select **Menu** > **Settings** and **Calling** > **Call** > **Image in video call**.


Even if you denied video sending during a video call, the call is still charged as a video call. To check costs, contact your service provider.

- 1 In the home screen, select  to open the dialler, and enter the phone number.

2 Select **Options > Call > Video call.**

The secondary camera on the front is used by default for video calls.

Starting a video call may take a while. If the call is not successful (for example, video calls are not supported by the network, or the receiving device is not compatible), you are asked if you want to try a normal call or send a message instead.

The video call is active when you see two videos, and hear the sound through the loudspeaker. The call recipient may deny video sending (indicated with ) and you only hear the voice of the caller, and may see an image or a grey screen.

End a video call

Press the end key.

During a video call


View live video or listen to the caller only

Select  or .

Mute or unmute the microphone

Select  or .

Activate the loudspeaker

Select . If you have attached a compatible headset with Bluetooth connectivity, to route the sound to the headset, select **Options > Activate BT handsfree.**

Switch back to the handset

Select .

Use the main camera to send video

Select **Options > Use secondary camera.**

Switch back to using the secondary camera to send video

Select **Options > Use main camera.**

Take a snapshot of the video you are sending

Select **Options > Send snapshot.** Video sending is paused and the snapshot is displayed to the recipient. The snapshot is not saved.

Zoom your image

Select **Options > Zoom.**

Set the video quality

Select **Options > Adjust > Video preference > Normal quality, Clearer detail, or Smoother motion.**

Answer or reject a video call

When a video call arrives,  is displayed.

Answer a video call

Press the call key.

To start sending live video, select **Yes.**

If you do not start sending video, you only hear the voice of the caller. A grey screen replaces your own video.

Start sending video during a video call

Select **Options > Enable > Sending video.**

Replace the grey screen with an image captured by the camera

Select **Menu > Settings and Calling > Call > Image in video call**.

Reject a video call

Press the end key.

Video sharing

Use video sharing (network service) to send live video or a video clip from your mobile device to another compatible mobile device during a voice call.

The loudspeaker is active when you activate video sharing. If you do not want to use the loudspeaker for the voice call while you share video, you can also use a compatible headset.

Warning:

Continuous exposure to high volume may damage your hearing. Listen to music at a moderate level, and do not hold the device near your ear when the loudspeaker is in use.

Video sharing requirements

Video sharing requires a 3G connection. Your ability to use video sharing depends on the availability of the 3G network. For more information on the service, 3G network availability, and fees associated with using this service, contact your service provider.

To use video sharing, ensure the following:

- Your device is set up for person-to-person connections.
- You have an active 3G connection and are within 3G network coverage. If

you move outside the 3G network during a video sharing session, the sharing stops, while your voice call continues.

- Both the sender and recipient are registered to the 3G network. If you invite someone to a sharing session and the recipient's device is not within 3G network coverage or does not have video sharing installed or person-to-person connections set up, the recipient does not receive invitations. You receive an error message that indicates that the recipient cannot accept the invitation.

Video sharing settings

To set up video sharing, you need person-to-person and 3G connection settings.

A person-to-person connection is also known as a Session Initiation Protocol (SIP) connection. The SIP profile settings must be configured in your device before you can use video sharing. Ask your service provider for the SIP profile settings, and save them to your device. Your service provider may send you the settings or give you a list of the needed parameters.

Add a SIP address to a contact

- 1 Select **Menu > Contacts**.
- 2 Select a contact or create a new contact.
- 3 Select **Options > Edit**.
- 4 Select **Options > Add detail > Share video**.
- 5 Enter the SIP address in the format `username@domainname` (you can use an IP address instead of a domain name).

If you do not know the SIP address for the contact, you can use the phone number of the recipient, including the country code, to share video (if supported by the network service provider).

Set up your 3G connection

Contact your service provider to establish an agreement for you to use the 3G network.

Ensure that the 3G access point connection settings for your device are configured properly. For more information about the settings, contact your service provider.

Share live video or video clips








During an active voice call, select **Options > Share video**.

Share live video during a call

- 1 Select **Live video**.
- 2 Select **Video clip** and the clip you want to share.
You may need to convert the video clip into a suitable format to be able to share it. If your device notifies you that the video clip must be converted, select **OK**. Your device must have a video editor for the conversion to work.
- 3 If the recipient has several SIP addresses or phone numbers saved in your contacts list, select the desired address or number. If the SIP address or phone number of the recipient is not available, enter the address or number of the recipient, including the country code, and select **OK** to send the invitation. Your device sends the invitation to the SIP address.

Sharing begins automatically when the recipient accepts the invitation.

Options during video sharing

-  or  Mute or unmute the microphone.
-  or  Switch the loudspeaker on or off
-  or  Pause or resume video sharing.
-  Switch to full screen mode (receiver only).

End the video sharing session

Select **Stop**. To end the voice call, press the end key. When you end the call, video sharing also ends.

Save the live video you shared

Select **Yes** when prompted.

If you access other applications while you are sharing a video clip, the sharing is paused. To return to the video sharing view and to continue sharing, in the home screen, select **Options > Continue**.

Accept a video sharing invitation

When someone sends you a video sharing invitation, the invitation message displays the sender's name or SIP address.

If someone sends you a sharing invitation and you are not within 3G network coverage, you will not receive the invitation.

Accept the received invitation

Select **Yes**. The sharing session is activated.

Reject the received invitation

Select **No**. The sender receives a message that you rejected the invitation. You can also press the end key to reject the invitation and end the voice call.

End the sharing session

Select **Stop** or end the voice call. When you end the call, video sharing also ends.

Internet calls**About internet calls**

With the internet call network service, you can make and receive calls over the internet. Internet call services may support calls between computers, between mobile phones, and between a VoIP device and a traditional telephone. For availability and costs, contact your internet call service provider.

To make or receive an internet call, you must be in the service area of a wireless LAN (WLAN) or have a packet data (GPRS) connection in a UMTS network, and be connected to an internet call service.

Your device may offer you an installation widget, to install internet call services.

Log into an internet call service


When an internet call service has been installed, a tab for the service is displayed in the contacts list.

Select **Menu** > **Contacts**, the service, and **Options** > **Log in**.


Add contacts as service contacts to the friends list

Select **Options** > **New contact**.



Make internet calls**Call a contact when you are logged into a service**

Tap the contact in the friends list, and select .

Make an internet call in the home screen

Select , enter the number, and select **Options** > **Call** > **Internet call**.

Make an internet call to an internet call address

In the home screen, select  > **Options** > **Open keyboard**. Enter the address, and select .

Internet communication settings

Select **Menu** > **Settings** and **Connectivity** > **Admin. settings** > **Net settings**.

To view and edit the settings for a service, select the service name.

To remove a service from your service list, select **Options** > **Delete service**.

Internet call service settings

Select **Menu** > **Contacts**. Open a service tab, and select **Options** > **Settings**.

Set an internet call service as the default service

Select **Default service**.

When you press the call key to call a number, your device makes an internet call using the default service if the service is connected. You can set only one service at a time as the default service.

Edit the service destination

Select **Service connectivity**.

Log

The log stores information about the communication history of the device. The device registers missed and received calls only if the network supports these functions, the device is switched on, and within the network service area.

Recent calls

You can view information about your recent calls.

Select **Menu > Applications > Tools > Log and Recent calls**.

View missed, received, and dialled calls

Select **Missed calls, Received calls, or Dialled numbers**.

Tip: To open the dialled numbers list in the home screen, press the call key.

Select **Options** and from the following:

Save to Contacts — Save a phone number from a recent calls list to your contacts.

Clear list — Clear the selected recent calls list.

Delete — Clear an event in the selected list.

Settings — Select **Log duration** and the length of time that the communication information is saved in the log. If you select **No log**, no information is saved in the log.

Call duration

You can view the approximate duration of your last call, dialled and received calls, and all calls.

Select **Menu > Applications > Tools > Log and Call duration**.

Packet data

Select **Menu > Applications > Tools > Log**.

You may be charged for your packet data connections by the amount of data sent and received.

Check the amount of data sent or received during packet data connections

Select **Packet data > All sent data or All received data**.

Clear both sent and received information

Select **Packet data > Options > Clear counters**. You need the lock code to clear the information.

Monitor all communication events

In the general log, you can view information on communication events, such as voice calls, text messages, or data and wireless LAN (WLAN) connections registered by your device.

Select **Menu > Applications > Tools > Log**.

Open the general log

Open the general log tab   .

Subevents, such as a text message sent in more than one part and packet data connections, are logged as one communication event. Connections to

your mailbox, multimedia messaging centre, or web pages are shown as packet data connections.

View the packet data connection details

Go to an incoming or outgoing packet data connection event indicated with GPRS, and select **Options > View**.

Copy a phone number from the log

Select **Options > Use number > Copy**. You can, for example, paste the phone number to a text message.

Filter the log

Select **Options > Filter** and a filter.

Define the log duration

Select **Options > Settings > Log duration**. If you select **No log**, all the log contents, recent calls register, and messaging delivery reports are permanently deleted.

Contacts (phonebook)


To open Contacts, select **Menu > Contacts**.

You can save and update contact information, such as phone numbers, home addresses, or e-mail addresses of your contacts. You can add a personal ringing tone or a thumbnail image to a contact. You can also create contact groups, which allow you to send text messages or e-mail to many recipients at the same time.

Save and edit names and numbers

Select **Menu > Contacts**.

Add a new contact to the contacts list

- 1 Select .
- 2 Select a field to enter information. To close the text input, select **Done**. Fill in the appropriate fields, and select **Done**.


Edit contacts

Select a contact and **Options > Edit**.


Contacts toolbar

Select **Menu > Contacts**.

Call a contact

Go to a contact, and select  **Call**.

Send a message to a contact

Go to a contact, and select  **Create message**.

Create a new contact

Select  **New contact**.

Manage names and numbers

Select **Menu** > **Contacts**.

Delete contacts

Select a contact and **Options** > **Delete**.

To delete several contacts at the same time, select **Options** > **Mark/Unmark** to mark the desired contacts, and to delete, select **Options** > **Delete**.

Copy contacts

Select the contact, **Options** > **Copy**, and the desired location.

Add contacts to favourites

Tap and hold a contact, and select **Add to favourites**.

Listen to the voice tag assigned to a contact

Select the contact and **Options** > **Voice tag details** > **Options** > **Play voice tag**.

Before using voice tags, note the following:

- Voice tags are not language-dependent. They are dependent on the speaker's voice.
- You must say the name exactly as you said it when you recorded it.
- Voice tags are sensitive to background noise. Record voice tags and use them in a quiet environment.
- Very short names are not accepted. Use long names, and avoid similar names for different numbers.

Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely solely upon voice dialling in all circumstances.

Assign default numbers and addresses

If a contact has several numbers or addresses, a default number or address makes it easier for you to call or send a message to the contact. The default number is also used in voice dialling.

- 1 Select **Menu** > **Contacts**.
- 2 Select a contact and **Options** > **Defaults**.
- 3 Select a default to which you want to add a number or an address, and select **Assign**.
- 4 Select a number or an address you want to set as a default.
- 5 To exit the Defaults view and save the changes, tap outside the view.

Contact cards

All available communication methods for a contact are displayed in the contact cards view.

Select **Menu** > **Contacts**.

Select a contact, the desired communication method, **Options**, and from the following:

Edit — Edit, add, or delete the contact card fields.

Defaults — Define the numbers and addresses to use by default when you communicate with the contact, if a contact has more than one number or address defined.

Voice tag details — View the voice tag details, or listen to the voice tag for the contact.

The available options and communication methods may vary.

Set contacts as favourites

You can set contacts as your favourite contacts. These contacts appear at the top of the contacts list and are marked with a star icon.

Select **Menu > Contacts**.

Set a contact as a favourite

Select a contact and **Options > Add to favourites**.

Remove a contact from favourites

Select a contact and **Options > Remove from favourites**. The removed contact is moved back to the standard contacts list.

Ringling tones, images, and call text for contacts

You can define a ringing tone for a contact or group, and an image and a call text for a contact. When the contact calls you, the device plays the selected ringing tone and shows the call text or image (if the caller's phone number is sent with the call and your device recognises it).

To define a ringing tone for a contact or a contact group, select the contact or contact group and **Options > Edit > Ringing tone**, and a ringing tone.

To add more fields to a contact details view, select the contact and **Options > Edit > Options > Add detail**.

To define a call text for a contact, select the contact and **Options > Edit > Options > Add detail > Call alert text**. Tap the text field to enter the call text, and select **Done**.

To add an image for a contact saved in the device memory, select the contact,

Options > Edit > Add image, and an image from Photos.

To remove the ringing tone, select **Default tone** from the list of ringing tones.

To view, change or remove the image from a contact, select the contact, **Options > Edit > Image > Options**, and the desired option.

Copy contacts

Select **Menu > Contacts**.


When you open the contacts list for the first time, the device asks if you want to copy names and numbers from the SIM card to your device.

Start copying

Select **OK**.

Cancel copying

Select **Cancel**.

The device asks if you want to view the SIM card contacts in the contacts list. To view the contacts, select **OK**. The contacts list opens, and the names stored on your SIM card are indicated with .

SIM services

For availability and information on using SIM card services, contact your SIM card vendor. This may be the network service provider or other vendor.

SIM contacts

The number of contacts that can be stored on the SIM card is limited.

Display contacts stored on the SIM card in the contacts list

Select **Options** > **Settings** > **Contacts to display** > **SIM memory**.

The numbers you save in the contacts list may not be automatically saved to your SIM card.

Copy contacts to the SIM card

Go to a contact, and select **Options** > **Copy** > **SIM memory**.

Select the default memory where to save the new contacts

Select **Options** > **Settings** > **Default saving memory** > **Phone memory** or **SIM memory**.

Contacts stored in the device memory can contain more than one phone number and an image.

Fixed dialling

With the fixed dialling service, you can restrict calls from your device to certain phone numbers. Not all SIM cards support the fixed dialling service. For more information, contact your service provider.

Select **Menu** > **Contacts and Options** > **SIM numbers** > **Fixed dial contacts**.

When security features that restrict calls are in use (such as call barring, closed user group, and fixed dialling), calls may be possible to the official emergency number programmed into your device. Call barring and call diverting cannot be active at the same time.

You need your PIN2 code to activate and deactivate fixed dialling or edit your fixed

dialling contacts. Contact your service provider for your PIN2 code.

Select **Options** and from the following:


Activate fixed dialling or **Deactivate fixed dialling** — Activate or deactivate fixed dialling.

New SIM contact — Enter the contact name and phone number to which calls are allowed.

Add from Contacts — Copy a contact from the contacts list to the fixed dialling list.

To send text messages to the SIM contacts while the fixed dialling service is active, you need to add the text message centre number to the fixed dialling list.

Contact groups

To open the group list, open the contacts list, and tap .

Create contact groups

With contact groups, you can contact several people with a single message.

Select **Menu** > **Contacts**, and open the groups tab.

Create a new group

- 1 Select **Options** > **New group**.
- 2 Use the default name, or enter a new name, and select **OK**.

Add members to the group

- 1 Select the group and **Options** > **Add members**.
- 2 Mark each contact you want to add, and select **OK**.

Manage contact groups

Select **Menu** > **Contacts**.

Send a message to all group members

Tap and hold the group, and select **Create message**.

Set a ringing tone for a group

Tap and hold the group, and select **Ringing tone**.

Rename a group

Tap and hold the group, and select **Rename**.

Delete a group

Tap and hold the group, and select **Delete**.

Add a contact to a group

Select the group and **Options > Add members**.

To check which other groups a contact belongs to, select the group and the contact, and **Options > Belongs to groups**.

Remove a contact from a group


Select the group and the contact, and **Options > Remove from group**.

E-mail**About e-mail**

Select **Menu > E-mail**.

With Mail, you can add several mailboxes and access them directly from your home screen. In the main e-mail view, you can switch from one mailbox to another. E-mail is a network service.

If you do not have a mailbox, you can create one at www.ovi.com.



- 1 Your current mailbox.
- 2 Switch between your mailboxes, and view e-mails in different folders.
- 3 Sort your e-mail by, for example, date.
- 4 E-mail in current mailbox.

Mail contains interactive elements. Select and hold, for example, an e-mail to view a pop-up menu.

Add a mailbox

You can add several mailboxes to your device.

Select Menu > E-mail

Add a mailbox

Select **New mailb.**, and follow the instructions.

Add an e-mail widget to the home screen

In the home screen, select and hold the desired location for the mail widget, and from the pop-up menu, select **Add content** and the desired mail widget.

Create another mailbox

Select **New mailb.**, and follow the instructions.

Delete a mailbox

Select **Settings**, go to the mailbox, and select **Options > Remove mailbox**.

Read e-mail

You can use your device to read and reply to e-mail.

Select **Menu > E-mail**.


Read an e-mail

Select an e-mail.


Open or save an attachment

Select and hold the attachment, and from the pop-up menu, select the appropriate option. If there is more than one attachment, you can save them all at once.

Reply to an e-mail

Select @⁺, and from the pop-up menu, select .

Forward an e-mail

Select @⁺, and from the pop-up menu, select .



Tip: To go to a web address that is in a mail, select the address. To add the web address to your bookmarks, after the page loads, select **Options > Web page options > Save as bookmark**.

Tip: To open the next or previous e-mail, use the arrow icons.

Send an e-mail

You can use your device to write and send e-mail, and attach files to your e-mail.

Select **Menu > E-mail**.

- 1 Select @⁺.
- 2 To add a recipient from your contacts list, select the To, Cc, or Bcc icon. To enter an e-mail address manually, select the To, Cc, or Bcc field.
- 3 To add an attachment to the e-mail, select .
- 4 To send the e-mail, select .

Mail for Exchange

With Mail for Exchange, you can receive your work e-mail to your device. You can read and reply to your e-mails, view and edit compatible attachments, view calendar information, receive and reply to meeting requests, schedule meetings, and view, add, and edit contact information.

ActiveSync

Use of the Mail for Exchange is limited to over-the-air synchronisation of PIM information between the Nokia device and the authorised Microsoft Exchange server.

Mail for Exchange can be set up only if your company has Microsoft Exchange Server. In addition, your company's IT administrator must have activated Mail for Exchange for your account.

Before starting to set up Mail for Exchange, ensure that you have the following:

- A corporate e-mail ID
- Your office network user name
- Your office network password
- Your network domain name (contact your company's IT department)
- Your Mail for Exchange server name (contact your company's IT department)

Depending on your company's Mail for Exchange server configuration, you may need to enter other information in addition to those listed. If you do not know the correct information, contact your company's IT department.

With Mail for Exchange, the use of the lock code may be mandatory. The default lock code of your device is 12345, but your company's IT administrator may have set a different one for you to use.

You can access and modify the Mail for Exchange profile and settings in the Messaging settings.

Messaging

Messaging main view

Select **Menu** > **Messaging**.


Messaging is a network service.

Create a new message


Select **New message**.


Tip: To avoid rewriting messages that you send often, use saved messages in the **Templates** folder in **My folders**. You can also create and save your own templates.


Messaging contains the following folders:


 **Inbox** — Received messages, except e-mail and cell broadcast messages.

 **My folders** — Organise your messages into folders.

 **Drafts** — Draft messages that have not been sent.

 **Sent** — The last messages that have been sent, excluding messages sent using Bluetooth connectivity. You can define the number of messages that can be saved in this folder.

 **Outbox** — Messages waiting to be sent are temporarily stored in the Outbox folder, for example, when your device is outside network coverage.

 **Delivery reports** — Request the network to send you a delivery report of the text messages and multimedia messages you have sent (network service).

Write and send messages

Select **Menu** > **Messaging**.

Messaging is a network service.

Important: Exercise caution when opening messages. Messages may contain malicious software or otherwise be harmful to your device or PC.

Before you can create a multimedia message, you must have the correct connection settings defined.

The wireless network may limit the size of MMS messages. If the inserted picture exceeds this limit, the device may make it smaller so that it can be sent by MMS.

Only devices that have compatible features can receive and display multimedia messages. The appearance of a message may vary depending on the receiving device.


Send a text or multimedia message

Select **New message**.

Send an audio message

Select **Options** > **Create message** and the relevant option.

Select recipients or groups from the contacts list

From the toolbar, select .

Enter the number manually

Tap the **To** field.

Enter the subject of the multimedia message

Enter the subject in the **Subject** field. If the **Subject** field is not visible, select **Options** > **Message header fields** to change the fields that are visible.

Write the message

Tap the message field.

Add an object to a message

Select  and the relevant type of content.

The message type may change to multimedia message based on the inserted content.

Send the message

Select , or press the call key.

Your device supports text messages beyond the limit for a single message. Longer messages are sent as two or more messages. Your service provider may charge accordingly. Characters with accents, other marks, or some language options take more space, and limit the number of characters that can be sent in a single message.

Messaging inbox

Receive messages

Select **Menu** > **Messaging and Inbox**.




An unread text message

An unread multimedia message

An unread audio message

Data received through Bluetooth connectivity

When you receive a message,  and **1 new message** are displayed in the home screen.

Open a message from the home screen

Select **Show**.

Open a message in the Inbox folder

Select the message.

Reply to a received message

Select **Options** > **Reply**.




Multimedia messages

Select **Menu** > **Messaging**.

Important: Exercise caution when opening messages. Messages may contain malicious software or otherwise be harmful to your device or PC.

Retrieve multimedia messages

Select **Options** > **Retrieve**. A packet data connection is opened to retrieve the message to your device. You may receive a notification that a multimedia message is waiting in the multimedia message centre.


When you open a multimedia message () , you may see an image and a message.  indicates that a sound clip is included.  indicates that a video clip is included.

Play the sound or video clip

Select the indicator.

View the media objects that have been included in a multimedia message

Select **Options** > **Objects**.

If the message includes a multimedia presentation,  is displayed.

Play the presentation

Select the indicator.

Data, settings, and web service messages

Your device can receive many kinds of messages that contain data, such as business cards, ringing tones, operator logos, and calendar entries. You may also

receive settings from your service provider in a configuration message.

Save the data in a message

Select **Options** and the appropriate option.

Web service messages are notifications (for example, news headlines), and may contain a text message or a link. For availability and subscription, contact your service provider.

View messages on a SIM card

You can view messages that are stored on a SIM card.

Select **Menu > Messaging and Options > SIM messages**.

Before you can view SIM messages, you must copy them to a folder in your device.

- 1 Mark the messages. Select **Options > Mark/Unmark > Mark** or **Mark all**.
- 2 Open a list of folders. Select **Options > Copy**.
- 3 Select a folder to copy.
- 4 To view the messages, open the folder .

Cell broadcast messages

Cell broadcast (network service) allows you to receive messages on various topics, such as weather or traffic conditions, from your service provider.

Select **Menu > Messaging and Options > Operator msgs..**

For available topics and relevant topic numbers, contact your service provider. This service may not be available for all regions. Cell broadcast messages cannot

be received in 3G networks. A packet data connection may prevent cell broadcast reception.

Service commands

With service commands (network service) you can enter and send service requests (also known as USSD commands), such as activation commands for network services, to your service provider. This service may not be available for all regions.

Select **Menu > Messaging and Options > Service commands**.

Messaging settings

The settings may be preconfigured in your device, or you may receive them in a message. To enter settings manually, fill in all fields marked with **Must be defined** or an asterisk.

Some or all message centres or access points may be preset for your device by your service provider, and you may not be able to change, create, edit, or remove them.

Text message settings

Select **Menu > Messaging and Options > Settings > Text message**.

Select from the following:

Message centres — View a list of all text message centres that have been defined.

Message centre in use — Select which message centre to use to deliver text messages.

Character encoding — To use character conversion to another encoding system when available, select **Reduced support**.

Receive report — Request the network to send you a delivery report of the text

messages you have sent (network service).

Message validity — Select for how long the message centre resends your message if the first attempt fails (network service). If the message cannot be sent within this time period, the message is deleted from the message centre.

Message sent as — To find out if your message centre is able to convert text messages into these other formats, contact your service provider.

Preferred connection — Select the connection to use.

Reply via same centre — Reply to messages using the same text message centre number (network service).

Multimedia message settings

Select Menu > Messaging and Options > Settings > Multimedia message.

Select from the following:

Image size — Define the size of the image in a multimedia message.

MMS creation mode — If you select **Guided**, the device informs you if you try to send a message that may not be supported by the recipient. If you select **Restricted**, the device prevents you from sending messages that may not be supported. To include content in your messages without notifications, select **Free**.

Access point in use — Select which access point is used as the preferred connection.

Multimedia retrieval — Select how you want to receive messages, if available. To receive messages automatically in your home network, select **Auto in home**

netw.. Outside your home network, you receive a notification that there is a message to retrieve in the multimedia message centre. If you select **Always automatic**, your device automatically makes an active packet data connection to retrieve the message both in and outside your home network. Select **Manual** to retrieve multimedia messages from the message centre manually, or **Off** to prevent receipt of any multimedia messages. Automatic retrieval may not be supported in all regions.

Allow anonymous msg. — Reject messages from anonymous senders.

Receive adverts — Receive multimedia message advertisements (network service).

Receive reports — Display the status of sent messages in the log (network service).

Deny report sending — Prevent your device from sending delivery reports of received messages.

Message validity — Select for how long the message centre resends your message if the first attempt fails (network service). If the message cannot be sent within this time period, the message is deleted from the message centre.

The device requires network support to indicate that a sent message has been received or read. Depending on the network and other circumstances, this information may not always be reliable.

Web service message settings

Select Menu > Messaging and Options > Settings > Service message. Select whether you want to receive service messages.

Automatically open the browser and retrieve content when you receive a service message

Select **Download messages** > **Automatically**.

Cell broadcast settings

Select **Menu** > **Messaging** and **Options** > **Settings** > **Operator message**.

For available topics and related topic numbers, contact your service provider.

Select from the following:

Reception — Set your device to receive cell broadcast messages.

Language — Select the languages in which you want to receive messages: **All**, **Selected**, or **Other**.

Topic detection — Set the device to automatically search for new topic numbers, and to save the new numbers without a name to the topic list.

Other settings

Select **Menu** > **Messaging** and **Options** > **Settings** > **Other**.

Select from the following:

Save sent messages — Save copies of the text or multimedia messages that you send to the Sent folder.

Number of saved msgs. — Define how many sent messages can be saved in the Sent folder. When the limit is reached, the oldest message is deleted.

Memory in use — Select where to save your messages.

Show messages in groups — Group the messages in Inbox, Sent, Drafts, and My folders.

Nokia Messaging

About Nokia Messaging

The Nokia Messaging service automatically transfers mail from your existing mail address to your device. You can read, respond to, and organise your mails on the go.

To set up your mail account on your device, select **Menu** > **E-mail** and **New mailb.**, and follow the instructions.

If you do not have a mail account, you can create one at www.oivi.com.

The Nokia Messaging service may be chargeable. For information on possible costs, contact your service provider or the Nokia Messaging service at messaging.nokia.com.

Nokia Messaging is a network service, and may not be available in all regions.

Connectivity

Your device offers several options to connect to the internet or to another compatible device or PC. For more information on other connectivity methods, see the extended user guide on the product support pages of the Nokia website.

Data connections and access points

Your device supports packet data connections (network service), such as GPRS in the GSM network. When you use your device in GSM and 3G networks, multiple data connections can be active at the same time, and access points can share a data connection. In the 3G network, data connections remain active during voice calls.

You can also use a WLAN data connection. Only one connection in one wireless LAN can be active at a time, but several applications can use the same internet access point.


To establish a data connection, an access point is required. You can define different kinds of access points, such as the following:

- MMS access point to send and receive multimedia messages
- Internet access point (IAP) to send and receive e-mail and connect to the internet

Check the type of access point you need with your service provider for the service you want to access. For availability and subscription to packet data connection services, contact your service provider.

Network settings

Select **Menu > Settings and Connectivity > Network**.

Your device can automatically switch between GSM and UMTS networks. GSM networks are indicated with . UMTS networks are indicated with **3G**.

An active high-speed downlink packet access (HSDPA) connection (network service) is indicated with **3.5G**.

Select from the following:

Network mode — Select which network to use. If you select **Dual mode**, the device uses the GSM or UMTS network automatically, according to the network parameters and the roaming agreements between the wireless service providers. For details and roaming costs, contact your network service provider. This option is shown only if supported by the wireless service provider.

A roaming agreement is an agreement between two or more service providers to enable the users of one service provider to use the services of other service providers.

Operator selection — Select **Automatic** to set the device to search for and select one of the available networks, or **Manual** to manually select the network from a list. If the connection to the manually selected network is lost, the device sounds an error tone and asks you to reselect a network. The selected network must have a roaming agreement with your home network.

Cell info display — Set the device to indicate when it is used in a cellular network based on microcellular network (MCN) technology and to activate cell info reception.

Wireless LAN

Your device can detect and connect to wireless local area networks (WLAN). Using a WLAN, you can connect your device to the internet and compatible devices that have WLAN support.

About WLAN

To use a wireless LAN (WLAN) connection, it must be available in the location, and your device must be connected to the WLAN. Some WLANs are protected, and you need an access key from the service provider to connect to them.

Note: In France, you are only allowed to use WLAN indoors.

Features that use WLAN, or that are allowed to run in the background while using other features, increase the demand on battery power and reduce the battery life.

Important: Always enable one of the available encryption methods to increase the security of your wireless LAN connection. Using encryption reduces the risk of unauthorised access to your data.

WLAN connections

To use a wireless LAN (WLAN) connection, you must create an internet access point (IAP) for WLAN. Use the access point for applications that need to connect to the internet.

A WLAN connection is established when you create a data connection using a WLAN internet access point. The active WLAN connection ends when you end the data connection.

You can use WLAN during a voice call or when packet data is active. You can only

be connected to one WLAN access point device at a time, but several applications can use the same internet access point.

When the device is in the offline profile, you can still use WLAN (if available). Remember to comply with any applicable safety requirements when establishing and using a WLAN connection.

Tip: To check the unique media access control (MAC) address that identifies your device, open the dialler and enter ***#62209526#**.

WLAN wizard

Select **Menu > Settings and Connectivity > WLAN**.

The WLAN wizard helps you to connect to a wireless LAN (WLAN) and manage your WLAN connections.

If the search finds WLANs, to create an internet access point (IAP) for a connection and start the web browser using this IAP, select the connection and **Start web browsing**.

If you select a secured WLAN, you are asked to enter the relevant password. To connect to a hidden network, you must enter the correct network name (service set identifier, SSID).

If you already have the web browser running using the currently active WLAN connection, to return to the web browser, select **Continue web browsing**.

To end the active connection, select the connection and **Disconnect WLAN**.

WLAN internet access points

Select **Menu > Settings and Connectivity > WLAN**.

Filter out WLANs from the list of found networks

Select **Options > Filter WLAN networks**. The selected networks are not displayed the next time the WLAN wizard searches for WLANs.

View the details of a network

Select **Options > Details**. If you select an active connection, the connection details are displayed.

Operating modes

There are two operating modes in WLAN: infrastructure and ad hoc.

The infrastructure operating mode allows two kinds of communication: wireless devices are connected to each other through a WLAN access point device, or wireless devices are connected to a wired LAN through a WLAN access point device.

In the ad hoc operating mode, devices can send and receive data directly with each other.

Wireless LAN settings

In the wireless LAN (WLAN) settings, you can define whether the WLAN indicator is displayed when a network is available and how often the network is scanned. You can also define whether and how the internet connectivity test is performed, and view advanced WLAN settings.

Select **Menu > Settings and Connectivity > WLAN > Options > Settings**.

Display when a WLAN is available

Select **Show WLAN availability > Yes**.

Set how often the device searches for available WLAN

Select **Show WLAN availability > Yes and Scan for networks**.

Define internet capability test settings

Select **Internet connectivity test** and whether to run the test automatically or after confirmation, or to never run the test. If the connectivity test is successful, the access point is saved to the internet destinations list.

View advanced settings


Select **Options > Advanced settings**.

It is recommended that you do not modify the advanced WLAN settings.





Access points**Create a new access point**

Select **Menu > Settings and Connectivity > Destinations**.




You may receive access point settings in a message from a service provider. Some or all access points may be preset for your device by your service provider, and you may not be able to change, create, edit, or remove them.

- 1 Select  **Access point**.
- 2 The device asks to check for available connections. After the search, connections that are already available are shown and can be shared by a new access point. If you skip this step, you are asked to select a connection method and to define the settings needed.

To view access points stored in your device, select an access point group. The different access point groups are the following:

-  Internet access points
-  Multimedia messaging access points
-  WAP access points
-  Uncategorised access points

The different access point types are indicated with the following:

-  Protected access point
-  Packet data access point
-  Wireless LAN (WLAN) access point

Manage access point groups

To avoid selecting a single access point every time the device makes a network connection, you can create a group that contains various access points to connect to that network and define the order in which the access points are used. For example, you can add wireless LAN (WLAN) and packet data access points to an internet access point group, and use the group for browsing the web. If you give WLAN the highest priority, the device connects to the internet through WLAN, if available, and through a packet data connection if not.

Select **Menu > Settings and Connectivity > Destinations**.

Create a new access point group

Select **Options > Manage > New destination**.

Add access points to an access point group

Select the group and **Options > New access point**.

Copy an existing access point from another group

Select the group, go to the access point to copy, and select **Options > Organise > Copy to other dest..**


Change the priority of an access point within a group

Select **Options > Organise > Change priority**.

Packet data access point settings

Select **Menu > Settings and Connectivity > Destinations > Access point**, and follow the instructions.

Edit a packet data access point

Select an access point group and access point marked with . Follow the instructions from your service provider.

Select from the following:

Access point name — The access point name is provided by your service provider.

User name — The user name may be needed to make a data connection, and is usually provided by your service provider.

Prompt password — If you must enter the password every time you log in to a server, or if you do not want to save your password in the device, select **Yes**.

Password — A password may be needed to make a data connection, and is usually provided by your service provider.

Authentication — To always send your password encrypted, select **Secure**. To

send your password encrypted when possible, select **Normal**.

Homepage — Depending on the access point you are setting up, enter the web address or the address of the multimedia message centre.

Use access point — Set the device to connect to the destination using this access point after confirmation or automatically.

Modify advanced packet data access point settings

Select **Options > Advanced settings**.

Select from the following:

Network type — Select the internet protocol type to transfer data to and from your device. The other settings depend on the selected network type.

Phone IP address (for IPv4 only) — Enter the IP address of your device.


DNS addresses — Enter the IP addresses of the primary and secondary DNS servers, if required by your service provider. To obtain these addresses, contact your internet service provider.

Proxy server address — Enter the address of the proxy server.

Proxy port number — Enter the port number of the proxy server.

WLAN internet access points

Select **Menu > Settings and Connectivity > Destinations > Access point**, and follow the instructions.

To edit a wireless LAN (WLAN) access point, open one of the access point groups, and select an access point marked with .

Follow the instructions from your WLAN service provider.

Select from the following:

WLAN network name — Select **Enter manually** or **Search for networks**. If you select an existing network, WLAN network mode and WLAN security mode are determined by the settings of its access point device.

Network status — Define whether the network name is displayed.

WLAN network mode — Select **Ad-hoc** to create an ad hoc network and to allow devices to send and receive data directly; a WLAN access point device is not needed. In an ad hoc network, all devices must use the same WLAN network name.

WLAN security mode — Select the encryption used: **WEP**, **802.1x**, or **WPA/WPA2** (802.1x and WPA/WPA2 are not available for ad hoc networks). If you select **Open network**, no encryption is used. The WEP, 802.1x and WPA functions can be used only if the network supports them.

Homepage — Enter the web address of the starting page.


Use access point — Set the device to create a connection using this access point automatically or after confirmation.

The available options may vary.

View your active data connections

Select **Menu > Settings and Connectivity > Connection mgr..**

In the active data connections view, you can see your data connections:

 data calls



packet data connections
WLAN connections

Close a connection

Select **Options** > **Disconnect**.


Close all open connections

Select **Options** > **Disconnect all**.

View the details of a connection

Select **Options** > **Details**.

Synchronisation

 With the Synchronisation application, you can synchronise your notes, messages, browser bookmarks, and contacts with compatible applications on a compatible PC or on the internet.

Select **Menu** > **Settings** and **Connectivity** > **Data transfer** > **Sync**.

You may receive synchronisation settings in a special message from your service provider.

A synchronisation profile contains the necessary settings for synchronisation. When you open the application, the default or previously used synchronisation profile is displayed.

Create a new synchronisation profile

Select **Options** > **New sync profile**.

Define the features included in the synchronisation profile

Select a synchronisation item to include it in the profile or to leave it out.

Manage synchronisation profiles

Select **Options** and the desired option.

Synchronise data

Select **Options** > **Synchronise**.

Bluetooth connectivity

About Bluetooth connectivity

With Bluetooth connectivity, you can make a wireless connection to other compatible devices, such as mobile devices, computers, headsets, and car kits.

You can use the connection to send items from your device, transfer files from your compatible PC, and print files with a compatible printer.



Select **Menu** > **Settings** and **Connectivity** > **Bluetooth**.

Since devices with Bluetooth wireless technology communicate using radio waves, they do not need to be in direct line-of-sight. However, they must be within 10 metres (33 feet) of each other, although the connection may be subject to interference from obstructions such as walls or from other electronic devices.

This device is compliant with Bluetooth Specification 2.0 + EDR supporting the following profiles: Dial-Up Networking (DUN), Object Push Profile (OPP), File Transfer Profile (FTP), Hands Free Profile (HFP), Headset Profile (HSP), Basic Imaging Profile (BIP), Remote SIM Access Profile (SimAP), Device Identification Profile (DI), Phonebook Access Profile (PBAP), Human Interface Device Profile (HID), Generic Audio/Video Distribution Profile (GAVDP), Audio/Video Remote Control Profile (AVRCP), Advanced Audio Distribution Profile (A2DP). To ensure interoperability between other devices supporting Bluetooth technology, use Nokia approved accessories for this model.

Check with the manufacturers of other devices to determine their compatibility with this device.

When the device is locked, only connections to authorised devices are possible.

Features using Bluetooth technology increase the demand on battery power and reduce the battery life.

Bluetooth settings

Select **Menu > Settings and Connectivity > Bluetooth**.

Select from the following:

Bluetooth — Activate Bluetooth connectivity.

My phone's visibility — To allow your device to be visible to other Bluetooth devices, select **Shown to all**. To set a length of time, after which the visibility is set from shown to hidden, select **Set visibility period**. To hide your device from other devices, select **Hidden**.

My phone's name — Edit the name of your device. The name is shown to other Bluetooth devices.

Remote SIM mode — Allow another device, such as a compatible car kit accessory, to use the SIM card in your device to connect to the network.

Security tips

Select **Menu > Settings and Connectivity > Bluetooth**.

When you are not using Bluetooth connectivity, to control who can find your device and connect to it, select **Bluetooth > Off** or **My phone's visibility > Hidden**. Deactivating the

Bluetooth function does not affect other functions in your device.





Do not pair with or accept connection requests from an unknown device. This helps to protect your device from harmful content. Operating the device in hidden mode is a safer way to avoid malicious software.

Send data using Bluetooth connectivity

You can have several Bluetooth connections active at a time. For example, if you are connected to a compatible headset, you can also transfer files to another compatible device.

- 1 Open the application where the item you want to send is stored.
- 2 Go to an item, and select **Options > Send > Via Bluetooth**.

Devices with Bluetooth wireless technology that are within range are displayed. Device icons are as follows:

	computer
	phone
	audio or video device
	other device

To interrupt the search, select **Cancel**.

- 3 Select the device with which you want to connect.
- 4 If the other device requires pairing before data can be transmitted, a tone sounds, and you are asked to enter a passcode. The same passcode must be entered in both devices.

When the connection is established, **Sending data** is displayed.

Tip: When searching for devices, some devices may show only the unique address (device address). To find the unique address of your device, in the home screen, enter ***#2820#**.

Pair devices

You can pair your device with a compatible device to make subsequent Bluetooth connections between the devices quicker. Before pairing, create your own passcode (1 to 16 digits), and agree with the owner of the other device to use the same code. Devices that do not have a user interface have a factory-set passcode. The passcode is used only once.

Select **Menu > Settings and Connectivity > Bluetooth**.

- 1 Open the Paired devices tab.
- 2 Select **Options > New paired device**. Devices that are within range are displayed.
- 3 Select the device.
- 4 Enter the passcode on both devices.

⌘ indicates a paired device in the device search view.

Connect to an accessory after pairing

Select **Options > Connect to audio device**. Some audio accessories connect automatically to your device after pairing.

Set a device as authorised

Select **Set as authorised**. Connections between your device and the authorised device can be made without your knowledge. Use this only for your own devices, such as your compatible headset or PC, or devices that belong to someone

you trust. ⌘ indicates authorised devices in the paired devices view.

Cancel a pairing with a device

Select **Options > Delete**.

Cancel all pairings

Select **Options > Delete all**.

Receive data using Bluetooth connectivity

When you receive data using Bluetooth connectivity, a tone sounds, and the device asks you if you want to accept the message. If you accept, ⓧ is displayed, and you can find an informative message about the data in the Inbox folder in Messaging. The received data is automatically saved to the device memory. Messages received using Bluetooth connectivity are indicated with ⓧ.

Block devices

You can prevent devices from establishing a Bluetooth connection to your device.

Select **Menu > Settings and Connectivity > Bluetooth**.

Block a device

On the Paired devices tab, go to a device you want to block, and select **Options > Block**.

Unblock a device

On the Blocked devices tab, go to a device, and select **Options > Delete**.

Unblock all blocked devices

Select **Options > Delete all**.

If you reject a pairing request from another device, you are asked if you want to block all future connection requests from this device. If you accept the query, the device is added to the list of blocked devices.

Remote SIM mode

With remote SIM mode, you can use a compatible car kit accessory. Before remote SIM mode can be activated, the two devices must be paired and the pairing initiated from the other device. When pairing, use a 16-digit passcode, and set the other device as authorised.

Select **Menu > Settings and Connectivity > Bluetooth**.

Activate remote SIM mode

- 1 Activate Bluetooth connectivity. Select **Bluetooth**.
- 2 Activate remote SIM mode in your device. Select **Remote SIM mode**.
- 3 Activate remote SIM mode in the other device.

When remote SIM mode is activated, **Remote SIM mode** is displayed in the home screen. The connection to the wireless network is closed, and you cannot use SIM card services or features that require cellular network coverage.

When your device is in remote SIM mode, you can only make or receive calls using the connected accessory. Your device can only make calls to the emergency numbers programmed into your device.


Deactivate remote SIM mode

Press the power key, and select **Exit remote SIM mode**.

Transfer data using a USB cable



Select **Menu > Settings and Connectivity > USB**.



Select the **USB mode** every time a compatible data cable is connected

Select **Ask on connection > Yes**.

If the **Ask on connection** option is not active, or you want to change the USB mode during an active connection, select **USB connection mode** and from the following:

PC Suite — Use Nokia PC applications such as Nokia Ovi Suite or Nokia Software Updater.

Mass storage — Transfer data between your device and a compatible PC.

Image transfer — Print images using a compatible printer.

Media transfer — Synchronise music with Nokia Music or Windows Media Player.

PC connections

You can use your mobile device with a variety of compatible PC connectivity and data communications applications. With Nokia Ovi Suite you can, for example, transfer files and images between your device and a compatible computer.

To use Ovi Suite with USB connection mode, select **PC Suite**.

For more information about Ovi Suite, see the support area at www.ovi.com.

Administrative settings

Packet data settings

Select **Menu > Settings and Connectivity > Admin. settings > Packet data**.

The packet data settings affect all access points using a packet data connection.

Open a packet data connection whenever the network is available

Select **Packet data connection > When available**.

It is quicker, for example, to send an e-mail, if the connection is always open. If there is no network coverage, the device periodically tries to open a packet data connection.

Open a packet data connection only when needed

Select **Packet data connection > When needed**.

Every time you, for example, send an e-mail, the connection needs to be opened first.

Use HSDPA (network service) in UMTS networks

Select **High speed packet access**.

You can use your device as a modem for your computer, to access the internet over a packet data connection.

Define the access point to use when using your device as a modem

Select **Access point**.

SIP settings

Session Initiation Protocol (SIP) settings are needed for certain network services using SIP. You may receive the settings in a special text message from your service provider. You can view, delete, or create these setting profiles in SIP settings.

Select **Menu > Settings and Connectivity > Admin. settings > SIP settings**.

Internet

With the Web browser, you can view hypertext markup language (HTML) web pages on the internet as originally designed. You can also browse web pages that are designed specifically for mobile devices, and use extensible hypertext markup language (XHTML), or the wireless markup language (WML).


To browse the web, you need to have an internet access point configured in your device. Using the web browser requires network support.

Browse the web

With the Browser application, you can browse web pages.

Select **Menu > Web**.

Go to a web page

From the toolbar, select  **Go to URL or search**, and enter a web address, or to search the web, enter search words in the search field.

Exit full screen mode to see control icons

Select the arrow icon in the bottom right corner. By default, the browser goes back to full screen mode after a few seconds.

Some web pages may contain material, such as video clips, that requires a large amount of memory to view. If your device runs out of memory while loading such a web page, insert a memory card. Otherwise, the video clips are not displayed.

Disable graphics to save memory and speed up downloading

Select **Options > Settings > Page > Load content > Text only**.

Refresh the content of the web page

Select **Options > Web page options > Reload**.

View snapshots of web pages you have visited

Select **Back**. A list of pages you have visited during the current browsing session opens. This option is available if **History list** is activated in the browser settings.

Block or allow the automatic opening of multiple windows

Select **Options > Web page options > Block pop-ups or Allow pop-ups**.

Zoom in and out on a web page

To zoom in, double-tap the display. To zoom back out, double-tap the display again.


Tip: To send the browser to the background without closing the application or connection, press the end key once.


Browser toolbar


The browser toolbar helps you select frequently used functions of the browser.


To open the toolbar when browsing, select the arrow in the bottom right corner.


From the toolbar, select from the following:


 **Expand toolbar** — Expand the toolbar to access more toolbar functions.


 **Go to URL or search** — Enter a web address, or to search the web, enter search words in the search field.


 **Show zoom** — Zoom in or out on the web page.

To use the expanded toolbar, select  **Expand toolbar** and from the following:


 **Go to feeds** — View your current feed subscriptions.

 **Send URL** — Send the web address of the current page to another device.


 **Switch win.** — Switch between open browser windows.


 **Subsc. feeds** — View a list of available web feeds on the current web page, and subscribe to a web feed.


 **Settings** — Modify the settings.

 **Save bkmrk.** — Save the current web page as a bookmark.

 **Reload** — Refresh the web page.

 **Homepage** — Go to the homepage (if defined in settings).

 **Bookmarks** — Open the bookmarks view.



 **Find keywrd.** — Search on the current web page.

Navigate pages

When you are browsing a large web page, you can use Page overview to view the page at a glance.

Select **Menu > Web**.

See an overview of a page

- 1 Select  **Expand toolbar**.
- 2 Select  **Overview**. A miniature image of the current web page opens.

- 3 Move on the miniature image by dragging up, down, left, or right.
- 4 Tap the section you want to view. The web page opens at that section.

Web feeds and blogs

With web feeds, you can easily follow news headlines and your favourite blogs.

Select **Menu > Web**.

Web feeds are XML files on web pages. They are used to share, for example, the latest news headlines or blogs. It is common to find web feeds on web, blog, and wiki pages.

The browser application automatically detects if a web page contains web feeds.

Subscribe to a web feed when a feed is available on the page

Select **Options > Subscribe to web feeds**.

Update a web feed

In the Web feeds view, select a feed and **Options > Web feed options > Refresh**.

Set automatic update for all web feeds



In the Web feeds view, select **Options > Edit > Edit**. This option is not available if one or more feeds are marked.

Content search

With keyword search, you can quickly find the information you are looking for on a web page.

Select **Menu > Web**.

Search for text within the current web page

Select **Options** > **Find keyword**. To go to the previous or next match, from the toolbar, select  **Find next** or  **Find previous**.

Bookmarks

You can store your favourite web pages in Bookmarks for instant access.

Select **Menu** > **Web**.

Access bookmarks

- 1 If you have a page other than Bookmarks as your homepage, select **Options** > **Go to** > **Bookmarks**.
- 2 Select a web address from the list or from the collection of bookmarks in the Recently visited pages folder.

Save the current web page as a bookmark

While browsing, select **Options** > **Web page options** > **Save as bookmark**.

Edit or delete bookmarks


Select **Options** > **Bookmark manager**.

Send or add a bookmark, or set a bookmarked web page as the homepage

Select **Options** > **Bookmark options**.

From the toolbar, select from the following:

 **Add bookmark** — Add a new bookmark.

 **Go to URL or search** — Enter a web address, or to search the web, enter search words in the search field.

 **Delete** — Delete a bookmark.

Empty the cache

Emptying the cache memory helps you keep your data secure. The information or services you have accessed are stored in the cache memory of the device. If you have accessed or tried to access confidential information requiring passwords, empty the cache after each browsing session.

Select **Options** > **Clear privacy data** > **Cache**.

End the connection

End the connection and close the Browser application


Select **Options** > **Exit**.

Delete cookies

Select **Options** > **Clear privacy data** > **Cookies**. Cookies contain information collected about your visits to web pages.

Connection security

With a secure connection and security certificates, you can safely browse the internet.

If the security indicator () is displayed during a connection, the data transmission between the device and the internet gateway or server is encrypted.

The security icon does not indicate that the data transmission between the gateway and the content server (where the data is stored) is secure. The service provider secures the data transmission between the gateway and the content server.

Security certificates may be required for some services, such as banking services.

You are notified if the identity of the server is not authentic or if you do not have the correct security certificate in your device. For more information, contact your service provider.

Important: Even if the use of certificates makes the risks involved in remote connections and software installation considerably smaller, they must be used correctly in order to benefit from increased security. The existence of a certificate does not offer any protection by itself; the certificate manager must contain correct, authentic, or trusted certificates for increased security to be available. Certificates have a restricted lifetime. If "Expired certificate" or "Certificate not valid yet" is shown, even if the certificate should be valid, check that the current date and time in your device are correct.

Before changing any certificate settings, you must make sure that you really trust the owner of the certificate and that the certificate really belongs to the listed owner.

Web settings

With different settings, you can enhance your browsing experience according to your needs.

Select **Menu > Web and Options > Settings**, and from the following:

General settings

Access point — Change the default access point. Some or all access points may be preset for your device by your service provider. You may not be able to change, create, edit, or remove them.

Homepage — Define the homepage.

History list — If you select **On**, while browsing, to see a list of the pages you have visited during the current session, select **Back**.

Web address suffix — Enter a web address suffix that the device uses by default when you enter a web address in the Go to field (for example, .com or .org).

Security warnings — Hide or show security notifications.

Java/ECMA script — Enable or disable the use of scripts.

Java/ECMA script errors — Set the device to receive script notifications.

Open while downloading — Enable the opening of a file while the file is being downloaded.

Page settings

Load content — Select whether you want to load images and other objects while browsing. If you select **Text only**, to load images or objects later during browsing, select **Options > Display options > Load images**.

Default encoding — If text characters are not shown correctly, you can select another encoding according to the language for the current page.

Block pop-ups — Allow or block automatic opening of pop-up windows while browsing.

Automatic reload — Set web pages to be refreshed automatically while browsing.

Font size — Define the font size that is used for web pages.

Privacy settings

Recently visited pages — Enable or disable automatic bookmark collecting. If you want to continue saving the

addresses of the visited web pages into the Recently visited pages folder, but hide the folder from the bookmarks view, select **Hide folder**.

Form data saving — Select whether you want the password data or data you enter on different forms on a web page to be saved and used the next time you open the page.

Cookies — Enable or disable the receiving and sending of cookies.

Web feed settings

Acc. point for auto-update — Select the desired access point for updating. This option is only available when **Automatic updates** is active.

Update when roaming — Activate the automatic updating of web feeds when roaming.

Positioning (GPS)

You can use applications such as GPS data to find out your location, or measure distances and coordinates. These applications require a GPS connection.

About GPS

The Global Positioning System (GPS) is operated by the government of the United States, which is solely responsible for its accuracy and maintenance. The accuracy of location data can be affected by adjustments to GPS satellites made by the United States government and is subject to change with the United States Department of Defense civil GPS policy and the Federal Radionavigation Plan. Accuracy can also be affected by poor satellite geometry. Availability and quality of GPS signals may be affected by your location, buildings, natural obstacles, and weather conditions. GPS signals may not be available inside buildings or underground and may be impaired by materials such as concrete and metal.

GPS should not be used for precise location measurement, and you should never rely solely on location data from the GPS receiver and cellular radio networks for positioning or navigation.

The trip meter has limited accuracy, and rounding errors may occur. Accuracy can also be affected by availability and quality of GPS signals.

The coordinates in the GPS are expressed using the international WGS-84 coordinate system. The availability of the coordinates may vary by region.

About assisted GPS (A-GPS)

Your device supports A-GPS (network service). When you activate A-GPS, your device receives useful satellite information from an assistance data server over the cellular network. With the help of assisted data, your device can obtain the GPS position faster.

Assisted GPS (A-GPS) is used to retrieve assistance data over a packet data connection, which assists in calculating the coordinates of your current location when your device is receiving signals from satellites.

Your device is preconfigured to use the Nokia A-GPS service, if no service provider-specific A-GPS settings are available. The assistance data is retrieved from the Nokia A-GPS service server only when needed.


You must have an internet access point defined in the device to retrieve assistance data from the Nokia A-GPS service over a packet data connection.

Define an access point for A-GPS

Select **Menu > Applications > Location and Positioning > Positioning server > Access point**. Only a packet data internet access point can be used for this service. Your device asks for the internet access point when GPS is used for the first time.

Hold your device correctly

When using the GPS receiver, ensure you do not cover the antenna with your hand.



Establishing a GPS connection may take from a couple of seconds to several minutes. Establishing a GPS connection in a vehicle may take longer.

The GPS receiver draws its power from the device battery. Using the GPS receiver may drain the battery faster.

Tips on creating a GPS connection

Check the satellite signal status

Select **Menu > Applications > Location and GPS data > Options > Satellite status**.



If your device has found satellites, a bar for each satellite is shown in the satellite info view. The longer the bar, the stronger the satellite signal. When your device has received enough data from the satellite signal to calculate your location, the bar colour changes.

Initially your device must receive signals from at least four satellites to be able to calculate your location. When the initial calculation has been made, it may be


possible to continue calculating your location with three satellites. However, the accuracy is generally better when more satellites are found.

To view the positions of found satellites, select **Chg. view**.

If no satellite signal can be found, consider the following:

- If you are indoors, go outdoors to receive a better signal.
- If you are outdoors, move to a more open space.
- If the weather conditions are bad, the signal strength may be affected.
- Some vehicles have tinted (athermic) windows, which may block the satellite signals.

Ensure you do not cover the antenna with your hand.



Establishing a GPS connection may take from a couple of seconds to several minutes. Establishing a GPS connection in a vehicle may take longer.

The GPS receiver draws its power from the device battery. Using GPS may drain the battery faster.

Position requests

You may receive a request from a network service to receive your position information. Service providers may offer information about local topics, such as weather or traffic conditions, based on the location of your device.

When you receive a position request, the service that is making the request is displayed. Select **Accept** to allow your position information to be sent or **Reject** to deny the request.

Landmarks



With Landmarks, you can save the position information of locations in your device. You can sort the saved locations into different categories, such as business, and add details to them. You can use your saved landmarks in compatible applications.

Select **Menu > Applications > Location and Landmarks**.

Select **Options** and from the following:

New landmark — Create a new landmark. To request position information of your current location, select **Current position**. To enter the position information manually, select **Enter manually**.

Edit — Edit a saved landmark (for example, add a street address).

Add to category — Add a landmark to a category. Select each category to which you want to add the landmark.

Send — Send one or several landmarks to a compatible device.

Create a new landmark category


On the categories tab, select **Options** > **Edit categories**.

GPS data

GPS data is designed to provide route guidance information to a selected destination, position information about your current location, and traveling information, such as the approximate distance to the destination and approximate duration of travel.

Select **Menu** > **Applications** > **Location** and **GPS data**.

Route guidance

 Route guidance shows the straightest route and the shortest distance to the destination, measured in a straight line. It ignores any obstacles on the route, such as buildings and natural obstacles, or differences in altitude. Route guidance is active only when you move. Start the route guidance outdoors to receive the necessary information from the satellites.

Select **Menu** > **Applications** > **Location** and **GPS data** > **Navigation**.


Set your destination

Select **Options** > **Set destination** and a landmark as the destination, or enter the latitude and longitude coordinates.

Clear the destination

Select **Stop navigation**

Retrieve position information


 You can view the position information of your current location and an estimate of the accuracy of the location.

Select **Menu** > **Applications** > **Location** and **GPS data** > **Position**.

Save your current location as a landmark

Select **Options** > **Save position**. Landmarks can be used in other compatible applications and transferred between compatible devices.

Trip meter

 With the trip meter, you can calculate the distance, speed, and time of your trip. Use the trip meter outdoors to receive a better GPS signal.

Select **Menu** > **Applications** > **Location** and **GPS data** > **Trip distance**.

Start calculating the trip distance

Select **Options** > **Start**. The calculated values remain on the display.

Start a new calculation

Select **Options** > **Reset**. This sets the trip distance and time and average and maximum speeds to zero.

Set the odometer and total time to zero

Select **Options** > **Restart**.

The trip meter has limited accuracy, and rounding errors may occur. Accuracy can also be affected by availability and quality of GPS signals.

Positioning settings

Positioning settings define the methods, server, and notation settings used in positioning.

Select **Menu > Applications > Location and Positioning**.

Define positioning methods

Use only the integrated GPS receiver of your device

Select **Integrated GPS**.

Use Assisted GPS (A-GPS) to receive assistance data from a positioning server

Select **Assisted GPS**.

Use information from the cellular network (network service)

Select **Network based**.

Define positioning server

Define an access point and positioning server for network-assisted positioning

Select **Positioning server**.

This is used for assisted GPS or network-based positioning. The positioning server may be preset by your service provider, and you may not be able to edit the settings.

Define notation settings

Select the measurement system to use for speeds and distances

Select **Measurement system > Metric or Imperial**.

Define in which format the coordinate information is displayed in your device

Select **Coordinate format** and the desired format.

Maps

Maps overview



Select **Menu > Maps**.

Welcome to Maps.

Maps shows you what is nearby, helps you plan your route, and guides you where you want to go.

- Find cities, streets, and services.
- Find your way with turn-by-turn directions.
- Synchronise your favourite locations and routes between your mobile device and the Ovi Maps internet service.
- Check weather forecasts and other local information, if available.

Note: Downloading content such as maps, satellite images, voice files, guides or traffic information may involve transmission of large amounts of data (network service).

Some services may not be available in all countries, and may be provided only in selected languages. The services may be network dependent. For more information, contact your network service provider.

Almost all digital cartography is inaccurate and incomplete to some extent. Never rely solely on the cartography that you download for use in this device.


Content such as satellite images, guides, weather and traffic information and related services are generated by third parties independent of Nokia. The content

may be inaccurate and incomplete to some extent and is subject to availability. Never rely solely on the aforementioned content and related services.

View your location and the map

See your current location on the map, and browse maps of different cities and countries.

Select **Menu > Maps and My position**.

When the GPS connection is active,  marks your current or last known location on the map. If the icon's colours are faint, no GPS signal is available.

If only cell ID based positioning is available, a red halo around the positioning icon indicates the general area you might be in. The accuracy of the estimate increases in densely populated areas.

Move on the map

Drag the map with your finger. By default, the map is oriented north.

View your current or last known location

Select .


Zoom in or out

Select **+** or **-**.

If you browse to an area not covered by maps that are stored on your device and you have an active data connection, new maps are automatically downloaded.


Map coverage varies by country and region.

Navigation view



- 1 Route
- 2 Your location and direction
- 3 Compass
- 4 Information bar (speed, distance, time)

Map view



- 1 Selected location
- 2 Indicator area
- 3 Point of interest (for example, a railway station or a museum)
- 4 Information area

Plan a route

Plan your journey, and create your route and view it on the map before setting off.

Select **Menu** > **Maps**.

Create a route

- 1 In the map view, tap a location. To search for an address or place, select **Search**.
- 2 Tap the location's information area (i).
- 3 Select **Add to route**.
- 4 To add another route point, select **Add new route point** and the appropriate option.

Change the order of the route points

- 1 Select a route point.
- 2 Select **Move**.
- 3 Tap the place where you want to move the route point to.

Edit the location of a route point

Tap the route point, and select **Edit** and the appropriate option.

View the route on the map

Select **Show route**.

Navigate to the destination

Select **Show route** > **Options** > **Start driving** or **Start walking**.

Change the settings for a route

The route settings affect the navigation guidance and the way the route is displayed on the map.

- 1 In the route planner view, open the **Settings** tab. To get to the route planner view from the navigation

view, select **Options** > **Route points** or **Route point list**.

- 2 Set the transportation mode to **Drive** or **Walk**. If you select **Walk**, one-way streets are regarded as normal streets, and walkways and routes through, for example, parks and shopping centres, can be used.
- 3 Select the desired option.

Select the walking mode

Open the **Settings** tab, and select **Walk** > **Preferred route** > **Streets** or **Straight line**. **Straight line** is useful on off-road terrain as it indicates the walking direction.

Use the faster or shorter driving route

Open the **Settings** tab, and select **Drive** > **Route selection** > **Faster route** or **Shorter route**.

Use the optimised driving route

Open the **Settings** tab, and select **Drive** > **Route selection** > **Optimised**. The optimised driving route combines the advantages of both the shorter and the faster routes.

You can also choose to allow or avoid using, for example, motorways, toll roads, or ferries.

Get traffic and safety information

Enhance your driving experience with real-time information about traffic events, lane assistance, and speed limit warnings, if available for your country or region.

Select **Menu** > **Maps** and **Drive**.

View traffic events on the map


During drive navigation, select **Options** > **Traffic info**. The events are displayed as triangles and lines.

Update traffic information

Select **Options** > **Traffic info** > **Update traffic info**.

When planning a route, you can set the device to avoid traffic events, such as traffic jams or roadworks.

Avoid traffic events

In the main view, select  and **Navigation** > **Reroute due to traffic**.

The location of speed cameras may be shown on your route during navigation, if this feature is enabled. Some jurisdictions prohibit or regulate the use of speed camera location data. Nokia is not responsible for the accuracy, or the consequences of using speed camera location data.

Drive to your destination

When you need turn-by-turn directions while driving, Maps helps you get to your destination.

Select **Menu** > **Maps and Drive**.

Drive to a destination


Select **Set destination** and the appropriate option.

Drive to your home

Select **Drive home**.

When you select **Drive home** or **Walk home** for the first time, you are prompted to define your home location. To later

change the home location, do the following:

- 1 In the main view, select .
- 2 Select **Navigation** > **Home Location** > **Redefine**.
- 3 Select the appropriate option.

Tip: To drive without a set destination, select **Map**. Your location is displayed on the centre of the map as you move.

Change views during navigation

Swipe the screen, and select **2D view**, **3D view**, **Arrow view**, or **Route overview**.

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

Walk to your destination

When you need directions to follow a route on foot, Maps guides you over squares, and through parks, pedestrian zones, and even shopping centres.

Select **Menu** > **Maps**.

Walk to a destination

Select **Set destination** and the appropriate option.

Walk to your home

Select **Walk home**.

When you select **Drive home** or **Walk home** for the first time, you are prompted to define your home location. To later change the home location, do the following:

- 1 In the main view, select .

- 2 Select **Navigation > Home Location > Redefine**.
- 3 Select the appropriate option.

Tip: To walk without a set destination, select **Map**. Your location is displayed on the centre of the map as you move.

Share location

Publish your current location to Facebook, together with text and a photo. Your Facebook friends can see your location on a map.

Select **Menu > Maps and Share location**.

To share your location, you need a Nokia account and a Facebook account.

- 1 Select **Share location**.
- 2 Sign in to your Nokia account, or, if you do not yet have one, select **Create new account**.
- 3 Sign in to your Facebook account.
- 4 Select your current location.
- 5 Enter your status update.
- 6 To attach a photo to your post, select **Add a photo**.
- 7 Select **Share location**.

Manage your Facebook account

In the main view, select **Accounts > Share location settings > Facebook**.

Sharing your location and viewing the location of others requires an internet connection. This may involve the transmission of large amounts of data and related data traffic costs.

The applicable Facebook terms of use apply to sharing your location to

Facebook. Familiarise yourself with the Facebook terms of use and the privacy practices, and use appropriate consideration before disclosing your location data to others or viewing the location of others.


Before sharing your location, always consider carefully with whom you are sharing. Check the privacy settings of the social network you are using as you might share your location with a large group of people.

Save places and routes


Save addresses, places of interest, and routes, so they can be quickly used later.

Select **Menu > Maps**.

Save a place

- 1 In the map view, tap the location. To search for an address or place, select **Search**.
- 2 Tap the location's information area .
- 3 Select **Save place**.

Save a route

- 1 In the map view, tap the location. To search for an address or place, select **Search**.
- 2 Tap the location's information area .
- 3 To add another route point, select **Add to route**.
- 4 Select **Add new route point** and the appropriate option.
- 5 Select **Show route > Options > Save route**.

View your saved places and routes

Select **Favourites** > **Places** or **Routes**.

Send places to your friends

When you want to share place information with your friends, send these details directly to their devices.

Send a place to your friend's compatible device

Select a location on the map, tap the location's information area (i), and select **Send**.

Change the look of the map

View the map in different modes, to easily identify where you are.

Select **Menu** > **Maps** and **My position**.

Select  and from the following:

Map view — In the standard map view, details such as location names or motorway numbers, are easy to read.

Satellite view — For a detailed view, use satellite images.

Terrain view — View at a glance the ground type and altitude, for example, when you are travelling off-road.

3D — For a more realistic view, change the perspective of the map.

Landmarks — Display prominent buildings and attractions on the map.

Night mode — Dim the colours of the map. When travelling at night, the map is easier to read in this mode.


Camera

Your device supports an image capture resolution of 2592x1944 pixels (5 megapixels). The image resolution in this guide may appear different.

To ensure good quality photos, wipe the camera lens carefully with a cleaning cloth.

Image capture

Capture and recording settings



To open the capture and recording settings view before capturing an image or recording a video clip, select **Menu** > **Applications** > **Camera** and .



The capture and recording settings view provides you with shortcuts to different items and settings before capturing an image or recording a video clip.


The capture and recording settings return to the default settings after you close the camera.


Select from the following:

A Select the scene.

 or  Switch between video and image mode.


 or  Show or hide the viewfinder grid (images only).


 Activate the self-timer (images only).


 Activate sequence mode (images only).


 Open **Photos**


Image settings:

 Select a colour effect.

 Adjust the white balance. Select the current lighting conditions. This allows the camera to reproduce colours more accurately.

 Adjust the exposure compensation (images only). If you are shooting a dark subject against a very light background, such as snow, adjust the exposure to +1 or +2 to compensate for the background brightness. For light subjects against a dark background, use -1 or -2.

 Adjust light sensitivity (images only). Increase the light sensitivity in low light conditions to avoid too dark images and blurry images. Increasing the light sensitivity may also increase the image noise.

 Adjust contrast (images only). Adjust the difference between the lightest and darkest parts of the image.

 Adjust sharpness (images only).

The screen display changes to match the settings you define.



The capture settings are shooting-mode specific. Switching between the modes does not reset the defined settings.

If you select a new scene, the capture settings are replaced by the selected scene. You can change the capture settings after selecting a scene if needed.


Saving the captured image may take longer if you change the zoom, lighting, or colour settings.

Capture an image

When capturing an image, note the following:

- Use both hands to keep the camera steady.
 - The quality of a digitally zoomed image is lower than that of a non-zoomed image.
 - The camera goes into battery saving mode after about a minute of inactivity.
 - Keep a safe distance when using the flash. Do not use the flash on people or animals at close range. Do not cover the flash while taking a picture.
- 1 To switch from video mode to image mode, if necessary, select  > .
 - 2 Press the capture key. Do not move the device before the image is saved and the final image displayed.

Capture images with the secondary camera

- 1 Select **Options** > **Use secondary camera**.
- 2 To capture an image, select . Do not move the device before the image is saved and the final image displayed.

Zoom in or out when capturing an image

Use the zoom slider.

Leave the camera open in the background and use other applications

Press the menu key. To return to the camera, press and hold the capture key.

On-screen controls and indicators for still image capture

The still image viewfinder displays the following:



- 1 Capture mode indicator
- 2 Zoom slider. To activate or deactivate the zoom slider, tap the screen.
- 3 Capture icon. Select to capture an image.
- 4 Flash mode. Select to change settings.
- 5 Capture settings. Select to change settings.
- 6 Battery charge level indicator
- 7 Image resolution indicator
- 8 Image counter (the estimated number of images you can capture using the current image quality setting and available memory)
- 9 Memory in use. Depending on the setup of your device, there are the following options: device memory (📁), memory card (📁).
- 10 GPS signal indicator

Location information

You can automatically add capture location information to the file details of the captured material. For example, in the Photos application, you can then view the location where an image was captured.

Select **Menu > Applications > Camera**.

Add location information to all captured material

Select **Options > Settings > Show GPS info > On**. The location information is available only for images captured with the main camera.


Location information can be attached to an image or a video clip if location coordinates can be determined via network and GPS. If you share an image or a video clip which has location information attached, the location information is visible to others that view the image or the video clip. You can deactivate geotagging in the camera settings.

It may take several minutes to obtain the coordinates of your location. The availability and quality of GPS signals may be affected by your location, buildings, natural obstacles, and weather conditions. If you share a file that includes location information, also the location information is shared, and your location may be visible to third parties viewing the file. The device requires network services to acquire location information.

Location information indicators:


📶 — Location information unavailable. GPS stays active in the background for several minutes. If a satellite connection is made and the indicator changes to 📍 within that time, all the images captured and video clips recorded during that time are tagged based on the received GPS positioning information.


📍 — Location information is available. Location information is added to the file details.

Files with location information are indicated with  in the Photos application.

After capturing an image

After you capture an image, select from the following options (available only if you have selected **Options > Settings > Show captured image > Yes**):

 — Send the image in a multimedia or e-mail message, or through connection methods such as Bluetooth connectivity.

 — Upload the image to a compatible online album.

 **Delete** — Delete the image.

To use the image as wallpaper in the home screen, select **Options > Use image > Set as wallpaper**.





To set the image as a default call image to be used for every call situation, select **Options > Use image > Set as call image**.

To assign the image to a contact, **Options > Use image > Assign to contact**.

To return to the viewfinder to capture a new image, press the capture key.

Flash and video light

The camera of your device has a dual LED flash for low light conditions.

To select the desired flash mode, select the current flash mode indicator, which is one of the following:  **Automatic**,  **Reduce red**,  **On**, and  **Off**.

Avoid touching the flash LEDs when the back cover has been removed. The LEDs may get hot after prolonged usage.

Keep a safe distance when using the flash. Do not use the flash on people or animals at close range. Do not cover the flash while taking a picture.

Increase light levels when recording video in low light

Select .

Scenes

A scene helps you to find the right colour and lighting settings for the current environment. The settings of each scene have been set according to a certain style or environment.

The default scene in image and video modes is indicated with **A** (Automatic).

Change the scene

Select  **> Scene modes** and a scene.

Create your own scene suitable for a certain environment

Select **User defined** and **Edit**. In the user defined scene, you can adjust different lighting and colour settings.

Copy the settings of another scene

Select **Based on scene mode** and the desired scene. To save the changes and return to the scenes list, select **Back**.

Activate your own scene



Select **User defined > Select**.

Capture images in a sequence

Select **Menu > Applications > Camera**.

Sequence mode is available only in the main camera. To use sequence mode, you need to have enough memory available.

Set the camera to capture images in a sequence

- 1 Select  > **Sequence**. To close the settings view, select .
- 2 Press and hold the capture key. The device captures images until you select **Stop**, or until 18 images have been captured.

Deactivate sequence mode

Select  > **Single shot**.



The captured images are displayed in a grid. To view an image, select the image. To return to the sequence mode viewfinder, press the capture key.

You can also use sequence mode with the self-timer.

Self-timer

Use the self-timer to delay the capture, so that you can include yourself in the image.




Set the self-timer delay

Select  >  and the delay desired before the image is captured.

Activate the self-timer

Select **Activate**. The stopwatch icon on the screen blinks and the remaining time is displayed when the timer is running. The camera captures the image after the selected delay elapses.




Deactivate the self-timer

Select  >  > .

Tip: To keep your hand steady when capturing an image, try using a delay of 2 seconds.


Video recording

Record a video clip

- 1 To switch from image mode to video mode, if necessary, select  > .
- 2 To start recording, press the capture key, or select . A red record icon is displayed.
- 3 To pause recording, select **Pause**. To resume, select **Continue**. If you pause recording and do not press any key within one minute, the recording stops.
To zoom in or out, use the zoom keys.
- 4 To stop recording, press the capture key. The video clip is automatically saved in **Photos**.

Video recording on-screen controls and indicators

The video viewfinder displays the following:






- 1 Capture mode indicator
- 2 Audio muted
- 3 Capture icon. Select to record video clips.
- 4 Video light indicator

- 5 Recording settings. Select to change settings.
- 6 Battery charge level indicator
- 7 Video quality indicator. To change this setting, select **Options > Settings > Video quality**.
- 8 Video clip file type
- 9 Available recording time. When you are recording, the current video length indicator also shows the elapsed and remaining time.
- 10 The location to which the video clip is saved
- 11 GPS signal indicator

After recording a video clip

After you record a video clip, select from the following options (available only if you have selected **Options > Settings > Show last captured video > Yes**):

-  **Play** — Play the video clip you just recorded.
-  — Upload the image to a compatible online album.
-  **Delete** — Delete the video clip.

To return to the viewfinder to record a new video clip, press the capture key.

Camera settings

Still image camera settings

Select **Menu > Applications > Camera**.

To change the main settings, in image mode, select **Options > Settings** and from the following:

Image quality — Set the resolution. The higher the image resolution, the more memory the image consumes.

Show captured image — View the image after it is captured, or continue image capturing immediately.

Default image name — Define the default name for captured images.

Capture tone — Set the tone that sounds when you capture an image.

Memory in use — Select where to store your images.

Show GPS info — To add GPS location coordinates to each image file, select **On**. Receiving a GPS signal may take time, or the signal may not be available.

Auto-rotate images — Select whether you want images that are captured when the device is held upright to be rotated when you open them in Photos.

Restore camera settings — Restore the camera settings to the default values.

Video settings

Select **Menu > Applications > Camera**.

To modify the main settings, in video mode, select **Options > Settings** and from the following:

Video quality — Set the quality of the video clip. To send a video clip in a multimedia message, select **Sharing**. The clip is recorded in QCIF resolution, in the 3GPP file format, and the size is limited to 600 kB (approximately one minute). You may not be able to send video clips saved in the MPEG4 file format in a multimedia message.

Show GPS info — To automatically add GPS location coordinates to video clips, select **On**. Receiving the GPS signal may take time, or the signal may not be available.

Location information can be attached to an image or a video clip if location coordinates can be determined via network and GPS. If you share an image or a video clip which has location

information attached, the location information is visible to others that view the image or the video clip. You can deactivate geotagging in the camera settings.

Audio recording — Record sound.

Show last captured video — View the first frame of the recorded video clip after the recording stops. To view the entire video clip, select **Play** ▶.

Default video name — Enter the default name for recorded video clips.

Memory in use — Select where to store your video clips.

Restore camera settings — Restore the camera settings to the default values.

Photos

About Photos

With Photos, you can view images and video clips you have captured and recorded, downloaded from the web, received in a multimedia or e-mail message, saved on a memory card, or copied to your device memory from a memory card or other sources.

Select **Menu** > **Photos** and from the following:

Captured — View all the images and video clips you have captured and recorded.

Months — View images and video clips categorised by the month they were captured or recorded. Applicable only for content captured or recorded with your device.

Albums — View the default albums and the ones you have created.

Tags — View the tags you have created for each item.

All — View all images and video clips on your device.

Share online — Post your images or video clips to the web.

Copy or move files to another memory location

Select a file, **Options** > **Organise**, and the appropriate option.

View images and video clips

Select **Menu** > **Photos**.



The images and video clip files are ordered by date and time. The number of files is displayed.

Browse the files

Swipe up or down.

Open a file

Select the file.

To view the toolbar, tap the image. To zoom in the image, use the zoom slider. The zooming ratio is not stored permanently.

Edit an image or a video clip

Select the file and **Options** > **Edit**.

View the details of an image

Select the file and **Options** > **Details**.

Print your images on a compatible printer

Select **Options** > **Print**.

Images and video clips can also be sent to you from a compatible device. To be able to view a received image or video clip in Photos, you must first save it.

View and edit file details

Select **Menu** > **Photos**.

To view and edit the properties of an image or a video clip, select the file, **Options** > **Details**, and from the following:

Name — View the thumbnail image of the file and the current file name. To edit the file name, select the file name field.

Description — View a free-form description of the file. To add a description, select the field.

Tag — View the currently used tags. To add more tags to the current file, select **New tag**.

Album — View in which albums the current file is located.

Location — View GPS location information, if available.

Resolution — View the size of the image in pixels.

Duration — View the length of the video clip.

Licence — View the digital rights management (DRM) rights of the current file.

The available options may vary.

Organise images and video clips

Select **Menu** > **Photos**.

View items by months

Select **Months**.

Create an album to store items

Select **Albums > Options > New album**.

Add an image or a video clip to an album

Select the item and **Options > Add to album**.

Delete an image or video clip

Select the item and **Delete** from the active toolbar.

View items in the Tags view

Select **Tags** and a tag. You must first add tags to the items.

Photos toolbar

From the active toolbar, select the desired option. The available options vary depending on the view you are in and whether you have selected an image or a video clip.

When viewing an image or a video clip in full screen mode, tap the item to show the toolbar and the zoom slider.

Select an image or a video clip and from the following:



Send the image or video clip.



Mark the image or video clip.



Upload the image or video clip to a compatible online album (only available if you have set up an account for a compatible online album).

Albums

With albums, you can conveniently manage your images and video clips.

Select **Menu > Photos and Albums**.

Create a new album

Select .

Add an image or a video clip to an album

Select the item and **Options > Add to album**. A list of albums opens. Select the album to which you want to add the image or video clip. The item you added to the album is still visible in Photos.

Remove an image or a video clip from an album

Select the album and the item, and **Options > Remove from album**.

Tags

With tags, you can categorise media items in Photos. The tag browser shows the currently used tags and the number of items associated with each tag.

Select **Menu > Photos**.

Assign a tag to an image

Select the image and **Options > Add tag**. To create a tag, select **New tag**.

View the tags you have created

Select **Tags**. The size of a tag name corresponds to the number of items the tag is assigned to.

View all the images associated with a tag

Select the tag from the list.

Sort the tags by name

Select **Options > Name**.

Sort the tags by popularity

Select **Options > Popularity**.

Remove an image from a tag

Select the tag and the image, and select **Options** > **Remove from tag**.

Slide show

Select **Menu** > **Photos**.

To view your images as a slide show, select an image and **Options** > **Slide show** > **Play**. The slide show starts from the selected file.

To view only a selection of images as a slide show, select **Options** > **Mark/Unmark** > **Mark** to mark the images. To start the slide show, select **Options** > **Slide show** > **Play**.

To resume a paused slide show, select **Continue**.

To end the slide show, select **Back**.

Before starting the slide show, to adjust the slide show settings, select **Options** > **Slide show** > **Settings** and from the following:

Image order — Display images from older to newer or vice versa.

Song — Select a music file from the list.

Transition speed — Adjust the tempo of the slide show.

To adjust the volume during the slide show, use the volume keys.

Edit images**Image editor**

Select **Menu** > **Photos**.

Edit an image

Tap the image, and select **Options** > **Edit**.

Add effects to your images

Select **Options** > **Add effect**. You can crop and rotate the image; adjust the brightness, colour, contrast, and resolution; and add effects, text, clip art, or a frame to the image.

Crop images

Select **Menu** > **Photos**.

Crop an image


Select **Options** > **Add effect** >  (**Crop**).

Crop an image manually

Select **Manual**. A cross is displayed in the upper left and lower right corner of the image. To adjust the crop borders, drag the crosses from the corners. To set the crop area, select **Set**. When the crop area is set, you can drag to move the crop area without changing the size or aspect ratio. When you are satisfied with the crop area, select **Crop**.

If you select a predefined aspect ratio, the selected aspect ratio is locked when you adjust the crop borders.

Reduce red-eye

- 1 Select **Menu** > **Photos**.
- 2 Select an image and **Options** > **Edit** > **Options** > **Add effect** >  (**Red-eye reduction**).
- 3 Drag the cross onto the eye, and select **Options** > **Set**. Drag to resize and move the loop to outline the eye, and select **Options** > **Reduce red-eye**.

effect. When you have finished editing the image, select **Done**.

- 4 To save the changes and return to the previous view, select **Back**.

Edit videos

The video editor supports .3gp and .mp4 video file formats, and .aac, .amr, .mp3, and .wav audio file formats. It does not necessarily support all features of a file format or all the variations of file formats.

To edit video clips in Photos, scroll to a video clip, select **Options** > **Edit**, and from the following:

Merge — to add an image or a video clip to the beginning or the end of the selected video clip

Change sound — to add a new sound clip, and to replace the original sound in the video clip.

Add text — to add text to the beginning or the end of the video clip

Cut — to trim the video and mark the sections you want to keep in the video clip

To take a snapshot of a video clip, in the cut video view, select **Options** > **Take snapshot**. In the thumbnail preview view, press the scroll key, and select **Take snapshot**.

Image print

You can print images from your device using a printer compatible with PictBridge. You can only print images that are in the JPEG file format.

To print images in Photos, camera, or image viewer, mark the images, and select **Options** > **Print**.

Connect to printer

In the Print submenu, select whether you want to print the image using Bluetooth connectivity or using a compatible USB data cable.

If you want to print using a USB data cable, first connect your device to a compatible printer using the USB data cable, and select **Image transfer** as the USB connection mode.

Print preview

After you select the printer, the selected images are displayed using predefined layouts.

Change the layout of the preview

Browse through the available layouts for the selected printer. If the images do not fit on a single page, swipe up or down to display the additional pages.

Select the paper size

Select **Options** > **Print settings** > **Paper size**.

Select the print quality

Select **Options** > **Print settings** > **Print quality**.

Share online

You can share images and video clips in compatible online albums, weblogs, or in other compatible online sharing services on the web. You can upload content, save unfinished posts as drafts and continue later, and view the content of the albums. The supported content types may vary depending on the service provider.

To share images and videos online, you must have an account with an online image sharing service. You can usually

subscribe to such a service on the web page of your service provider. Contact your service provider for more information.

Using this service may involve the transmission of large amounts of data through your service provider's network. Contact your service provider for information about data transmission charges.

The recommended connection method is WLAN.

To upload a file from Photos to an online service, select **Menu > Photos**, the desired file and **Options > Send > Upload or Share on Ovi**.

For more information on the application and compatible service providers, see the Nokia product support pages or your local Nokia website.

Music

Warning:

Continuous exposure to high volume may damage your hearing. Listen to music at a moderate level, and do not hold the device near your ear when the loudspeaker is in use.

Play a song or podcast

Select **Menu > Music > Music library**.

Start playing

- 1 Select the songs or podcasts you want to play.
- 2 To play an item, select the item from the list.

Pause, resume, or stop playback

To pause playback, select ; to resume, select .

Fast-forward or rewind a song

Select and hold or .

Play songs in random order

Select **Options > Shuffle play** to play songs randomly ().

Repeat the current item or all items

Select **Options > Repeat** to repeat the current item () or all items (.

If you play podcasts, shuffle and repeat are automatically deactivated.

Modify the tone of the music playback

Select **Options > Equaliser**.

Modify the balance and stereo image, or enhance the bass

Select **Options** > **Settings**.


Return to the home screen, and leave the player playing in the background

Press the end key.

Close Music player

Select **Options** > **Exit**.

Playlists

 With playlists, you can create selections of songs to play in a specific order.

Select **Menu** > **Music** > **Music library and Playlists**.

Create a playlist

- 1 Select **Options** > **New playlist**.
- 2 Enter a name for the playlist, and select **OK**.
- 3 To add songs now, select **Yes**. To add the songs later, select **No**.
- 4 If you select **Yes**, select artists to find the songs you want to add to the playlist. To add items, select **Add**.
To display or hide the songs under an artist, select **Expand** or **Collapse**.
- 5 When you have made your selections, select **Done**.
If a compatible memory card is inserted, the playlist is saved to the memory card.

View the details of the playlist

Select **Options** > **Playlist details**.

Add more songs when viewing the playlist

Select **Options** > **Add songs**.

Add songs, albums, artists, genres, or composers to a playlist

Select an item and **Options** > **Add to playlist** > **Saved playlist** or **New playlist**.

Remove a song from a playlist

Select **Options** > **Remove**.

This does not delete the song from the device; it only removes it from the playlist.

Reorder the songs in a playlist

- 1 Select the song you want to move and **Options** > **Reorder playlist**.
- 2 Move the song into the desired position, and select **Drop**.
- 3 To move another song, select the song and **Grab**, move the song into the desired position, and select **Drop**.
- 4 To finish reordering the playlist, select **Done**.

Podcasts

Select **Menu** > **Music** > **Music library and Podcasts**.

Podcast episodes have three states: never played, partially played, and completely played. If the state is partially played, the episode plays from the last playback position the next time it is played. If the state is never played or completely played, the episode plays from the beginning.

Transfer music from a computer

You can use the following methods to transfer music.

Manage and organise your music files with Nokia Music

Download the PC software from www.music.nokia.com/download, and follow the instructions.

Synchronise music with Windows Media Player

Connect a compatible USB data cable, and select **Media transfer** as the connection mode. A compatible memory card must be inserted in the device.

Use your device as a mass memory

To view your device on a computer as a mass memory device where you can transfer any data files, make the connection with a compatible USB data cable or Bluetooth connectivity.

If you are using a USB data cable, select **Mass storage** as the connection mode. A compatible memory card must be inserted in the device.

Change the default USB connection mode

Select **Menu > Settings and Connectivity > USB > USB connection mode**.

Ovi Music

With Ovi Music (network service), you can search, browse, purchase, and download music to your device.

The Ovi Music service will eventually replace the Music store.

Select **Menu > Music > Ovi Music**.

To download music, you first need to register for the service.

Downloading music may involve additional costs and the transmission of large amounts of data (network service). For information about data transmission charges, contact your network service provider.

To access Ovi Music, you must have a valid internet access point in the device. You may be asked to select the access point to use when connecting to Ovi Music.

Select the access point

Select **Default access point**.

The availability and appearance of Ovi Music settings may vary. The settings may also be predefined and you may not be able to modify them. When browsing Ovi Music, you may be able to modify the settings.

Modify Ovi Music settings

Select **Options > Settings**.

Ovi Music is not available for all countries or regions.

Nokia Podcasting About Podcasting



With the Podcasting application, you can find, subscribe to, and download podcasts, and play, manage, and share podcasts.

Downloading and sharing podcasts requires network support.

The recommended connection method is WLAN. For information about data transmission charges and terms, contact your service provider.

Setting the application to retrieve podcasts automatically may involve the transmission of large amounts of data (network service).

Find podcasts

You can find podcasts by searching by keyword or title.

Select **Menu** > **Applications** > **Podcasting**.

Define a podcast search service web address

To use the search service, you need to define a podcast search service web address. Select **Options** > **Settings** > **Connection** > **Search service URL**.

Search for podcasts

Select **Search**, and enter the desired keywords.

Tip: The search service looks for podcast titles and keywords in descriptions, not specific episodes. General topics, such as football or hip-hop, usually give better results than a specific team or artist.

Subscribe to a found podcast

Select the title of the podcast. The podcast will be added to your list of subscribed podcasts.

Start a new search

Select **Options** > **New search**.

Go the website of a podcast

Select **Options** > **Open web page**.

View the details of a podcast

Select **Options** > **Description**.

Play and manage podcasts

Select **Menu** > **Applications** > **Podcasting and Podcasts**.

View the available episodes of a podcast

Select the title of a podcast. A list of episodes is displayed.

Play a fully downloaded episode

Select **Options** > **Play**.

Update a podcast

Select **Options** > **Update**.

Stop the update

Select **Options** > **Stop update**.

Add a new podcast by entering the web address of the podcast

- 1 Select **Options** > **New podcast**.
- 2 Enter the web address of the podcast.
If you do not have an access point defined, or if when attempting to open a packet data connection, you are asked to enter a user name and password, contact your service provider.

Edit the web address of a podcast

Select **Options** > **Edit**.

Delete a downloaded podcast from your device

Select **Options** > **Delete**.

Open the website of the podcast

Select **Options** > **Open web page**.

Comment on the podcast or view comments (if available)

Select **Options** > **View comments**.

Send a podcast to another compatible device

- 1 Select **Options** > **Send**.
- 2 Select the sending method (as .opml files in a multimedia message or by Bluetooth connectivity).

Download podcasts

After you have subscribed to a podcast, you can download, play, and manage the podcast episodes.

Select **Menu** > **Applications** > **Podcasting**.

View a list of subscribed podcasts

Select **Podcasts**.

View individual episode titles

Select the podcast title.

An episode is a particular media file of a podcast.

Start a download

Select the episode title.

You can download multiple episodes at the same time.

Start playing a podcast before the download is complete

Go to a podcast, and select **Options** > **Play preview**.

Successfully downloaded podcasts are stored in the Podcasts folder, but may not be displayed immediately.

Directories

Directories help you find new podcast episodes, to which you can subscribe.

Select **Menu** > **Applications** > **Podcasting**.

Open a directory

Select **Directories**, and the desired directory. If the directory is not up-to-date, selecting it will start the updating process. When the update is complete, select the directory again to open it.

Directories can include podcasts listed by popularity, and themed folders.

Open a themed folder

Select the folder. A list of podcasts is displayed.

Subscribe to a podcast

Go to the title, and select **Subscribe**.

After you have subscribed to a podcast, you can download, manage, and play the podcast episodes in the podcasts menu.

Edit a folder, web link, or web directory

Select **Options** > **Edit**.

Send a directory folder

- 1 Go to a directory in the list.
- 2 Select **Options** > **Send**.
- 3 Select the sending method.

Import an OPML file stored on your device

- 1 Select **Options** > **Import OPML file**.
- 2 Select the location of the file, and import it.

Add a new web directory or folder

- 1 In the Directories view, select **Options** > **New** > **Web directory or Folder**.
- 2 Enter the title and web address of the outline processor markup language (OPML) file.

Podcasting settings

Select **Menu** > **Applications** > **Podcasting**.

To start using Podcasting, define your connection and download settings.

Connection settings

Select **Options** > **Settings** > **Connection** and from the following:

Default access point — Select the access point to use to connect to the internet.

Search service URL — Define the podcast search service web address, to use to search for podcasts.

Download settings

Select **Options** > **Settings** > **Download** and from the following:

Save to — Define where to save podcasts.

Update interval — Define how often podcasts are updated.

Next update time — Define the time of the next automatic update.

Automatic updates only occur if a specific default access point is selected and the Podcasting application is open.

Download limit (%) — Define the percentage of memory that is reserved for podcast downloads.

If limit exceeds — Define what to do if the download limit is exceeded.

Setting the application to retrieve podcasts automatically may involve the transmission of large amounts of data through your service provider's network. For information on data transmission charges, contact your service provider.

Restore default settings

Select **Options** > **Restore default**.

FM radio


Listen to the radio

Select **Menu** > **Music** > **Radio**.

The FM radio depends on an antenna other than the wireless device antenna. A compatible headset or accessory needs to be attached to the device for the FM radio to function properly.

When you open the application for the first time, you can choose to have the local stations tuned automatically.

To listen to the next or the previous station, select  or .

To mute the radio, select .

Select **Options** and from the following:

Stations — View saved radio stations.

Tune stations — Search for radio stations.

Save — Save the radio station.

Activate loudspeaker or **Deactivate loudspeaker** — Turn the loudspeaker on or off.

Alternative frequencies — Select whether you want the radio to automatically search for a better RDS frequency for the station if the frequency level becomes low.

Play in background — Return to the home screen with the radio playing in the background.

Manage radio stations

Select **Menu** > **Music** > **Radio**.

To listen to saved stations, select **Options > Stations**, and select a station from the list.

To remove or rename a station, select **Options > Stations > Options > Delete or Rename**.

To set the desired frequency manually, select **Options > Tune stations > Options > Manual tuning**.

Videos

You can download and stream video clips over the air from compatible internet video services (network service) using a packet data or WLAN connection. You can also transfer video clips from a compatible PC to your device to view them.

Downloading videos may involve the transmission of large amounts of data through your service provider's network. Contact your service provider for information about data transmission charges.

Your device may have predefined services.

Service providers may provide free content or charge a fee. Check the pricing in the service or from the service provider.

Download and play a video clip

Select **Menu > Videos & TV**.

Install a video service

Select **Video feeds > Video directory** and the desired video service.

Add a video feed manually

In the Video feeds view, select **Options > Add feed > Add manually**.

Browse installed video services

Select **Video feeds**. The content of some video services is divided into categories. To browse video clips, select a category.

Search for a video clip

Select **Video search**. Search may not be available in all services.

Download a video clip

Select **Options** > **Download**. Some video clips can be streamed over the air, but others must be first downloaded to your device. Downloads continue in the background if you exit the application. The downloaded video clips are saved in My videos.

Stream a video clip or play a downloaded video clip

Select the Play icon.

To view the control keys during playback, tap the screen.

To adjust the volume, use the volume keys.

Schedule downloads

Schedule an automatic download for video clips in a service

Select **Options** > **Schedule downloads**. New video clips are automatically downloaded daily at the time you define.

Cancel scheduled downloads

Select **Manual download** as the download method.

Setting the application to download video clips automatically may involve the transmission of large amounts of data through your service provider's network. For information about data transmission charges, contact your service provider.

Video feeds

Select **Menu** > **Videos & TV**.

View and manage feeds

Select **Video feeds**.

View video clips available in a feed

Select a feed from the list.

The content of the installed video services is distributed using RSS feeds.

Select **Options** and from the following:

Feed subscriptions — Check your current feed subscriptions.

Feed details — View information about a video feed.

Add feed — Subscribe to new feeds. To select a feed from the services in the video directory, select **Via Video directory**.

Refresh feeds — Refresh the content of all feeds.

Manage account — Manage your account options for a particular feed, if available.

Move — Move video clips to a desired location.

My videos

My videos is a storage place for all videos. You can list downloaded videos and video clips recorded with the device camera in separate views.

To open a folder and view video clips, select the folder. When a video clip is playing, to use the control keys for controlling the player, tap the screen.

To adjust the volume, press the volume key.

Select **Options** and from the following:

Resume download — Resume a paused or failed download.

Cancel download — Cancel a download.

Video clip details — View information about a video clip.

Memory status — View the amount of available and used memory.

Sort by — Sort video clips. Select the desired category.

Move and copy — Move or copy video clips. Select **Copy** or **Move** and the desired location.

Transfer video clips from your PC

Transfer your own video clips from compatible devices using a compatible USB data cable. Only video clips which are in a format supported by your device are displayed.

- 1 To view your device on a PC as a mass memory device where you can transfer any data files, connect using a compatible USB data cable.
- 2 Select **Mass storage** as the connection mode. A compatible memory card needs to be inserted in the device.
- 3 Select the video clips you want to copy from your PC.
- 4 Transfer the video clips to **E:\My Videos** on the memory card.
The transferred video clips appear in the My videos folder.

Videos & TV settings

Select **Menu > Videos & TV**.

Select **Options > Settings** and from the following:

Video service selection — Select the video services that you want to appear in the main view. You can also add, remove, edit, and view the details of a video service. You cannot edit preinstalled video services.

Connection settings — To define the network destination used for the network connection, select **Network connection**. To select the connection manually each time a network connection is opened, select **Always ask**.

Parental control — Set an age limit for video clips. The required password is the same as the device lock code. The factory setting for the lock code is 12345. In video-on-demand services, video clips which have the same or a higher age limit than you have set, are hidden.

Preferred memory — Select where to save downloaded videos. If the selected memory becomes full, the device saves the videos in another memory.

Thumbnails — Select whether to download and view thumbnail images of video feeds.

Personalise your device

You can personalise your device by changing the standby mode, main menu, tones, themes, or font size. Most of the personalisation options, such as changing the font size, can be accessed through the device settings.

Change the look of your device

Select **Menu** > **Settings and Themes**.

You can use themes to change the look of the display, such as the background image.

To change the theme that is used for all the applications in your device, select **General**. To preview a theme before activating it, go to the theme, and wait for a few seconds. To activate the theme, select **Options** > **Set**. ✓ indicates the active theme.

To have an image or a slide show of changing images as the background in the home screen, select **Wallpaper** > **Image** or **Slide show**.

To change the image displayed in the home screen when a call is received, select **Call image**.

Profiles

You can use profiles to set and customise the ringing tones, message alert tones, and other tones for different events, environments, or caller groups. The name of the selected profile is displayed at the top of the home screen. If the General profile is in use, only the date is displayed.

Select **Menu** > **Settings and Profiles**.

Go to a profile, and select from the following:

Activate — Activate the profile.

Personalise — Personalise the profile.

Timed — Set the profile to be active until a certain time within the next 24 hours.

When the time expires, the profile changes back to the previously active non-timed profile. In the home screen, ⌚ indicates a timed profile. The Offline profile cannot be timed.

To create a new profile, select **Options** > **Create new**.

3-D tones

With 3-D tones, you can enable three-dimensional sound effects for ringing tones. Not all ringing tones support 3-D effects.

Select **Menu** > **Settings and Profiles**. Go to a profile, and select **Options** > **Personalise**.

To enable a 3-D effect that is applied to the ringing tone, select **3-D ringing tone effect** and the desired effect.

To change the 3-D echo effect that is applied to the ringing tone, select **3-D ringing tone echo** and the desired effect.

To listen to a 3-D effect before selecting it, go to the effect, and wait for a second.

Modify the home screen

To modify items, such as e-mail notifications, in the home screen, select **Options** > **Edit content**.

To select an image or image slide show as the background image in the home screen, select **Menu** > **Settings** and **Themes** > **Wallpaper**.

To change the clock shown in the home screen, tap the clock in the home screen, and select **Options** > **Settings** > **Clock type**.

Modify the main menu

In the menu you can access the functions in your device. To open the main menu, press the menu key.

To change the menu view, select **Options** > **List view** or **Grid view**.

To reorganise the main menu, select **Options** > **Organise**. For example, to move a menu icon to another folder, select the icon, **Options** > **Move to folder**, and the new folder. You can also drag and drop an icon to a new location in the main menu.

Applications

Calendar

With Calendar you can manage calendar entries, such as meetings, to-do notes, and anniversaries.



Open the calendar

Select **Menu** > **Calendar**.

Calendar views

Select **Menu** > **Calendar**.

Switch between calendar views

Select **Options** > **Change view** > **Day**, **Week**, or **To-do**.

Change the starting day of the week, or modify calendar alarm settings

Select **Options** > **Settings**. The starting day of the week is the view that is displayed when you open the calendar.

Go to a specific date

Select **Options** > **Go to date**.


Calendar toolbar

Select **Menu** > **Calendar**.


From the calendar toolbar, select from the following:


 **Next view** — Select the month view.

 **Next view** — Select the week view.

 **Next view** — Select the day view.

 **Next view** — Select the to-do view.

 **New meeting** — Add a new meeting reminder.

 **New to-do note** — Add a new to-do note.

Create a calendar entry

Select **Menu** > **Calendar**.

- 1 Go to the desired date, and select **Options** > **New entry** and from the following:

Meeting — Set a reminder for your meeting.

Meeting request — Create and send a new meeting request. A mailbox needs to have been set up.

Memo — Write a general note for the day.

Anniversary — Add a reminder of birthdays or special dates (entries are repeated annually).

To-do note — Set a reminder for a task that must be done by a specific date.

- 2 Fill in all the fields. Select a field to enter the text. To close the text input dialog, select **Done**.

To add a description to an entry, select **Options** > **Add description**.

- 3 Select **Done**.

The available options may vary.

Mute or stop a calendar alarm

Select **Silence** or **Stop**.

Set an alarm to snooze

Select **Snooze**.

To define the period after which the calendar alarm sounds again when set to snooze, select **Options** > **Settings** > **Alarm snooze time**.

Manage calendar entries

Select **Menu** > **Calendar**.

Delete several entries at a time

In the month view, select **Options** > **Delete entry** > **Before selected date** or **All entries**.

Mark a task as completed

In the to-do view, go to the task, and select **Options** > **Mark as done**.

Send a calendar note to a compatible device

Select **Options** > **Send**.

If the other device is not compatible with Coordinated Universal Time (UTC), the time information of received calendar entries may not be displayed correctly.

You can synchronise your calendar with a compatible PC using Ovi Suite. When creating a calendar entry, set the desired synchronisation option.

Clock

Set time and date

Select **Menu** > **Applications** > **Clock**.

Select **Options** > **Settings** and from the following:

Time — Set the time.

Date — Set the date.

Automatic time update — Set the network to automatically update the time, date, and time zone information for your device (network service).

Alarm clock

Select **Menu** > **Applications** > **Clock**.

Set a new alarm

- 1 Select **New alarm**.

- 2 Set the alarm time.
- 3 Select **Repeat** to set whether and when the alarm is repeated.
- 4 Select **Done**.

View your alarms

Select **Alarms**.  indicates an active alarm.  indicates a repeated alarm.

Remove an alarm

Select **Alarms**, go to the alarm, and select **Options** > **Delete alarm**.

Stop the alarm

Select **Stop**. If your device is switched off when an alarm expires, your device switches itself on and starts sounding the alarm tone.

Set the alarm to snooze

Select **Snooze**.

Define the snooze time

Select **Options** > **Settings** > **Alarm snooze time**.

Change the alarm tone

Select **Options** > **Settings** > **Clock alarm tone**.

World clock

With the world clock, you can view the current time in different locations.

Select **Menu** > **Applications** > **Clock**.

View the time

Select **World clock**.

Add locations to the list

Select **Options** > **Add location**.

Set your current location

Go to a location, and select **Options** > **Set as current location**. The time in your device is changed according to the selected location. Ensure that the time is correct and matches your time zone.

RealPlayer

With RealPlayer, you can play video clips or stream media files over the air without saving them to the device first.

RealPlayer does not necessarily support all file formats or all the variations of file formats.

Play a video clip

Select **Menu** > **Applications** > **Tools** > **RealPlayer**.

Play a video clip

Select **Video clips** and a video clip.

List recently played files

In the main view, select **Recently played**.

Go to a video clip, and select **Options** and from the following:

Use video clip — Assign a video clip to a contact or set it as a ringing tone.

Mark/Unmark — Mark or unmark an item, to send or delete multiple items at the same time.

View details — View details, such as format, resolution, and duration.

Settings — Edit settings for video playback and streaming.

Stream content over the air

In RealPlayer, you can only open an RTSP link. However, RealPlayer plays a RAM file if you open an HTTP link to it in a browser.

Select **Menu > Applications > Tools > RealPlayer**.

To stream content over the air (network service), select **Streaming links** and a link. You can also receive a streaming link in a text message or multimedia message, or open a link on a web page.

Before live content begins streaming, your device connects to the site and starts loading the content. The content is not saved in your device.

RealPlayer settings

Select **Menu > Applications > Tools > RealPlayer**.

You may receive RealPlayer settings in a special message from your service provider. For more information, contact your service provider.

- 1 To edit the video settings, select **Options > Settings > Video**.
- 2 To select whether to use a proxy server, to change the default access point, and to set the port range used when connecting, select **Options > Settings > Streaming**. For the correct settings, contact your service provider.
- 3 To edit the advanced settings, select **Options > Settings > Streaming > Network > Options > Advanced settings**.
- 4 To select the bandwidth used for a network type, select the network type and the desired value.

To edit the bandwidth yourself, select **User defined**.

Recorder



You can use the recorder to record voice memos and telephone conversations. You can also send sound clips to your friends.

Select **Menu > Applications > Recorder**.

Record a sound clip

Select .

Stop recording a sound clip

Select .


Listen to the sound clip

Select .

Send a sound clip as a message

Select **Options > Send**.

Record a telephone conversation

Open the recorder during a voice call, and select . Both parties hear a tone at regular intervals during recording.

Select the recording quality or where to save sound clips

Select **Options > Settings**.

The recorder cannot be used when a data call or GPRS connection is active.

Notes

About Notes



Select **Menu > Applications > Notes**.

You can write notes and save received plain text files (.txt file format) to the Notes application.

Write a note

- 1 Select **Menu** > **Applications** > **Notes**.
- 2 Select **Options** > **New note**.
- 3 Enter text in the note field.
- 4 Select **Done**.

Manage notes

Select **Menu** > **Applications** > **Notes**.

Select **Options** and from the following:

Open — Open the note.

Send — Send the note to other compatible devices.

Delete — Delete a note. You can also delete several notes at once. To mark each note you want to delete, select **Options** > **Mark/Unmark**, and delete the notes.

Synchronisation — Synchronise the notes with compatible applications on a compatible device, or define the synchronisation settings.

Office

File manager

About File manager

Select **Menu** > **Applications** > **Office** > **File mgr..**

With File manager, you can browse, manage, and open files on your device or a compatible external drive.

Find and organise files

Select **Menu** > **Applications** > **Office** > **File mgr..**

Search for a file

Select **Options** > **Find**. Enter search text that matches the file name.

Move and copy files and folders

Select **Options** > **Organise** and the desired option.

Sort files

Select **Options** > **Sort by** and the desired category.

Edit the memory card

You can format a memory card to erase the data on it, or you can protect the data on the memory card with a password.

Select **Menu** > **Applications** > **Office** > **File mgr..**

Rename or format a memory card

Select **Options** > **Memory card options** and the desired option.

Password protect a memory card

Select **Options** > **Memory card password**.

These options are available only if a compatible memory card is inserted in the device.

Back up files

Select **Menu** > **Applications** > **Office** > **File mgr..**

It is recommended that you back up the device memory regularly to a memory card or a compatible computer.

Back up data from the device memory to a memory card

Select **Options** > **Back up phone memory**.

Restore data from the memory card to the device memory

Select **Options** > **Restore from mem. card**.

You can also connect your device to a compatible computer, and use Nokia Ovi Suite to back up data.

Dictionary

You can translate words from one language to another. Not all languages may be supported.

Look up a word to translate

- 1 Select **Menu** > **Applications** > **Office** > **Dictionary**.
- 2 Enter text in the search field. As you enter text, suggestions of words to translate are displayed.
- 3 Select the word from the list.

Select **Options** and from the following:

Listen — Listen to the selected word.

History — Find previously translated words from the current session.

Languages — Change the source or target language, download languages from the internet, or remove a language from the dictionary. You cannot remove the English language from the dictionary. You can have two additional languages installed, besides English.

Speech — Edit the voice feature settings. You can adjust the speed and volume of the voice.

Quickoffice

About Quickoffice

Select **Menu** > **Applications** > **Office** > **Quickoffice**.

Quickoffice consists of the following:

- Quickword for viewing Microsoft Word documents
- Quicksheet for viewing Microsoft Excel worksheets
- Quickpoint for viewing Microsoft PowerPoint presentations
- Quickmanager for purchasing software

If you have the editor version of Quickoffice, you can also edit files.

Not all file formats or features are supported.

Converter

With Converter, you can convert measures from one unit to another.

The converter has limited accuracy, and rounding errors may occur.

Convert currency

- 1 Select **Menu** > **Applications** > **Office** > **Converter and Options** > **Conversion type** > **Currency**.
- 2 In the second Unit field, select the currency to which you want to convert.
- 3 In the first Amount field, enter the value you want to convert. The second Amount field shows the converted value automatically.

Convert measures

You can convert measures, such as length, from one unit to another.

Select **Menu > Applications > Office > Converter**.

- 1 In the Type field, select the measure to use.
- 2 In the first Unit field, select the unit from which you want to convert.
- 3 In the second Unit field, select the unit to which you want to convert.
- 4 In the first Amount field, enter the value you want to convert. The second Amount field shows the converted value automatically.

Calculator

Make a calculation

- 1 Select **Menu > Applications > Office > Calculator**.
- 2 Enter the first number of the calculation.
To delete a number, press the backspace key.
- 3 Select a function, such as add or subtract.
- 4 Enter the second number of the calculation.
- 5 Select **=**.

This calculator has limited accuracy and is designed for simple calculations.

Save calculations

You can save the result of a calculation and use it in a new calculation. The saved result replaces the previously stored result in the memory.

Save the result of a calculation

Select **Options > Memory > Save**.

Retrieve the result of a calculation

Select **Options > Memory > Recall**.

View the last saved result

Select **Options > Last result**. Exiting the Calculator application or switching off the device does not clear the memory. You can recall the last saved result the next time you open the Calculator application.

Zip manager



Select **Menu > Applications > Office > Zip**.

With Zip manager, you can create new archive files to store compressed ZIP formatted files; add single or multiple compressed files or directories to an archive; set, clear, or change the archive password for protected archives; and change settings, such as the level of compression used.

You can save the archived files in the device memory or on a memory card.

Active notes

About Active notes



Select **Menu > Applications > Active notes**.

Active notes allows you to create notes that contain images and sound or video clips. You can also link a note to a contact. The note is displayed during a call with the contact.

Create and edit notes

Select **Menu > Applications > Active notes**.

Create a note

Start writing.

Edit a note

Select **Options > Editing options**.

Select **Options** and from the following:

Insert object — Insert items to the note.

Send — Send the note to a compatible device.

Link note to call — Select **Add contacts** to link a note to a contact. The note is displayed when making a call to or receiving a call from the contact.

Active notes settings

Select **Menu > Applications > Active notes and Options > Settings**.

Select where to save notes

Select **Memory in use** and the desired memory.

Change the layout of active notes

Select **Change view > Grid or List**.

Display a note during phone calls

Select **Show note during call > Yes**.

Tip: If you temporarily do not want to see notes during phone calls, select **Show note during call > No**. This way you do not have to remove the links between notes and contact cards.

Adobe Reader



Select **Menu > Applications > Office > Adobe PDF**.

With Adobe Reader, you can read PDF documents with your device; search for text in the documents; modify settings, such as zoom level and page views; and send PDF files by mail.

Settings

Some settings may be preset for the device by your service provider, and you may not be able to change them.

Phone settings

Date and time settings

Select **Menu > Settings and Phone > Date and time**.

Select from the following:

Time — Enter the current time.

Time zone — Select your location.

Date — Enter the current date.

Date format — Select the date format.

Date separator — Select the symbol that separates days, months, and years.

Time format — Select the time format.

Time separator — Select the symbol that separates hours and minutes.

Clock type — Select the clock type.

Clock alarm tone — Select the tone for the alarm clock.

Alarm snooze time — Adjust the snooze time.

Workdays — Select your working days. You can then set an alarm only for working day mornings, for example.

Automatic time update — Set the device to update the time, date, and time zone automatically. This network service may not be available on all networks.

Speech

Select **Menu > Settings > Phone > Speech**.

With the Speech application, you can set the language, voice, and voice properties for the Message reader.

Set the language for the Message reader

Select **Language**. To download additional languages to your device, select **Options > Download languages**.

Tip: When you download a new language, you must download at least one voice for that language.

Set the speaking voice

Select **Voice**. The voice depends on the selected language.

Set the speaking rate

Select **Speed**.

Set the speaking volume

Select **Volume**.

View details of a voice

Open the voice tab, and select the voice and **Options > Voice details**. To listen to a voice, select the voice and **Options > Play voice**.

Delete languages or voices

Select the item and **Options > Delete**.

Message reader settings

To change the Message reader settings, open the Settings tab, and define the following:

Language detection — Activate automatic reading language detection.

Continuous reading — Activate continuous reading of all selected messages.

Speech prompts — Set the Message reader to insert prompts in messages.

Audio source — Listen to messages through the earpiece or loudspeaker.

Language settings

Select **Menu > Settings and Phone > Language**.

Change the device language

Select **Phone language**.

Change the writing language

Select **Writing language**.

Activate predictive text input

Select **Predictive text**.

Display settings

Select **Menu > Settings and Phone > Display**.

Select from the following:

Light sensor — Adjust the light sensor sensitivity of your device. The light sensor turns the lights on when the lighting of your location is dim and off when it is bright.

Font size — Select the size of text and icons on the display.

Welcome note / logo — Select whether you want to display a note or image when you switch on the device.

Light time-out — Set how long the light stays on when you stop using the device.

Voice commands

Activate voice commands

Press and hold the call key in the home screen, and say a command. The voice command is the name of the application or profile displayed in the list.

To view the list of voice commands, select **Menu > Settings and Phone > Voice commands**.

Select **Options** and from the following:

Change command — Edit the voice commands.

Playback — Listen to the synthesised voice tag.

Remove voice command — Remove a voice command that you added manually.

Settings — Adjust the settings.

Voice command tutorial — Open the tutorial for voice commands.

Sensor settings and display rotation

When you activate the sensors in your device, you can control certain functions by turning the device.

Select **Menu > Settings and Phone > Sensor settings**.

Select from the following:

Sensors — Activate the sensors.

Turning control — Select **Silencing calls** and **Snoozing alarms** to mute calls and snooze alarms by turning your device so that the display faces down. Select **Auto-rotate display** to rotate the display content automatically when you turn the device on its left side or back to a vertical position. Some applications and features may not support rotating the display content.

Slide settings

Select **Menu > Settings and Phone > Phone mgmt. > Slide settings**.

To set the device to lock the keypad when you close the slide, select **Close slide to lock keypad**.

Accessory settings

Select **Menu > Settings and Phone > Accessories**.

Some accessory connectors indicate which type of accessory is connected to the device.

Select an accessory and from the following:

Default profile — Set the profile you want activated each time you connect a certain compatible accessory to your device.

Automatic answer — Set the device to answer an incoming call automatically after 5 seconds. If the ringing type is set to **Beep once** or **Silent**, automatic answer is disabled.

Lights — Set the lights to remain on after the time-out.

The available settings depend on the type of accessory.

Application settings

Select **Menu > Settings and Phone > Application sett..**

In application settings, you can edit the settings of some of the applications in your device.

To edit the settings, you can also select **Options > Settings** in each application.

Device updates

With Device updates, you can connect to a server and receive configuration settings for your device, create new server profiles, view existing software version and device information, or view and manage existing server profiles.

Select **Menu > Settings and Phone > Phone mgmt. > Device updates.**

If software updates over the air are supported by your network, you may also

be able to request updates through the device.

You may receive server profiles and different configuration settings from your service providers and company information management department. These configuration settings may include connection and other settings used by different applications in your device.

Receive configuration settings

- 1 Select **Options > Server profiles.**
- 2 Go to a profile, and select **Options > Start configuration.**

Create a server profile

Select **Options > Server profiles > Options > New server profile.**

Delete a server profile

Select **Options > Delete.**

Security settings

Phone and SIM

You can define security settings for your device and SIM card. For example, you can change access codes.

Select **Menu > Settings and Phone > Phone mgmt. > Security settings > Phone and SIM card.**

Select from the following:

PIN code request — When active, the code is requested each time the device is switched on. Deactivating the PIN code request may not be allowed by some SIM cards.

PIN code, PIN2 code, and Lock code — Change the PIN code, PIN2 code, and lock code. These codes can only include numbers from 0 to 9. Avoid using

access codes similar to the emergency numbers to prevent accidental dialling of the emergency number. If you forget the PIN or PIN2 code, contact your service provider. If you forget the lock code, contact a Nokia Care point or your service provider.

Phone autolock period — To avoid unauthorised use, set a time-out after which the device automatically locks. A locked device cannot be used until the correct lock code is entered. To deactivate this option, select **None**.

Lock if SIM card changed — Set the device to ask for the lock code when an unknown SIM card is inserted into your device. The device maintains a list of SIM cards that are recognised as the owner's cards.

Remote phone locking — Enable or disable remote lock.

Closed user group — Specify a group of people to whom you can call and who can call you (network service).

Confirm SIM services — Set the device to ask for confirmation when you are using a SIM card service (network service).

Manage certificates

Digital certificates protect your content when transferring confidential information. Certificates should be used when connecting to an online bank or another site, or to a remote server for actions that involve transferring confidential information.

Certificates should also be used when you want to reduce the risk of viruses or other malicious software and be sure of the authenticity of software when downloading and installing software.

Select **Menu > Settings and Phone > Phone mgmt. > Security settings > Certificate management** and select the desired certificate type.

Digital certificates do not guarantee safety; they are used to verify the origin of software.

Important: Even if the use of certificates makes the risks involved in remote connections and software installation considerably smaller, they must be used correctly in order to benefit from increased security. The existence of a certificate does not offer any protection by itself; the certificate manager must contain correct, authentic, or trusted certificates for increased security to be available. Certificates have a restricted lifetime. If "Expired certificate" or "Certificate not valid yet" is shown, even if the certificate should be valid, check that the current date and time in your device are correct.

Security module

The security module provides security services for different applications.

Select **Menu > Settings and Phone > Phone mgmt. > Security settings > Security module** and the desired security module.

View security module details

Select **Options > Security details**.

Restore original settings

You may want to reset some of the settings to their original values. All active calls and connections must be ended.

Select **Menu > Settings and Phone > Phone mgmt. > Factory settings.** To restore the settings, you need to enter the lock code.

After resetting, the device may take a longer time to switch on. Documents and files are unaffected.

Protected content

Digital rights management (DRM) protected content, for example some media files, such as images, music, or video clips, comes with an associated licence that defines your rights to use the content.

You can view the details and status of the licences, and reactivate and remove licences.

Manage digital rights licences

Select **Menu > Settings > Phone > Phone mgmt. > Security settings > Protected content.**

Digital rights management

Content owners may use different types of digital rights management (DRM) technologies to protect their intellectual property, including copyrights. This device uses various types of DRM software to access DRM-protected content. With this device you can access content protected with WMDRM 10, OMA DRM 1.0, and OMA DRM 2.0. If certain DRM software fails to protect the content, content owners may ask that such DRM software's ability to access new DRM-protected content be revoked. Revocation may also prevent renewal of such DRM-protected content already in your device. Revocation of such DRM software does not affect the use of content protected with other types

of DRM or the use of non-DRM-protected content.

Digital rights management (DRM) protected content comes with an associated licence that defines your rights to use the content.

If your device has OMA DRM-protected content, to back up both the activation keys and the content, use the backup feature of Nokia Ovi Suite.

If your device has WMDRM-protected content, both the licence and the content will be lost if the device memory is formatted. You may also lose the licence and the content if the files on your device get corrupted. Losing the licence or the content may limit your ability to use the same content on your device again. For more information, contact your service provider.

Some licence may be connected to a specific SIM card, and the protected content can be accessed only if the SIM card is inserted in the device.

Notification lights

Select **Menu > Settings and Phone > Notificat. lights.**

To turn the standby breathing light on or off, select **Standby br. light.**

When the standby breathing light is turned on, the menu key lights up periodically.

To turn the notification light on or off, select **Notification light.**

When the notification light is turned on, the menu key lights up for a period you

define to notify of missed events, such as missed calls or unread messages.

Application manager

About Application manager



Select Menu > Settings and Application mgr..

With Application manager, you can see the software packages installed in your device. You can view details of installed applications, remove applications, and define installation settings.

You can install the following types of applications and software:

- JME applications based on Java™ technology with .jad or .jar file extensions
- Other applications and software suitable for the Symbian operating system with .sis or .sisx file extensions
- Widgets with the .wgz file extension

Only install software that is compatible with your device.

Install applications

You can transfer installation files to your device from a compatible computer, download them during browsing, or receive them in a multimedia message, as an e-mail attachment, or using other connectivity methods, such as Bluetooth connectivity.

You can use Nokia Application Installer in Nokia Ovi Suite to install an application to your device.

Icons in Application manager indicate the following:



SIS or SISX application



Java application
widgets



application installed in the
memory card

Important: Only install and use applications and other software from trusted sources, such as applications that are Symbian Signed or have passed the Java Verified™ testing.

Before installation, note the following:

- To view the application type, version number, and the supplier or manufacturer of the application, select **Options** > **View details**.

To view the security certificate details of the application, select **Details** > **Certificates** > **View details**. Control the use of digital certificates in Certificate management.

- If you install a file that contains an update or repair to an existing application, you can only restore the original application if you have the original installation file or a full backup copy of the removed software package. To restore the original application, remove the application, and install the application again from the original installation file or the backup copy.

The JAR file is required for installing Java applications. If it is missing, the device may ask you to download it. If there is no access point defined for the application, you are asked to select one.

To install an application, do the following:

- 1 To locate an installation file, select **Menu > Settings and Application mgr.**. Alternatively, search installation files using File manager, or select **Messaging > Inbox**, and open a message that contains an installation file.
- 2 In Application manager, select **Options > Install**. In other applications, select the installation file to start the installation. During installation, the device shows information about the progress of the installation. If you install an application without a digital signature or certification, the device displays a warning. Continue installation only if you are sure of the origin and contents of the application.

To start an installed application, locate the application in the menu, and select the application. If the application does not have a default folder defined, it is installed in the Installed apps. folder in the main menu.

To see which software packages are installed or removed and when, select **Options > View log**.

Important: Your device can only support one antivirus application. Having more than one application with antivirus functionality could affect performance and operation or cause the device to stop functioning.

After you install applications to a compatible memory card, installation files (.sis, .sisx) remain in the device memory. The files may use large amounts of memory and prevent you from storing other files. To maintain sufficient

memory, use Nokia Ovi Suite to back up installation files to a compatible PC, then use the file manager to remove the installation files from the device memory. If the .sis file is a message attachment, delete the message from the Messaging inbox.

Remove applications

You can remove applications that you have installed, for example, to increase the amount of available memory.

Select **Menu > Settings**.

- 1 Select **Application mgr.**
- 2 Select **Installed apps. > Options > Uninstall**.
- 3 Select **Yes**.

If you remove an application, you can only reinstall it if you have the original software package or a full backup of the removed software package. If you remove a software package, you may no longer be able to open documents created with that software.

If another software package depends on the software package that you removed, the other software package may stop working. See the documentation of the installed software package for details.

Application manager settings

Select **Menu > Settings and Application mgr.**

Select **Installation settings** and from the following:

Software installation — Allow or deny installation of Symbian software that does not have a verified digital signature.

Online certificate check — Check online certificates before installing an application.

Default web address — Set the default web address used to check online certificates.

Calling settings

Call settings

With call settings, you can define call specific settings in your device.

Select **Menu > Settings and Calling > Call**.

Select from the following:

Send my caller ID — Select **Yes** to show your phone number to the person you are calling. To use the setting agreed upon with your service provider, select **Set by network** (network service).

Send my internet call ID — Select **Yes** to show your internet call ID to the person you are calling.

Call waiting — Set your device to notify you of incoming calls while you are in a call (network service), or check whether the feature is activated.

Internet call waiting — Set your device to notify you of a new incoming internet call while you are in a call.

Internet call alert — To set your device to alert for incoming internet calls, select **On**. If you select **Off**, you receive only a notification if you missed a call.

Reject call with message — Send a text message when you reject a call, informing the caller why you could not answer the call.

Message text — Write the standard text message that is sent when you reject a call.

Own video in recvd. call — Allow or deny video sending during a video call from your device.

Image in video call — If video is not sent during a video call, select the image to be displayed instead.

Automatic redial — Set your device to make a maximum of 10 attempts to connect the call after an unsuccessful call attempt. To stop automatic redialling, press the end key.

Show call duration — Display the length of a call during a call.

Summary after call — Display the length of a call after a call ends.

Speed dialling — Activate speed dialling.

Anykey answer — Activate anykey answer.

Line in use — This setting (network service) is shown only if the SIM card supports two subscriber numbers, that is, two phone lines. Select which phone line you want to use to make calls or send text messages. Calls on both lines can be answered irrespective of the selected line. If you select **Line 2**, and have not subscribed to this network service, you are not able to make calls. When line 2 is selected, **2** is displayed in the home screen.

Line change — Prevent phone line selection (network service), if supported by your SIM card. To change this setting, you need the PIN2 code.

The available options may vary.


Call divert

You can divert incoming calls to your voice mailbox or another phone number. For details, contact your service provider.

Select **Menu > Settings and Calling > Call divert.**

Divert all voice calls to your voice mailbox or another phone number

- 1 Select **Voice calls > All voice calls.**
- 2 To activate call divert, select **Activate.**
- 3 To divert calls to your voice mailbox, select **To voice mailbox.**
- 4 To divert calls to another phone number, select **To other number**, and enter the number, or select **Find** to retrieve a number saved in the contacts list.

Several diverting options can be active at the same time. In the home screen,  indicates that all calls are diverted.

Call barring affects all calls, including data calls.

Bar an internet call

To select whether anonymous calls are allowed from the internet, select **Anonymous call barring.**

Call barring

With call barring (network service), you can restrict the calls that you make or receive with the device. For example, you can restrict all outgoing international calls or incoming calls when you are abroad. To change the settings, you need the barring password from your service provider.

Select **Menu > Settings and Calling > Call barring.**

When security features that restrict calls are in use (such as call barring, closed user group, and fixed dialling), calls may be possible to the official emergency number programmed into your device. Call barring and call diverting cannot be active at the same time.

Bar a voice call

Select the desired barring option and **Activate, Deactivate, or Check status.**

Troubleshooting

To view frequently asked questions about your device, see the product support pages at www.nokia.com/support.

Q: What is my password for the lock, PIN, or PUK codes?

A: The default lock code is 12345. If you forget the lock code, contact your device dealer. If you forget a PIN or PUK code, or if you have not received such a code, contact your network service provider.

For information about passwords, contact your access point provider, for example, a commercial internet service provider (ISP) or network service provider.

Q: How do I close an application that is not responding?

A: Select **Options > Show open apps.**, and go to the application using the menu key. Press and hold the menu key to open the application, and select **Options > Exit**.

Q: Why do images look smudgy?

A: Ensure that the camera lens protection windows are clean.

Q: Why do missing, discoloured, or bright dots appear on the screen every time I switch on my device?

A: This is a characteristic of this type of display. Some displays may contain pixels or dots that remain on or off. This is normal, not a fault.

Q: Why can't my Nokia device establish a GPS connection?

A: Establishing a GPS connection may take from a couple of seconds to several minutes. Establishing a GPS connection in a vehicle may take longer. If you are indoors, go outdoors to receive a better signal. If you are outdoors, move to a more open space. Ensure that your hand does not cover the GPS antenna of your device. If the weather conditions are bad, the signal strength may be affected. Some vehicles have tinted (athermic) windows, which may block the satellite signals.

Q: Why can't I find my friend's device while using Bluetooth connectivity?

A: Check that both devices are compatible, have activated Bluetooth connectivity, and are not in hidden mode. Check also that the distance between the two devices is not over 10 metres (33 feet) and that there are no walls or other obstructions between the devices.

Q: Why can't I end a Bluetooth connection?

A: If another device is connected to your device, you can close the connection from the other device or deactivate Bluetooth connectivity in your device. Select **Menu > Settings and Connectivity > Bluetooth > Bluetooth > Off**.

Q: Why can't I see a wireless LAN (WLAN) access point even though I know I'm within its range?

A: The WLAN access point may use a hidden service set identifier (SSID). You can only access networks that use a hidden SSID if you know the correct SSID, and have created a WLAN internet access point for the network on your Nokia device.

Q: How do I turn the wireless LAN (WLAN) off on my Nokia device?

A: The WLAN on your Nokia device is deactivated when you are not connected or trying to connect to another access point, or not scanning for available networks. To further reduce battery consumption, you can specify that your Nokia device does not scan, or scans less often, for available networks in the background. The WLAN is deactivated in between background scans.

To change the background scan settings, do the following:

- 1 Select **Menu > Settings and Connectivity > WLAN**.
- 2 To increase the background scan time interval, adjust the time in Scan for networks. To stop background scans, select **Show WLAN availability > Never**.
- 3 To save your changes, select **Back**. When **Show WLAN availability** is set to **Never**, the WLAN availability icon is not displayed in the home screen. However, you can still manually scan for available WLAN networks, and connect to WLAN networks as usual.

Q: What do I do if the memory is full?

A: Delete items from the memory. If **Not enough memory to perform operation. Delete some data first. or Memory low. Delete some data from phone memory.** is displayed when you are deleting several items at the same time, delete items one by one, beginning with the smallest items.

Q: Why can't I select a contact for my message?

A: The contact card does not have a phone number, address, or e-mail address. Select **Menu > Contacts** and the relevant contact, and edit the contact card.

Q: How can I end the data connection when the device starts a data connection again and again?

A: The device may be trying to retrieve a multimedia message from the multimedia message centre. To stop the device from making a data connection, select **Menu > Messaging and Options > Settings > Multimedia message > Multimedia retrieval**. Select **Manual** to have the multimedia messaging centre save messages to be retrieved later, or **Off** to ignore all incoming multimedia messages. If you select **Manual**, you receive a notification when you have a new message in the multimedia message centre. If you select **Off**, the device does not make any network connections related to multimedia messaging.

To set the device to use a packet data connection only if you start an application or action that needs it, select **Menu >**

Settings and Connectivity > Admin. settings > Packet data > Packet data connection > When needed.

If this does not help, switch the device off and then on again.

Q: Can I use my Nokia device as a fax modem with a compatible PC?

A: You cannot use your device as a fax modem. However, with call diverting (network service), you can divert incoming fax calls to a fax number.

Q: How do I calibrate the screen?

A: The screen is calibrated at the factory. If it is necessary to recalibrate the screen, select **Menu > Settings and Phone > Touch input > Touch screen calibration**. Follow the instructions.

Green tips



Here are tips on how you can contribute to protecting the environment.

Save energy

When you have fully charged the battery and disconnected the charger from the device, unplug the charger from the wall outlet.

You do not need to charge your battery so often if you do the following:

- Close and disable applications, services, and connections when not in use.
- Decrease the brightness of the screen.
- Set the device to enter the power saver mode after the minimum period of inactivity, if available in your device.
- Disable unnecessary sounds, such as keypad and ringing tones.

Recycle

Most of the materials in a Nokia phone are recyclable. Check how to recycle your Nokia products at www.nokia.com/werecycle, or with a mobile device, www.nokia.mobi/werecycle.

Recycle packaging and user guides at your local recycling scheme.

Save paper

This user guide helps you get started with your device. For more detailed instructions, open the in-device help (in

most applications, select **Options > Help**). For further support, see www.nokia.com/support.

Learn more

For more information on the environmental attributes of your device, see www.nokia.com/ecodeclaration.

Product and safety information

Accessories

Warning:

Use only batteries, chargers, and accessories approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous. In particular, use of unapproved chargers or batteries may present a risk of fire, explosion, leakage, or other hazard.

For availability of approved accessories, please check with your dealer. When you disconnect the power cord of any accessory, grasp and pull the plug, not the cord.

Battery

Battery and charger information

Your device is powered by a rechargeable battery. The battery intended for use with this device is BL-4J. Nokia may make additional battery models available for this device. This device is intended for use when supplied with power from the following chargers: AC-15. The exact charger model number may vary depending on the type of plug. The plug variant is identified by one of the following: E, EB, X, AR, U, A, C, K, or UB.

The battery can be charged and discharged hundreds of times, but it will eventually wear out. When the talk and standby times are noticeably shorter than normal, replace the battery. Use only Nokia approved batteries, and recharge your battery only with Nokia approved chargers designated for this device.

If a battery is being used for the first time or if the battery has not been used for a prolonged period, it may be necessary to connect the charger, then disconnect and reconnect it to begin charging the battery. If the battery is completely discharged, it may take several minutes before the charging indicator appears on the display or before any calls can be made.

Safe removal. Always switch the device off and disconnect the charger before removing the battery.

Proper charging. Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

Avoid extreme temperatures. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Battery performance is particularly limited in temperatures well below freezing.

Do not short-circuit. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) This might happen, for example, when you carry a spare battery in your pocket or purse. Short-circuiting the terminals may damage the battery or the connecting object.

Disposal. Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Leak. Do not dismantle, cut, open, crush, bend, puncture, or shred cells or batteries. In the event of a battery leak, prevent battery liquid contact with skin or eyes. If this happens, flush the affected areas immediately with water, or seek medical help.

Damage. Do not modify, remanufacture, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged.

Correct use. Use the battery only for its intended purpose. Improper battery use may result in a fire, explosion, or other hazard. If the device or battery is dropped, especially on a hard surface, and you believe the battery has been damaged, take it to a service centre for inspection before continuing to use it. Never use any charger or battery that is damaged. Keep your battery out of the reach of small children.

Nokia battery authentication guidelines

Always use original Nokia batteries for your safety. To check that you are getting an original Nokia battery, purchase it from a Nokia authorised service centre or dealer, and inspect the hologram label using the following steps:

Authenticate hologram

- 1 When you look at the hologram on the label, you should see the Nokia connecting hands symbol from one angle and the Nokia Original Enhancements logo when looking from another angle.



- 2 When you angle the hologram left, right, down and up, you should see 1, 2, 3 and 4 dots on each side respectively.



Successful completion of the steps is not a total assurance of the authenticity of the battery. If you cannot confirm authenticity or if you have any reason to believe that your Nokia battery with the hologram on the label is not an authentic Nokia battery, you should refrain from using it, and take it to the nearest Nokia authorised service centre or dealer for assistance.

To find out more about original Nokia batteries, see www.nokia.com/battery.

Taking care of your device

Your device is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.

- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics. When the device warms to its normal temperature from a cold temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use only the supplied or an approved replacement antenna. Unauthorised antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.
- Use chargers indoors.
- Backup all data you want to keep, such as contacts and calendar notes.
- To reset the device from time to time for optimum performance, power off the device and remove the battery.

These suggestions apply equally to your device, battery, charger, or any accessory.

Recycle

Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled waste disposal and promote the recycling of materials. Check product environmental information and how to recycle your Nokia products at www.nokia.com/werecycle, or nokia.mobi/werecycle.



The crossed-out wheeled-bin symbol on your product, battery, literature, or packaging reminds you that all electrical and electronic products, batteries, and accumulators must be taken to separate collection at the end of their working life. This requirement applies in the European Union. Do not dispose of these products as unsorted municipal waste. For more environmental information, see

the product Eco-Declarations at www.nokia.com/environment.

Additional safety information

Small children

Your device and its accessories are not toys. They may contain small parts. Keep them out of the reach of small children.

Operating environment

This device meets RF exposure guidelines in the normal use position at the ear or at least 1.5 centimetres (5/8 inch) away from the body. Any carry case, belt clip, or holder for body-worn operation should not contain metal and should position the device the above-stated distance from your body.

To send data files or messages requires a quality connection to the network. Data files or messages may be delayed until such a connection is available. Follow the separation distance instructions until the transmission is completed.

Parts of the device are magnetic. Metallic materials may be attracted to the device. Do not place credit cards or other magnetic storage media near the device, because information stored on them may be erased.

Medical devices

Operation of radio transmitting equipment, including wireless phones, may interfere with the function of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external RF energy. Switch off your device when regulations posted instruct you to do so. Hospitals or health care facilities may use equipment sensitive to external RF energy.

Implanted medical devices

Manufacturers of medical devices recommend a minimum separation of 15.3 centimetres (6 inches) between a wireless device and an implanted medical device, such as a pacemaker or implanted cardioverter defibrillator, to avoid potential interference with the medical device. Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimetres (6 inches) from the medical device.
- Not carry the wireless device in a breast pocket.
- Hold the wireless device to the ear opposite the medical device.
- Turn the wireless device off if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Hearing aids

Some digital wireless devices may interfere with some hearing aids.

Hearing aids

Warning:

For hearing aid compatibility, you must turn off the Bluetooth connectivity.

Your mobile device model complies with FCC rules governing hearing aid compatibility. These rules require an M3 microphone or higher value. The M-value, shown on the device box, refers to lower radio frequency (RF) emissions. A higher M-value generally indicates that a device model has a lower RF emissions level, which may improve the likelihood that the device will operate with certain hearing aids. Some hearing aids are more immune than others to interference. Please consult your hearing health professional to determine the M-rating of your hearing aid and whether your hearing aid will work with this device. More information on accessibility can be found at www.nokiaaccessibility.com.

This device has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this device that have not been tested yet for use with hearing aids. It is important to try the different features of this device thoroughly and in different locations, using your hearing aid or cochlear implant, to determine whether you hear any interfering noise. Consult your service provider about its return and exchange policies and for information on hearing aid compatibility.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection, electronic antilock braking, electronic speed control, and air bag systems. For more information, check with the manufacturer of your vehicle or its equipment.

Only qualified personnel should service the device or install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate your warranty. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or accessories. Remember that air bags inflate with great force. Do not place your device or accessories in the air bag deployment area.

Switch off your device before boarding an aircraft. The use of wireless teledevices in an aircraft may be dangerous to the operation of the aircraft and may be illegal.


Potentially explosive environments

Switch off your device in any area with a potentially explosive atmosphere. Obey all posted instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or death. Switch off the device at refuelling points such as near gas pumps at service stations. Observe restrictions in fuel depots, storage, and distribution areas; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include areas where you would be advised to turn off your vehicle engine, below deck on boats, chemical transfer or storage facilities and where the air contains chemicals or particles such as grain, dust, or metal powders. You should check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) to determine if this device can be safely used in their vicinity.

Emergency calls

Important: This device operates using radio signals, wireless networks, landline networks, and user-programmed functions. If your device supports voice calls over the internet (internet calls), activate both the internet calls and the cellular phone. The device will attempt to make emergency calls over both the cellular networks and through your internet call provider if both are activated. Connections in all conditions cannot be guaranteed. You should never rely solely on any wireless device for essential communications like medical emergencies.

To make an emergency call:

- 1 If the device is not on, switch it on. Check for adequate signal strength. Depending on your device, you may also need to complete the following:
 - Insert a SIM card if your device uses one.
 - Remove certain call restrictions you have activated in your device.
 - Change your profile from offline profile mode to an active profile.
 - If the screen and keys are locked, slide the lock switch on the side of the device to unlock them.
- 2 Press the end key as many times as needed to clear the display and ready the device for calls.
- 3 Open the dialler by selecting the dialler icon .
- 4 Enter the official emergency number for your present location. Emergency numbers vary by location.
- 5 Press the call key.

When making an emergency call, give all the necessary information as accurately as possible. Your wireless device may be the only means of communication at the scene of an accident. Do not end the call until given permission to do so.

Certification information (SAR)

This mobile device meets guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organisation ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 watts/kilogram (W/kg) averaged over 10 grams of tissue. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network. That amount changes depending on a number of factors such as how close you are to a network base station.

The highest SAR value under the ICNIRP guidelines for use of the device at the ear is 1.05 W/kg.

Use of device accessories may result in different SAR values. SAR values may vary depending on national reporting and testing requirements and the network band. Additional SAR information may be provided under product information at www.nokia.com.

© 2010 Nokia. All rights reserved.

DECLARATION OF CONFORMITY



Hereby, NOKIA CORPORATION declares that this RM-612 product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of Conformity can be found at http://www.nokia.com/phones/declaration_of_conformity/.

Nokia, Nokia Connecting People, Nokia Original Accessories logo, and Ovi are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited. Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.



This product includes software licensed from Symbian Software Ltd ©1998-2009. Symbian and Symbian OS are trademarks of Symbian Ltd.



Java and all Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc.

Portions of the Nokia Maps software are ©1996-2009 The FreeType Project. All rights reserved.

This product is licensed under the MPEG-4 Visual Patent Portfolio License (i) for personal and noncommercial use in connection with information which has been encoded in compliance with the MPEG-4 Visual Standard by a consumer engaged in a personal and noncommercial activity and (ii) for use in connection with MPEG-4 video provided by a licensed video provider. No license is granted or shall be implied for any other use. Additional information, including that related to promotional, internal, and commercial uses, may be obtained from MPEG LA, LLC. See <http://www.mpegla.com>.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

The third-party applications provided with your device may have been created and may be owned by persons or entities not affiliated with or related to Nokia. Nokia does not own the copyrights or intellectual property rights to the third-party applications. As such, Nokia does not take any responsibility for end-user support, functionality of the applications, or the information in the applications or these materials. Nokia does not provide any warranty for the third-party applications.

BY USING THE APPLICATIONS YOU ACKNOWLEDGE THAT THE APPLICATIONS ARE PROVIDED AS IS WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. YOU FURTHER ACKNOWLEDGE THAT NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE APPLICATIONS WILL NOT INFRINGE ANY THIRD-PARTY PATENTS, COPYRIGHTS, TRADEMARKS, OR OTHER RIGHTS.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

Reverse engineering of software in the device is prohibited to the extent permitted by applicable law. Insofar as this user guide contains any limitations on Nokia's representations, warranties, damages and liabilities, such limitations shall likewise limit any representations, warranties, damages and liabilities of Nokia's licensors.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details and availability of language options. This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

FCC/INDUSTRY CANADA NOTICE

Your device may cause TV or radio interference (for example, when using a telephone in close proximity to receiving equipment). The FCC or Industry Canada can require you to stop using your telephone if such interference cannot be eliminated. If you require assistance, contact your local

service facility. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by Nokia could void the user's authority to operate this equipment.

/Issue 1 EN

Index**Symbols/Numbers**

3-D ringing tones 97

A

A-GPS (assisted GPS) 69

access codes 9

access points 56, 57

accessories 107

accounts 31

Active notes 104, 105

alarm clock 99

albums, media 85

answering calls 34

antennas 14

application settings 108

applications 111, 112

assisted GPS (A-GPS) 68

attachments 50

audio messages 49

B

background image 97

backing up data 102

backing up device memory 102

barring calls 114

battery

— charging 15

— inserting 13

— saving power 10

blocking

— device 61

blogs 65

Bluetooth 59, 60, 61, 62

bookmarks 64, 66

browser 64, 66

— browsing pages 65

— cache memory 66

— searching content 65

— security 66

— settings 67

— toolbar 64

C

cable connection 62

cache memory 66

calculator 104

calendar 98, 99

call log 41

call waiting 35

calls 33

— answering 34

— conference 35

— dialled numbers 25

— duration of 41

— ending 35

— options 33

— redialling 113

— rejecting 34

— restricting 45

— settings 113

— video calls 36

camera

— assigning images to contacts 80

— capturing images 78

— flash 80

— image mode 78

— image quality 82

— indicators 79, 81

— location information 79

— options 80

— recording 82

— scenes 80

— sending images 80

— sequence mode 80

— settings 77, 82

— video mode 81

— video quality 82

cell broadcast messages 51, 53

certificates 109

charger, battery 15

chat services (IM) 29

clock	97, 99, 100
computer connections	62
<i>See also data connections</i>	
conference calls	35
connectivity	58
connectors	12
contacts	42, 43, 44
— adding	42
— copying	44
— defaults	43
— editing	42
— favourites	23
— groups	45
— managing	43
— ringing tones	44
— saving	42
— searching	34
— synchronising	59
— voice tags	43
converter for currency	103
converter for measurements	104
cookies	66
copyright protection	110
currency converter	103

D

data connections	58
— Bluetooth	59
— PC connectivity	62
— synchronisation	59
date and time	106
declining calls	
<i>See rejecting calls</i>	
device	
— updating	108
dictionary	103
dismissing calls	34
display settings	107
downloads	
— podcasts	92
DRM (digital rights management)	110
duration of calls	41

E

e-mail	46, 48
— attachments	47
— creating	47
— mailbox	46
— reading and replying to	47
— sending	47
— setup	46

F

factory settings, restoring	109
favourites	44
feeds, news	65
file management	102
file manager	102
fixed dialling	45
FM radio	93

G

general information	8
GPS	69
— position requests	70
GPS (Global Positioning System)	68
GPS (global positioning system)	68, 71

H

headset	20
help application	8
home screen	22, 23, 97
— contacts	23
HSDPA (high-speed downlink packet access)	26

I

IAPs (internet access points)	56
icons	23
IM (instant messaging)	29
images	
— editing	86
— sharing online	87
inbox, message	50
inbox, messages	50

indicators	23, 50
installing applications	111
internet browser	64
internet calls	40
— settings	40
internet connection	64
See also <i>browser</i>	

J

Java applications	111
-------------------	-----

K

keyboard	17
keypad lock	20
keys and parts	12

L

landmarks	70
language settings	107
licences	110
location information	68, 71
lock code	9, 15
lock switch	20
locking	
— remotely	10
logs	41
loudspeaker	26

M

mail	53
Mail for Exchange	48
mailbox	
— video	36
— voice	36
Maps	72
— browsing	73
— changing views	77
— display elements	73
— driving routes	75
— navigating	75
— planning routes	74
— saving places	76

— saving routes	76
— sending places	77
— sharing locations	76
— traffic information	74
— walking	75
measurement converter	104
media	
— RealPlayer	100
memory	
— clearing	11
— web cache	66
memory card	14, 102
Message reader	106
messages	49, 50
— cell broadcast	51
— multimedia	50
— service	52
— service messages	50
— settings	51, 53
— voice	36
MMS (multimedia message service)	49, 50, 52
multimedia messages	49, 50, 52
music player	23, 88, 89
— playlists	89
muting sound	34
my music	88

N

navigation tools	68, 71
network settings	54
news feeds	65
Nokia account	27, 31
Nokia Messaging	53
Nokia support information	8
Notes	101, 102
notification light	110

O

offline profile	26
Ovi	27

Ovi Contacts	27, 28	PUK codes	9
— adding friends	29		
— availability status	28	Q	
— connection settings	32	Quickoffice	103
— landmarks	31		
— personalisation	32	R	
— presence	31	radio	93
— profiles	28	— listening	93
— searching	29	— stations	93
— settings	31	RealPlayer	100, 101
— sharing your location	28, 31	recent calls	41
— synchronising	30	recorder	101
Ovi Music	90	recording	
Ovi Store	27	— video clips	81
		red-eye removal	86
P		rejecting calls	34
packet data connection	41, 57, 63	remote locking	10
page overview	65	remote SIM mode	62
pairing devices	61	restoring settings	109
PDF reader	105	ringing tones	97
personalisation	97	roaming	54
phonebook	44		
photographs		S	
<i>See camera</i>		scenes	80
Photos	83, 84	search	
— albums	85	— settings	25
— organising files	84	searching	25
— tags	85	— contacts	34
— toolbar	85	security	
PIN code	9, 15	— browser	66
PIN2 code	9	— certificates	109
podcasting	88, 89, 90, 91, 92, 93	— settings	108
positioning information	68, 71	security code	9
powering device on/off	15	security module	109
presence	31	self-timer, camera	81
presentations, multimedia	50	sensor settings	107
printer	87	service commands	51
profiles	97	service messages	50
— changing profiles	25	settings	
— offline restrictions	26	— access points	56, 57
proximity sensor	33	— accessories	107
proxy settings	58	— application manager	112

— applications	108
— Bluetooth	60
— browser	67
— calls	113
— camera	77
— certificates	109
— date and time	106
— display	107
— internet calls	40
— language	107
— messages	52
— network	54
— packet data	63
— podcasting	93
— positioning	71
— security	108
— SIP	63
— slide	107
— video	96
— WLAN	56, 58
Share online	23
shared video	38
sharing your location	30
shooting modes	
— camera	80
SIM card	44, 108
— inserting	13
— messages	51
SIP (session initiation protocol)	63
slide settings	107
slide show	86
SMS (short message service)	49
software applications	111
software updates	8, 9
songs	88
speakerphone	26
Speech	106
speed dialling	34
support resources	8
switching device on/off	15
synchronisation	30, 59
synchronising	21

T	
text input	17, 18
text messages	
— sending	49
— settings	51
— SIM messages	51
themes	97
tones	97
— 3-D	97
touch screen	15, 33
transferring	
— files	89
transferring content	20, 21
trip meter	71
troubleshooting	115
turning device on/off	15

U	
updates	9
— device	108
UPIN code	9
UPUK code	9
USB cable connection	62
useful information	8

V	
video	
— my videos	95
— playing	95
— shared	38, 39
video calls	36, 37
— answering	37
— rejecting	37
video clips	
— downloading	94
— playing	94, 100
— shared	38
— transferring	96
— video feeds	95
video settings	82
videos & TV	
— settings	96

voice calls

See *calls*

voice commands 25, 35, 107

voice dialling 35

voice mailbox 25

volume control 26

W

web browser 64

web connection 64

widgets 23

wireless LAN (WLAN) 55

WLAN (wireless local are network) 56

WLAN (wireless local area network) 58

world clock 100

Z

Zip manager 104