


Smart Relay

SRW 01

Addendum to User Manual V1.3X

Language: English
Document: 10000590245 / 00





Addendum to User Manual V1.3X

Series: SRW 01

Language: English

Document Number: 10000590245 / 00

Firmware Version: V2.0X

Publication Date: 08/2009

SUMMARY

1 INTRODUCTION	7
2 QUICK REFERENCE OF THE PARAMETERS	9
3 GENERAL INFORMATION	17
3.1 TERMS AND DEFINITIONS USED IN THE MANUAL	17
3.2 ABOUT SRW 01	17
3.3 SRW 01 IDENTIFICATION LABEL	18
4 INSTALLATION AND CONNECTION	19
4.1 ELECTRICAL INSTALLATION	19
4.2 CURRENT MEASUREMENT UNIT (UMC) CONNECTION	20
4.3 CONNECTION OF THE EARTH LEAKAGE SENSOR (ELS)	21
4.4 SHORT CIRCUIT RANGES (UL)	22
5 HUMAN-MACHINE INTERFACE (HMI)	23
5.1 COPY FUNCTION	23
6 PARAMETERIZATION	25
6.1 LOCAL COMMAND	26
6.2 DIGITAL INPUTS AND OUTPUTS	27
6.3 SRW 01 CHECK BACK	30
6.4 OPERATION MODES	32
6.4.1 Transparent Mode	32
6.4.1.1 Connection Diagram – Transparent Mode	32
6.4.2 Overload Relay	33
6.4.2.1 Connection Diagram – Overload Relay	34
6.4.3 DIRECT STARTER	35
6.4.3.1 Connection Diagram – Direct Starter	35
6.4.3.2 Operation Diagram – Direct Starter	37
6.4.4 Reversing Starter	37
6.4.4.1 Connection Diagram – Reversing Starter	38
6.4.4.2 Operation Diagram – Reversing Starter	39
6.4.5 Star-Delta Starter	39
6.4.5.1 Connection Diagram – Star-Delta Starter	40
6.4.5.2 Operation Diagram – Star-Delta Starter	42
6.4.6 Dahlander Starter	42
6.4.6.1 Connection Diagram – Dahlander Starter	43
6.4.6.2 Operation Diagram – Dahlander Starter	45
6.4.7 Pole Changing Starter	45
6.4.7.1 Connection Diagram – Pole Changing Starter	46
6.4.7.2 Operation Diagram – Pole Changing Starter	47
6.4.8 PLC Mode	47
6.4.8.1 Connection Diagram – PLC	48
6.5 MOTOR CONFIGURATION	49
6.6 COMMUNICATION NETWORK CONFIGURATION	50
6.6.1 Modbus-RTU	50
6.7 PROTECTION CONFIGURATION PARAMETERS	51

6.7.1 External Fault	52
6.7.2 PTC Thermal Protection.....	53
6.7.3 RESET Button.....	54
6.7.3.1 Reset.....	54
6.7.3.2 Trip Test	55
6.7.4 Earth Leakage	56
6.7.4.1 Earth Leakage protection operation	57
6.7.4.2 Inhibition of the Earth Leakage Protection at Starting.....	58
6.7.4.3 Trip Inhibition Function in Case of Short Circuit.....	59
6.7.4.4 Verification of the Earth Leakage Current Measuring.....	60
 7 MONITORING PARAMETERS	 61
 8 DIAGNOSIS	 65
8.1 DIAGNOSIS VIA LEDS	65
8.2 DIAGNOSIS VIA HMI.....	65
 9 TECHNICAL CHARACTERISTICS	 67
9.1 MECHANICAL DATA	68

1 INTRODUCTION

This ADDENDUM describes the changes present on the new software version for the SRW 01 Smart Relay. It complements manual 0899.5838 P/03 version 1.3X that accompanies the product with the new 2.0X version incorporated.

The 2.0X software version of the SRW 01 Smart Relay has some differences in the operation in relation to the previous 1.3X version:

- New hardware and inclusion of new parameters for Earth Leakage protection using an external sensor (ELS) connected to terminals S1 and S2 of the Control Unit.
- A new way of driving using digital inputs. It is possible to select the local control with three wires (pushbutton) or with two wires (switch). The OFF control logic for three wires (pushbutton) can be changed from active on level 0, normally closed (NC) to active on level 1, normally open (NO), using parameter P231.
- Inclusion of six Programmable Reading Parameters. On the Modbus –RTU communication mode it can read six parameters sequentially and detection the Timeout on serial communication.
- Inclusion of digital output status on the Status Word #1 (P729).
- External Fault protection through the input signal on the selected digital input.
- Inclusion of new functions for digital outputs O1 to O4 which can signal Alarm/Fault (NO) or Trip/Error (NO or NC).

The changes are described below.



2 QUICK REFERENCE OF THE PARAMETERS

The parameters highlighted in blue are only available for the version of the Control Unit identified by: SRW01-UCxTxEx47 now called SRW01-PTC. The parameters in grey are only available for version SRW01-UCxExEx47, called SRW01-RCD. The parameters in white are of common use among the versions with PTC and Earth Leakage protection.

For further information about product identification, consult item 3.3 of this addendum or the catalog provided in electronic format on the CD-ROM that accompanies the product or access the WEG site - www.weg.net.

Parameter	Description	Adjustable Range	Factory Setting	User Setting	Proprieties
P000	Access to the Parameters	0 to 999	0		rw
P001	Scan Cycle Time	0.0 to 6553.5 ms	-		RO
P002	IN % Current	0 to 250 %	-		RO
P003	TRUE RMS Current	0.0 to 999.9 A	-		RO
P005	Line Frequency	0.0 to 99.9 Hz	-		RO
P006	Relay Status (binary)	bit0 = Error bit1 = TRIP bit2 = Alarm/Fault bit3 = Motor On bit4 = Remote Mode	-		RO
P012	Digital Inputs I1 to I4 Status (binary)	bit0 = I1 bit1 = I2 bit2 = I3 bit3 = I4	-		RO
P013	Digital Outputs O1 to O4 Status (binary)	bit0 = O1 bit1 = O2 bit2 = O3 bit3 = O4	-		RO
P014	Last Error	0 to 100	-		RO
P015	Second Error	0 to 100	-		RO
P016	Current Error	0 to 100	-		RO
P020	PTC Value (ohms)	0 to 10000 Ω	-		RO
P023	Firmware Version	0.00 to 655.35	-		RO
P030	R Phase TRUE RMS Current	0.0 to 999.9 A	-		RO
P031	S Phase TRUE RMS Current	0.0 to 999.9 A	-		RO
P032	T Phase TRUE RMS Current	0.0 to 999.9 A	-		RO
P036	Earth Leakage Percentage Current	0 to 3334 %	-		RO
P037	Earth Leakage TRUE RMS Current	0.000 to 10.000 A	-		RO
P042	Powered Relay Time	0 to 65530 h	-		RO
P043	Motor Running Time	0 to 65530 h	-		RO
P050	Motor Thermal Protection	0 to 250 %	-		RO
P051	Current Imbalance Level	0 to 100 %	-		RO
P052	Earth Fault Level	0 to 200 %	-		RO
P060	Number of Starts	0 to 65535	-		RO
P061	Number of Overload Trips	0 to 65535	-		RO
P062	Number of Current Imbalance Trips	0 to 65535	-		RO
P063	Number of Earth Fault Trips	0 to 65535	-		RO
P064	Number of Phase Loss Trips	0 to 65535	-		RO
P065	Number of Overcurrent Trips	0 to 65535	-		RO
P066	Number of Undercurrent Trips	0 to 65535	-		RO
P067	Number of Frequency Out of Range Trips	0 to 65535	-		RO
P068	Number of PTC Trips	0 to 65535	-		RO
P069	Number of Earth Leakage Trips	0 to 65535	-		RO

Addendum to User Manual V1.3X

Parameter	Description	Adjustable Range	Factory Setting	User Setting	Proprieties
P070	Number of External Fault Trips	0 to 65535	-		RO
P071	TRIP Status 1 (binary)	bit0 = PTC bit1 = Out of Frequency bit2 = Undercurrent bit3 = Overcurrent	-		RO
P072	TRIP Status 2 (binary)	bit0 = Phase Loss bit1 = Current Imbalance bit2 = Earth Fault bit3 = Overload	-		RO
P073	TRIP Status 3 (binary)	bit0 = Earth Leakage bit1 = External Fault bit2 = Trip Test bit3 = No Function	-		RO
P075	Alarm Status 1 (binary)	bit0 = PTC bit1 = Out of Frequency bit2 = Undercurrent bit3 = Overcurrent	-		RO
P076	Alarm Status 2 (binary)	bit0 = Phase Loss bit1 = Current Imbalance bit2 = Earth Fault bit3 = Overload	-		RO
P077	Alarm Status 3 (binary)	bit0 = Earth Leakage bit1 = External Fault bit2 = No Function bit3 = No Function	-		RO
P080	General Trip Status	0 to 65535	-		RO
P081	General Alarm Status	0 to 65535	-		RO
P084	Communication Module Type	0 = None 1 = Modbus-RTU 2 = DeviceNet 3 = Profibus DP	-		RO
P085	Type of Digital Inputs	0 = Invalid 1 = Invalid 2 = 24 Vdc 3 = 110 Vac	-		RO
P163	User Program Disabling	0 = Executes User Program 1 = Stops User Program	0 = Executes User Program		Sys, rw
P200	Password Status	0 = Inactive 1 = Active 2 = Change Password	1 = Active		Sys, rw
P202	Operation Mode	0 = Transparent 1 = Overload Relay 2 = Direct Starter 3 = Reversing Starter 4 = Star/Delta 5 = Dahlander 6 = Pole Changing 7 = PLC	1 = Overload Relay		Sys, CFG
P204	Counter Reset / Factory Settings	0 = No Function 1 = Reset of the Motor Running Time 2 = It resets the Protection counters and the Number of Starts counter 3 = No Function 4 = No Function 5 = Reset to the Factory Settings	0 = No Function		Sys, rw

Parameter	Description	Adjustable Range	Factory Setting	User Setting	Proprieties
P205	Reading Parameter Selection	1 = P002 (% IN Current) 2 = P003 (TRUE RMS Current) 3 = P005 (Line Frequency) 4 = P006 (Relay Status (binary))	2 = P003 (TRUE RMS Current)		Sys, rw
P208	Check Back Type	0 = Motor Current 1 = Digital Input Ix 2 = Simulation	0 = Motor Current		Sys, CFG
P209	Execution Time	100 to 2000 ms	200 ms		Sys, CFG
P210	Star/Delta Time	1 to 99 s	25 s		Sys, CFG
P211	Check Back Time	0 to 2000 ms	200 ms		Sys, CFG
P212	Motor Transition Time	50 to 5000 ms	50 ms		Sys, CFG
P220	Local/Remote Selection	0 = Always Local 1 = Always Remote 2 = HMI key (LOC) 3 = HMI key (REM) 4 = Digital Input I3 5 = Digital Input I4 6 = Fieldbus (LOC) 7 = Fieldbus (REM) 8 = USB/Ladder	2 = HMI key (LOC)		Sys, rw
P229	Local command Selection	0 = Ix 1 = HMI 2 = USB/Ladder	0 = Ix		Sys, rw
P230	Local Command (Ix) Two or Three wires	0 = Two wires (Switch) 1 = Three wires (Pushbutton)	1 = Three wires (Pushbutton)		Sys, CFG
P231	Logic Stop Command Local Mode (Ix) Three wires	0 = Digital Input I1 (NC) 1 = Digital Input I1 (NO)	0 = Digital Input I1 (NC)		Sys, CFG
P277	Digital Output O1 Function	0 = Internal Use (P202) 1 = Ladder 2 = Fieldbus 3 = Alarm/Fault Signal (NO) 4 = Trip/Error Signal (NO) 5 = Trip/Error Signal (NC)	1 = Ladder		Sys, CFG
P278	Digital Output O2 Function	0 = Internal Use (P202) 1 = Ladder 2 = Fieldbus 3 = Alarm/Fault Signal (NO) 4 = Trip/Error Signal (NO) 5 = Trip/Error Signal (NC)	1 = Ladder		Sys, CFG
P279	Digital Output O3 Function	0 = Internal Use (P202) 1 = Ladder 2 = Fieldbus 3 = Alarm/Fault Signal (NO) 4 = Trip/Error Signal (NO) 5 = Trip/Error Signal (NC)	1 = Ladder		Sys, CFG

Parameter	Description	Adjustable Range	Factory Setting	User Setting	Proprieties
P280	Digital Output O4 Function	0 = Internal Use (P202) 1 = Ladder 2 = Fieldbus 3 = Alarm/Fault Signal (NO) 4 = Trip/Error Signal (NO) 5 = Trip/Error Signal (NC)	1 = Ladder		Sys, CFG
P295	Current Measurement Unit (UMC)	0 = UMC0 (0.25 – 2.5 A) 1 = UMC1 (0.5 - 5 A) 2 = UMC2 (1.25 - 12.5 A) 3 = UMC3 (2.5 – 25 A) 4 = UMC4 (12.5 - 125 A) 5 = UMC5 (42 – 420 A) 6 = UMC6 (84 – 840 A)	1 = UMC1 (0.5 - 5 A)		Sys, CFG
P297	Motor Type	0 = Three-phase 1 = Single-phase	0 = Three-phase		Sys, CFG
P313	Action in Case of Communication Error	0 = Only fault indication 1 = The motor is turned off 2 = The motor is turned off and the commands are reset 3 = It changes to Local	0 = Only fault indication		Sys, rw
P314	Serial Watchdog	0.0 to 999.0 s	0.0 s		Sys, CFG
P400	Motor Nominal Voltage	0 to 999 V	380 V		Sys, CFG
P401	Motor Nominal Current 1	0.0 to 840.0 A	0.5 A		Sys, CFG
P402	Motor Nominal Current 2	0.0 to 840.0 A	0.5 A		Sys, CFG
P406	Service Factor	1.00 to 1.50	1.15		Sys, rw
P407	Line Frequency	0 to 99 Hz	60 Hz		Sys, rw
P500	Parameter Upload/Download	0 = No Function 1 = Save Bank 1 2 = Save Bank 2 3 = Save Bank 3 4 = Load Bank 1 5 = Load Bank 2 6 = Load Bank 3	0 = No Function		Sys, rw
P501	User Program Upload/Download	0 = No Function 1 = Save Applicative 1 2 = Save Applicative 2 3 = Save Applicative 3 4 = Load Applicative 1 5 = Load Applicative 2 6 = Load Applicative 3	0 = No Function		Sys, rw
P601	Reset Selection	0 = Without Local Reset 1 = Front Button 2 = RESET key (HMI) 3 = Digital Input I3 4 = Digital Input I4	1 = Front Button		Sys, rw
P602	Function Test/Reset Button	0 = Disabled 1 = Enabled	1		Sys, rw

Parameter	Description	Adjustable Range	Factory Setting	User Setting	Proprieties
P609	External Fault Time	0 = Disabled 1 a 99 s = Enabled	0 s		Sys, rw
P610	External Fault Monitoring of protection	0 = Always 1 = Only when the motor is running	0 = Always		Sys, rw
P611	External Fault Signal	0 = Digital Input I1 1 = Digital Input I2 2 = Digital Input I3 3 = Digital Input I4	3 = Digital Input I4		Sys, rw
P612	External Fault Signal Logic	0 = Digital Input NC 1 = Digital Input NO	1 = Digital Input NO		Sys, rw
P613	External Fault Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P614	Current Imbalance	5 to 100 %	40 %		Sys, rw
P615	Current Imbalance Time	0 = Disabled 1 to 99 s = Enabled	3 s		Sys, rw
P616	Current Imbalance Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P617	Earth Fault	40 to 100 %	50 %		Sys, rw
P618	Earth Fault Time	0 = Disabled 1 to 99 s = Enabled	3 s		Sys, rw
P619	Earth Fault Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P620	Phase Loss Time	0 = Disabled 1 to 99 s = Enabled	3 s		Sys, rw
P621	Phase Loss Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P622	Overcurrent	50 to 1000 %	400 %		Sys, rw
P623	Overcurrent Time	0 = Disabled 1 to 99 s = Enabled	3 s		Sys, rw
P624	Overcurrent Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P625	Undercurrent	5 to 100 %	20 %		Sys, rw
P626	Undercurrent Time	0 = Disabled 1 to 99 s = Enabled	0 s		Sys, rw
P627	Undercurrent Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P628	Frequency out of Range	5 to 20 %	5 %		Sys, rw
P629	Frequency out of Range time	0 = Disabled 1 to 99 s = Enabled	0 s		Sys, rw
P630	Frequency out of Range Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P631	Earth Leakage Protection	0 = Disabled 1 = Enabled	0 = Disabled		Sys, rw
P632	Earth Leakage Current Level Selection	0 = 0.3 A 1 = 0.5 A 2 = 1 A 3 = 2 A 4 = 3 A 5 = 5 A	2 = 1A		Sys, rw
P633	Earth Leakage Time	0.1 to 25.0 s	0.5 s		Sys, rw
P634	Earth Leakage Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P635	Earth Leakage Start up Inhibit	0 = Disabled 1 = Enabled	0 = Disabled		Sys, rw
P636	Earth Leakage Start up Time Inhibit	1 to 600 s	5 s		Sys, rw
P637	Earth Leakage Short circuit Trip Inhibit	0 = Disabled 1 = Enabled	0 = Disabled		Sys, rw

Addendum to User Manual V1.3X

Parameter	Description	Adjustable Range	Factory Setting	User Setting	Proprieties
P640	Relay Tripping Class	0 = Disabled 1 = Class 5 2 = Class 10 3 = Class 15 4 = Class 20 5 = Class 25 6 = Class 30 7 = Class 35 8 = Class 40 9 = Class 45	2 = Class 10		Sys, rw
P641	Overload Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P642	Cooling Time	0 = Disabled 1 to 3600 s = Enabled	0 s		Sys, rw
P643	Auto-reset	0 = Disabled 1 = Enabled	0 = Disabled		Sys, rw
P644	PTC Protection	0 = Disabled 1 = Enabled	0 = Disabled		Sys, rw
P645	PTC Protection Action	0 = Alarm 1 = Switch off (TRIP)	1 = Switch off (TRIP)		Sys, rw
P703	Bus Off Reset	0 = Manual 1 = Automatic	1 = Automatic		Sys, CFG
P705	CAN Controller Status	0 = Inactive 1 = Auto-baud 2 = CAN Active 3 = Alarm 4 = Error Passive 5 = Bus Off 6 = Without Power Supply	-		RO
P707	Transmitted CAN Telegrams Counter	0 to 65535	-		RO
P708	Bus Off Counter	0 to 65535	-		RO
P709	Lost CAN Telegrams Counter	0 to 65535			RO
P719	DeviceNet Network Status	0 = Offline 1 = Online, Not Connected 2 = Online Connected 3 = Expired Connection 4 = Connection Fault 5 = Auto-Baud	-		RO
P720	DeviceNet Master Status	0 = Run 1 = Idle	-		RO
P725	Communication Module Address	0 to 255	63		Sys, CFG
P726	DeviceNet/Modbus Baud Rate	0 = 125 kbit/s / 4.8 kbit/s 1 = 250 kbit/s / 9.6 kbit/s 2 = 500 kbit/s / 19.2 kbit/s 3 = Autobaud / 38.4 kbit/s	3 = Autobaud / 38.4 kbit/s		Sys, CFG
P727	DeviceNet Data Profile	0 = ODVA 1 = WEG	0 = ODVA		Sys, CFG
P728	Number of Words from the Slave to the Master	1 to 5	1		Sys, CFG
P729	Status Word # 1	0 to 65535	-		RO
P730	Parameter Transmitted at Word # 2	0 to 999	0		Sys, rw
P731	Parameter Transmitted at Word # 3	0 to 999	0		Sys, rw
P732	Parameter Transmitted at Word # 4	0 to 999	0		Sys, rw
P733	Parameter Transmitted at Word # 5	0 to 999	0		Sys, rw
P734	Number of Words from the Master to the Slave	1 to 2	1		Sys, rw
P735	Control Word # 1	0 to 65535	-		RO
P736	Parameter Received at Word # 2	0 to 999	0		Sys, rw

Parameter	Description	Adjustable Range	Factory Setting	User Setting	Proprieties
P740	Profibus Network Status	0 = Inactive 1 = Initialization error 2 = Offline 3 = Configuration data error 4 = Parameter data error 5 = Clear mode 6 = Online	-		RO
P770 to P775	Reading Programmable Parameter #1 to #6	0 to 999	0		Sys, rw
P780 to P785	Value of the Reading Programmable Parameter #1 to #6	0 to 65535	0		RO
P800 to P899	User Parameters	0 to 65535	0		Us, rw

RO = Read-only parameter.

rw = Reading/writing parameter.

CFG = Configuration parameter, it can only be changed with a stopped motor.

Sys = System parameter. Its value is updated when the  key is pressed.

Us = User parameter. Its value is instantaneously updated by the HMI, even before pressing the  key.



3 GENERAL INFORMATION

3.1 TERMS AND DEFINITIONS USED IN THE MANUAL

ELS: Earth Leakage Sensor.

RCD: According to IEC 60755, mechanical switching device (or device association) developed to cause contacts to open when a residual current reaches a certain value under specific conditions (Residual Current Device).

FLA: Set Current at Full Load (Full Load Amps).

3.2 ABOUT SRW 01

It was added one more component to the SRW 01:

(g) Earth Leakage sensors - SRW01-ELS

- 1 – SRW 01-EL1
- 2 – SRW 01-EL2
- 3 – SRW 01-EL3
- 4 – SRW 01-EL4




Figure 3.1: SRW 01 new component

3.3 SRW 01 IDENTIFICATION LABEL

- 1 – Product model
- 2 – WEG part number
- 3 – Serial number
- 4 – Manufacturing date
- 5 – Maximum ambient temperature
- 6 – Firmware version
- 7 – UC supply voltage (voltage and frequency)
- 8 – I1 to I4 digital input voltage
- 9 – Connection to the input terminals S1 and S2
- 10 – UMC current range
- 11 – Protection degree




Figure 3.2: Identification label the UC and UMC sides

On the superior part of the Control Unit there is a warning tag that informs which the voltage of the digital inputs is and what the function of terminals S1 and S2 for the acquired model is.




Figure 3.3: Warning Tag on the superior part of Control Unit

4 INSTALLATION AND CONNECTION

4.1 ELECTRICAL INSTALLATION



DANGER!

The following information serves as guidance for a correct installation. The applicable electrical installation regulations must also be followed.



DANGER!

Make sure the AC power supply is disconnected before beginning the connections.




Figure 4.1: Control unit connections

XC1 terminal strip:

- Inputs S1 and S2 – PTC or Earth Leakage Sensor;
- Digital inputs – I1, I2, I3 and I4;
- 24 Vdc output for the 24 Vdc digital inputs or common for the 110 Vac digital inputs – IC;
- Power supply terminal A1.

**NOTE!**

Check the nameplate or the warning tag on the product to know which model of the control unit was acquired:

- Digital inputs activated with 24 Vdc or with 110 Vac;
- PTC protection or earth leakage (RCD).

XC2 terminal strip:

- Profibus or Modbus – A, B and PE;
- DeviceNet – BK, BU, SH, WH and RD.

**NOTE!**

Refer to the used communication module manual for the pinout and wiring diagram.

XC6 terminal strip:

- Power supply terminal A2;
- Digital outputs – O1, O2, O3 and O4. The outputs O1 and O2 share the common terminal C1.

**ATTENTION!**

The incorrect application or installation of the SRW 01 may result in damage to its components, faults or reduction of the useful life of the product due to wiring or application errors, as well as the incorrect setting of the operation mode, rated current of the motor, incorrect selection of the Current Measuring Unit, incorrect or improper supply source for the digital inputs and/or Devicenet, application of voltage on the terminals S1 and S2.

4.2 CURRENT MEASUREMENT UNIT (UMC) CONNECTION

The SRW 01 has 6 current measurement units:

- UMC1 (0.5 – 5 A) (*)
- UMC2 (1.25 – 12.5 A)
- UMC3 (2.5 – 25 A)
- UMC4 (12.5 – 125 A)
- UMC5 (42 - 420 A)
- UMC6 (84 – 840 A)

(*) For the 0.25 -2.5 A range the UMC1 (5 A) with 2 turns in the primary must be used, according to the figure 4.2.




Figure 4.2: 0.25 to 2.5 A current range connection - two turns in the UMC1

The current measurement unit (UMC) measures the current of the 3 motor phases. The RMS current value of each phase is transmitted digitally to the control unit. The control unit (UC) signalizes through the Status LED and through the E0085 message on the HMI when the current measurement unit is not communicating with the UC.



NOTE!

The Control Unit (UC) reports value 0 (zero) for the reading of currents if the measured current is below 15% of the rated current (P401 and/or P402).



ATTENTION!

The incorrect selection of the Current Measuring Unit using parameter P295 may result in the incorrect communication of the measured current value sent to the Control Unit.

4.3 CONNECTION OF THE EARTH LEAKAGE SENSOR (ELS)

The earth leakage sensor is installed separately from the Control Unit. It can be installed in any position and it is connected to the Control Unit by a pair of braided and/or shielded wires, connected to the sensor terminals and to terminals S1 and S2 of the Control Unit. The distance of the connections between the earth leakage sensor and the Control Unit must be the smallest possible. The maximum recommended is 10 m.

The EL1(Ø 35 mm) earth leakage sensor can be assembled with M3 screws or directly on a DIN 35 mm rail using the adapter accessory.

The EL2 (Ø 70 mm), EL3 (Ø 120 mm) and EL4 (Ø 210 mm) sensors can only be assembled using screws. The EL2 and EL3 sensors are fixed by M3 screws and the EL4 sensor is fixed by M6 screws.

Addendum to User Manual V1.3X

It is recommended to use the equivalence ratio between the current measuring units and the earth leakage sensors (ELS) for installation as shown on the table below.

Table 4.1: *Equivalence between Current Measuring Units and ELS*

Current Measuring Unit (UMC)	Earth Leakage Sensor (ELS)
SRW01-UMC0 SRW01-UMC1 SRW01-UMC2 SRW01-UMC3	SRW01-EL1
SRW01-UMC4	SRW01-EL2
SRW01-UMC5	SRW01-EL3
SRW01-UMC6	SRW01-EL4



NOTE!

If the measured earth leakage current is inferior to 50 mA, the value 0 (zero) will be indicated on parameters P036 and P037.



NOTE!

Earth leakage protection is available only on version SRW 01-RCD.
Check if the acquired Control Unit model has this functionality.

4.4 SHORT CIRCUIT RANGES (UL)

The SRW01-UC and SRW01-UMC devices (UL Certificates), are appropriate to use in circuits with capacity to produce the symmetrical effective current (RMS) below 200.000 A with maximum voltage of 600 V. (This value of short circuit current is related to the use of non delayed fuses connected between the exterior enclosure/panel and the connector of the supply source (L2)).

5 HUMAN-MACHINE INTERFACE (HMI)

5.1 COPY FUNCTION

The SRW 01 copy function allows the storage of up to 3 parameter sets and/or 3 user programs.

It presents two procedures:

- 1 - Data upload: From the SRW 01 to the HMI;
- 2 - Data Download: From the HMI to the SRW 01.

After storing the parameters of the SRW 01 on the HMI it is possible to repass them to another relay using this function (P500). However, the relays must not have different hardware nor firmware versions. Check the nameplate to verify the version of the product.

It is understood that "different hardware" is the model of the control unit with PTC protection (SRW01-PTC) or earth leakage (SRW01-RCD) and that "different version" are those that are different in "x" or "y" supposing that the number of the firmware versions are described as Vx.yz.

When downloading the parameters (P500), if there is a conflict between the different hardware and/or firmware versions, the control unit will signal fault on the STATUS led and a "E0010" message on the HMI. Hardware and/or firmware differences are not verified when downloading the user program (P501).



NOTE!

The procedure of data download will not be performed, if the control unit (UC) identifies the inexistence of a user program or parameterization saved on the HMI. The upload of a user program will not be performed if there is not a program saved on the control unit (UC). In this case, the message "NULL" will flash on the HMI for two seconds.



ATTENTION!

Make sure the data download is done from the correct memory position, P500/501 = 4, 5 or 6. Perform this procedure only when the motor is disconnected from the power line.



6 PARAMETERIZATION

The system parameters of the Reading/Writing type can be divided into two groups: Control and Protection.

The Control group defines:

- Local/Remote Selection;
- Local Command Selection;
- Digital Inputs and Outputs;
- Operation Mode;
- Motor Configuration;
- Communication Network Configuration.

The Protection group defines:

- Current Imbalance Configuration;
- Earth Fault Configuration;
- Phase Loss Configuration;
- Overcurrent and Undercurrent Configuration;
- Frequency Out of Range Configuration;
- PTC Configuration;
- Overload Configuration;
- Earth Leakage Configuration;
- External Fault Configuration;
- Reset Button Selection;
- Auto-Reset Configuration.



NOTE!

- PTC protection available only on version SRW 01-PTC.
- Earth leakage protection is available only on version SRW 01-RCD.
- Check the nameplate or the warning tag on the product to know which model of the control unit was acquired.



NOTE!

There are parameters that can be changed only with the motor deenergized. In an attempt to change those parameters with the motor on, the message “STOP” will flash during 3 seconds on the HMI and the modification will not be accepted.

6.1 LOCAL COMMAND

If the Local mode is selected, the origin of the local commands must be defined at the parameter P229.




P229 – Local command Selection

Adjustable	0 = Ix	Factory	0
Range:	1 = HMI	Setting:	
	2 = USB/Ladder		
Proprieties:	Sys, rw		

Description:

It defines the origin of the local commands.

If P229 = 0, the local controls (on, off, revert, etc.) are controlled by digital inputs I1 to I4.

If P229 = 1, the local controls (on, off, revert, etc.) are controlled by keys ,  and  of the HMI.

P229 = 2 USB/Ladder – The Local commands (start, stop, reversion, etc.) are sent by the monitoring dialog box “Control/Signals” through the LC1, LC2 and LC3 commands via USB, or by the ladder user program via the system bit markers SX3001 ... SX3003 (refer to the WLP manual).



NOTE!

The “Reset” button in the monitoring dialog box “Control/Signals” works always, regardless of the P229 or P601 programming.

P230 – Command (Ix) Two or Three wires

Adjustable	0 = Two wires (Switch)	Factory	1
Range:	1 = Three wires (Pushbutton)	Setting:	
Proprieties:	Sys, CFG		

Description:

If P229 = 0 is selected, once defining that the local controls are controlled by the digital inputs, it is possible to select the type of control by:

- Two wires (Switch);
- Three wires (Pushbutton).

Type of Control	Behavior logic of digital inputs
Two wires (Switch)	<ul style="list-style-type: none"> ■ After detecting a start control, transition of the signal (0 → 1) by the rising edge of the digital input, the Control Unit according to the Operation Mode (P202), enables the digital output(s), driving the motor. The motor keeps drive while the digital input signal is on level 1 (active). If there is a signal transition to level 0, a stop control will be set.
Three wires (Pushbutton)	<ul style="list-style-type: none"> ■ After detecting a start control, transition of the signal (0 → 1) by the rising edge of the digital input, the Control Unit according to the Operation Mode (P202), enables the digital output(s), driving the motor. ■ After detecting a stop control, digital input I1 on level 0, the Control Unit disables the digital output (s), stopping the motor.


NOTE!

The control logic assigned to the digital inputs I1 to I4 and the digital outputs O1 to O4, is described in item 6.3 of this addendum, for each previously defined Operation Mode (P202).


NOTE!

The OFF control logic for three wires (Pushbuttons) can be changed from active on level 0, normally closed (NC) to active on level 1, normally open (NO), using parameter P231.

P231 – Logic Stop Command Local Mode (Ix) Three wires

Adjustable	0 = Digital Input I1 (NC)	Factory	0
Range:	1 = Digital Input I1 (NO)	Setting:	
Proprieties: Sys, CFG			

Description:

It allows the user to define the OFF control logic when in Local Mode the control is selected by the P229 = 0 digital inputs and control logic for three wires (Pushbuttons) P230 = 1, as per the Operation Mode (P202) selected.


ATTENTION!

The OFF control logic for drive in Local Mode through P229 = 0 digital inputs and control logic for three wires (Pushbuttons) P230 = 1 as a standard is active on level 0, P231 = 0. This assures that the Control Unit will stop the motor if the wires break.

6.2 DIGITAL INPUTS AND OUTPUTS

The SRW 01 presents 4 digital inputs that can be activated with a 24 Vdc or 110 Vac (according to the acquired model) voltage. It has an internal isolated 24 Vdc power supply exclusively for the operation of the digital inputs. The installation diagram is presented in the section 3.8 of the SRW 01 User Manual V1.3X.

It also presents 4 relay outputs that are configured through the parameters P277, P278, P279 and P280. The connection diagram is presented in the section 3.9 of the SRW 01 User Manual V1.3X.

P277 – Digital Output O1 Function

P278 – Digital Output O2 Function

P279 – Digital Output O3 Function

P280 – Digital Output O4 Function

Adjustable Range:	0 = Internal Use (P202) 1 = Ladder 2 = Fieldbus 3 = Alarm/Fault Signal (NO) 4 = Trip/Error Signal (NO) 5 = Trip/Error Signal (NC)	Factory Setting: P277 = 1 P278 = 1 P279 = 1 P280 = 1
Proprieties: Sys, CFG		

Description:

They define the relay output control origin.

Internal Use: it is used according to selected operation mode (P202);

Ladder: it is used by the user program implemented in Ladder;

Fieldbus: it is used directly by the industrial network master.

Alarm/Fault (NO) Signal: it is used to signal Alarm or Fault. In case of Alarm or Fault the output is closed, remaining like this until the cause of Fault is not present anymore and the reset control is set.

Trip/Error (NO) Signal: it is used to signal Trip or Error. In case of Trip or Error (Ex. No communication with the Current Measuring Unit) the output is closed, remaining this until the cause of the Fault is not present anymore and the reset control is set.

Trip/Error (NC) Signal: it is used to signal Trip or Error. In case of Trip or Error (Ex. No communication with the Current Measuring Unit) the output is closed, remaining like this until the cause of the Fault is not present anymore and the reset control is set.



NOTE!

The user can change the value of the parameter P277, P278, P279 or P280 according to the table 6.1. If the user does not respect the output availability for each operation mode an error will be generated and the control unit (UC) will signalize through the Status LED and via the message “E0024” on the HMI.

Table 6.1: Digital output availability

Operation mode	Output 1 – O1	Output 2 – O2	Output 3 – O3	Output 4 – O4
Transparent	Ladder	Ladder	Ladder	Ladder
Overload Relay	Internal use	Internal use	Ladder	Ladder
Direct Starter	Internal use	Ladder	Ladder	Ladder
Reversing Starter	Internal use	Internal use	Ladder	Ladder
Star/Delta Starter	Internal use	Internal use	Internal use	Ladder
Dahlander Starter	Internal use	Internal use	Internal use	Ladder
Pole Changing Starter	Internal use	Internal use	Ladder	Ladder
PLC	Ladder	Ladder	Ladder	Ladder

The parameters P012 and P013 present the status of the digital inputs and outputs, respectively.


NOTE!

The contents of the parameters P012 and P013 represent a binary number where each bit corresponds to one logic state. Its content is showed as binary on the HMI.

P012 – Digital Input Status

Adjustable Range: bit 0 = I1
bit 1 = I2
bit 2 = I3
bit 3 = I4

Factory Setting: -

Proprieties: RO

Description:

It monitors the status of the digital inputs Ix.

E.g.: P012 = 12 = 1100b. It means that the digital inputs I3 and I4 are actuated.

P013 – Digital Output Status

Adjustable Range: bit 0 = O1
bit 1 = O2
bit 2 = O3
bit 3 = O4

Factory Setting: -

Proprieties: RO

Description:

It monitors the status of the digital outputs Ox.

E.g.: P013 = 12 = 1100b. It means that the digital outputs O3 and O4 are activated.

6.3 SRW 01 CHECK BACK

Parameters P208, P209 and P211 configure the check back of the SRW 01 for each operation mode which assures that the motor was really driven and checking if it keeps this way until a stop control is identified or assuring that the motor keeps at standstill until a start control is identified. The digital inputs that can be used as check back depend on the Operation Mode (P202). Consult the following connection schemes.

P208 – Check Back Type

Adjustable	0 = Motor Current	Factory	0
Range:	1 = Digital Input Ix	Setting:	
	2 = Simulation		
Proprieties:	Sys, CFG		

Description:

Define the check back of the switch ON/OFF control of the motor.



NOTE!

Parameter P208 configured for simulation (P208 = 2) does not monitor the switch ON/OFF control of the motor. Therefore, it must be used only for testing.

P209 – Execution Time

Adjustable	100 to 2000 ms	Factory	200 ms
Range:		Setting:	
Proprieties:	Sys, CFG		

Description:

It defines the maximum waiting time of the check back signal to assure the setting of the ON and OFF controls.

If the Control Unit identifies an ON control and does not receive the check back signal in the time defined on P209, an error will be generated and the control unit will send out a signal through the STATUS led and message “E0078” on the HMI.

If the Control Unit identifies an OFF control and keeps receiving the check back signal in the time defined on P209, an error will be generated and the control unit will send out a signal through the STATUS led and message “E0079” on the HMI.



NOTE!

On Firmware versions 1.34 and earlier, parameter P209 was defined as Run Time.

P211 – Check Back Time

Adjustable 0 to 2000 ms

Range:

Proprieties: Sys, CFG

Factory 200 ms

Setting:

Description:

It defines the waiting time for the check back signal to go back to its normal working state in the case of the change of state without the suitable control for change.

The Control Unit monitors the check back signal continuously. If it changes without the corresponding ON/OFF control, it will wait until for it to go back to the normal state during the maximum time set on P211.

If after having confirmed the setting of the stop control the Control Unit identifies the change of state of the check back signal without the suitable ON control, an error will be generated and the control unit will send out a signal through the STATUS led and message “E0080” on the HMI.

If after having confirmed the setting of the stop control the Control Unit identifies the change of state of the check back signal without the suitable ON control, an error will be generated and the control unit will send out a signal through the STATUS led and message “E0081” on the HMI.

The following diagram exemplifies the operation of the check back signal verification:

- Check Back start control;
- Check Back stop control;
- Check Back standstill;
- Check Back operation.




Figure 6.1: Diagram of operation of the Check Back signal verification

6.4 OPERATION MODES

6.4.1 Transparent Mode

The transparent mode allows the user to develop its own application using the WLP software ladder language. The maximum allowed program size is 64 kB. The digital inputs and outputs can be used according to the application needs and are configured. The digital inputs and outputs can be used according to the need of the application and are configured as per table 6.2.

Table 6.2: Configuration of the digital inputs and outputs for the Transparent operation mode

Digital Inputs /Outputs	Function
I1	Free
I2	Free
I3	Free
I4	Free
O1	Ladder
O2	Ladder
O3	Ladder
O4	Ladder



ATTENTION!

If either Error or Trip occurs in the transparent mode, the SRW 01 will not automatically switch off its outputs. Protections must be programmed by the user with the Error or Trip bits in the SRW 01 Ladder logic.

6.4.1.1 Connection Diagram – Transparent Mode

The scheme on figure 6.2 shows an example of the use of the SRW 01 on the Transparent operation mode with drive through the digital inputs at 24 Vdc, where on the Ladder programming digital input I1 turns the motor ON/OFF, digital input I2 is used as a Check Back signal and digital output O1 drives the motor.




Figure 6.2: Connection scheme for the Transparent Operation Mode using digital inputs at 24 Vdc.

The modification of the scheme for the control unit with digital inputs at 110 Vac is shown on figure 6.3.




Figure 6.3: Detail modification for drive using digital inputs at 110 Vac

6.4.2 Overload Relay

In this operation mode the SRW 01 presents operation characteristics similar to an overload relay, using one NO (normally open) digital output and another NC (normally closed). The other digital outputs can be used according to the user's needs.

Addendum to User Manual V1.3X

In case of a TRIP event, the NC output opens and the NO closes. The NC output must be used in series with the motor starting contactor coil, in order to switch it off in case of a Trip. The NO output, however, can be used to activate an alarm or an indication lamp.

Digital inputs and outputs are configured as per table 6.3.

Table 6.3: Configuration of the digital inputs and outputs for Overload Relay operation mode

Digital Inputs /Outputs	Function
I1	Free
I2	Free
I3	Free
I4	Free
O1	TRIP - NO
O2	TRIP - NC
O3	Ladder
O4	Ladder

6.4.2.1 Connection Diagram – Overload Relay

The scheme on figure 6.4 shows an example of the use of the SRW 01 on the Overload Relay operation mode where the digital inputs I1 to I4 driven at 24 Vdc and the digital outputs O3 and O4 can be used according to the user's needs.




Figure 6.4: Connection scheme for the Overload Relay operation mode using digital inputs at 24 Vdc.

The modification of the scheme for the control unit with digital inputs at 110 Vac is shown on figure 6.5.




Figure 6.5: Detailed modification for drive using the digital inputs at 110 Vac

6.4.3 DIRECT STARTER

In this mode a direct on line starter for single-phase or three-phase motors is configured, where the digital O1 is reserved for operating the motor starting contactor. The other digital outputs can be used according the user's needs.

In case of a TRIP, the digital output O1 switches off the starting contactor, thus stopping the motor.

Digital inputs and outputs are configured as per table 6.4.

Table 6.4: Configuration of the digital inputs and outputs for the Direct Starting operation mode

Digital Inputs /Outputs	Function	
	Control Logic 3 wires (Pushbuttons)	Control Logic 2 wires (Switch)
I1	Stop Pushbutton	Free
I2	Start Pushbutton	ON/OFF Switch
I3 (*)	Check Back	
I4	Free	Free
O1	Contactor operation	
O2	Ladder	
O3	Ladder	
O4	Ladder	

(*) Adjust P208 according to the application.

6.4.3.1 Connection Diagram – Direct Starter

The scheme on figure 6.6 shows an example of the use of the SRW 01 on the Direct Starting operation mode with drive through the digital inputs (P229 = 0) at 24 Vdc using control logic of control with three wires (pushbuttons) (P230 = 1).




Figure 6.6: Connection scheme for the Direct Starting Operation Mode using digital inputs at 24 Vdc and driven by pushbuttons (P230 = 1)

The modification of the scheme for the control unit with digital inputs at 110 Vac is shown on figure 6.7 (a).

The modifications of the scheme for drive through the digital inputs (P229 = 0) at 24 Vdc, and at 110 Vac using two wires (switch) control logic (P230 = 0) are shown on figure 6.7 (b) and (c).




Figure 6.7 (a): Detail modification for drive using digital inputs at 110 Vac and driven by pushbuttons (P230 = 1)

(b): Detail modification for drive using digital inputs at 24 Vdc and

(c): Digital inputs at 110 Vac both with switch drive (P230 = 0)

6.4.3.2 Operation Diagram – Direct Starter




Figure 6.8: Operation diagram for the Direct Starter Operation Mode

6.4.4 Reversing Starter

In this mode a reversing starter for three-phase motors is configured. The digital outputs O1 and O2 are reserved for the operation of the motor starting contactors. The other digital outputs can be used according to the user's needs. In case of a TRIP, the digital outputs O1 and O2 switch off the starting contactors, thus stopping the motor. Digital inputs and outputs are configured as per table 6.5.

Table 6.5: Configuration of the digital inputs and outputs for the Reverter Starting operation mode

Digital Inputs /Outputs	Function	
	Control Logic 3 wires (Pushbuttons)	Control Logic 2 wires (Switch)
I1	Stop Pushbutton	Free
I2	Direct ON Button	Direct ON/OFF switch
I3	Reverse ON Button	Reverse ON/OFF switch
I4 (*)	Check Back	
O1	Forward Contactor Operation	
O2	Reverse Contactor Operation	
O3	Ladder	
O4	Ladder	

(*) Adjust P208 according to the application.



NOTE!

It is possible to make the motor reversion in two ways:

- By means of a stop control followed by a reverter control;
- By means of a reverter control without the need of the stop control. This way, the reverter control will only be set after the time defined on parameter P212.

P212 – Motor Transition Time

Adjustable Range:	50 to 5000 ms	Factory Setting:	50 ms
Proprieties: Sys, CFG			

Description:

It defined the Transition time between the switching of the start contactors of the motor. Used in the change of direction on the Reverter Starting mode (P202 = 3), in the conversion from star to delta on the Star-Delta starting mode (P202 = 4) and in the change of speed for the Dahlander Starting (P202 = 5) and Two Windings (P202 = 6) modes.

6.4.4.1 Connection Diagram – Reversing Starter

The scheme on figure 6.9 shows an example of the use of the SRW 01 on the Reverter Starting operation mode with drive through digital inputs (P229 = 0) at 24 Vdc using three wires control logic (pushbuttons) (P230 = 1).




Figure 6.9: Connection scheme for the Reverter Starting Operation Mode using digital inputs at 24 Vdc and driven by pushbuttons (P230 = 1)

The modification of the scheme for the control unit with digital inputs at 110 Vac is shown on figure 6.10 (a).

The modifications of the scheme for drive through the digital inputs ($P229 = 0$) at 24 Vdc, and at 110 Vac using two wires (switch) control logic ($P230 = 0$) are shown on figure 6.10 **(b)** and **(c)**.




Figure 6.10 (a): Detail modification for drive using digital inputs at 110 Vac and driven by pushbuttons ($P230 = 1$)
(b): Detail modification for drive using digital inputs at 24 Vdc and
(c): Digital inputs at 110 Vac both with switch drive ($P230 = 0$)

6.4.4.2 Operation Diagram – Reversing Starter




Figure 6.11: Operation diagram for the Reversing Starter Operation Mode

6.4.5 Star-Delta Starter

In this mode a star-delta starter for three-phase motors is configured. The digital outputs O1 and O3 are reserved for the operation of the motor in the star connection and the digital outputs O1 and O2 for the operation of the motor in the delta connection. The digital outputs O4 can be used according to the user's needs.

In case of a TRIP, the digital outputs O1, O2 and O3 switch off the starting contactors, thus stopping the motor.

Digital inputs and outputs are configured as per table 6.6.

Table 6.6: Configuration of the digital inputs and outputs for the Star-Delta Startinf operation mode

Digital Inputs /Outputs	Function	
	Control Logic 3 wires (Pushbuttons)	Control Logic 2 wires (Switch)
I1	Stop Pushbutton	Free
I2	Start Pushbutton	Start/Stop Switch
I3 (*)	Check Back K1-K2	
I4 (*)	Check Back K1-K3	
O1	K1 Contactor Operation	
O2	K2 Delta Contactor Operation	
O3	K3 – Star Contactor Operation	
O4	Ladder	

(*) Adjust P208 according to the application.

The changeover time from star to delta is configured through the parameter P210.

P210 – Star/Delta Time

Adjustable 1 to 99 s

Range:

Proprieties: Sys, CFG

Factory 25 s

Setting:

Description:

It defines the time delay for the changeover from star to delta.

6.4.5.1 Connection Diagram – Star-Delta Starter

The scheme on figure 6.12 shows an example of the use of the SRW 01 on the Star-Delta Starting operation mode with drive through digital inputs (P229 = 0) at 24 Vdc using three wires (pushbuttons) control logic (P230 = 1).




Figure 6.12: Connection scheme for the Star-Delta Starting Operation Mode –using digital inputs at 24 Vdc and driven by pushbuttons (P230=1)

The modification of the scheme for the control unit with digital inputs at 110 Vac is shown on figure 6.13 **(a)**.

The modifications of the scheme for drive through the digital inputs ($P229 = 0$) at 24 Vdc, and at 110 Vac using two wires (switch) control logic ($P230 = 0$) are shown on figure 6.13 **(b)** and **(c)**.




Figure 6.13 (a): Detail modification for drive using digital inputs at 110 Vac and driven by pushbuttons ($P230 = 1$)

(b): Detail modification for drive using digital inputs at 24 Vdc and

(c): Digital inputs at 110 Vac both with switch drive ($P_{230} = 0$)

6.4.5.2 Operation Diagram – Star-Delta Starter




Figure 6.14: Operation diagram for the Star-Delta Starter Operation Mode

6.4.6 Dahlander Starter

In this mode a Dahlander starter for three-phase motors is configured. The digital output O1 is reserved for running the motor at the low speed. The digital outputs O2 and O3 are reserved for running the motor at the high speed. The digital output O4 can be used according to the user's needs.

In case of a TRIP, the digital outputs O1, O2 and O3 switch off the starting contactors, thus stopping the motor.

Digital inputs and outputs are configured as per table 6.7.

Table 6.7: Configuration of the digital inputs and outputs for the Dahlander Starting operation mode

Digital Inputs /Outputs	Function	
	Control Logic 3 wires (Pushbuttons)	Control Logic 2 wires (Switch)
I1	Stop Pushbutton	Free
I2	Start High Speed Pushbutton	Start High Speed/ Stop Switch
I3	Start Low Speed Pushbutton	Start Low Speed/Stop Switch
I4 (*)	Check Back	
O1	K1 - Low Speed Contactor Operation	
O2	K2 - High Speed Contactor Operation	
O3	K3 - High Speed Contactor Operation	
O4	Ladder	

(*) Adjust P208 according to the application.


NOTE!

In the Dahlander Starter mode the parameter P401 must be programmed with the low speed nominal current and P402 must be programmed with the high speed nominal current.


NOTE!

The motor speed can be changed with the motor switched on, after the time defined in P212 has elapsed.

6.4.6.1 Connection Diagram – Dahlander Starter

The scheme on Figure 6.15 shows an example of the use of the SRW 01 on the Dahlander Starting operation mode with drive through digital inputs (P229 = 0) at 24 Vdc using three wires (pushbuttons) control logic (P230 = 1).




Figure 6.15: Connection scheme for the Dahlander Starting Operation Mode using digital inputs at 24 Vdc and driven by pushbuttons (P230 = 1)

The modification of the scheme for the control unit with digital inputs at 110 Vac is shown on figure 6.16 (a).

The modifications of the scheme for drive through the digital inputs (P229 = 0) at 24 Vdc, and at 110 Vac using two wires (switch) control logic (P230 = 0) are shown on figure 6.16 (b) and (c).




Figure 6.16 (a): Detail modification for drive using digital inputs at 110 Vac and driven by pushbuttons (P230 = 1)

(b): Detail modification for drive using digital inputs at 24 Vdc and driven by pushbuttons (P230 = 1)

(c): Digital inputs at 110 Vac both with switch drive (P230 = 0)

6.4.6.2 Operation Diagram – Dahlander Starter




Figure 6.17: Operation diagram for the Dahlander Starter Operation Mode

6.4.7 Pole Changing Starter

In this mode a Pole changing starter for three-phase motors with two windings is configured. The digital output O1 is reserved for running the motor at the low speed. The digital output O2 is reserved for running the motor at the high speed. The digital outputs O3 and O4 can be used according to the customer's needs.

In case of a TRIP, the digital outputs O1 and O2 switch off the starting contactors, thus stopping the motor.

Digital inputs and outputs are configured as per table 6.8.

Table 6.8: Configuration of the digital inputs and outputs for the Two Winding Starting operation mode

Digital Inputs /Outputs	Function	
	Control Logic 3 wires (Pushbuttons)	Control Logic 2 wires (Switch)
I1	Stop Pushbutton	Free
I2	Start High Speed Pushbutton	Start High Speed/ Stop Switch
I3	Start Low Speed Pushbutton	Start Low Speed/Stop Switch
I4 (*)	Check Back	
O1	K2 - Low Speed Contactor Operation	
O2	K1 - High Speed Contactor Operation	
O3	Ladder	
O4	Ladder	

(*) Adjust P208 according to the application.


NOTE!

In the Pole Changing Starter mode the parameter P401 must be programmed with the low speed nominal current and P402 must be programmed with the high speed nominal current.


NOTE!

The motor speed can be changed with the motor switched on, after the time defined in P212 has elapsed.

6.4.7.1 Connection Diagram – Pole Changing Starter

The connection scheme on figure 6.18 shows an example of the use of the SRW 01 on the Two Winding Starting operation mode with drive through digital inputs (P229 = 0) at 24 Vdc using three wires (pushbuttons) control logic (P230 = 1).




Figure 6.18: Connection scheme for the Two Windings Starting Operation Mode using digital inputs at 24 Vdc and driven by pushbuttons (P230=1)

The modification of the scheme for the control unit with digital inputs at 110 Vac is shown on figure 6.19 **(a)**.

The modifications of the scheme for drive through the digital inputs (P229 = 0) at 24 Vdc, and at 110 Vac using two wires (switch) control logic (P230 = 0) are shown on figure 6.19 **(b)** and **(c)**.




Figure 6.19 (a): Detail modification for drive using digital inputs at 110 Vac and driven by pushbuttons ($P230 = 1$)

(b): Detail modification for drive using digital inputs at 24 Vdc and

(c): Digital inputs at 110 Vac both with switch drive ($P230 = 0$)

6.4.7.2 Operation Diagram – Pole Changing Starter




Figure 6.20: Operation diagram for the Pole Changing Starter Operation Mode

6.4.8 PLC Mode

In this operation mode the SRW 01 does not use the UMC, so only the PTC thermal protection (P644) can be enabled for the SRW01-PTC and the Earth Leakage (P631) protection for the SRW01-RCD. In this mode the SRW 01 operates similarly to a PLC, allowing the user to develop its application using ladder language, through the WLP software. It can also be used as a remote I/O expansion without a ladder program.

Addendum to User Manual V1.3X

The digital inputs and outputs can be used according to the need of the application, operated in a remote way and configured as per table 6.9.

Table 6.9: Configuration of the digital inputs and outputs for the PLC operation mode

Digital Inputs /Outputs	Function
I1	Free
I2	Free
I3	Free
I4	Free
O1	Ladder
O2	Ladder
O3	Ladder
O4	Ladder



ATTENTION!

In this operation mode, only the PTC thermal protection (P644) can be abled for the SRW01-PTC and the Earth Leakage (P631) protection for the SRW01-RCD.

In the PLC mode, if an Error or Trip occurs the SRW 01 will not automatically disconnect its outputs. This protection must be programmed by the user using the Error and Trip bits on the Ladder logics of the SRW 01.



NOTE!

Check on the nameplate or on the warning tag of the product which is the model of the control unit acquired:

- PTC protection (SRW01-PTC) or
- Earth Leakage (SRW01-RCD).

6.4.8.1 Connection Diagram – PLC

The scheme on figure 6.21 shows an example of the use of the SRW 01 on the PLC operation mode with drive through digital inputs at 24 Vdc.




Figure 6.21: Connection scheme for the PLC Operation Mode using digital inputs at 24 Vdc..

The modification of the scheme for the control unit with digital inputs at 110 Vac is shown on figure 6.22.




Figure 6.22: Detail modification for drive using digital inputs at 110 Vac

6.5 MOTOR CONFIGURATION

In order to achieve an efficient motor protection, it is necessary to configure the parameters correctly according to the motor data.

P295 – Current Measurement Unit (UMC)

Adjustable Range:	0 = UMC0 (0.25 – 2.5 A)	Factory Setting:	1
	1 = UMC1 (0.5 – 5 A)		
	2 = UMC2 (1.5 – 12.5 A)		
	3 = UMC3 (2.5– 25 A)		
	4 = UMC4 (12.5 – 125 A)		
	5 = UMC5 (42 – 420 A)		
	6 = UMC6 (84 – 840 A)		

Proprieties: Sys, CFG

Description:

It selects the Current Measurement Unit (UMC) that will be connected to the SRW 01. For more information refer to the section 4.2 of this addendum.



NOTE!

The Control Unit sends out a signal through the STATUS Led (Red) and message "E0082" on the HMI if the rated current of the motor (P401/P402) is out of the current measuring unit range. In this condition, it does not allow the motor to be driven while there is an error condition and automatically leaves the error condition when the setting is valid. There is no need for the reset control. A signal is sent out through the STATUS Led (Green) and the message "E0082" on the HMI is cleaned.



NOTE!

On the Firmware versions 1.34 and earlier, parameter P295 was defined as TC Current.

6.6 COMMUNICATION NETWORK CONFIGURATION

6.6.1 Modbus-RTU

Parameters for the configuration and operation of the Modbus-RTU interface.

P314 –Serial Watchdog

P725 – Communication Module Address

P726 – DeviceNet/Modbus Baud Rate

P770 – Reading Programmable Parameter #1

P771 – Reading Programmable Parameter #2

P772 – Reading Programmable Parameter #3

P773 – Reading Programmable Parameter #4

P774 – Reading Programmable Parameter #5

P775 – Reading Programmable Parameter #6

P780 – Value of the Reading Programmable Parameter #1

P781 – Value of the Reading Programmable Parameter #2

P782 – Value of the Reading Programmable Parameter #3

P783 – Value of the Reading Programmable Parameter #4

P784 – Value of the Reading Programmable Parameter #5

P785 – Value of the Reading Programmable Parameter #6

In order to get more information, refer to the Modbus-RTU Communication Manual, supplied in electronic format on the CD-ROM that comes with the product, or obtained from the WEG website – www.weg.net.

6.7 PROTECTION CONFIGURATION PARAMETERS

The SRW 01 provides the following protections:

- Overload;
- Phase Loss;
- Current Imbalance;
- Overcurrent – configured for locked rotor protection;
- Undercurrent;
- Earth Fault;
- PTC thermal protection;
- Frequency out of range;
- Earth Leakage;
- External Fault.



NOTE!

- PTC protection available only on version SRW 01-PTC.
- Earth leakage protection is available only on version SRW 01-RCD.
- Check the nameplate or the warning tag on the product to know which model of the control unit was acquired.

6.7.1 External Fault

The external Fault protection can be used to monitor the state of an external equipment (for example, a limit switch) through a signal on a digital input. Monitoring can be done regardless of the state of the motor or only when it is in operation.

P609 – External Fault Time

Adjustable	0 = Disabled	Factory	0 s
Range:	1 to 99 = Enabled	Setting:	
Proprieties: Sys, rw			

Description:

It ables or disables the external Fault protection.

P610 – External Fault Monitoring of protection

Adjustable	0 = Always	Factory	0
Range:	1 = Only when the motor is running	Setting:	
Proprieties: Sys, rw			

Description:

It defines in which operation state the external Fault protection is verified.

If P610 = 0, the protection is active regardless whether the motor is operating or stopped.

If P610 = 1, the protection is only active when the motor is operating.

P611 – External Fault Signal

Adjustable	0 = Digital Input I1	Factory	3
Range:	1 = Digital Input I2	Setting:	
	2 = Digital Input I3		
	3 = Digital Input I4		
Proprieties: Sys, rw			

Description:

It defines which the digital input that corresponds to the external Fault signal is.

P612 – External Fault Signal Logic

Adjustable	0 = Normally Closed (NC)	Factory	1
Range:	1 = Normally Open (NO)	Setting:	
Proprieties: Sys, rw			

Description:

It defines the logic of the external Fault drive signal.

If P612 = 0, normally closed, active in logic level 0 (zero).

If P612 = 1, normally open, active in logic level 1.

P613 – External Fault Protection Action

Adjustable	0 = Alarm	Factory	1
Range:	1 = Switch off (TRIP)	Setting:	
Proprieties: Sys, rw			

Description:

It defines the protective action by external Fault.

6.7.2 PTC Thermal Protection

The PTC thermal protection uses PTC sensors installed inside the motor for its protection.

Actuation range:

- Actuation: value higher than 3.4 kΩ;
- Reset: value lower than 1.6 kΩ.

The PTC protection presents the following alarms:

- Shorted PTC sensor: The SRW 01 switches off the motor and signalizes ERROR on the Status LED and the message “E0034” on the HMI;
- Open PTC sensor: The SRW 01 switches off the motor and signalizes ERROR on the Status LED and the message “E0035” on the HMI.

P644 – PTC Protection

Adjustable	0 = Disabled	Factory	0 s
Range:	1 = Enabled	Setting:	
Proprieties: Sys, rw			

Description:

It enables or disables the PTC protection.

P645 – PTC Protection Action

Adjustable	0 = Alarm	Factory 1
Range:	1 = Switch off (TRIP)	Setting:
Proprieties:	Sys, rw	

Description:

It defines the action of the PTC protection.



NOTE!

The shorted PTC alarm is activated when the sensor resistance added to the one of the cables, is lower than 100 Ω . The table 6.10 informs the cross section and the maximum length of the cables, in order to assure shorted sensor detection.

Table 6.10: Considerations for PTC sensor short-circuit detection

Cable Cross Section	Maximum distance with short-circuit detection
2.5 mm ²	2 x 250 m (820.2 ft)
1.5 mm ²	2 X 150 m (492.1 ft)
0.5 mm ²	2 x 50 m (164 ft)

6.7.3 RESET Button

The reset button placed on the front part of the control unit allows the user to carry out the following functions, depending on the state of the SRW 01:

- Reset Function: in case of TRIP, alarm, error or fault;
- Trip Test Function: in normal operation.

6.7.3.1 Reset

If the Reset button is pressed when the relay is in the TRIP, alarm, error or fault state due to some fault on the motor or on the SRW 01, the SRW 01 must return to normal operation since the cause of the fault is not present anymore.



NOTE!

The reset button does not reset the thermal image, for that purpose one must use the cooling time.

P601 – Reset Selection

Adjustable Range: 0 = Without Local Reset
1 = Front Button
2 = RESET key (HMI)
3 = Digital Input I3
4 = Digital Input I4

Factory Setting: 1

Proprieties: Sys, rw

Description:

It selects the origin of the SRW 01 reset command.



NOTE!

The reset can be performed via Ladder or Fieldbus for any P601 adjustment.

6.7.3.2 Trip Test

The front Reset button allows the user to check the correct operation:

- Of the NET, TRIP and STATUS Leds placed on the front part of the Control Unit;
- Of the digital output that drives the motor, one or more outputs can be driven depending on the Operation Mode (P202) on item 6.3 of this addendum.

Table 6.11: Function stage of Test Trip

Normal Operation: Leds and output (s)		Motor OFF	Motor ON
First stage: Reset Button pressed between 1 s - 3 s			
NET led	Signaling as per table 7.1	Red/Green Flash	Red/Green Flash
Led STATUS	Green	Red	Red
TRIP led	Green	Red	Red
Output(s)	Unchanged	Unchanged	Unchanged
Second stage: Reset Button pressed between 3 s - 5 s			
Led NET	Signaling as per table 7.1	Signaling as per table 7.1	Signaling as per table 7.1
Led STATUS	Green	Green	Green
Led TRIP	Green	Red Flashlight	Red intermittent Flash
Saída(s)	Unchanged	Unchanged	Unchanged
Third stage: Reset Button pressed > 5 s			
Led NET	Signaling as per table 7.1	Signaling as per table 7.1	Signaling as per table 7.1
Led STATUS	Green	Red Flashlight	Red Flashlight
Led TRIP	Green	Red Flashlight	Red Flashlight
Output(s)	Changed, switch OFF (TRIP)	Changed, switch OFF (TRIP)	Changed, switch OFF (TRIP)

If the reset button placed on the front part of the Control Unit remains pressed between 1 to 3 s, the verification of the NET, TRIP and STATUS leds is made. If during this stage the HMI is connected to the Control Unit, it will show on

the display and change the state of the Leds near the keys which indicate the direction of

the rotation/speed of the motor and which indicate the operation mode of the SRW 01 Local/Remote.

Addendum to User Manual V1.3X

If the button remains pressed from 3 to 5s, the TRIP Led will send out a signal that it will enter the next stage of the test simulating a TRIP state if the time surpasses 5 s and opening the output(s) that drive(s) the motor (according to operation Mode - P202), signaling ERROR on the STATUS Led and the message “E0087” on the HMI.



NOTE!

Check the correct operation of the NET, TRIP and STATUS Leds, display of the HMI and contactor of the digital output(s) periodically.



NOTE!

The Trip Test Function can be disabled using parameter P602. Activation when the motor is operating will disconnect it if the third stage of the test is started.

P602 – Function Test/Reset Button

Adjustable 0 = Disabled

Range: 1 = Enabled

Proprieties: Sys, rw

Factory 1

Setting:

Description:

It ables or disables the trip test function through the reset button placed on the front of the control unit.

6.7.4 Earth Leakage

The IEC 60755 technical report defines the terms “*earth fault current*” as the current that flows to the earth due to an insulation fault; “*earth leakage current*” is the current that flows from the live parts of an installation to the earth in the absence of insulation fault; and “*residual current*” is the vectorial sum of the instantaneous current values flowing through the power circuit of the installation.

The SRW 01-RCD has the protection function against earth leakage currents when used with the earth leakage sensors (ELS). The protection action can be configured for alarm or trip. The sensors must be assembled separately from the relay and placed at a maximum distance of ten meters from it. The earth leakage protection allows to detect faults on the installation and/or electrical deterioration of equipment measuring residual currents between 300 mA and 5 A. The time for the protection to actuate can also be configured from 0.1 s up to 25.0 s.



ATTENTION!

This earth leakage protection system has the sole purpose to protect installations. IT IS NOT FOR THE PURPOSE OF PROTECTING PEOPLE.

It is expected for a fuse/circuit breaker, the upstream on the installation, with appropriate interruption capacity to perform for residual currents with high magnitudes, supposedly indicating currents circulating on the main circuit above the interruption capacity of the contactor. For this, the SRW 01-RCD offers a function that inhibits the opening of the relay when the residual current is larger than 10 A (for further information see the description of the function on item 6.6.4.3).

There are several situations during the start of electric induction motors that can indicate false presence of earth leakage on the sensor. This effect is intrinsic of certain applications and, in most cases, temporary and lasts for a short time. The SRW 01-RCD has a function that inhibits the relay trip during the start of the motor and the inhibition time of the trip can be configured by the user according to the configured application. This function allows reducing the risks of nuisance trips (for further information see the description of the function on item 6.6.4.2).

6.7.4.1 Earth Leakage protection operation

The SRW 01-RCD offers a protection against earth leakage current on an installation (the earth leakage protection set on parameter P631) whenever a fault occurs when the earth leakage sensor (ELS) detects that there is a residual current larger than the current set on parameter P632 and the time is larger than that set on parameter P633. The protection can be configured for alarm or trip through parameter P634. The factory standard for the earth leakage protection is disabled.



NOTE!

If the Earth Leakage inhibition functions on the Start function (P635) or inhibition of the Trip in case of Short-Circuit (P637) are abled, the SRW 01-RCD will act according to the description of these functions.

P631 – Earth Leakage Protection

Adjustable 0 = Disabled

Range: 1 = Enabled

Proprieties: Sys, rw

Factory 0

Setting:

Description:

It ables or disables the earth leakage protection.

P632 – Earth Leakage Current Level Selection

Adjustable 0 = 0.3 A

Range: 1 = 0.5 A

2 = 1 A

3 = 2 A

4 = 3 A

5 = 5 A

Proprieties: Sys, rw

Factory 2

Setting:

Description:

It selects the earth leakage current.

P633 – Earth Leakage Time

Adjustable	0.1 to 25.0 s	Factory	0.5 s
Range:		Setting:	
Proprieties:	Sys, rw		

Description:

It defines the earth leakage current time to turn off the motor or to signal alarm, increment/decrement of 0.1s.

P634 – Earth Leakage Protection Action

Adjustable	0 = Alarm	Factory	1
Range:	1 = Switch off (TRIP)	Setting:	
Proprieties:	Sys, rw		

Description:

It defines the action of earth leakage protection.

6.7.4.2 Inhibition of the Earth Leakage Protection at Starting

The SRW 01-RCD also offers a function that inhibits the earth leakage protection during motor start (P635) for a set time (P636), as long as the earth leakage protection (P631) and trip inhibition at the start (P635) are abled The factory standard of function P635 is disabled and the user can able it through the same parameter. The inhibition time of start can be set between 1 and 600s (standard 5 s) through parameter P636.

P635 – Earth Leakage Start up Inhibit

Adjustable	0 = Disabled	Factory	0
Range:	1 = Enabled	Setting:	
Proprieties:	Sys, rw		

Description:

It ables or disables the inhibition of the earth leakage protection action during motor start.

P636 – Earth Leakage Start up Time Inhibit

Adjustable	1 to 600 s	Factory	5 s
Range:		Setting:	
Proprieties:	Sys, rw		

Description:

It defines the inhibition time of the earth leakage protection action during motor start, increment/decrement of 1 s.



NOTE!

The inhibition time of the earth leakage protection at the motor start begins to be counted whenever the measured motor current is higher than 15% of the rated current set on parameters P401 and/or P402 or the residual current detected by the earth leakage current sensor (ELS) (P037) is higher than 150 mA.



NOTE!

At motor start, if there is a residual current detected by the earth leakage current sensor (ELS), if the Earth Leakage protection (P631) and the Earth Leakage Protection Inhibition function at Start (P635) are abled, the actuation time of the relay will be the sum of the times set on parameters P633 and P636.



NOTE!

If the Earth Leakage Protection function at Start is abled (P635), the earth leakage protection will only start when the inhibition time of the Protection at Start (set on P636) expires.

6.7.4.3 Trip Inhibition Function in Case of Short Circuit

The SRW 01-RCD also offers a trip inhibition function in case of short circuit (P637) as long as the earth leakage protection is abled on parameter P631. The level of short circuit current for this protection is fixed at 10 A and it cannot be set by the user. This function only has effect if the earth leakage protection action, configured on P634, is selected to Switch off (Trip).

If the residual current detected by the earth leakage sensor is higher than 10 A and the protection that inhibits the trip, when there is a short circuit condition, it abled on parameter P637, the SRW 01-RCD will generate the alarm "E0077" to indicate that the earth leakage current is in short circuit condition and it will not allow the SRW 01 to trip unless the earth leakage current reduces to a value lower than 10 A. The factory standard for this function is disabled.

P637 – Earth Leakage Short circuit Trip Inhibit

Adjustable 0 = Disabled
Range: 1 = Enabled
Proprieties: Sys, rw

Factory 0
Setting:

Description:

It ables or disables the trip inhibition in case of short circuit.

**ATTENTION!**

The Trip Test function described in item 6.6.3.2 of this addendum, makes it possible to verify the correct operation of the digital output (s), not verifying the flow of earth leakage current or default on the connection wiring between the earth leakage sensor (ELS) and the control unit (UC).

6.7.4.4 Verification of the Earth Leakage Current Measuring

It is recommended to check the correct operation of the system periodically by applying a known earth leakage current on the level defined on P632 through an earth leakage sensor and comparing it with that informed on P037. figure 6.23 shows a connection scheme for the test.

Resistor calculation "R":

$$R = \frac{V}{I}$$

Resistor power calculation "R"

$$P = R \cdot I^2$$

Calculation of error percentage between the circuit current (I) and the current informed on parameter P037:

$$erro(\%) = \left| \frac{I - I_{P037}}{I} \right| \times 100$$

Current I must satisfy the following condition:

$$0,3 \leq I \leq 5A$$

V = Alternate supply source.




Figure 6.23: Connection scheme for circuit test of earth leakage current Measuring

7 MONITORING

7.1 MONITORING PARAMETERS

The SRW 01 performs the monitoring of the following variables:

Parameter (address)	Description	Range
P006	Relay Status (binary)	bit0 = Error bit1 = TRIP bit2 = Alarm/Fault bit3 = Motor On bit4 = Remote Mode
P036	Earth Leakage Percentage Current	0 to 3334 %
P037	Earth Leakage TRUE RMS Current	0.000 to 10.000 A
P050	Motor Thermal Protection	0 to 250 %
P069	Number of Earth Leakage Trips	0 to 65535
P070	Number of External Fault Trips	0 to 65535
P073	TRIP Status 3 (binary)	bit0 = Earth Leakage bit1 = External Fault bit2 = Trip Test bit3 = No Function
P077	Alarm Status 3 (binary)	bit0 = Earth Leakage bit1 = External Fault bit2 = No Function bit3 = No Function
P080	General Trip Status	0 to 65535
P081	General Alarm Status	0 to 65535

P006 – Relay Status (binary)

Adjustable	bit0 = Error	Factory -
Range:	bit1 = Trip	Setting:
	bit2 = Alarm/Fault	
	bit3 = Motor On	
	bit4 = Remote Mode	
Proprieties:	RO	

Description:

This parameter allows monitoring the several states of the relay.

E.g.: P006 = 24 = 11000b. It means that the SRW 01 is in Remote Mode and that the motor is running.

The Error and/or Trip bits can be used on the user's Ladder logic, on the Transparent and PLC operation modes for trip of the output in case some protections actuate.

P036 – Earth Leakage Percentage Current

Adjustable	0 to 3334 %	Factory -
Range:		Setting:
Proprieties:	RO	

Description:

It informs the percentage of earth leakage current in relation to the current level set on parameter P632, as long as the earth leakage protection is abled (P631 = 1). It is only available for the SRW01-RCD relay.

P037 – Earth Leakage TRUE RMS Current

Adjustable 0.000 to 10.000 A

Range:

Proprieties: RO

Factory -

Setting:

Description:

It informs the TRUE RMS earth leakage current through the earth leakage sensor as long as the earth leakage protection is abled (P631 = 1). It is only available for the SRW01-RCD relay.

P050 – Motor Thermal Protection

Adjustable 0 to 250 %

Range:

Proprieties: RO

Factory -

Setting:

Description:

It informs the output value of the thermal model in a scale from 0 to 250% used on the overload protection of the SRW 01, being that 250 is the actuation point of the thermal protection of the motor.

The value indicated on this parameter depends on the operation condition of the motor and how much time it is found on this condition, for example: Standstill, start and at full rating.

It also depends on the selected thermal class, rated power of the motor and duty factor of the motor.

An approximate value of 160 can be read, if the motor is operating at full rating for more than 2 hours with current equal to the nominal plus the duty factor ($I_n \times F.S. @ 2h$).

P069 – Number of Earth Leakage Trips

Adjustable 0 to 65535

Range:

Proprieties: RO

Factory -

Setting:

Description:

It informs the number of trips per earth leakage. It is only available for the SRW01-RCD relay.

P070 – Number of External Fault Trips

Adjustable Range: 0 to 65535
Proprieties: RO

Factory - Setting:

Description:

It informs the number of trips per external fault.

P073 – TRIP Status 3 (binary)

Adjustable Range: bit0 = Earth Leakage
bit1 = External Fault
bit2 = Trip Test
bit3 = No Function
Proprieties: RO

Factory - Setting:

Description:

It indicates if any protection actuated with Trip.

Ex: P073 = 4 = 0100b. It means that the SRW 01 switched off (TRIP) the motor due to the Trip test actuation.

P077 – Alarm Status 3 (binary)

Adjustable Range: bit0 = Earth Leakage
bit1 = External Fault
bit2 = No Function
bit3 = No Function
Proprieties: RO

Factory - Setting:

Description:

It indicates if any protection actuated indicating only an alarm, without switching off the motor.

Ex: P077 = 2 = 0010b. It means that the External Fault protection actuated, but because it was configured for alarm, the motor has not been stopped.

P080 – General Trip Status

Adjustable Range: 0 to 65535
Proprieties: RO

Factory - Setting:

Description:

It indicates if any protection actuated with Trip.

P081 – General Alarm Status

Adjustable 0 to 65535

Range:

Proprieties: RO

Description:

Factory -

Setting:

It indicates if any protection actuated indicating only an alarm, without switching off the motor.

8 DIAGNOSIS

The error, alarm, trip and fault diagnoses can be done through the three SRW 01 status LEDs or via HMI messages.

8.1 DIAGNOSIS VIA LEDs

Table 8.1: SRW 01 Status via LEDs

LED	Signalization	Description
STATUS	Green	Relay is ready to use
	Flashing green	Fault – does not switch off the motor
	Flashing red	Error – switches off the motor
NET	According to the communication manual of each protocol	
TRIP	Green	Normal motor
	Flashing green	Alarm – does not switch off the motor
	Flashing red	Trip – switches off the motor

8.2 DIAGNOSIS VIA HMI

Table 8.2: Error code

Error	Type	Action	Description
E0005	Protection	Trip or Alarm	Overload
E0010	System	Fault	Error Copy Function
E0015	Protection	Trip or Alarm	Phase Loss
E0024	System	Error	Digital output configuration error
E0025	System	Error	Digital input configuration error
E0031 ^(*)	HMI	Fault	HMI without communication
E0032	Protection	Trip or Alarm	PTC protection
E0034	System	Error	Shorted PTC
E0035	System	Error	Open PTC
E0051	System	Fault	Fault by saving program
E0055	System	Fault	Program incompatible or out of the memory limits
E0056	System	Fault	CRC error during user program transfer
E0061	System	Fault	CAN interface BUS off error
E0063	System	Fault	Transceiver without power supply error
E0064	System	Fault	Idle DeviceNet Master
E0065	Protection	Trip or Alarm	Undercurrent
E0066	Protection	Trip or Alarm	Overcurrent
E0067	System	Fault	DeviceNet I/O connections timeout
E0068	System	Error or Fault	Profibus communication timeout
E0069	System	Error or Fault	Profibus interface initialization error
E0070	System	Error or Fault	Parameterization data error (Profibus)
E0071	System	Error or Fault	Configuration data error (Profibus)
E0072	System	Error or Fault	Clear mode (Profibus)
E0073	Protection	Trip or Alarm	Earth fault
E0074	Protection	Trip or Alarm	Current Imbalance
E0075	Protection	Trip or Alarm	Frequency out of range
E0076	Protection	Trip or Alarm	Earth Leakage
E0077 ^(**)	Protection	Error or Alarm	Earth Leakage: Inhibits Trip in case of short circuit
E0078	System	Error	Check back error, verification of start control
E0079	System	Error	Check back error, verification of stop control
E0080	System	Error	Check back error, stop verification
E0081	System	Error	Check back error, operation verification
E0082	System	Error	Current programmed on P401 (and P402) out of the UMC range
E0085	System	Error	Without communication with the UMC
E0086	System	Error or Fault	Timeout on serial communication (Modbus)
E0087	System	Trip	Trip Test
E0088	Protection	Trip or Alarm	External Fault

(*) HMI local error that is not registered in the SRW 01-UC.

(**) It signals error if the motor is OFF and does not allow driving it. If the motor is ON, it signals alarm.



9 TECHNICAL CHARACTERISTICS

GENERAL DATA	MOUNTING POSITION	ANY
	POLLUTION DEGREE (UL508)	2
	PROTECTION DEGREE (IEC 60529)	<ul style="list-style-type: none"> ■ Control Unit (UC): IP20 ■ Current Measurement Unit (UMC): <ul style="list-style-type: none"> - Without connection busbar: IP20 - With connection busbar: IP00 ■ Human-Machine Interface (HMI): IP20 ■ Earth Leakage Sensor (ELS): IP20
	ALLOWED AMBIENT TEMPERATURE	<ul style="list-style-type: none"> ■ Operation: 0... +40 °C (32... +104 °F) ■ Storage and transportation: -25... +80 °C (-13... 176 °F)
	SHORT-CIRCUIT RATINGS (UL)	<ul style="list-style-type: none"> ■ Control Unit (UC): refer to the section 3.11 in this addendum. ■ Current Measurement Unit (UMC): refer to the section 3.11 in this addendum.
	TRIPPING CLASS (UL)	<ul style="list-style-type: none"> ■ Control Unit (UC): 10/20/30 Class ■ Current Measurement Unit (UMC): 10/20/30 Class
CONTROL UNIT (UC)	NOMINAL ISOLATION VOLTAGE U_i	■ 300 V
	NOMINAL SUPPLY VOLTAGE U_s	■ 110...240 Vac/Vdc @ 50/60 Hz
	OPERATION RANGE	■ 0.85 U_s ... 1.10 U_s
	CONSUMPTION	■ 13 W
	NUMBER OF DIGITAL INPUTS	■ 4 optically isolated inputs (24 Vdc or 110 Vac)
	NUMBER OF DIGITAL OUTPUTS	■ 4 relay outputs
	MOTOR PROTECTION VIA – PTC	<ul style="list-style-type: none"> ■ TRIP level: > 3.4 kΩ; ■ Reset value: < 1.6 kΩ
	TERMINAL STRIPS	<ul style="list-style-type: none"> ■ Torque: 0.5 Nm - 4.5 lb.in ■ Conductor cross section: <ul style="list-style-type: none"> - Stripped solid wire: 1 x (0.2 ... 2.5 mm²); 1 x (26 ... 12 AWG) - Stranded with/without wire end ferrules: 1 x (0.2 ... 2.5 mm²); 1 x (26 ... 12 AWG) ■ Screws: M3
CURRENT MEASUREMENT UNIT (UMC)	RESET BUTTON	<ul style="list-style-type: none"> ■ Error or fault reset – system ■ TRIP or alarm reset – protections ■ TRIP Test
	CURRENT RANGES	■ 0.25...840 Aac
	INSULATION RATING U_i	■ 690 Vac
	NOMINAL OPERATING VOLTAGE U_e	<ul style="list-style-type: none"> ■ IEC 60947-4-1: 690 Vac ■ UL 508: 600 Vac
	IMPULSE STRENGTH U_{imp}	■ 6 kV
	FREQUENCY RANGE	■ 50/60 Hz
	APPLICATION	■ Single-phase and three-phase
	CABLE HOLE DIAMETERS	<ul style="list-style-type: none"> ■ UMC 1, 2 and 3: 8 mm (0.31 in) ■ UMC 4: 15 mm (0.59 in) ■ UMC 5: Busbar ■ UMC 6: 32 mm (1.26 in) or busbar
DIGITAL INPUTS	NUMBER OF DIGITAL INPUTS	■ 4 inputs optically isolated (24 Vdc or 110 Vac)
	POWER SUPPLY FOR THE DIGITAL INPUTS	<ul style="list-style-type: none"> ■ Internal (isolated) or external 24 Vdc ■ External 110 Vac
	DIGITAL INPUT CURRENT	■ 11 mA @24 Vdc / 5 mA @ 110 Vac
	INSULATION	■ 3 kV
DIGITAL OUTPUTS	NUMBER OF DIGITAL OUTPUTS	■ 4 relay outputs
	CONTACT GROUPING	<ul style="list-style-type: none"> ■ 2 SPST outputs ■ 2 SPST outputs with shared common
	MAXIMUM MANEUVER VOLTAGE	■ 250 Vdc, 240 Vac
	SMALLEST MANEUVER POWER	■ 1 W ou 1 VA
	RELAY CONTACT MANEUVER CAPACITY	<ul style="list-style-type: none"> ■ UL 508: C300, R300 ■ AC-15 (IEC 60947-5-1): 1,5 Aac / 120 Vac 0,75 Aca / 240 Vac ■ DC-13 (IEC 60947-5-1): 0,22 Adc / 125 Vdc 0,1 Adc / 250 Vdc
	CONTACT CAPACITY (RESISTIVE LOAD)	■ 5 A, 30 Vdc / 250 Vac
	EXTERNAL PROTECTION AGAINST SHORT-CIRCUIT	■ 6 A gl/gG fuse
	MECHANICAL LIFE	■ 1.000.000 cycles

Addendum to User Manual V1.3X

EARTH LEAKAGE SENSOR (ELS)	CURRENT RANGES	■ 0.3 ... 5 Aac
	NOMINAL ISOLATION VOLTAGE U_i	■ 690 Vac
	NOMINAL OPERATING VOLTAGE U_e	■ IEC 60947-4-1: 690 Vac ■ UL 508: 600 Vac
	IMPULSE STRENGTH U_{imp}	■ 6 kV
	FREQUENCY RANGE	■ 50/60 Hz
	APPLICATION	■ Single-phase and three-phase
	INTERNAL DIAMETER OF THE WINDOW	■ EL1: 35 mm (1.37 in) ■ EL2: 70 mm (2.75 in) ■ EL3: 120 mm (4.72 in) ■ EL4: 210 mm (8.27 in)
	TERMINAL STRIPS	■ Torque: 0.29 Nm - 2.6 lb.in ■ Conductor cross section: - Stripped solid wire: 1 x (0.2 ... 2.5 mm ²); 1 x (22 ... 14 AWG) - Stranded with/without wire end ferrules: 1 x (0.2 ... 1.5 mm ²); 1 x (22 ... 14 AWG) ■ Screws: M3

9.1 MECHANICAL DATA





Figure 9.1: Dimensions mm (in) of the EL1 Earth Leakage Sensor



Model	Ø	H	W	X1	X2	D1	D2
EL2	70 (2.7)	116 (4.6)	104 (4.1)	64 (2.5)	36 (1.4)	20 (0.8)	40 (1.6)
EL3	120 (4.7)	169 (6.6)	154 (6.1)	94 (3.7)	66 (2.6)	20 (0.8)	40 (1.6)
EL4	210 (8.3)	304 (11.9)	290 (11.4)	150 (5.9)	110 (4.3)	33 (1.3)	90 (3.5) ^(*)

(*) with metallic support at the base.

Figure 9.2: Dimensions mm (in) of the EL2, EL3 and EL4 Earth Leakage Sensors