

Canon

Speed light Transmitter ST-E2



- J** 使用説明書
- E** Instructions
- F** Mode d'emploi
- G** Bedienungsanleitung
- S** Instrucciones

Japanese

English

French

German

Spanish

Thank you for purchasing a Canon product.

Speedlite Transmitter ST-E2 is a wireless transmitter which can control up to two Speedlite 550EX groups set as slaves.

The transmitting range is about 12 to 15 meters / 39.4 to 49.2 ft indoors and 8 to 10 meters / 26.2 to 32.8 ft outdoors. With Type A cameras (EOS-3, EOS Elan II/III, EOS 50/50E, EOS 500N/Rebel G, EOS IX, EOS IX7/IX Lite), the ST-E2 can execute the following operations through wireless control:

- E-TTL autoflash
- High-speed sync (FP flash)
- FE lock
- Flash exposure compensation
- Manual flash (Flash output set with Speedlite)
- Multi-flash firing (Set with the Speedlites)

With the EOS-3, the following operations are also possible: Flash ratio control between two Speedlite slave groups, modeling flash firing, and linkage of AF-assist beam to area AF.

This Instructions booklet assume that a Type A camera is used with the ST-E2.

With Type B cameras (EOS cameras except Type A models), the ST-E2 can be used only for manual flash and multi-flash photography. See pages 23 to 27 in this booklet and the Speedlite 550EX Instructions.

Symbols used in this Instructions booklet:

-  Warning for preventing camera or ST-E2 malfunction.
-  Supplementary notes for using the ST-E2 with the camera.
-  Helpful tip for using the ST-E2 and taking pictures.
- **Keep this Instructions booklet handy for future reference.**



The CE Mark is a Directive conformity mark of the European Community (EC).

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus", ICES-003 of the Industry Canada.

Contents

1. Nomenclature	22
2. Readyng the ST-E2.....	23
3. Readyng the 550EX (Slave Setting).....	25
4. Basic Wireless E-TTL Autoflash Operation.....	26
5. Wireless Multi-Flash E-TTL Autoflash Operation	29
6. Applications	33
7. Troubleshooting	34
Specifications.....	35

Note

All the operation instructions in this booklet assume that the ST-E2 and other relevant equipment are already turned on. Before proceeding, make sure the ST-E2 and other equipment are on.

This **device** complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Do not make any changes or modifications to the equipment unless otherwise specified in the instructions. If such changes or modifications should be made, you could be required to stop operation of the equipment.


This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

1. Nomenclature

● Front




● Rear



2. Readyng the ST-E2

(1) Installing the Battery



Use one lithium 2CR5 battery (sold separately).

- 1 Slide the battery compartment cover as shown by the arrow and remove.
- 2 Install the battery in the orientation shown in the compartment.
- 3 Install the battery compartment cover to close the battery compartment.




About the battery

If the battery contacts are soiled, improper electrical contact may result. Before installing the battery, wipe the battery contacts with a clean cloth.

When to replace the battery
Replace the battery if it takes 30 sec. or longer for the red pilot lamp to light after you set the main switch to <I> or <HOLD>.

(2) Attachment to the Camera




- 1 Push in the ST-E2's mounting foot all the way into the camera's hot shoe.
- 2 Slide the shoe lock slider as shown by the arrow. (The lock pin protrudes to lock the ST-E2 onto the camera.)
 - To remove the ST-E2, slide the shoe lock slider in the opposite direction (the lock pin retracts) and slide off the ST-EP.



The hot shoe on the EOS 650, EOS 620, EOS 750, and EOS 850 will not couple with the lock pin. The ST-E2 can still be attached to these cameras, but it cannot be locked onto the hot shoe.

(3) Turning On the Power



- 1 Turn the main switch to <I>.
 - The main switch has the following three positions:
 - <O> : Turns off the power.
 - <I> : Turns on the power.
 - <HOLD> : The settings which were set at the I switch position arc frozen. All transmitter controls except the test transmission button are disabled. This prevents inadvertant alteration of transmitter settings.

- 2 When transmission is possible, the pilot lamp lights in red and the 5 icon lights in the camera viewfinder.




When the  icon lights in the camera viewfinder, it indicates that the ST-E2 is able to transmit. When Speedlite 550EX is recharged and ready to fire, its AF-assist beam emitter blinks.



- If the ST-E2 is on and not used for 90 sec., the SE (Save Energy) feature takes effect and turns off the power automatically to save battery power. The ST-E2 turns back on when the shutter button or test transmission button is pressed.
- With a Type A camera (EOS-3, EOS Elan II/IIE, EOS 50/50E, EOS 500N/Rebel G, EOS IX, EOS IX7/IX Lite) equipped with E-ITL, the ST-E2's E-ITL indicator lights.

3. Readyng the 550EX (Slave Setting)

(4) Channel Setting




To prevent wireless signals from being transmitted to unrelated Speedlite 550EX units in the vicinity, you can set a channel different from the one used by the unrelated Speedlite 550EX units. One of four channels can be set. The ST-E2 (master) and slave Speedlite(s) must be set to the same channel No.

Press the **<CH.>** button and select the desired channel.

- Each time the button is pressed the channel indicator changes in the following loop: 1 → 2 → 3 → 4 → 1
- The ST-E2 and Speedlite 550EX must be set to the same channel No

(1) Slave setting/Power on



- Set the wireless selector to **< SLAVE >**. Hereinafter, a Speedlite 550EX set to this mode will be called a "slave."
 - The zoom setting is set automatically to **24mm**. This can be overridden manually.
- Set the slave's main switch to **< I >** or **< SE >** to turn it on.
 - When the Speedlite is ready to fire, the AF-assist beam emitter blinks continuously at 1 Hz.

(2) Channel setting



- Each time you press the **< SEL/SET >** button, the blinking display changes in the following loop:
→ **CH** → **SLAVE** → Lights ←
 - While **CH** is blinking, press the **< + >** or **< - >** button to select the same channel No. as the ST-E2's.
-  If the 550EX's channel No. is different from the ST-E2's channel No., wireless transmission will not work.

4. Basic Wireless E-TTL Autoflash Operation


- 3 Press the < SEL/SET > button to register the channel No. (the display stops blinking and stays on).

After the ST-E2 and slave are ready, they can work within the area shown below for easy wireless E-TTL autoflash.

- For explanatory purposes, the EOS-3 will be used as the sample camera here.

(1) Positioning of ST-E2 and slave

- Attach the slave to the mini stand (equipped with tripod socket) which comes with the 550EX.
- Turn the Speedlite's body (bounce feature) so that the slave sensor faces toward the ST-EZ.
- Indoors, the slave position need not be so precise since the light will also bounce off the walls.
- After positioning the camera and slaves, be sure to test the wireless control before taking a picture.
- Do not place any obstructions between the **ST-EP** and slaves. Otherwise, remote transmission may not be achieved.




(2) Camera operation


Set the camera for normal flash operation.



With the EOS-3, make sure the ST-E2's flash ratio control lamp is off. (If necessary, press the <RATIO> button to turn it off.) If the flash ratio control lamp is on, the Speedlite may not fire or a correct exposure may not be attained. After turning off the flash ratio control lamp, set the main switch to <HOLD> to prevent the flash ratio control lamp from lighting inadvertently.




(3) Checking the ST-E2's pilot lamp and slave-ready status



Check that the ST-E2's pilot lamp is on and that the slave is ready.

- When the slave is ready to fire, its AF-assist beam emitter flashes at 1 Hz.

(4) Wireless operation test




Press the ST-E2's pilot lamp (which also functions as a test transmission button).

- If everything is OK, slave A will fire followed by slave B (at 1/64 output).
- If the slave(s) does not fire, reposition the slave's angle or distance toward the ST-E2 and test it again.



When the ST-E2's pilot lamp lights and the  icon lights in the camera viewfinder, they indicate that the ST-E2 is ready for remote transmission. They do not indicate that the slave is ready (recharged).

(5) Taking the picture and flash confirmation



When you press the shutter button completely, a wireless signal is transmitted to the slave, then the slave fires a preflash and then the main flash when the picture is taken.

- The subject's flash exposure reading is obtained with the preflash and used to set the main flash output. Wireless flash photography is thereby executed with an optimum flash output.
- When the correct flash exposure is obtained, the ST-E2's flash confirmation lamp lights for about 3 sec. immediately after the flash fires. If it does not light, the picture might be underexposed. In this case, use a larger aperture or place the slave

closer to the subject and repeat steps (2) to (5).



- With the EOS-3, the modeling flash can be fired to see the lighting effects before the picture is taken. See page 32.
- The slave must be properly positioned to receive the wireless transmission.
- After the picture is taken, the slave's operation result is displayed on the slave's display panel.
- If the slave is in the SE (Save Energy) mode, pressing the ST-E2's test transmission button will cancel it.
- When you press the shutter button halfway and activate the camera's exposure meter, the ST-E2 cannot be used to cancel the slave's SE mode or to execute a test transmission. The camera's exposure meter must turn off (viewfinder's exposure setting display turns off) before the SE mode can be canceled or a test transmission executed.

● AF-assist beam

Under low-light or low-contrast conditions, the ST-E2's AF-assist beam is emitted to assist autofocus. The AF-assist beam is compatible with the EOS-3's Area AF. The AF-assist beam's effective range is about **0.6 meter to 10 meters** at the center and **0.6 meter to 5 meters** along the periphery.

- The ST-E2's AF-assist beam can be emitted only while the ST-E2 is attached to the EOS-3. In the case of EOS cameras with a built-in AF-assist beam emitter, the beam will be emitted by the camera.
- The slave's AF-assist beam is not emitted (except when the flash is ready).



To prevent overheating, limit the number of consecutive wireless transmissions to 50. After 50 consecutive wireless transmissions, allow the ST-E2 to rest for 10 minutes.

5. Wireless Multi-Flash E-TTL Autoflash Operation

There are **two** types of wireless multi-flash E-TTL autoflash operations:

① **<RATIO> OFF**: All slaves fire the same flash output.

② **<RATIO> ON**: Slaves are given an ID, either A or B. The flash ratio is then set for each ID.

- The flash ratio can be set only when the camera is an EOS-3.
- The flash ratio cannot be set with an EOS Elan II/IE, EOS 50/50E, EOS Rebel G/500N, EOS IX or EOS IX7/IX Lite.



- By changing the distance between the subject and slaves, the lighting balance (flash ratio) can be changed accordingly.
- Two or more slaves can be used.
- With the EOS-3, a modeling flash can be fired to check the lighting effects before the picture is taken.

As an example, two slaves are used here, one positioned on the left and the other on the right of the subject.


Multi-Flash with a Uniform Flash Output

All the slaves set at the same channel fire at the same output controlled by E-TTL autoflash to obtain a correct exposure.

- The operation procedure is the same as with wireless E-TTL autoflash.




With the EOS-3, make sure the ST-E2's flash ratio control lamp is off. (If necessary, press the **<RATIO>** button to turn it off.) If the flash ratio control lamp is on, the Speedlite may not fire or a correct exposure may not be attained. After turning off the flash ratio control lamp, set the main switch to **<HOLD>** to prevent the flash ratio control lamp from lighting inadvertently.



Sample Multi-Flash Setup with Uniform Flash Output

In the sample flash setup shown below, the lighting on the left will be brighter than on the right of the subject.




Multi-Flash with Slave ID and Flash Ratio Settings

In the example shown for "Multi-Flash with a Uniform Flash Output," the lighting balance (flash ratio) was adjusted by placing the slaves at different distances to the subject. However, with "Multi-Flash with Slave ID and Flash Ratio Settings," the flash ratio can be adjusted without moving the slaves.

The flash ratio can be adjusted from 8:1 to 1 and from 1 to 1:8 in half-stop increments.


■ Sample Multi-Flash Setup with Slave ID and Flash Ratio Settings



(1) Setting the Slave ID

With the wireless control of multiple slaves, you can set the flash ratio and specify the main flash and fill flash by assigning a slave ID. There are three IDs: A, B, and C. The ST-E2 can control slaves A and B. When the flash ratio control lamp is lit, the C slave does not fire.

- Set the slave ID to A for the slave on the left of the camera, and to B for the slave on the right of the camera.



- Press the slave's **<SEL/SET>** button to select **<SLAVE>**.
- Press the **<+>** or **<->** button to set the slave ID to **<A>**.
- Press the **<SEL/SET>** button to register the slave ID. (The slave ID stops blinking and stays on.)
- Follow the same procedure for the other slave to set the slave ID to ****.


! If the slave's ID is set to C, it cannot be controlled by the ST-E2. Be sure to set the slave ID to A or B.

! There is no limit as to the number of slaves that can be used. Set the slave ID for all the slaves to either A or B.

About Slave Group Control


All slaves set to the same ID are controlled as one group.

- Shown below is a group of three slaves whose ID is A. They will be controlled as a single slave group A.




(2) Setting the A:B Flash Ratio

The flash ratio between slave A and slave B can be set to specify the main flash and fill flash. The flash ratio can be set from 8:1 to 1 and from 1 to 1:8 in half-stop increments. In terms of exposure stops, it ranges from 3:1 to 1 and from 1 to 1:3. When the flash ratio is set, E-TTL autoflash metering controls the flash output to obtain a correct exposure.




- 1 Check that the ST-E2's main switch is set to **<I>**, then press the **<RATIO>** button.
 - The flash ratio control lamp lights in red, and the respective flash ratio indicator lights.

The flash ratios for the unmarked indicators (■) are shown in parentheses below.



(3) Camera and Slave Positions

Position the ST-E2-attached camera and the two slaves to obtain the desired lighting effect. See page 26.




The modeling flash can be fired to see the lighting effects before the picture is taken.

- 4 Follow the basic procedure for wireless E-TTL autoflash exposure to take the picture. See page 26.


6. Applications

Even with a wireless multi-flash system, you can use high-speed sync (FP flash), FE lock, and flash exposure compensation in the same way as with a camera-attached 550EX.

- Wireless high-speed sync (FP flash)
- Wireless FE lock



After setting the wireless single- or multi-flash setup, just set the ST-E2's high-speed sync button to **<H>**. This enables wireless high-speed sync. The slaves need not be touched at all.



After setting the wireless single- or multi-flash setup, just press the camera's **<FEL>** button to enable wireless FE lock.

- Flash exposure compensation
Flash exposure compensation can be set with the camera.
Wireless manual flash
Wireless manual flash can be fired by setting the slave to single-slave or manual flash
- Wireless repeating flash
Wireless repeating flash can be used when the slave has been set to single-slave or repeating flash
For details, see the 550EX's Instructions

 The ST-E2 can transmit wireless signals only toward the front. Therefore, the slaves cannot be positioned behind the camera. Otherwise, they will not be able to pick up the ST-E2's wireless control signals. However, with Off-Camera Shoe Cord 2 (sold separately), the ST-E2 can be positioned away from the camera and face any direction for wireless transmission.

7. Troubleshooting

Problem	Probable Cause	Solution	Page
Soon after the power is turned on, the indicator lamp turns on'	If the power is turned on and the ST-E2 is not used for 90 sec., the power turns off automatically.	Either press the shutter button halfway or press the <PILOT> button.	24
Although the  icon is lit in the viewfinder, the slave does not fire.	The  icon in the viewfinder does not indicate flash ready. Rather, it indicates that the ST-E2 is able to transmit.	When the slave is ready to fire, its AF-assist beam emitter blinks	27
The flash picture came out underexposed	The flash ratio control lamp was lit even though a multi-flash system with flash ratio settings was not used.	Turn off the flash ratio control lamp before taking the picture.	29
	The subject is beyond the effective flash range.	Place the slave nearer to the subject or use a larger aperture (smaller f-number).	28
The slave does not fire even when the shutter is released.	The slave's channel does not match the ST-E2's channel.	Set the slave to the same channel as the ST-E2.	25
	The slave is too far away from the ST-E2.	Position the slave nearer to the ST-E2 and test the transmission before taking the picture.	26
	The slave is on the side or back of the camera.	Use Off-Camera Shoe Cord 2 (sold separately) and point the ST-E2's transmitter toward the slave.	33
	The Speedlite's slave sensor is not properly pointed at the ST-E2.	Use the 550EX's bounce feature to point its slave sensor toward the ST-E2.	26
	The flash ratio has been set, but the slave ID has been set to C.	Set the slave ID to A or B.	31
The ST-E2 does not emit the AF-assist beam.	The camera is not an EOS-3.	If the EOS camera has a built-in AF-assist beam, the camera will emit the beam instead of the ST-E2.	28
The slave's flash-ready indicator (blinking AF-assist beam) turns off.	The slave is in the SE mode.	Press the ST-E2's <PILOT> button to cancel the slave's SE mode.	28
The test transmission does not work.	You pressed the shutter button halfway and this activated the exposure meter	Make sure the metering display in the viewfinder is off. Then test the transmission.	28
The flash ratio cannot be set.	The camera is not an EOS-3.	The flash ratio cannot be set with cameras other than the EOS-3.	—
	The ST-E2's main switch is set to <HOLD>.	Set the main switch to <I>.	24

Specifications

Type	550EX-dedicated, clip-on Speedlite transmitter with direct contacts
Compatible Cameras	Type A EOS cameras (E-TTL auto flash) Type B EOS cameras (Manual flash)
Channels	4
Flash Ratio Control	For AR ratio 1/8 to 1:1 to 8:1, in half-step increments or 13 steps
High-Speed Sync (FP flash)	Enabled with high-speed sync mode 
Slave Operation Confirmation	With 1st transmission button. *Slave A fires followed by slave B at 1/64 output.
Flash Exposure Confirmation	1 Before flash fires during FE lock Adequate flash exposure indicated by the  icon lit in the viewfinder. Insufficient flash exposure indicated by the  icon blinking in the viewfinder. 2 After flash fires ST-E2's flash confirmation lamp lights in green for 9 sec.
Wireless slave SE mode cancellation	Cancels when the test transmission button or FE lock button is pressed to turn on the slave unit
Wireless Transmission	Infrared pulse
Transmission Range	Indoors: Approx. 12 • 15 meters/39.4 • 49.2 ft Outdoors: Approx. 8 • 10 meters/26.2 • 32.8 ft
Transmission Coverage	±40° horizontal and ±30° vertical
Battery Life	Approx. 1,500 transmissions (At room temperature and with a new set of batteries)
AF-assist Beam	Compatible with EOS-3's 45-point Area AF and 28mm and longer lens focal lengths
AF-assist Beam Effective Range	Approx. 0.6 to 10 m / 2.0 to 33 ft at center. 0.6 to 5 m/2.0 to 16.5 ft along the periphery (in total darkness).
SE Feature	While the power switch is set to 1 or HOLD, the transmitter turns off automatically after about 90 sec. of non-use.
Power Source	2CR2 lithium (6 V) battery × 1
Dimensions	62 (W) × 51 (H) × 80 (D) mm 2.4 (W) × 2.0 (H) × 3.1 (D) in
Weight	100 g/3.5 oz (excluding battery)

Wireless Operation Differences with the 550EX		
Wireless Operation	ST-E2	550EX (Master)
Flash ratio control	2 groups A, B	3 groups: A, B, C
FER		
Flash exposure compensation	Each slave is set manually.	Set with master.
Manual flash		
Repeating flash		

- All data are based on Canon's Standard Test Method.
- Subject to change without notice.

Canon

キヤノン株式会社／キヤノン販売株式会社

〒108-8011 東京都港区三田3-12-15 (東急三田ビル) カメラ相談センター (03) 3455-9353

CANON INC. 30-2, Shimomarucho 3-chome, Ohta-ku, Tokyo 146-8501, Japan

U.S.A.	CANON U.S.A., INC. For all inquiries concerning this camera, call toll free in the U.S. 1-800-828-4040 or write to: Customer Relations, Canon U.S.A., Inc. One Canon Plaza, Lake Success, N.Y. 11042-1198
CANADA	CANON CANADA INC. HEADQUARTERS 6390 Dixie Road, Mississauga, Ontario L5T 1P7, Canada CANON CANADA INC. MONTREAL BRANCH 5990, Côte de Liesse, Montreal Québec H4T 1V7, Canada CANON CANADA INC. CALGARY OFFICE 2828, 16th Street N.E. Calgary, Alberta T2E 7K7, Canada For all inquiries concerning this camera, call toll free in Canada 1 800 828-4040
EUROPE, AFRICA 8 MIDDLE EAST	CANON EUROPA N.V. Bovenkerkerweg 59 61, P.O. Box 2262 1180 EG Amstelveen, The Netherlands CANON PHOTO VIDEO FRANCE S.A. 102, avenue Charles de Gaulle 92250 La Garenne Colombes, France CANON UK LTD. Brent Trading Centre, Ninth Circular Road, London NW10 0JF, United Kingdom CANON EURO-PHOTO G.m.b.H. Siemensring 90 92, D-47877 Willich, Germany CANON ITALIA S.p.A. Palazzo L, Strada 6, 20089 Rozzano, Milanoliori, Milano, Italy CANON Benelux N.V./S.A. Bessenveldstraat 7, 1831 Diegen (Machelen), Belgium CANON Schweiz AG Geschäftsbereich Wiederverkauf, Industriestrasse 12, CH-8305 Dietlikon, Switzerland CANON G.m.b.H. Oberlaaerstrasse 233, 4th floor, 1100 Wien, Austria
CENTRAL & SOUTH AMERICA	CANON LATIN AMERICA, INC. DEPTO DE VENTAS 6505 Blue Lagoon Drive, Suite 325, Miami, FL 33126 U.S.A. CANON LATIN AMERICA, INC. CENTRO DE SERVICIO Y REPARACION Avenida 201, Zona Preuccion, Republica de Panamá
ASIA	CANON SINGAPORE PTE. LTD. 79 Anson Road #09 01.05 Singapore 079906
OCEANIA	CANON AUSTRALIA PTY. LTD. 1 Thomas Holt Drive, North Ryde, N.S.W. 2113, Australia CANON NEW ZEALAND LTD. Fred Thomas Drive, P.O. Box 33-336, Takapuna, Auckland, New Zealand
JAPAN	CANON SALES CO., INC. 12-15, Mita, 3 Chome, Minato-ku, Tokyo 108-8011, Japan

CT1 - 7724 - 001

© CANON INC. 1998

PRINTED IN JAPAN

0299Ni1.2