

Panasonic

Cordless Phone with Answering System

KX-T4410-B

Model No. KX-T4410D-B

Pulse-or-tone dialing capability

Operating Instructions



SOUND CHARGER
IMPL. G.L. 135

PLEASE READ BEFORE USE AND SAVE.

Charge the battery for 10 hours before initial use.

Getting Started

Cordless Telephone

Answering System

Useful Information

Before Initial Use

Please read **IMPORTANT SAFETY INSTRUCTIONS** on pages 56–57 before use. Read and understand all instructions.

Thank you for purchasing the Panasonic cordless telephone with answering system.

Attach your purchase receipt here.

Serial No

(found on the bottom of the unit)


Date of purchase

Name of dealer

Dealer's address

Accessories

AC Adaptor (p 10)




one

Telephone Line Cord (p 10)




one

Wall Mounting Adaptor (p 19)



one

Incoming Message Tape (MC-30) (p 9)



one


oTo order accessories, call 1-800-332-5368

For Best Performance

Battery Charge

To power the handset, charge the battery for **10 hours** before initial use (p 11)

The battery is beneath this cover




Operating Distance/Noise

Calls are transmitted between the base unit and the handset using wireless radio waves. **For maximum distance and noise free operation**, the recommended base unit placement is

Away from electrical appliances such as a TV, radio, or personal computer

In a **HIGH** and **CENTRAL** location with no obstructions such as walls



Contents

Getting Started

Location of Controls	6
Setting Up	9
Inserting the Incoming Message Tape	9
Connection	10
Battery Charge	11
Recording a Greeting Message	12
Programmable Preparations	14
Selecting the Number of Rings	15
Selecting the Caller's Recording Time	16
Setting the CPC (Calling Party Control) Function	17
Setting the Greeting Monitor Function	18
Wall Mounting	19

Cordless Telephone

Making Calls	20
Answering Calls	21
With the Handset	21
With the Base Unit	22
Automatic Dialing	23
Storing Phone Numbers in Memory	23
Dialing a Stored Number	24
Special Features	25
Automatic Security Code Setting	25
For Call Waiting Service Users	25
Temporary Tone Dialing	25
If Your Unit is Connected to a PBX	25
Intercom	26
Transferring a Call Using Intercom	28

Answering System


Automatic Answering Operation	29
Setting the Unit to Answer Calls	29
Listening to the Recorded Messages	30
Listening to New Messages	31
Listening to All the (saved) Messages	31
Resetting the Tape	32
Erasing All the Incoming Messages	32
Saving Specific Messages	32
Recording a Memo Message	33
Pager Call	34
Storing the Pager Number	34
Setting the Unit to Call the Pager	35
Remote Operation from a Touch Tone Phone	36
Setting the Remote Code Number	36
Remote Operation Sequence	38
Operation from the Handset	42
Operation Sequence	42


Useful Information

Battery Replacement	49
Maintenance of Cassette Tape and Deck	50
Adding Another Phone	51
Before Requesting Help	52
Cordless Telephone	52
Answering System	54
General	55
Important Safety Instructions	56
FCC and Other Information	58

Location of Controls


Base unit





Location of Controls

Handset





Inserting the Incoming Message Tape


- 1 Remove the stopper.



- 2 Open the cassette cover.




- 3 Insert the tape with the full reel to the right with the exposed tape facing you.



◇ Setting Up

Connection



- USE ONLY Panasonic AC ADAPTOR KX-A11.
- The AC adaptor must remain connected at all times.
(It may feel warm during use. This is normal.)




Battery Charge

Leave the handset on the base unit for **10 hours**.

- The IN USE/CHARGE indicator lights.

IN USE/CHARGE Indicator



Recharge

When the BATT LOW/PROG indicator flashes or beeps intermittently, **recharge** the battery.

BATT LOW/PROG Indicator



Standard battery life

If your Panasonic battery is fully charged;

While in use (TALK)	Up to about 8 hours
While not in use (Stand-By)	Up to about 30 days


- Battery life may vary depending on usage conditions and ambient temperature.
- The battery cannot be overcharged.
- Clean the charge contacts with a soft cloth once a month**, or the battery may not charge properly.
- Once the battery is fully charged, you do not have to place the handset on the base unit until the BATT LOW/PROG indicator flashes.

➤ Setting Up

Recording a Greeting Message

- 1 Press **GREETING RECORD**, then release it.
 - A long beep sounds.
- 2 Immediately after the long beep speak into **MIC** (microphone) 20 cm (8") away for up to 16 seconds.
 - The **IN USE** () indicator flashes slowly. After 13 seconds, it flashes quickly.

- 3 When finished recording, press **STOP**.
 - To change the greeting message, repeat from step 1.



- The greeting message can never be erased even if a power failure occurs.

To check the greeting message

Press **GREETING CHECK**.

- The recorded greeting is played.
- Adjust the speaker volume using **VOLUME**.
 - To increase, press \wedge .
 - To decrease, press \vee .

Sample of a greeting message

"Hello, this is (your name and/or number). Sorry, I cannot answer your call. Please leave your name, number and a short message after the long beep. Thank you."

Programmable Preparations

Summary of programming procedures

See the pages indicated with brackets for detailed procedures.

Make sure that the TALK indicator light is off before programming.

Lift the handset, then press **PROGRAM/2WAY REC**.



Press **SCREEN/PLAYBACK**.



◦ If an alarm tone sounds, move toward the base unit, then try again.

- **The remote code**, press "1". (page 36)
- **The number of rings**, press "2". (page 15)
- **The CPC function**, press "3". (page 17)
- **The greeting monitor function**, press "4". (page 18)
- **The caller's recording time**, press "5". (page 16)
- **The pager number**, press "#". (page 34)



◦ If 6 beeps sound, you pressed a wrong key. Try again.

When finished, press **PROGRAM/2WAY REC**.
The confirmation tone sounds.*

◦ To cancel the programming halfway, press **PROGRAM/2WAY REC**, then start from the beginning.

*Confirmation tone meaning

1 beep: The number is newly stored.

2 beeps: The number is the same as a previously stored one.

To confirm the current setting, repeat the same steps above and listen for the confirmation tone.

Selecting the Number of Rings

You can select the number of rings "1" to "7" or "AUTO" (preset) before your answering system answers a call. (See below.)

1 Lift the handset, then press **PROGRAM/2WAY REC**.

- The BATT LOW/PROG indicator lights.

2 Press **SCREEN/PLAYBACK**.

- The SCREEN/PLAYBACK indicator lights.

3 Press "2".


4 Press a number from "0" to "7" to set the number of rings.

0: "AUTO" is selected.
(Toll Saver)

1-7: The unit will answer on the selected number of rings.

5 When finished, press **PROGRAM/2WAY REC**.

- The indicator lights go out.



Toll Saver (When set to "AUTO"):

When you call the unit from a touch tone telephone,

- If the unit answers on the 2nd ring: There is at least one new message.
- If the unit answers on the 4th ring: There are no new messages.

If you hang up immediately after the 3rd ring, then you can save the toll charge.

➤ Programmable Preparations

Selecting the Caller's Recording Time

You may select the recording time of incoming calls to "unlimited (up to the tape end)" or "1 minute". The factory preset is "unlimited".

1 Lift the handset, then press **PROGRAM/2WAY REC**.

◦The BATT LOW/PROG indicator lights.

2 Press **SCREEN/PLAYBACK**.

◦The SCREEN/PLAYBACK indicator lights.

3 Press "5".


4 Press "1" or "2" to select the recording time.

1: "1 minute" is selected.

2: "unlimited" is selected.

5 When finished, press **PROGRAM/2WAY REC**.

◦The indicator lights go out.





Setting the CPC (Calling Party Control) Function

The CPC function is preset to "A". If you use a call waiting service, set to "B". If set to "A", the call waiting tone will disconnect someone leaving a message.

1 Lift the handset, then press **PROGRAM/2WAY REC**.

◦The BATT LOW/PROG indicator lights.

2 Press **SCREEN/PLAYBACK**.


◦The SCREEN/PLAYBACK indicator lights.

3 Press "3".

4 To select "B", press "2".
OR
To select "A", press "1".

5 When finished, press **PROGRAM/2WAY REC**.

◦The indicator lights go out.



➤ Programmable Preparations

Setting the Greeting Monitor Function

When the greeting message is played back to the caller, you may also hear it through the speaker. If you want to hear the message, set to "2 (ON)". The factory preset is "1 (OFF)".

1 Lift the handset, then press **PROGRAM/2WAY REC**.

◦The BATT LOW/PROG indicator lights.

2 Press **SCREEN/PLAYBACK**.

◦The SCREEN/PLAYBACK indicator lights.

3 Press "4".


4 To set to "ON", press "2".

OR

To set to "OFF", press "1".

5 When finished, press **PROGRAM/2WAY REC**.

◦The indicator lights go out.




Wall Mounting

This unit can be mounted on a wall phone plate.


- 1** Reverse the handset hook in the cradle so the tab will hold the handset.

- ① Push to remove.
- ② Rotate 180°.
- ③ Replace it with the tab upward.




- 2** Connect the AC adaptor. Tuck the telephone line cord inside the wall mounting adaptor, then push it in the direction of the arrow.

- The word "UP" should face upward.




- 3** Connect the telephone line cord. Mount the unit, then slide down.

- Extend the antenna fully.




- 4** **To charge the battery:** Place the handset on the handset hook as shown.

- The IN USE/CHARGE indicator lights.



Making Calls

- 1 Press **TALK**.
 - oThe indicator lights.
- 2 Dial a telephone number.
 - oIf you misdial, press **FLASH** firmly then dial again.
- 3 To hang up, press **TALK** or place the handset on the base unit.
 - oThe indicator light goes out.



oIf an alarm tone sounds in step 1, move toward the base unit or place the handset on the base unit and try again.

To redial the last number

Press **TALK** ⇨ **REDIAL/PAUSE**.

If noise interferes with the conversation

Press **CH** to select a clear channel or move closer to the base unit.

To set the receiver volume to HIGH or NORMAL (preset)

Press **VOLUME/RINGER** during a conversation.


- oEach time you press, the volume level will change.

Answering Calls



With the Handset

If the handset is off the base unit, press **TALK**



OR

If on the base unit, just lift it



Cordless Telephone

Any Key Talk

You can also answer the call by pressing any dialing button (0 to 9, *, or #)

Ringer Volume

Be sure the TALK and INTERCOM indicator lights are off

To set the volume to HIGH (preset) or LOW, press **VOLUME/RINGER**

• Each time you press, the bell sounds and the ringer volume will change

To turn the ringer OFF, while pressing **VOLUME/RINGER** press **0** until 2 beeps sound

To turn the ringer ON, press **VOLUME/RINGER**

• The ringer will sound at the HIGH level


◆ Answering Calls

With the Base Unit

1 Press **SP-PHONE**.

2 Speak into **MIC**.

3 To hang up, press **SP-PHONE**.




○For best performance of the speakerphone, use in a quiet room and speak alternately with the caller.

○When using the speakerphone, if the handset is on the base unit, you may switch to it by lifting up.

To set the ringer volume

Set the **RINGER** selector to **HIGH**, **LOW**, or **OFF**.

○When set to **OFF**, the base unit will not ring.



To adjust the speaker volume (8 levels)

To increase, press \wedge . To decrease, press \vee .

To put a call on hold

Press **HOLD**.

○If a call is put on hold for over 6 minutes, a warning tone will sound. The call will be disconnected after a total of 10 minutes.

To release the hold

Press **SP-PHONE** or lift the handset from the base unit.

○If another phone is connected on the same line, you can also lift that handset to release the hold feature.

Automatic Dialing

Storing Phone Numbers in Memory

The dialing buttons of the handset (0 to 9) function as memory stations.

- The TALK indicator light must be off.

1 Press **PROGRAM/2WAY REC**.

- The BATT LOW/PROG indicator lights.

2 Enter a phone number up to 16 digits.

- If you misdial, press **PROGRAM/2WAY REC** to end storing, then restart from step 1.

3 Press **AUTO**.


4 Press a memory station number (0 to 9).

- Confirmation tone sounds. (See below.)
- To store other numbers, repeat steps 1 through 4.

PROGRAM/2WAY REC

AUTO

BATT LOW/
PROG Indicator



Cordless Telephone

Confirmation tone meaning

1 beep: The number is newly stored.

2 beeps: The number is the same as a previously stored one.

➤ Automatic Dialing

To erase a stored number


Press **PROGRAM/2WAY REC** ➤ **AUTO** ➤ the memory station number to be erased

Memory sticker


You may use an included memory sticker as memorandum for automatic dialing. Write down the names or phone numbers, then attach it to the unit or at a convenient place.

Dialing a Stored Number

- 1 Press **TALK**
- 2 Press **AUTO**
- 3 Press the memory station number (0 to 9)
 - The stored number is dialed



Special Features



Automatic Security Code Setting

Whenever you place the handset on the base unit, the unit automatically selects one of 65,000 security codes. These codes help to avoid unauthorized use of your telephone line by another cordless telephone.

For Call Waiting Service Users

Press **FLASH** lightly if you hear a call-waiting tone during a conversation.

- The first call is put on hold and you can answer the second call.
- To return to the first call, press **FLASH** again.

Temporary Tone Dialing (For Rotary Service Users)

Press **TONE** before dialing.

- The dialing mode changes to tone. You can enter numbers to access the answering system or electronic banking services, etc. When you hang up, the mode returns to pulse.

If Your Unit is Connected to a PBX

We recommend you press **REDIAL/PAUSE** between the access number for an outside line and the phone number.

- Pressing **REDIAL/PAUSE** once makes a 3.5-second pause and prevents misdialing when you redial or dial a stored number.

Intercom


2-way intercom is available between the handset and the base unit.

Paging the base unit from the handset

Handset:


Press **INTERCOM**, then speak.

o To end the intercom,
press **INTERCOM**.



Base unit:

When the other party's voice is heard, talk into the **MIC**.



Paging the handset from the base unit (Handset locator)


Using this feature, you can locate the handset if it is misplaced.

Base unit:

Press **LOCATOR/INTERCOM**.

- The handset beeps for 1 minute.
- To stop paging, press **LOCATOR/INTERCOM**.

Speak into **MIC**.



Handset:

Press **INTERCOM** to answer.

- To end the intercom, press **INTERCOM**.



When using the intercom:

- Intercom calls can only be ended with the handset.
- If the handset user has difficulty hearing the base unit user, decrease the speaker volume by pressing ∇ .
- If two tones sound, it means there is an incoming call. To answer press **TALK** or **SP-PHONE**. The intercom is ended.

Transferring a Call Using Intercom

You can transfer an outside call between the handset and the base unit using intercom.

From the handset to the base unit

HANDSET

- 1 During a call, press **INTERCOM**, then speak to the base unit user.
 - The call is put on hold.



BASE UNIT

- 2 When the paging party's voice is heard, answer into the MIC.
- 3 To answer the call, press **SP-PHONE**.
 - The transfer is completed.
 - Handset user may join the conversation by pressing **TALK**.

From the base unit to the handset

BASE UNIT

- 1 During a call, press **HOLD**.
 - The call is put on hold.
 - The SP-PHONE indicator flashes.
- 2 Press **LOCATOR/INTERCOM** to page the handset.



HANDSET

- 3 When the handset beeps, press **INTERCOM** to answer the page.
- 4 Press **TALK** to answer the call.
 - The transfer is completed.
 - Base unit user may join the conversation by pressing **SP-PHONE**.


Automatic Answering Operation

When a call is received, the unit plays back your greeting message and records the caller's message

Setting the Unit to Answer Calls

Press **ANSWER ON** to turn on the answering system

- The button lights
- To turn off, press **ANSWER ON** again
The button's light goes out



- You can also turn on the answering system with your handset or a remote phone (p 41, 44)

Monitoring incoming calls


When an incoming call is being recorded, you can monitor the call using the speaker. Adjust the volume with **VOLUME**

To answer the call while monitoring, press **SP-PHONE** or **TALK**

The unit will stop recording

To monitor with the handset, see page 44

Listening to the Recorded Messages




- When the tape is full, the IN USE () indicator flashes rapidly. Use the opposite side of the tape or reset the tape (p. 32).
- When new incoming messages have been recorded, **ANSWER ON** flashes up to 15 times indicating the number of new messages.



Listening to New Messages

Only the new messages you have not listened to will be played back.




Press **NEW MESSAGE** lightly.

- A beep will sound.
- At the end of the newly recorded messages, 3 beeps sound and the tape stops.

Listening to All the (saved) Messages

All the recorded messages including the reviewed ones will be played back.




Press **NEW MESSAGE** firmly for more than 1 second.

- At the end of the recorded messages, 3 beeps sound and the tape stops.

To repeat the message	Press REW/REPEAT during playback. (If you press within 5 seconds of the playback, the previous message is played.)
To skip the message	Press FF/SKIP during playback. The next message is played.
To stop the operation	Press STOP .

➔ Listening to the Recorded Messages


Resetting the Tape



Press **REW/REPEAT** while not in playback.

- The tape is rewound to the beginning and new messages will be recorded over the old ones.


Erasing All the Incoming Messages




Press **ICM ERASE** after listening to all the recorded messages.

- The unit erases all the recorded messages while the tape rewinds.


Saving Specific Messages



Play back the recorded messages to the end of the message(s) you want to save.



Press **STOP**.




Press **ANSWER ON** to turn the answering system on.

- The button lights and the new messages will be recorded after the saved message(s).

Recording a Memo Message

You may record a personal message.

1



Press **MEMO REC**.

- A long beep sounds.


2



After the beep, speak clearly into **MIC** (microphone).

- The IN USE () indicator flashes.

3




When finished, press **STOP**.

Pager Call

Using this feature the unit informs you that you have received a message by calling your pager. Then you can retrieve the message by using any touch tone telephone.


Storing the Pager Number

Make sure that the TALK indicator light is off.




Lift the handset and press **PROGRAM/2WAY REC**.

o The BATT LOW/PROG indicator lights.




Press **SCREEN/PLAYBACK**.

o The SCREEN/PLAYBACK indicator lights.



Press "#".



Enter your pager number up to 30 digits.

o If necessary, press **REDIAL/PAUSE** twice*.

o If you misdial, press **PROGRAM/2WAY REC**, then restart from step 1.


* Your pager company may require a delay after the pager number is dialed. Contact the pager company regarding the pause time needed. Each time you press **REDIAL/PAUSE**, it creates a 3.5-second delay.

5



Enter the call back number you want to display on your pager.
(Press # if required by your pager company. Please confirm with your pager company.)

6



When finished, press **PROGRAM/2WAY REC**.

- The indicator lights go out.

To confirm the stored number

Press **SP-PHONE** ♦ **PAGER CALL**.


- The unit dials the stored number and the pager beeps.
- If the pager does not beep, start from step 1.

To erase the pager number

Press **PROGRAM/2WAY REC** ♦ **SCREEN/PLAYBACK** ♦ **#**
♦ **PROGRAM/2WAY REC**.

Setting the Unit to Call the Pager

Make sure that the pager number has been stored.



Press **PAGER CALL** to turn on the pager call mode.

- The PAGER CALL indicator lights.
- 6 beeps are heard if the pager number is not stored.
- The unit will call your pager only once about 30 seconds after recording each message.
- To turn off, press **PAGER CALL** again.

Remote Operation from a Touch Tone Phone


You can operate the answering system from a remote touch tone phone.

Setting the Remote Code Number

The remote code prevents unauthorized persons from listening to your messages.

Make sure that the TALK indicator light is off.


1



Press **PROGRAM/2WAY REC**.

◦The BATT LOW/PROG indicator lights.


2



Press **SCREEN/PLAYBACK**.


◦The SCREEN/PLAYBACK indicator lights.

3



Press "1".


4



Enter a 2-digit remote code number (00-99).



5



When finished,
press **PROGRAM/2WAY REC**.

- The indicator lights go out.
- Confirmation tone sounds.
(See below.)

Confirmation tone meaning

1 beep: The number is newly stored.

2 beeps: The number is same as a previously stored one.

To confirm the current setting, repeat the same steps and listen for the confirmation tone(s).

➤ Remote Operation from a Touch Tone Phone

Remote Operation Sequence

1

Call your unit from a touch tone telephone.



2

Press **the Remote Code Number** during the greeting message playback.

◦ Short beeps sound up to 8 times, to indicate the number of new messages.



3

Enter **the Remote Access Key**.

◦ Refer to the Remote Access Key List on pages 39 and 40.



4

Hang up. The messages are saved.



Remote Access Key List

NEW MESSAGE
PLAYBACK

4

- Only new messages are played back.
- 3 beeps sound at the end of playback. If you hear 6 long beeps, the incoming message tape is full. Reset the tape.

ALL MESSAGE
PLAYBACK

5

- All the messages are played back.
- 3 beeps sound at the end of playback.
- If you hear 6 long beeps, the incoming message tape is full. Reset the tape.

REPEAT

1

- The current message is repeated from the beginning.

SKIP

2

- The current message is skipped. Playback starts from the next message.

STOP

9

- Playback is stopped temporarily. To resume press **9** again within 15 seconds, or the call will be disconnected.

RESET

3

- Press within 10 seconds after hearing the last message.
- If pressed after new message playback, it will rewind to the beginning of the new messages. To rewind to the beginning of the tape press **3** again after the beep.
- If pressed after all message playback, the tape will rewind to the beginning of the tape.
- To cancel the reset to save the messages, press **2**.

➡ Remote Operation from a Touch Tone Phone

ROOM SOUND
MONITOR

6

- The sound around the base unit is monitored for 30 seconds.
- At the end of monitoring a beep sounds. To continue, press **6** again within 10 seconds.

GREETING
MESSAGE
RECORDING

7

- A long beep sounds.

◇

RECORD
MESSAGE

- Speak immediately after the long beep up to 16 seconds.

◇

9

- The new recorded message is played back.

PAGER CALL ON

*
7

- Pager call feature is turned on.
- If you hear 6 beeps, the pager number is not stored. Store the number using the handset. (p. 34)

◇

7

PAGER CALL OFF

*
7

- Pager call feature is turned off.

◇

8

ANSWERING
SYSTEM OFF

0

- The answering system is turned off.

Skipping the greeting message

Callers can record messages without listening to the greeting.

After calling your unit press ***** during the greeting message playback.

•The unit skips the rest of the greeting and starts recording.

Recording your own message (Marker message)

You can record your own message on the tape after listening to the last message.

1. Wait for 3 beeps indicating the end of the last message and another 10 seconds for 2 more beeps. Then leave your message.
2. When finished, hang up.

Turning on the answering system

Call your unit and wait for 15 rings.

- The unit will answer and the greeting message is played.
- Hang up or enter the remote code number for more options.

Operation from the Handset


You can operate your answering system from the handset.

Operation Sequence

1

Press **SCREEN/PLAYBACK**.

- The indicator lights.
- Short beeps sound up to 8 times, indicating the number of new messages.



- If the SCREEN/PLAYBACK indicator flashes, the answering system is off. To turn on, see page 44.

2

Enter **the Access Key**.


- Refer to the Access Key List on pages 43 and 44.



3

Press **SCREEN/PLAYBACK** to end the operation.

- The indicator light goes out.



- When an incoming message has been recorded, 4 short beeps sound twice on the handset.



Access Key List

NEW MESSAGE
PLAYBACK

4

- Only new messages are played back.
- 3 beeps sound at the end of playback.
- If you hear 6 long beeps, the incoming message tape is full. Reset the tape.

ALL MESSAGE
PLAYBACK

5

- All of the messages are played back.
- 3 beeps sound at the end of playback.
- If you hear 6 long beeps, the incoming message tape is full. Reset the tape.

REPEAT

1

- The current message is repeated from the beginning.

SKIP

2

- The current message is skipped. Playback starts from the next message.

STOP

9

- Playback is stopped temporarily. To resume press **9** again within 15 seconds or the remote operation will be terminated.

RESET

3

- Press within 10 seconds after hearing the last message.
- If pressed after new message playback, it will rewind to the beginning of the new messages. To rewind to the beginning of the tape press **3** again after the beep.
- If pressed after all message playback, the tape will rewind to the beginning.
- To cancel the reset to save the message, press **2**.

➔ Operation from the Handset

ROOM SOUND
MONITOR



- The sound around the base unit is monitored for 30 seconds.
- At the end of monitoring a beep sounds. To continue, press **6** again within 10 seconds.

ANSWERING
SYSTEM ON



- The answering system is turned on. The SCREEN/PLAYBACK indicator lights.

ANSWERING
SYSTEM OFF



- The SCREEN/PLAYBACK indicator light flashes and the answering system is turned off.

PAGER CALL ON



- Pager call feature is turned on.
- If you hear 6 beeps, the pager number is not stored. Store the number. (p. 34)



PAGER CALL OFF



- Pager call feature is turned off.



Monitoring incoming calls

When the SCREEN/PLAYBACK indicator flashes slowly, an incoming message is being recorded.


1. Press **SCREEN/PLAYBACK**.
 - The indicator turns to a steady light and you can listen to the incoming call.
 - To answer the call, press **TALK**. The recording is ended.
2. When finished, press **SCREEN/PLAYBACK**.

Recording your telephone conversation

- During a conversation, press **PROGRAM/2WAY REC**.
 - The SCREEN/PLAYBACK indicator lights and recording begins.
- Continue your conversation.
- When finished, press **PROGRAM/2WAY REC**.
 - The SCREEN/PLAYBACK indicator light goes out.

Many states have imposed regulations on the manner in which 2-way telephone conversations may be recorded, so you should inform the other party that the conversation is being recorded. Consult your local telephone company for further information.

OPERATION FROM TONE PHONE




Call your unit.


Press remote code no. _____

- To play back new messages, press **4**.
- To play back all messages, press **5**.
- To repeat, press **7**.
- To skip, press **2**.
- To reset the tape after playback, press **3**.
- To record your message, speak after 2 beeps following the 3 beeps at the end of playback.
- To save the messages, hang up after playback.

When you press a button, press firmly.



OPERATION FROM HANDSET




If the SCREEN/PLAYBACK indicator flashes when you press **SCREEN/PLAYBACK**, the answering system is off. To set the unit to answer calls, press "8".

Press **SCREEN/PLAYBACK**.

- To play back new messages, press "4".
- To play back all messages, press "5".
- To repeat, press "1".
- To skip, press "2".
- To reset the tape after playback, press "3".

Press **SCREEN/PLAYBACK** to end the operation.

OPERATION FROM TONE PHONE



Call your unit.

Press remote code no. _____

- To play back new messages, press [4].
- To play back all messages, press [5].
- To repeat, press [1].
- To skip, press [2].
- To reset the tape after playback, press [3].
- To record your message, speak after 2 beeps following the 3 beeps at the end of playback.
- To save the messages, hang up after playback.

When you press a button, press firmly.

Press **SCREEN/PLAYBACK**.

- To monitor the room sound, press "6".
- To turn off the answering system, press "0".
- To turn on the pager call feature, press "*7".
- To turn off the pager call feature, press "*8".

Press **SCREEN/PLAYBACK** to end the operation.

To monitor incoming calls:

When the **SCREEN/PLAYBACK** indicator flashes slowly, press **SCREEN/PLAYBACK**. When finished, press the button again.

To answer the call, press **TALK**.

To record your telephone conversation:

1. During a conversation, press **PROGRAM/2WAY REC**.
2. Continue your conversation.
3. When finished, press **PROGRAM/2WAY REC**.

Call your unit.

To skip greeting message, press **[6]**.

Press remote code no. _____

To turn off the answering system, press **[0]**, then hang up.

To re-record the greeting message,

1. Press **[7]** to re-record the greeting message.
2. Speak after a long beep.
-The recording time is up to 16 seconds.
3. When finished, press **[9]**.

To turn on the pager call feature, press **[*] [7]**.

To turn off the pager call feature, press **[*] [8]**.

To monitor room sound, press **[6]**.

To turn on the answering system, call your unit and wait for 15 rings. The unit will answer, then hang up.

Battery Replacement

If the BATT LOW/PROG indicator flashes after being fully charged, replace with a new Panasonic KX-A36A battery. (To order, call 1-800-332-5368.) To prevent memory loss, replace within 5 minutes.


- 1 Remove the cover.



- 2 Replace the battery, then close the cover.



- 3 Charge the new battery for 10 hours.



Attention:


The product that you have purchased contains a rechargeable battery. The battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal.



Maintenance of Cassette Tape and Deck


Cassette tape

- For optimum sound quality and performance, we recommend that you **use the opposite side of the cassette tape after six months and replace the tape with a new one every year**, assuming that the unit answers about ten calls a day.
- Never place a cassette tape near a magnetic source, such as a magnet or a TV set. It may erase or distort the recorded message(s) on the tape.
- Slack in the tape can be tightened by rotating the tape reel with an instrument like a pencil, as shown.



Tape deck

Since the head and capstan assemblies are in contact with the tape, dirt and residue from the tape may easily adhere to these parts, causing distortion. These parts should be cleaned periodically in the following manner. Clean the head surface, pinch roller, and capstan with a cotton swab. If these surfaces are extremely dirty, wipe them with the cotton swab dampened with alcohol, then dry with a soft cloth.




- Do not bring magnetic or metal objects, such as a screwdriver, near the head assemblies. These objects can magnetize the heads.
- Do not oil any part of the unit.

Cassette cover installation


If the cover comes off, replace it by pushing as shown.

Insert into the slots in the base unit carefully.



Adding Another Phone

This unit will not function during a power failure. To connect a standard telephone on the same line, use a Panasonic T-adaptor KX-J66. See the illustration below. (To order, call 1-800-332-5368.)



Before Requesting Help

Cordless Telephone

Problem	Remedy
Static, sound cuts in/out, fades. Interference from other electrical appliances.	<ul style="list-style-type: none">◦Set the handset and base unit away from electrical appliances.◦Move closer to the base unit.◦Extend the base unit antenna.◦Press (CH) to change the channel.
Alarm tone sounds when you press (TALK) , (SCREEN/PLAYBACK) or (INTERCOM) .	<ul style="list-style-type: none">◦Move toward the base unit and try again.◦Place the handset on the base unit and try again.◦Plug in the AC adaptor.◦Clean the charge contacts and charge again.
The handset does not ring.	<ul style="list-style-type: none">◦The ringer volume is "OFF". Press (VOLUME/RINGER) when the TALK and INTERCOM indicator lights are off.
The base unit does not ring.	<ul style="list-style-type: none">◦The RINGER selector is set to "OFF". Set to "HIGH" or "LOW".
You cannot store a phone number.	<ul style="list-style-type: none">◦The unit is in the talk or intercom mode.◦Do not pause for over about 30 seconds while storing.
While storing a phone number, the unit starts to ring.	<ul style="list-style-type: none">◦Press (TALK) or (SP-PHONE) to answer. Restart storing after the call is ended.
During intercom two tones are heard.	<ul style="list-style-type: none">◦An outside call is received. To answer, press (TALK) or (SP-PHONE).
(REDIAL/PAUSE) does not function properly.	<ul style="list-style-type: none">◦The button has a double function; redial before dialing (p. 20) and pause during dialing (p. 25).



Problem

Remedy

VOLUME/RINGER does not function properly.

- The button has a double function; receiver volume selector during a conversation (p. 20) and a ringer selector when the TALK and INTERCOM indicator lights are off (p. 21).

LOCATOR/INTERCOM does not function properly.

- The handset is too far from the base unit or an outside call is in process.

➤ Before Requesting Help

Answering System

Problem	Remedy
The answering system is on, but incoming messages cannot be recorded.	◦The incoming message tape is full. Use the opposite side or reset the tape.
You cannot operate the answering system from a touch tone phone.	◦Turn the answering system on. (p. 41) ◦Press your correct remote code number. ◦Press each button firmly to produce a long tone. ◦In some areas, a remote touch tone phone may not function due to telephone line conditions.
You cannot operate the answering system from the base unit.	◦The handset is in use. Wait till the IN USE/CHARGE indicator goes out.
Some incoming messages are not recorded to the end.	◦Set the CPC function to "B". (p. 17)
I cannot operate the answering system with the handset.	◦Move toward the base unit. ◦Someone is using the answering system.
The VOLUME does not function properly.	◦Clean the heads.
4 short beeps are heard twice from the handset.	◦A new message has just been recorded.
While operating the answering system from the handset, two tones are heard.	◦An incoming call is received. Press TALK to answer. The handset operation is ended.
The PROGRAM/2WAY REC does not function properly.	◦The button has a double function. If pressed during a conversation, the unit records the conversation. If pressed when the TALK indicator light is off, the unit enters the programming mode.

General

Problem	Remedy
The BATT LOW/PROG indicator flashes. Beeps sound intermittently.	◦Charge the battery fully. (p. 11)
You charged the battery fully, but the BATT LOW/PROG indicator flashes after a few telephone calls.	◦Clean the charge contacts and charge again. ◦Replace with a new battery. (p. 49)
You cannot set-up any programmable preparations such as selecting the number of rings.	◦You cannot program while the unit is in the talk or intercom mode.
During the programmable preparations, the unit starts to ring.	◦Press TALK or SP-PHONE to answer. Restart programming after the call is ended.
The unit does not work.	◦Check the setting up. (p. 10) ◦Clean the charge contacts and charge the battery fully. ◦Place the handset on the base unit for security code's identity.
While operating the unit, the AC adaptor feels warm. The IN USE/CHARGE indicator lights while the handset is on the base unit.	◦These are normal operating conditions.
I cannot use the unit during a power failure.	◦The unit will not function during a power failure. ◦You may connect another telephone. (p. 51)
The unit stops working during operation.	◦Place the handset on the base unit and unplug the AC adaptor to reset. Plug in then try again.
If you cannot solve your problem.	◦Call our customer satisfaction center at 201-348-9090.

Important Safety Instructions

When using this unit, basic safety precautions should always be followed to reduce the risk of fire, electric shock, or personal injury.

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the unit.
3. Unplug this unit from wall outlets before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this unit near water, for example, near a bath tub, wash bowl, kitchen sink, or the like. Never spill any liquid on the unit.
5. Install this unit securely on a stable surface. Serious damage and/or injury may result if the unit falls.
6. Do not cover slots and openings on the unit. They are provided for ventilation and protection against overheating. Never place the unit near radiators, or a place where proper ventilation is not available.
7. Use only the power source as marked on the unit. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.
8. Do not place objects on the power cord. Install the unit where no one can step or trip on the cord.
9. Do not overload wall outlets and extension cords. This can result in the risk of fire or electric shock.
10. Never push any objects into the unit through the slots. This may result in the risk of fire or electric shock.
11. To reduce the risk of electric shock, do not disassemble this unit. Take it to an authorized servicer when service is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.
12. Unplug this unit from the wall outlet and refer servicing to an authorized servicer when the following conditions occur:
 - A. When the power supply cord or plug is damaged or frayed.
 - B. If liquid has been spilled into the unit.
 - C. If the unit has been exposed to rain or water.
 - D. If the unit does not work normally by following the operating instructions. Adjust only controls covered by the operating instructions. Improper adjustment of internal controls may require extensive work by an authorized servicer.
 - E. If the unit has been dropped or physically damaged.
 - F. If the unit exhibits a distinct change in performance.
13. During thunderstorms, avoid using telephones except cordless types. There may be a remote risk of an electric shock from lightning.
14. Do not use this unit to report a gas leak, when in the vicinity of the gas leak.

SAVE THESE INSTRUCTIONS

CAUTION:

To reduce the risk of fire or injury to persons, read, understand and follow these instructions.

1. Use only the battery(ies) specified by the manufacturer.
2. Do not dispose of the battery(ies) in a fire. They may explode. Check with local waste management codes for special disposal instructions.
3. Do not open or mutilate the battery(ies). Released electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
4. Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets, and keys. The battery or conductor may overheat and cause burns.
5. Charge the battery(ies) that are provided or identified for use with this product only in accordance with the instructions and limitations specified in this manual.

WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR ANY TYPE OF MOISTURE.

FCC and Other Information

If requested by the telephone company, inform them as follows:

FCC registration No.(found on the bottom of the unit)
Ringer Equivalence0.2B

The particular telephone line to which the equipment is connected.

This unit must not be connected to a coin operated line.

If you are on a party line, check with your local telephone company.

Ringer Equivalence No. (REN):

The REN is useful in determining the quantity of devices you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the REN's of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices you may connect to your line, as determined by the REN, you should contact your local telephone company to determine the maximum REN for your calling area.

In the event terminal equipment causes harm to the telephone network, the telephone company should notify the customer, if possible, that service may be stopped.

However, where prior notice is impractical, the company may temporarily cease service providing that they:

- (a) Promptly notify the customer.
- (b) Give the customer an opportunity to correct the problem with their equipment.
- (c) Inform the customer of the right to bring a complaint to the Federal Communication Commission pursuant to procedures set out in FCC Rules and Regulations Subpart E of Part 68.

The Telephone Company may make changes in its communications facilities, equipment, operations or procedures, where such action is reasonably required in the operation of its business and is not inconsistent with the rules and regulations in FCC Part 68.

If such changes can be reasonably expected to render any customer terminal equipment incompatible with telephone company communications facilities, or require modification or alteration of such terminal equipment, or otherwise materially affect its use or performance, the customer shall be given adequate notice in writing, to allow the customer an opportunity to maintain uninterrupted service.

CAUTION:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

When programming emergency numbers and/or making test calls to emergency numbers:

1. Remain on the line and briefly explain to the dispatcher the reason for the call before hanging up.
2. Perform such activities in the off-peak hours, such as early morning hours or late evenings.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Privacy of communications may not be ensured when using this phone.

- **Environment**—do not place the unit in room where the temperature is less than 5°C (41°F) or greater than 40°C (104°F). Allow 10 cm (4") clearance around the unit for proper ventilation. Avoid excessive smoke, dust, mechanical vibration, shock, or direct sunlight.
- **Routine care**—wipe the unit with a soft cloth. Do not use benzine, thinner, or any abrasive powder. When you leave the unit unused for long time, unplug the AC adaptor from the outlet.
- **If there is any trouble**—disconnect the unit from the telephone line and connect a known working phone. If the known working phone operates properly, have your unit repaired by one of the authorized Panasonic Factory Service Centers. If the known working phone does not operate properly, consult with your telephone company.

For product service

- Panasonic Servicenters are listed in the servicenter directory.
- Call 1-800-545-2672 for the location of an authorized servicenter.

When you ship the product

- Carefully pack your unit, preferably in the original carton.
- Attach a letter, detailing the symptom, to the outside of the carton.

Symptom

- Send the unit to an authorized servicenter, prepaid and adequately insured.
- Do not send your unit to the Matsushita Consumer Electronics Company listed below or to executive or regional sales offices. These locations do not repair consumer products.

- This cordless telephone is designed for use in the United States of America. Sale or use of this product in other countries may violate local laws.
- Ce téléphone sans fil est conçu pour être utilisé aux États-Unis d'Amérique. La vente ou l'emploi de cet appareil dans certains autres pays peut constituer une infraction à la législation locale.
- Este teléfono sin cordón fue elaborado para uso en los Estados Unidos de América. La venta o el empleo de este producto en ciertos países puede constituir violación de la legislación local.
- このコードレス電話機は、日本国外での使用を目的として設計されており、日本国内での使用は法律違反となります。従って、当社では日本国内においては原則として修理などのサービスは致しかねます。

Matsushita Consumer Electronics Company,
Division of Matsushita Electric Corporation of America
One Panasonic Way, Secaucus, New Jersey 07094

Panasonic Sales Company ("PSC"),
Division of Matsushita Electric of Puerto Rico, Inc.
Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park
Carolina, Puerto Rico 00985